

11/21+ RLV11 RL11/RLV11 CTRL TST 2
RL01/02 CNRLHA0

COPYRIGHT (c) 1979-83
AH-T758A-MC
FICHE 1 OF 1

APR 1984
digital
Made In USA

This microfiche card contains a grid of frames. The frames are arranged in approximately 12 rows and 10 columns. Each frame contains a different view of data, likely related to the RL11/RLV11 control test. The data is presented in various formats, including tables, diagrams, and text. The text is small and difficult to read, but it appears to be technical information. The diagrams show various components and their relationships. The overall layout is organized and systematic, typical of a microfiche card used for data storage and retrieval.

.TITLE CNRLHAO RL11/RLV11 CTLR TST 2
.NLIST TOC
.REM @

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
47

IDENTIFICATION

PRODUCT CODE: AC-T757A-MC
PRODUCT NAME: CNRLHAO RL11/RLV11 CONTROLLER TEST 2
PRODUCT DATE: DECEMBER 19, 1983
MAINTAINER: ISS DIAGNOSTIC SERVICES
AUTHOR: JAMES S. DOUCETTE

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS MANUAL.

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED TO THE PURCHASER UNDER A LICENSE FOR USE ON A SINGLE COMPUTER SYSTEM AND CAN BE COPIED (WITH INCLUSION OF DIGITAL'S COPYRIGHT NOTICE) ONLY FOR USE IN SUCH SYSTEM, EXCEPT AS MAY OTHERWISE BE PROVIDED IN WRITING BY DIGITAL.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

COPYRIGHT (C) 1983, DIGITAL EQUIPMENT CORPORATION

49
 50
 51
 52
 53
 54
 55
 56
 57
 58
 59
 60
 61
 62
 63
 64
 65
 66
 67
 68
 69
 70
 71
 72
 73
 74

REVISION HISTORY

CHANGES MADE TO CZRLH00 IN PRODUCING CNRLH00 FOR THE SBC-11/21+ (FALCON-PLUS),
 DEC. 19, 1983. CHANGES ARE IDENTIFIED BY ";JSD REV A".

1. CHANGED THE FORM OF THE ARGUMENT TO ALL "DELAY" MACRO CALLS FROM @<VALUE> TO <VALUE>. THE FORMER GAVE ASSEMBLY ERRORS UNDER THE VAX/VMS DEVELOPMENT ENVIRONMENT (MCR MAC).
2. CHANGED THE GENERAL OPERATING PRIORITY OF THE PROGRAM FROM LEVEL 7 TO LEVEL 6 TO ALLOW THE "BREAK" KEY TO INVOKE ODT. (THE TRAP HANDLER AND DEVICE INTERRUPT SERVICE ROUTINES STILL RUN BRIEFLY AT LEVEL 7).
3. SET VECTOR 140 WITH THE ADDRESS OF ODT IN ROM (170000).
4. PREVENTED THE EXECUTION OF TEST 7, WHICH IS DEPENDENT ON CLOCK INTERRUPTS. UNDER FALCON-PLUS, CLOCK OPERATION IS NOT GUARANTEED. CLOCK INTERRUPTS MAY OR MAY NOT BE HARD-ENABLED, AND EVEN IF THEY WERE, THE INTERRUPT RATE COULD BE 50, 60, OR 800 HERTZ. FURTHERMORE, THE DRS CLOCK MACROS RETURN MISLEADING INFORMATION (UNDER FALCON-PLUS).

76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117
118

TABLE OF CONTENTS

1.0	GENERAL INFORMATION
1.1	PROGRAM ABSTRACT
1.1.1	STRUCTURE OF PROGRAM
1.1.2	DIAGNOSTIC INFORMATION
1.2	SYSTEM REQUIREMENTS
1.2.1	HARDWARE REQUIREMENTS
1.2.2	SOFTWARE REQUIREMENTS
1.3	RELATED DOCUMENTS AND STANDARDS
1.4	DIAGNOSTIC HIERARCHY PREREQUISITES
1.5	ASSUMPTIONS
2.0	OPERATING INSTRUCTIONS
2.1	HOW TO RUN THIS DIAGNOSTIC
2.1.1	THE FIVE STEPS OF EXECUTION
2.1.2	SAMPLE RUN-THROUGH
2.2	CHAIN MODE OPERATION
2.3	DETAILS OF COMMANDS AND SYNTAX
2.3.1	TABLE OF COMMAND VALIDITY
2.3.2	COMMAND SYNTAX
2.4	EXTENDED P-TABLE DIALOGUE
2.5	HARDWARE PARAMETERS
2.6	SOFTWARE PARAMETERS
3.0	ERROR INFORMATION
3.1	ERROR HALTS
4.0	PERFORMANCE AND PROGRESS REPORTS
4.1	PERFORMANCE REPORTS
4.2	PROGRESS REPORTS
5.0	DEVICE INFORMATION TABLES
6.0	TEST SUMMARIES

120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166

1.0 GENERAL INFORMATION

1.1 PROGRAM ABSTRACT

1.1.1 STRUCTURE OF PROGRAM

THIS DIAGNOSTIC IS COMPATIBLE WITH BOTH CNDP+ AND ACT. IT CAN BE RUN STANDALONE UNDER CNDP+, AND CAN BE CHAINED UNDER CNDP+, ACT AND APT IN ACT MODE (SEE 2.2 "CHAIN MODE OPERATION" FOR DETAILS OF CHAINING PROCEDURE). IT IS A SINGLE PROGRAM FROM THE STANDPOINT OF THE DIAGNOSTIC USER, WHICH AT RUN TIME IS APPENDED TO A COMMON FRONT-END PIECE OF SUPERVISOR SOFTWARE THROUGH WHICH THE DIAGNOSTIC PROGRAM INTERFACES TO THE ENVIRONMENT AS IT EXECUTES. (IN THIS DOCUMENT, "CNDP+" REFERS TO THE FALCON-SPECIFIC XXDP+ SYSTEM).

WHEN THIS DIAGNOSTIC IS STARTED, CONTROL GOES FIRST TO THE SUPERVISOR PORTION, WHICH WILL ASK CERTAIN "HARD CORE" QUESTIONS ABOUT THE ENVIRONMENT. THEN IT WILL ENTER COMMAND MODE, INDICATED BY A PROMPT CHARACTER (DR>). AT COMMAND MODE THE OPERATOR MAY ENTER ANY OF SEVERAL COMMANDS AS DESCRIBED IN 2.0 "OPERATING INSTRUCTIONS".

THE DIAGNOSTIC PROGRAM IS LOADED IN THE LOWER 8K OF MEMORY. THE DIAGNOSTIC SUPERVISOR CODING OCCUPIES 6.25K OF THE UPPER PART OF MEMORY JUST BELOW THE CNDP+ MONITOR WHICH RESIDES IN THE UPPERMOST 1.5K OF MEMORY SPACE.

1.1.2 DIAGNOSTIC INFORMATION

THE RL11/RLV11 CONTROLLER TEST (PART 2) IS A KXT-11 BASED PROGRAM THAT WILL TEST THE CONTROLLER. IT COMPLEMENTS PART 1 BY EXTENDING THE TEST COVERAGE TO INCLUDE WRITE DATA, READ DATA, WRITE CHECK AND READ DATA WITHOUT HEADER COMPARE. IT IS AIMED AT FULLY TESTING THE CONTROLLER IN THESE AREAS, BUT BY DEFAULT ALSO EXERCISES THE DRIVE.

1.2 SYSTEM REQUIREMENTS

168
169
170
171
172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196
197
198
199
200
201
202
203
204
205
206
207
208
209
210
211
212
213
214
215
216
217
218
219
220

1.2.1 HARDWARE REQUIREMENTS

- * SBC-11/21+ PROCESSOR, 28KW MEMORY, JUMPERED FOR MEMORY MAP 0
- * CONSOLE DEVICE (LA30,LA36,VT50,ETC.)
- * 1 OR 2 RL11/RLV11 CONTROLLER(S) WITH:
 - 1 - 8 RL01 DRIVES WITH RL01K CARTRIDGES CONTAINING A 'BAD SECTOR FILE'
 - 1 - 8 RL02 DRIVES WITH RL02K CARTRIDGES CONTAINING A 'BAD SECTOR FILE'
- * CNDP+ (XXDP+) LOAD DEVICE (RL02, RX02, ETC.)
- * LINE PRINTER (OPTIONAL)

1.2.2 SOFTWARE REQUIREMENTS

CNRLHA RL11/RLV11 CTLR TEST 2

1.3 RELATED DOCUMENTS AND STANDARDS

RL01 DISK SUBSYSTEM USER'S GUIDE (EK-RL01-UG-002)
XXDP+/SUPERVISOR USER'S MANUAL

1.4 DIAGNOSTIC HIERARCHY PREREQUISITES

THE RL01/02 SUBSYSTEM SHOULD HAVE SUCCESSFULLY RUN THE FOLLOWING PROGRAMS:

CVRLABO	RLV11 RL01 DISKLESS TEST (RLV11 ONLY)
CNRLGAO	RL11/RLV11 RL01/02 CONTROLLER TEST (PART 1)

1.5 ASSUMPTIONS

THE HARDWARE OTHER THAN THE RL01/02 SUBSYSTEM IS ASSUMED TO WORK PROPERLY. FALSE ERRORS MAY BE REPORTED IF THE PROCESSOR, ETC., DO NOT FUNCTION PROPERLY.

2.0 OPERATING INSTRUCTIONS

222
223
224
225
226
227
228
229
230
231
232
233
234
235
236
237
238
239
240
241
242
243
244
245
246
247
248
249
250
251
252
253
254
255
256
257
258
259
260
261
262
263
264
265
266
267
268
269
270
271
272
273

2.1 HOW TO RUN THIS DIAGNOSTIC

2.1.1 THE FIVE STEPS OF EXECUTION

THIS DIAGNOSTIC PROGRAM SHOULD BE LOADED AND STARTED USING NORMAL XXDP+ PROCEDURES. START THE EXECUTION OF THE CNDP+ MONITOR BY USING THE APPROPRIATE BOOTSTRAP PROGRAM. THE MONITOR WILL PRINT A MESSAGE IDENTIFYING ITSELF AND REQUESTING THAT THE CURRENT DATE BE ENTERED. AN EXAMPLE OF THIS MESSAGE IS GIVEN BELOW FOR THE CNDP+ MONITOR:

CNMDYAO CNDP+ DY MONITOR
BOOTED VIA UNIT 0
ENTER DATE (DD-MMM-YY):

AFTER THE DATE HAS BEEN ACCEPTED BY THE MONITOR THE RESTART ADDRESS OF THE MONITOR IS PRINTED. THEN THE FOLLOWING TWO QUESTIONS ARE ASKED:

50 HZ ? N
LSI ? N

THE DEFAULTS ARE BOTH "NO". TYPE "R" AND THE PROGRAM NAME TO RUN THE PROGRAM. DO NOT TYPE THE EXTENSION.

WHEN THIS DIAGNOSTIC IS STARTED THE FOLLOWING 5 STEPS WILL OCCUR:

* STEP 1 *

THE DIAGNOSTIC WILL ISSUE THE PROMPT "DR>". FROM THIS POINT UNTIL THE TIME WHEN YOU RESTART CNDP+, YOU WILL BE TALKING TO THE DIAGNOSTIC, NOT CNDP+. WE WILL REFER TO THE PRESENCE OF THIS PROMPT AS BEING IN DIAGNOSTIC COMMAND MODE, AS OPPOSED TO CNDP+ COMMAND MODE.

AT THIS POINT YOU WILL ENTER A "START" COMMAND. THIS IS NOT THE SAME AS THE CNDP+ "START" COMMAND, WHICH YOU ALREADY ISSUED IN RESPONSE TO THE CNDP+ DOT PROMPT. THIS "START" COMMAND CAN TAKE A NUMBER OF SWITCHES AND FLAGS (ALL OPTIONAL) AND THE DETAILS OF THESE ARE SET FORTH IN 2.3 "DETAILS OF COMMANDS AND SYNTAX". HOWEVER, IN ORDER TO USE THE PROGRAM, ALL YOU NEED TO SAY IS SOMETHING LIKE THIS:

STA/PASS:1/FLAGS:HOE

275
276
277
278
279
280
281
282
283
284
285
286
287
288
289
290
291
292
293
294
295
296
297
298
299
300
301
302
303
304
305
306
307
308
309
310
311
312
313
314
315
316
317
318
319
320
321
322
323
324
325
326
327
328
329

THINGS TO NOTE HERE:

1. ONLY THE FIRST THREE CHARACTERS OF THIS OR ANY COMMAND AT THE "DR>" LEVEL NEED TO BE TYPED.
2. THE "PASS" SWITCH SPECIFIES HOW MANY PASSES YOU DESIRE. A PASS CONSISTS OF RUNNING THE FULL DIAGNOSTIC AGAINST ALL UNITS BEING TESTED (THIS WILL BE EXPLAINED SHORTLY). ONE PASS IS SPECIFIED IN THE ABOVE EXAMPLE.
3. THE "FLAGS" SWITCH MAY SPECIFY ANY OF A NUMBER OF FLAGS, BUT THE MAIN USEFUL ONES ARE:

PNT	PRINT NUMBER OF TEST BEING EXECUTED
LOE	LOOP ON ERROR
HOE	HALT ON ERROR
IER	INHIBIT ERROR PRINTOUT

THE HOE FLAG IS SPECIFIED IN THE ABOVE EXAMPLE (WE'LL SEE WHY SHORTLY).

* STEP 2 *

WHEN YOU HAVE TYPED IN A "START" COMMAND, THE DIAGNOSTIC WILL COME BACK WITH THE QUESTION "# UNITS?" TO WHICH YOU SHOULD RESPOND BY TYPING IN THE NUMBER OF DEVICES YOU WISH TO TEST.

A WORD OF WARNING HERE: THE NUMBER OF UNITS DEPENDS ON THE TARGET DEVICE OF THE DIAGNOSTIC. FOR EXAMPLE, IF THE DIAGNOSTIC IS DIRECTED AT A DISK DRIVE, THEN THE NUMBER OF UNITS WOULD BE THE NUMBER OF DRIVES TO BE TESTED. WHEREAS IF THE DIAGNOSTIC WAS DIRECTED AT THE DISK CONTROLLER, THEN THE NUMBER OF UNITS WOULD BE THE NUMBER OF CONTROLLERS. THE TARGET DEVICE OF A DIAGNOSTIC CAN ALWAYS BE DETERMINED BY INSPECTING THE "HEADER" STATEMENT NEAR THE BEGINNING OF THE SOURCE CODE. ONE OF THE OPERANDS OF THIS "HEADER" STATEMENT SHOULD BE THE DEVICE TYPE OF THE DIAGNOSTIC.

* STEP 3 *

WHEN YOU HAVE TYPED IN THE NUMBER OF UNITS TO BE TESTED, THE DIAGNOSTIC WILL ASK YOU THE "HARDWARE QUESTIONS". THE ANSWERS TO THESE QUESTIONS ARE USED TO BUILD TABLES IN CORE, CALLED "HARDWARE P-TABLES". ONE HARDWARE P-TABLE WILL BE BUILT FOR EACH UNIT TO BE TESTED.

THERE ARE SEVERAL HARDWARE QUESTIONS AND THE ENTIRE SERIES WILL BE POSED N TIMES, WHERE N IS THE NUMBER OF UNITS.

331 THIS REPRESENTS A NEW PHILOSOPHY IN DIAGNOSTIC ENGINEERING.
332 DIAGNOSTICS IN THE FUTURE WILL NOT BE WRITTEN TO AUTOSIZE OR ASSUME
333 STANDARD ADDRESSES: INSTEAD, THEY WILL ASK THE OPERATOR FOR ALL
334 THE INFORMATION THEY NEED TO TEST THE DEVICE.
335
336

337 *****
338 * STEP 4 *
339 *****
340

341 AFTER YOU HAVE ANSWERED ALL THE HARDWARE QUESTIONS (SEC 2.5) FOR
342 ALL THE UNITS, YOU WILL BE ASKED "CHANGE SW?" IF YOU WANT TO BE
343 ASKED THE SOFTWARE QUESTIONS THAT DETERMINE THE BEHAVIOR OF THIS
344 PROGRAM, TYPE "Y". IF YOU WANT TO TAKE ALL THE DEFAULTS TO THESE
345 QUESTIONS, TYPE "N". IF YOU TYPE "Y" YOU WILL BE ASKED THE
346 SOFTWARE QUESTIONS (SEC 2.6), AND THE ANSWERS WILL BE PUT INTO THE
347 SOFTWARE P-TABLE IN THE PROGRAM. THE SERIES OF QUESTIONS WILL BE
348 ASKED JUST ONCE, REGARDLESS OF THE NUMBER OF UNITS TO BE TESTED.
349

350 *****
351 * STEP 5 *
352 *****
353

354 AFTER YOU HAVE ANSWERED THE SOFTWARE QUESTIONS, THE DIAGNOSTIC WILL
355 BEGIN TO EXECUTE THE HARDWARE TEST CODE. THERE ARE SEVERAL THINGS
356 THAT CAN HAPPEN NEXT, DEPENDING ON WHETHER A HARDWARE ERROR IS
357 ENCOUNTERED AND ALSO ON WHAT SWITCH VALUES YOU SELECTED ON THE
358 START COMMAND. CONSIDER THE POSSIBILITIES:
359

- 360 1. IF NO ERROR IS ENCOUNTERED, THEN THE DIAGNOSTIC WILL SIMPLY
361 EXECUTE THE DESIRED NUMBER OF PASSES AND RETURN TO COMMAND
362 MODE (PROMPT DR>).
363
- 364 2. IF AN ERROR IS ENCOUNTERED, THEN ONE OF THREE THINGS
365 HAPPENS, DEPENDING ON THE SETTINGS OF THE HOE AND LOE
366 FLAGS.
367

368 HOE SET: THE ERROR WILL BE REPORTED ON THE CONSOLE AND THE
369 DIAGNOSTIC WILL RETURN TO COMMAND MODE.
370

371 LOE SET: THE DIAGNOSTIC WILL LOOP ENDLESSLY ON THE BLOCK
372 OF CODE THAT DETECTED THE ERROR.
373

374 NEITHER HOE NOR LOE SET: THE ERROR WILL BE REPORTED ON THE
375 CONSOLE AND NORMAL EXECUTION WILL RESUME AS IF NO ERROR HAD
376 OCCURRED.
377
378
379

2.1.2 SAMPLE RUN-THROUGH

LET'S SEE HOW ALL THIS WORKS IN A REAL SITUATION. RECALL THAT WE ENTERED THE COMMAND "STA/PASS:1/FLAGS:HOE". THIS WOULD BE A VERY TYPICAL WAY TO RUN THE DIAGNOSTIC. IF NO ERRORS ARE ENCOUNTERED, THE SINGLE REQUESTED PASS WILL BE EXECUTED AND THE PROMPT WILL BE RE-ISSUED.

IF AN ERROR IS ENCOUNTERED, THE ERROR WILL BE REPORTED AND THE PROMPT WILL BE REISSUED (BECAUSE THE HOE FLAG IS SET). AT THIS POINT THERE ARE FOUR DIFFERENT WAYS YOU CAN GET THE PROGRAM GOING AGAIN:

1. ISSUE ANOTHER "START" COMMAND (THUS GOING THRU ALL OF STEPS 1, 2, 3, 4, AND 5 AGAIN).
2. ISSUE A "RESTART" COMMAND (SAME AS START COMMAND EXCEPT THAT THE HARDWARE QUESTIONS ARE NOT ASKED).
3. ISSUE A "CONTINUE" COMMAND (EXECUTION WILL RESUME AT THE BEGINNING OF THE PARTICULAR HARDWARE TEST (MOST DIAGNOSTICS CONSIST OF A NUMBER OF THESE) THAT IT WAS IN WHEN THE ERROR HALT OCCURRED. NO QUESTIONS ASKED).
4. ISSUE A "PROCEED" COMMAND: EXECUTION WILL RESUME AT THE INSTRUCTION FOLLOWING THE ERROR REPORT (THIS IS A SPECIAL COMMAND AND CAN BE ISSUED ONLY AT A HALT ON ERROR).

THE MOST TYPICAL THING TO DO HERE IS TO ISSUE THE PROCEED, BUT WITH DIFFERENT FLAG SETTINGS. PROBABLY YOU WOULD WANT TO SAY:

PRO/FLAGS:IER:LOE:HOE=0

THIS WILL DO THE FOLLOWING:

1. TURN ON THE IER (INHIBIT ERROR PRINTOUT) FLAG
2. TURN ON THE LOE FLAG
3. TURN OFF THE HOE FLAG
4. RESUME EXECUTION AT INSTRUCTION AFTER ERROR REPORT

THE DIAGNOSTIC WILL NOW LOOP ON THE BLOCK OF CODE THAT DETECTED AND REPORTED THE ERROR, BUT NO ERROR PRINTOUT WILL OCCUR. THUS YOU CAN STUDY THE ERROR OR SCOPE IT OR WHATEVER.

381
382
383
384
385
386
387
388
389
390
391
392
393
394
395
396
397
398
399
400
401
402
403
404
405
406
407
408
409
410
411
412
413
414
415
416
417
418
419
420
421
422
423
424
425
426
427
428
429
430
431

433
434
435
436
437
438
439
440
441
442
443
444
445
446
447
448
449
450
451
452
453
454
455
456
457
458
459
460
461
462
463
464
465
466

WHEN YOU'VE SEEN ENOUGH, YOU MAY HIT CONTROL/C. THIS WILL TAKE YOU OUT OF THE LOOP AND PUT YOU BACK INTO COMMAND MODE. YOU NOW HAVE THREE CHOICES:

1. START
2. RESTART
3. CONTINUE

LET'S SAY YOU'VE REPAIRED THE DEFECT FOUND ABOVE AND WANT TO FINISH RUNNING THE DIAGNOSTIC. YOU WOULD TYPE

CON/FLAGS:HOE:IER=0:LOE=0

THIS WILL RESTORE THE FLAGS TO THEIR ORIGINAL VALUES AND RESUME EXECUTION AT THE BEGINNING OF THE HARDWARE TEST YOU WERE IN. IF THE ERROR DOES NOT RECUR, THE EXECUTION WILL FLOW RIGHT ON THRU TO THE NEXT ERROR OR TO END OF PASS.

IF AT END OF PASS YOU WANT TO RUN THE DIAGNOSTIC AGAIN, YOU HAVE TWO CHOICES:

1. START
2. RESTART

YOU WOULD CHOOSE ONE, DEPENDING ON WHETHER YOU WANTED TO ANSWER THE HARDWARE QUESTIONS AGAIN.

468
469
470
471
472
473
474
475
476
477
478
479
480
481
482
483
484
485
486
487
488
489
490
491
492
493
494
495
496
497
498
499
500
501
502
503
504
505
506
507
508
509
510
511
512
513
514
515
516
517
518
519
520

THE FULL PRINT-OUT FROM THE ABOVE DIALOGUE MIGHT LOOK LIKE THIS
(O=OPERATOR, D=DIAGNOSTIC):

	BY WHOM ENTERED: -----
.R NRLHAO	O
DRS LOADED	D
DIAG. RUN-TIME SERVICES REV. D APR-79	D
CNRLH-A-0	D
CNRLH TESTS WRITE DATA, READ DATA, AND WRITE CHECK OPERATIONS	D
UNIT IS RL01, RL02	D
DR>STA/PASS:1/FLAGS:HOE	D.O
CHANGE HW (L) ? Y	D.O
# UNITS (D) ? 2	D.O
UNIT 0	D
BUS ADDRESS (O) 174400 ?	D.O
VECTOR (O) 160 ?	D.O
DRIVE TYPE = RL01 (L) Y ?	D.O
BR LEVEL (O) 5 ?	D.O
DRIVE (O) 0 ?	D.O
UNIT 1	D
RL11 (L) Y ?	D.O
BUS ADDRESS (O) 174400 ?	D.O
VECTOR (O) 160 ?	D.O
DRIVE TYPE = RL01 (L) ? N	D.O (N=RL02)
BR LEVEL (O) 5 ?	D.O
DRIVE (O) 0 ?	D.O
DROP ON ERROR LIMIT (L) N ?	
COMPARE DATA ON DCK (L) N ?	
CNRLH HRD ERR 00004 TST 003 SUB 002 PC:004130 ERR HLT	
DR>PRO/FLAGS:IER:LOE:HOE=0	D.O

 AT THIS POINT THE DIAGNOSTIC IS LOOPING ON THE
 ERROR WITHOUT PRINTING ANYTHING. YOU CAN SCOPE
 THE ERROR UNTIL YOU HAVE LOCATED IT, THEN ↑C OUT

522
523
524
525
526
527
528
529
530
531
532
533
534
535
536
537
538
539
540
541
542
543
544
545
546
547
548
549
550
551
552
553
554
555
556
557
558
559
560
561
562
563
564
565
566
567
568
569
570
571
572
573
574
575
576
577

```

†C                                0
DR>CON/FLAGS:HOE:IER:LOE=0      D,0
CHANGE SW (L) ? N                D,0
CNRLH EOP 1                       D
†C
DR>RESTART/PASS:1                D,0
CHANGE SW (L) ? N                D,0
-----
-----
-----

```

2.2 CHAIN MODE OPERATION

CHAIN MODE OPERATION CONSISTS OF THE SEQUENTIAL EXECUTION OF PROGRAMS WITHOUT OPERATOR INTERVENTION. ONLY PROGRAMS THAT HAVE BEEN MODIFIED TO RUN IN CHAIN MODE CAN BE CHAINED. CHAINABLE PROGRAMS ARE IDENTIFIED IN THE DIRECTORY BY A BIC EXTENSION.

TO RUN CHAIN MODE, THE CNDP+ MONITOR USES AN ASCII FILE (KNOWN AS A CHAIN FILE) LISTING THE PROGRAMS TO BE RUN AND THE NUMBER OF PASSES EACH PROGRAM SHOULD RUN. THIS FILE MUST BE ON THE SYSTEM DEVICE.

A CHAIN FILE MAY BE GENERATED BY USE OF THE XTECO TEXT EDITOR. THIS FILE MUST HAVE A CCC EXTENSION. THE CHAIN FILE MAY CONTAIN ANY OF THE COMMANDS SUPPORTED BY THE CNDP+ MONITOR. THE COMMANDS IN THE ASCII FILE ARE EXECUTED IN THE ORDER IN WHICH THEY ARE ENCOUNTERED.

TO EXECUTE A CHAIN FILE THE USER TYPES:

```

C FILNAM <CR> OR
C FILNAM/QV <CR>

```

IN THE FIRST CASE THE PASS COUNT SPECIFIED IN THE CHAIN FILE IS USED BY THE CNDP+ MONITOR TO DETERMINE THE NUMBER OF PASSES TO EXECUTE EACH PROGRAM. IN THE SECOND CASE THE PASS COUNT IS NOT USED AND EACH PROGRAM IS EXECUTED ONLY ONCE. THE /QV SWITCH PROVIDES A SINGLE EXECUTION MODE OF OPERATION OF QUICK VERIFY.

WHEN PROGRAMS ARE RUN IN CHAIN MODE, THE SOFTWARE SWITCH REGISTER SHOULD BE SET TO 00000. THE CNDP+ MONITOR PRINTS EACH COMMAND TAKEN FROM THE CHAIN FILE AND THEN EXECUTES THE COMMAND. WHEN THE LAST COMMAND OTHER THAN ANOTHER C COMMAND HAS BEEN EXECUTED THE CNDP+ MONITOR TERMINATES CHAIN MODE AND TYPES A PROMPT (.). IT IS READY TO ACCEPT ANOTHER COMMAND FROM THE CONSOLE. IF THE LAST COMMAND IS ANOTHER C COMMAND, THE CHAIN MODE WILL CONTINUE AND THE CHAIN FILE SPECIFIED BY THIS NEW C COMMAND WILL BE USED.

579
580
581
582
583
584
585
586
587
588
589
590
591
592
593
594
595
596
597
598
599
600
601
602
603
604
605
606
607
608
609
610
611
612
613
614
615
616
617
618
619
620
621
622
623
624
625
626
627
628
629
630
631
632

IF THE USER WISHES TO TERMINATE CHAIN MODE BEFORE ITS NORMAL TERMINATION HE MAY DO SO BY TYPING A CONTROL/C. HOWEVER, THE MONITOR WILL NOT ABORT THE CHAIN MODE UNTIL IT RECEIVES PROGRAM CONTROL FROM THE PROGRAM CURRENTLY RUNNING.

2.3 DETAILS OF COMMANDS AND SYNTAX

2.3.1 TABLE OF COMMAND VALIDITY

THERE ARE FOUR WAYS OF ENTERING DIAGNOSTIC COMMAND MODE, AND DIFFERENT SUBSETS OF THE DIAG COMMAND SET ARE AVAILABLE WITH EACH:

HOW ENTERED	LEGAL COMMANDS
-----	-----
1. OPERATOR ENTERED 'RUN DIAG'	START PRINT DISPLAY FLAGS ZFLAGS EXIT
2. DIAGNOSTIC HAS FINISHED ALL ITS REQUESTED PASSES	START RESTART PRINT DISPLAY FLAGS ZFLAGS EXIT
3. OPERATOR INTERRUPTED THE DIAGNOSTIC WITH CTRL/C	START RESTART CONTINUE PRINT DISPLAY FLAGS ZFLAGS EXIT
4. AN ERROR WAS ENCOUNTERED WITH THE HOE FLAG SET SET	START RESTART CONTINUE PROCEED PRINT DISPLAY FLAGS ZFLAGS EXIT

634
635
636
637
638
639
640
641
642
643
644
645
646
647
648
649
650
651
652
653
654
655
656
657
658
659
660
661
662
663
664
665
666
667
668
669
670
671
672
673
674
675
676
677
678
679
680
681
682
683
684
685

2.3.2 COMMAND SYNTAX

STA(RT)/TESTS:TEST-LIST/PASS:PASS-CNT/FLAGS:FLAG-LIST/EOP:EOP-INCR

THE DIAGNOSTIC IN CORE IS EXECUTED IN ACCORDANCE WITH THE SWITCHES SPECIFIED. THE MESSAGE "0 UNITS?" IS PRINTED. THE START COMMAND MAY BE ISSUED WHEN DIAGNOSTIC COMMAND MODE HAS BEEN ENTERED VIA ONE OF THE FOLLOWING: A) OPERATOR TYPED "RUN DIAGNOSTIC" B) DIAGNOSTIC FINISHED EXECUTING C) ERROR WAS ENCOUNTERED WITH MOE FLAG SET D) OPERATOR ENTERED CONTROL/C. AFTER THE OPERATOR RESPONDS TO "0 UNITS?", THE HARDWARE DIALOGUE IS INITIATED. WHEN IT IS COMPLETED, THE QUESTIONS "CHANGE SW?" IS ISSUED, AND THE ANSWERS, IF GIVEN, BECOME THE NEW DEFAULTS. THEREFORE IT IS NECESSARY TO RELOAD THE PROGRAM IN ORDER TO RETURN TO THE LOAD DEFAULTS.

THE SWITCH ARGUMENTS ARE AS FOLLOWS:

"TEST-LIST" IS A SEQUENCE OF DECIMAL NUMBERS (1:2 ETC.) OR RANGES OF DECIMAL NUMBERS (1-5:8-10 ETC.) THAT SPECIFY THE TESTS TO BE EXECUTED. THE NUMBERS ARE SEPARATED BY COLONS. THE NUMBERS RANGE FROM 1 TO THE LARGEST TEST NUMBER IN THE DIAGNOSTIC. THEY MAY BE SPECIFIED IN ANY ORDER. TESTS WILL BE EXECUTED IN NUMERICAL ORDER REGARDLESS OF THE ORDER OF SPECIFICATION. THE DEFAULT IS TO EXECUTE ALL TESTS.

"PASS-CNT" IS A DECIMAL NUMBER INDICATING THE DESIRED NUMBER OF PASSES. A PASS IS DEFINED AS THE EXECUTION OF THE FULL DIAGNOSTIC (ALL SELECTED TESTS) AGAINST ALL UNITS SUBMITTED. THE DEFAULT IS NON-ENDING TEST EXECUTION. "FLAG-LIST" IS A SEQUENCE OF ELEMENTS OF THE FORM <FLAG>, <FLAG=1>, OR <FLAG=0>, SEPARATED BY COLONS, WHERE <FLAG> HAS ONE OF THE FOLLOWING VALUES:

MOE HALT ON ERROR, CAUSING COMMAND MODE TO BE ENTERED WHEN AN ERROR IS ENCOUNTERED

LOE LOOP ON ERROR, CAUSING THE DIAGNOSTIC TO LOOP CONTINUOUSLY WITHIN THE SMALLEST DEFINED BLOCK OF CODING (SEGMENT, SUBTEST, OR TEST) CONTAINING THE ERROR

IER INHIBIT ERROR REPORTING

IBE INHIBIT BASIC ERROR REPORTS

IXE INHIBIT EXTENDED ERROR REPORTS

PRI DIRECT ALL MESSAGES TO A LINE PRINTER

PNT PRINT NUMBER OF TEST BEING EXECUTED

687
688
689
690
691
692
693
694
695
696
697
698
699
700
701
702
703
704
705
706
707
708
709
710
711
712
713
714
715
716
717
718
719
720
721
722
723
724
725
726
727
728
729
730
731
732
733
734
735
736
737
738

BOE BELL ON ERROR
UAM RUN IN UNATTENDED MODE, BYPASSING MANUAL INTERVENTION TESTS
ISR INHIBIT STATISTICAL REPORTS
IDU INHIBIT DROPPING OF UNITS BY DIAGNOSTIC
ADR EXECUTE AUTODROP CODE
LOT LOOP ON TEST
EVL EVALUATE

THE FLAGS NAMED OR EQUATED TO 1 ARE SET, THOSE EQUATED TO 0 ARE CLEARED. A FLAG NOT SPECIFIED IS CLEARED. IF THE FLAGS SWITCH IS NOT GIVEN ALL FLAGS ARE CLEARED.

"EOP-INCR" IS A DECIMAL NUMBER INDICATING HOW OFTEN (IN TERMS OF PASSES) IT IS DESIRED THAT THE END OF PASS MESSAGE BE PRINTED. THE DEFAULT IS AT THE END OF EVERY PASS.

RES(TART)/TEST:TEST-LIST/PASS:PASS-CNT/FLAGS:FLAG-LIST/EOP:EOP-INCR/UNITS:UNIT-LIST

THE DIAGNOSTIC IN CORE IS EXECUTED IN ACCORDANCE WITH THE SWITCHES SPECIFIED. HOWEVER, NEW "P-TABLES" ARE NOT BUILT. INSTEAD, THE ONES IN CORE ARE USED.

THE QUESTION "CHANGE SW?" IS ASKED AND THE ANSWERS GIVEN BECOME THE NEW DEFAULTS. THE COMMAND MAY BE ISSUED WHEN COMAND MODE HAS BEEN ENTERED VIA A) DIAGNOSTIC IS FINISHED B) HALT ON ERROR C) CONTROL/C.

THE SWITCH ARGUMENTS ARE AS IN THE START COMMAND EXCEPT:

1. "UNIT-LIST" IS A SEQUENCE OF LOGICAL UNIT NUMBERS RANGING FROM 1 THRU N (N = NUMBER OF UNITS BEING TESTED) SPECIFYING WHICH UNITS ARE TO BE TESTED. THE LOGICAL UNIT NUMBER DESIGNATES THE POSITION OF THE P-TABLE IN CORE, ACCORDING TO THE ORDER IN WHICH THEY WERE BUILT. THE UNITS SPECIFIED MUST NOT HAVE BEEN DROPPED BY THE OPERATOR DROP COMMAND. THE UNIT-LIST DEFAULTS TO "ALL THAT HAVE NOT BEEN DROPPED BY OPERATOR COMMAND". THE EFFECT OF THE UNIT-LIST LASTS UNTIL THE NEXT START (WHERE IT IS AUTOMATICALLY RESET TO "ALL") OR THE NEXT RESTART.
2. ALL UNSPECIFIED FLAG SETTINGS ARE UNCHANGED.

740
741
742
743
744
745
746
747
748
749
750
751
752
753
754
755
756
757
758
759
760
761
762
763
764
765
766
767
768
769
770
771
772
773
774
775
776
777
778
779
780
781
782
783
784
785
786
787
788
789
790

CON(TINUE)/PASS:<PASS-CNT/FLAGS:<FLAG-LIST>

COMMAND MODE MUST HAVE BEEN ENTERED DUE TO A HALT ON ERROR OR A CONTROL/C. THE EFFECT OF THE COMMAND IS TO GO TO THE BEGINNING OF THE TEST THAT WAS BEING EXECUTED WHEN THE HALT OR CONTROL/C TOOK PLACE. SOFTWARE DIALOGUE MAY OPTIONALLY BE RE-EXECUTED. HARDWARE PARAMETERS MAY NOT BE CHANGED.

THE SWITCH ARGUMENTS ARE AS IN THE START COMMAND EXCEPT:

- 1. DEFAULT FOR PASS-CNT IS THE UNSATISFIED PASS-CNT FROM THE PREVIOUS START OR RESTART
- 2. UNSPECIFIED FLAG SETTINGS ARE UNCHANGED

PRO(CCEED)/FLAGS:<FLAC 'IST>

COMMAND MODE MUST HAVE BEEN ENTERED VIA A HALT ON ERROR. THE EFFECT OF THE COMMAND IS TO BEGIN EXECUTION AT THE LOCATION FOLLOWING THE ERROR CALL. NEITHER HARDWARE NOR SOFTWARE PARAMETERS MAY BE ALTERED.

THE SWITCH ARGUMENTS ARE THE SAME AS THE START COMMAND EXCEPT:

- 1. UNSPECIFIED FLAG SETTINGS ARE UNCHANGED

EXIT

RETURN TO CNDP. PROMPT MODE.

DRO(P)/UNITS:UNIT-LIST

THE UNITS SPECIFIED ARE DROPPED FROM TESTING UNTIL THEY ARE ADDED BACK OR UNTIL A START COMMAND IS GIVEN. A DROP CANNOT BE FOLLOWED BY A PROCEED.

THERE IS ALSO A "DROP" MACRO INTERNAL TO THE DIAGNOSTIC, WHICH GIVES THE FACILITY OF AUTO-DROPPING. THE DURATION OF A PROGRAM DROP, HOWEVER, IS ONLY UNTIL THE NEXT START OR RESTART.

792
793
794
795
796
797
798
799
800
801
802
803
804
805
806
807
808
809
810
811
812
813
814
815
816
817
818
819
820
821
822
823
824
825
826
827
828
829
830
831
832
833
834
835
836
837
838
839
840
841
842
843

ADD/UNITS:UNIT-LIST

THE UNITS SPECIFIED ARE ADDED BACK (THEY MUST HAVE BEEN PREVIOUSLY DROPPED BY THE DROP COMMAND) TO THE TEST SEQUENCE. AN ADD CANNOT BE FOLLOWED BY A PROCEED.

PRI(NT)

ALL STATISTICS TABLES ACCUMULATED BY THE DIAGNOSTIC ARE PRINTED. THE ISR (INHIBIT STATISTICAL REPORTING) FLAG IS CLEARED.

DIS(PLAY)/UNITS:<UNIT-LIST>

THE HARDWARE P-TABLES FOR ALL UNITS UNDER TEST ARE PRINTED OUT IN THE FORMAT IN WHICH THEY WERE ENTERED. ANY UNITS THAT WERE DROPPED BY THE OPERATOR "DROP" COMMAND ARE SO DESIGNATED.

FLA(GS)

THE CURRENT SETTINGS OF ALL FLAGS ARE PRINTED.

ZFL(AGS)

ALL FLAGS ARE CLEARED.

2.4 EXTENDED P-TABLE DIALOGUE

THE FULL CAPABILITY OF THE HARDWARE DIALOGUE IS REVEALED BY THE FOLLOWING DISCUSSION OF WHAT HAPPENS INTERNALLY.

AS SOON AS THE QUESTION "N UNITS?" IS ANSWERED (WITH THE NUMBER N), SPACE IN CORE IS ALLOCATED FOR "N" P-TABLES. ALL OF THE P-TABLES ARE OF THE SAME FORMAT, AND THERE IS A ONE-TO-ONE CORRESPONDENCE BETWEEN THE HARDWARE PARAMETER QUESTIONS AND THE SLOTS IN THE P-TABLE FORMAT.

845
846
847
848
849
850
851
852
853
854
855
856
857
858
859
860
861
862
863
864
865
866
867
868
869
870
871
872
873
874
875
876
877
878
879
880
881
882
883
884
885
886
887
888
889
890
891
892
893
894
895
896
897
898

IN GIVING A STRING OF VALUES, COMMAS WITHOUT INTERVENING VALUES MAY BE USED TO INDICATE A REPETITION OF THE LAST NAMED VALUE.

A STRING OF VALUES MAY BE GIVEN AS A RANGE (6-10 FOR EXAMPLE). IF THE VALUES REPRESENT PURE NUMERICAL DATA, THIS SAMPLE RANGE TRANSLATES TO THE STRING 6,7,8,9,10 (AN INCREMENT OF 1). IF THE VALUES ARE ADDRESSES, THE SAMPLE RANGE TRANSLATES TO THE STRING 6,8,10 (AN INCREMENT OF 2).

NOW LET US SEE HOW WE COULD USE THESE CAPABILITIES TO CONSTRUCT A SET OF P-TABLES. ASSUME THAT WE HAVE 8 RL UNITS, AND THAT THERE ARE FIVE (5) HARDWARE PARAMETERS FOR EACH (5 SLOTS IN THE P-TABLE, 5 HARDWARE QUESTIONS IN THE DIALOGUE).

FOLLOWING IS THE DIALOGUE FOR THIS 8 RLOX DRIVE SYSTEM. THIS SYSTEM HAS TWO (2) RL11 TYPE CONTROLLERS ALL TO BE SET AT "BR LEVEL" 5. THE FIRST 4 DRIVES ARE RLO1'S AND THE LAST 4 DRIVES ARE RLO2'S (ON THE SECOND CONTROLLER):

UNITS (0) ? 8

UNIT 0
RL11 (L) Y ?
BUS ADDRESS (0) 174400 ?
VECTOR (0) 160 ?
DRIVE TYPE = RLO1 (L) Y ?
BR LEVEL (0) 5 ?
DRIVE (0) 0 ? 0-3

UNIT 4
RL11 (L) Y ?
BUS ADDRESS (0) 174400 ? 175400
VECTOR (0) 160 ? 164
DRIVE TYPE = RLO1 (L) Y ? N
BR LEVEL (0) 5 ?
DRIVE (0) 0 ? 0-3

THE FIRST TIME THRU THE P-TABLE QUESTIONS THE DEFAULT VALUES ARE USED FOR THE CONTROLLER TYPE (QUESTION #1), CSR ADDRESS OF THE CONTROLLER (QUESTION #2), THE CONTROLLER VECTOR ASSIGNMENT (QUESTION #3), THE DRIVE TYPE (QUESTION #4), AND THE "BR LEVEL" (QUESTION #5). THE ACTUAL UNIT NUMBERS OF THE RLO1'S FOR QUESTION #6 WERE ASSIGNED 0 THRU 3 FOR THE FIRST 4 P-TABLE SLOTS.

THE SECOND TIME THRU THE P-TABLE QUESTIONS (FOR THE RLO2 ASSIGNMENT ON THE SECOND CONTROLLER), THE FIRST QUESTION DEFAULTED TO "RL11" TYPE CONTROLLER. THE SECOND QUESTION WAS ANSWERED TO REFLECT THE CHANGE IN CSR ADDRESS FOR THE RLO2 CONTROLLER (175400). THE SECOND CONTROLLER'S VECTOR WAS ALSO CHANGED TO 164 IN QUESTION #3. THE RLO2 TEST UNIT NUMBERS WERE ASSIGNED VALUES 0 TO 3 IN QUESTION #4 AND THE DRIVE TYPE WAS SET FOR RLO2'S FOR THE REMAINING 4 UNITS IN QUESTION #4. QUESTION #5 WAS DEFAULTED USING THE "BR LEVEL" FROM THE FIRST PASS.

900
901
902
903
904
905
906
907
908
909
910
911
912
913
914
915
916
917
918
919
920
921
922
923
924
925
926
927
928
929
930
931
932
933
934
935
936
937
938
939
940
941
942
943
944
945
946
947
948
949
950
951

2.5 **HARDWARE PARAMETERS**

THE FOLLOWING QUESTIONS WILL BE ASKED ON A START COMMAND. THE VALUE LOCATED TO THE LEFT OF THE QUESTION MARK IS THE DEFAULT VALUE THAT WILL BE TAKEN ON A CARRIAGE RETURN RESPONSE.

RL11 (L) Y?

ANSWER YES(Y) IF YOU HAVE AN RL11 CONTROLLER, NO(N) IF YOU HAVE AN RLV11 CONTROLLER.

BUS ADDRESS (0) 174400?

ANSWER WITH THE BUS ADDRESS OF THE CONTROLLER.

VECTOR (0) 160?

ANSWER WITH THE INTERRUPT VECTOR OF THE CONTROLLER.

DRIVE TYPE = RL01 (L) ?

ANSWER NO (N) IF DRIVE IS AN RL02

BR LEVEL (0) 5?

ANSWER WITH THE INTERRUPT PRIORITY OF THE CONTROLLER.

DRIVE (0) 0?

ANSWER WITH THE DRIVE(S) CONNECTED TO THE CONTROLLER.

2.6 **SOFTWARE PARAMETERS**

THE FOLLOWING QUESTIONS ARE ASKED IF REQUESTED ON A START, RESTART, OR CONTINUE. THEY ALLOW FLEXIBILITY IN THE WAY THE PROGRAM BEHAVES. THE SOFTWARE PARAMETERS GIVE THE PROGRAM FLEXIBILITY IN THE WAY IT RUNS. THE PARAMETERS CAN BE MODIFIED ON A START, RESTART, OR CONTINUE BY ANSWERING (Y)ES TO THE FOLLOWING QUESTION:

"CHANGE S.W. ?"

A YES ANSWER WILL ASK THE FOLLOWING SOFTWARE PARAMETER QUESTIONS, WITH THE PRESENT DEFAULT VALUE PRINTED TO THE LEFT OF THE QUESTION MARK. (THE LAST ANSWER GIVEN IS THE DEFAULT) THE DEFAULT IS TAKEN ON A <CR>. CONTROL Z (^Z) WILL DEFAULT ALL REMAINING QUESTIONS AND START THE TEST.

"DROP ON ERROR LIMIT (L) Y?"

953
954
955
956
957
958
959
960
961
962
963
964
965
966
967
968
969
970
971
972
973
974
975
976
977
978
979
980
981
982
983
984
985
986
987
988
989
990
991
992
993
994
995
996
997
998
999
1000
1001
1002
1003
1004
1005
1006
1007

TO ALLOW THE UNIT TO BE DROPPED ONCE A PREDETERMINED NUMBER OF ERRORS ARE ENCOUNTERED.

ANSWER Y OR N

"ERROR LIMIT (D) 10?"

NUMBER OF ERRORS ALLOWED BEFORE DROPPING UNIT.

ANSWER 1 TO 65K

"COMPARE DATA ON DCK (L) N?"

WHEN A DATA CHECK IS ENCOUNTERED AND DATA IS KNOWN, ALLOW AN INCORE COMPARISON OF DATA.

ANSWER Y OR N

"# OF WORDS IN ERROR REPORTED (D) 3? "

NUMBER OF MISCOMPARES TO BE PRINTED ON CONSOLE DEVICE.

ANSWER 0 - 128

3.0 ERROR INFORMATION

ALL ERROR INFORMATION IS PRINTED ON THE CONSOLE DEVICE. ERROR REPORTS ARE AIMED AT BEING SELF EXPLANATORY. THE GENERAL FORMAT IS:

CNRLH XXX ERR YYYY TST ZZZ SUB PPP PC: RRRRRR

WHERE:

XXX IS SFT - SOFT ERROR
 HRD - HARD ERROR
 DV FAT - DEVICE FATAL ERROR
 SYS FAT - SYSTEM FATAL ERROR
 YYYY IS THE ERROR NUMBER
 ZZZ IS THE TEST NUMBER
 PPP IS THE SUBTEST NUMBER
 RRRRRR IS THE PROGRAM LISTING LOCATION

ERRORS GIVE THE REGISTER CONTENTS BEFORE AND AFTER THE ERROR ALONG WITH A ONE LINE DESCRIPTION AND RELEVANT DATA.

EXAMPLE:

ONE LINE DESCRIPTION
 (OPTIONAL SECOND LINE)
 (OPTIONAL THIRD LINE)
 BEFORE COMMAND: CS:XXXXXX BA:XXXXXX DA:XXXXXX MP:XXXXXX
 TIME OF ERROR: CS:XXXXXX BA:XXXXXX DA:XXXXXX MP:XXXXXX XXXXXX XXXXXX

1009
1010
1011
1012
1013
1014
1015
1016
1017
1018
1019
1020
1021
1022
1023
1024
1025
1026
1027
1028
1029
1030
1031
1032
1033
1034
1035
1036
1037
1038
1039
1040
1041
1042
1043
1044
1045
1046
1047
1048
1049
1050
1051
1052
1053
1054
1055
1056
1057
1058
1059
1060
1061
1062
1063

3.1 ERROR HALTS

ERROR HALTS ARE SUPPORTED PER DESCRIBED IN THE PREVIOUS SECTION WITH /FLAG:MOE. THERE ARE NO OTHER HALTS.

4.0 PERFORMANCE AND PROGRESS REPORTS

4.1 PERFORMANCE REPORTS

THIS PROGRAM WILL NOT GIVE ANY PERFORMANCE REPORTS.

4.2 PROGRESS REPORTS

THIS PROGRAM WILL NOT GIVE ANY PROGRESS REPORTS.

5.0 DEVICE INFORMATION TABLES

THE RL11/RLV11 CONTROLLER HAS THE FOLLOWING FOUR(4) REGISTERS FOR CONTROL OF THE SUBSYSTEM.

RLCS - CONTROL AND STATUS REGISTER (XXXXX0)

- BIT 15 - COMPOSITE ERROR
- BIT 14 - DRIVE ERROR
- BIT 13 - NON EXISTANT MEMORY ERROR
- BIT 12 - HEADER NOT FOUND (WITH BIT 10 SET)
- DATA LATE (WITH BIT 10 CLEAR)
- BIT 11 - HEADER CRC (WITH BIT 10 SET)
- DATA CRC (WITH BIT 10 CLEAR)
- BIT 10 - OPERATION INCOMPLETE
- BIT 9/8 - DRIVE SELECT (0-3)
- BIT 7 - CONTROLLER READY
- BIT 6 - INTERRUPT ENABLE
- BIT 5 - EXTENDED BUS ADDRESS (BIT 17)
- BIT 4 - EXTENDED BUS ADDRESS (BIT 16)
- BIT 3-1 - FUNCTION CODE
 - 0 - NOP (PDP-11) MAINT (LSI-11)
 - 1 - WRITE CHECK
 - 2 - GET DRIVE STATUS
 - 3 - SEEK
 - 4 - READ HEADER
 - 5 - WRITE DATA
 - 6 - READ DATA
 - 7 - READ WITHOUT HEADER COMPARE

1065
1066
1067
1068
1069
1070
1071
1072
1073
1074
1075
1076
1077
1078
1079
1080
1081
1082
1083
1084
1085
1086
1087
1088
1089
1090
1091
1092
1093
1094
1095
1096
1097
1098
1099
1100
1101
1102
1103
1104
1105
1106
1107
1108
1109
1110
1111
1112
1113
1114
1115
1116
1117

BIT 0 - DRIVE READY

RLBA - BUS ADDRESS REGISTER (XXXXX2)

BITS 15-1 BUS ADDRESS OF DATA TRANSFER
BIT 0 SHOULD BE 0

RLDA - DISK ADDRESS REGISTER (XXXXX4)

FOR READ/WRITE FUNCTIONS

BIT 15-7 - CYLINDER ADDRESS FOR TRANSFER
BIT 6 - SURFACE FOR TRANSFER
BIT 5-0 - SECTOR FOR TRANSFER (1-40.)

FOR SEEK FUNCTION

BIT 15-7 - DIFFERENCE TO NEW CYLINDER
BIT 6-5 - MUST BE ZERO (0)
BIT 4 - SURFACE (0=UPPER, 1=LOWER)
BIT 3 - MUST BE ZERO (0)
BIT 2 - SEEK DIRECTION(1-IN / 0-OUT)
BIT 1 - MUST BE ZERO (0)
BIT 0 - MUST BE ONE (1)

FOR GET STATUS FUNCTION

BIT 15-4 - IGNORED SHOULD BE ZERO (0)
BIT 3 - DRIVE RESET
BIT 2 - MUST BE ZERO (0)
BIT 1 - MUST BE ONE (1)
BIT 0 - MUST BE ONE (1)

RLMP - MULTIPURPOSE REGISTER

FOR READ/WRITE FUNCTION

BIT 15 - 0 - WORD COUNT (TWO'S COMPLIMENT)

FOR READ HEADER FUNCTION

BIT 15-0 - DISK HEADER OF SECTOR (FIRST READ)
 - ZERO WORD (SECOND READ)
 - HEADER CRC (THIRD READ)

1119
1120
1121
1122
1123
1124
1125
1126
1127
1128
1129
1130
1131
1132
1133
1134
1135
1136
1137
1138
1139
1140
1141
1142
1143
1144
1145
1146
1147
1148
1149
1150
1151
1152
1153
1154
1155
1156
1157
1158
1159
1160
1161
1162
1163
1164
1165
1166
1167
1168
1169
1170

FOR GET STATUS FUNCTION

HAS DRIVE STATUS

- BIT 15 - WRITE DATA ERROR
- BIT 14 - CURRENT HEAD ERROR (CHE)
- BIT 13 - WRITE LOCK STATUS (WL)
- BIT 12 - SEEK TIME OUT (SKTO)
- BIT 11 - SPIN ERROR (SPE)
- BIT 10 - WRITE GATE ERROR (WGE)
- BIT 9 - VOLUME CHECK (VC)
- BIT 8 - DRIVE SELECT ERROR (DSE)
- BIT 7 - DRIVE TYPE IS RLO2 IF SET
- BIT 6 - SURFACE (0=UPPPER, 1=LOWER)
- BIT 5 - COVER OPEN
- BIT 4 - HEADS HOME
- BIT 3 - BRUSHES HOME
- BIT 2-0 - STATE BITS
 - 0 - LOAD STATE
 - 1 - SPIN UP
 - 2 - BRUSH CYCLE
 - 3 - LOAD HEADS
 - 4 - SEEK - TRACK COUNTING
 - 5 - SEEK - LINEAR MODE
 - 6 - UNLOAD HEADS
 - 7 - SPIN DOWN

6.0 TEST SUMMARIES

TEST 1 - WRITE FUNCTION

THIS TEST WILL VERIFY THAT THE WRITE FUNCTION WILL RESET CONTROLLER READY AND POST NO ERRORS.

TEST 2 - WRITE FUNCTION INTERRUPT

THIS TEST WILL VERIFY THAT THE WRITE FUNCTION WILL GENERATE AN INTERRUPT ON COMPLETION.

TEST 3 - PROPER INCREMENT OF RLBA ON WRITE

THIS TEST WILL VERIFY THAT THE BUS ADDRESS REGISTER INCREMENTS PROPERLY ON A WRITE FUNCTION.

1172
1173
1174
1175
1176
1177
1178
1179
1180
1181
1182
1183
1184
1185
1186
1187
1188
1189
1190
1191
1192
1193
1194
1195
1196
1197
1198
1199
1200
1201
1202
1203
1204
1205
1206
1207
1208
1209
1210
1211
1212
1213
1214
1215
1216
1217
1218
1219
1220
1221
1222
1223
1224
1225
1226
1227
1228

TEST 4 - PROPER INCREMENT OF RLDA ON WRITE

THIS TEST WILL VERIFY THAT THE DISK ADDRESS REGISTER INCREMENTS PROPERLY ON A WRITE FUNCTION.

TEST 5 - FORCE HEADER NOT FOUND WITH WRITE

THIS TEST WILL FORCE A HEADER NOT FOUND ERROR ON A WRITE. THE RLDA IS SET UP TO LOOK FOR SECTOR 40, A WRITE IS THEN ISSUED. THE HEADER NOT FOUND ERROR SHOULD THEN SET.

TEST 6 - FORCE HEADER NOT FOUND WITH WRITE INTERRUPT

THIS TEST WILL FORCE A HEADER NOT FOUND ERROR UNDER INTERRUPT CONTROL. HEADER NOT FOUND IS FORCED BY SETTING SECTOR 40 OF RLDA AND ISSUING A WRITE.

TEST 7 - CHECK OPI TIME WITH HNF

(THIS TEST HAS BEEN REMOVED FROM CNRLHA). -- JSD REV A

THIS TEST WILL TIME THE SETTING OF HNF (OPI) FROM ISSUANCE. THIS IS DONE BY ISSUING A WRITE TO SECTOR 40. THE TIME OF OPI SHOULD BE AROUND 200 MILLISECONDS.

TEST 8 - MULTIPLE SECTOR TRANSFER ON WRITE

THIS TEST THE ABILITY FOR THE WRITE FUNCTION TO WRITE MORE THAN ONE SECTOR. WE SET UP FOR A TWO SECTOR WRITE.

TEST 9 - CHECK DIRECTION OF WRITE NPR

THIS TEST WILL VERIFY THAT THE NPR DIRECTION OF A WRITE FUNCTION IS FROM MEMORY TO THE CONTROLLER. THIS IS DONE BY WRITING A PATTERN IN MEMORY AND ISSUING A WRITE, THEN CHECKING MEMORY TO VERIFY THAT IT DID NOT GET DISTURBED.

TEST 10 - CHECK FULL INCREMENT OF RLBA

THIS TEST WILL CHECK THAT THE RLBA CAN INCREMENT OF THE FULL 16 BIT RANGE. THIS IS DONE BY ISSUING A ONE WORD WRITE TO CHECK EACH BIT TOGGLE FROM 1-0 AND 0-1. THIS IS DONE FROM 0 TO 17776 REGARDLESS OF MEMORY SIZE.

1230
1231
1232
1233
1234
1235
1236
1237
1238
1239
1240
1241
1242
1243
1244
1245
1246
1247
1248
1249
1250
1251
1252
1253
1254
1255
1256
1257
1258
1259
1260
1261
1262
1263
1264
1265
1266
1267
1268
1269
1270
1271
1272
1273
1274
1275
1276
1277
1278
1279
1280
1281

TEST 11 - BA BIT 16 INCREMENT

THIS TEST WILL CHECK THAT BUS ADDRESS BIT 16 WILL SET WHEN THE RLBA IS 177776. AND THAT THE RLBA GOES TO 0.

TEST 12 - BA BIT 17 INCREMENT

THIS TEST WILL CHECK THAT BUS ADDRESS BIT 17 WILL SET WHEN BIT 16 AND THE RLBA ARE SET. THE RLBA AND BIT 16 ARE CHECKED TO GO TO ZERO.

TEST 14 - READ NPR INTEGRITY

THIS TEST WILL VERIFY THAT THE READ FUNCTION WILL NOT CAUSE A BUS TRAP THEREFORE VERIFYING THE NPR LOGIC BETWEEN THE CONTROLLER AND PROCESSOR.

TEST 13 - READ FUNCTION

THIS TEST WILL VERIFY THAT THE READ FUNCTION WILL RESET CONTROLLER READY AND POST NO ERRORS.

TEST 14 - READ FUNCTION INTERRUPT

THIS TEST WILL VERIFY THAT THE READ FUNCTION WILL GENERATE AN INTERRUPT ON COMPLETION.

TEST 15 - CHECK DIRECTION OF READ NPR

THIS TEST WILL VERIFY THAT THE NPR DIRECTION OF A READ FUNCTION IS FROM CONTROLLER TO THE MEMORY. THIS IS DONE BY WRITING A PATTERN IN MEMORY AND ISSUING A READ, THEN CHECKING MEMORY TO VERIFY THAT IT DID NOT GET DISTURBED.

TEST 16 - PROPER INCREMENT OF RLBA ON READ

THIS TEST WILL VERIFY THAT THE BUS ADDRESS REGISTER INCREMENTS PROPERLY ON A READ FUNCTION.

1283
1284
1285
1286
1287
1288
1289
1290
1291
1292
1293
1294
1295
1296
1297
1298
1299
1300
1301
1302
1303
1304
1305
1306
1307
1308
1309
1310
1311
1312
1313
1314
1315
1316
1317
1318
1319
1320
1321
1322
1323
1324
1325
1326
1327
1328
1329
1330
1331
1332
1333
1334
1335
1336
1337

TEST 17 - PROPER INCREMENT OF RLDA ON READ

THIS TEST WILL VERIFY THAT THE DISK ADDRESS REGISTER INCREMENTS PROPERLY ON A READ FUNCTION.

TEST 18 - FORCE HEADER NOT FOUND WITH READ

THIS TEST WILL FORCE A HEADER NOT FOUND ERROR ON A READ. THE RLDA IS SET UP TO LOOK FOR SECTOR 40. A READ IS THEN ISSUED. THE HEADER NOT FOUND ERROR SHOULD THEN SET.

TEST 19 - FORCE HEADER NOT FOUND WITH READ INTERRUPT

THIS TEST WILL FORCE A HEADER NOT FOUND ERROR UNDER INTERRUPT CONTROL. HEADER NOT FOUND IS FORCED BY SETTING SECTOR 40 OF RLDA AND ISSUING A READ.

TEST 20 - CHECK HEADER COMPARE LOGIC

THIS TEST WILL EXTENSIVELY CHECK THE CYLINDER AND HEAD BITS OF THE HEADER WORD TO COMPARE CORRECTLY. THIS IS DONE BY WALKING AND GROWING 0'S AND 1'S THRU THE PROPER RLDA BITS AND ISSUING READ TO SEE IF ALL BIT POSITIONS CAN COMPARE.

TEST 21 - MULTIPLE SECTOR TRANSFER ON READ

THIS TEST THE ABILITY FOR THE READ FUNCTION TO WRITE MORE THAN ONE SECTOR. WE SET UP FOR A TWO SECTOR READ.

TEST 22 - FORCE HNF AT END OF TRACK

THIS TEST WILL CHECK THE ABILITY TO DETECT HEADER NOT FOUND AT THE END OF A TRACK. THIS DONE BY SETTING UP FOR A TWO SECTOR READ AT SECTOR 39.

TEST 23 - FORCE NON-EXISTENT MEMORY ERROR

THIS TEST WILL CHECK THAT THE NON-EXISTANT MEMORY ERROR (NXM) CAN SET. WE WILL ISSUE A READ TO THE MAXIMUM ADDRESS AND EXPECT A NXM ERROR. (THIS TEST WILL NOT BE DONE ON A 128K MACHINE.)

1339
1340
1341
1342
1343
1344
1345
1346
1347
1348
1349
1350
1351
1352
1353
1354
1355
1356
1357
1358
1359
1360
1361
1362
1363
1364
1365
1366
1367
1368
1369
1370
1371
1372
1373
1374
1375
1376
1377
1378
1379
1380
1381
1382
1383
1384
1385
1386
1387
1388
1389
1390
1391
1392
1393
1394

TEST 24 - FORCE NXM UNDER INTERRUPT

THIS TEST WILL ATTEMPT TO FORCE AN INTERRUPT VIA NXM. (THIS TEST WILL NOT BE DONE ON A 128K MACHINE.)

TEST 25 - CHECK READ WRITE LOOP

THIS TEST WILL WRITE A PATTERN TO SECTOR 0 AND TRY TO RECOVER IT WITH A WRITE.

TEST 26 - CHECK OF SILO LINES

THIS TEST WILL CHECK THAT WE CAN WRITE AND READ UNIQUE BIT PATTERNS VERIFY THAT THE LINES ON THE SILO ARE NOT STUCK OR TIED TOGETHER. THIS IS DONE WITH WALKING AND GROWING 0'S AND 1'S.

TEST 27 - CHECK THROUGHPUT OF SILO

THIS TEST WILL ATTEMPT TO CHECK THAT THE FALL THROUGH OF THE SILO IS WORKING CORRECTLY. WE WRITE A SECTOR OF 128 UNIQUE PATTERNS AND READ IT BACK CHECKING THAT EACH LOCATION IS UNIQUE AND CORRECT.

TEST 28 - CHECK ZERO FILL ON WRITE

THIS TEST WILL CHECK THE ABILITY OF THE CONTROLLER TO FILL THE REMAINING SECTOR WITH ZEROS ON A WRITE. WE WRITE A SECTOR WITH FROM 1 TO 127 WORDS, READ IT BACK AND VERIFY THAT THE NON WRITTEN WORDS ARE ZERO.

TEST 29 - CHECK SECTOR BITS ON HEADER COMPARE

THIS TEST WILL CHECK THAT THE SECTOR BITS CAN COMPARE CORRECTLY. THIS IS DONE BY WRITING THE SECTORS ADDRESS INTO THE SECTOR FOR A FULL TRACK. EACH SECTOR IS READ TO VERIFY THE SECTOR HAS THE CORRECT DATA, IF NOT THEN THE SECTOR BITS ARE NOT COMPARING CORRECTLY.

TEST 30 - WRITE CHECK NPR INTEGRITY

THIS TEST WILL CHECK THAT THE WRITE CHECK WILL FUNCTION WITHOUT CAUSING A BUS TRAP. TEST IS SET UP TO HANDLE BUS TRAPS.

1396
1397
1398
1399
1400
1401
1402
1403
1404
1405
1406
1407
1408
1409
1410
1411
1412
1413
1414
1415
1416
1417
1418
1419
1420
1421
1422
1423
1424
1425
1426
1427
1428
1429
1430
1431
1432
1433
1434
1435
1436
1437
1438
1439
1440
1441
1442
1443
1444

TEST 31 - WRITE CHECK FUNCTION

THIS TEST WILL CHECK THAT A WRITE CHECK FUNCTION WILL COMPLETE WITH THE SPECIFIED TIME WITHOUT POSTING ERRORS.

TEST 32 - WRITE CHECK FUNCTION INTERRUPT

THIS TEST WILL CHECK THAT AN INTERRUPT CAN BE GENERATED FROM ISSUING A WRITE CHECK.

TEST 33 - PROPER INCREMENT OF RLBA ON WRITE CHECK

THIS TEST WILL CHECK THAT THE RLBA INCREMENTS PROPERLY DURING A WRITE CHECK.

TEST 34 - PROPER INCREMENT OF RLDA ON WRITE CHECK

THIS TEST WILL CHECK THAT THE RLDA INCREMENTS PROPERLY DURING A WRITE CHECK.

TEST 35 - MULTIPLE SECTOR WRITE CHECK

THIS TEST WILL CHECK THAT WE CAN WRITE CHECK MORE THAN ONE SECTOR AT A TIME.

TEST 36 - FORCE DCK WITH WRITE CHECK

THIS TEST WILL CHECK THAT WE CAN DETECT A DCK DURING A WRITE CHECK. THIS IS DONE BY MODIFYING MEMORY BETWEEN A WRITE AND A WRITE CHECK.

TEST 37 - FORCE DCK WITH WRITE CHECK INTERRUPT

THIS TEST WILL CHECK THAT A DCK DURING A WRITE CHECK WILL CAUSE AN INTERRUPT TO OCCUR.

1446
1447
1448
1449
1450
1451
1452
1453
1454
1455
1456
1457
1458
1459
1460
1461
1462
1463
1464
1465
1466
1467
1468
1469
1470
1471
1472
1473
1474
1475
1476
1477
1478
1479
1480
1481
1482
1483
1484
1485
1486
1487
1488
1489
1490
1491
1492
1493
1494
1495
1496
1497

TEST 38 - CHECK ZERO FILL ON WRITE WITH WRITE CHECK

THIS TEST WILL VERIFY THAT WE CAN SUCCESSFULLY WRITE CHECK ALL WORD COUNTS FROM 1 - 127.

TEST 39 - EXTENDED CHECK OF WRITE CHECK

THIS TEST WILL VERIFY THAT WE CAN WRITE CHECK SUCCESSFULLY ALL PATTERNS. PATTERNS USED ARE WALKING 1'S, 0'S, GROWING 1'S, 0'S.

TEST 40 - READ WITHOUT HEADER COMPARE

THIS TEST VERIFIES THAT THE FUNCTION READ WITHOUT HEADER COMPARE (7) RESETS THE CONTROLLER READY AND POSTS NO ERRORS. THE DISK ADDRESS IS SET TO ALL ONES.

TEST 41 - READ WITHOUT HEADER COMPARE INTERRUPT

THIS TEST WILL VERIFY THAT THE FUNCTION READ WITHOUT HEADER COMPARE (7) CAN GENERATE AN INTERRUPT ON COMPLETION.

TEST 42 - CHECK RD W/O HDR CMP READS

THIS TEST CHECKS THAT THE FUNCTION CAN ACTUALLY RECOVER DATA. WE WRITE A PATTERN IN MEMORY AND CHECK THAT THE FUNCTION CAN OVERLAY IT WITH DATA.

TEST 43 - CHECK RLBA INCREMENT WITH RD W/O HDR CMP

THIS TEST CHECKS THAT THE RLBA CAN INCREMENT PROPERLY ON THE FUNCTION.

TEST 44 - CHECK RLDA DOES INCREMENT

THIS TEST CHECKS THAT THE RLDA DOES INCREMENT WITH THE FUNCTION READ WITHOUT HEADER COMPARE.

8

```

1499          .ENABLE AMA
1500 000000   .ENABLE ABS
1501          .MCALL SVC
1502          002000   .-2000
1503
1504          .SBTTL  MACRO DEFINITIONS
1505
1506          .MACRO  CKERFG
1507                  TST      ERFLG          ;ERROR IN HEADS HOME ROUTINE
1508                  BEQ      123$          ;NO, THEN CONTINUE
1509                  EXIT     TST           ;YES, EXIT TEST
1510          123$:   ;CONTINUE WITH TEST
1511          .ENDM
1512
1513          .MACRO  WAITUS  ARG          ;MACRO MICRO-SEC WAIT
1514                  MOV     ARG,XDELAY    ;SAVE ARGUMENT
1515                  JSR     PC,TIME       ;CALL TIMING ROUTINE
1516          .ENDM
1517
1518          .MACRO  WAITMS  ARG          ;MACRO MILLISEC WAIT
1519                  MOV     ARG,YDELAY    ;SAVE ARGUMENT
1520                  JSR     PC,XTIME     ;CALL TIMING ROUTINE
1521          .ENDM
1522
1523          .NLIST  CND,MD,ME
1524
1525          002000   SVC
1526          000000   SVCINS=0
1527          000000   SVCTAG=0
1528
1529          002000   POINTER BGNSW,BGNSFT,BGNDU
1530
1531          002000   BGNMOD MDHEDR
1532
1533          002000   HEADER  CNRLH,A,0,60,0,PRI06          ;JSD REV A - ADDED PRI06
1534          002000   103    .ASCII /C/
1535          002001   116    .ASCII /N/
1536          002002   122    .ASCII /R/
1537          002003   114    .ASCII /L/
1538          002004   110    .ASCII /H/
1539          002005   000    .BYTE  0
1540          002006   000    .BYTE  0
1541          002007   000    .BYTE  0
1542          002010   101    .ASCII /A/
1543          002011   060    .ASCII /O/
1544          002012   000000 .WORD  0
1545          002014   000060 .WORD  60
1546          002016   033562 .WORD  L#HARD
1547          002020   033736 .WORD  L#SOFT
1548          002022   012416 .WORD  L#HW
1549          002024   012434 .WORD  L#SW
1550          002026   034130 .WORD  L#LAST
1551          002030   000000 .WORD  0
1552          002032   000000 .WORD  0
1553          002034   000000 .WORD  0
1554          002036   000000 .WORD  0
1555          002040   012450 .WORD  L#DISPATCH

```

MACRO DEFINITIONS

002042	000300	.WORD	PRI06
002044	000000	.WORD	0
002046	000000	.WORD	0
002050	003	.BYTE	C#REVISION
002051	003	.BYTE	C#EDIT
002052	000000	.WORD	0
002054	000000	.WORD	0
002056	000000	.WORD	0
002060	002220	.WORD	L#DVTYP
002062	000000	.WORD	0
002064	000000	.WORD	0
002066	000000	.WORD	0
002070	000000	.WORD	0
002072	013610	.WORD	L#DU
002074	000000	.WORD	0
002076	002122	.WORD	L#DESC
002100	104035	EMT	E#LOAD
002102	000000	.WORD	0
002104	012600	.WORD	L#INIT
002106	013514	.WORD	L#CLEAN
002110	013326	.WORD	L#AUTO
002112	012406	.WORD	L#PROT
002114	000000	.WORD	0
002116	000000	.WORD	0
002120	000000	.WORD	0

1534
1535
1536
1537

002122 ENDMOD

DESCRPT <CNRLH TESTS WRITE DATA, READ DATA, AND WRITE CHECK OPERATIONS>
.ASCIZ /CNRLH TESTS WRITE DATA, READ DATA, AND WRITE CHECK OPERATIONS/

002122	103	116	122
002125	114	110	040
002130	124	105	123
002133	124	123	040
002136	127	122	111
002141	124	105	040
002144	104	101	124
002147	101	054	040
002152	122	105	101
002155	104	040	104
002160	101	124	101
002163	054	040	101
002166	116	104	040
002171	127	122	111
002174	124	105	040
002177	103	110	105
002202	103	113	040
002205	117	120	105
002210	122	101	124
002213	111	117	116
002216	123	000	

.EVEN

1538
1539

002220	122	114	060	DEV TYP	<RL01,RL02>
002223	061	054	122	.ASCIZ	#RL01,RL02#
002226	114	060	062		
002231	000				

MACRO DEFINITIONS

```

      .EVEN
1540
1541      .SBTTL GLOBAL EQUATES
1542
1543      BGNMOD GLBEQAT
1544      EQUALS

;
; BIT DIFINITIONS
;
100000      BIT15== 100000
040000      BIT14== 40000
020000      BIT13== 20000
010000      BIT12== 10000
004000      BIT11== 4000
002000      BIT10== 2000
001000      BIT09== 1000
000400      BIT08== 400
000200      BIT07== 200
000100      BIT06== 100
000040      BIT05== 40
000020      BIT04== 20
000010      BIT03== 10
000004      BIT02== 4
000002      BIT01== 2
000001      BIT00== 1

;
001000      BIT9== BIT09
000400      BIT8== BIT08
000200      BIT7== BIT07
000100      BIT6== BIT06
000040      BIT5== BIT05
000020      BIT4== BIT04
000010      BIT3== BIT03
000004      BIT2== BIT02
000002      BIT1== BIT01
000001      BIT0== BIT00

;
; EVENT FLAG DEFINITIONS
; EF32:EF17 RESERVED FOR SUPERVISOR TO PROGRAM COMMUNICATION
;
;
; BIT POSITION IN SECOND STATUS WORD
000040      EF.START== 32. ; (100000) START COMMAND WAS ISSUED
000037      EF.RESTART== 31. ; (040000) RESTART COMMAND WAS ISSUED
000036      EF.CONTINUE== 30. ; (020000) CONTINUE COMMAND WAS ISSUED
000035      EF.NEW== 29. ; (010000) A NEW PASS HAS BEEN STARTED
000034      EF.PWR== 28. ; (004000) A POWER-FAIL/POWER-UP OCCURRED

;
; PRIORITY LEVEL DEFINITIONS
;
000340      PRI07== 340
000300      PRI06== 300
000240      PRI05== 240
000200      PRI04== 200
000140      PRI03== 140
000100      PRI02== 100
000040      PRI01== 40

```

GLOBAL EQUATES

```

000000          PRI00== 0
                ;
                ;OPERATOR FLAG BITS
                ;
000004          EVL==      4
000010          LOT==     10
000020          ADR==     20
000040          IDU==     40
000100          ISR==    100
000200          UAM==    200
000400          BOE==    400
001000          PNT==   1000
002000          PRI==   2000
004000          IXE==   4000
010000          IBE==  10000
020000          IER==  20000
040000          LOE==  40000
100000          HOE== 100000
1545          000001      DRDY=BIT0          ;DRIVE READY (RLCS)
1546          000100      INTEN=BIT6         ;INTERRUPT ENABLE (RLCS)
1547          100000      ERR=BIT15          ;RL11 ERROR (RLCS)
1548          040000      DERR=BIT14         ;RL01 DRIVE ERROR (RLCS)
1549          002000      OPI=BIT10          ;OPERATION INCOMPLETE (RLCS)
1550          000200      CRDY=BIT7          ;CONTROLLER READY (RLCS)
1551          000040      BA17=BIT5          ;EXTENDED ADDRESS BIT 17 (RLCS)
1552          000020      BA16=BIT4          ;EXTENDED ADDRESS BIT 16 (RLCS)
1553          020000      NOM=BIT13         ;NON-EXISTANT MEMORY (RLCS)
1554          000000      DS0=0              ;DRIVE SELECT 0 (RLCS)
1555          000400      DS1=BIT8           ;DRIVE SELECT 1 (RLCS)
1556          001000      DS2=BIT9           ;DRIVE SELECT 2 (RLCS)
1557          001400      DS3=BIT8!BIT9      ;DRIVE SELECT 3 (RLCS)
1558          000000      NOOP0=0            ;FUNCTION-NOOP(0)
1559          000002      WRCHK=BIT1         ;WRITE CHECK FUNCTION
1560          000004      GSTAT=BIT2         ;GET STATUS FUNCTION
1561          000006      SEEK=BIT2!BIT1     ;SEEK FUNCTION
1562          000010      RDHDR=BIT3         ;READ HEADER FUNCTION
1563          000012      WRITE=BIT3!BIT1    ;WRITE DATA FUNCTION
1564          000014      READ=BIT3!BIT2     ;READ DATA FUNCTION
1565          000016      RDND=BIT3!BIT2!BIT1 ;READ W/O HEADER VERIFICATION
1566          000202      GODRVR=BIT1!BIT7   ;CRDY AND DRDY
1567          000010      DRST=BIT3         ;DRIVE RESET (RLDA)
1568          000002      GSBIT=BIT1        ;GET STATUS BIT (RLDA)
1569          000001      MK=BIT0           ;MARKER BIT (RLDA)
1570          000004      SIGN=BIT2         ;SIGN BIT (RLDA)
1571          000100      RHMS=BIT6         ;HEAD SELECT IN READ HEADER
1572          000100      STHS=BIT6         ;HEAD SELECT IN STATUS BACK
1573          000020      DAHS=BIT4         ;HEAD SELECT IN SEEK
1574
1575          ;OFFSET FOR HARDWARE P-TABLE
1576
1577          000000      CSR=0
1578          000002      VECT=2
1579          000004      PRIOR=4
1580          000006      TYPDR=6
1581          000010      DRBT=10
1582          000012      CNT=12
1583

```

GLOBAL EQUATES

```

1584                ;OFFSET FOR SOFTWARE P-TABLE
1585
1586                DLT=0
1587                ELT=2
1588                SIZE=4
1589                DMPCK=6
1590                DLMT=10
1591                ANS=12
1592
1593 002232          ENDMOD
1594
1595                .SBTTL GLOBAL DATA
1596
1597 002232          BGNMOD GLBDAT
1598
1599 002232 000000   T.DRIVE: .WORD 0
1600 002234 000000   CHECK:  .WORD 0
1601 002236 000000   T.CRC:  .WORD 0
1602 002240 000000   WHY:   .WORD 0
1603 002242 000000   CDCNT: .WORD 0
1604 002244 000004   ERRVEC: .WORD 4
1605 002246 000000   DRIVE: .WORD 0
1606 002250 000000   UUT:   .WORD 0
1607 002252 000000   UNITST: .WORD 0
1608 002254 000000   TRPFLG: .WORD 0
1609 002256 000000   INTFLG: .WORD 0
1610 002260 000000   LDCSR: .WORD 0
1611 002262 000077   SECMSK: .WORD 77
1612 002264 120001   XPOLY: .WORD 120001
1613 002266 000000   BCCFBK: .WORD 0
1614 002270 000000   CALBCC: .WORD 0
1615 002272 000000   TMP0:  .WORD 0
1616 002274 000000   TMP1:  .WORD 0
1617 002276 000000   TMP2:  .WORD 0
1618 002300 000000   GDDAT: .WORD 0
1619 002302 000000   BDDAT: .WORD 0
1620 002304 000000   TEMP2: .WORD 0
1621 002306 000000   TEMP3: .WORD 0
1622 002310 000000   TEMP4: .WORD 0
1623 002312 000000   FIRST: .WORD 0
1624 002314 177700   CYLMSK: .WORD 177700
1625 002316 000050   MXSEC1: .WORD 40.
1626 002320 000047   MAXSEC: .WORD 39.
1627 002322 000000   DWORD: .WORD 0
1628 002324 177600   MAXCYL: .WORD 177600
1629 002326 000000   SVMD:  .WORD 0
1630 002330 000000   B.CS:  .WORD 0
1631 002332 000000   B.BA:  .WORD 0
1632 002334 000000   B.DA:  .WORD 0
1633 002336 000000   B.MP:  .WORD 0
1634 002340 000000   E.CS:  .WORD 0
1635 002342 000000   E.BA:  .WORD 0
1636 002344 000000   E.DA:  .WORD 0
1637 002346 000000   E.MP:  .WORD 0
1638 002350 000000   E.MP1: .WORD 0
1639 002352 000000   E.MP2: .WORD 0
1640 002354 000000   RLCS:  .WORD 0

```

```

; INTERRUPT OCCURANCE FLAG
; LOCATION TO FORM RLCS
; MASK OUT SECTOR
; POLYNOMIAL FOR CRC 16
; LOCATION USED BY "SIMBCC"
; LOCATION USED BY "SIMBCC"

```

```

; LOCATION USED BY "SIMBCC"
; LOCATION USED BY "SIMBCC"
; LOCATION USED BY "SIMBCC"
; FIRST SECTOR READ
; MASK CYLINDER AND HEAD SELECT
; MAX SECTOR ADDRESS +1
; MAX SECTOR ADDRESS
; DIFFERENCE WORD (SEEK)
; MAXIMUM CYLINDER ADDRESS
; SAVE CURRENT HEAD SELECT
; CS - BEFORE OPERATION
; BA - BEFORE OPERATION
; DA - BEFORE OPERATION
; MP - BEFORE OPERATION
; CS - AT OCCURANCE OF ERROR
; BA - AT OCCURANCE OF ERROR
; DA - AT OCCURANCE OF ERROR
; MP - AT OCCURANCE OF ERROR

```


GLOBAL DATA

1641 002356 000000
 1642 002360 000000
 1643 002362 000000
 1644 002364 000000
 1645 002366 000000
 1646 002370 000000
 1647 002372 000000
 1648 002374 000000
 1649 002376 000000
 1650 002400 000000
 1651 002402 001212
 1652 002404 000233
 1653 002406 000620
 1654 002410 000240
 1655 002412 000000
 1656 002414 000000
 1657 002416 000000
 1658 002420 000000
 1659 002422 000000
 1660 002424 000000
 1661 002426 000000
 1662 002626 000000
 1663 002630 000000
 1664 002632 000000
 1665 002634 000000
 1666 002636 000000
 1667 002640 000000
 1668 002642 000000
 1669 002644 000000
 1670 002646 000000
 1671 002650 000000
 1672 002652 000000
 1673 002654 000000
 1674 002656 000000
 1675 002660 000000
 1676 002662 000000
 1677 002664 000000
 1678 002666 000000
 1679
 1680
 1681
 1682 002670 000000
 1683 002672 000001
 1684 002674 000002
 1685 002676 000004
 1686 002700 000010
 1687 002702 000020
 1688 002704 000040
 1689 002706 000100
 1690 002710 000200
 1691 002712 000400
 1692 002714 001000
 1693 002716 002000
 1694 002720 004000
 1695 002722 010000
 1696 002724 020000
 1697 002726 040000

RLBA: .WORD 0
 RLDA: .WORD 0
 RLMP: .WORD 0
 BCSR: .WORD 0
 BVEC: .WORD 0
 BPRIOR: .WORD 0
 FNDFNC: .WORD 0
 XMEM: .WORD 0
 TRYFNC: .WORD 0
 ERFLG: .WORD 0
 LOPIX: .WORD 650.
 LOPIH: .WORD 155.
 UOPIX: .WORD 400.
 UOPIH: .WORD 160.
 OPIH: .WORD 0
 OPIX: .WORD 0
 PWRFLG: .WORD 0
 T.CNTRL: .WORD 0
 DERFLG: .WORD 0
 ERPOINT: .WORD 0
 ERCOUNT: .BLKW 64.
 XDELAY: .WORD 0
 YDELAY: .WORD 0
 TEMPO: .WORD 0
 TEMP: .WORD 0
 TIM.US: .WORD 0
 TAG: .WORD 0
 PCLKCS: .WORD 0
 PCSR: .WORD 0
 VEC: .WORD 0
 HZ: .WORD 0
 XITFLG: .WORD 0
 FIFTY: .WORD 0
 SIXTY: .WORD 0
 PCLOCK: .WORD 0
 NOTST: .WORD 0
 OPITIM: .WORD 0
 CLKFLD: .WORD 0

;CSR FROM P-TABLE
 ;VECTOR FROM P-TABLE
 ;BR LEVEL FROM P-TABLE

;CLOCK FIELD USED TO CHECK IF LSI-11 CLOCK
 ;/IS "TICKING"

.SBTTL LIST TO CHECK HEADER COMPARE LOGIC
 HDRTAB: .WORD 0 ;WALK 1
 .WORD BIT0
 .WORD BIT1
 .WORD BIT2
 .WORD BIT3
 .WORD BIT4
 .WORD BIT5
 .WORD BIT6
 .WORD BIT7
 .WORD BIT8
 .WORD BIT9
 .WORD BIT10
 .WORD BIT11
 .WORD BIT12
 .WORD BIT13
 .WORD BIT14

LIST TO CHECK HEADER COMPARE LOGIC

1698	002730	000003	.WORD	3		;GROW 1
1699	002732	000007	.WORD	7		
1700	002734	000017	.WORD	17		
1701	002736	000037	.WORD	37		
1702	002740	000137	.WORD	137		
1703	002742	000337	.WORD	337		
1704	002744	000737	.WORD	737		
1705	002746	001737	.WORD	1737		
1706	002750	003737	.WORD	3737		
1707	002752	007737	.WORD	7737		
1708	002754	017737	.WORD	17737		
1709	002756	037737	.WORD	37737		
1710	002760	077737	.WORD	77737		
1711	002762	077736	.WORD	77736		;GROW 0
1712	002764	077734	.WORD	77734		
1713	002766	077730	.WORD	77730		
1714	002770	077720	.WORD	77720		
1715	002772	077700	.WORD	77700		
1716	002774	077600	.WORD	77600		
1717	002776	077400	.WORD	77400		
1718	003000	077000	.WORD	77000		
1719	003002	076000	.WORD	76000		
1720	003004	074000	.WORD	74000		
1721	003006	070000	.WORD	70000		
1722	003010	060000	.WORD	60000		
1723	003012	040000	.WORD	40000		
1724	003014	077735	.WORD	77735		;WALK 0
1725	003016	077733	.WORD	77733		
1726	003020	077727	.WORD	77727		
1727	003022	077717	.WORD	77717		
1728	003024	077637	.WORD	77637		
1729	003026	077537	.WORD	77537		
1730	003030	077337	.WORD	77337		
1731	003032	076737	.WORD	76737		
1732	003034	075737	.WORD	75737		
1733	003036	073737	.WORD	73737		
1734	003040	067737	.WORD	67737		
1735	003042	057737	.WORD	57737		
1736	003044	037737	.WORD	37737		
1737	003046	000000	.WORD	0		
1738	003050	000000	.WORD	0		;WALK 1
1739	003052	000001	.WORD	BIT0		
1740	003054	000002	.WORD	BIT1		
1741	003056	000004	.WORD	BIT2		
1742	003060	000010	.WORD	BIT3		
1743	003062	000020	.WORD	BIT4		
1744	003064	000040	.WORD	BIT5		
1745	003066	000100	.WORD	BIT6		
1746	003070	000200	.WORD	BIT7		
1747	003072	000400	.WORD	BIT8		
1748	003074	001000	.WORD	BIT9		
1749	003076	002000	.WORD	BIT10		
1750	003100	004000	.WORD	BIT11		
1751	003102	010000	.WORD	BIT12		
1752	003104	020000	.WORD	BIT13		
1753	003106	040000	.WORD	BIT14		
1754	003110	100000	.WORD	BIT15		

HDREND:
HTAB:

LIST TO CHECK HEADER COMPARE LOGIC

1755	003112	000003			.WORD	3		;GROW 1
1756	003114	000007			.WORD	7		
1757	003116	000017			.WORD	17		
1758	003120	000037			.WORD	37		
1759	003122	000137			.WORD	137		
1760	003124	000337			.WORD	337		
1761	003126	000737			.WORD	737		
1762	003130	001737			.WORD	1737		
1763	003132	003737			.WORD	3737		
1764	003134	007737			.WORD	7737		
1765	003136	017737			.WORD	17737		
1766	003140	037737			.WORD	37737		
1767	003142	077737			.WORD	77737		
1768	003144	177737			.WORD	177737		
1769	003146	177736			.WORD	177736		;GROW 0
1770	003150	177734			.WORD	177734		
1771	003152	177730			.WORD	177730		
1772	003154	177720			.WORD	177720		
1773	003156	177700			.WORD	177700		
1774	003160	177600			.WORD	177600		
1775	003162	177400			.WORD	177400		
1776	003164	177000			.WORD	177000		
1777	003166	176000			.WORD	176000		
1778	003170	174000			.WORD	174000		
1779	003172	170000			.WORD	170000		
1780	003174	160000			.WORD	160000		
1781	003176	140000			.WORD	140000		
1782	003200	100000			.WORD	100000		
1783	003202	177735			.WORD	177735		;WALK 0
1784	003204	177733			.WORD	177733		
1785	003206	177727			.WORD	177727		
1786	003210	177717			.WORD	177717		
1787	003212	177637			.WORD	177637		
1788	003214	177537			.WORD	177537		
1789	003216	177337			.WORD	177337		
1790	003220	176737			.WORD	176737		
1791	003222	175737			.WORD	175737		
1792	003224	173737			.WORD	173737		
1793	003226	167737			.WORD	167737		
1794	003230	157737			.WORD	157737		
1795	003232	137737			.WORD	137737		
1796	003234	000000			.WORD	0		
1797								
1798	003236	000001	000002	000004	DATPAT: .WORD	1,2,4,10,20,40,100,200,400,1000,2000,4000,10000,20000,40000,100000		
	003244	000010	000020	000040				
	003252	000100	000200	000400				
	003260	001000	002000	004000				
	003266	010000	020000	040000				
	003274	100000						
1799	003276	177777	177776	177775	.WORD	177777,177776,177775,177773,177767,177757,177737,177677		
	003304	177773	177767	177757				
	003312	177737	177677					
1800	003316	177577	177377	176777	.WORD	177577,177377,176777,175777,173777,167777,157777,137777		
	003324	175777	173777	167777				
	003332	157777	137777					
1801	003336	077777	177774	177770	.WORD	77777,177774,177770,177760,177740,177700,177600,177400		
	003344	177760	177740	177700				

LIST TO CHECK HEADER COMPARE LOGIC

```

1802 003352 177600 177400
      003356 177000 176000 174000 .WORD 177000,176000,174000,170000,160000,140000,3,7,17,37,77
      003364 170000 160000 140000
      003372 000003 000007 000017
      003400 000037 000077
1803 003404 000177 000377 000777 .WORD 177,377,777,1777,3777,7777,17777,37777,0
      003412 001777 003777 007777
      003420 017777 037777 000000

```

```

1804
1805 003426 000400          BUF: 256.          ;BUFFER FOR READ/WRITE
1806

```

```

1807 003430          ENDMOD
1808

```

```

1809          .SBTTL GLOBAL TEXT
1810

```

```

1811 003430          BGNMOD GLBTXT
1815 003430          103      123      072  ARLCS: .ASCIZ /CS: /
1816 003435          040      102      101  ARLBA: .ASCIZ /BA: /
1817 003443          040      104      101  ARLDA: .ASCIZ /DA: /
1818 003451          040      115      120  ARLMP: .ASCIZ /MP: /
1819 003457          102      105      106  BEREG: .ASCIZ /BEFORE COMMAND: /
1820 003500          124      111      115  AFREG: .ASCIZ /TIME OF ERROR: /
1821 003521          103      117      116  CRTIM: .ASCIZ /CONTROLLER TIMED OUT/
1822 003546          104      122      111  DRTIM: .ASCIZ /DRIVE READY TIMED OUT/
1823 003574          040      104      122  DEMES: .ASCIZ /DRV/
1824 003601          040      116      130  NXMES: .ASCIZ /NXM/
1825 003606          040      117      120  OPIMES: .ASCIZ /OPI/
1826 003613          040      110      103  MRCMES: .ASCIZ /MRC/
1827 003621          040      110      116  MNFMES: .ASCIZ /MNF/
1828 003626          040      104      103  DCKMES: .ASCIZ /DCK/
1829 003633          040      104      114  DLTMES: .ASCIZ /DLT/
1830 003640          015      000      LF: .ASCIZ <15>
1831 003642          015      012      000  MSCRLF: .ASCIZ <15><12>
1832 003645          040      103      117  COMP: .ASCIZ /COMP/
1833 003653          106      122      103  OPIERR: .ASCIZ /FRCD OPI C' SED OTHER ERRS/
1834 003705          116      117      117  NOPMES: .ASCIZ /NOOP OPR'TN-FLAG MODE/
1835 003733          116      117      117  NOPINT: .ASCIZ /NOOP OPR'TN-INTR. MODE/
1836 003762          127      122      111  WCKMES: .ASCIZ /WRITE CHCK OPR'TN-FLAG MODE/
1837 004016          127      122      111  WCKINT: .ASCIZ /WRITE CHCK OPR'TN-INTR. MODE/
1838 004053          122      104      040  RDMES: .ASCIZ /RD HDR OPR'TN-FLAG MODE/
1839 004103          122      104      040  RHDINT: .ASCIZ /RD HDR OP-INTR. MODE/
1840 004130          123      113      040  SEKMES: .ASCIZ /SK OP-FLAG MODE/
1841 004150          123      113      040  SEKINT: .ASCIZ /SK OP-INTR. MODE/
1842 004171          107      105      124  GSTMES: .ASCIZ /GET STATUS OP-FLAG MODE/
1843 004221          107      105      124  GSTINT: .ASCIZ /GET STATUS OP-INTR MODE/
1844 004251          122      104      040  RDDMES: .ASCIZ /RD OP-FLAG MODE/
1845 004271          122      104      040  RDDINT: .ASCIZ /RD OP-INTR MODE/
1846 004311          127      122      124  WRTMES: .ASCIZ /WRT OP-FLAG MODE/
1847 004332          127      122      124  WRTINT: .ASCIZ /WRT OP-INTR MODE/
1848 004353          122      104      040  RDNMES: .ASCIZ #RD W/O HDR - FLG MODE#
1849 004401          122      104      040  RDNINT: .ASCIZ #RD W/O HDR - INTR MODE#
1850 004430          103      101      116  SKHOME: .ASCIZ /CAN'T SK TO TRK 0/
1851 004452          127      122      124  WRLOCK: .ASCIZ /WRT LOCK ERR/
1852 004467          122      114      103  EM1: .ASCIZ /RLCS HAD FOLLOWING ERR(S):/
1853 004522          EM100: .BLKB 120.
1854 004712          116      117      040  EM4: .ASCIZ /NO INTRPT ON RD OP/
1855 004735          122      104      040  EM5: .ASCIZ /RD OP DID NOT WRT MEM/

```

GLOBAL TEXT

1856	004763	122	114	102	EM6:	.ASCIZ	/RLBA DID NOT INCR DURING RD/
1857	005017	123	105	103	EM7:	.ASCIZ	/SECTR DID NOT INCR PROPERLY AFTER RD/
1858	005064	110	104	122	EM10:	.ASCIZ	/HDR NOT FND COULD NOT BE FORCED/
1859	005124	127	122	117	EM11:	.ASCIZ	/WRONG CYL ON SK/
1860	005144	110	104	122	EM12:	.ASCIZ	/HDR NOT FND WOULD NOT SET/
1861	005176	104	122	126	EM13:	.ASCIZ	/DRV RDY WOULD NOT SET/
1862	005224	104	123	113	EM14:	.ASCIZ	/DSK ADDR INCORRECT AFTER MULTIPLE SCTR READ/
1863	005300	104	122	126	EM16:	.ASCIZ	/DRV ERR ON WRT OP/
1864	005322	116	117	040	EM17:	.ASCIZ	/NO INTRPT ON WRT OP/
1865	005346	122	114	102	EM20:	.ASCIZ	/RLBA DID NOT INCR PROPERLY DURING WRT/
1866	005414	123	103	124	EM21:	.ASCIZ	/SCTR DID NOT INCR PROPERLY AFTER WRT/
1867	005461	104	123	113	EM22:	.ASCIZ	/DSK ADDR (RLDA) INCORRECT AFT MUL'PLE SCTR WRT/
1868	005540	110	104	122	EM23:	.ASCIZ	/HDR NOT FND COULD NOT BE FORCED AT END OF TRK/
1869	005616	116	130	115	EM24:	.ASCIZ	/NXM MEM ERR COULD NOT BE FORCED/
1870	005656	104	101	124	EM25:	.ASCIZ	#DATA CMP ERR - RD/WRT ERR#
1871	005710	127	122	124	EM26:	.ASCIZ	/WRT OP MODIFIED MEM/
1872	005734	105	122	122	EM27:	.ASCIZ	/ERR ON PARTIAL SCTR WRT - ZERO FILL CHCK/
1873	006005	122	114	102	EM30:	.ASCIZ	/RLBA DID NOT INCR PROPERLY/
1874	006040	102	101	040	EM31:	.ASCIZ	/BA BIT 16 DID NOT SET ON INCR/
1875	006076	102	101	040	EM32:	.ASCIZ	/BA BIT 17 SET ON BA16 INCR TST/
1876	006135	122	114	102	EM33:	.ASCIZ	/RLBA DID NOT INCR WITH BA16/
1877	006171	102	101	040	EM34:	.ASCIZ	/BA BIT 17 DID NOT SET ON INCR/
1878	006227	102	101	040	EM35:	.ASCIZ	/BA BIT 16 DID NOT CLR ON INCR/
1879	006265	122	114	102	EM36:	.ASCIZ	/RLBA DID NOT INCR WITH BA17/
1880	006321	122	105	101	EM40:	.ASCIZ	/READ(FUNCTION 7) DID NOT INTRPT/
1881	006361	122	104	050	EM41:	.ASCIZ	/RD(FUNCTION 7) ERR - BAD DATA/
1882	006417	122	104	040	EM42:	.ASCIZ	/RD (FUNCTION 7) ERR AT END OF TRK/
1883	006461	116	117	040	EM43:	.ASCIZ	/NO INTRPT WITH HDR NT FND FORCED/
1884	006522	116	117	040	EM44:	.ASCIZ	/NO INTRPT WITH NXM FORCED/
1885	006554	105	122	122	EM45:	.ASCIZ	#ERR ON BIT BANG OF SILO#
1886	006604	123	111	114	EM47:	.ASCIZ	/SILO OP FAIL/
1887	006621	110	104	122	EM50:	.ASCIZ	/HDR CMP FAILURE - SECTOR/
1888	006652	122	104	040	EM55:	.ASCIZ	?RD W/O HDR CMP OP DID NOT WRT MEMORY?
1889	006717	122	114	102	EM53:	.ASCIZ	?RLBA D'NT INCR DURING RD W/O HDR CMP?
1890	006764	122	114	104	EM54:	.ASCIZ	?RLDA DID NOT INCR AFTER RD W/O HDR CMP?
1891	007033	117	120	111	EM56:	.ASCIZ	/OPI TIMING ERR/
1892	007052	127	122	124	EM57:	.ASCIZ	/WRT CHCK NPR CAUSED BUS TRAP/
1893	007107	127	122	124	EM60:	.ASCIZ	/WRT CHCK DID NOT INTRPT/
1894	007137	122	114	102	EM61:	.ASCIZ	/RLBA DID NOT INCR PROPERLY DURING WRCHK/
1895	007207	122	114	104	EM62:	.ASCIZ	/RLDA DID NOT INCR DURING WRCHK/
1896	007246	122	114	104	EM63:	.ASCIZ	/RLDA DID NOT INCR AFT A MULT' SCTR WRT CHK/
1897	007321	127	122	124	EM64:	.ASCIZ	/WRT CHECK OF PARTIAL SCTR WRT FAIL/
1898	007364	103	101	116	EM65:	.ASCIZ	/CANNOT FORCE DCK ON WRT CHCK/
1899	007421	103	101	116	EM66:	.ASCIZ	/CANNOT FORCE INTERRUPT WITH DCK ON WRCHK/
1900	007472	127	122	124	EM70:	.ASCIZ	/WRT CHCK FAIL/
1901							
1902					.EVEN		
1903							
1907							
1908	007510				ENDMOD		
1909							
1910	007510				BGNMOD	GLBERR	
1911							
1912					.SBTTL	GLOBAL ERRORS	
1913	007510				BGNMSG	ERRO	
1914							
1915	007510	004737	010522		JSR	PC,LINE1	

GLOBAL ERRORS

1916	007514	004737	010556	JSR	PC,LINE2	
1917						
1918	007520	004537	014526	JSR	R5,CKERLT	;INCREMENT ERROR AND CHECK LIMIT
1919						
1920	007524			ENDMSG		
	007524			L10000:		
	007524	104423		TRAP	C#MSG	
1921						
1922	007526			BGNMSG	ERR1	
1923						
1924	007526	004737	010522	JSR	PC,LINE1	
1925						
1926	007532	004537	014526	JSR	R5,CKERLT	;INCREMENT ERROR AND CHECK LIMIT
1927						
1928	007536			ENDMSG		
	007536			L10001:		
	007536	104423		TRAP	C#MSG	
1929						
1930	007540			BGNMSG	ERR2	
1931						
1932	007540	004737	010522	JSR	PC,LINE1	
1933	007544			PRINTB	#FRMT4,GDDAT,BDDAT	
	007544	013746	002302	MOV	BDDAT,-(SP)	
	007550	013746	002300	MOV	GDDAT,-(SP)	
	007554	012746	011170	MOV	#FRMT4,-(SP)	
	007560	012746	000003	MOV	#3,-(SP)	
	007564	010600		MOV	SP,R0	
	007566	104414		TRAP	C#PNTB	
	007570	062706	000010	ADD	#10,SP	
1934						
1935	007574	004537	014526	JSR	R5,CKERLT	;INCREMENT ERROR AND CHECK LIMIT
1936						
1937	007600			ENDMSG		
	007600			L10002:		
	007600	104423		TRAP	C#MSG	
1938						
1939	007602			BGNMSG	ERR3	
1940						
1941	007602	004737	010522	JSR	PC,LINE1	
1942	007606	004737	010556	JSR	PC,LINE2	
1943	007612			PRINTB	#FRMT5,TMPO,BDDAT,GDDAT	
	007612	013746	002300	MOV	GDDAT,-(SP)	
	007616	013746	002302	MOV	BDDAT,-(SP)	
	007622	013746	002272	MOV	TMPO,-(SP)	
	007626	012746	011226	MOV	#FRMT5,-(SP)	
	007632	012746	000004	MOV	#4,-(SP)	
	007636	010600		MOV	SP,R0	
	007640	104414		TRAP	C#PNTB	
	007642	062706	000012	ADD	#12,SP	
1944						
1945	007646	004537	014526	JSR	R5,CKERLT	;INCREMENT ERROR AND CHECK LIMIT
1946						
1947	007652			ENDMSG		
	007652			L10003:		
	007652	104423		TRAP	C#MSG	
1948						
1949	007654			BGNMSG	ERR4	

GLOBAL ERRORS

1950						
1951	007654	004737	010522	JSR	PC,LINE1	
1952	007660	004737	010556	JSR	PC,LINE2	
1953	007664			PRINTB	#FRMT4,GDDAT,BDDAT	
	007664	013746	002302	MOV	BDDAT,-(SP)	
	007670	013746	002300	MOV	GDDAT,-(SP)	
	007674	012746	011170	MOV	#FRMT4,-(SP)	
	007700	012746	000003	MOV	#3,-(SP)	
	007704	010600		MOV	SP,R0	
	007706	104414		TRAP	C#PNTB	
	007710	062706	000010	ADD	#10,SP	
1954						
1955	007714	004537	014526	JSR	R5,CKERLT	;INCREMENT ERROR AND CHECK LIMIT
1956						
1957	007720			ENDMSG		
	007720			L10004:		
	007720	104423		TRAP	C#MSG	
1958						
1959	007722			BGNMSG	ERR5	
1960						
1961	007722	004737	010522	JSR	PC,LINE1	
1962	007726			PRINTB	#FRMT3,RESTMS	
	007726	013746	015036	MOV	RESTMS,-(SP)	
	007732	012746	011163	MOV	#FRMT3,-(SP)	
	007736	012746	000002	MOV	#2,-(SP)	
	007742	010600		MOV	SP,R0	
	007744	104414		TRAP	C#PNTB	
	007746	062706	000006	ADD	#6,SP	
1963						
1964	007752	004537	014526	JSR	R5,CKERLT	;INCREMENT ERROR AND CHECK LIMIT
1965						
1966	007756			ENDMSG		
	007756			L10005:		
	007756	104423		TRAP	C#MSG	
1967						
1968	007760			BGNMSG	ERR6	
1969						
1970	007760	004737	010522	JSR	PC,LINE1	
1971	007764	004737	011000	JSR	PC,LINE3	
1972	007770	004737	010556	JSR	PC,LINE2	
1973						
1974	007774			PRINTB	#FRMT99	
	007774	012746	012106	MOV	#FRMT99,-(SP)	
	010000	012746	000001	MOV	#1,-(SP)	
	010004	010600		MOV	SP,R0	
	010006	104414		TRAP	C#PNTB	
	010010	062706	000004	ADD	#4,SP	
1975	010014	004537	014526	JSR	R5,CKERLT	;INCREMENT ERROR AND CHECK LIMIT
1976						
1977	010020			ENDMSG		
	010020			L10006:		
	010020	104423		TRAP	C#MSG	
1978						
1979	010022			BGNMSG	ERR7	
1980						
1981	010022	004537	014526	JSR	R5,CKERLT	;INCREMENT ERROR AND CHECK LIMIT
1982						

GLOBAL ERRORS

1983 010026
 010026
 010026 104423
 1984
 1985 010030
 1986
 1987 010030 004737 010522
 1988 010034 004737 010556
 1989 010040
 010040 013746 002302
 010044 013746 002300
 010050 013746 002274
 010054 012746 011277
 010060 012746 000004
 010064 010600
 010066 104414
 010070 062706 000012
 1990
 1991 010074 004537 014526
 1992
 1993 010100
 010100
 010100 104423
 1994
 1995 010102
 1996
 1997 010102 004737 010522
 1998 010106 004737 010556
 1999 010112
 010112 010246
 010114 013746 002272
 010120 012746 011170
 010124 012746 000003
 010130 010600
 010132 104414
 010134 062706 000010
 2000
 2001 010140 004537 014526
 2002
 2003 010144
 010144
 010144 104423
 2004
 2005 010146
 2006
 2007 010146 004737 010522
 2008 010152 004737 010556
 2009 010156
 010156 013746 002302
 010162 013746 002300
 010166 013746 002274
 010172 012746 011354
 010176 012746 000004
 010202 010600
 010204 104414
 010206 062706 000012
 2010

ENDMSG
 L10007: TRAP C#MSG
 BGNMSG ERR8
 JSR PC,LINE1
 JSR PC,LINE2
 PRINTB #FRMT6,TMP1,GDDAT,BDDAT
 MOV BDDAT,-(SP)
 MOV GDDAT,-(SP)
 MOV TMP1,-(SP)
 MOV #FRMT6,-(SP)
 MOV #4,-(SP)
 MOV SP,R0
 TRAP C#PNTB
 ADD #12,SP
 JSR R5,CKERLT ;INCREMENT ERROR AND CHECK LIMIT
 ENDMSG
 L10010: TRAP C#MSG
 BGNMSG ERR9
 JSR PC,LINE1
 JSR PC,LINE2
 PRINTB #FRMT4,TMP0,R2
 MOV R2,-(SP)
 MOV TMP0,-(SP)
 MOV #FRMT4,-(SP)
 MOV #3,-(SP)
 MOV SP,R0
 TRAP C#PNTB
 ADD #10,SP
 JSR R5,CKERLT ;INCREMENT ERROR AND CHECK LIMIT
 ENDMSG
 L10011: TRAP C#MSG
 BGNMSG ERR10
 JSR PC,LINE1
 JSR PC,LINE2
 PRINTB #FRMT7,TMP1,GDDAT,BDDAT
 MOV BDDAT,-(SP)
 MOV GDDAT,-(SP)
 MOV TMP1,-(SP)
 MOV #FRMT7,-(SP)
 MOV #4,-(SP)
 MOV SP,R0
 TRAP C#PNTB
 ADD #12,SP

GLOBAL ERRORS

2011	010212	004537	014526		JSR	R5,CKERLT		;INCREMENT ERROR AND CHECK LIMIT
2012								
2013	010216				ENDMSG			
	010216			L10012:				
	010216	104423			TRAP	C#MSG		
2014								
2015	010220			BGNMSG	ERR11			
2016								
2017	010220	004737	010522		JSR	PC,LINE1		
2018	010224	004737	010556		JSR	PC,LINE2		
2019	010230				PRINTB	#FRMT8,TMPO,GDDAT,BDDAT		
	010230	013746	002302		MOV	BDDAT,-(SP)		
	010234	013746	002300		MOV	GDDAT,-(SP)		
	010240	013746	002272		MOV	TMPO,-(SP)		
	010244	012746	011426		MOV	#FRMT8,-(SP)		
	010250	012746	000004		MOV	#4,-(SP)		
	010254	010600			MOV	SP,RO		
	010256	104414			TRAP	C#PNTB		
	010260	062706	000012		ADD	#12,SP		
2020								
2021	010264	004537	014526		JSR	R5,CKERLT		;INCREMENT ERROR AND CHECK LIMIT
2022								
2023	010270				ENDMSG			
	010270			L10013:				
	010270	104423			TRAP	C#MSG		
2024								
2025	010272			BGNMSG	ERR12			
2026								
2027	010272	004737	010522		JSR	PC,LINE1		
2028	010276	004737	010556		JSR	PC,LINE2		
2029	010302				PRINTB	#FRMT9,TMP1,R3,GDDAT,BDDAT		
	010302	013746	002302		MOV	BDDAT,-(SP)		
	010306	013746	002300		MOV	GDDAT,-(SP)		
	010312	010346			MOV	R3,-(SP)		
	010314	013746	002274		MOV	TMPO,-(SP)		
	010320	012746	011547		MOV	#FRMT9,-(SP)		
	010324	012746	000005		MOV	#5,-(SP)		
	010330	010600			MOV	SP,RO		
	010332	104414			TRAP	C#PNTB		
	010334	062706	000014		ADD	#14,SP		
2030								
2031	010340	004537	014526		JSR	R5,CKERLT		;INCREMENT ERROR AND CHECK LIMIT
2032								
2033	010344				ENDMSG			
	010344			L10014:				
	010344	104423			TRAP	C#MSG		
2034								
2035	010346			BGNMSG	ERR13			
2036								
2037	010346	004737	010522		JSR	PC,LINE1		
2038	010352				PRINTB	#FRMT10,OPIMN,OPIMX,BDDAT		
	010352	013746	002302		MOV	BDDAT,-(SP)		
	010356	013746	002414		MOV	OPIMX,-(SP)		
	010362	013746	002412		MOV	OPIMN,-(SP)		
	010366	012746	011652		MOV	#FRMT10,-(SP)		
	010372	012746	000004		MOV	#4,-(SP)		
	010376	010600			MOV	SP,RO		

GLOBAL ERRORS

010400	104414			TRAP	C#PNTB	
2039 010402	062706	000012		ADD	#12,SP	
2040 010406	004537	014526		JSR	R5,CKERLT	;INCREMENT ERROR AND CHECK LIMIT
2041						
2042 010412				ENDMSG		
010412			L10015:			
2043 010412	104423			TRAP	C#MSG	
2044 010414			BGNMSG	ERR14		
2045						
2046 010414	004737	010522		JSR	PC,LINE1	
2047 010420	004737	010556		JSR	PC,LINE2	
2048 010424				PRINTB	#FRMT14,TMP1,#BUF	
010424	012746	003426		MOV	#BUF,-(SP)	
010430	013746	002274		MOV	TMP1,-(SP)	
010434	012746	011476		MOV	#FRMT14,-(SP)	
010440	012746	000003		MOV	#3,-(SP)	
010444	010600			MOV	SP,RO	
010446	104414			TRAP	C#PNTB	
2049 010450	062706	000010		ADD	#10,SP	
2050 010454	004537	014526		JSR	R5,CKERLT	;INCREMENT ERROR AND CHECK LIMIT
2051						
2052 010460				ENDMSG		
010460			L10016:			
2053 010460	104423			TRAP	C#MSG	
2054 010462			BGNMSG	ERR15		
2055						
2056 010462	004737	010522		JSR	PC,LINE1	
2057 010466	004737	010556		JSR	PC,LINE2	
2058 010472				PRINTB	#FRMT15,R2	
010472	010246			MOV	R2,-(SP)	
010474	012746	012142		MOV	#FRMT15,-(SP)	
010500	012746	000002		MOV	#2,-(SP)	
010504	010600			MOV	SP,RO	
010506	104414			TRAP	C#PNTB	
010510	062706	000006		ADD	#6,SP	
2059 010514	004537	014526		JSR	R5,CKERLT	
2060						
2061 010520				ENDMSG		
010520			L10017:			
2062 010520	104423			TRAP	C#MSG	
2063 010522			LINE1:	PRINTB	#FRMT1,RLCS,<B,DRIVE+1>	
010522	005046			CLR	-(SP)	
010524	153716	002247		BISB	DRIVE+1,(SP)	
010530	013746	002354		MOV	RLCS,-(SP)	
010534	012746	011052		MOV	#FRMT1,-(SP)	
010540	012746	000003		MOV	#3,-(SP)	
010544	010600			MOV	SP,RO	
010546	104414			TRAP	C#PNTB	
2064 010550	062706	000010		ADD	#10,SP	
2065 010554	000207			RTS	PC	
2066 010556			LINE2:	PRINTB	#FRMT2,#BEREG,#ARLCS,B.CS,#ARLBA,B.BA	

GLOBAL ERRORS

	010556	013746	002332	MOV	B.BA, -(SP)
	010562	012746	003435	MOV	@ARLBA, -(SP)
	010566	013746	002330	MOV	B.CS, -(SP)
	010572	012746	003430	MOV	@ARLCS, -(SP)
	010576	012746	003457	MOV	@BEREG, -(SP)
	010602	012746	011102	MOV	@FRMT2, -(SP)
	010606	012746	000006	MOV	@6, -(SP)
	010612	010600		MOV	SP, R0
	010614	104414		TRAP	C#PNTB
	010616	062706	000016	ADD	@16, SP
2067	010622			PRINTB	@FRMT2A, @ARLDA, B.DA, @ARLMP, B.MP
	010622	013746	002336	MOV	B.MP, -(SP)
	010626	012746	003451	MOV	@ARLMP, -(SP)
	010632	013746	002334	MOV	B.DA, -(SP)
	010636	012746	003443	MOV	@ARLDA, -(SP)
	010642	012746	011121	MOV	@FRMT2A, -(SP)
	010646	012746	000005	MOV	@5, -(SP)
	010652	010600		MOV	SP, R0
	010654	104414		TRAP	C#PNTB
	010656	062706	000014	ADD	@14, SP
2068	010662			PRINTB	@FRMT2, @AFREG, @ARLCS, E.CS, @ARLBA, E.BA
	010662	013746	002342	MOV	E.BA, -(SP)
	010666	012746	003435	MOV	@ARLBA, -(SP)
	010672	013746	002340	MOV	E.CS, -(SP)
	010676	012746	003430	MOV	@ARLCS, -(SP)
	010702	012746	003500	MOV	@AFREG, -(SP)
	010706	012746	011102	MOV	@FRMT2, -(SP)
	010712	012746	000006	MOV	@6, -(SP)
	010716	010600		MOV	SP, R0
	010720	104414		TRAP	C#PNTB
	010722	062706	000016	ADD	@16, SP
2069	010726			PRINTB	@FRMT2B, @ARLDA, E.DA, @ARLMP, E.MP, E.MP1, E.MP2
	010726	013746	002352	MOV	E.MP2, -(SP)
	010732	013746	002350	MOV	E.MP1, -(SP)
	010736	013746	002346	MOV	E.MP, -(SP)
	010742	012746	003451	MOV	@ARLMP, -(SP)
	010746	013746	002344	MOV	E.DA, -(SP)
	010752	012746	003443	MOV	@ARLDA, -(SP)
	010756	012746	011134	MOV	@FRMT2B, -(SP)
	010762	012746	000007	MOV	@7, -(SP)
	010766	010600		MOV	SP, R0
	010770	104414		TRAP	C#PNTB
	010772	062706	000020	ADD	@20, SP
2070	010776	000207		RTS	PC
2071					
2072	011000			LINE3: PRINTB	@FRMT3, @EM1
	011000	012746	004467	MOV	@EM1, -(SP)
	011004	012746	011163	MOV	@FRMT3, -(SP)
	011010	012746	000002	MOV	@2, -(SP)
	011014	010600		MOV	SP, R0
	011016	104414		TRAP	C#PNTB
	011020	062706	000006	ADD	@6, SP
2073	011024			PRINTB	@FRMT3, @EM100
	011024	012746	004522	MOV	@EM100, -(SP)
	011030	012746	011163	MOV	@FRMT3, -(SP)
	011034	012746	000002	MOV	@2, -(SP)
	011040	010600		MOV	SP, R0

GLOBAL ERRORS

```

011042 104414
011044 062706 000006
2074 011050 000207
2075
2079
2080 011052 045 101 103 FRMT1: .ASCIZ /#ACNTRLR: #06#A DRV #01/
2081 011102 045 116 045 FRMT2: .ASCIZ /#N#T#T#06#T#06/
2082 011121 045 124 045 FRMT2A: .ASCIZ /#T#06#T#06/
2083 011134 045 124 045 FRMT2B: .ASCIZ /#T#06#T#06#A #06#A #06/
2084 011163 045 116 045 FRMT3: .ASCIZ /#N#T/
2085 011170 045 116 045 FRMT4: .ASCIZ /#N#AEXP'D: #06#A REC'D: #06#N/
2086 011226 045 116 045 FRMT5: .ASCIZ /#N#ALAST: #06#A PRES: #06#A EXP'D: #06#N/
2087 011277 045 116 045 FRMT6: .ASCIZ /#N#ABUS ADR: #06#A EXP'D: #06#A REC'D: #06#N/
2088 011354 045 116 045 FRMT7: .ASCIZ /#N#AWORD: #03#A EXP'D: #06#A REC'D: #06#N/
2089 011426 045 116 045 FRMT8: .ASCIZ /#N#ADA: #06#A REC'D: #06#A EXP'D: #06#N/
2090 011476 045 116 045 FRMT14: .ASCIZ /#N#AWORDS WRITTEN: #03#A BUS ADDR: #06#N/
2091 011547 045 116 045 FRMT9: .ASCIZ /#N#AWORDS WRITTEN: #03#A BUS ADDR: #06#A EXP'D: #06#A REC'D: #06#N/
2092 011652 045 116 045 FRMT10: .ASCIZ /#N#ARANGE #03#A - #03#A MILLISECONDS WAS #06#N/
2093 011731 045 101 115 .ASCIZ /#AMAX TIMEOUT OF PROGRAM IS 3 SECONDS#N/
2094 012001 045 116 045 FRMT11: .ASCIZ /#N#AERR LIMIT EXCEEDED - DROPPED#N/
2095 012044 045 101 104 FRMT98: .ASCII /#ADRV DID NOT RCVR FROM POWER FAIL/
2096 012106 045 116 000 FRMT99: .ASCIZ /#N/
2097 012111 045 116 045 FRMT13: .ASCIZ /#N#T#A - WILL NOT TEST#N/
2098 012142 045 116 045 FRMT15: .ASCIZ /#N#APATTERN WAS: #06/
2099 012167 045 116 045 FRMT16: .ASCIZ /#N#ADRIE DROPPED - NO CONTROLLER#N/
2100 012233 045 116 045 FRMT17: .ASCIZ /#N#ADRIE DROPPED - DID NOT RESPOND WITH "READY"#N/
2101 012316 045 116 045 FRMT18: .ASCIZ /#N#ATEST 7 CANNOT BE PERFORMED...CLOCK IS NOT AVAILABLE/
2102
2103 .EVEN
2104
2108
2109 012406 ENDMOD
2110
2111 ;LOAD PROTECTION TABLE
2112 012406 BGNPROT
2113 012406 000000 .WORD 0 ;OFFSET OF CSR IN P-TABLE
2114 012410 177777 .WORD -1 ;NOT A MASS-BUS DRIVE
2115 012412 000010 .WORD 10 ;OFFSET OF DRIVE IN P-TABLE
2116 012414 ENDPROT
2117
2118 012414 BGNMOD HPTCODE
2119 012414 BGNHW
2120 012414 000006 .WORD L10021-L#HW/2
2121 012416 174400 .WORD 174400 ;CSR
2122 012420 000160 .WORD 160 ;VECTOR
2123 012422 000240 .WORD 240 ;PRIORITY
2124 012424 000001 .WORD 1 ;TYPE OF DRIVE RL01 OR RL02
2125 012426 000000 .WORD 0 ;DRIVE (BITS 8,9,10)
2126 012430 000001 .WORD 1 ;RL11=1 RLV11=0
2127
2128 012432 ENDMH
012432 L10021:
2129 012432 ENDMOD
2130
2131 012432 BGNMOD SPTCODE
2132 012432 BGNSW

```


GLOBAL ERRORS

2133	012432	000005	.WORD	L10022-L#SW/2
2134	012434	000000	DROP:	.WORD 0
2135	012436	000012	MERLMT:	.WORD 10.
2136	012440	000000	T.DMP:	.WORD 0
2137	012442	000000	T.LMT:	.WORD 0
2138	012444	000001	T.ANS:	.WORD 1
2139				
2140	012446		ENDSW	
	012446		L10022:	
2141	012446		ENDMOD	
2142				
2143	012446		BGNMOD	DSPCODE
2144				
2145	012446		DISPATCH	44
	012446	000054	.WORD	44
	012450	016240	.WORD	T1
	012452	016404	.WORD	T2
	012454	016534	.WORD	T3
	012456	016670	.WORD	T4
	012460	017022	.WORD	T5
	012462	017160	.WORD	T6
	012464	017356	.WORD	T7
	012466	017760	.WORD	T8
	012470	020150	.WORD	T9
	012472	020346	.WORD	T10
	012474	020520	.WORD	T11
	012476	020716	.WORD	T12
	012500	021116	.WORD	T13
	012502	021220	.WORD	T14
	012504	021344	.WORD	T15
	012506	021540	.WORD	T16
	012510	021674	.WORD	T17
	012512	022026	.WORD	T18
	012514	022146	.WORD	T19
	012516	022326	.WORD	T20
	012520	023140	.WORD	T21
	012522	023334	.WORD	T22
	012524	023500	.WORD	T23
	012526	023664	.WORD	T24
	012530	024050	.WORD	T25
	012532	024450	.WORD	T26
	012534	025072	.WORD	T27
	012536	025520	.WORD	T28
	012540	026200	.WORD	T29
	012542	026632	.WORD	T30
	012544	027246	.WORD	T31
	012546	027500	.WORD	T32
	012550	027770	.WORD	T33
	012552	030264	.WORD	T34
	012554	030556	.WORD	T35
	012556	031150	.WORD	T36
	012560	031450	.WORD	T37
	012562	032010	.WORD	T38
	012564	032322	.WORD	T39
	012566	032646	.WORD	T40
	012570	032736	.WORD	T41

GLOBAL ERRORS

	012572	033070			.WORD	T42		
	012574	033266			.WORD	T43		
	012576	033424			.WORD	T44		
2146								
2147	012600				ENDMOD			
2148								
2149					.SBTTL	INITIALIZATION CODE		
2150								
2151	012600				BGNMOD	INITCODE		
2152	012600				BGNINIT			
2153					:			
2154	012600				SETPRI	#PRI07		;JSD REV A
	012600	012700	000300		SETPRI	#PRI06		;JSD REV A
	012604	104441			MOV	#PRI06,RO		
2155	012606				TRAP	C#SPRI		
	012606	012700	000034		READEF	#EF.PWR		
	012612	104447			MOV	#EF.PWR,RO		
2156	012614				TRAP	C#REFG		
	012614	103004			BNCOMPLETE	NO PWR		
2157	012616	013737	002012	002416	BCC	NO PWR		
2158	012624	000510			MOV	L#UNIT,PWRFLG		
2159	012626				BR	CONT		
	012626	012700	000037		NO PWR:	READEF #EF.RESTART		
	012632	104447			MOV	#EF.RESTART,RO		
2160	012634				TRAP	C#REFG		
	012634	103404			BCOMPLETE	START1		
2161	012636				BCS	START1		
	012636	012700	000040		READEF	#EF.START		
	012642	104447			MOV	#EF.START,RO		
2162	012644				TRAP	C#REFG		
	012644	103023			BNCOMPLETE	CONTINUE		
2163	012646				BCC	CONTINUE		
	012646	012746	000340		START1:	SETVEC #140,#170000,#340		;ODT STARTING ADDR ;JSD REV A
	012652	012746	170000		MOV	#340,-(SP)		
	012656	012746	000140		MOV	#170000,-(SP)		
	012662	012746	000003		MOV	#140,-(SP)		
	012666	104437			MOV	#3,-(SP)		
	012670	062706	000010		TRAP	C#SVEC		
2164	012674	012700	002426		ADD	#10,SP		
2165	012700	012701	000100		MOV	#ERCOUNT,RO		
2166	012704	005020			MOV	#64,R1		
2167	012706	005301			10:	CLR (R0)+		
2168	012710	001375			DEC	R1		
2169	012712	000407			BNE	10		
2170	012714				BR	START		
	012714	012700	000036		CONTINUE:	READEF #EF.CONTINUE		
	012720	104447			MOV	#EF.CONTINUE,RO		
2171	012722				TRAP	C#REFG		
	012722	103451			BCOMPLETE	CONT		
2172	012724	005737	002250		NXT:	TST UUT		;DONE WITH ALL UNITS
2173	012730	001011			BNE	XXX		;NO
2174	012732	012737	177777	002252	START:	MOV #-1,UNITST		
2175	012740	013737	002012	002250	MOV	L#UNIT,UUT		
2176	012746	012737	002424	002424	MOV	#ERCOUNT-2,ERPOINT		
2177	012754	005237	002252		XXX:	INC UNITST		
2178	012760	062737	000002	002424	ADD	#2,ERPOINT		
2179	012766	005337	002250		DEC	UUT		

INITIALIZATION CODE

2180	012772				REST:	GPHARD	UNITST,RO	
	012772	013700	002252			MOV	UNITST,RO	
	012776	104442				TRAP	C#GPHRD	
2181	013000					BCOMPLETE	2#	
	013000	103406				BCS	2#	
2182	013002	005737	002416			TST	PWRFLG	
2183	013006	001746				BEQ	NXT	
2184	013010	005337	002416			DEC	PWRFLG	
2185	013014	000743				BR	NXT	
2186	013016	012037	002364		2#:	MOV	(RO)+,BCSR	;GET BUS ADDRESS
2187	013022	012037	002366			MOV	(RO)+,BVEC	;GET VECTOR
2188	013026	012037	002370			MOV	(RO)+,BPRIOR	;GET PRIORITY
2189	013032	012037	002232			MOV	(RO)+,T.DRIVE	;GET TYPE OF DRIVE
2190	013036	012037	002246			MOV	(RO)+,DRIVE	;GET DRIVE
2191	013042	012037	002420			MOV	(RO)+,T.CNTRL	;GET CONTROLLER TYPE
2192	013046	013700	002364		CONT:	MOV	BCSR,RO	;CREATE REGISTERS
2193	013052	010037	002354			MOV	RO,RLCS	
2194	013056	062700	000002			ADD	#2,RO	
2195	013062	010037	002356			MOV	RO,RLBA	
2196	013066	062700	000002			ADD	#2,RO	
2197	013072	010037	002360			MOV	RO,RLDA	
2198	013076	062700	000002			ADD	#2,RO	
2199	013102	010037	002362			MOV	RO,RLMP	
2200	013106	005737	002416			TST	PWRFLG	;POWER UP?
2201	013112	001452				BEQ	END	;NO
2202	013114	012777	000200	167232		MOV	#200,BRLCS	
2203	013122	053777	002246	167224		BIS	DRIVE,BRLCS	
2204	013130	012701	000170			MOV	#120.,R1	;INITIALIZE WAIT COUNT
2205	013134				3#:	WAITMS	#10.	
2206	013146	032777	000001	167200		BIT	#1,BRLCS	
2207	013154	001031				BNE	END	
2208	013156	005301				DEC	R1	
2209	013160	001365				BNE	3#	
2210	013162					PRINTF	#FRMT99	
	013162	012746	012106			MOV	#FRMT99,-(SP)	
	013166	012746	000001			MOV	#1,-(SP)	
	013172	010600				MOV	SP,RO	
	013174	104417				TRAP	C#PNTF	
	013176	062706	000004			ADD	#4,SP	
2211	013202					PRINTF	#FRMT98	
	013202	012746	012044			MOV	#FRMT98,-(SP)	
	013206	012746	000001			MOV	#1,-(SP)	
	013212	010600				MOV	SP,RO	
	013214	104417				TRAP	C#PNTF	
	013216	062706	000004			ADD	#4,SP	
2212	013222	004737	010522			JSR	PC,LINE1	
2213	013226					DODU	UNITST	
	013226	013700	002252			MOV	UNITST,RO	
	013232	104451				TRAP	C#DODU	
2214	013234	000137	012724			JMP	NXT	
2215	013240	013737	002410	002412	END:	MOV	UOIMN,OPIMN	
2216	013246	013737	002406	002414		MOV	UOIMX,OPIMX	
2217	013254	005737	002420			TST	T.CNTRL	;RL11??
2218	013260	001006				BNE	1#	;YES, THEN KEEP LIMITS SET
2219	013262	013737	002404	002412		MOV	LOIMN,OPIMN	
2220	013270	013737	002402	002414		MOV	LOIMX,OPIMX	
2221	013276				1#:	SETVEC	BVEC,#INTSRV,#340	

INITIALIZATION CODE

```

013276 012746 000340      MOV      #340,-(SP)
013302 012746 014464      MOV      #INTSRV,-(SP)
013306 013746 002366      MOV      BVEC,-(SP)
013312 012746 000003      MOV      #3,-(SP)
013316 104437              TRAP     C#SVEC
013320 062706 000010      ADD      #10,SP
2222 013324      ENDINIT
013324      L10023:
013324 104411              TRAP     C#INIT
2223 013326      ENDMOD
2224
2225      .SBTTL  AUTO DROP SECTION
2226
2227 013326      BGNAUTO
2228 013326 005037 002254      CLR      TRPFLG          ;CLEAR TRAP FLAG
2229 013332      SETVEC  ERRVEC,#TRPHAN,#340 ;SET UP TRAP VECTOR TO DETECT
013332 012746 000340      MOV      #340,-(SP)
013336 012746 015756      MOV      #TRPHAN,-(SP)
013342 013746 002244      MOV      ERRVEC,-(SP)
013346 012746 000003      MOV      #3,-(SP)
013352 104437              TRAP     C#SVEC
013354 062706 000010      ADD      #10,SP
2230
2231 013360 005777 166770      TST      @RLCS          ;/NON-EXISTENT CONTROLLER
2232 013364      CLRV   ERRVEC          ;ACCESS CONTROLLER
013364 013700 002244      MOV      ERRVEC,R0     ;RELEASE TRAP VECTOR
013370 104436              TRAP     C#CVEC
2233 013372 005737 002254      TST      TRPFLG        ;DID IT TRAP?
2234 013376 001416      BEQ      1#            ;NO - CHECK ITS DRIVE
2235 013400      PRINTB #FRMT16        ;ELSE, PRINT MSG. "DRIVE DROPPED - NO CONTROLLER"
013400 012746 012167      MOV      #FRMT16,-(SP)
013404 012746 000001      MOV      #1,-(SP)
013410 010600              MOV      SP,R0
013412 104414              TRAP     C#PNTB
013414 062706 000004      ADD      #4,SP
2236 013420 004737 010522      JSR      PC,LINE1     ;PROVIDE DRIVE INFORMATION
2237 013424      DODU   UNITST         ;DO DROP UNIT ON DRIVE
013424 013700 002252      MOV      UNITST,R0
013430 104451              TRAP     C#DODU
2238 013432 000427      BR       2#
2239 013434 012777 000200 166712 1#:      MOV      #200,@RLCS   ;EXIT
2240 013442 053777 002246 166704      BIS      DRIVE,@RLCS  ;SET CONTROLLER READY
2241 013450 032777 000001 166676      BIT      #1,@RLCS    ;SELECT DRIVE
2242 013456 001015      BNE      2#          ;IS DRIVE READY?
2243 013460      PRINTB #FRMT17        ;YES - EXIT
013460 012746 012233      MOV      #FRMT17,-(SP) ;ELSE, PRINT MSG. "DRIVE DROPPED - DID NOT
013464 012746 000001      MOV      #1,-(SP)
013470 010600              MOV      SP,R0
013472 104414              TRAP     C#PNTB
013474 062706 000004      ADD      #4,SP
2244
2245 013500 004737 010522      JSR      PC,LINE1     ;/RESPOND WITH 'READY' "
2246 013504      DODU   UNITST         ;PROVIDE DRIVE INFORMATION
013504 013700 002252      MOV      UNITST,R0   ;DO DROP UNIT ON DRIVE
013510 104451              TRAP     C#DODU
2247 013512
2248 013512      2#:
      ENDAUTO

```

AUTO DROP SECTION

```

013512
013512 104461
2249
2250
2251
2252 013514
2253 013514
2254
2255 013514
013514 012746 000340
013520 012746 015756
013524 013746 002244
013530 012746 000003
013534 104437
013536 062706 000010
2256 013542 032777 000200 166604 1#:
2257 013550 001774
2258 013552 042777 000100 166574
2259 013560
013560 013700 002366
013564 104436
2260 013566 005737 002416
2261 013572 001402
2262 013574 005337 002416
2263 013600
013600 013700 002244
013604 104436
2264
2265 013606
013606
013606 104412
2266 013610
2267
2279
2280
2281
2282 013614
2283
2284 013614 012737 000160 002116 TIME:
2285 013622 005237 002636
2286 013626 005437 002626
2287 013632 005737 002420
2288 013636 001420
2289
2290 013640
013640 012727 000001
013644 000000
013646 013727 002116
013652 000000
013654 005367 177772
013660 001375
013662 005367 177756
013666 001367
2291 013670 005237 002626
2292 013674 002761
2293 013676 000422
2294 013700 012737 000150 002116 2#:

L10024:
TRAP C#AUTO
.SBTTL CLEANUP CODE SECTION
BGNMOD CLNCODE
BGNCLN
SETVEC ERRVEC,#TRPHAN,#340
MOV #340,-(SP)
MOV #TRPHAN,-(SP)
MOV ERRVEC,-(SP)
MOV #3,-(SP)
TRAP C#SVEC
ADD #10,SP
1#: BIT #CRDY,@RLCS
BEQ 1#
BIC #INTEN,@RLCS
CLRVEC BVEC
MOV BVEC,R0
TRAP C#CVEC
TST PWRFLG
BEQ 2#
DEC PWRFLG
2#: CLRVEC ERRVEC
MOV ERRVEC,R0
TRAP C#CVEC
ENDCLN
L10025:
TRAP C#CLEAN
ENDMOD
.SBTTL GLOBAL SUBROUTINES
BGNMOD GLBSUB
TIME: MOV #160,L#DLY ;GET OUTER DELAY LOOP
INC TIM.US ;US-WAIT ROUTINE INDICATOR
NEG XDELAY ;GET NEGATIVE OF FACTOR
TST T.CNTRL ;RL11?
BEQ 2# ;BRANCH - IF NO
1#: DELAY #1. ;WAIT AT LEAST 100 US-- ;JSD REV A
1#: DELAY 1. ;WAIT AT LEAST 100 US-- ;JSD REV A
MOV #1.,(PC)+
.WORD 0
MOV L#DLY,(PC)+
.WORD 0
DEC -6(PC)
BNE .-4
DEC -22(PC)
BNE .-20
INC XDELAY ;WAIT FACTOR EXPIRED?
BLT 1# ;BRANCH - IF NO
BR 4# ;EXIT
2#: MOV #150,L#DLY ;GET OUTER DELAY LOOP

```

GLOBAL SUBROUTINES

```

2295          ;3$: DELAY  #1.          ;WAIT WITH RESPECT TO FONZ BUS ;JSD REV A
2296 013706   3$: DELAY  1.          ;WAIT WITH RESPECT TO FONZ BUS ;JSD REV A
      013706 012727 000001          MOV  #1.,(PC)+
      013712 000000          .WORD  0
      013714 013727 002116          MOV  L#DLY,(PC)+
      013720 000000          .WORD  0
      013722 005367 177772          DEC  -6(PC)
      013726 001375          BNE  .-4
      013730 005367 177756          DEC  -22(PC)
      013734 001367          BNE  .-20
2297 013736 005237 002626          INC  XDELAY
2298 013742 002761          BLT  3$
2299 013744 000207          4$: RTS  PC          ;WAIT FACTOR EXPIRED?
                                   ;BRANCH - IF NO
                                   ;RETURN
2300
2301 013746 012737 000160 002116 XTIME: MOV  #160,L#DLY          ;GET OUTER DELAY LOOP
2302 013754 005037 002636          CLR  TIM.US          ;MS WAIT INDICATOR
2303 013760 006337 002630          ASL  YDELAY          ;MULTIPLY BY FACTOR 4
2304 013764 006337 002630          ASL  YDELAY          ; -----
2305 013770 005437 002630          NEG  YDELAY          ;GET NEGATIVE OF RESULT
2306 013774 005737 002420          TST  T.CNTRL          ;RL11?
2307 014000 001023          BNE  1$          ;BRANCH - IF YES
2308 014002 012737 000150 002116          MOV  #150,L#DLY          ;GET OUTER DELAY LOOP
2309          ;2$: DELAY  #20          ;WAIT WITH RESPECT TO FONZ BUS ;JSD REV A
2310 014010   2$: DELAY  20          ;WAIT WITH RESPECT TO FONZ BUS ;JSD REV A
      014010 012727 000020          MOV  #20,(PC)+
      014014 000000          .WORD  0
      014016 013727 002116          MOV  L#DLY,(PC)+
      014022 000000          .WORD  0
      014024 005367 177772          DEC  -6(PC)
      014030 001375          BNE  .-4
      014032 005367 177756          DEC  -22(PC)
      014036 001367          BNE  .-20
2311 014040 005237 002630          INC  YDELAY          ;WAIT FACTOR EXPIRED?
2312 014044 002761          BLT  2$          ;BRANCH - IF NO
2313 014046 000417          BR   3$          ;GET TIME
2314          ;1$: DELAY  #10          ;WAIT AT LEAST 25 MS          ;JSD REV A
2315 014050   1$: DELAY  10          ;WAIT AT LEAST 25 MS          ;JSD REV A
      014050 012727 000010          MOV  #10,(PC)+
      014054 000000          .WORD  0
      014056 013727 002116          MOV  L#DLY,(PC)+
      014062 000000          .WORD  0
      014064 005367 177772          DEC  -6(PC)
      014070 001375          BNE  .-4
      014072 005367 177756          DEC  -22(PC)
      014076 001367          BNE  .-20
2316 014100 005237 002630          INC  YDELAY          ;WAIT FACTOR EXPIRED?
2317 014104 002761          BLT  1$          ;BRANCH - IF NO
2318 014106 000207          3$: RTS  PC          ;RETURN
2319
2320 014110 010146          SETCLK: MOV  R1,-(SP)          ;SAVE R1
2321          ;
2322          ; UNDER FALCON-PLUS, CLOCK OPERATION IS NOT GUARANTEED. CLOCK          ;JSD REV A
2323          ; INTERRUPTS MAY OR MAY NOT BE HARD-ENABLED, AND EVEN IF THEY WERE,          ;JSD REV A
2324          ; THE INTERRUPT RATE COULD BE 50, 60, OR 800 HERTZ. FURTHERMORE, THE          ;JSD REV A
2325          ; FOLLOWING CLOCK MACROS PROVIDE MISLEADING INFORMATION (UNDER          ;JSD
REV A          ;
2326          ; FALCON-PLUS). FOR ALL THESE REASONS, ASSUME NO CLOCK PRESENT, AND          ;JSD
REV A          ;
2327          ; DON'T RUN TEST 7.          ;JSD
REV A

```


GLOBAL SUBROUTINES

```

2328 ; ; ; JSD
REV A ; ; ;
2329 ; CLOCK P,PCLKCS ;PROGRAMMABLE CLOCK AVAILABLE? - CSR=772540 ;JSD
REV A ; BCOMPLETE 1# ;BRANCH - IF YES ;JSD
2330 ; ; ;
REV A ; CLOCK L,PCLKCS ;LINE CLOCK AVAILABLE? - CSR=777546 ;JSD
2331 ; ; ;
REV A ; BCOMPLETE 20# ;BRANCH IF L-CLOCK ;JSD
2332 ; ; ;
REV A ; ; ;
2333 014112 000462 BR 2# ;ELSE, INDICATE CLOCK IS NOT PRESENT
2334 014114 104407 20# READBUS ;CHECK TYPE OF BUS
014114 104407 TRAP C#RDBU
2335 014116 103036 BNCOMPLETE 1# ;BRANCH IF NOT Q-BUS
014116 103036 BCC 1#
2336 014120 005037 002666 CLR CLKFLD ;CLEAR CLOCK FIELD FOR STORING "TICKS"
2337 014124 012746 000340 SETVEC #100,#CLKTIK,#340 ;SET UP LSI-11 L-CLOCK INTERRUPT VECTOR
014124 012746 014520 MOV #340,-(SP)
014130 012746 000100 MOV #CLKTIK,-(SP)
014134 012746 000003 MOV #100,-(SP)
014140 012746 104437 TRAP C#SVEC
014144 062706 000010 ADD #10,SP

2338 ; ; ;
2339 014152 SETPRI #PRI05 ;/TO CHECK IF CLOCK IS "TICKING"
014152 012700 000240 MOV #PRI05,R0 ;SET PRIORITY TO 5 TO ALLOW CLOCK INTERRUPTS
014156 104441 TRAP C#SPRI

2340 014160 WAITMS #5 ;PAUSE TO ALLOW CLOCK INTERRUPTS
2341 ; ; ;
2342 014172 SETPRI #PRI07 ;RESTORE PRI TO 7 TO INHIBIT INT'S ;JSD REV A
014172 012700 000300 SETPRI #PRI06 ;RESTORE PRI TO 6 TO INHIBIT INT'S ;JSD REV A
014176 104441 MOV #PRI06,R0

2343 014200 TRAP C#SPRI ;CLEAR L-CLOCK INTERRUPT VECTOR
014200 012700 000100 CLRVEC #100
014204 104436 MOV #100,R0
2344 014206 005737 002666 TRAP C#CVEC
2345 014212 001422 TST CLKFLD ;L-CLOCK "TICKS"?
2346 014214 013701 002642 1# BEQ 2# ;BRANCH IF NO "TICKS"
2347 014220 011137 002644 MOV PCLKCS,R1 ;GET POINTER TO CLOCK CONTROL STATUS REGISTER
2348 014224 016137 000004 002646 MOV (R1),PCSR ;GET CLOCK CONTROL STATUS REGISTER
2349 014232 016137 000006 002650 MOV 4(R1),VEC ;GET CLOCK VECTOR ADDRESS
2350 014240 022737 000074 002650 MOV 6(R1),HZ ;GET CLOCK FREQUENCY
2351 014246 001407 CMP #60.,HZ ;60 HZ.?
2352 014250 022737 000062 002650 BEQ 3# ;BRANCH - IF YES
2353 014256 001420 CMP #50.,HZ ;50 HZ.?
2354 014260 005237 002652 2# BEQ 4# ;BRANCH - IF YES
2355 014264 000475 INC XITFLG ;SET EXIT FLAG
2356 014266 005737 002420 3# BR 8# ;EXIT
2357 014272 001404 TST T.CNTRL ;RL11?
2358 014274 012737 000030 002664 BEQ 9# ;BRANCH - IF NO
2359 014302 000403 MOV #24.,OPITIM ;SET OPIMX FOR 60 HZ CLOCK & RL11
2360 014304 012737 000047 002664 9# BR 10# ;CONTINUE
2361 014312 005237 002656 10# MOV #39.,OPITIM ;SET OPIMX FOR 60 HZ CLOCK & RLV11
2362 014316 000414 INC SIXTY ;SET 60 HZ CLOCK INDICATOR
2363 014320 005737 002420 4# BR 5# ;CHECK CLOCK TYPE
2364 014324 001404 TST T.CNTRL ;RL11?
2365 014326 012737 000024 002664 BEQ 11# ;BRANCH - IF NO
2366 014334 000403 MOV #20.,OPITIM ;SET OPIMX FOR 50 HZ CLOCK & RL11
2367 014336 012737 000040 002664 11# BR 12# ;CONTINUE
2368 014344 005237 002654 12# INC FIFTY ;SET OPIMX FOR 50 HZ CLOCK & RLV11
2369 014350 022737 000104 002646 5# CMP #104,VEC ;SET 50 HZ. CLOCK INDICATOR
2370 014356 001016 BNE 6# ;P-CLOCK?
;BRANCH - IF NO

```

GLOBAL SUBROUTINES

```

2371 014360 005237 002660      INC      PCLOCK      ;SET P-CLOCK INDICATOR
2372 014364      SETVEC     VEC,@CLKINT,@340 ;SET CLOCK INTERRUPT SERVICE ROUTINE
      014364 012746 000340      MOV      @340,-(SP)
      014370 012746 014504      MOV      @CLKINT,-(SP)
      014374 013746 002646      MOV      VEC,-(SP)
      014400 012746 000003      MOV      @3,-(SP)
      014404 104437      TRAP     C@SVEC
      014406 062706 000010      ADD      @10,SP
2373 014412 000422      BR       8@          ;EXIT
2374 014414 022737 000100 002646 6@:  CMP      @100,VEC    ;L-CLOCK?
2375 014422 001401      BEQ     7@          ;BRANCH - IF YES
2376 014424 000715      BR       2@          ;EXIT
2377 014426      7@:  SETVEC     VEC,@CLKINT,@340 ;SET CLOCK INTERRUPT SERVICE ROUTINE
      014426 012746 000340      MOV      @340,-(SP)
      014432 012746 014504      MOV      @CLKINT,-(SP)
      014436 013746 002646      MOV      VEC,-(SP)
      014442 012746 000003      MOV      @3,-(SP)
      014446 104437      TRAP     C@SVEC
      014450 062706 000010      ADD      @10,SP
2378 014454 005037 002660      CLR     PCLOCK      ;INIT P-CLOCK INDICATOR
2379 014460 012601      8@:  MOV      (SP)+,R1  ;RESTORE R1
2380 014462 000207      RTS     PC          ;RETURN
2381
2382 014464      BGNSRV
2383 014464      INTSRV:
2384
2385 014464 005237 002256      INC     INTFLG      ;SET INTERRUPT OCCURANCE FLAG
2386
2387 014470      ENDSRV
      014470 L10027:
      014470 000002      RTI
2388
2389      ;ROUTINE USED IN TIMING OPI
2390
2391 014472      BGNSRV
2392 014472      TIMSRV:
2393
2394 014472 005237 002256      INC     INTFLG      ;SET INTERRUPT INDICATOR FLAG
2395 014476 005077 166142      CLR     @PCSR      ;DISABLE CLOCK
2396
2397 014502      ENDSRV
      014502 L10030:
      014502 000002      RTI
2398
2399 014504      BGNSRV
2400 014504      CLKINT:          ;CLOCK INTERRUPT SERVICE ROUTINE
2401
2402 014504 005337 002664      DEC     OPITIM      ;OPIMX EXPIRED?
2403 014510 001002      BNE    1@          ;BRANCH - IF NO
2404 014512 005077 166126      CLR     @PCSR      ;DISABLE CLOCK
2405 014516      1@:
2406
2407 014516      ENDSRV
      014516 L10031:
      014516 000002      RTI
2408
2409 014520      BGNSRV

```

GLOBAL SUBROUTINES

```

2410 014520          CLKTIK:          ;L-CLOCK "TICK" CHECK ROUTINE FOR LSI-11
2411                                     ;INCREMENT CLOCK FIELD TO INDICATE THAT
2412 014520 005237 002666          INC      CLKFLD          ;/CLOCK IS "TICKING"
2413
2414
2415 014524          ENDSRV
      014524          L10032:
      014524 000002          RTI

2416
2417 014526          CKERLT: INLOOP
      014526 104420          TRAP      C#INLP
2418 014530          BCOMPLETE          99#
      014530 103427          BCS       99#
2419 014532 005737 012434          TST      DROP
2420 014536 001424          BEQ       99#
2421 014540 005277 165660          INC      @ERPOINT
2422 014544 027737 165654 012436  CMP      @ERPOINT, MERLMT
2423 014552 002416          BLT      99#
2424 014554          PRINTF          #FRMT11
      014554 012746 012001          MOV      @FRMT11, -(SP)
      014560 012746 000001          MOV      @1, -(SP)
      014564 010600          MOV      SP, R0
      014566 104417          TRAP      C#PNTF
2425 014570 062706 000004          ADD      @4, SP
2426 014574 004737 010522          JSR      PC, LINE1
      014600 013700 002252          DODU     UNITST, DROP THIS UNIT
      014604 104451          MOV      UNITST, R0
2427 014606          TRAP      C#DODU
      014606 104444          DOCLN
      TRAP      C#DCLN

2428
2429 014610          99#:
2430 014610 000205          RTS      R5
2431
2432          .SBTTL  ROUTINE TO CHECK FOR CONTROLLER ERRORS
2433
2434          ;*****
2435          ;*THIS ROUTINE WILL CHECK RLCS FOR ERRORS AND PRINT THEM
2436          ;*ACCORDINGLY. IT WILL MERGE THE ERROR PRINTOUT WITH THE TEST
2437          ;*ERROR MESSAGE.
2438          ;*
2439          ;*ROUTINE USES R0,R1 AND PICKS HEADER FROM R3
2440          ;*
2441          ;*      CALL      JSR      R5,CHERR          ;CHECK CNTLR FOR ERRORS
2442          ;*
2443          ;*
2444          ;*
2445
2446 014612 005037 002236          CHERR: CLR      T.CRC
2447 014616 032737 176000 002340  BIT      @176000,E.CS          ;ANY ERROR BITS SET?
2448 014624 001001          BNE     2#          ;YES,FIND OUT WHICH
2449 014626 000205          RTS     R5          ;NO EXIT
2450 014630 012701 004522          2#:  MOV      @EM100,R1          ;GET START OF STRING
2451 014634 005737 002340          TST      E.CS          ;IS COMPOSITE ERROR SET?(BETTER BE)
2452 014640 100003          BPL     99#          ;IT'S NOT SOMETHING IS WRONG
2453 014642 004537 015350          JSR      R5, FIX          ;YES, PUT "COMP" IN STRING
2454 014646 003645          COMP          ;"COMP"

```


ROUTINE TO CHECK FOR CONTROLLER ERRORS

```

2455 014650 032737 040000 002340 99: BIT #DERR,E.CS ;DRIVE ERROR SET?
2456 014656 001405 BEQ 3# ;NO, CONTINUE
2457 014660 005237 002422 INC DERFLG
2458 014664 004537 015350 JSR R5,FIX ;YES, PUT "DRV" INTO STRING
2459 014670 003574 DEMES ;"DRV"
2460 014672 032737 020000 002340 3#: BIT #NXM,E.CS ;NON-EXISTENT MEMORY ERROR?
2461 014700 001403 BEQ 4# ;NO, CONTINUE
2462 014702 004537 015350 JSR R5,FIX ;YES, PUT "NXM" INTO STRING
2463 014706 003601 NXMMES ;"NXM"
2464 014710 032737 002000 002340 4#: BIT #OPI,E.CS ;IS OPI SET?
2465 014716 001422 BEQ 6# ;NO, GO CHECK BITS 11 & 12
2466 014720 004537 015350 JSR R5,FIX ;PUT "OPI" INTO STRING
2467 014724 003606 OPIMES ;"OPI"
2468 014726 032737 004000 002340 BIT #BIT11,E.CS ;HEADERCRC ERROR?
2469 014734 001403 BEQ 5# ;NO, GO CHECK HEADER NOT FOUND
2470 014736 004537 015350 JSR R5,FIX ;GO PUT "HCRC" IN STRING
2471 014742 003613 HCRMES ;"HCRC"
2472 014744 032737 010000 002340 5#: BIT #BIT12,E.CS ;HEADER NOT FOUND?
2473 014752 001424 BEQ 8# ;NO, GO PUT "CRLF" IN STRING
2474 014754 004537 015350 JSR R5,FIX ;PUT "HNF" IN STRING
2475 014760 003621 HNFMES ;"HNF"
2476 014762 000420 BR 8# ;PUT "CRLF" IN STRING
2477 014764 032737 004000 002340 6#: BIT #BIT11,E.CS ;DATA CRC ERROR?
2478 014772 001405 BEQ 7# ;NO, GO CHECK DATA LATE
2479 014774 005237 002236 INC T.CRC
2480 015000 004537 015350 JSR R5,FIX ;PUT "DCK" IN STRING
2481 015004 003626 DCKMES ;"DCK"
2482 015006 032737 010000 002340 7#: BIT #BIT12,E.CS ;DATA LATE ERROR?
2483 015014 001403 BEQ 8# ;NO, GO PUT IN "CRLF"
2484 015016 004537 015350 JSR R5,FIX ;PUT "DLT" IN STRING
2485 015022 003633 DLTMES ;"DLT"
2486 015024 004537 015350 8#: JSR R5,FIX ;PUT "CRLF" INTO STRING
2487 015030 003642 MSCRLF ;"CRLF"
2488 015032 004537 015350 JSR R5,FIX ;MOVE HEADER
2489 015036 000000 RESTMS: .WORD 0 ;HEADER FROM TEST
2490 015040 105011 CLRB (R1) ;PUT TERMINATOR IN
2491 015042 ERROF 300.,LF,ERR6
2492 015042 104455 TRAP C:ERDF
2493 015044 000454 .WORD 300
2494 015046 003640 .WORD LF
2495 015050 007760 .WORD ERR6
2496 015052 000205 RTS ;EXIT ROUTINE
2497
2498 ;*****
2499 ;* ROUTINE TO LOAD RLCS WITH FUNCTION TO BE PERFORMED
2500 ;* CALL: JSR R5,LDFUNC ;LOAD THE FUNCTION IN NEXT WORD
2501 ;* .WORD ;BITS TO BE LOADED, FUNCTION
2502 ;* ;AND INTR ENABLE ONLY
2503
2504
2505
2506
2507 LDFUNC: BIT #BIT14,BRLCS ;DRIVE ERROR SET
BEQ 5#
MOV BRLDA,B.DA
MOV #13,BRLDA
MOV #200,B.CS
BIS DRIVE,B.CS

```

ROUTINE TO CHECK FOR CONTROLLER ERRORS

```

2508 015114 013777 002330 165232      MOV      B.CS,@RLCS
2509 015122 032777 000200 165224 6#:    BIT      @200,@RLCS
2510 015130 001774                BEQ      6#
2511 015132 013777 002334 165220      MOV      B.DA,@RLDA
2512 015140 012537 002260      5#:    MOV      (R5)+,LDCSR      ;GET BITS TO LOAD
2513 015144 010346                MOV      R3,-(SP)        ;SAVE R3
2514 015146 042737 177661 002260      BIC      @177661,LDCSR  ;CLEAR ALL BUT FUNC & INTR EN
2515 015154 013737 002260 002372      MOV      LDCSR,FNDFNC  ;SAVE FUNCTION
2516 015162 042737 000100 002372      BIC      @INTEN,FNDFNC ;ONLY FUNCTION
2517 015170 012703 015310                MOV      @MDRLST,R3     ;GET HEADER LIST
2518 015174 006237 002372                ASR      FNDFNC         ;ALIGN TO LEFT
2519 015200 001404                BEQ      2#             ;IF EQUAL TO ZERO, SET R3
2520 015202 022323                1#:    CMP      (R3)+,(R3)+ ;BUMP R3 BY 4
2521 015204 005337 002372                DEC      FNDFNC         ;DEC FUNCTION
2522 015210 001374                BNE      1#            ;FOUND IT? NO-GO BACK
2523 015212 032737 000100 002260      2#:    BIT      @INTEN,LDCSR ;YES, DO WE WANT FLAG OR INTR?
2524 015220 001401                BEQ      3#            ;FLAG BRANCH
2525 015222 005723                TST      (R3)+         ;INTR POINT TO THAT ONE
2526 015224 011303                3#:    MOV      (R3),R3   ;SET HEADER
2527 015226 010337 015036                MOV      R3,RESTMS    ;SET UP HEADER
2528 015232 010337 002376                MOV      R3,TRYFNC    ;SAVE HEADER FOR LATER
2529 015236 053737 002374 002260      BIS      XMEM,LDCSR   ;LOAD E.A. BITS
2530 015244 005037 002374                CLR      XMEM          ;CLEAR OUT THE BITS
2531 015250 053737 002246 002260      BIS      DRIVE,LDCSR ;SELECT DRIVE
2532 015256 052737 000200 002260      BIS      @200,LDCSR
2533 015264 013777 002260 165062      MOV      LDCSR,@RLCS ;LOAD FUNCTION
2534 015272 004537 015362                JSR      R5,BEFORE     ;READ REGISTERS
2535 015276 042777 000200 165050      4#:    BIC      @200,@RLCS ;ISSUE COMMAND
2536 015304 012603                MOV      (SP)+,R3     ;RESTORE R3
2537 015306 000205                RTS      R5           ;EXIT

```

```

2538
2539 015310 003705      MDRLST: NOPMES
2540 015312 003733      NOPINT
2541 015314 003762      WCKMES
2542 015316 004016      WCKINT
2543 015320 004171      GSTMES
2544 015322 004221      GSTINT
2545 015324 004130      SEKMES
2546 015326 004150      SEKINT
2547 015330 004053      RDMMES
2548 015332 004103      RMDINT
2549 015334 004311      WRTMES
2550 015336 004332      WRTINT
2551 015340 004251      RDMMES
2552 015342 004271      RDDINT
2553 015344 004353      RDMMES
2554 015346 004401      RDNINT

```

```

2555
2556 ;*****
2557 ;*ROUTINE TO MOVE ASCII STRINGS
2558 ;*USES REGISTERS R1 - WHERE STRING IS BEING BUILT
2559 ;*
2560 ;*      CALL      JSR      R5,FIX
2561 ;*      .WORD      .WORD      ;ADDRESS OF STRING TO MOVE
2562
2563 015350 012504      FIX:  MOV      (R5)+,R4     ;GET ADDRESS AND MOVE RETURN
2564 015352 112421      1#:  MOVB     (R4)+,(R1)+  ;GET BYTE AND UPDATE

```

ROUTINE TO CHECK FOR CONTROLLER ERRORS

```

2565 015354 001376          BNE      1#           ;WATCH 0 BYTE TERMINATOR
2566 015356 105741          TSTB    -(R1)        ;BACK UP OVER ZERO BYTE
2567 015360 000205          RTS      R5          ;EXIT
2568
2569                        ;ROUTINE TO READ REGISTERS PRIOR TO OPERATION
2570                        ;CALL: JSR R5,BEFORE
2571
2572 015362 017737 164766 002330 BEFORE: MOV    SRLCS,B.CS      ;READ CS
2573 015370 017737 164762 002332          MOV    SRLBA,B.BA      ;      BA
2574 015376 017737 164756 002334          MOV    SRLDA,B.DA      ;      DA
2575 015404 017737 164752 002336          MOV    SRLMP,B.MP      ;      MP
2576 015412 000205          RTS      R5
2577
2578                        ;ROUTINE TO READ REGISTERS AT TIME OF ERROR
2579                        ;CALL: JSR R5,AFTER
2580
2581 015414 017737 164734 002340 AFTER:  MOV    SRLCS,E.CS      ;READ CS
2582 015422 017737 164730 002342          MOV    SRLBA,E.BA      ;      BA
2583 015430 017737 164724 002344          MOV    SRLDA,E.DA      ;      DA
2584 015436 017737 164720 002346          MOV    SRLMP,E.MP      ;      MP
2585 015444 017737 164712 002350          MOV    SRLMP,E.MP1     ;      MP
2586 015452 017737 164704 002352          MOV    SRLMP,E.MP2     ;      MP
2587 015460 000205          RTS      R5
2588
2589 015462 010046          SIMBCC: MOV    R0,-(SP)      ;SAVE R0
2590 015464 010146          MOV    R1,-(SP)      ;SAVE R1
2591 015466 010246          MOV    R2,-(SP)      ;SAVE R2
2592 015470 012537 002304          MOV    (R5)+,TEMP2    ;GET NUMBER OF BITS
2593 015474 012537 002306          MOV    (R5)+,TEMP3    ;GET DATA FOR CRC CALCULATION
2594 015500 012537 002310          MOV    (R5)+,TEMP4    ;GET STARTING CRC
2595 015504 005037 002266          1#:  CLR    BCCFBK      ;
2596 015510 013700 002310          MOV    TEMP4,R0      ;GET PRESENT CRC
2597 015514 006037 002306          ROR    TEMP3        ;ROTATE NEW DATA
2598 015520 005500          ADC    R0            ;MERGE NEW WITH OLD
2599 015522 032700 000001          BIT    #1,R0        ;BIT 0 SET
2600 015526 001402          BEQ    2#           ;IF NOT CONTINUE
2601 015530 005137 002266          COM    BCCFBK      ;
2602 015534 013700 002264          2#:  MOV    XPOLY,R0      ;GET CRC POLYNOMIAL (CRC-16)
2603 015540 005100          COM    R0            ;COMPLEMENT POLYNOMIAL
2604 015542 040037 002266          BIC    R0,BCCFBK
2605 015546 000241          CLC                    ;CLEAR CARRY
2606 015550 006037 002310          ROR    TEMP4
2607 015554 013700 002266          MOV    BCCFBK,R0
2608 015560 013701 002310          MOV    TEMP4,R1
2609 015564 010102          MOV    R1,R2
2610 015566 040100          BIC    R1,R0
2611 015570 043702 002266          BIC    BCCFBK,R2
2612 015574 050200          BIS    R2,R0
2613 015576 043737 002264 002310          BIC    XPOLY,TEMP4
2614 015604 050037 002310          BIS    R0,TEMP4
2615 015610 005337 002304          DEC    TEMP2
2616 015614 001333          BNE    1#
2617
2618 015616 013737 002310 002270          MOV    TEMP4,CALBCC
2619 015624 012602          MOV    (SP)+,R2
2620 015626 012601          MOV    (SP)+,R1
2621 015630 012600          MOV    (SP)+,R0

```


ROUTINE TO CHECK FOR CONTROLLER ERRORS

```

2622 015632 000205          RTS      R5          ;RETURN
2623
2624          ;ROUTINE TO WAIT FOR DRIVE READY
2625
2626 015634 012701 000144   WTDRDY: MOV     #100.,R1
2627 015640 032777 000001 164506 1#: BIT     #DRDY,&RLCS
2628 015646 001013          BNE     2#
2629
2630 015650          WAITUS  #20.
2631 015662 005301          DEC     R1
2632 015664 001365          BNE     1#
2633
2634 015666          ERRDF  200.,DRTIM,ERR5
    015666 104455          TRAP   C#ERDF
    015670 000310          .WORD 200
    015672 003546          .WORD DRTIM
    015674 007722          .WORD ERR5
2635
2636 015676 000205   2#:  RTS      R5
2637
2638          ;ROUTINE TO WAIT FOR CONTROLLER
2639
2640 015700 012701 000620   WTCRDY: MOV     #400.,R1
2641 015704 032777 000200 164442 1#: BIT     #CRDY,&RLCS
2642 015712 001016          BNE     2#
2643
2644 015714          WAITUS  #20.
2645 015726 005301          DEC     R1
2646 015730 001365          BNE     1#
2647 015732 004537 015414          JSR    R5,AFTER
2648
2649 015736          ERRDF  100.,CRTIM,ERR5
    015736 104455          TRAP   C#ERDF
    015740 000144          .WORD 100
    015742 003521          .WORD CRTIM
    015744 007722          .WORD ERR5
2650 015746 000205          RTS      R5
2651
2652 015750 004537 015414   2#:  JSR    R5,AFTER
2653 015754 000205          RTS      R5
2654
2655 015756 005237 002254   TRPHAN: INC     TRPFLG
2656 015762 000002          RTI
2657
2658 015764          MDHOME:
2659
2660 015764          BGNSEG          ;##START OF SEGMENT##
    015764 104404          TRAP   C#BSEG
2661          ;ISSUE DRIVE RESET
2662
2663 015766 012737 000001 002400   MOV     #1,ERFLG          ;SET ERROR FLAG
2664 015774 012777 000013 164356   MOV     #DRST!MK!GSBIT,&RLDA
2665 016002 004537 015054          JSR    R5,LDFUNC          ;LOAD THE FUNCTION IN NEXT WORD
2666 016006 000004          GSTAT
2667 016010 004537 015700          JSR    R5,WTCRDY
2668 016014          ESCAPE  SEG          ;CHECK FOR FL:LOE, ELSE EXIT SEG
    016014 104410          TRAP   C#ESCAPE

```

ROUTINE TO CHECK FOR CONTROLLER ERRORS

2669	016016	000216			.WORD	10000\$-.		
2670	016020	004537	014612		JSR	R5,CHERR		;CHECK CNTLR FOR ERRORS
	016024	104410			ESCAPE	SEG		;CHECK FOR FL:LOE, ELSE EXIT SEG
	016026	000206			TRAP	C\$ESCAPE		
					.WORD	10000\$-.		
2671								
2672	016030	004537	015054		JSR	R5,LDFUNC		;LOAD THE FUNCTION IN NEXT WORD
2673	016034	000010			RDHDR			
2674	016036	104410			ESCAPE	SEG		;CHECK FOR FL:LOE, ELSE EXIT SEG
	016040	000174			TRAP	C\$ESCAPE		
					.WORD	10000\$-.		
2675	016042	004537	015700		JSR	R5,WTCRDY		
2676	016046	104410			ESCAPE	SEG		;CHECK FOR FL:LOE, ELSE EXIT SEG
	016046	104410			TRAP	C\$ESCAPE		
	016050	000164			.WORD	10000\$-.		
2677								
2678	016052	004537	014612		JSR	R5,CHERR		;CHECK CNTLR FOR ERRORS
2679	016056	104410			ESCAPE	SEG		;CHECK FOR FL:LOE, ELSE EXIT SEG
	016056	104410			TRAP	C\$ESCAPE		
	016060	000154			.WORD	10000\$-.		
2680								
2681	016062	013737	002346	002272	MOV	E.MP, TMPO		;GET HEADER
2682	016070	042737	000077	002272	BIC	#77, TMPO		
2683	016076	001424			BEQ	99\$;SEEK IS NOT NECESSARY
2684	016100	042737	000100	002272	BIC	#100, TMPO		
2685	016106	012777	000001	164244	MOV	#PK, BRLDA		;SET TO SEEK
2686	016114	053777	002272	164236	BIS	TMPO, BRLDA		;SET IN DIFFERENCE
2687								
2688	016122	004537	015054		JSR	R5,LDFUNC		;LOAD THE FUNCTION IN NEXT WORD
2689	016126	000006			SEEK			
2690	016130	004537	015700		JSR	R5,WTCRDY		
2691	016134	104410			ESCAPE	SEG		;CHECK FOR FL:LOE, ELSE EXIT SEG
	016134	104410			TRAP	C\$ESCAPE		
	016136	000076			.WORD	10000\$-.		
2692								
2693	016140	004537	014612		JSR	R5,CHERR		;CHECK CNTLR FOR ERRORS
2694	016144	104410			ESCAPE	SEG		;CHECK FOR FL:LOE, ELSE EXIT SEG
	016144	104410			TRAP	C\$ESCAPE		
	016146	000066			.WORD	10000\$-.		
2695								
2696	016150	004537	015054		JSR	R5,LDFUNC		;LOAD THE FUNCTION IN NEXT WORD
2697	016154	000010			RDHDR			
2698	016156	004537	015700		JSR	R5,WTCRDY		
2699	016162	104410			ESCAPE	SEG		;CHECK FOR FL:LOE, ELSE EXIT SEG
	016162	104410			TRAP	C\$ESCAPE		
	016164	000050			.WORD	10000\$-.		
2700	016166	004537	014612		JSR	R5,CHERR		
2701	016172	104410			ESCAPE	SEG		
	016172	104410			TRAP	C\$ESCAPE		
	016174	000040			.WORD	10000\$-.		
2702								
2703	016176	013737	002346	002272	MOV	E.MP, TMPO		;GET HEADER
2704	016204	043737	002262	002272	BIC	SECMASK, TMPO		;IGNORE SECTOR
2705	016212	001404			BEQ	1\$;ON ZERO
2706								
2707	016214	104455			ERRDF	400., SKHOME, ERRO		;CAN'T SEEK TO TRACK 0
	016214	104455			TRAP	C\$ERDF		

99\$:

ROUTINE TO CHECK FOR CONTROLLER ERRORS

```

016216 000620          .WORD 400
016220 004430          .WORD SKHOME
016222 007510          .WORD ERRO
2708
2709 016224          1$:  ESCAPE SEG          ;CHECK FOR FL:LOE, ELSE EXIT SEG
      016224 104410    TRAP C$ESCAPE
      016226 000006    .WORD 10000$-.
2710
2711 016230 005037 002400 CLR ERFLG          ;INDICATE SUCCESS BACK TO MAIN PROGRAM
2712
2713 016234          ENDSEG          ;##END OF SEGMENT##
      016234          10000$:
      016234 104405    TRAP C$ESEG
2714
2715 016236 000207    RTS PC
2716
2717 016240          ENDMOD
2718
2719          .SBTTL **TEST 1** - WRITE FUNCTION
2720
2721 016240          BGNST          ;**START OF TEST**
2722
2723 016240          STARS
      ;*****
      ;CHECK OF WRITE LOGIC UNDER FLAG MODE, WE WILL FIRST ISSUE A
      ;READ HEADER SO THAT WE DON'T WRITE ON THE BAD SECTOR
      ;FILE TRACK. WE WILL WRITE A FULL SECTOR (128 WORDS) FROM
      ;MEMORY (BUF). WE CHECK THAT NO ERRORS OCCUR. IF WE
      ;HAVE A DRIVE ERROR WE WILL DO A "GET STATUS" TO SEE
      ;IF WRITE PROTECT IS SET IF IT IS WE WILL ABORT THE
      ;TEST. AN ERROR ON THE WRITE WILL LOOP ON JUST THE
      ;WRITE PORTION. LOOP ON TEST WILL READ HEADER, SEEK (IF
      ;NECESSARY) AND WRITE.
      STARS
      ;*****
2734
2735 016240 004737 015764 JSR PC,HOMHOME          ;HEADS OVER TRACK 0
2736 016244          CKERFG          ;HEADS GO HOME OKAY
      016252 104432    TRAP C$EXIT
      016254 000126    .WORD L10033-.
2737
2738 016256          BGNSEG          ;##START OF SEGMENT##
      016256 104404    TRAP C$BSEG
2739
2740 016260          3$:
2741 016260 005077 164074 CLR $RLDA          ;SET DISK ADDRESS
2742 016264 012777 177600 164070 MOV #-128,$RLMP      ;WORD COUNT
2743 016272 012777 003426 164056 MOV $BUF,$RLBA      ;BUS ADDRESS
2744 016300 004537 015054 JSR R5,LDFUNC        ;LOAD THE FUNCTION IN NEXT WORD
2745 016304 000012    WRITE          ;WRITE
2746
2747 016306 004537 015700 JSR R5,WTCRDY        ;WAIT FOR CONTROLLER READY
2748 016312          ESCAPE SEG          ;CHECK FOR FL:LOE, ELSE EXIT SEG
      016312 104410    TRAP C$ESCAPE
      016314 000064    .WORD 10001$-.
2749
2750 016316 032777 040000 164030 BIT $DERR,$RLCS      ;DRIVE ERROR SET?

```


***TEST 1** - WRITE FUNCTION

```

2751 016324 001425          BEQ      4$          ;BRANCH IF NOT
2752
2753 016326 012777 000003 164024  MOV     @MK!GSBIT,@RLDA ;SET GET STATUS OF DRIVE
2754 016334 004537 015054          JSR     R5,LDFUNC      ;LOAD THE FUNCTION IN NEXT WORD
2755 016340 000004          GSTAT          ;GET STATUS
2756 016342 004537 015700          JSR     R5,WTCRDY     ;WAIT FOR CONTROLLER READY
2757 016346          ESCAPE  SEG          ;CHECK FOR FL:LOE, ELSE EXIT SEG
      016346 104410          TRAP   C$ESCAPE
      016350 000030          .WORD 10001$-
2758
2759 016352 013737 002346 002300  MOV     E.MP,GDDAT    ;READ DRIVE STATUS
2760 016360 032737 020000 002300  BIT     @BIT13,GDDAT  ;WRITE LOCK ERROR?
2761 016366 001404          BEQ     4$          ;NO, BRANCH
2762
2763 016370          ERRSF  3.,WRLOCK,ERRO          ;WRITE LOCK ERROR
      016370 104454          TRAP   C$ERSF
      016372 000003          .WORD 3
      016374 004452          .WORD WRLOCK
      016376 007510          .WORD ERRO
2764 016400          4$:
2765
2766 016400          ENDSEG          ;##END OF SEGMENT##
      016400          10001$:
      016400 104405          TRAP   C$ESEG
2767 016402          ENDTST          ;**END OF TEST**
      016402          L10033:
      016402 104401          TRAP   C$ETST
2768
2769          .SBTTL  **TEST 2** - WRITE FUNCTION INTERRUPT
2770
2771 016404          BGNST          ;**START OF TEST**
2772
2773 016404          STARS
      ;*****
      ;CHECK OF WRITE LOGIC UNDER INTERRUPT MODE, WE WILL ISSUE A
      ;READ HEADER SO THAT WE DON'T WRITE ON THE BAD SECTOR FILE
      ;TRACK. WE WILL WRITE A FULL SECTOR (128 WORDS) FROM MEMORY (BUF).
      ;WE CHECK THAT NO ERRORS OCCUR. WE DO NOT CHECK RLDA OR RLBA
      ;INCREMENT AT THIS TIME.
      STARS
      ;*****
2774
2775
2776
2777
2778
2779 016404
2780
2781 016404 004737 015764          JSR     PC,HOMOME    ;HEADS OVER TRACK 0
2782 016410          CKERFG          ;HEADS GO HOME OKAY
      016416 104432          TRAP   C$EXIT
      016420 000112          .WORD L10034-.
2783
2784 016422          BGNSEG          ;##START OF SEGMENT##
      016422 104404          TRAP   C$BSEG
2785
2786 016424 005037 002256          CLR     INTFLG      ;CLEAR INTERRUPT OCCURANCE FLAG
2787 016430 005077 163724          CLR     @RLDA
2788 016434 012777 177600 163720  MOV     #-128.,@RLMP ;SET UP WORD COUNT
2789 016442 012777 003426 163706  MOV     @BUF,@RLBA  ;SET UP BUS ADDRESS
2790
2791 016450          SETPRI @PRI00          ;PRIORITY TO 0
      016450 012700 000000          MOV     @PRI00,R0

```

TEST 2 - WRITE FUNCTION INTERRUPT

```

016454 104441 TRAP C#SPRI
2792 016456 004537 015054 JSR R5,LDFUNC ;LOAD THE FUNCTION IN NEXT WORD
2793 016462 000112 WRITE!INTEN ;WRITE UNDER INTERRUPT
2794 016464 004537 015700 JSR R5,WTCRDY ;WAIT FOR INTERRUPT
2795 016470 ESCAPE SEG ;CHECK FOR FL:LOE, ELSE EXIT SEG
      016470 104410 TRAP C#ESCAPE
      016472 000036 .WORD 10000#-.

2796
2797
2798 016474 ; SETPRI #PRI07 ;SET PRIORITY TO 7 ;JSD REV A
      016474 012700 000300 SETPRI #PRI06 ;SET PRIORITY TO 6 ;JSD REV A
      016500 104441 MOV #PRI06,RO
2799 016502 005737 002256 TRAP C#SPRI
2800 016506 001004 TST INTFLG ;DID INTERRUPT OCCUR?
2801 BNE 2# ;YES-BRANCH NO-REPORT
2802 016510 ERRDF 4,EM17,ERRO ;WRITE DID NOT INTERRUPT
      016510 104455 TRAP C#ERDF
      016512 000004 .WORD 4
      016514 005322 .WORD EM17
      016516 007510 .WORD ERRO
2803 016520 2#; ESCAPE SEG ;CHECK FOR FL:LOE, ELSE EXIT SEG
      016520 104410 TRAP C#ESCAPE
      016522 000006 .WORD 10000#-.

2804
2805 016524 004537 014612 JSR R5,CHERR ;CHECK CNTLR FOR ERRORS
2806
2807 016530 ENDSEG ;##END OF SEGMENT##
      016530 10000#; TRAP C#ESEG
2808 016532 ENDTST ;**END OF TEST**
      016532 L10034; TRAP C#ETST
      016532 104401

2809
2810 .SBTTL **TEST 3** - PROPER INCREMENT OF RLBA ON WRITE
2811 BGNTST ;**START OF TEST**
2812 016534
2813
2814 016534 STARS
      ;*****
      ;CHECK THAT THE RLBA WILL INCREMENT PROPERLY AFTER THE
      ;WRITE WAS FINISHED THE RLBA SHOULD BE 128 WORDS (256 BYTES)
      ;CREATED. STARTING RLBA IS "BUF", ENDING SHOULD BE "BUF + 256."
      ;WE WILL MONITOR ALL ERRORS AND REPORT THEM ACCORDINGLY
      STARS
      ;*****

2820
2821 016534 004737 015764 JSR PC,HDHOME ;HEADS OVER TRACK 0
2822 016540 CKERFG ;HEADS GO HOME OKAY
      016546 104432 TRAP C#EXIT
      016550 000116 .WORD L10035-.

2823
2824 016552 BGNSEG ;##START OF SEGMENT##
      016552 104404 TRAP C#BSEG

2825
2826 016554 3#; CLR #RLDA
2827 016554 005077 163600 MOV #BUF,#RLBA ;SET UP BUS ADDRESS
2828 016560 012777 003426 163570

```

***TEST 3** - PROPER INCREMENT OF RLBA ON WRITE

```

2829 016566 012777 177600 163566      MOV    #-128.,@RLMP      ;WORD COUNT
2830 016574 012737 003426 002300      MOV    @BUF,GDDAT      ;FORM EXPECTED BUS ADDRESS
2831 016602 062737 000400 002300      ADD    @256.,GDDAT     ;AFTER WRITE
2832
2833 016610 004537 015054                JSR    R5,LDFUNC        ;LOAD THE FUNCTION IN NEXT WORD
2834 016614 000012                        WRITE
2835 016616 004537 015700                JSR    R5,WTCRDY       ;WRITE
2836 016622 004537 015700                ESCAPE SEG             ;WAIT FOR CONTROLLER READY
                                TRAP  C$ESCAPE           ;CHECK FOR FL:LOE, ELSE EXIT SEG
                                .WORD 10000$-.
2837
2838 016626 004537 014612                JSR    R5,CHERR        ;CHECK CNTLR FOR ERRORS
2839 016632 004537 014612                ESCAPE SEG             ;CHECK FOR FL:LOE, ELSE EXIT SEG
                                TRAP  C$ESCAPE           ;CHECK FOR FL:LOE, ELSE EXIT SEG
                                .WORD 10000$-.
2840 016636 017737 163514 002302      MOV    @RLBA,BDDAT     ;READ 'RLBA' FOR PRESENT ADDRESS
2841 016644 023737 002302 002300      CMP    BDDAT,GDDAT     ;DID 'BA' INCREMENT PROPERLY?
2842 016652 001404                        BEQ    2$              ;YES, CONTINUE
2843
2844 016654                        ERRDF  5.,EM20,ERR4    ;BA DID NOT INCREMENT
                                TRAP  C$ERDF
                                .WORD 5
                                .WORD EM20
                                .WORD ERR4

```

```

2845
2846 016664                        2$:
2847
2848 016664                        ENDSEG                    ;##END OF SEGMENT##
                                10000$:
2849 016666 104405                TRAP  C$ESEG
                                ENDTST
                                L10035:
2850 016666 104401                TRAP  C$ETST

```

.SBTTL ***TEST 4** - PROPER INCREMENT OF RLDA ON WRITE

```

2851
2852
2853 016670                        BGNTST                    ;**START OF TEST**
2854
2855 016670

```

```

STARS
;*****
;CHECK THAT THE SECTOR INCREMENTS AFTER THE WRITE WAS FINISHED.
;WE RANDOMLY PICK A SECTOR (OTHER THAN LAST TRACK) AND ISSUE
;A FULL SECTOR WRITE THE RLDA SHOULD REFLECT AN INCREMENT
;OF THE SECOTR. "GDDAT" WAS THE EXPECTED RLDA.
STARS
;*****

```

```

2861
2862 016670 004737 015764                JSR    PC,H0HOME       ;HEADS OVER TRACK 0
2863 016674                        CKERFG
                                TRAP  C$EXIT           ;HEADS GO HOME OKAY
                                .WORD L10036-.
2864
2865 016706                        BGNSEG                    ;##START OF SEGMENT##
                                TRAP  C$BSEG
2866
2867 016710                        3$:
2868 016710 005037 002300                CLR    GDDAT

```


TEST 4 - PROPER INCREMENT OF RLDA ON WRITE

```

2869 016714 013777 002300 163436      MOV      GDDAT, @RLDA      ;SETUP DISK ADDRESS
2870 016722 005237 002300              INC      GDDAT            ;CREATE EXPECTED SECTOR
2871 016726 012777 177600 163426      MOV      @-128., @RLMP    ;WORD COUNT
2872 016734 012777 003426 163414      MOV      @BUF, @RLBA     ;SETUP BUS ADDRESS
2873
2874 016742 004537 015054              JSR      R5, LDFUNC       ;LOAD THE FUNCTION IN NEXT WORD
2875 016746 000012              WRITE          ;WRITE
2876 016750 004537 015700              JSR      R5, WTCRDY      ;WAIT FOR CONTROLLER READY
2877 016754              ESCAPE SEG          ;CHECK FOR FL:LOE, ELSE EXIT SEG
      016754 104410      TRAP      C#ESCAPE
      016756 000040      .WORD    10000#-.
2878
2879 016760 004537 014612              JSR      R5, CHERR       ;CHECK CNTLR FOR ERRORS
2880 016764              ESCAPE SEG          ;CHECK FOR FL:LOE, ELSE EXIT SEG
      016764 104410      TRAP      C#ESCAPE
      016766 000030      .WORD    10000#-.
2881
2882 016770 013737 002344 002302      MOV      E.DA, BDDAT     ;READ DISK ADDRESS
2883 016776 023737 002300 002302      CMP      GDDAT, BDDAT    ;DID SECTOR INCREMENT PROPERLY
2884 017004 001404              BEQ      2#             ;YES, BRANCH NO, REPORT ERROR
2885
2886 017006              ERRDF 6., EM21, ERR4    ;DA DID NOT INCREMENT
      017006 104455      TRAP      C#ERDF
      017010 000006      .WORD    6
      017012 005414      .WORD    EM21
      017014 007654      .WORD    ERR4
2887
2888 017016              2#:
2889
2890 017016              ENDSEG                ;##END OF SEGMENT##
      017016              10000#:
      017016 104405      TRAP      C#ESEG
2891 017020              ENDTST                ;##END OF TEST##
      017020              L10036:
      017020 104401      TRAP      C#ETST
2892
2893              .SBTTL  ***TEST 5*** - FORCE HEADER NOT FOUND WITH WRITE
2894
2895 017022              BGNTST                ;##START OF TEST##
2896
2897 017022              STARS
      ;*****
      ;FORCE HEADER NOT FOUND ERROR TO OCCUR. THIS IS DONE
      ;BY SETTING SECTOR 40 OF THE RLDA AND ISSUING A
      ;WRITE. SECTOR 40 DOES NOT EXIST ON THE RLO1 PACK
      ;THEREFORE HDR NT FOUND SHOULD SET.
      STARS
      ;*****
2903
2904 017022 004737 015764              JSR      PC, HDHOME     ;HEADS OVER TRACK 0
2905 017026              CKERFG                ;HEADS GO HOME OKAY
      017034 104432      TRAP      C#EXIT
      017036 000120      .WORD    L10037-.
2906
2907 017040              BGNSEG                ;##START OF SEGMENT##
      017040 104404      TRAP      C#BSEG
2908

```

TEST 5 - FORCE HEADER NOT FOUND WITH WRITE

```

2909 017042 012777 000050 163310      MOV    #40.,@RLDA      ;INSURE NOT TO FIND HEADER BY
2910 017050 012777 003426 163300      MOV    @BUF,@RLBA     ;SETTING SECTOR 40 OF CYL. ADDR.
2911 017056 012777 177777 163276      MOV    #-1,@RLMP     ;WORD COUNT
2912
2913 017064 004537 015054                JSR    R5.LDFUNC      ;LOAD THE FUNCTION IN NEXT WORD
2914 017070 000012                WRITE                ;WRITE
2915 017072 004537 015700                JSR    R5.WTCRDY     ;WAIT FOR CONTROLLER READY
2916 017076 017076 104410                ESCAPE SEG           ;CHECK FOR FL:LOE, ELSE EXIT SEG
                TRAP    C#ESCAPE
                .WORD   10000#-.
2917
2918 017102 013737 002340 002272      MOV    E.CS,TMPO     ;GET RLCS
2919 017110 042737 001777 002272      BIC    #1777,TMPO    ;SAVE ERROR BITS
2920 017116 022737 112000 002272      CMP    #BIT15!BIT12!BIT10,TMPO ;HDR NOT FOUND SET.
2921 017124 001402                BEQ    1#            ;YES, CONTINUE
2922
2923 017126 004537 014612                JSR    R5.CHERR
2924 017132 017132 104406                1#:  CKLOOP
                TRAP    C#CLP1
2925
2926 017134 022737 112000 002272      CMP    #BIT15!BIT12!BIT10,TMPO
2927 017142 001404                BEQ    2#
2928 017144 017144 104455                ERDF   23.,EM10,ERRO
                TRAP    C#ERDF
                .WORD   23
                .WORD   EM10
                .WORD   ERRO
2929
2930 017154                2#:
                ;WHEN FORCED
2931
2932 017154                ENDSEG              ;##END OF SEGMENT##
                10000#:
                TRAP    C#ESEG
2933 017156 017156 104405                ENDTST              ;**END OF TEST**
                L10037:
                TRAP    C#ETST
2934
2935                .SBTTL  ***TEST 6*** - FORCE HEADER NOT FOUND WITH WRITE INTERRUPT
2936
2937 017160                BGNTST              ;**START OF TEST**
2938
2939 017160                STARS
                ;*****
                ;TEST THAT HEADER NOT FOUND ERROR WILL GENERATE AN INTERRUPT
                ;ON OCCURRENCE. HEADER NOT FOUND WILL BE FORCED BY SETTING
                ;SECTOR 40 OF RLDA AND ISSUEING A WRITE
                STARS
                ;*****
2944
2945 017160 004737 015764                JSR    PC,HDRHOME    ;HEADS OVER TRACK 0
2946 017164 017172 104432                CKERFG              ;HEADS GO HOME OKAY
                TRAP    C#EXIT
                .WORD   L10040-.
2947
2948 017176 017176 104404                BGNSEG              ;##START OF SEGMENT##
                TRAP    C#BSEG
2949

```

TEST 6 - FORCE HEADER NOT FOUND WITH WRITE INTERRUPT

```

2950 017200          SETPRI  #PRI00
      017200 012700 000000  MOV    #PRI00,R0
      017204 104441  TRAP   C#SPRI
2951 017206 005037 002256  CLR    INTFLG          ;CLEAR INTERRUPT OCCURANCE FLAG
2952 017212 012777 000050 163140  MOV    #40.,@RLDA      ;INSURE NOT TO FIND HEADER BY
2953 017220 012777 003426 163130  MOV    @BUF,@RLBA      ;SETTING SECTOR 40 OF CYL. ADDR.
2954 017226 012777 177777 163126  MOV    #-1,@RLMP      ;WORD COUNT
2955
2956 017234 004537 015054  JSR    R5,LDFUNC      ;LOAD THE FUNCTION IN NEXT WORD
2957 017240 000112  WRITE!INTEN          ;WRITE
2958 017242 004537 015700  JSR    R5,WTCRDY      ;WAIT FOR CONTROLLER READY
2959 017246
      017246 104406  TRAP   C#CLP1
2960
2961 017250          SETPRI  #PRI07          ;JSD REV A
      017250 012700 000300  SETPRI #PRI06          ;JSD REV A
      017254 104441  MOV    #PRI06,R0
      TRAP  C#SPRI
2962
2963 017256 005737 002256  TST    INTFLG          ;DID INTERRUPT OCCUR
2964 017262 001004  BNE    2#             ;YES OKAY
2965
2966 017264          ERRDF  24.,EM43,ERRO ;NO INTERRUPT FROM OPI
      017264 104455  TRAP  C#ERDF
      017266 000030  .WORD 24
      017270 006461  .WORD EM43
      017272 007510  .WORD ERRO
2967
2968 017274          2#:  ESCAPE  SEG          ;CHECK FOR FL:LOE, ELSE EXIT SEG
      017274 104410  TRAP  C#ESCAPE
      017276 000054  .WORD 10000#-.
2969
2970 017300 013737 002340 002272  MOV    E.CS,TMPO      ;GET RLCS
2971 017306 042737 001777 002272  BIC    #1777,TMPO      ;SAVE ERROR BITS
2972 017314 022737 112000 002272  CMP    @BIT15!BIT12!BIT10,TMPO ;WDR NOT FOUND SET.
2973 017322 001402  BEQ    1#             ;YES, CONTINUE
2974
2975 017324 004537 014612  JSR    R5,CHERR
2976 017330          1#:  CKLOOP
      017330 104406  TRAP  C#CLP1
2977
2978 017332 022737 112000 002272  CMP    @BIT15!BIT12!BIT10,TMPO
2979 017340 001404  BEQ    3#
2980 017342          ERRDF  25.,EM10,ERRO
      017342 104455  TRAP  C#ERDF
      017344 000031  .WORD 25
      017346 005064  .WORD EM10
      017350 007510  .WORD ERRO
2981
2982 017352          3#:
2983
2984 017352          ENDSEG          ;##END OF SEGMENT##
      017352          10000#:
      017352 104405  TRAP  C#ESEG
2985 017354          ENDTST
      017354          L10040:
      017354 104401  TRAP  C#ETST
2986

```


••TEST 7•• - CHECK OPI TIME WITH HDR NT FND

```

2987 .SBTTL ••TEST 7•• - CHECK OPI TIME WITH HDR NT FND
2988
2989 017356 BGNTST ;••START OF TEST••
2990
2991 017356 STARS
;*****
;CHECK OPI TIME IT SHOULD BE AROUND 200 MILLISECONDS (ON UNIBUS)
;CHECK THIS BY TIMING OPI ON A FORCED HEADER NOT FOUND
;ISSUE WRITE WITH SECTOR 40 SET IN THE DISK ADDRESS
2992 STARS
2993 ;*****
2994
2995 017356
2996
2997 017356 004737 014110 JSR PC,SETCLK ;CALL INITIALIZE CLOCK ROUTINE
2998 017362 005737 002652 TST XITFLG ;EXIT?
2999 017366 001402 BEQ 1$ ;BRANCH - IF NO
3000 ; PRINTB #FRMT18 ;ELSE, PRINT MSG. "TEST 7 CANNOT BE PERFORMED... ;JSD
REV A
3001 ;/CLOCK IS NOT AVAILABLE"
3002 017370 000137 017742 JMP 8$ ;EXIT
3003 017374 004737 015764 1$: JSR PC,HOMOME ;HEADS OVER TRACK 0
3004 017400 CKERFG ;HEADS GO HOME OKAY
017406 104432 TRAP C$EXIT
017410 000346 .WORD L10041-.
3005
3006 017412 BGNSEG ;#START OF SEGMENT#
017412 104404 TRAP C$BSEG
3007
3008 017414 CLRVEC BVEC ;CLEAR PRESENT INTERRUPT VECTOR
017414 013700 002366 MOV BVEC,R0
017420 104436 TRAP C$CVEC
3009 017422 SETVEC BVEC,@TIMSRV,#340 ;SET INTR. VEC. WITH DISABLE CLOCK
017422 012746 000340 MOV #340,-(SP)
017426 012745 014472 MOV @TIMSRV,-(SP)
017432 013746 002366 MOV BVEC,-(SP)
017436 012746 000003 MOV #3,-(SP)
017442 104437 TRAP C$SVEC
017444 062706 000010 ADD #10,SP
3010 017450 SETPRI #PRI00
017450 012700 000000 MOV #PRI00,R0
017454 104441 TRAP C$SPRI
3011 017456 005037 002256 CLR INTFLG ;CLEAR INTERRUPT FLAG
3012 017462 012777 000050 162670 MOV #40,@R1LDA ;SET UP FOR HDR NT FND
3013 017470 012777 003426 162660 MOV @BUF,@R1LBA ;BUS ADDRESS
3014 017476 012777 177777 162656 MOV #-1,@R1LMP ;WORD COUNT
3015 017504 013737 002664 002302 MOV OPITIM,BDDAT ;GET OPIMX FOR WORST CASE
3016 017512 013701 002644 MOV PCSR,R1 ;GET CSR
3017 017516 005737 002660 TST PCLOCK ;USING THE P-CLOCK?
3018 017522 001404 BEQ 6$ ;BRANCH - IF NO
3019 017524 012711 000014 MOV #14,(R1) ;SET P-CLOCK, REPEAT-INT,LINE FREQ.
3020 017530 005061 000002 CLR 2(R1) ;INIT COUNT BUFFER REGISTER
3021 017534 004537 015054 6$: JSR R5,LDFUNC ;LOAD THE FUNCTION IN THE NEXT WORD
3022 017540 000112 WRITE!INTEN ;WRITE UNDER INTERRUPT
3023 017542 013700 002664 MOV OPITIM,R0 ;GET OPIMX TO CALCULATE TIME EXPIRED
3024 017546 052711 000101 BIS #101,(R1) ;ENABLE CLOCK
3025 017552 005737 002664 40$: TST OPITIM ;COUNT EXPIRED?
3026 017556 001446 BEQ 4$ ;BRANCH - IF YES
3027 017560 005737 002256 TST INTFLG ;INTERRUPT OCCURED?
3028 017564 001772 BEQ 40$ ;BRANCH - IF NO

```

••TEST 7•• - CHECK OPI TIME WITH HDR NT FND

```

3029 017566 005437 002664      NEG      OPITIM      ;GET NEGATIVE OF FACTOR FOR SUBTRACTION
3030 017572 060037 002664      ADD      RO,OPITIM   ;SUBTRACT PASSING TIME FROM ORIGINAL
3031 017576 013700 002664      MOV      OPITIM,RO   ;GET TIME EXPIRED
3032 017602 005737 002656      TST      SIXTY      ;60 HZ.?
3033 017606 001405                BEQ      9#          ;BRANCH - IF NO
3034 017610 006300                ASL      RO          ;MULTIPLY BY 16(10)
3035 017612 006300                ASL      RO          ;FOR
3036 017614 006300                ASL      RO          ;60 HZ.
3037 017616 006300                ASL      RO          ;CASE
3038 017620 000410                BR       2#          ;EXIT
3039 017622 006300      9#:      ASL      RO          ;MULTIPLY BY 20(10)
3040 017624 006300                ASL      RO          ;FOR
3041 017626 006300                ASL      RO          ;THE
3042 017630 006300                ASL      RO          ;50 HZ.
3043 017632 063700 002664      ADD      OPITIM,RO   ;CASE
3044 017636 063700 002664      ADD      OPITIM,RO   ;STOP HERE
3045
3046      ;CHECK THAT OPI TIME IS WITHIN LIMITS
3047
3048 017642 010037 002302      2#:      MOV      RO,BDDAT      ;SAVE EXPIRED TIME
3049      ;
3050 017646                SETPRI   #PRI07      ;JSD REV A
      017646 012700 000300      SETPRI   #PRI06      ;JSD REV A
      017652 104441                MOV      #PRI06,RO
3051 017654 023737 002414 002302      TRAP    C#SPRI
3052 017662 002404                CMP      OPIMX,BDDAT  ;IS IT WITHIN LIMITS
3053 017664 023737 002412 002302      BLT     4#          ;NO, REPORT ERROR
3054 017672 003404                CMP      OPIMN,BDDAT  ;WITHIN LIMITS
3055 017674                BLE     5#          ;YES
      017674 104455      4#:      ERDF    974.,EM56,ERR13 ;OPI TIMING INCORRECT
      017676 001716      TRAP    C#ERDF
      017700 007033      .WORD  974
      017702 010346      .WORD  EM56
3056 017704                .WORD  ERR13
      017704 013700 002366      5#:      CLRVEC  BVEC          ;CLEAR PRESENT VECTOR
      017710 104436      MOV     BVEC,RO
3057 017712                TRAP    C#CVEC
      017712 012746 000340      SETVEC  BVEC,#INTSRV,#340 ;SET IN OLD VECTOR
      017716 012746 014464      MOV     #340,-(SP)
      017722 013746 002366      MOV     #INTSRV,-(SP)
      017726 012746 000003      MOV     BVEC,-(SP)
      017732 104437      MOV     #3,-(SP)
      017734 062706 000010      TRAP    C#SVEC
3058 017740                ADD     #10,SP
      017740                ENDSEG      ;##END OF SEGMENT##
      017740 104405      10000#: TRAP    C#ESEG
3059 017742 005037 002652      8#:      CLR     XITFLG      ;INIT EXIT FLAG
3060 017746 005037 002656      CLR     SIXTY      ;INIT 60 HZ. FLAG
3061 017752 005037 002660      CLR     PCLOCK     ;INIT PCLOCK INDICATOR
3062
3063 017756                ENDTST
      017756                L10041:
      017756 104401      TRAP    C#ETST
3064
3065      .SBTTL  ••TEST 8•• - MULTIPLE SECTOR TRANSFER ON WRITE
3066
3067 017760      BGNST      ;••START OF TEST••

```

TEST 8 - MULTIPLE SECTOR TRANSFER ON WRITE

```

3068
3069 017760          STARS
                    ;*****
3070                ;CHECK FOR MULTIPLE SECTOR TRANSFER ON WRITE. THIS TEST CHECKS
3071                ;THAT TWO SECTORS CAN BE SUCCESSFULLY WRITTEN. WE LOAD
3072                ;A WORD COUNT OF 129 WORDS (ONE SECTOR + 1 WORD) STARTING AT
3073                ;SECTOR 0 THRU SECTOR 37 AND VERIFY THAT THE RLDA DOES
3074                ;A DOUBLE INCREMENT EACH TIME.
3075 017760          STARS
                    ;*****
3076
3077 017760 004737 015764      JSR    PC,MDHOME      ;HEADS OVER TRACK 0
3078 017764                CKERFG                    ;HEADS GO HOME OKAY
                    TRAP    C#EXIT
                    .WORD   L10042-.
3079
3080 017776 005037 002272      CLR    TMP0          ;CLEAR TEMP LOCATIONS
3081 020002 005037 002274      CLR    TMP1
3082
3083 020006                BGNSEG                    ;##START OF SEGMENT##
                    TRAP    C#BSEG
3084
3085 020010 013737 002274 002300 1#:  MOV    TMP1,GDDAT      ;GET CYLINDER
3086 020016 053737 002272 002300      BIS    TMP0,GDDAT      ;GET SECTOR
3087 020024 013777 002300 162326      MOV    GDDAT,BRLDA     ;SET DISK ADDRESS-SECTOR 0
3088 020032 062737 000002 002300      ADD    #2,GDDAT        ;SET EXPECTED + 2
3089 020040 012777 003426 162310      MOV    #BUF,BRLBA     ;SET BUS ADDRESS
3090 020046 012777 177577 162306      MOV    #-129.,BRLMP   ;WORD COUNT-SECTOR+1 WORD
3091
3092 020054 004537 015054      JSR    R5,LDFUNC      ;LOAD THE FUNCTION IN NEXT WORD
3093 020060 000012                WRITE
3094 020062 004537 015700      JSR    R5,WTCRDY     ;WAIT FOR CONTROLLER READY?
3095 020066                ESCAPE SEG
                    TRAP    C#ESCAPE
                    .WORD   10000#-.
                    ;CHECK FOR FL:LOE, ELSE EXIT SEG
3096
3097 020072 004537 014612      JSR    R5,CHERR      ;CHECK CNTLR FOR ERRORS
3098 020076                ESCAPE SEG
                    TRAP    C#ESCAPE
                    .WORD   10000#-.
                    ;CHECK FOR FL:LOE, ELSE EXIT SEG
3099
3100 020102 013737 002344 002302      MOV    E.DA,BDDAT     ;READ DISK ADDRESS
3101 020110 023737 002302 002300      CMP    BDDAT,GDDAT    ;IS DISK ADDRESS CORRECT
3102 020116 001404                BEQ
                    ;YES, BRANCH NO, REPORT ERROR
3103
3104 020120                ERRDF
                    TRAP    7.,EM22,ERR4
                    .WORD   C#ERDF
                    .WORD   7
                    .WORD   EM22
                    .WORD   ERR4
                    ;DISK ADDRESS NOT CORRECT
3105
3106 020130                2#:
3107
3108 020130 005237 002272                INC    TMP0          ;NEXT SECTOR
3109 020134 022737 000046 002272      CMP    #46,TMP0      ;AT END?
3110 020142 001322                BNE    1#           ;NO, GO BACK
3111

```


TEST 8 - MULTIPLE SECTOR TRANSFER ON WRITE

```

3112 020144          ENDSEG          ;##END OF SEGMENT##
      020144          10000# : TRAP    C#ESEG
3113 020144 104405  ENDTST          ;**END OF TEST**
      020146          L10042: TRAP    C#ETST
      020146 104401
3114
3115      .SBTTL  ***TEST 9*** - CHECK DIRECTION OF WRITE NPR
3116
3117 020150  BGNTST          ;**START OF TEST**
3118
3119 020150  STARS
      ;*****
3120      ;VERIFY THAT A WRITE IS WRITING NOT READING. WE WRITE A
3121      ;KNOWN PATTERN IN "BUF" (128 WORD), WE THEN ISSUE A WRITE.
3122      ;ONCE THE WRITE IS FINISHED WE CHECK THAT "BUF" IS INTACT.
3123      ;THIS IS DONE TO PROVE THAT THE NPR IS GOING THE RIGHT
3124      ;WAY.
3125 020150  STARS
      ;*****
3126
3127 020150 004737 015764 JSR    PC,HDHOME      ;HEADS OVER TRACK 0
3128 020154  CKERFG          ;HEADS GO HOME OKAY
      020162 104432 TRAP    C#EXIT
      020164 000160 .WORD  L10043-.
3129
3130 020166  BGNSEG          ;##START OF SEGMENT##
      020166 104404 TRAP    C#BSEG
3131
3132 020170 2# :
3133 020170 012702 003426 MOV    #BUF,R2        ;WRITE BUFFER FOR WRITE OPERATION
3134 020174 012701 000200 MOV    #128.,R1       ;ONE SECTOR'S WORTH
3135 020200 012722 125252 3# : MOV    #125252,(R2)+  ;WRITE BUFFER
3136 020204 005301 DEC    R1             ;DONE?
3137 020206 001374 BNE    3#             ;NO, GO BACK
3138
3139 020210 005077 162144 CLR    @RLDA          ;LOAD DISK ADDRESS
3140 020214 012777 177600 162140 MOV    #-128.,@RLMP  ;WORD COUNT
3141 020222 012777 003426 162126 MOV    @BUF,@RLBA   ;BUS ADDRESS
3142 020230 004537 015054 JSR    R5,LDFUNC     ;LOAD THE FUNCTION IN NEXT WORD
3143 020234 000012 WRITE          ;WRITE SOME DATA
3144 020236 004537 015700 JSR    R5,WTCRDY     ;WAIT FOR IT TO FINISH
3145 020242 ESCAPE SEG    ;CHECK FOR FL:LOE, ELSE EXIT SEG
      020242 104410 TRAP    C#ESCAPE
      020244 000076 .WORD  10000#-.
3146
3147 020246 004537 014612 JSR    R5,CHERR      ;CHECK CNTLR FOR ERRORS
3148 020252 ESCAPE SEG    ;CHECK FOR FL:LOE, ELSE EXIT SEG
      020252 104410 TRAP    C#ESCAPE
      020254 000066 .WORD  10000#-.
3149
3150 020256 012702 003426 MOV    #BUF,R2        ;SET UP TO CHECK BUFFER
3151 020262 012701 000200 MOV    #128.,R1       ;CHECK 128 WORDS
3152
3153 020266  BGNSEG          ;##START OF SEGMENT##
      020266 104404 TRAP    C#BSEG
3154

```

TEST 9 - CHECK DIRECTION OF WRITE NPR

```

3155 020270 012737 125252 002300      MOV      #125252,GDDAT      ;DATA SHOULD BE 125252
3156 020276 011237 002302      MOV      (R2),BDDAT        ;LOAD DATA INTO BDDAT
3157 020302 023737 002300 002302 4#:  CMP      GDDAT,BDDAT      ;IS IT OKAY?
3158 020310 001406      BEQ      5#                ;YES, CONTINUE
3159
3160 020312 010237 002274      MOV      R2,TMP1          ;LOAD MEMORY LOCATION OF FAILURE
3161 020316      ERRDF  8.,EM26,ERR8
      TRAP  C#ERRDF
      .WORD 8
      .WORD EM26
      .WORD ERR8
3162
3163 020326      5#:  ESCAPE  SEG          ;CHECK FOR FL:LOE, ELSE EXIT SEG
      TRAP  C#ESCAPE
      .WORD 10001#-.
3164 020332 005722      6#:  TST    (R2)+        ;NEXT!
3165 020334 005301      DEC    R1                ;DONE?
3166 020336 001357      BNE    4#                ;NO, GO BACK
3167
3168 020340      ENDSEG                    ;##END OF SEGMENT##
      10001#: TRAP  C#ESEG
3169 020342 104405      ENDSEG                    ;##END OF SEGMENT##
      10000#: TRAP  C#ESEG
3170 020344 104405      ENDTST                    ;**END OF TEST**
      L10043: TRAP  C#ETST

```

.SBTTL ***TEST 10*** - CHECK FULL RLBA INCREMENT

```

3171
3172      BGNST                    ;**START OF TEST**
3173
3174 020346
3175
3176 020346
3177      STARS
3178      ;*****
3179      ;TEST THAT THE RLBA WILL INCREMENT, WE DO NOT DO A FULL 16
3180      ;BIT INCREMENT WE CHECK THAT EACH BIT WILL TOGGLE 0 TO 1
3181      ;AND 1 TO 0. WE DO CHECK ALL BITS EVEN IF ALL MEMORY
3182      ;IS NOT AVAILABLE. (WE IGNORE NON-EXISTANT MEMORY ERRORS).
3183      ;WE USE THE SAME DISK ADDRESS (RANDOM) AND A 1 WORD TRANSFER.
3184      STARS
3185      ;*****
3186      JSR    PC,HOMHOME      ;HEADS OVER TRACK 0
3187      CKERFG
3188      TRAP  C#EXIT          ;HEADS GO HOME OKAY
3189      .WORD  L10044-.
3190
3191 020364 005037 002274      CLR    TMP1              ;CLEAR LOCATION
3192
3193 020370      BGNSEG                    ;##START OF SEGMENT##
3194 020370 104404      TRAP  C#BSEG
3195
3196 020372      3#:  MOV    #-1,BRLMP      ;ONLY ONE (1) WORD
3197 020372 012777 177777 161762  CLR    BRLDA            ;LOAD DISK ADDRESS
3198 020400 005077 161754      MOV    TMP1,BRLBA       ;BUS ADDRESS
3199 020404 013777 002274 161744

```

***TEST 10** - CHECK FULL RLBA INCREMENT

```

3195
3196 020412 004537 015054      JSR      R5,LDFUNC          ;LOAD THE FUNCTION IN NEXT WORD
3197 020416 000012              WRITE
3198 020420 004537 015700      JSR      R5,WTCRDY        ;WAIT FOR WRITE TO FINISH
3199 020424              ESCAPE SEG          ;CHECK FOR FL:LOE, ELSE EXIT SEG
      020424 104410          TRAP      C#ESCAPE
      020426 000066          .WORD    10000#-.

3200
3201 020430 013737 002274 002300 4# :  MOV      TMP1,GDDAT        ;SET UP EXPECTED RLBA
3202 020436 062737 000002 002300      ADD      #2,GDDAT         ;PREVIOUS RLBA+2
3203 020444 013737 002342 002302      MOV      E.BA,BDDAT      ;READ RLBA
3204 020452 023737 002300 002302      CMP      GDDAT,BDDAT     ;WAS IT UPDATED PROPERLY?
3205 020460 001404          BEQ      5#              ;YES, CONTINUE
3206
3207 020462              ERRDF  9.,EM30,ERR4      ;BA INCREMENT ERROR
      020462 104455          TRAP      C#ERDF
      020464 000011          .WORD    9
      020466 006005          .WORD    EM30
      020470 007654          .WORD    ERR4
3208 020472              5# :  ESCAPE SEG          ;CHECK FOR FL:LOE, ELSE EXIT SEG
      020472 104410          TRAP      C#ESCAPE
      020474 000020          .WORD    10000#-.

3209
3210 020476 006337 002274          ASL      TMP1              ;NEXT PATTERN TO TEST RLBA
3211 020502 103404          BCS      6#              ;DONE?
3212 020504 052737 000002 002274      BIS      #BIT1,TMP1       ;NO, SET IN BIT 1
3213 020512 000727          BR       3#              ;GO CHECK NEXT.
3214
3215 020514              6# :  ;END TEST
3216
3217 020514          ENDSEG          ;##END OF SEGMENT##
      10000# :
      020514 104405          TRAP      C#ESEG
3218 020516          ENDTST          ;**END OF TEST**
      020516 L10044 :
      020516 104401          TRAP      C#ETST

3219
3220          .SBTTL  ***TEST 11** - BA BIT 16 INCREMENT
3221
3222 020520          BGNTST          ;**START OF TEST**
3223
3224 020520          STARS
      ;*****
      ;CHECK THAT BA BIT 16 WILL INCREMENT. WE WILL LOAD THE
      ;RLBA WITH 177776 AND ISSUE A ONE WORD WRITE WE THEN
      ;CHECK BA BIT 16 TO SET, BA 17 TO STAY A 0 AND THE RLBA
      ;TO GO TO ZERO
      ;*****
      STARS
      ;*****
3230
3231 020520 004737 015764          JSR      PC,HDRHOME       ;HEADS OVER TRACK 0
3232 020524              CKERFG          ;HEADS GO HOME OKAY
      020532 104432          TRAP      C#EXIT
      020534 000160          .WORD    L10045-.

3233
3234 020536              BGNSEG          ;##START OF SEGMENT##
      020536 104404          TRAP      C#BSEG
    
```


TEST 11 - BA BIT 16 INCREMENT

```

3235
3236 020540          24:
3237 020540 012777 177776 161610  MOV    #177776,BRLBA ;SET MAX BA TO INC. BA16
3238 020546 005037 002374          CLR    XMEM          ;WE DON'T WANT TO LOAD ANY EA
3239 020552 012777 177777 161602  MOV    #-1,BRLMP    ;ONE WORD TRANSFER
3240 020560 005077 161574          CLR    BRLDA
3241 020564 004537 015054          JSR    R5,LDFUNC    ;LOAD THE FUNCTION IN NEXT WORD
3242 020570 000012          WRITE
3243 020572 004537 015700          JSR    R5,WTCRDY    ;WAIT FOR WRITE TO FINISH
3244 020576          ESCAPE SEG ;CHECK FOR FL:LOE, ELSE EXIT SEG
      020576 104410          TRAP   C#ESCAPE
      020600 000112          .WORD 10000#-
3245 020602 032737 020000 002340  BIT    #NXM,E.CS    ;NON-EXISTANT MEMORY ERROR?
3246 020610 001002          BNE    3#           ;YES, CONTINUE
3247
3248 020612 004537 014612          JSR    R5,CHERR    ;CHECK CNTLR FOR ERRORS
3249 020616          3#:  ESCAPE SEG ;CHECK FOR FL:LOE, ELSE EXIT SEG
      020616 104410          TRAP   C#ESCAPE
      020620 000072          .WORD 10000#-
3250
3251 020622 032737 000020 002340  BIT    #BA16,E.CS   ;DID BA16 SET?
3252 020630 001004          BNE    4#           ;YES, CONTINUE
3253
3254 020632          ERRDF 10.,EM31,ERRO ;BA 16 DID NOT INCREMENT
      020632 104455          TRAP   C#ERDF
      020634 000012          .WORD 10
      020636 006040          .WORD EM31
      020640 007510          .WORD ERRO
3255
3256 020642          4#:  CKLOOP
      020642 104406          TRAP   C#CLP1
3257
3258 020644 032737 000040 002340  BIT    #BA17,E.CS   ;DID BA17 SET ALSO?
3259 020652 001404          BEQ    5#           ;NO, GOOD CONTINUE
3260
3261 020654          ERRDF 11.,EM32,ERRO ;BA 17 GOT CARRIED AWAY
      020654 104455          TRAP   C#ERDF
      020656 000013          .WORD 11
      020660 006076          .WORD EM32
      020662 007510          .WORD ERRO
3262
3263 020664          5#:  CKLOOP
      020664 104406          TRAP   C#CLP1
3264
3265 020666 005037 002300          CLR    GDDAT        ;CHECK THAT BA15-BA0 IS CLEAR
3266 020672 013737 002342 002302  MOV    E.BA,BDDAT  ;READ BA
3267 020700 001404          BEQ    6#           ;IS BA ZERO?
3268 020702          ERRDF 12.,EM33,ERR4 ;BA SHOULD BE ZERO
      020702 104455          TRAP   C#ERDF
      020704 000014          .WORD 12
      020706 006135          .WORD EM33
      020710 007654          .WORD ERR4
3269
3270 020712          6#:
3271
3272 020712          10000#:  ENDSEG ;##END OF SEGMENT##
      020712

```

***TEST 11** - BA BIT 16 INCREMENT

3273 020712 104405
 020714
 020714
 3274 020714 104401

TRAP C#ESEG ;**END OF TEST**
 ENDTST
 L10045:
 TRAP C#ETST

3275
 3276
 3277 020716
 3278
 3279 020716

.SBTTL ***TEST 12** - BA BIT 17 INCREMENT
 BGNTST ;**START OF TEST**

3280
 3281
 3282
 3283
 3284 020716

STARS
 ;*****
 ;CHECK THAT BA BIT 17 WILL INCREMENT. WE WILL LOAD THE
 ;RLBA WITH 177776 AND BA 16 SET, WE WILLISSUE A ONE WORD
 ;WRITE. WE THEN CHECK BA17 TO SET, BA16 TO CLEAR AND
 ;BA15 - BAO TO CLEAR.
 STARS
 ;*****

3285
 3286 020716 004737 015764
 3287 020722
 020730 104432
 020732 000162

JSR PC,HDHOME ;HEADS OVER TRACK 0
 CKERFG ;HEADS GO HOME OKAY
 TRAP C#EXIT
 .WORD L10046-.

3288
 3289 020734
 020734 104404

BGNSEG ;**START OF SEGMENT**
 TRAP C#BSEG

3290
 3291 020736
 3292 020736 012777 177776 161412
 3293 020744 012737 000020 002374
 3294 020752 012777 177777 161402
 3295 020760 005077 161374
 3296 020764 004537 015054
 3297 020770 000012
 3298 020772 004537 015700
 3299 020776

2#:
 MOV #177776,BRLBA ;SET MAX BA TO INC. BA16
 MOV #BA16,XMEM ;SET BA16 IN RLCS
 MOV #-1,BRLMP ;ONE WORD TRANSFER
 CLR BRLDA
 JSR R5,LDFUNC ;LOAD THE FUNCTION IN NEXT WORD
 WRITE
 JSR R5,WTCRDY ;WAIT FOR WRITE TO FINISH
 ESCAPE SEG ;CHECK FOR FL:LOE, ELSE EXIT SEG
 TRAP C#ESCAPE
 .WORD 10000#-.
 BIT #NXM,E.CS ;NON-EXISTANT MEMORY ERROR?
 BNE 3# ;YES, CONTINUE

3300 021002 032737 020000 002340
 3301 021010 001002
 3302
 3303 021012 004537 014612
 3304 021016
 021016 104410
 021020 000072

3#:
 JSR R5,CHERR ;CHECK CNTLR FOR ERRORS
 ESCAPE SEG ;CHECK FOR FL:LOE, ELSE EXIT SEG
 TRAP C#ESCAPE
 .WORD 10000#-.

3305
 3306 021022 032737 000040 002340
 3307 021030 001004
 3308

BIT #BA17,E.CS ;DID BA17 SET?
 BNE 4# ;YES, CONTINUE

3309 021032
 021032 104455
 021034 000015
 021036 006171
 021040 007510

ERRDF 13.,EM34,ERRO ;BA 17 DID NOT SET
 TRAP C#ERDF
 .WORD 13
 .WORD EM34
 .WORD ERRO

3310
 3311 021042
 021042 104406
 3312

4#:
 CKLOOP
 TRAP C#CLP1

TEST 12 - BA BIT 17 INCREMENT

```

3313 021044 032737 000020 002340      BIT      @BA16,E.CS      ;DID BA16 SET ALSO?
3314 021052 001404                      BEQ      5$             ;NO, GOOD CONTINUE
3315
3316 021054                      ERRDF    14.,EM35,ERRO  ;BA 16 DIDN'T KNOW WHEN TO QUIT.
      021054 104455      TRAP    C$ERDF
      021056 000016      .WORD  14
      021060 006227      .WORD  EM35
      021062 007510      .WORD  ERRO
3317 021064                      5$:    CKLOOP
      021064 104406      TRAP    C$CLP1
3318
3319 021066 005037 002300              CLR      GDDAT          ;CHECK THAT BA15-BA0 IS CLEAR
3320 021072 013737 002342 002302      MOV     E.BA,BDDAT     ;READ BA
3321 021100 001404                      BEQ      6$             ;IS BA ZERO?
3322 021102                      ERRDF    15.,EM36,ERR4  ;BA SHOULD BE ZERO
      021102 104455      TRAP    C$ERDF
      021104 000017      .WORD  15
      021106 006265      .WORD  EM36
      021110 007654      .WORD  ERR4
3323
3324 021112                      6$:
3325
3326 021112                      ENDSEG                    ;##END OF SEGMENT##
      021112 104405      10000$: TRAP    C$ESEG
3327 021114                      ENDTST                    ;**END OF TEST**
      021114 104401      L10046: TRAP    C$ETST
3328
3329      .SBTTL  **TEST 13** - READ FUNCTION
3330
3331 021116                      BGNTST                    ;**START OF TEST**
3332
3333 021116                      STARS
      ;*****
      ;CHECK OF THE READ FUNCTION. WE WILL FIRST DO A READ
      ;HEADER TO FIND OUT WHERE WE ARE AND THEN ISSUE
      ;A FULL SECTOR READ, WAIT FOR READY AND CHECK FOR
      ;ANY ERRORS
      STARS
      ;*****
3334
3335
3336
3337
3338 021116
3339
3340 021116 004737 015764              JSR     PC,HDHOME      ;HEADS OVER TRACK 0
3341 021122                      CKERFG                    ;HEADS GO HOME OKAY
      021130 104432      TRAP    C$EXIT
      021132 000064      .WORD  L10047-.
3342
3343 021134                      BGNSEG                    ;##START OF SEGMENT##
      021134 104404      TRAP    C$BSEG
3344
3345 021136 012737 001750 002272      MOV     @1000.,TMPO
3346 021144 005077 161210 161210      1$:    CLR     @RLDA      ;LOAD DISK ADDRESS
3347 021150 012777 177600 161204      MOV     @-128.,@RLMP   ;SET WORD LENGTH
3348 021156 012777 003426 161172      MOV     @BUF,@RLBA     ;SET BUS ADDRESS
3349
3350 021164 004537 015054              JSR     R5,LDFUNC      ;LOAD THE FUNCTION IN NEXT WORD
3351 021170 000014                      READ

```


***TEST 13** - READ FUNCTION

```

3352 021172 004537 015700      JSR    R5,WTCRDY      ;WAIT FOR CONTROLLER READY
3353 021176                ESCAPE  SEG           ;CHECK FOR FL:LOE, ELSE EXIT SEG
      021176 104410        TRAP    C#ESCAPE
      021200 000014        .WORD  10000$-.
3354
3355 021202 004537 014612      JSR    R5,CHERR       ;CHECK CNTLR FOR ERRORS
3356
3357 021206 005337 002272      DEC    TMO           ;
3358 021212 001354        BNE    1$
3359 021214                ENDSEG                ;##END OF SEGMENT##
      021214 104405        TRAP    C#ESEG
      021214 104401        TRAP    C#ETST
3360 021216                ENDTST
      021216 104401        L10047:

```

.SBTTL ***TEST 14** - READ FUNCTION INTERRUPT

```

3361
3362
3363
3364 021220      BGNTST                ;**START OF TEST**
3365
3366 021220      STARS
3367
3368
3369
3370
3371 021220      ;*****
;CHECK OF THE READ FUNCTION UNDER INTERRUPT CONTROL, WE WILL
;ISSUE A READ HEADER TO GET POSITION AND THEN READ
;A FULL SECTOR WAITING FOR THE INTERRUPT. CHECK FOR
;ERRORS ON INTERRUPT.
STARS
;*****

```

```

3372
3373 021220 004737 015764      JSR    PC,MDHOME     ;HEADS OVER TRACK 0
3374 021224                CKERFG                ;HEADS GO HOME OKAY
      021232 104432        TRAP    C#EXIT
      021234 000106        .WORD  L10050-.
3375
3376 021236                BGNSEG                ;##START OF SEGMENT##
      021236 104404        TRAP    C#BSEG
3377
3378 021240 005037 002256      CLR    INTFLG        ;CLEAR INTERRUPT INDICATOR
3379 021244 005077 161110      CLR    @RLDA         ;SET DISK ADDRESS
3380 021250 012777 177600 161104  MOV    #-128,@RLMP   ;SET UP WORD COUNT
3381 021256 012777 003426 161072  MOV    @BUF,@RLBA    ;SET UP BUS ADDRESS
3382
3383 021264                SETPRI  #PRI00        ;PRIORITY TO 0
      021264 012700 000000  MOV    #PRI00,R0
      021270 104441        TRAP    C#SPRI
3384 021272 004537 015054      JSR    R5,LDFUNC     ;LOAD THE FUNCTION IN NEXT WORD
3385 021276 000114        READ!INTEN          ;READ UNDER INTERRUPT
3386 021300 004537 015700      JSR    R5,WTCRDY     ;WAIT FOR INTERRUPT
3387 021304                CKLOOP
      021304 104406        TRAP    C#CLP1
3388
3389 021306                SETPRI  #PRI07        ;PRIORITY TO 7
      021306 012700 000300  SETPRI  #PRI06        ;PRIORITY TO 6
      021312 104441        MOV    #PRI06,R0
      021312 104441        TRAP    C#SPRI
3390
3391 021314 005737 002256      TST    INTFLG        ;DID INTERRUPT OCCUR?
3392 021320 001004        BNE    1$           ;YES-BRANCH NO-REPORT

```

;JSD REV A
;JSD REV A

TEST 14 - READ FUNCTION INTERRUPT

```

3393
3394 021322          ERRDF  19.,EM4,ERRO  ;READ DID NOT INTERRUPT
      021322 104455  TRAP    C#ERDF
      021324 000023  .WORD  19
      021326 004712  .WORD  EM4
      021330 007510  .WORD  ERRO
3395 021332          1$:  CKLOOP          ;CHECK FOR LOOP
      021332 104406  TRAP    C#CLP1
3396
3397 021334 004537 014612 JSR    R5,CHERR          ;CHECK CNTLR FOR ERRORS
3398
3399          ENDSEG          ;##END OF SEGMENT##
      021340          10000$:
      021340 104405  TRAP    C#ESEG
3400 021342          ENDTST          ;**END OF TEST**
      021342          L10050:
      021342 104401  TRAP    C#ETST
3401
3402          .SBTTL  **TEST 15** - CHECK READ NPR DIRECTION
3403
3404 021344          BGNTST          ;**START OF TEST**
3405
3406 021344          STARS
      ;*****
      ;CHECK THAT THE READ FUNCTION ACTUALLY READS (INTO MEMORY)
      ;WE WILL WRITE A PATTERN INTO MEMORY AND THEN ISSUE
      ;A READ TO OVERLAY THAT PATTERN. AFTER THE READ
      ;WE CHECK TO SEE IF THE WRITTEN PATTERN HAS CHANGED.
      ;IF NOT WE ISSUE IT AGAIN AT THE SAME SECTION AFTER
      ;HAVING MODIFIED OUR PATTERN IN MEMORY (SINCE THERE IS
      ;ONE CHANCE THAT THE DISK COULD HAVE OUR PATTERN). AFTER
      ;THE SECOND READ WE CHECK THE BUFFER AGAIN. IF IT'S
      ;NO CHANGED WF REPORT AN ERROR
      STARS
      ;*****
3417
3418 021344 004737 015764 JSR    PC,HDHOME        ;HEADS OVER TRACK 0
3419 021350          CKERFG          ;HEADS GO HOME OKAY
      021356 104432  TRAP    C#EXIT
      021360 000156  .WORD  L10051-.
3420
3421 021362          BGNSEG          ;##START OF SEGMENT##
      021362 104404  TRAP    C#BSEG
3422
3423 021364 012737 123456 002272 MOV    #123456,TMP0     ;SET PATTERN TO WRITE
3424 021372 005037 002274 CLR    TMP1             ;CLEAR PASS INDICATOR
3425 021376 012700 003426 1$:  MOV    #BUF,R0             ;SET UP BUFFER BEGINNING
3426 021402 012701 000200 MOV    #128.,R1
3427 021406 013720 002272 2$:  MOV    TMP0,(R0)+         ;WRITE BUFFER
3428 021412 005301 DEC    R1                 ;DONE??
3429 021414 001374 BNE    2$                 ;NO, GO BACK
3430 021416 005077 160736 CLR    @RLDA             ;LOAD DISK ADDRESS
3431 021422 012777 177600 160732 MOV    #-128.,@RLMP    ;SET WORD COUNT
3432 021430 012777 003426 160720 MOV    #BUF,@RLBA     ;LOAD BUS ADDRESS
3433 021436 012737 003426 002300 MOV    #BUF,GDDAT     ;FOR ERROR PRINT
3434
3435 021444 004537 015054 JSR    R5,LDFUNC        ;LOAD THE FUNCTION IN NEXT WORD

```

••TEST 15•• - CHECK READ NPR DIRECTION

```

3436 021450 000014          READ
3437 021452 004537 015700 JSR    R5,WTCRDY      ;READ
3438 021456          ESCAPE SEG      ;WAIT FOR CONTROLLER READY
      021456 104410 TRAP  C#ESCAPE ;CHECK FOR FL:LOE, ELSE EXIT SEG
      021460 000054 .WORD 10000#-.

3439
3440 021462 004537 014612 JSR    R5,CHERR      ;CHECK CNTLR FOR ERRORS
3441 021466          ESCAPE SEG      ;CHECK FOR FL:LOE, ELSE EXIT SEG
      021466 104410 TRAP  C#ESCAPE
      021470 000044 .WORD 10000#-.

3442
3443 021472 012702 003426 4# : MOV    #BUF,R2      ;SET TO START COMPARING DATA
3444 021476 022237 002272 CMP    (R2)+,TMP0    ;DID DATA CHANGE?
3445 021502 001014 BNE    6#           ;YES, CHECK FOR END
3446
3447
3448
3449 021504 005737 002274 TST    TMP1          ;DATA DIDN'T CHANGE, CHECK
3450 021510 001005 BNE    5#           ;IF 1ST OR 2ND TIME?
3451                                     ;2ND-REPORT 1ST-TRY AGAIN
3452 021512 005237 002274 INC    TMP1          ;INC PASS COUNT
3453 021516 005137 002272 COM    TMP0          ;COMPLIMENT PATTERN
3454 021522 000725 BR     1#           ;GO DO IT AGAIN
3455
3456 021524          5# : ERRDF 20,EMS,ERR9 ;READ DID NOT MODIFY MEMORY
      021524 104455 TRAP  C#ERDF
      021526 000024 .WORD 20
      021530 004735 .WORD EMS
      021532 010102 .WORD ERR9

3457
3458 021534          6# :
3459
3460 021534          ENDSEG          ;##END OF SEGMENT##
      021534          10000# : TRAP  C#ESEG
      021534 104405
3461 021536          ENDTST          ;••END OF TEST••
      021536          L10051 : TRAP  C#ETST
      021536 104401

3462
3463 .SBTTL ••TEST 16•• - PROPER INCREMENT OF RLBA ON READ
3464
3465 021540          BGNTST          ;••START OF TEST••
3466
3467 021540          STARS
      ;*****
      ;CHECK THAT THE RLBA WILL INCREMENT WITH THE READ
      ;THE RLBA SHOULD CONTAIN "BUF +256." AFTER A FULL SECTOR
      ;READ.
      ;*****
3468
3469
3470
3471 021540          JSR    PC,HOMOME ;HEADS OVER TRACK 0
3472                                     ;HEADS GO HOME OKAY
3473 021540 004737 015764 CKERFG
3474 021544          TRAP  C#EXIT
      021552 104432 .WORD L10052-.
      021554 000116

3475
3476 021556          BGNSEG          ;##START OF SEGMENT##

```


••TEST 16•• - PROPER INCREMENT OF RLBA ON READ

```

021556 104404 TRAP C#BSEG
3477
3478 021560 005077 160574 CLR BRLDA ;SET UP DISK ADDRESS
3479 021564 012777 003426 160564 MOV #BUF,BRLBA ;SET UP BUS ADDRESS
3480 021572 012777 177600 160562 MOV #-128.,BRLMP ;WORD COUNT
3481 021600 012737 003426 002300 MOV #BUF,GDDAT ;FORM EXPECTED BUS ADDRESS
3482 021606 062737 000400 002300 ADD #256.,GDDAT ;AFTER READ
3483
3484 021614 004537 015054 JSR R5,LDFUNC ;LOAD THE FUNCTION IN NEXT WORD
3485 021620 000014 READ ;READ
3486 021622 004537 015700 JSR R5,WTCRDY ;WAIT FOR CONTROLLER READY
3487 021626 ESCAPE SEG ;CHECK FOR FL:LOE, ELSE EXIT SEG
021626 104410 TRAP C#ESCAPE
021630 000040 .WORD 10000#-.
3488
3489 021632 004537 014612 JSR R5,CHERR ;CHECK CNTLR FOR ERRORS
3490 021636 ESCAPE SEG ;CHECK FOR FL:LOE, ELSE EXIT SEG
021636 104410 TRAP C#ESCAPE
021640 000030 .WORD 10000#-.
3491 021642 013737 002342 002302 MOV E.BA,BDDAT ;READ 'RLBA' FOR PRESENT ADDRESS
3492 021650 023737 002302 002300 CMP BDDAT,GDDAT ;DID 'BA' INCREMENT PROPERLY?
3493 021656 001404 BEQ 1# ;YES, CONTINUE
3494
3495 021660 ERRDF 21.,EM6,ERR4 ;BA DID NOT INCREMENT PROPERLY
021660 104455 TRAP C#ERDF
021662 000025 .WORD 21
021664 004763 .WORD EM6
021666 007654 .WORD ERR4
3496
3497 021670 1#:
3498
3499 021670 ENDSEG ;##END OF SEGMENT##
021670 10000#: TRAP C#ESEG
021670 104405
3500 021672 ENDTST ;••END OF TEST••
021672 L10052: TRAP C#ETST
021672 104401
3501
3502 .SBTTL ••TEST 17•• - PROPER INCREMENT OF RLDA ON READ
3503
3504 021674 BGNTST ;••START OF TEST••
3505
3506 021674 STARS
;*****
;CHECK THAT THE RLDA INCREMENTS BY ONE AFTER A
;FULL SECTOR READ, WE FIRST READ A HEADER TO FIND
;OUT WHERE WE ARE, THEN ISSUE A READ AFTER
;THE READ THE RLDA SHOULD BE RLDA (START) + 1
;*****
3507
3508
3509
3510
3511 021674 STARS
;*****
3512
3513 021674 004737 015764 JSR PC,HOMHOME ;HEADS OVER TRACK 0
3514 021700 CKERFG ;HEADS GO HOME OKAY
021706 104432 TRAP C#EXIT
021710 000114 .WORD L10053-.
3515
3516 021712 BGNSEG ;##START OF SEGMENT##

```

••TEST 17•• - PROPER INCREMENT OF RLDA ON READ

```

021712 104404 TRAP C#BSEG
3517
3518 021714 005037 002300 CLR GDDAT
3519 021720 013777 002300 160432 MOV GDDAT,#RLDA ;SETUP DISK ADDRESS
3520 021726 005237 002300 INC GDDAT ;CREATE EXPECTED SECTOR
3521 021732 012777 177600 160422 MOV #128.,#RLMP ;WORD COUNT
3522 021740 012777 003426 160410 MOV #BUF,#RLBA ;SETUP BUS ADDRESS
3523
3524 021746 004537 015054 JSR R5,LDFUNC ;LOAD THE FUNCTION IN NEXT WORD
3525 021752 000014 READ ;READ
3526 021754 004537 015700 JSR R5,WTCRDY ;WAIT FOR CONTROLLER READY
3527 021760 ESCAPE SEG ;CHECK FOR FL:LOE, ELSE EXIT SEG
021760 104410 TRAP C#ESCAPE
021762 000040 .WORD 10000#-.
3528
3529 021764 004537 014612 JSR R5,CHERR ;CHECK CNTLR FOR ERRORS
3530 021770 ESCAPE SEG ;CHECK FOR FL:LOE, ELSE EXIT SEG
021770 104410 TRAP C#ESCAPE
021772 000030 .WORD 10000#-.
3531
3532 021774 013737 002344 002302 MOV E.DA,BDDAT ;READ DISK ADDRESS
3533 022002 023737 002300 002302 CMP GDDAT,BDDAT ;DID SECTOR INCREMENT PROPERLY
3534 022010 001404 BEL 1# ;YES, BRANCH NO, REPORT ERROR
3535
3536 022012 ERRDF 22.,EM7,ERR4 ;DISK ADDRESS DID NOT INCREMENT
022012 104455 TRAP C#ERDF
022014 000026 .WORD 22
022016 005017 .WORD EM7
022020 007654 .WORD ERR4
3537
3538 022022 1# :
3539
3540 022022 ENDSEG ;##END OF SEGMENT##
022022 10000# :
022022 104405 TRAP C#ESEG
3541 022024 ENDTST ;••END OF TEST••
022024 L10053 :
022024 104401 TRAP C#ETST
3542
3543 .SBTTL ••TEST 18•• - FORCE HEADER NOT FOUND WITH READ
3544
3545 022026 BGNTST ;••START OF TEST••
3546
3547 022026 STARS
;*****
;FORCE HEADER NOT FOUND ERROR TO OCCUR. THIS IS DONE
;BY SETTING SECTOR 40 OF THE RLDA AND ISSUING A
;READ. SECTOR 40 DOES NOT EXIST ON THE RLO1 PACK
;THEREFORE HDR NT FOUND SHOULD SET.
STARS
;*****
3553
3554 022026 004737 015764 JSR PC,HDHOME ;HEADS OVER TRACK 0
3555 022032 CKERFG ;HEADS GO HOME OKAY
022040 104432 TRAP C#EXIT
022042 000102 .WORD L10054-.
3556

```

##TEST 18## - FORCE HEADER NOT FOUND WITH READ

```

3557 022044          BGNSEG          ;##START OF SEGMENT##
      022044 104404 TRAP          C#BSEG
3558
3559 022046 012777 000050 160304 MOV      #40.,@RLDA ;INSURE NOT TO FIND HEADER BY
3560 022054 012777 003426 160274 MOV      @BUF,@RLBA ;SETTING SECTOR 40 OF CYL. ADDR.
3561 022062 012777 177777 160272 MOV      #-1,@RLMP ;WORD COUNT
3562
3563 022070 004537 015054 JSR      R5,LDFUNC ;LOAD THE FUNCTION IN NEXT WORD
3564 022074 000014 READ          ;READ
3565 022076 004537 015700 JSR      R5,WTCRDY ;WAIT FOR CONTROLLER READY
3566 022102 ESCAPE SEG ;CHECK FOR FL:LOE, ELSE EXIT SEG
      022102 104410 TRAP          C#ESCAPE
      022104 000036 .WORD      10000#-.
3567
3568 022106 013737 002340 002272 MOV      E.CS,TMPO ;GET RLCS
3569 022114 042737 001777 002272 BIC      #1777,TMPO ;SAVE ERROR BITS
3570 022122 022737 112000 002272 CMP      @BIT15!BIT12!BIT10,TMPO ;HDR NOT FOUND SET.
3571 022130 001404 BEQ      1# ;YES, CONTINUE
3572
3573 022132 ERRDF 23.,EM10,ERRO ;HEADER NOT FOUND WOULD NOT SET
      022132 104455 TRAP          C#ERDF
      022134 000027 .WORD      23
      022136 005064 .WORD      EM10
      022140 007510 .WORD      ERRO
3574
3575 022142 1#:
3576 ;
3577
3578 022142          ENDSEG          ;##END OF SEGMENT##
      022142 10000#: TRAP          C#ESEG
3579 022144 104405 ENDTST          ;##END OF TEST##
      022144 L10054: TRAP          C#ETST
      022144 104401
3580
3581 .SBTTL ##TEST 19## - FORCE HEADER NOT FOUND WITH READ INTERRUPT
3582
3583 022146 BGNTST          ;##START OF TEST##
3584
3585 022146 STARS
      ;*****
      ;TEST THAT HEADER NOT FOUND ERROR WILL GENERATE AN INTERRUPT
      ;ON OCCURANCE. HEADER NOT FOUND WILL BE FORCED BY SETTING
      ;SECTOR 40 OF RLDA AND ISSUING A READ
      STARS
      ;*****
3586
3587
3588
3589 022146
3590
3591 022146 004737 015764 JSR      PC,HOMME ;HEADS OVER TRACK 0
3592 022152 CKERFG ;HEADS GO HOME OKAY
      022160 104432 TRAP          C#EXIT
      022162 000142 .WORD      L10055-.
3593
3594 022164          BGNSEG          ;##START OF SEGMENT##
      022164 104404 TRAP          C#BSEG
3595
3596 022166 SETPRI #PRI00
      022166 012700 000000 MOV      @PRI00,RO

```


***TEST 19** - FORCE HEADER NOT FOUND WITH READ INTERRUPT

```

3597 022172 104441 TRAP C#SPRI
3598 022174 005037 002256 CLR INTFLG ;CLEAR INTERRUPT OCCURANCE FLAG
3599 022200 012777 000050 160152 MOV #40.,@RLDA ;INSURE NOT TO FIND HEADER BY
3600 022206 012777 003426 160142 MOV #8UF,@RLBA ;SETTING SECTOR 40 OF CYL. ADDR.
3601 022214 012777 177777 160140 MOV # -1,@RLMP ;WORD COUNT
3602 022222 004537 015054 JSR R5,LDFUNC ;LOAD THE FUNCTION IN NEXT WORD
3603 022226 000114 READ!INTEN ;READ
3604 022230 004537 015700 JSR R5,WTCRDY ;WAIT FOR CONTROLLER READY
3605 022234 CKLOOP
3606 022234 104406 TRAP C#CLP1
3607 022236 SETPRI #PRI07 ;JSD REV A
022236 012700 000300 SETPRI #PRI06 ;JSD REV A
022242 104441 MOV #PRI06,R0
3608 TRAP C#SPRI
3609 022244 005737 002256 TST INTFLG ;DID INTERRUPT OCCUR
3610 022250 001004 BNE 2# ;YES
3611
3612 022252 ERRDF 24.,EM43,ERRO ;HNF DID NOT INTERRUPT
022252 104455 TRAP C#ERDF
022254 000030 .WORD 24
022256 006461 .WORD EM43
022260 007510 .WORD ERRO
3613
3614 022262 2# : ESCAPE SEG ;CHECK FOR FL:LOE, ELSE EXIT SEG
022262 104410 TRAP C#ESCAPE
022264 000036 .WORD 10000#-.
3615
3616 022266 013737 002340 002272 MOV E.CS,TMPO ;GET RLCS
3617 022274 042737 001777 002272 BIC #1777,TMPO ;SAVE ERROR BITS
3618 022302 022737 112000 002272 CMP #BIT15!BIT12!BIT10,TMPO ;WDR NOT FOUND SET.
3619 022310 001404 BEQ 1# ;YES, CONTINUE
3620
3621 022312 ERRDF 25.,EM10,ERRO
022312 104455 TRAP C#ERDF
022314 000031 .WORD 25
022316 005064 .WORD EM10
022320 007510 .WORD ERRO
3622 ;WHEN FORCED
3623 022322 1# :
3624
3625 022322 ENDSEG ;##END OF SEGMENT##
022322 10000# :
022322 104405 TRAP C#ESEG
3626 022324 ENDTST ;**END OF TEST**
022324 L10055 :
022324 104401 TRAP C#ETST
3627
3628 .SBTTL ***TEST 20** - CHECK HEADER COMPARE LOGIC
3629
3630 022326 BGNTST ;**START OF TEST**
3631
3632 022326 STARS
3633 ;*****
3634 ;CHECK THE HEADER COMPARE LOGIC WORKS. UP TO THIS POINT WE
;KNOW THAT THE LOGIC FUNCTIONS PROPERLY BUT NOW WE WILL

```

••TEST 20•• - CHECK HEADER COMPARE LOGIC

```

3635 ;CHECK ALL THE BITS IN THE HEADER WORD. FOUR PATTERNS
3636 ;ARE USED A WALKING 1, GROWING 1, WALKING 0, GROWING 0. A SEEK
3637 ;IS ISSUED BEFORE EACH READ TO INSURE WE ARE ON THE PROPER
3638 ;TRACK. ONCE WE ARE ON THE RIGHT TRACKWE LOAD THE RLDA
3639 ;AND ISSUE THE READ. UPON COMPLETION WE WILL CHECK FOR ERRORS
3640 ;WE THEN LOAD THE COMPLEMENT PATTERN INTO THE RLDA
3641 ;EXPECTING A HEADER NOT FOUND TO SET
3642 022326 STARS
;*****

3643
3644 022326 004737 015764 JSR PC,HDHOME ;HEADS OVER TRACK 0
3645 022332 CKERFG ;HEADS GO HOME OKAY
022340 104432 TRAP C#EXIT
022342 000574 .WORD L10056-.

3646
3647 022344 BGNSEG ;##START OF SEGMENT##
022344 104404 TRAP C#BSEG

3648
3649 ;
3650 022346 SETPRI #PRI07 ;PRIORITY TO 7 ;JSD REV A
022346 012700 000300 SETPRI #PRI06 ;PRIORITY TO 6 ;JSD REV A
022352 104441 MOV #PRI06,R0
3651 022354 022737 000001 002232 TRAP C#SPRI
3652 022362 001003 CMP #1,T.DRIVE ;CHECK TYPE OF DRIVE (RL01 OR RL02)
3653 022364 012703 002670 BNE 22# ;RL02? THEN BRANCH
3654 022370 000402 MOV #HRTAB,R3 ;MOV ADDRESS OF BEG PATTERN TO R3
3655 022372 012703 003050 BR 33# ; THEN BRANCH
3656 022376 22#: MOV #HTAB,R3 ;MOV ADDRESS OF BEG PATTERN TO R3
022376 104404 33#: BGNSEG ;START OF SEGMENT
TRAP C#BSEG

3657 022400 1#:
3658 022400 004537 015054 JSR R5,LDFUNC ;LOAD THE FUNCTION IN NEXT WORD
3659 022404 000010 RDHDR ;READ HEADER
3660 022406 004537 015700 JSR R5,WTCRDY ;WAIT FOR CONTROLLRE READY
3661 022412 ESCAPE SEG ;CHECK FOR FL:LOE, ELSE EXIT SEG
022412 104410 TRAP C#ESCAPE
022414 000516 .WORD 10001#-.

3662
3663 022416 004537 014612 JSR R5,CHERR ;CHECK CNTLR FOR ERRORS
3664 022422 ESCAPE SEG ;CHECK FOR FL:LOE, ELSE EXIT SEG
022422 104410 TRAP C#ESCAPE
022424 000506 .WORD 10001#-.

3665 022426 013737 002346 002274 MOV E.MP,TMP1 ;READ AND SAVE HEADER
3666
3667 022434 042737 000177 002274 BIC #177,TMP1 ;CLEAR OUT SECTOR AND H.S.
3668 022442 012777 000001 1577:0 MOV #1,BRLDA ;SETUP MARKER FOR SEEK
3669 022450 011337 002276 MOV (R3),TMP2 ;GET HEADER PATTERN
3670 022454 042737 000177 002276 BIC #177,TMP2 ;CLEAR OUT SECTOR AND H.S.
3671 022462 163737 002274 002276 SUB TMP1,TMP2 ;CALCULATE DIFFERENCE TO SEEK
3672 022470 103404 BCS 2# ;BRANCH FOR SEEK OUT
3673 022472 052777 000004 157660 BIS #SIGN,BRLDA ;SEEK TOWARDS SPINDLE
3674 022500 000402 BR 3# ;GO PUT IN DIFFERENCE WORD
3675 022502 005437 002276 2#: NEG TMP2 ;WE HAVE TO NEGATE DIFFERENCE
3676 022506 053777 002276 157644 3#: BIS TMP2,BRLDA ;SET IN DIFFERENCE WORD
3677 022514 032713 000100 BIT #RHMS,(R3) ;DO WE WANT HEAD SELECT AS 0?
3678 022520 001403 BEQ 4# ;YES, SKIP OVER SETTING H.S.
3679 022522 052777 000020 157630 BIS #DAHS,BRLDA ;SET HEAD SELECT TO ONE
3680 022530 004537 015054 4#: JSR R5,LDFUNC ;LOAD THE FUNCTION IN NEXT WORD

```


••TEST 20•• - CHECK HEADER COMPARE LOGIC

```

3720 022732 004537 014612      JSR      R5,CHERR          ;CHECK CNTLR FOR ERRORS
3721 022736                      ESCAPE   SEG              ;CHECK FOR FL:LOE, ELSE EXIT SEG
      022736 104410              TRAP     C#ESCAPE
      022740 000172              .WORD   10001#-.
3722
3723 022742 011377 157412      MOV      (R3),@RLDA        ;SET UP DISK ADDRESS AS
3724 022746 005177 157406      COM     @RLDA              ;COMPLIMENT TO CAUSE HDR NT FND
3725 022752 012777 177777 157402  MOV     #-1,@RLMP         ;WORD COUNT
3726 022760 012777 003426 157370  MOV     @BUF,@RLBA        ;BUS ADDRESS
3727
3728 022766 004537 015054      JSR      R5,LDFUNC         ;LOAD THE FUNCTION IN NEXT WORD
3729 022772 000014              READ     ;READ
3730 022774 004537 015700      JSR      R5,WTCRDY        ;WAIT FOR CONTROLLER READY
3731 023000                      ESCAPE   SEG              ;CHECK FOR FL:LOE, ELSE EXIT SEG
      023000 104410              TRAP     C#ESCAPE
      023002 000130              .WORD   10001#-.
3732 023004 013737 002340 002272  MOV     E.CS,TMPO         ;GET CS
3733 023012 042737 001777 002272  BIC     @1777,TMPO        ;SAVE ERROR BITS
3734 023020 022737 112000 002272  CMP     @BIT15!BIT12!BIT10,TMPO ;DID HEADER NOT FOUND SET
3735 023026 001402                      BEQ     8#                 ;YES, CONTINUE
3736 023030 004537 014612      JSR      R5,CHERR
3737 023034                      8#:    CKLOOP
      023034 104406              TRAP     C#CLP1
3738
3739 023036 022737 112000 002272  CMP     @BIT15!BIT12!BIT10,TMPO
3740 023044 001413                      BEQ     6#
3741
3742 023046 011337 002300          MOV     (R3),GDDAT        ;SET UP DATA FOR ERROR
3743 023052 013737 002300 002302  MOV     GDDAT,BDDAT      ;PRINT OUT
3744 023060 005137 002302          COM     BDDAT
3745
3746 023064                      ERRDF   28.,EM12,ERR4     ;HDR NOT FOUND WOULD NOT SET
      023064 104455              TRAP     C#ERDF
      023066 000034              .WORD   28
      023070 005144              .WORD   EM12
      023072 007654              .WORD   ERR4
3747
3748 023074                      6#:    ESCAPE   SEG              ;CHECK FOR FL:LOE, ELSE EXIT SEG
      023074 104410              TRAP     C#ESCAPE
      023076 000034              .WORD   10001#-.
3749
3750 023100 005723                      TST     (R3)+             ;GET NEXT PATTERN
3751 023102 022737 000001 002232  CMP     @1,T.DRIVE        ;TYPE OF DRIVE RL01 OR RL02
3752 023110 001003                      BNE     60#              ;RL02 ? THEN BRANCH
3753 023112 020327 003046          CMP     R3,@HDREND        ;CMP IT WITH @HDREND
3754 023116 000402                      BR      77#              ;THEN BRANCH
3755 023120 020327 003234 60#:    CMP     R3,@HEND          ;CMP IT WITH @HEND
3756 023124 001402 77#:    BEQ     7#                 ;YES,EXIT TEST
3757 023126 000137 022400          JMP     1#                 ;NO, GO BACK
3758
3759 023132                      7#:
3760 023132                      ENDSEG                    ;##END OF SEGMENT##
      023132 10001#:              TRAP     C#ESEG
      023132 104405
3761
3762 023134                      10000#: ENDSEG           ;##END OF SEGMENT##
      023134

```

***TEST 20** - CHECK HEADER COMPARE LOGIC

```

3763 023134 104405          TRAP      C#ESEG          ;**END OF TEST**
      023136          ENDTST
      023136          L10056:
      023136 104401          TRAP      C#ETST

3764
3765          .SBTTL  ***TEST 21** - CHECK MULTIPLE SECTORS ON READ
3766
3767 023140          BGNTST          ;**START OF TEST**
3768
3769 023140          STARS
      ;*****
      ;VERIFY THAT MULTIPLE SECTORS CAN BE READ, WE WILL CHECK
      ;THAT THE RLDA INCREMENTS PROPERLY.
      STARS
      ;*****

3770
3771
3772 023140

3773
3774 023140 004737 015764          JSR      PC,HDHOME          ;HEADS OVER TRACK 0
3775 023144          CKERFG          ;HEADS GO HOME OKAY
      023152 104432          TRAP      C#EXIT
      023154 000156          .WORD    L10057-.

3776
3777 023156 005037 002272          CLR      TMP0          ;CLEAR LOCATIONS
3778 023162 005037 002274          CLR      TMP1
3779
3780 023166          BGNSEG          ;**START OF SEGMENT**
      023166 104404          TRAP      C#BSEG

3781
3782 023170          10:
3783 023170 013737 002274 002300          MOV      TMP1,GDDAT          ;GET CYLINDER
3784 023176 053737 002272 002300          BIS      TMP0,GDDAT          ;GET SECTOR
3785 023204 013777 002300 157146          MOV      GDDAT,8RLDA          ;SET DISK ADDRESS-SECTOR 0
3786 023212 062737 000002 002300          ADD      #2,GDDAT          ;SET EXPECTED + 2
3787 023220 012777 003426 157130          MOV      #8UF,8RLBA          ;SET BUS ADDRESS
3788 023226 012777 177577 157126          MOV      #-129.,8RLMP          ;WORD COUNT-SECTOR+1 WORD
3789
3790 023234 004537 015054          JSR      R5,LDFUNC          ;LOAD THE FUNCTION IN NEXT WORD
3791 023240 000014          READ          ;READ
3792 023242 004537 015700          JSR      R5,WTCRDY          ;WAIT FOR CONTROLLER READY?
3793 023246          ESCAPE          SEG          ;CHECK FOR FL:LOE, ELSE EXIT SEG
      023246 104410          TRAP      C#ESCAPE
      023250 000060          .WORD    10000#-.

3794
3795 023252 004537 014612          JSR      R5,CHERR          ;CHECK CNTLR FOR ERRORS
3796 023256          ESCAPE          SEG          ;CHECK FOR FL:LOE, ELSE EXIT SEG
      023256 104410          TRAP      C#ESCAPE
      023260 000050          .WORD    10000#-.

3797
3798 023262 013737 002344 002302          MOV      E.DA,BDDAT          ;READ DISK ADDRESS
3799 023270 023737 002302 002300          CMP      BDDAT,GDDAT          ;IS DISK ADDRESS CORRECT
3800 023276 001404          BEQ      2#          ;YES, BRANCH NO, REPORT ERROR
3801
3802 023300          ERRDF          29.,EM14,ERR4          ;DA DID NOT INCREMENT
      023300 104455          TRAP      C#ERDF
      023302 000035          .WORD    29
      023304 005224          .WORD    EM14
      023306 007654          .WORD    ERR4

3803

```

***TEST 21** - CHECK MULTIPLE SECTORS ON READ

```

3804 023310          2# :   ESCAPE  SEG          ;CHECK FOR FL:LOE, ELSE EXIT SEG
      023310 104410   TRAP    C#ESCAPE
      023312 000016   .WORD   10000#-.
3805
3806 023314 005237 002272   INC     TMPO          ;NEXT SECTOR?
3807 023320 022737 000046 002272   CMP    #46, TMPO     ;DONE?
3808 023326 001320          BNE    1#           ;NO, GO BACK
3809
3810 023330          ENDSEG          ;##END OF SEGMENT##
      023330          10000# :
      023330 104405   TRAP    C#ESEG
3811 023332          ENDTST          ;**END OF TEST**
      023332          L10057 :
      023332 104401   TRAP    C#ETST
3812 023334          STARS
      ;*****
      ;CHECK THAT WE CAN FORCE A HEADER NOT FOUND AT THE
      ;END OF A TRACK DOING A MULTIPLE SECTOR READ. WE
      ;SET UP TO READ TWO SECTORS STARTING AT SECTOR 39
      ;WE SHOULD TRANSFER 128 WORDS THEN ABORT WITH A
      ;HEADER NOT FOUND FOR SECTOR 40
      STARS
      ;*****
3819
3820          .SBTTL  **TEST 22** - FORCE HDR NT FND AT END OF TRACK
3821
3822 023334          BGNST          ;**START OF TEST**
3823
3824 023334 004737 015764   JSR    PC, HDHOME    ;HEADS OVER TRACK 0
3825 023340          CKERFG          ;HEADS GO HOME OKAY
      023346 104432   TRAP    C#EXIT
      023350 000126   .WORD   L10060-.
3826
3827 023352          BGNSEG          ;##START OF SEGMENT##
      023352 104404   TRAP    C#BSEG
3828
3829 023354 012737 000047 002300   MOV    #39, GDDAT    ;CREATE LAST SECTOR
3830 023362 013777 002300 156770   MOV    GDDAT, SRLDA  ;LOAD DISK ADDRESS
3831 023370 012777 177577 156764   MOV    #-129, SRLMP  ;WORD COUNT
3832 023376 012777 003426 156752   MOV    #BUF, SRLBA   ;BUS ADDRESS
3833 023404 004537 015054          JSR    R5, LDFUNC    ;LOAD THE FUNCTION IN NEXT WORD
3834 023410 000014          READ          ;READ
3835 023412 004537 015700          JSR    R5, WTCRDY    ;WAIT FOR CONTROLLER READY
3836 023416          ESCAPE  SEG          ;CHECK FOR FL:LOE, ELSE EXIT SEG
      023416 104410   TRAP    C#ESCAPE
      023420 000054   .WORD   10000#-.
3837
3838 023422 013737 002340 002302   MOV    E.CS, BDDAT   ;READ CS
3839 023430 042737 001777 002302   BIC    #1777, BDDAT  ;SAVE ERROR BITS
3840 023436 022737 112000 002302   CMP    #112000, BDDAT ;HDR NOT FOUND SET?
3841 023444 001402          BEQ    4#           ;YES, CONTINUE
3842 023446 004537 014612          JSR    R5, CHERR
3843 023452          4# :   CKLOOP
      023452 104406   TRAP    C#CLP1
3844
3845 023454 022737 112000 002302   CMP    #112000, BDDAT
3846 023462 001404          BEQ    1#

```


TEST 22 - FORCE HDR NT FND AT END OF TRACK

```

3847
3848 023464          ERRDF  30.,EM23,ERRO ;HEADER NOT FOUND DID NOT SET
      023464 104455  TRAP   C#ERDF
      023466 000036  .WORD  30
      023470 005540  .WORD  EM23
      023472 007510  .WORD  ERRO
3849
3850 023474          1# :
3851
3852 023474          ENDSEG                ;##END OF SEGMENT##
      023474          10000# :
      023474 104405  TRAP   C#ESEG
3853 023476          ENDTST                ;**END OF TEST**
      023476          L10060 :
      023476 104401  TRAP   C#ETST
3854
3855          .SBTTL **TEST 23** - FORCE NON-EXISTENT MEMORY ERROR
3856
3857 023500          BGNTST                ;**START OF TEST**
3858
3859 023500          STARS
      ;*****
      ;CHECK FOR RLV-11
      ; E
      ;SIZE IF MEMORY >= 124K - IF TRUE DO NOT PERFORM TESTS 23 & 24
      STARS
      ;*****
3864
3865 023500 005037 002662          CLR    NOTST          ;INIT ABORT TEST
3866 023504 005737 002420          TST    T.CNTRL        ;RLV11?
3867 023510 001013                    BNE    4#             ;BRANCH - IF NO
3868 023512 013700 002120          MOV    L#HIMEM,RO    ;GET HIGHEST OCTAL MEMORY ADDRESS IN PAR FORMAT
3869 023516 006200                    ASR    RO             ;DIVIDE BY
3870 023520 006200                    ASR    RO             ;32(10),40(8)
3871 023522 006200                    ASR    RO             ;TO CONVERT TO
3872 023524 006200                    ASR    RO             ;1K(10)
3873 023526 006200                    ASR    RO             ;BLOCKS
3874 023530 005200                    INC    RO             ;TO INCLUDE LOCATION ZERO
3875 023532 022700 000174          CMP    #124.,RO     ;MEMORY >= 124K.?
3876 023536 003447                    BLE    5#             ;BRANCH - IF YES
3877
3878 023540          STARS
      ;*****
      ;FORCE A NON-EXISTENT MEMORY ERROR,
      ;WE SET THE RLBA TO EQUAL THE
      ;LAST ADDRESS IN MEMORY AND ISSUE A READ. THE
      ;READ SHOULD ABORT AFTER ONE WORD TRANSFERRED
      STARS
      ;*****
3884
3885 023540 004737 015764          4# :   JSR    PC,HDRHOME ;HEADS OVER TRACK 0
3886 023544          CKERFG                ;HEADS GO HOME OKAY
      023552 104432  TRAP   C#EXIT
      023554 000106  .WORD  L10061-.
3887
3888 023556          BGNSEG                ;##START OF SEGMENT##
      023556 104404  TRAP   C#BSEG

```

***TEST 23** - FORCE NON-EXISTENT MEMORY ERROR

```

3889
3890 023560 012777 160000 156570      MOV      #160000,@RLBA      ;LEAD BA
3891 023566 012737 000060 002374      MOV      @BA16!BA17,XMEM  ;SET EA BIT
3892 023574 005077 156560                CLR      @RLDA            ;LOAD DISK AVAILABLE
3893 023600 012777 177600 156554      MOV      #-128,@RLMP     ;WORD COUNT
3894 023606 004537 015054                JSR      R5,LDFUNC        ;LOAD THE FUNCTION IN NEXT WORD
3895 023612 000014                READ                     ;READ
3896 023614 004537 015700                JSR      R5,WTCRDY        ;WAIT FOR CONTROLLER
3897 023620                ESCAPE  SEG              ;CHECK FOR FL:LOE, ELSE EXIT SEG
    023620 104410                TRAP   C#ESCAPE
    023622 000026                .WORD 10000#-
3898 023624 032737 020000 002340      BIT      @NXM,E.CS        ;DID NXM SET?
3899 023632 001004                BNE     3#                ;YES, CONTINUE
3900 023634                ERRDF  31.,EM24,ERRO     ;NXM DID NOT SET
    023634 104455                TRAP   C#ERDF
    023636 000037                .WORD 31
    023640 005616                .WORD EM24
    023642 007510                .WORD ERRO
3901 023644                3#:  ESCAPE  SEG          ;CHECK FOR FL:LOE, ELSE EXIT SEG
    023644 104410                TRAP   C#ESCAPE
    023646 000002                .WORD 10000#-
3902 023650                ENDSEG                    ;##END OF SEGMENT##
    023650 104405                10000#: TRAP   C#ESEG
3903 023652                EXIT  TST
    023652 104432                TRAP   C#EXIT
    023654 000006                .WORD L10061-
3904 023656 005237 002662                5#:  INC      NOTST      ;ABORT TEST 24
3905
3906 023662                ENDTST                    ;**END OF TEST**
    023662                L10061: TRAP   C#ETST
    023662 104401
3907
3908                .SBTTL  ***TEST 24** - FORCE NON-EXISTENT MEMORY ERROR INTERRUPT
3909
3910 023664                BGNTST                    ;**START OF TEST**
3911 023664                STARS
    ;*****
    ;CHECK THAT WE CAN FORCE AN INTERRUPT WITH A
    ;NON-EXISTENT MEMORY ERROR.
    STARS
    ;*****
3912
3913
3914 023664
3915
3916 023664 005737 002662                TST     NOTST            ;RLV-11 & MEMORY SIZE >= 124K.?
3917 023670 001066                BNE     1#                ;BRANCH - IF YES
3918 023672 004737 015764                JSR     PC,HDHOME        ;HEADS OVER TRACK 0
3919 023676                CKERFG                    ;HEADS GO HOME OKAY
    023704 104432                TRAP   C#EXIT
    023706 000140                .WORD L10062-
3920
3921 023710                BGNSEG                    ;##START OF SEGMENT##
    023710 104404                TRAP   C#BSEG
3922
3923 023712 005037 002256                CLR     INTFLG           ;CLEAR INTERRUPT OCCURANCE FLAG
3924 023716                SETPRI #PRI00
    023716 012700 000000                MOV     #PRI00,R0
    023722 104441                TRAP   C#SPRI

```

TEST 24 - FORCE NON-EXISTENT MEMORY ERROR INTERRUPT

```

3925 023724 012777 160000 156424      MOV      #160000, @RLBA ;PRELOAD BA
3926 023732 012737 000060 002374      MOV      #BA16!BA17, XMEM ;SET EA BITS
3927 023740 005077 156414                CLR      @RLDA ;LOAD DA
3928 023744 012777 177777 156410      MOV      #-1, @RLMP ;WORD COUNT
3929 023752 004537 015054                JSR      R5, LDFUNC ;LOAD THE FUNCTION IN NEXT WORD
3930 023756 000114                READ!INTEN ;READ
3931 023760 004537 015700                JSR      R5, WTCRDY ;WAIT FOR CONTROLLER
3932                                ;
3933 023764                                SETPRI  #PRI07 ;PRIORITY TO 7 ;JSD REV A
                                SETPRI  #PRI06 ;PRIORITY TO 6 ;JSD REV A
                                MOV      #PRI06, R0
3934 023772                                TRAP    C$SPRI
                                ESCAPE  SEG ;CHECK FOR FL:LOE, ELSE EXIT SEG
                                TRAP    C$ESCAPE
                                .WORD   10000$-.
3935 023776 005737 002256                TST     INTFLG ;INTERRUPT OCCUR?
3936 024002 001004                BNE     4$ ;YES OKAY
3937 024004                                ERRDF   32., EM44, ERRO ;NO INTERRUPT W/NXM
                                TRAP    C$ERDF
                                .WORD   32
                                .WORD   EM44
                                .WORD   ERRO
3938 024014                                4$:   ESCAPE  SEG ;CHECK FOR FL:LOE, ELSE EXIT SEG
                                TRAP    C$ESCAPE
                                .WORD   10000$-.
3939 024020 032737 020000 002340                BIT     #NXM, E.CS ;DID NXM SET?
3940 024026 001004                BNE     3$ ;YES, CONTINUE
3941 024030                                ERRDF   33., EM24, ERRO ;NO NXM
                                TRAP    C$ERDF
                                .WORD   33
                                .WORD   EM24
                                .WORD   ERRO
3942 024040                                3$:   ESCAPE  SEG ;CHECK FOR FL:LOE, ELSE EXIT SEG
                                TRAP    C$ESCAPE
                                .WORD   10000$-.
3943 024044                                ENDSEG ;##END OF SEGMENT##
                                10000$: TRAP    C$ESEG
3944 024046                                1$:
3945                                ENDTST ;**END OF TEST**
3946 024046                                L10062: TRAP    C$ETST
                                024046 104401
3947
3948                                .SBTTL  **TEST 25** - CHECK READ WRITE LOOP
3949
3950 024050                                BGNTST ;**START OF TEST**
3951
3952 024050                                STARS
                                ;*****
                                ;VERIFY THAT THE WRITE ACTUALLY WRITES. AT THIS
                                ;TIME WE KNOW THAT THE WRITE FUNCTION GOES THRU
                                ;THE MOTIONS BUT WE DON'T KNOW THAT THE DATA
                                ;ACTUALLY GETS RECORDED ON THE PLATTER.
                                STARS
                                ;*****
3953
3954
3955
3956
3957 024050
3958
3959 024050 004737 015764                JSR     PC, HDHOME ;HEADS OVER TRACK 0

```


••TEST 25•• - CHECK READ WRITE LOOP

```

4004 024274 012702 003426      MOV      #BUF,R2      ;COMPARE BUFFER TO CHECK WRITE
4005 024300 012701 000200      MOV      #128.,R1    ;128 WORDS
4006 024304 012737 125252 002300  MOV      #125252,GDDAT ;SET UP EXPECTED
4007 024312 011237 002302      MOV      (R2),BDDAT  ;GET DATA
4008 024316 023737 002300 002302 5#:      CMP      GDDAT,BDDAT ;IS DATA OKAY
4009 024324 001442              BEQ      6#          ;YES, CONTINUE
4010 024326 010237 002274              MOV      R2,TMP1    ;LOAD BAD MEM LOCATION
4011 024332 023737 002242 012442      CMP      CDCNT,T.LMT ;CHECKED ENOUGH??
4012 024340 001002              BNE      333#       ;NO
4013 024342              ESCAPE  SEG          ;CHECK FOR FL:LOE, ELSE EXIT SEG
      024342 104410          TRAP   C#ESCAPE
      024344 000076          .WORD 10001#-.
4014 024346 005237 002242      333#:      INC      CDCNT      ;ACCOUNT FOR IT
4015
4016 024352 005737 002234      TST     CHECK      ;HEADER OR JUST DATA
4017 024356 001007              BNE     9#          ;JUST DATA
4018 024360              ERRDF  34.,EM25,ERR8 ;BAD DATA
      024360 104455          TRAP   C#ERDF
      024362 000042          .WORD 34
      024364 005656          .WORD EM25
      024366 010030          .WORD ERR8
4019 024370 005237 002234      INC     CHECK      ;ACCOUNT FOR PRINT OF HEADER
4020 024374 000416              BR      6#
4021
4022 024376              9#:      PRINTB #FRMT6,TMP1,GDDAT,BDDAT
      024376 013746 002302      MOV     BDDAT,-(SP)
      024402 013746 002300      MOV     GDDAT,-(SP)
      024406 013746 002274      MOV     TMP1,-(SP)
      024412 012746 011277      MOV     #FRMT6,-(SP)
      024416 012746 000004      MOV     #4,-(SP)
      024422 010600          MOV     SP,R0
      024424 104414          TRAP   C#PNTB
      024426 062706 000012      ADD     #12,SP
4023
4024 024432              6#:      CKLOOP
      024432 104406          TRAP   C#CLP1
4025 024434 005722              7#:      TST     (R2).      ;BUMP BUFFER POINTER
4026 024436 005301              DEC     R1          ;DONE?
4027 024440 001324              BNE     5#          ;NO, GO BACK
4028 024442              ENDSEG              ;END OF SEGMENT##
      024442
      024442 104405          10001#: TRAP   C#ESEG
4029 024444              ENDSEG              ;END OF SEGMENT##
      024444
      024444 104405          10000#: TRAP   C#ESEG
4030 024446              ENDTST              ;••END OF TEST••
      024446
      024446 104401          L10063: TRAP   C#ETST
4031
4032      .SBTTL  ••TEST 26•• - CHECK SILO LINES
4033
4034 024450              BGNTST              ;••START OF TEST••
4035
4036 024450              STARS
4037      ;*****
4038      ;TEST THAT LINES IN / TO SILO ARE GOOD, THAT IS THAT EACH LINE IS
      ;GOOD AND CAN BE AT EITHER A 1 OR A 0 STATE INDEPENDENTLY OF EACH

```

TEST 26 - CHECK SILO LINES

```

4039 ;OTHER BIT POSITION THIS IS DONE BY WRITING PATTERNS OF FLOATING 1,
4040 ;FLOATING 0, WALKING 0, WALKING 1
4041 024450 STARS
;*****

4042
4043 024450 004737 015764 JSR PC,HDHOME ;HEADS OVER TRACK 0
4044 024454 CKERFG ;HEADS GO HOME OKAY
024462 104432 TRAP C#EXIT
024464 000404 .WORD L10064-.

4045
4046 024466 012703 003236 MOV #DATPAT,R3

4047
4048 024472 BGNSEG ;##START OF SEGMENT##
024472 104404 TRAP C#BSEG

4049 024474 012700 003426 6#: MOV #BUF,R0 ;WRITE PATTERN INTO MEMORY
4050 024500 012701 000200 MOV #128.,R1 ;128 WORDS
4051 024504 011320 2#: MOV (R3),(R0)+ ;WRITE THE PATTERN
4052 024506 005301 DEC R1 ;DONE?
4053 024510 001375 BNE 2# ;NO GO BACK

4054
4055 024512 012777 003426 155636 MOV #BUF,BRLBA ;SETUP TO WRITE PATTERN ONTO DISK
4056 024520 005077 155634 CLR BRLDA ;LOAD DA
4057 024524 012777 177600 155630 MOV #-128.,BRLMP ;WORD COUNT
4058 024532 004537 015054 JSR R5,LDFUNC ;LOAD THE FUNCTION IN NEXT WORD
4059 024536 000012 WRITE
4060 024540 004537 015700 JSR R5,WTCRDY
4061 024544 ESCAPE SEG ;CHECK FOR FL:LOE, ELSE EXIT SEG
024544 104410 TRAP C#ESCAPE
024546 000320 .WORD 10000#-.

4062 024550 004537 014612 JSR R5,CHERR ;CHECK CNTLR FOR ERRORS
4063 024554 ESCAPE SEG ;CHECK FOR FL:LOE, ELSE EXIT SEG
024554 104410 TRAP C#ESCAPE
024556 000310 .WORD 10000#-.

4064 024560 BGNSEG ;##START OF SEGMENT##
024560 104404 TRAP C#BSEG

4065 024562 012700 003426 MOV #BUF,R0 ;CLEAR MEMORY BEFORE READING IT BACK
4066 024566 012701 000200 MOV #128.,R1 ;128 WORDS
4067 024572 005020 3#: CLR (R0)+ ;CLEAR
4068 024574 005301 DEC R1 ;EONE
4069 024576 001375 BNE 3# ;NO

4070
4071 024600 012777 003426 155550 MOV #BUF,BRLBA ;SETUP TO READ IT BACK
4072 024606 012777 177600 155546 MOV #-128.,BRLMP ;128 WORDS
4073 024614 005077 155540 CLR BRLDA ;SECTOR ZERO
4074 024620 004537 015054 JSR R5,LDFUNC ;LOAD THE FUNCTION IN NEXT WORD
4075 024624 000014 READ
4076 024626 004537 015700 JSR R5,WTCRDY
4077 024632 ESCAPE SEG ;CHECK FOR FL:LOE, ELSE EXIT SEG
024632 104410 TRAP C#ESCAPE
024634 000224 .WORD 10001#-.

4078 024636 004537 014612 JSR R5,CHERR ;CHECK CNTLR FOR ERRORS
4079 024642 005737 002236 TST T.CRC ;WAS ERROR A DCK??
4080 024646 001003 BNE 8# ;YES,SEE IF WE A DUMP
4081 024650 ESCAPE SEG ;CHECK FOR FL:LOE, ELSE EXIT SEG
024650 104410 TRAP C#ESCAPE
024652 000206 .WORD 10001#-.
4082 024654 000404 BR 99# ;SKIP AROUND

```


TEST 26 - CHECK SILO LINES

```

4083 024656 005737 012440      8:  TST      T.DMP      ;DO WE STILL WANT TO CHECK IT
4084 024662 001772              BEQ      10:      ;NO
4085 024664              CKLOOP      ;YES, CHECK FOR LOOP FIRST
      024664 104406              TRAP     C:CLP1
4086
4087 024666 005037 002242      9:  CLR      CDCNT      ;CLEAR NUMBER WE'RE TO PRINT
4088 024672 005037 002234      CLR      CHECK      ;ALLOW HEADER ON FIRST PRINT
4089 024676 011337 002300      MOV      (R3),GDDAT ;COMPARE WHAT WE READ BACK
4090 024702 012737 003426 002276  MOV      @BUF,TMP2  ;BUFFER START
4091 024710 012737 000001 002274  MOV      @1,TMP1   ;START WITH FIRST
4092
4093 024716 017737 155354 002302  5:  MOV      @TMP2,BDDAT ;GET DATA
4094 024724 023737 002300 002302  CMP      GDDAT,BDDAT ;GOOD?
4095 024732 001440              BEQ      4:        ;YES, BRANCH
4096
4097 024734 023737 002242 012442      CMP      CDCNT,T.LMT ;CHECKED ENOUGH??
4098 024742 001002              BNE      333:     ;NO
4099 024744              ESCAPE      SEG      ;CHECK FOR FL:LOE, ELSE EXIT SEG
      024744 104410              TRAP     C:ESCAPE
      024746 000112              .WORD   10001:--
4100 024750 005237 002242      333: INC      CDCNT      ;ACCOUNT FOR IT
4101
4102 024754 005737 002234      TST      CHECK      ;HEADER OR JUST DATA
4103 024760 001007              BNE      9:        ;JUST DATA
4104 024762              ERRDF      35.,EM45,ERR10 ;BAD DATA BACK
      024762 104455              TRAP     C:ERDF
      024764 000043              .WORD   35
      024766 006554              .WORD   EM45
      024770 010146              .WORD   ERR10
4105
4106 024772 005237 002234      INC      CHECK      ;ACCOUNT FOR PRINT OF HEADER
4107 024776 000416              BR       4:
4108
4109 025000      9:  PRINTB @FRMT7,TMP1,GDDAT,BDDAT
      025000 013746 002302      MOV      BDDAT,-(SP)
      025004 013746 002300      MOV      GDDAT,-(SP)
      025010 013746 002274      MOV      TMP1,-(SP)
      025014 012746 011354      MOV      @FRMT7,-(SP)
      025020 012746 000004      MOV      @4,-(SP)
      025024 010600      MOV      SP,R0
      025026 104414      TRAP     C:PNTB
      025030 062706 000012      ADD      @12,SP
4110 025034      4:  CKLOOP
      025034 104406              TRAP     C:CLP1
4111
4112 025036 062737 000002 002276      ADD      @2,TMP2      ;NEXT LOCATION
4113 025044 005237 002274      INC      TMP1         ;NEXT WORD
4114 025050 023727 002274 000201      CMP      TMP1,@129.  ;DONE
4115 025056 001317              BNE      5:        ;NO, GO BACK
4116
4117 025060              ENDSEG              ;##END OF SEGMENT##
      025060              10001:
      025060 104405              TRAP     C:SEEG
4118
4119 025062 005723              TST      (R3),      ;DONE ALL PATTERNS
4120 025064 001203              BNE      6:        ;NO, GO BACK
4121

```

***TEST 26** - CHECK SILO LINES

4122 025066
 025066 104405
 4123 025070
 025070 104401
 4124
 4125
 4126
 4127 025072
 4128
 4129 025072

ENDSEG ;##END OF SEGMENT##
 100001: TRAP C#ESEG ;##END OF TEST##
 ENDTST
 L10064: TRAP C#ETST

.SBTTL ***TEST 27** - CHECK THROUGHPUT OF SILO

4127 025072
 4128
 4129 025072
 4130
 4131
 4132
 4133 025072

BGNTST ;##START OF TEST##
 STARS
 ;*****
 ;TEST THAT THE SILO OPERATES CORRECTLY. WE WILL WRITE A PATTERN
 ;THAT CONTAINS A UNIQUE PATTERN IN EACH LOCATION. WE EXPECT IT
 ;BACK IN PROPER ORDER. WE DO A ONE SECTOR TRANSFER.
 STARS
 ;*****

4134
 4135 025072 004737 015764
 4136 025076
 025104 104432
 025106 000410

JSR PC,HDHOME ;HEADS OVER TRACK 0
 CKERFG ;HEADS GO HOME OKAY
 TRAP C#EXIT
 .WORD L10065-.

4137
 4138 025110
 025110 104404

BGNSEG ;##START OF SEGMENT##
 TRAP C#BSEG

4139
 4140 025112 012700 000001
 4141 025116 012701 000200
 4142 025122 012702 003426
 4143 025126 010022
 4144 025130 005200
 4145 025132 005301
 4146 025134 001374
 4147

21: MOV #1,R0 ;INITIAL 1
 MOV #128.,R1 ;128 WORDS
 MOV #BUF,R2 ;BUFFER
 MOV RO,(R2)+ ;WRITE A WORD
 INC RO ;NEXT PATTERN (1-128)
 DEC R1 ;DONE
 BNE 21 ;NO

4148 025136 012777 003426 155212
 4149 025144 012777 177600 155210
 4150 025152 005077 155202
 4151 025156 004537 015054
 4152 025162 000012
 4153 025164 004537 015700
 4154 025170
 025170 104410
 025172 000322

MOV #BUF,BRLBA ;SETUP TO WRITE
 MOV #-128.,BRLMP ;128 WORDS
 CLR BRLDA ;DISK ADDRESS 0
 JSR R5,LDFUNC ;LOAD THE FUNCTION IN NEXT WORD
 WRITE
 JSR R5,WTCRDY
 ESCAPE SEG ;CHECK FOR FL:LOE, ELSE EXIT SEG
 TRAP C#ESCAPE
 .WORD 100001-.

4155
 4156 025174 004537 014612
 4157 025200
 025200 104410
 025202 000312

JSR R5,CHERR ;CHECK CNTLR FOR ERRORS
 ESCAPE SEG ;CHECK FOR FL:LOE, ELSE EXIT SEG
 TRAP C#ESCAPE
 .WORD 100001-.

4158 025204
 025204 104404
 4159 025206 012700 003426
 4160 025212 012701 000200
 4161 025216 005020
 4162 025220 005301
 4163 025222 001375
 4164

BGNSEG ;##START OF SEGMENT##
 TRAP C#BSEG
 MOV #BUF,R0 ;CLEAR BUFFER
 MOV #128.,R1 ;128 IN LENGTH
 CLR (R0)+ ;CLEAR
 DEC R1 ;DOWN COUNT
 BNE 31 ;DONE?

TEST 27 - CHECK THROUGHPUT OF SILO

4165	025224	012777	003426	155124	MOV	#BUF,@RLBA	;BUS ADDRESS	
4166	025232	012777	177600	155122	MOV	#-128.,@RLMP	;WORD COUNT	
4167	025240	005077	155114		CLR	@RLDA	;DISK ADDRESS	
4168	025244	004537	015054		JSR	R5,LDFUNC	;LOAD THE FUNCTION IN NEXT WORD	
4169	025250	000014			READ			
4170	025252	004537	015700		JSR	R5,WTCRDY		
4171	025256				ESCAPE	SEG	;CHECK FOR FL:LOE, ELSE EXIT SEG	
	025256	104410			TRAP	C#ESCAPE		
	025260	000232			.WORD	10001#-.		
4172								
4173	025262	004537	014612		JSR	R5,CHERR	;CHECK CNTLR FOR ERRORS	
4174	025266	005737	002236		TST	T.CRC	;WAS ERROR A DCK??	
4175	025272	001003			BNE	8#	;YES,SEE IF WE A DUMP	
4176	025274			10#:	ESCAPE	SEG	;CHECK FOR FL:LOE, ELSE EXIT SEG	
	025274	104410			TRAP	C#ESCAPE		
	025276	000214			.WORD	10001#-.		
4177	025300	000404			BR	99#	;SKIP AROUND	
4178	025302	005737	012440	8#:	TST	T.DMP	;DO WE STILL WANT TO CHECK IT	
4179	025306	001772			BEQ	10#	;NO	
4180	025310				CKLOOP		;YES, CHECK FOR LOOP FIRST	
	025310	104406			TRAP	C#CLP1		
4181								
4182	025312	005037	002242	99#:	CLR	CDCNT	;CLEAR NUMBER WE'RE TO PRINT	
4183	025316	005037	002234		CLR	CHECK	;ALLOW HEADER ON FIRST PRINT	
4184	025322	012737	000001	002300	MOV	#1,GDDAT	;START GOOD AT 1	
4185	025330	012737	003426	002276	MOV	#BUF,TMP2	;START OF BUFFER	
4186	025336	012737	000001	002274	MOV	#1,TMP1	;FIRST WORD	
4187								
4188	025344	017737	154726	002302	4#:	MOV	@TMP2,BDDAT	;GET WORD
4189	025352	023737	002302	002300	CMP	BDDAT,GDDAT	;CORRECT?	
4190	025360	001440			BEQ	6#	;YES	
4191								
4192	025362	023737	002242	012442	CMP	CDCNT,T.LMT	;CHECKED ENOUGH??	
4193	025370	001002			BNE	333#	;NO	
4194	025372				ESCAPE	SEG	;CHECK FOR FL:LOE, ELSE EXIT SEG	
	025372	104410			TRAP	C#ESCAPE		
	025374	000116			.WORD	10001#-.		
4195	025376	005237	002242	333#:	INC	CDCNT	;ACCOUNT FOR IT	
4196								
4197	025402	005737	002234		TST	CHECK	;HEADER OR JUST DATA	
4198	025406	001007			BNE	9#	;JUST DATA	
4199	025410				ERRDF	36.,EM47,ERR10	;BAD DATA	
	025410	104455			TRAP	C#ERDF		
	025412	000044			.WORD	36		
	025414	006604			.WORD	EM47		
	025416	010146			.WORD	ERR10		
4200	025420	005237	002234		INC	CHECK	;ACCOUNT FOR PRINT OF HEADER	
4201	025424	000416			BR	6#		
4202								
4203	025426			9#:	PRINTB	#FRMT7,TMP1,GDDAT,BDDAT		
	025426	013746	002302		MOV	BDDAT,-(SP)		
	025432	013746	002300		MOV	GDDAT,-(SP)		
	025436	013746	002274		MOV	TMP1,-(SP)		
	025442	012746	011354		MOV	#FRMT7,-(SP)		
	025446	012746	000004		MOV	#4,-(SP)		
	025452	010600			MOV	SP,RO		
	025454	104414			TRAP	C#PNTB		

***TEST 27** - CHECK THROUGHPUT OF SILO

```

4204 025456 062706 000012          6:  ADD    #12,SP
      025462          CKLOOP
      025462 104406          TRAP   C#CLP1
4205
4206 025464 062737 000002 002276  ADD    #2,TMP2      ;NEXT
4207 025472 005237 002274          INC    TMP1         ;NEXT
4208 025476 005237 002300          INC    GDDAT        ;NEXT
4209 025502 023727 002274 000201  CMP    TMP1,#129.   ;DONE?
4210 025510 001315          BNE    4#
4211
4212 025512          10001:  ENDSEG                ;##END OF SEGMENT##
      025512          TRAP   C#ESEG
      025512 104405
4213
4214 025514          10000:  ENDSEG                ;##END OF SEGMENT##
      025514          TRAP   C#ESEG
      025514 104405
4215 025516          ENDTST                ;**END OF TEST**
      025516          L10065:  TRAP   C#ETST
      025516 104401
4216
4217          .SBTTL  ***TEST 28** - CHECK ZERO FILL ON WRITE
4218
4219 025520          BGNTST                ;**START OF TEST**
4220
4221 025520          STARS
      ;*****
      ;WHEN WRITING PARTIAL SECTORS (LESS THAN 128 WORDS) THE
      ;CONTROLLER WILL FILL IN THE REMAINING PORTION OF
      ;THE SECTOR WITH ZERO WORDS. CHECK THIS FEATURE
      ;WITH WORD COUNTS FROM 1 TO 127
      STARS
      ;*****
4222
4223
4224
4225
4226 025520
4227
4228 025520 004737 015764          JSR    PC,MDHOME     ;HEADS OVER TRACK 0
4229 025524          CKERFG                ;HEADS GO HOME OKAY
      025532 104432          TRAP   C#EXIT
      025534 000442          .WORD  L10066-.
4230
4231 025536          BGNSEG                ;##START OF SEGMENT##
      025536 104404          TRAP   C#BSEG
4232
4233 025540 012737 000001 002274  MOV    #1,TMP1      ;START WITH 1 WORD WRITE
4234 025546 012700 003426 35:  MOV    #BUF,RO      ;WRITE BUFFER WITH 52525, WE'LL
4235 025552 012701 000200          MOV    #128.,R1    ;WRITE 128 WORDS ALL THOUGH WE'RE
4236 025556 012720 052525 34:  MOV    #52525,(RO)+ ;ONLY GOING TO TRANSFER < 128
4237 025562 005301          R1                ;DONE WITH BUFFER?
4238 025564 001374          R1                ;NO, GO BACK
4239 025566 013700 002274 33:  MOV    TMP1,RO      ;GET TRANSFER WORD COUNT
4240 025572 005400          NEG    RO          ;NEGATE FOR RLMP
4241 025574 010077 154562          MOV    RO,BRLMP    ;STORE WORD COUNT AWAY
4242 025600 012777 003426 154550  MOV    #BUF,BRLBA  ;SET UP RLBA
4243 025606 005077 154546          CLR    BRLDA
4244 025612 004537 015054          JSR    R5,LDFUNC   ;LOAD THE FUNCTION IN NEXT WORD
4245 025616 000012          WRITE             ;WRITE IT
4246 025620 004537 015700          JSR    R5,WTCRDY  ;WAIT FOR WRITE TO FINISH
4247 025624          ESCAPE  SEG      ;CHECK FOR FL:LOE, ELSE EXIT SEG

```

TEST 28 - CHECK ZERO FILL ON WRITE

4248	025624	104410			TRAP	C#ESCAPE			
	025626	000346			.WORD	10000#--			
4249	025630	004537	014612		JSR	R5,CHERR			;CHECK CNTLR FOR ERRORS
4250	025634	104410			ESCAPE	SEG			;CHECK FOR FL:LOE, ELSE EXIT SEG
	025634	104410			TRAP	C#ESCAPE			
	025636	000336			.WORD	10000#--			
4251	025640	104404			BGNSEG				;##START OF SEGMENT##
	025640	104404			TRAP	C#BSEG			
4252	025642	012700	003426		MOV	#BUF,R0			;WE'RE GOING TO OVERLAY BUFFER BEFORE
4253	025646	012701	000200		MOV	#128.,R1			;READING IT BACK.
4254	025652	012720	125252	18#:	MOV	#125252,(R0)+			;OVERLAY IT WITH COMPLIMENT
4255	025656	005301			DEC	R1			;DONE?
4256	025660	001374			BNE	18#			;NO, KEEP GOING
4257	025662	012777	003426	154466	MOV	#BUF,#RLBA			;SET UP TO READ
4258	025670	012777	177600	154464	MOV	#-128.,#RLMP			;128 WORDS TO CHECK ZERO FILL
4259	025676	005077	154456		CLR	#RLDA			;SECTOR
4260	025702	004537	015054		JSR	R5,LDFUNC			;LOAD THE FUNCTION IN NEXT WORD
4261	025706	000014			READ				
4262	025710	004537	015700		JSR	R5,WTCRDY			;WAIT TIL WE FINISH THE READ
4263	025714	104410			ESCAPE	SEG			;CHECK FOR FL:LOE, ELSE EXIT SEG
	025714	104410			TRAP	C#ESCAPE			
	025716	000234			.WORD	10001#--			
4264									
4265	025720	004537	014612		JSR	R5,CHERR			;CHECK CNTLR FOR ERRORS
4266	025724	005737	002236		TST	T.CRC			;WAS ERROR A DCK??
4267	025730	001003			BNE	8#			;YES,SEE IF WE A DUMP
4268	025732	104410		10#:	ESCAPE	SEG			;CHECK FOR FL:LOE, ELSE EXIT SEG
	025732	104410			TRAP	C#ESCAPE			
	025734	000216			.WORD	10001#--			
4269	025736	000404			BR	99#			;SKIP AROUND
4270	025740	005737	012440	8#:	TST	T.DMP			;DO WE STILL WANT TO CHECK IT
4271	025744	001772			BEQ	10#			;NO
4272	025746	104406			CKLOOP				;YES, CHECK FOR LOOP FIRST
	025746	104406			TRAP	C#CLP1			
4273	025750	005037	002242	99#:	CLR	CDCNT			;CLEAR NUMBER WE'RE TO PRINT
4274	025754	005037	002234		CLR	CHECK			;ALLOW HEADER ON FIRST PRINT
4275	025760	013702	002274		MOV	TMP1,R2			;WORDS WRITTEN IN R2
4276	025764	012701	000200		MOV	#128.,R1			;CHECK 128 WORDS
4277									
4278	025770	012703	003426		MOV	#BUF,R3			;SET UP BUFFER BEGINNING
4279	025774	005037	002276		CLR	TMP2			;ZERO WORD COUNT
4280	026000	012737	052525	002300	MOV	#52525,GDDAT			;SET UP EXPECTED
4281	026006	011337	002302	4#:	MOV	(R3),BDDAT			;GET WORD
4282	026012	023737	002302	002300	CMF	BDDAT,GDDAT			;IS WORD CORRECT?
4283	026020	001441			BEQ	12#			;YES, GO CHECK COUNTS AND REPEAT
4284									
4285	026022	023737	002242	012442	CMF	CDCNT,T.LMT			;CHECKED ENOUGH??
4286	026030	001002			BNE	333#			;NO
4287	026032	104410			ESCAPE	SEG			;CHECK FOR FL:LOE, ELSE EXIT SEG
	026032	104410			TRAP	C#ESCAPE			
	026034	000116			.WORD	10001#--			
4288	026036	005237	002242	333#:	INC	CDCNT			;ACCOUNT FOR IT
4289									
4290	026042	005737	002234		TST	CHECK			;HEADER OR JUST DATA
4291	026046	001007			BNE	9#			;JUST DATA
4292	026050				ERRDF	37.,EM27,ERR12			

***TEST 28** - CHECK ZERO FILL ON WRITE

```

026050 104455 TRAP C#ERDF
026052 000045 .WORD 37
026054 005734 .WORD EM27
026056 010272 .WORD ERR12
4293 026060 005237 002234 INC CHECK ;ACCOUNT FOR PRINT OF HEADER
4294 026064 000417 BR 12#
4295
4296 026066 9# : PRINTB #FRMT9,TMP1,R3,GDDAT,BDDAT
026066 013746 002302 MOV BDDAT,-(SP)
026072 013746 002300 MOV GDDAT,-(SP)
026076 010346 MOV R3,-(SP)
026100 013746 002274 MOV TMP1,-(SP)
026104 012746 011547 MOV #FRMT9,-(SP)
026110 012746 000005 MOV #5,-(SP)
026114 010600 MOV SP,R0
026116 104414 TRAP C#PNTB
026120 062706 000014 ADD #14,SP
4297 026124 12# : CKLOOP
026124 104406 TRAP C#CLP1
4298 026126 005723 6# : TST (R3)+
4299 026130 005237 002276 INC TMP2
4300 026134 005301 DEC R1 ;DONE ALL WORDS?
4301 026136 001405 BEQ 7# ;EXIT TEST
4302 026140 005302 DEC R2 ;DONE CHECKING NON-ZERO WORDS
4303 026142 003321 BGT 4# ;NO, BRANCH BACK
4304 026144 005037 002300 CLR GDDAT ;YES, SET EXP'D AS ZERO
4305 026150 000716 BR 4# ;BRANCH BACK
4306
4307 026152 7# : ;EXIT TEST
4308 026152 ENDSEG ;##END OF SEGMENT##
026152 10001# :
026152 104405 TRAP C#ESEG
4309
4310 026154 005237 002274 INC TMP1
4311 026160 023727 002274 000200 CMP TMP1,#128.
4312 026166 001402 BEQ 34#
4313 026170 000137 025546 JMP 35#
4314 026174 34# :
4315
4316 026174 ENDSEG ;##END OF SEGMENT##
026174 10000# :
026174 104405 TRAP C#ESEG
4317 026176 ENDTST ;**END OF TEST**
026176 L10066 :
026176 104401 TRAP C#ETST
4318
4319 .SBTTL ***TEST 29** - CHECK SECTOR BITS OF HEADER COMPARE
4320
4321 026200 BGNTST ;**START OF TEST**
4322
4323 026200 STARS
;*****
;TEST THAT ALL SECTOR BITS OF HEADER WORD CAN COMPARE
;UNIQUELY. WE TESTED THE HEADER COMPARE LOGIC EARLIER
;BUT THAT WAS NOT AN EXTENSIVE TEST OF THE SECTOR BITS.
;THE TEST PROCEDURE IS TO WRITE EACH SECTOR OF TRACK
;0 WITH THE SECTOR ADDRESS, THEN GO BACK AND READ

```


TEST 29 - CHECK SECTOR BITS OF HEADER COMPARE

```

4329 ;EACH SECTOR. IF ANY SECTOR HAS ANY DATA THEN THAT
4330 ;WHICH WAS EXPECTED THEN WE HAVE AN ERROR
4331 ;ERROR PRINT OUT WILL GIVE SECTOR, EXPECTED AND RECEIVED
4332 026200 STARS
;*****
4333
4334 026200 004737 015764 JSR PC,HDHOME ;HEADS OVER TRACK 0
4335 026204 CKERFG ;HEADS GO HOME OKAY
026212 104432 TRAP C#EXIT
026214 000414 .WORD L10067-.
4336
4337 026216 BGNSEG ;##START OF SEGMENT##
026216 104404 TRAP C#BSEG
4338
4339 026220 005037 002272 1#: CLR TMO ;CLEAR
4340
4341 026224 BGNSEG ;##START OF SEGMENT##
026224 104404 TRAP C#BSEG
4342
4343 026226 012702 003426 199#: MOV #BUF,R2 ;WRITE A PATTERN FOR THE WRITE
4344 026232 012701 000200 MOV #128.,R1 ;ONE SECTOR'S WORTH
4345 026236 013722 002272 2#: MOV TMO,(R2)+ ;WRITE IT
4346 026242 005301 DEC R1 ;DONE.
4347 026244 001374 BNE 2# ;IF NOT, GO BACK
4348
4349 026246 012777 177600 154106 MOV #-128.,BRLMP ;ONE SECTOR WORD COUNT
4350 026254 012777 003426 154074 MOV #BUF,BRLBA ;WRITE FROM BUF
4351 026262 013777 002272 154070 MOV TMO,BRLDA ;SECTOR
4352 026270 004537 015054 JSR R5,LDFUNC ;LOAD THE FUNCTION IN NEXT WORD
4353 026274 000012 WRITE
4354 026276 004537 015700 JSR R5,WTCRDY ;WAIT FOR WRITE TO FINISH
4355 026302 ESCAPE SEG ;CHECK FOR FL:LOE, ELSE EXIT SEG
026302 104410 TRAP C#ESCAPE
026304 000320 .WORD 10001#-.
4356 026306 005237 002272 INC TMO ;NEXT SECTOR
4357 026312 023727 002272 000050 CMP TMO,#40. ;ALL DONE?
4358 026320 001342 BNE 199# ;NO GO BACK
4359 026322 005037 002272 CLR TMO ;CLEAR
4360
4361 026326 BGNSEG ;##START OF SEGMENT##
026326 104404 TRAP C#BSEG
4362
4363 026330 012702 003426 98#: MOV #BUF,R2 ;CLEAR THE BUFFER FIRST
4364 026334 012701 000200 MOV #128.,R1 ;128 WORDS
4365 026340 005022 3#: CLR (R2)+
4366 026342 005301 DEC R1
4367 026344 001375 BNE 3#
4368
4369 026346 013777 002272 154004 MOV TMO,BRLDA ;GET SECTOR
4370 026354 012777 003426 153774 MOV #BUF,BRLBA ;SETUP BUS ADDRESS
4371
4372 026362 012777 177600 153772 MOV #-128.,BRLMP ;READ A SECTOR
4373 026370 004537 015054 JSR R5,LDFUNC ;LOAD THE FUNCTION IN NEXT WORD
4374 026374 000014 READ
4375 026376 004537 015700 JSR R5,WTCRDY
4376 026402 ESCAPE SEG ;CHECK FOR FL:LOE, ELSE EXIT SEG
026402 104410 TRAP C#ESCAPE

```

TEST 29 - CHECK SECTOR BITS OF HEADER COMPARE

```

026404 000216 .WORD 10002#-.
4377
4378 026406 004537 014612 JSR R5,CHERR ;CHECK CNTLR FOR ERRORS
4379 026412 005737 002236 TST T.CRC ;WAS ERROR A DCK??
4380 026416 001003 BNE 8# ;YES,SEE IF WE A DUMP
4381 026420 10# : ESCAPE SEG ;CHECK FOR FL:LOE, ELSE EXIT SEG
026420 104410 TRAP C#ESCAPE
026422 000200 .WORD 10002#-.
4382 026424 000404 BR 99# ;SKIP AROUND
4383 026426 005737 012440 8# : TST T.DMP ;DO WE STILL WANT TO CHECK IT
4384 026432 001772 BEQ 10# ;NO
4385 026434 104406 CKLOOP ;YES, CHECK FOR LOOP FIRST
TRAP C#CLP1

4386
4387 ;CHECK NOW TO SEE IF WE READ THE RIGHT SECTOR
4388
4389 026436 005037 002242 99# : CLR CDCNT ;CLEAR NUMBER WE'RE TO PRINT
4390 026442 005037 002234 CLR CHECK ;ALLOW HEADER ON FIRST PRINT
4391 026446 013737 002272 002300 MOV TMPO,GDDAT ;EXPECTED DATA
4392 026454 012702 003426 MOV #BUF,R2 ;BUFFER
4393 026460 012701 000200 MOV #128,R1 ;WORD COUNT
4394 026464 012237 002302 5# : MOV (R2)+,BDDAT ;
4395 026470 023737 002302 002300 CMP BDDAT,GDDAT
4396 026476 001440 BEQ 6#
4397
4398 026500 023737 002242 012442 CMP CDCNT,T.LMT ;CHECKED ENOUGH??
4399 026506 001002 BNE 333# ;NO
4400 026510 104410 ESCAPE SEG ;CHECK FOR FL:LOE, ELSE EXIT SEG
026510 104410 TRAP C#ESCAPE
026512 000110 .WORD 10002#-.
4401 026514 005237 002242 333# : INC CDCNT ;ACCOUNT FOR IT
4402
4403 026520 005737 002234 TST CHECK ;HEADER OR JUST DATA
4404 026524 001007 BNE 9# ;JUST DATA
4405 026526 104455 ERRDF 38,EM50,ERR11 ;
026526 104455 TRAP C#ERRDF
026530 000046 .WORD 38
026532 006621 .WORD EM50
026534 010220 .WORD ERR11
4406 026536 005237 002234 INC CHECK ;ACCOUNT FOR PRINT OF HEADER
4407 026542 000416 BR 6#
4408
4409 026544 9# : PRINTB #FRMT8, TMPO, GDDAT, BDDAT
026544 013746 002302 MOV BDDAT, -(SP)
026550 013746 002300 MOV GDDAT, -(SP)
026554 013746 002272 MOV TMPO, -(SP)
026560 012746 011426 MOV #FRMT8, -(SP)
026564 012746 000004 MOV #4, -(SP)
026570 010600 MOV SP, R0
026572 104414 TRAP C#PNTB
026574 062706 000012 ADD #12, SP
4410 026600 6# : CKLOOP
026600 104406 TRAP C#CLP1
4411
4412 026602 005301 DEC R1 ;ALL OF SECTOR CHECKED?
4413 026604 001327 BNE 5# ;GO BACK IF NOT
4414 026606 005237 002272 INC TMPO ;NEXT SECTOR

```


TEST 30 - WRITE CHECK NPR INTEGRITY

```

4493 027216 005737 002254      TST      TRPFLG      ;DID TRAP OCCUR?
4494 027222 001406      BEQ      7#         ;NO
4495 027224 004537 015414      JSR      R5,AFTER  ;
4496 027230      ERRSF      1.,EM57,ERRO ;TRAP ON WRITE
      027230 104454      TRAP     C#ERSF
      027232 000001      .WORD   1
      027234 007052      .WORD   EM57
      027236 007510      .WORD   ERRO
4497 027240      7#:
4498
4499 027240      ENDSEG          ;##END OF SEGMENT##
      027240      10001#:
      027240 104405      TRAP     C#ESEG
4500 027242      ENDSEG          ;##END OF SEGMENT##
      027242      10000#:
      027242 104405      TRAP     C#ESEG
4501
4502 027244      ENDTST         ;**END OF TEST**
      027244      L10070:
      027244 104401      TRAP     C#ETST
4503
4504      .SBTTL **TEST 31** - WRITE CHECK FUNCTION
4505
4506 027246      BGNTST          ;**START OF TEST**
4507
4508 027246      STARS
      ;*****
      ;CHECK OF WRITE CHECK LOGIC UNDER FLAG MODE
      ; WE WILL WRITE CHECK A FULL SECTOR (128 WORDS) FROM
      ;MEMORY (BUF). WE CHECK THAT NO ERRORS OCCUR.
      STARS
      ;*****
4513
4514 027246 004737 015764      JSR      PC,HDHOME ;HEADS OVER TRACK 0
4515 027252      CKERFG          ;HEADS GO HOME OKAY
      027260 104432      TRAP     C#EXIT
      027262 000214      .WORD   L10071-.
4516
4517 027264      BGNSEG          ;##START OF SEGMENT##
      027264 104404      TRAP     C#BSEG
4518
4519 027266 012700 003426      MOV      #BUF,R0   ;SETUP AND WRITE
4520 027272 012701 000200      MOV      #128.,R1 ;128 WORDS
4521 027276 012720 125252      299#:  MOV      #125252,(R0);WRITE
4522 027302 005301      DEC      R1        ;DONE??
4523 027304 001374      BNE      299#
4524
4525 027306 012777 003426 153042      MOV      #BUF,BRLBA ;LOAD BUS ADDRESS
4526 027314 012777 177600 153040      MOV      #-128.,BRLMP ;WORD COUNT
4527 027322 005077 153032      CLR      BRLDA    ;CLEAR DISK ADDRESS
4528 027326 004537 015054      JSR      R5,LDFUNC ;LOAD THE FUNCTION IN NEXT WORD
4529 027332 000012      WRITE
4530 027334 004537 015700      JSR      R5,WTCRDY ;WAIT FOR CONTROLLER READY
4531 027340      ESCAPE          ;CHECK FOR FL:LOE, ELSE EXIT SEG
      027340 104410      TRAP     C#ESCAPE
      027342 000132      .WORD   10000#-.
4532 027344 004537 014612      JSR      R5,CHERR ;CHECK CNTLR FOR ERRORS

```

***TEST 31** - WRITE CHECK FUNCTION

```

4533 027350          ESCAPE SEG          ;CHECK FOR FL:LOE, ELSE EXIT SEG
      027350 104410  TRAP C#ESCAPE
      027352 000122  .WORD 10000#-.
4534 027354          BGNSEG          ;##START OF SEGMENT##
      027354 104404  TRAP C#BSEG
4535
4536          ;VERIFY WRITE WITH READ BEFORE WRCHK
4537
4538 027356 005077 152776  CLR      @RLDA
4539 027362 012777 003426 152766  MOV      @BUF,@RLBA
4540 027370 012777 177600 152764  MOV      @-128.,@RLMP
4541 027376 004537 015054  JSR      R5,LDFUNC          ;LOAD THE FUNCTION IN NEXT WORD
4542 027402 000014  READ
4543 027404 004537 015700  JSR      R5,WTCRDY
4544 027410          ESCAPE SEG          ;CHECK FOR FL:LOE, ELSE EXIT SEG
      027410 104410  TRAP C#ESCAPE
      027412 000060  .WORD 10001#-.
4545 027414 004537 014612  JSR      R5,CHERR          ;CHECK CNTLR FOR ERRORS
4546 027420          ESCAPE SEG          ;CHECK FOR FL:LOE, ELSE EXIT SEG
      027420 104410  TRAP C#ESCAPE
      027422 000050  .WORD 10001#-.
4547
4548 027424          BGNSEG          ;##START OF SEGMENT##
      027424 104404  TRAP C#BSEG
4549
4550 027426          3#:
4551 027426 005077 152726  CLR      @RLDA
4552 027432 012777 177600 152722  MOV      @-128.,@RLMP
4553 027440 012777 003426 152710  MOV      @BUF,@RLBA
4554 027446 004537 015054  JSR      R5,LDFUNC          ;LOAD THE FUNCTION IN NEXT WORD
4555 027452 000002  WRCHK          ;WRITE CHECK
4556
4557 027454 004537 015700  JSR      R5,WTCRDY          ;WAIT FOR CONTROLLER READY
4558 027460          ESCAPE SEG          ;CHECK FOR FL:LOE, ELSE EXIT SEG
      027460 104410  TRAP C#ESCAPE
      027462 000006  .WORD 10002#-.
4559
4560 027464 004537 014612  JSR      R5,CHERR          ;CHECK CNTLR FOR ERRORS
4561
4562 027470          ENDSEG          ;##END OF SEGMENT##
      027470          10002#:
      027470 104405  TRAP C#ESEG
4563 027472          ENDSEG          ;##END OF SEGMENT##
      027472          10001#:
      027472 104405  TRAP C#ESEG
4564 027474          ENDSEG          ;##END OF SEGMENT##
      027474          10000#:
      027474 104405  TRAP C#ESEG
4565 027476          ENDTST          ;**END OF TEST**
      027476          L10071:
      027476 104401  TRAP C#ETST
4566
4567          .SBTTL **TEST 32** - WRITE CHECK FUNCTION INTERRUPT
4568
4569 027500          BGNTST          ;**START OF TEST**
4570
4571 027500          STARS

```


TEST 32 - WRITE CHECK FUNCTION INTERRUPT

```

4572
4573
4574
4575
4576 027500
4577
4578 027500 004737 015764
4579 027504
      027512 104432
      027514 000252
4580
4581 027516
      027516 104404
4582
4583 027520 012700 003426
4584 027524 012701 000200
4585 027530 012720 125252
4586 027534 005301
4587 027536 001374
4588
4589 027540 012777 003426 152610
4590 027546 012777 177600 152606
4591 027554 005077 152600
4592 027560 004537 015054
4593 027564 000012
4594 027566 004537 015700
4595 027572
      027572 104410
      027574 000170
4596 027576 004537 014612
4597 027602
      027602 104410
      027604 000160
4598
4599
4600 027606 005077 152546
4601 027612 012777 003426 152536
4602 027620 012777 177600 152534
4603 027626 004537 015054
4604 027632 000014
4605 027634 004537 015700
4606 027640
      027640 104410
      027642 000122
4607 027644 004537 014612
4608 027650
      027650 104410
      027652 000112
4609
4610 027654
      027654 104404
4611
4612 027656 005037 002256
4613 027662 005077 152472
4614 027666 012777 177600 152466

```

```

;*****
;CHECK OF WRITE CHECK LOGIC UNDER INTERRUPT MODE
;WE WILL WRITE CHECK A FULL SECTOR (128 WORDS) FROM MEMORY (BUF).
;WE CHECK THAT NO ERRORS OCCUR. WE DO NOT CHECK RLDA OR RLBA
;INCREMENT AT THIS TIME.
STARS
;*****

      JSR      PC,HDHOME      ;HEADS OVER TRACK 0
      CKERFG
      TRAP    C#EXIT        ;HEADS GO HOME OKAY
      .WORD   L10072-.

      BGNSEG
      TRAP    C#BSEG        ;##START OF SEGMENT##

      MOV     #BUF,R0        ;SETUP AND WRITE
      MOV     #128.,R1       ;128 WORDS
2999:  MOV     #125252,(R0)+   ;WRITE
      DEC     R1             ;DONE??
      BNE    2999

      MOV     #BUF,BRLBA    ;LOAD BUS ADDRESS
      MOV     #-128.,BRLMP  ;WORD COUNT
      CLR     BRLDA        ;CLEAR DISK ADDRESS
      JSR     R5,LDFUNC     ;LOAD THE FUNCTION IN NEXT WORD
      WRITE
      JSR     R5,WTCRDY     ;WAIT FOR CONTROLLER READY
      ESCAPE  SEG          ;CHECK FOR FL:LOE, ELSE EXIT SEG
      TRAP   C#ESCAPE
      .WORD  10000#-.

      JSR     R5,CHERR      ;CHECK CNTLR FOR ERRORS
      ESCAPE  SEG          ;CHECK FOR FL:LOE, ELSE EXIT SEG
      TRAP   C#ESCAPE
      .WORD  10000#-.

;VERIFY WRITE WITH READ BEFORE WRCHK

      CLR     BRLDA
      MOV     #BUF,BRLBA
      MOV     #-128.,BRLMP
      JSR     R5,LDFUNC     ;LOAD THE FUNCTION IN NEXT WORD
      READ
      JSR     R5,WTCRDY
      ESCAPE  SEG          ;CHECK FOR FL:LOE, ELSE EXIT SEG
      TRAP   C#ESCAPE
      .WORD  10000#-.

      JSR     R5,CHERR      ;CHECK CNTLR FOR ERRORS
      ESCAPE  SEG          ;CHECK FOR FL:LOE, ELSE EXIT SEG
      TRAP   C#ESCAPE
      .WORD  10000#-.

      BGNSEG
      TRAP    C#BSEG        ;##START OF SEGMENT##

      CLR     INTFLG        ;CLEAR INTERRUPT OCCURANCE FLAG
      CLR     BRLDA
      MOV     #-128.,BRLMP  ;SET UP WORD COUNT

```

***TEST 32** - WRITE CHECK FUNCTION INTERRUPT

```

4615 027674 012777 003426 152454      MOV      #BUF,@RLBA      ;SET UP BUS ADDRESS
4616
4617 027702                                SETPRI   #PRI00          ;PRIORITY TO 0
      027702 012700 000000      MOV      #PRI00,R0
      027706 104441      TRAP    C#SPRI
4618 027710 004537 015054      JSR      R5,LDFUNC      ;LOAD THE FUNCTION IN NEXT WORD
4619 027714 000102      WRCHK!INTEN ;WRITE CHECK UNDER INTERRUPT
4620 027716 004537 015700      JSR      R5,WTCRDY     ;WAIT FOR INTERRUPT
4621 027722      ESCAPE  SEG           ;CHECK FOR FL:LOE, ELSE EXIT SEG
      027722 104410      TRAP    C#ESCAPE
      027724 000036      .WORD   10001#-.

4622
4623                                ;
4624 027726                                ; SETPRI   #PRI07          ;SET PRIORITY TO 7
      027726 012700 000300      SETPRI   #PRI06          ;SET PRIORITY TO 6
      027732 104441      MOV      #PRI06,R0      ;JSD REV A
4625 027734 005737 002256      TRAP    C#SPRI          ;JSD REV A
4626 027740 001004      TST     INTFLG
4627                                ;
4628 027742      ERRDF   4.,EM60,ERRO ;WRITE DID NOT INTERRUPT
      027742 104455      TRAP    C#ERDF
      027744 000004      .WORD   4
      027746 007107      .WORD   EM60
      027750 007510      .WORD   ERRO
4629 027752      2# :      ESCAPE  SEG           ;CHECK FOR FL:LOE, ELSE EXIT SEG
      027752 104410      TRAP    C#ESCAPE
      027754 000006      .WORD   10001#-.

4630
4631 027756 004537 014612      JSR      R5,CHERR      ;CHECK CNTLR FOR ERRORS
4632
4633 027762                                ENDSEG      ;##END OF SEGMENT##
      027762 104405      10001# : TRAP    C#ESEG
4634 027764                                ENDSEG      ;##END OF SEGMENT##
      027764 104405      10000# : TRAP    C#ESEG
4635 027766      ENDTST      ;**END OF TEST**
      027766 104401      L10072 : TRAP    C#ETST

4636
4637                                .SBTTL  ***TEST 33** - PROPER INCREMENT OF RLBA ON WRITE CHECK
4638
4639 027770      BGNTST      ;**START OF TEST**
4640
4641 027770      STARS
      ;*****
4642                                ;CHECK THAT THE RLBA WILL INCREMENT PROPERLY AFTER THE
4643                                ;WRITE CHECK WAS FINISHED THE RLBA SHOULD BE 128 WORDS (256 BYTES)
4644                                ;CREATER. STARTING RLBA IS "BUF", ENDING SHOULD BE "BUF + 256."
4645                                ;WE WILL MONITOR ALL ERRORS AND REPORT THEM ACCORDINGLY
4646 027770      STARS
      ;*****

4647
4648 027770 004737 015764      JSR      PC,HOMHOME    ;HEADS OVER TRACK 0
4649 027774                                CKERFG      ;HEADS GO HOME OKAY
      030002 104432      TRAP    C#EXIT
      030004 000256      .WORD   L10073-.
    
```

••TEST 33•• - PROPER INCREMENT OF RLBA ON WRITE CHECK

```

4650
4651 030006          BGNSEG          ;##START OF SEGMENT##
      030006 104404 TRAP          C#BSEG
4652
4653 030010 012700 003426          MOV      #BUF,R0          ;SETUP AND WRITE
4654 030014 012701 000200          MOV      #-128.,R1       ;128 WORDS
4655 030020 012720 125252          299# : MOV      #125252,(R0)+   ;WRITE
4656 030024 005301          DEC      R1              ;DONE??
4657 030026 001374          BNE     299#
4658
4659 030030 012777 003426 152320   MOV      #BUF,BRLBA      ;LOAD BUS ADDRESS
4660 030036 012777 177600 152316   MOV      #-128.,BRLMP    ;WORD COUNT
4661 030044 005077 152310          CLR     BRLDA           ;CLEAR DISK ADDRESS
4662 030050 004537 015054          JSR    R5,LDFUNC        ;LOAD THE FUNCTION IN NEXT WORD
4663 030054 000012          WRITE
4664 030056 004537 015700          JSR    R5,WTCRDY        ;WAIT FOR CONTROLLER READY
4665 030062          ESCAPE SEG             ;CHECK FOR FL:LOE, ELSE EXIT SEG
      030062 104410 TRAP     C#ESCAPE
      030064 000174 .WORD  10000#-
4666 030066 004537 014612          JSR    R5,CHERR         ;CHECK CNTLR FOR ERRORS
4667 030072          ESCAPE SEG             ;CHECK FOR FL:LOE, ELSE EXIT SEG
      030072 104410 TRAP     C#ESCAPE
      030074 000164 .WORD  10000#-
4668          ;VERIFY WRITE WITH READ BEFORE WRCHK
4669
4670 030076 005077 152256          CLR     BRLDA
4671 030102 012777 003426 152246   MOV      #BUF,BRLBA
4672 030110 012777 177600 152244   MOV      #-128.,BRLMP
4673 030116 004537 015054          JSR    R5,LDFUNC        ;LOAD THE FUNCTION IN NEXT WORD
4674 030122 000014          READ
4675 030124 004537 015700          JSR    R5,WTCRDY        ;CHECK FOR FL:LOE, ELSE EXIT SEG
4676 030130          ESCAPE SEG
      030130 104410 TRAP     C#ESCAPE
      030132 000126 .WORD  10000#-
4677 030134 004537 014612          JSR    R5,CHERR         ;CHECK CNTLR FOR ERRORS
4678 030140          ESCAPE SEG             ;CHECK FOR FL:LOE, ELSE EXIT SEG
      030140 104410 TRAP     C#ESCAPE
      030142 000116 .WORD  10000#-
4679
4680 030144          BGNSEG          ;##START OF SEGMENT##
      030144 104404 TRAP          C#BSEG
4681
4682 030146          3# :
4683 030146 005077 152206          CLR     BRLDA
4684 030152 012777 003426 152176   MOV      #BUF,BRLBA
4685 030160 012777 177600 152174   MOV      #-128.,BRLMP
4686 030166 012737 003426 002300   MOV      #BUF,GDDAT
4687 030174 062737 000400 002300   ADD     #256.,GDDAT     ;AFTER WRITE
4688
4689 030202 004537 015054          JSR    R5,LDFUNC        ;LOAD THE FUNCTION IN NEXT WORD
4690 030206 000002          WRCHK
4691 030210 004537 015700          JSR    R5,WTCRDY        ;WRITE CHECK
4692 030214          ESCAPE SEG             ;WAIT FOR CONTROLLER READY
      030214 104410 TRAP     C#ESCAPE
      030216 000040 .WORD  10001#-
4693          ;CHECK FOR FL:LOE, ELSE EXIT SEG
4694 030220 004537 014612          JSR    R5,CHERR         ;CHECK CNTLR FOR ERRORS

```


***TEST 33** - PROPER INCREMENT OF RLBA ON WRITE CHECK

```

4695 030224          ESCAPE SEG          ;CHECK FOR FL:LOE, ELSE EXIT SEG
      030224 104410  TRAP C#ESCAPE
      030226 000030  .WORD 10001#-.
4696 030230 017737 152122 002302  MOV @RLBA,BDDAT ;READ 'RLBA' FOR PRESENT ADDRESS
4697 030236 023737 002302 002300  CMP BDDAT,GDDAT ;DID 'BA' INCREMENT PROPERLY?
4698 030244 001404  BEQ 2# ;YES, CONTINUE
4699
4700 030246          ERRDF 5.,EM61,ERR4 ;BA DID NOT INCREMENT
      030246 104455  TRAP C#ERRDF
      030250 000005  .WORD 5
      030252 007137  .WORD EM61
      030254 007654  .WORD ERR4
4701
4702 030256          2#:
4703
4704 030256          ENDSEG ;##END OF SEGMENT##
      030256          10001#:
      030256 104405  TRAP C#ESEG
4705 030260          ENDSEG ;##END OF SEGMENT##
      030260          10000#:
      030260 104405  TRAP C#ESEG
4706 030262          ENDTST ;**END OF TEST**
      030262          L10073:
      030262 104401  TRAP C#ETST
4707
4708 .SBTTL ***TEST 34** - PROPER INCREMENT OF RLDA ON WRITE CHECK
4709
4710 030264          BGNTST ;**START OF TEST**
4711
4712 030264          STARS
      ;*****
      ;CHECK THAT THE SECTOR INCREMENTS AFTER THE WRITE CHECK WAS FINISHED.
      ;A FULL SECTOR WRITE CHECK THE RLDA SHOULD REFLECT AN INCREMENT
      ;OF THE SECOTR. "GDDAT" WAS THE EXPECTED RLDA.
      STARS
      ;*****
4713
4714
4715
4716 030264
4717
4718 030264 004737 015764  JSR PC,HDHOME ;HEADS OVER TRACK 0
4719 030270          CKERFG ;HEADS GO HOME OKAY
      030276 104432  TRAP C#EXIT
      030300 000254  .WORD L10074-.
4720
4721 030302          BGNSEG ;##START OF SEGMENT##
      030302 104404  TRAP C#BSEG
4722
4723 030304 012700 003426  MOV @BUF,R0 ;SETUP AND WRITE
4724 030310 012701 000200  MOV @128.,R1 ;128 WORDS
4725 030314 012720 125252  299#: MOV @125252,(R0) ;WRITE
4726 030320 005301  DEC R1 ;DONE??
4727 030322 001374  BNE 299#
4728
4729 030324 012777 003426 152024  MOV @BUF,@RLBA ;LOAD BUS ADDRESS
4730 030332 012777 177600 152022  MOV @-128.,@RLMP ;WORD COUNT
4731 030340 005077 152014  CLR @RLDA ;CLEAR DISK ADDRESS
4732 030344 004537 015054  JSR R5,LDFUNC ;LOAD THE FUNCTION IN NEXT WORD
4733 030350 000012  WRITE
4734 030352 004537 015700  JSR R5,WTCRDY ;WAIT FOR CONTROLLER READY

```

TEST 34 - PROPER INCREMENT OF RLDA ON WRITE CHECK

```

4735 030356          ESCAPE SEG          ;CHECK FOR FL:LOE, ELSE EXIT SEG
      030356 104410  TRAP C#ESCAPE
      030360 000172  .WORD 10000#-.
4736 030362 004537 014612 JSR R5,CHERR          ;CHECK CNTLR FOR ERRORS
4737 030366          ESCAPE SEG          ;CHECK FOR FL:LOE, ELSE EXIT SEG
      030366 104410  TRAP C#ESCAPE
      030370 000162  .WORD 10000#-.
4738          ;VERIFY WRITE WITH READ BEFORE WRCHK
4739
4740 030372 005077 151762 CLR BRLDA
4741 030376 012777 003426 151752 MOV #BUF,BRLBA
4742 030404 012777 177600 151750 MOV #-128.,BRLMP
4743 030412 004537 015054 JSR R5,LDFUNC          ;LOAD THE FUNCTION IN NEXT WORD
4744 030416 000014  READ
4745 030420 004537 015700 JSR R5,WTCRDY
4746 030424          ESCAPE SEG          ;CHECK FOR FL:LOE, ELSE EXIT SEG
      030424 104410  TRAP C#ESCAPE
      030426 000124  .WORD 10000#-.
4747 030430 004537 014612 JSR R5,CHERR          ;CHECK CNTLR FOR ERRORS
4748 030434          ESCAPE SEG          ;CHECK FOR FL:LOE, ELSE EXIT SEG
      030434 104410  TRAP C#ESCAPE
      030436 000114  .WORD 10000#-.
4749
4750 030440          BGNSEG          ;START OF SEGMENT
      030440 104404  TRAP C#BSEG
4751
4752 030442          30:
4753 030442 005037 002300 CLR GDDAT
4754 030446 013777 002300 151704 MOV GDDAT,BRLDA          ;SETUP DISK ADDRESS
4755 030454 005237 002300 INC GDDAT          ;CREATE EXPECTED SECTOR
4756 030460 012777 177600 151674 MOV #-128.,BRLMP          ;WORD COUNT
4757 030466 012777 003426 151662 MOV #BUF,BRLBA          ;SETUP BUS ADDRESS
4758
4759 030474 004537 015054 JSR R5,LDFUNC          ;LOAD THE FUNCTION IN NEXT WORD
4760 030500 000002  WRCHK          ;WRITE CHECK
4761 030502 004537 015700 JSR R5,WTCRDY          ;WAIT FOR CONTROLLER READY
4762 030506          ESCAPE SEG          ;CHECK FOR FL:LOE, ELSE EXIT SEG
      030506 104410  TRAP C#ESCAPE
      030510 000040  .WORD 10001#-.
4763
4764 030512 004537 014612 JSR R5,CHERR          ;CHECK CNTLR FOR ERRORS
4765 030516          ESCAPE SEG          ;CHECK FOR FL:LOE, ELSE EXIT SEG
      030516 104410  TRAP C#ESCAPE
      030520 000030  .WORD 10001#-.
4766
4767 030522 013737 002344 002302 MOV E.DA,BDDAT          ;READ DISK ADDRESS
4768 030530 023737 002300 002302 CMP GDDAT,BDDAT          ;DID SECTOR INCREMENT PROPERLY
4769 030536 001404  BEQ 2#          ;YES, BRANCH NO, REPORT ERROR
4770
4771 030540          ERRDF          ;DA DID NOT INCREMENT
      030540 104455  TRAP C#ERDF
      030542 000006  .WORD 6
      030544 007207  .WORD EM62
      030546 007654  .WORD ERR4
4772
4773 030550          20:
4774

```

TEST 34 - PROPER INCREMENT OF RLDA ON WRITE CHECK

```

4775 030550          ENDSEG          ;##END OF SEGMENT##
      030550          10001: TRAP    C#ESEG
4776 030552 104405  ENDSEG          ;##END OF SEGMENT##
      030552          10000: TRAP    C#ESEG
4777 030554 104405  ENDTST          ;##END OF TEST##
      030554          L10074: TRAP   C#ETST
      030554 104401

```

.SBTTL TEST 35 - MULTIPLE SECTOR WRITE CHECK

```

4778
4779
4780
4781 030556  BGNTST          ;##START OF TEST##
4782
4783 030556  STARS

```

```

;*****
;CHECK FOR MULTIPLE SECTOR WRITE CHECK. THIS TEST CHECKS
;THAT TWO SECTORS CAN BE SUCCESSFULLY CHECKED. WE LOAD
;A WORD COUNT OF 129 WORDS (ONE SECTOR + 1 WORD) STARTING AT
;SECTOR 0 THRU SECTOR 37 AND VERIFY THAT THE RLDA DOES
;A DOUBLE INCREMENT EACH TIME.
STARS
;*****

```

```

4790
4791 030556 004737 015764      JSR    PC,HDHOME      ;HEADS OVER TRACK 0
4792 030562          CKERFG          ;HEADS GO HOME OKAY
      030570 104432          TRAP    C#EXIT
      030572 000354          .WORD   L10075-.
4793
4794 030574          BGNSEG          ;##START OF SEGMENT##
      030574 104404          TRAP    C#BSEG
4795
4796 030576 012737 000000 002272  MOV    #0,TMP0
4797 030604 012737 000000 002274  MOV    #0,TMP1
4798 030612 012700 003426          MOV    #BUF,R0        ;SETUP AND WRITE
4799 030616 012701 000201          MOV    #129.,R1       ;129 WORDS
4800 030622 012720 125252 299:   MOV    #125252,(R0)+  ;WRITE
4801 030626 005301          DEC    R1              ;DONE??
4802 030630 001374          BNE    299#
4803
4804 030632 012777 003426 151516 1:   MOV    #BUF,BRLBA     ;LOAD BUS ADDRESS
4805 030640 012777 177577 151514      MOV    #-129.,BRLMP   ;WORD COUNT
4806 030646 013737 002274 002300      MOV    TMP1,GDDAT
4807 030654 053737 002272 002300      BIS    TMP0,GDDAT
4808 030662 013777 002300 151470      MOV    GDDAT,BRLDA
4809 030670 004537 015054          JSR    R5,LDFUNC      ;LOAD THE FUNCTION IN NEXT WORD
4810 030674 000012          WRITE
4811 030676 004537 015700          JSR    R5,WTCRDY     ;WAIT FOR CONTROLLER READY
4812 030702          ESCAPE SEG          ;CHECK FOR FL:LOE, ELSE EXIT SEG
      030702 104410          TRAP   C#ESCAPE
      030704 000240          .WORD  10000!-.
4813 030706 004537 014612          JSR    R5,CHERR      ;CHECK CNTLR FOR ERRORS
4814 030712          ESCAPE SEG          ;CHECK FOR FL:LOE, ELSE EXIT SEG
      030712 104410          TRAP   C#ESCAPE
      030714 000230          .WORD  10000!-.
4815
4816

```

;VERIFY WRITE WITH READ BEFORE WRCHK

TEST 35 - MULTIPLE SECTOR WRITE CHECK

```

4817
4818 030716 013737 002274 002300      MOV      TMP1,GDDAT
4819 030724 053737 002272 002300      BIS      TMP0,GDDAT
4820 030732 013777 002300 151420      MOV      GDDAT,BRLDA
4821 030740 012777 003426 151410      MOV      @BUF,BRLBA
4822 030746 012777 177577 151406      MOV      @-129.,BRLMP
4823 030754 004537 015054                JSR      R5,LDFUNC                ;LOAD THE FUNCTION IN NEXT WORD
4824 030760 000014                READ
4825 030762 004537 015700                JSR      R5,WTCRDY
4826 030766                ESCAPE  SEG                ;CHECK FOR FL:LOE, ELSE EXIT SEG
      030766 104410                TRAP    C#ESCAPE
      030770 000154                .WORD  10000#-.
4827 030772 004537 014612                JSR      R5,CHERR                ;CHECK CNTLR FOR ERRORS
4828 030776                ESCAPE  SEG                ;CHECK FOR FL:LOE, ELSE EXIT SEG
      030776 104410                TRAP    C#ESCAPE
      031000 000144                .WORD  10000#-.
4829
4830 031002                BGNSEG
      031002 104404                TRAP    C#BSEG                ;##START OF SEGMENT##
4831
4832 031004 013737 002274 002300      MOV      TMP1,GDDAT                ;GET CYLINDER
4833 031012 053737 002272 002300      BIS      TMP0,GDDAT                ;GET SECTOR
4834 031020 013777 002300 151332      MOV      GDDAT,BRLDA                ;SET DISK ADDRESS-SECTOR 0
4835 031026 062737 000002 002300      ADD      @2,GDDAT                ;SET EXPECTED + 2
4836 031034 012777 003426 151314      MOV      @BUF,BRLBA                ;SET BUS ADDRESS
4837 031042 012777 177577 151312      MOV      @-129.,BRLMP                ;WORD COUNT-SECTOR+1 WORD
4838
4839 031050 004537 015054                JSR      R5,LDFUNC                ;LOAD THE FUNCTION IN NEXT WORD
4840 031054 000002                WRCHK
4841 031056 004537 015700                JSR      R5,WTCRDY                ;WRITE CHECK
4842 031062                ESCAPE  SEG                ;WAIT FOR CONTROLLER READY?
      031062 104410                TRAP    C#ESCAPE                ;CHECK FOR FL:LOE, ELSE EXIT SEG
      031064 000042                .WORD  10001#-.
4843
4844 031066 004537 014612                JSR      R5,CHERR                ;CHECK CNTLR FOR ERRORS
4845 031072                ESCAPE  SEG                ;CHECK FOR FL:LOE, ELSE EXIT SEG
      031072 104410                TRAP    C#ESCAPE
      031074 000032                .WORD  10001#-.
4846
4847 031076 013737 002344 002302      MOV      E.DA,BDDAT                ;READ DISK ADDRESS
4848 031104 023737 002302 002300      CMP      BDDAT,GDDAT                ;IS DISK ADDRESS CORRECT
4849 031112 001404                BEQ     2#                          ;YES, BRANCH NO, REPORT ERROR
4850
4851 031114                ERDF   7.,EM63,ERR4                ;DISK ADDRESS NOT CORRECT
      031114 104455                TRAP    C#ERDF
      031116 000007                .WORD  7
      031120 007246                .WORD  EM63
      031122 007654                .WORD  ERR4
4852
4853 031124                2#:  CKLOOP
      031124 104406                TRAP    C#CLP1
4854
4855 031126                ENDSEG                ;##END OF SEGMENT##
      031126                10001#:
      031126 104405                TRAP    C#ESEG
4856
4857 031130 005237 002272                INC     TMP0                ;NEXT SECTOR

```

***TEST 35** - MULTIPLE SECTOR WRITE CHECK

```

4858 031134 022737 000046 002272          CMP      #46, TMPO          ;AT END?
4859 031142 001233                          BNE      1#                ;NO, GO BACK
4860 031144                                ENDSEG                      ;##END OF SEGMENT##
                                10000# :
                                TRAP    C#ESEG
4861 031144 104405          ENDTST                      ;**END OF TEST**
                                L10075:
                                TRAP    C#ETST
4862 031146 104401          .SBTTL  **TEST 36** - FORCE DCK WITH WRITE CHECK
4863
4864 031150          BGNTST                      ;**START OF TEST**
4865
4866 031150          STARS
                                ;*****
                                ;FORCE A DCK WITH WRITE CHECK. THIS IS DONE BY WRITING
                                ;A SECTOR AND CHANGING A WORD IN MEMORY BEFORE WRITE CHECK
                                ;IS ISSUED..
                                STARS
                                ;*****
4871
4872 031150 004737 015764          JSR      PC, HDHOME        ;HEADS OVER TRACK 0
4873 031154                                CKERFG                      ;HEADS GO HOME OKAY
                                TRAP    C#EXIT
                                .WORD   L10076-.
4874
4875 031166                                BGNSEG                      ;##START OF SEGMENT##
                                TRAP    C#BSEG
4876
4877 031170 012700 003426          MOV      #BUF, R0          ;SETUP AND WRITE
4878 031174 012701 000200          MOV      #128, R1         ;128 WORDS
4879 031200 012720 125252          299# : MOV      #125252, (R0)+ ;WRITE
4880 031204 005301                          DEC      R1                ;DONE??
4881 031206 001374                          BNE      299#
4882
4883 031210 012777 003426 151140     MOV      #BUF, SRLBA      ;LOAD BUS ADDRESS
4884 031216 012777 177600 151136     MOV      #-128, SRLMP     ;WORD COUNT
4885 031224 005077 151130          CLR      SRLDA            ;CLEAR DISK ADDRESS
4886 031230 004537 015054          JSR      R5, LDFUNC       ;LOAD THE FUNCTION IN NEXT WORD
4887 031234 000012                          WRITE
4888 031236 004537 015700          JSR      R5, WTCRDY      ;WAIT FOR CONTROLLER READY
4889 031242                                ESCAPE  SEG               ;CHECK FOR FL:LOE, ELSE EXIT SEG
                                TRAP    C#ESCAPE
                                .WORD   10000#-.
4890 031246 004537 014612          JSR      R5, CHERR       ;CHECK CNTLR FOR ERRORS
4891 031252                                ESCAPE  SEG               ;CHECK FOR FL:LOE, ELSE EXIT SEG
                                TRAP    C#ESCAPE
                                .WORD   10000#-.
4892                                ;VERIFY WRITE WITH READ BEFORE WRCHK
4893
4894 031256 005077 151076          CLR      SRLDA
4895 031262 012777 003426 151066     MOV      #BUF, SRLBA
4896 031270 012777 177600 151064     MOV      #-128, SRLMP
4897 031276 004537 015054          JSR      R5, LDFUNC       ;LOAD THE FUNCTION IN NEXT WORD
4898 031302 000014                          READ
4899 031304 004537 015700          JSR      R5, WTCRDY      ;CHECK FOR FL:LOE, ELSE EXIT SEG
4900 031310                                ESCAPE  SEG
                                TRAP    C#ESCAPE
                                .WORD   10000#-.

```


TEST 37 - FORCE DCK WITH WRITE CHECK INTERRUPT

```

4940 031450          STARS
;*****
4941
4942 031450 004737 015764      JSR    PC,HDHOME      ;HEADS OVER TRACK 0
4943 031454          CKERFG      ;HEADS GO HOME OKAY
      031462 104432      TRAP    C#EXIT
      031464 000322      .WORD   L10077-.
4944
4945 031466          BGNSEG      ;##START OF SEGMENT##
      031466 104404      TRAP    C#BSEG
4946
4947 031470 012700 003426      MOV    #BUF,RO        ;SETUP AND WRITE
4948 031474 012701 000200      MOV    #128.,R1      ;128 WORDS
4949 031500 012720 125252      299#: MOV    #125252,(RO)+ ;WRITE
4950 031504 005301          DEC    R1              ;DONE??
4951 031506 001374          BNE    299#
4952
4953 031510 012777 003426 150640 MOV    #BUF,@RLBA     ;LOAD BUS ADDRESS
4954 031516 012777 177600 150636 MOV    #-128.,@RLMP   ;WORD COUNT
4955 031524 005077 150630      CLR    @RLDA          ;CLEAR DISK ADDRESS
4956 031530 004537 015054      JSR    R5,LDFUNC     ;LOAD THE FUNCTION IN NEXT WORD
4957 031534 000012          WRITE
4958 031536 004537 015700      JSR    R5,WTCRDY     ;WAIT FOR CONTROLLER READY
4959 031542          ESCAPE   SEG      ;CHECK FOR FL:LOE, ELSE EXIT SEG
      031542 104410      TRAP    C#ESCAPE
      031544 000240      .WORD   10000#-.
4960 031546 004537 014612      JSR    R5,CHERR      ;CHECK CNTLR FOR ERRORS
4961 031552          ESCAPE   SEG      ;CHECK FOR FL:LOE, ELSE EXIT SEG
      031552 104410      TRAP    C#ESCAPE
      031554 000230      .WORD   10000#-.
;VERIFY WRITE WITH READ BEFORE WRCHK
4962
4963
4964 031556 005077 150576      CLR    @RLDA
4965 031562 012777 003426 150566 MOV    #BUF,@RLBA
4966 031570 012777 177600 150564 MOV    #-128.,@RLMP
4967 031576 004537 015054      JSR    R5,LDFUNC     ;LOAD THE FUNCTION IN NEXT WORD
4968 031602 000014          READ
4969 031604 004537 015700      JSR    R5,WTCRDY
4970 031610          ESCAPE   SEG      ;CHECK FOR FL:LOE, ELSE EXIT SEG
      031610 104410      TRAP    C#ESCAPE
      031612 000172      .WORD   10000#-.
4971 031614 004537 014612      JSR    R5,CHERR      ;CHECK CNTLR FOR ERRORS
4972 031620          ESCAPE   SEG      ;CHECK FOR FL:LOE, ELSE EXIT SEG
      031620 104410      TRAP    C#ESCAPE
      031622 000162      .WORD   10000#-.
4973
4974 031624          BGNSEG      ;##START OF SEGMENT##
      031624 104404      TRAP    C#BSEG
4975
4976 031626          SETPRI   #PRI00
      031626 012700 000000      MOV    #PRI00,RO
      031632 104441      TRAP    C#SPRI
4977 031634 005037 002256      CLR    INTFLG        ;CLEAR INTERRUPT OCCURANCE FLAG
4978 031640 005037 003426      CLR    BUF
4979 031644 005077 150510      CLR    @RLDA
4980 031650 012777 003426 150500 MOV    #BUF,@RLBA     ;SETTING SECTOR 40 OF CYL. ADDR.
4981 031656 012777 177600 150476 MOV    #-128.,@RLMP   ;WORD COUNT

```

***TEST 37** - FORCE DCK WITH WRITE CHECK INTERRUPT

```

4982
4983 031664 004537 015054      JSR      R5,LDFUNC          ;LOAD THE FUNCTION IN NEXT WORD
4984 031670 000102              WRCHK!INTEN                ;WRITE CHECK
4985 031672 004537 015700      JSR      R5,WTCRDY        ;WAIT FOR CONTROLLER READY
4986 031676              CKLOOP
4986 031676 104406              TRAP    C#CLP1
4987              SETPRI  #PRI07          ;JSD REV A
4988 031700              SETPRI  #PRI06          ;JSD REV A
4988 031700 012700 000300      MOV      #PRI06,R0
4988 031704 104441              TRAP    C#SPRI
4989
4990 031706 005737 002256      TST      INTFLG          ;DID INTERRUPT OCCUR
4991 031712 001004              BNE     2#              ;YES OKAY
4992
4993 031714              ERRDF   24.,EM66,ERRO    ;NO INTERRUPT FROM DCK
4993 031714 104455              TRAP    C#ERDF
4993 031716 000030              .WORD  24
4993 031720 007421              .WORD  EM66
4993 031722 007510              .WORD  ERRO
4994
4995 031724              2#:    ESCAPE  SEG          ;CHECK FOR FL:LOE, ELSE EXIT SEG
4995 031724 104410              TRAP    C#ESCAPE
4995 031726 000054              .WORD  10001#-.
4996
4997 031730 013737 002340 002272      MOV      E.CS,TMPO      ;GET RLCS
4998 031736 042737 001777 002272      BIC      #1777,TMPO     ;SAVE ERROR BITS
4999 031744 022737 104000 002272      CMP      #BIT15!BIT11,TMPO ;DCK SET.
5000 031752 001402              BEQ     1#              ;YES, CONTINUE
5001
5002 031754 004537 014612              JSR      R5,CHERR
5003 031760              1#:    CKLOOP
5003 031760 104406              TRAP    C#CLP1
5004
5005 031762 022737 104000 002272      CMP      #BIT15!BIT11,TMPO
5006 031770 001404              BEQ     3#
5007 031772              ERRDF   25.,EM65,ERRO
5007 031772 104455              TRAP    C#ERDF
5007 031774 000031              .WORD  25
5007 031776 007364              .WORD  EM65
5007 032000 007510              .WORD  ERRO
5008
5009 032002              3#:
5010
5011 032002              ENDSEG                    ;##END OF SEGMENT##
5011 032002 10001#:              TRAP    C#ESEG
5012 032004              ENDSEG                    ;##END OF SEGMENT##
5012 032004 10000#:              TRAP    C#ESEG
5013 032006              ENDTST                    ;**END OF TEST**
5013 032006 L10077:              TRAP    C#ETST
5014
5015              .SBTTL  **TEST 38** - CHECK ZERO FILL ON WRITE WITH WRITE CHECK
5016
5017 032010              BGNTST                    ;**START OF TEST**
5018

```

••TEST 38•• - CHECK ZERO FILL ON WRITE WITH WRITE CHECK

```

5019 032010          STARS
                    ;*****
5020                ;WHEN WRITING PARTIAL SECTORS (LESS THAN 128 WORDS) THE
5021                ;CONTROLLER WILL FILL IN THE REMAINING PORTION OF
5022                ;THE SECTOR WITH ZERO WORDS. CHECK THIS FEATURE CAN BE WRITE CHECKED
5023                ;WITH WORD COUNTS FROM 1 TO 127
5024 032010          STARS
                    ;*****
5025
5026 032010 004737 015764      JSR    PC,MDHOME      ;HEADS OVER TRACK 0
5027 032014          CKERFG          ;HEADS GO HOME OKAY
                    032022 104432      TRAP   C#EXIT
                    032024 000274      .WORD  L10100-.
5028
5029 032026          BGNSEG          ;#START OF SEGMENT#
                    032026 104404      TRAP   C#BSEG
5030
5031 032030 012737 000001 002274  MOV   #1,TMP1      ;START WITH 1 WORD WRITE
5032 032036 012700 003426 33:    MOV   #BUF,RO      ;WRITE BUFFER WITH 52525, WE'LL
5033 032042 012701 000200          MOV   #128,,R1     ;WRITE 128 WORDS ALL THOUGH WE'RE
5034 032046 012720 052525 3:     MOV   #52525,(RO). ;ONLY GOING TO TRANSFER < 128
5035 032052 005301          DEC   R1           ;DONE WITH BUFFER?
5036 032054 001374          BNE   3:          ;NO, GO BACK
5037 032056 013700 002274          MOV   TMP1,RO      ;GET TRANSFER WORD COUNT
5038 032062 005400          NEG   RO           ;NEGATE FOR RLMP
5039 032064 010077 150272          MOV   RO,BRLMP    ;STORE WORD COUNT AWAY
5040 032070 012777 003426 150260 MOV   #BUF,BRLBA  ;SET UP RLBA
5041 032076 005077 150256          CLR   BRLDA
5042 032102 004537 015054          JSR   R5,LDFUNC   ;LOAD THE FUNCTION IN NEXT WORD
5043 032106 000012          WRITE          ;WRITE IT
5044 032110 004537 015700          JSR   R5,WTCRDY  ;WAIT FOR WRITE TO FINISH
5045 032114          ESCAPE SEG      ;CHECK FOR FL:LOE, ELSE EXIT SEG
                    032114 104410      TRAP   C#ESCAPE
                    032116 000200      .WORD  10000!-.
5046
5047 032120 004537 014612          JSR   R5,CHERR    ;CHECK CNTLR FOR ERRORS
5048 032124          ESCAPE SEG      ;CHECK FOR FL:LOE, ELSE EXIT SEG
                    032124 104410      TRAP   C#ESCAPE
                    032126 000170      .WORD  10000!-.
5049                ;VERIFY WRITE WITH READ BEFORE WRCHK
5050
5051 032130 005077 150224          CLR   BRLDA
5052 032134 012777 003426 150214 MOV   #BUF,BRLBA
5053 032142 013700 002274          MOV   TMP1,RO
5054 032146 005400          NEG   RO
5055 032150 010077 150206          MOV   RO,BRLMP
5056 032154 004537 015054          JSR   R5,LDFUNC   ;LOAD THE FUNCTION IN NEXT WORD
5057 032160 000014          READ
5058 032162 004537 015700          JSR   R5,WTCRDY  ;CHECK FOR FL:LOE, ELSE EXIT SEG
5059 032166          ESCAPE SEG
                    032166 104410      TRAP   C#ESCAPE
                    032170 000126      .WORD  10000!-.
5060 032172 004537 014612          JSR   R5,CHERR    ;CHECK CNTLR FOR ERRORS
5061 032176          ESCAPE SEG      ;CHECK FOR FL:LOE, ELSE EXIT SEG
                    032176 104410      TRAP   C#ESCAPE
                    032200 000116      .WORD  10000!-.
5062

```


••TEST 38•• - CHECK ZERO FILL ON WRITE WITH WRITE CHECK

```

5063 032202          BGNSEG                                ;##START OF SEGMENT##
      032202 104404 TRAP C#BSEG
5064 032204 012777 003426 150144 MOV #BUF, @RLBA ;SET UP TO READ
5065 032212 013700 002274 MOV TMP1, R0
5066 032216 005400 NEG R0
5067 032220 010077 150136 MOV R0, @RLMP
5068 032224 005077 150130 CLR @RLDA ;SECTOR
5069 032230 004537 015054 JSR R5, LDFUNC ;LOAD THE FUNCTION IN NEXT WORD
5070 032234 000002 WRCHK
5071 032236 004537 015700 JSR R5, WTCRDY ;WAIT TIL WE FINISH THE WRCHK
5072 032242 ESCAPE SEG ;CHECK FOR FL:LOE, ELSE EXIT SEG
      032242 104410 TRAP C#ESCAPE
      032244 000034 .WORD 10001#-.

5073
5074 032246 004537 014612 JSR R5, CHERR ;CHECK CNTLR FOR ERRORS
5075 032252 005737 002236 TST T.CRC ;WAS ERROR A DCK??
5076 032256 001003 BNE 8# ;YES, GIVE MOR INFO
5077 032260 10# : ESCAPE SEG ;CHECK FOR FL:LOE, ELSE EXIT SEG
      032260 104410 TRAP C#ESCAPE
      032262 000016 .WORD 10001#-.

5078 032264 000405 BR 99# ;SKIP AROUND
5079 032266 8# : CKLOOP ;YES, CHECK FOR LOOP FIRST
      032266 104406 TRAP C#CLP1
5080 032270 ERRDF 37., EM64, ERR14
      032270 104455 TRAP C#ERDF
      032272 000045 .WORD 37
      032274 007321 .WORD EM64
      032276 010414 .WORD ERR14

5081 032300 99# : ;EXIT TEST
5082 032300 ENDSEG ;##END OF SEGMENT##
      032300 10001# : TRAP C#ESEG
      032300 104405

5083
5084 032302 005237 002274 000200 INC TMP1
5085 032306 023727 002274 000200 CMP TMP1, #128.
5086 032314 001250 BNE 33#
5087
5088 032316 ENDSEG ;##END OF SEGMENT##
      032316 10000# : TRAP C#ESEG
      032316 104405

5089 032320 ENDTST ;##END OF TEST##
      032320 L10100 : TRAP C#ETST
      032320 104401

5090
5091 .SBTTL ••TEST 39•• - EXTENDED CHECK OF WRITE CHECK FUNCTION
5092
5093 032322 BGNSTST ;##START OF TEST##
5094
5095 032322 STARS
      ;*****
5096 ;CHECK OF WRITE CHECK LOGIC UNDER FLAG MODE
5097 ;TEST IS DONE WITH ALL BIT PATTERNS
5098 ; WE WILL WRITE CHECK A FULL SECTOR (128 WORDS) FROM
5099 ;MEMORY (BUF). WE CHECK THAT NO ERRORS OCCUR.
5100 032322 STARS
      ;*****
5101

```

TEST 39 - EXTENDED CHECK OF WRITE CHECK FUNCTION

```

5102 032322 004737 015764      JSR      PC,MDHOME      ;HEADS OVER TRACK 0
5103 032326      CKERFG      ;HEADS GO HOME OKAY
      032334 104432      TRAP      C#EXIT
      032336 000306      .WORD     L10101-.
5104
5105 032340 022737 000001 002232      CMP      #1,T.DRIVE      ;CHECK TYPE OF DRIVE
5106 032346 001003      BNE      22#             ;NOT RLO1 THEN BRANCH
5107 032350 012703 002670      MOV      #MDRTAB,R3      ;MOV #MDRTAB TO R3
5108 032354 000402      BR       33#             ;THEN BRANCH
5109 032356 012703 003050      22# :   MOV      #HTAB,R3      ;MOV #HTAB TO R3 (RLO2)
5110
5111 032362      33# :   BGNSEG      ;START OF SEGMENT
      032362 104404      TRAP      C#BSEG
5112
5113 032364 012700 003426      298# :   MOV      #BUF,R0      ;SETUP AND WRITE
5114 032370 012701 000200      MOV      #128.,R1        ;128 WORDS
5115 032374 011302      MOV      (R3),R2         ;GET PATTERN
5116 032376 052702 100000      BIS      #BIT15,R2
5117 032402 010220      299# :   MOV      R2,(R0)
5118 032404 005301      DEC      R1              ;DONE??
5119 032406 001375      BNE      299#
5120
5121 032410 012777 003426 147740      MOV      #BUF,BRLBA      ;LOAD BUS ADDRESS
5122 032416 012777 177600 147736      MOV      #-128.,BRLMP    ;WORD COUNT
5123 032424 005077 147730      CLR      BRLDA           ;CLEAR DISK ADDRESS
5124 032430 004537 015054      JSR      R5,LDFUNC        ;LOAD THE FUNCTION IN NEXT WORD
5125 032434 000012      WRITE
5126 032436 004537 015700      JSR      R5,WTCRDY       ;WAIT FOR CONTROLLER READY
5127 032442      ESCAPE      SEG         ;CHECK FOR FL:LOE, ELSE EXIT SEG
      032442 104410      TRAP      C#ESCAPE
      032444 000176      .WORD     10000#-.
5128 032446 004537 014612      JSR      R5,CHERR        ;CHECK CNTLR FOR ERRORS
5129 032452      ESCAPE      SEG         ;CHECK FOR FL:LOE, ELSE EXIT SEG
      032452 104410      TRAP      C#ESCAPE
      032454 000166      .WORD     10000#-.
5130 032456      BGNSEG      ;##START OF SEGMENT##
      032456 104404      TRAP      C#BSEG
5131
5132      ;VERIFY WRITE WITH READ BEFORE WRCHK
5133
5134 032460 005077 147674      CLR      BRLDA
5135 032464 012777 003426 147664      MOV      #BUF,BRLBA
5136 032472 012777 177600 147662      MOV      #-128.,BRLMP
5137 032500 004537 015054      JSR      R5,LDFUNC        ;LOAD THE FUNCTION IN NEXT WORD
5138 032504 000014      READ
5139 032506 004537 015700      JSR      R5,WTCRDY       ;CHECK FOR FL:LOE, ELSE EXIT SEG
5140 032512      ESCAPE      SEG
      032512 104410      TRAP      C#ESCAPE
      032514 000076      .WORD     10001#-.
5141 032516 004537 014612      JSR      R5,CHERR        ;CHECK CNTLR FOR ERRORS
5142 032522      ESCAPE      SEG         ;CHECK FOR FL:LOE, ELSE EXIT SEG
      032522 104410      TRAP      C#ESCAPE
      032524 000066      .WORD     10001#-.
5143
5144 032526      BGNSEG      ;##START OF SEGMENT##
      032526 104404      TRAP      C#BSEG
5145

```

TEST 39 - EXTENDED CHECK OF WRITE CHECK FUNCTION

```

5146 032530          3$:
5147 032530 005077 147624      CLR      @RLDA
5148 032534 012777 177600 147620  MOV      @-128.,@RLMP      ;WORD COUNT
5149 032542 012777 003426 147606  MOV      @BUF,@RLBA      ;BUS ADDRESS
5150 032550 004537 015054      JSR      R5,LDFUNC      ;LOAD THE FUNCTION IN NEXT WORD
5151 032554 000002      WRCHK      ;WRITE CHECK
5152
5153 032556 004537 015700      JSR      R5,WTCRDY      ;WAIT FOR CONTROLLER READY
5154 032562          ESCAPE SEG      ;CHECK FOR FL:LOE, ELSE EXIT SEG
      032562 104410      TRAP     C#ESCAPE
      032564 000024      .WORD    10002#-.
5155
5156 032566 004537 014612      JSR      R5,CHERR      ;CHECK CNTLR FOR ERRORS
5157 032572 005737 002236      TST     T.CRC
5158 032576 001404      BEQ     4#
5159
5160 032600          ERRHRD 410.,ERR15,EM70
      032600 104456      TRAP     C#ERHRD
      032602 000632      .WORD    410
      032604 010462      .WORD    ERR15
      032606 007472      .WORD    EM70
5161
5162 032610          4$:
5163
5164 032610          ENDSEG      ;##END OF SEGMENT##
      032610          10002#:
5165 032612 104405      TRAP     C#ESEG      ;##END OF SEGMENT##
      032612          10001#:
      032612 104405      TRAP     C#ESEG
5166
5167 032614 005723          TST     (R3)+
5168 032616 022737 000001 002232  CMP     @1,T.DRIVE      ;RL01 OR RL02?
5169 032624 001003          BNE     60#             ;RL02? THEN BRANCH
5170 032626 020327 003046      CMP     R3,@HDREND      ;LAST OF PATERN?
5171 032632 000402          BR      77#
5172 032634 020327 003234 60#:  CMP     R3,@#END      ;LAST OF PATTERN (RL02)
5173 032640 001251          77#:  BNE     298#
5174
5175 032642          ENDSEG      ;##END OF SEGMENT##
      032642          10000#:
      032642 104405      TRAP     C#ESEG
5176 032644          ENDTST      ;##END OF TEST##
      032644          L10101:
      032644 104401      TRAP     C#ETST
5177          .SBTTL  **TEST 40** - READ WITHOUT HEADER COMPARE FUNCTION
5178
5179 032646          STARS
5180          ;*****
5181          ;TEST THAT READ WITHOUT HEADER VERIFICATION WORKS. THIS FUNCTION SHOULD
5182          ;READ AT THE NEXT SECTOR ENCOUNTERED. SET THE RLDA TO 0
5183          ;AND ISSUE THE FUNCTION IN FLAG MODE. UPON COMPLETION CHECK
5184          ;FOR ERRORS
5184 032646          STARS
5185          ;*****
5185 032646          BGNTST      ;**START OF TEST**
5186

```


***TEST 40** - READ WITHOUT HEADER COMPARE FUNCTION

```

5187 032646 004737 015764      JSR    PC,HDHOME      ;HEADS OVER TRACK 0
5188 032652                      CKERFG                ;HEADS GO HOME OKAY
      032660 104432      TRAP   C#EXIT
      032662 000052      .WORD  L10102-.
5189
5190 032664                      BGNSEG                ;##START OF SEGMENT##
      032664 104404      TRAP   C#BSEG
5191
5192 032666 012777 177600 147466  MOV   #-128.,@RLMP    ;SET UP WORD COUNT
5193 032674 012777 003426 147454  MOV   @BUF,@RLBA     ;SETUP BUS ADDRESS
5194 032702 012777 177777 147450  MOV   #-1,@RLDA     ;HEADER SHOULDN'T MATTER
5195 032710 004537 015054          JSR   R5,LDFUNC      ;LOAD THE FUNCTION IN NEXT WORD
5196 032714 000016          RDNHD                ;READ DATA WITHOUT HEADER VERIFY
5197 032716 004537 015700          JSR   R5,WTCRDY     ;WAIT FOR IT TO FINISH
5198 032722                      ESCAPE                ;CHECK FOR FL:LOE, ELSE EXIT SEG
      032722 104410      TRAP   C#ESCAPE
      032724 000006      .WORD  10000#-.
5199
5200 032726 004537 014612          JSR   R5,CHERR      ;CHECK CNTLR FOR ERRORS
5201
5202 032732                      ENDSEG                ;##END OF SEGMENT##
      032732          10000#:
5203 032734 104405      TRAP   C#ESEG
      032734          ENDTST
      032734 104401      TRAP   C#ETST

```

.SBTTL ***TEST 41** - READ WITHOUT HEADER COMPARE FUNCTION INTERRUPT

```

5204
5205
5206
5207 032736          BGNST                ;##START OF TEST##
5208
5209 032736          STARS
      ;*****
      ;TEST THAT READ WITHOUT HEADER VERIFICATION WORKS IN
      ;INTERRUPT MODE.
      STARS
      ;*****
5210
5211
5212 032736
5213
5214 032736 004737 015764      JSR    PC,HDHOME      ;HEADS OVER TRACK 0
5215 032742                      CKERFG                ;HEADS GO HOME OKAY
      032750 104432      TRAP   C#EXIT
      032752 000114      .WORD  L10103-.
5216
5217 032754                      BGNSEG                ;##START OF SEGMENT##
      032754 104404      TRAP   C#BSEG
5218
5219 032756 005037 002256          CLR   INTFLG        ;CLEAR INTERRUPT OCCURANCE FLAG
5220 032762 012777 177600 147372  MOV   #-128.,@RLMP    ;SET UP WORD COUNT FOR ONE SECTOR
5221 032770 012777 003426 147360  MOV   @BUF,@RLBA     ;SETUP BUFFER ADDRESS
5222 032776 012777 177777 147354  MOV   #-1,@RLDA     ;DISK ADDRESS IS A DON'T CARE
5223 033004          SETPRI @PRI00
      033004 012700 000000      MOV   @PRI00,R0
      033010 104441      TRAP   C#SPRI
5224 033012 004537 015054          JSR   R5,LDFUNC      ;LOAD THE FUNCTION IN NEXT WORD
5225 033016 000116          RDNHD!INTEN         ;INTERRUPT ENABLED
5226 033020 004537 015700          JSR   R5,WTCRDY     ;WAIT FOR INTERRUPT
5227

```

***TEST 41** - READ WITHOUT HEADER COMPARE FUNCTION INTERRUPT

;JSD REV A

```

5228 033024          SETPRI  @PRI06
      033024 012700 000300  MOV    @PRI06,RO
      033030 104441  TRAP   C@SPRI
5229 033032          ESCAPE  SEG          ;CHECK FOR FL:LOE, ELSE EXIT SEG
      033032 104410  TRAP   C@ESCAPE
      033034 000030  .WORD  10000@-
5230
5231 033036 005737 002256  TST    INTFLG          ;DID IT INTERRUPT
5232 033042 001004          BNE    1@             ;IF INTERRUPT GO TO 1@
5233
5234 033044          ERRDF   40.,EM40,ERRO ;NO INTERRUPT
      033044 104455  TRAP   C@ERDF
      033046 000050  .WORD  40
      033050 006321  .WORD  EM40
      033052 007510  .WORD  ERRO
5235 033054          1@:   ESCAPE  SEG          ;CHECK FOR FL:LOE, ELSE EXIT SEG
      033054 104410  TRAP   C@ESCAPE
      033056 000006  .WORD  10000@-
5236
5237 033060 004537 014612  JSR    R5,CHERR          ;CHECK CNTLR FOR ERRORS
5238
5239 033064          ENDSEG          ;##END OF SEGMENT##
      033064 10000@:  TRAP   C@ESEG
5240 033066          ENDTST          ;**END OF TEST**
      033066 104405  L10103: TRAP   C@ETST
      033066 104401
5241
5242          .SBTTL  **TEST 42** - CHECK RD W/O HDR CMP ACTUALLY READS
5243
5244 033070          BGNTST          ;**START OF TEST**
5245
5246 033070          STARS
      ;*****
      ;CHECK THAT THE READ W/O HDR CMP FUNCTION ACTUALLY READS (INTO MEMORY)
      ;WE WILL WRITE A PATTERN INTO MEMORY AND THEN ISSUE
      ;A READ TO OVERLAY THAT PATTERN. AFTER THE READ
      ;WE CHECK TO SEE IF THE WRITTEN PATTERN HAS CHANGED.
      ;IF NOT WE ISSUE IT AGAIN AT THE SAME SECTION AFTER
      ;HAVING MODIFIED OUR PATTERN IN MEMORY (SINCE THERE IS
      ;ONE CHANCE THAT THE DISK COULD HAVE OUR PATTERN). AFTER
      ;THE SECOND READ WE CHECK THE BUFFER AGAIN. IF IT'S
      ;NOT CHANGED WE REPORT AN ERROR
      STARS
      ;*****
5247
5248
5249
5250
5251
5252
5253
5254
5255
5256 033070
5257
5258 033070 004737 015764  JSR    PC,H0HOME          ;HEADS OVER TRACK 0
5259 033074          CKERFG          ;HEADS GO HOME OKAY
      033102 104432  TRAP   C@EXIT
      033104 000160  .WORD  L10104-.
5260
5261 033106          BGNSEG          ;##START OF SEGMENT##
      033106 104404  TRAP   C@BSEG
5262
5263 033110 012737 024350 002272  MOV    @24350,TMPO        ;SET PATTERN TO WRITE
5264 033116 005037 002274          CLR    TMP1              ;CLEAR PASS INDICATOR
5265 033122 012700 003426  1@:   MOV    @BUF,RO        ;SET UP BUFFER BEGINNING

```

TEST 42 - CHECK RD W/O HDR CMP ACTUALLY READS

```

5266 033126 012701 000200      MOV      #128.,R1
5267 033132 013720 002272      2$:     MOV      TMO,(R0)+      ;WRITE BUFFER
5268 033136 005301              DEC      R1              ;DONE??
5269 033140 001374              BNE     2$              ;NO, GO BACK
5270 033142 012777 000050 147210  MOV      #40.,@RLDA      ;LOAD DISK ADDRESS TO NONSENSE
5271 033150 012777 177600 147204  MOV      #-128.,@RLMP    ;SET WORD COUNT
5272 033156 012777 003426 147172  MOV      @BUF,@RLBA      ;LOAD BUS ADDRESS
5273 033164 012737 003426 002300  MOV      @BUF,GDDAT      ;FOR ERROR PRINT
5274
5275 033172 004537 015054          JSR      R5,LDFUNC        ;LOAD THE FUNCTION IN NEXT WORD
5276 033176 000016          RDNHD
5277 033200 004537 015700          JSR      R5,WTCRDY       ;READ W/O HDR CMP
5278 033204 104410          ESCAPE  SEG              ;WAIT FOR CONTROLLER READY
033204 000054          TRAP   C#ESCAPE         ;CHECK FOR FL:LOE, ELSE EXIT SEG
033206
5279
5280 033210 004537 014612          JSR      R5,CHERR        ;CHECK CNTLR FOR ERRORS
5281 033214 104410          ESCAPE  SEG              ;CHECK FOR FL:LOE, ELSE EXIT SEG
033214 000044          TRAP   C#ESCAPE
033216
5282
5283 033220 012702 003426      4$:     MOV      @BUF,R2        ;SET TO START COMPARING DATA
5284 033224 022237 002272      CMP      (R2)+,TMO       ;DID DATA CHANGE?
5285 033230 001014          BNE     6$              ;YES, CHECK FOR END
5286
5287
5288
5289 033232 005737 002274          TST     TMP1             ;DATA DIDN'T CHANGE, CHECK
5290 033236 001005          BNE     5$              ;IF 1ST OR 2ND TIME?
5291
5292 033240 005237 002274          INC     TMP1             ;2ND-REPORT 1ST-TRY AGAIN
5293 033244 005137 002272          COM     TMO
5294 033250 000724          BR      1$              ;INC PASS COUNT
5295
5296 033252 104455          ERRDF  20.,EM55,ERR9    ;COMPLIMENT PATTERN
033252 000024          TRAP   C#ERDF          ;GODO IT AGAIN
033254
033256 20
033260 006652          .WORD  EM55
010102          .WORD  ERR9
5297
5298 033262
5299
5300 033262          ENDSEG                  ;##END OF SEGMENT##
033262 104405          10000$: TRAP   C#ESEG
5301 033264          ENDTST                  ;**END OF TEST**
033264          L10104: TRAP   C#ETST
033264 104401
5302
5303          .SBTTL  **TEST 43** - CHECK RLBA INCREMENT WITH RD W/O HDR CMP
5304
5305 033266          BGNTST                  ;**START OF TEST**
5306
5307 033266          STARS
5308          ;*****
5309          ;CHECK THAT THE RLBA WILL INCREMENT WITH THE READ W/O HDR CMP
          ;THE RLBA SHOULD CONTAIN "BUF +256." AFTER A FULL SECTOR

```


***TEST 43** - CHECK RLBA INCREMENT WITH RD W/O HDR CMP

```

5310                                     ;READ.
5311 033266                               STARS
                                           ;*****
5312
5313 033266 004737 015764                 JSR    PC,HDRHOME      ;HEADS OVER TRACK 0
5314 033272                                     CKERFG                ;HEADS GO HOME OKAY
      033300 104432                         TRAP   C#EXIT
      033302 000120                         .WORD L10105-.
5315
5316 033304                                     BGNSEG
      033304 104404                         TRAP   C#BSEG          ;##START OF SEGMENT##
5317
5318 033306 012777 000050 147044          MOV    #40.,BRLDA
5319 033314 012777 003426 147034          MOV    #BUF,BRLBA     ;SET UP BUS ADDRESS
5320 033322 012777 177600 147032          MOV    #-128.,BRLMP  ;WORD COUNT
5321 033330 012737 003426 002300          MOV    #BUF,GDDAT    ;FORM EXPECTED BUS ADDRESS
5322 033336 062737 000400 002300          ADD    #256.,GDDAT   ;AFTER READ
5323
5324 033344 004537 015054                 JSR    R5,LDFUNC      ;LOAD THE FUNCTION IN NEXT WORD
5325 033350 000016                                     RDNHD                ;READ W/O HDR CMP
5326 033352 004537 015700                 JSR    R5,WTCRDY     ;WAIT FOR CONTROLLER READY
5327 033356                                     ESCAPE SEG           ;CHECK FOR FL:LOE, ELSE EXIT SEG
      033356 104410                         TRAP   C#ESCAPE
      033360 000040                         .WORD 10000#-.
5328
5329 033362 004537 014612                 JSR    R5,CHERR      ;CHECK CNTLR FOR ERRORS
5330 033366                                     ESCAPE SEG           ;CHECK FOR FL:LOE, ELSE EXIT SEG
      033366 104410                         TRAP   C#ESCAPE
      033370 000030                         .WORD 10000#-.
5331 033372 013737 002342 002302          MOV    E.BA,BDDAT    ;READ 'RLBA' FOR PRESENT ADDRESS
5332 033400 023737 002302 002300          CMP    BDDAT,GDDAT  ;DID 'BA' INCREMENT PROPERLY?
5333 033406 001404                                     BEQ    1#            ;YES, CONTINUE
5334
5335 033410                                     ERRDF
      033410 104455                         TRAP   C#ERDF
      033412 000025                         .WORD 21
      033414 006717                         .WORD EM53
      033416 007654                         .WORD ERR4
5336
5337 033420                                     1#:
5338
5339 033420                                     ENDSEG
      033420                                     10000#:
      033420 104405                         TRAP   C#ESEG        ;##END OF SEGMENT##
5340 033422                                     ENDTST
      033422                                     L10105:
      033422 104401                         TRAP   C#ETST        ;**END OF TEST**
5341
5342                                     .SBTTL  **TEST 44** - CHECK RLDA DOES INCREMENT WITH RD W/O HDR CMP
5343
5344 033424                                     BGNTST
5345
5346 033424                                     STARS
                                           ;*****
5347                                     ;CHECK THAT THE RLDA DOES INCREMENT BY ONE AFTER A
5348                                     ;FULL SECTOR READ W/O HDR CMP
5349                                     ;AFTER THE READ THE RLDA SHOULD STILL BE THE INITIAL RLDA + 1

```

TEST 44 - CHECK RLDA DOES INCREMENT WITH RD W/O HDR CMP

```

5350 033424          STARS
                    ;*****
5351
5352 033424 004737 015764      JSR      PC,MDHOME      ;HEADS OVER TRACK 0
5353 033430          CKERFG      ;HEADS GO HOME OKAY
                    TRAP      C#EXIT
                    .WORD     L10106-.
5354
5355 033442          BGNSEG      ;##START OF SEGMENT##
                    TRAP      C#BSEG
5356
5357 033444 012737 000050 002300  MOV      #40.,GDDAT      ;DA TO NONSENSE
5358 033452 013777 002300 146700  MOV      GDDAT,RLDA      ;SETUP DISK ADDRESS
5359 033460 005237 002300          INC      GDDAT
5360 033464 012777 177600 146670  MOV      #-128.,RLMP      ;WORD COUNT
5361 033472 012777 003426 146656  MOV      #BUF,RLBA      ;SETUP BUS ADDRESS
5362
5363 033500 004537 015054          JSR      R5,LDFUNC      ;LOAD THE FUNCTION IN NEXT WORD
5364 033504 000016          RDNHD      ;READ WITHOUT HEADER COMPARE
5365 033506 004537 015700          JSR      R5,WTCRDY      ;WAIT FOR CONTROLLER READY
5366 033512          ESCAPE      SEG      ;CHECK FOR FL:LOE, ELSE EXIT SEG
                    TRAP      C#ESCAPE
                    .WORD     10000#-.
5367
5368 033516 004537 014612          JSR      R5,CHERR      ;CHECK CNTLR FOR ERRORS
5369 033522          ESCAPE      SEG      ;CHECK FOR FL:LOE, ELSE EXIT SEG
                    TRAP      C#ESCAPE
                    .WORD     10000#-.
5370
5371 033526 013737 002344 002302  MOV      E.DA,BDDAT      ;READ DISK ADDRESS
5372 033534 023737 002300 002302  CMP      GDDAT,BDDAT      ;DID SECTOR INCREMENT PROPERLY
5373 033542 001404          BEQ      1#      ;YES, BRANCH NO, REPORT ERROR
5374
5375 033544          ERRDF      22.,EM54,ERR4
                    TRAP      C#ERDF
                    .WORD     22
                    .WORD     EM54
                    .WORD     ERR4
5376
5377 033554          1#:
5378
5379 033554          ENDSEG      ;##END OF SEGMENT##
                    10000#: TRAP      C#ESEG
5380 033556          ENDTST      ;**END OF TEST**
                    L10106: TRAP      C#ETST
5381
5382 033560          BGNMOD      HRDPRM
5383
5384 033560          BGNHRD      ;
                    .WORD     L10107-L#HARD/2
5385
5386 033562          GPRML      CNTYPE,CNT,1,YES
                    .WORD     T#CODE
                    .WORD     CNTYPE
                    .WORD     1

```

TEST 44 - CHECK RLDA DOES INCREMENT WITH RD W/O HDR CMP

5387	033570				GPRMA	CSRMSG,CSR,0.160000,177776,YES
	033570	000031			.WORD	T#CODE
	033572	033647			.WORD	CSRMSG
	033574	160000			.WORD	T#LOLIM
	033576	177776			.WORD	T#HILIM
5388	033600				GPRML	DRTYPE,TYPDR,1,YES
	033600	003130			.WORD	T#CODE
	033602	033674			.WORD	DRTYPE
	033604	000001			.WORD	1
5389	033606				GPRMA	VECMMSG,VECT,0,0,776,YES
	033606	001031			.WORD	T#CODE
	033610	033716			.WORD	VECMMSG
	033612	000000			.WORD	T#LOLIM
	033614	000776			.WORD	T#HILIM
5390	033616				GPRMD	BRMSG,PRIOR,0,340,0,7,YES
	033616	002032			.WORD	T#CODE
	033620	033663			.WORD	BRMSG
	033622	000340			.WORD	340
	033624	000000			.WORD	T#LOLIM
	033626	000007			.WORD	T#HILIM
5391	033630				GPRMD	DRMSG,DRBT,0,03400,0,7,YES
	033630	004032			.WORD	T#CODE
	033632	033725			.WORD	DRMSG
	033634	003400			.WORD	03400
	033636	000000			.WORD	T#LOLIM
	033640	000007			.WORD	T#HILIM

5392

5393 033642

ENDHRD
.EVEN

033642

L10107:

5394						
5395	033642	122	114	061	CNTYPE: .ASCIZ	/RL11/
	033645	061	000			
5396	033647	102	125	123	CSRMSG: .ASCIZ	/BUS ADDRESS/
	033652	040	101	104		
	033655	104	122	105		
	033660	123	123	000		
5397	033663	102	122	040	BRMSG: .ASCIZ	/BR LEVEL/
	033666	114	105	126		
	033671	105	114	000		
5398	033674	104	122	111	DRTYPE: .ASCIZ	/DRIVE TYPE = RL01/
	033677	126	105	040		
	033702	124	131	120		
	033705	105	040	075		
	033710	040	122	114		
	033713	060	061	000		
5399	033716	126	105	103	VECMMSG: .ASCIZ	/VECTOR/
	033721	124	117	122		
	033724	000				
5400	033725	104	122	111	DRMSG: .ASCIZ	/DRIVE/
	033730	126	105	000		

5401

5402

5403 033734

5404

5405 033734

5406

.EVEN
ENDMOD
BGNMOD SFTPRM

***TEST 44** - CHECK RLDA DOES INCREMENT WITH RD W/O HDR CMP

```

5407 033734          BGNSFT
      033734 000022      .WORD L10110-L$SOFT/2
5408
5409 033736          GPRML  DMSG,DLT,1,YES
      033736 000130      .WORD  T$CODE
      033740 034002      .WORD  DMSG
      033742 000001      .WORD  1
5410 033744          XFERF  1$
      033744 006044      .WORD  T$CODE
5411 033746          GPRMD  EMSG,ELT,D,177777,0,177777,YES
      033746 001052      .WORD  T$CODE
      033750 034107      .WORD  EMSG
      033752 177777      .WORD  177777
      033754 000000      .WORD  T$LOLIM
      033756 177777      .WORD  T$HILIM
5412 033760          1$: GPRML  CMSG,DMPCK,1,YES
      033760 003130      .WORD  T$CODE
      033762 034026      .WORD  CMSG
      033764 000001      .WORD  1
5413 033766          XFERF  2$
      033766 006044      .WORD  T$CODE
5414 033770          GPRMD  LMSG,DLMT,D,177777,1,128.,YES
      033770 004052      .WORD  T$CODE
      033772 034052      .WORD  LMSG
      033774 177777      .WORD  177777
      033776 000001      .WORD  T$LOLIM
      034000 000200      .WORD  T$HILIM
5415 034002          2$:
5416
5417 034002          ENDSFT
      034002          .EVEN
                    L10110:
5418
5419 034002          104    122    117  DMSG:  .ASCIZ  /DROP ON ERROR LIMIT/
      034005          120    040    117
      034010          116    040    105
      034013          122    122    117
      034016          122    040    114
      034021          111    115    111
      034024          124    000
5420 034026          103    117    115  CMSG:  .ASCIZ  /COMPARE DATA ON DCK/
      034031          120    101    122
      034034          105    040    104
      034037          101    124    101
      034042          040    117    116
      034045          040    104    103
      034050          113    000
5421 034052          043    040    117  LMSG:  .ASCIZ  /# OF WORDS IN ERROR REPORTED/
      034055          106    040    127
      034060          117    122    104
      034063          123    040    111
      034066          116    040    105
      034071          122    122    117
      034074          122    040    122
      034077          105    120    117
      034102          122    124    105
      034105          104    000

```

***TEST 44** - CHECK RLDA DOES INCREMENT WITH RD W/O HDR CMP

5422	034107	105	122	122	EMSG:	.ASCIZ	/ERROR LIMIT/
	034112	117	122	040			
	034115	114	111	115			
	034120	111	124	000			

5423

5424 034123

ENDMOD

5425

5426 034123

LASTAD

034124 000000

.EVEN	
.WORD	0
.WORD	0

034126 000000

034130

L\$LAST::

5427

5428

000001

.END

SYMBOL TABLE

ADR = 000020 G	CLKINT 014504	C#RDBU= 000007	EM24 005616	ERR9 010102 G
AFREG 003500	CLKTIK 014520	C#REFG= 000047	EM25 005656	EVL = 000004 G
AFTER 015414	CLNCOD 013514 G	C#RESE= 000033	EM26 005710	E#END = 002100
ANS = 000012	CMMSG 034026	C#REVI= 000003	EM27 005734	E#LOAD= 000035
ARLBA 003435	CNT = 000012	C#RFLA= 000021	EM30 006005	E.BA 002342
ARLCS 003430	CNTYPE 033642	C#RPT = 000025	EM31 006040	E.CS 002340
ARLDA 003443	COMP 003645	C#SEFG= 000046	EM32 006076	E.DA 002344
ARLMP 003451	CONT 013046	C#SPRI= 000041	EM33 006135	E.MP 002346
ASSEMB= 000010	CONTIN 012714	C#SVEC= 000037	EM34 006171	E.MP1 002350
BA16 = 000020	CRDY = 000200	C#TPRI= 000013	EM35 006227	E.MP2 002352
BA17 = 000040	CRTIM 003521	DAHS = 000020	EM36 006265	FIFTY 002654
BCCFBK 002266	CSR = 000000	DATPAT 003236	EM4 004712	FIRST 002312
BCSR 002364	CSRMSG 033647	DCKMES 003626	EM40 006321	FIX 015350
BDDAT 002302	CYLMSK 002314	DEMES 003574	EM41 006361	FNDFNC 002372
BEFORE 015362	C#AU = 000052	DERFLG 002422	EM42 006417	FRMT1 011052
BEREG 003457	C#AUTO= 000061	DERR = 040000	EM43 006461	FRMT10 011652
BIT0 = 000001 G	C#BRK = 000022	DIAGMC= 000000	EM44 006522	FRMT11 012001
BIT00 = 000001 G	C#BSEG= 000004	DLMT = 000010	EM45 006554	FRMT13 012111
BIT01 = 000002 G	C#BSUB= 000002	DLT = 000000	EM47 006604	FRMT14 011476
BIT02 = 000004 G	C#CEFG= 000045	DLTMES 003633	EM5 004735	FRMT15 012142
BIT03 = 000010 G	C#CLCK= 000062	DMPCK = 000006	EM50 006621	FRMT16 012167
BIT04 = 000020 G	C#CLEA= 000012	DMSG 034002	EM53 006717	FRMT17 012233
BIT05 = 000040 G	C#CLOS= 000035	DRBT = 000010	EM54 006764	FRMT18 012316
BIT06 = 000100 G	C#CLP1= 000006	DRDY = 000001	EM55 006652	FRMT2 011102
BIT07 = 000200 G	C#CVEC= 000036	DRIVE 002246	EM56 007033	FRMT2A 011121
BIT08 = 000400 G	C#DCLN= 000044	DRMSG 033725	EM57 007052	FRMT2B 011134
BIT09 = 001000 G	C#DODU= 000051	DROP 012434	EM6 004763	FRMT3 011163
BIT1 = 000002 G	C#DRPT= 000024	DRPCOD 013610 G	EM60 007107	FRMT4 011170
BIT10 = 002000 G	C#DU = 000053	DRST = 000010	EM61 007137	FRMT5 011226
BIT11 = 004000 G	C#EDIT= 000003	DRTIM 003546	EM62 007207	FRMT6 011277
BIT12 = 010000 G	C#ERDF= 000055	DRTYPE 033674	EM63 007246	FRMT7 011354
BIT13 = 020000 G	C#ERHR= 000056	DSPCOD 012446 G	EM64 007321	FRMT8 011426
BIT14 = 040000 G	C#ERRO= 000060	DS0 = 000000	EM65 007364	FRMT9 011547
BIT15 = 100000 G	C#ERSF= 000054	DS1 = 000400	EM66 007421	FRMT9B 012044
BIT2 = 000004 G	C#ERSO= 000057	DS2 = 001000	EM7 005017	FRMT99 012106
BIT3 = 000010 G	C#ESCA= 000010	DS3 = 001400	EM70 007472	F#AU = 000015
BIT4 = 000020 G	C#ESEG= 000005	DWORD 002322	END 013240	F#AUTO= 000020
BIT5 = 000040 G	C#ESUB= 000003	EF.CON= 000036 G	ERCOUN 002426	F#BGN = 000040
BIT6 = 000100 G	C#ETST= 000001	EF.NEW= 000035 G	ERFLG 002400	F#CLEA= 000007
BIT7 = 000200 G	C#EXIT= 000032	EF.PWR= 000034 G	ERPOIN 002424	F#DU = 000016
BIT8 = 000400 G	C#GETB= 000026	EF.RES= 000037 G	ERR = 100000	F#END = 000041
BIT9 = 001000 G	C#GETW= 000027	EF.STA= 000040 G	ERRVEC 002244	F#HARD= 000004
BOE = 000400 G	C#GHAN= 000043	ELT = 000002	ERRO 007510 G	F#HW = 000013
BPRIOR 002370	C#GPHR= 000042	EMSG 034107	ERR1 007526 G	F#INIT= 000006
BRMSG 033663	C#GPLO= 000030	EM1 004467	ERR10 010146 G	F#JMP = 000050
BUF 003426	C#GPRI= 000040	EM10 005064	ERR11 010220 G	F#MOD = 000000
BVEC 002366	C#INIT= 000011	EM100 004522	ERR12 010272 G	F#MSG = 000011
B.BA 002332	C#INLP= 000020	EM11 005124	ERR13 010346 G	F#PROT= 000021
B.CS 002330	C#MANI= 000050	EM12 005144	ERR14 010414 G	F#PWR = 000017
B.DA 002334	C#MEM = 000031	EM13 005176	ERR15 010462 G	F#RPT = 000012
B.MP 002336	C#MSG = 000023	EM14 005224	ERR2 007540 G	F#SEG = 000003
CALBCC 002270	C#OPEN= 000034	EM16 005300	ERR3 007602 G	F#SOFT= 000005
CDCNT 002242	C#PNTB= 000014	EM17 005322	ERR4 007654 G	F#SRV = 000010
CHECK 002234	C#PNTF= 000017	EM20 005346	ERR5 007722 G	F#SUB = 000002
CHERR 014612	C#PNTS= 000016	EM21 005414	ERR6 007760 G	F#SW = 000014
CKERLT 014526	C#PNTX= 000015	EM22 005461	ERR7 010022 G	F#TEST= 000001
CLKFLD 002666	C#QIO = 000377	EM23 005540	ERR8 010030 G	GDDAT 002300

SYMBOL TABLE

GLBDAT	002232	G	I#MSG	=	000041	L#LUN	002074	G	L10051	021536	O#DU	=	000001	
GLBEQA	002232	G	I#PROT	=	000040	L#MREV	002050	G	L10052	021672	O#ERRT	=	000000	
GLBERR	007510	G	I#PTAB	=	000041	L#NAME	002000	G	L10053	022024	O#GNSW	=	000001	
GLBSUB	013614	G	I#PWR	=	000041	L#PRIO	002042	G	L10054	022144	O#POIN	=	000001	
GLBXTX	003430	G	I#RPT	=	000041	L#PROT	012406	G	L10055	022324	O#SETU	=	000000	
GODRVR	=	000202	I#SEG	=	000041	L#PRT	002112	G	L10056	023136	PCLKCS	=	002642	
GSBIT	=	000002	I#SETU	=	000041	L#REPP	002062	G	L10057	023332	PCLOCK	=	002660	
GSTAT	=	000004	I#SFT	=	000041	L#REV	002010	G	L10060	023476	PCSR	=	002644	
GSTINT	004221		I#SRV	=	000041	L#SOFT	033736	G	L10061	023662	PNT	=	001000 G	
GSTMES	004171		I#SUB	=	000041	L#SPC	002056	G	L10062	024046	PRI	=	002000 G	
G#CNTD	=	000200	I#TST	=	000041	L#SPCP	002020	G	L10063	024446	PRIOR	=	000004	
G#DELM	=	000372	J#JMP	=	000167	L#SPTP	002024	G	L10064	025070	PRI00	=	000000 G	
G#DISP	=	000003	LDCSR	=	002260	L#STA	002030	G	L10065	025516	PRI01	=	000040 G	
G#EXCP	=	000400	LDFUNC	=	015054	L#SW	012434	G	L10066	026176	PRI02	=	000100 G	
G#HILI	=	000002	LF	=	003640	L#TEST	002114	G	L10067	026630	PRI03	=	000140 G	
G#LOLI	=	000001	LINE1	=	010522	L#TIML	002014	G	L10070	027244	PRI04	=	000200 G	
G#NO	=	000000	LINE2	=	010556	L#UNIT	002012	G	L10071	027476	PRI05	=	000240 G	
G#OFFS	=	000400	LINE3	=	011000	L10000	007524		L10072	027766	PRI06	=	000300 G	
G#OFSI	=	000376	LMSG	=	034052	L10001	007536		L10073	030262	PRI07	=	000340 G	
G#PRMA	=	000001	LOE	=	040000 G	L10002	007600		L10074	030554	PWRFLG	=	002416	
G#PRMD	=	000002	LOPINN	=	002404	L10003	007652		L10075	031146	RDDINT	=	004271	
G#PRML	=	000000	LOPIMX	=	002402	L10004	007720		L10076	031446	RDDMES	=	004251	
G#RADA	=	000140	LOT	=	000010 G	L10005	007756		L10077	032006	RDHDR	=	000010	
G#RADB	=	000000	L#ACP	=	002110 G	L10006	010020		L10100	032320	RDHND	=	000016	
G#RADD	=	000040	L#APT	=	002036 G	L10007	010026		L10101	032644	RDNINT	=	004401	
G#RADL	=	000120	L#AUT	=	002070 G	L10010	010100		L10102	032734	RDNMES	=	004353	
G#RADO	=	000020	L#AUTO	=	013326 G	L10011	010144		L10103	033066	READ	=	000014	
G#XFER	=	000004	L#CCP	=	002106 G	L10012	010216		L10104	033264	REST	=	012772	
G#YES	=	000010	L#CLEA	=	013514 G	L10013	010270		L10105	033422	RESTMS	=	015036	
HCRCHE	003613		L#CO	=	002032 G	L10014	010344		L10106	033556	RHDINT	=	004103	
HDHOME	015764		L#DEPO	=	002011 G	L10015	010412		L10107	033642	RHDMES	=	004053	
HDREND	003046		L#DESC	=	002122 G	L10016	010460		L10110	034002	RHMS	=	000100	
HDRLST	015310		L#DESP	=	002076 G	L10017	010520		MAXCYL	002324	RLBA	=	002356	
HDRTAB	002670		L#DEVP	=	002060 G	L10021	012432		MAXSEC	002320	RLCS	=	002354	
HEND	003234		L#DISP	=	012450 G	L10022	012446		MDMEDR	002000 G	RLDA	=	002360	
HNFMES	003621		L#DLY	=	002116 G	L10023	013324		MERLMT	012436	RLMP	=	002362	
HOE	=	100000 G	L#DTP	=	002040 G	L10024	013512		MK	=	000001	SECMASK	=	002262
HPTCOD	012414	G	L#DTYP	=	002034 G	L10025	013606		MSCRLF	003642	SEEK	=	000006	
HRDPRM	033560	G	L#DU	=	013610 G	L10026	013612		MXSEC1	002316	SEKINT	=	004150	
HTAB	003050		L#DUT	=	002072 G	L10027	014470		NOOPO	=	000000	SEKMES	=	004130
HZ	002650		L#DVTY	=	002220 G	L10030	014502		NOPINT	003733	SETCLK	=	014110	
IBE	=	010000 G	L#EF	=	002052 G	L10031	014516		NOPMES	003705	SFTPRM	=	033734 G	
IDU	=	000040 G	L#ENVI	=	002044 G	L10032	014524		NOPWR	012626	SIGN	=	000004	
IER	=	020000 G	L#ETP	=	002102 G	L10033	016402		NOTST	002662	SIMBCC	=	015462	
INITCO	012600	G	L#EXP1	=	002046 G	L10034	016532		NXM	=	020000	SIXTY	=	002656
INTEN	=	000100	L#EXP4	=	002064 G	L10035	016666		NXMES	003601	SIZE	=	000004	
INTFLG	002256		L#EXP5	=	002066 G	L10036	017020		NXT	012724	SKHOME	=	004430	
INTSRV	014464		L#HARD	=	033562 G	L10037	017156		OPI	=	002000	SPTCOD	=	012432 G
ISR	=	000100 G	L#HIME	=	002120 G	L10040	017354		OPIERR	003653	START	=	012732	
IXE	=	004000 G	L#HPCP	=	002016 G	L10041	017756		OPIMES	003606	START1	=	012646	
I#AU	=	000041	L#HPTP	=	002022 G	L10042	020146		OPIMN	002412	STHS	=	000100	
I#AUTO	=	000041	L#HW	=	012416 G	L10043	020344		OPIMX	002414	SVCGBL	=	000000	
I#CLN	=	000041	L#ICP	=	002104 G	L10044	020516		OPITIM	002664	SVCINS	=	000000	
I#DU	=	000041	L#INIT	=	012600 G	L10045	020714		O#APTS	=	000000	SVCSUB	=	177777
I#HRD	=	000041	L#LADP	=	002026 G	L10046	021114		O#AU	=	000000	SVCTAG	=	000000
I#INIT	=	000041	L#LAST	=	034130 G	L10047	021216		O#BGNR	=	000000	SVCTST	=	177777
I#MOD	=	000041	L#LOAD	=	002100 G	L10050	021342		O#BGNS	=	000001	SVMD	=	002326

SYMBOL TABLE

S\$LSYM= 010000	T\$NEST= 177777	T\$SRV= 010032	T27 025072 G	UOPIMN 002410
TAG 002640	T\$NS0 = 000000	T\$SW = 010022	T28 025520 G	UOPIMX C02406
TEMP 002634	T\$NS1 = 000005	T\$TES= 010106	T29 026200 G	UUT 002250
TEMPO 002632	T\$NS2 = 000003	T.ANS 012444	T3 016534 G	VEC 002646
TEMP2 002304	T\$NS3 = 000003	T.CNTL 002420	T30 026632 G	VECMG 033716
TEMP3 002306	T\$PTNU= 000000	T.CRC 002236	T31 027246 G	VECT = 000002
TEMP4 002310	T\$SAVL= 177777	T.DMP 012440	T32 027500 G	WCKINT 004016
TIME 013614	T\$SEGL= 177777	T.DRIV 002232	T33 027770 G	WCKMES 003762
TIMSRV 014472	T\$SEK0= 010000	T.LMT 012442	T34 030264 G	WHY 002240
TIM.US 002636	T\$SEK1= 010001	T1 016240 G	T35 030556 G	WRCHK = 000002
TMP0 002272	T\$SEK2= 010002	T10 020346 G	T36 031150 G	WRITE = 000012
TMP1 002274	T\$SUBN= 000000	T11 020520 G	T37 031450 G	WRLOCK 004452
TMP2 002276	T\$TAGL= 177777	T12 020716 G	T38 032010 G	WRTINT 004332
TRPFLG 002234	T\$TAGN= 010111	T13 021116 G	T39 032322 G	WRTMES 004311
TRPHAN 015756	T\$TEMP= 000000	T14 021220 G	T4 016670 G	WTCRDY 015700
TRYFNC 002376	T\$TEST= 000054	T15 021344 G	T40 032646 G	WTRDY 015634
TYPDR = 000006	T\$TSTM= 177777	T16 021540 G	T41 032736 G	XDELAY 002626
T\$ARGC= 000004	T\$TSTS= 000001	T17 021674 G	T42 033070 G	XITFLG 002652
T\$CODE= 004052	T\$AUT= 010024	T18 022026 G	T43 033266 G	XMEM 002374
T\$ERRN= 000026	T\$CLE= 010025	T19 022146 G	T44 033424 G	XPOLY 002264
T\$EXCP= 000000	T\$DU = 010026	T2 016404 G	T5 017022 G	XTIME 013746
T\$FLAG= 000040	T\$HAR= 010107	T20 022326 G	T6 017160 G	XXX 012754
T\$GMAN= 000000	T\$HM = 010021	T21 023140 G	T7 017356 G	X\$ALWA= 000000
T\$HILI= 000200	T\$INI= 010023	T22 023334 G	T8 017760 G	X\$FALS= 000040
T\$LAST= 000001	T\$MSG= 010017	T23 023500 G	T9 020150 G	X\$OFFS= 000400
T\$LOLI= 000001	T\$PRO= 010020	T24 023664 G	UAM = 000200 G	X\$TRUE= 000020
T\$LSYM= 010000	T\$SEG= 010000	T25 024050 G	UNITST 002252	YDELAY 002630
T\$LTND= 000054	T\$SOF= 010110	T26 024450 G		

. ABS. 034130 000
000000 001

ERRORS DETECTED: 0

VIRTUAL MEMORY USED: 28726 WORDS (113 PAGES)

DYNAMIC MEMORY: 20060 WORDS (77 PAGES)

ELAPSED TIME: 00:36:12

CNRLHA.BIN,CNRLHA.LST/-SP=SVC34.NLB/ML,CNRLHA.MAC