

DHV11

DHV-11 FUNC TST PT1
CVDHAA0

AH-T653A-MC
FICHE 1 OF 1

OCT 1983
COPYRIGHT © 1983
MADE IN USA



A large grid of approximately 100 small, illegible data tables or charts, arranged in a dense pattern across the page. Each cell contains faint, structured information, likely technical specifications or test results.

CVDHAAO DHV-11 FUNC TST PART1 MACY11 30A(1052) 12-JUL-83 10:52 PAGE 2
CVDHAA.P11 12-JUL-83 00:42 PROGRAM DOCUMENT

.REM 8

IDENTIFICATION

PRODUCT CODE: AC-T652A-MC
PRODUCT NAME: CVDHAAO DHV-11 FUNC TST PART1
PRODUCT DATE: 31 OCTOBER 1983
MAINTAINER: EDSHE - DIAGNOSTICS GROUP
AUTHOR: BERT KLEINSCHMIDT
TONY GRIMSHAW

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS DOCUMENT.

NO RESPONSIBILITY IS ASSUMED FOR THE USE OR RELIABILITY OF SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL OR ITS AFFILIATED COMPANIES.

COPYRIGHT (C) 1983 BY DIGITAL EQUIPMENT CORPORATION

THE FOLLOWING ARE TRADEMARKS OF DIGITAL EQUIPMENT CORPORATION:

DIGITAL
DEC

PDP
DECUS

UNIBUS
DECTAPE

MASSBUS

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 3
PROGRAM DOCUMENT

***** MODIFICATION HISTORY *****

ORIGINAL RELEASE: 31-OCT-83 BERT KLEINSCHMIDT

TABLE OF CONTENTS

1.0	GENERAL PROGRAM CONSIDERATIONS
1.1	PROGRAM ABSTRACT
1.2	SYSTEM REQUIREMENTS
1.3	RELATED DOCUMENTS AND STANDARDS
1.4	DIAGNOSTIC HIERARCY PREREQUISITES
2.0	OPERATING INSTRUCTIONS
2.1	COMMANDS
2.2	SWITCHES
2.3	FLAGS
2.4	EXTENDED COMMAND SYNTAX
2.4.1	START COMMAND
2.4.1.1	TESTS SWITCH (/TESTS:<TEST-LIST>)
2.4.1.2	PASS SWITCH (/PASS:<PASS-CNT>)
2.4.1.3	FLAGS SWITCH (/FLAGS:<FLAG-LIST>)
2.4.1.4	END OF PASS SWITCH (/EOP:<INCR>)
2.4.1.5	EFFECT OF START COMMAND
2.4.2	RESTART COMMAND
2.4.2.1	TESTS, PASS, AND FLAGS SWITCHES
2.4.2.2	UNITS SWITCH (/UNITS:<UNIT-LIST>)
2.4.2.3	EFFECT OF RESTART COMMAND
2.4.3	CONTINUE COMMAND
2.4.3.1	FLAG SWITCH (/FLAGS:<FLAG-LIST>)
2.4.3.2	EFFECT OF CONTINUE COMMAND
2.4.4	PROCEED COMMAND
2.4.4.1	FLAGS SWITCH (/FLAGS:<FLAG-LIST>)
2.4.4.2	EFFECT OF PROCEED COMMAND
2.4.5	ADD COMMAND
2.4.6	EFFECT OF ADD COMMAND
2.4.7	DROP COMMAND
2.4.8	EFFECT OF DROP COMMAND
2.4.9	PRINT COMMAND
2.4.9.1	EFFECT OF PRINT COMMAND
2.4.10	DISPLAY COMMAND
2.4.10.1	EFFECT OF DISPLAY COMMAND
2.4.11	FLAGS COMMAND
2.4.11.1	EFFECT OF FLAGS COMMAND
2.4.12	ZFLAGS COMMAND
2.4.13	ZFLAGS COMMAND
2.4.14	CONTROL CHARACTERS
2.5	HARDWARE QUESTIONS
2.6	SOFTWARE QUESTIONS
2.7	EXTENDED P-TABLE DIALOGUE
2.8	QUICK START-UP PROCEDURE (XXDP+)
3.0	ERROR INFORMATION
3.1	TYPES OF ERROR MESSAGES
3.2	ERROR MESSAGES
4.0	PERFORMANCE AND PROGRESS REPORTS
5.0	TEST SUMMARIES
6.0	EXAMPLE ERROR FREE PASS

CVDHAAO DHV-11 FUNC TST PART1 MACY11 30A(1052) 12-JUL-83 10:52 PAGE 5
CVDHAA.P11 12-JUL-83 00:42 PROGRAM DOCUMENT

1.0 GENERAL PROGRAM CONSIDERATIONS

1.1 PROGRAM ABSTRACT

CVDHA IS PART ONE OF THE DHV-11 FUNCTIONAL VERIFICATION TEST. THIS PART OF THE TEST VERIFIES THAT RESET AND REGISTER ACCESS FUNCTIONS OF THE DHV BOARD UNDER TEST ARE FUNCTIONING CORRECTLY.

THIS DIAGNOSTIC HAS BEEN WRITTEN FOR USE WITH THE DIAGNOSTIC RUNTIME SERVICES SOFTWARE (SUPERVISOR). THESE SERVICES PROVIDE THE INTERFACE TO THE OPERATOR AND TO THE SOFTWARE ENVIRONMENT. THIS PROGRAM CAN BE USED WITH XXDP+, ACT, APT, SLIDE AND PAPER TAPE. FOR A COMPLETE DESCRIPTION OF THE RUNTIME SERVICES, REFER TO THE XXDP+ USER'S MANUAL. THERE IS A BRIEF DESCRIPTION OF THE RUNTIME SERVICES IN THE OPERATING INSTRUCTIONS-COMMANDS OF THIS DOCUMENT.

1.2 SYSTEM REQUIREMENTS

THE FOLLOWING HARDWARE IS REQUIRED TO RUN THE DHV FVT:

- 0 LSI-11 PROCESSOR WITH AT LEAST 32 KBYTES OF RAM.
- 0 DHV11 BOARDS INSTALLED ON THE Q-BUS.
- 0 APPROPRIATE PROGRAM LOAD DEVICE SUPPORTING XXDP+ MEDIA OR A DOWN-LINE LOADING SYSTEM.

1.3 RELATED DOCUMENTS AND STANDARDS

- 0 DHV-11 HARDWARE MANUAL - THIS MANUAL DESCRIBES THE FUNCTIONS AND USES OF THE DHV-11 DEVICE.
- 0 XXDP+ USER'S MANUAL - DESCRIBES THE RUNNING OF DIAGNOSTICS UNDER THE XXDP+ MONITOR.

1.4 DIAGNOSTIC HIERARCY PREREQUISITES

THE LSI-11 PROCESSOR, THE Q-BUS, THE SYSTEM MEMORY, THE CONSOLE TERMINAL, AND THE LOAD MEDIA ARE ASSUMED TO HAVE BEEN TESTED AND FOUND WORKING BEFORE THIS PROGRAM IS RUN.

2.0 OPERATING INSTRUCTIONS

THIS SECTION CONTAINS A BRIEF DESCRIPTION OF THE RUNTIME

CVDHAAO DHV-11 FUNC TST PART1 MACY11 30A(1052) 12-JUL-83 10:52 PAGE 6
 CVDHAA.P11 12-JUL-83 00:42 PROGRAM DOCUMENT

SERVICES. FOR DETAILED INFORMATION, REFER TO THE XXDP+
 USER'S MANUAL (CHQUS).

2.1 COMMANDS

THERE ARE ELEVEN LEGAL COMMANDS FOR THE DIAGNOSTIC RUNTIME SERVICES
 (SUPERVISOR). THIS SECTION LISTS THE COMMANDS AND GIVES A VERY
 BRIEF DESCRIPTION OF THEM. THE XXDP+ USER'S MANUAL HAS MORE DETAILS.

COMMAND	EFFECT
START	START THE DIAGNOSTIC FROM AN INITIAL STATE
RESTART	START THE DIAGNOSTIC WITHOUT INITIALIZING
CONTINUE	CONTINUE AT TEST THAT WAS INTERRUPTED (AFTER ^C)
PROCEED	CONTINUE FROM AN ERROR HALT
EXIT	RETURN TO XXDP+ MONITOR (XXDP+ OPERATION ONLY!)
ADD	ACTIVATE A UNIT FOR TESTING (ALL UNITS ARE CONSIDERED TO BE ACTIVE AT START TIME)
DROP	DEACTIVATE A UNIT
PRINT	PRINT STATISTICAL INFORMATION (IF IMPLEMENTED BY THE DIAGNOSTIC - SEE PERFORMANCE AND PROGRESS REPORTS SECTION OF THIS DOCUMENT)
DISPLAY	TYPE A LIST OF ALL DEVICE INFORMATION
FLAGS	TYPE THE STATE OF ALL FLAGS (SEE FLAGS SECTION)
ZFLAGS	CLEAR ALL FLAGS (SEE FLAGS SECTION)

A COMMAND CAN BE RECOGNIZED BY THE FIRST THREE CHARACTERS. SO
 YOU MAY, FOR EXAMPLE, TYPE "STA" INSTEAD OF "START".
 MORE INFORMATION CAN BE FOUND WITHIN THE SECTION LABELLED
 EXTENDED COMMAND SYNTAX

2.2 SWITCHES

THERE ARE SEVERAL SWITCHES WHICH ARE USED TO MODIFY SUPERVISOR OPERATION.
 THESE SWITCHES ARE APPENDED TO THE LEGAL COMMANDS. ALL OF THE LEGAL
 SWITCHES ARE TABULATED BELOW WITH A BRIEF DESCRIPTION OF EACH.
 IN THE DESCRIPTIONS BELOW, A DECIMAL NUMBER IS DESIGNATED BY "DDDD".

SWITCH	EFFECT
/TESTS:LIST	EXECUTE ONLY THOSE TESTS SPECIFIED IN THE LIST. LIST IS A STRING OF TEST NUMBERS, FOR EXAMPLE - /TESTS:1:5:7-10. THIS LIST WILL CAUSE TESTS 1,5,7,8,9,10 TO BE RUN. ALL OTHER TESTS WILL NOT BE RUN.

CVDHAAO DHV-11 FUNC TST PART1 MACY11 30A(1052) 12-JUL-83 10:52 PAGE 7
 CVDHAA.P11 12-JUL-83 00:42 PROGRAM DOCUMENT

/PASS:DDDDD EXECUTE DDDDD PASSES (DDDDD = 1 TO 64000)
 /FLAGS:FLGS SET SPECIFIED FLAGS.SEE THE FLAGS SECTION
 OF THIS DOCUMENT.
 /EOP:DDDDD REPORT END OF PASS MESSAGE AFTER EVERY
 DDDDD PASSES ONLY. (DDDDD = 1 TO 64000)
 /UNITS:LIST TEST/ADD/DROP ONLY THOSE UNITS SPECIFIED
 IN THE LIST. LIST EXAMPLE - /UNITS:0:5:10-12
 USE UNITS 0,5,10,11,12 (UNIT NUMBERS = 0-63)

EXAMPLE OF SWITCH USAGE:

START/TESTS:1-5/PASS:1000/EOP:100

THE EFFECT OF THIS COMMAND WILL BE: 1) TESTS 1 THROUGH 5 WILL BE EXECUTED, 2) ALL UNITS WILL TESTED 1000 TIMES AND 3) THE END OF PASS MESSAGES WILL BE PRINTED AFTER EACH 100 PASSES ONLY. A SWITCH CAN BE RECOGNIZED BY THE FIRST THREE CHARACTERS. YOU MAY, FOR EXAMPLE, TYPE "/TES:1-5" INSTEAD OF "/TESTS:1-5".

BELOW IS A TABLE THAT SPECIFIES WHICH SWITCHES CAN BE USED BY EACH COMMAND.

	TESTS	PASS	FLAGS	EOP	UNITS
START	X	X	X	X	X
RESTART	X	X	X	X	X
CONTINUE		X	X	X	
PROCEED			X		
DROP					X
ADD					X
PRINT					
DISPLAY					X
FLAGS					
ZFLAGS					
EXIT					

2.3 FLAGS

FLAGS ARE USED TO SET UP CERTAIN OPERATIONAL PARAMETERS SUCH AS LOOPING ON ERROR. ALL FLAGS ARE CLEARED AT STARTUP AND REMAIN CLEARED UNTIL EXPLICITLY SET USING THE FLAGS SWITCH. FLAGS ARE ALSO CLEARED AFTER A START COMMAND UNLESS SET USING THE FLAG SWITCH. THE ZFLAGS COMMAND MAY ALSO BE USED TO CLEAR ALL FLAGS. WITH THE EXCEPTION OF THE START AND ZFLAGS COMMANDS, NO COMMANDS AFFECT THE STATE OF THE FLAGS; THEY REMAIN SET OR CLEARED AS SPECIFIED BY THE LAST FLAG SWITCH.

FLAG	EFFECT
HOE	HALT ON ERROR - CONTROL IS RETURNED TO RUNTIME SERVICES COMMAND MODE
LOE	LOOP ON ERROR
IER*	INHIBIT ALL ERROR REPORTS
IBR*	INHIBIT ALL ERROR REPORTS EXCEPT FIRST LEVEL (FIRST LEVEL CONTAINS

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 8
PROGRAM DOCUMENT

IXR*	ERROR TYPE, NUMBER, PC, TEST AND UNIT)
	INHIBIT EXTENDED ERROR REPORTS (THOSE
	CALLED BY PRINTX MACRO'S)
PRI	DIRECT MESSAGES TO LINE PRINTER
PNT	PRINT TEST NUMBER AS TEST EXECUTES
BOE	'BELL' ON ERROR
UAM	UNATTENDED MODE (NO MANUAL INTERVENTION)
ISR	INHIBIT STATISTICAL REPORTS (DOES NOT
	APPLY TO DIAGNOSTICS WHICH DO NOT SUPPORT
	STATISTICAL REPORTING)
IDR	INHIBIT PROGRAM DROPPING OF UNITS
ADR	EXECUTE AUTODROP CODE
LOT	LOOP ON TEST
EVL	EXECUTE EVALUATION (ON DIAGNOSTICS WHICH
	HAVE EVALUATION SUPPORT)

*SEE THE ERROR INFORMATION SECTION OF THIS DOCUMENT.

SEE THE XXDP+ USER'S MANUAL FOR MORE DETAILS ON FLAGS. YOU MAY SPECIFY MORE THAN ONE FLAG WITH THE FLAG SWITCH. FOR EXAMPLE, TO CAUSE THE PROGRAM TO LOOP ON ERROR, INHIBIT ERROR REPORTS AND TYPE A 'BELL' ON ERROR, YOU MAY USE THE FOLLOWING STRING:

/FLAGS:LOE:IER:BOE

2.4 EXTENDED COMMAND SYNTAX

2.4.1 START COMMAND -

```
*****
STA(RT)/TESTS:<TEST-LIST>/PASS:<PASS-CNT>/FLAGS:
<FLAG-LIST>/EOP:<INCR>
*****
```

2.4.1.1 TESTS SWITCH (/TESTS:<TEST-LIST>) -

<TEST-LIST> IS A SEQUENCE OF DECIMAL NUMBERS (1:2 ETC.) OR RANGES OF DECIMAL NUMBERS (1-5:8-10 ETC.), SEPERATED BY COLONS, THAT SPECIFY THE TESTS TO BE EXECUTED. TESTS WILL BE EXECUTED IN NUMERICAL ORDER REGARDLESS OF THE ORDER OF SPECIFICATION. THE DEFAULT IS TO EXECUTE ALL TESTS. ON THIS AND ALL SWITCHES, THE ANGLE BRACKETS <> ARE PUNCTUATION USED IN THE DEFINITION ONLY, AND ARE NOT TO BE TYPED BY THE OPERATOR. SEE EXAMPLE AT END OF 'EFFECT OF START COMMAND' SECTION.

2.4.1.2 PASS SWITCH (/PASS:<PASS-CNT>) -

<PASS-CNT> IS A DECIMAL NUMBER INDICATING THE DESIRED NUMBER OF PASSES. A PASS IS DEFINED AS THE EXECUTION OF THE

CVDHAAO DHV-11 FUNC TST PART1 MACY11 30A(1052) 12-JUL-83 10:52 PAGE 9
 CVDHAA.P11 12-JUL-83 00:42 PROGRAM DOCUMENT

FULL DIAGNOSTIC (ALL SELECTED TESTS). THE DEFAULT IS NON-ENDING EXECUTION. IN THIS CASE, EXIT FROM THE PROGRAM IS ACCOMPLISHED EITHER BY TYPING A CONTROL/C OR BY OCCURANCE OF AN ERROR WITH THE HALT ON ERROR FLAG BEING SET. THE EXIT IS A RETURN TO COMMAND MODE. SEE EXAMPLE AT END OF "EFFECT OF START COMMAND" SECTION.

2.4.1.3 FLAGS SWITCH (/FLAGS:<FLAG-LIST>) -

<FLAG-LIST> IS A SEQUENCE OF ELEMENTS OF THE FORM <FLAG>, <FLAG=1>, OR <FLAG=0>, SEPARATED BY COLONS, WHERE <FLAG> HAS ONE OF THE FOLLOWING VALUES:

HOE HALT ON ERROR, CAUSING COMMAND MODE TO BE ENTERED WHEN AN ERROR IS ENCOUNTERED.
 LOE LOOP ON ERROR, CAUSING THE DIAGNOSTIC TO LOOP CONTINUOUSLY WITHIN THE SMALLEST DEFINED BLOCK OF CODING (SEGMENT, SUBTEST, OR TEST) CONTAINING THE ERROR.
 IER INHIBIT ERROR REPORTING.
 IBE INHIBIT BASIC ERROR REPORTS.
 IXE INHIBIT EXTENDED ERROR REPORTS.
 PRI DIRECT ALL MESSAGES TO A LINE PRINTER.
 PNT PRINT NUMBER OF TEST BEING EXECUTED.
 BOE BELL ON ERROR (NOT RELATED TO BELL PROMPTING).
 UAM RUN IN UNATTENDED MODE, BYPASSING MANUAL INTERVENTION (ILLEGAL FOR THIS DIAGNOSTIC).
 ISR INHIBIT STATISTICAL REPORTS.
 IDU INHIBIT DROPPING OF UNITS BY DIAGNOSTIC. (HAS NO EFFECT IN THIS DIAGNOSTIC.)
 LOT LOOP ON TEST.

THE FLAGS NAMED OR EQUATED TO 1 ARE SET, THOSE EQUATED TO 0 ARE CLEARED. A FLAG NOT SPECIFIED IS CLEARED. IF THE FLAGS SWITCH IS NOT GIVEN ALL FLAGS ARE CLEARED. SEE EXAMPLE AT END OF "EFFECT OF START COMMAND" SECTION.

2.4.1.4 END OF PASS SWITCH (/EOP:<INCR>) -

<INCR> IS A DECIMAL NUMBER INDICATING HOW OFTEN (IN TERMS OF PASSES) IT IS DESIRED THAT THE END OF PASS MESSAGE BE PRINTED. THE DEFAULT IS AT THE END OF EVERY PASS. SEE EXAMPLE AT END OF "EFFECT OF START COMMAND" SECTION.

2.4.1.5 EFFECT OF START COMMAND -

THE EFFECT OF THE START COMMAND IS TO INITIATE THE HARDWARE PARAMETER DIALOGUE, THE SOFTWARE PARAMETER DIALOGUE, THE INITIALIZATION QUESTIONS, AND THEN THE DIAGNOSTIC COMMENCES TESTING.

THE HARDWARE PARAMETER DIALOGUE COMMENCES WITH THE QUESTION "# UNITS (D) ?" TO WHICH THE OPERATOR SHOULD REPLY WITH THE NUMBER OF UNITS TO BE TESTED. FOLLOWING THIS ARE THE QUESTIONS WHEREBY THE P-TABLES THEMSELVES ARE BUILT. EACH P-TABLE IS A CORE-RESIDENT TABLE CONTAINING ALL THE HARDWARE INFORMATION FOR ONE COMPLETE UNIT. EACH QUESTION IS FOLLOWED BY THE RESPONSE RADIX (D FOR DECIMAL, B FOR BINARY, O FOR OCTAL, L FOR YES/NO) IN PARENTHESES AND THE DEFAULT VALUE AFTER THE PARENTHESES. FOR THE ACTUAL HARDWARE P-TABLE QUESTIONS SEE THE "HARDWARE PARAMETERS" SECTION.

FOLLOWING THE HARDWARE QUESTIONS ARE THE SOFTWARE QUESTIONS TO BUILD THE SOFTWARE TABLES, WHICH DEFINE OPERATING PARAMETERS OF THE DIAGNOSTIC PROGRAM. THESE QUESTIONS ARE DESCRIBED IN THE "SOFTWARE PARAMETERS" SECTION.

EXAMPLE:

STA/TESTS:1:3-4:/PASS:3/FLAGS:IER:HOE=1

THIS COMMAND WILL CAUSE THREE PASSES TO BE MADE, WITH EACH PASS CONSISTING OF TESTS 1,3, AND 4. THERE IS NO DIFFERENCE BETWEEN SAYING <FLAG> AND SAYING <FLAG=1>. THE NOTATION <FLAG=0> IS MEANINGFUL ONLY ON A COMMAND OTHER THAN START TO CLEAR A FLAG THAT WAS PREVIOUSLY SET. NOTE THAT ON ALL COMMANDS ONLY THE FIRST THREE LETTERS ARE SCANNED.

2.4.2 RESTART COMMAND -

 RES(TART)/TESTS:<TEST-LIST>/PASS:<PASS-CNT>/FLAGS:
 <FLAG-LIST>/UNITS:<UNIT-LIST>

2.4.2.1 TESTS, PASS, AND FLAGS SWITCHES -

<TEST-LIST>, <PASS-CNT>, AND <FLAG-LIST> ARE AS IN THE START COMMAND.

2.4.2.2 UNITS SWITCH (/UNITS:<UNIT-LIST>) - <UNIT-LIST> IS A SEQUENCE OF DECIMAL NUMBERS (0,1 ETC.) OR RANGES OF DECIMAL NUMBERS (0-5, 8-10 ETC.) THAT SPECIFY THE UNITS TO BE TESTED. THE NUMBERS ARE SEPARATED BY COLONS. THE NUMBERS MAY RANGE FROM 0 THRU N-1 (N IS THE NUMBER OF UNITS SPECIFIED IN THE PREVIOUS START COMMAND). THE NUMBER INDICATES THE POSITION OF THE P-TABLE AS THE DATA WAS ENTERED DURING THE HARDWARE DIALOGUE. THE UNITS WHICH ARE SELECTED MUST NOT HAVE BEEN DROPPED BY THE DROP COMMAND. SEE THE DISCUSSION OF ADD AND DROP COMMANDS BELOW. DEFAULT IS TO TEST ALL UNITS WHICH HAVE NOT BEEN DROPPED BY A DROP

COMMAND.

2.4.2.3 EFFECT OF RESTART COMMAND -

THE RESTART COMMAND DIFFERS FROM THE START COMMAND IN THAT THE P-TABLES FROM THE PREVIOUS START COMMAND (THERE MUST HAVE BEEN ONE) ARE USED, INSTEAD OF NEW ONES BEING BUILT. THE SOFTWARE DIALOGUE MAY OPTIONALLY BE REEXECUTED (OPERATOR WILL BE ASKED). THE COMMAND CAN BE USED AFTER COMMAND MODE HAS BEEN REENTERED IN ANY OF THE THREE NORMAL WAYS: A) THE REQUESTED NUMBER OF PASSES HAVE BEEN MADE, B) AN ERROR WAS ENCOUNTERED WITH THE HALT ON ERROR FLAG SET, OR C) A CONTROL/C WAS ENTERED BY THE OPERATOR.

2.4.3 CONTINUE COMMAND -

CON(TINUE)/PASS:<PASS-CNT/FLAGS:<FLAG-LIST>

2.4.3.1 FLAG SWITCH (/FLAGS:<FLAG-LIST>) -

<FLAG-LIST> IS SAME AS IN THE START COMMAND, BUT UNSPECIFIED FLAGS RETAIN THEIR CURRENT VALUE.

2.4.3.2 EFFECT OF CONTINUE COMMAND -

CONTINUE MUST FOLLOW A START OR RESTART, AND COMMAND MODE MUST HAVE BEEN ENTERED DUE TO A HALT ON ERROR OR A CONTROL/C. THE EFFECT OF THE COMMAND IS TO GO TO THE BEGINNING OF THE TEST THAT WAS BEING EXECUTED WHEN THE HALT OR CONTROL/C TOOK PLACE. SOFTWARE DIALOGUE MAY OPTIONALLY BE REEXECUTED. HARDWARE PARAMETERS MAY NOT BE CHANGED.

2.4.4 PROCEED COMMAND -

PRO(CEED)/FLAGS:<FLAG-LIST>

2.4.4.1 FLAGS SWITCH (/FLAGS:<FLAG-LIST>) -

<FLAG-LIST> IS AS IN THE START COMMAND, BUT UNSPECIFIED FLAGS RETAIN THEIR CURRENT VALUE.

2.4.4.2 EFFECT OF PROCEED COMMAND -

CVDI
CVDI
1
1
1
1

CVDHAAO DHV-11 FUNC TST PART1 MACY11 30A(1052) 12-JUL-83 10:52 PAGE 15
 CVDHAA.P11 12-JUL-83 00:42 PROGRAM DOCUMENT

TO ILLUSTRATE A MORE EFFICIENT METHOD, SUPPOSE YOU ARE TESTING A FICTIONAL DEVICE, THE XY11. SUPPOSE THIS DEVICE CONSISTS OF A CONTROL MODULE WITH EIGHT UNITS (SUB-DEVICES) ATTACHED TO IT. THESE UNITS ARE DESCRIBED BY THE OCTAL NUMBERS 0 THROUGH 7. THERE IS ONE HARDWARE PARAMETER THAT CAN VARY AMONG UNITS CALLED THE Q-FACTOR. THIS Q-FACTOR MAY BE 0 OR 1. BELOW IS A SIMPLE WAY TO BUILD A TABLE FOR ONE XY11 WITH EIGHT UNITS.

UNITS (D) ? 8<CR>

UNIT 1
 CSR ADDRESS (O) ? 160000<CR>
 SUB-DEVICE # (O) ? 0<CR>
 Q-FACTOR (O) 0 ? 1<CR>

UNIT 2
 CSR ADDRESS (O) ? 160000<CR>
 SUB-DEVICE # (O) ? 1<CR>
 Q-FACTOR (O) 1 ? 0<CR>

UNIT 3
 CSR ADDRESS (O) ? 160000<CR>
 SUB-DEVICE # (O) ? 2<CR>
 Q-FACTOR (O) 0 ? <CR>

UNIT 4
 CSR ADDRESS (O) ? 160000<CR>
 SUB-DEVICE # (O) ? 3<CR>
 Q-FACTOR (O) 0 ? <CR>

UNIT 5
 CSR ADDRESS (O) ? 160000<CR>
 SUB-DEVICE # (O) ? 4<CR>
 Q-FACTOR (O) 0 ? <CR>

UNIT 6
 CSR ADDRESS (O) ? 160000<CR>
 SUB-DEVICE # (O) ? 5<CR>
 Q-FACTOR (O) 0 ? <CR>

UNIT 7
 CSR ADDRESS (O) ? 160000<CR>
 SUB-DEVICE # (O) ? 6<CR>
 Q-FACTOR (O) 0 ? 1<CR>

UNIT 8
 CSR ADDRESS (O) 160000<CR>
 SUB-DEVICE # (O) ? 7<CR>

Q-FACTOR (O) 1 ? <CR>

NOTICE THAT THE DEFAULT VALUE FOR THE Q-FACTOR CHANGES WHEN A NON-DEFAULT RESPONSE IS GIVEN. BE CAREFUL WHEN SPECIFYING MULTIPLE UNITS!

AS YOU CAN SEE FROM THE ABOVE EXAMPLE, THE HARDWARE PARAMETERS DO NOT VARY SIGNIFICANTLY FROM UNIT TO UNIT. THE PROCEDURE SHOWN IS

CVDHAAO DHV-11 FUNC TST PART1 MACY11 30A(1052) 12-JUL-83 10:52 PAGE 16
 CVDHAA.P11 12-JUL-83 00:42 PROGRAM DOCUMENT

NOT VERY EFFICIENT.

THE RUNTIME SERVICES CAN TAKE MULTIPLE UNIT SPECIFICATIONS HOWEVER.
 LET'S BUILD THE SAME TABLE USING THE MULTIPLE SPECIFICATION
 FEATURE.

UNITS (D) ? 8<CR>

UNIT 1
 CSR ADDRESS (0) ? 160000<CR>
 SUB-DEVICE # (0) ? 0,1<CR>
 Q-FACTOR (0) 0 ? 1,0<CR>

UNIT 3
 CSR ADDRESS (0) ? 160000<CR>
 SUB-DEVICE # (0) ? 2-5<CR>
 Q-FACTOR (0) 0 ? 0<CR>

UNIT 7
 CSR ADDRESS (0) ? 160000<CR>
 SUB-DEVICE # (0) ? 6,7<CR>
 Q-FACTOR (0) 0 ? 1<CR>

AS YOU CAN SEE IN THE ABOVE DIALOGUE, THE RUNTIME SERVICES WILL
 BUILD AS MANY ENTRIES AS IT CAN WITH THE INFORMATION GIVEN IN ANY
 ONE PASS THROUGH THE QUESTIONS. IN THE FIRST PASS, TWO ENTRIES
 ARE BUILT SINCE TWO SUB-DEVICES AND Q-FACTORS WERE SPECIFIED. THE
 SERVICES ASSUME THAT THE CSR ADDRESS IS 160000 FOR BOTH SINCE IT
 WAS SPECIFIED ONLY ONCE. IN THE SECOND PASS, FOUR ENTRIES WERE
 BUILT. THIS IS BECAUSE FOUR SUB-DEVICES WERE SPECIFIED. THE
 "-" CONSTRUCT TELLS THE RUNTIME SERVICES TO INCREMENT THE DATA
 FROM THE FIRST NUMBER TO THE SECOND. IN THIS CASE, SUB-DEVICES
 2, 3, 4 AND 5 WERE SPECIFIED. (IF THE SUB-DEVICE WERE SPECIFIED
 BY ADDRESSES, THE INCREMENT WOULD BE BY 2 SINCE ADDRESSES MUST
 BE ON AN EVEN BOUNDARY.) THE CSR ADDRESSES AND Q-FACTORS FOR
 THE FOUR ENTRIES ARE ASSUMED TO BE 160000 AND 0 RESPECTIVELY
 SINCE THEY WERE ONLY SPECIFIED ONCE. THE LAST TWO UNITS ARE
 SPECIFIED IN THE THIRD PASS.

THE WHOLE PROCESS COULD HAVE BEEN ACCOMPLISHED IN ONE PASS AS
 SHOWN BELOW.

UNITS (D) ? 8<CR>

UNIT 1
 CSR ADDRESS (0) ? 160000<CR>
 SUB-DEVICE # (0) ? 0-7<CR>
 Q-FACTOR (0) 0 ? 0,1,0,,,,,1,1<CR>

AS YOU CAN SEE FROM THIS EXAMPLE, NULL REPLIES (COMMAS ENCLOSING
 A NULL FIELD) TELL THE RUNTIME SERVICES TO REPEAT THE LAST REPLY.

2.8 QUICK START-UP PROCEDURE (XXDP+)

TO START-UP THIS PROGRAM:

CVDHAAO DHV-11 FUNC TST PART1 MACY11 30A(1052) 12-JUL-83 10:52 PAGE 17
 CVDHAA.P11 12-JUL-83 00:42 PROGRAM DOCUMENT

1. BOOT XXDP+
2. GIVE THE DATE AND ANSWER THE LSI AND 50HZ (IF THERE IS A CLOCK AND THE QUESTION IS ASKED) QUESTIONS
3. TYPE 'R NAME', WHERE NAME IS THE NAME OF THE BIN OR BIC FILE FOR THIS PROGRAM
4. TYPE "START"
5. ANSWER THE "CHANGE HW" QUESTION WITH "Y"
6. ANSWER ALL THE HARDWARE QUESTIONS
7. ANSWER THE "CHANGE SW" QUESTION WITH "N"

WHEN YOU FOLLOW THIS PROCEDURE YOU WILL BE USING ONLY THE DEFAULTS FOR FLAGS AND SOFTWARE PARAMETERS. FOR DEFAULT INFORMATION SEE THE SECTIONS WITHIN THIS DOCUMENT ON FLAGS, AND HARDWARE QUESTIONS.

3.0 ERROR INFORMATION

3.1 TYPES OF ERROR MESSAGES

THERE ARE THREE LEVELS OF ERROR MESSAGES THAT MAY BE ISSUED BY A DIAGNOSTIC: GENERAL, BASIC AND EXTENDED. GENERAL ERROR MESSAGES ARE ALWAYS PRINTED UNLESS THE "IER" FLAG IS SET (SEE THE FLAGS SECTION OF THIS DOCUMENT).

THE GENERAL ERROR MESSAGE IS OF THE FORM:

```
NAME TYPE NUMBER ON UNIT NUMBER TST NUMBER PC:XXXXXX
ERROR MESSAGE
```

,WHERE; NAME = DIAGNOSTIC NAME
 TYPE = ERROR TYPE (SYS FATAL, DEV FATAL, HARD OR SOFT)
 NUMBER = ERROR NUMBER
 UNIT NUMBER = 0 - N (N IS LAST UNIT IN PTABLE)
 TST NUMBER = TEST AND SUBTEST WHERE ERROR OCCURRED
 PC:XXXXXX = ADDRESS OF ERROR MESSAGE CALL

BASIC ERROR MESSAGES ARE MESSAGES THAT CONTAIN SOME ADDITIONAL INFORMATION ABOUT THE ERROR. THESE ARE ALWAYS PRINTED UNLESS THE "IER" OR "IBR" FLAGS ARE SET (SEE THE FLAGS SECTION OF THIS DOCUMENT). THESE MESSAGES ARE PRINTED AFTER THE ASSOCIATED GENERAL MESSAGE.

EXTENDED ERROR MESSAGES CONTAIN SUPPLEMENTARY ERROR INFORMATION SUCH AS REGISTER CONTENTS OR GOOD/BAD DATA. THESE ARE ALWAYS PRINTED UNLESS THE "IER", "IBR" OR "IXR" FLAGS ARE SET (SEE THE

FLAGS SECTION OF THIS DOCUMENT). THESE MESSAGES ARE PRINTED AFTER THE ASSOCIATED GENERAL ERROR

CVDHAAO DHV-11 FUNC TST PART1 MACY11 30A(1052) 12-JUL-83 10:52 PAGE 18
CVDHAA.P11 12-JUL-83 00:42 PROGRAM DOCUMENT

MESSAGE AND ANY ASSOCIATED BASIC ERROR MESSAGES.

3.2 ERROR MESSAGES

THIS PROGRAM IS INTENDED TO PROVIDE A GO/NO-GO INDICATION OF THE FUNCTIONALITY OF DHV-11 BOARDS. TO EXECUTE THE PROGRAM IN THIS MODE THE OPERATOR CAN RUN WITH THE INHIBIT BASIC ERROR REPORTING SWITCH. IN THIS MODE THE PROGRAM PRINTS ERROR MESSAGES WHICH CONTAIN THE ERROR MESSAGE HEADER DESCRIBED ABOVE, PLUS THE NAME OF THE FAILING TEST. FOR A LIST OF THE TEST NAMES IN THIS PROGRAM SEE THE TEST SUMMARIES SECTION OF THIS DOCUMENT. AN EXAMPLE OF SUCH AN ERROR MESSAGE IS THE FOLLOWING:

CVDHA DVC FTL ERR 01603 ON UNIT 02 TST 015 SUB 000 PC: 015244
DEVICE REGISTER WORD READ/WRITE TEST

THIS ERROR INDICATES THAT A FATAL ERROR WAS ENCOUNTERED WITHIN THE TEST WHICH TESTS THE READ/WRITE CAPABILITY OF THE DHV-11 REGISTERS.

IF THE OPERATOR REQUIRES MORE EXTENSIVE ERROR REPORTING HE CAN RUN WITH ALL ERROR REPORTING ENABLED BY NOT USING THE INHIBIT REPORTING SWITCHES. THE ABOVE ERROR MESSAGE WOULD THEN BECOME THE FOLLOWING:

CVDHA DVC FTL ERR 01603 ON UNIT 02 TST 015 SUB 000 PC: 015244
DEVICE REGISTER WORD READ/WRITE TEST
BAD BIT(S) IN DEVICE TBUFFAD1 REGISTER FOR LINE 7 (D).
EXPECTED DATA: 000000 (0).
ACTUAL DATA: 000023 (0).

4.0 PERFORMANCE AND PROGRESS REPORTS

AT THE END OF EACH PASS, THE PASS COUNT IS GIVEN ALONG WITH THE TOTAL NUMBER OF ERRORS REPORTED SINCE THE DIAGNOSTIC WAS STARTED. THE 'EOP' SWITCH CAN BE USED TO CONTROL HOW OFTEN THE END OF PASS MESSAGE IS PRINTED. FOR FURTHER INFORMATION SEE THE SWITCHES SECTION OF THIS DOCUMENT.

5.0 TEST SUMMARIES

THE FOLLOWING TESTS ARE INCLUDED WITHIN CVDHA:

1. DEVICE REGISTER ADDRESS TEST - VERIFIES THAT THE UUT REGISTERS WILL RESPOND WITH THE PROPER Q-BUS HANDSHAKING WHEN ACCESSED. VERIFIES THAT THE UUT IS AT THE PROPER ADDRESS.
2. MASTER.RESET (SELFTEST) TEST - VERIFIES THAT THE MASTER.RESET BIT CLEARS WITHIN A SPECIFIED TIME OF IT BEING SET.
3. MASTER.RESET (SKIP SELFTEST) TEST - VERIFIES THAT THE MASTER.RESET BIT CLEARS WITHIN A SHORT TIME AFTER IT IS SET

IF THE SKIP SELFTEST SEQUENCE IS USED.

4. RECEPTION HANDSHAKING TESTS - THESE TESTS VERIFY THAT THE HANDSHAKING BITS WHICH ARE NECESSARY FOR THE READING OF CODES FROM THE FIFO ARE WORKING.
5. RX.CHARACTER FIELD TEST - VERIFIES THAT THE DATA BITS OF THE CODES IN THE FIFO AFTER A RESET AND SKIP SELFTEST ARE CONSISTANT WITH THE SKIP SELFTEST CODES.
6. RECEPTION FLAG FIELD TEST - VERIFIES THAT THE 3 DATA STATUS BITS (OVERRUN, FRAMING, AND PARITY ERROR BITS) ARE ALL SET ON ALL OF THE SKIP SELFTEST CODES IN THE FIFO AFTER A RESET AND SKIP SELFTEST SEQUENCE.
7. RX.DATA.AVAIL TEST - VERIFIES THAT THE RX.DATA.AVAIL BIT IS SET WHEN THE SKIP SELFTEST CODES ARE IN THE FIFO AND THAT IT CLEARS AFTER THEY ARE READ.
8. RX.DATA.VALID TEST - VERIFIES THAT THE RX.DATA.VALID BIT IS SET FOR EACH VALID SKIP SELFTEST CODE IN THE FIFO AND CLEAR AFTER ALL VALID CODES ARE READ.
9. RX.LINE FIELD TEST - VERIFIES THAT THE RX.LINE FIELDS ARE CORRECT FOR THE SKIP SELFTEST CODES.
10. BMP RUN TEST - THIS TEST RUNS THE BMP AND VERIFIES THAT IT DOES NOT FAIL WITHIN A SPECIFIED PERIOD. THIS TEST SHOULD SIGNAL PROBLEMS THAT THE BMP CODES COULD CAUSE WITH LATER TESTS.
11. SKIP SELFTEST TEST - THIS TEST VERIFIES THAT IF THE SELFTEST IS SKIPPED THE PROPER CODES ARE PLACED IN THE FIFO AND THAT NO ERRORS ARE ENCOUNTERED.
12. DIAGNOSTIC.FAIL (SKIP SELFTEST) TEST - THIS TEST VERIFIES, BY USING THE SKIP SELFTEST SEQUENCE, THAT THE DIAGNOSTIC.FAIL BIT WILL GO TO BOTH THE ACTIVE AND INACTIVE STATES.
13. SELFTEST RUN TEST - VERIFIES THAT NO ERRORS ARE FOUND BY THE EXECUTION OF THE SELFTEST.
14. SELFTEST FAIL TEST - VERIFIES THAT THE SELFTEST WILL REPORT ERRORS CORRECTLY WHEN IT IS FORCED TO FAIL.
15. ROM VERSION PRINTOUT TEST - IF REQUESTED, REPORTS THE VERSION NUMBERS OF THE 8051 ROMS.
16. WORD ACCESS READ/WRITE TEST - VERIFIES THAT THE REGISTERS RESPOND CORRECTLY TO WORD READ AND WRITE ACCESSES.
17. WORD ACCESS READ/MODIFY/WRITE TEST - VERIFIES THAT THE REGISTERS RESPOND CORRECTLY TO READ/MODIFY/WRITE WORD ACCESSES.
18. BYTE ACCESS READ/WRITE TEST - VERIFIES THAT THE REGISTERS

CVDHAAO DHV-11 FUNC TST PART1 MACY11 30A(1052) 12-JUL-83 10:52 PAGE 20
 CVDHAA.P11 12-JUL-83 00:42 PROGRAM DOCUMENT

RESPOND CORRECTLY TO BYTE READ AND WRITE ACCESSES.

19. BYTE ACCESS READ/MODIFY/WRITE TEST - VERIFIES THAT THE REGISTERS RESPOND CORRECTLY TO READ/MODIFY/WRITE BYTE ACCESSES.
20. ID.BIT TEST - VERIFIES THAT THE ID.BIT READS AS A ZERO.
21. REPORT BMP CODES TEST - THIS PSEUDO TEST REPORTS THE FIRST 32 BMP CODES WHICH WERE DISCOVERED IN THE FIFO DURING THE EXECUTION OF THE OTHER TESTS. THIS AVOIDS THE INTERRUPTION OF OTHER TESTS BY THESE CODES, IF THEY ARE NOT CRITICAL TO THE TESTS BEING PERFORMED.

6.0 EXAMPLE ERROR FREE PASS

THE FOLLOWING IS AN EXAMPLE OF AN ERROR FREE PASS DIALOGUE:

.R CVDHAAO
 CVDHAAO.BIC

DRS
 CVDHAAO
 DHV-11 FUNC TST PART1
 UNIT IS DHV-11
 RESTART ADDR: 147670
 DR>STA

CHANGE HW (L) ? Y

UNITS (D) ? 2

UNIT 0
 CSR ADDRESS: (0) 160020 ? ^Z

UNIT 1
 CSR ADDRESS: (0) 160020 ? 160040
 ACTIVE LINE BIT MAP: (0) 377 ? 10

CHANGE SW (L) ? N

TESTING UNIT : 0

ROM VERSION NUMBERS: PROC_1 = 1 PROC_2 = 1

CVDHAAO DHV-11 FUNC TST PART1 MACY11 30A(1052) 12-JUL-83 10:52 PAGE 21
CVDHAA.P11 12-JUL-83 00:42 PROGRAM DOCUMENT

TESTING UNIT

ROM VERSION NUMBERS: PROC_1 = 1 PROC_2 = 1

CVDHA EOP 1
0 CUMULATIVE ERRORS

...

&

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 27
DEFAULT HARDWARE P-TABLE

1172
1173
1174
1175
1176
1177
1178
1179
1180
1181
1182
1183 002202
1184 002202 000002
1185 002204
1186 002204
1187
1188 002204 000021
1189 002206 000000
1190
1191 002210
1192 002210

.SBTTL SOFTWARE P-TABLE

:++
: THE SOFTWARE TABLE CONTAINS VARIOUS DATA USED BY THE
: PROGRAM AS OPERATIONAL PARAMETERS. THESE PARAMETERS ARE
: SET UP AT ASSEMBLY TIME AND MAY BE VARIED BY THE OPERATOR
: AT RUN TIME.
:--

BGNSW SFPTBL

.WORD L10001-L\$\$W/2
L\$\$W::
SFPTBL::

OPTION::
NDERPT::
OPTION:: .WORD 21 :BIT MAP OF PROGRAM CONTROL FLAGS
NDERPT:: .WORD 0 :DEFAULT NUMBER OF INDIVIDUAL DATA ERRORS TO RPT

ENDSW

L10001:

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 28
SOFTWARE P-TABLE

CV
CV

1193
1194
1195
1196
1197
1198
1199
1200
1201
1202
1203
1204
1205
1206
1207
1208
1209
1210
1211
1212
1213
1214
1215
1216
1217
1218
1219
1220
1221
1222
1223
1224
1225
1226
1227
1228
1229
1230
1231
1232
1233
1234
1235
1236
1237
1238
1239
1240
1241
1242
1243
1244
1245
1246
1247
1248

002210

000010
000377

000000
000002
000002
000004
000006
000010
000012
000014
000016

000020
000030
000100

100000
040000
020000
010000
004000
002000
001000
000400
000200
000100
000040
000020
000010
000004
000002
000001

001000
000400
000200
000100

.SBTTL GLOBAL EQUATES SECTION

;++
: THE GLOBAL EQUATES SECTION CONTAINS PROGRAM EQUATES THAT
: ARE USED IN MORE THAN ONE TEST.
:--

NUMLNS==10 ;NUMBER OF LINES ON DHV11 IS 8.
MAPLNS==377 ;BIT MAP OF LINES ON DHV11.

***** DEVICE REGISTER OFFSETS FROM THE CSR'S ADDRESS *****
CSRO==0 ;CSR REGISTER OFFSET FROM THE CSR ADDRESS
RBUFO==2 ;RECEIVE REGISTER OFFSET FROM THE CSR ADDRESS
TXCHRO==2 ;TRANSMIT REGISTER OFFSET FROM THE CSR ADDRESS
LPRO==4 ;LINE PARAMETER REGISTER OFFSET FROM THE CSR ADDRESS
STATO==6 ;STATUS REGISTER OFFSET FROM THE CSR ADDRESS
LNCTRO==10 ;LINE CONTROL REGISTER OFFSET FROM THE CSR ADDRESS
TXAD10==12 ;TRANSMIT ADDRESS 1 REGISTER OFFSET FROM THE CSR ADDRESS
TXAD20==14 ;TRANSMIT ADDRESS 2 REGISTER OFFSET FROM THE CSR ADDRESS
TXBFCO==16 ;TRANSMIT COUNT REGISTER OFFSET FROM THE CSR ADDRESS

***** EQUATES USED WITH RESPECT TO THE RX BUFFER *****
RXBETX==16. ;LEVEL OF RX BUFFER AT WHICH TO RE-ENABLE TRANSMISSION.
RXBDTX==24. ;LEVEL OF RX BUFFER AT WHICH TO DISABLE TRANSMISSION.
RXBFUL==64. ;TOTAL CHARACTER CAPACITY OF THE RX BUFFER.

EQUALS

: BIT DIFINITIONS

BIT15== 100000
BIT14== 40000
BIT13== 20000
BIT12== 10000
BIT11== 4000
BIT10== 2000
BIT09== 1000
BIT08== 400
BIT07== 200
BIT06== 100
BIT05== 40
BIT04== 20
BIT03== 10
BIT02== 4
BIT01== 2
BIT00== 1

BIT9== BIT09
BIT8== BIT08
BIT7== BIT07
BIT6== BIT06

CVDHAAO DHV-11 FUNC TST PART1 MACY11 30A(1052) 12-JUL-83 10:52 PAGE 29
 CVDHAA.P11 12-JUL-83 00:42 GLOBAL EQUATES SECTION

```

1249      000040      BIT5== BIT05
1250      000020      BIT4== BIT04
1251      000010      BIT3== BIT03
1252      000004      BIT2== BIT02
1253      000002      BIT1== BIT01
1254      000001      BIT0== BIT00
1255      :
1256      : EVENT FLAG DEFINITIONS
1257      : EF32:EF17 RESERVED FOR SUPERVISOR TO PROGRAM COMMUNICATION
1258      :
1259      000040      EF.START==      32.      ; START COMMAND WAS ISSUED
1260      000037      EF.RESTART==     31.      ; RESTART COMMAND WAS ISSUED
1261      000036      EF.CONTINUE==    30.      ; CONTINUE COMMAND WAS ISSUED
1262      000035      EF.NEW==         29.      ; A NEW PASS HAS BEEN STARTED
1263      000034      EF.PWR==         28.      ; A POWER-FAIL/POWER-UP OCCURRED
1264      :
1265      :
1266      : PRIORITY LEVEL DEFINITIONS
1267      :
1268      000340      PRI07== 340
1269      000300      PRI06== 300
1270      000240      PRI05== 240
1271      000200      PRI04== 200
1272      000140      PRI03== 140
1273      000100      PRI02== 100
1274      000040      PRI01== 40
1275      000000      PRI00== 0
1276      :
1277      : OPERATOR FLAG BITS
1278      :
1279      000004      EVL==          4
1280      000010      LOT==         10
1281      000020      ADR==         20
1282      000040      IDU==         40
1283      000100      ISR==        100
1284      000200      UAM==        200
1285      000400      BOE==        400
1286      001000      PNT==       1000
1287      002000      PRI==       2000
1288      004000      IXE==       4000
1289      010000      IBE==      10000
1290      020000      IER==      20000
1291      040000      LOE==      40000
1292      100000      HOE==     100000
1293

```

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 30
GLOBAL EQUATES SECTION

1294
1295
1296
1297
1298
1299
1300
1301
1302
1303
1304
1305
1306
1307
1308
1309
1310
1311
1312
1313
1314
1315
1316
1317
1318
1319
1320
1321
1322
1323
1324
1325
1326
1327
1328
1329
1330
1331
1332
1333
1334
1335
1336
1337
1338
1339
1340
1341
1342
1343
1344
1345
1346
1347
1348
1349

.SBTTL GLOBAL DATA SECTION

;++
: THE GLOBAL DATA SECTION CONTAINS DATA THAT ARE USED
: IN MORE THAN ONE TEST.
:--

: UNIT VARIABLE AREA
:*****

ACTLNS:: .WORD 377 ;ACTIVE LINE BIT MAP.
UNITN:: .WORD 0 ;UNIT NUMBER.

: DEVICE REGISTER ADDRESS TABLE
:*****

DRADRT::
CSRA:: .WORD 160020 ;DHV-11 CSR ADDRESS
TXCHA:: RBUFA:: .WORD 160022 ;DHV-11 RECEIVE/TRANSMIT BUFFER ADDRESS
LPRA:: .WORD 160024 ;DHV-11 LINE PARAMETER REGISTER ADDRESS
STATA:: .WORD 160026 ;DHV-11 STATUS REGISTER ADDRESS
LNCTRA:: .WORD 160030 ;DHV-11 LINE CONTROL REGISTER ADDRESS
TXAD1A:: .WORD 160032 ;DHV-11 TRANSMIT BUFFER 1 REGISTER ADDRESS
TXAD2A:: .WORD 160034 ;DHV-11 TRANSMIT BUFFER 2 REGISTER ADDRESS
TXBFCA:: .WORD 160036 ;DHV-11 TRANSMIT BUFFER COUNT REGISTER ADDRESS

: BIT MASK TABLE OF UN-USED DHV DEVICE REGISTER BITS.
:*****

UNBTTB:: .WORD 137660 ;UNUSED BIT MASK FOR THE CSR
 .WORD 177777 ;UNUSED BIT MASK FOR THE RBUF/TX REG
 .WORD 7 ;UNUSED BIT MASK FOR THE LPR
 .WORD 177777 ;UNUSED BIT MASK FOR THE STAT
 .WORD 166051 ;UNUSED BIT MASK FOR THE LNCTRL
 .WORD 0 ;UNUSED BIT MASK FOR THE TBUFFAD1
 .WORD 77700 ;UNUSED BIT MASK FOR THE TBUFFAD2
 .WORD 0 ;UNUSED BIT MASK FOR THE TBUFFCT

: REGISTER MESSAGE ADDRESS TABLE
:*****

RMATBB:: .WORD DR00MG ;ADDRESS OF "CSR" MESSAGE.
 .WORD DR02MG ;ADDRESS OF "RBUF" MESSAGE.
 .WORD DR04MG ;ADDRESS OF "LPR" MESSAGE.
 .WORD DR06MG ;ADDRESS OF "STAT" MESSAGE.
 .WORD DR10MG ;ADDRESS OF "LNCTRL" MESSAGE.
 .WORD DR12MG ;ADDRESS OF "TBUFFAD1" MESSAGE.
 .WORD DR14MG ;ADDRESS OF "TBUFFAD2" MESSAGE.
 .WORD DR16MG ;ADDRESS OF "TBUFFCT" MESSAGE.

: ASSORTED GLOBAL VARIABLES:
:*****

CV
CV

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 31
GLOBAL DATA SECTION

1350
1351 002274 000001
1352 002276 000000
1353 002300 000000
1354 002302 000000
1355 002304 000000
1356 002306 000000
1357 002310 000000

```
*****
TSTNUM:: .WORD 1 ;STORAGE FOR THE TEST NUMBER.
IESTAT:: .WORD 0 ;STORAGE FOR THE INTERRUPT ENABLE BIT STATES.
PASCNT:: .WORD 0 ;STO'G FOR PASS COUNT USED IN ROM VERSION# TST.
TP4VEC:: .WORD 0 ;STORAGE FOR THE NORMAL 004 TRAP VECTOR.
TP4FLG:: .WORD 0 ;FLAGS SET WHEN AN EXPECTED 004 TRAP OCCURS.
WORD1:: .WORD 0 ;LOCATION FOR PASSING INDIRECT PARAMETERS.
CTRLCF:: .WORD 0 ;STORAGE FOR THE CONTROL-C FLAG.
*****
```

1358
1359
1360
1361
1362 002312 177546
1363 002314 000300
1364 002316 000100
1365 002320 000074
1366 002322 000000
1367 002324 000000
1368 002326 000170
1369 002330 000170
1370 002332 000021
1371 002334 000062

```
*****
: LINE TIME CLOCK VARIABLES AND STORAGE.
*****
CLKCSR:: .WORD 177546 ;CSR ADDRESS OF THE LTC.
CLKBRL:: .WORD PRI06 ;INTERRUPT PRIORITY LEVEL OF THE LTC.
CLKVEC:: .WORD 100 ;INTERRUPT VECTOR ADDRESS OF THE LTC.
CLKHRZ:: .WORD 60. ;INTERRUPT FREQUENCY OF THE LTC.
TIMER1:: .WORD 0 ;HARDWARE CLOCK COUNTER #1.
TIMER2:: .WORD 0 ;HARDWARE CLOCK COUNTER #2.
TIMER3:: .WORD 120. ;HARDWARE BREAK COUNTER LOCATION.
BCOUNT:: .WORD 120. ;BREAK COUNT VALUE IN CLOCK TICKS.
MSTICK:: .WORD 17. ;NUMBER OF MILLI-SECONDS PER LTC TICK.
MSLCNT:: .WORD 62 ;LOOP COUNT (USED BY MSLOOP) TO DELAY 1 MS.
*****
```

1372
1373
1374
1375
1376 002336 177572
1377 002340 000000
1378 002342 000000
1379 002344 172340

```
*****
: MEMORY MANAGEMENT VARIABLES AND FLAGS.
*****
MMSRO:: .WORD 177572 ;ADDRESS OF MEM MGT STATUS REGISTER #0.
MMPRES:: .WORD 0 ;MEM MGT PRESENT FLAG (0 IF MM NOT PRESENT).
MMENAB:: .WORD 0 ;MEM MGT ENABLED FLAG (0 IF MM NOT ENABLED).
PAR0A:: .WORD 172340 ;ADDRESS OF MEM MGT PAR #0.
*****
```

1380
1381
1382
1383
1384 002346 000001
1385 002350 000002
1386 002352 000004
1387 002354 000010
1388 002356 000020
1389 002360 000040
1390 002362 000100
1391 002364 000200
1392 002366 000400
1393 002370 001000
1394 002372 002000
1395 002374 004000
1396 002376 010000
1397 002400 020000
1398 002402 040000
1399 002404 100000

```
*****
: TABLE OF WORDS WITH CORRESPONDING BIT SET FOR GENERATION OF BIT MAPS.
*****
BITTBL:: .WORD 1 ;BIT 0 SET.
: .WORD 2 ;BIT 1 SET.
: .WORD 4 ;BIT 2 SET.
: .WORD 10 ;BIT 3 SET.
: .WORD 20 ;BIT 4 SET.
: .WORD 40 ;BIT 5 SET.
: .WORD 100 ;BIT 6 SET.
: .WORD 200 ;BIT 7 SET.
: .WORD 400 ;BIT 8 SET.
: .WORD 1000 ;BIT 9 SET.
: .WORD 2000 ;BIT 10 SET.
: .WORD 4000 ;BIT 11 SET.
: .WORD 10000 ;BIT 12 SET.
: .WORD 20000 ;BIT 13 SET.
: .WORD 40000 ;BIT 14 SET.
: .WORD 100000 ;BIT 15 SET.
*****
```

1400
1401
1402
1403
1404 002406
1405 002406 000000

```
*****
: * GPR SAVE AREA ZERO.
*****
GPRSOB:: ;BASE OF GPR SAVE AREA NUMBER ZERO.
: .WORD 0 ;WORD 1, STORAGE FOR R1.
*****
```

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 32
GLOBAL DATA SECTION

1406 002410 000000
1407 002412 000000
1408 002414 000000
1409 002416 000000
1410
1411
1412
1413
1414 002420 000000
1415 002422 000020
1416
1417
1418
1419
1420 002462 000000
1421 002464 000100
1422 002664
1423
1424 002664
1425 002664
1426 002664 000000
1427 002666 000000
1428 002670 000000
1429 002672 000000
1430
1431

.WORD 0 ;WORD 2, STORAGE FOR R2.
.WORD 0 ;WORD 3, STORAGE FOR R3.
.WORD 0 ;WORD 4, STORAGE FOR R4.
.WORD 0 ;WORD 5, STORAGE FOR R5.

: * TRANSMISSION AND RECEPTION VARIABLES, POINTERS, AND FLAGS.
: *****
ERSMRF:: .WORD 0 ;ERROR SUMMARY REPORT FLAGS.
ERCNTB:: .BLKW 16. ;TABLE OF ERROR COUNTERS.

: STORAGE AREA FOR THE BMP CODE QUEUE.
: *****
BMPCQP:: .WORD 0 ;POINTER USED TO ACCESS THE NEXT CELL IN QUE.
BMPCQB:: .BLKW 64. ;STORAGE FOR 32 CELLS, TEST# PLUS BMP CODE.
BMPCQE:: ;LAST ADDRESS PLUS 2 OF THE BMP CODE QUEUE.

ERRTBL

L\$ERRTBL::

ERRTYP:: .WORD 0
ERRNBR:: .WORD 0
ERRMSG:: .WORD 0
ERRBLK:: .WORD 0

.EVEN

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 33
GPR HANDLING ROUTINES FOR SUBROUTINE CALLS.

1432
1433
1434
1435
1436
1437
1438
1439
1440
1441
1442
1443
1444
1445
1446
1447
1448
1449
1450
1451
1452
1453
1454
1455
1456
1457
1458
1459
1460
1461
1462
1463
1464
1465
1466
1467
1468

```

.SBTTL GPR HANDLING ROUTINES FOR SUBROUTINE CALLS.
*****
THERE ARE 4 ROUTINES AND MACRO DEFINITIONS USED FOR THE HANDLING OF
GPR VALUES DURING SUBROUTINE CALLS WITHIN THIS PROGRAM. THE FOUR
ROUTINES/MACRO CALLS HAVE THE FOLLOWING NAMES:

SAVE - MACRO DEFINITION USED AT THE BEGINNING OF A SUBROUTINE TO
      SAVE THE GPR CONTENTS FOR LATER RESTORATION.
PASS - MACRO DEFINITION USED AT THE END OF A SUBROUTINE TO RESTORE
      THE PREVIOUSLY SAVED GPR CONTENTS AND TO LEAVE THE CONTENTS
      OF THE SPECIFIED GPR(S) INTACT (NOT RESTORED).
PREG05 - SUBROUTINE WHICH IS CALLED FROM THE SAVE AND PASS MACRO
        EXPANSIONS WHICH ACTUALLY PERFORMS THE ACTIONS ON THE GPRS.

DURING A SUBROUTINE WHICH USES THESE GPR SAVE ROUTINES THE VALUES
OF THE GPRS ARE STORED ON THE STACK IN THE FOLLOWING STACK FRAME:

      SP    -> RET PC INTO PREG05 ROUTINE.
      SF+2  -> GPR R0 CONTENTS.
      SP+4  -> GPR R1 CONTENTS.
      SP+6  -> GPR R2 CONTENTS.
      SP+8  -> GPR R3 CONTENTS.
      SP+10 -> GPR R4 CONTENTS.
      SP+12 -> GPR R5 CONTENTS.
      SP+14 -> RET PC INTO CALLER OF SUB'TNE WHICH CALLED PREG05.

EACH LEVEL OF SUB'TNE CALLING USES 8 WORDS OF STACK OVERHEAD.
THE SAVE AND PASS MACROS CAN ALSO BE USED IN "STRAIGHT LINE CODE"
TO SAVE AND RESTORE THE GPR VALUES. IN ANY CASE, AFTER THE
ISSUING OF A PASS CALL THE GPRS WILL BE RESTORED TO THE VALUES
THEY HAD PRIOR TO THE LAST SAVE CALL (EXCEPT FOR THE EXCEPTED,
OR PASSED INTACT, GPRS SPECIFIED AS PARAMETERS TO THE PASS CALL)
AND THE SP WILL ALSO BE RESTORED TO ITS CONDITION BEFORE THE LAST
SAVE CALL. THE PROGRAMMER MUST BE SURE THAT THE SP HAS THE SAME
VALUE WHEN THE PASS MACRO IS CALLED AS IT HAD IMMEDIATELY AFTER
THE SAVE MACRO WAS CALLED.
*****

```

CV
CV

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 34
GPR FRAME ACCESS EQUATES

.SBTTL GPR FRAME ACCESS EQUATES

:+++
:EQUATES THAT ALLOW ACCESS TO THE STACK FRAME. THESE ARE THE
:OFFSETS INTO THE STACK FOR REGISTERS SAVED DURING THE PREG05
:ROUTINE.
:---

1469
1470
1471
1472
1473
1474
1475
1476
1477
1478
1479
1480
1481
1482
1483

000036
000016
000014
000012
000010
000006
000004
000002

LPCSLT== 36 :OFFSET FOR LAST RETURN PC.
PCSLOT== 16 :OFFSET FOR RETURN PC.
R5SLOT== 14 :OFFSET FOR R5.
R4SLOT== 12 :OFFSET FOR R4.
R3SLOT== 10 :OFFSET FOR R3.
R2SLOT== 6 :OFFSET FOR R2.
R1SLOT== 4 :OFFSET FOR R1.
ROSLOT== 2 :OFFSET FOR R0.

CV
CV

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 35
GLOBAL MACRO DEFINITION - SAVE -

1484
1485
1486
1487
1488
1489
1490
1491
1492
1493
1494
1495
1496
1497
1498
1499
1500
1501
1502
1503
1504
1505
1506
1507

```

.SBTTL GLOBAL MACRO DEFINITION - SAVE -
*****
* THIS MACRO IS USED AT THE BEGINNING OF A SUBROUTINE TO SAVE THE
* CONTENTS OF THE GPRS R0 THRU R5.
*
* INPUTS: SP - UNCHANGED SINCE SUBROUTINE WAS ENTERED
* R5SLOT - OFFSET TO STACK SLOT FOR R5 (EQUATED TO 14 OCTAL)
*
* OUTPUTS: GPR SAVE AREA ON THE STACK IS LOADED WITH THE CONTENTS OF GPRS
* TOP OF STACK - LOADED WITH THE RETURN ADDRESS INTO PREG05
*
* CALLING SEQUENCE: SAVE
*
* COMMENTS: NO ARGUMENTS ARE ALLOWED.
* THE PASS MACRO SHOULD BE CALLED TO RESTORE THE GPR VALUES.
*
* SUBORDINATE ROUTINES CALLED: PREG05.
*****

```

```

.MACRO SAVE
.LIST JSR R5,PREG05 ;CALL REGISTER SAVE SUBRT.
.NLIST
.ENDM SAVE

```

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 36
GLOBAL MACRO DEFINITION - PASS -

1508
1509
1510
1511
1512
1513
1514
1515
1516
1517
1518
1519
1520
1521
1522
1523
1524
1525
1526
1527
1528
1529
1530
1531
1532
1533
1534
1535
1536
1537
1538
1539
1540
1541
1542
1543
1544
1545
1546
1547
1548
1549
1550
1551
1552
1553
1554
1555

```

.SBTTL GLOBAL MACRO DEFINITION - PASS -
*****
* THIS MACRO IS USED IN CONJUNCTION WITH THE SAVE MACRO. IT IS
* CALLED AT END OF A SUBROUTINE TO PASS PARAMETERS IN GPRS BACK TO THE
* CALLING ROUTINE BY ALTERING THE GPR SAVE AREA ON THE STACK AND THEN
* RETURNING TO PREG05 TO RESTORE THE GPRS TO THEIR SAVED VALUES.
*
* INPUTS: ONLY ALLOWED ARGUMENTS ARE 'R0' THRU 'R5'.
* ROSLOT THRU R5SLOT MUST BE EQUATED TO THEIR RESPECTIVE GPR SAVE
* SLOT OFFSETS BEFORE CALLING THIS MACRO.
*
* OUTPUTS: THE GPR VALUES ARE PUT IN THEIR RESPECTIVE SLOTS ON THE STACK.
*
* CALLING SEQUENCE: PASS R0,R1,...
*
* COMMENTS: ANY COMBINATION OF GPR ARGUMENTS MAY BE LISTED IN ANY ORDER.
* FOR EXAMPLE, THE FOLLOWING ARE LEGAL:
* PASS R1
* PASS R4,R0,R2
* THE GPRS LISTED AS ARGUMENTS WILL BE PASSED INTACT TO THE
* CALLING ROUTINE, ALL OTHER GPRS WILL BE RESTORED.
* THE SP MUST BE AT ITS ORIGINAL VALUE WHEN PASS IS CALLED.
*
* THE MACRO CALL
* PASS R0,R3
* EXPANDS INTO THE FOLLOWING ASSEMBLY CODE:
* MOV R0,ROSLOT(SP) ;PUT R0 IN STACK SLOT.
* MOV R3,R3SLOT(SP) ;PUT R3 IN STACK SLOT.
* JSR PC,@(SP)+ ;RETURN TO PREG05 SUBRT.
* IN THIS EXAMPLE GPRS R1, R2, R4, AND R5 WILL BE RESTORED TO
* THEIR VALUES CONTAINED IN THE STACK FRAME AND R0 AND R3
* WILL BE LEFT AT THEIR VALUES PRIOR TO THIS PASS CALL.
*
* SUBORDINATE ROUTINES CALLED: (PREGRT - LABEL WITHIN PREG05, VALUE ON STACK.)
*****
.MACRO PASS A,B,C,D,E,F
.IRP X,<A,B,C,D,E,F>
.IF NB,X
.LIST
MOV X,X'SLOT(SP) ;PUT X IN STACK SLOT.
.NLIST
.ENDC
.ENDM
.LIST
JSR PC,@(SP)+ ;RETURN TO PREG05 SUBRT.
.NLIST
.ENDM PASS

```

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 37
GLOBAL SUBROUTINE - PREG05 -

```

1556 .SBTTL GLOBAL SUBROUTINE - PREG05 -
1557 :*****
1558 :* PRESERVE REGISTERS R0 THROUGH R5 FOR SUBROUTINE CALLS.
1559 :*
1560 :* INPUTS: THE RETURN ADDRESS BACK INTO THE CALLING ROUTINE MUST BE IN
1561 :* GPR R5. (I.E.- MACROS USE "JSR R5,PREG05".)
1562 :*
1563 :* OUTPUTS: REGISTERS R0 THROUGH R5 ARE SAVED ON THE STACK.
1564 :*
1565 :*CALLING SEQUENCE: SAVE ;MACRO EXPANSION CALLS PREG05.
1566 :* [SUBROUTINE CODE]...
1567 :* PASS ;MACRO EXPANSION RECALLS PREG05.
1568 :*
1569 :*COMMENTS: THIS ROUTINE IS RE-ENTRANT.
1570 :*
1571 :* PARAMETERS MAY BE PASSED OUT OF A SUBROUTINE BY MODIFYING THE
1572 :* REGISTER SAVE AREA ON THE STACK. USE THE PASS GPRN MACRO
1573 :* TO RETURN GPR VALUES INTACT.
1574 :* USE THE RNSLOT OFFSETS FROM THE SP TO PASS OTHER PARAMETERS.
1575 :* [EXAMPLE: MOV VALUE,R0SLOT(SP) ]
1576 :* MAKE SURE THE SP IS AT ITS ORIGINAL VALUE WHEN YOU DO THIS.
1577 :*
1578 :*SUBORDINATE ROUTINES CALLED: NONE.
1579 :*****
1580
1581 002674 PREG05: ;R5 HAS BEEN LOADED ON THE STACK BY THE SUBROUTINE CALL
1582 002674 010446 MOV R4,-(SP) ;SAVE R4
1583 002676 010346 MOV R3,-(SP) ;SAVE R3
1584 002700 010246 MOV R2,-(SP) ;SAVE R2
1585 002702 010146 MOV R1,-(SP) ;SAVE R1
1586 002704 010046 MOV R0,-(SP) ;SAVE R0
1587 002706 010546 MOV R5,-(SP) ;PUSH RETURN PC ON TOP OF STACK
1588 002710 016605 000014 MOV R5SLOT(SP),R5 ;RESTORE R5 TO VALUE IT HAD BEFORE CALLS
1589
1590 002714 004736 JSR PC,@(SP)+ ;CALL THE SUBROUTINE AT THE RETURN ADDRESS
1591 ;FROM THE PREG05 CALL, PUTTING THE PRESENT
1592 ;PC ON THE STACK AS A RETURN ADDRESS INTO
1593 ;THIS (PREG05) ROUTINE.
1594
1595 :+++
1596 :THE FOLLOWING CODE IS EXECUTED WHEN THE CALLING ROUTINE DOES A
1597 :"RETURN" [JSR PC,@(SP)+] USING THE PC DEPOSITED ON THE STACK ABOVE.
1598 :---
1599
1600 002716 012605 PREGRT:: MOV (SP)+,R5 ;PUT RETURN PC IN R5.
1601 002720 012600 MOV (SP)+,R0 ;RESTORE R0.
1602 002722 012601 MOV (SP)+,R1 ;RESTORE R1.
1603 002724 012602 MOV (SP)+,R2 ;RESTORE R2.
1604 002726 012603 MOV (SP)+,R3 ;RESTORE R3.
1605 002730 012604 MOV (SP)+,R4 ;RESTORE R4.
1606
1607 002732 000205 RTS R5 ;RETURN TO THE SUBROUTINE WHICH CALLED PREG05.
1608 ;RESTORING R5 IN THE PROCESS.

```

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 38
GLOBAL TEXT SECTION

.SBTTL GLOBAL TEXT SECTION

:++
: THE GLOBAL TEXT SECTION CONTAINS FORMAT STATEMENTS,
: MESSAGES, AND ASCII INFORMATION THAT ARE USED IN
: MORE THAN ONE TEST.
:--

:
: NAMES OF DEVICES SUPPORTED BY PROGRAM
:

DEVTYP <DHV-11>

LSDVTYP::
.ASCIZ /DHV-11/
.EVEN

: TEST DESCRIPTION
:

DESCRIPT <DHV-11 FUNC TST PART1>

L\$DESC::
.ASCIZ /DHV-11 FUNC TST
.EVEN

1609
1610
1611
1612
1613
1614
1615
1616
1617
1618
1619
1620
1621
1622
1623
1624
1625
1626
1627
1628
1629
1630
1631
1632
1633
1634
1635
1636
1637
1638
1639

002734
002734
002734 044104 026526 030461
002742 000
002744

002744
002744
002744 044104 026526 030461
002752 043040 047125 020103
002760 051524 020124 040520
002766 052122 000061

.EVEN

CVDHAAO DHV-11 FUNC TST PART1 MACY11 30A(1052) 12-JUL-83 10:52 PAGE 39
 CVDHAA.P11 12-JUL-83 00:42 GLOBAL TEXT SECTION

```

:
: FORMAT STATEMENTS USED IN PRINT CALLS
:

```

```

1640
1641
1642
1643
1644
1645
1646
1647
1648
1649
1650 .NLIST BIN
1651 .SBTTL GLOBAL MESSAGE AREA
1652 : ***** FORMAT STATEMENTS *****
1653 MFUNIT:: .ASCIZ /%N% TESTING UNIT :%D4%(D)%N/
1654 002772
1655 003000
1656 003006
1657 003014
1658 003022
1659 003030 EF0503:: .ASCIZ /%T%N/
1660 003035 EF1401:: .ASCIZ /%N% ROM VERSION NUMBERS: PROC_1 = %D2%(D) PROC_2 = %D2%(D)%N/
1661 003042
1662 003050
1663 003056
1664 003064
1665 003072
1666 003100
1667 003106
1668 003114
1669 003122
1670 003130
1671 003136 EF1402:: .ASCIZ /%T% ROM VERSION NUMBER %T%N/
1672 003144
1673 003152
1674 003160
1675 003166
1676 003174 EF1601:: .ASCIZ /%A %T% ABORTED %N/
1677 003202
1678 003210
1679 003216
1680 003220 EF1602:: .ASCIZ /%A EXPECTED DATA: %O6%(O)%N/
1681 003226
1682 003234
1683 003242
1684 003250
1685 003256
1686 003262 EF1603:: .ASCIZ /%A ACTUAL DATA: %O6%(O)%N/
1687 003270
1688 003276
1689 003304
1690 003312
1691 003320
1692 003324 EF1604:: .ASCIZ /%A BAD BIT(S) IN DEVICE %T% REGISTER FOR LINE %D2%(D)%N/
1693 003332
1694 003340
1695 003346

```

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 40
GLOBAL MESSAGE AREA

```

1696 003354
1697 003362
1698 003370
1699 003376
1700 003404
1701 003412
1702 003420
1703 003421 EF9001:: .ASCIZ /%A UNEXPECTED %T%A FOUND IN RECEIVE CHAR FIFO:%N/
1704 003426
1705 003434
1706 003442
1707 003450
1708 003456
1709 003464
1710 003472
1711 003500
1712 003503 EF9002:: .ASCIZ /%A CODE IS ASSOCIATED WITH LINE: %D2%A(D)%N/
1713 003510
1714 003516
1715 003524
1716 003532
1717 003540
1718 003546
1719 003554
1720 003562 EF9003:: .ASCIZ /%A CODE IS: %O3%A(O)%N/
1721 003570
1722 003576
1723 003604
1724 003612
1725 003616 EF9004:: .ASCIZ /%A %T%A VALUE: %O3%A(O)%N/
1726 003624
1727 003632
1728 003640
1729 003646
1730 003653 EF9005:: .ASCIZ /%A %T%A VALUE: NONE%N/
1731 003660
1732 003666
1733 003674
1734 003702
1735 003704 EF9006:: .ASCIZ /%A %T%A %D2%A(D)%N/
1736 003712
1737 003720
1738 003726
1739 003730 EF9010:: .ASCIZ /%A NUMBER OF ERRORS DETECTED ON LINE %D2%A(D) IS %D5%A(D)%N/
1740 003736
1741 003744
1742 003752
1743 003760
1744 003766
1745 003774
1746 004002
1747 004010
1748 004016
1749 004024
1750 004027 EF9016:: .ASCIZ /%A UNEXPECTED %T%A FOR LINE %D2%A(D) IN FIFO AFTER RESET:%N/
1751 004034

```


CVDHAAO DHV-11 FUNC TST PART1 MACY11 30A(1052) 12-JUL-83 10:52 PAGE 41
 CVDHAA.P11 12-JUL-83 00:42 GLOBAL MESSAGE AREA

```

1752 004042
1753 004050
1754 004056
1755 004064
1756 004072
1757 004100
1758 004106
1759 004114
1760 004122
1761 004124 EF9017:: .ASCIZ /%A %T%A (WITH ERROR FLAGS) IS %06%A(0)%N/
1762 004132
1763 004140
1764 004146
1765 004154
1766 004162
1767 004170
1768 004176
1769 004200 EF9018:: .ASCII /%A %T%A IN SELFTTEST CODE FIFO SLOT FOR LINE %D2/
1770 004206
1771 004214
1772 004222
1773 004230
1774 004236
1775 004244
1776 004252
1777 004260 .ASCIZ /%A(D) AFTER RESET.%N/
1778 004266
1779 004274
1780 004302
1781 004305 EF9019:: .ASCIZ /%A %T%A %06%A(0)%N/
1782 004312
1783 004320
1784 004326
1785 004331 EF9301:: .ASCIZ /%A %T%D2%A(D), BMP CODE REPORTED :%03%A(0)%N/
1786 004336
1787 004344
1788 004352
1789 004360
1790 004366
1791 004374
1792 004402
1793 004407 EF9302:: .ASCIZ /%A OVERFLOW OCCURRED (MORE THAN 31 BMP CODES FOUND IN QUEUE)%N/
1794 004414
1795 004422
1796 004430
1797 004436
1798 004444
1799 004452
1800 004460
1801 004466
1802 004474
1803 004502
1804 ;***** ERROR MESSAGES *****
1805 004507 DR00MG:: .ASCIZ /CSR/
1806 004513 DR02MG:: .ASCIZ /RBUF/
1807 004520 DR04MG:: .ASCIZ /LPR/

```

CVDHAAO DHV-11 FUNC TST PART1 MACY11 30A(1052) 12-JUL-83 10:52 PAGE 42
CVDHAA.P11 12-JUL-83 00:42 GLOBAL MESSAGE AREA

```
1808 004524 DR06MG:: .ASCIZ /STAT/
1809 004531 DR10MG:: .ASCIZ /LNCTRL/
1810 004536
1811 004540 DR12MG:: .ASCIZ /TBUFFAD1/
1812 004546
1813 004551 DR14MG:: .ASCIZ /TBUFFAD2/
1814 004556
1815 004562 DR16MG:: .ASCIZ /TBUFFCT/
1816 004570
1817 004572 EM0103:: .ASCIZ /DEVICE REGISTER ACCESS ERRORS/
1818 004600
1819 004606
1820 004614
1821 004622
1822 004630 EM0201:: .ASCIZ /MASTER RESET (PERFORM SELFTEST) TEST /
1823 004636
1824 004644
1825 004652
1826 004660
1827 004666
1828 004674
1829 004676 EM0202:: .ASCIZ / MASTER RESET BIT DID NOT CLEAR AFTER BOARD RESET./
1830 004704
1831 004712
1832 004720
1833 004726
1834 004734
1835 004742
1836 004750
1837 004756
1838 004762 .ASCIZ / WAITED 5 SECONDS. BIT DEFECTIVE OR FIRMWARE HUNG./
1839 004770
1840 004776
1841 005004
1842 005012
1843 005020
1844 005026
1845 005034
1846 005042
1847 005050
1848 005051 EM0203:: .ASCIZ / MASTER RESET BIT CLEAR IMMEDIATELY AFTER BOARD RESET./
1849 005056
1850 005064
1851 005072
1852 005100
1853 005106
1854 005114
1855 005122
1856 005130
1857 005136
1858 005141 .ASCIZ / BIT DEFECTIVE OR BOARD FIRMWARE ERROR./
1859 005146
1860 005154
1861 005162
1862 005170
1863 005176
```

CVDHAAO DHV-11 FUNC TST PART1 MACY11 30A(1052) 12-JUL-83 10:52 PAGE 43
CVDHAA.P11 12-JUL-83 00:42 GLOBAL MESSAGE AREA

```
1864 005204
1865 005212
1866 005214 EM0204:: .ASCIZ \ MR BIT WENT CLEAR WITHIN 1/2 SECOND OF BOARD RESET.\
1867 005222
1868 005230
1869 005236
1870 005244
1871 005252
1872 005260
1873 005266
1874 005274
1875 005302 .ASCIZ / BIT DEFECTIVE OR SELFTEST WAS (INCORRECTLY) SKIPPED./
1876 005310
1877 005316
1878 005324
1879 005332
1880 005340
1881 005346
1882 005354
1883 005362
1884 005370
1885 005373 EM0301:: .ASCIZ /MASTER RESET (SKIP SELFTEST) TEST /
1886 005400
1887 005406
1888 005414
1889 005422
1890 005430
1891 005436 EM0302:: .ASCIZ / MR BIT CLR WITHIN 10 MILISECOND AFTER BOARD RESET./
1892 005444
1893 005452
1894 005460
1895 005466
1896 005474
1897 005502
1898 005510
1899 005516
1900 005523 .ASCIZ / BIT DEFECTIVE OR BOARD FIRMWARE ERROR./
1901 005530
1902 005536
1903 005544
1904 005552
1905 005560
1906 005566
1907 005574
1908 005576 EM0303:: .ASCIZ \ MR BIT WENT CLEAR 1/5 TO 5 SECONDS AFTER RESET.\
1909 005604
1910 005612
1911 005620
1912 005626
1913 005634
1914 005642
1915 005650
1916 005656
1917 005660 .ASCIZ / SELFTEST DID NOT GET SKIPPED (SHOULD HAVE BEEN SKIPPED)./
1918 005666
1919 005674
```

CVDHAAO DHV-11 FUNC TST PART1 MACY11 30A(1052) 12-JUL-83 10:52 PAGE 44
CVDHAA.P11 12-JUL-83 00:42 GLOBAL MESSAGE AREA

```
1920 005702
1921 005710
1922 005716
1923 005724
1924 005732
1925 005740
1926 005746
1927 005754
1928 005755 EM0401:: .ASCIZ /RBUF REGISTER RX CHARACTER FIELD TEST /
1929 005762
1930 005770
1931 005776
1932 006004
1933 006012
1934 006020
1935 006024 EM0402:: .ASCIZ / IMPROPER CODE FOUND IN RX FIFO AFTER DUT RESET./
1936 006032
1937 006040
1938 006046
1939 006054
1940 006062
1941 006070
1942 006076
1943 006104
1944 006106 .ASCIZ / EXPECTED: SELFTEST CODE. ACTUAL: IMPROPER CODE./
1945 006114
1946 006122
1947 006130
1948 006136
1949 006144
1950 006152
1951 006160
1952 006166
1953 006174 EM0501:: .ASCIZ /RBUF REGISTER ERROR FLAGS FIELD TEST /
1954 006202
1955 006210
1956 006216
1957 006224
1958 006232
1959 006240
1960 006242 EM0502:: .ASCIZ / RX ERROR FLAG(S) FOUND CLEAR ON SELFTEST CODE./
1961 006250
1962 006256
1963 006264
1964 006272
1965 006300
1966 006306
1967 006314
1968 006322
1969 006323 .ASCIZ / EXPECTED: ALL ERROR FLAGS SET, ACTUAL: FLAG(S) CLEAR./
1970 006330
1971 006336
1972 006344
1973 006352
1974 006360
1975 006366
```

CVDHAAO DHV-11 FUNC TST PART1 MACY11 30A(1052) 12-JUL-83 10:52 PAGE 45
CVDHAA.P11 12-JUL-83 00:42 GLOBAL MESSAGE AREA

```
1976 006374
1977 006402
1978 006410
1979 006416 EM0601:: .ASCIZ /CSR RX.DATA.AVAIL BIT TEST /
1980 006424
1981 006432
1982 006440
1983 006446
1984 006452 EM0602:: .ASCIZ / RX.DATA.AVAIL BIT FOUND CLEAR AFTER RESET COMPLETION./
1985 006460
1986 006466
1987 006474
1988 006502
1989 006510
1990 006516
1991 006524
1992 006532
1993 006540
1994 006542 .ASCIZ / EXPECTED BIT TO BE SET FROM SELFTEST CODES IN FIFO./
1995 006550
1996 006556
1997 006564
1998 006572
1999 006600
2000 006606
2001 006614
2002 006622
2003 006630
2004 006632 EM0603:: .ASCIZ / RX.DATA.AVAIL BIT COULD NOT BE CLEARED BY PURGING FIFO./
2005 006640
2006 006646
2007 006654
2008 006662
2009 006670
2010 006676
2011 006704
2012 006712
2013 006720
2014 006724 .ASCIZ / 600 CHARS READ FROM FIFO WITHOUT R.D.A BIT CLEARING./
2015 006732
2016 006740
2017 006746
2018 006754
2019 006762
2020 006770
2021 006776
2022 007004
2023 007012
2024 007015 EM0701:: .ASCIZ /RBUF RX.DATA.VALID BIT TEST /
2025 007022
2026 007030
2027 007036
2028 007044
2029 007052 EM0702:: .ASCIZ / RX.DATA.VALID BIT FOUND CLEAR AFTER RESET COMPLETION./
2030 007060
2031 007066
```

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 46
GLOBAL MESSAGE AREA

2032 007074
2033 007102
2034 007110
2035 007116
2036 007124
2037 007132
2038 007140
2039 007142
2040 007150
2041 007156
2042 007164
2043 007172
2044 007200
2045 007206
2046 007214
2047 007222
2048 007230
2049 007232
2050 007240
2051 007246
2052 007254
2053 007262
2054 007270
2055 007276
2056 007304
2057 007312
2058 007320
2059 007324
2060 007332
2061 007340
2062 007346
2063 007354
2064 007362
2065 007370
2066 007376
2067 007404
2068 007412
2069 007415
2070 007422
2071 007430
2072 007436
2073 007444
2074 007452
2075 007455
2076 007462
2077 007470
2078 007476
2079 007504
2080 007512
2081 007520
2082 007526
2083 007530
2084 007536
2085 007544
2086 007552
2087 007560

.ASCIZ / EXPECTED BIT TO BE SET FROM SELFTEST CODES IN FIFO./

EM0703:: .ASCIZ / RX.DATA.VALID BIT COULD NOT BE CLEARED BY PURGING FIFO./

.ASCIZ / 600 CHARS READ FROM FIFO WITHOUT R.D.V BIT CLEARING./

EM0801:: .ASCIZ /RBUF RX.LINE.NUMBER FIELD TEST /

EM0802:: .ASCIZ / LINE NUMBER IS WRONG ON A SELFTEST CODE./

EM0901:: .ASCIZ /CHECK FOR BMP_CODES TEST/

CVDHAAO DHV-11 FUNC TST PART1 MACY11 30A(1052) 12-JUL-83 10:52 PAGE 47
CVDHAA.P11 12-JUL-83 00:42 GLOBAL MESSAGE AREA

```
2088 007561 EM0902:: .ASCIZ /UNEXPECTED BMP CODES FOUND./
2089 007566
2090 007574
2091 007602
2092 007610
2093 007615 EM1001:: .ASCIZ /DIAGNOSTIC FAIL (SKP SELFTEST) TEST/
2094 007622
2095 007630
2096 007636
2097 007644
2098 007652
2099 007660
2100 007661 EM1002:: .ASCIZ / SKIP SELF-TEST TOOK TOO LONG TO COMPLETE, > 50 MS./
2101 007666
2102 007674
2103 007702
2104 007710
2105 007716
2106 007724
2107 007732
2108 007740
2109 007746 EM1003:: .ASCIZ / SKIP SELF-TEST COMPLETED TOO SOON, < 10 MS./
2110 007754
2111 007762
2112 007770
2113 007776
2114 010004
2115 010012
2116 010020
2117 010024 EM1101:: .ASCIZ /SKIP SELF-TEST TEST/
2118 010032
2119 010040
2120 010046
2121 010050 EM1201:: .ASCIZ /SELF-TEST TEST/
2122 010056
2123 010064
2124 010067 EM1202:: .ASCIZ / SELF-TEST TOOK TOO LONG TO COMPLETE, > 3 SECONDS./
2125 010074
2126 010102
2127 010110
2128 010116
2129 010124
2130 010132
2131 010140
2132 010146
2133 010153 EM1203:: .ASCIZ \ SELF-TEST COMPLETED TOO SOON, < 1/2 SECOND.\
2134 010160
2135 010166
2136 010174
2137 010202
2138 010210
2139 010216
2140 010224
2141 010231 EM1204:: .ASCIZ / SELF-TEST DID NOT EXECUTE/
2142 010236
2143 010244
```

CVDHAAO DHV-11 FUNC TST PART1 MACY11 30A(1052) 12-JUL-83 10:52 PAGE 48
CVDHAA.P11 12-JUL-83 00:42 GLOBAL MESSAGE AREA

```
2144 010252
2145 010260
2146 010265 EM1205:: .ASCIZ / DIAG_FAIL BIT BAD/
2147 010272
2148 010300
2149 010306
2150 010311 EM1301:: .ASCIZ /FAIL SELF-TEST TEST/
2151 010316
2152 010324
2153 010332
2154 010335 EM1302:: .ASCIZ / SELF-TEST ERROR REPORTING BAD/
2155 010342
2156 010350
2157 010356
2158 010364
2159 010372
2160 010374 EM1401:: .ASCIZ /ROM VERSION_NUMBER TEST/
2161 010402
2162 010410
2163 010416
2164 010424 EM1402:: .ASCIZ / FIFO EMPTY, ONE OR MORE ROM VERSION_NUMBERS MISSING/
2165 010432
2166 010440
2167 010446
2168 010454
2169 010462
2170 010470
2171 010476
2172 010504
2173 010512 EM1403:: .ASCIZ / ROM VERSION_NUMBER FOUND OUT OF SEQUENCE/
2174 010520
2175 010526
2176 010534
2177 010542
2178 010550
2179 010556
2180 010564
2181 010565 EM1404:: .ASCIZ / ONE OR MORE ROM VERSION_NUMBERS MISSING/
2182 010572
2183 010600
2184 010606
2185 010614
2186 010622
2187 010630
2188 010636
2189 010637 EM1405:: .ASCIZ / PROC_1/
2190 010644
2191 010652 EM1406:: .ASCIZ / PROC_2/
2192 010660
2193 010665 EM1407:: .ASCIZ /NOT FOUND/
2194 010672
2195 010677 EM1408:: .ASCIZ /FOUND/
2196 010704
2197 010705 EM1601:: .ASCIZ /TIMEOUT OCCURRED WAITING FOR MASTER RESET TO CLEAR/
2198 010712
2199 010720
```


CVDHAAO DHV-11 FUNC TST PART1 MACY11 30A(1052) 12-JUL-83 10:52 PAGE 49
CVDHAA.P11 12-JUL-83 00:42 GLOBAL MESSAGE AREA

```
2200 010726
2201 010734
2202 010742
2203 010750
2204 010756
2205 010764
2206 010770 EM1604:: .ASCIZ \DEVICE REGISTER WORD READ/WRITE TEST \
2207 010776
2208 011004
2209 011012
2210 011020
2211 011026
2212 011034
2213 011036 EM1701:: .ASCIZ \DEVICE REGISTER WORD READ/MODIFY/WRITE TEST \
2214 011044
2215 011052
2216 011060
2217 011066
2218 011074
2219 011102
2220 011110
2221 011113 EM1801:: .ASCIZ \DEVICE REGISTER BYTE READ/WRITE TEST \
2222 011120
2223 011126
2224 011134
2225 011142
2226 011150
2227 011156
2228 011161 EM1901:: .ASCIZ \DEVICE REGISTER BYTE READ/MODIFY/WRITE TEST \
2229 011166
2230 011174
2231 011202
2232 011210
2233 011216
2234 011224
2235 011232
2236 011236 EM2001:: .ASCIZ /DEVICE STAT REGISTER ID BIT TEST /
2237 011244
2238 011252
2239 011260
2240 011266
2241 011274
2242 011300 EM2002:: .ASCIZ /ID BIT BAD. EXPECTED: CLEAR, ACTUAL: SET./
2243 011306
2244 011314
2245 011322
2246 011330
2247 011336
2248 011344
2249 011352
2250 011353 EM9009:: .ASCIZ /EXPECTED OR CORRECT/
2251 011360
2252 011366
2253 011374
2254 011377 EM9010:: .ASCIZ /ACTUAL OR MEASURED /
2255 011404
```

CVDHAAO DHV-11 FUNC TST PART1 MACY11 30A(1052) 12-JUL-83 10:52 PAGE 50
CVDHAA.P11 12-JUL-83 00:42 GLOBAL MESSAGE AREA

```
2256 011412
2257 011420
2258 011423 EM9014:: .ASCIZ /SUMMARY REPORTS FOR LINES WITH EXCESSIVE NUMBERS OF ERRORS:/
2259 011430
2260 011436
2261 011444
2262 011452
2263 011460
2264 011466
2265 011474
2266 011502
2267 011510
2268 011516
2269 011517 EM9017:: .ASCII / FIFO WILL NOT PURGE (DATA.VALID STUCK SET),/
2270 011524
2271 011532
2272 011540
2273 011546
2274 011554
2275 011562
2276 011570
2277 011574 .ASCIZ / REMAINDER OF TEST SKIPPED./
2278 011602
2279 011610
2280 011616
2281 011624
2282 011630 EM9018:: .ASCIZ /NO CODE/
2283 011636
2284 011640 EM9019:: .ASCIZ /NON-SELFTEST/
2285 011646
2286 011654
2287 011655 EM9020:: .ASCIZ /SELFTEST ERROR CODE/
2288 011662
2289 011670
2290 011676
2291 011701 EM9022:: .ASCIZ /DATA CHARACTER/
2292 011706
2293 011714
2294 011720 EM9023:: .ASCIZ /MODEM STATUS CODE/
2295 011726
2296 011734
2297 011742 EM9024:: .ASCIZ /SELFTEST CODE/
2298 011750
2299 011756
2300 011760 EM9026:: .ASCIZ / LPR CONTENTS: /
2301 011766
2302 011774
2303 012002
2304 012004 EM9301:: .ASCIZ /BMP CODE REPORT/
2305 012012
2306 012020
2307 012024 EM9302:: .ASCIZ /BMP CODE FOUND IN TEST /
2308 012032
2309 012040
2310 012046
2311 012054 EM9303:: .ASCIZ /THE LAST BMP CODE WAS FOUND IN TEST /
```

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 51
GLOBAL MESSAGE AREA

2312 012062
2313 012070
2314 012076
2315 012104
2316 012112
2317 012120
2318 012121
2319 012126
2320 012134
2321 012142
2322 012150
2323 012156
2324 012164
2325 012172
2326
2327

EM9304:: .ASCIZ /UNEXPECTED BMP CODES FOUND DURING THIS PASS/

.EVEN

.LIST BIN

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 52
GLOBAL MESSAGE AREA

2328
2329
2330
2331
2332
2333
2334
2335
2336
2337

.SBTTL GLOBAL ERROR REPORT SECTION

:++
: THE GLOBAL ERROR REPORT SECTION CONTAINS MESSAGE PRINTING AREAS
: USED BY MORE THAN ONE TEST TO OUTPUT ADDITIONAL ERROR INFORMATION. PRINTB
: (BASIC) AND PRINTX (EXTENDED) CALLS ARE USED TO CALL PRINT SERVICES.
:--

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 53
GLOBAL ERROR REPORTING ROUTINE

- ER0101 -

2338
2339
2340
2341
2342
2343
2344
2345
2346
2347
2348
2349
2350
2351
2352
2353
2354
2355
2356
2357
2358
2359
2360
2361
2362
2363
2364
2365
2366
2367
2368
2369
2370
2371
2372
2373
2374
2375
2376
2377
2378
2379
2380
2381
2382
2383
2384
2385
2386
2387
2388
2389
2390
2391
2392
2393

```

.SBTTL GLOBAL ERROR REPORTING ROUTINE - ER0101 -
*****
: * THIS IS AN ERROR REPORTING SUBROUTINE WHICH PRINTS ADDITIONAL ERROR
: * INFORMATION IF AN ERROR IS DETECTED IN TEST 1 (REGISTER ADDRESS
: * ACCESS TEST). THIS SUBROUTINE REPORTS THE TYPE OF ACCESS (READ OR
: * WRITE OR BOTH) WHICH CAUSED A BUS TIME-OUT TRAP (004 TRAP).
: * A MESSAGE INDICATING THAT THE DHV MAY BE AT THE WRONG Q-BUS ADDRESS
: * IS ALSO PRINTED.
: *
: * INPUTS: R5 - ERROR FLAG WORD.
: * IF BIT 0 IS SET, A READ ERROR OCCURED.
: * IF BIT 1 IS SET, A WRITE ERROR OCCURED.
: *
: * OUTPUTS: MESSAGES ARE PRINTED AT THE OPERATOR CONSOLE.
: *
: * CALLING SEQUENCE: INCLUDE THE LABEL 'ER0101' AS THE MESSAGE POINTER
: * PARAMETER IN THE DRS ERROR REPORT MACRO CALL.
: *
: * COMMENTS:
: *
: * SUBORDINATE ROUTINES USED: NONE.
*****

```

```

012176 BGNMSG ER0101
012176 ER0101::
012176 SAVE ;SAVE THE GPR CONTENTS.
012176 004537 002674 JSR R5,PREG05 ;CALL REGISTER SAVE SUBRT.
012202 032705 000001 BIT #BIT0,R5 ;TEST FOR READ ERROR.
012206 001410 BEQ 2$ ;SKIP READ ERROR MSG IF NO READ ERROR.
012210 PRINTB #MSG1 ;PRINT READ ERROR MESSAGE.
012210 012746 012302 MOV #MSG1,-(SP)
012214 012746 000001 MOV #1,-(SP)
012220 010600 MOV SP,R0
012222 104414 TRAP C$PNTB
012224 062706 000004 ADD #4,SP
2$: 012230 032705 000002 BIT #BIT1,R5 ;TEST FOR WRITE ERROR.
012234 001410 BEQ 4$ ;SKIP WRITE ERROR MSG IF NO WRITE ERROR.
012236 PRINTB #MSG2 ;PRINT WRITE ERROR MESSAGE.
012236 012746 012360 MOV #MSG2,-(SP)
012242 012746 000001 MOV #1,-(SP)
012246 010600 MOV SP,R0
012250 104414 TRAP C$PNTB
012252 062706 000004 ADD #4,SP
4$: 012256 PRINTX #MSG3 ;SUGGEST THAT DHV MAY BE AT WRONG ADDRESS.
012256 012746 012437 MOV #MSG3,-(SP)
012262 012746 000001 MOV #1,-(SP)
012266 010600 MOV SP,R0
012270 104415 TRAP C$PNTX
012272 062706 000004 ADD #4,SP
012276 PASS ;RESTORE THE GPR CONTENTS.
012276 004736 JSR PC,@(SP)+ ;RETURN TO PREG05 SUBRT.
012300 ENDMSG
012300 L10002:
012300 104423 TRAP C$MSG

```

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 54
GLOBAL ERROR REPORTING ROUTINE

- ER0101 -

2394	012302	040445	052502	020123	MSG1:: .ASCIZ /%ABUS TIME-OUT TRAP CAUSED BY READ ATTEMPT.%N/
2395	012310	044524	042515	047455	
2396	012316	052125	052040	040522	
2397	012324	020120	040503	051525	
2398	012332	042105	041040	020131	
2399	012340	042522	042101	040440	
2400	012346	052124	046505	052120	
2401	012354	022456	000116		
2402	012360	040445	052502	020123	MSG2:: .ASCIZ /%ABUS TIME-OUT TRAP CAUSED BY WRITE ATTEMPT.%N/
2403	012366	044524	042515	047455	
2404	012374	052125	052040	040522	
2405	012402	020120	040503	051525	
2406	012410	042105	041040	020131	
2407	012416	051127	052111	020105	
2408	012424	052101	042524	050115	
2409	012432	027124	047045	000	
2410	012437	045	042101	053110	MSG3:: .ASCIZ /%ADHV MAY BE AT THE WRONG Q-BUS ADDRESS.%N%N/
2411	012444	046440	054501	041040	
2412	012452	020105	052101	052040	
2413	012460	042510	053440	047522	
2414	012466	043516	050440	041055	
2415	012474	051525	040440	042104	
2416	012502	042522	051523	022456	
2417	012510	022516	000116		
2418					
2419					.EVEN

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MAC:11 30A(1052) 12-JUL-83 10:52 PAGE 55
GLOBAL ERROR REPORTING ROUTINE

- ER0201 -

```

2420 .SBTTL GLOBAL ERROR REPORTING ROUTINE - ER0201 -
2421 *****
2422 * THIS IS AN ERROR REPORTING SUBROUTINE WHICH PRINTS 2 CONTIGUOUS
2423 * ASCII ERROR MESSAGES. THE ADDRESS OF THE FIRST MESSAGE IS PASSED
2424 * AS AN INPUT PARAMETER AND THE ADDRESS OF THE SECOND IS FOUND BY
2425 * SEARCHING FOR THE END OF THE FIRST MESSAGE.
2426 *
2427 * INPUTS: R1 - ADDRESS OF THE FIRST MESSAGE TO PRINT.
2428 *
2429 * OUTPUTS: A MESSAGES IS PRINTED AT THE OPERATOR CONSOLE.
2430 *
2431 * CALLING SEQUENCE: LOAD THE ADDRESS OF THE FIRST MESSAGE IN R1.
2432 * INCLUDE THE LABEL 'ER0201' AS THE MESSAGE POINTER
2433 * PARAMETER IN THE DIAG SUPER ERROR REPORT MACRO CALL.
2434 *
2435 * COMMENTS: THE MESSAGE IS PRINTED AS BASIC ERROR INFORMATION.
2436 * THE SECOND MESSAGE SHOULD FOLLOW THE FIRST ONE IN THE PROGRAM
2437 * MEMORY. EACH MESSAGE SHOULD BE DEFINED USING .ASCIZ
2438 *
2439 * SUBORDINATE ROUTINES USED: NONE.
2440 *****
2441
2442 012514 BGNMSG ER0201
2443 012514 ER0201::
2444 012514 SAVE ;SAVE THE GPR CONTENTS.
2445 012514 004537 002674 JSR R5,PREG05 ;CALL REGISTER SAVE SUBRT.
2446
2447 012520 010102
2448 012522 105722 2$: MOV R1,R2 ;CHECK FOR A ZERO BYTE (END OF MESSAGE).
2449 012524 001376 TSTB (R2)+ ;LOOP UNTIL NEXT MESSAGE IS FOUND.
2450 BNE 2$
2451 012526 PRINTB #EF0503,R1 ;PRINT THE FIRST MESSAGE.
2452 012526 010146 MOV R1,-(SP)
2453 012530 012746 003030 MOV #EF0503,-(SP)
2454 012534 012746 000002 MOV #2,-(SP)
2455 012540 010600 MOV SP,R0
2456 012542 104414 TRAP C$PNTB
2457 012544 062706 000006 ADD #6,SP
2458 012550 PRINTB #EF0503,R2 ;PRINT THE SECOND MESSAGE.
2459 012550 010246 MOV R2,-(SP)
2460 012552 012746 003030 MOV #EF0503,-(SP)
2461 012556 012746 000002 MOV #2,-(SP)
2462 012562 010600 MOV SP,R0
2463 012564 104414 TRAP C$PNTB
2464 012566 062706 000006 ADD #6,SP
2465
2466 012572 PASS ;RESTORE THE GPR CONTENTS.
2467 012572 004736 JSR PC,@(SP)+ ;RETURN TO PREG05 SUBRT.
2468
2469 012574 ENDMSG
2470 012574 L10003:
2471 012574 104423 TRAP C$MSG

```

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 56
GLOBAL ERROR REPORTING ROUTINE

- ER0503 -

2472
2473
2474
2475
2476
2477
2478
2479
2480
2481
2482
2483
2484
2485
2486
2487
2488
2489
2490
2491
2492
2493
2494
2495
2496
2497
2498
2499
2500
2501
2502
2503

012576
012576

012576 010146
012576 012746 003030
012600 012746 000002
012610 010600
012612 104414
012614 062706 000006

012620
012620
012620 104423

```
.SBTTL GLOBAL ERROR REPORTING ROUTINE - ER0503 -
*****
* THIS IS AN ERROR REPORTING SUBROUTINE WHICH PRINTS AN ADDITIONAL ERROR
* MESSAGE WHOSE ADDRESS IS PASSED AS AN INPUT PARAMETER.
*
* INPUTS: R1 - ADDRESS OF THE MESSAGE TO PRINT.
*
* OUTPUTS: A MESSAGES IS PRINTED AT THE OPERATOR CONSOLE.
*
* CALLING SEQUENCE: LOAD THE ADDRESS OF THE MESSAGE IN R1.
* INCLUDE THE LABEL 'ER0503' AS THE MESSAGE POINTER
* PARAMETER IN THE DIAG SUPER ERROR REPORT MACRO CALL.
*
* COMMENTS: THE MESSAGE IS PRINTED AS BASIC ERROR INFORMATION.
*
* SUBORDINATE ROUTINES USED: NONE.
*****
```

BGNMSG ER0503

ER0503::

PRINTB #EF0503,R1 ;PRINT THE MESSAGE.

```
MOV R1,-(SP)
MOV #EF0503,-(SP)
MOV #2,-(SP)
MOV SP,R0
TRAP C$PNTB
ADD #6,SP
```

ENDMSG

L10004:

```
TRAP C$MSG
```

CV
CV

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 57
GLOBAL ERROR REPORTING ROUTINE

- ER1401 -

2504
2505
2506
2507
2508
2509
2510
2511
2512
2513
2514
2515
2516
2517
2518
2519
2520
2521
2522
2523
2524
2525
2526
2527
2528
2529
2530
2531
2532
2533
2534
2535
2536
2537
2538
2539
2540
2541
2542
2543
2544
2545
2546
2547
2548
2549
2550
2551
2552
2553
2554
2555
2556
2557
2558
2559

```

.SBTTL GLOBAL ERROR REPORTING ROUTINE - ER1401 -
*****
* THIS IS AN ERROR REPORTING SUBROUTINE WHICH PRINTS ADDITIONAL ERROR
* INFORMATION IF AN ERROR IS DETECTED IN THE ROM VERSION TEST.
* THIS SUBROUTINE ANALYSES THE INPUT PARAMETERS WHICH CONTAIN THE
* ROM VERSION NUMBERS FOR PROC 1 AND PROC_2 AND REPORTS THE APPROPRIATE
* ERROR MESSAGE TO THE OPERATOR.
*
* INPUTS: R1 - CONTAINS THE ADDRESS OF THE FIRST MESSAGE TO BE REPORTED.
* R3 - CONTAINS THE ROM VERSION NUMBER OF PROC_1.
* R4 - CONTAINS THE ROM VERSION NUMBER OF PROC_2.
*
* OUTPUTS: BASIC AND EXTENDED ERROR MESSAGES ARE REPORTED AT THE
* OPERATORS CONSOLE.
*
* CALLING SEQUENCE: INCLUDE THE LABEL 'ER1401' AS THE MESSAGE POINTER
* PARAMETER IN THE DRS ERROR REPORT MACRO CALL.
*
* COMMENTS:
*
* SUBORDINATE ROUTINES USED: NONE.
*****

```

```

012622
012622
012622 010146
012624 012746 003030
012630 012746 000002
012634 010600
012636 104414
012640 062706 000006
012644 012705 000143
012650 012701 010637
012654 012702 010665
012660 120305
012662 001402
012664 012702 010677
012670 004737 012722
012674 012701 010652
012700 012702 010665
012704 120405
012706 001402
012710 012702 010677
012714 004737 012722
012720 000413
012722
012722 010246

```

```

BGNMSG ER1401
ER1401::
PRINTB #EF0503,R1 ;REPORT THE ERROR MESSAGE PASSED IN.
MOV R1,-(SP)
MOV #EF0503,-(SP)
MOV #2,-(SP)
MOV SP,R0
TRAP C$PNTB
ADD #6,SP

:+
: DETERMINE WHICH ROM VERSION NUMBER(S) ARE MISSING.
:-

MOV #99,R5 ;GET INVALID ROM NUMBER.
MOV #EM1405,R1 ;SELECT PROC 1 MESSAGE.
MOV #EM1407,R2 ;SELECT THE "NOT FOUND" MESSAGE.
CMPB R3,R5 ;CHECK PROC 1 ROM VERSION NUMBER.
BEQ 2$ ;GO REPORT PROC 1 CODE NOT FOUND.
MOV #EM1408,R2 ;SELECT "FOUND" MESSAGE.
JSR PC,50$ ;GO REPORT MESSAGE.

MOV #EM1406,R1 ;SELECT PROC 2 MESSAGE.
MOV #EM1407,R2 ;SELECT THE "NOT FOUND" MESSAGE.
CMPB R4,R5 ;CHECK PROC 2 ROM VERSION NUMBER.
BEQ 4$ ;GO REPORT PROC 2 CODE NOT FOUND.
MOV #EM1408,R2 ;SELECT "FOUND" MESSAGE.
JSR PC,50$ ;GO REPORT THE MESSAGE.
BR 60$ ;EXIT.

50$: PRINTX #EF1402,R1,R2 ;REPORT THE MESSAGE.
MOV R2,-(SP)

```

CV
CV

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 58
GLOBAL ERROR REPORTING ROUTINE

- ER1401 -

2560	012724	010146	
2561	012726	012746	003137
2562	012732	012746	000003
2563	012736	010600	
2564	012740	104415	
2565	012742	062706	000010
2566	012746	000207	
2567	012750		
2568	012750		
2569	012750	104423	

60\$: RTS PC
ENDMSG

;RETURN.

L10005:

MOV	R1,-(SP)
MOV	#EF1402,-(SP)
MOV	#3,-(SP)
MOV	SP,R0
TRAP	C\$PNTX
ADD	#10,SP

TRAP C\$MSG

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 59
GLOBAL ERROR REPORTING ROUTINE

- ER1601 -

2570
2571
2572
2573
2574
2575
2576
2577
2578
2579
2580
2581
2582
2583
2584
2585
2586
2587
2588
2589
2590
2591
2592
2593 012752
2594 012752
2595
2596 012752 016304 002254
2597
2598 012756
2599 012756 010546
2600 012760 010446
2601 012762 012746 003324
2602 012766 012746 000003
2603 012772 010600
2604 012774 104414
2605 012776 062706 000010
2606 013002
2607 013002 010246
2608 013004 012746 003220
2609 013010 012746 000002
2610 013014 010600
2611 013016 104415
2612 013020 062706 000006
2613 013024
2614 013024 010146
2615 013026 012746 003262
2616 013032 012746 000002
2617 013036 010600
2618 013040 104415
2619 013042 062706 000006
2620 013046
2621 013046
2622 013046 104423

```
.SBTTL GLOBAL ERROR REPORTING ROUTINE - ER1601 -
*****
* THIS AN ERROR REPORTING SUBROUTINE WHICH PRINTS ADDITIONAL ERROR
* INFORMATION IF AN ERROR IS DETECTED IN ONE OF THE DEVICE REGISTER
* ACCESS TESTS.
* THIS SUBROUTINE REPORTS THE ACTUAL AND EXPECTED FROM THE DEVICE
* REGISTER(S) WHICH IS(ARE) IN FAULTY.
*
* INPUTS: R1 - ACTUAL DATA (UNUSED BITS SET TO 0).
* R2 - EXPECTED DATA (UNUSED BITS SET TO 0).
* R3 - OFFSET (IN BYTES) TO THE REGISTER BEING TESTED.
* R5 - LINE NUMBER OF REGISTER BEING TESTED.
* RMATBB - LABEL AT BASE OF REGISTER MESSAGE ADDRESS TABLE.
*
* OUTPUTS: MESSAGES ARE PRINTED AT THE OPERATORS CONSOLE.
*
* CALLING SEQUENCE: INCLUDE THE LABEL 'ER1601' AS THE MESSAGE POINTER
* PARAMETER IN THE DRS ERROR REPORT MACRO CALL.
*
* COMMENTS:
*
* SUBORDINATE ROUTINES CALLED: NONE
*****
```

BGNMSG ER1601

ER1601::

```
MOV RMATBB(R3),R4 ;FETCH ADDRESS OF REGISTER NAME MESSAGE.
PRINTB #EF1604,R4,R5 ;REPORT BASIC MESSAGE (REG NAME AND LINE #).
MOV R5,-(SP)
MOV R4,-(SP)
MOV #EF1604,-(SP)
MOV #3,-(SP)
MOV SP,R0
TRAP C$PNTB
ADD #10,SP
PRINTX #EF1602,R2 ;PRINT THE EXPECTED DATA.
MOV R2,-(SP)
MOV #EF1602,-(SP)
MOV #2,-(SP)
MOV SP,R0
TRAP C$PNTX
ADD #6,SP
PRINTX #EF1603,R1 ;PRINT THE ACTUAL DATA.
MOV R1,-(SP)
MOV #EF1603,-(SP)
MOV #2,-(SP)
MOV SP,R0
TRAP C$PNTX
ADD #6,SP
ENDMSG
L10006: TRAP C$MSG
```

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 60
GLOBAL ERROR REPORTING ROUTINE

- ER1603 -

2623
2624
2625
2626
2627
2628
2629
2630
2631
2632
2633
2634
2635
2636
2637
2638
2639
2640
2641
2642
2643
2644 013050
2645 013050
2646 013050
2647 013050 004537 002674
2648
2649 013054
2650 013054 010146
2651 013056 012746 003030
2652 013062 012746 000002
2653 013066 010600
2654 013070 104414
2655 013072 062706 000006
2656
2657 013076 013702 002670
2658 013102
2659 013102 010246
2660 013104 012746 003174
2661 013110 012746 000002
2662 013114 010600
2663 013116 104414
2664 013120 062706 000006
2665
2666 013124
2667 013124 004736
2668 013126
2669 013126
2670 013126 104423

```

.SBTTL GLOBAL ERROR REPORTING ROUTINE - ER1603 -
*****
* THIS ERROR REPORTING ROUTINE IS USED TO PRINT OUT A BASIC ERROR
* MESSAGE, ALONG WITH A MESSAGE INFORMING THE OPERATOR WHICH TEST IS
* ABOUT TO BE ABORTED.
*
* INPUTS: R1 - CONTAINS THE ADDRESS OF THE MESSAGE TO BE PRINTED.
* ERRMSG - CONTAINS THE ADDRESS OF THE MESSAGE THAT INDICATES
* THE TEST THAT IS BEING PERFORMED, EG DMA, BREAK ETC.
*
* OUTPUTS: MESSAGES ARE PRINTED AT THE OPERATORS CONSOLE.
* "TESTNAME TEST ABORTED"
*
* CALLING SEQUENCE: INCLUDE THE LABEL 'ER1603' AS THE MESSAGE POINTER
* PARAMETER IN THE DRS ERROR REPORT MACRO CALL.
*
* COMMENTS:
*
* SUBORDINATE ROUTINES CALLED: NONE.
*****
BGNMSG ER1603
ER1603::
SAVE JSR ;SAVE THE CONTENTS OF THE GPRS.
R5,PREG05 ;CALL REGISTER SAVE SUBRT.

PRINTB #EF0503,R1 ;PRINT BASIC MESSAGE ON OPERATORS CONSOLE.
MOV R1,-(SP)
MOV #EF0503,-(SP)
MOV #2,-(SP)
MOV SP,R0
TRAP C$PNTB
ADD #6,SP

MOV ERRMSG,R2 ;GET THE "TEST MESSAGE".
PRINTB #EF1601,R2 ;PRINT "TEST ABORTED" MESSAGE.
MOV R2,-(SP)
MOV #EF1601,-(SP)
MOV #2,-(SP)
MOV SP,R0
TRAP C$PNTB
ADD #6,SP

PASS ;RESTORE THE CONTENTS OF THE GPRS.
JSR PC,@(SP)+ ;RETURN TO PREG05 SUBRT.

ENDMSG
L10007: TRAP C$MSG

```

CV
CV

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 61
GLOBAL ERROR REPORTING ROUTINE

- ER9004 -

2671
2672
2673
2674
2675
2676
2677
2678
2679
2680
2681
2682
2683
2684
2685
2686
2687
2688
2689
2690
2691
2692 013130
2693 013130
2694
2695 013130
2696 013130 012746 011423
2697 013134 012746 003030
2698 013140 012746 000002
2699 013144 010600
2700 013146 104414
2701 013150 062706 000006
2702 013154 005002
2703 013156 013703 002420
2704 013162 005004
2705 013164 000241
2706 013166 006003
2707 013170 103013
2708 013172
2709 013172 016446 002422
2710 013176 010246
2711 013200 012746 003730
2712 013204 012746 000003
2713 013210 010600
2714 013212 104415
2715 013214 062706 000010
2716 013220 012405
2717 013222 005202
2718 013224 005703
2719 013226 001356
2720
2721 013230
2722 013230
2723 013230 104423

.SBTTL GLOBAL ERROR REPORTING ROUTINE - ER9004 -

* THIS IS AN ERROR REPORTING SUBROUTINE WHICH REPORTS ERROR SUMMARIES
* FOR LINES WHICH HAVE EXCEEDED THE SPECIFIED MAXIMUM NUMBER OF
* INDIVIDUAL RECEPTION ERRORS.
*
* INPUTS: R1 - ADDRESS OF MESSAGE TO PRINT FIRST.
* ERCNTB - LABEL AT BASE OF LINE ERROR COUNTERS TABLE.
* ERSRMR - "REPORT ERROR SUMMARY FOR LINE" FLAGS.
*
* OUTPUTS: A MESSAGE IS PRINTED AT THE OPERATOR CONSOLE.
*
* CALLING SEQUENCE: INCLUDE THE LABEL 'ER9004' AS THE MESSAGE POINTER
* PARAMETER IN THE DIAG SUPER ERROR REPORT MACRO CALL.
*
* COMMENTS: THE MESSAGE IS PRINTED AS BASIC AND EXTENDED ERROR INFORMATION.
* THE CONTENTS OF GPR'S R2, R3, R4, AND R5 ARE DESTROYED.
*
* SUBORDINATE ROUTINES USED: NONE.

BGNMSG ER9004

ER9004::

PRINTB #EF0503,#EM9014 ;REPORT THE SECONDARY ERROR MESSAGE.

MOV #EM9014,-(SP)
MOV #EF0503,-(SP)
MOV #2,-(SP)
MOV SP,R0
TRAP C\$PNTB
ADD #6,SP

2\$: CLR R2 ;CLEAR THE LINE COUNTER.
MOV ERSRMR,R3 ;GET THE ERROR SUMMARY FLAGS.
CLR R4 ;CLEAR 'LINE COUNTER TIMES 2' OFFSET.
CLC ;CLEAR THE CARRY FOR THE FOLLOWING ROTATE.
ROR R3 ;SHIFT ANOTHER ERROR SUMMARY FLAG INTO CARRY.
BCC 4\$;SKIP PRINTING MESSAGE IF FLAG FOR LINE CLEAR.
PRINTX #EF9010,R2,ERCNTB(R4)

MOV ERCNTB(R4),-(SP)
MOV R2,-(SP)
MOV #EF9010,-(SP)
MOV #3,-(SP)
MOV SP,R0
TRAP C\$PNTX
ADD #10,SP

4\$: MOV (R4)+,R5 ;INCREMENT THE LINE OFFSET BY 2.
INC R2 ;INCREMT THE LINE COUNTER.
TST R3 ;CHECK THE ERROR SUMMARY FLAGS.
BNE 2\$;IF MORE FLAGS SET, LOOP TO DO OTHER LINES.

ENDMSG

L10010:

TRAP C\$MSG

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 62
GLOBAL ERROR REPORTING ROUTINE

- ER9007 -

2724
2725
2726
2727
2728
2729
2730
2731
2732
2733
2734
2735
2736
2737
2738
2739
2740
2741
2742
2743
2744
2745
2746
2747
2748
2749
2750
2751
2752
2753
2754
2755
2756
2757
2758
2759
2760
2761
2762
2763
2764
2765
2766
2767
2768

013232
013232
013232 042703 177760
013236 010346
013240 010146
013242 012746 004200
013246 012746 000003
013252 010600
013254 104414
013256 062706 000010
013262
013262 010246
013264 010146
013266 012746 004124
013272 012746 000003
013276 010600
013300 104415
013302 062706 000010
013306
013306
013306 104423

```
.SBTTL GLOBAL ERROR REPORTING ROUTINE - ER9007 -
*****
* THIS IS AN ERROR REPORTING SUBROUTINE WHICH IS USED TO REPORT THAT
* SOMETHING OTHER THAN A SELFTEST CODE WAS FOUND IN A SELFTEST CODE
* FIFO SLOT DURING THE REMOVAL OF THE SELFTEST CODES FROM THE FIFO.
* THIS ROUTINE IS USED BY THE RSTRPT ROUTINE.
*
* INPUTS: R1 - ADDRESS OF ERROR MESSAGE QUALIFIER STRING.
* R2 - INCORRECT CODE AS READ FROM THE SELFTEST CODE FIFO SLOT.
* R3 - LINE NUMBER ASSOCIATED WITH THE SELFTEST FIFO SLOT.
*
* OUTPUTS: A MESSAGE IS PRINTED AT THE OPERATOR CONSOLE.
*
* CALLING SEQUENCE: INCLUDE THE LABEL 'ER9007' AS THE MESSAGE POINTER
* PARAMETER IN THE DIAG SUPER ERROR REPORT MACRO CALL.
*
* COMMENTS: THE MESSAGE IS PRINTED AS BASIC AND EXTENDED ERROR INFORMATION.
*
* SUBORDINATE ROUTINES USED: NONE.
*****
```

BGNMSG ER9007

ER9007::

BIC #177760,R3 ;REMOVE ALL BUT LINE # BITS FROM LINE # WORD.
PRINTB #EF9018,R1,R3 ;REPORT SECONDARY ERROR MESSAGE.

MOV R3,-(SP)
MOV R1,-(SP)
MOV #EF9018,-(SP)
MOV #3,-(SP)
MOV SP,R0
TRAP C\$PNTB
ADD #10,SP

PRINTX #EF9017,R1,R2 ;REPORT THE ACTUAL INCORRECT CODE.

MOV R2,-(SP)
MOV R1,-(SP)
MOV #EF9017,-(SP)
MOV #3,-(SP)
MOV SP,R0
TRAP C\$PNTX
ADD #10,SP

ENDMSG

L10011:

TRAP C\$MSG

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 63
GLOBAL ERROR REPORTING ROUTINE

- ER9008 -

2769
2770
2771
2772
2773
2774
2775
2776
2777
2778
2779
2780
2781
2782
2783
2784
2785
2786
2787
2788 013310
2789 013310
2790
2791
2792
2793
2794
2795 013310 010203
2796 013312 000303
2797 013314 042703 177760
2798 013320
2799 013320 010346
2800 013322 010146
2801 013324 012746 004027
2802 013330 012746 000003
2803 013334 010600
2804 013336 104414
2805 013340 062706 000010
2806 013344
2807 013344 010246
2808 013346 010146
2809 013350 012746 004124
2810 013354 012746 000003
2811 013360 010600
2812 013362 104415
2813 013364 062706 000010
2814
2815 013370
2816 013370
2817 013370 104423

.SBTTL GLOBAL ERROR REPORTING ROUTINE - ER9008 -

: THIS IS AN ERROR REPORTING SUBROUTINE WHICH IS USED TO REPORT THAT
: AN UNEXPECTED CODE OR CHARACTER HAS BEEN FOUND IN THE DUT RECEIVE
: CHARACTER FIFO.
: INPUTS: R1 - ADDRESS OF PARTIAL ERROR MESSAGE STRING.
: R2 - INCORRECT CODE AS READ FROM THE SELFTEST CODE FIFO SLOT.
: OUTPUTS: A MESSAGE IS PRINTED AT THE OPERATOR CONSOLE.
: CALLING SEQUENCE: INCLUDE THE LABEL 'ER9008' AS THE MESSAGE POINTER
: PARAMETER IN THE DIAG SUPER ERROR REPORT MACRO CALL.
: COMMENTS: THE MESSAGE IS PRINTED AS BASIC AND EXTENDED ERROR INFORMATION.
: SUBORDINATE ROUTINES USED: NONE.

BGNMSG ER9008

ER9008::

:+ EXTRACT THE LINE NUMBER FROM THE INCORRECT CODE OR CHARACTER WHICH WAS READ
: FROM THE SELFTEST CODE FIFO SLOT.
:-

MOV R2,R3
SWAB R3
BIC #177760,R3 ;CALCULATE LINE NUMBER OF CODE.
PRINTB #EF9016,R1,R3 ;REPORT TYPE OF INCORRECT CODE FOUND.
MOV R3,-(SP)
MOV R1,-(SP)
MOV #EF9016,-(SP)
MOV #3,-(SP)
MOV SP,R0
TRAP C\$PNTB
ADD #10,SP
PRINTX #EF9017,R1,R2 ;REPORT THE ACTUAL INCORRECT CODE.
MOV R2,-(SP)
MOV R1,-(SP)
MOV #EF9017,-(SP)
MOV #3,-(SP)
MOV SP,R0
TRAP C\$PNTX
ADD #10,SP

ENDMSG

L10012:

TRAP C\$MSG

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 64
GLOBAL ERROR REPORTING ROUTINE

- ER9301 -

```

2818 .SBTTL GLOBAL ERROR REPORTING ROUTINE - ER9301 -
2819 *****
2820 * THIS IS AN ERROR REPORTING SUBROUTINE WHICH PRINTS ANY BMP CODES
2821 * THAT ARE FOUND IN THE BMP CODE QUEUE, TOGETHER WITH THE THE NUMBER OF
2822 * THE TEST THAT WAS EXECUTING AT THE TIME THE BMP CODE WAS LOGGED.
2823 *
2824 * INPUTS: R1 - THE ADDRESS OF THE FIRST MESSAGE TO BE REPORTED.
2825 * R2 - THE ADDRESS OF THE NEXT EMPTY CELL IN THE QUEUE.
2826 *
2827 * OUTPUTS: THE TEST NUMBER FOLLOWED BY THE BMP CODE ARE PRINTED AT THE
2828 * OPERATOR CONSOLE.
2829 *
2830 * CALLING SEQUENCE: INCLUDE THE LABEL 'ER9301' AS THE MESSAGE POINTER
2831 * PARAMETER IN THE DIAG SUPER ERROR REPORT MACRO CALL.
2832 *
2833 * COMMENTS: THE MESSAGE IS PRINTED AS BASIC ERROR INFORMATION.
2834 *
2835 * SUBORDINATE ROUTINES USED: NONE.
2836 *****
2837
2838 013372 BGNMSG ER9301
2839 013372 ER9301::
2840 013372 SAVE ;SAVE THE GPRS ON THE STACK.
2841 013372 004537 002674 JSR R5,PREG05 ;CALL REGISTER SAVE SUBRT.
2842
2843 013376 PRINTB #EF0503,R1 ;REPORT UNEXPECTED BMP CODES FOUND.
2844 013376 010146 MOV R1,-(SP)
2845 013400 012746 003030 MOV #EF0503,-(SP)
2846 013404 012746 000002 MOV #2,-(SP)
2847 013410 010600 MOV SP,R0
2848 013412 104414 TRAP C$PNTB
2849 013414 062706 000006 ADD #6,SP
2850 013420 012703 002464 MOV #BMPCQB,R3 ;GET THE START ADDRESS OF THE BMP CODE QUEUE.
2851 013424 012705 012024 MOV #EM9302,R5 ;GET THE MESSAGE TO BE REPORTED.
2852 013430 012301 2$: MOV (R3)+,R1 ;GET THE NUMBER OF THE TEST THAT WAS EXECUTING.
2853 013432 012304 MOV (R3)+,R4 ;GET BMP CODE THAT WAS REPORTED OFF THE QUEUE.
2854 013434 004737 013516 JSR PC,50$ ;GO REPORT THE BMP CODE.
2855 013440 020302 CMP R3,R2 ;CHECK IF ALL CODES HAVE BEEN REPORTED.
2856 013442 103772 BLO 2$ ;IF IT IS NOT THE LAST BMP CODE THEN LOOP.
2857
2858 ;+
2859 ; CHECK IF OVERFLOW HAS OCCURRED.
2860 ; THE CONDITIONS FOR OVERFLOW ARE: THE POINTER CONTAINS THE ADDRESS OF THE
2861 ; LAST CELL IN THE QUEUE, AND A BMP CODE HAS ALREADY BEEN WRITTEN INTO THAT
2862 ; CELL.
2863 013444 020227 002660 CMP R2,#BMPCQE-4 ;CHECK IF THE POINTER IS AT THE LAST LOCATION.
2864 013450 001036 BNE 60$ ;EXIT IF NOT AT THE LAST LOCATION.
2865 013452 005762 000002 TST 2(R2) ;CHECK FOR A BMP CODE IN THE LAST CELL
2866 013456 001433 BEQ 60$ ;EXIT IF NO OVERFLOW HAS OCCURED, CELL EMPTY.
2867 013460 012301 MOV (R3)+,R1 ;GET THE TEST NUMBER OFF THE QUEUE.
2868 013462 011304 MOV (R3),R4 ;GET THE BMP CODE OFF THE QUEUE.
2869 013464 012705 012054 MOV #EM9303,R5 ;SELECT THE MESSAGE TO BE REPORTED.
2870 013470 PRINTX #EF9302 ;REPORT OVERFLOW CONDITION.
2871 013470 012746 004407 MOV #EF9302,-(SP)
2872 013474 012746 000001 MOV #1,-(SP)
2873 013500 010600 MOV SP,R0

```


CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 65
GLOBAL ERROR REPORTING ROUTINE

- ER9301 -

2874	013502	104415						TRAP	C\$PNTX
2875	013504	062706	000004					ADD	#4,SP
2876	013510	004737	013516						
2877	013514	000414							
2878									
2879	013516			50\$:	PRINTX	#EF9301,R5,R1,R4			
2880	013516	010446						MOV	R4,-(SP)
2881	013520	010146						MOV	R1,-(SP)
2882	013522	010546						MOV	R5,-(SP)
2883	013524	012746	004331					MOV	#EF9301,-(SP)
2884	013530	012746	000004					MOV	#4,-(SP)
2885	013534	010600						MOV	SP,R0
2886	013536	104415						TRAP	C\$PNTX
2887	013540	062706	000012					ADD	#12,SP
2888	013544	000207							
2889	013546			60\$:	RTS	PC			
2890	013546	004736			PASS				
2891									
2892	013550								
2893	013550								
2894	013550	104423			ENDMSG				

;REPORT THE LAST BMP CODE PLACED ON THE QUEUE.
;EXIT.

;PRINT THE MESSAGE.

;RETURN.
;RESTORE THE GPR CONTENTS.
;RETURN TO PREG05 SUBRT.

L10013: TRAP C\$MSG

CVD
CVD

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 66
GLOBAL SUBROUTINES SECTION

.SBTTL GLOBAL SUBROUTINES SECTION

2895
2896
2897
2898
2899
2900
2901

:++
: THE GLOBAL SUBROUTINES SECTION CONTAINS THE SUBROUTINES
: THAT ARE USED IN MORE THAN ONE TEST.
:--

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 67
GLOBAL SUBROUTINE

- CALMSL -

```

2902 .SBTTL GLOBAL SUBROUTINE - CALMSL -
2903 :+ *****
2904 :+ - CALIBRATE MILLI SECOND LOOP COUNT SUBROUTINE -
2905 :+ THIS SUBROUTINE CALIBRATES THE TIMING LOOP WHICH IS USED IN THE MSLOOP
2906 :+ ROUTINE. THIS SUBROUTINE CALCULATES A VALUE FOR THE MSLCNT VARIABLE
2907 :+ WHICH IS THE NUMBER OF SOFTWARE LOOPS WHICH TAKES 1 MS TO EXECUTE IN
2908 :+ THE MSLOOP ROUTINE. THIS ROUTINE CALIBRATES THE COUNT BY USING THE
2909 :+ LINE TIME CLOCK (LTC), SO IF NO LTC IS AVAILABLE THE DEFAULT VALUE FOR
2910 :+ THE DELAY COUNT MUST BE USED.
2911 :+
2912 :+
2913 :+ INPUTS: MSLCNT - DEFAULT 1 MS DELAY LOOP COUNT VALUE, OR
2914 :+ VALUE FROM PREVIOUS CALIBRATION.
2915 :+ MSTICK - NUMBER OF MS PER LTC CLOCK TICK.
2916 :+ TIMER1 - TIMER COUNTER CHANGED BY LTC INTERRUPT SERVICE RTN.
2917 :+ CLKHRZ - NUMBER OF LTC CLICKS PER SECOND (50 OR 60).
2918 :+
2919 :+ OUTPUTS: CARRY - SET IF LTC IS AVAILABLE, AND NEW CALIBRATION PERFORMED.
2920 :+ MSLCNT - NEW 1 MS DELAY LOOP COUNT VALUE IF LTC AVAILABLE, OR
2921 :+ UNCHANGED IF NO LTC IS AVAILABLE.
2922 :+
2923 :+ CALLING SEQUENCE: JSR PC,CALMSL
2924 :+
2925 :+ COMMENTS:
2926 :+
2927 :+ SUBORDINATE ROUTINES CALLED: UNSDIV,OOPS.
2928 :+ *****
2929 :+
2930 CALMSL:: SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
2931 013552 004537 002674 JSR R5,PREG05 ;CALL REGISTER SAVE SUBRT.
2932 013556 005037 013772 CLR 62$ ;CLEAR THE 2ND TIME FLAG.
2933 :+
2934 :+ SYNCHRONIZE WITH THE LTC.
2935 :+
2936 013562 012705 000001 2$: MOV #1,R5 ;SET OUTER LOOP COUNTER TO 1 LOOP.
2937 ;INCREASE THE VALUE LOADED INTO THIS COUNTER IF THE < **
2938 ;FOLLOWING LOOP FAILS ON FUTURE, FASTER PROCESSORS. < **
2939 013566 005000 CLR R0 ;CLEAR THE WAIT FOR CLOCK INT COUNTER.
2940 013570 012737 000001 002322 MOV #1,TIMER1 ;SET UP COUNT OF 1 TO SYNCH WITH LTC.
2941 013576 005737 002322 4$: TST TIMER1 ;CHECK FOR COUNTER HAVING GONE TO ZERO.
2942 013602 001410 BEQ 6$ ;JUMP OUT OF LOOP IF LTC HAS INTERRUPTED.
2943 013604 005200 INC R0 ;COUNT THIS ITERATION OF THE INNER LOOP.
2944 013606 001373 BNE 4$ ;LOOP IF COUNTER HAS NOT TURNED OVER.
2945 013610 005305 DEC R5 ;DECREMENT THE INNER LOOP COUNTER.
2946 013612 003371 BGT 4$ ;LOOP IF OUTER LOOP COUNT NOT UP.
2947 :+
2948 :+ IF WE GOT NO LTC INTERRUPT, INDICATE THAT THERE IS NO LTC AVAILABLE.
2949 :+ LTC MUST BE FLAKEY, OR NOT REALLY AN LTC AT ALL.
2950 :+
2951 013614 005037 002320 CLR CLKHRZ ;CLEAR LTC FREQUENCY WORD TO INDICATE NO LTC.
2952 013620 000241 CLC ;INDICATE FAILURE FOR RETURN.
2953 013622 000461 BR 60$ ;BYPASS THE FOLLOWING CALIBRATION PROCEDURES.
2954 :+
2955 :+ WE ARE NOW SYNCHRONIZED WITH THE LTC.
2956 :+ SET UP FOR THE CALIBRATION LOOP.
2957 :+

```

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 68
GLOBAL SUBROUTINE

- CALMSL -

```

2958 013624 012704 002322      6$:  MOV    #TIMER1,R4      ;WILL TEST TIMER1 IN THE LOOP BELOW.
2959 013630 005001              CLR    R1                ;CLEAR THE OUTER LOOP COUNTER.
2960 013632 005002              CLR    R2                ;INDICATE TO CHECK ALL BITS OF TIMER1.
2961 013634 005003              CLR    R3                ;INDICATE TO CHECK FOR TIMER1 CLEAR.
2962 013636 012714 000001      MOV    #1,(R4)           ;LOAD TIMER1 WITH COUNT OF 1.
2963
2964 013642 013705 002334      8$:  MOV    MSLCNT,R5        ;LOAD MS LOOP COUNT.
2965 013646 011400      10$: MOV    (R4),R0          ;GET THE TIMER1 VALUE.
2966 013650 010037 013774      MOV    R0,64$           ;SAVE WORD (LIKE IN THE REAL LOOP).
2967 013654 040200              BIC    R2,R0             ;LEAVE ALL THE BITS.
2968 013656 020003              CMP    R0,R3             ;COMPARE AGAINST ZERO.
2969 013660 000261              SEC                      ;SET CARRY IN CASE OF SUCCESS.
2970 013662 001406              BEQ    12$               ;EXIT LOOP IF TIMER1 HAS CLEARED.
2971 013664 005305              DEC    R5                ;COUNT DOWN THE INSIDE MS LOOP COUNT.
2972 013666 001367              BNE    10$               ;LOOP IF MS NOT UP.
2973 013670 005301              DEC    R1                ;DECREMENT THE MS TIME COUNT.
2974 013672 001363              BNE    8$                ;KEEP LOOPING.
2975 013674 004737 014316      JSR    PC,OOPS           ;WE OVERFLOWED, SOMETHING IS WRONG, ABORT.
2976
2977      ;+
2978      ; WE HAVE NOW HAVE LOOP COUNT INFORMATION FOR ONE CLOCK TICK.
2979      ; WE HAVE NEGATIVE OF NUMBER OF OUTER LOOPS IN R1, EACH IS MSLCNT INNER LOOPS.
2980      ; WE HAVE THE PORTION OF THE LAST OUTER LOOP NOT EXECUTED, IN R5.
2981      ; NOW WE CALCULATE THE TOTAL NUMBER OF INNER LOOPS EXECUTED.
2982      ;-
2982 013700 005401      12$: NEG    R1                ;GET NUMBER OF OUTER LOOPS.
2983 013702 013702 002334      MOV    MSLCNT,R2        ;GET THE NUMBER OF INNER LOOPS PER OUTER LOOP.
2984 013706 010203              MOV    R2,R3             ;COPY NUMBER OF LOOPS FOR MULTIPLY.
2985 013710 160502              SUB    R5,R2             ;CALC # OF INNER LOOPS DONE IN LAST OUTER LOOP
2986 013712 010204              MOV    R2,R4             ; AND ADD TO ACCUMULATOR LSWORD.
2987 013714 005005              CLR    R5                ;CLEAR ACCUMULATOR MSWORD.
2988 013716 005301      14$: DEC    R1                ;CHECK R1 FOR 0 CONDITION
2989 013720 100403              BMI    16$               ; SKIP MULTIPLICATION IF ZERO
2990 013722 060304              ADD    R3,R4             ;MULTIPLY NUMBER OF INNER
2991 013724 005505              ADC    R5                ; LOOPS PER OUTER LOOP BY
2992 013726 000773              BR     14$               ;NUMBER OF OUTER LOOPS PERFORMED.
2993
2994      ;+
2995      ; DIVIDE THE TOTAL NUMBER OF INNER LOOPS BY THE NUMBER OF MS PER LTC TICK.
2996      ;-
2996 013730 013701 002332      16$: MOV    MSTICK,R1        ;# OF MS PER LTC TICK IS DIVISOR.
2997 013734 010403              MOV    R4,R3             ;LSWORD OF LOOP COUNT IS LSWORD OF DIVIDEND.
2998 013736 010502              MOV    R5,R2             ;MSWORD OF LOOP COUNT IS MSWORD OF DIVIDEND.
2999 013740 004737 016340      JSR    PC,UNSDIV        ;DIVIDE NUMBER OF LOOPS BY MS PER LTC TICK.
3000 013744 103402              BCS    18$               ;BYPASS OOPS IF WE'RE OK.
3001 013746 004737 014316      JSR    PC,OOPS           ;CLOCK ROUTINES ARE NOT LONG ENOUGH, OR BUG.
3002 013752 010137 002334      18$: MOV    R1,MSLCNT        ;SET NEW VALUE FOR MS LOOP COUNT.
3003 013756 005137 013772      COM    62$               ;SET THE 2ND ITERATION FLAGS IF 1ST ITERATION.
3004 013762 001277              BNE    2$                ;BRANCH IF ONLY ONE ITERATION DONE.
3005 013764 000261              SEC                      ;SET THE SUCCESS FLAG FOR EXIT.
3006
3007 013766      60$: PASS                ;RESTORE GPRS,
3008 013766 004736              PC,@(SP)+                ;RETURN TO PREG05 SUBRT.
3009 013770 000207              RTS    PC                ; CARRY - SUCCESS FLAG. SET IF SUCCESS.
3010
3011 013772 000000      62$: .WORD 0                ;2ND CALIBRATION ITERATION FLAGS.
3012 013774 000000      64$: .WORD 0                ;DUMMY WORD FOR STORAGE OF THE READ WORD.

```

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 69
GLOBAL SUBROUTINE - CKTRAP -

3013
3014
3015
3016
3017
3018
3019
3020
3021
3022
3023
3024
3025
3026
3027
3028
3029
3030
3031
3032
3033
3034
3035
3036
3037
3038
3039
3040
3041
3042
3043
3044
3045
3046

013776
013776 004537 002674
014002 005037 002304
014006 011011
014010 005737 002304
014014 000261
014016 001401
014020 000241
014022
014022 004736
014024 000207

```
.SBTTL GLOBAL SUBROUTINE - CKTRAP -
*****
* CHECK TRAP ROUTINE -
* THIS SUBROUTINE IS USED TO CHECK FOR A BUS TIME-OUT TRAP (004 TRAP)
* WHICH IS CAUSED BY AN ACCESS TO A NON-EXISTENT MEMORY OR I/O LOCATION.
* IF THE TRAP DOES NOT OCCUR, THIS ROUTINE RETURNS A SUCCESS INDICATION.
*
* INPUTS: R0 - SOURCE ADDRESS FOR MOVE.
* R1 - DESTINATION ADDRESS FOR MOVE.
* (R0) - SOURCE FOR THE MOVE.
*
* OUTPUTS: (R1) - WRITTEN TO THE CONTENTS OF (R0).
* CARRY FLAG - SET ON RETURN IF NO 004 TRAP DETECTED.
* TP4FLG - NONZERO IF TRAP OCCURRED, CLEARED OTHERWISE.
*
* CALLING SEQUENCE: JSR PC,CKTRAP
*
* COMMENTS: IF THIS SUBROUTINE CAUSES A TRAP, EITHER THE ADDRESS WHICH
* IS LABELED ADRPTR WILL BE THE TRAP PC ADDRESS ON THE STACK.
*
* SUBORDINATE ROUTINES CALLED: NONE.
*****
```

```
CKTRAP:: SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
;R5,PREG05 ;CALL REGISTER SAVE SUBRT.
CLR TP4FLG JSR ;CLEAR THE 004 TRAP FLAGS.
MOV (R0),(R1) ;PERFORM THE MOVE IN QUESTION.
ADRPTR:: TST TP4FLG ;CHECK FOR OCCURENCE OF TRAP.
SEC ;INDICATE SUCCESS.
BEQ 60$ ;EXIT WITH SUCCESS IF TRAP DID NOT OCCUR.
CLC ;INDICATE FAILURE.
60$: PASS ;RESTORE GPRS.
;RTS PC JSR PC,@(SP)+ ;RETURN TO PREG05 SUBRT.
```

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 70
GLOBAL SUBROUTINE - CLR16W -

3047
3048
3049
3050
3051
3052
3053
3054
3055
3056
3057
3058
3059
3060
3061
3062
3063
3064
3065
3066
3067
3068
3069
3070
3071

014026
014026 004537 002674
014032 012701 000020
014036 005020
014040 005301
014042 001375
014044
014044 004736
014046 000207

```

.SBTTL GLOBAL SUBROUTINE - CLR16W -
:++ *****
: * - CLEAR SIXTEEN WORDS ROUTINE -
: * THIS SUBROUTINE CLEARS 16 WORDS STARTING WITH THE SPECIFIED WORD.
: *
: * INPUTS: R0 - ADDRESS OF THE FIRST WORD TO CLEAR.
: *
: * OUTPUTS: (R0) TO (R0+15) - 16 WORDS OF MEMORY ARE CLEARED TO 0.
: *
: * CALLING SEQUENCE: JSR PC,CLR16W
: *
: * COMMENTS:
: *
: * SUBORDINATE ROUTINES CALLED: NONE.
:-- *****

CLR16W:: SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
                JSR R5,PREG05 ;CALL REGISTER SAVE SUBRT.
                ;SET THE LOOP COUNTER TO 16.
2$: MOV #16,R1 ;CLEAR A WORD OF MEMORY.
    CLR (R0)+ ;COUNT THIS LOOP.
    DEC R1 ;LOOP IF NOT 16 WORD CLEARED.
    BNE 2$ ;RESTORE GPRS.
60$: PASS
                JSR PC,@(SP)+ ;RETURN TO PREG05 SUBRT.
                RTS PC

```

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 71
GLOBAL SUBROUTINE - CNTERR -

```

3072 .SBTTL GLOBAL SUBROUTINE - CNTERR -
3073 :++ *****
3074 :* - COUNT ERROR ROUTINE -
3075 :* THIS SUBROUTINE IS USED TO COUNT A 'DATA' ERROR ON THE SPECIFIED
3076 :* LINE. IT CHECKS WHETHER ERROR SUMMARY REPORTING IS ACTIVE, OR SHOULD
3077 :* BE MADE ACTIVE ON THIS LINE, AND ACTIVATES IT IF NECESSARY.
3078 :*
3079 :* INPUTS: R5 - LINE NUMBER OF LINE UNDER CONSIDERATION.
3080 :* ERCNTB - LABEL AT BASE OF ERROR COUNTERS TABLE.
3081 :* ERSMRF - ERROR SUMMARY FLAGS (BIT SET IF LINE IN SUMMARY MODE).
3082 :* NDERPT - NUMBER OF INDIVIDUAL DATA ERRORS TO REPORT ON A LINE.
3083 :*
3084 :* OUTPUTS: CARRY - SET IF LINE IS IN ERROR SUMMARY MODE.
3085 :* ERCNT - ERROR COUNTER INCREMENTED FOR SPECIFIED LINE.
3086 :* ERSMRF - BIT SET IF LINE SHOULD BE IN SUMMARY MODE.
3087 :*
3088 :* CALLING SEQUENCE: JSR PC,CNTERR
3089 :*
3090 :* COMMENTS:
3091 :*
3092 :* SUBORDINATE ROUTINES CALLED: NONE.
3093 :-- *****
3094
3095 014050 CNTERR:: SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
3096 014050 004537 002674 JSR R5,PREG05 ;CALL REGISTER SAVE SUBRT.
3097
3098 :+ COUNT THE ERROR ON THE COUNTER FOR THE SPECIFIED LINE.
3099 :-
3100 014054 006305 ASL R5 ;FORM WORD OFFSET FROM LINE NUMBER.
3101 014056 016501 002422 MOV ERCNTB(R5),R1 ;GET THE PRESENT ERROR COUNT FOR THIS LINE.
3102 014062 005201 INC R1 ;COUNT ERROR.
3103 014064 103402 BCS 2$ ;OVERFLOW? YES, DON'T UPDATE COUNTER IN TABLE.
3104 014066 010165 002422 MOV R1,ERCNTB(R5) ;UPDATE ERROR COUNTER TABLE ENTRY.
3105 014072 005737 002206 2$: TST NDERPT
3106 014076 001411 BEQ 60$ ;SUMMARYS DISABLED? YES, EXIT WITH CARRY 0.
3107 014100 020137 002206 CMP R1,NDERPT ;NO, CHECK FOR ENOUGH ERRORS FOR SUMMARY USE.
3108 014104 101002 BHI 4$ ;ENOUGH ERRORS TO USE SUMMARY? YES, GO HANDLE.
3109 014106 000241 CLC ;INDICATE NOT TO USE SUMMARY REPORT YET.
3110 014110 000404 BR 60$ ;EXIT WITH CARRY 0.
3111 014112 056537 002346 002420 4$: BIS BITTBL(R5),ERSMRF ;SET THE ERROR SUMMARY FLAG FOR LINE.
3112 014120 000261 SEC ;INDICATE TO USE SUMMARY REPORT.
3113 014122 60$: PASS ;RESTORE GPRS.
3114 014122 004736 JSR PC,@(SP)+ ;RETURN TO PREG05 SUBRT.
3115 014124 000207 RTS PC

```

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 72
GLOBAL SUBROUTINE - DELAY -

3116
3117
3118
3119
3120
3121
3122
3123
3124
3125
3126
3127
3128
3129
3130
3131
3132
3133
3134
3135
3136
3137
3138
3139
3140
3141
3142
3143
3144
3145
3146
3147

014126
014126 004537 002674
014132 010401
014134 012702 177777
014140 005003
014142 012704 014164
014146 004737 014302
014152 103002
014154 004737 014316
014160
014160 004736
014162 000207
014164 177777

```

.SBTTL GLOBAL SUBROUTINE - DELAY -
*****
*          - DELAY SUBROUTINE -
*          THIS SUBROUTINE IS USED TO DELAY A VARIABLE NUMBER OF MILLI-SECONDS.
*
* INPUTS:   R4 - CONTAINS THE NUMBER OF MS TO DELAY.
*           MSLCNT.
*
* OUTPUTS:  NONE.
*
* CALLING SEQUENCE:  JSR   PC,DELAY
*
* COMMENTS:  IF NO HARDWARE CLOCK INTERRUPTS ARE OCCURING, CONTROL-CS WILL
*            NOT BE HONORED FOR THE DURATION OF THE DELAY.
*
* SUBORDINATE ROUTINES CALLED: NONE.
*****
DELAY:: SAVE
                JSR   R5,PREG05 ;SAVE CONTENTS OF GPRS R0 THRU R5.
                MOV   R4,R1     ;CALL REGISTER SAVE SUBRT.
                MOV   #-1,R2    ;PASS NUMBER OF MS DELAY AS TIME-OUT VALUE.
                CLR   R3        ;TELL MSLOOP ROUTINE TO CHECK ALL BITS.
                MOV   #62$,R4   ;TELL MSLOOP RTN TO CHECK FOR ALL BITS CLEAR.
                JSR   PC,MSLOOP ;TELL MSLOOP TO CHECK DUMMY NON-ZERO WORD.
                BCC   60$       ;DELAY THE REQUESTED # OF MS.
                JSR   PC,OOPS    ;EXIT ROUTINE IF WE TIMED-OUT.]
                JSR   PC,00PS    ;IF NO TIME-OUT, BAD PROGRAM OR HOST MACHINE.
60$: PASS
                JSR   PC,@(SP)+ ;RESTORE GPRS.
                                ;RETURN TO PREG05 SUBRT.
                RTS   PC
62$: .WORD -1 ;DUMMY, NON-ZERO WORD.

```


CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 73
GLOBAL SUBROUTINE

- MSLGET -

3148
3149
3150
3151
3152
3153
3154
3155
3156
3157
3158
3159
3160
3161
3162
3163
3164
3165
3166
3167
3168
3169
3170
3171
3172
3173
3174
3175
3176
3177
3178
3179
3180
3181
3182
3183
3184
3185
3186
3187
3188
3189
3190
3191
3192
3193
3194
3195
3196
3197
3198
3199
3200
3201
3202
3203

```

.SBTTL GLOBAL SUBROUTINE - MSLGET -
*****
- MILLI SECONDS LOOP WHICH RETURNS READ WORD AND REMAINING TIME -
THIS SUBROUTINE IS A GENERAL PURPOSE TEST LOOP SUBROUTINE. IT IS USED
TO VERIFY THAT A CERTAIN ACTION OCCURS BEFORE A TIME-OUT PERIOD. THE
CALLING ROUTINE PASSES IN WHICH BITS SHOULD BE SET AND CLEARED FOR THE
DESIRED CONDITION AND THE TIME-OUT VALUE IN MILLI-SECONDS.
THIS ROUTINE CHECKS FOR THE DESIRED CONDITION UPON ENTRANCE INTO THE
ROUTINE AND THEN ONCE EACH MILLI-SECOND THERE AFTER.
UPON RETURN, THE LAST WORD WHICH WAS READ TO CHECK FOR THE CONDITION
IS RETURNED BY THIS SUBROUTINE.

* INPUTS: R1 - TIME-OUT VALUE IN MILLI-SECONDS (UP TO 64K MS).
          R2 - BIT MAP OF BITS TO TEST (1 INDICATES TO TEST THE BIT).
          R3 - DESIRED STATES OF THE INDICATED FIELDS IN R2.
          R4 - ADDRESS OF THE WORD TO TEST.
          MSLCNT - MILLI SECOND SOFTWARE LOOP COUNT.

* OUTPUTS: R0 - THE LAST WORD WHICH WAS READ TO CHECK FOR THE CONDITION.
           R1 - REMAINING NUMBER OF MS IN TIME-OUT TIME.
           CARRY - SUCCESS FLAG (SET IF CONDITION IS MET BEFORE TIME-OUT).

* CALLING SEQUENCE: JSR PC,MSLGET

* COMMENTS: THIS ROUTINE WORKS WITH OR WITHOUT A HARDWARE CLOCK, BUT THE
            CALIBRATION IS ONLY GUARENTEED WHEN A LINE CLOCK IS AVAILABLE
            ON THE SYSTEM.
            THIS ROUTINE CAN BE USED AS A DELAY ROUTINE, BY SPECIFYING THE
            DESIRED DELAY AS THE TIME-OUT AND SPECIFYING A CONDITION TO
            LOOK FOR WHICH WILL NOT BE MET DURING THE DELAY.
            IF A TIME-OUT VALUE OF 0 IS SPECIFIED, THIS ROUTINE CHECKS FOR
            THE DESIRED CONDITION BEFORE RETURNING. IT INDICATES SUCCESS
            IF THE CONDITION IS MET, FAILURE OTHERWISE.

* SUBORDINATE ROUTINES CALLED: NONE.
*****
MSLGET:: SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
          JSR R5,PREG05 ;CALL REGISTER SAVE SUBRT.

;+
; SET UP MASK FOR REMOVING UNUSED BITS IN THE TEST WORD, AND CLEAR UNUSED
; BITS IN THE DESIRED STATE WORD TO ALLOW DIRECT COMPARISON.
;-
          COM R2 ;GET MASK OF UNUSED BITS.
          BIC R2,R3 ;MASK OUT UNUSED BITS IN DESIRED STATE WORD.

;+
; HANDLE THE TEST AND EXIT IF WE HAVE A 0 TIME-OUT VALUE.
;-
          TST R1 ;TEST THE TIME-OUT VALUE FOR ZERO.
          BNE 2$ ;IF NON-ZERO TIME-OUT, GO LOOP AND TEST.
          MOV (R4),R0 ;GET THE WORD TO TEST BEFORE EXITING.
          MOV R0,62$ ;SAVE VALUE SO WE CAN RETURN IT.
          BIC R2,R0 ;MASK OUT UNTESTED BITS OF WORD.
          CMP R0,R3 ;COMPARE AGAINST DESIRED STATE WORD.
          SEC ;INDICATE SUCCESS IN CASE WORDS ARE EQUAL.

```

014166 004537 002674
014172 005102
014174 040203
014176 005701
014200 001011
014202 011400
014204 010037 014300
014210 040200
014212 020003
014214 000261

CVE
CVE

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 74

GLOBAL SUBROUTINE

- MSLGET -

```

3204 014216 001420          BEQ      6$          ;EXIT WITH SUCCESS IF WORDS ARE EQUAL.
3205 014220 000241          CLC          ;INDICATE FAILURE (TIME-OUT).
3206 014222 000416          BR       6$          ;EXIT WITH FAILURE, WORDS AREN'T EQUAL.
3207
3208      ;+
3209      ; NON-ZERO TIME-OUT VALUE. LOOP, WAITING FOR CONDITION OR TIME-OUT.
3210 014224 013705 002334 2$:   MOV      MSLCNT,R5      ;LOAD MS LOOP COUNT.
3211 014230 011400          4$:   MOV      (R4),R0      ;GET THE WORD TO TEST.
3212 014232 010037 014300      MOV      R0,62$        ;SAVE WORD IN CASE THIS IS THE LAST.
3213 014236 040200          BIC      R2,R0          ;MASK OUT UNTESTED BITS OF WORD.
3214 014240 020003          CMP      R0,R3          ;COMPARE AGAINST DESIRED STATE WORD.
3215 014242 000261          SEC          ;SET CARRY IN CASE OF SUCCESS.
3216 014244 001405          BEQ      6$          ;EXIT WITH SUCCESS IF WORDS ARE EQUAL.
3217 014246 005305          DEC      R5            ;COUNT DOWN THE INSIDE MS LOOP COUNT.
3218 014250 001367          BNE      4$            ;LOOP IF MS NOT UP.
3219 014252 005301          DEC      R1            ;DECREMENT THE MS TIME COUNT.
3220 014254 001363          BNE      2$            ;IF TIME NOT UP, LOOP TO COUNT ANOTHER MS.
3221 014256 000241          CLC          ;CLEAR CARRY, WE TIMED-OUT.
3222
3223      ;+
3224      ; HAVE EITHER FOUND CONDITION, OR TIMED-OUT (POSSIBLY FROM 0 TIME-OUT VALUE).
3225      ; RESTORE THE LAST CONTENTS READ FROM THE TEST WORD. EXIT ROUTINE.
3226 014260 013700 014300 6$:   MOV      62$,R0        ;PASS OUT THE LAST READ WORD.
3227 014264          60$:  PASS      R0,R1      ;RESTORE GPRS, EXCEPT THE FOLLOWING:
3228 014264 010066 000002          MOV      R0,R0SLOT(SP) ;PUT R0 IN STACK SLOT.
3229 014270 010166 000004          MOV      R1,R1SLOT(SP) ;PUT R1 IN STACK SLOT.
3230 014274 004736          JSR      PC,@(SP)+     ;RETURN TO PREG05 SUBRT.
3231          ;R0 - LAST READ WORD CHECKED FOR CONDITION.
3232          ;R1 - REMAINING TIME (0 IF TIME-OUT OCCURED).
3233 014276 000207          RTS      PC          ;CARRY - SET IF SUCCESS, CLEAR IF TIME-OUT.
3234
3235      ;+
3236      ; LOCAL STORAGE.
3237 014300 000000 62$:  .WORD  0          ;STORAGE FOR THE LAST READ WORD.

```

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 75
GLOBAL SUBROUTINE

- MSLOOP -

```

3238 .SBTTL GLOBAL SUBROUTINE - MSLOOP -
3239 *****
3240 * - TEST LOOP SUBROUTINE -
3241 * THIS SUBROUTINE IS A GENERAL PURPOSE TEST LOOP SUBROUTINE. IT IS USED
3242 * TO VERIFY THAT A CERTAIN ACTION OCCURS BEFORE A TIME-OUT PERIOD. THE
3243 * CALLING ROUTINE PASSES IN WHICH BITS SHOULD BE SET AND CLEARED FOR THE
3244 * DESIRED CONDITION AND THE TIME-OUT VALUE IN MILLI-SECONDS.
3245 * THIS ROUTINE CHECKS FOR THE DESIRED CONDITION UPON ENTRANCE INTO THE
3246 * ROUTINE AND THEN ONCE EACH MILLI-SECOND THEREAFTER.
3247 *
3248 * INPUTS: R1 - TIME-OUT VALUE IN MILLI-SECONDS (UP TO 64K MS).
3249 * R2 - BIT MAP OF BITS TO TEST (1 INDICATES TO TEST THE BIT).
3250 * R3 - DESIRED STATES OF THE INDICATED FIELDS IN R2.
3251 * R4 - ADDRESS OF THE WORD TO TEST.
3252 * MSLCNT - MILLI SECOND SOFTWARE LOOP COUNT.
3253 *
3254 * OUTPUTS: CARRY - SUCCESS FLAG (SET IF CONDITION IS MET BEFORE TIME-OUT).
3255 *
3256 * CALLING SEQUENCE: JSR PC,MSLOOP
3257 *
3258 * COMMENTS: THIS ROUTINE WORKS WITH OR WITHOUT A HARDWARE CLOCK, BUT THE
3259 * CALIBRATION IS ONLY GUARENTEED WHEN A LINE CLOCK IS AVAILABLE
3260 * ON THE SYSTEM.
3261 * THIS ROUTINE CAN BE USED AS A DELAY ROUTINE, BY SPECIFYING THE
3262 * DESIRED DELAY AS THE TIME-OUT AND SPECIFYING A CONDITION TO
3263 * LOOK FOR WHICH WILL NOT BE MET DURING THE DELAY.
3264 * IF A TIME-OUT VALUE OF 0 IS SPECIFIED, THIS ROUTINE CHECKS FOR
3265 * THE DESIRED CONDITION BEFORE RETURNING. IT INDICATES SUCCESS
3266 * IF THE CONDITION IS MET, FAILURE OTHERWISE.
3267 *
3268 * SUBORDINATE ROUTINES CALLED: MSLGET.
3269 *****
3270
3271 014302 MSLOOP:: SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
3272 014302 004537 002674 JSR R5,PREG05 ;CALL REGISTER SAVE SUBRT.
3273
3274 ;+
3275 ; CALLING THE MSLGET ROUTINE FROM THE MSLOOP ROUTINE ISOLATES THE CALLER OF
3276 ; MSLOOP FROM THE RETURNED TEST WORD AND REMAINING TIME-OUT VALUES.
3277 ;-
3278 014306 004737 014166 JSR PC,MSLGET ;CALL THE MULTI-PURPOSE MS LOOP AND SEARCH RTN.
3279
3280 014312 60$: PASS ;RESTORE GPRS,
3281 014312 004736 JSR PC,@(SP)+ ;RETURN TO PREG05 SUBRT.
3282 014314 000207 RTS PC ;CARRY - SET IF SUCCESS, CLEAR IF TIME-OUT.

```

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 76
GLOBAL SUBROUTINE - OOPS -

```

3283
3284
3285
3286
3287
3288
3289
3290
3291
3292
3293
3294
3295
3296
3297
3298
3299
3300
3301
3302 014316
3303 014316 004537 002674
3304
3305 014322
3306 014322 104454
3307 014324 000145
3308 014326 014362
3309 014330 000000
3310
3311 014332
3312 014332 012746 014446
3313 014336 012746 000001
3314 014342 010600
3315 014344 104417
3316 014346 062706 000004
3317 014352
3318 014352 104422
3319 014354 000776
3320 014356
3321 014356 004736
3322 014360 000207
3323
3324 014362 047510 052123 041440
3325 014370 046517 052520 042524
3326 014376 020122 040510 042122
3327 014404 040527 042522 047440
3328 014412 020122 047523 052106
3329 014420 040527 042522 041040
3330 014426 043525 042440 041516
3331 014434 052517 052116 051105
3332 014442 042105 000056
3333 014446 047045 040445 051120
3334 014454 043517 040522 020115
3335 014462 052510 043516 020054
3336 014470 040527 052111 047111
3337 014476 020107 047506 020122
3338 014504 020101 047503 052116

```

```

.SBTTL GLOBAL SUBROUTINE - OOPS -
*****
- PROGRAM ABORT SUBROUTINE -
THIS SUBROUTINE IS USED TO ABORT THE PROGRAM WHEN A FATAL ERROR IS
DETECTED IN THE PROGRAM OR THE HOST SYSTEM HARDWARE. AN ERROR MESSAGE
IS PRINTED GIVING SOME INFORMATION ABOUT THE NATURE OF THE ABORT.
*
* INPUTS: R1 - ERROR CODE GIVING REASON FOR ABORT.
*
* OUTPUTS: AN ERROR MESSAGE IS PRINTED.
A LIST OF RETURN PC VALUES FOR ALL SUBROUTINE CALLS IS PRINTED.
*
* CALLING SEQUENCE: JSR PC,OOPS
*
* COMMENTS:
*
* SUBORDINATE ROUTINES CALLED: NONE.
*****
OOPS:: SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
; R5,PREG05 ;CALL REGISTER SAVE SUBRT.
; REPORT 'HOST COMPUTER HARDWARE OR SOFTWARE BUG ENCOUNTERED.' ERROR.
ERRSF 101,EM0101
TRAP C$ERSF
.WORD 101
.WORD EM0101
.WORD 0
; REPORT 'PROGRAM HUNG, WAITING FOR A CONTROL-C.'
PRINTF #EM0102
MOV #EM0102,-(SP)
MOV #1,-(SP)
MOV SP,R0
TRAP C$PNTF
ADD #4,SP
2$: BREAK ;LOOK FOR OPERATOR CONTROL-C INPUT.
TRAP C$BRK
60$: BR 2$ ;INFINITE LOOP.
PASS ;DON'T NEED THIS, BUT SOMEBODY MAY CHANGE THIS
JSR PC,@(SP)+ ;RETURN TO PREG05 SUBRT.
RTS PC ; ROUTINE IN THE FUTURE, SO BE CONSISTANT.
EM0101:: .ASCIZ /HOST COMPUTER HARDWARE OR SOFTWARE BUG ENCOUNTERED./
EM0102:: .ASCIZ /%N%PROGRAM HUNG, WAITING FOR A CONTROL-C. <*****%N%N/

```

CVD
CVD

.....

CVDHAAO DHV-11 FUNC TST PART1 MACY11 30A(1052) 12-JUL-83 10:52 PAGE 77
CVDHAA.P11 12-JUL-83 00:42 GLOBAL SUBROUTINE - OOPS -

3339	014512	047522	026514	027103
3340	014520	036040	025052	025052
3341	014526	025052	025052	025052
3342	014534	025052	022452	022516
3343	014542	000116		
3344				

.EVEN

CVD
CVD

.....

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 79
GLOBAL SUBROUTINE - RDPDR -

3396
3397
3398
3399
3400
3401
3402
3403
3404
3405
3406
3407
3408
3409
3410
3411
3412
3413
3414
3415
3416
3417
3418
3419
3420
3421
3422
3423
3424
3425
3426
3427
3428
3429
3430
3431
3432
3433
3434
3435
3436
3437
3438
3439
3440
3441
3442
3443
3444
3445
3446
3447
3448
3449
3450
3451

```

.SBTTL GLOBAL SUBROUTINE - RDPDR -
*****
- READ AND VERIFY DATA PATTERN FROM DEVICE REGISTERS ROUTINE -
THIS ROUTINE READS AND VERIFIES THE ROTATED DATA PATTERN WHICH HAS
BEEN WRITTEN BY THE WDPDR SUBROUTINE.
EACH ACTIVE LINE'S REGISTER'S CONTENTS IS READ AND COMPARED WITH THE
WRITTEN DATA.
AFTER THE UNUSED AND READ ONLY (RO) BITS ARE MASKED OUT, ANY ERRORS ARE
REPORTED FROM THIS ROUTINE.
THIS ROUTINE WILL TAKE INTO ACCOUNT THE TYPE OF WRITE OPERATION WHICH
WAS PERFORMED BY THE WDPDR SUBROUTINE.

INPUTS: R2 - USED TO PASS IN THE DATA PATTERN TO BE ROTATED & VERIFIED.
R3 - BYTE INDICATOR (- => LO BYTE, + => HI BYTE, 0 => BOTH).
R4 - OPERATION TYPE INDICATOR (- => BIC, + => BIS, 0 => MOV).
ACTLNS - BIT MAP OF ACTIVE LINES ON THE DEVICE UNDER TEST.
CSRA - CONTAINS THE CSR ADDRESS OF THE DEVICE UNDER TEST.
DRADRT - BASE ADDRESS OF DEVICE REGISTER ADDRESS TABLE.
ERCNTB - LABEL AT BASE OF ERROR COUNTERS TABLE FOR LINES.
ERRMSG - SET UP WITH THE PROPER ERROR MESSAGE FOR THIS TEST.
ERRNBR - SET UP WITH THE PROPER ERROR NUMBER.
LPRO - EQUATED TO LPR REG OFFSET FROM DEVICE CSR ADDRESS.
NUMLNS - NUMBER OF LINES ON THE DEVICE UNDER TEST.
NDERPT - NUMBER OF INDIVIDUAL DATA ERRORS TO REPORT ON A LINE.
TXBFCO - EQUATED TO TBUFFCT REG OFFSET FROM DEVICE CSR ADDRESS.
UNBTB - BASE ADDRESS OF THE UNUSED BIT TABLE.

OUTPUTS: ERROR MESSAGES MAY BE PRINTED AT THE OPERATOR'S CONSOLE.
ERCNT - ERROR COUNTERS TABLE IS UPDATED FOR LINE UNDER TEST.
ERRBLK - CONTENTS DESTROYED.
ERSMRF - ERROR SUMMARY FLAGS BIT SET IF LINE IN SUMMARY MODE.
UUT CSR - ALL BITS CLEARED, EXCEPT IND.ADR.REG FIELD DESTROYED.

CALLING SEQUENCE: JSR PC,RDPDR

COMMENTS: FOR BYTE ACCESSES, ONLY THE SPECIFIED BYTE IS VERIFIED.

SUBORDINATE ROUTINES CALLED: ER1601,ROLDAP.
*****
RDPDR:: SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
;R5, PREGOS ;CALL REGISTER SAVE SUBRT.
MOV #ER1601,ERRBLK ;SET UP THE ADDRESS OF THE ERROR REPORT RTN.

;+ DETERMINE WHETHER REGISTER DATA SHOULD BE INVERTED FROM DATA PATTERN.
;-
TST R4 ;CHECK THE OPERAND TYPE INDICATOR.
BPL 2$ ;BIC WRITE PERFORMED? NO, USE STANDARD DATA.
COM R2 ;YES, INVERT THE DATA PATTERN.

;+ SET UP OUTER LOOP.
;-
2$: CLR R5 ;CLEAR LINE COUNTER TO SELECT LINE 0.

;+ THE OUTER LOOP FOLLOWS. EACH PASS THROUGH THIS LOOP READS AND COMPARES DATA
; FROM ALL OF THE DEVICE REGISTERS FOR A PARTICULAR LINE IF THE LINE IS ACTIVE.

```

```

014626
014626 004537 002674
014632 012737 012752 002672
014640 005704
014642 100001
014644 005102
014646 005005

```

CVD
CVD

.....

CVDHAAO DHV-11 FUNC TST PART1 MACY11 30A(1052) 12-JUL-83 10:52 PAGE 80
 CVDHAA.P11 12-JUL-83 00:42 GLOBAL SUBROUTINE - RDPDR -

```

3452
3453 014650 010237 015044      4$:  MOV    R2,70$           ;SAVE THE OUTER LOOP DATA PATTERN.
3454 014654 010577 165334      MOV    R5,aCSRA        ;SET CSR IND.ADR.REG FIELD TO THIS LINE.
3455 014660 010500              MOV    R5,R0
3456 014662 006300              ASL    R0
3457 014664 036037 002346 002210  BIT    BITTBL(R0),ACTLNS
3458 014672 001452              BEQ    16$             ;IS THE LINE ACTIVE? NO, SKIP THE LINE.
3459 014674 012703 000004      MOV    #LPRO,R3       ;YES, INITIALIZE REGISTER OFFSET FOR LPR.
3460
3461      ;+
3462      ;:
3463      ;-
3464 014700 010204              6$:  MOV    R2,R4           ;SAVE THE INNER LOOP DATA PATTERN.
3465 014702 046302 002234      BIC    UNBITB(R3),R2  ;REMOVE UNUSED BITS FROM EXPECTED DATA.
3466 014706 016300 002214      MOV    DRADRT(R3),R0
3467 014712 005766 000010      TST    R3SLOT(SP)    ;CHECK THE ACCESS TYPE INDICATOR.
3468 014716 001002              BNE    8$             ;BYTE ACCESS? YES, GO PERFORM BYTE READ.
3469 014720 011001              MOV    (R0),R1       ;NO, PERFORM WORD READ OF DEVICE REGISTER.
3470 014722 000416              BR     12$
3471 014724 100410              8$:  BMI    10$           ;LOW BYTE ACCESS? YES, GO DO LOW BYTE READ.
3472 014726 005200              INC    R0             ;HIGH BYTE ACCESS. FORM HIGH BYTE ADDRESS.
3473 014730 111001              MOVB   (R0),R1       ;READ THE HI BYTE OF THE DUT REGISTER.
3474 014732 000301              SWAB   R1            ;PUT HI BYTE BACK INTO THE HI BYTE.
3475 014734 042701 000377      BIC    #377,R1       ;REMOVE THE UNUSED BYTE IN ACTUAL DATA.
3476 014740 042702 000377      BIC    #377,R2       ;REMOVE THE UNUSED BYTE IN EXPECTED DATA.
3477 014744 000405              BR     12$
3478 014746 111001              10$: MOVB   (R0),R1      ;READ THE LOW BYTE OF THE DUT REGISTER.
3479 014750 042701 177400      BIC    #177400,R1   ;REMOVE THE UNUSED BYTE.
3480 014754 042702 177400      BIC    #177400,R2   ;FORM EXPECTED LOW BYTE FOR COMPARISON.
3481
3482 014760 046301 002234      12$: BIC    UNBITB(R3),R1 ;REMOVE UNUSED BITS FROM ACTUAL DATA.
3483 014764 020102              CMP    R1,R2         ;COMPARE ACTUAL AND EXPECTED DATA.
3484 014766 001404              BEQ    14$           ;ACTUAL = EXPECTED? YES, SKIP ERROR.
3485 014770 004737 014050      JSR    PC,CNTERR     ;NO, COUNT THE ERROR, CHECK FOR ERROR SUMMARY.
3486 014774 103401              BCS    14$           ;USE ERROR SUMMARY? YES, SKIP ERROR.
3487      ;NO, REPORT 'BAD BIT(S) IN DEVICE XXXXX REGISTER FOR LINE NN (D).''
3488 014776              ERROR
3489 014776 104460              TRAP   CSERROR
3490 015000 010402              14$: MOV    R4,R2           ;RESTORE THE INNER LOOP DATA PATTERN.
3491 015002 004737 015416      JSR    PC,ROLDAP    ;ROTATE DATA PATTERN LEFT, NOT THROUGH CARRY.
3492 015006 062703 000002      ADD    #2,R3         ;SET REGISTER OFFSET TO THE NEXT REGISTER.
3493 015012 020327 000016      CMP    R3,#TXBFCO   ;COMPARE REG OFFSET WITH OFFSET OF LAST REG.
3494 015016 003730              BLE   6$            ;LOOP IF NOT ALL REG DONE FOR THIS LINE.
3495
3496      ;+
3497      ;:
3498      ;-
3498 015020 013702 015044      16$: MOV    70$,R2       ;SET UP TO ROTATE THE DATA PATTERN.
3499 015024 004737 015416      JSR    PC,ROLDAP    ;ROTATE THE DATA PATTERN.
3500 015030 005205              INC    R5            ;COUNT THIS LINE
3501 015032 020527 000010      CMP    R5,#NUMLNS   ;COMPARE LINE COUNT WITH NUMBER OF LINES.
3502 015036 002704              BLT   4$            ;LOOP IF SOME LINES NOT DONE.
3503
3504 015040              60$: PASS           ;RESTORE GPRS.
3505 015040 004736              JSR    PC,a(SP)+    ;RETURN TO PREG05 SUBRT.
3506 015042 000207              RTS    PC
3507

```


CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 81
GLOBAL SUBROUTINE

- RDPDR -

3508 015044 000000

70\$: .WORD 0

;STORAGE FOR DATA PATTERN OUTSIDE INNER LOOP.

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 82
GLOBAL SUBROUTINE - REGTST -

```

3509 .SBTTL GLOBAL SUBROUTINE - REGTST -
3510 :+ *****
3511 :* - REGISTERS TEST SUBROUTINE -
3512 :* SUBROUTINE TO TEST THE DEVICE UNDER TEST (DUT) REGISTERS. THE USED
3513 :* BITS OF THE REGISTERS ARE EITHER ALL CLEARED OR ALL SET AND THEN THE
3514 :* DATA PATTERN IS WRITTEN AND VERIFIED USING EITHER WORD OR BYTE
3515 :* ACCESSES IN READ/WRITE OR READ/MODIFY/WRITE MODE.
3516 :*
3517 :* INPUTS: R3 - BYTE INDICATOR (- => LOW, + => HIGH, 0 => BOTH BYTES).
3518 :* R4 - ACCESS MODE (-1 => SET THEN BIC, 1 => CLEAR THEN BIS,
3519 :* (-2 => SET THEN MOV, +2 CLEAR THEN MOV).
3520 :* ERRNBR - SET UP WITH INITIAL ERROR NUMBER.
3521 :*
3522 :* OUTPUTS: GPRS0 - GPR SAVE AREA 0 IS DESTROYED.
3523 :* DEVICE UNDER TEST REGISTERS ARE WRITTEN.
3524 :* ERROR MESSAGES MAY BE PRINTED AT THE OPERATORS CONSOLE.
3525 :*
3526 :* CALLING SEQUENCE: JSR PC,REGTST
3527 :*
3528 :* COMMENTS: THIS ROUTINE LOOP 16 TIMES WRITING THE SAME DATA PATTERN
3529 :* ROTATED LEFT ONCE EACH ITERATION.
3530 :* THIS ROUTINE CAN REPORT ERRORS INITIAL ERRNBR THRU INITIAL+2.
3531 :*
3532 :* SUBORDINATE ROUTINES CALLED: RDPDR,RCLDAP,SWAPO,WDPDR
3533 :-- *****
3534
3535 015046 REGTST:: SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
3536 015046 004537 002674 JSR R5,PREG05 ;CALL REGISTER SAVE SUBRT.
3537
3538 :+ SET UP THE GPRS FOR THE WRITTING OF THE DATA PATTERN.
3539 :-
3540 015052 012705 000020 MOV #16,R5 ;SET UP LOOP COUNTER TO COUNT 16 ITERATIONS.
3541 015056 012702 167410 MOV #167410,R2 ;INITIALIZE THE DATA PATTERN.
3542 015062 032704 000001 BIT #BIT0,R4 ;TEST FOR R/W ACCESS.
3543 015066 001001 BNE 2$ ;R/M/W ACCESS? YES, R4 IS ALL SET UP.
3544 015070 005004 CLR R4 ;NO, INDICATE R/W ACCESS.
3545 015072 2$:
3546 :+
3547 :+ SET UP THE GPRS FOR THE CLEARING OR SETTING OF ALL THE USED BITS.
3548 :-
3549 015072 010400 MOV R4,R0 ;PASS OPERATION TYPE INDICATOR AROUND SWAPO.
3550 015074 004737 016156 JSR PC,SWAPO ;GET ALTERNATE GPR SET IN R1 THRU R5.
3551 015100 013701 002666 MOV ERRNBR,R1 ;SAVE THE INITIAL ERROR NUMBER.
3552 015104 010004 MOV R0,R4
3553 015106 005404 NEG R4 ;SET UP OP TYPE FOR CLEARING OR SETTING.
3554 015110 005002 CLR R2 ;SET UP CLEAR WRITE PATTERN.
3555 015112 026627 000012 000002 CMP R4,SLOT(SP),#2 ;TEST FOR CLEAR THEN MOV TEST SEQUENCE.
3556 015120 001401 BEQ 4$ ;CLEAR THEN MOV? YES, LEAVE WRITE PAT CLEAR.
3557 015122 005102 COM R2 ;NO, SET ALL BITS OF WRITE PATTERN.
3558 015124 005003 4$: CLR R3 ;INDICATE THAT WORD ACCESSES SHOULD BE USED.
3559 015126 005000 CLR R0 ;SET ALTERNATE BYTE EXPECTED DATA PAT TO CLEAR.
3560 015130 026627 000012 177776 CMP R4,SLOT(SP),#-2 ;TEST FOR SET THEN MOV TEST SEQUENCE.
3561 015136 001001 BNE 6$ ;SET THEN MOV? YES, LEAVE ALT BYTE PAT CLEAR.
3562 015140 005100 COM R0 ;NO, SET ALT BYTE EXPECTED DATA PAT TO ALL 1'S.
3563 015142 004737 016156 6$: JSR PC,SWAPO ;RESTORE SWAPPED GPR VALUES TO R1 THRU R5.
3564 :+

```

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 83
GLOBAL SUBROUTINE - REGTST -

```

3565      ; START OF DATA PATTERN LOOP.
3566      ;
3567      015146      8$:
3568      ;
3569      ;+ SET OR CLEAR ALL THE USED BITS OF THE DEVICE REGISTERS FOR ALL LINES.
3570      ;- VERIFY THAT ALL THE BITS WERE SET OR CLEARED CORRECTLY.
3571      ;
3572      015146 004737 016156      JSR      PC,SWAPO      ;GET ALTERNATE GPRS FOR SETTING INTIAL STATES.
3573      015152 004737 016550      JSR      PC,WDPDR      ;GO CLEAR ALL USED REGISTER BITS, ALL LINES.
3574      015156 010137 002666      MOV      R1,ERRNBR     ;SET UP ERROR NUMBER TO INITIAL ERRNBR.
3575      015162 004737 014626      JSR      PC,RDPDR     ;VERIFY ALL USED REGISTER BITS, ALL LINES.
3576      015166 004737 016156      JSR      PC,SWAPO     ;RESTORE MAIN GPRS CONTENTS.
3577      ;
3578      ;+ WRITE DATA PATTERNS, ALL LOWER BYTE USED BITS, ALL REGISTERS, ALL LINES.
3579      ;- VERIFY THAT THE DATA PATTERN WAS WRITTEN CORRECTLY.
3580      ;
3581      015172 004737 016550      JSR      PC,WDPDR     ;WRITE DATA PATTERN TO DEVICE REGISTERS.
3582      015176 005237 002666      INC      ERRNBR       ;SET ERROR NUMBER TO INITIAL+1.
3583      015202 004737 014626      JSR      PC,RDPDR     ;VERIFY DATA PATTERN IN ALTERRED BYTE(S).
3584      015206 005703              TST      R3           ;CHECK THE BYTE INDICATOR.
3585      015210 001411              BEQ      10$         ;WORD ACCESS? YES, SKIP SECOND BYTE CHECK.
3586      ;
3587      ;+ CHECK THAT THE ALTERNATE (UNMODIFIED) BYTE IS CLEAR OR SET AS EXPECTED.
3588      ;-
3589      015212 010201              MOV      R2,R1        ;SAVE THE DATA PATTERN.
3590      015214 010002              MOV      R0,R2        ;GET THE ALTERNATE BYTE EXPECTED DATA.
3591      015216 005403              NEG      R3           ;INDICATE THAT OTHER BYTE IS TO BE CHECKED.
3592      015220 005237 002666      INC      ERRNBR       ;SET ERROR NUMBER TO INITIAL+2.
3593      015224 004737 014626      JSR      PC,RDPDR     ;VERIFY DATA PATS IN OTHER BYTES OF REGISTERS.
3594      015230 005403              NEG      R3           ;RESTORE BYTE INDICATOR.
3595      015232 010102              MOV      R1,R2        ;RESTORE DATA PATTERN.
3596      ;
3597      ;+ PEPAARE THE NEXT DATA PATTERN AND LOOP IF NOT DONE.
3598      ;-
3599      015234 004737 015416      10$: JSR      PC,ROLDAP    ;ROTATE DATA PATTERN LEFT, NOT THROUGH CARRY.
3600      015240 005305              DEC      R5           ;COUNT THIS ITERATION OF THE LOOP.
3601      015242 003341              BGT      8$          ;ALL PATTERNS DONE? NO, LOOP.
3602      ;
3603      015244 013737 002406 002666 60$: MOV      GPRS0B,ERRNBR ;YES, RESTORE ERROR NUMBER AND EXIT.
3604      015252              PASS              ;GET THE ERROR NUMBR FROM GPR SWAP STORAGE.
3605      015252 004736              JSR      PC,@(SP)+   ;RESTORE GPRS.
3606      015254 000207              RTS      PC          ;RETURN TO PREG05 SUBRT.

```

```

3607 .SBTTL GLOBAL SUBROUTINE - REPSMR -
3608 .+ *****
3609 * - REPORT ERROR SUMMARY ROUTINE -
3610 * THIS SUBROUTINE REPORTS AN ERROR SUMMARY FOR THOSE LINES WHICH HAVE
3611 * EXCEEDED THE NUMBER OF INDIVIDUAL ERRORS TO REPORT FOR A SINGLE LINE
3612 * IN A SINGLE TEST. THIS PARAMETER CAN BE SPECIFIED BY THE OPERATOR IF
3613 * HE/SHE ANSWERS THE SOFTWARE PARAMETER QUESTIONS.
3614 *
3615 * INPUTS: ERCNTB - LABEL AT BASE OF LINE ERROR COUNTERS TABLE.
3616 *          ERRMSG - ADDRESS OF PRIMARY ERROR MESSAGE.
3617 *          ERRNBR - ERROR NUMBER OF ERRORS IN THIS ROUTINE.
3618 *          ERSMRF - 'REPORT ERROR SUMMARY FOR LINE' FLAGS.
3619 *
3620 * OUTPUTS: ERRBLK - ADDRESS OF ERROR REPORTING ROUTINE (DESTROYED).
3621 *          SUMMARY MESSAGES MAY BE PRINTED AT THE OPERATOR CONSOLE.
3622 *
3623 * CALLING SEQUENCE: JSR PC,REPSMR
3624 *
3625 * COMMENTS: IF NO LINES HAVE EXCEEDED THE MAXIMUM NUMBER OF INDIVIDUAL
3626 *            ERRORS TO REPORT, NO MESSAGES ARE PRINTED BY THIS ROUTINE.
3627 *            ERROR SUMMARIES IN THIS ROUTINE ARE REPORTED AS ERRORS.
3628 *            THE CONTENTS OF ERRBLK ARE DESTROYED.
3629 *
3630 * SUBORDINATE ROUTINES CALLED:
3631 * - *****
3632 *
3633 015256 REPSMR:: SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
3634 015256 004537 002674 JSR R5,PREG05 ;CALL REGISTER SAVE SUBRT.
3635 015262 005737 002420 TST ERSMRF ;CHECK THE 'PRINT LINE ERROR SUMMARY' FLAGS.
3636 015266 001404 BEQ 60$ ;EXIT WITHOUT ACTION IF NO SUMMARY FLAGS SET.
3637 *
3638 * WE HAVE SOME ERROR SUMMARIES TO REPORT.
3639 * -
3640 015270 012737 013130 002672 MOV #ER9004,ERRBLK ;SELECT ERROR REPORTING ROUTINE.
3641 *
3642 * REPORT
3643 * 'ERROR SUMMARY REPORT FOR LINES WITH EXCESSIVE NUMBERS OF ERRORS:'
3644 * -
3645 015276 ERROR
3646 015276 104460 TRAP C$ERROR
3647 *
3648 015300 60$: PASS ;RESTORE GPRS.
3649 015300 004736 JSR PC,@(SP)+ ;RETURN TO PREG05 SUBRT.
3650 015302 000207 RTS PC

```

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 85
GLOBAL SUBROUTINE - RESETT -

```

3651 .SBTTL GLOBAL SUBROUTINE - RESETT -
3652 *****
3653 - RESET DEVICE UNDER TEST -
3654 THIS SUBROUTINE IS USED TO RESET THE DUT TO A KNOWN STATE.
3655 IF RESET DOES NOT SUCCESSFULLY COMPLETE, IE. TIME-OUT OCCURS, THEN
3656 AN ABORT TEST ERROR MESSAGE IS REPORTED.
3657
3658 INPUTS: CSRA - CONTAINS THE ADDRESS OF THE CSR
3659 TXBFCA - CONTAINS ADDRESS OF DUT DMA BUFFER COUNT REGISTER.
3660 ERRCTL- ERRTP,ERNBR,AND ERRMSG SET UP CORRECTLY.
3661
3662 OUTPUTS: THE DUT PERFORMS ITS RESET FUNCTION INTO A KNOWN STATE.
3663 CARRY - CLEAR INDICATES THE TEST IS TO BE ABORTED.
3664 ERRLK - VALUE MAY BE DESTROYED.
3665 IESTAT - TX AND RX INTERRUPT FLAGS ARE CLEARED.
3666 TX AND RX INTERRUPT ENABLE BITS IN THE DUT'S CSR ARE CLEARED.
3667
3668 CALLING SEQUENCE: JSR PC,RESETT
3669
3670 COMMENTS: THIS SUBROUTINE CAN REPORT ERRORS WITH NUMBERS INITIAL ERNBR
3671 THIS ROUTINE DOES NOT DESTROY THE VALUE OF ERNBR.
3672
3673 SUBORDINATE ROUTINES CALLED: DELAY,MSLGET.
3674 *****
3675
3676 015304 RESETT:: SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
3677 015304 004537 002674 JSR R5,PREG05 ;CALL REGISTER SAVE SUBRT.
3678 015310 012702 000040 MOV #BIT05,R2 ;SET BIT MASK OF MASTER RESET BIT.
3679
3680 ;+
3681 ; TEST THE STATE OF THE MASTER RESET BIT IN THE CSR.
3682 ; IF MR IS SET THEN WAIT FOR SELF-TEST TO COMPLETE.
3683 ; IF TIME-OUT OCCURS, REPORT THE ERROR AND PASS-OUT ABORT TEST INDICATOR.
3684
3684 015314 013704 002214 MOV CSRA,R4 ;GET THE ADDRESS OF THE DUT'S CSR.
3685 015320 030214 BIT R2,(R4) ;CHECK STATE OF MASTER RESET BIT.
3686 015322 001406 BEQ 2$ ;DON'T DELAY IF MR IS ALREADY CLEAR.
3687 015324 005003 CLR R3 ;SET UP DESIRED STATE OF MASTER RESET BIT.
3688 015326 012701 004704 MOV #2500.,R1 ;PASS TIME-OUT VALUE OF 2.5 SECONDS.
3689 015332 004737 014166 JSR PC,MSLGET ;WAIT FOR SELF-TEST TO COMPLETE, MR CLEAR.
3690 015336 103012 BCC 4$ ;GO REPORT ERROR IF TIMEOUT OCCURRED.
3691
3692
3693 ;+
3694 ; SET MASTER RESET BIT IN CSR. CLEAR TX AND RX ENABLE BITS, ETC.
3695 ; SKIP THE SELFTEST.
3696 ; TIME-OUT OF 2.5 SECS, JUST IN CASE THE SELF-TEST EXECUTES.
3697
3697 015340 010277 164650 2$: MOV R2,@CSRA ;SET MASTER RESET BIT, DISABLE TX AND RX INTS.
3698 015344 004737 016100 JSR PC,SKPSTS ;TRY TO SKIP THE SELFTEST.
3699
3700 ;+
3701 ; SET SELF-TEST TIME-OUT OF 2.5 SECONDS, AND WAIT FOR M.R TO CLEAR.
3702 ; IF TIME-OUT OCCURS, THEN REPORT THE FATAL ERROR AND PASS-OUT THE ABORT
3703 ; TEST INDICATOR.
3704
3704 015350 005003 CLR R3 ;SET UP DESIRED STATE OF MASTER RESET BIT.
3705 015352 012701 004704 MOV #2500.,R1 ;PASS TIME-OUT VALUE OF 2.5 SECONDS.
3706 015356 004737 014166 JSR PC,MSLGET ;WAIT FOR SELF-TEST TO COMPLETE, MR CLEAR.

```


CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 88
GLOBAL SUBROUTINE - RSTRPT -

CVD
CVD
4

```

3765
3766
3767
3768
3769
3770
3771
3772
3773
3774
3775
3776
3777
3778
3779
3780
3781
3782
3783
3784
3785
3786
3787
3788
3789
3790
3791
3792
3793
3794 015450
3795 015450 004537 002674
3796
3797
3798
3799
3800 015454 005003
3801 015456 013705 002666
3802 015462 017702 164530
3803 015466 100412
3804
3805
3806
3807 015470 010537 002666
3808 015474 012701 011630
3809 015500 012737 013232 002672
3810
3811
3812
3813
3814 015506
3815 015506 104460
3816
3817
3818
3819 015510 000261
3820 015512 000545

```

```

.SBTTL GLOBAL SUBROUTINE - RSTRPT -
:++ *****
: * - REPORT ANY RESET ERRORS ROUTINE -
: * THIS ROUTINE DETERMINES IF ANY ERROR CODES ARE AMONG THE DIAGNOSTIC
: * CODES REPORTED PLACED IN THE DUT RECEIVED CHARACTER FIFO BY THE
: * SELF-TEST. IF ANY NON BMP ERROR CODES ARE FOUND, OR IF OTHER ERRORS
: * ARE ENCOUNTERED, APPROPRIATE ERRORS ARE REPORTED. ANY BMP CODES THAT
: * ARE FOUND, ARE PLACED ON THE BMP CODE QUEUE TO BE REPORTED LATER.
: * THIS ROUTINE ALSO PURGES THE DUT FIFO LOOKING FOR ANY CHARACTERS
: * OR MODEM STATUS CODES. IF ANY ARE FOUND, ERRORS ARE REPORTED.
: *
: * INPUTS: ERRMSG - ADDRESS OF THE PRIMARY ERROR MESSAGE.
: *          ERRNBR - ERROR NUMBER OF FIRST ERROR REPORTED BY THIS ROUTINE.
: *          NUMLNS - EQUATED TO THE NUMBER OF LINE ON THE DUT.
: *          RBUFA - CONTAINS ADDRESS OF THE DUT RECEIVER FIFO.
: *
: * OUTPUTS: CARRY - SUCCESS FLAG (SET IF FIFO CLEARED SUCCESSFULLY).
: *          ERRBLK - ADDRESS OF THE ERROR REPORT ROUTINE (DESTROYED).
: *          ERROR MESSAGES CAN BE PRINTED AT THE OPERATORS CONSOLE.
: *
: * CALLING SEQUENCE: JSR PC,RSTRPT
: *
: * COMMENTS: THIS SUBROUTINE CAN REPORT ERRORS WITH NUMBERS INITIAL ERRNBR
: *            THRU INITIAL ERRNBR+4.
: *            THIS ROUTINE DOES NOT DESTROY THE VALUE OF ERRNBR.
: *
: * SUBORDINATE ROUTINES CALLED: ER0503,ER9007,ER9008,SAVBMP.
:-- *****
RSTRPT:: SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
          JSR R5,PREG05 ;CALL REGISTER SAVE SUBRT.
:++
: READ CORRECT NUMBER (NUMBER OF LINE ON DUT) OF CHARS FROM THE FIFO.
: VERIFY THAT EACH CHAR IS A SELFTEST SUCCESS CODE.
:--
          CLR R3 ;CLEAR THE CODE COUNTER.
          MOV ERRNBR,R5 ;SAVE ERRNBR FOR RESTORATION LATER.
2$:      MOV @RBUFA,R2 ;READ A CHAR FROM THE DUT FIFO.
          BMI 4$ ;SKIP ERROR IF DATA.VALID SET FOR CHAR.
:++
: WE EXPECT A SELFTEST CODE, BUT THIS FIFO SLOT IS EMPTY.
:--
          MOV R5,ERRNBR ;RESTORE ERROR NUMBER TO INITIAL VALUE.
          MOV #EM9018,R1 ;PASS ERROR MESSAGE INFO TO ER9007 ROUTINE.
          MOV #ER9007,ERRBLK ;SELECT PROPER ERROR REPORT ROUTINE.
:++
: REPORT ERROR WITH NUMBER INITIAL ERRNBR.
: 'NO SELFTEST CODE IN SELFTEST CODE FIFO SLOT FOR LINE NN AFTER RESET.'
:--
          ERROR ; >>>> ERROR <<<<.
: * TRAP C$ERROR
:++
: INDICATE "SUCCESS" (BECAUSE FIFO IS PURGED), AND EXIT THIS ROUTINE.
:--
          SEC ;SET SUCCESS FLAG.
          BR 60$ ;EXIT ROUTINE.

```


CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 89
GLOBAL SUBROUTINE - RSTRPT -

```

3821
3822
3823
3824 015514 012700 070001
3825 015520 040200
3826 015522 001033
3827
3828
3829
3830
3831 015524 032702 000200
3832 015530 001443
3833 015532 120227 000203
3834 015536 001440
3835 015540 120227 000201
3836 015544 001435
3837 015546 012700 000300
3838 015552 040200
3839 015554 001003
3840 015556 004737 016032
3841 015562 000426
3842
3843
3844
3845 015564 010537 002666
3846 015570 005237 002666
3847 015574 012701 011655
3848 015600 012737 013310 002672
3849
3850
3851
3852
3853 015606
3854 015606 104460
3855 015610 000413
3856
3857
3858
3859 015612 010537 002666
3860 015616 062737 000002 002666
3861 015624 012701 011640
3862 015630 012737 013232 002672
3863
3864
3865
3866
3867 015636
3868 015636 104460
3869
3870
3871
3872 015640 005203
3873 015642 020327 000010
3874 015646 002705
3875
3876

:+
: DETERMINE IF THIS IS NOT A SELFTEST CODE.
:-
4$:  MOV    #70001,R0      ;GENERATE BIT MAP OF ANY CLEAR ERROR BITS OR
    BIC    R2,R0         ; BIT 0 WHICH ARE CLEAR.
    BNE    8$           ;GO TO REPORT ERROR IF THIS IS NOT A TEST CODE.

:+
: WE HAVE A TEST CODE (EITHER BMP OR SELFTEST CODE).
:-
: DETERMINE WHAT TYPE OF CODE WE HAVE.
:
: BIT    #BIT7,R2       ;TEST ROM VERSION CODE INDICATOR BIT.
: BEQ    10$           ;SKIP ERRORS IF SELFTEST ROM VERSION CODE.
: CMPB   R2,#203       ;CHECK IF SKIP SELF TEST CODE.
: BEQ    10$           ;SKIP ERROR REPORT IF SKIP SELF TEST CODE FOUND
: CMPB   R2,#201       ;CHECK IF NULL CODE PRESENT.
: BEQ    10$           ;SKIP ERROR REPORT IF SELF TEST NULL CODE.
: MOV    #300,R0       ;TEST CODE TYPE BITS FOR BOTH CODE
: BIC    R2,R0         ; TYPE BITS SET (INDICATING BMP CODE).
: BNE    6$           ;IF IT IS NOT A BMP CODE GO REPORT ERROR.
: JSR    PC,SAVBMP     ;SAVE THE BMP CODE ON THE QUEUE.
: BR     10$          ;GO GET THE NEXT CHARACTER FROM THE FIFO.

:+
: WE HAVE A SELFTEST ERROR CODE.
:-
6$:  MOV    R5,ERRNBR     ;RESTORE ERROR NUMBER TO INITIAL VALUE.
    INC    ERRNBR       ;CALCULATE INITIAL ERROR NUMBER PLUS 1.
    MOV    #EM9020,R1   ;PASS ERROR MESSAGE INFO TO ER9008 ROUTINE.
    MOV    #ER9008,ERRBLK ;SELECT PROPER ERROR REPORT ROUTINE.

:+
: REPORT ERROR WITH NUMBER INITIAL ERRNBR + 1.
: 'UNEXPECTED SELFTEST ERROR CODE FOR LINE NN IN FIFO AFTER RESET:'
:-
: ERROR                                     ; >>>> ERROR <<<<.
:                                     TRAP    C$ERROR
: BR     10$                               ;GO TO END OF LOOP.

:+
: WE HAVE A NON-SELFTEST CODE (EITHER BMP CODE OR DATA CHAR).
:-
8$:  MOV    R5,ERRNBR     ;RESTORE ERROR NUMBER TO INITIAL VALUE.
    ADD    #2,ERRNBR    ;CALCULATE INITIAL ERROR NUMBER PLUS 2.
    MOV    #EM9019,R1   ;PASS ERROR MESSAGE INFO TO ER9007 ROUTINE.
    MOV    #ER9007,ERRBLK ;SELECT PROPER ERROR REPORT ROUTINE.

:+
: REPORT ERROR WITH NUMBER INITIAL ERRNBR + 2.
: 'NON-SELFTEST CODE IN SELFTEST CODE FIFO SLOT FOR LINE NN AFTER RESET.'
:-
: ERROR                                     ; >>>> ERROR <<<<.
:                                     TRAP    C$ERROR

:+
: END OF LOOP, LOOP IF NOT ALL CHARS HAVE BEEN READ FROM THE FIFO.
:-
10$: INC    R3           ;SET CODE COUNTER FOR NEXT ITERATION OF LOOP.
    CMP    R3,#NUMLNS   ;TEST FOR ALL CODES READ.
    BLT    2$           ;LOOP IF NOT CHARS READ FROM FIFO.

:+
: PURGE THE FIFO UNTIL DATA.VALID IS CLEAR OR UNTIL TOO MANY CHARS ARE READ.

```

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 90
GLOBAL SUBROUTINE - RSTRPT -

```

3877      ;
3878      015650 012704 000022      :-      MOV      #18.,R4      ;INITIALIZE THE CHARACTER COUNTER.
3879      015654 010537 002666      MOV      R5,ERRNBR      ;GET INITIAL VALUE OF THE ERROR NUMBER.
3880      015660 062737 000003      ADD      #3,ERRNBR      ;CALCULATE ERROR NUMBER OF NEXT ERROR.
3881      015666 012737 013310      MOV      #ER9008,ERRBLK ;SELECT PROPER ERROR REPORT ROUTINE.
3882      015674 017702 164316      12$:      MOV      @RBUFA,R2      ;READ A CHARACTER FROM THE DUT FIFO.
3883      015700 000261      SEC      ;INDICATE SUCCESS IN CASE DATA.VALID IS CLEAR.
3884      015702 100051      BPL      60$      ;EXIT ROUTINE WITH SUCCESS IF DATA.VALID CLEAR.
3885
3886      ;+
3887      ; WE HAVE A CHARACTER.
3888      ; DETERMINE IF CHARACTER IS A DATA CHARACTER.
3889      015704 012700 070000      :-      MOV      #70000,R0      ;TEST BITS 12 THRU 14 OF THE
3890      015710 040200      BIC      R2,R0      ; CODE READ FROM THE DUT FIFO.
3891      015712 001403      BEQ      14$      ;SKIP THIS ERROR IF CODE IS NOT A DATA CHAR.
3892
3893      ;+
3894      ; WE HAVE AN UNEXPECTED DATA CHARACTER: SET UP AND GO TO REPORT ERROR.
3895      015714 012701 011701      :-      MOV      #EM9022,R1      ;SELECT ERROR MSG INFO FOR ER0808 ROUTINE.
3896      015720 000423      BR       22$      ;GO TO REPORT THIS ERROR.
3897
3898      ;+
3899      ; WE HAVE AN UNEXPECTED CODE.
3900      ; DETERMINE IF THE CODE IS A MODEM STATUS CODE.
3901      015722 032702 000001      14$:      BIT      #BIT0,R2      ;TEST MODEM STATUS INDICATOR BIT OF CODE.
3902      015726 001003      BNE      16$      ;SKIP THIS ERROR IF NOT MODEM STATUS CODE.
3903
3904      ;+
3905      ; WE HAVE A MODEM STATUS CODE: SET UP AND GO TO REPORT ERROR.
3906      015730 012701 011720      :-      MOV      #EM9023,R1      ;SELECT ERROR MSG INFO FOR ER0808 ROUTINE.
3907      015734 000415      BR       22$      ;GO TO REPORT THIS ERROR.
3908
3909      ;+
3910      ; WE HAVE AN ONBOARD TEST CODE.
3911      ; DETERMINE IF THIS CODE IS A BMP CODE.
3912      015736 032702 000200      16$:      BIT      #BIT7,R2      ;TEST THE ROM VERSION BIT OF THE CODE.
3913      015742 001404      BEQ      18$      ;GOTO SET UP FOR SELFTEST CODE IF ROM VERSION.
3914      015744 012700 000300      MOV      #300,R0
3915      015750 040200      BIC      R2,R0      ;TEST THE ERROR TYPE BITS OF THE CODE.
3916      015752 001403      BEQ      20$      ;SKIP THIS ERROR IF BMP CODE.
3917
3918      ;+
3919      ; WE HAVE A SELFTEST CODE: SET UP AND GO TO REPORT ERROR.
3920      015754 012701 011742      18$:      MOV      #EM9024,R1      ;SELECT ERROR MSG INFO FOR ER0808 ROUTINE.
3921      015760 000403      BR       22$      ;GO TO REPORT THIS ERROR.
3922
3923      ;+
3924      ; WE HAVE A BMP CODE: SAVE IT ON THE QUEUE.
3925      015762 004737 016032      20$:      JSR      PC,SAVBMP      ;SAVE THE BMP CODE ON THE QUEUE.
3926      015766 000401      BR       24$
3927
3928      ;+
3929      ; REPORT THE ERROR WITH ERROR NUMBER OF INITIAL ERRNBR + 3.
3930      ; 'UNEXPECTED XXX XXXX FOR LINE NN IN FIFO AFTER RESET:'
3931      015770      22$:      ERROR      ;
3932      015770 104460      ;>>>> ERROR <<<<<.

```

TRAP C\$ERROR

```

3933
3934
3935
3936
3937 015772 005304
3938 015774 001337
3939
3940
3941
3942
3943
3944 015776 012701 011517
3945 016002 010537 002666
3946 016006 062737 000004 002666
3947 016014 012737 012576 002672
3948
3949 016022
3950 016022 104460
3951 016024 000241
3952
3953 016026
3954 016026 004736
3955 016030 000207

    END OF LOOP.
    COUNT THE CHARACTER WE JUST RECEIVED, AND CHECK FOR TOO MANY RECEIVED.
24$:   DEC    R4           ;COUNT THIS CHARACTER.
       BNE   12$         ;LOOP IF NOT TOO MANY CHARACTERS PURGED.
    WE READ TOO MANY VALID CHARACTERS WHILE TRYING TO PURGE THE FIFO.
    REPORT ERROR AND EXIT WITHOUT SUCCESS.
    "FIFO WILL NOT PURGE (DATA.VALID STUCK SET), REMAINDER OF TEST SKIPPED."
    MOV     #EM9017,R1    ;SELECT PROPER ERROR MESSAGE.
    MOV     R5,ERRNBR    ;GET INITIAL ERROR NUMBER.
    ADD     #4,ERRNBR    ;CALCULATE INITIAL ERRNBR + 4.
    MOV     #ER0503,ERRBLK ;SELECT PROPER ERROR REPORT ROUTINE.
    PRINT  ERROR REPORT.
    ERROR                                         ;          >>>> ERROR <<<<<.
                                                    TRAP   C$ERROR
    CLC                                           ;CLEAR THE SUCCESS FLAG.
60$:   PASS
       JSR           ;RESTORE GPRS,
       PC,@(SP)+    ;RETURN TO PREG05 SUBRT.
       RTS    PC     ; CARRY - SUCCESS FLAG (SET IF FIFO IS PURGED).

```

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 92
GLOBAL SUBROUTINE - SAVBMP -

3956
3957
3958
3959
3960
3961
3962
3963
3964
3965
3966
3967
3968
3969
3970
3971
3972
3973
3974
3975
3976
3977
3978
3979
3980
3981
3982
3983
3984
3985
3986
3987
3988
3989
3990
3991
3992
3993

016032
016032 004537 002674
016036 013704 002462
016042 113724 002274
016046 005204
016050 042702 177400
016054 010224
016056 020427 002664
016062 103402
016064 162704 000004
016070 010437 002462
016074
016074 004736
016076 000207

```

.SBTTL GLOBAL SUBROUTINE - SAVBMP -
:++ *****
:
:           - SAVE BMP CODES ROUTINE -
: THIS ROUTINE SAVES THE PARAMETER PASSED IN, ONTO THE BMP CODE QUEUE
: TOGETHER WITH THE NUMBER OF THE CURRENTLY EXECUTING TEST.
:
: INPUTS:      R2 - CONTAINS THE BMP CODE THAT IS TO BE PLACED ON THE QUEUE.
:              BMPCQP - CONTAINS ADDRESS OF NEXT LOCATION IN THE BMP QUEUE.
:              BMPCQB - LABEL AT BASE OF THE BMP CODE QUEUE.
:              BMPCQE - LABEL OF NEXT LOCATION AFTER THE END OF THE BMP QUEUE.
:              TSTNUM - CONTAINS THE NUMBER OF THE CURRENT TEST.
:
: OUTPUTS:     BMPCQP - INCREMENTED BY 4.
:              THE CONTENTS OF THE BMP CODE QUEUE ARE UPDATED.
:
: CALLING SEQUENCE:  JSR    PC,SAVBMP
:
: COMMENTS:      IF THE OVERFLOW OCCURS THEN THE LAST LOCATION WILL BE
:                OVERWRITTEN BY ANY SUBSEQUENT ATTEMPTS TO UPDATE THE QUEUE.
:
: SUBORDINATE ROUTINES CALLED: NONE.
:-- *****

SAVBMP:: SAVE                ;SAVE CONTENTS OF GPRS R0 THRU R5.
                            R5,PREG05 ;CALL REGISTER SAVE SUBRT.
                            MOV    BMPCQP,R4 ;GET THE POINTER TO THE NEXT LOCATION IN QUEUE.
                            MOV    TSTNUM,(R4)+ ;SAVE THE CURRENT TEST NUMBER ON THE QUEUE.
                            INC    F,4 ;INCREMENT THE POINTER TO GIVE AN EVEN ADDRESS.
                            BIC    #177400,R2 ;CLEAR THE UNWANTED BITS FROM THE BMP CODE.
                            MOV    R2,(R4)+ ;SAVE THE BMP CODE ON THE QUEUE.
                            CMP    R4,#BMPCQE ;CHECK IF OVERFLOW WILL OCCUR THE NEXT TIME.
                            BLO    2$ ;GO SAVE THE POINTER IF WE WILL NOT OVERFLOW.
                            SUB    #4,R4 ;RESET THE POINTER TO THE LAST LOCATION IN QUE.
2$: MOV    R4,BMPCQP ;SAVE THE POINTER.

60$: PASS

RTS    PC    JSR    PC,@(SP)+ ;RESTORE GPRS. ;RETURN TO PREG05 SUBRT.

```

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 93
GLOBAL SUBROUTINE - SKPSTS -

3994
3995
3996
3997
3998
3999
4000
4001
4002
4003
4004
4005
4006
4007
4008
4009
4010
4011
4012
4013
4014 016100
4015 016100 004537 002674
4016 016104 012704 000012
4017 016110 004737 014126
4018
4019
4020
4021 016114 012701 000050
4022
4023
4024 016120 012703 052525
4025 016124 005301
4026 016126 013704 002214
4027 016132 010124
4028 016134 010324
4029 016136 020437 002232
4030 016142 103774
4031 016144 032701 000017
4032 016150 001365
4033
4034 016152
4035 016152 004736
4036 016154 000207

```

.SBTTL GLOBAL SUBROUTINE - SKPSTS -
:++ *****
: * - SKIP SELFTEST ROUTINE -
: * THIS SUBROUTINE IS USED TO SKIP THE SELFTEST AFTER A DUT RESET HAS BEEN
: * INITIATED. IT MUST BE ENTERED IMMEDIATELY AFTER SETTING THE DUT MASTER
: * RESET ROUTINE OR AFTER THE EXECUTION OF A BUS RESET (BECAUSE OF TIMING
: * CONSIDERATIONS).
: * INPUTS: CSRA - CONTAINS ADDRESS OF THE DUT CSR.
: * TXBFCA - CONTAINS ADDRESS OF DUT DMA BUFFER COUNT REGISTER.
: * OUTPUTS: SKIP SELFTEST CODES ARE WRITTEN TO THE DUT REGISTERS.
: * CALLING SEQUENCE: JSR PC,SKPSTS
: * COMMENTS:
: * SUBORDINATE ROUTINES CALLED: DELAY.
:-- *****
SKPSTS:: SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
;R5,PREG05 ;CALL REGISTER SAVE SUBRT.
MOV #10,R4 ;PASS DELAY VALUE OF 10 MILLI-SECONDS.
JSR PC,DELAY ;DELAY FOR 10 MILLI-SECONDS.
:++
: WRITE SKIP SELF-TEST CODE (52525) TO ALL THE INDEXED DUT REGISTERS.
:--
MOV #NUMLNS!BIT05,R1 ;FORM IND.ADR.REG FIELD (PLUS M.R. BIT) WORD.
;THE ABOVE INCLUSION OF THE M.R. BIT IS NECESSARY BECAUSE OF THE
; LACK OF A M.R. BIT WRITE LOCK-OUT ON THE DHV-11.
MOV #52525,R3 ;INITIALISE THE SKIP SELF-TEST CODE.
4$: DEC R1 ;SELECT THE NEXT SET OF DEVICE REGISTERS.
MOV CSRA,R4 ;GET THE ADDRESS OF THE CSR OF THE DUT.
MOV R1,(R4)+ ;SELECT A BANK OF DUT REGISTERS.
6$: MOV R3,(R4)+ ;WRITE THE CODE TO A DUT REGISTER.
CMP R4,TXBFCA ;COMPARE POINTER WITH LAST REGISTER ADDRESS.
BLO 6$ ;LOOP IF NOT ALL REGS DONE IN THIS BANK.
BIT #17,R1 ;TEST FOR IND.ADR.REG FIELD DECREMENTED TO 0.
BNE 4$ ;LOOP UNTIL ALL REGISTERS CONTAIN THE CODE.
60$: PASS ;RESTORE GPRS.
;PC,@(SP)+ ;RETURN TO PREG05 SUBRT.
RTS PC JSR

```

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 94
GLOBAL SUBROUTINE - SWAPO -

```

4037 .SBTTL GLOBAL SUBROUTINE - SWAPO -
4038 :+ *****
4039 :+ - SWAP GPRS WITH GPR SET 0 ROUTINE -
4040 :+ THIS SUBROUTINE SWAPS THE PRESENT CONTENTS OF GPRS R1 THRU R5 WITH
4041 :+ THE CONTENTS OF THE NUMBER ZERO GPR SAVE AREA. THE CONTENTS OF R0
4042 :+ ARE NOT ALTERED BY THIS SUBROUTINE.
4043 :+
4044 :+ INPUTS: GPR CONTENTS R1 THRU R5.
4045 :+ GPRS0B - LABEL AT BASE OF GPR SAVE AREA NUMBER ZERO.
4046 :+
4047 :+ OUTPUTS: R1 THRU R5 CONTAIN THE PREVIOUS CONTENTS OF GPR SAVE AREA
4048 :+ ZERO WORDS 1 THRU 5 RESPECTIVELY.
4049 :+ GPRS0 - GPR SAVE AREA 0 WORDS 1 THRU 5, CONTAIN PREVIOUS
4050 :+ CONTENTS OF GPRS R1 THRU R5 RESPECTIVELY.
4051 :+
4052 :+ CALLING SEQUENCE: JSR PC,SWAPO
4053 :+
4054 :+ COMMENTS: THE STATE OF THE CARRY FLAG IS NOT ALTERED BY THIS ROUTINE.
4055 :+
4056 :+ SUBORDINATE ROUTINES CALLED: NONE.
4057 :+----- *****
4058 :+
4059 016156 010046 SWAPO:: MOV R0,-(SP) ;SAVE THE CONTENTS OF R0.
4060 :+
4061 :+ LOAD THE STACK FROM THE GPRS.
4062 :+-----
4063 016160 010146 MOV R1,-(SP) ;SAVE THE CONTENTS OF R1.
4064 016162 010246 MOV R2,-(SP) ;SAVE THE CONTENTS OF R2.
4065 016164 010346 MOV R3,-(SP) ;SAVE THE CONTENTS OF R3.
4066 016166 010446 MOV R4,-(SP) ;SAVE THE CONTENTS OF R4.
4067 016170 010546 MOV R5,-(SP) ;SAVE THE CONTENTS OF R5.
4068 :+
4069 :+ LOAD THE GPRS FROM THE GPR SAVE AREA 0.
4070 :+-----
4071 016172 012700 002406 MOV #GPRS0B,R0 ;GET THE BASE ADDRESS OF GPR SAVE AREA 0.
4072 016176 012001 MOV (R0)+,R1 ;LOAD R1 WITH GPR SAVE AREA 0 WORD 1.
4073 016200 012002 MOV (R0)+,R2 ;LOAD R1 WITH GPR SAVE AREA 0 WORD 2.
4074 016202 012003 MOV (R0)+,R3 ;LOAD R1 WITH GPR SAVE AREA 0 WORD 3.
4075 016204 012004 MOV (R0)+,R4 ;LOAD R1 WITH GPR SAVE AREA 0 WORD 4.
4076 016206 012005 MOV (R0)+,R5 ;LOAD R1 WITH GPR SAVE AREA 0 WORD 5.
4077 :+
4078 :+ LOAD THE GPR SAVE AREA 0 FROM THE STACK.
4079 :+-----
4080 016210 012640 MOV (SP)+,-(R0) ;LOAD GPR SAVE AREA 0 WORD 5 WITH SAVED R5.
4081 016212 012640 MOV (SP)+,-(R0) ;LOAD GPR SAVE AREA 0 WORD 4 WITH SAVED R4.
4082 016214 012640 MOV (SP)+,-(R0) ;LOAD GPR SAVE AREA 0 WORD 3 WITH SAVED R3.
4083 016216 012640 MOV (SP)+,-(R0) ;LOAD GPR SAVE AREA 0 WORD 2 WITH SAVED R2.
4084 016220 012640 MOV (SP)+,-(R0) ;LOAD GPR SAVE AREA 0 WORD 1 WITH SAVED R1.
4085 :+
4086 016222 012600 MOV (SP)+,R0 ;RESTORE THE INITIAL VALUE OF R0.
4087 :+
4088 016224 000207 RTS PC

```

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 95
GLOBAL SUBROUTINE - TSABRT -

4089
4090
4091
4092
4093
4094
4095
4096
4097
4098
4099
4100
4101
4102
4103
4104
4105
4106
4107
4108
4109
4110
4111
4112
4113
4114
4115
4116
4117
4118
4119
4120
4121
4122
4123
4124
4125
4126
4127
4128
4129

016226
016226 004537 002674
016232 012701 016250
016236 012737 013050 002672
016244
016244 104460
016246 000432
016250 047040 047117 051055
016256 046105 052101 042105
016264 052040 051505 020124
016272 051105 047522 020122
016300 047506 047125 020104
016306 052504 044522 043516
016314 052040 051505 020124
016322 054105 041505 052125
016330 047511 000116
016334
016334 004736
016336 000207

```

.SBTTL GLOBAL SUBROUTINE - TSABRT -
++ *****
* - TEST ABORT ROUTINE -
* THIS SUBROUTINE IS USED WHEN A NON-TEST RELATED ERROR HAS BEEN FOUND
* DURING THE EXECUTION OF THE CURRENT TEST.
* IT IS USED TO INFORM THE OPERATOR THAT THE CURRENT TEST HAS BEEN
* ABORTED.
* INPUTS: ERRMSG - CONTAINS THE NAME OF THE CURRENT TEST.
*          ERRNBR - CONTAINS THE CORRECT ERROR NUMBER.
*          THE REMAINDER OF THE ERRTBL IS CORRECTLY INITIALISED.
* OUTPUTS: MESSAGES ARE REPORTED TO THE OPERATOR.
* CALLING SEQUENCE: JSR PC,TSABRT
* COMMENTS:
* SUBORDINATE ROUTINES CALLED: ER1603.
-- *****

TSABRT:: SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
                JSR R5,PREG05 ;CALL REGISTER SAVE SUBRT.
                MOV #2$,R1 ;PASS ADDRESS OF FIRST MESSAGE TO BE REPORTED.
                MOV #ER1603,ERRBLK ;SET-UP THE ERROR REPORTING ROUTINE.
                ERROR ; >>>> ERROR <<<<<. TRAP C$ERROR
                BR 60$

2$: .ASCIZ / NON-RELATED TEST ERROR FOUND DURING TEST EXECUTION/

.EVEN
60$: PASS ;RESTORE GPRS.
                JSR PC,@(SP)+ ;RETURN TO PREG05 SUBRT.
                RTS PC

```

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 96
GLOBAL SUBROUTINE - UNSDIV -

```

4130 .SBTTL GLOBAL SUBROUTINE - UNSDIV -
4131 :+ *****
4132 :* - UNSIGNED DIVIDE ROUTINE -
4133 :* THIS SUBROUTINE IS USED TO DIVIDE A 32 BIT UNSIGNED DIVIDEND BY A
4134 :* 16 BIT UNSIGNED DIVISOR GIVING A 16 BIT QUOTIENT. ALL NUMBERS ARE
4135 :* CONSIDERED TO BE UNSIGNED. A SUCCESS FLAG IS NOT SET ON RETURN IF
4136 :* THE QUOTIENT WAS TOO BIG TO BE CONTAINED IN 16 BITS.
4137 :*
4138 :* INPUTS: R1 - THE DIVISOR, UNSIGNED, 16 BITS.
4139 :* R2 - MOST SIGNIFICANT WORD OF THE DIVIDEND, UNSIGNED, 16 BITS.
4140 :* R3 - LEAST SIGNIFICANT WORD OF THE DIVIDEND, UNSIGNED, 16 BITS.
4141 :*
4142 :* OUTPUTS: R1 - QUOTIENT, UNSIGNED, 16 BITS (177777 IF OVERFLOW).
4143 :* CARRY - SUCCESS FLAG, SET IF COMPLETE QUOTIENT FITS IN 16 BITS.
4144 :*
4145 :* CALLING SEQUENCE: JSR PC,UNSDIV
4146 :*
4147 :* COMMENTS: IF THE DIVISOR IS 0 THE QUOTIENT IS RETURNED AS ALL ONES
4148 :* (177777) AND THE CARRY IS CLEAR REGARDLESS OF THE DIVIDEND.
4149 :*
4150 :* SUBORDINATE ROUTINES CALLED: NONE.
4151 :-- *****
4152
4153 016340 UNSDIV:: SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
4154 016340 004537 002674 JSR R5,PREG05 ;CALL REGISTER SAVE SUBRT.
4155
4156 :+ CHECK FOR QUOTIENT GREATER THAN 16 BITS CONDITION.
4157 :-
4158 016344 010204 MOV R2,R4 ;GET MSW OF DIVIDEND FOR SUBTRACT.
4159 016346 160104 SUB R1,R4 ;SUBTRACT DIVISOR FROM MSW OF DIVIDEND.
4160 016350 103403 BCS 2$ ;IF IT DIDN'T GO, WE HAVE QUOTIENT < 16 BITS.
4161 016352 012701 177777 MOV #-1,R1 ;SET QUOTIENT TO ALL ONES (177777),
4162 016356 000442 BR 60$ ;EXIT WITH CARRY CLEAR.
4163
4164 :+ SET UP COUNTERS AND VARIOUS WORKING GPRS.
4165 :-
4166 016360 005004 2$: CLR R4 ;CLEAR THE LSW OF THE DIVISOR.
4167 016362 000241 CLC ;CLEAR CARRY FOR THE SHIFT OF THE DIVISOR.
4168 016364 006001 ROR R1 ; DIVISOR BY
4169 016366 006004 ROR R4 ; 2(UNSIGNED)
4170 016370 012700 000020 MOV #16.,R0 ;SET UP INITIAL SHIFT COUNT TO 16.
4171
4172 :+ THE SUBTRACT AND SHIFT LOOP.
4173 :-
4174 016374 010246 4$: MOV R2,-(SP) ;SAVE MSWORD OF DIVIDEND.
4175 016376 010346 MOV R3,-(SP) ;SAVE LSWORD OF DIVIDEND.
4176 016400 160403 SUB R4,R3 ;LSWORD DIVIDEND - LSWORD OF DIVISOR.
4177 016402 005602 SBC R2 ;MSWORD DIVIDEND - BORROW
4178 016404 103402 BCS 6$ ;IF BORROW FROM BORROW SUBTRACT, IT DIDN'T GO.
4179 016406 160102 SUB R1,R2 ;MSWORD DIVIDEND - MSWORD OF DIVISOR.
4180 016410 103003 BCC 8$ ;IF NO BORROW, IT WENT, CARRY IS CLEAR.
4181
4182 :+ IT DIDN'T GO, SO WE SHIFT A 1 INTO THE QUOTIENT (COMPLEMENTED LATER).
4183 :+ CARRY IS SET.
4184 :-
4185 016412 012603 6$: MOV (SP)+,R3 ;RESTORE LSWORD OF DIVIDEND.

```


CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 97
GLOBAL SUBROUTINE

- UNSDIV -

```

4186 016414 012602          MOV    (SP)+,R2      ;RESTORE MSWORD OF DIVIDEND.
4187 016416 000401          BR     10$          ;GOTO SHIFT 1 INTO THE QUOTIENT.
4188
4189      ;+ IT WENT, SO WE RESTORE THE STACK AND SHIFT A 0 INTO QUOTIENT (WILL BE
4190      ;- COMPLEMENTED LATER). CARRY IS CLEAR.
4191
4192 016420 012626      8$:   MOV    (SP)+,(SP)+  ;POP THE SAVED DIVIDEND OFF OF THE STACK.
4193
4194      ;+ SHIFT THE RESULT OF THE SUBTRACT ATTEMPT INTO THE QUOTIENT SHIFT REG.
4195      ;-
4196 016422 006105      10$:  ROL    R5          ;SHIFT NEXT BIT INTO THE INVERTED QUOTIENT.
4197 016424 000241          CLC          ;DIVIDE THE
4198 016426 006001          ROR    R1          ; DEVISOR BY
4199 016430 006004          ROR    R4          ; 2 (UNSIGNED).
4200 016432 005300          DEC    R0          ;COUNT THIS SHIFT AND SUBTRACT.
4201 016434 001357          BNE    4$          ;LOOP FOR ANOTHER SHIFT & SUB IF NOT DONE.
4202 016436 005105          COM    R5          ;GET QUOTIENT FROM INVERTED QUOTIENT.
4203
4204      ;+ NOW WE EITHER ROUND UP OR LEAVE QUOTIENT ALONE.
4205      ;-
4206 016440 000241          CLC          ;CLEAR THE CARRY FOR THE SHIFT OF THE DIVIDEND.
4207 016442 006103          ROL    R3          ;MULTIPLY LSWORD OF DIVIDEND BY 2, MSWORD IS 0.
4208 016444 103402          BCS    12$        ;IF CARRY FROM SHIFT, ROUND UP.
4209 016446 160403          SUB    R4,R3      ;SUBTRACT DIVISOR FROM DIVIDEND.
4210 016450 103403          BCS    14$        ;IF BORROW, DON'T ROUND UP.
4211
4212      ;+ ROUND UP, EXTRA SUBTRACT WENT.
4213      ;-
4214 016452 005205      12$:  INC    R5          ;INCREMENT THE QUOTIENT BY ONE.
4215 016454 001001          BNE    14$        ;IF NO OVERFLOW, WE LEAVE THE ROUND UP.
4216 016456 005305          DEC    R5          ;DON'T LET ROUNDING CAUSE OVERFLOW.
4217
4218      ;+ ALL DONE, PASS QUOTIENT AND EXIT.
4219      ;-
4220 016460 010501      14$:  MOV    R5,R1        ;PASS QUOTIENT BACK IN R1.
4221 016462 000261          SEC          ;INDICATE NO OVERFLOW.
4222
4223 016464          60$:  PASS    R1          ;RESTORE GPRS, LEAVE THE FOLLOWING INTACT:
4224 016464 010166 000004      MOV    R1,R1SLOT(SP) ;PUT R1 IN STACK SLOT.
4225 016470 004736          JSR    PC,@(SP)+    ;RETURN TO PREG05 SUBRT.
4226
4227 016472 000207          RTS    PC          ;R1 - 16 BIT, UNSIGNED QUOTIENT,
;CARRY - SET INDICATES NO OVERFLOW (SUCCESS).

```

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 98
GLOBAL SUBROUTINE - WAIBIS -

4228
4229
4230
4231
4232
4233
4234
4235
4236
4237
4238
4239
4240
4241
4242
4243
4244
4245
4246
4247
4248
4249
4250
4251
4252
4253
4254
4255
4256 016474
4257 016474 004537 002674
4258 016500 010204
4259 016502 010102
4260 016504 042701 170000
4261 016510 042702 007777
4262 016514 000302
4263 016516 006202
4264 016520 006202
4265 016522 006202
4266 016524 016202 002346
4267 016530 010203
4268 016532 004737 014166
4269
4270 016536 010002
4271 016540
4272 016540 010266 000006
4273 016544 004736
4274
4275 016546 000207

```
.SBTTL GLOBAL SUBROUTINE - WAIBIS -
++ *****
* - WAIT FOR BIT SET ROUTINE -
* THIS SUBROUTINE WAITS FOR THE SPECIFIED BIT TO BECOME SET. IF THE
* SPECIFIED BIT GOES TO A SET STATE WITHIN THE SPECIFIED TIME-OUT
* PERIOD A SUCCESS INDICATION IS RETURNED BY THIS ROUTINE.
* THE LAST VALUE WHICH IS READ LOOKING FOR THE CONDITION IS RETURNED TO
* ALLOW THE USE OF THIS ROUTINE TO LOOK FOR DESTRUCTIVE READ CONDITIONS.
* INPUTS: R1 - TIME-OUT VALUE AND BIT NUMBER INDICATION:
* BITS 15 THRU 12 - NUMBER OF BIT TO TEST (RANGE 0 THRU 15).
* BITS 11 THRU 0 - TIME-OUT VALUE IN MILLI-SECONDS (4095 MAX).
* R2 - ADDRESS OF WORD CONTAINING THE BIT TO TEST.
* MSLCNT.
* OUTPUTS: R2 - THE LAST WORD WHICH WAS READ TO CHECK FOR THE CONDITION.
* CARRY - SUCCESS FLAG (CARRY SET IF BIT SET BEFORE TIME-OUT).
* CALLING SEQUENCE: MOV #130040,R1 ;PASS BIT 11 (13 OCTAL) AND
* ; 32 (40 OCTAL) MS DELAY.
* MOV #LABEL,R2 ;TEST BIT IN WORD AT 'LABEL'.
* JSR PC,WAIBIS ;WAIT 32 MS FOR BIT 11 TO SET.
* COMMENTS:
* SUBORDINATE ROUTINES CALLED: MSLGET.
*-- *****
```

```
WAIBIS:: SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
JSR R5,PREG05 ;CALL REGISTER SAVE SUBRT.
;SET UP THE ADDRESS PARAMETER FOR MSLGET.
MOV R2,R4
MOV R1,R2
BIC #170000,R1 ;SEPERATE DELAY COUNT OUT OF PASSED PARAMETER.
BIC #7777,R2 ;SEPERATE LINE NUMBER FIELD OF PASSED PARAM.
SWAB R2 ;PUT LINE NUMBER FIELD IN LSBYTE.
ASR R2 ;SHIFT THE LINE NUMBER FIELD INTO THE PROPER
; POSITION TO USE IT AS A WORD TABLE OFFSET
ASR R2 ; FOR THE TABLE LOOKUP OF THE LINE BIT MAP.
ASR R2
MOV BITTBL(R2),R2 ;GET BIT MAP OF LINE TO TEST FROM TABLE.
MOV R2,R3 ;INDICATE THAT THE BIT SHOULD BE SET.
JSR PC,MSLGET ;WAIT FOR THE BIT TO BE SET WITHIN TIME-OUT.
; CARRY IS CORRECT UPON MSLGET RETURN.
MOV R0,R2 ;PASS LAST VALUE READ AS OUTPUT PARAMETER.
60$: PASS R2 ;RESTORE GPRS, EXCEPT THE FOLLOWING:
MOV R2,R2SLOT(SP) ;PUT R2 IN STACK SLOT.
JSR PC,@(SP)+ ;RETURN TO PREG05 SUBRT.
; R2 - LAST VALUE READ LOOKING FOR CONDITION.
; CARRY - SUCCESS FLAG (SET IF BIT FOUND SET).
```

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 99
GLOBAL SUBROUTINE - WDPDR -

4276
4277
4278
4279
4280
4281
4282
4283
4284
4285
4286
4287
4288
4289
4290
4291
4292
4293
4294
4295
4296
4297
4298
4299
4300
4301
4302
4303
4304
4305
4306
4307
4308
4309
4310
4311
4312
4313
4314
4315
4316
4317 016550
4318 016550 004537 002674
4319
4320
4321
4322 016554 005005
4323
4324
4325
4326
4327 016556 010204
4328 016560 010577 163430
4329 016564 006305
4330 016566 036537 002346 002210
4331 016574 001451

```
.SBTTL GLOBAL SUBROUTINE - WDPDR -
:++ *****
: * - WRITE DATA PATTERN TO DEVICE REGISTERS -
: * THIS ROUTINE WRITES A ROTATED DATA PATTERN TO EACH OF THE 6 DEVICE
: * REGISTERS OF EACH ACTIVE LINE OF THE DEVICE UNDER TEST.
: * THE DATA PATTERN IS ROTATED ONCE AFTER EACH WRITE TO A DEVICE REGISTER
: * ON A PARTICULAR LINE. THE STARTING DATA PATTERN FOR EACH LINE
: * IS ROTATED ONCE AFTER WRITING ALL THE REGISTERS ON A PARTICULAR
: * LINE. THIS LEADS TO THE FOLLOWING DATA PATTERN:
: * LINE 0, REGISTER 0 - SHIFTED 0 BIT POSITIONS
: * LINE 0, REGISTER 1 - SHIFTED 1 BIT POSITION
: *
: * LINE 1, REGISTER 0 - SHIFTED 1 BIT POSITION
: * LINE 2, REGISTER 1 - SHIFTED 2 BIT POSITIONS
: *
: * ANY BITS FIELDS IN THE DEVICE REGISTERS THAT CANNOT BE ALTERED
: * ARE MASKED OUT OF THE DATA PATTERN BEFORE IT IS WRITTEN.
: * THIS ROUTINE WILL USE EITHER MOV, MOVB, BIS, BISB, BIC, OR BICB
: * INSTRUCTIONS. THE UPPER OR LOWER BYTE CAN BE SPECIFIED FOR WRITING.
: *
: * INPUTS: R2 - USED TO PASS IN THE DATA PATTERN TO BE ROTATED & WRITTEN.
: * R3 - BYTE INDICATOR (- => LO BYTE, + => HI BYTE, 0 => BOTH).
: * R4 - OPERATION TYPE INDICATOR (- => BIC, + => BIS, 0 => MOV).
: * ACTLNS - BIT MAP OF THE ACTIVE LINES ON THE DEVICE UNDER TEST.
: * CSRA - CONTAINS THE CSR ADDRESS OF THE DEVICE UNDER TEST.
: * DRADRT - BASE ADDRESS OF DEVICE REGISTER ADDRESS TABLE.
: * LPRO - EQUATED TO LPR REG OFFSET FROM DEVICE CSR ADDRESS.
: * NUMLNS - NUMBER OF LINES ON THE DEVICE UNDER TEST.
: * TXBFCO - EQUATED TO TBUFFCT REG OFFSET FROM DEVICE CSR ADDRESS.
: * UNBTB - BASE ADDRESS OF THE UNUSED BIT TABLE.
: *
: * OUTPUTS: DEVICE REGISTERS ON ALL ACTIVE DEVICE LINES ARE MODIFIED.
: *
: * CALLING SEQUENCE: JSR PC,WDPDR
: *
: * COMMENTS: THIS ROUTINE DOES NOT WRITE ANY DATA TO THE TX.CHAR REGISTERS.
: * THE CSR IS CLEARED EXCEPT FOR THE IND.ADR.REG FIELD.
: *
: * SUBORDINATE ROUTINES CALLED: ROLDAP.
:-- *****
WDPDR:: SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
JSR R5,PREG05 ;CALL REGISTER SAVE SUBRT.
: +
: SET UP OUTER LOOP WHICH WRITES THE DATA PATTERN TO EACH LINE'S REGISTERS
: -
CLR R5 ;CLEAR LINE COUNTER TO SELECT LINE 0.
: +
: THE OUTER LOOP FOLLOWS. EACH PASS THROUGH THIS LOOP WRITES DATA TO ALL OF
: THE DEVICE REGISTERS FOR A PARTICULAR LINE IF IT IS ACTIVE.
: -
2$: MOV R2,R4 ;SAVE THE OUTER LOOP DATA PATTERN.
MOV R5,@CSRA ;SET CSR IND.ADR.REG FIELD TO THIS LINE.
ASL R5 ;TURN LINE NUMBER INTO A WORD OFFSET.
BIT BITTBL(R5),ACTLNS
BEQ 20$ ;LINE ACTIVE? NO, SKIP THIS LINE.
```

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 100

GLOBAL SUBROUTINE

- WDPDR -

```

4332 016576 012701 000004      MOV    #LPRO,R1      ;YES, INITIALIZE THE REGISTER OFFSET.
4333                               ;+
4334                               ; THE INNER LOOP FOLLOWS.  EACH PASS THROUGH THIS LOOP WRITES DATA TO A
4335                               ; DEVICE REGISTER.
4336                               ; -
4337 016602 010200      4$:  MOV    R2,R0
4338 016604 046100      BIC    UNBTTB(R1),R0 ;CLEAR BIT FIELDS FOR UNUSED REGISTER BITS.
4339 016610 016103      MOV    DRADRT(R1),R3 ;GET THE ADDRESS OF THE DEVICE REGISTER.
4340 016614 005766      TST    R3SLOT(SP)   ;CHECK THE OPERAND TYPE INDICATOR.
4341 016620 003402      BLE    6$          ;HIGH BYTE? NO, SKIP HIGH BYTE ADDRESS SET UP.
4342 016622 005203      INC    R3          ;YES, SET THE REG ADDRESS TO THE HIGH BYTE.
4343 016624 000300      SWAB  R0          ;MOVE HIGH BYTE DATA INTO THE LOW BYTE.
4344 016626 005766      6$:  TST    R3SLOT(SP)   ;CHECK THE OPERAND TYPE INDICATOR.
4345 016632 001412      BEQ    12$        ;WORD ACCESS? YES, GO PERFORM WORD ACCESS.
4346                               ;+
4347                               ; PERFORM BYTE ACCESS TO THE SPECIFIED BYTE OF THE SPECIFIED REGISTER.
4348                               ; -
4349 016634 005766      8$:  TST    R4SLOT(SP)   ;NO, CHECK THE ACCESS TYPE INDICATOR.
4350 016640 100403      BMI    8$         ;USE BIC? YES, GO PERFORM BICB INSTRUCTION.
4351 016642 001404      BEQ    10$        ;USE MOV? YES, GO PERFORM MOV B INSTRUCTION.
4352 016644 150013      BISB  R0,(R3)    ;NEITHER. PERFORM BISB ACCESS TO REGISTER.
4353 016646 000415      BR    18$
4354 016650 140013      8$:  BICB  R0,(R3)    ;PERFORM BICB ACCESS TO REGISTER.
4355 016652 000413      BR    18$
4356 016654 110013      10$: MOV B  R0,(R3)   ;PERFORM MOV B ACCESS TO REGISTER.
4357 016656 000411      BR    18$
4358                               ;+
4359                               ; PERFORM WORD ACCESS TO THE SPECIFIED REGISTER.
4360                               ; -
4361 016660 005766      12$: TST    R4SLOT(SP)   ;CHECK THE ACCESS TYPE INDICATOR.
4362 016664 100403      BMI    14$        ;USE BIC? YES, GO PERFORM BIC INSTRUCTION.
4363 016666 001404      BEQ    16$        ;USE MOV? YES, GO PERFORM MOV INSTRUCTION.
4364 016670 050013      BIS   R0,(R3)    ;NEITHER. PERFORM BIS ACCESS TO REGISTER.
4365 016672 000403      BR    18$
4366 016674 040013      14$: BIC   R0,(R3)    ;PERFORM BIC ACCESS TO REGISTER.
4367 016676 000401      BR    18$
4368 016700 010013      16$: MOV   R0,(R3)   ;PERFORM MOV ACCESS TO REGISTER.
4369                               ;+
4370                               ; PREPARE THE DATA PATTERN AND OFFSET FOR THE NEXT REGISTER ON THIS LINE.
4371                               ; -
4372 016702 004737      18$: JSR    PC,ROLDAP  ;ROTATE DATA PATTERN LEFT, NOT THROUGH CARRY.
4373 016706 062701      ADD    #2,R1      ;INCREMENT OFFSET FOR NEXT REGISTER.
4374 016712 020127      CMP    R1,#TXBFCO ;COMPARE REG OFFSET WITH OFFSET OF LAST REG.
4375 016716 003731      BLE    4$        ;LOOP IF NOT ALL REG DONE FOR THIS LINE.
4376                               ;+
4377                               ; BACK INTO THE OUTER LOOP.  NOW SET UP FOR NEXT LINE.  LOOP IF NOT DONE.
4378                               ; -
4379 016720 010402      20$: MOV    R4,R2
4380 016722 004737      JSR    PC,ROLDAP  ;SET UP TO ROTATE THE DATA PATTERN.
4381 016726 006205      ASR   R5          ;ROTATE THE DATA PATTERN.
4382 016730 005205      INC   R5          ;CONVERT BACK TO LINE NUMBER FROM WORD OFFSET.
4383 016732 020527      CMP   R5,#NUMLNS ;COUNT THIS LINE.
4384 016736 002707      BLT   2$         ;COMPARE LINE COUNT WITH NUMBER OF LINES.
4385                               ;LOOP IF SOME LINES NOT DONE.
4386 016740      60$:  PASS
4387 016740 004736      JSR    PC,@(SP)+ ;RESTORE GPRS.
;RETURN TO PREG05 SUBRT.

```


CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 102
INTERRUPT SERVICE ROUTINE - CLKINT -

4389
4390
4391
4392
4393
4394
4395
4396
4397
4398
4399
4400
4401
4402
4403
4404
4405
4406
4407
4408
4409
4410
4411
4412
4413
4414
4415
4416
4417
4418
4419
4420
4421
4422
4423
4424
4425

016744 005737 002322
016750 001402
016752 005337 002322
016756 005737 002324
016762 001402
016764 005337 002324
016770 005337 002326
016774 001006
016776 013737 002330 002326
017004 010046
017006
017006 104422
017010 012600
017012 000002

```
.SBTTL INTERRUPT SERVICE ROUTINE - CLKINT -
:++ *****
:* THIS ROUTINE IS EXECUTED CLKHRZ TIMES PER SECOND. IT DECREMENTS THE
:* TWO TIMER COUNTERS DOWN TO ZERO.
:*
:* INPUTS: TIMER1 - TIMER COUNTER #1.
:*          TIMER2 - TIMER COUNTER #2.
:*          TIMER3 - TIMER COUNTER FOR CALL OF BREAK MACRO.
:*
:* OUTPUTS: THE 2 TIMER COUNTERS ARE DECREMENTED IF THEY ARE NOT ZERO.
:*
:* CALLING SEQUENCE: PUT #CLKINT IN THE CLOCK INTERRUPT VECTOR SLOT.
:*                   PUT THE DESIRED TIME PERIOD (SECONDS TIMES CLKHRZ) IN
:*                   EITHER TIMER1 OR TIMER2 AND POLL THE RESPECTIVE TIMER
:*                   COUNTER TO DETECT ITS GOING TO 0 ON TIME-OUT.
:*
:* COMMENTS: THE 2 COUNTERS WILL NOT WRAPAROUND BUT WILL STOP AT 0. THIS
:*            ALLOWS THE DETECTION OF A TIME-OUT ANY TIME AFTER THE TIME-OUT
:*            HAS OCCURRED UNTIL THE TIMER COUNTER IS SET TO ANOTHER VALUE.
:*
:* SUBORDINATE ROUTINES CALLED: NONE.
:-- *****
CLKINT:: TST  TIMER1      ;CHECK FOR TIMER1 AT ZERO.
        BEQ  2$          ;BRANCH TO LEAVE IT AT ZERO IF IT IS ZERO.
        DEC  TIMER1      ;DECREMENT TIME COUNT.
2$:     TST  TIMER2      ;CHECK FOR TIMER2 AT ZERO.
        BEQ  4$          ;BRANCH TO LEAVE IT ALONE IF IT'S ALREADY ZERO.
        DEC  TIMER2      ;DECREMENT TIME COUNT.
4$:     DEC  TIMER3      ;DECREMENT THE BREAK COUNT.
        BNE  60$         ;EXIT IF NOT TIME TO CALL BREAK.
        MOV  BCOUNT,TIMER3 ;SET UP TIME TILL NEXT BREAK.
        MOV  R0,-(SP)    ;SAVE CONTENTS OF R0 FROM BREAK MACRO.
        BREAK           ;CHECK FOR OPERATOR CONTROL/C. TRAP C$BRK
60$:   MOV  (SP)+,R0    ;RESTORE CONTENTS OF R0.
        RTI
```


CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 105
PROTECTION TABLE

.SBTTL PROTECTION TABLE

:++
: THIS TABLE IS USED BY THE RUNTIME SERVICES
: TO PROTECT THE LOAD MEDIA.
:--

4476
4477
4478
4479
4480
4481
4482
4483
4484
4485
4486
4487
4488
4489
4490
4491
4492

017044
017044

017044 177777
017046 177777
017050 177777

017052

BGNPROT

L\$PROT::

-1
-1
-1

:OFFSET INTO P-TABLE FOR CSR ADDRESS
:OFFSET INTO P-TABLE FOR MASSBUS ADDRESS
:OFFSET INTO P-TABLE FOR DRIVE NUMBER

ENDPROT

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 106
PROTECTION TABLE

4493
4494
4495
4496
4497
4498
4499
4500
4501
4502
4503
4504
4505
4506
4507 017052
4508 017052
4509
4510 017052
4511 017052 012700 000040
4512 017056 104447
4513 017060
4514 017060 103416
4515
4516 017062
4517 017062 012700 000037
4518 017066 104447
4519 017070
4520 017070 103555
4521
4522 017072
4523 017072 012700 000035
4524 017076 104447
4525 017100
4526 017100 103554
4527
4528 017102
4529 017102 012700 000036
4530 017106 104447
4531 017110
4532 017110 103160
4533 017112 000137 017632
4534 017116
4535 017116
4536 017116 104433
4537
4538
4539
4540 017120
4541 017120 012700 000114
4542 017124 104462
4543 017126 010001
4544 017130 012137 002312
4545 017134 012137 002314
4546 017140 012137 002316
4547 017144 012137 002320
4548 017150 023727 002320 000062

.SBTTL INITIALIZE SECTION

```

:++
:*****
:* THIS SECTION CONTAINS THE CODE WHICH IS PERFORMED AT THE BEGINNING OF
:* EACH PASS OR AFTER A CONTINUE COMMAND.
:* THIS CODE PERFORMS THE FOLLOWING ACTIONS:
:*
:* MOVES THE INFORMATION HELD IN THE HARDWARE P-TABLE INTO THE GLOBAL
:* DATA AREA.
:*****
:--

```

BGNINIT

LSINIT::

```

;SEE IF PROGRAM JUST STARTED, BR IF YES
  READEF #EF.START
                                MOV #EF.START,RO
                                TRAP CSREFG
  BCOMPLETE NEWSTA
                                BCS NEWSTA
;SEE IF PROGRAM JUST RESTARTED, BR IF YES
  READEF #EF.RESTART
                                MOV #EF.RESTART,RO
                                TRAP CSREFG
  BCOMPLETE NEWRES
                                BCS NEWRES
;SEE IF THIS IS A NEW PASS, BR IF YES
  READEF #EF.NEW
                                MOV #EF.NEW,RO
                                TRAP CSREFG
  BCOMPLETE NEWPAS
                                BCS NEWPAS
;SEE IF PROGRAM WAS JUST CONTINUED
  READEF #EF.CONTINUE
                                MOV #EF.CONTINUE,RO
                                TRAP CSREFG
  BNCOMPLETE GETPRM
                                BCC GETPRM
  JMP ENDIT
NEWSTA:
  BRESET ;RESET THE BUS TO PREVENT ILLEGAL INTERRUPTS.
                                TRAP CSRESET
:++
: SET UP FOR LINE TIME CLOCK INTERRUPTS.
:--
  CLOCK L,R1 ;GET THE CLOCK PARAMETERS.
                                MOV #'L,RO
                                TRAP CSCLK
                                MOV RO,R1
  MOV (R1)+,CLKCSR ;STORE CLOCK CSR ADDRESS.
  MOV (R1)+,CLKBRL ;STORE CLOCK BUS REQ INT LEVEL.
  MOV (R1)+,CLKVEC ;STORE CLOCK INTERRUPT VECTOR.
  MOV (R1)+,CLKHRZ ;STORE CLOCK FREQUENCY.
  CMP CLKHRZ,#50. ;TEST FOR 50HZ LINE FREQUENCY.

```

CVDHAAO DHV-11 FUNC TST PART1 MACY11 30A(1052) 12-JUL-83 10:52 PAGE 107
 CVDHAA.P11 12-JUL-83 00:42 INITIALIZE SECTION

```

4549 017156 001004          BNE      2$          ;BRANCH IF CLOCK IS NOT 50HZ.
4550 017160 012737 000024 002332  MOV     #20.,MSTICK ;INDICATE 20MS PER CLOCK TICK.
4551 017166 000403          BR       4$
4552 017170 012737 000021 002332 2$:  MOV     #17.,MSTICK ;INDICATE 17 MS PER CLOCK TICK.
4553 017176          4$:  SETVEC  CLKVEC,#CLKINT,PRI06 ;INITIALIZE CLOCK INTERRUPT VECTOR.
4554 017176 013746 000300          MOV     PRI06,-(SP)
4555 017202 012746 016744          MOV     #CLKINT,-(SP)
4556 017206 013746 002316          MOV     CLKVEC,-(SP)
4557 017212 012746 000003          MOV     #3,-(SP)
4558 017216 104437          TRAP   C$$VEC
4559 017220 062706 000010          ADD     #10,SP
4560 017224 013700 002320          MOV     CLKHRZ,RO ;INITIALIZE THE BREAK COUNT
4561 017230 006300          ASL     RO          ; TO CAUSE A BREAK
4562 017232 010037 002330          MOV     RO,BCOUNT ; EVERY 2 SECONDS.
4563 017236          SETPRI #PRI05      ;ALLOW CLOCK INTERRUPTS DISABLE OTHERS.
4564 017236 012700 000240          MOV     #PRI05,RO
4565 017242 104441          TRAP   C$$PRI
4566
4567 :+
4568 :+ ENABLE THE LINE TIME CLOCK (LTC) CHECKING TO MAKE SURE THAT THE CSR
4569 :+ IS ACCESSABLE.
4570 :+ FIRST SET UP TO CATCH ANY 004 TRAPS WHICH OCCUR:
4571 :+
4571 017244 013737 000004 002302  MOV     4,TP4VEC ;SAVE THE EXISTING 004 TRAP VECTOR.
4572 017252 012737 017014 000004  MOV     #TP4RTN,4 ;SET 004 TRAP VECTOR TO OUR SERVICE RTN ADR.
4573 :+
4574 :+ ENABLE LTC CHECKING FOR 004 TRAP IN CASE CSR IS NOT THERE.
4575 :+
4576 017260 005037 002304          CLR     TP4FLG ;CLEAR THE 004 TRAP FLAG.
4577 017264 012737 000100 002306  MOV     #BIT6,WORD1 ;SET UP TO SET BIT6 OF THE LTC CSR.
4578 017272 012700 002306  MOV     #WORD1,RO ;SET UP WORD1 AS THE CKTRAP MOVE SOURCE.
4579 017276 013701 002312  MOV     CLKCSR,R1 ;SET UP LTC CSR AS DESTINATION FOR CKTRAP MOVE.
4580 017302 004737 013776  JSR     PC,CKTRAP ;MOVE AND CHECK FOR TRAP.
4581 017306 013737 002302 000004  MOV     TP4VEC,4 ;RESTORE THE NORMAL 004 TRAP VECTOR.
4582 017314 103403          BCS     6$          ;IF NO TRAP, LTC IS THERE SO CONTINUE.
4583 017316 005037 002320  CLR     CLKHRZ ;CLEAR LTC FREQUENCY WORD TO INDICATE NO LTC.
4584 017322 000402          BR      8$          ;BYPASS THE FOLLOWING CALIBRATION PROCEDURES.
4585
4586 :+
4587 :+ CALIBRATE THE DELAY ROUTINE MILLI-SECOND DELAY COUNT VALUE.
4588 017324 004737 013552 6$:  JSR     PC,CALMSL
4589 :+
4590 :+ CHECK FOR MEMMORY MANAGEMENT PRESENT ON THIS MACHINE.
4591 :+ IF MEM MGT IS PRESENT, DISABLE IT.
4592 :+
4593 017330 013737 000004 002302 8$:  MOV     4,TP4VEC ;SAVE THE EXISTING 004 TRAP VECTOR.
4594 017336 012737 017014 000004  MOV     #TP4RTN,4 ;SET 004 TRAP VECTOR TO OUR SERVICE RTN ADR.
4595 017344 005037 002304          CLR     TP4FLG ;CLEAR THE 004 TRAP FLAG.
4596 017350 005037 002306  CLR     WORD1 ;PREPARE TO CLEAR THE MEM MGT SRO REGISTER.
4597 017354 012700 002306  MOV     #WORD1,RO ;SELECT CLEARED WORD AS CKTRAP RTN SOURCE.
4598 017360 013701 002336  MOV     MMSRO,R1 ;SELECT MEM MGT SRO REGISTER AS DESTINATION.
4599 017364 005037 002340  CLR     MMPRES ;INDICATE NO MEM MGT PRESENT IN CASE IT ISN'T.
4600 017370 005037 002342  CLR     MMENAB ;INDICATE MEM MGT IS NOT ENABLED.
4601 017374 004737 013776  JSR     PC,CKTRAP ;CLEAR THE MEM MGT SRO REG AND CHECK FOR TRAP.
4602 017400 013737 002302 000004  MOV     TP4VEC,4 ;RESTORE THE NORMAL 004 TRAP VECTOR.
4603 017406 103003          BCC     10$         ;SKIP INDICATING MEM MGT PRESENT IF IT ISN'T.
4604 017410 012737 000001 002340  MOV     #1,MMPRES ;INDICATE THAT MEM MGT IS PRESENT.

```

CVDHAAO DHV-11 FUNC TST PART1 MACY11 30A(1052) 12-JUL-83 10:52 PAGE 108
 CVDHAA.P11 12-JUL-83 00:42 INITIALIZE SECTION

```

4605 017416 005037 002300 10$: CLR PASCNT ;CLR COUNTER USED IN REPORTING ROM VERSION #.
4606 017422 000403 BR NEWPAS
4607
4608 017424 NEWRES: BRESET ;AVOID ILLEGAL INTERRUPT PROBLEMS.
4609 017424 104433 TRAP CSRESET
4610 017426 005037 002300 CLR PASCNT ;CLR COUNTER USED IN REPORTING ROM VERSION #.
4611 017432 NEWPAS:
4612 017432 012737 177777 002212 MOV #-1,UNITN ;RESET LOGICAL DEVICE TO -1
4613
4614 ;+
4615 ; INCREMENT THE PASS COUNTER, CORRECT FOR ANY OVERFLOW.
4616 ; THIS COUNTER IS USED IN THE ROM VERSION TEST.
4617 017440 005237 002300 INC PASCNT ;INCREMENT THE PASS COUNTER.
4618 017444 001002 BNE GETPRM ;BRANCH IF WE HAVE NOT YET! OVERFLOWED.
4619 017446 005337 002300 DEC PASCNT ;SET PASS COUNT TO 177777 OCTAL.
4620
4621 ; GET THE HARDWARE PARAMETERS FOR THIS UNIT.
4622 017452 GETPRM:
4623 017452 005237 002212 INC UNITN ;INCREMENT LOGICAL DEVICE NUMBER
4624 017456 023737 002212 002012 CMP UNITN,L$UNIT ;SEE IF MAXIMUM UNIT NO. EXCEEDED
4625 017464 002362 BGE NEWPAS ;BR IF YES
4626
4627 017466 GPHARD UNITN,R1 ;GET P-TABLE POINTER INTO R1
4628 017466 013700 002212 MOV UNITN,R0
4629 017472 104442 TRAP CS$GPHRD
4630 017474 010001 MOV R0,R1
4631 017476 BCOMPLETE 30$ ;BR IF DEVICE AVAILABLE
4632 017476 103401 BCS 30$
4633 017500 000764 BR GETPRM ;SKIP THIS DEVICE
4634
4635
4636 ;***** HARDWARE PARAMETER MOVING CODE *****
4637 017502 012137 002214 30$: MOV (R1)+,CSRA ;STORE DHV-11 CSR ADDRESS IN DEV.REG.ADDRESS TABLE
4638 017506 012137 002210 MOV (R1)+,ACTLNS ;STORE THE ACTIVE LINES BIT MAP.
4639
4640 ;+
4641 ; CALCULATE DEVICE REGISTER ADDRESSES,AND PUT THEM IN THE
4642 ; DEVICE REGISTER ADDRESS TABLE.
4643 017512 013701 002214 MOV CSRA,R1 ;COPY CSR ADDRESS
4644 017516 005201 INC R1 ;INCREMENT CSR ADDRESS
4645 017520 005201 INC R1 ; COPY BY 2.
4646 017522 012703 000007 MOV #7,R3 ;SET UP REGISTER COUNT
4647 017526 012702 002216 MOV #RBUFA,R2 ;GET LOCATION WHERE RBUF ADDRESS GOES IN TABLE
4648 017532 010122 12$: MOV R1,(R2)+ ;STORE REGISTER ADDRESS IN TABLE
4649 017534 005201 INC R1 ;INCREMENT REGISTER ADDRESS
4650 017536 005201 INC R1 ; BY 2, FOR THE NEXT DEVICE REGISTER.
4651 017540 005303 DEC R3 ;DECREMENT REGISTER COUNT
4652 017542 001373 BNE 12$ ;LOOP IF NOT DONE
4653
4654 ;+
4655 ; INITIALISE THE BMP CODE QUEUE.
4656 017544 012700 002464 MOV #BMPCQB,R0 ;GET THE START ADDRESS OF THE QUEUE.
4657 017550 012701 002664 MOV #BMPCQE,R1 ;GET THE END ADDRESS OF THE QUEUE.
4658 017554 010037 002462 MOV R0,BMPCQP ;SET THE POINTER TO THE START OF THE QUEUE.
4659 017560 005020 14$: CLR (R0)+ ;CLEAR OUT THE CONTENTS OF THE QUEUE.
4660 017562 020001 CMP R0,R1 ;CHECK IF END OF QUEUE HAS BEEN REACHED.

```

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 109
INITIALIZE SECTION

```

4661 017564 103775           BLO      14$           ;LOOP IF NOT ALL DONE.
4662
4663           :+      REPORT THE UNIT NUMBER IF THE SOFTWARE P-TABLE QUESTION WAS ANSWERED YES,
4664           :      AND THE MAXIMUM UNIT NUMBER IS GREATER THAN 1.
4665           :-
4666 017566 032737 000020 002204    BIT      #BIT4,OPTION    ;CHECK IF THE QUESTION WAS ANSWERED YES.
4667 017574 001416                    BEQ      16$             ;SKIP REPORTING UNIT NUMBER IF IT IS DISABLED.
4668 017576 023727 002012 000001    CMP      LSUNIT,#1      ;CHECK MAXIMUM NUMBER OF UNITS SELECTED.
4669 017604 003412                    BLE      16$             ;DO NOT REPORT UNIT NUMBER IF MAX NUMBER < 1.
4670 017606                    PRINTF   #MFUNIT,UNITN   ;REPORT UNIT NUMBER.
4671 017606 013746 002212                    MOV      UNITN,-(SP)
4672 017612 012746 002772                    MOV      #MFUNIT,-(SP)
4673 017616 012746 000002                    MOV      #2,-(SP)
4674 017622 010600                    MOV      SP,R0
4675 017624 104417                    TRAP    C$PNTF
4676 017626 062706 000006                    ADD     #6,SP
4677 017632
4678
4679 017632 005037 002310    16$:
4680           ENDIT: CLR      CTRLCF           ;CLR THE CTRL-C TEST ABORT FLAG.
4681           :+      SET THE PROCESSOR PRIORITY TO ALLOW LTC INTERRUPTS BUT NOT OTHERS.
4682           :-
4683 017636                    SETPRI   #PRI07           ;SET PROCESSOR PRIORITY TO 5.
4684 017636 012700 000340                    MOV      #PRI07,R0
4685 017642 104441                    TRAP    C$SPRI
4686
4687 017644                    ENDINIT
4688 017644
4689 017644 104411                    L10016: TRAP    C$INIT

```

CVDHAAO DHV-11 FUNC TST PART1
 CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 110
 INITIALIZE SECTION

4690
 4691
 4692
 4693
 4694
 4695
 4696
 4697
 4698
 4699
 4700
 4701
 4702
 4703
 4704
 4705
 4706
 4707
 4708

017646
 017646

 017646
 017646
 017646 104461

.SBTTL AUTODROP SECTION

```

:++
: THIS CODE IS EXECUTED IMMEDIATELY AFTER THE INITIALIZE CODE IF
: THE 'ADR' FLAG WAS SET. THE UNIT(S) UNDER TEST ARE CHECKED TO
: SEE IF THEY WILL RESPOND. THOSE THAT DON'T ARE IMMEDIATELY
: DROPPED FROM TESTING.
:--

```

BGNAUTO

L\$AUTO::

ENDAUTO

L10017: TRAP C\$AUTO

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 111
AUTODROP SECTION

4709
4710
4711
4712
4713
4714
4715
4716
4717
4718 017650
4719 017650
4720
4721 017650 005737 002310
4722 017654 001401
4723 017656
4724 017656 104433
4725 017660
4726 017660
4727 017660 104432
4728 017662 000002
4729
4730
4731
4732
4733 017664
4734 017664
4735 017664 104412

.SBTTL CLEANUP CODING SECTION

;++
: THE CLEANUP CODING SECTION CONTAINS THE CODING THAT IS PERFORMED
: AFTER THE HARDWARE TESTS HAVE BEEN PERFORMED.
:--

BGNCLN

L\$CLEAN::

TST CTRLCF
BEQ 2\$
BRESET

:DID WE GET HERE BY CTRL-C FROM TEST?
:CTRL-C FROM TEST? NO, SKIP BUS RESET.
:YES, CLR ANY DMAS OR OUTSTANDING INTERRUPTS.
TRAP C\$RESET

2\$:

EXIT CLN

TRAP C\$EXIT
.WORD L10020-

.EVEN

ENDCLN

L10020:
TRAP C\$CLEAN

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 112
CLEANUP CODING SECTION

4736
4737
4738
4739
4740
4741
4742
4743
4744
4745
4746
4747
4748
4749
4750
4751
4752
4753
4754
4755
4756
4757
4758
4759
4760
4761
4762
4763
4764
4765
4766
4767
4768
4769
4770
4771
4772
4773
4774

017666
017666
017666
017666 010046
017670 012746 017712
017674 012746 000002
017700 010600
017702 104417
017704 062706 000006
017710 000427

017712 040445 052440 044516
017720 022524 033104 040445
017726 042040 047522 050120
017734 042105 043040 047522
017742 020115 052506 052122
017750 042510 020122 042524
017756 052123 047111 027107
017764 047045 000
017770
017770
017770 000167
017772 000000

017774
017774
017774 104453

.SBTTL DROP UNIT SECTION

:++
: THE DROP-UNIT SECTION CONTAINS THE CODING THAT CAUSES A DEVICE
: TO NO LONGER BE TESTED.
:--

BGNDU

PRINTF #DROP,RO

;REPORT UNIT THAT HAS BEEN DROPPED.

L\$DU::

MOV RO,-(SP)
MOV #DROP,-(SP)
MOV #2,-(SP)
MOV SP,RO
TRAP C\$PNTF
ADD #6,SP

BR EDROP

;BRANCH AROUND THE MESSAGE.

DROP: .ASCIZ/%A UNIT%D6%A DROPPED FROM FURTHER TESTING.%N/

EDROP: .EVEN

EXIT DU

.WORD JSJMP
.WORD L10021-2-

ENDDU

L10021:

TRAP C\$DU

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 113
DROP UNIT SECTION

4775
4776
4777
4778
4779
4780
4781
4782
4783
4784
4785
4786
4787
4788
4789
4790
4791
4792
4793
4794
4795
4796
4797

.SBTTL ADD UNIT SECTION

:+
: THE ADD-UNIT SECTION CONTAINS ANY CODE THE PROGRAMMER WISHES
: TO BE EXECUTED IN CONJUNCTION WITH THE ADDING OF A UNIT BACK
: TO THE TEST CYCLE.
:--

017776
017776
017776
017776 000167
020000 000000

020002
020002
020002 104452

BGNAU
EXIT AU

.EVEN
ENDAU

LSAU::

.WORD JSJMP
.WORD L10022-2-

L10022: TRAP CSAU

CVD
CVD

.....

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 114
HARDWARE TEST - ADRA -

4798
4799
4800
4801
4802
4803
4804
4805
4806
4807
4808
4809
4810
4811
4812
4813
4814
4815
4816
4817
4818
4819
4820
4821
4822
4823
4824
4825
4826
4827
4828
4829
4830
4831
4832
4833
4834
4835
4836
4837
4838
4839
4840
4841
4842
4843
4844
4845
4846
4847
4848
4849
4850
4851
4852
4853

020004
020004
000001
020004 012737 000001 002274
020012 012737 177777 002310

020020 013737 000004 002302
020026 012737 017014 000004
020034 005005

020036 005004

020040 005037 002304
020044 013700 002214
020050 012701 020264
020054 004737 013776
020060 103402
020062 052705 100001
020066 042737 000017 020264
020074 050437 020264
020100 010100
020102 013701 002214
020106 004737 013776
020112 103403
020114 052705 100002
020120 000440

020122 012702 000010
020126 013737 002214 020262
020134 012700 020262
020140 012701 020264

```
.SBTTL HARDWARE TEST - ADRA -
:++
:*****
:* - REGISTER ADDRESS TEST -
:*
:* THIS TEST VERIFIES THAT THE Q-BUS CAN READ AND WRITE TO THE DHV11
:* DEVICE REGISTERS. IF THE DHV11 DOES NOT RESPOND TO THE ACCESS
:* ATTEMPTS (IF THE DHV11 IS AT THE WRONG ADDRESS, FOR EXAMPLE) THE
:* 004 BUS TIME-OUT TRAP IS DETECTED BY THIS ROUTINE AND AN ERROR
:* IS REPORTED.
:*****
:--

BGNTST
T1::
TNUM == 1 ;THIS TEST MUST ALWAYS BE INCLUDED AS TEST 1.
MOV #TNUM,TSTNUM ;SET THE TEST NUMBER TO 1.
MOV #-1,CTRLCF ;INDICATE THAT WE ARE IN A TEST.

:+ SET UP TO CATCH ANY 004 TRAPS WHICH OCCUR:
:-
MOV 4,TP4VEC ;SAVE THE EXISTING 004 TRAP VECTOR.
MOV #TP4RTN,4 ;SET 004 TRAP VECTOR TO OUR SERVICE RTN ADR.
CLR R5 ;CLEAR THE ERROR FLAGS.

:+ SET UP FOR THE INITIAL ITERATION OF THE TEST LOOP:
:-
CLR R4 ;CLEAR THE LINE COUNTER.

:+ HERE BEGINS THE LOOP TO TEST THE REGISTERS FOR A LINE.
:+ FIRST TEST THE CSR AND SET THE IND.ADR.REG (I.A.R) FIELD.
:-
2$: CLR TP4FLG ;CLEAR THE 004 TRAP FLAG.
MOV CSRA,R0 ;SET UP CSR AS THE CKTRAP MOVE SOURCE.
MOV #52$,R1 ;SET UP DESTINATION LOCATION FOR CKTRAP MOVE.
JSR PC,CKTRAP ;MOVE AND CHECK FOR TRAP.
BCS 4$ ;IF NO TRAP, BYPASS ERROR.
BIS #100001,R5 ;SET FATAL READ ERROR FLAGS.
4$: BIC #17,52$ ;CLEAR THE I.A.R FIELD OF THE CSR DATA.
BIS R4,52$ ;OR IN THE LINE COUNTER TO THE I.A.R FIELD.
MOV R1,R0 ;USE OLD DESTINATION FOR SOURCE OF CKTRAP MOVE.
MOV CSRA,R1 ;SET UP CSR AS THE CKTRAP MOVE DESTINATION.
JSR PC,CKTRAP ;MOVE AND CHECK FOR TRAP.
BCS 6$ ;IF NO TRAP, BYPASS ERROR.
BIS #100002,R5 ;SET FATAL WRITE ERROR FLAGS.
BR 40$ ;EXIT AND REPORT FATAL ERROR.

:+ NOW, WE TEST EACH REGISTER FOR THIS LINE.
:-
6$: MOV #10,R2 ;INIT REGISTER COUNTER TO 8.
MOV CSRA,50$ ;INITIALIZE THE REGISTER POINTER.
8$: MOV #50$,R0 ;SET UP REGISTER AS THE SOURCE FOR CKTRAP MOVE.
MOV #52$,R1 ;SET UP LOCAL STORAGE AS THE DES FOR CKTRAP.
```

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 115
HARDWARE TEST - ADRA -

```

4854 020144 004737 013776      JSR    PC,CKTRAP      ;PERFORM THE MOVE, CHECK FOR TRAP.
4855 020150 103402              BCS    10$            ;IF NO TRAP, BYPASS THE SETTING OF ERROR FLAGS.
4856 020152 052705 100001      BIS    #100001,R5     ;SET FATAL READ ERROR FLAGS.
4857 020156 010100      10$:  MOV    R1,R0      ;USE OLD DEST AS SRC FOR CKTRAP MOVE.
4858 020160 012701 020262      MOV    #50$,R1       ;SET UP REGISTER AS THE DEST FOR CKTRAP MOVE.
4859 020164 004737 013776      JSR    PC,CKTRAP     ;PERFORM THE MOVE, CHECK FOR TRAP.
4860 020170 103402              BCS    12$            ;IF NO TRAP, BYPASS THE SETTING OF ERROR FLAGS.
4861 020172 052705 100002      BIS    #100002,R5     ;SET FATAL WRITE ERROR FLAGS.
4862 020176 005237 020262      12$:  INC    50$      ;INCREMENT THE REGISTER
4863 020202 005237 020262      INC    50$           ; POINTER BY 2.
4864 020206 005302              DEC    R2            ;COUNT THE REGISTER.
4865 020210 001351              BNE    8$            ;LOOP TO TEST THE NEXT REGISTER ADDRESS.
4866
4867
4868      ;+ NOW WE SET UP TO TEST THE NEXT LINE, OR TO EXIT IF WE ARE DONE.
4869      ;-
4870 020212 005204              INC    R4            ;INCREMENT THE LINE COUNTER.
4871 020214 020427 000010      CMP    R4,#NUMLNS    ;COMPARE LINE COUNTER AGAINST NUMBER OF LINES.
4872 020220 002707              BLT    2$            ;LOOP TO TEST THE NEXT LINE IF WE'RE NOT DONE.
4873
4874
4875      ;+ DONE CHECKING DEVICE REGISTER ADDRESSES.
4876      ;- REPORT ANY ERRORS AND EXIT.
4877
4878 020222 013737 002302 000004 40$:  MOV    TP4VEC,4      ;RESTORE THE NORMAL 004 TRAP VECTOR.
4879 020230 005705              TST    R5            ;CHECK THE ERROR FLAGS.
4880 020232 100015              BPL    60$           ;EXIT ROUTINE IF NO ERRORS.
4881      ; REPORT 'DEVICE REGISTER ACCESS ERRORS'
4882 020234              ERRDF 101,EM0103,ER0101; >>>> ERROR #101 <<<<<.
4883 020234 104455              TRAP  C$ERDF
4884 020236 000145              .WORD 101
4885 020240 004572              .WORD EM0103
4886 020242 012176              .WORD ER0101
4887
4888 020244              DODU  UNITN         ;DROP THIS UNIT FROM FUTHER TESTING.
4889 020244 013700 002212      MOV    UNITN,R0      ;
4890 020250 104451              TRAP  C$DODU
4891 020252 005037 002310      CLR    CTRLCF        ;INDICATE NO CTRL-C ABORT FROM TEST.
4892 020256              DOCLN              ;ABORT THIS SUB PASS.
4893 020256 104444              TRAP  C$DCLN
4894 020260 000402              BR    60$            ;
4895
4896      ;+ LOCAL STORAGE.
4897      ;-
4898 020262 000000      50$:  .WORD 0          ;STORAGE FOR THE SOURCE OR DEST OF THE CKTRAP MOVE.
4899 020264 000000      52$:  .WORD 0          ;STORAGE FOR THE SOURCE OR DEST OF THE CKTRAP MOVE.
4900 020266 005037 002310      60$:  CLR    CTRLCF    ;INDICATE THAT WE ARE NOT WITHIN A TEST.
4901 020272
4902 020272
4903 020272 104401              L10023: TRAP  C$ETST

```

```

4904 .SBTTL HARDWARE TEST - MRSTA -
4905 :+ *****
4906 :* - MASTER RESET WITH SELFTEST TEST -
4907 :* THIS TEST VERIFIES THAT THE MASTER RESET BIT WILL CLEAR AFTER A DEVICE
4908 :* RESET AND THE PERFORMANCE OF THE DUT ROM BASED SELFTEST.
4909 :*
4910 :-- *****
4911 020274 BGNSTST
4912 020274
4913 000002 TNUM == TNUM + 1 ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
4914 020274 012737 000002 002274 MOV #TNUM,TSTNUM ;SET UP THE TEST NUMBER. (2)
4915 020302 012737 177777 002310 MOV #-1,CTRLCF ;INDICATE THAT WE ARE IN A TEST.
4916 020310 SETPRI #PRI05 ;ALLOW LTC INTERRUPTS.
4917 020310 012700 000240 MOV #PRI05,R0
4918 020314 104441 TRAP C$SPRI
4919 020316 012737 000001 002664 MOV #1,ERRTYP ;SET ERROR TYPE AS FATAL IN ERROR TABLE.
4920 020324 012737 004630 002670 MOV #EM0201,ERRMSG ;SET ERROR MESSAGE ADDRESS IN ERROR TABLE.
4921 020332 012737 012514 002672 MOV #ER0201,ERRBLK ;SET ERROR ROUTINE ADDRESS IN ERROR TABLE.
4922 :+
4923 : WAIT UP TO 5 SECONDS FOR THE DUT MASTER RESET BIT TO CLEAR.
4924 :--
4925 020340 012701 011610 MOV #5000.,R1 ;TIME-OUT VALUE IS 5.0 SECONDS.
4926 020344 012702 000040 MOV #BIT05,R2 ;WAITING FOR MASTER RESET BIT.
4927 020350 005003 CLR R3 ;WAITING FOR BIT TO CLEAR.
4928 020352 013704 002214 MOV CSRA,R4 ;BIT IS IN THE DUT'S CSR.
4929 020356 004737 014166 JSR PC,MSLGET ;WAIT FOR DUT CSR MR BIT TO CLEAR.
4930 020362 103410 BCS 2$ ;SKIP TO RESET DUT IF MR CLEAR.
4931 :+
4932 : DUT MASTER RESET BIT DID NOT GO CLEAR. DEVICE MAY BE STUCK IN SOME
4933 : ODD STATE. TRY TO RESET DEVICE WITH A BUS RESET.
4934 :--
4935 020364 BRESET ;NO, TRY TO JOG DEVICE WITH BUS RESET.
4936 020364 104433 TRAP C$RESET
4937 020366 004737 016100 JSR PC,SKPSTS ;TRY TO SKIP THE SELFTEST.
4938 020372 012701 011610 MOV #5000.,R1 ;TIME-OUT VALUE IS 5.0 SECONDS.
4939 020376 004737 014166 JSR PC,MSLGET ;WAIT FOR DUT CSR MR BIT TO CLEAR.
4940 020402 103016 BCC 4$ ;GO REPORT ERROR IF MR BIT DID NOT CLEAR.
4941 :+
4942 : SET THE MASTER RESET BIT AND VERIFY THAT IT CLEARS WITHIN THE PROPER TIME.
4943 :--
4944 020404 012701 011610 2$: MOV #5000.,R1 ;TIME-OUT VALUE IS 5.0 SECONDS.
4945 020410 010214 MOV R2,(R4) ;SET THE DUT MASTER RESET BIT.
4946 020412 004737 014166 JSR PC,MSLGET ;WAIT FOR DUT CSR MR BIT TO CLEAR.
4947 020416 103010 BCC 4$ ;GO REPORT ERROR IF MR BIT DID NOT CLEAR.
4948 020420 012702 011610 MOV #5000.,R2
4949 020424 160102 SUB R1,R2 ;CALCULATE # OF MS FOR MR TO CLEAR.
4950 020426 001413 BEQ 6$ ;GO REPORT ERROR IF MR CLEAR IMMEDIATELY.
4951 020430 020227 000764 CMP R2,#500.
4952 020434 002417 BLT 8$ ;GO REPORT ERROR IF MR CLEAR IN < 1/2 SECOND.
4953 020436 000424 BR 60$ ;EXIT THE TEST WITHOUT ERROR.
4954 :+
4955 : ERROR REPORTS:
4956 :--
4957 : ;REPORT MR BIT WOULD NOT CLEAR AFTER A DUT RESET.
4958 020440 012737 000311 002666 4$: MOV #201.,ERRNBR ;SET THE ERROR NUMBER IN ERROR TABLE.
4959 020446 012701 004676 MOV #EM0202,R1 ;SELECT ERROR MESSAGE.

```


CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 118
HARDWARE TEST - MRSSTA -

4984
4985
4986
4987
4988
4989
4990
4991 020524
4992 020524
4993 000003
4994 020524 012737 000003 002274
4995 020532 012737 177777 002310
4996 020540
4997 020540 012700 000240
4998 020544 104441
4999 020546 012737 000001 002664
5000 020554 012737 005373 002670
5001 020562 012737 012514 002672
5002
5003
5004
5005 020570 012701 011610
5006 020574 012702 000040
5007 020600 005003
5008 020602 013704 002214
5009 020606 004737 014166
5010 020612 103410
5011
5012
5013
5014
5015 020614
5016 020614 104433
5017 020616 004737 016100
5018 020622 012701 011610
5019 020626 004737 014166
5020 020632 103024
5021
5022
5023
5024
5025 020634 012701 000310
5026 020640 010214
5027 020642 004737 016100
5028 020646 004737 014166
5029 020652 103007
5030 020654 012702 000310
5031 020660 160102
5032 020662 020227 000012
5033 020666 002415
5034 020670 000431
5035
5036
5037
5038 020672 012701 011300
5039 020676 004737 014166

```

.SBTTL  HARDWARE TEST          - MRSSTA -
:++ *****
: *          - MASTER RESET WITH SKIP SELFTEST TEST -
: *          THIS TEST VERIFIES THAT THE MASTER RESET BIT WILL CLEAR AFTER A DEVICE
: *          RESET AND THE SKIPPING OF THE DUT ROM BASED SELFTEST.
: *
:-- *****
      BGNST
:++
: *          T3::
: *          TNUM == TNUM + 1      ; INCREMENT THE ASSEMBLY TIME TEST COUNTER.
: *          MOV #TNUM,TSTNUM      ; SET UP THE TEST NUMBER. (3)
: *          MOV #-1,CTRLCF        ; INDICATE THAT WE ARE IN A TEST.
: *          SETPRI #PRI05         ; ALLOW LTC INTERRUPTS.
: *
: *          MOV #PRI05,RO         ;
: *          TRAP C$SPRI          ;
: *          MOV #1,ERRRTP         ; SET ERROR TYPE AS FATAL IN ERKOR TABLE.
: *          MOV #EM0301,ERRMSG    ; SET ERROR MESSAGE ADDRESS IN ERROR TABLE.
: *          MOV #ER0201,ERRBLK   ; SET ERROR ROUTINE ADDRESS IN ERROR TABLE.
: *
: *          WAIT UP TO 5 SECONDS FOR THE DUT MASTER RESET BIT TO CLEAR.
: *
: *          MOV #5000.,R1         ; TIME-OUT VALUE IS 5.0 SECONDS.
: *          MOV #BIT05,R2        ; WAITING FOR MASTER RESET BIT.
: *          CLR R3                ; WAITING FOR BIT TO CLEAR.
: *          MOV CSRA,R4           ; BIT IS IN THE DUT'S CSR.
: *          JSR PC,MSLGET         ; WAIT FOR DUT CSR MR BIT TO CLEAR.
: *          BCS 2$               ; SKIP TO RESET DUT IF MR CLEAR.
: *
: *          DUT MASTER RESET BIT DID NOT GO CLEAR. DEVICE MAY BE STUCK IN SOME
: *          ODD STATE. TRY TO RESET DEVICE WITH A BUS RESET.
: *
: *          BRESET                ; NO, TRY TO JOG DEVICE WITH BUS RESET.
: *          TRAP C$RESET         ;
: *          JSR PC,SKPSTS         ; TRY TO SKIP THE SELFTEST.
: *          MOV #5000.,R1         ; TIME-OUT VALUE IS 5.0 SECONDS.
: *          JSR PC,MSLGET         ; WAIT FOR DUT CSR MR BIT TO CLEAR.
: *          BCC 6$               ; GO REPORT ERROR IF MR BIT DID NOT CLEAR.
: *
: *          SET THE MASTER RESET BIT, TRY TO SKIP THE SELFTEST, AND VERIFY THAT THE
: *          MR BIT CLEARS WITHIN 1/5 SECOND.
: *
: *          2$: MOV #200.,R1       ; TIME-OUT VALUE IS 1/5 SECOND.
: *          MOV R2,(R4)          ; SET THE DUT MASTER RESET BIT.
: *          JSR PC,SKPSTS         ; TRY TO SKIP THE SELFTEST.
: *          JSR PC,MSLGET         ; WAIT FOR DUT CSR MR BIT TO CLEAR.
: *          BCC 4$               ; GO FIND OUT WHAT IS WRONG IF MR NOT CLEAR.
: *          MOV #200.,R2         ;
: *          SUB R1,R2            ; CALCULATE # OF MS FOR MR TO CLEAR.
: *          CMP R2,#10.          ;
: *          BLT 8$               ; GO REPORT ERROR IF MR CLEAR IN < 10 MS.
: *          BR 60$              ; EXIT THE TEST WITHOUT ERROR.
: *
: *          MR DID NOT CLEAR WITHIN 1/5 SECOND, SEE IF IT CLEARS WITHIN 5 SECONDS.
: *
: *          4$: MOV #4800.,R1     ; TIME-OUT VALUE IS 5 SECONDS MINUS 1/5 SECOND.
: *          JSR PC,MSLGET         ; WAIT FOR DUT_CSR_MR BIT TO CLEAR.

```

CVDHAAO DHV-11 FUNC TST PART1 MACY11 30A(1052) 12-JUL-83 10:52 PAGE 119
 CVDHAA.P11 12-JUL-83 00:42 HARDWARE TEST - MRSSTA -

```

5040 020702 103416          BCS 10$          ;GO REPORT ERROR IF MR CLEARED FINALLY.
5041
5042          ;+
5043          ;-
5044          ;REPORT MR BIT WOULD NOT CLEAR AFTER A DUT RESET.
5045 020704 012737 000455 002666 6$:  MOV #0301,ERRNBR ;SET THE ERROR NUMBER IN ERROR TABLE.
5046 020712 012701 004676          MOV #EM0202,R1 ;SELECT ERROR MESSAGE.
5047 020716          ERROR ;REPORT ERROR. >>>> ERROR #0301 <<<<<
5048 020716 104460          TRAP C$ERROR
5049 020720 000415          BR 60$          ;EXIT THE TEST.
5050
5051          ;REPORT MR BIT CLEAR WITHIN 10 MS AFTER DUT RESET.
5052 020722 012737 000456 002666 8$:  MOV #0302,ERRNBR ;SET THE ERROR NUMBER IN ERROR TABLE.
5053 020730 012701 005436          MOV #EM0302,R1 ;SELECT ERROR MESSAGE.
5054 020734          ERROR ;REPORT ERROR. >>>> ERROR #0302 <<<<<
5055 020734 104460          TRAP C$ERROR
5056 020736 000406          BR 60$          ;EXIT THE TEST.
5057
5058          ;REPORT MR CLEARED BETWEEN 1/5 SECOND AND 5 SECONDS OF DUT RESET.
5059 020740 012737 000457 002666 10$: MOV #0303,ERRNBR ;SET THE ERROR NUMBER IN ERROR TABLE.
5060 020746 012701 005576          MOV #EM0303,R1 ;SELECT ERROR MESSAGE.
5061 020752          ERROR ;REPORT ERROR. >>>> ERROR #0303 <<<<<
5062 020752 104460          TRAP C$ERROR
5063
5064 020754          60$:  SETPRI #PRI07          ;DISABLE ALL INTERRUPTS.
5065 020754 012700 000340          MOV #PRI07,RO
5066 020760 104441          TRAP C$SPRI
5067 020762 005037 002310          CLR CTRLCF          ;INDICATE THAT WE COMPLETED THE TEST.
5068 020766          ENDTST
5069 020766          L10025:
5070 020766 104401          TRAP C$SETST

```

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 120
HARDWARE TEST - RXCHRA -

```

5071 .SBTTL HARDWARE TEST - RXCHRA -
5072 :++ *****
5073 :* - RBUF REGISTER RX CHARACTER FIELD TEST -
5074 :* THIS TEST VERIFIES THAT THE RX CHARACTER FIELD OF THE DUT RBUF REGISTER
5075 :* APPEARS TO BE FUNCTIONING CORRECTLY. THIS TEST USES THE CODES WHICH
5076 :* SHOULD BE IN THE FIFO AFTER A BOARD RESET AND SKIP SELFTEST SEQUENCE.
5077 :*
5078 :-- *****
5079 020770 BGNTST
5080 020770
5081 020770
5082 020770 012700 000240
5083 020774 104441
5084 000004
5085 020776 012737 000004 002274
5086 021004 012737 177777 002310
5087 021012 012737 000001 002664
5088 021020 012737 005755 002670
5089 021026 012737 012514 002672
5090
5091 :+ SET THE DUT CSR MASTER RESET (MR) BIT, PERFORM THE SKIP SELFTEST SEQUENCE,
5092 :+ AND WAIT UP TO 5 SECONDS FOR THE MR BIT TO CLEAR.
5093 :--
5094 021034 012701 011610
5095 021040 012702 000040
5096 021044 005003
5097 021046 013704 002214
5098 021052 010214
5099 021054 004737 016100
5100 021060 004737 014166
5101 021064 103015
5102
5103 :+ READ 6 CHARACTERS FROM THE DUT AND VERIFY THAT THEY ARE VALID SELFTEST
5104 :+ CODES.
5105 :--
5106 021066 012400
5107 021070 012701 000006
5108 021074 011402
5109 021076 010200
5110 021100 042700 177476
5111 021104 020027 000201
5112 021110 001012
5113 021112 005301
5114 021114 001367
5115 021116 000415
5116
5117 :+ ERROR REPORTS:
5118 :+
5119 :--
5120 :+ ;REPORT MR BIT WOULD NOT CLEAR AFTER A DUT RESET.
5121 021120 012737 000621 002666 4$: MOV #0401,ERRNBR ;SET THE ERROR NUMBER IN ERROR TABLE.
5122 021126 012701 004676 MOV #EM0202,R1 ;SELECT ERROR MESSAGE.
5123 021132 ERROR ;REPORT ERROR. >>>> ERROR #0401 <<<<<
5124 021132 104460 TRAP C$ERROR
5125 021134 000406 BR 60$ ;EXIT THE TEST.
5126

```


CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 121
HARDWARE TEST - RXCHRA -

```

5127 ;REPORT IMPROPER CODE FOUND IN DUT RBUF AFTER RESET (SKIP SELFTEST).
5128 021136 012737 000622 002666 6$: MOV #0402,ERRNBR ;SET THE ERROR NUMBER IN ERROR TABLE.
5129 021144 012701 006024 MOV #EM0402,R1 ;SELECT ERROR MESSAGE.
5130 021150 ERROR ;REPORT ERROR. >>>> ERROR #0402 <<<<<
5131 021150 104460 TRAP C$ERROR
5132
5133 021152 60$: SETPRI #PRI07 ;DISABLE ALL INTERRUPTS.
5134 021152 012700 000340 MOV #PRI07,R0
5135 021156 104441 TRAP C$SPRI
5136 021160 005037 002310 CLR CTRLCF ;INDICATE THAT WE COMPLETED THE TEST.
5137 021164 ENDTST
5138 021164 L:0026:
5139 021164 104401 TRAP C$SETST

```

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 122
HARDWARE TEST - RXFFDA -

```

5140 .SBTTL HARDWARE TEST - RXFFDA -
5141 :++ *****
5142 :* - RBUF REGISTER RX FLAG FIELD TEST -
5143 :* THIS TEST VERIFIES THAT THE FIELD OF 3 FLAG BITS IN THE RBUF READS
5144 :* AS ALL ONES WHEN THE SELFTEST CODES ARE BEING READ FROM THE DUT
5145 :* AFTER A BOARD RESET AND SKIP SELFTEST SEQUENCE.
5146 :*
5147 :-- *****
5148 021166 BGNTST
5149 021166
5150 021166
5151 021166 012700 000240
5152 021172 104441
5153 000005
5154 021174 012737 000005 002274 TNUM == TNUM + 1 ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
5155 021202 012737 177777 002310 MOV #TNUM,TSTNUM ;SET UP THE TEST NUMBER. (5)
5156 021210 012737 000001 002664 MOV #-1,CTRLCF ;INDICATE THAT WE ARE WITHIN A TEST.
5157 021216 012737 006174 002670 MOV #1,ERRTYP ;SET ERROR TYPE AS FATAL IN ERROR TABLE.
5158 021224 012737 012514 002672 MOV #EM0501,ERRMSG ;SET ERROR MESSAGE ADDRESS IN ERROR TABLE.
5159 MOV #ER0201,ERRBLK ;SET ERROR ROUTINE ADDRESS IN ERROR TABLE.
5160 :+ SET THE DUT CSR MASTER RESET (MR) BIT, PERFORM THE SKIP SELFTEST SEQUENCE,
5161 :+ AND WAIT UP TO 5 SECONDS FOR THE MR BIT TO CLEAR.
5162 :--
5163 021232 012701 011610 MOV #5000.,R1 ;TIME-OUT VALUE IS 5.0 SECONDS.
5164 021236 012702 000040 MOV #BIT05,R2 ;WAITING FOR MASTER RESET BIT.
5165 021242 005003 CLR R3 ;WAITING FOR BIT TO CLEAR.
5166 021244 013704 002214 MOV CSRA,R4 ;BIT IS IN THE DUT'S CSR.
5167 021250 010214 MOV R2,(R4) ;SET THE DUT MASTER RESET BIT.
5168 021252 004737 016100 JSR PC,SKPSTS ;SKIP THE SELFTEST.
5169 021256 004737 014166 JSR PC,MSLGET ;WAIT FOR DUT CSR MR BIT TO CLEAR.
5170 021262 103013 BCC 4$ ;GO REPORT ERROR IF MR DID NOT CLEAR.
5171 :+
5172 :+ READ 8 CHARACTERS FROM THE DUT AND VERIFY THAT ALL 3 RX ERROR FLAGS ARE
5173 :+ SET FOR EACH CHARACTERS.
5174 :--
5175 021264 012400
5176 021266 012701 000010
5177 021272 011402
5178 021274 012700 070000 2$: MOV (R4)+,R0 ;INCREMENT POINTER TO POINT TO DUT RBUF REGSTR.
5179 021300 040200 MOV #8,R1 ;INITIALIZE THE LOOP COUNTER.
5180 021302 001012 MOV (R4),R2 ;READ A CHARACTER FROM THE DUT RBUF REGISTER.
5181 021304 005301 MOV #70000,R0
5182 021306 001371 BIC R2,R0 ;CALCULATE BIT MAP OF CLEAR RX ERROR FLAGS.
5183 021310 000415 BNE 6$ ;GO REPORT ERROR IF NOT ALL RX ERROR FLAGS SET.
5184 DEC R1 ;COUNT THIS LOOP ITERATION.
5185 BNE 2$ ;LOOP IF NOT ALL LINES DONE.
5186 BR 60$ ;EXIT TEST, NO ERROR FOUND.
5187 :+
5188 :+ ERROR REPORTS:
5189 021312 012737 000765 002666 4$: ;REPORT MR BIT WOULD NOT CLEAR AFTER A DUT RESET.
5190 021320 012701 004676 MOV #0501,ERRNBR ;SET THE ERROR NUMBER IN ERROR TABLE.
5191 021324 MOV #EM0202,R1 ;SELECT ERROR MESSAGE.
5192 021324 104460 ERROR ;REPORT ERROR. >>>> ERROR #0501 <<<<
5193 021326 000406 BR 60$ ;EXIT THE TEST. TRAP CSERROR
5194
5195 ;REPORT ONE OR MORE RX ERROR FLAGS FOUND SET WITH SELFTEST CODE.

```

CVDHAAO DHV-11 FUNC TST PART1 MACY11 30A(1052) 12-JUL-83 10:52 PAGE 123
 CVDHAA.P11 12-JUL-83 00:42 HARDWARE TEST - RXFFDA -

```

5196 021330 012737 000766 002666 6$:      MOV      #0502,ERRNBR ;SET THE ERROR NUMBER IN ERROR TABLE.
5197 021336 012701 006242          MOV      #EM0502,R1 ;SELECT ERROR MESSAGE.
5198 021342          ERROR    ;REPORT ERROR.          >>>>> ERROR #0502 <<<<<
5199 021342 104460          TRAP      C$ERROR
5200
5201 021344          60$:    SETPRI  #PRI07      ;DISABLE ALL INTERRUPTS.
5202 021344 012700 000340          MOV      #PRI07,RO
5203 021350 104441          TRAP      C$SPRI
5204 021352 005037 002310          CLR      CTRLCF      ;INDICATE THAT WE COMPLETED THE TEST.
5205 021356          ENDTST
5206 021356          L10027:
5207 021356 104401          TRAP      C$SETST
  
```

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 124
HARDWARE TEST - RDAA -

```

5208 .SBTTL HARDWARE TEST - RDAA -
5209 :++ *****
5210 :* - CSR RX DATA AVAILABLE BIT TEST -
5211 :* THIS TEST VERIFIES THAT THE DUT CSR RX DATA AVAILABLE BIT IS SET BY THE
5212 :* INCLUSION OF THE SELFTEST CODES IN THE DUT FIFO AND THAT THE BIT CLEARS
5213 :* AFTER THE FIFO HAS BEEN EMPTIED.
5214 :*
5215 :-- *****
5216 021360 BGNTST
5217 021360
5218 021360
5219 021360 012700 000240
5220 021364 104441
5221 000006
5222 021366 012737 000006 002274 TNUM == TNUM + 1 ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
5223 021374 012737 177777 002310 MOV #TNUM,TSTNUM ;SET UP THE TEST NUMBER. (6)
5224 021402 012737 000001 002664 MOV #-1,CTRLCF ;INDICATE THAT WE ARE WITHIN A TEST.
5225 021410 012737 006416 002670 MOV #1,ERRTYP ;SET ERROR TYPE AS FATAL IN ERROR TABLE.
5226 021416 012737 012514 002672 MOV #EM0601,ERRMSG ;SET ERROR MESSAGE ADDRESS IN ERROR TABLE.
5227 MOV #ER0201,ERRBLK ;SET ERROR ROUTINE ADDRESS IN ERROR TABLE.
5228 :+ SET THE DUT CSR MASTER RESET (MR) BIT, PERFORM THE SKIP SELFTEST SEQUENCE,
5229 :+ AND WAIT UP TO 5 SECONDS FOR THE MR BIT TO CLEAR.
5230 :--
5231 021424 012701 011610 MOV #5000,R1 ;TIME-OUT VALUE IS 5.0 SECONDS.
5232 021430 012702 000040 MOV #BIT05,R2 ;WAITING FOR MASTER RESET BIT.
5233 021434 005003 CLR R3 ;WAITING FOR BIT TO CLEAR.
5234 021436 013704 002214 MOV CSRA,R4 ;BIT IS IN THE DUT'S CSR.
5235 021442 010214 MOV R2,(R4) ;SET THE DUT MASTER RESET BIT.
5236 021444 004737 016100 JSR PC,SKPSTS ;SKIP THE SELFTEST.
5237 021450 004737 014166 JSR PC,MSLGET ;WAIT FOR DUT CSR MR BIT TO CLEAR.
5238 021454 103016 BCC 4$ ;GO REPORT ERROR IF MR DID NOT CLEAR.
5239 :+
5240 :+ CHECK THAT THE RX DATA AVAILABLE BIT IS SET.
5241 :--
5242 021456 032714 000200 BIT #BIT7,(R4) ;TEST THE DUT RX.DATA.AVAIL BIT.
5243 021462 001422 BEQ 6$ ;GO REPORT ERROR IF BIT IS NOT SET.
5244 :+
5245 :+ READ CHARACTERS FROM THE DUT RX FIFO AND WAIT FOR RX.DATA.AVAIL TO GO CLEAR.
5246 :--
5247 021464 012705 001130 MOV #600,R5 ;ALLOW READING 600 CHARS BEFORE ERROR.
5248 021470 010403 MOV R4,R3
5249 021472 012300 MOV (R3)+,R0 ;CALCULATE THE RBUF ADDRESS.
5250 021474 011300 2$: MOV (R3),R0 ;READ A CHARACTER FROM THE RX FIFO.
5251 021476 032714 000200 BIT #BIT7,(R4) ;TEST THE DUT RX.DATA.AVAIL BIT.
5252 021502 001427 BEQ 60$ ;EXIT TEST WITHOUT ERROR IF RX.DATA.AVAIL CLR.
5253 021504 005305 DEC R5 ;COUNT THE CHARACTER JUST READ.
5254 021506 001372 BNE 2$ ;LOOP IF NOT TOO MANY CHARS READ FROM FIFO.
5255 021510 000416 BR 8$ ;GO REPORT ERROR IF RX.DATA.AVAIL WOULDN'T CLR.
5256
5257 :+
5258 :+ ERROR REPORTS:
5259 :--
5260 ;REPORT MR BIT WOULD NOT CLEAR AFTER A DUT RESET.
5261 021512 012737 001131 002666 4$: MOV #0601,ERRNBR ;SET THE ERROR NUMBER IN ERROR TABLE.
5262 021520 012701 004676 MOV #EM0202,R1 ;SELECT ERROR MESSAGE.
5263 021524 ERROR ;REPORT ERROR. >>>> ERROR #0601 <<<<

```


CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 126
HARDWARE TEST - RDVA -

```

5287 .SBTTL HARDWARE TEST - RDVA -
5288 :+ *****
5289 :* - RBUF RX DATA VALID BIT TEST -
5290 :* THIS TEST VERIFIES THAT THE DUT RBUF RX DATA VALID BIT IS SET BY THE
5291 :* INCLUSION OF THE SELFTEST CODES IN THE DUT FIFO AND THAT THE BIT CLEARS
5292 :* AFTER THE FIFO HAS BEEN EMPTIED.
5293 :*
5294 :-- *****
5295 021576 BGNTST
5296 021576
5297 021576
5298 021576 012700 000240
5299 021602 104441
5300 000007
5301 021604 012737 000007 002274 TNUM == TNUM + 1 ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
5302 021612 012737 177777 002310 MOV #TNUM,TSTNUM ;SET UP THE TEST NUMBER. (7)
5303 021620 012737 000001 002664 MOV #-1,CTRLCF ;INDICATE THAT WE ARE WITHIN A TEST.
5304 021626 012737 007015 002670 MOV #1,ERRTYP ;SET ERROR TYPE AS FATAL IN ERROR TABLE.
5305 021634 012737 012514 002672 MOV #EM0701,ERRMSG ;SET ERROR MESSAGE ADDRESS IN ERROR TABLE.
5306 MOV #ER0201,ERRBLK ;SET ERROR ROUTINE ADDRESS IN ERROR TABLE.
5307 :+ SET THE DUT CSR MASTER RESET (MR) BIT, PERFORM THE SKIP SELFTEST SEQUENCE,
5308 :+ AND WAIT UP TO 5 SECONDS FOR THE MR BIT TO CLEAR.
5309 :--
5310 021642 012701 011610 MOV #5000.,R1 ;TIME-OUT VALUE IS 5.0 SECONDS.
5311 021646 012702 000040 MOV #BIT05,R2 ;WAITING FOR MASTER RESET BIT.
5312 021652 005003 CLR R3 ;WAITING FOR BIT TO CLEAR.
5313 021654 013704 002214 MOV CSRA,R4 ;BIT IS IN THE DUT'S CSR.
5314 021660 010214 MOV R2,(R4) ;SET THE DUT MASTER RESET BIT.
5315 021662 004737 016100 JSR PC,SKPSTS ;SKIP THE SELFTEST.
5316 021666 004737 014166 JSR PC,MSLGET ;WAIT FOR DUT CSR MR BIT TO CLEAR.
5317 021672 103012 BCC 4$ ;GO REPORT ERROR IF MR DID NOT CLEAR.
5318 :+
5319 :+ CHECK THAT THE RX DATA VALID BIT IS SET.
5320 :--
5321 021674 012400 MOV (R4)+,R0 ;INCREMENT POINTER TO PNT TO DUT RBUF REG.
5322 021676 005714 TST (R4) ;TEST THE DUT RX.DATA.VALID BIT.
5323 021700 100016 BPL 6$ ;GO REPORT ERROR IF BIT IS NOT SET.
5324 :+
5325 :+ READ CHARACTERS FROM THE DUT RX FIFO AND WAIT FOR RX.DATA.VALID TO GO CLEAR.
5326 :--
5327 021702 012705 001130 MOV #600.,R5 ;ALLOW READING 600 CHARS BEFORE ERROR.
5328 021706 011400 2$: MOV (R4),R0 ;READ A CHARACTER FROM THE RX FIFO.
5329 021710 100027 BPL 60$ ;EXIT TEST WITHOUT ERROR IF BIT IS CLEAR.
5330 021712 005305 DEC R5 ;COUNT THE CHARACTER JUST READ.
5331 021714 001374 BNE 2$ ;LOOP IF NOT TOO MANY CHARS READ FROM FIFO.
5332 021716 000416 BR 8$ ;GO REPORT ERROR IF RX.DATA.VALID WOULDN'T CLR.
5333 :+
5334 :+ ERROR REPORTS:
5335 :--
5336 :+
5337 :+ ;REPORT MR BIT WOULD NOT CLEAR AFTER A DUT RESET.
5338 021720 012737 001275 002666 4$: MOV #0701.,ERRNBR ;SET THE ERROR NUMBER IN ERROR TABLE.
5339 021726 012701 004676 MOV #EM0202,R1 ;SELECT ERROR MESSAGE.
5340 021732 ERROR ;REPORT ERROR. >>>> ERROR #0701 <<<<<
5341 021732 104460 TRAP C$ERROR
5342 021734 000415 BR 60$ ;EXIT THE TEST.

```

CVDHAAO DHV-11 FUNC TST PART1 MACY11 30A(1052) 12-JUL-83 10:52 PAGE 127
 CVDHAA.P11 12-JUL-83 00:42 HARDWARE TEST - RDVA -

```

5343
5344
5345 021736 012737 001276 002666 6$: ;REPORT THAT RX.DATA.VALID BIT WAS NOT SET AFTER A RESET COMPLETION.
5346 021744 012701 007052          MOV #0702,ERRNBR ;SET THE ERROR NUMBER IN ERROR TABLE.
5347 021750          MOV #EM0702,R1 ;SELECT ERROR MESSAGE.
5348 021750 104460          ERROR ;REPORT ERROR. >>>> ERROR #0702 <<<<<
5349 021752 000406          BR 60$ ;EXIT THE TEST. TRAP C$ERROR
5350
5351
5352 021754 012737 001277 002666 8$: ;REPORT THAT RX.DATA.VALID BIT COULD NOT BE CLEARED BY PURGING FIFO.
5353 021762 012701 007232          MOV #0703,ERRNBR ;SET THE ERROR NUMBER IN ERROR TABLE.
5354 021766          MOV #EM0703,R1 ;SELECT ERROR MESSAGE.
5355 021766 104460          ERROR ;REPORT ERROR. >>>> ERROR #0703 <<<<<
5356
5357 021770          60$: SETPRI #PRI07 ;DISABLE ALL INTERRUPTS.
5358 021770 012700 000340          MOV #PRI07,R0
5359 021774 104441          TRAP C$SPRI
5360 021776 005037 002310          CLR CTRLCF ;INDICATE THAT WE COMPLETED THE TEST.
5361 022002          ENDTST
5362 022002          L10031:
5363 022002 104401          TRAP C$ETST
    
```

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 128
HARDWARE TEST - RLNA -

```

5364
5365
5366
5367
5368
5369
5370
5371
5372 022004
5373 022004
5374 022004
5375 022004 012700 000240
5376 022010 104441
5377 000010
5378 022012 012737 000010 002274
5379 022020 012737 177777 002310
5380 022026 012737 000001 002664
5381 022034 012737 007415 002670
5382
5383
5384
5385
5386 022042 012701 011610
5387 022046 012702 000040
5388 022052 005003
5389 022054 013704 002214
5390 022060 010214
5391 022062 004737 016100
5392 022066 004737 014166
5393 022072 103016
5394
5395
5396
5397
5398
5399 022074 005001
5400 022076 012400
5401 022100 011402
5402 022102 010203
5403 022104 000303
5404 022106 042703 177760
5405 022112 020301
5406 022114 001017
5407 022116 005201
5408 022120 020127 000010
5409 022124 001365
5410 022126 000423
5411
5412
5413
5414
5415
5416 022130 012737 001441 002666
5417 022136 012737 012576 002672
5418 022144 012701 004676
5419 022150

```

```

.SBTTL HARDWARE TEST - RLNA -
:++ *****
: * - RBUF RX LINE NUMBER FIELD TEST -
: * THIS TEST VERIFIES THAT THE DUT RBUF RX LINE NUMBER FIELD IS WORKING
: * CORRECTLY BY UTILIZING THE SELFTEST CODES WHICH ARE PUT IN THE RX
: * FIFO AFTER A BOARD RESET.
: *
:-- *****
BGNTST
T8::
SETPRI #PRI05 ;ALLOW LTC INTERRUPTS.
MOV #PRI05,R0
TRAP C$SPRI
TNUM == TNUM + 1 ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
MOV #TNUM,TSTNUM ;SET UP THE TEST NUMBER. (8)
MOV #-1,CTRLCF ;INDICATE THAT WE ARE WITHIN A TEST.
MOV #1,ERRTYP ;SET ERROR TYPE AS FATAL IN ERROR TABLE.
MOV #EM0801,ERRMSG ;SET ERROR MESSAGE ADDRESS IN ERROR TABLE.
:++
: SET THE DUT CSR MASTER RESET (MR) BIT, PERFORM THE SKIP SELFTEST SEQUENCE,
: AND WAIT UP TO 5 SECONDS FOR THE MR BIT TO CLEAR.
:--
MOV #5000,R1 ;TIME-OUT VALUE IS 5.0 SECONDS.
MOV #BIT05,R2 ;WAITING FOR MASTER RESET BIT.
CLR R3 ;WAITING FOR BIT TO CLEAR.
MOV CSRA,R4 ;BIT IS IN THE DUT'S CSR.
MOV R2,(R4) ;SET THE DUT MASTER RESET BIT.
JSR PC,SKPSTS ;SKIP THE SELFTEST.
JSR PC,MSLGET ;WAIT FOR DUT CSR MR BIT TO CLEAR.
BCC 4$ ;GO REPORT ERROR IF MR DID NOT CLEAR.
:++
: READ CHARACTERS FROM THE DUT RX FIFO AND VERIFY THAT THE LINE NUMBERS ARE
: CORRECT.
: ONE CHARACTER IS READ FROM THE FIFO FOR EACH POSSIBLE LINE ON THE DUT.
:--
CLR R1 ;CLEAR THE LINE COUNTER.
MOV (R4)+,R0 ;INCREMENT POINTER TO PNT TO THE DUT RBUF REG.
2$: MOV (R4),R2 ;READ A CHARACTER FROM THE DUT RX FIFO.
MOV R2,R3
SWAB R3
BIC #177760,R3 ;REMOVE ALL BUT LINE NUMBER BITS.
CMP R3,R1 ;COMPARE WITH EXPECTED LINE NUMBER.
BNE 6$ ;GO REPORT ERROR IF LINE NUMBERS DON'T MATCH.
INC R1 ;INCREMENT THE EXPECTED LINE NUMBER.
CMP R1,#NUMLNS ;COMPARE WITH NUMBER OF LINES ON DUT.
BNE 2$ ;LOOP UNTIL CODES FOR ALL LINES ARE READ.
BR 60$ ;EXIT TEST WITHOUT ERROR.
:++
: ERROR REPORTS:
:--
:REPORT MR BIT WOULD NOT CLEAR AFTER A DUT RESET.
4$: MOV #0801,ERRNBR ;SET THE ERROR NUMBER IN ERROR TABLE.
MOV #ER0503,ERRBLK ;SET ERROR ROUTINE ADDRESS IN ERROR TABLE.
MOV #EM0202,R1 ;SELECT ERROR MESSAGE.
ERROR ;REPORT ERROR. >>>> ERROR #0801 <<<<

```


CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 129
HARDWARE TEST - RLNA -

```

5420 022150 104460
5421 022152 000411
5422
5423
5424 022154 012737 001442 002666 6$: ;REPORT THAT RX LINE NUMBER FIELD IS WRONG FOR SELFTEST CODE.
5425 022162 012737 012514 002672 MOV #0802,ERRNBR ;SET THE ERROR NUMBER IN ERROR TABLE.
5426 022170 012701 007455 MOV #ER0201,ERRBLK ;SET ERROR ROUTINE ADDRESS IN ERROR TABLE.
5427 022174 MOV #EM0802,R1 ;SELECT ERROR MESSAGE.
5428 022174 104460 ERROR ;REPORT ERROR. >>>> ERROR #0802 <<<<
5429 TRAP C$ERROR
5430 022176 60$: SETPRI #PRI07 ;DISABLE ALL INTERRUPTS.
5431 022176 012700 000340 MOV #PRI07,RO
5432 022202 104441 TRAP C$SPRI
5433 022204 005037 002310 CLR CTRLCF ;INDICATE THAT WE COMPLETED THE TEST.
5434 022210 ENDTST
5435 022210 L10032:
5436 022210 104401 TRAP C$ETST

```

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 130
HARDWARE TEST - BMPCHK -

```

5437
5438
5439
5440
5441
5442
5443
5444
5445
5446
5447
5448
5449 022212
5450 022212
5451 022212
5452 022212 012700 000240
5453 022216 104441
5454 000011
5455 022220 012737 000011 002274
5456 022226 012737 177777 002310
5457 022234 012737 000001 002664
5458 022242 012737 001605 002666
5459
5460
5461
5462
5463 022250 012701 005670
5464 022254 012702 000040
5465 022260 005003
5466 022262 013704 002214
5467 022266 004737 014166
5468 022272 103027
5469
5470
5471
5472 022274 010214
5473 022276 004737 016100
5474
5475
5476
5477
5478 022302 012704 000764
5479 022306 004737 014126
5480 022312 004737 014544
5481 022316 103015
5482
5483
5484
5485 022320 013702 002462
5486 022324 012703 002464
5487 022330 020203
5488 022332 001414
5489
5490
5491
5492

```

```

.SBTTL HARDWARE TEST - BMPCHK -
:++ *****
:
: - BMP CHECK TEST -
: THIS TEST IS USED TO VERIFY THAT THE DUT DOES NOT IMMEDIATELY FAIL
: THE ON-BOARD BACKGROUND-MONITOR PROGRAM, AND HENCE INVALIDATE
: SUCCEEDING TESTS.
: THIS TEST LOOKS FOR BMP CODES IN THE FIFO FOR A SET PERIOD IMMEDIATELY
: AFTER THE SELF-TEST IS SKIPPED.
: ANY BMP CODES THAT ARE FOUND ARE SAVED ON THE QUEUE AND ARE ALSO
: REPORTED IN THIS TEST.
:-- *****
BGNTST
SETPRI #PRI05 ;ALLOW LTC INTERRUPTS. T9::
MOV #PRI05,R0
TRAP C$SPRI
TNUM == TNUM + 1 ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
MOV #TNUM,TSTNUM ;SET UP THE TEST NUMBER. (9)
MOV #-1,CTRLCF ;INDICATE THAT WE ARE WITHIN A TEST.
MOV #1,ERRTYP ;SET ERROR TYPE AS FATAL IN ERROR TABLE.
MOV #0901.,ERRNBR ;SET THE ERROR NUMBER.
:
: + WAIT UP TO 3 SECONDS FOR THE DUT MASTER RESET BIT TO CLEAR.
: IF TIME-OUT OCCURS, THEN EXIT THIS TEST.
:--
MOV #3000.,R1 ;TIME-OUT VALUE IS 3.0 SECONDS.
MOV #BIT05,R2 ;WAITING FOR MASTER RESET BIT.
CLR R3 ;WAITING FOR BIT TO CLEAR.
MOV CSRA,R4 ;BIT IS IN THE DUT'S CSR.
JSR PC,MSLGET ;WAIT FOR DUT CSR MR BIT TO CLEAR.
BCC 50$ ;ABORT THE TEST IF MR DID NOT CLEAR.
:
: + RESET THE DUT, SKIP THE SELF-TEST.
:--
MOV R2,(R4) ;SET THE DUT MASTER RESET BIT.
JSR PC,SKPSTS ;WRITE THE SKIP SELFTEST CODES TO THE DUT.
:
: + WAIT FOR MASTER RESET TO CLEAR. DELAY FOR 500 MILLI-SECS BEFORE PURGING
: THE FIFO.
:--
MOV #500.,R4 ;TIME-OUT VALUE IS 500 MILLI-SECONDS.
JSR PC,DELAY ;WAIT FOR BMP TO BEGIN EXECUTION.
JSR PC,PUFIFO ;PURGE THE FIFO, SAVING ANY BMP CODES.
BCC 50$ ;ABORT THE TEST IF THE FIFO DID NOT CLEAR.
:
: + REPORT THE ERROR IF ANY BMP CODES WERE FOUND.
:--
MOV BMPCQP,R2 ;GET THE CONTENTS OF THE POINTER TO THE BMP Q.
MOV #BMPCQB,R3 ;GET THE START ADDRESS OF THE QUEUE.
CMP R2,R3 ;SEE IF THE POINTER HAS MOVED FROM THE BASE.
BEQ 60$ ;EXIT NO CODES IN THE QUEUE.
:
: + THERE IS AT LEAST ONE BMP CODE IN THE QUEUE. REPORT THE ERROR.
:--
;REPORT ERROR BMP CODE FOUND IN TEST NN, BMP CODE:NNNNNN''

```

CVDHAAO DHV-11 FUNC TST PART1 MACY11 30A(1052) 12-JUL-83 10:52 PAGE 131
CVDHAA.P11 12-JUL-83 00:42 HARDWARE TEST - BMPCHK -

```

5493 022334 012701 007561      MOV      #EM0902,R1      ;PASS THE MESSAGE TO BE REPORTED.
5494 022340                      ERRDF    0901,EM0901,ER9301 ; >>>> ERROR #0901 <<<<<.
5495 022340 104455                      TRAP    C$ERDF
5496 022342 001605                      .WORD  901
5497 022344 007530                      .WORD  EM0901
5498 022346 013372                      .WORD  ER9301
5499 022350 000405      BR      60$
5500
5501 022352 012737 001606 002666 50$:      MOV      #902.,ERRNBR      ;SET >>>> ERROR #0902 <<<<<.
5502 022360 004737 016226                      JSR     PC,TSABRT        ;REPORT NON-TEST RELATED ERROR.
5503
5504 022364                      60$:      SETPRI  #PRI07          ;DISABLE ALL INTERRUPTS.
5505 022364 012700 000340                      MOV     #PRI07,R0
5506 022370 104441                      TRAP   C$SPRI
5507 022372 005037 002310                      CLR     CTRLCF          ;INDICATE THAT WE COMPLETED THE TEST.
5508 022376
5509 022376                      L10033:
5510 022376 104401                      TRAP   C$ETST

```

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 132
HARDWARE TEST - BMPCHK -

```

5511
5512
5513      .SBTTL  HARDWARE TEST          - SKSELF -
5514      :+ *****
5515      :*          - SKIP SELF-TEST TEST -
5516      :*      THIS TEST VERIFIES THAT THE DUT SKIPS THE SELF-TEST WITHIN THE
5517      :*      TIME ALLOWED, AND THAT THE FIFO CONTAINS THE CORRECT CODES AFTER ITS
5518      :*      COMPLETION.
5519      :*
5520      :-- *****
5521      022400      BGNST
5522      022400
5523      022400          SETPRI  #PRI05          ;ALLOW LTC INTERRUPTS.          T10::
5524      022400      012700      000240          MOV          #PRI05,R0
5525      022404      104441          TRAP          C$SPRI
5526      000012          TNUM == TNUM + 1          ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
5527      022406      012737      000012      002274      MOV          #TNUM,TSTNUM          ;SET UP THE TEST NUMBER.          (10)
5528      022414      012737      177777      002310      MOV          #-1,CTRLCF          ;INDICATE THAT WE ARE WITHIN A TEST.
5529      022422      012737      000001      002664      MOV          #1,ERRTYP          ;SET ERROR TYPE AS FATAL IN ERROR TABLE.
5530      022430      012737      007615      002670      MOV          #EM1001,ERRMSG          ;SET ERROR MESSAGE ADDRESS IN ERROR TABLE.
5531      022436      012737      012576      002672      MOV          #ER0503,ERRBLK          ;SET ERROR ROUTINE ADDRESS IN ERROR TABLE.
5532
5533      :+ WAIT UP TO 3 SECONDS FOR THE DUT MASTER RESET BIT TO CLEAR.
5534      : IF TIME-OUT OCCURS, THEN EXIT THIS TEST.
5535      :--
5536      022444      012701      005670      MOV          #3000.,R1          ;TIME-OUT VALUE IS 3.0 SECONDS.
5537      022450      012702      000040      MOV          #BIT05,R2          ;WAITING FOR MASTER RESET BIT.
5538      022454      005003          CLR          R3          ;WAITING FOR BIT TO CLEAR.
5539      022456      013704      002214      MOV          CSRA,R4          ;BIT IS IN THE DUT'S CSR.
5540      022462      004737      014166      JSR          PC,MSLGET          ;WAIT FOR DUT CSR_MR BIT TO CLEAR.
5541      022466      103037          BCC          50$          ;ABORT THE TEST IF MR DID NOT CLEAR.
5542
5543      :+ DETERMINE IF THE DUT TAKES TOO SHORT OR TOO LONG A TIME TO SKIP THE SELF-TEST
5544      : SET-UP A TIME-OUT OF 50 MILLI-SECOND, IF MR IS CLEAR IN LESS THAN 10 MILLI
5545      : -SECOND, OR GREATER THAN 50 MILLI-SECONDS, REPORT THE ERROR.
5546      :--
5547      022470      012701      000062      MOV          #50.,R1          ;TIME-OUT VALUE IS 50 MILLI-SECONDS.
5548      022474      010214          MOV          R2,(R4)          ;SET THE DUT MASTER RESET BIT.
5549      022476      004737      016100      JSR          PC,SKPSTS          ;WRITE THE SKIP SELFTEST CODES TO THE DUT.
5550      022502      004737      014166      JSR          PC,MSLGET          ;WAIT FOR DUT CSR_MR BIT TO CLEAR.
5551      022506      103011          BCC          2$          ;GO REPORT ERR IF SKIPPING STEST TOOK TOO LONG.
5552      022510      020127      000050      CMP          R1,#40.
5553      022514      003015          BGT          4$          ;GO REP ERR IF SELFTEST COMPLETED IN < 10 MS.
5554
5555      :+ SELF-TEST COMPLETED WITHIN 10 MILLI-SEC TO 50 MILLI-SECONDS.
5556      : VERIFY THAT THE SELF-TEST CODES IN THE FIFO ARE "GOOD" CODES ,IE THE DUT
5557      : SUCCESSFULLY COMPLETED THE SELF-TEST.
5558      : THIS SUBROUTINE REPORTS ERRORS WITH NUMBERS >>>> 1003 THRU 1007 <<<<.
5559      :--
5560      022516      012737      001753      002666      MOV          #1003.,ERRNBR          ;SET ERROR NUMBER TO 1003.
5561      022524      004737      015450      JSR          PC,RSTRPT          ;CHECK SELF-TEST CODES IN THE FIFO.
5562      022530      000423          BR          60$          ;EXIT TEST.
5563
5564      :+ ERROR REPORTS:
5565      :--
5566          ;REPORT SKIP SELF-TEST TOOK TOO LONG.

```

CVDHAAO DHV-11 FUNC TST PART1 MACY11 30A(1052) 12-JUL-83 10:52 PAGE 133
 CVDHAA.P11 12-JUL-83 00:42 HARDWARE TEST - SKSELF -

```

5567 022532 012737 001751 002666 2$:  MOV #1001,ERRNBR ;SET THE ERROR NUMBER IN THE ERROR TABLE.
5568 022540 012701 007661  MOV #EM1002,R1 ;SELECT ERROR MESSAGE.
5569 022544  ERROR ;REPORT ERROR. >>>> ERROR #1001 <<<<<
5570 022544 104460  TRAP C$ERROR
5571 022546 000414  BR 60$ ;EXIT THE TEST.
5572
5573 ;REPORT SKIP SELF-TEST COMPLETED TOO SOON.
5574 022550 012737 001752 002666 4$:  MOV #1002,ERRNBR ;SET THE ERROR NUMBER IN THE ERROR TABLE.
5575 022556 012701 007746  MOV #EM1003,R1 ;SELECT ERROR MESSAGE.
5576 022562  ERROR ;REPORT ERROR. >>>> ERROR #1002 <<<<<
5577 022562 104460  TRAP C$ERROR
5578 022564 000405  BR 60$ ;EXIT THE TEST.
5579
5580 022566 012737 001753 002666 50$:  MOV #1003,ERRNBR ;SET ERROR NUMBER.
5581 022574 004737 016226  JSR PC,TSABRT ;REPORT NON-TEST RELATED ERROR.
5582
5583 022600 60$:  SETPRI #PRI07 ;DISABLE ALL INTERRUPTS.
5584 022600 012700 000340  MOV #PRI07,RO
5585 022604 104441  TRAP C$SPRI
5586 022606 005037 002310  CLR CTRLCF ;INDICATE THAT WE COMPLETED THE TEST.
5587 022612  ENDTST
5588 022612  L10034:
5589 022612 104401  TRAP C$SETST

```

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 134
HARDWARE TEST - SKSELF -

```

5590
5591
5592
5593
5594
5595
5596
5597
5598
5599 022614
5600 022614
5601 022614
5602 022614 012700 000240
5603 022620 104441
5604 000013
5605 022622 012737 000013 002274
5606 022630 012737 177777 002310
5607 022636 012737 000001 002664
5608 022644 012737 010024 002670
5609 022652 012737 012576 002672
5610
5611
5612
5613
5614 022660 012701 005670
5615 022664 012702 000040
5616 022670 005003
5617 022672 013704 002214
5618 022676 004737 014166
5619 022702 103044
5620
5621
5622
5623 022704 010214
5624 022706 004737 016100
5625
5626
5627
5628
5629 022712 012701 000005
5630 022716 012702 020000
5631 022722 010203
5632 022724 013704 002214
5633 022730 004737 014166
5634 022734 103020
5635
5636
5637
5638
5639
5640
5641
5642 022736 012701 000017
5643 022742 005003
5644 022744 004737 014166
5645 022750 103012

```

```

.SBTTL  HARDWARE TEST          - DFSKST -
:++ *****
:*          - DIAGNOSTIC FAIL BIT, SKIP SELF-TEST TEST -
:*          THIS TEST VERIFIES THAT THE DIAGNOSTIC FAIL BIT OF THE DUT, CORRECTLY
:*          CHANGES STATE AS THE ON-BOARDED SELFTEST IS SKIPPED.
:*
:-- *****
BGNTST
                                T11::
SETPRI  #PRI05                ;ALLOW LTC INTERRUPTS.
                                MOV      #PRI05,R0
                                TRAP    C$SPRI
TNUM == TNUM + 1              ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
MOV     #TNUM,TSTNUM          ;SET UP THE TEST NUMBER. (11)
MOV     #-1,CTRLCF            ;INDICATE THAT WE ARE WITHIN A TEST.
MOV     #1,ERRTF              ;SET ERROR TYPE AS FATAL IN ERROR TABLE.
MOV     #EM1101,ERRMSG        ;SET ERROR MESSAGE ADDRESS IN ERROR TABLE.
MOV     #ER0503,ERRBLK       ;SET ERROR ROUTINE ADDRESS IN ERROR TABLE.

:++
: WAIT UP TO 3 SECONDS FOR THE DUT MASTER RESET BIT TO CLEAR.
: IF TIME-OUT OCCURS, THEN EXIT THIS TEST.
:--
MOV     #3000.,R1              ;TIME-OUT VALUE IS 3.0 SECONDS.
MOV     #BIT05,R2              ;WAITING FOR MASTER RESET BIT.
CLR     R3                     ;WAITING FOR BIT TO CLEAR.
MOV     CSRA,R4                ;BIT IS IN THE DUT'S CSR.
JSR     PC,MSLGET              ;WAIT FOR DUT_CSR_MR BIT TO CLEAR.
BCC     50$                    ;ABORT THE TEST IF MR DID NOT CLEAR.

:++
: RESET THE DUT, SKIP THE SELF-TEST.
:--
MOV     R2,(R4)                ;SET THE DUT MASTER RESET BIT.
JSR     PC,SKPSTS              ;WRITE THE SKIP SELFTEST CODES TO THE DUT.

:++
: SET TIME OUT OF 5 MILLI SECONDS, WAIT FOR DIAG_FAIL BIT TO SET.
: IF TIME-OUT OCCURS GO REPORT THE ERROR.
:--
MOV     #5,R1                  ;TIME-OUT VALUE IS 5 MILLI-SECONDS.
MOV     #BIT13,R2              ;WAITING FOR DIAGNOSTIC FAIL BIT.
MOV     R2,R3                  ;WAITING FOR BIT TO SET.
MOV     CSRA,R4                ;BIT IS IN THE DUT'S CSR.
JSR     PC,MSLGET              ;WAIT FOR DUT_CSR_DF BIT TO CLEAR.
BCC     4$                     ;IF DIAG_FAIL DID NOT SET, GO REPORT ERROR.

:++
: SET TIME-OUT OF 15 MILLI-SECS, WAIT FOR DIAG_FAIL TO CLEAR.
: IF TIME-OUT OCCURS GO REPORT THE ERROR.
: VERIFY THE DIAG FAIL BIT IS IN A STABLE STATE BEFORE CONTINUING. LOOP
: BACK IF THE STATE WAS TRANSITORY, USING THE REMAINDER OF THE 15 MS TIME-OUT.
:--
MOV     #15.,R1                ;TIME-OUT VALUE IS 15 MILLI-SECONDS.
CLR     R3                     ;WAITING FOR BIT TO CLEAR.
JSR     PC,MSLGET              ;WAIT FOR DUT_CSR_DF BIT TO CLEAR.
BCC     4$                     ;IF DIAG_FAIL DID NOT CLEAR, GO REPORT ERROR.

2$:

```

CVDHAAO DHV-11 FUNC TST PART1 MACY11 30A(1052) 12-JUL-83 10:52 PAGE 135
 CVDHAA.P11 12-JUL-83 00:42 HARDWARE TEST - DFKST -

```

5646 022752 010105          MOV    R1,R5          ;SAVE THE REMAINING TIME-OUT VALUE.
5647 022754 012701 000001    MOV    #1,R1          ;SET TIME-OUT OF 1 MILLI-SECOND.
5648 022760 052703 020000    BIS    #BIT13,R3      ;WAIT FOR BIT TO SET.
5649 022764 004737 014166    JSR    PC,MSLGET      ;DOUBLE CHECK TO ELIMINATE NOISE PROBLEMS.
5650 022770 103016          BCC    60$            ;EXIT IF DIAG FAIL BIT STILL CLEAR.
5651 022772 010501          MOV    R5,R1          ;PASS THE REMAINING TIME-OUT VALUE.
5652 022774 000762          BR     2$             ;LOOP TO CHECK AGAIN.
5653
5654      ;+
5654      ;-
5655      ;-
5656      ;REPORT DIAGNOSTIC FAIL BIT BAD.
5657 022776 012737 002115 002666 4$:  MOV    #1101,ERRNBR  ;SET THE ERROR NUMBER IN THE ERROR TABLE.
5658 023004 012701 010265          MOV    #EM1205,R1    ;SELECT ERROR MESSAGE.
5659 023010          ERROR              ;REPORT ERROR. >>>> ERROR #1101 <<<<<
5660 023010 104460          TRAP    C$ERROR
5661 023012 000405          BR     60$            ;EXIT THE TEST.
5662
5663 023014 012737 002116 002666 50$:  MOV    #1102,ERRNBR  ;SET THE ERROR NUMBER FOR TSABRT RTN.
5664 023022 004737 016226          JSR    PC,TSABRT     ;REPORT NON-TEST RELATED ERROR.
5665
5666 023026          60$:  SETPRI #PRI07        ;DISABLE ALL INTERRUPTS.
5667 023026 012700 000340          MOV    #PRI07,R0    ;
5668 023032 104441          TRAP    C$SPRI
5669 023034 005037 002310          CLR    CTRLCF       ;INDICATE THAT WE COMPLETED A TEST.
5670 023040          ENDTST
5671 023040          L10035:
5672 023040 104401          TRAP    C$SETST

```


CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 137
HARDWARE TEST - SELFTS -

```

5729      ; VERIFY THAT THE SELF-TEST CODES IN THE FIFO ARE 'GOOD' CODES ,IE THE DUT
5730      ; SUCCESSFULLY COMPLETED THE SELF-TEST.
5731      ; THIS SUBROUTINE REPORTS ERRORS WITH NUMBERS >>>> 1205 THRU 1209 <<<<.
5732      ;-
5733 023212 012737 002265 002666 2$:   MOV   #1205,ERRNBR ;SET ERROR NUMBER TO 1205.
5734 023220 004737 015450           JSR   PC,RSTRPT  ;CHECK SELF-TEST CODES IN THE FIFO.
5735 023224 000431           BR    60$        ;EXIT TEST.
5736
5737      ;+
5738      ; ERROR REPORTS:
5739      ;-
5740 023226 012737 002261 002666 4$:   ;REPORT SELF-TEST TOOK TOO LONG TO COMPLETE.
5741 023234 012701 010067           MOV   #1201,ERRNBR ;SET THE ERROR NUMBER IN THE ERROR TABLE.
5742 023240           MOV   #EM1202,R1 ;SELECT ERROR MESSAGE.
5743 023240 104460           ERROR ;REPORT ERROR. >>>> ERROR #1201 <<<<
5744 023242 000422           BR    60$        ;EXIT THE TEST.
5745
5746      ;REPORT SELF-TEST DID NOT EXECUTE AFTER DUT RESET.
5747 023244 012737 002262 002666 6$:   MOV   #1202,ERRNBR ;SET THE ERROR NUMBER IN ERROR TABLE.
5748 023252 012701 010231           MOV   #EM1204,R1 ;SELECT ERROR MESSAGE.
5749 023256           ERROR ;REPORT ERROR. >>>> ERROR #1202 <<<<
5750 023256 104460           BR    60$        ;EXIT THE TEST.
5751
5752      ;REPORT SELF-TEST COMPETED TOO SOON.
5753 023260 012737 002263 002666 8$:   MOV   #1203,ERRNBR ;SET THE ERROR NUMBER IN THE ERROR TABLE.
5754 023266 012701 010153           MOV   #EM1203,R1 ;SELECT ERROR MESSAGE.
5755 023272           ERROR ;REPORT ERROR. >>>> ERROR #1203 <<<<
5756 023272 104460           BR    60$        ;EXIT THE TEST.
5757 023274 000405
5758
5759 023276 012737 002272 002666 50$:  MOV   #1210,ERRNBR ;SET THE ERROR NUMBER FOR TSABRT RTN.
5760 023304 004737 016226           JSR   PC,TSABRT  ;REPORT NON-TEST RELATED ERROR.
5761
5762 023310           60$:  SETPRI #PRI07 ;DISABLE ALL INTERRUPTS.
5763 023310 012700 000340           MOV   #PRI07,R0
5764 023314 104441           TRAP  C$SPRI
5765 023316 005037 002310           CLR   CTRLCF
5766 023322           ENDTST ;INDICATE THAT WE COMPLETED THE TEST.
5767 023322
5768 023322 104401           L10036: TRAP  C$SETST

```

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 138
HARDWARE TEST - SELFTS -

5769
5770
5771
5772
5773
5774
5775
5776
5777
5778
5779
5780
5781
5782
5783
5784
5785
5786
5787
5788
5789
5790
5791
5792
5793
5794
5795
5796
5797
5798
5799
5800
5801
5802
5803
5804
5805
5806
5807
5808
5809
5810
5811
5812
5813
5814
5815
5816
5817
5818
5819
5820
5821
5822
5823
5824

023324
023324
023324
023324 012700 000240
023330 104441
000015
023332 012737 000015 002274
023340 012737 177777 002310
023346 012737 000001 002664
023354 012737 010311 002670
023362 012737 012576 002672
023370 012737 002425 002666

023376 012701 005670
023402 012702 000040
023406 005003
023410 013704 002214
023414 004737 014166
023420 103071

023422 010214
023424 012704 000031
023430 004737 014126
023434 012777 146314 156570

023442 005237 002666
023446 012701 003720
023452 013704 002214
023456 004737 014166
023462 103050

023464 005237 002666
023470 032714 020000
023474 001437

```
.SBTTL HARDWARE TEST - STFAIL -
:++ *****
:* - SELF-TEST FAIL TEST -
:* THIS TEST VERIFIES THAT THE DUT WILL REPORT SELFTEST ERRORS VIA THE
:* FIFO. AND THAT THE DIAGNOSTIC FAIL BIT WILL INDICATE THE ERROR.
:* THIS IS ACCOMPLISHED VIA A SOFTWARE 'HOOK' IN THE SELF-TEST, WHICH
:* FORCES A 'PROCI TO RAM ERROR' TO BE PLACED IN THE FIFO.
:-- *****
BGNTST
SETPRI #PRI05 ;ALLOW LTC INTERRUPTS. T13::
MOV #PRI05,R0
TRAP C$SPRI
TNUM == TNUM + 1 ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
MOV #TNUM,TSTNUM ;SET UP THE TEST NUMBER. (13)
MOV #-1,CTRLCF ;INDICATE THAT WE ARE WITHIN A TEST.
MOV #1,ERRTYP ;SET ERROR TYPE AS FATAL IN ERROR TABLE.
MOV #EM1301,ERRMSG ;SET ERROR MESSAGE ADDRESS IN ERROR TABLE.
MOV #ER0503,ERRBLK ;SET ERROR ROUTINE ADDRESS IN ERROR TABLE.
MOV #1301.,ERRNBR ;SET ERROR NUMBER TO 1301.
:++
: WAIT UP TO 3 SECONDS FOR THE DUT MASTER RESET BIT TO CLEAR.
: IF TIME-OUT OCCURS, THEN EXIT THIS TEST.
:--
MOV #3000.,R1 ;TIME-OUT VALUE IS 3.0 SECONDS.
MOV #BIT05,R2 ;WAITING FOR MASTER RESET BIT.
CLR R3 ;WAITING FOR BIT TO CLEAR.
MOV CSRA,R4 ;BIT IS IN THE DUT'S CSR.
JSR PC,MSLGET ;WAIT FOR DUT CSR MR BIT TO CLEAR.
BCC 50$ ;GO REPORT ERROR IF MR DID NOT CLEAR.
:++
: RESET THE DUT, DELAY FOR 25 MILLI-SECONDS BEFORE WRITING THE FAIL_SELF_TEST
: CODE TO TBUFFCT REGISTER ON CHANNEL 0.
:--
MOV R2,(R4) ;SET DUT MASTER RESET BIT, SELECT CHANNEL 0.
MOV #25.,R4 ;PASS DELAY PERIOD OF 25 MILLI SECS.
JSR PC,DELAY ;WAIT FOR SELFTEST TO INITIALISE.
MOV #146314,@TXBFCA ;WRITE THE FAIL SELF-TEST CODE TO TBUFFCT REG.
:++
: WAIT UP TO 2 SECONDS FOR THE SELF-TEST TO COMPLETE.
: IF TIME-OUT OCCURS, THEN EXIT THIS TEST.
:--
INC ERRNBR ;SET ERROR NUMBER TO 1302.
MOV #2000.,R1 ;TIME-OUT VALUE IS 2.0 SECONDS.
MOV CSRA,R4 ;BIT IS IN THE DUT'S CSR.
JSR PC,MSI.GET ;WAIT FOR DUT CSR MR BIT TO CLEAR.
BCC 50$ ;GO REPORT ERROR IF MR DID NOT CLEAR.
:++
: VERIFY THE DIAGNOSTIC FAIL BIT IS SET, INDICATING THE ERROR.
: REPORT ERROR IF DIAGNOSTIC FAIL BIT IS CLEAR.
:--
INC ERRNBR ;SET ERROR NUMBER TO 1303.
BIT #BIT13,(R4) ;CHECK THE STATE OF THE DIAG FAIL BIT.
BEQ 8$ ;GO REPORT ERROR IF DIAG_FAIL BIT CLEAR.
```


CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 140
HARDWARE TEST - STFAIL -

```

5866
5867
5868
5869
5870
5871
5872
5873
5874
5875
5876
5877 023624
5878 023624
5879 023624
5880 023624 012700 000240
5881 023630 104441
5882 000016
5883 023632 012737 000016 002274
5884 023640 012737 177777 002310
5885 023646 012737 000001 002664
5886 023654 012737 010374 002670
5887 023662 012737 012576 002672
5888
5889
5890
5891
5892 023670 012701 005670
5893 023674 012702 000040
5894 023700 005003
5895 023702 013704 002214
5896 023706 004737 014166
5897 023712 103131
5898
5899
5900
5901 023714 010214
5902 023716 004737 016100
5903 023722 012701 005670
5904 023726 004737 014166
5905 023732 103121
5906
5907
5908
5909
5910
5911
5912
5913 023734 012705 000040
5914 023740 012703 000143
5915 023744 010304
5916 023746 012737 002571 002666
5917 023754 012701 010424
5918
5919 023760 017702 156232
5920 023764 100077
5921

```

```

.SBTTL HARDWARE TEST - ROMVER -
:++ *****
: * - ROM VERSION TEST -
: * THIS TEST VERIFIES THAT THE DUT'S SELF-TEST PLACES VALID ROM VERSION
: * NUMBERS IN THE FIFO AFTER IT HAS BEEN SKIPPED. THE ROM VERSION NUMBERS
: * WILL BE REPORTED (ON THE FIRST PASS ONLY), IF AN AFFIRMATIVE ANSWER
: * WAS GIVEN TO THE SOFTWARE P-TABLE QUESTION.
: *
: *
:-- *****
BGNTST
T14::
SETPRI #PRI05 ;ALLOW LTC INTERRUPTS.
MOV #PRI05,R0
TRAP C$SPRI
TNUM == TNUM + 1 ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
MOV #TNUM,TSTNUM ;SET UP THE TEST NUMBER. (14)
MOV #-1,CTRLCF ;INDICATE THAT WE ARE WITHIN A TEST.
MOV #1,ERRTYP ;SET ERROR TYPE AS FATAL IN ERROR TABLE.
MOV #EM1401,ERRMSG ;SET ERROR MESSAGE ADDRESS IN ERROR TABLE.
MOV #ER0503,ERRBLK ;SET ERROR ROUTINE ADDRESS IN ERROR TABLE.
:++
: * WAIT UP TO 3 SECONDS FOR THE DUT MASTER RESET BIT TO CLEAR.
: * IF TIME-OUT OCCURS, THEN EXIT THIS TEST.
:--
MOV #3000,R1 ;TIME-OUT VALUE IS 3.0 SECONDS.
MOV #BIT05,R2 ;WAITING FOR MASTER RESET BIT.
CLR R3 ;WAITING FOR BIT TO CLEAR.
MOV CSRA,R4 ;BIT IS IN THE DUT'S CSR.
JSR PC,MSLGET ;WAIT FOR DUT CSR MR BIT TO CLEAR.
BCC 50$ ;ABORT THE TEST IF MR DID NOT CLEAR.
:++
: * SET THE MASTER RESET BIT, AND SKIP THE SELF TEST.
:--
MOV R2,(R4) ;SET THE MASTER RESET BIT.
JSR PC,SKPSTS ;SKIP THE SELF TEST.
MOV #3000,R1 ;TIME-OUT VALUE IS 3.0 SECONDS.
JSR PC,MSLGET ;WAIT FOR DUT CSR MR BIT TO CLEAR.
BCC 50$ ;ABORT THE TEST IF MR DID NOT CLEAR.
:++
: * REMOVE CHARACTERS FROM THE FIFO UNTIL EITHER;
: * (A) THE FIFO IS PURGED, GO REPORT THE ERROR.
: * (B) THE MAXIMUM TRY COUNTER IS ZERO, GO REPORT THE ERROR.
: * (C) PROC_1'S ROM VERSION NUMBER WAS FOUND BEFORE PROC_2'S, GO REPORT ERROR.
: * (D) BOTH ROM VERSION NUMBERS HAVE BEEN FOUND.
:--
MOV #4*NUMLNS,R5 ;SET MAXIMUM TRY COUNTER.
MOV #99,R3 ;SET AN INVALID ROM VERSION NUMBER FOR PROC_1.
MOV R3,R4 ;SET AN INVALID ROM VERSION NUMBER FOR PROC_2.
MOV #1401,ERRNBR ;SET THE ERROR NUMBER TO 1401.
MOV #EM1402,R1 ;SELECT MESSAGE TO BE REPORTED IF FIFO EMPTY.
2$: MOV @RBUFA,R2 ;READ THE NEXT CHAR FROM THE FIFO.
BPL 12$ ;GO REPORT ERROR IF FIFO EMPTY.
:++

```

CV
CV

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 141
HARDWARE TEST - ROMVER -

```

5922          : CHECK IF THE READ DATA IS A BMP CODE.
5923          :-
5924 023766 012700 000301      MOV    #301,R0      ;SET-UP A BIT MASK OF A BMP CODE.
5925 023772 040200          BIC    R2,R0      ;TRY TO CLEAR THE BIT MASK WITH THE READ DATA.
5926 023774 001003          BNE    4$        ;BRANCH IF NOT A BMP CODE.
5927 023776 004737 016032      JSR    PC,SAVBMP  ;SAVE THE BMP CODE ON THE QUEUE.
5928 024002 000435          BR     8$        ;
5929
5930          :+
5931          : CHECK IF THE READ DATA IS A SELF-TEST CODE.
5932 024004 012700 000201      4$:    MOV    #201,R0      ;SET-UP A BIT MASK OF A SELFTEST CODE.
5933 024010 040200          BIC    R2,R0      ;TRY TO CLEAR THE BIT MASK WITH THE READ DATA.
5934 024012 001431          BEQ    8$        ;BRANCH IF IT IS A SELFTEST CODE.
5935
5936          :+
5937          : THE READ DATA IS A ROM VERSION NUMBER, DETERMINE WHICH ONE IT IS.
5938          :-
5939 024014 032702 000002      BIT    #BIT1,R2    ;CHECK THE PROCESSOR NUMBER BIT IN THE CODE.
5940 024020 001407          BEQ    6$        ;BRANCH IF IT IS PROC_1 ROM VERSION NUMBER.
5941 024022 010204          MOV    R2,R4      ;SAVE PROC_2 ROM VERSION NUMBER.
5942 024024 042704 177603      BIC    #177603,R4 ;CLEAR ANY UNWANTED BITS.
5943 024030 000241          CLC          ;CLEAR THE CARRY BIT.
5944 024032 006004          ROR    R4        ;SHIFT THE CODES ALONG TO GET THE ROM
5945 024034 006004          ROR    R4        ; VERSION NUMBER IN THE LOW 5 BITS.
5946 024036 000417          BR     8$        ;
5947 024040 010203          6$:    MOV    R2,R3      ;SAVE PROC_1 ROM VERSION NUMBER.
5948 024042 042703 177603      BIC    #177603,R3 ;CLEAR ANY UNWANTED BITS.
5949 024046 000241          CLC          ;CLEAR THE CARRY BIT.
5950 024050 006003          ROR    R3        ;SHIFT THE CODE ALONG TO GET THE ROM
5951 024052 006003          ROR    R3        ; VERSION NUMBER IN THE LOW 5 BITS.
5952 024054 020427 000143      CMP    R4,#99.    ;CHECK IF WE HAVE RECEIVE PROC 2 ROM CODE.
5953 024060 001016          BNE    10$       ;GO REPORT BOTH ROM VERSION NUMBERS.
5954
5955          :+
5956          : RECEIVED ROM VERSION NUMBERS OUT OF SEQUENCE.
5957          : IE, PROC_1'S ROM VERSION NUMBER FOUND IN THE FIFO BEFORE PROC_2'S.
5958          :-
5958 024062 012701 010512      MOV    #EM1403,R1 ;SELECT THE ERROR MESSAGE TO BE REPORTED.
5959 024066 012737 002572 002666  MOV    #1402.,ERRNBR ;SET THE ERROR NUMBER.
5960 024074 000433          BR     12$       ;GO REPORT ERROR.
5961
5962 024076 005305          8$:    DEC    R5        ;DECREMENT THE MAX TRY COUNTER.
5963 024100 001327          BNE    2$        ;LOOP TO GET THE NEXT CHAR FROM THE FIFO.
5964 024102 012701 010565      MOV    #EM1404,R1 ;SELECT THE ERROR MESSAGE TO BE REPORTED.
5965 024106 012737 002573 002666  MOV    #1403.,ERRNBR ;SET THE ERROR NUMBER.
5966 024114 000423          BR     12$       ;GIVE UP, GO REPORT ERROR.
5967
5968          :+
5969          : IF THIS IS THE FIRST PASS, AND SOFTWARE P-TABLE QUESTION WAS ANSWERED YES,
5970          : THEN REPORT THE ROM VERSION NUMBERS TO THE OPERATOR.
5971          :-
5971 024116 032737 000001 002204 10$:    BIT    #BIT0,OPTION ;CHECK ON THE STATE OF THE SOFTWARE SWITCH.
5972 024124 001431          BEQ    60$       ;EXIT IF NO ROM VERSION PRINTOUT WAS REQUESTED.
5973 024126 023727 002300 000001  CMP    PASCNT,#1  ;CHECK IF THIS IS THE FIRST PASS.
5974 024134 003025          BGT    60$       ;EXIT IF ROM VERS HAVE ALREADY BEEN REPORTED.
5975 024136          PRINTB #EF1401,R3,R4 ;PRINT THE ROM VERSION NUMBERS.
5976 024136 010446          MOV    R4,-(SP)
5977 024140 010346          MOV    R3,-(SP)

```

CVDHAAO DHV-11 FUNC TST PART1 MACY11 30A(1052) 12-JUL-83 10:52 PAGE 142
CVDHAA.P11 12-JUL-83 00:42 HARDWARE TEST - ROMVER -

```

5978 024142 012746 003035          MOV      #EF1401,-(SP)
5979 024146 012746 000003          MOV      #3,-(SP)
5980 024152 010600                   MOV      SP,R0
5981 024154 104414                   TRAP     C$PNTB
5982 024156 062706 000010          ADD      #10,SP
5983 024162 000412                   BR       60$          ;EXIT THIS TEST.
5984
5985      :-
5986      :- ERROR REPORTS:
5987 024164 012737 012622 002672 12$:  MOV      #ER1401,ERRBLK ;SELECT THE ERROR REPORTING ROUTINE.
5988 024172                   ERROR                   ;REPORT ERROR.          >>>>> ERROR <<<<<
5989 024172 104460                   TRAP     C$ERROR
5990 024174 000405                   BR       60$
5991
5992 024176 012737 002575 002666 50$:  MOV      #1405,ERRNBR  ;SET UP ERROR NUMBER FOR TSABRT RTN.
5993 024204 004737 016226                   JSR      PC,TSABRT    ;REPORT NON-TEST RELATED ERROR.
5994
5995      60$:  SETPRI  #PRI07          ;DISABLE ALL INTERRUPTS.
5996 024210 012700 000340                   MOV      #PRI07,R0
5997 024214 104441                   TRAP     C$SPRI
5998 024216 005037 002310                   CLR      CTRLCF
5999 024222                   ENDTST          ;INDICATE THAT WE COMPLETED THE TEST.
6000 024222                   L10040:
6001 024222 104401                   TRAP     C$SETST

```

CV
CV

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 143
HARDWARE TEST - REGWRW -

```

6002
6003
6004
6005
6006
6007
6008
6009
6010
6011 024224
6012 024224
6013 024224
6014 024224 012700 000240
6015 024230 104441
6016 000017
6017 024232 012737 000017 002274
6018 024240 012737 177777 002310
6019 024246 012737 000001 002664
6020 024254 012737 003101 002666
6021 024262 012737 010770 002670
6022 024270 005037 002420
6023 024274 012700 002422
6024 024300 004737 014026
6025
6026
6027
6028
6029
6030 024304 004737 015304
6031 024310 103402
6032 024312 000137 024434
6033
6034
6035
6036 024316 005237 002666
6037 024322 012702 000017
6038 024326 013704 002214
6039 024332 010214
6040 024334 011401
6041 024336 042701 177760
6042 024342 020102
6043 024344 001406
6044
6045 024346 012737 012752 002672
6046 024354 005003
6047 024356 005005
6048 024360
6049 024360 104460
6050 024362 005302
6051 024364 002362
6052
6053
6054
6055
6056
6057 024366 005237 002666

```

```

.SBTTL  HARDWARE TEST          - REGWRW -
:++ *****
: *
: *   - DEVICE REGISTER WORD ACCESS READ AND WRITE TEST -
: *
: * THIS TEST VERIFIES THAT THE DEVICE REGISTERS CAN BE READ AND WRITTEN
: * CORRECTLY USING WORD ACCESSES.
: *
:-- *****

      BGNSTST
      SETPRI #PRI05          ;ALLOW THE LTC TO INTERRUPT.
                                T15::
                                MOV #PRI05,R0
                                TRAP C$SPRI

      TNUM == TNUM + 1      ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
      MOV #TNUM,TSTNUM     ;SET UP THE TEST NUMBER. (16)
      MOV #-1,CTRLCF      ;INDICATE THAT WE ARE WITHIN A TEST.
      MOV #1,ERRTYP       ;SET UP DEVICE FATAL INDICATOR IN ERROR TYPE.
      MOV #1601,ERRNBR    ;SET UP ERROR NUMBER IN THE ERROR TABLE.
      MOV #EM1604,ERRMSG  ;SET UP ERROR MESSAGE FOR TEST IN ERROR TABLE.
      CLR ERSMRF          ;CLEAR THE ERROR SUMMARY FLAGS.
      MOV #ERCNTB,R0
      JSR PC,CLR16W       ;CLEAR THE ERROR COUNTER TABLE.

:++
: * RESET THE DUT TO A KNOWN STATE, DO NOT REMOVE THE STATUS CODES FROM THE FIFO.
: * CLEAR TX AND RX INTERRUPT ENABLE BITS IN THE CSR.
: * THIS SUBROUTINE REPORTS ERRORS >>>> 1601 <<<<<.
:--
      JSR PC,RESETT       ;RESET THE DHV-11, REPORT ANY ERRORS FOUND.
      BCS +6              ;FATAL RESET ERROR? NO, CONTINUE WITH TEST.
      JMP 60$             ;YES, EXIT THE TEST.

:++
: * VERIFY READ/WRITE CAPABILITY TO INDIRECT ADDRESS FIELD OF CSR
:--
      INC ERRNBR          ;SET THE ERROR REPORT NUMBER TO 1602.
      MOV #17,R2          ;SET LOOP COUNT.
      MOV CSRA,R4         ;GET CSR ADDRESS.
2$:  MOV R2,(R4)           ;WRITE COUNT TO CSR.
      MOV (R4),R1         ;READ BACK THE CONTENTS OF THE CSR
      BIC #177760,R1     ;MASK OUT ALL BUT THE IND.ADR.REG FIELD.
      CMP R1,R2          ;CHECK FOR CORRECT DATA WRITTEN/READ.
      BEQ 4$             ;IS EXPECTED DATA BAD? NO, SKIP ERROR REPORT.
      ;REPORT 'BAD BIT(S) IN DEVICE CSR REGISTER FOR LINE 0 (D)'.
      MOV #ER1601,ERRBLK ;SELECT THE PROPER ERROR REPORT ROUTINE.
      CLR R3              ;SET OFFSET TO 0 TO CAUSE REPORT OF CSR REG.
      CLR R5              ;CAUSE REPORT OF LINE 0.
      ERROR              ; >>>> ERROR # 1602 <<<<<
                                TRAP C$ERROR
4$:  DEC R2               ;DECREMENT LOOP COUNT/IND.ADD.REG ADDRESS.
      BGE 2$             ;LOOP BACK TO TEST NEXT ADDRESS IF NOT DONE.

:++
: * WRITE AND VERIFY 16 DATA PATTERNS IN ALL USED BITS OF ALL REGISTERS ON ALL
: * ACTIVE LINES. BEFORE WRITING EACH PATTERN, CLEAR ALL THE BITS.
: * REGTST ROUTINE REPORTS ERRORS WITH NUMBERS >>>> ERROR 1603 - 1605 <<<<<.
:--
      INC ERRNBR          ;SET THE ERROR NUMBER TO 1603.

```

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 144
HARDWARE TEST - REGWRW -

6058	024372	005003		
6059	024374	012704	000002	
6060	024400	004737	015046	
6061				
6062				
6063				
6064				
6065				
6066	024404	012737	003106	002666
6067	024412	005003		
6068	024414	005404		
6069	024416	004737	015046	
6070				
6071				
6072				
6073				
6074	024422	012737	003111	002666
6075	024430	004737	015256	
6076	024434	005037	002310	
6077	024440			
6078	024440			
6079	024440	104401		

```

CLR R3 ;INDICATE THAT WORD ACCESSES ARE TO BE USED.
MOV #2,R4 ;INDICATE R/W ACCESS, CLEAR FIRST.
JSR PC,REGTST ;WRITE AND VERIFY DATA PATTERNS.

```

```

:+
: WRITE AND VERIFY 16 DATA PATTERNS IN ALL USED BITS OF ALL REGISTERS ON ALL
: ACTIVE LINES. BEFORE WRITING EACH PATTERN, SET ALL THE BITS.
: REGTST ROUTINE REPORTS ERRORS WITH NUMBERS >>>> ERROR 1606 - 1608 <<<<.
:-

```

```

MOV #1606.,ERRNBR ;SET UP ERROR NUMBER FOR REGTST ROUTINE.
CLR R3 ;INDICATE THAT WORD ACCESSES ARE TO BE USED.
NEG R4 ;INDICATE R/W ACCESS, SET FIRST.
JSR PC,REGTST ;WRITE AND VERIFY DATA PATTERNS.

```

```

:+
: PRINT ERROR SUMMARY REPORTS IF NECESSARY.
: THE FOLLOWING ROUTINE REPORTS ERRORS WITH NUMBER >>>> ERROR # 1609 <<<<
:-

```

```

MOV #1609.,ERRNBR ;SET UP ERROR NUMBER FOR NEXT RTN.
JSR PC,REPSMR ;REPORT ERROR SUMMARY IF NECESSARY.
60$: CLR CTRLCF ;INDICATE THAT WE COMPLETED THE TEST.
ENDTST

```

```

L10041: TRAP C$ETST

```


CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 145
HARDWARE TEST - REGWRM -

```

6080 .SBTTL HARDWARE TEST - REGWRM -
6081 :+ *****
6082 :* - DEVICE REGISTER WORD ACCESS READ/MODIFY/WRITE TEST -
6083 :*
6084 :* THIS TEST VERIFIES THAT THE DEVICE REGISTERS CAN BE WRITTEN CORRECTLY
6085 :* USING WORD READ/MODIFY/WRITE ACCESSES.
6086 :*
6087 :-- *****
6088
6089 024442 BGNTST
6090 024442 T16::
6091 024442 SETPRI #PRI05 ;ALLOW THE LTC TO INTERRUPT.
6092 024442 012700 000240 MOV #PRI05,R0
6093 024446 104441 TRAP C$SPRI
6094 000020 TNUM == TNUM + 1 ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
6095 024450 012737 000020 002274 MOV #TNUM,TSTNUM ;SET UP THE TEST NUMBER. (17)
6096 024456 012737 177777 002310 MOV #-1,CTRLCF ;INDICATE THAT WE ARE WITHIN A TEST.
6097 024464 012737 000001 002664 MOV #1,ERRTYP ;SET UP DEVICE FATAL INDICATOR IN ERROR TYPE.
6098 024472 012737 003245 002666 MOV #1701,ERRNBR ;SET UP ERROR NUMBER IN THE ERROR TABLE.
6099 024500 012737 011036 002670 MOV #EM1701,ERRMSG ;SET UP ERROR MESSAGE FOR TEST IN ERROR TABLE.
6100 024506 005037 002420 CLR ERSMRF ;CLEAR THE ERROR SUMMARY FLAGS.
6101 024512 012700 002422 MOV #ERCNTB,R0
6102 024516 004737 014026 JSR PC,CLR16W ;CLEAR THE ERROR COUNTER TABLE.
6103
6104 :+ RESET THE DUT TO A KNOWN STATE, DO NOT REMOVE THE STATUS CODES FROM THE FIFO.
6105 : CLEAR TX AND RX INTERRUPT ENABLE BITS IN THE CSR.
6106 : THIS SUBROUTINE REPORTS ERRORS >>>> 1701 <<<<.
6107 :-
6108 024522 004737 015304 JSR PC,RESETT ;RESET THE DHV-11, REPORT ANY ERRORS FOUND.
6109 024526 103402 BCS +6 ;FATAL RESET ERROR? NO, CONTINUE WITH TEST.
6110 024530 000137 024656 JMP 60$ ;YES, EXIT THE TEST.
6111
6112 :+ VERIFY READ/MODIFY/WRITE CAPABILITY TO INDIRECT ADDRESS FIELD OF CSR
6113 :-
6114 024534 005237 002666 INC ERRNBR ;SET THE ERROR REPORT NUMBER TO 1702.
6115 024540 012702 000017 MOV #17,R2 ;SET LOOP COUNT.
6116 024544 013704 002214 MOV CSRA,R4 ;GET CSR ADDRESS.
6117 024550 042714 000017 2$: BIC #17,(R4) ;CLEAR THE DUT CSR USING READ/MODIFY/WRITE.
6118 024554 050214 BIS R2,(R4) ;WRITE COUNT TO CSR USING READ/MODIFY/WRITE.
6119 024556 011401 MOV (R4),R1 ;READ BACK THE CONTENTS OF THE CSR
6120 024560 042701 177760 BIC #177760,R1 ;MASK OUT ALL BUT THE IND.ADR.REG FIELD.
6121 024564 020102 CMP R1,R2 ;CHECK FOR CORRECT DATA WRITTEN/READ.
6122 024566 001406 BEQ 4$ ;IS EXPECTED DATA BAD? NO, SKIP ERROR REPORT.
6123 ;REPORT 'BAD BIT(S) IN DEVICE CSR REGISTER FOR LINE 0 (D)'.
6124 024570 012737 012752 002672 MOV #ER1601,ERRBLK ;SELECT THE PROPER ERROR REPORT ROUTINE.
6125 024576 005003 CLR R3 ;SET OFFSET TO 0 TO CAUSE REPORT OF CSR REG.
6126 024600 005005 CLR R5 ;CAUSE REPORT OF LINE 0.
6127 024602 ERROR ; >>>> ERROR # 1702 <<<<
6128 024602 104460 TRAP C$ERROR
6129 024604 005302 4$: DEC R2 ;DECREMENT LOOP COUNT/IND.ADD.REG ADDRESS.
6130 024606 002360 BGE 2$ ;LOOP BACK TO TEST NEXT ADDRESS IF NOT DONE.
6131
6132 :+ WRITE AND VERIFY 16 DATA PATTERNS IN ALL USED BITS OF ALL REGISTERS ON ALL
6133 : ACTIVE LINES USING R/M/W. BEFORE WRITING EACH PATTERN, CLEAR ALL THE BITS.
6134 : REGTST ROUTINE REPORTS ERRORS WITH NUMBERS >>>> ERROR 1703 - 1705 <<<<.
6135 :-

```

CVDHAAO DHV-11 FUNC TST PART1 MACY11 30A(1052) 12-JUL-83 10:52 PAGE 146
CVDHAA.P11 12-JUL-83 00:42 HARDWARE TEST - REGWRM -

6136 024610 005237 002666
6137 024614 005003
6138 024616 012704 000001
6139 024622 004737 015046

INC ERRNBR ;SET THE ERROR NUMBER TO 1703.
CLR R3 ;INDICATE THAT WORD ACCESSES ARE TO BE USED.
MOV #1,R4 ;INDICATE R/M/W ACCESS, CLEAR FIRST.
JSR PC,REGTST ;WRITE AND VERIFY DATA PATTERNS.

6140
6141
6142
6143
6144
6145 024626 012737 003252 002666
6146 024634 005003
6147 024636 005404
6148 024640 004737 015046

:+
: WRITE AND VERIFY 16 DATA PATTERNS IN ALL USED BITS OF ALL REGISTERS ON ALL
: ACTIVE LINES USING R/M/W. BEFORE WRITING EACH PATTERN, SET ALL THE BITS.
: REGTST ROUTINE REPORTS ERRORS WITH NUMBERS >>>> ERROR 1706 - 1708 <<<<.
:-
MOV #1706.,ERRNBR ;SET UP ERROR NUMBER FOR REGTST ROUTINE.
CLR R3 ;INDICATE THAT WORD ACCESSES ARE TO BE USED.
NEG R4 ;INDICATE R/M/W ACCESS, SET FIRST.
JSR PC,REGTST ;WRITE AND VERIFY DATA PATTERNS.

6149
6150
6151
6152

:+
: PRINT ERROR SUMMARY REPORTS IF NECESSARY.
: THE FOLLOWING ROUTINE REPORTS ERRORS WITH NUMBER >>>> ERROR # 1709 <<<<
:-

6153 024644 012737 003255 002666
6154 024652 004737 015256
6155 024656 005037 002310
6156 024662
6157 024662
6158 024662 104401

MOV #1709.,ERRNBR ;SET UP ERROR NUMBER FOR NEXT RTN.
JSR PC,REPSMR ;REPORT ERROR SUMMARY IF NECESSARY.
60\$: CLR CTRLCF ;INDICATE THAT WE COMPLETED THE TEST.
ENDTST

L10042: TRAP CSETST

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 147
HARDWARE TEST - REGBRW -

```

6159
6160
6161
6162
6163
6164
6165
6166
6167
6168 024664
6169 024664
6170 024664
6171 024664 012700 000240
6172 024670 104441
6173 000021
6174 024672 012737 000021 002274
6175 024700 012737 177777 002310
6176 024706 012737 000001 002664
6177 024714 012737 003411 002666
6178 024722 012737 011113 002670
6179 024730 005037 002420
6180 024734 012700 002422
6181 024740 004737 014026
6182
6183
6184
6185
6186
6187 024744 004737 015304
6188 024750 103402
6189 024752 000137 025130
6190 024756 012737 003412 002666
6191
6192
6193
6194
6195 024764 012702 000017
6196 024770 013704 002214
6197 024774 110214
6198 024776 111401
6199 025000 042701 177760
6200 025004 020102
6201 025006 001406
6202
6203 025010 012737 012752 002672
6204 025016 005003
6205 025020 005005
6206 025022
6207 025022 104460
6208 025024 005302
6209 025026 002362
6210
6211
6212
6213
6214

```

```

.SBTTL HARDWARE TEST - REGBRW -
:++ *****
: * - DEVICE REGISTER BYTE ACCESS READ AND WRITE TEST -
: *
: * THIS TEST VERIFIES THAT THE DEVICE REGISTERS CAN BE READ AND WRITTEN
: * CORRECTLY USING BYTE ACCESSES.
: *
:-- *****

BGNTST
                                T17::
SETPRI #PRI05                   ;ALLOW THE LTC TO INTERRUPT.
                                MOV #PRI05,RO
                                TRAP C$SPRI

TNUM == TNUM + 1                ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
MOV #TNUM,TSTNUM                ;SET UP THE TEST NUMBER. (18)
MOV #-1,CTRLCF                 ;INDICATE THAT WE ARE WITHIN A TEST.
MOV #1,ERRTYP                  ;SET UP DEVICE FATAL INDICATOR IN ERROR TYPE.
MOV #1801,ERRNBR               ;SET UP ERROR NUMBER IN THE ERROR TABLE.
MOV #EM1801,ERRMSG             ;SET UP ERROR MESSAGE FOR TEST IN ERROR TABLE.
CLR ERSMRF                     ;CLEAR THE ERROR SUMMARY FLAGS.
MOV #ERCNTB,RO                 ;
JSR PC,CLR16W                  ;CLEAR THE ERROR COUNTER TABLE.

:++
: RESET THE DUT TO A KNOWN STATE, DO NOT REMOVE THE STATUS CODES FROM THE FIFO.
: CLEAR TX AND RX INTERRUPT ENABLE BITS IN THE CSR.
: THIS SUBROUTINE REPORTS ERRORS >>>> 1801 <<<<.
:-
JSR PC,RESETT                  ;RESET THE DHV-11, REPORT ANY ERRORS FOUND.
BCS .+6                         ;FATAL RESET ERROR? NO, CONTINUE WITH TEST.
JMP 60$                         ;YES, EXIT THE TEST.
MOV #1802,ERRNBR                ;SET THE ERROR REPORT NUMBER TO 1802.

:++
: VERIFY READ/WRITE CAPABILITY TO INDIRECT ADDRESS FIELD OF CSR.
: USE BYTE ACCESSES.
:-
MOV #17,R2                      ;SET LOOP COUNT.
MOV CSRA,R4                     ;GET CSR ADDRESS.
2$: MOVB R2,(R4)                 ;WRITE COUNT TO CSR.
    MOVB (R4),R1                ;READ BACK THE CONTENTS OF THE CSR
    BIC #177760,R1              ;MASK OUT ALL BUT THE IND.ADR.REG FIELD.
    CMP R1,R2                   ;CHECK FOR CORRECT DATA WRITTEN/READ.
    DEQ 4$                      ;IS EXPECTED DATA BAD? NO, SKIP ERROR REPORT.
    ;REPORT 'BAD BIT(S) IN DEVICE CSR REGISTER FOR LINE 0 (D)..'
    MOV #ER1601,ERRBLK          ;SELECT THE PROPER ERROR REPORT ROUTINE.
    CLR R3                      ;SET OFFSET TO 0 TO CAUSE REPORT OF CSR REG.
    CLR R5                      ;CAUSE REPORT OF LINE 0.
    ERROR                       ; >>>> ERROR # 1802 <<<<
                                TRAP C$ERROR
4$: DEC R2                      ;DECREMENT LOOP COUNT/IND.ADD.REG ADDRESS.
    BGE 2$                      ;LOOP BACK TO TEST NEXT ADDRESS IF NOT DONE.

:++
: WRITE AND VERIFY 16 DATA PATTERNS IN ALL USED BITS OF ALL LOWER BYTES OF ALL
: REGISTERS ON ALL ACTIVE LINES. USE READ/WRITE ACCESSES. BEFORE WRITING
: EACH PATTERN, CLEAR ALL THE USED BITS OF ALL ACTIVE REGISTERS.
: REGTST ROUTINE REPORTS ERRORS WITH NUMBERS >>>> ERROR 1803 - 1805 <<<<.

```

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 148
HARDWARE TEST - REGBRW -

```

6215
6216 025030 005237 002666      :-      INC      ERRNBR      ;SET THE ERROR NUMBER TO 1803.
6217 025034 012703 177777      MOV      #-1,R3      ;INDICATE THAT LO BYTE ACCESSES ARE TO BE USED.
6218 025040 012704 000002      MOV      #2,R4      ;INDICATE R/W ACCESS, CLEAR FIRST.
6219 025044 004737 015046      JSR      PC,REGTST   ;WRITE AND VERIFY DATA PATTERNS.
6220
6221      :+
6222      :WRITE AND VERIFY 16 DATA PATTERNS IN ALL USED BITS OF ALL HIGH BYTES OF ALL
6223      :REGISTERS ON ALL ACTIVE LINES. USE READ/WRITE ACCESSES. BEFORE WRITING
6224      :EACH PATTERN, CLEAR ALL THE USED BITS OF ALL ACTIVE REGISTERS.
6225      :REGTST ROUTINE REPORTS ERRORS WITH NUMBERS >>>> ERROR 1806 - 1808 <<<<.
6226 025050 012737 003416 002666      :-      MOV      #1806.,ERRNBR ;SET UP ERROR NUMBER FOR REGTST ROUTINE.
6227 025056 005403      NEG      R3          ;INDICATE THAT HI BYTE ACCESSES ARE TO BE USED.
6228 025060 004737 015046      JSR      PC,REGTST   ;WRITE AND VERIFY DATA PATTERNS.
6229
6230      :+
6231      :WRITE AND VERIFY 16 DATA PATTERNS IN ALL USED BITS OF ALL LOWER BYTES OF ALL
6232      :REGISTERS ON ALL ACTIVE LINES. USE READ/WRITE ACCESSES. BEFORE WRITING
6233      :EACH PATTERN, SET ALL THE USED BITS OF ALL ACTIVE REGISTERS.
6234      :REGTST ROUTINE REPORTS ERRORS WITH NUMBERS >>>> ERROR 1809 - 1811 <<<<.
6235 025064 012737 003421 002666      :-      MOV      #1809.,ERRNBR ;SET UP ERROR NUMBER FOR REGTST ROUTINE.
6236 025072 005403      NEG      R3          ;INDICATE THAT LO BYTE ACCESSES ARE TO BE USED.
6237 025074 005404      NEG      R4          ;INDICATE R/W ACCESS, SET FIRST.
6238 025076 004737 015046      JSR      PC,REGTST   ;WRITE AND VERIFY DATA PATTERNS.
6239
6240      :+
6241      :WRITE AND VERIFY 16 DATA PATTERNS IN ALL USED BITS OF ALL HIGH BYTES OF ALL
6242      :REGISTERS ON ALL ACTIVE LINES. USE READ/WRITE ACCESSES. BEFORE WRITING
6243      :EACH PATTERN, SET ALL THE USED BITS OF ALL ACTIVE REGISTERS.
6244      :REGTST ROUTINE REPORTS ERRORS WITH NUMBERS >>>> ERROR 1812 - 1814 <<<<.
6245 025102 012737 003424 002666      :-      MOV      #1812.,ERRNBR ;SET UP ERROR NUMBER FOR REGTST ROUTINE.
6246 025110 005403      NEG      R3          ;INDICATE THAT HI BYTE ACCESSES ARE TO BE USED.
6247 025112 004737 015046      JSR      PC,REGTST   ;WRITE AND VERIFY DATA PATTERNS.
6248
6249      :+
6250      :PRINT ERROR SUMMARY REPORTS IF NECESSARY.
6251      :THE FOLLOWING ROUTINE REPORTS ERRORS WITH NUMBER >>>> ERROR # 1815 <<<<
6252 025116 012737 003427 002666      :-      MOV      #1815.,ERRNBR ;SET UP ERROR NUMBER FOR NEXT RTN.
6253 025124 004737 015256      JSR      PC,REPSMR  ;REPORT ERROR SUMMARY IF NECESSARY.
6254 025130 005037 002310      60$:   CLR      CTRLCF  ;INDICATE THAT WE COMPLETED THE TEST.
6255 025134
6256 025134
6257 025134 104401

```

L10043: TRAP CSETST

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 149
HARDWARE TEST - REGBRM -

```

6258 .SBTTL HARDWARE TEST - REGBRM -
6259 :+ *****
6260 :* - DEVICE REGISTER BYTE ACCESS READ/MODIFY/WRITE TEST -
6261 :*
6262 :* THIS TEST VERIFIES THAT THE DEVICE REGISTERS CAN BE READ AND WRITTEN
6263 :* CORRECTLY USING BYTE ACCESSES IN READ/MODIFY/WRITE MODE.
6264 :*
6265 :-- *****
6266
6267 025136 BGNTST
6268 025136
6269 025136 SETPRI #PRI05 ;ALLOW THE LTC TO INTERRUPT. T18::
6270 025136 012700 000240 MOV #PRI05,R0
6271 025142 104441 TRAP C$SPRI
6272 000022 TNUM == TNUM + 1 ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
6273 025144 012737 000022 002274 MOV #TNUM,TSTNUM ;SET UP THE TEST NUMBER. (19)
6274 025152 012737 177777 002310 MOV #-1,CTRLCF ;INDICATE THAT WE ARE WITHIN A TEST.
6275 025160 012737 000001 002664 MOV #1,ERRTYP ;SET UP DEVICE FATAL INDICATOR IN ERROR TYPE.
6276 025166 012737 003555 002666 MOV #1901,ERRNBR ;SET UP ERROR NUMBER IN THE ERROR TABLE.
6277 025174 012737 011161 002670 MOV #EM1901,ERRMSG ;SET UP ERROR MESSAGE FOR TEST IN ERROR TABLE.
6278 025202 005037 002420 CLR ERSMRF ;CLEAR THE ERROR SUMMARY FLAGS.
6279 025206 012700 002422 MOV #ERCNTB,R0
6280 025212 004737 014026 JSR PC,CLR16W ;CLEAR THE ERROR COUNTER TABLE.
6281
6282 :+
6283 : CLEAR TX AND RX INTERRUPT ENABLE BITS IN THE CSR.
6284 : THIS SUBROUTINE REPORTS ERRORS >>>> 1901 <<<<.
6285 :-
6286 025216 004737 015304 JSR PC,RESETT ;RESET THE DHV-11, REPORT ANY ERRORS FOUND.
6287 025222 103402 BCS +6 ;FATAL RESET ERROR? NO, CONTINUE WITH TEST.
6288 025224 000137 025406 JMP 60$ ;YES, EXIT THE TEST.
6289 025230 012737 003556 002666 MOV #1902,ERRNBR ;SET THE ERROR REPORT NUMBER TO 1902.
6290
6291 :+
6292 : VERIFY READ/WRITE CAPABILITY TO INDIRECT ADDRESS FIELD OF CSR.
6293 : USE BYTE ACCESSES.
6294 :-
6294 025236 012702 000017 MOV #17,R2 ;SET LOOP COUNT.
6295 025242 013704 002214 MOV CSRA,R4 ;GET CSR ADDRESS.
6296 025246 142714 000017 2$: BICB #17,(R4) ;CLEAR THE DUT CSR USING READ/MODIFY/WRITE.
6297 025252 150214 BICB R2,(R4) ;WRITE COUNT TO CSR USING READ/MODIFY/WRITE.
6298 025254 111401 MOV R4,R1 ;READ BACK THE CONTENTS OF THE CSR
6299 025256 042701 177760 BIC #177760,R1 ;MASK OUT ALL BUT THE IND.ADR.REG FIELD.
6300 025262 020102 CMP R1,R2 ;CHECK FOR CORRECT DATA WRITTEN/READ.
6301 025264 001406 BEQ 4$ ;IS EXPECTED DATA BAD? NO, SKIP ERROR REPORT.
6302 :REPORT 'BAD BIT(S) IN DEVICE CSR REGISTER FOR LINE 0 (D).
6303 025266 012737 012752 002672 MOV #ER1601,ERRBLK ;SELECT THE PROPER ERROR REPORT ROUTINE.
6304 025274 005003 CLR R3 ;SET OFFSET TO 0 TO CAUSE REPORT OF CSR REG.
6305 025276 005005 CLR R5 ;CAUSE REPORT OF LINE 0.
6306 025300 ERROR ; >>>> ERROR # 1902 <<<<
6307 025300 104460 TRAP C$ERROR
6308 025302 005302 4$: DEC R2 ;DECREMENT LOOP COUNT/IND.ADD.REG ADDRESS.
6309 025304 002360 BGE 2$ ;LOOP BACK TO TEST NEXT ADDRESS IF NOT DONE.
6310
6311 :+
6312 : WRITE AND VERIFY 16 DATA PATTERNS IN ALL USED BITS OF ALL LOWER BYTES OF ALL
6313 : REGISTERS ON ALL ACTIVE LINES. USE READ/MODIFY/WRITE ACCESSES. BEFORE
: WRITING EACH PATTERN, CLEAR ALL THE USED BITS OF ALL ACTIVE REGISTERS.

```

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 150
HARDWARE TEST - REGBRM -

```

6314      : REGTST ROUTINE REPORTS ERRORS WITH NUMBERS >>>> ERROR 1903 - 1905 <<<<.
6315      :-
6316 025306 005237 002666      INC   ERRNBR      ;SET THE ERROR NUMBER TO 1903.
6317 025312 012703 177777      MOV   #-1,R3      ;INDICATE THAT LO BYTE ACCESSES ARE TO BE USED.
6318 025316 012704 000001      MOV   #1,R4      ;INDICATE R/M/W ACCESS, CLEAR FIRST.
6319 025322 004737 015046      JSR   PC,REGTST  ;WRITE AND VERIFY DATA PATTERNS.
6320
6321      +
6322      : WRITE AND VERIFY 16 DATA PATTERNS IN ALL USED BITS OF ALL HIGH BYTES OF ALL
6323      : REGISTERS ON ALL ACTIVE LINES. USE READ/MODIFY/WRITE ACCESSES. BEFORE
6324      : WRITING EACH PATTERN, CLEAR ALL THE USED BITS OF ALL ACTIVE REGISTERS.
6325      : REGTST ROUTINE REPORTS ERRORS WITH NUMBERS >>>> ERROR 1906 - 1908 <<<<.
6326 025326 012737 003562 002666      MOV   #1906.,ERRNBR ;SET UP ERROR NUMBER FOR REGTST ROUTINE.
6327 025334 005403                NEG   R3           ;INDICATE THAT HI BYTE ACCESSES ARE TO BE USED.
6328 025336 004737 015046      JSR   PC,REGTST  ;WRITE AND VERIFY DATA PATTERNS.
6329
6330      +
6331      : WRITE AND VERIFY 16 DATA PATTERNS IN ALL USED BITS OF ALL LOWER BYTES OF ALL
6332      : REGISTERS ON ALL ACTIVE LINES. USE READ/MODIFY/WRITE ACCESSES. BEFORE
6333      : WRITING EACH PATTERN, SET ALL THE USED BITS OF ALL ACTIVE REGISTERS.
6334      : REGTST ROUTINE REPORTS ERRORS WITH NUMBERS >>>> ERROR 1909 - 1911 <<<<.
6335 025342 012737 003565 002666      MOV   #1909.,ERRNBR ;SET UP ERROR NUMBER FOR REGTST ROUTINE.
6336 025350 005403                NEG   R3           ;INDICATE THAT LO BYTE ACCESSES ARE TO BE USED.
6337 025352 005404                NEG   R4           ;INDICATE R/M/W ACCESS, SET FIRST.
6338 025354 004737 015046      JSR   PC,REGTST  ;WRITE AND VERIFY DATA PATTERNS.
6339
6340      +
6341      : WRITE AND VERIFY 16 DATA PATTERNS IN ALL USED BITS OF ALL HIGH BYTES OF ALL
6342      : REGISTERS ON ALL ACTIVE LINES. USE READ/MODIFY/WRITE ACCESSES. BEFORE
6343      : WRITING EACH PATTERN, SET ALL THE USED BITS OF ALL ACTIVE REGISTERS.
6344      : REGTST ROUTINE REPORTS ERRORS WITH NUMBERS >>>> ERROR 1912 - 1914 <<<<.
6345 025360 012737 003570 002666      MOV   #1912.,ERRNBR ;SET UP ERROR NUMBER FOR REGTST ROUTINE.
6346 025366 005403                NEG   R3           ;INDICATE THAT HI BYTE ACCESSES ARE TO BE USED.
6347 025370 004737 015046      JSR   PC,REGTST  ;WRITE AND VERIFY DATA PATTERNS.
6348
6349      +
6350      : PRINT ERROR SUMMARY REPORTS IF NECESSARY.
6351      : THE FOLLOWING ROUTINE REPORTS ERRORS WITH NUMBER >>>> ERROR # 1915 <<<<
6352 025374 012737 003573 002666      MOV   #1915.,ERRNBR ;SET UP ERROR NUMBER FOR NEXT RTN.
6353 025402 004737 015256      JSR   PC,REPSMR  ;REPORT ERROR SUMMARY IF NECESSARY.
6354 025406 005037 002310      60$: CLR   CTRLCF ;INDICATE THAT WE COMPLETED THE TEST.
6355 025412
6356 025412
6357 025412 104401

```

L10044: TRAP CSETST

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 153
HARDWARE TEST - REPBMP -

6436
6437
6438
6439
6440
6441
6442
6443
6444
6445
6446
6447
6448
6449
6450
6451
6452
6453
6454
6455
6456
6457
6458
6459
6460
6461
6462
6463
6464
6465
6466
6467
6468
6469
6470
6471
6472
6473
6474
6475
6476
6477
6478
6479
6480

.SBTTL HARDWARE PARAMETER CODING SECTION

;++
: THE HARDWARE PARAMETER CODING SECTION CONTAINS MACROS
: THAT ARE USED BY THE SUPERVISOR TO BUILD P-TABLES. THE
: MACROS ARE NOT EXECUTED AS MACHINE INSTRUCTIONS BUT ARE
: INTERPRETED BY THE SUPERVISOR AS DATA STRUCTURES. THE
: MACROS ALLOW THE SUPERVISOR TO ESTABLISH COMMUNICATIONS
: WITH THE OPERATOR.
:--

BGNHRD

000011

.WORD L10047-L\$HARD/2
L\$HARD::

:DEVICE CSR ADDRESS QUESTION:
GPRMA HWPTQ1,0,0,160000,177776,YES

.WORD TSCODE
.WORD HWPTQ1
.WORD TSLOLIM
.WORD TSHILIM

:ACTIVE LINES BIT MAP QUESTION:
GPRMD HWPTQ3,2,0,MAPLNS,0,MAPLNS,YES

.WORD TSCODE
.WORD HWPTQ3
.WORD MAPLNS
.WORD TSLOLIM
.WORD TSHILIM

ENDHRD

.EVEN
L10047:

HWPTQ1: .ASCIZ /CSR ADDRESS: /

HWPTQ3: .ASCIZ /ACTIVE LINE BIT MAP: /

.EVEN

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 154
HARDWARE PARAMETER CODING SECTION

6481
6482
6483
6484
6485
6486
6487
6488
6489
6490
6491
6492
6493
6494 025700
6495 025700 000013
6496 025702
6497
6498
6499 025702
6500 025702 000130
6501 025704 025730
6502 025706 000020
6503
6504 025710
6505 025710 001052
6506 025712 026004
6507 025714 177777
6508 025716 000000
6509 025720 177777
6510
6511 025722
6512 025722 000130
6513 025724 026073
6514 025726 000001
6515
6516
6517
6518 025730
6519
6520 025730
6521
6522
6523 025730 042522 047520 052122
6524 025736 052440 044516 020124
6525 025744 052516 041115 051105
6526 025752 040440 020123 040505
6527 025760 044103 052440 044516
6528 025766 020124 051511 052040
6529 025774 051505 042524 035104
6530 026002 000040
6531 026004 052516 041115 051105
6532 026012 047440 020106 047111
6533 026020 044504 044526 052504
6534 026026 046101 042040 052101
6535 026034 020101 051105 047522
6536 026042 051522 052040 020117

.SBTTL SOFTWARE PARAMETER CODING SECTION

```

:++
: THE SOFTWARE PARAMETER CODING SECTION CONTAINS MACROS
: THAT ARE USED BY THE SUPERVISOR TO BUILD P-TABLES. THE
: MACROS ARE NOT EXECUTED AS MACHINE INSTRUCTIONS BUT ARE
: INTERPRETED BY THE SUPERVISOR AS DATA STRUCTURES. THE
: MACROS ALLOW THE SUPERVISOR TO ESTABLISH COMMUNICATIONS
: WITH THE OPERATOR.
:--

```

BGNSFT

.WORD L10050-L\$\$SOFT/2
L\$\$SOFT::

:UNIT NUMBER PRINTOUT QUESTION:
GPRML SWPTQ1,0,20,YES

.WORD T\$CODE
.WORD SWPTQ1
.WORD 20

:NUMBER OF INDIVIDUAL DATA ERRORS TO REPORT ON A LINE QUESTION:
GPRMD SWPTQ2,2,D,177777,0,177777,YES

.WORD T\$CODE
.WORD SWPTQ2
.WORD 177777
.WORD T\$LOLIM
.WORD T\$HILIM

:ROM VERSION PRINTOUT ON FIRST PASS QUESTION:
GPRML SWPTQ3,0,1,YES

.WORD T\$CODE
.WORD SWPTQ3
.WORD 1

.EVEN

ENDSFT

.EVEN
L10050:

SWPTQ1: .ASCIZ /REPORT UNIT NUMBER AS EACH UNIT IS TESTED: /

SWPTQ2: .ASCIZ /NUMBER OF INDIVIDUAL DATA ERRORS TO REPORT ON A LINE: /

CVDHAAO DHV-11 FUNC TST PART1 MACY11 30A(1052) 12-JUL-83 10:52 PAGE 155
CVDHAA.P11 12-JUL-83 00:42 SOFTWARE PARAMETER CODING SECTION

6537	026050	042522	047520	052122
6538	026056	047440	020116	020101
6539	026064	044514	042516	020072
6540	026072	000		
6541	026073	122	046517	053040
6542	026100	051105	044523	047117
6543	026106	050040	044522	052116
6544	026114	052517	020124	047117
6545	026122	052040	042510	043040
6546	026130	051111	052123	050040
6547	026136	051501	035123	000040
6548				

SWPTQ3: .ASCIZ /ROM VERSION PRINTOUT ON THE FIRST PASS: /

.EVEN

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 156
SOFTWARE PARAMETER CODING SECTION

```

6549
6550
6551 026144
6552 026144 000024
6553
6554
6555
6556
6557
6558 026214
6559
6560 026214 000000
6561 026216 000000
6562 026220
6563 026220
6564
6565
6566
6567
6568
6569
6570
6571

```

SPATCH::

.BLKW 24

LASTAD

.EVEN 0

.WORD 0

.WORD 0

LSLAST::

ENDMOD

000001

.END

CVI
CVI
TS
TS
TS
TS
T1
T1
T1
T1
T1
T1
T1
T1
T1
T1
T1
T1
T2
T2
T3
T4
T5
T6
T7
T8
T9
UA
UN
UN
UN
WA
WD
WC
XS
XS
XS
XS
SF

CVDHAAO DHV-11 FUNC TST PART1 MACY11 30A(1052) 12-JUL-83 10:52 PAGE 159
CVDHAA.P11 12-JUL-83 00:42 CROSS REFERENCE TABLE -- USER SYMBOLS

C\$BRK = 000022	1014#	3318	4423															
C\$BSEG= 000004	1014#																	
C\$BSUB= 000002	1014#																	
C\$CEFG= 000045	1014#																	
C\$CLCK= 000062	1014#	4542																
C\$CLEA= 000012	1014#	4735																
C\$CLOS= 000035	1014#																	
C\$CLP1= 000006	1014#																	
C\$CVEC= 000036	1014#																	
C\$DCLN= 000044	1014#	4893																
C\$DODU= 000051	1014#	4890																
C\$DRPT= 000024	1014#																	
C\$DU = 000053	1014#	4774																
C\$EDIT= 000003	1014#	1079																
C\$ERDF= 000055	1014#	4883	5495	6425														
C\$ERHR= 000056	1014#																	
C\$ERRO= 000060	1014#	3489	3646	3717	3815	3854	3868	3932	3950	4115	4961	4968	4975					
	5048	5055	5062	5124	5131	5192	5199	5264	5271	5278	5341	5348	5355					
	5420	5428	5570	5577	5660	5727	5743	5750	5756	5854	5989	6049	6128					
	6207	6307	6394															
C\$ERSF= 000054	1014#	3306																
C\$ERSO= 000057	1014#																	
C\$ESCA= 000010	1014#																	
C\$ESEG= 000005	1014#																	
C\$ESUB= 000003	1014#																	
C\$ETST= 000001	1014#	4903	4983	5070	5139	5207	5286	5363	5436	5510	5589	5672	5768					
	5865	6001	6079	6158	6257	6357	6398	6435										
C\$EXIT= 000032	1014#	4727																
C\$GETB= 000026	1014#																	
C\$GETW= 000027	1014#																	
C\$GMAN= 000043	1014#																	
C\$GPHR= 000042	1014#	4629																
C\$GPLO= 000030	1014#																	
C\$GPRI= 000040	1014#																	
C\$INIT= 000011	1014#	4689																
C\$INLP= 000020	1014#																	
C\$MANI= 000050	1014#																	
C\$MEM = 000031	1014#																	
C\$MSG = 000023	1014#	2392	2471	2503	2569	2622	2670	2723	2768	2817	2894							
C\$OPEN= 000034	1014#																	
C\$PNTB= 000014	1014#	2372	2380	2456	2463	2498	2535	2604	2654	2663	2700	2755	2804					
	2848	5981																
C\$PNTF= 000017	1014#	3315	4675	4752														
C\$PNTS= 000016	1014#																	
C\$PNTX= 000015	1014#	2386	2564	2611	2618	2714	2763	2812	2874	2886								
C\$QIO = 000377	1014#																	
C\$RDBU= 000007	1014#																	
C\$REFG= 000047	1014#	4512	4518	4524	4530													
C\$RESE= 000033	1014#	4536	4609	4724	4936	5016												
C\$REVI= 000003	1014#	1078																
C\$RFLA= 000021	1014#																	
C\$RPT = 000025	1014#	4475																
C\$SEFG= 000046	1014#																	
C\$SPRI= 000041	1014#	4565	4685	4918	4979	4998	5066	5083	5135	5152	5203	5220	5282					
	5299	5359	5376	5432	5453	5506	5525	5585	5603	5668	5685	5764	5783					
	5861	5881	5997	6015	6093	6172	6271	6370										

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 161
CROSS REFERENCE TABLE -- USER SYMBOLS

EM0602	006452	G	1984#	5269																		
EM0603	006632	G	2004#	5276																		
EM0701	007015	G	2024#	5304																		
EM0702	007052	G	2029#	5346																		
EM0703	007232	G	2049#	5353																		
EM0801	007415	G	2069#	5381																		
EM0802	007455	G	2075#	5426																		
EM0901	007530	G	2083#	5497																		
EM0902	007561	G	2088#	5493																		
EM1001	007615	G	2093#	5530																		
EM1002	007661	G	2100#	5568																		
EM1003	007746	G	2109#	5575																		
EM1101	010024	G	2117#	5608																		
EM1201	010050	G	2121#	5690																		
EM1202	010067	G	2124#	5741																		
EM1203	010153	G	2133#	5754																		
EM1204	010231	G	2141#	5748																		
EM1205	010265	G	2146#	5658	5725																	
EM1301	010311	G	2150#	5788																		
EM1302	010335	G	2154#	5852																		
EM1401	010374	G	2160#	5886																		
EM1402	010424	G	2164#	5917																		
EM1403	010512	G	2173#	5958																		
EM1404	010565	G	2181#	5964																		
EM1405	010637	G	2189#	2543																		
EM1406	010652	G	2191#	2550																		
EM1407	010665	G	2193#	2544	2551																	
EM1408	010677	G	2195#	2547	2554																	
EM1601	010705	G	2197#	3712																		
EM1604	010770	G	2206#	6021																		
EM1701	011036	G	2213#	6099																		
EM1801	011113	G	2221#	6178																		
EM1901	011161	G	2228#	6277																		
EM2001	011236	G	2236#	6376																		
EM2002	011300	G	2242#	6391																		
EM9009	011353	G	2250#																			
EM9010	011377	G	2254#																			
EM9014	011423	G	2258#	2696																		
EM9017	011517	G	2269#	3944																		
EM9018	011630	G	2282#	3808																		
EM9019	011640	G	2284#	3861																		
EM9020	011655	G	2287#	3847																		
EM9022	011701	G	2291#	3895																		
EM9023	011720	G	2294#	3906																		
EM9024	011742	G	2297#	3920																		
EM9026	011760	G	2300#																			
EM9301	012004	G	2304#	6427																		
EM9302	012024	G	2307#	2851																		
EM9303	012054	G	2311#	2869																		
EM9304	012121	G	2318#	6423																		
ENDIT	017632		4533	4679#																		
ERCNTB	002422	G	1415#	2709	3101	3104*	6023	6101	6180	6279												
ERRBLK	002672	G	1429#	3438*	3640*	3713*	3809*	3848*	3862*	3881*	3947*	4113*	4921*	5001*	5089*							
			5158*	5226*	5305*	5417*	5425*	5531*	5609*	5691*	5789*	5887*	5987*	6045*	6124*							
			6203*	6303*	6392*																	
ERRMSG	002670	G	1428#	2657	4920*	5000*	5088*	5157*	5225*	5304*	5381*	5530*	5608*	5690*	5788*							

CVDHAAO DHV-11 FUNC TST PART1 MACY11 30A(1052) 12-JUL-83 10:52 PAGE 165
 CVDHAA.P11 12-JUL-83 00:42 CROSS REFERENCE TABLE -- USER SYMBOLS

LSPRT	002112	G	1111#		
LSREPP	002062	G	1087#		
LSREV	002010	G	1043#		
LSRPT	017036	G	1088	4465#	
LSSOFT	025702	G	1054	6495	6496#
LSSPC	002056	G	1083#		
LSSPCP	002020	G	1053#		
LSSPTP	002024	G	1057#		
L\$STA	002030	G	1061#		
L\$SW	002204	G	1058	1184	1185#
L\$TEST	002114	G	1113#		
L\$TIML	002014	G	1049#		
L\$UNIT	002012	G	1047#	4624	4668
L10000	002202		1163	1171#	
L10001	002210		1184	1192#	
L10002	012300		2391#		
L10003	012574		2470#		
L10004	012620		2502#		
L10005	012750		2568#		
L10006	013046		2621#		
L10007	013126		2669#		
L10010	013230		2722#		
L10011	013306		2767#		
L10012	013370		2816#		
L10013	013550		2893#		
L10014	017042		4469	4474#	
L10016	017644		4688#		
L10017	017646		4707#		
L10020	017664		4728	4734#	
L10021	017774		4768	4773#	
L10022	020002		4789	4795#	
L10023	020272		4902#		
L10024	020522		4982#		
L10025	020766		5069#		
L10026	021164		5138#		
L10027	021356		5206#		
L10030	021574		5285#		
L10031	022002		5362#		
L10032	022210		5435#		
L10033	022376		5509#		
L10034	022612		5588#		
L10035	023040		5671#		
L10036	023322		5767#		
L10037	023622		5864#		
L10040	024222		6000#		
L10041	024440		6078#		
L10042	024662		6157#		
L10043	025134		6256#		
L10044	025412		6356#		
L10045	025526		6397#		
L10046	025606		6434#		
L10047	025634		6452	6470#	
L10050	025730		6495	6520#	
MAPLNS=	000377	G	1205#	6463	6465
MFUNIT	002772	G	1653#	4672	
MMENAB	002342	G	1378#	4600*	

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 167
CROSS REFERENCE TABLE -- USER SYMBOLS

RXBETX= 000020 G	1219#													
RXBFUL= 000100 G	1221#													
ROSLOT= 000002 G	1483#	3228*												
R1SLOT= 000004 G	1482#	3229*	4224*											
R2SLOT= 000006 G	1481#	3761*	4272*											
R3SLOT= 000010 G	1480#	3467	4340	4344										
R4SLOT= 000012 G	1479#	3555	3560	4349	4361									
R5SLOT= 000014 G	1478#	1588												
SAVBMP 016032 G	3384	3840	3925	3979#	5927									
SFPTBL 002204 G	1186#													
SKPSTS 016100 G	3698	4014#	4937	5017	5027	5099	5168	5236	5315	5391	5473	5549	5624	
	5902													
STAT 002222 G	1317#	6387												
STATO = 000006 G	1212#													
SVCGBL = 000000	1014#	1017#	1034	1043	1045	1047	1049	1051	1053	1055	1057	1059	1061	
	1063	1065	1067	1069	1071	1073	1075	1077	1080	1083	1085	1087	1089	
	1091	1093	1095	1097	1099	1101	1103	1105	1107	1109	1111	1113	1115	
	1117	1129	1164	1165	1185	1186	1425	1622	1631	2362	2443	2491	2528	
	2594	2645	2693	2746	2789	2839	4465	4485	4508	4703	4719	4746	4786	
	6453	6496	6562#	6563										
SVCINS= 000001	1014#	1035	1036	1037	1038	1039	1040	1041	1042	1044	1046	1048	1050	
	1052	1054	1056	1058	1060	1062	1064	1066	1068	1070	1072	1074	1076	
	1078	1079	1081	1082	1084	1086	1088	1090	1092	1094	1096	1098	1100	
	1102	1104	1106	1108	1110	1112	1114	1116	1118	1128	1130	1131	1132	
	1133	1134	1135	1136	1137	1138	1139	1140	1141	1142	1143	1144	1145	
	1146	1147	1148	1149	1163	1184	1623	1625	1632	1636	2369	2370	2371	
	2372	2373	2377	2378	2379	2380	2381	2383	2384	2385	2386	2387	2392	
	2452	2453	2454	2455	2456	2457	2459	2460	2461	2462	2463	2464	2471	
	2494	2495	2496	2497	2498	2499	2503	2531	2532	2533	2534	2535	2536	
	2559	2560	2561	2562	2563	2564	2565	2569	2599	2600	2601	2602	2603	
	2604	2605	2607	2608	2609	2610	2611	2612	2614	2615	2616	2617	2618	
	2619	2622	2650	2651	2652	2653	2654	2655	2659	2660	2661	2662	2663	
	2664	2670	2696	2697	2698	2699	2700	2701	2709	2710	2711	2712	2713	
	2714	2715	2723	2750	2751	2752	2753	2754	2755	2756	2758	2759	2760	
	2761	2762	2763	2764	2768	2799	2800	2801	2802	2803	2804	2805	2807	
	2808	2809	2810	2811	2812	2813	2817	2844	2845	2846	2847	2848	2849	
	2871	2872	2873	2874	2875	2880	2881	2882	2883	2884	2885	2886	2887	
	2894	3306	3307	3308	3309	3312	3313	3314	3315	3316	3318	3489	3646	
	3717	3815	3854	3868	3932	3950	4115	4423	4468	4469	4475	4511	4512	
	4514	4517	4518	4520	4523	4524	4526	4529	4530	4532	4536	4541	4542	
	4543	4554	4555	4556	4557	4558	4559	4564	4565	4609	4628	4629	4630	
	4632	4671	4672	4673	4674	4675	4676	4684	4685	4689	4708	4724	4727	
	4728	4735	4748	4749	4750	4751	4752	4753	4767	4768	4774	4788	4789	
	4796	4883	4884	4885	4886	4889	4890	4893	4903	4917	4918	4936	4961	
	4968	4975	4978	4979	4983	4997	4998	5016	5048	5055	5062	5065	5066	
	5070	5082	5083	5124	5131	5134	5135	5139	5151	5152	5192	5199	5202	
	5203	5207	5219	5220	5264	5271	5278	5281	5282	5286	5298	5299	5341	
	5348	5355	5358	5359	5363	5375	5376	5420	5428	5431	5432	5436	5452	
	5453	5495	5496	5497	5498	5505	5506	5510	5524	5525	5570	5577	5584	
	5585	5589	5602	5603	5660	5667	5668	5672	5684	5685	5727	5743	5750	
	5756	5763	5764	5768	5782	5783	5854	5860	5861	5865	5880	5881	5976	
	5977	5978	5979	5980	5981	5982	5989	5996	5997	6001	6014	6015	6049	
	6079	6092	6093	6128	6158	6171	6172	6207	6257	6270	6271	6307	6357	
	6369	6370	6394	6398	6425	6426	6427	6428	6435	6452	6457	6458	6459	
	6460	6463	6464	6465	6466	6467	6469	6495	6500	6501	6502	6505	6506	
	6507	6508	6509	6512	6513	6514	6519	6559	6560	6561				

CVDHAAO DHV-11 FUNC TST PART1 MACY11 30A(1052) 12-JUL-83 10:52 PAGE 168
 CVDHAA.P11 12-JUL-83 00:42 CROSS REFERENCE TABLE -- USER SYMBOLS

SVCSUB= 000001	1014#	1016#																
SVCTAG= 000001	1014#	1018#	1171	1192	2391	2470	2502	2568	2621	2669	2722	2767	2816					
	2893	4474	4688	4707	4734	4773	4795	4902	4982	5069	5138	5206	5285					
	5362	5435	5509	5588	5671	5767	5864	6000	6078	6157	6256	6356	6397					
	6434	6470	6520															
SVCTST= 000001	1014#	1015#	4813	4912	4992	5080	5149	5217	5296	5373	5450	5522	5600					
	5682	5780	5878	6012	6090	6169	6268	6367	6410									
SWAPO 016156 G	3550	3563	3572	3576	4059#													
SWPTQ1 025730	6501	6523#																
SWPTQ2 026004	6506	6531#																
SWPTQ3 026073	6513	6541#																
S&LSYM= 010000	1014#	1172#	1193#	2392#	2471#	2503#	2569#	2622#	2670#	2723#	2768#	2817#	2894#					
	4475#	4689#	4708#	4735#	4774#	4796#	4903#	4983#	5070#	5139#	5207#	5286#	5363#					
	5436#	5510#	5589#	5672#	5768#	5865#	6001#	6079#	6158#	6257#	6357#	6398#	6435#					
	6471#	6521#																
TIMER1 002322 G	1366#	2940*	2941	2958	4412	4414*												
TIMER2 002324 G	1367#	4415	4417*															
TIMER3 002326 G	1368#	4418*	4420*															
TNUM = 000024 G	4814#	4815	4913#	4914	4993#	4994	5084#	5085	5153#	5154	5221#	5222	5300#					
	5301	5377#	5378	5454#	5455	5526#	5527	5604#	5605	5686#	5687	5784#	5785					
	5882#	5883	6016#	6017	6094#	6095	6173#	6174	6272#	6273	6371#	6372	6411#					
	6412																	
TP4FLG 002304 G	1355#	3038*	3040	4453*	4576*	4595*	4833*											
TP4RTN 017014 G	4450#	4572	4594	4821														
TP4VEC 002302 G	1354#	4452	4571*	4581	4593*	4602	4820*	4878										
TSABRT 016226 G	4110#	5502	5581	5664	5760	5857	5993											
TSTNUM 002274 G	1351#	3982	4815*	4914*	4994*	5085*	5154*	5222*	5301*	5378*	5455*	5527*	5605*					
	5687*	5785*	5883*	6017*	6095*	6174*	6273*	6372*	6412*									
TXAD1A 002226 G	1319#																	
TXAD1O= 000012 G	1214#																	
TXAD2A 002230 G	1320#																	
TXAD2O= 000014 G	1215#																	
TXBFCA 002232 G	1321#	4029	5808*															
TXBFCA= 000016 G	1216#	3493	4374															
TXCHA 002216 G	1315#																	
TXCHRO= 000002 G	1210#																	
T\$ARGC= 000003	1035#	1036#	1037#	1038#	1039#	1040#	2369#	2373	2377#	2381	2383#	2387	2452#					
	2457	2459#	2464	2494#	2499	2531#	2536	2559#	2565	2599#	2605	2607#	2612					
	2614#	2619	2650#	2655	2659#	2664	2696#	2701	2709#	2715	2750#	2756	2758#					
	2764	2799#	2805	2807#	2813	2844#	2849	2871#	2875	2880#	2887	3312#	3316					
	4671#	4676	4748#	4753	5976#	5982												
	6457#	6463#	6500#	6505#	6512#													
T\$CODE= 000130	1014#	3307#	4884#	5496#	6426#													
T\$ERRN= 022125	6457#	6461	6463#	6468	6505#	6510												
T\$EXCP= 000000	4468#	4470	4727#	4767#	4769	4788#	4790											
T\$FLAG= 000050	1014#																	
T\$GMAN= 000000	6457#	6460	6463#	6467	6505#	6509												
T\$HILI= 177777	1014#	6560#																
T\$LAST= 000001	6457#	6459	6463#	6466	6505#	6508												
T\$LOLI= 000000	1014#	1172	1193	2392	2471	2503	2569	2622	2670	2723	2768	2817	2894					
T\$LSYM= 010000	4475	4689	4708	4735	4774	4796	4903	4983	5070	5139	5207	5286	5363					
	5436	5510	5589	5672	5768	5865	6001	6079	6158	6257	6357	6398	6435					
	6471	6521																
	6563#																	
T\$LTNO= 000024	1014#	1024#	1163#	1171#	1184#	1192#	2362#	2391#	2443#	2470#	2491#	2502#	2528#					
T\$NEST= 177777	2568#	2594#	2621#	2645#	2669#	2693#	2722#	2746#	2767#	2789#	2816#	2839#	2893#					

CVDHAAO DHV-11 FUNC TST PART1 MACY11 30A(1052) 12-JUL-83 10:52 PAGE 173
 CVDHAA.P11 12-JUL-83 00:42 CROSS REFERENCE TABLE -- MACRO NAMES

ENDSUB	1#	1014#													
ENDSW	1#	1014#	1191												
ENDTST	1#	1014#	4901	4981	5068	5137	5205	5284	5361	5434	5508	5587	5670	5766	5863
	5999	6077	6156	6255	6355	6396	6433								
EQUALS	1#	1014#	1224												
ERRDF	1#	1014#	4882	5494	6424										
ERRHRD	1#	1014#													
ERROR	1#	1014#	3488	3645	3716	3814	3853	3867	3931	3949	4114	4960	4967	4974	5047
	5054	5061	5123	5130	5191	5198	5263	5270	5277	5340	5347	5354	5419	5427	5569
	5576	5659	5726	5742	5749	5755	5853	5988	6048	6127	6206	6306	6393		
ERRSF	1#	1014#	3305												
ERRSOF	1#	1014#													
ERRTBL	1#	1014#	1424												
ESCAPE	1#	1014#													
EXIT	1#	1014#	4467	4726	4766	4787									
FEQUAL	1#	1014#													
GETBYT	1#	1014#													
GETPRI	1#	1014#													
GETWOR	1#	1014#													
GMANIA	1#	1014#													
GMANID	1#	1014#													
GMANIL	1#	1014#													
GPHARD	1#	1014#	4627												
GPRMA	1#	1014#	6456												
GPRMD	1#	1014#	6462	6504											
GPRML	1#	1014#	6499	6511											
HEADER	1#	1014#	1033												
INLOOP	1#	1014#													
IOSETU	1#	1014#													
IOSTAR	1#	1014#													
KT11	1#	1014#													
LASTAD	1#	1014#	6558												
MANUAL	1#	1014#													
MEMORY	1#	1014#													
MSBYTE	1#	1014#	1034#	1040	1041	1042									
MSCHEC	1#	1014#	4468#	4727#	4767#	4788#									
MSCNTO	1#	1014#	6457#	6463#	6500#	6505#	6512#								
MSCOUN	1#	1014#	2369#	2377#	2383#	2452#	2459#	2494#	2531#	2559#	2599#	2607#	2614#	2650#	2659#
	2696#	2709#	2750#	2758#	2799#	2807#	2844#	2871#	2880#	3312#	4671#	4748#	5976#		
MSDATA	1#	1014#	1034#	1043	1045	1047	1049	1051	1053	1055	1057	1059	1061	1063	1065
	1067	1069	1071	1073#	1075	1077	1080	1083	1085	1087	1089	1091	1093	1095	1097
	1099	1101	1103	1105	1107	1109	1111	1113	1115	1117	1622#	1631#			
MSDECR	1#	1014#	1171#	1192#	2391#	2470#	2502#	2568#	2621#	2669#	2722#	2767#	2816#	2893#	4474#
	4492#	4688#	4707#	4734#	4773#	4795#	4902#	4982#	5069#	5138#	5206#	5285#	5362#	5435#	5509#
	5588#	5671#	5767#	5864#	6000#	6078#	6157#	6256#	6356#	6397#	6434#	6469#	6519#	6564#	
MSDEFA	1#	1014#	6457#	6463#	6500#	6505#	6512#								
MSENDE	1#	1014#	1171#	1192#	2391#	2470#	2502#	2568#	2621#	2669#	2722#	2767#	2816#	2893#	4474#
	4688#	4707#	4734#	4773#	4795#	4902#	4982#	5069#	5138#	5206#	5285#	5362#	5435#	5509#	5588#
	5671#	5767#	5864#	6000#	6078#	6157#	6256#	6356#	6397#	6434#	6469#	6519#	6564#		
MSERRI	1#	1014#	3306#	4883#	5495#	6425#									
MSESCA	1#	1014#													
MSESCS	1#	1014#													
MSEXCP	1#	1014#	6457#	6463#	6505#										
MSEXIT	1#	1014#	4468#	4727#	4728	4767#	4788#								
MSEXSE	1#	1014#	4468#	4727#	4767#	4788#									
MSEXTJ	1#	1014#	4468#	4469	4727#	4767#	4768	4788#	4789						

CVDHAAO DHV-11 FUNC TST PART1 MACY11 30A(1052) 12-JUL-83 10:52 PAGE 174
 CVDHAA.P11 12-JUL-83 00:42 CROSS REFERENCE TABLE -- MACRO NAMES

MSGEN	1#	1014#	1034#	1043#	1045#	1047#	1049#	1051#	1053#	1055#	1057#	1059#	1061#	1063#	1065#
	1067#	1069#	1071#	1073#	1075#	1077#	1080#	1083#	1085#	1087#	1089#	1091#	1093#	1095#	1097#
	1099#	1101#	1103#	1105#	1107#	1109#	1111#	1113#	1115#	1117#	1129#	1164#	1165#	1171#	1185#
	1186#	1192#	1425#	1622#	1631#	2362#	2391#	2443#	2470#	2491#	2502#	2528#	2568#	2594#	2621#
	2645#	2669#	2693#	2722#	2746#	2767#	2789#	2816#	2839#	2893#	4465#	4474#	4485#	4508#	4688#
	4703#	4707#	4719#	4734#	4746#	4773#	4786#	4795#	4813#	4902#	4912#	4982#	4992#	5069#	5080#
	5138#	5149#	5206#	5217#	5285#	5296#	5362#	5373#	5435#	5450#	5509#	5522#	5588#	5600#	5671#
	5682#	5767#	5780#	5864#	5878#	6000#	6012#	6078#	6090#	6157#	6169#	6256#	6268#	6356#	6367#
	6397#	6410#	6434#	6453#	6470#	6496#	6520#	6562#							
MSGENB	1#	1014#													
MSGETS	1#	1014#	1171#	1192#	2391#	2470#	2502#	2568#	2621#	2669#	2722#	2767#	2816#	2893#	4474#
	4492#	4688#	4707#	4734#	4773#	4795#	4902#	4982#	5069#	5138#	5206#	5285#	5362#	5435#	5509#
	5588#	5671#	5767#	5864#	6000#	6078#	6157#	6256#	6356#	6397#	6434#	6469#	6519#	6564#	
MSGETT	1#	1014#	4468#	4727#	4767#	4788#									
MSGNGB	1#	1014#	1024#	1034#	1043#	1045#	1047#	1049#	1051#	1053#	1055#	1057#	1059#	1061#	1063#
	1065#	1067#	1069#	1071#	1073#	1075#	1077#	1080#	1083#	1085#	1087#	1089#	1091#	1093#	1095#
	1097#	1099#	1101#	1103#	1105#	1107#	1109#	1111#	1113#	1115#	1117#	1128#	1129	1163#	1164
	1165	1184#	1185	1186	1425#	1622#	1631#	2362#	2443#	2491#	2528#	2594#	2645#	2693#	2746#
	2789#	2839#	4465#	4485#	4508#	4703#	4719#	4746#	4786#	6452#	6453	6495#	6496	6559#	6562
MSGNIN	1#	1014#	1034#	1035	1036	1037	1038	1039	1040#	1041#	1042#	1043#	1044	1045#	1046
	1047#	1048	1049#	1050	1051#	1052	1053#	1054	1055#	1056	1057#	1058	1059#	1060	1061#
	1062	1063#	1064	1065#	1066	1067#	1068	1069#	1070	1071#	1072	1073#	1074	1075#	1076
	1077#	1078	1079	1080#	1081	1082#	1083#	1084	1085#	1086	1087#	1088	1089#	1090	1091#
	1092	1093#	1094	1095#	1096	1097#	1098	1099#	1100	1101#	1102	1103#	1104	1105#	1106
	1107#	1108	1109#	1110	1111#	1112	1113#	1114	1115#	1116	1117#	1118	1128#	1130#	1131#
	1132#	1133#	1134#	1135#	1136#	1137#	1138#	1139#	1140#	1141#	1142#	1143#	1144#	1145#	1146#
	1147#	1148#	1149#	1163#	1184#	1622#	1623	1625	1631#	1632	1636	2369#	2370#	2371	2372#
	2373	2377#	2378#	2379	2380#	2381	2383#	2384#	2385	2386#	2387	2392#	2452#	2453#	2454#
	2455	2456#	2457	2459#	2460#	2461#	2462	2463#	2464	2471#	2494#	2495#	2496#	2497	2498#
	2499	2503#	2531#	2532#	2533#	2534	2535#	2536	2559#	2560#	2561#	2562#	2563	2564#	2565
	2569#	2599#	2600#	2601#	2602#	2603	2604#	2605	2607#	2608#	2609#	2610	2611#	2612	2614#
	2615#	2616#	2617	2618#	2619	2622#	2650#	2651#	2652#	2653	2654#	2655	2659#	2660#	2661#
	2662	2663#	2664	2670#	2696#	2697#	2698#	2699	2700#	2701	2709#	2710#	2711#	2712#	2713
	2714#	2715	2723#	2750#	2751#	2752#	2753#	2754	2755#	2756	2758#	2759#	2760#	2761#	2762
	2763#	2764	2768#	2799#	2800#	2801#	2802#	2803	2804#	2805	2807#	2808#	2809#	2810#	2811
	2812#	2813	2817#	2844#	2845#	2846#	2847	2848#	2849	2871#	2872#	2873	2874#	2875	2880#
	2881#	2882#	2883#	2884#	2885	2886#	2887	2894#	3306#	3307#	3308#	3309#	3312#	3313#	3314
	3315#	3316	3318#	3489#	3646#	3717#	3815#	3854#	3868#	3932#	3950#	4115#	4423#	4468#	4469#
	4475#	4511#	4512#	4514#	4517#	4518#	4520#	4523#	4524#	4526#	4529#	4530#	4532#	4536#	4541#
	4542#	4543#	4554#	4555#	4556#	4557#	4558#	4559	4564#	4565#	4609#	4628#	4629#	4630#	4632#
	4671#	4672#	4673#	4674	4675#	4676	4684#	4685#	4689#	4708#	4724#	4727#	4728#	4735#	4748#
	4749#	4750#	4751	4752#	4753	4767#	4768#	4774#	4788#	4789#	4796#	4883#	4884#	4885#	4886#
	4889#	4890#	4893#	4903#	4917#	4918#	4936#	4961#	4968#	4975#	4978#	4979#	4983#	4997#	4998#
	5016#	5048#	5055#	5062#	5065#	5066#	5070#	5082#	5083#	5124#	5131#	5134#	5135#	5139#	5151#
	5152#	5192#	5199#	5202#	5203#	5207#	5219#	5220#	5264#	5271#	5278#	5281#	5282#	5286#	5298#
	5299#	5341#	5348#	5355#	5358#	5359#	5363#	5375#	5376#	5420#	5428#	5431#	5432#	5436#	5452#
	5453#	5495#	5496#	5497#	5498#	5505#	5506#	5510#	5524#	5525#	5570#	5577#	5584#	5585#	5589#
	5602#	5603#	5660#	5667#	5668#	5672#	5684#	5685#	5727#	5743#	5750#	5756#	5763#	5764#	5768#
	5782#	5783#	5854#	5860#	5861#	5865#	5880#	5881#	5976#	5977#	5978#	5979#	5980	5981#	5982
	5989#	5996#	5997#	6001#	6014#	6015#	6049#	6079#	6092#	6093#	6128#	6158#	6171#	6172#	6207#
	6257#	6270#	6271#	6307#	6357#	6369#	6370#	6394#	6398#	6425#	6426#	6427#	6428#	6435#	6452#
	6457#	6458	6459	6460	6463#	6464	6465	6466	6467	6469#	6495#	6500#	6501	6502	6505#
	6506	6507	6508	6509	6512#	6513	6514	6519#	6559#	6560#	6561#				
MSGNLS	1#	1014#													
MSGNSU	1#	1014#													
MSGNTA	1#	1014#	1171#	1192#	2391#	2470#	2502#	2568#	2621#	2669#	2722#	2767#	2816#	2893#	4474#

CVDHAAO DHV-11 FUNC TST PART1 MACY11 30A(1052) 12-JUL-83 10:52 PAGE 175
 CVDHAA.P11 12-JUL-83 00:42 CROSS REFERENCE TABLE -- MACRO NAMES

	4688#	4707#	4734#	4773#	4795#	4902#	4982#	5069#	5138#	5206#	5285#	5362#	5435#	5509#	5588#
	5671#	5767#	5864#	6000#	6078#	6157#	6256#	6356#	6397#	6434#	6469#	6470	6519#	6520	
MSGNTE	1#	1014#	4813#	4912#	4992#	5080#	5149#	5217#	5296#	5373#	5450#	5522#	5600#	5682#	5780#
	5878#	6012#	6090#	6169#	6268#	6367#	6410#								
MSHAPT	1#	1014#	1034#												
MSHNAP	1#	1014#	1034#	1073											
MSINCR	1#	1014#	1024#	1163#	1184#	2362#	2372#	2380#	2386#	2392#	2443#	2456#	2463#	2471#	2491#
	2498#	2503#	2528#	2535#	2564#	2569#	2594#	2604#	2611#	2618#	2622#	2645#	2654#	2663#	2670#
	2693#	2700#	2714#	2723#	2746#	2755#	2763#	2768#	2789#	2804#	2812#	2817#	2839#	2848#	2874#
	2886#	2894#	3306#	3315#	3318#	3489#	3646#	3717#	3815#	3854#	3868#	3932#	3950#	4115#	4423#
	4465#	4475#	4485#	4508#	4512#	4518#	4524#	4530#	4536#	4542#	4558#	4565#	4609#	4629#	4675#
	4685#	4689#	4703#	4708#	4719#	4724#	4727#	4735#	4746#	4752#	4774#	4786#	4796#	4813#	4814#
	4883#	4890#	4893#	4903#	4912#	4913#	4918#	4936#	4961#	4968#	4975#	4979#	4983#	4992#	4993#
	4998#	5016#	5048#	5055#	5062#	5066#	5070#	5080#	5081#	5083#	5124#	5131#	5135#	5139#	5149#
	5150#	5152#	5192#	5199#	5203#	5207#	5217#	5218#	5220#	5264#	5271#	5278#	5282#	5286#	5296#
	5297#	5299#	5341#	5348#	5355#	5359#	5363#	5373#	5374#	5376#	5420#	5428#	5432#	5436#	5450#
	5451#	5453#	5495#	5506#	5510#	5522#	5523#	5525#	5570#	5577#	5585#	5589#	5600#	5601#	5603#
	5660#	5668#	5672#	5682#	5683#	5685#	5727#	5743#	5750#	5756#	5764#	5768#	5780#	5781#	5783#
	5854#	5861#	5865#	5878#	5879#	5881#	5981#	5989#	5997#	6001#	6012#	6013#	6015#	6049#	6079#
	6090#	6091#	6093#	6128#	6158#	6169#	6170#	6172#	6207#	6257#	6268#	6269#	6271#	6307#	6357#
	6367#	6368#	6370#	6394#	6398#	6410#	6411#	6425#	6435#	6452#	6495#				
MSIOSE	1#	1014#													
MSLDRO	1#	1014#	4511#	4517#	4523#	4529#	4541#	4564#	4628#	4684#	4889#	4917#	4978#	4997#	5065#
	5082#	5134#	5151#	5202#	5219#	5281#	5298#	5358#	5375#	5431#	5452#	5505#	5524#	5584#	5602#
	5667#	5684#	5763#	5782#	5860#	5880#	5996#	6014#	6092#	6171#	6270#	6369#			
MSMASK	1#	1014#													
MSMCHI	1#	1014#													
MSMCLO	1#	1014#													
MSMSK1	1#	1014#													
MSPOP	1#	1014#	1171#	1192#	2391#	2470#	2502#	2568#	2621#	2669#	2722#	2767#	2816#	2893#	4474#
	4492#	4688#	4707#	4734#	4773#	4795#	4902#	4982#	5069#	5138#	5206#	5285#	5362#	5435#	5509#
	5588#	5671#	5767#	5864#	6000#	6078#	6157#	6256#	6356#	6397#	6434#	6469#	6519#	6564#	
MSPRIN	1#	1014#	2369#	2377#	2383#	2452#	2459#	2494#	2531#	2559#	2599#	2607#	2614#	2650#	2659#
	2696#	2709#	2750#	2758#	2799#	2807#	2844#	2871#	2880#	3312#	4671#	4748#	5976#		
MSPUSH	1#	1014#	1024#	1163#	1184#	2362#	2443#	2491#	2528#	2594#	2645#	2693#	2746#	2789#	2839#
	4465#	4485#	4508#	4703#	4719#	4746#	4786#	4813#	4814	4912#	4913	4992#	4993	5080#	5081
	5149#	5150	5217#	5218	5296#	5297	5373#	5374	5450#	5451	5522#	5523	5600#	5601	5682#
	5683	5780#	5781	5878#	5879	6012#	6013	6090#	6091	6169#	6170	6268#	6269	6367#	6368
	6410#	6411	6452#	6495#											
MSPUT	1#	1014#	2369#	2377#	2383#	2452#	2459#	2494#	2531#	2559#	2599#	2607#	2614#	2650#	2659#
	2696#	2709#	2750#	2758#	2799#	2807#	2844#	2871#	2880#	3312#	4554#	4671#	4748#	5976#	
MSPUT1	1#	1014#	2369#	2370	2377#	2378	2383#	2384	2452#	2453	2454	2459#	2460	2461	2494#
	2495	2496	2531#	2532	2533	2559#	2560	2561	2562	2599#	2600	2601	2602	2607#	2608
	2609	2614#	2615	2616	2650#	2651	2652	2659#	2660	2661	2696#	2697	2698	2709#	2710
	2711	2712	2750#	2751	2752	2753	2758#	2759	2760	2761	2799#	2800	2801	2802	2807#
	2808	2809	2810	2844#	2845	2846	2871#	2872	2880#	2881	2882	2883	2884	3312#	3313
	4554#	4555	4556	4557	4671#	4672	4673	4748#	4749	4750	5976#	5977	5978	5979	
MSRADI	1#	1014#	6457#	6463#	6500#	6505#	6512#								
MSRBRO	1#	1014#													
MSRNRO	1#	1014#	4541#	4543	4628#	4630									
MSSETS	1#	1014#	1024#	1163#	1184#	2362#	2443#	2491#	2528#	2594#	2645#	2693#	2746#	2789#	2839#
	4465#	4485#	4508#	4703#	4719#	4746#	4786#	4814#	4913#	4993#	5081#	5150#	5218#	5297#	5374#
	5451#	5523#	5601#	5683#	5781#	5879#	6013#	6091#	6170#	6269#	6368#	6411#	6452#	6495#	
MSSTAR	1#	1014#													
MS SVC	1#	1014#	2369#	2372	2377#	2380	2383#	2386	2391#	2392	2452#	2456	2459#	2463	2470#
	2471	2494#	2498	2502#	2503	2531#	2535	2559#	2564	2568#	2569	2599#	2604	2607#	2611

CVDHAAO DHV-11 FUNC TST PART1
CVDHAA.P11 12-JUL-83 00:42

MACY11 30A(1052) 12-JUL-83 10:52 PAGE 176
CROSS REFERENCE TABLE -- MACRO NAMES

	2614#	2618	2621#	2622	2650#	2654	2659#	2663	2669#	2670	2696#	2700	2709#	2714	2722#
	2723	2750#	2755	2758#	2763	2767#	2768	2799#	2804	2807#	2812	2816#	2817	2844#	2848
	2871#	2874	2880#	2886	2893#	2894	3306	3312#	3315	3318#	3489#	3646#	3717#	3815#	3854#
	3868#	3932#	3950#	4115#	4423#	4468#	4474#	4475	4511#	4512	4517#	4518	4523#	4524	4529#
	4530	4536#	4541#	4542	4554#	4558	4564#	4565	4609#	4628#	4629	4671#	4675	4684#	4685
	4688#	4689	4707#	4708	4724#	4727#	4734#	4735	4748#	4752	4767#	4773#	4774	4788#	4795#
	4796	4883	4889#	4890	4893#	4902#	4903	4917#	4918	4936#	4961#	4968#	4975#	4978#	4979
	4982#	4983	4997#	4998	5016#	5048#	5055#	5062#	5065#	5066	5069#	5070	5082#	5083	5124#
	5131#	5134#	5135	5138#	5139	5151#	5152	5192#	5199#	5202#	5203	5206#	5207	5219#	5220
	5264#	5271#	5278#	5281#	5282	5285#	5286	5298#	5299	5341#	5348#	5355#	5358#	5359	5362#
	5363	5375#	5376	5420#	5428#	5431#	5432	5435#	5436	5452#	5453	5495	5505#	5506	5509#
	5510	5524#	5525	5570#	5577#	5584#	5585	5588#	5589	5602#	5603	5660#	5667#	5668	5671#
	5672	5684#	5685	5727#	5743#	5750#	5756#	5763#	5764	5767#	5768	5782#	5783	5854#	5860#
	5861	5864#	5865	5880#	5881	5976#	5981	5989#	5996#	5997	6000#	6001	6014#	6015	6049#
	6078#	6079	6092#	6093	6128#	6157#	6158	6171#	6172	6207#	6256#	6257	6270#	6271	6307#
	6356#	6357	6369#	6370	6394#	6397#	6398	6425	6434#	6435					
M\$TLAB	1#	1014#	2372#	2380#	2386#	2392#	2456#	2463#	2471#	2498#	2503#	2535#	2564#	2569#	2604#
	2611#	2618#	2622#	2654#	2663#	2670#	2700#	2714#	2723#	2755#	2763#	2768#	2804#	2812#	2817#
	2848#	2874#	2886#	2894#	3306#	3315#	3318#	3489#	3646#	3717#	3815#	3854#	3868#	3932#	3950#
	4115#	4423#	4475#	4512#	4518#	4524#	4530#	4536#	4542#	4558#	4565#	4609#	4629#	4675#	4685#
	4689#	4708#	4724#	4727#	4735#	4752#	4774#	4796#	4883#	4890#	4893#	4903#	4918#	4936#	4961#
	4968#	4975#	4979#	4983#	4998#	5016#	5048#	5055#	5062#	5066#	5070#	5083#	5124#	5131#	5135#
	5139#	5152#	5192#	5199#	5203#	5207#	5220#	5264#	5271#	5278#	5282#	5286#	5299#	5341#	5348#
	5355#	5359#	5363#	5376#	5420#	5428#	5432#	5436#	5453#	5495#	5506#	5510#	5525#	5570#	5577#
	5585#	5589#	5603#	5660#	5668#	5672#	5685#	5727#	5743#	5750#	5756#	5764#	5768#	5783#	5854#
	5861#	5865#	5881#	5981#	5989#	5997#	6001#	6015#	6049#	6079#	6093#	6128#	6158#	6172#	6207#
	6257#	6271#	6307#	6357#	6370#	6394#	6398#	6425#	6435#						
M\$STL	1#	1014#	2372#	2380#	2386#	2392#	2456#	2463#	2471#	2498#	2503#	2535#	2564#	2569#	2604#
	2611#	2618#	2622#	2654#	2663#	2670#	2700#	2714#	2723#	2755#	2763#	2768#	2804#	2812#	2817#
	2848#	2874#	2886#	2894#	3306#	3315#	3318#	3489#	3646#	3717#	3815#	3854#	3868#	3932#	3950#
	4115#	4423#	4475#	4512#	4518#	4524#	4530#	4536#	4542#	4558#	4565#	4609#	4629#	4675#	4685#
	4689#	4708#	4724#	4727#	4735#	4752#	4774#	4796#	4883#	4890#	4893#	4903#	4918#	4936#	4961#
	4968#	4975#	4979#	4983#	4998#	5016#	5048#	5055#	5062#	5066#	5070#	5083#	5124#	5131#	5135#
	5139#	5152#	5192#	5199#	5203#	5207#	5220#	5264#	5271#	5278#	5282#	5286#	5299#	5341#	5348#
	5355#	5359#	5363#	5376#	5420#	5428#	5432#	5436#	5453#	5495#	5506#	5510#	5525#	5570#	5577#
	5585#	5589#	5603#	5660#	5668#	5672#	5685#	5727#	5743#	5750#	5756#	5764#	5768#	5783#	5854#
	5861#	5865#	5881#	5981#	5989#	5997#	6001#	6015#	6049#	6079#	6093#	6128#	6158#	6172#	6207#
	6257#	6271#	6307#	6357#	6370#	6394#	6398#	6425#	6435#						
M\$WORD	1#	1014#	1073#	1082	1128#	1130	1131	1132	1133	1134	1135	1136	1137	1138	1139
	1140	1141	1142	1143	1144	1145	1146	1147	1148	1149	3306#	3307	3308	3309	4468#
	4727#	4767#	4788#	4883#	4884	4885	4886	5495#	5496	5497	5498	6425#	6426	6427	6428
	6457#	6463#	6500#	6505#	6512#	6560	6561								
M\$XFER	1#	1014#													
OPEN	1#	1014#													
PASS	1544#	2388	2466	2666	2889	3007	3044	3069	3113	3143	3227	3280	3320	3392	3504
	3604	3648	3727	3760	3953	3991	4034	4127	4223	4271	4386				
POINTE	1#	1014#	1030												
PRINTB	1#	1014#	2368	2376	2451	2458	2493	2530	2598	2649	2658	2695	2749	2798	2843
	5975														
PRINTF	1#	1014#	3311	4670	4747										
PRINTS	1#	1014#													
PRINTX	1#	1014#	2382	2558	2606	2613	2708	2757	2806	2870	2879				
READBU	1#	1014#													
READEF	1#	1014#	4510	4516	4522	4528									
RFLAGS	1#	1014#													
SAVE	1503#	2363	2444	2646	2840	2930	3036	3063	3095	3134	3186	3271	3302	3364	3436

CVDHAAO DHV-11 FUNC TST PART1 MACY11 30A(1052) 12-JUL-83 10:52 PAGE 177
 CVDHAA.P11 12-JUL-83 00:42 CROSS REFERENCE TABLE -- MACRO NAMES

SETPRI	3535	3633	3676	3751	3794	3979	4014	4110	4153	4256	4317				
	1#	1014#	4563	4683	4916	4977	4996	5064	5081	5133	5150	5201	5218	5280	5297
	5357	5374	5430	5451	5504	5523	5583	5601	5666	5683	5762	5781	5859	5879	5995
	6013	6091	6170	6269	6368										
SETVEC	1#	1014#	4553												
SLASH	1#	1014#													
STARS	1#	1014#													
SVC	1#	1012#	1013												
XFER	1#	1014#	4468#	4727#	4767#	4788#									
XFERF	1#	1014#													
XFERT	1#	1014#													

. ABS. 026220 000

ERRORS DETECTED: 0

CVDHAA.BIC,CVDHAA.LST/CRF/NL:TOC/SOL=SVC34R.MLB,CVDHAA.P11
 RUN-TIME: 18 25 2 SECONDS
 RUN-TIME RATIO: 335/46=7.1
 CORE USED: 16K (31 PAGES)