

The table consists of 12 rows and 4 columns of small, dense diagrams or data tables. Each cell contains technical information, likely related to the DMA interface. The content is too small to read in detail but appears to be organized into a structured grid.



5624  
5625  
5626  
5627  
5628  
5629  
5630  
5631  
5632  
5633  
5634  
5635  
5636  
5637  
5638  
5639  
5640  
5641  
5642  
5643  
5644  
5645  
5646  
5647  
5648  
5649  
5650  
5651  
5652  
5653  
5654  
5655  
5656  
5657  
5658  
5659  
5660  
5661  
5662  
5663  
5664  
5665  
5666  
5667  
5668  
5669  
5670  
5671

.REM #

IDENTIFICATION  
-----

PRODUCT CODE: AC-8178C-MC  
PRODUCT NAME: CVDRACO DRV11B DMA INTFC DIAG  
DATE: JUNE 1985  
MAINTAINER: DIAGNOSTIC ENGINEERING

COPYRIGHT (C) 1976,1985  
DIGITAL EQUIPMENT CORPORATION, MAYNARD, MASS.  
THIS SOFTWARE IS FURNISHED UNDER A LICENSE FOR USE ONLY ON A SINGLE  
COMPUTER SYSTEM AND MAY BE COPIED ONLY WITH THE INCLUSION OF THE ABOVE  
COPYRIGHT NOTICE. THIS SOFTWARE, OR ANY OTHER COPIES THEREOF, MAY NOT  
BE PROVIDED OR OTHERWISE MADE AVAILABLE TO ANY OTHER PERSON EXCEPT FOR  
USE ON SUCH SYSTEM AND TO ONE WHO AGREES TO THESE LICENSE TERMS. TITLE  
TO AND OWNERSHIP OF THE SOFTWARE SHALL AT ALL TIMES REMAIN IN DEC.

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND  
SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION.

DEC ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE  
ON EQUIPMENT WHICH IS NOT SUPPLIED BY DEC.



5673  
5674  
5675  
5676  
5677  
5678  
5679  
5680  
5681  
5682  
5683  
5684  
5685  
5686  
5687  
5688  
5689

HISTORY

-----  
REVISION A :FIRST RELEASE OF DIAGNOSTIC  
REVISION B :THIS REVISION WAS MADE TO SUPPORT 11/23-B  
REVISION C :THIS REVISION WAS MADE TO SUPPORT ORION (11/73)CPU  
SEE ;DD001



5691  
5692  
5693  
5694  
5695  
5696  
5697  
5698  
5699  
5700  
5701  
5702  
5703  
5704  
5705  
5706  
5707  
5708  
5709  
5710  
5711  
5712  
5713  
5714  
5715  
5716  
5717  
5718  
5719  
5720  
5721  
5722  
5723  
5724  
5725  
5726  
5727  
5728  
5729  
5730  
5731  
5732  
5733  
5734  
5735  
5736  
5737  
5738  
5739

TABLE OF CONTENTS

-----

1.0	ABSTRACT
2.0	REQUIREMENTS
2.1	EQUIPMENT
2.2	STORAGE
3.0	LOADING PROCEDURE
4.0	STARTING PROCEDURE
4.1	PROGRAM START
5.0	SOFTWARE SWITCH REGISTER
5.1	OPTIONS
5.2	CONTROL
6.0	ERROR REPORTING
6.1	ERROR COMMENT
6.2	ERROR DATA
7.0	MISCELLANEOUS
7.1	DRV11B BUS & VECTOR ADDRESS MODIFICATION
7.2	XXDP/APT NOTES
7.3	POWER FAIL
7.4	MULTIPLE DRV11B INTERFACE TESTING
7.5	RESTRICTIONS
8.0	EXECUTION TIME
9.0	PROGRAM TEST DESCRIPTIONS
9.1	GENERAL
9.2	REGISTER TESTS
9.3	BYTE ADDRESSING TESTS
9.4	'FNCT' TO 'STAT' WRAP AROUND TEST
9.5	READY INTERRUPT TEST
9.6	NPR DATA TRANSFER TESTS
9.7	MAINT MODE NPR DATA TRANSFER TESTS
9.8	BURST & NON-BURST MODE TESTS
9.9	'NEX' ERROR CONDITION TEST
10.0	LISTING



5741  
5742  
5743  
5744  
5745  
5746  
5747  
5748  
5749  
5750  
5751  
5752  
5753  
5754  
5755  
5756  
5757  
5758  
5759  
5760  
5761  
5762  
5763  
5764  
5765  
5766  
5767  
5768  
5769  
5770  
5771  
5772  
5773  
5774  
5775  
5776  
5777  
5778  
5779  
5780  
5781  
5782  
5783  
5784  
5785  
5786  
5787  
5788  
5789  
5790  
5791  
5792  
5793  
5794  
5795  
5796

## 1.0 ABSTRACT

-----

THE DRV11B DIAGNOSTIC PROGRAM IS A SERIES OF TESTS DESIGNED TO TEST ALL LOGIC FUNCTIONS AND DATA PATHS ACCESSIBLE WITH THE LOOP BACK CABLE INSERTED IN THE USER I/O CONNECTORS. TOTAL PROGRAM CONTROL IS ACCOMPLISHED THRU THE CONSOLE TERMINAL VIA THE ODT/CONSOLE MICROCODE AND THE PROVISIONS OF SECTION 5 OF THIS DOCUMENT. IF THE SYSTEM ALSO INCLUDES AN "REV11" (DMA REFRESH), THE DMA REFRESH MUST BE DISABLED AND CPU REFRESH MUST BE ENABLED.

## 2.0 REQUIREMENTS

-----

### 2.1 EQUIPMENT

1. LSI-11 FAMILY PROCESSOR.  
11/03(LSI-11/02), 11/23(KDF11-A), 11/23B(KDF11-B)
2. DLV11 WITH I/O TYPE TERMINAL
3. DRV11B WITH LOOP BACK CABLE

### 2.2 STORAGE

THE PROGRAM USES THE LOWER 4K OF MEMORY.

## 3.0 LOADING PROCEDURE

-----

IF USING PAPER TAPE READER FOLLOW THIS PROCEDURE:

1. ASSURE THAT THE LSI-11 IS IN THE ODT MICROCODE STATE.
2. LOAD THE LOW OR HIGH SPEED READER WITH THE ABSOLUTE LOADER TAPE.
3. TYPE THE READER'S CSR ADDRESS (177560-LOW OR 177550-HIGH) AND CHARACTER 'L'.
4. AFTER TAPE IS LOADED, LOAD THE DRV11B BINARY TAPE INTO THE READER AND TYPE THE CHARACTER 'P'.
5. IF THE ABSOLUTE LOADER HAS ALREADY BEEN LOADED (STEPS 2 & 3), THEN ONLY THE STARTING ADDRESS OF THE ABSOLUTE LOADER AND THE CHARACTER 'G' NEED BE TYPED (WITH THE DRV11B BINARY TAPE IN THE APPROPRIATE READER).

## 4.0 STARTING PROCEDURE

-----

FOR PAPER TAPE MEDIA:

1. MAKE SURE THE MAINTENANCE LOOP BACK CABLE IS INSERTED IN THE I/O CONNECTORS ON THE M7950 MODULE.
2. MAKE SURE THE DEVICE BUS & VECTOR ADDRESSES AGREE WITH THE DEFAULT VALUES DEFINED IN SECTION 7.1. IF NOT, CHANGE LOCATION(S) AS DESIRED VIA THE 'ADDRESS/' ODT COMMAND.



5797  
5798  
5799  
5800  
5801  
5802  
5803  
5804  
5805  
5806  
5807  
5808  
5809  
5810  
5811  
5812  
5813  
5814  
5815  
5816  
5817  
5818  
5819  
5820  
5821  
5822  
5823  
5824  
5825  
5826  
5827  
5828  
5829  
5830  
5831  
5832  
5833  
5834  
5835  
5836  
5837  
5838  
5839  
5840  
5841  
5842  
5843  
5844  
5845  
5846  
5847  
5848  
5849  
5850  
5851  
5852

3. INSURE THAT THE HALT SWITCH IS DISABLED (IF ANY).
4. TYPE THE STARTING ADDRESS OF 200 AND THE CHARACTER G.
5. THE PROGRAM WILL RESPOND BY TYPING THE SOFTWARE SWITCH REGISTER CONTENTS AND ALLOWING THE USER TO CHANGE ITS CONTENTS BY ENTERING OCTAL SWITCH REGISTER DATA TERMINATED BY A CARRIAGE RETURN - SEE SECTION 5.0 FOR SWITCH REGISTER OPTIONS.
6. THE NEXT QUESTION ASKED IS ABOUT THE TYPE OF A PROCESSOR. TYPE 'Y' WITH CARRIGE RETURN IF USING KDF11-B, 'N' OTHERWISE.

IF RUNNING UNDER XXDP+ MONITOR:

- A) DO 1., 2., 3. OF THE ABOVE.
- B) IN MONITOR MODE TYPE IN 'R VDRAB?'
- C) DO 5. AND 6.

\*\*\*\*\*

IF USING LSI-11/23B(KDF11-B) AND WANT TO TEST DMA TRANSFERS TO I/O PAGE PUT THE ADDRESS OF YOUR I/O INTERFACE CONTROL REGISTER INTO LOCATION 1544 (IOPAGE). TO DO THIS PERMANENTLY USE LOAD-MOD-DUMP PROCEDURE DEFINED IN 7.2. FOR TEMPORARY CHANGES JUST MODIFY LOCATIONS AFTER LOADING THE PROGRAM.

NOTE: THIS TEST IS NOT GOING TO BE PERFORMED UNLESS THE ABOVE MENTIONED LOCATIONS ARE MODIFIED.

5.0 SOFTWARE SWITCH REGISTER

5.1 OPTIONS

SWITCH	OCTAL	FUNCTION
SW15=1	100000	HALT ON ERROR
SW14=1	040000	LOOP ON TEST
SW13=1	020000	INHIBIT ERROR TYPEOUTS
SW11=1	004000	INHIBIT ITERATIONS
SW10=1	002000	BELL ON ERROR
SW09=1	001000	LOOP ON ERROR
SW08=1	0004XX	LOOP ON TEST IN SWR <5-0>
***SW07=1	000200	DEVICE IS KDF11-B

\*\*\*DIAGNOSTIC WILL SET THIS SWITCH AUTOMATICALLY, IF THIS TYPE OF A PROCESSOR HAS BEEN CONFIRMED IN A DIALOGUE. IF RUNNING IN AUTOMATIC MODE (CHAINS UNDER XXDP OR APT) SEE SECTION 7.2

5.2 CONTROL

1. THE SOFTWARE SWITCH REGISTER 'SWREG' (LOC. 176) CAN BE CHANGED BY USING THE ODT FACILITIES.
2. THE SOFTWARE SWITCH REGISTER CAN BE CHANGED UNDER PROGRAM CONTROL BY TYPING THE 'CONTROL & G' KEYS. THIS KEYBOARD OPERATION WILL PRINT OUT THE CURRENT CONTENTS AND ACCEPT NEW OCTAL SWITCH REGISTER DATA TERMINATED WITH A CARRIAGE RETURN.
3. ONCE THE ODT MODE HAS BEEN ENTERED BECAUSE OF AN ERROR CONDITION WITH BIT15 SET (HALT ON ERROR), STEP #2 ABOVE IS OF NO VALUE, SO RESORT TO STEP #1 TO ALTER THE SOFTWARE SWITCH REGISTER IF DESIRED BEFORE TYPING



5853  
5854  
5855  
5856  
5857  
5858  
5859  
5860  
5861  
5862  
5863  
5864  
5865  
5866  
5867  
5868  
5869  
5870  
5871  
5872  
5873  
5874  
5875  
5876  
5877  
5878  
5879  
5880  
5881  
5882  
5883  
5884  
5885  
5886  
5887  
5888  
5889  
5890  
5891  
5892  
5893  
5894  
5895  
5896  
5897  
5898  
5899  
5900  
5901  
5902  
5903  
5904  
5905  
5906  
5907  
5908

'P' (CONTINUE).

4. IF THE PROGRAM IS PERFORMING RESET INSTRUCTIONS, SEVERAL 'CONTROL & G' COMMANDS MAY BE NECESSARY TO BE ACKNOWLEDGE BY THE PROGRAM.

6.0 ERROR REPORTING  
-----

6.1 ERROR COMMENT

ALL ERRORS ARE ACCOMPANIED WITH AN ENGLISH LANGUAGE DESCRIPTIVE COMMENT AS TO THE TYPE OF FAILURE. FURTHER QUALIFICATION OF THE ERROR CAN BE OBTAINED IF NEEDED FROM THE COMMENT AT THE ERROR PC OR FROM THE TEST ITSELF.

6.2 ERROR DATA

*ERRPC	LISTING ADDRESS WHERE THE ERROR WAS DETECTED
*TSTNUM	TEST NUMBER WHERE THE ERROR OCCURRED
BUSADR	DRV11B BUS REG ADDRESS OF CONCERNED OPERATION
EXPT	DATA THAT WAS EXPECTED
RCVD	DATA THAT WAS RECEIVED
ADRS	MEMORY ADDRESS OF DATA TRANSFER ON ERROR

7.0 \*ALWAYS REPORTED  
MISCELLANEOUS  
-----

7.1 DRV11B BUS & VECTOR ADDRESS MODIFICATION

MODIFY LOCATION '\$BASE' IF BASE BUS ADDRESS IS NOT 172410.  
MODIFY LOCATION '\$VECT1' IF VECTOR ADDRESS IS NOT 124.

\*NOTE: USE THE LSI-11 ODT FACILITIES TO MODIFY THESE LOCATIONS AFTER PROGRAM LOAD. NO VECTOR ASSIGNMENT ABOVE 774 SHOULD BE ALLOWED.

7.2 XXDP/APT NOTES

THIS DIAGNOSTIC IS CHAINABLE UNDER XXDP (REF. 7.5)(REQUIRES 8K OR MORE). THIS DIAGNOSTIC DOES SUPPORT "APT" AND HAS RUN UNDER IT.

IF THE PROCESSOR USED IS KDF11-B:  
FOR APT SET \$SWREG BIT07 TO 1 (000200)  
FOR XXDP CHAINS SET LOCATION 176 (SWR) BIT07 TO 1  
TO DO THIS UNDER XXDP:

1. R UPD2
2. LOAD VDRAB?.BIC
3. MOD 176  
THE TERMINAL WILL RESPOND: 176/000000
4. NOW TYPE IN 200
5. BE CAREFUL: AT THIS POINT IT IS NECESSARY TO DELETE THE FILE FROM THE DISK.  
DEL DLO:VDRAB?.BIC (IF MEDIA IS RL ON DRIVE 0)
6. DUMP VDRABO.BIC  
TO BE SAFE, SKIP 5. AND DUMP THE FILE UNDER DIFFERENT NAME

5909  
5910  
5911  
5912  
5913  
5914  
5915  
5916  
5917  
5918  
5919  
5920  
5921  
5922  
5923  
5924  
5925  
5926  
5927  
5928  
5929  
5930  
5931  
5932  
5933  
5934  
5935  
5936  
5937  
5938  
5939  
5940  
5941  
5942  
5943  
5944  
5945  
5946  
5947  
5948  
5949  
5950  
5951  
5952  
5953  
5954  
5955  
5956  
5957  
5958  
5959  
5960  
5961  
5962  
5963  
5964

WITH .BIC EXTENSION.

NOTE: THIS PROCEDURE ASSUMES THAT DIAGNOSTIC IS ON THE DISK FROM WHICH THE SYSTEM IS BOOTED. IF THIS IS UNTRUE IN 2. AND 6. THE OPERATOR HAVE TO SPECIFY THE DRIVE BEFORE THE NAME.

7.3 POWER FAIL

A POWER FAILURE WILL CAUSE A RESTART MESSAGE ON POWER UP AT WHICH TIME THE PROGRAM IS RESTARTED (ONLY ON SYSTEMS WITH NON-VOLATILE MEMORY AND WITH APPROPRIATE HARDWARE).

7.4 MULTIPLE DRV11B INTERFACE TESTING

THIS PROGRAM DOES NOT "AUTO-SIZE" THE NUMBER OF DRV11B'S CONNECTED. THIS DIAGNOSTIC WILL TEST SEQUENTIALLY UP TO 8 DRV11B INTERFACES WITH CONTIGUOUS BUS AND VECTOR ADDRESSES. THIS IS ACCOMPLISHED BY THE OPERATOR SETTING UP LOCATION '\$DEVN' WITH A BIT MAP INDICATING WHAT INTERFACES ARE TO TESTED. I.E. BIT0=1 SAYS TEST 1ST DRV11B, BIT1=1 SAYS TEST 2ND DRV11B, BIT2=1 SAYS TEST 3RD DRV11B, ETC..

7.5 RESTRICTIONS

IF THE SYSTEM ALSO INCLUDES AN "REV11" (DMA REFRESH), THE DMA REFRESH MUST BE DISABLED AND CPU REFRESH MUST BE ENABLED.

8.0 EXECUTION TIME  
-----

EXECUTION TIME RANGES FROM ABOUT 5 SECONDS WITH NO ITERATIONS TO ABOUT 90 SECONDS WITH ITERATIONS ENABLED WITH ONE DRV11B CONNECTED. AN END PASS MESSAGE INDICATES ALL TESTS HAVE COMPLETED ON ALL SELECTED UNITS.

9.0 PROGRAM TEST DESCRIPTIONS  
-----

9.1 GENERAL

THIS DIAGNOSTIC CONTAINS A SERIES OF INDEPENDENT TESTS DESIGNED TO TEST LOGIC FUNCTIONS AND DATA PATHS OF THE DRV11B DMA INTERFACE. A HIGH DEGREE OF TESTING IS ACCOMPLISHED WITH THE AID OF THE MAINTENANCE LOOP BACK CABLE PROVIDED FOR DIAGNOSTIC TESTING. A COMPLETE LIST OF TESTS IS AVAILABLE IN THE TABLE OF CONTENTS AT THE BEGINNING OF THE LISTING. THE COMMENT FIELD WITHIN EACH TEST CAN BE BENEFICIAL IN TEST UNDERSTANDING.

9.2 REGISTER TESTS

THE FOLLOWING REGISTERS ARE READ/WRITE & RESET TESTED:

1. WORD COUNT
2. BUFFER ADDRESS
3. COMMAND/STATUS
4. DATA BUFFER

9.3 BYTE ADDRESSING TESTS



5965  
5966  
5967  
5968  
5969  
5970  
5971  
5972  
5973  
5974  
5975  
5976  
5977  
5978  
5979  
5980  
5981  
5982  
5983  
5984  
5985  
5986  
5987  
5988  
5989  
5990  
5991  
5992  
5993  
5994  
5995  
5996  
5997  
5998  
5999  
6000  
6001  
6002  
6003  
6004

1. COMMAND/STATUS
  2. DATA BUFFER
- 9.4 'FNCT' TO 'STAT' WRAP AROUND TEST
- 9.5 READY INTERRUPT TEST
- 9.6 NPR DATA TRANSFER TESTS
- THE FOLLOWING NPR XFERS ARE CHECKED FOR CORRECT STATUS,  
WORD COUNT, BUFFER ADDRESS & DATA:
1. SINGLE 'DATI' XFER - FLOATING 1/0 PTRN
  2. SINGLE 'DATO' XFER - FLOATING 1/0 PTRN
  3. 200 'DATI' XFERS - FLOATING 1/0 PTRN
  4. 200 'DATO' XFERS - FLOATING 1/0 PTRN
  5. SINGLE 'DATI' XFER TO THE TTY PRINTER CSR  
FOR KDF11-B PROCESSOR THE USER HAVE TO SELECT  
CSR OF A PARTICULAR INTERFACE (DISK INTERFACES  
ARE SUGGESTED). SOME OF THEM ARE:  
RXV11 (RX01): 177170  
RXV21 (RX02): 177170  
RKV11-D (RK05): 177404
- 9.7 MAINT MODE NPR DATA TRANSFER TESTS
1. THAT MAINT MODE CONTROLS 'FNCT' BITS
  2. 200 MAINT MODE XFERS - CHECKING STATUS & DATA
  3. 200 MAINT MODE XFERS TO EACH 4K AVAILABLE MEM
- 9.8 BURST & NON-BURST MODE TESTS
1. THAT CPU IS LOCKED OUT IN BURST MODE
  2. THAT CPU IS NOT LOCKED OUT IN NON-BURST MODE
- 9.9 'NEX' ERROR CONDITION TEST
- 10.0 LISTING -----

6006  
 6007  
 6008  
 6009  
 6010  
 6011  
 6012  
 6013  
 6014  
 6015  
 6016  
 6017  
 6018  
 6019  
 6020  
 6021  
 6025  
 6026  
 6027  
 6028  
 6029  
 6030  
 6034  
 6043  
 6044  
 6045  
 6046  
 6047  
 6048  
 6049  
 6050  
 6051  
 6052  
 6053  
 6054  
 6055  
 6056  
 6057  
 6058  
 6059  
 6060  
 6061  
 6062  
 6063  
 6064  
 6065  
 6066  
 6067  
 6068  
 6069  
 6070  
 6071  
 6072  
 6073  
 6074  
 6075

000007  
 104401  
 104402  
 104403  
 104404  
 104405  
 104406  
 104407  
 104410  
 104411  
 104412  
 000021  
 000023  
 000001  
 160000  
 167400  
 000300  
 000001

```

.TITLE MAINDEC-11-CVDRA-C DRV11B DMA INTERFACE DIAGNOSTIC
;*COPYRIGHT (C) FEBRUARY 1985
;*DIGITAL EQUIPMENT CORP.
;*MAYNARD, MASS. 01754
;*
;*PROGRAM BY R. MOORE
;*
;*THIS PROGRAM WAS ASSEMBLED USING THE PDP-11 MAINDEC SYSMAC
;*PACKAGE (MAINDEC-11-DZQAC-C5), FEB, 1985.
;*
```

.ENABLE ABS,AMA

```

MFPT=000007
TYPE=104401
TYPOC=104402
TYPOS=104403
TYPON=104404
TYPDS=104405
GTSWR=104406
CKSWR=104407
RDCHR=104410
RDLIN=104411
RDOCT=104412
$XON=000021
$XOFF=000023
$TN=1
$SWR=160000      ;;HALT ON ERROR, LOOP ON TEST, INHIBIT ERROR TYP0UT
$SWR=167400
$SWRMK=300
$TN=1
```

```

.SBTTL OPERATIONAL SWITCH SETTINGS
;*
;* SWITCH USE
;* -----
;*      15 HALT ON ERROR
;*      14 LOOP ON TEST
;*      13 INHIBIT ERROR TYPEOUTS
;*      11 INHIBIT ITERATIONS
;*      10 BELL ON ERROR
;*      9 LOOP ON ERROR
;*      8 LOOP ON TEST IN SWR<5:0>
```

```

.SBTTL BASIC DEFINITIONS
;*INITIAL ADDRESS OF THE STACK POINTER *** 1100 ***
```



```

6076      001100      STACK= 1100
6077      .EQUIV EMT,ERROR      ;;BASIC DEFINITION OF ERROR CALL
6078      .EQUIV IOT,SCOPE      ;;BASIC DEFINITION OF SCOPE CALL
6079
6080      ;*MISCELLANEOUS DEFINITIONS
6081      HT= 11      ;;CODE FOR HORIZONTAL TAB
6082      LF= 12      ;;CODE FOR LINE FEED
6083      CR= 15      ;;CODE FOR CARRIAGE RETURN
6084      CRLF= 200      ;;CODE FOR CARRIAGE RETURN-LINE FEED
6085      PS= 177776      ;;PROCESSOR STATUS WORD
6086      .EQUIV PS,PSW
6087      177774      STKLMT= 177774      ;;STACK LIMIT REGISTER
6088      177772      PIRQ= 177772      ;;PROGRAM INTERRUPT REQUEST REGISTER
6089      177570      DSWR= 177570      ;;HARDWARE SWITCH REGISTER
6090      177570      DDISP= 177570      ;;HARDWARE DISPLAY REGISTER
6091
6092      ;*GENERAL PURPOSE REGISTER DEFINITIONS
6093      R0= #0      ;;GENERAL REGISTER
6094      R1= #1      ;;GENERAL REGISTER
6095      R2= #2      ;;GENERAL REGISTER
6096      R3= #3      ;;GENERAL REGISTER
6097      R4= #4      ;;GENERAL REGISTER
6098      R5= #5      ;;GENERAL REGISTER
6099      R6= #6      ;;GENERAL REGISTER
6100      R7= #7      ;;GENERAL REGISTER
6101      SP= #6      ;;STACK POINTER
6102      PC= #7      ;;PROGRAM COUNTER
6103
6104      ;*PRIORITY LEVEL DEFINITIONS
6105      PR0= 0      ;;PRIORITY LEVEL 0
6106      PR1= 40      ;;PRIORITY LEVEL 1
6107      PR2= 100      ;;PRIORITY LEVEL 2
6108      PR3= 140      ;;PRIORITY LEVEL 3
6109      PR4= 200      ;;PRIORITY LEVEL 4
6110      PR5= 240      ;;PRIORITY LEVEL 5
6111      PR6= 300      ;;PRIORITY LEVEL 6
6112      PR7= 340      ;;PRIORITY LEVEL 7
6113
6114      ;*"SWITCH REGISTER" SWITCH DEFINITIONS
6115      100000      SW15= 100000
6116      040000      SW14= 40000
6117      020000      SW13= 20000
6118      010000      SW12= 10000
6119      004000      SW11= 4000
6120      002000      SW10= 2000
6121      001000      SW09= 1000
6122      000400      SW08= 400
6123      000200      SW07= 200
6124      000100      SW06= 100
6125      000040      SW05= 40
6126      000020      SW04= 20
6127      000010      SW03= 10
6128      000004      SW02= 4
6129      000002      SW01= 2
6130      000001      SW00= 1
6131      .EQUIV SW09,SW9
  
```

```

6132 .EQUIV SW08,SW8
6133 .EQUIV SW07,SW7
6134 .EQUIV SW06,SW6
6135 .EQUIV SW05,SW5
6136 .EQUIV SW04,SW4
6137 .EQUIV SW03,SW3
6138 .EQUIV SW02,SW2
6139 .EQUIV SW01,SW1
6140 .EQUIV SW00,SW0
6141
6142 ;*DATA BIT DEFINITIONS (BIT00 TO BIT15)
6143 100000 BIT15= 100000
6144 040000 BIT14= 40000
6145 020000 BIT13= 20000
6146 010000 BIT12= 10000
6147 004000 BIT11= 4000
6148 002000 BIT10= 2000
6149 001000 BIT09= 1000
6150 000400 BIT08= 400
6151 000200 BIT07= 200
6152 000100 BIT06= 100
6153 000040 BIT05= 40
6154 000020 BIT04= 20
6155 000010 BIT03= 10
6156 000004 BIT02= 4
6157 000002 BIT01= 2
6158 000001 BIT00= 1
6159 .EQUIV BIT09,BIT9
6160 .EQUIV BIT08,BIT8
6161 .EQUIV BIT07,BIT7
6162 .EQUIV BIT06,BIT6
6163 .EQUIV BIT05,BIT5
6164 .EQUIV BIT04,BIT4
6165 .EQUIV BIT03,BIT3
6166 .EQUIV BIT02,BIT2
6167 .EQUIV BIT01,BIT1
6168 .EQUIV BIT00,BIT0
6169
6170 ;*BASIC "CPU" TRAP VECTOR ADDRESSES
6171 000004 ERRVEC= 4 ;;TIME OUT AND OTHER ERRORS
6172 000010 RESVEC= 10 ;;RESERVED AND ILLEGAL INSTRUCTIONS
6173 000014 TBITVEC=14 ;; "T" BIT
6174 000014 TRTVEC= 14 ;;TRACE TRAP
6175 000014 BPTVEC= 14 ;;BREAKPOINT TRAP (BPT)
6176 000020 IOTVEC= 20 ;;INPUT/OUTPUT TRAP (IOT) **SCOPE**
6177 000024 PWRVEC= 24 ;;POWER FAIL
6178 000030 EMTVEC= 30 ;;EMULATOR TRAP (EMT) **ERROR**
6179 000034 TRAPVEC=34 ;; "TRAP" TRAP
6180 000060 TKVEC= 60 ;;TTY KEYBOARD VECTOR
6181 000064 TPVEC= 64 ;;TTY PRINTER VECTOR
6182 000240 PIRQVEC=240 ;;PROGRAM INTERRUPT REQUEST VECTOR
6183 172410 ABASE= 172410 ;BASE DRV11B BUS ADRS EQUATE
6184 104400 TRAP=104400
6185 000124 AVECT1= 000124 ;BASE DRV11B VECTOR ADRS EQUATE -
6186 000001 ADEVM= 1 ;DEFAULT TO ONE DRV11B
6187 106427 MTPS=106427 ;INSTR EQUATE THAT MOVES BYTE TO PSW
    
```



BASIC DEFINITIONS

```
6188          177522          THAIN= 177522          ;MAINTENCE REGISTER(FOR USE WITH KDF11-B)
6189
6190
6191
6192          000000          AMSGTY=0
6193          000000          AFATAL=0
6194          000000          ATESTN=0
6195          000000          APASS=0
6196          000000          ADEVCT=0
6197          000000          AUNIT=0
6198          000000          AMSGAD=0
6199          000000          AMSGLG=0
6200          000000          AENV=0
6201          000000          AENVM=0
6202          000000          ASWREG=0
6203          000000          AUSWR=0
6204          000000          ACPUOP=0
6205          000000          AMAMS1=0
6206          000000          AMTYP1=0
6207          000000          AMADR1=0
6208          000000          AMAMS2=0
6209          000000          AMTYP2=0
6210          000000          AMADR2=0
6211          000000          AMAMS3=0
6212          000000          AMTYP3=0
6213          000000          AMADR3=0
6214          000000          AMAMS4=0
6215          000000          AMTYP4=0
6216          000000          AMADR4=0
6217          000000          AVECT2=0
6218          000000          ACDW1=0
6219          000000          ACDW2=0
6220          000000          ADDW0=0
6221          000000          ADDW1=0
6222          000000          ADDW2=0
6223          000000          ADDW3=0
6224          000000          ADDW4=0
6225          000000          ADDW5=0
6226          000000          ADDW6=0
6227          000000          ADDW7=0
6228          000000          ADDW8=0
6229          000000          ADDW9=0
6230          000000          ADDW10=0
6231          000000          ADDW11=0
6232          000000          ADDW12=0
6233          000000          ADDW13=0
6234          000000          ADDW14=0
6235          000000          ADDW15=0
6236
6237          .SBTTL TRAP CATCHER
6238
6239          000000          .ASECT
6240          000000 014052          $TRAP
6241          000002 000340          340
6242          000000          .=0
6243          ;*ALL UNUSED LOCATIONS FROM 4 - 776 CONTAIN A ".+2,HALT"
```

```

6244 ;*SEQUENCE TO CATCH ILLEGAL TRAPS AND INTERRUPTS
6245 ;*LOCATION 0 CONTAINS 0 TO CATCH IMPROPERLY LOADED VECTORS
6246      000174      .=174
6247 000174 000000  DISPREG: .WORD 0      ;;SOFTWARE DISPLAY REGISTER
6248 000176 000000  SWREG:   .WORD 0      ;;SOFTWARE SWITCH REGISTER
6249      .SBTTL  STARTING ADDRESS(ES)
6250 000200 000137 001550  JMP      @START ;;JUMP TO STARTING ADDRESS OF PROGRAM
6251      .=100
6252 000100 000104 000200 000002  .WORD 104,200,2      ;IF 'B EVENT' ON Q BUS IS CONNECTED
6253      ;IGNORE IT'S INTERRUPT - JUST DO A RTI
6254      .SBTTL  ACT11 HOOKS
6255
6256      ;*****
6257 ;HOOKS REQUIRED BY ACT11
6258      $SVPC=.      ;SAVE PC
6259      .=46
6260 000046 010042      $ENDAD      ;;1)SET LOC.46 TO ADDRESS OF $ENDAD IN .EOP
6261      .=52
6262 000052 000000      .WORD 0      ;;2)SET LOC.52 TO ZERO
6263      .=$SVPC      ;; RESTORE PC
6264      .=1000
6265      .SBTTL  APT PARAMETER BLOCK
6266
6267      ;*****
6268 ;SET LOCATIONS 24 AND 44 AS REQUIRED FOR APT
6269      ;*****
6270      . $X=.      ;;SAVE CURRENT LOCATION
6271      .=24      ;;SET POWER FAIL TO POINT TO START OF PROGRAM
6272 000024 000200      200      ;;FOR APT START UP
6273      .=44      ;;POINT TO APT INDIRECT ADDRESS PNTR.
6274 000044 001000      $APTHDR ;;POINT TO APT HEADER BLOCK
6275      .=$X      ;;RESET LOCATION COUNTER
6276      ;*****
6277 ;SETUP APT PARAMETER BLOCK AS DEFINED IN THE APT-PDP11 DIAGNOSTIC
6278 ;INTERFACE SPEC.
6279
6280 $APTHD:
6281 001000 000000  $HIBTS: .WORD 0      ;;TWO HIGH BITS OF 18 BIT MAILBOX ADDR.
6282 001002 001174  $MBADR: .WORD $MAIL  ;;ADDRESS OF APT MAILBOX (BITS 0-15)
6283 001004 000031  $TSTM:  .WORD 25.    ;;RUN TIM OF LONGEST TEST
6284 001006 000006  $PASTM: .WORD 6.     ;;RUN TIME IN SECS. OF 1ST PASS ON 1 UNIT (QUICK VERIFY)
6285 001010 000144  $UNITH: .WORD 100.   ;;ADDITIONAL RUN TIME (SECS) OF A PASS FOR EACH ADDITIONAL UNIT
6286 001012 000052  .WORD $ETEND-$MAIL/2 ;;LENGTH MAILBOX-ETABLE(WORDS)
6287      .SBTTL  COMMON TAGS
6288
6289      ;*****
6290 ;*THIS TABLE CONTAINS VARIOUS COMMON STORAGE LOCATIONS
6291 ;*USED IN THE PROGRAM.
6292
6293      .=1100
6294 001100 001100  $CHTAG:      ;;START OF COMMON TAGS
6295 001100 000000
6296 001102 000      $TSTM:  .BYTE 0      ;;CONTAINS THE TEST NUMBER
6297 001103 000      $ERFLG: .BYTE 0      ;;CONTAINS ERROR FLAG
6298 001104 000000  $ICNT:  .WORD 0      ;;CONTAINS SUE TEST ITERATION COUNT
6299 001106 000000  $LPADR: .WORD 0      ;;CONTAINS SCPE LOOP ADDRESS
  
```



```
6300 001110 000000 . PERR: .WORD 0 ;;CONTAINS SCOPE RETURN FOR ERRORS
6301 001112 000000 $ERTTL: .WORD 0 ;;CONTAINS TOTAL ERRORS DETECTED
6302 001114 000 $ITEMB: .BYTE 0 ;;CONTAINS ITEM CONTROL BYTE
6303 001115 001 $ERMAX: .BYTE 1 ;;CONTAINS MAX. ERRORS PER TEST
6304 001116 000000 $ERRPC: .WORD 0 ;;CONTAINS PC OF LAST ERROR INSTRUCTION
6305 001120 000000 $GDADR: .WORD 0 ;;CONTAINS ADDRESS OF 'GOOD' DATA
6306 001122 000000 $BDADR: .WORD 0 ;;CONTAINS ADDRESS OF 'BAD' DATA
6307 001124 000000 $GDDAT: .WORD 0 ;;CONTAINS 'GOOD' DATA
6308 001126 000000 $BDDAT: .WORD 0 ;;CONTAINS 'BAD' DATA
6309 001130 000000 .WORD 0 ;;RESERVED--NOT TO BE USED
6310 001132 000000 .WORD 0
6311 001134 000 $AUTOB: .BYTE 0 ;;AUTOMATIC MODE INDICATOR
6312 001135 000 $INTAG: .BYTE 0 ;;INTERRUPT MODE INDICATOR
6313 001136 000000 .WORD 0
6314 001140 177570 SWR: .WORD DSWR ;;ADDRESS OF SWITCH REGISTER
6315 001142 177570 DISPLAY: .WORD DDISP ;;ADDRESS OF DISPLAY REGISTER
6316 001144 177560 $TKS: 177560 ;;TTY KBD STATUS
6317 001146 177562 $TKB: 177562 ;;TTY KBD BUFFER
6318 001150 177564 $TPS: 177564 ;;TTY PRINTER STATUS REG. ADDRESS
6319 001152 177566 $TPB: 177566 ;;TTY PRINTER BUFFER REG. ADDRESS
6320 001154 000 $NULL: .BYTE 0 ;;CONTAINS NULL CHARACTER FOR FILLS
6321 001155 002 $FILLS: .BYTE 2 ;;CONTAINS # OF FILLER CHARACTERS REQUIRED
6322 001156 012 $FILLC: .BYTE 12 ;;INSERT FILL CHARS. AFTER A "LINE FEED"
6323 001157 000 $TPFLG: .BYTE 0 ;;"TERMINAL AVAILABLE" FLAG (BIT<07>=0=YES)
6324 001160 000000 $TIMES: 0 ;;MAX. NUMBER OF ITERATIONS
6325 001162 000000 $ESCAPE: 0 ;;ESCAPE ON ERROR ADDRESS
6326 001164 177607 000377 $BELL: .ASCIZ <207><377><377> ;;CODE FOR BELL
6327 001170 077 $QUES: .ASCII /?/ ;;QUESTION MARK
6328 001171 015 $CRLF: .ASCII <15> ;;CARRIAGE RETURN
6329 001172 000012 $LF: .ASCIZ <12> ;;LINE FEED
6330 ;;*****
6331 .SBTTL APT MAILBOX-ETABLE
6332
6333 ;;*****
6334 .EVEN
6335 $MAIL: ;;APT MAILBOX
6336 001174 000000 $MSGTY: .WORD AMSGTY ;;MESSAGE TYPE CODE
6337 001176 000000 $FATAL: .WORD AFATAL ;;FATAL ERROR NUMBER
6338 001200 000000 $TESTN: .WORD ATESTN ;;TEST NUMBER
6339 001202 000000 $PASS: .WORD APASS ;;PASS COUNT
6340 001204 000000 $DEVCT: .WORD ADEVCT ;;DEVICE COUNT
6341 001206 000000 $UNIT: .WORD AUNIT ;;I/O UNIT NUMBER
6342 001210 000000 $MSGAD: .WORD AMSGAD ;;MESSAGE ADDRESS
6343 001212 000000 $MSGLG: .WORD AMSGLG ;;MESSAGE LENGTH
6344 001214 $ETABLE: ;;APT ENVIRONMENT TABLE
6345 001214 000 $ENV: .BYTE AENV ;;ENVIRONMENT BYTE
6346 001215 000 $ENVM: .BYTE AENVM ;;ENVIRONMENT MODE BITS
6347 001216 000000 $SWREG: .WORD ASWREG ;;APT SWITCH REGISTER
6348 001220 000000 $USWR: .WORD AUSWR ;;USER SWITCHES
6349 001222 000000 $CPUOP: .WORD ACPUOP ;;CPU TYPE,OPTIONS
6350 ;* BITS 15-11-CPU TYPE
6351 ;* 11/04=01,11/05=02,11/20=03,11/40=04,11/45=05
6352 ;* 11/70=06,PDQ=07,Q=10
6353 ;* BIT 10-REAL TIME CLOCK
6354 ;* BIT 9-FLOATING POINT PROCESSOR
6355 ;* BIT 8-MEMORY MANAGEMENT
```

```

6356 001224 000 $MAMS1: .BYTE AMAMS1 ;;HIGH ADDRESS,M.S. BYTE
6357 001225 000 $MTYP1: .BYTE AMTYP1 ;;MEM. TYPE,BLK#1
6358 ;* MEM.TYPE BYTE -- (HIGH BYTE)
6359 ;* 900 NSEC CORE=001
6360 ;* 300 NSEC BIPOLAR=002
6361 ;* 500 NSEC MOS=003
6362 001226 000000 $MADR1: .WORD AMADR1 ;;HIGH ADDRESS,BLK#1
6363 ;* MEM.LAST ADDR.=3 BYTES,THIS WORD AND LOW OF "TYPE" ABOVE
6364 001230 000 $MAMS2: .BYTE AMAMS2 ;;HIGH ADDRESS,M.S. BYTE
6365 001231 000 $MTYP2: .BYTE AMTYP2 ;;MEM. TYPE,BLK#2
6366 001232 000000 $MADR2: .WORD AMADR2 ;;MEM.LAST ADDRESS,BLK#2
6367 001234 000 $MAMS3: .BYTE AMAMS3 ;;HIGH ADDRESS,M.S.BYTE
6368 001235 000 $MTYP3: .BYTE AMTYP3 ;;MEM. TYPE,BLK#3
6369 001236 000000 $MADR3: .WORD AMADR3 ;;MEM.LAST ADDRESS,BLK#3
6370 001240 000 $MAMS4: .BYTE AMAMS4 ;;HIGH ADDRESS,M.S.BYTE
6371 001241 000 $MTYP4: .BYTE AMTYP4 ;;MEM. TYPE,BLK#4
6372 001242 000000 $MADR4: .WORD AMADR4 ;;MEM.LAST ADDRESS,BLK#4
6373 001244 000124 $VECT1: .WORD AVECT1 ;;INTERRUPT VECTOR#1,BUS PRIORITY#1
6374 001246 000000 $VECT2: .WORD AVECT2 ;;INTERRUPT VECTOR#2BUS PRIORITY#2
6375 001250 172410 $BASE: .WORD ABASE ;;BASE ADDRESS OF EQUIPMENT UNDER TEST
6376 001252 000001 $DEV#1: .WORD ADEV#1 ;;DEVICE MAP
6377 001254 000000 $CDW1: .WORD ACDW1 ;;CONTROLLER DESCRIPTION WORD#1
6378 001256 000000 $CDW2: .WORD ACDW2 ;;CONTROLLER DESCRIPTION WORD#2
6379 001260 000000 $DDW0: .WORD ADDW0 ;;DEVICE DESCRIPTOR WORD#0
6380 001262 000000 $DDW1: .WORD ADDW1 ;;DEVICE DESCRIPTOR WORD#1
6381 001264 000000 $DDW2: .WORD ADDW2 ;;DEVICE DESCRIPTOR WORD#2
6382 001266 000000 $DDW3: .WORD ADDW3 ;;DEVICE DESCRIPTOR WORD#3
6383 001270 000000 $DDW4: .WORD ADDW4 ;;DEVICE DESCRIPTOR WORD#4
6384 001272 000000 $DDW5: .WORD ADDW5 ;;DEVICE DESCRIPTOR WORD#5
6385 001274 000000 $DDW6: .WORD ADDW6 ;;DEVICE DESCRIPTOR WORD#6
6386 001276 000000 $DDW7: .WORD ADDW7 ;;DEVICE DESCRIPTOR WORD#7
6387 001300 000000 $DDW8: .WORD ADDW8 ;;DEVICE DESCRIPTOR WORD#8
6388 001302 000000 $DDW9: .WORD ADDW9 ;;DEVICE DESCRIPTOR WORD#9
6389 001304 000000 $DDW10: .WORD ADDW10 ;;DEVICE DESCRIPTOR WORD#10
6390 001306 000000 $DDW11: .WORD ADDW11 ;;DEVICE DESCRIPTOR WORD#11
6391 001310 000000 $DDW12: .WORD ADDW12 ;;DEVICE DESCRIPTOR WORD#12
6392 001312 000000 $DDW13: .WORD ADDW13 ;;DEVICE DESCRIPTOR WORD#13
6393 001314 000000 $DDW14: .WORD ADDW14 ;;DEVICE DESCRIPTOR WORD#14
6394 001316 000000 $DDW15: .WORD ADDW15 ;;DEVICE DESCRIPTOR WORD#15
6395
6396
6397 001320 $ETEND:
6398
6399 .SBTTL ERROR POINTER TABLE
6400
6401 ;*THIS TABLE CONTAINS THE INFORMATION FOR EACH ERROR THAT CAN OCCUR.
6402 ;*THE INFORMATION IS OBTAINED BY USING THE INDEX NUMBER FOUND IN
6403 ;*LOCATION $ITEMB. THIS NUMBER INDICATES WHICH ITEM IN THE TABLE IS PERTINENT.
6404 ;*NOTE1: IF $ITEMB IS 0 THE ONLY PERTINENT DATA IS ($ERRPC).
6405 ;*NOTE2: EACH ITEM IN THE TABLE CONTAINS 4 POINTERS EXPLAINED AS FOLLOWS:
6406
6407 ;* EM ;;POINTS TO THE ERROR MESSAGE
6408 ;* DH ;;POINTS TO THE DATA HEADER
6409 ;* DT ;;POINTS TO THE DATA
6410 ;* DF ;;POINTS TO THE DATA FORMAT
6411
    
```



6412									
6413	001320								
6414				\$ERRTB:					
6415	001320	014134		:ERROR	1				
6416	001322	015025			EM1				:REG TIMEOUT ER
6417	001324	015176			DH1				:ERRPC TSTNUM BUSADR EXPCT RCVD
6418	001326	000000			DT1				:ERRPC TSTNUM \$BDADR \$GDDAT \$BDDAT
6419					0				
6420				:ERROR	2				
6421	001330	014153			EM2				:REG READ/WRITE ER
6422	001332	015025			DH1				:ERRPC TSTNUM BUSADR EXPCT RCVD
6423	001334	015176			DT1				:ERRPC TSTNUM \$BDADR \$GDDAT \$BDDAT
6424	001336	000000			0				
6425									
6426				:ERROR	3				
6427	001340	014175			EM3				:BUS RESET ER
6428	001342	015025			DH1				:ERRPC TSTNUM BUSADR EXPCT RCVD
6429	001344	015176			DT1				:ERRPC TSTNUM \$BDADR \$GDDAT \$BDDAT
6430	001346	000000			0				
6431									
6432				:ERROR	4				
6433	001350	014212			EM4				:FNCT BITS FAILED TO SET STAT BITS
6434	001352	015025			DH1				:ERRPC TSTNUM BUSADR EXPCT RCVD
6435	001354	015176			DT1				:ERRPC TSTNUM \$BDADR \$GDDAT \$BDDAT
6436	0C1356	000000			0				
6437									
6438				:ERROR	5				
6439	001360	014254			EM5				:READY INTR FAILURE
6440	001362	015025			DH1				:ERRPC TSTNUM BUSADR EXPCT RCVD
6441	001364	015176			DT1				:ERRPC TSTNUM \$BDADR \$GDDAT \$BDDAT
6442	001366	000000			0				
6443									
6444				:ERROR	6				
6445	001370	014277			EM6				:READY CLR OR SET ER
6446	001372	015025			DH1				:ERRPC TSTNUM BUSADR EXPCT RCVD
6447	001374	015176			DT1				:ERRPC TSTNUM \$BDADR \$GDDAT \$BDDAT
6448	001376	000000			0				
6449				:ERROR	7				
6450	001400	014323			EM7				:STATUS ER ON XFER
6451	001402	015025			DH1				:ERRPC TSTNUM BUSADR EXPCT RCVD
6452	001404	015176			DT1				:ERRPC TSTNUM \$BDADR \$GDDAT \$BDDAT
6453	001406	000000			0				
6454									
6455				:ERROR	10				
6456	001410	014345			EM10				:WORD COUNT ER ON XFER
6457	001412	015025			DH1				:ERRPC TSTNUM BUSADR EXPCT RCVD
6458	001414	015176			DT1				:ERRPC TSTNUM \$BDADR \$GDDAT \$BDDAT
6459	001416	000000			0				
6460									
6461				:ERROR	11				
6462	001420	014373			EM11				:BUFFER ADRS ER ON XFER
6463	001422	015025			DH1				:ERRPC TSTNUM BUSADR EXPCT RCVD
6464	001424	015176			DT1				:ERRPC TSTNUM \$BDADR \$GDDAT \$BDDAT
6465	001426	000000			0				
6466									
6467				:ERROR	12				

6468	001430	014422	EM12	;DATA ER FROM MEM				
6469	001432	015072	DH2	;ERRPC TSTNUM	BUSADR	ADRS	EXPCT	RCVD
6470	001434	015212	DT2	;ERRPC TSTNUM	\$BDADR	\$GDADR	\$GDDAT	\$BDDAT
6471	001436	000000	0					
6472								
6473			;ERROR 13					
6474	001440	014443	EM13	;DATA ER TO MEM				
6475	001442	015072	DH2	;ERRPC TSTNUM	BUSADR	ADRS	EXPCT	RCVD
6476	001444	015212	DT2	;ERRPC TSTNUM	\$BDADR	\$GDADR	\$GDDAT	\$BDDAT
6477	001446	000000	0					
6478								
6479			;ERROR 14					
6480	001450	014462	EM14	;SINGLE CYCLE OFF DID NOT LOCK OUT CPU				
6481	001452	015147	DH3	;ERRPC TSTNUM	BUSADR			
6482	001454	015230	DT3	;ERRPC TSTNUM	\$BDADR			
6483	001456	000000	0					
6484								
6485			;ERROR 15					
6486	001460	014530	EM15	;SINGLE CYCLE ON LOCKED OUT CPU				
6487	001462	015147	DH3	;ERRPC TSTNUM	BUSADR			
6488	001464	015230	DT3	;ERRPC TSTNUM	\$BDADR			
6489	001466	000000	0					
6490								
6491			;ERROR 16					
6492	001470	014716	EM16	;NEX LOGIC ER				
6493	001472	015025	DH1	;ERRPC TSTNUM	BUSADR	EXPCT	RCVD	
6494	001474	015176	DT1	;ERRPC TSTNUM	\$BDADR	\$GDDAT	\$BDDAT	
6495	001476	000000	0					
6496								
6497			;ERROR 17					
6498	001500	014733	EM17	;CYCLE FAILED TO CLK DBR (IN)				
6499	001502	015025	DH1	;ERRPC TSTNUM	BDADR	GDDAT	BDDAT	
6500	001504	015176	DT1	;ERRPC TSTNUM	\$BDADR	\$GDDAT	\$BDDAT	
6501	001506	000000	0					
6502			;ERROR 20					
6503	001510	014770	EM20	;DATA ER FROM I/O PAGE (XCSR)				
6504	001512	015072	DH2	;ERRPC TSTNUM	BUSADR	ADRS	EXPCT	RCVD
6505	001514	015212	DT2	;ERRPC TSTNUM	\$BDADR	\$GDADR	\$GDDAT	\$BDDAT
6506	001516	000000	0					
6507								
6508								
6509			;DRV11B BUS REGISTER ADDRESS POINTERS					
6510								
6511	001520	172410	DRVWCR: 172410	;WORD COUNT				
6512	001522	172412	DRVBAR: 172412	;BUFFER ADDRESS				
6513	001524	172414	DRVCSR: 172414	;COMMAND/STATUS				
6514	001526	172416	DRVDBR: 172416	;DATA BUFFER				
6515								
6516			;DRV11B VECTOR ADDRESS POINTERS					
6517								
6518	001530	000124	DRVCT0: 124	;READY, NEX & INCOMPLETE DATIO VECTOR				
6519	001532	000126	DRVCT2: 126	;NEW PSW ON INTR				
6520								
6521			;COMMON PROGRAM LOCATION(S)					
6522								
6523	001534	000000	TSTNUM: 0	;CONTAINS TEST NUMBER ON ERROR				



```

6524 001536 000001          DMAP: 1           ;DEVICE MAP - EA BIT SAYS TEST THAT DRV11B
6525 001540 000000          CORSZ: 0          ;CONTAINS 1ST NON-EXISTANT MEM ADRS
6526 001542 015364          DBUFP: DBUF       ;CONTAINS CURRENT 4K NPR BUFFER ADRS
6527 001544 000000          IOPAGE: 0         ;CONTAINS ADDRESS FOR I/O TRANSFERS
6528 001546 000000          KDF: 0           ;IF KDF11-B
6529                          .SBTTL PROGRAM START
6530 001550          START:
6531          .SBTTL INITIALIZE THE COMMON TAGS
6532          ;;CLEAR THE COMMON TAGS (%CMTAG) AREA
6533 001550 012706 001100      MOV    %CMTAG,R6    ;;FIRST LOCATION TO BE CLEARED
6534 001554 005026           CLR    (R6)+        ;;CLEAR MEMORY LOCATION
6535 001556 022706 001140      CMP    %SWR,R6     ;;DONE?
6536 001562 001374           BNE    -6           ;;LOOP BACK IF NO
6537 001564 012706 001100      MOV    %STACK,SP   ;;SETUP THE STACK POINTER
6538          ;;INITIALIZE A FEW VECTORS
6539 001570 012737 012432 000020  MOV    %SCOPE,%IOTVEC ;;IOT VECTOR FOR SCOPE ROUTINE
6540 001576 012737 000340 000022  MOV    %340,%IOTVEC+2 ;;LEVEL 7
6541 001604 012737 012070 000030  MOV    %ERROR,%EMTVEC ;;EMT VECTOR FOR ERROR ROUTINE
6542 001612 012737 000340 000032  MOV    %340,%EMTVEC+2 ;;LEVEL 7
6543 001620 012737 014052 000034  MOV    %TRAP,%TRAPVEC ;;TRAP VECTOR FOR TRAP CALLS
6544 001626 012737 000340 000036  MOV    %340,%TRAPVEC+2;LEVEL 7
6545 001634 012737 013646 000024  MOV    %PWRDN,%PWRVEC ;;POWER FAILURE VECTOR
6546 001642 012737 000340 000026  MOV    %340,%PWRVEC+2 ;;LEVEL 7
6547 001650 005037 001160      CLR    %TIMES      ;;INITIALIZE NUMBER OF ITERATIONS
6548 001654 005037 001162      CLR    %ESCAPE     ;;CLEAR THE ESCAPE ON ERROR ADDRESS
6549 001660 112737 000001 001115  MOVB  %1,%ERMAX    ;;ALLOW ONE ERROR PER TEST
6550 001666 012737 001666 001106  MOV    %.,%LPADR    ;;INITIALIZE THE LOOP ADDRESS FOR SCOPE
6551 001674 012737 001674 001110  MOV    %.,%LPERR    ;;SETUP THE ERROR LOOP ADDRESS
6552          ;;SIZE FOR A HARDWARE SWITCH REGISTER. IF NOT FOUND OR IT IS
6553          ;;EQUAL TO A "-1", SETUP FOR A SOFTWARE SWITCH REGISTER.
6554 001702 013746 000004          MOV    %ERRVEC,-(SP) ;;SAVE ERROR VECTOR
6555 001706 012737 001742 000004  MOV    %64,%ERRVEC  ;;SET UP ERROR VECTOR
6556 001714 012737 177570 001140  MOV    %DSWR,SWR    ;;SETUP FOR A HARDWARE SWICH REGISTER
6557 001722 012737 177570 001142  MOV    %DDISP,DISPLAY ;;AND A HARDWARE DISPLAY REGISTER
6558 001730 022777 177777 177202  CMP    #-1,%SWR    ;;TRY TO REFERENCE HARDWARE SWR
6559 001736 001012           BNE    66$         ;;BRANCH IF NO TIMEOUT TRAP OCCURRED
6560          ;;AND THE HARDWARE SWR IS NOT = -1
6561 001740 000403           BR     65$         ;;BRANCH IF NO TIMEOUT
6562 001742 012716 001750      64$: MOV    %65$, (SP)  ;;SET UP FOR TRAP RETURN
6563 001746 000002           RTI
6564 001750 012737 000176 001140  65$: MOV    %SWREG,SWR ;;POINT TO SOFTWARE SWR
6565 001756 012737 000174 001142  MOV    %DISPREG,DISPLAY
6566 001764 012637 000004      66$: MOV    (SP)+,%ERRVEC ;;RESTORE ERROR VECTOR
6567
6568 001770 005037 001202          CLR    %PASS       ;;CLEAR PASS COUNT
6569 001774 132737 000200 001215  BITB  %APTSIZE,%ENVM ;;TEST USER SIZE UNDER APT
6570 002002 001403           BEQ    67$         ;;YES,USE NON-APT SWITCH
6571 002004 012737 001216 001140  MOV    %SWREG,SWR  ;;NO,USE APT SWITCH REGISTER
6572 002012          67$:
6573 002012 012700 001520      START1: MOV    %DRVWCR,R0 ;SET UP REG ADRS POINTERS
6574 002016 013701 001250      MOV    %BASE,R1   ;GET BASE ADRS
6575 002022 010120      SETUP2: MOV    R1,(R0)+ ;LOAD EM
6576 002024 062701 000002      ADD    %2,R1      ;
6577 002030 022700 001530      CMP    %DRVDBR+2,R0 ;ALL DONE?
6578 002034 001372           BNE    SETUP2     ;BR IF NOT
6579 002036 012700 001530      MOV    %DRVCTO,R0 ;SET UP DRV11B VECTOR ADRS POINTER
    
```

```
6580 002042 013701 001244      MOV      $VECT1,R1      ;GET BASE VECTOR ADRS
6581 002046 042701 170000      BIC      #170000,R1    ;CLR OUT PRIORITY BITS
6582 002052 010120      SETUP3: MOV     R1,(R0)+  ;
6583 002054 062701 000002      ADD      #2,R1        ;POINT TO NEXT
6584 002060 022700 001534      CMP      #DRVCT2+2,R0 ;ALL DONE?
6585 002064 001372      BNE      SETUP3       ;BR IF NOT
6586
6587      .SBTTL  TYPE PROGRAM NAME
      ;;TYPE THE NAME OF THE PROGRAM IF FIRST PASS
6588 002066 005227 177777      INC      #-1          ;;FIRST TIME?
6589 002072 001052      BNE      64$          ;;BRANCH IF NO
6590 002074 104401 002142      TYPE     .65$        ;;TYPE ASCIZ STRING
6591      .SBTTL  GET VALUE FOR SOFTWARE SWITCH REGISTER
6592 002100 005737 000042      TST      #042        ;;ARE WE RUNNING UNDER XXDP/ACT?
6593 002104 001012      BNE      66$          ;;BRANCH IF YES
6594 002106 123727 001214 000001      CMPB     $ENV,#1     ;;ARE WE RUNNING UNDER APT?
6595 002114 001406      BEQ      66$          ;;BRANCH IF YES
6596 002116 023727 001140 000176      CMP      SWR,#SWREG  ;;SOFTWARE SWITCH REG SELECTED?
6597 002124 001005      BNE      67$          ;;BRANCH IF NO
6598 002126 104406      GTSWR    ;           ;;GET SOFT-SWR SETTINGS
6599 002130 000403      BR       67$
6600 002132 112737 000001 001134 66$:  MOVB     #1,$AUTOB    ;;SET AUTO-MODE INDICATOR
6601 002140      67$:
6602 002140 000427      BR       64$          ;;GET OVER THE ASCIZ
6603 002142 046600 026504 030461 65$:  .ASCIZ  <CRLF>#MD-11-CVDRA-C DRV11B DMA INTERFACE DIAG #<CRLF>
      002150 041455 042126 040522
      002156 041455 020040 051104
      002164 030526 041061 042040
      002172 040515 044440 052116
      002200 051105 040506 042503
      002206 042040 040511 020107
      002214 100040      000
6604      002220
6605      .EVEN
6606      64$:
6607      ;
6608      ; INC      #-1          ;FIRST PASS? ;DD001 INSTRUCTIONS
6609      ; BNE      100$        ;BRANCH IF NO ;DD001 NO LONGER
6610      ; CMPB     #1,$AUTOB  ;MANUAL INTERVENTION PERMITTED? ;DD001 NECESSARY
6611      ; BEQ      100$        ;BR IF NO ;DD001
6612      ; MOV      #010,-(SP) ;SAVE ILLEGAL INSTRUCTION ;DD001
6613      ; MOV      #012,-(SP) ;TRAP VECTOR ;DD001
6614      ; MOV      #100$,#010 ; ;DD001
6615      ; MFPT ;IF CPU TYPE IS 11/23 ;DD001
6616      ; BISB     #BIT07,#SWR ;THEN SET BIT 7 IN SWREG ;DD001
6617      ; MOV      (SP)+,#012 ;AND RESTORE TRAP VECTOR ;DD001
6618      ; MOV      (SP)+,#010 ; ;DD001
6619      ; TST      CORSZ      ;TEST IF FIRST PASS
6620      ; BNE      CORSZR     ;BR IF NOT
6621      ; TYPE     ,WARN      ;TELL THE OPERATOR TO TURN OFF DMA REFRESH
6622      ;;*****
      ;LET'S SEE HOW MUCH MEM WE HAVE
      ;;*****
6623 002270 012700 020000      CORSZR: MOV     #20000,R0 ;USE R0 TO LOOK
6624 002274 012737 002306 000004      MOV      #2$,#ERRVEC ;SET UP TIME OUT RETURN ADRS
6625 002302 005720      1$:  TST      (R0)+      ;TAKE A LOOK
6626 002304 000776      BR       1$          ;UNTIL TIMEOUT
6627 002306 042700 017777      2$:  BIC      #17777,R0   ;POINT TO 1ST NON-EXSISTANT 4K BLK
6628 002312 010037 001540      MOV      R0,CORSZ   ;SAVE FOR LATER
```



```

6629 002316 012737 000006 000004      MOV      #ERRVEC+2,#ERRVEC ;RESTORE VECTOR
6630 002324 012737 015364 001542      MOV      #DBUF,DBUFP      ;INITIALIZE TO LOWEST 4K
6631 002332 012737 000000 001206      MOV      #0,#UNIT        ;SET UP UNIT COUNT
6632 002340 013737 001252 001536      MOV      #DEVN,DMAP      ;GET THE # & POSITION OF DRV11B'S
6633 002346 042737 177400 001536      BIC      #177400,DMAP     ;UP TO 8 ONLY
6634 002354 001406                BEQ      RESTRT          ;GO CONTINUE AS IF SOMETHING WAS SELECTED
6635 002356 032737 000001 001536      BIT      #1,DMAP         ;IS 1ST DRV11B SELECTED?
6636 002364 001002                BNE      RESTRT          ;BR IF SO
6637 002366 000137 007660                JMP      NXDEV1          ;NO - GO ADVANCE BASE DRV11B ADDRESSES
6638 002372 106427 000200      RESTRT: MTPS          #200 ;SET PRIORITY TO HIGHEST LEVEL
6639 002376 012706 001100                MOV      #STACK,SP      ;ALWAYS RESET STACK PTR
6640 002402 013737 001206 001204      MOV      #UNIT,#DEVCT   ;LOAD APT COUNTER
6641 002410 013700 001206                MOV      #UNIT,RO       ;MAKE AN INDEX
6642 002414 006300                ASL      RO              ; VALUE
6643 002416 013760 001520 001260      MOV      DRVWCR,#DDWO(RO) ;SAVE THE BUS ADDRESS
6644 002424 000005                RESET             ;INITIALIZE DRV11B BEFORE TESTING
6645                ;*****
6646                ;*TEST 1          TEST THAT ALL DRV11B REGS ARE ACCESSIBLE
6647                ;*****
6648 002426 000240      TST1: <NOP>
6649 002430 012737 002444 001106      MOV      #10#,#LPADR    ;;SET SCOPE LOOP ADDRESS
6650 002436 012737 000001 001200      MOV      #1,#TESTN      ;;SET TEST NUMBER IN APT MAIL BOX
6651 002444 112737 000001 001192      10#: MOVB   #1,#TSTNM     ;SET TO TEST #1
6652 002452 012737 002506 001110      MOV      #1#,#LPERR     ;SET UP SCOPE LOOP ADRS
6653 002460 005037 001124                CLR      #GDDAT         ;NO DATA COMPARE
6654 002464 005037 001126                CLR      #BDDAT         ;NO DATA COMPARE
6655 002470 012737 002524 000004      MOV      #2#,#ERRVEC    ;SET UP TIMEOUT RETURN ADRS
6656 002476 013700 001520      MOV      DRVWCR,RO      ;SET UP 1ST DRV11 BUS ADRS
6657 002502 012701 000004      MOV      #4,R1          ;SET UP REG COUNT
6658 002506 010037 001122      1#: MOV    RO,#BDADR     ;SET UP CURRENT DRV BUS ADRS
6659 002512 005710                TST      (RO)           ;SEE IF THERE
6660 002514 005720                TST      (RO)+         ;BUMP TO NEXT
6661 002516 005301                DEC      R1             ;COUNT 4 OF THEM
6662 002520 001403                BEQ      3#            ;BR IF ALL DONE
6663 002522 000771                BR       1#            ;TRY NEXT
6664 002524 022626      2#: CMP    (SP)+,(SP)+  ;FIX STACK SINCE NO RTI
6665 002526 104001                ERROR   1              ;BUS ADRS INDICATED DID NOT RESPOND
6666 002530 012737 000006 000004      3#: MOV    #ERRVEC+2,#ERRVEC ;RESTORE LOC 4
6667
6668                ;*****
6669                ;*TEST 2          TEST THAT THE WORD COUNT REG IS WRITE/READABLE (FLOAT 0 COM PTRN)
6670                ;*****
6671 002536 000004      TST2: SCOPE
6672 002540 012737 002564 001110      MOV      #1#,#LPERR     ;SET UP SCOPE LOOP ADRS
6673 002546 013737 001520 001122      MOV      DRVWCR,#BDADR  ;SET UP WC REG ADRS
6674 002554 005000                CLR      RO             ;RO SAYS SHIFT PTRN WHEN 0
6675 002556 012737 177776 001124      MOV      #-2,#GDDAT     ;FLOAT 0 RIGHT TO LEFT
6676 002564 013777 001124 176726      1#: MOV    #GDDAT,#DRVWCR ;LD WC
6677 002572 017737 176722 001126      MOV      #DRVWCR,#BDDAT ;READ IT BACK
6678 002600 023737 001124 001126      CMP      #GDDAT,#BDDAT  ;CORRECT?
6679 002606 001401                BEQ      2#            ;BR IF SO
6680 002610 104002                ERROR   2              ;WORD COUNT WRITE/READ FAILURE
6681 002612 005137 001124      2#: COM    #GDDAT        ;COMPELEMENT ZERO
6682 002616 005100                COM      RO             ;RO SAYS SHIFT LEFT WHEN = 0
6683 002620 001361                BNE     1#            ;TRY THE COMPLEMENT IF RO NOT 0
6684 002622 006337 001124                ASL     #GDDAT         ;COMPLEMENT WAS DONE - NOW SHIFT ZERO LEFT

```

```
6685 002626 005237 001124      INC      $GDDAT      ;KEEP LSB SET
6686 002632 103754      BCS      1$        ;AGAIN TILL ALL PATRNS DONE
6687
6688
6689      ;*****
6690      ;*TEST 3      TEST THAT THE BUFFER ADDRESS REG IS WRITE/READABLE (FLOAT 0 COM PTRN)
6691      ;*****
6691 002634 000004      TST3:  SCOPE
6692 002636 012737 002662 001110      MOV      #1$, $LPERR      ;SET UP SCOPE LOOP ADRS
6693 002644 013737 001522 001122      MOV      DRVBAR, $BDADR    ;SET UP BA REG ADRS
6694 002652 005000      CLR      RO              ;RO SAYS SHIFT PTRN WHEN 0
6695 002654 012737 177774 001124      MOV      #-4, $GDDAT      ;FLOAT 0 RIGHT TO LEFT
6696 002662 013777 001124 176632 1$:  MOV      $GDDAT, @DRVBAR    ;LD BA
6697 002670 017737 176626 001126      MOV      @DRVBAR, $BDDAT   ;READ IT BACK
6698 002676 042737 000001 001126      BIC      @BIT00, $BDDAT    ;DON'T WANT BIT00
6699 002704 023737 001124 001126      CMP      $GDDAT, $BDDAT    ;CORRECT?
6700 002712 001401      BEQ      2$              ;BR IF SO
6701 002714 104002      ERROR   2              ;BUS ADRS WRITE/READ FAILURE
6702 002716 005137 001124 001124 2$:  COM      $GDDAT            ;COMPLEMENT ZERO
6703 002722 042737 000001 001124      BIC      @BIT00, $GDDAT    ;BIT 00 NOT INVOLVED
6704 002730 005100      COM      RO              ;RO SAYS SHIFT LEFT WHEN = 0
6705 002732 001353      BNE      1$              ;TRY THE COMPLEMENT IF RO NOT 0
6706 002734 006337 001124      ASL      $GDDAT            ;COMPLEMENT WAS DONE - NOW SHIFT ZERO LEFT
6707 002740 103004      BCC      TST4            ;NEXT TEST IF BIT 15 DONE
6708 002742 062737 000002 001124      ADD      #2, $GDDAT        ;KEEP ADDR LSB SET
6709 002750 000744      BR       1$              ;AGAIN TILL ALL PATRNS DONE
6710
6711
6712      ;*****
6713      ;*TEST 4      TEST THAT THE DATA BUFFER REG IS WRITE/READABLE (FLOAT 0 COM PTRN)
6714      ;*****
6714 002752 000004      TST4:  SCOPE
6715 002754 012737 003000 001110      MOV      #1$, $LPERR      ;SET UP SCOPE LOOP ADRS
6716 002762 013737 001526 001122      MOV      DRVDBR, $BDADR    ;SET UP DB REG ADRS
6717 002770 005000      CLR      RO              ;RO SAYS SHIFT PTRN WHEN 0
6718 002772 012737 177776 001124      MOV      #-2, $GDDAT      ;FLOAT 0 RIGHT TO LEFT
6719 003000 013777 001124 176520 1$:  MOV      $GDDAT, @DRVDBR    ;LD DB
6720 003006 017737 176514 001126      MOV      @DRVDBR, $BDDAT   ;READ IT BACK
6721 003014 023737 001124 001126      CMP      $GDDAT, $BDDAT    ;CORRECT?
6722 003022 001401      BEQ      2$              ;BR IF SO
6723 003024 104002      ERROR   2              ;DATA BUFFER WRITE/READ FAILURE (LOOP BACK)
6724 003026 005137 001124 001124 2$:  COM      $GDDAT            ;COMPLEMENT ZERO
6725 003032 005100      COM      RO              ;RO SAYS SHIFT LEFT WHEN = 0
6726 003034 001361      BNE      1$              ;TRY THE COMPLEMENT IF RO NOT 0
6727 003036 006337 001124      ASL      $GDDAT            ;COMPLEMENT WAS DONE - NOW SHIFT ZERO LEFT
6728 003042 005237 001124      INC      $GDDAT            ;KEEP LSB SET
6729 003046 103754      BCS      1$              ;AGAIN TILL ALL PATRNS DONE
6730
6731
6732      ;*****
6733      ;*TEST 5      TEST THAT THE DATA BUFFER REG IS BYTE ADDRESSABLE
6734      ;*****
6734 003050 000004      TST5:  SCOPE
6735 003052 013700 001526      MOV      DRVDBR, RO        ;GET DB REG ADRS
6736 003056 010037 001122      MOV      RO, $BDADR        ;SET UP DB REG ADRS
6737 003062 005010      CLR      (RO)             ;ZERO DATA BUFFER REG
6738 003064 012737 177177 001124      MOV      #177177, $GDDAT   ;LD EXPECTED
6739 003072 012737 077776 001126      MOV      #77776, $BDDAT    ;SEND DATA FROM "BDDAT"
6740 003100 153760 001126 000001      BISB    $BDDAT, 1(RO)     ;LOAD HI BYTE DB
```



```

6741 003106 153710 001127      BISB  $BDDAT+1,(R0) ;LOAD LO BYTE DB
6742 003112 011037 001126      MOV   (R0), $BDDAT ;READ IT BACK
6743 003116 023737 001124 001126  CMP   $GDDAT, $BDDAT ;CORRECT?
6744 003124 001401          BEQ   TST6          ;NEXT TEST IF SO
6745 003126 104002          ERROR  2          ;DATA ERROR ON BYTE ADDRESSING THE DATA BUFFER REG
6746
6747
6748 ;*****
6749 ;*TEST 6 TEST THAT RESET CLEARS WORD COUNT, BUS ADDRESS & DATA REGS
6750 ;*****
6750 003130 000004          TST6:  SCOPE
6751 003132 012737 000010 001160      MOV   #10, $TIMES ;DO 10 ITERATIONS
6752 003140 005037 001124          CLR   $GDDAT      ;LD EXPECTED
6753 003144 012777 177777 176346      MOV   #-1, @DRVWCR ;SET ALL BITS - WC REG
6754 003152 012777 177776 176342      MOV   #-2, @DRVBAR ;SET ALL BITS - BUS ADRS REG
6755 003160 012777 177777 176340      MOV   #-1, @DRVDBR ;SET ALL BITS - DB OUT REG
6756 003166 000005          RESET ;DO A BUS RESET
6757 003170 017737 176324 001126      MOV   @DRVWCR, $BDDAT ;READ WC REG
6758 003176 001404          BEQ   1$          ;BR IF CLRED
6759 003200 013737 001520 001122      MOV   DRVWCR, $BDADR ;SET UP WC REG ADRS
6760 003206 104003          ERROR  3          ;RESET FAILED TO CLR WC REG
6761 003210 017737 176306 001126 1$:  MOV   @DRVBAR, $BDDAT ;READ BUS ADRS REG
6762 003216 042737 000001 001126      BIC   #BIT00, $BDDAT ;DON'T WANT BIT00
6763 003224 001404          BEQ   2$          ;BR IF CLRED
6764 003226 013737 001522 001122      MOV   DRVBAR, $BDADR ;SET UP BA REG ADRS
6765 003234 104003          ERROR  3          ;RESET FAILED TO CLR BUS ADRS REG
6766 003236 017737 176264 001126 2$:  MOV   @DRVDBR, $BDDAT ;READ DATA BUFFER REG
6767 003244 001404          BEQ   TST7        ;NEXT TEST IF CLRED
6768 003246 013737 001526 001122      MOV   DRVDBR, $BDADR ;SET UP DB REG ADRS
6769 003254 104003          ERROR  3          ;RESET FAILED TO CLR DATA BUFFER OUT REG
6770
6771 ;*****
6772 ;*TEST 7 TEST THAT THE CONTROL/STATUS REG IS WRITE/READABLE (COUNT PTRN)
6773 ;*****
6774 003256 000004          TST7:  SCOPE
6775 003260 012737 000010 001160      MOV   #10, $TIMES ;DO 10 ITERATIONS
6776 003266 106427 000200          MTPS  #200        ;DON'T WANT ANY INTRs
6777 003272 004537 010076          JSR   R5, SETVEC ;SET UP INTR RETURN ADRS IN CASE
6778 003276 003374          3$          ;RETURN TO 3$ ON ILLEGAL INTR
6779 003300 013737 003320 001110      MOV   1$, $LPERR ;SET UP SCOPE LOOP ADRS
6780 003306 013737 001524 001122      MOV   DRVCSR, $BDADR ;SET UP CSR ADRS
6781 003314 012700 160000          MOV   #160000, R0 ;START AT 0 - HI BITS FOR NOISE
6782 003320 010037 001124          1$:  MOV   R0, $GDDAT ;LD EXPECTED
6783 003324 042737 167201 001124      BIC   #167201, $GDDAT ;MASK TO WRITEABLE BITS
6784 003332 010077 176166          MOV   R0, @DRVCSR ;LD CSR
6785 003336 017737 176162 001126      MOV   @DRVCSR, $BDDAT ;READ IT BACK
6786 003344 042737 007200 001126      BIC   #7200, $BDDAT ;DON'T LOOK AT STAT & RDY BITS
6787 003352 023737 001124 001126      CMP   $GDDAT, $BDDAT ;CORRECT?
6788 003360 001401          BEQ   2$          ;BR IF SO
6789 003362 104002          ERROR  2          ;CONTROL/STATUS REG WRITE/READ FAILURE
6790 003364 062700 000002          2$:  ADD   #2, R0      ;ADVANCE COUNT PATTERN
6791 003370 001353          BNE   1$          ;WRITE NEXT PATTERN IF NOT ALL TESTED
6792 003372 000413          BR    4$          ;GO RESTORE VECTOR
6793 003374 022626          3$:  CMP   (SP)+, (SP)+ ;FIX STACK - SHOULD NOT HAVE INTR'ED
6794 003376 052737 000200 001124      BIS   #200, $GDDAT ;CORRECT EXPECTED
6795 003404 017737 176114 001126      MOV   @DRVCSR, $BDDAT ;READ CSR
6796 003412 042737 007000 001126      BIC   #7000, $BDDAT ;DON'T WANT 'STAT' BITS

```

```
6797 003420 104005          ERROR 5 ;CPU FAILED TO LOCK OUT DRV11B INTR REQ
6798 003422 004737 010116 4$: JSR PC,RSTVEC ;GO RESTORE VECTOR
6799
6800 ;*****
6801 ;*TEST 10 TEST THAT RESET CLEARS ALL WRITEABLE BITS & SET READY IN CSR
6802 ;*****
6803 003426 000004          TST10: SCOPE
6804 003430 012737 000010 001160      MOV #10,$TIMES ;DO 10 ITERATIONS
6805 003436 013737 001524 001122      MOV DRVCSR,$BDADR ;SET UP CSR ADRS
6806 003444 012737 000200 001124      MOV #200,$GDDAT ;LD EXPECTED
6807 003452 012777 177776 176044      MOV #-2,@DRVCSR ;LD ALL CSR BITS
6808 003460 000005          RESET ;DO A BUS RESET
6809 003462 017737 176036 001126      MOV @DRVCSR,$BDDAT ;READ CSR
6810 003470 023737 001124 001126      CMP $GDDAT,$BDDAT ;CORRECT?
6811 003476 001401          BEQ TST11 ;NEXT TEST IF CSR CLRED & READY SET
6812 003500 104003          ERROR 3 ;RESET FAILED TO SET UP THE CSR
6813
6814 ;*****
6815 ;*TEST 11 TEST THAT THE CSR IS BYTE ADDRESSABLE
6816 ;*****
6817 003502 000004          TST11: SCOPE
6818 003504 013700 001524          MOV DRVCSR,RO ;GET CSR ADRS
6819 003510 010037 001122          MOV RO,$BDADR ;SET UP CSR ADRS
6820 003514 005010          CLR (RO) ;ZERO CSR
6821 003516 012737 010300 001124      MOV #10300,$GDDAT ;LD EXPECTED
6822 003524 012737 040020 001126      MOV #40020,$BDDAT ;SEND DATA FROM "BDDAT" - USE MAIN + IE
6823 003532 153760 001126 000001      BISB $BDDAT,1(RO) ;LOAD HI BYTE CSR
6824 003540 153710 001127          BISB $BDDAT+1,(RO) ;LOAD LO BYTE CSR
6825 003544 011037 001126          MOV (RO),$BDDAT ;READ IT BACK
6826 003550 023737 001124 001126      CMP $GDDAT,$BDDAT ;CORRECT?
6827 003556 001401          BEQ 1$ ;BR IF SO
6828 003560 104002          ERROR 2 ;DATA ERROR ON BYTE ADDRESSING THE CSR
6829 003562 005010          1$: CLR (RO) ;ZERO CSR BEFORE ADVANCING
6830
6831 ;*****
6832 ;*TEST 12 TEST THAT THE 3 "FNCT" BITS CONTROL THE 3 "STAT" BITS (COUNT PTRN)
6833 ;*****
6834 003564 000004          TST12: SCOPE
6835 003566 012737 003614 001110      MOV #1,$LPERR ;SET UP SCOPE LOOP ADRS
6836 003574 013737 001524 001122      MOV DRVCSR,$BDADR ;SET UP CSR ADRS
6837 003602 012737 007000 001124      MOV #7000,$GDDAT ;LD EXPECTED
6838 003610 012700 000016          MOV #16,RO ;RO CONTAINS "FNCT" BITS WRITTEN
6839 003614 010077 175704          1$: MOV RO,@DRVCSR ;WRITE INTO "FNCT" BITS
6840 003620 017737 175700 001126      MOV @DRVCSR,$BDDAT ;READ BACK THRU "STAT" BITS
6841 003626 042737 170777 001126      BIC #170777,$BDDAT ;MASK TO "STAT" BITS ONLY
6842 003634 023737 001124 001126      CMP $GDDAT,$BDDAT ;CORRECT?
6843 003642 001401          BEQ 2$ ;BR IF SO
6844 003644 104004          ERROR 4 ;"FNCT" BITS FAILED TO SET "STAT" BITS (LOOP BACK)
6845 003646 162737 001000 001124      2$: SUB #1000,$GDDAT ;CHANGE TO NEXT EXPECTED
6846 003654 162700 000002          SUB #2,RO ;DECREASE COUNT PATTERN
6847 003660 100355          BPL 1$ ;DO AGAIN UNTIL 0 TESTED
6848
6849 ;*****
6850 ;*TEST 13 TEST THAT READY SET WILL CAUSE AN INTERRUPT AT LEVEL 0
6851 ;*****
6852 003662 000004          TST13: SCOPE
```



```

6853 003664 012737 000010 001160      MOV      #10,#TIMES      ;;DO 10 ITERATIONS
6854 003672 106427 000200              MTPS     #200           ;DONT WANT INTR YET
6855 003676 000005              RESET    ;SET THE READY FLAG BY INIT
6856 003700 012777 003760 175622      MOV      #1#,@DRVCTO    ;SET UP PREMATURE INTR RETURN ADRS
6857 003706 013737 001524 001122      MOV      DRVCSR,#BDADR  ;SET UP CSR ADRS
6858 003714 012737 000300 001124      MOV      #300,#GDDAT   ;LD EXPECTED (READY + IE)
6859 003722 106427 000000              MTPS     #0            ;ALLOW AN INTR
6860 003726 021616              CMP      (SP),(SP)     ;STALL
6861 003730 012777 003774 175572      MOV      #2#,@DRVCTO    ;SET UP EXPECTED INTR RETURN ADRS
6862 003736 052777 000100 175560      BIS      #BIT6,@DRVCSR  ;ENABLE THE EXPECTED INTERRUPT
6863 003744 021616              CMP      (SP),(SP)     ;STALL
6864 003746 017737 175552 001126      MOV      @DRVCSR,#BDDAT ;GET THE CSR
6865 003754 104005              ERROR   5             ;READY FAILED TO CAUSE AN INTERRUPT
6866 003756 000417              BR       3#           ;GO RESTORE VECTOR
6867 003760 022626              CMP      (SP)+,(SP)+   ;SHOULD NEVER GET HERE - IE NOT WORKING?
6868 003762 017737 175536 001126      MOV      @DRVCSR,#BDDAT ;GET THE CSR
6869 003770 104005              ERROR   5             ;READY INTERRUPTED WITHOUT THE IE BIT
6870 003772 000411              BR       3#           ;GO RESTORE VECTOR
6871 003774 022626              CMP      (SP)+,(SP)+   ;FIX STACK SINCE NO RETURN
6872 003776 017737 175522 001126      MOV      @DRVCSR,#BDDAT ;READ STATUS
6873 004004 023737 001124 001126      CMP      #GDDAT,#BDDAT ;CORRECT?
6874 004012 001401              BEQ      3#           ;BR IF SO
6875 004014 104005              ERROR   5             ;INCORRECT STATUS ON READY INTR
6876 004016 004737 010116      JSR     PC,RSTVEC     ;GO RESTORE VECTOR
6877
6878
6879      ;;*****
6880      ;*TEST 14      TEST THAT GO CLRS READY & FNCT 2 WILL SET IT
6881      ;;*****
6882      TST14:  SCOPE
6883      MTPS     #200           ;DONT WANT ANY INTRS
6884      MOV      DRVCSR,#BDADR  ;SET UP CSR ADRS
6885      CLR      #GDDAT         ;EXPECT 0
6886      MOV      #1,@DRVCSR     ;SET GO WHICH SHOULD CLR READY
6887      MOV      @DRVCSR,#BDDAT ;READ THE CSR
6888      CMP      #GDDAT,#BDDAT ;CORRECT?
6889      BEQ      1#           ;BR IF SO
6890      ERROR   6             ;THE GO BIT FAILED TO CLR READY
6891      BIS      #4,@DRVCSR     ;FNCT 2 SHOULD SET READY
6892      MOV      #2204,#GDDAT   ;LD EXPECTED
6893      MOV      @DRVCSR,#BDDAT ;GET CSR
6894      CMP      #GDDAT,#BDDAT ;CORRECT?
6895      BEQ      TST15         ;NEXT TEST IF SET
6896      ERROR   6             ;FNCT 2 (VIA ATTN) FAILED TO SET READY
6897
6898      ;;*****
6899      ;*TEST 15      TEST THAT READY CONTROLS 'BAR' BIT00
6900      ;;*****
6901      TST15:  SCOPE
6902      MOV      #4,@DRVCSR     ;SET READY
6903      MOV      DRVBAR,#BDADR  ;SET UP BAR ADRS
6904      MOV      #1,#GDDAT     ;EXPECT LSB OF BAR
6905      CLR      @DRVBAR        ;CLR BAR
6906      MOV      @DRVBAR,#BDDAT ;READ BAR
6907      CMP      #GDDAT,#BDDAT ;CORRECT?
6908      BEQ      1#           ;BR IF SO
6909      ERROR   2             ;A00 FAILED TO READ A ONE(SB TIED TO RDY)

```

```

6909 004174 012777 000001 175322 1#:  MOV    #1,0DRVCSR    ;SET GO(CLR BAR BIT00)
6910 004202 017737 175314 001126    MOV    0DRVBAR,#BDDAT ;READ BAR
6911 004210 001403                BEQ    2#            ;BR IF ZERO
6912 004212 005037 001124    CLR    #GDDAT        ;EXPECTED ZERO
6913 004216 104002                ERROR  2            ;WHEN RDY CLRD-A00 FAILED TO READ A ZERO
6914 004220 012777 000004 175276 2#:  MOV    #4,0DRVCSR    ;INSURE RDY SET BEFORE ADVANCING
6915
6916
6917 ;*****
6918 ;*TEST 16      TEST THAT 'CYCLE' WILL CLOCK THE DBR (IN)
6919 ;*****
6919 004226 000004    TST16: SCOPE
6920 004230 013737 001526 001122    MOV    DRVDBR,#BDADR  ;SET UP DBR ADRS
6921 004236 012737 125252 001124    MOV    #125252,#GDDAT ;LD EXPECTED
6922 004244 013777 001124 175254    MOV    #GDDAT,0DRVDBR ;LD DBR WITH #125252
6923 004252 012777 000400 175244    MOV    #400,0DRVCSR   ;SET CYCLE - SHOULD CLK DBR (IN)
6924 004260 012777 052525 175240    MOV    #52525,0DRVDBR ;CHANGE DBR (OUT) DATA - SHOULD NOT AFFECT (IN)
6925 004266 017737 175234 001126    MOV    0DRVDBR,#BDDAT ;READ DBR
6926 004274 023737 001124 001126    CMP    #GDDAT,#BDDAT  ;CORRECT?
6927 004302 001401                BEQ    1#            ;BR IF SO
6928 004304 104017                ERROR  17           ;CYCLE DID NOT LATCH DBR (IN) DATA
6929 004306 042777 000400 175210 1#:  BIC    #400,0DRVCSR   ;REMOVE CYCLE
6930 004314 012737 052525 001124    MOV    #52525,#GDDAT  ;NOW EXPECT #52525
6931 004322 017737 175200 001126    MOV    0DRVDBR,#BDDAT ;READ DBR
6932 004330 023737 001124 001126    CMP    #GDDAT,#BDDAT  ;CORRECT?
6933 004336 001401                BEQ    TST17        ;NEXT TEST IF SO
6934 004340 104002                ERROR  2            ;DBR FAILED TO READ WHEN CYCLE CLRD (NORMAL)
6935
6936 ;*****
6937 ;*TEST 17      TEST SINGLE "DATI" NPR TRANSFERS (FLOATING 0 COMPLEMENT PATRN)
6938 ;*****
6939 004342 000004    TST17: SCOPE
6940 004344 012737 004366 001110    MOV    #1#,#LPERR    ;SET UP SCOPE LOOP ADRS
6941 004352 004537 010076                JSR    R5,SETVEC     ;GO SET UP INTERRUPT RETURN
6942 004356 004462                2#
6943 004360 012700 177776                MOV    #-2,R0        ;FLOAT ZERO RIGHT TO LEFT
6944 004364 005001                CLR    R1            ;R1 CONTROLS DATA SHIFTING
6945 004366 012777 177777 175124 1#:  MOV    #-1,0DRVWCR   ;DO ONE XFER
6946 004374 012777 015364 175120    MOV    0DBUF,0DRVBAR ;GET DATA WORD FROM "DBUF"
6947 004402 010037 015364                MOV    R0,DBUF       ;SET UP MEM DATA
6948 004406 012777 000101 175110    MOV    #101,0DRVCSR  ;SET IE & GO
6949 004414 052777 000400 175102    BIS    #400,0DRVCSR  ;SET CYCLE
6950 004422 106427 000000                MTPS  #0            ;ENABLE THE INTR
6951 004426 013737 001524 001122    MOV    DRVCSR,#BDADR  ;SET UP CSR ADRS
6952 004434 012737 000700 001124    MOV    #700,#GDDAT   ;LD EXPECTED
6953 004442 017737 175056 001126    MOV    0DRVCSR,#BDDAT ;READ THE CSR
6954 004450 042777 000100 175046    BIC    #100,0DRVCSR  ;CLR IE
6955 004456 104005                ERROR  5            ;MCO FAILED TO INTERRUPT (CHECK FOR MCO)
6956 004460 000442                BR     4#            ;GO RESTORE VECTOR
6957 004462 022626                CMP    (SP)+,(SP)+   ;INTR RETURNS HERE - FIX STACK SINCE NO RTI
6958 004464 004537 010142 2#:  JSR    R5,CKSTAT     ;GO CHECK STATUS
6959 004470 000700                700                ;CSR STATUS EXPECTED
6960 004472 000001                1                ;# OF XFERS
6961 004474 104007                ERROR  7            ;RETURN HERE IF STATUS ER - EXPECTED CYCLE, READY & IE
6962 004476 000433                BR     4#            ;GO RESTORE VECTOR
6963 004500 104010                ERROR  10           ;RETURN HERE IF MC ER - EXPECTED 0
6964 004502 000431                BR     4#            ;GO RESTORE VECTOR

```



```
6965 004504 104011          ERROR 11          ;RETURN HERE IF BAR ER - SHOULD = DBUF+2
6966 004506 000427          BR      4#        ;GO RESTORE VECTOR
6967 004510 012737 015364 001120  MOV     #DBUF,#GDADR ;RETURN HERE IF OK - SET UP XFER ADRS
6968 004516 010037 001124          MOV     RO,#GDDAT   ;LD EXPECTED
6969 004522 017737 175000 001126  MOV     @DRVDBR,#BDDAT ;READ DATA XFERED
6970 004530 023737 001124 001126  CMP     #GDDAT,#BDDAT ;CORRECT?
6971 004536 001405          BEQ     3#        ;BR IF SO
6972 004540 013737 001526 001122  MOV     DRVDBR,#BDADR ;SET UP DBR ADRS
6973 004546 104012          ERROR 12          ;DATA ER - DBR CONTAINS WRONG DATA
6974 004550 000406          BR      4#        ;GO RESTORE VECTOR
6975 004552 005100          3#:  COM     RO      ;RETURN HERE ON GOOD DATA - NOW COM PATRN
6976 004554 005101          COM     R1      ;KEEP TRACK OF COMPLEMENT
6977 004556 001303          BNE     1#        ;DO COMPLEMENT OF THIS FLOATING ZERO IF 0
6978 004560 006300          ASL     RO      ;WAS DONE - NOW SHIFT ZERO LEFT
6979 004562 005200          INC     RO      ;KEEP LSB SET
6980 004564 103700          BCS     1#        ;AGAIN TILL ZERO BIT IN CARRY
6981 004566 004737 010116 4#:  JSR     PC,RSTVEC ;GO RESTORE VECTOR
6982
6983 ;*****
6984 ;*TEST 20 TEST SINGLE "DATO" NPR TRANSFERS (FLOATING 0 COMPLEMENT PATRN)
6985 ;*****
6986 004572 000004          TST20: SCOPE
6987 004574 012737 004616 001110  MOV     #1#,#LPERR ;SET UP SCOPE LOOP ADRS
6988 004602 004537 010076          JSR     R5,SETVEC ;GO SET UP INTERRUPT RETURN
6989 004606 004704          2#
6990 004610 012700 177776          MOV     #-2,RO    ;RETURN TO 2# ON INTR
6991 004614 005001          CLR     R1      ;FLOAT ZERO RIGHT TO LEFT
6992 004616 012777 177777 174674 1#:  MOV     #-1,@DRVWCR ;R1 CONTROLS DATA SHIFTING
6993 004624 012777 015364 174670  MOV     #DBUF,@DRVBAR ;DO ONE XFER
6994 004632 010077 174670          MOV     RO,@DRVDBR ;WRITE DATA WORD TO "DBUF"
6995 004636 012777 000103 174660  MOV     #103,@DRVCSR ;SET UP DATA IN DBR
6996 004644 052777 000400 174652  BIS     #400,@DRVCSR ;SET IE, GO & FNCT1 (C1 CONTROL)
6997 004652 106427 000000          MTPS    #0      ;SET CYCLE
6998 004656 013737 001524 001122  MOV     DRVCSR,#BDADR ;ENABLE THE INTR
6999 004664 012737 001702 001124  MOV     #1702,#GDDAT ;SET UP CSR ADRS
7000 004672 017737 174626 001126  MOV     @DRVCSR,#BDDAT ;LD EXPECTED
7001 004700 104005          MOV     @DRVCSR,#BDDAT ;READ THE CSR
7002 004702 000442          ERROR 5          ;WCO FAILED TO INTERRUPT (CHECK FOR WCO)
7003 004704 022626          BR      4#        ;GO RESTORE VECTOR
7004 004706 004537 010142 2#:  CMP     (SP)+,(SP)+ ;INTR RETURNS HERE - FIX STACK SINCE NO RTI
7005 004712 001702          JSR     R5,CKSTAT ;GO CHECK STATUS
7006 004714 000001          1702          ;CSR STATUS EXPECTED
7007 004716 104007          1          ;# OF XFERS
7008          ERROR 7          ;RETURN HERE IF STATUS ER - EXPECTED STAT C.
7009          BR      4#        ;CYCLE, READY, IE & FNCT 1
7010 004722 104010          BR      4#        ;GO RESTORE VECTOR
7011 004724 000431          ERROR 10         ;RETURN HERE IF WC ER - EXPECTED 0
7012 004726 104011          BR      4#        ;GO RESTORE VECTOR
7013 004730 000427          ERROR 11         ;RETURN HERE IF BAR ER - SHOULD = DBUF+2
7014 004732 012737 015364 001120  BR      4#        ;GO RESTORE VECTOR
7015 004740 010037 001124          MOV     #DBUF,#GDADR ;RETURN HERE IF OK - SET UP XFER ADRS
7016 004744 013737 015364 001126  MOV     RO,#GDDAT   ;LD EXPECTED
7017 004752 023737 001124 001126  MOV     DBUF,#BDDAT ;GET DATA XFERED
7018 004760 001405          CMP     #GDDAT,#BDDAT ;CORRECT?
7019 004762 013737 001526 001122  BEQ     3#        ;BR IF SO
7020 004770 104013          MOV     DRVDBR,#BDADR ;SET UP DBR ADRS
          ERROR 13          ;DATA ER - MEM CONTAINS WRONG DATA
```

```

7021 004772 000406          BR      4#      ;GO RESTORE VECTOR
7022 004774 005100    3#:  COM      R0      ;RETURN HERE ON GOOD DATA - NOW COM PATRN
7023 004776 005101          COM      R1      ;KEEP TRACK OF COMPLEMENT
7024 005000 001306          BNE     1#      ;DO COMPLEMENT OF THIS FLOATING ZERO IF 0
7025 005002 006300          ASL     R0      ;COMPLEMENT WAS DONE - NOW SHIFT ZERO LEFT
7026 005004 005200          INC     R0      ;KEEP LSB SET
7027 005006 103703          BCS     1#      ;AGAIN TILL ZERO BIT IN CARRY
7028 005010 004737 010116    4#:  JSR     PC,RSTVEC ;GO RESTORE VECTOR
7029
7030
7031      ;*****
7032      ;*TEST 21      TEST 200 "DATI" NPR TRANSFERS (BURST MODE)
7033      ;*****
7033 005014 000004    TST21: SCOPE
7034 005016 012737 000010 001160    MOV     #10,$TIMES      ;;DO 10 ITERATIONS
7035 005024 004537 010076          JSR     R5,SETVEC      ;GO SET UP INTERRUPT RETURN
7036 005030 005126          1#      ;RETURN TO 1# ON INTR
7037 005032 004737 010322          JSR     PC,LDBUF      ;GO LOAD BUFFER WITH COMPLEMENTING PATRN
7038 005036 012777 177470 174454    MOV     #-200.,@DRVWCR ;LOAD WC REG - WILL DO 200 XFERS
7039 005044 012777 015364 174450    MOV     @DBUF,@DRVBAR ;SET UP CURRENT ADRS
7040 005052 106427 000000          MTPS   #0            ;ENABLE THE INTR
7041 005056 012777 000101 174440    MOV     #101,@DRVCSR  ;SET IE & GO
7042 005064 052777 000400 174432    BIS     #400,@DRVCSR  ;SET CYCLE
7043 005072 013737 001524 001122    MOV     DRVCSR,$BDADR ;SET UP CSR ADRS
7044 005100 012737 000700 001124    MOV     #700,$GDDAT   ;LD EXPECTED
7045 005106 017737 174412 001126    MOV     @DRVCSR,$BDDAT ;READ THE CSR
7046 005114 042777 000100 174402    BIC     #100,@DRVCSR  ;CLR INTR ENABLE
7047 005122 104005          ERROR  5            ;WCO FAILED TO INTERRUPT (SNGL CYCL ON COULD CAUSE THIS)
7048 005124 000434          BR      2#      ;GO RESTORE VECTOR
7049 005126 022626    1#:  CMP     (SP)+,(SP)+   ;INTR RETURNS HERE - FIX STACK SINCE NO RTI
7050 005130 004537 010142          JSR     R5,CKSTAT     ;GO CHECK STATUS
7051 005134 000700          700          ;CSR STATUS EXPECTED
7052 005136 000310          200.         ;# OF XFERS
7053 005140 104007          ERROR  7            ;RETURN HERE IF STATUS ER - EXPECTED CYCLE, READY & IE
7054 005142 000425          BR      2#      ;GO RESTORE VECTOR
7055 005144 104010          ERROR  10          ;RETURN HERE IF WC ER - EXPECTED 0
7056 005146 000423          BR      2#      ;GO RESTORE VECTOR
7057 005150 104011          ERROR  11          ;RETURN HERE IF BAR ER - SHOULD = DBUF+620
7058 005152 000421          BR      2#      ;GO RESTORE VECTOR
7059 005154 012737 016202 001120    MOV     @DBUF+616,$GDADR ;OK - SET UP LAST XFER ADRS WHERE #70707 SHOULD BE
7060 005162 012737 070707 001124    MOV     #70707,$GDDAT ;LD EXPECTED
7061 005170 017737 174332 001126    MOV     @DRVDBR,$BDDAT ;DBR SHOULD HAVE LAST DATUM
7062 005176 023737 001124 001126    CMP     $GDDAT,$BDDAT ;CORRECT?
7063 005204 001404          BEQ     2#      ;BR IF SO
7064 005206 013737 001526 001122    MOV     DRVDBR,$BDADR ;SET UP DBR ADRS
7065 005214 104012          ERROR  12          ;DATA ER - DBR DID NOT CONTAIN EXPECTED LAST XFER
7066 005216 004737 010116    2#:  JSR     PC,RSTVEC      ;GO RESTORE VECTOR
7067
7068
7069      ;*****
7070      ;*TEST 22      TEST 200 "DATO" NPR TRANSFERS (BURST MODE)
7071      ;*****
7071 005222 000004    TST22: SCOPE
7072 005224 012737 000010 001160    MOV     #10,$TIMES      ;;DO 10 ITERATIONS
7073 005232 004537 010076          JSR     R5,SETVEC      ;GO SET UP INTERRUPT RETURN
7074 005236 005336          1#      ;RETURN TO 1# ON INTR
7075 005240 012777 177470 174252    MOV     #-200.,@DRVWCR ;WORD WC REG - WILL DO 200 XFER'S
7076 005246 012777 015364 174246    MOV     @DBUF,@DRVBAR ;SET UP CURRENT ADRS
    
```



```

7077 005254 012777 177377 174244      MOV      #177377,@DRVDBR ;THIS WILL BE WRITTEN TO MEM
7078 005262 106427 000000                MTPS     #0              ;ENABLE THE INTR
7079 005266 012777 000103 174230      MOV      #103,@DRVCSR   ;SET IE, FNCT 1 & GO
7080 005274 052777 000400 174222      BIS      #400,@DRVCSR   ;SET CYCLE
7081 005302 013737 001524 001122      MOV      DRVCSR,#BDADR  ;SET UP CSR ADRS
7082 005310 012737 001702 001124      MOV      #1702,#GDDAT  ;LD EXPECTED
7083 005316 017737 174202 001126      MOV      @DRVCSR,#BDDAT ;READ THE CSR
7084 005324 042777 000100 174172      BIC      #100,@DRVCSR   ;CLR INTR ENABLE
7085 005332 104005                ERROR    5              ;WCO FAILED TO INTERRUPT (SNGL CYCL ON COULD CAUSE THIS)
7086 005334 000416                BR       2#             ;GO RESTORE VECTOR
7087 005336 022626                1#:     CMP      (SP)+,(SP)+ ;INTR RETURNS HERE - FIX STACK SINCE NO RTI
7088 005340 004537 010142                JSR      R5,CKSTAT     ;GO CHECK STATUS
7089 005344 001702                1702
7090 005346 000310                200.
7091 005350 104007                ERROR    7              ;RETURN HERE IF STATUS ER - EXPECTED STAT C.
7092
7093 005352 000407                BR       2#             ;CYCLE, READY, IE & FNCT 1
7094 005354 104010                ERROR    10            ;GO RESTORE VECTOR
7095 005356 000405                BR       2#             ;RETURN HERE IF WC ER - EXPECTED 0
7096 005360 104011                ERROR    11            ;GO RESTORE VECTOR
7097 005362 000403                BR       2#             ;RETURN HERE IF BAR ER - SHOULD = DBUF+620
7098 005364 004737 010444                JSR      PC,CKDAT     ;GO RESTORE VECTOR
7099 005370 104013                ERROR    13            ;RETURN HERE IF OK - NOW GO CHECK DATA
7100 005372 004737 010116                2#:     JSR      PC,RSTVEC   ;RETURN HERE IF DATA ER - DBR CONTAINS WRONG DATA
7101
7102
7103
7104
7105 005376 000004                ;;*****
7106 005400 012737 000010 001160                :*TEST 23      TEST THAT THE CPU IS LOCKED OUT WITH SINGLE CYCLE OFF
7107 005406 013737 001524 001122                ;;*****
7108 005414 004537 010076                TST23:  SCOPE
7109 005420 005530                MOV      #10,#TIMES    ;;DO 10 ITERATIONS
7110 005422 012700 000010                MOV      DRVCSR,#BDADR ;SET UP CSR ADRS
7111 005426 005037 001126                JSR      R5,SETVEC     ;GO SET UP INTR RETURN
7112 005432 012777 177470 174060 1#:     3#      3#              ;RETURN TO 3# ON INTR
7113 005440 012777 015364 174054                MOV      #10,R0        ;DO EIGHT 200 WORD XFER'S
7114 005446 106427 000000                CLR      #BDDAT        ;USR #BDDAT AS A COUNTER
7115 005452 012777 000101 174044                MOV      #-200.,@DRVWCR ;DO 200 XFERS (DATI'S)
7116 005460 052777 000400 174036                MOV      @DBUF,@DRVBAR ;FROM DBUF
7117 005466 005201 5#:     MTPS     #0              ;ALLOW AN INTR
7118 005470 001376                MOV      #101,@DRVCSR  ;SET IE & GO
7119 005472 000240                BIS      #400,@DRVCSR  ;SET CYCLE
7120 005474 005237 001126                2#:     INC      R1              ;INCREMENT R1 -DD001
7121 005500 001375                BNE      5#             ;DD001
7122 005502 012737 000700 001124                INC      #BDDAT        ;START COUNTING - SHOULD NEVER GET HERE
7123 005510 C17737 174010 001126                BNE      2#             ;UNTIL 64K
7124 005516 042777 000100 174000                MOV      #700,#GDDAT   ;LD EXPECTED
7125 005524 104005                MOV      @DRVCSR,#BDDAT ;READ STATUS
7126 005526 000407                BIC      #100,@DRVCSR   ;CLR IE
7127 005530 022626                3#:     ERROR    5              ;NO INTERRUPT ON 200 DATI'S
7128 005532 005300                BR       4#             ;GO RESTORE VECTOR
7129 005534 001336                CMP      (SP)+,(SP)+   ;FIX STACK SINCE NO RTI
7130 005536 005737 001126                DEC      R0              ;DONE 8 TIMES?
7131 005542 001401                BNE      1#             ;BR IF NOT
7132 005544 104014                TST      #BDDAT        ;SHOULD STILL BE ZERO
                                BEQ      4#             ;BR IF SO
                                ERROR    14            ;BURST MD (SINGLE CYCLE=0) FAILS TO LOCK OUT CPU

```

```
7133 005546 004737 010116 4$: JSR PC,RSTVEC ;GO RESTORE VECTOR
7134
7135 ;*****
7136 ;*TEST 24 TEST THAT THE CPU IS NOT LOCKED OUT WITH SINGLE CYCLE ON
7137 ;*****
7138 005552 000004 TST24: SCOPE
7139 005554 012737 000010 001160 MOV #10,#TIMES ;DO 10 ITERATIONS
7140 005562 013737 001524 001122 MOV DRVCSR,#BDADR ;SET UP CSR ADRS
7141 005570 004537 010076 JSR R5,SETVEC ;GO SET UP INTR RETURN
7142 005574 005702 3$ ;RETURN TO 3$ ON INTR
7143 005576 012700 000010 MOV #10,R0 ;DO EIGHT 200 WORD XFER'S
7144 005602 012737 000000 001126 MOV #0,#BDDAT ;USE #BDDAT AS A COUNTER
7145 005610 012777 177470 173702 1$: MOV #-200.,@DRVWCR ;DO 200 XFERS (DATI'S)
7146 005616 012777 015364 173676 MOV @DBUF,@DRVBAR ;FROM DBUF
7147 005624 106427 000000 MTPS #0 ;ALLOW AN INTR
7148 005630 012777 000111 173666 MOV #111,@DRVCSR ;SET IE, FNCT3 & GO
7149 005636 052777 000400 173660 BIS #400,@DRVCSR ;SET CYCLE
7150 005644 000240 NOP ;FREEBEE
7151 005646 005237 001126 2$: INC #BDDAT ;START COUNTING
7152 005652 001375 BNE 2$ ;UNTIL 64K - SHOULD INTR BEFORE OVERFLOW
7153 005654 012737 004710 001124 MOV #4710,#GDDAT ;LD EXPECTED
7154 005662 017737 173636 001126 MOV @DRVCSR,#BDDAT ;READ STATUS
7155 005670 042777 000100 173626 BIC #100,@DRVCSR ;CLR IE
7156 005676 104005 ERROR 5 ;NO INTERRUPT ON 200 DATI'S (WITH SINGLE CYCLE)
7157 005700 000423 BR 5$ ;GO RESTORE VECTOR
7158 005702 022626 3$: CMP (SP)+,(SP)+ ;FIX STACK SINCE NO RTI
7159 005704 005300 DEC R0 ;DONE 8 TIMES?
7160 005706 001340 BNE 1$ ;BR IF NOT
7161 005710 022737 000000 001126 CMP #0,#BDDAT ;#BDDAT SHOULD HAVE BEEN COUNTED
7162 005716 103401 BCS 4$ ;BR IF SO
7163 005720 104015 ERROR 15 ;CPU APPEARED LOCKED OUT WITH SINGLE CYCLE SET
7164 005722 017737 173576 001126 4$: MOV @DRVCSR,#BDDAT ;READ STATUS
7165 005730 012737 004710 001124 MOV #4710,#GDDAT ;LD EXPECTED
7166 005736 023737 001124 001126 CMP #GDDAT,#BDDAT ;CORRECT?
7167 005744 001401 BEQ 5$ ;BR IF SO
7168 005746 104007 ERROR 7 ;STATUS INCORRECT ON XFER WITH SINGLE CYCLE SET
7169 005750 004737 010116 5$: JSR PC,RSTVEC ;GO RESTORE VECTOR
7170
7171 ;*****
7172 ;*TEST 25 TEST THAT MAINT MODE CONTROLS FNCT BITS, XFER DIR & SINGLE CYCLE
7173 ;*****
7174 005754 000004 TST25: SCOPE
7175 005756 012737 000200 001160 MOV #200,#TIMES ;DO 200 ITERATIONS
7176 005764 004537 010076 JSR R5,SETVEC ;GO SET UP INTR RETURN
7177 005770 006106 2$ ;RETURN TO 2$ ON INTR
7178 005772 004737 010374 JSR PC,LDBUF1 ;GO SET UP DBUF (SPECIAL COM PATTERN)
7179 005776 012737 011702 006114 MOV #11702,3$ ;3$ CONTAINS EXPECTED STATUS
7180 006004 012737 000001 006116 MOV #1,4$ ;4$ CONTAINS THE CURRENT XFER NO # (MAX 8)
7181 006012 106427 000000 1$: MTPS #0 ;ALLOW INTR
7182 006016 012777 015364 173476 MOV @DBUF,@DRVBAR ;SET UP CURRENT ADRS
7183 006024 013777 006116 173466 MOV 4,@DRVWCR ;GET XFER #
7184 006032 005477 173462 NEG @DRVWCR ;NEGATE FOR WC
7185 006036 012777 010101 173460 MOV #10101,@DRVCSR ;SET UP MAINT, IE & GO
7186 006044 052777 000400 173452 BIS #400,@DRVCSR ;SET CYCLE
7187 006052 013737 001524 001122 MOV DRVCSR,#BDADR ;SET UP CSR ADRS
7188 006060 013737 006114 001124 MOV 3,#GDDAT ;LD EXPECTED
```



```

7189 006066 017737 173432 001126      MOV      @DRVCSR,#BDDAT ;READ STATUS
7190 006074 042777 000100 173422      BIC      #100,@DRVCSR ;DISABLE IE
7191 006102 104005                      ERROR    5 ;NO INTR ON XFER (IN MAINT MD)
7192 006104 000440                      BR       6$ ;GO RESTORE VECTOR
7193 006106 022626                      2$:    CMP      (SP)+,(SP)+ ;RETURN HERE ON INTR - FIX STACK SINCE NO RTI
7194 006110 004537 010142                      JSR      R5,CKSTAT ;GO CHECK STATUS
7195 006114 011702                      3$:    11702 ;THIS LOCATION WILL CONTAIN EXPECTED STATUS
7196 006116 000001                      4$:    1 ;THIS LOCATION WILL CONTAIN CURRENT XFER # (MAX 8)
7197 006120 104007                      ERROR    7 ;RETURN HERE IF STATUS ER - WILL EXPECT
7198                                     ;MAINT, COUNT INCREASE OF FNCT & STAT BITS,
7199                                     ;CYCLE, READY & IE
7200 006122 000431                      BR       6$ ;GO RESTORE VECTOR
7201 006124 104010                      ERROR    10 ;RETURN HERE IF WC ER - SHOULD BE 0
7202 006126 000427                      BR       6$ ;GO RESTORE VECTOR
7203 006130 104011                      ERROR    11 ;RETURN HERE IF BAR ER-
7204 006132 000425                      BR       6$ ;GO RESTORE VECTOR
7205 006134 062737 001002 006114      ADD      #1002,3$ ;RETURN HERE IF OK - ADVANCE EXPECTED STATUS LOC
7206 006142 032737 020000 006114      BIT      #BIT13,3$ ;LOOK FOR OVERFLOW
7207 006150 001403                      BEQ      5$ ;BR IF NOT
7208 006152 012737 010700 006114      MOV      #10700,3$ ;FNCT & STAT BITS SHOULD BE ZERO THIS TIME
7209 006160 005237 006116                      5$:    INC      4$ ;ADVANCE CURRENT XFER #
7210 006164 022737 000011 006116      CMP      #11,4$ ;HAVE 10 XFERS BEEV DONE
7211 006172 001307                      BNE     1$ ;BR IF NOT
7212 006174 004537 010512                      JSR      R5,CKDAT1 ;NOW GO CHECK DATA
7213 006200 000010                      10 ;# OF XFER'S TO CHECK
7214 006202 104013                      ERROR    13 ;RETURN HERE IF DATA ER - (WITH MAINT SET)
7215 006204 000240                      NOP ;RESTORE VECTOR NEXT
7216 006206 004737 010116                      6$:    JSR      PC,RSTVEC ;GO RESTORE VECTOR
7217
7218
7219                                     ;;*****
7219                                     ;*TEST 26 TEST THAT A DATI FROM A NON-EXISTANT BUS ADRS SETS 'NEX'
7220                                     ;;*****
7221 006212 000004                      TST26:  SCOPE
7222 006214 012737 000100 001160      MOV      #100,$TIMES ;DO 100 ITERATIONS
7223 006222 012700 000002                      MOV      #2,R0 ;R0 WHEN ZERO SAYS CLR 'NEX' WITH RESET
7224 006226 004537 010076                      1$:    JSR      R5,SETVEC ;GO SET UP INTERRUPT RETURN
7225 006232 006324                      2$:    ;RETURN TO 2$ ON TIMEOUT INTR
7226 006234 012777 177777 173256      MOV      #-1,@DRVWCR ;SET UP FOR ONE XFER'S
7227 006242 012777 160000 173252      MOV      #160000,@DRVBAR ;SET UP CA TO 160000 (RESERVED)
7228 006250 106427 000000                      MTPS    #0 ;ALLOW INTR
7229 006254 012777 000161 173242      MOV      #161,@DRVCSR ;SET IE, XAD 17,16 & GO
7230 006262 052777 000400 173234      BIS      #400,@DRVCSR ;SET CYCLE
7231 006270 013737 001524 001122      MOV      DRVCSR,#BDADR ;SET UP CSR ADRS - SHOULD NEVER GET HERE
7232 006276 012737 140760 001124      MOV      #140760,$GDDAT ;LD EXPECTED
7233 006304 017737 173214 001126      MOV      @DRVCSR,#BDDAT ;GIVE THEM THE STATUS
7234 006312 042777 000100 173204      BIC      #100,@DRVCSR ;CLR IE
7235 006320 104016                      ERROR    16 ;NEX FAILED TO CAUSE AN INTERRUPT
7236 006322 000521                      BR       7$ ;GO RESTORE VECTOR
7237 006324 022626                      2$:    CMP      (SP)+,(SP)+ ;SHOULD INTR RETURN HERE - FIX STACK
7238 006326 017737 173172 001126      MOV      @DRVCSR,#BDDAT ;READ THE CSR
7239 006334 012737 140760 001124      MOV      #140760,$GDDAT ;LD EXPECTED
7240 006342 023737 001124 001126      CMP      $GDDAT,$BDDAT ;CORRECT?
7241 006350 001405                      BEQ     3$ ;BR IF SO
7242 006352 013737 001524 001122      MOV      DRVCSR,#BDADR ;SET UP CSR ADRS
7243 006360 104016                      ERROR    16 ;STATUS ER - EXPECTED
7244                                     ;ER, NEX, CYCLE, READY, IE, XAD17 & XAD16

```

```

7245 006362 000501          BR      7$          ;GO RESTORE VECTOR
7246 006364 017737 173130 001126 3$:  MOV     @DRVWCR,$BDDAT ;READ WORD COUNT
7247 006372 012737 177777 001124      MOV     #-1,$GDDAT   ;SHOULD STILL HAVE -1
7248 006400 023737 001124 001126      CMP     $GDDAT,$BDDAT ;CORRECT?
7249 006406 001405          BEQ     4$          ;BR IF SO
7250 006410 013737 001520 001122      MOV     DRVWCR,$BDADR ;SET UP WCR ADRS
7251 006416 104010          ERROR   10         ;WC INCREMENTED ON A TIMEOUT ER
7252 006420 000462          BR      7$          ;GO RESTORE VECTOR
7253 006422 017737 173074 001126 4$:  MOV     @DRVBAR,$BDDAT ;READ BUFFER ADRS
7254 006430 012737 160000 001124      MOV     @160000,$GDDAT ;SHOULD NOT HAVE INCREMENTED
7255 006436 023737 001124 001126      CMP     $GDDAT,$BDDAT ;CORRECT?
7256 006444 001405          BEQ     5$          ;BR IF SO
7257 006446 013737 001522 001122      MOV     DRVBAR,$BDADR ;SET UP BAR ADRS
7258 006454 104011          ERROR   11         ;BAR INCREMENTED ON A TIMEGUT ER
7259 006456 000443          BR      7$          ;GO RESTORE VECTOR
7260 006460 005300          5$:  DEC     R0          ;KEEP TRACK ON HOW TO CLR
7261 006462 001422          BEQ     6$          ;BR IF CLR BY RESET
7262 006464 042777 040000 173032      BIC     @40000,@DRVCSR ;WRITE NEX TO ZERO
7263 006472 017737 173026 001126      MOV     @DRVCSR,$BDDAT ;READ CSR
7264 006500 012737 000760 001124      MOV     @760,$GDDAT   ;LD EXPECTED
7265 006506 023737 001124 001126      CMP     $GDDAT,$BDDAT ;CORRECT?
7266 006514 001644          BEQ     1$          ;BR IF SO + REPEAT TEST FOR RESET TEST
7267 006516 013737 001524 001122      MOV     DRVCSR,$BDADR ;SET UP CSR ADRS
7268 006524 104016          ERROR   16         ;'NEX' FAILED TO WRITE TO ZERO
7269 006526 000417          BR      7$          ;GO RESTORE VECTOR
7270 006530 000005          6$:  RESET          ;ISSUE BUS RESET
7271 006532 017737 172766 001126      MOV     @DRVCSR,$BDDAT ;READ THE CSR
7272 006540 012737 000200 001124      MOV     @200,$GDDAT   ;EXPECT ONLY READY
7273 006546 023737 001124 001126      CMP     $GDDAT,$BDDAT ;CORRECT?
7274 006554 001404          BEQ     7$          ;BR IF SO
7275 006556 013737 001524 001122      MOV     DRVCSR,$BDADR ;SET UP CSR ADRS
7276 006564 104016          ERROR   16         ;RESET FAILED TO CLR 'NEX'
7277 006566 004737 010116      7$:  JSR     PC,RSTVEC   ;GO RESTORE VECTOR
7278                                     ;:*****
7279                                     ;*TEST 27      TEST 200 NPR TRANSFERS IN MAINT MODE
7280                                     ;:*****
7281 006572 000004          TST27: SCOPE
7282 006574 012737 000010 001160      MOV     @10,$TIMES   ;;DO 10 ITERATIONS
7283 006602 004537 010076          JSR     R5,SETVEC    ;GO SET UP INTR RETURN
7284 006606 006720          2$:
7285 006610 004737 010374          JSR     PC,LDBUF1    ;RETURN TO 2$ ON INTR
7286 006614 012777 015364 172700      MOV     @DBUF,@DRVBAR ;GO SET UP DBUF (SPECIAL COM PATTERN)
7287 006622 012777 177470 172670      MOV     #-200.,@DRVWCR ;SET UP CURRENT ADRS
7288 006630 106427 000000          MTPS   #0          ;SET UP FOR 200 XFER'S
7289 006634 012777 010101 172662      MOV     @10101,@DRVCSR ;ALLOW INTR
7290 006642 052777 000400 172654      BIS     @400,@DRVCSR  ;SET MAINT, IE & GO
7291 006650 012737 000000 001126      MOV     @0,$BDDAT    ;SET CYCLE
7292 006656 005237 001126          1$:  INC     $BDDAT       ;SET UP A COUNTER
7293 006662 001375          BNE     1$          ;COUNT AWAY
7294 006664 013737 001524 001122      MOV     DRVCSR,$BDADR ;WAIT TILL DONE - SHOULD INTR BEFORE OVFL0
7295 006672 012737 010700 001124      MOV     @10700,$GDDAT ;SET UP CSR ADRS
7296 006700 017737 172620 001126      MOV     @DRVCSR,$BDDAT ;LD EXPECTED
7297 006706 042777 000100 172610      BIC     @100,@DRVCSR  ;READ STATUS
7298 006714 104005          ERROR   5          ;DISABLE IE
7299 006716 000420          BR      3$          ;NO INTR AFTER 200 MAINT MODE XFER'S
7300 006720 022626          2$:  CMP     (SP)+,(SP)+  ;GO RESTORE VECTOR
                                     ;RETURN HERE ON INTR - FIX STACK SINCE NO RTI

```



```

7301 006722 004537 010142      JSR      R5,CKSTAT      ;GO CHECK STATUS
7302 006726 010700              10700      ;EXPECTED STATUS
7303 006730 000310              200.      ;# OF XFRS
7304 006732 104007              ERROR     7      ;RETURN HERE IF STATUS ER - EXPECTED MAINT,
7305                                ;CYCLE, READY & IE
7306 006734 000411              BR        3#      ;GO RESTORE VECTOR
7307 006736 104010              ERROR     10     ;RETURN HERE IF WC ER - SHOULD BE 0
7308 006740 000407              BR        3#      ;GO RESTORE VECTOR
7309 006742 104011              ERROR     11     ;RETURN HERE IF BAR ER - SHOULD = DBUF+620
7310 006744 000405              BR        3#      ;GO RESTORE VECTOR
7311 006746 004537 010512      JSR      R5,CKDAT1     ;RETURN HERE IF OK - NOW GO CHECK DATA
7312 006752 000310              200.      ;# OF XFER'S TO CHECK
7313 006754 104013              ERROR     13     ;RETURN HERE IF DATA ER - (WITH MAINT SET)
7314 006756 000240              NOP
7315 006760 004737 010116      3#:      JSR      PC,RSTVEC ;GO RESTORE VECTOR
7316                                ;*****
7317                                ;*TEST 30      TEST A 200 WORD MAINT MODE XFER TO EACH ADDITIONAL AVAILABLE 4K
7318                                ;*****
7319 006764 000004              TST30:  SCOPE
7320 006766 012737 000005 001160      MOV      #5,#TIMES    ;;DO 5 ITERATIONS
7321 006774 004537 010076              JSR      R5,SETVEC    ;GO SET UP INTR RETURN
7322 007000 007134              3#      ;RETURN TO 3# ON INTR
7323 007002 005037 001542              CLR      DBUFP        ;GET LOWEST BUFFER ADRS
7324 007006 062737 020000 001542 1#:      ADD      #20000,DBUFP ;POINT TO NEXT 4K
7325 007014 023737 001540 001542      CMP      CORSZ,DBUFP  ;IS THE 4K THERE?
7326 007022 001465              BEQ      4#          ;BR IF NOT
7327 007024 004737 010374              JSR      PC,LDBUF1    ;GO SET UP SPECIAL COMPEMENT PATTERN
7328 007030 013777 001542 172464      MOV      DBUFP,@DRVBAR ;SET UP BUFFER ADRS
7329 007036 012777 177470 172454      MOV      #-200.,@DRVWCR ;SET UP FOR 200 XFER'S
7330 007044 106427 000000              MTPS     #0          ;ALLOW INTR
7331 007050 012777 010101 172446      MOV      #10101,@DRVCSR ;SET MAINT,IE & GO
7332 007056 052777 000400 172440      BIS      #400,@DRVCSR  ;SET CYCLE
7333 007064 012737 000000 001126      MOV      #0,#BDDAT    ;SET UP A COUNTER
7334 007072 005237 001126      2#:      INC      #BDDAT      ;COUNT AWAY
7335 007076 001375              BNE      2#          ;SHOULD ALWAYS INTR FROM THIS LOOP
7336 007100 013737 001524 001122      MOV      DRVCSR,#BDADR ;SET UP CSR ADRA
7337 007106 012737 010700 001124      MOV      #10700,#GDDAT ;LD EXPECTED
7338 007114 017737 172404 001126      MOV      @DRVCSR,#BDDAT ;READ CSR
7339 007122 042777 000100 172374      BIC      #100,@DRVCSR  ;DISABLE IE
7340 007130 104005              ERROR     5          ;NO INTR AFTER 200 MAINT MODE XFER'S
7341 007132 000421              BR        4#          ;GO RESTORE VECTOR
7342 007134 022626              3#:      CMP      (SP)+,(SP)+  ;RETURN HERE ON INTR - FIX STACK SINCE NO RTI
7343 007136 004537 010142      JSR      R5,CKSTAT    ;GO CHECK STATUS
7344 007142 010700              10700      ;EXPECTED STATUS
7345 007144 000310              200.      ;# OF XFER'S
7346 007146 104007              ERROR     7      ;RETURN HERE IF STATUS ER - EXPECTED MAINT,
7347                                ;CYCLE, READY & IE
7348 007150 000412              BR        4#      ;GO RESTORE VECTOR
7349 007152 104010              ERROR     10     ;RETURN HERE IF WC ER - SHOULD = 0
7350 007154 000410              BR        4#      ;GO RESTORE VECTOR
7351 007156 104011              ERROR     11     ;RETURN HERE IF BAR ER - SHOULD = DBUFP+620
7352 007160 000406              BR        4#      ;GO RESTORE VECTOR
7353 007162 004537 010512      JSR      R5,CKDAT1     ;RETURN HERE IF OK - NOW GO CK DATA
7354 007166 000310              200.      ;# OF XFER'S TO CK
7355 007170 104013              ERROR     13     ;RETURN HERE IF DATA ER
7356 007172 000401              BR        4#      ;GO RESTORE VECTOR
  
```

```

7357 007174 000704          BR      1$          ;TRY NEXT BANK
7358 007176 012737 015364 001542 4$:  MOV      @DBUF,DBUFP ;RESTORE BUFFER ADRS TO LOWEST 4K
7359 007204 004737 010116          JSR      PC,RSTVEC ;GO RESTORE VECTOR
7360          ;*****
7361          ;*TEST 31      TEST THE ADDRESS (I/O) ABILITY TO THE TTY PRINTER CSR
7362          ;*****
7363 007210 000004          TST31: SCOPE
7364 007212 105777 171722          TSTB     @SWR          ;KDF11-B?
7365 007216 100507          BMI     ALTERN        ;IF YES,GO TO THE NEXT SUBTEST
7366 007220 004537 010076          101$:  JSR      R5,SETVEC ;GO SET UP INTR RETURN
7367 007224 007330          1$     ;RETURN TO 1$ ON INTR
7368 007226 012777 177777 172264  MOV      #-1,@DRVWCR ;SET UP WC - 1 XFER
7369 007234 013737 001150 001542  MOV      $TPS,DBUFP   ;SET UP BUFFER ADRS TO PRINTER CSR ADRS
7370 007242 013777 001150 172252  MOV      $TPS,@DRVBAR ;SET UP BUFFER ADRS - FROM PRINTER CSR
7371 007250 106427 000000          MTPS    #0           ;ALLOW INTR
7372 007254 005077 172246          CLR     @DRVDBR      ;ZERO THE DBR
7373 007260 012777 000161 172236  MOV      @161,@DRVCSR ;SET IE, XAD17 & XAD16, & GO
7374 007266 052777 000400 172230  BIS     @400,@DRVCSR ;SET CYCLE
7375 007274 013737 001524 001122  MOV      DRVCSR,@BDADR ;SET UP CSR ADRS
7376 007302 012737 000760 001124  MOV      @760,$GDDAT  ;LD EXPECTED STATUS
7377 007310 017737 172210 001126  MOV      @DRVCSR,@BDDAT ;READ THE CSR
7378 007316 042777 000100 172200  BIC     @100,@DRVCSR ;DISABLE IE
7379 007324 104005          ERROR   5           ;NO INTR ON 1 WD XFER FROM XCSR
7380 007326 000434          BR      2$          ;GO RESTORE VECTOR
7381 007330 022626          1$:   CMP     (SP)+,(SP)+ ;INTR RETURNS HERE - FIX STK SINCE NO RTI
7382 007332 004537 010142          JSR      R5,CKSTAT  ;GO CK STATUS
7383 007336 000760          760    ;CSR EXPECTED STATUS
7384 007340 000001          1      ;# OF XFER'S
7385 007342 104007          ERROR   7           ;RETURN HERE IF STATUS ER - EXPECTED CYCLE.
7386          ;XAD17 & XAD16, RDY & IE
7387 007344 000425          BR      2$          ;GO RESTORE VECTOR
7388 007346 104010          ERROR   10          ;RETURN HERE IF WC ER - EXPECTED 0
7389 007350 000423          BR      2$          ;GO RESTORE VECTOR
7390 007352 104011          ERROR   11          ;RETURN HERE IF BAR ER - SHOULD = XCSR+2
7391 007354 000421          BR      2$          ;GO RESTORE VECTOR
7392 007356 017737 171566 001124  MOV      @TPS,$GDDAT  ;RETURN HERE IF OK - GET XCSR CONTENTS
7393 007364 017737 172136 001126  MOV      @DRVDBR,@BDDAT ;READ DBR
7394 007372 023737 001124 001126  CMP     $GDDAT,@BDDAT ;CORRECT?
7395 007400 001407          BEQ     2$          ;BR IF SO
7396 007402 013737 001526 001122  MOV      DRVDBR,@BDADR ;SET UP DBR ADRS
7397 007410 013737 001150 001120  MOV      $TPS,$GDADR  ;GET ADRS OF DATA (XCSR)
7398 007416 104020          ERROR   20          ;DATA ER FROM TTY PRINTER CSR
7399 007420 012737 015364 001542 2$:  MOV      @DBUF,DBUFP ;RESTORE BUFFER ADRS TO LOWEST 4K
7400 007426 004737 010116          JSR      PC,RSTVEC  ;GO RESTORE VECTOR
7401 007432 000137 007656          JMP     NXDEV        ;IGNORE NEXT 'SUBTEST
7402
7403          ;*****
7404          ;IN CASE OF KDF11-B TEST SOME SPECIFIED I/O PAGE
7405          ;*****
7406 007436 005737 001544          ALTERN: TST     IOPAGE ;I/O TRANSFER DESIRED?
7407 007442 001505          BEQ     NXDEV        ;IF NOT, SKIP THE TEST
7408 007444 004537 010076          JSR      R5,SETVEC  ;GO SET UP INTR RETURN
7409 007450 007554          1$     ;RETURN TO 1$ ON INTR
7410 007452 012777 177777 172040  MOV      #-1,@DRVWCR ;SET UP WC - 1 XFER
7411 007460 013737 001544 001542  MOV      IOPAGE,DBUFP ;SET UP BUFFER ADRS TO I/O CSR ADRS
7412 007466 013777 001544 172026  MOV      IOPAGE,@DRVBAR ;SET UP BUFFER ADRS - FROM I/O CSR
    
```





```

7469 007754          $EOP:
7470 007754 000240      NOP
7471 007756 005037 001102  CLR      $TSTNM      ;; ZERO THE TEST NUMBER
7472 007762 005037 001160  CLR      $TIMES      ;; ZERO THE NUMBER OF ITERATIONS
7473 007766 005237 001202  INC      $PASS       ;; INCREMENT THE PASS NUMBER
7474 007772 042737 100000 001202  BIC      $100000,$PASS ;; DON'T ALLOW A NEG. NUMBER
7475 010000 005327      DEC      (PC)+      ;; LOOP?
7476 010002 000001      $EOPCT: .WORD      1
7477 010004 003022      BGT      $DOAGN     ;; YES
7478 010006 012737      MOV      (PC)+,$(PC)+ ;; RESTORE COUNTER
7479 010010 000001      $ENDCT: .WORD      1
7480 010012 010002      $EOPCT
7481 010014 104401 010061  TYPE     , $ENDMG   ;; TYPE "END PASS #"
7482 010020 013746 001202  MOV      $PASS,-(SP) ;; SAVE $PASS FOR TYPEOUT
7483 010024 104405      TYPDS     ;; GO TYPE--DECIMAL ASCII WITH SIGN
7484 010026 104401 010056  TYPE     , $ENULL   ;; TYPE A NULL CHARACTER
7485 010032 013700 000042  $GET42: MOV      @42,R0 ;; GET MONITOR ADDRESS
7486 010036 001405      BEQ      $DOAGN     ;; BRANCH IF NO MONITOR
7487 010040 000005      RESET    ;; CLEAR THE WORLD
7488 010042 004710      $ENDAD: JSR     PC,(R0) ;; GO TO MONITOR
7489 010044 000240      NOP
7490 010046 000240      NOP      ;; SAVE ROOM
7491 010050 000240      NOP      ;; FOR
7492 010052      NOP      ;; ACT11
7493 010052 000137      $DOAGN: JMP      @(PC)+   ;; RETURN
7494 010054 002012      $RTNAD: .WORD    START1
7495 010056      377      377      000  $ENULL: .BYTE    -1,-1,0 ;; NULL CHARACTER STRING
7496 010061      015    042412 042116  $ENDMG: .ASCIZ   <15><12>/END PASS #/
       010066 050040 051501 020123
       010074 000043
7497
    
```



```

7499
7500
7501
7502
7503      .SBTTL  PROGRAM SUBROUTINES
7504
7505
7506      ;;*****
7507      ;THIS ROUTINE SETS THE PRIORITY LEVEL FOR NO INTERRUPT -
7508      ;SETS UP THE DRV11B INTERRUPT TO RETURN ON INTERRUPT
7509      ;TO THE ADDRESS INDICATED ((R5)) BY THE CALL +2
7510      ;;*****
7511      010076 106427 000200      SETVEC: MTPS    #200      ;SET UP FOR NO INTERRUPT
7512      010102 012577 171422      MOV      (R5)+, @DRVCT0  ;SET UP INTR RETURN ADRS
7513      010106 012777 000200 171416  MOV      #200, @DRVCT2  ;KEEP PRIORITY LEVEL AT TOP ON INTR
7514      010114 000205      RTS      R5      ;EXIT
7515
7516      ;;*****
7517      ;THIS ROUTINE CLEARS THE DRV11B CSR - RESTORES THE DRV11B
7518      ;INTERRUPT VECTOR TO A HALT - RAISES PRIORITY LEVEL
7519      ;;*****
7520      010116 005077 171402      RSTVEC: CLR     @DRVCSR   ;CLR STATUS & CONTROL
7521      010122 013777 001532 171400  MOV     DRVCT2, @DRVCT0 ;POINT VECTOR TO HALT
7522      010130 005077 171376      CLR     @DRVCT2      ;SET UP HALT
7523      010134 106427 000200      MTPS   #200      ;RAISE PRIORITY LEVEL
7524      010140 000207      RTS     PC      ;EXIT
7525
7526      ;;*****
7527      ;THIS ROUTINE CHECKS ON ALL DATA TRANSFERS FOR: CORRECT STATUS,
7528      ;CORRECT WORD COUNT & CORRECT BUFFER ADDRESS - THE EXPECTED DATA IS
7529      ;SUPPLIED IN THE CALL +2 & +4 - THE RETURN IS TO +22 IF NO ERRORS
7530      ;DETECTED - IF AN ERROR IS DETECTED THE RETURN IS TO THE APPROPRIATE ERROR EMT
7531      ;;*****
7532      010142 017737 171356 001126  CKSTAT: MOV     @DRVCSR, @BDDAT ;READ THE STATUS
7533      010150 042777 000100 171346  BIC     #100, @DRVCSR ;DISABLE THE IE BIT
7534      010156 012537 001124      MOV     (R5)+, @GDDAT ;SET UP EXPECTED STATUS
7535      010162 023737 001124 001126  CMP     @GDDAT, @BDDAT ;CORRECT?
7536      010170 001406      BEQ     1$ ;BR IF SO
7537      010172 013737 001524 001122  MOV     DRVCSR, @BDADR ;SET UP CSR ADRS
7538      010200 062705 000002      ADD     #2, R5 ;POINT TO THE CSR ER
7539      010204 000205      RTS     R5 ;EXIT HERE ON STATUS ERROR
7540      010206 017737 171306 001126 1$: MOV     @DRVWCR, @BDDAT ;GET WC
7541      010214 001410      BEQ     2$ ;BR IF ZERO
7542      010216 013737 001520 001122  MOV     DRVWCR, @BDADR ;SET UP WCR ADRS
7543      010224 005037 001124      CLR     @GDDAT ;EXPECTED 0
7544      010230 062705 000006      ADD     #6, R5 ;POINT TO THE WCR ER
7545      010234 000205      RTS     R5 ;EXIT HERE ON WCR ER
7546      010236 011537 001124      2$: MOV     (R5), @GDDAT ;GET XFER #
7547      010242 006337 001124      ASL     @GDDAT ;CONVERT TO WORD
7548      010246 063737 001542 001124  ADD     DBUFP, @GDDAT ;POINT TO LAST XFER +2
7549      010254 017737 171242 001126  MOV     @DRVBAR, @BDDAT ;GET BA
7550      010262 042737 000001 001126  BIC     @BIT00, @BDDAT ;DON'T WANT BIT00
7551      010270 023737 001124 001126  CMP     @GDDAT, @BDDAT ;CORRECT?
7552      010276 001406      BEQ     3$ ;BR IF SO
7553      010300 013737 001522 001122  MOV     DRVBAR, @BDADR ;SET UP BAR ADRS
7554      010306 062705 000012      ADD     #12, R5 ;POINT TO BAR ER

```

```

7555 010312 000205
7556 010314 062705 000016
7557 010320 000205
7558
7559
7560
7561
7562
7563
7564
7565 010322 012703 015364
7566 010326 012704 177776
7567 010332 010423
7568 010334 005104
7569 010336 022703 016202
7570 010342 001003
7571 010344 012713 070707
7572 010350 000207
7573 010352 010423
7574 010354 022703 016202
7575 010360 001771
7576 010362 005104
7577 010364 006304
7578 010366 005204
7579 010370 103356
7580 010372 000757
7581
7582
7583
7584
7585
7586
7587
7588 010374 013703 001542
7589 010400 010305
7590 010402 062705 000620
7591 010406 012704 177776
7592 010412 010423
7593 010414 005023
7594 010416 005104
7595 010420 010423
7596 010422 005023
7597 010424 020503
7598 010426 001001
7599 010430 000207
7600 010432 005104
7601 010434 006304
7602 010436 005204
7603 010440 103362
7604 010442 000763
7605
7606
7607
7608
7609
7610

```

```

          RTS      R5          ;EXIT HERE ON BAR ER
3$:      ADD      #16,R5      ;ALL OK - POINT TO GOOD EXIT
          RTS      R5          ;EXIT HERE IF NO ERRORS

;*****
;THIS ROUTINE LOADS 'DBUF' WITH A FLOATING ZERO/ONE PATTERN
;FOR 199 LOCATIONS - THE LAST LOCATION IS LOADED WITH THE
;#70707 WHICH SHOULD BE THE DATA WORD AVAILABLE IN THE DBR
;AT THE COMPLETION OF A 200 WORD TRANSFER
;*****
LDBUF:   MOV      #DBUF,R3      ;GET BUFFER ADRS
1$:      MOV      #177776,R4    ;SET UP FLOATING ZERO PATRN
2$:      MOV      R4,(R3)+      ;LOAD IT (FLOATING 0)
          COM      R4          ;MAKE INTO FLOATING 1
          CMP      #DBUF+616,R3 ;AT END OF BUFFER?
          BNE     4$          ;BR IF NOT
3$:      MOV      #70707,(R3)   ;LOAD LAST DATVAR (SPECIAL)
          RTS      PC          ;GET OUT
4$:      MOV      R4,(R3)+      ;LOAD IT (FLOATING 1)
          CMP      #DBUF+616,R3 ;AT END OF BUFFER?
          BEQ     3$          ;BR IF SO
          COM      R4          ;BACK TO FLOATING ZERO
          ASL     R4          ;SHIFT LEFT
          INC     R4          ;KEEP LSB SET
          BCC     1$          ;GO RESET FLOATING PATRN
          BR      2$          ;GO LOAD NEXT PATRN

;*****
;THIS ROUTINE LOADS 'DBUF' WITH A UNIQUE FLOATING ZERO/ONE PATTERN
;(177776,0,1,0,177775,0,2,0,177773,0,4,0,177767,0,10,0 ETC.)
;IT IS USED WITH MAINT BIT SET (DATI/DATO SEQUENCE) - 200 LOCS
;ARE LOADED WITH THIS PATTERN
;*****
LDBUF1:  MOV      DBUF,R3      ;GET BUFFER ADRS
          MOV      R3,R5      ;SAVE IN R5
          ADD     #620,R5      ;POINT TO END OF BUFFER
1$:      MOV      #177776,R4    ;SET UP FLOATING ZERO PATRN
2$:      MOV      R4,(R3)+      ;LOAD IT (FLOATING 0)
          CLR     (R3)+      ;ZERO NEXT
          COM      R4          ;SET UP FLOATING 1
          MOV      R4,(R3)+      ;LOAD IT
          CLR     (R3)+      ;ZERO NEXT
          CMP     R5,R3      ;200 LOCS DONE?
          BNE     3$          ;BR IF NOT
          RTS     PC          ;GET OUT
3$:      COM      R4          ;BACK TO FLOATING ZERO
          ASL     R4          ;SHIFT LEFT
          INC     R4          ;KEEP LSB SET
          BCC     1$          ;GO RESET FLOATING PATRN
          BR      2$          ;GO FLOAT NEXT PATRN

;*****
;THIS ROUTINE CHECKS 200 LOCATIONS IN "DBUF" FOR GOOD TRANSFERED
;DATA (#177377) ON 'DATO' TRANSFERS - IF AN ERROR IS DETECTED
;THE RETURN IS TO CALL +2 - IF NO ERROR THE RETURN IS TO CALL +4
;*****

```



```

7611 010444 012701 015364      CKDAT:  MOV    #DBUF,R1      ;GET BUFFER ADRS
7612 010450 022721 177377      1#:    CMP    #177377,(R1)+  ;DATA OK?
7613 010454 001410              BEQ    2#                ;BR IF SO
7614 010456 013737 001526 001122  MOV    DRVDBR,#BDADR     ;SET UP DBR ADRS
7615 010464 014137 001126      MOV    -(R1),#BDDAT     ;GET ACTUAL DATA XFERED
7616 010470 010137 001120      MOV    R1,#GDADR       ;GET MEMORY ADRS
7617 010474 000207              RTS    PC                ;RETURN TO ERROR
7618 010476 022701 016204      2#:    CMP    #DBUF+620,R1 ;AT END OF 'DBUF'?
7619 010502 001362              BNE    1#                ;BR IF MORE
7620 010504 062716 000002      ADD    #2,(SP)         ;ADJUST STACK FOR GOOD RETURN
7621 010510 000207              RTS    PC                ;GET OUT
7622
7623
7624
7625
7626
7627
7628
7629
7630 010512 012500              ;;*****
7631 010514 013702 001542      ;THIS ROUTINE CHECK 200 LOCATIONS IN 'DBUF' FOR GOOD TRANSFERED
7632 010520 012701 177776      ;DATA (177776,177776,1,1,177775,177775,2,2,177773,177773,ETC.)
7633 010524 005003              ;ON MAINT MODE TRANSFERS - THE NUMBER OF CHECKS REQUIRED IS INDICATED
7634 010526 020122              ;BY THE CALL +2 - IF AN ERROR IS DETECTED THE RETURN IS TO CALL +4 -
7635 010530 001010              ;IF NO ERROR THE RETURN IS TO CALL +10
7636 010532 020122              ;;*****
7637 010534 001006              CKDAT1: MOV    (R5)+,R0     ;GET # OF CHECKS
7638 010536 162700 000002      MOV    DBUF,R2         ;GET BUFFER ADRS
7639 010542 003015              1#:    MOV    #177776,R1   ;SET UP FLOATING ZERO PATRN
7640 010544 062705 000004      CLR    R3              ;R3 SAYS WHEN TO SHIFT PATRN
7641 010550 000205              2#:    CMP    R1,(R2)+    ;DATA OK?
7642 010552 014237 001126      BNE    3#                ;BR IF NOT
7643 010556 010237 001120      CMP    R1,(R2)+    ;DATA WRITTEN OK?
7644 010562 010137 001124      BNE    3#                ;BR IF NOT
7645 010566 013737 001526 001122  SUB    #2,R0           ;ACCOUNT FOR TWO ADRS'S
7646 010574 000205              BGT    4#                ;BR IF MORE
7647 010576 005101              ADD    #4,R5           ;ADJUST FOR GOOD RETURN
7648 010600 005103              RTS    R5              ;EXIT
7649 010602 001351              3#:    MOV    -(R2),#BDDAT ;GET BAD DATA
7650 010604 006301              MOV    R2,#GDADR     ;GET MEM ADRS
7651 010606 005201              MOV    R1,#GDDAT     ;LD EXPECTED DATA
7652 010610 103343              MOV    DRVDBR,#BDADR ;SET UP DBR ADRS
7653 010612 000745              RTS    R5              ;RETURN TO ERROR
7654
7655
7656
7657
7658
7659
7660
7661
7662
7663
7664
7665
7666
7667
7668
7669
7670
7671
7672
7673
7674
7675
7676
7677
7678
7679
7680
7681
7682
7683
7684
7685
7686
7687
7688
7689
7690
7691
7692
7693
7694
7695
7696
7697
7698
7699
7700
7701
7702
7703
7704
7705
7706
7707
7708
7709
7710
7711
7712
7713
7714
7715
7716
7717
7718
7719
7720
7721
7722
7723
7724
7725
7726
7727
7728
7729
7730
7731
7732
7733
7734
7735
7736
7737
7738
7739
7740
7741
7742
7743
7744
7745
7746
7747
7748
7749
7750
7751
7752
7753
7754
7755
7756
7757
7758
7759
7760
7761
7762
7763
7764
7765
7766
7767
7768
7769
7770
7771
7772
7773
7774
7775
7776
7777
7778
7779
7780
7781
7782
7783
7784
7785
7786
7787
7788
7789
7790
7791
7792
7793
7794
7795
7796
7797
7798
7799
7800
7801
7802
7803
7804
7805
7806
7807
7808
7809
7810
7811
7812
7813
7814
7815
7816
7817
7818
7819
7820
7821
7822
7823
7824
7825
7826
7827
7828
7829
7830
7831
7832
7833
7834
7835
7836
7837
7838
7839
7840
7841
7842
7843
7844
7845
7846
7847
7848
7849
7850
7851
7852
7853
7854
7855
7856
7857
7858
7859
7860
7861
7862
7863
7864
7865
7866
7867
7868
7869
7870
7871
7872
7873
7874
7875
7876
7877
7878
7879
7880
7881
7882
7883
7884
7885
7886
7887
7888
7889
7890
7891
7892
7893
7894
7895
7896
7897
7898
7899
7900
7901
7902
7903
7904
7905
7906
7907
7908
7909
7910
7911
7912
7913
7914
7915
7916
7917
7918
7919
7920
7921
7922
7923
7924
7925
7926
7927
7928
7929
7930
7931
7932
7933
7934
7935
7936
7937
7938
7939
7940
7941
7942
7943
7944
7945
7946
7947
7948
7949
7950
7951
7952
7953
7954
7955
7956
7957
7958
7959
7960
7961
7962
7963
7964
7965
7966
7967
7968
7969
7970
7971
7972
7973
7974
7975
7976
7977
7978
7979
7980
7981
7982
7983
7984
7985
7986
7987
7988
7989
7990
7991
7992
7993
7994
7995
7996
7997
7998
7999
8000
    
```

7656  
7657  
7658  
7659  
7660  
7661  
7662  
7663  
7664  
7665  
7666  
7667  
7668  
7669  
7670  
7671  
7672  
7673  
7674  
7675  
7676  
7677  
7678  
7679  
7680  
7681  
7682  
7683  
7684  
7685  
7686  
7687  
7688  
7689  
7690  
7691  
7692  
7693  
7694  
7695  
7696  
7697  
7698  
7699  
7700  
7701  
7702  
7703  
7704  
7705  
7706  
7707  
7708  
7709  
7710  
7711

.SBTTL SYSMAC ROUTINES

.SBTTL TYPE ROUTINE

```

;*****
;*ROUTINE TO TYPE ASCIZ MESSAGE. MESSAGE MUST TERMINATE WITH A 0 BYTE.
;*THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED.
;*NOTE1:      #NULL CONTAINS THE CHARACTER TO BE USED AS THE FILLER CHARACTER.
;*NOTE2:      #FILLS CONTAINS THE NUMBER OF FILLER CHARACTERS REQUIRED.
;*NOTE3:      #FILLC CONTAINS THE CHARACTER TO FILL AFTER.
;*
;*CALL:
;*1) USING A TRAP INSTRUCTION
;*      TYPE      MESADR      ;;MESADR IS FIRST ADDRESS OF AN ASCIZ STRING
;*OR
;*      TYPE
;*      MESADR
;*
;*TYPE:  TSTB      #TPFLG      ;;IS THERE A TERMINAL?
;        BPL      1#          ;;BR IF YES
;        HALT     ;;HALT HERE IF NO TERMINAL
;        BR      3#          ;;LEAVE
;1#:    MOV      RO,-(SP)     ;;SAVE RO
;        MOV      @2(SP),RO   ;;GET ADDRESS OF ASCIZ STRING
;        CMPB    @APTENV,#ENV ;;RUNNING IN APT MODE
;        BNE    62#         ;;NO,GO CHECK FOR APT CONSOLE
;        BITB   @APTPOOL,#ENVM ;;SPOOL MESSAGE TO APT
;        BEQ    62#         ;;NO,GO CHECK FOR CONSOLE
;        MOV    RO,61#       ;;SETUP MESSAGE ADDRESS FOR APT
;        JSR   PC,#ATY3     ;;SPOOL MESSAGE TO APT
;        .WORD  0           ;;MESSAGE ADDRESS
;        BITB   @APTCSUP,#ENVM ;;APT CONSOLE SUPPRESSED
;        BNE    60#         ;;YES,SKIP TYPE OUT
;        MOVB   (RO)+,-(SP)  ;;PUSH CHARACTER TO BE TYPED ONTO STACK
;        BNE    4#          ;;BR IF IT ISN'T THE TERMINATOR
;        TST   (SP)+        ;;IF TERMINATOR POP IT OFF THE STACK
;        MOV   (SP)+,RO     ;;RESTORE RO
;        ADD   @2,(SP)     ;;ADJUST RETURN PC
;        RTI   ;;RETURN
;4#:    CMPB   @HT,(SP)    ;;BRANCH IF <HT>
;        BEQ   8#          ;;BRANCH IF NOT <CRLF>
;        CMPB   @CRLF,(SP)
;        BNE   5#          ;;POP <CR><LF> EQUIV
;        TST   (SP)+      ;;TYPE A CR AND LF
;        TYPE  ,#CRLF     ;;CLEAR CHARACTER COUNT
;        CLRB  #CHARCNT   ;;GET NEXT CHARACTER
;        BR   2#          ;;GO TYPE THIS CHARACTER
;5#:    JSR   PC,#TYPEC    ;;IS IT TIME FOR FILLER CHARS.?
;6#:    CMPB  #FILLC,(SP)+ ;;IF NO GO GET NEXT CHAR.
;        BNE  2#          ;;GET # OF FILLER CHARS. NEEDED
;        MOV  #NULL,-(SP)
    
```



```

7712
7713 010762 105366 000001      7$:  DECB  1(SP)      ;; AND THE NULL CHAR.
7714 010766 002770             BLT   6$           ;; DOES A NULL NEED TO BE TYPED?
7715 010770 004737 011026     JSR   PC,$TYPEC    ;; BR IF NO--GO POP THE NULL OFF OF STACK
7716 010774 105337 011144     DECB  $CHARCNT     ;; GO TYPE A NULL
7717 011000 000770             BR    7$           ;; DO NOT COUNT AS A COUNT
7718                                     ;; LOOP
7719
7720      ;HORIZONTAL TAB PROCESSOR
7721 011002 112716 000040     8$:  MOVB  #' ,(SP)      ;; REPLACE TAB WITH SPACE
7722 011006 004737 011026     9$:  JSR   PC,$TYPEC    ;; TYPE A SPACE
7723 011012 132737 000007 011144  BITB  #',$CHARCNT    ;; BRANCH IF NOT AT
7724 011020 001372             BNE   9$           ;; TAB STOP
7725 011022 005726             TST  (SP)+         ;; POP SPACE OFF STACK
7726 011024 000724             BR    2$           ;; GET NEXT CHARACTER
7727 011025      $TYPEC:
7728 011026 105777 170112     TSTB  #'TKS        ;; CHAR IN KYBD BUFFER?      ;MJD001
7729 011032 100022             BPL   10$          ;; BR IF NOT                    ;MJD001
7730 011034 017746 170106     MOV   #'TKB,-(SP)   ;; GET CHAR                      ;MJD001
7731 011040 042716 177600     BIC   #'177600,(SP) ;; STRIP EXTRANEIOUS BITS       ;MJD001
7732 011044 122716 000023     CMPB  #'XOFF,(SP)  ;; WAS CHAR XOFF                ;MJD001
7733 011050 001012             BNE   102$         ;; BR IF NOT                    ;MJD001
7734 011052
7735 011052 105777 170066     101$: TSTB  #'TKS        ;; WAIT FOR CHAR                ;MJD001
7736 011056 100375             BPL   101$         ;;                               ;MJD001
7737 011060 117716 170062     MOVB  #'TKB,(SP)    ;; GET CHAR                      ;MJD001
7738 011064 042716 177600     BIC   #'177600,(SP) ;; STRIP IT                      ;MJD001
7739 011070 122716 000021     CMPB  #'XON,(SP)   ;; WAS IT XON?                 ;MJD001
7740 011074 001366             BNE   101$         ;; BR IF NOT                    ;MJD001
7741 011076
7742 011076 005726             102$: TST  (SP)+         ;; FIX STACK                    ;MJD001
7743 011100
7744 011100 105777 170044     10$:  TSTB  #'TPS        ;; WAIT UNTIL PRINTER IS READY  ;MJD001
7745 011104 100375             BPL   10$          ;;                               ;MJD001
7746 011106 116677 000002 170036  MOVB  2(SP),#'TPB   ;; LOAD CHAR TO BE TYPED INTO DATA REG.
7747 011114 122766 000015 000002  CMPB  #'CR,2(SP)    ;; IS CHARACTER A CARRIAGE RETURN?
7748 011122 001003             BNE   1$           ;; BRANCH IF NO
7749 011124 105037 011144     CLRB  $CHARCNT     ;; YES--CLEAR CHARACTER COUNT
7750 011130 000406             BR    $TYPEX       ;; EXIT
7751 011132 122766 000012 000002  1$:  CMPB  #'LF,2(SP)  ;; IS CHARACTER A LINE FEED?
7752 011140 001402             BEQ   $TYPEX       ;; BRANCH IF YES
7753 011142 105227             INCB  (PC)+        ;; COUNT THE CHARACTER
7754 011144 000000      $CHARCNT: .WORD 0  ;; CHARACTER COUNT STORAGE
7755 011146 000207      $TYPEX: RTS   PC
7756
7757      .SBTTL  APT COMMUNICATIONS ROUTINE
7758
7759      ;; *****
7760 011150 112737 000001 011414  $ATY1: MOVB  #'1,$FFLG  ;; TO REPORT FATAL ERROR
7761 011156 112737 000001 011412  $ATY3: MOVB  #'1,$MFLG  ;; TO TYPE A MESSAGE
7762 011164 000403             BR    $ATYC
7763 011166 112737 000001 011414  $ATY4: MOVB  #'1,$FFLG  ;; TO ONLY REPORT FATAL ERROR
7764 011174      $ATYC:
7765 011174 010046             MOV   R0,-(SP)     ;; PUSH R0 ON STACK
7766 011176 010146             MOV   R1,-(SP)     ;; PUSH R1 ON STACK
7767 011200 105737 011412     TSTB  $MFLG       ;; SHOULD TYPE A MESSAGE?

```

```

7768 011204 001450      BEQ      5#           ;;IF NOT: BR
7769 011206 122737 000001 001214      CMPB     @APTENV,#ENV  ;;OPERATING UNDER APT?
7770 011214 001031      BNE      3#           ;;IF NOT: BR
7771 011216 132737 000100 001215      BITB     @APTSPOOL,#ENVM ;;SHOULD SPOOL MESSAGES?
7772 011224 001425      BEQ      3#           ;;IF NOT: BR
7773 011226 017600 000004      MOV      @4(SP),R0     ;;GET MESSAGE ADDR.
7774 011232 062766 000002 000004      ADD      @2,4(SP)      ;;BUMP RETURN ADDR.
7775 011240 005737 001174      1#:     TST      $MSGTYPE  ;;SEE IF DONE W/ LAST XMISSION?
7776 011244 001375      BNE      1#           ;;IF NOT: WAIT
7777 011246 010037 001210      MOV      R0,$MSGAD     ;;PUT ADDR IN MAILBOX
7778 011252 105720      2#:     TSTB     (R0)+      ;;FIND END OF MESSAGE
7779 011254 001376      BNE      2#           ;;
7780 011256 163700 001210      SUB      $MSGAD,R0     ;;SUB START OF MESSAGE
7781 011262 006200      ASR      R0           ;;GET MESSAGE LNGTH IN WORDS
7782 011264 010037 001212      MOV      R0,$MSGLGT    ;;PUT LENGTH IN MAILBOX
7783 011270 012737 000004 001174      MOV      @4,$MSGTYPE   ;;TELL APT TO TAKE MSG.
7784 011276 000413      BR       5#           ;;
7785 011300 017637 000004 011324 3#:     MOV      @4(SP),4#     ;;PUT MSG ADDR IN JSR LINKAGE
7786 011306 062766 000002 000004      ADD      @2,4(SP)      ;;BUMP RETURN ADDRESS
7787 011314 013746 177776      MOV      177776,-(SP)  ;;PUSH 177776 ON STACK
7788 011320 004737 010614      JSR      PC,$TYPE     ;;CALL TYPE MACRO
7789 011324 000000      4#:     .WORD    0
7790 011326      5#:
7791 011326 105737 011414      10#:    TSTB     $FFLG        ;;SHOULD REPORT FATAL ERROR?
7792 011332 001416      BEQ      12#          ;;IF NOT: BR
7793 011334 005737 001214      TST      $ENV         ;;RUNNING UNDER APT?
7794 011340 001413      BEQ      12#          ;;IF NOT: BR
7795 011342 005737 001174      11#:    TST      $MSGTYPE    ;;FINISHED LAST MESSAGE?
7796 011346 001375      BNE      11#          ;;IF NOT: WAIT
7797 011350 017637 000004 001176      MOV      @4(SP),$FATAL ;;GET ERROR #
7798 011356 062766 000002 000004      ADD      @2,4(SP)      ;;BUMP RETURN ADDR.
7799 011364 005237 001174      INC      $MSGTYPE     ;;TELL APT TO TAKE ERROR
7800 011370 105037 011414      12#:    CLRB     $FFLG        ;;CLEAR FATAL FLAG
7801 011374 105037 011413      CLRB     $LFLG        ;;CLEAR LOG FLAG
7802 011400 105037 011412      CLRB     $MFLG        ;;CLEAR MESSAGE FLAG
7803 011404 012601      MOV      (SP)+,R1     ;;POP STACK INTO R1
7804 011406 012600      MOV      (SP)+,R0     ;;POP STACK INTO R0
7805 011410 000207      RTS      PC           ;;RETURN
7806 011412 000      $MFLG: .BYTE 0       ;;MESSG. FLAG
7807 011413 000      $LFLG: .BYTE 0       ;;LOG FLAG
7808 011414 000      $FFLG: .BYTE 0       ;;FATAL FLAG
7809 011416      .EVEN
7810 000200      APTSIZE=200
7811 000001      APTENV=001
7812 000100      APTSPOOL=100
7813 000040      APTCSUP=040
7814      .SBTTL  BINARY TO OCTAL (ASCII) AND TYPE
7815
7816      ;;*****
7817      ;*THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 6-DIGIT
7818      ;*OCTAL (ASCII) NUMBER AND TYPE IT.
7819      ;*$TYPOS---ENTER HERE TO SETUP SUPPRESS ZEROS AND NUMBER OF DIGITS TO TYPE
7820      ;*CALL:
7821      ;*      MOV      NUM,-(SP)      ;;NUMBER TO BE TYPED
7822      ;*      TYPOS   ;;CALL FOR TYPEOUT
7823      ;*      .BYTE  N                ;;N=1 TO 6 FOR NUMBER OF DIGITS TO TYPE

```



```

7824      ;*      .BYTE  M          ;:M=1 OR 0
7825      ;*
7826      ;*
7827      ;*
7828      ;*$TYPON---ENTER HERE TO TYPE OUT WITH THE SAME PARAMETERS AS THE LAST
7829      ;*$TYPOS OR $TYPOC
7830      ;*CALL:
7831      ;*      MOV      NUM,-(SP)      ;:NUMBER TO BE TYPED
7832      ;*      TYPON          ;:CALL FOR TYPEOUT
7833      ;*
7834      ;*$TYPOC---ENTER HERE FOR TYPEOUT OF A 16 BIT NUMBER
7835      ;*CALL:
7836      ;*      MOV      NUM,-(SP)      ;:NUMBER TO BE TYPED
7837      ;*      TYPOC          ;:CALL FOR TYPEOUT
7838
7839      011416 017646 000000      $TYPOS: MOV      @ (SP),-(SP)      ;:PICKUP THE MODE
7840      011422 116637 000001 011641      MOV      1(SP),%OFILL      ;:LOAD ZERO FILL SWITCH
7841      011430 112637 011643      MOV      (SP)+,%OMODE+1      ;:NUMBER OF DIGITS TO TYPE
7842      011434 062716 000002      ADD      @2,(SP)          ;:ADJUST RETURN ADDRESS
7843      011440 000406      BR      $TYPON
7844      011442 112737 000001 011641      $TYPOC: MOV      @1,%OFILL      ;:SET THE ZERO FILL SWITCH
7845      011450 112737 000006 011643      MOV      @6,%OMODE+1      ;:SET FOR SIX(6) DIGITS
7846      011456 112737 000005 011640      $TYPON: MOV      @5,%OCNT      ;:SET THE ITERATION COUNT
7847      011464 010346      MOV      R3,-(SP)          ;:SAVE R3
7848      011466 010446      MOV      R4,-(SP)          ;:SAVE R4
7849      011470 010546      MOV      R5,-(SP)          ;:SAVE R5
7850      011472 113704 011643      MOV      %OMODE+1,R4      ;:GET THE NUMBER OF DIGITS TO TYPE
7851      011476 005404      NEG      R4
7852      011500 062704 000006      ADD      @6,R4          ;:SUBTRACT IT FOR MAX. ALLOWED
7853      011504 110437 011642      MOV      R4,%OMODE      ;:SAVE IT FOR USE
7854      011510 113704 011641      MOV      %OFILL,R4      ;:GET THE ZERO FILL SWITCH
7855      011514 016605 000012      MOV      12(SP),R5      ;:PICKUP THE INPUT NUMBER
7856      011520 005003      CLR      R3          ;:CLEAR THE OUTPUT WORD
7857      011522 006105      1$: ROL      R5          ;:ROTATE MSB INTO "C"
7858      011524 000404      BR      3$          ;:GO DO MSB
7859      011526 006105      2$: ROL      R5          ;:FORM THIS DIGIT
7860      011530 006105      ROL      R5
7861      011532 006105      ROL      R5
7862      011534 010503      MOV      R5,R3
7863      011536 006103      3$: ROL      R3          ;:GET LSB OF THIS DIGIT
7864      011540 105337 011642      DECB    %OMODE      ;:TYPE THIS DIGIT?
7865      011544 100016      BPL      7$          ;:BR IF NO
7866      011546 042703 177770      BIC      @177770,R3      ;:GET RID OF JUNK
7867      011552 001002      BNE      4$          ;:TEST FOR 0
7868      011554 005704      TST      R4          ;:SUPPRESS THIS 0?
7869      011556 001403      BEQ      5$          ;:BR IF YES
7870      011560 005204      4$: INC      R4          ;:DON'T SUPPRESS ANYMORE 0'S
7871      011562 052703 000060      BIS      @'0,R3      ;:MAKE THIS DIGIT ASCII
7872      011566 052703 000040      5$: BIS      @',R3      ;:MAKE ASCII IF NOT ALREADY
7873      011572 110337 011636      MOV      R3,@8$      ;:SAVE FOR TYPING
7874      011576 104401 011636      TYPE    ,8$          ;:GO TYPE THIS DIGIT
7875      011602 105337 011640      7$: DECB    %OCNT      ;:COUNT BY 1
7876      011606 003347      BGT      2$          ;:BR IF MORE TO DO
7877      011610 002402      BLT      6$          ;:BR IF DONE
7878      011612 005204      INC      R4          ;:INSURE LAST DIGIT ISN'T A BLANK
7879      011614 000744      BR      2$          ;:GO DO THE LAST DIGIT
    
```

```

7880 011616 012605      6$:  MOV    (SP)+,R5      ;;RESTORE R5
7881 011620 012604      MOV    (SP)+,R4      ;;RESTORE R4
7882 011622 012603      MOV    (SP)+,R3      ;;RESTORE R3
7883 011624 016666 000002 000004  MOV    2(SP),4(SP)   ;;SET THE STACK FOR RETURNING
7884 011632 012616      MOV    (SP)+,(SP)
7885 011634 000002      RTI                    ;;RETURN
7886 011636 000        8$:  .BYTE  0              ;;STORAGE FOR ASCII DIGIT
7887 011637 000        .BYTE  0              ;;TERMINATOR FOR TYPE ROUTINE
7888 011640 000        $OCNT: .BYTE  0          ;;OCTAL DIGIT COUNTER
7889 011641 000        $OFILL: .BYTE  0       ;;ZERO FILL SWITCH
7890 011642 000000      $OMODE: .WORD  0       ;;NUMBER OF DIGITS TO TYPE
7891                                     .SBTTL CONVERT BINARY TO DECIMAL AND TYPE ROUTINE
7892
7893                                     ;;*****
7894                                     ;*THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 5-DIGIT
7895                                     ;*SIGNED DECIMAL (ASCII) NUMBER AND TYPE IT. DEPENDING ON WHETHER THE
7896                                     ;*NUMBER IS POSITIVE OR NEGATIVE A SPACE OR A MINUS SIGN WILL BE TYPED
7897                                     ;*BEFORE THE FIRST DIGIT OF THE NUMBER. LEADING ZEROS WILL ALWAYS BE
7898                                     ;*REPLACED WITH SPACES.
7899                                     ;*CALL:
7900                                     ;*   MOV    NUM,-(SP)      ;;PUT THE BINARY NUMBER ON THE STACK
7901                                     ;*   TYPDS                    ;;GO TO THE ROUTINE
7902
7903                                     $TYPDS:
7904 011644 010046      MOV    R0,-(SP)      ;;PUSH R0 ON STACK
7905 011646 010146      MOV    R1,-(SP)      ;;PUSH R1 ON STACK
7906 011650 010246      MOV    R2,-(SP)      ;;PUSH R2 ON STACK
7907 011652 010346      MOV    R3,-(SP)      ;;PUSH R3 ON STACK
7908 011654 010546      MOV    R5,-(SP)      ;;PUSH R5 ON STACK
7909 011656 012746 020200  MOV    #20200,-(SP)  ;;SET BLANK SWITCH AND SIGN
7910 011662 016605 000020  MOV    20(SP),R5     ;;GET THE INPUT NUMBER
7911 011666 100004      BPL    1$            ;;BR IF INPUT IS POS.
7912 011670 005405      NEG    R5            ;;MAKE THE BINARY NUMBER POS.
7913 011672 112766 000055 000001  MOVB   #'-,1(SP)     ;;MAKE THE ASCII NUMBER NEG.
7914 011700 005000      1$:  CLR    R0            ;;ZERO THE CONSTANTS INDEX
7915 011702 012703 012060  MOV    #DBLK,R3      ;;SETUP THE OUTPUT POINTER
7916 011706 112723 000040  MOVB   #' ,(R3)+     ;;SET THE FIRST CHARACTER TO A BLANK
7917 011712 005002      2$:  CLR    R2            ;;CLEAR THE BCD NUMBER
7918 011714 016001 012050  MOV    $DTBL(R0),R1  ;;GET THE CONSTANT
7919 011720 160105      3$:  SUB    R1,R5        ;;FORM THIS BCD DIGIT
7920 011722 002402      BLT    4$            ;;BR IF DONE
7921 011724 005202      INC    R2            ;;INCREASE THE BCD DIGIT BY 1
7922 011726 000774      BR     3$
7923 011730 060105      4$:  ADD    R1,R5        ;;ADD BACK THE CONSTANT
7924 011732 005702      TST    R2            ;;CHECK IF BCD DIGIT=0
7925 011734 001002      BNE    5$            ;;FALL THROUGH IF 0
7926 011736 105716      TSTB   (SP)          ;;STILL DOING LEADING 0'S?
7927 011740 100407      BMI    7$            ;;BR IF YES
7928 011742 106316      5$:  ASLB   (SP)          ;;MSD?
7929 011744 103003      BCC    6$            ;;BR IF NO
7930 011746 116663 000001 177777  MOVB   1(SP),-1(R3)  ;;YES--SET THE SIGN
7931 011754 052702 000060  6$:  BIS    #'0,R2       ;;MAKE THE BCD DIGIT ASCII
7932 011760 052702 000040  7$:  BIS    #' ,R2       ;;MAKE IT A SPACE IF NOT ALREADY A DIGIT
7933 011764 110223      MOVB   R2,(R3)+     ;;PUT THIS CHARACTER IN THE OUTPUT BUFFER
7934 011766 005720      TST    (R0)+        ;;JUST INCREMENTING
7935 011770 020027 000010  CMP    R0,#10       ;;CHECK THE TABLE INDEX
  
```



```

7936 011774 002746          BLT      2$          ;;GO DO THE NEXT DIGIT
7937 011776 003002          BGT      8$          ;;GO TO EXIT
7938 012000 010502          MOV      R5,R2       ;;GET THE LSD
7939 012002 000764          BR       6$          ;;GO CHANGE TO ASCII
7940 012004 105726          8$:    TSTB     (SP)+   ;;WAS THE LSD THE FIRST NON-ZERO?
7941 012006 100003          BPL      9$          ;;BR IF NO
7942 012010 116663 177777 177776  MOVB    -1(SP),-2(R3) ;;YES--GET THE SIGN FOR TYPING
7943 012016 105013          9$:    CLRB     (R3)   ;;SET THE TERMINATOR
7944 012020 012605          MOV      (SP)+,R5   ;;POP STACK INTO R5
7945 012022 012603          MOV      (SP)+,R3   ;;POP STACK INTO R3
7946 012024 012602          MOV      (SP)+,R2   ;;POP STACK INTO R2
7947 012026 012601          MOV      (SP)+,R1   ;;POP STACK INTO R1
7948 012030 012600          MOV      (SP)+,R0   ;;POP STACK INTO R0
7949 012032 104401 012060          TYPE     ,#DBLK     ;;NOW TYPE THE NUMBER
7950 012036 016666 000002 000004  MOV      2(SP),4(SP) ;;ADJUST THE STACK
7951 012044 012616          MOV      (SP)+,(SP)
7952 012046 000002          RTI                          ;;RETURN TO USER
7953 012050 023420          $DTBL: 10000.
7954 012052 001750          1000.
7955 012054 000144          100.
7956 012056 000012          10.
7957 012060 000004          $DBLK: .BLKW 4
7958                                .SBTTL  ERROR HANDLER ROUTINE
7959
7960                                ;;*****
7961                                ;*THIS ROUTINE WILL INCREMENT THE ERROR FLAG AND THE ERROR COUNT,
7962                                ;*SAVE THE ERROR ITEM NUMBER AND THE ADDRESS OF THE ERROR CALL
7963                                ;*AND GO TO SWRCK ON ERROR
7964                                ;*THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
7965                                ;*SW15=1      HALT ON ERROR
7966                                ;*SW13=1      INHIBIT ERROR TYPEOUTS
7967                                ;*SW10=1      BELL ON ERROR
7968                                ;*SW09=1      LOOP ON ERROR
7969                                ;*CALL
7970                                ;*      ERROR  N      ;;ERROR=EMT AND N=ERROR ITEM NUMBER
7971
7972                                $ERROR:
7973 012070 104407          CKSWR                                ;;TEST FOR CHANGE IN SOFT-SWR
7974 012072 104407          CKSWR                                ;GO LOOK FOR SWR CHANGE
7975 012074 105237 001103          7$:  INCB     $ERFLG   ;;SET THE ERROR FLAG
7976 012100 001775          BEQ      7$          ;;DON'T LET THE FLAG GO TO ZERO
7977 012102 013777 001102 167032  MOV      $TSTNM,$DISPLAY ;;DISPLAY TEST NUMBER AND ERROR FLAG
7978 012110 032777 002000 167022  BIT      @BIT10,@SWR   ;;BELL ON ERROR?
7979 012116 001402          BEQ      1$          ;;NO - SKIP
7980 012120 104401 001164          TYPE     ,#BELL     ;;RING BELL
7981 012124 005237 001112          1$:  INC      $ERTTL   ;;COUNT THE NUMBER OF ERRORS
7982 012130 011637 001116          MOV      (SP),$ERRPC ;;GET ADDRESS OF ERROR INSTRUCTION
7983 012134 162737 000002 001116  SUB      @2,$ERRPC
7984 012142 117737 166750 001114  MOVB    @ERRPC,$ITEMB ;;STRIP AND SAVE THE ERROR ITEM CODE
7985 012150 032777 020000 166762  BIT      @BIT13,@SWR  ;;SKIP TYPEOUT IF SET
7986 012156 001004          BNE      20$        ;;SKIP TYPEOUTS
7987 012160 004737 012260          JSR      PC,SWRCK   ;;GO TO USER, ERROR ROUTINE
7988 012164 104401 001171          TYPE     ,#CRLF
7989 012170
7990 012170 122737 000001 001214          20$:  CHPB    @APTENV,$ENV ;;RUNNING IN APT MODE
7991 012176 001007          BNE      2$          ;;NO,SKIP APT ERROR REPORT
  
```





```

8048 012366 000000
8049 012370 104401 001171
8050 012374 011000
8051 012376 001004
8052 012400 012600
8053 012402 104401 001171
8054 012406 000207
8055 012410
8056 012410 013046
8057 012412 104402
8058 012414 005710
8059 012416 001770
8060 012420 104401 012426
8061 012424 000771
8062 012426 020040 000
8063 012432
8064
8065
8066
8067
8068
8069
8070
8071
8072
8073
8074
8075
8076
8077
8078 012432
8079 012432 104407
8080 012434 104407
8081 012436 032777 040000 166474
8082 012444 001117
8083
8084 012446 000416
8085
8086 012450 013746 000004
8087 012454 012737 012474 000004
8088 012462 005737 177060
8089 012466 012637 000004
8090 012472 000466
8091 012474 022626
8092 012476 012637 000004
8093 012502 000426
8094 012504
8095 012504 032777 000400 166426
8096 012512 001407
8097 012514 017746 166420
8098 012520 042716 000300
8099 012524 122637 001102
8100 012530 001465
8101 012532 105737 001103
8102 012536 001421
8103 012540 123737 001115 001103

4$: .WORD 0 ;; "DATA HEADER" POINTER GOES HERE
    TYPE , $CRLF ;; "CARRIAGE RETURN" & "LINE FEED"
5$: MOV (RO),RO ;; PICKUP "DATA TABLE" POINTER
    BNE 7$ ;; GO TYPE THE DATA
6$: MOV (SP)+,RO ;; RESTORE RO
    TYPE , $CRLF ;; "CARRIAGE RETURN" & "LINE FEED"
    RTS PC ;; RETURN
7$: MOV @ (RO)+, -(SP) ;; SAVE @ (RO)+ FOR TYPEOUT
    TYPOC ;; GO TYPE--OCTAL ASCII(ALL DIGITS)
    TST (RO) ;; IS THERE ANOTHER NUMBER?
    BEQ 6$ ;; BR IF NO
    TYPE , 8$ ;; TYPE TWO(2) SPACES
    BR 7$ ;; LOOP
8$: .ASCIZ / / ;; TWO(2) SPACES
    .EVEN
.SBTTL SCOPE HANDLER ROUTINE

;*****
;*THIS ROUTINE CONTROLS THE LOOPING OF SUBTESTS. IT WILL INCREMENT
;*AND LOAD THE TEST NUMBER($TSTNM) INTO THE DISPLAY REG.(DISPLAY<7:0>)
;*AND LOAD THE ERROR FLAG ($ERFLG) INTO DISPLAY<15:08>
;*THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
;*$SW14=1 LOOP ON TEST
;*$SW11=1 INHIBIT ITERATIONS
;*$SW09=1 LOOP ON ERROR
;*$SW08=1 LOOP ON TEST IN SWR<5:0>
;*$CALL
;*$ SCOPE ;;SCOPE=IOT

$SCOPE:
    CKSWR
    CKSWR
1$: BIT @BIT14,@SWR ;;TEST FOR CHANGE IN SOFT-SWR
    BNE $OVER ;;GO LOOK FOR SWR CHANGE
    ;;LOOP ON PRESENT TEST?
    ;;YES IF SW14=1
;*****START OF CODE FOR THE XOR TESTER*****
$XTSTR: BR 6$ ;;IF RUNNING ON THE "XOR" TESTER CHANGE
    MOV @ERRVEC, -(SP) ;;THIS INSTRUCTION TO A "NOP" (NOP=240)
    MOV #5,@ERRVEC ;;SAVE THE CONTENTS OF THE ERROR VECTOR
    TST @177060 ;;SET FOR TIMEOUT
    MOV (SP)+,@ERRVEC ;;TIME OUT ON XOR?
    BR $SVLAD ;;RESTORE THE ERROR VECTOR
    ;;GO TO THE NEXT TEST
5$: CMP (SP)+,(SP)+ ;;CLEAR THE STACK AFTER A TIME OUT
    MOV (SP)+,@ERRVEC ;;RESTORE THE ERROR VECTOR
    BR 7$ ;;LOOP ON THE PRESENT TEST
6$: *****END OF CODE FOR THE XOR TESTER*****
    BIT @BIT08,@SWR ;;LOOP ON SPEC. TEST?
    BEQ 2$ ;;BR IF NO
    MOV @SWR, -(SP) ;;SET DESIRED TEST NUM. FROM SWR
    BIC @SWRMK,(SP) ;;STRIP AWAY UNDESIRED BITS
    CMPB (SP)+,$TSTNM ;;ON THE RIGHT TEST?
    BEQ $OVER ;;BR IF YES
2$: TSTB $ERFLG ;;HAS AN ERROR OCCURRED?
    BEQ 3$ ;;BR IF NO
    CMPB $ERMAX,$ERFLG ;;MAX. ERRORS FOR THIS TEST OCCURRED?
    
```

```

8104 012546 101015          BHI      3$          ;;BR IF NO
8105 012550 032777 001000 166362 BIT      @BIT09,@SWR ;;LOOP ON ERROR?
8106 012556 001404          BEQ      4$          ;;BR IF NO
8107 012560 013737 001110 001106 7$:  MOV     $LPERR,$LPADR ;;SET LOOP ADDRESS TO LAST SCOPE
8108 012566 000446          BR       $OVER
8109 012570 105037 001103          4$:  CLRB   $ERFLG      ;;ZERO THE ERROR FLAG
8110 012574 005037 001160          CLR     $TIMES     ;;CLEAR THE NUMBER OF ITERATIONS TO MAKE
8111 012600 000415          BR       1$          ;;ESCAPE TO THE NEXT TEST
8112 012602 032777 004000 166330 3$:  BIT     @BIT11,@SWR ;;INHIBIT ITERATIONS?
8113 012610 001011          BNE     1$          ;;BR IF YES
8114 012612 005737 001202          TST     $PASS     ;;IF FIRST PASS OF PROGRAM
8115 012616 001406          BEQ     1$          ;;      INHIBIT ITERATIONS
8116 012620 005237 001104          INC     $ICNT     ;;INCREMENT ITERATION COUNT
8117 012624 023737 001160 001104 CMP     $TIMES,$ICNT ;;CHECK THE NUMBER OF ITERATIONS MADE
8118 012632 002024          BGE     $OVER     ;;BR IF MORE ITERATION REQUIRED
8119 012634 012737 0000 1 001104 1$:  MOV     @1,$ICNT  ;;REINITIALIZE THE ITERATION COUNTER
8120 012642 013737 012720 001160 MOV     $MXCNT,$TIMES ;;SET NUMBER OF ITERATIONS TO DO
8121 012650 105237 001102          $SVLAD: INCB   $TSTNM ;;COUNT TEST NUMBERS
8122 012654 113737 001102 001200 MOVB   $TSTNM,$TESTN ;;SET TEST NUMBER IN APT MAILBOX
8123 012662 011637 001106          MOV     (SP),$LPADR ;;SAVE SCOPE LOOP ADDRESS
8124 012666 011637 001110          MOV     (SP),$LPERR ;;SAVE ERROR LOOP ADDRESS
8125 012672 005037 001162          CLR     $ESCAPE  ;;CLEAR THE ESCAPE FROM ERROR ADDRESS
8126 012676 112737 000001 001115 MOVB   @1,$ERMAX  ;;ONLY ALLOW ONE(1) ERROR ON NEXT TEST
8127 012704 013777 001102 166230 $OVER: MOV     $TSTNM,@DISPLAY ;;DISPLAY TEST NUMBER
8128 012712 013716 001106          MOV     $LPADR,(SP) ;;FUDGE RETURN ADDRESS
8129 012716 000002          RTI
8130 012720 003720          $MXCNT: 2000.    ;;FIXES PS
8131          .SBTTL TTY INPUT ROUTINE      ;;MAX. NUMBER OF ITERATIONS
8132
8133          ;;*****
8134          .ENABL  LSB
8135
8136          ;;*****
8137          ;*SOFTWARE SWITCH REGISTER CHANGE ROUTINE.
8138          ;*ROUTINE IS ENTERED FROM THE TRAP HANDLER, AND WILL
8139          ;*SERVICE THE TEST FOR CHANGE IN SOFTWARE SWITCH REGISTER TRAP CALL
8140          ;*WHEN OPERATING IN TTY FLAG MODE.
8141 012722 022737 000176 001140 $CKSWR: CMP     @SWREG,SWR ;;IS THE SOFT-SWR SELECTED?
8142 012730 001074          BNE     15$        ;;BRANCH IF NO
8143 012732 105777 166206          TSTB   @TKS       ;;CHAR THERE?
8144 012736 100071          BPL     15$        ;;IF NO, DON'T WAIT AROUND
8145 012740 117746 166202          MOVB   @TKB,-(SP) ;;SAVE THE CHAR
8146 012744 042716 177600          BIC     @C177,(SP) ;;STRIP-OFF THE ASCII
8147 012750 022726 000007          CMP     @7,(SP)+  ;;IS IT A CONTROL G?
8148 012754 001062          BNE     15$        ;;NO, RETURN TO USER
8149 012756 123727 001134 000001 CMPB   $AUTOB,@1   ;;ARE WE RUNNING IN AUTO-MODE?
8150 012764 001456          BEQ     15$        ;;BRANCH IF YES
8151
8152 012766 104401 013457          TYPE   , $CNTLG  ;;ECHO THE CONTROL-G (+G)
8153 012772 104401 013464          $GTSWR: TYPE   , $MSWR  ;;TYPE CURRENT CONTENTS
8154 012776 013746 000176          MOV     SWREG,-(SP) ;;SAVE SWREG FOR TYPEOUT
8155 013002 104402          TYPOC          ;;GO TYPE--OCTAL ASCII(ALL DIGITS)
8156 013004 104401 013475          TYPE   , $MNEW  ;;PROMPT FOR NEW SWR
8157 013010 005046          19$:  CLR     -(SP)    ;;CLEAR COUNTER
8158 013012 005046          CLR     -(SP)    ;;THE NEW SWR
8159 013014 105777 166124          7$:  TSTB   @TKS     ;;CHAR THERE?
    
```



```

8160 013020 100375          BPL      7$           ;;IF NOT TRY AGAIN
8161
8162 013022 117746 166120    MOVB    8$TKB,-(SP)      ;;PICK UP CHAR
8163 013026 042716 177600    BIC     0+C177,(SP)     ;;MAKE IT 7-BIT ASCII
8164
8165
8166
8167 013032 021627 000025    9$:    CMP     (SP),#25      ;;IS IT A CONTROL-U?
8168 013036 001005          BNE     10$           ;;BRANCH IF NOT
8169 013040 104401 013452    TYPE   ,#CNTLU         ;;YES, ECHO CONTROL-U (+U)
8170 013044 062706 000006    20$:   ADD     #6,SP        ;;IGNORE PREVIOUS INPUT
8171 013050 000757          BR      19$           ;;LET'S TRY IT AGAIN
8172
8173
8174 013052 021627 000015    10$:   CMP     (SP),#15     ;;IS IT A <CR>?
8175 013056 001022          BNE     16$           ;;BRANCH IF NO
8176 013060 005766 000004    TST    4(SP)           ;;YES, IS IT THE FIRST CHAR?
8177 013064 001403          BEQ    11$           ;;BRANCH IF YES
8178 013066 016677 000002 166044    MOV    2(SP),#SWR      ;;SAVE NEW SWR
8179 013074 062706 000006    11$:   ADD     #6,SP        ;;CLEAR UP STACK
8180 013100 104401 001171    14$:   TYPE   ,#CRLF        ;;ECHO <CR> AND <LF>
8181 013104 123727 001135 000001    CMPB   $INTAG,#1      ;;RE-ENABLE TTY KBD INTERRUPTS?
8182 013112 001003          BNE     15$           ;;BRANCH IF NOT
8183 013114 012777 000100 166022    MOV    #100,#TKS      ;;RE-ENABLE TTY KBD INTERRUPTS
8184 013122 000002          RTI                    ;;RETURN
8185 013124 004737 011026    16$:   JSR    PC,$TYPEPC     ;;ECHO CHAR
8186 013130 021627 000060    CMP    (SP),#60       ;;CHAR < 0?
8187 013134 002420          BLT    18$           ;;BRANCH IF YES
8188 013136 021627 000067    CMP    (SP),#67       ;;CHAR > 7?
8189 013142 003015          BGT    18$           ;;BRANCH IF YES
8190 013144 042726 000060    BIC    #60,(SP)+      ;;STRIP-OFF ASCII
8191 013150 005766 000002    TST    2(SP)          ;;IS THIS THE FIRST CHAR
8192 013154 001403          BEQ    17$           ;;BRANCH IF YES
8193 013156 006316          ASL    (SP)           ;;NO, SHIFT PRESENT
8194 013160 006316          ASL    (SP)           ;; CHAR OVER TO MAKE
8195 013162 006316          ASL    (SP)           ;; ROOM FOR NEW ONE.
8196 013164 005266 000002    17$:   INC    2(SP)          ;;KEEP COUNT OF CHAR
8197 013170 056616 177776    BIS    -2(SP),(SP)    ;;SET IN NEW CHAR
8198 013174 000707          BR     7$           ;;GET THE NEXT ONE
8199 013176 104401 001170    18$:   TYPE   ,#QUES        ;;TYPE ?<CR><LF>
8200 013202 000720          BR     20$           ;;SIMULATE CONTROL-U
8201          .DSABL  LSB
8202
8203
8204          ;;*****
8205          ;;THIS ROUTINE WILL INPUT A SINGLE CHARACTER FROM THE TTY
8206          ;;CALL:
8207          ;; RDCHR          ;;INPUT A SINGLE CHARACTER FROM THE TTY
8208          ;; RETURN HERE   ;;CHARACTER IS ON THE STACK
8209          ;;              ;;WITH PARITY BIT STRIPPED OFF
8210          ;
8211
8212 013204 011646          $RDCHR: MOV    (SP),-(SP)      ;;PUSH DOWN THE PC
8213 013206 016666 000004 000002    MOV    4(SP),2(SP)    ;;SAVE THE PS
8214 013214 105777 165724    1$:    TSTB   8$TKS         ;;WAIT FOR
8215 013220 100375          BPL    1$           ;;A CHARACTER
    
```

```

8216 013222 117766 165720 000004      MOVB      0#TKB,4(SP)      ;;READ THE TTY
8217 013230 042766 177600 000004      BIC      0+C<177>,4(SP)  ;;GET RID OF JUNK IF ANY
8218 013236 026627 000004 000023      CMP      4(SP),023      ;;IS IT A CONTROL-S?
8219 013244 001013                BNE      3#              ;;BRANCH IF NO
8220 013246 105777 165672          2#:      TSTB      0#TKS          ;;WAIT FOR A CHARACTER
8221 013252 100375                BPL      2#              ;;LOOP UNTIL ITS THERE
8222 013254 117746 165666      MOVB      0#TKB,-(SP)    ;;GET CHARACTER
8223 013260 042716 177600      BIC      0+C177,(SP)    ;;MAKE IT 7-BIT ASCII
8224 013264 022627 000021      CMP      (SP)-,021      ;;IS IT A CONTROL-Q?
8225 013270 001366                BNE      2#              ;;IF NOT DISCARD IT
8226 013272 000750                BR       1#              ;;YES, RESUME
8227 013274 026627 000004 000021  3#:      CMP      4(SP),0#XON    ;;IS IT A RANDOM XON?      ;RAN001
8228 013302 001744                BEQ      1#              ;;BRANCH IF YES          ;RAN001
8229 013304 026627 000004 000140      CMP      4(SP),0140     ;;IS IT UPPER CASE?
8230 013312 002407                BLT      4#              ;;BRANCH IF YES
8231 013314 026627 000004 000175      CMP      4(SP),0175     ;;IS IT A SPECIAL CHAR?
8232 013322 003003                BGT      4#              ;;BRANCH IF YES
8233 013324 042766 000040 000004      BIC      040,4(SP)      ;;MAKE IT UPPER CASE
8234 013332 000002          4#:      RTI              ;;GO BACK TO USER
8235                                     ;;*****
8236                                     ;*THIS ROUTINE WILL INPUT A STRING FROM THE TTY
8237                                     ;*CALL:
8238                                     ;*      RDLIN              ;;INPUT A STRING FROM THE TTY
8239                                     ;*      RETURN HERE      ;;ADDRESS OF FIRST CHARACTER WILL BE ON THE STACK
8240                                     ;*                                     ;;TERMINATOR WILL BE A BYTE OF ALL 0'S
8241
8242 013334 010346          $RDLIN: MOV      R3,-(SP)      ;;SAVE R3
8243 013336 012703 013442      1#:      MOV      0#TTYIN,R3    ;;GET ADDRESS
8244 013342 022703 013452      2#:      CMP      0#TTYIN+8.,R3  ;;BUFFER FULL?
8245 013346 101405                BLOS     4#              ;;BR IF YES
8246 013350 104410                RDCHR                    ;;GO READ ONE CHARACTER FROM THE TTY
8247 013352 112613                MOVB     (SP)+,(R3)      ;;GET CHARACTER
8248 013354 122713 000177      10#:     CMPB     0177,(R3)      ;;IS IT A RUBOUT
8249 013360 001003                BNE      3#              ;;SKIP IF NOT
8250 013362 104401 001170      4#:      TYPE     ,#QUES        ;;TYPE A '?'
8251 013366 000763                BR       1#              ;;CLEAR THE BUFFER AND LOOP
8252 013370 111337 013440      3#:      MOVB     (R3),9#        ;;ECHO THE CHARACTER
8253 013374 104401 013440                TYPE     ,9#
8254 013400 122723 000015                CMPB     015,(R3)+      ;;CHECK FOR RETURN
8255 013404 001356                BNE      2#              ;;LOOP IF NOT RETURN
8256 013406 105063 177777                CLRB     -1(R3)         ;;CLEAR RETURN (THE 15)
8257 013412 104401 001172                TYPE     ,#LF          ;;TYPE A LINE FEED
8258 013416 012603                MOV      (SP)+,R3      ;;RESTORE R3
8259 013420 011646                MOV      (SP)-,(SP)    ;;ADJUST THE STACK AND PUT ADDRESS OF THE
8260 013422 016666 000004 000002      MOV      4(SP),2(SP)   ;;FIRST ASCII CHARACTER ON IT
8261 013430 012766 013442 000004      MOV      0#TTYIN,4(SP)
8262 013436 000002                RTI
8263 013440 000          9#:      .BYTE    0              ;;RETURN
8264 013441 000                .BYTE    0              ;;STORAGE FOR ASCII CHAR. TO TYPE
8265 013442 000010          $TTYIN: .BLKB    8.      ;;TERMINATOR
8266 013452 052536 005015 000      $CNTLU: .ASCIZ  /+U/<15><12>  ;;RESERVE 8 BYTES FOR TTY INPUT
8267 013457 136 006507 000012      $CNTLG: .ASCIZ  /+G/<15><12>  ;;CONTROL "U"
8268 013464 005015 053523 020122      $MSWR:  .ASCIZ  <15><12>/SWR = /  ;;CONTROL "G"
8269 013472 020075 000
8270 013475 040 047040 053505      $MNEW:  .ASCIZ  / NEW = /
    
```



013502 036440 000040

```

8271
8272      .SBTTL  READ AN OCTAL NUMBER FROM THE TTY
8273
8274      ;;*****
8275      ;*THIS ROUTINE WILL READ AN OCTAL (ASCII) NUMBER FROM THE TTY AND
8276      ;*CHANGE IT TO BINARY.
8277      ;*THE INPUT CHARACTERS WILL BE CHECKED TO INSURED THEY ARE LEGAL
8278      ;*OCTAL DIGITS. IF AN ILLEGAL CHARACTER IS READ A "?" WILL BE TYPED
8279      ;*FOLLOWED BY A CARRIAGE RETURN-LINE FEED. THE COMPLETE NUMBER MUST
8280      ;*THEN BE RETYPED. THE INPUT IS TERMINATED BY TYPING A CARRIAGE RETURN.
8281      ;*CALL:
8282      ;*      RDOCT          ;;READ AN OCTAL NUMBER
8283      ;*      RETURN HERE   ;;LOW ORDER BITS ARE ON TOP OF THE STACK
8284      ;*                   ;;HIGH ORDER BITS ARE IN $HIOCT
8285
8286      013506 011646          $RDOCT: MOV      (SP),-(SP)      ;;PROVIDE SPACE FOR THE
8287      013510 016666 000004 000002  MOV      4(SP),2(SP)      ;;INPUT NUMBER
8288      013516 010046          MOV      RO,-(SP)        ;;PUSH RO ON STACK
8289      013520 010146          MOV      R1,-(SP)        ;;PUSH R1 ON STACK
8290      013522 010246          MOV      R2,-(SP)        ;;PUSH R2 ON STACK
8291      013524 104411          1$:  RDLIN          ;;READ AN ASCII LINE
8292      013526 012600          MOV      (SP)+,RO      ;;GET ADDRESS OF 1ST CHARACTER
8293      013530 010037 013634  MOV      RO,5$      ;;AND SAVE IT
8294      013534 005001          CLR      R1          ;;CLEAR DATA WORD
8295      013536 005002          CLR      R2
8296      013540 112046          2$:  MOVB      (RO)+,-(SP)      ;;PICKUP THIS CHARACTER
8297      013542 001420          BEQ      3$          ;;IF ZERO GET OUT
8298      013544 122716 000060  CMPB      #'0,(SP)      ;;MAKE SURE THIS CHARACTER
8299      013550 003026          BGT      4$          ;;IS AN OCTAL DIGIT
8300      013552 122716 000067  CMPB      #'7,(SP)
8301      013556 002423          BLT      4$
8302      013560 006301          ASL      R1          ;;*2
8303      013562 006102          ROL      R2
8304      013564 006301          ASL      R1          ;;*4
8305      013566 006102          ROL      R2
8306      013570 006301          ASL      R1          ;;*8
8307      013572 006102          ROL      R2
8308      013574 042716 177770  BIC      #'C7,(SP)      ;;STRIP THE ASCII JUNK
8309      013600 062601          ADD      (SP)+,R1      ;;ADD IN THIS DIGIT
8310      013602 000756          BR       2$          ;;LOOP
8311      013604 005726          3$:  TST      (SP)+      ;;CLEAN TERMINATOR FROM STACK
8312      013606 010166 000012  MOV      R1,12(SP)      ;;SAVE THE RESULT
8313      013612 010237 013644  MOV      R2,$HIOCT
8314      013616 012602          MOV      (SP)+,R2      ;;POP STACK INTO R2
8315      013620 012601          MOV      (SP)+,R1      ;;POP STACK INTO R1
8316      013622 012600          MOV      (SP)+,RO      ;;POP STACK INTO RO
8317      013624 000002          RTI          ;;RETURN
8318      013626 005726          4$:  TST      (SP)+      ;;CLEAN PARTIAL FROM STACK
8319      013630 105010          CLRB     (RO)         ;;SET A TERMINATOR
8320      013632 104401          TYPE          ;;TYPE UP THRU THE BAD CHAR.
8321      013634 000000          5$:  .WORD     0
8322      013636 104401 001170  TYPE     ,#QUES      ;; "?" "CR" & "LF"
8323      013642 000730          BR       1$          ;;TRY AGAIN
8324      013644 000000          $HIOCT: .WORD     0  ;;HIGH ORDER BITS GO HERE
8325      .SBTTL  POWER DOWN AND UP ROUTINES
    
```

```

8326
8327
8328      ;*****
8329      ;POWER DOWN ROUTINE
8329      013646 012737 014012 000024 $PWRDN: MOV    @ILLUP,@PWRVEC ;;SET FOR FAST UP
8330      013654 012737 000340 000026      MOV    @340,@PWRVEC+2 ;;PRIO:7
8331      013662 010046      MOV    R0,-(SP)    ;;PUSH R0 ON STACK
8332      013664 010146      MOV    R1,-(SP)    ;;PUSH R1 ON STACK
8333      013666 010246      MOV    R2,-(SP)    ;;PUSH R2 ON STACK
8334      013670 010346      MOV    R3,-(SP)    ;;PUSH R3 ON STACK
8335      013672 010446      MOV    R4,-(SP)    ;;PUSH R4 ON STACK
8336      013674 010546      MOV    R5,-(SP)    ;;PUSH R5 ON STACK
8337      013676 017746 165236      MOV    @SWR,-(SP)  ;;PUSH @SWR ON STACK
8338      013702 010637 014016      MOV    SP,$SAVR6  ;;SAVE SP
8339      013706 012737 013720 000024      MOV    @PWRUP,@PWRVEC ;;SET UP VECTOR
8340      013714 000000      HALT
8341      013716 000776      BR     .-2        ;;HANG UP
8342
8343      ;*****
8344      ;POWER UP ROUTINE
8345      C13720 012737 014012 000024 $PWRUP: MOV    @ILLUP,@PWRVEC ;;SET FOR FAST DOWN
8346      013726 013706 014016      MOV    $SAVR6.SP  ;;GET SP
8347      013732 005037 014016      CLR    $SAVR6    ;;WAIT LOOP FOR THE TTY
8348      013736 005237 014016      1$:   INC    $SAVR6    ;;WAIT FOR THE INC
8349      013742 001375      BNE    1$        ;;OF WORD
8350      013744 012677 165170      MOV    (SP)+,@SWR ;;POP STACK INTO @SWR
8351      013750 012605      MOV    (SP)+,R5  ;;POP STACK INTO R5
8352      013752 012604      MOV    (SP)+,R4  ;;POP STACK INTO R4
8353      013754 012603      MOV    (SP)+,R3  ;;POP STACK INTO R3
8354      013756 012602      MOV    (SP)+,R2  ;;POP STACK INTO R2
8355      013760 012601      MOV    (SP)+,R1  ;;POP STACK INTO R1
8356      013762 012600      MOV    (SP)+,R0  ;;POP STACK INTO R0
8357      013764 012737 013646 000024      MOV    @PWRDN,@PWRVEC ;;SET UP THE POWER DOWN VECTOR
8358      013772 012737 000340 000026      MOV    @340,@PWRVEC+2 ;;PRIO:7
8359      014000 104401      TYPE    ;;REPORT THE POWER FAILURE
8360      014002 014020      $PWRMG: .WORD PWRMSG ;;POWER FAIL MESSAGE POINTER
8361      014004 012716      MOV    (PC)+,(SP) ;;RESTART AT RESTR
8362      014006 002372      $PWRAD: .WORD RESTR  ;;RESTART ADDRESS
8363      014010 000002      RTI
8364      014012 000000      $ILLUP: HALT    ;;THE POWER UP SEQUENCE WAS STARTED
8365      014014 000776      BR     .-2        ;; BEFORE THE POWER DOWN WAS COMPLETE
8366      014016 000000      $SAVR6: 0        ;;PUT THE SP HERE
8367      014020 005015 042522 052123 PWRMSG: .ASCIZ <15><12>/RESTARTED FROM PWR FAIL/
8368      014026 051101 042524 020104
8369      014034 051106 046517 050040
8370      014042 051127 043040 044501
8371      014050 000114
8372
8373      .EVEN
8374      .SBTTL TRAP DECODER
8375
8376      ;*****
8377      ;*THIS ROUTINE WILL PICKUP THE LOWER BYTE OF THE "TRAP" INSTRUCTION
      ;*AND USE IT TO INDEX THROUGH THE TRAP TABLE FOR THE STARTING ADDRESS
    
```



```

8378 ;*OF THE DESIRED ROUTINE. THEN USING THE ADDRESS OBTAINED IT WILL
8379 ;*GO TO THAT ROUTINE.
8380
8381 014052 010046 ;*TRAP: MOV RO,-(SP) ;:SAVE RO
8382 014054 016600 000002 MOV 2(SP),RO ;:GET TRAP ADDRESS
8383 014060 005740 TST -(RO) ;:BACKUP BY 2
8384 014062 111000 MOVB (RO),RO ;:GET RIGHT BYTE OF TRAP
8385 014064 006300 ASL RO ;:POSITION FOR INDEXING
8386 014066 016000 014106 MOV #TRPAD(RO),RO ;:INDEX TO TABLE
8387 014072 000200 RTS RO ;:GO TO ROUTINE
8388
8389
8390 ;:THIS IS USE TO HANDLE THE "GETPRI" MACRO
8391
8392 014074 011646 ;*TRAP2: MOV (SP),-(SP) ;:MOVE THE PC DOWN
8393 014076 016666 000004 000002 MOV 4(SP),2(SP) ;:MOVE THE PSW DOWN
8394 014104 000002 RTI ;:RESTORE THE PSW
8395
8396 .SBTTL TRAP TABLE
8397
8398 ;*THIS TABLE CONTAINS THE STARTING ADDRESSES OF THE ROUTINES CALLED
8399 ;*BY THE "TRAP" INSTRUCTION.
8400
8401 ; ROUTINE
8402 ; -----
8403 014106 014074 ;*TRPAD: .WORD #TRAP2
8404 014110 010614 ;:TYPE ;:CALL=TYPE TRAP+1(104401) TTY TYPEOUT ROUTINE
8405 014112 011442 ;:TYPOC ;:CALL=TYPOC TRAP+2(104402) TYPE OCTAL NUMBER (WITH LEADING ZEROS)
8406 014114 011416 ;:TYPOS ;:CALL=TYPOS TRAP+3(104403) TYPE OCTAL NUMBER (NO LEADING ZEROS)
8407 014116 011456 ;:TYPON ;:CALL=TYPON TRAP+4(104404) TYPE OCTAL NUMBER (AS PER LAST CALL)
8408 014120 011644 ;:TYPDS ;:CALL=TYPDS TRAP+5(104405) TYPE DECIMAL NUMBER (WITH SIGN)
8409
8410 014122 012772 ;:GTSWR ;:CALL=GTSWR TRAP+6(104406) GET SOFT-SWR SETTING
8411
8412 014124 012722 ;:CKSWR ;:CALL=CKSWR TRAP+7(104407) TEST FOR CHANGE IN SOFT-SWR
8413 014126 013204 ;:RDCHR ;:CALL=RDCHR TRAP+10(104410) TTY TYPEIN CHARACTER ROUTINE
8414 014130 013334 ;:RDLIN ;:CALL=RDLIN TRAP+11(104411) TTY TYPEIN STRING ROUTINE
8415 014132 013506 ;:RDOCT ;:CALL=RDOCT TRAP+12(104412) READ AN OCTAL NUMBER FROM TTY
8416
8417 .SBTTL ASCII MESSAGES
8418 014134 042522 020107 044524 EM1: .ASCIZ /REG TIMEOUT ER/
8419 014142 042515 052517 020124
8420 014150 051105 000
8421
8422
8423
8424
8425 014153 122 043505 051040 EM2: .ASCIZ 'REG READ/WRITE ER'
8426 014160 040505 027504 051127
8427 014166 052111 020105 051105
8428 014174 000
8429
8430
8431
8432
8433
8434
8435 014175 102 051525 051040 EM3: .ASCIZ /BUS RESET ER/
8436 014202 051505 052105 042440
8437 014210 000122
8438
8439
8440
8441
8442
8443
8444
8445
8446
8447
8448
8449
8450
8451
8452
8453
8454
8455
8456
8457
8458
8459
8460
8461
8462
8463
8464
8465
8466
8467
8468
8469
8470
8471
8472
8473
8474
8475
8476
8477
8478
8479
8480
8481
8482
8483
8484
8485
8486
8487
8488
8489
8490
8491
8492
8493
8494
8495
8496
8497
8498
8499
8500

```

INTERFACE DIAGNOSTIC  
ASCII MESSAGES

8427					
8428	014212	047106	052103	041040	EM4: .ASCIZ /FNCT BITS FAILED TO SET STAT BITS/
	014220	052111	020123	040506	
	014226	046111	042105	052040	
	014234	020117	042523	020124	
	014242	052123	052101	041040	
	014250	052111	000123		
8429					
8430					
8431					
8432					
8433					
8434	014254	042522	042101	020131	EM5: .ASCIZ /READY INTR FAILURE/
	014262	047111	051124	043040	
	014270	044501	052514	042522	
	014276	000			
8435					
8436					
8437					
8438	014277	122	040505	054504	EM6: .ASCIZ /READY CLR OR SET ER/
	014304	041440	051114	047440	
	014312	020122	042523	020124	
	014320	051105	000		
8439					
8440					
8441					
8442	014323	123	040524	052524	EM7: .ASCIZ /STATUS ER ON XFER/
	014330	020123	051105	047440	
	014336	020116	043130	051105	
	014344	000			
8443					
8444					
8445					
8446	014345	127	051117	020104	EM10: .ASCIZ /WORD COUNT ER ON XFER/
	014352	047503	047125	020124	
	014360	051105	047440	020116	
	014366	043130	051105	000	
8447					
8448					
8449					
8450	014373	102	043125	042506	EM11: .ASCIZ /BUFFER ADRS ER ON XFER/
	014400	020122	042101	051522	
	014406	042440	020122	047117	
	014414	054040	042506	000122	
8451					
8452					
8453					
8454	014422	040504	040524	042440	EM12: .ASCIZ /DATA ER FROM MEM/
	014430	020122	051106	046517	
	014436	046440	046505	000	
8455					
8456					
8457	014443	104	052101	020101	EM13: .ASCIZ /DATA ER TO MEM/
	014450	051105	052040	020117	
	014456	042515	000115		
8458					



8459

8460 014462 044523 043516 042514 EM14: .ASCIZ /SINGLE CYCLE OFF DID NOT LOCK OUT CPU/  
014470 041440 041531 042514  
014476 047440 043106 042040  
014504 042111 047040 052117  
014512 046040 041517 020113  
014520 052517 020124 050103  
014526 000125

8461

8462

8463

8464

8465

8466

8467 014530 044523 043516 042514 EM15: .ASCIZ /SINGLE CYCLE ON LOCKED OUT CPU/  
014536 041440 041531 042514  
014544 047440 020116 047514  
014552 045503 042105 047440  
014560 052125 041440 052520  
014566 000

8468

8469

8470

8471

8472

8473 014567 015 050012 042514 WARN: .ASCII <15><12>/PLEASE DISABLE "REV11" MEMORY REFRESH OPTION/  
014574 051501 020105 044504  
014602 040523 046102 020105  
014610 051042 053105 030461  
014616 020042 042515 047515  
014624 054522 051040 043105  
014632 042522 044123 047440  
014640 052120 047511 116

8474

8475

8476

8477

8478

8479

8480

8481 014645 015 040412 042116 .ASCIZ <15><12>/AND ENABLE PROCESSOR MEMORY REFRESH /  
014652 042440 040516 046102  
014660 020105 051120 041517  
014666 051505 047523 020122  
014674 042515 047515 054522  
014702 051040 043105 042522  
014710 044123 020040 000040

8482

8483

8484

8485

8486

8487

8488 014716 042516 020130 047514 EM16: .ASCIZ /NEX LOGIC ER/  
014724 044507 020103 051105  
014732 000

8489

8490

8491 014733 103 041531 042514 EM17: .ASCIZ /CYCLE FAILED TO CLK DBR (IN)/  
014740 043040 044501 042514  
014746 020104 047524 041440  
014754 045514 042040 051102  
014762 024040 047111 000051

8492

8493

8494

8495

8496 014770 040504 040524 042440 EM20: .ASCIZ "DATA ER FROM I/O PAGE (XCSR)"  
014776 020122 051106 046517  
015004 044440 047457 050040  
015012 043501 020105 054050  
015020 051503 024522 000

8497

8498

8499

8500

8501 015025 105 051122 041520 DH1: .ASCIZ /ERRPC TSTNUM BUSADR EXPCT RCVD/  
015032 020040 052040 052123  
015040 052516 020115 041040  
015046 051525 042101 020122  
015054 042440 050130 052103  
015062 020040 051040 053103  
015070 000104

8502

8503

8504

8505

8506

8507

8508 015072 051105 050122 020103 DH2: .ASCIZ /ERRPC TSTNUM BUSADR ADRS EXPCT RCVD/  
015100 020040 051524 047124  
015106 046525 020040 052502  
015114 040523 051104 020040  
015122 042101 051522 020040  
015130 020040 054105 041520  
015136 020124 020040 041522  
015144 042126 000

8509

8510

8511

8512

8513

8514

8515

8516 015147 105 051122 041520 DH3: .ASCIZ /ERRPC TSTNUM BUSADR/  
015154 020040 052040 052123  
015162 052516 020115 041040  
015170 051525 042101 000122

8517

8518

8519

8520



```
8521
8522 015176 001116 001534 001122 DT1: .EVEN
      015204 001124 001126 000000 $ERRPC,TSTNUM,$BDADR,$GDDAT,$BDDAT,0
8523
8524 015212 001116 001534 001122 DT2: $ERRPC,TSTNUM,$BDADR,$GDADR,$GDDAT,$BDDAT,0
      015220 001120 001124 001126
      015226 000000
8525
8526
8527 015230 001116 001534 001122 DT3: $ERRPC,TSTNUM,$BDADR,0
      015236 000000
8528
8529 015240 005015 051511 052040 KDF11B: .ASCIZ <15><12>/IS THE PROCESSOR KDF11-B? /
      015246 042510 050040 047522
      015254 042503 051523 051117
      015262 045440 043104 030461
      015270 041055 020077 000040
8530
8531
8532
8533
8534 015276 005015 051124 047101 IOTEST: .ASCIZ <15><12>.TRANSFERS FOR I/O PAGE? .
      015304 043123 051105 020123
      015312 047506 020122 027511
      015320 020117 040520 042507
      015326 020077 000040
8535
8536
8537
8538
8539 015332 005015 042101 051104 IOADR: .ASCIZ <15><12>\ADDRESS OF I/O PAGE? \
      015340 051505 020123 043117
      015346 044440 047457 050040
      015354 043501 037505 020040
      015362 000
8540
8541
8542
8543
8544 015364
8545 .EVEN
8546 ;*****
8547 ;'DBUF' IS THE WORKING AREA IN EACH 4K MEM FOR ALL
8548 ;NPR OPERATIONS - IT IS 200 WORDS LONG
8549 ;*****
8549 015364 000000 DBUF: 0 ;1ST ADRS OF DATA BUFFER
8550 000001 .END
```

ABASE = 172410	6183#	6375				
ACDW1 = 000000	6218#	6377				
ACDW2 = 000000	6219#	6378				
ACPUOP = 000000	6204#	6349				
ADDW0 = 000000	6220#	6379				
ADDW1 = 000000	6221#	6380				
ADDW10 = 000000	6230#	6389				
ADDW11 = 000000	6231#	6390				
ADDW12 = 000000	6232#	6391				
ADDW13 = 000000	6233#	6392				
ADDW14 = 000000	6234#	6393				
ADDW15 = 000000	6235#	6394				
ADDW2 = 000000	6222#	6381				
ADDW3 = 000000	6223#	6382				
ADDW4 = 000000	6224#	6383				
ADDW5 = 000000	6225#	6384				
ADDW6 = 000000	6226#	6385				
ADDW7 = 000000	6227#	6386				
ADDW8 = 000000	6228#	6387				
ADDW9 = 000000	6229#	6388				
ADEVCT = 000000	6196#	6340				
ADEVN = 000001	6186#	6376				
AENV = 000000	6200#	6345				
AENVN = 000000	6201#	6346				
AFATAL = 000000	6193#	6337				
ALTERN = 007436	7365	7406#				
AMADR1 = 000000	6207#	6362				
AMADR2 = 000000	6210#	6366				
AMADR3 = 000000	6213#	6369				
AMADR4 = 000000	6216#	6372				
AMAMS1 = 000000	6205#	6356				
AMAMS2 = 000000	6208#	6364				
AMAMS3 = 000000	6211#	6367				
AMAMS4 = 000000	6214#	6370				
AMSGAD = 000000	6198#	6342				
AMSGLG = 000000	6199#	6343				
AMSGTY = 000000	6192#	6336				
AMTYP1 = 000000	6206#	6357				
AMTYP2 = 000000	6209#	6365				
AMTYP3 = 000000	6212#	6368				
AMTYP4 = 000000	6215#	6371				
APASS = 000000	6195#	6339				
APTCSU = 000040	7692	7813#				
APTENV = 000001	7685	7769	7811#	7990		
APTSIZ = 000200	6569	7810#				
APTSPO = 000100	7687	7771	7812#			
ASWREG = 000000	6202#	6347				
ATESTN = 000000	6194#	6338				
AUNIT = 000000	6197#	6341				
AUSWR = 000000	6203#	6348				
AVECT1 = 000124	6185#	6373				
AVECT2 = 000000	6217#	6374				
BIT0 = 000001	6168#					
BIT00 = 000001	6158#	6168	6698	6703	6762	7550
BIT01 = 000002	6157#	6167				
BIT02 = 000004	6156#	6166				



BIT03 = 000010	6155#	6165												
BIT04 = 000020	6154#	6164												
BIT05 = 000040	6153#	6163												
BIT06 = 000100	6152#	6162												
BIT07 = 000200	6151#	6161	6614											
BIT08 = 000400	6150#	6160	8095											
BIT09 = 001000	6149#	6159	8001	8105										
BIT1 = 000002	6167#													
BIT10 = 002000	6148#	7978												
BIT11 = 004000	6147#	8112												
BIT12 = 010000	6146#													
BIT13 = 020000	6145#	7206	7985											
BIT14 = 040000	6144#	8081												
BIT15 = 100000	6143#													
BIT2 = 000004	6166#													
BIT3 = 000010	6165#													
BIT4 = 000020	6164#													
BIT5 = 000040	6163#													
BIT6 = 000100	6162#	6862												
BIT7 = 000200	6161#													
BIT8 = 000400	6160#													
BIT9 = 001000	6159#													
BPTVEC = 000014	6175#													
CKDAT 010444	7098	7611#												
CKDAT1 010512	7212	7311	7353	7630#										
CKSTAT 010142	6958	7004	7050	7088	7194	7301	7343	7382	7424	7532#				
CKSWR = 104407	6051#	7973	7974	8000	8015	8079	8080							
CORSZ 001540	6525#	6617	6628*	7325										
CORSZR 002270	6618	6623#												
CR = 000015	6083#	7747												
CRLF = 000200	6084#	6603	7702											
DBUF 015364	6526	6630	6946	6947*	6967	6993	7014	7016	7039	7059	7076	7113	7146	
	7182	7286	7358	7399	7441	7565	7569	7574	7611	7618	8549#			
DBUFP 001542	6526#	6630*	7323*	7324*	7325	7328	7358*	7369*	7399*	7411*	7441*	7548	7588	
	7631													
DDISP = 177570	6090#	6315	6557											
DH1 015025	6416	6422	6428	6434	6440	6446	6451	6457	6463	6493	6499	8501#		
DH2 015072	6469	6475	6504	8508#										
DH3 015147	6481	6487	8516#											
DISPLA 001142	6315#	6557*	6565*	7977*	8127*									
DISPRE 000174	6247#	6565												
DMAP 001536	6524#	6632*	6633*	6635	7449*	7458								
DRVBAR 001522	6512#	6693	6696*	6697	6754*	6761	6764	6902	6904*	6905	6910	6946*	6993*	
	7039*	7076*	7113*	7146*	7182*	7227*	7253	7257	7286*	7328*	7370*	7412*	7452*	
	7549	7553												
DRVCSR 001524	6513#	6780	6784*	6785	6795	6805	6807*	6809	6818	6836	6839*	6840	6857	
	6862*	6864	6868	6872	6883	6885*	6886	6890*	6892	6901*	6909*	6914*	6923*	
	6929*	6948*	6949*	6951	6953	6954*	6995*	6996*	6998	7000	7041*	7042*	7043	
	7045	7046*	7079*	7080*	7081	7083	7084*	7107	7115*	7116*	7123	7124*	7140	
	7148*	7149*	7154	7155*	7164	7185*	7186*	7187	7189	7190*	7229*	7230*	7231	
	7233	7234*	7238	7242	7262*	7263	7267	7271	7275	7289*	7290*	7294	7296	
	7297*	7331*	7332*	7336	7338	7339*	7373*	7374*	7375	7377	7378*	7415*	7416*	
	7417	7419	7420*	7453*	7520*	7532	7533*	7537						
DRVCTO 001530	6518#	6579	6856*	6861*	7455*	7512*	7521*							
DRVCT2 001532	6519#	6584	7456*	7513*	7521	7522*								
DRVDBR 001526	6514#	6577	6716	6719*	6720	6735	6755*	6766	6768	6920	6922*	6924*	6925	

	6931	6969	6972	6994*	7019	7061	7064	7077*	7372*	7393	7396	7414*	7435
	7438	7454*	7614	7645									
DRVWCR 001520	6511#	6573	6643	6656	6673	6676*	6677	6753*	6757	6759	6945*	6992*	7038*
	7075*	7112*	7145*	7183*	7184*	7226*	7246	7250	7287*	7329*	7368*	7410*	7451*
	7540	7542											
DSWR = 177570	6089#	6314	6556										
DT1 015176	6417	6423	6429	6435	6441	6447	6452	6458	6464	6494	6500	8522#	
DT2 015212	6470	6476	6505	8524#									
DT3 015230	6482	6488	8527#										
EMTVEC= 000030	6178#	6541*	6542*										
EM1 014134	6415	8418#											
EM10 014345	6456	8446#											
EM11 014373	6462	8450#											
EM12 014422	6468	8454#											
EM13 014443	6474	8457#											
EM14 014462	6480	8460#											
EM15 014530	6486	8467#											
EM16 014716	6492	8488#											
EM17 014733	6498	8491#											
EM2 014153	6421	8421#											
EM20 014770	6503	8496#											
EM3 014175	6427	8425#											
EM4 014212	6433	8428#											
EM5 014254	6439	8434#											
EM6 014277	6445	8438#											
EM7 014323	6450	8442#											
ERRVEC= 000004	6171#	6554	6555*	6566*	6624*	6629*	6655*	6666*	8086	8087*	8089*	8092*	
GTSWR = 104406	6050#	6598											
HT = 000011	6081#	7700											
IOADR 015332	8539#												
IOPAGE 001544	6527#	7406	7411	7412	7434	7439							
IOTEST 015276	8534#												
IOTVEC= 000020	6176#	6539*	6540*										
KDF 001546	6528#												
KDF11B 015240	8529#												
LDBUF 010322	7037	7565#											
LDBUF1 010374	7178	7285	7327	7588#									
LF = 000012	6082#	7751											
MFPT = 000007	6044#	6613											
MTPS = 106427	6187#												
NXDEV 007656	7401	7407	7447#										
NXDEV1 007660	6637	7448#	7459										
PIRQ = 177772	6088#												
PIRQVE= 000240	6182#												
PRO = 000000	6105#												
PR1 = 000040	6106#												
PR2 = 000100	6107#												
PR3 = 000140	6108#												
PR4 = 000200	6109#												
PR5 = 000240	6110#												
PR6 = 000300	6111#												
PR7 = 000340	6112#												
PS = 177776	6085#	6086											
PSW = 177776	6086#												
PWRMSG 014020	8360	8367#											
PWRVEC= 000024	6177#	6545*	6546*	8329*	8330*	8339*	8345*	8357*	8358*				















#TESTN	001200	6338#	6650*	8122*										
#TIMES	001160	6324#	6547*	6751*	6775*	6804*	6853*	7034*	7072*	7106*	7139*	7175*	7222*	7282*
		7320*	7472*	8110*	8117	8120*								
#TKB	001146	6317#	7730	7737	8145	8162	8216	8222						
#TKS	001144	6316#	7728	7735	8143	8159	8183*	8214	8220					
#TN =	000001	6057#	6061#											
#TPB	001152	6319#	7746*											
#TPFLG	001157	6323#	7679											
#TPS	001150	6318#	7369	7370	7392	7397	7744							
#TRAP	014052	6240	6543	8381#										
#TRAP2	014074	8392#	8403											
#TRPAD	014106	8386	8403#											
#TSTM	001004	6283#												
#TSTM1	001102	6296#	6651*	7471*	7977	8013	8099	8121*	8122	8127				
#TTYIN	013442	8243	8244	8261	8265#									
#TYPDS	011644	7903#	8408											
#TYPE	010614	7679#	7788	8404										
#TYPEC	011026	7708	7715	7722	7727#	8185								
#TYPEX	011146	7750	7752	7755#										
#TYPOC	011442	7844#	8405											
#TYPON	011456	7843	7846#	8407										
#TYPOS	011416	7839#	8406											
#UNIT	001206	6341#	6631*	6640	6641	7457*								
#UNITM	001010	6285#												
#USWR	001220	6348#												
#VECT1	001244	6373#	6580											
#VECT2	001246	6374#												
#XOFF =	000023	6056#	7732											
#XON =	000021	6055#	7739	8227										
#XTSTR	012446	8084#												
#OFILL	011641	7840*	7044*	7854	7889#									
.	015366	6242#	6246#	6251#	6258	6259#	6261#	6263#	6264#	6270	6271#	6273#	6275#	6293#
		6536	6550	6551	6604#	7809#	7957#	8063#	8265#	8341	8365	8544#		
.#X =	001000	6270#	6275											

. ABS. 015366 000

ERRORS DETECTED: 0

CVDRA.C,CVDRA.C/CRF:SYM/NL:TOC=SYSMAC.SML,CVDRA.C.P11  
 RUN-TIME: 9 12 .8 SECONDS  
 RUN-TIME RATIO: 77/22=3.3  
 CORE USED: 36K (72 PAGES)