

# NCV-11

DIAGNOSTIC  
CZNCCA0

AH-E772A-MC  
COPYRIGHT © 73-78  
FICHE 1 OF 1

DEC 1978  
**digital**  
MADE IN USA

This microfiche card contains a grid of frames, each containing diagnostic data. The data is organized into columns and rows, with some frames containing text and others containing graphical representations like bar charts or waveforms. The text is too small to read clearly, but it appears to be technical information related to the diagnostic code CZNCCA0.

IDENTIFICATION

B 1

SEQ 0001

PRODUCT CODE: AC-E771A-MC  
PRODUCT NAME: CZNCCAO NCV11 DIAGNOSTIC TEST  
DATE: AUGUST 1978  
MAINTAINER: DIAGNOSTIC ENGINEERING

COPYRIGHT (C) 1973,1978  
DIGITAL EQUIPMENT CORPORATION, MAYNARD, MASS.

THIS SOFTWARE IS FURNISHED UNDER A LICENSE FOR USE ONLY ON A SINGLE COMPUTER SYSTEM AND MAY BE COPIED ONLY WITH THE INCLUSION OF THE ABOVE COPYRIGHT NOTICE. THIS SOFTWARE, OR ANY OTHER COPIES THEREOF, MAY NOT BE PROVIDED OR OTHERWISE MADE AVAILABLE TO ANY OTHER PERSON EXCEPT FOR USE ON SUCH SYSTEM AND TO ONE WHO AGREES TO THESE LICENSE TERMS. TITLE TO AND OWNERSHIP OF THE SOFTWARE SHALL AT ALL TIMES REMAIN IN DEC.

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION.

DEC ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT WHICH IS NOT SUPPLIED BY DEC.

TABLE OF CONTENTS

1.0.	ABSTRACT
2.0	REQUIREMENTS
2.1	EQUIPMENT
2.2	STORAGE
2.3	PRELIMINARY PROGRAMS
3.0	LOADING PROCEDURE
4.0	STARTING PROCEDURE
4.1	PROGRAM START
5.0	SOFTWARE SWITCH REGISTER
5.1	LOGIC TEST OPTIONS
5.2	FIELD ADJUSTMENT OPTIONS
5.3	CONTROL
6.0	ERROR REPORTING
7.0	MISCELLANEOUS
7.1	NCV11 BUS ADDRESS MODIFICATION
7.2	XXDP/APT NOTES
7.3	POWER FAIL
7.4	MULTIPLE NCV11 INTERFACE TESTING
7.5	RESTRICTIONS
7.6	ADDRESS MAKER TABLE
8.0	EXECUTION TIME
9.0	PROGRAM TEST DESCRIPTIONS
10.0	LISTING

## 1.0 ABSTRACT

THE NCV11 DIAGNOSTIC PROGRAM IS A SERIES OF TESTS DESIGNED TO TEST ALL LOGIC FUNCTIONS AND DATA PATHS ACCESSIBLE ON THE M8026 AND M8036. THE M7952 DIAGNOSTIC SHOULD HAVE BEEN EXECUTED. TOTAL PROGRAM CONTROL IS ACCOMPLISHED THRU THE CONSOLE TERMINAL VIA KEYBOARD TEST SELECTION AND THE PROVISIONS OF SECTION 5. THE PROGRAM CAN BE EXECUTED ON AN LSI-11 OR PDP-11 COMPUTER.

## 2.0 REQUIREMENTS

## 2.1 EQUIPMENT

1. PDP11 FAMILY OR LSI-11 FAMILY COMPUTER
2. I/O TERMINAL (IE: LA36)
3. NCV11 OPTION INCLUDING KVV11 REAL TIME CLOCK (M7952)
4. A017 SELF-TEST CONNECTOR (70-12894) (REQUIRED FOR SECTION 9.2 + 9.3)
5. H3060 JOYSTICK (OPTIONAL)
6. HARDWARE TESTER AND PROM BLASTER (OPTIONAL)

## 2.2 STORAGE

THE PROGRAM REQUIRES 16K OF MEMORY. IF MEMORY MANAGEMENT OR ADDITIONAL MEMORY ARE SENSED, THE PROGRAM WILL USE THOSE HARDWARE OPTIONS.

## 2.3 PRELIMINARY PROGRAMS

THE KVV11 DIAGNOSTIC (MD-11-DVKWA) SHOULD HAVE BEEN RUN.

## 3.0 LOADING PROCEDURE

NORMAL PROCEDURE FOR LOADING A BINARY PROGRAM INTO MEMORY SHOULD BE FOLLOWED.

## 4.0 STARTING PROCEDURE

1. MAKE SURE THE NCV11 DEVICE BUS ADDRESS, INTERRUPT VECTOR ON THE M8026 AGREE WITH THE DEFAULT VALUES DEFINED IN SECTION 7.1.
2. MAKE SURE THE NCV11 CLOCK BUS ADDRESS ON THE M7952 AGREE WITH THE DEFAULT VALUE DEFINED IN SECTION 7.1.
3. MAKE SURE THE NCV11 INTERRUPT PRIORITY LEVEL ON THE M8217 AGREE WITH THE DEFAULT VALUE DEFINED IN SECTION 7.1.
4. INSURE THAT THE HALT SWITCH IS DISABLED (IF ANY).
- LSI11: 5. TYPE THE STARTING ADDRESS OF 200 AND THE CHARACTER G.
- LSI11: 6. THE PROGRAM WILL RESPOND BY TYPING THE PROGRAM TITLE.
7. THE PROGRAM WILL REQUEST SWITCH REGISTER VALUE.
8. THE PROGRAM WILL TYPE THE TEST SELECTION MENU FOR THE OPERATOR.
9. THE OPERATOR SELECT'S THE APPROPRIATE TEST BY TYPING THE TEST LETTER AND 'CR'

IF THE PROGRAM IS EXECUTED ON A CPU WITH A SWITCH REGISTER AND THE OPERATOR SETS ALL SWITCHES TO A 1, THE SOFTWARE S.R. WILL BE USED. IF THE HARDWARE SWITCH REGISTER IS USED, THE SOFTWARE S.R. HAS NO EFFECT.

## 4.1 PROGRAM START

200  
204  
210

STARTING ADDRESS OF THE PROGRAM  
RESTART ADDRESS OF THE PROGRAM  
STARTING ADDRESS FOR THE FACTORY OPTION CHECK-OUT AREA.  
(INFORMS THE PROGRAM THE TESTER AND BLASTER ARE CONNECTED)

## 5.0 SOFTWARE SWITCH REGISTER

## 5.1 LOGIC TEST OPTIONS

SWITCH	OCTAL	FUNCTION
SW15=1	100000	HALT ON ERROR
SW14=1	040000	LOOP ON TEST
SW13=1	020000	INHIBIT ERROR TYPEOUTS
SW11=1	004000	INHIBIT ITERATIONS
SW10=1	002000	BELL ON ERROR
SW09=1	001000	LOOP ON ERROR
SW08=1	0004XX	LOOP ON TEST IN SWR <7-0>

## 5.2 FIELD ADJUSTMENT LOOP

SWITCH	OCTAL	FUNCTION
SW15=1	100000	HALT ON "INPUT VOLTAGE OUT OF RANGE" ERROR
SW13=1	020000	INHIBIT ERROR OR CONVERSION TYPEOUT
SW09=1	001000	INHIBIT CONVERSIONS ON CAMERA #3 GAIN = 1
SW08=1	000400	INHIBIT CONVERSIONS ON CAMERA #2 GAIN = 1
SW07=1	000200	INHIBIT CONVERSIONS ON CAMERA #1 GAIN = 1
SW06=1	000100	INHIBIT CONVERSIONS ON CAMERA #0 GAIN = 1
SW04=1	000020	INHIBIT CONVERSIONS ON JOYSTICK
SW03=1	000010	INHIBIT CONVERSIONS ON CAMERA #3 GAIN = 2
SW02=1	000004	INHIBIT CONVERSIONS ON CAMERA #2 GAIN = 2
SW01=1	000002	INHIBIT CONVERSIONS ON CAMERA #1 GAIN = 2
SW00=1	000001	INHIBIT CONVERSIONS ON CAMERA #0 GAIN = 2

## 5.3 CONTROL

1. THE SOFTWARE SWITCH REGISTER 'SWREG' (LOC. 176) CAN BE CHANGED BY USING THE ODT FACILITIES.
2. THE SOFTWARE SWITCH REGISTER CAN BE CHANGED UNDER PROGRAM CONTROL BY TYPING THE 'CONTROL & G' KEYS. THIS KEYBOARD OPERATION WILL PRINT THE CURRENT CONTENTS AND ACCEPT NEW OCTAL SWITCH REGISTER DATA TERMINATED WITH A CARRIAGE RETURN.
- LSI-11: 3. ONCE THE ODT MODE HAS BEEN ENTERED BECAUSE OF AN ERROR CONDITION WITH BIT15 SET (HALT ON ERROR), STEP #2 ABOVE IS OF NO VALUE, SO RESORT TO STEP #1 TO ALTER THE SOFTWARE SWITCH REGISTER IF DESIRED BEFORE TYPING 'P' (CONTINUE).
4. IF THE PROGRAM IS PERFORMING RESET INSTRUCTIONS, SEVERAL 'CONTROL & C' OR 'CONTROL & G' COMMANDS MAY BE NECESSARY TO BE ACKNOWLEDGE BY THE PROGRAM.
5. TESTING CAN BE ABORTED BY TYPING THE 'CONTROL & C' KEYS.

6.0 ERROR REPORTING  
-----

ALL ERRORS ARE ACCOMPANIED WITH AN ENGLISH LANGUAGE DESCRIPTIVE COMMENT AS TO THE TYPE OF FAILURE. FURTHER QUALIFICATION OF THE ERROR CAN BE OBTAINED IF NEEDED FROM THE COMMENT AT THE ERROR PC OR FROM THE TEST ITSELF.

7.0 MISCELLANEOUS  
-----

## 7.1 NCV11 BUS ADDRESS MODIFICATION

MODIFY LOCATION '\$BASE' (LOC. 1250) IF BASE NCV11 BUS ADDRESS IS NOT 772760.  
MODIFY THE LOW NINE BITS OF LOCATION '\$VECT1' (LOC. 1244) IF BASE NCV11 INTERRUPT VECTOR IS NOT 370.  
MODIFY THE HIGH THREE BITS OF LOCATION '\$VECT1' (LOC. 1244) IF THE INTERRUPT PRIORITY LEVEL IS NOT LEVEL 6 ON A UNIBUS CPU.  
MODIFY LOCATION '\$CDW1' (LOC. 1254) IF BASE NCV11 CLOCK BUS ADDRESS IS NOT 770420.

## 7.2 XXDP/APT NOTES

THIS DIAGNOSTIC IS CHAINABLE UNDER XXDP (REQUIRES 16K OR MORE).  
IF RUNNING UNDER XXDP/ACT/APT, THE LOGIC AND DIFLIN TESTS WILL BE RUN.

## 7.3 POWER FAIL

A POWER FAILURE WILL CAUSE A RESTART MESSAGE ON POWER UP AT WHICH TIME THE PROGRAM IS RESTARTED (ONLY ON SYSTEMS WITH NON-VOLATILE MEMORY AND WITH APPROPRIATE HARDWARE).

## 7.4 MULTIPLE NCV11'S INTERFACE TESTING

THIS PROGRAM DOES NOT 'AUTO-SIZE' THE NUMBER OF NCV11'S CONNECTED. FOR EACH ADDITIONAL NCV11, THE OPERATOR MUST MODIFY LOCATIONS \$BASE, \$VECT1 AND \$CDW1 (REF. 7.1).

## 7.5 RESTRICTIONS

KWV11 REAL TIME CLOCK (M7952) MUST NOT BE CONNECTED TO M8C26 'FAST-ON' TABS. UNLESS OTHERWISE STATED, NO EXTERNAL CONNECTIONS TO M8036 OR A017.

## 7.6 ADDRESS MAKER TABLE

SEQ 0006

THE M8036 CONTAINS LOGIC TO CONVERT A/D DATA INTO A RELATIVE ADDRESS. BELOW IS A TABLE WHICH SHOWS THE ADDRESS MAKER OUTPUT WITH THE 'TEST CONTROL' MAINT. BIT SET. SETTING THIS BIT ENABLES THE STATES OF THE 'GAIN, ZB ENABLE AND RESOLUTION' BITS SIMULATE THE CONVERTED A/D DATA.

RESOLUTION			ADDRESS MAKER OUTPUT BITS																
RES0	RES1	WORD*16	15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00	
1	1	1	B	G	Z	G	Z	G	1	1	1	G	Z	G	Z	G	1	1	1
1	1	0	0	B	G	Z	G	Z	G	1	1	G	Z	G	Z	G	1	1	0
1	0	1	0	0	B	G	Z	G	Z	G	1	0	G	Z	G	Z	G	1	0
1	0	0	0	0	0	B	G	Z	G	Z	G	1	G	Z	G	Z	G	1	0
0	1	1	0	0	0	0	B	G	Z	G	Z	G	0	G	Z	G	Z	G	0
0	1	0	0	0	0	0	0	B	G	Z	G	Z	G	G	Z	G	Z	G	0
0	0	1	0	0	0	0	0	0	B	G	Z	G	Z	G	G	Z	G	Z	G

0 = ALWAYS A 0

1 = ALWAYS A 1

G = GAIN FLOP STATE

Z = ZB ENABLE FLOP STATE

B = THE 'AND' OF ZB ENABLE WITH ZB MAINT. INPUT

## 8.0 EXECUTION TIME

LOGIC: EXECUTION TIME RANGES FROM ABOUT 5 SECONDS WITH NO ITERATIONS TO ABOUT 70 SECONDS WITH ITERATIONS ENABLED.  
 AN END PASS MESSAGE INDICATES ALL SUB-TESTS HAVE COMPLETED.  
 EACH ADDITIONAL 4K OF MEMORY WILL ADD ABOUT 10 SECONDS TO THE LOGIC TEST RUNTIME.  
 DIFFERENTIAL LINEARITY: EXECUTION TIME IS ABOUT 90 SECONDS.

## 9.0 PROGRAM TEST DESCRIPTIONS

SEQ 0007

-----  
THE PROGRAM CONSISTS OF FOUR MAIN SECTIONS PLUS THREE AUXILIARY AND THREE FACTORY OPTION CHECK-OUT SECTIONS. THE OPERATOR SELECTS EACH SECTION VIA THE CONSOLE KEYBOARD. BELOW IS A BRIEF DESCRIPTION OF EACH SECTION AND THE KEYBOARD CHARACTER.

MAIN SECTIONS  
-----

## 9.1 L LOGIC TEST (M8026 + M8036)

<NO INTERVENTION> <SETUP ONLY IF SA=210>

THE TEST CONTAINS A SERIES OF INDEPENDENT SUB-TESTS DESIGNED TO TEST LOGIC FUNCTIONS AND DATA PATHS OF THE NCV11 GAMMA CAMERA INTERFACE. A COMPLETE LIST OF TESTS IS AVAILABLE IN THE TABLE OF CONTENTS AT THE BEGINNING OF THE LISTING. THE COMMENT FIELD WITHIN EACH SUB-TEST TITLE CAN BE BENEFICIAL TO UNDERSTANDING THE LOGIC TESTED. ADDITIONAL LOGIC TESTS OF THE A017 WILL BE EXECUTED IF THE PROGRAM WAS STARTED AT LOC. 210.

## 9.2 D (M) DIFFERENTIAL LINEARITY (A017)

<REQUIRES SELF-TEST CONNECTOR IN J1 ON THE A017> <SETUP INTERVENTION ONLY>  
<A017 SWITCH SET TO 'MAINT.'" POSITION>

A FINITE VARIATION OF INPUT VOLTAGE EQUALS A GIVEN CONVERTED VALUE OR STATE. THE TEST IS TO VERIFY THE WIDTH OF EACH POSSIBLE STATE. AN INPUT VOLTAGE IS RAMPED AND THE NCV11 SAMPLES THE RESULT. THE NCV11 INCREMENTS THE RESPECTIVE MEMORY LOCATION CORRESPONDING TO THE INPUT VALUE. THE PROGRAM THEN DETERMINES IF ANY STATE HAS BEEN SKIPPED, IS EXCESSIVELY WIDE OR NARROW. WHEN 'M' IS USED TO SELECT THE SECTION, THE PROGRAM OUTPUT AN EXPANDED REPORT OF THE 254. STATES. TIGHTER ERROR TOLERANCES ARE USED IF RUNNING IN THE OPTION CHECKOUT AREA (SA 210).

## 9.3 F FINAL ACCEPTANCE

<REQUIRES SELF-TEST CONNECTOR IN J1 ON THE A017> <SETUP INTERVENTION ONLY>  
<A017 SWITCH SET TO 'MAINT.'" POSITION>

THE SUB-SECTION RUNS SECTION 'L' AND 'D' TO VERIFY PROPER OPERATION.



## 9.4 A ADJUSTMENT OF A017 AT FIELD SITE

<MANUAL INTERVENTION> <SETUP INTERVENTION>  
 <A017 SWITCH SET TO 'OPER.' POSITION>

COARSE ADJUSTMENT OF THE A017 CAN BE PERFORMED USING THIS SUB-SECTION.  
 THE OPERATOR MAY SELECT THE CAMERA AND GAIN TO BE SAMPLED USING THE  
 SWITCH REGISTER. A SERIES OF CONVERSIONS ARE TAKEN ON EACH CAMERA  
 AND THE OPERATOR IS INFORMED OF THE RESULTS.

SWITCH	OCTAL	FUNCTION
SW15=1	100000	HALT ON "INPUT VOLTAGE OUT OF RANGE" ERROR
SW13=1	020000	INHIBIT ERROR OR CONVERTED VALUE TYPE-OUT
SW09=1	001000	INHIBIT CONVERSIONS ON CAMERA #3 GAIN - 1
SW08=1	000400	INHIBIT CONVERSIONS ON CAMERA #2 GAIN - 1
SW07=1	000200	INHIBIT CONVERSIONS ON CAMERA #1 GAIN 1
SW06=1	000100	INHIBIT CONVERSIONS ON CAMERA #0 GAIN 1
SW04=1	000020	INHIBIT CONVERSIONS ON JOYSTICK
SW03=1	000010	INHIBIT CONVERSIONS ON CAMERA #3 GAIN 2
SW02=1	000004	INHIBIT CONVERSIONS ON CAMERA #2 GAIN = 2
SW01=1	000002	INHIBIT CONVERSIONS ON CAMERA #1 GAIN 2
SW00=1	000001	INHIBIT CONVERSIONS ON CAMERA #0 GAIN 2

AUXILIARY SECTION  
 -----

## 9.5 O OTHER TERMINAL ADDRESS

IN SOME CUSTOMER SITES, THE CONSOLE TERMINAL MAY NOT BE LOCATED  
 WITHIN EASY ACCESS TO THE NCV11. THIS SECTION ALLOWS THE OPERATOR  
 TO CHANGE THE PROGRAMS CONTROL TO ANOTHER TERMINAL.

## 9.6 H HELP THE OPERATOR

A LIST OF THE COMMANDS WILL BE TYPED TO REFRESH THE OPERATOR'S MEMORY.

## 9.7 S SOFTWARE SWITCH REGISTER

ENABLES THE OPERATOR TO CHANGE THE SOFTWARE SWITCH REGISTER WHEN  
 NOT RUNNING ANOTHER SUB-SECTION.

FACTORY OPTION CHECK-OUT SECTION  
 -----

## 9.8 I INITIAL ADJUSTMENT OF A017

<MANUAL INTERVENTION> <SETUP INTERVENTION> <HARDWARE TESTER>  
 <A017 SWITCH SET TO 'OPER.' POSITION>

A KNOWN GOOD DIGITAL TO ANALOG (D/A) SUPPLIES A REFERENCE INPUT  
 VOLTAGE. THE OPERATOR IS INFORMED WHICH ADJUSTMENT TO PERFORM.  
 THE PURPOSE OF THE TEST IS TO VERIFY THAT THE ADJUSTMENT TO THE PRE-AMP  
 SECTION CAN BE PERFORMED. THE TEST DOES NOT ATTEMPT TO CALIBRATE  
 THE PRE-AMP, BUT ONLY TO FUNCTIONALLY VERIFY THE ADJUSTMENTS.

9.9

B BLASTING THE LINEARITY CORRECTION PROM

J 1

SEQ 0009

<MANUAL INTERVENTION> <SETUP INTERVENTION> <HARDWARE TESTER>  
<A017 SWITCH SET TO 'MAINT.' POSITION>

THE TEST IS DESIGNED TO CREATE THE LINEARITY CORRECTION PROM (LCP). THE TESTER HARDWARE CONTAINS RAM STORAGE TO EMULATE THE LCP. THE PROGRAM WILL RUN DIFFERENTIAL LINEARITY. THE PROGRAM WILL THEN USE THE RESULTS TO DETERMINE THE CORRECT VALUE TO BE PLACED IN THE LCP. THE PROGRAM WILL THEN INFORM THE PROM BLASTER TO GENERATE A CORRECTED LINEARITY PROM FOR THE A017 MODULE. UPON COMPLETION OF GENERATION AND VERIFICATION STAGE, THE OPERATOR IS INSTRUCTED TO REMOVE THE EMULATOR CABLE FROM THE A017 AND INSERT THE NEWLY CREATED LCP. THE PROGRAM WILL RE-EXECUTE DIFFERENTIAL LINEARITY.

9.10

C CONTROL PROGRAM PROM

<MANUAL INTERVENTION> <SETUP INTERVENTION> <HARDWARE TESTER>

THE ROUTINE WILL CREATE THE M8036 CONTROL PROM. THE OPERATOR MAY CREATE SEVERAL COPIES BY REPEATELY EXECUTING THIS SECTION. THE PROGRAM WILL INFORM THE OPERATOR THE STEPS TO PERFORM.

LOCATION	OCTAL	BINARY
00	215	10001101
01	244	10100100
02	116	01001110
03	144	01100100
04	215	10001101
05	244	10100100
06	116	01001110
07	144	01100100
10	215	10001101
11	244	10100100
12	116	01001110
13	144	01100100
14	215	10001101
15	244	10100100
16	116	01001110
17	144	01100100
20	116	01001110
21	144	01100100
22	216	10001110
23	244	10100100

10.0

LISTING

17	BASIC DEFINITIONS
127	MEMORY MANAGEMENT DEFINITIONS
277	OPERATIONAL SWITCH SETTINGS
288	TRAP CATCHER
297	STARTING ADDRESS(ES)
304	ACT11 HOOKS
315	APT PARAMETER BLOCK
337	COMMON TAGS
381	APT MAILBOX-ETABLE
430	ERROR POINTER TABLE
586	INITIALIZE THE COMMON TAGS
629	TYPE PROGRAM NAME
636	GET VALUE FOR SOFTWARE SWITCH REGISTER
650	PRIME THE NCV11 ADDRESSES FROM THE DEFAULT VALUES
678	DIAGNOSTIC IDENTIFICATION TYPEOUT
691	KEYBOARD COMMAND DECODER
840	
841	TEST
842	DESCRIPTION
843	-----
844	T1 VERIFY THE 8 NCV11 AND 2 NCV11 CLOCK BUS ADDRESSES RESPOND
878	T2 FLOAT A 1 ACROSS 10 BITS OF THE COMMAND/STATUS REG.
899	T3 VERIFY THAT "INIT" CLEARS THE CSR REGISTER
913	T4 VERIFY THAT "CLEAR ALL" CLEARS THE CSR REGISTER
927	T5 VERIFY LOW BYTE OPERATION OF THE "CSR" REGISTER
947	T6 FLOAT A 1 ACROSS 4 BITS OF THE SPECIAL FUNCTION REGISTER
965	T7 VERIFY THAT CLEARING HIGH BYTE OF SFR DOES NOT CLEAR LOW BYTE
979	T10 VERIFY THAT "INIT" CLEARS THE SFR REGISTER
992	T11 VERIFY THAT "CLEAR ALL" CLEARS THE SFR REGISTER
1005	T12 FLOAT A 1 ACROSS THE WORD COUNT REGISTER
1023	T13 FLOAT A 1 ACROSS THE BUS ADDRESS REGISTER
1041	T14 FLOAT A 1 ACROSS THE OFFSET REGISTER
1059	T15 VERIFY NO DUAL REGISTER SELECTION
1099	T16 VERIFY "CLR ALL" CLEARS THE EXTENDED OFFSET BITS
1113	T17 TEST THE "ACTIVE" FLOP CAN SET AND CLEAR
1148	
1149	T20 VERIFY Z INPUTS CAUSE THE LOW 8 BITS OF 32 BIT COUNTER TO CHANGE IN MATRIX MODE
1176	T21 VERIFY Z INPUTS CAUSE THE LOW 16 BITS OF 32 BIT COUNTER TO CHANGE
1205	T22 VERIFY Z INPUTS CAUSE THE LOW 24 BITS OF 32 BIT COUNTER TO CHANGE
1229	T23 VERIFY Z INPUTS CAUSE THE HIGH 8 BITS OF THE 32 BIT COUNTER TO CHANGE
1248	T24 VERIFY Z INPUTS DO NOT CAUSE THE LOW 8 BITS OF 32 BIT COUNTER TO CHANGE IN LIST MODE
1265	T25 TEST THAT "WCA OVFL" SETS Z/WC OVERFLOW FLOP AND "CLR ALL" CLEARS IT
1301	T26 TEST THAT "WCA OVFL" SETS Z/WC OVERFLOW FLOP AND "CLR WC OVFL" CLEARS IT
1339	T27 TEST THAT "WCA OVFL" GENERATES AN INTERRUPT
1390	T30 VERIFY "WCA OVFL" CLEARS "ACTIVE"
1417	
1418	T31 VERIFY JOYSTICK DONE FLOP SETS
1442	T32 VERIFY THAT "RESET" INSTRUCTION CLEARS THE JOY READY FLOP
1473	T33 JOYSTICK DATA PATH = GAIN =0 ZB ENABLE =0 RES. = 000
1491	T34 JOYSTICK DATA PATH = GAIN =1
1509	T35 JOYSTICK DATA PATH = ZB ENABLE =1
1526	T36 JOYSTICK DATA PATH RES. = 001
1544	T37 JOYSTICK DATA PATH RES. = 010
1562	T40 JOYSTICK DATA PATH RES. = 100

1579		
1580	T41	VERIFY THE DATA INCREMENT FUNCTION
1598	T42	VERIFY THE DATA INCREMENT CARRY BIT
1617	T43	VERIFY THE DATA INCREMENT FUNCTION IS INHIBITED
1635	T44	VERIFY THE DATA DECREMENT FUNCTION
1654	T45	VERIFY THE DATA DECREMENT BORROW
1672	T46	VERIFY THE DATA DECREMENT FUNCTION IS INHIBITED
1690	T47	TEST ADDRESS MAKER - MATRIX MODE - RES = 7 GAIN = 0 ZB ENABLE = 0
1708	T50	TEST ADDRESS MAKER - MATRIX MODE - RES = 7 GAIN = 1 ZB ENABLE = 0
1726	T51	TEST ADDRESS MAKER - MATRIX MODE - RES = 7 GAIN = 0 ZB ENABLE = 1
1744	T52	TEST ADDRESS MAKER - MATRIX MODE - RES = 6 GAIN = 0 ZB ENABLE = 0
1762	T53	TEST ADDRESS MAKER - MATRIX MODE - RES = 6 GAIN = 1 ZB ENABLE = 0
1780	T54	TEST ADDRESS MAKER - MATRIX MODE - RES = 6 GAIN = 0 ZB ENABLE = 1
1798	T55	TEST ADDRESS MAKER - MATRIX MODE - RES = 5 GAIN = 0 ZB ENABLE = 0
1816	T56	TEST ADDRESS MAKER - MATRIX MODE - RES = 5 GAIN = 1 ZB ENABLE = 0
1834	T57	TEST ADDRESS MAKER - MATRIX MODE - RES = 5 GAIN = 0 ZB ENABLE = 1
1852	T60	TEST ADDRESS MAKER - MATRIX MODE - RES = 4 GAIN = 0 ZB ENABLE = 0
1870	T61	TEST ADDRESS MAKER - MATRIX MODE - RES = 4 GAIN = 1 ZB ENABLE = 0
1888	T62	TEST ADDRESS MAKER - MATRIX MODE - RES = 4 GAIN = 0 ZB ENABLE = 1
1906	T63	TEST ADDRESS MAKER - MATRIX MODE - RES = 3 GAIN = 0 ZB ENABLE = 0
1924	T64	TEST ADDRESS MAKER - MATRIX MODE - RES = 3 GAIN = 1 ZB ENABLE = 0
1942	T65	TEST ADDRESS MAKER - MATRIX MODE - RES = 3 GAIN = 0 ZB ENABLE = 1
1960	T66	TEST ADDRESS MAKER - MATRIX MODE - RES = 2 GAIN = 0 ZB ENABLE = 0
1978	T67	TEST ADDRESS MAKER - MATRIX MODE - RES = 2 GAIN = 1 ZB ENABLE = 0
1996	T70	TEST ADDRESS MAKER - MATRIX MODE - RES = 2 GAIN = 0 ZB ENABLE = 1
2014	T71	TEST ADDRESS MAKER - MATRIX MODE - RES = 1 GAIN = 0 ZB ENABLE = 0
2032	T72	TEST ADDRESS MAKER - MATRIX MODE - RES = 1 GAIN = 1 ZB ENABLE = 0
2050	T73	TEST ADDRESS MAKER - MATRIX MODE - RES = 1 GAIN = 0 ZB ENABLE = 1
2068	T74	TEST ADDRESS MAKER - LIST MODE - ZB ENABLE = 0 GAIN = 0
2087	T75	TEST ADDRESS MAKER - LIST MODE - ZB ENABLE = 1 GAIN = 0
2106	T76	TEST ADDRESS MAKER - LIST MODE - ZB FNABLE = 0 GAIN = 1
2124		
2125	T77	ENABLE A ONE WORD TRANSFER SECTION LIST MODE
2178	T100	ENABLE A 512 WORD TRANSFER SECTION LIST MODE
2232	T101	VERIFY 'TIMEOUT' FLOP SETS AND 'CLR ALL' CLEARS IT
2268	T102	VERIFY 'TIMEOUT' FLOP SETS AND 'CLR TIMEOUT' CLEARS IT
2303	T103	VERIFY 'TIMEOUT' INTERRUPT
2341	T104	VERIFY INCREMENTING INTO EXTENDED ADDRESS BIT 16
2368	T105	VERIFY INCREMENTING INTO EXTENDED ADDRESS BIT 17
2397	T106	VERIFY 'SET EVENT' DATA GENERATES A 177777 DATA WORD
2423	T107	VERIFY 'SET TIME' DATA GENERATES A 000000 DATA WORD
2449	T110	VERIFY 'CLOCK ST1' GENERATES A EVENT (177777) DATA WORD
2475	T111	VERIFY 'CLOCK OVERFLOW' GENERATES A TIME (000000) DATA WORD
2503	T112	VERIFY 'SET TIME' OVERRIDES 'SET EVENT' DATA
2528	T113	DO A ONE WORD MATRIX MODE TRANSFER -CHECK FOR INCREMENT FUNCTION
2556	T114	VERIFY EACH BIT OF THE INCREMENT REG. DATA PATH
2597	T115	CHECK FOR LOW BYTE 'INC OVFL' TO SET CELL OVERFLOW AND 'CLR CELL' TO CLEAR IT
2645	T116	CHECK FOR WORD 'INC OVFL' TO SET CELL OVERFLOW AND 'CLR ALL' TO CLEAR IT
2686	T117	CHECK FOR 'CELL OVERFLOW' INTERRUPT
2724	T120	VERIFY CORRECT BR LEVEL THE NCV-11
2779		
2780	T121	VERIFY A 1 WORD MATRIX MODE XFR USING OFFSET - 13
2802	T122	VERIFY A 1 WORD MATRIX MODE XFR USING OFFSET - 12
2824	T123	VERIFY A 1 WORD MATRIX MODE XFR USING OFFSET - 11

2846	T124	VERIFY A 1 WORD MATRIX MODE XFR USING OFFSET - 10
2868	T125	VERIFY A 1 WORD MATRIX MODE XFR USING OFFSET - 09
2890	T126	VERIFY A 1 WORD MATRIX MODE XFR USING OFFSET - 08
2912	T127	VERIFY A 1 WORD MATRIX MODE XFR USING OFFSET - 07
2934	T130	VERIFY A 1 WORD MATRIX MODE XFR USING OFFSET - 06
2956	T131	VERIFY A 1 WORD MATRIX MODE XFR USING OFFSET - 05
2978	T132	VERIFY A 1 WORD MATRIX MODE XFR USING OFFSET - 04
3000	T133	VERIFY A 1 WORD MATRIX MODE XFR USING OFFSET - 03
3022	T134	VERIFY A 1 WORD MATRIX MODE XFR USING OFFSET - 02
3044		
3045	T135	VERIFY THE ADM INPUT TO THE MATRIX MUX. USING GAIN ENABLE
3081	T136	VERIFY THE ADM INPUT TO THE MATRIX MUX. ADDER USING ZB ENABLE
3106	T137	VERIFY LOW BYTE OPERATION OF THE "TESTX" FLOP
3137	T140	VERIFY BIT 12 ADDER INPUT TO MATRIX MODE MUX
3159	T141	VERIFY BIT 13 ADDER INPUT TO MATRIX MODE MUX
3181	T142	VERIFY BIT 14 ADDER INPUT TO MATRIX MODE MUX
3208	T143	CHECK FOR HIGH BYTE "INC OVFL" TO SET CELL OVERFLOW
3243	T144	VERIFY EACH BIT OF THE LOWER 16 BIT Z COUNTER (TESTER ONLY)
3271	T145	VERIFY EACH BIT OF THE HIGHER 16 BIT Z COUNTER (TESTER ONLY)
3299	T146	VERIFY THAT CAMERA 01 CHANNEL IS OPERATIONAL (TESTER ONLY)
3324	T147	VERIFY THAT CAMERA 10 CHANNEL IS OPERATIONAL (TESTER ONLY)
3348	T150	VERIFY THAT CAMERA 11 CHANNEL IS OPERATIONAL (TESTER ONLY)
3372	T151	DYNAMIC MATRIX MODE ADDRESS
3448	T152	DYNAMIC LIST MODE ADDRESS
3521	T153	DYNAMIC LIST MODE TRANSFER - MAXIMUM BUFFER LENGTH IN LOWER 28K
3567	T154	ONE MATRIX DATA TRANSFER TO EACH 4K EXTENDED MEMORY
3621	T155	ONE LIST DATA TRANSFER TO EACH 4K EXTENDED MEMORY
3674	T156	VERIFY BIT 15 MATRIX ADDER INPUT
3714	T157	VERIFY HIGH BYTE OPERATION OF THE "TEST X"
3742	T160	VERIFY BIT 16 INPUT TO THE MATRIX MODE ADDER
3783	T161	DETERMINE IF DIFLIN IS TO BE RUN (F)
3792		END OF PASS ROUTINE
3831		ERROR ASCII MESSAGES
4094		TTY INPUT ROUTINE
4233		READ AN OCTAL NUMBER FROM THE TTY
4271		CONVERT BINARY TO DECIMAL AND TYPE ROUTINE
4338		SCOPE HANDLER ROUTINE
4404		TYPE ROUTINE
4483		BINARY TO OCTAL (ASCII) AND TYPE
4561		ERROR HANDLER ROUTINE
4616		ERROR MESSAGE TYPEOUT ROUTINE
4663		APT COMMUNICATIONS ROUTINE
4720		POWER DOWN AND UP ROUTINES
4763		ROUTINE TO SIZE MEMORY
4844		SAVE AND RESTORE R0-R5 ROUTINES
4889		INTEGER MULTIPLY ROUTINE
4936		INTEGER DIVIDE ROUTINE
5018		DOUBLE LENGTH BINARY TO DECIMAL ASCII CONVERT ROUTINE
5080		SINGLE LENGTH BINARY TO DECIMAL ASCII ROUTINE
5098		TRAP DECODER
5121		TRAP TABLE
5144		A TO D FIELD SITE AND ADJUSTMENT LOOP

```
1      .LIST ME
2      .NLIST MD,MC,CND
3
4      167400      .ENABL ABS,AMA
5      000001      $SWR-167400
6
7      .MCALL .SCATCH,.SCMTAG,.STYPE,.SEOP,.EQUAT,.HEADER,.$ERROR,.STYPOCT
8      .MCALL .SPARM,.$POWER,.$READ,.$SAVE,.$SCOPE,.SETUP,.$SPACE,.$SWDOC,.STYPE,.$TRA
9      .MCALL .SWRMI,.$ERRTYP,.$TYPDS,.$TYPBIN,$OFISWR,$CKSWR
10     .MCALL .SRDOCT,$SIZE,$KT11,$DIV,$MULT,$SAVE,$SB2D,$DB2D
11     .MCALL .SACT11,$APTHDR,$APTBL,$APTYP
12     .TITLE CZNCCA NCV11 DIAGNOSTIC
13     ;*COPYRIGHT (C) 1978
14     ;*DIGITAL EQUIPMENT CORP.
15     ;*MAYNARD, MASS. 01754
16
17     ;*PROGRAM BY RAYMOND SHOOP
18
19     ;*THIS PROGRAM WAS ASSEMBLED USING THE PDP-11 MAINDEC SYSMAC
20     ;*PACKAGE (MAINDEC-11-DZQAC-C3), JAN 19, 1977.
21
22     .SBTTL BASIC DEFINITIONS
23
24     ;*INITIAL ADDRESS OF THE STACK POINTER *** 1100 ***
25     001100     STACK= 1100
26     .EQUIV EMT,ERROR      ;;BASIC DEFINITION OF ERROR CALL
27     .EQUIV IOT,SCOPE      ;;BASIC DEFINITION OF SCOPE CALL
28
29     ;*MISCELLANEOUS DEFINITIONS
30     000011     HT= 11      ;;CODE FOR HORIZONTAL TAB
31     000012     LF= 12      ;;CODE FOR LINE FEED
32     000015     CR= 15      ;;CODE FOR CARRIAGE RETURN
33     000200     CRLF= 200    ;;CODE FOR CARRIAGE RETURN-LINE FEED
34     177776     PS= 177776   ;;PROCESSOR STATUS WORD
35     .EQUIV PS,PSW
36     177774     STKLMT= 177774 ;;STACK LIMIT REGISTER
37     177772     PIRQ= 177772  ;;PROGRAM INTERRUPT REQUEST REGISTER
38     177570     DSWR= 177570  ;;HARDWARE SWITCH REGISTER
39     177570     DDISP= 177570 ;;HARDWARE DISPLAY REGISTER
40
41     ;*GENERAL PURPOSE REGISTER DEFINITIONS
42     000000     R0= %0      ;;GENERAL REGISTER
43     000001     R1= %1      ;;GENERAL REGISTER
44     000002     R2= %2      ;;GENERAL REGISTER
45     000003     R3= %3      ;;GENERAL REGISTER
46     000004     R4= %4      ;;GENERAL REGISTER
47     000005     R5= %5      ;;GENERAL REGISTER
48     000006     R6= %6      ;;GENERAL REGISTER
49     000007     R7= %7      ;;GENERAL REGISTER
50     000006     SP= %6      ;;STACK POINTER
51     000007     PC= %7      ;;PROGRAM COUNTER
52
53     ;*PRIORITY LEVEL DEFINITIONS
54     000000     PRO= 0      ;;PRIORITY LEVEL 0
55     000040     PR1= 40     ;;PRIORITY LEVEL 1
```

55	000100	PR2=	100	:::PRIORITY LEVEL 2
56	000140	PR3=	140	:::PRIORITY LEVEL 3
57	000200	PR4=	200	:::PRIORITY LEVEL 4
58	000240	PR5=	240	:::PRIORITY LEVEL 5
59	000300	PR6=	300	:::PRIORITY LEVEL 6
60	000340	PR7=	340	:::PRIORITY LEVEL 7

62 ;\*'SWITCH REGISTER'' SWITCH DEFINITIONS

63	100000	SW15=	100000
64	040000	SW14=	40000
65	020000	SW13=	20000
66	010000	SW12=	10000
67	004000	SW11=	4000
68	002000	SW10=	2000
69	001000	SW09=	1000
70	000400	SW08=	400
71	000200	SW07=	200
72	000100	SW06=	100
73	000040	SW05=	40
74	000020	SW04=	20
75	000010	SW03=	10
76	000004	SW02=	4
77	000002	SW01=	2
78	000001	SW00=	1
79		.EQUIV	SW09,SW9
80		.EQUIV	SW08,SW8
81		.EQUIV	SW07,SW7
82		.EQUIV	SW06,SW6
83		.EQUIV	SW05,SW5
84		.EQUIV	SW04,SW4
85		.EQUIV	SW03,SW3
86		.EQUIV	SW02,SW2
87		.EQUIV	SW01,SW1
88		.EQUIV	SW00,SW0

90 ;\*DATA BIT DEFINITIONS (BIT00 TO BIT15)

91	100000	BIT15=	100000
92	040000	BIT14=	40000
93	020000	BIT13=	20000
94	010000	BIT12=	10000
95	004000	BIT11=	4000
96	002000	BIT10=	2000
97	001000	BIT09=	1000
98	000400	BIT08=	400
99	000200	BIT07=	200
100	000100	BIT06=	100
101	000040	BIT05=	40
102	000020	BIT04=	20
103	000010	BIT03=	10
104	000004	BIT02=	4
105	000002	BIT01=	2
106	000001	BIT00=	1
107		.EQUIV	BIT09,BIT9
108		.EQUIV	BIT08,BIT8

```
109 .EQUIV BIT07,BIT7
110 .EQUIV BIT06,BIT6
111 .EQUIV BIT05,BIT5
112 .EQUIV BIT04,BIT4
113 .EQUIV BIT03,BIT3
114 .EQUIV BIT02,BIT2
115 .EQUIV BIT01,BIT1
116 .EQUIV BIT00,BIT0
117
118 ;*BASIC 'CPU' TRAP VECTOR ADDRESSES
119 000004 ERRVEC= 4 ;:TIME OUT AND OTHER ERRORS
120 000010 RESVEC= 10 ;:RESERVED AND ILLEGAL INSTRUCTIONS
121 000014 TBITVEC=14 ;:'T' BIT
122 000014 TRTVEC= 14 ;:TRACE TRAP
123 000014 BPTVEC= 14 ;:BREAKPOINT TRAP (BPT)
124 000020 IOTVEC= 20 ;:INPUT/OUTPUT TRAP (IOT) **SCOPE**
125 000024 PWRVEC= 24 ;:POWER FAIL
126 000030 EMTVEC= 30 ;:EMULATOR TRAP (EMT) **ERROR**
127 000034 TRAPVEC=34 ;:'TRAP' TRAP
128 000060 TKVEC= 60 ;:TTY KEYBOARD VECTOR
129 000064 TPVEC= 64 ;:TTY PRINTER VECTOR
130 000240 PIRQVEC=240 ;:PROGRAM INTERRUPT REQUEST VECTOR
131
132 ;SBTTL MEMORY MANAGEMENT DEFINITIONS
133
134 ;*KT11 VECTOR ADDRESS
135 000250 MMVEC= 250
136
137 ;*KT11 STATUS REGISTER ADDRESSES
138
139 177572 SR0= 177572
140 177574 SR1= 177574
141 177576 SR2= 177576
142 172516 SR3= 172516
143
144 ;*USER 'I' PAGE DESCRIPTOR REGISTERS
145
146 177600 UIPDR0= 177600
147 177602 UIPDR1= 177602
148 177604 UIPDR2= 177604
149 177606 UIPDR3= 177606
150 177610 UIPDR4= 177610
151 177612 UIPDR5= 177612
152 177614 UIPDR6= 177614
153 177616 UIPDR7= 177616
154
155 ;*USER 'D' PAGE DESCRIPTOR REGISTORS
156
157 177620 UDPDR0= 177620
158 177622 UDPDR1= 177622
159 177624 UDPDR2= 177624
160 177626 UDPDR3= 177626
161 177630 UDPDR4= 177630
162 177632 UDPDR5= 177632
```



163	177634	UDPDR6= 177634
164	177636	UDPDR7= 177636
165		
166		;*USER 'I' PAGE ADDRESS REGISTERS
167		
168	177640	UIPAR0= 177640
169	177642	UIPAR1= 177642
170	177644	UIPAR2= 177644
171	177646	UIPAR3= 177646
172	177650	UIPAR4= 177650
173	177652	UIPAR5= 177652
174	177654	UIPAR6= 177654
175	177656	UIPAR7= 177656
176		
177		;*USER 'D' PAGE ADDRESS REGISTERS
178		
179	177660	UDPAR0= 177660
180	177662	UDPAR1= 177662
181	177664	UDPAR2= 177664
182	177666	UDPAR3= 177666
183	177670	UDPAR4= 177670
184	177672	UDPAR5= 177672
185	177674	UDPAR6= 177674
186	177676	UDPAR7= 177676
187		
188		;*SUPERVISOR 'I' PAGE DESCRIPTOR REGISTERS
189		
190	172200	SIPDR0= 172200
191	172202	SIPDR1= 172202
192	172204	SIPDR2= 172204
193	172206	SIPDR3= 172206
194	172210	SIPDR4= 172210
195	172212	SIPDR5= 172212
196	172214	SIPDR6= 172214
197	172216	SIPDR7= 172216
198		
199		;*SUPERVISOR 'D' PAGE DESCRIPTOR REGISTERS
200		
201	172220	SDPDR0= 172220
202	172222	SDPDR1= 172222
203	172224	SDPDR2= 172224
204	172226	SDPDR3= 172226
205	172230	SDPDR4= 172230
206	172232	SDPDR5= 172232
207	172234	SDPDR6= 172234
208	172236	SDPDR7= 172236
209		
210		;*SUPERVISOR 'I' PAGE ADDRESS REGISTERS
211		
212	172240	SIPAR0= 172240
213	172242	SIPAR1= 172242
214	172244	SIPAR2= 172244
215	172246	SIPAR3= 172246
216	172250	SIPAR4= 172250

217	172252	SIPAR5= 172252
218	172254	SIPAR6= 172254
219	172256	SIPAR7= 172256
220		
221		;*SUPERVISOR 'D' PAGE ADDRESS REGISTERS
222		
223	172260	SDPAR0= 172260
224	172262	SDPAR1= 172262
225	172264	SDPAR2= 172264
226	172266	SDPAR3= 172266
227	172270	SDPAR4= 172270
228	172272	SDPAR5= 172272
229	172274	SDPAR6= 172274
230	172276	SDPAR7= 172276
231		
232		;*KERNEL 'I' PAGE DESCRIPTOR REGISTERS
233		
234	172300	KIPDR0= 172300
235	172302	KIPDR1= 172302
236	172304	KIPDR2= 172304
237	172306	KIPDR3= 172306
238	172310	KIPDR4= 172310
239	172312	KIPDR5= 172312
240	172314	KIPDR6= 172314
241	172316	KIPDR7= 172316
242		
243		;*KERNEL 'D' PAGE DESCRIPTOR REGISTERS
244		
245	172320	KDPDR0= 172320
246	172322	KDPDR1= 172322
247	172324	KDPDR2= 172324
248	172326	KDPDR3= 172326
249	172330	KDPDR4= 172330
250	172332	KDPDR5= 172332
251	172334	KDPDR6= 172334
252	172336	KDPDR7= 172336
253		
254		;*KERNEL 'I' PAGE ADDRESS REGISTERS
255		
256	172340	KIPAR0= 172340
257	172342	KIPAR1= 172342
258	172344	KIPAR2= 172344
259	172346	KIPAR3= 172346
260	172350	KIPAR4= 172350
261	172352	KIPAR5= 172352
262	172354	KIPAR6= 172354
263	172356	KIPAR7= 172356
264		
265		;*KERNEL 'D' PAGE ADDRESS REGISTERS
266		
267	172360	KDPAR0= 172360
268	172362	KDPAR1= 172362
269	172364	KDPAR2= 172364
270	172366	KDPAR3= 172366

271 172370 KDPAR4= 172370  
272 172372 KDPAR5= 172372  
273 172374 KDPAR6= 172374  
274 172376 KDPAR7= 172376

275  
276  
277 172760 ABASE=172760 ;NCV11 BASE ADDRESS  
278 140370 AVECT1=140370 ;BR LEVEL 6 VECTOR TO 370  
279 170420 ACDW1=170420 ;NCV11 CLOCK ADDRESS

```

280
281      .SBTTL OPERATIONAL SWITCH SETTINGS
282      : *
283      : *      SWITCH              USE
284      : *      -----
285      : *      15              HALT ON ERROR
286      : *      14              LOOP ON TEST
287      : *      13              INHIBIT ERROR TYPEOUTS
288      : *      11              INHIBIT ITERATIONS
289      : *      10              BELL ON ERROR
290      : *      9              LOOP ON ERROR
291      : *      8              LOOP ON TEST IN SWR<7:0>
292      .SBTTL TRAP CATCHER
293
294      000000      .=0
295      ; *ALL UNUSED LOCATIONS FROM 4 - 776 CONTAIN A '+2,HALT'
296      ; *SEQUENCE TO CATCH ILLEGAL TRAPS AND INTERRUPTS
297      ; *LOCATION 0 CONTAINS 0 TO CATCH IMPROPERLY LOADED VECTORS
298      00C174      .=174
299      000174      000000      DISPREG: .WORD 0      ;;SOFTWARE DISPLAY REGISTER
300      000176      000000      SWREG: .WORD 0      ;;SOFTWARE SWITCH REGISTER
301      .SBTTL STARTING ADDRESS(ES)
302      000200      000137      002032      JMP @BEGIN ;;JUMP TO STARTING ADDRESS OF PROGRAM
303      000204      000137      002012      JMP RTRT      ;RESTART ADDRESS
304      000210      000137      002020      JMP TESTER      ;STARTING ADDRESS WHEN IN THE OPTION AREA
305
306      000100      000100
307      000100      000104      000200      000002      .-100
307      104,200,2      ;B EVENT SAFE GUARD
  
```

```

308          .SBTTL ACT11 HOOKS
309
310          ;*****
311          ;HOOKS REQUIRED BY ACT11
312          $SVPC=          ;SAVE PC
313          .-46
314 000046  $ENDAD          ;;1)SET LOC.46 TO ADDRESS OF $ENDAD IN .$EOP
315          .=52
316 000052  .WORD 0          ;;2)SET LOC.52 TO ZERO
317          .= $SVPC        ;; RESTORE PC
318          .=1000
319          .SBTTL APT PARAMETER BLOCK
320
321          ;*****
322          ;SET LOCATIONS 24 AND 44 AS REQUIRED FOR APT
323          ;*****
324          .$X=          ;;SAVE CURRENT LOCATION
325          .=24          ;;SET POWER FAIL TO POINT TO START OF PROGRAM
326 000024  200          ;;FOR APT START UP
327          .-44          ;;POINT TO APT INDIRECT ADDRESS PNTR.
328 000044  $APTHDR      ;;POINT TO APT HEADER BLOCK
329          .=.$X        ;;RESET LOCATION COUNTER
330          ;*****
331          ;SETUP APT PARAMETER BLOCK AS DEFINED IN THE APT-PDP11 DIAGNOSTIC
332          ;INTERFACE SPEC.
333
334 001000  $APTHD:
335 001000  000000  $HIBTS: .WORD 0          ;;TWO HIGH BITS OF 18 BIT MAILBOX ADDR.
336 001002  001174  $MBADR: .WORD $MAIL      ;;ADDRESS OF APT MAILBOX (BITS 0-15)
337 001004  000030  $STMT: .WORD 30          ;;RUN TIM OF LONGEST TEST
338 001006  000010  $PASTM: .WORD 10         ;;RUN TIME IN SECS. OF 1ST PASS ON 1 UNIT (QUICK VERIFY)
339 001010  000030  $UNITM: .WORD 30         ;;ADDITIONAL RUN TIME (SECS) OF A PASS FOR EACH ADDITIONAL UNIT
340 001012  000031  .WORD $ETEND-$MAIL/2 ;;LENGTH MAILBOX-ETABLE(WORDS)

```

```

341          .SBTTL  COMMON TAGS
342
343          ;:*****
344          ;*THIS TABLE CONTAINS VARIOUS COMMON STORAGE LOCATIONS
345          ;*USED IN THE PROGRAM.
346
347          001100          .=1100
348 001100 001100          $CMTAG:          ;;START OF COMMON TAGS
349 001100 000000          .WORD          0          ;;CONTAINS THE TEST NUMBER
350 001102 000          $TSTNM: .BYTE          0          ;;CONTAINS ERROR FLAG
351 001103 000          $ERFLG: .BYTE          0          ;;CONTAINS SUBTEST ITERATION COUNT
352 001104 000000          $ICNT:  .WORD          0          ;;CONTAINS SCOPE LOOP ADDRESS
353 001106 000000          $LPADR: .WORD          0          ;;CONTAINS SCOPE RETURN FOR ERRORS
354 001110 000000          $LPERR: .WORD          0          ;;CONTAINS TOTAL ERRORS DETECTED
355 001112 000000          $ERTTL: .WORD          0          ;;CONTAINS ITEM CONTROL BYTE
356 001114 000          $ITEMB: .BYTE          0          ;;CONTAINS MAX. ERRORS PER TEST
357 001115 001          $ERMAX: .BYTE          1          ;;CONTAINS PC OF LAST ERROR INSTRUCTION
358 001116 000000          $ERRPC: .WORD          0          ;;CONTAINS ADDRESS OF 'GOOD' DATA
359 001120 000000          $GDADR: .WORD          0          ;;CONTAINS ADDRESS OF 'BAD' DATA
360 001122 000000          $BDADR: .WORD          0          ;;CONTAINS 'GOOD' DATA
361 001124 000000          $GDDAT: .WORD          0          ;;CONTAINS 'BAD' DATA
362 001126 000000          $BDDAT: .WORD          0          ;;RESERVED--NOT TO BE USED
363 001130 000000          .WORD          0
364 001132 000000          .WORD          0
365 001134 000          $AUTOB: .BYTE          0          ;;AUTOMATIC MODE INDICATOR
366 001135 000          $INTAG: .BYTE          0          ;;INTERRUPT MODE INDICATOR
367 001136 000000          .WORD          0
368 001140 177570          SWR:          .WORD          DSWR          ;;ADDRESS OF SWITCH REGISTER
369 001142 177570          DISPLAY: .WORD          DDISP          ;;ADDRESS OF DISPLAY REGISTER
370 001144 177560          $TKS:          177560          ;;TTY KBD STATUS
371 001146 177562          $TKB:          177562          ;;TTY KBD BUFFER
372 001150 177564          $TPS:          177564          ;;TTY PRINTER STATUS REG. ADDRESS
373 001152 177566          $TPB:          177566          ;;TTY PRINTER BUFFER REG. ADDRESS
374 001154 000          $NULL:  .BYTE          0          ;;CONTAINS NULL CHARACTER FOR FILLS
375 001155 002          $FILLS: .BYTE          2          ;;CONTAINS # OF FILLER CHARACTERS REQUIRED
376 001156 012          $FILLC: .BYTE          12          ;;INSERT FILL CHARS. AFTER A 'LINE FEED'
377 001157 000          $TPFLG: .BYTE          0          ;;'TERMINAL AVAILABLE' FLAG (BIT<07>=0-YES)
378 001160 000000          $TIMES: 0          ;;MAX. NUMBER OF ITERATIONS
379 001162 000000          $ESCAPE: 0          ;;ESCAPE ON ERROR ADDRESS
380 001164 177607 000377          $BELL:  .ASCIZ  <207><377><377>          ;;CODE FOR BELL
381 001170 077          $QUES:  .ASCII  /?/          ;;QUESTION MARK
382 001171 015          $CRLF:  .ASCII  <15>          ;;CARRIAGE RETURN
383 001172 000012          $LF:    .ASCIZ  <12>          ;;LINE FEED
384          ;:*****
385          .SBTTL  APT MAILBOX-ETABLE
386
387          ;:*****
388          .EVEN
389 001174          $MAIL:          ;;APT MAILBOX
390 001174 000000          $MSGTY: .WORD          AMSGTY          ;;MESSAGE TYPE CODE
391 001176 000000          $FATAL: .WORD          AFATAL          ;;FATAL ERROR NUMBER
392 001200 000000          $TESTN: .WORD          ATESTN          ;;TEST NUMBER
393 001202 000000          $PASS:  .WORD          APASS          ;;PASS COUNT
394 001204 000000          $DEVCT: .WORD          ADEVCT          ;;DEVICE COUNT

```

395	001206	000000	\$UNIT: .WORD	AUNIT	:: I/O UNIT NUMBER
396	001210	000000	\$MSGAD: .WORD	AMSGAD	:: MESSAGE ADDRESS
397	001212	000000	\$MSGLG: .WORD	AMSGLG	:: MESSAGE LENGTH
398	001214		\$ETABLE:		:: APT ENVIRONMENT TABLE
399	001214	000	\$ENV: .BYTE	AENV	:: ENVIRONMENT BYTE
400	001215	000	\$ENVM: .BYTE	AENVM	:: ENVIRONMENT MODE BITS
401	001216	000000	\$SWREG: .WORD	ASWREG	:: APT SWITCH REGISTER
402	001220	000000	\$USWR: .WORD	AUSWR	:: USER SWITCHES
403	001222	000000	\$CPUOP: .WORD	ACPUOP	:: CPU TYPE, OPTIONS
404			*		BITS 15-11=CPU TYPE
405			*		11/04=01, 11/05=02, 11/20=03, 11/40=04, 11/45=05
406			*		11/70=06, PDQ=07, Q=10
407			*		BIT 10=REAL TIME CLOCK
408			*		BIT 9=FLOATING POINT PROCESSOR
409			*		BIT 8=MEMORY MANAGEMENT
410	001224	000	\$MAMS1: .BYTE	AMAMS1	:: HIGH ADDRESS, M.S. BYTE
411	001225	000	\$MTYP1: .BYTE	AMTYP1	:: MEM. TYPE, BLK#1
412			*		MEM. TYPE BYTE -- (HIGH BYTE)
413			*		900 NSEC CORE=001
414			*		300 NSEC BIPOLAR=002
415			*		500 NSEC MOS=003
416	001226	000000	\$MADR1: .WORD	AMADR1	:: HIGH ADDRESS, BLK#1
417			*		MEM. LAST ADDR.=3 BYTES, THIS WORD AND LOW OF 'TYPE' ABOVE
418	001230	000	\$MAMS2: .BYTE	AMAMS2	:: HIGH ADDRESS, M.S. BYTE
419	001231	000	\$MTYP2: .BYTE	AMTYP2	:: MEM. TYPE, BLK#2
420	001232	000000	\$MADR2: .WORD	AMADR2	:: MEM. LAST ADDRESS, BLK#2
421	001234	000	\$MAMS3: .BYTE	AMAMS3	:: HIGH ADDRESS, M.S. BYTE
422	001235	000	\$MTYP3: .BYTE	AMTYP3	:: MEM. TYPE, BLK#3
423	001236	000000	\$MADR3: .WORD	AMADR3	:: MEM. LAST ADDRESS, BLK#3
424	001240	000	\$MAMS4: .BYTE	AMAMS4	:: HIGH ADDRESS, M.S. BYTE
425	001241	000	\$MTYP4: .BYTE	AMTYP4	:: MEM. TYPE, BLK#4
426	001242	000000	\$MADR4: .WORD	AMADR4	:: MEM. LAST ADDRESS, BLK#4
427	001244	140370	\$VECT1: .WORD	AVECT1	:: INTERRUPT VECTOR#1, BUS PRIORITY#1
428	001246	000000	\$VECT2: .WORD	AVECT2	:: INTERRUPT VECTOR#2, BUS PRIORITY#2
429	001250	172760	\$BASE: .WORD	ABASE	:: BASE ADDRESS OF EQUIPMENT UNDER TEST
430	001252	000000	\$DEVN: .WORD	ADEVN	:: DEVICE MAP
431	001254	170420	\$CDW1: .WORD	ACDW1	:: CONTROLLER DESCRIPTION WORD#1
432	001256		\$ETEND:		
433			.MEXIT		

```

434      .SBTTL  ERROR POINTER TABLE
435
436      :: THIS TABLE CONTAINS THE INFORMATION FOR EACH ERROR THAT CAN OCCUR.
437      :: THE INFORMATION IS OBTAINED BY USING THE INDEX NUMBER FOUND IN
438      :: LOCATION $ITEMB. THIS NUMBER INDICATES WHICH ITEM IN THE TABLE IS PERTINENT.
439      :: NOT1:      IF $ITEMB IS 0 THE ONLY PERTINENT DATA IS ($ERRPC).
440      :: NOT2:      EACH ITEM IN THE TABLE CONTAINS 4 POINTERS EXPLAINED AS FOLLOWS:
441
442      :*      EM      ;;POINTS TO THE ERROR MESSAGE
443      :*      DH      ;;POINTS TO THE DATA HEADER
444      :*      DT      ;;POINTS TO THE DATA
445      :*      DF      ;;POINTS TO THE DATA FORMAT
446
447
448      $ERRTB:
449      001256 030220 032500 032730 E.11,DH2,DT2,DF0 ;M8026 NCV11 TIMEOUT
450      001264 033002
451      001266 030260 032500 032730 EM1,DH2,DT2,DF0 ;M8026 COMMAND-STATUS REGISTER ERROR
452      001274 033002
453      001276 030324 032500 032730 EM3,DH2,DT2,DF0 ;M8026 SPECIAL FUNCTION REGISTER ERROR
454      001304 033002
455      001306 030372 032500 032730 EM4,DH2,DT2,DF0 ;M8026 WORD COUNT REGISTER ERROR
456      001314 033002
457      001316 030432 032500 032730 EM5,DH2,DT2,DF0 ;M8026 BUS ADDRESS REGISTER ERROR
458      001324 033002
459      001326 030473 032500 032730 EM6,DH2,DT2,DF0 ;M8026 OFFSET REGISTER ERROR
460      001334 033002
461      001336 030527 032500 032730 EM7,DH2,DT2,DF0 ;M8026 DUAL REGISTER SELECTION ERROR
462      001344 033002
463      001346 030573 032500 032730 EM10,DH2,DT2,DF0 ;M8026-M8036 LOW 16 BIT Z COUNT ERROR
464      001354 033002
465      001356 030640 032500 032730 EM11,DH2,DT2,DF0 ;M8026-M8036 HIGH 16 BIT Z COUNT ERROR
466      001364 033002
467      001366 030706 032500 032730 EM12,DH2,DT2,DF0 ;M8026 Z COUNT STATUS ERROR
468      001374 033002
469      001376 030741 032500 032730 EM13,DH2,DT2,DF0 ;M8026 Z COUNT INTERRUPT ERROR
470      001404 033002
471      001406 030777 032500 032730 EM14,DH2,DT2,DF0 ;M8036 JOYSTICK STATUS ERROR
472      001414 033002
473      001416 031033 032500 032730 EM15,DH2,DT2,DF0 ;M8036 JOYSTICK DATA ERROR
474      001424 033002
475      001426 031065 032500 032730 EM16,DH2,DT2,DF0 ;M8036 DATA INCREMENT ERROR
476      001434 033002
477      001436 031120 032500 032730 EM17,DH2,DT2,DF0 ;M8036 DATA DECREMENT ERROR
478      001444 033002
479      001446 031153 032500 032730 EM20,DH2,DT2,DF0 ;M8026-M8036 MATRIX MODE ADDRESS MAKER DATA ERROR
480      001454 033002
481      001456 031234 032500 032730 EM21,DH2,DT2,DF0 ;M8026 LIST MODE ADDRESS MAKER DATA ERROR
482      001464 033002
483      001466 031305 032500 032730 EM22,DH2,DT2,DF0 ;M8026 LIST MODE TRANSFER BUS ADDRESS ERROR
484      001474 033002
485      001476 031360 032500 032730 EM23,DH2,DT2,DF0 ;M8026 LIST MODE TRANSFER WORD COUNT ERROR
486      001504 033002
487      001506 031432 032500 032730 EM24,DH2,DT2,DF0 ;M8026 LIST MODE TRANSFER OFFSET ERROR

```



488	001514	033002			EM25,DH2,DT2,DF0	:M8026	TIMEOUT STATUS ERROR
489	001516	031500	032500	032730			
490	001524	033002					
491	001526	031533	032500	032730	EM26,DH2,DT2,DF0	:M8026	TIMEOUT INTERRUPT ERROR
492	001534	033002					
493	001536	031571	032500	032730	EM27,DH2,DT2,DF0	:M8026	SET 'EVENT' OR 'TIME' DATA ERROR
494	001544	033002					
495	001546	031640	032500	032730	EM30,DH2,DT2,DF0	:M8026	CELL INCREMENT DATA ERROR
496	001554	033002					
497	001556	031700	032500	032730	EM31,DH2,DT2,DF0	:M8026	CELL OVERFLOW STATUS ERROR
498	001564	033002					
499	001566	031741	032500	032730	EM32,DH2,DT2,DF0	:M8026	CELL OVERFLOW INTERRUPT ERROR
500	001574	033002					
501	001576	032005	032524	032742	EM33,DH3,DT3,DF0	:M8026	MATRIX MODE ADDRESS MUX ERROR
502	001604	033002					
503	001606	032051	032500	032730	EM34,DH2,DT2,DF0	:M8026	'TESTX' FUNCTION ERROR
504	001614	033002					
505	001616	032106	032557	032756	EM35,DH4,DT4,DF0	:M8026	DATA ERROR WHEN TRANSFERRING TO EXTENDED MEMORY
506	001624	033002					
507	001626	032173	032500	032730	EM36,DH2,DT2,DF0	:M8026	LIST MODE TRANSFER STATUS ERROR
508	001634	033002					
509	001636	032241	032524	032742	EM37,DH3,DT3,DF0	:M8026	LIST MODE TRANSFER DATA ERROR
510	001644	033002					
511	001646	032305	032500	032730	EM40,DH2,DT2,DF0	:JUMPER-M8026-M7952	'EVENT' OR 'TIME' MARK ERROR
512	001654	033002					
513	001656	032365	032465	032774	EM41,DH1,DT5,DF0	:M7952	CLOCK TIMEOUT
514	001664	033002					
515	001666	032425	032465	032722	EM42,DH1,DT1,DF0	:M8217	INTERRUPT LEVEL ERROR
516	001674	033002					
517					:DL11 BLASTER COMM. ADDRESSES (THE OPERATOR MUST CHANGE IF DIFFERENT)		
518	001676	176510			DLICSR: 176510	:	INPUT STATUS REG.
519	001700	176512			DLIBD: 176512	:	INPUT DATA
520	001702	176514			DLOCSR: 176514	:	OUTPUT STATUS
521	001704	176516			DLODB: 176516	:	OUTPUT DATA
522							
523					:VSV01 ADDRESSES (THE OPERATOR MUST CHANGE IF DIFFERENT)		
524	001706	172600			VTCHAR: 172600	:	CHAR. STATUS
525	001710	172602			VTYPOS: 172602		
526	001712	172603			VTXPOS: 172603		
527	001714	172604			VTCXY: 172604		
528	001716	172620			VTCSR: 172620	:	MAP STATUS
529	001720	172622			VTMAP: 172622		
530	001722	172624			VTPX: 172624		
531	001724	172630			VTINT: 172630		
532							
533					:TESTER ADDRESSES (THE OPERATOR MUST CHANGE IF DIFFERENT)		
534	001726	176416			DACSR: 176416	:	KNOWN GOOD D/A STATUS
535	001730	176420			DACO: 176420		
536	001732	176422			DAC1: 176422		
537	001734	176424			DAC2: 176424		
538	001736	176426			DAC3: 176426		

```

539 ;KVV11 PROGRAM GENERATED ADDRESSES (THE OPER. ONLY HAS TO CHANGE '$CDW1')
540
541 001740 170420 KWCSR: ACDW1 ;KVV11 STATUS REGISTER
542 001742 170421 KWCSR1: ACDW1+1 ;KVV11 STATUS REG. HIGH BYTE
543 001744 170422 KWPSR: ACDW1+2 ;KVV11 PRESET REGISTER
544
545 ;NCV11 PROGRAM GENERATER ADDRESSES (THE OPER. ONLY HAS TO CHANGE '$BASE')
546
547 001746 172760 CSR: ABASE
548 001750 172762 OFF: ABASE+2
549 001752 172764 WCR: ABASE+4
550 001754 172766 BAR: ABASE+6
551 001756 172770 SFR: ABASE+10
552 001760 172772 ADM: ABASE+12
553 001762 172774 JOY: ABASE+14
554 001764 172776 BAR1: ABASE+16
555 001766 172761 CSRHB: ABASE+1
556 001770 172771 SFRHB: ABASE+11
557
558 ;NCV11 PROGRAM GENERATED VECTORS (THE OPER. ONLY HAS TO CHANGE LOW 9 BITS OF '$VECT1')
559
560 001772 140370 VECTA0: AVECT1
561 001774 140372 VECTA1: AVECT1+2
562 001776 140374 VECTB0: AVECT1+4
563 002000 140376 VECTB1: AVECT1+6
564
565 ;NCV11 PROGRAM GENERATED BR LEVEL (THE OPER. ONLY HAS TO CHANGE TOP 3 BITS OF '$VECT1')
566
567 002002 000300 BRLEV: 300 ;BR LEVEL 6
568
569 002004 000000 $TEMP: 0
570 002006 000001 CPUDLO: 1
571 002010 000020 CPUDL1: 20
572
573 040000 CLRWCO=BIT14
574 004000 CLRALL=BIT11
575 000400 ENDDMA=BIT8
576 000010 TSTDMA=BIT3
577 000004 TSTCON=BIT2
578 000002 TFSTZ=BIT1
579 000001 REDJOY=BIT0
580 000000 MORTST 0 ;DEFINE TO RESTORE TEST CODE
581

```

```

582 002012 005237 050116      RTRT:  INC      AGAN      ;SET RESTART FLAG
583 002016 000411              BR      RTRTA
584 002020 005237 050110      TESTER: INC      WFMODE   ;SET FLAG INDICATING OPTION AREA MODE
585 002024 005037 050116      CLR      AGAN
586 002030 000404              BR      RTRTA
587 002032 005037 050116      BEGIN:  CLR      AGAN
588 002036 005037 050110      CLR      WFMODE   ;CLEAR FLAG INDIC. OPTION TEST AREA MODE
589 002042
590
591      .SBTTL  INITIALIZE THE COMMON TAGS
      ;;CLEAR THE COMMON TAGS ($CMTAG) AREA
592 002042 012706 001100      MOV      # $CMTAG,R6    ;;FIRST LOCATION TO BE CLEARED
593 002046 005026      CLR      (R6)+         ;;CLEAR MEMORY LOCATION
594 002050 022706 001140      CMP      #SWR,R6      ;;DONE?
595 002054 001374      BNE      .-6           ;;LOOP BACK IF NO
596 002056 012706 001100      MOV      #STACK,SP    ;;SETUP THE STACK POINTER
597      ;;INITIALIZE A FEW VECTORS
598 002062 012737 034106 000020  MOV      # $SCOPE,@IOTVEC ;;IOT VECTOR FOR SCOPE ROUTINE
599 002070 012737 000340 000022  MOV      #340,@IOTVEC+2 ;;LEVEL 7
600 002076 012737 035102 000030  MOV      # $ERROR,@EMTVEC ;;EMT VECTOR FOR ERROR ROUTINE
601 002104 012737 000340 000032  MOV      #340,@EMTVEC+2 ;;LEVEL 7
602 002112 012737 037266 000034  MOV      # $TRAP,@TRAPVEC ;;TRAP VECTOR FOR TRAP CALLS
603 002120 012737 000340 000036  MOV      #340,@TRAPVEC+2;LEVEL 7
604 002126 012737 035704 000024  MOV      # $PWRDN,@PWRVEC ;;POWER FAILURE VECTOR
605 002134 012737 000340 000026  MOV      #340,@PWRVEC+2 ;;LEVEL 7
606 002142 013737 030132 030124  MOV      $ENDCT,$EOPCT ;;SETUP END-OF-PROGRAM COUNTER
607 002150 005037 001160      CLR      $TIMES       ;;INITIALIZE NUMBER OF ITERATIONS
608 002154 005037 001162      CLR      $ESCAPE     ;;CLEAR THE ESCAPE ON ERROR ADDRESS
609 002160 112737 000001 001115  MOVB     #1,$ERMAX    ;;ALLOW ONE ERROR PER TEST
610 002166 012737 002166 001106  MOV      #.,$SLPADR   ;;INITIALIZE THE LOOP ADDRESS FOR SCOPE
611 002174 012737 002174 001110  MOV      #.,$SLPERR   ;;SETUP THE ERROR LOOP ADDRESS
612      ;;SIZE FOR A HARDWARE SWITCH REGISTER. IF NOT FOUND OR IT IS
613      ;;EQUAL TO A "-1", SETUP FOR A SOFTWARE SWITCH REGISTER.
614 002202 013746 000004      MOV      @ERRVEC,-(SP) ;;SAVE ERROR VECTOR
615 002206 012737 002242 000004  MOV      #64$,@ERRVEC  ;;SET UP ERROR VECTOR
616 002214 012737 177570 001140  MOV      #DSWR,SWR    ;;SETUP FOR A HARDWARE SWICH REGISTER
617 002222 012737 177570 001142  MOV      #DDISP,DISPLAY ;;AND A HARDWARE DISPLAY REGISTER
618 002230 022777 177777 176702  CMP      #-1,@SWR    ;;TRY TO REFERENCE HARDWARE SWR
619 002236 001012      BNE     66$         ;;BRANCH IF NO TIMEOUT TRAP OCCURRED
620      ;;AND THE HARDWARE SWR IS NOT -1
621 002240 000403      BR     65$         ;;BRANCH IF NO TIMEOUT
622 002242 012716 002250      64$:  MOV      #65$, (SP) ;;SET UP FOR TRAP RETURN
623 002246 000002
624 002250 012737 000176 001140  65$:  MOV      #SWREG,SWR  ;;POINT TO SOFTWARE SWR
625 002256 012737 000174 001142  MOV      #DISPREG,DISPLAY
626 002264 012637 000004      66$:  MOV      (SP)+,@ERRVEC ;;RESTORE ERROR VECTOR
627
628 002270 005037 001202      CLR     $PASS       ;;CLEAR PASS COUNT
629 002274 132737 000200 001215  BITB    #APTSIZE,$ENVM ;;TEST USER SIZE UNDER APT
630 002302 001403      BEQ    67$         ;;YES,USE NON-APT SWITCH
631 002304 012737 001216 001140  MOV     # $SWREG,SWR ;;NO,USE APT SWITCH REGISTER
632 002312      67$:

```

```

633 .SBTTL TYPE PROGRAM NAME
634 ;;TYPE THE NAME OF THE PROGRAM IF FIRST PASS
635 002312 005227 177777 INC #-1 ;;FIRST TIME?
636 002316 001044 BNE 68$ ;;BRANCH IF NO
637 002320 022737 030164 000042 CMP #SENDAD,@#42 ;;ACT-11?
638 002326 001440 BEQ 68$ ;;BRANCH IF YES
639 002330 104401 002376 TYPE ,69$ ;;TYPE ASCIZ STRING
640 .SBTTL GET VALUE FOR SOFTWARE SWITCH REGISTER
641 002334 005737 000042 TST @#42 ;;ARE WE RUNNING UNDER XXDP/ACT?
642 002340 001012 BNE 70$ ;;BRANCH IF YES
643 002342 123727 001214 000001 CMPB $ENV,#1 ;;ARE WE RUNNING UNDER APT?
644 002350 001406 BEQ 70$ ;;BRANCH IF YES
645 002352 023727 001140 000176 CMP SWR,#SWREG ;;SOFTWARE SWITCH REG SELECTED?
646 002360 001005 BNE 71$ ;;BRANCH IF NO
647 002362 104406 GTSWR ;;GET SOFT-SWR SETTINGS
648 002364 000403 BR 71$
649 002366 112737 000001 001134 70$: MOVB #1,$AUTOB ;;SET AUTO-MODE INDICATOR
650 002374 71$:
651 002374 000415 BR 68$ ;;GET OVER THE ASCIZ
652 ;;69$: .ASCIZ <CRLF>#CZNCCA NCV11 DIAGNOSTIC#<CRLF>
653 002430 68$:
654 .SBTTL PRIME THE NCV11 ADDRESSES FROM THE DEFAULT VALUES
655 002430 112737 000103 052474 MOVB #'C,RUNIT ;:LOAD "CONTROL" SECTION BUS TRAP FLAG
656 002436 012737 003210 000004 MOV #BUSTRP,@#ERRVEC ;:LOAD BUS TRAP RETURN ADDRESS
657 002444 012700 001746 MOV #CSR,R0 ;:GET ADDRESS POINTER
658 002450 013701 001250 MOV $BASE,R1 ;:GET DEFAULT ADDRESS
659 002454 010120 1$: MOV R1,(R0)+ ;:LOAD AN VALUE
660 002456 062701 000002 ADD #2,R1 ;:BUMP THE VALUE
661 002462 022700 001766 CMP #CSRHB,R0 ;:TEST IF DONE
662 002466 001372 BNE 1$ ;:BR IF NOT
663 002470 013710 001250 MOV $BASE,(R0) ;:LOAD ODD BYTE
664 002474 005220 INC (R0)+ ;:ADDRESSES
665 002476 013710 001250 MOV $BASE,(R0)
666 002502 062720 000011 ADD #11,(R0)+
667 002506 013701 001244 MOV $VECT1,R1 ;:GET DEFAULT VECTOR
668 002512 010102 MOV R1,R2 ;:COPY R1
669 002514 000302 SWAB R2 ;:EXCHANGE BYTES
670 002516 042702 177437 BIC #177437,R2 ;:STRIP OFF ALL BUT BR LEVEL BITS
671 002522 010237 002002 MOV R2,BRLEV ;:SAVE FOR USE LATER
672 002526 042701 160000 BIC #160000,R1 ;:CLEAR OFF BR LEVEL
673 002532 010120 2$: MOV R1,(R0)+ ;:LOAD VECTOR
674 002534 005721 TST (R1)+ ;:BUMP THE VALUE
675 002536 022700 002002 CMP #VECTB1+2,R0 ;:TEST IF DONE
676 002542 001373 BNE 2$
677 002544 013737 001254 001740 MOV $CDW1,KWCSR ;:GET CLOCK ADDRESS
678 002552 013737 001740 001742 MOV KWCSR,KWCSR1 ;:SET CLOCK HIGH BYTE ADDR.
679 002560 013737 001740 001744 MOV KWCSR,KWPSR ;:SET CLOCK PRESET ADDRESS
680 002566 005237 001742 INC KWCSR1
681 002572 062737 000002 001744 ADD #2,KWPSR

```

```

682 .SBTTL DIAGNOSTIC IDENTIFICATION TYPEOUT
683 002600 005737 050116 TST AGAN ;TEST IF RESTART
684 002604 001017 BNE RBEGO ;BR IF YES
685 002606 105737 001134 TSTB $AUTOB ;TEST IF ACT/APT
686 002612 001405 BEQ 3$ ;BR IF NOT
687 002614 012737 177777 050106 MOV #-1,RUNDIF ;INDICATE TO RUN DIFLIN IN CHAIN MODE
688 002622 000137 003356 JMP LOGIC ;YES; RUN LOGIC AND DIFLIN TESTS
689 002626 005737 050110 3$: TST WFMODE ;TEST IF OPTION CHECKOUT MODE
690 002632 001402 BEQ 4$ ;BR IF YES
691 002634 104401 TYPE
692 002636 046256 LISTO ;TELL OPERATOR ABOUT OPTION AREA TESTS
693 002640 104401 4$: TYPE
694 002642 046466 LIST ;TELL OPERATOR ABOUT THE TEST
695 .SBTTL KEYBOARD COMMAND DECODER
696 002644 104401 047101 RBEGO: TYPE, LIST1 ;PRINT 'DOT'
697 002650 104411 1$: RDLIN ;READ THE RESPONSE
698 002652 013637 052474 MOV @ (SP)+,RUNIT ;GET THE CHARACTER
699 002656 142737 000040 052474 BICB #40,RUNIT ;ENSURE UPPER CASE
700 002664 112737 000042 052475 MOVB #'',RUNIT+1 ;FIX ASCII MESSAGE
701 002672 122737 000101 052474 CMPB #'A',RUNIT ;DETERMINE IF AN A
702 002700 001002 BNE 2$ ;BR IF NOT
703 002702 000137 003276 JMP TFSITE ;RUN SITE ADJUSTMENT LOOP
704 002706 005737 050110 2$: TST WFMODE ;TEST IF ON THE TESTER
705 002712 001406 BEQ 3$ ;BR IF NOT
706 002714 122737 000102 052474 CMPB #'B',RUNIT ;DETERMINE IF AN B
707 002722 001002 BNE 3$ ;BR IF NOT
708 002724 000137 042322 JMP BLAST ;RUN THE BLASTER SECTION
709 002730 122737 000104 052474 3$: CMPB #'D',RUNIT ;DETERMINE IF AN D
710 002736 001004 BNE 4$ ;BR IF NOT
711 002740 005037 050106 CLR RUNDIF ;INDICATE DIFLIN IS NOT TO BE RUN
712 002744 000137 043712 JMP DIFLIN ;AND RUN IT
713 002750 122737 000106 052474 4$: CMPB #'F',RUNIT ;DETERMINE IF AN F
714 002756 001005 BNE 5$ ;BR IF NOT
715 002760 012737 177777 050106 MOV #-1,RUNDIF ;INDICATE RUN DIFLIN AFTER THE LOGIC TEST
716 002766 000137 003356 JMP LOGIC ;AND RUN LOGIC TEST
717 002772 005737 050110 5$: TST WFMODE ;TEST IF OPTION CHECKOUT MODE
718 002776 001406 BEQ 6$ ;BR IF NOT
719 003000 122737 000111 052474 CMPB #'I',RUNIT ;DETERMINE IF AN I
720 003006 001002 BNE 6$ ;BR IF NOT
721 003010 000137 047106 JMP POTIME ;RUN IN-HOUSE ADJUSTMENT LOOP
722 003014 122737 000114 052474 6$: CMPB #'L',RUNIT ;DETERMINE IF AN L
723 003022 001004 BNE 7$ ;BR IF NOT
724 003024 005037 050106 CLR RUNDIF ;INDICATE NO DIFLIN
725 003030 000137 003356 JMP LOGIC
726 003034 122737 000110 052474 7$: CMPB #'H',RUNIT ;DETERMINE IF AN H
727 003042 001002 BNE 10$ ;BR IF NOT
728 003044 000137 002032 JMP BEGIN ;START OVER
729 003050 122737 000037 052474 10$: CMPB #37,RUNIT ;DETERMINE IF AN '?'
730 003056 001002 BNE 11$ ;BR IF NOT
731 003060 000137 002032 JMP BEGIN ;START OVER
732 003064 005737 050110 11$: TST WFMODE ;TEST IF OPTION CHECKOUT MODE
733 003070 001406 BEQ 12$ ;BR IF NOT
734 003072 122737 000124 052474 CMPB #'T',RUNIT ;DETERMINE IF AN T
735 003100 001002 BNE 12$ ;BR IF NOT

```

```

736 003102 000137 042050      JMP      BTALK      ;KEYBOARD LOOP WITH BLASTER
737 003106 005737 050110      12$:    TST      WFMODE ;TEST IF OPTION CHECKOUT MODE
738 003112 001406                BEQ      13$        ;BR IF NOT
739 003114 122737 000103 052474    CMPB    #'C,RUNIT  ;DETERMINE IF AN C
740 003122 001002                BNE     13$        ;BR IF NOT
741 003124 000137 043004      JMP      PBLAST     ;RUN M8036 PROM BLASTING CODE
742 003130 122737 000117 052474    13$:    CMPB    #'O,RUNIT  ;DETERMINE IF AN O
743 003136 001002                BNE     14$        ;BR IF NOT
744 003140 000137 003240      JMP      XTTY       ;CHANGE THE TTY ADDRESS
745 003144 122737 000123 052474    14$:    CMPB    #'S,RUNIT  ;DETERMINE IF AN S
746 003152 001002                BNE     15$        ;BR IF NOT
747 003154 104406                GTSWR                    ;GET SWITCH REGISTER VALUE
748 003156 000632                BR      RBEGO       ;RESTART
749 003160 122737 000115 052474    15$:    CMPB    #'M,RUNIT  ;DETERMINE IF AN M
750 003166 001005                BNE     FATFNG      ;BR IF NOT
751 003170 012737 000377 050106    MOV     #377,RUNDIF ;INDICATE DIFLIN WITH EXPAND REPORT
752 003176 000137 043712      JMP      DIFLIN     ;RUN DIF LIN
  
```

```

753          ;THE OPERATOR SELECTED THE WRONG THING - THEY SOMETIME HAVE 'FAT FINGERS'
754 003202 104401 FATFNG: TYPE
755 003204 001170          $QUES          ;TYPE QUESTION MARK
756 003206 000616          BR          RBEGO
757
758
759          ;RETURN TO HERE UPON UNEXPECTED BUS TRAP
760 003210 104401 052424 BUSTRP: TYPE, FATALO          ;REPORT FATAL TRAP TO THE OPERATOR
761 003214 011646          MOV (SP),-(SP)          ;GET TRAP ADDRESS
762 003216 104402          TYPOC
763 003220 005777 175714 1$: TST @SWR          ;TEST IF HALT ON ERROR
764 003224 100001          BPL 2$          ;BR IF SET
765 003226 000000          HALT          ;FATAL BUS TRAP DETECTED
766 003230 104401 052514 2$: TYPE, RUNITA
767 003234 000137 002012          JMP RTRT          ;RESTART
768
769          ;ROUTINE TO INPUT NEW TTY ADDRESS FROM THE OPERATOR
770 003240 104401 052604 XTTY: TYPE, WARNO          ;TELL THE OPERATOR THE RULES
771 003244 104412          RDOCT          ;LISTEN TO THE OPERATOR
772 003246 012600          MOV (SP)+,R0          ;READ THEIR INPUT
773 003250 001754          BEQ FATFNG          ;BR IF JUST 'CR'
774 003252 005710          TST (R0)          ;ADDRESS THE DEVICE AND CHECK BUS TRAP
775          ;IF NO BUS TRAP - THEY MUST KNOW WHAT THEY ARE DOING !
776 003254 012701 001144          MOV #STKS,R1          ;GET POINTER
777 003260 010021          1$: MOV R0,(R1)+          ;LOAD THE VALUE
778 003262 005720          TST (R0)+          ;BUMP VALUE
779 003264 020127 001154          CMP R1,#STKS+10          ;TEST IF DONE ALL ADDRESSES
780 003270 001373          BNE 1$          ;BR IF NOT
781 003272 000137 002042          JMP RTRTA          ;RETYPE THE HEADER AGAIN ON THE NEW TERMINAL
782
783          ;OPERATOR CHOSE THE FIELD ADJUSTMENT LOOP
784 003276 104401 051250 TFSITE: TYPE, PRIM6          ;TELL OPER. ABOUT A017
785 003302 104401 041374          TYPE, FIELDI          ;ASK THE OPERATOR FOR INPUT Z MODE
786 003306 005037 040410          CLR INOUTZ          ;DEFAULT TO USER SUPPLIED Z PULSES
787 003312 104411          RDLIN          ;READ OPER. INPUT
788 003314 013637 003350          MOV @(SP)+,10$          ;GET CHAR
789 003320 142737 000040 003350          BICB #40,10$          ;ENSURE UPPER CASE
790 003326 122737 000131 003350          CMPB #'Y,10$          ;TEST FOR 'Y' INPUT
791 003334 001003          BNE 1$          ;BR IF NOT 'Y'
792 003336 012737 000002 040410          MOV #2,INOUTZ          ;SET MAINT Z CONSTANT
793 003344 000137 037354          1$: JMP FSITE          ;NOW DO THE LOOP
794 003350 000000          10$: 0
795
796 003352 000000          ADNOKT: 0          ;LAST ADDRESS WITHOUT M.M. OR XXDP
797 003354 000000          NLSI11: 0          ;NON-ZERO INDICATES LSI-11 PROCESSOR

```

```

798
799 003356 000005          LOGIC:  RESET
800 003360 005737 001202      TST      $PASS          ;TEST IF FIRST PASS
801 003364 001124          BNE      TST1           ;:BR IF NOT
802 003366 005737 050110      TST      WFMODE        ;CHECK IF ON TESTER
803 003372 001402          BEQ      5$             ;BR IF NOT
804 003374 104401 052332      TYPE,   PRIM4         ;TELL OPERATOR CABLE MUST BE CONNECTED
805 003400 005037 036120      5$:    CLR      $KT11   ;INDICATE NO KT11
806 003404 004737 036062      JSR     PC,$SIZE      ;SIZE BASIC MEMORY SIZE
807 003410 162737 001000 036400  SUB     #1000,$LSTAD   ;PROTECT ABSLDR
808 003416 005737 000042      TST     @#42          ;TEST IF XXDP CHAIN MODE ?
809 003422 001403          BEQ      1$             ;BR IF NOT CHAIN MODE
810 003424 162737 006200 036400  SUB     #3200.,$LSTAD ;LEAVE ROOM FOR XXDP MONITOR
811 003432 013737 036400 003352  1$:    MOV     $LSTAD,ADNOKT ;SAVE BASIC MEMORY STAGE
812 003440 012737 000200 036120  MOV     #BIT7,$KT11   ;WITH M.M.
813 003446 004737 036062      JSR     PC,$SIZE      ;DETERMINE THE AMOUNT OF MEMORY
814 003452 005737 036120      TST     $KT11        ;TEST IF KT11 IS HERE
815 003456 100025          BPL     2$             ;BR IF NOT
816 003460 012737 000200 172342  MOV     #200,@#KIPAR1 ;
817 003466 012737 077406 172302  MOV     #77406,@#KIPDR1
818 003474 012737 000400 172344  MOV     #400,@#KIPAR2
819 003502 012737 077406 172304  MOV     #77406,@#KIPDR2
820 003510 012737 077406 172306  MOV     #77406,@#KIPDR3 ;4K, UP R/W FOR 60000
821 003516 012737 007600 172356  MOV     #7600,@#KIPAR7 ;I/O PAGE MAP
822 003524 012737 077406 172316  MOV     #77406,@#KIPDR7 ;4K, UP, R/W FOR I/O PAGE ACCESS
823 003532 105737 001134      2$:    TSTB    $AUTOB   ;TEST IF AUTO MODE
824 003536 001016          BNE     4$             ;:BR IF AUTO MODE
825 003540 104401 052545      TYPE,   MSGMEM        ;TELL OPERATOR THE AMOUNT OF MEMORY
826 003544 013700 036402      MOV     $LSTBK,RO     ;GET LAST GOOD BANK
827 003550 006200          ASR     RO
828 003552 006200          ASR     RO
829 003554 006200          ASR     RO
830 003556 006200          ASR     RO
831 003560 006200          ASR     RO
832 003562 005200          INC     RO
833 003564 010046          MOV     RO,-(SP)      ;CONVERT
834 003566 104405          TYPDS   ;TYPE OUT DEC. VALUE
835 003570 104401 052565      TYPE,   MSGK          ;AND THEN TYPE OUT THE REMAINDER OF MEMORY MESSAGE
836 003574 013737 000004 002004  4$:    MOV     @#ERRVEC,$TEMP ;SAVE LOC 4 VALUE
837 003602 012737 003630 000004  MOV     #3$,@#ERRVEC  ;LOAD LOC 4
838 003610 005037 003354          CLR     NLSI11       ;INDICATE NOT A LSI-11 CPU
839 003614 005037 177776          CLR     PSW          ;SHOULD FAIL IF LSI-11
840 003620 013737 002004 000004  MOV     $TEMP,@#ERRVEC ;RESTORE LOC 4 VALUE
841 003626 000403          BR      TST1         ;:BR IF TEST
842 003630 005237 003354      3$:    INC     NLSI11     ;SET AN LSI-11 FLAG
843 003634 000002          RTI                    ;RETURN

```



```
844
845
846
847 003636 000004
848 003640 012737 000100 001160
849 003646 013737 000004 004014
850 003654 012737 003752 000004
851 003662 005777 176060
852 003666 005777 176056
853 003672 005777 176054
854 003676 005777 176052
855 003702 005777 176050
856 003706 005777 176046
857 003712 005777 176046
858 003716 012737 003760 000004
859 003724 005777 176010
860 003730 005777 176010
861
862 003734 012737 000001 004016
863 003742 013737 004014 000004
864 003750 000423
865 003752 022626
866 003754 104001
867 003756 000411
868 003760 022626
869 003762 104041
870 003764 012737 000001 004016
871 003772 013737 004014 000004
872 004000 000407
873 004002 013737 004014 000004
874 004010 000137 030076
875 004014 000000
876 004016 000000

;*****
;*TEST 1 VERIFY THE 8 NCV11 AND 2 NCV11 CLOCK BUS ADDRESSES RESPOND
;*****
TST1: SCOPE
MOV #100,$TIMES ;;DO 100 ITERATIONS
MOV @#ERRVEC,10$ ;SAVE BUS TRAP VECTOR
MOV #1$,@#ERRVEC ;LOAD BUS TRAP VECTOR
TST @CSR ;ADDRESS
TST @OFF ;
TST @WCR ;THE
TST @BAR ;
TST @SFR ;NCV11
TST @ADM ;
TST @BAR1 ;ADDRESSES
MOV #2$,@#ERRVEC ;LOAD NEW RETURN
TST @KWCSR ;TEST CLOCK
TST @KWPSR ;ADDRESSES
;TEMP FIX THE DIAG TO NOT USE CLOCK JUMPERS
MOV #1,DEADKW ;INDICATE NCV11 CLOCK IS NOT THERE;TEMP. FIX UNTIL ECO M
MOV 10$,@#ERRVEC ;RESTORE THE BUS TRAP VECTOR
BR TST2 ;;BR AND TEST THE NCV11
1$: CMP (SP)+,(SP)+ ;CLEAN THE STACK
ERROR 1 ;BUS TRAP WHEN REFERENCING THE NCV11
BR 3$
2$: CMP (SP)+,(SP)+ ;CLEAN THE STACK
ERROR 41 ;BUS TRAP WHEN REFERENCING THE NCV11 CLOCK
MOV #1,DEADKW ;INDICATE NCV11 CLOCK IS NOT THERE
MOV 10$,@#ERRVEC ;RESTORE LOC 4
BR TST2 ;;
3$: MOV 10$,@#ERRVEC ;RESTORE BUS TRAP VECTOR
JMP $EOP ;EXIT
10$: 0
DEADKW: 0 ;NON-ZERO SAYS NO NCV11 CLOCK
```

```

877
878
879
880 004020 000004
881 004022 012737 000100 001160
882 004030 012737 004044 001110
883 004036 012737 004000 002004
884
885 004044 013777 002004 175674 1$: MOV $TEMP,@CSR ;LOAD CSR REG.
886 004052 017737 175670 001126 MOV @CSR,$BDDAT ;READ CSR
887 004060 013737 002004 001124 MOV $TEMP,$GDDAT ;LOAD EXPECTED
888 004066 052737 000200 001124 BIS #BIT7,$GDDAT ;FUDGE THE 'READY' BIT
889 004074 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE THE VALUES
890 004102 001401 BEQ 2$ ;:BR IF SAME
891 004104 104002 ERROR 2 ;UNEXPECTED VALUE IN THE CSR REGISTER
892
893 004106 006237 002004 2$: ASR $TEMP ;TRY THE NEXT DATA BIT
894 004112 022737 000001 002004 CMP #1,$TEMP ;TEST IF NOW BIT 0
895 004120 001351 BNE 1$ ;BR IF NOT
896
897
898
899
900 004122 000004
901 004124 012737 000010 001160
902 004132 012777 007776 175606
903 004140 000005
904 004142 012737 000200 001124
905 004150 017737 175572 001126
906 004156 023737 001124 001126
907 004164 001401
908 004166 104002
909
910
911
912
913 004170 000004
914 004172 012737 000010 001160
915 004200 012777 007776 175540
916 004206 012777 004000 175542
917 004214 012737 000200 001124
918 004222 017737 175520 001126
919 004230 023737 001124 001126
920 004236 001401
921 004240 104002
922

```

```

*****
:*TEST 2 FLOAT A 1 ACROSS 10 BITS OF THE COMMAND/STATUS REG.
*****

```

```

TST2: SCOPE
MOV #100,$TIMES ;:DO 100 ITERATIONS
MOV #1$,$LPERR ;LOAD LOOP ADDRESS
MOV #BIT11,$TEMP ;LOAD INITIAL REG. VALUE
1$: MOV $TEMP,@CSR ;LOAD CSR REG.
MOV @CSR,$BDDAT ;READ CSR
MOV $TEMP,$GDDAT ;LOAD EXPECTED
BIS #BIT7,$GDDAT ;FUDGE THE 'READY' BIT
CMP $GDDAT,$BDDAT ;COMPARE THE VALUES
BEQ 2$ ;:BR IF SAME
ERROR 2 ;UNEXPECTED VALUE IN THE CSR REGISTER
2$: ASR $TEMP ;TRY THE NEXT DATA BIT
CMP #1,$TEMP ;TEST IF NOW BIT 0
BNE 1$ ;BR IF NOT

```

```

*****
:*TEST 3 VERIFY THAT 'INIT' CLEARS THE CSR REGISTER
*****

```

```

TST3: SCOPE
MOV #10,$TIMES ;:DO 10 ITERATIONS
MOV #7776,@CSR ;LOAD CSR REG.
RESET ;INITILIZE THE REGISTER
MOV #BIT7,$GDDAT ;LOAD EXPECTED VALUE
MOV @CSR,$BDDAT ;READ CSR REG.
CMP $GDDAT,$BDDAT ;COMPARE THE VALUES
BEQ TST4 ;:BR IF EQUAL
ERROR 2 ;'BUS INIT' FAILED TO CLEAR CSR REG.

```

```

*****
:*TEST 4 VERIFY THAT 'CLEAR ALL' CLEARS THE CSR REGISTER
*****

```

```

TST4: SCOPE
MOV #10,$TIMES ;:DO 10 ITERATIONS
MOV #7776,@CSR ;LOAD CSR REG.
MOV #CLRALL,@SFR ;GENERATE 'CLR ALL L'
MOV #BIT7,$GDDAT ;LOAD EXPECTED VALUE
MOV @CSR,$BDDAT ;READ THE CSR REG.
CMP $GDDAT,$BDDAT ;COMPARE VALUES
BEQ TST5 ;:BR IF SAME
ERROR 2 ;'CLR ALL L' FAILED TO CLEAR CSR REG.

```

```

923
924
925
926 004242 000004
927 004244 012737 000100 001160
928 004252 012777 003636 175466
929 004260 012737 003600 001124
930 004266 105077 175454
931 004272 017737 175450 001126
932 004300 023737 001124 001126
933 004306 001401
934 004310 104002
935 004312 012777 003636 175426 1$:
936 004320 012737 000236 001124
937 004326 105077 175434
938 004332 017737 175410 001126
939 004340 023737 001124 001126
940 004346 001401
941 004350 104003
942
943
944
945 004352 000004
946 004354 012737 004370 001110
947 004362 012737 000020 002004
948
949 004370 013777 002004 175360 1$:
950 004376 017737 175354 001126
951 004404 013737 002004 001124
952 004412 023737 001124 001126
953 004420 001401
954 004422 104003
955 004424 006237 002004 2$:
956 004430 022737 000001 002004
957 004436 001354
958
959
960
961
962 004440 000004
963 004442 012737 000010 001160
964 004450 012777 000014 175300
965 004456 012737 000014 001124
966 004464 105077 175300
967 004470 017737 175262 001126
968 004476 023737 001124 001126
969 004504 001401
970 004506 104003
971
  
```

```

*****
*TEST 5      VERIFY LOW BYTE OPERATION OF THE 'CSR' REGISTER
*****
TST5:  SCOPE
        MOV      #100,$TIMES      ;;DO 100 ITERATIONS
        MOV      #3636,@CSR      ;LOAD CSR REGISTER
        MOV      #3600,$GDDAT    ;LOAD EXPECTED VALUE
        CLRB     @CSR            ;CLEAR LOW BYTE
        MOV      @CSR,$BDDAT     ;READ STATUS REG.
        CMP      $GDDAT,$BDDAT   ;COMPARE VALUES
        BEQ      1$              ;;BR IF SAME
        ERROR    2                ;CLEARING LOW BYTE OF THE CSR CHANGED THE HIGH B
1$:     MOV      #3636,@CSR      ;LOAD CSR REGISTER
        MOV      #236,$GDDAT     ;LOAD EXPECTED VALUE
        CLRB     @CSRHB         ;CLEAR HIGH BYTE OF THE CSR
        MOV      @CSR,$BDDAT     ;READ STATUS
        CMP      $GDDAT,$BDDAT   ;COMPARE VALUES
        BEQ      TST6            ;;BR IS SAME
        ERROR    3                ;CLEARING HIGH BYTE OF CSR CHANGED THE LOW BYTE
*****
*TEST 6      FLOAT A 1 ACROSS 4 BITS OF THE SPECIAL FUNCTION REGISTER
*****
TST6:  SCOPE
        MOV      #1$,$LPERR      ;LOAD LOOP ADDRESS
        MOV      #BIT4,$TEMP     ;LOAD INITIAL REG. VALUE
1$:     MOV      $TEMP,@SFR      ;LOAD SFR REG.
        MOV      @SFR,$BDDAT     ;READ SFR
        MOV      $TEMP,$GDDAT    ;LOAD EXPECTED
        CMP      $GDDAT,$BDDAT   ;COMPARE THE VALUES
        BEQ      2$              ;;BR IF SAME
        ERROR    3                ;UNEXPECTED VALUE IN THE SFR REGISTER
2$:     ASR      $TEMP           ;TRY THE NEXT DATA BIT
        CMP      #1,$TEMP        ;TEST IF NOW BIT 0
        BNE     1$              ;BR IF NOT
*****
*TEST 7      VERIFY THAT CLEARING HIGH BYTE OF SFR DOES NOT CLEAR LOW BYTE
*****
TST7:  SCOPE
        MOV      #10,$TIMES     ;;DO 10 ITERATIONS
        MOV      #14,@SFR       ;LOAD THE S.F. REGISTER
        MOV      #14,$GDDAT     ;LOAD THE EXPECTED VALUE
        CLRB     @SFRHB         ;CLEAR HIGH BYTE OF S.F. REG.
        MOV      @SFR,$BDDAT     ;READ THE REGISTER
        CMP      $GDDAT,$BDDAT   ;COMPARE THE VALUES
        BEQ      TST10           ;;BR IF SAME
        ERROR    3                ;CLEARING HIGH BYTE OF CSR REG. CHANGED THE LOW
  
```

```
972
973
974
975 004510 000004
976 004512 012737 000010 001160
977 004520 012777 000016 175230
978 004526 000005
979 004530 005037 001124
980 004534 017737 175216 001126
981 004542 001401
982 004544 104003
983
984
985
986
987 004546 000004
988 004550 012737 000010 001160
989 004556 012777 000016 175172
990 004564 052777 004000 175164
991 004572 005037 001124
992 004576 017737 175154 001126
993 004604 001401
994 004606 104003
995

*****
*TEST 10 VERIFY THAT 'INIT' CLEARS THE SFR REGISTER
*****
TST10: SCOPE
MOV #10,$TIMES ;;DO 10 ITERATIONS
MOV #16,@SFR ;LOAD SFR REG.
RESET ;INITILIZE THE REGISTER
CLR $GDDAT ;LOAD EXPECTED
MOV @SFR,$BDDAT ;READ SFR REG.
BEQ TST11 ;;BR IF EQUAL
ERROR 3 ;'BUS INIT' FAILED TO CLEAR SFR REG.

*****
*TEST 11 VERIFY THAT 'CLEAR ALL' CLEARS THE SFR REGISTER
*****
TST11: SCOPE
MOV #10,$TIMES ;;DO 10 ITERATIONS
MOV #16,@SFR ;LOAD SFR REG.
BIS #CLRALL,@SFR ;GENERATE 'CLR ALL L'
CLR $GDDAT ;LOAD EXPECTED VALUE
MOV @SFR,$BDDAT ;READ THE SFR REG.
BEQ TST12 ;;BR IF SAME
ERROR 3 ;'CLR ALL L' FAILED TO CLEAR SFR REG.
```

```

996
997
998
999 004610 000004
1000 004612 012737 000100 001160
1001 004620 012737 000001 001124
1002 004626 012737 004634 001110
1003
1004 004634 012777 004000 175114 1$: MOV #CLRALL,@SFR ;RESET THE DEVICE
1005 004642 013777 001124 175102 MOV $GDDAT,@WCR ;LOAD WORD COUNT 'A'
1006 004650 017737 175076 001126 MOV @WCR,$BDDAT ;READ WORD COUNT
1007 004656 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE VALUES
1008 004664 001401 BEQ 2$ ;:BR IF SAME
1009 004666 104004 ERROR 4 ;:WORD COUNT REG. IN ERROR
1010
1011 004670 006337 001124 2$: ASL $GDDAT ;CHANGE THE DATA
1012 004674 001357 BNE 1$ ;BR IF MORE DATA TO LOAD
1013
1014
1015
1016 004676 000004
1017 004700 012737 000100 001160
1018 004706 012737 000001 001124
1019 004714 012737 004722 001110
1020
1021 004722 012777 004000 175026 1$: MOV #CLRALL,@SFR ;RESET THE DEVICE
1022 004730 013777 001124 175016 MOV $GDDAT,@BAR ;LOAD BUS ADDRESS 'A'
1023 004736 017737 175012 001126 MOV @BAR,$BDDAT ;READ BUS ADDRESS
1024 004744 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE VALUES
1025 004752 001401 BEQ 2$ ;:BR IF SAME
1026 004754 104005 ERROR 5 ;BUS ADDRESS REG. IN ERROR
1027
1028 004756 006337 001124 2$: ASL $GDDAT ;CHANGE THE DATA
1029 004762 001357 BNE 1$ ;BR IF MORE DATA TO LOAD
1030
1031
1032
1033 004764 000004
1034 004766 012737 000100 001160
1035 004774 012737 000001 001124
1036 005002 012737 005010 001110
1037
1038 005010 012777 004000 174740 1$: MOV #CLRALL,@SFR ;RESET THE DEVICE
1039 005016 013777 001124 174724 MOV $GDDAT,@OFF ;LOAD OFFSET 'A'
1040 005024 017737 174720 001126 MOV @OFF,$BDDAT ;READ OFFSET
1041 005032 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE VALUES
1042 005040 001401 BEQ 2$ ;:BR IF SAME
1043 005042 104006 ERROR 6 ;OFFSET REG. IN ERROR
1044
1045 005044 006337 001124 2$: ASL $GDDAT ;CHANGE THE DATA
1046 005050 001357 BNE 1$ ;BR IF MORE DATA TO LOAD
    
```

```

1047
1048
1049
1050 005052 000004
1051 005054 012737 000010 001160
1052
1053 005062 012777 004000 174666
1054 005070 012777 011111 174652
1055 005076 012777 022222 174646
1056 005104 012777 033333 174642
1057 005112 012777 000036 174636
1058 005120 012777 007636 174620
1059
1060 005126 012737 011111 001124
1061 005134 017737 174610 001126
1062 005142 023737 001124 001126
1063 005150 001401
1064 005152 104007
1065 005154 012737 022222 001124 1$:
1066 005162 017737 174564 001126
1067 005170 023737 001124 001126
1068 005176 001401
1069 005200 104007
1070 005202 012737 033333 001124 2$:
1071 005210 017737 174540 001126
1072 005216 023737 001124 001126
1073 005224 001401
1074 005226 104007
1075 005230 012737 000036 001124 3$:
1076 005236 017737 174514 001126
1077 005244 023737 001124 001126
1078 005252 001401
1079 005254 104007
1080 005256 012737 007636 001124 4$:
1081 005264 017737 174456 001126
1082 005272 023737 001124 001126
1083 005300 001401
1084 005302 104007
1085 005304 012777 004000 174444 5$:
  
```

```

:*****
:*TEST 15 VERIFY NO DUAL REGISTER SELECTION
:*****
TST15: SCOPE
MOV #10,$TIMES ;;DO 10 ITERATIONS
;LOAD DIFFERENT NUMBERS INTO THE WCR, BAR AND OFF REGISTERS
MOV #CLRALL,@SFR ;CLEAR THE DEVICE
MOV #11111,@OFF ;LOAD OFFSET REGISTER
MOV #22222,@WCR ;LOAD W.C. REGISTER
MOV #33333,@BAR ;LOAD B.A. REGISTER
MOV #36,@SFR ;LOAD SPECIAL FUNCTION REGISTER
MOV #7636,@CSR ;LOAD COMMAND/STATUS REGISTER
;NOW READ EACH REGISTER AND CHECK THE VALUE
MOV #11111,$GDDAT ;LOAD EXPECTED VALUE
MOV @OFF,$BDDAT ;READ A OFFSET REG.
CMP $GDDAT,$BDDAT ;COMPARE
BEQ 1$ ;;BR IF SAME
ERROR 7 ;DUAL ADDRESS ERROR
MOV #22222,$GDDAT ;LOAD EXPECTED VALUE
MOV @WCR,$BDDAT ;READ W.C. REG.
CMP $GDDAT,$BDDAT ;COMPARE
BEQ 2$ ;;BR IF SAME
ERROR 7 ;DUAL ADDRESS ERROR
MOV #33333,$GDDAT ;LOAD EXPECTED VLAUE
MOV @BAR,$BDDAT ;READ B.A. REG.
CMP $GDDAT,$BDDAT ;COMPARE
BEQ 3$ ;;BR IF SAME
ERROR 7 ;DUAL ADDRESS ERROR
MOV #36,$GDDAT ;LOAD EXPECTED VALUE
MOV @SFR,$BDDAT ;READ SPECIAL FUNCTION REG
CMP $GDDAT,$BDDAT ;COMPARE
BEQ 4$ ;;BR IF SAME
ERROR 7 ;DUAL ADDRESS ERROR
MOV #7636,$GDDAT ;LOAD EXPECTED VALUE
MOV @CSR,$BDDAT ;READ COMMAND/STATUS REGISTER
CMP $GDDAT,$BDDAT ;COMPARE
BEQ 5$ ;;BR IF SAME
ERROR 7 ;DUAL ADDRESS ERROR
MOV #CLRALL,@SFR ;CLEAR THE DEVICE
  
```

```

1086
1087
1088
1089 005312 000004
1090 005314 012737 000010 001160
1091 005322 005037 001124
1092 005326 012777 004000 174422
1093 005334 012777 000003 174406
1094 005342 012777 004000 174406
1095 005350 017737 174374 001126
1096 005356 001401
1097 005360 104006
1098
1099
1100
1101
1102 005362 000004
1103 005364 012777 004000 174364
1104 005372 052777 000010 174356
1105 005400 000240
1106 005402 000240
1107 005404 000240
1108 005406 052777 000022 174332
1109
1110 005414 012737 000022 001124
1111 005422 052777 000001 174316
1112 005430 017737 174312 001126
1113 005436 023737 001124 001126
1114 005444 001404
1115 005446 052777 000400 174302
1116 005454 104001
1117
1118 005456 052777 000400 174272
1119 005464 012737 000222 001124
1120 005472 017737 174250 001126
1121 005500 023737 001124 001126
1122 005506 001401
1123 005510 104001
1124
1125
1126 005512 012737 000200 001124
1127 005520 052777 000001 174220
1128 005526 052777 004000 174222
1129 005534 017737 174206 001126
1130 005542 023737 001124 001126
1131 005550 001401
1132 005552 104001

:*****
:*TEST 16 VERIFY 'CLR ALL' CLEARS THE EXTENDED OFFSET BITS
:*****
TST16: SCOPE
MOV #10,$TIMES ;;DO 10 ITERATIONS
CLR $GDDAT ;CLEAR EXPECTED VALUE
MOV #CLRALL,@SFR ;CLEAR THE DEVICE
MOV #3,@OFF ;LOAD EXTENDED OFFSET REGISTER
MOV #CLRALL,@SFR ;CLEAR THE EXTENDED OFFSET REG.'S
MOV @OFF,$BDDAT ;READ EXTENDED OFFSET REG.
BEQ TST17 ;;BR IF CLEARED
ERROR 6 ;CLEAR ALL FAILED TO CLEAR EXTENDED OFFSET REGIS

:*****
:*TEST 17 TEST THE 'ACTIVE' FLOP CAN SET AND CLEAR
:*****
TST17: SCOPE
MOV #CLRALL,@SFR ;CLEAR THE DEVICE
BIS #TSTDMA,@SFR ;SET THE 'TEST DMA' TO PREVENT DATA TRANSFERS
NOP
NOP
NOP
BIS #BIT4!BIT1,@CSR ;SET 'MATRIX MODE' AND 'BYTE' MODE
;NOW SET THE 'ACTIVE' FLOP AND VERIFY 'INTERFACE IDLE' GOES LOW
MOV #BIT4!BIT1,$GDDAT ;LOAD EXPECTED VALUE
BIS #BIT0,@CSR ;SET 'ACTIVE' TO A 1
MOV @CSR,$BDDAT ;READ STATUS
CMP $GDDAT,$BDDAT ;COMPARE VALUES
BEQ 1$ ;;BR IF EXPECTED
BIS #ENDDMA,@SFR ;STOP DMA IF POSSIBLE
ERROR 1 ;'ACTIVE' FLOP FAILED TO SET
;POKE THE 'END DMA' SIGNAL AND VERIFY 'ACTIVE' CLEARS
1$: BIS #ENDDMA,@SFR ;SEND 'END DMA' SIGNAL
MOV #BIT7!BIT4!BIT1,$GDDAT ;SET 'INTERFACE IDLE' INTO EXPECTED
MOV @CSR,$BDDAT ;READ STATUS
CMP $GDDAT,$BDDAT ;COMPARE
BEQ 2$ ;;BR IF SAME
ERROR 1 ;'END DMA' AGAIN FAILED TO CLEAR 'ACTIVE' FLOP
;POKE 'ENABLE DMA' AND THEN ISSUE 'CLR ALL' SIGNAL TO
;ENSURE THE 'ACTIVE' FLOP CLEARS
2$: MOV #BIT7,$GDDAT ;LOAD EXPECTED
BIS #BIT0,@CSR ;POKE 'ENABLE DMA'
BIS #CLRALL,@SFR ;GENERATE 'CLR ALL'
MOV @CSR,$BDDAT ;READ STATUS
CMP $GDDAT,$BDDAT ;COMPARE
BEQ TST20 ;;BR IF SAME
ERROR 1 ;'CLR ALL' FAILED TO CLEAR 'ACTIVE' FLOPS

```

```

1133
1134
1135
1136 005554 000004
1137 005556 012737 000100 001160
1138 005564 012777 004000 174164
1139 005572 012777 000010 174156
1140 005600 012777 000000 174144
1141 005606 012777 000000 174140
1142 005614 012777 000022 174124
1143 005622 052777 000001 174116
1144 005630 052777 000002 174120
1145 005636 042777 000002 174112
1146 005644 012737 000001 001124
1147 005652 017737 174076 001126
1148 005660 001002
1149 005662 104010
1150 005664 000420
1151 005666 017737 174060 001126 1$:
1152 005674 001401
1153 005676 104011
1154 005700 012737 000020 001124 2$:
1155 005706 017737 174034 001126
1156 005714 032737 040000 001126
1157 005722 001401
1158 005724 104012
1159
1160
1161
1162 005726 000004
1163 005730 012737 000100 001160
1164 005736 012777 004000 174012
1165 005744 012777 000010 174004
1166 005752 012777 000000 173772
1167 005760 012777 000376 173766
1168 005766 012777 000022 173752
1169 005774 052777 000001 173744
1170 006002 052777 000002 173746
1171 006010 042777 000002 173740
1172 006016 012737 000400 001124
1173 006024 017737 173724 001126
1174 006032 105737 001127
1175 006036 001002
1176 006040 104010
1177 006042 000423
1178 006044 012737 000000 001124 1$:
1179 006052 017737 173674 001126
1180 006060 001401
1181 006062 104011
1182 006064 012737 000020 001124 2$:
1183 006072 017737 173650 001126
1184 006100 032737 040000 001126
1185 006106 001401
1186 006110 104012

*****
*TEST 20 VERIFY Z INPUTS CAUSE THE LOW 8 BITS OF 32 BIT COUNTER TO CHANGE IN MARI
*****
TST20: SCOPE
MOV #100,$TIMES ;;DO 100 ITERATIONS'
MOV #CLRALL,@SFR ;CLEAR THE DEVICE
MOV #TSTDMA,@SFR ;SET TEST DMA FLOP
MOV #0,@WCR ;LOAD W.C. REG
MOV #0,@BAR ;LOAD B.A. REG
MOV #BIT4!BIT1,@CSR ;ENTER MATRIX MODE
BIS #BIT0,@CSR ;GO 'ACTIVE'
BIS #TESTZ,@SFR ;ENABLE 'TEST Z' PULSES
BIC #TESTZ,@SFR ;DISABLE 'TEST Z' PULSES
MOV #1,$GDDAT ;LOAD EXPECTED
MOV @BAR,$BDDAT ;READ LOW 16 BITS
BNE 1$ ;;BR IF NON-ZERO
ERROR 10 ;Z INPUT FAILED TO CAUSE THE LOW BYTE OF 32 BIT
BR TST21 ;;
MOV @'CR,$BDDAT ;READ HIGH 16 BITS
BEQ 2$ ;;BR IF CLEARED
ERROR 11 ;HIGH 16 BIS CHANGED IN ERROR
MOV #BIT4,$GDDAT ;LOAD EXPECTED
MOV @CSR,$BDDAT ;READ STATUS
BIT #BIT14,$BDDAT ;TEST IF 'CELL OVERFLOW'
BEQ TST21 ;;BR IF CORRECT
ERROR 12 ;'CELL OVERFLOW' FLOP SET IN ERROR
*****
*TEST 21 VERIFY Z INPUTS CAUSE THE LOW 16 BITS OF 32 BIT COUNTER TO CHANGE
*****
TST21: SCOPE
MOV #100,$TIMES ;;DO 100 ITERATIONS
MOV #CLRALL,@SFR ;CLEAR THE DEVICE
MOV #TSTDMA,@SFR ;SET TEST DMA FLOP
MOV #0,@WCR ;LOAD W.C. REG
MOV #376,@BAR ;LOAD B.A. REG
MOV #BIT4!BIT1,@CSR ;ENTER MATRIX MODE
BIS #BIT0,@CSR ;GO 'ACTIVE'
BIS #TESTZ,@SFR ;ENABLE 'TEST Z' PULSES
BIC #TESTZ,@SFR ;DISABLE 'TEST Z' PULSES
MOV #BIT8,$GDDAT ;LOAD EXPECTED
MOV @BAR,$BDDAT ;READ LOW 16 BITS
TSTB $BDDAT+1 ;TEST HIGH BYTE
BNE 1$ ;BR IF NON-ZERO
ERROR 10 ;Z INPUT FAILED TO CAUSE THE HIGH BYTE OF THE LO
BR TST22 ;;
MOV #0,$GDDAT ;LOAD EXPECTED
MOV @WCR,$BDDAT ;READ HIGH 16 BITS
BEQ 2$ ;;BR IF CLEARED
ERROR 11 ;HIGH 16 BITS CHANGED IN ERROR
MOV #BIT4,$GDDAT ;LOAD EXPECTED
MOV @CSR,$BDDAT ;READ STATUS
BIT #BIT14,$BDDAT ;TEST IF 'CELL OVERFLOW'
BEQ TST22 ;;BR IF CORRECT
ERROR 12 ;'CELL OVERFLOW' FLOP SET IN ERROR

```



```
1187
1188
1189
1190 006112 000004
1191 006114 012737 000100 001160
1192 006122 012777 004000 173626
1193 006130 012777 000010 173620
1194 006136 012777 000000 173606
1195 006144 012777 177776 173602
1196 006152 012777 000022 173566
1197 006160 052777 000001 173560
1198 006166 052777 000002 173562
1199 006174 042777 000002 173554
1200 006202 012737 000001 001124
1201 006210 017737 173536 001126
1202 006216 001002
1203 006220 104011
1204 006222 000413
1205 006224 012737 000020 001124
1206 006232 017737 173510 001126
1207 006240 032737 040000 001126
1208 006246 001401
1209 006250 104012
1210
1211
1212
1213 006252 000004
1214 006254 012737 000100 001160
1215 006262 012777 004000 173466
1216 006270 012777 000010 173460
1217 006276 012777 000377 173446
1218 006304 012777 177776 173442
1219 006312 012777 000022 173426
1220 006320 052777 000001 173420
1221 006326 052777 000002 173422
1222 006334 042777 000002 173414
1223 006342 012737 000400 001124
1224 006350 017737 173376 001126
1225 006356 105737 001127
1226 006362 001001
1227 006364 104012

*****
*TEST 22 VERIFY Z INPUTS CAUSE THE LOW 24 BITS OF 32 BIT COUNTER TO CHANGE
*****
TST22: SCOPE
MOV #100,$TIMES ;;DO 100 ITERATIONS
MOV #CLRALL,@SFR ;CLEAR THE DEVICE
MOV #TSTDMA,@SFR ;SET TEST DMA FLOP
MOV #0,@WCR ;LOAD W.C. REG
MOV #-2,@BAR ;LOAD B.A. REG
MOV #BIT4!BIT1,@CSR ;ENTER MATRIX MODE
BIS #BIT0,@CSR ;GO 'ACTIVE'
BIS #TESTZ,@SFR ;ENABLE 'TEST Z' PULSES
BIC #TESTZ,@SFR ;DISABLE 'TEST Z' PULSES
MOV #1,$GDDAT ;LOAD EXPECTED
1$: MOV @WCR,$BDDAT ;READ HIGH 16 BITS
BNE 2$ ;BR IF SET
ERROR 11 ;LOW BYTE OF THE HIGH 16 BITS FAILED TO CHANGE
BR TST23 ;;
2$: MOV #BIT4,$GDDAT ;LOAD EXPECTED
MOV @CSR,$BDDAT ;READ STATUS
BIT #BIT14,$BDDAT ;TEST IF 'CELL OVERFLOW'
BEQ TST23 ;;BR IF CORRECT
ERROR 12 ;'CELL OVERFLOW' FLOP SET IN ERROR
*****
*TEST 23 VERIFY Z INPUTS CAUSE THE HIGH 8 BITS OF THE 32 BIT COUNTER TO CHANGE
*****
TST23: SCOPE
MOV #100,$TIMES ;;DO 100 ITERATIONS
MOV #CLRALL,@SFR ;CLEAR THE DEVICE
MOV #TSTDMA,@SFR ;SET TEST DMA FLOP
MOV #377,@WCR ;LOAD W.C. REG
MOV #-2,@BAR ;LOAD B.A. REG
MOV #BIT4!BIT1,@CSR ;ENTER MATRIX MODE
BIS #BIT0,@CSR ;GO 'ACTIVE'
BIS #TESTZ,@SFR ;ENABLE 'TEST Z' PULSES
BIC #TESTZ,@SFR ;DISABLE 'TEST Z' PULSES
MOV #BIT8,$GDDAT ;LOAD EXPECTED
1$: MOV @WCR,$BDDAT ;READ HIGH 16 BITS
TSTB $BDDAT+1 ;TEST HIGH BYTE
BNE TST24 ;;BR IF SET
ERROR 12 ;HIGH 8 BITS OF THE 32 BIT COUNTER FAILED TO CHANGE
```

```
1228
1229
1230
1231 006366 000004
1232 006370 012737 000100 001160
1233 006376 012777 004000 173352
1234 006404 012777 000000 173340
1235 006412 012777 000000 173334
1236 006420 005077 173322
1237 006424 052777 000002 173324
1238 006432 042777 000002 173316
1239 006440 012737 000000 001124
1240 006446 017737 173302 001126
1241 006454 001401
1242 006456 104010
1243
1244
1245
1246
1247 006460 000004
1248 006462 012737 000010 001160
1249 006470 012777 004000 173260
1250 006476 012777 000010 173252
1251 006504 012777 177777 173240
1252 006512 012777 177776 173234
1253 006520 012777 000022 173220
1254 006526 052777 000001 173212
1255
1256 006534 052777 000002 173214
1257 006542 042777 000002 173206
1258 006550 013700 002006
1259 006554 005001
1260 006556 012737 040020 001124
1261
1262 006564 032777 040000 173154 1$:
1263 006572 001011
1264 006574 005301
1265 006576 001372
1266 006600 005300
1267 006602 001370
1268 006604 012777 000400 173144
1269 006612 104012
1270 006614 000 16
1271
1272
1273 006616 052777 004000 173132 2$:
1274 006624 012737 000200 001124
1275 006632 017737 173110 001126
1276 006640 023737 001124 001126
1277 006646 001401
1278 006650 104012

;*****
;*TEST 24 VERIFY Z INPUTS DO NOT CAUSE THE LOW 8 BITS OF 32 BIT COUNTER TO CHANGE
;*****
TST24: SCOPE
MOV #100,$TIMES ;;DO 100 ITERATIONS
MOV #CLRALL,@SFR ;CLEAR THE DEVICE
MOV #0,@WCR ;LOAD W.C. REG
MOV #0,@BAR ;LOAD B.A. REG
CLR @CSR ;ENSURE LIST MODE
BIS #TESTZ,@SFR ;ENABLE 'TEST Z' PULSES
BIC #TESTZ,@SFR ;DISABLE 'TEST Z' PULSES
MOV #0,$GDDAT ;LOAD EXPECTED
MOV @BAR,$BDDAT ;READ LOW 16 BITS
BEQ TST25 ;;BR IF ZERO
ERROR 10 ;Z INPUT CAUSE THE 32 BIT COUNTER TO CHANGE IN LIST MODE

;*****
;*TEST 25 TEST THAT 'WCA OVFL' SETS Z/WC OVERFLOW FLOP AND 'CLR ALL' CLEARS IT
;*****
TST25: SCOPE
MOV #10,$TIMES ;;DO 10 ITERATIONS
MOV #CLRALL,@SFR ;CLEAR DEVICE
MOV #TSTDMA,@SFR ;SET TEST DMA FLOP
MOV #-1,@WCR ;LOAD Z COUNTER
MOV #-2,@BAR ;LOAD Z COUNTER
MOV #BIT4!BIT1,@CSR ;ENTER 'MATRIX' MODE
BIS #BIT0,@CSR ;ENABLE NCV11
;NOW ENABLE 'TEST Z' INPUTS
BIS #TESTZ,@SFR ;ENABLE 'TEST Z' PULSES
BIC #TESTZ,@SFR ;DISABLE 'TEST Z' PULSES
MOV CPUDLO,R0 ;LOAD GROSS TIMER
CLR R1
MOV #BIT14!BIT4,$GDDAT ;LOAD EXPECTED STATUS
1$: BIT #BIT14,@CSR ;TEST FOR Z/WC OVERFLOW
BNE 2$ ;BR IF SET
DEC R1 ;DELAY
BNE 1$
DEC R0 ;DELAY
BNE 1$
MOV #ENDDMA,@SFR ;STOP DMA TRANSFERS
ERROR 12 ;AFTER A GROSS TIME, THE Z/WC OVERFLOW FLOP FAILED TO SE
BR TST26 ;;

;NOW GENERATE 'CLR ALL' TO CLEAR Z/WC OVERFLOW BIT
2$: BIS #CLRALL,@SFR ;CLEAR Z/WC FLOP
MOV #BIT7,$GDDAT ;LOAD EXPECTED
MOV @CSR,$BDDAT ;READ STATUS
CMP $GDDAT,$BDDAT ;COMPARE
BEQ TST26 ;;BR IF SAME
ERROR 12 ;'CLR ALL' FAILED TO CLEAR 'Z/WC' FLOP
```

```

1279
1280
1281
1282 006652 000004
1283 006654 012737 000010 001160
1284 006662 012777 004000 173066
1285 006670 012777 000010 173060
1286 006676 012777 177777 173046
1287 006704 012777 177776 173042
1288 006712 012777 000022 173026
1289 006720 052777 000001 173020
1290
1291 006726 052777 000002 173022
1292 006734 042777 000002 173014
1293
1294 006742 013700 002006
1295 006746 005001
1296 006750 012737 040020 001124
1297
1298 006756 032777 040000 172762 1$:
1299 006764 001014
1300 006766 005301
1301 006770 001372
1302 006772 005300
1303 006774 001370
1304 006776 012777 000400 172752
1305 007004 042777 000002 172744
1306 007012 104012
1307 007014 000416
1308
1309
1310 007016 052777 040000 172732 2$:
1311 007024 012737 000022 001124
1312 007032 017737 172710 001126
1313 007040 023737 001124 001126
1314 007046 001401
1315 007050 104012

```

```

*****
*TEST 26 TEST THAT 'WCA OVFL' SETS Z/WC OVERFLOW FLOP AND 'CLR WC OVFL' CLEARS IT
*****
TST26: SCOPE
      MOV #10,$TIMES ;;DO 10 ITERATIONS
      MOV #CLRALL,@SFR ;CLEAR DEVICE
      MOV #TSTDMA,@SFR ;SET TEST DMA FLOP
      MOV #-1,@WCR ;LOAD Z COUNTER
      MOV #-2,@BAR ;LOAD Z COUNTER
      MO' #BIT4!BIT1,@CSR ;ENABLE 'MATRIX' MODE
      BIS #BIT0,@CSR ;SET NCV11 ACTIVE
;NOW ENABLE 'TEST Z' INPUTS
      BIS #TESTZ,@SFR ;ENABLE 'TEST Z' PULSES
      BIC #TESTZ,@SFR ;DISABLE 'TEST Z' PULSES
      MOV CPUDLO,R0 ;LOAD GROSS TIMER
      CLR R1
      MOV #BIT14!BIT4,$GDDAT ;LOAD EXPECTED STATUS
1$: BIT #BIT14,@CSR ;TEST FOR Z/WC OVERFLOW
   BNE 2$ ;BR IF SET
   DEC R1 ;DELAY
   BNE 1$
   DEC R0 ;DELAY
   BNE 1$
   MOV #ENDDMA,@SFR ;STOP DAM TRANSFERS
   BIC #TESTZ,@SFR ;STOP 'Z' INPUTS
   ERROR 12 ;AFTER A GROSS TIME, THE Z/WC OVERFLOW FLOP FAILED TO SET
   BR TST27 ;;
;NOW GENERATE 'CLR WC OVFL' TO CLEAR Z/WC OVERFLOW BIT
2$: BIS #CLRWCO,@SFR ;CLEAR Z/WC FLOP
   MOV #BIT4!BIT1,$GDDAT ;LOAD EXPECTED
   MOV @CSR,$BDDAT ;READ STATUS
   CMP $GDDAT,$BDDAT ;COMPARE
   BEQ TST27 ;;BR IF SAME
   ERROR 12 ;'CLR WC OVFL' FAILED TO CLEAR 'Z/WC' FLOP

```

```

1316
1317
1318
1319 007052 000004
1320 007054 012737 000010 001160
1321 007062 012777 004000 172666
1322 007070 012777 000010 172660
1323 007076 012777 177777 172646
1324 007104 012777 177776 172642
1325 007112 012777 000022 172626
1326 007120 052777 000001 172620
1327
1328 007126 052777 000002 172622
1329 007134 042777 000002 172614
1330 007142 013700 002006
1331 007146 005001
1332 007150 012737 040020 001124
1333
1334 007156 032777 040000 172562 1$:
1335 007164 001014
1336 007166 005301
1337 007170 001372
1338 007172 005300
1339 007174 001370
1340 007176 012777 000400 172552
1341 007204 042777 000002 172544
1342 007212 104012
1343 007214 000430
1344
1345
1346 007216 012746 000000
1347 007222 012746 007230
1348 007226 000002
1349 007230 012777 007274 172534 3$:
1350 007236 052777 000100 172502
1351 007244 000240
1352 007246 000240
1353 007250 000240
1354 007252 000240
1355 007254 017737 172466 001126
1356 007262 012777 004000 172466
1357 007270 104013
1358 007272 000401
1359
1360 007274 022626
1361 007276 005077 172444
1362 007302 012777 004000 172446
1363 007310 013777 001774 172454
1364 007316 005077 172452
1365

*****
*TEST 27 TEST THAT 'WCA OVFL' GENERATES AN INTERRUPT
*****
TST27: SCOPE
MOV #10,$TIMES ;;DO 10 ITERATIONS
MOV #CLRALL,@SFR ;CLEAR DEVICE
MOV #TSTDMA,@SFR ;SET TEST DMA FLOP
MOV #-1,@WCR ;LOAD Z COUNTER
MOV #-2,@BAR ;LOAD Z COUNTER
MOV #BIT4!BIT1,@CSR ;SET MATRIX MODE
BIS #BIT0,@CSR ;SET NCV11 ACTIVE
;NOW ENABLE 'TEST Z' INPUTS
BIS #TESTZ,@SFR ;ENABLE 'TEST Z' PULSES
BIC #TESTZ,@SIR ;DISABLE 'TEST Z' PULSES
MOV CPUDLO,RO ;LOAD GROSS TIMER
CLR R1
MOV #BIT14.BIT4,$GDDAT ;LOAD EXPECTED STATUS
1$: BIT #BIT14,@CSR ;TEST FOR Z/WC OVERFLOW
BNE 2$ ;BR IF SET
DEC R1 ;DELAY
BNE 1$
DEC RO ;DELAY
BNE 1$
MOV #ENDDMA,@SFR ;STOP DMA TRANSFERS
BIC #TESTZ,@SFR ;STOP 'Z' INPUTS
ERROR 12 ;AFTER A GROSS TIME, THE Z/WC OVERFLOW FLOP FAILED TO SET
BR 5$ ;;BR TO CLEAN UP

;NOW ENABLE THE WC/Z OVERFLOW INTERRUPT BIT AND WAIT FOR AN INTERRUPT
2$: MOV #0,-(SP)
MOV #3$,-(SP) ;LSI-11 HACK
RTI
3$: MOV #4$,@VECTAO ;LOAD INTR. VECTOR
BIS #BIT6,@CSR ;ENABLE INTERRUPT
NOP
NOP
NOP
MOV @CSR,$BDDAT ;READ STATUS
MOV #CLRALL,@SFR ;CLEAR THE DEVICE
ERROR 13 ;WC/Z OVERFLOW FAILED TO GENERATE INTERRUPT
BR 5$ ;;BR TO CLEAN UP

4$: CMP (SP)+,(SP)+
5$: CLR @CSR
MOV #CLRALL,@SFR ;CLEAR THE DEVICE
MOV VECTA1,@VECTAO
CLR @VECTA1

```

```

1366
1367
1368
1369 007322 000004
1370 007324 012737 000010 001160
1371 007332 012777 004000 172416
1372 007340 012777 000014 172410
1373 007346 012777 177777 172376
1374 007354 012777 177776 172372
1375 007362 005077 172362
1376 007366 012777 000022 172352
1377 007374 052777 000001 172344
1378 007402 052777 000002 172346
1379 007410 042777 000002 172340
1380 007416 017737 172324 001126
1381 007424 012737 040022 001124
1382 007432 023737 001124 001126
1383 007440 001402
1384 007442 104012
1385 007444 000407
1386
1387 007446 005037 001124 001126 1$: CLR $GDDAT ;CLEAR THE EXPECTED
1388 007452 017737 172272 001126 MOV @OFF,$BDDAT ;READ THE ACTUAL
1389 007460 001401 BEQ TST31 ;;BR IF CLEARED
1390 007462 104012 ERROR 12 ;'WCA INC X OFF' IN MATRIX MODE CHANGED
1391 ;THE OFFSET REGISTER

```

```

:*****
:*TEST 30 VERIFY 'WCA OVFL' CLEARS 'ACTIVE'
:*****

```

```

TST30: SCOPE
MOV #10,$TIMES ;;DO 10 ITERATIONS
MOV #CLRALL,@SFR ;CLEAR DEVICE
MOV #TSTDMA!TSTCON,@SFR ;SET TEST DMA
MOV #-1,@WCR ;LOAD W.C. REG.
MOV #-2,@BAR ;LOAD BAR REG.
CLR @OFF ;CLEAR OFFSET REG.
MOV #BIT4!BIT1,@CSR ;ENABLE MATRIX MODE
BIS #BIT0,@CSR ;SET 'ACTIVE'
BIS #TESTZ,@SFR ;ENABLE 'TEST Z' PULSES
BIC #TESTZ,@SFR ;DISABLE 'TEST Z' PULSES
MOV @CSR,$BDDAT ;READ STATUS
CMP $GDDAT,$BDDAT ;COMPARE
BEQ 1$ ;;BR IF SAME
ERROR 12 ;'WCA OVFL' FAILED TO CLEAR 'ACTIVE'
BR TST31 ;;

```

```
1392 ::*****
1393 :*TEST 31      VERIFY JOYSTICK DONE FLOP SETS
1394 :*****
1395 007464 000004 TST31: SCOPE
1396 007466 012737 000040 001160 MOV #40,$TIMES ;;DO 40 ITERATIONS
1397 007474 012777 004000 172254 MOV #CLRALL,@SFR ;CLEAR THE DEVICE
1398 007502 052777 000001 172246 BIS #REDJOY,@SFR ;REQUEST JOYSTICK DATA
1399 007510 013700 002010 MOV CPUDL1,R0 ;LOAD DELAY COUNTER
1400 007514 105777 172236 1$: TSTB @SFR ;WAIT FOR JOYSTICK READY
1401 007520 100411 BMI 2$ ;BR IF SET
1402 007522 005300 DEC R0 ;DELAY
1403 007524 001373 BNE 1$ ;BR IF NOT EXHAUSTED
1404 007526 017737 172224 001126 MOV @SFR,$BDDAT ;READ STATUS
1405 007534 012737 000200 001124 MOV #BIT7,$GDDAT ;LOAD EXPECTED
1406 007542 104014 ERROR 14 ;'JOYSTICK READY' FAILED TO SET
1407 ;NOW PERFORM A 'TST' INSTRUCTION TO THE JOYSTICK REGISTER
1408 ; THE ACCESS OF THIS BUS ADDRESS SHOULD CLEAR JOY READY FLOP'
1409 007544 005777 172212 2$: TST @JOY ;ADDRESS THE REGISTER
1410 007550 017737 172202 001126 MOV @SFR,$BDDAT ;READ STATUS
1411 007556 105737 001126 TSTB $BDDAT ;TEST IF THE BIT CLEARED
1412 007562 100003 BPL TST32 ;;BR IF YES
1413 007564 005037 001124 CLR $GDDAT ;LOAD EXPECTED
1414 007570 104014 ERROR 14 ;ADDRESSING THE JOYSTICK ADDRESS FAILED TO CLEAR
1415 :*****
1416 :*TEST 32      VERIFY THAT 'RESET' INSTRUCTION CLEARS THE JOY READY FLOP
1417 :*****
1418 007572 000004 TST32: SCOPE
1419 007574 012737 000040 001160 MOV #40,$TIMES ;;DO 40 ITERATIONS
1420 007602 012777 004000 172146 MOV #CLRALL,@SFR ;CLEAR THE DEVICE
1421 007610 052777 000001 172140 BIS #REDJOY,@SFR ;REQUEST JOYSTICK DATA
1422 007616 013700 002010 MOV CPUDL1,R0 ;LOAD DELAY
1423 007622 105777 172130 1$: TSTB @SFR ;WAIT FOR JOYSTICK READY
1424 007626 100411 BMI 2$ ;BR IF SET
1425 007630 005300 DEC R0 ;DELAY
1426 007632 001373 BNE 1$ ;BR IF NOT EXHAUSTED
1427 007634 017737 172116 001126 MOV @SFR,$BDDAT ;READ STATUS
1428 007642 012737 000200 001124 MOV #BIT7,$GDDAT ;LOAD EXPECTED VALUE
1429 007650 104014 ERROR 14 ;JOY READY FAILED TO SET
1430 ;NOW ISSUE A 'CLR ALL' AND VERIFY THE 'JOY READY' DOES NOT CLEAR
1431 007652 052777 004000 172076 2$: BIS #CLRALL,@SFR ;GENERATE 'CLR ALL'
1432 007660 017737 172072 001126 MOV @SFR,$BDDAT ;READ STATUS
1433 007666 012737 000200 001124 MOV #BIT7,$GDDAT ;LOAD EXPECTED VALUE
1434 007674 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE
1435 007702 001401 BEQ 3$ ;;BR IF SAME
1436 007704 104014 ERROR 14 ;'CLR ALL' CLEARED THE 'JOY READY' FLOP IN ERROR
1437 ;NOW ISSUE A BUS 'RESET' AND VERIFY THE JOY READY' CLEARS
1438 007706 000005 3$: RESET ;BUS 'INIT'
1439 007710 017737 172042 001126 MOV @SFR,$BDDAT ;READ STATUS
1440 007716 012737 000000 001124 MOV #0,$GDDAT ;LOAD EXPECTED
1441 007724 017737 172026 001126 MOV @SFR,$BDDAT ;READ STATUS
1442 007732 001401 BEQ TST33 ;;BR IF CLEARED
1443 007734 104014 ERROR 14 ;BUS INIT FAILED TO CLEAR JOY READY
```

```

1444
1445
1446      ;:*****
1447      ;*TEST 33      JOYSTICK DATA PATH = GAIN =0 ZB ENABLE -0 RES. = 000
1448      ;:*****
1448 007736 000004
1449 007740 012737 000010 001160 TST33: SCOPE
1450 007746 012777 004000 172002      MOV #10,$TIMES      ;;DO 10 ITERATIONS
1451 007754 012777 000014 171774      MOV #CLRALL,@SFR      ;CLEAR THE DEVICE
1452 007762 012777 000000 171756      MOV #TSTCON!TSTDMA,@SFR ;SET TEST CONTROLLER FLOP
1453 007770 052777 000001 171760      MOV #0,@CSR      ;LOAD CSR REGISTER
1454 007776 105777 171754      BIS #REDJOY,@SFR      ;REQUEST JOYSTICE DATA
1455 010002 100375      1$: TSTB @SFR      ;WAIT FOR JOYSTICE READY
1456 010004 017737 171752 001126      BPL 1$
1457 010012 012737 000000 001124      MOV @JOY,$BDDAT      ;READ THE REGISTER
1458 010020 023737 001124 001126      MOV #0,$GDDAT      ;LOAD EXPECTED
1459 010026 001401      CMP $GDDAT,$BDDAT      ;COMPARE
1460 010030 104015      BEQ TST34      ;;BR IF SAME
1461      ERROR 15      ;JOYSTICK DATA PATH BIT SET
  
```

```

1462
1463      ;:*****
1464      ;*TEST 34      JOYSTICK DATA PATH = GAIN =1
1465      ;:*****
1465 010032 000004
1466 010034 012737 000010 001160 TST34: SCOPE
1467 010042 012777 004000 171706      MOV #10,$TIMES      ;;DO 10 ITERATIONS
1468 010050 012777 000014 171700      MOV #CLRALL,@SFR      ;CLEAR THE DEVICE
1469 010056 012777 002000 171662      MOV #TSTCON!TSTDMA,@SFR ;SET TEST CONTROLLER FLOP
1470 010064 052777 000001 171664      MOV #2000,@CSR      ;LOAD CSR REGISTER
1471 010072 105777 171660      BIS #REDJOY,@SFR      ;REQUEST JOYSTICE DATA
1472 010076 100375      1$: TSTB @SFR      ;WAIT FOR JOYSTICE READY
1473 010100 017737 171656 001126      BPL 1$
1474 010106 012737 124250 001124      MOV @JOY,$BDDAT      ;READ THE REGISTER
1475 010114 023737 001124 001126      MOV #124250,$GDDAT      ;LOAD EXPECTED
1476 010122 001401      CMP $GDDAT,$BDDAT      ;COMPARE
1477 010124 104015      BEQ TST35      ;;BR IF SAME
1478      ERROR 15      ;JOYSTICK DATA PATH ERROR
  
```

```

1479
1480      ;:*****
1481      ;*TEST 35      JOYSTICK DATA PATH = ZB ENABLF =1
1482      ;:*****
1482 010126 000004
1483 010130 012737 000010 001160 TST35: SCOPE
1484 010136 012777 004000 171612      MOV #10,$TIMES      ;;DO 10 ITERATIONS
1485 010144 012777 000014 171604      MOV #CLRALL,@SFR      ;CLEAR THE DEVICE
1486 010152 012777 004000 171566      MOV #TSTCON!TSTDMA,@SFR ;SET TEST CONTROLLER FLOP
1487 010160 052777 000001 171570      MOV #4000,@CSR      ;LOAD CSR REGISTER
1488 010166 105777 171564      BIS #REDJOY,@SFR      ;REQUEST JOYSTICE DATA
1489 010172 100375      1$: TSTB @SFR      ;WAIT FOR JOYSTICE READY
1490 010174 017737 171562 001126      BPL 1$
1491 010202 012737 050120 001124      MOV @JOY,$BDDAT      ;READ THE REGISTER
1492 010210 023737 001124 001126      MOV #050120,$GDDAT      ;LOAD EXPECTED
1493 010216 001401      CMP $GDDAT,$BDDAT      ;COMPARE
1494 010220 104015      BEQ TST36      ;;BR IF SAME
1494      ERROR 15      ;JOYSTICK DATA PATH ERROR
  
```

```
1495
1496
1497
1498 010222 000004
1499 010224 012737 000010 001160
1500 010232 012777 004000 171516
1501 010240 012777 000014 171510
1502 010246 012777 000023 171472
1503 010254 052777 000001 171474
1504 010262 105777 171470
1505 010266 100375
1506 010270 017737 171466 001126
1507 010276 012737 000401 001124
1508 010304 023737 001124 001126
1509 010312 001401
1510 010314 104015
1511
1512
1513
1514
1515 010316 000004
1516 010320 012737 000010 001160
1517 010326 012777 004000 171422
1518 010334 012777 000014 171414
1519 010342 012777 000025 171376
1520 010350 052777 000001 171400
1521 010356 105777 171374
1522 010362 100375
1523 010364 017737 171372 001126
1524 010372 012737 001002 001124
1525 010400 023737 001124 001126
1526 010406 001401
1527 010410 104015
1528
1529
1530
1531
1532 010412 000004
1533 010414 012737 000010 001160
1534 010422 012777 004000 171326
1535 010430 012777 000014 171320
1536 010436 012777 000031 171302
1537 010444 052777 000001 171304
1538 010452 105777 171300
1539 010456 100375
1540 010460 017737 171276 001126
1541 010466 012737 002004 001124
1542 010474 023737 001124 001126
1543 010502 001401
1544 010504 104015
```

```
*****
*TEST 36 JOYSTICK DATA PATH RES. = 001
*****
TST36: SCOPE
MOV #10,$TIMES ;;DO 10 ITERATIONS
MOV #CLRALL,@SFR ;CLEAR THE DEVICE
MOV #TSTCON!TSTDMA,@SFR ;SET TEST CONTROLLER FLOP
MOV #23,@CSR ;LOAD CSR REGISTER
BIS #REDJOY,@SFR ;REQUEST JOYSTICE DATA
1$: TSTB @SFR ;WAIT FOR JOYSTICE READY
BPL 1$
MOV @JOY,$BDDAT ;READ THE REGISTER
MOV #401,$GDDAT ;LOAD EXPECTED
CMP $GDDAT,$BDDAT ;COMPARE
BEQ TST37 ;;BR IF SAME
ERROR 15 ;JOYSTICK DATA PATH ERROR RES. = 001
```

```
*****
*TEST 37 JOYSTICK DATA PATH RES. = 010
*****
TST37: SCOPE
MOV #10,$TIMES ;;DO 10 ITERATIONS
MOV #CLRALL,@SFR ;CLEAR THE DEVICE
MOV #TSTCON!TSTDMA,@SFR ;SET TEST CONTROLLER FLOP
MOV #25,@CSR ;LOAD CSR REGISTER
BIS #REDJOY,@SFR ;REQUEST JOYSTICE DATA
1$: TSTB @SFR ;WAIT FOR JOYSTICE READY
BPL 1$
MOV @JOY,$BDDAT ;READ THE REGISTER
MOV #1002,$GDDAT ;LOAD EXPECTED
CMP $GDDAT,$BDDAT ;COMPARE
BEQ TST40 ;;BR IF SAME
ERROR 15 ;JOYSTICK DATA PATH ERROR RES. = 010
```

```
*****
*TEST 40 JOYSTICK DATA PATH RES. = 100
*****
TST40: SCOPE
MOV #10,$TIMES ;;DO 10 ITERATIONS
MOV #CLRALL,@SFR ;CLEAR THE DEVICE
MOV #TSTCON!TSTDMA,@SFR ;SET TEST CONTROLLER FLOP
MOV #31,@CSR ;LOAD CSR REGISTER
BIS #REDJOY,@SFR ;REQUEST JOYSTICE DATA
1$: TSTB @SFR ;WAIT FOR JOYSTICE READY
BPL 1$
MOV @JOY,$BDDAT ;READ THE REGISTER
MOV #2004,$GDDAT ;LOAD EXPECTED
CMP $GDDAT,$BDDAT ;COMPARE
BEQ TST41 ;;BR IF SAME
ERROR 15 ;JOY STICK DATA PATH ERROR RES. = 100
```



```

1545
1546
1547
1548 010506 000004
1549 010510 012737 000010 001160
1550 010516 012777 004000 171232
1551 010524 012777 000014 171224
1552 010532 012777 000421 171206
1553 010540 052777 000001 171210
1554 010546 105777 171204
1555 010552 100375
1556 010554 017737 171202 001126
1557 010562 012737 000401 001124
1558 010570 023737 001124 001126
1559 010576 001401
1560 010600 104016
1561
1562
1563
1564
1565 010602 000004
1566 010604 012737 000010 001160
1567 010612 012777 004000 171136
1568 010620 012777 000014 171130
1569 010626 012777 002437 171112
1570 010634 052777 000001 171114
1571 010642 105777 171110
1572 010646 100375
1573 010650 017737 171106 001126
1574 010656 012737 130260 001124
1575 010664 023737 001124 001126
1576 010672 001401
1577 010674 104016
1578
1579
1580
1581
1582
1583 010676 000004
1584 010700 012737 000010 001160
1585 010706 012777 004000 171042
1586 010714 012777 000014 171034
1587 010722 012777 006437 171016
1588 010730 052777 000001 171020
1589 010736 105777 171014
1590 010742 100375
1591 010744 017737 171012 001126
1592 010752 012737 177777 001124
1593 010760 023737 001124 001126
1594 010766 001401
1595 010770 104016
1596
  
```

```

*****
*TEST 41 VERIFY THE DATA INCREMENT FUNCTION
*****
TST41: SCOPE
MOV #10,$TIMES ;;DO 10 ITERATIONS
MOV #CLRALL,@SFR ;CLEAR THE DEVICE
MOV #TSTCON!TSTDMA,@SFR ;SET TEST CONTROLLER FLOP
MOV #421,@CSR ;LOAD CSR REGISTER
BIS #REDJOY,@SFR ;REQUEST JOYSTICE DATA
1$: TSTB @SFR ;WAIT FOR JOYSTICE READY
BPL 1$
MOV @JOY,$BDDAT ;READ THE REGISTER
MOV #401,$GDDAT ;LOAD EXPECTED
CMP $GDDAT,$BDDAT ;COMPARE
BEQ TST42 ;;BR IF SAME
ERROR 16 ;MAINT. CAM01 FAILED TO INCREMENT DATA REGISTER
  
```

```

*****
*TEST 42 VERIFY THE DATA INCREMENT CARRY BIT
*****
TST42: SCOPE
MOV #10,$TIMES ;;DO 10 ITERATIONS
MOV #CLRALL,@SFR ;CLEAR THE DEVICE
MOV #TSTCON!TSTDMA,@SFR ;SET TEST CONTROLLER FLOP
MOV #2437,@CSR ;LOAD CSR REGISTER
BIS #REDJOY,@SFR ;REQUEST JOYSTICE DATA
1$: TSTB @SFR ;WAIT FOR JOYSTICE READY
BPL 1$
MOV @JOY,$BDDAT ;READ THE REGISTER
MOV #130260,$GDDAT ;LOAD EXPECTED
CMP $GDDAT,$BDDAT ;COMPARE
BEQ TST43 ;;BR IF SAME
ERROR 16 ;MAINT. CAM01 WITH RES.=7, G-1, ZB =0
;FAILED TO CAUSE DATA INCREMENT CARRY PROPERLY
  
```

```

*****
*TEST 43 VERIFY THE DATA INCREMENT FUNCTION IS INHIBITED
*****
TST43: SCOPE
MOV #10,$TIMES ;;DO 10 ITERATIONS
MOV #CLRALL,@SFR ;CLEAR THE DEVICE
MOV #TSTCON!TSTDMA,@SFR ;SET TEST CONTROLLER FLOP
MOV #6437,@CSR ;LOAD CSR REGISTER
BIS #REDJOY,@SFR ;REQUEST JOYSTICE DATA
1$: TSTB @SFR ;WAIT FOR JOYSTICE READY
BPL 1$
MOV @JOY,$BDDAT ;READ THE REGISTER
MOV #177777,$GDDAT ;LOAD EXPECTED
CMP $GDDAT,$BDDAT ;COMPARE
BEQ TST44 ;;BR IS SAME
ERROR 16 ;FAILED TO INHIBIT DATA INCREMENT FUNCTION
;IF THE BAD DATA WAS 0
  
```

```

1597
1598
1599
1600 010772 000004
1601 010774 012737 000010 001160
1602 011002 012777 004000 170746
1603 011010 012777 000014 170740
1604 011016 012777 001023 170722
1605 011024 052777 000001 170724
1606 011032 105777 170720
1607 011036 100375
1608 011040 017737 170716 001126
1609 011046 012737 000000 001124
1610 011054 023737 001124 001126
1611 011062 001401
1612 011064 104017
1613
1614
1615
1616
1617
1618 011066 000004
1619 011070 012737 000010 001160
1620 011076 012777 004000 170652
1621 011104 012777 000014 170644
1622 011112 012777 007037 170626
1623 011120 052777 000001 170630
1624 011126 105777 170624
1625 011132 100375
1626 011134 017737 170622 001126
1627 011142 012737 177376 001124
1628 011150 023737 001124 001126
1629 011156 001401
1630 011160 104017
1631
1632
1633
1634
1635 011162 000004
1636 011164 012737 000010 001160
1637 011172 012777 004000 170556
1638 011200 012777 000014 170550
1639 011206 012777 001021 170532
1640 011214 052777 000001 170534
1641 011222 105777 170530
1642 011226 100375
1643 011230 017737 170526 001126
1644 011236 012737 000000 001124
1645 011244 023737 001124 001126
1646 011252 001401
1647 011254 104017
1648

:*****
:*TEST 44 VERIFY THE DATA DECREMENT FUNCTION
:*****
TST44: SCOPE
MOV #10,$TIMES ;;DO 10 ITERATIONS
MOV #CLRALL,@SFR ;CLEAR THE DEVICE
MOV #TSTCON!TSTDMA,@SFR ;SET TEST CONTROLLER FLOP
MOV #1023,@CSR ;LOAD CSR REGISTER
BIS #REDJOY,@SFR ;REQUEST JOYSTICE DATA
1$: TSTB @SFR ;WAIT FOR JOYSTICE READY
BPL 1$
MOV @JOY,$BDDAT ;READ THE REGISTER
MOV #0,$GDDAT ;LOAD EXPECTED
CMP $GDDAT,$BDDAT ;COMPARE
BEQ TST45 ;;BR IF SAME
ERROR 17 ;IF DATA WAS 401, THE DATA DECREMENT FUNCTION FAILED
;OTHERWISE DECREMENTED DATA ERROR

:*****
:*TEST 45 VERIFY THE DATA DECREMENT BORROW
:*****
TST45: SCOPE
MOV #10,$TIMES ;;DO 10 ITERATIONS
MOV #CLRALL,@SFR ;CLEAR THE DEVICE
MOV #TSTCON!TSTDMA,@SFR ;SET TEST CONTROLLER FLOP
MOV #7037,@CSR ;LOAD CSR REGISTER
BIS #REDJOY,@SFR ;REQUEST JOYSTICE DATA
1$: TSTB @SFR ;WAIT FOR JOYSTICE READY
BPL 1$
MOV @JOY,$BDDAT ;READ THE REGISTER
MOV #177376,$GDDAT ;LOAD EXPECTED
CMP $GDDAT,$BDDAT ;COMPARE
BEQ TST46 ;;BR IF SAME
ERROR 17 ;DECREMENTED DATA ERROR

:*****
:*TEST 46 VERIFY THE DATA DECREMENT FUNCTION IS INHIBITED
:*****
TST46: SCOPE
MOV #10,$TIMES ;;DO 10 ITERATIONS
MOV #CLRALL,@SFR ;CLEAR THE DEVICE
MOV #TSTCON!TSTDMA,@SFR ;SET TEST CONTROLLER FLOP
MOV #1021,@CSR ;LOAD CSR REGISTER
BIS #REDJOY,@SFR ;REQUEST JOYSTICE DATA
1$: TSTB @SFR ;WAIT FOR JOYSTICE READY
BPL 1$
MOV @JOY,$BDDAT ;READ THE REGISTER
MOV #0,$GDDAT ;LOAD EXPECTED
CMP $GDDAT,$BDDAT ;COMPARE
BEQ TST47 ;;BR IF SAME
ERROR 17 ;INHIBIT DECREMENT FUNCTION ERROR
;IF DATA WAS 177777
    
```

```

1649
1650
1651
1652 011256 000004
1653 011260 012737 000010 001160
1654 011266 012777 004000 170462
1655 011274 012777 000014 170454
1656 011302 012777 000036 170436
1657 011310 052777 000002 170440
1658 011316 052777 000001 170422
1659 011324 042777 000002 170424
1660 011332 017737 170422 001126
1661 011340 012737 003407 001124
1662 011346 023737 001124 001126
1663 011354 001401
1664 011356 104020
1665
1666
1667
1668
1669 011360 000004
1670 011362 012737 000010 001160
1671 011370 012777 004000 170360
1672 011376 012777 000014 170352
1673 011404 012777 002036 170334
1674 011412 052777 000002 170336
1675 011420 052777 000001 170320
1676 011426 042777 000002 170322
1677 011434 017737 170320 001126
1678 011442 012737 127657 001124
1679 011450 023737 001124 001126
1680 011456 001401
1681 011460 104020
1682
1683
1684
1685
1686 011462 000004
1687 011464 012737 000010 001160
1688 011472 012777 004000 170256
1689 011500 012777 000014 170250
1690 011506 012777 004036 170232
1691 011514 052777 000002 170234
1692 011522 052777 000001 170216
1693 011530 042777 000002 170220
1694 011536 017737 170216 001126
1695 011544 012737 053527 001124
1696 011552 023737 001124 001126
1697 011560 001401
1698 011562 104020
1699
  
```

```

:*****
:*TEST 47 TEST ADDRESS MAKER - MATRIX MODE - RES = 7 GAIN = 0 ZB ENABLE = 0
:*****
TST47: SCOPE
MOV #10,$TIMES ;;DO 10 ITERATIONS
MOV #CLRALL,@SFR ;CLEAR DEVICE
MOV #TSTDMA!TSTCON,@SFR ;SET 'TEST DMA AND CONTROL'
MOV #36,@CSR ;LOAD RESOLUTION, GAIN, ZB ENABLE VALUE
BIS #TESTZ,@SFR ;ENABLE 'TEST Z' PULSES
BIS #BITO,@CSR ;SET ENABLE NCV11
BIC #TESTZ,@SFR ;DISABLE 'TEST Z' PULSES
MOV @ADM,$BDDAT ;READ THE ADDRESS DATA MAKER
MOV #3407,$GDDAT ;LOAD EXPECTED VALUE
CMP $GDDAT,$BDDAT ;COMPARE EXPECTED TO READ
BEQ TST50 ;;BR IF SAME
ERROR 20 ;INCORRECT ADDRESS MAKER DATA
; RESOLUTION = 7 GAIN = 0 ZB ENABLE = 0
:*****
:*TEST 50 TEST ADDRESS MAKER - MATRIX MODE - RES = 7 GAIN = 1 ZB ENABLE = 0
:*****
TST50: SCOPE
MOV #10,$TIMES ;;DO 10 ITERATIONS
MOV #CLRALL,@SFR ;CLEAR DEVICE
MOV #TSTDMA!TSTCON,@SFR ;SET 'TEST DMA AND CONTROL'
MOV #2036,@CSR ;LOAD RESOLUTION, GAIN, ZB ENABLE VALUE
BIS #TESTZ,@SFR ;ENABLE 'TEST Z' PULSES
BIS #BITO,@CSR ;SET ENABLE NCV11
BIC #TESTZ,@SFR ;DISABLE 'TEST Z' PULSES
MOV @ADM,$BDDAT ;READ THE ADDRESS DATA MAKER
MOV #127657,$GDDAT ;LOAD EXPECTED VALUE
CMP $GDDAT,$BDDAT ;COMPARE EXPECTED TO READ
BEQ TST51 ;;BR IF SAME
ERROR 20 ;INCORRECT ADDRESS MAKER DATA
; RESOLUTION = 7 GAIN = 1 ZB ENABLE = 0
:*****
:*TEST 51 TEST ADDRESS MAKER - MATRIX MODE - RES = 7 GAIN = 0 ZB ENABLE = 1
:*****
TST51: SCOPE
MOV #10,$TIMES ;;DO 10 ITERATIONS
MOV #CLRALL,@SFR ;CLEAR DEVICE
MOV #TSTDMA!TSTCON,@SFR ;SET 'TEST DMA AND CONTROL'
MOV #4036,@CSR ;LOAD RESOLUTION, GAIN, ZB ENABLE VALUE
BIS #TESTZ,@SFR ;ENABLE 'TEST Z' PULSES
BIS #BITO,@CSR ;SET ENABLE NCV11
BIC #TESTZ,@SFR ;DISABLE 'TEST Z' PULSES
MOV @ADM,$BDDAT ;READ THE ADDRESS DATA MAKER
MOV #053527,$GDDAT ;LOAD EXPECTED VALUE
CMP $GDDAT,$BDDAT ;COMPARE EXPECTED TO READ
BEQ TST52 ;;BR IF SAME
ERROR 20 ;INCORRECT ADDRESS MAKER DATA
; RESOLUTION = 7 GAIN = 0 ZB ENABLE = 1
  
```

1700  
1701  
1702  
1703 011564 000004  
1704 011566 012737 000010 001160  
1705 011574 012777 004000 170154  
1706 011602 012777 000014 170146  
1707 011610 012777 000034 170130  
1708 011616 052777 000002 170132  
1709 011624 052777 000001 170114  
1710 011632 042777 000002 170116  
1711 011640 017737 170114 001126  
1712 011646 012737 001406 001124  
1713 011654 023737 001124 001126  
1714 011662 001401  
1715 011664 104020  
1716  
1717  
1718  
1719  
1720 011666 000004  
1721 011670 012737 000010 001160  
1722 011676 012777 004000 170052  
1723 011704 012777 000014 170044  
1724 011712 012777 002034 170026  
1725 011720 052777 000002 170030  
1726 011726 052777 000001 170012  
1727 011734 042777 000002 170014  
1728 011742 017737 170012 001126  
1729 011750 012737 053656 001124  
1730 011756 023737 001124 001126  
1731 011764 001401  
1732 011766 104020  
1733  
1734  
1735  
1736  
1737 011770 000004  
1738 011772 012737 000010 001160  
1739 012000 012777 004000 167750  
1740 012006 012777 000014 167742  
1741 012014 012777 004034 167724  
1742 012022 052777 000002 167726  
1743 012030 052777 000001 167710  
1744 012036 042777 000002 167712  
1745 012044 017737 167710 001126  
1746 012052 012737 125526 001124  
1747 012060 023737 001124 001126  
1748 012066 001401  
1749 012070 104020  
1750

```
*****  
*TEST 52 TEST ADDRESS MAKER - MATRIX MODE - RES - 6 GAIN = 0 ZB ENABLE = 0  
*****  
TST52: SCOPE  
MOV #10,$TIMES ;;DO 10 ITERATIONS  
MOV #CLRALL,@SFR ;CLEAR DEVICE  
MOV #TSTDMA!TSTCON,@SFR ;SET 'TEST DMA AND CONTROL'  
MOV #34,@CSR ;LOAD RESOLUTION, GAIN, ZB ENABLE VALUE  
BIS #TESTZ,@SFR ;ENABLE 'TEST Z' PULSES  
BIS #BITO,@CSR ;SET ENABLE NCV11  
BIC #TESTZ,@SFR ;DISABLE 'TEST Z' PULSES  
MOV @ADM,$BDDAT ;READ THE ADDRESS DATA MAKER  
MOV #1406,$GDDAT ;LOAD EXPECTED VALUE  
CMP $GDDAT,$BDDAT ;COMPARE EXPECTED TO READ  
BEQ TST53 ;;BR IF SAME  
ERROR 20 ;INCORRECT ADDRESS MAKER DATA  
RESOLUTION = 6 GAIN = 0 ZB ENABLE = 0  
*****  
*TEST 53 TEST ADDRESS MAKER - MATRIX MODE - RES = 6 GAIN = 1 ZB ENABLE = 0  
*****  
TST53: SCOPE  
MOV #10,$TIMES ;;DO 10 ITERATIONS  
MOV #CLRALL,@SFR ;CLEAR DEVICE  
MOV #TSTDMA!TSTCON,@SFR ;SET 'TEST DMA AND CONTROL'  
MOV #2034,@CSR ;LOAD RESOLUTION, GAIN, ZB ENABLE VALUE  
BIS #TESTZ,@SFR ;ENABLE 'TEST Z' PULSES  
BIS #BITO,@CSR ;SET ENABLE NCV11  
BIC #TESTZ,@SFR ;DISABLE 'TEST Z' PULSES  
MOV @ADM,$BDDAT ;READ THE ADDRESS DATA MAKER  
MOV #53656,$GDDAT ;LOAD EXPECTED VALUE  
CMP $GDDAT,$BDDAT ;COMPARE EXPECTED TO READ  
BEQ TST54 ;;BR IF SAME  
ERROR 20 ;INCORRECT ADDRESS MAKER DATA  
RESOLUTION = 6 GAIN = 1 ZB ENABLE = 0  
*****  
*TEST 54 TEST ADDRESS MAKER - MATRIX MODE - RES = 6 GAIN = 0 ZB ENABLE = 1  
*****  
TST54: SCOPE  
MOV #10,$TIMES ;;DO 10 ITERATIONS  
MOV #CLRALL,@SFR ;CLEAR DEVICE  
MOV #TSTDMA!TSTCON,@SFR ;SET 'TEST DMA AND CONTROL'  
MOV #4034,@CSR ;LOAD RESOLUTION, GAIN, ZB ENABLE VALUE  
BIS #TESTZ,@SFR ;ENABLE 'TEST Z' PULSES  
BIS #BITO,@CSR ;SET ENABLE NCV11  
BIC #TESTZ,@SFR ;DISABLE 'TEST Z' PULSES  
MOV @ADM,$BDDAT ;READ THE ADDRESS DATA MAKER  
MOV #125526,$GDDAT ;LOAD EXPECTED VALUE  
CMP $GDDAT,$BDDAT ;COMPARE EXPECTED TO READ  
BEQ TST55 ;;BR IF SAME  
ERROR 20 ;INCORRECT ADDRESS MAKER DATA  
RESOLUTION = 6 GAIN = 0 ZB ENABLE = 1
```

```

1751
1752
1753
1754 012072 000004
1755 012074 012737 000010 001160
1756 012102 012777 004000 167646
1757 012110 012777 000014 167640
1758 012116 012777 000032 167622
1759 012124 052777 000002 167624
1760 012132 052777 000001 167606
1761 012140 042777 000002 167610
1762 012146 017737 167606 001126
1763 012154 012737 000402 001124
1764 012162 023737 001124 001126
1765 012170 001401
1766 012172 104020
1767
1768
1769
1770
1771 012174 000004
1772 012176 012737 000010 001160
1773 012204 012777 004000 167544
1774 012212 012777 000014 167536
1775 012220 012777 002032 167520
1776 012226 052777 000002 167522
1777 012234 052777 000001 167504
1778 012242 042777 000002 167506
1779 012250 017737 167504 001126
1780 012256 012737 025526 001124
1781 012264 023737 001124 001126
1782 012272 001401
1783 012274 104020
1784
1785
1786
1787
1788 012276 000004
1789 012300 012737 000010 001160
1790 012306 012777 004000 167442
1791 012314 012777 000014 167434
1792 012322 012777 004032 167416
1793 012330 052777 000002 167420
1794 012336 052777 000001 167402
1795 012344 042777 000002 167404
1796 012352 017737 167402 001126
1797 012360 012737 052452 001124
1798 012366 023737 001124 001126
1799 012374 001401
1800 012376 104020
1801

```

```

*****
*TEST 55 TEST ADDRESS MAKER - MATRIX MODE - RES 5 GAIN - 0 ZB ENABLE = 0
*****
TST55: SCOPE
MOV #10,$TIMES ;;DO 10 ITERATIONS
MOV #CLRALL,@SFR ;CLEAR DEVICE
MOV #TSTDMA!TSTCON,@SFR ;SET 'TEST DMA AND CONTROL'
MOV #32,@CSR ;LOAD RESOLUTION, GAIN, ZB ENABLE VALUE
BIS #TESTZ,@SFR ;ENABLE 'TEST Z' PULSES
BIS #BIT0,@CSR ;SET ENABLE NCV11
BIC #TESTZ,@SFR ;DISABLE 'TEST Z' PULSES
MOV @ADM,$BDDAT ;READ THE ADDRESS DATA MAKER
MOV #402,$GDDAT ;LOAD EXPECTED VALUE
CMP $GDDAT,$BDDAT ;COMPARE EXPECTED TO READ
BEQ TST56 ;;BR IF SAME
ERROR 20 ;INCORRECT ADDRESS MAKER DATA
RESOLUTION = 5 GAIN = 0 ZB ENABLE = 0
*****
*TEST 56 TEST ADDRESS MAKER - MATRIX MODE - RES = 5 GAIN = 1 ZB ENABLE - 0
*****
TST56: SCOPE
MOV #10,$TIMES ;;DO 10 ITERATIONS
MOV #CLRALL,@SFR ;CLEAR DEVICE
MOV #TSTDMA!TSTCON,@SFR ;SET 'TEST DMA AND CONTROL'
MOV #2032,@CSR ;LOAD RESOLUTION, GAIN, ZB ENABLE VALUE
BIS #TESTZ,@SFR ;ENABLE 'TEST Z' PULSES
BIS #BIT0,@CSR ;SET ENABLE NCV11
BIC #TESTZ,@SFR ;DISABLE 'TEST Z' PULSES
MOV @ADM,$BDDAT ;READ THE ADDRESS DATA MAKER
MOV #25526,$GDDAT ;LOAD EXPECTED VALUE
CMP $GDDAT,$BDDAT ;COMPARE EXPECTED TO READ
BEQ TST57 ;;BR IF SAME
ERROR 20 ;INCORRECT ADDRESS MAKER DATA
RESOLUTION = 5 GAIN = 1 ZB ENABLE = 0
*****
*TEST 57 TEST ADDRESS MAKER - MATRIX MODE - RES = 5 GAIN - 0 ZB ENABLE 1
*****
TST57: SCOPE
MOV #10,$TIMES ;;DO 10 ITERATIONS
MOV #CLRALL,@SFR ;CLEAR DEVICE
MOV #TSTDMA!TSTCON,@SFR ;SET 'TEST DMA AND CONTROL'
MOV #4032,@CSR ;LOAD RESOLUTION, GAIN, ZB ENABLE VALUE
BIS #TESTZ,@SFR ;ENABLE 'TEST Z' PULSES
BIS #BIT0,@CSR ;SET ENABLE NCV11
BIC #TESTZ,@SFR ;DISABLE 'TEST Z' PULSES
MOV @ADM,$BDDAT ;READ THE ADDRESS DATA MAKER
MOV #52452,$GDDAT ;LOAD EXPECTED VALUE
CMP $GDDAT,$BDDAT ;COMPARE EXPECTED TO READ
BEQ TST60 ;;BR IF SAME
ERROR 20 ;INCORRECT ADDRESS MAKER DATA
RESOLUTION = 5 GAIN = 0 ZB ENABLE = 1

```

1802  
1803  
1804  
1805 012400 000004  
1806 012402 012737 000010 001160  
1807 012410 012777 004000 167340  
1808 012416 012777 000014 167332  
1809 012424 012777 000030 167314  
1810 012432 052777 000002 167316  
1811 012440 052777 000001 167300  
1812 012446 042777 000002 167302  
1813 012454 017737 167300 001126  
1814 012462 012737 000202 001124  
1815 012470 023737 001124 001126  
1816 012476 001401  
1817 012500 104020  
1818  
1819  
1820  
1821  
1822 012502 000004  
1823 012504 012737 000010 001160  
1824 012512 012777 004000 167236  
1825 012520 012777 000014 167230  
1826 012526 012777 002030 167212  
1827 012534 052777 000002 167214  
1828 012542 052777 000001 167176  
1829 012550 042777 000002 167200  
1830 012556 017737 167176 001126  
1831 012564 012737 012726 001124  
1832 012572 023737 001124 001126  
1833 012600 001401  
1834 012602 104020  
1835  
1836  
1837  
1838  
1839 012604 000004  
1840 012606 012737 000010 001160  
1841 012614 012777 004000 167134  
1842 012622 012777 000014 167126  
1843 012630 012777 004030 167110  
1844 012636 052777 000002 167112  
1845 012644 052777 000001 167074  
1846 012652 042777 000002 167076  
1847 012660 017737 167074 001126  
1848 012666 012737 025252 001124  
1849 012674 023737 001124 001126  
1850 012702 001401  
1851 012704 104020  
1852

```
*****  
*TEST 60 TEST ADDRESS MAKER - MATRIX MODE - RES 4 GAIN - 0 ZB ENABLE - 0  
*****  
TST60: SCOPE  
MOV #10,$TIMES ;;DO 10 ITERATIONS  
MOV #CLRALL,@SFR ;CLEAR DEVICE  
MOV #TSTDMA!TSTCON,@SFR ;SET 'TEST DMA AND CONTROL'  
MOV #30,@CSR ;LOAD RESOLUTION, GAIN, ZB ENABLE VALUE  
BIS #TESTZ,@SFR ;ENABLE 'TEST Z' PULSES  
BIS #BIT0,@CSR ;SET ENABLE NCV11  
BIC #TESTZ,@SFR ;DISABLE 'TEST Z' PULSES  
MOV @ADM,$BDDAT ;READ THE ADDRESS DATA MAKER  
MOV #202,$GDDAT ;LOAD EXPECTED VALUE  
CMP $GDDAT,$BDDAT ;COMPARE EXPECTED TO READ  
BEQ TST61 ;;BR IF SAME  
ERROR 20 ;INCORRECT ADDRESS MAKER DATA  
RESOLUTION = 4 GAIN = 0 ZB ENABLE = 0  
*****  
*TEST 61 TEST ADDRESS MAKER - MATRIX MODE - RES = 4 GAIN = 1 ZB ENABLE 0  
*****  
TST61: SCOPE  
MOV #10,$TIMES ;;DO 10 ITERATIONS  
MOV #CLRALL,@SFR ;CLEAR DEVICE  
MOV #TSTDMA!TSTCON,@SFR ;SET 'TEST DMA AND CONTROL'  
MOV #2030,@CSR ;LOAD RESOLUTION, GAIN, ZB ENABLE VALUE  
BIS #TESTZ,@SFR ;ENABLE 'TEST Z' PULSES  
BIS #BIT0,@CSR ;SET ENABLE NCV11  
BIC #TESTZ,@SFR ;DISABLE 'TEST Z' PULSES  
MOV @ADM,$BDDAT ;READ THE ADDRESS DATA MAKER  
MOV #012726,$GDDAT ;LOAD EXPECTED VALUE  
CMP $GDDAT,$BDDAT ;COMPARE EXPECTED TO READ  
BEQ TST62 ;;BR IF SAME  
ERROR 20 ;INCORRECT ADDRESS MAKER DATA  
RESOLUTION = 4 GAIN = 1 ZB ENABLE = 0  
*****  
*TEST 62 TEST ADDRESS MAKER - MATRIX MODE - RES = 4 GAIN = 0 ZB ENABLE = 1  
*****  
TST62: SCOPE  
MOV #10,$TIMES ;;DO 10 ITERATIONS  
MOV #CLRALL,@SFR ;CLEAR DEVICE  
MOV #TSTDMA!TSTCON,@SFR ;SET 'TEST DMA AND CONTROL'  
MOV #4030,@CSR ;LOAD RESOLUTION, GAIN, ZB ENABLE VALUE  
BIS #TESTZ,@SFR ;ENABLE 'TEST Z' PULSES  
BIS #BIT0,@CSR ;SET ENABLE NCV11  
BIC #TESTZ,@SFR ;DISABLE 'TEST Z' PULSES  
MOV @ADM,$BDDAT ;READ THE ADDRESS DATA MAKER  
MOV #025252,$GDDAT ;LOAD EXPECTED VALUE  
CMP $GDDAT,$BDDAT ;COMPARE EXPECTED TO READ  
BEQ TST63 ;;BR IF SAME  
ERROR 20 ;INCORRECT ADDRESS MAKER DATA  
RESOLUTION - 4 GAIN = 0 ZB ENABLE = 1
```

1853  
1854  
1855  
1856 012706 000004  
1857 012710 012737 000010 001160  
1858 012716 012777 004000 167032  
1859 012724 012777 000014 167024  
1860 012732 012777 000026 167006  
1861 012740 052777 000002 167010  
1862 012746 052777 000001 166772  
1863 012754 042777 000002 166774  
1864 012762 017737 166772 001126  
1865 012770 012737 000000 001124  
1866 012776 023737 001124 001126  
1867 013004 001401  
1868 013006 104020  
1869  
1870  
1871  
1872  
1873 013010 000004  
1874 013012 012737 000010 001160  
1875 013020 012777 004000 166730  
1876 013026 012777 000014 166722  
1877 013034 012777 002026 166704  
1878 013042 052777 000002 166706  
1879 013050 052777 000001 166670  
1880 013056 042777 000002 166672  
1881 013064 017737 166670 001126  
1882 013072 012737 005252 001124  
1883 013100 023737 001124 001126  
1884 013106 001401  
1885 013110 104020  
1886  
1887  
1888  
1889  
1890 013112 000004  
1891 013114 012737 000010 001160  
1892 013122 012777 004000 166626  
1893 013130 012777 000014 166620  
1894 013136 012777 004026 166602  
1895 013144 052777 000002 166604  
1896 013152 052777 000001 166566  
1897 013160 042777 000002 166570  
1898 013166 017737 166566 001126  
1899 013174 012737 012424 001124  
1900 013202 023737 001124 001126  
1901 013210 001401  
1902 013212 104020  
1903

```
*****  
*TEST 63 TEST ADDRESS MAKER - MATRIX MODE - RES 3 GAIN 0 ZB ENABLE - 0  
*****  
TST63: SCOPE  
MOV #10,$TIMES ;;DO 10 ITERATIONS  
MOV #CLRALL,@SFR ;CLEAR DEVICE  
MOV #TSTDMA!TSTCON,@SFR ;SET 'TEST DMA AND CONTROL'  
MOV #26,@CSR ;LOAD RESOLUTION, GAIN, ZB ENABLE VALUE  
BIS #TESTZ,@SFR ;ENABLE 'TEST Z' PULSES  
BIS #BITO,@CSR ;SET ENABLE NCV11  
BIC #TESTZ,@SFR ;DISABLE 'TEST Z' PULSES  
MOV @ADM,$BDDAT ;READ THE ADDRESS DATA MAKER  
MOV #0,$GDDAT ;LOAD EXPECTED VALUE  
CMP $GDDAT,$BDDAT ;COMPARE EXPECTED TO READ  
BEQ TST64 ;;BR IF SAME  
ERROR 20 ;INCORRECT ADDRESS MAKER DATA  
RESOLUTION = 3 GAIN = 0 ZB ENABLE = 0  
*****  
*TEST 64 TEST ADDRESS MAKER - MATRIX MODE - RES = 3 GAIN = 1 ZB ENABLE - 0  
*****  
TST64: SCOPE  
MOV #10,$TIMES ;;DO 10 ITERATIONS  
MOV #CLRALL,@SFR ;CLEAR DEVICE  
MOV #TSTDMA!TSTCON,@SFR ;SET 'TEST DMA AND CONTROL'  
MOV #2026,@CSR ;LOAD RESOLUTION, GAIN, ZB ENABLE VALUE  
BIS #TESTZ,@SFR ;ENABLE 'TEST Z' PULSES  
BIS #BITO,@CSR ;SET ENABLE NCV11  
BIC #TESTZ,@SFR ;DISABLE 'TEST Z' PULSES  
MOV @ADM,$BDDAT ;READ THE ADDRESS DATA MAKER  
MOV #5252,$GDDAT ;LOAD EXPECTED VALUE  
CMP $GDDAT,$BDDAT ;COMPARE EXPECTED TO READ  
BEQ TST65 ;;BR IF SAME  
ERROR 20 ;INCORRECT ADDRESS MAKER DATA  
RESOLUTION = 3 GAIN = 1 ZB ENABLE = 0  
*****  
*TEST 65 TEST ADDRESS MAKER - MATRIX MODE - RES = 3 GAIN = 0 ZB ENABLE = 1  
*****  
TST65: SCOPE  
MOV #10,$TIMES ;;DO 10 ITERATIONS  
MOV #CLRALL,@SFR ;CLEAR DEVICE  
MOV #TSTDMA!TSTCON,@SFR ;SET 'TEST DMA AND CONTROL'  
MOV #4026,@CSR ;LOAD RESOLUTION, GAIN, ZB ENABLE VALUE  
BIS #TESTZ,@SFR ;ENABLE 'TEST Z' PULSES  
BIS #BITO,@CSR ;SET ENABLE NCV11  
BIC #TESTZ,@SFR ;DISABLE 'TEST Z' PULSES  
MOV @ADM,$BDDAT ;READ THE ADDRESS DATA MAKER  
MOV #12424,$GDDAT ;LOAD EXPECTED VALUE  
CMP $GDDAT,$BDDAT ;COMPARE EXPECTED TO READ  
BEQ TST66 ;;BR IF SAME  
ERROR 20 ;INCORRECT ADDRESS MAKER DATA  
RESOLUTION - 3 GAIN = 0 ZB ENABLE 1
```

1904  
1905  
1906  
1907 013214 000004  
1908 013216 012737 000010 001160  
1909 013224 012777 004000 166524  
1910 013232 012777 000014 166516  
1911 013240 012777 000024 166500  
1912 013246 052777 000002 166502  
1913 013254 052777 000001 166464  
1914 013262 042777 000002 166466  
1915 013270 017737 166464 001126  
1916 013276 012737 000000 001124  
1917 013304 023737 001124 001126  
1918 013312 001401  
1919 013314 104020  
1920  
1921  
1922  
1923  
1924 013316 000004  
1925 013320 012737 000010 001160  
1926 013326 012777 004000 166422  
1927 013334 012777 000014 166414  
1928 013342 012777 002024 166376  
1929 013350 052777 000002 166400  
1930 013356 052777 000001 166362  
1931 013364 042777 000002 166364  
1932 013372 017737 166362 001126  
1933 013400 012737 002552 001124  
1934 013406 023737 001124 001126  
1935 013414 001401  
1936 013416 104020  
1937  
1938  
1939  
1940  
1941 013420 000004  
1942 013422 012737 000010 001160  
1943 013430 012777 004000 166320  
1944 013436 012777 000014 166312  
1945 013444 012777 004024 166274  
1946 013452 052777 000002 166276  
1947 013460 052777 000001 166260  
1948 013466 042777 000002 166262  
1949 013474 017737 166260 001126  
1950 013502 012737 005224 001124  
1951 013510 023737 001124 001126  
1952 013516 001401  
1953 013520 104020  
1954

```
::*****  
:*TEST 66 TEST ADDRESS MAKER - MATRIX MODE - RES - 2 GAIN 0 ZB ENABLE = 0  
:*****  
TST66: SCOPE  
MOV #10,$TIMES ;;DO 10 ITERATIONS  
MOV #CLRALL,@SFR ;CLEAR DEVICE  
MOV #TSTDMA!TSTCON,@SFR ;SET 'TEST DMA AND CONTROL'  
MOV #24,@CSR ;LOAD RESOLUTION, GAIN, ZB ENABLE VALUE  
BIS #TESTZ,@SFR ;ENABLE 'TEST Z' PULSES  
BIS #BIT0,@CSR ;SET ENABLE NCV11  
BIC #TESTZ,@SFR ;DISABLE 'TEST Z' PULSES  
MOV @ADM,$BDDAT ;READ THE ADDRESS DATA MAKER  
MOV #0,$GDDAT ;LOAD EXPECTED VALUE  
CMP $GDDAT,$BDDAT ;COMPARE EXPECTED TO READ  
BEQ TST67 ;;BR IF SAME  
ERROR 20 ;INCORRECT ADDRESS MAKER DATA  
RESOLUTION = 2 GAIN = 0 ZB ENABLE - 0  
:*****  
:*TEST 67 TEST ADDRESS MAKER - MATRIX MODE - RES = 2 GAIN - 1 ZB ENABLE - 0  
:*****  
TST67: SCOPE  
MOV #10,$TIMES ;;DO 10 ITERATIONS  
MOV #CLRALL,@SFR ;CLEAR DFVICE  
MOV #TSTDMA!TSTCON,@SFR ;SET 'TEST DMA AND CONTROL'  
MOV #2024,@CSR ;LOAD RESOLUTION, GAIN, ZB ENABLE VALUE  
BIS #TESTZ,@SFR ;ENABLE 'TEST Z' PULSES  
BIS #BIT0,@CSR ;SET ENABLE NCV11  
BIC #TESTZ,@SFR ;DISABLE 'TEST Z' PULSES  
MOV @ADM,$BDDAT ;READ THE ADDRESS DATA MAKER  
MOV #2552,$GDDAT ;LOAD EXPECTED VALUE  
CMP $GDDAT,$BDDAT ;COMPARE EXPECTED TO READ  
BEQ TST70 ;;BR IF SAME  
ERROR 20 ;INCORRECT ADDRESS MAKER DATA  
RESOLUTION = 2 GAIN = 1 ZB ENABLE = 0  
:*****  
:*TEST 70 TEST ADDRESS MAKER - MATRIX MODE - RES = 2 GAIN = 0 ZB ENABLE - 1  
:*****  
TST70: SCOPE  
MOV #10,$TIMES ;;DO 10 ITERATIONS  
MOV #CLRALL,@SFR ;CLEAR DEVICE  
MOV #TSTDMA!TSTCON,@SFR ;SET 'TEST DMA AND CONTROL'  
MOV #4024,@CSR ;LOAD RESOLUTION, GAIN, ZB ENABLE VALUE  
BIS #TESTZ,@SFR ;ENABLE 'TEST Z' PULSES  
BIS #BIT0,@CSR ;SET ENABLE NCV11  
BIC #TESTZ,@SFR ;DISABLE 'TEST Z' PULSES  
MOV @ADM,$BDDAT ;READ THE ADDRESS DATA MAKER  
MOV #5224,$GDDAT ;LOAD EXPECTED VALUE  
CMP $GDDAT,$BDDAT ;COMPARE EXPECTED TO READ  
BEQ TST71 ;;BR IF SAME  
ERROR 20 ;INCORRECT ADDRESS MAKER DATA  
RESOLUTION 2 GAIN = 0 ZB ENABLE - 1
```



1955  
1956  
1957  
1958 013522 000004  
1959 013524 012737 000010 001160  
1960 013532 012777 004000 166216  
1961 013540 012777 000014 166210  
1962 013546 012777 000022 166172  
1963 013554 052777 000002 166174  
1964 013562 052777 000001 166156  
1965 013570 042777 000002 166160  
1966 013576 017737 166156 001126  
1967 013604 012737 000000 001124  
1968 013612 023737 001124 001126  
1969 013620 001401  
1970 013622 104020  
1971  
1972  
1973  
1974  
1975 013624 000004  
1976 013626 012737 000010 001160  
1977 013634 012777 004000 166114  
1978 013642 012777 000014 166106  
1979 013650 012777 002022 166070  
1980 013656 052777 000002 166072  
1981 013664 052777 000001 166054  
1982 013672 042777 000002 166056  
1983 013700 017737 166054 001126  
1984 013706 012737 001265 001124  
1985 013714 023737 001124 001126  
1986 013722 001401  
1987 013724 104020  
1988  
1989  
1990  
1991  
1992 013726 000004  
1993 013730 012737 000010 001160  
1994 013736 012777 004000 166012  
1995 013744 012777 000014 166004  
1996 013752 012777 004022 165766  
1997 013760 052777 000002 165770  
1998 013766 052777 000001 165752  
1999 013774 042777 000002 165754  
2000 014002 017737 165752 001126  
2001 014010 012737 002512 001124  
2002 014016 023737 001124 001126  
2003 014024 001401  
2004 014026 104020  
2005

```
::*****  
:*TEST 71 TEST ADDRESS MAKER - MATRIX MODE - RES - 1 GAIN 0 ZB ENABLE - C  
:*****  
TST71: SCOPE  
MOV #10,$TIMES ;;DO 10 ITERATIONS  
MOV #CLRALL,@SFR ;CLEAR DEVICE  
MOV #TSTDMA!TSTCON,@SFR ;SET 'TEST DMA AND CONTROL'  
MOV #22,@CSR ;LOAD RESOLUTION, GAIN, ZB ENABLE VALUE  
BIS #TESTZ,@SFR ;ENABLE 'TEST Z' PULSES  
BIS #BIT0,@CSR ;SET ENABLE NCV11  
BIC #TESTZ,@SFR ;DISABLE 'TEST Z' PULSES  
MOV @ADM,$BDDAT ;READ THE ADDRESS DATA MAKER  
MOV #0,$GDDAT ;LOAD EXPECTED VALUE  
CMP $GDDAT,$BDDAT ;COMPARE EXPECTED TO READ  
BEQ TST72 ;;BR IF SAME  
ERROR 20 ;INCORRECT ADDRESS MAKER DATA  
: RESOLUTION = 1 GAIN = 0 ZB ENABLE - 0  
:*****  
:*TEST 72 TEST ADDRESS MAKER - MATRIX MODE - RES - 1 GAIN = 1 ZB ENABLE - 0  
:*****  
TST72: SCOPE  
MOV #10,$TIMES ;;DO 10 ITERATIONS  
MOV #CLRALL,@SFR ;CLEAR DEVICE  
MOV #TSTDMA!TSTCON,@SFR ;SET 'TEST DMA AND CONTROL'  
MOV #2022,@CSR ;LOAD RESOLUTION, GAIN, ZB ENABLE VALUE  
BIS #TESTZ,@SFR ;ENABLE 'TEST Z' PULSES  
BIS #BIT0,@CSR ;SET ENABLE NCV11  
BIC #TESTZ,@SFR ;DISABLE 'TEST Z' PULSES  
MOV @ADM,$BDDAT ;READ THE ADDRESS DATA MAKER  
MOV #1265,$GDDAT ;LOAD EXPECTED VALUE  
CMP $GDDAT,$BDDAT ;COMPARE EXPECTED TO READ  
BEQ TST73 ;;BR IF SAME  
ERROR 20 ;INCORRECT ADDRESS MAKER DATA  
: RESOLUTION = 1 GAIN = 1 ZB ENABLE = 0  
:*****  
:*TEST 73 TEST ADDRESS MAKER - MATRIX MODE - RES = 1 GAIN = 0 ZB ENABLE - 1  
:*****  
TST73: SCOPE  
MOV #10,$TIMES ;;DO 10 ITERATIONS  
MOV #CLRALL,@SFR ;CLEAR DEVICE  
MOV #TSTDMA!TSTCON,@SFR ;SET 'TEST DMA AND CONTROL'  
MOV #4022,@CSR ;LOAD RESOLUTION, GAIN, ZB ENABLE VALUE  
BIS #TESTZ,@SFR ;ENABLE 'TEST Z' PULSES  
BIS #BIT0,@CSR ;SET ENABLE NCV11  
BIC #TESTZ,@SFR ;DISABLE 'TEST Z' PULSES  
MOV @ADM,$BDDAT ;READ THE ADDRESS DATA MAKER  
MOV #2512,$GDDAT ;LOAD EXPECTED VALUE  
CMP $GDDAT,$BDDAT ;COMPARE EXPECTED TO READ  
BEQ TST74 ;;BR IF SAME  
ERROR 20 ;INCORRECT ADDRESS MAKER DATA  
: RESOLUTION = 1 GAIN = 0 ZB ENABLE 1
```

```

2006
2007
2008
2009 014030 000004
2010 014032 012737 000010 001160
2011 014040 012777 004000 165710
2012 014046 012777 000014 165702
2013 014054 012777 000000 165664
2014 014062 052777 000002 165666
2015 014070 052777 000001 165650
2016 014076 042777 000002 165652
2017 014104 017737 165650 001126
2018 014112 012737 003407 001124
2019 014120 023737 001124 001126
2020 014126 001401
2021 014130 104021
2022
2023
2024
2025
2026
2027 014132 000004
2028 014134 012737 000010 001160
2029 014142 012777 004000 165606
2030 014150 012777 000014 165600
2031 014156 012777 004000 165562
2032 014164 052777 000002 165564
2033 014172 052777 000001 165546
2034 014200 042777 000002 165550
2035 014206 017737 165546 001126
2036 014214 012737 052452 001124
2037 014222 023737 001124 001126
2038 014230 001401
2039 014232 104021
2040
2041
2042
2043
2044
2045 014234 000004
2046 014236 012737 000010 001160
2047 014244 012777 004000 165504
2048 014252 012777 000014 165476
2049 014260 012777 002000 165460
2050 014266 052777 000002 165462
2051 014274 052777 000001 165444
2052 014302 042777 000002 165446
2053 014310 017737 165444 001126
2054 014316 012737 127657 001124
2055 014324 023737 001124 001126
2056 014332 001401
2057 014334 104021
2058
  
```

```

*****
*TEST 74 TEST ADDRESS MAKER - LIST MODE - ZB ENABLE = 0 GAIN - 0
*****
TST74: SCOPE
MOV #10,$TIMES ;;DO 10 ITERATIONS
MOV #CLRALL,@SFR ;CLEAR DEVICE
MOV #TSTDMA!TSTCON,@SFR ;SET TEST 'DMA AND CONTROL''
MOV #0,@CSR ;ENSURE LIST MODE
BIS #TESTZ,@SFR ;ENABLE 'TEST Z'' PULSES
BIS #BIT0,@CSR ;SET ENABLE NCV11
BIC #TESTZ,@SFR ;DISABLE 'TEST Z'' PULSES
MOV @ADM,$BDDAT ;READ THE ADDRESS MAKER VALUE
MOV #3407,$GDDAT ;LOAD EXPECTED VALUE
CMP $GDDAT,$BDDAT ;COMPARE EXPECTED TO READ
BEQ TST75 ;;BR IF SAME
ERROR 21 ;INCORRECT ADDRESS MAKER DATA
;RESOLUTION 7 <DEFAULT WHEN ZB IS NOT ENABLED>
  
```

```

*****
*TEST 75 TEST ADDRESS MAKER - LIST MODE - ZB ENABLE = 1 GAIN - 0
*****
TST75: SCOPE
MOV #10,$TIMES ;;DO 10 ITERATIONS
MOV #CLRALL,@SFR ;CLEAR DEVICE
MOV #TSTDMA!TSTCON,@SFR ;SET TEST 'DMA AND CONTROL''
MOV #4000,@CSR ;ENSURE LIST MODE AND ZB ENABLED
BIS #TESTZ,@SFR ;ENABLE 'TEST Z'' PULSES
BIS #BIT0,@CSR ;SET ENABLE NCV11
BIC #TESTZ,@SFR ;DISABLE 'TEST Z'' PULSES
MOV @ADM,$BDDAT ;READ THE ADDRESS MAKER VALUE
MOV #52452,$GDDAT ;LOAD EXPECTED VALUE
CMP $GDDAT,$BDDAT ;COMPARE EXPECTED TO READ
BEQ TST76 ;;BR IF SAME
ERROR 21 ;INCORRECT ADDRESS MAKER DATA
;RESOLUTION 5 <DEFAULT WHEN ZB IS ENABLED>
  
```

```

*****
*TEST 76 TEST ADDRESS MAKER - LIST MODE - ZB ENABLE - 0 GAIN = 1
*****
TST76: SCOPE
MOV #10,$TIMES ;;DO 10 ITERATIONS
MOV #CLRALL,@SFR ;CLEAR THE DEVICE
MOV #TSTDMA!TSTCON,@SFR ;SET TEST 'DMA AND CONTROL''
MOV #2000,@CSR ;SET GAIN FLOP
BIS #TESTZ,@SFR ;ENABLE 'TEST Z'' PULSES
BIS #BIT0,@CSR ;ENABLE THE NCV11
BIC #TESTZ,@SFR ;DISABLE THE 'TEST Z'' PULSES
MOV @ADM,$BDDAT ;READ THE ADDRESS MAKER VALUE
MOV #127657,$GDDAT ;LOAD THE EXPECTED
CMP $GDDAT,$BDDAT ;COMPARE
BEQ TST77 ;;BR IF SAME
ERROR 21 ;INCORRECT ADDRESS MAKER DATA
;RESOLUTION 7 - GAIN FLOP SET
  
```

```

2059
2060
2061
2062 014336 000004
2063 014340 012737 000040 001160
2064 014346 012777 004000 165402
2065 014354 012737 125252 060000
2066 014362 012777 011110 165360
2067 014370 012777 177777 165354
2068 014376 012777 060000 165350
2069 014404 012777 000014 165344
2070 014412 052777 000001 165326
2071 014420 052777 000002 165330
2072 014426 042777 000002 165322
2073 014434 000240
2074 014436 000240
2075 014440 000240
2076 014442 052777 010000 165306
2077 014450 000240
2078 014452 000240
2079 014454 000240
2080 014456 017737 165264 001126
2081 014464 012777 004000 165264
2082 014472 012737 040200 001124
2083 014500 023737 001124 001126
2084 014506 001402
2085 014510 104036
2086 014512 000453
2087 014514 017737 165234 001126 4$:
2088 014522 012737 060002 001124
2089 014530 023737 001124 001126
2090 014536 001401
2091 014540 104022
2092
2093
2094 014542 017737 165204 001126 1$:
2095 014550 012737 000000 001124
2096 014556 023737 001124 001126
2097 014564 001401
2098 014566 104023
2099
2100 014570 005037 001124 2$:
2101 014574 017737 165150 001126
2102 014602 001401
2103 014604 104024
2104
2105 014606 013737 060000 001126 3$:
2106 014614 012737 003407 001124
2107 014622 012737 060000 001122
2108 014630 023737 001124 001126
2109 014636 001401
2110 014640 104037

```

```

*****
*TEST 77          ENABLE A ONE WORD TRANSFER          SECTION LIST MODE
*****
TST77:  SCOPE
MOV          #40,$TIMES          ;;DO 40 ITERATIONS
MOV          #CLRALL,@SFR          ;CLEAR THE DEVICE
MOV          #125252,BUFO          ;PRIME TARGET BUFFER
MOV          #11110,@OFF          ;LOAD THE OFFSET VALUE WITH A NUMBER
MOV          #-1,@WCR          ;SET UP 1 WORD TRANSFER
MOV          #BUFO,@BAR          ;LOAD BUS ADDRESS FOR RESULT
MOV          #TSTDMA!TSTCON,@SFR  ;ENABLE TEST CONTROL AND DMA FLOPS
BIS          #BIT0,@CSR          ;ENABLE DEVICE
BIS          #TESTZ,@SFR          ;ENABLE 'TEST Z' PULSES
BIC          #TESTZ,@SFR          ;DISABLE 'TEST Z' PULSES
NOP
NOP
NOP
BIS          #BIT12,@SFR          ;ALLOW 1 DMA TRANSFER
NOP
NOP
NOP
MOV          @CSR,$BDDAT          ;READ STATUS
MOV          #CLRALL,@SFR          ;RESET THE DEVICE
MOV          #40200,$GDDAT          ;LOAD EXPECTED
CMP          $GDDAT,$BDDAT          ;TEST STATUS
BEQ          4$          ;;BR IF EXPECTED
ERROR       36          ;UNEXPECTED STATUS AFTER A 1 WORD TRANSFER
BR          TST100          ;;
MOV          @BAR,$BDDAT          ;READ BUS ADDRESS
MOV          #BUFO+2,$GDDAT          ;LOAD EXPECTED
CMP          $GDDAT,$BDDAT          ;COMPARE VALUES
BEQ          1$          ;;BR IF SAME
ERROR       22          ;INCORRECT BUS ADDRESS VALUE
;AFTER A 1 WORD TRANSFER
MOV          @WCR,$BDDAT          ;READ W.C. REGISTER
MOV          #0,$GDDAT          ;LOAD EXPECTED VALUE
CMP          $GDDAT,$BDDAT          ;COMPARE VALUES
BEQ          2$          ;;BR IF SAME
ERROR       23          ;INCORRECT WORD COUNT REGISTER VALUE
;AFTER A 1 WORD TRANSFER
CLR          $GDDAT          ;CLEAR THE EXPECTED VALUE
MOV          @OFF,$BDDAT          ;READ THE OFFSET REGISTER
BEQ          3$          ;;BR IF CLEARED
ERROR       24          ;OFFSET REG. FAILED TO CLEAR AFTER
;1 LIST MODE XFR.
MOV          BUFO,$BDDAT          ;GET BUFFER DATA
MOV          #3407,$GDDAT          ;LOAD EXPECTED
MOV          #BUFO,$BDADR          ;LOAD BAD ADDRESS
CMP          $GDDAT,$BDDAT          ;COMPARE DATA
BEQ          TST100          ;;BR IF SAME
ERROR       37          ;STATUS WAS OK BUT DATA WAS INCORRECT

```

```

2111 ::*****
2112 :*TEST 100      ENABLE A 512 WORD TRANSFER      SECTION LIST MODE
2113 :*****
2114 TST100: SCOPE
2115 014642 000004          MOV      #40,$TIMES      ;;DO 40 ITERATIONS
2116 014644 012737 000040 001160      MOV      #CLRALL,@SFR      ;CLEAR THE DEVICE
2117 014652 012777 004000 165076      MOV      #BUF0,R0      ;LOAD BUFFER POINTER
2118 014660 012700 060000          MOV      #125252,(R0)+    ;PRESET THE BUFFER WITH DATA
2119 014664 012720 125252 1$:      MOV      R0,#BUF1      ;TEST IF DONE
2120 014670 020027 062000          CMP      1$      ;BR IF NOT
2121 014674 001373          BNE      1$
2122 014676 012777 177000 165046      MOV      #-512,@WCR      ;SET UP 512. WORD TRANSFER
2123 014704 012777 060000 165042      MOV      #BUF0,@BAR      ;LOAD BUS ADDRESS FOR RESULT
2124 014712 012777 000014 165036      MOV      #TSTDMA!TSTCON,@SFR ;ENABLE TEST CONTROL AND DMA FLOPS
2125 014720 052777 000001 165020      BIS      #BIT0,@CSR      ;ENABLE DEVICE
2126 014726 012737 001000 002004      MOV      #512,$TEMP      ;LOAD THE COUNTER
2127 014734 052777 000002 165014 2$:      BIS      #TESTZ,@SFR      ;ENABLE 'TEST Z' PULSES
2128 014742 042777 000002 165006      BIC      #TESTZ,@SFR      ;DISABLE 'TEST Z' PULSES
2129 014750 052777 010000 165000      BIS      #BIT12,@SFR      ;ALLOW 1 DMA TRANSFER
2130 014756 005337 002004          DEC      $TEMP      ;FINISHED ALL WORDS?
2131 014762 001364          BNE      2$      ;BR UNTILL DONE
2132 ;THE TRANSFER IS NOW COMPLETE
2133 014764 017737 164756 001126      MOV      @CSR,$BDDAT      ;READ STATUS
2134 014772 012737 040200 001124      MOV      #40200,$GDDAT    ;LOAD EXPECTED STATUS
2135 015000 023737 001124 001126      CMP      $GDDAT,$BDDAT    ;COMPARE DATA
2136 015006 001402          BEQ      3$      ;;BR IF EXPECTED STATUS
2137 015010 104036          ERROR   36      ;UNEXPECTED STATUS AFTER 512 WORD TRANSFER
2138 015012 000465          BR      TST101      ;;
2139 015014 005037 001124 3$:      CLR      $GDDAT      ;CLEAR EXPECTED
2140 015020 017737 164724 001126      MOV      @OFF,$BDDAT      ;READ OFFSET REG.
2141 015026 001401          BEQ      4$      ;;BR IF CLEARED
2142 015030 104006          ERROR   6      ;UNEXPECTED OFFSET REGISTER BIT SET
2143 015032 012777 004000 164716 4$:      MOV      #CLRALL,@SFR      ;CLEAR THE DEVICE
2144 015040 017737 164710 001126      MOV      @BAR,$BDDAT      ;READ BUS ADDRESS
2145 015046 012737 062000 001124      MOV      #BUF1,$GDDAT      ;LOAD EXPECTED BAR VALUE
2146 015054 023737 001124 001126      CMP      $GDDAT,$BDDAT    ;COMPARE VALUES
2147 015062 001401          BEQ      5$      ;;BR IF SAME
2148 015064 104022          ERROR   22      ;INCORRECT BUS ADDRESS VALUE AFTER A 1 WORD TRANSFER
2149
2150 015066 017737 164660 001126 5$:      MOV      @WCR,$BDDAT      ;READ W.C. REGISTER
2151 015074 012737 000000 001124      MOV      #0,$GDDAT      ;LOAD EXPECTED W.C. VALUE
2152 015102 023737 001124 001126      CMP      $GDDAT,$BDDAT    ;COMPARE VALUES
2153 015110 001401          BEQ      6$      ;;BR IF SAME
2154 015112 104023          ERROR   23      ;INCORRECT WORD COUNT REGISTER VALUE AFTER A 1 WORD TRANSFER
2155 015114 012737 003407 001124 6$:      MOV      #3407,$GDDAT      ;LOAD EXPECTED DATA
2156 015122 012737 060000 001122      MOV      #BUF0,$BDADR      ;LOAD STARTING ADDRESS
2157 015130 017737 163766 001126 7$:      MOV      @$BDADR,$BDDAT    ;READ DATA WORD
2158 015136 023737 001124 001126      CMP      $GDDAT,$BDDAT    ;COMPARE DATA
2159 015144 001401          BEQ      10$      ;;BR IF EXPECTED
2160 015146 104037          ERROR   37      ;INCORRECT DATA IN LIST MODE XFER.
2161 015150 062737 000002 001122 10$:      ADD      #2,$BDADR      ;UPDATE POINTER
2162 015156 022737 062000 001122      CMP      #BUF0+1024,$BDADR ;TEST IF END OF BUFFER
2163 015164 001361          BNE      7$      ;;BR IF NOT DONE

```

```

2164
2165
2166
2167 015166 000004
2168 015170 012737 000040 001160
2169 015176 012777 004000 164552
2170 015204 012777 177777 164540
2171 015212 012777 000003 164530
2172 015220 012777 160000 164526
2173 015226 012777 000014 164522
2174 015234 012777 000016 164504
2175 015242 052777 000001 164476
2176 015250 052777 000002 164500
2177 015256 042777 000002 164472
2178 015264 000240
2179 015266 000240
2180 015270 000240
2181 015272 052777 010000 164456
2182 015300 000240
2183 015302 000240
2184 015304 000240
2185 015306 012737 140200 001124
2186 015314 017737 164426 001126
2187 015322 100402
2188 015324 104025
2189 015326 000423
2190 015330 023737 001124 001126 1$:
2191 015336 001401
2192 015340 104025
2193 015342 052777 004000 164406 2$:
2194 015350 012737 000200 001124
2195 015356 017737 164364 001126
2196 015364 023737 001124 001126
2197 015372 001401
2198 015374 104025
2199
2200
2201
2202 015376 000004
2203 015400 012737 000040 001160
2204 015406 012777 004000 164342
2205 015414 012777 177777 164330
2206 015422 012777 000003 164320
2207 015430 012777 160000 164316
2208 015436 012777 000014 164312
2209 015444 052777 000001 164274
2210 015452 052777 000002 164276
2211 015460 042777 000002 164270
2212 015466 000240
2213 015470 000240
2214 015472 000240
2215 015474 052777 010000 164254
2216 015502 000240
2217 015504 000240

```

```

*****
*TEST 101 VERIFY 'TIMEOUT' FLOP SETS AND 'CLR ALL' CLEARS IT
*****
TST101: SCOPE
MOV #40,$TIMES ;;DO 40 ITERATIONS
MOV #CLRALL,@SFR ;CLEAR DEVICE
MOV #-1,@WCR ;LOAD W.C. REGISTER
MOV #3,@OFF ;LOAD EXTENDED ADDRESS BITS
MOV #160000,@BAR ;LOAD BUS ADDRESS REGISTER TO A NON-EXISTENT ADDR
MOV #TSTCON!TSTDMA,@SFR ;SET TEST CONTROL AND DMA
MOV #16,@CSR ;LOAD RESOLUTION TO VERIFY 'SFR INIT' CLEARS
BIS #BIT0,@CSR ;ENABLE THE DEVICE
BIS #TESTZ,@SFR ;ENABLE 'TEST Z' PULSES
BIC #TESTZ,@SFR ;DISABLE 'TEST Z' PULSES
NOP
NOP
NOP
BIS #BIT12,@SFR ;ALLOW 1 DMA TRANSFER
NOP
NOP
MOV #BIT15!BIT14.BIT7,$GDDAT ;LOAD EXPECTED
MOV @CSR,$BDDAT ;READ STATUS REG.
BMI 1$ ;BR IF 'TIMEOUT' FLOP IS SET
ERROR 25 ;'TIMEOUT' FLOP FAILED TO SET
BR TST102 ;;
1$: CMP $GDDAT,$BDDAT ;COMPARE VALUES
BEQ 2$ ;;BR IF SAME
ERROR 25 ;'TIMEOUT' FLOP DID SET BUT FAILED TO GENERATE ''
2$: BIS #CLRALL,@SFR ;GENERATE AN 'CLR ALL' TO CLEAR TIMEOUT FLOP
MOV #BIT7,$GDDAT ;LOAD EXPECTED
MOV @CSR,$BDDAT ;READ STATUS
CMP $GDDAT,$BDDAT ;COMPARE VALUE
BEQ TST102 ;;BR IF SAME
ERROR 25 ;'CLR ALL' FAILED TO CLEAR TIMEOUT FLOP
*****
*TEST 102 VERIFY 'TIMEOUT' FLOP SETS AND 'CLR TIMEOUT' CLEARS IT
*****
TST102: SCOPE
MOV #40,$TIMES ;;DO 40 ITERATIONS
MOV #CLRALL,@SFR ;CLEAR DEVICE
MOV #-1,@WCR ;LOAD W.C. REGISTER
MOV #3,@OFF ;LOAD EXTENDED ADDRESS BITS
MOV #160000,@BAR ;LOAD BUS ADDRESS REGISTER TO A NON-EXISTENT ADDR
MOV #TSTCON!TSTDMA,@SFR ;SET TEST CONTROL AND DMA
MOV #BIT0,@CSR ;ENABLE THE DEVICE
BIS #TESTZ,@SFR ;ENABLE 'TEST Z' PULSES
BIC #TESTZ,@SFR ;DISABLE 'TEST Z' PULSES
NOP
NOP
NOP
BIS #BIT12,@SFR ;ALLOW 1 DMA TRANSFER
NOP
NOP

```

```

CZNCCA NCV11 DIAGNOSTIC MACY11 27(654) 8-AUG-78 15:05 PAGE 49
CZNCCA.P11 T102 VERIFY 'TIMEOUT' FLOP SETS AND 'CLR TIMEOUT' CLEARS IT SEQ 0061

2218 015506 000240 NOP
2219 015510 012737 140200 001124 MOV #BIT15.BIT14!BIT7,$GDDAT ;LOAD EXPECTED
2220 015516 017737 164224 001126 MOV @CSR,$BDDAT ;READ STATUS REG.
2221 015524 100402 BMI 1$ ;BR IF 'TIMEOUT' FLOP IS SET
2222 015526 104025 ERROR 25 ;'TIMEOUT' FLOP FAILED TO SET
2223 015530 000423 BR TST103 ;;
2224 015532 023737 001124 001126 1$: CMP $GDDAT,$BDDAT ;COMPARE VALUES
2225 015540 001401 BEQ 2$ ;;BR IF SAME
2226 015542 104025 ERROR 25 ;'TIMEOUT' FLOP DID SET BUT FAILED TO GENERATE ''
2227 015544 052777 100000 164204 2$: BIS #BIT15,@SFR ;GENERATE AN 'CLR TIMEOUT' TO CLEAR TIMEOUT FLOP
2228 015552 012737 040200 001124 MOV #BIT14!BIT7,$GDDAT ;LOAD EXPECTED
2229 015560 017737 164162 001126 MOV @CSR,$BDDAT ;READ STATUS
2230 015566 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE VALUE
2231 015574 001401 BEQ TST103 ;;BR IF SAME
2232 015576 104025 ERROR 25 ;'CLR TIMEOUT' FAILED TO CLEAR TIMEOUT FLOP
2233 *****
2234 *TEST 103 VERIFY 'TIMEOUT' INTERRUPT
2235 *****
2236 TST103: SCOPE
2237 015600 000004 MOV #40,$TIMES ;;DO 40 ITERATIONS
2238 015602 012737 000040 001160 MOV #CLRALL,@SFR ;CLEAR DEVICE
2239 015610 012777 004000 164140 MOV #-1,@WCR ;LOAD W.C. REGISTER
2240 015616 012777 177777 164126 MOV #3,@OFF ;LOAD EXTENDED ADDRESS BITS
2241 015624 012777 000003 164116 MOV #160000,@BAR ;LOAD BUS ADDRESS REGISTER TO A NON-EXISTENT ADDRE
2242 015632 012777 160000 164114 MOV #TSTCON!TSTDMA,@SFR ;SET TEST CONTROL AND DMA
2243 015646 012746 000000 MOV #0,-(SP)
2244 015652 012746 015660 MOV #1$,-(SP)
2245 015656 000002 RTI
2246 015660 012777 015752 164104 1$: MOV #2$,@VECTA0
2247 015666 000240 NOP
2248 015670 000240 NOP
2249 015672 000240 NOP
2250 015674 000240 NOP
2251 015676 052777 000101 164042 BIS #BIT6!BIT0,@CSR ;ENABLE THE DEVICE
2252 015704 052777 000002 164044 BIS #TESTZ,@SFR ;ENABLE 'TEST Z' PULSES
2253 015712 042777 000002 164036 BIC #TESTZ,@SFR ;DISABLE 'TEST Z' PULSES
2254 015720 000240 NOP
2255 015722 000240 NOP
2256 015724 000240 NOP
2257 015726 052777 010000 164022 BIS #BIT12,@SFR ;ALLOW 1 DMA TRANSFER
2258 015734 000240 NOP
2259 015736 000240 NOP
2260 015740 000240 NOP
2261 015742 005077 164000 CLR @CSR ;CLEAR ENABLE
2262 015746 104026 ERROR 26 ;'TIMEOUT' FAILED TO INTERRUPT
2263 015750 000401 BR 3$ ;;BR TO CLEAN UP
2264
2265 015752 022626 2$: CMP (SP)+,(SP)+ ;CLEAN THE STACK
2266 015754 005077 163766 3$: CLR @CSR
2267 015760 012777 004000 163770 MOV #CLRALL,@SFR ;CLEAR THE DEVICE
2268 015766 013777 001774 163776 MOV VECTA1,@VECTA0 ;RESET VECTOR
2269 015774 005077 163774 CLR @VECTA1

```

C  
C

2270  
 2271  
 2272  
 2273 016000 000004  
 2274 016002 012737 000040 001160  
 2275 016010 012777 004000 163740  
 2276 016016 023727 036402 002140  
 2277 016024 103450  
 2278 016026 012777 177777 163716  
 2279 016034 012777 177776 163712  
 2280 016042 005077 163702  
 2281 016046 012777 000014 163702  
 2282 016054 012777 000016 163664  
 2283 016062 052777 000001 163656  
 2284 016070 052777 000002 163660  
 2285 016076 042777 000002 163652  
 2286 016104 052777 010000 163644  
 2287 016112 000240  
 2288 016114 000240  
 2289 016116 000240  
 2290 016120 012737 000001 001124  
 2291 016126 017737 163616 001126  
 2292 016134 023737 001124 001126  
 2293 016142 001401  
 2294 016144 104006  
 2295  
 2296  
 2297  
 2298  
 2299 016146 000004  
 2300 016150 012737 000040 001160  
 2301 016156 012777 004000 163572  
 2302 016164 023727 036402 006140  
 2303 016172 103454  
 2304 016174 012777 177777 163550  
 2305 016202 012777 177776 163544  
 2306 016210 012777 000001 163532  
 2307 016216 012777 000014 163532  
 2308 016224 012777 000016 163514  
 2309 016232 052777 000001 163506  
 2310 016240 052777 000002 163510  
 2311 016246 042777 000002 163502  
 2312 016254 000240  
 2313 016256 000240  
 2314 016260 000240  
 2315 016262 052777 010000 163466  
 2316 016270 000240  
 2317 016272 000240  
 2318 016274 000240  
 2319 016276 012737 000002 001124  
 2320 016304 017737 163440 001126  
 2321 016312 023737 001124 001126  
 2322 016320 001401  
 2323 016322 104006

```

:*****
:*TEST 104      VERIFY INCREMENTING INTO EXTENDED ADDRESS BIT 16
:*****
TST104: SCOPE
MOV      #40,$TIMES      ;;DO 40 ITERATIONS
MOV      #CLRALL,@SFR    ;CLEAR THE DEVICE
CMP      $LSTBK,#2140    ;TEST IF ENOUGH MEMORY
BLO      TST105          ;;BR IF NOT ENOUGH MEMORY
MOV      #-1,@WCR        ;LOAD 1 WORD XFR
MOV      #177776,@BAR    ;LOAD LAST ADDRESS
CLR      @OFF            ;ENSURE CLEARED EXTENDED ADDRESS BITS
MOV      #TSTCON!TSTDMA,@SFR ;ENABLE CONTROLER
MOV      #16,@CSR        ;ENABLE THE MODE
BIS      #BIT0,@CSR      ;ENABLE THE NCV11
BIS      #TESTZ,@SFR     ;ENABLE 'TEST Z' PULSES
BIC      #TESTZ,@SFR     ;DISABLE 'TEST Z' PULSES
BIS      #BIT12,@SFR     ;ALLOW 1 DMA TRANSFER
NOP
NOP
NOP
MOV      #1,$GDDAT       ;LOAD EXPECTED VALUE
MOV      @OFF,$BDDAT     ;READ ACUTAL VALUE
CMP      $GDDAT,$BDDAT  ;COMPARE
BEQ      TST105          ;;BR IF SAME
ERROR    6               ;EXTENDED ADDRESS BIT 16 FAILED TO SET
  
```

```

:*****
:*TEST 105      VERIFY INCREMENTING INTO EXTENDED ADDRESS BIT 17
:*****
TST105: SCOPE
MOV      #40,$TIMES      ;;DO 40 ITERATIONS
MOV      #CLRALL,@SFR    ;CLEAR THE DEVICE
CMP      $LSTBK,#6140    ;TEST MEMORY SPACE >100K
BLO      TST106          ;;BR IF NOT ENOUGH MEMORY
MOV      #-1,@WCR        ;LOAD 1 WORD XFR
MOV      #177776,@BAR    ;LOAD LAST ADDRESS
MOV      #1,@OFF         ;LOAD EXTENDED ADDRESS BIT
MOV      #TSTDMA!TSTCON,@SFR ;ENABLE TEST CONTROL
MOV      #16,@CSR        ;ENABLE THE MODE
BIS      #BIT0,@CSR      ;ENAVLE THE DEVICE
BIS      #TESTZ,@SFR     ;ENABLE 'TEST Z' PULSES
BIC      #TESTZ,@SFR     ;DISABLE 'TEST Z' PULSES
NOP
NOP
NOP
BIS      #BIT12,@SFR     ;ALLOW 1 DMA TRANSFER
NOP
NOP
NOP
MOV      #2,$GDDAT       ;LOAD EXPECTED
MOV      @OFF,$BDDAT     ;READ ACTUAL
CMP      $GDDAT,$BDDAT  ;COMPARE
BEQ      TST106          ;;BR IF SAME
ERROR    6               ;EXTENDED ADDRESS BIT 17 FAILED TO SET
  
```

```

2324
2325
2326
2327 016324 000004
2328 016326 012737 000040 001160
2329 016334 012777 004000 163414
2330 016342 012777 177777 163402
2331 016350 012777 060000 163376
2332 016356 012777 000014 163372
2333 016364 012737 007070 060000
2334 016372 052777 000001 163346
2335 016400 000240
2336 016402 000240
2337 016404 000240
2338 016406 052777 002000 163342
2339 016414 052777 010000 163334
2340 016422 000240
2341 016424 000240
2342 016426 000240
2343 016430 013737 060000 001126
2344 016436 012737 177777 001124
2345 016444 023737 001124 001126
2346 016452 001401
2347 016454 104027
2348
2349
2350
2351
2352 016456 000004
2353 016460 012737 000040 001160
2354 016466 012777 004000 163262
2355 016474 012777 177777 163250
2356 016502 012777 060000 163244
2357 016510 012777 000014 163240
2358 016516 012737 007070 060000
2359 016524 052777 000001 163214
2360 016532 000240
2361 016534 000240
2362 016536 000240
2363 016540 052777 001000 163210
2364 016546 052777 010000 163202
2365 016554 000240
2366 016556 000240
2367 016560 000240
2368 016562 013737 060000 001126
2369 016570 012737 000000 001124
2370 016576 023737 001124 001126
2371 016604 001401
2372 016606 104027
2373

```

```

*****
*TEST 106 VERIFY 'SET EVENT' DATA GENERATES A 177777 DATA WORD
*****
TST106: SCOPE
MOV #40,$TIMES ;;DO 40 ITERATIONS
MOV #CLRALL,@SFR ;CLEAR THE DEVICE
MOV #-1,@WCR ;SET UP 1 WORD TRANSFER
MOV #BUFO,@BAR ;LOAD BUS ADDRESS FOR RESULT
MOV #TSTDMA!TSTCON,@SFR ;ENABLE TEST CONTROL AND DMA FLOPS
MOV #7070,BUFO ;PRESET DATA
BIS #BIT0,@CSR ;ENABLE DEVICE
NOP
NOP
NOP
BIS #BIT10,@SFR ;SET 'EVENT' FLOP
BIS #BIT12,@SFR ;ALLOW 1 DMA TRANSFER
NOP
NOP
NOP
MOV BUFO,$BDDAT ;READ DATA
MOV #-1,$GDDAT ;LOAD EXPECTED
CMP $GDDAT,$BDDAT ;COMPARE VALUES
BEQ TST107 ;;BR IF SAME
ERROR 27 ;INCORRECT DATA VALUE FOR 'EVENT' MARK
;AFTER A 1 WORD TRANSFER
*****
*TEST 107 VERIFY 'SET TIME' DATA GENERATES A 000000 DATA WORD
*****
TST107: SCOPE
MOV #40,$TIMES ;;DO 40 ITERATIONS
MOV #CLRALL,@SFR ;CLEAR THE DEVICE
MOV #-1,@WCR ;SET UP 1 WORD TRANSFER
MOV #BUFO,@BAR ;LOAD BUS ADDRESS FOR RESULT
MOV #TSTDMA!TSTCON,@SFR ;ENABLE TEST CONTROL AND DMA FLOPS
MOV #7070,BUFO ;PRESET THE DATA
BIS #BIT0,@CSR ;ENABLE DEVICE
NOP
NOP
NOP
BIS #BIT9,@SFR ;SET 'TIME' FLOP
BIS #BIT12,@SFR ;ALLOW 1 DMA TRANSFER
NOP
NOP
NOP
MOV BUFO,$BDDAT ;READ DATA
MOV #0,$GDDAT ;LOAD EXPECTED
CMP $GDDAT,$BDDAT ;COMPARE VALUES
BEQ TST110 ;;BR IF SAME
ERROR 27 ;INCORRECT DATA VALUE FOR 'TIME' MARK
;AFTER A 1 WORD TRANSFER

```



```

2374
2375
2376
2377 016610 000004
2378 016612 012737 000040 001160
2379 016620 012777 004000 163130
2380 016626 005737 004016
2381 016632 001044
2382 016634 012777 177777 163110
2383 016642 012777 060000 163104
2384 016650 012777 000014 163100
2385 016656 012737 007070 060000
2386 016664 052777 000001 163054
2387 016672 000240
2388 016674 000240
2389 016676 052777 000400 163034
2390 016704 052777 010000 163044
2391 016712 000240
2392 016714 000240
2393 016716 013737 060000 001126
2394 016724 012737 177777 001124
2395 016732 023737 001124 001126
2396 016740 001401
2397 016742 104040
2398
2399
2400
2401
2402 016744 000004
2403 016746 012737 000040 001160
2404 016754 012777 004000 162774
2405 016762 005737 004016
2406 016766 001052
2407 016770 012777 177777 162754
2408 016776 012777 060000 162750
2409 017004 012777 000014 162744
2410 017012 012737 007070 060000
2411 017020 052777 000001 162720
2412 017026 005077 162706
2413 017032 012777 177776 162704
2414 017040 012777 000011 162672
2415 017046 105777 162666
2416 017052 100375
2417 017054 052777 010000 162674
2418 017062 000240
2419 017064 000240
2420 017066 013737 060000 001126
2421 017074 012737 000000 001124
2422 017102 023737 001124 001126
2423 017110 001401
2424 017112 104040
2425

:*****
:*TEST 110 VERIFY 'CLOCK ST1' GENERATES A EVENT (177777) DATA WORD
:*****
TST110: SCOPE
MOV #40,$TIMES ;;DO 40 ITERATIONS
MOV #CLRALL,@SFR ;CLEAR THE DEVICE
TST DEADKW ;TEST IF NCV11 CLOCK IS PRESENT
BNE TST111 ;;BR IF NOT
MOV #-1,@WCR ;SET UP 1 WORD TRANSFER
MOV #BUFO,@BAR ;LOAD BUS ADDRESS FOR RESULT
MOV #TSTDMA!TSTCON,@SFR ;ENABLE TEST CONTROL AND DMA FLOPS
MOV #7070,BUFO ;PRESET THE DATA
BIS #BIT0,@CSR ;ENABLE THE DEVICE
NOP
NOP
BIS #BIT8,@KWCSR ;GENERATE CLOCK ST1 TO SET 'EVENT' FLOP
BIS #BIT12,@SFR ;ALLOW 1 DMA TRANSFER
NOP
NOP
MOV BUFO,$BDDAT ;READ BUFFER DATA
MOV #-1,$GDDAT ;LOAD EXPECTED DATA
CMP $GDDAT,$BDDAT ;COMPARE
BEQ TST111 ;;BR IF EXPECTED
ERROR 40 ;CLOCK ST1 FAILED TO GENERATE EVENT FLAG
;CHECK THE M8026 TO M7952 JUMPERS

:*****
:*TEST 111 VERIFY 'CLOCK OVERFLOW' GENERATES A TIME (000000) DATA WORD
:*****
TST111: SCOPE
MOV #40,$TIMES ;;DO 40 ITERATIONS
MOV #CLRALL,@SFR ;CLEAR THE DEVICE
TST DEADKW ;TEST IF NCV11 CLOCK IS PRESENT
BNE TST112 ;;BR IF NOT
MOV #-1,@WCR ;SET UP 1 WORD TRNSFER
MOV #BUFO,@BAR ;LOAD BUS ADDRESS FOR RESULT
MOV #TSTDMA!TSTCON,@SFR ;ENABLE TEST CONTROL AND DMA FLOPS
MOV #7070,BUFO ;PRESET THE DATA
BIS #BIT0,@CSR ;ENABLE THE DEVICE
CLR @KWCSR ;CLEAR STATUS
MOV #-2,@KWPSR ;LOAD COUNTER PRESET
MOV #11,@KWCSR ;ENABLE 1 MHZ. RATE AND CLOCK GO
1$: TSTB @KWCSR ;WAIT FOR CLOCK
BPL 1$
BIS #BIT12,@SFR ;ALLOW 1 DMA TRANSFER
NOP
NOP
MOV BUFO,$BDDAT ;READ DATA
MOV #0,$GDDAT ;LOAD EXPECTED
CMP $GDDAT,$BDDAT ;COMPARE VALUES
BEQ TST112 ;;BR IF SAME
ERROR 40 ;CLOCK OVERFLOW FAILED TO GENERATE 'TIME MARKS'
;CHECK THE M8026 TO M7952 JUMPERS

```

```

2426
2427
2428
2429 017114 000004
2430 017116 012737 000040 001160
2431 017124 012777 004000 162624
2432 017132 012777 177777 162612
2433 017140 012777 060000 162606
2434 017146 012777 000014 162602
2435 017154 012737 007070 060000
2436 017162 052777 000001 162556
2437 017170 000240
2438 017172 000240
2439 017174 000240
2440 017176 052777 003000 162552
2441 017204 052777 010000 162544
2442 017212 000240
2443 017214 000240
2444 017216 000240
2445 017220 013737 060000 001126
2446 017226 012737 000000 001124
2447 017234 023737 001124 001126
2448 017242 001401
2449 017244 104027
2450
2451
2452
2453 017246 000004
2454 017250 012737 000040 001160
2455 017256 012777 004000 162472
2456 017264 005037 060000
2457 017270 012777 060000 162452
2458 017276 012777 000022 162442
2459 017304 012777 000014 162444
2460 017312 052777 000001 162426
2461 017320 052777 000002 162430
2462 017326 042777 000002 162422
2463 017334 000240
2464 017336 000240
2465 017340 000240
2466 017342 052777 010000 162406
2467 017350 000240
2468 017352 000240
2469 017354 000240
2470 017356 013737 060000 001126
2471 017364 012737 000001 001124
2472 017372 023737 001124 001126
2473 017400 001401
2474 017402 104030
2475
2476

```

```

*****
*TEST 112  VERIFY 'SET TIME' OVERRIDES 'SET EVENT' DATA.
*****
TST112: SCOPE
MOV #40,$TIMES ;;DO 40 ITERATIONS
MOV #CLRALL,@SFR ;CLEAR THE DEVICE
MOV #-1,@WCR ;SET UP 1 WORD TRANSFER
MOV #BUFO,@BAR ;LOAD BUS ADDRESS FOR RESULT
MOV #TSTDMA!TSTCON,@SFR ;ENABLE TEST CONTROL AND DMA FLOPS
MOV #7070,BUFO ;PRESET THE DATA
BIS #BIT0,@CSR ;ENABLE DEVICE
NOP
NOP
NOP
BIS #BIT10!BIT9,@SFR ;SET 'TIME AND EVENT' FLOPS
BIS #BIT12,@SFR ;ALLOW 1 DMA TRANSFER
NOP
NOP
NOP
MOV BUFO,$BDDAT ;READ DATA
MOV #0,$GDDAT ;LOAD EXPECTED
CMP $GDDAT,$BDDAT ;COMPARE VALUES
BEQ TST113 ;;BR IF SAME
ERROR 27 ;'TIME' MARK FAILED TO OVERRIDE 'EVENT' OR DATA M
*****
*TEST 113  DO A ONE WORD MATRIX MODE TRANSFER -CHECK FOR INCREMENT FUNCTION
*****
TST113: SCOPE
MOV #40,$TIMES ;;DO 40 ITERATIONS
MOV #CLRALL,@SFR ;CLEAR THE DEVICE
CLR BUFO ;CLEAR INITIAL INCREMENT LOCATION
MOV #BUFO,@OFF ;LOAD INITIAL OFFSET REGISTER
MOV #BIT4!BIT1,@CSR ;ENABLE MATRIX MODE
MOV #TSTDMA!TSTCON,@SFR ;SET TEST DMA AND CONTROL
BIS #BIT0,@CSR ;ENABLE THE DEVICE
BIS #TESTZ,@SFR ;ENABLE 'TEST Z' PULSES
BIC #TESTZ,@SFR ;DISABLE 'TEST Z' PULSES
NOP
NOP
BIS #BIT12,@SFR ;ALLOW 1 TRANSFER
NOP
NOP
MOV BUFO,$BDDAT ;READ THE BUFO LOCATION
MOV #1,$GDDAT ;LOAD EXPECTED VALUE
CMP $GDDAT,$BDDAT ;COMPARE VALUES
BEQ TST114 ;;BR IF SAME
ERROR 30 ;INCORRECT DATA IN MATRIX MODE
;IF DATA WAS 0, THE ADDRESS ACCESSED WAS PROBLY WRONG
;IF DATA WAS NON ZERO, THE 'INCR' REGISTER IS STUCK TO A 1

```

```

2477      ::*****
2478      ::*TEST 114      VERIFY EACH BIT OF THE INCREMENT REG. DATA PATH
2479      ::*****
2480      017404 000004      TST114: SCOPE
2481      017406 012737 000040 001160      MOV      #40,$TIMES      ;;DO 40 ITERATIONS
2482      :CHECK FOR A "CARRY" INTO EACH BIT
2483      :IE:      000002-000001
2484      :      000004-000003
2485      :      000010-000007
2486      :      000020-000017
2487      :      000040-000037
2488      :      000100-000077
2489      :      000200-000177
2490      :      ETC
2491      017414 012737 017430 001110      MOV      #1,$$LPERR      ;LOAD RETURN ADDRESS IF ERROR
2492      017422 012737 000002 002004      MOV      #2,$TEMP      ;LOAD INITIAL VALUE
2493
2494      017430 012777 004000 162320 1$:      MOV      #CLRALL,@SFR      ;CLEAR THE DEVICE
2495      017436 012777 060000 162304      MOV      #BUFO,@OFF      ;LOAD INITIAL OFFSET REGISTER
2496      017444 012777 000024 162274      MOV      #BIT4!BIT2,@CSR      ;ENABLE WORD MATRIX MODE
2497      017452 012777 000014 162276      MOV      #TSTDMA!TSTCON,@SFR      ;SET TEST DMA AND CONTROL
2498      017460 052777 000001 162260      BIS      #BIT0,@CSR      ;ENABLE THE DEVICE
2499      017466 013737 002004 060000      MOV      $TEMP,BUFO      ;LOAD PRESET VALUE
2500      017474 005337 060000      DEC      BUFO      ;TO EXPECTED -1
2501      017500 052777 000002 162250      BIS      #TESTZ,@SFR      ;ENABLE "TEST Z" PULSES
2502      017506 042777 000002 162242      BIC      #TESTZ,@SFR      ;DISABLE "TEST Z" PULSES
2503      017514 052777 010000 162234      BIS      #BIT12,@SFR      ;ALLOW 1 TRANSFER
2504      017522 013737 002004 001124      MOV      $TEMP,$GDDAT      ;LOAD TYPEOUT EXPECTED
2505      017530 013737 060000 001126      MOV      BUFO,$BDDAT      ;READ THE BUFO LOCATION
2506      017536 023737 001124 001126      CMP      $GDDAT,$BDDAT      ;COMPARE VALUES
2507      017544 001401      BEQ      2$      ;;BR IF SAME
2508      017546 104030      ERROR    30      ;INCORRECT DATA IN THE INCREMENT REGISTER
2509      017550 017737 162172 001126 2$:      MOV      @CSR,$BDDAT      ;READ STATUS
2510      017556 032737 020000 001126      BIT      #BIT13,$BDDAT      ;TEST FOR UNEXPECTED CELL OVERFLOW
2511      017564 001407      BEQ      3$      ;BR IF NOT
2512      017566 012737 000024 001124      MOV      #BIT4!BIT2,$GDDAT      ;LOAD THE EXPECTED TYPEOUT
2513      017574 104031      ERROR    31      ;UNEXPECTED "CELL OVERFLOW" STATUS
2514      017576 052777 020000 162152      BIS      #BIT13,@SFR      ;TRY TO CLEAR THE FLAG
2515      017604 006337 002004 3$:      ASL      $TEMP      ;CHANGE THE EXPCTED
2516      017610 001307      BNE      1$      ;BR IF MORE DATA BITS

```

```

2517      ::*****
2518      :*TEST 115      CHECK FOR LOW BYTE 'INC OVFL' TO SET CELL OVERFLOW AND 'CLR CELL' TO CLE
2519      :*****
2520      TST115: SCOPE
2521      MOV      #40,$TIMES      ;;DO 40 ITERATIONS
2522      MOV      #CLRALL,@SFR      ;CLEAR THE DEVICE
2523      CLR      @WCR      ;CLEAR WC
2524      CLR      @BAR      ;CLEAR BAR
2525      MOV      #BUFO,@OFF      ;LOAD INITIAL OFFSET REGISTER
2526      MOV      #BIT4!BIT1,@CSR      ;ENABLE BYTE MATRIX MODE
2527      MOV      #TSTDMA!TSTCON,@SFR      ;SET TEST DMA AND CONTROL
2528      BIS      #BIT0,@CSR      ;ENABLE THE DEVICE
2529      BIS      #TESTZ,@SFR      ;ENABLE 'TEST Z' PULSES
2530      BIC      #TESTZ,@SFR      ;DISABLE 'TEST Z' PULSES
2531      NOP
2532      NOP
2533      NOP
2534      MOVB     #377,BUFO      ;SET LOW BYTE OF BUFO LOC. TO BYTE -1
2535      MOVB     #200,BUFO+1    ;SET HIGH BYTE OF BUFO TO KNOWN VALUE
2536      BIS      #BIT12,@SFR    ;ALLOW 1 TRANSFER
2537      NOP
2538      NOP
2539      NOP
2540      MOV      @CSR,$BDDAT      ;READ STATUS
2541      MOV      #BIT13!BIT4!BIT1,$G.DAT ;LOAD EXPECTED STATUS
2542      CMP      $GDDAT,$BDDAT    ;COMPARE VALUES
2543      BEQ      1$              ;;BR IF SAME
2544      ERROR    31              ;'CELL OVERFLOW' FLOP FAILED TO SET
2545      ;IN BYTE MODE FROM A LOW BYTE OVERFLOW
2546
2547
2548      ;NOW GENERATE 'CLR CELL' TO CLEAR CELL OVERFLOW FLOP
2549      1$:      BIS      #BIT13,@SFR      ;GENERATE 'CLR CELL'
2550      MOV      @CSR,$BDDAT      ;READ STATUS
2551      MOV      #BIT4!BIT1,$GDDAT    ;LOAD EXPECTED
2552      CMP      $GDDAT,$BDDAT    ;COMPARE VALUES
2553      BEQ      2$              ;;BR IF SAME
2554      ERROR    31              ;'CLR CELL' FAILED TO CLEAR 'CELL OVFL' FLOP
2555
2556      ;NOW VERIFY THE BYTE DATA CELL
2557      2$:      MOV      BUFO,$BDDAT      ;READ DATA
2558      MOV      #100377,$GDDAT      ;LOAD EXPECTED
2559      CMP      $GDDAT,$BDDAT    ;COMPARE
2560      BEQ      TST116          ;;BR IF SAME
2561      ERROR    31              ;OVERFLOW FROM INC. REG. FAILED TO INHIBIT
2562      ;'INC CNT' FROM CHANGING THE DATA OR
2563      ;'CSR BYTE CELLS' FAILED TO INHIBIT 'INC ENA HI'

```

CHECK FOR WORD "INC OVFL" TO SET CELL OVERFLOW AND "CLR ALL" TO CLEAR IT

```

2564
2565
2566
2567 020052 000004
2568 020054 012737 000040 001160
2569 020062 012777 004000 161666
2570 020070 005077 161660
2571 020074 005077 161652
2572 020100 012777 060000 161642
2573 020106 012777 000024 161632
2574 020114 012777 000014 161634
2575 020122 052777 000001 161616
2576 020130 052777 000002 161620
2577 020136 052777 000002 161612
2578 020144 000240
2579 020146 000240
2580 020150 000240
2581 020152 012737 177777 060000
2582 020160 052777 015000 161570
2583 020166 000240
2584 020170 000240
2585 020172 000240
2586 020174 017737 161546 001126
2587 020202 012737 020024 001124
2588 020210 023737 001124 001126
2589 020216 001401
2590 020220 104031
2591
2592 020222 052777 004000 161526
2593 020230 017737 161512 001126
2594 020236 012737 000200 001124
2595 020244 023737 001124 001126
2596 020252 001401
2597 020254 104031
2598
2599 020256 013737 060000 001126
2600 020264 012737 177777 001124
2601 020272 023737 001124 001126
2602 020300 001401
2603 020302 104031

```

```

*****
*TEST 116 CHECK FOR WORD "INC OVFL" TO SET CELL OVERFLOW AND "CLR ALL" TO CLEAR IT
*****
TST116: SCOPE
MOV #40,$TIMES ;;DO 40 ITERATIONS
MOV #CLRALL,@SFR ;CLEAR THE DEVICE
CLR @BAR
CLR @WCR
MOV #BUFO,@OFF ;LOAD INITIAL OFFSET REGISTER
MOV #BIT4!BIT2,@CSR ;ENABLE MATRIX MODE
MOV #TSTDMA!TSTCON,@SFR ;SET TEST DMA AND CONTROL
BIS #BIT0,@CSR ;ENABLE THE DEVICE
BIS #TESTZ,@SFR ;ENABLE "TEST Z" PULSES
BIC #TESTZ,@SFR ;DISABLE "TEST Z" PULSES
NOP
NOP
NOP
MOV #-1,BUFO ;SET BUFO LOC. TO WORD -1
BIS #BIT12,@SFR ;ALLOW 1 TRANSFER
NOP
NOP
MOV @CSR,$BDDAT ;READ STATUS
MOV #BIT13!BIT4!BIT2,$GDDAT ;LOAD EXPECTED STATUS
CMP $GDDAT,$BDDAT ;COMPARE VALUES
BEQ 1$ ;;BR IF SAME
ERROR 31 ;"CELL OVERFLOW" FLOP FAILED TO SET
;NOW GENERATE "CLR ALL" TO CLEAR CELL OVERFLOW FLOP
1$: BIS #CLRALL,@SFR ;GENERATE "CLR ALL"
MOV @CSR,$BDDAT ;READ STATUS
MOV #BIT7,$GDDAT ;LOAD EXPECTED
CMP $GDDAT,$BDDAT ;COMPARE VALUES
BEQ 2$ ;;BR IF SAME
ERROR 31 ;"CLR ALL" FAILED TO CLEAR "CELL OVFL" FLOP
;NOW VERIFY THE WORD CELL DATA
2$: MOV BUFO,$BDDAT ;READ DATA
MOV #-1,$GDDAT ;LOAD EXPECTED
CMP $GDDAT,$BDDAT ;COMPARE
BEQ TST17 ;;BR IF SAME
ERROR 31

```

```
2604 ::*****
2605 :*TEST 117 CHECK FOR 'CELL OVERFLOW' INTERRUPT
2606 :*****
2607 TST117: SCOPE
2608 020304 000004 MOV #40,$TIMES ;;DO 40 ITERATIONS
2609 020306 012737 000040 001160 MOV #CLRALL,@SFR ;CLEAR THE DEVICE
2610 020314 012777 004000 161434 CLR @BAR
2611 020322 005077 161426 CLR @WCR
2612 020332 012777 060000 161410 MOV #BUFO,@OFF ;LOAD INITIAL OFFSET REGISTER
2613 020340 012777 000064 161400 MOV #BIT5!BIT4!BIT2,@CSR ;ENABLE INTR. AND MATRIX MODE
2614 020346 012777 000014 161402 MOV #TSTDMA!TSTCON,@SFR ;SET TEST DMA AND CONTROL
2615 020354 052777 000001 161364 BIS #BIT0,@CSR ;ENABLE THE DEVICE
2616 020362 052777 000002 161366 BIS #TESTZ,@SFR ;ENABLE 'TEST Z' PULSES
2617 020370 042777 000002 161360 BIC #TESTZ,@SFR ;DISABLE 'TEST Z' PULSES
2618 020376 000240 NOP
2619 020400 000240 NOP
2620 020402 000240 NOP
2621 020404 012737 177777 060000 MOV #-1,BUFO ;SET BUFO LOC. TO WORD -1
2622 020412 012746 000000 MOV #0,-(SP)
2623 020416 012746 020424 MOV #1$,-(SP)
2624 020422 000002 RTI
2625 020424 012777 020452 161344 1$: MOV #2$,@VECTB0 ;LOAD RETURN VECTOR
2626 020432 052777 010000 161316 BIS #BIT12,@SFR ;ALLOW 1 TRANSFER
2627 020440 000240 NOP
2628 020442 000240 NOP
2629 020444 000240 NOP
2630 020446 104032 ERROR 32 ;'CELL OVERFLOW' FAILED TO CAUES AN INTERRUPT
2631 020450 000414 BR 3$ ;;BR TO CLEAN UP
2632 020452 022626 2$: CMP (SP)+,(SP)+
2633 020454 017737 161266 001126 MOV @CSR,$BDDAT ;READ STATUS
2634 020462 012737 020264 001124 MOV #BIT13!BIT7!BIT5!BIT4!BIT2,$GDDAT ;LOAD EXPECTED
2635 020470 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE VALUE
2636 020476 001401 BEQ 3$ ;;BR IF 'ACTIVE' CLEARED
2637 020500 104031 ERROR 31 ;'ACTIVE' FAILED TO CLEAR
2638 020502 012777 004000 161246 3$: MOV #CLRALL,@SFR ;CLEAR THE DEVICE
2639 020510 013777 002000 161260 MOV VECTB1,@VECTB0 ;RESET THE VECTORS
2640 020516 005077 161256 CLR @VECTB1
```

```

2641
2642
2643
2644 020522 000004
2645 020524 012737 000040 001160
2646 020532 013746 002002
2647 020536 012746 020544
2648 020542 000002
2649 020544 012777 004000 161204 1$:
2650 020552 012777 020746 161216
2651 020560 012777 000340 161212
2652 020566 005077 161162
2653 020572 005077 161154
2654 020576 012777 060000 161144
2655 020604 012777 000064 161134
2656 020612 012777 000014 161136
2657 020620 012737 177777 060000
2658 020626 052777 000001 161112
2659 020634 052777 000002 161114
2660 020642 042777 000002 161106
2661 020650 000240
2662 020652 000240
2663 020654 000240
2664 020656 052777 010000 161072
2665 020664 000240
2666 020666 000240
2667 020670 000240
2668 020672 000240
2669 020674 000240
2670 020676 000240
2671 020700 013700 002002
2672 020704 162700 000040
2673 020710 005737 003354
2674 020714 001401
2675 020716 005000
2676 020720 012777 020754 161050 2$:
2677 020726 010046
2678 020730 012746 020736
2679 020734 000002
2680 020736 000240 3$:
2681 020740 000240
2682 020742 104042
2683 020744 000404
2684
2685
2686 020746 022626
2687 020750 104042
2688 020752 000401
2689
2690
2691 020754 022626
2692 020756 012777 004000 160772
2693 020764 013777 002000 161004
2694 020772 005077 161002

```

```

:*****
:*TEST 120 VERIFY CORRECT BR LEVEL THE NCV-11
:*****
TST120: SCOPE
MOV #40,$TIMES ;DO 40 ITERATIONS
MOV BRLEV,-(SP) ;PUSH THE EXPECTED BR LEVEL ON STACK
MOV #1$,-(SP) ;PUSH THE RETURN ADDRESS ON STACK
RTI ;FAKE AN INTERRUPT TO BE LSI-11 AND PDP-11 COMPATABLE
1$: MOV #CLRALL,@SFR ;CLEAR THE DEVICE
MOV #10$,@VECTB0 ;LOAD UNEXPECTED INTERRUPT RETURN
MOV #340,@VECTB1
CLR @BAR ;INIT THE LOW Z COUNT
CLR @WCR ;INIT THE HIGH Z COUNT
MOV #BUFO,@OFF ;PRIME THE OFFSET REGISTER
MOV #64,@CSR ;SELECT INTR. AND MATRIX MODE
MOV #TSTDMA!TSTCON,@SFR ;MAINT. MODE
MOV #-1,BUFO ;PRIME THE TARGET LOCATION
BIS #BIT0,@CSR ;ENABLE THE NCV-11
BIS #TESTZ,@SFR ;ENABLE 'TEST Z' PULSES
BIC #TESTZ,@SFR ;DISABLE 'TEST Z' PULSES
NOP
NOP
NOP
BIS #BIT12,@SFR ;ENABLE 1 TRANSFER
NOP
NOP
NOP
MOV BRLEV,R0 ;GET CURRENT BR LEVEL
SUB #40,R0 ;AND MAKE IT 1 LEVEL LOWER
TST NLSI11 ;TEST IF LSI-11 CPU
BEQ 2$ ;BR IF NOT
CLR R0 ;LOAD BR LEVEL 0
2$: MOV #20$,@VECTB0 ;RELOAD TO EXPECTED VECTOR
MOV R0,-(SP) ;PUSH ADJUSTED BR LEVEL
MOV #3$,-(SP) ;PUSH RETURN ADDRESS
RTI ;LOWER CPU BR LEVEL
3$: NOP
NOP
ERROR 42 ;NCV11 FAILED TO INTERRUPT - INCORRECT NCV11 BR LEVEL?
BR 21$ ;BR TO CLEAN-UP
;UNEXPECTED INTERRUPT WITH BR LEVEL INDICATED
10$: CMP (SP)+,(SP)+ ;CLEAN THE STACK
ERROR 42 ;NCV11 INTERRUPTED ON AN INCORRECT BR LEVEL
BR 21$ ;BR TO CLEANUP
;EXPECTED INTERRUPT DID OCCUR
20$: CMP (SP)+,(SP)+ ;CLEAN THE STACK
21$: MOV #CLRALL,@SFR ;CLEAR THE DEVICE
MOV VECTB1,@VECTB0 ;RESET THE VECTOR
CLR @VECTB1

```

2695  
2696  
2697  
2698 020776 000004  
2699 021000 012737 000100 001160  
2700 021006 012777 004000 160742  
2701 021014 012777 060000 160726  
2702 021022 012777 000014 160726  
2703 021030 012777 000024 160710  
2704 021036 052777 000001 160702  
2705 021044 052777 000002 160704  
2706 021052 042777 000002 160676  
2707 021060 005037 060000  
2708 021064 052777 010000 160664  
2709 021072 012737 060000 001122  
2710 021100 012737 000001 001124  
2711 021106 017737 160010 001126  
2712 021114 023737 001124 001126  
2713 021122 001401  
2714 021124 104033  
2715  
2716  
2717  
2718  
2719 021126 000004  
2720 021130 012737 000100 001160  
2721 021136 012777 004000 160612  
2722 021144 012777 070000 160576  
2723 021152 012777 000014 160576  
2724 021160 012777 000024 160560  
2725 021166 052777 000001 160552  
2726 021174 052777 000002 160554  
2727 021202 042777 000002 160546  
2728 021210 005037 070000  
2729 021214 052777 010000 160534  
2730 021222 012737 070000 001122  
2731 021230 012737 000001 001124  
2732 021236 017737 157660 001126  
2733 021244 023737 001124 001126  
2734 021252 001401  
2735 021254 104033  
2736

```
::*****  
:*TEST 121 VERIFY A 1 WORD MATRIX MODE XFR USING OFFSET - 13  
:*****  
TST121: SCOPE  
MOV #100,$TIMES ;;DO 100 ITERATIONS  
MOV #CLRALL,@SFR ;CLEAR THE DEVICE  
MOV #60000,@OFF ;LOAD THE OFFSET REG.  
MOV #TSTDMA!TSTCON,@SFR ;SET TEST DMA AND CONTROL  
MOV #BIT4!BIT2,@CSR ;SELECT MATRIX WORD MODE  
BIS #BIT0,@CSR ;ENABLE NCV11  
BIS #TESTZ,@SFR ;ENABLE 'TEST Z' PULSES  
BIC #TESTZ,@SFR ;DISABLE 'TEST Z' PULSES  
CLR @#60000 ;CLEAR THE TARGET LOCATION  
BIS #BIT12,@SFR ;ALLOW 1 WORD TRANSFER  
MOV #60000,$BDADR ;LOAD EXPECTED ADDRESS  
MOV #1,$GDDAT ;LOAD EXPECTED DATA  
MOV @$BDADR,$BDDAT ;READ THE ACTUAL DATA  
CMP $GDDAT,$BDDAT ;COMPARE  
BEQ TST122 ;;BR IF SAME  
ERROR 33 ;OFFSET INPUT TO MATRIX MUX. SELECTED  
 ;THE WRONG ADDRESS - EXPECTED ADR. WAS 60000  
:*****  
:*TEST 122 VERIFY A 1 WORD MATRIX MODE XFR USING OFFSET - 12  
:*****  
TST122: SCOPE  
MOV #100,$TIMES ;;DO 100 ITERATIONS  
MOV #CLRALL,@SFR ;CLEAR THE DEVICE  
MOV #70000,@OFF ;LOAD THE OFFSET REG.  
MOV #TSTDMA!TSTCON,@SFR ;SET TEST DMA AND CONTROL  
MOV #BIT4!BIT2,@CSR ;SELECT MATRIX WORD MODE  
BIS #BIT0,@CSR ;ENABLE NCV11  
BIS #TESTZ,@SFR ;ENABLE 'TEST Z' PULSES  
BIC #TESTZ,@SFR ;DISABLE 'TEST Z' PULSES  
CLR @#70000 ;CLEAR THE TARGET LOCATION  
BIS #BIT12,@SFR ;ALLOW 1 WORD TRANSFER  
MOV #70000,$BDADR ;LOAD EXPECTED ADDRESS  
MOV #1,$GDDAT ;LOAD EXPECTED DATA  
MOV @$BDADR,$BDDAT ;READ THE ACTUAL DATA  
CMP $GDDAT,$BDDAT ;COMPARE  
BEQ TST123 ;;BR IF SAME  
ERROR 33 ;OFFSET INPUT TO MATRIX MUX. SELECTED  
 ;THE WRONG ADDRESS - EXPECTED ADR. WAS 70000
```



2737  
2738  
2739  
2740 021256 000004  
2741 021260 012737 000100 001160  
2742 021266 012777 004000 160462  
2743 021274 012777 064000 160446  
2744 021302 012777 000014 160446  
2745 021310 012777 000024 160430  
2746 021316 052777 000001 160422  
2747 021324 052777 000002 160424  
2748 021332 042777 000002 160416  
2749 021340 005037 064000  
2750 021344 052777 010000 160404  
2751 021352 012737 064000 001122  
2752 021360 012737 000001 001124  
2753 021366 017737 157530 001126  
2754 021374 023737 001124 001126  
2755 021402 001401  
2756 021404 104033  
2757  
2758  
2759  
2760  
2761 021406 000004  
2762 021410 012737 000100 001160  
2763 021416 012777 004000 160332  
2764 021424 012777 062000 160316  
2765 021432 012777 000014 160316  
2766 021440 012777 000024 160300  
2767 021446 052777 000001 160272  
2768 021454 052777 000002 160274  
2769 021462 042777 000002 160266  
2770 021470 005037 062000  
2771 021474 052777 010000 160254  
2772 021502 012737 062000 001122  
2773 021510 012737 000001 001124  
2774 021516 017737 157400 001126  
2775 021524 023737 001124 001126  
2776 021532 001401  
2777 021534 104033  
2778

```
*****  
*TEST 123 VERIFY A 1 WORD MATRIX MODE XFR USING OFFSET - 11  
*****  
TST123: SCOPE  
MOV #100,$TIMES ;;DO 100 ITERATIONS  
MOV #CLRALL,@SFR ;CLEAR THE DEVICE  
MOV #64000,@OFF ;LOAD THE OFFSET REG.  
MOV #TSTDMA!TSTCON,@SFR ;SET TEST DMA AND CONTROL  
MOV #BIT4!BIT2,@CSR ;SELECT MATRIX WORD MODE  
BIS #BIT0,@CSR ;ENABLE NCV11  
BIS #TESTZ,@SFR ;ENABLE 'TEST Z' PULSES  
BIC #TESTZ,@SFR ;DISABLE 'TEST Z' PULSES  
CLR @#64000 ;CLEAR THE TARGET LOCATION  
BIS #BIT12,@SFR ;ALLOW 1 WORD TRANSFER  
MOV #64000,$BDADR ;LOAD EXPECTED ADDRESS  
MOV #1,$GDDAT ;LOAD EXPECTED DATA  
MOV @SBDADR,$BDDAT ;READ THE ACTUAL DATA  
CMP $GDDAT,$BDDAT ;COMPARE  
BEQ TST124 ;;BR IF SAME  
ERROR 33 ;OFFSET INPUT TO MATRIX MUX. SELECTED  
;THE WRONG ADDRESS - EXPECTED ADR. WAS 64000  
*****  
*TEST 124 VERIFY A 1 WORD MATRIX MODE XFR USING OFFSET - 10  
*****  
TST124: SCOPE  
MOV #100,$TIMES ;;DO 100 ITERATIONS  
MOV #CLRALL,@SFR ;CLEAR THE DEVICE  
MOV #62000,@OFF ;LOAD THE OFFSET REG.  
MOV #TSTDMA!TSTCON,@SFR ;SET TEST DMA AND CONTROL  
MOV #BIT4!BIT2,@CSR ;SELECT MATRIX WORD MODE  
BIS #BIT0,@CSR ;ENABLE NCV11  
BIS #TESTZ,@SFR ;ENABLE 'TEST Z' PULSES  
BIC #TESTZ,@SFR ;DISABLE 'TEST Z' PULSES  
CLR @#62000 ;CLEAR THE TARGET LOCATION  
BIS #BIT12,@SFR ;ALLOW 1 WORD TRANSFER  
MOV #62000,$BDADR ;LOAD EXPECTED ADDRESS  
MOV #1,$GDDAT ;LOAD EXPECTED DATA  
MOV @SBDADR,$BDDAT ;READ THE ACTUAL DATA  
CMP $GDDAT,$BDDAT ;COMPARE  
BEQ TST125 ;;BR IF SAME  
ERROR 33 ;OFFSET INPUT TO MATRIX MUX. SELECTED  
;THE WRONG ADDRESS - EXPECTED ADR. WAS 62000
```

```
2779
2780
2781
2782 021536 000004
2783 021540 012737 000100 001160
2784 021546 012777 004000 160202
2785 021554 012777 061000 160166
2786 021562 012777 000014 160166
2787 021570 012777 000024 160150
2788 021576 052777 000001 160142
2789 021604 052777 000002 160144
2790 021612 042777 000002 160136
2791 021620 005037 061000
2792 021624 052777 010000 160124
2793 021632 012737 061000 001122
2794 021640 012737 000001 001124
2795 021646 017737 157250 001126
2796 021654 023737 001124 001126
2797 021662 001401
2798 021664 104033
2799
2800
2801
2802
2803 021666 000004
2804 021670 012737 000100 001160
2805 021676 012777 004000 160052
2806 021704 012777 060400 160036
2807 021712 012777 000014 160036
2808 021720 012777 000024 160020
2809 021726 052777 000001 160012
2810 021734 052777 000002 160014
2811 021742 042777 000002 160006
2812 021750 005037 060400
2813 021754 052777 010000 157774
2814 021762 012737 060400 001122
2815 021770 012737 000001 001124
2816 021776 017737 157120 001126
2817 022004 023737 001124 001126
2818 022012 001401
2819 022014 104033
2820
```

```
*****
*TEST 125 VERIFY A 1 WORD MATRIX MODE XFR USING OFFSET - 09
*****
TST125: SCOPE
MOV #100,$TIMES ;;DO 100 ITERATIONS
MOV #CLRALL,@SFR ;CLEAR THE DEVICE
MOV #61000,@OFF ;LOAD THE OFFSET REG.
MOV #TSTDMA!TSTCON,@SFR ;SET TEST DMA AND CONTROL
MOV #BIT4!BIT2,@CSR ;SELECT MATRIX WORD MODE
BIS #BIT0,@CSR ;ENABLE NCV11
BIS #TESTZ,@SFR ;ENABLE 'TEST Z' PULSES
BIC #TESTZ,@SFR ;DISABLE 'TEST Z' PULSES
CLR @#61000 ;CLEAR THE TARGET LOCATION
BIS #BIT12,@SFR ;ALLOW 1 WORD TRANSFER
MOV #61000,$BDADR ;LOAD EXPECTED ADDRESS
MOV #1,$GDDAT ;LOAD EXPECTED DATA
MOV @$BDADR,$BDDAT ;READ THE ACTUAL DATA
CMP $GDDAT,$BDDAT ;COMPARE
BEQ TST126 ;;BR IF SAME
ERROR 33 ;OFFSET INPUT TO MATRIX MUX. SELECTED
;THE WRONG ADDRESS - EXPECTED ADR. WAS 61000
*****
*TEST 126 VERIFY A 1 WORD MATRIX MODE XFR USING OFFSET - 08
*****
TST126: SCOPE
MOV #100,$TIMES ;;DO 100 ITERATIONS
MOV #CLRALL,@SFR ;CLEAR THE DEVICE
MOV #60400,@OFF ;LOAD THE OFFSET REG.
MOV #TSTDMA!TSTCON,@SFR ;SET TEST DMA AND CONTROL
MOV #BIT4!BIT2,@CSR ;SELECT MATRIX WORD MODE
BIS #BIT0,@CSR ;ENABLE NCV11
BIS #TESTZ,@SFR ;ENABLE 'TEST Z' PULSES
BIC #TESTZ,@SFR ;DISABLE 'TEST Z' PULSES
CLR @#60400 ;CLEAR THE TARGET LOCATION
BIS #BIT12,@SFR ;ALLOW 1 WORD TRANSFER
MOV #60400,$BDADR ;LOAD EXPECTED ADDRESS
MOV #1,$GDDAT ;LOAD EXPECTED DATA
MOV @$BDADR,$BDDAT ;READ THE ACTUAL DATA
CMP $GDDAT,$BDDAT ;COMPARE
BEQ TST127 ;;BR IF SAME
ERROR 33 ;OFFSET INPUT TO MATRIX MUX. SELECTED
;THE WRONG ADDRESS - EXPECTED ADR. WAS 60400
```

```

2821
2822
2823
2824 022016 000004
2825 022020 012737 000100 001160
2826 022026 012777 004000 157722
2827 022034 012777 060200 157706
2828 022042 012777 000014 157706
2829 022050 012777 000024 157670
2830 022056 052777 000001 157662
2831 022064 052777 000002 157664
2832 022072 042777 000002 157656
2833 022100 005037 060200
2834 022104 052777 010000 157644
2835 022112 012737 060200 001122
2836 022120 012737 000001 001124
2837 022126 017737 156770 001126
2838 022134 023737 001124 001126
2839 022142 001401
2840 022144 104033
2841
2842
2843
2844
2845 022146 000004
2846 022150 012737 000100 001160
2847 022156 012777 004000 157572
2848 022164 012777 060100 157556
2849 022172 012777 000014 157556
2850 022200 012777 000024 157540
2851 022206 052777 000001 157532
2852 022214 052777 000002 157534
2853 022222 042777 000002 157526
2854 022230 005037 060100
2855 022234 052777 010000 157514
2856 022242 012737 060100 001122
2857 022250 012737 000001 001124
2858 022256 017737 156640 001126
2859 022264 023737 001124 001126
2860 022272 001401
2861 022274 104033
2862

::*****
:*TEST 127 VERIFY A 1 WORD MATRIX MODE XFR USING OFFSET - 07
::*****
TST127: SCOPE
MOV #100,$TIMES ;;DO 100 ITERATIONS
MOV #CLRALL,@SFR ;CLEAR THE DEVICE
MOV #60200,@OFF ;LOAD THE OFFSET REG.
MOV #TSTDMA!TSTCON,@SFR ;SET TEST DMA AND CONTROL
MOV #BIT4!BIT2,@CSR ;SELECT MATRIX WORD MODE
BIS #BIT0,@CSR ;ENABLE NCV11
BIS #TESTZ,@SFR ;ENABLE 'TEST Z' PULSES
BIC #TESTZ,@SFR ;DISABLE 'TEST Z' PULSES
CLR @#60200 ;CLEAR THE TARGET LOCATION
BIS #BIT12,@SFR ;ALLOW 1 WORD TRANSFER
MOV #60200,$BDADR ;LOAD EXPECTED ADDRESS
MOV #1,$GDDAT ;LOAD EXPECTED DATA
MOV @$BDADR,$BDDAT ;READ THE ACTUAL DATA
CMP $GDDAT,$BDDAT ;COMPARE
BEQ TST130 ;;BR IF SAME
ERROR 33 ;OFFSET INPUT TO MATRIX MUX. SELECTED
;THE WRONG ADDRESS - EXPECTED ADR. WAS 60200

::*****
:*TEST 130 VERIFY A 1 WORD MATRIX MODE XFR USING OFFSET - 06
::*****
TST130: SCOPE
MOV #100,$TIMES ;;DO 100 ITERATIONS
MOV #CLRALL,@SFR ;CLEAR THE DEVICE
MOV #60100,@OFF ;LOAD THE OFFSET REG.
MOV #TSTDMA!TSTCON,@SFR ;SET TEST DMA AND CONTROL
MOV #BIT4!BIT2,@CSR ;SELECT MATRIX WORD MODE
BIS #BIT0,@CSR ;ENABLE NCV11
BIS #TESTZ,@SFR ;ENABLE 'TEST Z' PULSES
BIC #TESTZ,@SFR ;DISABLE 'TEST Z' PULSES
CLR @#60100 ;CLEAR THE TARGET LOCATION
BIS #BIT12,@SFR ;ALLOW 1 WORD TRANSFER
MOV #60100,$BDADR ;LOAD EXPECTED ADDRESS
MOV #1,$GDDAT ;LOAD EXPECTED DATA
MOV @$BDADR,$BDDAT ;READ THE ACTUAL DATA
CMP $GDDAT,$BDDAT ;COMPARE
BEQ TST131 ;;BR IF SAME
ERROR 33 ;OFFSET INPUT TO MATRIX MUX. SELECTED
;THE WRONG ADDRESS - EXPECTED ADR. WAS 60100

```

```

2863
2864
2865
2866 022276 000004
2867 022300 012737 000100 001160
2868 022306 012777 004000 157442
2869 022314 012777 060040 157426
2870 022322 012777 000014 157426
2871 022330 012777 000024 157410
2872 022336 052777 000001 157402
2873 022344 052777 000002 157404
2874 022352 042777 000002 157376
2875 022360 005037 060040
2876 022364 052777 010000 157364
2877 022372 012737 060040 001122
2878 022400 012737 000001 001124
2879 022406 017737 156510 001126
2880 022414 023737 001124 001126
2881 022422 001401
2882 022424 104033
2883
2884
2885
2886
2887 022426 000004
2888 022430 012737 000100 001160
2889 022436 012777 004000 157312
2890 022444 012777 060020 157276
2891 022452 012777 000014 157276
2892 022460 012777 000024 157260
2893 022466 052777 000001 157252
2894 022474 052777 000002 157254
2895 022502 042777 000002 157246
2896 022510 005037 060020
2897 022514 052777 010000 157234
2898 022522 012737 060020 001122
2899 022530 012737 000001 001124
2900 022536 017737 156360 001126
2901 022544 023737 001124 001126
2902 022552 001401
2903 022554 104033
2904

```

```

*****
*TEST 131 VERIFY A 1 WORD MATRIX MODE XFR USING OFFSET - 05
*****
TST131: SCOPE
MOV #100,$TIMES ;;DO 100 ITERATIONS
MOV #CLRALL,@SFR ;CLEAR THE DEVICE
MOV #60040,@OFF ;LOAD THE OFFSET REG.
MOV #TSTDMA!TSTCON,@SFR ;SET TEST DMA AND CONTROL
MOV #BIT4!BIT2,@CSR ;SELECT MATRIX WORD MODE
BIS #BIT0,@CSR ;ENABLE NCV11
BIS #TESTZ,@SFR ;ENABLE 'TEST Z' PULSES
BIC #TESTZ,@SFR ;DISABLE 'TEST Z' PULSES
CLR @#60040 ;CLEAR THE TARGET LOCATION
BIS #BIT12,@SFR ;ALLOW 1 WORD TRANSFER
MOV #60040,$BDADR ;LOAD EXPECTED ADDRESS
MOV #1,$GDDAT ;LOAD EXPECTED DATA
MOV @$BDADR,$BDDAT ;READ THE ACTUAL DATA
CMP $GDDAT,$BDDAT ;COMPARE
BEQ TST132 ;;BR IF SAME
ERROR 33 ;OFFSET INPUT TO MATRIX MUX. SELECTED
;THE WRONG ADDRESS - EXPECTED ADR. WAS 60040
*****
*TEST 132 VERIFY A 1 WORD MATRIX MODE XFR USING OFFSET - 04
*****
TST132: SCOPE
MOV #100,$TIMES ;;DO 100 ITERATIONS
MOV #CLRALL,@SFR ;CLEAR THE DEVICE
MOV #60020,@OFF ;LOAD THE OFFSET REG.
MOV #TSTDMA!TSTCON,@SFR ;SET TEST DMA AND CONTROL
MOV #BIT4!BIT2,@CSR ;SELECT MATRIX WORD MODE
BIS #BIT0,@CSR ;ENABLE NCV11
BIS #TESTZ,@SFR ;ENABLE 'TEST Z' PULSES
BIC #TESTZ,@SFR ;DISABLE 'TEST Z' PULSES
CLR @#60020 ;CLEAR THE TARGET LOCATION
BIS #BIT12,@SFR ;ALLOW 1 WORD TRANSFER
MOV #60020,$BDADR ;LOAD EXPECTED ADDRESS
MOV #1,$GDDAT ;LOAD EXPECTED DATA
MOV @$BDADR,$BDDAT ;READ THE ACTUAL DATA
CMP $GDDAT,$BDDAT ;COMPARE
BEQ TST133 ;;BR IF SAME
ERROR 33 ;OFFSET INPUT TO MATRIX MUX. SELECTED
;THE WRONG ADDRESS - EXPECTED ADR. WAS 60020

```

```
2905
2906
2907
2908 022556 000004
2909 022560 012737 000100 001160
2910 022566 012777 004000 157162
2911 022574 012777 060010 157146
2912 022602 012777 000014 157146
2913 022610 012777 000024 157130
2914 022616 052777 000001 157122
2915 022624 052777 000002 157124
2916 022632 042777 000002 157116
2917 022640 005037 060010
2918 022644 052777 010000 157104
2919 022652 012737 060010 001122
2920 022660 012737 000001 001124
2921 022666 017737 156230 001126
2922 022674 023737 001124 001126
2923 022702 001401
2924 022704 104033
2925
2926
2927
2928
2929 022706 000004
2930 022710 012737 000100 001160
2931 022716 012777 004000 157032
2932 022724 012777 040004 157016
2933 022732 012777 000014 157016
2934 022740 012777 000024 157000
2935 022746 052777 000001 156772
2936 022754 052777 000002 156774
2937 022762 042777 000002 156766
2938 022770 005037 040004
2939 022774 052777 010000 156754
2940 023002 012737 040004 001122
2941 023010 012737 000001 001124
2942 023016 017737 156100 001126
2943 023024 023737 001124 001126
2944 023032 001401
2945 023034 104033
2946
```

```
*****
*TEST 133 VERIFY A 1 WORD MATRIX MODE XFR USING OFFSET - 03
*****
TST133: SCOPE
MOV #100,$TIMES ;;DO 100 ITERATIONS
MOV #CLRALL,@SFR ;CLEAR THE DEVICE
MOV #60010,@OFF ;LOAD THE OFFSET REG.
MOV #TSTDMA!TSTCON,@SFR ;SET TEST DMA AND CONTROL
MOV #BIT4!BIT2,@CSR ;SELECT MATRIX WORD MODE
BIS #BIT0,@CSR ;ENABLE NCV11
BIS #TESTZ,@SFR ;ENABLE 'TEST Z' PULSES
BIC #TESTZ,@SFR ;DISABLE 'TEST Z' PULSES
CLR @#60010 ;CLEAR THE TARGET LOCATION
BIS #BIT12,@SFR ;ALLOW 1 WORD TRANSFER
MOV #60010,$BDADR ;LOAD EXPECTED ADDRESS
MOV #1,$GDDAT ;LOAD EXPECTED DATA
MOV @$BDADR,$BDDAT ;READ THE ACTUAL DATA
CMP $GDDAT,$BDDAT ;COMPARE
BEQ TST134 ;;BR IF SAME
ERROR 33 ;OFFSET INPUT TO MATRIX MUX. SELECTED
;THE WRONG ADDRESS - EXPECTED ADR. WAS 60010
*****
*TEST 134 VERIFY A 1 WORD MATRIX MODE XFR USING OFFSET - 02
*****
TST134: SCOPE
MOV #100,$TIMES ;;DO 100 ITERATIONS
MOV #CLRALL,@SFR ;CLEAR THE DEVICE
MOV #40004,@OFF ;LOAD THE OFFSET REG.
MOV #TSTDMA!TSTCON,@SFR ;SET TEST DMA AND CONTROL
MOV #BIT4!BIT2,@CSR ;SELECT MATRIX WORD MODE
BIS #BIT0,@CSR ;ENABLE NCV11
BIS #TESTZ,@SFR ;ENABLE 'TEST Z' PULSES
BIC #TESTZ,@SFR ;DISABLE 'TEST Z' PULSES
CLR @#40004 ;CLEAR THE TARGET LOCATION
BIS #BIT12,@SFR ;ALLOW 1 WORD TRANSFER
MOV #40004,$BDADR ;LOAD EXPECTED ADDRESS
MOV #1,$GDDAT ;LOAD EXPECTED DATA
MOV @$BDADR,$BDDAT ;READ THE ACTUAL DATA
CMP $GDDAT,$BDDAT ;COMPARE
BEQ TST135 ;;BR IF SAME
ERROR 33 ;OFFSET INPUT TO MATRIX MUX. SELECTED
;THE WRONG ADDRESS - EXPECTED ADR. WAS 40004
```

```

2947
2948
2949
2950 023036 000004
2951 023040 012737 000010 001160
2952
2953
2954
2955 023046 012777 004000 156702
2956 023054 012777 062550 156666
2957 023062 012777 000014 156666
2958 023070 012777 002024 156650
2959 023076 052777 000001 156642
2960 023104 052777 000002 156644
2961 023112 042777 000002 156636
2962 023120 005037 065322
2963 023124 005037 062722
2964 023130 052777 010000 156620
2965 023136 000240
2966 023140 000240
2967 023142 000240
2968 023144 012737 065322 001122
2969 023152 012737 000001 001124
2970 023160 017737 155736 001126
2971 023166 023737 001124 001126
2972 023174 001413
2973 023176 005737 062722
2974 023202 001002
2975 023204 104033
2976
2977 023206 000406
2978 023210 013737 062722 001126 1$:
2979 023216 005037 001124
2980 023222 104033
2981
  
```

```

*****
:*TEST 135 VERIFY THE ADM INPUT TO THE MATRIX MUX. USING GAIN ENABLE
*****
TST135: SCOPE
MOV #10,$TIMES ;;DO 10 ITERATIONS
;WITH GAIN SET IN TEST CONTROL MODE, THE SELF TEST DATA SHOULD BE BYTE 250
;WHEN PROCESSED THRU THE ADDRESS MAKER LOGIC THE NEW VALUE IS '2552'
;VERIFY THAT THE MATRIX MUX CAN ADD 62550 AND 2552 CORRECTLY
MOV #CLRALL,@SFR ;CLEAR THE DEVICE
MOV #BUF0+2550,@OFF ;LOAD THE OFFSET REG.
MOV #TSTDMA!TSTCON,@SFR ;SET TEST DMA AND CONTROL
MOV #2024,@CSR ;ENABLE GAIN, WORD MATRIX MODE
BIS #BIT0,@CSR ;ENABLE THE NCV11
BIS #TESTZ,@SFR ;ENABLE 'TEST Z' PULSES
BIC #TESTZ,@SFR ;DISABLE 'TEST Z' PULSES
CLR @#BUF0+5322 ;CLEAR THE TARGET ADDRESS
CLR @#BUF0+2722 ;CLEAR THE TARGET ADDRESS IF 'TESTX' FAILS
BIS #BIT12,@SFR ;ALLOW 1 TRANSFER
NOP
NOP
NOP
MOV #BUF0+5322,$BDADR ;LOAD THE EXPECTED ADDRESS
MOV #1,$GDDAT ;LOAD THE EXPECTED DATA
MOV @#BDADR,$BDDAT ;READ THE ACTUAL DATA
CMP $GDDAT,$BDDAT ;COMPARE
BEQ TST136 ;;BR IF SAME
TST @#BUF0+2722 ;TEST OTHER ADDRESS
BNE 1$ ;BR IF NON-ZERO
ERROR 33 ;MATRIX MODE ADDER ERROR
;USING GAIN AND WORD MATRIX MODE, THE ADDRESSES SELECTED WAS INCORRECT
BR TST136 ;;
MOV @#BUF0+2722,$BDDAT ;LOAD INCORRECT DATA
CLR $GDDAT ;CLEAR THE EXPECTED DATA
ERROR 33 ;MATRIX MODE ADDER ERROR DUE TO
;'TESTX' LOGIC SET IN ERROR
  
```

```

2982
2983
2984
2985 023224 000004
2986 023226 012737 000010 001160
2987
2988
2989
2990 023234 012777 004000 156514
2991 023242 012777 065224 156500
2992 023250 012777 000014 156500
2993 023256 012777 004024 156462
2994 023264 052777 000002 156464
2995 023272 052777 000001 156446
2996 023300 042777 000001 156450
2997 023306 005037 072450
2998 023312 052777 010000 156436
2999 023320 012737 072450 001122
3000 023326 012737 000001 001124
3001 023334 017737 155562 001126
3002 023342 023737 001124 001126
3003 023350 001401
3004 023352 104033
3005
3006
3007
3008
3009 023354 000004
3010 023356 012737 000010 001160
3011 023364 012777 004000 156364
3012 023372 012777 060000 156350
3013 023400 012777 000014 156350
3014 023406 012777 002024 156332
3015 023414 052777 000001 156324
3016 023422 052777 000002 156326
3017 023430 042777 000002 156320
3018 023436 052777 000020 156312
3019 023444 005037 062552
3020 023450 005037 060152
3021 023454 052777 010000 156274
3022 023462 000240
3023 023464 000240
3024 023466 000240
3025 023470 012737 000001 001124
3026 023476 013737 060152 001126
3027 023504 023737 001124 001126
3028 023512 001413
3029 023514 005737 062552
3030 023520 001002
3031 023522 104034
3032 023524 000406
3033 023526 013737 062552 001126 1$:
3034 023534 005037 001124
3035 023540 104034

```

```

*****
*TEST 136 VERIFY THE ADM INPUT TO THE MATRIX MUX. ADDER USING ZB ENABLE
*****
TST136: SCOPE
MOV #10,$TIMES ;;DO 10 ITERATIONS
;WITH ZB ENABLE SET IN TEST CONTROL MODE, THE SELF TEST DATA SHOULD BE BYTE 224
;WHEN PROCESSED THRU THE ADDRESS MAKER LOGIC THE NEW VALUE IS 12450
;VERIFY THAT THE MATRIX MUX CAN ADD CORRECTLY
MOV #CLRALL,@SFR ;CLEAR THE DEVICE
MOV #BUF0+5224,@OFF ;LOAD THE OFFSET REGISTER
MOV #TSTDMA!TSTCON,@SFR ;SET TEST DMA AND CONTROL
MOV #4024,@CSR ;ENABLE ZB AND WORD MATRIX MODE
BIS #TESTZ,@SFR ;ENABLE 'TEST Z' PULSES
BIS #BIT0,@CSR ;ENABLE NCV11
BIC #BIT0,@SFR ;DISABLE 'TEST Z' PULSES
CLR @#BUF0+12450 ;CLEAR THE TARGET LOCATION
BIS #BIT12,@SFR ;ALLOW 1 TRANSFER
MOV #BUF0+12450,$BDDADR ;LOAD THE EXPECTED ADDRESS
MOV #1,$GDDAT ;LOAD THE EXPECTED DATA
MOV @#BDDADR,$BDDAT ;READ THE ACTUAL DATA
CMP $GDDAT,$BDDAT ;COMPARE
BEQ TST137 ;;BR IF SAME
ERROR 33 ;ADM INPUT TO THE MATRIX MUX SELECTED
;WRONG ADDRESS - EXPECTED ADDRESS WAS BUF0 + 2450
*****
*TEST 137 VERIFY LOW BYTE OPERATION OF THE 'TESTX' FLOP
*****
TST137: SCOPE
MOV #10,$TIMES ;;DO 10 ITERATIONS
MOV #CLRALL,@SFR ;CLEAR THE DEVICE
MOV #BUF0,@OFF ;LOAD OFFSET REG.
MOV #TSTDMA!TSTCON,@SFR ;LOAD TEST DMA AND CONTROL
MOV #2024,@CSR ;SET 'GAIN' AND WORD MATRIX MODE
BIS #BIT0,@CSR ;SET NCV11 ACTIVE
BIS #TESTZ,@SFR ;ENABLE 'TEST Z' PULSES
BIC #TESTZ,@SFR ;DISABLE 'TEST Z' PULSES
BIS #BIT4,@SFR ;SET 'TESTX' FLOP
CLR @#BUF0+2552 ;CLEAR THE TEST FAILED LOCATION
CLR @#BUF0+0152 ;CLEAR THE TESTX WORKED LOCATION
BIS #BIT12,@SFR ;ALLOW 1 TRANSFER
NOP
NOP
NOP
MOV #1,$GDDAT ;LOAD EXPECTED DATA
MOV @#BUF0+0152,$BDDAT ;READ THE ACTUAL DATA
CMP $GDDAT,$BDDAT ;COMPARE DATA
BEQ TST140 ;;BR IF SAME
TST @#BUF0+2552 ;TEST TESTX FAILED LOCATION
BNE 1$ ;;BR IF YES
ERROR 34 ;TESTX FAILED TO INHIBIT BITS 8-15 OF THE 'SUM ADDER'
BR TST140
MOV @#BUF0+2552,$BDDAT ;GET ACTUAL DATA
CLR $GDDAT ;CLEAR EXPECTED
ERROR 34 ;TESTX FAILED TO INHIBIT BITS 8-15 OF THE 'SUM A

```

CZI  
CZI

```

3036
3037
3038
3039 023542 000004
3040 023544 012737 000100 001160
3041 023552 012777 004000 156176
3042 023560 012777 050000 156162
3043 023566 012777 000014 156162
3044 023574 012777 002030 156144
3045 023602 052777 000001 156136
3046 023610 052777 000002 156140
3047 023616 042777 000002 156132
3048 023624 005037 062726
3049 023630 052777 010000 156120
3050 023636 012737 062726 001122
3051 023644 012737 000001 001124
3052 023652 017737 155244 001126
3053 023660 023737 001124 001126
3054 023666 001401
3055 023670 104033
3056
3057
3058
3059
3060 023672 000004
3061 023674 012737 000100 001160
3062 023702 012777 004000 156046
3063 023710 012777 037774 156032
3064 023716 012777 000014 156032
3065 023724 012777 002032 156014
3066 023732 052777 000001 156006
3067 023740 052777 000002 156010
3068 023746 042777 000002 156002
3069 023754 005037 065522
3070 023760 052777 010000 155770
3071 023766 012737 065522 001122
3072 023774 012737 000001 001124
3073 024002 017737 155114 001126
3074 024010 023737 001124 001126
3075 024016 001401
3076 024020 104033
3077

```

```

*****
*TEST 140 VERIFY BIT 12 ADDER INPUT TO MATRIX MODE MUX
*****

```

```

TST140: SCOPE
MOV #100,$TIMES ;;DO 100 ITERATIONS
MOV #CLRALL,@SFR ;CLEAR THE DEVICE
MOV #50000,@OFF ;LOAD THE OFFSET REG.
MOV #TSTDMA!TSTCON,@SFR ;SET TEST DMA AND CONTROL
MOV #2030,@CSR ;SELECT GAIN MATRIX BYTE MODE
BIS #BIT0,@CSR ;ENABLE NCV11
BIS #TESTZ,@SFR ;ENABLE 'TEST Z' PULSES
BIC #TESTZ,@SFR ;DISABLE 'TEST Z' PULSES
CLR @#BUF0+2726 ;CLEAR THE TARGET LOCATION
BIS #BIT12,@SFR ;ALLOW 1 WORD TRANSFER
MOV #BUF0+2726,$BDADR ;LOAD EXPECTED ADDRESS
MOV #1,$GDDAT ;LOAD EXPECTED DATA
MOV @#BDADR,$BDDAT ;READ THE ACTUAL DATA
CMP $GDDAT,$BDDAT ;COMPARE
BEQ TST141 ;;BR IF SAME
ERROR 33 ;MATRIX ADDER FAILED TO SELECT CORRECT ADDRESS
;THE WRONG ADDRESS - EXPECTED ADR. WAS BUF0+2726

```

```

*****
*TEST 141 VERIFY BIT 13 ADDER INPUT TO MATRIX MODE MUX
*****

```

```

TST141: SCOPE
MOV #100,$TIMES ;;DO 100 ITERATIONS
MOV #CLRALL,@SFR ;CLEAR THE DEVICE
MOV #37774,@OFF ;LOAD THE OFFSET REG.
MOV #TSTDMA!TSTCON,@SFR ;SET TEST DMA AND CONTROL
MOV #2032,@CSR ;SELECT GAIN MATRIX BYTE MODE
BIS #BIT0,@CSR ;ENABLE NCV11
BIS #TESTZ,@SFR ;ENABLE 'TEST Z' PULSES
BIC #TESTZ,@SFR ;DISABLE 'TEST Z' PULSES
CLR @#BUF0+5522 ;CLEAR THE TARGET LOCATION
BIS #BIT12,@SFR ;ALLOW 1 WORD TRANSFER
MOV #BUF0+5522,$BDADR ;LOAD EXPECTED ADDRESS
MOV #1,$GDDAT ;LOAD EXPECTED DATA
MOV @#BDADR,$BDDAT ;READ THE ACTUAL DATA
CMP $GDDAT,$BDDAT ;COMPARE
BEQ TST142 ;;BR IF SAME
ERROR 33 ;MATRIX ADDER FAILED TO SELECT CORRECT ADDRESS
;THE WRONG ADDRESS - EXPECTED ADR. WAS BUF0+5522

```



```

3078
3079
3080
3081 024022 000004
3082 024024 012737 000100 001160
3083
3084
3085
3086 024032 012777 004000 155716
3087 024040 023727 036402 001340
3088 024044 103445
3089 024050 012777 050000 155672
3090 024056 012777 000014 155672
3091 024064 012777 002034 155654
3092 024072 052777 000001 155646
3093 024100 052777 000002 155650
3094 024106 042777 000002 155642
3095 024114 005037 123656
3096 024120 052777 010000 155630
3097 024126 012737 123656 001122
3098 024134 012737 000001 001124
3099 024142 017737 154754 001126
3100 024150 023737 001124 001126
3101 024156 001401
3102 024160 104033
3103

:*****
:*TEST 142 VERIFY BIT 14 ADDER INPUT TO MATRIX MODE MUX
:*****
TST142: SCOPE
MOV #100,$TIMES ;;DO 100 ITERATIONS
:OFFSET = 50000
:ADM OUTPUT = 53656
:TARGET = 123656
MOV #CLRALL,@SFR ;CLEAR THE DEVICE
CMP $LSTBK,#1340 ;TEST IF ENOUGH MEMORY >20K
BLO TST143 ;;BR IF NO ROOM
MOV #50000,@OFF ;LOAD THE OFFSET REG.
MOV #TSTDMA!TSTCON,@SFR ;SET TEST DMA AND CONTROL
MOV #2034,@CSR ;SELECT GAIN MATRIX BYTE MODE
BIS #BIT0,@CSR ;ENABLE NCV11
BIS #TESTZ,@SFR ;ENABLE 'TEST Z' PULSES
BIC #TESTZ,@SFR ;DISABLE 'TEST Z' PULSES
CLR @#BUF0+43656 ;CLEAR THE TARGET LOCATION
BIS #BIT12,@SFR ;ALLOW 1 WORD TRANSFER
MOV #BUF0+43656,$BDADR ;LOAD EXPECTED ADDRESS
MOV #1,$GDDAT ;LOAD EXPECTED DATA
MOV @#BDADR,$BDDAT ;READ THE ACTUAL DATA
CMP $GDDAT,$BDDAT ;COMPARE
BEQ TST143 ;;BR IF SAME
ERROR 33 ;MATRIX ADDER FAILED TO SELECT CORRECT ADDRESS
;THE WRONG ADDRESS - EXPECTED ADR. WAS BUF0+43656

```

```

3104
3105
3106
3107 024162 000004
3108 024164 012737 000010 001160
3109 024172 012777 004000 155556
3110 024200 005077 155546
3111 024204 005077 155544
3112 024210 012777 060000 155532
3113 024216 012777 002022 155522
3114 024224 012777 000014 155524
3115 024232 052777 000001 155506
3116 024240 052777 000002 155510
3117 024246 042777 000002 155502
3118 024254 000240
3119 024256 000240
3120 024260 000240
3121 024262 112737 000100 061264
3122 024270 112737 000377 061265
3123 024276 052777 010000 155452
3124 024304 000240
3125 024306 000240
3126 024310 000240
3127 024312 012737 022022 001124
3128 024320 017737 155422 001126
3129 024326 023737 001124 001126
3130 024334 001401
3131 024336 104030
3132
3133 024340 013737 061264 001126 1$:
3134 024346 012737 177500 001124
3135 024354 023737 001124 001126
3136 024362 001401
3137 024364 104030

```

```

:*****
:*TEST 143 CHECK FOR HIGH BYTE 'INC OVFL' TO SET CELL OVERFLOW
:*****
TST143: SCOPE
MOV #10,$TIMES ;;DO 10 ITERATIONS
MOV #CLRALL,@SFR ;CLEAR THE DEVICE
CLR @WCR ;CLEAR W.C.
CLR @BAR ;CLEAR B.A.
MOV #BUFO,@OFF ;LOAD INITIAL OFFSET REGISTER
MOV #BIT10!BIT4!BIT1,@CSR ;ENABLE MATRIX MODE BYTE AND SET GAIN
MOV #TSTDMA!TSTCON,@SFR ;SET TEST DMA AND CONTROL
BIS #BIT0,@CSR ;ENABLE THE DEVICE
BIS #TESTZ,@SFR ;ENABLE 'TEST Z' PULSES
BIC #TESTZ,@SFR ;DISABLE 'TEST Z' PULSES
NOP
NOP
NOP
MOVB #100,BUFO+1264 ;LOAD LOW BYTE TO A KNOWN VALUE
MOVB #377,BUFO+1265 ;SET HIGH BYTE TO 377
BIS #BIT12,@SFR ;ALLOW 1 TRANSFER
NOP
NOP
NOP
MOV #BIT13!BIT10!BIT4!BIT1,$GDDAT ;LOAD EXPECTED STATUS
MOV @CSR,$BDDAT ;READ THE ACTUAL STATUS
CMP $GDDAT,$BDDAT ;COMPARE
BEQ 1$ ;;BR IF SAME
ERROR 30 ;CELL OVERFLOW FAILED TO SET
;WHEN INCREMENT THE HIGH BYTE
MOV BUFO+1264,$BDDAT ;READ 1 BUFO LOCATION
MOV #177500,$GDDAT ;LOAD EXPECTED VALUE
CMP $GDDAT,$BDDAT ;COMPARE VALUES
BEQ TST144 ;;BR IF SAME
ERROR 30 ;TARGET LOC. DATA WAS INCORRECT

```

```

3138
3139
3140
3141 024366 000004
3142 024370 012737 000400 001160
3143 024376 005737 050110
3144 024402 001454
3145 024404 012737 000001 001124
3146 024412 012737 024420 001110
3147
3148 024420 012777 004000 155330 1$: MOV #CLRALL,@SFR ;CLEAR THE DEVICE
3149 024426 012777 000010 155322 MOV #TSTDMA,@SFR ;SET TEST DMA FLOP
3150 024434 012777 000000 155310 MOV #0,@WCR ;LOAD UPPER 16 BITS
3151 024442 013777 001124 155304 MOV $GDDAT,@BAR ;
3152 024450 005377 155300 DEC @BAR ;LOAD INITIAL COUNTER VALUE
3153 024454 012777 000022 155264 MOV #BIT4!BIT1,@CSR ;ENTER MATRIX MODE
3154 024462 052777 000001 155256 BIS #BIT0,@CSR ;ENABLE THE DEVICE
3155 024470 052777 000001 155230 BIS #BIT0,@DACSR ;GENERATE 'Z' PULSE
3156 024476 105777 155224 2$: TSTB @DACSR ;WAIT FOR Z PULSE COMPLETION
3157 024502 100375 BPL 2$
3158 024504 017737 155244 001126 MOV @BAR,$BDDAT ;READ EXPECTED REGISTER VALUE
3159 024512 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE
3160 024520 001402 BEQ 3$ ;:BR IF SAME
3161 024522 104010 FRROR 10 ;LOWER 16 BITS OF THE Z COUNTER IN ERROR
3162 024524 000403 BR TST145 ;:
3163 024526 006337 001124 3$: ASL $GDDAT ;CHANGE THE DATA BIT
3164 024532 001332 BNE 1$ ;BR AND TRY NEXT BIT
3165
3166
3167
3168 024534 000004
3169 024536 012737 000400 001160
3170 024544 005737 050110
3171 024550 001454
3172 024552 012737 000001 001124
3173 024560 012737 024566 001110
3174
3175 024566 012777 004000 155162 1$: MOV #CLRALL,@SFR ;CLEAR THE DEVICE
3176 024574 012777 000010 155154 MOV #TSTDMA,@SFR ;SET TEST DMA FLOP
3177 024602 013777 001124 155142 MOV $GDDAT,@WCR ;
3178 024610 005377 155136 DEC @WCR ;LOAD INITIAL COUNTER VALUE
3179 024614 012777 177777 155132 MOV #-1,@BAR ;LOAD LOWER 16 BITS
3180 024622 012777 000022 155116 MOV #BIT4!BIT1,@CSR ;ENTER MATRIX MODE
3181 024630 052777 000001 155110 BIS #BIT0,@CSR ;ENABLE THE DEVICE
3182 024636 052777 000001 155062 BIS #BIT0,@DACSR ;GENERATE 'Z' PULSE
3183 024644 105777 155056 2$: TSTB @DACSR ;WAIT FOR Z PULSE COMPLETION
3184 024650 100375 BPL 2$
3185 024652 017737 155074 001126 MOV @WCR,$BDDAT ;READ EXPECTED REGISTER VALUE
3186 024660 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE
3187 024666 001402 BEQ 3$ ;:BR IF SAME
3188 024670 104011 ERROR 11 ;HIGHER 16 BITS OF THE Z COUNTER IN ERROR
3189 024672 000403 BR TST146 ;:
3190 024674 006337 001124 3$: ASL $GDDAT ;CHANGE THE DATA BIT
3191 024700 001332 BNE 1$ ;BR AND TRY NEXT BIT
    
```

```

3192
3193
3194
3195 024702 000004
3196 024704 012737 000400 001160
3197 024712 005737 050110
3198 024716 001443
3199 024720 012737 000001 001124
3200
3201 024726 012777 004000 155022 1$: MOV #CLRALL,@SFR ;CLEAR THE DEVICE
3202 024734 012777 000010 155014 MOV #TSTDMA,@SFR ;SET TEST DMA FLOP
3203 024742 012777 000000 155002 MOV #0,@WCR ;LOAD UPPER 16 BITS
3204 024750 012777 000000 154776 MOV #0,@BAR ;LOAD LOWER 16 BITS
3205 024756 012777 000422 154762 MOV #BIT8!BIT4!BIT1,@CSR ;ENTER MATRIX MODE ON CAMERA 01
3206 024764 052777 000001 154754 BIS #BIT0,@CSR ;ENABLE THE DEVICE
3207 024772 052777 000001 154726 BIS #BIT0,@DACSR ;GENERATE 'Z' PULSE
3208 025000 105777 154722 2$: TSTB @DACSR ;WAIT FOR Z PULSE COMPLETION
3209 025004 100375 BPL 2$
3210 025006 017737 154742 001126 MOV @BAR,$BDDAT ;READ EXPECTED REGISTER VALUE
3211 025014 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE
3212 025022 001401 BEQ TST147 ;;BR IF SAME
3213 025024 104010 ERROR 10 ;LOWER 16 BITS OF THE Z COUNTER
;IN ERROR WHEN USING CAMERA 01

```

```

3214
3215
3216
3217
3218
3219 025026 000004
3220 025030 012737 000100 001160
3221 025036 005737 050110
3222 025042 001443
3223 025044 012737 000001 001124
3224
3225 025052 012777 004000 154676 1$: MOV #CLRALL,@SFR ;CLEAR THE DEVICE
3226 025060 012777 000010 154670 MOV #TSTDMA,@SFR ;SET TEST DMA FLOP
3227 025066 012777 000000 154656 MOV #0,@WCR ;LOAD UPPER 16 BITS
3228 025074 012777 000000 154652 MOV #0,@BAR ;LOAD LOWER 16 BITS
3229 025102 012777 001022 154636 MOV #BIT9!BIT4!BIT1,@CSR ;ENTER MATRIX MODE
3230 025110 052777 000001 154630 BIS #BIT0,@CSR ;ENABLE THE DEVICE
3231 025116 052777 000001 154602 BIS #BIT0,@DACSR ;GENERATE 'Z' PULSE
3232 025124 105777 154576 2$: TSTB @DACSR ;WAIT FOR Z PULSE COMPLETION
3233 025130 100375 BPL 2$
3234 025132 017737 154616 001126 MOV @BAR,$BDDAT ;READ EXPECTED REGISTER VALUE
3235 025140 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE
3236 025146 001401 BEQ TST150 ;;BR IF SAME
3237 025150 104010 ERROR 10 ;LOWER 16 BITS OF THE Z COUNTER
;IN ERROR WHEN USING CAMERA 10

```

```

3239
3240
3241
3242 025152 000004
3243 025154 012737 000100 001160
3244 025162 005737 050110
3245 025166 001443
3246 025170 012737 000001 001124
3247
3248 025176 012777 004000 154552 1$:
3249 025204 012777 000010 154544
3250 025212 012777 000000 154532
3251 025220 012777 000000 154526
3252 025226 012777 001422 154512
3253 025234 052777 000001 154504
3254 025242 052777 000001 154456
3255 025250 105777 154452 2$:
3256 025254 100375
3257 025256 017737 154472 001126
3258 025264 023737 001124 001126
3259 025272 001401
3260 025274 104010
3261

```

```

:*****
:*TEST 150 VERIFY THAT CAMERA 11 CHANNEL IS OPERATIONAL (TESTER ONLY)
:*****
TST150: SCOPE
MOV #100,$TIMES ;;DO 100 ITERATIONS
TST WFMODE ;TEST IF TESTER MODE
BEQ TST151 ;;BR IF NOT
MOV #1,$GDDAT ;LOAD EXPECTED VALUE

1$: MOV #CLRALL,@SFR ;CLEAR THE DEVICE
MOV #TSTDMA,@SFR ;SET TEST DMA FLOP
MOV #0,@WCR ;LOAD UPPER 16 BITS
MOV #0,@BAR ;LOAD LOWER 16 BITS
MOV #BIT9!BIT8!BIT4!BIT1,@CSR ;ENTER MATRIX MODE
BIS #BIT0,@CSR ;ENABLE THE DEVICE
BIS #BIT0,@DACSR ;GENERATE 'Z' PULSE
TSTB @DACSR ;WAIT FOR Z PULSE COMPLETION
BPL 2$

2$: MOV @BAR,$BDDAT ;READ EXPECTED REGISTER VALUE
CMP $GDDAT,$BDDAT ;COMPARE
BEQ TST151 ;;BR IF SAME
ERROR 10 ;LOWER 16 BITS OF THE Z COUNTER
;IN ERROR WHEN USING CAMERA 11

```

```

3262
3263
3264
3265 025276 000004
3266 025300 012737 000002 001160
3267
3268
3269
3270
3271
3272
3273 025306 012737 060000 050114
3274 025314 012737 020000 025662
3275 025322 012737 025330 001110
3276
3277 025330 012700 060000
3278 025334 012701 125252
3279 025340 013702 103352
3280 025344 010120
3281 025346 020002
3282 025350 001375
3283 025352 012777 177770 022534
3284
3285 025360 012777 004000 154370
3286 025366 013777 050114 154354
3287 025374 012777 177777 154350
3288 025402 005077 154346
3289 025406 012777 000004 154342
3290 025414 012777 000024 154324
3291 025422 052777 000002 154326
3292 025430 052777 000001 154310
3293
3294 025436 012700 000004
3295 025442 005001
3296 025444 032777 060000 154274 4$:
3297 025452 001014
3298 025454 005301
3299 025456 001372
3300 025460 005300
3301 025462 001370
3302 025464 017737 154256 001126
3303 025472 012737 060224 001124
3304 025500 104002
3305 025502 000470
3306 025504 012700 060000 5$:
3307 025510 023700 050114 6$:
3308 025514 001415
3309 025516 010037 001122
3310 025522 011037 001126
3311 025526 012737 125252 001124
3312 025534 023737 001124 001126
3313 025542 001417
3314 025544 104033
3315 025546 000446

:*****
:*TEST 151 DYNAMIC MATRIX MODE ADDRESS
:*****
TST151: SCOPE
MOV #2,$TIMES ;;DO 2 ITERATIONS
:CELL INCREMENT OF A FLOATING LOCATION (60000,70000,64000,62000,61000)
:FILL THE MEMORY BUFFER WITH A KNOWN PATTERN (125252)
:COLLECT DATA OF 0 AND INCREMENT A TARGET LOCATION
:VERIFY THAT NO OTHER ADDRESS IS CHANGED
:AFTER VERIFYING THE WHOLE BUFFER - UPDATE THE OFFSET REGISTER
: AND INCREMENT ANOTHER LOCATION
MOV #BUFO,CURRENT ;PRIME THE CURRENT TARGET LOC.
MOV #BIT13,100$ ;LOAD FORCE BIT
MOV #2$,$LPERR ;LOAD RETURN ADDRESS
:PRIME THE BUFFER WITH A 125252 PATTERN
2$: MOV #BUFO,R0 ;LOAD POINTER TO BUFFER
MOV #125252,R1 ;LOAD VALUE
MOV ADNOKT,R2 ;LOAD BUFFER END ADDRESS
3$: MOV R1,(R0)+ ;LOAD BUFFER WITH DATA
CMP R0,R2 ;TEST FOR END
BNE 3$
MOV #-10,@CURRENT ;PRIME THE TARGET LOCATION
MOV #CLRALL,@SFR ;INIT THE DEVICE
MOV CURRENT,@OFF ;LOAD OFFSET TO TARGET
MOV #-1,@WCR ;PRIME THE HIGH 16 BIT Z COUNTER
CLR @BAR ;CLEAR LOW 16 BIT COUNTER
MOV #TSTCON,@SFR ;ENABLE TEST CONNECTOR
MOV #24,@CSR ;LOAD MATRIX WORD MODE
BIS #TESTZ,@SFR ;SET TEST Z FLOP
BIS #BIT0,@CSR ;ENABLE THE NCV11
MOV #4,R0 ;PRIME THE DELAY
CLR R1
3296 BIT #BIT14!BIT11,@CSR ;TEST FOR CELL OR Z OVERFLOW
3297 BNE 5$ ;;BR IF EITHER IS SET
3298 DEC R1 ;DELAY
3299 BNE 4$
3300 DEC R0 ;DELAY
3301 BNE 4$
3302 MOV @CSR,$BDDAT ;READ BAD STATUS
3303 MOV #BIT14!BIT13+224,$GDDAT ;LOAD EXPECTED STATUS
3304 ERROR 2 ;DYNAMIC MATRIX MODE STATUS ERROR
3305 BR TST152
3306 MOV #BUFO,R0 ;GET BUFFER POINER
3307 CMP CURRENT,R0 ;TEST IF TARGET ADDRESS
3308 BEQ 7$ ;;BR IF YES
3309 MOV R0,$BDADR ;GET BAD ADDRESS FOR TYPE-OUT
3310 MOV (R0),$BDDAT ;GET BAD DATA
3311 MOV #125252,$GDDAT ;LOAD EXPECTED DATA
3312 CMP $GDDAT,$BDDAT ;COMPARE
3313 BEQ 10$ ;;BR IF SAME
3314 ERROR 33 ;CHANGED AN INCORRECT TARGET LOCATION
3315 BR TST152
  
```

```

I 7
CZNRCA NCV11 DIAGNOSTIC MACY11 27(654) 8-AUG-78 15:05 PAGE 74
CZNRCA.P11 T151 DYNAMIC MATRIX MODE ADDRESS SEQ 0086

3316 025550 013737 050114 001122 7$: MOV CURENT,$BDADR ;LOAD EXPECTED ADDRESS
3317 025556 017737 022332 001126 MOV @CUREN,$BDDAT ;LOAD ACTUAL DATA
3318 025564 012737 003407 001124 MOV #3407,$GDDAT ;LOAD EXPECTED DATA
3319 025572 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE
3320 025600 001400 BEQ 10$ ;:BR IF SAME
3321
3322 025602 005720 10$: TST (R0)+ ;BUMP THE POINTER INTO THE BUFFER
3323 025604 023700 003352 CMP ADNOKT,R0 ;TEST IF FINISHED THE BUFFER
3324 025610 001337 BNE 6$ ;BR AND RETEST THE REST OF THE BUFFER
3325
3326 025612 005737 001202 TST $PASS ;TEST IF FIRST PASS
3327 025616 001422 BEQ TST152 ;:BR IF YES
3328 025620 032777 004000 153312 BIT #SW11,@SWR ;TEST INHIBIT INTER.
3329 025626 001016 BNE TST152 ;:BR IF SET
3330 025630 006237 025662 ASR 100$ ;CHANGE THE FORCED ADDR. BIT
3331 025634 022737 000002 025662 CMP #2,100$ ;TEST IF FINISHED
3332 025642 001410 BEQ TST152 ;:BR IF FINISHED
3333 025644 012737 060000 050114 MOV #BUFO,CURENT ;MAKE UP NEW ADDRESS
3334 025652 053737 025662 050114 BIS 100$,CURENT ;
3335 025660 000623 BR 2$
3336 025662 020000 100$: BIT13
3337
3338 ;:*****
3339 ;*TEST 152 DYNAMIC LIST MODE ADDRESS
3340 ;:*****
3340 025664 000004 TST152: SCOPE
3341 025666 012737 000002 001160 MOV #2,$TIMES ;:DO 2 ITERATIONS
3342 ;FILL THE MEMORY BUFFER WITH A KNOWN PATTERN (125252)
3343 ;DO A 1 WORD TRANSFER TO A TAGEY LOCATION
3344 ;VERIFY THAT NO OTHER LOCATION IN THE BUFFER IS CHANGED
3345 ;AFTER VERIFYING BUMP THE BUS ADDRESS AND DO SUB-TEST AGAIN
3346 025674 012737 060000 050114 MOV #BUFO,CURENT ;PRIME THE CURRENT TARGET LOC.
3347 025702 012737 020000 026242 MOV #BIT13,100$ ;LOAD FORCE BIT
3348 025710 012737 025716 001110 MOV #2,$LPERR ;LOAD RETURN ADDRESS
3349 ;PRIME THE BUFFER WITH A 125252 PATTERN
3350 025716 012700 060000 2$: MOV #BUFO,R0 ;LOAD POINTER TO BUFFER
3351 025722 012701 125252 MOV #125252,R1 ;LOAD VALUE
3352 025726 013702 003352 MOV ADNOKT,R2 ;LOAD BUFFER END ADDRESS
3353 025732 010120 3$: MOV R1,(R0)+ ;LOAD BUFFER WITH DATA
3354 025734 020002 CMP R0,R2 ;TEST FOR END
3355 025736 001375 BNE 3$
3356
3357 025740 012777 004000 154010 MOV #CLRALL,@SFR ;INIT THE DEVICE
3358 025746 012777 177777 153776 MOV #-1,@WCR ;PRIME THE WORD COUNT
3359 025754 013777 050114 153772 MOV CURENT,@JAR ;LOAD TARGET LOCATION POINTER
3360 025762 012777 000004 153766 MOV #TSTCON,@SFR ;ENABLE MAINT. MODE
3361 025770 052777 000001 153750 BIS #BIT0,@CSR ;ENABLE THE NCV11
3362 025776 052777 000002 153752 BIS #TESTZ,@SFR ;ENABLE 'TEST Z' PULSES
3363 026004 042777 000002 153744 BIC #TESTZ,@SFR ;DISABLE 'TEST Z' PULSES
3364
3365 026012 012700 000004 MOV #4,R0 ;PRIME THE DELAY
3366 026016 005001 CLR R1
3367 026020 032777 060000 153720 4$: BIT #BIT14!BIT13,@CSR ;TEST FOR CELL OR Z OVERFLOW
3368 026026 001014 BNE 5$ ;:BR IF EITHER IS SET
3369 026030 005301 DEC R1 ;DELAY

```

```

3370 026032 001372      BNE      4$
3371 026034 005300      DEC      RO          ;DELAY
3372 026036 001370      BNE      4$
3373 026040 017737 153702 001126      MOV      @CSR,$BDDAT ;READ BAD STATUS
3374 026046 012737 060224 001124      MOV      BIT14,BIT13+224,$GDDAT ;LOAD EXPECTED STATUS
3375 026054 104036      ERROR    36          ;DYNAMIC LIST MODE STATUS ERROR
3376 026056 000472      BR       TST153      ;
3377 026060 012700 060000 5$:      MOV      #BUFO,RO    ;GET BUFFER POINER
3378 026064 023700 050114 6$:      CMP      CURENT,RO   ;TEST IF TARGET ADDRESS
3379 026070 001415      BEQ      7$          ;:BR IF YES
3380 026072 010037 001122      MOV      RO,$BDADR   ;GET BAD ADDRESS FOR TYPE-OUT
3381 026076 011037 001126      MOV      (RO),$BDDAT ;GET BAD DATA
3382 026102 012737 125252 001124      MOV      #125252,$GDDAT ;LOAD EXPECTED DATA
3383 026110 023737 001124 001126      CMP      $GDDAT,$BDDAT ;COMPARE
3384 026116 001421      BEQ      10$         ;:BR IF SAME
3385 026120 104021      ERROR    21          ;CHANGED AN INCORRECT TARGET LOCATION
3386 026122 000450      BR       TST153      ;
3387 026124 013737 050114 001122 7$:      MOV      CURENT,$BDADR ;LOAD EXPECTED ADDRESS
3388 026132 017737 021756 001126      MOV      @CURENT,$BDDAT ;GET ACTUAL DATA
3389 026140 012737 003407 001124      MOV      #3407,$GDDAT  ;LOAD EXPECTED DATA
3390 026146 023737 001124 001126      CMP      $GDDAT,$BDDAT ;COMPARE
3391 026154 001402      BEQ      10$         ;:BR IF SAME
3392 026156 104037      ERROR    37          ;LIST MODE DATA ERROR
3393 026160 000431      BR       TST153      ;
3394 026162 005720 10$:      TST      (RO)+       ;BUMP THE POINTER INTO THE BUFFER
3395 026164 023700 003352      CMP      ADNOKT,RO   ;TEST IF FINISHED THE BUFFER
3396 026170 001335      BNE      6$          ;BR AND RETEST THE REST OF THE BUFFER
3397
3398 026172 005737 001202      TST      $PASS       ;TEST IF FIRST PASS
3399 026176 001422      BEQ      TST153      ;:BR IF FIRST PASS
3400 026200 032777 004000 152732      BIT      #SW11,@SWR  ;TEST INHIBIT INTER.
3401 026206 001016      BNE      TST153      ;:BR IF SET
3402 026210 006237 026242      ASR      100$        ;CHANGE THE FORCE ADDRESS
3403 026214 022737 000002 026242      CMP      #2,100$     ;TEST IF END
3404 026222 001410      BEQ      TST153      ;:BR IF FINISHED
3405 026224 012737 060000 050114      MOV      #BUFO,CURENT ;MAKE NEW ADDRESS
3406 026232 053737 026242 050114      BIS      100$,CURENT ;
3407 026240 000626      BR       2$          ;
3408 026242 020000 100$:      BIT13
  
```



```

3409
3410
3411
3412 026244 000004
3413 026246 012737 000040 001160
3414 026254 013700 003352
3415 026260 162700 060000
3416 026264 005400
3417 026266 006200
3418
3419 026270 012703 060000
3420 026274 012701 125252
3421 026300 013702 003352
3422 026304 010123
3423 026306 020302
3424 026310 001375
3425
3426 026312 012777 004000 153436
3427 026320 010077 153426
3428 026324 012777 060000 153422
3429 026332 012777 000004 153416
3430 026340 052777 000001 153400
3431 026346 052777 000002 153402
3432 026354 012700 000004
3433 026360 032777 060000 153360
3434 026366 001014
3435 026370 005301
3436 026372 001372
3437 026374 005300
3438 026376 001370
3439 026400 017737 153342 001126
3440 026406 012737 060200 001124
3441 026414 104036
3442 026416 000423
3443 026420 012700 060000
3444 026424 010037 001122
3445 026430 011037 001126
3446 026434 012737 003407 001124
3447 026442 023737 001124 001126
3448 026450 001402
3449 026452 104037
3450 026454 000404
3451 026456 005720
3452 026460 023700 003352
3453 026464 001357

```

```

*****
*TEST 153 DYNAMIC LIST MODE TRANSFER - MAXIMUM BUFFER LENGTH IN LOWER 28K
*****
TST153: SCOPE
MOV #40,$TIMES ;DO 40 ITERATIONS
MOV ADNOKT,R0 ;GET LAST ADDRESS
SUB #BUFO,R0 ;DETERMINE THE WORD COUNT VALUE
NEG R0
ASR R0
;PRIME THE BUFFER WITH A 125252 PATTERN
2$: MOV #BUFO,R3 ;LOAD POINTER TO BUFFER
MOV #125252,R1 ;LOAD VALUE
MOV ADNOKT,R2 ;LOAD BUFFER END ADDRESS
3$: MOV R1,(R3)+ ;LOAD BUFFER WITH DATA
CMP R3,R2 ;TEST FOR END
BNE 3$
;NOW COLLECT THE LIST MODE DATA
MOV #CLRALL,@SFR ;INIT THE DEVICE
MOV R0,@WCR ;PRIME THE WORD COUNT
MOV #BUFO,@BAR ;LOAD TARGET LOCATION POINTER
MOV #TSTCON,@SFR ;ENABLE MAINT. MODE
BIS #BIT0,@CSR ;ENABLE THE NCV11
BIS #TESTZ,@SFR ;ENABLE MAINT. Z
MOV #4,R0 ;PRIME THE DELAY
4$: BIT #BIT14.BIT13,@CSR ;TEST FOR CELL OR Z OVERFLOW
BNE 5$ ;BR IF EITHER IS SET
DEC R1 ;DELAY
BNE 4$
DEC R0 ;DELAY
BNE 4$
MOV @CSR,$BDDAT ;READ BAD STATUS
MOV #BIT14!BIT13+200,$GDDAT ;LOAD EXPECTED STATUS
ERROR 36 ;DYNAMIC LIST MODE STATUS ERROR - NO WORD COUNT OVERFLOW
BR TST154
5$: MOV #BUFO,R0 ;GET BUFFER POINER
6$: MOV R0,$BDADR ;GET BAD ADDRESS FOR TYPE-OUT
MOV (R0),$BDDAT ;GET BAD DATA
MOV #3407,$GDDAT ;LOAD EXPECTED DATA
CMP $GDDAT,$BDDAT ;COMPARE
BEQ 10$ ;BR IF SAME
ERROR 37 ;LIST MODE DATA ERROR
BR TST154
10$: TST (R0)+ ;BUMP THE POINTER INTO THE BUFFER
CMP ADNOKT,R0 ;TEST IF FINISHED THE BUFFER
BNE 6$ ;BR AND RETEST THE REST OF THE BUFFER

```

```

3454
3455
3456
3457 026466 000004
3458 026470 012737 000002 001160
3459 026476 005737 036120
3460 026502 100127
3461
3462
3463 026504 012737 000600 041772
3464 026512 013737 041772 172346
3465 026520 012700 060000
3466 026524 012710 125252
3467 026530 052737 001400 177572
3468 026536 012710 000370
3469 026542 042737 001400 177572
3470 026550 013701 041772
3471 026554 005002
3472 026556 006301
3473 026560 006301
3474 026562 006301
3475 026564 006301
3476 026566 006301
3477 026570 006102
3478 026572 006301
3479 026574 006102
3480 026576 010237 041756
3481 026602 010137 001122
3482 026606 060201
3483
3484
3485 026610 012777 004000 153140
3486 026616 010177 153126
3487 026622 012777 000022 153116
3488 026630 012777 000014 153120
3489 026636 052777 000001 153102
3490 026644 052777 000002 153104
3491 026652 042777 000002 153076
3492 026660 012737 000371 001124
3493 026666 052777 010000 153062
3494 026674 052737 000001 177572
3495 026702 011037 001126
3496 026706 042737 000001 177572
3497 026714 023737 001124 001126
3498 026722 001401
3499 026724 104035
3500 026726 005737 001202
3501 026732 001413
3502 026734 032777 004000 152176
3503 026742 001007
3504 026744 062737 000200 041772
3505 026752 023737 036402 041772
3506 026760 101254

```

```

*****
*TEST 154 ONE MATRIX DATA TRANSFER TO EACH 4K EXTENDED MEMORY
*****
TST154: SCOPE
MOV #2,$TIMES ;DO 2 ITERATIONS
TST $KT11 ;TEST IF KT-11 INSTALLED
BPL TST155 ;BR IF NONE
;DO A BYTE MATRIX MODE TRANSFER TO A 1 BYTE LOCATION IN EACH 4K EXTENDED
;MEMORY BANK
MOV #600,OUT ;LOAD INITIAL BANK VALUE
1$: MOV OUT,@#KIPAR3 ;LOAD KT-PAR REG #3 <BUFFER IS AT LOC 60000>
MOV #BUF0,R0 ;LOAD BUFFER POINTER
MOV #125252,(R0) ;PRIME BAD TARGET LOC. IF EXT ADD FAILS
BIS #1400,@#SRO ;ENABLE MAINT. MODE KT-11
MOV #370,(R0) ;LOAD TARGET LOCATION DATA VALUE
BIC #1400,@#SRO ;DISABLE MAINT. MODE KT-11
MOV OUT,R1 ;GET BANK VALUE
CLR R2 ;CLEAR EXT. ADD. TEMPORARY
ASL R1 ;MOVE LEFT
ASL R1 ;MOVE LEFT
ASL R1 ;MOVE LEFT
ASL R1 ;MOVE LEFT
ASL R1 ;MOVE LEFT
ROL R2 ;SAVE EA BITS
ASL R1
ROL R2 ;SAVE EA BITS
MOV R2,NARROW ;SAVE EA BITS FOR TYPEOUT
MOV R1,$BDADR ;SAVE ADDRESS BITS FOR TYPEOUT
ADD R2,R1 ;MAKE COMPLETE ADDRESS

;NOW GET READY TO DO THE TRANSFER
MOV #CLRALL,@SFR ;INIT THE NCV11
MOV R1,@OFF ;LOAD COMBINED BUFFER ADDRESS
MOV #BIT4!BIT1,@CSR ;ENABLE THE NCV11
MOV #TSTDMA!TSTCON,@SFR ;ENABLE MAINT NCV11 MODE
BIS #BIT0,@CSR ;ENABLE THE NCV11
BIS #TESTZ,@SFR ;ENABLE 'TEST Z' PULSES
BIC #TESTZ,@SFR ;DISABLE 'TEST Z' PULSES
MOV #371,$GDDAT ;LOAD EXPECTED DATA
BIS #BIT12,@SFR ;ENABLE 1 BYTE TRANSFER
BIS #BIT0,@#SRO ;ENABLE KT-11
MOV (R0),$BDDAT ;GET ACTUAL DATA
BIC #BIT0,@#SRO ;DISABLE KT-11
CMP $GDDAT,$BDDAT ;COMPARE DATA
BEQ 2$ ;BR IF SAME
ERROR 35 ;DATA TRANSFER ERROR TO EXTENDED MEMORY
2$: TST $PASS ;TEST PASS COUNTER
BEQ TST155 ;BR IF FIRST PASS
BIT #SW11,@SWR ;TEST IF INHIBIT INTER.
BNE TST155 ;BR IF SET
ADD #200,OUT ;UPDATE BANK VALUE
CMP $LSTBK,OUT ;TEST IF DONE
BHI 1$ ;BR IF NOT

```

M 7

```

3507
3508
3509
3510 026762 000004
3511 026764 012737 000002 001160
3512 026772 005737 036120
3513 026776 100130
3514
3515 027000 012737 000600 041772
3516 027006 013737 041772 172346
3517 027014 012700 060000
3518 027020 012710 052525
3519 027024 052737 001400 177572
3520 027032 012710 125252
3521 027036 042737 001400 177572
3522 027044 013701 041772
3523 027050 005002
3524 027052 006301
3525 027054 006301
3526 027056 006301
3527 027060 006301
3528 027062 006301
3529 027064 006102
3530 027066 006301
3531 027070 006102
3532
3533
3534 027072 012777 004000 152656
3535 027100 010277 152644
3536 027104 012777 177777 152640
3537 027112 010177 152636
3538 027116 012777 000014 152632
3539 027124 052777 000001 152614
3540 027132 052777 000002 152616
3541 027140 042777 000002 152610
3542 027146 010137 001122
3543 027152 010237 041756
3544 027156 052777 010000 152572
3545 027164 012737 003407 001124
3546 027172 052737 000001 177572
3547 027200 011037 001126
3548 027204 042737 000001 177572
3549 027212 023737 001124 001126
3550 027220 001401
3551 027222 104035
3552 027224 005737 001202
3553 027230 001413
3554 027232 032777 004000 151700
3555 027240 001007
3556 027242 062737 000200 041772
3557 027250 023737 036402 041772
3558 027256 101253

*****
*TEST 155 ONE LIST DATA TRANSFER TO EACH 4K EXTENDED MEMORY
*****
TST155: SCOPE
MOV #2,$TIMES ;DO 2 ITERATIONS
TST $KT11 ;TEST IF KT-11 INSTALLED
BPL TST156 ;BR IF NONE
;DO A 1 WORD MODE TRANSFER TO A 1 WORD BUFFER IN EACH 4K EXTENDED MEMORY BANK
MOV #600,OUT ;LOAD INITIAL BANK VALUE <60000>
1$: MOV OUT,@#KIPAR3 ;LOAD KT-PAR REG #3 <BUFFER IS AT LOC 60000>
MOV #BUF0,R0 ;LOAD BUFFER POINTER
MOV #52525,(R0) ;LOAD BAD TARGET LOC. IF EXT ADD FAILS
BIS #1400,@#SRO ;ENABLE MAINT. MODE KT-11
MOV #125252,(R0) ;PRESET THE TARGET LOCATION
BIC #1400,@#SRO ;DISABLE MAINT. MODE KT-11
MOV OUT,R1 ;GET BANK VALUE
CLR R2 ;CLEAR EXT. ADD TEMPORARY
ASL R1
ASL R1
ASL R1
ASL R1
ROL R2 ;SAVE EXT. ADDRESS BITS
ASL R1
ROL R2 ;SAVE EXT. ADDRESS BITS

;NOW GET READY TO DO THE TRANSFER
MOV #CLRALL,@SFR ;INIT THE NCV11
MOV R2,@OFF ;LOAD THE EXTENDED ADDRESS BITS
MOV #-1,@WCR ;LOAD WORD COUNT
MOV R1,@BAR ;LOAD BUS ADDRESS
MOV #TST156,@SFR ;ENABLE MAINT NCV11 MODE
BIS #BI.1,@CSR ;ENABLE THE NCV11
BIS #TESTZ,@SFR ;ENABLE 'TEST Z' PULSES
BIC #TESTZ,@SFR ;DISABLE 'TEST Z' PULSES
MOV R1,$BDADR ;SAVE TARGET ADDRESS
MOV R2,NARROW ;SAVE EA BITS FOR ERROR TYPEOUT
BIS #BIT12,@SFR ;ENABLE 1 BYTE TRANSFER
MOV #3407,$GDDAT ;LOAD EXPECTED DATA
BIS #BIT0,@#SRO ;ENABLE KT-11
MOV (R0),$BDDAT ;GET ACTUAL DATA
BIC #BIT0,@#SRO ;DISABLE KT-11
CMP $GDDAT,$BDDAT ;COMPARE DATA
BEQ 2$ ;BR IF SAME
ERROR 35 ;LIST MODE DATA TRANSFER ERROR TO EXTENDED MEMORY
2$: TST $PASS ;TEST PASS COUNTER
BEQ TST156 ;BR IF FIRST PASS
BIT #SW11,@SWR ;TEST INHIBIT INTER.
BNE TST156 ;BR IF SET
ADD #200,OUT ;UPDATE BANK VALUE
CMP $LSTBK,OUT ;TEST IF DONE
BHI 1$ ;BR IF NOT
  
```

```

3559
3560
3561
3562 027260 000004
3563 027262 012737 000100 001160
3564
3565
3566
3567 027270 023727 036402 003140
3568 027276 103476
3569 027300 012737 002676 172346
3570 027306 012700 060056
3571 027312 012710 125252
3572 027316 052737 001400 177572
3573 027324 005010
3574 027326 042737 001400 177572
3575
3576
3577 027334 012777 004000 152414
3578 027342 012777 140000 152400
3579 027350 012777 002036 152370
3580 027356 012777 000014 152372
3581 027364 052777 000001 152354
3582 027372 052777 000002 152356
3583 027400 042777 000002 152350
3584 027406 000240
3585 027410 000240
3586 027412 052777 010000 152336
3587 027420 000240
3588 027422 000240
3589 027424 000240
3590 027426 012737 000001 041756
3591 027434 012737 000400 001124
3592 027442 052737 000001 177572
3593 027450 011037 001126
3594 027454 042737 000001 177572
3595 027462 023737 001124 001126
3596 027470 001401
3597 027472 104020

```

```

*****
*TEST 156 VERIFY BIT 15 MATRIX ADDER INPUT
*****
TST156: SCOPE
MOV #100,$TIMES ;;DO 100 ITERATIONS
;ADM OUTPUT = 127657
;OFFSET = 140000
;TARGET = 267657
CMP $LSTBK,#3140 ;TEST IF >52K IS AVAILABLE
BLO TST157 ;;BR IF NO MORE MEMORY
MOV #2676,@#KIPAR3 ;LOAD KT-PAR REG #3 <BUFFER IS AT LOC 60000>
MOV #BUF0+56,R0 ;LOAD BUFFER POINTER
MOV #125252,(R0) ;LOAD BAD TARGET LOC. IF EXT ADD FAILS
BIS #1400,@#SRO ;ENABLE MAINT. MODE KT-11
CLR (R0) ;LOAD TARGET LOCATION DATA VALUE
BIC #1400,@#SRO ;DISABLE MAINT. MODE KT-11

;NOW GET READY TO DO THE TRANSFER
MOV #CLRALL,@SFR ;INIT THE NCV11
MOV #140000,@OFF ;LOAD COMBINED BUFFER ADDRESS
MOV #2036,@CSR ;ENABLE THE NCV11
MOV #TSTDMA!TSTCON,@SFR ;ENABLE MAINT NCV11 MODE
BIS #BIT0,@CSR ;ENABLE THE NCV11
BIS #TESTZ,@SFR ;ENABLE 'TEST Z' PULSES
BIC #TESTZ,@SFR ;DISABLE 'TEST Z' PULSES
NOP
NOP
BIS #BIT12,@SFR ;ENABLE 1 BYTE TRANSFER
NOP
NOP
NOP
MOV #1,NARROW ;SAVE EA BITS FOR ERROR TYPEOUT
MOV #400,$GDDAT ;LOAD EXPECTED DATA
BIS #BIT0,@#SRO ;ENABLE KT-11
MOV (R0),$BDDAT ;SAVE ACTUAL DATA
BIC #BIT0,@#SRO ;DISABLE KT-11
CMP $GDDAT,$BDDAT ;COMPARE DATA
BEQ TST157 ;;BR IF SAME
ERROR 20 ;BIT 15 INPUT TO MATRIX MODE ADDER FAILED

```

```
3598 ::*****
3599 :*TEST 157 VERIFY HIGH BYTE OPERATION OF THE 'TEST X'
3600 :*****
3601 027474 000004 TST157: SCOPE
3602 027476 012737 000040 001160 MOV #40,$TIMES ;:DO 40 ITERATIONS
3603 :TEST X = 1
3604 :OFFSET =100000
3605 :ADM OUTPUT =127657
3606 :TARGET =100257
3607 027504 012777 004000 152244 MOV #CLRALL,@SFR ;CLEAR THE DEVICE
3608 027512 023727 036402 001140 CMP $LSTBK,#1140 ;TEST IF LEAST 20K
3609 027520 103445 BLO TST160 ;:BR IF NOT
3610 027522 012777 100000 152220 MOV #100000,@OFF ;SET BIT 15 OF OFFSET
3611 027530 012777 000034 152220 MOV #TSTDMA!TSTCON!BIT4,@SFR ;SET TEST DMA, CONTROL AND TESTX
3612 027536 012777 002036 152202 MOV #2036,@CSR ;ENABLE THE NCV11
3613 027544 052777 000001 152174 BIS #BIT0,@CSR ;ENABLE THE NCV11
3614 027552 052777 000002 152176 BIS #TESTZ,@SFR ;ENABLE 'TEST Z' PULSES
3615 027560 042777 000002 152170 BIC #TESTZ,@SFR ;DISABLE 'TEST Z' PULSES
3616 027566 005037 100256 CLR @#BUF0+20256 ;CLEAR THE TARGET LOC.
3617 027572 052777 010000 152156 BIS #BIT12,@SFR ;ALLOW 1 DMA TRANSFER
3618 027600 012737 100256 001122 MOV #BUF0+20256,$BDADR ;LOAD EXPECTED ADDRESSES VALUE
3619 027606 012737 000400 001124 MOV #400,$GDDAT ;LOAD EXPECTED VALUE READ
3620 027614 017737 151302 001126 MOV @$BDADR,$BDDAT ;READ ACTUAL DATA
3621 027622 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE
3622 027630 001401 BEQ TST160 ;:BR IF SAME
3623 027632 104034 ERROR 34 ;MATRIX ADDER INPUT OF ADM15 AND TESTX L
3624 ;FAILED TO BE INHIBITED
```

```

3625
3626
3627
3628 027634 000004
3629 027636 012737 000100 001160
3630
3631
3632
3633 027644 023727 036402 005140
3634 027652 103500
3635 027654 012737 004635 172346
3636 027662 012700 060026
3637 027666 012710 125252
3638 027672 052737 001400 177572
3639 027700 005010
3640 027702 042737 001400 177572
3641
3642
3643 027710 012777 004000 152040
3644 027716 012777 010001 152024
3645 027724 012777 000014 152024
3646 027732 012777 004036 152006
3647 027740 052777 000001 152000
3648 027746 052777 000002 152002
3649 027754 042777 000002 151774
3650 027762 000240
3651 027764 000240
3652 027766 052777 010000 151762
3653 027774 000240
3654 027776 000240
3655 030000 000240
3656 030002 012737 000002 041756
3657 030010 012737 000400 001124
3658 030016 052737 000001 177572
3659 030024 111037 001126
3660 030030 042737 000001 177572
3661 030036 105037 001126
3662 030042 023737 001124 001126
3663 030050 001401
3664 030052 104020

```

```

*****
*TEST 160 VERIFY BIT 16 INPUT TO THE MATRIX MODE ADDER
*****
TST160: SCOPE
MOV #100,$TIMES ;;DO 100 ITERATIONS
;ADM OUTPUT = 253527
;OFFSET = 210000
;TARGET = 463527
CMP $LSTBK,#5140 ;TEST IF ENOUGH MEMORY >84K
BLO TST161 ;;BR IF NOT
MOV #4635,@#KIPAR3 ;LOAD KT-PAR REG #3 <BUFFER IS AT LOC 60000>
MOV #BUF0+26,R0 ;LOAD BUFFER POINTER
MOV #125252,(R0) ;LOAD BAD TARGET LOC.
BIS #1400,@#SRO ;ENABLE MAINT. MODE KT-11
CLR (R0) ;PRESET THE TARGET LOCATION
BIC #1400,@#SRO ;DISABLE MAINT. MODE KT-11

;NOW GET READY TO DO THE TRANSFER
MOV #CLRALL,@SFR ;INIT THE NCV11
MOV #10001,@OFF ;LOAD THE EXTENDED ADDRESS BITS
MOV #TSTDMA!TSTCON,@SFR ;ENABLE MAINT NCV11 MODE
MOV #4036,@CSR ;LOAD MATRIX MODE AND ZB ENABLE
BIS #BIT0,@CSR ;ENABLE THE NCV11
BIS #TESTZ,@SFR ;ENABLE 'TEST Z' PULSES
BIC #TESTZ,@SFR ;DISABLE 'TEST Z' PULSES
NOP
NOP
BIS #BIT12,@SFR ;ENABLE 1 BYTE TRANSFER
NOP
NOP
MOV #2,NARROW ;SAVE EA BITS FOR ERROR TYPEOUT
MOV #400,$GDDAT ;LOAD EXPECTED DATA
BIS #BIT0,@#SRO ;ENABLE KT-11
MOVB (R0), $BDDAT ;SAVE ACTUAL DATA
BIC #BIT0,@#SRO ;DISABLE KT-11
CLRB $BDDAT ;MASK OFF LOW BYTE
CMP $GDDAT,$BDDAT ;COMPARE DATA
BEQ TST161 ;;BR IF SAME
ERROR 20 ;BIT 16 INPUT TO MATRIX MODE ADDER FAILED

```

```

3665
3666
3667
3668 030054 000004
3669 030056 012737 000001 001160
3670 030064 005737 050106
3671 030070 001402
3672 030072 000137 043712
3673
3674
3675
3676
3677
3678
3679
3680
3681
3682 030076
3683 030076 000004
3684 030100 005037 001102
3685 030104 005037 001160
3686 030110 005237 001202
3687 030114 042737 100000 001202
3688 030122 005327
3689 030124 000001
3690 030126 003022
3691 030130 012737
3692 030132 000001
3693 030134 030124
3694 030136 104401 030203
3695 030142 013746 001202
3696 030146 104405
3697 030150 104401 030200
3698 030154 013700 000042
3699 030160 001405
3700 030162 000005
3701 030164 004710
3702 030166 000240
3703 030170 000240
3704 030172 000240
3705 030174
3706 030174 000137
3707 030176 003356
3708 030200 377 377 000
3709 030203 015 042412 042116
3710 030210 050040 051501 020123
3711 030216 000043

```

```

:*****
:*TEST 161 DETERMINE IF DIFLIN IS TO BE RUN (F)
:*****
TST161: SCOPE
MOV #1,$TIMES ;;DO 1 ITERATION
TST RUNDIF ;;TEST IF DIFLIN IS TO BE RUN
BEQ $EOP ;;BR IF NOT TO BE RUN
JMP DIFLIN ;;JUMP AND RUN DIFLIN
.SBTTL END OF PASS ROUTINE

:*****
:*INCREMENT THE PASS NUMBER ($PASS)
:*INDICATE END-OF-PROGRAM AFTER 1 PASSES THRU THE PROGRAM
:*TYPE 'END PASS #XXXXX' (WHERE XXXXX IS A DECIMAL NUMBER)
:*IF THERES A MONITOR GO TO IT
:*IF THERE ISN'T JUMP TO LOGIC

$EOP:
SCOPE
CLR $TSTNM ;;ZERO THE TEST NUMBER
CLR $TIMES ;;ZERO THE NUMBER OF ITERATIONS
INC $PASS ;;INCREMENT THE PASS NUMBER
BIC #100000,$PASS ;;DON'T ALLOW A NEG. NUMBER
DEC (PC)+ ;;LOOP?
$EOPCT: .WORD 1
BGT $DOAGN ;;YES
MOV (PC)+,@(PC)+ ;;RESTORE COUNTER
$ENDCT: .WORD 1
$EOPCT
TYPE $ENDMG ;;TYPE 'END PASS #'
MOV $PASS,-(SP) ;;SAVE $PASS FOR TYPEOUT
TYPDS ;;GO TYPE--DECIMAL ASCII WITH SIGN
TYPE $ENULL ;;TYPE A NULL CHARACTER
$GET42: MOV @#42,R0 ;;GET MONITOR ADDRESS
BEQ $DOAGN ;;BRANCH IF NO MONITOR
RESET ;;CLEAR THE WORLD
$ENDAD: JSR PC,(R0) ;;GO TO MONITOR
NOP ;;SAVE ROOM
NOP ;;FOR
NOP ;;ACT11
$DOAGN: JMP @(PC)+ ;;RETURN
$RTNAD: .WORD LOGIC
$ENULL: .BYTE -1,-1,0 ;;NULL CHARACTER STRING
$ENDMG: .ASCIZ <15><12>/END PASS #/

```

```
3712 .SBTTL ERROR ASCII MESSAGES
3713
3714 030220 034115 031060 004466 EM1: .ASCIZ /M8026 NCV11 BUS ADDRESS TIMEOUT/
3715 030226 041516 030526 020061
3716 030234 052502 020123 042101
3717 030242 051104 051505 020123
3718 030250 044524 042515 052517
3719 030256 000124
3720 030260 034115 031060 004466 EM2: .ASCIZ /M8026 COMMAND-STATUS REGISTER ERROR/
3721 030266 047503 046515 047101
3722 030274 026504 052123 052101
3723 030302 051525 051040 043505
3724 030310 051511 042524 020122
3725 030316 051105 047522 000122
3726 030324 034115 031060 004466 EM3: .ASCIZ /M8026 SPECIAL FUNCTION REGISTER ERROR/
3727 030332 050123 041505 040511
3728 030340 020114 052506 041516
3729 030346 044524 047117 051040
3730 030354 043505 051511 042524
3731 030362 020122 051105 047522
3732 030370 000122
3733 030372 034115 031060 004466 EM4: .ASCIZ /M8026 WORD COUNT REGISTER ERROR/
3734 030400 047527 042122 041440
3735 030406 052517 052116 051040
3736 030414 043505 051511 042524
3737 030422 020122 051105 047522
3738 030430 000122
3739 030432 034115 031060 004466 EM5: .ASCIZ /M8026 BUS ADDRESS REGISTER ERROR/
3740 030440 052502 020123 042101
3741 030446 051104 051505 020123
3742 030454 042522 044507 052123
3743 030462 051105 042440 051122
3744 030470 051117 000
3745 030473 115 030070 033062 EM6: .ASCIZ /M8026 OFFSET REGISTER ERROR/
3746 030500 047411 043106 042523
3747 030506 020124 042522 044507
3748 030514 052123 051105 042440
3749 030522 051122 051117 000
3750 030527 115 030070 033062 EM7: .ASCIZ /M8026 DUAL REGISTER SELECTION ERROR/
3751 030534 042011 040525 020114
3752 030542 042522 044507 052123
3753 030550 051105 051440 046105
3754 030556 041505 044524 047117
3755 030564 042440 051122 051117
3756 030572 000
3757 030573 115 030070 033062 EM10: .ASCIZ /M8026-M8036 LOW 16 BIT Z COUNT ERROR/
3758 030600 046455 030070 033063
3759 030606 046011 053517 030440
3760 030614 020066 044502 020124
3761 030622 020132 047503 047125
3762 030630 020124 051105 047522
3763 030636 000122
3764 030640 034115 031060 026466 EM11: .ASCIZ /M8026-M8036 HIGH 16 BIT Z COUNT ERROR/
3765 030646 034115 031460 004466
```



3766	030654	044510	044107	030440				
3767	030662	020066	044502	020124				
3768	030670	020132	047503	047125				
3769	030676	020124	051105	047522				
3770	030704	000122						
3771	030706	034115	031060	004466	EM12:	.ASCIZ	/M8026	Z COUNT STATUS ERROR/
3772	030714	020132	047503	047125				
3773	030722	020124	052123	052101				
3774	030730	051525	042440	051122				
3775	030736	051117	000					
3776	030741	115	030070	033062	EM13:	.ASCIZ	/M8026	Z COUNT INTERRUPT ERROR/
3777	030746	055011	041440	052517				
3778	030754	052116	044440	052116				
3779	030762	051105	052522	052120				
3780	030770	042440	051122	051117				
3781	030776	000						
3782	030777	115	030070	033063	EM14:	.ASCIZ	/M8036	JOYSTICK STATUS ERROR/
3783	031004	045011	054517	052123				
3784	031012	041511	020113	052123				
3785	031020	052101	051525	042440				
3786	031026	051122	051117	000				
3787	031033	115	030070	033063	EM15:	.ASCIZ	/M8036	JOYSTICK DATA ERROR/
3788	031040	045011	054517	052123				
3789	031046	041511	020113	040504				
3790	031054	040524	042440	051122				
3791	031062	051117	000					
3792	031065	115	030070	033063	EM16:	.ASCIZ	/M8036	DATA INCREMENT ERROR/
3793	031072	042011	052101	020101				
3794	031100	047111	051103	046505				
3795	031106	047105	020124	051105				
3796	031114	047522	000122					
3797	031120	034115	031460	004466	EM17:	.ASCIZ	/M8036	DATA DECREMENT ERROR/
3798	031126	040504	040524	042040				
3799	031134	041505	042522	042515				
3800	031142	052116	042440	051122				
3801	031150	051117	000					
3802	031153	115	030070	033062	EM20:	.ASCIZ	/M8026-M8036	MATRIX MODE ADDRESS MAKER DATA ERROR/
3803	031160	046455	030070	033063				
3804	031166	046411	052101	044522				
3805	031174	020130	047515	042504				
3806	031202	040440	042104	042522				
3807	031210	051523	046440	045501				
3808	031216	051105	042040	052101				
3809	031224	020101	051105	047522				
3810	031232	000122						
3811	031234	034115	031060	004466	EM21:	.ASCIZ	/M8026	LIST MODE ADDRESS MAKER DATA ERROR/
3812	031242	044514	052123	046440				
3813	031250	042117	020105	042101				
3814	031256	051104	051505	020123				
3815	031264	040515	042513	020122				
3816	031272	040504	040524	042440				
3817	031300	051122	051117	000				
3818	031305	115	030070	033062	EM22:	.ASCIZ	/M8026	LIST MODE TRANSFER BUS ADDRESS ERROR/
3819	031312	046011	051511	020124				

3820	031320	047515	042504	052040			
3821	031326	040522	051516	042506			
3822	031334	020122	052502	020123			
3823	031342	042101	051104	051505			
3824	031350	020123	051105	047522			
3825	031356	000122					
3826	031360	034115	031060	004466	EM23:	.ASCIZ	/M8026 LIST MODE TRANSFER WORD COUNT ERROR/
3827	031366	044514	052123	046440			
3828	031374	042117	020105	051124			
3829	031402	047101	043123	051105			
3830	031410	053440	051117	020104			
3831	031416	047503	047125	020124			
3832	031424	051105	047522	000122			
3833	031432	034115	031060	004466	EM24:	.ASCIZ	/M8026 LIST MODE TRANSFER OFFSET ERROR/
3834	031440	044514	052123	046440			
3835	031446	042117	020105	051124			
3836	031454	047101	043123	051105			
3837	031462	047440	043106	042523			
3838	031470	020124	051105	047522			
3839	031476	000122					
3840	031500	034115	031060	004466	EM25:	.ASCIZ	/M8026 TIMEOUT STATUS ERROR/
3841	031506	044524	042515	052517			
3842	031514	020124	052123	052101			
3843	031522	051525	042440	051122			
3844	031530	051117	000				
3845	031533	115	030070	033062	EM26:	.ASCIZ	/M8026 TIMEOUT INTERRUPT ERROR/
3846	031540	052011	046511	047505			
3847	031546	052125	044440	052116			
3848	031554	051105	052522	052120			
3849	031562	042440	051122	051117			
3850	031570	000					
3851	031571	115	030070	033062	EM27:	.ASCIZ	/M8026 SET 'EVENT' OR 'TIME' DATA ERROR/
3852	031576	051411	052105	021040			
3853	031604	053105	047105	021124			
3854	031612	047440	020122	052042			
3855	031620	046511	021105	042040			
3856	031626	052101	020101	051105			
3857	031634	047522	000122				
3858	031640	034115	031060	004466	EM30:	.ASCIZ	/M8026 CELL INCREMENT DATA ERROR/
3859	031646	042503	046114	044440			
3860	031654	041516	042522	042515			
3861	031662	052116	042040	052101			
3862	031670	020101	051105	047522			
3863	031676	000122					
3864	031700	034115	031060	004466	EM31:	.ASCIZ	/M8026 CELL OVERFLOW STATUS ERROR/
3865	031706	042503	046114	047440			
3866	031714	042526	043122	047514			
3867	031722	020127	052123	052101			
3868	031730	051525	042440	051122			
3869	031736	051117	000				
3870	031741	115	030070	033062	EM32:	.ASCIZ	/M8026 CELL OVERFLOW INTERRUPT ERROR/
3871	031746	041411	046105	020114			
3872	031754	053117	051105	046106			
3873	031762	053517	044440	052116			

3874	031770	051105	052522	052120			
3875	031776	042440	051122	051117			
3876	032004	000					
3877	032005	115	030070	033062	EM33:	.ASCIIZ /M8026	MATRIX MODE ADDRESS MUX ERROR/
3878	032012	046411	052101	044522			
3879	032020	020130	047515	042504			
3880	032026	040440	042104	042522			
3881	032034	051523	046440	054125			
3882	032042	042440	051122	051117			
3883	032050	000					
3884	032051	115	030070	033062	EM34:	.ASCIIZ /M8026	'TESTX' FUNCTION ERROR/
3885	032056	021011	042524	052123			
3886	032064	021130	043040	047125			
3887	032072	052103	047511	020116			
3888	032100	051105	047522	000122			
3889	032106	034115	031060	004466	EM35:	.ASCIIZ /M8026	DATA ERROR WHEN TRANSFERING TO EXTENDED MEMORY/
3890	032114	040504	040524	042440			
3891	032122	051122	051117	053440			
3892	032130	042510	020116	051124			
3893	032136	047101	043123	051105			
3894	032144	047111	020107	047524			
3895	032152	042440	052130	047105			
3896	032160	042504	020104	042515			
3897	032166	047515	054522	000			
3898	032173	115	030070	033062	EM36:	.ASCIIZ /M8026	LIST MODE TRANSFER STATUS ERROR/
3899	032200	046011	051511	020124			
3900	032206	047515	042504	052040			
3901	032214	040522	051516	042506			
3902	032222	020122	052123	052101			
3903	032230	051525	042440	051122			
3904	032236	051117	000				
3905	032241	115	030070	033062	EM37:	.ASCIIZ /M8026	LIST MODE TRANSFER DATA ERROR/
3906	032246	046011	051511	020124			
3907	032254	047515	042504	052040			
3908	C??262	040522	051516	042506			
3909	032270	020122	040504	040524			
3910	032276	042440	051122	051117			
3911	032304	000					
3912	032305	112	046525	042520	EM40:	.ASCIIZ /JUMPER-M8026-M7952	'EVENT' OR 'TIME' MARK ERROR/
3913	032312	026522	034115	031060			
3914	032320	026466	033515	032471			
3915	032326	004462	042442	042526			
3916	032334	052116	020042	051117			
3917	032342	021040	044524	042515			
3918	032350	020042	040515	045522			
3919	032356	042440	051122	051117			
3920	032364	000					
3921	032365	115	034467	031065	EM41:	.ASCIIZ /M7952	CLOCK BUS ADDRESS TIMEOUT/
3922	032372	041411	047514	045503			
3923	032400	041040	051525	040440			
3924	032406	042104	042522	051523			
3925	032414	052040	046511	047505			
3926	032422	052125	000				
3927	032425	115	031070	033461	EM42:	.ASCIIZ /M8217	INCORRECT INTERRUPT LEVEL/

3928	032432	044411	041516	051117																	
3929	032440	042522	052103	041110																	
3930	032446	052116	051105	051117																	
3931	032454	052120	046040	051117																	
3932	032462	046105	000																		
3933																					
3934	032465	105	051122	041520	DH1:	.ASCIZ	/ERRPC	ADDR/													
3935	032472	040411	042104	000122																	
3936	032500	051105	050122	004503	DH2:	.ASCIZ	/ERRPC	ADDR	GOOD	BAD/											
3937	032506	042101	051104	043411																	
3938	032514	047517	004504	040502																	
3939	032522	000104																			
3940	032524	051105	050122	004503	DH3:	.ASCIZ	/ERRPC	ADDR	GOOD	BAD	BADADR/										
3941	032532	042101	051104	043411																	
3942	032540	047517	004504	040502																	
3943	032546	004504	040502	040504																	
3944	032554	051104	000																		
3945	032557	105	051122	041520	DH4:	.ASCIZ	/ERRPC	ADDR	GOOD	BAD	EA ADR	BADADR/									
3946	032564	040411	042104	004522																	
3947	032572	047507	042117	041011																	
3948	032600	042101	042411	020101																	
3949	032606	042101	004522	040502																	
3950	032614	040504	051104	000																	
3951	032621	015	012	007	OUTRNG:	.BYTE	15,12,7														
3952	032624	047516	021040	021132		.ASCII	/NO 'Z' PULSES OR /														
3953	032632	050040	046125	042523																	
3954	032640	020123	051117	040																	
3955	032645	111	050116	052125		.ASCII	/INPUT VOLTAGE OUT OF RANGE ON CHANNEL #/														
3956	032652	053040	046117	040524																	
3957	032660	042507	047440	052125																	
3958	032666	047440	020106	040522																	
3959	032674	043516	020105	047117																	
3960	032702	041440	040510	047116																	
3961	032710	046105	021440																		
3962	032714	060	015	012	OUTCHN:	.BYTE	60,15,12,7,0														
3963	032717	007	000																		
3964		032722				.EVEN															
3965	032722	001116	001250	000000	DT1:	.WORD	\$ERRPC,\$BASE,0														
3966	032730	001116	001250	001124	DT2:	.WORD	\$ERRPC,\$BASE,\$GDDAT,\$BDDAT,0														
3967	032736	001126	000000																		
3968	032742	001116	001250	001124	DT3:	.WORD	\$ERRPC,\$BASE,\$GDDAT,\$BDDAT,\$BDADR,0														
3969	032750	001126	001122	000000																	
3970	032756	001116	001250	001124	DT4:	.WORD	\$ERRPC,\$BASE,\$GDDAT,\$BDDAT,NARROW,\$BDADR,0														
3971	032764	001126	041756	001122																	
3972	032772	000000																			
3973	032774	001116	001254	000000	DT5:	.WORD	\$ERRPC,\$CDW1,0														
3974	033002	000000			DF0:	.WORD	0														

C  
C

```

3975          .SBTTL  TTY INPUT ROUTINE
3976
3977          ;:*****
3978          .ENABL  LSB
3979
3980          ;:*****
3981          ;*SOFTWARE SWITCH REGISTER CHANGE ROUTINE.
3982          ;*ROUTINE IS ENTERED FROM THE TRAP HANDLER, AND WILL
3983          ;*SERVICE THE TEST FOR CHANGE IN SOFTWARE SWITCH REGISTER TRAP CALL
3984          ;*WHEN OPERATING IN TTY FLAG MODE.
3985 033004 022737 000176 001140 $CKSWR: CMP    #SWREG,SWR    ;; IS THE SOFT-SWR SELECTED?
3986 033012 001074                BNE    15$          ;; BRANCH IF NO
3987 033014 105777 146124          TSTB   @TKS        ;; CHAR THERE?
3988 033020 100071                BPL    15$          ;; IF NO, DON'T WAIT AROUND
3989 033022 117746 146120          MOVB   @TKB,-(SP)   ;; SAVE THE CHAR
3990 033026 042716 177600          BIC    #^C177,(SP) ;; STRIP-OFF THE ASCII
3991 033032 022726 000007          CMP    #7,(SP)+    ;; IS IT A CONTROL G?
3992 033036 001062                BNE    15$          ;; NO, RETURN TO USER
3993 033040 123727 001134 000001  CMPB   $AUTOB,#1   ;; ARE WE RUNNING IN AUTO-MODE?
3994 033046 001456                BEQ    15$          ;; BRANCH IF YES
3995
3996 033050 104401 033531          TYPE   , $CNTLG    ;; ECHO THE CONTROL-G (^G)
3997 033054 104401 033536          $GTSWR: TYPE   , $MSWR    ;; TYPE CURRENT CONTENTS
3998 033060 013746 000176          MOV    SWREG,-(SP) ;; SAVE SWREG FOR TYPEOUT
3999 033064 104402                TYPOC                ;; GO TYPE--OCTAL ASCII(ALL DIGITS)
4000 033066 104401 033547          TYPE   , $MNEW    ;; PROMPT FOR NEW SWR
4001 033072 005046                19$: CLR    -(SP)    ;; CLEAR COUNTER
4002 033074 005046                CLR    -(SP)    ;; THE NEW SWR
4003 033076 105777 146042          7$:  TSTB   @TKS        ;; CHAR THERE?
4004 033102 100375                BPL    7$         ;; IF NOT TRY AGAIN
4005
4006 033104 117746 146036          MOVB   @TKB,-(SP)   ;; PICK UP CHAR
4007 033110 042716 177600          BIC    #^C177,(SP) ;; MAKE IT 7-BIT ASCII
4008
4009
4010
4011 033114 021627 000025          9$:  CMP    (SP),#25  ;; IS IT A CONTROL-U?
4012 033120 001005                BNE    10$        ;; BRANCH IF NOT
4013 033122 104401 033524          TYPE   , $CNTLU    ;; YES, ECHO CONTROL-U (^U)
4014 033126 062706 000006          20$: ADD    #6,SP    ;; IGNORE PREVIOUS INPUT
4015 033132 000757                BR     19$        ;; LET'S TRY IT AGAIN
4016
4017
4018 033134 021627 000015          10$: CMP    (SP),#15  ;; IS IT A <CR>?
4019 033140 001022                BNE    16$        ;; BRANCH IF NO
4020 033142 005766 000004          TST    4(SP)       ;; YES, IS IT THE FIRST CHAR?
4021 033146 001403                BEQ    11$        ;; BRANCH IF YES
4022 033150 016677 000002 145762  MOV    2(SP),@SWR   ;; SAVE NEW SWR
4023 033156 062706 000006          11$: ADD    #6,SP    ;; CLEAR UP STACK
4024 033162 104401 001171          14$: TYPE   , $CRLF    ;; ECHO <CR> AND <LF>
4025 033166 123727 001135 000001  CMPB   $INTAG,#1   ;; RE-ENABLE TTY KBD INTERRUPTS?
4026 033174 001003                BNE    15$        ;; BRANCH IF NOT
4027 033176 012777 000100 145740  MOV    #100,@TKS   ;; RE-ENABLE TTY KBD INTERRUPTS
4028 033204 000002          15$: RTI          ;; RETURN
  
```

```

4029 033206 004737 034604      16$: JSR    PC,$TYPEC      ;;ECHO CHAR
4030 033212 021627 000060      CMP    (SP),#60        ;;CHAR < 0?
4031 033216 002420                BLT    18$             ;;BRANCH IF YES
4032 033220 021627 000067      CMP    (SP),#67        ;;CHAR > 7?
4033 033224 003015                BGT    18$             ;;BRANCH IF YES
4034 033226 042726 000060      BIC    #60,(SP)+       ;;STRIP-OFF ASCII
4035 033232 005766 000002      TST    2(SP)           ;;IS THIS THE FIRST CHAR
4036 033236 001403                BEQ    17$             ;;BRANCH IF YES
4037 033240 006316                ASL    (SP)            ;;NO, SHIFT PRESENT
4038 033242 006316                ASL    (SP)            ;;CHAR OVER TO MAKE
4039 033244 006316                ASL    (SP)            ;;ROOM FOR NEW ONE.
4040 033246 005266 000002      17$: INC    2(SP)        ;;KEEP COUNT OF CHAR
4041 033252 056616 177776      BIS    -2(SP),(SP)    ;;SET IN NEW CHAR
4042 033256 000707                BR     7$              ;;GET THE NEXT ONE
4043 033260 104401 001170      18$: TYPE  $QUES      ;;TYPE ?<CR><LF>
4044 033264 000720                BR     20$            ;;SIMULATE CONTROL-U
4045 .DSABL  LSB
4046
4047
4048
4049
4050
4051
4052
4053
4054
4055
4056 033266 011646                $RDCHR: MOV    (SP),-(SP) ;;PUSH DOWN THE PC
4057 033270 016666 000004 000002 MOV    4(SP),2(SP)    ;;SAVE THE PS
4058 033276 105777 145642      1$: TSTB   @$TKS      ;;WAIT FOR
4059 033302 100375                BPL    1$             ;;A CHARACTER
4060 033304 117766 145636 000004 MOVVB  @$TKB,4(SP)    ;;READ THE TTY
4061 033312 042766 177600 000004 BIC    #^C<177>,4(SP) ;;GET RID OF JUNK IF ANY
4062 033320 026627 000004 000023 CMP    4(SP),#23     ;;IS IT A CONTROL-S?
4063 033326 001013                BNE    3$             ;;BRANCH IF NO
4064 033330 105777 145610      2$: TSTB   @$TKS      ;;WAIT FOR A CHARACTER
4065 033334 100375                BPL    2$             ;;LOOP UNTIL ITS THERE
4066 033336 117746 145604 MOVVB  @$TKB,-(SP)    ;;GET CHARACTER
4067 033342 042716 177600 BIC    #^C177,(SP)   ;;MAKE IT 7-BIT ASCII
4068 033346 022627 000021 CMP    (SP)+,#21     ;;IS IT A CONTROL-Q?
4069 033352 001366                BNE    2$             ;;IF NOT DISCARD IT
4070 033354 000750                BR     1$             ;;YES, RESUME
4071 033356 026627 000004 000140 3$: CMP    4(SP),#140    ;;IS IT UPPER CASE?
4072 033364 002407                BLT    4$             ;;BRANCH IF YES
4073 033366 026627 000004 000175 CMP    4(SP),#175    ;;IS IT A SPECIAL CHAR?
4074 033374 003003                BGT    4$             ;;BRANCH IF YES
4075 033376 042766 000040 000004 BIC    #40,4(SP)     ;;MAKE IT UPPER CASE
4076 033404 000002      4$: RTI                ;;GO BACK TO USER
4077
4078
4079
4080
4081
4082

```

\*\*\*\*\*

\*THIS ROUTINE WILL INPUT A SINGLE CHARACTER FROM THE TTY

\*CALL:

```

* RDCHR      ;;INPUT A SINGLE CHARACTER FROM THE TTY
* RETURN HERE ;;CHARACTER IS ON THE STACK
*           ;;WITH PARITY BIT STRIPPED OFF

```

:

\*\*\*\*\*

\*THIS ROUTINE WILL INPUT A STRING FROM THE TTY

\*CALL:

```

* RDLIN     ;;INPUT A STRING FROM THE TTY
* RETURN HERE ;;ADDRESS OF FIRST CHARACTER WILL BE ON THE STACK
*           ;;TERMINATOR WILL BE A BYTE OF ALL 0'S

```

```

4083
4084 033406 010346 $RDLIN: MOV R3,-(SP) ;;SAVE R3
4085 033410 012703 033514 1$: MOV #$TTYIN,R3 ;;GET ADDRESS
4086 033414 022703 033524 2$: CMP #$TTYIN+8.,R3 ;;BUFFER FULL?
4087 033420 101405 BLOS 4$ ;;BR IF YES
4088 033422 104410 RDCHR ;;GO READ ONE CHARACTER FROM THE TTY
4089 033424 112613 MOVB (SP)+,(R3) ;;GET CHARACTER
4090 033426 122713 000177 10$: CMPB #177,(R3) ;;IS IT A RUBOUT
4091 033432 001003 BNE 3$ ;;SKIP IF NOT
4092 033434 104401 001170 4$: TYPE ,SQUES ;;TYPE A '?'
4093 033440 000763 BR 1$ ;;CLEAR THE BUFFER AND LOOP
4094 033442 111337 033512 3$: MOVB (R3),9$ ;;ECHO THE CHARACTER
4095 033446 104401 033512 TYPE ,9$
4096 033452 122723 000015 CMPB #15,(R3)+ ;;CHECK FOR RETURN
4097 033456 001356 BNE 2$ ;;LOOP IF NOT RETURN
4098 033460 105063 177777 CLR B -1(R3) ;;CLEAR RETURN (THE 15)
4099 033464 104401 001172 TYPE ,SLF ;;TYPE A LINE FEED
4100 033470 012603 MOV (SP)+,R3 ;;RESTORE R3
4101 033472 011646 MOV (SP),-(SP) ;;ADJUST THE STACK AND PUT ADDRESS OF THE
4102 033474 016666 000004 000002 MOV 4(SP),2(SP) ;; FIRST ASCII CHARACTER ON IT
4103 033502 012766 033514 000004 MOV #$TTYIN,4(SP)
4104 033510 000002 RTI ;;RETURN
4105 033512 000 9$: .BYTE 0 ;;STORAGE FOR ASCII CHAR. TO TYPE
4106 033513 000 .BYTE 0 ;;TERMINATOR
4107 033514 000010 $TTYIN: .BLKB 8. ;;RESERVE 8 BYTES FOR TTY INPUT
4108 033524 052536 005015 000 $CNTLU: .ASCIZ /^U/<15><12> ;;CONTROL 'U'
4109 033531 136 006507 000012 $CNTLG: .ASCIZ /^G/<15><12> ;;CONTROL 'G'
4110 033536 005015 053523 020122 $MSWR: .ASCIZ <15><12>/SWR = /
4111 033544 020075 000
4112 033547 040 047040 053505 $MNEW: .ASCIZ / NEW = /
4113 033554 036440 000040

```

```

4114          .SBTTL  READ AN OCTAL NUMBER FROM THE TTY
4115
4116          ;:*****
4117          ;:THIS ROUTINE WILL READ AN OCTAL (ASCII) NUMBER FROM THE TTY AND
4118          ;:CHANGE IT TO BINARY.
4119          ;:CALL:
4120          ;:*      RDOCT          ;:READ AN OCTAL NUMBER
4121          ;:*      RETURN HERE  ;:LOW ORDER BITS ARE ON TOP OF THE STACK
4122          ;:*                ;:HIGH ORDER BITS ARE IN $HIOCT
4123
4124 033560 011646          $RDOCT: MOV      (SP),-(SP)      ;:PROVIDE SPACE FOR THE
4125 033562 016666 000004 000002      MOV      4(SP),2(SP)  ;:INPUT NUMBER
4126 033570 010046          MOV      R0,-(SP)      ;:PUSH R0 ON STACK
4127 033572 010146          MOV      R1,-(SP)      ;:PUSH R1 ON STACK
4128 033574 010246          MOV      R2,-(SP)      ;:PUSH R2 ON STACK
4129 033576 104411          1$:  RDLIN          ;:READ AN ASCII LINE
4130 033600 012600          MOV      (SP)+,R0      ;:GET ADDRESS OF 1ST CHARACTER
4131 033602 005001          CLR      R1          ;:CLEAR DATA WORD
4132 033604 005002          CLR      R2
4133 033606 112046          2$:  MOVB     (R0)+,-(SP)  ;:PICKUP THIS CHARACTER
4134 033610 001412          BEQ     3$          ;:IF ZERO GET OUT
4135 033612 006301          ASL     R1          ;:*2
4136 033614 006102          ROL     R2
4137 033616 006301          ASL     R1          ;:*4
4138 033620 006102          ROL     R2
4139 033622 006301          ASL     R1          ;:*8
4140 033624 006102          ROL     R2
4141 033626 042716 177770          BIC     #^C7,(SP)  ;:STRIP THE ASCII JUNK
4142 033632 062601          ADD     (SP)+,R1  ;:ADD IN THIS DIGIT
4143 033634 000764          BR      2$          ;:LOOP
4144 033636 005726          3$:  TST     (SP)+      ;:CLEAN TERMINATOR FROM STACK
4145 033640 010166 000012          MOV     R1,12(SP) ;:SAVE THE RESULT
4146 033644 010237 033660          MOV     R2,$HIOCT
4147 033650 012602          MOV     (SP)+,R2  ;:POP STACK INTO R2
4148 033652 012601          MOV     (SP)+,R1  ;:POP STACK INTO R1
4149 033654 012600          MOV     (SP)+,R0  ;:POP STACK INTO R0
4150 033656 000002          RTI          ;:RETURN
4151 033660 000000          $HIOCT: .WORD 0  ;:HIGH ORDER BITS GO HERE

```



```

4152          .SBTTL  CONVERT BINARY TO DECIMAL AND TYPE ROUTINE
4153
4154          ;:*****
4155          ;:THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 5-DIGIT
4156          ;:SIGNED DECIMAL (ASCII) NUMBER AND TYPE IT. DEPENDING ON WHETHER THE
4157          ;:NUMBER IS POSITIVE OR NEGATIVE A SPACE OR A MINUS SIGN WILL BE TYPED
4158          ;:BEFORE THE FIRST DIGIT OF THE NUMBER. LEADING ZEROS WILL ALWAYS BE
4159          ;:REPLACED WITH SPACES.
4160          ;:CALL:
4161          ;*      MOV      NUM,-(SP)          ;;PUT THE BINARY NUMBER ON THE STACK
4162          ;*      TYPDS          ;;GO TO THE ROUTINE
4163
4164          $TYPDS:
4165          033662 010046          MOV      R0,-(SP)          ;;PUSH R0 ON STACK
4166          033664 010146          MOV      R1,-(SP)          ;;PUSH R1 ON STACK
4167          033666 010246          MOV      R2,-(SP)          ;;PUSH R2 ON STACK
4168          033670 010346          MOV      R3,-(SP)          ;;PUSH R3 ON STACK
4169          033672 010546          MOV      R5,-(SP)          ;;PUSH R5 ON STACK
4170          033674 012746 020200  MOV      #20200,-(SP)      ;;SET BLANK SWITCH AND SIGN
4171          033700 016605 000020  MOV      20(SP),R5        ;;GET THE INPUT NUMBER
4172          033704 100004          BPL      1$                ;;BR IF INPUT IS POS.
4173          033706 005405          NEG      R5                ;;MAKE THE BINARY NUMBER POS.
4174          033710 112766 000055 000001  MOVB     #'-,1(SP)        ;;MAKE THE ASCII NUMBER NEG.
4175          033716 005000          1$:      CLR      R0                ;;ZERO THE CONSTANTS INDEX
4176          033720 012703 034076          MOV      #$DBLK,R3        ;;SETUP THE OUTPUT POINTER
4177          033724 112723 000040          MOVB     #' ,(R3)+        ;;SET THE FIRST CHARACTER TO A BLANK
4178          033730 005002          2$:      CLR      R2                ;;CLEAR THE BCD NUMBER
4179          033732 016001 034066          MOV      $DTBL(R0),R1     ;;GET THE CONSTANT
4180          033736 160105          3$:      SUB      R1,R5          ;;FORM THIS BCD DIGIT
4181          033740 002402          BLT      4$                ;;BR IF DONE
4182          033742 005202          INC      R2                ;;INCREASE THE BCD DIGIT BY 1
4183          033744 000774          BR       3$
4184          033746 060105          4$:      ADD      R1,R5          ;;ADD BACK THE CONSTANT
4185          033750 005702          TST      R2                ;;CHECK IF BCD DIGIT=0
4186          033752 001002          BNE      5$                ;;FALL THROUGH IF 0
4187          033754 105716          TSTB     (SP)             ;;STILL DOING LEADING 0'S?
4188          033756 100407          BMI      7$                ;;BR IF YES
4189          033760 106316          5$:      ASLB     (SP)             ;;MSD?
4190          033762 103003          BCC      6$                ;;BR IF NO
4191          033764 116663 000001 177777  MOVB     1(SP),-1(R3)     ;;YES--SET THE SIGN
4192          033772 052702 000060          BIS      #'0,R2           ;;MAKE THE BCD DIGIT ASCII
4193          033776 052702 000040          6$:      BIS      #' ,R2           ;;MAKE IT A SPACE IF NOT ALREADY A DIGIT
4194          034002 110223          MOVB     R2,(R3)+        ;;PUT THIS CHARACTER IN THE OUTPUT BUFFER
4195          034004 005720          TST      (R0)+           ;;JUST INCREMENTING
4196          034006 020027 000010          CMP      R0,#10          ;;CHECK THE TABLE INDEX
4197          034012 002746          BLT      2$                ;;GO DO THE NEXT DIGIT
4198          034014 003002          BGT      8$                ;;GO TO EXIT
4199          034016 010502          MOV      R5,R2           ;;GET THE LSD
4200          034020 000764          BR       6$                ;;GO CHANGE TO ASCII
4201          034022 105726          8$:      TSTB     (SP)+        ;;WAS THE LSD THE FIRST NON-ZERO?
4202          034024 100003          BPL      9$                ;;BR IF NO
4203          034026 116663 177777 177776  MOVB     -1(SP),-2(R3)   ;;YES--SET THE SIGN FOR TYPING
4204          034034 105013          9$:      CLRB     (R3)           ;;SET THE TERMINATOR
4205          034036 012605          MOV      (SP)+,R5        ;;POP STACK INTO R5

```

```

4206 034040 012603      MOV      (SP)+,R3      ;;POP STACK INTO R3
4207 034042 012602      MOV      (SP)+,R2      ;;POP STACK INTO R2
4208 034044 012601      MOV      (SP)+,R1      ;;POP STACK INTO R1
4209 034046 012600      MOV      (SP)+,R0      ;;POP STACK INTO R0
4210 034050 104401 034076  TYPE      $DBLK      ;;NOW TYPE THE NUMBER
4211 034054 016666 000002 000004  MOV      2(SP),4(SP)   ;;ADJUST THE STACK
4212 034062 012616      MOV      (SP)+,(SP)
4213 034064 000002      RTI                      ;;RETURN TO USER
4214 034066 023420      $DTBL: 10000.
4215 034070 001750      1000.
4216 034072 000144      100.
4217 034074 000012      10.
4218 034076 000004      $DBLK: .BLKW 4
4219                      .SBTTL SCOPE HANDLER ROUTINE
4220
4221                      ;:*****
4222                      ;*THIS ROUTINE CONTROLS THE LOOPING OF SUBTESTS. IT WILL INCREMENT
4223                      ;*AND LOAD THE TEST NUMBER($STNM) INTO THE DISPLAY REG.(DISPLAY<7:0>)
4224                      ;*AND LOAD THE ERROR FLAG ($ERFLG) INTO DISPLAY<15:08>
4225                      ;*THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
4226                      ;*SW14=1      LOOP ON TEST
4227                      ;*SW11=1      INHIBIT ITERATIONS
4228                      ;*SW09=1      LOOP ON ERROR
4229                      ;*SW08=1      LOOP ON TEST IN SWR<7:0>
4230                      ;*CALL
4231                      ;*      SCOPE      ;;SCOPE-IOT
4232
4233                      $SCOPE:
4234 034106 104407      CKSWR      ;;TEST FOR CHANGE IN SOFT-SWR
4235 034110 004737 046042      JSR      PC,CTRLCG      ;TEST FOR CTRL C OR G
4236 034114 032777 040000 145016 1$:      BIT      #BIT14,@SWR      ;;LOOP ON PRESENT TEST?
4237 034122 001114      BNE      $OVER      ;;YES IF SW14=1
4238                      ;*****START OF CODE FOR THE XOR TESTER*****
4239 034124 000416      $XTSTR: BR      6$      ;;IF RUNNING ON THE 'XOR' TESTER CHANGE
4240                      ;;THIS INSTRUCTION TO A 'NOP' (NOP=240)
4241 034126 013746 000004      MOV      @#ERRVEC,-(SP)  ;;SAVE THE CONTENTS OF THE ERROR VECTOR
4242 034132 012737 034152 000004      MOV      #5$,@#ERRVEC  ;;SET FOR TIMEOUT
4243 034140 005737 177060      TST      @#177060      ;;TIME OUT ON XOR?
4244 034144 012637 000004      MOV      (SP)+,@#ERRVEC ;;RESTORE THE ERROR VECTOR
4245 034150 000463      BR      $SVLAD      ;;GO TO THE NEXT TEST
4246 034152 022626      5$:      CMP      (SP)+,(SP)+    ;;CLEAR THE STACK AFTER A TIME OUT
4247 034154 012637 000004      MOV      (SP)+,@#ERRVEC ;;RESTORE THE ERROR VECTOR
4248 034160 000423      BR      7$      ;;LOOP ON THE PRESENT TEST
4249 034162      6$: ;*****END OF CODE FOR THE XOR TESTER*****
4250 034162 032777 000400 144750      BIT      #BIT08,@SWR      ;;LOOP ON SPEC. TEST?
4251 034170 001404      BEQ      2$      ;;BR IF NO
4252 034172 127737 144742 001102      CMPB    @SWR,$STNM      ;;ON THE RIGHT TEST? SWR<7:0>
4253 034200 001465      BEQ      $OVER      ;;BR IF YES
4254 034202 105737 001103      2$:      TSTB    $ERFLG      ;;HAS AN ERROR OCCURRED?
4255 034206 001421      BEQ      3$      ;;BR IF NO
4256 034210 123737 001115 001103      CMPB    $ERMAX,$ERFLG  ;;MAX. ERRORS FOR THIS TEST OCCURRED?
4257 034216 101015      BHI      3$      ;;BR IF NO
4258 034220 032777 001000 144712      BIT      #BIT09,@SWR      ;;LOOP ON ERROR?
4259 034226 001404      BEQ      4$      ;;BR IF NO

```

```

4260 034230 013737 001110 001106 7$: MOV $LPERR,$LPADR ;;SET LOOP ADDRESS TO LAST SCOPE
4261 034236 000446 BR $OVER
4262 034240 105037 001103 4$: CLRB $ERFLG ;;ZERO THE ERROR FLAG
4263 034244 005037 001160 CLR $TIMES ;;CLEAR THE NUMBER OF ITERATIONS TO MAKE
4264 034250 000415 BR 1$ ;;ESCAPE TO THE NEXT TEST
4265 034252 032777 004000 144660 3$: BIT #BIT11,@SWR ;;INHIBIT ITERATIONS?
4266 034260 001011 BNE 1$ ;;BR IF YES
4267 034262 005737 001202 TST $PASS ;;IF FIRST PASS OF PROGRAM
4268 034266 001406 BEQ 1$ ;; INHIBIT ITERATIONS
4269 034270 005237 001104 INC $ICNT ;;INCREMENT ITERATION COUNT
4270 034274 023737 001160 001104 CMP $TIMES,$ICNT ;;CHECK THE NUMBER OF ITERATIONS MADE
4271 034302 002024 BGE $OVER ;;BR IF MORE ITERATION REQUIRED
4272 034304 012737 000001 001104 1$: MOV #1,$ICNT ;;REINITIALIZE THE ITERATION COUNTER
4273 034312 013737 034370 001160 MOV $MXCNT,$TIMES ;;SET NUMBER OF ITERATIONS TO DO
4274 034320 105237 001102 $SVLAD: INCB $TSTNM ;;COUNT TEST NUMBERS
4275 034324 113737 001102 001200 MOVB $TSTNM,$TESTN ;;SET TEST NUMBER IN APT MAILBOX
4276 034332 011637 001106 MOV (SP),$LPADR ;;SAVE SCOPE LOOP ADDRESS
4277 034336 011637 001110 MOV (SP),$LPERR ;;SAVE ERROR LOOP ADDRESS
4278 034342 005037 001162 CLR $ESCAPE ;;CLEAR THE ESCAPE FROM ERROR ADDRESS
4279 034346 112737 000001 001115 MOVB #1,$ERMAX ;;ONLY ALLOW ONE(1) ERROR ON NEXT TEST
4280 034354 013777 001102 144560 $OVER: MOV $TSTNM,@DISPLAY ;;DISPLAY TEST NUMBER
4281 034362 013716 001106 MOV $LPADR,(SP) ;;FUDGE RETURN ADDRESS
4282 034366 000002 RTI ;;FIXES PS
4283 034370 003720 $MXCNT: 2000. ;;MAX. NUMBER OF ITERATIONS
4284 .SBTTL TYPE ROUTINE
4285
4286 *****
4287 *ROUTINE TO TYPE ASCIZ MESSAGE. MESSAGE MUST TERMINATE WITH A 0 BYTE.
4288 *THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED.
4289 *NOTE1: $NULL CONTAINS THE CHARACTER TO BE USED AS THE FILLER CHARACTER.
4290 *NOTE2: $FILLS CONTAINS THE NUMBER OF FILLER CHARACTERS REQUIRED.
4291 *NOTE3: $FILLC CONTAINS THE CHARACTER TO FILL AFTER.
4292 *
4293 *CALL:
4294 *1) USING A TRAP INSTRUCTION
4295 * TYPE ,MESADR ;;MESADR IS FIRST ADDRESS OF AN ASCIZ STRING
4296 *OR
4297 * TYPE
4298 * MESADR
4299 *
4300
4301 034372 105737 001157 $TYPE: TSTB $TPFLG ;;IS THERE A TERMINAL?
4302 034376 100002 BPL 1$ ;;BR IF YES
4303 034400 000000 HALT ;;HALT HERE IF NO TERMINAL
4304 034402 000430 BR 3$ ;;LEAVE
4305 034404 010046 1$: MOV R0,-(SP) ;;SAVE R0
4306 034406 017600 000002 MOV @2(SP),R0 ;;GET ADDRESS OF ASCIZ STRING
4307 034412 122737 000001 001214 CMPB #APTENV,$ENV ;;RUNNING IN APT MODE
4308 034420 001011 BNE 62$ ;;NO,GO CHECK FOR APT CONSOLE
4309 034422 132737 000100 001215 BITB #APTSPOOL,$ENVM ;;SPOOL MESSAGE TO APT
4310 034430 001405 BEQ 62$ ;;NO,GO CHECK FOR CONSOLE
4311 034432 010037 034442 MOV R0,61$ ;;SETUP MESSAGE ADDRESS FOR APT
4312 034436 004737 035444 JSR PC,$ATY3 ;;SPOOL MESSAGE TO APT
4313 034442 000000 61$: .WORD 0 ;;MESSAGE ADDRESS

```

```

4314 034444 132737 000040 001215 62$: BITB #APTCSUP,$ENVM ;;APT CONSOLE SUPPRESSED
4315 034452 001003 BNE 60$ ;;YES,SKIP TYPE OUT
4316 034454 112046 2$: MOVB (RO)+,-(SP) ;;PUSH CHARACTER TO BE TYPED ONTO STACK
4317 034456 001005 BNE 4$ ;;BR IF IT ISN'T THE TERMINATOR
4318 034460 005726 TST (SP)+ ;;IF TERMINATOR POP IT OFF THE STACK
4319 034462 012600 60$: MOV (SP)+,RO ;;RESTORE RO
4320 034464 062716 C00002 3$: ADD #2,(SP) ;;ADJUST RETURN PC
4321 034470 000002 RTI ;;RETURN
4322 034472 122716 000011 4$: CMPB #HT,(SP) ;;BRANCH IF <HT>
4323 034476 001430 BEQ 8$
4324 034500 122716 000200 CMPB #CRLF,(SP) ;;BRANCH IF NOT <CRLF>
4325 034504 001006 BNE 5$
4326 034506 005726 TST (SP)+ ;;POP <CR><LF> EQUIV
4327 034510 104401 TYPE ;;TYPE A CR AND LF
4328 034512 001171 $CRLF
4329 034514 105037 034650 CLRB $CHARCNT ;;CLEAR CHARACTER COUNT
4330 034520 000755 BR 2$ ;;GET NEXT CHARACTER
4331 034522 004737 034604 5$: JSR PC,$TYPEC ;;GO TYPE THIS CHARACTER
4332 034526 123726 001156 6$: CMPB $FILLC,(SP)+ ;;IS IT TIME FOR FILLER CHARS.?
4333 034532 001350 BNE 2$ ;;IF NO GO GET NEXT CHAR.
4334 034534 013746 001154 MOV $NULL,-(SP) ;;GET # OF FILLER CHARS. NEEDED
4335 ;;AND THE NULL CHAR.
4336 034540 105366 000001 7$: DECB 1(SP) ;;DOES A NULL NEED TO BE TYPED?
4337 034544 002770 BLT 6$ ;;BR IF NO--GO POP THE NULL OFF OF STACK
4338 034546 004737 034604 JSR PC,$TYPEC ;;GO TYPE A NULL
4339 034552 105337 034650 DECB $CHARCNT ;;DO NOT COUNT AS A COUNT
4340 034556 000770 BR 7$ ;;LOOP
4341
4342 ;HORIZONTAL TAB PROCESSOR
4343
4344 034560 112716 000040 8$: MOVB #' ,(SP) ;;REPLACE TAB WITH SPACE
4345 034564 004737 034604 9$: JSR PC,$TYPEC ;;TYPE A SPACE
4346 034570 132737 000007 034650 BITB #7,$CHARCNT ;;BRANCH IF NOT AT
4347 034576 001372 BNE 9$ ;;TAB STOP
4348 034600 005726 TST (SP)+ ;;POP SPACE OFF STACK
4349 034602 000724 BR 2$ ;;GET NEXT CHARACTER
4350 034604 105777 144340 $TYPEC: TSTB @$TPS ;;WAIT UNTIL PRINTER IS READY
4351 034610 100375 BPL $TYPEC
4352 034612 116677 000002 144332 MOVB 2(SP),@$TPB ;;LOAD CHAR TO BE TYPED INTO DATA REG.
4353 034620 122766 000015 000002 CMPB #CR,2(SP) ;;IS CHARACTER A CARRIAGE RETURN?
4354 034626 001003 BNE 1$ ;;BRANCH IF NO
4355 034630 105037 034650 CLRB $CHARCNT ;;YES--CLEAR CHARACTER COUNT
4356 034634 000406 BR $TYPEX ;;EXIT
4357 034636 122766 000012 000002 1$: CMPB #LF,2(SP) ;;IS CHARACTER A LINE FEED?
4358 034644 001402 BEQ $TYPEX ;;BRANCH IF YES
4359 034646 105227 INCB (PC)+ ;;COUNT THE CHARACTER
4360 034650 000000 $CHARCNT: .WORD 0 ;;CHARACTER COUNT STORAGE
4361 034652 000207 $TYPEX: RTS PC
4362

```

```

4363          .SBTTL BINARY TO OCTAL (ASCII) AND TYPE
4364
4365          ;:*****
4366          ;:THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 6-DIGIT
4367          ;:OCTAL (ASCII) NUMBER AND TYPE IT.
4368          ;:$TYPOS---ENTER HERE TO SETUP SUPPRESS ZEROS AND NUMBER OF DIGITS TO TYPE
4369          ;:CALL:
4370          ;:      MOV      NUM,-(SP)          ;:NUMBER TO BE TYPED
4371          ;:      TYPOS          ;:CALL FOR TYPEOUT
4372          ;:      .BYTE  N          ;:N=1 TO 6 FOR NUMBER OF DIGITS TO TYPE
4373          ;:      .BYTE  M          ;:M=1 OR 0
4374          ;:
4375          ;:
4376          ;:
4377          ;:$TYPON----ENTER HERE TO TYPE OUT WITH THE SAME PARAMETERS AS THE LAST
4378          ;:$TYPOS OR $TYPOC
4379          ;:CALL:
4380          ;:      MOV      NUM,-(SP)          ;:NUMBER TO BE TYPED
4381          ;:      TYPON          ;:CALL FOR TYPEOUT
4382          ;:
4383          ;:$TYPOC---ENTER HERE FOR TYPEOUT OF A 16 BIT NUMBER
4384          ;:CALL:
4385          ;:      MOV      NUM,-(SP)          ;:NUMBER TO BE TYPED
4386          ;:      TYPOC          ;:CALL FOR TYPEOUT
4387
4388 034654 017646 000000          $TYPOS: MOV      @ (SP),-(SP)          ;:PICKUP THE MODE
4389 034660 116637 000001 035077  MOVVB   1(SP), $OFILL          ;:LOAD ZERO FILL SWITCH
4390 034666 112637 035101          MOVVB   (SP)+, $OMODE+1          ;:NUMBER OF DIGITS TO TYPE
4391 034672 062716 000002          ADD     #2, (SP)          ;:ADJUST RETURN ADDRESS
4392 034676 000406          BR      $TYPON
4393 034700 112737 000001 035077  $TYPOC: MOVVB  #1, $OFILL          ;:SET THE ZERO FILL SWITCH
4394 034706 112737 000006 035101  MOVVB   #6, $OMODE+1          ;:SET FOR SIX(6) DIGITS
4395 034714 112737 000005 035076  $TYPON: MOVVB  #5, $OCNT          ;:SET THE ITERATION COUNT
4396 034722 010346          MOV     R3, -(SP)          ;:SAVE R3
4397 034724 010446          MOV     R4, -(SP)          ;:SAVE R4
4398 034726 010546          MOV     R5, -(SP)          ;:SAVE R5
4399 034730 113704 035101          MOVVB  $OMODE+1, R4          ;:GET THE NUMBER OF DIGITS TO TYPE
4400 034734 005404          NEG     R4
4401 034736 062704 000006          ADD     #6, R4          ;:SUBTRACT IT FOR MAX. ALLOWED
4402 034742 110437 035100          MOVVB  R4, $OMODE          ;:SAVE IT FOR USE
4403 034746 113704 035077          MOVVB  $OFILL, R4          ;:GET THE ZERO FILL SWITCH
4404 034752 016605 000012          MOV     12(SP), R5          ;:PICKUP THE INPUT NUMBER
4405 034756 005003          CLR     R3          ;:CLEAR THE OUTPUT WORD
4406 034760 006105          1$:    ROL     R5          ;:ROTATE MSB INTO 'C'
4407 034762 000404          BR      3$
4408 034764 006105          2$:    ROL     R5          ;:FORM THIS DIGIT
4409 034766 006105          ROL     R5
4410 034770 006105          ROL     R5
4411 034772 010503          MOV     R5, R3
4412 034774 006103          3$:    ROL     R3          ;:GET LSB OF THIS DIGIT
4413 034776 105337 035100          DECB   $OMODE          ;:TYPE THIS DIGIT?
4414 035002 100016          BPL    7$
4415 035004 042703 177770          BIC    #177770, R3          ;:GET RID OF JUNK
4416 035010 001002          BNE    4$          ;:TEST FOR 0

```

```

4417 035012 005704          TST      R4          ;;SUPPRESS THIS 0?
4418 035014 001403          BEQ      5$          ;;BR IF YES
4419 035016 005204          4$: INC      R4          ;;DON'T SUPPRESS ANYMORE 0'S
4420 035020 052703 000060     BIS      #'0,R3      ;;MAKE THIS DIGIT ASCII
4421 035024 052703 000040     5$: BIS      #' ,R3      ;;MAKE ASCII IF NOT ALREADY
4422 035030 110337 035074     MOVB     R3,8$       ;;SAVE FOR TYPING
4423 035034 104401 035074     TYPE     ,8$        ;;GO TYPE THIS DIGIT
4424 035040 105337 035076     7$: DECB     $OCNT     ;;COUNT BY 1
4425 035044 003347          BGT      2$          ;;BR IF MORE TO DO
4426 035046 002402          BLT      6$          ;;BR IF DONE
4427 035050 005204          INC      R4          ;;INSURE LAST DIGIT ISN'T A BLANK
4428 035052 000744          BR       2$          ;;GO DO THE LAST DIGIT
4429 035054 012605          6$: MOV      (SP)+,R5  ;;RESTORE R5
4430 035056 012604          MOV      (SP)+,R4  ;;RESTORE R4
4431 035060 012603          MOV      (SP)+,R3  ;;RESTORE R3
4432 035062 016666 000002 000004  MOV      2(SP),4(SP) ;;SET THE STACK FOR RETURNING
4433 035070 012616          MOV      (SP)+,(SP)
4434 035072 000002          RTI          ;;RETURN
4435 035074 000          8$: .BYTE    0          ;;STORAGE FOR ASCII DIGIT
4436 035075 000          .BYTE    0          ;;TERMINATOR FOR TYPE ROUTINE
4437 035076 000          $OCNT: .BYTE 0          ;;OCTAL DIGIT COUNTER
4438 035077 000          $OFILL: .BYTE 0        ;;ZERO FILL SWITCH
4439 035100 000000          $OMODE: .WORD 0       ;;NUMBER OF DIGITS TO TYPE
4440
4441          .SBTTL  ERROR HANDLER ROUTINE
4442
4443          ;;*****
4444          ;;*THIS ROUTINE WILL INCREMENT THE ERROR FLAG AND THE ERROR COUNT,
4445          ;;*SAVE THE ERROR ITEM NUMBER AND THE ADDRESS OF THE ERROR CALL
4446          ;;*AND GO TO $ERRTYP ON ERROR
4447          ;;*THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
4448          ;;*SW15=1 HALT ON ERROR
4449          ;;*SW13=1 INHIBIT ERROR TYPEOUTS
4450          ;;*SW10=1 PFL ON ERROR
4451          ;;*SW09=1 LOOP ON ERROR
4452          ;;*CALL
4453          ;;* ERROR N ;;ERROR-EMT AND N-ERROR ITEM NUMBER
4454
4455          $ERROR:
4456 035102 104407          CKSWR          ;;TEST FOR CHANGE IN SOFT-SWR
4457 035104 105237 001103     7$: INCB     $ERFLG     ;;SET THE ERROR FLAG
4458 035110 001775          BEQ      7$          ;;DON'T LET THE FLAG GO TO ZERO
4459 035112 013777 001102 144022  MOV      $TSTNM,@DISPLAY ;;DISPLAY TEST NUMBER AND ERROR FLAG
4460 035120 032777 002000 144012  BIT      #BIT10,@SWR   ;;BELL ON ERROR?
4461 035126 001402          BEQ      1$          ;;NO - SKIP
4462 035130 104401 001164          TYPE     ,SBELL      ;;RING BELL
4463 035134 005237 001112     1$: INC      $ERTTL     ;;COUNT THE NUMBER OF ERRORS
4464 035140 011637 001116     MOV      (SP),$ERRPC  ;;GET ADDRESS OF ERROR INSTRUCTION
4465 035144 162737 000002 001116  SUB      #2,$ERRPC
4466 035152 117737 143740 001114  MOVB     @$ERRPC,$ITEMB ;;STRIP AND SAVE THE ERROR ITEM CODE
4467 035160 032777 020000 143752  BIT      #BIT13,@SWR   ;;SKIP TYPEOUT IF SET
4468 035166 001004          BNE     20$         ;;SKIP TYPEOUTS
4469 035170 004737 035302          JSR     PC,$ERRTYP   ;;GO TO USER ERROR ROUTINE
4470 035174 104401 001171          TYPE     ,SCLF

```

```

4471 035200
4472 035200 122737 000001 001214 20$: CMPB #APTEN.,$ENV ;;RUNNING IN APT MODE
4473 035206 001007 BNE 2$ ;;NO SKIP APT ERROR REPORT
4474 035210 113737 001114 035222 MOVB $ITEMB,21$ ;;SET ITEM NUMBER AS ERROR NUMBER
4475 035216 004737 035454 JSR PC,$ATY4 ;;REPORT FATAL ERROR TO APT
4476 035222 000 21$: .BYTE 0
4477 035223 000 .BYTE 0
4478 035224 000777 22$: BR 22$ ;;APT ERROR LOOP
4479 035226 005777 143706 2$: TST @SWR ;;HALT ON ERROR
4480 035232 100002 BPL 3$ ;;SKIP IF CONTINUE
4481 035234 000000 HALT ;;HALT ON ERROR!
4482 035236 104407 CKSWR ;;TEST FOR CHANGE IN SOFT-SWR
4483 035240 032777 001000 143672 3$: BIT #BIT09,@SWR ;;LOOP ON ERROR SWITCH SET?
4484 035246 001402 BEQ 4$ ;;BR IF NO
4485 035250 013716 001110 MOV $LPERR,(SP) ;;FUDGE RETURN FOR LOOPING
4486 035254 005737 001162 4$: TST $ESCAPE ;;CHECK FOR AN ESCAPE ADDRESS
4487 035260 001402 BEQ 5$ ;;BR IF NONE
4488 035262 013716 001162 MOV $ESCAPE,(SP) ;;FUDGE RETURN ADDRESS FOR ESCAPE
4489 035266
4490 035266 022737 030164 000042 5$: CMP #SENDAD,@#42 ;;ACT-11 AUTO-ACCEPT?
4491 035274 001001 BNE 6$ ;;BRANCH IF NO
4492 035276 000000 HALT ;;YES
4493 035300
4494 035300 000002 6$: RTI ;;RETURN
4495
4496
4497
4498
4499
4500
4501
4502
4503
4504 035302 104401 001171
4505 035306 010046
4506 035310 005000
4507 035312 153700 001114
4508 035316 001004
4509
4510 035320 013746 001116
4511
4512 035324 104402
4513 035326 000426
4514 035330 005300 1$: DEC R0
4515 035332 006300 ASL R0
4516 035334 006300 ASL R0
4517 035336 006300 ANI R0
4518 035340 062700 001256 ADD #SERRTB,R0 ;;FORM TABLE POINTER
4519 035344 012037 035354 MOV (R0)+,2$ ;;PICKUP 'ERROR MESSAGE' POINTER
4520 035350 001404 BEQ 3$ ;;SKIP TYPEOUT IF NO POINTER
4521 035352 104401 TYPE ;;TYPE THE 'ERROR MESSAGE'
4522 035354 000000 2$: .WORD 0 ;;'ERROR MESSAGE' POINTER GOES HERE
4523 035356 104401 001171 TYPE ,SCLRF ;;'CARRIAGE RETURN' & 'LINE FEED'
4524 035362 012037 035372 3$: MOV (R0)+,4$ ;;PICKUP 'DATA HEADER' POINTER
  
```

.SBTTL ERROR MESSAGE TYPEOUT ROUTINE

\*\*\*\*\*  
 \*THIS ROUTINE USES THE 'ITEM CONTROL BYTE' (\$ITEMB) TO DETERMINE WHICH  
 \*ERROR IS TO BE REPORTED. IT THEN OBTAINS, FROM THE 'ERROR TABLE' (\$ERRTB),  
 \*AND REPORTS THE APPROPRIATE INFORMATION CONCERNING THE ERROR.

```

$ERRTYP:
TYPE ,SCLRF ;;'CARRIAGE RETURN' & 'LINE FEED'
MOV R0,-(SP) ;;SAVE R0
CLR R0 ;;PICKUP THE ITEM INDEX
BISB @#$ITEMB,R0
BNE 1$ ;;IF ITEM NUMBER IS ZERO, JUST
TYPE THE PC OF THE ERROR
MOV $ERRPC,-(SP) ;;SAVE $ERRPC FOR TYPEOUT
ERROR ADDRESS
GO TYPE--OCTAL ASCII(ALL DIGITS)
BR 6$ ;;GET OUT
DEC R0 ;;ADJUST THE INDEX SO THAT IT WILL
ASL R0 ;; WORK FOR THE ERROR TABLE
ASL R0
ANI R0
ADD #SERRTB,R0 ;;FORM TABLE POINTER
MOV (R0)+,2$ ;;PICKUP 'ERROR MESSAGE' POINTER
BEQ 3$ ;;SKIP TYPEOUT IF NO POINTER
TYPE ;;TYPE THE 'ERROR MESSAGE'
WORD 0 ;;'ERROR MESSAGE' POINTER GOES HERE
TYPE ,SCLRF ;;'CARRIAGE RETURN' & 'LINE FEED'
MOV (R0)+,4$ ;;PICKUP 'DATA HEADER' POINTER
  
```

```

4525 035366 001404          BEQ      5$          ::SKIP TYPEOUT IF 0
4526 035370 104401          TYPE          ::TYPE THE 'DATA HEADER'
4527 035372 000000          4$: .WORD 0      ::'DATA HEADER' POINTER GOES HERE
4528 035374 104401 001171  TYPE      ,SCLF    ::'CARRIAGE RETURN' & 'LINE FEED'
4529 035400 011000          5$: MOV      (R0),R0  ::PICKUP 'DATA TABLE' POINTER
4530 035402 001004          BNE      7$          ::GO TYPE THE DATA
4531 035404 012600          6$: MOV      (SP)+,R0  ::RESTORE R0
4532 035406 104401 001171  TYPE      ,SCLF    ::'CARRIAGE RETURN' & 'LINE FEED'
4533 035412 000207          RTS      PC          ::RETURN
4534 035414
4535 035414 013046          MOV      @(R0)+,-(SP)  ::SAVE @(R0)+ FOR TYPEOUT
4536 035416 104402          TYPOC          ::GO TYPE--OCTAL ASCII(ALL DIGITS)
4537 035420 005710          TST      (R0)       ::IS THERE ANOTHER NUMBER?
4538 035422 001770          BEQ      6$          ::BR IF NO
4539 035424 104401 035432  TYPE      ,8$          ::TYPE TWO(2) SPACES
4540 035430 000771          BR      7$          ::LOOP
4541 035432 020040 000      8$: .ASCIZ  / /      ::TWO(2) SPACES
4542 035436          .EVEN
  
```



```

4543          .SBTTL  APT COMMUNICATIONS ROUTINE
4544
4545          :*****
4546 035436 112737 000001 035702 $ATY1:  MOV  #1,$FFLG      ;;TO REPORT FAIAL ERROR
4547 035444 112737 000001 035700 $ATY3:  MOV  #1,$MFLG      ;;TO TYPE A MESSAGE
4548 035452 000403          BR      $ATYC
4549 035454 112737 000001 035702 $ATY4:  MOV  #1,$FFLG      ;;TO ONLY REPORT FATAL ERROR
4550 035462          $ATYC:
4551 035462 010046          MOV  R0,-(SP)      ;;PUSH R0 ON STACK
4552 035464 010146          MOV  R1,-(SP)      ;;PUSH R1 ON STACK
4553 035466 105737 035700          TSTB $MFLG      ;;SHOULD TYPE A MESSAGE?
4554 035472 001450          BEQ  5$          ;;IF NOT: BR
4555 035474 122737 000001 001214          CMPB #APTENV,$ENV      ;;OPERATING UNDER APT?
4556 035502 001031          BNE  3$          ;;IF NOT: BR
4557 035504 132737 000100 001215          BITB #APTSPOOL,$ENVM  ;;SHOULD SPOOL MESSAGES?
4558 035512 001425          BEQ  3$          ;;IF NOT: BR
4559 035514 017600 000004          MOV  @4(SP),R0      ;;GET MESSAGE ADDR.
4560 035520 062766 000002 000004          ADD  #2,4(SP)      ;;BUMP RETURN ADDR.
4561 035526 005737 001174          1$:  TST  $MSGTYPE      ;;SEE IF DONE W/ LAST XMISSION?
4562 035532 001375          BNE  1$          ;;IF NOT: WAIT
4563 035534 010037 001210          MOV  R0,$MSGAD      ;;PUT ADDR IN MAILBOX
4564 035540 105720          2$:  TSTB (R0)+      ;;FIND END OF MESSAGE
4565 035542 001376          BNE  2$
4566 035544 163700 001210          SUB  $MSGAD,R0      ;;SUB START OF MESSAGE
4567 035550 006200          ASR  R0          ;;GET MESSAGE LNGTH IN WORDS
4568 035552 010037 001212          MOV  R0,$MSGGLT      ;;PUT LENGTH IN MAILBOX
4569 035556 012737 000004 001174          MOV  #4,$MSGTYPE      ;;TELL APT TO TAKE MSG.
4570 035564 000413          BR  5$
4571 035566 017637 000004 035612 3$:  MOV  @4(SP),4$      ;;PUT MSG ADDR IN JSR LINKAGE
4572 035574 062766 000002 000004          ADD  #2,4(SP)      ;;BUMP RETURN ADDRESS
4573 035602 013746 177776          MOV  177776,-(SP)  ;;PUSH 177776 ON STACK
4574 035606 004737 034372          JSR  PC,$TYPE      ;;CALL TYPE MACRO
4575 035612 000000          4$:  .WORD  0
4576 035614          5$:
4577 035614 105737 035702          10$: TSTB $FFLG      ;;SHOULD REPORT FATAL ERROR?
4578 035620 001416          BEQ  12$      ;;IF NOT: BR
4579 035622 005737 001214          TST  $ENV      ;;RUNNING UNDER APT?
4580 035626 001413          BEQ  12$      ;;IF NOT: BR
4581 035630 005737 001174          11$: TST  $MSGTYPE      ;;FINISHED LAST MESSAGE?
4582 035634 001375          BNE  11$      ;;IF NOT: WAIT
4583 035636 017637 000004 001176          MOV  @4(SP),$FATAL  ;;GET ERROR #
4584 035644 062766 000002 000004          ADD  #2,4(SP)      ;;BUMP RETURN ADDR.
4585 035652 005237 001174          INC  $MSGTYPE      ;;TELL APT TO TAKE ERROR
4586 035656 105037 035702          12$: CLRB $FFLG      ;;CLEAR FATAL FLAG
4587 035662 105037 035701          CLRB $LFLG      ;;CLEAR LOG FLAG
4588 035666 105037 035700          CLRB $MFLG      ;;CLEAR MESSAGE FLAG
4589 035672 012601          MOV  (SP)+,R1      ;;POP STACK INTO R1
4590 035674 012600          MOV  (SP)+,R0      ;;POP STACK INTO R0
4591 035676 000207          RTS  PC          ;;RETURN
4592 035700          000          $MFLG: .BYTE  0      ;;MESSG. FLAG
4593 035701          000          $LFLG: .BYTE  0      ;;LOG FLAG
4594 035702          000          $FFLG: .BYTE  0      ;;FATAL FLAG
4595          035704          .EVEN
4596          000200          APTSIZE=200

```

```

4597      000001      APTENV=001
4598      000100      APTSPOOL-100
4599      000040      APTCSUP=040
4600      .SBTTL      POWER DOWN AND UP ROUTINES
4601
4602      ::*****
4603      :POWER DOWN ROUTINE
4604 035704 012737 036044 000024 $PWRDN: MOV    #SILLUP,@#PWRVEC  ;;SET FOR FAST UP
4605 035712 012737 000340 000026      MOV    #340,@#PWRVEC+2  ;;PRIO:7
4606 035720 010046      MOV    R0,-(SP)        ;;PUSH R0 ON STACK
4607 035722 010146      MOV    R1,-(SP)        ;;PUSH R1 ON STACK
4608 035724 010246      MOV    R2,-(SP)        ;;PUSH R2 ON STACK
4609 035726 010346      MOV    R3,-(SP)        ;;PUSH R3 ON STACK
4610 035730 010446      MOV    R4,-(SP)        ;;PUSH R4 ON STACK
4611 035732 010546      MOV    R5,-(SP)        ;;PUSH R5 ON STACK
4612 035734 017746 143200      MOV    @SWR,-(SP)      ;;PUSH @SWR ON STACK
4613 035740 010637 036050      MOV    SP,$SAVR6      ;;SAVE SP
4614 035744 012737 035756 000024      MOV    #SPWRUP,@#PWRVEC ;;SET UP VECTOR
4615 035752 000000      HALT
4616 035754 000776      BR     .-2            ;;HANG JP
4617
4618      ::*****
4619      :POWER UP ROUTINE
4620 035756 012737 036044 000024 $PWRUP: MOV    #SILLUP,@#PWRVEC  ;;SET FOR FAST DOWN
4621 035764 013706 036050      MOV    $SAVR6,SP      ;;GET SP
4622 035770 005037 036050      CLR    $SAVR6         ;;WAIT LOOP FOR THE TTY
4623 035774 005237 036050      1$:  INC    $SAVR6     ;;WAIT FOR THE INC
4624 036000 001375      BNE    1$             ;;OF WORD
4625 036002 012677 143132      MOV    (SP)+,@SWR     ;;POP STACK INTO @SWR
4626 036006 012605      MOV    (SP)+,R5      ;;POP STACK INTO R5
4627 036010 012604      MOV    (SP)+,R4      ;;POP STACK INTO R4
4628 036012 012603      MOV    (SP)+,R3      ;;POP STACK INTO R3
4629 036014 012602      MOV    (SP)+,R2      ;;POP STACK INTO R2
4630 036016 012601      MOV    (SP)+,R1      ;;POP STACK INTO R1
4631 036020 012600      MOV    (SP)+,R0      ;;POP STACK INTO R0
4632 036022 012737 035704 000024      MOV    #SPWRDN,@#PWRVEC ;;SET UP THE POWER DOWN VECTOR
4633 036030 012737 000340 000026      MOV    #340,@#PWRVEC+2 ;;PRIO:7
4634 036036 104401      TYPE
4635 036040 036052      $PWRMG: .WORD    $POWER  ;;REPORT THE POWER FAILURE
4636 036042 000002      RTI                ;;POWER FAIL MESSAGE POINTER
4637 036044 000000      $SILLUP: HALT
4638 036046 000776      BR     .-2            ;;THE POWER UP SEQUENCE WAS STARTED
4639 036050 000000      $SAVR6: 0           ;;BEFORE THE POWER DOWN WAS COMPLETE
4640 036052 005015 047520 042527 $POWER: .ASCIZ  <15><12>'POWER'
4641 036060 000122
4642      .EVEN
    
```

```

4643      .SBTTL  ROUTINE TO SIZE MEMORY
4644
4645      ;*****
4646      ;*CALL:
4647      ;*      JSR      PC,$SIZE
4648      ;*      RETURN
4649      ;*$LSTAD WILL CONTAIN:
4650      ;*      WITH KT11 OPTION      -- LAST VIRTUAL ADDRESS OF THE LAST BANK
4651      ;*      WITHOUT KT11 OPTION   -- LAST ABSOLUTE ADDRESS OF AVAILABLE MEMORY
4652      ;*$LSTBK WILL CONTAIN THE LAST BANK AS A SAF
4653      ;*$KT11 IS THE MEMORY MANAGEMENT KEY
4654      ;*BIT07 = 0 DON'T USE MEMORY MANAGEMENT
4655      ;*      MUST BE SETUP BEFORE THE CALL
4656      ;*BIT15 = 0 DON'T HAVE MEMORY MANAGEMENT OPTION
4657      ;*      DETERMINED BY ROUTINE
4658
4659      $SIZE:  MOV     R0,-(SP)      ;;SAVE R0 ON THE STACK
4660      MOV     R1,-(SP)      ;;SAVE R1 ON THE STACK
4661      MOV     R2,-(SP)      ;;SAVE R2 ON THE STACK
4662      MOV     R3,-(SP)      ;;SAVE R3 ON THE STACK
4663      MOV     @#ERRVEC,-(SP)  ;;SAVE PRESENT ERROR VECTOR PS & PC
4664      MOV     @#ERRVEC+2,-(SP)
4665      MOV     SP,R0          ;;SAVE THE STACK POINTER
4666      ;;SET THE ERRVEC PS TO THE PRESENT PS
4667      TRAP
4668      MOV     (SP)+,@#ERRVEC+2  ;;PUSH OLD PSW AND PC ON STACK
4669      MOV     #3776,R1        ;;SAVE THE PSW IN @#ERRVEC+2
4670      TSTB   (PC)+          ;;SETUP ADDRESS
4671      TSTB   (PC)+          ;;USE MEMORY MANAGEMENT?
4672      $KT11: .WORD  200      ;;SET TO USE MEMORY MANAGEMENT
4673      BPL    $SCORE         ;;BR IF NO
4674      MOV     #KTNEX,@#ERRVEC  ;;SET FOR TIMEOUT
4675      TST    @#SRO          ;;KT11 ARE YOU THERE?
4676      BIS    #100000,$KT11    ;;YES--SET KT11 KEY
4677      MOV     #KTERR,@#MMVEC  ;;SET IN CASE OF ERROR
4678      MOV     #340,@#MMVEC+2
4679      CLR    -(SP)         ;;INITIALIZE FOR 'PAR' LOADING
4680      MOV     #KIPAR0,R2      ;;ADDRESS OF FIRST 'PAR'
4681      MOV     #^D8,R3        ;;LOAD EIGHT 'PAR.'S' AND EIGHT 'PDR.'S'
4682      MOV     #77406,-40(R2)  ;;PDR = 4K, UP, READ/WRITE
4683      MOV     (SP),(R2)+     ;;LOAD 'PAR'
4684      ADD    #200,(SP)       ;;UPDATE FOR NEXT 'PAR'
4685      SOB    R3,1$         ;;LOOP UNTIL ALL EIGHT ARE LOADED
4686      MOV     #177600,-(R2)   ;;SETUP KIPAR7 FOR I/O
4687      CLR    -(R2)         ;;SETUP KIPAR6 FOR TESTING
4688      MOV     #2$,@#ERRVEC   ;;CATCH TIMEOUT IF NO SR3
4689      MOV     #20,@#SR3      ;;ENABLE 22 BIT MODE
4690      BR    3$            ;;THIS PDP-11 HAS A SR3 REGISTER
4691      2$:  CMP    (SP)+,(SP)+  ;;CLEAN OFF THE STACK--NO SR3
4692      3$:  INC    @#SRO        ;;TURN ON MEMORY MANAGEMENT
4693      MOV     #KTOUR,@#ERRVEC  ;;SET FOR TIME OUT
4694      4$:  TST    @#143776     ;;TRAP ON NON-EX-MEM
4695      ADD    #40,(R2)        ;;MAKE A 1K STEP
4696      CMP    @#KIPAR7,(R2)    ;;LAST ONE?
4697      BHI    4$            ;;NO--TRY IT
    
```

```

4697 036266 011202          $KTOUT: MOV    (R2),R2          ;;GET LAST BANK+1
4698 036270 005037 177572          CLR    @#SR0          ;;TURN OFF MEMORY MANAGEMENT
4699 036274 000421          BR     $SIZEX
4700 036276 042737 100000 036120 $KTNEX: BIC    #100000,$KT11 ;;KT11 NON-EXISTENT
4701 036304 012737 036334 000004 $CORE:  MOV    # $CROUT,@#ERRVEC ;;SET FOR TIMEOUT
4702 036312 005002          CLR    R2            ;;SET UP BANK
4703 036314 062701 004000          1$:   ADD    #4000,R1    ;;INCREMENT BY 1K
4704 036320 062702 000040          ADD    #40,R2        ;;1K STEP
4705 036324 005711          TST   (R1)          ;;TRAP ON TIME OUT
4706 036326 022701 177776          CMP   #177776,R1    ;;LAST ONE
4707 036332 001370          BNE   1$           ;;NO--TRY AGAIN
4708 036334 162701 004000          $CROUT: SUB   #4000,R1
4709 036340 162702 000040          $SIZEX: SUB   #40,R2    ;;DROP BACK
4710 036344 010006          MOV   R0,SP        ;;RESTORE THE STACK
4711 036346 012637 000006          MOV   (SP)+,@#ERRVEC+2 ;;RESTORE ERROR VECTOR
4712 036352 012637 000004          MOV   (SP)+,@#ERRVEC
4713 036356 010137 036400          MOV   R1,$LSTAD    ;;LAST ADDRESS
4714 036362 010237 036402          MOV   R2,$LSTBK    ;;LAST BANK
4715 036366 012603          MOV   (SP)+,R3     ;;RESTORE R3
4716 036370 012602          MOV   (SP)+,R2     ;;RESTORE R2
4717 036372 012601          MOV   (SP)+,R1     ;;RESTORE R1
4718 036374 012600          MOV   (SP)+,R0     ;;RESTORE R0
4719 036376 000207          RTS   PC
4720 036400 000000          $LSTAD: .WORD 0      ;;CONTAINS THE LAST ADDRESS
4721 036402 000000          $LSTBK: .WORD 0      ;;CONTAINS THE LAST BANK
4722 036404 000000          KTERR: HALT
4723 036406 000776          BR    KTERR
  
```

```

4724          .SBTTL  SAVE AND RESTORE R0-R5 ROUTINES
4725
4726          ;*****
4727          ;*SAVE R0-R5
4728          ;*CALL:
4729          ;*   SAVREG
4730          ;*UPON RETURN FROM $SAVREG THE STACK WILL LOOK LIKE:
4731          ;*
4732          ;*TOP---(+16)
4733          ;* +2---(+18)
4734          ;* +4---R5
4735          ;* +6---R4
4736          ;* +8---R3
4737          ;*+10---R2
4738          ;*+12---R1
4739          ;*+14---R0
4740
4741          $SAVREG:
4742          036410 010046      MOV     R0,-(SP)      ;;PUSH R0 ON STACK
4743          036412 010146      MOV     R1,-(SP)      ;;PUSH R1 ON STACK
4744          036414 010246      MOV     R2,-(SP)      ;;PUSH R2 ON STACK
4745          036416 010346      MOV     R3,-(SP)      ;;PUSH R3 ON STACK
4746          036420 010446      MOV     R4,-(SP)      ;;PUSH R4 ON STACK
4747          036422 010546      MOV     R5,-(SP)      ;;PUSH R5 ON STACK
4748          036424 016646 000022  MOV     22(SP),-(SP)  ;;SAVE PS OF MAIN FLOW
4749          036430 016646 000022  MOV     22(SP),-(SP)  ;;SAVE PC OF MAIN FLOW
4750          036434 016646 000022  MOV     22(SP),-(SP)  ;;SAVE PS OF CALL
4751          036440 016646 000022  MOV     22(SP),-(SP)  ;;SAVE PC OF CALL
4752          036444 000002      RTI
4753
4754          ;*RESTORE R0-R5
4755          ;*CALL:
4756          ;*   RESREG
4757          $RESREG:
4758          036446 012666 000022  MOV     (SP)+,22(SP)  ;;RESTORE PC OF CALL
4759          036452 012666 000022  MOV     (SP)+,22(SP)  ;;RESTORE PS OF CALL
4760          036456 012666 000022  MOV     (SP)+,22(SP)  ;;RESTORE PC OF MAIN FLOW
4761          036462 012666 000022  MOV     (SP)+,22(SP)  ;;RESTORE PS OF MAIN FLOW
4762          036466 012605      MOV     (SP)+,R5      ;;POP STACK INTO R5
4763          036470 012604      MOV     (SP)+,R4      ;;POP STACK INTO R4
4764          036472 012603      MOV     (SP)+,R3      ;;POP STACK INTO R3
4765          036474 012602      MOV     (SP)+,R2      ;;POP STACK INTO R2
4766          036476 012601      MOV     (SP)+,R1      ;;POP STACK INTO R1
4767          036500 012600      MOV     (SP)+,R0      ;;POP STACK INTO R0
4768          036502 000002      RTI

```

```

4769          .SBTTL  INTEGER MULTIPLY ROUTINE
4770
4771          :*****
4772          :*CALL
4773          :*   MOV    MULTIPLER,-(SP)
4774          :*   MOV    MULTIPLICAND,-(SP)
4775          :*   JSR    PC,@$MULT
4776          :*   RETURN ;:PRODUCT IS ON THE STACK
4777          :*
4778          :*   STACK  PRODUCT
4779          :*   -----
4780          :*   TOP    LSB'S
4781          :*   +2     MSB'S
4782
4783          $MULT:
4784          036504 010046      MOV    R0,-(SP)      ;:PUSH R0 ON STACK
4785          036506 010146      MOV    R1,-(SP)      ;:PUSH R1 ON STACK
4786          036510 010246      MOV    R2,-(SP)      ;:PUSH R2 ON STACK
4787          036512 005046      CLR    -(SP)         ;:CLEAR THE SIGN KEY
4788          036514 016601 000012  MOV    12(SP),R1     ;:GET THE MULTIPLICAND
4789          036520 100002      BPL    1$           ;:BR IF PLUS
4790          036522 005216      INC    (SP)         ;:SET THE SIGN KEY
4791          036524 005401      NEG    R1           ;:MAKE THE MULTIPLICAND POSTIVE
4792          036526 016602 000014  1$:  MOV    14(SP),R2     ;:GET THE MULTIPLIER
4793          036532 100002      BPL    2$           ;:BR IF PLUS
4794          036534 005316      DEC    (SP)         ;:UPDATE THE SIGN KEY
4795          036536 005402      NEG    R2           ;:MAKE THE MULTIPLIER POSTIVE
4796          036540 012746 000021  2$:  MOV    #17,-(SP)    ;:SET THE LOOP COUNT
4797          036544 005000      CLR    R0           ;:SETUP FOR THE MULTIPLY LOOP
4798          036546 103001  3$:  BCC    4$           ;:DON'T ADD IF MULTIPLICAND = 0
4799          036550 060200      ADD    R2,R0
4800          036552 006000  4$:  ROR    R0           ;:POSITION THE PARITIAL PRODUCT AND
4801          036554 006001      ROR    R1           ;:THE MULTIPLICAND
4802          036556 005316      DEC    (SP)         ;:HAS ALL BITS OF THE MULTIPLICAND BEEN DONE?
4803          036560 001372      BNE    3$           ;:BR IF NO
4804          036562 022616      CMP    (SP)+,(SP)   ;:SHOULD PRODUCT BE NEGATIVE?
4805          036564 001403      BEQ    5$           ;:GO TO EXIT IF NO
4806          036566 005400      NEG    R0           ;:YES--SO MAKE IT SO
4807          036570 005401      NEG    R1
4808          036572 005600      SBC    R0
4809          036574 005726  5$:  TST    (SP)+        ;:CLEAR SIGN INFO. OFF OF STACK
4810          036576 010066 000012  MOV    R0,12(SP)    ;:PUT THE PRODUCT ON THE STACK (MSB'S)
4811          036602 010166 000010  MOV    R1,10(SP)    ;:LSB'S
4812          036606 012602      MOV    (SP)+,R2     ;:POP STACK INTO R2
4813          036610 012601      MOV    (SP)+,R1     ;:POP STACK INTO R1
4814          036612 012600      MOV    (SP)+,R0     ;:POP STACK INTO R0
4815          036614 000207      RTS    PC
  
```

```

4816
4817
4818
4819
4820
4821
4822
4823
4824
4825
4826
4827
4828
4829
4830
4831
4832
4833
4834
4835
4836
4837
4838
4839
4840
4841 036616
4842 036616 104400
4843 036620 042716 000017
4844 036624 010046
4845 036626 010146
4846 036630 010246
4847 036632 010346
4848 036634 005046
4849 036636 012746 000021
4850 036642 016601 000024
4851 036646 016600 000022
4852 036652 100005
4853 036654 105366 000003
4854 036660 005400
4855 036662 005401
4856 036664 005600
4857 036666 016602 000020
4858 036672 002407
4859 036674 003011
4860 036676 052766 000003 000014
4861 036704 012700 177777
4862 036710 000424
4863 036712 005266 000002
4864 036716 000401
4865 036720 005402
4866 036722 000241
4867 036724 000405
4868 036726 006100
4869 036730 010003
    
```

.SBTTL INTEGER DIVIDE ROUTINE

```

*****
*THIS ROUTINE WILL DIVIDE A 32-BIT TWO'S COMPLEMENT INTEGER
*DIVIDEND BY A 16-BIT TWO'S COMPLEMENT INTEGER DIVISOR GIVING
*A 16-BIT TWO'S COMPLEMENT INTEGER QUOTIENT AND A 16-BIT REMAINDER.
*DIVISION WILL BE PERFORMED SO THAT THE REMAINDER IS OF THE
*SAVE SIGN AS THE DIVIDEND.
*CALL:
*   MOV     LOW DIVIDEND,-(SP) ;;THE HIGH DIVIDEND MUST BE < 1/2
*   MOV     HIGH DIVIDEND,-(SP); AS LARGE AS THE DIVISOR
*   MOV     DIVISOR,-(SP)
*   JSR     PC,$DIV
*   RETURN                                ;;QUOTIENT & REMAINDER ARE ON THE STACK
*   'V' 0  IMPLIES NO ERROR
*   'V' 1  IMPLIES ERROR OCCURRED
*   'C' 0  DIVIDE OVERFLOW OCCURRED
*   'C' 1  ATTEMPTED TO DIVIDE BY ZERO

*   STACK NO ERROR OVERFLOW DIVIDE BY ZERO
*   -----
*   TOP    REMAINDER ALL ZEROS ALL ONES
*   +2     QUOTIENT  ALL ZEROS ALL ONES
    
```

```

$DIV:
TRAP                                ;;PUSH OLD PSW AND PC ON STACK
BIC #17,(SP)                        ;;STRIP AWAY CONDITION CODES
MOV R0,-(SP)                        ;;PUSH R0 ON STACK
MOV R1,-(SP)                        ;;PUSH R1 ON STACK
MOV R2,-(SP)                        ;;PUSH R2 ON STACK
MOV R3,-(SP)                        ;;PUSH R3 ON STACK
CLR -(SP)                          ;;SAVE A PLACE FOR SIGNS
MOV #17,-(SP)                      ;;SETUP THE ITERATION COUNTER
MOV 24(SP),R1                      ;;PICKUP THE DIVIDEND
MOV 22(SP),R0
BPL 1$                              ;;CHECK THE SIGN
DECB 3(SP)                          ;;KEEP TRACK OF THE SIGN
NEG R0                              ;;AND NEGATE THE ORIGINAL
NEG R1                              ;;NUMBER
SBC R0
1$: MOV 20(SP),R2                    ;;PICKUP THE DIVISOR
BLT 2$                              ;;CHECK THE SIGN
BGT 3$                              ;;DIVISOR OF 0 IS A NO-NO
BIS #3,14(SP)                      ;;SET 'V' & 'C'
MOV #-1,R0                          ;;SET REMAINDER TO ALL ONES
BR 7$                               ;;EXIT
2$: INC 2(SP)                       ;;KEEP TRACK OF DIVISORS SIGN
BR 4$
3$: NEG R2                          ;;NEGATE THE ORIGINAL NUMBER
4$: CLC                              ;;CLEAR 'C'
BR 6$                               ;;START FORMING QUOTIENT
5$: ROL R0                          ;;POSITION MSB'S
MOV R0,R3                          ;;COPY
    
```

4870	036732	060203			ADD	R2,R3	::COMPARE DIVIDEND & DIVISOR
4871	036734	103001			BCC	6\$	::BR IF DIVIDEND > DIVISOR
4872	036736	010300			MOV	R3,R0	::REMAINDER AFTER THIS LOOP
4873	036740	006101		6\$:	ROL	R1	::QUOTIENT BIT ENTERS HERE
4874	036742	005316			DEC	(SP)	::DONE?
4875	036744	001370			BNE	5\$	::BR IF NO
4876	036746	005701			TST	R1	::OVERFLOW?
4877	036750	100005			BPL	8\$	::BR IF NO
4878	036752	052766	000002	000014	BIS	#2,14(SP)	::SET 'V' IN RETURN STATUS WORD
4879	036760	005000			CLR	R0	::SET REMAINDER TO ALL ZEROS
4880	036762	010001		7\$:	MOV	R0,R1	::COPY REMAINDER INTO QUOTIENT
4881	036764	005726		8\$:	TST	(SP)+	::CLEAR COUNTER FROM STACK
4882	036766	005716			TST	(SP)	::REMAINDER SIGN CORRECTION NEEDED?
4883	036770	002004			BGE	9\$	::BR IF NO
4884	036772	005400			NEG	R0	::NEGATE REMAINDER
4885	036774	105066	000001		CLRB	1(SP)	::CLEAR SIGN
4886	037000	005316			DEC	(SP)	::BUT DON'T FORGET QUOTIENT
4887	037002	005726		9\$:	TST	(SP)+	::QUOTIENT SIGN CORRECTION NEEDED?
4888	037004	001401			BEQ	10\$	::BR IF NO
4889	037006	005401			NEG	R1	::NEGATE QUOTIENT
4890	037010	010166	000020	10\$:	MOV	R1,20(SP)	::RETURN QUOTIENT AND
4891	037014	010066	000016		MOV	R0,16(SP)	::REMAINDER TO USER
4892	037020	012603			MOV	(SP)+,R3	::POP STACK INTO R3
4893	037022	012602			MOV	(SP)+,R2	::POP STACK INTO R2
4894	037024	012601			MOV	(SP)+,R1	::POP STACK INTO R1
4895	037026	012600			MOV	(SP)+,R0	::POP STACK INTO R0
4896	037030	012666	000002		MOV	(SP)+,2(SP)	::SETUP TO RETURN CONDITION CODES
4897	037034	000002			RTI		::RETURN



4898  
4899  
4900  
4901  
4902  
4903  
4904  
4905  
4906  
4907  
4908  
4909  
4910  
4911  
4912  
4913  
4914  
4915  
4916  
4917  
4918  
4919  
4920  
4921  
4922  
4923  
4924  
4925  
4926  
4927  
4928  
4929  
4930  
4931  
4932  
4933  
4934  
4935  
4936  
4937  
4938  
4939  
4940  
4941  
4942  
4943  
4944  
4945  
4946  
4947  
4948  
4949  
4950  
4951

037036 104413  
037040 016602 000002  
037044 012700 037216  
037050 010066 000002  
037054 012201  
037056 012202  
037060 012737 000012 037134  
037066 012704 037146  
037072 012705 037150  
037076 005003  
037100 161401  
037102 005602  
037104 161502  
037106 002402  
037110 005203  
037112 000772  
037114 062401  
037116 005502  
037120 062402  
037122 022525  
037124 052703 000060  
037130 110320  
037132 005327  
037134 000000  
037136 001357  
037140 105020  
037142 104414  
037144 000207  
037146 145000  
037150 035632  
037152 160400  
037154 002765  
037156 113200  
037160 000230  
037162 041100  
037164 000017  
037166 103240  
037170 000001  
037172 023420  
037174 000000  
037176 001750

```

.SBTTL DOUBLE LENGTH BINARY TO DECIMAL ASCII CONVERT ROUTINE
:*****
:*THIS ROUTINE WILL CONVERT A 32-BIT BINARY NUMBER TO AN UNSIGNED
:*DECIMAL (ASCII) NUMBER. THE SIGN OF THE BINARY NUMBER MUST BE
:*POSITIVE.
:*CALL
:*      MOV      #PNTR,-(SP)      ;; POINTER TO LOW WORD OF BINARY NUMBER
:*      JSR      PC,@#$DB2D      ;; THE FIRST ADDRESS OF ASCII
:*      RETURN                      ;; IS ON THE STACK
$DB2D: SAVREG                      ;; SAVE REGISTERS
      MOV      2(SP),R2           ;; PICKUP THE DATA POINTER
      MOV      #$DECVL,R0        ;; GET ADDRESS OF '$DECVL' STRING
      MOV      R0,2(SP)          ;; PUT ADDRESS OF ASCII STRING ON STACK
      MOV      (R2)+,R1          ;; PICKUP THE BINARY NUMBER
      MOV      (R2)+,R2
      MOV      #10,,4$           ;; SET UP TO DO 10 CONVERSIONS
      MOV      #$TNPWR,R4        ;; ADDRESS OF TEN POWER
      MOV      #$TNPWR+2,R5
1$: CLR      R3                  ;; CLEAR PARTIAL
2$: SUB      (R4),R1             ;; SUBTRACT TEN POWER
   SBC      R2
   SUB      (R5),R2
   BLT      3$                  ;; BR IF TEN POWER TOO LARGE
   INC      R3                  ;; ADD 1 TO PARTIAL
   BR      2$                   ;; LOOP
3$: ADD      (R4)+,R1           ;; RESTORE SUBTRACTED VALUE
   ADC      R2
   ADD      (R4)+,R2
   CMP      (R5)+,(R5)+        ;; MOVE TO NEXT TEN POWER
   BIS      #'0,R3             ;; CHANGE PARTIAL TO ASCII
   MOVB     R3,(R0)+           ;; SAVE IT
   DEC      (PC)+              ;; DONE?
4$: .WORD    0
   BNE     1$                  ;; BR IF NO
   CLRB    (R0)+              ;; TERMINATOR
   RESREG                      ;; RESTORE REGISTERS
   RTS     PC                  ;; RETURN
$TNPWR: 145000                 ;; 1.0E09
        35632
        160400                 ;; 1.0E08
        2765
        113200                 ;; 1.0E07
        230
        041100                 ;; 1.0E06
        17
        103240                 ;; 1.0E05
        1
        23420                  ;; 1.0E04
        0
        1750                   ;; 1.0E03

```

4952 037200 000000  
4953 037202 000144  
4954 037204 000000  
4955 037206 000012  
4956 037210 000000  
4957 037212 000001  
4958 037214 000000  
4959 037216 000014

0  
144            :::1.0E02  
0  
12             :::1.0E01  
0  
1              :::1.0E00  
0

\$DECVL: .BLKB 12.            :::RESERVE STORAGE FOR ASCIZ STRING  
.SBTTL SINGLE LENGTH BINARY TO DECIMAL ASCII ROUTINE

4960  
4961  
4962  
4963  
4964  
4965  
4966  
4967  
4968  
4969  
4970

:::\*\*\*\*\*  
:::THIS ROUTINE WILL CONVERT A 16-BIT UNSIGNED BINARY NUMBER TO AN  
:::UNSIGNED DECIMAL ASCII NUMBER.  
:::CALL  
:::    MOV     NUMBER,-(SP)        :::PUT BINARY NUMBER ON THE STACK  
:::    JSR     PC,@#SSB2D         :::CALL  
:::    RETURN                    :::ADDRESS OF THE 1ST ASCII CHAR.IS ON THE STACK

4971 037232 016637 000002 037262  
4972 037240 012746 037262  
4973 037244 004737 037036  
4974 037250 062716 000005  
4975 037254 012666 000002  
4976 037260 000207  
4977 037262 000000 000000

\$SB2D: MOV     2(SP),1\$         :::SAVE BINARY NUMBER  
      MOV     #1\$,-(SP)        :::SET POINTER  
      JSR     PC,@#SSB2D       :::CALL DOUBLE LENGTH CONVERT  
      ADD     #5,(SP)          :::ONLY ALLOW FIVE CHARACTERS  
      MOV     (SP)+,2(SP)       :::PICKUP POINTER  
      RTS     PC                :::RETURN  
1\$:    .WORD  0,0

4978  
4979  
4980  
4981  
4982  
4983  
4984  
4985  
4986 037266 010046  
4987 037270 016600 000002  
4988 037274 005740  
4989 037276 111000  
4990 037300 006300  
4991 037302 016000 037322  
4992 037306 000200  
4993  
4994  
4995  
4996  
4997 037310 011646  
4998 037312 016666 000004 000002  
4999 037320 000002  
5000  
5001  
5002  
5003  
5004  
5005  
5006  
5007  
5008 037322 037310  
5009 037324 034372  
5010 037326 034700  
5011 037330 034654  
5012 037332 034714  
5013 037334 033662  
5014  
5015 037336 033054  
5016  
5017 037340 033004  
5018 037342 033266  
5019 037344 033406  
5020 037346 033560  
5021 037350 036410  
5022 037352 036446  
5023

.SBTTL TRAP DECODER

```

*****
*THIS ROUTINE WILL PICKUP THE LOWER BYTE OF THE 'TRAP' INSTRUCTION
*AND USE IT TO INDEX THROUGH THE TRAP TABLE FOR THE STARTING ADDRESS
*OF THE DESIRED ROUTINE. THEN USING THE ADDRESS OBTAINED IT WILL
*GO TO THAT ROUTINE.

```

```

$TRAP:  MOV    R0,-(SP)      ;;SAVE R0
        MOV    2(SP),R0     ;;GET TRAP ADDRESS
        TST   -(R0)        ;;BACKUP BY 2
        MCVB  (R0),R0      ;;GET RIGHT BYTE OF TRAP
        ASL   R0           ;;POSITION FOR INDEXING
        MOV   $TRPAD(R0),R0 ;;INDEX TO TABLE
        RTS   R0           ;;GO TO ROUTINE

```

;;THIS IS USE TO HANDLE THE 'GETPRI' MACRO

```

$TRAP2: MOV   (SP),-(SP)    ;;MOVE THE PC DOWN
        MOV   4(SP),2(SP)  ;;MOVE THE PSW DOWN
        RTI                    ;;RESTORE THE PSW

```

.SBTTL TRAP TABLE

```

*THIS TABLE CONTAINS THE STARTING ADDRESSES OF THE ROUTINES CALLED
*BY THE 'TRAP' INSTRUCTION.

```

```

:      ROUTINE
:      -----
$TRPAD: .WORD  $TRAP2
        $TYPE  ;;CALL=TYPE      TRAP+1(104401)  TTY TYPEOUT ROUTINE
        $TYPOC ;;CALL=TYPOC    TRAP+2(104402)  TYPE OCTAL NUMBER (WITH LEADING ZEROS)
        $TYPOS ;;CALL=TYPOS    TRAP+3(104403)  TYPE OCTAL NUMBER (NO LEADING ZEROS)
        $TYPON ;;CALL=TYPON    TRAP+4(104404)  TYPE OCTAL NUMBER (AS PER LAST CALL)
        $TYPDS ;;CALL=TYPDS    TRAP+5(104405)  TYPE DECIMAL NUMBER (WITH SIGN)
        $GTSWR ;;CALL=GTSWR    TRAP+6(104406)  GET SOFT-SWR SETTING
        $CKSWR ;;CALL=CKSWR    TRAP+7(104407)  TEST FOR CHANGE IN SOFT-SWR
        $RDCHR ;;CALL=RDCHR    TRAP+10(104410) TTY TYPEIN CHARACTER ROUTINE
        $RDLIN ;;CALL=RDLIN   TRAP+11(104411) TTY TYPEIN STRING ROUTINE
        $RDOCT ;;CALL=RDOCT   TRAP+12(104412) READ AN OCTAL NUMBER FROM TTY
        $SAVREG ;;CALL=SAVREG  TRAP+13(104413) SAVE R0-R5 ROUTINE
        $RESREG ;;CALL=RESREG  TRAP+14(104414) RESTORE R0-R5 ROUTINE

```

```

5024 .SBTTL A TO D FIELD SITE AND ADJUSTMENT LOOP
5025 037354 004737 046042 FSITE: JSR PC,CTRLCG ;TEST FOR CTRL C OR G
5026 :CAMERA #0
5027 037360 032777 000100 141552 BIT #SW06,@SWR ;TEST IF CAM 0 G=1
5028 037366 001004 BNE 1$
5029 037370 004537 040102 JSR R5,CONVRT ;CONVERT
5030 037374 000000 0 ;CAMERA 0
5031 037376 040474 CAMOG1 ;STORE RESULTS
5032 037400 032777 000001 141532 1$: BIT #SW00,@SWR ;TEST IF CAM 0 G=2
5033 037406 001004 BNE 2$
5034 037410 004537 040102 JSR R5,CONVRT ;CONVERT
5035 037414 002000 BIT10 ;GAIN = 2
5036 037416 040476 CAMOG2
5037 :CAMERA #1
5038 037420 032777 000200 141512 2$: BIT #SW7,@SWR ;TEST IF CAM 1 G=1
5039 037426 001004 BNE 3$
5040 037430 004537 040102 JSR R5,CONVRT ;CONVERT
5041 037434 000400 BIT8 ;CAMERA 1
5042 037436 040500 CAM1G1 ;STORE RESULTS
5043 037440 032777 000002 141472 3$: BIT #SW01,@SWR ;TEST IF CAM 1 G=2
5044 037446 001004 BNE 4$
5045 037450 004537 040102 JSR R5,CONVRT ;CONVERT
5046 037454 002400 BIT10!BIT8 ;CAMERA 1 GAIN - 2
5047 037456 040502 CAM1G2 ;RESULTS
5048 :CAMERA #2
5049 037460 032777 000400 141452 4$: BIT #SW8,@SWR ;TEST IF CAM 2 G=1
5050 037466 001004 BNE 5$
5051 037470 004537 040102 JSR R5,CONVRT ;CONVERT
5052 037474 001000 BIT9 ;CAMERA #2
5053 037476 040504 CAM2G1 ;RESULTS
5054 037500 032777 000004 141432 5$: BIT #SW2,@SWR ;TEST IF CAM 2 G=2
5055 037506 001004 BNE 6$
5056 037510 004537 040102 JSR R5,CONVRT ;CONVERT
5057 037514 003000 BIT10.BIT9 ;GAIN - 2
5058 037516 040506 CAM2G2 ;RESULTS
5059 :CAMERA #3
5060 037520 032777 001000 141412 6$: BIT #SW9,@SWR ;TEST IF CAM 3 G=1
5061 037526 001004 BNE 7$
5062 037530 004537 040102 JSR R5,CONVRT ;CONVERT
5063 037534 001400 BIT9!BIT8 ;CAMERA #3
5064 037536 040510 CAM3G1 ;RESULTS
5065 037540 032777 000010 141372 7$: BIT #SW3,@SWR ;TEST IF CAM 3 G=2
5066 037546 001004 BNE 10$
5067 037550 004537 040102 JSR R5,CONVRT ;CONVERT
5068 037554 003400 BIT10.BIT9!BIT8 ;GAIN = 2
5069 037556 040512 CAM3G2 ;RESULTS
5070 :JOYSTICK
5071 037560 032777 000020 141352 10$: BIT #SW4,@SWR ;TEST IF JOYSTICK
5072 037566 001011 BNE CALRPT
5073 037570 052777 000001 142160 BIS #BIT0,@SFR ;ASK FOR JOYSTICK
5074 037576 105777 142154 11$: TSTB @SFR ;WAIT FOR JOY DONE
5075 037602 100375 BPL 11$
5076 037604 017737 142152 040514 MOV @JOY,JOYG1 ;SAVE THE RESULT
  
```

```

5077 ;NOW TEST IS TYPEOUT IS ENABLED
5078
5079 037612 004537 040060 CALRPT: JSR R5,CKTSWR ;TEST BIT 6
5080 037616 000100 BIT6
5081 037620 000405 BR 1$ ;BR IF SET
5082 037622 104401 040516 TYPE, CAM0TX ;REPORT CAMERA #0
5083 037626 004537 040412 JSR R5,CAMUNP ;REPORT VALUES
5084 037632 040474 CAM0G1
5085 037634 004537 040060 1$: JSR R5,CKTSWR ;TEST BIT 0
5086 037640 000001 BIT0
5087 037642 000405 BR 2$
5088 037644 104401 040535 TYPE, CAM0TW ;REPORT G-2
5089 037650 004537 040412 JSR R5,CAMUNP
5090 037654 040476 CAM0G2
5091
5092 037656 004537 040060 2$: JSR R5,CKTSWR ;TEST BIT 7
5093 037662 000200 BIT7
5094 037664 000405 BR 3$ ;BR IF SET
5095 037666 104401 040554 TYPE, CAM1TX ;REPORT CAMERA #1
5096 037672 004537 040412 JSR R5,CAMUNP ;REPORT VALUES
5097 037676 040500 CAM1G1
5098 037700 004537 040060 3$: JSR R5,CKTSWR ;TEST BIT 1
5099 037704 000002 BIT1
5100 037706 000405 BR 4$
5101 037710 104401 040573 TYPE, CAM1TW ;REPORT CAM 1 G=2
5102 037714 004537 040412 JSR R5,CAMUNP
5103 037720 040502 CAM1G2
5104
5105 037722 004537 040060 4$: JSR R5,CKTSWR ;TEST BIT 8
5106 037726 000400 BIT8
5107 037730 000405 BR 5$ ;BR IF SET
5108 037732 104401 040612 TYPE, CAM2TX ;REPORT CAMERA #2
5109 037736 004537 040412 JSR R5,CAMUNP ;REPORT VALUES
5110 037742 040504 CAM2G1
5111 037744 004537 040060 5$: JSR R5,CKTSWR ;TEST BIT 2
5112 037750 000004 BIT2
5113 037752 000405 BR 6$
5114 037754 104401 040631 TYPE, CAM2TW ;REPORT CAMERA #2 G=2
5115 037760 004537 040412 JSR R5,CAMUNP
5116 037764 040506 CAM2G2
5117
5118 037766 004537 040060 6$: JSR R5,CKTSWR ;TEST BIT 9
5119 037772 001000 BIT9
5120 037774 000405 BR 7$ ;BR IF SET
5121 037776 104401 040650 TYPE, CAM3TX ;REPORT CAMERA #3
5122 040002 004537 040412 JSR R5,CAMUNP ;REPORT VLAUES
5123 040006 040510 CAM3G1
5124 040010 004537 040060 7$: JSR R5,CKTSWR ;TEST BIT 3
5125 040014 000010 BIT3
5126 040016 000405 BR 10$
5127 040020 104401 040667 TYPE, CAM3TW ;REPORT CAMERA #3 G-2
5128 040024 004537 040412 JSR R5,CAMUNP
5129 040030 040512 CAM3G2
5130
  
```

```
5131 040032 004537 040060      10$: JSR R5,CKTSWR      ;TEST BIT 4
5132 040036 000020                BIT4
5133 040040 000405                BR 11$
5134 040042 104401 040706        TYPE, JOYTW
5135 040046 004537 040412        JSR R5,CAMUNP      ;REPORT JOYSTICK
5136 040052 040514                JOYG1
5137 040054 000137 037354      11$: JMP FSITE
5138
5139 040060 032577 141054        CKTSWR: BIT (R5)+,@SWR      ;TEST IF INHIBIT THIS CAMERA
5140 040064 001005                BNE 1$              ;BR IF YES
5141 040066 032777 020000 141044 BIT #SW13,@SWR      ;TEST INHIBIT TYPE-OUT
5142 040074 001001                BNE 1$              ;BR IF YES
5143 040076 005725                TST (R5)+           ;BUMP EXIT POINTER
5144 040100 000205      1$: RTS R5           ;EXIT
```

```

5145 ;SUBROUTINE TO TAKE 8 CONVERSIONS AND AVERAGE FOUR OF THEM
5146 040102 012537 040406 CONVRT: MOV (R5)+,1$ ;SAVE CAMERA CHANNEL
5147 040106 012777 004000 141642 4$: MOV #CLRALL,@SFR ;CLEAR THE DEVICE
5148 040114 013777 040406 141624 MOV 11$,@CSR ;SELECT CAMERA AND GAIN
5149 040122 012777 060000 141624 MOV #BUFO,@BAR ;LOAD BUS ADDRESS
5150 040130 012777 177770 141614 MOV #-10,@WCR ;LOAD WORD COUNT
5151 040136 000240 NOP
5152 040140 000240 NOP
5153 040142 000240 NOP
5154 040144 000240 NOP
5155 040146 013777 040410 141602 MOV INOUTZ,@SFR ;SET Z INPUTS IF ENABLED
5156 040154 000240 NOP
5157 040156 000240 NOP
5158 040160 012700 000004 MOV #4.,R0 ;LOAD COUNTER
5159 040164 005001 CLR R1 ;FOR OUT OF RANGE VOLTAGE
5160 040166 000240 NOP
5161 040170 052777 000001 141550 BIS #BIT0,@CSR ;ENABLE THE DEVICE
5162 040176 105777 141544 1$: TSTB @CSR ;WAIT FOR IDLE
5163 040202 100430 BMI 3$
5164 040204 005301 DEC R1 ;DELAY
5165 040206 001373 BNE 1$
5166 040210 004737 046042 JSR PC,CTRLCG ;TEST FOR CTRL G OR C
5167 040214 005300 DEC R0 ;FINISHED OUT OF RANGE TIMER
5168 040216 001367 BNE 1$
5169 040220 032777 020000 140712 BIT #SW13,@SWR ;TEST IF INHIBIT TYPEOUT
5170 040226 001010 BNE 5$ ;BR IF INHIBIT
5171 040230 113700 040407 MOVB 11$+1,R0 ;GET CAMERA #
5172 040234 062700 000060 ADD #60,R0 ;MAKE INTO ASCII
5173 040240 110037 032714 MOVB R0,OUTCHN ;INSERT INTO ASCII ERROR MESSAGE
5174 040244 104401 032621 TYPE, OUTRNG ;TELL OPERATOR
5175 040250 032777 100000 140662 5$: BIT #SW15,@SWR ;TEST IF HALT ON NO CONVERSION ERROR
5176 040256 001401 BEQ 6$ ;BR IF CLEARED
5177 040260 000000 HALT ;NO CONVERT FLAG - INPUT VOLTAGE WAS OUT OF RANGE OR NO 'Z' PULSES
5178 040262 000711 BR 4$
5179 040264 012700 060000 3$: MOV #BUFO,R0 ;LOAD POINTER
5180 040270 005003 CLR R3 ;CLEAR RESULT
5181 040272 005004 CLR R4
5182 040274 012737 000004 040404 MOV #4,10$ ;LOAD COUNTER
5183 040302 112002 2$: MOVB (R0)+,R2 ;GET LOW BYTE
5184 040304 112001 MOVB (R0)+,R1 ;GET HIGH BYTE
5185 040306 042702 177400 BIC #177400,R2
5186 040312 042701 177400 BIC #177400,R1
5187 040316 060104 ADD R1,R4 ;UPDATE RESULT
5188 040320 060203 ADD R2,R3 ;UPDATE RESULT
5189 040322 005337 040404 DEC 10$ ;FINISHED ?
5190 040326 001365 BNE 2$
5191 040330 006203 ASR R3
5192 040332 006203 ASR R3
5193 040334 000240 NOP
5194 040336 000240 NOP
5195 040340 006204 ASR R4
5196 040342 006204 ASR R4
5197 040344 000240 NOP
5198 040346 000240 NOP

```

```

5199 040350 000240      NOP
5200 040352 010437 040404  MOV      R4,10$      ;SAVE IT
5201 040356 105037 040405  CLR      10$+1      ;CLEAR HIGH BYTE
5202 040362 110337 040405  MOV      R3,10$+1   ;LOAD HIGH BYTE
5203 040366 013735 040404  MOV      10$,@(R5)+ ;SAVE THE RESULT
5204 040372 000240      NOP
5205 040374 000240      NOP
5206 040376 000240      NOP
5207 040400 000240      NOP
5208 040402 000205      RTS      R5
5209 040404 000000      10$: 0
5210 040406 000000      11$: 0
5211 040410 000002      INOUTZ: TESTZ      ;0= USE CUSTOMER Z PULSES, 1= MAINT Z PULSES
5212
5213      ;SUBROUTINE TO TYPE THE CAMERA MESSAGE
5214 040412 013537 040470 040472 CAMUNP: MOV      @(R5)+,10$      ;GET RESULT
5215 040416 113737 040471 040472 MOV      10$+1,11$
5216 040424 105037 040471 040472 CLR      10$+1
5217 040430 105037 040473 040472 CLR      11$+1
5218 040434 013746 040470 040472 MOV      10$,-(SP)
5219 040440 104403
5220 040442 003 001      .BYTE 3,1      ;TYPE 3 DIGIT NUMBER
5221 040444 104401 040724 040724 TYPE, G1B      ;AND TRALING ASCII
5222 040450 013746 040472 040472 MOV      11$,-(SP)
5223 040454 104403
5224 040456 003 001      .BYTE 3,1      ;TYPE 3 DIGIT NUMBER
5225 040460 000240      NOP
5226 040462 000240      NOP
5227 040464 000240      NOP
5228 040466 000205      RTS      R5      ;EXIT
5229 040470 000000      10$: 0
5230 040472 000000      11$: 0
5231 040474 000000      CAM0G1: 0
5232 040476 000000      CAM0G2: 0
5233 040500 000000      CAM1G1: 0
5234 040502 000000      CAM1G2: 0
5235 040504 000000      CAM2G1: 0
5236 040506 000000      CAM2G2: 0
5237 040510 000000      CAM3G1: 0
5238 040512 000000      CAM3G2: 0
5239 040514 000000      JOYG1: 0
5240
5241 040516 015 012      CAM0TX: .BYTE 15,12
5242 040520 040503 030115 020060 .ASCIZ /CAM00 G=1 X=/
5243 040526 036507 020061 036530
5244 040534 000
5245 040535 015 012      CAM0TW: .BYTE 15,12
5246 040537 103 046501 030060 .ASCIZ /CAM00 G=2 X=/
5247 040544 043440 031075 054040
5248 040552 000075
5249 040554 015 012      CAM1TX: .BYTE 15,12
5250 040556 040503 030115 020061 .ASCIZ /CAM01 G=1 X=/
5251 040564 036507 020061 036530
5252 040572 000
  
```



5253	040573	015	012			CAM1TW: .BYTE 15,12
5254	040575	103	046501	030460		.ASCIZ /CAM01 G=2 X-/
5255	040602	043440	031075	054040		
5256	040610	000075				
5257	040612	015	012			CAM2TX: .BYTE 15,12
5258	040614	040503	030115	020062		.ASCIZ /CAM02 G=1 X=/
5259	040622	036507	020061	036530		
5260	040630	000				
5261	040631	015	012			CAM2TW: .BYTE 15,12
5262	040633	103	046501	031060		.ASCIZ /CAM02 G=2 X=/
5263	040640	043440	031075	054040		
5264	040646	000075				
5265	040650	015	012			CAM3TX: .BYTE 15,12
5266	040652	040503	030115	020063		.ASCIZ /CAM03 G=1 X=/
5267	040660	036507	020061	036530		
5268	040666	000				
5269	040667	015	012			CAM3TW: .BYTE 15,12
5270	040671	103	046501	031460		.ASCIZ /CAM03 G=2 X=/
5271	040676	043440	031075	054040		
5272	040704	000075				
5273	040706					JOYTX:
5274	040706	015	012			JOYTW: .BYTE 15,12
5275	040710	047512	051531	044524		.ASCIZ /JOYSTICK X=/
5276	040716	045503	054040	000075		
5277	040724	054440	000075			G1B: .ASCIZ / Y=/
5278	040730	005015	044504	043106		GAIN: .ASCII <15><12>/DIFFERENTIAL LINEARITY:/
5279	040736	051105	047105	044524		
5280	040744	046101	046040	047111		
5281	040752	040505	044522	054524		
5282	040760	072				
5283	040761	040	020040	040507		GAINX: .ASCII / GAIN = /
5284	040766	047111	036440	040		
5285	040773	061	040	040		GAIN1: .BYTE 61,40,40,0
5286	040776	000				
5287	040777	040	026455	000040		DASH: .ASCIZ / -- /
5288	041004	046040	041123	005015		LSBMSG: .ASCIZ / LSB/<15><12>
5289	041012	000				
5290	041013	040	045523	050111		SKPMSG: .ASCIZ / SKIPPED STATE(S)/<15><12>
5291	041020	042520	020104	052123		
5292	041026	052101	024105	024523		
5293	041034	005015	000			
5294	041037	040	025052	051105		ERMSG: .ASCIZ / **ERROR**/<15><12>
5295	041044	047522	025122	006452		
5296	041052	000012				
5297	041054	020040	020040	047440		OKMSG: .ASCIZ / OK/<15><12>
5298	041062	006513	000012			
5299	041066	047040	051101	047522		NARMSG: .ASCIZ # NARROW STATE(S)#<15><12>
5300	041074	020127	052123	052101		
5301	041102	024105	024523	005015		
5302	041110	000				
5303	041111	040	044527	042504		WIDMSG: .ASCIZ # WIDE STATE(S)#<15><12>
5304	041116	051440	040524	042524		
5305	041124	051450	006451	000012		
5306	041132	052123	052101	026505		STATE: .ASCIZ /STATE-- WIDTH/<15><12>

5307	041140	020055	044527	052104	
5308	041146	006510	000012		
5309	041152	046040	041123	046440	LINEA: .ASCIZ / LSB MAXIMUS AT /
5310	041160	054101	046511	051525	
5311	041166	040440	020124	000	
5312	041173	057	000		SLASH: .ASCIZ #/#
5313	041175	122	046105	052101	MSG21: .ASCIZ /RELATIVE ACCURACY: /<15><12>
5314	041202	053111	020105	041501	
5315	041210	052503	040522	054503	
5316	041216	006472	000012		
5317	041222	005015	047522	020115	COMP: .ASCIZ <15><12>/ROM BLASTING COMPLETED/
5318	041230	046102	051501	044524	
5319	041236	043516	041440	046517	
5320	041244	046120	052105	042105	
5321	041252	000			
5322	041253	015	052012	046511	TIMEO: .ASCII <15><12>/TIMEOUT FROM BLASTER CHECK SWITCHES ON BLASTER/
5323	041260	047505	052125	043040	
5324	041266	047522	020115	046102	
5325	041274	051501	042524	020122	
5326	041302	020040	044103	041505	
5327	041310	020113	053523	052111	
5328	041316	044103	051505	047440	
5329	041324	020116	046102	051501	
5330	041332	042524	122		
5331	041335	015	020012	051117	.ASCIZ <15><12>/ OR REPLACE ROM IN BLASTER/<15><12>
5332	041342	051040	050105	040514	
5333	041350	042503	051040	046517	
5334	041356	044440	020116	046102	
5335	041364	051501	042524	006522	
5336	041372	000012			
5337	041374	015	012		FIELDI: .BYTE 15,12
5338	041376	047111	042524	047122	.ASCIZ /INTERNAL MAINT. Z PULSES <Y FOR YES> ? /
5339	041404	046101	046440	044501	
5340	041412	052116	020056	020132	
5341	041420	052520	051514	051505	
5342	041426	036040	020131	047506	
5343	041434	020122	042531	037123	
5344	041442	037440	000040		
5345	041446	005015	053101	051105	AVRGO: .ASCIZ <15><12>/AVERAGE OF 128 STATES = /
5346	041454	043501	020105	043117	
5347	041462	030440	034062	051440	
5348	041470	040524	042524	020123	
5349	041476	020075	000		
5350	041501	015	012	007	UNFIX: .BYTE 15,12,7
5351	041504	054105	042503	042105	.ASCIZ /EXCEEDED CORRECTION COUNTER FOR /
5352	041512	042105	041440	051117	
5353	041520	042522	052103	047511	
5354	041526	020116	047503	047125	
5355	041534	042524	020122	047506	
5356	041542	020122	000		
5357	041545	015	012	007	ABORTB: .BYTE 15,12,7
5358	041550	047522	020115	046102	.ASCII /ROM BLASTING ABORTED/
5359	041556	051501	044524	043516	
5360	041564	040440	047502	052122	

5361	041572	042105					
5362	041574	015	012	007		.BYTE	15,12,7,0
5363	041577	000					
5364	041600	020040	026455	020040	SGNVAL:	.ASCII	/ -- /
5365	041606	053	040		SGNVL1:	.BYTE	53,40
5366	041610	060	060	052	LSBTXT:	.BYTE	60,60,52,60,15,12,0
5367	041613	060	015	012			
5368	041616	000					
5369	041617	015	012	000	RTN:	.BYTE	15,12,0,0
5370	041622	000					
5371	041623	040	042502	047514	BELMSG:	.ASCIZ	/ BELOW LIMIT/<15><12>
5372	041630	020127	044514	044515			
5373	041636	006524	000012				
5374	041642	047040	051117	040515	NORMSG:	.ASCIZ	/ NORMAL STATES/<15><12>
5375	041650	020114	052123	052101			
5376	041656	051505	005015	000			
5377	041663	040	041101	053117	ABOMSG:	.ASCIZ	/ ABOVE LIMIT/<15><12>
5378	041670	020105	044514	044515			
5379	041676	006524	000012				
5380	041702	050040	051501	042523	PASMSG:	.ASCIZ	/ PASSED/<15><12>
5381	041710	006504	000012				
5382	041714	043040	044501	042514	FAIMSG:	.ASCIZ	/ FAILED/<15><12>
5383	041722	006504	000012				
5384							
5385	041726	000000				.EVEN	
5386	041730	000000			LSBAVG:	0	
5387	041732	000000			LSBSVQ:	0	
5388	041734	000000			LSBSVR:	0	
5389	041736	000000			LSBSVW:	0	
5390	041740	042162			DIFEX1:	0	
5391	041742	027340			ROMPNT:	ROMVAL	
5392					NOMIAL:	12000.	; AVERAGE COUNT
5393							
5394	041744	000000					; THESE LOC.'S CLEARED BY DIPLIN
5395	041746	000000			AVGVAL:	0	
5396	041750	000000			DIFERR:	0	
5397	041752	000000			BELOW:	0	
5398	041754	000000			ABOVE:	0	
5399	041756	000000			NORMAL:	0	
5400	041760	000000			NARROW:	0	
5401	041762	000000			NARA:	0	
5402	041764	000000			NARB:	0	
5403	041766	000000			WIDA:	0	
5404	041770	000000			WIDB:	0	
5405	041772	000000			DIF:	0	
5406	041774	000000			OUT:	0	
					FIRST:	0	

```

5407
5408 :KEYBOARD CONVERSATION TO THE BLASTER SELECT TEST 'T'
5409 :APPLY POWER TO BLASTER AND DEPRESS I/O AND EXECUTE BUTTONS
5410 :ALL INDICATORS SHOULD LIGHT THE BLASTER SHOULD SEND A '>' CHARACTER
5411 :TYPE THE COMMANDS FOLLOWED BY A 'CR', SOME WILL ECHO THE CR AND OTHERS
5412 :WILL NOT TYPE 'ESC'/'ALT' KEYS TO ABORT CURRNET COMMAND
5413 :TYPE KF2/2 :THIS SETS OCTAL COMMAND MODE
5414 :TYPE FM30 :THIS SET OCTAL INPUT/OUTPUT
5415 :TYPE SP[0037/8] :THIS SIZES THE PROM -- 0037/8 IS REPORTED BY THE BLASTER
5416 :TYPE LD :THIS READS THE PROM INTO THE RAM
5417 :TYPE D00/37 :THIS OUTPUTS THE RAM CONTENTS TO THE TTY
5418 :TYPE ZP :THIS EXITS COMPUTER CONTROL TO THE BUTTON MODE
5419
5420 041776 105777 137674 LOOPC: TSTB @DLICSR ;BLASTER INPUT ?
5421 042002 100007 BPL LOOPD ;NO
5422 042004 000240 NOP
5423 042006 000240 NOP
5424 042010 000240 NOP
5425 042012 017720 137662 MOV @DLIED,(R0)+ ;SAVE THE CHARACTER
5426 042016 005237 042160 INC BLICNT ;UPDATE COUNTER
5427
5428 042022 105777 137122 LOOPD: TSTB @STPS ;PRINTER READY ?
5429 042026 100363 BPL LOOPC ;BR IF NOT
5430 042030 005737 042160 TST BLICNT ;ANY CHARACTERS
5431 042034 001413 BEQ LOOPE ;BR IF NOT
5432 042036 012177 137110 MOV (R1)+,@STPB ;PRINT THE CHAR.
5433 042042 005337 042160 DEC BLICNT
5434 042046 001353 BNE LOOPC ;RR IF MORE DATA
5435 042050 012700 060000 BTALK: MOV #BUFO,R0
5436 042054 010001 MOV R0,R1
5437 042056 005037 042160 CLR BLICNT
5438 042062 000745 BR LOOPC
5439 ;COME HERE IS NO BLASTER DATA TO BE TYPED
5440 042064 105777 137054 LOOPE: TSTB @STKS ;KEYBOARD INPUT
5441 042070 100342 BPL LOOPC ;BR IF NOT
5442 042072 017702 137050 MOV @STKB,R2 ;READ CHAR
5443 042076 042702 177600 BIC #177600,R2 ;MASK THE DATA
5444 042102 022702 000003 CMP #3,R2 ;TEST FOR CTRL C
5445 042106 001413 BEQ 2$ ;BR IF CTRL C
5446 042110 022702 000177 CMP #177,R2 ;TEST FOR RUBOUT
5447 042114 001412 BEQ LOOPF ;BR IF ESC
5448 042116 020227 000140 CMP R2,#140 ;TEST IF LOWER CASE
5449 042122 103402 BLO 1$ ;BR IF NOT
5450 042124 042702 000040 BIC #40,R2 ;MAKE UPPER CASE
5451 042130 010277 137550 1$: MOV R2,@DLODB ;LOAD BLASTER DATA OUT
5452 042134 000720 BR LOOPC
5453 042136 000137 002644 2$: JMP RBEGO ;JUMP TO RESTART
5454 042142 012777 000033 137534 LOOPF: MOV #33,@DLODB ;LOAD ESC <CANCLE>
5455 042150 012777 000134 136774 MOV #' \,@STPB
5456 042156 000707 BR LOOPC
5457 042160 000000 BLICNT: 0

```

```

5458
5459           ;A017 CORRECTION PROM VALUES   <MEMORY RAM>
5460
5461 042162      200      200      200  ROMVAL: .BYTE  200,200,200,200,200,200,200,200 ;GAIN - 1 VALUE
5462 042165      200      200      200
5463 042170      200      200
5464 042172      200      200      200      .BYTE  200,200,200,200,200,200,200,200
5465 042175      200      200      200
5466 042200      200      200
5467 042202      200      200      200      .BYTE  200,200,200,200,200,200,200,200 ;GAIN = 2 VALUE
5468 042205      200      200      200
5469 042210      200      200
5470 042212      200      200      200      .BYTE  200,200,200,200,200,200,200,200
5471 042215      200      200      200
5472 042220      200      200
5473
5474           ;A017 CORRECTION PRAM VALUES   <RAM MEMORY>
5475           ;ROMVAL MUST BE IN COMPLEMENTED AND REVERSED ORDER <LSB=MSB>
5476
5477 042222      376      376      376  RAMVAL: .BYTE  376,376,376,376,376,376,376,376 ;GAIN = 1 VALUE
5478 042225      376      376      376
5479 042230      376      376
5480 042232      376      376      376      .BYTE  376,376,376,376,376,376,376,376
5481 042235      376      376      376
5482 042240      376      376
5483 042242      376      376      376      .BYTE  376,376,376,376,376,376,376,376 ;GAIN = 2 VALUE
5484 042245      376      376      376
5485 042250      376      376
5486 042252      376      376      376      .BYTE  376,376,376,376,376,376,376,376
5487 042255      376      376      376
5488 042260      376      376
5489
5490           ;M8036 PROGRAM PROM VALUES
5491
5492
5493 042262      215      244      116  PROROM: .BYTE  215,244,116,144,215,244,116,144 ;M8036 PROGRAM PROM
5494 042265      144      215      244
5495 042270      116      144
5496 042272      215      244      116      .BYTE  215,244,116,144,215,244,116,144
5497 042275      144      215      244
5498 042300      116      144
5499 042302      116      144      216      .BYTE  116,144,216,244,377,377,377,377
5500 042305      244      377      377
5501 042310      377      377
5502 042312      377      377      377      .BYTE  377,377,377,377,377,377,377,377
5503 042315      377      377      377
5504 042320      377      377

```

```

5505 ;BLASTER SECTION
5506 042322 104401 051046 BLAST: TYPE, PRIMO ; TELL OPERATOR ABOUT THE CABLE
5507 042326 104401 051460 TYPE, PRIM5 ; AND SWITCHES
5508 042332 042777 000001 137336 BIC #BIT0,@DLICSR ; ENSURE INIT. ROM CONTROL LINE
5509 042340 004537 043112 JSR R5,RDBLST ; TELL THE BLASTER TO INITILIZE
5510 042344 052644 ESCP ; REALLY WE ARE WAITING FOR THE OPERATOR
5511 042346 004537 043112 JSR R5,RDBLST ; TELL THE BLASTER THE KEYBOARD INPUT MODE
5512 042352 052646 KFO
5513 042354 004537 043112 JSR R5,RDBLST ; TELL THE BLASTER THE DATA FORMAT <ASCII-OCTAL>
5514 042360 052655 FMO
5515 ;PRIME THE MEMORY RAM BUFFER
5516 042362 012700 042162 MOV #ROMVAL,RO ; GET POINTER
5517 042366 112720 000200 1$: MOVB #200,(R0)+ ; LOAD THE BUFFER
5518 042372 022700 042222 CMP #ROMVAL+40,RO ; TEST IF DONE
5519 042376 001373 BNE 1$ ; BR IF BUFFER NOT PRIMED
5520 042400 012737 000036 046146 MOV #36,PRIME1 ; LOAD GAIN AND RESOL. VALUES
5521 042406 004537 046152 JSR R5,LIMITS ; LOAD DIFLIN ERROR LIMIT VALUES
5522 042412 046216 G1LIM0 ; G1 LIMIT - USERS
5523 042414 046226 G1LIM1 ; G1 LIMIT - OPTION CHECKOUT
5524 042416 112737 000061 040773 MOVB #'1,GAIN1 ; LOAD GAIN TYPEOUT VALUE
5525 042424 012737 042163 041740 MOV #ROMVAL+1,ROMPNT ; LOAD RAM POINTER
5526 042432 004737 042476 JSR PC,4$ ; TEST THAT GAIN
5527 042436 012737 002036 046146 MOV #2036,PRIME1 ; LOAD GAIN AND RESOL. VALUES
5528 042444 004537 046152 JSR R5,LIMITS ; LOAD DIFLIN ERROR LIMIT VALUES
5529 042450 046236 G2LIMO ; G2 LIMIT - USERS
5530 042452 046246 G2LIM1 ; G2 LIMIT - OPTION CHECKOUT
5531 042454 112737 000062 040773 MOVB #'2,GAIN1 ; LOAD GAIN TYPEOUT VALUE
5532 042462 012737 042203 041740 MOV #ROMVAL+21,ROMPNT ; LOAD RAM POINTER
5533 042470 004737 042476 JSR PC,4$ ; TEST GAIN OF 2
5534 042474 000436 BR 10$
5535 042476 012737 000003 042646 4$: MOV #3,100$ ; LOAD LOOP COUNTER
5536 042504 012737 000001 041736 5$: MOV #1,DIFEX1 ; LOAD DIFLIN EXIT FLAG
5537 042512 012737 042530 046150 MOV #6$,DIFEXO ; LOAD DIFLIN EXIT RETURN
5538 042520 004737 042650 JSR PC,ZAPRAM ; ENSURE BLASTER RAM HAS BEEN LOADED WITH
5539 ; THE 'RAMVAL' VALUE
5540 042524 000137 044064 JMP DIFLNO ; RUN 'DIFLIN'
5541 042530 004737 043422 6$: JSR PC,ADJFIX ; ADJUST AND FIX THE CORRECTION WEIGHTS
5542 042534 005337 042646 DEC 100$ ; HAS THIS SECTION BEEN EXECITED N TIMES
5543 042540 001361 BNE 5$ ; BR IF NOT
5544 042542 005737 041746 TST DIFERR ; TEST IF ERROR OCCURRED?
5545 042546 001410 BEQ 8$ ; BR IF NOT
5546 042550 104401 041501 7$: TYPE, UNFIX ; TELL THE OPERATOR
5547 042554 104401 040761 TYPE, GAINX ; ABOUT IT
5548 042560 104401 041545 TYPE, ABORTB ; TELL OPER. THE BLASTING IS ABORTED
5549 042564 000137 002644 JMP RBEGO ; RESTART
5550 042570 000207 8$: RTS PC ; EXIT

```

```

5551                                     ;THE RAM DATA IS NOW CORRECT - BLAST THE BLANK ROM
5552 042572 004537 043112 10$: JSR R5,RDBLST ;TELL THE BLASTER TO COMP. THE DATA
5553 042576 053075 CMO
5554 042600 004537 043112 JSR R5,RDBLST ;TELL THE BLASTER TO CHECK-SUM DATA
5555 042604 053105 CCO
5556 042606 004537 043112 JSR R5,RDBLST ;TELL THE BLASTER TO BLAST THE ROM
5557 042612 053110 PGO
5558 042614 005237 043274 INC NOEXIT ;SET FLAG TO EXIT WITHOUT RECPT OF '>' CHAR FROM BLASTER
5559 042620 004537 043112 JSR R5,RDBLST ;TELL THE BLASTER TO RETURN TO KEYPAD MODE
5560 042624 053120 ZPO
5561                                     ;INFORM THE OPERATOR ABOUT THE BLASTER ROM
5562 042626 104401 052051 TYPE, PRIM1 ;TELL OPERATOR TO REMOVE RAM CABLE AND INSTERT ROM INTO A017
5563 042632 104411 RDLIN
5564 042634 012600 MOV (SP)+,R0 ;CLEAN STACK
5565 042636 104401 041222 TYPE, COMP ;COMPLETED
5566 042642 000137 002644 JMP RBEGO
5567 042646 000000 100$: 0
5568
5569                                     ;SUBROUTINE TO CONVERT THE MEMORY RAM VALUE INTO RAM MEMORY VALUE
5570
5571 042650 012703 042222 ZAPRAM: MOV #RAMVAL,R3 ;LOAD OUTPUT POINTER
5572 042654 012700 042162 MOV #ROMVAL,R0 ;LOAD INPUT POINTER
5573 042660 112001 1$: MOVB (R0)+,R1 ;GET A BYTE
5574 042662 105101 COMB R1 ;INVERT VALUE
5575 042664 005002 CLR R2 ;CLEAR RESULT
5576 042666 006001 ROR R1 ;MOVE INTO CARRY BIT
5577 042670 006102 ROL R2 ;MOVE CARRY INTO BIT 0
5578 042672 006001 ROR R1 ;MOVE INTO CARRY BIT
5579 042674 006102 ROL R2 ;MOVE CARRY INTO BIT 0
5580 042676 006001 ROR R1 ;MOVE INTO CARRY BIT
5581 042700 006102 ROL R2 ;MOVE CARRY INTO BIT 0
5582 042702 006001 ROR R1 ;MOVE INTO CARRY BIT
5583 042704 006102 ROL R2 ;MOVE CARRY INTO BIT 0
5584 042706 006001 ROR R1 ;MOVE INTO CARRY BIT
5585 042710 006102 ROL R2 ;MOVE CARRY INTO BIT 0
5586 042712 006001 ROR R1 ;MOVE INTO CARRY BIT
5587 042714 006102 ROL R2 ;MOVE CARRY INTO BIT 0
5588 042716 006001 ROR R1 ;MOVE INTO CARRY BIT
5589 042720 006102 ROL R2 ;MOVE CARRY INTO BIT 0
5590 042722 006001 ROR R1 ;MOVE INTO CARRY BIT
5591 042724 006102 ROL R2 ;MOVE CARRY INTO BIT 0
5592 042726 110223 MOVB R2,(R3)+ ;SAVE OUTPUT BYTE
5593 042730 020027 042222 CMP R0,#ROMVAL+40 ;TEST IF END
5594 042734 001351 BNE 1$ ;BR IF NOT
5595                                     ;SUBROUTINE TO LOAD MEMORY RAM INTO RAM MEMORY
5596 042736 004537 043276 JSR R5,CONROM ;CONVERT 'ROMVAL' TABLE INTO BLASTER FORMAT
5597 042742 042222 RAMVAL
5598 042744 052777 000001 136724 BIS #BIT0,@DLICSR ;ENABLE RAM MEMORY TO BE LOADED
5599 042752 004537 043112 JSR R5,RDBLST ;TELL THE BLASTER THE NEW RAM DATA
5600 042756 052663 DIO
5601 042760 004537 043112 JSR R5,RDBLST ;TELL THE BLASTER TO CHECKSUM THE DATA
5602 042764 053105 CCO
5603 042766 004537 043112 JSR R5,RDBLST ;TELL THE BLASTER TO PROGRAM THE RAM-PAK
5604 042772 053110 PGO

```

5605	042774	042777	000001	136674	BIC	#BITO,@DLICSR	;RE-ENTER EMMULATE MODE
5606	043002	000207			RTS	PC	;EXIT



```
5607                ;BLASTING THE PROGRAM PROM (M8036)
5608
5609 043004 104401 051622 PBLAST: TYPE, PRIM3 ;INFORM THE OPERATOR
5610 043010 042777 000001 136660 BIC #BIT0,@DLICSR ;ENSURE ROM MODE
5611 043016 004537 043112 JSR R5,RDBLST ;TE L THE BLASTER TO INITILIZE
5612 043022 052644 ESCP
5613 043024 004537 043112 JSR R5,RDBLST ;T.LL THE BLASTER THE KEYBOARD INPUT MODE
5614 043030 052646 KFO
5615 043032 004537 043112 JSR R5,RDBLST ;TELL THE BLASTER THE DATA FORMAT <ASCII-OCTAL>
5616 043036 052655 FMO
5617 043040 004537 043276 JSR R5,CONROM ;CONVERT THE 'PROROM' TABLE INTO BLASTER FORMAT
5618 043044 042262 PROROM
5619 043046 004537 043112 JSR R5,RDBLST ;TELL THE BLASTER THE PROM DATA
5620 043052 052663 DIO
5621 043054 004537 043112 JSR R5,RDBLST ;TELL THE BLASTER TO CHECKSUM THE DATA
5622 043060 053105 CCO
5623 043062 004537 043112 JSR R5,RDBLST ;TELL THE BLASTER TO BLAST THE PROM
5624 043066 053110 PGO
5625 043070 005237 043274 INC NOEXIT ;SET FLAG TO EXIT WITHOUT RECPT OF '>' FROM BLASTER
5626 043074 004537 043112 JSR R5,RDBLST ;TELL THE BLASTER TO RETURN TO KEYPAD MODE
5627 043100 053120 ZPO
5628 043102 104401 041222 TYPE, COMP ;INFORM THE OPERATOR IT'S DONE
5629 043106 000137 002644 JMP RBEGO
```

```

5630
5631      ;COME THERE TO OUTPUT A MESSAGE TO THE BLASTER
5632      ;EXIT ONLY WHEN THE BLASTER HAS ECHOED AN '>'
5633      ;REPORT AN ERROR UPON TIMEOUT UNLESS 'NOEXIT' IS NON-ZERO
5634 043112 010046      RDBLST: MOV      R0, -(SP)      ;SAVE R0
5635 043114 012500      MOV      (R5)+, R0      ;GET ARG.
5636 043116 012737 000012 043272      MOV      #10, 13$      ;LOAD DELAY FOR ERROR COUNTER
5637 043124 111037 043264      MOV      (R0), 10$      ;LOAD A CHAR
5638 043130 017737 136544 043266      MOV      @DLIBD, 11$      ;FALSE READ TO CLEAR READY
5639 043136 105777 136540      1$: TST      @DLOCSR      ;WAIT FOR OUTPUT READY
5640 043142 100375      BPL      1$
5641 043144 105737 043264      TST      10$      ;TEST IF FINISHED ?
5642 043150 001406      BEQ      2$
5643 043152 112037 043264      MOV      (R0)+, 10$      ;GET A CHAR.
5644 043156 001403      BEQ      2$      ;BR IF TERM
5645 043160 113777 043264 136516      MOV      10$, @DLODB      ;OUTPUT THE CHARACTER
5646 043166 105777 136504      2$: TST      @DLICSR      ;WAIT FOR INPUT
5647 043172 100416      BMI      4$      ;BR IF INPUT
5648 043174 005337 043270      DEC      12$      ;DELAY
5649 043200 001372      BNE      2$
5650 043202 005337 043272      DEC      13$      ;DELAY
5651 043206 001367      BNE      2$
5652 043210 005737 043274      TST      NOEXIT      ;TEST IF EXIT IS ALLOWED WITHOUT '>'
5653 043214 001017      BNE      5$      ;BR IF YES
5654 043216 104401 041253      TYPE,   TIMEO
5655 043222 000137 002644      JMP      RBEGO
5656 043226 000240      NOP
5657 043230 017737 136444 043266 4$: MOV      @DLIBD, 11$      ;READ CHAR
5658 043236 042737 177600 043266      BIC      #177600, 11$      ;MASK OFF BITS
5659 043244 022737 000076 043266      CMP      #'>, 11$      ;TEST FOR >
5660 043252 001331      BNE      1$      ;TRY NEXT CHAR.
5661 043254 012600      5$: MOV      (SP)+, R0      ;RESTORE R0
5662 043256 005037 043274      CLR      NOEXIT
5663 043262 000205      RTS      R5      ;EXIT
5664
5665 043264 000000      10$: 0
5666 043266 000000      11$: 0
5667 043270 000000      12$: 0
5668 043272 000000      13$: 0
5669 043274 000000      NOEXIT: 0

```

```
5670
5671          ;CONVERT ROM DATA INTO PROM BLASTER FORMAT
5672 043276 012700 052676 CONROM: MOV #DIDATA+3,R0 ;LOAD RESULT POINTER
5673 043302 012501          MOV (R5)+,R1 ;LOAD INITIAL VALUE POINTER
5674 043304 010137 043360          MOV R1,10$ ;COPY THE START
5675 043310 062737 000040 043360          ADD #40,10$ ;MAKE THE END ADDRESS
5676 043316 111102          1$: MOV (R1),R2 ;GET A BYTE OF DATA
5677 043320 004737 043402          JSR PC,SHUF0 ;CONVERT IT TO ASCII
5678 043324 111102          MOV (R1),R2 ;GET SAME BYTE AGAIN
5679 043326 004737 043374          JSR PC,SHUF3 ;CONVERT 2ND DIGIT
5680 043332 112102          MOV (R1)+,R2 ;GET MSD
5681 043334 004737 043362          JSR PC,SHUF6 ;CONVERT IT
5682 043340 062700 000007          ADD #7,R0 ;UPDATE RESULT POINTER
5683 043344 000240          NOP
5684 043346 000240          NOP
5685 043350 020137 043360          CMP R1,10$ ;TEST IF DONE
5686 043354 001360          BNE 1$
5687 043356 000205          RTS R5 ;EXIT
5688 043360 000000          10$: 0
5689
5690          ;ROTATE THE DATA RIGHT AND MAKE ASCII CHARACTER
5691
5692 043362 042702 177477          SHUF6: BIC #177477,R2 ;MASK OFF BITS
5693 043366 006202          ASR R2
5694 043370 006202          ASR R2
5695 043372 006202          ASR R2
5696 043374 006202          SHUF3: ASR R2
5697 043376 006202          ASR R2
5698 043400 006202          ASR R2
5699 043402 042702 177770          SHUF0: BIC #177770,R2 ;MASK OFF BITS
5700 043406 062702 000060          ADD #60,R2 ;MAKE ASCII
5701 043412 110240          MOV (R2),-(R0) ;LOAD RESULT BYTE
5702 043414 000240          NOP
5703 043416 000240          NOP
5704 043420 000207          RTS PC ;EXIT
5705
```

```

5706 ;SUBROUTINE TO ADJUST THE LSB VALUES
5707 043422 012700 062036 ADJFIX: MOV #BUF1+36,R0 ;GET BUFFER POINTER
5708 043426 013702 041740 MOV ROMPNT,R2 ;GET ROM POINTER
5709 043432 010204 MOV R2,R4
5710 043434 062704 000017 ADD #17,R4 ;MAKE END VALUE
5711 043440 012001 10$: MOV (R0)+,R1 ;GET LSB (17) M-1
5712 043442 061001 ADD (R0),R1 ;ADD LSB (00) M
5713 043444 163701 041744 SUB AVGVAL,R1 ;SUB 2 LSB AVG.
5714 043450 163701 041744 SUB AVGVAL,R1
5715 043454 010137 041734 MOV R1,LSBSVW ;SAVE FOR LATER USAGE
5716 043460 000240 NOP
5717 043462 000240 NOP
5718 043464 000240 NOP
5719 043466 000240 NOP
5720 043470 000240 NOP
5721 043472 000240 NOP
5722 043474 000240 NOP
5723 043476 000240 NOP
5724 043500 000240 NOP
5725 043502 000240 NOP
5726 043504 000240 NOP
5727 043506 000240 NOP
5728 043510 000240 NOP
5729 043512 000240 NOP
5730 043514 000240 NOP
5731 043516 000240 NOP
5732
5733 043520 010146 MOV R1,-(SP) ;SAVE ON STACK
5734 043522 012746 000316 MOV #316,-(SP) ;MULTI BY 316 (8)
5735 043526 004737 036504 JSR PC,$MULT
5736 043532 012637 043706 MOV (SP)+,100$ ;SAVE LSW
5737 043536 012637 043710 MOV (SP)+,101$ ;SAVE MSW
5738
5739 043542 013746 043706 MOV 100$,-(SP) ;
5740 043546 013746 043710 MOV 101$,-(SP) ;
5741 043552 013746 041744 MOV AVGVAL,-(SP) ;
5742 043556 004737 036616 JSR PC,$DIV
5743 043562 102004 BVC 1$ ;BR IF NO ERROR
5744 043564 000000 HALT
5745 043566 000000 HALT
5746 043570 000240 NOP
5747 043572 000240 NOP
5748 043574 012637 041732 1$: MOV (SP)+,LSBSVR ;SAVE INTGR. REMAINDER
5749 043600 012637 041730 MOV (SP)+,LSBSVQ ;SAVE QUOTIENT
5750
5751 ;NOW ADD THE QUOTIENT TO THE MEMORY RAM VALUE
5752
5753 043604 111203 MOVB (R2),R3 ;GET CURRENT MEMORY RAM VALUE
5754 043606 000240 NOP
5755 043610 042703 177400 BIC #177400,R3 ;CLEAR OFF UPPER BITS
5756 043614 000240 NOP
5757 043616 000240 NOP
5758 043620 000240 NOP
5759 043622 000240 NOP

```

```
5760 043624 163703 041730      SUB    LSBSVQ,R3      ;ADD THE QUOTIENT
5761 043630 000240              NOP
5762 043632 000240              NOP
5763 043634 000240              NOP
5764 043636 000240              NOP
5765 043640 000240              NOP
5766 043642 110322              MOVB   R3,(R2)+      ;RELOAD MEMORY RAM VALUE
5767
5768                          ;NOW UPDATE 'M' VALUE POINTER
5769
5770 043644 062700 000036      ADD    #36,R0        ;UPDATE POINTER
5771 043650 011001              MOV    (R0),R1      ;GET VALUE
5772 043652 000240              NOP
5773 043654 000240              NOP
5774 043656 000240              NOP
5775 043660 000240              NOP
5776 043662 063701 041734      ADD    LSBSVW,R1    ;CORRECT THE VALUE (#10)
5777 043666 000240              NOP
5778 043670 000240              NOP
5779 043672 000240              NOP
5780 043674 000240              NOP
5781 043676 010110              MOV    R1,(R0)      ;RESTORE FOR NEXT USAGE
5782 043700 020204              CMP    R2,R4        ;TEST WHEN FINISHED
5783 043702 001256              BNE   10$          ;BR UNTIL DONE
5784
5785 043704 000207              RTS   PC           ;EXIT
5786
5787 043706 000000              100$: 0
5788 043710 000000              101$: 0
```

```

5789
5790
5791 043712 005037 041736
5792 043716 112737 000061 040773
5793 043724 105737 001134
5794 043730 001007
5795 043732 104401 040730
5796 043736 005737 043712
5797 043742 100402
5798 043744 104401 051046
5799 043750 012737 000036 046146 10$:
5800 043756 004537 046152
5801 043762 046216
5802 043764 046226
5803 043766 012737 043776 046150
5804 043774 000433
5805 043776 112737 000062 040773 1$:
5806 044004 012737 002036 046146
5807 044012 004537 046152
5808 044016 046236
5809 044020 046246
5810 044022 012737 044044 046150
5811 044030 105737 001134
5812 044034 001002
5813 044036 104401 040730
5814 044042 000410
5815 044044 022737 177777 050106 11$:
5816 044052 001002 2$:
5817 044054 000137 030076
5818 044060 000137 002644 3$:
5819
5820
5821
5822 044064 012700 041744
5823 044070 005020
5824 044072 022700 041776
5825 044076 001374
5826 044100 012700 060000
5827 044104 005020 1$:
5828 044106 022700 064000
5829 044112 001374
5830
5831 044114 004737 045774
5832
5833 044120 012777 000000 135616
5834 044126 012777 000025 135604
5835
5836 044134 004737 045640
5837 044140 022702 000000 2$:
5838 044144 001773
5839 044146 105077 135570
5840 044152 152777 000002 135562
5841 044160 017737 135560 046032
5842

;:DIFFERENTIAL LINEARITY
DIFLIN: CLR DIFEX1 ;CLEAR EXIT FLAG
          MOVB #1,GAIN1 ;LOAD GAIN MESSAGE VALUE
          TSTB $AUTOB ;TEST IF UNDER MONITOR
          BNE 10$ ;BR IF YES
          TYPE, GAIN
          TST DIFLIN ;TEST BIT 15
          BMI 10$ ;DONT TELL OPER. ABOUT A017
          TYPE, PRIMO ;TELL OPERATOR ABOUT A017
          MOV #36,PRIME1 ;LOAD RESOLUTION AND GAIN
          JSR R5,LIMITS ;LOAD DIFLIN TOLERANCE
          G1LIMO ;G1 USER LIMIT
          G1LIM1 ;G1 OPTION AREA
          MOV #1$,DIFEXO ;LOAD RETURN ADDRESS
          BR DIFLNO
          MOVB #2,GAIN1 ;LOAD GAIN MESSAGE VALUE
          MOV #2036,PRIME1 ;LOAD RESOLUTION AND GAIN
          JSR R5,LIMITS ;LOAD DIFLIN TOLERANCE
          G2LIMO ;G2 USER LIMIT
          G2LIM1 ;G2 OPTION AREA
          MOV #2$,DIFEXO ;LOAD RETURN ADDRESS
          TSTB $AUTOB ;RUNNING UNDER MONITOR
          BNE 11$ ;BR IF YES
          TYPE, GAIN
          BR DIFLNO
          CMP #-1,RUNDIF ;ENTER VIA 'F' SELECTION ?
          BNE 3$ ;BR IF NOT
          JMP $EOP ;YES REPORT END OF PASS
          JMP RBEGO

;DIFLIN ROUTINE
DIFLNO: MOV #AVGVAL,RO ;LOAD CLEARING POINTER
DIFLNx: CLR (RO)+
          CMP #FIRST+2,RO ;FINISHED ?
          BNE DIFLNx ;BR IF NOT DONE
          MOV #BUF0,RO ;LOAD BUFFER POINTER
          CLR (RO)+ ;CLEAR THE DATA BUFFER
          CMP #BUF2,RO ;TEST IF FINISHED
          BNE 1$ ;BR IF NOT

;LOOK FOR THE DATA REGION FOR TO
          JSR PC,STDATO ;FIND THE NON-ZERO TO ZERO TRANS. DATA
;DATA HAS NOW GONE INTO THE GOOD 0 DATA REGION
          MOV #0,@KWPSR ;INIT THE CLOCK PRESET
          MOV #25,@KWCSR ;ENABLE THE CLOCK
;NOW TIME 'T1' LENGTH
          JSR PC,LISTDT ;GET CURRENT DATA VALUE
          CMP #0,R2 ;TEST FOR EXIT OF 0 DATA REGION
          BEQ 2$ ;BR UNTILL DONE
          CLRB @KWCSR1
          BISB #BIT1,@KWCSR1 ;FIRE ST2
          MOV @KWPSR,DIFT1 ;SAVE COUNTER VALUE
;NOW TIME 'T2' LENGTH

```

```

5843 044166 004737 045640      3$: JSR PC_LISTDT ;GET CURRENT DATA VALUE
5844 044172 022702 000377      CMP #377,R2 ;TEST FOR ENTRY INTO MAX DATA REGION
5845 044176 001373      BNE 3$ ;BR IF NOT
5846 044200 105077 135536      CLRB @KWCSR1
5847 044204 152777 000002 135530  BISB #BIT1,@KWCSR1 ;FIRE ST2
5848 044212 017737 135526 046034  MOV @KWPSR,DIFT2 ;SAVE COUNTER VALUE
5849 ;NOW TIME 'T3' LENGTH
5850 044220 004737 045640      4$: JSR PC_LISTDT ;GET CURRENT DATA VALUE
5851 044224 022702 000377      CMP #377,R2 ;TEST FOR EXIT OF MAX DATA REGION
5852 044230 001773      BEQ 4$ ;BR IF NOT
5853 044232 105077 135504      CLRB @KWCSR1
5854 044236 152777 000002 135476  BISB #BIT1,@KWCSR1 ;FIRE ST2
5855 044244 017737 135474 046036  MOV @KWPSR,DIFT3 ;SAVE COUNTER VALUE
5856 044252 005077 135462      CLR @KWCSR ;STOP CLOCK
5857 ;NOW DETERMINE THE AVG TIME (T3+T2)/2 AND SAVE IN 'HT2T3'
5858 044256 013700 046034      MOV DIFT2,R0 ;GET T2 VALUE
5859 044262 063700 046036      ADD DIFT3,R0 ;ADD T3 VALUE
5860 044266 006000      ROR R0 ;/2
5861 044270 010037 046040      MOV R0,HT2T3 ;SAVE FOR LATER USE
5862 ;NOW RETURN TO LIST MODE AND LOOK FOR THE NON-ZERO TO ZERO EDGE AGAIN
5863 044274 004737 045774      DIFLN1: JSR PC_STDATO ;FIND THE EDGE
5864 ;NOW START THE CLOCK USING THE AVG TIME
5865 ;AND DO AN MATRIX MODE COLLECTION
5866 044300 013700 046040      MOV HT2T3,R0 ;GET AVG CLOCK
5867 044304 005400      NEG R0 ;FIX FOR CLOCK PRESET REG
5868 044306 010077 135432      MOV R0,@KWPSR ;LOAD CLOCK PRESET
5869 044312 012777 000020 135420  MOV #20,@KWCSR ;PRIME CLOCK
5870 044320 012777 004000 135430  MOV #CLRALL,@SFR ;INIT THE NCV11
5871 044326 012777 060000 135414  MOV #BUFO,@OFF ;LOAD OFFSET
5872 044334 005077 135412      CLR @WCR ;CLEAR Z COUNTER
5873 044340 005077 135410      CLR @BAR ;
5874 044344 013777 046146 135374  MOV PRIME1,@CSR ;SET MODE AND RES.
5875 044352 052777 000022 135376  BIS #TESTZ!BIT4,@SFR ;SET TESTZ AND TESTX
5876 044360 052777 000001 135360  BIS #BIT0,@CSR ;ENABLE NCV11
5877 044366 052777 000001 135344  BIS #BIT0,@KWCSR ;ENABLE CLOCK
5878 044374 105777 135340      1$: TSTB @KWCSR ;WAIT FOR CLOCK FLAG
5879 044400 100375      BPL 1$
5880 044402 052777 000400 135346  BIS #ENDDMA,@SFR ;STOP DMA XFR
  
```

```

5881      :THE MATRIX MODE XFR IF NOW COMPLETED
5882      ;NOW ADD THE CURRENT B TE DATA COLLECTION INTO A TOTAL INCREMENT BUFFER
5883 044410 005037 050100      CLR      $TEMP1
5884 044414 012700 060000      MOV      #BUF0,R0
5885 044420 012701 062000      MOV      #BUF1,R1
5886
5887 044424 111037 050100      2$:      MOVB      (R0),$TEMP1      ;GET THE WORD
5888 044430 105020      CLR      (R0)+      ;CLEAR THE BYTE TABLE ENTRY
5889 044432 063721 050100      ADD      $TEMP1,(R1)+      ;UPDATE THE LIST
5890 044436 103003      BCC      3$      ;BR IF NO OVERFLOW
5891 044440 005741      TST      -(R1)      ;POSITION POINTER
5892 044442 012721 177777      MOV      #-1,(R1)+      ;SET TO 177777
5893 044446 022701 064000      3$:      CMP      #BUF2,R1      ;FINISHED?
5894 044452 001364      BNE      2$      ;BR IF NOT
5895      ;GET THE AVERAGE OF THE 128 CENTER STATES
5896 044454 012700 062100      MOV      #BUF1+64.,R0      ;GET INITIAL POINTER
5897 044460 005001      CLR      R1
5898 044462 005002      CLR      R2
5899 044464 062001      4$:      ADD      (R0)+,R1      ;GET A VALUE
5900 044466 103001      BCC      5$      ;BR IF NO CARRY OVERFLOW
5901 044470 005202      INC      R2      ;UPDATE MSW
5902 044472 022700 062300      5$:      CMP      #BUF1+192.,R0      ;FINISHED THE BUFFER
5903 044476 001372      BNE      4$      ;BR IF NOT DONE AVERAGE
5904 044500 000241      CLC
5905 044502 006002      ROR      R2      ;ROTATE MSW
5906 044504 006001      ROR      R1      ;INTO LSW
5907 044506 000241      CLC
5908 044510 006002      ROR      R2      ;ROTATE MSW
5909 044512 006001      ROR      R1      ;INTO LSW
5910 044514 000241      CLC
5911 044516 006002      ROR      R2      ;ROTATE MSW
5912 044520 006001      ROR      R1      ;INTO LSW
5913 044522 000241      CLC
5914 044524 006002      ROR      R2      ;ROTATE MSW
5915 044526 006001      ROR      R1      ;INTO LSW
5916 044530 000241      CLC
5917 044532 006002      ROR      R2      ;ROTATE MSW
5918 044534 006001      ROR      R1      ;INTO LSW
5919 044536 000241      CLC
5920 044540 006002      ROR      R2      ;ROTATE MSW
5921 044542 006001      ROR      R1      ;INTO LSW
5922 044544 010137 041744      MOV      R1,AVGVAL      ;SAVE THE AVERAGE
5923 044550 004737 046042      JSR      PC,CTRLCG      ;TEST FOR ^C OR ^G
5924 044554 023737 041744 041742      CMP      AVGVAL,NOMIAL      ;TEST IF AVG. IF >
5925 044562 103644      BLO      DIFLNT      ;BR IF NOT
5926

```



```
5927 ;READ THE TOTAL INCREMENT BUFFER AND DETERMINE IF ANY VALUES OUT OF RANGE
5928
5929 044564 013737 041744 045260 READ1: MOV AVGVAL,101$ ;GET AVERAGE
5930 044572 012700 000001 MOV #1,R0
5931 044576 012701 062002 MOV #BUF1+2,R1
5932 044602 012137 045256 1$: MOV (R1)+,100$ ;GET A WORD
5933 044606 163737 045260 045256 SUB 101$,100$ ;REMOVE THE AVERAGE
5934 044614 100006 BPL 2$
5935 044616 005137 045256 COM 100$
5936 044622 112737 000055 041606 MOVB #'-,SGNVL1 ;INSERT '-' SIGN
5937 044630 000403 BR 3$
5938 044632 112737 000053 041606 2$: MOVB #'+,SGNVL1 ;INSERT '+' SIGN
5939 044640 013746 045256 3$: MOV 100$,-(SP)
5940 044644 012746 001750 MOV #1000.,-(SP)
5941 044650 004737 036504 JSR PC,$MULT ;MULTIPLY NUM-AVG BY 1000.
5942 044654 012637 045274 MOV (SP)+,107$ ;GET RESULT
5943 044660 012637 045276 MOV (SP)+,110$
5944 044664 013746 045274 MOV 107$,-(SP) ;DIVIDE RESULT
5945 044670 013746 045276 MOV 110$,-(SP)
5946 044674 013746 045260 MOV 101$,-(SP) ;DIVIDE AGAIN
5947 044700 004737 036616 JSR PC,$DIV
5948 044704 102003 BVC 4$
5949 044706 000000 HALT ;FATAL ERROR DURING CAL. OF ERROR TOLERANCES
5950 044710 000240 NOP
5951 044712 000240 NOP
5952 044714 012637 045266 4$: MOV (SP)+,104$ ;GET REMAINDER
5953 044720 012637 045270 MOV (SP)+,105$ ;GET QOUT
5954 044724 013702 045260 MOV 101$,R2 ;ROUND UP IF NEEDED
5955 044730 006202 ASR R2
5956 044732 023702 045266 CMP 104$,R2 ;COMPARE RESULT
5957 044736 002402 BLT 5$
5958 044740 005237 045270 INC 105$ ;ROUND UP
5959 044744 000240 5$: NOP
5960 ;DIFLIN ERROR CHECK
5961
5962 044746 123737 045270 046207 6$: CMPB 105$,NORTOL ;TEST AGAINST NORMAL
5963 044754 103446 BLO 50$ ;BR IF OK
5964 044756 123737 045270 046211 CMPB 105$,NARTOL ;TEST AGAINST WIDE/NARROW TOLERANCE
5965 044764 103416 BLO 20$ ;BR IF OK
5966 044766 123737 045270 046213 CMPB 105$,NURTOL ;TEST AGAINST LARGE/SMALL TOLERANCE
5967 044774 103424 BLO 21$ ;BR IF OK
5968 044776 122737 000053 041606 CMPB #'+,SGNVL1 ;TEST IF +
5969 045004 001403 BEQ 7$
5970 045006 005237 041750 INC BELOW ;COUNT THE LOWER VALUE
5971 045012 000435 BR 51$
5972 045014 005237 041752 7$: INC ABOVE ;COUNT THE HIGHER VALUE
5973 045020 000432 BR 51$
5974 045022 122737 000053 041606 20$: CMPB #'+,SGNVL1 ;TEST IF +
5975 045030 001403 BEQ 22$
5976 045032 005237 041762 INC NARB ;COUNT THE LOWER
5977 045036 000423 BR 51$
5978 045040 005237 041766 22$: INC WIDB ;COUNT THE HIGHER
5979 045044 000420 BR 51$
5980 045046 122737 000053 041606 21$: CMPB #'+,SGNVL1 ;TEST IF +
```

```

5981 045054 001403          BEQ      23$
5982 045056 005237 041760    INC      NARA          ;COUNT THE LOWER
5983 045062 000411          BR       51$
5984 045064 005237 041764    23$:    INC      WIDA          ;COUNT THE HIGHER
5985 045070 000406          BR       51$
5986 045072 005237 041754    50$:    INC      NORMAL        ;COUNT THE NORMAL
5987 045076 122737 000115 052474  CMPB    #'M,RUNIT      ;TEST IF FORCE REPORT
5988 045104 001054          BNE     77$
5989 045106 105737 001134    51$:    TSTB    $AUTOB        ;TEST IF MONITOR ?
5990 045112 001051          BNE     77$          ;BR IF YES
5991          ;REPORT THE STATE INFORMATION
5992 045114 005737 041774    TST     FIRST          ;FIRST TYPEOUT ?
5993 045120 001013          BNE     10$          ;BR IF YES
5994 045122 005237 041774    INC     FIRST          ;SET FLAG
5995 045126 104401 041446    TYPE   ,AVRGO          ;TELL THE OPERATOR THE AVERG.
5996 045132 013746 041744    MOV     AVGVAL,-(SP)
5997 045136 104405          TYPDS
5998 045140 104401 041617    TYPE,  RTN
5999 045144 104401 041132    TYPE,  STATE          ;ADD HEADER INFO
6000 045150 010046          10$:    MOV     RO,-(SP)      ;LOAD STATE #
6001 045152 104403          TYPOS
6002 045154 003 001          .BYTE  3,1
6003 045156 122737 000115 052474  CMPB    #'M,RUNIT      ;TEST IF EXPAND OUTPUT SELECTED
6004 045164 001005          BNE     11$
6005 045166 104401 040777    TYPE,  DASH
6006 045172 013746 045256    MOV     100$,-(SP)    ;INSERT SPACING
6007 045176 104405          TYPDS          ;REPORT DIFFERENCE
6008 045200 013746 045270    11$:    MOV     105$,-(SP)
6009 045204 004737 037232    JSR    PC,$SB2D        ;CONVERT TO ASCII
6010 045210 012602          MOV     (SP)+,R2      ;GFT RESULT POINTER TO MESSAGE
6011 045212 062702 000002    ADD    #2,R2          ;ADJUST POINTER
6012 045216 112237 041610    MOVB   (R2)+,LSBTXT
6013 045222 112237 041611    MOVB   (R2)+,LSBTXT+1
6014 045226 112237 041613    MOVB   (R2)+,LSBTXT+3
6015 045232 104401 041600    TYPE,  SGNVAL
6016
6017 045236 004737 046042    77$:    JSR    PC,CTRLCG      ;TEST IF CTRL C/G
6018 045242 005200          INC     RO
6019 045244 022700 000377    CMP    #255.,RO      ;TEST IF DONE
6020 045250 001414          BEQ    READ          ;BR IF DONE
6021 045252 000137 044602    JMP    1$            ;TRY NEXT VALUE
6022
6023 045256 000000          100$:   0
6024 045260 000000          101$:   0
6025 045262 000000          102$:   0
6026 045264 000000          103$:   0
6027 045266 000000          104$:   0
6028 045270 000000          105$:   0
6029 045272 000000          106$:   0
6030 045274 000000          107$:   0
6031 045276 000000          110$:   0
6032 045300 000000          111$:   0

```

```
6033
6034          ;NOW ACCOUNT FOR ALL THE ERRORS
6035 045302 005037 041746      READ: CLR      DIFERR      ;CLEAR FLAG
6036 045306 013702 041752      MOV      ABOVE,R2    ;GET HIGH VALUE
6037 045312 063702 041750      ADD      BELOW,R2   ;ADD LOW
6038 045316 120237 046214      CMPB    R2,OBSCNT   ;TEST IF EXCEEDS LIMIT <OBEASE ABOVE/BELOW>
6039 045322 101026                BHI     1$          ;BR IF ERRORS
6040 045324 013702 041760      MOV      NARA,R2    ;GET LOW VALUE
6041 045330 063702 041764      ADD      WIDA,R2    ;ADD HIGH
6042 045334 120237 046212      CMPB    R2,NURCNT   ;TEST IF EXCEEDS LIMIT <LARGE ABOVE/BELOW>
6043 045340 101017                BHI     1$
6044 045342 013702 041762      MOV      NARB,R2    ;GET LOW VALUE
6045 045346 063702 041766      ADD      WIDB,R2    ;ADD HIGH
6046 045352 120237 046210      CMPB    R2,NARCNT   ;TEST IF EXCEEDS LIMIT <SMALL ABOVE/BELOW>
6047 045356 101010                BHI     1$
6048 045360 123737 046206 041754  CMPB    NORCNT,NORMAL ;TEST IF MIN. NORMAL COUNT HAS BEEN HIT
6049 045366 101004                BHI     1$
6050 045370 012737 041702 045516  MOV     #PASMSG,READ7 ;LOAD MESSAGE POINTER
6051 045376 000405                BR      2$
6052 045400 012737 041714 045516 1$: MOV     #FAIMSG,READ7 ;LOAD MESSAGE POINTER
6053 045406 005237 041746                INC     DIFERR      ;SET ERROR FLAG
6054 045412 013746 041750      2$: MOV     BELOW,-(SP) ;GET NO. OF STATES BELOW LIMITS
6055 045416 104405                TYPDS                ;REPORT VALUE
6056 045420 104401 041623      TYPE    ,BELMSG     ;TYPE MESSAGE
6057 045424 013702 041760      MOV     NARA,R2     ;GET NARROW LOW
6058 045430 063702 041762      ADD     NARB,R2     ;ADD NARROW HIGH
6059 045434 010246                MOV     R2,-(SP)    ;GET NO. OF NARROW STATES
6060 045436 1.4405                TYPDS
6061 045440 104401 041066      TYPE    ,NARMSG     ;TYPE MESSAGE
6062 045444 013746 041754      MOV     NORMAL,-(SP) ;GET NORMAL COUNT
6063 045450 104405                TYPDS
6064 045452 104401 041642      TYPE    ,NORMSG     ;REPORT NORMAL TEXT
6065 045456 013702 041764      MOV     WIDA,R2     ;GET WIDE LOW
6066 045462 063702 041766      ADD     WIDB,R2     ;ADD WIDE HIGH
6067 045466 010246                MOV     R2,-(SP)
6068 045470 104405                TYPDS
6069 045472 104401 041111      TYPE    ,WIDMSG     ;TYPE MESSAGE
6070 045476 013746 041752      MOV     ABOVE,-(SP) ;TYPE NO. OF STATES ABOVE LIMIT
6071 045502 104405                TYPDS
6072 045504 104401 041663      TYPE    ,ABOMSG     ;TYPE MESSAGE
6073
6074          ;REPORT PASS/FAIL MESSAGE
6075
6076 045510 104401 040730      TYPE    ,GAIN       ;RE-TYPE THE GAIN MESSAGE
6077 045514 104401
6078 045516 041702      READ7: PASMSG      ;REPORT PASS/FAIL
6079
```

```

6080
6081
6082 045520 032777 004000 133412 ;TYPE OUT MEMORY RAM AND RAM MEMORY VALUES IF SELECTED
6083 045526 001440 READXX: BIT #SW11,@SWR ;TEST IF THIS IS WANTED
6084 045530 005737 041736 BEQ 4$ ;BR IF NOT
6085 045534 001435 TST DIFEX1 ;TEST IF BLASTING MODE
6086 BEQ 4$ ;BR IF NOT
6087 045536 012700 042162 MOV #ROMVAL,R0 ;LOAD INITIAL POINTER
6088 045542 004737 045572 1$: JSR PC,2$ ;TYPE OUT LINE
6089 045546 022700 042262 CMP #ROMVAL+100,R0 ;TEST IF ALL DONE
6090 045552 001373 BNE 1$ ;BR IF NOT
6091 045554 104401 041617 TYPE, RTN
6092 045560 104401 041617 TYPE, RTN
6093 045564 104401 041617 TYPE, RTN
6094 045570 000417 BR 4$
6095
6096 045572 012701 000020 2$: MOV #16.,R1 ;LOAD WIDE COUNTER
6097 045576 104401 041617 TYPE, RTN
6098 045602 112002 3$: MOVB (R0)+,R2 ;GET A BYTE
6099 045604 042702 177400 BIC #177400,R2 ;MASK OFF HIGHER BITS
6100 045610 010246 MOV R2,-(SP) ;LOAD VALUE
6101 045612 104403 TYPOS
6102 045614 003 001 .BYTE 3,1
6103 045616 104401 041002 TYPE, DASH+3
6104 045622 005301 DEC R1 ;FINISHED ?
6105 045624 001366 BNE 3$
6106 045626 000207 RTS PC ;EXIT
6107
6108
6109 045630 005037 041736 4$: CLR DIFEX1
6110 045634 000177 000310 JMP @DIFEX0 ;EXIT THIS CRAZYNES
6111

```

```

6112                                     ;DIF LIN SUBROUTINE LIST MODE DATA COLLECTOR
6113
6114 045640 012777 004000 134110 LISTDT: MOV #CLRALL,@SFR ;CLEAR THE DEVICE
6115 045646 005077 134076 CLR @OFF ;PRIME OFFSET REG.
6116 045652 012777 177770 134072 MOV #-8.,@WCR ;LOAD WC.
6117 045660 012777 060000 134066 MOV #BUFO,@BAR ;LOAD BUS ADDR.
6118 045666 012777 000000 134052 MOV #0,@CSR ;SET RES. AND MODE
6119 045674 032737 002000 046146 BIT #2000,PRIME1 ;TEST GAIN BIT
6120 045702 001403 BEQ 3$ ;BR IF CLEARED
6121 045704 052777 002000 134034 BIS #2000,@CSR ;SELECT GAIN = 2
6122 045712 052777 000002 134036 3$: BIS #TESTZ,@SFR ;SET Z PULSES
6123 045720 052777 000001 134020 BIS #BIT0,@CSR ;ENABLE THE DEVICE
6124
6125 045726 105777 134014 1$: TSTB @CSR ;WAIT FOR IDLE
6126 045732 100375 BPL 1$
6127 045734 012700 060000 MOV #BUFO,R0 ;LOAD POINTER TO NEW DATA
6128 045740 005002 CLR R2
6129 045742 012703 000010 MOV #8.,R3 ;LOAD COUNTER
6130 045746 011001 2$: MOV (R0),R1 ;GET DATA WORD
6131 045750 005020 CLR (R0)+ ;CLR BUFFER WORD
6132 045752 042701 177400 BIC #177400,R1 ;MAKE OFF BITS
6133 045756 060102 ADD R1,R2 ;UPDATE TOTAL
6134 045760 005303 DEC R3 ;FINISHED ?
6135 045762 001371 BNE 2$ ;BR IF NOT
6136 045764 006202 ASR R2
6137 045766 006202 ASR R2
6138 045770 006202 ASR R2
6139 045772 000207 RTS PC ;EXIT
6140
6141 045774 012737 177777 046030 ;SUBROUTINE TO FIND THE TRUE EDGE OF ZERO DATA
6142 046002 004737 045640 STDATO: MOV #-1,10$ ;SET ENTRY FLAG
6143 046006 005702 1$: JSR PC,LISTDT ;GET DATA
6144 046010 001403 TST R2 ;CHECK DATA
6145 046012 005037 046030 BEQ 2$ ;BR IF ZERO
6146 046016 000771 CLR 10$ ;CLEAR ALREADY NON-ZERO DATA FLAG
6147 BR 1$
6148 046020 005737 046030 ;DATA WAS ZERO - CHECK IF WE STARTED IN 0 DATA REGION
6149 046024 001366 2$: TST 10$ ;TEST FLAG
6150 BNE 1$ ;BR IF NOT A GOOD TIME TO EXIT
6151 ;DATA HAS NOW GONE TO A GOOD ZERO DATA REGION
6152 ;NOW EXIT
6153 RTS PC ;BYEBYE
6154 10$: 0
6155 DIFT1: 0
6156 DIFT2: 0
6157 DIFT3: 0
HT2T3: 0

```

```

6158                                     ;SUBROUTINE TO TEST IF OPERATOR TYPED CTRL C OR G
6159 046042 105777 133076                 CTRLCG: TSTB   @STKS   ;INPUT FLAG
6160 046046 100033                         BPL          2$      ;BR IF NON
6161 046050 017737 133072 046140          MOV          @STKB,CTRCHA ;GET CHARACTER
6162 046056 042737 177600 046140          BIC          #177600,CTRCHA ;MASK OFF BITS
6163 046064 022737 000003 046140          CMP          #3,CTRCHA   ;TEST IF CTRL C
6164 046072 001014                         BNE          1$      ;BR IF NOT ^C
6165 046074 052777 000400 133654          BIS          #ENDDMA,@SFR ;STOP NPR'S
6166 046102 000240                         NOP
6167 046104 000240                         NOP
6168 046106 000240                         NOP
6169 046110 052777 004000 133640          BIS          #CLRALL,@SFR ;CLEAR THE DEVICE
6170 046116 005726                         TST          (SP)+    ;CLEAN STACK
6171 046120 000137 002012                 JMP          RTRT     ;RE-START
6172 046124 022737 000007 046140 1$:    CMP          #7,CTRCHA   ;TEST IF CTRL G
6173 046132 001001                         BNE          2$      ;BR IF NOT
6174 046134 104406                         GTSWR
6175 046136 000207 2$:                    RTS          PC      ;EXIT
6176 046140 000000                 CTRCHA: 0
6177 046142 177777                 PRIME: -1.
6178 046144 177400                 PRIME0: 177400
6179 046146 000036                 PRIME1: 36
6180 046150 000000                 DIFEX0: 0
6181
6182                                     ;SUBROUTINE TO DETERMINE ERROR LIMITS FOR DIPLIN
6183 046152 012500                 LIMITS: MOV    (R5)+,R0   ;GET 1ST ARG.
6184 046154 005737 050110          TST          WFMODE    ;TEST IF ON TESTER
6185 046160 001402                 BEQ          1$      ;BR IF NOT
6186 046162 012500                 MOV          (R5)+,R0   ;GET TESTER LIMITS
6187 046164 000401                 BR          2$
6188 046166 005725 1$:                    TST          (R5)+    ;BUMP ADDRESS
6189 046170 012701 046206 2$:            MOV          #NORCNT,R1 ;GET POINTER
6190 046174 012021                 MOV          (R0)+,(R1)+ ;GET VALUE
6191 046176 012021                 MOV          (R0)+,(R1)+
6192 046200 012021                 MOV          (R0)+,(R1)+
6193 046202 012021                 MOV          (R0)+,(R1)+
6194 046204 000205                 RTS          R5      ;EXIT

```

```

6195                ;ACTUAL VALUES FOR DIF LIN ERROR TOLERANCE
6196
6197
6198 046206          322          NORCNT: .BYTE 210.          ;'NORMAL'' MIN COUNT VALUE
6199 046207          013          NORTOL: .BYTE 11.           ;'NORMAL'' TOLERANCE VALUE
6200 046210          036          NARCNT: .BYTE 30.           ;'NARROW/WIDE'' MAX. COUNT VALUE
6201 046211          032          NARTOL: .BYTE 26.           ;'NARROW/WIDE'' TOLERANCE VALUE
6202 046212          016          NURCNT: .BYTE 14.           ;'LARGE/SMALL'' MAX. COUNT VALUE
6203 046213          145          NURTOL: .BYTE 101.          ;'LARGE/SMALL'' TOLERANCE VALUE
6204 046214          000          OBSCNT: .BYTE 0.            ;'OBESITY'' MAX. COUNT VALUE
6205 046215          377          OBSTOL: .BYTE 377          ;'OBESITY'' TOLERANCE VALUE
6206
6207                ;DIFLIN ERROR TOLERANCE          GAIN = 1          USER
6208
6209 046216          342          025          G1LIM0: .BYTE 226.,21.        ;226 MIN. COUNT, =<2.0%
6210 046220          024          063          .BYTE 20.,51.          ;20 MAX. COUNT, =<5.0%
6211 046222          010          145          .BYTE 8.,101.          ;8 MAX. COUNT, =<10.%
6212 046224          000          377          .BYTE 0.,377          ;0 MAX COUNT, >10%
6213
6214                ;DIFLIN ERROR TOLERANCE          GAIN = 1          OPTION AREA
6215
6216 046226          342          024          G1LIM1: .BYTE 226.,20.        ;226 MIN COUNT, =<1.9%
6217 046230          024          061          .BYTE 20.,49.          ;20 MAX. COUNT, <4.8%
6218 046232          010          140          .BYTE 8.,96.           ;8 MAX COUNT, =<9.5%
6219 046234          000          377          .BYTE 0.,377          ;0 MAX COUNT, >9.5%
6220
6221                ;DIFLIN ERROR TOLERANCE          GAIN = 2          USER
6222
6223 046236          330          031          G2LIM0: .BYTE 216.,25.        ;216. MIN COUNT, =<2.4%
6224 046240          036          073          .BYTE 30.,59.          ;30. MAX COUNT, =<6.0%
6225 046242          010          171          .BYTE 8.,121.          ;14. MAX COUNT, =<12.0%
6226 046244          000          377          .BYTE 0.,377          ;0 MAX COUNT, >12.0%
6227
6228                ;DIFLIN ERROR TOLERANCE          GAIN = 2          OPTION AREA
6229
6230 046246          330          025          G2LIM1: .BYTE 216.,21.        ;216. MIN COUNT, =<2.0%
6231 046250          036          063          .BYTE 30.,51.          ;30. MAX COUNT, =<5.0%
6232 046252          010          145          .BYTE 8.,101.          ;8. MAX COUNT, =<10.0%
6233 046254          000          377          .BYTE 0.,377          ;0 MAX COUNT, >10.0%
6234
  
```









```
6360          :NOW SAMPLE THE CAMERA CHANNELS
6361 047276    SAMCAM:
6362          :CAMERA 0, X INPUT
6363 047276 004537 047422      JSR      R5,ADJCAM      :
6364 047302 050126              ADMSG0          :CAM 0 MESSAGE
6365 047304 001730              DAC0            :DAC ADDRESS
6366 047306      000      000      .BYTE      0,0      :CAMERA 0, X AXIS
6367          :DO CAMERA 1, X INPUT
6368 047310 004537 047422      JSR      R5,ADJCAM      :
6369 047314 050312              ADMSG2          :CAM 1, X MESSAGE
6370 047316 001732              DAC1            :DAC ADDRESS
6371 047320      001      000      .BYTE      1,0      :CAMERA 1, X AXIS
6372          :DO CAMERA 2, X INPUT
6373 047322 004537 047422      JSR      R5,ADJCAM      :
6374 047326 050476              ADMSG4          :CAM 2, X MESSAGE
6375 047330 001734              DAC2            :DAC ADDRESS
6376 047332      002      000      .BYTE      2,0      :CAMERA 2, X AXIS
6377          :DO CAMERA 3, X INPUT
6378 047334 004537 047422      JSR      R5,ADJCAM      :
6379 047340 050662              ADMSG6          :CAM 3, X MESSAGE
6380 047342 001736              DAC3            :DAC ADDRESS
6381 047344      003      000      .BYTE      3,0      :CAMERA 3, X AXIS
6382          :NOW SAMPLE THE Y CAMERA CHANNELS
6383          :DO CAMERA 0 Y INPUT
6384 047346 004537 047422      JSR      R5,ADJCAM      :
6385 047352 050220              ADMSG1          :CAM 0 Y MESSAGE
6386 047354 001732              DAC1            :DAC ADDRESS
6387 047356      000      001      .BYTE      0,1      :CAMERA 0, Y AXIS
6388          :DO CAMERA 1, Y INPUT
6389 047360 004537 047422      JSR      R5,ADJCAM      :
6390 047364 050404              ADMSG3          :CAM 1, Y MESSAGE
6391 047366 001730              DAC0            :DAC ADDRESS
6392 047370      001      001      .BYTE      1,1      :CAMERA 1, Y AXIS
6393          :DO CAMERA 2, Y INPUT
6394 047372 004537 047422      JSR      R5,ADJCAM      :
6395 047376 050570              ADMSG5          :CAM 2, Y MESSAGE
6396 047400 001736              DAC3            :DAC ADDRESS
6397 047402      002      001      .BYTE      2,1      :CAMERA 2, Y AXIS
6398          :DO CAMERA 3, Y INPUT
6399 047404 004537 047422      JSR      R5,ADJCAM      :
6400 047410 050754              ADMSG7          :CAM 3, Y MESSAGE
6401 047412 001734              DAC2            :DAC ADDRESS
6402 047414      003      001      .BYTE      3,1      :CAMERA 3 Y AXIS
6403
6404 047416 000137 002644      JMP      RBEGO
```

```

6405                ;REPORT THE MESSAGE FIRST
6406
6407 047422 012500    ADJCAM: MOV      (R5)+,R0      ;GET ASCII POINTER
6408 047424 005777 132256 3$:      TST      @VTCHAR      ;WAIT FOR READY
6409 047430 100375    BPL      3$
6410 047432 012777 012000 132254 1$:      MOV      #12000,@VTCXY  ;POSITION THE CAHRACTERS
6411 047440 005777 132242      TST      @VTCHAR      ;WAIT FOR CHAR. READY
6412 047444 100375    BPL      1$
6413 047446 112077 132234      MOVB     (R0)+,@VTCHAR  ;LOAD THE CHAR.
6414 047452 105710      TSTB     (R0)          ;TEST IF TERM.
6415 047454 001371      BNE      1$          ;BR IF NOT
6416
6417 047456 013537 050104      MOV      @(R5)+,DACADR ;SAVE ADDRESS
6418 047462 012537 050112      MOV      (R5)+,CAMVAL ;SAVE CAMERA DATA
6419
6420 047466 012777 002315 000410 2$:      MOV      #2315,@DACADR ;PRESET DAC TO - GAIN INPUT
6421 047474 004737 047576      JSR      PC,SAMDAT
6422 047500 010137 050120      MOV      R1,VAL0      ;SAVE RESULTS
6423 047504 004737 050022      JSR      PC,FXLIN      ;POSITION THE CROSS HAIR LINE
6424 047510 012777 004000 000366      MOV      #4000,@DACADR ;PRESET DAC TO OFFSET
6425 047516 004737 047576      JSR      PC,SAMDAT      ;SAMPLE THE DATA
6426 047522 010137 050122      MOV      R1,VAL1      ;SAVE AVERAGE RESULTS
6427 047526 004737 050022      JSR      PC,FXLIN      ;POSITION THE CROSS HAIR LINE
6428 047532 012777 005463 000344      MOV      #5463,@DACADR ;PRESET DAC TO + GAIN INPUT
6429 047540 004737 047576      JSR      PC,SAMDAT      ;SAMPLE THE DATA
6430 047544 010137 050124      MOV      R1,VAL2      ;SAVE AVERAGE RESULTS
6431 047550 004737 050022      JSR      PC,FXLIN      ;POSITION THE CROSS HAIR LINE
6432 047554 004737 046042      JSR      PC,CTRLCG     ;TEST FOR CTRL C/G
6433 047560 122737 000103 046140      CMPSB   #'C,CTRCHA    ;CHECK IF CHARACTER WAS A \C\
6434 047566 001337      BNE      2$          ;BR IF NOT
6435 047570 005037 046140      CLR      CTRCHA      ;CLEAR CHAR
6436 047574 000205      RTS      R5          ;EXIT
6437
6438                ;COLLECT 64 SAMPLES FROM THE SELECTED CAMERA
6439                ;R1 CONTAINS THE AVERAGE
6440
6441 047576 012700 060000    SAMDAT: MOV      #BUF0,R0
6442 047602 012701 062000      MOV      #BUF1,R1
6443 047606 005020      1$:      CLR      (R0)+      ;CLEAR THE BUFFER
6444 047610 020001      CMP      R0,R1      ;FINISHED ?
6445 047612 001375      BNE      1$          ;BR IF NOT
6446
6447 047614 012777 177700 132130      MOV      #-100,@WCR   ;LOAD WORD COUNT
6448 047622 012777 060000 132124      MOV      #BUF0,@BAR   ;LOAD ADDRESS
6449 047630 113777 050112 132130      MOVB     CAMVAL,@CSRHB ;SELECT THE CAMERA
6450 047636 052777 000002 132112      BIS      #TESTZ,@SFR  ;SET TEST Z ENABLE
6451 047644 052777 000001 132074      BIS      #BIT0,@CSR   ;ENABLE NCV11
6452
6453 047652 105777 132070      2$:      TSTB     @CSR        ;WAIT UNTIL DONE
6454 047656 100375      BPL      2$
6455
6456 047660 012777 004000 132070      MOV      #CLRALL,@SFR ;CLEAR THE DEVICE
6457 047666 005037 050100      CLR      $TEMP1
6458 047672 005037 050102      CLR      $TEMP2
  
```



6513	050112	000000				CAMVAL: 0
6514	050114	000000				CURRENT: 0
6515	050116	000000				AGAN: 0
6516	050120	000000				VAL0: 0
6517	050122	000000				VAL1: 0
6518	050124	000000				VAL2: 0
6519	050126	040503	042515	040522		ADMSG0: .ASCII /CAMERA 00/
6520	050134	030040	060			
6521	050137	015	012			.BYTE 15,12
6522	050141	101	045104	051525		.ASCII /ADJUST R09 FOR X OFFSET/
6523	050146	020124	030122	020071		
6524	050154	047506	020122	020130		
6525	050162	043117	051506	052105		
6526	050170	015	012			.BYTE 15,12
6527	050172	042101	052512	052123		.ASCIIZ /ADJUST R24 FOR X GAIN/
6528	050200	051040	032062	043040		
6529	050206	051117	054040	043440		
6530	050214	044501	000116			
6531	050220	040503	042515	040522		ADMSG1: .ASCII /CAMERA 00/
6532	050226	030040	060			
6533	050231	015	012			.BYTE 15,12
6534	050233	101	045104	051525		.ASCII /ADJUST R13 FOR Y OFFSET/
6535	050240	020124	030522	020063		
6536	050246	047506	020122	020131		
6537	050254	043117	051506	052105		
6538	050262	015	012			.BYTE 15,12
6539	050264	042101	052512	052123		.ASCIIZ /ADJUST R20 FOR Y GAIN/
6540	050272	051040	030062	043040		
6541	050300	051117	054440	043440		
6542	050306	044501	000116			
6543	050312	040503	042515	040522		ADMSG2: .ASCII /CAMERA 01/
6544	050320	030040	061			
6545	050323	015	012			.BYTE 15,12
6546	050325	101	045104	051525		.ASCII /ADJUST R10 FOR X OFFSET/
6547	050332	020124	030522	020060		
6548	050340	047506	020122	020130		
6549	050346	043117	051506	052105		
6550	050354	015	012			.BYTE 15,12
6551	050356	042101	052512	052123		.ASCIIZ /ADJUST R23 FOR X GAIN/
6552	050364	051040	031462	043040		
6553	050372	051117	054040	043440		
6554	050400	044501	000116			
6555	050404	040503	042515	040522		ADMSG3: .ASCII /CAMERA 01/
6556	050412	030040	061			
6557	050415	015	012			.BYTE 15,12
6558	050417	101	045104	051525		.ASCII /ADJUST R14 FOR Y OFFSET/
6559	050424	020124	030522	020064		
6560	050432	047506	020122	020131		
6561	050440	043117	051506	052105		
6562	050446	015	012			.BYTE 15,12
6563	050450	042101	052512	052123		.ASCIIZ /ADJUST R19 FOR Y GAIN/
6564	050456	051040	034461	043040		
6565	050464	051117	054440	043440		
6566	050472	044501	000116			

6567	050476	040503	042515	040522	ADMSG4: .ASCII /CAMERA 02/
6568	050504	030040	062		
6569	050507	015	012		.BYTE 15,12
6570	050511	101	045104	051525	.ASCII /ADJUST R11 FOR X OFFSET/
6571	050516	020124	030522	020061	
6572	050524	047506	020122	020130	
6573	050532	043117	051506	052105	
6574	050540	015	012		.BYTE 15,12
6575	050542	042101	052512	052123	.ASCIZ /ADJUST R22 FOR X GAIN/
6576	050550	051040	031062	043040	
6577	050556	051117	054040	043440	
6578	050564	044501	000116		
6579	050570	040503	042515	040522	ADMSG5: .ASCII /CAMERA 02/
6580	050576	030040	062		
6581	050601	015	012		.BYTE 15,12
6582	050603	101	045104	051525	.ASCII /ADJUST R15 FOR Y OFFSET/
6583	050610	020124	030522	020065	
6584	050616	047506	020122	020131	
6585	050624	043117	051506	052105	
6586	050632	015	012		.BYTE 15,12
6587	050634	042101	052512	052123	.ASCIZ /ADJUST R18 FOR Y GAIN/
6588	050642	051040	034061	043040	
6589	050650	051117	054440	043440	
6590	050656	044501	000116		
6591	050662	040503	042515	040522	ADMSG6: .ASCII /CAMERA 03/
6592	050670	030040	063		
6593	050673	015	012		.BYTE 15,12
6594	050675	101	045104	051525	.ASCII /ADJUST R12 FOR X OFFSET/
6595	050702	020124	030522	020062	
6596	050710	047506	020122	020130	
6597	050716	043117	051506	052105	
6598	050724	015	012		.BYTE 15,12
6599	050726	042101	052512	052123	.ASCIZ /ADJUST R21 FOR X GAIN/
6600	050734	051040	030462	043040	
6601	050742	051117	054040	043440	
6602	050750	044501	000116		
6603	050754	040503	042515	040522	ADMSG7: .ASCII /CAMERA 03/
6604	050762	030040	063		
6605	050765	015	012		.BYTE 15,12
6606	050767	101	045104	051525	.ASCII /ADJUST R16 FOR Y OFFSET/
6607	050774	020124	030522	020066	
6608	051002	047506	020122	020131	
6609	051010	043117	051506	052105	
6610	051016	015	012		.BYTE 15,12
6611	051020	042101	052512	052123	.ASCIZ /ADJUST R17 FOR Y GAIN/
6612	051026	051040	033461	043040	
6613	051034	051117	054440	043440	
6614	051042	044501	000116		
6615					
6616	051046	015	012		PRIMO: .BYTE 15,12
6617	051050	044124	020105	042523	.ASCII /THE SELF-TEST CONNECTOR MUST BE INSTALLED ON A017/
6618	051056	043114	052055	051505	
6619	051064	020124	047503	047116	
6620	051072	041505	047524	020122	

6621	051100	052515	052123	041040
6622	051106	020105	047111	052123
6623	051114	046101	042514	020104
6624	051122	047117	040440	030460
6625	051130	067		
6626	051131	015	012	
6627	051133	124	042510	051440
6628	051140	044527	041524	020110
6629	051146	047117	040440	030460
6630	051154	020067	052515	052123
6631	051162	041040	020105	047111
6632	051170	021040	040515	047111
6633	051176	027124	020042	047520
6634	051204	044523	044524	047117
6635	051212	024040	047524	040527
6636	051220	042122	052040	042510
6637	051226	044440	047457	041440
6638	051234	047117	042516	052103
6639	051242	051117	051	
6640	051245	015	012	000
6641	051250	015	012	
6642	051252	044124	020105	042523
6643	051260	043114	052055	051505
6644	051266	020124	047503	047116
6645	051274	041505	047524	020122
6646	051302	052515	052123	041040
6647	051310	020105	042522	047515
6648	051316	042526	020104	051106
6649	051324	046517	052040	042510
6650	051332	040440	030460	067
6651	051337	015	012	
6652	051341	124	042510	051440
6653	051346	044527	041524	020110
6654	051354	047117	040440	030460
6655	051362	020067	052515	052123
6656	051370	041040	020105	047111
6657	051376	021040	050117	051105
6658	051404	021056	050040	051517
6659	051412	052111	047511	020116
6660	051420	040450	040527	020131
6661	051426	051106	046517	052040
6662	051434	042510	044440	047457
6663	051442	041440	047117	042516
6664	051450	052103	051117	051
6665	051455	015	012	000
6666	051460	047111	042523	052122
6667	051466	051040	046501	050055
6668	051474	045501	041440	041101
6669	051502	042514	044440	052116
6670	051510	020117	044124	020105
6671	051516	047523	045503	052105
6672	051524	047440	020116	044124
6673	051532	020105	030101	033461
6674	051540	015	012	

.BYTE 15,12  
.ASCII \THE SWITCH ON A017 MUST BE IN 'MAINT.' POSITION (TOWARD THE I/O CONNECT

PRIM6: .BYTE 15,12,0  
.BYTE 15,12  
.ASCII /THE SELF-TEST CONNECTOR MUST BE REMOVED FROM THE A017/

.BYTE 15,12  
.ASCII \THE SWITCH ON A017 MUST BE IN 'OPER.' POSITION (AWAY FROM THE I/O CONNE

PRIM5: .BYTE 15,12,0  
.ASCII /INSERT RAM-PAK CABLE INTO THE SOCKET ON THE A017/

.BYTE 15,12



6675	051542	042523	020124	040522
6676	051550	026515	040520	020113
6677	051556	053523	052111	044103
6678	051564	051505	052040	020117
6679	051572	044442	021116	020054
6680	051600	047042	051117	021115
6681	051606	040440	042116	021040
6682	051614	043117	021106	
6683	051620	015	012	
6684	051622	047111	042523	052122
6685	051630	041040	040514	045516
6686	051636	051040	046517	044440
6687	051644	052116	020117	047522
6688	051652	020115	046102	051501
6689	051660	042524	020122	047523
6690	051666	045503	052105	
6691	051672	015	012	
6692	051674	046120	040505	042523
6693	051702	042040	050105	042522
6694	051710	051523	052040	042510
6695	051716	021040	027511	021117
6696	051724	040440	042116	021040
6697	051732	054105	041505	052125
6698	051740	021105	041040	052125
6699	051746	047524	051516	052040
6700	051754	043517	052105	042510
6701	051762	122		
6702	051763	015	012	
6703	051765	124	042510	032040
6704	051772	050040	047522	042503
6705	052000	051523	046040	042105
6706	052006	020123	044527	046114
6707	052014	046040	043511	052110
6708	052022	053440	042510	020116
6709	052030	047504	042516	041440
6710	052036	051117	042522	052103
6711	052044	054514		
6712	052046	015	012	000
6713	052051	015	012	
6714	052053	120	042514	051501
6715	052060	020105	042522	047515
6716	052066	042526	051040	046501
6717	052074	050055	045501	041440
6718	052102	041101	042514	
6719	052106	015	012	
6720	052110	040440	042116	044440
6721	052116	051516	051105	020124
6722	052124	044124	020105	046102
6723	052132	051501	042524	020104
6724	052140	047522	020115	047111
6725	052146	047524	051440	041517
6726	052154	042513	020124	047117
6727	052162	040440	030460	020067
6728	052170	047515	052504	042514

.ASCII /SET RAM-PAK SWITCHES TO 'IN', 'NORM' AND 'OFF'/

PRIM3: .BYTE 15,12  
.ASCII /INSERT BLANK ROM INTO ROM BLASTER SOCKET/

.BYTE 15,12  
.ASCII \PLEASE DEPRESS THE 'I/O' AND 'EXECUTE' BUTTONS TOGETHER\

.BYTE 15,12  
.ASCII \THE 4 PROCESS LEDS WILL LIGHT WHEN DONE CORRECTLY\

PRIM1: .BYTE 15,12,0  
.BYTE 15,12  
.ASCII /PLEASE REMOVE RAM-PAK CABLE/

.BYTE 15,12  
.ASCII / AND INSERT THE BLASTED ROM INTO SOCKET ON A017 MODULE/

6729	052176	015	012			.BYTE	15,12	
6730	052200	042504	051120	051505		.ASCII	/DEPRESS THE "CR" KEY WHEN READY/	
6731	052206	020123	044124	020105				
6732	052214	041442	021122	045440				
6733	052222	054505	053440	042510				
6734	052230	020116	042522	042101				
6735	052236	131						
6736	052237	015	012	000		.BYTE	15,12,0	
6737	052242	015	012		PRIM2:	.BYTE	15,12	
6738	052244	050042	030512	020042		.ASCII	/'PJ1" CABLE MUST BE CONNECTED TO THE A017 CONNECTOR/	
6739	052252	040503	046102	020105				
6740	052260	052515	052123	041040				
6741	052266	020105	047503	047116				
6742	052274	041505	042524	020104				
6743	052302	047524	052040	042510				
6744	052310	040440	030460	020067				
6745	052316	047503	047116	041505				
6746	052324	047524	122					
6747	052327	015	012	000		.BYTE	15,12,0	
6748	052332	015	012		PRIM4:	.BYTE	15,12	
6749	052334	050042	031512	020042		.ASCII	/'PJ3" CABLE MUST BE CONNECTED TO THE M8036 CONNECTOR/	
6750	052342	040503	046102	020105				
6751	052350	052515	052123	041040				
6752	052356	020105	047503	047116				
6753	052364	041505	042524	020104				
6754	052372	047524	052040	042510				
6755	052400	046440	030070	033063				
6756	052406	041440	047117	042516				
6757	052414	052103	051117					
6758	052420	015	012	000		.BYTE	15,12,0	
6759		052424				.EVEN		
6760	052424	015	012	007	FATALO:	.BYTE	15,12,7	;'RUNIT' MUST BE ON A WORD BOUNDRY
6761	052427	106	052101	046101		.ASCII	/FATAL BUS TRAP WHEN PERFORMING TEST '/	
6762	052434	041040	051525	052040				
6763	052442	040522	020120	044127				
6764	052450	047105	050040	051105				
6765	052456	047506	046522	047111				
6766	052464	020107	042524	052123				
6767	052472	021040						
6768	052474	021103	040411	020124	RUNIT:	.ASCIZ	/C" AT LOCATION /	;'RUNIT' MUST BE A WORD BOUNDRY
6769	052502	047514	040503	044524				
6770	052510	047117	000040					
6771	052514	005015	051120	043517	RUNITA:	.ASCIZ	<15><12>/PROGRAM RESTARTING/	;'RUNIT' MUST BE A WORD BOUNDRY
6772	052522	040522	020115	042522				
6773	052530	052123	051101	044524				
6774	052536	043516	000					
6775	052541	015	012	007		.BYTE	15,12,7,0	
6776	052544	000						
6777	052545	015	012		MSGMEM:	.BYTE	15,12	
6778	052547	122	047125	044516		.ASCIZ	/RUNNING WITH /	
6779	052554	043516	053440	052111				
6780	052562	020110	000					
6781	052565	040	020113	043117	MSGK:	.ASCIZ	/ K OF MEMORY/<15><12>	
6782	052572	046440	046505	051117				























PROROM	042262	5493#	5618												
PRO	= 000000	53#													
PR1	= 000040	54#													
PR2	= 000100	55#													
PR3	= 000140	56#													
PR4	= 000200	57#													
PR5	= 000240	58#													
PR6	= 000300	59#													
PR7	= 000340	60#													
PS	= 177776	33#	34												
PSW	= 177776	34#	839*												
PWRVEC	= 000024	125#	604*	605*	4604*	4605*	4614*	4620*	4632*	4633*					
RAMVAL	042222	5477#	5571	5597											
RBEGO	002644	684	696#	748	756	5453	5549	5566	5629	5655	5818	6404			
RDBLST	043112	5509	5511	5513	5552	5554	5556	5559	5599	5601	5603	5611	5613	5615	
		5619	5621	5623	5626	5634									
RDCHR	= 104410	4088	5018#												
RDLIN	= 104411	697	787	4129	5019#	5563									
RDOCT	= 104412	771	5020#												
READ	045302	6020	6035#												
RFADXX	045520	6082#													
READ1	044564	5929#													
READ7	045516	6050*	6052*	6078#											
REDJOY	= 000001	579#	1398	1421	1453	1470	1487	1503	1520	1537	1553	1570	1588	1605	
		1623	1640												
		4937	5022#												
RESREG	= 104414	120#													
RESVEC	= 000010	5390#	5525*	5532*	5708										
ROMPNT	041740	5390	5461#	5516	5518	5525	5532	5572	5593	6087	6089				
ROMVAL	042162	5369#	5998	6091	6092	6093	6097								
RTN	041617	303	582#	767	6171										
RTRT	002012	583	586	589#	781										
RTRTA	002042	687*	711*	715*	724*	751*	3670	5815	6511#						
RUNDIF	050106	655*	698*	699*	700*	701	706	709	713	719	722	726	729	734	
RUNIT	052474	739	742	745	749	5987	6003	6768#							
		766	6771#												
RUNITA	052514	41#	657*	659*	661	663*	664*	665*	666*	673*	675	772*	774	777	
RO	%000000	778	826*	827*	828*	829*	830*	831*	832*	833	1258*	1266*	1294*	1302*	
		1330*	1338*	1399*	1402*	1422*	1425*	2117*	2118*	2119	2671*	2672*	2675*	2677	
		3277*	3280*	3281	3294*	3300*	3306*	3307	3309	3310	3322	3323	3350*	3353*	
		3354	3365*	3371*	3377*	3378	3380	3381	3394	3395	3414*	3415*	3416*	3417*	
		3427	3432*	3437*	3443*	3444	3445	3451	3452	3465*	3466*	3468*	3495	3517*	
		3518*	3520*	3547	3570*	3571*	3573*	3593	3636*	3637*	3639*	3659	3698*	3701	
		4126	4130*	4133	4149*	4165	4175*	4179	4195	4196	4209*	4305	4306*	4311	
		4316	4319*	4505	4506*	4507*	4514*	4515*	4516*	4517*	4518*	4519	4524	4529*	
		4531*	4535	4537	4551	4559*	4563	4564	4566*	4567*	4568	4590*	4606	4631*	
		4659	4665*	4710	4718*	4742	4767*	4784	4797*	4799*	4800*	4806*	4808*	4810	
		4814*	4844	4851*	4854*	4856*	4861*	4868*	4869	4872*	4879*	4880	4884*	4891	
		4895*	4913*	4914	4932*	4936*	4986	4987*	4988	4989*	4990*	4991*	4992*	5158*	
		5167*	5171*	5172*	5173	5179*	5183	5184	5425*	5435*	5436	5516*	5517*	5518	
		5564*	5572*	5573	5593	5634	5635*	5637	5643	5661*	5672*	5682*	5701*	5707*	
		5711	5712	5770*	5771	5781*	5822*	5823*	5824	5826*	5827*	5828	5858*	5859*	
		5860*	5861	5866*	5867*	5868	5884*	5887	5888*	5896*	5899	5902	5930*	6000	
		6018*	6019	6087*	6089	6098	6127*	6130	6131*	6183*	6186*	6190	6191	6192	





CZNRCA NCV11  
CZNRCA.P11

DIAGNOSTIC  
CROSS REFERENCE

MACY11 27(654) 8-AUG-78 15:05  
PAGE 163

G 14

SEQ 0175

SIPAR0=	172240	212#												
SIPAR1=	172242	213#												
SIPAR2=	172244	214#												
SIPAR3=	172246	215#												
SIPAR4=	172250	216#												
SIPAR5=	172252	217#												
SIPAR6=	172254	218#												
SIPAR7=	172256	219#												
SIPDR0=	172200	190#												
SIPDR1=	172202	191#												
SIPDR2=	172204	192#												
SIPDR3=	172206	193#												
SIPDR4=	172210	194#												
SIPDR5=	172212	195#												
SIPDR6=	172214	196#												
SIPDR7=	172216	197#												
SKPMSG	041013	5290#												
SLASH	041173	5312#												
SP	-%000006	49#	596*	614*	622*	626	698	761*	772	788	833*	865	868	1346*
		1347*	1360	2243*	2244*	2265	2622*	2623*	2632	2646*	2647*	2677*	2678*	2686
		2691	3695*	3989*	3990*	3991	3998*	4001*	4002*	4006*	4007*	4011	4014*	4018
		4020	4022	4023*	4030	4032	4034*	4035	4037*	4038*	4039*	4040*	4041*	4056*
		4057*	4060*	4061*	4062	4066*	4067*	4068	4071	4073	4075*	4084*	4089	4100
		4101*	4102*	4103*	4124*	4125*	4126*	4127*	4128*	4130	4133*	4141*	4142	4144
		4145*	4147	4148	4149	4165*	4166*	4167*	4168*	4169*	4170*	4171	4174*	4187
		4189*	4191	4201	4203	4205	4206	4207	4208	4209	4211*	4212*	4241*	4244
		4246	4247	4276	4277	4281*	4305*	4306	4316*	4318	4319	4320*	4322	4324
		4326	4332	4334*	4336*	4344*	4348	4352	4353	4357	4388*	4389	4390	4391*
		4396*	4397*	4398*	4404	4429	4430	4431	4432*	4433*	4464	4485*	4488*	4505*
		4510*	4531	4535*	4551*	4552*	4559	4560*	4571	4572*	4573*	4583	4584*	4589
		4590	4606*	4607*	4608*	4609*	4610*	4611*	4612*	4613	4621*	4625	4626	4627
		4628	4629	4630	4631	4659*	4660*	4661*	4662*	4663*	4664*	4665	4668	4678*
		4682	4683*	4690	4710*	4711	4712	4715	4716	4717	4718	4742*	4743*	4744*
		4745*	4746*	4747*	4748*	4749*	4750*	4751*	4758*	4759*	4760*	4761*	4762	4763
		4764	4765	4766	4767	4784*	4785*	4786*	4787*	4788	4790*	4792	4794*	4796*
		4802*	4804	4809	4810*	4811*	4812	4813	4814	4843*	4844*	4845*	4846*	4847*
		4848*	4849*	4850	4851	4853*	4857	4860*	4863*	4874*	4878*	4881	4882	4885*
		4886*	4887	4890*	4891*	4892	4893	4894	4895	4896*	4912	4914*	4971	4972*
		4974*	4975*	4986*	4987	4997*	4998*	5218*	5222*	5564	5634*	5661	5733*	5734*
		5736	5737	5739*	5740*	5741*	5748	5749	5939*	5940*	5942	5943	5944*	5945*
		5946*	5952	5953	5996*	6000*	6006*	6008*	6010	6054*	6059*	6062*	6067*	6070*
		6100*	6170											
SRO	177572	139#	3467*	3469*	3494*	3496*	3519*	3521*	3546*	3548*	3572*	3574*	3592*	3594*
		3638*	3640*	3658*	3660*	4674	4691*	4698*						
SR1	- 177574	140#												
SR2	= 177576	141#												
SR3	= 172516	142#	4688*											
STACK	= 001100	24#	596											
STATE	041132	5306#	5999											
STDATO	045774	5831	5863	6141#										
STKLMT	= 177774	35#												
SWR	001140	368#	594	616*	618	624*	631*	645	763	3328	3400	3502	3554	3985
		4022*	4236	4250	4252	4258	4265	4460	4467	4479	4483	4612	4625*	5027
		5032	5038	5043	5049	5054	5060	5065	5071	5139	5141	5169	5175	6082



SWREG	000176	300#	624	645	3985	3998								
SW0	= 000001	88#												
SW00	= 000001	78#	88	5032										
SW01	= 000002	77#	87	5043										
SW02	= 000004	76#	86											
SW03	= 000010	75#	85											
SW04	= 000020	74#	84											
SW05	= 000040	73#	83											
SW06	= 000100	72#	82	5027										
SW07	= 000200	71#	81											
SW08	= 000400	70#	80											
SW09	= 001000	69#	79											
SW1	= 000002	87#												
SW10	= 002000	68#												
SW11	= 004000	67#	3328	3400	3502	3554	6082							
SW12	= 010000	66#												
SW13	= 020000	65#	5141	5169										
SW14	= 040000	64#												
SW15	= 100000	63#	5175											
SW2	= 000004	86#	5054											
SW3	= 000010	85#	5065											
SW4	= 000020	84#	5071											
SW5	= 000040	83#												
SW6	= 000100	82#												
SW7	= 000200	81#	5038											
SW8	= 000400	80#	5049											
SW9	= 001000	79#	5060											
TBITVE	= 000014	121#												
TESTER	002020	304	584#											
TESTZ	= 000002	578#	1144	1145	1170	1171	1198	1199	1221	1222	1237	1238	1256	1257
		1291	1292	1305	1328	1329	1341	1378	1379	1657	1659	1674	1676	1691
		1693	1708	1710	1725	1727	1742	1744	1759	1761	1776	1778	1793	1795
		1810	1812	1827	1829	1844	1846	1861	1863	1878	1880	1895	1897	1912
		1914	1929	1931	1946	1948	1963	1965	1980	1982	1997	1999	2014	2016
		2032	2034	2050	2052	2071	2072	2127	2128	2176	2177	2210	2211	2252
		2253	2284	2285	2310	2311	2461	2462	2501	2502	2529	2530	2576	2577
		2616	2617	2659	2660	2705	2706	2726	2727	2747	2748	2768	2769	2789
		2790	2810	2811	2831	2832	2852	2853	2873	2874	2894	2895	2915	2916
		2936	2937	2960	2961	2994	3016	3017	3046	3047	3067	3068	3093	3094
		3116	3117	3291	3362	3363	3431	3490	3491	3540	3541	3582	3583	3614
		3615	3648	3649	5211	5875	6122	6450						
TFSITE	003276	703	784#											
TIMEO	041253	5322#	5654											
TKVEC	= 000060	128#												
TPVEC	= 000064	129#												
TRAPVE	= 000034	127#	602*	603*										
TRTVEC	= 000014	122#												
TSTCON	= 000004	577#	1372	1451	1468	1485	1501	1518	1535	1551	1568	1586	1603	1621
		1638	1655	1672	1689	1706	1723	1740	1757	1774	1791	1808	1825	1842
		1859	1876	1893	1910	1927	1944	1961	1978	1995	2012	2030	2048	2069
		2123	2173	2208	2242	2281	2307	2332	2357	2384	2409	2434	2459	2497
		2527	2574	2614	2656	2702	2723	2744	2765	2786	2807	2828	2849	2870
		2891	2912	2933	2957	2992	3013	3043	3064	3090	3114	3289	3360	3429
		3488	3538	3580	3611	3645								

C  
C  
A  
A  
A  
A  
B  
B  
E  
E  
E  
E  
E

TSTDMA= 000010

576#	1104	1139	1165	1193	1216	1250	1285	1322	1372	1451	1468	1485
1501	1518	1535	1551	1568	1586	1603	1621	1638	1655	1672	1689	1706
1723	1740	1757	1774	1791	1808	1825	1842	1859	1876	1893	1910	1927
1944	1961	1978	1995	2012	2030	2048	2069	2123	2173	2208	2242	2281
2307	2332	2357	2384	2409	2434	2459	2497	2527	2574	2614	2656	2702
2723	2744	2765	2786	2807	2828	2849	2870	2891	2912	2933	2957	2992
3013	3043	3064	3090	3114	3149	3176	3202	3226	3249	3488	3538	3580
3611	3645											

TST1	003636	801	841	847#								
TST10	004510	969	975#									
TST100	014642	2086	2109	2114#								
TST101	015166	2138	2167#									
TST102	015376	2189	2197	2202#								
TST103	015600	2223	2231	2236#								
TST104	016000	2273#										
TST105	016146	2277	2293	2299#								
TST106	016324	2303	2322	2327#								
TST107	016456	2346	2352#									
TST11	004546	981	987#									
TST110	016610	2371	2377#									
TST111	016744	2381	2396	2402#								
TST112	017114	2406	2423	2429#								
TST113	017246	2448	2453#									
TST114	017404	2473	2480#									
TST115	017612	2520#										
TST116	020052	2560	2567#									
TST117	020304	2602	2607#									
TST12	004610	993	999#									
TST120	020522	2644#										
TST121	020776	2698#										
TST122	021126	2713	2719#									
TST123	021256	2734	2740#									
TST124	021406	2755	2761#									
TST125	021536	2776	2782#									
TST126	021666	2797	2803#									
TST127	022016	2818	2824#									
TST13	004676	1016#										
TST130	022146	2839	2845#									
TST131	022276	2860	2866#									
TST132	022426	2881	2887#									
TST133	022556	2902	2908#									
TST134	022706	2923	2929#									
TST135	023036	2944	2950#									
TST136	023224	2972	2977	2985#								
TST137	023354	3003	3009#									
TST14	004764	1033#										
TST140	023542	3028	3032	3039#								
TST141	023672	3054	3060#									
TST142	024022	3075	3081#									
TST143	024162	3088	3101	3107#								
TST144	024366	3136	3141#									
TST145	024534	3144	3162	3168#								
TST146	024702	3171	3189	3195#								
TST147	025026	3198	3212	3219#								

TST15	005052	1050#						
TST150	025152	3222	3236	3242#				
TST151	025276	3245	3259	3265#				
TST152	025664	3305	3315	3327	3329	3332	3340#	
TST153	026244	3376	3386	3393	3399	3401	3404	3412#
TST154	026466	3442	3450	3457#				
TST155	026762	3460	3501	3503	3510#			
TST156	027260	3513	3553	3555	3562#			
TST157	027474	3568	3596	3601#				
TST16	005312	1089#						
TST160	027634	3609	3622	3628#				
TST161	030054	3634	3663	3668#				
TST17	005362	1096	1102#					
TST2	004020	864	872	880#				
TST20	005554	1131	1136#					
TST21	005726	1150	1157	1162#				
TST22	006112	1177	1185	1190#				
TST23	006252	1204	1208	1213#				
TST24	006366	1226	1231#					
TST25	006460	1241	1247#					
TST26	006652	1270	1277	1282#				
TST27	007052	1307	1314	1319#				
TST3	004122	900#						
TST30	007322	1369#						
TST31	007464	1385	1389	1395#				
TST32	007572	1412	1418#					
TST33	007736	1442	1448#					
TST34	010032	1459	1465#					
TST35	010126	1476	1482#					
TST36	010222	1493	1498#					
TST37	010316	1509	1515#					
TST4	004170	907	913#					
TST40	010412	1526	1532#					
TST41	010506	1543	1548#					
TST42	010602	1559	1565#					
TST43	010676	1576	1583#					
TST44	010772	1594	1600#					
TST45	011066	1611	1618#					
TST46	011162	1629	1635#					
TST47	011256	1646	1652#					
TST5	004242	920	926#					
TST50	011360	1663	1669#					
TST51	011462	1680	1686#					
TST52	011564	1697	1703#					
TST53	011666	1714	1720#					
TST54	011770	1731	1737#					
TST55	012072	1748	1754#					
TST56	012174	1765	1771#					
TST57	012276	1782	1788#					
TST6	004352	940	945#					
TST60	012400	1799	1805#					
TST61	012502	1816	1822#					
TST62	012604	1833	1839#					
TST63	012706	1850	1856#					

C  
C  
C  
C  
D  
D  
E  
H  
I  
I  
J  
J  
M

TST64	013010	1867	1873#											
TST65	013112	1884	1890#											
TST66	013214	1901	1907#											
TST67	013316	1918	1924#											
TST7	004440	962#												
TST70	013420	1935	1941#											
TST71	013522	1952	1958#											
TST72	013624	1969	1975#											
TST73	013726	1986	1992#											
TST74	014030	2003	2009#											
TST75	014132	2020	2027#											
TST76	014234	2038	2045#											
TST77	014336	2056	2062#											
TYPDS -	104405	834	3696	5013#	5997	6007	6055	6060	6063	6068	6071			
TYPE =	104401	639	691	693	696	754	760	766	770	784	785	804	825	835
		3694	3697	3996	3997	4000	4013	4024	4043	4092	4095	4099	4210	4327
		4423	4462	4470	4504	4521	4523	4526	4528	4532	4539	4634	5009#	5082
		5088	5095	5101	5108	5114	5121	5127	5134	5174	5221	5506	5507	5546
		5547	5548	5562	5565	5609	5628	5654	5795	5798	5813	5995	5998	5999
		6005	6015	6056	6061	6064	6069	6072	6076	6077	6091	6092	6093	6097
		6103	6322											
		762	3999	4512	4536	5010#								
TYPOC -	104402													
TYPON =	104404	5012#												
TYPOS =	104403	5011#	5219	5223	6001	6101								
UDPAR0=	177660	179#												
UDPAR1=	177662	180#												
UDPAR2=	177664	181#												
UDPAR3=	177666	182#												
UDPAR4=	177670	183#												
UDPAR5=	177672	184#												
UDPAR6=	177674	185#												
UDPAR7=	177676	186#												
UDPDR0=	177620	157#												
UDPDR1=	177622	158#												
UDPDR2=	177624	159#												
UDPDR3=	177626	160#												
UDPDR4=	177630	161#												
UDPDR5=	177632	162#												
UDPDR6=	177634	163#												
UDPDR7=	177636	164#												
UIPAR0=	177640	168#												
UIPAR1=	177642	169#												
UIPAR2=	177644	170#												
UIPAR3=	177646	171#												
UIPAR4=	177650	172#												
UIPAR5=	177652	173#												
UIPAR6=	177654	174#												
UIPAR7=	177656	175#												
UIPDR0=	177600	146#												
UIPDR1=	177602	147#												
UIPDR2=	177604	148#												
UIPDR3=	177606	149#												
UIPDR4=	177610	150#												
UIPDR5=	177612	151#												

C  
C







CZNCCA NCV11  
CZNCCA.P11

DIAGNOSTIC  
CROSS REFERENCE

MACY11 27(654) 8-AUG-78 15:05 B 15  
PAGE 171

SEQ 0183

\$MSGAD 001210	396#	4563*	4566												
\$MSGLG 001212	397#	4568*													
\$MSGTY 001174	390#	4561	4569*	4581	4585*										
\$MSWR 033536	3997	4110#													
\$MTYP1 001225	411#														
\$MTYP2 001231	419#														
\$MTYP3 001235	422#														
\$MTYP4 001241	425#														
\$MULT 036504	4783#	5735	5941												
\$MXCNT 034370	4273	4283#													
\$NULL 001154	374#	4334	4363												
\$NWTST= 000001	844#	877#	897#	910#	923#	942#	959#	972#	984#	996#	1013#	1030#	1047#		
	1086#	1099#	1133#	1159#	1187#	1210#	1228#	1244#	1279#	1316#	1366#	1392#	1415#		
	1445#	1462#	1479#	1495#	1512#	1529#	1545#	1562#	1580#	1597#	1615#	1632#	1649#		
	1666#	1683#	1700#	1717#	1734#	1751#	1768#	1785#	1802#	1819#	1836#	1853#	1870#		
	1887#	1904#	1921#	1938#	1955#	1972#	1989#	2006#	2024#	2042#	2059#	2111#	2164#		
	2199#	2233#	2270#	2296#	2324#	2349#	2374#	2399#	2426#	2450#	2477#	2517#	2564#		
	2604#	2641#	2695#	2716#	2737#	2758#	2779#	2800#	2821#	2842#	2863#	2884#	2905#		
	2926#	2947#	2982#	3006#	3036#	3057#	3078#	3104#	3138#	3165#	3192#	3216#	3239#		
	3262#	3337#	3409#	3454#	3507#	3559#	3598#	3625#	3665#						
\$OCNT 035076	4395*	4424*	4437#												
\$OMODE 035100	4390*	4394*	4399	4402*	4413*	4439#									
\$OVER 034354	4237	4253	4261	4271	4280#										
\$PASS 001202	393#	628*	800	3326	3398	3500	3552	3686*	3687*	3695	3708	4267	4284		
\$PASTM 001006	338#														
\$POWER 036052	4635	4640#													
\$PWRDN 035704	604	4604#	4632												
\$PWRMG 036040	4635#														
\$PWRUP 035756	4614	4620#													
\$QUES 001170	381#	755	4043	4092	4108	4363	4495								
\$RDCHR 033266	4056#	5018													
\$RDDEC= ***** U	5021														
\$RDLIN 033406	4084#	5019													
\$RDOCT 033560	4124#	5020													
\$RDSZ = 000010	4077#														
\$RESRE 036446	4757#	5022													
\$RTNAD 030176	3707#														
\$R2A = ***** U	5023														
\$\$AVRE 036410	4741#	5021													
\$\$AVR6 036050	4613*	4621	4622*	4623*	4639#										
\$\$B2D 037232	4971#	6009													
\$\$SCOPE 034106	598	4233#													
\$\$SETUP= 000137	582#	597	598	600	602	604	606	607	608	610	637	640	3684		
	3980	4114	4234	4456	4482	4490									
\$\$SIZE 036062	806	813	4659#												
\$\$SIZE X 036340	4699	4709#													
\$\$STUP = 177777	582#														
\$\$VLAD 034320	4245	4274#													
\$\$VPC = 000106	312#	317													
\$\$WR - 167400	4#	21	285	286	287	288	289	290	291	378	379	380	607		
	608	610	611	848	881	901	914	927	946	963	976	982	1000		
	1017	1034	1051	1090	1103	1137	1163	1191	1214	1232	1248	1283	1320		
	1370	1396	1419	1449	1466	1483	1499	1516	1533	1549	1566	1584	1601		
	1619	1636	1653	1670	1687	1704	1721	1738	1755	1772	1789	1806	1823		



		1840	1857	1874	1891	1908	1925	1942	1959	1976	1993	2010	2028	2046
		2063	2115	2168	2203	2237	2274	2300	2328	2353	2378	2403	2430	2454
		2481	2521	2568	2608	2645	2699	2720	2741	2762	2783	2804	2825	2846
		2867	2888	2909	2930	2951	2986	3010	3040	3061	3082	3108	3142	3169
		3196	3220	3243	3266	3341	3413	3458	3511	3563	3602	3629	3669	3679
		3685	3700	3706	3708	4225	4226	4227	4228	4229	4236	4248	4250	4251
		4254	4255	4256	4263	4264	4265	4277	4280	4283	4447	4448	4449	4450
		4451	4460	4467	4479	4483	4495	4636						
\$SWREG	001216	401#	631											
\$SWRM	C 10000	291	292	4229	4230	4252								
\$STEMF	02004	569#	836*	840	883*	885	887	893*	894	947*	949	951	955*	956
		2125*	2130*	2492*	2499	2504	2515*							
\$TEMP1	050100	5883*	5887*	5889	6457*	6463*	6464	6469*	6470	6508#				
\$TEMP2	050102	6458*	6464*	6465	6470*	6471	6509#							
\$TESTN	001200	392#	4275*											
\$TIMES	001160	378#	607*	848*	881*	901*	914*	927*	963*	976*	988*	1000*	1017*	1034*
		1051*	1090*	1137*	1163*	1191*	1214*	1232*	1248*	1283*	1320*	1370*	1396*	1419*
		1449*	1466*	1483*	1499*	1516*	1533*	1549*	1566*	1584*	1601*	1619*	1636*	1653*
		1670*	1687*	1704*	1721*	1738*	1755*	1772*	1789*	1806*	1823*	1840*	1857*	1874*
		1891*	1908*	1925*	1942*	1959*	1976*	1993*	2010*	2028*	2046*	2063*	2115*	2168*
		2203*	2237*	2274*	2300*	2328*	2353*	2378*	2403*	2430*	2454*	2481*	2521*	2568*
		2608*	2645*	2699*	2720*	2741*	2762*	2783*	2804*	2825*	2846*	2867*	2888*	2909*
		2930*	2951*	2986*	3010*	3040*	3061*	3082*	3108*	3142*	3169*	3196*	3220*	3243*
		3266*	3341*	3413*	3458*	3511*	3563*	3602*	3629*	3669*	3685*	4263*	4270	4273*
		4283												
\$TKB	001146	371#	3978	3989	4006	4060	4066	5442	6161					
\$TKS	001144	370#	776	779	3978	3987	4003	4027*	4058	4064	5440	6159		
\$TN	= 000162	5#	21	801	841	844	848#	864	872	877	881#	897	901#	907
		910	914#	920	923	927#	940	942	946#	959	963#	969	972	976#
		981	984	988#	993	996	1000#	1013	1017#	1030	1034#	1047	1051#	108f
		1090#	1096	1099	1103#	1131	1133	1137#	1150	1157	1159	1163#	1177	118j
		1187	1191#	1204	1208	1210	1214#	1226	1228	1232#	1241	1244	1248#	1270
		1277	1279	1283#	1307	1314	1316	1320#	1366	1370#	1385	1389	1392	1396#
		1412	1415	1419#	1442	1445	1449#	1459	1462	1466#	1476	1479	1483#	1493
		1495	1499#	1509	1512	1516#	1526	1529	1533#	1543	1545	1549#	1559	1562
		1566#	1576	1580	1584#	1594	1597	1601#	1611	1615	1619#	1629	1632	1636#
		1646	1649	1653#	1663	1666	1670#	1680	1683	1687#	1697	1700	1704#	1714
		1717	1721#	1731	1734	1738#	1748	1751	1755#	1765	1768	1772#	1782	1785
		1789#	1799	1802	1806#	1816	1819	1823#	1833	1836	1840#	1850	1853	1857#
		1867	1870	1874#	1884	1887	1891#	1901	1904	1908#	1918	1921	1925#	1935
		1938	1942#	1952	1955	1959#	1969	1972	1976#	1986	1989	1993#	2003	2006
		2010#	2020	2024	2028#	2038	2042	2046#	2056	2059	2063#	2086	2109	2111
		2115#	2138	2164	2168#	2189	2197	2199	2203#	2223	2231	2233	2237#	2270
		2274#	2277	2293	2296	2300#	2303	2322	2324	2328#	2346	2349	2353#	2371
		2374	2378#	2381	2396	2399	2403#	2406	2423	2426	2430#	2448	2450	2454#
		2473	2477	2481#	2517	2521#	2560	2564	2568#	2602	2604	2608#	2641	2645#
		2695	2699#	2713	2716	2720#	2734	2737	2741#	2755	2758	2762#	2776	2779
		2783#	2797	2800	2804#	2818	2821	2825#	2839	2842	2846#	2860	2863	2867#
		2881	2884	2888#	2902	2905	2909#	2923	2926	2930#	2944	2947	2951#	2972
		2977	2982	2986#	3003	3006	3010#	3028	3032	3036	3040#	3054	3057	3061#
		3075	3078	3082#	3088	3101	3104	3108#	3136	3138	3142#	3144	3162	3165
		3169#	3171	3189	3192	3196#	3198	3212	3216	3220#	3222	3236	3239	3243#
		3245	3259	3262	3266#	3305	3315	3327	3329	3332	3337	3341#	3376	3386
		3393	3399	3401	3404	3409	3413#	3442	3450	3454	3458#	3460	3501	3503



COMEN	131#														
ENDCOM	131#														
ERROR	25#	866	869	891	908	921	934	941	954	970	982	994	1009	1026	1043
	1064	1069	1074	1079	1084	1097	1116	1123	1132	1149	1153	1158	1176	1181	1186
	1203	1209	1227	1242	1269	1278	1306	1315	1342	1357	1384	1390	1406	1414	1429
	1436	1443	1460	1477	1494	1510	1527	1544	1560	1577	1595	1612	1630	1647	1664
	1681	1698	1715	1732	1749	1766	1783	1800	1817	1834	1851	1868	1885	1902	1919
	1936	1953	1970	1987	2004	2021	2039	2057	2085	2091	2098	2103	2110	2137	2142
	2148	2154	2160	2188	2192	2198	2222	2226	2232	2262	2294	2323	2347	2372	2397
	2424	2449	2474	2508	2513	2544	2554	2561	2590	2597	2603	2630	2637	2682	2687
	2714	2735	2756	2777	2798	2819	2840	2861	2882	2903	2924	2945	2975	2980	3004
	3031	3035	3055	3076	3102	3131	3137	3161	3188	3213	3237	3260	3304	3314	3375
	3385	3392	3441	3449	3499	3551	3597	3623	3664						
ESCAPE	131#														
GETPRI	131#	4667	4841												
GETSWR	131#	640#													
JOYMAC	1444#	1450	1467	1484	1500	1517	1534	1550	1567	1585	1602	1620	1637		
MULT	131#														
NEWTST	131#	844	877	897	910	923	942	959	972	984	996	1013	1030	1047	1086
	1099	1133	1159	1187	1210	1228	1244	1279	1316	1366	1392	1415	1445	1462	1479
	1495	1512	1529	1545	1562	1580	1597	1615	1632	1649	1666	1683	1700	1717	1734
	1751	1768	1785	1802	1819	1836	1853	1870	1887	1904	1921	1938	1955	1972	1989
	2006	2024	2042	2059	2111	2164	2199	2233	2270	2296	2324	2349	2374	2399	2426
	2450	2477	2517	2564	2604	2641	2695	2716	2737	2758	2779	2800	2821	2842	2863
	2884	2905	2926	2947	2982	3006	3036	3057	3078	3104	3138	3165	3192	3216	3239
	3262	3337	3409	3454	3507	3559	3598	3625	3665						
OFFBIT	2695#	2716	2737	2758	2779	2800	2821	2842	2863	2884	2905	2926			
POP	131#	4147	4205	4589	4590	4625	4626	4762	4812	4892					
PUSH	131#	4126	4164	4550	4552	4573	4606	4612	4742	4783	4844				
REPORT	131#														
RESLM	1649#	1666	1683	1700	1717	1734	1751	1768	1785	1802	1819	1836	1853	1870	1887
	1904	1921	1938	1955	1972	1989									
SCOPE	26#	847	880	900	913	926	945	962	975	987	999	1016	1033	1050	1089
	1102	1136	1162	1190	1213	1231	1247	1282	1319	1369	1395	1418	1448	1465	1482
	1498	1515	1532	1548	1565	1583	1600	1618	1635	1652	1669	1686	1703	1720	1737
	1754	1771	1788	1805	1822	1839	1856	1873	1890	1907	1924	1941	1958	1975	1992
	2009	2027	2045	2062	2114	2167	2202	2236	2273	2299	2327	2352	2377	2402	2429
	2453	2480	2520	2567	2607	2644	2698	2719	2740	2761	2782	2803	2824	2845	2866
	2887	2908	2929	2950	2985	3009	3039	3060	3081	3107	3141	3168	3195	3219	3242
	3265	3340	3412	3457	3510	3562	3601	3628	3668	3683					
SETPRI	131#														
SETTRA	5001#	5010	5011	5012	5013	5015	5017	5018	5019	5020	5021	5022			
SETUP	131#	589													
SETZ	582#	1144	1170	1198	1221	1237	1256	1291	1328	1378	2071	2126	2176	2210	2252
	2284	2310	2461	2501	2529	2576	2616	2659	2705	2726	2747	2768	2789	2810	2831
	2852	2873	2894	2915	2936	2960	3016	3046	3067	3093	3116	3362	3490	3540	3582
	3614	3648													
SKIP	131#	801	824	841	864	872	890	907	920	933	940	953	969	981	993
	1008	1025	1042	1063	1068	1073	1078	1083	1096	1114	1122	1131	1148	1150	1152
	1157	1177	1180	1185	1204	1208	1226	1241	1270	1277	1307	1314	1343	1358	1383
	1385	1389	1412	1435	1442	1459	1476	1493	1509	1526	1543	1559	1576	1594	1611
	1629	1646	1663	1680	1697	1714	1731	1748	1765	1782	1799	1816	1833	1850	1867
	1884	1901	1918	1935	1952	1969	1986	2003	2020	2038	2056	2084	2086	2090	2097
	2102	2109	2136	2138	2141	2147	2153	2159	2163	2189	2191	2197	2223	2225	2231

CZNCCA NCV11		DIAGNOSTIC		MACY11 27(654)		8-AUG-78		15:05		F 15		PAGE 175		SEQ 0187	
CZNCCA.P11		CROSS REFERENCE		TABLE											
	2263	2277	2293	2303	2322	2346	2371	2381	2396	2406	2423	2448	2473	2507	2543
	2553	2560	2589	2596	2602	2631	2636	2683	2688	2713	2734	2755	2776	2797	2818
	2839	2860	2881	2902	2923	2944	2972	2977	3003	3028	3030	3032	3054	3075	3088
	3101	3130	3136	3144	3160	3162	3171	3187	3189	3198	3212	3222	3236	3245	3259
	3297	3305	3308	3313	3315	3320	3327	3329	3332	3368	3376	3379	3384	3386	3391
	3393	3399	3401	3404	3434	3442	3448	3450	3460	3498	3501	3503	3513	3550	3553
	3555	3568	3596	3609	3622	3634	3663	3671							
SLASH	131#														
SOFTSW	8#														
SPACE	131#														
STARS	131#														
	912	310	321	323	330	343	384	387	844	846	877	879	897	899	910
	1030	923	925	942	944	959	961	972	974	984	986	996	998	1013	1015
	1212	1032	1047	1049	1086	1088	1099	1101	1133	1135	1159	1161	1187	1189	1210
	1445	1228	1230	1244	1246	1279	1281	1316	1318	1366	1368	1392	1394	1415	1417
	1564	1447	1462	1464	1479	1481	1495	1497	1512	1514	1529	1531	1545	1547	1562
	1700	1580	1582	1597	1599	1615	1617	1632	1634	1649	1651	1666	1668	1683	1685
	1821	1702	1717	1719	1734	1736	1751	1753	1768	1770	1785	1787	1802	1804	1819
	1955	1836	1838	1853	1855	1870	1872	1887	1889	1904	1906	1921	1923	1938	1940
	2113	1957	1972	1974	1989	1991	2006	2008	2024	2026	2042	2044	2059	2061	2111
	2374	2164	2166	2199	2201	2233	2235	2270	2272	2296	2298	2324	2326	2349	2351
	2606	2376	2399	2401	2426	2428	2450	2452	2477	2479	2517	2519	2564	2566	2604
	2821	2641	2643	2695	2697	2716	2718	2737	2739	2758	2760	2779	2781	2800	2802
	2984	2823	2842	2844	2863	2865	2884	2886	2905	2907	2926	2928	2947	2949	2982
	3192	3006	3008	3036	3038	3057	3059	3078	3080	3104	3106	3138	3140	3165	3167
	3509	3194	3216	3218	3239	3241	3262	3264	3337	3339	3409	3411	3454	3456	3507
	4154	3559	3561	3598	3600	3625	3627	3665	3667	3675	3977	3980	4048	4077	4116
	4980	4221	4286	4365	4443	4498	4545	4602	4618	4645	4726	4771	4818	4900	4962
SWRSU	131#	612#													
TRMTRP	5001#														
TYPBIN	131#														
TYPDEC	131#	3695													
TYPNAM	131#	633													
TYPNUM	131#														
TYPOCS	131#														
TYPOCT	131#	3998	4510	4534											
TYPTXT	131#														
\$\$CMRE	341#														
\$\$CMTM	341#														
\$\$ESCA	131#														
\$\$NEWT	131#	844	877	897	910	923	942	959	972	984	996	1013	1030	1047	1086
	1099	1133	1159	1187	1210	1228	1244	1279	1316	1366	1392	1415	1445	1462	1479
	1495	1512	1529	1545	1562	1580	1597	1615	1632	1649	1666	1683	1700	1717	1734
	1751	1768	1785	1802	1819	1836	1853	1870	1887	1904	1921	1938	1955	1972	1989
	2006	2024	2042	2059	2111	2164	2199	2233	2270	2296	2324	2349	2374	2399	2426
	2450	2477	2517	2564	2604	2641	2695	2716	2737	2758	2779	2800	2821	2842	2863
	2884	2905	2926	2947	2982	3006	3036	3057	3078	3104	3138	3165	3192	3216	3239
	3262	3337	3409	3454	3507	3559	3598	3625	3665						
\$\$SET	5001#	5010	5011	5012	5013	5015	5017	5018	5019	5020	5021	5022			
\$\$SETM	628#														
\$\$SKIP	131#	801	841	864	872	907	920	940	969	981	993	1096	1131	1150	1157
	1177	1185	1204	1208	1226	1241	1270	1277	1307	1314	1385	1389	1412	1442	1459
	1476	1493	1509	1526	1543	1559	1576	1594	1611	1629	1646	1663	1680	1697	1714
	1731	1748	1765	1782	1799	1816	1833	1850	1867	1884	1901	1918	1935	1952	1969





CZNCCA CZNCCA.P11	NCV11	DIAGNOSTIC CROSS REFERENCE	MACY11 TABLE	27(654)	8-AUG-78	15:05	I 15 PAGE 178	SEQ 0190							
	3592	3613	3614	3617	3638	3647	3648	3652	3658	4041	4192	4193	4420	4421	4675
	4860	4878	4931	5073	5161	5598	5875	5876	5877	5880	6121	6122	6123	6165	6159
	6330	6359	6450	6451	6505										
BISB	4507	5840	5847	5854											
BIT	1156	1184	1207	1262	1298	1334	2510	3296	3328	3367	3400	3433	3502	3554	4236
	4250	4258	4265	4460	4467	4483	5027	5032	5038	5043	5049	5054	5060	5065	5071
	5139	5141	5169	5175	6082	6119									
BITB	629	4309	4314	4346	4557										
BLO	2277	2303	3088	3568	3609	3634	5449	5925	5963	5965	5967				
BLOS	4087														
BLT	4031	4072	4181	4197	4337	4426	4858	4924	5957						
BMI	1401	1424	2187	2221	4188	5163	5647	5797							
BNE	595	619	636	642	646	662	676	684	702	707	710	714	720	723	727
	730	735	740	743	746	750	780	791	801	824	895	957	1012	1029	1046
	1148	1175	1202	1226	1263	1265	1267	1299	1301	1303	1335	1337	1339	1403	1426
	2120	2131	2163	2381	2406	2516	2974	3030	3164	3191	3282	3297	3299	3301	3324
	3329	3355	3368	3370	3372	3396	3401	3424	3434	3436	3438	3453	3503	3555	3986
	3992	4012	4019	4026	4063	4069	4091	4097	4186	4237	4266	4308	4315	4317	4325
	4333	4347	4354	4416	4468	4473	4491	4508	4530	4556	4562	4565	4582	4624	4707
	4803	4875	4935	5028	5033	5039	5044	5050	5055	5061	5066	5072	5140	5142	5165
	5168	5170	5190	5434	5519	5543	5594	5649	5651	5653	5660	5686	5783	5794	5812
	5816	5825	5829	5845	5894	5903	5988	5990	5993	6004	6090	6105	6135	6149	6164
	6173	6340	6346	6352	6415	6434	6445	6467	6473						
BPL	764	815	1412	1455	1472	1489	1505	1522	1539	1555	1572	1590	1607	1625	1642
	2416	3157	3184	3209	3233	3256	3460	3513	3988	4004	4059	4065	4172	4202	4302
	4351	4414	4480	4672	4789	4793	4852	4877	5075	5421	5429	5441	5640	5879	5934
	6126	6160	6329	6332	6409	6412	6454	6503							
BR	583	586	621	648	651	748	756	841	864	867	872	1150	1177	1204	1270
	1307	1343	1358	1385	2086	2138	2189	2223	2263	2631	2683	2688	2977	3032	3162
	3189	3305	3315	3335	3376	3386	3393	3407	3442	3450	4015	4042	4044	4070	4093
	4143	4183	4200	4239	4245	4248	4261	4264	4304	4330	4340	4349	4356	4392	4407
	4428	4478	4513	4540	4548	4570	4616	4638	4689	4699	4723	4862	4864	4867	4926
	5081	5087	5094	5100	5107	5113	5120	5126	5133	5178	5438	5452	5456	5534	5804
	5814	5937	5971	5973	5977	5979	5983	5985	6051	6094	6146	6187	6468		
BVC	5743	5948													
CLC	4866	5904	5907	5910	5913	5916	5919								
CLR	585	587	588	593	607	608	628	711	724	786	805	838	839	979	991
	1091	1236	1259	1295	1331	1361	1364	1375	1387	1413	2100	2139	2261	2266	2269
	2280	2412	2456	2523	2524	2570	2571	2610	2611	2640	2652	2653	2675	2694	2707
	2728	2749	2770	2791	2812	2833	2854	2875	2896	2917	2938	2962	2963	2979	2997
	3019	3020	3034	3048	3069	3095	3110	3111	3288	3295	3366	3471	3523	3573	3616
	3639	3684	3685	4001	4002	4131	4132	4175	4178	4263	4278	4405	4506	4622	4678
	4686	4698	4702	4787	4797	4848	4879	4920	5159	5180	5181	5437	5575	5662	5791
	5823	5827	5856	5872	5873	5883	5897	5898	6035	6109	6115	6128	6131	6145	6324
	6325	6435	6443	6457	6458	6459									
CLRB	930	937	966	3661	4098	4204	4262	4329	4355	4586	4587	4588	4885	4936	5201
	5216	5217	5839	5846	5853	5888									
CMR	594	618	637	645	661	675	779	865	868	889	894	906	919	932	939
	952	956	963	1007	1024	1041	1062	1067	1072	1077	1082	1113	1121	1130	1276
	1313	1360	1382	1434	1458	1475	1492	1508	1525	1542	1558	1575	1593	1610	1628
	1645	1662	1679	1696	1713	1730	1747	1764	1781	1798	1815	1832	1849	1866	1883
	1900	1917	1934	1951	1968	1985	2002	2019	2037	2055	2083	2089	2096	2108	2119
	2135	2146	2152	2158	2162	2190	2196	2224	2230	2265	2276	2292	2302	2321	2345
	2370	2395	2422	2447	2472	2506	2542	2552	2559	2588	2595	2601	2632	2635	2686

	2691	2712	2733	2754	2775	2796	2817	2838	2859	2880	2901	2922	2943	2971	3002
	3027	3053	3074	3087	3100	3129	3135	3159	3186	3211	3235	3258	3281	3307	3312
	3319	3323	3331	3354	3378	3383	3390	3395	3403	3423	3447	3452	3497	3505	3549
	3557	3567	3595	3608	3621	3633	3662	3985	3991	4011	4018	4030	4032	4062	4068
	4071	4073	4086	4196	4246	4270	4490	4690	4695	4706	4804	4930	5444	5446	5448
	5518	5593	5659	5685	5782	5815	5824	5828	5837	5844	5851	5893	5902	5924	5956
	6019	6089	6163	6172	6339	6345	6351	6444	6466	6472					
CMPB	643	701	706	709	713	719	722	726	729	734	739	742	745	749	790
	3993	4025	4090	4096	4252	4256	4307	4322	4324	4332	4353	4357	4472	4555	5962
	5964	5966	5968	5974	5980	5987	6003	6038	6042	6046	6048	6433			
COM	5935														
COMB	5574														
DEC	1264	1266	1300	1302	1336	1338	1402	1425	2130	2500	3152	3178	3298	3300	3369
	3371	3435	3437	3688	4514	4794	4802	4874	4886	4933	5164	5167	5189	5433	5542
	5648	5650	6104	6134											
DECB	4336	4339	4413	4424	4853										
EMT	25														
HALT	298	765	4303	4481	4492	4615	4637	4722	5177	5744	5745	5949			
INC	582	584	635	664	680	832	842	3686	4040	4182	4269	4419	4427	4463	4585
	4623	4691	4790	4863	4925	5426	5558	5625	5901	5958	5970	5972	5976	5978	5982
	5984	5986	5994	6018	6053	6338	6344	6350							
INCB	4274	4359	4457												
IOT	26														
JMP	302	303	304	688	703	708	712	716	721	725	728	731	736	741	744
	752	767	781	793	874	3672	3706	5137	5453	5540	5549	5566	5629	5655	5817
	5818	6021	6110	6171	6404										
JSR	806	813	3701	4029	4235	4312	4331	4338	4345	4469	4475	574	4973	5025	5029
	5034	5040	5045	5051	5056	5062	5067	5079	5083	5085	5089	5092	5096	5098	5102
	5105	5109	5111	5115	5118	5122	5124	5128	5131	5135	5166	5509	5511	5513	5521
	5526	5528	5533	5538	5541	5552	5554	5556	5559	5596	5599	5601	5603	5611	5613
	5615	5617	5619	5621	5623	5626	5677	5679	5681	5735	5742	5800	5807	5831	5836
	5843	5850	5863	5923	5941	5947	6009	6017	6088	6142	6337	6343	6349	6363	6368
	6373	6378	6384	6389	6394	6399	6421	6423	6425	6427	6429	6431	6432		
MOV	592	596	598	599	600	601	602	603	604	605	606	610	611	614	615
	616	617	622	624	625	626	631	656	657	658	659	663	665	667	668
	671	673	677	678	679	687	698	715	751	761	772	776	777	788	792
	811	812	816	817	818	819	820	821	822	826	833	836	837	840	848
	849	850	858	862	863	870	871	873	881	882	883	885	886	887	901
	902	904	905	914	915	916	917	918	927	928	929	931	935	936	938
	946	947	949	950	951	963	964	965	967	976	977	980	988	989	992
	1000	1001	1002	1004	1005	1006	1017	1018	1019	1021	1022	1023	1034	1035	1036
	1038	1039	1040	1051	1053	1054	1055	1056	1057	1058	1060	1061	1065	1066	1070
	1071	1075	1076	1080	1081	1085	1090	1092	1093	1094	1095	1103	1110	1112	1119
	1120	1126	1129	1137	1138	1139	1140	1141	1142	1146	1147	1151	1154	1155	1163
	1164	1165	1166	1167	1168	1172	1173	1178	1179	1182	1183	1191	1192	1193	1194
	1195	1196	1200	1201	1205	1206	1214	1215	1216	1217	1218	1219	1223	1224	1232
	1233	1234	1235	1239	1240	1248	1249	1250	1251	1252	1253	1258	1260	1268	1274
	1275	1283	1284	1285	1286	1287	1288	1294	1296	1304	1311	1312	1320	1321	1322
	1323	1324	1325	1330	1332	1340	1346	1347	1349	1355	1356	1362	1363	1370	1371
	1372	1373	1374	1376	1380	1381	1388	1396	1397	1399	1404	1405	1410	1419	1420
	1422	1427	1428	1432	1433	1439	1440	1441	1449	1450	1451	1452	1456	1457	1466
	1467	1468	1469	1473	1474	1483	1484	1485	1486	1490	1491	1499	1500	1501	1502
	1506	1507	1516	1517	1518	1519	1523	1524	1533	1534	1535	1536	1540	1541	1549
	1550	1551	1552	1556	1557	1566	1567	1568	1569	1573	1574	1584	1585	1586	1587



1591	1592	1601	1602	1603	1604	1608	1609	1619	1620	1621	1622	1626	1627	1636
1637	1638	1639	1643	1644	1653	1654	1655	1656	1660	1661	1670	1671	1672	1673
1677	1678	1687	1688	1689	1690	1694	1695	1704	1705	1706	1707	1711	1712	1721
1722	1723	1724	1728	1729	1738	1739	1740	1741	1745	1746	1755	1756	1757	1758
1762	1763	1772	1773	1774	1775	1779	1780	1789	1790	1791	1792	1796	1797	1806
1807	1808	1809	1813	1814	1823	1824	1825	1826	1830	1831	1840	1841	1842	1843
1847	1848	1857	1858	1859	1860	1864	1865	1874	1875	1876	1877	1881	1882	1891
1892	1893	1894	1898	1899	1908	1909	1910	1911	1915	1916	1925	1926	1927	1928
1932	1933	1942	1943	1944	1945	1949	1950	1959	1960	1961	1962	1966	1967	1976
1977	1978	1979	1983	1984	1993	1994	1995	1996	2000	2001	2010	2011	2012	2013
2017	2018	2028	2029	2030	2031	2035	2036	2046	2047	2048	2049	2053	2054	2063
2064	2065	2066	2067	2068	2069	2080	2081	2082	2087	2088	2094	2095	2101	2105
2106	2107	2115	2116	2117	2118	2121	2122	2123	2125	2133	2134	2140	2143	2144
2145	2150	2151	2155	2156	2157	2168	2169	2170	2171	2172	2173	2174	2185	2186
2194	2195	2203	2204	2205	2206	2207	2208	2219	2220	2228	2229	2237	2238	2239
2240	2241	2242	2243	2244	2246	2267	2268	2274	2275	2278	2279	2281	2282	2290
2291	2300	2301	2304	2305	2306	2307	2308	2319	2320	2328	2329	2330	2331	2332
2333	2343	2344	2353	2354	2355	2356	2357	2358	2368	2369	2378	2379	2382	2383
2384	2385	2393	2394	2403	2404	2407	2408	2409	2410	2413	2414	2420	2421	2430
2431	2432	2433	2434	2435	2445	2446	2454	2455	2457	2458	2459	2470	2471	2481
2491	2492	2494	2495	2496	2497	2499	2504	2505	2509	2512	2521	2522	2525	2526
2527	2540	2541	2550	2551	2557	2558	2568	2569	2572	2573	2574	2581	2586	2587
2593	2594	2599	2600	2608	2609	2612	2613	2614	2621	2622	2623	2625	2633	2634
2638	2639	2645	2646	2647	2649	2650	2651	2654	2655	2656	2657	2671	2676	2677
2678	2692	2693	2699	2700	2701	2702	2703	2709	2710	2711	2720	2721	2722	2723
2724	2730	2731	2732	2741	2742	2743	2744	2745	2751	2752	2753	2762	2763	2764
2765	2766	2772	2773	2774	2783	2784	2785	2786	2787	2793	2794	2795	2804	2805
2806	2807	2808	2814	2815	2816	2825	2826	2827	2828	2829	2835	2836	2837	2846
2847	2848	2849	2850	2856	2857	2858	2867	2868	2869	2870	2871	2877	2878	2879
2888	2889	2890	2891	2892	2898	2899	2900	2909	2910	2911	2912	2913	2919	2920
2921	2930	2931	2932	2933	2934	2940	2941	2942	2951	2955	2956	2957	2958	2968
2969	2970	2978	2986	2990	2991	2992	2993	2999	3000	3001	3010	3011	3012	3013
3014	3025	3026	3033	3040	3041	3042	3043	3044	3050	3051	3052	3061	3062	3063
3064	3065	3071	3072	3073	3082	3086	3089	3090	3091	3097	3098	3099	3108	3109
3112	3113	3114	3127	3128	3133	3134	3142	3145	3146	3148	3149	3150	3151	3153
3158	3169	3172	3173	3175	3176	3177	3179	3180	3185	3196	3199	3201	3202	3203
3204	3205	3210	3220	3223	3225	3226	3227	3228	3229	3234	3243	3246	3248	3249
3250	3251	3252	3257	3266	3273	3274	3275	3277	3278	3279	3280	3283	3285	3286
3287	3289	3290	3294	3302	3303	3306	3309	3310	3311	3316	3317	3318	3333	3341
3346	3347	3348	3350	3351	3352	3353	3357	3358	3359	3360	3365	3373	3374	3377
3380	3381	3382	3387	3388	3389	3405	3413	3414	3419	3420	3421	3422	3426	3427
3428	3429	3432	3439	3440	3443	3444	3445	3446	3458	3463	3464	3465	3466	3468
3470	3480	3481	3485	3486	3487	3488	3492	3495	3511	3515	3516	3517	3518	3520
3522	3534	3535	3536	3537	3538	3542	3543	3545	3547	3563	3569	3570	3571	3577
3578	3579	3580	3590	3591	3593	3602	3607	3610	3611	3612	3618	3619	3620	3629
3635	3636	3637	3643	3644	3645	3646	3656	3657	3669	3691	3695	3698	3998	4022
4027	4056	4057	4084	4085	4100	4101	4102	4103	4124	4125	4126	4127	4128	4130
4145	4146	4147	4148	4149	4165	4166	4167	4168	4169	4170	4171	4176	4179	4199
4205	4206	4207	4208	4209	4211	4212	4241	4242	4244	4247	4260	4272	4273	4276
4277	4280	4281	4305	4306	4311	4319	4334	4388	4396	4397	4398	4404	4411	4429
4430	4431	4432	4433	4459	4464	4485	4488	4505	4510	4519	4524	4529	4531	4535
4551	4552	4559	4563	4568	4569	4571	4573	4583	4589	4590	4604	4605	4606	4607
4608	4609	4610	4611	4612	4613	4614	4620	4621	4625	4626	4627	4628	4629	4630
4631	4632	4633	4659	4660	4661	4662	4663	4664	4665	4668	4669	4673	4676	4677

CZNCCA NCV11 CZNCCA.P11		DIAGNOSTIC CROSS REFERENCE			MACY11 27(654)			8-AUG-78 15:05			L 15 PAGE 181			SEQ 0193	
	4679	4680	4681	4682	4685	4687	4688	4692	4697	4701	4710	4711	4712	4713	4714
	4715	4716	4717	4718	4742	4743	4744	4745	4746	4747	4748	4749	4750	4751	4758
	4759	4760	4761	4762	4763	4764	4765	4766	4767	4784	4785	4786	4788	4792	4796
	4810	4811	4812	4813	4814	4844	4845	4846	4847	4849	4850	4851	4857	4861	4869
	4872	4880	4890	4891	4892	4893	4894	4895	4896	4912	4913	4914	4915	4916	4917
	4918	4919	4971	4972	4975	4986	4987	4991	4997	4998	5076	5146	5147	5148	5149
	5150	5155	5158	5179	5182	5200	5203	5214	5218	5222	5425	5432	5435	5436	5442
	5451	5454	5455	5516	5520	5525	5527	5532	5535	5536	5537	5564	5571	5572	5634
	5635	5636	5638	5657	5661	5672	5673	5674	5707	5708	5709	5711	5715	5733	5734
	5736	5737	5739	5740	5741	5748	5749	5771	5781	5799	5803	5806	5810	5822	5826
	5833	5834	5841	5848	5855	5858	5861	5866	5868	5869	5870	5871	5874	5884	5885
	5892	5896	5922	5929	5930	5931	5932	5939	5940	5942	5943	5944	5945	5946	5952
	5953	5954	5996	6000	6006	6008	6010	6036	6040	6044	6050	6052	6054	6057	6059
	6062	6065	6067	6070	6087	6096	6100	6114	6116	6117	6118	6127	6129	6130	6141
	6161	6183	6186	6189	6190	6191	6192	6193	6323	6335	6336	6342	6348	6356	6357
	6358	6407	6410	6417	6418	6420	6422	6424	6426	6428	6430	6441	6442	6447	6448
	6456	6460	6463	6469	6501	6504									
MOV	609	649	655	700	2534	2535	3121	3122	3659	3989	4006	4060	4066	4089	4094
	4133	4174	4177	4191	4194	4203	4275	4279	4316	4344	4352	4389	4390	4393	4394
	4395	4399	4402	4403	4422	4466	4474	4546	4547	4549	4932	4989	5171	5173	5183
	5184	5202	5215	5517	5524	5531	5573	5592	5637	5643	5645	5676	5678	5680	5701
	5753	5766	5792	5805	5887	5936	5938	6012	6013	6014	6098	6413	6449	6464	6470
	6496														
NEG	3416	4173	4400	4791	4795	4806	4807	4854	4855	4865	4884	4889	5867		
NOP	1105	1106	1107	1351	1352	1353	1354	2073	2074	2075	2077	2078	2079	2178	2179
	2180	2182	2183	2184	2212	2213	2214	2216	2217	2218	2247	2248	2249	2250	2254
	2255	2256	2258	2259	2260	2287	2288	2289	2312	2313	2314	2316	2317	2318	2335
	2336	2337	2340	2341	2342	2360	2361	2362	2365	2366	2367	2387	2388	2391	2392
	2418	2419	2437	2438	2439	2442	2443	2444	2463	2464	2465	2467	2468	2469	2531
	2532	2533	2537	2538	2539	2578	2579	2580	2583	2584	2585	2618	2619	2620	2627
	2628	2629	2661	2662	2663	2665	2666	2667	2668	2669	2670	2680	2681	2965	2966
	2967	3022	3023	3024	3118	3119	3120	3124	3125	3126	3584	3585	3587	3588	3589
	3650	3651	3653	3654	3655	3702	3703	3704	5151	5152	5153	5154	5156	5157	5160
	5193	5194	5197	5198	5199	5204	5205	5206	5207	5225	5226	5227	5422	5423	5424
	5656	5683	5684	5702	5703	5716	5717	5718	5719	5720	5721	5722	5723	5724	5725
	5726	5727	5728	5729	5730	5731	5746	5747	5754	5756	5757	5758	5759	5761	5762
	5763	5764	5765	5772	5773	5774	5775	5777	5778	5779	5780	5950	5951	5959	6166
	6167	6168	6474	6475	6477	6479	6481	6483	6485	6487	6492	6493	6494	6879	
RESET	799	903	978	1438	3700	6321									
ROL	3477	3479	3529	3531	4136	4138	4140	4406	4408	4409	4410	4412	4868	4873	5577
	5579	5581	5583	5585	5587	5589	5591								
ROR	4800	4801	5576	5578	5580	5582	5584	5586	5588	5590	5860	5905	5906	5908	5909
	5911	5912	5914	5915	5917	5918	5920	5921							
RTI	623	843	1348	2245	2624	2648	2679	4028	4076	4104	4150	4213	4282	4321	4434
	4494	4636	4752	4768	4897	4999									
RTS	4361	4533	4591	4719	4815	4938	4976	4992	5144	5208	5228	5550	5606	5663	5687
	5704	5785	6106	6139	6152	6175	6194	6436	6488	6497	6506				
SBC	4808	4856	4922												
SOB	4684														
SUB	807	810	2672	3415	4180	4465	4566	4708	4709	4921	4923	5713	5714	5760	5933
SWAB	669														
TRAP	4667	4842	5001	5010	5011	5012	5013	5015	5017	5018	5019	5020	5021	5022	
TST	641	674	683	689	704	717	732	737	763	774	778	800	802	808	814
	851	852	853	854	855	856	857	859	860	1409	2380	2405	2673	2973	3029

CZNCCA	NCV11	DIAGNOSTIC		MACY11	27(654)	8-AUG-78	15:05	M 15	PAGE 182		SEQ 0194				
CZNCCA.P11		CROSS REFERENCE		TABLE											
	3143	3170	3197	3221	3244	3322	3326	3394	3398	3451	3459	3500	3512	3552	3670
	4020	4035	4144	4185	4195	4243	4267	4318	4326	4348	4417	4479	4486	4537	4551
	4579	4581	4674	4693	4705	4809	4876	4881	4882	4887	4988	5143	5430	5544	5652
	5796	5891	5992	6084	6143	6148	6170	6184	6188	6408	6411				
TSTB	685	823	1174	1225	1400	1411	1423	1457	1471	1488	1504	1521	1538	1554	1571
	1589	1606	1624	1641	2415	3156	3183	3208	3232	3255	3987	4003	4058	4064	4187
	4201	4254	4301	4350	4553	4564	4577	4670	5074	5162	5420	5428	5440	5639	5641
.ASCII	5646	5793	5811	5878	5989	6125	6159	6328	6331	6414	6453	6461	6502		
	381	382	3952	3955	5278	5283	5322	5358	5364	6236	6246	6262	6269	6277	6284
	6292	6300	6519	6522	6531	6534	6543	6546	6555	6558	6567	6570	6579	6582	6591
	6594	6603	6606	6617	6627	6642	6652	6666	6675	6684	6692	6703	6714	6720	6730
.ASCIZ	6738	6749	6761	6791	6793	6795	6864	6868	6870						
	380	383	653	3709	3714	3720	3726	3733	3739	3745	3750	3757	3764	3771	3776
	3782	3787	3792	3797	3802	3811	3818	3826	3833	3840	3845	3851	3858	3864	3870
	3877	3884	3889	3898	3905	3912	3921	3927	3934	3936	3940	3945	4108	4109	4110
	4112	4541	4640	5242	5246	5250	5254	5258	5262	5266	5270	5275	5277	5287	5288
	5290	5294	5297	5299	5303	5306	5309	5312	5313	5317	5331	5338	5345	5351	5371
	5374	5377	5380	5382	6255	6307	6316	6527	6539	6551	6563	6575	6587	6599	6611
	6768	6771	6778	6781	6785	6867									
.BLKB	4107	4959													
.BLKW	4218	6877	6878												
.BYTE	350	351	356	357	365	366	374	375	376	377	399	400	410	411	418
	419	421	422	424	425	3708	3951	3962	4105	4106	4435	4436	4437	4438	4476
	4477	4592	4593	4594	5220	5224	5241	5245	5249	5253	5257	5261	5265	5269	5274
	5285	5337	5350	5357	5362	5365	5366	5369	5461	5464	5467	5470	5477	5480	5483
	5486	5493	5496	5499	5502	6002	6102	6198	6199	6200	6201	6202	6203	6204	6205
	6209	6210	6211	6212	6216	6217	6218	6219	6223	6224	6225	6226	6230	6231	6232
	6233	6235	6245	6254	6261	6268	6276	6283	6291	6299	6306	6315	6366	6371	6376
	6381	6387	6392	6397	6402	6521	6526	6533	6538	6545	6550	6557	6562	6569	6574
	6581	6586	6593	6598	6605	6610	6616	6626	6640	6641	6651	6665	6674	6683	6691
	6702	6712	6713	6719	6729	6736	6737	6747	6748	6758	6760	6775	6777	6784	6790
	6792	6794	6797	6799	6801	6803	6805	6807	6809	6811	6813	6815	6817	6819	6821
	6823	6825	6827	6829	6831	6833	6835	6837	6839	6841	6843	6845	6847	6849	6851
	6853	6855	6857	6859	6861	6863	6866	6869	6871						
.DSABL	4045														
.ENABL	3	3978													
.END	6881														
.ENDC	16	25	117	131	165	187	209	231	253	275	288	290	291	292	303
	311	315	317	322	324	331	344	348	350	378	379	380	381	385	388
	410	418	421	424	427	428	429	430	431	434	582	596	597	600	602
	604	606	607	608	610	612	633	637	639	645	651	653	802	825	842
	845	846	847	848	849	865	873	878	879	880	881	882	891	898	899
	900	901	902	908	911	912	913	914	915	921	924	925	926	927	928
	934	941	943	944	945	946	954	960	961	962	963	964	970	973	974
	975	976	977	982	985	986	987	988	989	994	997	998	999	1000	1001
	1009	1014	1015	1016	1017	1018	1026	1031	1032	1033	1034	1035	1043	1048	1049
	1050	1051	1052	1064	1069	1074	1079	1084	1087	1088	1089	1090	1091	1097	1100
	1101	1102	1103	1115	1123	1132	1134	1135	1136	1137	1138	1149	1151	1153	1158
	1160	1161	1162	1163	1164	1178	1181	1186	1188	1189	1190	1191	1192	1205	1209
	1211	1212	1213	1214	1215	1227	1229	1230	1231	1232	1233	1242	1245	1246	1247
	1248	1249	1271	1278	1280	1281	1282	1283	1284	1308	1315	1317	1318	1319	1320
	1321	1344	1359	1367	1368	1369	1370	1371	1384	1386	1390	1393	1394	1395	1396
	1397	1413	1416	1417	1418	1419	1420	1436	1443	1446	1447	1448	1449	1450	1460
	1463	1464	1465	1466	1467	1477	1480	1481	1482	1483	1484	1494	1496	1497	1498

1499	1500	1510	1513	1514	1515	1516	1517	1527	1530	1531	1532	1533	1534	1544
1546	1547	1548	1549	1550	1560	1563	1564	1565	1566	1567	1577	1581	1582	1593
1584	1585	1595	1598	1599	1600	1601	1602	1612	1616	1617	1618	1619	1620	1630
1633	1634	1635	1636	1637	1647	1650	1651	1652	1653	1654	1664	1667	1668	1669
1670	1671	1681	1684	1685	1686	1687	1688	1698	1701	1702	1703	1704	1705	1715
1718	1719	1720	1721	1722	1732	1735	1736	1737	1738	1739	1749	1752	1753	1754
1755	1756	1766	1769	1770	1771	1772	1773	1783	1786	1787	1788	1789	1790	1800
1803	1804	1805	1806	1807	1817	1820	1821	1822	1823	1824	1834	1837	1838	1839
1840	1841	1851	1854	1855	1856	1857	1858	1868	1871	1872	1873	1874	1875	1885
1888	1889	1890	1891	1892	1902	1905	1906	1907	1908	1909	1919	1922	1923	1924
1925	1926	1936	1939	1940	1941	1942	1943	1953	1956	1957	1958	1959	1960	1970
1973	1974	1975	1976	1977	1987	1990	1991	1992	1993	1994	2004	2007	2008	2009
2010	2011	2021	2025	2026	2027	2028	2029	2039	2043	2044	2045	2046	2047	2057
2060	2061	2062	2063	2064	2085	2087	2091	2098	2103	2110	2112	2113	2114	2115
2116	2137	2139	2142	2148	2154	2160	2164	2165	2166	2167	2168	2169	2190	2192
2198	2200	2201	2202	2203	2204	2224	2226	2232	2234	2235	2236	2237	2238	2264
2271	2272	2273	2274	2275	2278	2294	2297	2298	2299	2300	2301	2304	2323	2325
2326	2327	2328	2329	2347	2350	2351	2352	2353	2354	2372	2375	2376	2377	2378
2379	2382	2397	2400	2401	2402	2403	2404	2407	2424	2427	2428	2429	2430	2431
2449	2451	2452	2453	2454	2455	2474	2478	2479	2480	2481	2482	2508	2518	2519
2520	2521	2522	2544	2554	2561	2565	2566	2567	2568	2569	2590	2597	2603	2605
2606	2607	2608	2609	2632	2637	2642	2643	2644	2645	2646	2684	2689	2696	2697
2698	2699	2700	2714	2717	2718	2719	2720	2721	2735	2738	2739	2740	2741	2742
2756	2757	2760	2761	2762	2763	2777	2780	2781	2782	2783	2784	2798	2801	2802
2803	2804	2805	2819	2822	2823	2824	2825	2826	2840	2843	2844	2845	2846	2847
2861	2864	2865	2866	2867	2868	2882	2885	2886	2887	2888	2889	2903	2906	2907
2908	2909	2910	2924	2927	2928	2929	2930	2931	2945	2948	2949	2950	2951	2952
2973	2978	2983	2984	2985	2986	2987	3004	3007	3008	3009	3010	3011	3029	3031
3033	3037	3038	3039	3040	3041	3055	3058	3059	3060	3061	3062	3076	3079	3080
3081	3082	3083	3089	3102	3105	3106	3107	3108	3109	3131	3137	3139	3140	3141
3142	3143	3145	3161	3163	3166	3167	3168	3169	3170	3172	3188	3190	3193	3194
3195	3196	3197	3199	3213	3217	3218	3219	3220	3221	3223	3237	3240	3241	3242
3243	3244	3246	3260	3263	3264	3265	3266	3267	3298	3306	3309	3314	3316	3321
3328	3330	3333	3338	3339	3340	3341	3342	3369	3377	3380	3385	3387	3392	3394
3400	3402	3405	3410	3411	3412	3413	3414	3435	3443	3449	3451	3455	3456	3457
3458	3459	3461	3499	3502	3504	3508	3509	3510	3511	3512	3514	3551	3554	3556
3560	3561	3562	3563	3564	3569	3597	3599	3600	3601	3602	3603	3610	3623	3626
3627	3628	3629	3630	3635	3664	3665	3666	3667	3668	3669	3670	3672	3676	3678
3679	3681	3684	3690	3693	3694	3698	3700	3706	3708	3709	3712	3975	3978	3979
3981	4009	4045	4049	4077	4078	4085	4087	4090	4092	4108	4114	4117	4119	4152
4155	4222	4225	4230	4236	4238	4249	4252	4253	4254	4256	4258	4265	4269	4274
4276	4280	4283	4284	4287	4316	4366	4444	4447	4457	4464	4469	4470	4471	4479
4490	4494	4495	4499	4514	4543	4546	4547	4550	4577	4592	4603	4612	4613	4619
4625	4626	4636	4643	4646	4669	4678	4722	4727	4772	4819	4843	4901	4963	4981
4987	4990	5009	5010	5011	5012	5013	5014	5015	5016	5017	5018	5019	5020	5021
5022	5023													
.EQUIV	25	34	79	80	81	82	83	84	85	86	87	88	107	108
	109	111	112	113	114	115	116							
.EVEN	386	653	3964	4542	4595	4642	5384	6318	6759	6872				
.IF	12	89	117	143	154	176	187	198	198	220	242	264	288	289
	291	292	301	310	313	315	321	323	327	343	347	349	378	379
	384	385	387	410	418	421	424	427	428	429	430	431	432	434
	591	596	598	600	602	604	606	607	608	610	628	636	637	638
	643	652	801	824	841	844	846	848	849	864	872	877	879	881

B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P  
Q  
R  
S  
T  
U  
V  
W  
X  
Y  
Z

890	897	899	901	902	907	910	912	914	915	920	923	925	927	928	
933	940	942	944	946	953	959	961	963	964	969	972	974	976	977	
981	984	986	988	989	993	996	998	1000	1001	1008	1013	1015	1017	1018	
1025	1030	1032	1034	1035	1042	1047	1049	1051	1052	1063	1068	1073	1078	1083	
1086	1088	1090	1091	1096	1099	1101	1103	1114	1122	1131	1133	1135	1137	1138	
1148	1150	1152	1157	1159	1161	1163	1164	1177	1180	1185	1187	1189	1191	1192	
1204	1208	1210	1212	1214	1215	1226	1228	1230	1232	1233	1241	1244	1246	1248	
1249	1270	1277	1279	1281	1283	1284	1307	1314	1316	1318	1320	1321	1343	1358	
1366	1368	1370	1371	1383	1385	1389	1392	1394	1396	1397	1412	1415	1417	1419	
1420	1435	1442	1445	1447	1449	1450	1459	1462	1464	1466	1467	1476	1479	1481	
1483	1484	1493	1495	1497	1499	1500	1509	1512	1514	1516	1517	1526	1529	1531	
1533	1534	1543	1545	1547	1549	1550	1559	1562	1564	1566	1567	1576	1580	1582	
1584	1585	1594	1597	1599	1601	1602	1611	1615	1617	1619	1620	1629	1632	1634	
1636	1637	1646	1649	1651	1653	1654	1663	1666	1668	1670	1671	1680	1683	1685	
1687	1688	1697	1700	1702	1704	1705	1714	1717	1719	1721	1722	1731	1734	1736	
1738	1739	1748	1751	1753	1755	1756	1765	1768	1770	1772	1773	1782	1785	1787	
1789	1790	1799	1802	1804	1806	1807	1816	1819	1821	1823	1824	1833	1836	1838	
1840	1841	1850	1853	1855	1857	1858	1867	1870	1872	1874	1875	1884	1887	1889	
1891	1892	1901	1904	1906	1908	1909	1918	1921	1923	1925	1926	1935	1938	1940	
1942	1943	1952	1955	1957	1959	1960	1969	1972	1974	1976	1977	1986	1989	1991	
1993	1994	2003	2006	2008	2010	2011	2020	2024	2026	2028	2029	2038	2042	2044	
2046	2047	2056	2059	2061	2063	2064	2084	2086	2090	2097	2102	2109	2111	2113	
2115	2116	2136	2138	2141	2147	2153	2159	2163	2164	2166	2168	2169	2189	2191	
2197	2199	2201	2203	2204	2223	2225	2231	2233	2235	2237	2238	2263	2270	2272	
2274	2275	2277	2293	2296	2298	2300	2301	2303	2322	2324	2326	2328	2329	2346	
2349	2351	2353	2354	2371	2374	2376	2378	2379	2381	2396	2399	2401	2403	2404	
2406	2423	2426	2428	2430	2431	2448	2450	2452	2454	2455	2473	2477	2479	2481	
2482	2507	2517	2519	2521	2522	2543	2553	2560	2564	2566	2568	2569	2589	2596	
2602	2604	2606	2608	2609	2631	2636	2641	2643	2645	2646	2683	2688	2695	2697	
2699	2700	2713	2716	2718	2720	2721	2734	2737	2739	2741	2742	2755	2758	2760	
2762	2763	2776	2779	2781	2783	2784	2797	2800	2802	2804	2805	2818	2821	2823	
2825	2826	2839	2842	2844	2846	2847	2860	2863	2865	2867	2868	2881	2884	2886	
2888	2889	2902	2905	2907	2909	2910	2923	2926	2928	2930	2931	2944	2947	2949	
2951	2952	2972	2977	2982	2984	2986	2987	3003	3006	3008	3010	3011	3028	3030	
3032	3036	3038	3040	3041	3054	3057	3059	3061	3062	3075	3078	3080	3082	3083	
3088	3101	3104	3106	3108	3109	3130	3136	3138	3140	3142	3143	3144	3160	3162	
3165	3167	3169	3170	3171	3187	3189	3192	3194	3196	3197	3198	3212	3216	3218	
3220	3221	3222	3236	3239	3241	3243	3244	3245	3259	3262	3264	3266	3267	3297	
3305	3308	3313	3315	3320	3327	3329	3332	3337	3339	3341	3342	3368	3376	3379	
3384	3386	3391	3393	3399	3401	3404	3409	3411	3413	3414	3434	3442	3448	3450	
3454	3456	3458	3459	3460	3498	3501	3503	3507	3509	3511	3512	3513	3550	3553	
3555	3559	3561	3563	3564	3568	3596	3598	3600	3602	3603	3609	3622	3625	3627	
3629	3630	3634	3663	3665	3667	3669	3670	3671	3675	3676	3677	3678	3679	3680	
3681	3683	3689	3692	3694	3698	3700	3706	3708	3709	3977	3979	3980	3981	4009	
4048	4049	4077	4085	4086	4090	4091	4107	4108	4114	4116	4119	4131	4154	4221	
4224	4229	4235	4236	4248	4250	4251	4252	4254	4255	4256	4265	4267	4275	4277	
4282	4283	4284	4286	4307	4365	4443	4446	4457	4460	4467	4469	4470	4472	4479	
4483	4490	4494	4495	4498	4513	4529	4545	4547	4550	4577	4592	4602	4612	4613	
4618	4625	4626	4634	4636	4640	4645	4649	4668	4676	4726	4771	4818	4843	4900	
4962	4980	4986	4990	5001	5010	5011	5012	5013	5014	5015	5017	5018	5019	5020	
5021	5022	5023													
.IFDF	877														
.IFF	23	288	290	291	292	311	315	317	322	324	331	344	347	350	378
	385	388	596	636	638	802	824	842	845	846	847	848	865	873	878



.IRP	5015	5017	5018	5019	5020	5021	5022	959	972	984	996	1013	1030	1047	1086
	582	844	877	897	910	923	942	1279	1316	1366	1392	1415	1445	1462	1479
	1099	1133	1159	1187	1210	1228	1244	1615	1632	1649	1666	1683	1700	1717	1734
	1495	1512	1529	1545	1562	1580	1597	1870	1887	1904	1921	1938	1955	1972	1989
	1751	1768	1785	1802	1819	1836	1853	2233	2270	2296	2324	2349	2374	2399	2426
	2006	2024	2042	2059	2111	2164	2199	2716	2737	2758	2779	2800	2821	2842	2863
	2450	2477	2517	2564	2604	2641	2695	3057	3078	3104	3138	3165	3192	3216	3239
	2884	2905	2926	2947	2982	3006	3036	3625	3665	4126	4147	4165	4205	4235	4551
	3262	3337	3409	3454	3507	3559	3598	4626	4742	4762	4784	4812	4844	4892	
	4552	4573	4589	4590	4606	4612	4625	582	612	637	640	653	844	848	877
.LIST	1	131	291	298	378	385	388	942	946	959	963	972	976	984	988
	881	897	901	910	914	923	927	1051	1086	1090	1099	1103	1133	1137	1159
	996	1000	1013	1017	1030	1034	1047	1244	1248	1279	1283	1316	1320	1366	1370
	1163	1187	1191	1210	1214	1228	1232	1466	1479	1483	1495	1499	1512	1516	1529
	1392	1396	1415	1419	1445	1449	1462	1597	1601	1615	1619	1632	1636	1649	1653
	1533	1545	1549	1562	1566	1580	1584	1721	1734	1738	1751	1755	1768	1772	1785
	1666	1670	1683	1687	1700	1704	1717	1853	1857	1870	1874	1887	1891	1904	1908
	1789	1802	1806	1819	1823	1836	1840	1976	1989	1993	2006	2010	2024	2028	2042
	1921	1925	1938	1942	1955	1959	1972	2199	2203	2233	2237	2270	2274	2296	2300
	2046	2059	2063	2111	2115	2164	2168	2403	2426	2430	2450	2454	2477	2481	2517
	2324	2328	2349	2353	2374	2378	2399	2695	2699	2716	2720	2737	2741	2758	2762
	2521	2564	2568	2604	2608	2641	2645	2846	2863	2867	2884	2888	2905	2909	2926
	2779	2783	2800	2804	2821	2825	2842	3036	3040	3057	3061	3078	3082	3104	3108
	2930	2947	2951	2982	2986	3006	3010	3220	3239	3243	3262	3266	3337	3341	3409
	3138	3142	3165	3169	3192	3196	3216	3598	3602	3625	3629	3665	3669	3684	3700
	3413	3454	3458	3507	3511	3559	3563	5012	5013	5014	5015	5016	5017	5018	5019
	4077	4229	4490	5001	5009	5010	5011								
.MACRO	5020	5021	5022	5023				5001							
	292	341	582	628	1444	1649	2695	612	640						
.MCALL	6	7	8	9	10	131	385								
.MEXIT	433														
.NLIST	2	131	291	298	378	385	388	582	612	637	640	653	844	848	877
	881	897	901	910	914	923	927	942	946	959	963	972	976	984	988
	996	1000	1013	1017	1030	1034	1047	1051	1086	1090	1099	1103	1133	1137	1159
	1163	1187	1191	1210	1214	1228	1232	1244	1248	1279	1283	1316	1320	1366	1370
	1392	1396	1415	1419	1445	1449	1462	1466	1479	1483	1495	1499	1512	1516	1529
	1533	1545	1549	1562	1566	1580	1584	1597	1601	1615	1619	1632	1636	1649	1653
	1666	1670	1683	1687	1700	1704	1717	1721	1734	1738	1751	1755	1768	1772	1785
	1789	1802	1806	1819	1823	1836	1840	1853	1857	1870	1874	1887	1891	1904	1908
	1921	1925	1938	1942	1955	1959	1972	1976	1989	1993	2006	2010	2024	2028	2042
	2046	2059	2063	2111	2115	2164	2168	2199	2203	2233	2237	2270	2274	2296	2300
	2324	2328	2349	2353	2374	2378	2399	2403	2426	2430	2450	2454	2477	2481	2517
	2521	2564	2568	2604	2608	2641	2645	2695	2699	2716	2720	2737	2741	2758	2762
	2779	2783	2800	2804	2821	2825	2842	2846	2863	2867	2884	2888	2905	2909	2926
	2930	2947	2951	2982	2986	3006	3010	3036	3040	3057	3061	3078	3082	3104	3108
	3138	3142	3165	3169	3192	3196	3216	3220	3239	3243	3262	3266	3337	3341	3409
	3413	3454	3458	3507	3511	3559	3563	3598	3602	3625	3629	3665	3669	3684	3700
	4077	4229	4490	5001	5009	5010	5011	5012	5013	5014	5015	5016	5017	5018	5019
	5020	5021	5022	5023											
.PAGE	341	434	2270												
.REPT	298	3472	3524	5576	5716	5904	6476	6799							
.SBTTL	21	131	281	292	301	308	319	341	385	434	590	633	640	654	682
	695	844	877	897	910	923	942	959	972	984	996	1013	1030	1047	1086
	1099	1133	1159	1187	1210	1228	1244	1279	1316	1366	1392	1415	1445	1462	1479

	1495	1512	1529	1545	1562	1580	1597	1615	1632	1649	1666	1683	1700	1717	1734
	1751	1768	1785	1802	1819	1836	1853	1870	1887	1904	1921	1938	1955	1972	1999
	2006	2024	2042	2059	2111	2164	2199	2233	2270	2296	2324	2349	2374	2399	2426
	2450	2477	2517	2564	2604	2641	2695	2716	2737	2779	2779	2800	2821	2842	2863
	2884	2905	2926	2947	2982	3006	3036	3057	3078	3104	3138	3165	3192	3216	3239
	3262	3337	3409	3454	3507	3559	3598	3625	3665	3673	3712	3975	4114	4152	4219
	4284	4363	4441	4496	4543	4600	4643	4724	4769	4816	4898	4960	4978	5001	5024
.TITLE	11														
.WORD	298	299	300	316	335	336	337	338	339	340	349	352	353	354	355
	358	359	360	361	362	363	364	367	368	369	390	391	392	393	394
	395	396	397	401	402	403	416	420	423	426	427	428	429	430	431
	3689	3692	3707	3965	3966	3968	3970	3973	3974	4151	4313	4360	4439	4522	4527
	4575	4635	4671	4720	4721	4934	4977	5008							

ERRORS DETECTED: 0



CZNCCA NCV11 DIAGNOSTIC MACY11 27(654) 8-AUG-78 15:05 F 16  
CZNCCA.P11 PAGE 188

SEQ 0200

\*CZNCCA,CZNCCA/CRF/SOL=CZNCCA  
RUN-TIME: 43 31 6 SECONDS  
CORE USED: 30K