

RM02/03/05

RM05/3/2 FCTNL TST 2
CZRMNBO

AH-F925B-MC
FICHE 1 OF 2

AUG 1981
COPYRIGHTS 80-81
MADE IN USA



The main body of the document is a large, dense grid of data. Each cell in the grid contains a small, structured table or form. The text within these cells is extremely faint and difficult to read, but the overall layout suggests a comprehensive data set or a series of related forms. The grid covers most of the page area below the header.

RM02/03/05

RM05/3/2 FCTNL TST 2
CZRMNBO

AH-F925B-MC
FICHE 2 OF 2

AUG 1981
COPYRIGHT © 80-81
MADE IN USA



.REM \

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44

IDENTIFICATION

PRODUCT CODE: AC-F924B-MC
PRODUCT NAME: CZRMNBO RM05/3/2 FUNCTIONAL TEST, PT 2
PRODUCT DATE: APRIL 1981
MAINTAINER: CX DIAGNOSTIC GROUP
AUTHOR: MIKE LEAVITT

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS MANUAL.

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED UNDER A LICENSE AND MAY ONLY BE USED OR COPIED IN ACCORDANCE WITH THE TERMS OF SUCH LICENSE.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

COPYRIGHT (C) 1980,1981 DIGITAL EQUIPMENT CORPORATION

CONTENTS

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43

- 1. INTRODUCTION
 - 1. ABSTRACT
 - 2. UNIT UNDER TEST
- 2. OPERATING REQUIREMENTS
 - 1. HARDWARE REQUIREMENTS
 - 2. MEDIA REQUIREMENTS
 - 3. PREREQUISITE DIAGNOSTIC PROGRAMS
- 3. OPERATING PROCEDURE
 - 1. LOADING
 - 2. SWITCH OPTIONS
 - 3. STARTING
 - 4. HALTING
 - 5. RESTARTING
- 4. OPERATOR INTERFACE
 - 1. PROGRAM I.D.
 - 2. CONSOLE DIALOGUE
 - 3. PROGRESS REPORTS
 - 4. PERFORMANCE REPORTS
 - 5. PROGRAM HALTS
 - 6. ERROR REPORTS
 - 7. EXECUTION TIME
- 5. ENVIRONMENTAL SUPPORT
 - 1. PROCESSOR COMPATIBILITY
 - 2. DUAL PORT CONFIGURATIONS
 - 3. MEMORY PARITY HARDWARE
 - 4. MEMORY MANAGEMENT HARDWARE
 - 5. ACT, APT COMPATIBILITY
 - 6. XXDP COMPATIBILITY
 - 7. OPERATING SYSTEM COMPATIBILITY
- 6. TEST DESCRIPTION

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57

1.0 INTRODUCTION

1.1 ABSTRACT

THE RM05/3/2 SUBSYSTEM FUNCTIONAL TEST IS A STAND ALONE PROGRAM WHICH USES FUNCTIONAL MEANS TO VERIFY THE OPERABILITY OF THE RM05/3/2 DISK SUBSYSTEM. IN PARTICULAR, THE PROGRAM SERVES THE FOLLOWING PURPOSES:

TO EXPLICITLY ESTABLISH CONFIDENCE IN THE BASIC OPERATIONS OF THE DISK DRIVE, INCLUDING MECHANICAL POSITIONING AND DATA TRANSFER OPERATIONS;

TO IMPLICITLY ESTABLISH CONFIDENCE IN THE DRIVE/ADAPTER ELECTRICAL INTERFACE;

TO VERIFY THE FUNCTIONALITY OF THE RM05/3/2 SUBSYSTEM, INCLUDING THE MASSBUS CONTROLLER, MASSBUS ADAPTER AND THE DISK DRIVE.

THE TEST IS COMPRISED OF 3 PARTS, WHICH WOULD NORMALLY BE RUN IN SEQUENCE, STARTING WITH PART 1. BRIEFLY, PART 1 TESTS HOUSEKEEPING AND MECHANICAL POSITIONING OPERATIONS; PART 2 TESTS WRITE, READ AND WRITE CHECK OPERATIONS USING HEADER AND DATA; PART 3 TESTS WRITE, READ AND WRITE CHECK OPERATIONS USING DATA.

1.2 UNIT UNDER TEST

THE UNIT UNDER TEST (UUT) IS THE RM05/3/2 DISK SUBSYSTEM WHICH CONSISTS OF THE RH MASSBUS CONTROLLER, THE RM05/3/2 MASSBUS ADAPTER, AND THE STORAGE MODULE DISK DRIVE. NOTE THAT A DISK PACK IS REQUIRED FOR TESTING AND IS CONSIDERED AN INTEGRAL OF THE STORAGE MODULE DISK DRIVE.

2.0 OPERATING REQUIREMENTS

2.1 HARDWARE REQUIREMENTS

THE FOLLOWING MINIMUM HARDWARE CONFIGURATION, ASSUMED TO BE OPERATIONAL, IS REQUIRED TO LOAD AND EXECUTE THE RM05/3/2 SUBSYSTEM FUNCTIONAL TEST:

PDP-11 PROCESSOR
20K MEMORY
KW11-L OR KW11-P CLOCK
PROGRAM LOADING DEVICE
TERMINAL
RH11 OR RH70 CONTROLLER
1 TO 8 DISK DRIVES (ANY COMBINATION OF RM05'S, RM03'S OR RM02'S)

58
59
60
61
62
63
64
65
66
67
68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114

2.2 MEDIA REQUIREMENTS

EACH UNIT BEING TESTED MUST BE LOADED WITH A SCRATCH DISK PACK BEFORE TESTING BEGINS ON THAT UNIT. THE DISK MUST BE FORMATTED AND CONTAIN A READABLE COPY OF THE MFG AND USR BAD SECTOR FILES.

2.3 PREREQUISITE DIAGNOSTIC PROGRAMS

RM05/3/2 DISKLESS TEST, PART 1 & 2
RM05/3/2 FUNCTIONAL TEST, PART 1

3.0 OPERATING PROCEDURE

3.1 LOADING

THE PROGRAM MAY BE LOADED BY EITHER OF THE FOLLOWING MEDIA:

- .PAPER TAPE, USING THE STANDARD PAPER TAPE LOADING PROCEDURE.
- .XXDP MEDIA, USING THE APPROPRIATE LOADING DEVICE.

3.2 SWITCH OPTIONS

THE FOLLOWING SWITCH OPTIONS ARE PROVIDED TO ENHANCE THE UTILITY OF THE PROGRAM.

- SW15 HALT ON ERROR
- SW14 LOOP ON TEST (CURRENTLY BEING EXECUTED)
- SW13 INHIBIT ERROR TYPEOUTS
- SW12 UNUSED
- SW11 INHIBIT TEST ITERATIONS
- SW10 BELL ON ERROR
- SW09 LOOP ON ERROR
- SW08 LOOP ON TEST IN SW07-00

THE LOW ORDER 8 SWITCHES (SW07-SW00), ARE USED IN CONJUNCTION WITH SW08 TO SPECIFY THE OCTAL NUMBER OF THE TEST WHICH THE PROGRAM WILL LOOP ON.

3.3 STARTING

THE PROGRAM MAY BE STARTED AT LOCATION 200 OR 204. STARTING AT 200 WILL BE THE NORMAL STARTING ADDRESS. STARTING AT 204 WILL ENABLE THE RH/RM BASE ADDRESS TO BE CHANGED. IF RUNNING IN A STAND-ALONE ENVIRONMENT, THE PROGRAM USES CONSOLE DIALOGUE TO ALLOW THE OPERATOR TO CONTROL TEST CONDITIONS.

115
116
117
118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167
168
169
170
171

3.4 HALTING

THE PROGRAM SHOULD BE HALTED BY TYPING CONTROL C FROM THE CONSOLE.

NOTE: IF THE PROGRAM IS HALTED BY ANY OTHER MEANS, BAD HEADER INFORMATION MAY BE LEFT ON THE DISK PACK. THIS OF COURSE DEPENDS ON WHICH TEST IS BEING PERFORMED AT THE TIME OF THE HALT.

3.5 RESTARTING

THE PROGRAM CAN BE RESTARTED AT ADDRESS 200 OR 204. (SEE SECTION 3.3)

4.0 OPERATOR INTERFACE

4.1 PROGRAM ID

THE PROGRAM TYPES ITS TITLE AND MAINDEC NUMBER THE FIRST TIME IT IS STARTED AFTER BEING LOADED. ALSO, A WARNING MESSAGE IS TYPED, NOTIFYING THE OPERATOR OF POSSIBLE HEADER CORRUPTION IF THE PROGRAM IS HALTED IMPROPERLY. THE PROGRAM IDENTIFICATION AND THE WARNING DO NOT OCCUR IF THE PROGRAM IS RESTARTED.

4.2 CONSOLE DIALOGUE

WHEN THE PROGRAM IS RUNNING IN STAND ALONE MODE, IT ENTERS A CONSOLE DIALOGUE SEQUENCE AFTER TYPING THE PROGRAM I.D. AND WARNING MESSAGE. (SEE SECTION 4.1)

THE FIRST QUESTION TYPED OUT IS: "TYPE HELP TEXT (L) N ?". IF THE OPERATOR RESPONDS WITH A 'Y', THE PROGRAM WILL TYPE A BRIEF HELP MESSAGE WHICH WILL LIST SWITCH OPTIONS, ETC. ANY OTHER RESPONSE TO THE QUESTION IS CONSIDERED A 'N' AND NO HELP TEXT IS TYPED. THIS QUESTION IS ONLY ASKED ON THE INITIAL PROGRAM START AND NOT ON SUBSEQUENT START-UP'S.

ON THE PROGRAM INITIAL START AND WHEN RESTARTING AT LOCATION 204, THE OPERATOR MAY CHANGE THE RH/RM BASE ADDRESSES WITH THE FOLLOWING DIALOGUE.

EXAMPLE 1

```
RMCS1=176700 <CR>      ;NO CHANGE IN ADDRESS  
RMVEC=000254 <CR>      ;NO CHANGE IN ADDRESS
```

EXAMPLE 2

```
RMCS1=176700 177200<CR> ;CHANGE BASE ADDRESS TO 177200  
RMVEC=000254 260<CR>   ;CHANGE VECTOR ADDRESS TO 260
```

ON THE INITIAL START, THE NEXT QUESTION TYPED IS, 'TYPE 'A' TO

172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196
197
198
199
200
201
202
203
204
205
206
207
208
209
210
211
212
213
214
215
216
217
218
219
220
221
222
223
224
225
226
227
228

TEST ALL DRIVES, OR TYPE DRIVE NUMBER(S) AND TERMINATE INPUT WITH A CARRIAGE RETURN'. THEN, 'DRIVE(S):' IS TYPED AND WAITS FOR THE OPERATOR TO TYPE AN 'A', TO TEST ALL POSSIBLE DRIVES OR TYPE ANY STRING OF DRIVE NUMBER(S) TO BE TESTED AND TERMINATE THE INPUT WITH A 'CARRIAGE RETURN'. NO COMMAS OR ANY OTHER SEPARATORS ARE NEEDED WHEN ENTERING THE DRIVE NUMBERS AS A STRING. THE PROGRAM ENTERS THE COMMA SEPARATOR AUTOMATICALLY AFTER TYPING EACH NUMBER. ON ALL SUBSEQUENT STARTS, ONLY THE 'DRIVE(S):' PROMPT IS TYPED.

THE DIAGNOSTIC THEN INITIALIZES AND REPORTS THE STATUS OF THE DRIVES WHICH WERE PREVIOUSLY SPECIFIED FOR TESTING. THE FOLLOWING IS AN EXAMPLE PRINTOUT:

```
'UNIT STATUS:
0   ONLINE   RM03
1   LOAD DEVICE
2   OFFLINE  RM05
3   NOT PRESENT
4   NOT PRESENT
5   NOT AN RM05/3/2
6   NOT PRESENT
7   NOT PRESENT'
```

THE ABOVE UNIT STATUS SHOWS THAT DRIVE 0 WILL BE TESTED, WHILE DRIVES 1 - 7 WILL NOT BE TESTED.

THE DIAGNOSTIC THEN TYPES THE FOLLOWING MESSAGE, BASED ON THE STATUS OF THE DRIVE:

```
'DRIVE(S) TO BE TESTED, 0'
```

IF NO DRIVES ARE AVAILABLE FOR TESTING, THE FOLLOWING MESSAGE WILL BE TYPED TO THE OPERATOR:

```
'DRIVE(S) TO BE TESTED, NONE'
```

THE PROGRAM WILL THEN, EITHER START TESTING THE DRIVES AVAILABLE FOR TESTING OR RETURN TO THE BEGINNING OF THE PROGRAM AND WAIT.

ONCE THE DRIVES START TESTING, THE FOLLOWING MESSAGE WILL OCCUR AS EACH DRIVE BEGINS TO BE TESTED:

```
'DRIVE 0'
```

AFTER ALL THE DRIVES ARE COMPLETELY TESTED, THE END OF PASS MESSAGE WILL BE TYPED (SEE SECTION 4.3) AND THE PROGRAM WILL START TESTING ALL THE DRIVES AGAIN. THIS WILL CONTINUE UNTIL THE PROGRAM IS HALTED BY THE OPERATOR.

NOTE: THE LETTER LOCATED WITHIN THE BRACKETS () INDICATES THE TYPE OF RESPONSE REQUIRED BY THE USER, D=DECIMAL, O=OCTAL AND L=LETTER.

4.3 PROGRESS REPORTS

229
230
231
232
233
234
235
236
237
238
239
240
241
242
243
244
245
246
247
248
249
250
251
252
253
254
255
256
257
258
259
260
261
262
263
264
265
266
267
268
269
270
271
272
273
274
275
276
277
278
279
280
281
282
283
284
285

AN END OF PASS REPORT OCCURS EACH TIME THE PROGRAM IS EXECUTED FOR ALL DEVICES IN THE TEST QUE. THE END OF PASS REPORT IS AS FOLLOWS.

'END OF PASS 1'

THE FOLLOWING MESSAGE WILL ALSO OCCUR IF THERE WERE ERRORS SINCE THE LAST END OF PASS REPORT.

'TOTAL ERRORS SINCE LAST REPORT 0'

4.4 PERFORMANCE REPORT

NO PERFORMANCE REPORTS ARE GIVEN DURING THE EXECUTION OF THE PROGRAM.

4.5 PROGRAM HALTS

THERE ARE NO SCHEDULED HALTS DURING THE EXECUTION OF THE PROGRAM. PROCESSOR HALTS ARE DUE TO THE TRAP CATCHER.

4.6 ERROR REPORTS

THE FIRST LINE OF THE ERROR REPORT CONTAINS THE NUMBER OF THE UNIT (DRIVE) BEING TESTED, THE DRIVE TYPE, THE TEST NUMBER, THE ERROR NUMBER AND THE VALUE OF THE PROGRAM COUNTER WHERE THE ERROR WAS CALLED. THIS LINE IS FOLLOWED BY THE ERROR MESSAGE: ONE OR MORE LINES OF TEXT WHICH GIVE A BRIEF, YET COMPREHENSIVE DESCRIPTION OF THE ERROR. THE ERROR MESSAGE IS NORMALLY FOLLOWED BY ONE OR MORE PAIRS OF LINES CONTAINING DATA HEADERS AND DATA PERTINENT TO THE ERROR, INCLUDING EXPECTED AND ACTUAL TEST RESULTS.

THE FOLLOWING PRINTOUT SHOWS A TYPICAL ERROR MESSAGE FOR THIS PROGRAM:

```
DRV# 0 - RM03, TEST# 14, ERR# 326, PC=016654
MASSBUS DATA BUS PARITY ERROR 'MDPE' (RMCS2, BIT 8) DETECTED
DURING WRITE COMMAND
EXPECTD      RECEVD
040300      040700
RMCS1      RMCS2      RMDS      RMER1      RMER2      RMAS
144252      040700      010700      000000      000000      000000
RMWC      RMBA      RMDA      RMOF      RMDC      RMEC1      RMEC2
177403      104604      000002      010000      000000      004066      000000
RMMR1      RMMR2      RMDT      RMSN
000010      011777      024026      177777
```

4.7 EXECUTION TIME

PASS 1 OF THE PROGRAM TAKES ABOUT 6 SECONDS. PASS 2 AND SUBSEQUENT PASSES TAKE 35 SECONDS.

286
287
288
289
290
291
292
293
294
295
296
297
298
299
300
301
302
303
304
305
306
307
308
309
310
311
312
313
314
315
316
317
318
319
320
321
322
323
324
325
326
327
328
329
330
331
332
333
334
335
336
337
338
339
340
341
342

5.0 ENVIRONMENTAL SUPPORT

5.1 PROCESSOR COMPATIBILITY

THE RM05/3/2 SUBSYSTEM FUNCTIONAL TEST IS EXECUTABLE ON ANY PDP-11 PROCESSOR, PROVIDING PREVIOUSLY MENTIONED HARDWARE REQUIREMENTS ARE MET, AND PROVIDING THAT DATA THROUGHPUT ON THE SYSTEM IS SUFFICIENT TO SUSTAIN DATA TRANSFER OPERATIONS.

5.2 DUAL PORT CONFIGURATIONS

THE RM05/3/2 SUBSYSTEM FUNCTIONAL TEST DOES NOT SPECIFICALLY TEST DUAL PORT LOGIC IN THE RM05/3/2 ADAPTER BUT IS EXECUTABLE ON RM05/3/2 SUBSYSTEMS HAVING THE DUAL PORT OPTION PROVIDING THE DUAL PORT SWITCH IS SET TO THE APPROPRIATE PORT (A OR B).

5.3 MEMORY PARITY HARDWARE

MEMORY PARITY HARDWARE IS NOT USED DURING THE EXECUTION OF THE RM05/3/2 SUBSYSTEM FUNCTIONAL TEST.

5.4 MEMORY MANAGEMENT HARDWARE

MEMORY MANAGEMENT HARDWARE IS NOT USED DURING THE RM05/3/2 SUBSYSTEM FUNCTIONAL TEST. CAPABILITIES OF THE MASSBUS CONTROLLER.

5.5 ACT11, APT11 COMPATIBILITY

THE RM05/3/2 SUBSYSTEM FUNCTIONAL TEST IS COMPATIBLE WITH ACT11 AND APT11 IN BOTH DUMP AND AUTOMATIC MODES. FURTHER, THE PROGRAM WILL EXECUTE A QUICK PASS DURING THE FIRST PASS IN SUPPORT OF QUICK VERIFY MODE.

5.6 XXDP COMPATIBILITY

THE RM05/3/2 SUBSYSTEM FUNCTIONAL TEST IS COMPATIBLE WITH XXDP IN DUMP AND CHAIN MODES, AND PROVIDES MEDIA PROTECTION IN THE CASE WHERE THE RM05/3/2 IS THE XXDP LOADING DEVICE.

5.7 OPERATING SYSTEM COMPATIBILITY

THE PROGRAM IS NOT COMPATIBLE WITH ANY SOFTWARE OPERATING SYSTEM.

6.0 TEST DESCRIPTION

TEST 1 CONTROLLER ACCESS TEST

PURPOSE:

TO VERIFY THAT THE UNIBUS ADDRESS OF THE SUBSYSTEM IS CORRECT, AS DEFINED AT LOCATION \$BASE.

PROCEDURE:

THE TEST TRIES TO ACCESS ALL MASSBUS CONTROLLER REGISTERS USING THE \$BASE ADDRESS. REGISTER CONTENTS ARE IGNORED DURING THE TEST, AND THE TEST FAILS IF A BUS TIMEOUT OCCURS FOR ANY REGISTER TRANSFER.

IF THE TEST FAILS AND THE PROGRAM IS RUNNING IN A STAND ALONE ENVIRONMENT, I.E., LOCATION 42 IS 0, THE PROGRAM WILL JUMP TO LOCATION 204 WHICH ALLOWS THE OPERATOR TO CHANGE THE \$BASE ADDRESS VIA CONSOLE DIALOGUE. OTHERWISE, THE PROGRAM ESCAPES TO THE END OF PASS HANDLER.

TEST 2 - 31 WRITE/READ HEADER AND DATA (FORMAT) TESTS

PURPOSE:

TO TEST WRITE HEADER AND DATA AND READ HEADER AND DATA FUNCTIONALITY OF THE RM05/3/2 SUBSYSTEM USING A SET OF VARIABLES WHICH INCLUDE WORD COUNT, HEAD MOTION, HEAD SWITCHING AND ERROR CONDITIONS.

PROCEDURE:

ALTHOUGH EACH TEST EXERCISES A DIFFERENT VARIABLE, THE GENERAL PROCEDURE OF EACH TEST IS THE SAME. THE DRIVE IS INITIALIZED AND RECALIBRATED IF 'PIP' OR 'SKI' ARE ACTIVE SO THAT THERE ARE NO ERRORS WHEN A TEST BEGINS. FOLLOWING THAT, THE TEST PERFORMS ANY EXPLICIT SEEKS REQUIRED FOR THE CONDITIONS OF THE TEST. REGISTERS ARE PRESET AND THE WRITE HEADER AND DATA COMMAND IS EXECUTED. WHEN THE WRITE COMMAND IS COMPLETE, THE TEST STORES ALL SUBSYSTEM STATUS AND CHECKS FOR PRIMARY ERRORS WHICH PRECLUDE OTHER STATUS CHECKS. IF THERE ARE NO PRIMARY ERRORS, THE TEST VERIFIES THE RESULTS OF THE WRITE COMMAND AND THEN CHECKS FOR SECONDARY ERRORS. LOOP ADDRESSES ARE MODIFIED FOLLOWING THE SUCCESSFUL COMPLETION OF THE WRITE COMMAND IN ORDER TO SHORTEN EXECUTION TIMES AND ENHANCE SCOPING LOOPS, THEN THE PROGRAM EXECUTES THE READ HEADER AND DATA PORTION OF THE TEST, VERIFYING THE SAME TYPE OF ERRORS AS IN THE WRITE COMMAND.

400
401
402
403
404
405
406
407
408
409
410
411
412
413
414
415
416
417
418
419
420
421
422
423
424
425
426
427
428
429
430
431
432
433
434
435
436
437
438
439
440
441
442
443
444
445
446
447
448
449
450
451
452
453
454
455
456

NOTE: THE SECTOR USED DURING A TEST MAY DIFFER FROM THE PROGRAM LISTING BECAUSE THE PROGRAM SUBSTITUTES A GOOD SECTOR, IF THE ONE SELECTED IS LISTED IN THE BAD BLOCK TABLE.

TEST 2 FORMAT ZEROS TEST

THE TEST SEEKS TO CYLINDER 0, THEN WRITES HEADER AND DATA ON SECTOR 0 IN 18 BIT FORMAT. THE HEADER AND DATA FIELDS ARE ALL ZEROS, CAUSING THE DEVICE TO USE NORMAL WRITE GATE. THE HEADER AND DATA ARE READ AND COMPARED WITH THE WRITE BUFFER. THE INITIAL SEEK POSITIONS THE HEAD SUCH THAT THERE IS NO IMPLIED SEEK. THE TEST IS REPEATED FOR 16 BIT FORMAT.

TEST 3 ZERO FILL TEST TEST

THE TEST EXECUTES A SEEK TO CYLINDER 0 TO INSURE THAT THERE IS NO HEAD MOTION DURING DATA TRANSFER. THIS IS FOLLOWED BY A WRITE HEADER AND DATA COMMAND WITH THE WORD COUNT EQUAL TO THE SIZE OF THE HEADER WHICH CAUSES THE RH TO ZERO FILL THE DATA FIELD. THE READ HEADER AND DATA COMMAND THAT FOLLOWS READS A FULL SECTOR AND VERIFIES THAT DATA WAS ZERO FILLED.

TEST 4. FORMAT CHECK ZEROS TEST

THE TEST WRITES HEADER AND AN ALL ZEROS DATA FIELD, THEN PERFORMS A WRITE CHECK HEADER AND DATA COMMAND AND VERIFIES THERE ARE NO ERRORS.

TEST 5 FORMAT CHECK ZEROS W/ WCE ERROR TEST

THE TEST WRITES HEADER AND AN ALL ZEROS DATA FIELD. AFTER COMPLEMENTING THE LAST WORD OF THE WRITE BUFFER, THE TEST PERFORMS A WRITE CHECK HEADER AND DATA COMMAND AND VERIFIES THAT THE CORRECT WRITE CHECK ERROR IS DETECTED.

TEST 6 FORMAT ONES TEST

457
458
459
460
461
462
463
464
465
466
467
468
469
470
471
472
473
474
475
476
477
478
479
480
481
482
483
484
485
486
487
488
489
490
491
492
493
494
495
496
497
498
499
500
501
502
503
504
505
506
507
508
509
510
511
512
513

THE TEST WRITES HEADER AND AN ALL ONES DATA FIELD, THEN READS THE HEADER AND DATA, VERIFYING THE READ BUFFER WITH THE WRITE BUFFER. THE ALL ONES FIELD IS A CONSTANT FREQUENCY, AND THE DRIVE SHOULD USE NORMAL WRITE GATE.

TEST 7 FORMAT CHECK ONES TEST

THE TEST FORMATS AN ALL ONES DATA FIELD, THEN PERFORMS A WRITE CHECK HEADER AND DATA COMMAND, VERIFYING THAT THERE ARE NO ERRORS.

TEST 10 FORMAT CHECK ONES W/ WCE ERROR TEST

THE TEST FORMATS AN ALL ONES DATA FIELD, THEN COMPLEMENTS THE LAST WORD OF THE WRITE BUFFER. A WRITE CHECK HEADER AND DATA COMMAND IS EXECUTED, AND THE TEST VERIFIES THAT THE CORRECT WRITE CHECK ERROR IS DETECTED.

TEST 11 FORMAT MULTIPLE SECTORS TEST

THE TEST SEEKS TO CYLINDER 0 TO INSURE THERE IS NO HEAD MOTION DURING DATA TRANSFER. THE WRITE HEADER AND DATA COMMAND FOLLOWS, WITH THE WORD COUNT EQUAL TO MULTIPLE SECTORS. THE SAME SECTORS ARE VERIFIED WITH A WRITE CHECK HEADER AND DATA COMMAND.

TEST 12 FORMAT WITH HEAD SWITCHING TEST

THE TEST SEEKS TO CYLINDER 0 TO INSURE THERE IS NO HEAD MOTION DURING DATA TRANSFER. THE WRITE HEADER AND DATA COMMAND STARTS WITH CYLINDER 0, TRACK 0, SECTOR 31. THE WORD COUNT IS EQUAL TO MULTIPLE SECTORS WHICH CAUSES THE SUBSYSTEM TO SWITCH FROM TRACK 0 TO TRACK 1 AFTER THE FIRST OF THE MULTIPLE SECTORS ARE WRITTEN. THE SAME SECTORS ARE VERIFIED WITH A WRITE CHECK HEADER AND DATA COMMAND, USING THE SAME WORD COUNT AND STARTING SECTOR.

514
515
516
517
518
519
520
521
522
523
524
525
526
527
528
529
530
531
532
533
534
535
536
537
538
539
540
541
542
543
544
545
546
547
548
549
550
551
552
553
554
555
556
557
558
559
560
561
562
563
564
565
566
567
568
569
570

TEST 13 FORMAT WITH MID-TRANSFER SEEK TEST

THIS TEST WRITES MULTIPLE SECTORS STARTING WITH CYLINDER 0, LAST TRACK AND SECTOR 31., CAUSING A MIDTRANSFER SEEK AFTER THE FIRST SECTOR IS WRITTEN. THE SAME SECTORS ARE VERIFIED WITH WRITE CHECK HEADER AND DATA COMMAND.

TEST 14 FORMAT WITH IMPLIED SEEK TEST

THIS TEST SEEKS TO THE LAST CYLINDER PRIOR TO WRITING HEADER AND DATA ON CYLINDER 0. THE EXPLICIT SEEK INSURES THAT THERE WILL BE MAXIMUM HEAD MOTION DURING THE IMPLIED SEEK OF THE WRITE COMMAND. THE SAME OPERATION, INCLUDING THE EXPLICIT SEEK IS REPEATED FOR READ HEADER AND DATA.

TEST 15 FORMAT EACH SECTOR ADDRESS TEST

HEADERS AND DATA OF EACH SECTOR ON CYLINDER 0, TRACK 0 ARE FORMATTED AND READ WITH THE PROGRAM VERIFYING HEADERS AND DATA.

TEST 16 FORMAT EACH TRACK ADDRESS TEST

THIS TEST FORMATS SECTOR 0 OF EACH TRACK ON CYLINDER 0 AND READS EACH SECTOR WITH THE PROGRAM VERIFYING HEADERS AND DATA.

TEST 17 FORMAT PRIME CYLINDERS TEST

THIS TEST FORMATS AND READS SECTOR 0, TRACK 0 ON EACH PRIME CYLINDER, I.E., CYLINDERS 1, 2, 4, 8., 16., 32., 64., 128., 256., AND 512.

TEST 20 READ HEADER & DATA IN LAST SECTOR TEST

THIS TEST READS HEADER AND DATA ON THE LAST SECTOR OF THE, DISK, I.E., AND VERIFIES THAT 'LBT' STATUS SETS.

571
572
573
574
575
576
577
578
579
580
581
582
583
584
585
586
587
588
589
590
591
592
593
594
595
596
597
598
599
600
601
602
603
604
605
606
607
608
609
610
611
612
613
614
615
616
617
618
619
620
621
622
623
624
625
626
627

TEST 21 READ HEADER & DATA W/ AOE ERROR TEST

THIS TEST READS MULTIPLE SECTORS STARTING WITH THE LAST SECTOR 31. AND VERIFIES THAT AOE STATUS SETS.

TEST 22 READ INVALID SECTOR ADDRESS TEST

THIS TEST USES AN ILLEGAL SECTOR ADDRESS AND VERIFIES THAT IAE STATUS SETS..

TEST 23 READ INVALID TRACK ADDRESS TEST

THIS TEST USES AN ILLEGAL TRACK ADDRESS AND VERIFIES THAT IAE STATUS SETS.

TEST 24 READ INVALID CYLINDER ADDRESS TEST

THIS TEST USES AN ILLEGAL CYLINDER ADDRESS AND VERIFIES THAT IAE STATUS SETS.

TEST 25 FORMAT AT OFFSET TEST

THE PROGRAM SETS OFFSET MODE AND EXECUTES A WRITE HEADER AND DATA COMMAND, VERIFYING THAT OFFSET MODE IS RESET BY THE WRITE COMMAND.

TEST 26 IVC FORMAT TEST

VOLUME VALID IS RESET BY SETTING AND RESETTING DIAGNOSTIC MODE. THE TEST THEN EXECUTES A WRITE HEADER AND DATA COMMAND AND VERIFIES THAT INVALID COMMAND STATUS SETS. THE TEST IS REPEATED FOR READ HEADER AND DATA COMMAND.

628
629
630
631
632
633
634
635
636
637
638
639
640
641
642
643
644
645
646
647
648
649
650

TEST 27 FORMAT ERROR TEST

A SINGLE SECTOR IS FORMATTED WITH THE OFFSET REGISTER SET FOR 16 BIT FORMAT AFTER WHICH THE SAME SECTOR IS READ IN 18 BIT FORMAT WITH THE PROGRAM VERIFYING THAT FORMAT ERROR STATUS IS SET. THE SAME PROCEDURE IS REPEATED WITH THE SECTOR WRITTEN IN 18 BIT FORMAT AND READ IN 16 BIT FORMAT.

TEST 30 & 31 FORMAT HCE TEST (1ST AND 2ND HEADER WORDS)

THESE TWO TESTS WRITE AN INCORRECT HEADER THEN READ THE HEADER AND VERIFY THAT THE CORRECT HEADER ERROR IS DETECTED. THE TESTS SETUP THE CORRECT HEADER, THEN COMPLEMENT BIT 0 AND USE THE MODIFIED BUFFER TO WRITE THE HEADER. THE PROCESS IS REPEATED UNTIL EACH BIT POSITION HAS BEEN SEPARATELY TESTED.

1
479
480

```

;*LAST REVISION 04-APR-81
.TITLE CZRMNBO RM05/3/2 FCTNL TST 2
;*COPYRIGHT (C) 1981
;*DIGITAL EQUIPMENT CORPORATION
;*COLORADO SPGS., CO. 80919
;*
;*PROGRAM BY MIKE LEAVITT
;*
;*THIS PROGRAM WAS ASSEMBLED USING THE PDP-11 MAINDEC SYSMAC
;*PACKAGE (MAINDEC-11-DZQAC-C5), 18-MAR-81

```

481

```

.SBTTL OPERATIONAL SWITCH SETTINGS
;*
;*      SWITCH      USE
;*      -----
;*      15          HALT ON ERROR
;*      14          LOOP ON TEST
;*      13          INHIBIT ERROR TYPEOUTS
;*      12          UNUSED
;*      11          INHIBIT ITERATIONS
;*      10          BELL ON ERROR
;*      9           LOOP ON ERROR
;*      8           LOOP ON TEST IN SWR<7:0>
;*      7           TN128
;*      6           TN64
;*      5           TN32
;*      4           TN16
;*      3           TN8
;*      2           TN4
;*      1           TN2
;*      0           TN1

```

482

483
484

```

.SBTTL BASIC DEFINITIONS
;*INITIAL ADDRESS OF THE STACK POINTER *** 1100 ***
STACK = 1100
ERROR = EMT            ;;BASIC DEFINITION OF ERROR CALL
SCOPE = IOT            ;;BASIC DEFINITION OF SCOPE CALL

```

001100
104000
000004

```

;*MISCELLANEOUS DEFINITIONS
HT = 11            ;;CODE FOR HORIZONTAL TAB
LF = 12            ;;CODE FOR LINE FEED
CR = 15            ;;CODE FOR CARRIAGE RETURN
CRLF = 200        ;;CODE FOR CARRIAGE RETURN-LINE FEED
PS = 177776        ;;PROCESSOR STATUS WORD
PSW=PS
STKLMT = 177774    ;;STACK LIMIT REGISTER
PIRQ = 177772     ;;PROGRAM INTERRUPT REQUEST REGISTER
DSWR = 177570     ;;HARDWARE SWITCH REGISTER
DDISP = 177570    ;;HARDWARE DISPLAY REGISTER

```

000011
000012
000015
000200
177776
177776
177774
177772
177570
177570

```

;*GENERAL PURPOSE REGISTER DEFINITIONS
R0 = %0            ;;GENERAL REGISTER
R1 = %1            ;;GENERAL REGISTER
R2 = %2            ;;GENERAL REGISTER
R3 = %3            ;;GENERAL REGISTER

```

000000
000001
000002
000003

BASIC DEFINITIONS

000004	R4	= %4	::GENERAL REGISTER
000005	R5	= %5	::GENERAL REGISTER
000006	R6	= %6	::GENERAL REGISTER
000007	R7	= %7	::GENERAL REGISTER
000006	SP	= %6	::STACK POINTER
000007	PC	= %7	::PROGRAM COUNTER

::*PRIORITY LEVEL DEFINITIONS

000000	PR0	= 0	::PRIORITY LEVEL 0
000040	PR1	= 40	::PRIORITY LEVEL 1
000100	PR2	= 100	::PRIORITY LEVEL 2
000140	PR3	= 140	::PRIORITY LEVEL 3
000200	PR4	= 200	::PRIORITY LEVEL 4
000240	PR5	= 240	::PRIORITY LEVEL 5
000300	PR6	= 300	::PRIORITY LEVEL 6
000340	PR7	= 340	::PRIORITY LEVEL 7

::*'SWITCH REGISTER' SWITCH DEFINITIONS

100000	SW15	= 100000
040000	SW14	= 40000
020000	SW13	= 20000
010000	SW12	= 10000
004000	SW11	= 4000
002000	SW10	= 2000
001000	SW09	= 1000
000400	SW08	= 400
000200	SW07	= 200
000100	SW06	= 100
000040	SW05	= 40
000020	SW04	= 20
000010	SW03	= 10
000004	SW02	= 4
000002	SW01	= 2
000001	SW00	= 1
001000	SW9=SW09	
000400	SW8=SW08	
000200	SW7=SW07	
000100	SW6=SW06	
000040	SW5=SW05	
000020	SW4=SW04	
000010	SW3=SW03	
000004	SW2=SW02	
000002	SW1=SW01	
000001	SW0=SW00	

::*DATA BIT DEFINITIONS (BIT00 TO BIT15)

100000	BIT15	= 100000
040000	BIT14	= 40000
020000	BIT13	= 20000
010000	BIT12	= 10000
004000	BIT11	= 4000
002000	BIT10	= 2000
001000	BIT09	= 1000
000400	BIT08	= 400
000200	BIT07	= 200
000100	BIT06	= 100
000040	BIT05	= 40

```

000020      BIT04    = 20
000010      BIT03    = 10
000004      BIT02    = 4
000002      BIT01    = 2
000001      BIT00    = 1
001000      BIT9=BIT09
000400      BIT8=BIT08
000200      BIT7=BIT07
000100      BIT6=BIT06
000040      BIT5=BIT05
000020      BIT4=BIT04
000010      BIT3=BIT03
000004      BIT2=BIT02
000002      BIT1=BIT01
000001      BIT0=BIT00
    
```

;*BASIC "CPU" TRAP VECTOR ADDRESSES

```

000004      ERRVEC    = 4                    ;:TIME OUT AND OTHER ERRORS
000010      RESVEC    = 10                  ;:RESERVED AND ILLEGAL INSTRUCTIONS
000014      TBITVEC   = 14                  ;: "T" BIT
000014      TRTVEC    = 14                  ;:TRACE TRAP
000014      BPTVEC    = 14                  ;:BREAKPOINT TRAP (BPT)
000020      IOTVEC    = 20                  ;:INPUT/OUTPUT TRAP (IOT) **SCOPE**
000024      PWRVEC    = 24                  ;:POWER FAIL
000030      EMTVEC    = 30                  ;:EMULATOR TRAP (EMT) **ERROR**
000034      TRAPVEC   = 34                  ;: "TRAP" TRAP
000060      TKVEC     = 60                  ;:TTY KEYBOARD VECTOR
000064      TPVEC     = 64                  ;:TTY PRINTER VECTOR
000240      PIRQVEC   = 240                ;:PROGRAM INTERRUPT REQUEST VECTOR
    
```

.SBTTL RM REGISTER BIT DEFINITIONS

;*RMCS1 CONTROL STATUS REGISTER

```

004000      DVA        = BIT11               ;:DEVICE AVAILABLE-READ ONLY
000040      F4        = BIT05               ;:FUNCTION CODE
000020      F3        = BIT04               ;:FUNCTION CODE
000010      F2        = BIT03               ;:FUNCTION CODE
000004      F1        = BIT02               ;:FUNCTION CODE
000002      F0        = BIT01               ;:FUNCTION CODE
000001      GO        = BIT00               ;:GO BIT
000077      FNCMSK   = 000077              ;:FUNCTION CODE MASK
    
```

;*FUNCTION CODES (BITS 01-05 OF RMCS1)

```

485
486
487
488
489
490      000000      NOP        = 000000               ;:NOP COMMAND
491      000002      ILF02    = 000002               ;:ILLEGAL COMMAND
492      000004      SEEK     = 000004               ;:SEEK COMMAND
493      000006      RECAL    = 000006               ;:RECALIBRATE COMMAND
494      000010      DRVCLR   = 000010               ;:DRIVE CLEAR COMMAND
495      000012      RELEASE = 000012               ;:RELEASE COMMAND
496      000014      OFFSET   = 000014               ;:OFFSET COMMAND
497      000016      RTC       = 000016               ;:RETURN TO CENTERLINE COMMAND
498      000020      RIP       = 000020               ;:READ IN PRESET COMMAND
499      000022      PAKACK   = 000022               ;:PACK ACKNOWLEDGE COMMAND
500      000022      PACACK   = PAKACK               ;:PACK ACKNOWLEDGE COMMAND
501      000024      ILF24    = 000024               ;:ILLEGAL COMMAND
502      000026      ILF26    = 000026               ;:ILLEGAL COMMAND
503
504
505
506
507
508
509
510
511
512
    
```


513	000030	SEARCH	= 000030	:SEARCH COMMAND
516	000030	ILF30	= 000030	:ILLEGAL COMMAND
	000032	ILF32	= 000032	:ILLEGAL COMMAND
	000034	ILF34	= 000034	:ILLEGAL COMMAND
	000036	ILF36	= 000036	:ILLEGAL COMMAND
	000040	ILF40	= 000040	:ILLEGAL COMMAND
	000042	ILF42	= 000042	:ILLEGAL COMMAND
	000044	ILF44	= 000044	:ILLEGAL COMMAND
	000046	ILF46	= 000046	:ILLEGAL COMMAND
517	000050	WCD	= 000050	:WRITE CHECK DATA COMMAND
518	000052	WCH	= 000052	:WRITE CHECK HEADER AND DATA
519	000054	ILF54	= 000054	:ILLEGAL COMMAND
520	000056	ILF56	= 000056	:ILLEGAL COMMAND
521	000060	WD	= 000060	:WRITE DATA COMMAND
522	000062	WH	= 000062	:WRITE HEADER AND DATA COMMAND
523	000064	ILF64	= 000064	:ILLEGAL COMMAND
524	000066	ILF66	= 000066	:ILLEGAL COMMAND
525	000070	RD	= 000070	:READ DATA COMMAND
526	000072	RH	= 000072	:READ HEADER AND DATA COMMAND
527	000074	ILF74	= 000074	:ILLEGAL COMMAND
528	000076	ILF76	= 000076	:ILLEGAL COMMAND
529				
530		;*RMDA DISK ADDRESS REGISTER		
531				
532		;TRACK ADDRESS DEFINITIONS		
533	010000	TA16	= BIT12	:TRACK ADDRESS 16.
534	004000	TA8	= BIT11	:TRACK ADDRESS 8.
535	002000	TA4	= BIT10	:TRACK ADDRESS 4
536	001000	TA2	= BIT09	:TRACK ADDRESS 2
537	000400	TA1	= BIT08	:TRACK ADDRESS 1
538				
539		;SECTOR ADDRESS DEFINITIONS		
540	000020	SA16	= BIT04	:SECTOR ADDRESS 16.
541	000010	SA8	= BIT03	:SECTOR ADDRESS 8.
542	000004	SA4	= BIT02	:SECTOR ADDRESS 4
543	000002	SA2	= BIT01	:SECTOR ADDRESS 2
544	000001	SA1	= BIT00	:SECTOR ADDRESS 1
545				
546		;TRACK & SECTOR MASKS		
547	177400	TADMSK	= 177400	:TRACK ADDRESS MASK
548	000377	SADMSK	= 000377	:SECTOR ADDRESS MASK
549				
550		;*RMDS DRIVE STATUS REGISTER		
551				
552	100000	ATA	= BIT15	:ATTENTION ACTIVE
553	040000	ERR	= BIT14	:COMPOSITE ERROR
554	020000	PIP	= BIT13	:POSITIONING IN PROGRESS
555	010000	MOL	= BIT12	:MEDIUM ON LINE
556	004000	WRL	= BIT11	:WRITE LOCK
557	002000	LBT	= BIT10	:LAST BLOCK TRANSFERRED
558	001000	PGM	= BIT09	:PROGRAMMABLE
559	000400	DFR	= BIT08	:DRIVE PRESENT
560	000200	DRY	= BIT07	:DRIVE READY
561	000100	VV	= BIT06	:VOLUME VALID
562	000001	OM	= BIT00	:OFFSET MODE ACTIVE
563				
564		;*RMER1 ERROR REGISTER #1		

```

565
566      100000      DCK      = BIT15      ;DATA CHECK ERROR
567      040000      UNS      = BIT14      ;DRIVE UNSAFE
568      020000      OPI      = BIT13      ;OPERATION INCOMPLETE
569      010000      DTE      = BIT12      ;DRIVE TIMING ERROR
570      004000      WLE      = BIT11      ;WRITE LOCK ERROR
571      002000      IAE      = BIT10      ;INVALID ADDRESS ERROR
572      001000      AOE      = BIT09      ;ADDRESS OVERFLOW ERROR
573      000400      HCRC     = BIT08      ;HEADER CRC ERROR
574      000200      HCE      = BIT07      ;HEADER COMPARE ERROR
575      000100      ECH      = BIT06      ;ECC "HARD" ERROR
576      000040      WCF      = BIT05      ;WRITE CLOCK FAILURE
577      000020      FER      = BIT04      ;FORMAT ERROR
578      000010      PAR      = BIT03      ;PARITY ERROR
579      000004      RMR      = BIT02      ;REGISTER MODIFICATION REFUSED
580      000002      ILR      = BIT01      ;ILLEGAL REGISTER
581      000001      ILF      = BIT00      ;ILLEGAL FUNCTION
582
583      115760      NDTMSK   = DCK!DTE!WLE!AOE!HCRC!HCE!ECH!WCF!FER
584      ;"NDTMSK" IS USED TO MASK ERROR REGISTER 1 DURING NON - DATA
585      ;COMMANDS, I.E., HOUSEKEEPING AND POSITIONING COMMANDS
586
587      ;*RMAS ATTENTION SUMMARY REGISTER
588
589      000377      ATNMSK   = 377      ;MASK FOR ATTENTION BITS
590
591      ;*RMLA LOOK AHEAD REGISTER
592
593      002000      SC4      = BIT10      ;SECTOR COUNT = 16
594      001000      SC3      = BIT09      ;SECTOR COUNT = 8
595      000400      SC2      = BIT08      ;SECTOR COUNT = 4
596      000200      SC1      = BIT07      ;SECTOR COUNT = 2
597      000100      SC0      = BIT06      ;SECTOR COUNT = 1
598
599      003700      SCTMSK   = 003700    ;SECTOR COUNT MASK
600
601      ;*RMMR1 MAINTENANCE REGISTER #1
602
603      ;WRITE ONLY BITS
604      100000      DBCK     = BIT15      ;DEBUG CLOCK
605      040000      DBEN     = BIT14      ;DEBUG CLOCK ENABLE
606      020000      DEBL     = BIT13      ;DIAGNOSTIC END OF BLOCK
607      010000      DTO      = BIT12      ;DIAGNOSTIC TIMEOUT
608      004000      MCLK     = BIT11      ;MAINTENANCE CLOCK
609      002000      MRD      = BIT10      ;READ DATA
610      001000      MUR      = BIT09      ;UNIT READY
611      000400      MOC      = BIT08      ;ON CYLINDER
612      000200      MSER     = BIT07      ;SEEK ERROR
613      000100      MDF      = BIT06      ;DRIVE FAULT
614      000040      MS       = BIT05      ;SECTOR PULSE
615      000010      MWP      = BIT03      ;WRITE PROTECT
616      000004      MI       = BIT02      ;INDEX PULSE
617      000002      MSC      = BIT01      ;SECTOR COMPARE
618      000001      DMD      = BIT00      ;DIAGNOSTIC MODE
619
620      ;READ ONLY BITS
621      100000      OCC      = BIT15      ;OCCUPIED

```


622	040000	RG	= BIT14	:RUN AND GO
623	020000	EBL	= BIT13	:END OF BLOCK
624	010000	REX	= BIT12	:EXCEPTION
625	004000	ESRC	= BIT11	:ENABLE SEARCH
626	002000	PLFS	= BIT10	:LOOKING FOR SYNC
627	001000	ECRC	= BIT09	:ENABLE CRC OUT
628	000400	PDA	= BIT08	:DATA AREA
629	000200	PHA	= BIT07	:HEADER AREA
630	000100	CONT	= BIT06	:CONTINUE
631	000040	WC	= BIT05	:WORD CLOCK
632	000020	EECC	= BIT04	:ENABLE ECC OUT
633	000010	MWD	= BIT03	:WRITE DATA BIT
634	000004	LS	= BIT02	:LAST SECTOR
635	000002	LST	= BIT01	:LAST SECTOR AND TRACK
636	000001	DMD	= BIT00	:DIAGNOSTIC MODE
637				
638		;*RMDT DRIVE TYPE REGISTER		
639				
640	100000	NSA	= BIT15	:NOT SECTOR ADDRESSED = 0
641	040000	TAP	= BIT14	:TAPE DRIVE = 0
642	020000	MOH	= BIT13	:MOVING HEAD = 1
643	004000	DRQ	= BIT11	:DRIVE REQUEST REQUIRED
644				
645	020024	SNGPRT	= 020024	:SINGLE PORT DRIVE TYPE (RM02)
646	024024	DULPRT	= 024024	:DUAL PORT DRIVE TYPE (RM02)
647				
648		;*RMOF OFFSET REGISTER		
649				
650	010000	FMT16	= BIT12	:16 BIT WORD FORMAT
651	004000	ECI	= BIT11	:ECC INHIBIT
652	002000	HCI	= BIT10	:HEADER COMPARE INHIBIT
653	000200	OFD	= BIT07	:OFFSET FORWARD
654				
655		;*RMDC DESIRED CYLINDER ADDRESS REGISTER		
656				
657	001777	CYLMSK	= 001777	:MASK FOR CYLINDER ADDRESS
658				
659		;*RMMR2 MAINTENANCE REGISTER #2		
660				
661		:READ ONLY BITS		
662	100000	RQA	= BIT15	:PORT A REQUEST
663	040000	RQB	= BIT14	:PORT B REQUEST
664	020000	TAG	= BIT13	:TAG CONTROL
665	010000	TST	= BIT12	:COMMAND SEQUENCE TEST BIT
666	004000	CC	= BIT11	:CONTROL OR CYLINDER TAG
667	002000	CH	= BIT10	:CONTROL OR HEAD TAG
670	001000	BB09	= BIT09	:TAG BUS
	000400	BB08	= BIT08	:TAG BUS
	000200	BB07	= BIT07	:TAG BUS
	000100	BB06	= BIT06	:TAG BUS
	000040	BB05	= BIT05	:TAG BUS
	000020	BB04	= BIT04	:TAG BUS
	000010	BB03	= BIT03	:TAG BUS
	000004	BB02	= BIT02	:TAG BUS
	000002	BB01	= BIT01	:TAG BUS
	000001	BB00	= BIT00	:TAG BUS

```

672                                     ;*RMER2 ERROR REGISTER 2
673
674         100000                       BSE      = BIT15           ;BAD SECTOR ERROR
675         040000                       SKI      = BIT14           ;SEEK INCOMPLETE
676         020000                       OPE      = BIT13           ;OPERATOR PLUG ERROR
677         010000                       IVC      = BIT12           ;INVALID COMMAND ERROR
678         004000                       LSC      = BIT11           ;LOSS OF SYSTEM CLOCK
679         002000                       LBC      = BIT10           ;LOSS OF BIT CLOCK
680         000200                       DVC      = BIT07           ;DEVICE CHECK
681         000010                       DPE      = BIT03           ;DATA PARITY ERROR
682
683         .SBTTL  PROGRAM MNEMONICS
684
685         100000                       MSE      = BIT15           ;MANUFACTURING DETECTED SECTOR ERROR
686         040000                       USE      = BIT14           ;USER DETECTED SECTOR ERROR
687
688         .SBTTL  RM REGISTER INDEX VALUES
689
690         000000                       RMCS1   = 00           ;CONTROL STATUS REGISTER #1
691         000006                       RMDA    = 06           ;DISK ADDRESS REGISTER
692         000012                       RMDS    = 12           ;DRIVE STATUS REGISTER
693         000014                       RMER1   = 14           ;ERROR REGISTER #1
694         000016                       RMAS    = 16           ;ATTENTION SUMMARY REGISTER
695         000020                       RMLA    = 20           ;LOOK AHEAD REGISTER
696         000024                       RMMR1   = 24           ;MAINTENANCE REGISTER
697         000026                       RMDT    = 26           ;DRIVE TYPE REGISTER
698         000030                       RMSN    = 30           ;SERIAL NUMBER REGISTER
699         000032                       RMOF    = 32           ;OFFSET REGISTER
700         000034                       RMDC    = 34           ;DESIRED CYLINDER REGISTER
701         000036                       RMHR    = 36           ;HOLDING REGISTER
702         000040                       RMMR2   = 40           ;MAINTENANCE REGISTER #2
703         000042                       RMER2   = 42           ;ERROR REGISTER #2
704         000044                       RMEC1   = 44           ;ECC POSITION REGISTER
705         000046                       RMEC2   = 46           ;ECC PATTERN REGISTER
706         000050                       ILRG50  = 50           ;ILLEGAL REGISTER 50
707         000052                       ILRG52  = 52           ;ILLEGAL REGISTER 52
708         000054                       ILRG54  = 54           ;ILLEGAL REGISTER 54
709         000056                       ILRG56  = 56           ;ILLEGAL REGISTER 56
710         000060                       ILRG60  = 60           ;ILLEGAL REGISTER 60
711         000062                       ILRG62  = 62           ;ILLEGAL REGISTER 62
712         000064                       ILRG64  = 64           ;ILLEGAL REGISTER 64
713         000066                       ILRG66  = 66           ;ILLEGAL REGISTER 66
714         000070                       ILRG70  = 70           ;ILLEGAL REGISTER 70
715         000072                       ILRG72  = 72           ;ILLEGAL REGISTER 72
716         000074                       ILRG74  = 74           ;ILLEGAL REGISTER 74
717         000076                       ILRG76  = 76           ;ILLEGAL REGISTER 76
718
719         000077                       IDXMSK  = 77           ;MASK FOR REGISTER INDEX NUMBER
720
721         .SBTTL  RH CONTROLLER REGISTER BIT DEFINITIONS
722
723         ;*RMCS1 CONTROL STATUS REGISTER #1
724
725         100000                       SC       = BIT15           ;SPECIAL CONDITION-READ ONLY
726         040000                       TRE      = BIT14           ;TRANSFER ERROR
727         020000                       MCPE    = BIT13           ;MASSBUS CONTROL BUS PARITY ERROR-READ ONLY
728         002000                       PSEL    = BIT10           ;PORT B SELECT

```


720	001000	A17 = BIT09	:ADDRESS EXTENSION
721	000400	A16 = BIT08	:ADDRESS EXTENSION
722	000200	RDY = BIT07	:READY-READ ONLY
723	000100	IE = BIT06	:INTERRUPT ENABLE
724			
725		:*RMCS2 RH CONTROL STATUS REGISTER #2	
726			
727	100000	DLT = BIT15	:DATA LATE-READ ONLY
728	040000	WCE = BIT14	:WRITE CHECK ERROR-READ ONLY
729	020000	UPE = BIT13	:UNIBUS PARITY ERROR
730	010000	NED = BIT12	:NONEXISTANT DRIVE-READ ONLY
731	004000	NEM = BIT11	:NONEXISTANT MEMORY-READ ONLY
732	002000	PGE = BIT10	:PROGRAM ERROR-READ ONLY
733	001000	MXF = BIT09	:MISSED TRANSFER
734	000400	MDPE = BIT08	:MASSBUS DATA BUS PARITY ERROR-READ ONLY
735	000200	OR = BIT07	:OUTPUT READY-READ ONLY
736	000100	IR = BIT06	:INPUT READY-READ ONLY
737	000040	CLR = BIT05	:CONTROLLER CLEAR
738	000020	PAT = BIT04	:PARITY TEST
739	000010	BAI = BIT03	:UNIBUS ADDRESS INCREMENT INHIBIT
742	000004	U2 = BIT02	:UNIT SELECT
	000002	U1 = BIT01	:UNIT SELECT
	000001	U0 = BIT00	:UNIT SELECT
743			
744		:UNIT SELECT MASK	
745			
746	000007	UNTMSK = 7	:UNIT SELECT MASK
747			
748		:*RMCS3 RH70 CONTROL STATUS REGISTER #3	
749			
750	100000	APE = BIT15	:ADDRESS PARITY ERROR
751	040000	DPEHI = BIT14	:DATA PARITY ERROR HIGH WORD
752	020000	DPELO = BIT13	:DATA PARITY ERROR LOW WORD
753	010000	WCEHI = BIT12	:WRITE CHECK ERROR HIGH WORD
754	004000	WCELO = BIT11	:WRITE CHECK ERROR LOW WORD
755	002000	DBL = BIT10	:DOUBLE WORD TRANSFER
756	000100	IE = BIT06	:INTERRUPT ENABLE
757	000010	IPCK3 = BIT03	:INVERT PARITY CHECK
758	000004	IPCK2 = BIT02	:INVERT PARITY CHECK
759	000002	IPCK1 = BIT01	:INVERT PARITY CHECK
760	000001	IPCK0 = BIT00	:INVERT PARITY CHECK
761			
762		.SBTTL RH CONTROLLER REGISTER INDEX VALUES	
763			
764	000000	RMCS1 = 00	:CONTROL, STATUS REGISTER #1
765	000002	RMWC = 02	:WORD COUNT REGISTER
766	000004	RMBA = 04	:BUS ADDRESS REGISTER
767	000010	RMCS2 = 10	:CONTROL, STATUS REGISTER #2
768	000022	RMDB = 22	:DATA BUFFER
769	000050	RMBAE = 50	:BUS ADDRESS EXTENSION
770	000052	RMCS3 = 52	:CONTROL, STATUS REGISTER #3
771			
772	176700	ABASE = 176700	:UNIBUS ADDRESS
773	120254	AVECT1 = 120254	:UNIBUS VECTOR ADDRESS AND PRIORITY
774			

1
2
3
4
5
6
7
8
9

000000
000174 000174
000174 000000
000176 000000
:
000200 000137 005432
000204 000137 005422
:
000210 000210
000046 032122
000052 000052
000052 000000
000210 000210
:
001100 001100
:
000024 000024
000200 000200
000044 000044
000044 001100
001100 001100
:
001100 001100
001100 000000
001102 001222
001104 000006
001106 000006
001110 000006
001112 000042
001114 001114

```

.SBTTL TRAP CATCHER
.=0
;*ALL UNUSED LOCATIONS FROM 4 - 776 CONTAIN A ".+2,HALT"
;*SEQUENCE TO CATCH ILLEGAL TRAPS AND INTERRUPTS
;*LOCATION 0 CONTAINS 0 TO CATCH IMPROPERLY LOADED VECTORS
.=174
DISPREG: .WORD 0      ;;SOFTWARE DISPLAY REGISTER
SWREG:   .WORD 0      ;;SOFTWARE SWITCH REGISTER

.SBTTL STARTING ADDRESS(LS)
      JMP @#START      ;;JUMP TO STARTING ADDRESS OF PROGRAM
      JMP @#START1     ;CHANGE RH/RM BUS ADDRESS

.SBTTL ACT11 HOOKS
;*****
;HOOKS REQUIRED BY ACT11
      $SVPC=.          ;SAVE PC
      .=46             ;1)SET LOC.46 TO ADDRESS OF $ENDAD IN .$EOP
      $ENDAD           ;
      .=52             ;2)SET LOC.52 TO ZERO
      .WORD 0          ;
      .=$SVPC          ; RESTORE PC

.=1100
.SBTTL APT PARAMETER BLOCK
;*****
;SET LOCATIONS 24 AND 44 AS REQUIRED FOR APT
;*****
      .$X=.            ;;SAVE CURRENT LOCATION
      .=24             ;;SET POWER FAIL TO POINT TO START OF PROGRAM
      200              ;;FOR APT START UP
      .=44             ;;POINT TO APT INDIRECT ADDRESS PNTR.
      $APTHDR          ;;POINT TO APT HEADER BLOCK
      .=.$X            ;;RESET LOCATION COUNTER
;*****
;SETUP APT PARAMETER BLOCK AS DEFINED IN THE APT-PDP11 DIAGNOSTIC
;INTERFACE SPEC.

$APTHD:
$HIBTS: .WORD 0      ;;TWO HIGH BITS OF 18 BIT MAILBOX ADDR.
$MBADR: .WORD $MAIL  ;;ADDRESS OF APT MAILBOX (BITS 0-15)
$STMT:  .WORD 6      ;;RUN TIM OF LONGEST TEST
$PASTM: .WORD 6      ;;RUN TIME IN SECS. OF 1ST PASS ON 1 UNIT (QUICK VERIFY)
$UNITM: .WORD 6      ;;ADDITIONAL RUN TIME (SECS) OF A PASS FOR EACH ADDED UNIT
      .WORD $ETEND-$MAIL/2 ;;LENGTH MAILBOX-ETABLE(WORDS)

TAGADR=.
  
```


0

.SBTTL COMMON TAGS

*THIS TABLE CONTAINS VARIOUS COMMON STORAGE LOCATIONS
*USED IN THE PROGRAM.

Address	Value	Tag Name	Format	Value	Description
001114	001114	SCMTAG:	.=TAGADR		::START OF COMMON TAGS
001114	000000		.WORD	0	
001116	000	\$TSTNM:	.BYTE	0	::CONTAINS THE TEST NUMBER
001117	000	\$ERFLG:	.BYTE	0	::CONTAINS ERROR FLAG
001120	000000	\$ICNT:	.WORD	0	::CONTAINS SUBTEST ITERATION COUNT
001122	000000	\$LPADR:	.WORD	0	::CONTAINS SCOPE LOOP ADDRESS
001124	000000	\$LPERR:	.WORD	0	::CONTAINS SCOPE RETURN FOR ERRORS
001126	000000	\$ERTTL:	.WORD	0	::CONTAINS TOTAL ERRORS DETECTED
001130	000	\$ITEMB:	.BYTE	0	::CONTAINS ITEM CONTROL BYTE
001131	001	\$ERMAX:	.BYTE	1	::CONTAINS MAX. ERRORS PER TEST
001132	000000	\$ERRPC:	.WORD	0	::CONTAINS PC OF LAST ERROR INSTRUCTION
001134	000000	\$GDADR:	.WORD	0	::CONTAINS ADDRESS OF 'GOOD' DATA
001136	000000	\$BDADR:	.WORD	0	::CONTAINS ADDRESS OF 'BAD' DATA
001140	000000	\$GDDAT:	.WORD	0	::CONTAINS 'GOOD' DATA
001142	000000	\$BDDAT:	.WORD	0	::CONTAINS 'BAD' DATA
001144	000000		.WORD	0	::RESERVED--NOT TO BE USED
001146	000000		.WORD	0	
001150	000	\$AUTOB:	.BYTE	0	::AUTOMATIC MODE INDICATOR
001151	000	\$INTAG:	.BYTE	0	::INTERRUPT MODE INDICATOR
001152	000000		.WORD	0	
001154	177570	SWR:	.WORD	DSWR	::ADDRESS OF SWITCH REGISTER
001156	177570	DISPLAY:	.WORD	DDISP	::ADDRESS OF DISPLAY REGISTER
001160	177560	\$TKS:	.WORD	177560	::TTY KBD STATUS
001162	177562	\$TKB:	.WORD	177562	::TTY KBD BUFFER
001164	177564	\$TPS:	.WORD	177564	::TTY PRINTER STATUS REG. ADDRESS
001166	177566	\$TPB:	.WORD	177566	::TTY PRINTER BUFFER REG. ADDRESS
001170	000	\$NULL:	.BYTE	0	::CONTAINS NULL CHARACTER FOR FILLS
001171	002	\$FILLS:	.BYTE	2	::CONTAINS # OF FILLER CHARACTERS REQUIRED
001172	012	\$FILLC:	.BYTE	12	::INSERT FILL CHARS. AFTER A 'LINE FEED'
001173	000	\$TPFLG:	.BYTE	0	::'TERMINAL AVAILABLE' FLAG (BIT<07>=0=YES)
001174	000000	\$TMP0:	.WORD	0	::USER DEFINED
001176	000000	\$TMP1:	.WORD	0	::USER DEFINED
001200	000000	\$TMP2:	.WORD	0	::USER DEFINED
001202	000000	\$TMP3:	.WORD	0	::USER DEFINED
001204	000000	\$TMP4:	.WORD	0	::USER DEFINED
001206	000000	\$TIMES:	.WORD	0	::MAX. NUMBER OF ITERATIONS
001210	000000	\$ESCAPE:	.WORD	0	::ESCAPE ON ERROR ADDRESS
001212	207	\$BELL:	.ASCIZ	<207><377><377>	::CODE FOR BELL
001216	077	\$QUES:	.ASCII	/?/	::QUESTION MARK
001217	015	\$CRLF:	.ASCII	<15>	::CARRIAGE RETURN
001220	012	\$LF:	.ASCIZ	<12>	::LINE FEED

.SBTTL APT MAILBOX-ETABLE

Address	Value	Tag Name	Format	Value	Description
001222		.EVEN			
001222	000000	\$MAIL:			::APT MAILBOX
001224	000000	\$MSGTY:	.WORD	AMSGTY	::MESSAGE TYPE CODE
001226	000000	\$FATAL:	.WORD	AFATAL	::FATAL ERROR NUMBER
001226	000000	\$TESTN:	.WORD	ATESTN	::TEST NUMBER

001230	000000	\$PASS:	.WORD	APASS	::PASS COUNT
001232	000000	\$DEVCT:	.WORD	ADEVCT	::DEVICE COUNT
001234	000000	\$UNIT:	.WORD	AUNIT	::I/O UNIT NUMBER
001236	000000	\$MSGAD:	.WORD	AMSGAD	::MESSAGE ADDRESS
001240	000000	\$MSGLG:	.WORD	AMSGLG	::MESSAGE LENGTH
001242		\$ETABLE:			::APT ENVIRONMENT TABLE
001242	000	\$ENV:	.BYTE	AENV	::ENVIRONMENT BYTE
001243	000	\$ENVM:	.BYTE	AENVM	::ENVIRONMENT MODE BITS
001244	000000	\$SWREG:	.WORD	ASWREG	::APT SWITCH REGISTER
001246	000000	\$USWR:	.WORD	AUSWR	::USER SWITCHES
001250	000000	\$CPUOP:	.WORD	ACPUOP	::CPU TYPE,OPTIONS
		*			BITS 15-11=CPU TYPE
		*			11/04=01,11/05=02,11/20=03,11/40=04,11/45=05
		*			11/70=06,PDQ=07,Q=10
		*			BIT 10=REAL TIME CLOCK
		*			BIT 9=FLOATING POINT PROCESSOR
		*			BIT 8=MEMORY MANAGEMENT
001252	000	\$MAMS1:	.BYTE	AMAMS1	::HIGH ADDRESS,M.S. BYTE
001253	000	\$MTYP1:	.BYTE	AMTYP1	::MEM. TYPE,BLK#1
		*			MEM.TYPE BYTE -- (HIGH BYTE)
		*			900 NSEC CORE=001
		*			300 NSEC BIPOLAR=002
		*			500 NSEC MOS=003
001254	000000	\$MADR1:	.WORD	AMADR1	::HIGH ADDRESS,BLK#1
		*			MEM.LAST ADDR.=3 BYTES,THIS WORD AND LOW OF "TYPE" ABOVE
001256	000	\$MAMS2:	.BYTE	AMAMS2	::HIGH ADDRESS,M.S. BYTE
001257	000	\$MTYP2:	.BYTE	AMTYP2	::MEM. TYPE,BLK#2
001260	000000	\$MADR2:	.WORD	AMADR2	::MEM.LAST ADDRESS,BLK#2
001262	000	\$MAMS3:	.BYTE	AMAMS3	::HIGH ADDRESS,M.S.BYTE
001263	000	\$MTYP3:	.BYTE	AMTYP3	::MEM. TYPE,BLK#3
001264	000000	\$MADR3:	.WORD	AMADR3	::MEM.LAST ADDRESS,BLK#3
001266	000	\$MAMS4:	.BYTE	AMAMS4	::HIGH ADDRESS,M.S.BYTE
001267	000	\$MTYP4:	.BYTE	AMTYP4	::MEM. TYPE,BLK#4
001270	000000	\$MADR4:	.WORD	AMADR4	::MEM.LAST ADDRESS,BLK#4
001272	120254	\$VECT1:	.WORD	AVECT1	::INTERRUPT VECTOR#1,BUS PRIORITY#1
001274	000000	\$VECT2:	.WORD	AVECT2	::INTERRUPT VECTOR#2BUS PRIORITY#2
001276	176700	\$BASE:	.WORD	ABASE	::BASE ADDRESS OF EQUIPMENT UNDER TEST
001300	000000	\$DEVW:	.WORD	ADEVW	::DEVICE MAP
001302	000000	\$CDW1:	.WORD	ACDW1	::CONTROLLER DESCRIPTION WORD#1
001304	000000	\$CDW2:	.WORD	ACDW2	::CONTROLLER DESCRIPTION WORD#2
001306	000000	\$DDW0:	.WORD	ADDW0	::DEVICE DESCRIPTOR WORD#0
001310	000000	\$DDW1:	.WORD	ADDW1	::DEVICE DESCRIPTOR WORD#1
001312	000000	\$DDW2:	.WORD	ADDW2	::DEVICE DESCRIPTOR WORD#2
001314	000000	\$DDW3:	.WORD	ADDW3	::DEVICE DESCRIPTOR WORD#3
001316	000000	\$DDW4:	.WORD	ADDW4	::DEVICE DESCRIPTOR WORD#4
001320	000000	\$DDW5:	.WORD	ADDW5	::DEVICE DESCRIPTOR WORD#5
001322	000000	\$DDW6:	.WORD	ADDW6	::DEVICE DESCRIPTOR WORD#6
001324	000000	\$DDW7:	.WORD	ADDW7	::DEVICE DESCRIPTOR WORD#7
001326		\$ETEND:			
		.MEXIT			

.SBTTL USER DEFINED TAGS

001326	000000	CTFLG:	.WORD	0	:CONTAINS CONTROL-C FLAG
001330	000000	CHGADR:	.WORD	0	:CHANGE RH/RM BUS ADDRESS = -1, NO CHANGE = 0
001332	000000	XXDP:	.WORD	0	:THE LOW BYTE CONTAINS THE DRIVE NUMBER FROM WHICH :THE PROGRAM WAS LOADED. THE HIGH BYTE CONTAINS THE :'XXDP' DEVICE CODE FOR THE RM05/3/2.
001334	000	LSTRK:	.BYTE	0	:LO BYTE = 0
001335	000		.BYTE	0	:HI BYTE, CONTAINS LAST TRACK ADDRESS OF UNIT :UNDER TEST. RM02/3 = 4., RM05 = 18.

:THE REGISTER INPUT BUFFER IS USED FOR
 :STORING DRIVE STATUS

001336

GETBUF:

		:REGISTER INPUT BUFFER			
001336	000000	RMCS1I:	.WORD	0	:CONTROL, STATUS REGISTER #1
001340	000000	RMWCI:	.WORD	0	:WORD COUNT REGISTER
001342	000000	RMBAI:	.WORD	0	:BUS ADDRESS REGISTER
001344	000000	RMDAI:	.WORD	0	:DISK ADDRESS REGISTER
001346	000000	RMCS2I:	.WORD	0	:CONTROL, STATUS REGISTER #2
001350	000000	RMDSI:	.WORD	0	:DRIVE STATUS REGISTER
001352	000000	RMER1I:	.WORD	0	:ERROR REGISTER #1
001354	000000	RMASI:	.WORD	0	:ATTENTION SUMMARY REGISTER
001356	000000	RMLAI:	.WORD	0	:LOOK AHEAD REGISTER
001360	000000	RMDBI:	.WORD	0	:DATA BUFFER
001362	000000	RMMR1I:	.WORD	0	:MAINTENANCE REGISTER #1
001364	000000	RMDTI:	.WORD	0	:DRIVE TYPE REGISTER
001366	000000	RMSNI:	.WORD	0	:SERIAL NUMBER REGISTER
001370	000000	RMOFI:	.WORD	0	:OFFSET REGISTER
001372	000000	RMDCI:	.WORD	0	:DESIRED CYLINDER REGISTER
001374	000000	RMHRI:	.WORD	0	:HOLDING REGISTER
001376	000000	RMMR2I:	.WORD	0	:MAINTENANCE REGISTER #2
001400	000000	RMER2I:	.WORD	0	:ERROR REGISTER #2
001402	000000	RMEC1I:	.WORD	0	:ECC POSITION REGISTER
001404	000000	RMEC2I:	.WORD	0	:ECC PATTERN REGISTER
001406	000000	RMBAEI:	.WORD	0	:BUS ADDRESS EXTENSION REGISTER
001410	000000	RMCS3I:	.WORD	0	:CONTROL, STATUS REGISTER #3

:THE REGISTER OUTPUT BUFFER IS USED FOR
 :ASSEMBLING DATA GOING TO REGISTER

001412

PUTBUF:

		:REGISTER OUTPUT BUFFER			
001412	000000	RMCS1O:	.WORD	0	:CONTROL, STATUS REGISTER #1
001414	000000	RMWCO:	.WORD	0	:WORD COUNT REGISTER
001416	000000	RMBAO:	.WORD	0	:BUS ADDRESS REGISTER
001420	000000	RMDAO:	.WORD	0	:DISK ADDRESS REGISTER
001422	000000	RMCS2O:	.WORD	0	:CONTROL, STATUS REGISTER #2
001424	000000	RMDSO:	.WORD	0	:DRIVE STATUS REGISTER
001426	000000	RMER1O:	.WORD	0	:ERROR REGISTER #1
001430	000000	RMASO:	.WORD	0	:ATTENTION SUMMARY REGISTER
001432	000000	RMLAO:	.WORD	0	:LOOK AHEAD REGISTER
001434	000000	RMDBO:	.WORD	0	:DATA BUFFER
001436	000000	RMMR1O:	.WORD	0	:MAINTENANCE REGISTER #1

001440 000000
 001442 000000
 001444 000000
 001446 000000
 001450 000000
 001452 000000
 001454 000000
 001456 000000
 001460 000000
 001462 000000
 001464 000000

RMDTO: .WORD 0 ;DRIVE TYPE REGISTER
 RMSNO: .WORD 0 ;SERIAL NUMBER REGISTER
 RMOFO: .WORD 0 ;OFFSET REGISTER
 RMDCO: .WORD 0 ;DESIRED CYLINDER REGISTER
 RMHRO: .WORD 0 ;HOLDING REGISTER
 RMMR20: .WORD 0 ;MAINTENANCE REGISTER #2
 RMER20: .WORD 0 ;ERROR REGISTER #2
 RMEC10: .WORD 0 ;ECC POSITION REGISTER
 RMEC20: .WORD 0 ;ECC PATTERN REGISTER
 RMBAE0: .WORD 0 ;BUS ADDRESS EXTENSION REGISTER
 RMCS30: .WORD 0 ;CONTROL, STATUS REGISTER #3

;EACH WORD OF THE TEST QUE CONTAINS THE DEVICE NUMBER IN
 ;THE LOW BYTE AND THE ATTENTION BIT IN THE HIGH BYTE. THE
 ;FIRST WORD CONTAINS THE ADDRESS OF THE DEVICE UNDER TEST
 ;IN THE TABLE. A ZERO WORD IS A BLANK AND REPRESENTS THE
 ;END OF THE QUE.

001466 000000
 001470 000000
 001510 000000

TSTQUE: .WORD 0 ;CONTAINS DEVICE POINTER
 .BLKW 8. ;TEST QUE FOR DEVICES UNDER TEST
 .WORD 0 ;TABLE TERMINATOR GOES HERE WHEN
 ;ALL 8. DEVICES ARE UNDER TEST.

;MEDIA ENABLE IS SET IF THE BAD SECTOR FILES HAVE BEEN RECOVERED
 ;FOR THE UNIT UNDER TEST, OTHERWISE IT IS ZERO.

001512 000000

MEDENB: .WORD 0 ;MEDIA ENABLE

;LOCATIONS 'ASNDC' AND 'ASNDC' CONTAIN THE CYLINDER, TRACK AND SECTOR
 ;ADDRESS ASSIGNED BY THE BAD SECTOR MODULE.

001514 000000
 001516 000000
 001520 000000
 001522 000000

ASNDC: .WORD 0 ;ASSIGNED DESIRED CYLINDER
 ASNDA: .WORD 0 ;ASSIGNED TRACK, AND SECTOR
 CLKADR: .WORD 0 ;UNIBUS ADDRESS OF KW11 CLOCK
 CLKVCT: .WORD 0 ;VECTOR ADDRESS OF KW11 CLOCK

;THE GET INDEX TABLE CONTAINS A BYTE LIST OF REGISTERS WHICH
 ;ARE READ BY THE GET SUBROUTINE. THE LIST IS TERMINATED BY
 ;A NEGATIVE BYTE.

001524

GETINX: .BLKB 23. ;GET INDEX TABLE

;THE PUT INDEX TABLE ICONTAINS A BYTE LIST OF REGISTERS WHICH
 ;ARE WRITTEN BY THE PUT SUBROUTINE. THE LIST IS TERMINATED BY
 ;A NEGATIVE BYTE.

001553

PUTINX: .BLKB 23. ;PUT INDEX TABLE

;PUT TAGS HERE

.SBTTL ERROR POINTER TABLE

;*THIS TABLE CONTAINS THE INFORMATION FOR EACH ERROR THAT CAN OCCUR.
 ;*THE INFORMATION IS OBTAINED BY USING THE INDEX NUMBER FOUND IN
 ;*LOCATION \$ITEMB. THIS NUMBER INDICATES WHICH ITEM IN THE TABLE IS PERTINENT.
 ;*NOTE1: IF \$ITEMB IS 0 THE ONLY PERTINENT DATA IS (\$ERRPC).
 ;*NOTE2: EACH ITEM IN THE TABLE CONTAINS 4 POINTERS EXPLAINED AS FOLLOWS:

;* EM ::POINTS TO THE ERROR MESSAGE
 ;* DH ::POINTS TO THE DATA HEADER
 ;* DT ::POINTS TO THE DATA
 ;* DF ::POINTS TO THE DATA FORMAT

1
2
3

001602
 001604 065324
 001606 071410
 001610 071534
 001610 071624

\$ERRTB:
 ;ERROR 1 WRONG UNIT SELECTED
 EMT1
 EHT1
 EDT1
 EFT1

4
5
6

001612 065330
 001614 071410
 001616 071534
 001620 071624

;ERROR 2 DEVICE WENT UNAVAILABLE
 EMT2
 EHT1
 EDT1
 EFT1

7
8
9

001622 065336
 001624 071410
 001626 071534
 001630 071624

;ERROR 3 DEVICE WENT NONEXISTENT
 EMT3
 EHT1
 EDT1
 EFT1

10
11
12

001632 065344
 001634 071410
 001636 071534
 001640 071624

;ERROR 4 CONTROLLER NOT READY
 EMT4
 EHT1
 EDT1
 EFT1

13
14
15

001642 065352
 001644 071410
 001646 071534
 001650 071624

;ERROR 5 DRIVE NOT READY AND GO NOT RESET
 EMT5
 EHT1
 EDT1
 EFT1

16
17

;ERROR 6 UNEXPECTED VALUE FOR 'ATA' STATUS

ERROR POINTER TABLE

18	001652	065360	EMT6
	001654	071410	EHT1
	001656	071534	EDT1
	001660	071624	EFT1
19			
20			:ERROR 7 BUS TIMEOUT TRYING TO READ OR WRITE REGISTER
21	001662	065366	EMT7
	001664	000000	0
	001666	000000	0
	001670	000000	0
22			
23			:ERROR 10 DRIVE NOT READY BUT GO IS RESET
24	001672	065374	EMT10
	001674	071410	EHT1
	001676	071534	EDT1
	001700	071624	EFT1
25			
26			:ERROR 11 GO NOT RESET BUT DRIVE IS READY
27	001702	065400	EMT11
	001704	071410	EHT1
	001706	071534	EDT1
	001710	071624	EFT1
28			
29			:ERROR 12 INCORRECT FUNCTION CODE
30	001712	065404	EMT12
	001714	071410	EHT1
	001716	071534	EDT1
	001720	071624	EFT1
31			
32			:ERROR 13 PARITY ERROR READING REMOTE REGISTERS
33	001722	065412	EMT13
	001724	071410	EHT1
	001726	071534	EDT1
	001730	071624	EFT1
34			
35			:ERROR 14 TRANSFER ERROR IS INCORRECT
36	001732	065424	EMT14
	001734	071410	EHT1
	001736	071534	EDT1
	001740	071624	EFT1
37			
38			:ERROR 15 INCORRECT WORD COUNT
39			

ERROR POINTER TABLE				
	001742 065432			EMT15
	001744 071410			EHT1
	001746 071534			EDT1
	001750 071624			EFT1
40				
41		:ERROR	16	INCORRECT BUS ADDRESS
42				
	001752 065440			EMT16
	001754 071410			EHT1
	001756 071534			EDT1
	001760 071624			EFT1
43				
44		:ERROR	17	INCORRECT LBT STATUS
45				
	001762 065450			EMT17
	001764 071410			EHT1
	001766 071534			EDT1
	001770 071624			EFT1
46				
47		:ERROR	20	INCORRECT AOE
48				
	001772 065460			EMT20
	001774 071410			EHT1
	001776 071534			EDT1
	002000 071624			EFT1
49				
50		:ERROR	21	INCORRECT DISK ADDRESS
51				
	002002 065470			EMT21
	002004 071410			EHT1
	002006 071534			EDT1
	002010 071624			EFT1
52				
53		:ERROR	22	INCORRECT CYLINDER ADDRESS
54				
	002012 065500			EMT22
	002014 071410			EHT1
	002016 071534			EDT1
	002020 071624			EFT1
55				
56		:ERROR	23	INCORRECT WLE STATUS
57				
	002022 065510			EMT23
	002024 071410			EHT1
	002026 071534			EDT1
	002030 071624			EFT1
58				
59		:ERROR	24	INCORRECT UPE STATUS
60				
	002032 065520			EMT24

	002034	071410	EHT1	
	002036	071534	EDT1	
	002040	071624	EFT1	
61				
62				:ERROR 25 INCORRECT WCF STATUS
63				
	002042	065530	EMT25	
	002044	071410	EHT1	
	002046	071534	EDT1	
	002050	071624	EFT1	
64				
65				:ERROR 26 INCORRECT WCE STATUS
66				
	002052	065540	EMT26	
	002054	071410	EHT1	
	002056	071534	EDT1	
	002060	071624	EFT1	
67				
68				:ERROR 27 INCORRECT MDPE STATUS
69				
	002062	065550	EMT27	
	002064	071410	EHT1	
	002066	071534	EDT1	
	002070	071624	EFT1	
70				
71				:ERROR 30 INCORRECT DCK STATUS
72				
	002072	065560	EMT30	
	002074	071410	EHT1	
	002076	071534	EDT1	
	002100	071624	EFT1	
73				
74				:ERROR 31 INCORRECT ECH STATUS
75				
	002102	065570	EMT31	
	002104	071410	EHT1	
	002106	071534	EDT1	
	002110	071624	EFT1	
76				
77				:ERROR 32 DLT SHOULD NOT BE SET
78				
	002112	065600	EMT32	
	002114	071410	EHT1	
	002116	071534	EDT1	
	002120	071624	EFT1	
79				
80				:ERROR 33 MXF SHOULD NOT BE SET
81				
	002122	065610	EMT33	
	002124	071410	EHT1	

	002126	071534	EDT1	
	002130	071624	EFT1	
82				
83				;ERROR 34 DTE SHOULD NOT BE SET
84	002132	065620	EMT34	
	002134	071410	EHT1	
	002136	071534	EDT1	
	002140	071624	EFT1	
85				
86				;ERROR 35 INCORRECT HCRC STATUS
87	002142	065630	EMT35	
	002144	071410	EHT1	
	002146	071534	EDT1	
	002150	071624	EFT1	
88				
89				;ERROR 36 INCORRECT HCE STATUS
90	002152	065640	EMT36	
	002154	071410	EHT1	
	002156	071534	EDT1	
	002160	071624	EFT1	
91				
92				;ERROR 37 INCORRECT FER STATUS
93	002162	065650	EMT37	
	002164	071410	EHT1	
	002166	071534	EDT1	
	002170	071624	EFT1	
94				
95				;ERROR 40 DPE SHOULD NOT BE SET (NOT A DATA COMMAND)
96	002172	065660	EMT40	
	002174	071410	EHT1	
	002176	071534	EDT1	
	002200	071624	EFT1	
97				
98				;ERROR 41 LOST 'MOL' DURING PACK ACKNOWLEDGE
99	002202	065666	EMT41	
	002204	071410	EHT1	
	002206	071534	EDT1	
	002210	071624	EFT1	
100				
101				;ERROR 42 UNSAFE ERROR DURING PACK ACKNOWLEDGE
102	002212	065676	EMT42	
	002214	071410	EHT1	
	002216	071534	EDT1	

	002220	071624	EFT1	
103				
104			:ERROR 43	'DPI' ERROR DURING PACK ACKNOWLEDGE
105	002222	065710	EMT43	
	002224	071410	EHT1	
	002226	071534	EDT1	
	002230	071624	EFT1	
106				
107			:ERROR 44	'RMR' ERROR DURING PACK ACKNOWLEDGE
108	002232	065720	EMT44	
	002234	071410	EHT1	
	002236	071534	EDT1	
	002240	071624	EFT1	
109				
110			:ERROR 45	'ILR' ERROR DURING PACK ACKNOWLEDGE
111	002242	065730	EMT45	
	002244	071410	EHT1	
	002246	071534	EDT1	
	002250	071624	EFT1	
112				
113			:ERROR 46	'ILF' ERROR DURING PACK ACKNOWLEDGE
114	002252	065740	EMT46	
	002254	071410	EHT1	
	002256	071534	EDT1	
	002260	071624	EFT1	
115				
116			:ERROR 47	COMPOSITE ERROR STATUS IS INCORRECT
117	002262	065750	EMT47	
	002264	071410	EHT1	
	002266	071534	EDT1	
	002270	071624	EFT1	
118				
119			:ERROR 50	PARITY ERROR WRITING REMOTE REGISTERS
120	002272	065756	EMT50	
	002274	071410	EHT1	
	002276	071534	EDT1	
	002300	071624	EFT1	
121				
122			:ERROR 51	INCORRECT IAE STATUS DURING SEEK COMMAND
123	002302	065766	EMT51	
	002304	071410	EHT1	
	002306	071534	EDT1	
	002310	071624	EFT1	

124				
125			;ERROR 52	OPI ERROR DURING SEEK - MEDIUM IS NOT ON LINE
126	002312	066000		
	002314	071410	EMT52	
	002316	071534	EHT1	
	002320	071624	EDT1	
			EFT1	
127				
128			;ERROR 53	OPI ERROR DURING SEEK - MEDIUM IS ON LINE, ASSUME
129			:	ON CYLINDER LATCH DIDN'T RESET
130	002322	066016		
	002324	071410	EMT53	
	002326	071534	EHT1	
	002330	071624	EDT1	
			EFT1	
131				
132			;ERROR 54	SEEK INCOMPLETE ERROR DURING SEEK COMMAND
133	002332	066034		
	002334	071410	EMT54	
	002336	071534	EHT1	
	002340	071624	EDT1	
			EFT1	
134				
135			;ERROR 55	DEVICE CHECK DURING SEEK COMMAND
136	002342	066044		
	002344	071410	EMT55	
	002346	071534	EHT1	
	002350	071624	EDT1	
			EFT1	
137				
138			;ERROR 56	PIP IS STILL SET AFTER SEEK - SKI IS RESET
139	002352	066056		
	002354	071410	EMT56	
	002356	071534	EHT1	
	002360	071624	EDT1	
			EFT1	
140				
141			;ERROR 57	ATA DID NOT SET DURING SEEK COMMAND
142	002362	066074		
	002364	071410	EMT57	
	002366	071534	EHT1	
	002370	071624	EDT1	
			EFT1	
143				
144			;ERROR 60	I.. ERROR DURING SEEK COMMAND - LOST
145			:	VOLUME VALID
146	002372	066104		
	002374	071410	EMT60	
	002376	071534	EHT1	
			EDT1	

	002400	071624	EFT1	
147				
148				
149				
150				
	002402	066122	EMT61	
	002404	071410	EHT1	
	002406	071534	EDT1	
	002410	071624	EFT1	
151				
152				
153				
154				
	002412	066142	EMT62	
	002414	071410	EHT1	
	002416	071534	EDT1	
	002420	071624	EFT1	
155				
156				
157				
	002422	000000	0	
	002424	000000	0	
	002426	000000	0	
	002430	000000	0	
158				
159				
160				
	002432	066160	EMT64	
	002434	071410	EHT1	
	002436	071534	EDT1	
	002440	071624	EFT1	
161				
162				
163				
	002442	066200	EMT65	
	002444	071410	EHT1	
	002446	071534	EDT1	
	002450	071624	EFT1	
164				
165				
166				
	002452	066220	EMT66	
	002454	071410	EHT1	
	002456	071534	EDT1	
	002460	071624	EFT1	
167				
168				
169				
	002462	066232	EMT67	
	002464	071410	EHT1	

:ERROR 61 ERRONEOUS IVC ERROR DURING SEEK COMMAND -
 ; VOLUME VALID IS STIL SET

:ERROR 62 MOL IS ZERO, BUT OPI WAS NOT
 ; REPORTED DURING SEEK COMMAND

:ERROR 63 UNUSED

:ERROR 64 DRIVE DID NOT DETECT "IVC" ERROR DURING SEEK

:ERROR 65 DRIVE EXECUTED A SEEK WITH ERROR SET

:ERROR 66 UNEXPECTED ERROR SET IN RMER1

:ERROR 67 UNEXPECTED ERROR SET IN RMER2

ERROR POINTER TABLE				
	002466 071534		EDT1	
	002470 071624		EFT1	
170				
171		:ERROR 70		ERRONEOUS "IAE" ERROR DURING RECALIBRATE
172				
	002472 066244		EMT70	
	002474 071410		EHT1	
	002476 071534		EDT1	
	002500 071624		EFT1	
173				
174		:ERROR 71		"ILF" ERROR DURING RECALIBRATE
175				
	002502 066254		EMT71	
	002504 071410		EHT1	
	002506 071534		EDT1	
	002510 071624		EFT1	
176				
177		:ERROR 72		"OPI" ERROR DURING RECALIBRATE DUE TO "MOL" = 0
178				
	002512 066264		EMT72	
	002514 071410		EHT1	
	002516 071534		EDT1	
	002520 071624		EFT1	
179				
180		:ERROR 73		"OPI" ERROR DURING RECALIBRATE BECAUSE ON
181		:		CYLINDER DIDNT DROP
182				
	002522 066302		EMT73	
	002524 071410		EHT1	
	002526 071534		EDT1	
	002530 071624		EFT1	
183				
184		:ERROR 74		"IVC" ERROR DURING RECALIBRATE - "VV" = 0
185				
	002532 066320		EMT74	
	002534 071410		EHT1	
	002536 071534		EDT1	
	002540 071624		EFT1	
186				
187		:ERROR 75		ERRONEOUS "IVC" ERROR DURING RECALIBRATE - "VV" = 1
188				
	002542 066330		EMT75	
	002544 071410		EHT1	
	002546 071534		EDT1	
	002550 071624		EFT1	
189				
190		:ERROR 76		"SKI" ERROR DURING RECALIBRATE
191				
	002552 066350		EMT76	
	002554 071410		EHT1	

	002556	071534		EDT1	
	002560	071624		EFT1	
192					
193			;ERROR	77	'DVC' OCCURRED DURING RECALIBRATE
194					
	002562	066360		EMT77	
	002564	071410		EHT1	
	002566	071534		EDT1	
	002570	071624		EFT1	
195					
196			;ERROR	100	LOST 'MOL' DURING RECALIBRATE - 'OPI' = 0
197					
	002572	066372		EMT100	
	002574	071410		EHT1	
	002576	071534		EDT1	
	002600	071624		EFT1	
198					
199			;ERROR	101	LOST 'VV' DURING RECALIBRATE - 'IVC' = 0
200					
	002602	066410		EMT101	
	002604	071410		EHT1	
	002606	071534		EDT1	
	002610	071624		EFT1	
201					
202			;ERROR	102	'ATA' DID NOT SET DURING RECALIBRATE
203					
	002612	066426		EMT102	
	002614	071410		EHT1	
	002616	071534		EDT1	
	002620	071624		EFT1	
204					
205			;ERROR	103	'OM' DID NOT RESET DURING RECALIBRATE
206					
	002622	066436		EMT103	
	002624	071410		EHT1	
	002626	071534		EDT1	
	002630	071624		EFT1	
207					
208			;ERROR	104	'PIP' IS STIL SET AFTER RECALIBRATE
209					
	002632	066450		EMT104	
	002634	071410		EHT1	
	002636	071534		EDT1	
	002640	071624		EFT1	
210					
211			;ERROR	105	UNEXPECTED 'ILR' ERROR DURING RECALIBRATE
212					
	002642	066466		EMT105	
	002644	071410		EHT1	
	002646	071534		EDT1	

	002650	071624	EFT1	
213				
214			:ERROR 106	UNEXPECTED 'RMR' ERROR DURING RECALIBRATE
215				
	002652	066476	EMT106	
	002654	071410	EHT1	
	002656	071534	EDT1	
	002660	071624	EFT1	
216				
217			:ERROR 107	'UNS' ERROR DURING RECALIBRATE - AC POWER IS LOW
218				
	002662	066506	EMT107	
	002664	071410	EHT1	
	002666	071534	EDT1	
	002670	071624	EFT1	
219				
220			:ERROR 110	CANNOT ACCESS MASSBUS CONTROLLER VIA UNIBUS
221				
	002672	066526	EMT110	
	002674	071432	EHT110	
	002676	071552	EDT110	
	002700	071642	EFT110	
222				
223			:ERROR 111	NONEXISTENT DEVICE
224				
	002702	066540	EMT111	
	002704	071436	EHT111	
	002706	071554	EDT111	
	002710	071644	EFT111	
225				
226			:ERROR 112	DEVICE NOT AVAILABLE
227				
	002712	066546	EMT112	
	002714	071436	EHT111	
	002716	071554	EDT111	
	002720	071644	EFT111	
228				
229			:ERROR 113	BUS TIMEOUT-NED STATUS FAILURE
230				
	002722	066554	EMT113	
	002724	000000	0	
	002726	000000	0	
	002730	000000	0	
231				
232			:ERROR 114	DEVICE NOT AN RM05/3/2
233				
	002732	066570	EMT114	
	002734	071442	EHT114	
	002736	071556	EDT114	
	002740	071646	EFT114	

234			
235			:ERROR 115 RMCS1 NOT INITIALIZED BY UNIBUS
236	002742	066576	EMT115
	002744	071410	EHT1
	002746	071534	EDT1
	002750	071624	EFT1
237			
238			:ERROR 116 RMBA NOT INITIALIZED BY UNIBUS
239	002752	066606	EMT116
	002754	071410	EHT1
	002756	071534	EDT1
	002760	071624	EFT1
240			
241			:ERROR 117 RMCS2 NOT INITIALIZED BY UNIBUS
242	002762	066616	EMT117
	002764	071410	EHT1
	002766	071534	EDT1
	002770	071624	EFT1
243			
244			:ERROR 120 RMER1 NOT INITIALIZED BY UNIBUS
245	002772	066626	EMT120
	002774	071410	EHT1
	002776	071534	EDT1
	003000	071624	EFT1
246			
247			:ERROR 121 RMAS NOT INITIALIZED BY UNIBUS
248	003002	066636	EMT121
	003004	071410	EHT1
	003006	071534	EDT1
	003010	071624	EFT1
249			
250			:ERROR 122 RMMR1 NOT INITIALIZED BY UNIBUS
251	003012	066646	EMT122
	003014	071410	EHT1
	003016	071534	EDT1
	003020	071624	EFT1
252			
253			:ERROR 123 RMDS NOT INITIALIZED BY UNIBUS
254	003022	066656	EMT123
	003024	071410	EHT1
	003026	071534	EDT1
	003030	071624	EFT1

Line	Code	Address	Message
255			
256	:ERROR	124	RMEC2 NOT INITIALIZED BY UNIBUS
257			
		003032 066666	EMT124
		003034 071410	EHT1
		003036 071534	EDT1
		003040 071624	EFT1
258			
259	:ERROR	125	RMMR2 NOT INITIALIZED BY UNIBUS
260			
		003042 066676	EMT125
		003044 071410	EHT1
		003046 071534	EDT1
		003050 071624	EFT1
261			
262	:ERROR	126	RMCS1 NOT CLEARED BY CONTROLLER CLEAR
263			
		003052 066706	EMT126
		003054 071410	EHT1
		003056 071534	EDT1
		003060 071624	EFT1
264			
265	:ERROR	127	RMBA NOT CLEARED BY CONTROLLER CLEAR
266			
		003062 066720	EMT127
		003064 071410	EHT1
		003066 071534	EDT1
		003070 071624	EFT1
267			
268	:ERROR	130	RMCS2 NOT CLEARED BY CONTROLLER CLEAR
269			
		003072 066732	EMT130
		003074 071410	EHT1
		003076 071534	EDT1
		003100 071624	EFT1
270			
271	:ERROR	131	RMER1 NOT CLEARED BY CONTROLLER CLEAR
272			
		003102 066744	EMT131
		003104 071410	EHT1
		003106 071534	EDT1
		003110 071624	EFT1
273			
274	:ERROR	132	RMAS NOT CLEARED BY CONTROLLER CLEAR
275			
		003112 066756	EMT132
		003114 071410	EHT1
		003116 071534	EDT1
		003120 071624	EFT1
276			

277			:ERROR 133	RMMR1 NOT CLEARED BY CONTROLLER CLEAR
278	003122	066770		
	003124	071410	EMT133	
	003126	071534	EHT1	
	003130	071624	EDT1	
			EFT1	
279				
280			:ERROR 134	RMDS NOT CLEARED BY CONTROLLER CLEAR
281	003132	067002		
	003134	071410	EMT134	
	003136	071534	EHT1	
	003140	071624	EDT1	
			EFT1	
282				
283			:ERROR 135	RMEC2 NOT CLEARED BY CONTROLLER CLEAR
284	003142	067014		
	003144	071410	EMT135	
	003146	071534	EHT1	
	003150	071624	EDT1	
			EFT1	
285				
286			:ERROR 136	RMMR2 NOT CLEARED BY CONTROLLER CLEAR
287	003152	067026		
	003154	071410	EMT136	
	003156	071534	EHT1	
	003160	071624	EDT1	
			EFT1	
288				
289			:ERROR 137	RMCS1 NOT CLEARED BY ERROR CLEAR
290	003162	067040		
	003164	071410	EMT137	
	003166	071534	EHT1	
	003170	071624	EDT1	
			EFT1	
291				
292			:ERROR 140	RMCS2 NOT CLEARED BY ERROR CLEAR
293	003172	067050		
	003174	071410	EMT140	
	003176	071534	EHT1	
	003200	071624	EDT1	
			EFT1	
294				
295			:ERROR 141	RMCS1 NOT CLEARED BY DRIVE CLEAR
296	003202	067060		
	003204	071410	EMT141	
	003206	071534	EHT1	
	003210	071624	EDT1	
			EFT1	
297				
298			:ERROR 142	RMDS NOT CLEARED BY DRIVE CLEAR

299

003212	067070	EMT142
003214	071410	EHT1
003216	071534	EDT1
003220	071624	EFT1

300

301

302

:ERROR 143 RMER1 NOT CLEARED BY DRIVE CLEAR

003222	067100	EMT143
003224	071410	EHT1
003226	071534	EDT1
003230	071624	EFT1

303

304

305

:ERROR 144 RMAS NOT CLEARED BY DRIVE CLEAR

003232	067110	EMT144
003234	071410	EHT1
003236	071534	EDT1
003240	071624	EFT1

306

307

308

:ERROR 145 RMMR1 NOT CLEARED BY DRIVE CLEAR

003242	067120	EMT145
003244	071410	EHT1
003246	071534	EDT1
003250	071624	EFT1

309

310

311

:ERROR 146 RMMR2 NOT CLEARED BY DRIVE CLEAR

003252	067130	EMT146
003254	071410	EHT1
003256	071534	EDT1
003260	071624	EFT1

312

313

314

:ERROR 147 RMER2 NOT CLEARED BY DRIVE CLEAR

003262	067140	EMT147
003264	071410	EHT1
003266	071534	EDT1
003270	071624	EFT1

315

316

317

:ERROR 150 RMEC2 NOT CLEARED BY DRIVE CLEAR

003272	067150	EMT150
003274	071410	EHT1
003276	071534	EDT1
003300	071624	EFT1

318

319

320

:ERROR 151 MEDIUM NOT ON LINE

Line	Code	Address	Label	Description
	003302	067160	EMT151	
	003304	071410	EHT1	
	003306	071534	EDT1	
	003310	071624	EFT1	
321				
322			:ERROR 152	DRIVE FAULT
323				
	003312	067172	EMT152	
	003314	071410	EHT1	
	003316	071534	EDT1	
	003320	071624	EFT1	
324				
325			:ERROR 153	UNSAFE SHOULD BE SET BECAUSE DVC IS SET
326				
	003322	067204	EMT153	
	003324	071410	EHT1	
	003326	071534	EDT1	
	003330	071624	EFT1	
327				
328			:ERROR 154	UNSAFE SHOULD NOT BE SET, AC IS LOW
329				
	003332	067222	EMT154	
	003334	071410	EHT1	
	003336	071534	EDT1	
	003340	071624	EFT1	
330				
331			:ERROR 155	VOLUME VALID NOT SET BY PACK ACK
332				
	003342	067240	EMT155	
	003344	071410	EHT1	
	003346	071534	EDT1	
	003350	071624	EFT1	
333				
334			:ERROR 156	OFFSET MODE NOT SET BY OFFSET COMMAND
335				
	003352	067252	EMT156	
	003354	071410	EHT1	
	003356	071534	EDT1	
	003360	071624	EFT1	
336				
337			:ERROR 157	OFFSET MODE NOT RESET BY RTC COMMAND
338				
	003362	067264	EMT157	
	003364	071410	EHT1	
	003366	071534	EDT1	
	003370	071624	EFT1	
339				
340			:ERROR 160	RMOF NOT RESET BY RIP COMMAND
341				
	003372	067276	EMT160	

ERROR POINTER TABLE				
	003374	071410		EHT1
	003376	071534		EDT1
	003400	071624		EFT1
342				
343			:ERROR 161	RMDA NOT RESET BY RIP COMMAND
344				
	003402	067306		EMT161
	003404	071410		EHT1
	003406	071534		EDT1
	003410	071624		EFT1
345				
346			:ERROR 162	RMDC NOT RESET BY RIP COMMAND
347				
	003412	067320		EMT162
	003414	071410		EHT1
	003416	071534		EDT1
	003420	071624		EFT1
348				
349			:ERROR 163	DATA WAS ECC CORRECTED BUT DOES NOT COMPARE WITH
350			:	WRITE BUFFER
351				
	003422	071204		EMT336
	003424	071472		EHT336
	003426	071570		EDT336
	003430	071660		EFT336
352				
353			:ERROR 164	OPI SHOULD NOT BE SET
354				
	003432	067342		EMT164
	003434	071410		EHT1
	003436	071534		EDT1
	003440	071624		EFT1
355				
356			:ERROR 165	IVC SHOULD NOT BE SET
357				
	003442	067350		EMT165
	003444	071410		EHT1
	003446	071534		EDT1
	003450	071624		EFT1
358				
359			:ERROR 166	IAE SHOULD NOT BE SET
360				
	003452	067356		EMT166
	003454	071410		EHT1
	003456	071534		EDT1
	003460	071624		EFT1
361				
362			:ERROR 167	NEM SHOULD NOT BE SET
363				
	003462	067364		EMT167

	003464	071410	EHT1	
	003466	071534	EDT1	
	003470	071624	EFT1	
364				
365				:ERROR 170 INCORRECT 'MOL' STATUS DURING DIAGNOSTIC MODE
366				
	003472	067372	EMT170	
	003474	071410	EHT1	
	003476	071534	EDT1	
	003500	071624	EFT1	
367				
368				:ERROR 171 'ATA' NOT SET DURING RETURN TO CENTERLINE
369				
	003502	067404	EMT171	
	003504	071410	EHT1	
	003506	071534	EDT1	
	003510	071624	EFT1	
370				
371				:ERROR 172 'ATA' NOT SET BY OFFSET COMMAND
372				
	003512	067414	EMT172	
	003514	071410	EHT1	
	003516	071534	EDT1	
	003520	071624	EFT1	
373				
374				:ERROR 173 RMER2 NOT INITIALIZED BY UNIBUS INIT
375				
	003522	067424	EMT173	
	003524	071410	EHT1	
	003526	071534	EDT1	
	003530	071624	EFT1	
376				
377				:ERROR 174 RMER2 NOT INITIALIZED BY CONTROLLER CLEAR
378				
	003532	067434	EMT174	
	003534	071410	EHT1	
	003536	071534	EDT1	
	003540	071624	EFT1	
379				
380				:ERROR 175 SELECTED DEVICE IS IN WRITE PROTECT
381				
	003542	067446	EMT175	
	003544	071410	EHT1	
	003546	071534	EDT1	
	003550	071624	EFT1	
382				
383				:ERROR 176 CANNOT SET DIAGNOSTIC MODE
384				
	003552	067454	EMT176	
	003554	071410	EHT1	

	003556	071534	EDT1	
	003560	071624	EFT1	
385				
386			:ERROR	177 --RESERVED FOR POWER MONITOR BIT FAILURE--
387				
	003562	000000	0	
	003564	000000	0	
	003566	000000	0	
	003570	000000	0	
388				
389			:ERROR	200 INCORRECT 'PIP' STATUS DURING DIAGNOSTIC MODE
390				
	003572	067464	EMT200	
	003574	071410	EHT1	
	003576	071534	EDT1	
	003600	071624	EFT1	
391				
392			:ERROR	201 INCORRECT 'WRL' STATUS DURING DIAGNOSTIC MODE
393				
	003602	067476	EMT201	
	003604	071410	EHT1	
	003606	071534	EDT1	
	003610	071624	EFT1	
394				
395			:ERROR	202 INCORRECT 'SKI' STATUS DURING DIAGNOSTIC MODE
396				
	003612	067510	EMT202	
	003614	071410	EHT1	
	003616	071534	EDT1	
	003620	071624	EFT1	
397				
398			:ERROR	203 INCORRECT 'DVC' STATUS DURING DIAGNOSTIC MODE
399				
	003622	067522	EMT203	
	003624	071410	EHT1	
	003626	071534	EDT1	
	003630	071624	EFT1	
400				
401			:ERROR	204 'VV' WAS NOT RESET BY MAINTENANCE UNIT READY
402				
	003632	067534	EMT204	
	003634	071410	EHT1	
	003636	071534	EDT1	
	003640	071624	EFT1	
403				
404			:ERROR	205 SELECTED DEVICE HAS A PERSISTENT 'SKI' ERROR
405				
	003642	067552	EMT205	
	003644	071410	EHT1	
	003646	071534	EDT1	

Line	Code	Address	Pointer	Description
		003650	071624	EFT1
406				
407	:ERROR	206		"LBC" DID NOT SET DURING DIAGNOSTIC MODE
408		003652	067562	EMT206
		003654	071410	EHT1
		003656	071534	EDT1
		003660	071624	EFT1
409				
410	:ERROR	207		UNEXPECTED LOSS OF "MOL" - MEDIUM IS OFF LINE
411		003662	067572	EMT207
		003664	071410	EHT1
		003666	071534	EDT1
		003670	071624	EFT1
412				
413	:ERROR	210		UNEXPECTED LOSS OF VOLUME VALID - "VV" = 0
414		003672	067604	EMT210
		003674	071410	EHT1
		003676	071534	EDT1
		003700	071624	EFT1
415				
416	:ERROR	211		UNEXPECTED MECHANICAL MOTION - "PIP" = 1
417		003702	067612	EMT211
		003704	071410	EHT1
		003706	071534	EDT1
		003710	071624	EFT1
418				
419	:ERROR	212		UNEXPECTED DEVICE FAULT - "DVC" = 1
420		003712	067626	EMT212
		003714	071410	EHT1
		003716	071534	EDT1
		003720	071624	EFT1
421				
422	:ERROR	213		UNEXPECTED SEEK INCOMPLETE ERROR - "SKI" = 1
423		003722	067642	EMT213
		003724	071410	EHT1
		003726	071534	EDT1
		003730	071624	EFT1
424				
425	:ERROR	214		DRIVE EXECUTED A RECALIBRATE WITH ERROR SET
426		003732	067652	EMT214
		003734	071422	EHT2
		003736	071544	EDT2
		003740	071634	EFT2

427			
428		:ERROR 215	DRIVE DID NOT DETECT "IVC" ERROR DURING RECALIBRATE
429	003742 067672	EMT215	
	003744 071422	EHT2	
	003746 071544	EDT2	
	003750 071634	EFT2	
430			
431		:ERROR 216	INCORRECT "IVC" STATUS
432	003752 067704	EMT216	
	003754 071410	EHT1	
	003756 071534	EDT1	
	003760 071624	EFT1	
433			
434		:ERROR 217	INCORRECT "IAE" STATUS
435	003762 067714	EMT217	
	003764 071410	EHT1	
	003766 071534	EDT1	
	003770 071624	EFT1	
436			
437		:ERROR 220	INCORRECT "WLE" STATUS
438	003772 067724	EMT220	
	003774 071410	EHT1	
	003776 071534	EDT1	
	004000 071624	EFT1	
439			
440		:ERROR 221	INCORRECT "DPI" STATUS
441	004002 067734	EMT221	
	004004 071410	EHT1	
	004006 071534	EDT1	
	004010 071624	EFT1	
442			
443		:ERROR 222	RM DID NOT DETECT RMR ERROR
444	004012 067744	EMT222	
	004014 071410	EHT1	
	004016 071534	EDT1	
	004020 071624	EFT1	
445			
446		:ERROR 223	RM DID NOT DETECT PARITY ERROR ON MASSBUS CONTROL BUS
447	004022 067754	EMT223	
	004024 071446	EHT223	
	004026 071560	EDT223	
	004030 071650	EFT223	

448				
449			:ERROR	224
450				UNUSED
	004032	000000		0
	004034	000000		0
	004036	000000		0
	004040	000000		0
451				
452			:ERROR	225
453				UNUSED
	004042	000000		0
	004044	000000		0
	004046	000000		0
	004050	000000		0
454				
455			:ERROR	226
456				UNUSED
	004052	000000		0
	004054	000000		0
	004056	000000		0
	004060	000000		0
457				
458			:ERROR	227
459				UNUSED
	004062	000000		0
	004064	000000		0
	004066	000000		0
	004070	000000		0
460				
461			:ERROR	230
462				UNUSED
	004072	000000		0
	004074	000000		0
	004076	000000		0
	004100	000000		0
463				
464			:ERROR	231
465				UNUSED
	004102	000000		0
	004104	000000		0
	004106	000000		0
	004110	000000		0
466				
467			:ERROR	232
468				UNUSED
	004112	000000		0
	004114	000000		0
	004116	000000		0
	004120	000000		0
469				

470			:ERROR 233	UNUSED
471				
	004122	000000	0	
	004124	000000	0	
	004126	000000	0	
	004130	000000	0	
472				
473			:ERROR 234	UNUSED
474				
	004132	000000	0	
	004134	000000	0	
	004136	000000	0	
	004140	000000	0	
475				
476			:ERROR 235	UNUSED
477				
	004142	000000	0	
	004144	000000	0	
	004146	000000	0	
	004150	000000	0	
478				
479			:ERROR 236	UNUSED
480				
	004152	000000	0	
	004154	000000	0	
	004156	000000	0	
	004160	000000	0	
481				
482			:ERROR 237	UNUSED
483				
	004162	000000	0	
	004164	000000	0	
	004166	000000	0	
	004170	000000	0	
484				
485			:ERROR 240	UNUSED
486				
	004172	000000	0	
	004174	000000	0	
	004176	000000	0	
	004200	000000	0	
487				
488			:ERROR 241	UNUSED
489				
	004202	000000	0	
	004204	000000	0	
	004206	000000	0	
	004210	000000	0	
490				
491			:ERROR 242	UNUSED

492	004212	000000	0	
	004214	000000	0	
	004216	000000	0	
	004220	000000	0	
493				
494			:ERROR 243	UNUSED
495	004222	000000	0	
	004224	000000	0	
	004226	000000	0	
	004230	000000	0	
496				
497			:ERROR 244	UNUSED
498	004232	000000	0	
	004234	000000	0	
	004236	000000	0	
	004240	000000	0	
499				
500			:ERROR 245	UNUSED
501	004242	000000	0	
	004244	000000	0	
	004246	000000	0	
	004250	000000	0	
502				
503			:ERROR 246	'ATA' NOT RESET BY GO WHEN 'ERR' = 0
504	004252	070030	EMT246	
	004254	071410	EHT1	
	004256	071534	EDT1	
	004260	071624	EFT1	
505				
506			:ERROR 247	'ATA' NOT RESET BY WRITING RMAS
507	004262	070040	EMT247	
	004264	071410	EHT1	
	004266	071534	EDT1	
	004270	071624	EFT1	
508				
509			:ERROR 250	'ATA' WAS RESET BY GO WHEN 'ERR' = 1
510	004272	070052	EMT250	
	004274	071410	EHT1	
	004276	071534	EDT1	
	004300	071624	EFT1	
511				
512			:ERROR 251	PROGRAM INTERRUPT WAS NOT GENERATED
513				

	004302	070066		EMT251
	004304	071422		EHT2
	004306	071544		EDT2
	004310	071634		EFT2
514				
515			:ERROR	252 PROGRAM INTERRUPT SHOULD NOT HAVE BEEN GENERATED
516				
	004312	070074		EMT252
	004314	071422		EHT2
	004316	071544		EDT2
	004320	071634		EFT2
517				
518			:ERROR	253 OFFSET MODE WAS NOT RESET BY WRITING RMDC
519				
	004322	070102		EMT253
	004324	071410		EHT1
	004326	071534		EDT1
	004330	071624		EFT1
520				
521			:ERROR	254 INCORRECT "ILF" STATUS
522				
	004332	070120		EMT254
	004334	071410		EHT1
	004336	071534		EDT1
	004340	071624		EFT1
523				
524			:ERROR	255 INCORRECT "ATA" STATUS
525				
	004342	070130		EMT255
	004344	071410		EHT1
	004346	071534		EDT1
	004350	071624		EFT1
526				
527			:ERROR	256 INCORRECT "ILR" STATUS
528				
	004352	070140		EMT256
	004354	071460		EHT256
	004356	071560		EDT223
	004360	071650		EFT223
529				
530			:ERROR	257 INVALID IAE STATUS DURING SEARCH COMMAND
531				
	004362	070150		EMT257
	004364	071410		EHT1
	004366	071534		EDT1
	004370	071624		EFT1
532				
533			:ERROR	260 "IVC" WAS NOT DETECTED DURING SEARCH COMMAND
534				
	004372	070162		EMT260

040

SEQ 0053

ERROR POINTER TABLE				
	004374	071410		EHT1
	004376	071534		EDT1
	004400	071624		EFT1
535				
536			:ERROR 261	DRIVE EXECUTED SEARCH WITH ERROR SET
537				
	004402	070174		EMT261
	004404	071410		EHT1
	004406	071534		EDT1
	004410	071624		EFT1
538				
539			:ERROR 262	"LBC" ERROR NOT SET DURING DIAGNOSTIC MODE
540				
	004412	070214		EMT262
	004414	071410		EHT1
	004416	071534		EDT1
	004420	071624		EFT1
541				
542			:ERROR 263	"SKI" ERROR DURING SEARCH COMMAND
543				
	004422	070224		EMT263
	004424	071410		EHT1
	004426	071534		EDT1
	004430	071624		EFT1
544				
545			:ERROR 264	"IVC" ERROR DURING SEARCH - LOST VOLUME VALID
546				
	004432	070234		EMT264
	004434	071410		EHT1
	004436	071534		EDT1
	004440	071624		EFT1
547				
548			:ERROR 265	ERRONEOUS IVC ERROR DURING SEARCH - VOLUME IS VALID
549				
	004442	070254		EMT265
	004444	071410		EHT1
	004446	071534		EDT1
	004450	071624		EFT1
550				
551			:ERROR 266	DEVICE FAULT (DVC) DURING SEARCH
552				
	004452	070274		EMT266
	004454	071410		EHT1
	004456	071534		EDT1
	004460	071624		EFT1
553				
554			:ERROR 267	SKI SHOULD HAVE BEEN SET BECAUSE CYLINDER
555			:	ADDRESS IS TOO LARGE
556				
	004462	070306		EMT267

Line	Address	Code	Description
	004464	071410	EHT1
	004466	071534	EDT1
	004470	071624	EFT1
557			
558			:ERROR 270 OPI ERROR DURING SEARCH BECAUSE MOL = 0
559			
	004472	070324	EMT270
	004474	071410	EHT1
	004476	071534	EDT1
	004500	071624	EFT1
560			
561			:ERROR 271 OPI ERROR DURING SEARCH BECAUSE ON CYLINDER
562			: DIDN'T DROP
563			
	004502	070340	EMT271
	004504	071410	EHT1
	004506	071534	EDT1
	004510	071624	EFT1
564			
565			:ERROR 272 LOST MOL DURING SEARCH, OPI IS NOT SET
566			
	004512	070356	EMT272
	004514	071410	EHT1
	004516	071534	EDT1
	004520	071624	EFT1
567			
568			:ERROR 273 PIP STIL SET AFTER SEARCH
569			
	004522	070374	EMT273
	004524	071410	EHT1
	004526	071534	EDT1
	004530	071624	EFT1
570			
571			:ERROR 274 PARITY ERROR OCCURRED WHILE WRITING REMOTE
572			: REGISTERS BUT MXF DID NOT SET
573			
	004532	070412	EMT274
	004534	071410	EHT1
	004536	071534	EDT1
	004540	071624	EFT1
574			
575			:ERROR 275 MXF ERROR - COMPOSITE ERROR OCCURRED BEFORE DATA
576			: COMMAND STARTED
577			
	004542	070430	EMT275
	004544	071410	EHT1
	004546	071534	EDT1
	004550	071624	EFT1
578			
579			:ERROR 276 'OPI' ERROR DURING DATA TRANSFER BECAUSE 'MOL' WAS

580			ZERO
581	004552	070442	EMT276
	004554	071410	EHT1
	004556	071534	EDT1
	004560	071624	EFT1
582			
583	:ERROR	277	'DPI' ERROR DURING DATA TRANSFER BECAUSE 1) ON
584	:		CYLINDER DIDN'T DROP OR 2) SEARCH TIMED OUT OR
585	:		3) RUN TIMED OUT
586			
	004562	070456	EMT277
	004564	071410	EHT1
	004566	071534	EDT1
	004570	071624	EFT1
587			
588	:ERROR	300	'IVC' ERROR DURING DATA TRANSFER BECAUSE VOLUME
589	:		WAS NOT VALID
590			
	004572	070474	EMT300
	004574	071410	EHT1
	004576	071534	EDT1
	004600	071624	EFT1
591			
592	:ERROR	301	ERRONEOUS 'IVC' ERROR DURING DATA TRANSFER - VOLUME
593	:		IS VALID
594			
	004602	070514	EMT301
	004604	071410	EHT1
	004606	071534	EDT1
	004610	071624	EFT1
595			
596	:ERROR	302	'ILR' ERROR DURING DATA TRANSFER
597			
	004612	070536	EMT302
	004614	071410	EHT1
	004616	071534	EDT1
	004620	071624	EFT1
598			
599	:ERROR	303	'ILF' ERROR DURING DATA TRANSFER
600			
	004622	070550	EMT303
	004624	071410	EHT1
	004626	071534	EDT1
	004630	071624	EFT1
601			
602	:ERROR	304	'RMR' ERROR DURING DATA TRANSFER
603			
	004632	070562	EMT304
	004634	071410	EHT1
	004636	071534	EDT1

	004640	071624	EFT1	
604				
605			:ERROR 305	INCORRECT "IAE" STATUS DURING DATA TRANSFER
606				
	004642	070574	EMT305	
	004644	071410	EHT1	
	004646	071534	EDT1	
	004650	071624	EFT1	
607				
608			:ERROR 306	"SKI" ERROR DURING DATA TRANSFER
609				
	004652	070606	EMT306	
	004654	071410	EHT1	
	004656	071534	EDT1	
	004660	071624	EFT1	
610				
611			:ERROR 307	DRIVE DID NOT DETECT SKI ERROR DUE TO CYLINDER
612				
	004662	070616	EMT307	
	004664	071410	EHT1	
	004666	071534	EDT1	
	004670	071624	EFT1	
613				
614			:ERROR 310	DEVICE FAULT DURING DATA TRANSFER
615				
	004672	070636	EMT310	
	004674	071410	EHT1	
	004676	071534	EDT1	
	004700	071624	EFT1	
616				
617			:ERROR 311	LOSS OF BIT CLOCK DURING DATA TRANSFER
618				
	004702	070650	EMT311	
	004704	071410	EHT1	
	004706	071534	EDT1	
	004710	071624	EFT1	
619				
620			:ERROR 312	LOSS OF SYSTEM CLOCK DURING DATA TRANSFER
621				
	004712	070662	EMT312	
	004714	071410	EHT1	
	004716	071534	EDT1	
	004720	071624	EFT1	
622				
623			:ERROR 313	UNSAFE ERROR DURING DATA TRANSFER (DVC = 0)
624				
	004722	070674	EMT313	
	004724	071410	EHT1	
	004726	071534	EDT1	
	004730	071624	EFT1	

625				
626			:ERROR 314	DRIVE TIMING ERROR DURING DATA TRANSFER
627	004732	070714		
	004734	071410		EMT314
	004736	071534		EHT1
	004740	071624		EDT1
				EFT1
628				
629			:ERROR 315	WRITE LOCK ERROR
630	004742	070726		
	004744	071410		EMT315
	004746	071534		EHT1
	004750	071624		EDT1
				EFT1
631				
632			:ERROR 316	ERRONEOUS WRITE LOCK ERROR
633	004752	070740		
	004754	071410		EMT316
	004756	071534		EHT1
	004760	071624		EDT1
				EFT1
634				
635			:ERROR 317	HEADER CRC ERROR DURING DATA TRANSFER
636	004762	070752		
	004764	071410		EMT317
	004766	071534		EHT1
	004770	071624		EDT1
				EFT1
637				
638			:ERROR 320	FORMAT ERROR DURING DATA TRANSFER
639	004772	070762		
	004774	071410		EMT320
	004776	071534		EHT1
	005000	071624		EDT1
				EFT1
640				
641			:ERROR 321	HEADER COMPARE ERROR DURING DATA TRANSFER
642	005002	070772		
	005004	071410		EMT321
	005006	071534		EHT1
	005010	071624		EDT1
				EFT1
643				
644			:ERROR 322	HEADER ERRORS SHOULD NOT BE SET
645	005012	071002		
	005014	071410		EMT322
	005016	071534		EHT1
	005020	071624		EDT1
				EFT1

ERROR POINTER TABLE

646				
647			:ERROR 323	DATA CHECK ERROR DURING DATA TRANSFER
648	005022	071010	EMT323	
	005024	071410	EHT1	
	005026	071534	EDT1	
	005030	071624	EFT1	
649				
650			:ERROR 324	CORRECTABLE DATA CHECK ERROR DURING DATA TRANSFER
651	005032	071020	EMT324	
	005034	071410	EHT1	
	005036	071534	EDT1	
	005040	071624	EFT1	
652				
653			:ERROR 325	UNCORRECTABLE DATA CHECK ERROR DURING DATA TRANSFER
654	005042	071032	EMT325	
	005044	071410	EHT1	
	005046	071534	EDT1	
	005050	071624	EFT1	
655				
656			:ERROR 326	DATA PARITY ERROR DURING READ COMMAND
657	005052	071044	EMT326	
	005054	071410	EHT1	
	005056	071534	EDT1	
	005060	071624	EFT1	
658				
659			:ERROR 327	OFFSET MODE NOT RESET BY WRITE COMMAND
660	005062	071062	EMT327	
	005064	071410	EHT1	
	005066	071534	EDT1	
	005070	071624	EFT1	
661				
662			:ERROR 330	DATA PARITY ERROR DURING WRITE COMMAND
663	005072	071074	EMT330	
	005074	071410	EHT1	
	005076	071534	EDT1	
	005100	071624	EFT1	
664				
665			:ERROR 331	WRITE CLOCK FAILURE DURING WRITE COMMAND
666	005102	071104	EMT331	
	005104	071410	EHT1	
	005106	071534	EDT1	
	005110	071624	EFT1	
667				

668			:ERROR 332	DATA LATE ERROR DURING DATA TRANSFER
669	005112	071116		EMT332
	005114	071410		EHT1
	005116	071534		EDT1
	005120	071624		EFT1
670				
671			:ERROR 333	PIP STIL SET AFTER DATA TRANSFER - SKI = 0
672	005122	071130		EMT333
	005124	071410		EHT1
	005126	071534		EDT1
	005130	071624		EFT1
673				
674			:ERROR 334	LOST MOL DURING DATA TRANSFER - OPI = 0
675	005132	071146		EMT334
	005134	071410		EHT1
	005136	071534		EDT1
	005140	071624		EFT1
676				
677			:ERROR 335	LOST VOLUME VALID DURING DATA TRANSFER - IVC = 0
678	005142	071164		EMT335
	005144	071410		EHT1
	005146	071534		EDT1
	005150	071624		EFT1
679				
680			:ERROR 336	DATA READ DOES NOT COMPARE WITH DATA WRITTEN
681	005152	071204		EMT336
	005154	071472		EHT336
	005156	071570		EDT336
	005160	071660		EFT336
682				
683			:ERROR 337	WRITE CHECK ERROR NOT DETECTED
684	005162	071214		EMT337
	005164	071504		EHT337
	005166	071600		EDT337
	005170	071670		EFT337
685				
686			:ERROR 340	WRITE CHECK ERROR AT UNEXPECTED ADDRESS
687	005172	071224		EMT340
	005174	071472		EHT336
	005176	071570		EDT336
	005200	071660		EFT336
688				
689			:ERROR 341	INCORRECT DATA DURING WRITE CHECK ERROR

690	005202 071236	EMT341	
	005204 071472	EHT336	
	005206 071570	EDT336	
	005210 071660	EFT336	
691			
692		:ERROR 342	"IVC" ERROR NOT DETECTED DURING DATA TRANSFER
693			
	005212 071244	EMT342	
	005214 071410	EHT1	
	005216 071534	EDT1	
	005220 071624	EFT1	
694			
695		:ERROR 343	"FER" NOT DETECTED DURING DATA TRANSFER
696			
	005222 071256	EMT343	
	005224 071410	EHT1	
	005226 071534	EDT1	
	005230 071624	EFT1	
697			
698		:ERROR 344	"HCE" NOT DETECTED DURING DATA TRANSFER
699			
	005232 071270	EMT344	
	005234 071516	EHT344	
	005236 071610	EDT344	
	005240 071700	EFT344	
700			
701		:ERROR 345	"BSE" NOT DETECTED DURING DATA TRANSFER
702			
	005242 071302	EMT345	
	005244 071410	EHT1	
	005246 071534	EDT1	
	005250 071624	EFT1	
703			
704		:ERROR 346	HEADER ERROR WAS DETECTED W/ HCI SET
705			
	005252 071312	EMT346	
	005254 071410	EHT1	
	005256 071534	EDT1	
	005260 071624	EFT1	
706			
707		:ERROR 347	DATA TRANSFER NOT ABORTED W/ COMP ERROR SET
708			
	005262 071326	EMT347	
	005264 071410	EHT1	
	005266 071534	EDT1	
	005270 071624	EFT1	
709			
710		:ERROR 350	LOST VOLUME VALID DURING SEARCH - "IVC" = 0
711			

005272	071340	EMT350
005274	071410	EHT1
005276	071534	EDT1
005300	071624	EFT1

712
713
714

:ERROR 351 "ATA" DID NOT SET DURING SEARCH

005302	071356	EMT351
005304	071410	EHT1
005306	071534	EDT1
005310	071624	EFT1

715
716
717

:ERROR 352 PROGRAM TIMEOUT WHILE TESTING RMLA

005312	071366	EMT352
005314	000000	0
005316	000000	0
005320	000000	0

718
719
720

:ERROR 353 LOOK AHEAD TEST FAILS

005322	071372	EMT353
005324	071530	EHT353
005326	071622	EDT353
005330	071710	EFT353

721
722
723

:ERROR 354 BSE SHOULD NOT BE SET

005332	071402	EMT354
005334	071410	EHT1
005336	071534	EDT1
005340	071624	EFT1

724
725

:PUT ERROR TABLE HERE

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28

```
.SBTTL  ERROR TABLE USAGE
:THE ERROR TABLE ABOVE CONSISTS OF FOUR WORD ENTRIES FOR EACH ERROR
:NUMBER, I.E.,
:
:      EMT - ERROR MESSAGE TABLE ADDRESS
:      EHT - ERROR HEADER TABLE ADDRESS
:      EDT - ERROR DATA TABLE ADDRESS
:      EFT - ERROR FORMAT TABLE ADDRESS
:
:THE EMT ENTRY IS THE ADDRESS OF THE TABLE OF ERROR MESSAGE STRINGS
:FOR THE PARTICULAR ERROR.  EACH ERROR MESSAGE TABLE LISTS THE ADDRESS
:OF ONE OR MORE ERROR MESSAGE STRINGS WHICH ARE TO BE FORMATTED AND
:TYPED BY THE ERROR TYPE SUBROUTINE.  IF THE EMT ENTRY IS ZERO, THERE IS
:NO MESSAGE TO BE TYPED FOR THE ERROR.
:
:SIMILARLY, THE EHT, EDT, AND EFT ENTRIES ARE ADDRESSES OF TABLES
:OF HEADER, DATA AND FORMAT INFORMATION FOR A GIVEN ERROR.  EACH ENTRY
:IN THE ERROR HEADER TABLE MAY OR MAY NOT HAVE AN ASSOCIATED LINE OF
:DATA, HOWEVER, EACH DATA LINE MUST HAVE AN ASSOCIATED FORMAT AND
:HEADER.  THAT IS, A HEADER LINE MAY BE PRINTED WITHOUT ANY DATA,
:BUT A DATA LINE IS NOT PRINTED WITHOUT A HEADER, AND EACH DATA LINE
:MUST ALSO HAVE A FORMAT.
:
:IN SUMMARY,
:      EACH NONZERO ENTRY IS THE ADDRESS OF A TABLE,
:      EACH TABLE IS A LIST OF ADDRESSES WHICH DEFINES THE LOCATIONS
:      OF MESSAGE STRINGS, HEADERS, DATA OR FORMAT.
```

```

1      ;THIS ROUTINE HANDLES UNEXPECTED TIMEOUTS
2
3 005342 011600      BADTMO: MOV      (SP),R0      ;SAVE PC WHERE THE TIME OUT OCCURED
4 005344 005740      TST      -(R0)      ;ADJUST PC -2
5 005346 022626      CMP      (SP)+,(SP)+      ;RESTORE STACK POINTER
6 005350 104401 005356  TYPE      65$      ;;TYPE ASCIZ STRING
   005354 000417      BR       64$      ;;GET OVER THE ASCIZ
   ;:65$: .ASCIZ <CRLF>/UNEXPECTED BUS TIMEOUT, PC=/
   64$:
7 005414 010046      MOV      R0,-(SP)      ;SETUP FOR TYPING OUT PC
8 005416 104402      TYPOC
9 005420 000240      NOP
   ;PUT 'HALT(0)' INSTRUCTION HERE IF YOU WISH
   ;TO STOP ON UNEXPECTED TIMEOUT.
10
11
12      .SBTTL START OF PROGRAM
13
14 005422 012737 177777 001330 START1: MOV      #-1,CHGADR      ;CHANGE RH/RM BUS ADDRESS
15 005430 000402      BR       START2
16
17 005432 005037 001330 START:  CLR      CHGADR      ;NO CHANGE IN ADDRESS
18 005436 000240 START2: NOP
19 005440 005227 000000      INC      #0      ;TTY LOOP, WAIT FOR INCREMENT
20 005444 001375      BNE     -4      ;OF WORD
21 005446 000005      RESET     ;RESET THE WORLD
22
23      .SBTTL INITIALIZE THE COMMON TAGS
   ;;CLEAR THE COMMON TAGS ($CMTAG) AREA
   MOV      #$CMTAG,R6      ;;FIRST LOCATION TO BE CLEARED
   CLR      (R6)+      ;;CLEAR MEMORY LOCATION
   CMP      #SWR,R6      ;;DONE?
   BNE     -6      ;;LOOP BACK IF NO
   MOV      #STACK,SP      ;;SETUP THE STACK POINTER
   ;;INITIALIZE A FEW VECTORS
   MOV      #SCOPE,@#IOTVEC ;;IOT VECTOR FOR SCOPE ROUTINE
   MOV      #340,@#IOTVEC+2 ;;LEVEL 7
   MOV      #ERROR,@#EMTVEC ;;EMT VECTOR FOR ERROR ROUTINE
   MOV      #340,@#EMTVEC+2 ;;LEVEL 7
   MOV      #STRAP,@#TRAPVEC ;;TRAP VECTOR FOR TRAP CALLS
   MOV      #340,@#TRAPVEC+2;LEVEL 7
   MOV      #SPWRDN,@#PWRVEC ;;POWER FAILURE VECTOR
   MOV      #340,@#PWRVEC+2 ;;LEVEL 7
   MOV      $ENDCT,$EOPCT   ;;SETUP END-OF-PROGRAM COUNTER
   CLR      $TIMES      ;;INITIALIZE NUMBER OF ITERATIONS
   CLR      $ESCAPE     ;;CLEAR THE ESCAPE ON ERROR ADDRESS
   MOV     #1,$ERMAX     ;;ALLOW ONE ERROR PER TEST
   MOV     #,$SLPADR    ;;INITIALIZE THE LOOP ADDRESS FOR SCOPE
   MOV     #,$SLPERR   ;;SETUP THE ERROR LOOP ADDRESS
   ;;SIZE FOR A HARDWARE SWITCH REGISTER. IF NOT FOUND OR IT IS
   ;;EQUAL TO A "-1", SETUP FOR A SOFTWARE SWITCH REGISTER.
   MOV     @#ERRVEC,-(SP) ;;SAVE ERROR VECTOR
   MOV     #64$,@#ERRVEC ;;SET UP ERROR VECTOR
   MOV     #DSWR,SWR    ;;SETUP FOR A HARDWARE SWICH REGISTER
   MOV     #DDISP,DISPLAY ;;AND A HARDWARE DISPLAY REGISTER
   CMP     #-1,@SWR    ;;TRY TO REFERENCE HARDWARE SWR
   BNE     66$        ;;BRANCH IF NO TIMEOUT TRAP OCCURRED
   ;;AND THE HARDWARE SWR IS NOT = -1
   BR     65$        ;;BRANCH IF NO TIMEOUT

```



```

005650 012716 005656      64$:  MOV    #65$, (SP)      ;;SET UP FOR TRAP RETURN
005654 000002
005656 012737 000176 001154 65$:  MOV    #SWREG,SWR      ;;POINT TO SOFTWARE SWR
005664 012737 000174 001156      MOV    #DISPREG,DISPLAY
005672 012637 000004      66$:  MOV    (SP)+,@#ERRVEC    ;;RESTORE ERROR VECTOR

005676 005037 001230      CLR    $PASS            ;;CLEAR PASS COUNT
005702 132737 000200 001243      BITB  #APTSIZE,$ENVM    ;;TEST USER SIZE UNDER APT
005710 001403      BEQ    67$              ;;YES,USE NON-APT SWITCH
005712 012737 001244 001154      MOV    #$$SWREG,SWR    ;;NO,USE APT SWITCH REGISTER
005720
24      ;SETUP "TIMEOUT" TRAP VECTOR FOR UNEXPECTED BUS TIMEOUTS
25 005720 012737 005342 000004      MOV    #BADTMO,ERRVEC  ;;SETUP FOR UNEXPECTED TIMEOUT
26 005726 012737 000300 000006      MOV    #PR6,ERRVEC+2  ;;LEVEL 6
27
28      .SBTTL  TYPE PROGRAM NAME
      ;;TYPE THE NAME OF THE PROGRAM IF FIRST PASS
005734 005227 177777      INC    #-1              ;;FIRST TIME?
005740 001035      BNE    68$              ;;BRANCH IF NO
005742 022737 032122 000042      CMP    #SENDAD,@#42    ;;ACT-11?
005750 001431      BEQ    68$              ;;BRANCH IF YES
005752 104401 005760      TYPE  ,69$              ;;TYPE ASCIZ STRING
005756 000426      BR     68$              ;;GET OVER THE ASCIZ
      ;;69$: .ASCIZ <CRLF>@CZRMNBO - RM05/3/2 FUNCTIONAL TEST, PT 2@<CRLF>
006034
      68$: .SBTTL  GET VALUE FOR SOFTWARE SWITCH REGISTER
006034 005737 000042      TST    @#42              ;;ARE WE RUNNING UNDER XXDP/ACT?
006040 001012      BNE    70$              ;;BRANCH IF YES
006042 123727 001242 000001      CMPB  $ENV,#1           ;;ARE WE RUNNING UNDER APT?
006050 001406      BEQ    70$              ;;BRANCH IF YES
006052 023727 001154 000176      CMP    SWR,#SWREG      ;;SOFTWARE SWITCH REG SELECTED?
006060 001005      BNE    71$              ;;BRANCH IF NO
006062 104407      GTSWR                    ;;GET SOFT-SWR SETTINGS
006064 000403
006066 112737 000001 001150 70$:  MOVB  #1,$AUTOB        ;;SET AUTO-MODE INDICATOR
006074      71$:

29
30      ;THE FOLLOWING FINDS OUT THE PROGRAM CONTROL MODE:
31      ;PAPER TAPE (MANUAL), ACT11, XXDP CHAIN OR DUMP
32
33 006074 005037 001332      CLR    XXDP              ;CLEAR 'XXDP' LOAD DEVICE STORAGE
34 006100 122737 000016 000041      CMPB  #16,@#41          ;LOADED FROM AN RM05/3/2 ?
35 006106 001160      BNE    3$               ;BRANCH IF NOT
36 006110 013737 000040 001332      MOV    @#40,XXDP        ;GET DEVICE INDICATOR AND NUMBER
37 006116 122737 000007 001332      CMPB  #7,XXDP           ;IS IT A VALID NUMBER ?
38 006124 103002      BHIS  1$                ;YES
39 006126 105037 001332      CLRB  XXDP              ;NO, DEFAULT TO DRIVE 0
40 006132 005737 000042      1$:  TST    @#42              ;CHAIN MODE OR ACT11 AUTO ACCEPT ?
41 006136 001425      BEQ    2$               ;BR IF NEITHER
42 006140 104401 006146      TYPE  ,73$              ;;TYPE ASCIZ STRING
006144 000412      BR     72$              ;;GET OVER THE ASCIZ
      ;;73$: .ASCIZ <CRLF>/NOT TESTING DRIVE /
      72$:
43 006172 005046      CLR    -(SP)            ;CLEAR WORD ON STACK
44 006174 113716 001332      MOVB  XXDP,(SP)        ;GET DRIVE ADDRESS
45 006200 104403      TYPOS                    ;TYPE THE ADDRESS
46 006202 001      .BYTE 1                ;ONLY 1 CHARACTER
    
```

```

47 006203      000      .BYTE 0      ;SUPRESS LEADING ZEROS
48 006204 104401 001217  TYPE  , $CRLF ;CR-LF
49 006210 000517      BR 3$      ;GET NUMBER OF DRIVES
50
51 006212 005227 177777 2$: INC #-1      ;FIRST TIME THRU HERE ?
52 006216 001114      BNE 3$      ;NO
53 006220 104401 006226  TYPE ,75$    ;:TYPE ASCIZ STRING
    006224 000410      BR -74$     ;:GET OVER THE ASCIZ
    ;:75$: .ASCIZ <CRLF>/TO TEST DRIVE /
    74$:
54 006246 005046      CLR -(SP)    ;CLEAR WORD ON STACK
55 006250 113716 001332  MOVB XXDP,(SP) ;GET DRIVE ADDRESS
56 006254 104403      TYPOS      ;TYPE DRIVE ADDRESS
57 006256      001      .BYTE 1      ;ONLY 1 CHARACTER
58 006257      000      .BYTE 0      ;SUPPRESS LEADING ZEROS
59 006260 104401 006266  TYPE ,77$    ;:TYPE ASCIZ STRING
    006264 000431      BR 76$      ;:GET OVER THE ASCIZ
    ;:77$: .ASCIZ /, HALT PROGRAM, REMOVE RRDP PACK AND REPLACE IT/<CRLF>
    76$:
60 006350 104401 006356  TYPE ,78$    ;:TYPE ASCIZ STRING
    006354 000435      BR 3$      ;:GET OVER THE ASCIZ
    ;:78$: .ASCIZ /WITH A WORK PACK, CLEAR LOCATION 40 AND RESTART PROGRAM./<CRLF>
    3$:
64 ;CHECK FOR AUTO MODE OR STANDLONE MODE
65 006450 005737 000042  TST @#42    ;RUNNING IN AUTO MODE ?
66 006454 001561      BEQ STANDALONE ;BR IF NO
67 006456 012737 000377 001300  MOV #377,$DEV ;SET DEVICE MAP FOR ALL DRIVES
68
69 ;PROGRAM IS RUNNING IN AUTO MODE - SEE IF SIZING IS ALLOWED
70 XSIZ:
71 006464 132737 000200 001243  BITB #BIT7,$ENVM ;SIZING ALLOWED ?
72 006472 001146      BNE 12$     ;NO
73
74 006474 005001      CLR R1      ;START FROM DRIVE 0
75 006476 013700 001276  MOV $BASE,R0 ;LOAD THE BASE ADDRESS
76 006502 104401 064350  TYPE ,SYSTAT ;TYPE 'UNIT STATUS:'
77
78 006506 136137 064666 001300 1$: BITB ATNTBL(R1),$DEV ;IS DEVICE PRESENT IN MAP ?
79 006514 001531      BEQ 11$     ;BR IF NO
80 006516 104401 001217  TYPE , $CRLF ;CR-LF
81 006522 010146      MOV R1,-(SP) ;:SAVE R1 FOR TYPEOUT
    006524 104403      TYPOS      ;:GO TYPE--OCTAL ASCII
    006526      002      .BYTE 2      ;:TYPE 2 DIGIT(S)
    006527      000      .BYTE 0      ;:SUPPRESS LEADING ZEROS
82 006530 104401 064560  TYPE ,BLNKS4 ;TYPE 4 BLANKS
83
84 006534 012760 000040 000010  MOV #CLR,RMCS2(R0) ;CLEAR MASS BUS
85 006542 010160 000010  MOV R1,RMCS2(R0) ;LOAD THE DRIVE ADDRESS
86 006546 005760 000012  TST RMD5(R0) ;ACCESS DRIVE REGISTER
87 006552 032760 010000 000010  BIT #NED,RMCS2(R0) ;IS DRIVE PRESENT ?
88 006560 001051      BNE 3$      ;BR IF NO
89 006562 032760 004000 000000  BIT #DVA,RMCS1(R0) ;IS DRIVE AVAILABLE ?
90 006570 001450      BEQ 4$      ;BR IF NO
91 006572 016002 000026  MOV RMDT(R0),R2 ;SAVE DRIVE TYPE REGISTER IN R2
92 006576 012737 064366 006776  MOV # $RM02,10$ ;ASSUME RM02 DEVICE
93 006604 022702 020025  CMP #20025,R2 ;SINGLE PORT RM02 ?
94 006610 001430      BEQ 2$      ;BR IF YES
    
```


95	006612	022702	024025			CMP	#24025,R2	:DUAL PORT RM02 ?
96	006616	001425				BEQ	2\$:BR IF YES
97	006620	012737	064373	006776		MOV	#\$RM03,10\$:ASSUME RM03 DEVICE
98	006626	022702	020024			CMP	#20024,R2	:SINGLE PORT RM03 ?
99	006632	001417				BEQ	2\$:BR IF YES
100	006634	022702	024024			CMP	#24024,R2	:DUAL PORT RM03 ?
101	006640	001414				BEQ	2\$:BR IF YES
102	006642	012737	064400	006776		MOV	#\$RM05,10\$:ASSUME RM05 DEVICE
103	006650	022702	020027			CMP	#20027,R2	:SINGLE PORT RM05 ?
104	006654	001406				BEQ	2\$:BR IF YES
105	006656	022702	024027			CMP	#24027,R2	:DUAL PORT RM05 ?
106	006662	001403				BEQ	2\$:BR IF YES
107	006664	104401	064405			TYPE	,NOTRM	:DRIVE NOT AN RM05/3/2
108	006670	000412				BR	5\$:CHECK NEXT DRIVE
109	006672	032760	010000	000012	2\$:	BIT	#MOL,RMDS(R0)	:IS MEDIUM ON LINE ?
110	006700	001412				BEQ	6\$:BR IF NO
111	006702	000417				BR	7\$	
112								
113	006704	104401	064443		3\$:	TYPE	,NOTPRS	:DRIVE NOT PRESENT
114	006710	000402				BR	5\$:CHECK NEXT DRIVE
115								
116	006712	104401	064460		4\$:	TYPE	,NOTAVL	:DRIVE NOT AVAILABLE
117	006716	146137	064666	001300	5\$:	BICB	ATNTBL(R1), \$DEVM	:CLEAR DEVICE FROM BIT MAP
118	006724	000425				BR	11\$:CHECK NEXT DRIVE
119								
120	006726	104401	064477		6\$:	TYPE	,UNTOFF	:DRIVE OFFLINE
121	006732	146137	064666	001300		BICB	ATNTBL(R1), \$DEVM	:CLEAR DEVICE FROM BIT MAP
122	006740	000413				BR	9\$:PRINT DRIVE TYPE
123								
124	006742	005737	001332		7\$:	TST	XXDP	:LOADED FROM RM05/3/2 ?
125	006746	001406				BEQ	8\$:NO
126	006750	123701	001332			CMPB	XXDP,R1	:IS THIS THE DRIVE ?
127	006754	001360				BNE	5\$:BR IF NO
128	006756	104401	064426			TYPE	,LODEV	:DRIVE IS LOAD DEVICE
129	006762	000755				BR	5\$	
130								
131	006764	104401	064510		8\$:	TYPE	,UNTON	:DRIVE ONLINE
132	006770	104401	064562		9\$:	TYPE	,BLNKS2	:TYPE 2 BLANKS
133	006774	104401				TYPE		:PRINT DRIVE TYPE
134	006776	000000			10\$:	.WORD	0	:MESSAGE ADDRESS HERE
135								
136	007000	005201			11\$:	INC	R1	:INCREMENT THE DRIVE ADDRESS
137	007002	020127	000007			CMP	R1,#7	:ALL DRIVES ARE CHECKED ?
138	007006	003637				BLE	1\$:BRANCH IF NOT
139								
140	007010	104401	001217		12\$:	TYPE	, \$CRLF	:CR-LF
141	007014	000137	007476			JMP	CMNSTART	:JUMP TO COMMON START

```

1      .SBTTL  STANDALONE INPUT ROUTINES
2
3      007020
4      007020  004737  061230
5
6      007024  005227  177777
7      007030  001023
8
9      :SEE IF OPERATOR WANTS HELP TEXT
10
11     007032  104401  063450
12     007036  104411
13     007040  012637  001176
14     007044  123727  001176  000131
15     007052  001005
16     007054  104401  001176
17     007060  104401  101360
18     007064  000414
19     007066  104401  064554
20     007072  104401  001217
21     007076  000407
22
23     :SEE IF USER WANTS TO CHANGE UNIBUS ADDRESS
24     007100
25     007100  005737  001330
26     007104  001457
27     007106  005037  001330
28     007112  104401  001217
29
30     :DIALOGUE TO CHANGE THE UNIBUS ADDRESS, VECTOR ADDRESS AND INTERRUPT PRIORITY
31     007116
32     007116  104401  064025
33     007122  013746  001276
34     007126  104402
35     007130  104401  064562
36     007134  104413
37     007136  012637  001176
38     007142  001412
39     007144  022737  160000  001176
40     007152  101403
41     007154  104401  064035
42     007160  000756
43     007162  013737  001176  001276
44     007170  104401  064077
45     007174  005046
46     007176  113716  001272
47     007202  104402
48     007204  104401  064562
49     007210  104413
50     007212  012637  001176
51     007216  001412
52     007220  022737  001000  001176
53     007226  101003
54     007230  104401  064106
55     007234  000755
56     007236  113737  001176  001272

```

```

STANDALONE:
JSR    PC,$TKINT      :INITIALIZE CONSOLE
INC    #-1            :FIRST TIME THRU HERE ?
BNE    2$             :BR IF NO

```

```

:SEE IF OPERATOR WANTS HELP TEXT
TYPE   ,MSHELP        :WANT HELP ?
RDCHR  :              :GET RESPONSE
MOV    (SP)+,$TMP1    :SAVE AND ECHO RESPONSE
CMPB   $TMP1,#'Y      :WAS IT A YES RESPONSE ?
BNE    1$             :NO
TYPE   , $TMP1        :TYPE 'Y'
TYPE   ,HELP          :YES - TYPE HELP TEXT
BR     3$
1$:    TYPE   ,N        :TYPE 'N'
TYPE   , $CRLF        :CR-LF
BR     3$

```

```

:SEE IF USER WANTS TO CHANGE UNIBUS ADDRESS
2$:    TST    CHGADR    :CHANGE RH/RM BUS ADDRESS ?
BEQ    7$             :BR IF NO
CLR    CHGADR        :NO CHANGE NEXT TIME
TYPE   , $CRLF        :CR-LF

```

```

:DIALOGUE TO CHANGE THE UNIBUS ADDRESS, VECTOR ADDRESS AND INTERRUPT PRIORITY
3$:    TYPE   ,CNSLO1   :TYPE CURRENT BUS ADDRESS
MOV    $BASE,-(SP)    :SAVE $BASE FOR TYPEOUT
TYPOC  :              :GO TYPE--OCTAL ASCII(ALL DIGITS)
TYPE   ,BLNKS2       :TYPE 2 BLANKS
RDOCT  :              :GET NEW BUS ADDRESS
MOV    (SP)+,$TMP1    :CARRIAGE RETURN ?
BEQ    5$             :YES-SKIP TO NEXT ENTRY
CMP    #160000,$TMP1 :BASE ADDRESS IN I/O PAGE ?
BLOS   4$             :YES
TYPE   ,CNSLO2       :TYPE WARNING MESSAGE
BR     3$             :TRY AGAIN
MOV    $TMP1,$BASE    :STORE NEW BUS ADDRESS

```

```

5$:    TYPE   ,CNSLO3   :TYPE CURRENT VECTOR ADDRESS
CLR    -(SP)
MOVB   $VECT1,(SP)   :GET CURRENT VECTOR ADDRESS
TYPOC  :              :TYPE 2 BLANKS
RDOCT  :              :GET NEW VECTOR ADDRESS
MOV    (SP)+,$TMP1    :CARRIAGE RETURN?
BEQ    7$             :YES-SKIP TO NEXT ENTRY
CMP    #1000,$TMP1    :VECTOR ADDRESS < 1000 ?
BHI    6$             :YES!!
TYPE   ,CNSLO4       :TYPE WARNING MESSAGE
BR     5$             :RETRY
MOVB   $TMP1,$VECT1  :STORE NEW VECTOR ADDRESS

```



```

57
58
59 007244 005227 177777
60 007250 001002
61 007252 104401 064142
62 007256 104401 001217
63 007262 005037 001300
64 007266 104401 064326
65 007272 104411
66 007274 012637 001176
67 007300 023727 001176 000101
68 007306 001007
69 007310 104401 063434
70 007314 012737 000377 001300
71 007322 000137 006464
72
73 007326 023727 001176 000015 10$:
74 007334 001436
75 007336 104401 001176
76 007342 023727 001176 000060
77 007350 002430
78 007352 023727 001176 000067
79 007360 003427
80 007362 000423
81
82 007364 104411
83 007366 012637 001176
84 007372 023727 001176 000015
85 007400 001432
86 007402 104401 063445
87 007406 104401 001176
88 007412 023727 001176 000060
89 007420 002404
90 007422 023727 001176 000067
91 007430 003403
92 007432 104401 064304
93 007436 000711
94
95 007440 013701 001176
96 007444 042701 177770
97 007450 156137 064666 001300
98 007456 122737 000377 001300
99 007464 101337
100 007466 104401 001217
101 007472 000137 006464

;DIALOGUE TO INPUT DEVICE NUMBERS
7$: INC #-1 ;FIRST TIME THRU ?
    BNE 8$ ;BR IF NO
    TYPE ,CNSL07 ;TYPE INPUT INSTRUCTIONS
8$: TYPE , $CRLF ;CR-LF
9$: CLR $DEV ;CLEAR DEVICE MAP
    TYPE ,MSDRVS ;TYPE 'DRIVE(S): '
    RDCHR
    MOV (SP)+,$TMP1 ;GET RESPONSE
    CMP $TMP1,#'A ;IS INPUT 'A' ?
    BNE 10$ ;NO
    TYPE ,ALL ;YES, TYPE 'ALL' AND GO
    MOV #377,$DEV ;SET DEVICE MAP FOR ALL DRIVES
    JMP XSIZ ;AUTO SIZE.

10$: CMP $TMP1,#CR ;CARRIAGE RETURN ?
    BEQ 12$ ;YES
    TYPE , $TMP1 ;ECHO RESPONSE
    CMP $TMP1,#'0 ;NUMBER < 0 ?
    BLT 12$ ;YES
    CMP $TMP1,#'7 ;NUMBER > 7 ?
    BLE 13$ ;NO
    BR 12$ ;ILLEGAL INPUT

11$: RDCHR
    MOV (SP)+,$TMP1 ;GET RESPONSE
    CMP $TMP1,#CR ;CARRIAGE RETURN ?
    BEQ 14$ ;YES
    TYPE ,COMMA ;TYPE ','
    TYPE , $TMP1 ;ECHO RESPONSE
    CMP $TMP1,#'0 ;NUMBER < 0 ?
    BLT 12$ ;YES
    CMP $TMP1,#'7 ;NUMBER > 7 ?
    BLE 13$ ;NO
    TYPE ,CNSL08 ;TYPE CR-LF '' ?ILLEGAL INPUT''
    BR 9$ ;RETRY

13$: MOV $TMP1,R1 ;R1 = DRIVE NUMBER
    BIC #^C7,R1
    BISB ATNTBL(R1),$DEV ;SET DEVICE IN MAP
    CMPB #377,$DEV ;DONE ?
    BHI 11$ ;NO

14$: TYPE , $CRLF ;CR-LF
    JMP XSIZ ;GO SIZE DEVICES

```

```

1
2 007476      :ASSEMBLE TEST QUE FROM DEVICE MAP
3 007476 104401 064520 CMNSTART:
4 007502 013700 001300      TYPE      ,DRIVES      :TYPE 'DRIVE(S) TO BE TESTED'
5 007506 001004      MOV      $DEVN,R0      :R0 = DEVICE MAP
6 007510 104401 063445      BNE      1$           :BR IF DRIVES TO TEST
7 007514 104401 064547      TYPE      ,COMMA      :TYPE ' '
8 007520 012701 001470      TYPE      ,NONE       :TYPE 'NONE'
9 007524 010137 001466      1$:      MOV      #TSTQUE+2,R1 :R1 = ADDRESS OF FIRST ENTRY IN QUE
10 007530 012702 000001      MOV      R1,TSTQUE    :INITIALIZE ENTRY POINTER
11 007534 005003      MOV      #1,R2        :R2 = DEVICE POINTER
12 007536 030200      CLR      R3           :R3 = DEVICE NUMBER
13 007540 001413      2$:      BIT      R2,R0        :IS THIS DEVICE IN MAP ?
14 007542 104401 063445      BEQ      3$           :NO !!
15 007546 010311      TYPE      ,COMMA      :TYPE ' '
16 007550 010346      MOV      R3,(R1)      :YES - ENTER DEVICE NUMBER IN QUE
    007552 104403      MOV      R3,-(SP)     :SAVE R3 FOR TYPEOUT
    007554 001      TYPOS      1         :GO TYPE--OCTAL ASCII
    007555 000      .BYTE      1         :TYPE 1 DIGIT(S)
17 007556 116361 064666 000001 .BYTE      0         :SUPPRESS LEADING ZEROS
18 007564 062701 000002      MOVB     ATNTBL(R3),1(R1) :ENTER ATTENTION BIT IN QUE
19 007570 006302      ADD      #2,R1        :ADVANCE ENTRY POINTER
20 007572 105702      3$:      ASL      R2           :ADVANCE DEVICE POINTER
21 007574 001402      TSTB     R2           :DONE ALL DEVICES ?
22 007576 005203      BEQ      4$           :YES
23 007600 000756      INC      R3           :ADVANCE DEVICE NUMBER
24 007602 005011      BR       2$           :ENTER NEXT DEVICE
25 007604 104401 001217      4$:      CLR      (R1)        :TERMINATE TEST QUE
    007604 104401 001217      TYPE     ,$CRLF       :TYPE CR-LF
26
27      :SIZE FOR CLOCK
28 007610 004737 036460      JSR      PC,$IZCLK    :SEE IF CLOCK PRESENT
29 007614 000425      BR       6$           :YES - CLOCK IS PRESENT
30 007616 104401 007624      TYPE     ,65$        :TYPE ASCII STRING
    007622 000413      BR       64$        :GET OVER THE ASCIIZ
    007652      ;;65$: .ASCIIZ <CRLF>/NO 'L' OR 'P' CLOCK/
31 007652 005737 000042      64$:      TST      @#42        :ANY MONITOR PRESENT ?
32 007656 001002      BNE      5$           :BR IF YES
33 007660 000137 005432      JMP      START       :JUMP TO START
34 007664 000137 032112      5$:      JMP      $GET42      :RETURN CONTROL TO MONITOR
35 007670
36
37 007670 000240      READY:  NOP           :READY TO START TEST
38 007672 105737 001300      TSTB     $DEVN        :ANY DRIVES IN MAP ?
39 007676 001007      BNE      2$           :BR IF YES
40 007700 005737 000042      TST      @#42        :ANY MONITOR PRESENT ?
41 007704 001002      BNE      1$           :BR IF YES
42 007706 000137 005432      JMP      START       :JUMP TO START
43 007712 000137 032112      1$:      JMP      $GET42      :RETURN CONTROL TO MONITOR
44
45 007716 105037 001116      2$:      CLRB     $TSTNM      :RESET TEST NUMBER
46 007722 005037 001206      CLR      $TIMES      :INITIALIZE NUMBER OF ITERATIONS
47 007726 005037 001326      CLR      CTLFG       :CLEAR CONTROL-C FLAG
48 007732 004737 061230      JSR      PC,$TKINT    :INITIALIZE ITY
49 007736 012746 000240      MOV      #PR5,-(SP)   :PUT NEW PS ON STACK
    007742 012746 007750      MOV      #64$,-(SP)  :PUT NEW PC ON STACK
    007746 000002      RTI                :POP NEW PC AND PS

```



```

007750
50 007750 117737 171512 001234 64$:      MOVB  @TSTQUE,$UNIT  ;LOAD DRIVE NUMBER
51 007756 005037 001512          CLR   MEDENB        ;CLEAR MEDIA ENABLE
52
53          ;CLEAR MASSBUS CONTROLLER, SELECT DRIVE AND DETERMINE THE LAST TRACK
54          ;OF THE DIFFERENT DRIVE TYPES
55
56 007762 012737 002000 001334      MOV   #TA4,LSTRK    ;ASSUME LAST TRACK FOR RM02/3 = 4.
57 007770 013700 001276          MOV   $BASE,R0      ;R0 = UNIBUS ADDRESS
58 007774 012760 000040 000010      MOV   #CLR,RMCS2(R0) ;CLEAR MASSBUS
59 010002 117760 171460 000010      MOVB  @TSTQUE,RMCS2(R0) ;SELECT DEVICE UNDER TEST
60 010010 016002 000026          MOV   RMDT(R0),R2   ;GET RMDT AND
61 010014 042702 177770          BIC   #177770,R2    ;SAVE DRIVE TYPE BITS
62 010020 022702 000007          CMP   #7,R2         ;IS IT AN RM05 ?
63 010024 001003          BNE   3$           ;NO, MUST BE AN RM02 OR RM03
64 010026 012737 011000 001334      MOV   #TA16!TA2,LSTRK ;YES--SET LAST TRACK = 18.
65
66          ;TYPE DRIVE NUMBER TO BE TESTED($UNIT)
67
68 010034 104401 001217 3$:      TYPE  ,SRLF        ;CR-LF
69 010040 104401 064342          TYPE  ,MSGDRV      ;TYPE 'DRIVE'
70 010044 013746 001234          MOV   $UNIT,-(SP)  ;;SAVE $UNIT FOR TYPEOUT
                          ;;TYPE DRIVE NUMBER
                          ;;GO TYPE--OCTAL ASCII
                          ;;TYPE 2 DIGIT(S)
                          ;;SUPPRESS LEADING ZEROS
                          ;THESE TWO LOOPS ARE ADDED TO
                          ;WAIT FOR TTY
      TYPOS
      .BYTE 2
      .BYTE 0
71 010054 005004          CLR   R4
72 010056 005304          DEC  R4
73 010060 001376          BNE  .-2
74 010062 005304          DEC  R4
75 010064 001376          BNE  .-2

```

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32

010066
010066 000004
010070 000240
010072 012706 001100
010076 013700 001276
010102 013701 001466
010106 012737 000001 001226
010114 005001
010116 013746 000004
010122 013746 000006
010126 012737 010230 000004
010134 012737 000300 000006
010142 110160 000001
010146 010160 000002
010152 016002 000002
010156 010160 000004
010162 016002 000004
010166 016046 000010
010172 010160 000010
010176 016002 000010
010202 012660 000010
010206 010160 000022
010212 016002 000022
010216 012637 000006
010222 012637 000004
010226 000417
010230 022626
010232 012637 000006
010236 012637 000004
010242 104110
010244 005737 000042
010250 001002
010252 000137 005422
010256 005037 001300
010262 000137 031724
010266

*TEST 1 CONTROLLER ACCESS TEST

TST1:
SCOPE :SCOPE CALL
NOP :START OF TEST
MOV #STACK,SP :INITIALIZE STACK POINTER
MOV \$BASE,R0 :R0 = UNIBUS ADDRESS
MOV TSTQUE,R1 : (R1) = DEVICE BEING TESTED
MOV #1,\$TESTN ;;SET TEST NUMBER IN APT MAIL BOX
CLR R1
MOV ERRVEC,-(SP) ;;PUSH ERRVEC ON STACK
MOV ERRVEC+2,-(SP) ;;PUSH ERRVEC+2 ON STACK
MOV #1\$,ERRVEC
MOV #PR6,ERRVEC+2
MOVB R1,RMCS1+1(R0) :MOVE HI BYTE TO RMCS1
MOV R1,RMWC(R0) :MOVE WORD COUNT REGISTER
MOV RMWC(R0),R2
MOV R1,RMBA(R0) :MOVE BUS ADDRESS REGISTER
MOV RMBA(R0),R2
MOV RMCS2(R0),-(SP) ;;PUSH RMCS2(R0) ON STACK
MOV R1,RMCS2(R0) :MOVE CONTROL STATUS REGISTER
MOV RMCS2(R0),R2
MOV (SP)+,RMCS2(R0) ;;POP STACK INTO RMCS2(R0)
MOV R1,RMDB(R0) :MOVE DATA BUFFER
MOV RMDB(R0),R2
MOV (SP)+,ERRVEC+2 ;;POP STACK INTO ERRVEC+2
MOV (SP)+,ERRVEC ;;POP STACK INTO ERRVEC
BR 3\$:NO BUS TIMEOUT OCCURRED
1\$: CMP (SP)+,(SP)+ :ADJUST STACK
MOV (SP)+,ERRVEC+2 ;;POP STACK INTO ERRVEC+2
MOV (SP)+,ERRVEC ;;POP STACK INTO ERRVEC
EMT 110
TST @#42 :STAND ALONE MODE ?
BNE 2\$:NO!!
JMP START1 :YES-GO GET \$BASE
2\$: CLR \$DEVM :FUDGE NO DRIVES IN MAP
JMP \$EOP :RETURN TO \$EOP
3\$:

*TEST 2 FORMAT ZEROS

010266
010266 000004
010270 000240
010272 012706 001100
010276 013700 001276
010302 013701 001466
010306 012737 000002 001226
010314 012737 000000 001444
010322

TST2:
SCOPE :SCOPE CALL
NOP :START OF TEST
MOV #STACK,SP :INITIALIZE STACK POINTER
MOV \$BASE,R0 :R0 = UNIBUS ADDRESS
MOV TSTQUE,R1 : (R1) = DEVICE BEING TESTED
MOV #2,\$TESTN ;;SET TEST NUMBER IN APT MAIL BOX
:SETUP PARAMETERS FOR GENERATING DATA BUFFER
MOV #0,RMOFO :18 BIT FORMAT
1\$:


```

37 010322 012737 000000 001446      MOV      #0.,RMDCO      ;CYLINDER = 0
38 010330 012737 000000 001420      MOV      #0.,RMDAO      ;TRACK = 0, SECTOR = 0
39 010336 012737 177376 001414      MOV      #-258.,RMWCO    ;2 + 256 WORDS (2'S COMP)
40 010344 012737 101360 001416      MOV      #BUFONE,RMBAO   ;DATA BUFFER ADDRESS
41 010352 012737 000062 001412      MOV      #WH,RMCS10     ;WRITE HEADER AND DATA
42
43                                     ;VERIFY THAT SECTOR IS NOT BAD
    010360 004737 033152      JSR      PC,BADSCT      ;CALL BAD SECTOR MODULE
    010364 000405              BR       2$             ;GO TO 2$ IF NO ERROR
    010366 104401 063346      TYPE     ,SCTMSG        ;TYPE BAD SECTOR MESSAGE
    010372 104000              EMT      ;ERROR # DEFINED BY BADSCT SUBROUTINE
    010374 000137 011130      JMP      20$           ;GO TO 20$ IF ERROR
44 010400                                     2$:
45 010400 012737 065000 001174      MOV      #ZEROS,$TMP0   ;USE ALL ZEROS DATA PATTERN
46 010406 012737 000001 001176      MOV      #1,$TMP1
47 010414 004737 035104      JSR      PC,GENBUF      ;GO GENERATE DATA BUFFER
48 010420                                     3$:
49
50                                     ;PREPARE DEVICE FOR DATA TRANSFER
51 010420 004737 032176      JSR      PC,TSTPRP      ;PREPARE DEVICE FOR TEST
    010424 154130      .WORD   154130         ;TASK DESCRIPTOR AS FOLLOWS:
                                                                ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
                                                                ;CLEAR CONTROLLER & SELECT DEVICE
                                                                ;VERIFY CONTROLLER CLEAR OPERATION
                                                                ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
                                                                ;VERIFY PACK ACKNOWLEDGE
                                                                ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
                                                                ;VERIFY RECALIBRATION
    010426 000404              BR       4$             ;GO TO 4$ IF NO ERROR
    010430 000240              NOP      ;RETURN HERE IF ERROR
    010432 104000              EMT      ;ERROR # DEFINED BY TSTPRP SUBROUTINE
    010434 000137 011130      JMP      20$           ;GO TO 20$ IF ERROR
52 010440                                     4$:
53
54                                     ;SETUP PARAMETERS AND EXECUTE SEEK TO GET DRIVE ON CYLINDER
55 010440 012737 000005 001412      MOV      #SEEK!GO,RMCS10 ;CHANGE COMMAND TO SEEK
56 010446 012702 001553      MOV      #PUTINX,R2     ;WRITE REGISTER INDEX TABLE
57 010452 112722 000006      MOVVB   #RMDA,(R2)+
58 010456 112722 000034      MOVVB   #RMDC,(R2)+
59 010462 112722 000032      MOVVB   #RMOF,(R2)+
60 010466 112722 000000      MOVVB   #RMCS1,(R2)+
61 010472 112722 000200      MOVVB   #200,(R2)+
62
63 010476 004737 036240      JSR      PC,PUT         ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
    010502 000404              BR       5$             ;GO TO 5$ IF NO ERROR
    010504 000240              NOP      ;RETURN HERE IF ERROR
    010506 104000              EMT      ;ERROR # DEFINED BY PUT SUBROUTINE
    010510 000137 011130      JMP      20$           ;GO TO 20$ IF ERROR
64 010514                                     5$:
65
66                                     ;SETUP FOR READING STATUS AND THEN WAIT FOR SEEK TO COMPLETE
67 010514 004737 035704      JSR      PC,GETSTS      ;SETUP FOR STATUS
68 010520 004737 036602      JSR      PC,TIMOUT     ;WAIT FOR SEEK TO COMPLETE
69 010524                                     6$:
70
71                                     ;GO READ SEEK STATUS
72 010524 004737 035770      JSR      PC,GET         ;GO READ REGISTER(S) WITH GET SUBROUTINE

```

```

010530 000404          BR      7$          :GO TO 7$ IF NO ERROR
010532 000240          NOP                    :RETURN HERE IF ERROR
010534 104000          EMT                    :ERROR # DEFINED BY GET SUBROUTINE
010536 000137 011130  JMP      20$          :GO TO 20$ IF ERROR
73 010542          7$:
74
75          :VERIFY THE RESULTS OF THE SEEK COMMAND
76 010542 004737 044104 JSR      PC,SEKSTS      :GO VERIFY RESULTS OF SEEK OPERATION
010546 000405          BR      8$          :GO TO 8$ IF NO ERROR
010550 000240          NOP                    :RETURN HERE IF ERROR
010552 104000          EMT                    :ERROR # DEFINED BY SEKSTS SUBROUTINE
010554 004736          JSR      PC,@(SP)+      :GO BACK FOR MORE ERROR CHECKS
010556 000137 011130  JMP      20$          :GO TO 20$ IF ERROR
77 010562          8$:
78
79          :SETUP AND EXECUTE WRITE HEADER AND DATA COMMAND
80 010562 012737 000063 001412 MOV      #WH!GO,RMCS10 :WRITE HEADER AND DATA
81 010570 012702 001556 MOV      #PUTINX+3,R2  :EXTEND REGISTER INDEX TABLE
82 010574 112722 000002 MOVVB   #RMWC,(R2)+
83 010600 112722 000004 MOVVB   #RMBA,(R2)+
84 010604 112722 000000 MOVVB   #RMCS1,(R2)+
85 010610 112722 000200 MOVVB   #200,(R2)+
86
87 010614 004737 036240 JSR      PC,PUT          :GO WRITE REGISTER(S) WITH PUT SUBROUTINE
010620 000404          BR      9$          :GO TO 9$ IF NO ERROR
010622 000240          NOP                    :RETURN HERE IF ERROR
010624 104000          EMT                    :ERROR # DEFINED BY PUT SUBROUTINE
010626 000137 011130  JMP      20$          :GO TO 20$ IF ERROR
88 010632          9$:
89
90          :WAIT FOR WRITE COMMAND TO COMPLETE AND READ STATUS
91 010632 004737 036602 JSR      PC,TIMOUT      :WAIT FOR COMMAND TO COMPLETE
92
93          :GO READ REGISTER(S) WITH GET SUBROUTINE
010636 004737 035770 JSR      PC,GET          :GO READ REGISTER(S) WITH GET SUBROUTINE
010642 000404          BR      10$         :GO TO 10$ IF NO ERROR
010644 000240          NOP                    :RETURN HERE IF ERROR
010646 104000          EMT                    :ERROR # DEFINED BY GET SUBROUTINE
010650 000137 011130  JMP      20$          :GO TO 20$ IF ERROR
94 010654          10$:
95
96          :VERIFY RESULTS OF WRITE COMMAND
97 010654 004737 036766 JSR      PC,PRIERR      :GO CHECK FOR PRIMARY ERRORS
010660 000405          BR      11$         :GO TO 11$ IF NO ERROR
010662 000240          NOP                    :RETURN HERE IF ERROR
010664 104000          EMT                    :ERROR # DEFINED BY PRIERR SUBROUTINE
010666 004736          JSR      PC,@(SP)+      :GO BACK FOR MORE ERROR CHECKS
010670 000137 011130  JMP      20$          :GO TO 20$ IF ERROR
98 010674          11$:
99 010674 004737 051502 JSR      PC,DTASTS      :GO VERIFY RESULTS OF DATA TRANSFER
010700 000405          BR      12$         :GO TO 12$ IF NO ERROR
010702 000240          NOP                    :RETURN HERE IF ERROR
010704 104000          EMT                    :ERROR # DEFINED BY DTASTS SUBROUTINE
010706 004736          JSR      PC,@(SP)+      :GO BACK FOR MORE ERROR CHECKS
010710 000137 011130  JMP      20$          :GO TO 20$ IF ERROR
100 010714          12$:
101 010714 004737 037620 JSR      PC,SECERR      :GO CHECK FOR SECONDARY ERRORS
010720 000405          BR      13$         :GO TO 13$ IF NO ERROR

```



```

010722 000240      NOP      ;RETURN HERE IF ERROR
010724 104000      EMT      ;ERROR # DEFINED BY SECERR SUBROUTINE
010726 004736      JSR      PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
010730 000137 011130 JMP      20$      ;GO TO 20$ IF ERROR
102 010734      13$:
103
104      ;READ HEADER AND DATA FOR SECTOR JUST WRITTEN
105 010734 012737 000073 001412 MOV      #RH!GO,RMCS10 ;READ HEADER & DATA COMMAND
106 010742 012737 102364 001416 MOV      #BUFTWO,RMBA0 ;CHANGE BUS ADDRESS
107
108 010750 004737 036240 JSR      PC,PUT    ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
010754 000404      BR      14$      ;GO TO 14$ IF NO ERROR
010756 000240      NOP      ;RETURN HERE IF ERROR
010760 104000      EMT      ;ERROR # DEFINED BY PUT SUBROUTINE
010762 000137 011130 JMP      20$      ;GO TO 20$ IF ERROR
109 010766      14$:
110
111      ;WAIT FOR READ TO COMPLETE AND GET STATUS
112 010766 004737 036602 JSR      PC,TIMOUT ;WAIT FOR READ TO COMPLETE
113
114 010772 004737 035770 JSR      PC,GET    ;GO READ REGISTER(S) WITH GET SUBROUTINE
010776 000404      BR      15$      ;GO TO 15$ IF NO ERROR
011000 000240      NOP      ;RETURN HERE IF ERROR
011002 104000      EMT      ;ERROR # DEFINED BY GET SUBROUTINE
011004 000137 011130 JMP      20$      ;GO TO 20$ IF ERROR
115 011010      15$:
116
117      ;VERIFY THE RESULTS OF READ OPERATION
118 011010 004737 036766 JSR      PC,PRIERR ;GO CHECK FOR PRIMARY ERRORS
011014 000405      BR      16$      ;GO TO 16$ IF NO ERROR
011016 000240      NOP      ;RETURN HERE IF ERROR
011020 104000      EMT      ;ERROR # DEFINED BY PRIERR SUBROUTINE
011022 004736      JSR      PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
011024 000137 011130 JMP      20$      ;GO TO 20$ IF ERROR
119 011030      16$:
120 011030 004737 051502 JSR      PC,DTASTS ;GO VERIFY RESULTS OF DATA TRANSFER
011034 000405      BR      17$      ;GO TO 17$ IF NO ERROR
011036 000240      NOP      ;RETURN HERE IF ERROR
011040 104000      EMT      ;ERROR # DEFINED BY DTASTS SUBROUTINE
011042 004736      JSR      PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
011044 000137 011130 JMP      20$      ;GO TO 20$ IF ERROR
121 011050      17$:
122 011050 004737 037620 JSR      PC,SECERR ;GO CHECK FOR SECONDARY ERRORS
011054 000405      BR      18$      ;GO TO 18$ IF NO ERROR
011056 000240      NOP      ;RETURN HERE IF ERROR
011060 104000      EMT      ;ERROR # DEFINED BY SECERR SUBROUTINE
011062 004736      JSR      PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
011064 000137 011130 JMP      20$      ;GO TO 20$ IF ERROR
123 011070      18$:
124
125      ;VERIFY DATA
126 011070 004737 035342 JSR      PC,CMPBUF ;GO COMPARE WRITE, READ DATA BUFFERS
011074 101360      .WORD  BUFO1E ;STARTING ADDRESS OF WRITE BUFFER
011076 102364      .WORD  BUFTWO ;STARTING ADDRESS OF READ BUFFER
011100 000402      BR      19$      ;GO TO 19$ IF NO ERROR
011102 000240      NOP      ;RETURN HERE IF ERROR
011104 104000      EMT      ;ERROR # DEFINED BY CMPBUF SUBROUTINE

```

```

127 011106          19$:
128 011106 032737 010000 001444      BIT      #FMT16,RMOFO      :TEST 16 BIT MODE YET ?
129 011114 001005          BNE      20$           :YES
130 011116 012737 010000 001444      MOV      #FMT16,RMOFO  :SET 16 BIT MODE AND
131 011124 000137 010322          JMP      1$           :TEST AGAIN.
132 011130          20$:
133
134
:*****
:*TEST 3          ZERO FILL TEST
:*****
TST3:
011130          SCOPE          :SCOPE CALL
011130 000004          NOP          :START OF TEST
011132 000240          MOV      #STACK,SP    :INITIALIZE STACK POINTER
011134 012706 001100      MOV      $BASE,R0     :R0 = UNIBUS ADDRESS
011140 013700 001276      MOV      TSTQUE,R1    :(R1) = DEVICE BEING TESTED
011144 013701 001466      MOV      #3,$TESTN   ;;SET TEST NUMBER IN APT MAIL BOX
011150 012737 000003 001226
135
136          ;SETUP PARAMETERS FOR GENERATING DATA BUFFER
137 011156 012737 000000 001446      MOV      #0,RMDCO     :CYLINDER = 0
138 011164 012737 000000 001420      MOV      #0,RMDAO     :TRACK = 0, SECTOR = 0
139 011172 012737 010000 001444      MOV      #FMT16,RMOFO :16 BIT FORMAT
140 011200 012737 177376 001414      MOV      #-258.,RMWCO :2 + 256 WORDS (2'S COMP)
141 011206 012737 101360 001416      MOV      #BUFONE,RMBAO :DATA BUFFER ADDRESS
142 011214 012737 000062 001412      MOV      #WH,RMCS10   :WRITE HEADER AND DATA
143
144          ;VERIFY THAT SECTOR IS NOT BAD
011222 004737 033152      JSR      PC,BADSCT    :CALL BAD SECTOR MODULE
011226 000405          BR       1$           :GO TO 1$ IF NO ERROR
011230 104401 063346      TYPE     ,SCTMSG      :TYPE BAD SECTOR MESSAGE
011234 104000          EMT          :ERROR # DEFINED BY BADSCT SUBROUTINE
011236 000137 011764      JMP      18$         :GO TO 18$ IF ERROR
145 011242          1$:
146 011242 012737 065000 001174      MOV      #ZEROS,$TMP0 :USE ALL ZEROS DATA PATTERN
147 011250 012737 000001 001176      MOV      #1,$TMP1
148 011256 004737 035104      JSR      PC,GENBUF   :GO GENERATE DATA BUFFER
149 011262          2$:
150
151          ;PREPARE DEVICE FOR DATA TRANSFER
152 011262 004737 032176      JSR      PC,TSTPRP   :PREPARE DEVICE FOR TEST
011266 154130      .WORD    154130     :TASK DESCRIPTOR AS FOLLOWS:
:SELECT DEVICE & VERIFY DEVICE AVAILABLE
:CLEAR CONTROLLER & SELECT DEVICE
:VERIFY CONTROLLER CLEAR OPERATION
:PACK ACKNOWLEDGE IF VOLUME NOT VALID
:VERIFY PACK ACKNOWLEDGE
:RECALIBRATE IF 'SKI' OR 'PIP' IS SET
:VERIFY RECALIBRATION
011270 000404          BR       3$           :GO TO 3$ IF NO ERROR
011272 000240          NOP          :RETURN HERE IF ERROR
011274 104000          EMT          :ERROR # DEFINED BY TSTPRP SUBROUTINE
011276 000137 011764      JMP      18$         :GO TO 18$ IF ERROR
153 011302          3$:
154
155          ;SETUP PARAMETERS AND EXECUTE SEEK TO GET DRIVE ON CYLINDER
156 011302 012737 000005 001412      MOV      #SEEK!GO,RMCS10 :CHANGE COMMAND TO SEEK
157 011310 012702 001553      MOV      #PUTINX,R2   :WRITE REGISTER INDEX TABLE
    
```



```

158 011314 112722 000006      MOVB  #RMDA,(R2)+
159 011320 112722 000034      MOVB  #RMDC,(R2)+
160 011324 112722 000032      MOVB  #RMOF,(R2)+
161 011330 112722 000000      MOVB  #RMCS1,(R2)+
162 011334 112722 000200      MOVB  #200,(R2)+
163
164 011340 004737 036240      JSR   PC,PUT          ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      011344 000404          BR    4$             ;GO TO 4$ IF NO ERROR
      011346 000240          NOP                    ;RETURN HERE IF ERROR
      011350 104000          EMT                    ;ERROR # DEFINED BY PUT SUBROUTINE
      011352 000137 011764      JMP   18$           ;GO TO 18$ IF ERROR
165 011356      4$:
166
167      ;SETUP FOR READING STATUS AND THEN WAIT FOR SEEK TO COMPLETE
168 011356 004737 035704      JSR   PC,GETSTS      ;SETUP FOR STATUS
169 011362 004737 036602      JSR   PC,TIMOUT      ;WAIT FOR SEEK TO COMPLETE
170 011366      5$:
171
172      ;GO READ SEEK STATUS
173 011366 004737 035770      JSR   PC,GET          ;GO READ REGISTER(S) WITH GET SUBROUTINE
      011372 000404          BR    6$             ;GO TO 6$ IF NO ERROR
      011374 000240          NOP                    ;RETURN HERE IF ERROR
      011376 104000          EMT                    ;ERROR # DEFINED BY GET SUBROUTINE
      011400 000137 011764      JMP   18$           ;GO TO 18$ IF ERROR
174 011404      6$:
175
176      ;VERIFY THE RESULTS OF THE SEEK COMMAND
177 011404 004737 044104      JSR   PC,SEKSTS      ;GO VERIFY RESULTS OF SEEK OPERATION
      011410 000405          BR    7$             ;GO TO 7$ IF NO ERROR
      011412 000240          NOP                    ;RETURN HERE IF ERROR
      011414 104000          EMT                    ;ERROR # DEFINED BY SEKSTS SUBROUTINE
      011416 004736          JSR   PC,@(SP)+      ;GO BACK FOR MORE ERROR CHECKS
      011420 000137 011764      JMP   18$           ;GO TO 18$ IF ERROR
178 011424      7$:
179
180      ;SETUP AND EXECUTE WRITE HEADER AND DATA COMMAND
181 011424 012737 177776 001414  MOV   #-2,RMWC0      ;FORMAT PARTIAL SECTOR
182 011432 012737 000063 001412  MOV   #WH!GO,RMCS10 ;WRITE HEADER AND DATA
183 011440 012702 001556      MOV   #PUTINX+3,R2  ;EXTEND REGISTER INDEX TABLE
184 011444 112722 000002      MOVB  #RMWC,(R2)+
185 011450 112722 000004      MOVB  #RMBA,(R2)+
186 011454 112722 000000      MOVB  #RMCS1,(R2)+
187 011460 112722 000200      MOVB  #200,(R2)+
188
189 011464 004737 036240      JSR   PC,PUT          ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      011470 000404          BR    8$             ;GO TO 8$ IF NO ERROR
      011472 000240          NOP                    ;RETURN HERE IF ERROR
      011474 104000          EMT                    ;ERROR # DEFINED BY PUT SUBROUTINE
      011476 000137 011764      JMP   18$           ;GO TO 18$ IF ERROR
190 011502      8$:
191
192      ;WAIT FOR WRITE COMMAND TO COMPLETE AND READ STATUS
193 011502 004737 036602      JSR   PC,TIMOUT      ;WAIT FOR COMMAND TO COMPLETE
194
195 011506 004737 035770      JSR   PC,GET          ;GO READ REGISTER(S) WITH GET SUBROUTINE
      011512 000404          BR    9$             ;GO TO 9$ IF NO ERROR
      011514 000240          NOP                    ;RETURN HERE IF ERROR

```

```

011516 104000
011520 000137 011764
196 011524 9$: EMT ;ERROR # DEFINED BY GET SUBROUTINE
JMP 18$ ;GO TO 18$ IF ERROR
197
198 ;VERIFY RESULTS OF WRITE COMMAND
199 011524 004737 036766 JSR PC,PRIERR ;GO CHECK FOR PRIMARY ERRORS
011530 000405 BR 10$ ;GO TO 10$ IF NO ERROR
011532 000240 NOP ;RETURN HERE IF ERROR
011534 104000 EMT ;ERROR # DEFINED BY PRIERR SUBROUTINE
011536 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
011540 000137 011764 JMP 18$ ;GO TO 18$ IF ERROR
200 011544 10$:
201 011544 004737 051502 JSR PC,DTASTS ;GO VERIFY RESULTS OF DATA TRANSFER
011550 000405 BR 11$ ;GO TO 11$ IF NO ERROR
011552 000240 NOP ;RETURN HERE IF ERROR
011554 104000 EMT ;ERROR # DEFINED BY DTASTS SUBROUTINE
011556 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
011560 000137 011764 JMP 18$ ;GO TO 18$ IF ERROR
202 011564 11$:
203 011564 004737 037620 JSR PC,SECERR ;GO CHECK FOR SECONDARY ERRORS
011570 000405 BR 12$ ;GO TO 12$ IF NO ERROR
011572 000240 NOP ;RETURN HERE IF ERROR
011574 104000 EMT ;ERROR # DEFINED BY SECERR SUBROUTINE
011576 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
011600 000137 011764 JMP 18$ ;GO TO 18$ IF ERROR
204 011604 12$:
205
206 ;READ HEADER AND DATA FOR SECTOR JUST WRITTEN
207 011604 012737 177376 001414 MOV #-258.,RMWCO ;2 + 256 WORDS (2'S COMP)
208 011612 012737 000073 001412 MOV #RH!GO,RMCS10 ;READ HEADER & DATA COMMAND
209 011620 012737 102364 001416 MOV #BUFTWO,RMBAO ;CHANGE BUS ADDRESS
210
211 011626 004737 036240 JSR PC,PUT ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
011632 000404 BR 13$ ;GO TO 13$ IF NO ERROR
011634 000240 NOP ;RETURN HERE IF ERROR
011636 104000 EMT ;ERROR # DEFINED BY PUT SUBROUTINE
011640 000137 011764 JMP 18$ ;GO TO 18$ IF ERROR
212 011644 13$:
213
214 ;WAIT FOR READ TO COMPLETE AND GET STATUS
215 011644 004737 036602 JSR PC,TIMOUT ;WAIT FOR READ TO COMPLETE
216
217 011650 004737 035770 JSR PC,GET ;GO READ REGISTER(S) WITH GET SUBROUTINE
011654 000404 BR 14$ ;GO TO 14$ IF NO ERROR
011656 000240 NOP ;RETURN HERE IF ERROR
011660 104000 EMT ;ERROR # DEFINED BY GET SUBROUTINE
011662 000137 011764 JMP 18$ ;GO TO 18$ IF ERROR
218 011666 14$:
219
220 ;VERIFY THE RESULTS OF READ OPERATION
221 011666 004737 036766 JSR PC,PRIERR ;GO CHECK FOR PRIMARY ERRORS
011672 000405 BR 15$ ;GO TO 15$ IF NO ERROR
011674 000240 NOP ;RETURN HERE IF ERROR
011676 104000 EMT ;ERROR # DEFINED BY PRIERR SUBROUTINE
011700 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
011702 000137 011764 JMP 18$ ;GO TO 18$ IF ERROR
222 011706 15$:

```



```

223 011706 004737 051502      JSR    PC,DTASTS      ;GO VERIFY RESULTS OF DATA TRANSFER
      011712 000405      BR     16$           ;GO TO 16$ IF NO ERROR
      011714 000240      NOP                    ;RETURN HERE IF ERROR
      011716 104000      EMT                    ;ERROR # DEFINED BY DTASTS SUBROUTINE
      011720 004736      JSR    PC,@(SP)+     ;GO BACK FOR MORE ERROR CHECKS
      011722 000137 011764      JMP    18$           ;GO TO 18$ IF ERROR
224 011726                      16$:
225 011726 004737 037620      JSR    PC,SECERR     ;GO CHECK FOR SECONDARY ERRORS
      011732 000405      BR     17$           ;GO TO 17$ IF NO ERROR
      011734 000240      NOP                    ;RETURN HERE IF ERROR
      011736 104000      EMT                    ;ERROR # DEFINED BY SECERR SUBROUTINE
      011740 004736      JSR    PC,@(SP)+     ;GO BACK FOR MORE ERROR CHECKS
      011742 000137 011764      JMP    18$           ;GO TO 18$ IF ERROR
226 011746                      17$:
227
228
229 011746 004737 035342      ;VERIFY DATA
      011752 101360      JSR    PC,CMPBUF     ;GO COMPARE WRITE, READ DATA BUFFERS
      011754 102364      .WORD  BUFO1E       ;STARTING ADDRESS OF WRITE BUFFER
      011756 000402      .WORD  BUFTWO      ;STARTING ADDRESS OF READ BUFFER
      011760 000240      BR     18$           ;GO TO 18$ IF NO ERROR
      011762 104000      NOP                    ;RETURN HERE IF ERROR
      011764                      EMT                    ;ERROR # DEFINED BY CMPBUF SUBROUTINE
230
231
232
      ;*****
      ;*TEST 4          FORMAT CHECK ZEROS
      ;*****
TST4:
      011764                      SCOPE                    ;SCOPE CALL
      011766 000004      NOP                    ;START OF TEST
      011770 012706 001100      MOV    #STACK,SP    ;INITIALIZE STACK POINTER
      011774 013700 001276      MOV    $BASE,R0     ;R0 = UNIBUS ADDRESS
      012000 013701 001466      MOV    TSTQUE,R1    ;(R1) = DEVICE BEING TESTED
      012004 012737 000004 001226  MOV    #4,$TESTN   ;SET TEST NUMBER IN APT MAIL BOX
233
234
235 012012 012737 000000 001446 ;SETUP PARAMETERS FOR GENERATING DATA BUFFER
      012020 012737 000000 001420  MOV    #0,RMDCO    ;CYLINDER = 0
      012026 012737 010000 001444  MOV    #0,RMDAO    ;TRACK = 0, SECTOR = 0
      012034 012737 177376 001414  MOV    #FMT16,RMOFO ;16 BIT FORMAT
      012042 012737 101360 001416  MOV    #-258.,RMWCO ;2 + 256 WORDS (2'S COMP)
      012050 012737 000062 001412  MOV    #BUFO1E,RMBAO ;DATA BUFFER ADDRESS
      012056 004737 033152      MOV    #WH,RMCS10  ;WRITE HEADER AND DATA
      012062 000405
      012064 104401 063346      ;VERIFY THAT SECTOR IS NOT BAD
      012070 104000      JSR    PC,BADSCT    ;CALL BAD SECTOR MODULE
      012072 000137 012554      BR     1$           ;GO TO 1$ IF NO ERROR
      012076                      TYPE    ,SCTMSG        ;TYPE BAD SECTOR MESSAGE
      012076 012737 065000 001174  EMT                    ;ERROR # DEFINED BY BADSCT SUBROUTINE
      012104 012737 000001 001176  JMP    18$           ;GO TO 18$ IF ERROR
243 012076                      1$:
244 012076 012737 065000 001174  MOV    #ZEROS,$TMPO ;USE ALL ZEROS DATA PATTERN
245 012104 012737 000001 001176  MOV    #1,$TMP1
246 012112 004737 035104      JSR    PC,GENBUF    ;GO GENERATE DATA BUFFER
247 012116                      2$:
248
249
250 012116 004737 032176      ;PREPARE DEVICE FOR DATA TRANSFER
      JSR    PC,TSTPRP ;PREPARE DEVICE FOR TEST

```

```
012122 154130 .WORD 154130 ;TASK DESCRIPTOR AS FOLLOWS:
;SELECT DEVICE & VERIFY DEVICE AVAILABLE
;CLEAR CONTROLLER & SELECT DEVICE
;VERIFY CONTROLLER CLEAR OPERATION
;PACK ACKNOWLEDGE IF VOLUME NOT VALID
;VERIFY PACK ACKNOWLEDGE
;RECALIBRATE IF "SKI" OR "PIP" IS SET
;VERIFY RECALIBRATION
;GO TO 3$ IF NO ERROR
;RETURN HERE IF ERROR
;ERROR # DEFINED BY TSTPRP SUBROUTINE
;GO TO 18$ IF ERROR

251 012124 000404 BR 3$
252 012126 000240 NOP
253 012130 104000 EMT
254 012132 000137 012554 JMP 18$
255 012136 000137 012554 3$:
;SETUP PARAMETERS AND EXECUTE SEEK TO GET DRIVE ON CYLINDER
254 012136 012737 000005 001412 MOV #SEEK!GO, RMCS10 ;CHANGE COMMAND TO SEEK
255 012144 012702 001553 MOV #PUTINX, R2 ;WRITE REGISTER INDEX TABLE
256 012150 112722 000006 MOVB #RMDA, (R2)+
257 012154 112722 000034 MOVB #RMDC, (R2)+
258 012160 112722 000032 MOVB #RMOF, (R2)+
259 012164 112722 000000 MOVB #RMCS1, (R2)+
260 012170 112722 000200 MOVB #200, (R2)+
261
262 012174 004737 036240 JSR PC, PUT ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
263 012200 000404 BR 4$ ;GO TO 4$ IF NO ERROR
264 012202 000240 NOP ;RETURN HERE IF ERROR
265 012204 104000 EMT ;ERROR # DEFINED BY PUT SUBROUTINE
266 012206 000137 012554 JMP 18$ ;GO TO 18$ IF ERROR
267 012212 000137 012554 4$:
;SETUP FOR READING STATUS AND THEN WAIT FOR SEEK TO COMPLETE
266 012212 004737 035704 JSR PC, GETSTS ;SETUP FOR STATUS
267 012216 004737 036602 JSR PC, TIMEOUT ;WAIT FOR SEEK TO COMPLETE
268 012222
269
270
271 012222 004737 035770 ;GO READ SEEK STATUS
272 012226 000404 JSR PC, GET ;GO READ REGISTER(S) WITH GET SUBROUTINE
273 012230 000240 BR 6$ ;GO TO 6$ IF NO ERROR
274 012232 104000 NOP ;RETURN HERE IF ERROR
275 012234 000137 012554 EMT ;ERROR # DEFINED BY GET SUBROUTINE
276 012240 000137 012554 JMP 18$ ;GO TO 18$ IF ERROR
277
278
279 012240 004737 044104 ;VERIFY THE RESULTS OF THE SEEK COMMAND
280 012244 000405 JSR PC, SEKSTS ;GO VERIFY RESULTS OF SEEK OPERATION
281 012246 000240 BR 7$ ;GO TO 7$ IF NO ERROR
282 012250 104000 NOP ;RETURN HERE IF ERROR
283 012252 004736 EMT ;ERROR # DEFINED BY SEKSTS SUBROUTINE
284 012254 000137 012554 JSR PC, @ (SP)+ ;GO BACK FOR MORE ERROR CHECKS
285 012260 000137 012554 JMP 18$ ;GO TO 18$ IF ERROR
286
287
288
289 012260 012737 000063 001412 ;SETUP AND EXECUTE WRITE HEADER AND DATA COMMAND
290 012266 012702 001556 MOV #JH!GO, RMCS10 ;WRITE HEADER AND DATA
291 012272 112722 000002 MOV #PUTINX+3, R2 ;EXTEND REGISTER INDEX TABLE
292 012276 112722 000004 MOVB #RMWC, (R2)+
293 012276 112722 000004 MOVB #RMBA, (R2)+
```



```

283 012302 112722 000000      MOVB   #RMCS1,(R2)+
284 012306 112722 000200      MOVB   #200,(R2)+
285
286 012312 004737 036240      JSR    PC,PUT                ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      012316 000404                BR     8$                    ;GO TO 8$ IF NO ERROR
      012320 000240                NOP
      012322 104000                EMT
      012324 000137 012554        JMP    18$                   ;ERROR # DEFINED BY PUT SUBROUTINE
      ;GO TO 18$ IF ERROR
287 012330      8$:
288
289      ;WAIT FOR WRITE COMMAND TO COMPLETE AND READ STATUS
290 012330 004737 036602      JSR    PC,TIMOUT            ;WAIT FOR COMMAND TO COMPLETE
291
292 012334 004737 035770      JSR    PC,GET                ;GO READ REGISTER(S) WITH GET SUBROUTINE
      012340 000404                BR     9$                    ;GO TO 9$ IF NO ERROR
      012342 000240                NOP
      012344 104000                EMT
      012346 000137 012554        JMP    18$                   ;ERROR # DEFINED BY GET SUBROUTINE
      ;GO TO 18$ IF ERROR
293 012352      9$:
294
295      ;VERIFY RESULTS OF WRITE COMMAND
296 012352 004737 036766      JSR    PC,PRIERR            ;GO CHECK FOR PRIMARY ERRORS
      012356 000405                BR     10$                   ;GO TO 10$ IF NO ERROR
      012360 000240                NOP
      012362 104000                EMT
      012364 004736                JSR    PC,@(SP)+            ;GO BACK FOR MORE ERROR CHECKS
      012366 000137 012554        JMP    18$                   ;GO TO 18$ IF ERROR
297 012372      10$:
298 012372 004737 051502      JSR    PC,DTASTS            ;GO VERIFY RESULTS OF DATA TRANSFER
      012376 000405                BR     11$                   ;GO TO 11$ IF NO ERROR
      012400 000240                NOP
      012402 104000                EMT
      012404 004736                JSR    PC,@(SP)+            ;GO BACK FOR MORE ERROR CHECKS
      012406 000137 012554        JMP    18$                   ;GO TO 18$ IF ERROR
299 012412      11$:
300 012412 004737 037620      JSR    PC,SECERR            ;GO CHECK FOR SECONDARY ERRORS
      012416 000405                BR     12$                   ;GO TO 12$ IF NO ERROR
      012420 000240                NOP
      012422 104000                EMT
      012424 004736                JSR    PC,@(SP)+            ;GO BACK FOR MORE ERROR CHECKS
      012426 000137 012554        JMP    18$                   ;GO TO 18$ IF ERROR
301 012432      12$:
302
303      ;WRITE CHECK HEADER AND DATA FOR SECTOR JUST WRITTEN
304 012432 012737 000053 001412  MOV    #WCH!GO,RMCS10      ;WRITE CHECK COMMAND
305
306 012440 004737 036240      JSR    PC,PUT                ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      012444 000404                BR     13$                   ;GO TO 13$ IF NO ERROR
      012446 000240                NOP
      012450 104000                EMT
      012452 000137 012554        JMP    18$                   ;ERROR # DEFINED BY PUT SUBROUTINE
      ;GO TO 18$ IF ERROR
307 012456      13$:
308
309      ;WAIT FOR WRITE CHECK TO COMPLETE AND GET STATUS
310 012456 004737 036602      JSR    PC,TIMOUT            ;WAIT FOR READ TO COMPLETE
311
312 012462 004737 035770      JSR    PC,GET                ;GO READ REGISTER(S) WITH GET SUBROUTINE

```

```

012466 000404 BR 14$ :GO TO 14$ IF NO ERROR
012470 000240 NOP :RETURN HERE IF ERROR
012472 104000 EMT :ERROR # DEFINED BY GET SUBROUTINE
012474 000137 012554 JMP 18$ :GO TO 18$ IF ERROR
313 012500 14$:
314
315
316 012500 004737 036766 ;VERIFY THE RESULTS OF WRITE CHECK OPERATION
012504 000405 JSR PC,PRIERR :GO CHECK FOR PRIMARY ERRORS
012506 000240 BR 15$ :GO TO 15$ IF NO ERROR
012510 104000 NOP :RETURN HERE IF ERROR
012512 004736 EMT :ERROR # DEFINED BY PRIERR SUBROUTINE
012514 000137 012554 JSR PC,@(SP)+ :GO BACK FOR MORE ERROR CHECKS
317 012520 15$: JMP 18$ :GO TO 18$ IF ERROR
318 012520 004737 051502 JSR PC,DTASTS :GO VERIFY RESULTS OF DATA TRANSFER
012524 000405 BR 16$ :GO TO 16$ IF NO ERROR
012526 000240 NOP :RETURN HERE IF ERROR
012530 104000 EMT :ERROR # DEFINED BY DTASTS SUBROUTINE
012532 004736 JSR PC,@(SP)+ :GO BACK FOR MORE ERROR CHECKS
319 012534 000137 012554 JMP 18$ :GO TO 18$ IF ERROR
320 012540 004737 037620 JSR PC,SECERR :GO CHECK FOR SECONDARY ERRORS
012544 000403 BR 17$ :GO TO 17$ IF NO ERROR
012546 000240 NOP :RETURN HERE IF ERROR
012550 104000 EMT :ERROR # DEFINED BY SECERR SUBROUTINE
012552 004736 JSR PC,@(SP)+ :GO BACK FOR MORE ERROR CHECKS
321 012554 17$:
322
323 012554 18$:
324
325

```

```

*****
*TEST 5 FORMAT CHECK ZEROS W/ WCE ERROR
*****
TST5:

```

```

012554 000004 SCOPE :SCOPE CALL
012556 000240 NOP :START OF TEST
012560 012706 001100 MOV #STACK,SP :INITIALIZE STACK POINTER
012564 013700 001276 MOV $BASE,R0 :R0 = UNIBUS ADDRESS
012570 013701 001466 MOV TSTQUE,R1 :(R1) = DEVICE BEING TESTED
012574 012737 000005 001226 MOV #5,$TESTN ;;SET TEST NUMBER IN APT MAIL BOX
326
327 ;SETUP PARAMETERS FOR GENERATING DATA BUFFER
328 012602 012737 000000 001446 MOV #0,RMDCO :CYLINDER = 0
329 012610 012737 000000 001420 MOV #0,RMDAO :TRACK = 0, SECTOR = 0
330 012616 012737 010000 001444 MOV #FMT16,RMOFO :16 BIT FORMAT
331 012624 012737 177376 001414 MOV #-258.,RMWCO :2 + 256 WORDS (2'S COMP)
332 012632 012737 101360 001416 MOV #BUFONE,RMBAO :DATA BUFFER ADDRESS
333 012640 012737 000062 001412 MOV #WH,RMCS10 :WRITE HEADER AND DATA
334
335 ;VERIFY THAT SECTOR IS NOT BAD
012646 004737 033152 JSR PC,BADSCT :CALL BAD SECTOR MODULE
012652 000405 BR 1$ :GO TO 1$ IF NO ERROR
012654 104401 063346 TYPE ,SCTMSG :TYPE BAD SECTOR MESSAGE
012660 104000 EMT :ERROR # DEFINED BY BADSCT SUBROUTINE
012662 000137 013514 JMP 20$ :GO TO 20$ IF ERROR
336 012666 1$:
337 012666 012737 065000 001174 MOV #ZEROS,$TMP0 :USE ALL ONES DATA PATTERN

```



```

338 012674 012737 000001 001176      MOV    #1,$TMP1
339 012702 004737 035104              JSR    PC,GENBUF      ;GO GENERATE DATA BUFFER
340 012706                                2$:
341
342                                ;PREPARE DEVICE FOR DATA TRANSFER
343 012706 004737 032176      JSR    PC,TSTPRP     ;PREPARE DEVICE FOR TEST
    012712 154130      .WORD 154130      ;TASK DESCRIPTOR AS FOLLOWS:
    ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
    ;CLEAR CONTROLLER & SELECT DEVICE
    ;VERIFY CONTROLLER CLEAR OPERATION
    ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
    ;VERIFY PACK ACKNOWLEDGE
    ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
    ;VERIFY RECALIBRATION
    ;GO TO 3$ IF NO ERROR
    ;RETURN HERE IF ERROR
    ;ERROR # DEFINED BY TSTPRP SUBROUTINE
    ;GO TO 20$ IF ERROR

    012714 000404      BR     3$
    012716 000240      NOP
    012720 104000      EMT
    012722 000137 013514  JMP    20$
344 012726                                3$:
345
346                                ;SETUP PARAMETERS AND EXECUTE SEEK TO GET DRIVE ON CYLINDER
347 012726 012737 000005 001412      MOV    #SEEK:GO,RMCS10 ;CHANGE COMMAND TO SEEK
348 012734 012702 001553              MOV    #PUTINX,R2     ;WRITE REGISTER INDEX TABLE
349 012740 112722 000006      MOVB  #RMDA,(R2)+
350 012744 112722 000034      MOVB  #RMDC,(R2)+
351 012750 112722 000032      MOVB  #RMOF,(R2)+
352 012754 112722 000000      MOVB  #RMCS1,(R2)+
353 012760 112722 000200      MOVB  #200,(R2)+
354
355 012764 004737 036240      JSR    PC,PUT        ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
    012770 000404      BR     4$
    012772 000240      NOP
    012774 104000      EMT
    012776 000137 013514  JMP    20$
    ;GO TO 4$ IF NO ERROR
    ;RETURN HERE IF ERROR
    ;ERROR # DEFINED BY PUT SUBROUTINE
    ;GO TO 20$ IF ERROR
356 013002                                4$:
357
358                                ;SETUP FOR READING STATUS AND THEN WAIT FOR SEEK TO COMPLETE
359 013002 004737 035704      JSR    PC,GETSTS     ;SETUP FOR STATUS
360 013006 004737 036602      JSR    PC,TIMOUT     ;WAIT FOR SEEK TO COMPLETE
361 013012                                5$:
362
363                                ;GO READ SEEK STATUS
364 013012 004737 035770      JSR    PC,GET        ;GO READ REGISTER(S) WITH GET SUBROUTINE
    013016 000404      BR     6$
    013020 000240      NOP
    013022 104000      EMT
    013024 000137 013514  JMP    20$
    ;GO TO 6$ IF NO ERROR
    ;RETURN HERE IF ERROR
    ;ERROR # DEFINED BY GET SUBROUTINE
    ;GO TO 20$ IF ERROR
365 013030                                6$:
366
367                                ;VERIFY THE RESULTS OF THE SEEK COMMAND
368 013030 004737 044104      JSR    PC,SEKSTS     ;GO VERIFY RESULTS OF SEEK OPERATION
    013034 000405      BR     7$
    013036 000240      NOP
    013040 104000      EMT
    013042 004736      JSR    PC,@(SP)+     ;GO BACK FOR MORE ERROR CHECKS
    013044 000137 013514  JMP    20$
    ;GO TO 7$ IF NO ERROR
    ;RETURN HERE IF ERROR
    ;ERROR # DEFINED BY SEKSTS SUBROUTINE
    ;GO TO 20$ IF ERROR
369 013050                                7$:
  
```

```

370
371
372 013050 012737 000063 001412 ;SETUP AND EXECUTE WRITE HEADER AND DATA COMMAND
373 013056 012702 001556          MOV      #WH!GO,RMCS10 ;WRITE HEADER AND DATA
374 013062 112722 000002          MOV      #PUTINX+3,R2 ;EXTEND REGISTER INDEX TABLE
375 013066 112722 000004          MOVB    #RMWC,(R2)+
376 013072 112722 000000          MOVB    #RMBA,(R2)+
377 013076 112722 000200          MOVB    #RMCS1,(R2)+
378
379 013102 004737 036240          JSR     PC,PUT ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      013106 000404          BR     8$ ;GO TO 8$ IF NO ERROR
      013110 000240          NOP    ;RETURN HERE IF ERROR
      013112 104000          EMT    ;ERROR # DEFINED BY PUT SUBROUTINE
      013114 000137 013514          JMP    20$ ;GO TO 20$ IF ERROR
380 013120          8$:
381
382 ;WAIT FOR WRITE COMMAND TO COMPLETE AND READ STATUS
383 013120 004737 036602          JSR     PC,TIMOUT ;WAIT FOR COMMAND TO COMPLETE
384
385 013124 004737 035770          JSR     PC,GET ;GO READ REGISTER(S) WITH GET SUBROUTINE
      013130 000404          BR     9$ ;GO TO 9$ IF NO ERROR
      013132 000240          NOP    ;RETURN HERE IF ERROR
      013134 104000          EMT    ;ERROR # DEFINED BY GET SUBROUTINE
      013136 000137 013514          JMP    20$ ;GO TO 20$ IF ERROR
386 013142          9$:
387
388 ;VERIFY RESULTS OF WRITE COMMAND
389 013142 004737 036766          JSR     PC,PRIERR ;GO CHECK FOR PRIMARY ERRORS
      013146 000405          BR     10$ ;GO TO 10$ IF NO ERROR
      013150 000240          NOP    ;RETURN HERE IF ERROR
      013152 104000          EMT    ;ERROR # DEFINED BY PRIERR SUBROUTINE
      013154 004736          JSR     PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
      013156 000137 013514          JMP    20$ ;GO TO 20$ IF ERROR
390 013162          10$:
391 013162 004737 051502          JSR     PC,DTASTS ;GO VERIFY RESULTS OF DATA TRANSFER
      013166 000405          BR     11$ ;GO TO 11$ IF NO ERROR
      013170 000240          NOP    ;RETURN HERE IF ERROR
      013172 104000          EMT    ;ERROR # DEFINED BY DTASTS SUBROUTINE
      013174 004736          JSR     PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
      013176 000137 013514          JMP    20$ ;GO TO 20$ IF ERROR
392 013202          11$:
393 013202 004737 037620          JSR     PC,SECERR ;GO CHECK FOR SECONDARY ERRORS
      013206 000405          BR     12$ ;GO TO 12$ IF NO ERROR
      013210 000240          NOP    ;RETURN HERE IF ERROR
      013212 104000          EMT    ;ERROR # DEFINED BY SECERR SUBROUTINE
      013214 004736          JSR     PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
      013216 000137 013514          JMP    20$ ;GO TO 20$ IF ERROR
394 013222          12$:
395
396 ;ALTER DATA BUFFER
397 013222 005137 102362          COM     BUFTWO-2 ;COMPLEMENT LAST DATA WORD
398
399 ;SETUP AND WRITE CHECK HEADER AND DATA COMMAND
400 013226 012737 000053 001412          MOV      #WCH!GO,RMCS10 ;WRITE CHECK COMMAND
401
402 013234 004737 036240          JSR     PC,PUT ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      013240 000404          BR     13$ ;GO TO 13$ IF NO ERROR
  
```



```

013242 000240      NOP      ;RETURN HERE IF ERROR
013244 104000      EMT      ;ERROR # DEFINED BY PUT SUBROUTINE
013246 000137 013514  JMP 20$  ;GO TO 20$ IF ERROR
403 013252      13$:
404
405      ;WAIT FOR WRITE CHECK COMMAND TO COMPLETE AND READ STATUS
406 013252 004737 036602  JSR PC,TIMOUT ;WAIT FOR COMMMAND TO COMPLETE
407
408 013256 004737 035770  JSR PC,GET    ;GO READ REGISTER(S) WITH GET SUBROUTINE
    013262 000404      BR 14$      ;GO TO 14$ IF NO ERROR
    013264 000240      NOP      ;RETURN HERE IF ERROR
    013266 104000      EMT      ;ERROR # DEFINED BY GET SUBROUTINE
    013270 000137 013514  JMP 20$      ;GO TO 20$ IF ERROR
409 013274      14$:
410
411      ;CHECK FOR PRIMARY ERRORS
412 013274 004737 036766  JSR PC,PRIERR ;GO CHECK FOR PRIMARY ERRORS
    013300 000405      BR 15$      ;GO TO 15$ IF NO ERROR
    013302 000240      NOP      ;RETURN HERE IF ERROR
    013304 104000      EMT      ;ERROR # DEFINED BY PRIERR SUBROUTINE
    013306 004736      JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
    013310 000137 013514  JMP 20$      ;GO TO 20$ IF ERROR
413 013314      15$:
414
415      ;MAKE SURE THE WRITE CHECK ERROR WAS DETECTED
416 013314 032737 040000 001346  BIT #WCE,RMCS2I ;IS WRITE CHECK ERROR SET??
417 013322 001023      BNE 17$      ;YES!!
418
419 013324 004737 051502  JSR PC,DTASTS ;GO VERIFY RESULTS OF DATA TRANSFER
    013330 000405      BR 16$      ;GO TO 16$ IF NO ERROR
    013332 000240      NOP      ;RETURN HERE IF ERROR
    013334 104000      EMT      ;ERROR # DEFINED BY DTASTS SUBROUTINE
    013336 004736      JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
    013340 000137 013514  JMP 20$      ;GO TO 20$ IF ERROR
420
421 013344 013737 001346 001140 16$:  MOV RMCS2I,$GDDAT ;LOAD EXPECTED STATUS
422 013352 052737 040000 001140  BIS #WCE,$GDDAT
423 013360 013737 001346 001142  MOV RMCS2I,$BDDAT ;LOAD RECEIVED STATUS
424 013366 104337      EMT 337
425 013370 000451      BR 20$
426 013372      17$:
427
428      ;VERIFY THE ADDRESS OF THE WRITE CHECK ERROR
429 013372 012737 102362 001134  MOV #BUFTWO-2,$GDADR ;LOAD EXPECTED ADDRESS
430 013400 013737 001342 001136  MOV RMBAI,$BDADR   ;LOAD RECEIVED ADDRESS
431 013406 162737 000002 001136  SUB #2,$BDADR      ;DECREMENT RECEIVED ADDRESS
432
433      ;GET WCE DATA AND VERIFY IT IS OK
434 013414 112737 000022 001524  MOVSB #RMDB,GETINX ;SETUP FOR READING RMDB
435 013422 112737 000200 001525  MOVSB #200,GETINX+1
436
437 013430 004737 035770  JSR PC,GET    ;GO READ REGISTER(S) WITH GET SUBROUTINE
    013434 000404      BR 18$      ;GO TO 18$ IF NO ERROR
    013436 000240      NOP      ;RETURN HERE IF ERROR
    013440 104000      EMT      ;ERROR # DEFINED BY GET SUBROUTINE
    013442 000137 013514  JMP 20$      ;GO TO 20$ IF ERROR
438 013446 013737 001360 001142 18$:  MOV RMDBI,$BDDAT ;LOAD RECEIVED DATA WORD
  
```

```

439 013454 013737 102362 001140      MOV      BUF-TWO-2,$GDDAT ;LOAD EXPECTED DATA WORD
440 013462 005137 001140      COM      $GDDAT
441 013466 023737 001134 001136      CMP      $GDADR,$BDADR  ;IS ADDRESS OK??
442 013474 001402      BEQ      19$             ;YES!!
443 013476 104340      EMT      340
444 013500 000405      BR       20$
445 013502 023737 001140 001142 19$:      CMP      $GDDAT,$BDDAT  ;IS DATA WORD OK??
446 013510 001401      BEQ      20$             ;YES!!
447 013512 104341      EMT      341
448 013514      20$:
449
450
;*****
;*TEST 6          FORMAT ONES
;*****
TST6:
013514      SCOPE                ;SCOPE CALL
013514 000004      NOP                  ;START OF TEST
013516 000240      MOV      #STACK,SP   ;INITIALIZE STACK POINTER
013520 012706 001100      MOV      $BASE,R0    ;R0 = UNIBUS ADDRESS
013524 013700 001276      MOV      TSTQUE,R1   ;(R1) = DEVICE BEING TESTED
013530 013701 001466      MOV      #6,$TESTN   ;:SET TEST NUMBER IN APT MAIL BOX
013534 012737 000006 001226
451
452      ;SETUP PARAMETERS FOR GENERATING DATA BUFFER
453 013542 012737 000000 001446      MOV      #0,RMDCO    ;CYLINDER = 0
454 013550 012737 000000 001420      MOV      #0,RMDAO    ;TRACK = 0, SECTOR = 0
455 013556 012737 010000 001444      MOV      #FMT16,RMOFO ;16 BIT FORMAT
456 013564 012737 177376 001414      MOV      #-258.,RMWCO ;2 + 256 WORDS (2'S COMP)
457 013572 012737 101360 001416      MOV      #BUFONE,RMBAO ;DATA BUFFER ADDRESS
458 013600 012737 000062 001412      MOV      #WH,RMC$10  ;WRITE HEADER AND DATA
459
460      ;VERIFY THAT SECTOR IS NOT BAD
013606 004737 033152      JSR      PC,BADSCT   ;CALL BAD SECTOR MODULE
013612 000405      BR       1$          ;GO TO 1$ IF NO ERROR
013614 104401 063346      TYPE     ,SCTMSG     ;TYPE BAD SECTOR MESSAGE
013620 104000      EMT
013622 000137 014334      JMP      18$         ;ERROR # DEFINED BY BADSCT SUBROUTINE
461 013626      1$:
462 013626 012737 064736 001174      MOV      #ONES,$TMPO ;USE ALL ONES DATA PATTERN
463 013634 012737 000001 001176      MOV      #1,$TMP1
464 013642 004737 035104      JSR      PC,GENBUF   ;GO GENERATE DATA BUFFER
465 013646      2$:
466
467      ;PREPARE DEVICE FOR DATA TRANSFER
468 013646 004737 032176      JSR      PC,TSTPRP  ;PREPARE DEVICE FOR TEST
013652 154130      .WORD   154130      ;TASK DESCRIPTOR AS FOLLOWS:
;SELECT DEVICE & VERIFY DEVICE AVAILABLE
;CLEAR CONTROLLER & SELECT DEVICE
;VERIFY CONTROLLER CLEAR OPERATION
;PACK ACKNOWLEDGE IF VOLUME NOT VALID
;VERIFY PACK ACKNOWLEDGE
;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
;VERIFY RECALIBRATION
013654 000404      BR       3$          ;GO TO 3$ IF NO ERROR
013656 000240      NOP
013660 104000      EMT
013662 000137 014334      JMP      18$         ;ERROR # DEFINED BY TSTPRP SUBROUTINE
469 013666      3$:
    
```



```

470
471
472 013666 012737 000005 001412 ;SETUP PARAMETERS AND EXECUTE SEEK TO GET DRIVE ON CYLINDER
473 013674 012702 001553      MOV #SEEK!GO,RMCS10 ;CHANGE COMMAND TO SEEK
474 013700 112722 000006      MOV #PUTINX,R2      ;WRITE REGISTER INDEX TABLE
475 013704 112722 000034      MOVB #RMDA,(R2)+
476 013710 112722 000032      MOVB #RMDC,(R2)+
477 013714 112722 000000      MOVB #RMOF,(R2)+
478 013720 112722 000200      MOVB #RMCS1,(R2)+
479      MOVB #200,(R2)+
480 013724 004737 036240      JSR PC,PUT          ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      013730 000404      BR 4$              ;GO TO 4$ IF NO ERROR
      013732 000240      NOP                ;RETURN HERE IF ERROR
      013734 104000      EMT                ;ERROR # DEFINED BY PUT SUBROUTINE
      013736 000137 014334      JMP 18$            ;GO TO 18$ IF ERROR
481 013742
482
483
484 013742 004737 035704      ;SETUP FOR READING STATUS AND THEN WAIT FOR SEEK TO COMPLETE
      013746 004737 036602      JSR PC,GETSTS      ;SETUP FOR STATUS
485      JSR PC,TIMOUT    ;WAIT FOR SEEK TO COMPLETE
486 013752
487
488
489 013752 004737 035770      ;GO READ SEEK STATUS
      013756 000404      JSR PC,GET         ;GO READ REGISTER(S) WITH GET SUBROUTINE
      013760 000240      BR 6$              ;GO TO 6$ IF NO ERROR
      013762 104000      NOP                ;RETURN HERE IF ERROR
      013764 000137 014334      EMT                ;ERROR # DEFINED BY GET SUBROUTINE
490      JMP 18$            ;GO TO 18$ IF ERROR
491
492
493 013770 004737 044104      ;VERIFY THE RESULTS OF THE SEEK COMMAND
      013774 000405      JSR PC,SEKSTS     ;GO VERIFY RESULTS OF SEEK OPERATION
      013776 000240      BR 7$              ;GO TO 7$ IF NO ERROR
      014000 104000      NOP                ;RETURN HERE IF ERROR
      014002 004736      EMT                ;ERROR # DEFINED BY SEKSTS SUBROUTINE
      014004 000137 014334      JSR PC,@(SP)+     ;GO BACK FOR MORE ERROR CHECKS
494      JMP 18$            ;GO TO 18$ IF ERROR
495
496
497 014010 012737 000063 001412 ;SETUP AND EXECUTE WRITE HEADER AND DATA COMMAND
498 014016 012702 001556      MOV #WH!GO,RMCS10 ;WRITE HEADER AND DATA
499 014022 112722 000002      MOV #PUTINX+3,R2  ;EXTEND REGISTER INDEX TABLE
500 014026 112722 000004      MOVB #RMWC,(R2)+
501 014032 112722 000000      MOVB #RMBA,(R2)+
502 014036 112722 000200      MOVB #RMCS1,(R2)+
503      MOVB #200,(R2)+
504 014042 004737 036240      JSR PC,PUT          ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      014046 000404      BR 8$              ;GO TO 8$ IF NO ERROR
      014050 000240      NOP                ;RETURN HERE IF ERROR
      014052 104000      EMT                ;ERROR # DEFINED BY PUT SUBROUTINE
      014054 000137 014334      JMP 18$            ;GO TO 18$ IF ERROR
505 014060
506
507
508 014060 004737 036602      ;WAIT FOR WRITE COMMAND TO COMPLETE AND READ STATUS
      JSR PC,TIMOUT    ;WAIT FOR COMMAND TO COMPLETE
509
    
```

```

510 014064 004737 035770      JSR    PC,GET      ;GO READ REGISTER(S) WITH GET SUBROUTINE
      014070 000404          BR      9$        ;GO TO 9$ IF NO ERROR
      014072 000240          NOP           ;RETURN HERE IF ERROR
      014074 104000          EMT           ;ERROR # DEFINED BY GET SUBROUTINE
      014076 000137 014334    JMP      18$      ;GO TO 18$ IF ERROR
511 014102          9$:
512
513
514 014102 004737 036766      ;VERIFY RESULTS OF WRITE COMMAND
      014106 000405          JSR    PC,PRIERR  ;GO CHECK FOR PRIMARY ERRORS
      014110 000240          BR      10$      ;GO TO 10$ IF NO ERROR
      014112 104000          NOP           ;RETURN HERE IF ERROR
      014114 004736          EMT           ;ERROR # DEFINED BY PRIERR SUBROUTINE
      014116 000137 014334    JSR    PC,@(SP)+  ;GO BACK FOR MORE ERROR CHECKS
      JMP      18$        ;GO TO 18$ IF ERROR
515 014122          10$:
516 014122 004737 051502      JSR    PC,DTASTS  ;GO VERIFY RESULTS OF DATA TRANSFER
      014126 000405          BR      11$      ;GO TO 11$ IF NO ERROR
      014130 000240          NOP           ;RETURN HERE IF ERROR
      014132 104000          EMT           ;ERROR # DEFINED BY DTASTS SUBROUTINE
      014134 004736          JSR    PC,@(SP)+  ;GO BACK FOR MORE ERROR CHECKS
      014136 000137 014334    JMP      18$        ;GO TO 18$ IF ERROR
517 014142          11$:
518 014142 004737 037620      JSR    PC,SECERR  ;GO CHECK FOR SECONDARY ERRORS
      014146 000405          BR      12$      ;GO TO 12$ IF NO ERROR
      014150 000240          NOP           ;RETURN HERE IF ERROR
      014152 104000          EMT           ;ERROR # DEFINED BY SECERR SUBROUTINE
      014154 004736          JSR    PC,@(SP)+  ;GO BACK FOR MORE ERROR CHECKS
      014156 000137 014334    JMP      18$        ;GO TO 18$ IF ERROR
519 014162          12$:
520
521
522 014162 012737 000073 001412 ;READ HEADER AND DATA FOR SECTOR JUST WRITTEN
523 014170 012737 102364 001416  MOV     #RH!GO,RMCS10 ;READ HEADER & DATA COMMAND
524
525 014176 004737 036240      MOV     #BUFTWO,RMBA0 ;CHANGE BUS ADDRESS
      014202 000404          JSR    PC,PUT     ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      014204 000240          BR      13$      ;GO TO 13$ IF NO ERROR
      014206 104000          NOP           ;RETURN HERE IF ERROR
      014210 000137 014334    EMT           ;ERROR # DEFINED BY PUT SUBROUTINE
      014214          JMP      18$        ;GO TO 18$ IF ERROR
526 014214          13$:
527
528
529 014214 004737 036602      ;WAIT FOR READ TO COMPLETE AND GET STATUS
530
531 014220 004737 035770      JSR    PC,TIMOUT ;WAIT FOR READ TO COMPLETE
      014224 000404          JSR    PC,GET     ;GO READ REGISTER(S) WITH GET SUBROUTINE
      014226 000240          BR      14$      ;GO TO 14$ IF NO ERROR
      014230 104000          NOP           ;RETURN HERE IF ERROR
      014232 000137 014334    EMT           ;ERROR # DEFINED BY GET SUBROUTINE
      014236          JMP      18$        ;GO TO 18$ IF ERROR
532 014236          14$:
533
534
535 014236 004737 036766      ;VERIFY THE RESULTS OF READ OPERATION
      014242 000405          JSR    PC,PRIERR  ;GO CHECK FOR PRIMARY ERRORS
      014244 000240          BR      15$      ;GO TO 15$ IF NO ERROR
      014246 104000          NOP           ;RETURN HERE IF ERROR
      014250 004736          EMT           ;ERROR # DEFINED BY PRIERR SUBROUTINE
      JSR    PC,@(SP)+  ;GO BACK FOR MORE ERROR CHECKS
    
```



```

536 014252 000137 014334          JMP      18$          :GO TO 18$ IF ERROR
537 014256 004737 051502          JSR      PC,DTASTS   :GO VERIFY RESULTS OF DATA TRANSFER
    014262 000405          BR       16$          :GO TO 16$ IF NO ERROR
    014264 000240          NOP                     :RETURN HERE IF ERROR
    014266 104000          EMT                     :ERROR # DEFINED BY DTASTS SUBROUTINE
    014270 004736          JSR      PC,@(SP)+   :GO BACK FOR MORE ERROR CHECKS
    014272 000137 014334          JMP      18$          :GO TO 18$ IF ERROR
538 014276 004737 037620          JSR      PC,SECERR   :GO CHECK FOR SECONDARY ERRORS
539 014302 000405          BR       17$          :GO TO 17$ IF NO ERROR
    014304 000240          NOP                     :RETURN HERE IF ERROR
    014306 104000          EMT                     :ERROR # DEFINED BY SECERR SUBROUTINE
    014310 004736          JSR      PC,@(SP)+   :GO BACK FOR MORE ERROR CHECKS
    014312 000137 014334          JMP      18$          :GO TO 18$ IF ERROR
540 014316 004737 035342          JSR      PC,CMPBUF   :GO COMPARE WRITE, READ DATA BUFFERS
541 014322 101360          .WORD   BUFO1         :STARTING ADDRESS OF WRITE BUFFER
542 014324 102364          .WORD   BUFTWO        :STARTING ADDRESS OF READ BUFFER
543 014326 000402          BR       18$          :GO TO 18$ IF NO ERROR
    014330 000240          NOP                     :RETURN HERE IF ERROR
    014332 104000          EMT                     :ERROR # DEFINED BY CMPBUF SUBROUTINE
544 014334
545
546
    ;*****
    ;*TEST 7          FORMAT CHECK ONES
    ;*****
    TST7:
    014334          SCOPE                   :SCOPE CALL
    014334 000004          NOP                     :START OF TEST
    014336 000240          MOV      #STACK,SP     :INITIALIZE STACK POINTER
    014340 012706 001100          MOV      $BASE,R0       :R0 = UNIBUS ADDRESS
    014344 013700 001276          MOV      TSTQUE,R1      :(R1) = DEVICE BEING TESTED
    014350 013701 001466          MOV      #7,$TESTN      ;;SET TEST NUMBER IN APT MAIL BOX
    014354 012737 000007 001226
547
548          ;SETUP PARAMETERS FOR GENERATING DATA BUFFER
549 014362 012737 000000 001446          MOV      #0,RMDCO       :CYLINDER = 0
550 014370 012737 000000 001420          MOV      #0,RMDAO       :TRACK = 0, SECTOR = 0
551 014376 012737 010000 001444          MOV      #FMT16,RMOFO   :16 BIT FORMAT
552 014404 012737 177376 001414          MOV      #-258,RMWCO    :2 + 256 WORDS (2'S COMP)
553 014412 012737 101360 001416          MOV      #BUFO1,RMBAO   :DATA BUFFER ADDRESS
554 014420 012737 000062 001412          MOV      #WH,RMCS10     :WRITE HEADER AND DATA
555
556          ;VERIFY THAT SECTOR IS NOT BAD
    014426 004737 033152          JSR      PC,BADSCT     :CALL BAD SECTOR MODULE
    014432 000405          BR       1$           :GO TO 1$ IF NO ERROR
    014434 104401 063346          TYPE    ,SCTMSG       :TYPE BAD SECTOR MESSAGE
    014440 104000          EMT                     :ERROR # DEFINED BY BADSCT SUBROUTINE
    014442 000137 015124          JMP      18$          :GO TO 18$ IF ERROR
557 014446 012737 064736 001174          MOV      #ONES,$TMP0    :USE ALL ONES DATA PATTERN
558 014446 012737 000001 001176          MOV      #1,$TMP1
559 014454 012737 000001 001176          JSR      PC,GENBUF     :GO GENERATE DATA BUFFER
560 014462 004737 035104
561 014466
562
    1$:
    2$:
    
```

```

563                                     ;PREPARE DEVICE FOR DATA TRANSFER
564 014466 004737 032176             JSR   PC,TSTPRP           ;PREPARE DEVICE FOR TEST
    014472 154130                     .WORD 154130             ;TASK DESCRIPTOR AS FOLLOWS:
                                     ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
                                     ;CLEAR CONTROLLER & SELECT DEVICE
                                     ;VERIFY CONTROLLER CLEAR OPERATION
                                     ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
                                     ;VERIFY PACK ACKNOWLEDGE
                                     ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
                                     ;VERIFY RECALIBRATION
                                     ;GO TO 3$ IF NO ERROR
                                     ;RETURN HERE IF ERROR
                                     ;ERROR # DEFINED BY TSTPRP SUBROUTINE
                                     ;GO TO 18$ IF ERROR

    014474 000404                     BR    3$
    014476 000240                     NOP
    014500 104000                     EMT
    014502 000137 015124             JMP   18$
565 014506
566
567                                     ;SETUP PARAMETERS AND EXECUTE SEEK TO GET DRIVE ON CYLINDER
568 014506 012737 000005 001412     MOV   #SEEK!GO,RMCS10 ;CHANGE COMMAND TO SEEK
569 014514 012702 001553             MOV   #PUTINX,R2      ;WRITE REGISTER INDEX TABLE
570 014520 112722 000006             MOVB  #RMDA,(R2)+
571 014524 112722 000034             MOVB  #RMDC,(R2)+
572 014530 112722 000032             MOVB  #RMOF,(R2)+
573 014534 112722 000000             MOVB  #RMCS1,(R2)+
574 014540 112722 000200             MOVB  #200,(R2)+
575
576 014544 004737 036240             JSR   PC,PUT          ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
    014550 000404                     BR    4$
    014552 000240                     NOP
    014554 104000                     EMT
    014556 000137 015124             JMP   18$
577 014562
578
579                                     ;SETUP FOR READING STATUS AND THEN WAIT FOR SEEK TO COMPLETE
580 014562 004737 035704             JSR   PC,GETSTS      ;SETUP FOR STATUS
581 014566 004737 036602             JSR   PC,TIMOUT     ;WAIT FOR SEEK TO COMPLETE
582 014572
583
584                                     ;GO READ SEEK STATUS
585 014572 004737 035770             JSR   PC,GET         ;GO READ REGISTER(S) WITH GET SUBROUTINE
    014576 000404                     BR    6$
    014600 000240                     NOP
    014602 104000                     EMT
    014604 000137 015124             JMP   18$
586 014610
587
588                                     ;VERIFY THE RESULTS OF THE SEEK COMMAND
589 014610 004737 044104             JSR   PC,SEKSTS     ;GO VERIFY RESULTS OF SEEK OPERATION
    014614 000405                     BR    7$
    014616 000240                     NOP
    014620 104000                     EMT
    014622 004736                     JSR   PC,@(SP)+     ;GO BACK FOR MORE ERROR CHECKS
    014624 000137 015124             JMP   18$
590 014630
591
592                                     ;SETUP AND EXECUTE WRITE HEADER AND DATA COMMAND
593 014630 012737 000063 001412     MOV   #WH!GO,RMCS10 ;WRITE HEADER AND DATA
594 014636 012702 001556             MOV   #PUTINX+3,R2  ;EXTEND REGISTER INDEX TABLE
    
```



```

595 014642 112722 000002      MOVB  #RMWC,(R2)+
596 014646 112722 000004      MOVB  #RMBA,(R2)+
597 014652 112722 000000      MOVB  #RMCS1,(R2)+
598 014656 112722 000200      MOVB  #200,(R2)+
599
600 014662 004737 036240      JSR   PC,PUT          ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      014666 000404          BR    8$             ;GO TO 8$ IF NO ERROR
      014670 000240          NOP                    ;RETURN HERE IF ERROR
      014672 104000          EMT                    ;ERROR # DEFINED BY PUT SUBROUTINE
      014674 000137 015124      JMP   18$           ;GO TO 18$ IF ERROR
601 014700      8$:
602
603      ;WAIT FOR WRITE COMMAND TO COMPLETE AND READ STATUS
604 014700 004737 036602      JSR   PC,TIMOUT      ;WAIT FOR COMMAND TO COMPLETE
605
606 014704 004737 035770      JSR   PC,GET         ;GO READ REGISTER(S) WITH GET SUBROUTINE
      014710 000404          BR    9$             ;GO TO 9$ IF NO ERROR
      014712 000240          NOP                    ;RETURN HERE IF ERROR
      014714 104000          EMT                    ;ERROR # DEFINED BY GET SUBROUTINE
      014716 000137 015124      JMP   18$           ;GO TO 18$ IF ERROR
607 014722      9$:
608
609      ;VERIFY RESULTS OF WRITE COMMAND
610 014722 004737 036766      JSR   PC,PRIERR     ;GO CHECK FOR PRIMARY ERRORS
      014726 000405          BR    10$            ;GO TO 10$ IF NO ERROR
      014730 000240          NOP                    ;RETURN HERE IF ERROR
      014732 104000          EMT                    ;ERROR # DEFINED BY PRIERR SUBROUTINE
      014734 004736          JSR   PC,@(SP)+     ;GO BACK FOR MORE ERROR CHECKS
      014736 000137 015124      JMP   18$           ;GO TO 18$ IF ERROR
611 014742      10$:
612 014742 004737 051502      JSR   PC,DTASTS     ;GO VERIFY RESULTS OF DATA TRANSFER
      014746 000405          BR    11$            ;GO TO 11$ IF NO ERROR
      014750 000240          NOP                    ;RETURN HERE IF ERROR
      014752 104000          EMT                    ;ERROR # DEFINED BY DTASTS SUBROUTINE
      014754 004736          JSR   PC,@(SP)+     ;GO BACK FOR MORE ERROR CHECKS
      014756 000137 015124      JMP   18$           ;GO TO 18$ IF ERROR
613 014762      11$:
614 014762 004737 037620      JSR   PC,SECERR     ;GO CHECK FOR SECONDARY ERRORS
      014766 000405          BR    12$            ;GO TO 12$ IF NO ERROR
      014770 000240          NOP                    ;RETURN HERE IF ERROR
      014772 104000          EMT                    ;ERROR # DEFINED BY SECERR SUBROUTINE
      014774 004736          JSR   PC,@(SP)+     ;GO BACK FOR MORE ERROR CHECKS
      014776 000137 015124      JMP   18$           ;GO TO 18$ IF ERROR
615 015002      12$:
616
617      ;WRITE CHECK HEADER AND DATA FOR SECTOR JUST WRITTEN
618 015002 012737 000053 001412  MOV   #WCH!GO,RMCS10 ;WRITE CHECK COMMAND
619
620 015010 004737 036240      JSR   PC,PUT         ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      015014 000404          BR    13$            ;GO TO 13$ IF NO ERROR
      015016 000240          NOP                    ;RETURN HERE IF ERROR
      015020 104000          EMT                    ;ERROR # DEFINED BY PUT SUBROUTINE
      015022 000137 015124      JMP   18$           ;GO TO 18$ IF ERROR
621 015026      13$:
622
623      ;WAIT FOR WRITE CHECK TO COMPLETE AND GET STATUS
624 015026 004737 036602      JSR   PC,TIMOUT      ;WAIT FOR READ TO COMPLETE
  
```

```

625
626 015032 004737 035770      JSR    PC,GET      ;GO READ REGISTER(S) WITH GET SUBROUTINE
      015036 000404      BR     14$        ;GO TO 14$ IF NO ERROR
      015040 000240      NOP                    ;RETURN HERE IF ERROR
      015042 104000      EMT                    ;ERROR # DEFINED BY GET SUBROUTINE
      015044 000137 015124      JMP    18$        ;GO TO 18$ IF ERROR
627 015050      14$:
628
629      ;VERIFY THE RESULTS OF WRITE CHECK OPERATION
630 015050 004737 036766      JSR    PC,PRIERR   ;GO CHECK FOR PRIMARY ERRORS
      015054 000405      BR     15$        ;GO TO 15$ IF NO ERROR
      015056 000240      NOP                    ;RETURN HERE IF ERROR
      015060 104000      EMT                    ;ERROR # DEFINED BY PRIERR SUBROUTINE
      015062 004736      JSR    PC,@(SP)+   ;GO BACK FOR MORE ERROR CHECKS
      015064 000137 015124      JMP    18$        ;GO TO 18$ IF ERROR
631 015070      15$:
632 015070 004737 051502      JSR    PC,DTASTS   ;GO VERIFY RESULTS OF DATA TRANSFER
      015074 000405      BR     16$        ;GO TO 16$ IF NO ERROR
      015076 000240      NOP                    ;RETURN HERE IF ERROR
      015100 104000      EMT                    ;ERROR # DEFINED BY DTASTS SUBROUTINE
      015102 004736      JSR    PC,@(SP)+   ;GO BACK FOR MORE ERROR CHECKS
      015104 000137 015124      JMP    18$        ;GO TO 18$ IF ERROR
633 015110      16$:
634 015110 004737 037620      JSR    PC,SECERR   ;GO CHECK FOR SECONDARY ERRORS
      015114 000403      BR     17$        ;GO TO 17$ IF NO ERROR
      015116 000240      NOP                    ;RETURN HERE IF ERROR
      015120 104000      EMT                    ;ERROR # DEFINED BY SECERR SUBROUTINE
      015122 004736      JSR    PC,@(SP)+   ;GO BACK FOR MORE ERROR CHECKS
635 015124      17$:
636
637 015124      18$:
638
639
      ;*****
      ;*TEST 10      FORMAT CHECK ONES W/ WCE ERRORS
      ;*****
      TST10:
      015124      SCOPE      ;SCOPE CALL
      015124 000004      NOP                    ;START OF TEST
      015126 000240      MOV     #STACK,SP    ;INITIALIZE STACK POINTER
      015130 012706 001100      MOV     $BASE,R0     ;R0 = UNIBUS ADDRESS
      015134 013700 001276      MOV     TSTQUE,R1    ;(R1) = DEVICE BEING TESTED
      015140 013701 001466      MOV     #10,$TESTN   ;:SET TEST NUMBER IN APT MAIL BOX
      015144 012737 000010 001226
640
641      ;SETUP PARAMETERS FOR GENERATING DATA BUFFER
642 015152 012737 000000 001446      MOV     #0,RMDCO     ;CYLINDER = 0
643 015160 012737 000000 001420      MOV     #0,RMDAO     ;TRACK = 0, SECTOR = 0
644 015166 012737 010000 001444      MOV     #FMT16,RMOFO ;16 BIT FORMAT
645 015174 012737 177376 001414      MOV     #-258.,RMWCO ;2 + 256 WORDS (2'S COMP)
646 015202 012737 101360 001416      MOV     #BUFONE,RMBAO ;DATA BUFFER ADDRESS
647 015210 012737 000062 001412      MOV     #WH,RMCS10   ;WRITE HEADER AND DATA
648
649      ;VERIFY THAT SECTOR IS NOT BAD
      015216 004737 033152      JSR    PC,BADSCT   ;CALL BAD SECTOR MODULE
      015222 000405      BR     1$          ;GO TO 1$ IF NO ERROR
      015224 104401 063346      TYPE   ,SCTMSG     ;TYPE BAD SECTOR MESSAGE
      015230 104000      EMT                    ;ERROR # DEFINED BY BADSCT SUBROUTINE
      015232 000137 016062      JMP    20$        ;GO TO 20$ IF ERROR
  
```



```

650 015236 1$:
651 015236 012737 064736 001174 MOV #ONES,$TMP0 ;USE ALL ONES DATA PATTERN
652 015244 012737 000001 001176 MOV #1,$TMP1
653 015252 004737 035104 JSR PC,GENBUF ;GO GENERATE DATA BUFFER
654 015256
655
656
657 015256 004737 032176 ;PREPARE DEVICE FOR DATA TRANSFER
    015262 154130 JSR PC,TSTPRP ;PREPARE DEVICE FOR TEST
    .WORD 154130 .WORD ;TASK DESCRIPTOR AS FOLLOWS:
    ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
    ;CLEAR CONTROLLER & SELECT DEVICE
    ;VERIFY CONTROLLER CLEAR OPERATION
    ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
    ;VERIFY PACK ACKNOWLEDGE
    ;RECALIBRATE IF "SKI" OR "PIP" IS SET
    ;VERIFY RECALIBRATION
    ;GO TO 3$ IF NO ERROR
    ;RETURN HERE IF ERROR
    ;ERROR # DEFINED BY TSTPRP SUBROUTINE
    ;GO TO 20$ IF ERROR
    015264 000404 BR 3$
    015266 000240 NOP
    015270 104000 EMT
    015272 000137 016062 JMP 20$
658 015276 3$:
659
660 ;SETUP PARAMETERS AND EXECUTE SEEK TO GET DRIVE ON CYLINDER
661 015276 012737 000005 001412 MOV #SEEK!GO,RMCS10 ;CHANGE COMMAND TO SEEK
662 015304 012702 001553 MOV #PUTINX,R2 ;WRITE REGISTER INDEX TABLE
663 015310 112722 000006 MOVB #RMDA,(R2)+
664 015314 112722 000034 MOVB #RMDC,(R2)+
665 015320 112722 000032 MOVB #RMOF,(R2)+
666 015324 112722 000000 MOVB #RMCS1,(R2)+
667 015330 112722 000200 MOVB #200,(R2)+
668
669 015334 004737 036240 JSR PC,PUT ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
    015340 000404 BR 4$ ;GO TO 4$ IF NO ERROR
    015342 000240 NOP ;RETURN HERE IF ERROR
    015344 104000 EMT ;ERROR # DEFINED BY PUT SUBROUTINE
    015346 000137 016062 JMP 20$ ;GO TO 20$ IF ERROR
670 015352 4$:
671
672 ;SETUP FOR READING STATUS AND THEN WAIT FOR SEEK TO COMPLETE
673 015352 004737 035704 JSR PC,GETSTS ;SETUP FOR STATUS
674 015356 004737 036602 JSR PC,TIMOUT ;WAIT FOR SEEK TO COMPLETE
675 015362 5$:
676
677 ;GO READ SEEK STATUS
678 015362 004737 035770 JSR PC,GET ;GO READ REGISTER(S) WITH GET SUBROUTINE
    015366 000404 BR 6$ ;GO TO 6$ IF NO ERROR
    015370 000240 NOP ;RETURN HERE IF ERROR
    015372 104000 EMT ;ERROR # DEFINED BY GET SUBROUTINE
    015374 000137 016062 JMP 20$ ;GO TO 20$ IF ERROR
679 015400 6$:
680
681 ;VERIFY THE RESULTS OF THE SEEK COMMAND
682 015400 004737 044104 JSR PC,SEKSTS ;GO VERIFY RESULTS OF SEEK OPERATION
    015404 000405 BR 7$ ;GO TO 7$ IF NO ERROR
    015406 000240 NOP ;RETURN HERE IF ERROR
    015410 104000 EMT ;ERROR # DEFINED BY SEKSTS SUBROUTINE
    015412 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
  
```

```

015414 000137 016062          JMP      20$          ;GO TO 20$ IF ERROR
683 015420          7$:
684
685          ;SETUP AND EXECUTE WRITE HEADER AND DATA COMMAND
686 015420 012737 000063 001412  MOV     #WH!GO, RMCS10 ;WRITE HEADER AND DATA
687 015426 012702 001556          MOV     #PUTINX+3, R2  ;EXTEND REGISTER INDEX TABLE
688 015432 112722 000002          MOV     #RMWC, (R2)+
689 015436 112722 000004          MOV     #RMBA, (R2)+
690 015442 112722 000000          MOV     #RMCS1, (R2)+
691 015446 112722 000200          MOV     #200, (R2)+
692
693 015452 004737 036240          JSR     PC, PUT        ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
        015456 000404          BR      8$            ;GO TO 8$ IF NO ERROR
        015460 000240          NOP
        015462 104000          EMT
        015464 000137 016062          JMP     20$            ;ERROR # DEFINED BY PUT SUBROUTINE
        ;GO TO 20$ IF ERROR
694 015470          8$:
695
696          ;WAIT FOR WRITE COMMAND TO COMPLETE AND READ STATUS
697 015470 004737 036602          JSR     PC, TIMEOUT   ;WAIT FOR COMMAND TO COMPLETE
698
699 015474 004737 035770          JSR     PC, GET        ;GO READ REGISTER(S) WITH GET SUBROUTINE
        015500 000404          BR      9$            ;GO TO 9$ IF NO ERROR
        015502 000240          NOP
        015504 104000          EMT
        015506 000137 016062          JMP     20$            ;ERROR # DEFINED BY GET SUBROUTINE
        ;GO TO 20$ IF ERROR
700 015512          9$:
701
702          ;VERIFY RESULTS OF WRITE COMMAND
703 015512 004737 036766          JSR     PC, PRIERR    ;GO CHECK FOR PRIMARY ERRORS
        015516 000405          BR      10$           ;GO TO 10$ IF NO ERROR
        015520 000240          NOP
        015522 104000          EMT
        015524 004736          JSR     PC, @ (SP)+   ;GO BACK FOR MORE ERROR CHECKS
        015526 000137 016062          JMP     20$            ;GO TO 20$ IF ERROR
704 015532          10$:
705 015532 004737 051502          JSR     PC, DTASTS    ;GO VERIFY RESULTS OF DATA TRANSFER
        015536 000405          BR      11$           ;GO TO 11$ IF NO ERROR
        015540 000240          NOP
        015542 104000          EMT
        015544 004736          JSR     PC, @ (SP)+   ;GO BACK FOR MORE ERROR CHECKS
        015546 000137 016062          JMP     20$            ;GO TO 20$ IF ERROR
706 015552          11$:
707 015552 004737 037620          JSR     PC, SECERR    ;GO CHECK FOR SECONDARY ERRORS
        015556 000405          BR      12$           ;GO TO 12$ IF NO ERROR
        015560 000240          NOP
        015562 104000          EMT
        015564 004736          JSR     PC, @ (SP)+   ;GO BACK FOR MORE ERROR CHECKS
        015566 000137 016062          JMP     20$            ;GO TO 20$ IF ERROR
708 015572          12$:
709
710          ;ALTER DATA BUFFER
711 015572 005137 102362          COM     BUFTWO-2      ;COMPLEMENT DATA WORD
712
713          ;SETUP AND WRITE CHECK HEADER AND DATA COMMAND
714 015576 012737 000053 001412  MOV     #WCH!GO, RMCS10 ;WRITE CHECK COMMAND
715
  
```



```

716 015604 004737 036240      JSR    PC,PUT      ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      015610 000404      BR     13$        ;GO TO 13$ IF NO ERROR
      015612 000240      NOP                    ;RETURN HERE IF ERROR
      015614 104000      EMT                    ;ERROR # DEFINED BY PUT SUBROUTINE
      015616 000137 016062      JMP    20$        ;GO TO 20$ IF ERROR
717 015622      13$:
718
719      ;WAIT FOR WRITE CHECK COMMAND TO COMPLETE AND READ STATUS
720 015622 004737 036602      JSR    PC,TIMOUT  ;WAIT FOR COMMAND TO COMPLETE
721
722 015626 004737 035770      JSR    PC,GET     ;GO READ REGISTER(S) WITH GET SUBROUTINE
      015632 000404      BR     14$        ;GO TO 14$ IF NO ERROR
      015634 000240      NOP                    ;RETURN HERE IF ERROR
      015636 104000      EMT                    ;ERROR # DEFINED BY GET SUBROUTINE
      015640 000137 016062      JMP    20$        ;GO TO 20$ IF ERROR
723 015644      14$:
724
725      ;CHECK FOR PRIMARY ERRORS
726 015644 004737 036766      JSR    PC,PRIERR  ;GO CHECK FOR PRIMARY ERRORS
      015650 000405      BR     15$        ;GO TO 15$ IF NO ERROR
      015652 000240      NOP                    ;RETURN HERE IF ERROR
      015654 104000      EMT                    ;ERROR # DEFINED BY PRIERR SUBROUTINE
      015656 004736      JSR    PC,@(SP)+  ;GO BACK FOR MORE ERROR CHECKS
      015660 000137 016062      JMP    20$        ;GO TO 20$ IF ERROR
727 015664      15$:
728
729      ;MAKE SURE THE WRITE CHECK ERROR WAS DETECTED
730 015664 032737 040000 001346  BIT    #WCE,RMCS2I ;IS WRITE CHECK ERROR SET??
731 015672 001022      BNE    17$        ;YES!!
732
733 015674 004737 051502      JSR    PC,DTASTS  ;GO VERIFY RESULTS OF DATA TRANSFER
      015700 000405      BR     16$        ;GO TO 16$ IF NO ERROR
      015702 000240      NOP                    ;RETURN HERE IF ERROR
      015704 104000      EMT                    ;ERROR # DEFINED BY DTASTS SUBROUTINE
      015706 004736      JSR    PC,@(SP)+  ;GO BACK FOR MORE ERROR CHECKS
      015710 000137 016062      JMP    20$        ;GO TO 20$ IF ERROR
734 015714 013737 001346 001140 16$:  MOV    RMCS2I,$GDDAT ;LOAD EXPECTED STATUS
735 015722 052737 040000 001140      BIS    #WCE,$GDDAT
736 015730 013737 001346 001142      MOV    RMCS2I,$BDDAT ;LOAD RECEIVED STATUS
737 015736 104337      EMT    337
738 015740      17$:
739
740      ;VERIFY THE ADDRESS OF THE WRITE CHECK ERROR
741 015740 012737 102362 001134      MOV    #BUFTWO-2,$GDADR ;LOAD EXPECTED ADDRESS
742 015746 013737 001342 001136      MOV    RMBAI,$BDADR  ;LOAD RECEIVED ADDRESS
743 015754 162737 000002 001136      SUB    #2,$BDADR     ;DECREMENT RECEIVED ADDRESS
744
745      ;GET WCE DATA AND VERIFY IT IS OK
746 015762 112737 000022 001524      MOVB  #PMDB,GETINX  ;SETUP FOR READING RMDB
747 015770 112737 000200 001525      MOVB  #200,GETINX+1
748
749 015776 004737 035770      JSR    PC,GET     ;GO READ REGISTER(S) WITH GET SUBROUTINE
      016002 000404      BR     18$        ;GO TO 18$ IF NO ERROR
      016004 000240      NOP                    ;RETURN HERE IF ERROR
      016006 104000      EMT                    ;ERROR # DEFINED BY GET SUBROUTINE
      016010 000137 016062      JMP    20$        ;GO TO 20$ IF ERROR
750 016014 013737 001360 001142 18$:  MOV    RMDBI,$BDDAT ;LOAD RECEIVED DATA WORD
  
```

```

751 016022 013737 102362 001140      MOV      BUFTWO-2,$GDDAT ;LOAD EXPECTED DATA WORD
752 016030 005137 001140      COM      $GDDAT
753 016034 023737 001134 001136      CMP      $GDADR,$BDADR ;IS ADDRESS OK??
754 016042 001402      BEQ      19$ ;YES!!
755 016044 104340      EMT      340
756 016046 000405      BR       20$
757 016050      19$:
758 016050 023737 001140 001142      CMP      $GDDAT,$BDDAT ;IS DATA WORD OK??
759 016056 001401      BEQ      20$ ;YES!!
760 016060 104341      EMT      341
761 016062      20$:
762
763
:*****
:*TEST 11      FORMAT MULTIPLE SECTORS
:*****
TST11:
016062      SCOPE ;SCOPE CALL
016062 000004      NOP ;START OF TEST
016064 000240      MOV #STACK,SP ;INITIALIZE STACK POINTER
016066 012706 001100      MOV $BASE,R0 ;R0 = UNIBUS ADDRESS
016072 013700 001276      MOV TSTQUE,R1 ;(R1) = DEVICE BEING TESTED
016076 013701 001466      MOV #11,$TESTN ;:SET TEST NUMBER IN APT MAIL BOX
016102 012737 000011 001226
764
765 ;SETUP PARAMETERS FOR GENERATING DATA BUFFER
766 016110 012737 010000 001444      MOV #FMT16,RMOFO ;:16 BIT FORMAT
767 016116 012737 000000 001446      MOV #0,RMDCO ;:CYLINDER = 0
768 016124 012737 000000 001420      MOV #0,RMDAO ;:TRACK = 0, SECTOR = 0
769 016132 012737 176774 001414      MOV #-258.*2,RMWCO ;:WORD COUNT FOR 2 SECTORS (2'S COMP)
770 016140 012737 101360 001416      MOV #BUFONE,RMBAO ;:DATA BUFFER ADDRESS
771 016146 012737 000062 001412      MOV #WH,RMCS10 ;:WRITE HEADER AND DATA
772
773 ;VERIFY THAT SECTOR IS NOT BAD
016154 004737 033152      JSR PC,BADSCT ;:CALL BAD SECTOR MODULE
016160 000405      BR 1$ ;:GO TO 1$ IF NO ERROR
016162 104401 063346      TYPE ,SCTMSG ;:TYPE BAD SECTOR MESSAGE
016166 104000      EMT ;:ERROR # DEFINED BY BADSCT SUBROUTINE
016170 000137 016656      JMP 17$ ;:GO TO 17$ IF ERROR
774 016174      1$:
775 016174 012737 065000 001174      MOV #ZEROS,$TMPO ;:USE ALL ZEROS DATA PATTERN
776 016202 012737 000001 001176      MOV #1,$TMP1
777 016210 004737 035104      JSR PC,GENBUF ;:GO GENERATE DATA BUFFER
778 016214      2$:
779
780 ;PREPARE DEVICE FOR DATA TRANSFER
781 016214 004737 032176      JSR PC,TSTPRP ;:PREPARE DEVICE FOR TEST
016220 154130      .WORD 154130 ;:TASK DESCRIPTOR AS FOLLOWS:
;:SELECT DEVICE & VERIFY DEVICE AVAILABLE
;:CLEAR CONTROLLER & SELECT DEVICE
;:VERIFY CONTROLLER CLEAR OPERATION
;:PACK ACKNOWLEDGE IF VOLUME NOT VALID
;:VERIFY PACK ACKNOWLEDGE
;:RECALIBRATE IF "SKI" OR "PIP" IS SET
;:VERIFY RECALIBRATION
016222 000404      BR 3$ ;:GO TO 3$ IF NO ERROR
016224 000240      NOP ;:RETURN HERE IF ERROR
016226 104000      EMT ;:ERROR # DEFINED BY TSTPRP SUBROUTINE
016230 000137 016656      JMP 18$ ;:GO TO 18$ IF ERROR

```



```

782 016234          3$:
783
784                ;SETUP PARAMETERS AND EXECUTE SEEK TO GET DRIVE ON CYLINDER
785 016234 012737 000005 001412  MOV      #SEEK!GO,RMCS10 ;CHANGE COMMAND TO SEEK
786 016242 012702 001553          MOV      #PUTINX,R2      ;WRITE REGISTER INDEX TABLE
787 016246 112722 000006          MOVVB   #RMDA,(R2)+
788 016252 112722 000034          MOVVB   #RMDC,(R2)+
789 016256 112722 000032          MOVVB   #RMOF,(R2)+
790 016262 112722 000000          MOVVB   #RMCS1,(R2)+
791 016266 112722 000200          MOVVB   #200,(R2)+
792
793 016272 004737 036240          JSR     PC,PUT          ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      016276 000404          BR      4$            ;GO TO 4$ IF NO ERROR
      016300 000240          NOP
      016302 104000          EMT
      016304 000137 016656          JMP     18$          ;ERROR # DEFINED BY PUT SUBROUTINE
      ;GO TO 18$ IF ERROR
794 016310          4$:
795
796                ;SETUP FOR READING STATUS AND THEN WAIT FOR SEEK TO COMPLETE
797 016310 004737 035704          JSR     PC,GETSTS      ;SETUP FOR STATUS
798 016314 004737 036602          JSR     PC,TIMOUT      ;WAIT FOR SEEK TO COMPLETE
799 016320          5$:
800
801                ;GO READ SEEK STATUS
802 016320 004737 035770          JSR     PC,GET          ;GO READ REGISTER(S) WITH GET SUBROUTINE
      016324 000404          BR      6$            ;GO TO 6$ IF NO ERROR
      016326 000240          NOP
      016330 104000          EMT
      016332 000137 016656          JMP     18$          ;ERROR # DEFINED BY GET SUBROUTINE
      ;GO TO 18$ IF ERROR
803 016336          6$:
804
805                ;VERIFY THE RESULTS OF THE SEEK COMMAND
806 016336 004737 044104          JSR     PC,SEKSTS      ;GO VERIFY RESULTS OF SEEK OPERATION
      016342 000405          BR      7$            ;GO TO 7$ IF NO ERROR
      016344 000240          NOP
      016346 104000          EMT
      016350 004736          JSR     PC,@(SP)+      ;GO BACK FOR MORE ERROR CHECKS
      016352 000137 016656          JMP     18$          ;GO TO 18$ IF ERROR
807 016356          7$:
808
809                ;SETUP AND EXECUTE WRITE HEADER AND DATA COMMAND
810 016356 012737 000063 001412  MOV      #WH!GO,RMCS10 ;WRITE HEADER AND DATA
811 016364 012702 001556          MOV      #PUTINX+3,R2 ;EXTEND REGISTER INDEX TABLE
812 016370 112722 000002          MOVVB   #RMWC,(R2)+
813 016374 112722 000004          MOVVB   #RMBA,(R2)+
814 016400 112722 000000          MOVVB   #RMCS1,(R2)+
815 016404 112722 000200          MOVVB   #200,(R2)+
816
817 016410 004737 036240          JSR     PC,PUT          ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      016414 000404          BR      8$            ;GO TO 8$ IF NO ERROR
      016416 000240          NOP
      016420 104000          EMT
      016422 000137 016656          JMP     18$          ;ERROR # DEFINED BY PUT SUBROUTINE
      ;GO TO 18$ IF ERROR
818 016426          8$:
819
820                ;WAIT FOR WRITE COMMAND TO COMPLETE AND READ STATUS
821 016426 004737 036602          JSR     PC,TIMOUT      ;WAIT FOR COMMAND TO COMPLETE
  
```

```

822
823 016432 004737 035770      JSR    PC,GET      ;GO READ REGISTER(S) WITH GET SUBROUTINE
      016436 000404          BR      9$         ;GO TO 9$ IF NO ERROR
      016440 000240          NOP          ;RETURN HERE IF ERROR
      016442 104000          EMT          ;ERROR # DEFINED BY GET SUBROUTINE
      016444 000137 016656    JMP      18$       ;GO TO 18$ IF ERROR
824 016450      9$:
825
826 ;VERIFY RESULTS OF WRITE COMMAND
827 016450 004737 036766      JSR    PC,PRIERR   ;GO CHECK FOR PRIMARY ERRORS
      016454 000405          BR      10$        ;GO TO 10$ IF NO ERROR
      016456 000240          NOP          ;RETURN HERE IF ERROR
      016460 104000          EMT          ;ERROR # DEFINED BY PRIERR SUBROUTINE
      016462 004736          JSR    PC,@(SP)+   ;GO BACK FOR MORE ERROR CHECKS
      016464 000137 016656    JMP      18$       ;GO TO 18$ IF ERROR
828 016470      10$:
829 016470 004737 051502      JSR    PC,DTASTS   ;GO VERIFY RESULTS OF DATA TRANSFER
      016474 000405          BR      11$        ;GO TO 11$ IF NO ERROR
      016476 000240          NOP          ;RETURN HERE IF ERROR
      016500 104000          EMT          ;ERROR # DEFINED BY DTASTS SUBROUTINE
      016502 004736          JSR    PC,@(SP)+   ;GO BACK FOR MORE ERROR CHECKS
      016504 000137 016656    JMP      18$       ;GO TO 18$ IF ERROR
830 016510      11$:
831 016510 004737 037620      JSR    PC,SECERR   ;GO CHECK FOR SECONDARY ERRORS
      016514 000405          BR      12$        ;GO TO 12$ IF NO ERROR
      016516 000240          NOP          ;RETURN HERE IF ERROR
      016520 104000          EMT          ;ERROR # DEFINED BY SECERR SUBROUTINE
      016522 004736          JSR    PC,@(SP)+   ;GO BACK FOR MORE ERROR CHECKS
      016524 000137 016656    JMP      18$       ;GO TO 18$ IF ERROR
832 016530      12$:
833
834 ;WRITE CHECK HEADER AND DATA FOR SECTORS JUST WRITTEN
835 016530 012737 000053 001412 MOV     #WCH!GO,RMCS10 ;WRITE CHECK COMMAND
836
837 016536 004737 036240      JSR    PC,PUT      ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      016542 000404          BR      13$        ;GO TO 13$ IF NO ERROR
      016544 000240          NOP          ;RETURN HERE IF ERROR
      016546 104000          EMT          ;ERROR # DEFINED BY PUT SUBROUTINE
      016550 000137 016656    JMP      18$       ;GO TO 18$ IF ERROR
838 016554      13$:
839
840 ;WAIT FOR WRITE CHECK TO COMPLETE AND GET STATUS
841 016554 004737 036602      JSR    PC,TIMOUT   ;WAIT FOR WRITE CHECK TO FINISH
842
843 016560 004737 035770      JSR    PC,GET      ;GO READ REGISTER(S) WITH GET SUBROUTINE
      016564 000404          BR      14$        ;GO TO 14$ IF NO ERROR
      016566 000240          NOP          ;RETURN HERE IF ERROR
      016570 104000          EMT          ;ERROR # DEFINED BY GET SUBROUTINE
      016572 000137 016656    JMP      18$       ;GO TO 18$ IF ERROR
844 016576      14$:
845
846 ;VERIFY THE RESULTS OF WRITE CHECK OPERATION
847 016576 004737 036766      JSR    PC,PRIERR   ;GO CHECK FOR PRIMARY ERRORS
      016602 000405          BR      15$        ;GO TO 15$ IF NO ERROR
      016604 000240          NOP          ;RETURN HERE IF ERROR
      016606 104000          EMT          ;ERROR # DEFINED BY PRIERR SUBROUTINE
      016610 004736          JSR    PC,@(SP)+   ;GO BACK FOR MORE ERROR CHECKS
  
```



```

T11 FORMAT MULTIPLE SECTORS
      016612 000137 016656
848 016616
849 016616 004737 051502
      016622 000405
      016624 000240
      016626 104000
      016630 004736
      016632 000137 016656
850 016636
851 016636 004737 037620
      016642 000405
      016644 000240
      016646 104000
      016650 004736
      016652 000137 016656
852 016656
853
854 016656
855
856
      *****
      *TEST 12          FORMAT W/ HEAD SWITCHING
      *****
TST12:
      016656
      016656 000004
      016660 000240
      016662 012706 001100
      016666 013700 001276
      016672 013701 001466
      016676 012737 000012 001226
857
858
859 016704 012737 000000 001446
860 016712 112737 000000 001421
861 016720 112737 000037 001420
862 016726 012737 010000 001444
863 016734 012737 176774 001414
864 016742 012737 101360 001416
865 016750 012737 000062 001412
866
867
      016756 004737 033152
      016762 000405
      016764 104401 063346
      016770 104000
      016772 000137 017470
868 016776
869 016776 123727 001420 000037
870 017004 001345
871 017006 012737 065000 001174
872 017014 012737 000001 001176
873 017022 004737 035104
874
875
876 017026 004737 032176
      017032 154130
      JMP      18$          ;GO TO 18$ IF ERROR
15$:
      JSR      PC,DTASTS   ;GO VERIFY RESULTS OF DATA TRANSFER
      BR      16$          ;GO TO 16$ IF NO ERROR
      NOP
      EMT
      JSR      PC,@(SP)+   ;ERROR # DEFINED BY DTASTS SUBROUTINE
      MP      18$          ;GO BACK FOR MORE ERROR CHECKS
      ;GO TO 18$ IF ERROR
16$:
      JSR      PC,SECERR   ;GO CHECK FOR SECONDARY ERRORS
      BR      17$          ;GO TO 17$ IF NO ERROR
      NOP
      EMT
      JSR      PC,@(SP)+   ;ERROR # DEFINED BY SECERR SUBROUTINE
      JMP      18$          ;GO BACK FOR MORE ERROR CHECKS
      ;GO TO 18$ IF ERROR
17$:
18$:
      *****
      *TEST 12          FORMAT W/ HEAD SWITCHING
      *****
TST12:
      SCOPE
      NOP
      MOV      #STACK,SP   ;SCOPE CALL
      MOV      $BASE,R0    ;START OF TEST
      MOV      TSTQUE,R1   ;INITIALIZE STACK POINTER
      MOV      #12,$TESTN  ;R0 = UNIBUS ADDRESS
      ;(R1) = DEVICE BEING TESTED
      ;:SET TEST NUMBER IN APT MAIL BOX
;SETUP PARAMETERS FOR GENERATING DATA BUFFER
      MOV      #0,RMDCO    ;CYLINDER = 0
      MOV      #0,RMDAO+1  ;TRACK = 0
1$:
      MOV      #31,RMDAO   ;SECTOR = 31
      MOV      #FMT16,RMOFO ;16 BIT FORMAT
      MOV      #-258.*2,RMWCO ;WORD COUNT FOR 2 SECTORS (2'S COMP)
      MOV      #BUFONE,RMBAO ;DATA BUFFER ADDRESS
      MOV      #WH,RMCSTO  ;WRITE HEADER AND DATA
;VERIFY THAT SECTOR IS NOT BAD
      JSR      PC,BADSCT   ;CALL BAD SECTOR MODULE
      BR      2$          ;GO TO 2$ IF NO ERROR
      TYPE    ,SCTMSG     ;TYPE BAD SECTOR MESSAGE
      EMT
      JMP      18$        ;ERROR # DEFINED BY BADSCT SUBROUTINE
      ;GO TO 18$ IF ERROR
2$:
      CMPB    RMDAO,#31.   ;IS LAST SECTOR ASSIGNED ?
      BNE     1$          ;BR IF NO
      MOV     #ZEROS,$TMPO ;USE ALL ZEROS DATA PATTERN
      MOV     #1,$TMP1
      JSR     PC,GENBUF    ;GO GENERATE DATA BUFFER
;PREPARE DEVICE FOR DATA TRANSFER
      JSR     PC,TSTPRP    ;PREPARE DEVICE FOR TEST
      .WORD  154130       ;TASK DESCRIPTOR AS FOLLOWS:
      ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
      ;CLEAR CONTROLLER & SELECT DEVICE

```

```

                                ;VERIFY CONTROLLER CLEAR OPERATION
                                ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
                                ;VERIFY PACK ACKNOWLEDGE
                                ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
                                ;VERIFY RECALIBRATION
                                ;GO TO 3$ IF NO ERROR
                                ;RETURN HERE IF ERROR
                                ;ERROR # DEFINED BY TSTPRP SUBROUTINE
                                ;GO TO 18$ IF ERROR
017034 000404 BR 3$
017036 000240 NOP
017040 104000 EMT
017042 000137 017470 JMP 18$
877 017046 3$:
878
879 ;SETUP PARAMETERS AND EXECUTE SEEK TO GET DRIVE ON CYLINDER
880 017046 012737 000005 001412 MOV #SEEK!GO, RMCS10 ;CHANGE COMMAND TO SEEK
881 017054 012702 001553 MOV #PUTINX, R2 ;WRITE REGISTER INDEX TABLE
882 017060 112722 000006 MOVB #RMDA, (R2)+
883 017064 112722 000034 MOVB #RMDC, (R2)+
884 017070 112722 000032 MOVB #RMOF, (R2)+
885 017074 112722 000000 MOVB #RMCS1, (R2)+
886 017100 112722 000200 MOVB #200, (R2)+
887
888 017104 004737 036240 JSR PC, PUT ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
017110 000404 BR 4$ ;GO TO 4$ IF NO ERROR
017112 000240 NOP ;RETURN HERE IF ERROR
017114 104000 EMT ;ERROR # DEFINED BY PUT SUBROUTINE
017116 000137 017470 JMP 18$ ;GO TO 18$ IF ERROR
889 017122 4$:
890
891 ;SETUP FOR READING STATUS AND THEN WAIT FOR SEEK TO COMPLETE
892 017122 004737 035704 JSR PC, GETSTS ;SETUP FOR STATUS
893 017126 004737 036602 JSR PC, TIMEOUT ;WAIT FOR SEEK TO COMPLETE
894 017132
895
896 ;GO READ SEEK STATUS
897 017132 004737 035770 JSR PC, GET ;GO READ REGISTER(S) WITH GET SUBROUTINE
017136 000404 BR 6$ ;GO TO 6$ IF NO ERROR
017140 000240 NOP ;RETURN HERE IF ERROR
017142 104000 EMT ;ERROR # DEFINED BY GET SUBROUTINE
017144 000137 017470 JMP 18$ ;GO TO 18$ IF ERROR
898 017150 6$:
899
900 ;VERIFY THE RESULTS OF THE SEEK COMMAND
901 017150 004737 044104 JSR PC, SEKSTS ;GO VERIFY RESULTS OF SEEK OPERATION
017154 000405 BR 7$ ;GO TO 7$ IF NO ERROR
017156 000240 NOP ;RETURN HERE IF ERROR
017160 104000 EMT ;ERROR # DEFINED BY SEKSTS SUBROUTINE
017162 004736 JSR PC, @(SP)+ ;GO BACK FOR MORE ERROR CHECKS
017164 000137 017470 JMP 18$ ;GO TO 18$ IF ERROR
902 017170 7$:
903
904 ;SETUP AND EXECUTE WRITE HEADER AND DATA COMMAND
905 017170 012737 000063 001412 MOV #WH!GO, RMCS10 ;WRITE HEADER AND DATA
906 017176 012702 001556 MOV #PUTINX+3, R2 ;EXTEND REGISTER INDEX TABLE
907 017202 112722 000002 MOVB #RMWC, (R2)+
908 017206 112722 000004 MOVB #RMBA, (R2)+
909 017212 112722 000000 MOVB #RMCS1, (R2)+
910 017216 112722 000200 MOVB #200, (R2)+
911
  
```



```

939 017404 000137 017470          JMP      18$          ;GO TO 18$ IF ERROR
940 017410          14$:
941          ;VERIFY THE RESULTS OF WRITE CHECK OPERATION
942 017410 004737 036766          JSR      PC,PRIERR    ;GO CHECK FOR PRIMARY ERRORS
          017414 000405          BR       15$          ;GO TO 15$ IF NO ERROR
          017416 000240          NOP                      ;RETURN HERE IF ERROR
          017420 104000          EMT                      ;ERROR # DEFINED BY PRIERR SUBROUTINE
          017422 004736          JSR      PC,@(SP)+    ;GO BACK FOR MORE ERROR CHECKS
          017424 000137 017470          JMP      18$          ;GO TO 18$ IF ERROR
943 017430          15$:
944 017430 004737 051502          JSR      PC,DTASTS    ;GO VERIFY RESULTS OF DATA TRANSFER
          017434 000405          BR       16$          ;GO TO 16$ IF NO ERROR
          017436 000240          NOP                      ;RETURN HERE IF ERROR
          017440 104000          EMT                      ;ERROR # DEFINED BY DTASTS SUBROUTINE
          017442 004736          JSR      PC,@(SP)+    ;GO BACK FOR MORE ERROR CHECKS
          017444 000137 017470          JMP      18$          ;GO TO 18$ IF ERROR
945 017450          16$:
946 017450 004737 037620          JSR      PC,SECERR    ;GO CHECK FOR SECONDARY ERRORS
          017454 000405          BR       17$          ;GO TO 17$ IF NO ERROR
          017456 000240          NOP                      ;RETURN HERE IF ERROR
          017460 104000          EMT                      ;ERROR # DEFINED BY SECERR SUBROUTINE
          017462 004736          JSR      PC,@(SP)+    ;GO BACK FOR MORE ERROR CHECKS
          017464 000137 017470          JMP      18$          ;GO TO 18$ IF ERROR
947 017470          17$:
948          18$:
949 017470
950
951

```

```

*****
;*TEST 13          FORMAT W/ MID TRANSFER SEEK
*****
TST13:

```

```

          017470          000004          ;SCOPE CALL
          017472 000240          NOP          ;START OF TEST
          017474 012706 001100          MOV      #STACK,SP    ;INITIALIZE STACK POINTER
          017500 013700 001276          MOV      $BASE,R0     ;R0 = UNIBUS ADDRESS
          017504 013701 001466          MOV      TSTQUE,R1    ;(R1) = DEVICE BEING TESTED
          017510 012737 000013 001226          MOV      #13,$TESTN   ;:SET TEST NUMBER IN APT MAIL BOX
952
953          ;SETUP PARAMETERS FOR GENERATING DATA BUFFER
954 017516 012737 000000 001446          MOV      #0,RMDCO     ;CYLINDER = 0
955 017524 013737 001334 001420          1$: MOV      LSTRK,RMDAO ;START LAST TRACK AND
956 017532 112737 000037 001420          MOV      #31.,RMDAO  ;LAST SECTOR
957 017540 012737 010000 001444          MOV      #FMT16,RMOFO ;16 BIT FORMAT
958 017546 012737 176774 001414          MOV      #-258.*2,RMWCO ;WORD COUNT FOR 2 SECTORS (2'S COMP)
959 017554 012737 101360 001416          MOV      #BUFONE,RMBAO ;DATA BUFFER ADDRESS
960 017562 012737 000062 001412          MOV      #WH,RMC$10  ;WRITE HEADER AND DATA
961
962          ;VERIFY THAT SECTOR IS NOT BAD
          017570 004737 033152          JSR      PC,BADSCT    ;CALL BAD SECTOR MODULE
          017574 000405          BR       2$          ;GO TO 2$ IF NO ERROR
          017576 104401 063346          TYPE     ,SCTMSG     ;TYPE BAD SECTOR MESSAGE
          017602 104000          EMT                      ;ERROR # DEFINED BY BADSCT SUBROUTINE
          017604 000137 020302          JMP      19$          ;GO TO 19$ IF ERROR
963 017610          2$:
964 017610 123737 001421 001335          CMPB    RMDAO+1,LSTRK+1 ;IS LAST TRACK ASSIGNED ?
965 017616 001342          BNE     1$          ;BR IF NO

```



```

966 017620 012737 065000 001174      MOV    #ZEROS,$TMP0      ;USE ALL ZEROS DATA PATTERN
967 017626 012737 000001 001176      MOV    #1,$TMP1
968 017634 004737 035104              JSR    PC,GENBUF        ;GO GENERATE DATA BUFFER
969 017640
970
971
972 017640 004737 032176              ;PREPARE DEVICE FOR DATA TRANSFER
    017644 154130              JSR    PC,TSTPRP        ;PREPARE DEVICE FOR TEST
    .WORD 154130              .WORD 154130            ;TASK DESCRIPTOR AS FOLLOWS:
    ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
    ;CLEAR CONTROLLER & SELECT DEVICE
    ;VERIFY CONTROLLER CLEAR OPERATION
    ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
    ;VERIFY PACK ACKNOWLEDGE
    ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
    ;VERIFY RECALIBRATION
    ;GO TO 4$ IF NO ERROR
    ;RETURN HERE IF ERROR
    ;ERROR # DEFINED BY TSTPRP SUBROUTINE
    ;GO TO 19$ IF ERROR

    017646 000404              BR     4$
    017650 000240              NOP
    017652 104000              EMT
    017654 000137 020302        JMP    19$
973 017660              4$:
974
975
976 017660 012737 000005 001412        ;SETUP PARAMETERS AND EXECUTE SEEK TO GET DRIVE ON CYLINDER
977 017666 012702 001553              MOV    #SEEK!GO,RMCS10 ;CHANGE COMMAND TO SEEK
978 017672 112722 000006              MOV    #PUTINX,R2      ;WRITE REGISTER INDEX TABLE
979 017676 112722 000034              MOV    #RMDA,(R2)+
980 017702 112722 000032              MOV    #RMDC,(R2)+
981 017706 112722 000000              MOV    #RMOF,(R2)+
982 017712 112722 000200              MOV    #RMCS1,(R2)+
983
984 017716 004737 036240              JSR    PC,PUT          ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
    017722 000404              BR     5$
    017724 000240              NOP
    017726 104000              EMT
    017730 000137 020302        JMP    19$
985 017734              5$:
986
987
988 017734 004737 035704              ;SETUP FOR READING STATUS AND THEN WAIT FOR SEEK TO COMPLETE
989 017740 004737 036602              JSR    PC,GETSTS      ;SETUP FOR STATUS
990 017744              JSR    PC,TIMOUT      ;WAIT FOR SEEK TO COMPLETE
991
992
993 017744 004737 035770              ;GO READ SEEK STATUS
    017750 000404              JSR    PC,GET          ;GO READ REGISTER(S) WITH GET SUBROUTINE
    017752 000240              BR     7$
    017754 104000              NOP
    017756 000137 020302        EMT
994 017762              JMP    19$
995
996
997 017762 004737 044104              ;VERIFY THE RESULTS OF THE SEEK COMMAND
    017766 000405              JSR    PC,SEKSTS      ;GO VERIFY RESULTS OF SEEK OPERATION
    017770 000240              BR     8$
    017772 104000              NOP
    017774 004736              EMT
    017776 000137 020302        JSR    PC,@(SP)+      ;GO BACK FOR MORE ERROR CHECKS
    JMP    19$            ;GO TO 19$ IF ERROR
  
```

```

998 020002      8$:
999
1000           ;SETUP AND EXECUTE WRITE HEADER AND DATA COMMAND
1001 020002 012737 000063 001412  MOV   #WH!GO, RMCS10 ;WRITE HEADER AND DATA
1002 020010 012702 001556      MOV   #PUTINX+3, R2 ;EXTEND REGISTER INDEX TABLE
1003 020014 112722 000002      MOVB  #RMWC, (R2)+
1004 020020 112722 000004      MOVB  #RMBA, (R2)+
1005 020024 112722 000000      MOVB  #RMCS1, (R2)+
1006 020030 112722 000200      MOVB  #200, (R2)+
1007
1008 020034 004737 036240      JSR   PC, PUT ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      020040 000404      BR    9$ ;GO TO 9$ IF NO ERROR
      020042 000240      NOP   ;RETURN HERE IF ERROR
      020044 104000      EMT   ;ERROR # DEFINED BY PUT SUBROUTINE
      020046 000137 020302     JMP   19$ ;GO TO 19$ IF ERROR
1009 020052      9$:
1010
1011           ;WAIT FOR WRITE COMMAND TO COMPLETE AND READ STATUS
1012 020052 004737 036602      JSR   PC, TIMEOUT ;WAIT FOR COMMAND TO COMPLETE
1013
1014 020056 004737 035770      JSR   PC, GET ;GO READ REGISTER(S) WITH GET SUBROUTINE
      020062 000404      BR    10$ ;GO TO 10$ IF NO ERROR
      020064 000240      NOP   ;RETURN HERE IF ERROR
      020066 104000      EMT   ;ERROR # DEFINED BY GET SUBROUTINE
      020070 000137 020302     JMP   19$ ;GO TO 19$ IF ERROR
1015 020074      10$:
1016
1017           ;VERIFY RESULTS OF WRITE COMMAND
1018 020074 004737 036766      JSR   PC, PRIERR ;GO CHECK FOR PRIMARY ERRORS
      020100 000405      BR    11$ ;GO TO 11$ IF NO ERROR
      020102 000240      NOP   ;RETURN HERE IF ERROR
      020104 104000      EMT   ;ERROR # DEFINED BY PRIERR SUBROUTINE
      020106 004736      JSR   PC, @ (SP)+ ;GO BACK FOR MORE ERROR CHECKS
      020110 000137 020302     JMP   19$ ;GO TO 19$ IF ERROR
1019 020114      11$:
1020 020114 004737 051502      JSR   PC, DTASTS ;GO VERIFY RESULTS OF DATA TRANSFER
      020120 000405      BR    12$ ;GO TO 12$ IF NO ERROR
      020122 000240      NOP   ;RETURN HERE IF ERROR
      020124 104000      EMT   ;ERROR # DEFINED BY DTASTS SUBROUTINE
      020126 004736      JSR   PC, @ (SP)+ ;GO BACK FOR MORE ERROR CHECKS
      020130 000137 020302     JMP   19$ ;GO TO 19$ IF ERROR
1021 020134      12$:
1022 020134 004737 037620      JSR   PC, SECERR ;GO CHECK FOR SECONDARY ERRORS
      020140 000405      BR    13$ ;GO TO 13$ IF NO ERROR
      020142 000240      NOP   ;RETURN HERE IF ERROR
      020144 104000      EMT   ;ERROR # DEFINED BY SECERR SUBROUTINE
      020146 004736      JSR   PC, @ (SP)+ ;GO BACK FOR MORE ERROR CHECKS
      020150 000137 020302     JMP   19$ ;GO TO 19$ IF ERROR
1023 020154      13$:
1024
1025           ;WRITE CHECK HEADER AND DATA FOR SECTORS JUST WRITTEN
1026 020154 012737 000053 001412  MOV   #WCH!GO, RMCS10 ;WRITE CHECK COMMAND
1027
1028 020162 004737 036240      JSR   PC, PUT ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      020166 000404      BR    14$ ;GO TO 14$ IF NO ERROR
      020170 000240      NOP   ;RETURN HERE IF ERROR
      020172 104000      EMT   ;ERROR # DEFINED BY PUT SUBROUTINE
  
```



```

1029 020174 000137 020302          JMP      19$          ;GO TO 19$ IF ERROR
1030 020200          14$:
1031          ;WAIT FOR WRITE CHECK TO COMPLETE AND GET STATUS
1032 020200 004737 036602          JSR      PC,TIMOUT   ;WAIT FOR WRITE CHECK TO FINISH
1033
1034 020204 004737 035770          JSR      PC,GET      ;GO READ REGISTER(S) WITH GET SUBROUTINE
      020210 000404          BR       15$         ;GO TO 15$ IF NO ERROR
      020212 000240          NOP
      020214 104000          EMT     ;RETURN HERE IF ERROR
      020216 000137 020302          JMP      19$         ;ERROR # DEFINED BY GET SUBROUTINE
1035 020222          15$:
1036          ;VERIFY THE RESULTS OF WRITE CHECK OPERATION
1037
1038 020222 004737 036766          JSR      PC,PRIERR   ;GO CHECK FOR PRIMARY ERRORS
      020226 000405          BR       16$         ;GO TO 16$ IF NO ERROR
      020230 000240          NOP
      020232 104000          EMT     ;RETURN HERE IF ERROR
      020234 004736          JSR      PC,@(SP)+   ;ERROR # DEFINED BY PRIERR SUBROUTINE
      020236 000137 020302          JMP      19$         ;GO BACK FOR MORE ERROR CHECKS
1039 020242          16$:
1040 020242 004737 051502          JSR      PC,DTASTS   ;GO VERIFY RESULTS OF DATA TRANSFER
      020246 000405          BR       17$         ;GO TO 17$ IF NO ERROR
      020250 000240          NOP
      020252 104000          EMT     ;RETURN HERE IF ERROR
      020254 004736          JSR      PC,@(SP)+   ;ERROR # DEFINED BY DTASTS SUBROUTINE
      020256 000137 020302          JMP      19$         ;GO BACK FOR MORE ERROR CHECKS
1041 020262          17$:
1042 020262 004737 037620          JSR      PC,SECERR   ;GO CHECK FOR SECONDARY ERRORS
      020266 000405          BR       18$         ;GO TO 18$ IF NO ERROR
      020270 000240          NOP
      020272 104000          EMT     ;RETURN HERE IF ERROR
      020274 004736          JSR      PC,@(SP)+   ;ERROR # DEFINED BY SECERR SUBROUTINE
      020276 000137 020302          JMP      19$         ;GO BACK FOR MORE ERROR CHECKS
1043 020302          18$:
1044
1045 020302          19$:
1046
1047

```

```

*****
;*TEST 14      ' FORMAT W/ IMPLIED SEEK
*****

```

```

TST14:
      020302          SCOPE          ;SCOPE CALL
      020302 000004          NOP          ;START OF TEST
      020304 000240          MOV      #STACK,SP ;INITIALIZE STACK POINTER
      020306 012706 001100          MOV      $BASE,R0   ;R0 = UNIBUS ADDRESS
      020312 013700 001276          MOV      TSTQUE,R1  ;(R1) = DEVICE BEING TESTED
      020316 013701 001466          MOV      #14,$TESTN ;SET TEST NUMBER IN APT MAIL BOX
      020322 012737 000014 001226
1048
1049          ;SETUP PARAMETERS FOR GENERATING DATA BUFFER
1050 020330 012737 000000 001446          MOV      #0,RMDCO   ;CYLINDER = 0
1051 020336 012737 000000 001420          MOV      #0,RMDAO   ;TRACK = 0, SECTOR = 0
1052 020344 012737 010000 001444          MOV      #FMT16,RMOFO ;16 BIT FORMAT
1053 020352 012737 176774 001414          MOV      #-258.*2,RMWCO ;WORD COUNT FOR 2 SECTORS (2'S COMP)
1054 020360 012737 101360 001416          MOV      #BUFONE,RMBAO ;DATA BUFFER ADDRESS
1055 020366 012737 000062 001412          MOV      #WH,RMCS10 ;WRITE HEADER AND DATA
1056

```

```

1057      020374 004737 033152      ;VERIFY THAT SECTOR IS NOT BAD
          020400 000405                JSR   PC,BADSCT      ;CALL BAD SECTOR MODULE
          020402 104401 063346        BR    1$              ;GO TO 1$ IF NO ERROR
          020406 104000                TYPE  ,SCTMSG        ;TYPE BAD SECTOR MESSAGE
          020410 000137 021120        EMT                    ;ERROR # DEFINED BY BADSCT SUBROUTINE
          020414 000137 021120        JMP   18$            ;GO TO 18$ IF ERROR
1058 020414 000137 021120
1059 020414 012737 065000 001174    1$:   MOV   #ZEROS,$TMP0  ;USE ALL ZEROS DATA PATTERN
1060 020422 012737 000001 001176    MOV   #1,$TMP1
1061 020430 004737 035104            JSR   PC,GENBUF      ;GO GENERATE DATA BUFFER
1062 020434
1063
1064
1065 020434 004737 032176      ;PREPARE DEVICE FOR DATA TRANSFER
          020440 154130                JSR   PC,TSTPRP     ;PREPARE DEVICE FOR TEST
                                          .WORD 154130        ;TASK DESCRIPTOR AS FOLLOWS:
                                          ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
                                          ;CLEAR CONTROLLER & SELECT DEVICE
                                          ;VERIFY CONTROLLER CLEAR OPERATION
                                          ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
                                          ;VERIFY PACK ACKNOWLEDGE
                                          ;RECALIBRATE IF "SKI" OR "PIP" IS SET
                                          ;VERIFY RECALIBRATION
                                          ;GO TO 3$ IF NO ERROR
                                          ;RETURN HERE IF ERROR
                                          ;ERROR # DEFINED BY TSTPRP SUBROUTINE
                                          ;GO TO 18$ IF ERROR
          020442 000404                BR    3$
          020444 000240                NOP
          020446 104000                EMT
          020450 000137 021120        JMP   18$
1066 020454
1067
1068
1069 020454 013737 001446 021122    ;SETUP PARAMETERS AND EXECUTE SEEK TO GET DRIVE OFF CYLINDER
          020462 012737 001466 001446  MOV   RMDCO,19$     ;SAVE CYLINDER ADDRESS
          020470 012737 000005 001412  MOV   #822.,RMDCO  ;SEEK TO LAST CYLINDER
          020476 012702 001553          MOV   #SEEK!GO,RMCS10 ;CHANGE COMMAND TO SEEK
          020502 112722 000006          MOV   #PUTINX,R2    ;WRITE REGISTER INDEX TABLE
          020506 112722 000034          MOVB  #RMDA,(R2)+
          020512 112722 000032          MOVB  #RMDC,(R2)+
          020516 112722 000000          MOVB  #RMOF,(R2)+
          020522 112722 000200          MOVB  #RMCS1,(R2)+
          020526 004737 036240          MOVB  #200,(R2)+
          020532 000404                JSR   PC,PUT        ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
          020534 000240                BR    4$            ;GO TO 4$ IF NO ERROR
          020536 104000                NOP                ;RETURN HERE IF ERROR
          020540 000137 021120        EMT                    ;ERROR # DEFINED BY PUT SUBROUTINE
          020544 000137 021120        JMP   18$            ;GO TO 18$ IF ERROR
1080 020544
1081
1082
1083 020544 004737 035704      ;SETUP FOR READING STATUS AND THEN WAIT FOR SEEK TO COMPLETE
          020550 004737 036602        JSR   PC,GETSTS     ;SETUP FOR STATUS
          020554 004737 036602        JSR   PC,TIMOUT     ;WAIT FOR SEEK TO COMPLETE
1084 020550 004737 036602
1085 020554
1086
1087
1088 020554 004737 035770      ;GO READ SEEK STATUS
          020560 000404                JSR   PC,GET        ;GO READ REGISTER(S) WITH GET SUBROUTINE
          020562 000240                BR    6$            ;GO TO 6$ IF NO ERROR
          020564 104000                NOP                ;RETURN HERE IF ERROR
          020566 000137 021120        EMT                    ;ERROR # DEFINED BY GET SUBROUTINE
          020566 000137 021120        JMP   18$            ;GO TO 18$ IF ERROR
  
```



```

1089 020572          6$:
1090
1091
1092 020572 004737 044104 ;VERIFY THE RESULTS OF THE SEEK COMMAND
      020576 000405      JSR    PC,SEKSTS ;GO VERIFY RESULTS OF SEEK OPERATION
      020600 000240      BR     7$ ;GO TO 7$ IF NO ERROR
      020602 104000      NOP    ;RETURN HERE IF ERROR
      020604 004736      EMT    ;ERROR # DEFINED BY SEKSTS SUBROUTINE
      020606 000137 021120 JSR    PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
      JMP    18$ ;GO TO 18$ IF ERROR

1093 020612          7$:
1094
1095 ;SETUP AND EXECUTE WRITE HEADER AND DATA COMMAND
1096 020612 013737 021122 001446 MOV    19$,RMDCO ;RESTORE DISK ADDRESS
1097 020620 012737 000063 001412 MOV    #WH!GO,RMCS10 ;WRITE HEADER AND DATA
1098 020626 012702 001556 MOV    #PUTINX+3,R2 ;EXTEND REGISTER INDEX TABLE
1099 020632 112722 000002 MOVB   #RMWC,(R2)+
1100 020636 112722 000004 MOVB   #RMBA,(R2)+
1101 020642 112722 000000 MOVB   #RMCS1,(R2)+
1102 020646 112722 000200 MOVB   #200,(R2)+
1103
1104 020652 004737 036240 JSR    PC,PUT ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      020656 000404      BR     8$ ;GO TO 8$ IF NO ERROR
      020660 000240      NOP    ;RETURN HERE IF ERROR
      020662 104000      EMT    ;ERROR # DEFINED BY PUT SUBROUTINE
      020664 000137 021120 JMP    18$ ;GO TO 18$ IF ERROR

1105 020670          8$:
1106
1107 ;WAIT FOR WRITE COMMAND TO COMPLETE AND READ STATUS
1108 020670 004737 036602 JSR    PC,TIMOUT ;WAIT FOR COMMAND TO COMPLETE
1109
1110 020674 004737 035770 JSR    PC,GET ;GO READ REGISTER(S) WITH GET SUBROUTINE
      020700 000404      BR     9$ ;GO TO 9$ IF NO ERROR
      020702 000240      NOP    ;RETURN HERE IF ERROR
      020704 104000      EMT    ;ERROR # DEFINED BY GET SUBROUTINE
      020706 000137 021120 JMP    18$ ;GO TO 18$ IF ERROR

1111 020712          9$:
1112
1113 ;VERIFY RESULTS OF WRITE COMMAND
1114 020712 004737 036766 JSR    PC,PRIERR ;GO CHECK FOR PRIMARY ERRORS
      020716 000405      BR     10$ ;GO TO 10$ IF NO ERROR
      020720 000240      NOP    ;RETURN HERE IF ERROR
      020722 104000      EMT    ;ERROR # DEFINED BY PRIERR SUBROUTINE
      020724 004736      JSR    PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
      020726 000137 021120 JMP    18$ ;GO TO 18$ IF ERROR

1115 020732          10$:
1116 020732 004737 051502 JSR    PC,DTASTS ;GO VERIFY RESULTS OF DATA TRANSFER
      020736 000405      BR     11$ ;GO TO 11$ IF NO ERROR
      020740 000240      NOP    ;RETURN HERE IF ERROR
      020742 104000      EMT    ;ERROR # DEFINED BY DTASTS SUBROUTINE
      020744 004736      JSR    PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
      020746 000137 021120 JMP    18$ ;GO TO 18$ IF ERROR

1117 020752          11$:
1118 020752 004737 037620 JSR    PC,SECERR ;GO CHECK FOR SECONDARY ERRORS
      020756 000405      BR     12$ ;GO TO 12$ IF NO ERROR
      020760 000240      NOP    ;RETURN HERE IF ERROR
      020762 104000      EMT    ;ERROR # DEFINED BY SECERR SUBROUTINE
      020764 004736      JSR    PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
  
```

```

1119 020766 000137 021120      JMP      18$      ;GO TO 18$ IF ERROR
1120 020772      12$:
1121      ;WRITE CHECK HEADER AND DATA FOR SECTORS JUST WRITTEN
1122 020772 012737 000053 001412  MOV      #WCH!GO, RMCS10 ;WRITE CHECK COMMAND
1123
1124 021000 004737 036240      JSR      PC, PUT      ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      021004 000404      BR      13$      ;GO TO 13$ IF NO ERROR
      021006 000240      NOP
      021010 104000      EMT
      021012 000137 021120      JMP      18$      ;ERROR # DEFINED BY PUT SUBROUTINE
      ;GO TO 18$ IF ERROR
1125 021016      13$:
1126
1127      ;WAIT FOR WRITE CHECK TO COMPLETE AND GET STATUS
1128 021016 004737 036602      JSR      PC, TIMEOUT ;WAIT FOR WRITE CHECK TO FINISH
1129
1130 021022 004737 035770      JSR      PC, GET      ;GO READ REGISTER(S) WITH GET SUBROUTINE
      021026 000404      BR      14$      ;GO TO 14$ IF NO ERROR
      021030 000240      NOP
      021032 104000      EMT
      021034 000137 021120      JMP      18$      ;RETURN HERE IF ERROR
      ;ERROR # DEFINED BY GET SUBROUTINE
      ;GO TO 18$ IF ERROR
1131 021040      14$:
1132
1133      ;VERIFY THE RESULTS OF WRITE CHECK OPERATION
1134 021040 004737 036766      JSR      PC, PRIERR   ;GO CHECK FOR PRIMARY ERRORS
      021044 000405      BR      15$      ;GO TO 15$ IF NO ERROR
      021046 000240      NOP
      021050 104000      EMT
      021052 004736      JSR      PC, @ (SP)+ ;ERROR # DEFINED BY PRIERR SUBROUTINE
      021054 000137 021120      JMP      18$      ;GO BACK FOR MORE ERROR CHECKS
      ;GO TO 18$ IF ERROR
1135 021060      15$:
1136 021060 004737 051502      JSR      PC, DTASTS   ;GO VERIFY RESULTS OF DATA TRANSFER
      021064 000405      BR      16$      ;GO TO 16$ IF NO ERROR
      021066 000240      NOP
      021070 104000      EMT
      021072 004736      JSR      PC, @ (SP)+ ;ERROR # DEFINED BY DTASTS SUBROUTINE
      021074 000137 021120      JMP      18$      ;GO BACK FOR MORE ERROR CHECKS
      ;GO TO 18$ IF ERROR
1137 021100      16$:
1138 021100 004737 037620      JSR      PC, SECERR   ;GO CHECK FOR SECONDARY ERRORS
      021104 000405      BR      17$      ;GO TO 17$ IF NO ERROR
      021106 000240      NOP
      021110 104000      EMT
      021112 004736      JSR      PC, @ (SP)+ ;ERROR # DEFINED BY SECERR SUBROUTINE
      021114 000137 021120      JMP      18$      ;GO BACK FOR MORE ERROR CHECKS
      ;GO TO 18$ IF ERROR
1139 021120      17$:
1140
1141 021120 000401      18$: BR      20$
1142
1143 021122 000000      19$: .WORD 0      ;TEMPORARY STORAGE
1144
1145 021124      20$:
1146
1147
;*****
;*TEST 15      FORMAT EACH SECTOR ADDRESS
;*****
TST15:
SCOPE      ;SCOPE CALL
    
```

021124
021124 000004


```

021126 000240      NOP      :START OF TEST
021130 012706 001100  MOV     #STACK,SP  :INITIALIZE STACK POINTER
021134 013700 001276  MOV     $BASE,R0   :R0 = UNIBUS ADDRESS
021140 013701 001466  MOV     TSTQUE,R1  :(R1) = DEVICE BEING TESTED
021144 012737 000015 001226  MOV     #15,$TESTN :SET TEST NUMBER IN APT MAIL BOX

1148
1149      :SETUP PARAMETERS FOR GENERATING DATA BUFFER
1150 021152 012737 000000 001446  MOV     #0,RMDCO   :CYLINDER = 0
1151 021160 012737 000000 001420  MOV     #0,RMDAO   :TRACK = 0, SECTOR = 0
1152 021166 012737 010000 001444  MOV     #FMT16,RMOFO :16 BIT FORMAT
1153 021174      1$:
1154 021174 012737 177376 001414  MOV     #-258.,RMWCO :2 + 256 WORDS (2'S COMP)
1155 021202 012737 101360 001416  MOV     #BUFONE,RMBAO :DATA BUFFER ADDRESS
1156 021210 012737 000062 001412  MOV     #WH,RMCS10  :WRITE HEADER AND DATA
1157
1158      :VERIFY THAT SECTOR IS NOT BAD
021216 004737 033152  JSR     PC,BADSCT  :CALL BAD SECTOR MODULE
021222 000405      BR      2$        :GO TO 2$ IF NO ERROR
021224 104401 063346  TYPE    ,SCTMSG   :TYPE BAD SECTOR MESSAGE
021230 104000      EMT
021232 000137 021666  JMP     16$       :ERROR # DEFINED BY BADSCT SUBROUTINE
:GO TO 16$ IF ERROR

1159 021236      2$:
1160 021236 012737 001420 001174  MOV     #RMDAO,$TMP0 :USE SECTOR FOR DATA PATTERN
1161 021244 012737 000001 001176  MOV     #1,$TMP1
1162 021252 004737 035104  JSR     PC,GENBUF   :GO GENERATE DATA BUFFER
1163 021256      3$:
1164
1165      :PREPARE DEVICE FOR DATA TRANSFER
1166 021256 004737 032176  JSR     PC,TSTPRP  :PREPARE DEVICE FOR TEST
021262 154130      .WORD 154130 :TASK DESCRIPTOR AS FOLLOWS:
:SELECT DEVICE & VERIFY DEVICE AVAILABLE
:CLEAR CONTROLLER & SELECT DEVICE
:VERIFY CONTROLLER CLEAR OPERATION
:PACK ACKNOWLEDGE IF VOLUME NOT VALID
:VERIFY PACK ACKNOWLEDGE
:RECALIBRATE IF "SKI" OR "PIP" IS SET
:VERIFY RECALIBRATION
021264 000404      BR      4$        :GO TO 4$ IF NO ERROR
021266 000240      NOP      :RETURN HERE IF ERROR
021270 104000      EMT
021272 000137 021666  JMP     16$       :ERROR # DEFINED BY TSTPRP SUBROUTINE
:GO TO 16$ IF ERROR

1167 021276      4$:
1168
1169      :SETUP AND EXECUTE WRITE HEADER AND DATA COMMAND
1170 021276 012737 000063 001412  MOV     #WH!GO,RMCS10 :WRITE HEADER AND DATA
1171 021304 012702 001553  MOV     #PUTINX,R2   :WRITE REGISTER INDEX TABLE
1172 021310 112722 000006  MOVB   #RMDA,(R2)+
1173 021314 112722 000034  MOVB   #RMDC,(R2)+
1174 021320 112722 000032  MOVB   #RMOF,(R2)+
1175 021324 112722 000002  MOVB   #RMWC,(R2)+
1176 021330 112722 000004  MOVB   #RMBA,(R2)+
1177 021334 112722 000000  MOVB   #RMCS1,(R2)+
1178 021340 112722 000200  MOVB   #200,(R2)+
1179
1180 021344 004737 036240  JSR     PC,PUT     :GO WRITE REGISTER(S) WITH PUT SUBROUTINE
021350 000404      BR      5$        :GO TO 5$ IF NO ERROR
021352 000240      NOP      :RETURN HERE IF ERROR
  
```

```

021354 104000          EMT          ;ERROR # DEFINED BY PUT SUBROUTINE
021356 000137 021666   JMP          16$          ;GO TO 16$ IF ERROR
1181 021362          5$:
1182
1183          ;SETUP INPUT REGISTER BUFFER FOR READING STATUS
1184 021362 004737 035704   JSR          PC,GETSTS
1185 021366 004737 036602   JSR          PC,TIMOUT          ;WAIT FOR COMMAND TO COMPLETE
1186
1187 021372 004737 035770   JSR          PC,GET          ;GO READ REGISTER(S) WITH GET SUBROUTINE
      021376 000404   BR          6$          ;GO TO 6$ IF NO ERROR
      021400 000240   NOP          ;RETURN HERE IF ERROR
      021402 104000   EMT          ;ERROR # DEFINED BY GET SUBROUTINE
      021404 000137 021666   JMP          16$          ;GO TO 16$ IF ERROR
1188 021410          6$:
1189
1190          ;VERIFY RESULTS OF WRITE COMMAND
1191 021410 004737 036766   JSR          PC,PRIERR          ;GO CHECK FOR PRIMARY ERRORS
      021414 000405   BR          7$          ;GO TO 7$ IF NO ERROR
      021416 000240   NOP          ;RETURN HERE IF ERROR
      021420 104000   EMT          ;ERROR # DEFINED BY PRIERR SUBROUTINE
      021422 004736   JSR          PC,@(SP)+          ;GO BACK FOR MORE ERROR CHECKS
      021424 000137 021666   JMP          16$          ;GO TO 16$ IF ERROR
1192 021430          7$:
1193 021430 004737 051502   JSR          PC,DTASTS          ;GO VERIFY RESULTS OF DATA TRANSFER
      021434 000405   BR          8$          ;GO TO 8$ IF NO ERROR
      021436 000240   NOP          ;RETURN HERE IF ERROR
      021440 104000   EMT          ;ERROR # DEFINED BY DTASTS SUBROUTINE
      021442 004736   JSR          PC,@(SP)+          ;GO BACK FOR MORE ERROR CHECKS
      021444 000137 021666   JMP          16$          ;GO TO 16$ IF ERROR
1194 021450          8$:
1195 021450 004737 037620   JSR          PC,SECERR          ;GO CHECK FOR SECONDARY ERRORS
      021454 000405   BR          9$          ;GO TO 9$ IF NO ERROR
      021456 000240   NOP          ;RETURN HERE IF ERROR
      021460 104000   EMT          ;ERROR # DEFINED BY SECERR SUBROUTINE
      021462 004736   JSR          PC,@(SP)+          ;GO BACK FOR MORE ERROR CHECKS
      021464 000137 021666   JMP          16$          ;GO TO 16$ IF ERROR
1196 021470          9$:
1197
1198          ;READ HEADER AND DATA FOR SECTOR JUST WRITTEN
1199 021470 012737 000073 001412   MOV          #RH!GO,RMC$10          ;READ HEADER & DATA COMMAND
1200 021476 012737 102364 001416   MOV          #BUFTWO,RMBAG          ;CHANGE BUS ADDRESS
1201
1202 021504 004737 036240   JSR          PC,PUT          ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      021510 000404   BR          10$          ;GO TO 10$ IF NO ERROR
      021512 000240   NOP          ;RETURN HERE IF ERROR
      021514 104000   EMT          ;ERROR # DEFINED BY PUT SUBROUTINE
      021516 000137 021666   JMP          16$          ;GO TO 16$ IF ERROR
1203 021522          10$:
1204
1205          ;WAIT FOR READ TO COMPLETE AND GET STATUS
1206 021522 004737 036602   JSR          PC,TIMOUT          ;WAIT FOR READ TO COMPLETE
1207
1208 021526 004737 035770   JSR          PC,GET          ;GO READ REGISTER(S) WITH GET SUBROUTINE
      021532 000404   BR          11$          ;GO TO 11$ IF NO ERROR
      021534 000240   NOP          ;RETURN HERE IF ERROR
      021536 104000   EMT          ;ERROR # DEFINED BY GET SUBROUTINE
      021540 000137 021666   JMP          16$          ;GO TO 16$ IF ERROR
  
```



```

1209 021544
1210
1211
1212 021544 004737 036766
      021550 000405
      021552 000240
      021554 104000
      021556 004736
      021560 000137 021666
1213 021564
1214 021564 004737 051502
      021570 000405
      021572 000240
      021574 104000
      021576 004736
      021600 000137 021666
1215 021604
1216 021604 004737 037620
      021610 000405
      021612 000240
      021614 104000
      021616 004736
      021620 000137 021666
1217 021624
1218
1219
1220 021624 004737 035342
      021630 101360
      021632 102364
      021634 000404
      021636 000240
      021640 104000
      021642 000137 021666
1221
1222
1223 021646
1224 021646 005237 001420
1225 021652 122737 000037 001420
1226 021660 103402
1227 021662 000137 021174
1228 021666
1229
1230
      021666
      021666 000004
      021670 000240
      021672 012706 001100
      021676 013700 001276
      021702 013701 001466
      021706 012737 000016 001226
1231
1232
1233 021714 012737 000000 001446
1234 021722 012737 000000 001420
1235 021730 012737 010000 001444
  
```

```

11$:
:VERIFY THE RESULTS OF READ OPERATION
      JSR      PC,PRIERR      ;GO CHECK FOR PRIMARY ERRORS
      BR       12$           ;GO TO 12$ IF NO ERROR
      NOP
      EMT
      JSR      PC,@(SP)+     ;ERROR # DEFINED BY PRIERR SUBROUTINE
      JMP      16$           ;GO BACK FOR MORE ERROR CHECKS
      ;GO TO 16$ IF ERROR

12$:
      JSR      PC,DTASTS     ;GO VERIFY RESULTS OF DATA TRANSFER
      BR       13$           ;GO TO 13$ IF NO ERROR
      NOP
      EMT
      JSR      PC,@(SP)+     ;ERROR # DEFINED BY DTASTS SUBROUTINE
      JMP      16$           ;GO BACK FOR MORE ERROR CHECKS
      ;GO TO 16$ IF ERROR

13$:
      JSR      PC,SECERR     ;GO CHECK FOR SECONDARY ERRORS
      BR       14$           ;GO TO 14$ IF NO ERROR
      NOP
      EMT
      JSR      PC,@(SP)+     ;ERROR # DEFINED BY SECERR SUBROUTINE
      JMP      16$           ;GO BACK FOR MORE ERROR CHECKS
      ;GO TO 16$ IF ERROR

14$:
:VERIFY DATA
      JSR      PC,CMPBUF     ;GO COMPARE WRITE, READ DATA BUFFERS
      .WORD   BUFONE        ;STARTING ADDRESS OF WRITE BUFFER
      .WORD   BUFTWO        ;STARTING ADDRESS OF READ BUFFER
      BR       15$           ;GO TO 15$ IF NO ERROR
      NOP
      EMT
      JSR      PC,@(SP)+     ;ERROR # DEFINED BY CMPBUF SUBROUTINE
      JMP      16$           ;GO TO 16$ IF ERROR

:INCREMENT ADDRESS AND FORMAT NEXT SECTOR
15$:
      INC      RMDAO         ;ADVANCE SECTOR COUNT
      CMPB    #31,,RMDAO    ;DONE ALL SECTORS??
      BLO     16$           ;YES!!
      JMP     1$            ;GO DO NEXT SECTOR

16$:
:*****
:*TEST 16      FORMAT EACH TRACK ADDRESS
:*****
TST16:
      SCOPE
      NOP
      MOV     #STACK,SP     ;SCOPE CALL
      ;START OF TEST
      MOV     $BASE,R0      ;INITIALIZE STACK POINTER
      ;R0 = UNIBUS ADDRESS
      MOV     TSTQUE,R1     ;(R1) = DEVICE BEING TESTED
      MOV     #16,$TESTN    ;:SET TEST NUMBER IN APT MAIL BOX

:SETUP PARAMETERS FOR GENERATING DATA BUFFER
      MOV     #0,RMDCO      ;CYLINDER = 0
      MOV     #0,RMDAO      ;TRACK = 0, SECTOR = 0
      MOV     #FMT16,RMOFO  ;16 BIT FORMAT
  
```

```

1236 021736 1$:
1237 021736 012737 177376 001414 MOV #-258.,RMWCO ;2 + 256 WORDS (2'S COMP)
1238 021744 012737 101360 001416 MOV #BUFONE,RMBAO ;DATA BUFFER ADDRESS
1239 021752 012737 000062 001412 MOV #WH,RMCS10 ;WRITE HEADER AND DATA
1240
1241 ;VERIFY THAT SECTOR IS NOT BAD
021760 004737 033152 JSR PC,BADSCT ;CALL BAD SECTOR MODULE
021764 000405 BR 2$ ;GO TO 2$ IF NO ERROR
021766 104401 063346 TYPE ,SCTMSG ;TYPE BAD SECTOR MESSAGE
021772 104000 EMT ;ERROR # DEFINED BY BADSCT SUBROUTINE
021774 000137 022430 JMP 16$ ;GO TO 16$ IF ERROR
1242 022000 2$:
1243 022000 012737 001420 001174 MOV #RMDAO,$TMP0 ;USE TRACK FOR DATA PATTERN
1244 022006 012737 000001 001176 MOV #1,$TMP1
1245 022014 004737 035104 JSR PC,GENBUF ;GO GENERATE DATA BUFFER
1246 022020 3$:
1247 ;PREPARE DEVICE FOR DATA TRANSFER
1248 JSR PC,TSTPRP ;PREPARE DEVICE FOR TEST
1249 022020 004737 032176 .WORD 154130 ;TASK DESCRIPTOR AS FOLLOWS:
022024 154130 ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
;CLEAR CONTROLLER & SELECT DEVICE
;VERIFY CONTROLLER CLEAR OPERATION
;PACK ACKNOWLEDGE IF VOLUME NOT VALID
;VERIFY PACK ACKNOWLEDGE
;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
;VERIFY RECALIBRATION
;GO TO 4$ IF NO ERROR
;RETURN HERE IF ERROR
;ERROR # DEFINED BY TSTPRP SUBROUTINE
;GO TO 16$ IF ERROR
022026 000404 BR 4$
022030 000240 NOP
022032 104000 EMT
022034 000137 022430 JMP 16$
1250 022040 4$:
1251 ;SETUP AND EXECUTE WRITE HEADER AND DATA COMMAND
1252 MOV #WH!GO,RMCS10 ;WRITE HEADER AND DATA
1253 022040 012737 000063 001412 MOV #PUTINX,R2 ;WRITE REGISTER INDEX TABLE
1254 022046 012702 001553 MOV #RMDA,(R2)+
1255 022052 112722 000006 MOV #RMDC,(R2)+
1256 022056 112722 000034 MOV #RMOF,(R2)+
1257 022062 112722 000032 MOV #RMWC,(R2)+
1258 022066 112722 000002 MOV #RMBA,(R2)+
1259 022072 112722 000004 MOV #RMCS1,(R2)+
1260 022076 112722 000000 MOV #200,(R2)+
1261 022102 112722 000200
1262
1263 022106 004737 036240 JSR PC,PUT ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
022112 000404 BR 5$ ;GO TO 5$ IF NO ERROR
022114 000240 NOP ;RETURN HERE IF ERROR
022116 104000 EMT ;ERROR # DEFINED BY PUT SUBROUTINE
022120 000137 022430 JMP 16$ ;GO TO 16$ IF ERROR
1264 022124 5$:
1265 ;SETUP INPUT REGISTER BUFFER FOR READING STATUS
1266 JSR PC,GETSTS
1267 022124 004737 035704 JSR PC,TIMOUT ;WAIT FOR COMMAND TO COMPLETE
1268 022130 004737 036602
1269
1270 022134 004737 035770 JSR PC,GET ;GO READ REGISTER(S) WITH GET SUBROUTINE
022140 000404 BR 6$ ;GO TO 6$ IF NO ERROR
  
```



```

022142 000240      NOP      ;RETURN HERE IF ERROR
022144 104000      EMT      ;ERROR # DEFINED BY GET SUBROUTINE
022146 000137 022430 JMP      16$      ;GO TO 16$ IF ERROR
1271 022152      6$:
1272
1273      ;VERIFY RESULTS OF WRITE COMMAND
1274 022152 004737 036766 JSR      PC,PRIERR ;GO CHECK FOR PRIMARY ERRORS
022156 000405      BR      7$      ;GO TO 7$ IF NO ERROR
022160 000240      NOP      ;RETURN HERE IF ERROR
022162 104000      EMT      ;ERROR # DEFINED BY PRIERR SUBROUTINE
022164 004736      JSR      PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
022166 000137 022430 JMP      16$      ;GO TO 16$ IF ERROR
1275 022172      7$:
1276 022172 004737 051502 JSR      PC,DTASTS ;GO VERIFY RESULTS OF DATA TRANSFER
022176 000405      BR      8$      ;GO TO 8$ IF NO ERROR
022200 000240      NOP      ;RETURN HERE IF ERROR
022202 104000      EMT      ;ERROR # DEFINED BY DTASTS SUBROUTINE
022204 004736      JSR      PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
022206 000137 022430 JMP      16$      ;GO TO 16$ IF ERROR
1277 022212      8$:
1278 022212 004737 037620 JSR      PC,SECERR ;GO CHECK FOR SECONDARY ERRORS
022216 000405      BR      9$      ;GO TO 9$ IF NO ERROR
022220 000240      NOP      ;RETURN HERE IF ERROR
022222 104000      EMT      ;ERROR # DEFINED BY SECERR SUBROUTINE
022224 004736      JSR      PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
022226 000137 022430 JMP      16$      ;GO TO 16$ IF ERROR
1279 022232      9$:
1280
1281      ;READ HEADER AND DATA FOR SECTOR JUST WRITTEN
1282 022232 012737 000073 001412 MOV      #RH!GO,RMCS10 ;READ HEADER & DATA COMMAND
1283 022240 012737 102364 001416 MOV      #BUFTWO,RMBAO ;CHANGE BUS ADDRESS
1284
1285 022246 004737 036240 JSR      PC,PUT      ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
022252 000404      BR      10$     ;GO TO 10$ IF NO ERROR
022254 000240      NOP      ;RETURN HERE IF ERROR
022256 104000      EMT      ;ERROR # DEFINED BY PUT SUBROUTINE
022260 000137 022430 JMP      16$      ;GO TO 16$ IF ERROR
1286 022264      10$:
1287
1288      ;WAIT FOR READ TO COMPLETE AND GET STATUS
1289 022264 004737 036602 JSR      PC,TIMOUT  ;WAIT FOR READ TO COMPLETE
1290
1291 022270 004737 035770 JSR      PC,GET      ;GO READ REGISTER(S) WITH GET SUBROUTINE
022274 000404      BR      11$     ;GO TO 11$ IF NO ERROR
022276 000240      NOP      ;RETURN HERE IF ERROR
022300 104000      EMT      ;ERROR # DEFINED BY GET SUBROUTINE
022302 000137 022430 JMP      16$      ;GO TO 16$ IF ERROR
1292 022306      11$:
1293
1294      ;VERIFY THE RESULTS OF READ OPERATION
1295 022306 004737 036766 JSR      PC,PRIERR  ;GO CHECK FOR PRIMARY ERRORS
022312 000405      BR      12$     ;GO TO 12$ IF NO ERROR
022314 000240      NOP      ;RETURN HERE IF ERROR
022316 104000      EMT      ;ERROR # DEFINED BY PRIERR SUBROUTINE
022320 004736      JSR      PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
022322 000137 022430 JMP      16$      ;GO TO 16$ IF ERROR
1296 022326      12$:

```

```

1297 022326 004737 051502      JSR    PC,DTASTS      ;GO VERIFY RESULTS OF DATA TRANSFER
      022332 000405          BR      13$           ;GO TO 13$ IF NO ERROR
      022334 000240          NOP                    ;RETURN HERE IF ERROR
      022336 104000          EMT                    ;ERROR # DEFINED BY DTASTS SUBROUTINE
      022340 004736          JSR    PC,@(SP)+      ;GO BACK FOR MORE ERROR CHECKS
      022342 000137 022430      JMP      16$           ;GO TO 16$ IF ERROR
1298 022346          ;
1299 022346 004737 037620      JSR    PC,SECERR      ;GO CHECK FOR SECONDARY ERRORS
      022352 000405          BR      14$           ;GO TO 14$ IF NO ERROR
      022354 000240          NOP                    ;RETURN HERE IF ERROR
      022356 104000          EMT                    ;ERROR # DEFINED BY SECERR SUBROUTINE
      022360 004736          JSR    PC,@(SP)+      ;GO BACK FOR MORE ERROR CHECKS
      022362 000137 022430      JMP      16$           ;GO TO 16$ IF ERROR
1300 022366          ;
1301          ;
1302          ;
1303 022366 004737 035342      ;VERIFY DATA
      022372 101360          JSR    PC,CMPBUF      ;GO COMPARE WRITE, READ DATA BUFFERS
      022374 102364          .WORD  BUFO1          ;STARTING ADDRESS OF WRITE BUFFER
      022376 000404          .WORD  BUFTWO         ;STARTING ADDRESS OF READ BUFFER
      022400 000240          BR      15$           ;GO TO 15$ IF NO ERROR
      022402 104000          NOP                    ;RETURN HERE IF ERROR
      022404 000137 022430      EMT                    ;ERROR # DEFINED BY CMPBUF SUBROUTINE
      JMP      16$           ;GO TO 16$ IF ERROR
1304          ;
1305          ;
1306 022410          ;INCREMENT ADDRESS AND FORMAT NEXT TRACK
1307 022410 105237 001421      INCB   RMDAO+1        ;ADVANCE TRACK COUNT
1308 022414 123737 001421 001335 CMPB   RMDAO+1,LSTRK+1 ;LAST TRACK ?
1309 022422 101002          BHI    16$           ;YES!!
1310 022424 000137 021736      JMP      1$           ;GO DO NEXT SECTOR
1311 022430          ;
1312          ;
1313          ;
      ;*****
      ;*TEST 17          FORMAT PRIME CYLINDERS
      ;*****
      TST17:
      022430          SCOPE          ;SCOPE CALL
      022432 000240          NOP                    ;START OF TEST
      022434 012706 001100      MOV     #STACK,SP     ;INITIALIZE STACK POINTER
      022440 013700 001276      MOV     $BASE,R0      ;R0 = UNIBUS ADDRESS
      022444 013701 001466      MOV     TSTQUE,R1     ;(R1) = DEVICE BEING TESTED
      022450 012737 000017 001226 MOV     #17,$TESTN    ;SET TEST NUMBER IN APT MAIL BOX
1314          ;
1315          ;SETUP PARAMETERS FOR GENERATING DATA BUFFER
1316 022456 012737 000001 001446 MOV     #1,RMDCO      ;CYLINDER = 1
1317 022464 012737 000000 001420 MOV     #0,RMDAO      ;TRACK = 0, SECTOR = 0
1318 022472          ;
1319 022472 012737 010000 001444 MOV     #FMT16,RMOFO  ;16 BIT FORMAT
1320 022500 012737 177376 001414 MOV     #-258.,RMWCO  ;2 + 256 WORDS (2'S COMP)
1321 022506 012737 101360 001416 MOV     #BUFO1,RMBAO  ;DATA BUFFER ADDRESS
1322 022514 012737 000062 001412 MOV     #WH,RMCS10    ;WRITE HEADER AND DATA
1323          ;
1324          ;VERIFY THAT SECTOR IS NOT BAD
      022522 004737 033152      JSR    PC,BADSCT     ;CALL BAD SECTOR MODULE
      022526 000405          BR      2$           ;GO TO 2$ IF NO ERROR
      022530 104401 063346      TYPE   ,SCTMSG       ;TYPE BAD SECTOR MESSAGE
      022534 104000          EMT                    ;ERROR # DEFINED BY BADSCT SUBROUTINE
    
```



```

1325 022536 000137 023172          JMP      16$          :GO TO 16$ IF ERROR
1326 022542          2$:          MOV      #RMDCO,$TMPO :USE CYLINDER FOR DATA PATTERN
1327 022542 012737 001446 001174      MOV      #1,$TMP1
1328 022550 012737 000001 001176      JSR      PC,GENBUF   :GO GENERATE DATA BUFFER
1329 022556 004737 035104
1330 022562          3$:
1331          :PREPARE DEVICE FOR DATA TRANSFER
1332          JSR      PC,TSTPRP :PREPARE DEVICE FOR TEST
1333 022562 004737 032176      .WORD   154130      :TASK DESCRIPTOR AS FOLLOWS:
1334 022566 154130          :SELECT DEVICE & VERIFY DEVICE AVAILABLE
1335          :CLEAR CONTROLLER & SELECT DEVICE
1336          :VERIFY CONTROLLER CLEAR OPERATION
1337          :PACK ACKNOWLEDGE IF VOLUME NOT VALID
1338          :VERIFY PACK ACKNOWLEDGE
1339          :RECALIBRATE IF 'SKI' OR 'PIP' IS SET
1340          :VERIFY RECALIBRATION
1341          BR      4$          :GO TO 4$ IF NO ERROR
1342          NOP
1343          EMT
1344          JMP      16$      :RETURN HERE IF ERROR
1345          :ERROR # DEFINED BY TSTPRP SUBROUTINE
1346          :GO TO 16$ IF ERROR
1347          4$:
1348          :SETUP AND EXECUTE WRITE HEADER AND DATA COMMAND
1349          MOV      #WH!GO,RMCS1G :WRITE HEADER AND DATA
1350          MOV      #PUTINX,R2   :WRITE REGISTER INDEX TABLE
1351          MOVB     #RMDA,(R2)+
1352          MOVB     #RMDC,(R2)+
1353          MOVB     #RMOF,(R2)+
1354          MOVB     #RMWC,(R2)+
1355          MOVB     #RMBA,(R2)+
1356          MOVB     #RMCS1,(R2)+
1357          MOVB     #200,(R2)+
1358          JSR      PC,PUT       :GO WRITE REGISTER(S) WITH PUT SUBROUTINE
1359          BR      5$          :GO TO 5$ IF NO ERROR
1360          NOP
1361          EMT
1362          JMP      16$      :RETURN HERE IF ERROR
1363          :ERROR # DEFINED BY PUT SUBROUTINE
1364          :GO TO 16$ IF ERROR
1365          5$:
1366          :SETUP INPUT REGISTER BUFFER FOR READING STATUS
1367          JSR      PC,GETSTS
1368          :WAIT FOR WRITE COMMAND TO COMPLETE AND READ STATUS
1369          JSR      PC,TIMOUT     :WAIT FOR COMMAND TO COMPLETE
1370          JSR      PC,GET       :GO READ REGISTER(S) WITH GET SUBROUTINE
1371          BR      6$          :GO TO 6$ IF NO ERROR
1372          NOP
1373          EMT
1374          JMP      16$      :RETURN HERE IF ERROR
1375          :ERROR # DEFINED BY GET SUBROUTINE
1376          :GO TO 16$ IF ERROR
1377          6$:
1378          :VERIFY RESULTS OF WRITE COMMAND
1379          JSR      PC,PRIERR     :GO CHECK FOR PRIMARY ERRORS
1380          BR      7$          :GO TO 7$ IF NO ERROR
1381          NOP
1382          :RETURN HERE IF ERROR

```

	022724	104000			EMT			:ERROR # DEFINED BY PRIERR SUBROUTINE
	022726	004736			JSR	PC,@(SP)+		:GO BACK FOR MORE ERROR CHECKS
	022730	000137	023172		JMP	16\$:GO TO 16\$ IF ERROR
1359	022734			7\$:				
1360	022734	004737	051502		JSR	PC,DTASTS		:GO VERIFY RESULTS OF DATA TRANSFER
	022740	000405			BR	8\$:GO TO 8\$ IF NO ERROR
	022742	000240			NOP			:RETURN HERE IF ERROR
	022744	104000			EMT			:ERROR # DEFINED BY DTASTS SUBROUTINE
	022746	004736			JSR	PC,@(SP)+		:GO BACK FOR MORE ERROR CHECKS
	022750	000137	023172		JMP	16\$:GO TO 16\$ IF ERROR
1361	022754			8\$:				
1362	022754	004737	037620		JSR	PC,SECERR		:GO CHECK FOR SECONDARY ERRORS
	022760	000405			BR	9\$:GO TO 9\$ IF NO ERROR
	022762	000240			NOP			:RETURN HERE IF ERROR
	022764	104000			EMT			:ERROR # DEFINED BY SECERR SUBROUTINE
	022766	004736			JSR	PC,@(SP)+		:GO BACK FOR MORE ERROR CHECKS
	022770	000137	023172		JMP	16\$:GO TO 16\$ IF ERROR
1363	022774			9\$:				
1364								
1365								
1366	022774	012737	000073	001412	MOV	#RH!GO,RMCS10		:READ HEADER & DATA COMMAND
1367	023002	012737	102364	001416	MOV	#BUFTWO,RMBAO		:CHANGE BUS ADDRESS
1368	023010	004737	036240		JSR	PC,PUT		:GO WRITE REGISTER(S) WITH PUT SUBROUTINE
	023014	000404			BR	10\$:GO TO 10\$ IF NO ERROR
	023016	000240			NOP			:RETURN HERE IF ERROR
	023020	104000			EMT			:ERROR # DEFINED BY PUT SUBROUTINE
	023022	000137	023172		JMP	16\$:GO TO 16\$ IF ERROR
1369	023026			10\$:				
1370								
1371								
1372	023026	004737	036602		JSR	PC,TIMOUT		:WAIT FOR READ TO COMPLETE
1373	023032	004737	035770		JSR	PC,GET		:GO READ REGISTER(S) WITH GET SUBROUTINE
	023036	000404			BR	11\$:GO TO 11\$ IF NO ERROR
	023040	000240			NOP			:RETURN HERE IF ERROR
	023042	104000			EMT			:ERROR # DEFINED BY GET SUBROUTINE
	023044	000137	023172		JMP	16\$:GO TO 16\$ IF ERROR
1374	023050			11\$:				
1375								
1376								
1377	023050	004737	036766		JSR	PC,PRIERR		:GO CHECK FOR PRIMARY ERRORS
	023054	000405			BR	12\$:GO TO 12\$ IF NO ERROR
	023056	000240			NOP			:RETURN HERE IF ERROR
	023060	104000			EMT			:ERROR # DEFINED BY PRIERR SUBROUTINE
	023062	004736			JSR	PC,@(SP)+		:GO BACK FOR MORE ERROR CHECKS
	023064	000137	023172		JMP	16\$:GO TO 16\$ IF ERROR
1378	023070			12\$:				
1379	023070	004737	051502		JSR	PC,DTASTS		:GO VERIFY RESULTS OF DATA TRANSFER
	023074	000405			BR	13\$:GO TO 13\$ IF NO ERROR
	023076	000240			NOP			:RETURN HERE IF ERROR
	023100	104000			EMT			:ERROR # DEFINED BY DTASTS SUBROUTINE
	023102	004736			JSR	PC,@(SP)+		:GO BACK FOR MORE ERROR CHECKS
	023104	000137	023172		JMP	16\$:GO TO 16\$ IF ERROR
1380	023110			13\$:				
1381	023110	004737	037620		JSR	PC,SECERR		:GO CHECK FOR SECONDARY ERRORS
	023114	000405			BR	14\$:GO TO 14\$ IF NO ERROR
	023116	000240			NOP			:RETURN HERE IF ERROR
	023120	104000			EMT			:ERROR # DEFINED BY SECERR SUBROUTINE


```

1382 023122 004736 023172 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
1383 023124 000137 023172 JMP 16$ ;GO TO 16$ IF ERROR
1384 023130
1385 023130 004737 035342 :VERIFY DATA
023134 101360 JSR PC,CMPBUF ;GO COMPARE WRITE, READ DATA BUFFERS
023136 102364 .WORD BUFO1E ;STARTING ADDRESS OF WRITE BUFFER
023140 000404 .WORD BUFTWO ;STARTING ADDRESS OF READ BUFFER
023142 000240 BR 15$ ;GO TO 15$ IF NO ERROR
023144 104000 NOP ;RETURN HERE IF ERROR
023146 000137 023172 EMT ;ERROR # DEFINED BY CMPBUF SUBROUTINE
1386 023152 JMP 16$ ;GO TO 16$ IF ERROR
1387
1388 :INCREMENT ADDRESS AND FORMAT NEXT PRIME CYLINDER
1389 023152 006337 001446 ASL RMDCO ;ADVANCE CYLINDER COUNT
1390 023156 023727 001446 001000 CMP RMDCO,#512. ;DONE ALL PRIME CYLINDERS ?
1391 023164 003002 BGT 16$ ;YES!!
1392 023166 000137 022472 JMP 1$ ;GO DO NEXT CYLINDER
1393 023172
1394
1395 :*****
:*TEST 20 READ HEADER & DATA IN LAST SECTOR
:*****
TST20:
023172 SCOPE ;SCOPE CALL
023172 000004 NOP ;START OF TEST
023174 000240 MOV #STACK,SP ;INITIALIZE STACK POINTER
023176 012706 001100 MOV $BASE,R0 ;R0 = UNIBUS ADDRESS
023202 013700 001276 MOV TSTQUE,R1 ;(R1) = DEVICE BEING TESTED
023206 013701 001466 MOV #20,$TESTN ;:SET TEST NUMBER IN APT MAIL BOX
023212 012737 000020 001226

1396 :SETUP PARAMETERS FOR READING LAST SECTOR
1397 MOV #822.,RMDCO ;LAST CYLINDER
1398 023220 012737 001466 001446 MOV LSTRK,RMDAO ;SET LAST TRACK AND
1399 023226 013737 001334 001420 MOV #30.,RMDAO ;LAST SECTOR
1400 023234 112737 000036 001420 MOV #FMT16,RMOFO ;16 BIT FORMAT
1401 023242 012737 010000 001444
1402 023250
1403 023250 012737 177376 001414 1$: MOV #-258.,RMWCO ;2 + 256 WORDS (2'S COMP)
1404 023256 012737 102364 001416 MOV #BUFTWO,RMBAO ;DATA BUFFER ADDRESS
1405 023264 012737 000073 001412 MOV #RH!GO,RMC10 ;READ HEADER AND DATA
1406
1407 :PREPARE DEVICE FOR DATA TRANSFER
1408 023272 004737 032176 JSR PC,TSTPRP ;PREPARE DEVICE FOR TEST
023276 154130 .WORD 154130 ;TASK DESCRIPTOR AS FOLLOWS:
;SELECT DEVICE & VERIFY DEVICE AVAILABLE
;CLEAR CONTROLLER & SELECT DEVICE
;VERIFY CONTROLLER CLEAR OPERATION
;PACK ACKNOWLEDGE IF VOLUME NOT VALID
;VERIFY PACK ACKNOWLEDGE
;RECALIBRATE IF "SKI" OR "PIP" IS SET
;VERIFY RECALIBRATION
023300 000404 BR 2$ ;GO TO 2$ IF NO ERROR
023302 000240 NOP ;RETURN HERE IF ERROR
023304 104000 EMT ;ERROR # DEFINED BY TSTPRP SUBROUTINE
023306 000137 023476 JMP 9$ ;GO TO 9$ IF ERROR
1409 023312
2$:

```

```

1410 023312 012702 001553      MOV      #PUTINX,R2      ;WRITE REGISTER INDEX TABLE
1411 023316 112722 000006      MOVB    #RMDA,(R2)+
1412 023322 112722 000034      MOVB    #RMDC,(R2)+
1413 023326 112722 000032      MOVB    #RMOF,(R2)+
1414 023332 112722 000004      MOVB    #RMBA,(R2)+
1415 023336 112722 000002      MOVB    #RMWC,(R2)+
1416 023342 112722 000000      MOVB    #RMCS1,(R2)+
1417 023346 112722 000200      MOVB    #200,(R2)+      ;TERMINATOR
1418 023352
1419
1420
1421 023352 004737 036240      ;READ HEADER AND DATA OF LAST SECTOR
      JSR    PC,PUT        ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      BR    4$           ;GO TO 4$ IF NO ERROR
      NOP                    ;RETURN HERE IF ERROR
      EMT                    ;ERROR # DEFINED BY PUT SUBROUTINE
      JMP    9$           ;GO TO 9$ IF ERROR
1422 023370
1423
1424
1425 023370 004737 035704      ;SETUP INPUT REGISTER BUFFER FOR READING STATUS
      JSR    PC,GETSTS
1426 023374 004737 036602      JSR    PC,TIMOUT      ;WAIT FOR READ TO COMPLETE
1427
1428 023400 004737 035770      JSR    PC,GET        ;GO READ REGISTER(S) WITH GET SUBROUTINE
      BR    5$           ;GO TO 5$ IF NO ERROR
      NOP                    ;RETURN HERE IF ERROR
      EMT                    ;ERROR # DEFINED BY GET SUBROUTINE
      JMP    9$           ;GO TO 9$ IF ERROR
1429 023416
1430
1431
1432 023416 004737 036766      ;VERIFY THE RESULTS OF READ OPERATION
      JSR    PC,PRIERR    ;GO CHECK FOR PRIMARY ERRORS
      BR    6$           ;GO TO 6$ IF NO ERROR
      NOP                    ;RETURN HERE IF ERROR
      EMT                    ;ERROR # DEFINED BY PRIERR SUBROUTINE
      JSR    PC,@(SP)+    ;GO BACK FOR MORE ERROR CHECKS
      JMP    9$           ;GO TO 9$ IF ERROR
1433 023436
1434 023436 004737 051502      6$: JSR    PC,DTASTS    ;GO VERIFY RESULTS OF DATA TRANSFER
      BR    7$           ;GO TO 7$ IF NO ERROR
      NOP                    ;RETURN HERE IF ERROR
      EMT                    ;ERROR # DEFINED BY DTASTS SUBROUTINE
      JSR    PC,@(SP)+    ;GO BACK FOR MORE ERROR CHECKS
      JMP    9$           ;GO TO 9$ IF ERROR
1435 023456
1436 023456 004737 037620      7$: JSR    PC,SECERR    ;GO CHECK FOR SECONDARY ERRORS
      BR    8$           ;GO TO 8$ IF NO ERROR
      NOP                    ;RETURN HERE IF ERROR
      EMT                    ;ERROR # DEFINED BY SECERR SUBROUTINE
      JSR    PC,@(SP)+    ;GO BACK FOR MORE ERROR CHECKS
      JMP    9$           ;GO TO 9$ IF ERROR
1437 023476
1438
1439 023476
1440
1441

```

```

*****
*TEST 21      READ HEADER & DATA W/ AOE ERROR
*****

```



```

023476          TST21:
023476 000004          SCOPE          :SCOPE CALL
023500 000240          NOP          :START OF TEST
023502 012706 001100  MOV      #STACK,SP  :INITIALIZE STACK POINTER
023506 013700 001276  MOV      $BASE,R0    :R0 = UNIBUS ADDRESS
023512 013701 001466  MOV      TSTQUE,R1  :(R1) = DEVICE BEING TESTED
023516 012737 000021 001226  MOV      #21,$TESTN  ::SET TEST NUMBER IN APT MAIL BOX

1442
1443
1444 023524 013737 001334 001420  :SETUP PARAMETERS FOR READING 2 SECTORS STARTING WITH LAST SECTOR
1445 023532 112737 000036 001420  MOV      LSTRK,RMDAO :SET LAST TRACK AND
1446 023540 012737 010000 001444  MOVB    #30.,RMDAO  :LAST SECTOR
1447 023546          MOV      #FMT16,RMOFO :16 BIT FORMAT
1448 023546 012737 001466 001446  1$:    MOV      #822.,RMDCO  :LAST CYLINDER
1449 023554 012737 176774 001414  MOV      #-258.*2,RMWCO :READ 2 SECTORS
1450 023562 012737 102364 001416  MOV      #BUFTWO,RMBAO  :DATA BUFFER ADDRESS
1451 023570 012737 000073 001412  MOV      #RH!GO,RMCSTO  :READ HEADER AND DATA
1452
1453
1454 023576 004737 032176          :PREPARE DEVICE FOR DATA TRANSFER
      023602 154130          JSR      PC,TSTPRP    :PREPARE DEVICE FOR TEST
      .WORD 154130          .WORD    154130      :TASK DESCRIPTOR AS FOLLOWS:
      :SELECT DEVICE & VERIFY DEVICE AVAILABLE
      :CLEAR CONTROLLER & SELECT DEVICE
      :VERIFY CONTROLLER CLEAR OPERATION
      :PACK ACKNOWLEDGE IF VOLUME NOT VALID
      :VERIFY PACK ACKNOWLEDGE
      :RECALIBRATE IF "SKI" OR "PIP" IS SET
      :VERIFY RECALIBRATION
      :GO TO 2$ IF NO ERROR
      :RETURN HERE IF ERROR
      :ERROR # DEFINED BY TSTPRP SUBROUTINE
      :GO TO 8$ IF ERROR

      BR      2$
      NOP
      EMT
      JMP      8$

1455 023616          2$:
1456 023616 012702 001553  MOV      #PUTINX,R2  :WRITE REGISTER INDEX TABLE
1457 023622 112722 000006  MOVB    #RMDA,(R2)+
1458 023626 112722 000034  MOVB    #RMDC,(R2)+
1459 023632 112722 000032  MOVB    #RMOF,(R2)+
1460 023636 112722 000002  MOVB    #RMWC,(R2)+
1461 023642 112722 000004  MOVB    #RMBA,(R2)+
1462 023646 112722 000000  MOVB    #RMCS1,(R2)+
1463 023652 112722 000200  MOVB    #200,(R2)+
1464
1465 023656 004737 036240          JSR      PC,PUT      :GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      023662 000404          BR      3$          :GO TO 3$ IF NO ERROR
      023664 000240          NOP          :RETURN HERE IF ERROR
      023666 104000          EMT          :ERROR # DEFINED BY PUT SUBROUTINE
      023670 000137 024002          JMP      8$          :GO TO 8$ IF ERROR

1466 023674          3$:
1467
1468
1469 023674 004737 035704          :SETUP INPUT REGISTER BUFFER FOR READING STATUS
1470 023700 004737 036602          JSR      PC,GETSTS
1471          JSR      PC,TIMOUT  :WAIT FOR READ TO COMPLETE
1472 023704 004737 035770          JSR      PC,GET      :GO READ REGISTER(S) WITH GET SUBROUTINE
      023710 000404          BR      4$          :GO TO 4$ IF NO ERROR
      023712 000240          NOP          :RETURN HERE IF ERROR
      023714 104000          EMT          :ERROR # DEFINED BY GET SUBROUTINE
    
```

```

1473 023716 000137 024002          JMP      8$          :GO TO 8$ IF ERROR
1474 023722
1475
1476 023722 004737 036766          :VERIFY THE RESULTS OF READ OPERATION
      023726 000405          JSR      PC,PRIERR  :GO CHECK FOR PRIMARY ERRORS
      023730 000240          BR       5$          :GO TO 5$ IF NO ERROR
      023732 104000          NOP
      023734 004736          EMT
      023736 000137 024002          JSR      PC,@(SP)+  :ERROR # DEFINED BY PRIERR SUBROUTINE
      023736 000137 024002          JMP      8$          :GO BACK FOR MORE ERROR CHECKS
      023736 000137 024002          :GO TO 8$ IF ERROR
1477 023742
1478 023742 004737 051502          5$:
      023746 000405          JSR      PC,DTASTS  :GO VERIFY RESULTS OF DATA TRANSFER
      023750 000240          BR       6$          :GO TO 6$ IF NO ERROR
      023752 104000          NOP
      023754 004736          EMT
      023756 000137 024002          JSR      PC,@(SP)+  :ERROR # DEFINED BY DTASTS SUBROUTINE
      023756 000137 024002          JMP      8$          :GO BACK FOR MORE ERROR CHECKS
      023756 000137 024002          :GO TO 8$ IF ERROR
1479 023762
1480 023762 004737 037620          6$:
      023766 000405          JSR      PC,SECERR  :GO CHECK FOR SECONDARY ERRORS
      023770 000240          BR       7$          :GO TO 7$ IF NO ERROR
      023772 104000          NOP
      023774 004736          EMT
      023776 000137 024002          JSR      PC,@(SP)+  :ERROR # DEFINED BY SECERR SUBROUTINE
      023776 000137 024002          JMP      8$          :GO BACK FOR MORE ERROR CHECKS
      023776 000137 024002          :GO TO 8$ IF ERROR
1481 024002
1482
1483 024002
1484
1485

```

```

*****
:*TEST 22          READ INVALID SECTOR ADDRESS
*****
TST22:

```

```

024002
024002 000004
024004 000240
024006 012706 001100
024012 013700 001276
024016 013701 001466
024022 012737 000022 001226
1486
1487 024030 012737 000000 001446
1488 024036 012737 000036 001420
1489 024044 012737 000000 001444
1490 024052 012737 101360 001416
1491 024060 012737 177376 001414
1492 024066 012737 000073 001412
1493 024074
1494
1495
1496 024074 004737 032176
      024100 154130
      SCOPE          :SCOPE CALL
      NOP            :START OF TEST
      MOV      #STACK,SP  :INITIALIZE STACK POINTER
      MOV      $BASE,R0   :R0 = UNIBUS ADDRESS
      MOV      TSTQUE,R1  :(R1) = DEVICE BEING TESTED
      MOV      #22,$TESTN :SET TEST NUMBER IN APT MAIL BOX
      MOV      #0,RMDCO   :CYLINDER = 0
      MOV      #30.,RMDAO :TRACK = 0, INVALID SECTOR = 30.
      MOV      #0,RMOFO   :18 BIT FORMAT
      MOV      #BUFONE,RMBAO :CHANGE BUS ADDRESS
      MOV      #-258.,RMWCO :2 + 256 WORDS (2'S COMP)
      MOV      #RH!GO,RMCSTO :READ HEADER AND DATA
1$:
:PREPARE DEVICE FOR DATA TRANSFER
      JSR      PC,TSTPRP  :PREPARE DEVICE FOR TEST
      .WORD   154130      :TASK DESCRIPTOR AS FOLLOWS:
                          :SELECT DEVICE & VERIFY DEVICE AVAILABLE
                          :CLEAR CONTROLLER & SELECT DEVICE
                          :VERIFY CONTROLLER CLEAR OPERATION
                          :PACK ACKNOWLEDGE IF VOLUME NOT VALID
                          :VERIFY PACK ACKNOWLEDGE
                          :RECALIBRATE IF 'SKI' OR 'PIP' IS SET
                          :VERIFY RECALIBRATION

```



```

024102 000404 BR 2$ :GO TO 2$ IF NO ERROR
024104 000240 NOP :RETURN HERE IF ERROR
024106 104000 EMT :ERROR # DEFINED BY TSTPRP SUBROUTINE
024110 000137 024344 JMP 9$ :GO TO 9$ IF ERROR
1497 024114 2$:
1498
1499 :SETUP AND EXECUTE READ HEADER AND DATA COMMAND
1500 024114 012702 001553 MOV #PUTINX,R2 :LOAD REGISTER INDEX TABLE
1501 024120 112722 000006 MOVB #RMDA,(R2)+
1502 024124 112722 000034 MOVB #R'MDC,(R2)+
1503 024130 112722 000032 MOVB #RMOF,(R2)+
1504 024134 112722 000002 MOVB #RMWC,(R2)+
1505 024140 112722 000004 MOVB #RMBA,(R2)+
1506 024144 112722 000000 MOVB #RMCS1,(R2)+
1507 024150 112722 000200 MOVB #200,(R2)+ :SET TERMINATOR BYTE
1508
1509 024154 004737 036240 JSR PC,PUT :GO WRITE REGISTER(S) WITH PUT SUBROUTINE
024160 000404 BR 3$ :GO TO 3$ IF NO ERROR
024162 000240 NOP :RETURN HERE IF ERROR
024164 104000 EMT :ERROR # DEFINED BY PUT SUBROUTINE
024166 000137 024344 JMP 9$ :GO TO 9$ IF ERROR
1510 024172 3$:
1511
1512 :SETUP INPUT REGISTER BUFFER FOR READING STATUS
1513 024172 004737 035704 JSR PC,GETSTS
1514 024176 004737 036602 JSR PC,TIMOUT :WAIT FOR COMMAND TO COMPLETE
1515
1516 024202 004737 035770 JSR PC,GET :GO READ REGISTER(S) WITH GET SUBROUTINE
024206 000404 BR 4$ :GO TO 4$ IF NO ERROR
024210 000240 NOP :RETURN HERE IF ERROR
024212 104000 EMT :ERROR # DEFINED BY GET SUBROUTINE
024214 000137 024344 JMP 9$ :GO TO 9$ IF ERROR
1517 024220 4$:
1518
1519 :VERIFY RESULTS OF READ COMMAND
1520 024220 004737 036766 JSR PC,PRIERR :GO CHECK FOR PRIMARY ERRORS
024224 000405 BR 5$ :GO TO 5$ IF NO ERROR
024226 000240 NOP :RETURN HERE IF ERROR
024230 104000 EMT :ERROR # DEFINED BY PRIERR SUBROUTINE
024232 004736 JSR PC,@(SP)+ :GO BACK FOR MORE ERROR CHECKS
024234 000137 024344 JMP 9$ :GO TO 9$ IF ERROR
1521 024240 5$:
1522 024240 004737 051502 JSR PC,DTASTS :GO VERIFY RESULTS OF DATA TRANSFER
024244 000405 BR 6$ :GO TO 6$ IF NO ERROR
024246 000240 NOP :RETURN HERE IF ERROR
024250 104000 EMT :ERROR # DEFINED BY DTASTS SUBROUTINE
024252 004736 JSR PC,@(SP)+ :GO BACK FOR MORE ERROR CHECKS
024254 000137 024344 JMP 9$ :GO TO 9$ IF ERROR
1523 024260 6$:
1524 024260 004737 037620 JSR PC,SECERR :GO CHECK FOR SECONDARY ERRORS
024264 000405 BR 7$ :GO TO 7$ IF NO ERROR
024266 000240 NOP :RETURN HERE IF ERROR
024270 104000 EMT :ERROR # DEFINED BY SECERR SUBROUTINE
024272 004736 JSR PC,@(SP)+ :GO BACK FOR MORE ERROR CHECKS
024274 000137 024344 JMP 9$ :GO TO 9$ IF ERROR
1525 024300 7$:
1526

```

```

1527          ;INCREMENT ADDRESS AND READ NEXT SECTOR
1528 024300 005237 001420      INC      RMDAO      ;ADVANCE SECTOR COUNT
1529 024304 023727 001420 000100  CMP      RMDAO,#64.  ;DONE ALL SECTORS??
1530 024312 101412          BLOS     8$         ;NO !!
1531
1532 024314 032737 010000 001444  BIT      #FMT16,RMOFO ;TEST 16 BIT MODE YET ?
1533 024322 001010          BNE      9$         ;YES !!
1534 024324 012737 000040 001420  MOV      #32.,RMDAO  ;TRACK = 0, INVALID SECTOR = 32.
1535 024332 012737 010000 001444  MOV      #FMT16,RMOFO ;SET 16 BIT MODE IN OFFSET AND
1536 024340 000137 024074      8$:      JMP      1$         ;TEST AGAIN.
1537
1538 024344          9$:
1539
1540          ;*****
          ;*TEST 23      READ INVALID TRACK ADDRESS
          ;*****
          TST23:
          SCOPE          ;SCOPE CALL
          NOP           ;START OF TEST
          MOV      #STACK,SP ;INITIALIZE STACK POINTER
          MOV      $BASE,R0  ;R0 = UNIBUS ADDRESS
          MOV      TSTQUE,R1 ; (R1) = DEVICE BEING TESTED
          MOV      #23,$TESTN ;:SET TEST NUMBER IN APT MAIL BOX
1541
1542 024372 012737 000000 001446  MOV      #0,RMDCO    ;CYLINDER = 0
1543 024400 013737 001334 001420  MOV      LSTRK,RMDAO ;LOAD LAST TRACK, SECTOR = 0
1544 024406 105237 001421          INCB     RMDAO+1    ;INCREMENT TO FIRST INVALID TRACK
1545 024412 012737 010000 001444  MOV      #FMT16,RMOFO ;16 BIT FORMAT
1546 024420 012737 177376 001414  MOV      #-258.,RMWCO ;2 + 256 WORDS (2'S COMP)
1547 024426 012737 101360 001416  MOV      #BUFONE,RMBAO ;DATA BUFFER ADDRESS
1548 024434 012737 000073 001412  MOV      #RH!GO,RMCS10 ;READ HEADER AND DATA
1549 024442
1550
1551          ;PREPARE DEVICE FOR DATA TRANSFER
1552 024442 004737 032176      JSR      PC,TSTPRP  ;PREPARE DEVICE FOR TEST
          .WORD    154130 ;TASK DESCRIPTOR AS FOLLOWS:
          ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
          ;CLEAR CONTROLLER & SELECT DEVICE
          ;VERIFY CONTROLLER CLEAR OPERATION
          ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
          ;VERIFY PACK ACKNOWLEDGE
          ;RECALIBRATE IF "SKI" OR "PIP" IS SET
          ;VERIFY RECALIBRATION
          ;GO TO 2$ IF NO ERROR
          ;RETURN HERE IF ERROR
          ;ERROR # DEFINED BY TSTPRP SUBROUTINE
          ;GO TO 8$ IF ERROR
          BR      2$
          NOP
          EMT
          JMP      8$
1553 024462      2$:
1554
1555          ;SETUP AND EXECUTE READ HEADER AND DATA COMMAND
1556 024462 012702 001553      MOV      #PUTINX,R2 ;LOAD REGISTER INDEX TABLE
1557 024466 112722 000006      MOV      #RMDA,(R2)+
1558 024472 112722 000034      MOV      #RMDC,(R2)+
1559 024476 112722 000032      MOV      #RMOF,(R2)+
1560 024502 112722 000002      MOV      #RMWC,(R2)+
1561 024506 112722 000004      MOV      #RMBA,(R2)+
1562 024512 112722 000000      MOV      #RMCS1,(R2)+

```



```

1563 024516 112722 000200          MOVB   #200,(R2)+      ;SET TERMINATOR BYTE
1564
1565 024522 004737 036240          JSR    PC,PUT         ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      024526 000404          BR     3$            ;GO TO 3$ IF NO ERROR
      024530 000240          NOP                    ;RETURN HERE IF ERROR
      024532 104000          EMT                    ;ERROR # DEFINED BY PUT SUBROUTINE
      024534 000137 024666          JMP    8$            ;GO TO 8$ IF ERROR
1566 024540          3$:
1567
1568          ;SETUP INPUT REGISTER BUFFER FOR READING STATUS
1569 024540 004737 035704          JSR    PC,GETSTS     ;
1570 024544 004737 036602          JSR    PC,TIMOUT    ;WAIT FOR COMMAND TO COMPLETE
1571
1572 024550 004737 035770          JSR    PC,GET        ;GO READ REGISTER(S) WITH GET SUBROUTINE
      024554 000404          BR     4$            ;GO TO 4$ IF NO ERROR
      024556 000240          NOP                    ;RETURN HERE IF ERROR
      024560 104000          EMT                    ;ERROR # DEFINED BY GET SUBROUTINE
      024562 000137 024666          JMP    8$            ;GO TO 8$ IF ERROR
1573 024566          4$:
1574
1575          ;VERIFY RESULTS OF READ COMMAND
1576 024566 004737 036766          JSR    PC,PRIERR    ;GO CHECK FOR PRIMARY ERRORS
      024572 000405          BR     5$            ;GO TO 5$ IF NO ERROR
      024574 000240          NOP                    ;RETURN HERE IF ERROR
      024576 104000          EMT                    ;ERROR # DEFINED BY PRIERR SUBROUTINE
      024600 004736          JSR    PC,@(SP)+    ;GO BACK FOR MORE ERROR CHECKS
      024602 000137 024666          JMP    8$            ;GO TO 8$ IF ERROR
1577 024606          5$:
1578 024606 004737 051502          JSR    PC,DTASTS    ;GO VERIFY RESULTS OF DATA TRANSFER
      024612 000405          BR     6$            ;GO TO 6$ IF NO ERROR
      024614 000240          NOP                    ;RETURN HERE IF ERROR
      024616 104000          EMT                    ;ERROR # DEFINED BY DTASTS SUBROUTINE
      024620 004736          JSR    PC,@(SP)+    ;GO BACK FOR MORE ERROR CHECKS
      024622 000137 024666          JMP    8$            ;GO TO 8$ IF ERROR
1579 024626          6$:
1580 024626 004737 037620          JSR    PC,SECERR    ;GO CHECK FOR SECONDARY ERRORS
      024632 000405          BR     7$            ;GO TO 7$ IF NO ERROR
      024634 000240          NOP                    ;RETURN HERE IF ERROR
      024636 104000          EMT                    ;ERROR # DEFINED BY SECERR SUBROUTINE
      024640 004736          JSR    PC,@(SP)+    ;GO BACK FOR MORE ERROR CHECKS
      024642 000137 024666          JMP    8$            ;GO TO 8$ IF ERROR
1581 024646          7$:
1582
1583          ;INCREMENT ADDRESS AND READ NEXT TRACK
1584 024646 105237 001421          INCB   RMDAO+1      ;ADVANCE TRACK COUNT
1585 024652 123727 001421 000200    CMPB   RMDAO+1,#128. ;DONE ALL TRACKS??
1586 024660 101002          BHI    8$            ;YES!!
1587 024662 000137 024442          JMP    1$            ;GO DO NEXT TRACK
1588 024666          8$:
1589
1590          ;*****
          ;*TEST 24      READ INVALID CYLINDER ADDRESS
          ;*****
          TST24:
024666          SCOPE          ;SCOPE CALL
024666 000004          NOP              ;START OF TEST
024670 000240          MOV    #STACK,SP ;INITIALIZE STACK POINTER
024672 012706 001100

```

```

024676 013700 001276      MOV    $BASE,R0      ;R0 = UNIBUS ADDRESS
024702 013701 001466      MOV    TSTQUE,R1     ;(R1) = DEVICE BEING TESTED
024706 012737 000024 001226  MOV    #24,$TESTN    ;;SET TEST NUMBER IN APT MAIL BOX

1591
1592 024714 012737 001467 001446      MOV    #823.,RMDCO   ;START AT FIRST INVALID CYLINDER
1593 024722 012737 000000 001420      MOV    #0,RMDAO     ;TRACK = 0, SECTOR = 0
1594 024730 012737 010000 001444      MOV    #FMT16,RMOFO  ;16 BIT FORMAT
1595 024736 012737 177376 001414      MOV    #-258.,RMWCO  ;2 + 256 WORDS (2'S COMP)
1596 024744 012737 101360 001416      MOV    #BUFONE,RMBAO ;DATA BUFFER ADDRESS
1597 024752 012737 000073 001412      MOV    #RH!GO,RMCS10 ;READ HEADER AND DATA
1598 024760
1599
1600
1601 024760 004737 032176      ;PREPARE DEVICE FOR DATA TRANSFER
024764 154130      JSR    PC,TSTPRP    ;PREPARE DEVICE FOR TEST
                          .WORD 154130 ;TASK DESCRIPTOR AS FOLLOWS:
                          ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
                          ;CLEAR CONTROLLER & SELECT DEVICE
                          ;VERIFY CONTROLLER CLEAR OPERATION
                          ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
                          ;VERIFY PACK ACKNOWLEDGE
                          ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
                          ;VERIFY RECALIBRATION
                          ;GO TO 2$ IF NO ERROR
                          ;RETURN HERE IF ERROR
                          ;ERROR # DEFINED BY TSTPRP SUBROUTINE
                          ;GO TO 8$ IF ERROR

024766 000404      BR     2$
024770 000240      NOP
024772 104000      EMT
024774 000137 025204      JMP    8$
1602 025000      2$:
1603
1604      ;SETUP AND EXECUTE READ HEADER AND DATA COMMAND
1605 025000 012702 001553      MOV    #PUTINX,R2   ;LOAD REGISTER INDEX TABLE
1606 025004 112722 000006      MOVB  #RMDA,(R2)+
1607 025010 112722 000034      MOVB  #RMDC,(R2)+
1608 025014 112722 000032      MOVB  #RMOF,(R2)+
1609 025020 112722 000002      MOVB  #RMWC,(R2)+
1610 025024 112722 000004      MOVB  #RMBA,(R2)+
1611 025030 112722 000000      MOVB  #RMCS1,(R2)+
1612 025034 112722 000200      MOVB  #200,(R2)+   ;SET TERMINATOR BYTE
1613
1614 025040 004737 036240      JSR    PC,PUT       ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
025044 000404      BR     3$          ;GO TO 3$ IF NO ERROR
025046 000240      NOP              ;RETURN HERE IF ERROR
025050 104000      EMT              ;ERROR # DEFINED BY PUT SUBROUTINE
025052 000137 025204      JMP    8$          ;GO TO 8$ IF ERROR
1615 025056      3$:
1616
1617      ;SETUP INPUT REGISTER BUFFER FOR READING STATUS
1618 025056 004737 035704      JSR    PC,GETSTS
1619 025062 004737 036602      JSR    PC,TIMOUT   ;WAIT FOR COMMAND TO COMPLETE
1620
1621 025066 004737 035770      JSR    PC,GET       ;GO READ REGISTER(S) WITH GET SUBROUTINE
025072 000404      BR     4$          ;GO TO 4$ IF NO ERROR
025074 000240      NOP              ;RETURN HERE IF ERROR
025076 104000      EMT              ;ERROR # DEFINED BY GET SUBROUTINE
025100 000137 025204      JMP    8$          ;GO TO 8$ IF ERROR
1622 025104      4$:
1623
1624      ;VERIFY RESULTS OF READ COMMAND

```



```

1625 025104 004737 036766      JSR    PC,PRIERR      ;GO CHECK FOR PRIMARY ERRORS
      025110 000405          BR     5$             ;GO TO 5$ IF NO ERROR
      025112 000240          NOP                    ;RETURN HERE IF ERROR
      025114 104000          EMT                    ;ERROR # DEFINED BY PRIERR SUBROUTINE
      025116 004736          JSR    PC,@(SP)+      ;GO BACK FOR MORE ERROR CHECKS
      025120 000137 025204      JMP    8$             ;GO TO 8$ IF ERROR
1626 025124          5$:
1627 025124 004737 051502      JSR    PC,DTASTS     ;GO VERIFY RESULTS OF DATA TRANSFER
      025130 000405          BR     6$             ;GO TO 6$ IF NO ERROR
      025132 000240          NOP                    ;RETURN HERE IF ERROR
      025134 104000          EMT                    ;ERROR # DEFINED BY DTASTS SUBROUTINE
      025136 004736          JSR    PC,@(SP)+      ;GO BACK FOR MORE ERROR CHECKS
      025140 000137 025204      JMP    8$             ;GO TO 8$ IF ERROR
1628 025144          6$:
1629 025144 004737 037620      JSR    PC,SECERR     ;GO CHECK FOR SECONDARY ERRORS
      025150 000405          BR     7$             ;GO TO 7$ IF NO ERROR
      025152 000240          NOP                    ;RETURN HERE IF ERROR
      025154 104000          EMT                    ;ERROR # DEFINED BY SECERR SUBROUTINE
      025156 004736          JSR    PC,@(SP)+      ;GO BACK FOR MORE ERROR CHECKS
      025160 000137 025204      JMP    8$             ;GO TO 8$ IF ERROR
1630 025164          7$:
1631
1632          ;INCREMENT ADDRESS AND READ NEXT CYLINDER
1633 025164 005237 001446      INC    RMDCO         ;ADVANCE CYLINDER COUNT
1634 025170 023727 001446 002000  CMP    RMDCO,#1024.  ;DONE ALL CYLINDERS??
1635 025176 002002          BGE    8$             ;YES!!
1636 025200 000137 024760      JMP    1$            ;GO DO NEXT SECTOR
1637 025204          8$:
1638
1639          ;*****
          ;*TEST 25      FORMAT AT OFFSET
          ;*****
          TST25:
          025204          SCOPE          ;SCOPE CALL
          025204 000004          NOP          ;START OF TEST
          025206 000240          MOV    #STACK,SP  ;INITIALIZE STACK POINTER
          025210 012706 001100      MOV    $BASE,R0    ;R0 = UNIBUS ADDRESS
          025214 013700 001276      MOV    TSTQUE,R1   ;(R1) = DEVICE BEING TESTED
          025220 013701 001466      MOV    #25,$TESTN  ;:SET TEST NUMBER IN APT MAIL BOX
          025224 012737 000025 001226
          1640          ;SETUP PARAMETERS FOR GENERATING DATA BUFFER
          1641          MOV    #0,RMDCO      ;CYLINDER = 0
          1642 025232 012737 000000 001446      MOV    #0,RMDAO    ;TRACK = 0, SECTOR = 0
          1643 025240 012737 000000 001420      MOV    #FMT16,RMOFO ;16 BIT FORMAT
          1644 025246 012737 010000 001444      MOV    #-258.,RMWCO ;2 + 256 WORDS (2'S COMP)
          1645 025254 012737 177376 001414      MOV    #BUFONE,RMBAO ;DATA BUFFER ADDRESS
          1646 025262 012737 101360 001416      MOV    #WH!GO,RMCS10 ;WRITE HEADER AND DATA
          1647 025270 012737 000063 001412
          1648
          1649          ;VERIFY THAT SECTOR IS NOT BAD
          025276 004737 033152      JSR    PC,BADSCT    ;CALL BAD SECTOR MODULE
          025302 000405          BR     1$            ;GO TO 1$ IF NO ERROR
          025304 104401 063346      TYPE    ,SCTMSG     ;TYPE BAD SECTOR MESSAGE
          025310 104000          EMT                    ;ERROR # DEFINED BY BADSCT SUBROUTINE
          025312 000137 026116      JMP    17$          ;GO TO 17$ IF ERROR
1650 025316          1$:
1651 025316 012737 001420 001174      MOV    #RMDAO,$TMP0 ;USE SECTOR FOR DATA PATTERN
1652 025324 012737 000001 001176      MOV    #1,$TMP1
  
```

```

1653 025332 004737 035104          JSR    PC,GENBUF      ;GO GENERATE DATA BUFFER
1654 025336          2$:
1655
1656          ;PREPARE DEVICE FOR DATA TRANSFER
1657 025336 004737 032176          JSR    PC,TSTPRP     ;PREPARE DEVICE FOR TEST
          025342 154130          .WORD  154130        ;TASK DESCRIPTOR AS FOLLOWS:
          ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
          ;CLEAR CONTROLLER & SELECT DEVICE
          ;VERIFY CONTROLLER CLEAR OPERATION
          ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
          ;VERIFY PACK ACKNOWLEDGE
          ;RECALIBRATE IF "SKI" OR "PIP" IS SET
          ;VERIFY RECALIBRATION
          025344 000404          BR     3$            ;GO TO 3$ IF NO ERROR
          025346 000240          NOP
          025350 104000          EMT
          025352 000137 026116          JMP    17$          ;RETURN HERE IF ERROR
          ;ERROR # DEFINED BY TSTPRP SUBROUTINE
          ;GO TO 17$ IF ERROR
1658 025356          3$:
1659
1660          ;OFFSET DEVICE FOR WRITE
1661 025356 012737 000015 001412    MOV    #OFFSET!GO, RMCS10 ;CHANGE TO OFFSET COMMAND
1662 025364 012702 001553          MOV    #PUTINX,R2      ;WRITE PUT INDEX TABLE
1663 025370 112722 000006          MOVB  #RMDA,(R2)+
1664 025374 112722 000034          MOVB  #RMDC,(R2)+
1665 025400 112722 000032          MOVB  #RMOF,(R2)+
1666 025404 112722 000000          MOVB  #RMCS1,(R2)+
1667 025410 112712 000200          MOVB  #200,(R2)      ;TERMINATE TABLE
1668
1669 025414 004737 036240          JSR    PC,PUT        ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
          025420 000404          BR     4$            ;GO TO 4$ IF NO ERROR
          025422 000240          NOP
          025424 104000          EMT
          025426 000137 026116          JMP    17$          ;RETURN HERE IF ERROR
          ;ERROR # DEFINED BY PUT SUBROUTINE
          ;GO TO 17$ IF ERROR
1670 025432          4$:
1671
1672          ;SETUP AND EXECUTE WRITE HEADER AND DATA COMMAND AT OFFSET
1673 025432 012737 000063 001412    MOV    #WH!GO, RMCS10 ;WRITE HEADER AND DATA COMMAND
1674 025440 012702 001553          MOV    #PUTINX,R2      ;WRITE REGISTER INDEX TABLE
1675 025444 112722 000002          MOVB  #RMWC,(R2)+
1676 025450 112722 000004          MOVB  #RMBA,(R2)+
1677 025454 112722 000000          MOVB  #RMCS1,(R2)+
1678 025460 112722 000200          MOVB  #200,(R2)+
1679
1680 025464 004737 036240          JSR    PC,PUT        ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
          025470 000404          BR     5$            ;GO TO 5$ IF NO ERROR
          025472 000240          NOP
          025474 104000          EMT
          025476 000137 026116          JMP    17$          ;RETURN HERE IF ERROR
          ;ERROR # DEFINED BY PUT SUBROUTINE
          ;GO TO 17$ IF ERROR
1681 025502          5$:
1682
1683          ;SETUP INPUT REGISTER BUFFER FOR READING STATUS
1684 025502 004737 035704          JSR    PC,GETSTS
1685 025506 004737 036602          JSR    PC,TIMOUT     ;WAIT FOR COMMAND TO COMPLETE
1686
1687 025512 004737 035770          JSR    PC,GET        ;GO READ REGISTER(S) WITH GET SUBROUTINE
          025516 000404          BR     6$            ;GO TO 6$ IF NO ERROR
          025520 000240          NOP
          ;RETURN HERE IF ERROR
  
```


1688	025522	104000			EMT			:ERROR # DEFINED BY GET SUBROUTINE
1689	025524	000137	026116		JMP	17\$:GO TO 17\$ IF ERROR
1690	025530						6\$:	
1691	025530	004737	036766					:VERIFY RESULTS OF WRITE COMMAND
	025534	000405			JSR	PC,PRIERR		:GO CHECK FOR PRIMARY ERRORS
	025536	000240			BR	7\$:GO TO 7\$ IF NO ERROR
	025540	104000			NOP			:RETURN HERE IF ERROR
	025542	004736			EMT			:ERROR # DEFINED BY PRIERR SUBROUTINE
	025544	000137	026116		JSR	PC,@(SP)+		:GO BACK FOR MORE ERROR CHECKS
1692	025550				JMP	17\$:GO TO 17\$ IF ERROR
1693	025550	004737	051502				7\$:	
	025554	000405			JSR	PC,DTASTS		:GO VERIFY RESULTS OF DATA TRANSFER
	025556	000240			BR	8\$:GO TO 8\$ IF NO ERROR
	025560	104000			NOP			:RETURN HERE IF ERROR
	025562	004736			EMT			:ERROR # DEFINED BY DTASTS SUBROUTINE
	025564	000137	026116		JSR	PC,@(SP)+		:GO BACK FOR MORE ERROR CHECKS
1694	025570				JMP	17\$:GO TO 17\$ IF ERROR
1695	025570	004737	037620				8\$:	
	025574	000405			JSR	PC,SECERR		:GO CHECK FOR SECONDARY ERRORS
	025576	000240			BR	9\$:GO TO 9\$ IF NO ERROR
	025600	104000			NOP			:RETURN HERE IF ERROR
	025602	004736			EMT			:ERROR # DEFINED BY SECERR SUBROUTINE
	025604	000137	026116		JSR	PC,@(SP)+		:GO BACK FOR MORE ERROR CHECKS
1696	025610				JMP	17\$:GO TO 17\$ IF ERROR
1697							9\$:	
1698	025610	012737	000015	001412				:OFFSET DEVICE FOR READ
1699	025616	012702	001553		MOV	#OFFSET!GO,RMCS10		:CHANGE TO OFFSET COMMAND
1700	025622	112722	000006		MOV	#PUTINX,R2		:WRITE PUT INDEX TABLE
1701	025626	112722	000034		MOVB	#RMDA,(R2)+		
1702	025632	112722	000032		MOVB	#RMDC,(R2)+		
1703	025636	112722	000000		MOVB	#RMOF,(R2)+		
1704	025642	112722	000200		MOVB	#RMCS1,(R2)+		
1705					MOVB	#200,(R2)+		
1706	025646	004737	036240					
	025652	000404			JSR	PC,PUT		:GO WRITE REGISTER(S) WITH PUT SUBROUTINE
	025654	000240			BR	10\$:GO TO 10\$ IF NO ERROR
	025656	104000			NOP			:RETURN HERE IF ERROR
	025660	000137	026116		EMT			:ERROR # DEFINED BY PUT SUBROUTINE
1707	025664				JMP	17\$:GO TO 17\$ IF ERROR
1708							10\$:	
1709								
1710								:READ HEADER AND DATA AT OFFSET
1711	025664	012737	000073	001412	MOV	#RH!GO,RMCS10		:READ HEADER & DATA COMMAND
1712	025672	012737	102364	001416	MOV	#BUFTWO,RMBA0		:CHANGE BUS ADDRESS
1713	025700	012702	001553		MOV	#PUTINX,R2		:WRITE PUT INDEX TABLE
1714	025704	112722	000002		MOVB	#RMWC,(R2)+		
1715	025710	112722	000004		MOVB	#RMBA,(R2)+		
1716	025714	112722	000000		MOVB	#RMCS1,(R2)+		
1717	025720	112722	000200		MOVB	#200,(R2)+		
1718								
1719	025724	004737	036240					
	025730	000404			JSR	PC,PUT		:GO WRITE REGISTER(S) WITH PUT SUBROUTINE
	025732	000240			BR	11\$:GO TO 11\$ IF NO ERROR
	025734	104000			NOP			:RETURN HERE IF ERROR
	025736	000137	026116		EMT			:ERROR # DEFINED BY PUT SUBROUTINE
					JMP	17\$:GO TO 17\$ IF ERROR

```

1720 025742          11$:
1721
1722
1723 025742 004737 036602      :WAIT FOR READ TO COMPLETE AND GET STATUS
1724          JSR      PC,TIMOUT      :WAIT FOR READ TO COMPLETE
1725 025746 004737 035770      JSR      PC,GET      :GO READ REGISTER(S) WITH GET SUBROUTINE
          025752 000404          BR      12$          :GO TO 12$ IF NO ERROR
          025754 000240          NOP          :RETURN HERE IF ERROR
          025756 104000          EMT          :ERROR # DEFINED BY GET SUBROUTINE
          025760 000137 026116    JMP      17$          :GO TO 17$ IF ERROR
1726 025764          12$:
1727
1728
1729 025764 004737 036766      :VERIFY THE RESULTS OF READ OPERATION
          025770 000405          JSR      PC,PRIERR    :GO CHECK FOR PRIMARY ERRORS
          025772 000240          BR      13$          :GO TO 13$ IF NO ERROR
          025774 104000          NOP          :RETURN HERE IF ERROR
          025776 004736          EMT          :ERROR # DEFINED BY PRIERR SUBROUTINE
          026000 000137 026116    JSR      PC,@(SP)+    :GO BACK FOR MORE ERROR CHECKS
          JMP      17$          :GO TO 17$ IF ERROR
1730 026004          13$:
1731 026004 004737 051502      JSR      PC,DTASTS    :GO VERIFY RESULTS OF DATA TRANSFER
          026010 000405          BR      14$          :GO TO 14$ IF NO ERROR
          026012 000240          NOP          :RETURN HERE IF ERROR
          026014 104000          EMT          :ERROR # DEFINED BY DTASTS SUBROUTINE
          026016 004736          JSR      PC,@(SP)+    :GO BACK FOR MORE ERROR CHECKS
          026020 000137 026116    JMP      17$          :GO TO 17$ IF ERROR
1732 026024          14$:
1733 026024 004737 037620      JSR      PC,SECERR    :GO CHECK FOR SECONDARY ERRORS
          026030 000405          BR      15$          :GO TO 15$ IF NO ERROR
          026032 000240          NOP          :RETURN HERE IF ERROR
          026034 104000          EMT          :ERROR # DEFINED BY SECERR SUBROUTINE
          026036 004736          JSR      PC,@(SP)+    :GO BACK FOR MORE ERROR CHECKS
          026040 000137 026116    JMP      17$          :GO TO 17$ IF ERROR
1734 026044          15$:
1735
1736
1737 026044 004737 035342      :VERIFY DATA
          026050 101360          JSR      PC,CMPBUF    :GO COMPARE WRITE, READ DATA BUFFERS
          026052 102364          .WORD    BUFOONE      :STARTING ADDRESS OF WRITE BUFFER
          026054 000404          .WORD    BUFTWO      :STARTING ADDRESS OF READ BUFFER
          026056 000240          BR      16$          :GO TO 16$ IF NO ERROR
          026060 104000          NOP          :RETURN HERE IF ERROR
          026062 000137 026116    EMT          :ERROR # DEFINED BY CMPBUF SUBROUTINE
          JMP      17$          :GO TO 17$ IF ERROR
1738 026066          16$:
1739 026066 032737 000200 001444 BIT      #OFD,RMOFO      :DONE BOTH OFFSETS??
1740 026074 001010          BNE     17$          :YES!!
1741 026076 052737 000200 001444 BIS      #OFD,RMOFO      :SET FORWARD OFFSET
1742 026104 012737 101360 001416 MOV      #BUFOONE,RMBAO :CHANGE DATA BUFFER
1743 026112 000137 025336          JMP      2$
1744 026116          17$:
1745
1746

```

```

*****
:*TEST 26          IVC FORMAT TEST
*****
TST26:
          SCOPE          :SCOPE CALL
          NOP            :START OF TEST

```

```

026116
026116 000004
026120 000240

```



```

026122 012706 001100      MOV      #STACK,SP      ;INITIALIZE STACK POINTER
026126 013700 001276      MOV      $BASE,R0       ;R0 = UNIBUS ADDRESS
026132 013701 001466      MOV      TSTQUE,R1      ;(R1) = DEVICE BEING TESTED
026136 012737 000026 001226  MOV      #26,$TESTN     ;;SET TEST NUMBER IN APT MAIL BOX

1747
1748      ;SETUP PARAMETERS FOR GENERATING DATA BUFFER
1749 026144 012737 000000 001446  MOV      #0,RMDCO       ;CYLINDER = 0
1750 026152 012737 000000 001420  MOV      #0,RMDAO       ;TRACK = 0, SECTOR = 0
1751 026160 012737 010000 001444  MOV      #FMT16,RMOFO   ;16 BIT FORMAT
1752 026166 012737 177376 001414  MOV      #-258.,RMWCO   ;2 + 256 WORDS (2'S COMP)
1753 026174 012737 101360 001416  MOV      #BUFONE,RMBAO  ;DATA BUFFER ADDRESS
1754 026202 012737 000062 001412  MOV      #WH,RMC$10     ;WRITE HEADER AND DATA
1755
1756      ;VERIFY THAT SECTOR IS NOT BAD
026210 004737 033152      JSR      PC,BADSCT     ;CALL BAD SECTOR MODULE
026214 000405              BR       1$           ;GO TO 1$ IF NO ERROR
026216 104401 063346      TYPE    ,SCTMSG       ;TYPE BAD SECTOR MESSAGE
026222 104000              EMT                     ;ERROR # DEFINED BY BADSCT SUBROUTINE
026224 000137 026740      JMP     16$          ;GO TO 16$ IF ERROR
1757 026230      1$:
1758 026230 012737 001420 001174  MOV      #RMDAO,$TMP0   ;USE SECTOR FOR DATA PATTERN
1759 026236 012737 000001 001176  MOV      #1,$TMP1
1760 026244 004737 035104      JSR      PC,GENBUF     ;GO GENERATE DATA BUFFER
1761 026250      2$:
1762
1763      ;PREPARE DEVICE FOR DATA TRANSFER
1764 026250 004737 032176      JSR      PC,TSTPRP    ;PREPARE DEVICE FOR TEST
026254 154130      .WORD  154130        ;TASK DESCRIPTOR AS FOLLOWS:
                                ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
                                ;CLEAR CONTROLLER & SELECT DEVICE
                                ;VERIFY CONTROLLER CLEAR OPERATION
                                ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
                                ;VERIFY PACK ACKNOWLEDGE
                                ;RECALIBRATE IF "SKI" OR "PIP" IS SET
                                ;VERIFY RECALIBRATION
026256 000404              BR       3$           ;GO TO 3$ IF NO ERROR
026260 000240              NOP                    ;RETURN HERE IF ERROR
026262 104000              EMT                     ;ERROR # DEFINED BY TSTPRP SUBROUTINE
026264 000137 026740      JMP     16$          ;GO TO 16$ IF ERROR
1765 026270      3$:
1766
1767      ;RESET VOLUME VALID BY SETTING AND RESETTING DIAGNOSTIC MODE
1768 026270 012737 000001 001436  MOV      #DMD,RMMR10   ;SET DIAGNOSTIC MODE
1769 026276 112737 000024 001553  MOVB    #RMMR1,PUTINX  ;WRITE REGISTER INDEX TABLE
1770 026304 112737 000200 001554  MOVB    #200,PUTINX+1
1771
1772 026312 004737 036240      JSR      PC,PUT        ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
026316 000404              BR       4$           ;GO TO 4$ IF NO ERROR
026320 000240              NOP                    ;RETURN HERE IF ERROR
026322 104000              EMT                     ;ERROR # DEFINED BY PUT SUBROUTINE
026324 000137 026740      JMP     16$          ;GO TO 16$ IF ERROR
1773 026330      4$:
1774
1775      ;SETUP AND EXECUTE WRITE HEADER AND DATA COMMAND
1776 026330 012737 000063 001412  MOV      #WH!GO,RMC$10 ;WRITE HEADER AND DATA
1777 026336 012737 000000 001436  MOV      #0,RMMR10     ;RESET DIAGNOSTIC MODE
1778 026344 012702 001553      MOV      #PUTINX,R2    ;WRITE REGISTER INDEX TABLE
  
```

```

1779 026350 112722 000024      MOVB  #RMMR1,(R2)+
1780 026354 112722 000006      MOVB  #RMDA,(R2)+
1781 026360 112722 000034      MOVB  #RMDC,(R2)+
1782 026364 112722 000032      MOVB  #RMOF,(R2)+
1783 026370 112722 000002      MOVB  #RMWC,(R2)+
1784 026374 112722 000004      MOVB  #RMBA,(R2)+
1785 026400 112722 000000      MOVB  #RMCS1,(R2)+
1786 026404 112722 000200      MOVB  #200,(R2)+
1787
1788 026410 004737 036240      JSR   PC,PUT          ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      026414 000404          BR    5$             ;GO TO 5$ IF NO ERROR
      026416 000240          NOP                    ;RETURN HERE IF ERROR
      026420 104000          EMT                    ;ERROR # DEFINED BY PUT SUBROUTINE
      026422 000137 026740      JMP   16$           ;GO TO 16$ IF ERROR
1789 026426      5$:
1790
1791      ;SETUP INPUT REGISTER BUFFER FOR READING STATUS
1792 026426 004737 035704      JSR   PC,GETSTS
1793 026432 004737 036602      JSR   PC,TIMOUT      ;WAIT FOR COMMAND TO COMPLETE
1794
1795 026436 004737 035770      JSR   PC,GET          ;GO READ REGISTER(S) WITH GET SUBROUTINE
      026442 000404          BR    6$             ;GO TO 6$ IF NO ERROR
      026444 000240          NOP                    ;RETURN HERE IF ERROR
      026446 104000          EMT                    ;ERROR # DEFINED BY GET SUBROUTINE
      026450 000137 026740      JMP   16$           ;GO TO 16$ IF ERROR
1796 026454      6$:
1797
1798      ;VERIFY RESULTS OF WRITE COMMAND
1799 026454 004737 036766      JSR   PC,PRIERR      ;GO CHECK FOR PRIMARY ERRORS
      026460 000405          BR    7$             ;GO TO 7$ IF NO ERROR
      026462 000240          NOP                    ;RETURN HERE IF ERROR
      026464 104000          EMT                    ;ERROR # DEFINED BY PRIERR SUBROUTINE
      026466 004736          JSR   PC,@(SP)+      ;GO BACK FOR MORE ERROR CHECKS
      026470 000137 026740      JMP   16$           ;GO TO 16$ IF ERROR
1800 026474      7$:
1801 026474 032737 010000 001400  BIT   #IVC,RMER2I    ;IS IVC STATUS SET??
1802 026502 001012          BNE   8$             ;YES!!
1803 026504 013737 001400 001142  MOV   RMER2I,$BDDAT ;RECEIVED STATUS FOR TYPEOUT
1804 026512 013737 001400 001140  MOV   RMER2I,$GDDAT ;EXPECTED STATUS
1805 026520 052737 010000 001140  BIS   #IVC,$GDDAT
1806 026526 104342          EMT   342
1807 026530      8$:
1808 026530 004737 037620      JSR   PC,SECERR      ;GO CHECK FOR SECONDARY ERRORS
      026534 000405          BR    9$             ;GO TO 9$ IF NO ERROR
      026536 000240          NOP                    ;RETURN HERE IF ERROR
      026540 104000          EMT                    ;ERROR # DEFINED BY SECERR SUBROUTINE
      026542 004736          JSR   PC,@(SP)+      ;GO BACK FOR MORE ERROR CHECKS
      026544 000137 026740      JMP   16$           ;GO TO 16$ IF ERROR
1809 026550      9$:
1810
1811      ;CLEAR IVC ERROR
1812 026550 004737 032176      JSR   PC,TSTPRP      ;PREPARE DEVICE FOR TEST
      026554 040100          .WORD 040100      ;TASK DESCRIPTOR AS FOLLOWS:
      ;CLEAR CONTROLLER & SELECT DEVICE
      ;VERIFY CONTROLLER CLEAR OPERATION
      026556 000404          BR    10$           ;GO TO 10$ IF NO ERROR
      026560 000240          NOP                    ;RETURN HERE IF ERROR
  
```



```

026562 104000          EMT          ;ERROR # DEFINED BY TSTPRP SUBROUTINE
026564 000137 026740  JMP          16$          ;GO TO 16$ IF ERROR
1813 026570          10$:
1814
1815          ;READ HEADER AND DATA FOR SECTOR JUST WRITTEN
1816 026570 012737 000073 001412  MOV          #RH!GO,RMCS10 ;READ HEADER & DATA COMMAND
1817 026576 012737 102364 001416  MOV          #BUFTWO,RMBAO ;CHANGE BUS ADDRESS
1818
1819 026604 004737 036240          JSR          PC,PUT          ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
026610 000404          BR          11$          ;GO TO 11$ IF NO ERROR
026612 000240          NOP          ;RETURN HERE IF ERROR
026614 104000          EMT          ;ERROR # DEFINED BY PUT SUBROUTINE
026616 000137 026740  JMP          16$          ;GO TO 16$ IF ERROR
1820 026622          11$:
1821
1822          ;SETUP INPUT REGISTER BUFFER FOR READING STATUS
1823 026622 004737 035704          JSR          PC,GETSTS
1824 026626 004737 036602          JSR          PC,TIMOUT      ;WAIT FOR READ TO COMPLETE
1825
1826 026632 004737 035770          JSR          PC,GET          ;GO READ REGISTER(S) WITH GET SUBROUTINE
026636 000404          BR          12$          ;GO TO 12$, IF NO ERROR
026640 000240          NOP          ;RETURN HERE IF ERROR
026642 104000          EMT          ;ERROR # DEFINED BY GET SUBROUTINE
026644 000137 026740  JMP          16$          ;GO TO 16$ IF ERROR
1827 026650          12$:
1828
1829          ;VERIFY THE RESULTS OF READ OPERATION
1830 026650 004737 036766          JSR          PC,PRIERR      ;GO CHECK FOR PRIMARY ERRORS
026654 000405          BR          13$          ;GO TO 13$ IF NO ERROR
026656 000240          NOP          ;RETURN HERE IF ERROR
026660 104000          EMT          ;ERROR # DEFINED BY PRIERR SUBROUTINE
026662 004736          JSR          PC,@(SP)+    ;GO BACK FOR MORE ERROR CHECKS
026664 000137 026740  JMP          16$          ;GO TO 16$ IF ERROR
1831 026670          13$:
1832 026670 032737 010000 001400  BIT          #IVC,RMER2I    ;IS IVC STATUS SET??
1833 026676 001012          BNE          14$          ;YES!!
1834 026700 013737 001400 001142  MOV          RMER2I,$BDDAT  ;RECEIVED STATUS FOR TYPEOUT
1835 026706 013737 001400 001140*  MOV          RMER2I,$GDDAT  ;EXPECTED STATUS
1836 026714 052737 010000 001140  BIS          #IVC,$GDDAT
1837 026722 104342          EMT          342
1838 026724          14$:
1839 026724 004737 037620          JSR          PC,SECERR      ;GO CHECK FOR SECONDARY ERRORS
026730 000403          BR          15$          ;GO TO 15$ IF NO ERROR
026732 000240          NOP          ;RETURN HERE IF ERROR
026734 104000          EMT          ;ERROR # DEFINED BY SECERR SUBROUTINE
026736 004736          JSR          PC,@(SP)+    ;GO BACK FOR MORE ERROR CHECKS
1840 026740          15$:
1841
1842 026740          16$:
1843
1844
;*****
;*TEST 27          FORMAT ERROR TEST
;*****
TST27:
026740          SCOPE          ;SCOPE CALL
026740 000004          NOP          ;START OF TEST
026742 000240          MOV          #STACK,SP    ;INITIALIZE STACK POINTER
026744 012706 001100

```

```

026750 013700 001276      MOV    $BASE,R0      ;R0 = UNIBUS ADDRESS
026754 013701 001466      MOV    TSTQUE,R1     ;(R1) = DEVICE BEING TESTED
026760 012737 000027 001226  MOV    #27,$TESTN    ;:SET TEST NUMBER IN APT MAIL BOX

1845
1846      ;SETUP PARAMETERS FOR GENERATING DATA BUFFER
1847 026766 012737 000000 001446  MOV    #0,RMDCO      ;CYLINDER = 0
1848 026774 012737 000000 001420  MOV    #0,RMDAO      ;TRACK = 0, SECTOR = 0
1849 027002 012737 000000 001444  MOV    #0,RMOFO      ;18 BIT FORMAT
1850 027010 012737 177376 001414  MOV    #-258.,RMWCO   ;2 + 256 WORDS (2'S COMP)
1851 027016
1852 027016 012737 101360 001416 1$:    MOV    #BUFONE,RMBAO ;:DATA BUFFER ADDRESS
1853 027024 012737 000062 001412  MOV    #WH,RMCS10    ;:WRITE HEADER AND DATA
1854
1855      ;VERIFY THAT SECTOR IS NOT BAD
027032 004737 033152      JSR    PC,BADSCT     ;:CALL BAD SECTOR MODULE
027036 000405              BR     2$            ;:GO TO 2$ IF NO ERROR
027040 104401 063346      TYPE   ,SCTMSG       ;:TYPE BAD SECTOR MESSAGE
027044 104000              EMT                    ;:ERROR # DEFINED BY BADSCT SUBROUTINE
027046 000137 027522      JMP    16$          ;:GO TO 16$ IF ERROR
1856 027052
1857 027052 012737 065000 001174 2$:    MOV    #ZEROS,$TMP0   ;:USE ALL ZEROS DATA PATTERN
1858 027060 012737 000001 001176  MOV    #1,$TMP1
1859 027066 004737 035104  JSR    PC,GENBUF     ;:GO GENERATE DATA BUFFER
1860 027072
1861
1862      ;PREPARE DEVICE FOR DATA TRANSFER
1863 027072 004737 032176  JSR    PC,TSTPRP     ;:PREPARE DEVICE FOR TEST
027076 154130      .WORD 154130        ;:TASK DESCRIPTOR AS FOLLOWS:
                                ;:SELECT DEVICE & VERIFY DEVICE AVAILABLE
                                ;:CLEAR CONTROLLER & SELECT DEVICE
                                ;:VERIFY CONTROLLER CLEAR OPERATION
                                ;:PACK ACKNOWLEDGE IF VOLUME NOT VALID
                                ;:VERIFY PACK ACKNOWLEDGE
                                ;:RECALIBRATE IF 'SKI' OR 'PIP' IS SET
                                ;:VERIFY RECALIBRATION
027100 000404              BR     4$            ;:GO TO 4$ IF NO ERROR
027102 000240              NOP                    ;:RETURN HERE IF ERROR
027104 104000              EMT                    ;:ERROR # DEFINED BY TSTPRP SUBROUTINE
027106 000137 027522      JMP    16$          ;:GO TO 16$ IF ERROR
1864 027112
1865
1866      ;SETUP AND EXECUTE WRITE HEADER AND DATA COMMAND
1867 027112 012737 000063 001412  MOV    #WH!GO,RMCS10 ;:WRITE HEADER AND DATA
1868 027120 012702 001553  MOV    #PUTINX,R2    ;:WRITE REGISTER INDEX TABLE
1869 027124 112722 000006  MOVB   #RMDA,(R2)+
1870 027130 112722 000034  MOVB   #RMDC,(R2)+
1871 027134 112722 000032  MOVB   #RMOF,(R2)+
1872 027140 112722 000002  MOVB   #RMWC,(R2)+
1873 027144 112722 000004  MOVB   #RMBA,(R2)+
1874 027150 112722 000000  MOVB   #RMCS1,(R2)+
1875 027154 112722 000200  MOVB   #200,(R2)+
1876
1877 027160 004737 036240  JSR    PC,PUT        ;:GO WRITE REGISTER(S) WITH PUT SUBROUTINE
027164 000404              BR     5$            ;:GO TO 5$ IF NO ERROR
027166 000240              NOP                    ;:RETURN HERE IF ERROR
027170 104000              EMT                    ;:ERROR # DEFINED BY PUT SUBROUTINE
027172 000137 027522      JMP    16$          ;:GO TO 16$ IF ERROR

```



```

1909 027366 000137 027522          JMP      16$          ;GO TO 16$ IF ERROR
1910 027372
1911
1912 027372 004737 036766          ;VERIFY THE RESULTS OF READ OPERATION
      027376 000405          JSR      PC,PRIERR    ;GO CHECK FOR PRIMARY ERRORS
      027400 000240          BR       12$          ;GO TO 12$ IF NO ERROR
      027402 104000          NOP
      027404 004736          EMT
      027406 000137 027522          JSR      PC,@(SP)+    ;ERROR # DEFINED BY PRIERR SUBROUTINE
      027412          JMP      16$          ;GO BACK FOR MORE ERROR CHECKS
      ;GO TO 16$ IF ERROR
1913 12$:
1914
1915          ;VERIFY THAT FORMAT ERROR IS SET
1916 027412 032737 000020 001352    BIT      #FER,RMER1I  ;IS FORMAT ERROR SET??
1917 027420 001022          BNE     14$          ;YES!!
1918
1919 027422 004737 051502          JSR      PC,DTASTS    ;GO VERIFY RESULTS OF DATA TRANSFER
      027426 000405          BR       13$          ;GO TO 13$ IF NO ERROR
      027430 000240          NOP
      027432 104000          EMT
      027434 004736          JSR      PC,@(SP)+    ;ERROR # DEFINED BY DTASTS SUBROUTINE
      027436 000137 027522          JMP      16$          ;GO BACK FOR MORE ERROR CHECKS
      ;GO TO 16$ IF ERROR
1920
1921 027442 013737 001352 001142    13$:    MOV      RMER1I,$BDDAT ;BAD DATA FOR TYPEOUT
1922 027450 013737 001352 001140    MOV      RMER1I,$GDDAT ;EXPECTED DATA
1923 027456 052737 000020 001140    BIS      #FER,$GDDAT
1924 027464 104343          EMT      343
1925 027466
1926 027466 004737 037620          14$:    JSR      PC,SECERR    ;GO CHECK FOR SECONDARY ERRORS
      027472 000405          BR       15$          ;GO TO 15$ IF NO ERROR
      027474 000240          NOP
      027476 104000          EMT
      027500 004736          JSR      PC,@(SP)+    ;ERROR # DEFINED BY SECERR SUBROUTINE
      027502 000137 027522          JMP      16$          ;GO BACK FOR MORE ERROR CHECKS
      ;GO TO 16$ IF ERROR
1927 027506
1928 027506 032737 010000 001444    15$:    BIT      #FMT16,RMOFO ;TEST WRITE 16 BIT FORMAT AND
1929          ;READ 18 BIT MODE ?
1930 027514 001402          BEQ     16$          ;BR IF YES
1931 027516 000137 027016          JMP     1$           ;TEST AGAIN
1932 027522
1933 16$:
1934          ;*****
          ;*TEST 30          FORMAT HCE, FIRST HEADER WORD
          ;*****
          TST30:
          SCOPE          ;SCOPE CALL
          NOP           ;START OF TEST
          MOV      #STACK,SP ;INITIALIZE STACK POINTER
          MOV      $BASE,R0  ;R0 = UNIBUS ADDRESS
          MOV      TSTQUE,R1 ;(R1) = DEVICE BEING TESTED
          MCV      #30,$TESTN ;SET TEST NUMBER IN APT MAIL BOX
1935
1936 027522 000004
      027524 000240
      027526 012706 001100
      027532 013700 001276
      027536 013701 001466
      027542 012737 000030 001226
1937
1938          ;SETUP PARAMETERS FOR GENERATING DATA BUFFER
1939 1$:
1940 027550 012737 000001 030520    MOV      #1,23$      ;INIT BIT POSITION
      027556 012737 010000 001444    MOV      #FMT16,RMOFO ;16 BIT FORMAT
  
```



```

1978 030010 000137 030516          JMP      22$          ;GO TO 22$ IF ERROR
1979 030014          7$:
1980          ;SETUP INPUT REGISTER BUFFER FOR READING STATUS
1981 030014 004737 035704          JSR      PC,GETSTS
1982 030020 004737 036602          JSR      PC,TIMOUT          ;WAIT FOR COMMAND TO COMPLETE
1983
1984 030024 004737 035770          JSR      PC,GET          ;GO READ REGISTER(S) WITH GET SUBROUTINE
      030030 000404          BR      8$          ;GO TO 8$ IF NO ERROR
      030032 000240          NOP
      030034 104000          EMT          ;RETURN HERE IF ERROR
      030036 000137 030516          EMT          ;ERROR # DEFINED BY GET SUBROUTINE
1985 030042          JMP      22$          ;GO TO 22$ IF ERROR
1986
1987          ;VERIFY RESULTS OF WRITE COMMAND
1988 030042 004737 036766          JSR      PC,PRIERR          ;GO CHECK FOR PRIMARY ERRORS
      030046 000405          BR      9$          ;GO TO 9$ IF NO ERROR
      030050 000240          NOP          ;RETURN HERE IF ERROR
      030052 104000          EMT          ;ERROR # DEFINED BY PRIERR SUBROUTINE
      030054 004736          JSR      PC,@(SP)+          ;GO BACK FOR MORE ERROR CHECKS
      030056 000137 030516          JMP      22$          ;GO TO 22$ IF ERROR
1989 030062          9$:
1990 030062 004737 051502          JSR      PC,DTASTS          ;GO VERIFY RESULTS OF DATA TRANSFER
      030066 000405          BR      10$          ;GO TO 10$ IF NO ERROR
      030070 000240          NOP          ;RETURN HERE IF ERROR
      030072 104000          EMT          ;ERROR # DEFINED BY DTASTS SUBROUTINE
      030074 004736          JSR      PC,@(SP)+          ;GO BACK FOR MORE ERROR CHECKS
      030076 000137 030516          JMP      22$          ;GO TO 22$ IF ERROR
1991 030102          10$:
1992 030102 004737 037620          JSR      PC,SECERR          ;GO CHECK FOR SECONDARY ERRORS
      030106 000405          BR      11$          ;GO TO 11$ IF NO ERROR
      030110 000240          NOP          ;RETURN HERE IF ERROR
      030112 104000          EMT          ;ERROR # DEFINED BY SECERR SUBROUTINE
      030114 004736          JSR      PC,@(SP)+          ;GO BACK FOR MORE ERROR CHECKS
      030116 000137 030516          JMP      22$          ;GO TO 22$ IF ERROR
1993 030122          11$:
1994
1995          ;READ HEADER AND DATA FOR SECTOR JUST WRITTEN
1996 030122 012737 000073 001412          MOV      #RH!GO,RMCS10          ;READ HEADER & DATA COMMAND
1997 030130 012737 102364 001416          MOV      #BUFTWO,RMBAO          ;CHANGE BUS ADDRESS
1998
1999 030136 004737 036240          JSR      PC,PUT          ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      030142 000404          BR      12$          ;GO TO 12$ IF NO ERROR
      030144 000240          NOP          ;RETURN HERE IF ERROR
      030146 104000          EMT          ;ERROR # DEFINED BY PUT SUBROUTINE
      030150 000137 030516          JMP      22$          ;GO TO 22$ IF ERROR
2000 030154          12$:
2001
2002          ;WAIT FOR READ TO COMPLETE AND GET STATUS
2003 030154 004737 036602          JSR      PC,TIMOUT          ;WAIT FOR READ TO COMPLETE
2004
2005 030160 004737 035770          JSR      PC,GET          ;GO READ REGISTER(S) WITH GET SUBROUTINE
      030164 000404          BR      13$          ;GO TO 13$ IF NO ERROR
      030166 000240          NOP          ;RETURN HERE IF ERROR
      030170 104000          EMT          ;ERROR # DEFINED BY GET SUBROUTINE
      030172 000137 030516          JMP      22$          ;GO TO 22$ IF ERROR
2006 030176          13$:

```



```

2007
2008
2009 030176 004737 036766      ;VERIFY THE RESULTS OF READ OPERATION
      JSR    PC,PRIERR      ;GO CHECK FOR PRIMARY ERRORS
      BR     14$           ;GO TO 14$ IF NO ERROR
      NOP                    ;RETURN HERE IF ERROR
      EMT                    ;ERROR # DEFINED BY PRIERR SUBROUTINE
      JSR    PC,@(SP)+      ;GO BACK FOR MORE ERROR CHECKS
      JMP    22$           ;GO TO 22$ IF ERROR
2010 030216 000137 030516      14$:
2011 030216 032737 140000 030520 BIT    #MSE!USE,23$      ;SHOULD BSE BE SET ?
2012 030224 001033           BNE    16$              ;YES !!
2013 030226 032737 010000 030520 BIT    #FMT16,23$      ;IS THIS FER ??
2014 030234 001456           BEQ    18$              ;NO !!
2015
2016      ;VERIFY THAT FER IS SET
2017 030236 032737 000020 001352 BIT    #FER,RMER1I      ;IS FER SET ??
2018 030244 001107           BNE    20$              ;YES !!
2019
2020 030246 004737 051502      JSR    PC,DTASTS      ;GO VERIFY RESULTS OF DATA TRANSFER
      BR     15$           ;GO TO 15$ IF NO ERROR
      NOP                    ;RETURN HERE IF ERROR
      EMT                    ;ERROR # DEFINED BY DTASTS SUBROUTINE
      JSR    PC,@(SP)+      ;GO BACK FOR MORE ERROR CHECKS
      JMP    22$           ;GO TO 22$ IF ERROR
2021 030266 000137 030516      15$:
2022 030266 013737 001352 001142 MOV    RMER1I,$BDDAT   ;RECEIVED STATUS
2023 030274 013737 001352 001140 MOV    RMER1I,$GDDAT   ;EXPECTED STATUS
2024 030302 052737 000020 001140 BIS    #FER,$GDDAT
2025 030310 104343           EMT    343
2026 030312 000501           BR     22$
2027
2028      ;VERIFY THAT BSE IS SET
2029 030314 000137 030516      16$:
2030 030314 032737 100000 001400 BIT    #BSE,RMER2I      ;IS BSE SET ??
2031 030322 001060           BNE    20$              ;YES !!
2032
2033 030324 004737 051502      JSR    PC,DTASTS      ;GO VERIFY RESULTS OF DATA TRANSFER
      BR     17$           ;GO TO 17$ IF NO ERROR
      NOP                    ;RETURN HERE IF ERROR
      EMT                    ;ERROR # DEFINED BY DTASTS SUBROUTINE
      JSR    PC,@(SP)+      ;GO BACK FOR MORE ERROR CHECKS
      JMP    22$           ;GO TO 22$ IF ERROR
2034 030344 000137 030516      17$:
2035 030344 013737 001400 001142 MOV    RMER2I,$BDDAT   ;RECEIVED STATUS
2036 030352 013737 001400 001140 MOV    RMER2I,$GDDAT   ;EXPECTED STATUS
2037 030360 052737 100000 001140 BIS    #BSE,$GDDAT
2038 030366 104345           EMT    345
2039 030370 000452           BR     22$              ;SKIP REST OF TEST
2040
2041      ;VERIFY THAT HCE IS SET
2042 030372 000137 030516      18$:
2043 030372 032737 000200 001352 BIT    #HCE,RMER1I      ;IS 'HCE' SET??
2044 030400 001031           BNE    20$              ;YES!!
2045
2046 030402 004737 051502      JSR    PC,DTASTS      ;GO VERIFY RESULTS OF DATA TRANSFER
      BR     19$           ;GO TO 19$ IF NO ERROR
      NOP                    ;RETURN HERE IF ERROR
  
```

```

030412 104000 EMT ;ERROR # DEFINED BY DTAITS SUBROUTINE
030414 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
030416 000137 030516 JMP 22$ ;GO TO 22$ IF ERROR
2047 030422 19$:
2048 030422 013737 001352 001142 MOV RMER11,$BDDAT ;RECEIVED STATUS FOR TYPEOUT
2049 030430 013737 001352 001140 MOV RMER11,$GDDAT ;EXPECTED STATUS
2050 030436 052737 000200 001140 BIS #HCE,$GDDAT
2051 030444 012737 000001 001174 MOV #1,$TMPO ;GET HEADER WORD NUMBER
2052 030452 013737 030520 001176 MOV 23$,$TMP1 ;GET FAILING BIT POSITION
2053 030460 104344 EMT 34;
2054 030462 000415 BR 22$
2055 030464 20$:
2056
2057 ;CHECK FOR OTHER ERRORS
2058 030464 004737 037620 JSR PC,SECERR ;GO CHECK FOR SECONDARY ERRORS
030470 000405 BR 21$ ;GO TO 21$ IF NO ERROR
030472 000240 NOP ;RETURN HERE IF ERROR
030474 104000 EMT ;ERROR # DEFINED BY SECERR SUBROUTINE
030476 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
030500 000137 030516 JMP 22$ ;GO TO 22$ IF ERROR
2059 030504 21$:
2060
2061 ;ADVANCE THE BIT POSITION AND FORMAT AGAIN IF NOT DONE
2062 030504 006337 030520 ASL 23$ ;SHIFT TO NEXT BIT POSITION
2063 030510 001404 BEQ 24$ ;EXIT IF DONE
2064 030512 000137 027556 JMP 1$ ;GO DO NEXT SECTOR
2065
2066 030516 000465 22$: BR 27$ ;JUMP TO NEXT TEST
2067 030520 000000 23$: .WORD 0 ;STORAGE FOR BIT POSITION
2068
2069
2070 ;*****
2071 ;*REFORMAT SECTOR THAT WAS WRITTEN WITH BAD HEADER
2072 ;*****
2072 030522 24$:
2073 030522 012737 010000 001444 MOV #FMT16,RMOFO ;16 BIT MODE
2074 030530 012737 177776 001414 MOV #-2,RMWCO ;ONLY TWO HEADER WORDS
2075 030536 012737 101360 001416 MOV #BUFONE,RMBAO ;SELECT THE BUFFER
2076 030544 012737 000062 001412 MOV #WH,RMCS10 ;WRITE HEAD AND DATA COMMAND
2077 030552 004737 035104 JSR PC,GENBUF ;GENERATE THE BUFFER PATTERN
2078
2079 030556 004737 032176 JSR PC,TSTPRP ;PREPARE DEVICE FOR TEST
030562 154130 .WORD 154130 ;TASK DESCRIPTOR AS FOLLOWS:
;SELECT DEVICE & VERIFY DEVICE AVAILABLE
;CLEAR CONTROLLER & SELECT DEVICE
;VERIFY CONTROLLER CLEAR OPERATION
;PACK ACKNOWLEDGE IF VOLUME NOT VALID
;VERIFY PACK ACKNOWLEDGE
;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
;VERIFY RECALIBRATION
030564 000404 BR 25$ ;GO TO 25$ IF NO ERROR
030566 000240 NOP ;RETURN HERE IF ERROR
030570 104000 EMT ;ERROR # DEFINED BY TSTPRP SUBROUTINE
030572 000137 030576 JMP 25$ ;GO TO 25$ IF ERROR
2080 030576 25$:
2081 030576 012737 000063 001412 MOV #WH!GO,RMCS10 ;SET THE GO BIT
2082 030604 012702 001553 MOV #PUTINX,R2 ;PUT THE REGISTER ADDRESS INTO TABLE
2083 030610 112722 000006 MOVB #RMDA,(R2)+
    
```



```

                                ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
                                ;VERIFY PACK ACKNOWLEDGE
                                ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
                                ;VERIFY RECALIBRATION
                                ;GO TO 4$ IF NO ERROR
                                ;RETURN HERE IF ERROR
                                ;ERROR # DEFINED BY TSTPRP SUBROUTINE
                                ;GO TO 23$ IF ERROR
031040 000404                BR      4$
031042 000240                NOP
031044 104000                EMT
031046 000137 031666        JMP      23$

2119
2120                ;COMPLEMENT DATA BIT IN SECOND HEADER WORD
2121 031052        4$:
2122 031052 033737 031514 101362    BIT      19$,BUFONE+2    ;IS BIT IN HEADER ON??
2123 031060 001404                BEQ      5$                ;NO!!
2124 031062 043737 031514 101362    BIC      19$,BUFONE+2    ;RESET BIT IN HEADER
2125 031070 000403                BR      6$
2126 031072 053737 031514 101362    5$:    BIS      19$,BUFONE+2    ;SET BIT IN HEADER
2127
2128                ;SETUP AND EXECUTE WRITE HEADER AND DATA COMMAND
2129 031100        6$:
2130 031100 012737 0C0063 001412    MOV      #WH!GO, RMCS10    ;WRITE HEADER AND DATA
2131 031106 012702 001553                MOV      #PUTINX, R2        ;WRITE REGISTER INDEX TABLE
2132 031112 112722 000006                MOVB     #RMDA, (R2)+
2133 031116 112722 000034                MOVB     #RMDC, (R2)+
2134 031122 112722 000032                MOVB     #RMOF, (R2)+
2135 031126 112722 000002                MOVB     #RMWC, (R2)+
2136 031132 112722 000004                MOVB     #RMBA, (R2)+
2137 031136 112722 000000                MOVB     #RMCS1, (R2)+
2138 031142 112722 000200                MOVB     #200, (R2)+
2139
2140 031146 004737 036240                JSR      PC, PUT            ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
                                BR      7$                ;GO TO 7$ IF NO ERROR
                                NOP                    ;RETURN HERE IF ERROR
                                EMT                    ;ERROR # DEFINED BY PUT SUBROUTINE
                                JMP      18$           ;GO TO 18$ IF ERROR
031152 000404
031154 000240
031156 104000
031160 000137 031512
2141 031164        7$:
2142
2143                ;SETUP INPUT REGISTER BUFFER FOR READING STATUS
2144 031164 004737 035704                JSR      PC, GETSTS
2145 031170 004737 036602                JSR      PC, TIMEOUT        ;WAIT FOR COMMAND TO COMPLETE
2146
2147 031174 004737 035770                JSR      PC, GET            ;GO READ REGISTER(S) WITH GET SUBROUTINE
                                BR      8$                ;GO TO 8$ IF NO ERROR
                                NOP                    ;RETURN HERE IF ERROR
                                EMT                    ;ERROR # DEFINED BY GET SUBROUTINE
                                JMP      18$           ;GO TO 18$ IF ERROR
031200 000404
031202 000240
031204 104000
031206 000137 031512
2148 031212        8$:
2149
2150                ;VERIFY RESULTS OF WRITE COMMAND
2151 031212 004737 036766                JSR      PC, PRIERR        ;GO CHECK FOR PRIMARY ERRORS
                                BR      9$                ;GO TO 9$ IF NO ERROR
                                NOP                    ;RETURN HERE IF ERROR
                                EMT                    ;ERROR # DEFINED BY PRIERR SUBROUTINE
                                JSR      PC, @(SP)+        ;GO BACK FOR MORE ERROR CHECKS
                                JMP      18$           ;GO TO 18$ IF ERROR
031216 000405
031220 000240
031222 104000
031224 004736
031226 000137 031512
2152 031232        9$:
2153 031232 004737 051502                JSR      PC, DTASTS        ;GO VERIFY RESULTS OF DATA TRANSFER
                                BR      10$           ;GO TO 10$ IF NO ERROR
031236 000405
    
```



```

2184 031440 012737 000002 001174      MOV      #2,$TMP0      ;GET HEADER WORD NUMBER
2185 031446 013737 031514 001176      MOV      19$,$TMP1    ;GET FAILING BIT POSITION
2186 031454 104344                      EMT      344
2187 031456 000415                      BR       18$
2188 031460
2189
2190
2191 031460 004737 037620      ;CHECK FOR OTHER ERRORS
      031464 000405      JSR      PC,SECERR    ;GO CHECK FOR SECONDARY ERRORS
      031466 000240      BR       17$         ;GO TO 17$ IF NO ERROR
      031470 104000      NOP                      ;RETURN HERE IF ERROR
      031472 004736      EMT                      ;ERROR # DEFINED BY SECERR SUBROUTINE
      031474 000137 031512 JSR      PC,@(SP)+    ;GO BACK FOR MORE ERROR CHECKS
2192 031500      JMP      18$         ;GO TO 18$ IF ERROR
2193
2194
2195 031500 006337 031514      ;ADVANCE THE BIT POSITION AND FORMAT NEXT SECTOR IF NOT DONE
      031504 001404      ASL      19$         ;SHIFT TO NEXT BIT POSITION
2196 031504 000137 030726      BEQ      20$         ;EXIT IF DONE
2197 031506 000137 030726      JMP      1$         ;GO DO NEXT SECTOR
2198
2199 031512 000465      18$: BR       23$         ;JUMP OVER STORAGE
2200 031514 000000      19$: .WORD 0         ;STORAGE FOR BIT POSITION
2201
2202
2203
2204
2205 031516
2206 031516 012737 010000 001444      ;*****
2207 031524 012737 177776 001414      ;*REFORMAT SECTOR THAT WAS WRITTEN WITH BAD HEADER
2208 031532 012737 101360 001416      ;*****
2209 031540 012737 000062 001412      20$:
2210 031546 004737 035104      MOV      #FMT16,RMOFO ;16 BIT MODE
2211
2212 031552 004737 032176      MOV      #-2,RMWCO    ;2 HEADER WORDS ONLY
      031556 154130      MOV      #BUFONE,RMBAO ;BUFFER ADDRESS
      JSR      PC,GENBUF ;WRITE HEAD AND DATA COMMAND
      JSR      PC,TSTPRP ;SET UP THE BUFFER
      .WORD 154130      ;PREPARE DEVICE FOR TEST
      ;TASK DESCRIPTOR AS FOLLOWS:
      ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
      ;CLEAR CONTROLLER & SELECT DEVICE
      ;VERIFY CONTROLLER CLEAR OPERATION
      ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
      ;VERIFY PACK ACKNOWLEDGE
      ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
      ;VERIFY RECALIBRATION
      BR       21$         ;GO TO 21$ IF NO ERROR
      NOP                      ;RETURN HERE IF ERROR
      EMT                      ;ERROR # DEFINED BY TSTPRP SUBROUTINE
      JMP      21$         ;GO TO 21$ IF ERROR
2213 031572
2214 031572 012737 000063 001412      21$:
2215 031600 012702 001553      MOV      #WH!GO,RMCS10 ;SET GO BIT
2216 031604 112722 000006      MOV      #PUTINX,R2   ;TABLE ADDRESS
2217 031610 112722 000034      MOVB    #RMDA,(R2)+
2218 031614 112722 000032      MOVB    #RMDC,(R2)+
2219 031620 112722 000004      MOVB    #RMOF,(R2)+
2220 031624 112722 000002      MOVB    #RMBA,(R2)+
2221 031630 112722 000000      MOVB    #RMWC,(R2)+
2222 031634 112722 000200      MOVB    #RMCS1,(R2)+
2223 031640 004737 036240      MOVB    #200,(R2)+   ;TERMINATOR
      JSR      PC,PUT     ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
    
```


	031644	000404		BR	22\$:GO TO 22\$ IF NO ERROR
	031646	000240		NOP			:RETURN HERE IF ERROR
	031650	104000		EMT			:ERROR # DEFINED BY PUT SUBROUTINE
	031652	000137	031666	JMP	23\$:GO TO 23\$ IF ERROR
2224	031656					22\$:	
2225	031656	000240		NOP			
2226	031660	004737	036602	JSR	PC, TIMEOUT		:WAIT FOR TIME OUT
2227	031664	000240		NOP			
2228	031666					23\$:	

032106	104401	001217		\$GT42P: TYPE	,\$SCLF	::TYPE CARRIAGE RETURN, LINE FEED
032112	013700	000042		\$GET42: MOV	@#42,RO	::GET MONITOR ADDRESS
032116	001405			BEG	\$DOAGN	::BRANCH IF NO MONITOR
032120	000005			RESET		::CLEAR THE WORLD
032122	004710			\$ENDAD: JSR	PC,(R0)	::GO TO MONITOR
032124	000240			NOP		::SAVE ROOM
032126	000240			NOP		::FOR
032130	000240			NOP		::ACT11
032132				\$DOAGN:		
032132	000137			JMP	@(PC)+	::RETURN
032134	032142			\$RTNAD: .WORD	SHUT	
032136	377	377	000	\$ENULL: .BYTE	-1,-1,0	::NULL CHARACTER STRING
				.EVEN		
21						
22	032142	005737	001326	SHUT:	TST	CTLFG
23	032146	001002			BNE	1\$
24	032150	000137	007670		JMP	READY
25	032154	005737	000042	1\$:	TST	@#42
26	032160	001002			BNE	2\$
27	032162	000137	005432		JMP	START
28	032166	005037	001300	2\$:	CLR	\$DEVN
29	032172	000137	031724		JMP	\$EOP
						:WAS CONTROL C FLAGGED ?
						:BR IF YES
						:CONTINUE
						:ANY MONITOR PRESENT ?
						:BR IF YES
						:GO TO START
						:FUDGE NO DRIVES IN MAP
						:RETURN TO \$EOP

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57

.SBTTL TEST PREPARATION MODULE

: THIS MODULE PREPARES THE SUBSYSTEM FOR THE EXECUTION OF A TEST,
: REPORTING AN ERROR TO THE USER IF AN ERROR IS DETECTED. THE USER
: SPECIFIES TASKS TO BE PERFORMED, WHICH THE MODULE EXECUTES
: USING SUBROUTINES..

:CALL:

```

JSR    PC,TSTPRP          TASK/VERIFY DESCRIPTOR
.WORD  NN'NNN             RETURN HERE IF NO ERROR
BR     ??                 RETURN HERE IF ERROR
NOP
ERROR  ERROR DEFINED BY MODULE
    
```

:TASK/VERIFY DESCRIPTOR

```

BIT 15 = 1  SELECT DEVICE AND VERIFY DEVICE IS AVAILABLE
-----
BIT 14 = 1  CLEAR CONTROLLER AND SELECT DEVICE
BIT 13      (RESERVED FOR DRIVE CLEAR)
BIT 12 = 1  PACK ACKNOWLEDGE IF VOLUME NOT VALID
-----
BIT 11 = 1  RECALIBRATE IF POSITIONING IN PROGRESS OR SKI ERROR
BIT 10 = 1  RECALIBRATE DRIVE
BIT 9
-----
BIT 8
BIT 7
BIT 6 = 1  VERIFY CONTROLLER CLEAR OPERATION
-----
BIT 5      (RESERVED FOR DRIVE CLEAR)
BIT 4 = 1  VERIFY PACK ACKNOWLEDGE
BIT 3 = 1  VERIFY RECALIBRATION
-----
BIT 2
BIT 1
BIT 0
    
```

TSTPRP:

:STORE TASK DESCRIPTOR AND CLEAR USER'S ERROR CALL

```

MOV    @ (SP),39$        ;STORE DESCRIPTOR
ADD    #6,(SP)           ;MOVE SP TO USERS ERROR CALL
CLRB   @ (SP)            ;CLEAR ERROR CALL
SUB    #4,(SP)           ;MOVE SP TO NO ERROR RETURN

JSR    PC,GETSTS         ;SETUP TO READ ALL REGISTERS
JSR    PC,GET            ;GET RMER2
BR     2$                ;BR IF NO ERROR DETECTED
BR     1$                ;GET OVER ERROR NUMBER
.WORD  0                 ;ERROR DEFINED BY GET SUBROUTINE
1$:    ADD    #4,(SP)     ;XFER ERROR TO USER AND
MOV    1$-2,@ (SP)      ;GET ERROR NUMBER.
JMP    37$

2$:    MOV    RMER2I,40$ ;GET RMER2 AND SAVE FOR LATER
    
```

032176

033146

000000

033150

::*****


```

58                                     ;SELECT DEVICE AND VERIFY DEVICE AVAILABLE IF BIT 15 SET IN TASK
59 032262 005737 033146                TST      39$      ;SELECT DEVICE??
60 032266 100014                BPL      4$      ;NO!!
61
62 032270 004737 043672                JSR      PC,DEVSEL ;GO SELECT DEVICE
63 032274 000411                BR       4$      ;NO ERROR - CONTINUE
64 032276 000401                BR       3$      ;
65 032300 000000                .WORD   0        ;ERROR NUMBER FROM DEVSEL
66 032302 062716 000004 3$:      ADD      #4,(SP)  ;TRANSFER ERROR TO USER
67 032306 113776 032300 000000    MOVB    3$-2,@(SP)
68 032314 000137 033136                JMP      37$
69
70                                     ;*****
71                                     ;CLEAR CONTROLLER IF BIT 14 IS SET IN TASK
72 032320                                4$:
73 032320 032737 040000 033146        BIT      #BIT14,39$ ;CLEAR CONTROLLER??
74 032326 001451                BEQ      13$      ;NO!!
75
76 032330 004737 045344                JSR      PC,CNTCLR ;GO CLEAR CONTROLLER
77 032334 000411                BR       7$      ;CONTINUE - NO ERROR
78 032336 000401                BR       6$      ;
79 032340 000000                .WORD   0        ;ERROR NUMBER FROM CNTCLR
80 032342 062716 000004 5$:      ADD      #4,(SP)  ;TRANSFER ERROR TO USER
81 032346 113776 032340 000000    MOVB    5$,@(SP)
82 032354 000137 033136                JMP      37$
83
84                                     ;*****
85                                     ;VERIFY CONTROLLER CLEAR IF BIT6 SET IN TASK
86 032360                                7$:
87 032360 032737 000100 033146        BIT      #BIT6,39$ ;VERIFY??
88 032366 001431                BEQ      13$      ;NO!!
89
90 032370 004737 035770                JSR      PC,GET   ;GO GET STATUS
91 032374 000411                BR       10$     ;NO ERROR GETTING STATUS
92 032376 000401                BR       9$      ;
93 032400 000000                .WORD   0        ;ERROR FROM GETTING STATUS
94 032402 062716 000004 8$:      ADD      #4,(SP)  ;TRANSFER ERROR TO USER
95 032406 113776 032400 000000    MOVB    8$,@(SP)
96 032414 000137 033136                JMP      37$
97
98 032420 004737 045462 10$:      JSR      PC,CLRSTS ;GO VERIFY STATUS CLEAR
99 032424 000412                BR       13$     ;NO ERROR IN CLEAR
100 032426 000401                BR       12$     ;
101 032430 000000                .WORD   0        ;ERROR IN STATUS CLEAR
102 032432 005726 12$:      TST      (SP)+   ;STRIP RETURN ADDRESS TO
103 032434 062716 000004                ADD      #4,(SP) ;SUBROUTINE AND TRANSFER
104 032440 113776 032430 000000    MOVB    11$,@(SP) ;ERROR TO USER
105 032446 000137 033136                JMP      37$
106
107                                     ;*****
108                                     ;EXECUTE PACK ACKNOWLEDGE IF BIT12 SET IN TASK AND VOLUME IS
109                                     ;NOT VALID
110 032452                                13$:
111 032452 032737 010000 033146        BIT      #BIT12,39$ ;PACK ACKNOWLEDGE??
112 032460 001501                BEQ      25$      ;NO!!
113
114 032462 004737 035770                JSR      PC,GET

```

```

115 032466 000411 BR 16$ :NO ERROR GETTING RMDS
116 032470 000401 BR 15$
117 032472 000000 14$: .WORD 0
118 032474 062716 000004 15$: ADD #4,(SP) :TRANSFER ERROR TO USER
119 032500 113776 032472 000000 MOVB 14$,a(SP)
120 032506 000137 033136 JMP 37$
121
122 032512 032737 000100 001350 16$: BIT #VV,RMDSI :IS VOLUME VALID??
123 032520 001061 BNE 25$ :YES!!
124
125 032522 012737 000023 001412 MOV #PAKACK!GO,RMCS10 :LOAD PACK ACK COMMAND
126 032530 112737 000000 001553 MOVB #RMCS1,PUTINX :SETUP REGISTER INDEX TABLE
127 032536 112737 000200 001554 MOVB #200,PUTINX+1
128 032544 004737 036240 JSR PC,PUT :GO WRITE COMMAND
129 032550 000410 BR 19$ :NO ERROR LOADING REGISTER
130 032552 000401 BR 18$
131 032554 000000 17$: .WORD 0 :ERROR FROM PUT SUB
132 032556 062716 000004 18$: ADD #4,(SP) :TRANSFER ERROR TO USER
133 032562 113776 032554 000000 MOVB 17$,a(SP)
134 032570 000562 BR 37$
135
136 032572 004737 036602 19$: JSR PC,TIMOUT :WAIT FOR COMMAND TO COMPLETE
137
138 :*****
139 :VERIFY PACK ACKNOWLEDGE IF #BIT4 SET IN TASK
140 032576 032737 000020 033146 BIT #BIT4,39$ :VERIFY PACK ACKNOWLEDGE??
141 032604 001427 BEQ 25$ :NO!!
142
143 032606 004737 035770 JSR PC,GET :GO GET STATUS
144 032612 000410 BR 22$ :NO ERROR GETTING STATUS
145 032614 000401 BR 21$
146 032616 000000 20$: .WORD 0 :ERROR FROM GET SUB
147 032620 062716 000004 21$: ADD #4,(SP) :TRANSFER ERROR TO USER
148 032624 113776 032616 000000 MOVB 20$,a(SP)
149 032632 000541 BR 37$
150
151 032634 004737 046342 22$: JSR PC,ACKSTS :GO CHECK ACKNOWLEDGE
152 032640 000411 BR 25$ :NO ERROR
153 032642 000401 BR 24$
154 032644 000000 23$: .WORD 0 :PACK ACKNOWLEDGE ERROR
155 032646 005726 24$: TST (SP)+ :STRIP RETURN TO SUB AND
156 032650 062716 000004 ADD #4,(SP) :TRANSFER ERROR TO USER
157 032654 113776 032644 000000 MOVB 23$,a(SP)
158 032662 000525 BR 37$
159
160 :*****
161 :RECALIBRATE DRIVE IF BIT 11 IS SET IN TASK AND 'SKI' IS SET
162 :OR 'PIP' IS ACTIVE.
163 :RECALIBRATE DRIVE IF BIT 10 IS SET
164 032664 25$:
165 032664 032737 002000 033146 BIT #BIT10,39$ :RECALIBRATE DRIVE ?
166 032672 001027 BNE 29$ :YES!!
167 032674 032737 004000 033146 BIT #BIT11,39$ :RECALIBRATE??
168 032702 001517 BEQ 38$ :NO!!
169
170 032704 004737 035770 JSR PC,GET :GO GET RMDS
171 032710 000410 BR 28$ :NO ERROR GETTING RMDS

```



```

172 032712 000401          BR      27$
173 032714 000000          .WORD  0          ;ERROR FROM GET SUB
174 032716 062716 000004 26$:   ADD    #4,(SP)   ;TRANSFER ERROR TO USER
175 032722 113776 032714 000000 27$:   MOVB   26$,@ (SP)
176 032730 000502          BR      37$
177
178 032732 032737 040000 033150 28$:   BIT    #SKI,40$   ;WAS SKI SET ?
179 032740 001004          BNE    29$        ;YES, GO RECALIBRATE
180 032742 032737 020000 001350      BIT    #PIP,RMDSI ;IS PIP ACTIVE??
181 032750 001474          BEQ    38$        ;NO!!
182
183 032752 005037 001446 29$:   CLR    RMDCO      ;CLEAR CYLINDER ADDRESS
184 032756 005037 001420      CLR    RMDAO      ;CLEAR TRACK/SECTOR ADDRESS
185 032762 012737 000007 001412      MOV    #RECAL!GO,RMCS10 ;LOAD RECALIBRATE COMMAND
186 032770 112737 000034 001553      MOVB   #RMDC,PUTINX ;MAKE CYLINDER ADDRESS AND
187 032776 112737 000006 001554      MOVB   #RMDA,PUTINX+1 ;TRK/SEC ADDRESS LOOK LIKE SEEK TO ZERO
188 033004 112737 000000 001555      MOVB   #RMCS1,PUTINX+2 ;AND REGISTER INDEX
189 033012 112737 000200 001556      MOVB   #200,PUTINX+3 ;SET TERMINATOR
190 033020 004737 036240      JSR    PC,PUT     ;GO ISSUE RECALIBRATE
191 033024 000410          BR     31$        ;NO ERROR
192 033026 000401          BR     30$
193 033030 000000          .WORD  0          ;ERROR IN REGISTER TRANSFER
194 033032 062716 000004 30$:   ADD    #4,(SP)   ;TRANSFER ERROR TO USER
195 033036 113776 033030 000000      MOVB   30$-2,@ (SP)
196 033044 000434          BR     37$
197
198 033046 004737 036602 31$:   JSR    PC,TIMOUT ;WAIT FOR COMPLETION
199
200
201
202 033052 032737 000010 033146 32$:   BIT    #BIT3,39$ ;VERIFY RECALIBRATE IF BIT 3 SET IN TASK
203 033060 001430          BEQ    38$        ;VERIFY RECALIBRATE??
204
205 033062 004737 035770          JSR    PC,GET     ;GO GET STATUS
206 033066 000410          BR     34$        ;NO ERROR GETTING STATUS
207 033070 000401          BR     33$
208 033072 000000          .WORD  0          ;ERROR FROM GET
209 033074 062716 000004 33$:   ADD    #4,(SP)   ;TRANSFER ERROR TO USER
210 033100 113776 033072 000000      MOVB   32$,@ (SP)
211 033106 000413          BR     37$
212
213 033110 004737 047136 34$:   JSR    PC,RCLSTS ;GO CHECK RECALIBRATE
214 033114 000412          BR     38$        ;NO ERROR DURING RECALIBRATE
215 033116 000401          BR     36$
216 033120 000000          .WORD  0          ;ERROR DURING RECALIBRATE
217 033122 005726 35$:   TST   (SP)+      ;STRIP RETURN TO SUB AND
218 033124 062716 000004 36$:   ADD    #4,(SP)   ;TRANSFER ERROR TO USER
219 033130 113776 033120 000000      MOVB   35$,@ (SP)
220 033136 162716 000002 37$:   SUB    #2,(SP)   ;MOVE SP BACK BEFORE ERROR
221 033142 000240          38$:   NOP
222 033144 000207          RTS    PC        ;RETURN TO USER
223
224 033146 000000          39$:   .WORD  0
225 033150 000000          40$:   .WORD  0          ;TASK/VERIFY DESCRIPTOR
                ;CONTAINS RMER2
    
```

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56

.SBTTL BAD SECTOR MODULE

:THE MODULE IS INTENDED TO BE CALLED PRIOR TO CALLING THE BUFFER
:GENERATOR SUBROUTINE, AND PRESERVES THE 'PUT BUFFER' SO THAT THE
:BUFFER NEED ONLY BE FILLED ONCE FOR THE EXECUTION OF A FORMAT
:OPERATION.

:THE MODULE RETURNS TO THE CALLING TEST WITH THE APPROVED OR ASSIGNED
:SECTOR IN THE PUT BUFFER AND ALSO IN LOCATIONS 'ASNDA' AND 'ASNDC'
:SO THAT A REFERENCE IS AVAILABLE TO THE TEST OUTSIDE OF THE PUT BUFFER.

:THE BAD SECTOR MODULE PERFORMS TWO MAJOR FUNCTIONS:

- : (1) RECOVER THE BAD SECTOR FILES AND
- : (2) APPROVE THE USAGE OF A SECTOR BASED ON INFORMATION IN
: THE BAD SECTOR FILES OR ASSIGN A NEW SECTOR IF THE ONE
: ELECTED IS NOT AVAILABLE FOR USE.

:INFORMATION REQUIRED BY THE MODULE INCLUDES:

- : (1) .RMDCO - THE DESIRED CYLINDER,
- : (2) .RMDAO - THE TRACK AND SECTOR ADDRESS,
- : (3) .RMWCO - THE WORD COUNT,
- : (4) .RMCS10 - THE COMMAND,
- : (5) .RMOFO - THE FORMAT MODE

:CALL:

```

JSR    PC,BADSCT    ;CALL SUBROUTINE
BR     ???          ;RETURN HERE IF NO ERROR
TYPE   ,MESSAGE     ;RETURN HERE IF THE BAD SECTOR FILE
                        ;CANNOT BE RECOVERED.
ERROR  N            ;THE EMT OFFSET NUMBER 'N' IS DEFINED
                        ;BY BAD SECTOR MODULE.
    
```

BADSCT:

```

ADD    #6,(SP)      ;CLEAR ERROR NUMBER IN USER'S
CLRB   @2(SP)       ;ERROR CALL.
SUB    #6,(SP)
    
```

:TEST 'MEDIA ENABLE' TO DETERMINE WHETHER OR NOT THE BAD SECTOR FILES
:HAVE BEEN RECOVERED.

```

TST    MEDENB      ;HAS BAD SECTOR FILES BEEN RECOVERED ?
BEQ    1$          ;BR IF NO
JMP    54$         ;YES, BAD SECTOR FILE IS AVAILABLE
    
```

:RECOVER THE MANUFACTURES / USERS BAD SECTOR FILE FROM CYLINDER = 822.
:TRACK = LAST TRACK (RM02/3 = 4 AND RM05 = 18.). ALSO, SAVE THE USER'S
:PUT BUFFER

```

1$:
MOV    R0,-(SP)    ;;PUSH R0 ON STACK
CLR    R0          ;START WITH RMCS1
2$:
MOV    PUTBUF(R0),BUFFER(R0)
ADD    #2,R0       ;ADVANCE TO NEXT BUFFER POSITION
CMP    #46,R0      ;END OF BUFFER
BHS    2$          ;NO !!
    
```

:SET RETRY COUNT AND LOAD PUT BUFFER AND REGISTER INDEX TABLE

:SETUP PARAMETERS TO READ SKIP SECTOR FILE FIRST (3 SECTORS)

```

MOV    #3,68$     ;RETRY COUNT
    
```

```

33 033152
34 033152 062716 000006
35 033156 105076 000000
36 033162 162716 000006
37
38
39
40 033166 005737 001512
41 033172 001402
42 033174 000137 034452
43
44
45
46
47 033200
   033200 010046
48 033202 005000
49 033204 016060 001412 101360
50 033212 062700 000002
51 033216 022700 000046
52 033222 103370
53
54
55
56 033224 012737 000003 035070
    
```



```

57 033232 012737 001466 001446      MOV      #822.,RMDCO      ;DESIRED CYLINDER = 822.
58 033240 013737 001334 001420      MOV      LSTRK,RMDAO     ;STARTING LAST TRACK, SECTOR = 0
59 033246 012737 177376 001414      MOV      #-258.,RMWCO   ;2 + 256. WORDS (2'S COMP)
60 033254 012737 010000 001444      MOV      #FMT16,RMOFO   ;16 BIT FORMAT
61 033262 012737 103370 001416      MOV      #MFGFIL,RMBAO  ;POINT TO MANUFACTURES FILE BUFFER
62
63 033270 012700 001553                MOV      #PUTINX,RO     ;RO POINTS TO REGISTER INDEX TABLE
64 033274 112720 000006      MOVVB   #RMDA,(RO)+
65 033300 112720 000034      MOVVB   #RMDC,(RO)+
66 033304 112720 000002      MOVVB   #RMWC,(RO)+
67 033310 112720 000032      MOVVB   #RMOF,(RO)+
68 033314 112720 000004      MOVVB   #RMBA,(RO)+
69 033320 112720 000000      MOVVB   #RMCS1,(RO)+
70 033324 112720 000200      MOVVB   #200,(RO)+
71 033330 012600                MOV      (SP)+,RO      ;;POP STACK INTO RO
72
73                                ;SET GET INDEX TABLE FOR READING STATUS
74 033332                3$:
75 033332 004737 035704      JSR      PC,GETSTS     ;SETUP GET INDEX REGISTER FOR STATUS
76 033336 004737 035770      JSR      PC,GET       ;GET REGISTERS
77 033342 000411                BR      5$            ;BR IF NO ERROR
78 033344 000401                BR      4$            ;JUMP OVER ERROR NUMBER
79 033346 000000                .WORD   0            ;ERROR DEFINED BY GET SUB
80 033350 062716 000006      4$:      ADD      #6,(SP)     ;XFER ERROR TO USER AND
81 033354 113776 033346 000000      MOVVB   4$-2,@(SP)   ;GET ERROR NUMBER.
82 033362 000137 034156      JMP      42$
83
84 033366 013737 001400 035102 5$:      MOV      RMER2I,73$   ;GET RMER2 AND SAVE FOR LATER
85
86                                ;CLEAR THE DEVICE USING DRIVE CLEAR COMMAND
87 033374 012737 000011 001412      MOV      #DRVCLR!GO,RMCS10 ;LOAD COMMAND IN PUT BUFFER
88 033402 004737 036240      JSR      PC,PUT       ;OUTPUT COMMAND
89 033406 000411                BR      8$            ;RETURN HERE IF NO ERROR
90 033410 000401                BR      7$            ;GET AROUND ERROR #
91 033412 000000                .WORD   0            ;ERROR # GOES HERE
92 033414 062716 000006      6$:      .WORD   0
93 033420 113776 033412 000000      7$:      ADD      #6,(SP)     ;MOVE SP TO USERS ERROR CALL
94 033426 000137 034156      MOVVB   6$,@(SP)    ;MOVE ERROR NUMBER TO USER
95                                JMP      42$
96 033432 004737 036602      8$:      JSR      PC,TIMOUT   ;WAIT FOR COMPLETION
97 033436 004737 035770      JSR      PC,GET       ;GO GET STATUS
98 033442 000411                BR      11$           ;RETURN HERE IF NO ERROR
99 033444 000401                BR      10$           ;GET AROUND ERROR #
100 033446 000000                .WORD   0            ;ERROR # GOES HERE
101 033450 062716 000006      9$:      .WORD   0
102 033454 113776 033446 000000      10$:     ADD      #6,(SP)     ;MOVE SP TO USERS ERROR CALL
103 033462 000137 034156      MOVVB   9$,@(SP)   ;MOVE ERROR # TO USERS ERROR CALL
104                                JMP      42$
105 033466 004737 050700      11$:     JSR      PC,DRVSTS   ;GO VERIFY DRIVE CLEAR COMMAND
106 033472 000412                BR      14$           ;RETURN HERE IF NO ERROR
107 033474 000401                BR      13$           ;GET AROUND ERROR
108 033476 000000                .WORD   0            ;ERROR # GOES HERE
109 033500 005726                12$:     .WORD   0
110 033502 062716 000006      13$:     TST      (SP)+      ;STRIP RETURN TO SUBROUTINE
111 033506 113776 033476 000000      ADD      #6,(SP)     ;MOVE SP TO USERS ERROR CALL
112 033514 000137 034156      MOVVB   12$,@(SP)  ;MOVE ERROR # TO USER CALL
113                                JMP      42$

```

BAD SECTOR MODULE

```

114
115 033520
116 033520 032737 000100 001350
117 033526 001052
118
119 033530 012737 000023 001412
120 033536 004737 036240
121 033542 000411
122 033544 000401
123 033546 000000
124 033550 062716 000006
125 033554 113776 033546 000000
126 033562 000137 034156
127
128 033566 004737 036602
129 033572 004737 035770
130 033576 000411
131 033600 000401
132 033602 000000
133 033604 062716 000006
134 033610 113776 033602 000000
135 033616 000137 034156
136
137 033622 004737 046342
138 033626 000412
139 033630 000401
140 033632 000000
141 033634 005726
142 033636 062716 000006
143 033642 113776 033632 000000
144 033650 000137 034156
145
146
147 033654
148 033654 032737 040000 035102
149 033662 001004
150 033664 032737 020000 001350
151 033672 001452
152
153 033674 012737 000007 001412
154 033702 004737 036240
155 033706 000411
156 033710 000401
157 033712 000000
158 033714 062716 000006
159 033720 113776 033712 000000
160 033726 000137 034156
161
162 033732 004737 036602
163 033736 004737 035770
164 033742 000411
165 033744 000401
166 033746 000000
167 033750 062716 000006
168 033754 113776 033746 000000
169 033762 000137 034156
170

```

:ISSUE A PACK ACKNOWLEDGE IF VOLUME VALID IS RESET
14\$: BIT #VV,RMDSI :IS VV RESET ??
BNE 23\$:NO !!
MOV #PACK!GO,RMCS10 :LOAD COMMAND
JSR PC,PUT :GO PUT COMMAND TO DRIVE
BR 17\$:RETURN HERE IF NO OUTPUT ERROR
BR 16\$:GET AROUND ERROR #
15\$: .WORD 0 :ERROR # GOES HERE
16\$: ADD #6,(SP) :MOVE SP TO USERS ERROR CALL
MOVB 15\$,@ (SP) :MOVE ERROR # TO ERROR CALL
JMP 42\$
17\$: JSR PC,TIMOUT :WAIT FOR COMPLETION
JSR PC,GET :GO GET STATUS FOR PACK ACK
BR 20\$:RETURN HERE IF NO ERROR
BR 19\$:GET AROUND ERROR #
18\$: .WORD 0 :ERROR # GOES HERE
19\$: ADD #6,(SP) :MOVE SP TO USERS ERROR CALL
MOVB 18\$,@ (SP) :MOVE ERROR # TO CALL
JMP 42\$
20\$: JSR PC,ACKSTS :GO VERIFY ACKNOWLEDGE STATUS
BR 23\$:RETURN HERE IF NO ERROR
BR 22\$:GET AROUND ERROR #
21\$: .WORD 0 :ERROR # GOES HERE
22\$: TST (SP)+ :STRIP RETURN TO SUBROUTINE
ADD #6,(SP) :MOVE SP TO USERS ERROR CALL
MOVB 21\$,@ (SP) :MOVE ERROR # TO USERS ERROR CALL
JMP 42\$
:RECALIBRATE THE DRIVE IF 'SKI' OR 'PIP' IS SET
23\$: BIT #SKI,73\$:WAS SKI SET ?
BNE 24\$:YES, GO RECALIBRATE
BIT #PIP,RMDSI :IS PIP SET ??
BEQ 32\$:NO !!
24\$: MOV #RECAL!GO,RMCS10 :LOAD RECALIBRATE COMMAND
JSR PC,PUT :PUT THE RECAL COMMAND
BR 26\$:RETURN HERE IF NO ERROR
BR 25\$:GET AROUND ERROR #
25\$: .WORD 0 :ERROR # GOES HERE
25\$: ADD #6,(SP) :MOVE SP TO USERS ERROR CALL
MOVB 25\$-2,@ (SP) :MOVE ERROR # TO USERS CALL
JMP 42\$
26\$: JSR PC,TIMOUT :WAIT FOR RECALIBRATE TO COMPLETE
JSR PC,GET :GO GET RECAL STATUS
BR 29\$:RETURN HERE IF NO ERROR
BR 28\$:GET AROUND ERROR #
27\$: .WORD 0 :ERROR # GOES HERE
28\$: ADD #6,(SP) :MOVE SP TO USERS ERROR CALL
MOVB 27\$,@ (SP) :MOVE ERROR TO USERS CALL
JMP 42\$


```

171 033766 004737 047136      29$: JSR PC,RCLSTS      ;GO VERIFY RECALIBRATE STATUS
172 033772 000412              BR 32$              ;RETURN HERE IF NO ERROR
173 033774 000401              BR 31$              ;GET AROUND ERROR #
174 033776 000000              .WORD 0              ;ERROR # GOES HERE
175 034000 005726              30$: TST (SP)+        ;STRIP RETURN TO SUBROUTINE
176 034002 062716 000006      31$: ADD #6,(SP)         ;MOVE SP TO USERS ERROR CALL
177 034006 113776 033776 000000 MOVB 30$,a(SP)       ;MOVE ERROR # TO USERS CALL
178 034014 000137 034156      JMP 42$
179
180                               ;READ THE SECTOR IDENTIFIED BY RMDAO, INCLUDING HEADER AND DATA
181 034020      32$: MOV #RH!GO,RMCS10    ;LOAD READ HEADER AND DATA COMMAND
182 034020 012737 000073 001412 JSR PC,PUT           ;PUT COMMAND
183 034026 004737 036240      BR 35$              ;RETURN HERE IF NO ERROR
184 034032 000411              BR 34$              ;GET AROUND ERROR #
185 034034 000401              .WORD 0              ;ERROR # GOES HERE
186 034036 000000              33$: ADD #6,(SP)         ;MOVE SP TO USERS ERROR CALL
187 034040 062716 000006      34$: MOVB 33$,a(SP)       ;MOVE ERROR # TO USERS ERROR CALL
188 034044 113776 034036 000000 JMP 42$
189 034052 000137 034156
190
191 034056 004737 036602      35$: JSR PC,TIMOUT    ;WAIT FOR READ OPERATION TO COMPLETE
192 034062 004737 035770      JSR PC,GET           ;GO GET STATUS FOR READ OPERATION
193 034066 000411              BR 38$              ;RETURN HERE IF NO ERROR
194 034070 000401              BR 37$              ;GET AROUND ERROR #
195 034072 000000              .WORD 0              ;ERROR # GOES HERE
196 034074 062716 000006      36$: ADD #6,(SP)         ;MOVE SP TO USERS ERROR CALL
197 034100 113776 034072 000000 37$: MOVB 36$,a(SP)       ;MOVE ERROR # TO CALL
198 034106 000137 034156      JMP 42$
199
200 034112 004737 051502      38$: JSR PC,DTASTS    ;GO VERIFY RESULTS OF READ OPERATION
201 034116 000412              BR 41$              ;RETURN HERE IF NO ERROR
202 034120 000401              BR 40$              ;GET AROUND ERROR #
203 034122 000000              .WORD 0              ;ERROR # GOES HERE
204 034124 005726              39$: TST (SP)+        ;STRIP RETURN ADDRESS TO SUBROUTINE
205 034126 062716 000006      40$: ADD #6,(SP)         ;MOVE SP TO USERS ERROR CALL
206 034132 113776 034122 000000 MOVB 39$,a(SP)       ;MOVE ERROR # TO USERS CALL
207 034140 000137 034156      JMP 42$
208
209 034144 032737 040000 001336 41$: BIT #TRE,RMCS1I    ;ANY CONTROLLER ERRORS ?
210 034152 001001              BNE 42$              ;BR IF YES
211 034154 000446              BR 48$              ;NO ERRORS DETECTED
212
213                               ;*****
214                               ;AN ERROR HAS BEEN DETECTED IN TRYING TO READ THE BAD SECTOR FILE.
215                               ;THE SECTOR WILL BE RETRIED IF POSSIBLE.
216
217 034156 005337 035070      42$: DEC 68$           ;YES, DECREMENT RETRY COUNT AND
218 034162 100026              BPL 45$              ;RETRY IF COUNT NOT NEGATIVE.
219
220                               ;THE RETRY COUNT HAS EXPIRED - SEE IF THE ERROR IS MEDIA RELATED
221
222 034164 032737 100720 001352 43$: BIT #DCK!HCRC!HCE!FER!ECH,RMER1I ;ANY MEDIA RELATED ERRORS ?
223 034172 001004              BNE 44$              ;YES, GO TRY NEXT AVAILABLE SECTOR
224
225 034174 032737 100000 001400 BIT #BSE,RMER2I     ;ANY MEDIA RELATED ERRORS ?
226 034202 001422              BEQ 46$              ;NO, EXIT AND REPORT ERROR ON RETURN
227

```

```

228                                     ;THE ERRORS DETECTED WHILE TRYING TO RECOVER THE BAD SECTOR FILE ARE
229                                     ;DUE TO THE MEDIA. SEE IF THE BAD SECTOR FILE CAN BE RECOVERED FROM
230                                     ;ANOTHER AREA ON THE LAST TRACK
231
232 034204 062737 000002 001420 44$:  ADD      #2,RMDAO      ;ADVANCE SECTOR ADDRESS BY 2
233 034212 122737 000012 001420      CMPB     #10.,RMDAO    ;QUIT IF ALL MFG SECTORS HAVE BEEN
234 034220 001413                                BEQ      46$          ;TRIED.
235 034222 122737 000040 001420      CMPB     #32.,RMDAO   ;QUIT IF ALL USER SECTORS HAVE BEEN
236 034230 001407                                BEQ      46$          ;TRIED.
237
238 034232 012737 000003 035070      MOV      #3,68$      ;REINSTATE RETRY COUNT FOR THIS SECTOR
239 034240 162716 000006                                SUB      #6,(SP)     ;MOVE SP BACK TO NO ERROR
240 034244 000137 033332                                JMP      3$          ;RETRY THE READ OPERATION
241
242                                     ;THE BAD SECTOR FILE CANNOT BE READ
243
244 034250 000240                                NOP
245 034252 032777 020000 144674      BIT      #SW13,@SWR  ;INHIBIT MESSAGE ?
246 034260 001002                                BNE     47$          ;YES
247 034262 162716 000004                                SUB      #4,(SP)     ;MOVE SP TO ERROR RETURN
248 034266 000137 035064 47$:  JMP      67$          ;GO TO MODULE EXIT
249
250                                     ;THE SECTOR WAS RECOVERED WITHOUT ERROR - READ THE USER FILE IF
251                                     ;THIS IS THE MGF FILE OR ELSE DONE.
252
253 034272 022737 104376 001416 48$:  CMP      #USRFIL,RMBAO ;WAS THE USER FILE READ ??
254 034300 001446                                BEQ     52$          ;YES - READ IS COMPLETE
255 034302 112737 000012 001420      MOVB    #10.,RMDAO   ;READ THE USER FILE LAST TRACK, SECTOR = 10.
256 034310 012737 104376 001416      MOV     #USRFIL,RMBAO ;POINT TO USERS FILE BUFFER
257
258 034316 012737 000003 035070      MOV     #3,68$      ;RELOAD THE RETRY COUNT FOR THIS SECTOR
259 034324 000137 033332                                JMP     3$          ;GO READ THE USER FILE
260
261                                     ;DUMMY THE BAD SECTOR FILES
262 034330 49$:  MOV      R0,-(SP)      ;;PUSH R0 ON STACK
263 034330 010046                                MOV     R1,-(SP)    ;;PUSH R1 ON STACK
264 034332 010146                                MOV     #252.,R1    ;R1 = NUMBER OF ENTRIES IN FILES
265 034334 012701 000374                                MOV     #14.,R0     ;R0 = ADDRESS INDEX TO FILE STORAGE
266 034340 012700 000014                                MOV     #-1,MFGFIL(R0) ;ENTER ALL ONES IN MFG FILE
267 034344 012760 177777 103370 50$:  MOV     #-1,USRFIL(R0) ;ENTER ALL ONES IN USER FILE
268 034352 012760 177777 104376      TST     (R0)+        ;ADVANCE ADDRESS
269 034360 005720                                DEC     R1           ;DECREMENT COUNT
270 034362 005301                                BNE    50$          ;CONTINUE IF NOT DONE
271 034364 001367
272 034366 012701 000006                                MOV     #6.,R1      ;CLEAR HEADER, CLEAR ID & SERIAL NUMBERS
273 034372 005000                                CLR     R0
274 034374 005060 103370 51$:  CLR     MFGFIL(R0)
275 034400 005060 104376      CLR     USRFIL(R0)
276 034404 005720                                TST     (R0)+        ;ADVANCE ADDRESS
277 034406 005301                                DEC     R1
278 034410 001371                                BNE    51$
279 034412 012601                                MOV     (SP)+,R1    ;;POP STACK INTO R1
280 034414 012600                                MOV     (SP)+,R0    ;;POP STACK INTO R0
281 034416 52$:  ;SET MEDIA ENABLE AND RESTORE THE USERS PUT BUFFER
    
```



```

282 034416 010046          MOV    R0,-(SP)          ;;PUSH R0 ON STACK
283 034420 005000          CLR    R0                ;;R0 IS REGISTER INDEX
284 034422 012737 177777 001512 53$:  MOV    #-1,MEDENB
285 034430 016060 101360 001412  MOV    BUFFER(R0),PUTBUF(R0)
286 034436 062700 000002  ADD    #2,R0              ;;ADVANCE R0
287 034442 022700 000046  CMP    #46,R0            ;;DONE ??
288 034446 103370  BHIS   53$
289 034450 012600          MOV    (SP)+,R0         ;;POP STACK INTO R0
290
291
292
293
294
295
296
297 034452          ;;*****
034452 010046          ;;VERIFY THAT THE DESIRED SECTOR IS NOT IN THE MFG BAD SECTOR FILE
034454 010146          ;;AND NOT IN THE USERS BAD SECTOR FILE. ASSIGN A NEW SECTOR IF THE
034456 010246          ;;SECTOR IS IN ANY OF THE FILES.
298 034460 013737 001446 001514 54$:  ;;*****
299 034466 013737 001420 001516  MOV    R0,-(SP)          ;;PUSH R0 ON STACK
300 034474 005002          MOV    R1,-(SP)          ;;PUSH R1 ON STACK
301 034476 013700 001414  MOV    R2,-(SP)          ;;PUSH R2 ON STACK
302 034502 005400          MOV    RMDCO,ASNDC       ;;LOAD REQUESTED CYLINDER, TRACK,
303 034504 012701 000400  MOV    RMDAO,ASNDA       ;;AND SECTOR ADDRESS IN ASSIGNED STORAGE
304 034510 032737 000002 001412  CLR    R2                ;;R2 = NUMBER OF SECTORS
305 034516 001402          MOV    RMWCO,R0          ;;R0 = WORD COUNT
306 034520 012701 000402  NEG    R0                ;;MAKE NUMBER POSITIVE
307 034524 020100          MOV    #256.,R1          ;;R1 = NUMBER OF WORDS PER SECTOR
308 034526 101404          BIT    #BIT1,RMCS10      ;;IS THIS A HEADER AND DATA COMMAND ??
309 034530 005700          BEQ    55$              ;;NO !!
310 034532 001405          MOV    #258.,R1          ;;CHANGE WORDS PER SECTOR
311 034534 005202          CMP    R1,R0            ;;IS THERE A FULL SECTOR ??
312 034536 000403          BLOS   56$              ;;YES !!
313 034540 160100          TST   R0                ;;IS R0 ZERO ??
314 034542 005202          BEQ    57$              ;;YES !!
315 034544 000767          INC   R2                ;;INCREMENT FOR PARTIAL SECTOR
316 034546 010237 035070 56$:  SUB    R1,R0            ;;SUBTRACT ONE SECTOR FROM WORD COUNT
317
318          INC   R2                ;;INCREMENT SECTOR COUNT
319          BR    55$
320          BR    57$
321          MOV    R2,68$      ;;SAVE SECTOR COUNT
322 034552 012737 103404 035100 57$:  MOV    #MFGFIL+14,72$    ;;THE STARTING ADDRESS OF MFG FILE
323
324 034560 004737 034602          JSR    PC,58$           ;;TO BASE ADDRESS STORAGE.
325 034564 012737 104412 035100  MOV    #USRFIL+14,72$    ;;GO SEARCH FILE
326
327 034572 004737 034602          JSR    PC,58$           ;;LOAD STARTING ADDRESS OF USR FILE
328 034576 000137 035042          JSR    PC,58$           ;;TO BASE ADDRESS STORAGE.
329
330 034602 013737 001514 035074 58$:  JMP    66$              ;;GO SEARCH FILE
331 034610 013737 001516 035076          ;;DONE WITH ALL FILE SEARCHES !!
332 034616 013737 035070 035072  MOV    ASNDC,70$        ;;LOAD COMPARING CYLINDER ADDRESS
333
334          MOV    ASNDA,71$    ;;LOAD COMPARING TRACK, SECTOR ADDRESS
          MOV    68$,69$    ;;LOAD NUMBER OF SECTORS TO CONFIRM
          ;;SETUP FOR A BINARY SEARCH OF THE CURRENT FILE FOR THE COMPARING
    
```

```

335                                     ;CYLINDER, TRACK AND SECTOR ADDRESS
336 034624                               59$:
337 034624 013700 035100                MOV     72$,RO           ;LOAD THE BASE ADDRESS IN RO
338 034630 022710 177777                CMP     #-1,(RO)       ;IS THIS FILE TERMINATOR ?
339 034634 001446                        BEQ     64$             ;BR IF YES
340 034636 021037 035074                CMP     (RO),70$      ;DOES TABLE ENTRY = COMPARING CYLINDER ?
341 034642 001010                        BNE     62$             ;BR IF NO
342
343                                     ;FILE ENTRY EQUALS COMPARING CYLINDER. SEE IF THE NEXT ENTRY EQUALS
344                                     ;THE COMPARING TRACK, AND SECTOR.
345 034644                               61$:
346 034644 126037 000003 035077        CMPB   3(RO),71$+1    ;DOES TABLE ENTRY = COMPARING TRACK ?
347 034652 001004                        BNE     62$             ;BR IF NO
348
349 034654 126037 000002 035076        CMPB   2(RO),71$     ;DOES TABLE ENTRY = COMPARING SECTOR ?
350 034662 001402                        BEQ     63$             ;BR IF YES
351
352 034664 022020                          62$:  CMP     (RO)+,(RO)+ ;NO, ADJUST CYLINDER POINTER IN BAD FILE
353 034666 000760                        BR      60$             ;AND CONTINUE SEARCH.
354
355                                     ;THE COMPARING CYLINDER, TRACK AND SECTOR IS IN THE BAD SECTOR FILE.
356                                     ;ADVANCE THE ASSIGNED SECTOR AND START THE SEARCH ALL OVER.
357 034670                               63$:
358 034670 105237 001516                INCB   ASNDA           ;INCREMENT SECTOR
359 034674 122737 000037 001516        CMPB   #31.,ASNDA    ;SECTOR OK ??
360 034702 103337                        BHIS   58$            ;YES !!
361 034704 105037 001516                CLR    ASNDA          ;CLEAR SECTOR AND ADVANCE TRACK
362 034710 105237 001517                INCB   ASNDA+1
363 034714 123737 001335 001517        CMPB   LSTRK+1,ASNDA+1 ;TRACK OK ?
364 034722 103327                        BHIS   58$            ;YES !!
365 034724 005037 001516                CLR    ASNDA          ;CLEAR TRACK AND SECTOR
366 034730 005237 001514                INC    ASNDC          ;INCREMENT CYLINDER
367 034734 022737 001466 001514        CMP    #822.,ASNDC   ;CYLINDER OK ??
368 034742 103317                        BHIS   58$            ;YES !!
369 034744 005037 001514                CLR    ASNDC          ;START AT CYLINDER 0
370 034750 000714                        BR      58$            ;SEARCH NEXT SECTOR
371
372                                     ;THE COMPARING SECTOR IS NOT IN THE BAD SECTOR FILES. DECREMENT THE
373                                     ;NUMBER OF SECTORS TO COMPARE AND SEARCH THE NEXT SECTOR IF THE NUMBER
374                                     ;IS NOT ZERO.
375 034752                               64$:
376 034752 005337 035072                DEC    69$            ;DECREMENT NUMBER OF SECTORS TO COMPARE
377 034756 001442                        BEQ    67$            ;DONE IF ZERO
378
379 034760 105237 035076                INCB   71$            ;INCREMENT THE COMPARING SECTOR
380 034764 122737 000037 035076        CMPB   #31.,71$     ;SECTOR OK ??
381 034772 103022                        BHIS   65$            ;YES !!
382 034774 105037 035076                CLR    71$            ;CLEAR SECTOR
383 035000 105237 035077                INCB   71$+1         ;INCREMENT TRACK
384 035004 123737 001335 035077        CMPB   LSTRK+1,71$+1 ;TRACK OK ??
385 035012 103012                        BHIS   65$            ;YES !!
386 035014 005037 035076                CLR    71$            ;CLEAR SECTOR TRACK
387 035020 005237 035074                INC    70$            ;INCREMENT CYLINDER
388 035024 022737 001466 035074        CMP    #822.,70$    ;CYLINDER OK ??
389 035032 103002                        BHIS   65$            ;YES !!
390 035034 005037 035074                CLR    70$            ;START AT CYLINDER 0
391
    
```



```

392 035040 000671      65$:    BR      59$                    ;SEARCH NEXT SECTOR
393
394                    ;ASSIGN THE SECTOR AND RETURN TO USER
395 035042            66$:
396 035042 013737 001514 001446      MOV    ASNDC,RMDCO      ;LOAD CYLINDER
397 035050 013737 001516 001420      MOV    ASNDA,RMDAO      ;LOAD TRACK AND SECTOR
398 035056 012602      MOV    (SP)+,R2          ;:POP STACK INTO R2
         035060 012601      MOV    (SP)+,R1          ;:POP STACK INTO R1
         035062 012600      MOV    (SP)+,R0          ;:POP STACK INTO R0
399
400 035064 000240      67$:    NOP
401 035066 000207           RTS      PC
402
403                    ;THE FOLLOWING ARE STORAGE LOCATIONS FOR THE MODULE
404
405 035070 000000      68$:    .WORD 0                ;RETRY COUNT/ NUMBER OF SECTORS REQUIRED
406 035072 000000      69$:    .WORD 0                ;NUMBER OF SECTORS TO COMPARE
407 035074 000000      70$:    .WORD 0                ;COMPARING CYLINDER
408 035076 000000      71$:    .WORD 0                ;COMPARING TRACK AND SECTOR
409 035100 000000      72$:    .WORD 0                ;BASE ADDRESS OF BAD SECTOR FILE BEING SEARCHED
410 035102 000000      73$:    .WORD 0                ;CONTAINS RMER2
    
```

```

1      .SBTTL  BUFFER GENERATOR SUBROUTINE
2
3      ;THIS SUBROUTINE GENERATES A DATA BUFFER FOR WRITE COMMANDS.  THE
4      ;BUFFER STARTS AT RMBA AND IS RMWC WORDS LONG.  THE BUFFER
5      ;CONTAINS A REPETITIVE DATA PATTERN CONSISTING OF $TMP1 WORDS
6      ;FROM THE DATA PATTERN TABLE, BEGINNING AT ADDRESS $TMP0.
7      ;HEADER INFORMATION FOR THE BUFFER IS EXTRACTED FROM RMDC,
8      ;RMDA AND RMOF.
9
10     ;R0 = ADDRESS OF DATA BUFFER
11     ;R1 = LENGTH OF DATA BUFFER
12     ;R2 = ADDRESS OF DATA PATTERN
13     ;R3 = LENGTH OF DATA PATTERN
14     ;R4 = SECTOR COUNT
15
16     ;CALL:
17     ;(1)  JSR      PC,GENBUF
18     ;(2)  ??
19
20     GENBUF:
21     035104 010046      MOV      R0,-(SP)      ;;PUSH R0 ON STACK
22     035106 010146      MOV      R1,-(SP)      ;;PUSH R1 ON STACK
23     035110 010246      MOV      R2,-(SP)      ;;PUSH R2 ON STACK
24     035112 010346      MOV      R3,-(SP)      ;;PUSH R3 ON STACK
25     035114 010446      MOV      R4,-(SP)      ;;PUSH R4 ON STACK
26     035116 013700 001416  MOV      RMBA0,R0      ;LOAD DATA BUFFER ADDRESS
27     035122 013701 001414  MOV      RMWC0,R1      ;LOAD WORD COUNT
28     035126 013737 001446 035336  MOV      RMDCO,60$     ;LOAD STARTING CYLINDER ADDRESS
29     035134 013737 001420 035340  MOV      RMDAO,65$     ;LOAD STARTING TRACK,SECTOR ADDRESS
30
31     035142 032737 000002 001412 10$:  BIT      #BIT1,RMCS10  ;WRITE HEADER & DATA??
32     035150 001445          BEQ      25$          ;NO!!
33     035152 013710 035336      MOV      60$,(R0)     ;WRITE HEADER WORD #1
34     035156 052710 140000      BIS      #MSE!USE,(R0) ;SET BAD SECTOR FLAGS FOR GOOD SECTOR
35     035162 012702 000035      MOV      #29.,R2     ;R2 = MAXIMUM SECTOR ADDRESS (29.)
36
37     035166 032737 010000 001444      BIT      #FMT16,RMOFO  ;18 BIT FORMAT??
38     035174 001404          BEQ      15$          ;YES !!
39     035176 052710 010000      BIS      #FMT16,(R0)  ;SET 16 FORMAT BIT IN HEADER
40     035202 012702 000037      MOV      #31.,R2     ;CHANGE MAXIMUM SECTOR ADDRESS (31.)
41
42     035206 005201          15$:  INC      R1          ;INCREMENT WORD COUNT
43     035210 001443          BEQ      50$          ;EXIT IF DONE
44
45     035212 005720          TST      (R0)+        ;MOVE R0 TO HEADER WORD #2
46     035214 013720 035340      MOV      65$,(R0)+   ;WRITE HEADER WORD #2
47     035220 005201          INC      R1          ;INCREMENT WORD COUNT AND
48     035222 001436          BEQ      50$          ;EXIT IF DONE
49     035224 012703 035340      MOV      #65$,R3     ;ADVANCE SECTOR ADDRESS
50     035230 105213          INCB    (R3)
51     035232 120213          CMPB   R2,(R3)       ;SECTOR OVERFLOW ??
52     035234 103013          BHIS   25$          ;NO !!
53     035236 105013          CLRB  (R3)          ;YES - CLEAR SECTOR ADDRESS
54     035240 105263 000001      INCB   1(R3)         ;ADVANCE TRACK ADDRESS
55     035244 123763 001335 000001  CMPB   LSTRK+1,1(R3) ;TRACK OVERFLOW ??
56     035252 103004          BHIS   25$          ;NO !!
57     035254 105063 000001      CLRB  1(R3)         ;YES - CLEAR TRACK ADDRESS

```



```

1      .SBTTL COMPARE BUFFER SUBROUTINE
2
3      ;THIS SUBROUTINE COMPARES THE CONTENTS OF BUFONE AND BUFTWO,
4      ;ASSUMING THAT BUFONE IS THE BUFFER FROM WHICH DATA WAS WRITTEN
5      ;AND BUFTWO IS THE BUFFER TO WHICH DATA WAS READ. ERRORS IN BUFFER
6      ;COMPARISON ARE REPORTED TO THE USER VIA THE USER'S ERROR CALL.
7
8      ;CALL:
9      ;(1) JSR PC,CMPBUF
10     ;(2) .WORD WRITE BUFFER ADDRESS
11     ;      .WORD READ BUFFER ADDRESS
12     ;(3) BR ?? RETURN HERE IF NO ERROR
13     ;(4) NOP RETURN HERE IF ERROR
14     ;(5) ERROR ERROR DEFINED BY SUBROUTINE
15     ;(6) ???
16
17     CMPBUF:
18     035342 010046 MOV R0,-(SP) ;;PUSH R0 ON STACK
19     035344 010146 MOV R1,-(SP) ;;PUSH R1 ON STACK
20     035346 010246 MOV R2,-(SP) ;;PUSH R2 ON STACK
21     035350 010346 MOV R3,-(SP) ;;PUSH R3 ON STACK
22     18 035352 005037 035702 CLR 150$ ;;CLEAR CORRECTION FLAG
23
24     ;DETERMINE IF DATA SHOULD BE CORRECTED
25     21 035356 033737 004000 001370 BIT ECI,RMOFI ;;WAS ECC CORRECTION ALLOWED ??
26     22 035364 001063 BNE 80$ ;;NO !!
27     23 035366 032737 100000 001352 BIT #DCK,RMER1I ;;WAS THERE A DATA CHECK ??
28     24 035374 001457 BEQ 80$ ;;NO !!
29     25 035376 032737 000100 001352 BIT #ECH,RMER1I ;;IS ERROR CORRECTION HARD SET ?
30     26 035404 001053 BNE 80$ ;;YES !!
31     27 035406 032737 010000 001370 BIT #FMT16,RMOFI ;;IS THIS 16 BIT FORMAT ??
32     28 035414 001447 BEQ 80$ ;;NO !!
33
34     ;CORRECT DATA USING ECC INFORMATION
35     31 035416 013700 001416 MOV RMBAD,R0 ;;R0 = STARTING BUFFER ADDRESS
36     32 035422 013701 001402 MOV RMECI,R1 ;;R1 = ECC POSITION
37     33 035426 052737 100000 035702 BIS #BIT15,150$ ;;SET CORRECTION FLAG
38
39     ;MOVE R0 TO WORD BOUNDARY OF ERROR BURST
40     36 035434 022701 000020 10$: CMP #16.,R1 ;;IS BIT POSITION > 1 WORD
41     37 035440 103004 BHIS 20$ ;;NO !!
42     38 035442 162701 000020 SUB #16.,R1 ;;SUBTRACT 1 WORDS WORTH
43     39 035446 005720 TST (R0)+ ;;ADVANCE BUFFER ADDRESS 1 WORD
44     40 035450 000771 BR 10$
45     41 035452 012702 000001 20$: MOV #1,R2 ;;R2 = BIT POINTER
46     42 035456 010203 MOV R2,R3 ;;R3 = BIT NUMBER
47
48     ;MOVE R2 TO STARTING BIT OF ERROR BURST
49     45 035460 020301 30$: CMP R3,R1 ;;IS R3 SAME AS R1 ??
50     46 035462 001403 BEQ 35$ ;;YES !!
51     47 035464 006302 ASL R2 ;;SHIFT BIT POINTER
52     48 035466 005203 INC R3 ;;INCREMENT BIT NUMBER
53     49 035470 000773 BR 30$
54     50 035472 012703 000013 35$: MOV #11.,R3 ;;R3 = LENGTH OF ERROR BURST
55
56     ;CORRECT THE ERROR BURST
57     52 035476 030237 001404 40$: BIT R2,RMEC2I ;;IS THIS BIT SET IN ECC PATTERN ??

```



```

54 035502 001405          BEQ      60$          ;NO - DO NOT CORRECT THIS BIT
55 035504 030210          BIT      R2,(R0)       ;IS THE BIT PRESENTLY SET ??
56 035506 001402          BEQ      50$          ;NO
57 035510 040210          BIC      R2,(R0)       ;RESET THE BIT
58 035512 000401          BR       60$
59 035514 050210          50$:    BIS      R2,(R0)       ;SET THE BIT
60 035516 006302          60$:    ASL      R2          ;SHIFT TO NEXT BIT
61 035520 001003          BNE      70$
62 035522 012702 000001  MOV      #1,R2          ;CONTINUE WITH FIRST BIT OF NEXT WORD
63 035526 005720          TST     (R0)+
64 035530 005303          70$:    DEC      R3          ;END OF BURST ??
65 035532 001361          BNE      40$          ;NO !!
66
67          ;COMPARE WRITE BUFFER TO READ BUFFER
68 035534 017600 000010  80$:    MOV      @10(SP),R0      ;R0 = WRITE BUFFER
69 035540 062766 000002 000010  ADD      #2,10(SP)        ;MOVE SP TO READ ADDRESS
70 035546 017601 000010  MOV      @10(SP),R1      ;R1 = READ BUFFER
71 035552 062766 000002 000010  ADD      #2,10(SP)        ;MOVE SP TO RETURN ADDRESS
72 035560 013702 001340  MOV      RMWCI,R2        ;R2 = NUMBER OF WORDS TRANSFER
73 035564 163702 001414  SUB      RMWCO,R2
74 035570 022021          90$:    CMP      (R0)+,(R1)+    ;COMPARE DATA WORDS
75 035572 001003          BNE      100$          ;EXIT IF NOT EQUAL
76 035574 005302          DEC      R2            ;DECREMENT WORD COUNT
77 035576 001374          BNE      90$          ;CONTINUE IF NOT DONE
78 035600 000433          BR       110$         ;DONE COMPARE - NO ERROR
79
80          ;DATA COMPARE FAILED
81 035602 014037 001140  100$:   MOV      -(R0),%GDDAT    ;STORE GOOD DATA FOR TYPEOUT
82 035606 014137 001142  MOV      -(R1),%BDDAT    ;STORE BAD DATA FOR TYPEOUT
83 035612 010037 001134  MOV      R0,%GDADR      ;STORE ADDRESS OF GOOD DATA
84 035616 010137 001136  MOV      R1,%BDADR      ;STORE ADDRESS OF BAD DATA
85 035622 010237 001174  MOV      R2,%TMP0       ;STORE WORD COUNT OF ERROR
86 035626 062766 000004 000010  ADD      #4,10(SP)        ;MOVE SP TO USER'S ERROR CALL
87 035634 112776 000336 000010  MOVVB   #336,@10(SP)     ;WRITE ERROR NUMBER IN CALL
88
89          ;CHANGE ERROR NUMBER IF ECC CORRECTION FAILED
90 035642 032737 100000 035702  BIT      #BIT15,150$     ;WAS ECC CORRECTION USED ??
91 035650 001403          BEQ      105$          ;NO !!
92 035652 112776 000163 000010  MOVVB   #163,@10(SP)     ;ECC CORRECTION FAILED
93 035660 162766 000002 000010  105$:   SUB      #2,10(SP)      ;MOVE SP TO RETURN IF ERROR
94 035666 000240          NOP
95 035670          110$:   MOV      (SP)+,R3        ;:POP STACK INTO R3
          MOV      (SP)+,R2        ;:POP STACK INTO R2
          MOV      (SP)+,R1        ;:POP STACK INTO R1
          MOV      (SP)+,R0        ;:POP STACK INTO R0
96 035700 000207          RTS      PC            ;RETURN TO USER
97
98 035702 000000          150$:   .WORD          ;ECC CORRECTION FLAG
    
```

```

1      .SBTTL  GET STATUS SUBROUTINE
2
3      ;THIS SUBROUTINE SETS UP THE "GET INDEX TABLE" AND THE "GET
4      ;BUFFER" FOR READING ALL SUBSYSTEM REGISTERS VIA THE GET SUBROUTINE
5      ;AND THEN RETURNS TO THE USER.
6
7      ;CALL:  JSR      PC,GETSTS
8      ;      ???
9
10     GETSTS:
11     MOV      R0,-(SP)      ;;PUSH R0 ON STACK
12     MOV      R1,-(SP)      ;;PUSH R1 ON STACK
13     MOV      R2,-(SP)      ;;PUSH R2 ON STACK
14     MOV      #GETINX,R0    ;R0 = ADDRESS OF INDEX TABLE
15     MOV      #RMEC2I+2,R1  ;R1 = ADDRESS OF GET BUFFER
16     MOV      #RMEC2,R2     ;R2 = REGISTER INDE
17     2$:     MOVB     R2,(R0)+ ;WRITE REGISTER INDEX IN TABLE
18     CLR      -(R1)         ;CLEAR CORRESPONDING LOCATION
19     3$:     SUB      #2,R2   ;DECREMENT TO NEXT INDEX
20     BMI      4$           ;BRANCH OUT IF DONE
21     CMP      #RMDB,R2     ;DONT WRITE RMDB INDEX
22     BNE     2$
23     CLR      -(R1)
24     BR      3$
25     4$:     MOVB     #200,(R0)+ ;WRITE TERMINATOR
26     MOV      (SP)+,R2     ;;POP STACK INTO R2
27     MOV      (SP)+,R1     ;;POP STACK INTO R1
28     MOV      (SP)+,R0     ;;POP STACK INTO R0
29     NOP
30     RTS      PC
  
```

```

10 035704
11 035706 010046
12 035710 010146
13 035712 010246 001524
14 035716 012701 001406
15 035722 012702 000046
16 035726 110220
17 035730 005041
18 035732 162702 000002
19 035736 100405
20 035740 022702 000022
21 035744 001370
22 035746 005041
23 035750 000770
24 035752 112720 000200
25 035756 012602
26 035760 012601
27 035762 012600
28 035764 000240
29 035766 000207
  
```


1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30

.SBTTL GET SUBROUTINE

:THIS SUBROUTINE READS THE REGISTERS WHICH ARE LISTED IN THE
: "GET INDEX TABLE" AND STORES THEIR VALUES IN THE CORRESPONDING
: LOCATION IN THE "GET REGISTER BUFFER". FOR EXAMPLE, AN
: ENTRY OF 04 IN THE TABLE WILL CAUSE THE SUBROUTINE TO
: READ "RMB4" AND STORE ITS CONTENTS AT THE LOCATION IN
: THE BUFFER ASSIGNED TO THAT REGISTER. THE NUMBER OF
: REGISTERS TO BE READ IS VARIABLE FROM 1 TO 22; THE INDEX
: TABLE MUST BE TERMINATED WITH A CONTROL BYTE (200)
: WHICH SHOULD FOLLOW THE LAST ENTRY.

:SUBROUTINE CALL:

- : (1) "GET INDEX TABLE" HAS BEEN LOADED WITH REGISTER INDEX
: VALUES AND TERMINATED WITH A CONTROL BYTE
- : (2) "GET INPUT BUFFER" IS AVAILABLE FOR USE. (NOTE THAT
: UNUSED LOCATIONS, I.E., ENTRIES IN BUFFER CORRESPONDING
: TO REGISTERS NOT READ, ARE NOT CHANGED.)
- : (3) JSR PC,GET
: BR ??? RETURN HERE IF NO ERROR FOUND
: NOP RETURN HERE IF ANY ERROR FOUND
: ERROR SUB DEFINES ERROR NUMBER
: ???

:R0 = REGISTER BASE ADDRESS
:R1 = REGISTER ADDRESS
:R2 = BUFFER BASE ADDRESS
:R3 = BUFFER ADDRESS
:R4 = POINTER TO REGISTER INDEX

31 035770 000240
32 035772 062716 000004
33 035776 105076 000000
34 036002 162716 000004
35 036006 010046
036010 010146
036012 010246
036014 010346
036016 010446
036020 013746 000004
036024 013746 000006
36 036030 013700 001276
37 036034 012702 001336
38 036040 012704 001524
39 036044 012737 036152 000004
40 036052 012737 000300 000006
41 036060 016037 000010 001174
42 036066 016037 000000 001176
43 036074 032737 004000 001176
44 036102 001007
45 036104 062766 000004 000016
46 036112 112776 000112 000016
47 036120 000423
48 036122 105714
49 036124 100433
50 036126 111401
51 036130 042701 177700

```

GET:  NOP
      ADD    #4,(SP)      ;CLEAR ERROR NUMBER IN USER'S
      CLRB  @ (SP)       ;ERROR CALL
      SUB   #4,(SP)
      MOV   R0,-(SP)     ;:PUSH R0 ON STACK
      MOV   R1,-(SP)     ;:PUSH R1 ON STACK
      MOV   R2,-(SP)     ;:PUSH R2 ON STACK
      MOV   R3,-(SP)     ;:PUSH R3 ON STACK
      MOV   R4,-(SP)     ;:PUSH R4 ON STACK
      MOV   ERRVEC,-(SP) ;:PUSH ERRVEC ON STACK
      MOV   ERRVEC+2,-(SP) ;:PUSH ERRVEC+2 ON STACK
      MOV   $BASE,R0
      MOV   #GETBUF,R2
      MOV   #GETINX,R4
      MOV   #5$,ERRVEC   ;SETUP FOR TIMEOUT
      MOV   #PR6,ERRVEC+2
1$:   MOV   RMCS2(R0),$TMP0 ;GET 'NED' STATUS
      MOV   RMCS1(R0),$TMP1 ;GET 'DVA' STATUS
      BIT   #DVA,$TMP1    ;DEVICE AVAILABLE??
      BNE   3$           ;YES!!
      ADD   #4,16(SP)     ;WRITE ERROR NUMBER IN USER'S
      MOVB #112,@16(SP)  ;ERROR CALL
      BR   7$
3$:   TSTB  (R4)         ;DONE??
      BMI  9$           ;YES!!
      MOVB (R4),R1      ;R1 = REGISTER ADDRESS
      BIC  #^CIDXMSK,R1 ;CLEAR ANY SIGN EXTENSION
    
```

```

52 036134 060001          ADD      R0,R1
53 036136 112403          MOVVB   (R4)+,R3      ;R3 = STORAGE ADDRESS FOR REGISTER
54 036140 042703 177700    BIC     #^CIDXMSK,R3 ;CLEAR ANY SIGN EXTENSION
55 036144 060203          ADD     R2,R3
56 036146 011113          MOV     (R1),(R3)    ;READ REGISTER
57 036150 000764          BR      3$
58
59 036152 022626          5$:    CMP     (SP)+,(SP)+ ;RESTORE STACK
60 036154 062766 000004 000016  ADD     #4,16(SP)     ;WRITE ERROR NUMBER IN
61 036162 112776 000007 000016  MOVVB  #7,@16(SP)    ;USER'S ERROR CALL
62 036170 162766 000002 000016  7$:    SUB     #2,16(SP)
63 036176 105714          8$:    TSTB   (R4)        ;DONE CLEARING??
64 036200 100405          BMI     9$          ;YES!!
65 036202 005003          CLR     R3          ;CLEAR REMAINING STORAGE
66 036204 112403          MOVVB  (R4)+,R3     ;LOCATIONS
67 036206 060203          ADD     R2,R3
68 036210 005013          CLR     (R3)
69 036212 000771          BR      8$
70 036214          9$:
    036214 012637 0C0006      MOV     (SP)+,ERRVEC+2 ;:POP STACK INTO ERRVEC+2
    036220 012637 000004      MOV     (SP)+,ERRVEC  ;:POP STACK INTO ERRVEC
    036224 012604          MOV     (SP)+,R4      ;:POP STACK INTO R4
    036226 012603          MOV     (SP)+,R3      ;:POP STACK INTO R3
    036230 012602          MOV     (SP)+,R2      ;:POP STACK INTO R2
    036232 012601          MOV     (SP)+,R1      ;:POP STACK INTO R1
    036234 012600          MOV     (SP)+,R0      ;:POP STACK INTO R0
71 036236 000207          RTS     PC           ;RETURN
    
```


1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51

```
.SBTTL PUT SUBROUTINE

:THIS SUBROUTINE WRITES THE REGISTERS WHICH ARE LISTED IN THE
:'PUT INDEX TABLE' WITH THE CONTENTS OF THE CORRESPONDING
:LOCATION IN THE 'PUT REGISTER BUFFER'. THE NUMBER OF
:REGISTERS WRITTEN IS VARIABLE; THE INDEX TABLE MUST
:BE TERMINATED WITH A CONTROL BYTE (200) WHICH SHOULD
:FOLLOW THE LAST ENTRY.

:SUBROUTINE CALL:

:(1) 'PUT INDEX TABLE' HAS BEEN LOADED WITH INDEX VALUES
:OF REGISTERS TO BE WRITTEN.
:(2) 'PUT REGISTER BUFFER' CONTAINS CONTENTS OF EACH
:REGISTER TO BE WRITTEN.
:(3) JSR PC,PUT
:BR ??? RETURN HERE IF NO ERROR FOUND
:NOP RETURN HERE IF ANY ERROR FOUND
:ERROR SUB DEFINES ERROR NUMBER
:???

:R0 = REGISTER BASE ADDRESS
:R1 = REGISTER ADDRESS
:R2 = BUFFER BASE ADDRESS
:R3 = BUFFER ADDRESS
:R4 = POINTER TO REGISTER INDEX
```

```
PUT:  NOP
      MOV R0,-(SP) ;;PUSH R0 ON STACK
      MOV R1,-(SP) ;;PUSH R1 ON STACK
      MOV R2,-(SP) ;;PUSH R2 ON STACK
      MOV R3,-(SP) ;;PUSH R3 ON STACK
      MOV R4,-(SP) ;;PUSH R4 ON STACK
      MOV ERRVEC,-(SP) ;;PUSH ERRVEC ON STACK
      MOV ERRVEC+2,-(SP) ;;PUSH ERRVEC+2 ON STACK
      MOV $BASE,R0
      MOV #PUTBUF,R2
      MOV #PUTINX,R4
      MOV #5$,ERRVEC ;:SETUP FOR TIMEOUT
      MOV #PR6,ERRVEC+2
1$:  MOV RMCS2(R0),$TMP0 ;:GET 'NED' STATUS
      MOV RMCS1(R0),$TMP1 ;:GET 'DVA' STATUS
      BIT #DVA,$TMP1 ;:DEVICE AVAILABLE??
      BNE 3$ ;:YES!!
      ADD #4,16(SP) ;:WRITE ERROR NUMBER IN
      MOVB #112,@16(SP) ;:USER'S ERROR CALL
      BR 7$
3$:  TSTB (R4) ;:DONE??
      BMI 9$ ;:YES!!
      MOVB (R4),R1 ;:R1 = REGISTER ADDRESS
      BIC #^CIDXMSK,R1 ;:CLEAR ANY SIGN EXTENSION
      ADD R0,R1
      MOVB (R4),R3 ;:R3 = STORAGE ADDRESS
      BIC #^CIDXMSK,R3 ;:CLEAR ANY SIGN EXTENSION
      ADD R2,R3
4$:  MOV (R3),(R1) ;:WRITE REGISTER
      TSTB (R4)+ ;:ADJUST REGISTER POINTER
```

```
036240 000240
036242 010046
036244 010146
036246 010246
036250 010346
036252 010446
036254 013746 000004
036260 013746 000006
30 036264 013700 001276
31 036270 012702 001412
32 036274 012704 001553
33 036300 012737 036410 000004
34 036306 012737 000300 000006
35 036314 016037 000010 001174 1$:
36 036322 016037 000000 001176
37 036330 032737 004000 001176
38 036336 001007
39 036340 062766 000004 000016
40 036346 112776 000112 000016
41 036354 000424
42 036356 105714 3$:
43 036360 100425
44 036362 111401
45 036364 042701 177700
46 036370 060001
47 036372 111403
48 036374 042703 177700
49 036400 060203
50 036402 011311
51 036404 105724
```

```
52 036406 000763          BR      3$
53
54 036410 022626          5$:    CMP      (SP)+,(SP)+      ;ADJUST STACK
55 036412 062766 000004 000016  ADD      #4,16(SP)      ;WRITE ERROR NUMBER IN
56 036420 112776 000007 000016  MOV      #7,@16(SP)    ;USER'S ERROR CALL
57 036426 162766 000002 000016  7$:    SUB      #2,16(SP)
58
59 036434          9$:
   036434 012637 000006  MOV      (SP)+,ERRVEC+2      ;:POP STACK INTO ERRVEC+2
   036440 012637 000004  MOV      (SP)+,ERRVEC      ;:POP STACK INTO ERRVEC
   036444 012604  MOV      (SP)+,R4          ;:POP STACK INTO R4
   036446 012603  MOV      (SP)+,R3          ;:POP STACK INTO R3
   036450 012602  MOV      (SP)+,R2          ;:POP STACK INTO R2
   036452 012601  MOV      (SP)+,R1          ;:POP STACK INTO R1
   036454 012600  MOV      (SP)+,R0          ;:POP STACK INTO R0
60 036456 000207  RTS      PC          ;RETURN
```



```

1          .SBTTL  SIZE CLOCK SUBROUTINE
2
3          SIZCLK:
4 036460  013746  000004      MOV  ERRVEC,-(SP)      ;;PUSH ERRVEC ON STACK
5 036464  013746  000006      MOV  ERRVEC+2,-(SP)    ;;PUSH ERRVEC+2 ON STACK
6 036470  012737  036526  000004  MOV  #1$,ERRVEC      ;;SET UP FOR BUS TIMEOUT
7 036476  012737  000300  000006  MOV  #PR6,ERRVEC+2
8 036504  012737  177546  001520  MOV  #177546,CLKADR  ;;LOAD ADDRESSES FOR KW11-L
9 036512  012737  000100  001522  MOV  #100,CLKVCT
10 036520  005777  142774      TST  @CLKADR          ;;TEST FOR KW11-L PRESENT
11 036524  000421      BR   3$              ;;YES - KW11-L IS PRESENT
12 036526  022626      1$:  CMP  (SP)+,(SP)+    ;;RESTORE SP
13 036530  012737  036560  000004  MOV  #2$,ERRVEC      ;;SET UP FOR BUS TIMEOUT
14 036536  012737  172540  001520  MOV  #172540,CLKADR  ;;LOAD ADDRESSES FOR KW11-P CLOCK
15 036544  012737  000104  001522  MOV  #104,CLKVCT
16 036552  005777  142742      TST  @CLKADR          ;;TEST FOR KW11-P PRESENT
17 036556  000404      BR   3$              ;;YES - KW11-P IS PRESENT
18 036560  022626      2$:  CMP  (SP)+,(SP)+    ;;RESTORE SP
19 036562  062766  000002  000004  ADD  #2,4(SP)        ;;MOVE RETURN TO ERROR
20 036570  012637  000006      3$:  MOV  (SP)+,ERRVEC+2  ;;POP STACK INTO ERRVEC+2
21 036574  012637  000004      MOV  (SP)+,ERRVEC    ;;POP STACK INTO ERRVEC
22 036600  000207      RTS  PC              ;;RETURN TO USER

```

```

1      .SBTTL  TIMEOUT SUBROUTINE
2
3      ;THIS SUBROUTINE WAITS FOR RDY = 1 AND GO = 0 OR FOR A TIMEOUT
4      ;GREATER THAN APPROX. 500 MSEC AND THEN RETURNS.
5
6      ;CALL:  JSR      PC,TIMOUT
7      ;      ???
8      ;      RETURN HERE
9
10     TIMOUT:
11     MOV      R0,-(SP)      ;;PUSH R0 ON STACK
12     MOV      R1,-(SP)      ;;PUSH R1 ON STACK
13     MOV      R2,-(SP)      ;;PUSH R2 ON STACK
14     MOV      ERRVEC,-(SP)  ;;PUSH ERRVEC ON STACK
15     MOV      ERRVEC+2,-(SP) ;;PUSH ERRVEC+2 ON STACK
16     MOV      #4$,ERRVEC    ;SETUP FOR BUS TIMEOUT - 04 TRAP
17     MOV      #PR6,ERRVEC+2
18     MOV      $BASE,R0      ;R0=BASE ADDRESS
19     MOV      CLKADR,R1     ;R1=CLOCK ADDRESS
20     MOV      #30.,R2       ;R2=NUMBER OF CLOCK CYCLES
21     1$:      CMP      R1,#172540 ;KW11-P CLOCK??
22     BNE      2$           ;NO!!
23     MOV      #1,2(R1)     ;SET COUNTER
24     2$:      MOV      #BIT2!BIT0,(R1) ;START COUNTER
25
26     3$:      MOV      RMCS1(R0),-(SP) ;GET STATUS
27     BIC      #^C<RDY!GO>,(SP)
28     CMP      #RDY,(SP)+   ;RDY=1,GO=0??
29     BEQ      5$           ;YES!!
30     BIT      #BIT7,(R1)   ;TIMER DONE??
31     BEQ      3$           ;NO!!
32     DEC      R2           ;DEC NUMBER OF CYCLES
33     BNE      1$           ;CONTINUE IF NOT DONE
34     BR       5$           ;'RDY' DID NOT SET OR 'GO' DID NOT RESET
35
36     4$:      CMP      (SP)+,(SP)+ ;WITHIN 500 MSEC AFTER THE COMMAND WAS ISSUED.
37     ADD      #4,12(SP)    ;ADJUST STACK
38     MOV      #7,@12(SP)  ;MOVE SP TO USER'S CALL
39     SUB      #2,12(SP)   ;WRITE ERROR NUMBER
40
41     5$:      MOV      (SP)+,ERRVEC+2 ;POP STACK INTO ERRVEC+2
42     MOV      (SP)+,ERRVEC  ;;POP STACK INTO ERRVEC
43     MOV      (SP)+,R2      ;;POP STACK INTO R2
44     MOV      (SP)+,R1      ;;POP STACK INTO R1
45     MOV      (SP)+,R0      ;;POP STACK INTO R0
46     RTS      PC          ;RETURN TO USER
    
```


1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57

```

.SBTTL ERROR CHECK SUBROUTINES
:*****
.SBTTL PRIMARY ERROR CHECK SUBROUTINE

:THE PURPOSE OF THIS SUBROUTINE IS TO VERIFY THAT STATUS IS VALID AND
:THAT FURTHER ERROR AND STATUS CHECKING SHOULD BE PERFORMED. THE
:FOLLOWING CHECKS ARE MADE:

:   .CORRECT UNIT IS SELECTED, I.E., THE UNIT SELECT BITS OF RMCS2
:(BITS 0-2) EQUAL THE UNIT BEING TESTED;

:   .SELECTED UNIT IS AVAILABLE, I.E., DVA (BIT 11 OF RMCS1) IS SET
:AND NED (BIT 12 OF RMCS2) IS RESET;

:   .LAST COMMAND WAS COMPLETED, I.E., THE MASSBUS CONTROLLER IS
:READY (BIT 7 OF RMCS1) AND THE GO BIT IS RESET (BIT 0 OF RMCS1) OR THE
:DRIVE READY BIT (BIT 7 OF RMDS) IS SET.
:   .NO PARITY ERROR OCCURRED WHEN READING REMOTE REGISTERS,
:I.E., MCPE = 0.
:   .NO PARITY ERROR OCCURRED WHEN WRITING REMOTE REGISTERS,
:I.E., PAR = 0, OR, PAR = DPE = 1

:THE SUBROUTINE ASSUMES THAT:

:   .STATUS HAS BEEN STORED IN THE REGISTER INPUT BUFFER,
:IN PARTICULAR, RMCS1, RMCS2 AND RMDS HAVE BEEN STORED IN THEIR
:CORRESPONDING LOCATIONS OF THE 'GET' BUFFER.

:   .($UNIT) CONTAINS THE DRIVE NUMBER

:THE SUBROUTINE IS CALLED AS FOLLOWS:

:(1)   JSR    PC,PRIERR
:       BR    ???           RETURN HERE IF NO ERROR
:       NOP
:       ERROR           RETURN HERE TO REPORT AN ERROR
:       JSR    PC,@(SP)+   ERROR NUMBER DEFINED BY SUB
:       ???           GO BACK TO SUB FOR MORE ERROR CHECKS
:                       RETURN HERE IF NO MORE ERRORS

PRIERR:

:CLEAR USER'S ERROR CALL
ADD    #4,(SP)           ;MOVE (SP) TO ERROR CALL
CLRB   @ (SP)           ;CLEAR ERROR NUMBER
SUB    #4,(SP)           ;MOVE (SP) TO NO ERROR RETURN

:REPORT AN ERROR IF THE WRONG UNIT IS SELECTED
MOV    RMCS2I,$BDDAT    ;CORRECT UNIT SELECTED??
BIC    #^CUNTMSK,$BDDAT
MOV    $UNIT,$GDDAT     ;GOOD DATA FOR TYPEOUT
BIC    #^CUNTMSK,$GDDAT
CMPB   $GDDAT,$BDDAT    ;COMPARE EXPECTED AND RECEIVED
:DRIVE NUMBERS
BEQ    1$               ;YES!!
ADD    #4,(SP)
MOVB   #1,@(SP)         ;ERROR 1
    
```

036766				
036766	062716	-000004		
036772	105076	000000		
036776	162716	000004		
037002	013737	001346	001142	
037010	042737	177770	001142	
037016	013737	001234	001140	
037024	042737	177770	001140	
037032	123737	001140	001142	
037040	001415			
037042	062716	000004		
037046	112776	000001	000000	

58	037054	162716	000002		SUB	#2,(SP)		;MOVE SP TO RETURN FOR ERROR
59	037060	004736			JSR	PC,@(SP)+		;REPORT WRONG UNIT SELECTED
60	037062	162716	000010		SUB	#10,(SP)		;RESTORE (SP)
61	037066	000240			NOP			
62	037070	000137	037610		JMP	10\$;SKIP OTHER CHECKS
63	037074						1\$:	
64								
65								;REPORT AN ERROR IF THE DEVICE IS NOT AVAILABLE OR IF
66								;THE DEVICE IS NONEXISTANT
67	037074	032737	004000	001336	BIT	#DVA, RMCS1I		;DEVICE AVAILABLE??
68	037102	001045			BNE	5\$;YES!!
69	037104	013737	001336	001140	MOV	RMCS1I,\$GDDAT		;EXPECTED STATUS
70	037112	052737	004000	001140	BIS	#DVA,\$GDDAT		
71	037120	013737	001336	001142	MOV	RMCS1I,\$BDDAT		;RECEIVED STATUS
72	037126	062716	000004		ADD	#4,(SP)		
73	037132	112776	000002	000000	MOVB	#2,@(SP)		;ERROR #2
74	037140	032737	010000	001346	BIT	#NED, RMCS2I		;WAS NED SET??
75	037146	001414			BEQ	2\$;NO!!
76	037150	013737	001346	001140	MOV	RMCS2I,\$GDDAT		;EXPECTED STATUS
77	037156	013737	001346	001142	MOV	RMCS2I,\$BDDAT		;RECEIVED STATUS
78	037164	042737	010000	001140	BIC	#NED,\$GDDAT		
79	037172	112776	000003	000000	MOVB	#3,@(SP)		;YES - CHANGE ERROR NUMBER
80	037200	162716	000002		SUB	#2,(SP)		;MOVE SP TO RETURN FOR ERROR
81	037204	004736			JSR	PC,@(SP)+		;REPORT DEVICE NOT AVAILABLE
82	037206	162716	000010		SUB	#10,(SP)		;RESTORE (SP)
83	037212	000240			NOP			
84	037214	000575			BR	10\$;SKIP OTHER CHECKS
85	037216						5\$:	
86								
87								;REPORT AN ERROR IF MASSBUS CONTROLLER IS NOT READY
88	037216	032737	000200	001336	BIT	#RDY, RMCS1I		;CONTROLLER READY??
89	037224	001030			BNE	7\$;YES!!
90	037226	013737	001336	001140	MOV	RMCS1I,\$GDDAT		;EXPECTED STATUS
91	037234	052737	000200	001140	BIS	#RDY,\$GDDAT		
92	037242	042737	160001	001140	BIC	#SC!TRE!MCPE!GO,\$GDDAT		
93	037250	013737	001336	001142	MOV	RMCS1I,\$BDDAT		;RECEIVED STATUS
94	037256	062716	000004		ADD	#4,(SP)		
95	037262	112776	000004	000000	MOVB	#4,@(SP)		;ERROR #4
96	037270	162716	000002		SUB	#2,(SP)		;MOVE SP TO RETURN FOR ERROR
97	037274	004736			JSR	PC,@(SP)+		;REPORT CONTROLLER NOT READY
98	037276	162716	000010		SUB	#10,(SP)		;RESTORE (SP)
99	037302	000240			NOP			
100	037304	000541			BR	10\$;SKIP OTHER CHECKS
101	037306						7\$:	
102								
103								;REPORT AN ERROR IF GO IS NOT ZERO AND DRY IS NOT ONE
104	037306	032737	000001	001336	BIT	#GO, RMCS1I		;GO RESET??
105	037314	001431			BEQ	8\$;YES!!
106	037316	032737	000200	001350	BIT	#DRY, RMDSI		;DRIVE READY??
107	037324	001025			BNE	8\$;YES!!
108	037326	013737	001336	001140	MOV	RMCS1I,\$GDDAT		;EXPECTED STATUS
109	037334	042737	160001	001140	BIC	#SC!TRE!MCPE!GO,\$GDDAT		
110	037342	013737	001336	001142	MOV	RMCS1I,\$BDDAT		;RECEIVED STATUS
111	037350	062716	000004		ADD	#4,(SP)		
112	037354	112776	000005	000000	MOVB	#5,@(SP)		;ERROR #5
113	037362	162716	000002		SUB	#2,(SP)		;MOVE SP TO RETURN FOR ERROR
114	037366	004736			JSR	PC,@(SP)+		;REPORT DRIVE NOT READY


```

115 037370 162716 000010          SUB      #10,(SP)          ;RESTORE (SP)
116 037374 000240          NOP
117 037376 000504          BR       10$
118 037400          8$:
119
120          ;REPORT AN ERROR IF THE RH CONTROLLER DETECTED BAD
121          ;PARITY ON THE MASSBUS CONTROL BUS
122 037400 032737 020000 001336      BIT      #MCPE,RMCS1I      ;PARITY ERROR ??
123 037406 001425          BEQ     9$                ;NO!!
124 037410 013737 001336 001140      MOV     RMCS1I,$GDDAT      ;EXPECTED STATUS
125 037416 042737 160001 001140      BIC     #SC!TRE!MCPE!GO,$GDDAT
126 037424 013737 001336 001142      MOV     RMCS1I,$BDDAT      ;RECEIVED STATUS
127 037432 062716 000004          ADD     #4,(SP)           ;MOVE SP TO USER'S ERROR
128 037436 112776 000013 000000      MOV     #13,@(SP)         ;ERROR #13
129 037444 162716 000002          SUB     #2,(SP)           ;MOVE SP TO RETURN FOR ERROR
130 037450 004736          JSR    PC,@(SP)+         ;REPORT ERROR VIA USER
131 037452 162716 000010          SUB     #10,(SP)          ;RESTORE STACK
132 037456 000240          NOP
133 037460 000453          BR       10$
134 037462          9$:
135
136          ;REPORT AN ERROR IF DETECTED A CONTROL BUS PARITY ERROR
137 037462 032737 000010 001352      BIT     #PAR,RMER1I        ;WAS THERE A PARITY ERROR??
138 037470 001451          BEQ    11$                ;NO!!
139 037472 032737 000010 001400      BIT     #DPE,RMER2I        ;WAS IT THE CONTROL BUS??
140 037500 001045          BNE    11$                ;NOT SURE!!
141 037502 032737 000010 001426      BIT     #PAR,RMER10        ;DID TEST SET PAR ??
142 037510 001413          BEQ    93$                ;NO!!
143 037512 010046          MOV    R0,-(SP)           ;:PUSH R0 ON STACK
144 037514 012700 001553          MOV    #PUTINX,R0         ;R0 POINTS TO INDEX TABLE
145 037520 122710 000014          91$: CMPB   #RMER1,(R0)       ;SEARCH TABLE FOR RMER1
146 037524 001002          BNE    92$                ;:POP STACK INTO R0
147 037526 012600          MOV    (SP)+,R0           ;PAR WAS SET BY TEST
148 037530 000431          BR     11$                ;END OF TABLE??
149 037532 105720          92$: TSTB   (R0)+            ;NO!!
150 037534 100371          BPL    91$                ;:POP STACK INTO R0
151 037536 012600          MOV    (SP)+,R0           ;EXPECTED STATUS
152 037540 013737 001352 001140      93$: MOV    RMER1I,$GDDAT
153 037546 042737 000010 001140      BIC     #PAR,$GDDAT
154 037554 013737 001352 001142      MOV     RMER1I,$BDDAT      ;RECEIVED STATUS
155 037562 062716 000004          ADD     #4,(SP)           ;MOVE SP TO USER'S ERROR CALL
156 037566 112776 000050 000000      MOV     #50,@(SP)         ;WRITE THE ERROR NUMBER
157 037574 162716 000002          SUB     #2,(SP)           ;MOVE SP TO RETURN FOR ERROR
158 037600 004736          JSR    PC,@(SP)+         ;REPORT THE ERROR
159 037602 162716 000010          SUB     #10,(SP)          ;MOVE SP TO NO ERROR RETURN
160 037606 000240          NOP
161 037610 062716 000010          10$: ADD     #10,(SP)         ;RETURN TO ERROR
162 037614 000240          11$: NOP
163 037616 000207          RTS     PC

```

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57

```

.SBTTL SECONDARY ERROR CHECK SUBROUTINE

;THE ERROR CHECK SUBROUTINE PROVIDES DETECTION OF SECONDARY ERRORS
;SUCH AS UNEXPECTED ERRORS AND UNEXPECTED REGISTER CONTENTS. THESE
;ERRORS ARE DEEMED SECONDARY IN THAT THEY ARE NOT NECESSARILY
;ASSOCIATED WITH THE OPERATION BEING PERFORMED.
;WHEN THE SUBROUTINE IDENTIFIES SUCH AN ERROR, IT MOVES THE ERROR
;NUMBER TO THE ERROR CALL IN THE TEST ROUTINE AND THEN RETURNS
;TO THE TEST ROUTINE WHICH MAKES THE ERROR CALL. AFTER THE TEST ROUTINE
;MAKES THE ERROR CALL, IT RETURNS TO THE SUBROUTINE WHICH THEN LOOKS FOR
;OTHER ERRORS. WHEN ALL ERRORS HAVE BEEN REPORTED, THE SUBROUTINE
;RETURNS TO THE ADDRESS FOLLOWING THE SUBROUTINE CALL.

:CALL: JSR    PC,SECERR
       BR     ???          RETURN HERE IF NO ERROR
       NOP
       ERROR          RETURN HERE TO REPORT AN ERROR
       JSR    PC,@(SP)+   ERROR NUMBER DEFINED BY SUB
       ???          GO BACK TO SUB FOR MORE ERROR CHECKS
                       RETURN HERE IF NO MORE ERRORS

;NOTE: THE SUBROUTINE ASSUMES THAT REGISTERS HAVE BEEN STORED AT THE
;INPUT REGISTER BUFFER.

SECERR:

:*****
:STORE FUNCTION CODE AND CLEAR USER'S ERROR NUMBER
MOV    RMCS10,515$      ;STORE FUNCTION CODE
BIC    #^C<F0!F1!F2!F3!F4>,515$
ADD    #4,(SP)          ;MOVE (SP) TO ERROR CALL
CLRB   @ (SP)           ;CLEAR ERROR NUMBER
SUB    #4,(SP)          ;MOVE (SP) TO NO ERROR RETURN

:*****
:CHECK SECONDARY ERRORS COMMON TO ALL COMMANDS

:REPORT ERROR IF DRIVE IS NOT READY, I.E., IF DRY = 0
BIT    #DRY,RMDSI      ;DRIVE READY??
BNE    5$              ;YES!!
MOV    RMDSI,$BDDAT    ;BAD DATA FOR TYPEOUT
BIC    #^CDRY,$BDDAT
MOV    #DRY,$GDDAT     ;GOOD DATA FOR TYPEOUT
ADD    #4,(SP)
MOVB   #10,@(SP)       ;ERROR NUMBER
SUB    #2,(SP)         ;MOVE SP TO RETURN FOR ERROR
JSR    PC,@(SP)+       ;REPORT NOT READY
SUB    #10,(SP)        ;RESTORE (SP) TO ERROR N
NOP

:REPORT ERROR IF GO BIT IS NOT RESET
5$: BIT    #GO,RMCS11    ;GO BIT RESET??
    BEQ    10$          ;YES!!
    MOV    RMCS11,$BDDAT ;BAD DATA FOR TYPEOUT
    BIC    #^CGO,$BDDAT
    CLR    $GDDAT       ;GOOD DATA FOR TYPEOUT
    ADD    #4,(SP)
    MOVB   #11,@(SP)    ;ERROR NUMBER
    
```

037620				
037620	013737	001412	043454	
037626	042737	177701	043454	
037634	062716	000004		
037640	105076	000000		
037644	162716	000004		
037650	032737	000200	001350	
037656	001024			
037660	013737	001350	001142	
037666	042737	177577	001142	
037674	012737	000200	001140	
037702	062716	000004		
037706	112776	000010	000000	
037714	162716	000002		
037720	004736			
037722	162716	000010		
037726	000240			
037730	032737	000001	001336	
037736	001423			
037740	013737	001336	001142	
037746	042737	177776	001142	
037754	005037	001140		
037760	062716	000004		
037764	112776	000011	000000	


```

58 037772 162716 000002      SUB      #2,(SP)      ;MOVE SP TO RETURN FOR ERROR
59 037776 004736              JSR      PC,@(SP)+   ;REPORT DEVICE NOT AVAILABLE
60 040000 162716 000010      SUB      #10,(SP)   ;RESTORE (SP)
61 040004 000240              NOP
62
63
64 040006 013737 001336 001142 ;REPORT ERROR IF FUNCTION CODE READ FROM DEVICE IS NOT CORRECT
65 040014 042737 177701 001142 10$:  MOV      RMCS11,$BDDAT ;IS FUNCTION CODE CORRECT??
66 040022 013737 043454 001140      BIC      #^C76,$BDDAT
67 040030 023737 001142 001140      MOV      515$,$GDDAT ;EXPECTED FUNCTION CODE
68 040036 001413              CMP      $BDDAT,$GDDAT
69 040040 062716 000004              BEQ      15$         ;YES!!
70 040044 112776 000012 000000      ADD      #4,(SP)
71 040052 162716 000002              MOVVB   #12,@(SP)   ;ERROR NUMBER
72 040056 004736              SUB      #2,(SP)   ;MOVE SP TO RETURN FOR ERROR
73 040060 162716 000010      JSR      PC,@(SP)+ ;REPORT WRONG FUNCTION CODE
74 040064 000240              SUB      #10,(SP)  ;RESTORE (SP)
75 040066
76
77
78
79 040066 005037 001140              CLR      $GDDAT     ;EXPECT 'ERR' = 0
80 040072 005737 001352              TST      RMER1I     ;IS RMER1 = 0??
81 040076 001003              BNE      20$        ;NO!!
82 040100 005737 001400              TST      RMER2I     ;IS RMERZ = 0??
83 040104 001403              BEQ      25$        ;YES!!
84 040106 052737 040000 001140 20$:  BIS      #ERR,$GDDAT ;'ERR' SOULD BE SET
85 040114 013737 001350 001142 25$:  MOV      RMDSI,$BDDAT
86 040122 042737 137777 001142      BIC      #^CERR,$BDDAT
87 040130 023737 001140 001142      CMP      $GDDAT,$BDDAT ;IS 'ERR' OK??
88 040136 001412              BEQ      30$        ;YES!!
89 040140 062716 000004              ADD      #4,(SP)   ;MOVE SP TO USER'S ERROR
90 040144 112776 000047 000000      MOVVB   #47,@(SP) ;WRITE ERROR NUMBER
91 040152 162716 000002              SUB      #2,(SP)   ;MOVE SP TO ERROR RETURN
92 040156 004736              JSR      PC,@(SP)+ ;REPORT INVALID COMP ERROR
93 040160 162716 000010      SUB      #10,(SP)
94
95
96
97
98 040164 005037 001140              ;REPORT AN ERROR IF 'TRE' IS SET AND NONE OF THE BITS WHICH SET
99 040170 013746 001346              ;TRE IS SET, OR IF TRE IS NOT SET AND ONE OR MORE BITS WHICH
100 040174 042726 000377              ;SET TRE IS SET
101 040200 001010              30$:  CLR      $GDDAT     ;EXPECT 'TRE' = 0
102 040202 032737 040000 001350      MOV      RMCS2I,-(SP) ;WAS DLT, WCE, UPE, NED, NEM
103 040210 001407              BIC      #377,(SP)+ ;PGE, MXF OR MDPE SET
104 040212 022737 000030 043454      BNE      35$        ;YES!!
105 040220 103003              BIT      #ERR,RMDSI ;WAS EXCEPTION RECEIVED??
106 040222 052737 040000 001140 35$:  BEQ      40$        ;NO!!
107 040230 013737 001336 001142 40$:  CMP      #SEARCH,515$ ;WAS DATA TRANSFERRED??
108 040236 042737 137777 001142      BHIS    40$        ;NO!!
109 040244 023737 001140 001142      BIS      #TRE,$GDDAT ;'TRE' SHOULD BE SET
110 040252 001413              MOV      RMCS1I,$BDDAT ;BAD DATA FOR TYPEOUT
111 040254 062716 000004              BIC      #^CTRE,$BDDAT
112 040260 112776 000014 000000      CMP      $GDDAT,$BDDAT ;IS 'TRE' OK??
113 040266 162716 000002              BEQ      45$        ;YES!!
114 040272 004736              ADD      #4,(SP)   ;MOVE SP TO USER'S ERROR CALL
                          MOVVB   #14,@(SP) ;WRITE ERROR NUMBER
                          SUB      #2,(SP) ;MOVE SP TO RETURN FOR ERROR
                          JSR      PC,@(SP)+ ;REPORT TRE ERROR
    
```

```

115 040274 162716 000010          SUB #10,(SP)      ;RESTORE (SP)
116 040300 000240          NOP
117 040302          45$:
118
119          ;*****
120          ;USING THE FUNCTION CODE TABLE, CHECK FOR THE FOLLOWING ERRORS:
121          ;.STATUS BITS NOT SET THAT SHOULD BE SET, E.G., ATA AND ILF
122          ;.STATUS BITS SET THAT SHOULD NOT BE SET, E.G., WCE AND ECH
123          ;NOTE THAT SOME ERROR BITS ARE CONDITIONAL ON THE COMMAND AND OTHER
124          ;STATUS CONDITIONS, E.G., WRITE LOCK ERROR SHOULD ONLY BE SET IF
125          ;WRITE LOCK IS ON AND THE COMMAND IS A WRITE.
126
127          ;GET AND STORE THE ENTRY FROM THE FUNCTION CODE TABLE
128 040302 010046          MOV R0,-(SP)      ;:PUSH R0 ON STACK
129 040304 013700 043454      MOV 515$,R0      ;:GET FUNCTION CODE
130 040310 016037 064566 043446  MOV FNCDTB(R0),500$ ;:STORE ENTRY
131 040316 012600          MOV (SP)+,R0     ;:POP STACK INTO R0
132
133          ;REPORT AN ERROR IF AN UNEXPECTED ATTENTION OCCURRED OR IF
134          ;ATA IS NOT SET AND SHOULD BE SET.
135 040320 013737 043446 001140  MOV 500$,$GDDAT  ;:GET EXPECTED ATA STATUS
136 040326 032737 040000 001350  BIT #ERR,RMDSI   ;:IS COMPOSITE ERROR SET ??
137 040334 001403          BEQ 50$         ;:NO !!
138 040336 052737 100000 001140  BIS #ATA,$GDDAT ;:EXPECT AN ATTENTION
139 040344 042737 077777 001140 50$: BIC #^CATA,$GDDAT ;:STRIP DONT CARES
140 040352 013737 001350 001142  MOV RMDSI,$BDDAT ;:GET RECEIVED ATA
141 040360 042737 077777 001142  BIC #^CATA,$BDDAT ;:STRIP DONT CARES
142 040366 023737 001140 001142  CMP $GDDAT,$BDDAT ;:IS ATA OK ??
143 040374 001413          BEQ 55$         ;:YES !!
144 040376 062716 000004          ADD #4,(SP)     ;:MOVE SP TO USERS ERROR CALL
145 040402 112776 000006 000000  MOVB #6,@(SP)   ;:LOAD ERROR # IN CALL
146 040410 162716 000002          SUB #2,(SP)     ;:MOVE SP TO ERROR RETURN
147 040414 004736          JSR PC,@(SP)+   ;:REPORT ERROR
148 040416 162716 000010          SUB #10,(SP)   ;:RESTORE SP
149 040422 000240          NOP
150 040424          55$:
151
152          ;REPORT ERROR IF ILF IS INCORRECT, I.E., IF ILF DOES NOT COMPARE
153          ;WITH FUNCTION CODE TABLE
154 040424 013737 043446 001140  MOV 500$,$GDDAT  ;:GET EXPECTED ILF
155 040432 042737 177776 001140  BIC #^CILF,$GDDAT ;:CLEAR ALL OTHER BITS
156 040440 013737 001352 001142  MOV RMER1I,$BDDAT ;:GET RECEIVED ILF
157 040446 042737 177776 001142  BIC #^CILF,$BDDAT ;:CLEAR ALL OTHER BITS
158 040454 023737 001140 001142  CMP $GDDAT,$BDDAT ;:IS ILF OK ??
159 040462 001412          BEQ 60$         ;:YES !!
160 040464 062716 000004          ADD #4,(SP)     ;:MOVE SP TO USERS ERROR CALL
161 040470 112776 000254 000000  MOVB #254,@(SP) ;:WRITE ERROR NUMBER IN CALL
162 040476 162716 000002          SUB #2,(SP)     ;:MOVE SP TO ERROR RETURN
163 040502 004736          JSR PC,@(SP)+   ;:REPORT ERROR AND RETURN
164 040504 162716 000010          SUB #10,(SP)   ;:MOVE SP TO NO ERROR
165 040510 005037 001140 60$: CLR $GDDAT      ;:CLEAR EXPECTED STATUS
166
167          ;REPORT AN ERROR IF WCE IS SET AND SHOULD NOT BE SET
168 040514 013746 043446          MOV 500$,-(SP)  ;:GET WCE STATUS ENABLE
169 040520 052716 137777          BIS #^CWCE,(SP) ;:SET ALL OTHER BITS
170 040524 013737 001346 001142  MOV RMCS2I,$BDDAT ;:RECEIVED STATUS
171 040532 042637 001142          BIC (SP)+,$BDDAT ;:CLEAR WCE IF ENABLED
    
```



```

172 040536 001412          BEQ      90$          :BRANCH IF WCE OK
173 040540 062716 000004    ADD      #4,(SP)      :MOVE SP TO USER'S ERROR CALL
174 040544 112776 000026 000000    MOVB    #26,@(SP)    :WRITE ERROR NUMBER
175 040552 162716 000002    SUB      #2,(SP)      :MOVE SP TO ERROR RETURN
176 040556 004736          JSR     PC,@(SP)+     :REPORT ERROR
177 040560 162716 000010    SUB      #10,(SP)     :RESTORE ERROR
178 040564
179
180          90$:
181 040564 013746 043446          :REPORT ERROR IF OPI STATUS IS SET AND SHOULD NOT BE SFT
182 040570 052716 157777    MOV     500$,-(SP)    :GET OPI STATUS ENABLE
183 040574 013737 001352 001142    BIS     #^COPI,(SP)   :SET ALL OTHER BITS
184 040602 042637 001142    MOV     RMER1I,$BDDAT :GET RECEIVED STATUS
185 040606 001412          BIC     (SP)+,$BDDAT  :CLEAR OPI IF ENABLED
186 040610 062716 000004    BEQ     100$         :BRANCH IF OPI OK
187 040614 112776 000164 000000    ADD     #4,(SP)      :MOVE SP TO USER'S ERROR CALL
188 040622 162716 000002    MOVB    #164,@(SP)   :WRITE ERROR NUMBER IN CALL
189 040626 004736          SUB     #2,(SP)      :MOVE SP TO ERROR RETURN
190 040630 162716 000010    JSR     PC,@(SP)+     :REPORT ERROR
191 040634          SUB     #10,(SP)     :RESTORE SP
192
193          100$:
194          :REPORT ERROR IF IVC IS SET AND IS NOT ENABLED OR IF IVC IS
195          :SET AND VV IS NOT RESET
196 040634 013746 043446          MOV     500$,-(SP)    :GET IVC STATUS ENABLE
197 040640 032737 000100 001350    BIT     #VV,RMDSI     :IS VV SET
198 040646 001402          BEQ     105$         :NO !!
199 040650 042716 010000    BIC     #IVC,(SP)    :YES - IVC SHOULD BE 0
200 040654 052716 167777 105$:    BIS     #^CIVC,(SP)  :SET ALL OTHER BITS
201 040660 013737 001400 001142    MOV     RMER2I,$BDDAT :GET RECEIVED STATUS
202 040666 042637 001142    BIC     (SP)+,$BDDAT :CLEAR IVC IF ENABLED
203 040672 001412          BEQ     110$         :BRANCH IF IVC OK
204 040674 062716 000004    ADD     #4,(SP)      :MOVE SP TO USERS ERROR CALL
205 040700 112776 000165 000000    MOVB    #165,@(SP)   :WRITE ERROR NUMBER IN CALL
206 040706 162716 000002    SUB     #2,(SP)      :MOVE SP TO ERROR RETURN
207 040712 004736          JSR     PC,@(SP)+     :REPORT ERROR
208 040714 162716 000010    SUB     #10,(SP)     :RESTORE SP TO NO ERROR
209
210          110$:
211          :BIT 11 (WLE) OF THE FUNCTION CODE TABLE IS THE ENABLING BIT FOR
212          :ALL WRITE ERRORS, I.E.,
213          :   RMER1 - WLE, WCF
214          :   RMER2 - DPE
215          :   RMCS2 - UPE.
216          :EACH OF THESE ERRORS IS CHECKED TO SEE IF AN ERROR IS SET WHEN THE
217          :WRITE ERROR ENABLE BIT IS RESET.
218
219          :REPORT AN ERROR IF WLE IS SET AND WRITE ERRORS ARE NOT ENABLED, OR IF
220          :THE DRIVE IS NOT WRITE PROTECTED
221 040720 012746 177777          MOV     #-1,-(SP)    :ASSUME WRITE ERRORS ENABLED
222 040724 032737 004000 043446    BIT     #WLE,500$    :ARE WRITE ERRORS ENABLED ??
223 040732 001404          BEQ     115$         :NO !!
224 040734 032737 004000 001350    BIT     #WRL,RMDSI   :IS THE DRIVE WRITE PROTECTED ??
225 040742 001002          BNE     120$         :YES !!
226 040744 042716 004000 115$:    BIC     #WLE,(SP)    :RESET WLE ENABLE
227 040750 013737 001352 001142 120$:    MOV     RMER1I,$BDDAT :GET RECEIVED STATUS
228 040756 042637 001142    BIC     (SP)+,$BDDAT :CLEAR WLE IF ENABLED
229 040762 001412          BEQ     125$         :BRANCH IF WLE OK

```



```

229 040764 062716 000004          ADD    #4,(SP)          :MOVE SP TO USERS ERROR CALL
230 040770 112776 000023 000000    MOVB   #23,@(SP)       :WRITE ERROR NUMBER IN CALL
231 040776 162716 000002          SUB    #2,(SP)         :MOVE SP TO ERROR RETURN
232 041002 004736          JSR    PC,@(SP)+       :REPORT ERROR AND RETURN
233 041004 162716 000010          SUB    #10,(SP)        :RESTORE SP TO NO ERROR
234 041010          125$:
235
236          :REPORT ERROR IF WCF IS SET AND WRITE ERRORS ARE NOT ENABLED
237 041010 012746 177777          MOV    #-1,-(SP)       :ASSUME WRITE ERRORS ENABLED
238 041014 032737 004000 043446    BIT    #WLE,500$       :ARE WRITE ERRORS ENABLED ??
239 041022 001002          BNE    130$            :YES !!
240 041024 042716 000040          BIC    #WCF,(SP)       :DISABLE WCF ERROR
241 041030 013737 001352 001142 130$:  MOV    RMER1I,$BDDAT    :GET RECEIVED STATUS
242 041036 042637 001142          BIC    (SP)+,$BDDAT    :RESET WCF IF ENABLED
243 041042 001412          BEQ    135$            :BRANCH IF WCF OK
244 041044 062716 000004          ADD    #4,(SP)         :MOVE SP TO USERS ERROR CALL
245 041050 112776 000025 000000    MOVB   #25,@(SP)       :WRITE ERROR NUMBER IN CALL
246 041056 162716 000002          SUB    #2,(SP)         :MOVE SP TO ERROR RETURN
247 041062 004736          JSR    PC,@(SP)+       :REPORT ERROR
248 041064 162716 000010          SUB    #10,(SP)        :RESTORE SP TO NO ERROR
249 041070          135$:
250
251          :REPORT ERROR IF DPE IS SET AND WRITE ERRORS ARE NOT ENABLED
252 041070 012746 177777          MOV    #-1,-(SP)       :ASSUME WRITE ERRORS ARE ENABLED
253 041074 032737 004000 043446    BIT    #WLE,500$       :ARE WRITE ERRORS ENABLED ??
254 041102 001002          BNE    140$            :YES !!
255 041104 042716 000010          BIC    #DPE,(SP)       :RESET DPE ENABLE
256 041110 013737 001400 001142 140$:  MOV    RMER2I,$BDDAT    :GET RECEIVED STATUS
257 041116 042637 001142          BIC    (SP)+,$BDDAT    :RESET DPE IF ENABLED
258 041122 001412          BEQ    145$            :BRANCH IF DPE OK
259 041124 062716 000004          ADD    #4,(SP)         :MOVE SP TO USERS ERROR CALL
260 041130 112776 000040 000000    MOVB   #40,@(SP)       :WRITE ERROR NUMBER IN CALL
261 041136 162716 000002          SUB    #2,(SP)         :MOVE SP TO ERROR RETURN
262 041142 004736          JSR    PC,@(SP)+       :REPORT ERROR
263 041144 162716 000010          SUB    #10,(SP)        :RESTORE SP TO NO ERROR
264 041150          145$:
265
266          :REPORT AN ERROR IF UPE IS SET AND WRITE ERRORS ARE NOT ENABLED
267 041150 012746 177777          MOV    #-1,-(SP)       :ASSUME WRITE ERRORS ARE ENABLED
268 041154 032737 004000 043446    BIT    #WLE,500$       :ARE WRITE ERRORS ENABLED ??
269 041162 001002          BNE    150$            :YES !!
270 041164 042716 020000          BIC    #UPE,(SP)       :DISABLE UPE ERROR
271 041170 013737 001346 001142 150$:  MOV    RMCS2I,$BDDAT    :GET RECEIVED STATUS
272 041176 042637 001142          BIC    (SP)+,$BDDAT    :RESET UPE IF ENABLED
273 041202 001412          BEQ    155$            :BRANCH IF UPE OK
274 041204 062716 000004          ADD    #4,(SP)         :MOVE SP TO USERS ERROR CALL
275 041210 112776 000024 000000    MOVB   #24,@(SP)       :WRITE ERROR NUMBER IN CALL
276 041216 162716 000002          SUB    #2,(SP)         :MOVE SP TO ERROR RETURN
277 041222 004736          JSR    PC,@(SP)+       :REPORT ERROR AND RETURN
278 041224 162716 000010          SUB    #10,(SP)        :MOVE SP TO NO ERROR
279 041230          155$:
280
281          :REPORT AN ERROR IF IAE IS SET AND IS NOT ENABLED
282 041230 013746 043446          MOV    500$,-(SP)      :GET IAE ENABLE
283 041234 052716 175777          BIS    #^CIAE,(SP)     :SET ALL OTHER BITS
284 041240 013737 001352 001142    MOV    RMER1I,$BDDAT    :GET RECEIVED STATUS
285 041246 042637 001142          BIC    (SP)+,$BDDAT    :CLEAR IAE IF ENABLED

```



```

286 041252 001412          BEQ      160$          :BRANCH IF IAE IS OK
287 041254 062716 000004    ADD      #4,(SP)       :MOVE SP TO USERS ERROR CALL
288 041260 112776 000166 000000  MOVVB   #166,@(SP)    :WRITE ERROR NUMBER
289 041266 162716 000002    SUB      #2,(SP)       :MOVE SP TO ERROR RETURN
290 041272 004736          JSR     PC,@(SP)+     :REPORT ERROR AND RETURN
291 041274 162716 000010    SUB      #10,(SP)      :MOVE SP TO NO ERROR
292 041300          160$:
293
294          :BIT 09 (AOE) OF THE FUNCTION CODE TABLE IS THE ENABLING BIT FOR
295          : ALL READ/WRITE ERRORS, I.E.,
296          :
297          : RMCS1 - TRE
298          : RMCS2 - DLT,NEM,MXF
299          : RMDS - LBT
300          : RMER1 - AOE
301          :NOTE:
302          : LBT IS NOT CHECKED BECAUSE IT ONLY RESETS WHEN THE DESIRED
303          : CYLINDER REGISTER IS WRITTEN
304          :NOTE:
305          : AOE CANNOT BE SET IF LBT IS NOT ALSO SET
306          :NOTE:
307          : TRE IS CHECKED AS A FUNCTION OF OTHER ERROR CONDITONS ABOVE
308
309          :REPORT AN ERROR IF DLT IS SET AND READ/WRITE ERRORS ARE NOT ENABLED
310 041300 012746 177777          MOV      #-1,-(SP)    :ASSUME ERRORS ARE ENABLED
311 041304 032737 001000 043446    BIT      #AOE,500$    :ARE ERRORS ENABLED ??
312 041312 001002          BNE      165$        :YES !!
313 041314 042716 100000          BIC      #DLT,(SP)    :RESET DLT ENABLE
314 041320 013737 001346 001142 165$: MOV      RMCS2I,$BDDAT :GET RECEIVED STATUS
315 041326 042637 001142          BIC      (SP)+,$BDDAT :CLEAR DLT IF ENABLED
316 041332 001412          BEQ      170$        :BRANCH IF DLT IS OK
317 041334 062716 000004    ADD      #4,(SP)       :MOVE SP TO USERS ERROR CALL
318 041340 112776 000032 000000  MOVVB   #32,@(SP)    :WRITE ERROR NUMBER IN CALL
319 041346 162716 000002    SUB      #2,(SP)       :MOVE SP TO ERROR RETURN
320 041352 004736          JSR     PC,@(SP)+     :REPORT ERROR AND RETURN
321 041354 162716 000010    SUB      #10,(SP)      :MOVE SP TO NO ERROR
322 041360          170$:
323
324          :REPORT ERROR IF NEM IS SET AND READ/WRITE ERRORS ARE NOT ENABLED
325 041360 012746 177777          MOV      #-1,-(SP)    :ASSUME ERRORS ARE ENABLED
326 041364 032737 001000 043446    BIT      #AOE,500$    :ARE ERRORS ENABLED ??
327 041372 001002          BNE      175$        :YES !!
328 041374 042716 004000          BIC      #NEM,(SP)    :DISABLE NEM
329 041400 013737 001346 001142 175$: MOV      RMCS2I,$BDDAT :GET RECEIVED STATUS
330 041406 042637 001142          BIC      (SP)+,$BDDAT :CLEAR NEM IF ENABLED
331 041412 001412          BEQ      180$        :BRANCH IF NEM IS OK
332 041414 062716 000004    ADD      #4,(SP)       :MOVE SP TO USERS ERROR CALL
333 041420 112776 000167 000000  MOVVB   #167,@(SP)    :WRITE ERROR NUMBER IN CALL
334 041426 162716 000002    SUB      #2,(SP)       :MOVE SP TO ERROR RETURN
335 041432 004736          JSR     PC,@(SP)+     :REPORT ERROR AND RETURN
336 041434 162716 000010    SUB      #10,(SP)      :MOVE SP TO NO ERROR
337 041440          180$:
338
339          :REPORT ERROR IF MXF IS SET AND READ/WRITE ERRORS ARE NOT ENABLED
340 041440 012746 177777          MOV      #-1,-(SP)    :ASSUME ERRORS ARE ENABLED
341 041444 032737 001000 043446    BIT      #AOE,500$    :ARE DATA ERRORS ENABLED ??
342 041452 001002          BNE      185$        :YES !!

```

```

343 041454 042716 001000      BIC      #MXF,(SP)      :DISABLE MXF ERROR
344 041460 013737 001346 001142 185$: MOV      RMCS2I,$BDDAT  :GET RECEIVED STATUS
345 041466 042637 001142      BIC      (SP)+,$BDDAT :CLEAR MXF IF ENABLED
346 041472 001412      BEQ      190$         :BRANCH IF MXF IS OK
347 041474 062716 000004      ADD      #4,(SP)      :MOVE SP TO USERS ERROR CALL
348 041500 112776 000033 000000  MOVB     #33,@(SP)    :WRITE ERROR NUMBER IN CALL
349 041506 162716 000002      SUB      #2,(SP)      :MOVE SP TO ERROR RETURN
350 041512 004736      JSR      PC,@(SP)+    :REPORT ERROR AND RETURN
351 041514 162716 000010      SUB      #10,(SP)     :MOVE SP TO NO ERROR
352 041520      190$:
353
354      ;REPORT ERROR IF AOE IS SET AND DATA ERRORS ARE NOT ENABLED
355 041520 012746 177777      MOV      #-1,-(SP)    :ASSUME DATA ERRORS ARE ENABLED
356 041524 032737 001000 043446  BIT      #AOE,500$    :ARE DATA ERRORS EAMBLED ??
357 041532 001404      BEQ      191$         :NO !!
358 041534 032737 002000 001350  BIT      #LBT,RMDS!   :IS LBT ALSO SET ??
359 041542 001002      BNE      195$         :YES !!
360 041544 042716 001000 191$: BIC      #AOE,(SP)    :DISABLE AOE
361 041550 013737 001352 001142 195$: MOV      RMER1I,$BDDAT :GET RECEIVED STATUS
362 041556 042637 001142      BIC      (SP)+,$BDDAT :CLEAR AOE IF ENABLED
363 041562 001412      BEQ      200$         :BRANCH IF AOE IS OK
364 041564 062716 000004      ADD      #4,(SP)      :MOVE SP TO USERS ERROR CALL
365 041570 112776 000020 000000  MOVB     #20,@(SP)    :WRITE ERROR NUMBER
366 041576 162716 000002      SUB      #2,(SP)      :MOVE SP TO ERROR RETURN
367 041602 004736      JSR      PC,@(SP)+    :REPORT ERROR AND RETURN
368 041604 162716 000010      SUB      #10,(SP)     :MOVE SP TO NO ERROR
369 041610      200$:
370
371      ;BIT 07 (HCE) OF THE FUNCTION CODE TABLE IS THE ENABLING BIT FOR
372      ;HEADER ERRORS, I.E.,
373      ;   RMER1 - HCRC,HCE,FER
374      ;   RMER2 - BSE
375
376      ;RESET THE ENABLING BIT (HCE) IF HEADER COMPARE INHIBIT IS SET
377 041610 032737 002000 001370  BIT      #HCI,RMOFI   :IS HCI SET ??
378 041616 001403      BEQ      201$         :NO !!
379 041620 042737 000200 043446  BIC      #HCE,500$    :YES - DISABLE ALL HEADER ERRORS
380 041626      201$:
381
382      ;REPORT AN ERROR IF HCRC IS SET AND HEADER ERRORS ARE NOT ENABLED
383 041626 012746 177777      MOV      #-1,-(SP)    :ASSUME ERRORS ENABLED
384 041632 032737 000200 043446  BIT      #HCE,500$    :ARE HEADER ERRORS ENABLED ??
385 041640 001002      BNE      205$         :YES !!
386 041642 042716 000400      BIC      #HCRC,(SP)   :DISABLE HCRC
387 041646 013737 001352 001142 205$: MOV      RMER1I,$BDDAT :GET RECEIVED STATUS
388 041654 042637 001142      BIC      (SP)+,$BDDAT :RESET HCRC IF ENABLED
389 041660 001412      BEQ      210$         :BRANCH IF HCRC IS OK
390 041662 062716 000004      ADD      #4,(SP)      :MOVE SP TO USERS ERROR CALL
391 041666 112776 000035 000000  MOVB     #35,@(SP)    :WRITE ERROR NUMBER IN CALL
392 041674 162716 000002      SUB      #2,(SP)      :MOVE SP TO ERROR RETURN
393 041700 004736      JSR      PC,@(SP)+    :REPORT ERROR AND RETURN
394 041702 162716 000010      SUB      #10,(SP)     :MOVE SP TO NO ERROR
395 041706      210$:
396
397      ;REPORT ERROR IF HCE IS SET AND HEADER ERRORS ARE NOT ENABLED
398 041706 012746 177777      MOV      #-1,-(SP)    :ASSUME ERRORS ENABLED
399 041712 032737 000200 043446  BIT      #HCE,500$    :ARE ERRORS ENABLED ??
    
```



```

400 041720 001002          BNE      215$      :YES !!
401 041722 042716 000200  BIC      #HCE,(SP) :DISABLE HCE
402 041726 013737 001352 001142 215$: MOV      RMER1I,$BDDAT :GET RECEIVED STATUS
403 041734 042637 001142  BIC      (SP)+,$BDDAT :CLEAR HCE IF ENABLED
404 041740 001412          BEQ      220$      :BRANCH IF HCE IS OK
405 041742 062716 000004  ADD      #4,(SP)    :MOVE SP TO USERS ERROR CALL
406 041746 112776 000036 000000  MOVVB   #36,@(SP)  :WRITE ERROR NUMBER IN CALL
407 041754 162716 000002  SUB      #2,(SP)    :MOVE SP TO ERROR RETURN
408 041760 004736          JSR      PC,@(SP)+ :REPORT ERROR AND RETURN
409 041762 162716 000010  SUB      #10,(SP)   :MOVE SP TO NO ERROR
410 041766          220$:
411
412          ;REPORT ERRGR IF FER IS SET AND HEADER ERRORS ARE NOT ENABLED
413 041766 012746 177777  MOV      #-1,-(SP)  :ASSUME FER IS ENABLED
414 041772 032737 000200 043446  BIT      #HCE,500$  :ARE HEADER ERRORS ENABLED ??
415 042000 001002          BNE      225$      :YES !!
416 042002 042716 000020  BIC      #FER,(SP)  :DISABLE FER
417 042006 013737 001352 001142 225$: MOV      RMER1I,$BDDAT :GET RECEIVED STATUS
418 042014 042637 001142  BIC      (SP)+,$BDDAT :RESET FER IF ENABLED
419 042020 001412          BEQ      230$      :BRANCH IF FER OK
420 042022 062716 000004  ADD      #4,(SP)    :MOVE SP TO USERS ERROR CALL
421 042026 112776 000037 000000  MOVVB   #37,@(SP)  :WRITE ERROR NUMBER IN CALL
422 042034 162716 000002  SUB      #2,(SP)    :MOVE SP TO ERROR RETURN
423 042040 004736          JSR      PC,@(SP)+ :REPORT ERROR AND RETURN
424 042042 162716 000010  SUB      #10,(SP)   :MOVE SP TO NO ERROR
425 042046          230$:
426
427          ;REPORT ERROR IF BSE IS SET AND HEADER ERRORS ARE NOT ENABLED
428 042046 012746 177777  MOV      #-1,-(SP)  :ASSUME ERRORS ENABLED
429 042052 032737 000200 043446  BIT      #HCE,500$  :ARE THEY ENABLED ??
430 042060 001002          BNE      235$      :YES !!
431 042062 042716 100000  BIC      #BSE,(SP)  :DISABLE BSE
432 042066 013737 001400 001142 235$: MOV      RMER2I,$BDDAT :GET RECEIVED STATUS
433 042074 042637 001142  BIC      (SP)+,$BDDAT :CLEAR BSE IF ENABLED
434 042100 001412          BEQ      240$      :BRANCH IF BSE OK
435 042102 062716 000004  ADD      #4,(SP)    :MOVE SP TO USERS ERROR CALL
436 042106 112776 000354 000000  MOVVB   #354,@(SP) :WRITE ERROR NUMBER
437 042114 162716 000002  SUB      #2,(SP)    :MOVE SP TO ERROR RETURN
438 042120 004736          JSR      PC,@(SP)+ :REPORT ERROR AND RETURN
439 042122 162716 000010  SUB      #10,(SP)   :MOVE SP TO NO ERROR
440 042126          240$:
441
442          ;BIT 06 OF THE FUNCTION CODE TABLE IS THE ENABLING BIT FOR DATA
443          ;FIELD ERRORS, I.E.,
444          ;      RMCS2 - MDPE
445          ;      RMER1 - DCK,ECH
446          ;NOTE:
447          ;      ECH CANNOT SET UNLESS IT IS ENABLED AND ECI IS RESET AND
448          ;      DCK IS SET.
449
450          ;REPORT ERROR IF MDPE IS SET AND IS NOT ENABLED
451 042126 012746 177777  MOV      #-1,-(SP)  :ASSUME ENABLED
452 042132 032737 000100 043446  BIT      #ECH,500$  :ARE DATA FIELD ERRORS ENABLED ??
453 042140 001002          BNE      245$      :YES !!
454 042142 042716 000400  BIC      #MDPE,(SP) :DISBALE MDPE
455 042146 013737 001346 001142 245$: MOV      RMCS2I,$BDDAT :GET RECEIVED STATUS
456 042154 042637 001142  BIC      (SP)+,$BDDAT :CLEAR MDPE IF ENABLED
    
```

457	042160	001412			BEQ	250\$:BRANCH IF MDPE OK	
458	042162	062716	000004		ADD	#4,(SP)	:MOVE SP TO USERS ERROR CALL	
459	042166	112776	000027	000000	MOVB	#27,@(SP)	:WRITE ERROR NUMBER IN CALL	
460	042174	162716	000002		SUB	#2,(SP)	:MOVE SP TO ERROR RETURN	
461	042200	004736			JSR	PC,@(SP)+	:REPORT ERROR AND RETURN	
462	042202	162716	000010		SUB	#10,(SP)	:MOVE SP TO NO ERROR	
463	042206			250\$:				
464								
465					:REPORT	ERROR IF DCK IS SET AND	DATA FIELD ERRORS ARE NOT ENABLED	
466	042206	012746	177777		MOV	#-1,-(SP)	:ASSUME ENABLED	
467	042212	032737	000100	043446	BIT	#ECH,500\$:ARE THEY ENABLED ??	
468	042220	001002			BNE	255\$:YES !!	
469	042222	042716	100000		BIC	#DCK,(SP)	:DISABLE DCK	
470	042226	013737	001352	001142	255\$:	MOV	RMER1I,\$BDDAT	:GET RECEIVED STATUS
471	042234	042637	001142		BIC	(SP)+,\$BDDAT	:CLEAR DCK IF ENABLED	
472	042240	001412			BEQ	260\$:BRANCH IF DCK IS OK	
473	042242	062716	000004		ADD	#4,(SP)	:MOVE SP TO USERS ERROR CALL	
474	042246	112776	000030	000000	MOVB	#30,@(SP)	:WRITE ERROR NUMBER IN CALL	
475	042254	162716	000002		SUB	#2,(SP)	:MOVE SP TO ERROR RETURN	
476	042260	004736			JSR	PC,@(SP)+	:REPORT ERROR AND RETURN	
477	042262	162716	000010		SUB	#10,(SP)	:MOVE SP TO NO ERROR	
478	042266			260\$:				
479								
480					:REPORT	ERROR IF ECH IS SET AND,		
481					:	DATA FIELD ERRORS ARE NOT ENABLED, OR		
482					:	ECI IS SET, OR		
483					:	DCK IS NOT SET.		
484	042266	012746	177777		MOV	#-1,-(SP)	:ASSUME ENABLED	
485	042272	032737	000100	043446	BIT	#ECH,500\$:ARE ERRORS ENABLED ??	
486	042300	001410			BEQ	265\$:NO !!	
487	042302	032737	004000	001370	BIT	#ECI,RMOFI	:IS ECI SET ??	
488	042310	001004			BNE	265\$:YES !!	
489	042312	032737	100000	001352	BIT	#DCK,RMER1I	:IS DCK ALSO SET ??	
490	042320	001002			BNE	270\$:YES !!	
491	042322	042716	000100		265\$:	BIC	#ECH,(SP)	:DISABLE ECH
492	042326	013737	001352	001142	270\$:	MOV	RMER1I,\$BDDAT	:GET RECEIVED STATUS
493	042334	042637	001142		BIC	(SP)+,\$BDDAT	:CLEAR ECH IF ENABLED	
494	042340	001412			BEQ	275\$:BRANCH IF ECH IS OK	
495	042342	062716	000004		ADD	#4,(SP)	:MOVE SP TO USERS ERROR CALL	
496	042346	112776	000031	000000	MOVB	#31,@(SP)	:WRITE ERROR NUMBER IN CALL	
497	042354	162716	000002		SUB	#2,(SP)	:MOVE SP TO ERROR RETURN	
498	042360	004736			JSR	PC,@(SP)+	:REPORT ERROR AND RETURN	
499	042362	162716	000010		SUB	#10,(SP)	:MOVE SP TO NO ERROR	
500	042366			275\$:				


```

1
2
3
4
5 042366 022737 000030 043454      CMP      #SEARCH,515$      ;WAS DATA TRANSFERRED ?
6 042374 103402                      BLO      280$              ;BR IF YES
7 042376 000137 043420              JMP      355$              ;NO - EXIT
8
9
10 042402 013737 001340 001142      ;REPORT ERROR IF RMWC NOT ZERO AND TRE IS ZERO
11 042410 001421                      280$:  MOV      RMWCI,$BDDAT      ;WORD COUNT ZERO??
12 042412 032737 040000 001336      BEQ      285$              ;YES
13 042420 001015                      BIT      #TRE,RMCS1I      ;TRANSFER ERROR DETECTED??
14 042422 062716 000004              BNE      285$              ;YES!!
15 042426 112776 000015 000000      ADD      #4,(SP)          ;ERROR NUMBER
16 042434 005037 001140              MOVVB   #15,@(SP)         ;GOOD DATA FOR TYPEOUT
17 042440 162716 000002              CLR      $GDDAT           ;MOVE SP TO RETURN FOR ERROR
18 042444 004736                      SUB      #2,(SP)          ;REPORT WORD COUNT NOT ZERO
19 042446 162716 000010              JSR     PC,@(SP)+         ;RESTORE (SP)
20 042452 000240                      SUB      #10,(SP)
21
22
23 042454 013737 001340 001140      ;REPORT ERROR IF RMBA IS NOT CORRECT
24 042462 163737 001414 001140      285$:  MOV      RMWCI,$GDDAT      ;GET WORD COUNT AT END OF TRANSFER AND
25 042470 006337 001140              SUB      RMWCO,$GDDAT      ;SUBTRACT STARTING WORD COUNT.
26 042474 063737 001416 001140      ASL      $GDDAT           ;* 2
27
28 042502 032737 000010 001346      ADD      RMBAO,$GDDAT      ;ADD STARTING BUS ADDRESS
29 042510 001403                      BIT      #BAI,RMCS2I      ;WAS BUS ADDRESS INHIBIT (BAI) SET ??
30 042512 013737 001416 001140      BEQ      290$              ;NO !!
31
32 042520 023737 001140 001342      MOV      RMBAO,$GDDAT      ;ADDRESS SHOULD NOT HAVE CHANGED
33 042526 001416                      290$:  CMP      $GDDAT,RMBAI      ;BUS ADDRESS OK??
34 042530 013737 001342 001142      BEQ      295$              ;YES!!
35 042536 062716 000004              MOV      RMBAI,$BDDAT      ;BAD DATA FOR TYPEOUT
36 042542 112776 000016 000000      ADD      #4,(SP)
37 042550 162716 000002              MOVVB   #16,@(SP)         ;ERROR NUMBER
38 042554 004736                      SUB      #2,(SP)          ;MOVE SP TO RETURN FOR ERROR
39 042556 162716 000010              JSR     PC,@(SP)+         ;REPORT UNEXPECTED ADDRESS
40 042562 000240                      SUB      #10,(SP)
41
42
43 042564 005046                      ;COMPUTE NUMBER OF SECTORS TRANSFERRED FROM WORD COUNT
44 042566 013746 001340              295$:  CLR      -(SP)            ;NUMBER OF SECTORS TRANSFERRED
45 042572 163716 001414              MOV      RMWCI,-(SP)       ;GET WORD COUNT AT END OF TRANSFER AND
46
47 042576 012746 000400              SUB      RMWCO,(SP)       ;SUBTRACT STARTING WORD COUNT.
48 042602 032737 000002 001412      MOV      #256,-(SP)       ;ASSUME 256. WORDS PER SECTOR
49 042610 001402                      BIT      #BIT1,RMCS1O     ;HEADER & DATA COMMAND ??
50 042612 062716 000002              BEQ      300$              ;NO !!
51
52 042616 005266 000004              ADD      #2,(SP)          ;CHANGE TO 258. WORDS PER SECTOR
53 042622 161666 000002              300$:  INC      4(SP)           ;INCREMENT SECTOR COUNT
54 042626 003373                      SUB      (SP),2(SP)       ;SUBTRACT ONE SECTOR'S WORTH
55 042630 022626                      BGT      300$              ;CONTINUE IF NOT DONE
56
57

```

;COMPUTE EXPECTED SECTOR, TRACK AND CYLINDER ADDRESS FROM

```

SECONDARY ERROR CHECK SUBROUTINE
58r
;NUMBER OF SECTORS
59 042632 013737 001446 043446 MOV RMDCO,500$ ;STORE ORIGINAL CYLINDER
60 042640 013737 001420 043450 MOV RMDAO,505$ ;STORE ORIGINAL TRACK
61 042646 013737 001420 043452 MOV RMDAO,510$ ;STORE ORIGINAL SECTOR
62 042654 013737 001334 043456 MOV LSTRK,520$ ;STORE LAST TRACK
63 042662 000337 043456 SWAB 520$ ;GET TRACK ADDRESS TO LO BYTE AND
64 042666 005237 043456 INC 520$ ;INCREMENT TO GET TOTL # OF TRACKS.
65
66 042672 042737 000377 043450 BIC #^C<TADMSK>,505$ ;SAVE TRACK ADDRESS BITS AND
67 042700 000337 043450 SWAB 505$ ;SWAP TRACK ADDRESS TO LOW BYTE.
68 042704 042737 177400 043452 BIC #^C<SADMSK>,510$ ;SAVE SECTOR ADDRESS BITS
69 042712 062637 043452 ADD (SP)+,510$
70
71 042716 023727 043452 000040 310$: CMP 510$,#32. ;SECTOR OVEFLOWED??
72 042724 103406 BLO 315$ ;NO!!
73 042726 005237 043450 INC 505$ ;INCREMENT TRACK
74 042732 162737 000040 043452 SUB #32.,510$ ;ADJUST SECTOR
75 042740 000766 BR 310$ ;TRY AGAIN
76
77 042742 023737 043450 043456 315$: CMP 505$,520$ ;TRACK OVERFLOWED??
78 042750 103407 BLO 320$ ;NO!!
79 042752 005237 043446 INC 500$ ;INCREMENT CYLINDER
80 042756 163737 043456 043450 SUB 520$,505$ ;ADJUST TRACK
81 042764 000766 BR 315$ ;TRY AGAIN
82 042766 000240 NOP
83
84 ;REPORT ERROR IF 'LBT' IS NOT CORRECT
85 042770 320$:
86 042770 005037 001140 CLR $GDDAT ;SET GOOD DATA FOR LBT = 0
87 042774 023727 043446 001466 CMP 500$,#822. ;SHOULD LBT BE SET??
88 043002 101407 BLOS 325$ ;NO!!
89 043004 032737 002000 001352 BIT #IAE,RMER1I ;WAS IAE SET ??
90 043012 001003 BNE 325$ ;YES - LBT SHOULD NOT BE SET
91 043014 012737 002000 001140 MOV #LBT,$GDDAT ;SET GOOD DATA FOR LBT = 1
92 043022 013737 001350 001142 325$: MOV RMDSI,$BDDAT ;BAD DATA FOR TYPEOUT
93 043030 042737 175777 001142 BIC #^CLBT,$BDDAT
94 043036 023737 001140 001142 CMP $GDDAT,$BDDAT ;IS LBT CORRECT??
95 043044 001413 BEQ 330$ ;YES!!
96 043046 062716 000004 ADD #4,(SP)
97 043052 112776 000017 000000 MOVB #17,@(SP) ;ERROR NUMBER
98 043060 162716 000002 SUB #2,(SP) ;MOVE SP TO RETURN FOR ERROR
99 043064 004736 JSR PC,@(SP)+ ;REPORT LBT IS WRONG
100 043066 162716 000010 SUB #10,(SP) ;RESTORE (SP)
101 043072 000240 NOP
102
103 ;REPORT ERROR IF 'AOE' IS INCORRECT
104 043074 005037 001140 330$: CLR $GDDAT ;SET FOR AOE = 0
105 043100 032737 002000 001352 BIT #IAE,RMER1I ;WAS 'IAE' DETECTED??
106 043106 001031 BNE 340$ ;YES-'AOE' SHOULD BE ZERO
107 043110 023727 043446 001466 CMP 500$,#822. ;SHOULD AOE BE SET??
108 043116 101425 BLOS 340$ ;NO!!
109 043120 005737 043450 TST 505$ ;MAYBE
110 043124 001012 BNE 335$ ;YES
111 043126 005737 043452 TST 510$
112 043132 001007 BNE 335$ ;YES !!
113 043134 032737 000010 043454 BIT #F2,515$ ;WAS THIS READ OR WRITE CHECK ??
114 043142 001413 BEQ 340$ ;NO !!

```



```

115 043144 005737 001340          TST      RMWCI          :WAS ALL DATA TRANSFERRED ??
116 043150 001410          BEQ      340$          :YES !!
117 043152 012737 001000 001140 335$: MOV      #AOE,$GDDAT    :SET FOR AOE = 1
118 043160 005037 043450          CLR      505$          :CLEAR EXPECTED TRACK
119 043164 012737 000001 043452 340$: MOV      #1,510$       :EXPECT SECTOR = 1
120 043172 013737 001352 001142 340$: MOV      RMER1I,$BDDAT :BAD DATA FOR TYPEOUT
121 043200 042737 176777 001142          BIC      #^CAOE,$BDDAT
122 043206 023737 001140 001142          CMP      $GDDAT,$BDDAT :IS AOE CORRECT??
123 043214 001413          BEQ      345$          :YES!!
124 043216 062716 000004          ADD      #4,(SP)
125 043222 112776 000020 000000          MOVVB   #20,@(SP)      :ERROR NUMBER
126 043230 162716 000002          SUB      #2,(SP)      :MOVE SP TO RETURN FOR ERROR
127 043234 004736          JSR      PC,@(SP)+    :REPORT AOE IS WRONG
128 043236 162716 000010          SUB      #10,(SP)     :RESTORE (SP)
129 043242 000240          NOP
130
131          :REPORT ERROR IF RMDA IS NOT CORRECT
132 043244 032737 002000 001352 345$: BIT      #IAE,RMER1I   :WAS THERE AN IAE ERROR ??
133 043252 001062          BNE      355$          :YES - DONT CHECK RMDA,RMDC
134 043254 013737 043450 001140          MOV      505$,$GDDAT  :SETUP EXPECTED DISK ADDRESS
135 043262 000337 001140          SWAB    $GDDAT
136 043266 113737 043452 001140          MOVVB   510$,$GDDAT
137 043274 013737 001344 001142          MOV      RMDAI,$BDDAT :SETUP RECEIVED DISK ADDRESS
138 043302 023737 001140 001142          CMP      $GDDAT,$BDDAT :COMPARE EXPECTED & RECEIVED
139 043310 001413          BEQ      350$          :BRANCH IF EQUAL
140 043312 062716 000004          ADD      #4,(SP)
141 043316 112776 000021 000000          MOVVB   #21,@(SP)     :ERROR NUMBER
142 043324 162716 000002          SUB      #2,(SP)      :MOVE SP TO RETURN FOR ERROR
143 043330 004736          JSR      PC,@(SP)+    :REPORT BAD DISK ADDRESS
144 043332 162716 000010          SUB      #10,(SP)     :RESTORE (SP)
145 043336 000240          NOP
146
147          :REPORT ERROR IF RMDC IS INCORRECT
148 043340 013737 043446 001140 350$: MOV      500$,$GDDAT  :SETUP EXPECTED CYLINDER
149 043346 042737 176000 001140          BIC      #^C1777,$GDDAT
150 043354 013737 001372 001142          MOV      RMDCI,$BDDAT :SETUP RECEIVED CYLINDER
151 043362 023737 001140 001142          CMP      $GDDAT,$BDDAT :COMPARE CYLINDERS
152 043370 001413          BEQ      355$          :BRANCH IF EQUAL
153 043372 062716 000004          ADD      #4,(SP)
154 043376 112776 000022 000000          MOVVB   #22,@(SP)     :ERROR NUMBER
155 043404 162716 000002          SUB      #2,(SP)      :MOVE SP TO RETURN FOR ERROR
156 043410 004736          JSR      PC,@(SP)+    :REPORT BAD CYLINDER
157 043412 162716 000010          SUB      #10,(SP)     :RESTORE (SP)
158 043416 000240          NOP
159
160 043420 062716 000004          355$: ADD      #4,(SP)      :MOVE (SP) TO ERROR CALL
161 043424 105776 000000          TSTB    @(SP)         :WAS ERROR FOUND??
162 043430 001403          BEQ      360$
163 043432 062716 000004          ADD      #4,(SP)      :MOVE (SP) TO ERROR RETURN
164 043436 000402          BR      365$
165 043440 162716 000004          360$: SUB      #4,(SP)      :MOVE (SP) TO NO ERROR RETURN
166 043444 000207          365$: RTS      PC
167
168 043446 000000          500$: .WORD    0        :CYLINDER
169 043450 000000          505$: .WORD    0        :TRACK
170 043452 000000          510$: .WORD    0        :SECTOR
171 043454 000000          515$: .WORD    0        :FUNCTION CODE

```


172 043456 000000

5208: .WORD 0

;TOTAL # OF TRACKS = LAST TRACK +1

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57

.SBTTL COMPOSITE ERROR CHECK SUBROUTINE

:THIS SUBROUTINE CHECKS THE STORED CONTENTS OF RMER1 AND
:RMER2 AFTER MASKING EACH REGISTER WORD WITH THE USER'S STATUS
:MASKS AND REPORTS AN ERROR IF ANY BITS ARE LEFT ON AFTER
:THE MASKS ARE APPLIED.

```
:CALL:
:(1) JSR PC,CMPERRSTS
:      .WORD MASK FOR ERROR REGISTER 1
:      .WORD MASK FOR ERROR REGISTER 2
:      BR ??? RETURN HERE IF NO ERROR
:      NOP RETURN HERE TO REPORT AN ERROR
:      ERROR ERROR NUMBER DEFINED BY SUB
:      JSR PC,@(SP)+ GO BACK TO SUB FOR MORE ERROR CHECKS
:      ??? RETURN HERE IF NO MORE ERRORS
```

:NOTE: BITS TO BE MASKED SHOULD BE ONE; BITS TO BE TESTED SHOULD
:BE ZERO

CMPEERRSTS:

```
:MASK AND STORE THE CONTENTS OF RMER1 AND RMER2
MOV RMER1I,$TMP1 ;STORE RMER1 AT TEMP STORAGE
BIC @($P),$TMP1 ;MASK RMER1
ADD #2,$($P) ;MOVE SP TO NEXT MASK
MOV RMER2I,$TMP2 ;STORE RMER2 AT TEMP STORAGE
BIC @($P),$TMP2 ;MASK RMER2
```

```
:CLEAR USER'S ERROR CALL
ADD #6,$($P) ;MOVE SP TO USER'S ERROR CALL
CLRB @($P) ;CLEAR ERROR NUMBER
SUB #4,$($P) ;LEAVE SP AT NO ERROR RETURN
```

```
:SEE IF THERE WERE ANY ERRORS IN RMER1, I.E., $TMP1
TST $TMP1 ;ANY ERRORS TO REPORT??
BEQ 5$ ;NO !!
MOV $TMP1,$BDDAT ;RECEIVED STATUS FOR TYPEOUT
CLR $GDDAT ;EXPECTED STATUS FOR TYPEOUT
ADD #4,$($P) ;MOVE SP TO USER'S ERROR CALL
MOVB #66,@($P) ;CORRECTABLE DATA CHECK ERROR #
SUB #2,$($P) ;MOVE SP TO RETURN FOR ERROR
JSR PC,@($P)+ ;REPORT ERROR VIA USER
SUB #10,$($P) ;MOVE SP BACK TO BRANCH
NOP
```

5\$:

```
:SEE IF THERE ARE ANY ERRORS TO REPORT IN RMER2 ($TMP2)
TST $TMP2 ;ANY ERRORS IN RMER2?
BEQ 10$ ;NO!!
MOV $TMP2,$BDDAT ;RECEIVED STATUS FOR TYPEOUT
CLR $GDDAT ;EXPECTED STATUS FOR TYPEOUT
ADD #4,$($P) ;MOVE SP TO USER'S ERROR CALL
MOVB #67,@($P) ;WRITE ERROR NUMBER IN USER'S CALL
SUB #2,$($P) ;MOVE SP TO RETURN FOR ERROR
```

```
043460
043460 013737 001352 001176
043466 047637 000000 001176
043474 062716 000002
043500 013737 001400 001200
043506 047637 000000 001200
043514 062716 000006
043520 105076 000000
043524 162716 000004
043530 005737 001176
043534 001420
043536 013737 001176 001142
043544 005037 001140
043550 062716 000004
043554 112776 000066 000000
043562 162716 000002
043566 004736
043570 162716 000010
043574 000240
043576
043576 005737 001200
043602 001420
043604 013737 001200 001142
043612 005037 001140
043616 062716 000004
043622 112776 000067 000000
043630 162716 000002
```

```
58 043634 004736          JSR    PC,@(SP)+      ;REPORT ERROR VIA USER
59 043636 162716 000010    SUB    #10,(SP)        ;MOVE SP TO NO ERROR RETURN
60 043642 000240          NOP
61 043644          10$:
62
63          ;AUGMENT THE RETURN ADDRESS IF ANY ERROR WAS DETECTED
64 043644 062716 000004    ADD    #4,(SP)         ;MOVE SP TO USER'S ERROR CALL
65 043650 105776 000000    TSTB  @ (SP)          ;WAS THERE AN ERROR CALLED??
66 043654 001403          BEQ    20$             ;NO!!
67 043656 062716 000004    ADD    #4,(SP)         ;YES - MOVE SP TO ERROR RETURN
68 043662 000402          BR    30$             ;
69 043664 162716 000004    20$: SUB    #4,(SP)        ;MOVE SP TO NO ERROR RETURN
70 043670 000207          30$: RTS    PC         ;RETURN TO USER
```



```

1      .SBTTL  DEVICE SELECT SUBROUTINE
2
3      ; THIS SUBROUTINE SELECTS THE DEVICE, GETTING THE DEVICE NUMBER FROM THE
4      ; TEST QUFUE.
5
6      ;CALL:
7      ;(1)   JSR    PC,DEVSEL
8      ;(2)   BR     ??          RETURN IF NO ERROR
9      ;(3)   NOP
10      ;(4)   ERROR          RETURN IF ERROR
11                               ERROR DEFINED BY SUBROUTINE
12
13      DEVSEL:
14
15      ;CLEAR USER'S ERROR CALL
16      ADD     #4,(SP)          ;MOVE SP TO USER'S ERROR
17      CLRB   @10(SP)         ;CLEAR LOW ORDER BYTE OF CALL
18      SUB     #4,(SP)          ;MOVE SP BACK
19
20      ;SAVE USER'S INFORMATION AND SETUP REGISTERS
21      MOV     ERRVEC,-(SP)    ;:PUSH ERRVEC ON STACK
22      MOV     ERRVEC+2,-(SP) ;:PUSH ERRVEC+2 ON STACK
23      MOV     R0,-(SP)       ;:PUSH R0 ON STACK
24      MOV     R1,-(SP)       ;:PUSH R1 ON STACK
25      MOV     #20$,ERRVEC    ;SETUP FOR BUS TIMEOUT
26      MOV     #PR6,ERRVEC+2
27      MOV     $BASE,R0       ;R0 = UNIBUS ADDRESS.
28      MOV     TSTQUE,R1      ;R1 POINTS TO DEVICE NUMBER
29
30      ;SELECT DEVICE AND VERIFY THAT DEVICE IS AVAILABLE
31      MOV     (R1),RMCS2(R0) ;WRITE UNIT SELECT BITS
32      MOV     RMCS1(R0),$TMP1 ;GET 'DVA' STATUS
33      MOV     RMCS2(R0),$TMP0 ;GET 'NED' STATUS
34
35      BIT     #NED,$TMP0     ;IS DEVICE NONEXISTENT ?
36      BEQ     10$           ;NO!!
37      ADD     #4,10(SP)      ;MOVE SP TO USERS ERROR CALL
38      MOV     #111,@10(SP)  ;WRITE ERROR NUMBER
39      BR     30$
40
41      BIT     #DVA,$TMP1     ;IS DEVICE AVAILABLE ?
42      BNE     35$           ;YES!!
43      ADD     #4,10(SP)      ;MOVE SP TO USERS ERROR CALL
44      MOV     #112,@10(SP)  ;WRITE ERROR NUMBER
45      BR     30$
46
47      ;HANDLE BUS TIMEOUT
48      20$:  CMP     (SP)+,(SP)+ ;ADJUST SP
49      ADD     #4,10(SP)      ;MOVE SP TO USERS ERROR CALL
50      MOV     #113,@10(SP)  ;WRITE BUS TIMEOUT ERROR NUMBER
51      SUB     #2,10(SP)     ;ADJUST RETURN TO 'NOP' PRECEDING
52                               ;THE ERROR CALL
53
54      ;RESTORE USERS DATA AND RETURN TO ADDRESS ON STACK
55      35$:  MOV     (SP)+,R1   ;:POP STACK INTO R1
56      MOV     (SP)+,R0       ;:POP STACK INTO R0
57      MOV     (SP)+,ERRVEC+2 ;:POP STACK INTO ERRVEC+2
    
```

```

12 043672
13
14
15 043672 062716 000004
16 043676 105076 000000
17 043702 162716 000004
18
19
20 043706 013746 000004
    043712 013746 000006
    043716 010046
    043720 010146
21 043722 012737 044042 000004
22 043730 012737 000300 000006
23 043736 013700 001276
24 043742 013701 001466
25
26
27 043746 111160 000010
28 043752 016037 000000 001176
29 043760 016037 000010 001174
30
31 043766 032737 010000 001174
32 043774 001407
33 043776 062766 000004 000010
34 044004 112776 000111 000010
35 044012 000422
36
37 044014 032737 004000 001176 10$:
38 044022 001021
39 044024 062766 000004 000010
40 044032 112776 000112 000010
41 044040 000407
42
43
44 044042 022626
45 044044 062766 000004 000010 20$:
46 044052 112776 000113 000010
47 044060 162766 000002 000010 30$:
48
49
50
51 044066
    044066 012601
    044070 012600
    044072 012637 000006
    
```

044076 012637 000004
52 044102 000207

MOV (SP)+,ERRVEC
RTS PC
::POP STACK INTO ERRVEC
:EXIT

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57

```

.SBTTL  SEEK STATUS CHECK SUBROUTINE

;THIS SUBROUTINE VERIFIES THE RESULTS OF SEEK TESTS USING STATUS
;STORED IN THE GET BUFFER AND TEST PARAMETERS STORED IN THE PUT BUFFER.

;THE SUBROUTINE RETURNS TO THE CALLING ROUTINE IF AN ERROR IS DETECTED
;AFTER HAVING LOADED THE APPROPRIATE ERROR NUMBER IN THE 'ERROR' TRAP
;OF THE CALLING ROUTINE.  SEEK STATUS IS CHECKED AS FOLLOWS:

:CALL:
:(1)  JSR    PC,SEKSTS
      BR     ???          RETURN HERE IF NO ERROR
      NOP
      ERROR          RETURN HERE TO REPORT AN ERROR
      JSR    PC,@(SP)+    ERROR NUMBER DEFINED BY SUB
      ???          GO BACK TO SUB FOR MORE ERROR CHECKS
                        RETURN HERE IF NO MORE ERRORS

SEKSTS:

;CLEAR USERS' ERROR CALL
      NOP
      ADD    #4,(SP)      ;MOVE (SP) TO ERROR CALL
      CLRB  @(SP)        ;CLEAR ERROR NUMBER
      SUB    #4,(SP)      ;MOVE (SP) TO NO ERROR RETURN
      CLR   300$        ;CLEAR ERROR FLAGS

;TEST FOR MASSBUS CONTROL BUS PARITY ERROR WHEN WRITING
;LOCAL REGISTERS, I.E., "PAR" = 1 AND "DPE" = 0
      BIT   #PAR,RMER1I  ;WAS PARITY ERROR DETECTED??
      BEQ   1$          ;NO!!
      BIT   #DPE,RMER2I  ;WAS IT DUE TO CONTROL BUS??
      BNE   1$          ;NOT SURE!!

;REPORT REGISTER PARITY ERROR VIA USER'S ERROR CALL
      CLR   $GDDAT      ;EXPECTED STATUS
      MOV   RMER1I,$BDDAT ;RECEIVED STATUS
      ADD   #4,(SP)      ;MOVE STACK TO USER'S ERROR
      MOVB #50,@(SP)    ;ERROR #50
      SUB   #2,(SP)      ;MOVE SP TO RETURN FOR ERROR
      JSR   PC,@(SP)+
      SUB   #10,(SP)     ;RESTORE STACK
      BR   3$          ;IAE SHOULD BE ZERO

;DETERMINE THE VALUE OF "IAE" STATUS BASED ON TRACK, SECTOR AND CYLINDER
;ALSO, SET "SKI" IF CYLINDER ADDRESS IS TOO LARGE.
1$:  MOV   #IAE,$GDDAT  ;SETUP FOR IAE = 1
      BIS   #SKI,300$   ;SETUP FOR SKI = 1
      CMP   RMDCO,#822. ;GREATER THAN LAST CYLINDER ?
      BHI   3$          ;YES - CYLINDER IS INVALID
      BIC   #SKI,300$   ;CLEAR SKI ERROR FLAG

      CMPB  RMDAO+1,LSTRK+1 ;GREATER THAN LAST TRACK ?
      BHI   3$          ;YES - TRACK IS INVALID

      CMPB  RMDAO,#29.  ;SECTOR > 29. ?
      BLOS  2$          ;BR IF NO
    
```

19	044104			
22	044104	000240		
23	044106	062716	000004	
24	044112	105076	000000	
25	044116	162716	000004	
26	044122	005037	045342	
30	044126	032737	000010	001352
31	044134	001424		
32	044136	032737	000010	001400
33	044144	001020		
36	044146	005037	001140	
37	044152	013737	001352	001142
38	044160	062716	000004	
39	044164	112776	000050	000000
40	044172	162716	000002	
41	044176	004736		
42	044200	162716	000010	
43	044204	000437		
47	044206	012737	002000	001140
48	044214	052737	040000	045342
49	044222	023727	001446	001466
50	044230	101025		
51	044232	042737	040000	045342
53	044240	123737	001421	001335
54	044246	101016		
56	044250	123727	001420	000035
57	044256	101410		

```

58 044260 032737 010000 001444 BIT #FMT16,RMOFO ;18 BIT FORMAT ?
59 044266 001406 BEQ 3$ ;YES - SECTOR IS INVALID FOR 18 BIT MODE
60 044270 123727 001420 000037 CMPB RMDAO,#31. ;SECTOR > 31. ?
61 044276 101002 BHI 3$ ;YES - SECTOR IS INVALID
62
63 044300 005037 001140 2$: CLR $GDDAT ;"IAE" SHOULD = 0
64
65 ;COMPARE EXPECTED AND RECIEVED "IAE" STATUS
66 044304 013737 001352 001142 3$: MOV RMER1I,$BDDAT ;IS IAE OK??
67 044312 042737 175777 001142 BIC #^CIAE,$BDDAT ;SAVE IAE BIT FOR COMPARE
68 044320 023737 001140 001142 CMP $GDDAT,$BDDAT ;CORRECT "IAE" STATUS ?
69 044326 001004 BNE 35$ ;BR IF NO
70 044330 042737 040000 045342 BIC #SKI,300$ ;CLEAR SKI FLAG
71 044336 000413 BR 5$ ;GO CHECK NEXT ERROR
72 044340
73 35$: ;REPORT INCORRECT "IAE" STATUS VIA USER'S ERROR CALL
74 044340 062716 000004 ADD #4,(SP)
75 044344 112776 000051 000000 MOVB #51,@(SP) ;ERROR 51
76 044352 162716 000002 SUB #2,(SP) ;MOVE SP TO RETURN FOR ERROR
77 044356 004736 JSR PC,@(SP)+ ;REPORT INCORRECT IAE
78 044360 162716 000010 SUB #10,(SP) ;RESTORE (SP)
79 044364 000240 NOP
80 044366
81
82 5$: ;REPORT ANY IVC ERROR AS
83 ; IVC ERROR WITH VOLUME VALID ZERO
84 ; ERRONEOUS IVC ERROR, VOLUME VALID IS SET
85 044366 032737 010000 001400 BIT #IVC,RMER2I ;IVC ERROR??
86 044374 001427 BEQ 52$ ;NO!!
87 044376 005037 001140 CLR $GDDAT ;EXPECTED STATUS
88 044402 013737 001400 001142 MOV RMER2I,$BDDAT ;RECEIVED STATUS
89 044410 062716 000004 ADD #4,(SP) ;MOVE SP TO USER'S ERROR
90 044414 112776 000060 000000 MOVB #60,@(SP) ;ERROR 60 IF VV = 0
91 044422 032737 000100 001350 BIT #VV,RMDSI
92 044430 001403 BEQ 51$
93 044432 112776 000061 000000 MOVB #61,@(SP) ;ERROR 61 IF VV = 1
94 044440 162716 000002 51$: SUB #2,(SP) ;MOVE SP TO RETURN FOR ERROR
95 044444 004736 JSR PC,@(SP)+ ;REPORT ERROR VIA USER
96 044446 162716 000010 SUB #10,(SP) ;RESTORE SP
97 044452 000240 NOP
98
99 044454 013737 001400 001142 52$: MOV RMER2I,$BDDAT ;RECEIVED STATUS
100 044462 042737 137777 001142 BIC #^CSKI,$BDDAT ;CLEAR DONT CARES
101 044470 013737 045342 001140 MOV 300$,$GDDAT ;GET EXPECTED SKI STATUS
102 044476 042737 137777 001140 BIC #^CSKI,$GDDAT ;CLEAR DONT CARES
103 044504 001417 BEQ 53$ ;BRANCH IF 0 EXPECTED
104
105 ;REPORT ERROR IF SKI IS NOT SET (IAE WAS NOT DETECTED)
106 044506 032737 040000 001142 BIT #SKI,$BDDAT ;WAS SKI DETECTED ??
107 044514 001032 BNE 54$ ;YES !!
108 044516 062716 000004 ADD #4,(SP) ;MOVE SP TO USERS ERROR CALL
109 044522 112776 000267 000000 MOVB #267,@(SP) ;WRITE ERROR NUMBER
110 044530 162716 000002 SUB #2,(SP) ;MOVE SP TO ERROR RETURN
111 044534 004736 JSR PC,@(SP)+ ;REPORT ERROR AND RETURN
112 044536 162716 000010 SUB #10,(SP) ;MOVE SP TO NO ERROR
113 044542 000443 BR 6$ ;GO TO NEXT ERROR CHECK
114 044544
53$:

```



```

115
116 ;REPORT ERROR IF SKI IS SET
117 044544 032737 040000 001142 BIT #SKI,$BDDAT ;IS SKI SET ??
118 044552 001413 BEQ 54$ ;NO - SKI IS OK
119 044554 062716 000004 ADD #4,(SP) ;MOVE (SP) TO ERROR
120 044560 112776 000054 000000 MOVB #54,@(SP) ;LOAD ERROR NUMBER
121 044566 162716 000002 SUB #2,(SP) ;MOVE SP TO RETURN FOR ERROR
122 044572 004736 JSR PC,@(SP)+ ;REPORT SEEK ERROR
123 044574 162716 000010 SUB #10,(SP) ;RESTORE (SP)
124 044600 000240 NOP
125
126 ;REPORT ANY DEVICE CHECK
127 044602 032737 000200 001400 54$: BIT #DVC,RMER2I ;WAS THERE DVC DURING SEEK??
128 044610 001420 BEQ 6$ ;NO!!
129 044612 005037 001140 CLR $GDDAT ;EXPECTED STATUS
130 044616 013737 001400 001142 MOV RMER2I,$BDDAT ;RECEIVED STATUS
131 044624 062716 000004 ADD #4,(SP)
132 044630 112776 000055 000000 MOVB #55,@(SP) ;ERROR #55
133 044636 162716 000002 SUB #2,(SP) ;MOVE SP TO RETURN FOR ERROR
134 044642 004736 JSR PC,@(SP)+ ;REPORT ERROR VIA USER
135 044644 162716 000010 SUB #10,(SP) ;RESTORE SP
136 044650 000240 NOP
137
138 ;REPORT ANY 'OPI' ERROR AS OPI WITH MOL = 0, OR OPI
139 ;BECAUSE ON CYLINDER LATCH DIDN'T RESET
140 044652 032737 020000 001352 6$: BIT #OPI,RMER1I ;'OPI' ERROR??
141 044660 001427 BEQ 8$ ;NO!!
142 044662 005037 001140 CLR $GDDAT ;EXPECTED STATUS
143 044666 013737 001352 001142 MOV RMER1I,$BDDAT ;RECEIVED STATUS
144 044674 062716 000004 ADD #4,(SP) ;MOVE (SP) TO ERROR
145 044700 112776 000052 000000 MOVB #52,@(SP) ;LOAD ERROR NUMBER
146 044706 032737 010000 001350 BIT #MOL,RMDSI ;WAS MEDIUM ON LINE??
147 044714 001403 BEQ 7$ ;NO!!
148 044716 112776 000053 000000 MOVB #53,@(SP) ;YES - CHANGE ERROR NUMBER
149 044724 162716 000002 7$: SUB #2,(SP) ;MOVE SP TO RETURN FOR ERROR
150 044730 004736 JSR PC,@(SP)+ ;REPORT 'OPI' ERROR
151 044732 162716 000010 SUB #10,(SP) ;RESTORE (SP)
152 044736 000240 NOP
153
154 ;SEE IF 'PIP' = 0, AND 'ATA', 'MOL' AND 'VV' = 1
155 044740 013746 001350 8$: MOV RMDSI,-(SP)
156 044744 042716 047677 BIC #^C<ATA!PIP!MOL!VV>,(SP)
157 044750 022726 110100 CMP #ATA!MOL!VV,(SP)+
158 044754 001002 BNE 9$ ;ERROR IN RMDS
159 044756 000137 045312 JMP 14$ ;RMDS IS OK
160
161 ;REPORT ERROR IF MOL = 0 AND OPI = 0
162 044762 032737 010000 001350 9$: BIT #MOL,RMDSI ;IS MOL RESET??
163 044770 001030 BNE 10$ ;NO - MOL IS SET
164 044772 032737 020000 001352 BIT #OPI,RMER1I ;WAS OPI SET
165 045000 001024 BNE 10$ ;YES - DONT REPORT ERROR
166 045002 013737 001350 001140 MOV RMDSI,$GDDAT ;EXPECTED STATUS
167 045010 052737 010000 001140 BIS #MOL,$GDDAT
168 045016 013737 001350 001142 MOV RMDSI,$BDDAT ;RECEIVED STATUS
169 045024 062716 000004 ADD #4,(SP)
170 045030 112776 000062 000000 MOVB #62,@(SP)
171 045036 162716 000002 SUB #2,(SP) ;MOVE SP TO RETURN FOR ERROR

```

```

172 045042 004736          JSR      PC,@(SP)+      ;REPORT ERROR VIA USER
173 045044 162716 000010  SUB      #10,(SP)
174 045050 000240          NOP
175
176
177 045052 032737 020000 001350 ;REPORT AN ERROR IF 'PIP' IS STIL SET AND SKI NOT SET
10$: BIT      #PIP,RMDSI      ;IS 'PIP' STILL SET??
178 045060 001430          BEQ      11$              ;NO!!
179 045062 032737 040000 001400 BIT      #SKI,RMER2I      ;WAS 'SKI' SET??
180 045070 001024          BNE      11$              ;YES-DONT REPORT PIP
181 045072 013737 001350 001140 MOV      RMDSI,$GDDAT     ;EXPECTED STATUS
182 045100 042737 020000 001142 BIC      #PIP,$BDDAT
183 045106 013737 001350 001142 MOV      RMDSI,$BDDAT     ;RECEIVED STATUS
184 045114 062716 000004          ADD      #4,(SP)          ;MOVE (SP) TO ERROR
185 045120 112776 000056 000000 MOVB     #56,@(SP)        ;LOAD ERROR NUMBER
186 045126 162716 000002          SUB      #2,(SP)          ;MOVE SP TO RETURN FOR ERROR
187 045132 004736          JSR      PC,@(SP)+      ;REPORT 'PIP' SET AFTER SEEK
188 045134 162716 000010  SUB      #10,(SP)          ;RESTORE (SP)
189 045140 000240          NOP
190
191
192 045142 032737 100000 001350 ;REPORT AN ERROR IF 'ATA' IS NOT SET
11$: BIT      #ATA,RMDSI      ;WAS 'ATA' SET ??
193 045150 001024          BNE      13$              ;YES!!
194 045152 013737 001350 001140 MOV      RMDSI,$GDDAT     ;EXPECTED STATUS
195 045160 052737 110600 001140 BIS      #ATA!MOL!DPR!DRY,$GDDAT
196 045166 013737 001350 001142 MOV      RMDSI,$BDDAT     ;RECEIVED STATUS
197 045174 062716 000004          ADD      #4,(SP)          ;MOVE (SP) TO ERROR
198 045200 112776 000057 000000 MOVB     #57,@(SP)        ;LOAD ERROR NUMBER
199 045206 162716 000002          SUB      #2,(SP)          ;MOVE SP TO RETURN FOR ERROR
200 045212 004736          JSR      PC,@(SP)+      ;REPORT ATTENTION NOT SET DURING
201                                     ;SEEK TEST
202 045214 162716 000010  SUB      #10,(SP)          ;RESTORE (SP)
203 045220 000240          NOP
204
205
206 045222 032737 000100 001350 ;REPORT ERROR IF VOLUME VALID IS RESET AND IVC IS ZERO
13$: BIT      #VV,RMDSI      ;IS VV = 0 ??
207 045230 001030          BNE      14$              ;NO!!
208 045232 032737 010000 001400 BIT      #IVC,RMER2I      ;IS IVC ALSO 0 ??
209 045240 001024          BNE      14$              ;NO - IVC IS SET
210 045242 013737 001350 001140 MOV      RMDSI,$GDDAT     ;EXPECTED STATUS
211 045250 052737 000100 001140 BIS      #VV,$GDDAT
212 045256 013737 001350 001142 MOV      RMDSI,$BDDAT     ;RECEIVED STATUS
213 045264 062716 000004          ADD      #4,(SP)
214 045270 112776 000064 000000 MOVB     #64,@(SP)        ;ERROR #64
215 045276 162716 000002          SUB      #2,(SP)          ;MOVE SP TO RETURN FOR ERROR
216 045302 004736          JSR      PC,@(SP)+
217 045304 162716 000010  SUB      #10,(SP)
218 045310 000240          NOP
219 045312          14$:
220
221
222 045312 000240          ;MODIFY THE RETURN ADDRESS IF AN ERROR WAS DETECTED
223 045314 062716 000004          NOP
224 045320 105776 000000          ADD      #4,(SP)          ;MOVE (SP) TO ERROR CALL
225 045324 001403          TSTB     @,(SP)          ;WAS ERROR CALLED??
226 045326 062716 000004          BEQ      15$              ;NO!!
227 045332 000402          ADD      #4,(SP)          ;MOVE TO ERROR RETURN
228                                     BR       16$

```


229 045334 162716 000004
230 045340 000207
231
232 045342 000000

15\$: SUB #4.(SP)
16\$: RTS PC
300\$: .WORD 0

:MOVE (SP) TO NO ERROR RETURN
:RETURN
:ERROR FLAGS

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26

.SBTTL CONTROLLER CLEAR SUBROUTINE

: THIS SUBROUTINE CLEARS THE MASSBUS CONTROLLER, MASSBUS ADAPTERS,
: AND DRIVES, THEN SELECTS THE DRIVE.

: CALL: JSR PC,CNTCLR
: BR ???
: NOP
: ERROR
: ???

RETURN HERE IF NO ERROR FOUND
RETURN HERE IF ANY ERROR FOUND
SUB DEFINES ERROR NUMBER

CNTCLR:

MOV R0,-(SP) ;:PUSH R0 ON STACK
MOV R1,-(SP) ;:PUSH R1 ON STACK
MOV ERRVEC,-(SP) ;:PUSH ERRVEC ON STACK
MOV ERRVEC+2,-(SP) ;:PUSH ERRVEC+2 ON STACK
MOV #10\$,ERRVEC ;:SETUP FOR BUS TIMEOUT
MOV #PR6,ERRVEC+2
MOV \$BASE,R0 ;:R0 = UNIBUS ADDRESS
MOV #CLR, RMCS2(R0) ;:CLEAR MASSBUS
MOV TSTQUE,R1 ;:GET DEVICE UNDER TEST
MOVB (R1),RMCS2(R0) ;:SELECT DEVICE
BR 20\$

10\$: CMP (SP)+,(SP)+ ;:ADJUST STACK
ADD #4,10(SP) ;:MOVE SP TO USER'S ERROR CALL
MOVB #7,@10(SP) ;:WRITE THE ERROR NUMBER
SUB #2,10(SP) ;:ADJUST SP TO RETURN TO ERROR

20\$: MOV (SP)+,ERRVEC+2 ;:POP STACK INTO ERRVEC+2
MOV (SP)+,ERRVEC ;:POP STACK INTO ERRVEC
MOV (SP)+,R1 ;:POP STACK INTO R1
MOV (SP)+,R0 ;:POP STACK INTO R0
RTS PC

045344 010046
045346 010146
045350 013746 000004
045354 013746 000006
045360 012737 045420 000004
045366 012737 000300 000006
045374 013700 001276
045400 012760 000040 000010
045406 013701 001466
045412 111160 000010
045416 000412

045420 022626
045422 062766 000004 000010
045430 112776 000007 000010
045436 162766 000002 000010
045444
045444 012637 000006
045450 012637 000004
045454 012601
045456 012600
045460 000207

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57

```

.SBTTL STATUS CHECK SUBROUTINES
:*****
.SBTTL CONTROLLER CLEAR STATUS CHECK SUBROUTINE

:THIS SUBROUTINE VERIFIES THAT THE SUBSYSTEM IS INITIALIZED BASED ON
:STATUS STORED IN THE GET BUFFER. THIS SUBROUTINE SHOULD ONLY BE
:USED FOLLOWING A CONTROLLER CLEAR OPERATION, I.E., WRITING A 1 IN BIT
:5 OF RMCS2, BECAUSE THE ERROR MESSAGES ARE BASED ON THAT CONDITION.

:STATUS PERTINENT TO THE DEVICE IS NOT CHECKED. IN PARTICULAR, THE
:FOLLOWING STATUS BITS ARE NOT CHECKED:
:
:   ATA,ERR,PIP,MOL,WRL,LBT,PGM,VV,OM,UNS,SKI,DVC
:
:CALL:
:(1) JSR PC,CLRSTS
:     BR   ???           RETURN HERE IF NO ERROR
:     NOP          RETURN HERE TO REPORT AN ERROR
:     ERROR       ERROR NUMBER DEFINED BY SUB
:     JSR PC,@(SP)+ GO BACK TO SUB FOR MORE ERROR CHECKS
:     ???           RETURN HERE IF NO MORE ERRORS

CLRSTS:

:CLEAR USER'S ERROR CALL
ADD #4,(SP) ;MOVE SP TO ERROR
CLRB @(SP) ;CLEAR ERROR NUMBER
SUB #4,(SP) ;MOVE SP BACK TO NO ERROR

:REPORT ERROR IF RMCS1 NOT INITIALIZED
4$: MOV RMCS1I,$BDDAT ;VERIFY RMCS1
BIC #SC,$BDDAT ;IGNORE SPECIAL CONDITION
MOV #DVA!RDY,$GDDAT ;EXPECT DVA & RDY
CMP $GDDAT,$BDDAT ;COMPARE EXPECTED, RECEIVED
BEQ 5$ ;BRANCH IF EQUAL
ADD #4,(SP) ;MOVE SP TO USER'S ERROR CALL
MOVB #126,@(SP) ;WRITE ERROR NUMBER IN CALL
SUB #2,(SP) ;MOVE SP TO RETURN FOR ERROR
JSR PC,@(SP)+ ;REPORT ERROR VIA USER
SUB #10,(SP) ;MOVE SP BACK TO NO ERROR
NOP

:REPORT ERROR IF RMBA NOT RESET
5$: CLR $GDDAT ;VERIFY RMBA IS ZERO
MOV RMBAI,$BDDAT
BEQ 7$ ;BRANCH IF ZERO
ADD #4,(SP) ;MOVE SP TO USER'S ERROR CALL
MOVB #127,@(SP) ;WRITE ERROR NUMBER IN CALL
SUB #2,(SP) ;MOVE SP TO RETURN FOR ERROR
JSR PC,@(SP)+ ;REPORT ERROR VIA USER
SUB #10,(SP) ;MOVE SP BACK TO NO ERROR
NOP

:REPORT ERROR IF RMCS2 NOT INITIALIZED
7$: MOV RMCS2I,$BDDAT ;VERIFY RMCS2
MOV R1,-(SP) ;PUSH R1 ON STACK
CLR -(SP) ;EXPECT IR & UNIT NUMBER
MOV TSTQUE,R1 ;R1 = ADDRESS OF TEST QUE
MOVB (R1),(SP)
    
```

24	045462			
27	045462	062716	000004	
28	045466	105076	000000	
29	045472	162716	000004	
31	045476	013737	001336	001142
32	045504	042737	100000	001142
33	045512	012737	004200	001140
34	045520	023737	001140	001142
35	045526	001413		
36	045530	062716	000004	
37	045534	112776	000126	000000
38	045542	162716	000002	
39	045546	004736		
40	045550	162716	000010	
41	045554	000240		
43	045556	005037	001140	
44	045562	013737	001342	001142
45	045570	001413		
46	045572	062716	000004	
47	045576	112776	000127	000000
48	045604	162716	000002	
49	045610	004736		
50	045612	162716	000010	
51	045616	000240		
53	045620	013737	001346	001142
54	045626	010146		
55	045630	005046		
56	045632	013701	001466	
57	045636	111116		

```

58 045640 052716 000100      BIS      #IR,(SP)
59 045644 012637 001140      MOV      (SP)+,$GDDAT
60 045650 012601              MOV      (SP)+,R1          ;;PGP STACK INTO R1
61 045652 023737 001140 001142  CMP      $GDDAT,$BDDAT    ;;COMPARE EXPECTED & RECEIVED
62 045660 001413              BEQ      9$              ;;BRANCH IF EQUAL
63 045662 062716 000004      ADD      #4,(SP)          ;;MOVE SP TO USER'S ERROR CALL
64 045666 112776 000130 000000  MOVVB   #130,@(SP)        ;;WITE ERROR NUMBER IN CALL
65 045674 162716 000002      SUB      #2,(SP)          ;;MOVE SP TO RETURN FOR ERROR
66 045700 004736              JSR      PC,@(SP)+        ;;REPORT ERROR VIA USER
67 045702 162716 000010      SUB      #10,(SP)         ;;MOVE SP BACK TO NO ERROR
68 045706 000240              NOP
69                               ;REPORT ERROR IF RMER1 NOT RESET-IGNORE UNS
70 045710 005037 001140 9$:      CLR      $GDDAT          ;;VERIFY RMER1
71 045714 013737 001352 001142  MOV      RMER1I,$BDDAT
72 045722 042737 040000 001142  BIC      #UNS,$BDDAT      ;;IGNORE UNSAFE
73 045730 001413              BEQ      13$             ;;BRANCH IF ZERO
74 045732 062716 000004      ADD      #4,(SP)          ;;MOVE SP TO USER'S ERROR CALL
75 045736 112776 000131 000000  MOVVB   #131,@(SP)        ;;WITE ERROR NUMBER IN CALL
76 045744 162716 000002      SUB      #2,(SP)          ;;MOVE SP TO RETURN FOR ERROR
77 045750 004736              JSR      PC,@(SP)+        ;;REPORT ERROR VIA USER
78 045752 162716 000010      SUB      #10,(SP)         ;;MOVE SP BACK TO NO ERROR
79 045756 000240              NOP
80                               ;REPORT ERROR IF RMMR1 NOT INITIALIZED-IGNORE WC,LS,LST
81 045760 013737 001362 001142 13$:   MOV      RMMR1I,$BDDAT    ;;VERIFY RMMR
82 045766 042737 000046 001142  BIC      #WC!LS!LST,$BDDAT ;;IGNORE WORD CLOCK, SCT, TRK
83 045774 012737 000010 001140  MOV      #MWD,$GDDAT      ;;EXPECT WRITE DATA BIT
84 046002 023737 001140 001142  CMP      $GDDAT,$BDDAT    ;;COMPARE EXPECTED AND RECEIVED
85 046010 001413              BEQ      17$             ;;BRANCH IF 0
86 046012 062716 000004      ADD      #4,(SP)          ;;MOVE SP TO USER'S ERROR CALL
87 046016 112776 000133 000000  MOVVB   #133,@(SP)        ;;WITE ERROR NUMBER IN CALL
88 046024 162716 000002      SUB      #2,(SP)          ;;MOVE SP TO RETURN FOR ERROR
89 046030 004736              JSR      PC,@(SP)+        ;;REPORT ERROR VIA USER
90 046032 162716 000010      SUB      #10,(SP)         ;;MOVE SP BACK TO NO ERROR
91 046036 000240              NOP
92                               ;REPORT AN ERROR IF RMEC2 IS NOT RESET
93 046040 005037 001140 17$:   CLR      $GDDAT          ;;EXPECT ZEROS
94 046044 013737 001404 001142  MOV      RMEC2I,$BDDAT    ;;VERIFY RMEC2=0
95 046052 001413              BEQ      19$
96 046054 062716 000004      ADD      #4,(SP)          ;;MOVE SP TO USER'S ERROR CALL
97 046060 112776 000135 000000  MOVVB   #135,@(SP)        ;;WITE ERROR NUMBER IN CALL
98 046066 162716 000002      SUB      #2,(SP)          ;;MOVE SP TO RETURN FOR ERROR
99 046072 004736              JSR      PC,@(SP)+        ;;REPORT ERROR VIA USER
100 046074 162716 000010     SUB      #10,(SP)         ;;MOVE SP BACK TO NO ERROR
101 046100 000240              NOP
102                               ;REPORT ERROR IF RMMR2 NOT INITIALIZED-IGNORE RQA,RQB
103 046102 013737 001376 001142 19$:   MOV      RMMR2I,$BDDAT    ;;VERIFY RMMR2
104 046110 042737 140000 001142  BIC      #RQA!RQB,$BDDAT
105 046116 012737 011777 001140  MOV      #TST!1777,$GDDAT ;;EXPECT TEST BIT ON
106 046124 023737 001140 001142  CMP      $GDDAT,$BDDAT
107 046132 001413              BEQ      21$
108 046134 062716 000004      ADD      #4,(SP)          ;;MOVE SP TO USER'S ERROR CALL
109 046140 112776 000136 000000  MOVVB   #136,@(SP)        ;;WITE ERROR NUMBER IN CALL
110 046146 162716 000002      SUB      #2,(SP)          ;;MOVE SP TO RETURN FOR ERROR
111 046152 004736              JSR      PC,@(SP)+        ;;REPORT ERROR VIA USER
112 046154 162716 000010     SUB      #10,(SP)         ;;MOVE SP BACK TO NO ERROR
113 046160 000240              NOP
114                               ;REPORT ERROR IF RMER2 NOT RESET-IGNORE SKI,DVC
    
```



```

115 046162 005037 001140      21$: CLR      $GDDAT      :EXPECT ALL ZEROS
116 046166 013737 001400 001142  MOV      RMER2I,$BDDAT :VERIFY RMER2
117 046174 042737 040200 001142  BIC      #SKI!DVC,$BDDAT :IGNORE DEVICE ERRORS
118 046202 001413          BEQ      215$          :BRANCH IF OTHER BITS 0
119 046204 062716 000004      ADD      #4,(SP)       :MOVE SP TO USER'S ERROR CALL
120 046210 112776 000174 000000  MOVB     #174,@(SP)    :WRITE ERROR NUMBER IN CALL
121 046216 162716 000002      SUB      #2,(SP)       :MOVE SP TO RETURN FOR ERROR
122 046222 004736          JSR      PC,@(SP)+     :REPORT ERROR VIA USER
123 046224 162716 000010      SUB      #10,(SP)     :MOVE SP BACK TO NO ERROR
124 046230 000240          NOP
125                                :REPORT ERROR IF RMD5 NOT INITIALIZED
126 046232 013737 001350 001142  215$: MOV      RMD5I,$BDDAT :TEST DRIVE STATUS REGISTER
127 046240 042737 177177 001142  BIC      #^C<DRY!DPR>,$BDDAT
128 046246 012737 000600 001140  MOV      #DPR!DRY,$GDDAT :EXPECTED DRIVE STATUS
129 046254 023737 001140 001142  CMP      $GDDAT,$BDDAT :COMPARE EXPECTED & RECEIVED
130 046262 001413          BEQ      22$          :BRANCH IF EQUAL
131 046264 062716 000004      ADD      #4,(SP)       :MOVE SP TO USER'S ERROR CALL
132 046270 112776 000134 000000  MOVB     #134,@(SP)    :WRITE ERROR NUMBER
133 046276 162716 000002      SUB      #2,(SP)       :MOVE SP TO RETURN FOR ERROR
134 046302 004736          JSR      PC,@(SP)+     :REPORT ERROR TO USER
135 046304 162716 000010      SUB      #10,(SP)     :MOVE SP BACK TO NO ERROR
136 046310 000240          NOP
137 046312 062716 000004      22$: ADD      #4,(SP)       :MOVE SP TO ERROR CALL
138 046316 105776 000000      TSTB     @(SP)         :WAS AN ERROE DETECTED??
139 046322 001403          BEQ      23$          :NO!!
140 046324 062716 000004      ADD      #4,(SP)       :YES - MOVE TO ERROR RETURN
141 046330 000402          BR       24$          :
142 046332 162716 000004      23$: SUB      #4,(SP)       :MOVE SP TO NO ERROR RETURN
143 046336 000240      24$: NOP
144 046340 000207      RTS      PC

```

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57

.SBTTL PACK ACKNOWLEDGE STATUS CHECK

: THIS SUBROUTINE CHECKS THE RESULTS OF A PACK ACKNOWLEDGE
 : COMMAND USING THE STATUS STORED IN THE GET BUFFER. ERRORS ARE
 : REPORTED TO THE USER VIA THE USER'S ERROR CALL.

```

:CALL:
:(1) JSR PC,ACKSTS
: BR ??? RETURN HERE IF NO ERROR
: NOP RETURN HERE TO REPORT AN ERROR
: ERROR ERROR NUMBER DEFINED BY SUB
: JSR PC,@(SP)+ GO BACK TO SUB FOR MORE ERROR CHECKS
: ??? RETURN HERE IF NO MORE ERRORS
    
```

ACKSTS:

```

: CLEAR USER'S ERROR CALL
ADD #4,(SP) :MOVE SP TO ERROR CALL
CLRB @(SP) :CLEAR LOW ORDER BYTE
SUB #4,(SP) :MOVE SP BACK
    
```

```

: REPORT AN ERROR IF 'VV' IS 0
BIT #VV,RMDSI :IS VOLUME VALID SET??
BNE 1$ :YES!!
MOV RMDSI,$GDDAT :EXPECTED STATUS
BIS #VV,$GDDAT
MOV RMDSI,$BDDAT :RECEIVED STATUS
ADD #4,(SP) :MOVE SP TO ERROR CALL
MOVB #155,@(SP) :WRITE NUMBER IN ERROR CALL
SUB #2,(SP) :MOVE SP TO RETURN FOR ERROR
JSR PC,@(SP)+ :REPORT THE ERROR
SUB #10,(SP) :MOVE SP BACK TO BRANCH
NOP
    
```

1\$:

```

: REPORT AN ERROR IF 'MOL' IS 0
BIT #MOL,RMDSI :IS MOL SET??
BNE 2$ :YES!!
MOV RMDSI,$GDDAT :EXPECTED STATUS
BIS #MOL,$GDDAT
MOV RMDSI,$BDDAT :RECEIVED STATUS
ADD #4,(SP) :MOVE SP TO ERROR CALL
MOVB #41,@(SP) :WRITE NUMBER OF ERROR IN CALL
SUB #2,(SP) :MOVE SP TO RETURN FOR ERROR
JSR PC,@(SP)+ :REPORT TH ERROR
SUB #10,(SP) :MOVE SP TO BRANCH
NOP
    
```

2\$:

```

: SEE IF 'UNS','OPI','RMR','ILR', OR 'ILF' IS SET
BIT #UNS:OPI!RMR!ILR!ILF,RMER1I
BEQ 7$
    
```

```

: REPORT AN ERROR IF 'UNS' IS SET
BIT #UNS,RMER1I :WAS UNS SET??
BEQ 3$ :NO!!
MOV RMER1I,$BDDAT :RECEIVED STATUS
    
```

```

15 046342
18 046342 062716 000004
19 046346 105076 000000
20 046352 162716 000004
23 046356 032737 000100 001350
24 046364 001024
25 046366 013737 001350 001140
26 046374 052737 000100 001140
27 046402 013737 001350 001142
28 046410 062716 000004
29 046414 112776 000155 000000
30 046422 162716 000002
31 046426 004736
32 046430 162716 000010
33 046434 000240
34 046436
37 046436 032737 010000 001350
38 046444 001024
39 046446 013737 001350 001140
40 046454 052737 010000 001140
41 046462 013737 001350 001142
42 046470 062716 000004
43 046474 112776 000041 000000
44 046502 162716 000002
45 046506 004736
46 046510 162716 000010
47 046514 000240
48 046516
51 046516 032737 060007 001352
52 046524 001570
55 046526 032737 040000 001352
56 046534 001424
57 046536 013737 001352 001142
    
```


58	046544	013737	001352	001140	MOV	RMER1I,\$GDDAT	:EXPECTED STATUS
59	046552	042737	040000	001140	BIC	#UNS,\$GDDAT	
60	046560	062716	000004		ADD	#4,(SP)	:MOVE SP TO ERROR CALL
61	046564	112776	000042	000000	MOVB	#42,@(SP)	:WRITE NUMBER OF ERROR IN CALL
62	046572	162716	000002		SUB	#2,(SP)	:MOVE SP TO RETURN FOR ERROR
63	046576	004736			JSR	PC,@(SP)+	:REPORT THE ERROR VIA USER
64	046600	162716	000010		SUB	#10,(SP)	:MOVE SP TO NO ERROR RETURN
65	046604	000240			NOP		
66	046606						
67							
68							
69	046606	032737	020000	001352	:REPORT	ANY OPI ERROR	
70	046614	001424			BIT	#OPI,RMER1I	:WAS OPI SET ??
71	046616	013737	001352	001142	BEQ	4\$:NO!!
72	046624	013737	001352	001140	MOV	RMER1I,\$BDDAT	:RECEIVED STATUS
73	046632	042737	020000	001140	MOV	RMER1I,\$GDDAT	:EXPECTED STATUS
74	046640	062716	000004		BIC	#OPI,\$GDDAT	
75	046644	112776	000043	000000	ADD	#4,(SP)	:MOVE SP TO ERROR CALL
76	046652	162716	000002		MOVB	#43,@(SP)	:WRITE NUMBER OF ERROR IN CALL
77	046656	004736			SUB	#2,(SP)	:MOVE SP TO RETURN FOR ERROR
78	046660	162716	000010		JSR	PC,@(SP)+	:REPORT THE ERROR VIA USER
79	046664	000240			SUB	#10,(SP)	:MOVE SP TO NO ERROR RETURN
80	046666				NOP		
81							
82							
83	046666	032737	000004	001352	:REPORT	ANY RMR ERROR	
84	046674	001424			BIT	#RMR,RMER1I	:WAS RMR SET??
85	046676	013737	001352	001142	BEQ	5\$:NO!!
86	046704	013737	001352	001140	MOV	RMER1I,\$BDDAT	:RECEIVED STATUS
87	046712	042737	000004	001140	MOV	RMER1I,\$GDDAT	:EXPECTED STATUS
88	046720	062716	000004		BIC	#RMR,\$GDDAT	
89	046724	112776	000044	000000	ADD	#4,(SP)	:MOVE SP TO ERROR CALL
90	046732	162716	000002		MOVB	#44,@(SP)	:WRITE NUMBER OF ERROR IN CALL
91	046736	004736			SUB	#2,(SP)	:MOVE SP TO RETURN FOR ERROR
92	046740	162716	000010		JSR	PC,@(SP)+	:REPORT THE ERROR VIA USER
93	046744	000240			SUB	#10,(SP)	:MOVE SP TO NO ERROR RETURN
94	046746				NOP		
95							
96							
97	046746	032737	000002	001352	:REPORT	ANY ILR ERROR	
98	046754	001424			BIT	#ILR,RMER1I	:WAS ILR SET??
99	046756	013737	001352	001142	BEQ	6\$:NO!!
100	046764	013737	001352	001140	MOV	RMER1I,\$BDDAT	:RECEIVED STATUS
101	046772	042737	000002	001140	MOV	RMER1I,\$GDDAT	:EXPECTED STATUS
102	047000	062716	000004		BIC	#ILR,\$GDDAT	
103	047004	112776	000045	000000	ADD	#4,(SP)	:MOVE SP TO ERROR CALL
104	047012	162716	000002		MOVB	#45,@(SP)	:WRITE NUMBER OF ERROR IN CALL
105	047016	004736			SUB	#2,(SP)	:MOVE SP TO RETURN FOR ERROR
106	047020	162716	000010		JSR	PC,@(SP)+	:REPORT THE ERROR VIA USER
107	047024	000240			SUB	#10,(SP)	:MOVE SP TO NO ERROR RETURN
108	047026				NOP		
109							
110							
111	047026	032737	000001	001352	:REPORT	ANY ILF ERROR	
112	047034	001424			BIT	#ILF,RMER1I	:WAS ILF SET??
113	047036	013737	001352	001142	BEQ	7\$:NO!!
114	047044	013737	001352	001140	MOV	RMER1I,\$BDDAT	:RECEIVED STATUS
					MOV	RMER1I,\$GDDAT	:EXPECTED STATUS

115	047052	042737	000001	001140	BIC	#ILF,\$GDDAT	
116	047060	062716	000004		ADD	#4,(SP)	;MOVE SP TO ERROR CALL
117	047064	112776	000046	000000	MOVB	#46,@(SP)	;WRITE NUMBER OF ERROR IN CALL
118	047072	162716	000002		SUB	#2,(SP)	;MOVE SP TO RETURN FOR ERROR
119	047076	004736			JSR	PC,@(SP)+	;REPORT THE ERROR VIA USER
120	047100	162716	000010		SUB	#10,(SP)	;MOVE SP TO NO ERROR RETURN
121	047104	000240			NOP		
122	047106						
123							
124							
125	047106	062716	000004		ADD	#4,(SP)	;MOVE SP TO ERROR CALL
126	047112	105776	000000		TSTB	@(SP)	;WAS ERROR FOUND??
127	047116	001403			BEQ	8\$;NO!!
128	047120	062716	000004		ADD	#4,(SP)	;YES - MOVE TO ERROR RETURN
129	047124	000402			BR	9\$	
130	047126	162716	000004		SUB	#4,(SP)	;MOVE SP TO NO ERROR RETURN
131	047132	000240			NOP		
132	047134	000207			RTS	PC	

7\$:

;AUGMENT RETURN ADDRESS IF ERROR WAS FOUND

8\$:

9\$:

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57

```

.SBTTL RECALIBRATE STATUS CHECK SUBROUTINE
;THIS SUBROUTINE CHECKS THE RESULTS OF A RECALIBRATE OPERATION
;USING THE STATUS STORED IN THE GET BUFFER.

;CALL:
;(1) JSR PC,RCLSTS ;CALL SUBROUTINE
      BR   ???      RETURN HERE IF NO ERROR
      NOP          RETURN HERE TO REPORT AN ERROR
      ERROR       ERROR NUMBER DEFINED BY SUB
      JSR PC,@(SP)+ GO BACK TO SUB FOR MORE ERROR CHECKS
      ???        RETURN HERE IF NO MORE ERRORS

RCLSTS:
;CLEAR USER'S ERROR NUMBER
      ADD #4,(SP)
      CLRB @ (SP) ;CLEAR USER'S ERROR CALL
      SUB #4,(SP) ;MOVE SP BACK TO BRANCH

;SEE IF 'PAR' OR 'ILF' OR 'OPI' OR 'IAE' IS SET
      BIT #OPI!PAR!ILF!IAE,RMER1I
      BEQ 4$ ;NONE ARE SET - GO TO NEXT CHECK

;REPORT ANY MASSBUS CONTROL BUS PARITY ERROR, I.E.,
;'PAR' = 1 AND 'DPE' = 0
      BIT #PAR,RMER1I ;WAS 'PAR' SET??
      BEQ 1$ ;NO!!
      BIT #DPE,RMER2I ;WAS 'DPE' SET??
      BNE 1$ ;YES - NOT A REGISTER ERROR
      MOV RMER1I,$GDDAT ;EXPECTED STATUS
      BIC #PAR,$GDDAT
      MOV RMER1I,$BDDAT ;RECEIVED STATUS
      ADD #4,(SP) ;MOVE SP TO USER'S ERROR CALL
      MOV #50,@(SP) ;WRITE ERROR NUMBER IN CALL
      SUB #2,(SP) ;MOVE SP TO RETURN FOR ERROR
      JSR PC,@(SP)+ ;GO REPORT ERROR
      SUB #10,(SP) ;MOVE SP BACK TO BRANCH
      NOP

1$:
;REPORT ANY 'ILF' ERROR
      BIT #ILF,RMER1I ;WAS 'ILF' SET??
      BEQ 2$ ;NO!!
      MOV RMER1I,$GDDAT ;EXPECTED STATUS
      BIC #ILF,$GDDAT
      MOV RMER1I,$BDDAT ;RECEIVED STATUS
      ADD #4,(SP) ;MOVE SP TO USER'S ERROR CALL
      MOV #71,@(SP) ;WRITE ERROR NUMBER IN CALL
      SUB #2,(SP) ;MOVE SP TO RETURN FOR ERROR
      JSR PC,@(SP)+ ;REPORT ERROR VIA USER
      SUB #10,(SP) ;MOVE SP BACK TO BRANCH
      NOP

2$:
    
```

047136
 047136 062716 000004
 047142 105076 000000
 047146 162716 000004
 047152 032737 022011 001352
 047160 001553
 047162 032737 000010 001352
 047170 001430
 047172 032737 000010 001400
 047200 001024
 047202 013737 001352 001140
 047210 042737 000010 001140
 047216 013737 001352 001142
 047224 062716 000004
 047230 112776 000050 000000
 047236 162716 000002
 047242 004736
 047244 162716 000010
 047250 000240
 047252
 047252 032737 000001 001352
 047260 001424
 047262 013737 001352 001140
 047270 042737 000001 001140
 047276 013737 001352 001142
 047304 062716 000004
 047310 112776 000071 000000
 047316 162716 000002
 047322 004736
 047324 162716 000010
 047330 000240
 047332

```

58      ;REPORT ANY 'OPI' ERROR AS
59      :
60      : . OPI DUE TO 'MOL' = 0
61      : . OPI BECAUSE ON CYLINDER LATCH DIDN'T RESET
62      BIT      #OPI,RMER1I      ;WAS OPI SET??
63      BEQ      31$              ;NO!!
64      MOV      RMER1I,$GDDAT    ;EXPECTED STATUS
65      BIC      #OPI,$GDDAT
66      MOV      RMER1I,$BDDAT    ;RECEIVED STATUS
67      ADD      #4,(SP)          ;MOVE SP TO USER'S ERROR CALL
68      MOV      #72,@(SP)        ;WRITE ERROR NUMBER IN USER'S CALL
69      BIT      #MOL,RMDSI      ;WAS 'MOL' = 0??
70      BEQ      3$              ;YES!!
71      MOV      #73,@(SP)        ;NO - CHANGE ERROR NUMBER
72      SUB      #2,(SP)          ;MOVE SP TO RETURN FOR ERROR
73      JSR      PC,@(SP)+        ;REPORT ERROR VIA USER
74      SUB      #10,(SP)         ;MOVE SP BACK TO BRANCH
75      NOP
76      31$:
77      ;REPORT AN ERROR IF 'IAE' IS SET
78      BIT      #IAE,RMER1I      ;IS 'IAE' SET??
79      BEQ      4$              ;NO!!
80      MOV      RMER1I,$GDDAT    ;EXPECTED STATUS
81      BIC      #IAE,$GDDAT
82      MOV      RMER1I,$BDDAT    ;RECEIVED STATUS
83      ADD      #4,(SP)          ;MOVE SP TO ERROR CALL
84      MOV      #70,@(SP)        ;WRITE ERROR NUMBER IN USER'S CALL
85      SUB      #2,(SP)          ;MOVE SP TO RETURN FOR ERROR
86      JSR      PC,@(SP)+        ;REPORT ERROR
87      SUB      #10,(SP)         ;MOVE SP BACK TO NO ERROR RETURN
88      NOP
89      4$:
90      ;SEE IF 'SKI' OR 'IVC' OR 'DVC' IS SET
91      BIT      #SKI!IVC!DVC,RMER2I
92      BEQ      8$              ;NONE OF THE BITS ARE SET
93
94
95
96      ;REPORT ANY 'IVC' ERROR AS
97      :
98      : . IVC WITH VV = 0
99      : . ERRONEOUS IVC ERROR
100     BIT      #IVC,RMER2I      ;WAS IVC SET??
101     BEQ      6$              ;NO!!
102     MOV      RMER2I,$GDDAT    ;EXPECTED STATUS
103     BIC      #IVC,$GDDAT
104     MOV      RMER2I,$BDDAT    ;RECEIVED STATUS
105     ADD      #4,(SP)          ;MOVE SP TO USER'S ERROR CALL
106     MOV      #74,@(SP)        ;WRITE ERROR NUMBER IN CALL
107     BIT      #VV,RMDSI        ;WAS VV = 0??
108     BEQ      5$              ;YES!!
109     MOV      #75,@(SP)        ;NO - CHANGE ERROR NUMBER
110     SUB      #2,(SP)          ;MOVE SP TO RETURN FOR ERROR
111     JSR      PC,@(SP)+        ;REPORT ERROR VIA USER
112     SUB      #10,(SP)         ;MOVE SP BACK TO BRANCH
113     NOP
114     5$:
115     6$:
    
```



```

115 ;REPORT ANY 'SKI' ERROR
116 047616 032737 040000 001400 BIT #SKI,RMER2I ;WAS SKI SET??
117 047624 001424 BEQ 7$ ;NO!!
118 047626 013737 001400 001140 MOV RMER2I,$GDDAT ;EXPECTED STATUS
119 047634 042737 040000 001140 BIC #SKI,$GDDAT
120 047642 013737 001400 001142 MOV RMER2I,$BDDAT ;RECEIVED STATUS
121 047650 062716 000004 ADD #4,(SP) ;MOVE SP TO USER'S ERROR CALL
122 047654 112776 000076 000000 MOVB #76,@(SP) ;WRITE ERROR NUMBER
123 047662 162716 000002 SUB #2,(SP) ;MOVE SP TO RETURN FOR ERROR
124 047666 004736 JSR PC,@(SP)+ ;REPORT ERROR VIA USER
125 047670 162716 000010 SUB #10,(SP) ;MOVE SP TO BRANCH
126 047674 000240 NOP
127 047676 7$:
128
129 ;REPORT ANY 'DVC' ERROR
130 047676 032737 000200 001400 BIT #DVC,RMER2I ;WAS 'DVC' SET??
131 047704 001424 BEQ 8$ ;NO!!
132 047706 013737 001400 001140 MOV RMER2I,$GDDAT ;EXPECTED STATUS
133 047714 042737 000200 001140 BIC #DVC,$GDDAT
134 047722 013737 001400 001142 MOV RMER2I,$BDDAT ;RECEIVED STATUS
135 047730 062716 000004 ADD #4,(SP) ;MOVE SP TO USER'S ERROR CALL
136 047734 112776 000077 000000 MOVB #77,@(SP) ;WRITE ERROR NUMBER
137 047742 162716 000002 SUB #2,(SP) ;MOVE SP TO RETURN FOR ERROR
138 047746 004736 JSR PC,@(SP)+ ;REPORT ERROR VIA USER
139 047750 162716 000010 SUB #10,(SP) ;MOVE SP TO USER'S BRANCH
140 047754 000240 NOP
141 047756 8$:
142
143 ;SEE IF 'PIP' AND 'OM' ARE 0, AND 'ATA','MOL' AND 'VV' ARE 1
144 047756 013746 001350 MOV RMDSI,-(SP) ;PUT RMDI ON STACK
145 047762 042716 047676 BIC #^C<PIP!MOL!VV!OM!ATA>,(SP)
146 047766 022726 110100 CMP #ATA!MOL!VV,(SP)+
147 047772 001002 BNE 85$
148 047774 000137 050410 JMP 13$
149 050000 85$:
150
151 ;REPORT AN ERROR IF MOL = 0 AND OPI = 0, I.E., MEDIUM WENT OFF
152 ;LINE AFTER RECALIBRATE WAS INITIATED
153 050000 032737 010000 001350 BIT #MOL,RMDSI ;DID MOL DROP??
154 050006 001030 BNE 9$ ;NO!!
155 050010 032737 020000 001352 BIT #OPI,RMER1I ;WAS OPI ERROR REPORTED??
156 050016 001024 BNE 9$ ;YES - DON'T REPORT MOL=0
157 050020 013737 001350 001140 MOV RMDSI,$GDDAT ;EXPECTED STATUS
158 050026 052737 010000 001140 BIS #MOL,$GDDAT
159 050034 013737 001350 001142 MOV RMDSI,$BDDAT ;RECEIVED STATUS
160 050042 062716 000004 ADD #4,(SP) ;MOVE SP TO USER'S ERROR CALL
161 050046 112776 000100 000000 MOVB #100,@(SP) ;WRITE ERROR NUMBER
162 050054 162716 000002 SUB #2,(SP) ;MOVE SP TO RETURN FOR ERROR
163 050060 004736 JSR PC,@(SP)+ ;REPORT ERROR VIA USER
164 050062 162716 000010 SUB #10,(SP) ;MOVE SP BACK TO USER'S BRANCH
165 050066 000240 NOP
166 050070 9$:
167
168 ;REPORT AN ERROR IF 'VV' = 0 AND 'IVC' = 0
169 050070 032737 000100 001350 BIT #VV,RMDSI ;DID 'VV' DROP??
170 050076 001030 BNE 10$ ;NO!!
171 050100 032737 010000 001400 BIT #IVC,RMER2I ;WAS THERE A IVC ERROR??
    
```

```

172 050106 001024          BNE      10$          ;YES - DONT REPORT VV=0
173 050110 013737 001350 001140  MOV      RMDSI,$GDDAT ;EXPECTED STATUS
174 050116 013737 001350 001142  MOV      RMDSI,$BDDAT ;RECEIVED STATUS
175 050124 052737 000100 001140  BIS      #VV,$GDDAT
176 050132 062716 000004          ADD      #4,(SP)      ;MOVE SP TO USER'S ERROR CALL
177 050136 112776 000101 000000  MOVVB   #101,@(SP)   ;WRITE ERROR NUMBER IN CALL
178 050144 162716 000002          SUB      #2,(SP)      ;MOVE SP TO RETURN FOR ERROR
179 050150 004736          JSR      PC,@(SP)+
180 050152 162716 000010  SUB      #10,(SP)     ;MOVE SP BACK TO USER'S BRANCH
181 050156 000240          NOP
182 050160
183
184
185 050160 032737 100000 001350  ;REPORT AN ERROR IF ATA IS NOT SET
186 050166 001024          BIT      #ATA,RMDSI   ;WAS ATA SET DURING RECALIBRATE??
187 050170 013737 001350 001140  BNE      11$          ;YES!!
188 050176 052737 100000 001140  MOV      RMDSI,$GDDAT ;EXPECTED STATUS
189 050204 013737 001350 001142  BIS      #ATA,$GDDAT
190 050212 062716 000004          MOV      RMDSI,$BDDAT ;RECEIVED STATUS
191 050216 112776 000102 000000  ADD      #4,(SP)      ;MOVE SP TO USER'S ERROR CALL
192 050224 162716 000002          MOVVB   #102,@(SP)   ;WRITE ERROR NUMBER IN CALL
193 050230 004736          SUB      #2,(SP)
194 050232 162716 000010  JSR      PC,@(SP)+
195 050236 000240          SUB      #10,(SP)     ;MOVE SP TO USER'S BRANCH
196
197 050240
198
199
200
201 050240 032737 000001 001350  ;REPORT AN ERROR IF 'OM' IS NOT ZERO BECAUSE RECALIBRATE SHOULD
202 050246 001424          ;ALWAYS CLEAR OFFSET MODE
203 050250 013737 001350 001140  BIT      #OM,RMDSI   ;WAS 'OM' RESET??
204 050256 042737 000001 001140  BEQ      12$          ;YES!!
205 050264 013737 001350 001142  MOV      RMDSI,$GDDAT ;EXPECTED STATUS
206 050272 062716 000004          BIC      #OM,$GDDAT
207 050276 112776 000103 000000  MOV      RMDSI,$BDDAT ;RECEIVED STATUS
208 050304 162716 000002          ADD      #4,(SP)      ;MOVE SP TO USER'S ERROR CALL
209 050310 004736          MOVVB   #103,@(SP)   ;WRITE ERROR NUMBER
210 050312 162716 000010  SUB      #2,(SP)      ;MOVE SP TO RETURN FOR ERROR
211 050316 000240          JSR      PC,@(SP)+
212 050320          SUB      #10,(SP)     ;REPORT ERROR VIA USER
213
214
215
216 050320 032737 020000 001350  ;REPORT AN ERROR IF 'PIP' IS STIL ON, I.E., DRIVE NOT ON
217 050326 001430          ;CYLINDER
218 050330 032737 040000 001400  BIT      #PIP,RMDSI   ;IS DRIVE OFF CYLINDER??
219 050336 001024          BEQ      13$          ;NO!!
220 050340 013737 001350 001140  BIT      #SKI,RMER2I  ;WAS 'SKI' DETECTED??
221 050346 042737 020000 001140  BNE      13$          ;YES-DONT REPORT 'PIP'
222 050354 013737 001350 001142  MOV      RMDSI,$GDDAT ;EXPECTED STATUS
223 050362 062716 000004          BIC      #PIP,$GDDAT
224 050366 112776 000104 000000  MOV      RMDSI,$BDDAT ;RECEIVED STATUS
225 050374 162716 000002          ADD      #4,(SP)      ;MOVE SP TO USER'S ERROR CALL
226 050400 004736          MOVVB   #104,@(SP)   ;WRITE ERROR NUMBER
227 050402 162716 000010  SUB      #2,(SP)      ;MOVE SP TO RETURN FOR ERROR
228 050406 000240          JSR      PC,@(SP)+
229
230
231
232
233
234
235
236
237
238
239
240
241
242
243
244
245
246
247
248
249
250
251
252
253
254
255
256
257
258
259
260
261
262
263
264
265
266
267
268
269
270
271
272
273
274
275
276
277
278
279
280
281
282
283
284
285
286
287
288
289
290
291
292
293
294
295
296
297
298
299
300
301
302
303
304
305
306
307
308
309
310
311
312
313
314
315
316
317
318
319
320
321
322
323
324
325
326
327
328
329
330
331
332
333
334
335
336
337
338
339
340
341
342
343
344
345
346
347
348
349
350
351
352
353
354
355
356
357
358
359
360
361
362
363
364
365
366
367
368
369
370
371
372
373
374
375
376
377
378
379
380
381
382
383
384
385
386
387
388
389
390
391
392
393
394
395
396
397
398
399
400
401
402
403
404
405
406
407
408
409
410
411
412
413
414
415
416
417
418
419
420
421
422
423
424
425
426
427
428
429
430
431
432
433
434
435
436
437
438
439
440
441
442
443
444
445
446
447
448
449
450
451
452
453
454
455
456
457
458
459
460
461
462
463
464
465
466
467
468
469
470
471
472
473
474
475
476
477
478
479
480
481
482
483
484
485
486
487
488
489
490
491
492
493
494
495
496
497
498
499
500
501
502
503
504
505
506
507
508
509
510
511
512
513
514
515
516
517
518
519
520
521
522
523
524
525
526
527
528
529
530
531
532
533
534
535
536
537
538
539
540
541
542
543
544
545
546
547
548
549
550
551
552
553
554
555
556
557
558
559
560
561
562
563
564
565
566
567
568
569
570
571
572
573
574
575
576
577
578
579
580
581
582
583
584
585
586
587
588
589
590
591
592
593
594
595
596
597
598
599
600
601
602
603
604
605
606
607
608
609
610
611
612
613
614
615
616
617
618
619
620
621
622
623
624
625
626
627
628
629
630
631
632
633
634
635
636
637
638
639
640
641
642
643
644
645
646
647
648
649
650
651
652
653
654
655
656
657
658
659
660
661
662
663
664
665
666
667
668
669
670
671
672
673
674
675
676
677
678
679
680
681
682
683
684
685
686
687
688
689
690
691
692
693
694
695
696
697
698
699
700
701
702
703
704
705
706
707
708
709
710
711
712
713
714
715
716
717
718
719
720
721
722
723
724
725
726
727
728
729
730
731
732
733
734
735
736
737
738
739
740
741
742
743
744
745
746
747
748
749
750
751
752
753
754
755
756
757
758
759
760
761
762
763
764
765
766
767
768
769
770
771
772
773
774
775
776
777
778
779
780
781
782
783
784
785
786
787
788
789
790
791
792
793
794
795
796
797
798
799
800
801
802
803
804
805
806
807
808
809
810
811
812
813
814
815
816
817
818
819
820
821
822
823
824
825
826
827
828
829
830
831
832
833
834
835
836
837
838
839
840
841
842
843
844
845
846
847
848
849
850
851
852
853
854
855
856
857
858
859
860
861
862
863
864
865
866
867
868
869
870
871
872
873
874
875
876
877
878
879
880
881
882
883
884
885
886
887
888
889
890
891
892
893
894
895
896
897
898
899
900
901
902
903
904
905
906
907
908
909
910
911
912
913
914
915
916
917
918
919
920
921
922
923
924
925
926
927
928
929
930
931
932
933
934
935
936
937
938
939
940
941
942
943
944
945
946
947
948
949
950
951
952
953
954
955
956
957
958
959
960
961
962
963
964
965
966
967
968
969
970
971
972
973
974
975
976
977
978
979
980
981
982
983
984
985
986
987
988
989
990
991
992
993
994
995
996
997
998
999
1000
    
```



```


229 050410      13$:
230
231             ;SEE IF 'ILR' OR 'RMR' OR 'UNS' IS SET
232 050410 032737 040006 001352      BIT      #ILR!RMR!UNS,RMER1I
233 050416 001514             BEQ      16$
234
235             ;REPORT AN ERROR IF 'ILR' IS SET.
236 050420 032737 000002 001352      BIT      #ILR,RMER1I      ;WAS ILR SET DURING RECALIBRATE??
237 050426 001424             BEQ      14$      ;NO!!
238 050430 013737 001352 001140      MOV      RMER1I,$GDDAT      ;EXPECTED STATUS
239 050436 042737 000002 001140      BIC      #ILR,$GDDAT
240 050444 013737 001352 001142      MOV      RMER1I,$BDDAT      ;RECEIVED STATUS
241 050452 062716 000004             ADD      #4,(SP) ;MOVE SP TO USER'S ERROR CALL
242 050456 112776 000105 000000      MOVVB   #105,@(SP) ;WRITE ERROR NUMBER IN CALL
243 050464 162716 000002             SUB      #2,(SP) ;MOVE SP TO RETURN FOR ERROR
244 050470 004736             JSR      PC,@(SP)+
245 050472 162716 000010             SUB      #10,(SP) ;MOVE SP TO USER'S BRANCH
246 050476 000240             NOP
247 050500
248
249             14$:
250 050500 032737 000004 001352      ;REPORT AN ERROR IF 'RMR' IS SET
251 050506 001424             BIT      #RMR,RMER1I      ;WAS RMR SET??
252 050510 013737 001352 001140      BEQ      15$      ;NO!!
253 050516 042737 000004 001140      MOV      RMER1I,$GDDAT      ;EXPECTED STATUS
254 050524 013737 001352 001142      BIC      #RMR,$GDDAT
255 050532 062716 000004             MOV      RMER1I,$BDDAT      ;RECEIVED STATUS
256 050536 112776 000106 000000      ADD      #4,(SP) ;MOVE SP TO USER'S ERROR CALL
257 050544 162716 000002             MOVVB   #106,@(SP) ;WRITE ERROR NUMBER IN USER'S CALL
258 050550 004736             SUB      #2,(SP) ;MOVE SP TO RETURN FOR ERROR
259 050552 162716 000010             JSR      PC,@(SP)+ ;REPORT ERROR VIA USER
260 050556 000240             SUB      #10,(SP) ;MOVE SP TO USER'S BRANCH
261 050560             NOP
262
263             15$:
264 050560 032737 040000 001352      ;REPORT AN ERROR IF 'UNS' IS SET AND 'DVC' IS 0
265 050566 001430             BIT      #UNS,RMER1I      ;WAS UNSAFE ON??
266 050570 032737 000200 001400      BEQ      16$      ;NO!!
267 050576 001024             BIT      #DVC,RMER2I      ;WAS THERE A DEVICE CHECK??
268 050600 013737 001352 001140      BNE      16$      ;YES - DON'T REPORT UNSAFE
269 050606 042737 040000 001140      MOV      RMER1I,$GDDAT      ;EXPECTED STATUS
270 050614 013737 001352 001142      BIC      #UNS,$GDDAT
271 050622 062716 000004             MOV      RMER1I,$BDDAT      ;RECEIVED STATUS
272 050626 112776 000107 000000      ADD      #4,(SP) ;MOVE SP TO USER'S ERROR CALL
273 050634 162716 000002             MOVVB   #107,@(SP) ;WRITE ERROR NUMBER
274 050640 004736             SUB      #2,(SP) ;MOVE SP TO RETURN FOR ERROR
275 050642 162716 000010             JSR      PC,@(SP)+ ;REPORT ERROR VIA USER
276 050646 000240             SUB      #10,(SP) ;MOVE SP BACK TO USER'S BRANCH
277 050650             NOP
278
279             16$:
280 050650 062716 000004             ;AUGMENT THE RETURN ADDRESS IF ANY ERROR WAS DETECTED
281 050654 105776 000000             ADD      #4,(SP) ;MOVE SP TO USER'S ERROR CALL
282 050660 001403             TSTB   @(SP) ;WAS AN ERROR REPORTED??
283 050662 062716 000004             BEQ      17$      ;NO!!
284 050666 000402             ADD      #4,(SP) ;YES - AUGMENT SP RETURN
285 050670 162716 000004             BR      18$
285 050670 162716 000004             17$: SUB      #4,(SP) ;NO ERROR - RETURN SP TO BRANCH
    
```


286 050674 000240
287 050676 000207

188:

NOP
RTS PC

:STATUS CECK IS COMPLETE




```

1      .SBTTL DRIVE CLEAR STATUS CHECK SUBROUTINE
2
3      :
4      : BR      ???      RETURN HERE IF NO ERROR
5      : NOP
6      : ERROR
7      : JSR    PC,@(SP)+  GO BACK TO SUB FOR MORE ERROR CHECKS
8      :      ???      RETURN HERE IF NO MORE ERRORS
9 050700
10
11      :CLEAR USER'S ERROR CALL
12 050700 062716 000004      ADD    #4,(SP)      ;MOVE SP TO ERROR CALL
13 050704 105076 000000      CLRB  @(SP)      ;CLEAR ERROR CALL
14 050710 162716 000004      SUB    #4,(SP)      ;MOVE SP TO USER'S BRANCH
15
16 050714 013737 001336 001142  ;REPORT ERROR IF RMCS1 NOT INITIALIZED
17 050722 042737 173700 001142  4$: MOV    RMCS1I,$BDDAT ;CHECK RMCS1
18 050730 012737 004010 001140  BIC    #^C<DVA!FNCMSK>,$BDDAT ;CLEAR DONT CARES
19 050736 023737 001140 001142  MOV    #DVA!DRVCLR,$GDDAT ;EXPECT DVA
20 050744 001443          CMP    $GDDAT,$BDDAT ;COMPARE EXPECTED & RECEIVED
21 050746 062716 000004          BEQ    6$          ;BRANCH IF EQUAL
22 050752 112776 000141 000000  ADD    #4,(SP)      ;MOVE SP TO ERROR CALL
23 050760 162716 000002          MOVB  #141,@(SP)    ;WRITE NUMBER OF ERROR IN CALL
24 050764 004736          SUB    #2,(SP)      ;MOVE SP TO RETURN FOR ERROR
25 050766 162716 000010          JSR    PC,@(SP)+    ;REPORT THE ERROR VIA USER
26 050772 000240          SUB    #10,(SP)     ;MOVE SP TO NO ERROR RETURN
27          NOP
28 050774 013737 001350 001142  ;REPORT ERROR IF RMD5 NOT INITIALIZED
29 051002 042737 021101 001142  5$: MOV    RMD5I,$BDDAT ;CHECK RMD5
30 051010 012737 010600 001140  BIC    #PGM!OM!VV!PIP,$BDDAT ;CLEAR DONT CARES
31 051016 023737 001140 001142  MOV    #MOL!DPR!DRY,$GDDAT ;EXPECT DRY & DPR
32 051024 001413          CMP    $GDDAT,$BDDAT ;COMPARE EXPECTED & RECEIVED
33 051026 062716 000004          BEQ    6$          ;BRANCH IF EQUAL
34 051032 112776 000142 000000  ADD    #4,(SP)      ;MOVE SP TO ERROR CALL
35 051040 162716 000002          MOVB  #142,@(SP)    ;WRITE NUMBER OF ERROR IN CALL
36 051044 004736          SUB    #2,(SP)      ;MOVE SP TO RETURN FOR ERROR
37 051046 162716 000010          JSR    PC,@(SP)+    ;REPORT THE ERROR VIA USER
38 051052 000240          SUB    #10,(SP)     ;MOVE SP TO NO ERROR RETURN
39          NOP
40 051054 005037 001140          ;REPORT ERROR IF RMER1 NOT INITIALIZED
41 051060 013737 001352 001142  6$: CLR    $GDDAT      ;EXPECT 0'S
42 051066 001413          MOV    RMER1I,$BDDAT ;CHECK RMER1
43 051070 062716 000004          BEQ    8$          ;BRANCH IF EQUAL
44 051074 112776 000143 000000  ADD    #4,(SP)      ;MOVE SP TO ERROR CALL
45 051102 162716 000002          MOVB  #143,@(SP)    ;WRITE NUMBER OF ERROR IN CALL
46 051106 004736          SUB    #2,(SP)      ;MOVE SP TO RETURN FOR ERROR
47 051110 162716 000010          JSR    PC,@(SP)+    ;REPORT THE ERROR VIA USER
48 051114 000240          SUB    #10,(SP)     ;MOVE SP TO NO ERROR RETURN
49          NOP
50 051116 013737 001354 001142  ;REPORT ERROR IF ATA NOT INITIALIZED
51 051124 010146          8$: MOV    RMASI,$BDDAT ;CHECK ATTENTION BIT
52 051126 010246          MOV    R1,-(SP)     ;:PUSH R1 ON STACK
53 051130 013701 001466          MOV    R2,-(SP)     ;:PUSH R2 ON STACK
54 051134 116102 000001          MOV    TSTQUE,R1
55 051140 042702 177400          MOVB  1(R1),R2
56 051144 005102          BIC    #^CATNMSK,R2
57 051146 040237 001142          COM    R2
          BIC    R2,$BDDAT
    
```

```

58 051152 012602          MOV      (SP)+,R2          ;;POP STACK INTO R2
59 051154 012601          MOV      (SP)+,R1          ;;POP STACK INTO R1
60 051156 005737 001142    TST      $BDDAT           ;;IS ATTENTION CLEARED??
61 051162 001413          BEQ      9$               ;;BRANCH IF ATTENTION CLEARED
62 051164 062716 000004    ADD      #4,(SP)          ;;MOVE SP TO ERROR CALL
63 051170 112776 000144 000000  MOVB     #144,@(SP)        ;;WRITE NUMBER OF ERROR IN CALL
64 051176 162716 000002    SUB      #2,(SP)          ;;MOVE SP TO RETURN FOR ERROR
65 051202 004736          JSR      PC,@(SP)+        ;;REPORT THE ERROR VIA USER
66 051204 162716 000010    SUB      #10,(SP)         ;;MOVE SP TO NO ERROR RETURN
67 051210 000240          NOP
68                                ;:REPORT ERROR IF RMMR1 NOT INITIALIZED
69 051212 013737 001362 001142 9$:      MOV      RMMR1I,$BDDAT    ;;CHECK RMMR
70 051220 042737 000046 001142    BIC      #WC!LS!LST,$BDDAT ;;CLEAR DONT CARES
71 051226 012737 000010 001140    MOV      #MWD,$GDDAT      ;;EXPECT WRITE DATA ON
72 051234 023737 001140 001142    CMP      $GDDAT,$BDDAT    ;;COMPARE EXPECTED AND RECEIVED
73 051242 001413          BEQ      11$              ;;BRANCH IF ZERO
74 051244 062716 000004    ADD      #4,(SP)          ;;MOVE SP TO ERROR CALL
75 051250 112776 000145 000000  MOVB     #145,@(SP)        ;;WRITE NUMBER OF ERROR IN CALL
76 051256 162716 000002    SUB      #2,(SP)          ;;MOVE SP TO RETURN FOR ERROR
77 051262 004736          JSR      PC,@(SP)+        ;;REPORT THE ERROR VIA USER
78 051264 162716 000010    SUB      #10,(SP)         ;;MOVE SP TO NO ERROR RETURN
79 051270 000240          NOP
80                                ;:REPORT ERROR IF RMMR2 NOT INITIALIZED
81 051272 013737 001376 001142 11$:     MOV      RMMR2I,$BDDAT    ;;CHECK RMMR2
82 051300 042737 140000 001142    BIC      #RQA!RQB,$BDDAT  ;;CLEAR REQA, REQB
83 051306 012737 011777 001140    MOV      #TST!1777,$GDDAT ;;EXPECT TEST BIT ON
84 051314 023737 001140 001142    CMP      $GDDAT,$BDDAT    ;;COMPARE EXPECTED & RECEIVED
85 051322 001413          BEQ      15$              ;;BRANCH IF EQUAL
86 051324 062716 000004    ADD      #4,(SP)          ;;MOVE SP TO ERROR CALL
87 051330 112776 000146 000000  MOVB     #146,@(SP)        ;;WRITE NUMBER OF ERROR IN CALL
88 051336 162716 000002    SUB      #2,(SP)          ;;MOVE SP TO RETURN FOR ERROR
89 051342 004736          JSR      PC,@(SP)+        ;;REPORT THE ERROR VIA USER
90 051344 162716 000010    SUB      #10,(SP)         ;;MOVE SP TO NO ERROR RETURN
91 051350 000240          NOP
92 051352 005037 001140 15$:     CLR      $GDDAT           ;;EXPECT ZEROS
93                                ;:REPORT ERROR IF RMEC2 NOT RESET
94 051356 013737 001404 001142 17$:     MOV      RMEC2I,$BDDAT    ;;CHECK RMEC2
95 051364 001413          BEQ      17$              ;;BRANCH IF 0
96 051366 062716 000004    ADD      #4,(SP)          ;;MOVE SP TO ERROR CALL
97 051372 112776 000150 000000  MOVB     #150,@(SP)        ;;WRITE NUMBER OF ERROR IN CALL
98 051400 162716 000002    SUB      #2,(SP)          ;;MOVE SP TO RETURN FOR ERROR
99 051404 004736          JSR      PC,@(SP)+        ;;REPORT THE ERROR VIA USER
100 051406 162716 000010   SUB      #10,(SP)         ;;MOVE SP TO NO ERROR RETURN
101 051412 000240          NOP
102                                ;:REPORT ERROR IF RMER2 NOT RESET
103 051414 013737 001400 001142 18$:     MOV      RMER2I,$BDDAT    ;;CHECK RMER2
104 051422 001413          BEQ      18$              ;;BRANCH IF NO ERROR
105 051424 062716 000004    ADD      #4,(SP)          ;;MOVE SP TO ERROR CALL
106 051430 112776 000147 000000  MOVB     #147,@(SP)        ;;WRITE NUMBER OF ERROR IN CALL
107 051436 162716 000002    SUB      #2,(SP)          ;;MOVE SP TO RETURN FOR ERROR
108 051442 004736          JSR      PC,@(SP)+        ;;REPORT THE ERROR VIA USER
109 051444 162716 000010   SUB      #10,(SP)         ;;MOVE SP TO NO ERROR RETURN
110 051450 000240          NOP
111                                18$:
112                                19$:
113 051452
114

```


1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57

```

.SBTTL DATA TRANSFER COMMAND STATUS CHECK SUBROUTINE

;THIS SUBROUTINE VERIFIES THE RESULTS OF ALL DATA TRANSFER COMMANDS
;USING STATUS STORED IN THE GET BUFFER AND TEST PARAMETERS
;STORED IN THE PUT BUFFER. ERRORS ARE REPORTED BY WRITING
;THE ERROR NUMBER IN THE USERS ERROR CALL.

;USER'S SUBROUTINE CALL:
;(1) JSR PC,DTASTS
;(2) BR ??
;(3) NOP
;(4) ERROR
;(5) JSR PC,@(SP)+
;(6) ??
;

DTASTS:

;CLEAR USER'S ERROR CALL AND ERROR FLAGS
ADD #4,(SP) ;MOVE SP TO USER'S ERROR
CLRB @(SP) ;CLEAR LOW ORDER BYTE OF TRAP
SUB #4,(SP) ;RESTORE SP TO NO ERROR
CLR 500$ ;CLEAR ERROR FLAGS

;REPORT ANY CONTROL BUS PARITY ERROR WHILE READING REMOTE REGISTERS,
;I.E., MCPE = 1
BIT #MCPE,RMCS1I ;WAS THERE A PARITY ERROR??
BEQ 10$ ;NO!!
MOV RMCS1I,$GDDAT ;EXPECTED STATUS
BIC #MCPE,$GDDAT
MOV RMCS1I,$BDDAT ;RECEIVED STATUS
ADD #4,(SP) ;MOVE SP TO USER'S ERROR CALL
MOVB #13,@(SP) ;WRITE ERROR NUMBER
SUB #2,(SP) ;MOVE SP TO RETURN IF ERROR
JSR PC,@(SP)+ ;REPORT ERROR AND RETURN
BR 30$

10$:

;REPORT ANY CONTROL BUS PARITY ERROR WHILE WRITING REMOTE REGISTERS,
;I.E., PAR = 1 AND DPE = 0
BIT #PAR,RMER1I ;WAS THERE A PARITY ERROR??
BEQ 20$ ;NO!!
BIT #DPE,RMER2I ;DATA PARITY ERROR ?
BNE 20$ ;YES!!
MOV RMER1I,$GDDAT ;EXPECTED STATUS
BIC #PAR,$GDDAT
MOV RMER1I,$BDDAT ;RECEIVED STATUS
ADD #4,(SP) ;MOVE SP TO USER'S ERROR
MOVB #50,@(SP) ;WRITE ERROR NUMBER
BIT #MXF,RMCS2I ;DID MXF GET SET??
BNE 15$ ;YES!!
MOVB #274,@(SP) ;NO - CHANGE ERROR NUMBER
SUB #2,(SP) ;MOVE SP TO RETURN IF ERROR
JSR PC,@(SP)+ ;REPORT ERROR AND RETURN
BR 30$

;LOOK FOR ANY ERRORS WHICH MAY HAVE OCCURRED DURING COMMAND INITIATION OR
    
```

051502				
051502	062716	000004		
051506	105076	000000		
051512	162716	000004		
051516	005037	055076		
051522	032737	020000	001336	
051530	001422			
051532	013737	001336	001140	
051540	042737	020000	001140	
051546	013737	001336	001142	
051554	062716	000004		
051560	112776	000013	000000	
051566	162716	000002		
051572	004736			
051574	000466			
051576				
051576	032737	000010	001352	
051604	001435			
051606	032737	000010	001400	
051614	001031			
051616	013737	001352	001140	
051624	042737	000010	001140	
051632	013737	001352	001142	
051640	062716	000004		
051644	112776	000050	000000	
051652	032737	001000	001346	
051660	001003			
051662	112776	000274	000000	
051670	162716	000002		
051674	004736			
051676	000425			


```

58      ;MECHANICAL POSITIONING
59
60      ;FIRST TEST MXF WHICH WOULD INDICATE COMPOSITE ERROR SET WHEN FUNCTION
61      ;CODE AND GO BIT WERE LOADED
62      051700      032737      001000      001346      20$:      BIT      #MXF,RMCS2I      ;WAS 'MISSED TRANSFER' SET??
63      051700      001425      001000      001346      BEQ      40$      ;NO!!
64      051706      001425      001000      001346      MOV      RMCS2I,$GDDAT      ;EXPECTED STATUS
65      051710      013737      001346      001140      BIC      #MXF,$GDDAT
66      051716      042737      001000      001140      MOV      RMCS2I,$BDDAT      ;RECEIVED STATUS
67      051724      013737      001346      001142      ADD      #4,(SP)      ;MOVE SP TO USER'S ERROR CALL
68      051732      062716      000004      000000      MOV      #275,@(SP)      ;WRITE ERROR NUMBER
69      051736      112776      000275      000000      SUB      #2,(SP)      ;MOVE SP TO RETURN IF ERROR
70      051744      162716      000002      000000      JSR      PC,@(SP)+      ;REPORT ERROR AND RETURN
71      051750      004736
72      051752      30$:
73
74      ;RESTORE SP TO NO ERROR RETURN AND BYPASS FURHTER STATUS CHECKING
75      051752      162716      000010      000010      SUB      #10,(SP)      ;MOVE SP TO NO ERROR
76      051756      000137      055050      000010      JMP      380$      ;SKIP TO END OF SUB
77
78      40$:
79
80      ;REPORT AN ERROR IF 'OPI' ERROR OCCURRED DUE TO 'MOL' = 0, OR IF 'OPI'
81      ;AND 'MOL' ARE SET, BUT 'VV' IS RESET, INDICATING AN INTERMITTENT
82      ;'MOL'
83      051762      032737      020000      001352      BIT      #OPI,RMER1I      ;IS 'OPI' SET??
84      051770      001447      020000      001352      BEQ      60$      ;NO!!
85      051772      013737      001352      001140      MOV      RMER1I,$GDDAT      ;EXPECTED STATUS
86      052000      042737      020000      001140      BIC      #OPI,$GDDAT
87      052006      013737      001352      001142      MOV      RMER1I,$BDDAT      ;RECEIVED STATUS
88      052014      032737      010000      001350      BIT      #MOL,RMDSI      ;WAS MEDIUM OFF LINE??
89      052022      001404      010000      001350      BEQ      45$      ;YES!!
90      052024      032737      000100      001350      BIT      #VV,RMDSI      ;WAS 'MOL' INTERMITTENT??
91      052032      001013      000100      001350      BNE      50$      ;NO!!
92      052034      062716      000004      000000      45$:      ADD      #4,(SP)      ;MOVE SP TO USER'S ERROR CALL
93      052040      112776      000276      000000      MOV      #276,@(SP)      ;WRITE ERROR NUMBER IN CALL
94      052046      162716      000002      000000      SUB      #2,(SP)      ;MOVE SP TO RETURN IF ERROR
95      052052      004736      000002      000010      JSR      PC,@(SP)+      ;REPORT ERROR AND RETURN
96      052054      162716      000010      000010      SUB      #10,(SP)      ;RESTORE SP TO NO ERROR
97      052060      000413
98      052062      50$:
99
100     ;REPORT 'OPI' ERROR, WHICH IS DUE TO 'ON CYLINDER' NOT DROPPING OR
101     ;'RUN' TIMEOUT (20 MS) OR SEARCH TIMEOUT (50 MS)
102     052062      062716      000004      000000      ADD      #4,(SP)      ;MOVE SP TO USER'S ERROR CALL
103     052066      112776      000277      000000      MOV      #277,@(SP)      ;WRITE ERROR NUMBER IN CALL
104     052074      162716      000002      000000      SUB      #2,(SP)      ;MOVE SP TO RETURN IF ERROR
105     052100      004736      000002      000010      JSR      PC,@(SP)+      ;REPORT ERROR AND RETURN
106     052102      162716      000010      000010      SUB      #10,(SP)      ;RESTORE SP TO NO ERROR
107     052106      000240      000010
108     052110      60$:
109
110     ;LOOK FOR 'IVC' ERROR DURING COMMAND INITIATION
111     052110      032737      010000      001400      BIT      #IVC,RMER2I      ;WAS THERE AN 'IVC' ERROR??
112     052116      001432      010000      001400      BEQ      70$      ;NO!!
113     ;REPORT 'IVC' ERROR DUE TO 'VV' = 0, OR REPORT ERRONEOUS 'IVC' ERROR
114     052120      013737      001400      001140      MOV      RMER2I,$GDDAT      ;EXPECTED STATUS
    
```

```

115 052126 042737 010000 001140 BIC #IVC,$GDDAT
116 052134 013737 001400 001142 MOV RMER2I,$BDDAT ;RECEIVED STATUS
117 052142 062716 000004 ADD #4,(SP) ;MOVE SP TO USER'S ERROR
118 052146 112776 000300 000000 MOVB #300,@(SP) ;WRITE ERROR NUMBER IN CALL
119 052154 032737 000100 001350 BIT #VV,RMDSI ;WAS VOLUME VALID??
120 052162 001403 BEQ 65$ ;NO!!
121 052164 112776 000301 000000 MOVB #301,@(SP) ;CHANGE ERROR NUMBER
122 052172 162716 000002 65$: SUB #2,(SP) ;MOVE SP TO RETURN IF ERROR
123 052176 004736 JSR PC,@(SP)+ ;REPORT 'IVC' ERROR AND RETURN
124 052200 162716 000010 SUB #10,(SP) ;RESTORE SP TO NO ERROR
125 052204 70$:
126
127 ;SEE IF 'ILF' OR 'RMR' IS SET
128 052204 032737 000007 001352 BIT #ILR!ILF!RMR,RMER1I
129 052212 001510 BEQ 100$ ;NO ERRORS DETECTED
130 ;REPORT AN ERROR IF 'ILR' IS SET
131 052214 032737 000002 001352 BIT #ILR,RMER1I ;WAS 'ILR' DETECTED??
132 052222 001424 BEQ 80$ ;NO!!
133 052224 013737 001352 001140 MOV RMER1I,$GDDAT ;EXPECTED STATUS
134 052232 042737 000002 001140 BIC #ILR,$GDDAT
135 052240 013737 001352 001142 MOV RMER1I,$BDDAT ;RECEIVED STATUS
136 052246 062716 000004 ADD #4,(SP) ;MOVE SP TO USER'S ERROR CALL
137 052252 112776 000302 000000 MOVB #302,@(SP) ;WRITE ERROR NUMBER IN CALL
138 052260 162716 000002 SUB #2,(SP) ;MOVE SP TO RETURN IF ERROR
139 052264 004736 JSR PC,@(SP)+ ;REPORT ERROR AND RETURN
140 052266 162716 000010 SUB #10,(SP) ;RESTORE SP TO NO ERROR
141 052272 000240 NOP
142 052274 80$:
143
144 ;REPORT AN ERROR IF 'ILF' IS SET
145 052274 032737 000001 001352 BIT #ILF,RMER1I ;WAS 'ILF' DETECTED??
146 052302 001424 BEQ 90$ ;NO!!
147 052304 013737 001352 001140 MOV RMER1I,$GDDAT ;EXPECTED STATUS
148 052312 042737 000001 001140 BIC #ILF,$GDDAT
149 052320 013737 001352 001142 MOV RMER1I,$BDDAT ;RECEIVED STATUS
150 052326 062716 000004 ADD #4,(SP) ;MOVE SP TO USER'S ERROR CALL
151 052332 112776 000303 000000 MOVB #303,@(SP) ;WRITE ERROR NUMBER IN CALL
152 052340 162716 000002 SUB #2,(SP) ;MOVE SP TO RETURN IF ERROR
153 052344 004736 JSR PC,@(SP)+ ;REPORT ERROR AND RETURN
154 052346 162716 000010 SUB #10,(SP) ;RESTORE SP TO NO ERROR
155 052352 000240 NOP
156 052354 90$:
157
158 ;REPORT AN ERROR IF 'RMR' IS SET
159 052354 032737 000004 001352 BIT #RMR,RMER1I ;WAS 'RMR' DETECTED??
160 052362 001424 BEQ 100$ ;NO!!
161 052364 013737 001352 001140 MOV RMER1I,$GDDAT ;EXPECTED STATUS
162 052372 042737 000004 001140 BIC #RMR,$GDDAT
163 052400 013737 001352 001142 MOV RMER1I,$BDDAT ;RECEIVED STATUS
164 052406 062716 000004 ADD #4,(SP) ;MOVE SP TO USER'S ERROR CALL
165 052412 112776 000304 000000 MOVB #304,@(SP) ;WRITE ERROR NUMBER IN CALL
166 052420 162716 000002 SUB #2,(SP) ;MOVE SP TO RETURN IF ERROR
167 052424 004736 JSR PC,@(SP)+ ;REPORT ERROR AND RETURN
168 052426 162716 000010 SUB #10,(SP) ;RESTORE SP TO NO ERROR
169 052432 000240 NOP
170 052434 100$:
171 ;DETERMINE WHETHER OR NOT 'IAE' SHOULD BE SET AND CHECK FOR ERROR
    
```



```

172 052434 012737 002000 001140      MOV      #IAE,$GDDAT      ;SETUP FOR "IAE" = 1
173 052442 052737 040000 055076      BIS      #SKI,500$      ;SETUP FOR "SKI" = 1
174 052450 023727 001446 001466      CMP      RMDCO,#822.    ;GREATER THAN LAST CYLINDER ?
175 052456 101025                BHI     110$            ;YES - CYLINDER IS INVALID
176 052460 042737 040000 055076      BIC      #SKI,500$      ;RESET SKI FLAG
177
178 052466 123737 001421 001335      CMPB    RMDAO+1,LSTRK+1 ;GREATER THAN LAST TRACK ?
179 052474 101016                BHI     110$            ;YES - TRACK IS INVALID
180
181 052476 123727 001420 000035      CMPB    RMDAO,#29.     ;IS SECTOR > 29. ?
182 052504 101410                BLOS   105$            ;NO
183 052506 032737 010000 001444      BIT      #FM16,RMOFO   ;18 BIT FORMAT ?
184 052514 001406                BEQ    110$            ;YES - SECTOR IS INVALID FOR 18 BIT MODE
185 052516 123727 001420 000037      CMPB    RMDAO,#31.     ;IS SECTOR > 31. ?
186 052524 101002                BHI     110$            ;YES - SECTOR IS INVALID
187 052526 005037 001140      105$:   CLR      $GDDAT      ;"IAE" SHOULD = 0
188
189 052532 013737 001352 001142      110$:   MOV      RMER1I,$BDDAT ;GET RECEIVED STATUS
190 052540 042737 175777 001142      BIC      #^CIAE,$BDDAT
191 052546 023737 001140 001142      CMP      $GDDAT,$BDDAT ;IS "IAE" STATUS OK??
192 052554 001004                BNE    115$            ;NO!!
193 052556 042737 040000 055076      BIC      #SKI,500$      ;IAE OK - SKI SHOULD BE 0
194 052564 000412                BR     120$
195 052566 062716 000004      115$:   ADD      #4,(SP)        ;MOVE SP TO USER'S ERROR CALL
196 052572 112776 000305 000000      MOVVB   #305,@(SP)     ;WRITE ERROR NUMBER
197 052600 162716 000002      SUB     #2,(SP)        ;MOVE SP TO RETURN IF ERROR
198 052604 004736                JSR    PC,@(SP)+      ;REPORT ERROR AND RETURN
199 052606 162716 000010      SUB     #10,(SP)       ;MOVE SP TO NO ERROR
200 052612
201
202 ;REPORT AN ERROR IF "SKI" IS SET AND "IAE" STATUS WAS OK
203 052612 013737 001400 001142      MOV      RMER2I,$BDDAT ;RECEIVED STATUS
204 052620 042737 137777 001142      BIC      #^CSKI,$BDDAT
205 052626 013737 055076 001140      MOV      500$,$GDDAT   ;EXPECTED STATUS
206 052634 042737 137777 001140      BIC      #^CSKI,$GDDAT
207 052642 032737 040000 001400      BIT      #SKI,RMER2I   ;WAS "SKI" SET??
208 052650 001417                BEQ    140$            ;NO!!
209 052652 032737 040000 055076      BIT      #SKI,500$     ;WAS SKI CAUSED BY IAE = 0??
210 052660 001032                BNE    150$            ;YES - DON'T REPORT SKI
211 052662 062716 000004      ADD      #4,(SP)        ;MOVE SP TO USERS ERROR CALL
212 052666 112776 000306 000000      MOVVB   #306,@(SP)     ;WRITE ERROR NUMBER
213 052674 162716 000002      SUB     #2,(SP)        ;MOVE SP TO RETURN IF ERROR
214 052700 004736                JSR    PC,@(SP)+      ;REPORT ERROR AND RETURN
215 052702 162716 000010      SUB     #10,(SP)       ;MOVE SP TO NO ERROR
216 052706 000417                BR     150$
217
218 052710      140$:
219
220 ;REPORT AN ERROR IF SKI = 0 AND IAE WAS NOT DETECTED
221 052710 032737 040000 055076      BIT      #SKI,500$     ;SHOULD SKI BE SET??
222 052716 001413                BEQ    150$            ;NO!!
223 052720 062716 000004      ADD      #4,(SP)        ;MOVE SP TO USER'S ERROR CALL
224 052724 112776 000307 000000      MOVVB   #307,@(SP)     ;WRITE ERROR NUMBER IN CALL
225 052732 162716 000002      SUB     #2,(SP)        ;MOVE SP TO RETURN IF ERROR
226 052736 004736                JSR    PC,@(SP)+      ;REPORT ERROR AND RETURN
227 052740 162716 000010      SUB     #10,(SP)       ;RESTORE SP TO NO ERROR
228 052744 000240                NOP
    
```



```

286 053232 013737 001352 001140      MOV    RMER1I,$GDDAT    ;EXPECTED STATUS
287 053240 042737 040000 001140      BIC    #UNS,$GDDAT
288 053246 013737 001352 001142      MOV    RMER1I,$BDDAT    ;RECEIVED STATUS
289 053254 062716 000004      ADD    #4,(SP)          ;MOVE SP TO USERS ERROR CALL
290 053260 112776 000313 000000      MOVVB #313,@(SP)       ;WRITE ERROR NUMBER
291 053266 162716 000002      SUB    #2,(SP)          ;MOVE SP TO RETURN IF ERROR
292 053272 004736      JSR    PC,@(SP)+        ;REPORT ERROR AND RETURN
293 053274 162716 000010      SUB    #10,(SP)        ;RESTORE SP TO NO ERROR
294 053300      190$:
295
296      ;REPORT ANY DRIVE TIMING ERROR, I.E., 'DTE' = 1
297 053300 032737 010000 001352      BIT    #DTE,RMER1I      ;IS DTE SET??
298 053306 001423      BEQ    200$             ;NO!!
299 053310 013737 001352 001140      MOV    RMER1I,$GDDAT    ;EXPECTED STATUS
300 053316 042737 010000 001140      BIC    #DTE,$GDDAT
301 053324 013737 001352 001142      MOV    RMER1I,$BDDAT    ;RECEIVED STATUS
302 053332 062716 000004      ADD    #4,(SP)          ;MOVE SP TO USER'S ERROR CALL
303 053336 112776 000314 000000      MOVVB #314,@(SP)       ;WRITE ERROR NUMBER IN CALL
304 053344 162716 000002      SUB    #2,(SP)          ;MOVE SP TO RETURN IF ERROR
305 053350 004736      JSR    PC,@(SP)+        ;REPORT ERROR AND RETURN
306 053352 162716 000010      SUB    #10,(SP)        ;MOVE SP TO NO ERROR
307 053356      200$:
308
309      ;REPORT AN ERROR IF WRITE LOCK ERROR IS SET. SEE IF DRIVE IS NOT
310      ;WRITE PROTECTED, OR IF FUNCTION WAS NOT A WRITE
311 053356 032737 004000 001352      BIT    #WLE,RMER1I      ;WAS 'WLE' SET??
312 053364 001441      BEQ    220$             ;NO!!
313 053366 013737 001352 001142      MOV    RMER1I,$BDDAT    ;RECEIVED STATUS
314 053374 013737 001352 001140      MOV    RMER1I,$GDDAT    ;EXPECTED STATUS
315 053402 052737 004000 001140      BIS    #WLE,$GDDAT
316 053410 062716 000004      ADD    #4,(SP)          ;MOVE SP TO USERS ERROR CALL
317 053414 112776 000315 000000      MOVVB #315,@(SP)       ;WRITE ERROR NUMBER IN CALL
318 053422 032737 004000 001350      BIT    #WRL,RMDSI       ;WAS DRIVE WRITE PROTECTED??
319 053430 001404      BEQ    205$             ;NO!!
320 053432 032737 000010 001412      BIT    #BIT3,RMCS10     ;WAS COMMAND A WRITE??
321 053440 001406      BEQ    210$             ;YES!!
322 053442 112776 000316 000000 205$: MOVVB #316,@(SP)       ;CHANGE ERROR NUMBER
323 053450 042737 004000 001140      BIC    #WLE,$GDDAT
324 053456 162716 000002 210$: SUB    #2,(SP)          ;MOVE SP TO RETURN IF ERROR
325 053462 004736      JSR    PC,@(SP)+        ;REPORT ERROR AND RETURN
326 053464 162716 000010      SUB    #10,(SP)        ;MOVE SP TO NO ERROR
327
328 053470      220$:
329
330      ;OMIT DATA ERROR CHECKS IF ANY PREVIOUS ERRORS HAVE BEEN DETECTED
331 053470 062716 000004      ADD    #4,(SP)          ;MOVE SP TO USER'S ERROR
332 053474 105776 000000      TSTB  @(SP)             ;WAS ERROR DETECTED??
333 053500 001404      BEQ    225$             ;NO - DO DATA CHECKS
334 053502 162716 000004      SUB    #4,(SP)          ;RESTORE SP
335 053506 000137 054510      JMP    340$             ;SKIP DATA CHECKS
336 053512 162716 000004 225$: SUB    #4,(SP)          ;RESTORE SP
337
338      ;CHECK HEADER ERRORS IF FUNCTION WAS NOT WRITE HEADER AND DATA, AND
339      ;IF HEADER COMPARE IS NOT INHIBITED
340 053516 013737 001412 055100      MOV    RMCS10,510$      ;STRIP AND STORE FUNCTION CODE
341 053524 042737 177700 055100      BIC    #^CFNCMSK,510$
342 053532 022737 000063 055100      CMP    #WH!GO,510$      ;WAS FUNCTION WRITE HEADER & DATA??
    
```

```

343 053540 001512          BEQ      250$          ;YES - SKIP HEADER CHECKS
344 053542 032737 002000 001370  BIT      #HCI,RMOFI      ;WAS HCI SET??
345 053550 001106          BNE      250$          ;YES - SKIP HEADER CHECKS
346
347          ;SEE IF ANY HEADER ERRORS ARE SET, I.E., 'FER' OR 'HCRC' OR 'HCE'
348 053552 032737 000620 001352  BIT      #HCRC!FER!HCE,RMER1I
349 053560 001533          BEQ      270$          ;NO ERRORS SET
350
351          ;REPORT HEADER CRC ERROR IF SET
352 053562 032737 000400 001352  BIT      #HCRC,RMER1I    ;WAS .HCRC SET??
353 053570 001422          BEQ      230$          ;NO!!
354 053572 013737 001352 001140  MOV      RMER1I,$GDDAT   ;EXPECTED STATUS
355 053600 042737 000400 001140  BIC      #HCRC,$GDDAT
356 053606 013737 001352 001142  MOV      RMER1I,$BDDAT   ;RECEIVED STATUS
357 053614 062716 000004          ADD      #4,(SP)         ;MOVE SP TO USERS ERROR
358 053620 112776 000317 000000  MOVVB   #317,@(SP)      ;WRITE ERROR NUMBER
359 053626 162716 000002          SUB      #2,(SP)         ;MOVE SP TO RETURN IF ERROR
360 053632 004736          JSR      PC,@(SP)+      ;REPORT ERROR AND RETURN
361 053634 000501          BR       260$
362 053636          230$:
363
364          ;REPORT FORMAT ERROR IF SET
365 053636 032737 000020 001352  BIT      #FER,RMER1I    ;WAS 'FER' SET??
366 053644 001422          BEQ      240$          ;NO!!
367 053646 013737 001352 001140  MOV      RMER1I,$GDDAT   ;EXPECTED STATUS
368 053654 042737 000020 001140  BIC      #FER,$GDDAT
369 053662 013737 001352 001142  MOV      RMER1I,$BDDAT   ;RECEIVED STATUS
370 053670 062716 000004          ADD      #4,(SP)         ;MOVE SP TO USERS ERROR
371 053674 112776 000320 000000  MOVVB   #320,@(SP)      ;WRITE ERROR NUMBER
372 053702 162716 000002          SUB      #2,(SP)         ;MOVE SP TO RETURN IF ERROR
373 053706 004736          JSR      PC,@(SP)+      ;REPORT ERROR AND RETURN
374 053710 000453          BR       260$
375 053712          240$:
376
377          ;REPORT HEADER COMPARE ERROR IF SET
378 053712 032737 000200 001352  BIT      #HCE,RMER1I    ;WAS 'HCE' SET??
379 053720 001453          BEQ      270$          ;NO!!
380 053722 013737 001352 001140  MOV      RMER1I,$GDDAT   ;EXPECTED STATUS
381 053730 042737 000200 001140  BIC      #HCE,$GDDAT
382 053736 013737 001352 001142  MOV      RMER1I,$BDDAT   ;RECEIVED STATUS
383 053744 062716 000004          ADD      #4,(SP)         ;MOVE SP TO USER'S ERROR
384 053750 112776 000321 000000  MOVVB   #321,@(SP)      ;WRITE ERROR NUMBER
385 053756 162716 000002          SUB      #2,(SP)         ;MOVE SP TO RETURN IF ERROR
386 053762 004736          JSR      PC,@(SP)+      ;REPORT ERROR AND RETURN
387 053764 000425          BR       260$
388          ;THERE SHOULD BE NO HEADER ERRORS BECAUSE
389          ; .COMMAND WAS WRITE HEADER AND DATA, OR
390          ; .HEADER COMPARE INHIBIT WAS SET
391 053766 032737 000620 001352  250$: BIT      #HCE!FER!HCRC,RMER1I
392 053774 001425          BEQ      270$          ;NO ERRORS WERE SET
393 053776 013737 001352 001140  MOV      RMER1I,$GDDAT   ;EXPECTED STATUS
394 054004 042737 000620 001140  BIC      #HCE!FER!HCRC,$GDDAT
395 054012 013737 001352 001142  MOV      RMER1I,$BDDAT   ;RECEIVED STATUS
396 054020 062716 000004          ADD      #4,(SP)         ;MOVE SP TO USER'S ERROR CALL
397 054024 112776 000322 000000  MOVVB   #322,@(SP)      ;WRITE ERROR NUMBER
398 054032 162716 000002          SUB      #2,(SP)         ;MOVE SP TO RETURN IF ERROR
399 054036 004736          JSR      PC,@(SP)+      ;REPORT ERROR AND RETURN
    
```



```

400 054040 162716 000010          260$: SUB    #10,(SP)      ;MOVE SP TO NO ERROR
401 054044 000137 054510          JMP     340$      ;OMIT FURTHER DATA CHECKS
402
403 054050          270$:
404
405          ;IF COMMAND WAS A WRITE COMMAND, GO DO WRITE ERROR CHECKS, OTHERWISE
406          ;DO READ ERROR CHECKS
407 054050 032737 000010 055100    BIT     #BIT3,510$ ;WAS THIS A WRITE COMMAND?
408 054056 001002          BNE     275$      ;NO!!
409 054060 000137 054276          JMP     310$      ;GO DO WRITE STATUS CHECK
410 054064          275$:
411
412          ;REPORT DATA CHECK IF SET
413 054064 032737 100000 001352    BIT     #DCK,RMER1I ;DATA CHECK ERROR??
414 054072 001450          BEQ     290$      ;NO!!
415 054074 013737 001352 001140    MOV     RMER1I,$GDDAT ;EXPECTED STATUS
416 054102 042737 100000 001140    BIC     #DCK,$GDDAT
417 054110 013737 001352 001142    MOV     RMER1I,$BDDAT ;RECEIVED STATUS
418 054116 062716 000004          ADD     #4,(SP)     ;MOVE SP TO USER'S ERROR
419 054122 112776 000323 000000    MOV     #323,@(SP) ;WRITE ERROR NUMBER
420 054130 032737 004000 001370    BIT     #ECI,RMOFI  ;WAS ECC CORRECTION DISABLED??
421 054136 001021          BNE     280$      ;YES!!
422 054140 112776 000324 000000    MOV     #324,@(SP) ;CHANGE TO RECOVERABLE ERROR
423 054146 032737 000100 001352    BIT     #ECH,RMER1I ;IS ERROR RECOVERABLE??
424 054154 001007          BNE     276$      ;NO !!
425          ;DO NOT REPORT RECOVERABLE ERROR IF READ COMMAND
426 054156 032737 000020 055100    BIT     #BIT4,510$ ;WAS THIS A READ COMMAND ??
427 054164 001406          BEQ     280$      ;NO !!
428 054166 162716 000004          SUB     #4,(SP)     ;RESTORE SP
429 054172 000410          BR      290$      ;SKIP ERROR - DATA WILL BE CORRECTED
430 054174 112776 000325 000000    276$: MOV     #325,@(SP) ;CHANGE TO NON RECOVERABLE
431 054202 162716 000002          280$: SUB     #2,(SP) ;MOVE SP TO RETURN IF ERROR
432 054206 004736          JSR     PC,@(SP)+ ;REPORT ERROR AND RETURN
433 054210 162716 000010          SUB     #10,(SP)   ;RESTORE SP TO NO ERROR
434
435 054214          290$:
436
437          ;REPORT DATA BUS PARITY ERROR IF SET, I.E., MDPE = 1
438 054214 032737 000400 001346    BIT     #MDPE,RMCS2I ;PARITY ERROR SET??
439 054222 001423          BEQ     300$      ;NO!!
440 054224 013737 001346 001140    MOV     RMCS2I,$GDDAT ;EXPECTED STATUS
441 054232 042737 000400 001140    BIC     #MDPE,$GDDAT
442 054240 013737 001346 001142    MOV     RMCS2I,$BDDAT ;RECEIVED STATUS
443 054246 062716 000004          ADD     #4,(SP)     ;MOVE SP TO USER'S ERROR
444 054252 112776 000326 000000    MOV     #326,@(SP) ;WRITE ERROR NUMBER
445 054260 162716 000002          SUB     #2,(SP)     ;MOVE SP TO RETURN IF ERROR
446 054264 004736          JSR     PC,@(SP)+ ;REPORT ERROR AND RETURN
447 054266 162716 000010          SUB     #10,(SP)   ;MOVE SP TO NO ERROR
448 054272 000137 054510          300$: JMP     340$      ;SKIP WRITE STATUS CHECK
449
450 054276          310$:
451
452          ;TEST TO SEE THAT OFFSET MODE WAS RESET; REPORT ERROR IF 'OM' = 1
453 054276 032737 000001 001350    BIT     #OM,RMDSI   ;IS OFFSET ON??
454 054304 001423          BEQ     320$      ;NO
455 054306 013737 001350 001140    MOV     RMDSI,$GDDAT ;EXPECTED STATUS
456 054314 042737 000001 001140    BIC     #OM,$GDDAT
  
```

```

457 054322 013737 001350 001142      MOV      RMDSI,$BDDAT      ;RECEIVED STATUS
458 054330 062716 000004              ADD      #4,(SP)          ;MOVE SP TO USER'S ERROR CALL
459 054334 112776 000327 000000      MOVVB   #327,@(SP)       ;WRITE ERROR NUMBER IN CALL
460 054342 162716 000002              SUB      #2,(SP)          ;MOVE SP TO RETURN IF ERROR
461 054346 004736              JSR     PC,@(SP)+        ;REPORT ERROR AND RETURN
462 054350 162716 000010              SUB      #10,(SP)        ;MOVE SP TO NO ERROR
463 054354              320$:
464
465              ;TEST FOR DATA BUS PARITY ERROR; REPORT ERROR IF 'DPE' = 1
466 054354 032737 000010 001400      BIT     #DPE,RMER2I      ;DATA PARITY ERROR??
467 054362 001423              BEQ     330$             ;NO!!
468 054364 013737 001400 001140      MOV     RMER2I,$GDDAT    ;EXPECTED STATUS
469 054372 042737 000010 001140      BIC     #DPE,$GDDAT
470 054400 013737 001400 001142      MOV     RMER2I,$BDDAT    ;RECEIVED STATUS
471 054406 062716 000004              ADD     #4,(SP)          ;MOVE SP TO USER'S ERROR CALL
472 054412 112776 000330 000000      MOVVB   #330,@(SP)       ;WRITE ERROR NUMBER
473 054420 162716 000002              SUB     #2,(SP)          ;MOVE SP TO RETURN IF ERROR
474 054424 004736              JSR     PC,@(SP)+        ;REPORT ERROR AND RETURN
475 054426 162716 000010              SUB     #10,(SP)        ;MOVE SP TO NO ERROR
476 054432              330$:
477
478              ;TEST FOR WRITE CLOCK FAILURE; REPORT ERROR IF 'WCF' = 1
479 054432 032737 000040 001352      BIT     #WCF,RMER1I      ;IS 'WCF' SET??
480 054440 001423              BEQ     340$             ;NO!!
481 054442 013737 001352 001140      MOV     RMER1I,$GDDAT    ;EXPECTED STATUS
482 054450 042737 000040 001140      BIC     #WCF,$GDDAT
483 054456 013737 001352 001142      MCV     RMER1I,$BDDAT    ;RECEIVED STATUS
484 054464 062716 000004              ADD     #4,(SP)          ;MOVE SP TO USERS ERROR CALL
485 054470 112776 000331 000000      MOVVB   #331,@(SP)       ;WRITE ERROR NUMBER
486 054476 162716 000002              SUB     #2,(SP)          ;MOVE SP TO RETURN IF ERROR
487 054502 004736              JSR     PC,@(SP)+        ;REPORT ERROR AND RETURN
488 054504 162716 000010              SUB     #10,(SP)        ;MOVE SP TO NO ERROR
489 054510              340$:
490
491              ;REPORT 'DATA LATE' ERROR IF 'DLT' = 1
492 054510 032737 100000 001346      BIT     #DLT,RMCS2I      ;IS 'DLT' SET??
493 054516 001423              BEQ     350$             ;NO!!
494 054520 013737 001346 001140      MOV     RMCS2I,$GDDAT    ;EXPECTED STATUS
495 054526 042737 100000 001140      BIC     #DLT,$GDDAT
496 054534 013737 001346 001142      MOV     RMCS2I,$BDDAT    ;RECEIVED STATUS
497 054542 062716 000004              ADD     #4,(SP)          ;MOVE SP TO USERS ERROR CALL
498 054546 112776 000332 000000      MOVVB   #332,@(SP)       ;WRITE ERROR NUMBER
499 054554 162716 000002              SUB     #2,(SP)          ;MOVE SP TO RETURN IF ERROR
500 054560 004736              JSR     PC,@(SP)+        ;REPORT ERROR AND RETURN
501 054562 162716 000010              SUB     #10,(SP)        ;MOVE SP TO NO ERROR
502 054566              350$:
503
504 054566 013746 001350              ;LOOK FOR UNEXPECTED CHANGES IN DRIVE STATUS
505 054572 042716 147677      MOV     RMDSI,-(SP)      ;STACK DRIVE STATUS
506 054576 022726 010100      BIC     #^C<PIP!MOL!VV>,(SP) ;CLEAR DONT CARES
507 054602 001522      CMP     #MOL!VV,(SP)+    ;IS DRIVE STATUS OK??
508              BEQ     380$             ;YES!!
509
510              ;REPORT ERROR IF POSITIONING IN PROGRESS AND NO SEEK INCOMPLETE ERROR,
511              ;I.E. PIP = 1 AND SKI = 0
511 054604 032737 020000 001350      BIT     #PIP,RMDSI      ;IS 'PIP' SET??
512 054612 001430              BEQ     360$             ;NO!!
513 054614 032737 040000 001400      BIT     #SKI,RMER2I      ;WAS 'SKI' ERROR REPORTED??
    
```



```

514 054622 001024          BNE      360$          :YES-DONT REPORT PIP
515 054624 013737 001350 001140  MOV      RMDSI,$GDDAT :EXPECTED STATUS
516 054632 042737 020000 001140  BIC      #PIP,$GDDAT
517 054640 013737 001350 001142  MOV      RMDSI,$BDDAT :RECEIVED STATUS
518 054646 062716 000004          ADD      #4,(SP)      :MOVE SP TO USERS ERROR CALL
519 054652 112776 000333 000000  MOVB    #333,@(SP)   :WRITE ERROR NUMBER
520 054660 162716 000002          SUB      #2,(SP)      :MOVE SP TO RETURN IF ERROR
521 054664 004736          JSR     PC,@(SP)+    :REPORT ERROR AND RETURN
522 054666 162716 000010          SUB      #10,(SP)    :MOVE SP TO NO ERROR
523 054672 000240
524 054674          360$:
525
526          :REPORT ERROR IF MEDIUM IS NOT ON LINE AND OPI ERROR WAS NOT
527          :REPORTED, I.E., MOL = OPI = 0
528 054674 032737 010000 001350  BIT      #MOL,RMDSI   :IS MEDIUM ON LINE??
529 054702 001027          BNE      370$          :YES!!
530 054704 032737 020000 001352  BIT      #OPI,RMER1I  :WAS OPI ERROR REPORTED??
531 054712 001023          BNE      370$          :YES!!
532 054714 013737 001350 001140  MOV      RMDSI,$GDDAT :EXPECTED STATUS
533 054722 052737 010000 001140  BIS      #MOL,$GDDAT
534 054730 013737 001350 001142  MOV      RMDSI,$BDDAT :RECEIVED STATUS
535 054736 062716 000004          ADD      #4,(SP)      :MOVE SP TO USER'S ERROR
536 054742 112776 000334 000000  MOVB    #334,@(SP)   :WRITE ERROR NUMBER
537 054750 162716 000002          SUB      #2,(SP)      :MOVE SP TO RETURN IF ERROR
538 054754 004736          JSR     PC,@(SP)+    :REPORT ERROR AND RETURN
539 054756 162716 000010          SUB      #10,(SP)    :MOVE SP TO NO ERROR
540 054762          370$:
541
542          :REPORT ERROR IF VOLUME IS NOT VALID AND "IVC" ERROR WAS NOT
543          :REPORTED, I.E., VV = IVC = 0
544 054762 032737 000100 001350  BIT      #VV,RMDSI    :IS VOLUME VALID??
545 054770 001027          BNE      380$          :YES!!
546 054772 032737 010000 001400  BIT      #IVC,RMER2I  :WAS IVC ERROR REPORTED??
547 055000 001033          BNE      390$          :YES!!
548 055002 013737 001350 001140  MOV      RMDSI,$GDDAT :EXPECTED STATUS
549 055010 052737 000100 001140  BIS      #VV,$GDDAT
550 055016 013737 001350 001142  MOV      RMDSI,$BDDAT :RECEIVED STATUS
551 055024 062716 000004          ADD      #4,(SP)      :MOVE SP TO USERS ERROR CALL
552 055030 112776 000335 000000  MOVB    #335,@(SP)   :WRITE ERROR NUMBER
553 055036 162716 000002          SUB      #2,(SP)      :MOVE SP TO RETURN IF ERROR
554 055042 004736          JSR     PC,@(SP)+    :REPORT ERROR AND RETURN
555 055044 162716 000010          SUB      #10,(SP)    :MOVE SP TO NO ERROR
556 055050          380$:
557
558          :AUGMENT THE RETURN ADDRESS IF ANY ERROR WAS FOUND
559 055050 062716 000004          ADD      #4,(SP)      :MOVE SP TO ERROR CALL
560 055054 105776 000000          TSTB    @(SP)        :ANY ERROR??
561 055060 001403          BEQ     390$          :NO!!
562 055062 062716 000004          ADD      #4,(SP)      :YES - MOVE SP TO ERROR RETURN
563 055066 000402          BR     400$
564 055070 162716 000004          390$: SUB      #4,(SP)    :MOVE SP TO NO ERROR RETURN
565
566 055074 000207          400$: RTS      PC      :RETURN TO USER
567
568 055076 000000          500$: .WORD          :ERROR FLAGS
569 055100 000000          510$: .WORD          :TEMPORARY STORAGE

```

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57

055102
 055102 062716 000004
 055106 105076 000000
 055112 162716 000004
 055116 013746 001350
 055122 042716 147677
 055126 022726 010100
 055132 001524
 055134 032737 010000 001350
 055142 001030
 055144 032737 020000 001352
 055152 001024
 055154 013737 001350 001140
 055162 052737 010000 001140
 055170 013737 001350 001142
 055176 062716 000004
 055202 112776 000207 000000
 055210 162716 000002
 055214 004736
 055216 162716 000010
 055222 000240
 055224
 055224 032737 000100 001350
 055232 001030

```

.SBTTL  STATIC DRIVE STATUS CHECK SUBROUTINE

:THIS SUBROUTINE LOOKS FOR UNEXPECTED CHANGES IN DRIVE
:STATUS, SUCH AS THE DRIVE LOSING VOLUME VALID.  THE SUBROUTINE
:CAN BE USED BY HOUSEKEEPING AND OTHER COMMANDS DURING WHICH THERE
:SHOULD NOT BE ANY DRIVE ERRORS OR CHANGES IN STATE.

:THE FOLLOWING CONDITIONS ARE TESTED AND REPORTED AS ERRORS
:IF TRUE:

:      .MOL = 0, INDICATES DRIVE WENT OFFLINE, NOTE
:      THAT MOL IS ASSUMED TO HAVE BEEN SET
:      .VV = 0, INDICATES THE DRIVE LOST VOLUME VALID
:      .PIP = 1, INDICATES THAT THE DRIVE IS OFF CYLINDER
:      .SKI = 1, INDICATES THE DRIVE HAS AN UNEXPECTED SKI ERROR
:      .DVC = 1, INDICATES AN UNEXPECTED DEVICE FAULT

:THE SUBROUTINE IS CALLED AFTER STORING STATUS IN THE GET BUFFER.

:(1)  JSR    PC,STCDRVSTS
:      BR     ???          RETURN HERE IF NO ERROR
:      NOP    ???          RETURN HERE TO REPORT AN ERROR
:      ERROR  ???          ERROR NUMBER DEFINED BY SUB
:      JSR    PC,@(SP)+    GO BACK TO SUB FOR MORE ERROR CHECKS
:      ???    ???          RETURN HERE IF NO MORE ERRORS

STCDRVSTS:

:CLEAR USER'S ERROR CALL
ADD    #4,(SP) ;MOVE SP TO USER'S ERROR CALL
CLRB   @4(SP) ;CLEAR ERROR NUMBER
SUB    #4,(SP) ;MOVE SP BACK TO NO ERROR RETURN

:SEE IF 'MOL' = 'VV' = 1, AND 'PIP' = 0
MOV    RMDSI,-(SP) ;PUT DRIVE STATUS ON STACK
BIC    #^C<PIP!MOL!VV>,(SP)
CMP    #MOL!VV,(SP)+ ;ARE MOL,VV AND PIP O.K.??
BEQ    30$ ;YES!!

:REPORT AN ERROR IF MOL = 0 AND 'OPI' = 0
BIT    #MOL,RMDSI ;IS MOL ON ??
BNE    10$ ;YES!!
BIT    #OPI,RMER1I ;WAS 'OPI' SET??
BNE    10$ ;YES-DONT REPORT 'MOL' = 0
MOV    RMDSI,$GDDAT ;EXPECTED STATUS
BIS    #MOL,$GDDAT
MOV    RMDSI,$BDDAT ;RECEIVED STATUS
ADD    #4,(SP) ;MOVE SP TO USER'S ERROR CALL
MOVB   #207,@(SP) ;WRITE ERROR NUMBER IN CALL
SUB    #2,(SP) ;MOVE SP TO RETURN FOR ERROR
JSR    PC,@(SP)+ ;REPORT ERROR VIA USER
SUB    #10,(SP) ;MOVE SP BACK TO NO ERROR RETURN
NOP

10$:

:REPORT AN ERROR IF VOLUME VALID IS NOW ZERO AND 'IVC' = 0
BIT    #VV,RMDSI ;IS 'VV' = 0??
BNE    20$ ;NO!!
    
```



```

58 055234 032737 010000 001400      BIT      #IVC,RMER2I      ;WAS 'IVC' SET??
59 055242 001024                    BNE      20$             ;YES-DONT REPORT 'VV' = 0
60 055244 013737 001350 001140      MOV      RMDSI,$GDDAT    ;EXPECTED STATUS
61 055252 052737 000100 001350      BIS      #VV,RMDSI
62 055260 013737 001350 001142      MOV      RMDSI,$BDDAT    ;RECEIVED STATUS
63 055266 062716 000004                    ADD      #4,(SP)         ;MOVE SP TO USER'S ERROR CALL
64 055272 112776 000210 000000      MOVVB   #210,@(SP)      ;WRITE ERROR NUMBER IN CALL
65 055300 162716 000002                    SUB      #2,(SP)         ;MOVE SP TO RETURN FOR ERROR
66 055304 004736                    JSR      PC,@(SP)+       ;REPORT ERROR VIA USER
67 055306 162716 000010                    SUB      #10,(SP)        ;MOVE SP BACK TO NO ERROR
68 055312 000240                    NOP
69 055314                    20$:
70
71                                ;REPORT AN ERROR IF DRIVE IS OFF CYLINDER AND 'SKI' = 0
72 055314 032737 020000 001350      BIT      #PIP,RMDSI      ;IS DRIVE OFF CYLINDER??
73 055322 001430                    BEQ      30$             ;NO!!
74 055324 032737 040000 001400      BIT      #SKI,RMER2I     ;WAS 'SKI' SET??
75 055332 001024                    BNE      30$             ;YES-DONT REPORT 'PIP' = 1
76 055334 013737 001350 001140      MOV      RMDSI,$GDDAT    ;EXPECTED STATUS
77 055342 042737 020000 001140      BIC      #PIP,$GDDAT
78 055350 013737 001350 001142      MOV      RMDSI,$BDDAT    ;RECEIVED STATUS
79 055356 062716 000004                    ADD      #4,(SP)         ;MOVE SP TO USER'S ERROR CALL
80 055362 112776 000211 000000      MOVVB   #211,@(SP)      ;WRITE ERROR NUMBER IN USER'S CALL
81 055370 162716 000002                    SUB      #2,(SP)         ;MOVE SP TO RETURN FOR ERROR
82 055374 004736                    JSR      PC,@(SP)+       ;REPORT ERROR VIA USER
83 055376 162716 000010                    SUB      #10,(SP)        ;MOVE SP TO NO ERROR RETURN
84 055402 000240                    NOP
85 055404                    30$:
86
87                                ;SEE IF 'SKI' = 'DVC' = 0
88 055404 013746 001400                    MOV      RMER2I,-(SP)    ;PUT ERROR REG 2 ON STACK
89 055410 042726 137577                    BIC      #^C<SKI!DVC>,(SP)+
90 055414 001460                    BEQ      60$             ;BRANCH IF NO ERROR
91 055416                    40$:
92
93                                ;REPORT AN ERROR IF THERE IS A DEVICE FAULT
94 055416 032737 000200 001400      BIT      #DVC,RMER2I     ;ANY DEVICE FAULT??
95 055424 001424                    BEQ      50$             ;NO!!
96 055426 013737 001400 001140      MOV      RMER2I,$GDDAT    ;EXPECTED STATUS
97 055434 042737 000200 001140      BIC      #DVC,$GDDAT
98 055442 013737 001400 001142      MOV      RMER2I,$BDDAT    ;RECEIVED STATUS
99 055450 062716 000004                    ADD      #4,(SP)         ;MOVE SP TO USER'S CALL
100 055454 112776 000212 000000      MOVVB   #212,@(SP)      ;WRITE NUMBER OF ERROR IN CALL
101 055462 162716 000002                    SUB      #2,(SP)         ;MOVE SP TO RETURN FOR ERROR
102 055466 004736                    JSR      PC,@(SP)+       ;REPORT ERROR VIA USER
103 055470 162716 000010                    SUB      #10,(SP)        ;MOVE SP BACK TO NO ERROR
104 055474 000240                    NOP
105 055476                    50$:
106
107                                ;REPORT AN ERROR IF 'SKI' = 1
108 055476 032737 040000 001400      BIT      #SKI,RMER2I     ;IS THERE A SEEK INCOMPLETE ERROR
109 055504 001424                    BEQ      60$             ;NO!!
110 055506 013737 001400 001140      MOV      RMER2I,$GDDAT    ;EXPECTED STATUS
111 055514 042737 040000 001140      BIC      #SKI,$GDDAT
112 055522 013737 001400 001142      MOV      RMER2I,$BDDAT    ;RECEIVED STATUS
113 055530 062716 000004                    ADD      #4,(SP)         ;MOVE SP TO USER'S ERROR CALL
114 055534 112776 000213 000000      MOVVB   #213,@(SP)      ;WRITE ERROR NUMBER IN USER'S ERROR CALL
    
```

```
115 055542 162716 000002          SUB    #2,(SP)          ;MOVE SP TO RETURN FOR ERROR
116 055546 004736          JSR    PC,@(SP)+      ;REPORT ERROR VIA USER
117 055550 162716 000010          SUB    #10,(SP)       ;MOVE SP BACK TO NO ERROR
118 055554 000240          NOP
119 055556          60$:
120
121          ;AUGMENT THE RETURN ADDRESS IF ANY ERROR WAS DETECTED
122 055556 062716 000004          ADD    #4,(SP)       ;MOVE SP TO USER'S ERROR CALL
123 055562 105776 000000          TSTB  @ (SP)         ;WAS AN ERROR DETECTED??
124 055566 001403          BEQ   70$           ;NO!!
125 055570 062716 000004          ADD    #4,(SP)       ;YES - MOVE SP TO USER'S ERROR RETURN
126 055574 000402          BR   80$           ;
127 055576 162716 000004          70$: SUB    #4,(SP)   ;NO - MOVE SP TO NO ERROR RETURN
128 055602 000240          80$: NOP
129 055604 000207          RTS    PC          ;RETURN TO USER
```


1

.SBTTL SAVE AND RESTORE R0-R5 ROUTINES

```

:*****
:*SAVE R0-R5
:*CALL:
:*   SAVREG
:*UPON RETURN FROM $SAVREG THE STACK WILL LOOK LIKE:
:*
:*TOP---(+16)
:* +2---(+18)
:* +4---R5
:* +6---R4
:* +8---R3
:*+10---R2
:*+12---R1
:*+14---R0
    
```

```

055606          $SAVREG:
055606 010046      MOV     R0,-(SP)      ;;PUSH R0 ON STACK
055610 010146      MOV     R1,-(SP)      ;;PUSH R1 ON STACK
055612 010246      MOV     R2,-(SP)      ;;PUSH R2 ON STACK
055614 010346      MOV     R3,-(SP)      ;;PUSH R3 ON STACK
055616 010446      MOV     R4,-(SP)      ;;PUSH R4 ON STACK
055620 010546      MOV     R5,-(SP)      ;;PUSH R5 ON STACK
055622 016646 000022  MOV     22(SP),-(SP)  ;;SAVE PS OF MAIN FLOW
055626 016646 000022  MOV     22(SP),-(SP)  ;;SAVE PC OF MAIN FLOW
055632 016646 000022  MOV     22(SP),-(SP)  ;;SAVE PS OF CALL
055636 016646 000022  MOV     22(SP),-(SP)  ;;SAVE PC OF CALL
055642 000002      RTI
    
```

```

:*RESTORE R0-R5

```

```

:*CALL:
:*   RESREG
$RESREG:
MOV     (SP)+,22(SP)  ;;RESTORE PC OF CALL
MOV     (SP)+,22(SP)  ;;RESTORE PS OF CALL
MOV     (SP)+,22(SP)  ;;RESTORE PC OF MAIN FLOW
MOV     (SP)+,22(SP)  ;;RESTORE PS OF MAIN FLOW
MOV     (SP)+,R5      ;;POP STACK INTO R5
MOV     (SP)+,R4      ;;POP STACK INTO R4
MOV     (SP)+,R3      ;;POP STACK INTO R3
MOV     (SP)+,R2      ;;POP STACK INTO R2
MOV     (SP)+,R1      ;;POP STACK INTO R1
MOV     (SP)+,R0      ;;POP STACK INTO R0
RTI
    
```

```

055644          $RESREG:
055644 012666 000022  MOV     (SP)+,22(SP)
055650 012666 000022  MOV     (SP)+,22(SP)
055654 012666 000022  MOV     (SP)+,22(SP)
055660 012666 000022  MOV     (SP)+,22(SP)
055664 012605      MOV     (SP)+,R5
055666 012604      MOV     (SP)+,R4
055670 012603      MOV     (SP)+,R3
055672 012602      MOV     (SP)+,R2
055674 012601      MOV     (SP)+,R1
055676 012600      MOV     (SP)+,R0
055700 000002      RTI
    
```

.SBTTL BINARY TO ASCII AND TYPE ROUTINE

::*****
 ::*THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 16-BIT
 ::*BINARY-ASCII NUMBER AND TYPE IT.
 ::*CALL:

```

:*      MOV      NUMBER,-(SP)      ::NUMBER TO BE TYPED
:*      TYPBN
::*
055702 010146          $TYPBN: MOV      R1,-(SP)      ::SAVE R1 ON THE STACK
055704 016601 000006  MOV      6(SP),R1      ::GET THE INPUT NUMBER
055710 000261          SEC                          ::SET 'C' SO CAN KEEP TRACK OF THE NUMBER OF BITS
055712 112737 000060 055754 1$:  MOVB    #'0,$BIN      ::SET CHARACTER TO AN ASCII '0'.
055720 006101          ROL      R1                          ::GET THIS BIT
055722 001406          BEQ      2$                          ::DONE?
055724 105537 055754  ADCB    $BIN                          ::NO--SET THE CHARACTER EQUAL TO THIS BIT
055730 104401 055754  TYPE    ,$BIN                          ::GO TYPE THIS BIT
055734 000241          CLC                          ::CLEAR 'C' SO CAN KEEP TRACK OF BITS
055736 000765          BR      1$                          ::GO DO THE NEXT BIT
055740 012601          2$:  MOV      (SP)+,R1      ::POP THE STACK INTO R1
055742 016666 000002 000004  MOV      2(SP),4(SP)    ::ADJUST THE STACK
055750 012616          MOV      (SP)+,(SP)
055752 000002          RTI                          ::RETURN TO USER
055754 000 000          $BIN:  .BYTE  0,0      ::STORAGE FOR ASCII CHAR. AND TERMINATOR
  
```


.SBTTL CONVERT BINARY TO DECIMAL AND TYPE ROUTINE

 *THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 5-DIGIT
 *SIGNED DECIMAL (ASCII) NUMBER AND TYPE IT. DEPENDING ON WHETHER THE
 *NUMBER IS POSITIVE OR NEGATIVE A SPACE OR A MINUS SIGN WILL BE TYPED
 *BEFORE THE FIRST DIGIT OF THE NUMBER. LEADING ZEROS WILL ALWAYS BE
 *REPLACED WITH SPACES.
 *CALL:

* MOV NUM,-(SP) ;:PUT THE BINARY NUMBER ON THE STACK
 * TYPDS ;:GO TO THE ROUTINE

055756				\$TYPDS:	MOV	R0,-(SP)	:::PUSH R0 ON STACK
055756	010046				MOV	R1,-(SP)	:::PUSH R1 ON STACK
055760	010146				MOV	R2,-(SP)	:::PUSH R2 ON STACK
055762	010246				MOV	R3,-(SP)	:::PUSH R3 ON STACK
055764	010346				MOV	R5,-(SP)	:::PUSH R5 ON STACK
055766	010546				MOV	#20200,-(SP)	:::SET BLANK SWITCH AND SIGN
055770	012746	020200			MOV	20(SP),R5	:::GET THE INPUT NUMBER
055774	016605	000020			BPL	1\$:::BR IF INPUT IS POS.
056000	100004				NEG	R5	:::MAKE THE BINARY NUMBER POS.
056002	005405				MOVB	#'-,1(SP)	:::MAKE THE ASCII NUMBER NEG.
056004	112766	000055	000001	1\$:	CLR	R0	:::ZERO THE CONSTANTS INDEX
056012	005000				MOV	#\$DBLK,R3	:::SETUP THE OUTPUT POINTER
056014	012703	056172			MOVB	#',(R3)+	:::SET THE FIRST CHARACTER TO A BLANK
056020	112723	000040		2\$:	CLR	R2	:::CLEAR THE BCD NUMBER
056024	005002				MOV	\$DTBL(R0),R1	:::GET THE CONSTANT
056026	016001	056162		3\$:	SUB	R1,R5	:::FORM THIS BCD DIGIT
056032	160105				BLT	4\$:::BR IF DONE
056034	002402				INC	R2	:::INCREASE THE BCD DIGIT BY 1
056036	005202				BR	3\$	
056040	000774			4\$:	ADD	R1,R5	:::ADD BACK THE CONSTANT
056042	060105				TST	R2	:::CHECK IF BCD DIGIT=0
056044	005702				BNE	5\$:::FALL THROUGH IF 0
056046	001002				TSTB	(SP)	:::STILL DOING LEADING 0'S?
056050	105716				BMI	7\$:::BR IF YES
056052	100407			5\$:	ASLB	(SP)	:::MSD?
056054	106316				BCC	6\$:::BR IF NO
056056	103003				MOVB	1(SP),-1(R3)	:::YES--SET THE SIGN
056060	116663	000001	177777	6\$:	BIS	#'0,R2	:::MAKE THE BCD DIGIT ASCII
056066	052702	000060		7\$:	BIS	#',R2	:::MAKE IT A SPACE IF NOT ALREADY A DIGIT
056072	052702	000040			MOVB	R2,(R3)+	:::PUT THIS CHARACTER IN THE OUTPUT BUFFER
056076	110223				TST	(R0)+	:::JUST INCREMENTING
056100	005720				CMP	R0,#10	:::CHECK THE TABLE INDEX
056102	020027	000010			BLT	2\$:::GO DO THE NEXT DIGIT
056106	002746				BGT	8\$:::GO TO EXIT
056110	003002				MOV	R5,R2	:::GET THE LSD
056112	010502				BR	6\$:::GO CHANGE TO ASCII
056114	000764			8\$:	TSTB	(SP)+	:::WAS THE LSD THE FIRST NON-ZERO?
056116	105726				BPL	9\$:::BR IF NO
056120	100003				MOVB	-1(SP),-2(R3)	:::YES--SET THE SIGN FOR TYPING
056122	116663	177777	177776	9\$:	CLRB	(R3)	:::SET THE TERMINATOR
056130	105013				MOV	(SP)+,R5	:::POP STACK INTO R5
056132	012605				MOV	(SP)+,R3	:::POP STACK INTO R3
056134	012603				MOV	(SP)+,R2	:::POP STACK INTO R2
056136	012602				MOV	(SP)+,R1	:::POP STACK INTO R1
056140	012601						

```
056142 012600          MOV      (SP)+,R0          ;;POP STACK INTO R0
056144 104401 056172   TYPE      ,SDBLK          ;;NOW TYPE THE NUMBER
056150 016666 000002 000004   MOV      2(SP),4(SP)      ;;ADJUST THE STACK
056156 012616          MOV      (SP)+,(SP)
056160 000002          RTI                          ;;RETURN TO USER
056162 023420          $DTBL: 10000.
056164 001750          1000.
056166 000144          100.
056170 000012          10.
056172          $DBLK: .BLKW 4
```


.SBTTL BINARY TO OCTAL (ASCII) AND TYPE

```

*****
*THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 6-DIGIT
*OCTAL (ASCII) NUMBER AND TYPE IT.
*$TYPOS---ENTER HERE TO SETUP SUPPRESS ZEROS AND NUMBER OF DIGITS TO TYPE
*CALL:
*      MOV      NUM,-(SP)      ;;NUMBER TO BE TYPED
*      TYPOS    ;;CALL FOR TYPEOUT
*      .BYTE   N              ;;N=1 TO 6 FOR NUMBER OF DIGITS TO TYPE
*      .BYTE   M              ;;M=1 OR 0
*                               ;;1=TYPE LEADING ZEROS
*                               ;;0=SUPPRESS LEADING ZEROS

```

```

*$TYPON---ENTER HERE TO TYPE OUT WITH THE SAME PARAMETERS AS THE LAST
*$TYPOS OR $TYPOC

```

```

*CALL:
*      MOV      NUM,-(SP)      ;;NUMBER TO BE TYPED
*      TYPON    ;;CALL FOR TYPEOUT

```

```

*$TYPOC---ENTER HERE FOR TYPEOUT OF A 16 BIT NUMBER

```

```

*CALL:
*      MOV      NUM,-(SP)      ;;NUMBER TO BE TYPED
*      TYPOC    ;;CALL FOR TYPEOUT

```

056202	017646	000000		\$TYPOS:	MOV	@(SP),-(SP)	;;PICKUP THE MODE
056206	116637	000001	056425		MOVB	1(SP), \$OFILL	;;LOAD ZERO FILL SWITCH
056214	112637	056427			MOVB	(SP)+, \$OMODE+1	;;NUMBER OF DIGITS TO TYPE
056220	062716	000002			ADD	#2,(SP)	;;ADJUST RETURN ADDRESS
056224	000406				BR	\$TYPON	
056226	112737	000001	056425	\$TYPOC:	MOVB	#1,\$OFILL	;;SET THE ZERO FILL SWITCH
056234	112737	000006	056427		MOVB	#6,\$OMODE+1	;;SET FOR SIX(6) DIGITS
056242	112737	000005	056424	\$TYPON:	MOVB	#5,\$OCNT	;;SET THE ITERATION COUNT
056250	010346				MOV	R3,-(SP)	;;SAVE R3
056252	010446				MOV	R4,-(SP)	;;SAVE R4
056254	010546				MOV	R5,-(SP)	;;SAVE R5
056256	113704	056427			MOVB	\$OMODE+1,R4	;;GET THE NUMBER OF DIGITS TO TYPE
056262	005404				NEG	R4	
056264	062704	000006			ADD	#6,R4	;;SUBTRACT IT FOR MAX. ALLOWED
056270	110437	056426			MOVB	R4,\$OMODE	;;SAVE IT FOR USE
056274	113704	056425			MOVB	\$OFILL,R4	;;GET THE ZERO FILL SWITCH
056300	016605	000012			MOV	12(SP),R5	;;PICKUP THE INPUT NUMBER
056304	005003				CLR	R3	;;CLEAR THE OUTPUT WORD
056306	006105			1\$:	ROL	R5	;;ROTATE MSB INTO 'C'
056310	000404				BR	3\$;;GO DO MSB
056312	006105			2\$:	ROL	R5	;;FORM THIS DIGIT
056314	006105				ROL	R5	
056316	006105				ROL	R5	
056320	010503				MOV	R5,R3	
056322	006103			3\$:	ROL	R3	;;GET LSB OF THIS DIGIT
056324	105337	056426			DECB	\$OMODE	;;TYPE THIS DIGIT?
056330	100016				BPL	7\$;;BR IF NO
056332	042703	177770			BIC	#177770,R3	;;GET RID OF JUNK
056336	001002				BNE	4\$;;TEST FOR 0
056340	005704				TST	R4	;;SUPPRESS THIS 0?
056342	001403				BEQ	5\$;;BR IF YES
056344	005204			4\$:	INC	R4	;;DON'T SUPPRESS ANYMORE 0'S

```

056346 052703 000060
056352 052703 000040
056356 110337 056422
056362 104401 056422
056366 105337 056424
056372 003347
056374 002402
056376 005204
056400 000744
056402 012605
056404 012604
056406 012603
056410 016666 000002 000004
056416 012616
056420 000002
056422 000
056423 000
056424 000
056425 000
056426 000000

5$: BIS #'0,R3
    BIS #' ,R3
    MOVB R3,8$
    TYPE ,8$
7$: DECB $OCNT
    BGT 2$
    BLT 6$
    INC R4
    BR 2$
6$: MOV (SP)+,R5
    MOV (SP)+,R4
    MOV (SP)+,R3
    MOV 2(SP),4(SP)
    MOV (SP)+,(SP)
8$: .BYTE 0
    .BYTE 0
$OCNT: .BYTE 0
$OFILL: .BYTE 0
$OMODE: .WORD 0

::MAKE THIS DIGIT ASCII
::MAKE ASCII IF NOT ALREADY
::SAVE FOR TYPING
::GO TYPE THIS DIGIT
::COUNT BY 1
::BR IF MORE TO DO
::BR IF DONE
::INSURE LAST DIGIT ISN'T A BLANK
::GO DO THE LAST DIGIT
::RESTORE R5
::RESTORE R4
::RESTORE R3
::SET THE STACK FOR RETURNING
::RETURN
::STORAGE FOR ASCII DIGIT
::TERMINATOR FOR TYPE ROUTINE
::OCTAL DIGIT COUNTER
::ZERO FILL SWITCH
::NUMBER OF DIGITS TO TYPE
    
```


.SBTTL TYPE ROUTINE

```

*****
*ROUTINE TO TYPE ASCIZ MESSAGE. MESSAGE MUST TERMINATE WITH A 0 BYTE.
*THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED.
*NOTE1: $NULL CONTAINS THE CHARACTER TO BE USED AS THE FILLER CHARACTER.
*NOTE2: $FILLS CONTAINS THE NUMBER OF FILLER CHARACTERS REQUIRED.
*NOTE3: $FILLC CONTAINS THE CHARACTER TO FILL AFTER.

```

```

*CALL:
*1) USING A TRAP INSTRUCTION
*      TYPE      ,MESADR      ;;MESADR IS FIRST ADDRESS OF AN ASCIZ STRING
*OR
*      TYPE
*      MESADR

```

056430	105737	001173	\$TYPE:	TSTB	\$TPFLG	:: IS THERE A TERMINAL?
056434	100002			BPL	1\$:: BR IF YES
056436	000000			HALT		:: HALT HERE IF NO TERMINAL
056440	000430			BR	3\$:: LEAVE
056442	010046		1\$:	MOV	RO,-(SP)	:: SAVE RO
056444	017600	000002		MOV	@2(SP),RO	:: GET ADDRESS OF ASCIZ STRING
056450	122737	000001	001242	CMPB	#APTENV,\$ENV	:: RUNNING IN APT MODE
056456	001011			BNE	62\$:: NO,GO CHECK FOR APT CONSOLE
056460	132737	000100	001243	BITB	#APTSPOOL,\$ENVM	:: SPOOL MESSAGE TO APT
056466	001405			BEQ	62\$:: NO,GO CHECK FOR CONSOLE
056470	010037	056500		MOV	RO,61\$:: SETUP MESSAGE ADDRESS FOR APT
056474	004737	063106		JSR	PC,\$ATY3	:: SPOOL MESSAGE TO APT
056500	000000		61\$:	.WORD	0	:: MESSAGE ADDRESS
056502	132737	000040	001243	62\$:	BITB	#APTCSUP,\$ENVM
056510	001003			BNE	60\$:: APT CONSOLE SUPPRESSED
056512	112046		2\$:	MOVB	(RO)+,-(SP)	:: YES,SKIP TYPE OUT
056514	001005			BNE	4\$:: BR IF IT ISN'T THE TERMINATOR
056516	005726			TST	(SP)+	:: IF TERMINATOR POP IT OFF THE STACK
056520	012600		60\$:	MOV	(SP)+,RO	:: RESTORE RO
056522	062716	000002	3\$:	ADD	#2,(SP)	:: ADJUST RETURN PC
056526	000002			RTI		:: RETURN
056530	122716	000011	4\$:	CMPB	#HT,(SP)	:: BRANCH IF <HT>
056534	001430			BEQ	8\$	
056536	122716	000200		CMPB	#CRLF,(SP)	:: BRANCH IF NOT <CRLF>
056542	001006			BNE	5\$	
056544	005726			TST	(SP)+	:: POP <CR><LF> EQUIV
056546	104401			TYPE		:: TYPE A CR AND LF
056550	001217			\$CRLF		
056552	105037	056760		CLRB	\$CHARCNT	:: CLEAR CHARACTER COUNT
056556	000755			BR	2\$:: GET NEXT CHARACTER
056560	004737	056642	5\$:	JSR	PC,\$TYPEC	:: GO TYPE THIS CHARACTER
056564	123726	001172	6\$:	CMPB	\$FILLC,(SP)+	:: IS IT TIME FOR FILLER CHARS.?
056570	001350			BNE	2\$:: IF NO GO GET NEXT CHAR.
056572	013746	001170		MOV	\$NULL,-(SP)	:: GET # OF FILLER CHARS. NEEDED
						:: AND THE NULL CHAR.
056576	105366	000001	7\$:	DECB	1(SP)	:: DOES A NULL NEED TO BE TYPED?
056602	002770			BLT	6\$:: BR IF NO--GO POP THE NULL OFF OF STACK
056604	004737	056642		JSR	PC,\$TYPEC	:: GO TYPE A NULL
056610	105337	056760		DECB	\$CHARCNT	:: DO NOT COUNT AS A COUNT
056614	000770			BR	7\$:: LOOP

:HORIZONTAL TAB PROCESSOR

056616	112716	000040		8\$:	MOVB	#' (SP)	::REPLACE TAB WITH SPACE
056622	004737	056642		9\$:	JSR	PC,\$TYPEC	::TYPE A SPACE
056626	132737	000007	056760		BITB	#7,\$CHARCNT	::BRANCH IF NOT AT
056634	001372				BNE	9\$::TAB STOP
056636	005726				TST	(SP)+	::POP SPACE OFF STACK
056640	000724				BR	2\$::GET NEXT CHARACTER
056642				\$TYPEC:			
056642	105777	122312			TSTB	@\$TKS	::CHAR IN KYBD BUFFER?
056646	100022				BPL	10\$::BR IF NOT
056650	017746	122306			MOV	@\$TKB, -(SP)	::GET CHAR
056654	042716	177600			BIC	#177600, (SP)	::STRIP EXTRANEIOUS BITS
056660	122716	000023			CMPB	#\$XOFF, (SP)	::WAS CHAR XOFF
056664	001012				BNE	102\$::BR IF NOT
056666				101\$:			
056666	105777	122266			TSTB	@\$TKS	::WAIT FOR CHAR
056672	100375				BPL	101\$	
056674	117716	122262			MOVB	@\$TKB, (SP)	::GET CHAR
056700	042716	177600			BIC	#177600, (SP)	::STRIP IT
056704	122716	000021			CMPB	#\$XON, (SP)	::WAS IT XON?
056710	001366				BNE	101\$::BR IF NOT
056712				102\$:			
056712	005726				TST	(SP)+	::FIX STACK
056714				10\$:			
056714	105777	122244			TSTB	@\$TPS	::WAIT UNTIL PRINTER IS READY
056720	100375				BPL	10\$	
056722	116677	000002	122236		MOVB	2(SP), @\$TPB	::LOAD CHAR TO BE TYPED INTO DATA REG.
056730	122766	000015	000002		CMPB	#CR, 2(SP)	::IS CHARACTER A CARRIAGE RETURN?
056736	001003				BNE	1\$::BRANCH IF NO
056740	105037	056760			CLRB	\$CHARCNT	::YES--CLEAR CHARACTER COUNT
056744	000406				BR	\$TYPEX	::EXIT
056746	122766	000012	000002	1\$:	CMPB	#LF, 2(SP)	::IS CHARACTER A LINE FEED?
056754	001402				BEQ	\$TYPEX	::BRANCH IF YES
056756	105227				INCB	(PC)+	::COUNT THE CHARACTER
056760	000000			\$CHARCNT:	.WORD	0	::CHARACTER COUNT STORAGE
056762	000207			\$TYPEX:	RTS	PC	

.SBTTL SCOPE HANDLER ROUTINE

```

*****
*THIS ROUTINE CONTROLS THE LOOPING OF SUBTESTS. IT WILL INCREMENT
*AND LOAD THE TEST NUMBER($TSTNM) INTO THE DISPLAY REG.(DISPLAY<7:0>)
*AND LOAD THE ERROR FLAG ($ERFLG) INTO DISPLAY<15:08>
*THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
*SW14=1      LOOP ON TEST
*SW11=1      INHIBIT ITERATIONS
*SW09=1      LOOP ON ERROR
*SW08=1      LOOP ON TEST IN SWR<7:0>
*CALL
*          SCOPE          ;;SCOPE=IOT
    
```

```

056764          $SCOPE:
056766          CKSWR          ;;TEST FOR CHANGE IN SOFT-SWR
056772          JSR          PC_STOP
057000          1$:          BIT          #BIT14,@SWR          ;;LOOP ON PRESENT TEST?
057002          BEQ          9$          ;;NO IF SW14=0
057006          JMP          $OVER          ;;JUMP OVER SCOPE ROUTINE
057006          9$:
          ;;#####START OF CODE FOR THE XOR TESTER#####
          $XTSTR: BR          6$          ;;IF RUNNING ON THE 'XOR' TESTER CHANGE
          ;;THIS INSTRUCTION TO A 'NOP' (NOP=240)
          MOV          @#ERRVEC,-(SP)          ;;SAVE THE CONTENTS OF THE ERROR VECTOR
          MOV          #5$,@#ERRVEC          ;;SET FOR TIMEOUT
          TST          @#177060          ;;TIME OUT ON XOR?
          MOV          (SP)+,@#ERRVEC          ;;RESTORE THE ERROR VECTOR
          BR          $$VLAD          ;;GO TO THE NEXT TEST
          5$:          CMP          (SP)+,(SP)+          ;;CLEAR THE STACK AFTER A TIME OUT
          MOV          (SP)+,@#ERRVEC          ;;RESTORE THE ERROR VECTOR
          BR          7$          ;;LOOP ON THE PRESENT TEST
          6$:          ;;#####END OF CODE FOR THE XOR TESTER#####
          BIT          #BIT08,@SWR          ;;LOOP ON SPEC. TEST?
          BEQ          2$          ;;BR IF NO
          CLR          -(SP)          ;;CLEAR A TEMP. LOCATION
          MOVB          @SWR,(SP)          ;;PICKUP THE DESIRED TEST NUMBER
          BEQ          8$          ;;BRANCH IF BAD TEST NUMBER IN SWR
          CMP          #31,(SP)          ;;CHECK THE NUMBER IN THE SWR
          BLT          8$          ;;BRANCH IF TEST NUMBER IS OUT OF RANGE
          MOV          (SP),$TSTNM          ;;UPDATE THE TEST NUMBER
          DEC          (SP)          ;;BACKUP BY ONE
          ASL          (SP)          ;;SCALE THE TEST NUMBER AS AN INDEX
          ADD          #$$SW08TBL,(SP)          ;;FORM THE ADDRESS OF TEST POINTER
          MOV          @(SP)+,$LPADR          ;;SET LOOP ADDRESS TO DESIRED TEST
          BR          $OVER          ;;GO LOOP ON THE TEST
          8$:          TST          (SP)+          ;;CLEAN THE BAD TEST NUMBER OFF OF THE STACK
          2$:          TSTB          $ERFLG          ;;HAS AN ERROR OCCURRED?
          BEQ          3$          ;;BR IF NO
          CMP          #-1,CPSAVE          ;;SEE IF TIMEOUT WAS PREVIOUSLY RECORDED
          BEQ          2003$          ;;KICK AROUND ROUTINE IF SO
          MOV          ERRVEC,-(SP)          ;;SAVE CONTENTS OF ERROR VECTOR
          MOV          #2000$,ERRVEC          ;;SETUP 'TRAP' RETURN ADDRESS
          MOV          177766,CPSAVE          ;;MOVE CPU ERROR REGISTER TO CPSAVE FOR TEST
          BR          2001$
          2000$:          MOV          #-1,CPSAVE          ;;SET CPU ERROR REGISTER TIMEOUT INDICATOR
          MOV          #2001$,(SP)          ;;SETUP RETURN ADDRESS
    
```

```

057170 000002 RTI
057172 012637 000004 2001$: MOV (SP)+,ERRVEC ::RESTORE CONTENTS OF ERROR VECTOR

057176 022737 177777 060150 2002$: CMP #-1,CPSAVE ::SEE IF CPSAVE HAS CPU ERR REG TIMEOUT INDICATION
057204 001430 BEQ 2003$ ::BRANCH IF SO
057206 032737 000001 060150 BIT #BIT00,CPSAVE ::SEE IF THE POWER MONITOR BIT IS ON
057214 001424 BEQ 2003$ ::BRANCH TO CONTINUE ROUTINE IF CLEAR
057216 042737 000001 177766 BIC #BIT00,177766 ::CLEAR THE BIT FOUND TO BE SET
057224 013746 001154 MOV SWR,-(SP) ::SAVE SWR ADDRESS
057230 017646 000000 MOV @ (SP),-(SP) ::SAVE SWR VALUE
057234 012737 000176 001154 MOV #176,SWR ::GET SOFTWARE SWR ADDRESS
057242 011677 121706 MOV (SP),@SWR ::GET CURRENT SWR VALUE
057246 042777 001000 121700 BIC #BIT09,@SWR ::DON'T ALLOW LOOP ON ERROR ON THIS ERROR
057254 104177 EMT 177 ::CALL SPECIAL POWER FAIL BIT ERROR CALL
057256 012676 000000 MOV (SP)+,@(SP) ::RESTORE SWR TO ORIGINAL VALUE
057262 012637 001154 MOV (SP)+,SWR ::RESTORE SWR ADDRESS
057266 2003$:
057266 123737 001131 001117 CMPB $ERMAX,$ERFLG ::MAX. ERRORS FOR THIS TEST OCCURRED?
057274 101015 BHI 3$ ::BR IF NO
057276 032777 001000 121650 BIT #BIT09,@SWR ::LOOP ON ERROR?
057304 001404 BEQ 4$ ::BR IF NO
057306 013737 001124 001122 7$: MOV $LPERR,$LPADR ::SET LOOP ADDRESS TO LAST SCOPE
057314 000446 BR $OVER
057316 105037 001117 4$: CLR $ERFLG ::ZERO THE ERROR FLAG
057322 005037 001206 CLR $TIMES ::CLEAR THE NUMBER OF ITERATIONS TO MAKE
057326 000415 BR 1$ ::ESCAPE TO THE NEXT TEST
057330 032777 004000 121616 3$: BIT #BIT11,@SWR ::INHIBIT ITERATIONS?
057336 001011 BNE 1$ ::BR IF YES
057340 005737 001230 TST $PASS ::IF FIRST PASS OF PROGRAM
057344 001406 BEQ 1$ :: INHIBIT ITERATIONS
057346 005237 001120 INC $ICNT ::INCREMENT ITERATION COUNT
057352 023737 001206 001120 CMP $TIMES,$ICNT ::CHECK THE NUMBER OF ITERATIONS MADE
057360 002024 BGE $OVER ::BR IF MORE ITERATION REQUIRED
057362 012737 000001 001120 1$: MOV #1,$ICNT ::REINITIALIZE THE ITERATION COUNTER
057370 013737 057446 001206 MOV $MXCNT,$TIMES ::SET NUMBER OF ITERATIONS TO DO
057376 105237 001116 $SVLAD: INCB $TSTNM ::COUNT TEST NUMBERS
057402 113737 001116 001226 MOV $TSTNM,$TESTN ::SET TEST NUMBER IN APT MAILBOX
057410 011637 001122 MOV (SP),$LPADR ::SAVE SCOPE LOOP ADDRESS
057414 011637 001124 MOV (SP),$LPERR ::SAVE ERROR LOOP ADDRESS
057420 005037 001210 CLR $ESCAPE ::CLEAR THE ESCAPE FROM ERROR ADDRESS
057424 112737 000001 001131 MOV $ERMAX ::ONLY ALLOW ONE(1) ERROR ON NEXT TEST
057432 013777 001116 121516 $OVER: MOV $TSTNM,@DISPLAY ::DISPLAY TEST NUMBER
057440 013716 001122 MOV $LPADR,(SP) ::FUDGE RETURN ADDRESS
057444 000002 RTI ::FIXES PS
057446 000005 $MXCNT: 5. ::MAX. NUMBER OF ITERATIONS
057450 $SWO8TBL:
.REPT $TN-1
057450 010070 .WORD TST1+2 ::STARTING ADDRESS OF TEST 1
057452 010270 .WORD TST2+2 ::STARTING ADDRESS OF TEST 2
057454 011132 .WORD TST3+2 ::STARTING ADDRESS OF TEST 3
057456 011766 .WORD TST4+2 ::STARTING ADDRESS OF TEST 4
057460 012556 .WORD TST5+2 ::STARTING ADDRESS OF TEST 5
057462 013516 .WORD TST6+2 ::STARTING ADDRESS OF TEST 6
057464 014336 .WORD TST7+2 ::STARTING ADDRESS OF TEST 7
057466 015126 .WORD TST10+2 ::STARTING ADDRESS OF TEST 10
057470 016064 .WORD TST11+2 ::STARTING ADDRESS OF TEST 11
057472 016660 .WORD TST12+2 ::STARTING ADDRESS OF TEST 12

```


	057474	017472		.WORD	TST13+2	::STARTING ADDRESS OF TEST 13
	057476	020304		.WORD	TST14+2	::STARTING ADDRESS OF TEST 14
	057500	021126		.WORD	TST15+2	::STARTING ADDRESS OF TEST 15
	057502	021670		.WORD	TST16+2	::STARTING ADDRESS OF TEST 16
	057504	022432		.WORD	TST17+2	::STARTING ADDRESS OF TEST 17
	057506	023174		.WORD	TST20+2	::STARTING ADDRESS OF TEST 20
	057510	023500		.WORD	TST21+2	::STARTING ADDRESS OF TEST 21
	057512	024004		.WORD	TST22+2	::STARTING ADDRESS OF TEST 22
	057514	024346		.WORD	TST23+2	::STARTING ADDRESS OF TEST 23
	057516	024670		.WORD	TST24+2	::STARTING ADDRESS OF TEST 24
	057520	025206		.WORD	TST25+2	::STARTING ADDRESS OF TEST 25
	057522	026120		.WORD	TST26+2	::STARTING ADDRESS OF TEST 26
	057524	026742		.WORD	TST27+2	::STARTING ADDRESS OF TEST 27
	057526	027524		.WORD	TST30+2	::STARTING ADDRESS OF TEST 30
	057530	030674		.WORD	TST31+2	::STARTING ADDRESS OF TEST 31
2						
3						
4						
5	057532					
	057532	012746	000140	MOV	#PR3,-(SP)	::PUT NEW PS ON STACK
	057536	012746	057544	MOV	#64\$,-(SP)	::PUT NEW PC ON STACK
	057542	000002		RTI		::POP NEW PC AND PS
	057544					
6						
7						
8						
9	057544	012746	000240	MOV	#PR5,-(SP)	::PUT NEW PS ON STACK
	057550	012746	057556	MOV	#65\$,-(SP)	::PUT NEW PC ON STACK
	057554	000002		RTI		::POP NEW PC AND PS
	057556					
10	057556	000207		RTS	PC	::RETURN

;DROP PRIORITY TO ALLOW CONSOLE INTERRUPT

STOP:

64\$:

;RAISE PRIORITY TO INHIBIT CONSOLE INTERRUPT

65\$:

1

.SBTTL ERROR HANDLER ROUTINE

```

*****
*THIS ROUTINE WILL INCREMENT THE ERROR FLAG AND THE ERROR COUNT,
*SAVE THE ERROR ITEM NUMBER AND THE ADDRESS OF THE ERROR CALL
*AND GO TO,ERRTYP ON ERROR
*THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
*SW15=1 HALT ON ERROR
*SW13=1 INHIBIT ERROR TYPEOUTS
*SW10=1 BELL ON ERROR
*SW09=1 LOOP ON ERROR
*CALL
*

```

```

*      ERROR      N      ;;ERROR=EMT AND N=ERROR ITEM NUMBER
057560 105037 060152 $ERROR: CLR      IBSAVE      ;;CLEAR THE ITEM BYTE SAVE LOCATION
057564 104410          CKSWR          ;;TEST FOR CHANGE IN SOFT-SWR
057566 105237 001117 7$:      INCB      $ERFLG      ;;SET THE ERROR FLAG
057572 001775          BEQ      7$          ;;DON'T LET THE FLAG GO TO ZERO
057574 013777 001116 121354 MOV      $TSTNM,@DISPLAY ;;DISPLAY TEST NUMBER AND ERROR FLAG
057602 032777 002000 121344 BIT      #BIT10,@SWR      ;;BELL ON ERROR?
057610 001402          BEQ      1$          ;;NO - SKIP
057612 104401 001212          TYPE      ,SBELL      ;;RING BELL
057616 005237 001126 1$:      INC      $ERTTL      ;;COUNT THE NUMBER OF ERRORS
057622 011637 001132          MOV      (SP), $ERRPC      ;;GET ADDRESS OF ERROR INSTRUCTION
057626 162737 000002 001132 SUB      #2,$ERRPC
057634 117737 121272 001130 MOVB    @ $ERRPC,$ITEMB    ;;STRIP AND SAVE THE ERROR ITEM CODE
057642 032777 001000 121304 BIT      #BIT09,@SWR      ;;SEE IF LOOP ON ERROR IS SET
057650 001060          BNE      1004$      ;;BRANCH AROUND ROUTINE IF SO
057652 122737 000177 001130 CMPB    #177,$ITEMB      ;;SEE IF THIS IS THE POWER FAIL CALL
057660 001454          BEQ      1004$      ;;BRANCH AROUND ROUTINE IF IT IS
057662 105737 060152          TSTB    IBSAVE      ;;SEE IF THIS IS THE 2ND ERROR CALL IN THIS ROUTINE
057666 001047          BNE      1003$      ;;BRANCH IF SO
057670 022737 177777 060150 CMP      #-1,CPSAVE      ;;SEE IF CPSAVE HAS CPU ERR REG TIMEOUT INDICATION
057676 001445          BEQ      1004$      ;;BRANCH IF SO
057700 013746 000004          MOV      ERRVEC,-(SP)      ;;SAVE CONTENTS OF ERROR VECTOR
057704 012737 057722 000004 MOV      #1000$,ERRVEC    ;;SETUP 'TRAP' RETURN ADDRESS
057712 013737 177766 060150 MOV      177766,CPSAVE    ;;MOVE CPU ERROR REGISTER TO CPSAVE FOR TEST
057720 000406          BR      1001$
057722 012737 177777 060150 1000$: MOV      #-1,CPSAVE      ;;SET CPU ERROR REGISTER TIMEOUT INDICATOR
057730 012716 057736          MOV      #1001$, (SP)      ;;SETUP RETURN ADDRESS
057734 000002          RTI
057736 012637 000004          1001$: MOV      (SP)+,ERRVEC      ;;RESTORE CONTENTS OF ERROR VECTOR

057742 022737 177777 060150 1002$: CMP      #-1,CPSAVE      ;;SEE IF CPSAVE HAS CPU ERR REG TIMEOUT INDICATION
057750 001420          BEQ      1004$      ;;BRANCH IF SO
057752 032737 000001 060150 BIT      #BIT00,CPSAVE    ;;SEE IF POWER MONITOR BIT IS SET IN CPU ERR REG
057760 001414          BEQ      1004$      ;;BRANCH IF OK
057762 042737 000001 177766 BIC      #BIT00,177766    ;;CLEAR THE BIT FOUND SET
057770 113737 001130 060152 MOVB    $ITEMB,IBSAVE      ;;MAKE IBSAVE NON-ZERO FOR DUAL ERROR CALL
057776 112737 000177 001130 MOVB    #177,$ITEMB      ;;SET $ITEMB TO SPECIAL POWER FAIL POINTER
060004 000402          BR      1004$      ;;BRANCH OVER IBSAVE CLEARING

060006 105037 060152          1003$: CLR      IBSAVE      ;;CLEAR IBSAVE SO 2ND TIME THROUGH EXITS
060012          1004$:
060012 032777 020000 121134 BIT      #BIT13,@SWR      ;;SKIP TYPEOUT IF SET
060020 001004          BNE      20$          ;;SKIP TYPEOUTS
060022 004737 060154          JSR      PC,ERRTYP      ;;GO TO USER ERROR ROUTINE

```



```

ERROR HANDLER ROUTINE
060026 104401 001217          TYPE      , $CRLF
060032          20$:
060032 122737 000001 001242  CMPB      #APTENV, $ENV      ;;RUNNING IN APT MODE
060040 001007          BNE          2$          ;;NO, SKIP APT ERROR REPORT
060042 113737 001130 060054  MOVB      $ITEMB, 21$      ;;SET ITEM NUMBER AS ERROR NUMBER
060050 004737 063116          JSR          PC, $ATY4      ;;REPORT FATAL ERROR TO APT
060054          21$:
060055          .BYTE      0
060056          .BYTE      0
060060 000777          22$:
060060 105737 060152          BR          22$          ;;APT ERROR LOOP
060064 001005          2$:
060064 005777 121062          TSTB     IBSAVE          ;;SEE IF IBSAVE IS LOADED
060072 100002          BNE          3$          ;;BRANCH IF NOT - NO HALT ON PWR MON BIT ERROR
060074 000000          TST          @SWR          ;;HALT ON ERROR
060076 104410          BPL          3$          ;;SKIP IF CONTINUE
060100          HALT          ;;HALT ON ERROR!
060100          CKSWR          ;;TEST FOR CHANGE IN SOFT-SWR
060100 032777 001000 121046  3$:
060106 001402          BIT          #BIT09, @SWR      ;;LOOP ON ERROR SWITCH SET?
060110 013716 001124          BEQ          4$          ;;BR IF NO
060114 005737 001210          MOV          $LPERR, (SP)    ;;FUDGE RETURN FOR LOOPING
060120 001402          4$:
060122 013716 001210          TST          $ESCAPE        ;;CHECK FOR AN ESCAPE ADDRESS
060126          BEQ          5$          ;;BR IF NONE
060126 022737 032122 000042  5$:
060134 001001          MOV          $ESCAPE, (SP)  ;;FUDGE RETURN ADDRESS FOR ESCAPE
060136 000000          CMP          # $ENDAD, @#42 ;;ACT-11 AUTO-ACCEPT?
060140          BNE          6$          ;;BRANCH IF NO
060140          HALT          ;;YES
060140          6$:
060140 105737 060152          TSTB     IBSAVE          ;;SEE IF ITEM BYTE SAVE LOCATION HAS AN ERROR CALL
060144 001210          BNE          7$          ;;BRANCH BACK TO CALL ORIGINAL ERROR
060146 000002          RTI          ;;RETURN
060150 000000          CPSAVE: .WORD      0      ;;LOCATION TO SAVE CPU ERROR REG CONTENTS
060152 000000          IBSAVE: .WORD     0      ;;LOCATION TO SAVE ITEM BYTE
    
```

.SBTTL ERROR TYPEOUT ROUTINE

;*THE ERROR TYPEOUT ROUTINE ASSEMBLES AND PRINTS INFORMATION
 :*REGARDING THE DETECTION OF AN ERROR AS FOLLOWS:

;* .UNIT NUMBER, DRIVE TYPE, TEST NUMBER, ERROR NUMBER AND
 :*PROGRAM COUNTER ARE PRINTED ON THE FIRST LINE;
 :* .ERROR MESSAGE IS ASSEMBLED, FORMATTED AND PRINTED ON
 :*ONE OR MORE SUCCEEDING LINES;
 :* .PAIRED LINES OF ERROR HEADERS AND ERROR DATA ARE PRINTED
 :*AFTER THE ERROR MESSAGE.

2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49

```

060154 104414
060156 032777 020000 120770
060164 001402
060166 000137 061014

060172 104401 0C1217
060176 104401 061030
060202 013746 001234

060206 104403
060210 003
060211 000

060212 013700 001276
060216 016000 000026
060222 042700 177740
060226 012737 064373 060300
060234 022700 000024
060240 001414

060242 012737 064366 060300
060250 022700 000025
060254 001406

060256 012737 064400 060300
060264 022700 000027
060270 001004
060272 104401 061065
060276 104401
060300 000000

060302 005037 061020
060306 013737 001226 061020
060314 104401 061035
060320 013746 061020

060324 104403
060326 003
060327 000

060330 005037 061022
060334 113737 001130 061022
  
```

```

ERRRYP: SAVREG
BIT #SW13,@SWR ;INHIBIT TYPEOUTS??
BEQ 1$ ;NO!!
JMP 27$ ;YES!!

;TYPE UNIT NUMBER, DRIVE TYPE, TEST NUMBER, ERROR NUMBER, AND
;PROGRAM COUNTER
1$: TYPE ,SCLRF
TYPE ,ERTY00 ;TYPE 'DRV#'
MOV $UNIT,-(SP) ;;SAVE $UNIT FOR TYPEOUT
;;TYPE DRIVE NUMBER
TYPOS ;;GO TYPE--OCTAL ASCII
.BYTE 3 ;;TYPE 3 DIGIT(S)
.BYTE 0 ;;SUPPRESS LEADING ZEROS

;TYPE 'DRIVE TYPE' RM05, RM03 OR RM02 FOR UNIT UNDER TEST
MOV $BASE,R0 ;GET RM BASE ADDRESS
MOV RMDT(R0),R0 ;GET DRIVE TYPE REGISTER
BIC #177740,R0 ;SAVE DRIVE TYPE BITS AND
MOV #SRM03,3$ ;GET ASCII DRIVE TYPE
CMP #24,R0 ;IS DEVICE AN RM03 ?
BEQ 2$ ;YES !!

MOV #SRM02,3$ ;SAVE ASCII DRIVE TYPE
CMP #25,R0 ;IS DEVICE AN RM02 ?
BEQ 2$ ;YES !!

MOV #SRM05,3$ ;SAVE ASCII DRIVE TYPE
CMP #27,R0 ;IS DEVICE AN RM05 ?
BNE 4$ ;NO !!
2$: TYPE ,ERTY05 ;TYPE " - "
TYPE ;TYPE DRIVE TYPE
3$: .WORD 0 ;DRIVE TYPE MESSAGE IS STORED HERE

;TYPE TEST NUMBER, ERROR NUMBER AND PROGRAM COUNTER
4$: CLR TSTNMB ;LOAD TEST NUMBER FOR
MOV $TESTN,TSTNMB
TYPE ,ERTY01 ;TYPE 'TST#'
MOV TSTNMB,-(SP) ;;SAVE TSTNMB FOR TYPEOUT
;;TYPE TEST NUMBER
TYPOS ;;GO TYPE--OCTAL ASCII
.BYTE 3 ;;TYPE 3 DIGIT(S)
.BYTE 0 ;;SUPPRESS LEADING ZEROS
CLR ERRNMB ;LOAD ERROR NUMBER FOR
MOVB $ITEMB,ERRNMB ;TYPEOUT
  
```



```

50 060342 001406
51 060344 104401 061045
52 060350 013746 061022
    060354 104403
    060356 003
    060357 000
53 060360 104401 061054
54 060364 013746 001132
    060370 104403
    060372 006
    060373 001
55
56
57 060374 005737 061022
58 060400 001002
59 060402 000137 061014
60
61 060406 104401 061217
62 060412 105037 061026
63 060416 105037 061027
64 060422 013700 061022
65 060426 122700 000177
66 060432 001003
67 060434 012700 061072
68 060440 000405
69 060442 006300
70 060444 006300
71 060446 006300
72 060450 062700 001572
73 060454 011001
74
75 060456 001507
76
77
78 060460 012102
79 060462 001505
80 060464 010237 060632
81 060470 005037 061024
82 060474 112203
83 060476 001454
84 060500 122703 000015
85 060504 001003
86 060506 105037 061027
87 060512 000770
88 060514 122703 000012
89 060520 001765
90 060522 122703 000011
91 060526 001007
92 060530 105237 061027
93 060534 132737 000007 061027
94 060542 001372
95 060544 000407
96 060546 105237 061027
97 060552 122703 000040
98 060556 001002

```

```

    BEQ 5$ ;SKIP IF NO ERROR CALLED
    TYPE ,ERTY02 ;TYPE 'ERR#'
    MOV ERRNMB,-(SP) ;SAVE ERRNMB FOR TYPEOUT
    ;TYPE ERROR NUMBER
    TYPOS ;GO TYPE--OCTAL ASCII
    .BYTE 3 ;TYPE 3 DIGIT(S)
    .BYTE 0 ;SUPPRESS LEADING ZEROS
    TYPE ,ERTY03 ;TYPE 'PC='
    MOV $ERRPC,-(SP) ;SAVE $ERRPC FOR TYPEOUT
    ;TYPE PROGRAM COUNTER
    TYPOS ;GO TYPE--OCTAL ASCII
    .BYTE 6 ;TYPE 6 DIGIT(S)
    .BYTE 1 ;TYPE LEADING ZEROS

6$: ;GENERATE POINTER TO ERROR TABLE UNLESS ERROR NUMBER IS 0
    TST ERRNMB ;WAS AN ERROR CALLED?
    BNE 7$ ;BR IF YES
    JMP 27$ ;NO--EXIT

7$: TYPE , $CRLF ;YES--TYPE CRLF
    CLRB BOTFLG ;CLEAR BOT FLAG
    CLRB CHRCNT ;CLEAR CHARACTER COUNTER
    MOV ERRNMB,R0 ;R0 POINTS TO FIRST OF
    CMPB #177,R0 ;SEE IF THIS ERROR CALL IS SPECIAL POWER FAIL CALL
    BNE 8$ ;BRANCH IF NOT
    MOV #PFECH,R0 ;MOVE POWER FAIL ERROR CALL TABLE TO R0
    BR 9$

8$: ASL R0 ;FOUR ENTRIES IN ERROR
    ASL R0 ;TABLE
    ASL R0

9$: ADD #$ERRTB-8.,R0 ;R1 POINTS TO ERROR MESSAGE
    MOV (R0),R1 ;TABLE
    BEQ 19$ ;BRANCH IF NO ERROR MESSAGE

10$: ;TYPE THE ERROR MESSAGE
    MOV (R1)+,R2 ;R2=ADDRESS OF MESSAGE STRING
    BEQ 19$ ;BRANCH IF END OF MESSAGE
    MOV R2,18$ ;LOAD ADDRESS OF STRING
    CLR BOTADR ;CLEAR BOT ADDRESS
    MOVB (R2)+,R3 ;END OF STRING??
    BEQ 17$ ;YES!!
    CMPB #CR,R3 ;CARRIAGE RETURN??
    BNE 12$ ;NO!!
    CLRB CHRCNT ;YES--CLEAR CHAR COUNT
    BR 11$ ;GET NEXT CHARACTER
    CMPB #LF,R3 ;LINE FEED??
    BEQ 11$ ;YES--GET NEXT CHARACTER
    CMPB #HT,R3 ;HORIZONTAL TAB??
    BNE 14$ ;NO!!
    INCB CHRCNT ;ADJUST CHARACTER COUNT
    BITB #7,CHRCNT
    BNE 13$
    BR 15$

11$:
12$:
13$:
14$: INCB CHRCNT ;INCREMENT CHARACTER COUNT
    CMPB #' ,R3 ;SPACE??
    BNE 15$ ;NO!!

```

```

99 060560 010237 061024      MOV      R2,BOTADR      ;SAVE ADDRESS OF SPACE
100 060564 122737 000100 061027 15$:  CMPB    #64.,CHRCNT    ;END OF LINE??
101 060572 103340          BHIS    11$            ;NO!!
102 060574 013704 061024      MOV      BOTADR,R4     ;GET ADDRESS OF LAST SPACE
103 060600 001007          BNE     16$            ;BRANCH IF SPACE DETECTED
104 060602 104401 001217      TYPE    , $CRLF        ;TYPE CRLF
105 060606 105037 061027      CLRB    CHRCNT         ;CLEAR CHARACTER COUNT
106 060612 013702 060632      MOV      18$,R2        ;SET UP R2 FOR TESTING
107 060616 000726          BR      11$
108 060620 105044          CLRB    -(R4)          ;REPLACE SPACE
109 060622 112737 177777 061026 16$:  MOVB    #-1,BOTFLG     ;SET BOT FLAG
110 060630 104401          TYPE    , $CRLF        ;TYPE ERROR MESSAGE STRING
111 060632 000000          18$:  .WORD    ;STRING ADDRESS GOES HERE
112 060634 105737 061026      TSTB    BOTFLG         ;WAS STRING TRUNCATED??
113 060640 001707          BEQ     10$            ;NO!!
114 060642 104401 001217      TYPE    , $CRLF        ;YES-TYPE CRLF
115 060646 105037 061026      CLRB    BOTFLG         ;CLEAR BOT FLAG
116 060652 105037 061027      CLRB    CHRCNT         ;CLEAR CHARACTER COUNT
117 060656 013702 061024      MOV      BOTADR,R2     ;SETUP R2 FOR TESTING
118 060662 010237 060632      MOV      R2,18$        ;SETUP 18$ FOR TYPING
119 060666 112742 000040      MOVB    #' ,-(R2)     ;RESTORE SPACE
120 060672 105722          TSTB    (R2)+          ;RESTORE R2
121 060674 000677          BR      11$            ;TYPE REST OF STRING
122
123          ;TYPE ERROR HEADER AND ERROR DATA
124 060676 016001 000002 19$:  MOV      2(R0),R1      ;R1 POINTS TO ERROR HEADER TABLE
125 060702 001444          BEQ     27$            ;BRANCH IF NO HEADER
126 060704 104401 001217      TYPE    , $CRLF        ;(ASSUME NO DATA)
127 060710 016002 000004      MOV      4(R0),R2      ;R2 POINTS TO DATA ADDRESS TABLE
128 060714 016003 000006      MOV      6(R0),R3      ;R3 POINTS TO FORMAT TABLE
129 060720 012137 060730 20$:  MOV      (R1)+,21$     ;PUT HEADER ADDRESS FOR TYPE
130 060724 001433          BEQ     27$            ;BRANCH IF END OF HEADERS
131          ;(ASSUME END OF DATA)
132 060726 104401          TYPE    , $CRLF        ;HEADER ADDRESS GOES HERE
133 060730 000000 21$:  .WORD    0
134 060732 104401 001217      TYPE    , $CRLF
135 060736 005702          TST     R2             ;DATA WITH HEADER??
136 060740 001767          BEQ     20$            ;NO!!
137 060742 012204          MOV     (R2)+,R4       ;R4 POINTS TO DATA ADDRESS
138 060744 012305          MOV     (R3)+,R5       ;R5 POINTS TO FORMAT
139 060746 105725 22$:  TSTB    (R5)+          ;WHAT KIND OF DATA??
140 060750 100407          BMI     24$            ;BINARY
141 060752 001403          BEQ     23$            ;OCTAL
142 060754 013446          MOV     @(R4)+,-(SP)   ;DECIMAL
143 060756 104405          TYPDS
144 060760 000405          BR      25$
145 060762 013446 23$:  MOV     @(R4)+,-(SP)
146 060764 104402          TYPOC
147 060766 000402          BR      25$
148 060770 013446 24$:  MOV     @(R4)+,-(SP)
149 060772 104406          TYPBN
150 060774 005714 25$:  TST     (R4)           ;MORE DATA??
151 060776 001403          BEQ     26$            ;NO!!
152 061000 104401 061062      TYPE    ,ERTY04        ;YES-TYPE 2 SPACES
153 061004 000760          BR      22$            ;AND CONTINUE
154 061006 104401 001217 26$:  TYPE    , $CRLF        ;TYPE ONE BLANK LINE
155 061012 000742          BR      20$            ;BEFORE NEXT HEADER

```


156	061014	104415			27\$:	RESREG				
157	061016	000207				RTS	PC			
158										
159	061020	000000			TSTNMB:	.WORD	0		:	TEST NUMBER
160	061022	000000			ERRNMB:	.WORD	0		:	ERROR NUMBER
161	061024	000000			BOTADR:	.WORD	0		:	BEGINNING OF TEXT ADDRESS
162	061026	000			BOTFLG:	.BYTE	0		:	BOT FLAG
163	061027	000			CHRCNT:	.BYTE	0		:	CHARACTER COUNT
164										
165	061030	104	122	126	ERTY00:	.ASCIZ	@DRV#@			
166	061035	054	040	124	ERTY01:	.ASCIZ	@, TEST#@			
167	061045	054	040	105	ERTY02:	.ASCIZ	@, ERR#@			
168	061054	054	040	120	ERTY03:	.ASCIZ	@, PC=@			
169	061062	040	040	000	ERTY04:	.ASCIZ	@ @			
170	061065	040	055	040	ERTY05:	.ASCIZ	@ - @			
171					.EVEN					
172	061072	061102	061170	061206	PFECH:	PFECH1,PFECH2,PFECH3,PFECH4			:	WORDS DEFINING TABLES BELOW
173	061102	061106	000000		PFECH1:	+.4,0				
174	061106	120	117	127		.ASCIZ	?POWER MONITOR BIT IN CPU ERROR REGISTER FOUND SET?			
175					.EVEN					
176	061170	061174	000000		PFECH2:	+.4,0				
177	061174	103	120	125		.ASCIZ	?CPUERREG?			
178					.EVEN					
179	061206	061210			PFECH3:	+.2				
180	061210	060150	000000			.WORD	CPSAVE,0			
181	061214	061216			PFECH4:	+.2				
182	061216	000	000			.BYTE	0,0			

1

.SBTTL TTY INPUT ROUTINE

```

*****
ENABL  LSB
061220 000000 $TKCNT: .WORD 0           ;;NUMBER OF ITEMS IN QUEUE
061222 000000 $TKQIN: .WORD 0           ;;INPUT POINTER
061224 000000 $TKQOUT: .WORD 0          ;;OUTPUT POINTER
061226 061227 $TKQSRT: .BLKB 1          ;;TTY KEYBOARD QUEUE
$TKQEND=.
.EVEN

;*TK INITIALIZE ROUTINE
;*THIS ROUTINE WILL INITIALIZE THE TTY KEYBOARD INPUT QUEUE
;*SETUP THE INTERRUPT VECTOR AND TURN ON THE KEYBOARD INTERRUPT
:
;*CALL:
:
;*      JSR      PC,$TKINT
:
;*      RETURN
:
061230 005037 061220 $TKINT: CLR      $TKCNT           ;;CLEAR COUNT OF ITEMS IN QUEUE
061234 012737 061226 061222 MOV      #$TKQSRT,$TKQIN      ;;MOVE THE STARTING ADDRESS OF THE
061242 013737 061222 061224 MOV      $TKQIN,$TKQOUT      ;;QUEUE INTO THE INPUT & OUTPUT POINTERS.
061250 012737 061300 000060 MOV      #$TKSRV,@#TKVEC    ;;INITIALIZE THE KEYBOARD VECTOR
061256 012737 000200 000062 MOV      #200,@#TKVEC+2    ;;'BR' LEVEL 4
061264 005777 117672 TST      @#TKB              ;;CLEAR DONE FLAG
061270 012777 000100 117662 MOV      #100,@#TKS        ;;ENABLE TTY KEYBOARD INTERRUPT
061276 000207 RTS      PC              ;;RETURN TO CALLER

;*TK SERVICE ROUTINE
;*THIS ROUTINE WILL SERVICE THE TTY KEYBOARD INTERRUPT
;*BY READING THE CHARACTER FROM THE INPUT BUFFER AND PUTTING
;*IT IN THE QUEUE.
;*IF THE CHARACTER IS A 'CONTROL-C' (^C) $TKINT IS CALLED AND
;*UPON RETURN EXIT IS MADE TO THE 'CONTROL-C' RESTART ADDRESS (SHUT2)
:
$TKSRV: MOVB     @#TKB,-(SP)      ;;PICKUP THE CHARACTER
BIC      #^C177,(SP)           ;;STRIP THE JUNK
CMP      (SP),#$XON            ;;IS IT A RANDOM XON?
BNE      30$                   ;;BRANCH IF NO
TST      (SP)+                 ;;CLEAN RANDOM XON OFF STACK
RTI
:
30$:
CMP      (SP),#3               ;;IS IT A CONTROL C?
BNE      1$                     ;;BRANCH IF NO
TYPE     ,SCNTLC                ;;TYPE A CONTROL-C (^C)
JSR      PC,$TKINT             ;;INIT THE KEYBOARD
TST      (SP)+                 ;;CLEAN UP STACK
JMP      SHUT2                 ;;CONTROL C RESTART
:
1$:
CMP      (SP),#7               ;;IS IT A CONTROL G?
BNE      2$                     ;;BRANCH IF NO
CMP      #SWREG,SWR            ;;IS SOFT-SWR SELECTED?
BEQ      6$                     ;;GO TO SWR CHANGE
:
2$:
CMP      #1,$TKCNT             ;;IS THE QUEUE FULL?
BNE      3$                     ;;BRANCH IF NO
TYPE     ,$BELL                ;;RING THE TTY BELL
:

```



```

061400 005726          TST      (SP)+          ;;CLEAN CHARACTER OFF OF STACK
061402 000451          BR       5$              ;;EXIT
061404 021627 000023  3$:      CMP      (SP),#23          ;;IS IT A CONTROL-S?
061410 001021          BNE      32$            ;;BRANCH IF NO
061412 005077 117542  CLR      @STKS          ;;DISABLE TTY KEYBOARD INTERRUPTS
061416 005726          TST      (SP)+          ;;CLEAN CHAR OFF STACK
061420 105777 117534  31$:      TSTB     @STKS          ;;WAIT FOR A CHAR
061424 100375          BPL      31$            ;;LOOP UNTIL ITS THERE
061426 117746 117530  MOVB     @STKB,-(SP)      ;;GET THE CHARACTER
061432 042716 177600  BIC      #^C177,(SP)    ;;MAKE IT 7-BIT ASCII
061436 022627 000021  CMP      (SP)+,#21      ;;IS IT A CONTROL-Q?
061442 001366          BNE      31$            ;;BRANCH IF NO
061444 012777 000100 117506  MOV      #100,@STKS     ;;REENABLE TTY KEYBOARD INTERRUPTS
061452 000002          RTI                     ;;RETURN
061454 005237 061220  32$:      INC      $TKCNT        ;;COUNT THIS CHARACTER
061460 021627 000140  CMP      (SP),#140     ;;IS IT UPPER CASE?
061464 002405          BLT      4$              ;;BRANCH IF YES
061466 021627 000175  CMP      (SP),#175     ;;IS IT A SPECIAL CHAR?
061472 003002          BGT      4$              ;;BRANCH IF YES
061474 042716 000040  BIC      #40,(SP)      ;;MAKE IT UPPER CASE
061500 112677 177516  4$:      MOVB     (SP)+,@STKQIN  ;;AND PUT IT IN QUEUE
061504 005237 061222  INC      $TKQIN         ;;UPDATE THE POINTER
061510 023727 061222 061227  CMP      $TKQIN,$$TKQEND ;;GO OFF THE END?
061516 001003          BNE      5$              ;;BRANCH IF NO
061520 012737 061226 061222  MOV      $$TKQRT,$TKQIN ;;RESET THE POINTER
061526 000002          RTI                     ;;RETURN

```

 *SOFTWARE SWITCH REGISTER CHANGE ROUTINE.
 *ROUTINE IS ENTERED FROM THE TRAP HANDLER, AND WILL
 *SERVICE THE TEST FOR CHANGE IN SOFTWARE SWITCH REGISTER TRAP
 *CALL WHEN OPERATING IN TTY INTERRUPT MODE.

```

061530 022737 000176 001154  $CKSWR: CMP      #SWREG,SWR    ;;IS THE SOFT-SWR SELECTED
061536 001124          BNE      15$            ;;EXIT IF NOT
061540 105777 117414  TSTB     @STKS          ;;IS A CHAR WAITING?
061544 100121          BPL      15$            ;;IF NOT, EXIT
061546 117746 117410  MOVB     @STKB,-(SP)    ;;YES
061552 042716 177600  BIC      #^C177,(SP)    ;;MAKE IT 7-BIT ASCII
061556 021627 000007  CMP      (SP),#7        ;;IS IT A CONTROL-G?
061562 001300          BNE      2$              ;;IF NOT, PUT IT IN THE TTY QUEUE
                                ;;AND EXIT

```

 *CONTROL IS PASSED TO THIS POINT FROM EITHER THE TTY INTERRUPT SERVICE
 *ROUTINE OR FROM THE SOFTWARE SWITCH REGISTER TRAP CALL, AS A RESULT OF A
 *CONTROL-G BEING TYPED, AND THE SOFTWARE SWITCH REGISTER BEING SELECTED.

```

061564 123727 001150 000001  6$:      CMPB     $AUTOB,#1      ;;ARE WE RUNNING IN AUTO-MODE?
061572 001674          BEQ      2$              ;;BRANCH IF YES
061574 005726          TST      (SP)+          ;;CLEAR CONTROL-G OFF STACK
061576 004737 061230  JSR      PC,$TKINT      ;;FLUSH THE TTY INPUT QUEUE
061602 005077 117352  CLR      @STKS          ;;DISABLE TTY KEYBOARD INTERRUPTS
061606 112737 000001 001151  MOVB     #1,$INTAG      ;;SET INTERRUPT MODE INDICATOR

061614 104401 062440  $GTSWR: TYPE     ,$CNTLG    ;;ECHO THE CONTROL-G (^G)
061620 104401 062445  TYPE     ,$MSWR        ;;TYPE CURRENT CONTENTS
061624 013746 000176  MOV      SWREG,-(SP)    ;;SAVE SWREG FOR TYPEOUT
061630 104402          TYPOC                ;;GO TYPE--OCTAL ASCII(ALL DIGITS)

```

```

061632 104401 062456          TYPE      , $MNEW          :: PROMPT FOR NEW SWR
061636 005046          CLR      -(SP)          :: CLEAR COUNTER
061640 005046          CLR      -(SP)          :: THE NEW SWR
061642 105777 117312      TSTB     @ $TKS          :: CHAR THERE?
061646 100375          BPL      7$             :: IF NOT TRY AGAIN

061650 117746 117306      MOVB    @ $TKB, -(SP)    :: PICK UP CHAR
061654 042716 177600      BIC     # ^C177, (SP)  :: MAKE IT 7-BIT ASCII

061660 021627 000003      CMP     (SP), #3        :: IS IT A CONTROL-C?
061664 001015          BNE     9$              :: BRANCH IF NOT
061666 104401 062426      TYPE    , $CNTLC       :: YES, ECHO CONTROL-C (^C)
061672 062706 000006      ADD     #6, SP         :: CLEAN UP STACK
061676 123727 001151 000001  CMPB    $INTAG, #1      :: REENABLE TTY KEYBOARD INTERRUPTS?
061704 001003          BNE     8$              :: BRANCH IF NO
061706 012777 000100 117244  MOV     #100, @ $TKS    :: ALLOW TTY KEYBOARD INTERRUPTS
061714 000137 062470      JMP     SHUT2          :: CONTROL-C RESTART

061720 021627 000025      CMP     (SP), #25      :: IS IT A CONTROL-U?
061724 001005          BNE     10$            :: BRANCH IF NOT
061726 104401 062433      TYPE    , $CNTLU       :: YES, ECHO CONTROL-U (^U)
061732 062706 000006      ADD     #6, SP         :: IGNORE PREVIOUS INPUT
061736 000737          BR     19$            :: LET'S TRY IT AGAIN

061740 021627 000015      CMP     (SP), #15     :: IS IT A <CR>?
061744 001022          BNE     16$            :: BRANCH IF NO
061746 005766 000004      TST     4(SP)          :: YES, IS IT THE FIRST CHAR?
061752 001403          BEQ     11$            :: BRANCH IF YES
061754 016677 000002 117172  MOV     2(SP), @ $SWR   :: SAVE NEW SWR
061762 062706 000006      ADD     #6, SP         :: CLEAN UP STACK
061766 104401 001217      TYPE    , $CRLF        :: ECHO <CR> AND <LF>
061772 123727 001151 000001  CMPB    $INTAG, #1      :: RE-ENABLE TTY KBD INTERRUPTS?
062000 001003          BNE     15$            :: BRANCH IF NOT
062002 012777 000100 117150  MOV     #100, @ $TKS    :: RE-ENABLE TTY KBD INTERRUPTS
062010 000002          RTI                    :: RETURN
062012 004737 056642      JSR     PC, $TYPEC     :: ECHO CHAR
062016 021627 000060      CMP     (SP), #60     :: CHAR < 0?
062022 002420          BLT     18$            :: BRANCH IF YES
062024 021627 000067      CMP     (SP), #67     :: CHAR > 7?
062030 003015          BGT     18$            :: BRANCH IF YES
062032 042726 000060      BIC     #60, (SP)+     :: STRIP-OFF ASCII
062036 005766 000002      TST     2(SP)          :: IS THIS THE FIRST CHAR
062042 001403          BEQ     17$            :: BRANCH IF YES
062044 006316          ASL     (SP)           :: NO, SHIFT PRESENT
062046 006316          ASL     (SP)           :: CHAR OVER TO MAKE
062050 006316          ASL     (SP)           :: ROOM FOR NEW ONE.
062052 005266 000002      INC     2(SP)          :: KEEP COUNT OF CHAR
062056 056616 177776      BIS     -2(SP), (SP)   :: SET IN NEW CHAR
062062 000667          BR     7$             :: GET THE NEXT ONE
062064 104401 001216      18$:   TYPE    , $QUES     :: TYPE ?<CR><LF>
062070 000720          BR     20$            :: SIMULATE CONTROL-U
.DSABL  LSB

```

::*****


```

: *THIS ROUTINE WILL INPUT A SINGLE CHARACTER FROM THE TTY
: *CALL:
: *   RDCHR           ;; GET A CHARACTER FROM THE QUEUE
: *   RETURN HERE    ;; CHARACTER IS ON THE STACK
: *                ;; WITH PARITY BIT STRIPPED OFF
:

```

```

062072 011646          $RDCHR: MOV    (SP),-(SP)    ;; PUSH DOWN THE PC AND
062074 016666 000004 000002  MOV    4(SP),2(SP)    ;; THE PS
062102 005066 000004          CLR    4(SP)          ;; GET READY FOR A CHARACTER
062106 005046          CLR    -(SP)          ;; PUT NEW PS ON STACK
062110 012746 062116          MOV    #64$,-(SP)    ;; PUT NEW PC ON STACK
062114 000002          RTI                    ;; POP NEW PC AND PS
062116
062116 005737 061220 64$:   TST    $TKCNT          ;; WAIT ON A CHARACTER
062122 001775          BEQ    1$
062124 005337 061220          DEC    $TKCNT          ;; DECREMENT THE COUNTER
062130 117766 177070 000004  MOVB  @$TKQOUT,4(SP)    ;; GET ONE CHARACTER
062136 005237 061224          INC    $TKQOUT          ;; UPDATE THE POINTER
062142 023727 061224 061227  CMP    $TKQOUT,#$TKQEND ;; DID IT GO OFF OF THE END?
062150 001003          BNE    2$          ;; BRANCH IF NO
062152 012737 061226 061224  MOV    #$TKQSRT,$TKQOUT ;; RESET THE POINTER
062160 000002          RTI                    ;; RETURN

```

```

: *****
: *THIS ROUTINE WILL INPUT A STRING FROM THE TTY
: *CALL:
: *   RDLIN
: *   RETURN HERE    ;; INPUT A STRING FROM THE TTY
: *                ;; ADDRESS OF FIRST CHARACTER WILL BE ON THE STACK
: *                ;; TERMINATOR WILL BE A BYTE OF ALL 0'S
:

```

```

062162 010346          $RDLIN: MOV    R3, -(SP)          ;; SAVE R3
062164 005046          CLR    -(SP)          ;; CLEAR THE RUBOUT KEY
062166 012703 062416 1$:   MOV    #$TTYIN,R3      ;; GET ADDRESS
062172 022703 062426 2$:   CMP    #$TTYIN+8.,R3    ;; BUFFER FULL?
062176 101456          BLOS  4$          ;; BR IF YES
062200 104411          RDCHR          ;; GO READ ONE CHARACTER FROM THE TTY
062202 112613          MOVB  (SP)+,(R3)      ;; GET CHARACTER
062204 122713 000177 10$:  CMPB  #177,(R3)        ;; IS IT A RUBOUT
062210 001022          BNE    5$          ;; BR IF NO
062212 005716          TST    (SP)          ;; IS THIS THE FIRST RUBOUT?
062214 001007          BNE    6$          ;; BR IF NO
062216 112737 000134 062414  MOVB  #' \,9$         ;; TYPE A BACK SLASH
062224 104401 062414          TYPE  ,9$
062230 012716 177777          MOV    #-1,(SP)      ;; SET THE RUBOUT KEY
062234 005303          DEC    R3          ;; BACKUP BY ONE
062236 020327 062416 6$:   CMP    R3,$$TTYIN    ;; STACK EMPTY?
062242 103434          BLO  4$          ;; BR IF YES
062244 111337 062414          MOVB  (R3),9$       ;; SETUP TO TYPEOUT THE DELETED CHAR.
062250 104401 062414          TYPE  ,9$
062254 000746          BR    2$          ;; GO READ ANOTHER CHAR.
062256 005716          5$:   TST    (SP)          ;; RUBOUT KEY SET?
062260 001406          BEQ    7$          ;; BR IF NO
062262 112737 000134 062414  MOVB  #' \,9$         ;; TYPE A BACK SLASH
062270 104401 062414          TYPE  ,9$
062274 005016          CLR    (SP)          ;; CLEAR THE RUBOUT KEY
062276 122713 000025 7$:   CMPB  #25,(R3)      ;; IS CHARACTER A CTRL U?
062302 001003          BNE    8$          ;; BR IF NO

```

```

TTY INPUT ROUTINE

062304 104401 062433          TYPE      ,SCNTLU          ;;TYPE A CONTROL 'U'
062310 000726          BR          1$          ;;GO START OVER
062312 122713 000022      8$:  CMPB      #22,(R3)      ;;IS CHARACTER A '^R'?
062316 001011          BNE          3$          ;;BRANCH IF NO
062320 105013          CLRB      (R3)          ;;CLEAR THE CHARACTER
062322 104401 001217      TYPE      ,SCRLF          ;;TYPE A 'CR' & 'LF'
062326 104401 062416      TYPE      ,STTYIN         ;;TYPE THE INPUT STRING
062332 000717          BR          2$          ;;GO PICKUP ANOTHER CHACTER
062334 104401 001216      4$:  TYPE      ,SQUES          ;;TYPE A '?'
062340 000712          BR          1$          ;;CLEAR THE BUFFER AND LOOP
062342 111337 062414      3$:  MOVB      (R3),9$          ;;ECHO THE CHARACTER
062346 104401 062414      TYPE      ,9$
062352 122723 000015      CMPB      #15,(R3)+      ;;CHECK FOR RETURN
062356 001305          BNE          2$          ;;LOOP IF NOT RETURN
062360 105063 177777      CLRB      -1(R3)        ;;CLEAR RETURN (THE 15)
062364 104401 001220      TYPE      ,SLF          ;;TYPE A LINE FEED
062370 005726          TST      (SP)+          ;;CLEAN RUBOUT KEY FROM THE STACK
062372 012603          MOV      (SP)+,R3        ;;RESTORE R3
062374 011646          MOV      (SP)-,(SP)      ;;ADJUST THE STACK AND PUT ADDRESS OF THE
062376 016666 000004 000002 MOV      4(SP),2(SP)      ;; FIRST ASCII CHARACTER ON IT
062404 012766 062416 000004 MOV      #STTYIN,4(SP)
062412 000002          RTI          ;;RETURN
062414 000          9$:  .BYTE      0          ;;STORAGE FOR ASCII CHAR. TO TYPE
062415 000          .BYTE      0          ;;TERMINATOR
062416          .BLKB      8          ;;RESERVE 8 BYTES FOR TTY INPUT
062426 136 103 015 $TTYIN: .ASCIZ  /^C/<15><12>  ;;CONTROL 'C'
062433 136 125 015 $CNTLC: .ASCIZ  /^U/<15><12>  ;;CONTROL 'U'
062440 136 107 015 $CNTLU: .ASCIZ  /^G/<15><12>  ;;CONTROL 'G'
062445 015 012 123 $MSWR: .ASCIZ  <15><12>/SWR = /
062456 040 040 116 $MNEW: .ASCIZ  / NEW = /
          .EVEN

2
3 062470 012737 177777 001326 SHUT2: MOV      #-1,CTFLG      ;SET THE CONTROL-C FLAG
4 062476 105737 001116      TSTB     $STNM          ;DOING ANY TESTS ?
5 062502 001002          BNE      1$          ;BR IF YES
6 062504 000137 032142      JMP      SHUT          ;NO--RESPOND TO ^C
7 062510 000002          1$:  RTI          ;EXIT FROM INTERRUPT
    
```


1

.SBTTL READ AN OCTAL NUMBER FROM THE TTY

::*****
 ::THIS ROUTINE WILL READ AN OCTAL (ASCII) NUMBER FROM THE TTY AND
 ::CHANGE IT TO BINARY.

::CALL:
 ::* RDOCT ::READ AN OCTAL NUMBER
 ::* RETURN HERE ::LOW ORDER BITS ARE ON TOP OF THE STACK
 ::* ::HIGH ORDER BITS ARE IN \$HIOCT

062512	011646			\$RDOCT: MOV	(SP),-(SP)	::PROVIDE SPACE FOR THE
062514	016666	000004	000002	MOV	4(SP),2(SP)	::INPUT NUMBER
062522	010046			MOV	R0,-(SP)	::PUSH R0 ON STACK
062524	010146			MOV	R1,-(SP)	::PUSH R1 ON STACK
062526	010246			MOV	R2,-(SP)	::PUSH R2 ON STACK
062530	104412			1\$: RDLIN		::READ AN ASCII LINE
062532	012600			MOV	(SP)+,R0	::GET ADDRESS OF 1ST CHARACTER
062534	005001			CLR	R1	::CLEAR DATA WORD
062536	005002			CLR	R2	
062540	112046			2\$: MOVB	(R0)+,-(SP)	::PICKUP THIS CHARACTER
062542	001412			BEQ	3\$::IF ZERO GET OUT
062544	006301			ASL	R1	::*2
062546	006102			ROL	R2	
062550	006301			ASL	R1	::*4
062552	006102			ROL	R2	
062554	006301			ASL	R1	::*8
062556	006102			ROL	R2	
062560	042716	177770		BIC	#^C7,(SP)	::STRIP THE ASCII JUNK
062564	062601			ADD	(SP)+,R1	::ADD IN THIS DIGIT
062566	000764			BR	2\$::LOOP
062570	005726			3\$: TST	(SP)+	::CLEAN TERMINATOR FROM STACK
062572	010166	000012		MOV	R1,12(SP)	::SAVE THE RESULT
062576	010237	062612		MOV	R2,\$HIOCT	
062602	012602			MOV	(SP)+,R2	::POP STACK INTO R2
062604	012601			MOV	(SP)+,R1	::POP STACK INTO R1
062606	012600			MOV	(SP)+,R0	::POP STACK INTO R0
062610	000002			RTI		::RETURN
062612	000000			\$HIOCT: .WORD	0	::HIGH ORDER BITS GO HERE

.SBTTL TRAP DECODER

*THIS ROUTINE WILL PICKUP THE LOWER BYTE OF THE 'TRAP' INSTRUCTION
*AND USE IT TO INDEX THROUGH THE TRAP TABLE FOR THE STARTING ADDRESS
*OF THE DESIRED ROUTINE. THEN USING THE ADDRESS OBTAINED IT WILL
*GO TO THAT ROUTINE.

062614	016646	000002	\$TRAP:	MOV	2(SP),-(SP)	::ASSUME THE STATUS OF
062620	042716	000020		BIC	#20,(SP)	:: THE CALLER--DO NOT ALLOW
062624	012746	062632		MOV	#1\$,-(SP)	:: T-BIT TRAPS
062630	000002			RTI		::SET THE NEW STATUS
062632	010046		1\$:	MOV	R0,-(SP)	::SAVE R0
062634	016600	000002		MOV	2(SP),R0	::GET TRAP ADDRESS
062640	005740			TST	-(R0)	::BACKUP BY 2
062642	111000			MOVB	(R0),R0	::GET RIGHT BYTE OF TRAP
062644	006300			ASL	R0	::POSITION FOR INDEXING
062646	016000	062666		MOV	\$TRPAD(R0),R0	::INDEX TO TABLE
062652	000200			RTS	R0	::GO TO ROUTINE

::THIS IS USE TO HANDLE THE 'GETPRI' MACRO

062654	011646		\$TRAP2:	MOV	(SP),-(SP)	::MOVE THE PC DOWN
062656	016666	000004		MOV	4(SP),2(SP)	::MOVE THE PSW DOWN
062664	000002	000002		RTI		::RESTORE THE PSW

.SBTTL TRAP TABLE

*THIS TABLE CONTAINS THE STARTING ADDRESSES OF THE ROUTINES CALLED
*BY THE 'TRAP' INSTRUCTION.

			:	ROUTINE		
			:	-----		
062666	062654		\$TRPAD:	.WORD	\$TRAP2	
062670	056430			\$TYPE	::CALL=TYPE	TRAP+1(104401) TTY TYPEOUT ROUTINE
062672	056226			\$TYPOC	::CALL=TYPOC	TRAP+2(104402) TYPE OCTAL NUMBER (WITH LEADING ZEROS)
062674	056202			\$TYPOS	::CALL=TYPOS	TRAP+3(104403) TYPE OCTAL NUMBER (NO LEADING ZEROS)
062676	056242			\$TYPON	::CALL=TYPON	TRAP+4(104404) TYPE OCTAL NUMBER (AS PER LAST CALL)
062700	055756			\$TYPDS	::CALL=TYPDS	TRAP+5(104405) TYPE DECIMAL NUMBER (WITH SIGN)
062702	055702			\$TYPBN	::CALL=TYPBN	TRAP+6(104406) TYPE BINARY (ASCII) NUMBER
062704	061620			\$GTSWR	::CALL=GTSWR	TRAP+7(104407) GET SOFT-SWR SETTING
062706	061530			\$CKSWR	::CALL=CKSWR	TRAP+10(104410) TEST FOR CHANGE IN SOFT-SWR
062710	062072			\$RDCHR	::CALL=RDCHR	TRAP+11(104411) TTY TYPEIN CHARACTER ROUTINE
062712	062162			\$RDLIN	::CALL=RDLIN	TRAP+12(104412) TTY TYPEIN STRING ROUTINE
062714	062512			\$RDOCT	::CALL=RDOCT	TRAP+13(104413) READ AN OCTAL NUMBER FROM TTY
062716	055606			\$SAVREG	::CALL=SAVREG	TRAP+14(104414) SAVE R0-R5 ROUTINE
062720	055644			\$RESREG	::CALL=RESREG	TRAP+15(104415) RESTORE R0-R5 ROUTINE

.SBTTL POWER DOWN AND UP ROUTINES

```

*****
:POWER DOWN ROUTINE
062722 012737 063062 000024 $PWRDN: MOV    #SILLUP,@#PWRVEC  ;;SET FOR FAST UP
062730 012737 000340 000026      MOV    #340,@#PWRVEC+2  ;;PRIO:7
062736 010046      MOV    R0,-(SP)        ;;PUSH R0 ON STACK
062740 010146      MOV    R1,-(SP)        ;;PUSH R1 ON STACK
062742 010246      MOV    R2,-(SP)        ;;PUSH R2 ON STACK
062744 010346      MOV    R3,-(SP)        ;;PUSH R3 ON STACK
062746 010446      MOV    R4,-(SP)        ;;PUSH R4 ON STACK
062750 010546      MOV    R5,-(SP)        ;;PUSH R5 ON STACK
062752 017746 116176      MOV    @SWR,-(SP)      ;;PUSH @SWR ON STACK
062756 010637 063066      MOV    SP,$SAVR6      ;;SAVE SP
062762 012737 062774 000024      MOV    #PWRUP,@#PWRVEC ;;SET UP VECTOR
062770 000000      HALT
062772 000776      BR     .-2            ;;HANG UP

*****
:POWER UP ROUTINE
062774 012737 063062 000024 $PWRUP: MOV    #SILLUP,@#PWRVEC  ;;SET FOR FAST DOWN
063002 013706 063066      MOV    $SAVR6,SP      ;;GET SP
063006 005037 063066      CLR    $SAVR6        ;;WAIT LOOP FOR THE TTY
063012 005237 063066 1$: INC    $SAVR6        ;;WAIT FOR THE INC
063016 001375      BNE    1$            ;;OF WORD
063020 012677 116130      MOV    (SP)+,@SWR     ;;POP STACK INTO @SWR
063024 012605      MOV    (SP)+,R5      ;;POP STACK INTO R5
063026 012604      MOV    (SP)+,R4      ;;POP STACK INTO R4
063030 012603      MOV    (SP)+,R3      ;;POP STACK INTO R3
063032 012602      MOV    (SP)+,R2      ;;POP STACK INTO R2
063034 012601      MOV    (SP)+,R1      ;;POP STACK INTO R1
063036 012600      MOV    (SP)+,R0      ;;POP STACK INTO R0
063040 012737 062722 000024      MOV    #PWRDN,@#PWRVEC ;;SET UP THE POWER DOWN VECTOR
063046 012737 000340 000026      MOV    #340,@#PWRVEC+2 ;;PRIO:7
063054 104401      TYPE                                ;;REPORT THE POWER FAILURE
063056 063070 $PWRMG: .WORD  $POWER          ;;POWER FAIL MESSAGE POINTER
063060 000002      RTI
063062 000000 $ILLUP: HALT
063064 000776      BR     .-2            ;;THE POWER UP SEQUENCE WAS STARTED
063066 000000      $SAVR6: 0             ;;BEFORE THE POWER DOWN WAS COMPLETE
063070 015 012 120 $POWER: .ASCIZ <15><12>'POWER' ;;PUT THE SP HERE
          .EVEN

```

2

.SBTTL APT COMMUNICATIONS ROUTINE

```

*****
$ATY1: MOV    #1,$FFLG  ;;TO REPORT FATAL ERROR
063106 112737 000001 063342 $ATY3: MOV    #1,$MFLG  ;;TO TYPE A MESSAGE
063114 000403      BR     $ATYC
063116 112737 000001 063344 $ATY4: MOV    #1,$FFLG  ;;TO ONLY REPORT FATAL ERROR
063124 $ATYC:
063124 010046      MOV    R0,-(SP)      ;;PUSH R0 ON STACK
063126 010146      MOV    R1,-(SP)      ;;PUSH R1 ON STACK
063130 105737 063342      TSTB   $MFLG        ;;SHOULD TYPE A MESSAGE?
063134 001450      BEQ    5$            ;;IF NOT: BR
063136 122737 000001 001242      CMPB   #APTENV,$ENV  ;;OPERATING UNDER APT?
063144 001031      BNE    3$            ;;IF NOT: BR
063146 132737 000100 001243      BITB   #APTPOOL,$ENVM ;;SHOULD SPOOL MESSAGES?

```

063154	001425			BEQ	3\$::IF NOT: BR
063156	017600	000004		MOV	@4(SP),R0	::GET MESSAGE ADDR.
063162	062766	000002	000004	ADD	#2,4(SP)	::BUMP RETURN ADDR.
063170	005737	001222		TST	\$MSGTYPE	::SEE IF DONE W/ LAST XMISSION?
063174	001375			BNE	1\$::IF NOT: WAIT
063176	010037	001236		MOV	R0,\$MSGAD	::PUT ADDR IN MAILBOX
063202	105720		2\$:	TSTB	(R0)+	::FIND END OF MESSAGE
063204	001376			BNE	2\$	
063206	163700	001236		SUB	\$MSGAD,R0	::SUB START OF MESSAGE
063212	006200			ASR	R0	::GET MESSAGE LNTH IN WORDS
063214	010037	001240		MOV	R0,\$MSGLGT	::PUT LENGTH IN MAILBOX
063220	012737	000004	001222	MOV	#4,\$MSGTYPE	::TELL APT TO TAKE MSG.
063226	000413			BR	5\$	
063230	017637	000004	063254	MOV	@4(SP),4\$::PUT MSG ADDR IN JSR LINKAGE
063236	062766	000002	000004	ADD	#2,4(SP)	::BUMP RETURN ADDRESS
063244	013746	177776		MOV	177776,-(SP)	::PUSH 177776 ON STACK
063250	004737	056430		JSR	PC,\$TYPE	::CALL TYPE MACRO
063254	000000		4\$:	.WORD	0	
063256	105737	063344	5\$:			
063262	001416		10\$:	TSTB	\$FFLG	::SHOULD REPORT FATAL ERROR?
063264	005737	001242		BEQ	12\$::IF NOT: BR
063270	001413			TST	\$ENV	::RUNNING UNDER APT?
063272	005737	001222		BEQ	12\$::IF NOT: BR
063276	001375		11\$:	TST	\$MSGTYPE	::FINISHED LAST MESSAGE?
063300	017637	000004	001224	BNE	11\$::IF NOT: WAIT
063306	062766	000002	000004	MOV	@4(SP),\$FATAL	::GET ERROR #
063314	005237	001222		ADD	#2,4(SP)	::BUMP RETURN ADDR.
063320	105037	063344	12\$:	INC	\$MSGTYPE	::TELL APT TO TAKE ERROR
063324	105037	063343		CLRB	\$FFLG	::CLEAR FATAL FLAG
063330	105037	063342		CLRB	\$LFLG	::CLEAR LOG FLAG
063334	012601			CLRB	\$MFLG	::CLEAR MESSAGE FLAG
063336	012600			MOV	(SP)+,R1	::POP STACK INTO R1
063340	000207			MOV	(SP)+,R0	::POP STACK INTO R0
063342	000			RTS	PC	::RETURN
063343	000					
063344	000					
				\$MFLG:	.BYTE	0
				\$LFLG:	.BYTE	0
				\$FFLG:	.BYTE	0
					.EVEN	
	000200			APTSIZE	=	200
	000001			APTENV	=	001
	000100			APTPOOL	=	100
	000040			APTCSUP	=	040


```

1
2
3 063346      200      103      101  SCTMSG: .ASCIZ <CRLF>@CANNOT RECOVER THE BAD SECTOR FILES ON THIS DEVICE@
4 063432      075      000
5 063434      101      114      114  ALL: .ASCIZ @ALL@<CRLF>
6 063441      040      077      040  QUES: .ASCIZ @ ? @
7 063445      054      040      000  COMMA: .ASCIZ @, @
8 063450      200      124      117  MSHELP: .ASCII <CRLF>@TO ENSURE THAT NO BAD HEADERS ARE LEFT ON THE DISK@
9 063536      200      120      101      .ASCII <CRLF>@PACK, THIS PROGRAM SHOULD BE HALTED BY TYPING A (^C)@
10 063624      200      103      117      .ASCII <CRLF>@CONTROL C. AS A RESULT, THE PROGRAM WILL BE HALTED@
11 063712      200      127      110      .ASCII <CRLF>@WHEN THE DRIVE UNDER TEST HAS COMPLETED TESTING.@<CRLF>
12 063774      200      124      131      .ASCIZ <CRLF>@TYPE HELP TEXT (L) N ? @
13 064025      200      122      115  CNSLO1: .ASCIZ <CRLF>@RMCS1=@
14 064035      040      114      111  CNSLO2: .ASCIZ @ LIMITS - LO= 160000, HI= 17XXXX@<CRLF>
15 064077      122      115      126  CNSLO3: .ASCIZ @RMVEC=@
16 064106      040      114      111  CNSLO4: .ASCIZ @ LIMITS - LO= 0, HI= 1000@<CRLF><LF>
17 064142      200      124      131  CNSLO7: .ASCII <CRLF>@TYPE 'A' TO TEST ALL DRIVES, OR TYPE DRIVE NUMBER(S)@
18 064227      200      101      116      .ASCIZ <CRLF>@AND TERMINATE INPUT WITH A CARRIAGE RETURN.@
19 064304      200
20 064305      040      077      111  CNSLO8: .ASCII <CRLF>
21 064326      200      104      122  CNSLO9: .ASCIZ @ ?ILLEGAL INPUT@<CRLF>
22 064342      104      122      111  MSDRVS: .ASCIZ <CRLF>/DRIVE(S): /
23 064350      200      125      116  MSGDRV: .ASCIZ /DRIVE/
24 064366      122      115      060  SYSTAT: .ASCIZ <CRLF>/UNIT STATUS:/
25 064373      122      115      060  $RM02: .ASCIZ /RM02/
26 064400      122      115      060  $RM03: .ASCIZ /RM03/
27 064405      040      116      117  $RM05: .ASCIZ /RM05/
28 064426      040      114      117  NOTRM: .ASCIZ @ NOT AN RM05/3/2@
29 064443      040      116      117  LODEV: .ASCIZ / LOAD DEVICE/
30 064460      040      116      117  NOTPRS: .ASCIZ / NOT PRESENT/
31 064477      040      117      106  NOTAVL: .ASCIZ / NOT AVAILABLE/
32 064510      040      117      116  UNTOFF: .ASCIZ / OFFLINE/
33 064520      200      104      122  UNTON: .ASCIZ / ONLINE/
34 064547      116      117      116  DRIVES: .ASCIZ <CRLF>/DRIVE(S) TO BE TESTED/
35 064554      116      000
36 064556      131      000      116  NONE: .ASCIZ /NONE/
37 064560      040      N: .ASCIZ /N/
38 064561      040      Y: .ASCIZ /Y/
39 064562      040      BLNKS4: .ASCII //
40 064563      040      BLNKS3: .ASCII //
41          000      BLNKS2: .ASCII //
          BLNKS1: .ASCIZ //
          .EVEN

```

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57

064566
064566 020000

.SBTTL FUNCTION CODE TABLE
:THE FUNCTION CODE TABLE IS USED TO DEFINE STATUS CONDITIONS FOR
:EACH FUNCTION CODE. BIT USAGE IS AS FOLLOWS:
:
: ATA - BIT 15 IS SET IN THE ENTRY FOR A GIVEN FUNCTION CODE
: IF ATA SHOULD BE SET WHEN THE FUNCTION CODE IS EXECUTED, OTHERWISE,
: BIT 15 IS ZERO, INDICATING THAT ATA SHOULD NOT NORMALLY BE SET.
: NOTE THAT ATA MAY BE SET WHEN A COMMAND IS EXECUTED EVEN THOUGH
: IT IS NOT EXPECTED AS A RESULT OF THE COMMAND.
:
: WCE - BIT 14 IS SET IN THE ENTRY FOR A GIVEN FUNCTION CODE
: IF WRITE CHECK ERRORS ARE ENABLED AS A FUNCTION OF THE COMMAND.
:
: OPI - BIT 13 IS SET IN THE ENTRY FOR A GIVEN FUNCTION CODE
: IF OPI ERRORS ARE ENABLED DURING THE EXECUTION OF THAT COMMAND.
:
: IVC - BIT 12 IS SET IN THE ENTRY FOR A GIVEN FUNCTION CODE
: IF IVC ERRORS ARE ENABLED DURING THE EXECUTION OF THAT COMMAND.
:
: WLE - BIT 11 IS SET IN THE ENTRY FOR A GIVEN FUNCTION CODE
: IF WRITE ERRORS ARE ENABLED DURING THE EXECUTION OF THAT COMMAND.
: THE WRITE ERRORS WHICH ARE ENABLED ARE 'WLE', 'WCF', 'DPE', 'UPE'.
:
: IAE - BIT 10 IS SET IN THE ENTRY FOR A GIVEN FUNCTION CODE
: IF INVALID ADDRESS ERROR IS ENABLED FOR THAT COMMAND.
:
: AOE - BIT 09 IS SET IN THE ENTRY FOR A GIVEN FUNCTION CODE
: IF READ AND WRITE ERRORS ARE ENABLED DURING THE EXECUTION OF THE
: COMMAND. THE ERRORS ENABLED BY THIS BIT ARE 'TRE', 'DLT', 'NEM',
: 'MXF', 'LBT', AND 'AOE'.
:
: BIT 08 IS NOT USED.
:
: HCE - BIT 07 IS SET IN THE ENTRY FOR A GIVEN FUNCTION CODE
: IF HEADER ERRORS ARE ENABLED DURING THE EXECUTION OF THAT COMMAND.
: HEADER ERRORS INCLUDE 'HCRC', 'HCE', 'FER', AND 'BSE'.
:
: ECH - BIT 06 IS SET IN THE ENTRY FOR A GIVEN FUNCTION CODE
: IF DATA FIELD ERRORS ARE ENABLED DURING THE EXECUTION OF THAT
: COMMAND. THESE ERRORS INCLUDE 'MDPE', 'DCK', AND 'ECH'.
:
: BIT 05 IS NOT USED.
:
: BIT 04 IS NOT USED.
:
: BIT 03 IS NOT USED.
:
: BIT 02 IS NOT USED.
:
: BIT 01 IS NOT USED.
:
: ILF - BIT 00 IS SET IF THE FUNCTION CODE IS ILLEGAL.
FNCDTB: ;FUNCTION CODE TABLE
.WORD OPI ;NOP

58	064570	130001	.WORD	OPI!ATA!ILF!IVC	:ILLEGAL FUNCTION (2)
59	064572	132000	.WORD	ATA!OPI!IVC!IAE	:SEEK
60	064574	130000	.WORD	ATA!OPI!IVC	:RECALIBRATE
61	064576	020000	.WORD	OPI	:DRIVE CLEAR
62	064600	030000	.WORD	OPI!IVC	:RELEASE
63	064602	130000	.WORD	OPI!ATA!IVC	:OFFSET
64	064604	130000	.WORD	OPI!ATA!IVC	:RETURN TO CENTERLINE
65	064606	020000	.WORD	OPI	:READ IN PRESET
66	064610	020000	.WORD	OPI	:PACK ACKNOWLEDGE
67	064612	130001	.WORD	OPI!ATA!ILF!IVC	:ILLEGAL FUNCTION (24)
68	064614	130001	.WORD	OPI!ATA!ILF!IVC	:ILLEGAL FUNCTION (26)
69	064616	132000	.WORD	ATA!OPI!IVC!IAE	:SEARCH
70	064620	130001	.WORD	OPI!ATA!ILF!IVC	:ILLEGAL FUNCTION (32)
71	064622	130001	.WORD	OPI!ATA!ILF!IVC	:ILLEGAL FUNCTION (34)
72	064624	130001	.WORD	OPI!ATA!ILF!IVC	:ILLEGAL FUNCTION (36)
73	064626	130001	.WORD	OPI!ATA!ILF!IVC	:ILLEGAL FUNCTION (40)
74	064630	130001	.WORD	OPI!ATA!ILF!IVC	:ILLEGAL FUNCTION (42)
75	064632	130001	.WORD	OPI!ATA!ILF!IVC	:ILLEGAL FUNCTION (44)
76	064634	130001	.WORD	OPI!ATA!ILF!IVC	:ILLEGAL FUNCTION (46)
77	064636	073300	.WORD	WCE!OPI!IVC!IAE!AOE!HCE!ECH	:WRITE CHECK DATA
78	064640	073300	.WORD	WCE!OPI!IVC!IAE!AOE!HCE!ECH	:WRITE CHECK HEADER AND DATA
79	064642	130001	.WORD	OPI!ATA!ILF!IVC	:ILLEGAL FUNCTION (54)
80	064644	130001	.WORD	OPI!ATA!ILF!IVC	:ILLEGAL FUNCTION (56)
81	064646	037200	.WORD	OPI!IVC!WLE!IAE!AOE!HCE	:WRITE DATA
82	064650	037000	.WORD	OPI!IVC!WLE!IAE!AOE	:WRITE HEADER AND DATA
83	064652	130001	.WORD	OPI!ATA!ILF!IVC	:ILLEGAL FUNCTION (64)
84	064654	130001	.WORD	OPI!ATA!ILF!IVC	:ILLEGAL FUNCTION (66)
85	064656	033300	.WORD	OPI!IVC!IAE!AOE!HCE!ECH	:READ DATA
86	064660	033300	.WORD	OPI!IVC!IAE!AOE!HCE!ECH	:READ HEADER AND DATA
87	064662	130001	.WORD	OPI!ATA!ILF!IVC	:ILLEGAL FUNCTION (74)
88	064664	130001	.WORD	OPI!ATA!ILF!IVC	:ILLEGAL FUNCTION (76)

1
2
3 064666 001
4 064667 002
5 064670 004
6 064671 010
7 064672 020
8 064673 040
9 064674 100
10 064675 200

.SBTTL ATTENTION (ATA) TABLE

ATNTBL: .BYTE 1.
.BYTE 2.
.BYTE 4.
.BYTE 8.
.BYTE 16.
.BYTE 32.
.BYTE 64.
.BYTE 123.

DATA PATTERN TABLE		.SBTTL DATA PATTERN TABLE	
1			
2			
3	064676		
4	064676	RGDTPT:	
5	064676	MIXED:	.WORD 0.
6	064700		.WORD 1.
7	064702		.WORD 3.
8	064704		.WORD 7.
9	064706		.WORD 15.
10	064710		.WORD 31.
11	064712		.WORD 63.
12	064714		.WORD 127.
13	064716		.WORD 255.
14	064720		.WORD 511.
15	064722		.WORD 1023.
16	064724		.WORD 2047.
17	064726		.WORD 4095.
18	064730		.WORD 8191.
19	064732		.WORD 16383.
20	064734		.WORD 32767.
21	064736	ONES:	.WORD 65535.
22	064740		.WORD 65535.
23	064742		.WORD 32767.
24	064744		.WORD 16383.
25	064746		.WORD 8191.
26	064750		.WORD 4095.
27	064752		.WORD 2047.
28	064754		.WORD 1023.
29	064756		.WORD 511.
30	064760		.WORD 255.
31	064762		.WORD 127.
32	064764		.WORD 63.
33	064766		.WORD 31.
34	064770		.WORD 15.
35	064772		.WORD 7.
36	064774		.WORD 3.
37	064776		.WORD 1.
38	065000	ZEROS:	.WORD 0.
39	065002		.WORD 0.
40	065004		.WORD 1.
41	065006		.WORD 2.
42	065010		.WORD 4.
43	065012		.WORD 8.
44	065014		.WORD 16.
45	065016		.WORD 32.
46	065020		.WORD 64.
47	065022		.WORD 128.
48	065024		.WORD 256.
49	065026		.WORD 512.
50	065030		.WORD 1024.
51	065032		.WORD 2048.
52	065034		.WORD 4096.
53	065036		.WORD 8192.
54	065040		.WORD 16384.
55	065042		.WORD 32768.
56	065044		.WORD 32768.
57	065046		.WORD 16384.

Line	Address	Value	Label	Value
58	065050	020000	.WORD	8192.
59	065052	010000	.WORD	4096.
60	065054	004000	.WORD	2048.
61	065056	002000	.WORD	1024.
62	065060	001000	.WORD	512.
63	065062	000400	.WORD	256.
64	065064	000200	.WORD	128.
65	065066	000100	.WORD	64.
66	065070	000040	.WORD	32.
67	065072	000020	.WORD	16.
68	065074	000010	.WORD	8.
69	065076	000004	.WORD	4.
70	065100	000002	.WORD	2.
71	065102	000001	.WORD	1.
72	065104	000000	.WORD	0.
73	065106	177777	.WORD	65535.
74	065110	177776	.WORD	65534.
75	065112	177774	.WORD	65532.
76	065114	177770	.WORD	65528.
77	065116	177760	.WORD	65520.
78	065120	177740	.WORD	65504.
79	065122	177700	.WORD	65472.
80	065124	177600	.WORD	65408.
81	065126	177400	.WORD	65280.
82	065130	177000	.WORD	65024.
83	065132	176000	.WORD	64512.
84	065134	174000	.WORD	63488.
85	065136	170000	.WORD	61440.
86	065140	160000	.WORD	57344.
87	065142	140000	.WORD	49152.
88	065144	100000	.WORD	32768.
89	065146	000000	.WORD	0.
90	065150	000000	.WORD	0.
91	065152	100000	.WORD	32768.
92	065154	140000	.WORD	49152.
93	065156	160000	.WORD	57344.
94	065160	170000	.WORD	61440.
95	065162	174000	.WORD	63488.
96	065164	176000	.WORD	64512.
97	065166	177000	.WORD	65024.
98	065170	177400	.WORD	65280.
99	065172	177600	.WORD	65408.
100	065174	177700	.WORD	65472.
101	065176	177740	.WORD	65504.
102	065200	177760	.WORD	65520.
103	065202	177770	.WORD	65528.
104	065204	177774	.WORD	65532.
105	065206	177776	.WORD	65534.
106	065210	177777	.WORD	65535.
107	065212	125252	.WORD	43690.
108	065214	152525	.WORD	43690./2
109	065216	125252	.WORD	43690.
110	065220	177777	.WORD	65535.
111	065222	177776	.WORD	65534.
112	065224	177775	.WORD	65533.
113	065226	177773	.WORD	65531.
114	065230	177767	.WORD	65527.

EARLY:

115	065232	177757	.WORD	65519.
116	065234	177737	.WORD	65503.
117	065236	177677	.WORD	65471.
118	065240	177577	.WORD	65407.
119	065242	177377	.WORD	65279.
120	065244	176777	.WORD	65023.
121	065246	175777	.WORD	64511.
122	065250	173777	.WORD	63487.
123	065252	167777	.WORD	61439.
124	065254	157777	.WORD	57343.
125	065256	137777	.WORD	49151.
126	065260	077777	.WORD	32767.
127	065262	077777	.WORD	32767.
128	065264	137777	.WORD	49151.
129	065266	157777	.WORD	57343.
130	065270	167777	.WORD	61439.
131	065272	173777	.WORD	63487.
132	065274	175777	.WORD	64511.
133	065276	176777	.WORD	65023.
134	065300	177377	.WORD	65279.
135	065302	177577	.WORD	65407.
136	065304	177677	.WORD	65471.
137	065306	177737	.WORD	65503.
138	065310	177757	.WORD	65519.
139	065312	177767	.WORD	65527.
140	065314	177773	.WORD	65531.
141	065316	177775	.WORD	65533.
142	065320	177776	.WORD	65534.
143	065322	177777	.WORD	65535.
144	065324			

ENRGDT:

				.SBTTL	ERROR MESSAGE TABLE	
1						
2						
3	065324	071712	000000	EMT1:	.WORD	EMS1,0
4	065330	071761	071776	EMT2:	.WORD	EMS2,EMS3,0
5	065336	071761	072041	EMT3:	.WORD	EMS2,EMS4,0
6	065344	072104	072134	EMT4:	.WORD	EMS5,EMS6,0
7	065352	072104	072246	EMT5:	.WORD	EMS5,EMS10,0
8	065360	076707	074125	EMT6:	.WORD	EMS167,EMS64,0
9	065366	074673	076734	EMT7:	.WORD	EMS110,EMS170,0
10	065374	072201	000000	EMT10:	.WORD	EMS7,0
11	065400	072246	000000	EMT11:	.WORD	EMS10,0
12	065404	072310	072321	EMT12:	.WORD	EMS11,EMS12,0
13	065412	072362	072373	EMT13:	.WORD	EMS13,EMS14,EMS15,EMS16,0
14	065424	072456	074125	EMT14:	.WORD	EMS17,EMS64,0
15	065432	072310	072541	EMT15:	.WORD	EMS11,EMS21,0
16	065440	072310	072564	EMT16:	.WORD	EMS11,EMS22,EMS27,0
17	065450	072310	072600	EMT17:	.WORD	EMS11,EMS23,EMS30,0
18	065460	072310	072626	EMT20:	.WORD	EMS11,EMS24,EMS30,0
19	065470	072310	072655	EMT21:	.WORD	EMS11,EMS25,EMS27,0
20	065500	072310	072672	EMT22:	.WORD	EMS11,EMS26,EMS27,0
21	065510	072310	072734	EMT23:	.WORD	EMS11,EMS31,EMS30,0
22	065520	072310	072763	EMT24:	.WORD	EMS11,EMS32,EMS30,0
23	065530	072310	073012	EMT25:	.WORD	EMS11,EMS33,EMS30,0
24	065540	072310	073040	EMT26:	.WORD	EMS11,EMS34,EMS30,0
25	065550	072310	073111	EMT27:	.WORD	EMS11,EMS35,EMS30,0
26	065560	072310	073140	EMT30:	.WORD	EMS11,EMS36,EMS30,0
27	065570	072310	073167	EMT31:	.WORD	EMS11,EMS37,EMS30,0
28	065600	072310	073215	EMT32:	.WORD	EMS11,EMS40,EMS30,0
29	065610	072310	073244	EMT33:	.WORD	EMS11,EMS41,EMS30,0
30	065620	072310	073272	EMT34:	.WORD	EMS11,EMS42,EMS30,0
31	065630	072310	073321	EMT35:	.WORD	EMS11,EMS43,EMS30,0
32	065640	072310	073350	EMT36:	.WORD	EMS11,EMS44,EMS30,0
33	065650	072310	073423	EMT37:	.WORD	EMS11,EMS45,EMS30,0
34	065660	074211	072516	EMT40:	.WORD	EMS66,EMS20,0
35	065666	074377	076110	EMT41:	.WORD	EMS75,EMS141,EMS76,0
36	065676	076201	076211	EMT42:	.WORD	EMS144,EMS145,EMS72,EMS76,0
37	065710	073515	073631	EMT43:	.WORD	EMS47,EMS53,EMS76,0
38	065720	074436	073631	EMT44:	.WORD	EMS77,EMS53,EMS76,0
39	065730	074464	073631	EMT45:	.WORD	EMS100,EMS53,EMS76,0
40	065740	074512	073631	EMT46:	.WORD	EMS101,EMS53,EMS76,0
41	065750	074143	074125	EMT47:	.WORD	EMS65,EMS64,0
42	065756	072362	072404	EMT50:	.WORD	EMS13,EMS15,EMS63,0
43	065766	072310	073466	EMT51:	.WORD	EMS11,EMS46,EMS30,EMS67,0
44	066000	073515	073631	EMT52:	.WORD	EMS47,EMS53,EMS67,EMS115,EMS140,EMS141,0
45	066016	073515	073631	EMT53:	.WORD	EMS47,EMS53,EMS67,EMS115,EMS141,EMS164,0
46	066034	073544	073631	EMT54:	.WORD	EMS50,EMS53,EMS67,0
47	066044	076136	076153	EMT55:	.WORD	EMS142,EMS143,EMS53,EMS67,0
48	066056	073573	074333	EMT56:	.WORD	EMS51,EMS72,EMS67,EMS115,EMS50,EMS70,0
49	066074	076707	074343	EMT57:	.WORD	EMS167,EMS73,EMS67,0
50	066104	073714	074261	EMT60:	.WORD	EMS56,EMS67,EMS115,EMS150,EMS152,EMS70,0
51	066122	074320	073714	EMT61:	.WORD	EMS71,EMS56,EMS67,EMS115,EMS150,EMS152,EMS72,0
52	066142	076067	074261	EMT62:	.WORD	EMS140,EMS67,EMS115,EMS47,EMS70,0
53	066156	000000		EMT63:	.WORD	
54	066160	076274	076337	EMT64:	.WORD	EMS150,EMS152,EMS70,EMS115,EMS56,EMS73,EMS67,0
55	066200	073621	077334	EMT65:	.WORD	EMS52,EMS205,EMS214,EMS206,EMS115,EMS51,EMS72,0
56	066220	076646	074567	EMT66:	.WORD	EMS165,EMS103,EMS72,EMS124,0
57	066232	076646	074567	EMT67:	.WORD	EMS165,EMS103,EMS72,EMS171,0

58	066244	073466	072516	076541	EMT70:	.WORD	EMS46,EMS20,EMS163,0
59	066254	074320	074512	076541	EMT71:	.WORD	EMS71,EMS101,EMS163,0
60	066264	073515	074333	076541	EMT72:	.WORD	EMS47,EMS72,EMS163,EMS115,EMS140,EMS141,0
61	066302	073515	074333	076541	EMT73:	.WORD	EMS47,EMS72,EMS163,EMS115,EMS141,EMS72,0
62	066320	073714	073631	076541	EMT74:	.WORD	EMS56,EMS53,EMS163,0
63	066330	074320	073714	076541	EMT75:	.WORD	EMS71,EMS56,EMS163,EMS115,EMS150,EMS152,EMS72,0
64	066350	073544	073631	076541	EMT76:	.WORD	EMS50,EMS53,EMS163,0
65	066360	076136	076153	073631	EMT77:	.WORD	EMS142,EMS143,EMS53,EMS163,0
66	066372	074377	076110	076541	EMT100:	.WORD	EMS75,EMS141,EMS163,EMS115,EMS47,EMS70,0
67	066410	074377	076274	076541	EMT101:	.WORD	EMS75,EMS150,EMS163,EMS115,EMS56,EMS73,0
68	066426	076707	074343	076541	EMT102:	.WORD	EMS167,EMS73,EMS163,0
69	066436	076257	076313	074360	EMT103:	.WORD	EMS147,EMS151,EMS74,EMS163,0
70	066450	073573	074360	076541	EMT104:	.WORD	EMS51,EMS74,EMS163,EMS115,EMS50,EMS70,0
71	066466	076646	074464	076541	EMT105:	.WORD	EMS165,EMS100,EMS163,0
72	066476	076646	074436	076541	EMT106:	.WORD	EMS165,EMS77,EMS163,0
73	066506	076201	076211	073631	EMT107:	.WORD	EMS144,EMS145,EMS53,EMS163,EMS115,EMS143,EMS70,0
74	066526	074673	074733	075076	EMT110:	.WORD	EMS110,EMS112,EMS116,EMS111,0
75	066540	075017	072041	000000	EMT111:	.WORD	EMS113,EMS4,0
76	066546	075017	071776	000000	EMT112:	.WORD	EMS113,EMS3,0
77	066554	074673	075073	075076	EMT113:	.WORD	EMS110,EMS115,EMS116,EMS117,EMS114,0
78	066570	075017	075150	000000	EMT114:	.WORD	EMS113,EMS120,0
79	066576	075171	075631	075655	EMT115:	.WORD	EMS121,EMS132,EMS133,0
80	066606	075234	075631	075655	EMT116:	.WORD	EMS122,EMS132,EMS133,0
81	066616	075271	075631	075655	EMT117:	.WORD	EMS123,EMS132,EMS133,0
82	066626	075334	075631	075655	EMT120:	.WORD	EMS124,EMS132,EMS133,0
83	066636	075366	075631	075655	EMT121:	.WORD	EMS125,EMS132,EMS133,0
84	066646	075431	075631	075655	EMT122:	.WORD	EMS126,EMS132,EMS133,0
85	066656	076032	075631	075655	EMT123:	.WORD	EMS137,EMS132,EMS133,0
86	066666	075533	075631	075655	EMT124:	.WORD	EMS130,EMS132,EMS133,0
87	066676	075571	075631	075655	EMT125:	.WORD	EMS131,EMS132,EMS133,0
88	066706	075171	075631	075700	EMT126:	.WORD	EMS121,EMS132,EMS134,EMS123,0
89	066720	075234	075631	075700	EMT127:	.WORD	EMS122,EMS132,EMS134,EMS123,0
90	066732	075271	075631	075700	EMT130:	.WORD	EMS123,EMS132,EMS134,EMS123,0
91	066744	075334	075631	075700	EMT131:	.WORD	EMS124,EMS132,EMS134,EMS123,0
92	066756	075366	075631	075700	EMT132:	.WORD	EMS125,EMS132,EMS134,EMS123,0
93	066770	075431	075631	075700	EMT133:	.WORD	EMS126,EMS132,EMS134,EMS123,0
94	067002	076032	075631	075700	EMT134:	.WORD	EMS137,EMS132,EMS134,EMS123,0
95	067014	075533	075631	075700	EMT135:	.WORD	EMS130,EMS132,EMS134,EMS123,0
96	067026	075571	075631	075700	EMT136:	.WORD	EMS131,EMS132,EMS134,EMS123,0
97	067040	075171	075631	075742	EMT137:	.WORD	EMS121,EMS132,EMS135,0
98	067050	075271	075631	075742	EMT140:	.WORD	EMS123,EMS132,EMS135,0
99	067060	075171	075631	076005	EMT141:	.WORD	EMS121,EMS132,EMS136,0
100	067070	076032	075631	076005	EMT142:	.WORD	EMS137,EMS132,EMS136,0
101	067100	075334	075631	076005	EMT143:	.WORD	EMS124,EMS132,EMS136,0
102	067110	075366	075631	076005	EMT144:	.WORD	EMS125,EMS132,EMS136,0
103	067120	075431	075631	076005	EMT145:	.WORD	EMS126,EMS132,EMS136,0
104	067130	075571	075631	076005	EMT146:	.WORD	EMS131,EMS132,EMS136,0
105	067140	076763	075631	076005	EMT147:	.WORD	EMS171,EMS132,EMS136,0
106	067150	075533	075631	076005	EMT150:	.WORD	EMS130,EMS132,EMS136,0
107	067160	076067	075073	076110	EMT151:	.WORD	EMS140,EMS115,EMS141,EMS70,0
108	067172	076136	075073	076153	EMT152:	.WORD	EMS142,EMS115,EMS143,EMS72,0
109	067204	076201	076211	076240	EMT153:	.WORD	EMS144,EMS145,EMS146,EMS115,EMS143,EMS72,0
110	067222	076201	076211	072516	EMT154:	.WORD	EMS144,EMS145,EMS20,EMS115,EMS143,EMS70,0
111	067240	076274	076337	076405	EMT155:	.WORD	EMS150,EMS152,EMS154,EMS153,0
112	067252	076257	076313	076405	EMT156:	.WORD	EMS147,EMS151,EMS154,EMS155,0
113	067264	076257	076313	076441	EMT157:	.WORD	EMS147,EMS151,EMS156,EMS157,0
114	067276	076511	076441	076474	EMT160:	.WORD	EMS161,EMS156,EMS160,0

Line	Code	Code	Code	Code	Code	Code	Code
115	067306	072655	072713	076441	EMT161:	.WORD	EMS25,EMS27,EMS156,EMS160,0
116	067320	072672	072713	076441	EMT162:	.WORD	EMS26,EMS27,EMS156,EMS160,0
117	067332	073515	076541	076067	EMT163:	.WORD	EMS47,EMS163,EMS140,0
118	067342	073515	072516	000000	EMT164:	.WORD	EMS47,EMS20,0
119	067350	073714	072516	000000	EMT165:	.WORD	EMS56,EMS20,0
120	067356	073466	072516	000000	EMT166:	.WORD	EMS46,EMS20,0
121	067364	100035	072516	000000	EMT167:	.WORD	EMS224,EMS20,0
122	067372	077273	076110	072724	EMT170:	.WORD	EMS203,EMS141,EMS30,EMS202,0
123	067404	076707	076405	076457	EMT171:	.WORD	EMS167,EMS154,EMS157,0
124	067414	076707	076405	076421	EMT172:	.WORD	EMS167,EMS154,EMS155,0
125	067424	076763	075631	075655	EMT173:	.WORD	EMS171,EMS132,EMS133,0
126	067434	076763	075631	075700	EMT174:	.WORD	EMS171,EMS132,EMS134,EMS123,0
127	067446	075017	077136	000000	EMT175:	.WORD	EMS113,EMS177,0
128	067454	077160	077175	000000	EMT176:	.WORD	EMS200,EMS201,0
129	067462	000000			EMT177:	.WORD	
130	067464	077273	073573	072724	EMT200:	.WORD	EMS203,EMS51,EMS30,EMS202,0
131	067476	077273	077306	072724	EMT201:	.WORD	EMS203,EMS204,EMS30,EMS202,0
132	067510	077273	073544	072724	EMT202:	.WORD	EMS203,EMS50,EMS30,EMS202,0
133	067522	077273	076153	072724	EMT203:	.WORD	EMS203,EMS143,EMS30,EMS202,0
134	067534	076274	074360	077243	EMT204:	.WORD	EMS150,EMS74,EMS202,EMS115,EMS152,EMS72,0
135	067552	073544	074567	074333	EMT205:	.WORD	EMS50,EMS103,EMS72,0
136	067562	074576	074343	077243	EMT206:	.WORD	EMS104,EMS73,EMS202,0
137	067572	074377	076110	075073	EMT207:	.WORD	EMS75,EMS141,EMS115,EMS140,0
138	067604	074377	076274	000000	EMT210:	.WORD	EMS75,EMS150,0
139	067612	073573	074333	075073	EMT211:	.WORD	EMS51,EMS72,EMS115,EMS50,EMS70,0
140	067626	076136	073631	075073	EMT212:	.WORD	EMS142,EMS53,EMS115,EMS143,EMS72,0
141	067642	073544	074567	073631	EMT213:	.WORD	EMS50,EMS103,EMS53,0
142	067652	073621	077334	076662	EMT214:	.WORD	EMS52,EMS205,EMS166,EMS206,EMS115,EMS51,EMS72,0
143	067672	073621	075126	073714	EMT215:	.WORD	EMS52,EMS117,EMS56,EMS163,0
144	067704	073714	072724	074125	EMT216:	.WORD	EMS56,EMS30,EMS64,0
145	067714	073466	072724	074125	EMT217:	.WORD	EMS46,EMS30,EMS64,0
146	067724	072734	072724	074125	EMT220:	.WORD	EMS31,EMS30,EMS64,0
147	067734	073515	072724	074125	EMT221:	.WORD	EMS47,EMS30,EMS64,0
148	067744	073621	075126	074436	EMT222:	.WORD	EMS52,EMS117,EMS77,0
149	067754	073621	075126	074077	EMT223:	.WORD	EMS52,EMS117,EMS63,0
150	067764	000000			EMT224:	.WORD	
151	067766	000000			EMT225:	.WORD	
152	067770	000000			EMT226:	.WORD	
153	067772	000000			EMT227:	.WORD	
154	067774	000000			EMT230:	.WORD	
155	067776	000000			EMT231:	.WORD	
156	070000	000000			EMT232:	.WORD	
157	070002	000000			EMT233:	.WORD	
158	070004	000000			EMT234:	.WORD	
159	070006	000000			EMT235:	.WORD	
160	070010	000000			EMT236:	.WORD	
161	070012	000000			EMT237:	.WORD	
162	070014	000000			EMT240:	.WORD	
163	070016	000000			EMT241:	.WORD	
164	070020	000000			EMT242:	.WORD	
165	070022	000000			EMT243:	.WORD	
166	070024	000000			EMT244:	.WORD	
167	070026	000000			EMT245:	.WORD	
168	070030	076707	075631	077373	EMT246:	.WORD	EMS167,EMS132,EMS207,0
169	070040	076707	075631	077420	EMT247:	.WORD	EMS167,EMS132,EMS210,EMS125,0
170	070052	076707	077431	077420	EMT250:	.WORD	EMS167,EMS211,EMS210,EMS207,EMS206,0
171	070066	077447	077472	000000	EMT251:	.WORD	EMS212,EMS213,0

172	070074	076646	077447	000000	EMT252: .WORD	EMS165,EMS212,0
173	070102	076257	076313	076441	EMT253: .WORD	EMS147,EMS151,EMS156,EMS210,EMS26,EMS27,0
174	070120	077273	074512	072724	EMT254: .WORD	EMS203,EMS101,EMS30,0
175	070130	077273	076707	072724	EMT255: .WORD	EMS203,EMS167,EMS30,0
176	070140	077273	074464	072724	EMT256: .WORD	EMS203,EMS100,EMS30,0
177	070150	072310	073466	072724	EMT257: .WORD	EMS11,EMS46,EMS30,EMS102,0
178	070162	073621	075126	073714	EMT260: .WORD	EMS52,EMS117,EMS56,EMS102,0
179	070174	073621	077334	077637	EMT261: .WORD	EMS52,EMS205,EMS220,EMS206,EMS115,EMS51,EMS72,0
180	070214	074576	074343	077243	EMT262: .WORD	EMS104,EMS73,EMS202,0
181	070224	073544	073631	074540	EMT263: .WORD	EMS50,EMS53,EMS102,0
182	070234	073714	073631	074540	EMT264: .WORD	EMS56,EMS53,EMS102,EMS115,EMS150,EMS152,EMS70,0
183	070254	074320	073714	074540	EMT265: .WORD	EMS71,EMS56,EMS102,EMS115,EMS150,EMS152,EMS72,0
184	070274	076136	076153	073631	EMT266: .WORD	EMS142,EMS143,EMS53,EMS102,0
185	070306	073544	076240	075073	EMT267: .WORD	EMS50,EMS146,EMS115,EMS52,EMS117,EMS46,0
186	070324	073515	073631	074540	EMT270: .WORD	EMS47,EMS53,EMS102,EMS115,EMS140,0
187	070340	073515	073631	074540	EMT271: .WORD	EMS47,EMS53,EMS102,EMS115,EMS141,EMS72,0
188	070356	074377	076110	074540	EMT272: .WORD	EMS75,EMS141,EMS102,EMS115,EMS47,EMS73,0
189	070374	073573	074360	074540	EMT273: .WORD	EMS51,EMS74,EMS102,EMS115,EMS50,EMS70,0
190	070412	074077	073631	073771	EMT274: .WORD	EMS63,EMS53,EMS57,EMS115,EMS41,EMS146,0
191	070430	075076	073631	073244	EMT275: .WORD	EMS116,EMS53,EMS41,EMS57,0
192	070442	073515	073631	073771	EMT276: .WORD	EMS47,EMS53,EMS57,EMS115,EMS140,0
193	070456	073515	073631	073771	EMT277: .WORD	EMS47,EMS53,EMS57,EMS115,EMS141,EMS72,0
194	070474	073714	073631	073771	EMT300: .WORD	EMS56,EMS53,EMS57,EMS115,EMS150,EMS152,EMS70,0
195	070514	074320	073714	073631	EMT301: .WORD	EMS71,EMS56,EMS53,EMS57,EMS115,EMS150,EMS152,EMS72,0
196	070536	076646	074464	074567	EMT302: .WORD	EMS165,EMS100,EMS103,EMS57,0
197	070550	076646	074512	074567	EMT303: .WORD	EMS165,EMS101,EMS103,EMS57,0
198	070562	076646	074436	074567	EMT304: .WORD	EMS165,EMS77,EMS103,EMS57,0
199	070574	073466	072724	074125	EMT305: .WORD	EMS46,EMS30,EMS64,EMS57,0
200	070606	073544	073631	073771	EMT306: .WORD	EMS50,EMS53,EMS57,0
201	070616	073544	076240	075073	EMT307: .WORD	EMS50,EMS146,EMS115,EMS52,EMS117,EMS46,EMS57,0
202	070636	076136	076153	073631	EMT310: .WORD	EMS142,EMS143,EMS53,EMS57,0
203	070650	074576	074567	073631	EMT311: .WORD	EMS104,EMS103,EMS53,EMS57,0
204	070662	074625	074567	073631	EMT312: .WORD	EMS105,EMS103,EMS53,EMS57,0
205	070674	076201	076211	074567	EMT313: .WORD	EMS144,EMS145,EMS103,EMS57,EMS115,EMS143,EMS70,0
206	070714	073272	074567	073631	EMT314: .WORD	EMS42,EMS103,EMS53,EMS57,0
207	070726	072734	074567	073631	EMT315: .WORD	EMS31,EMS103,EMS53,EMS57,0
208	070740	074320	072734	074567	EMT316: .WORD	EMS71,EMS31,EMS103,EMS57,0
209	070752	073321	074567	073771	EMT317: .WORD	EMS43,EMS103,EMS57,0
210	070762	073423	074567	073771	EMT320: .WORD	EMS45,EMS103,EMS57,0
211	070772	073350	074567	073771	EMT321: .WORD	EMS44,EMS103,EMS57,0
212	071002	074654	072516	000000	EMT322: .WORD	EMS106,EMS20,0
213	071010	073140	074567	073771	EMT323: .WORD	EMS36,EMS103,EMS57,0
214	071020	077036	073140	074567	EMT324: .WORD	EMS173,EMS36,EMS103,EMS57,0
215	071032	077016	073140	074567	EMT325: .WORD	EMS172,EMS36,EMS103,EMS57,0
216	071044	072362	077053	072404	EMT326: .WORD	EMS13,EMS174,EMS15,EMS35,EMS53,EMS175,0
217	071062	076257	076313	074360	EMT327: .WORD	EMS147,EMS151,EMS74,EMS175,0
218	071074	074211	073631	077061	EMT330: .WORD	EMS66,EMS53,EMS175,0
219	071104	073012	074567	073631	EMT331: .WORD	EMS33,EMS103,EMS53,EMS175,0
220	071116	073215	074567	073631	EMT332: .WORD	EMS40,EMS103,EMS53,EMS57,0
221	071130	073573	074360	073771	EMT333: .WORD	EMS51,EMS74,EMS57,EMS115,EMS50,EMS70,0
222	071146	074377	076110	073771	EMT334: .WORD	EMS75,EMS141,EMS57,EMS115,EMS47,EMS73,0
223	071164	074377	076274	076337	EMT335: .WORD	EMS75,EMS150,EMS152,EMS57,EMS115,EMS56,EMS73,0
224	071204	074017	074032	074061	EMT336: .WORD	EMS60,EMS61,EMS62,0
225	071214	075076	075126	073040	EMT337: .WORD	EMS116,EMS117,EMS34,0
226	071224	073040	073631	073643	EMT340: .WORD	EMS34,EMS53,EMS54,EMS111,0
227	071236	073665	073040	000000	EMT341: .WORD	EMS55,EMS34,0
228	071244	073621	075126	073714	EMT342: .WORD	EMS52,EMS117,EMS56,EMS57,0

229	071256	073621	075126	073423	EMT343: .WORD	EMS52,EMS117,EMS45,EMS57,0
230	071270	073621	075126	073350	EMT344: .WORD	EMS52,EMS117,EMS44,EMS57,0
231	071302	073621	075126	077657	EMT345: .WORD	EMS52,EMS117,EMS221,0
232	071312	074654	072516	075073	EMT346: .WORD	EMS106,EMS20,EMS115,EMS223,EMS72,0
233	071326	073621	077334	077727	EMT347: .WORD	EMS52,EMS205,EMS222,EMS206,0
234	071340	074377	076274	074540	EMT350: .WORD	EMS75,EMS150,EMS102,EMS115,EMS56,EMS73,0
235	071356	076707	074343	074540	EMT351: .WORD	EMS167,EMS73,EMS102,0
236	071366	077533	000000		EMT352: .WORD	EMS215,0
237	071372	077604	077273	077554	EMT353: .WORD	EMS217,EMS203,EMS216,0
238	071402	077657	072516	000000	EMT354: .WORD	EMS221,EMS20,0

1	071410	100107	100713	100770	EHT1: .WORD	EH1,STSH1,STSH2,STSH4,0
2	071422	100713	100770	101115	EHT2: .WORD	STSH1,STSH2,STSH4,0
3						
4	071432	100126	000000		EHT110: .WORD	EH110,0
5	071436	100135	000000		EHT111: .WORD	EH111,0
6						
7	071442	100154	000000		EHT114: .WORD	EH114,0
8	071446	100203	100713	100770	EHT223: .WORD	EH223,STSH1,STSH2,STSH4,0
9	071460	100231	100713	100770	EHT256: .WORD	EH256,STSH1,STSH2,STSH4,0
10						
11	071472	100305	100713	100770	EHT336: .WORD	EH336,STSH1,STSH2,STSH4,0
12	071504	100344	100713	100770	EHT337: .WORD	EH337,STSH1,STSH2,STSH4,0
13	071516	100501	100713	100770	EHT344: .WORD	EH344,STSH1,STSH2,STSH4,0
14						
15	071530	100637	000000		EHT353: .WORD	EH353,0

1	071534	101154	101250	101266	EDT1:	.WORD	ED1,STSD1,STSD2,STSD4
2	071544	101250	101266	101320	EDT2:	.WORD	STSD1,STSD2,STSD4
3							
4	071552	101162			EDT110:	.WORD	ED110
5	071554	101166			EDT111:	.WORD	ED111
6							
7	071556	101174			EDT114:	.WORD	ED114
8	071560	101204	101250	101266	EDT223:	.WORD	ED223,STSD1,STSD2,STSD4
9							
10	071570	101214	101250	101266	EDT336:	.WORD	ED336,STSD1,STSD2,STSD4
11	071600	101226	101250	101266	EDT337:	.WORD	ED337,STSD1,STSD2,STSD4
12	071610	101226	101250	101266	EDT344:	.WORD	ED337,STSD1,STSD2,STSD4,0
13							
14	071622	101240			EDT353:	.WORD	ED353

1	071624	101333	101351	101351	EFT1:	.WORD	EF111,STSF,STSF,STSF
2	071634	101351	101351	101351	EFT2:	.WORD	STSF,STSF,STSF
3							
4	071642	101332			EFT110:	.WORD	EF110
5	071644	101333			EFT111:	.WORD	EF111
6							
7	071646	101335			EFT114:	.WORD	EF114
8	071650	101335	101351	101351	EFT223:	.WORD	EF114,STSF,STSF,STSF
9							
10	071660	101340	101351	101351	EFT336:	.WORD	EF336,STSF,STSF,STSF
11	071670	101340	101351	101351	EFT337:	.WORD	EF336,STSF,STSF,STSF
12	071700	101340	101351	101351	EFT344:	.WORD	EF336,STSF,STSF,STSF
13							
14	071710	101335			EFT353:	.WORD	EF114

	.SBTTL			ERROR MESSAGE STRINGS
1				
2				
3	071712	127	122	117 EMS1: .ASCIZ @WRONG UNIT SELECTED (RMCS2, BITS 0-2) @
4	071761	104	105	126 EMS2: .ASCIZ @DEVICE WENT @
5	071776	125	116	101 EMS3: .ASCIZ @UNAVAILABLE 'DVA' (RMCS1, BIT 11) @
6	072041	116	117	116 EMS4: .ASCIZ @NONEXISTENT 'NED' (RMCS2, BIT 12) @
7	072104	103	117	115 EMS5: .ASCIZ @COMMAND NOT COMPLETED, @
8	072134	103	117	116 EMS6: .ASCIZ @CONTROLLER NOT READY (RMCS1, BIT 7) @
9	072201	104	122	111 EMS7: .ASCIZ @DRIVE NOT READY 'DRY' (RMDS, BIT 7) @
10	072246	107	117	040 EMS10: .ASCIZ @GO NOT RESET 'GO' (RMCS1, BIT 0) @
11	072310	111	116	126 EMS11: .ASCIZ @INVALID @
12	072321	106	125	116 EMS12: .ASCIZ @FUNCTION CODE (RMCS1, BITS 1-5) @
13	072362	115	101	123 EMS13: .ASCIZ @MASSBUS @
14	072373	103	117	116 EMS14: .ASCIZ @CONTROL @
15	072404	102	125	123 EMS15: .ASCIZ @BUS PARITY ERROR @
16	072426	042	115	103 EMS16: .ASCIZ @'MCPE' (RMCS1, BIT 13) @
17	072456	124	122	101 EMS17: .ASCIZ @TRANSFER ERROR (RMCS1, BIT 14) @
18	072516	123	110	117 EMS20: .ASCIZ @SHOULD NOT BE SET @
19	072541	127	117	122 EMS21: .ASCIZ @WORD COUNT (RMWC) @
20	072564	102	125	123 EMS22: .ASCIZ @BUS (RMBA) @
21	072600	042	114	102 EMS23: .ASCIZ @'LBT' (RMDS, BIT 10) @
22	072626	042	101	117 EMS24: .ASCIZ @'AOE' (RMER1, BIT 09) @
23	072655	104	111	123 EMS25: .ASCIZ @DISK (RMDA) @
24	072672	103	131	114 EMS26: .ASCIZ @CYLINDER (RMDC) @
25	072713	101	104	104 EMS27: .ASCIZ @ADDRESS @
26	072724	123	124	101 EMS30: .ASCIZ @STATUS @
27	072734	042	127	114 EMS31: .ASCIZ @'WLE' (RMER1, BIT 11) @
28	072763	042	125	120 EMS32: .ASCIZ @'UPE' (RMCS2, BIT 13) @
29	073012	042	127	103 EMS33: .ASCIZ @'WCF' (RMER1, BIT 5) @
30	073040	127	122	111 EMS34: .ASCIZ @WRITE CHECK ERROR-'WCE' (RMCS2, BIT 14) @
31	073111	042	115	104 EMS35: .ASCIZ @'MDPE' (RMCS2, BIT 8) @
32	073140	042	104	103 EMS36: .ASCIZ @'DCK' (RMER1, BIT 15) @
33	073167	042	105	103 EMS37: .ASCIZ @'ECH' (RMER1, BIT 6) @
34	073215	042	104	114 EMS40: .ASCIZ @'DLT' (RMCS2, BIT 15) @
35	073244	042	115	130 EMS41: .ASCIZ @'MXF' (RMCS2, BIT 9) @
36	073272	042	104	124 EMS42: .ASCIZ @'DTE' (RMER1, BIT 12) @
37	073321	042	110	103 EMS43: .ASCIZ @'HCRC' (RMER1, BIT 8) @
38	073350	110	105	101 EMS44: .ASCIZ @HEADER COMPARE ERROR 'HCE' (RMER1, BIT 7) @
39	073423	106	117	122 EMS45: .ASCIZ @FORMAT ERROR 'FER' (RMER1, BIT 4) @
40	073466	042	111	101 EMS46: .ASCIZ @'IAE' (RMER1, BIT 10) @
41	073515	042	117	120 EMS47: .ASCIZ @'DPI' (RMER1, BIT 13) @
42	073544	042	123	113 EMS50: .ASCIZ @'SKI' (RMER2, BIT 14) @
43	073573	042	120	111 EMS51: .ASCIZ @'PIP' (RMDS, BIT 13) @
44	073621	124	110	105 EMS52: .ASCIZ @THE RM @
45	073631	104	105	124 EMS53: .ASCIZ @DETECTED @
46	073643	101	124	040 EMS54: .ASCIZ @AT AN UNEXPECTED @
47	073665	111	116	103 EMS55: .ASCIZ @INCORRECT DATA DURING @
48	073714	111	116	126 EMS56: .ASCIZ @INVALID COMMAND ERROR 'IVC' (RMER2, BIT 12) @
49	073771	104	125	122 EMS57: .ASCIZ @DURING DATA TRANSFER @
50	074017	104	101	124 EMS60: .ASCIZ @DATA READ @
51	074032	104	117	105 EMS61: .ASCIZ @DOES NOT COMPARE WITH @
52	074061	104	101	124 EMS62: .ASCIZ @DATA WRITTEN @
53	074077	042	120	101 EMS63: .ASCIZ @'PAR' (RMER1, BIT 3) @
54	074125	111	123	040 EMS64: .ASCIZ @IS INCORRECT @
55	074143	103	117	115 EMS65: .ASCIZ @COMPOSITE ERROR 'ERR' (RMDS, BIT 14) @
56	074211	104	101	124 EMS66: .ASCIZ @DATA PARITY ERROR 'DPE' (RMER2, BIT 3) @
57	074261	104	125	122 EMS67: .ASCIZ @DURING SEEK COMMAND @

58	074306	111	123	040	EMS70:	.ASCIZ	@IS RESET @
59	074320	105	122	122	EMS71:	.ASCIZ	@ERRONEOUS @
60	074333	111	123	040	EMS72:	.ASCIZ	@IS SET @
61	074343	104	111	104	EMS73:	.ASCIZ	@DID NOT SET @
62	074360	104	111	104	EMS74:	.ASCIZ	@DID NOT RESET @
63	074377	114	117	123	EMS75:	.ASCIZ	@LOST @
64	074405	104	125	122	EMS76:	.ASCIZ	@DURING PACK ACK COMMAND @
65	074436	042	122	115	EMS77:	.ASCIZ	@'RMR' (RMER1, BIT 2) @
66	074464	042	111	114	EMS100:	.ASCIZ	@'ILR' (RMER1, BIT 1) @
67	074512	042	111	114	EMS101:	.ASCIZ	@'ILF' (RMER1, BIT 0) @
68	074540	104	125	122	EMS102:	.ASCIZ	@DURING SEARCH COMMAND @
69	074567	105	122	122	EMS103:	.ASCIZ	@ERROR @
70	074576	042	114	102	EMS104:	.ASCIZ	@'LBC' (RMER2, BIT 10) @
71	074625	042	114	123	EMS105:	.ASCIZ	@'LSC' (RMER2, BIT 11) @
72	074654	110	105	101	EMS106:	.ASCIZ	@HEADER ERRORS @
73	074673	102	125	123	EMS110:	.ASCIZ	@BUS TIMEOUT (04 TRAP) @
74	074722	101	104	104	EMS111:	.ASCIZ	@ADDRESS @
75	074733	127	110	105	EMS112:	.ASCIZ	@WHEN READING/WRITING RH REGISTERS @
76	074775	101	124	040		.ASCIZ	@AT THE FOLLOWING @
77	075017	124	110	105	EMS113:	.ASCIZ	@THE SELECTED DEVICE IS @
78	075047	116	117	116	EMS114:	.ASCIZ	@NONEXISTENT DEVICE @
79	075073	015	012	000	EMS115:	.ASCIZ	<CR><LF>
80	075076	124	110	105	EMS116:	.ASCIZ	@THE MASSBUS CONTROLLER @
81	075126	106	101	111	EMS117:	.ASCIZ	@FAILED TO DETECT @
82	075150	116	117	124	EMS120:	.ASCIZ	@NOT AN RM05/3/2 @
83	075171	103	117	116	EMS121:	.ASCIZ	@CONTROL STATUS REGISTER 1, RMCS1, @
84	075234	102	125	123	EMS122:	.ASCIZ	@BUS ADDRESS REGISTER, RMBA, @
85	075271	103	117	116	EMS123:	.ASCIZ	@CONTROL STATUS REGISTER 2, RMCS2, @
86	075334	105	122	122	EMS124:	.ASCIZ	@ERROR REGISTER 1, RMER1, @
87	075366	101	124	124	EMS125:	.ASCIZ	@ATTENTION SUMMARY REGISTER, RMAS, @
88	075431	115	101	111	EMS126:	.ASCIZ	@MAINTENANCE REGISTER #1, RMMR #1, @
89	075474	105	103	103	EMS127:	.ASCIZ	@ECC POSITION REGISTER, RMEC1, @
90	075533	105	103	103	EMS130:	.ASCIZ	@ECC PATTERN REGISTER, RMEC2, @
91	075571	115	101	111	EMS131:	.ASCIZ	@MAINTENANCE REGISTER 2, RMMR2, @
92	075631	116	117	124	EMS132:	.ASCIZ	@NOT INITIALIZED BY @
93	075655	125	116	111	EMS133:	.ASCIZ	@UNIBUS INITIALIZE @
94	075700	103	117	116	EMS134:	.ASCIZ	@CONTROLLER CLEAR, I.E. BIT 5 OF @
95	075742	122	110	057	EMS135:	.ASCIZ	@RH/RM ERROR CLEAR (RMCS1, BIT 14) @
96	076005	104	122	111	EMS136:	.ASCIZ	@DRIVE CLEAR COMMAND @
97	076032	104	122	111	EMS137:	.ASCIZ	@DRIVE STATUS REGISTER, RMDS @
98	076067	115	105	104	EMS140:	.ASCIZ	@MEDIUM OFF LINE @
99	076110	042	115	117	EMS141:	.ASCIZ	@'MOL' (RMDS, BIT 12) @
100	076136	104	122	111	EMS142:	.ASCIZ	@DRIVE FAULT @
101	076153	042	104	126	EMS143:	.ASCIZ	@'DVC' (RMER2, BIT 7) @
102	076201	125	116	123	EMS144:	.ASCIZ	@UNSAFE @
103	076211	042	125	116	EMS145:	.ASCIZ	@'UNS' (RMER1, BIT 14) @
104	076240	123	110	117	EMS146:	.ASCIZ	@SHOULD BE SET @
105	076257	117	106	106	EMS147:	.ASCIZ	@OFFSET MODE @
106	076274	040	126	117	EMS150:	.ASCIZ	@ VOLUME VALID @
107	076313	042	117	115	EMS151:	.ASCIZ	@'OM' (RMDS, BIT 0) @
108	076337	042	126	126	EMS152:	.ASCIZ	@'VV' (RMDS, BIT 6) @
109	076363	120	101	103	EMS153:	.ASCIZ	@PACK ACK COMMAND @
110	076405	116	117	124	EMS154:	.ASCIZ	@NOT SET BY @
111	076421	117	106	106	EMS155:	.ASCIZ	@OFFSET COMMAND @
112	076441	116	117	124	EMS156:	.ASCIZ	@NOT RESET BY @
113	076457	122	124	103	EMS157:	.ASCIZ	@RTC COMMAND @
114	076474	122	111	120	EMS160:	.ASCIZ	@RIP COMMAND @

115	076511	117	106	106	EMS161: .ASCIZ @OFFSET REGISTER (RMOF) @
116	076541				EMS162: ;<UNUSED>
117	076541	104	125	122	EMS163: .ASCIZ @DURING RECALIBRATE @
118	076565	111	123	040	EMS164: .ASCII @IS INTERMITTENT OR DRIVE DIDNT DROP ON @
119	076634	103	131	114	.ASCIZ @CYLINDER @
120	076646	125	116	105	EMS165: .ASCIZ @UNEXPECTED @
121	076662	122	105	103	EMS166: .ASCIZ @RECALIBRATE COMMAND @
122	076707	042	101	124	EMS167: .ASCIZ @'ATA' (RMDS, BIT15) @
123	076734	127	110	105	EMS170: .ASCIZ @WHEN READING REGISTER @
124	076763	105	122	122	EMS171: .ASCIZ @ERROR REGISTER #2, RMER2, @
125	077016	116	117	116	EMS172: .ASCIZ @NONRECOVERABLE @
126	077036	122	105	103	EMS173: .ASCIZ @RECOVERABLE @
127	077053	104	101	124	EMS174: .ASCIZ @DATA @
128	077061	104	125	122	EMS175: .ASCIZ @DURING WRITE COMMAND @
129	077107	042	117	120	EMS176: .ASCIZ @'OPE' (RMER2, BIT 13) @
130	077136	111	116	040	EMS177: .ASCIZ @IN WRITE PROTECT @
131	077160	103	101	116	EMS200: .ASCIZ @CAN NOT SET @
132	077175	104	111	101	EMS201: .ASCIZ @DIAGNOSTIC MODE 'DMD' (RMMR1, BIT 0) @
133	077243	104	125	122	EMS202: .ASCIZ @DURING DIAGNOSTIC MODE @
134	077273	111	116	103	EMS203: .ASCIZ @INCORRECT @
135	077306	042	127	122	EMS204: .ASCIZ @'WRL' (RMDS, BIT 11) @
136	077334	105	130	105	EMS205: .ASCIZ @EXECUTED @
137	077346	127	111	124	EMS206: .ASCIZ @WITH COMP ERROR SET @
138	077373	042	107	117	EMS207: .ASCIZ @'GO' (RMCS1, BIT 0) @
139	077420	127	122	111	EMS210: .ASCIZ @WRITING @
140	077431	127	101	123	EMS211: .ASCIZ @WAS RESET BY @
141	077447	120	122	117	EMS212: .ASCIZ @PROGRAM INTERRUPT @
142	077472	127	101	123	EMS213: .ASCIZ @WAS NOT GENERATED @
143	077515	123	105	105	EMS214: .ASCIZ @SEEK COMMAND @
144	077533	120	122	117	EMS215: .ASCIZ @PROGRAM TIMEOUT @
145	077554	104	125	122	EMS216: .ASCIZ @DURING LOOK AHEAD TEST @
146	077604	114	117	117	EMS217: .ASCIZ @LOOK AHEAD REGISTER, RMLA, @
147	077637	123	105	101	EMS220: .ASCIZ @SEARCH COMMAND @
148	077657	102	101	104	EMS221: .ASCIZ @BAD SECTOR ERROR 'BSE' (RMER2, BIT 15) @
149	077727	101	040	104	EMS222: .ASCIZ @A DATA TRANSFER COMMAND @
150	077760	110	105	101	EMS223: .ASCIZ @HEADER COMPARE INHIBIT 'HCI' (RMOF, BIT 10) @
151	100035	116	117	116	EMS224: .ASCIZ @NONEXISTENT MEMORY 'NEM' (RMCS2, BIT 11) @

1	100107	105	130	120	EH1:	.ASCIZ	@EXPCTD	RECEVD@			
2	100126	102	125	123	EH110:	.ASCIZ	@BUSADRA				
3	100135	040	122	115	EH111:	.ASCIZ	@ RMCS2	RMCS1@			
4											
5	100154	122	105	103	EH114:	.ASCIZ	@RECEVD	SNGPRT	DULPRT@		
6	100203	105	130	120	EH223:	.ASCIZ	@EXPCTD	RECEVD	DATA@		
7	100231	105	130	120	EH256:	.ASCII	@EXPCTD	RECEVD	RGSTR@<CRLF>		
8	100257	123	124	101		.ASCIZ	@STATUS	STATUS	INDEX@		
9											
10	100305	107	104	101	EH336:	.ASCIZ	@GDADRS	GDDATA	BDADRS	BDDATA@	
11	100344	122	115	103	EH337:	.ASCII	@RMCS2	STATUS	FAILING	DATA@<CRLF>	
12	100403	137	137	137		.ASCII	@			@<CRLF>	
13	100442	105	130	120		.ASCIZ	@EXPCTD	RECEVD	--BIT--	ADDRESS@	
14											
15	100501	122	115	105	EH344:	.ASCII	@RMER1	STATUS	HEADER	FAILING@<CRLF>	
16	100541	137	137	137		.ASCII	@		WORD	BIT@<CRLF>	
17	100577	105	130	120		.ASCIZ	@EXPCTD	RECEVD	NUMBER	POSITON@	
18	100637	105	130	120	EH353:	.ASCII	@EXPCTD	RECEVD@<CRLF>			
19	100656	074	103	122		.ASCIZ	@<CRLF>	RMLA	RMLA	RMOF @	
20											
21	100713	040	122	115	STSH1:	.ASCII	@ RMCS1	RMCS2	RMDS	RMER1	RMER2@
22	100760	040	040	040		.ASCIZ	@	RMAS@			
23	100770	040	122	115	STSH2:	.ASCII	@ RMWC	RMBA	RMDA	RMOF	RMDCA
24	101035	040	040	040		.ASCIZ	@	RMEC1	RMEC2@		
25	101057	040	122	115	STSH3:	.ASCIZ	@ RMDA	RMDC	RMOF	RMLA@	
26	101115	040	122	115	STSH4:	.ASCIZ	@ RMMR1	RMMR2	RMDT	RMSN@	
27						.EVEN					

1	101154	001140	001142	000000	ED1:	.WORD	\$GDDAT,\$BDDAT,0
2	101162	001276	000000		ED110:	.WORD	\$BASE,0
3	101166	001174	001176	000000	ED111:	.WORD	\$TMP0,\$TMP1,0
4							
5	101174	001364	001176	001200	ED114:	.WORD	RMDTI,\$TMP1,\$TMP2,0
6	101204	001140	001142	001174	ED223:	.WORD	\$GDDAT,\$BDDAT,\$TMP0,0
7							
8	101214	001134	001140	001136	ED336:	.WORD	\$GDADR,\$GDDAT,\$BDADR,\$BDDAT,0
9							
10	101226	001140	001142	001174	ED337:	.WORD	\$GDDAT,\$BDDAT,\$TMP0,\$TMP1,0
11	101240	001140	001142	001444	ED353:	.WORD	\$GDDAT,\$BDDAT,RMOFO,0
12							
13	101250	001336	001346	001350	STSD1:	.WORD	RMCS1I, RMCS2I, RMDSI, RMER1I, RMER2I, RMASI, 0
14	101266	001340	001342	001344	STSD2:	.WORD	RMWCI, RMBAI, RMDAI, RMOFI, RMDCI, RMECI
15	101302	001404	000000			.WORD	RMEC2I, 0
16	101306	001344	001372	001370	STSD3:	.WORD	RMDAI, RMDCI, RMOFI, RMLAI, 0
17	101320	001362	001376	001364	STSD4:	.WORD	RMMR1I, RMMR2I, RMDTI, RMSNI, 0

ERROR MESSAGE STRINGS

1	101332	000			EF110:	.BYTE	0
2	101333	000	000		EF111:	.BYTE	0,0
3	101335	000	000	000	EF114:	.BYTE	0,0,0
4	101340	000	000	000	EF336:	.BYTE	0,0,0,0
5	101344	000	000	000	EF337:	.BYTE	0,0,0,0,0
6							
7	101351	000	000	000	STSF:	.BYTE	0,0,0,0,0,0,0
8					.EVEN		

```

1          ;STORAGE FOR GENERAL DATA TRANSFERRS
2 101360  BUFFER:
3 101360  BUFOONE: .BLKW 258.
4 102364  BUFTWO: .BLKW 258.
5
6          ;STORAGE FOR MANUFACTURES 16 BIT MODE BAD SECTOR FILE
7 103370 000000 000000  MFGFIL: .WORD 0,0          ;2 HEADER WORDS
8 103374          .BLKW 256.          ;256. WORDS OF DATA
9 104374 177777          .WORD -1          ;TERMINATOR IF FILE IS FULL
10
11         ;STORAGE FOR USERS 16 BIT MODE BAD SECTOR FILE
12 104376 000000 000000  USRFIL: .WORD 0,0          ;2 HEADER WORDS
13 104402          .BLKW 256.          ;256. WORDS OF DATA
14 105402 177777          .WORD -1          ;TERMINATOR IF FILE IS FULL
15
16         .=BUFFER
17
18 101360  HELP:
19 101360 200  .ASCII <CRLF>
20 101361 200  .ASCII <CRLF>
21 101362 114 111 123 .ASCII @LIST OF TESTS@<CRLF>
22 101400 055 055 055 .ASCII @-----@<CRLF>
23 101416 124 061 011 .ASCII @T1 CONTROLLER ACCESS TEST@<CRLF>
24 101450 124 062 011 .ASCII @T2 FORMAT ZEROS@<CRLF>
25 101470 124 063 011 .ASCII @T3 ZERO FILL TEST@<CRLF>
26 101512 124 064 011 .ASCII @T4 FORMAT CHECK ZEROS@<CRLF>
27 101540 124 065 011 .ASCII @T5 FORMAT CHECK ZEROS W/ WCE ERROR@<CRLF>
28 101603 124 066 011 .ASCII @T6 FORMAT ONES@<CRLF>
29 101622 124 067 011 .ASCII @T7 FORMAT CHECK ONES@<CRLF>
30 101647 124 061 060 .ASCII @T10 FORMAT CHECK ONES W/ WCE ERRORS@<CRLF>
31 101713 124 061 061 .ASCII @T11 FORMAT MULTIPLE SECTORS@<CRLF>
32 101747 124 061 062 .ASCII @T12 FORMAT W/ HEAD SWITCHING@<CRLF>
33 102004 124 061 063 .ASCII @T13 FORMAT W/ MID TRANSFER SEEK@<CRLF>
34 102044 124 061 064 .ASCII @T14 FORMAT W/ IMPLIED SEEK@<CRLF>
35 102077 124 061 065 .ASCII @T15 FORMAT EACH SECTOR ADDRESS@<CRLF>
36 102136 124 061 066 .ASCII @T16 FORMAT EACH TRACK ADDRESS@<CRLF>
37 102174 124 061 067 .ASCII @T17 FORMAT PRIME CYLINDERS@<CRLF>
38 102227 124 062 060 .ASCII @T20 READ HEADER & DATA IN LAST SECTOR@<CRLF>
39 102275 124 062 061 .ASCII @T21 READ HEADER & DATA W/ AOE ERROR@<CRLF>
40 102341 124 062 062 .ASCII @T22 READ INVALID SECTOR ADDRESS@<CRLF>
41 102401 124 062 063 .ASCII @T23 READ INVALID TRACK ADDRESS@<CRLF>
42 102440 124 062 064 .ASCII @T24 READ INVALID CYLINDER ADDRESS@<CRLF>
43 102502 124 062 065 .ASCII @T25 FORMAT AT OFFSET@<CRLF>
44 102527 124 062 066 .ASCII @T26 IVC FORMAT TEST@<CRLF>
45 102553 124 062 067 .ASCII @T27 FORMAT ERROR TEST@<CRLF>
46 102601 124 063 060 .ASCII @T30 FORMAT HCE, FIRST HEADER WORD@<CRLF>
47 102643 124 063 061 .ASCII @T31 FORMAT HCE, SECOND HEADER WORD@<CRLF>
48 102706 200  .ASCII <CRLF>
49 102707 117 120 105 .ASCII @OPERATIONAL SWITCH SETTINGS@<CRLF>
50 102743 055 055 055 .ASCII @-----@<CRLF>
51 102777 123 127 111 .ASCII @SWITCH USE@<CRLF>
52 103014 055 055 055 .ASCII @-----@<CRLF>
53 103051 040 040 061 .ASCII @ 15 HALT ON ERROR@<CRLF>
54 103075 040 040 061 .ASCII @ 14 LOOP ON TEST@<CRLF>
55 103120 040 040 061 .ASCII @ 13 INHIBIT ERROR TYPEOUTS@<CRLF>
56 103155 040 040 061 .ASCII @ 12 @<CRLF>
57 103164 040 040 061 .ASCII @ 11 INHIBIT ITERATIONS@<CRLF>

```


58	103215	040	040	061	.ASCII	@	10	BELL ON ERROR@<CRLF>
59	103241	040	040	040	.ASCII	@	9	LOOP ON ERROR@<CRLF>
60	103265	040	040	040	.ASCII	@	8	LOOP ON TEST IN SWR<7:0>@<CRLF>
61	103324	040	040	040	.ASCII	@	7	TN128@<CRLF>
62	103340	040	040	040	.ASCII	@	6	TN64@<CRLF>
63	103353	040	040	040	.ASCII	@	5	TN32@<CRLF>
64	103366	040	040	040	.ASCII	@	4	TN16@<CRLF>
65	103401	040	040	040	.ASCII	@	3	TN8@<CRLF>
66	103413	040	040	040	.ASCII	@	2	TN4@<CRLF>
67	103425	040	040	040	.ASCII	@	1	TN2@<CRLF>
68	103437	040	040	040	.ASCIIZ	@	0	TN1@<CRLF>
69								
70	000200			.END			200	

ABASE = 176700	ATNMSK= 000377	BUFONE 101360	EBL = 020000	EH344 100501
ACDW1 = 000000	ATNTBL 064666	BUFTWO 102364	ECH = 000100	EH353 100637
ACDW2 = 000000	AUNIT = 000000	CC = 004000	ECI = 004000	EMS1 071712
ACKSTS 046342	AUSWR = 000000	CH = 002000	ECRC = 001000	EMS10 072246
ACPUOP= 000000	AVECT1= 120254	CHGADR 001330	EDT1 071534	EMS100 074464
ADDW0 = 000000	AVECT2= 000000	CHRCNT 061027	EDT110 071552	EMS101 074512
ADDW1 = 000000	A16 = 000400	CKSWR = 104410	EDT111 071554	EMS102 074540
ADDW10= 000000	A17 = 001000	CLKADR 001520	EDT114 071556	EMS103 074567
ADDW11= 000000	BACK = 000000	CLKVCT 001522	EDT2 071544	EMS104 074576
ADDW12= 000000	BADSCT 033152	CLR = 000040	EDT223 071560	EMS105 074625
ADDW13= 000000	BADTMO 005342	CLRSTS 045462	EDT336 071570	EMS106 074654
ADDW14= 000000	BAI = 000010	CMNSTA 007476	EDT337 071600	EMS11 072310
ADDW15= 000000	BB00 = 000001	CMPBUF 035342	EDT344 071610	EMS110 074673
ADDW2 = 000000	BB01 = 000002	CMPERR 043460	EDT353 071622	EMS111 074722
ADDW3 = 000000	BB02 = 000004	CNSL01 064025	ED1 101154	EMS112 074733
ADDW4 = 000000	BB03 = 000010	CNSL02 064035	ED110 101162	EMS113 075017
ADDW5 = 000000	BB04 = 000020	CNSL03 064077	ED111 101166	EMS114 075047
ADDW6 = 000000	BB05 = 000040	CNSL04 064106	ED114 101174	EMS115 075073
ADDW7 = 000000	BB06 = 000100	CNSL07 064142	ED223 101204	EMS116 075076
ADDW8 = 000000	BB07 = 000200	CNSL08 064304	ED336 101214	EMS117 075126
ADDW9 = 000000	BB08 = 000400	CNSL09 064305	ED337 101226	EMS12 072321
ADEVCT= 000000	BB09 = 001000	CNTCLR 045344	ED353 101240	EMS120 075150
ADEVN = 000000	BIT0 = 000001	COMMA 063445	EECC = 000020	EMS121 075171
ADR = 000001	BIT00 = 000001	CONT = 000100	EFT1 071624	EMS122 075234
AENV = 000000	BIT01 = 000002	CPSAVE 060150	EFT110 071642	EMS123 075271
AENVN = 000000	BIT02 = 000004	CR = 000015	EFT111 071644	EMS124 075334
AFATAL= 000000	BIT03 = 000010	CRLF = 000200	EFT114 071646	EMS125 075366
ALL 063434	BIT04 = 000020	CTLFG 001326	EFT2 071634	EMS126 075431
AMADR1= 000000	BIT05 = 000040	CYLMSK= 001777	EFT223 071650	EMS127 075474
AMADR2= 000000	BIT06 = 000100	DBCK = 100000	EFT336 071660	EMS13 072362
AMADR3= 000000	BIT07 = 000200	DBEN = 040000	EFT337 071670	EMS130 075533
AMADR4= 000000	BIT08 = 000400	DBL = 002000	EFT344 071700	EMS131 075571
AMAMS1= 000000	BIT09 = 001000	DCK = 100000	EFT353 071710	EMS132 075631
AMAMS2= 000000	BIT1 = 000002	DDISP = 177570	EF110 101332	EMS133 075655
AMAMS3= 000000	BIT10 = 002000	DEBL = 020000	EF111 101333	EMS134 075700
AMAMS4= 000000	BIT11 = 004000	DEVSEL 043672	EF114 101335	EMS135 075742
AMSGAD= 000000	BIT12 = 010000	DISPLA 001156	EF336 101340	EMS136 076005
AMSGLG= 000000	BIT13 = 020000	DISPRE 000174	EF337 101344	EMS137 076032
AMSGTY= 000000	BIT14 = 040000	DLT = 100000	EHT1 071410	EMS14 072373
AMTYP1= 000000	BIT15 = 100000	DMD = 000001	EHT110 071432	EMS140 076067
AMTYP2= 000000	BIT2 = 000004	DPE = 000010	EHT111 071436	EMS141 076110
AMTYP3= 000000	BIT3 = 000010	DPEHI = 040000	EHT114 071442	EMS142 076136
AMTYP4= 000000	BIT4 = 000020	DPELO = 020000	EHT2 071422	EMS143 076153
AOE = 001000	BIT5 = 000040	DPR = 000400	EHT223 071446	EMS144 076201
APASS = 000000	BIT6 = 000100	DRIVES 064520	EHT256 071460	EMS145 076211
APE = 100000	BIT7 = 000200	DRQ = 004000	EHT336 071472	EMS146 076240
APRIOR= 000000	BIT8 = 000400	DRVCLR= 000010	EHT337 071504	EMS147 076257
APTCSU= 000040	BIT9 = 001000	DRVSTS 050700	EHT344 071516	EMS15 072404
APTENV= 000001	BLNKS1 064563	DRY = 000200	EHT353 071530	EMS150 076274
APTSIZ= 000200	BLNKS2 064562	DSWR = 177570	EH1 100107	EMS151 076313
APTSPO= 000100	BLNKS3 064561	DTASTS 051502	EH110 100126	EMS152 076337
ARGS = 000004	BLNKS4 064560	DTE = 010000	EH111 100135	EMS153 076363
ASNDA 001516	BOTADR 061024	DTO = 010000	EH114 100154	EMS154 076405
ASNDC 001514	BOTFLG 061026	DULPRT= 024024	EH223 100203	EMS155 076421
ASWREG= 000000	BPTVEC= 000014	DVA = 004000	EH256 100231	EMS156 076441
ATA = 100000	BSE = 100000	DVC = 000200	EH336 100305	EMS157 076457
ATESTN= 000000	BUFFER 101360	EARLY 065212	EH337 100344	EMS16 072426

SYMBOL TABLE	
EMS160	076474
EMS161	076511
EMS162	076541
EMS163	076541
EMS164	076565
EMS165	076646
EMS166	076662
EMS167	076707
EMS17	072456
EMS170	076734
EMS171	076763
EMS172	077016
EMS173	077036
EMS174	077053
EMS175	077061
EMS176	077107
EMS177	077136
EMS2	071761
EMS20	072516
EMS200	077160
EMS201	077175
EMS202	077243
EMS203	077273
EMS204	077306
EMS205	077334
EMS206	077346
EMS207	077373
EMS21	072541
EMS210	077420
EMS211	077431
EMS212	077447
EMS213	077472
EMS214	077515
EMS215	077533
EMS216	077554
EMS217	077604
EMS22	072564
EMS220	077637
EMS221	077657
EMS222	077727
EMS223	077760
EMS224	100035
EMS23	072600
EMS24	072626
EMS25	072655
EMS26	072672
EMS27	072713
EMS3	071776
EMS30	072724
EMS31	072734
EMS32	072763
EMS33	073012
EMS34	073040
EMS35	073111
EMS36	073140
EMS37	073167
EMS4	072041
EMS40	073215
EMS41	073244
EMS42	073272
EMS43	073321
EMS44	073350
EMS45	073423
EMS46	073466
EMS47	073515
EMS5	072104
EMS50	073544
EMS51	073573
EMS52	073621
EMS53	073631
EMS54	073643
EMS55	073665
EMS56	073714
EMS57	073771
EMS6	072134
EMS60	074017
EMS61	074032
EMS62	074061
EMS63	074077
EMS64	074125
EMS65	074143
EMS66	074211
EMS67	074261
EMS7	072201
EMS70	074306
EMS71	074320
EMS72	074333
EMS73	074343
EMS74	074360
EMS75	074377
EMS76	074405
EMS77	074436
EMTVEC=	000030
EMT1	065324
EMT10	065374
EMT100	066372
EMT101	066410
EMT102	066426
EMT103	066436
EMT104	066450
EMT105	066466
EMT106	066476
EMT107	066506
EMT11	065400
EMT110	066526
EMT111	066540
EMT112	066546
EMT113	066554
EMT114	066570
EMT115	066576
EMT116	066606
EMT117	066616
EMT12	065404
EMT120	066626
EMT121	066636
EMT122	066646
EMT123	066656
EMT124	066666
EMT125	066676
EMT126	066706
EMT127	066720
EMT13	065412
EMT130	066732
EMT131	066744
EMT132	066756
EMT133	066770
EMT134	067002
EMT135	067014
EMT136	067026
EMT137	067040
EMT14	065424
EMT140	067050
EMT141	067060
EMT142	067070
EMT143	067100
EMT144	067110
EMT145	067120
EMT146	067130
EMT147	067140
EMT15	065432
EMT150	067150
EMT151	067160
EMT152	067172
EMT153	067204
EMT154	067222
EMT155	067240
EMT156	067252
EMT157	067264
EMT16	065440
EMT160	067276
EMT161	067306
EMT162	067320
EMT163	067332
EMT164	067342
EMT165	067350
EMT166	067356
EMT167	067364
EMT17	065450
EMT170	067372
EMT171	067404
EMT172	067414
EMT173	067424
EMT174	067434
EMT175	067446
EMT176	067454
EMT177	067462
EMT2	065330
EMT20	065460
EMT200	067464
EMT201	067476
EMT202	067510
EMT203	067522
EMT204	067534
EMT205	067552
EMT206	067562
EMT207	067572
EMT21	065470
EMT210	067604
EMT211	067612
EMT212	067626
EMT213	067642
EMT214	067652
EMT215	067672
EMT216	067704
EMT217	067714
EMT22	065500
EMT220	067724
EMT221	067734
EMT222	067744
EMT223	067754
EMT224	067764
EMT225	067766
EMT226	067770
EMT227	067772
EMT23	065510
EMT230	067774
EMT231	067776
EMT232	070000
EMT233	070002
EMT234	070004
EMT235	070006
EMT236	070010
EMT237	070012
EMT24	065520
EMT240	070014
EMT241	070016
EMT242	070020
EMT243	070022
EMT244	070024
EMT245	070026
EMT246	070030
EMT247	070040
EMT25	065530
EMT250	070052
EMT251	070066
EMT252	070074
EMT253	070102
EMT254	070120
EMT255	070130
EMT256	070140
EMT257	070150
EMT26	065540
EMT260	070162
EMT261	070174
EMT262	070214
EMT263	070224
EMT264	070234
EMT265	070254
EMT266	070274
EMT267	070306
EMT27	065550
EMT270	070324
EMT271	070340
EMT272	070356
EMT273	070374
EMT274	070412
EMT275	070430
EMT276	070442
EMT277	070456
EMT3	065336
EMT30	065560
EMT300	070474
EMT301	070514
EMT302	070536
EMT303	070550
EMT304	070562
EMT305	070574
EMT306	070606
EMT307	070616
EMT31	065570
EMT310	070636
EMT311	070650
EMT312	070662
EMT313	070674
EMT314	070714
EMT315	070726
EMT316	070740
EMT317	070752
EMT32	065600
EMT320	070762
EMT321	070772
EMT322	071002
EMT323	071010
EMT324	071020
EMT325	071032
EMT326	071044
EMT327	071062
EMT33	065610
EMT330	071074
EMT331	071104
EMT332	071116
EMT333	071130
EMT334	071146
EMT335	071164
EMT336	071204
EMT337	071214
EMT34	065620
EMT340	071224
EMT341	071236
EMT342	071244
EMT343	071256
EMT344	071270
EMT345	071302
EMT346	071312
EMT347	071326

EMT35 065630	ESRC = 004000	ILRG76= 000076	PACACK= 000022	RMBAI 001342
EMT350 071340	FER = 000020	IOTVEC= 000020	PAKACK= 000022	RMBAO 001416
EMT351 071356	FIND = 000001	IPCK0 = 000001	PAR = 000010	RMCS1 = 000000
EMT352 071366	FMT16 = 010000	IPCK1 = 000002	PAT = 000020	RMCS1I 001336
EMT353 071372	FNCDTB 064566	IPCK2 = 000004	PDA = 000400	RMCS10 001412
EMT354 071402	FNCMSK= 000077	IPCK3 = 000010	PFECH 061072	RMCS2 = 000010
EMT36 065640	F0 = 000002	IR = 000100	PFECH1 061102	RMCS2I 001346
EMT37 065650	F1 = 000004	IVC = 010000	PFECH2 061170	RMCS20 001422
EMT4 065344	F2 = 000010	LBC = 002000	PFECH3 061206	RMCS3 = 000052
EMT40 065660	F3 = 000020	LBT = 002000	PFECH4 061214	RMCS3I 001410
EMT41 065666	F4 = 000040	LF = 000012	PGE = 002000	RMCS30 001464
EMT42 065676	GENBUF 035104	LODEV 064426	PGM = 001000	RMDA = 000006
EMT43 065710	GET 035770	LS = 000004	PHA = 000200	RMDAI 001344
EMT44 065720	GETBUF 001336	LSC = 004000	PIP = 020000	RMDAO 001420
EMT45 065730	GETINX 001524	LST = 000002	PIRQ = 177772	RMDB = 000022
EMT46 065740	GETSTS 035704	LSTRK 001334	PIRQVE= 000240	RMDBI 001360
EMT47 065750	GO = 000001	MCLK = 004000	PLFS = 002000	RMDBO 001434
EMT5 065352	GTSWR = 104407	MCPE = 020000	PRIERR 036766	RMDC = 000034
EMT50 065756	HCE = 000200	MDF = 000100	PR0 = 000000	RMDCI 001372
EMT51 065766	HCI = 002000	MDPE = 000400	PR1 = 000040	RMDCO 001446
EMT52 066000	HCRC = 000400	MEDENB 001512	PR2 = 000100	RMDS = 000012
EMT53 066016	HELP 101360	MFGFIL 103370	PR3 = 000140	RMDSI 001350
EMT54 066034	HT = 000011	MI = 000004	PR4 = 000200	RMDSO 001424
EMT55 066044	IAE = 002000	MIXED 064676	PR5 = 000240	RMDT = 000026
EMT56 066056	IBSAVE 060152	MOC = 000400	PR6 = 000300	RMDTI 001364
EMT57 066074	IDXMSK= 000077	MOH = 020000	PR7 = 000340	RMDTO 001440
EMT6 065360	IE = 000100	MOL = 010000	PS = 177776	RMEC1 = 000044
EMT60 066104	ILF = 000001	MRD = 002000	PSEL = 002000	RMEC1I 001402
EMT61 066122	ILF02 = 000002	MS = 000040	PSW = 177776	RMEC10 001456
EMT62 066142	ILF24 = 000024	MSC = 000002	PUT 036240	RMEC2 = 000046
EMT63 066156	ILF26 = 000026	MSDRVS 064326	PUTBUF 001412	RMEC2I 001404
EMT64 066160	ILF30 = 000030	MSE = 100000	PUTINX 001553	RMEC20 001460
EMT65 066200	ILF32 = 000032	MSER = 000200	PWRVEC= 000024	RMER1 = 000014
EMT66 066220	ILF34 = 000034	MSGDRV 064342	QUES 063441	RMER1I 001352
EMT67 066232	ILF36 = 000036	MSHELP 063450	RCLSTS 047136	RMER10 001426
EMT7 065366	ILF40 = 000040	MUR = 001000	RD = 000070	RMER2 = 000042
EMT70 066244	ILF42 = 000042	MWD = 000010	RDCHR = 104411	RMER2I 001400
EMT71 066254	ILF44 = 000044	MWP = 000010	RDLIN = 104412	RMER20 001454
EMT72 066264	ILF46 = 000046	MXF = 001000	RDOCT = 104413	RMHR = 000036
EMT73 066302	ILF54 = 000054	N 064554	RDY = 000200	RMHRI 001374
EMT74 066320	ILF56 = 000056	NDTMSK= 115760	READY 007670	RMHRO 001450
EMT75 066330	ILF64 = 000064	NED = 010000	RECAL = 000006	RMLA = 000020
EMT76 066350	ILF66 = 000066	NEM = 004000	RESREG= 104415	RMLAI 001356
EMT77 066360	ILF74 = 000074	NONE 064547	RESVEC= 000010	RMLAO 001432
ENRGDT 065324	ILF76 = 000076	NOP = 000000	REX = 010000	RMMR1 = 000024
EQUALS 063432	ILR = 000002	NOTAVL 064460	RG = 040000	RMMR1I 001362
ERR = 040000	ILRG50= 000050	NOTPRS 064443	RGDTPT 064676	RMMR10 001436
ERRNMB 061022	ILRG52= 000052	NOTRM 064405	RH = 000072	RMMR2 = 000040
ERROR = 104000	ILRG54= 000054	NSA = 100000	RIP = 000020	RMMR2I 001376
ERRTYP 060154	ILRG56= 000056	OCC = 100000	RELEASE= 000012	RMMR20 001452
ERRVEC= 000004	ILRG60= 000060	OFD = 000200	RMAS = 000016	RMOF = 000032
ERTY00 061030	ILRG62= 000062	OFFSET= 000014	RMASI 001354	RMOFI 001370
ERTY01 061035	ILRG64= 000064	OM = 000001	RMASO 001430	RMOFO 001444
ERTY02 061045	ILRG66= 000066	ONES 064736	RMBA = 000004	RMR = 000004
ERTY03 061054	ILRG70= 000070	OPE = 020000	RMBAE = 000050	RMSN = 000030
ERTY04 061062	ILRG72= 000072	GPI = 020000	RMBAEI 001406	RMSNI 001366
ERTY05 061065	ILRG74= 000074	OR = 000200	RMBAE0 001462	RMSNO 001442

RMWC = 000002	SW04 = 000020	TST25 = 025204	\$CMTAG = 001114	\$LPERR = 001124
RMWCI = 001340	SW05 = 000040	TST26 = 026116	\$CM3 = 000000	\$MADR1 = 001254
RMWCO = 001414	SW06 = 000100	TST27 = 026740	\$CM4 = 000005	\$MADR2 = 001260
RQA = 100000	SW07 = 000200	TST3 = 011130	\$CNTLC = 062426	\$MADR3 = 001264
RQB = 040000	SW08 = 000400	TST30 = 027522	\$CNTLG = 062440	\$MADR4 = 001270
RTC = 000016	SW09 = 001000	TST31 = 030672	\$CNTLU = 062433	\$MAIL = 001222
R6 = %000006	SW1 = 000002	TST4 = 011764	\$CPUOP = 001250	\$MAMS1 = 001252
R7 = %000007	SW10 = 002000	TST5 = 012554	\$CRLF = 001217	\$MAMS2 = 001256
SADMSK = 000377	SW11 = 004000	TST6 = 013514	\$DBLK = 056172	\$MAMS3 = 001262
SAVREG = 104414	SW12 = 010000	TST7 = 014334	\$DDW0 = 001306	\$MAMS4 = 001266
SA1 = 000001	SW13 = 020000	TYPBN = 104406	\$DDW1 = 001310	\$MBADR = 001102
SA16 = 000020	SW14 = 040000	TYPDS = 104405	\$DDW2 = 001312	\$MFLG = 063342
SA2 = 000002	SW15 = 100000	TYPE = 104401	\$DDW3 = 001314	\$MNEW = 062456
SA4 = 000004	SW2 = 000004	TYPOC = 104402	\$DDW4 = 001316	\$MSGAD = 001236
SA8 = 000010	SW3 = 000010	TYPON = 104404	\$DDW5 = 001320	\$MSGLG = 001240
SC = 100000	SW4 = 000020	TYPOS = 104403	\$DDW6 = 001322	\$MSGTY = 001222
SCOPE = 000004	SW5 = 000040	UNS = 040000	\$DDW7 = 001324	\$MSWR = 062445
SCTMSG = 063346	SW6 = 000100	UNTMSK = 000007	\$DEVCT = 001232	\$MTYP1 = 001253
SCTMSK = 003700	SW7 = 000200	UNTOFF = 064477	\$DEVM = 001300	\$MTYP2 = 001257
SCO = 000100	SW8 = 000400	UNTON = 064510	\$DOAGN = 032132	\$MTYP3 = 001263
SC1 = 000200	SW9 = 001000	UPE = 020000	\$DTBL = 056162	\$MTYP4 = 001267
SC2 = 000400	SYSTAT = 064350	USE = 040000	\$ENDAD = 032122	\$MXCNT = 057446
SC3 = 001000	TADMSK = 177400	USRFIL = 104376	\$ENDCT = 031760	\$NULL = 001170
SC4 = 002000	TAG = 020000	U0 = 000001	\$ENULL = 032136	\$NWTST = 000001
SEARCH = 000030	TAGADR = 001114	U1 = 000002	\$ENV = 001242	\$OCNT = 056424
SECERR = 037620	TAP = 040000	U2 = 000004	\$ENVM = 001243	\$OMODE = 056426
SEEK = 000004	TA1 = 000400	VV = 000100	\$EOP = 031724	\$OVER = 057432
SEKSTS = 044104	TA16 = 010000	WC = 000040	\$EOPCT = 031752	\$PASS = 001230
SHUT = 032142	TA2 = 001000	WCD = 000050	\$EOSP = 031666	\$PASTM = 001106
SHUT2 = 062470	TA4 = 002000	WCE = 040000	\$ERFLG = 001117	\$POWER = 063070
SIZCLK = 036460	TA8 = 004000	WCEHI = 010000	\$ERMAX = 001131	\$PWRDN = 062722
SKI = 040000	TBITVE = 000014	WCELO = 004000	\$ERROR = 057560	\$PWRMG = 063056
SNGPRT = 020024	TIMOUT = 036602	WCF = 000040	\$ERRPC = 001132	\$PWRUP = 062774
STACK = 001100	TKVEC = 000060	WCH = 000052	\$ERRTB = 001602	\$QUES = 001216
STANDA = 007020	TPVEC = 000064	WD = 000060	\$ERTTL = 001126	\$RDCHR = 062072
START = 005432	TRAPVE = 000034	WH = 000062	\$ESCAP = 001210	\$RDLIN = 062162
START1 = 005422	TRE = 040000	WLE = 004000	\$ETABL = 001242	\$RDOCT = 062512
START2 = 005436	TRTVEC = 000014	WRL = 004000	\$ETEND = 001326	\$RDSZ = 000010
STCDRV = 055102	TST = 010000	XSIZ = 006464	\$FATAL = 001224	\$RESRE = 055644
STKLMT = 177774	TSTNMB = 061020	XXDP = 001332	\$FFLG = 063344	\$RM02 = 064366
STOP = 057532	TSTPRP = 032176	Y = 064556	\$FILLC = 001172	\$RM03 = 064373
STSD1 = 101250	TSTQUE = 001466	ZEROS = 065000	\$FILLS = 001171	\$RM05 = 064400
STSD2 = 101266	TST1 = 010066	\$APTHD = 001100	\$GDADR = 001134	\$RTNAD = 032134
STSD3 = 101306	TST10 = 015124	\$ATYC = 063124	\$GDDAT = 001140	\$SAVRE = 055606
STSD4 = 101320	TST11 = 016062	\$ATY1 = 063100	\$GET42 = 032112	\$SAVR6 = 063066
STSF = 101351	TST12 = 016656	\$ATY3 = 063106	\$GTSWR = 061620	\$SCOPE = 056764
STSH1 = 100713	TST13 = 017470	\$ATY4 = 063116	\$GT42P = 032106	\$SETUP = 000137
STSH2 = 100770	TST14 = 020302	\$AUTOB = 001150	\$HD = 000000	\$STUP = 177777
STSH3 = 101057	TST15 = 021124	\$BASE = 001276	\$HIBTS = 001100	\$SVLAD = 057376
STSH4 = 101115	TST16 = 021666	\$BDADR = 001136	\$HIOCT = 062612	\$SVPC = 000210
SWR = 001154	TST17 = 022430	\$BDDAT = 001142	\$ICNT = 001120	\$SWR = 167400
SWREG = 000176	TST2 = 010266	\$BELL = 001212	\$ILLUP = 063062	\$SWREG = 001244
SW0 = 000001	TST20 = 023172	\$BIN = 055754	\$INTAG = 001151	\$SWRMK = 000000
SW00 = 000001	TST21 = 023476	\$CDW1 = 001302	\$ITEMB = 001130	\$SW08T = 057450
SW01 = 000002	TST22 = 024002	\$CDW2 = 001304	\$LF = 001220	\$TESTN = 001226
SW02 = 000004	TST23 = 024344	\$CHARC = 056760	\$LFLG = 063343	\$TIMES = 001206
SW03 = 000010	TST24 = 024666	\$CKSWR = 061530	\$LPADR = 001122	\$TKB = 001162

\$TKCNT	061220	\$TMP1	001176	\$STRAP2	062654	\$TYPEC	056642	\$VECT2	001274
\$TKINT	061230	\$TMP2	001200	\$STRP =	000016	\$TYPEX	056762	\$XOFF =	000023
\$TKQEN=	061227	\$TMP3	001202	\$STRPAD	062666	\$TYPOC	056226	\$XON =	000021
\$TKQIN	061222	\$TMP4	001204	\$STSTM	001104	\$TYPON	056242	\$XTSTR	057006
\$TKQOU	061224	\$TN =	000032	\$STSTM	001116	\$TYPOS	056202	\$\$GET4=	000000
\$TKQSR	061226	\$TPB	001166	\$TTYIN	062416	\$UNIT	001234	\$\$SW08=	000032
\$TKS	001160	\$TPFLG	001173	\$TYPBN	055702	\$UNITM	001110	\$OFILL	056425
\$TKSRV	061300	\$TPS	001164	\$TYPDS	055756	\$USWR	001246	.\$X =	001100
\$TMPO	001174	\$STRAP	062614	\$TYPE	056430	\$VECT1	001272		

. ABS. 105404 000
000000 001

ERRORS DETECTED: 0

VIRTUAL MEMORY USED: 61696 WORDS (241 PAGES)
DYNAMIC MEMORY AVAILABLE FOR 70 PAGES
CZRMNB.BIC,CZRMNB/C=CZRMNB.DOC,CZRMNB,SYSMAC/M

AENV	6-0	6-0												
AENVM	6-0	6-0												
AFATAL	6-0	6-0												
ALL	11-69	49-5#												
AMADR1	6-0	6-0												
AMADR2	6-0	6-0												
AMADR3	6-0	6-0												
AMADR4	6-0	6-0												
AMAMS1	6-0	6-0												
AMAMS2	6-0	6-0												
AMAMS3	6-0	6-0												
AMAMS4	6-0	6-0												
AMSGAD	6-0	6-0												
AMSGLG	6-0	6-0												
AMSGTY	6-0	6-0												
AMTYP1	6-0	6-0												
AMTYP2	6-0	6-0												
AMTYP3	6-0	6-0												
AMTYP4	6-0	6-0												
AOE	4-572#	4-583	25-311	25-326	25-341	25-356	25-360	26-117	26-121	50-77	50-78	50-81	50-82	50-85
	50-86													
APASS	6-0	6-0												
APE	4-750#													
APRIOR	6-0													
APTC SU	41-1	48-2#												
APTENV	41-1	43-1	48-2	48-2#										
APTSIZ	10-23	48-2#												
APTSPO	41-1	48-2	48-2#											
ARGS	13-43#	13-51	13-51#	13-63#	13-72#	13-76#	13-87#	13-93#	13-97#	13-99#	13-101#	13-108#	13-114#	13-118#
	13-120#	13-122#	13-126#	13-144#	13-152	13-152#	13-164#	13-173#	13-177#	13-189#	13-195#	13-199#	13-201#	13-203#
	13-211#	13-217#	13-221#	13-223#	13-225#	13-229#	13-242#	13-250	13-250#	13-262#	13-271#	13-275#	13-286#	13-292#
	13-296#	13-298#	13-300#	13-306#	13-312#	13-316#	13-318#	13-320#	13-335#	13-343	13-343#	13-355#	13-364#	13-368#
	13-379#	13-385#	13-389#	13-391#	13-393#	13-402#	13-408#	13-412#	13-419#	13-437#	13-460#	13-468	13-468#	13-480#
	13-489#	13-493#	13-504#	13-510#	13-514#	13-516#	13-518#	13-525#	13-531#	13-535#	13-537#	13-539#	13-543#	13-556#
	13-564	13-564#	13-576#	13-585#	13-589#	13-600#	13-606#	13-610#	13-612#	13-614#	13-620#	13-626#	13-630#	13-632#
	13-634#	13-649#	13-657	13-657#	13-669#	13-678#	13-682#	13-693#	13-699#	13-703#	13-705#	13-707#	13-716#	13-722#
	13-726#	13-733#	13-749#	13-773#	13-781	13-781#	13-793#	13-802#	13-806#	13-817#	13-823#	13-827#	13-829#	13-831#
	13-837#	13-843#	13-847#	13-849#	13-851#	13-867#	13-876	13-876#	13-888#	13-897#	13-901#	13-912#	13-918#	13-922#
	13-924#	13-926#	13-932#	13-938#	13-942#	13-944#	13-946#	13-962#	13-972	13-972#	13-984#	13-993#	13-997#	13-:08#
	13-:14#	13-:18#	13-:20#	13-:22#	13-:28#	13-:34#	13-:38#	13-:40#	13-:42#	13-:57#	13-:65	13-:65#	13-:79#	13-:88#
	13-:92#	13-:04#	13-:10#	13-:14#	13-:16#	13-:18#	13-:24#	13-:30#	13-:34#	13-:36#	13-:38#	13-:58#	13-:66	13-:66#
	13-:80#	13-:87#	13-:91#	13-:93#	13-:95#	13-<02#	13-<08#	13-<12#	13-<14#	13-<16#	13-<20#	13-<41#	13-<49	13-<49#
	13-<63#	13-<70#	13-<74#	13-<76#	13-<78#	13-<85#	13-<91#	13-<95#	13-<97#	13-<99#	13-=03#	13-=24#	13-=33	13-=33#
	13-=46#	13-=54#	13-=58#	13-=60#	13-=62#	13-=68#	13-=73#	13-=77#	13-=79#	13-=81#	13-=85#	13->08	13->08#	13->21#
	13->28#	13->32#	13->34#	13->36#	13->54	13->54#	13->65#	13->72#	13->76#	13->78#	13->80#	13->96	13->96#	13-?09#
	13-?16#	13-?20#	13-?22#	13-?24#	13-?52	13-?52#	13-?65#	13-?72#	13-?76#	13-?78#	13-?80#	13-@01	13-@01#	13-@14#
	13-@21#	13-@25#	13-@27#	13-@29#	13-@49#	13-@57	13-@57#	13-@69#	13-@80#	13-@87#	13-@91#	13-@93#	13-@95#	13-A06#
	13-A19#	13-A25#	13-A29#	13-A31#	13-A33#	13-A37#	13-A56#	13-A64	13-A64#	13-A72#	13-A88#	13-A95#	13-A99#	13-B08#
	13-B12	13-B12#	13-B19#	13-B26#	13-B30#	13-B39#	13-B55#	13-B63	13-B63#	13-B77#	13-B84#	13-B88#	13-B90#	13-B92#
	13-C02#	13-C08#	13-C12#	13-C19#	13-C26#	13-C47#	13-C55	13-C55#	13-C77#	13-C84#	13-C88#	13-C90#	13-C92#	13-C99#
	13-D05#	13-D09#	13-D20#	13-D33#	13-D46#	13-D58#	13-D79	13-D79#	13-D90#	13-E10#	13-E18	13-E18#	13-E40#	13-E47#
	13-E51#	13-E53#	13-E55#	13-E62#	13-E68#	13-E72#	13-E79#	13-E91#	13-F12	13-F12#	13-F23#			
ASNDA	7-0#	16-299*	16-331	16-358*	16-359	16-361*	16-362*	16-363	16-365*	16-397				
ASNDC	7-0#	16-298*	16-330	16-366*	16-367	16-369*	16-396							
ASWREG	6-0	6-0												
ATA	4-552#	25-138	25-139	25-141	29-156	29-157	29-192	29-195	33-145	33-146	33-185	33-188	50-58	50-59
	50-60	50-63	50-64	50-67	50-68	50-69	50-70	50-71	50-72	50-73	50-74	50-75	50-76	50-79

	50-80	50-83	50-84	50-87	50-88									
ATESTN	6-0	6-0												
ATNMSK	4-589#	34-55												
ATNTBL	10-78	10-117	10-121	11-97	12-17	51-3#								
AUNIT	6-0	6-0												
AUSWR	6-0	6-0												
AVECT1	4-773#	6-0	6-0											
AVECT2	6-0	6-0												
BACK	13-43	13-43#	13-51	13-51#	13-63	13-63#	13-72	13-72#	13-76	13-76#	13-76#	13-87	13-87#	13-93
	13-93#	13-97	13-97#	13-97#	13-99	13-99#	13-99#	13-101	13-101#	13-101#	13-101#	13-108	13-108#	13-114
	13-118	13-118#	13-118#	13-120	13-120#	13-120#	13-122	13-122#	13-122#	13-122#	13-126	13-126#	13-144	13-144#
	13-152#	13-164	13-164#	13-173	13-173#	13-177	13-177#	13-177#	13-189	13-189#	13-189#	13-195	13-195#	13-199
	13-199#	13-201	13-201#	13-201#	13-203	13-203#	13-203#	13-211	13-211#	13-217	13-217#	13-221	13-221#	13-221#
	13-223	13-223#	13-223#	13-225	13-225#	13-225#	13-229	13-229#	13-242	13-242#	13-250	13-250#	13-262	13-262#
	13-271	13-271#	13-275	13-275#	13-275#	13-286	13-286#	13-292	13-292#	13-296	13-296#	13-296#	13-298	13-298#
	13-298#	13-300	13-300#	13-300#	13-306	13-306#	13-312	13-312#	13-316	13-316#	13-316#	13-318	13-318#	13-318#
	13-320	13-320#	13-320#	13-335	13-335#	13-343	13-343#	13-355	13-355#	13-364	13-364#	13-368	13-368#	13-368#
	13-379	13-379#	13-385	13-385#	13-389	13-389#	13-389#	13-391	13-391#	13-391#	13-393	13-393#	13-393#	13-402
	13-402#	13-408	13-408#	13-412	13-412#	13-412#	13-419	13-419#	13-419#	13-437	13-437#	13-460	13-460#	13-468
	13-468#	13-480	13-480#	13-489	13-489#	13-493	13-493#	13-493#	13-504	13-504#	13-510	13-510#	13-514	13-514#
	13-514#	13-516	13-516#	13-516#	13-518	13-518#	13-518#	13-525	13-525#	13-531	13-531#	13-535	13-535#	13-535#
	13-537	13-537#	13-537#	13-539	13-539#	13-539#	13-543	13-543#	13-556	13-556#	13-564	13-564#	13-576	13-576#
	13-585	13-585#	13-589	13-589#	13-589#	13-600	13-600#	13-606	13-606#	13-610	13-610#	13-610#	13-612	13-612#
	13-612#	13-614	13-614#	13-614#	13-620	13-620#	13-626	13-626#	13-630	13-630#	13-630#	13-632	13-632#	13-632#
	13-634	13-634#	13-634#	13-649	13-649#	13-657	13-657#	13-669	13-669#	13-678	13-678#	13-682	13-682#	13-682#
	13-693	13-693#	13-699	13-699#	13-703	13-703#	13-703#	13-705	13-705#	13-705#	13-707	13-707#	13-707#	13-716
	13-716#	13-722	13-722#	13-726	13-726#	13-726#	13-733	13-733#	13-733#	13-749	13-749#	13-773	13-773#	13-781
	13-781#	13-793	13-793#	13-802	13-802#	13-806	13-806#	13-806#	13-817	13-817#	13-823	13-823#	13-827	13-827#
	13-827#	13-829	13-829#	13-829#	13-831	13-831#	13-831#	13-837	13-837#	13-843	13-843#	13-847	13-847#	13-847#
	13-849	13-849#	13-849#	13-851	13-851#	13-851#	13-867	13-867#	13-876	13-876#	13-888	13-888#	13-897	13-897#
	13-901	13-901#	13-901#	13-912	13-912#	13-918	13-918#	13-922	13-922#	13-922#	13-924	13-924#	13-924#	13-926
	13-926#	13-926#	13-932	13-932#	13-938	13-938#	13-942	13-942#	13-942#	13-944	13-944#	13-944#	13-946	13-946#
	13-946#	13-962	13-962#	13-972	13-972#	13-984	13-984#	13-993	13-993#	13-997	13-997#	13-997#	13-:08	13-:08#
	13-:14	13-:14#	13-:18	13-:18#	13-:18#	13-:20	13-:20#	13-:20#	13-:22	13-:22#	13-:22#	13-:28	13-:28#	13-:34
	13-:34#	13-:38	13-:38#	13-:38#	13-:40	13-:40#	13-:40#	13-:42	13-:42#	13-:42#	13-:57	13-:57#	13-:65	13-:65#
	13-:79	13-:79#	13-:88	13-:88#	13-:92	13-:92#	13-:92#	13-:04	13-:04#	13-:10	13-:10#	13-:14	13-:14#	13-:14#
	13-:16	13-:16#	13-:16#	13-:18	13-:18#	13-:18#	13-:24	13-:24#	13-:30	13-:30#	13-:34	13-:34#	13-:34#	13-:36
	13-:36#	13-:36#	13-:38	13-:38#	13-:38#	13-:58	13-:58#	13-:66	13-:66#	13-:80	13-:80#	13-:87	13-:87#	13-:91
	13-:91#	13-:91#	13-:93	13-:93#	13-:93#	13-:95	13-:95#	13-:95#	13-:02#	13-:08	13-:08#	13-:12	13-:12#	13-:12#
	13-<12#	13-<14	13-<14#	13-<14#	13-<16	13-<16#	13-<16#	13-<20	13-<20#	13-<41	13-<41#	13-<49	13-<49#	13-<63
	13-<63#	13-<70	13-<70#	13-<74	13-<74#	13-<74#	13-<76	13-<76#	13-<76#	13-<78	13-<78#	13-<78#	13-<85	13-<85#
	13-<91	13-<91#	13-<95	13-<95#	13-<95#	13-<97	13-<97#	13-<99	13-<99#	13-<99#	13-<99#	13-03	13-03#	13-24
	13-24#	13-33	13-33#	13-46	13-46#	13-54	13-54#	13-58	13-58#	13-58#	13-60	13-60#	13-60#	13-62
	13-62#	13-62#	13-68	13-68#	13-73	13-73#	13-77	13-77#	13-77#	13-79	13-79#	13-79#	13-81	13-81#
	13-81#	13-85	13-85#	13->08	13->08#	13->21	13->21#	13->28	13->28#	13->32	13->32#	13->32#	13->34	13->34#
	13->34#	13->36	13->36#	13->36#	13->54	13->54#	13->65	13->65#	13->72	13->72#	13->76	13->76#	13->76#	13->78
	13->78#	13->78#	13->80	13->80#	13->80#	13->96	13->96#	13-?09	13-?09#	13-?16	13-?16#	13-?20	13-?20#	13-?20#
	13-?22	13-?22#	13-?22#	13-?24	13-?24#	13-?24#	13-?52	13-?52#	13-?65	13-?65#	13-?72	13-?72#	13-?76	13-?76#
	13-?76#	13-?78	13-?78#	13-?78#	13-?80	13-?80#	13-?80#	13-a01	13-a01#	13-a14	13-a14#	13-a21	13-a21#	13-a25
	13-a25#	13-a25#	13-a27	13-a27#	13-a27#	13-a29	13-a29#	13-a29#	13-a49	13-a49#	13-a57	13-a57#	13-a69	13-a69#
	13-a80	13-a80#	13-a87	13-a87#	13-a91	13-a91#	13-a91#	13-a93	13-a93#	13-a93#	13-a95	13-a95#	13-a95#	13-A06
	13-A06#	13-A19	13-A19#	13-A25	13-A25#	13-A29	13-A29#	13-A29#	13-A31	13-A31#	13-A31#	13-A33	13-A33#	13-A33#
	13-A37	13-A37#	13-A56	13-A56#	13-A64	13-A64#	13-A72	13-A72#	13-A88	13-A88#	13-A95	13-A95#	13-A99	13-A99#
	13-A99#	13-B08	13-B08#	13-B08#	13-B12	13-B12#	13-B19	13-B19#	13-B26	13-B26#	13-B30	13-B30#	13-B30#	13-B39
	13-B39#	13-B39#	13-B55	13-B55#	13-B63	13-B63#	13-B77	13-B77#	13-B84	13-B84#	13-B88	13-B88#	13-B88#	13-B90
	13-B90#	13-B90#	13-B92	13-B92#	13-B92#	13-C02	13-C02#	13-C08	13-C08#	13-C12	13-C12#	13-C12#	13-C19	13-C19#
	13-C19#	13-C26	13-C26#	13-C26#	13-C47	13-C47#	13-C55	13-C55#	13-C77	13-C77#	13-C84	13-C84#	13-C88	13-C88#

DRVSTS	16-105	34-9#												
DRY	4-560#	24-106	25-38	25-41	25-42	29-195	31-127	31-128	34-30					
DSWR	4-484#	6-0	10-23											
DTASTS	13-99	13-120	13-201	13-223	13-298	13-318	13-391	13-419	13-516	13-537	13-612	13-632	13-705	13-733
	13-829	13-849	13-924	13-944	13-:20	13-:40	13-:16	13-:36	13-:93	13-<14	13-<76	13-<97	13-=60	13-=79
	13->34	13->78	13-?22	13-?78	13-a27	13-a93	13-A31	13-B90	13-C19	13-C90	13-D20	13-D33	13-D46	13-E53
	13-E79	16-200	35-17#											
DTE	4-569#	4-583	35-279	35-297	35-300									
DTO	4-607#													
DULPRT	4-646#													
DVA	4-490#	10-89	20-43	21-37	24-67	24-70	28-37	31-33	34-17	34-18				
DVC	4-680#	29-127	31-117	33-92	33-130	33-133	33-266	35-232	35-236	35-239	35-284	36-89	36-94	36-97
EARLY	52-107#													
EBL	4-623#													
ECH	4-575#	4-583	16-222	18-25	25-452	25-467	25-485	25-491	35-423	50-77	50-78	50-85	50-86	
ECI	4-651#	18-21	25-487	35-420										
ECRC	4-627#													
ED1	55-1	59-1#												
ED110	55-4	59-2#												
ED111	55-5	59-3#												
ED114	55-7	59-5#												
ED223	55-8	59-6#												
ED336	55-10	59-8#												
ED337	55-11	55-12	59-10#											
ED353	55-14	59-11#												
EDT1	8-3	8-6	8-9	8-12	8-15	8-18	8-24	8-27	8-30	8-33	8-36	8-39	8-42	8-45
	8-48	8-51	8-54	8-57	8-60	8-63	8-66	8-69	8-72	8-75	8-78	8-81	8-84	8-87
	8-90	8-93	8-96	8-99	8-102	8-105	8-108	8-111	8-114	8-117	8-120	8-123	8-126	8-130
	8-133	8-136	8-139	8-142	8-146	8-150	8-154	8-160	8-163	8-166	8-169	8-172	8-175	8-178
	8-182	8-185	8-188	8-191	8-194	8-197	8-200	8-203	8-206	8-209	8-212	8-215	8-218	8-236
	8-239	8-242	8-245	8-248	8-251	8-254	8-257	8-260	8-263	8-266	8-269	8-272	8-275	8-278
	8-281	8-284	8-287	8-290	8-293	8-296	8-299	8-302	8-305	8-308	8-311	8-314	8-317	8-320
	8-323	8-326	8-329	8-332	8-335	8-338	8-341	8-344	8-347	8-354	8-357	8-360	8-363	8-366
	8-369	8-372	8-375	8-378	8-381	8-384	8-390	8-393	8-396	8-399	8-402	8-405	8-408	8-411
	8-414	8-417	8-420	8-423	8-432	8-435	8-438	8-441	8-444	8-504	8-507	8-510	8-519	8-522
	8-525	8-531	8-534	8-537	8-540	8-543	8-546	8-549	8-552	8-556	8-559	8-563	8-566	8-569
	8-573	8-577	8-581	8-586	8-590	8-594	8-597	8-600	8-603	8-606	8-609	8-612	8-615	8-618
	8-621	8-624	8-627	8-630	8-633	8-636	8-639	8-642	8-645	8-648	8-651	8-654	8-657	8-660
	8-663	8-666	8-669	8-672	8-675	8-678	8-693	8-696	8-702	8-705	8-708	8-711	8-714	8-723
	55-1#													
EDT110	8-221	55-4#												
EDT111	8-224	8-227	55-5#											
EDT114	8-233	55-7#												
EDT2	8-426	8-429	8-513	8-516	55-2#									
EDT223	8-447	8-528	55-8#											
EDT336	8-351	8-681	8-687	8-690	55-10#									
EDT337	8-684	55-11#												
EDT344	8-699	55-12#												
EDT353	8-720	55-14#												
EECC	4-632#													
EF110	56-4	60-1#												
EF111	56-1	56-5	60-2#											
EF114	56-7	56-8	56-14	60-3#										
EF336	56-10	56-11	56-12	60-4#										
EF337	60-5#													
EFT1	8-3	8-6	8-9	8-12	8-15	8-18	8-24	8-27	8-30	8-33	8-36	8-39	8-42	8-45
	8-48	8-51	8-54	8-57	8-60	8-63	8-66	8-69	8-72	8-75	8-78	8-81	8-84	8-87

EMS1	53-3	57-3#													
EMS10	53-7	53-11	57-10#												
EMS100	53-39	53-71	53-176	53-196	57-66#										
EMS101	53-40	53-59	53-174	53-197	57-67#										
EMS102	53-177	53-178	53-181	53-182	53-183	53-184	53-186	53-187	53-188	53-189	53-234	53-235	57-68#		
EMS103	53-56	53-57	53-135	53-141	53-196	53-197	53-198	53-203	53-204	53-205	53-206	53-207	53-208	53-209	
	53-210	53-211	53-213	53-214	53-215	53-219	53-220	57-69#							
EMS104	53-136	53-180	53-203	57-70#											
EMS105	53-204	57-71#													
EMS106	53-212	53-232	57-72#												
EMS11	53-12	53-15	53-16	53-17	53-18	53-19	53-20	53-21	53-22	53-23	53-24	53-25	53-26	53-27	
	53-28	53-29	53-30	53-31	53-32	53-33	53-43	53-177	57-11#						
EMS110	53-9	53-74	53-77	57-73#											
EMS111	53-74	53-226	57-74#												
EMS112	53-74	57-75#													
EMS113	53-75	53-76	53-78	53-127	57-77#										
EMS114	53-77	57-78#													
EMS115	53-44	53-45	53-48	53-50	53-51	53-52	53-54	53-55	53-60	53-61	53-63	53-66	53-67	53-70	
	53-73	53-77	53-107	53-108	53-109	53-110	53-134	53-137	53-139	53-140	53-142	53-179	53-182	53-183	
	53-185	53-186	53-187	53-188	53-189	53-190	53-192	53-193	53-194	53-195	53-201	53-205	53-221	53-222	
	53-223	53-232	53-234	57-79#											
EMS116	53-74	53-77	53-19	53-225	57-80#										
EMS117	53-77	53-143	53-148	53-149	53-178	53-185	53-201	53-225	53-228	53-229	53-230	53-231	57-81#		
EMS12	53-12	57-12#													
EMS120	53-78	57-82#													
EMS121	53-79	53-88	53-97	53-99	57-83#										
EMS122	53-80	53-89	57-84#												
EMS123	53-81	53-88	53-89	53-90	53-90	53-91	53-92	53-93	53-94	53-95	53-96	53-98	53-126	57-85#	
EMS124	53-56	53-82	53-91	53-101	57-86#										
EMS125	53-83	53-92	53-102	53-169	57-87#										
EMS126	53-84	53-93	53-103	57-88#											
EMS127	57-89#														
EMS13	53-13	53-42	53-216	57-13#											
EMS130	53-86	53-95	53-106	57-90#											
EMS131	53-87	53-96	53-104	57-91#											
EMS132	53-79	53-80	53-81	53-82	53-83	53-84	53-85	53-86	53-87	53-88	53-89	53-90	53-91	53-92	
	53-93	53-94	53-95	53-96	53-97	53-98	53-99	53-100	53-101	53-102	53-103	53-104	53-105	53-106	
	53-125	53-126	53-168	53-169	57-92#										
EMS133	53-79	53-80	53-81	53-82	53-83	53-84	53-85	53-86	53-87	53-125	57-93#				
EMS134	53-88	53-89	53-90	53-91	53-92	53-93	53-94	53-95	53-96	53-126	57-94#				
EMS135	53-97	53-98	57-95#												
EMS136	53-99	53-100	53-101	53-102	53-103	53-104	53-105	53-106	57-96#						
EMS137	53-85	53-94	53-100	57-97#											
EMS14	53-13	57-14#													
EMS140	53-44	53-52	53-60	53-107	53-117	53-137	53-186	53-192	57-98#						
EMS141	53-35	53-44	53-45	53-60	53-61	53-66	53-107	53-122	53-137	53-187	53-188	53-193	53-222	57-99#	
EMS142	53-47	53-65	53-108	53-140	53-184	53-202	57-100#								
EMS143	53-47	53-65	53-73	53-108	53-109	53-110	53-133	53-140	53-184	53-202	53-205	57-101#			
EMS144	53-36	53-73	53-109	53-110	53-205	57-102#									
EMS145	53-36	53-73	53-109	53-110	53-205	57-103#									
EMS146	53-109	53-185	53-190	53-201	57-104#										
EMS147	53-69	53-112	53-113	53-173	53-217	57-105#									
EMS15	53-13	53-42	53-216	57-15#											
EMS150	53-50	53-51	53-54	53-63	53-67	53-111	53-134	53-138	53-182	53-183	53-194	53-195	53-223	53-234	
	57-106#														
EMS151	53-69	53-112	53-113	53-173	53-217	57-107#									
EMS152	53-50	53-51	53-54	53-63	53-111	53-134	53-182	53-183	53-194	53-195	53-223	57-108#			

EMT101	8-200	53-67#
EMT102	8-203	53-68#
EMT103	8-206	53-69#
EMT104	8-209	53-70#
EMT105	8-212	53-71#
EMT106	8-215	53-72#
EMT107	8-218	53-73#
EMT11	8-27	53-11#
EMT110	8-221	53-74#
EMT111	8-224	53-75#
EMT112	8-227	53-76#
EMT113	8-230	53-77#
EMT114	8-233	53-78#
EMT115	8-236	53-79#
EMT116	8-239	53-80#
EMT117	8-242	53-81#
EMT12	8-30	53-12#
EMT120	8-245	53-82#
EMT121	8-248	53-83#
EMT122	8-251	53-84#
EMT123	8-254	53-85#
EMT124	8-257	53-86#
EMT125	8-260	53-87#
EMT126	8-263	53-88#
EMT127	8-266	53-89#
EMT13	8-33	53-13#
EMT130	8-269	53-90#
EMT131	8-272	53-91#
EMT132	8-275	53-92#
EMT133	8-278	53-93#
EMT134	8-281	53-94#
EMT135	8-284	53-95#
EMT136	8-287	53-96#
EMT137	8-290	53-97#
EMT14	8-36	53-14#
EMT140	8-293	53-98#
EMT141	8-296	53-99#
EMT142	8-299	53-100#
EMT143	8-302	53-101#
EMT144	8-305	53-102#
EMT145	8-308	53-103#
EMT146	8-311	53-104#
EMT147	8-314	53-105#
EMT15	8-39	53-15#
EMT150	8-317	53-106#
EMT151	8-320	53-107#
EMT152	8-323	53-108#
EMT153	8-326	53-109#
EMT154	8-329	53-110#
EMT155	8-332	53-111#
EMT156	8-335	53-112#
EMT157	8-338	53-113#
EMT16	8-42	53-16#
EMT160	8-341	53-114#
EMT161	8-344	53-115#
EMT162	8-347	53-116#
EMT163	53-117#	

EMT164	8-354	53-118#
EMT165	8-357	53-119#
EMT166	8-360	53-120#
EMT167	8-363	53-121#
EMT17	8-45	53-17#
EMT170	8-366	53-122#
EMT171	8-369	53-123#
EMT172	8-372	53-124#
EMT173	8-375	53-125#
EMT174	8-378	53-126#
EMT175	8-381	53-127#
EMT176	8-384	53-128#
EMT177	53-129#	
EMT2	8-6	53-4#
EMT20	8-48	53-18#
EMT200	8-390	53-130#
EMT201	8-393	53-131#
EMT202	8-396	53-132#
EMT203	8-399	53-133#
EMT204	8-402	53-134#
EMT205	8-405	53-135#
EMT206	8-408	53-136#
EMT207	8-411	53-137#
EMT21	8-51	53-19#
EMT210	8-414	53-138#
EMT211	8-417	53-139#
EMT212	8-420	53-140#
EMT213	8-423	53-141#
EMT214	8-426	53-142#
EMT215	8-429	53-143#
EMT216	8-432	53-144#
EMT217	8-435	53-145#
EMT22	8-54	53-20#
EMT220	8-438	53-146#
EMT221	8-441	53-147#
EMT222	8-444	53-148#
EMT223	8-447	53-149#
EMT224	53-150#	
EMT225	53-151#	
EMT226	53-152#	
EMT227	53-153#	
EMT23	8-57	53-21#
EMT230	53-154#	
EMT231	53-155#	
EMT232	53-156#	
EMT233	53-157#	
EMT234	53-158#	
EMT235	53-159#	
EMT236	53-160#	
EMT237	53-161#	
EMT24	8-60	53-22#
EMT240	53-162#	
EMT241	53-163#	
EMT242	53-164#	
EMT243	53-165#	
EMT244	53-166#	
EMT245	53-167#	

EMT246	8-504	53-168#
EMT247	8-507	53-169#
EMT25	8-63	53-23#
EMT250	8-510	53-170#
EMT251	8-513	53-171#
EMT252	8-516	53-172#
EMT253	8-519	53-173#
EMT254	8-522	53-174#
EMT255	8-525	53-175#
EMT256	8-528	53-176#
EMT257	8-531	53-177#
EMT26	8-66	53-24#
EMT260	8-534	53-178#
EMT261	8-537	53-179#
EMT262	8-540	53-180#
EMT263	8-543	53-181#
EMT264	8-546	53-182#
EMT265	8-549	53-183#
EMT266	8-552	53-184#
EMT267	8-556	53-185#
EMT27	8-69	53-25#
EMT270	8-559	53-186#
EMT271	8-563	53-187#
EMT272	8-566	53-188#
EMT273	8-569	53-189#
EMT274	8-573	53-190#
EMT275	8-577	53-191#
EMT276	8-581	53-192#
EMT277	8-586	53-193#
EMT3	8-9	53-5#
EMT30	8-72	53-26#
EMT300	8-590	53-194#
EMT301	8-594	53-195#
EMT302	8-597	53-196#
EMT303	8-600	53-197#
EMT304	8-603	53-198#
EMT305	8-606	53-199#
EMT306	8-609	53-200#
EMT307	8-612	53-201#
EMT31	8-75	53-27#
EMT310	8-615	53-202#
EMT311	8-618	53-203#
EMT312	8-621	53-204#
EMT313	8-624	53-205#
EMT314	8-627	53-206#
EMT315	8-630	53-207#
EMT316	8-633	53-208#
EMT317	8-636	53-209#
EMT32	8-78	53-28#
EMT320	8-639	53-210#
EMT321	8-642	53-211#
EMT322	8-645	53-212#
EMT323	8-648	53-213#
EMT324	8-651	53-214#
EMT325	8-654	53-215#
EMT326	8-657	53-216#
EMT327	8-660	53-217#

EMT33	8-81	53-29#	
EMT330	8-663	53-218#	
EMT331	8-666	53-219#	
EMT332	8-669	53-220#	
EMT333	8-672	53-221#	
EMT334	8-675	53-222#	
EMT335	8-678	53-223#	
EMT336	8-351	8-681	53-224#
EMT337	8-684	53-225#	
EMT34	8-84	53-30#	
EMT340	8-687	53-226#	
EMT341	8-690	53-227#	
EMT342	8-693	53-228#	
EMT343	8-696	53-229#	
EMT344	8-699	53-230#	
EMT345	8-702	53-231#	
EMT346	8-705	53-232#	
EMT347	8-708	53-233#	
EMT35	8-87	53-31#	
EMT350	8-711	53-234#	
EMT351	8-714	53-235#	
EMT352	8-717	53-236#	
EMT353	8-720	53-237#	
EMT354	8-723	53-238#	
EMT36	8-90	53-32#	
EMT37	8-93	53-33#	
EMT4	8-12	53-6#	
EMT40	8-96	53-34#	
EMT41	8-99	53-35#	
EMT42	8-102	53-36#	
EMT43	8-105	53-37#	
EMT44	8-108	53-38#	
EMT45	8-111	53-39#	
EMT46	8-114	53-40#	
EMT47	8-117	53-41#	
EMT5	8-15	53-7#	
EMT50	8-120	53-42#	
EMT51	8-123	53-43#	
EMT52	8-126	53-44#	
EMT53	8-130	53-45#	
EMT54	8-133	53-46#	
EMT55	8-136	53-47#	
EMT56	8-139	53-48#	
EMT57	8-142	53-49#	
EMT6	8-18	53-8#	
EMT60	8-146	53-50#	
EMT61	8-150	53-51#	
EMT62	8-154	53-52#	
EMT63	53-53#		
EMT64	8-160	53-54#	
EMT65	8-163	53-55#	
EMT66	8-166	53-56#	
EMT67	8-169	53-57#	
EMT7	8-21	53-9#	
EMT70	8-172	53-58#	
EMT71	8-175	53-59#	
EMT72	8-178	53-60#	

RESVEC	4-484#														
REX	4-624#														
RG	4-622#														
RGDTP	52-3#														
RH	4-526#	13-105	13-208	13-522	13-;99	13-<82	13-=66	13->05	13->51	13->92	13-?48	13-?97	13-A11	13-B16	
	13-C00	13-C96	13-E59	16-182											
RIP	4-508#														
RELEASE	4-505#														
RMAS	4-694#														
RMASI	7-0#	34-50	59-13												
RMASO	7-0#														
RMBA	4-766#	13-11*	13-12	13-83	13-185	13-282	13-375	13-500	13-596	13-689	13-813	13-908	13-:04	13-:00	
	13-;76	13-<59	13-=43	13->14	13->61	13-?05	13-?61	13-a10	13-a76	13-A15	13-A84	13-B73	13-C73	13-D87	
	13-E36	13-F19	16-68												
RMBAE	4-769#														
RMBAEI	7-0#														
RMBAEO	7-0#														
RMBAI	7-0#	13-430	13-742	26-32	26-34	31-44	59-14								
RMBAO	7-0#	13-40*	13-106*	13-141*	13-209*	13-239*	13-332*	13-457*	13-523*	13-553*	13-646*	13-770*	13-864*	13-959*	
	13-:54*	13-:55*	13-<00*	13-<38*	13-<83*	13-=21*	13-=67*	13->04*	13->50*	13->90*	13-?47*	13-?96*	13-a46*	13-A12*	
	13-A42*	13-A53*	13-B17*	13-B52*	13-B99*	13-C44*	13-C97*	13-D75*	13-E07*	13-E60*	13-F08*	16-61*	16-253	16-256*	
	17-21	18-31	26-26	26-30											
RMCS1	4-690#	4-764#	10-89	13-8*	13-60	13-84	13-161	13-186	13-259	13-283	13-352	13-376	13-477	13-501	
	13-573	13-597	13-666	13-690	13-790	13-814	13-885	13-909	13-981	13-:05	13-:76	13-:01	13-:77	13-<60	
	13-=44	13->16	13->62	13-?06	13-?62	13-a11	13-a66	13-a77	13-A03	13-A16	13-A85	13-B74	13-C74	13-D88	
	13-E37	13-F21	15-126	15-188	16-69	20-42	21-36	23-20	28-28						
RMCS1I	7-0#	16-209	24-67	24-69	24-71	24-88	24-90	24-93	24-104	24-108	24-110	24-122	24-124	24-126	
	25-51	25-53	25-64	25-107	26-12	31-31	34-16	35-27	35-29	35-31	59-13				
RMCS10	7-0#	13-41*	13-55*	13-80*	13-105*	13-142*	13-156*	13-182*	13-208*	13-240*	13-254*	13-279*	13-304*	13-333*	
	13-347*	13-372*	13-400*	13-458*	13-472*	13-497*	13-522*	13-554*	13-568*	13-593*	13-618*	13-647*	13-661*	13-686*	
	13-714*	13-771*	13-785*	13-810*	13-835*	13-865*	13-880*	13-905*	13-930*	13-960*	13-976*	13-:01*	13-:26*	13-:55*	
	13-:71*	13-:97*	13-:22*	13-:56*	13-:70*	13-:99*	13-<39*	13-<53*	13-<82*	13-=22*	13-=37*	13-=66*	13->05*	13->51*	
	13->92*	13-?48*	13-?97*	13-a47*	13-a61*	13-a73*	13-a98*	13-A11*	13-A54*	13-A76*	13-B16*	13-B53*	13-B67*	13-C00*	
	13-C45*	13-C67*	13-C96*	13-D76*	13-D81*	13-E08*	13-E30*	13-E59*	13-F09*	13-F14*	15-125*	15-185*	16-87*	16-119*	
	16-153*	16-182*	16-304	17-26	25-28	26-48	35-320	35-340							
RMCS2	4-767#	10-84*	10-85*	10-87	12-58*	12-59*	13-13	13-14*	13-15	13-16*	20-41	21-35	28-27*	28-29	
	30-16*	30-18*													
RMCS2I	7-0#	13-416	13-421	13-423	13-730	13-734	13-736	24-49	24-74	24-76	24-77	25-99	25-170	25-271	
	25-314	25-329	25-344	25-455	26-28	31-53	35-50	35-63	35-65	35-67	35-438	35-440	35-442	35-492	
	35-494	35-496	59-13												
RMCS20	7-0#														
RMCS3	4-770#														
RMCS3I	7-0#														
RMCS3O	7-0#														
RMDA	4-691#	13-57	13-158	13-256	13-349	13-474	13-570	13-663	13-787	13-882	13-978	13-:73	13-:72	13-<55	
	13-=39	13->11	13->57	13-?01	13-?57	13-a06	13-a63	13-A00	13-A80	13-B69	13-C69	13-D83	13-E32	13-F16	
	15-187	16-64													
RMDAI	7-0#	26-137	59-14	59-16											
RMDAO	7-0#	13-38*	13-138*	13-236*	13-329*	13-454*	13-550*	13-643*	13-768*	13-860*	13-861*	13-869	13-955*	13-956*	
	13-964	13-:51*	13-:51*	13-:60	13-<24*	13-<25	13-<34*	13-<43	13-=07*	13-=08	13-=17*	13-=99*	13->00*	13->44*	
	13->45*	13->88*	13-?28*	13-?29	13-?34*	13-?43*	13-?44*	13-?84*	13-?85	13-?93*	13-a43*	13-a51	13-A50*	13-A58	
	13-B48*	13-C42*	13-E04*	15-184*	16-58*	16-232*	16-233	16-235	16-255*	16-299	16-397*	17-24	26-60	26-61	
	29-53	29-56	29-60	35-178	35-181	35-185									
RMDB	4-768#	13-17*	13-18	13-434	13-746	19-20									
RMDBI	7-0#	13-438	13-750												
RMDBO	7-0#														
RMDC	4-700#	13-58	13-159	13-257	13-350	13-475	13-571	13-664	13-788	13-883	13-979	13-:74	13-:73	13-<56	

	13-40	13->12	13->58	13-?02	13-?58	13-a07	13-a64	13-A01	13-A81	13-B70	13-C70	13-D84	13-E33	13-F17
RMDCI	15-186	16-65												
RMDCO	7-0#	26-150	59-14	59-16										
	7-0#	13-37*	13-137*	13-235*	13-328*	13-453*	13-549*	13-642*	13-767*	13-859*	13-954*	13-:50*	13-:69	13-:70*
	13-:96*	13-:50*	13-<33*	13-16*	13-26	13-89*	13-90	13-98*	13->48*	13->87*	13-?42*	13-?92*	13-a33*	13-a34
RMDS	13-a42*	13-A49*	13-B47*	13-C41*	13-E03*	15-183*	16-57*	16-298	16-396*	17-23	26-59	29-49	35-174	
RMDSI	4-692#	10-86	10-109											
	7-0#	15-122	15-180	16-116	16-150	24-106	25-38	25-40	25-85	25-102	25-136	25-140	25-196	25-223
	25-358	26-92	29-91	29-146	29-155	29-162	29-166	29-168	29-177	29-181	29-183	29-192	29-194	29-196
	29-206	29-210	29-212	31-126	32-23	32-25	32-27	32-37	32-39	32-41	33-68	33-106	33-144	33-153
	33-157	33-159	33-169	33-173	33-174	33-185	33-187	33-189	33-201	33-203	33-205	33-216	33-220	33-222
	34-28	35-88	35-90	35-119	35-252	35-318	35-453	35-455	35-457	35-504	35-511	35-515	35-517	35-528
	35-532	35-534	35-544	35-548	35-550	36-34	36-40	36-44	36-46	36-56	36-60	36-61*	36-62	36-72
	36-76	36-78	59-13											
RMDSO	7-0#													
RMDT	4-697#	10-91	12-60	44-26										
RMDTI	7-0#	59-5	59-17											
RMDTO	7-0#													
RMEC1	4-704#													
RMEC1I	7-0#	18-32	59-14											
RMEC10	7-0#													
RMEC2	4-705#	19-15												
RMEC2I	7-0#	18-53	19-14	31-94	34-94	59-15								
RMEC20	7-0#													
RMER1	4-693#	24-145												
RMER1I	7-0#	13-C16	13-C21	13-C22	13-D17	13-D22	13-D23	13-D43	13-D48	13-D49	13-E76	13-E81	13-E82	16-222
	18-23	18-25	24-137	24-152	24-154	25-80	25-156	25-183	25-226	25-241	25-284	25-361	25-387	25-402
	25-417	25-470	25-489	25-492	26-89	26-105	26-120	26-132	27-24	29-30	29-37	29-66	29-140	29-143
	29-164	31-71	32-51	32-55	32-57	32-58	32-69	32-71	32-72	32-83	32-85	32-86	32-97	32-99
	32-100	32-111	32-113	32-114	33-24	33-29	33-33	33-35	33-45	33-47	33-49	33-61	33-63	33-65
	33-78	33-80	33-82	33-155	33-232	33-236	33-238	33-240	33-250	33-252	33-254	33-264	33-268	33-270
	34-41	35-41	35-45	35-47	35-83	35-85	35-87	35-128	35-131	35-133	35-135	35-145	35-147	35-149
	35-159	35-161	35-163	35-189	35-279	35-282	35-286	35-288	35-297	35-299	35-301	35-311	35-313	35-314
	35-348	35-352	35-354	35-356	35-365	35-367	35-369	35-378	35-380	35-382	35-391	35-393	35-395	35-413
	35-415	35-417	35-423	35-479	35-481	35-483	35-530	36-42	59-13					
RMER10	7-0#	24-141												
RMER2	4-703#													
RMER2I	7-0#	13-B01	13-B03	13-B04	13-B32	13-B34	13-B35	13-D30	13-D35	13-D36	15-55	16-84	16-225	24-139
	25-82	25-200	25-256	25-432	27-27	29-32	29-85	29-88	29-99	29-127	29-130	29-179	29-208	31-116
	33-31	33-92	33-99	33-101	33-103	33-116	33-118	33-120	33-130	33-132	33-134	33-171	33-218	33-266
	34-103	35-43	35-111	35-114	35-116	35-203	35-207	35-232	35-236	35-238	35-240	35-250	35-254	35-256
	35-266	35-268	35-270	35-284	35-466	35-468	35-470	35-513	35-546	36-58	36-74	36-88	36-94	36-96
	36-98	36-108	36-110	36-112	59-13									
RMER20	7-0#													
RMHR	4-701#													
RMHRI	7-0#													
RMHRO	7-0#													
RMLA	4-695#													
RMLAI	7-0#	59-16												
RMLAO	7-0#													
RMMR1	4-696#	13-A69	13-A79											
RMMR1I	7-0#	31-81	34-69	59-17										
RMMR10	7-0#	13-A68*	13-A77*											
RMMR2	4-702#													
RMMR2I	7-0#	31-103	34-81	59-17										
RMMR20	7-0#													
RMOF	4-699#	13-59	13-160	13-258	13-351	13-476	13-572	13-665	13-789	13-8E	13-980	13-:75	13-:74	13-<57

STCDRV	36-27#													
STKLMT	4-484#													
STUP	42-1	42-5#												
STSD1	55-1	55-2	55-8	55-10	55-11	55-12	59-13#							
STSD2	55-1	55-2	55-8	55-10	55-11	55-12	59-14#							
STSD3	59-16#													
STSD4	55-1	55-2	55-8	55-10	55-11	55-12	59-17#							
STSF	56-1	56-1	56-1	56-2	56-2	56-2	56-8	56-8	56-8	56-10	56-10	56-10	56-11	56-11
	56-11	56-12	56-12	56-12	60-7#									
STSH1	54-1	54-2	54-8	54-9	54-11	54-12	54-13	58-21#						
STSH2	54-1	54-2	54-8	54-9	54-11	54-12	54-13	58-23#						
STSH3	58-25#													
STSH4	54-1	54-2	54-8	54-9	54-11	54-12	54-13	58-26#						
SW0	4-484#													
SW00	4-484	4-484#												
SW01	4-484	4-484#												
SW02	4-484	4-484#												
SW03	4-484	4-484#												
SW04	4-484	4-484#												
SW05	4-484	4-484#												
SW06	4-484	4-484#												
SW07	4-484	4-484#												
SW08	4-484	4-484#												
SW09	4-484	4-484#												
SW1	4-484#													
SW10	4-484#													
SW11	4-484#													
SW12	4-484#													
SW13	4-484#	16-245	44-14											
SW14	4-484#													
SW15	4-484#													
SW2	4-484#													
SW3	4-484#													
SW4	4-484#													
SW5	4-484#													
SW6	4-484#													
SW7	4-484#													
SW8	4-484#													
SW9	4-484#													
SWR	6-0#	10-23	10-23	10-23*	10-23*	10-23*	10-28	16-245	42-1	42-1	42-1	42-1	42-1	42-1
	42-1*	42-1*	42-1*	42-1*	43-1	43-1	43-1	43-1	43-1	44-14	45-1	45-1	45-1*	48-1
	48-1*													
SWREG	5-1#	10-23	10-28	45-1	45-1	45-1								
SYSTAT	10-76	49-23#												
TA1	4-537#													
TA16	4-533#	12-64												
TA2	4-536#	12-64												
TA4	4-535#	12-56												
TA8	4-534#													
TADMSK	4-547#	26-66												
TAG	4-664#													
TAGADR	5-9#	6-0												
TAP	4-641#													
TBITVE	4-484#													
TIMOUT	13-68	13-91	13-112	13-169	13-193	13-215	13-267	13-290	13-310	13-360	13-383	13-406	13-485	13-508
	13-529	13-581	13-604	13-624	13-674	13-697	13-720	13-798	13-821	13-841	13-893	13-916	13-936	13-989
	13-:12	13-:32	13-:84	13-:08	13-:28	13-:85	13-<06	13-<68	13-<89	13-=53	13-=72	13->26	13->70	13-?14

UNTOFF	10-120	49-31#												
UNTON	10-131	49-32#												
UPE	4-729#	25-270												
USE	4-686#	13-D11	17-29											
USRFIL	16-253	16-256	16-266*	16-274*	16-325	61-12#								
VV	4-561#	15-122	16-116	25-196	29-91	29-156	29-157	29-206	29-211	32-23	32-26	33-106	33-145	33-146
	33-169	33-175	34-29	35-90	35-119	35-505	35-506	35-544	35-549	36-35	36-36	36-56	36-61	
WC	4-631#	31-82	34-70											
WCD	4-517#													
WCE	4-728#	13-416	13-422	13-730	13-735	25-169	50-77	50-78						
WCEHI	4-753#													
WCELO	4-754#													
WCF	4-576#	4-583	25-240	35-479	35-482									
WCH	4-518#	13-304	13-400	13-618	13-714	13-835	13-930	13-:26	13-:22					
WD	4-521#													
WH	4-522#	13-41	13-80	13-142	13-182	13-240	13-279	13-333	13-372	13-458	13-497	13-554	13-593	13-647
	13-686	13-771	13-810	13-865	13-905	13-960	13-:01	13-:55	13-:97	13-:56	13-:70	13-<39	13-<53	13-=22
	13-=37	13-@47	13-@73	13-A54	13-A76	13-B53	13-B67	13-C45	13-C67	13-D76	13-D81	13-E08	13-E30	13-F09
	13-F14	35-342												
WLE	4-570#	4-583	25-221	25-225	25-238	25-253	25-268	35-279	35-311	35-315	35-323	50-81	50-82	
WRL	4-556#	25-223	35-318											
XSIZ	10-70#	11-71	11-101											
XXDP	7-0#	10-33*	10-36*	10-37	10-39*	10-44	10-55	10-124	10-126					
Y	49-36#													
ZEROS	13-45	13-146	13-244	13-337	13-775	13-871	13-966	13-:59	13-B57	13-C49	13-E12	52-38#		

\$\$CMRE	5-10#													
\$\$CMTM	5-10#	6-0	6-0	6-0	6-0	6-0								
\$\$ESCA	4-484#													
\$\$NEWT	4-484#	13-1	13-32	13-134	13-232	13-325	13-450	13-546	13-639	13-763	13-856	13-951	13-:47	13-:47
	13-<30	13-=13	13-=95	13->41	13->85	13-?40	13-?90	13-@39	13-A46	13-B44	13-C34	13-D97		
\$\$SET	47-1	47-1	47-1	47-1	47-1	47-1	47-1	47-1	47-1	47-1	47-1	47-1	47-1	47-1#
\$\$SETM	10-23	10-23#												
\$\$SKIP	4-484#													
.\$ACT1	4-476#	5-5												
.\$APTB	4-476#	6-0	6-0#											
.\$APTH	4-476#	5-8												
.\$APTY	4-476#	48-2												
.\$CATC	4-472#	5-1												
.\$CMTA	4-473#	5-10												
.\$EOP	4-473#	14-20												
.\$ERRO	4-473#	43-1												
.\$POWE	4-475#	48-1												
.\$RDDE	4-474#													
.\$RDOC	4-474#	46-1												
.\$READ	4-474#	45-1												
.\$SAVE	4-475#	37-1												
.\$SCOP	4-473#	42-1												
.\$SIZE	4-475#													
.\$TRAP	4-475#	47-1												
.\$TYPB	4-474#	38-1												
.\$TYPD	4-474#	39-1												
.\$TYPE	4-473#	41-1												
.\$TYPO	4-474#	40-1												
.\$EQUAT	4-472#	4-484												
.\$HEADE	4-472#	4-480												
.\$SETUP	4-472#	4-775												
.\$SWRHI	4-472#	4-481												
.\$SWRLO	4-472#	4-481#	4-482											
CAL CLR	4-187#													
CAL SUB	4-201#	13-43	13-51	13-63	13-72	13-76	13-87	13-93	13-97	13-99	13-101	13-108	13-114	13-118
	13-120	13-122	13-126	13-144	13-152	13-164	13-173	13-177	13-189	13-195	13-199	13-201	13-203	13-211
	13-217	13-221	13-223	13-225	13-229	13-242	13-250	13-262	13-271	13-275	13-286	13-292	13-296	13-298
	13-300	13-306	13-312	13-316	13-318	13-320	13-335	13-343	13-355	13-364	13-368	13-379	13-385	13-389
	13-391	13-393	13-402	13-408	13-412	13-419	13-437	13-460	13-468	13-480	13-489	13-493	13-504	13-510
	13-514	13-516	13-518	13-525	13-531	13-535	13-537	13-539	13-543	13-556	13-564	13-576	13-585	13-589
	13-600	13-606	13-610	13-612	13-614	13-620	13-626	13-630	13-632	13-634	13-649	13-657	13-669	13-678
	13-682	13-693	13-699	13-703	13-705	13-707	13-716	13-722	13-726	13-733	13-749	13-773	13-781	13-793
	13-802	13-806	13-817	13-823	13-827	13-829	13-831	13-837	13-843	13-847	13-849	13-851	13-867	13-876
	13-888	13-897	13-901	13-912	13-918	13-922	13-924	13-926	13-932	13-938	13-942	13-944	13-946	13-962
	13-972	13-984	13-993	13-997	13-:08	13-:14	13-:18	13-:20	13-:22	13-:28	13-:34	13-:38	13-:40	13-:42
	13-:57	13-:65	13-:79	13-:88	13-:92	13-:04	13-:10	13-:14	13-:16	13-:18	13-:24	13-:30	13-:34	13-:36
	13-:38	13-:58	13-:66	13-:80	13-:87	13-:91	13-:93	13-:95	13-<02	13-<08	13-<12	13-<14	13-<16	13-<20
	13-<41	13-<49	13-<63	13-<70	13-<74	13-<76	13-<78	13-<85	13-<91	13-<95	13-<97	13-<99	13-=03	13-=24
	13-=33	13-=46	13-=54	13-=58	13-=60	13-=62	13-=68	13-=73	13-=77	13-=79	13-=81	13-=85	13->08	13->21
	13->28	13->32	13->34	13->36	13->54	13->65	13->72	13->76	13->78	13->80	13->96	13-?09	13-?16	13-?20
	13-?22	13-?24	13-?52	13-?65	13-?72	13-?76	13-?78	13-?80	13-@01	13-@14	13-@21	13-@25	13-@27	13-@29
	13-@49	13-@57	13-@69	13-@80	13-@87	13-@91	13-@93	13-@95	13-A06	13-A19	13-A25	13-A29	13-A31	13-A33
	13-A37	13-A56	13-A64	13-A72	13-A88	13-A95	13-A99	13-B08	13-B12	13-B19	13-B26	13-B30	13-B39	13-B55
	13-B63	13-B77	13-B84	13-B88	13-B90	13-B92	13-C02	13-C08	13-C12	13-C19	13-C26	13-C47	13-C55	13-C77
	13-C84	13-C88	13-C90	13-C92	13-C99	13-D05	13-D09	13-D20	13-D33	13-D46	13-D58	13-D79	13-D90	13-E10
	13-E18	13-E40	13-E47	13-E51	13-E53	13-E55	13-E62	13-E68	13-E72	13-E79	13-E91	13-F12	13-F23	

