

RM02/03/05

RM05/3/2 FCTNL TST 3
CZRM0B0

AH-F928B-MC
FICHE 1 OF 2

AUG 1981
COPYRIGHT © 80-81
MADE IN USA



RM02/03/05

RM05/3/2 FCTNL TST 3
CZRM0B0

AH-F928B-MC
FICHE 2 OF 2

AUG 1981
COPYRIGHT © 80-81
MADE IN USA



.REM \

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44

IDENTIFICATION

PRODUCT CODE: AC-F927B-MC
PRODUCT NAME: CZRM0B0 RM05/3/2 FUNCTIONAL TEST, PT 3
PRODUCT DATE: APRIL 1981
MAINTAINER: CX DIAGNOSTIC GROUP
AUTHOR: MIKE LEAVITT

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS MANUAL.

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED UNDER A LICENSE AND MAY ONLY BE USED OR COPIED IN ACCORDANCE WITH THE TERMS OF SUCH LICENSE.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

COPYRIGHT (C) 1980,1981 DIGITAL EQUIPMENT CORPORATION

CONTENTS

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43

- 1. INTRODUCTION
 - 1. ABSTRACT
 - 2. UNIT UNDER TEST
- 2. OPERATING REQUIREMENTS
 - 1. HARDWARE REQUIREMENTS
 - 2. MEDIA REQUIREMENTS
 - 3. PREREQUISITE DIAGNOSTIC PROGRAMS
- 3. OPERATING PROCEDURE
 - 1. LOADING
 - 2. SWITCH OPTIONS
 - 3. STARTING
 - 4. HALTING
 - 5. RESTARTING
- 4. OPERATOR INTERFACE
 - 1. PROGRAM I.D.
 - 2. CONSOLE DIALOGUE
 - 3. PROGRESS REPORTS
 - 4. PERFORMANCE REPORTS
 - 5. PROGRAM HALTS
 - 6. ERROR REPORTS
 - 7. EXECUTION TIME
- 5. ENVIRONMENTAL SUPPORT
 - 1. PROCESSOR COMPATIBILITY
 - 2. DUAL PORT CONFIGURATIONS
 - 3. MEMORY PARITY HARDWARE
 - 4. MEMORY MANAGEMENT HARDWARE
 - 5. ACT, APT COMPATIBILITY
 - 6. XXDP COMPATIBILITY
 - 7. OPERATING SYSTEM COMPATIBILITY
- 6. TEST DESCRIPTION

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57

1.0 INTRODUCTION

1.1 ABSTRACT

THE RM05/3/2 SUBSYSTEM FUNCTIONAL TEST IS A STAND ALONE PROGRAM WHICH USES FUNCTIONAL MEANS TO VERIFY THE OPERABILITY OF THE RM05/3/2 DISK SUBSYSTEM. IN PARTICULAR, THE PROGRAM SERVES THE FOLLOWING PURPOSES:

TO EXPLICITLY ESTABLISH CONFIDENCE IN THE BASIC OPERATIONS OF THE DISK DRIVE, INCLUDING MECHANICAL POSITIONING AND DATA TRANSFER OPERATIONS;

TO IMPLICITLY ESTABLISH CONFIDENCE IN THE DRIVE/ADAPTER ELECTRICAL INTERFACE;

TO VERIFY THE FUNCTIONALITY OF THE RM05/3/2 SUBSYSTEM, INCLUDING THE MASSBUS CONTROLLER, MASSBUS ADAPTER AND THE DISK DRIVE.

THE TEST IS COMPRISED OF 3 PARTS, WHICH WOULD NORMALLY BE RUN IN SEQUENCE, STARTING WITH PART 1. BRIEFLY, PART 1 TESTS HOUSEKEEPING AND MECHANICAL POSITIONING OPERATIONS; PART 2 TESTS WRITE, READ AND WRITE CHECK OPERATIONS USING HEADER AND DATA; PART 3 TESTS WRITE, READ AND WRITE CHECK OPERATIONS USING DATA.

1.2 UNIT UNDER TEST

THE UNIT UNDER TEST (UUT) IS THE RM05/3/2 DISK SUBSYSTEM WHICH CONSISTS OF THE RH MASSBUS CONTROLLER, THE RM05/3/2 MASSBUS ADAPTER, AND THE STORAGE MODULE DISK DRIVE. NOTE THAT A DISK PACK IS REQUIRED FOR TESTING AND IS CONSIDERED AN INTEGRAL OF THE STORAGE MODULE DISK DRIVE.

2.0 OPERATING REQUIREMENTS

2.1 HARDWARE REQUIREMENTS

THE FOLLOWING MINIMUM HARDWARE CONFIGURATION, ASSUMED TO BE OPERATIONAL, IS REQUIRED TO LOAD AND EXECUTE THE RM05/3/2 SUBSYSTEM FUNCTIONAL TEST:

PDP-11 PROCESSOR
20K MEMORY
KW11-L OR KW11-P CLOCK
PROGRAM LOADING DEVICE
TERMINAL
RH11 OR RH70 CONTROLLER
1 TO 8 DISK DRIVES (ANY COMBINATION OF RM05'S, RM03'S OR RM02'S)

58
59
60
61
62
63
64
65
66
67
68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114

2.2 MEDIA REQUIREMENTS

EACH UNIT BEING TESTED MUST BE LOADED WITH A SCRATCH DISK PACK BEFORE TESTING BEGINS ON THAT UNIT. THE DISK MUST BE FORMATTED AND CONTAIN A READABLE COPY OF THE MFG AND USR BAD SECTOR FILES.

2.3 PREREQUISITE DIAGNOSTIC PROGRAMS

RM05/3/2 DISKLESS TEST, PART 1 & 2

RM05/3/2 FUNCTIONAL TEST, PART 1 & 2

3.0 OPERATING PROCEDURE

3.1 LOADING

THE PROGRAM MAY BE LOADED BY EITHER OF THE FOLLOWING MEDIA:

.PAPER TAPE, USING THE STANDARD PAPER TAPE LOADING PROCEDURE.
.XXDP MEDIA, USING THE APPROPRIATE LOADING DEVICE.

3.2 SWITCH OPTIONS

THE FOLLOWING SWITCH OPTIONS ARE PROVIDED TO ENHANCE THE UTILITY OF THE PROGRAM.

SW15	HALT ON ERROR
SW14	LOOP ON TEST (CURRENTLY BEING EXECUTED)
SW13	INHIBIT ERROR TYPEOUTS
SW12	UNUSED
SW11	INHIBIT TEST ITERATIONS
SW10	BELL ON ERROR
SW09	LOOP ON ERROR
SW08	LOOP ON TEST IN SW07-00

THE LOW ORDER 8 SWITCHES (SW07-SW00), ARE USED IN CONJUNCTION WITH SW08 TO SPECIFY THE OCTAL NUMBER OF THE TEST WHICH THE PROGRAM WILL LOOP ON.

3.3 STARTING

THE PROGRAM MAY BE STARTED AT LOCATION 200 OR 204. STARTING AT 200 WILL BE THE NORMAL STARTING ADDRESS. STARTING AT 204 WILL ENABLE THE RH/RM BASE ADDRESS TO BE CHANGED. IF RUNNING IN A STAND-ALONE ENVIRONMENT, THE PROGRAM USES CONSOLE DIALOGUE TO ALLOW THE OPERATOR TO CONTROL TEST CONDITIONS.

115
116
117
118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167
168
169
170
171

3.4 HALTING

THE PROGRAM SHOULD BE HALTED BY TYPING CONTROL C FROM THE CONSOLE.

NOTE: IF THE PROGRAM IS HALTED BY ANY OTHER MEANS, BAD HEADER INFORMATION MAY BE LEFT ON THE DISK PACK. THIS OF COURSE DEPENDS ON WHICH TEST IS BEING PERFORMED AT THE TIME OF THE HALT.

3.5 RESTARTING

THE PROGRAM CAN BE RESTARTED AT ADDRESS 200 OR 204. (SEE SECTION 3.3)

4.0 OPERATOR INTERFACE

4.1 PROGRAM ID

THE PROGRAM TYPES ITS TITLE AND MAINDEC NUMBER THE FIRST TIME IT IS STARTED AFTER BEING LOADED. ALSO, A WARNING MESSAGE IS TYPED, NOTIFYING THE OPERATOR OF POSSIBLE HEADER CORRUPTION IF THE PROGRAM IS HALTED IMPROPERLY. THE PROGRAM IDENTIFICATION AND THE WARNING DO NOT OCCUR IF THE PROGRAM IS RESTARTED.

4.2 CONSOLE DIALOGUE

WHEN THE PROGRAM IS RUNNING IN STAND ALONE MODE, IT ENTERS A CONSOLE DIALOGUE SEQUENCE AFTER TYPING THE PROGRAM I.D. AND WARNING MESSAGE. (SEE SECTION 4.1)

THE FIRST QUESTION TYPED OUT IS: "TYPE HELP TEXT (L) N ?". IF THE OPERATOR RESPONDS WITH A 'Y', THE PROGRAM WILL TYPE A BRIEF HELP MESSAGE WHICH WILL LIST SWITCH OPTIONS, ETC. ANY OTHER RESPONSE TO THE QUESTION IS CONSIDERED A 'N' AND NO HELP TEXT IS TYPED. THIS QUESTION IS ONLY ASKED ON THE INITIAL PROGRAM START AND NOT ON SUBSEQUENT START-UP'S.

ON THE PROGRAM INITIAL START AND WHEN RESTARTING AT LOCATION 204, THE OPERATOR MAY CHANGE THE RH/RM BASE ADDRESSES WITH THE FOLLOWING DIALOGUE.

EXAMPLE 1

```
RMCS1=176700 <CR>      ;NO CHANGE IN ADDRESS
RMVEC=000254 <CR>      ;NO CHANGE IN ADDRESS
```

EXAMPLE 2

```
RMCS1=176700 177200<CR> ;CHANGE BASE ADDRESS TO 177200
RMVEC=000254 260<CR>   ;CHANGE VECTOR ADDRESS TO 260
```

172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196
197
198
199
200
201
202
203
204
205
206
207
208
209
210
211
212
213
214
215
216
217
218
219
220
221
222
223
224
225
226
227
228

ON THE INITIAL START, THE NEXT QUESTION TYPED IS, 'TYPE 'A' TO TEST ALL DRIVES, OR TYPE DRIVE NUMBER(S) AND TERMINATE INPUT WITH A CARRIAGE RETURN'. THEN, 'DRIVE(S):' IS TYPED AND WAITS FOR THE OPERATOR TO TYPE AN 'A', TO TEST ALL POSSIBLE DRIVES OR TYPE ANY STRING OF DRIVE NUMBER(S) TO BE TESTED AND TERMINATE THE INPUT WITH A 'CARRIAGE RETURN'. NO COMMAS OR ANY OTHER SEPARATORS ARE NEEDED WHEN ENTERING THE DRIVE NUMBERS AS A STRING. THE PROGRAM ENTERS THE COMMA SEPARTOR AUTOMATICALLY AFTER TYPING EACH NUMBER. ON ALL SUBSEQUENT STARTS, ONLY THE 'DRIVE(S):' PROMPT IS TYPED.

THE DIAGNOSTIC THEN INITIALIZES AND REPORTS THE STATUS OF THE DRIVES WHICH WERE PREVIOUSLY SPECIFIED FOR TESTING. THE FOLLOWING IS AN EXAMPLE PRINTOUT:

```
'UNIT STATUS:
0 ONLINE RM03
1 LOAD DEVICE
2 OFFLINE RM05
3 NOT PRESENT
4 NOT PRESENT
5 NOT AN RM05/3/2
6 NOT PRESENT
7 NOT PRESENT'
```

THE ABOVE UNIT STATUS SHOWS THAT DRIVE 0 WILL BE TESTED, WHILE DRIVES 1 - 7 WILL NOT BE TESTED.

THE DIAGNOSTIC THEN TYPES THE FOLLOWING MESSAGE, BASED ON THE STATUS OF THE DRIVE:

```
'DRIVE(S) TO BE TESTED, 0'
```

IF NO DRIVES ARE AVAILABLE FOR TESTING, THE FOLLOWING MESSAGE WILL BE TYPED TO THE OPERATOR:

```
'DRIVE(S) TO BE TESTED, NONE'
```

THE PROGRAM WILL THEN, EITHER START TESTING THE DRIVES AVAILABLE FOR TESTING OR RETURN TO THE BEGINNING OF THE PROGRAM AND WAIT.

ONCE THE DRIVES START TESTING, THE FOLLOWING MESSAGE WILL OCCUR AS EACH DRIVE BEGINS TO BE TESTED:

```
'DRIVE 0'
```

AFTER ALL THE DRIVES ARE COMPLETELY TESTED, THE END OF PASS MESSAGE WILL BE TYPED (SEE SECTION 4.3) AND THE PROGRAM WILL START TESTING ALL THE DRIVES AGAIN. THIS WILL CONTINUE UNTIL THE PROGRAM IS HALTED BY THE OPERATOR.

NOTE: THE LETTER LOCATED WITHIN THE BRACKETS () INDICATES THE TYPE OF RESPONSE REQUIRED BY THE USER, D=DECIMAL, O=OCTAL AND L=LETTER.

4.3 PROGRESS REPORTS

229
230 AN END OF PASS REPORT OCCURS EACH TIME THE PROGRAM IS EXECUTED
231 FOR ALL DEVICES IN THE TEST QUEUE. THE END OF PASS REPORT IS AS FOLLOWS.
232

233 'END OF PASS 1'
234

235 THE FOLLOWING MESSAGE WILL ALSO OCCUR IF THERE WERE ERRORS SINCE
236 THE LAST END OF PASS REPORT.
237

238 'TOTAL ERRORS SINCE LAST REPORT 0'
239

240
241 4.4 PERFORMANCE REPORT
242

243 NO PERFORMANCE REPORTS ARE GIVEN DURING THE EXECUTION OF THE
244 PROGRAM.
245

246
247
248 4.5 PROGRAM HALTS
249

250 THERE ARE NO SCHEDULED HALTS DURING THE EXECUTION OF THE PROGRAM.
251 PROCESSOR HALTS ARE DUE TO THE TRAP CATCHER.
252

253
254
255 4.6 ERROR REPORTS
256

257 THE FIRST LINE OF THE ERROR REPORT CONTAINS THE NUMBER OF THE
258 UNIT (DRIVE) BEING TESTED, THE DRIVE TYPE, THE TEST NUMBER, THE ERROR
259 NUMBER AND THE VALUE OF THE PROGRAM COUNTER WHERE THE ERROR WAS CALLED.
260 THIS LINE IS FOLLOWED BY THE ERROR MESSAGE: ONE OR MORE LINES OF TEXT
261 WHICH GIVE A BRIEF, YET COMPREHENSIVE DESCRIPTION OF THE ERROR. THE
262 ERROR MESSAGE IS NORMALLY FOLLOWED BY ONE OR MORE PAIRS OF LINES
263 CONTAINING DATA HEADERS AND DATA PERTINENT TO THE ERROR, INCLUDING
264 EXPECTED AND ACTUAL TEST RESULTS.
265

266 THE FOLLOWING PRINTOUT SHOWS A TYPICAL ERROR MESSAGE FOR THIS PROGRAM:
267

268 DRVA 0 - RM03, TEST# 14, ERR# 326, PC=016654
269 MASSBUS DATA BUS PARITY ERROR 'MDPE' (RMCS2, BIT 8) DETECTED
270 DURING WRITE COMMAND
271 EXPECTD RECEVD
272 040300 040700
273 RMCS1 RMCS2 RMDS RMER1 RMER2 RMAS
274 144252 040700 010700 000000 000000 000000
275 RMWC RMBA RMDA RMOF RMDC RMEC1 RMEC2
276 177403 104604 000002 010000 000000 004066 000000
277 RMMR1 RMMR2 RMDT RMSN
278 000010 011777 024026 177777
279

280
281 4.7 EXECUTION TIME
282

283 TIME FOR RM05:
284

285 PASS 1 OF THE PROGRAM TAKES ABOUT 15 SECONDS. PASS 2 AND

286
287
288
289
290
291
292
293
294
295
296
297
298
299
300
301
302
303
304
305
306
307
308
309
310
311
312
313
314
315
316
317
318
319
320
321
322
323
324
325
326
327
328
329
330
331
332
333
334
335
336
337
338
339
340
341
342

SUBSEQUENT PASSES TAKE 1 MINUTES 10 SECONDS.

TIME FOR RM02/3:

PASS 1 OF THE PROGRAM TAKES ABOUT 6 SECONDS. PASS 2 AND
SUBSEQUENT PASSES TAKE 40 SECONDS.

5.0 ENVIRONMENTAL SUPPORT

5.1 PROCESSOR COMPATIBILITY

THE RM05/3/2 SUBSYSTEM FUNCTIONAL TEST IS EXECUTABLE ON ANY PDP-11
PROCESSOR, PROVIDING PREVIOUSLY MENTIONED HARDWARE REQUIREMENTS ARE
MET, AND PROVIDING THAT DATA THROUGHPUT ON THE SYSTEM IS SUFFICIENT TO
SUSTAIN DATA TRANSFER OPERATIONS.

5.2 DUAL PORT CONFIGURATIONS

THE RM05/3/2 SUBSYSTEM FUNCTIONAL TEST DOES NOT SPECIFICALLY TEST
DUAL PORT LOGIC IN THE RM05/3/2 ADAPTER BUT IS EXECUTABLE ON
RM05/3/2 SUBSYSTEMS HAVING THE DUAL PORT OPTION PROVIDING THE DUAL
PORT SWITCH IS SET TO THE APPROPRIATE PORT (A OR B).

5.3 MEMORY PARITY HARDWARE

MEMORY PARITY HARDWARE IS NOT USED DURING THE EXECUTION OF THE
RM05/3/2 SUBSYSTEM FUNCTIONAL TEST.

5.4 MEMORY MANAGEMENT HARDWARE

MEMORY MANAGEMENT HARDWARE IS NOT USED DURING THE RM05/3/2
SUBSYSTEM FUNCTIONAL TEST. CAPABILITIES OF THE MASSBUS CONTROLLER.

5.5 ACT11, APT11 COMPATIBILITY

THE RM05/3/2 SUBSYSTEM FUNCTIONAL TEST IS COMPATIBLE WITH ACT11
AND APT11 IN BOTH DUMP AND AUTOMATIC MODES. FURTHER, THE PROGRAM
WILL EXECUTE A QUICK PASS DURING THE FIRST PASS IN SUPPORT OF QUICK
VERIFY MODE.

5.6 XXDP COMPATIBILITY

THE RM05/3/2 SUBSYSTEM FUNCTIONAL TEST IS COMPATIBLE WITH XXDP IN
DUMP AND CHAIN MODES, AND PROVIDES MEDIA PROTECTION IN THE CASE WHERE
THE RM05/3/2 IS THE XXDP LOADING DEVICE.

343
344
345
346
347
348
349
350
351
352
353
354
355
356
357
358
359
360
361
362
363
364
365
366
367
368
369
370
371
372
373
374
375
376
377
378
379
380
381
382
383
384
385
386
387
388
389
390
391
392
393
394
395
396
397
398
399

5.7 OPERATING SYSTEM COMPATIBILITY

THE PROGRAM IS NOT COMPATIBLE WITH ANY SOFTWARE OPERATING SYSTEM.

6.0 TEST DESCRIPTION

TEST 1 CONTROLLER ACCESS TEST

PURPOSE:

TO VERIFY THAT THE UNIBUS ADDRESS OF THE SUBSYSTEM IS CORRECT, AS DEFINED AT LOCATION \$BASE.

PROCEDURE:

THE TEST TRIES TO ACCESS ALL MASSBUS CONTROLLER REGISTERS USING THE \$BASE ADDRESS. REGISTER CONTENTS ARE IGNORED DURING THE TEST, AND THE TEST FAILS IF A BUS TIMEOUT OCCURS FOR ANY REGISTER TRANSFER.

IF THE TEST FAILS AND THE PROGRAM IS RUNNING IN A STAND ALONE ENVIRONMENT, I.E., LOCATION 42 IS 0, THE PROGRAM WILL JUMP TO LOCATION 204 WHICH ALLOWS THE OPERATOR TO CHANGE THE \$BASE ADDRESS VIA CONSOLE DIALOGUE. OTHERWISE, THE PROGRAM ESCAPES TO THE END OF PASS HANDLER.

TEST 2 - 25 WRITE/READ DATA TESTS

PURPOSE:

TO TEST WRITE DATA AND READ DATA FUNCTIONALITY OF THE RM05/3/2 SUBSYSTEM USING A SET OF VARIABLES WHICH INCLUDE WORD COUNT, HEAD MOTION, HEAD SWITCHING AND ERROR CONDITIONS.

PROCEDURE:

ALTHOUGH EACH TEST EXERCISES A DIFFERENT VARIABLE, THE GENERAL PROCEDURE OF EACH TEST IS THE SAME. THE DRIVE IS INITIALIZED AND RECALIBRATED IF 'PIP' OR 'SKI' ARE ACTIVE SO THAT THERE ARE NO ERRORS WHEN A TEST BEGINS. THEN, THE TEST FORMATS THE SECTOR BEING USED, WHICH MAY VARY FROM THE PROGRAM LISTING, BECAUSE SECTORS ARE SUBSTITUTED DURING RUN TIME IF THE SELECTED SECTOR IS LISTED IN THE BAD BLOCK TABLE OF THE LAST TRACK. FOLLOWING THAT, THE TEST PERFORMS ANY EXPLICIT SEEKS REQUIRED FOR

400
401
402
403
404
405
406
407
408
409
410
411
412
413
414
415
416
417
418
419
420
421
422
423
424
425
426
427
428
429
430
431
432
433
434
435
436
437
438
439
440
441
442
443
444
445
446
447
448
449
450
451
452
453
454
455
456

THE CONDITIONS OF THE TEST. REGISTERS ARE PRESET AND THE WRITE DATA COMMAND IS EXECUTED. WHEN THE WRITE COMMAND IS COMPLETE, THE TEST STORES ALL SUBSYSTEM STATUS AND CHECKS FOR PRIMARY ERRORS WHICH PRECLUDE OTHER STATUS CHECKS. IF THERE ARE NO PRIMARY ERRORS, THE TEST VERIFIES THE RESULTS OF THE WRITE COMMAND AND THEN CHECKS FOR SECONDARY ERRORS. LOOP ADDRESSES ARE MODIFIED FOLLOWING THE SUCCESSFUL COMPLETION OF THE WRITE COMMAND IN ORDER TO SHORTEN EXECUTION TIMES AND ENHANCE SCOPING LOOPS, THEN THE PROGRAM EXECUTES THE READ DATA PORTION OF THE TEST, VERIFYING THE SAME TYPE OF ERRORS AS IN THE WRITE COMMAND.

NOTE: THE SECTOR USED DURING A TEST MAY DIFFER FROM THE PROGRAM LISTING BECAUSE THE PROGRAM SUBSTITUTES A GOOD SECTOR, IF THE ONE SELECTED IS LISTED IN THE BAD BLOCK TABLE.

TEST 2 WRITE, READ ZEROS TEST

THE TEST WRITES AND READS AN ALL ZEROS DATA FIELD, CAUSING THE DRIVE TO USE NORMAL WRITE GATE THROUGHOUT THE WRITE PROCESS.

TEST 3 WRITE, WRITE CHECK ZEROS TEST

THE TEST WRITES AND WRITE CHECKS AN ALL ZEROS DATA FIELD, VERIFYING THAT THERE ARE NO ERRORS.

TEST 4 WRITE, WRITE CHECK ZEROS W/ WCE ERROR TEST

THE TEST WRITES AN ALL ZEROS DATA FIELD, THEN COMPLEMENTS EACH BIT IN THE LAST WORD OF THE WRITE BUFFER. A WRITE CHECK COMMAND IS EXECUTED AND THE TEST VERIFIES THAT THE CORRECT WRITE CHECK ERROR IS DETECTED.

TEST 5 WRITE, READ ONES TEST

THE TEST WRITES AND READS AN ALL ONES DATA FIELD, CAUSING THE DRIVE TO USE NORMAL WRITE GATE THROUGHOUT THE WRITE PROCESS.

457
458
459
460
461
462
463
464
465
466
467
468
469
470
471
472
473
474
475
476
477
478
479
480
481
482
483
484
485
486
487
488
489
490
491
492
493
494
495
496
497
498
499
500
501
502
503
504
505
506
507
508
509
510
511
512
513

TEST 6 WRITE, WRITE CHECK ONES TEST

THE TEST WRITES AND WRITE CHECKS AN ALL ONES DATA FIELD.

TEST 7 WRITE, WRITE CHECK ONES W/ WCE ERROR TEST

THE TEST WRITES AN ALL ONES DATA FIELD, THEN PERFORMS A WRITE CHECK DATA COMMAND AFTER COMPLEMENTING EACH BIT IN THE LAST WORD OF THE WRITE BUFFER. THE TEST VERIFIES THAT THE CORRECT WRITE CHECK ERROR IS DETECTED.

TEST 10 WRITE, WRITE CHECK MULTIPLE SECTORS TEST

THE TEST SEEKS TO CYLINDER 0 TO INSURE THERE IS NO HEAD MOTION DURING DATA TRANSFER. THE WRITE DATA COMMAND FOLLOWS, WITH THE WORD COUNT EQUAL TO MULTIPLE SECTORS. THE SAME SECTORS ARE VERIFIED WITH A WRITE CHECK DATA COMMAND.

TEST 11 WRITE, READ WITH IMPLIED SEEK TEST

THIS TEST SEEKS TO THE LAST CYLINDER PRIOR TO WRITING DATA ON CYLINDER 0, TRACK 0, SECTOR 0. THE EXPLICIT SEEK INSURES THAT THERE WILL BE MAXIMUM HEAD MOTION DURING THE IMPLIED SEEK OF THE WRITE COMMAND. THE SAME OPERATION, INCLUDING THE EXPLICIT SEEK IS REPEATED FOR READ DATA.

TEST 12 WRITE, WRITE CHECK WITH HEAD SWITCHING TEST

THE TEST SEEKS TO CYLINDER 0 TO INSURE THERE IS NO HEAD MOTION DURING DATA TRANSFER. THE WRITE DATA COMMAND STARTS WITH CYLINDER 0, TRACK 0, SECTOR 31. THE WORD COUNT IS EQUAL TO MULTIPLE SECTORS WHICH CAUSES THE SUBSYSTEM TO SWITCH FROM TRACK 0 TO TRACK 1 AFTER THE FIRST OF THE MULTIPLE SECTORS ARE WRITTEN. THE SAME SECTORS ARE VERIFIED WITH A WRITE CHECK DATA COMMAND, USING THE SAME WORD COUNT AND STARTING SECTOR.

514
515
516
517
518
519
520
521
522
523
524
525
526
527
528
529
530
531
532
533
534
535
536
537
538
539
540
541
542
543
544
545
546
547
548
549
550
551
552
553
554
555
556
557
558
559
560
561
562
563
564
565
566
567
568
569
570

TEST 13 WRITE, WRITE CHECK WITH MID-TRANSFER SEEK TEST

THIS TEST WRITES MULTIPLE SECTORS STARTING WITH CYLINDER 0, LAST TRACK AND SECTOR 31., CAUSING A MID-TRANSFER SEEK AFTER THE FIRST SECTOR IS WRITTEN. THE SAME SECTORS ARE VERIFIED WITH A WRITE CHECK DATA COMMAND.

TEST 14 WRITE, READ W/ HCE ERROR TEST

A SECTOR IS FORMATTED WITH AN INCORRECT HEADER, THEN THE TEST WRITES AND READS DATA FROM THE SECTOR AND VERIFIES THAT THE CORRECT ERROR IS DETECTED. EACH BIT POSITION OF BOTH HEADER WORDS IS TESTED IN THIS MANNER.

TEST 15 WRITE, READ W/ HCI TEST

A SECTOR IS FORMATTED WITH AN INCORRECT HEADER, THEN WRITTEN AND READ WITH HEADER COMPARE INHIBITED. THE TEST VERIFIES THAT NO ERROR IS DETECTED.

TEST 16 WRITE, READ W/ IVC ERROR TEST

VOLUME VALID IS RESET BY SETTING AND RESETTING DIAGNOSTIC MODE. THE TEST THEN EXECUTES A WRITE DATA COMMAND AND VERIFIES THAT INVALID COMMAND STATUS SETS. THE TEST IS REPEATED FOR READ DATA COMMAND.

TEST 17 WRITE, READ W/ ABORT TEST

THE TEST SETS AN ERROR IN THE ERROR REGISTER AND EXECUTES A WRITE DATA COMMAND VERIFYING THAT 'PIP' REMAINS INACTIVE. THE SAME PROCEDURE IS USED FOR READ DATA COMMAND.

TEST 20 WRITE, READ EACH CURRENT LEVEL TEST

THE TEST WRITES AND READS ON EACH OF THE FOLLOWING CYLINDERS IN ORDER TO WRITE AT EACH POSSIBLE CURRENT THRESHOLD.

571
572
573
574
575
576
577
578
579
580
581
582
583
584
585
586
587
588
589
590
591
592
593
594
595
596
597
598
599
600
601
602
603
604
605
606
607
608
609
610
611
612
613
614
615
616
617
618
619
620
621
622
623
624
625
626
627

CYLINDER			
0		110	MA
128		104	MA
256		97	MA
384		91	MA
512		84	MA
640		77	MA
768		70	MA

TEST 21 WRITE, WRITE CHECK W/ CURRENT LEVEL SWITCHING TEST

THE TEST WRITES 2 SECTORS STARTING WITH THE LAST SECTOR OF CYLINDER 383. THE FIRST SECTOR IS WRITTEN AT ONE CURRENT LEVEL AND THE SECOND SECTOR IS WRITTEN AT ANOTHER CURRENT LEVEL. BOTH SECTORS ARE VERIFIED WITH A WRITE CHECK DATA COMMAND.

TEST 22 WRITE, READ EARLY PEAK SHIFT TEST

THIS TEST WRITES AND READS A SINGLE SECTOR USING A DATA PATTERN DESIGNED TO INTRODUCE EARLY PEAK SHIFT.

TEST 23 WRITE, READ MIXED PEAK SHIFT TEST

THIS TEST WRITES AND READS A SINGLE SECTOR USING A DATA PATTERN DESIGNED TO INTRODUCE MIXED PEAK SHIFT.

TEST 24 WRITE, READ EACH TRACK TEST

THE TEST WRITES AND READS WITH EACH HEAD USING A MIX OF EARLY, NORMAL AND LATE WRITE GATES.

TEST 25 READ, WRITES CHECK MULTIPLE SECTORS IN OFFSET MODE TEST

THE TEST EXECUTES READ DATA AND WRITE CHECK DATA COMMANDS IN OFFSET MODE IN BOTH OFFSET DIRECTIONS WITH THE TRANSFER SIZE OF TWO SECTORS AT A TIME.

628

\

479
480

```

;*LAST REVISION 04-APR-81
.TITLE CZRM0B0 RM05/3/2 FCTNL TST 3
;*COPYRIGHT (C) 1981
;*DIGITAL EQUIPMENT CORPORATION
;*COLORADO SPGS., CO. 80919
;*
;*PROGRAM BY MIKE LEAVITT
;*
;*THIS PROGRAM WAS ASSEMBLED USING THE PDP-11 MAINDEC SYSMAC
;*PACKAGE (MAINDEC-11-DZQAC-C5), 18-MAR-81

```

481

```

.SBTTL OPERATIONAL SWITCH SETTINGS
;*
;*      SWITCH      USE
;*      -----      -----
;*      15          HALT ON ERROR
;*      14          LOOP ON TEST
;*      13          INHIBIT ERROR TYPEOUTS
;*      12          UNUSED
;*      11          INHIBIT ITERATIONS
;*      10          BELL ON ERROR
;*      9           LOOP ON ERROR
;*      8           LOOP ON TEST IN SWR<7:0>
;*      7           TN128
;*      6           TN64
;*      5           TN32
;*      4           TN16
;*      3           TN8
;*      2           TN4
;*      1           TN2
;*      0           TN1

```

482

483
484

```

.SBTTL BASIC DEFINITIONS
;*INITIAL ADDRESS OF THE STACK POINTER *** 1100 ***
STACK = 1100
ERROR = EMT          ;;BASIC DEFINITION OF ERROR CALL
SCOPE = IOT          ;;BASIC DEFINITION OF SCOPE CALL

```

001100
104000
000004

```

;*MISCELLANEOUS DEFINITIONS
HT = 11          ;;CODE FOR HORIZONTAL TAB
LF = 12          ;;CODE FOR LINE FEED
CR = 15          ;;CODE FOR CARRIAGE RETURN
CRLF = 200       ;;CODE FOR CARRIAGE RETURN-LINE FEED
PS = 177776     ;;PROCESSOR STATUS WORD
PSW=PS
STKLMT = 177774 ;;STACK LIMIT REGISTER
PIRQ = 177772   ;;PROGRAM INTERRUPT REQUEST REGISTER
DSWR = 177570   ;;HARDWARE SWITCH REGISTER
DDISP = 177570  ;;HARDWARE DISPLAY REGISTER

```

000011
000012
000015
000200
177776
177776
177774
177772
177570
177570

```

;*GENERAL PURPOSE REGISTER DEFINITIONS
R0 = %0          ;;GENERAL REGISTER
R1 = %1          ;;GENERAL REGISTER
R2 = %2          ;;GENERAL REGISTER
R3 = %3          ;;GENERAL REGISTER

```

000000
000001
000002
000003

```

000004            R4        = %4            :: GENERAL REGISTER
000005            R5        = %5            :: GENERAL REGISTER
000006            R6        = %6            :: GENERAL REGISTER
000007            R7        = %7            :: GENERAL REGISTER
000006            SP        = %6            :: STACK POINTER
000007            PC        = %7            :: PROGRAM COUNTER
    
```

;*PRIORITY LEVEL DEFINITIONS

```

000000            PR0       = 0            :: PRIORITY LEVEL 0
000040            PR1       = 40           :: PRIORITY LEVEL 1
000100            PR2       = 100          :: PRIORITY LEVEL 2
000140            PR3       = 140          :: PRIORITY LEVEL 3
000200            PR4       = 200          :: PRIORITY LEVEL 4
000240            PR5       = 240          :: PRIORITY LEVEL 5
000300            PR6       = 300          :: PRIORITY LEVEL 6
000340            PR7       = 340          :: PRIORITY LEVEL 7
    
```

;'SWITCH REGISTER' SWITCH DEFINITIONS

```

100000            SW15      = 100000
040000            SW14      = 40000
020000            SW13      = 20000
010000            SW12      = 10000
004000            SW11      = 4000
002000            SW10      = 2000
001000            SW09      = 1000
000400            SW08      = 400
000200            SW07      = 200
000100            SW06      = 100
000040            SW05      = 40
000020            SW04      = 20
000010            SW03      = 10
000004            SW02      = 4
000002            SW01      = 2
000001            SW00      = 1
001000            SW9=SW09
000400            SW8=SW08
000200            SW7=SW07
000100            SW6=SW06
000040            SW5=SW05
000020            SW4=SW04
000010            SW3=SW03
000004            SW2=SW02
000002            SW1=SW01
000001            SW0=SW00
    
```

;*DATA BIT DEFINITIONS (BIT00 TO BIT15)

```

100000            BIT15     = 100000
040000            BIT14     = 40000
020000            BIT13     = 20000
010000            BIT12     = 10000
004000            BIT11     = 4000
002000            BIT10     = 2000
001000            BIT09     = 1000
000400            BIT08     = 400
000200            BIT07     = 200
000100            BIT06     = 100
000040            BIT05     = 40
    
```

```
000020 BIT04 = 20
000010 BIT03 = 10
000004 BIT02 = 4
000002 BIT01 = 2
000001 BIT00 = 1
001000 BIT9=BIT09
000400 BIT8=BIT08
000200 BIT7=BIT07
000100 BIT6=BIT06
000040 BIT5=BIT05
000020 BIT4=BIT04
000010 BIT3=BIT03
000004 BIT2=BIT02
000002 BIT1=BIT01
000001 BIT0=BIT00
```

```
;*BASIC 'CPU' TRAP VECTOR ADDRESSES
000004 ERRVEC = 4 ;:TIME OUT AND OTHER ERRORS
000010 RESVEC = 10 ;:RESERVED AND ILLEGAL INSTRUCTIONS
000014 TBITVEC = 14 ;: 'T' BIT
000014 TRTVEC = 14 ;:TRACE TRAP
000014 BPTVEC = 14 ;:BREAKPOINT TRAP (BPT)
000020 IOTVEC = 20 ;:INPUT/OUTPUT TRAP (IOT) **SCOPE**
000024 PWRVEC = 24 ;:POWER FAIL
000030 EMTVEC = 30 ;:EMULATOR TRAP (EMT) **ERROR**
000034 TRAPVEC = 34 ;: 'TRAP' TRAP
000060 TKVEC = 60 ;:TTY KEYBOARD VECTOR
000064 TPVEC = 64 ;:TTY PRINTER VECTOR
000240 PIRQVEC = 240 ;:PROGRAM INTERRUPT REQUEST VECTOR
```

.SBTTL RM REGISTER BIT DEFINITIONS

;*RMCS1 CONTROL STATUS REGISTER

```
485
486
487
488
489
490 004000 DVA = BIT11 ;:DEVICE AVAILABLE-READ ONLY
491 000040 F4 = BIT05 ;:FUNCTION CODE
492 000020 F3 = BIT04 ;:FUNCTION CODE
493 000010 F2 = BIT03 ;:FUNCTION CODE
494 000004 F1 = BIT02 ;:FUNCTION CODE
495 000002 F0 = BIT01 ;:FUNCTION CODE
496 000001 GO = BIT00 ;:GO BIT
497 000077 FNCMSK = 000077 ;:FUNCTION CODE MASK
498
499
```

;FUNCTION CODES (BITS 01-05 OF RMCS1)

```
500 000000 NOP = 000000 ;:NOP COMMAND
501 000002 ILF02 = 000002 ;:ILLEGAL COMMAND
502 000004 SEEK = 000004 ;:SEEK COMMAND
503 000006 RECAL = 000006 ;:RECALIBRATE COMMAND
504 000010 DRVCLR = 000010 ;:DRIVE CLEAR COMMAND
505 000012 RELEASE = 000012 ;:RELEASE COMMAND
506 000014 OFFSET = 000014 ;:OFFSET COMMAND
507 000016 RTC = 000016 ;:RETURN TO CENTERLINE COMMAND
508 000020 RIP = 000020 ;:READ IN PRESET COMMAND
509 000022 PAKACK = 000022 ;:PACK ACKNOWLEDGE COMMAND
510 000022 PACACK = PAKACK
511 000024 ILF24 = 000024 ;:ILLEGAL COMMAND
512 000026 ILF26 = 000026 ;:ILLEGAL COMMAND
```

513	000030	SEARCH	= 000030	:SEARCH COMMAND
516	000030	ILF30	= 000030	:ILLEGAL COMMAND
	000032	ILF32	= 000032	:ILLEGAL COMMAND
	000034	ILF34	= 000034	:ILLEGAL COMMAND
	000036	ILF36	= 000036	:ILLEGAL COMMAND
	000040	ILF40	= 000040	:ILLEGAL COMMAND
	000042	ILF42	= 000042	:ILLEGAL COMMAND
	000044	ILF44	= 000044	:ILLEGAL COMMAND
	000046	ILF46	= 000046	:ILLEGAL COMMAND
517	000050	WCD	= 000050	:WRITE CHECK DATA COMMAND
518	000052	WCH	= 000052	:WRITE CHECK HEADER AND DATA
519	000054	ILF54	= 000054	:ILLEGAL COMMAND
520	000056	ILF56	= 000056	:ILLEGAL COMMAND
521	000060	WD	= 000060	:WRITE DATA COMMAND
522	000062	WH	= 000062	:WRITE HEADER AND DATA COMMAND
523	000064	ILF64	= 000064	:ILLEGAL COMMAND
524	000066	ILF66	= 000066	:ILLEGAL COMMAND
525	000070	RD	= 000070	:READ DATA COMMAND
526	000072	RH	= 000072	:READ HEADER AND DATA COMMAND
527	000074	ILF74	= 000074	:ILLEGAL COMMAND
528	000076	ILF76	= 000076	:ILLEGAL COMMAND
529				
530		:*RMDA	DISK ADDRESS REGISTER	
531				
532		:TRACK	ADDRESS DEFINITIONS	
533	010000	TA16	= BIT12	:TRACK ADDRESS 16.
534	004000	TA8	= BIT11	:TRACK ADDRESS 8.
535	002000	TA4	= BIT10	:TRACK ADDRESS 4
536	001000	TA2	= BIT09	:TRACK ADDRESS 2
537	000400	TA1	= BIT08	:TRACK ADDRESS 1
538				
539		:SECTOR	ADDRESS DEFINITIONS	
540	000020	SA16	= BIT04	:SECTOR ADDRESS 16.
541	000010	SA8	= BIT03	:SECTOR ADDRESS 8.
542	000004	SA4	= BIT02	:SECTOR ADDRESS 4
543	000002	SA2	= BIT01	:SECTOR ADDRESS 2
544	000001	SA1	= BIT00	:SECTOR ADDRESS 1
545				
546		:TRACK & SECTOR	MASKS	
547	177400	TADMSK	= 177400	:TRACK ADDRESS MASK
548	000377	SADMSK	= 000377	:SECTOR ADDRESS MASK
549				
550		:*RMDS	DRIVE STATUS REGISTER	
551				
552	100000	ATA	= BIT15	:ATTENTION ACTIVE
553	040000	ERR	= BIT14	:COMPOSITE ERROR
554	020000	PIP	= BIT13	:POSITIONING IN PROGRESS
555	010000	MOL	= BIT12	:MEDIUM ON LINE
556	004000	WRL	= BIT11	:WRITE LOCK
557	002000	LBT	= BIT10	:LAST BLOCK TRANSFERRED
558	001000	PGM	= BIT09	:PROGRAMMABLE
559	000400	DPR	= BIT08	:DRIVE PRESENT
560	000200	DRY	= BIT07	:DRIVE READY
561	000100	VV	= BIT06	:VOLUME VALID
562	000001	OM	= BIT00	:OFFSET MODE ACTIVE
563				
564		:*RMER1	ERROR REGISTER #1	

```

565
566      100000
567      040000
568      020000
569      010000
570      004000
571      002000
572      001000
573      000400
574      000200
575      000100
576      000040
577      000020
578      000010
579      000004
580      000002
581      000001
582
583      115760
584
585
586
587
588
589      000377
590
591
592
593      002000
594      001000
595      000400
596      000200
597      000100
598
599      003700
600
601
602
603
604      100000
605      040000
606      020000
607      010000
608      004000
609      002000
610      001000
611      000400
612      000200
613      000100
614      000040
615      000010
616      000004
617      000002
618      000001
619
620
621      100000

```

```

DCK      = BIT15      ;DATA CHECK ERROR
UNS      = BIT14      ;DRIVE UNSAFE
OPI      = BIT13      ;OPERATION INCOMPLETE
DTE      = BIT12      ;DRIVE TIMING ERROR
WLE      = BIT11      ;WRITE LOCK ERROR
IAE      = BIT10      ;INVALID ADDRESS ERROR
AOE      = BIT09      ;ADDRESS OVERFLOW ERROR
HCRC     = BIT08      ;HEADER CRC ERROR
HCE      = BIT07      ;HEADER COMPARE ERROR
ECH      = BIT06      ;ECC 'HARD' ERROR
WCF      = BIT05      ;WRITE CLOCK FAILURE
FER      = BIT04      ;FORMAT ERROR
PAR      = BIT03      ;PARITY ERROR
RMR      = BIT02      ;REGISTER MODIFICATION REFUSED
ILR      = BIT01      ;ILLEGAL REGISTER
ILF      = BIT00      ;ILLEGAL FUNCTION

NDTMSK   = DCK.DTE!WLE!AOE!HCRC!HCE!ECH!WCF!FER
;'NDTMSK' IS USED TO MASK ERROR REGISTER 1 DURING NON - DATA
;COMMANDS, I.E., HOUSEKEEPING AND POSITIONING COMMANDS

;*RMAS ATTENTION SUMMARY REGISTER

ATNMSK   = 377      ;MASK FOR ATTENTION BITS

;*RMLA LOOK AHEAD REGISTER

SC4      = BIT10      ;SECTOR COUNT = 16
SC3      = BIT09      ;SECTOR COUNT = 8
SC2      = BIT08      ;SECTOR COUNT = 4
SC1      = BIT07      ;SECTOR COUNT = 2
SC0      = BIT06      ;SECTOR COUNT = 1

SCTMSK   = 003700   ;SECTOR COUNT MASK

;*RMMR1 MAINTENANCE REGISTER #1

;WRITE ONLY BITS
DBCK     = BIT15      ;DEBUG CLOCK
DBEN     = BIT14      ;DEBUG CLOCK ENABLE
DEBL     = BIT13      ;DIAGNOSTIC END OF BLOCK
DTO      = BIT12      ;DIAGNOSTIC TIMEOUT
MCLK     = BIT11      ;MAINTENANCE CLOCK
MRD      = BIT10      ;READ DATA
MUR      = BIT09      ;UNIT READY
MOC      = BIT08      ;ON CYLINDER
MSER     = BIT07      ;SEEK ERROR
MDF      = BIT06      ;DRIVE FAULT
MS       = BIT05      ;SECTOR PULSE
MWP      = BIT03      ;WRITE PROTECT
MI       = BIT02      ;INDEX PULSE
MSC      = BIT01      ;SECTOR COMPARE
DMD      = BIT00      ;DIAGNOSTIC MODE

;READ ONLY BITS
OCC      BIT15      ;OCCUPIED

```

622	040000	RG	= BIT14	:RUN AND GO
623	020000	EBL	= BIT13	:END OF BLOCK
624	010000	REX	= BIT12	:EXCEPTION
625	004000	ESRC	= BIT11	:ENABLE SEARCH
626	002000	PLFS	= BIT10	:LOOKING FOR SYNC
627	001000	ECRC	= BIT09	:ENABLE CRC OUT
628	000400	PDA	= BIT08	:DATA AREA
629	000200	PHA	= BIT07	:HEADER AREA
630	000100	CONT	= BIT06	:CONTINUE
631	000040	WC	= BIT05	:WORD CLOCK
632	000020	EECC	= BIT04	:ENABLE ECC OUT
633	000010	MWD	= BIT03	:WRITE DATA BIT
634	000004	LS	= BIT02	:LAST SECTOR
635	000002	LST	= BIT01	:LAST SECTOR AND TRACK
636	000001	DMD	= BIT00	:DIAGNOSTIC MODE
637				
638		:*RMDT	DRIVE TYPE REGISTER	
639				
640	100000	NSA	= BIT15	:NOT SECTOR ADDRESSED = 0
641	040000	TAP	= BIT14	:TAPE DRIVE = 0
642	020000	MOH	= BIT13	:MOVING HEAD = 1
643	004000	DRQ	= BIT11	:DRIVE REQUEST REQUIRED
644				
645	020024	SNGPRT	= 020024	:SINGLE PORT DRIVE TYPE (RM02)
646	024024	DULPRT	= 024024	:DUAL PORT DRIVE TYPE (RM02)
647				
648		:*RMOF	OFFSET REGISTER	
649				
650	010000	FMT16	= BIT12	:16 BIT WORD FORMAT
651	004000	ECI	= BIT11	:ECC INHIBIT
652	002000	HCI	= BIT10	:HEADER COMPARE INHIBIT
653	000200	OFD	= BIT07	:OFFSET FORWARD
654				
655		:*RMDC	DESIRED CYLINDER ADDRESS REGISTER	
656				
657	001777	CYLMSK	= 001777	:MASK FOR CYLINDER ADDRESS
658				
659		:*RMMR2	MAINTENANCE REGISTER #2	
660				
661		:READ ONLY BITS		
662	100000	RQA	= BIT15	:PORT A REQUEST
663	040000	RQB	= BIT14	:PORT B REQUEST
664	020000	TAG	= BIT13	:TAG CONTROL
665	010000	TST	= BIT12	:COMMAND SEQUENCE TEST BIT
666	004000	CC	= BIT11	:CONTROL OR CYLINDER TAG
667	002000	CH	= BIT10	:CONTROL OR HEAD TAG
670	001000	BB09	= BIT09	:TAG BUS
	000400	BB08	= BIT08	:TAG BUS
	000200	BB07	= BIT07	:TAG BUS
	000100	BB06	= BIT06	:TAG BUS
	000040	BB05	= BIT05	:TAG BUS
	000020	BB04	= BIT04	:TAG BUS
	000010	BB03	= BIT03	:TAG BUS
	000004	BB02	= BIT02	:TAG BUS
	000002	BB01	= BIT01	:TAG BUS
	000001	BB00	= BIT00	:TAG BUS

```

672          ;*RMER2 ERROR REGISTER 2
673
674          100000      BSE      = BIT15      ;BAD SECTOR ERROR
675          040000      SKI      = BIT14      ;SEEK INCOMPLETE
676          020000      OPE      = BIT13      ;OPERATOR PLUG FRORR
677          010000      IVC      = BIT12      ;INVALID COMMAND ERROR
678          004000      LSC      = BIT11      ;LOSS OF SYSTEM CLOCK
679          002000      LBC      = BIT10      ;LOSS OF BIT CLOCK
680          000200      DVC      = BIT07      ;DEVICE CHECK
681          000010      DPE      = BIT03      ;DATA PARITY ERROR
682
683          .SBTTL  PROGRAM MNEMONICS
684
685          100000      MSE      = BIT15      ;MANUFACTURING DETECTED SECTOR ERROR
686          040000      USE      = BIT14      ;USER DETECTED SECTOR ERROR
687
688          .SBTTL  RM REGISTER INDEX VALUES
689
690          000000      RMCS1   = 00          ;CONTROL STATUS REGISTER #1
691          000006      RMDA    = 06          ;DISK ADDRESS REGISTER
692          000012      RMDS    = 12          ;DRIVE STATUS REGISTER
693          000014      RMER1   = 14          ;ERROR REGISTER #1
694          000016      RMAS    = 16          ;ATTENTION SUMMARY REGISTER
695          000020      RMLA    = 20          ;LOOK AHEAD REGISTER
696          000024      RMMR1   = 24          ;MAINTENANCE REGISTER
697          000026      RMDT    = 26          ;DRIVE TYPE REGISTER
698          000030      RMSN    = 30          ;SERIAL NUMBER REGISTER
699          000032      RMOF    = 32          ;OFFSET REGISTER
700          000034      RMDC    = 34          ;DESIRED CYLINDER REGISTER
701          000036      RMHR    = 36          ;HOLDING REGISTER
702          000040      RMMR2   = 40          ;MAINTENANCE REGISTER #2
703          000042      RMER2   = 42          ;ERROR REGISTER #2
704          000044      RMEC1   = 44          ;ECC POSITION REGISTER
705          000046      RMEC2   = 46          ;ECC PATTERN REGISTER
706          000050      ILRG50   = 50          ;ILLEGAL REGISTER 50
707          000052      ILRG52   = 52          ;ILLEGAL REGISTER 52
708          000054      ILRG54   = 54          ;ILLEGAL REGISTER 54
709          000056      ILRG56   = 56          ;ILLEGAL REGISTER 56
710          000060      ILRG60   = 60          ;ILLEGAL REGISTER 60
711          000062      ILRG62   = 62          ;ILLEGAL REGISTER 62
712          000064      ILRG64   = 64          ;ILLEGAL REGISTER 64
713          000066      ILRG66   = 66          ;ILLEGAL REGISTER 66
714          000070      ILRG70   = 70          ;ILLEGAL REGISTER 70
715          000072      ILRG72   = 72          ;ILLEGAL REGISTER 72
716          000074      ILRG74   = 74          ;ILLEGAL REGISTER 74
717          000076      ILRG76   = 76          ;ILLEGAL REGISTER 76
718
719          000077      IDXMSK  = 77          ;MASK FOR REGISTER INDEX NUMBER
720
721          .SBTTL  RH CONTROLLER REGISTER BIT DEFINITIONS
722
723          ;*RMCS1 CONTROL STATUS REGISTER #1
724
725          100000      SC       = BIT15      ;SPECIAL CONDITION-READ ONLY
726          040000      TRE      = BIT14      ;TRANSFER ERROR
727          020000      MCPE     = BIT13      ;MASSBUS CONTROL BUS PARITY ERROR-READ ONLY
728          002000      PSEL     = BIT10      ;PORT B SELECT

```

```

720      001000      A17      = BIT09      ;ADDRESS EXTENSION
721      000400      A16      = BIT08      ;ADDRESS EXTENSION
722      000200      RDY      = BIT07      ;READY-READ ONLY
723      000100      IE       = BIT06      ;INTERRUPT ENABLE
724
725      ;*RMCS2 RH CONTROL STATUS REGISTER #2
726
727      100000      DLT      = BIT15      ;DATA LATE-READ ONLY
728      040000      WCE      = BIT14      ;WRITE CHECK ERROR-READ ONLY
729      020000      UPE      = BIT13      ;UNIBUS PARITY ERROR
730      010000      NED      = BIT12      ;NONEXISTANT DRIVE-READ ONLY
731      004000      NEM      = BIT11      ;NONEXISTANT MEMORY-READ ONLY
732      002000      PGE      = BIT10      ;PROGRAM ERROR-READ ONLY
733      001000      MXF      = BIT09      ;MISSED TRANSFER
734      000400      MDPE     = BIT08      ;MASSBUS DATA BUS PARITY ERROR-READ ONLY
735      000200      OR       = BIT07      ;OUTPUT READY-READ ONLY
736      000100      IR       = BIT06      ;INPUT READY-READ ONLY
737      000040      CLR      = BIT05      ;CONTROLLER CLEAR
738      000020      PAT      = BIT04      ;PARITY TEST
739      000010      BAI      = BIT03      ;UNIBUS ADDRESS INCREMENT INHIBIT
742      000004      U2       = BIT02      ;UNIT SELECT
          000002      U1       = BIT01      ;UNIT SELECT
          000001      U0       = BIT00      ;UNIT SELECT

743
744      ;UNIT SELECT MASK
745
746      000007      UNTMSK   = 7          ;UNIT SELECT MASK
747
748      ;*RMCS3 RH70 CONTROL STATUS REGISTER #3
749
750      100000      APE      = BIT15      ;ADDRESS PARITY ERROR
751      040000      DPEHI    = BIT14      ;DATA PARITY ERROR HIGH WORD
752      020000      DPELO    = BIT13      ;DATA PARITY ERROR LOW WORD
753      010000      WCEHI    = BIT12      ;WRITE CHECK ERROR HIGH WORD
754      004000      WCELO    = BIT11      ;WRITE CHECK ERROR LOW WORD
755      002000      DBL      = BIT10      ;DOUBLE WORD TRANSFER
756      000100      IE       = BIT06      ;INTERRUPT ENABLE
757      000010      IPCK3    = BIT03      ;INVERT PARITY CHECK
758      000004      IFCK2    = BIT02      ;INVERT PARITY CHECK
759      000002      IPCK1    = BIT01      ;INVERT PARITY CHECK
760      000001      IPCK0    = BIT00      ;INVERT PARITY CHECK
761
762      .SBTTL      RH CONTROLLER REGISTER INDEX VALUES
763
764      000000      RMCS1     = 00          ;CONTROL, STATUS REGISTER #1
765      000002      RMWC      = 02          ;WORD COUNT REGISTER
766      000004      RMBA      = 04          ;BUS ADDRESS REGISTER
767      000010      RMCS2     = 10          ;CONTROL, STATUS REGISTER #2
768      000022      RMDB      = 22          ;DATA BUFFER
769      000050      RMBAE     = 50          ;BUS ADDRESS EXTENSION
770      000052      RMCS3     = 52          ;CONTROL, STATUS REGISTER #3
771
772      176700      ABASE     = 176700      ;UNIBUS ADDRESS
773      120254      AVECT1    = 120254      ;UNIBUS VECTOR ADDRESS AND PRIORITY
774

```



```
1          .SBTTL TRAP CATCHER
          000000
          .=0
          ;*ALL UNUSED LOCATIONS FROM 4 - 776 CONTAIN A '+2,HALT'
          ;*SEQUENCE TO CATCH ILLEGAL TRAPS AND INTERRUPTS
          ;*LOCATION 0 CONTAINS 0 TO CATCH IMPROPERLY LOADED VECTORS
000174     000174
000176     000000
          DISPREG: .WORD 0          ;;SOFTWARE DISPLAY REGISTER
          SWREG:   .WORD 0          ;;SOFTWARE SWITCH REGISTER

          .SBTTL STARTING ADDRESS(ES)
000200     000137 005432          JMP @#START          ;;JUMP TO STARTING ADDRESS OF PROGRAM
2 000204     000137 005422          JMP @#START1         ;CHANGE RH/RM BUS ADDRESS
3
4
5          .SBTTL ACT11 HOOKS
          ;*****
          ;HOOKS REQUIRED BY ACT11
          $SVPC=.          ;SAVE PC
          .=46
          $ENDAD          ;;1)SET LOC.46 TO ADDRESS OF $ENDAD IN .$EOP
          .=52
          .WORD 0          ;;2)SET LOC.52 TO ZERO
          .=$SVPC          ;; RESTORE PC
000046     000210
          000046     037242
          000052     000052
          000052     000000
          000210
6
7          .-1100
8          .SBTTL APT PARAMETER BLOCK
          ;*****
          ;SET LOCATIONS 24 AND 44 AS REQUIRED FOR APT
          ;*****
          .SX=.          ;;SAVE CURRENT LOCATION
          .=24          ;;SET POWER FAIL TO POINT TO START OF PROGRAM
          200          ;;FOR APT START UP
          .=44          ;;POINT TO APT INDIRECT ADDRESS PNTR.
          $APTHDR          ;;POINT TO APT HEADER BLOCK
          .=$X          ;;RESET LOCATION COUNTER
          ;*****
          ;SETUP APT PARAMETER BLOCK AS DEFINED IN THE APT-PDP11 DIAGNOSTIC
          ;INTERFACE SPEC.

001100     001100
001100     000000
001102     001222
001104     000006
001106     000006
001110     000006
001112     000042
9          001114     001114

          $APTHD:
          $HIBTS: .WORD 0          ;;TWO HIGH BITS OF 18 BIT MAILBOX ADDR.
          $MBADR: .WORD $MAIL      ;;ADDRESS OF APT MAILBOX (BITS 0-15)
          $STMT:  .WORD 6          ;;RUN TIM OF LONGEST TEST
          $PASTM: .WORD 6          ;;RUN TIME IN SECS. OF 1ST PASS ON 1 UNIT (QUICK VERIFY)
          $UNITM: .WORD 6          ;;ADDITIONAL RUN TIME (SECS) OF A PASS FOR EACH ADDED UNIT
          TAGADR: .WORD $ETEND-$MAIL/2 ;;LENGTH MAILBOX-ETABLE (WORDS)
```

0

.SBTTL COMMON TAGS

 *THIS TABLE CONTAINS VARIOUS COMMON STORAGE LOCATIONS
 *USED IN THE PROGRAM.

001114	001114			SCMTAG: .TAGADR	:: START OF COMMON TAGS
001114	000000			.WORD 0	
001116	000			\$TSTNM: .BYTE 0	:: CONTAINS THE TEST NUMBER
001117	000			\$ERFLG: .BYTE 0	:: CONTAINS ERROR FLAG
001120	000000			\$ICNT: .WORD 0	:: CONTAINS SUBTEST ITERATION COUNT
001122	000000			\$LPADR: .WORD 0	:: CONTAINS SCOPE LOOP ADDRESS
001124	000000			\$LPERR: .WORD 0	:: CONTAINS SCOPE RETURN FOR ERRORS
001126	000000			\$ERTTL: .WORD 0	:: CONTAINS TOTAL ERRORS DETECTED
001130	000			\$ITEMB: .BYTE 0	:: CONTAINS ITEM CONTROL BYTE
001131	001			\$ERMAX: .BYTE 1	:: CONTAINS MAX. ERRORS PER TEST
001132	000000			\$ERRPC: .WORD 0	:: CONTAINS PC OF LAST ERROR INSTRUCTION
001134	000000			\$GDADR: .WORD 0	:: CONTAINS ADDRESS OF 'GOOD' DATA
001136	000000			\$BDADR: .WORD 0	:: CONTAINS ADDRESS OF 'BAD' DATA
001140	000000			\$GDDAT: .WORD 0	:: CONTAINS 'GOOD' DATA
001142	000000			\$BDDAT: .WORD 0	:: CONTAINS 'BAD' DATA
001144	000000			.WORD 0	:: RESERVED--NOT TO BE USED
001146	000000			.WORD 0	
001150	000			\$AUTOB: .BYTE 0	:: AUTOMATIC MODE INDICATOR
001151	000			\$INTAG: .BYTE 0	:: INTERRUPT MODE INDICATOR
001152	000000			.WORD 0	
001154	177570			SWR: .WORD DSWR	:: ADDRESS OF SWITCH REGISTER
001156	177570			DISPLAY: .WORD DDISP	:: ADDRESS OF DISPLAY REGISTER
001160	177560			\$TKS: 177560	:: TTY KBD STATUS
001162	177562			\$TKB: 177562	:: TTY KBD BUFFER
001164	177564			\$TPS: 177564	:: TTY PRINTER STATUS REG. ADDRESS
001166	177566			\$TPB: 177566	:: TTY PRINTER BUFFER REG. ADDRESS
001170	000			\$NULL: .BYTE 0	:: CONTAINS NULL CHARACTER FOR FILLS
001171	002			\$FILLS: .BYTE 2	:: CONTAINS # OF FILLER CHARACTERS REQUIRED
001172	012			\$FILLC: .BYTE 12	:: INSERT FILL CHARS. AFTER A 'LINE FEED'
001173	000			\$TPFLG: .BYTE 0	:: 'TERMINAL AVAILABLE' FLAG (BIT<07>=0=YES)
001174	000000			\$TMP0: .WORD 0	:: USER DEFINED
001176	000000			\$TMP1: .WORD 0	:: USER DEFINED
001200	000000			\$TMP2: .WORD 0	:: USER DEFINED
001202	000000			\$TMP3: .WORD 0	:: USER DEFINED
001204	000000			\$TMP4: .WORD 0	:: USER DEFINED
001206	000000			\$TIMES: 0	:: MAX. NUMBER OF ITERATIONS
001210	000000			\$ESCAPE: 0	:: ESCAPE ON ERROR ADDRESS
001212	207	377	377	\$BELL: .ASCIZ <207><377><377>	:: CODE FOR BELL
001216	077			\$QUES: .ASCII /?/	:: QUESTION MARK
001217	015			\$CRLF: .ASCII <15>	:: CARRIAGE RETURN
001220	012	000		\$LF: .ASCIZ <12>	:: LINE FEED

 .SBTTL APT MAILBOX-ETABLE

001222				.EVEN	
001222	000000			\$MAIL: .	:: APT MAILBOX
001224	000000			\$MSGTY: .WORD AMSGTY	:: MESSAGE TYPE CODE
001226	000000			\$FATAL: .WORD AFATAL	:: FATAL ERROR NUMBER
				\$TESTN: .WORD ATESTN	:: TEST NUMBER

001230	000000	\$PASS:	.WORD	APASS	::PASS COUNT
001232	000000	\$DEVCT:	.WORD	ADEVCT	::DEVICE COUNT
001234	000000	\$UNIT:	.WORD	AUNIT	::I/O UNIT NUMBER
001236	000000	\$MSGAD:	.WORD	AMSGAD	::MESSAGE ADDRESS
001240	000000	\$MSGLG:	.WORD	AMSGLG	::MESSAGE LENGTH
001242		\$ETABLE:			::APT ENVIRONMENT TABLE
001242	000	\$ENV:	.BYTE	AENV	::ENVIRONMENT BYTE
001243	000	\$ENVM:	.BYTE	AENVM	::ENVIRONMENT MODE BITS
001244	000000	\$SWREG:	.WORD	ASWREG	::APT SWITCH REGISTER
001246	000000	\$USWR:	.WORD	AUSWR	::USER SWITCHES
001250	000000	\$CPUOP:	.WORD	ACPUOP	::CPU TYPE,OPTIONS
		*			BITS 15-11=CPU TYPE
		*			11/04=01,11/05=02,11/20=03,11/40=04,11/45=05
		*			11/70=06,PDQ=07,Q=10
		*			BIT 10=REAL TIME CLOCK
		*			BIT 9=FLOATING POINT PROCESSOR
		*			BIT 8=MEMORY MANAGEMENT
001252	000	\$MAMS1:	.BYTE	AMAMS1	::HIGH ADDRESS,M.S. BYTE
001253	000	\$MTYP1:	.BYTE	AMTYP1	::MEM. TYPE,BLK#1
		*			MEM. TYPE BYTE -- (HIGH BYTE)
		*			900 NSEC CORE=001
		*			300 NSEC BIPOLAR=002
		*			500 NSEC MOS=003
001254	000000	\$MADR1:	.WORD	AMADR1	::HIGH ADDRESS,BLK#1
		*			MEM.LAST ADDR.=3 BYTES,THIS WORD AND LOW OF "TYPE" ABOVE
001256	000	\$MAMS2:	.BYTE	AMAMS2	::HIGH ADDRESS,M.S. BYTE
001257	000	\$MTYP2:	.BYTE	AMTYP2	::MEM. TYPE,BLK#2
001260	000000	\$MADR2:	.WORD	AMADR2	::MEM.LAST ADDRESS,BLK#2
001262	000	\$MAMS3:	.BYTE	AMAMS3	::HIGH ADDRESS,M.S.BYTE
001263	000	\$MTYP3:	.BYTE	AMTYP3	::MEM. TYPE,BLK#3
001264	000000	\$MADR3:	.WORD	AMADR3	::MEM.LAST ADDRESS,BLK#3
001266	000	\$MAMS4:	.BYTE	AMAMS4	::HIGH ADDRESS,M.S.BYTE
001267	000	\$MTYP4:	.BYTE	AMTYP4	::MEM. TYPE,BLK#4
001270	000000	\$MADR4:	.WORD	AMADR4	::MEM.LAST ADDRESS,BLK#4
001272	120254	\$VECT1:	.WORD	AVECT1	::INTERRUPT VECTOR#1,BUS PRIORITY#1
001274	000000	\$VECT2:	.WORD	AVECT2	::INTERRUPT VECTOR#2BUS PRIORITY#2
001276	176700	\$BASE:	.WORD	ABASE	::BASE ADDRESS OF EQUIPMENT UNDER TEST
001300	000000	\$DEVN:	.WORD	ADEVN	::DEVICE MAP
001302	000000	\$CDW1:	.WORD	ACDW1	::CONTROLLER DESCRIPTION WORD#1
001304	000000	\$CDW2:	.WORD	ACDW2	::CONTROLLER DESCRIPTION WORD#2
001306	000000	\$DDW0:	.WORD	ADDW0	::DEVICE DESCRIPTOR WORD#0
001310	000000	\$DDW1:	.WORD	ADDW1	::DEVICE DESCRIPTOR WORD#1
001312	000000	\$DDW2:	.WORD	ADDW2	::DEVICE DESCRIPTOR WORD#2
001314	000000	\$DDW3:	.WORD	ADDW3	::DEVICE DESCRIPTOR WORD#3
001316	000000	\$DDW4:	.WORD	ADDW4	::DEVICE DESCRIPTOR WORD#4
001320	000000	\$DDW5:	.WORD	ADDW5	::DEVICE DESCRIPTOR WORD#5
001322	000000	\$DDW6:	.WORD	ADDW6	::DEVICE DESCRIPTOR WORD#6
001324	000000	\$DDW7:	.WORD	ADDW7	::DEVICE DESCRIPTOR WORD#7
001326		\$ETEND:			
		.MEXIT			

.SBTTL USER DEFINED TAGS

001326	000000	CTLFG:	.WORD	0	;CONTAINS CONTROL-C FLAG
001330	000000	CHGADR:	.WORD	0	;CHANGE RH/RM BUS ADDRESS = -1, NO CHANGE = 0
001332	000000	XXDP:	.WORD	0	;THE LOW BYTE CONTAINS THE DRIVE NUMBER FROM WHICH ;THE PROGRAM WAS LOADED. THE HIGH BYTE CONTAINS THE ;'XXDP' DEVICE CODE FOR THE RM05/3/2.
001334	000	._STRK:	.BYTE	0	;LO BYTE = 0
001335	000		.BYTE	0	;HI BYTE, CONTAINS LAST TRACK ADDRESS OF UNIT ;UNDER TEST. RM02/3 = 4., RM05 = 18.

;THE REGISTER INPUT BUFFER IS USED FOR
 ;STORING DRIVE STATUS

001336

GETBUF:

					;REGISTER INPUT BUFFER
001336	000000	RMCS1I:	.WORD	0	;CONTROL, STATUS REGISTER #1
001340	000000	RMWCI:	.WORD	0	;WORD COUNT REGISTER
001342	000000	RMBAI:	.WORD	0	;BUS ADDRESS REGISTER
001344	000000	RMDAI:	.WORD	0	;DISK ADDRESS REGISTER
001346	000000	RMCS2I:	.WORD	0	;CONTROL, STATUS REGISTER #2
001350	000000	RMDSI:	.WORD	0	;DRIVE STATUS REGISTER
001352	000000	RMER1I:	.WORD	0	;ERROR REGISTER #1
001354	000000	RMASI:	.WORD	0	;ATTENTION SUMMARY REGISTER
001356	000000	RMLAI:	.WORD	0	;LOOK AHEAD REGISTER
001360	000000	RMDBI:	.WORD	0	;DATA BUFFER
001362	000000	RMMR1I:	.WORD	0	;MAINTENANCE REGISTER #1
001364	000000	RMDTI:	.WORD	0	;DRIVE TYPE REGISTER
001366	000000	RMSNI:	.WORD	0	;SERIAL NUMBER REGISTER
001370	000000	RMOFI:	.WORD	0	;OFFSET REGISTER
001372	000000	RMDCI:	.WORD	0	;DESIRED CYLINDER REGISTER
001374	000000	RMHRI:	.WORD	0	;HOLDING REGISTER
001376	000000	RMMR2I:	.WORD	0	;MAINTENANCE REGISTER #2
001400	000000	RMER2I:	.WORD	0	;ERROR REGISTER #2
001402	000000	RMEC1I:	.WORD	0	;ECC POSITION REGISTER
001404	000000	RMEC2I:	.WORD	0	;ECC PATTERN REGISTER
001406	000000	RMBAEI:	.WORD	0	;BUS ADDRESS EXTENSION REGISTER
001410	000000	RMCS3I:	.WORD	0	;CONTROL, STATUS REGISTER #3

;THE REGISTER OUTPUT BUFFER IS USED FOR
 ;ASSEMBLING DATA GOING TO REGISTER

001412

PUTBUF:

					;REGISTER OUTPUT BUFFER
001412	000000	RMCS1O:	.WORD	0	;CONTROL, STATUS REGISTER #1
001414	000000	RMWCC:	.WORD	0	;WORD COUNT REGISTER
001416	000000	RMBAO:	.WORD	0	;BUS ADDRESS REGISTER
001420	000000	RMDAO:	.WORD	0	;DISK ADDRESS REGISTER
001422	000000	RMCS2O:	.WORD	0	;CONTROL, STATUS REGISTER #2
001424	000000	RMDSO:	.WORD	0	;DRIVE STATUS REGISTER
001426	000000	RMER1O:	.WORD	0	;ERROR REGISTER #1
001430	000000	RMASO:	.WORD	0	;ATTENTION SUMMARY REGISTER
001432	000000	RMLAO:	.WORD	0	;LOOK AHEAD REGISTER
001434	000000	RMDBO:	.WORD	0	;DATA BUFFER
001436	000000	RMMR1O:	.WORD	0	;MAINTENANCE REGISTER #1

001440 000000
 001442 000000
 001444 000000
 001446 000000
 001450 000000
 001452 000000
 001454 000000
 001456 000000
 001460 000000
 001462 000000
 001464 000000

RMDTO: .WORD 0 ;DRIVE TYPE REGISTER
 RMSNO: .WORD 0 ;SERIAL NUMBER REGISTER
 RMOFO: .WORD 0 ;OFFSET REGISTER
 RMDCO: .WORD 0 ;DESIRED CYLINDER REGISTER
 RMHRO: .WORD 0 ;HOLDING REGISTER
 RMMR20: .WORD 0 ;MAINTENANCE REGISTER #2
 RMER20: .WORD 0 ;ERROR REGISTER #2
 RMEC10: .WORD 0 ;ECC POSITION REGISTER
 RMEC20: .WORD 0 ;ECC PATTERN REGISTER
 RMBAE0: .WORD 0 ;BUS ADDRESS EXTENSION REGISTER
 RMCS30: .WORD 0 ;CONTROL, STATUS REGISTER #3

;EACH WORD OF THE TEST QUE CONTAINS THE DEVICE NUMBER IN
 ;THE LOW BYTE AND THE ATTENTION BIT IN THE HIGH BYTE. THE
 ;FIRST WORD CONTAINS THE ADDRESS OF THE DEVICE UNDER TEST
 ;IN THE TABLE. A ZERO WORD IS A BLANK AND REPRESENTS THE
 ;END OF THE QUE.

001466 000000
 001470 000000
 001510 000000

TSTQUE: .WORD 0 ;CONTAINS DEVICE POINTER
 .BLKW 8. ;TEST QUE FOR DEVICES UNDER TEST
 .WORD 0 ;TABLE TERMINATOR GOES HERE WHEN
 ;ALL 8. DEVICES ARE UNDER TEST.

;MEDIA ENABL IS SET IF THE BAD SECTOR FILES HAVE BEEN RECOVERED
 ;FOR THE UNIT UNDER TEST, OTHERWISE IT IS ZERO.

001512 000000

MEDENB: .WORD 0 ;MEDIA ENABLE

;LOCATIONS "ASNDC" AND "ASNDC" CONTAIN THE CYLINDER, TRACK AND SECTOR
 ;ADDRESS ASSIGNED BY THE BAD SECTOR MODULE.

001514 000000
 001516 000000
 001520 000000
 001522 000000

ASNDC: .WORD 0 ;ASSIGNED DESIRED CYLINDER
 ASNDA: .WORD 0 ;ASSIGNED TRACK, AND SECTOR
 CLKADR: .WORD 0 ;UNIBUS ADDRESS OF KW11 CLOCK
 CLKVCT: .WORD 0 ;VECTOR ADDRESS OF KW11 CLOCK

;THE GET INDEX TABLE CONTAINS A BYTE LIST OF REGISTERS WHICH
 ;ARE READ BY THE GET SUBROUTINE. THE LIST IS TERMINATED BY
 ;A NEGATIVE BYTE.

001524

GETINX: .BLKB 23. ;GET INDEX TABLE

;THE PUT INDEX TABLE ICONTAINS A BYTE LIST OF REGISTERS WHICH
 ;ARE WRITTEN BY THE PUT SUBROUTINE. THE LIST IS TERMINATED BY
 ;A NEGATIVE BYTE.

001553

PUTINX: .BLKB 23. ;PUT INDEX TABLE

;PUT TAGS HERE

.SBTTL ERROR POINTER TABLE

;*THIS TABLE CONTAINS THE INFORMATION FOR EACH ERROR THAT CAN OCCUR.
;*THE INFORMATION IS OBTAINED BY USING THE INDEX NUMBER FOUND IN
;*LOCATION \$ITEMB. THIS NUMBER INDICATES WHICH ITEM IN THE TABLE IS PERTINENT.
;*NOTE1: IF \$ITEMB IS 0 THE ONLY PERTINENT DATA IS (\$ERRPC).
;*NOTE2: EACH ITEM IN THE TABLE CONTAINS 4 POINTERS EXPLAINED AS FOLLOWS:

;* EM ;;POINTS TO THE ERROR MESSAGE
;* DH ;;POINTS TO THE DATA HEADER
;* DT ;;POINTS TO THE DATA
;* DF ;;POINTS TO THE DATA FORMAT

Line	Index	Item 1	Item 2	Pointer 1	Pointer 2	Pointer 3	Pointer 4	Description
1	001602							:ERROR 1 WRONG UNIT SELECTED
2				EMT1	EHT1	EDT1	EFT1	
3	001602	072404						
	001604	076470						
	001606	076614						
	001610	076704						
4								:ERROR 2 DEVICE WENT UNAVAILABLE
5				EMT2	EHT1	EDT1	EFT1	
6	001612	072410						
	001614	076470						
	001616	076614						
	001620	076704						
7								:ERROR 3 DEVICE WENT NONEXISTENT
8				EMT3	EHT1	EDT1	EFT1	
9	001622	072416						
	001624	076470						
	001626	076614						
	001630	076704						
10								:ERROR 4 CONTROLLER NOT READY
11				EMT4	EHT1	EDT1	EFT1	
12	001632	072424						
	001634	076470						
	001636	076614						
	001640	076704						
13								:ERROR 5 DRIVE NOT READY AND GO NOT RESET
14				EMT5	EHT1	EDT1	EFT1	
15	001642	072432						
	001644	076470						
	001646	076614						
	001650	076704						
16								:ERROR 6 UNEXPECTED VALUE FOR 'ATA' STATUS
17								

Line	Address	Value	Label	Description
18	001652	072440	EMT6	
	001654	076470	EHT1	
	001656	076614	EDT1	
	001660	076704	EFT1	
19				
20			:ERROR 7	BUS TIMEOUT TRYING TO READ OR WRITE REGISTER
21	001662	072446	EMT7	
	001664	000000	0	
	001666	000000	0	
	001670	000000	0	
22				
23			:ERROR 10	DRIVE NOT READY BUT GO IS RESET
24	001672	072454	EMT10	
	001674	076470	EHT1	
	001676	076614	EDT1	
	001700	076704	EFT1	
25				
26			:ERROR 11	GO NOT RESET BUT DRIVE IS READY
27	001702	072460	EMT11	
	001704	076470	EHT1	
	001706	076614	EDT1	
	001710	076704	EFT1	
28				
29			:ERROR 12	INCORRECT FUNCTION CODE
30	001712	072464	EMT12	
	001714	076470	EHT1	
	001716	076614	EDT1	
	001720	076704	EFT1	
31				
32			:ERROR 13	PARITY ERROR READING REMOTE REGISTERS
33	001722	072472	EMT13	
	001724	076470	EHT1	
	001726	076614	EDT1	
	001730	076704	EFT1	
34				
35			:ERROR 14	TRANSFER ERROR IS INCORRECT
36	001732	072504	EMT14	
	001734	076470	EHT1	
	001736	076614	EDT1	
	001740	076704	EFT1	
37				
38			:ERROR 15	INCORRECT WORD COUNT
39				

ERROR POINTER TABLE				
	001742	072512		EMT15
	001744	076470		EHT1
	001746	076614		EDT1
	001750	076704		EFT1
40				
41			:ERROR 16	INCORRECT BUS ADDRESS
42				
	001752	072520		EMT16
	001754	076470		EHT1
	001756	076614		EDT1
	001760	076704		EFT1
43				
44			:ERROR 17	INCORRECT LBT STATUS
45				
	001762	072530		EMT17
	001764	076470		EHT1
	001766	076614		EDT1
	001770	076704		EFT1
46				
47			:ERROR 20	INCORRECT AOE
48				
	001772	072540		EMT20
	001774	076470		EHT1
	001776	076614		EDT1
	002000	076704		EFT1
49				
50			:ERROR 21	INCORRECT DISK ADDRESS
51				
	002002	072550		EMT21
	002004	076470		EHT1
	002006	076614		EDT1
	002010	076704		EFT1
52				
53			:ERROR 22	INCORRECT CYLINDER ADDRESS
54				
	002012	072560		EMT22
	002014	076470		EHT1
	002016	076614		EDT1
	002020	076704		EFT1
55				
56			:ERROR 23	INCORRECT WLE STATUS
57				
	002022	072570		EMT23
	002024	076470		EHT1
	002026	076614		EDT1
	002030	076704		EFT1
58				
59			:ERROR 24	INCORRECT UPE STATUS
60				
	002032	072600		EMT24

	002034	076470		EMT1
	002036	076614		EDT1
	002040	076704		EFT1
61				
62			:ERROR 25	INCORRECT WCF STATUS
63				
	002042	072610		EMT25
	002044	076470		EHT1
	002046	076614		EDT1
	002050	076704		EFT1
64				
65			:ERROR 26	INCORRECT WCE STATUS
66				
	002052	072620		EMT26
	002054	076470		EHT1
	002056	076614		EDT1
	002060	076704		EFT1
67				
68			:ERROR 27	INCORRECT MDPE STATUS
69				
	002062	072630		EMT27
	002064	076470		EHT1
	002066	076614		EDT1
	002070	076704		EFT1
70				
71			:ERROR 30	INCORRECT DCK STATUS
72				
	002072	072640		EMT30
	002074	076470		EHT1
	002076	076614		EDT1
	002100	076704		EFT1
73				
74			:ERROR 31	INCORRECT ECM STATUS
75				
	002102	072650		EMT31
	002104	076470		EHT1
	002106	076614		EDT1
	002110	076704		EFT1
76				
77			:ERROR 32	DLT SHOULD NOT BE SET
78				
	002112	072660		EMT32
	002114	076470		EHT1
	002116	076614		EDT1
	002120	076704		EFT1
79				
80			:ERROR 33	MXF SHOULD NOT BE SET
81				
	002122	072670		EMT33
	002124	076470		EHT1

	002126 076614	EDT1	
	002130 076704	EFT1	
82			
83		;ERROR 34	DTE SHOULD NOT BE SET
84			
	002132 072700	EMT34	
	002134 076470	EHT1	
	002136 076614	EDT1	
	002140 076704	EFT1	
85			
86		;ERROR 35	INCORRECT HCRC STATUS
87			
	002142 072710	EMT35	
	002144 076470	EHT1	
	002146 076614	EDT1	
	002150 076704	EFT1	
88			
89		;ERROR 36	INCORRECT HCE STATUS
90			
	002152 072720	EMT36	
	002154 076470	EHT1	
	002156 076614	EDT1	
	002160 076704	EFT1	
91			
92		;ERROR 37	INCORRECT FER STATUS
93			
	002162 072730	EMT37	
	002164 076470	EHT1	
	002166 076614	EDT1	
	002170 076704	EFT1	
94			
95		;ERROR 40	DPE SHOULD NOT BE SET (NOT A DATA COMMAND)
96			
	002172 072740	EMT40	
	002174 076470	EHT1	
	002176 076614	EDT1	
	002200 076704	EFT1	
97			
98		;ERROR 41	LOST 'MOL' DURING PACK ACKNOWLEDGE
99			
	002202 072746	EMT41	
	002204 076470	EHT1	
	002206 076614	EDT1	
	002210 076704	EFT1	
100			
101		;ERROR 42	UNSAFE ERROR DURING PACK ACKNOWLEDGE
102			
	002212 072756	EMT42	
	002214 076470	EHT1	
	002216 076614	EDT1	

	002220	076704	EFT1	
103				
104			:ERROR 43	'DPI' ERROR DURING PACK ACKNOWLEDGE
105				
	002222	072770	EMT43	
	002224	076470	EHT1	
	002226	076614	EDT1	
	002230	076704	EFT1	
106				
107			:ERROR 44	'RMR' ERROR DURING PACK ACKNOWLEDGE
108				
	002232	073000	EMT44	
	002234	076470	EHT1	
	002236	076614	EDT1	
	002240	076704	EFT1	
109				
110			:ERROR 45	'ILR' ERROR DURING PACK ACKNOWLEDGE
111				
	002242	073010	EMT45	
	002244	076470	EHT1	
	002246	076614	EDT1	
	002250	076704	EFT1	
112				
113			:ERROR 46	'ILF' ERROR DURING PACK ACKNOWLEDGE
114				
	002252	073020	EMT46	
	002254	076470	EHT1	
	002256	076614	EDT1	
	002260	076704	EFT1	
115				
116			:ERROR 47	COMPOSITE ERROR STATUS IS INCORRECT
117				
	002262	073030	EMT47	
	002264	076470	EHT1	
	002266	076614	EDT1	
	002270	076704	EFT1	
118				
119			:ERROR 50	PARITY ERROR WRITING REMOTE REGISTERS
120				
	002272	073036	EMT50	
	002274	076470	EHT1	
	002276	076614	EDT1	
	002300	076704	EFT1	
121				
122			:ERROR 51	INCORRECT IAE STATUS DURING SEEK COMMAND
123				
	002302	073046	EMT51	
	002304	076470	EHT1	
	002306	076614	EDT1	
	002310	076704	EFT1	

124				
125			:ERROR 52	OPI ERROR DURING SEEK - MEDIUM IS NOT ON LINE
126				
	002312	073060	EMT52	
	002314	076470	EHT1	
	002316	076614	EDT1	
	002320	076704	EFT1	
127				
128			:ERROR 53	OPI ERROR DURING SEEK - MEDIUM IS ON LINE, ASSUME
129			:	ON CYLINDER LATCH DIDN'T RESET
130				
	002322	073076	EMT53	
	002324	076470	EHT1	
	002326	076614	EDT1	
	002330	076704	EFT1	
131				
132			:ERROR 54	SEEK INCOMPLETE ERROR DURING SEEK COMMAND
133				
	002332	073114	EMT54	
	002334	076470	EHT1	
	002336	076614	EDT1	
	002340	076704	EFT1	
134				
135			:ERROR 55	DEVICE CHECK DURING SEEK COMMAND
136				
	002342	073124	EMT55	
	002344	076470	EHT1	
	002346	076614	EDT1	
	002350	076704	EFT1	
137				
138			:ERROR 56	PIP IS STILL SET AFTER SEEK - SKI IS RESET
139				
	002352	073136	EMT56	
	002354	076470	EHT1	
	002356	076614	EDT1	
	002360	076704	EFT1	
140				
141			:ERROR 57	ATA DID NOT SET DURING SEEK COMMAND
142				
	002362	073154	EMT57	
	002364	076470	EHT1	
	002366	076614	EDT1	
	002370	076704	EFT1	
143				
144			:ERROR 60	IVC ERROR DURING SEEK COMMAND - LOST
145			:	VOLUME VALID
146				
	002372	073164	EMT60	
	002374	076470	EHT1	
	002376	076614	EDT1	

	002400	076704	EFT1	
147				
148			:ERROR 61	ERRONEOUS IVC ERROR DURING SEEK COMMAND -
149			:	VOLUME VALID IS STIL SET
150				
	002402	073202	EMT61	
	002404	076470	EHT1	
	002406	076614	EDT1	
	002410	076704	EFT1	
151				
152			:ERROR 62	MOL IS ZERO, BUT OPI WAS NOT
153			:	REPORTED DURING SEEK COMMAND
154				
	002412	073222	EMT62	
	002414	076470	EHT1	
	002416	076614	EDT1	
	002420	076704	EFT1	
155				
156			:ERROR 63	UNUSED
157				
	002422	000000	0	
	002424	000000	0	
	002426	000000	0	
	002430	000000	0	
158				
159			:ERROR 64	DRIVE DID NOT DETECT "IVC" ERROR DURING SEEK
160				
	002432	073240	EMT64	
	002434	076470	EHT1	
	002436	076614	EDT1	
	002440	076704	EFT1	
161				
162			:ERROR 65	DRIVE EXECUTED A SEEK WITH ERROR SET
163				
	002442	073260	EMT65	
	002444	076470	EHT1	
	002446	076614	EDT1	
	002450	076704	EFT1	
164				
165			:ERROR 66	UNEXPECTED ERROR SET IN RMER1
166				
	002452	073300	EMT66	
	002454	076470	EHT1	
	002456	076614	EDT1	
	002460	076704	EFT1	
167				
168			:ERROR 67	UNEXPECTED ERROR SET IN RMER2
169				
	002462	073312	EMT67	
	002464	076470	EHT1	

	002466	076614	EDT1	
	002470	076704	EFT1	
170				
171			:ERROR	70 ERRONEOUS "IAE" ERROR DURING RECALIBRATE
172				
	002472	073324	EMT70	
	002474	076470	EHT1	
	002476	076614	EDT1	
	002500	076704	EFT1	
173				
174			:ERROR	71 "ILF" ERROR DURING RECALIBRATE
175				
	002502	073334	EMT71	
	002504	076470	EHT1	
	002506	076614	EDT1	
	002510	076704	EFT1	
176				
177			:ERROR	72 "OPI" ERROR DURING RECALIBRATE DUE TO "MOL" = 0
178				
	002512	073344	EMT72	
	002514	076470	EHT1	
	002516	076614	EDT1	
	002520	076704	EFT1	
179				
180			:ERROR	73 "OPI" ERROR DURING RECALIBRATE BECAUSE ON
181			:	CYLINDER DIDNT DROP
182				
	002522	073362	EMT73	
	002524	076470	EHT1	
	002526	076614	EDT1	
	002530	076704	EFT1	
183				
184			:ERROR	74 "IVC" ERROR DURING RECALIBRATE - "VV" = 0
185				
	002532	073400	EMT74	
	002534	076470	EHT1	
	002536	076614	EDT1	
	002540	076704	EFT1	
186				
187			:ERROR	75 ERRONEOUS "IVC" ERROR DURING RECALIBRATE - "VV" = 1
188				
	002542	073410	EMT75	
	002544	076470	EHT1	
	002546	076614	EDT1	
	002550	076704	EFT1	
189				
190			:ERROR	76 "SKI" ERROR DURING RECALIBRATE
191				
	002552	073430	EMT76	
	002554	076470	EHT1	

	002556 076614	EDT1	
	002560 076704	EFT1	
192			
193		:ERROR 77	'DVC' OCCURRED DURING RECALIBRATE
194			
	002562 073440	EMT77	
	002564 076470	EHT1	
	002566 076614	EDT1	
	002570 076704	EFT1	
195			
196		:ERROR 100	LOST 'MOL' DURING RECALIBRATE - 'OPI' 0
197			
	002572 073452	EMT100	
	002574 076470	EHT1	
	002576 076614	EDT1	
	002600 076704	EFT1	
198			
199		:ERROR 101	LOST 'VV' DURING RECALIBRATE - 'IVC' = 0
200			
	002602 073470	EMT101	
	002604 076470	EHT1	
	002606 076614	EDT1	
	002610 076704	EFT1	
201			
202		:ERROR 102	'ATA' DID NOT SET DURING RECALIBRATE
203			
	002612 073506	EMT102	
	002614 076470	EHT1	
	002616 076614	EDT1	
	002620 076704	EFT1	
204			
205		:ERROR 103	'DM' DID NOT RESET DURING RECALIBRATE
206			
	002622 073516	EMT103	
	002624 076470	EHT1	
	002626 076614	EDT1	
	002630 076704	EFT1	
207			
208		:ERROR 104	'PIP' IS STIL SET AFTER RECALIBRATE
209			
	002632 073530	EMT104	
	002634 076470	EHT1	
	002636 076614	EDT1	
	002640 076704	EFT1	
210			
211		:ERROR 105	UNEXPECTED 'ILR' ERROR DURING RECALIBRATE
212			
	002642 073546	EMT105	
	002644 076470	EHT1	
	002646 076614	EDT1	

Line	Code	Address	Module	Description
		002650 076704	EFT1	
213				
214	;ERROR	106		UNEXPECTED 'RMR' ERROR DURING RECALIBRATE
215			EMT106	
		002652 073556	EHT1	
		002654 076470	EDT1	
		002656 076614	EFT1	
		002660 076704		
216				
217	;ERROR	107		'UNS' ERROR DURING RECALIBRATE - AC POWER IS LOW
218			EMT107	
		002662 073566	EHT1	
		002664 076470	EDT1	
		002666 076614	EFT1	
		002670 076704		
219				
220	;ERROR	110		CANNOT ACCESS MASSBUS CONTROLLER VIA UNIBUS
221			EMT110	
		002672 073606	EHT110	
		002674 076512	EDT110	
		002676 076632	EFT110	
		002700 076722		
222				
223	;ERROR	111		NONEXISTENT DEVICE
224			EMT111	
		002702 073620	EHT111	
		002704 076516	EDT111	
		002706 076634	EFT111	
		002710 076724		
225				
226	;ERROR	112		DEVICE NOT AVAILABLE
227			EMT112	
		002712 073626	EHT111	
		002714 076516	EDT111	
		002716 076634	EFT111	
		002720 076724		
228				
229	;ERROR	113		BUS TIMEOUT-NED STATUS FAILURE
230			EMT113	
		002722 073634	0	
		002724 000000	0	
		002726 000000	0	
		002730 000000		
231				
232	;ERROR	114		DEVICE NOT AN RM05/3/2
233			EMT114	
		002732 073650	EHT114	
		002734 076522	EDT114	
		002736 076636	EFT114	
		002740 076726		

234			
235			
236			
	002742	073656	
	002744	076470	
	002746	076614	
	002750	076704	
			EMT115
			EHT1
			EDT1
			EFT1
237			
238			
239			
	002752	073666	
	002754	076470	
	002756	076614	
	002760	076704	
			EMT116
			EHT1
			EDT1
			EFT1
240			
241			
242			
	002762	073676	
	002764	076470	
	002766	076614	
	002770	076704	
			EMT117
			EHT1
			EDT1
			EFT1
243			
244			
245			
	002772	073706	
	002774	076470	
	002776	076614	
	003000	076704	
			EMT120
			EHT1
			EDT1
			EFT1
246			
247			
248			
	003002	073716	
	003004	076470	
	003006	076614	
	003010	076704	
			EMT121
			EHT1
			EDT1
			EFT1
249			
250			
251			
	003012	073726	
	003014	076470	
	003016	076614	
	003020	076704	
			EMT122
			EHT1
			EDT1
			EFT1
252			
253			
254			
	003022	073736	
	003024	076470	
	003026	076614	
	003030	076704	
			EMT123
			EHT1
			EDT1
			EFT1

255			
256		:ERROR 124	RMEC2 NOT INITIALIZED BY UNIBUS
257			
	003032	073746	EMT124
	003034	076470	EHT1
	003036	076614	EDT1
	003040	076704	EFT1
258			
259		:ERROR 125	RMMR2 NOT INITIALIZED BY UNIBUS
260			
	003042	073756	EMT125
	003044	076470	EHT1
	003046	076614	EDT1
	003050	076704	EFT1
261			
262		:ERROR 126	RMCS1 NOT CLEARED BY CONTROLLER CLEAR
263			
	003052	073766	EMT126
	003054	076470	EHT1
	003056	076614	EDT1
	003060	076704	EFT1
264			
265		:ERROR 127	RMBA NOT CLEARED BY CONTROLLER CLEAR
266			
	003062	074000	EMT127
	003064	076470	EHT1
	003066	076614	EDT1
	003070	076704	EFT1
267			
268		:ERROR 130	RMCS2 NOT CLEARED BY CONTROLLER CLEAR
269			
	003072	074012	EMT130
	003074	076470	EHT1
	003076	076614	EDT1
	003100	076704	EFT1
270			
271		:ERROR 131	RMER1 NOT CLEARED BY CONTROLLER CLEAR
272			
	003102	074024	EMT131
	003104	076470	EHT1
	003106	076614	EDT1
	003110	076704	EFT1
273			
274		:ERROR 132	RMA5 NOT CLEARED BY CONTROLLER CLEAR
275			
	003112	074036	EMT132
	003114	076470	EHT1
	003116	076614	EDT1
	003120	076704	EFT1
276			

Line	Code	Description	Code	Description
277			:ERROR 133	RMMR1 NOT CLEARED BY CONTROLLER CLEAR
278	003122	074050		EMT133
	003124	076470		EHT1
	003126	076614		EDT1
	003130	076704		EFT1
279			:ERROR 134	RMDS NOT CLEARED BY CONTROLLER CLEAR
280				EMT134
281	003132	074062		EHT1
	003134	076470		EDT1
	003136	076614		EFT1
	003140	076704		
282			:ERROR 135	RMEC2 NOT CLEARED BY CONTROLLER CLEAR
283				EMT135
284	003142	074074		EHT1
	003144	076470		EDT1
	003146	076614		EFT1
	003150	076704		
285			:ERROR 136	RMMR2 NOT CLEARED BY CONTROLLER CLEAR
286				EMT136
287	003152	074106		EHT1
	003154	076470		EDT1
	003156	076614		EFT1
	003160	076704		
288			:ERROR 137	RMCS1 NOT CLEARED BY ERROR CLEAR
289				EMT137
290	003162	074120		EHT1
	003164	076470		EDT1
	003166	076614		EFT1
	003170	076704		
291			:ERROR 140	RMCS2 NOT CLEARED BY ERROR CLEAR
292				EMT140
293	003172	074130		EHT1
	003174	076470		EDT1
	003176	076614		EFT1
	003200	076704		
294			:ERROR 141	RMCS1 NOT CLEARED BY DRIVE CLEAR
295				EMT141
296	003202	074140		EHT1
	003204	076470		EDT1
	003206	076614		EFT1
	003210	076704		
297			:ERROR 142	RMDS NOT CLEARED BY DRIVE CLEAR
298				

299			
	003212	074150	EMT142
	003214	076470	EHT1
	003216	076614	EDT1
	003220	076704	EFT1
300			
301			:ERROR 143 RMER1 NOT CLEARED BY DRIVE CLEAR
302			
	003222	074160	EMT143
	003224	076470	EHT1
	003226	076614	EDT1
	003230	076704	EFT1
303			
304			:ERROR 144 RMAS NOT CLEARED BY DRIVE CLEAR
305			
	003232	074170	EMT144
	003234	076470	EHT1
	003236	076614	EDT1
	003240	076704	EFT1
306			
307			:ERROR 145 RMMR1 NOT CLEARED BY DRIVE CLEAR
308			
	003242	074200	EMT145
	003244	076470	EHT1
	003246	076614	EDT1
	003250	076704	EFT1
309			
310			:ERROR 146 RMMR2 NOT CLEARED BY DRIVE CLEAR
311			
	003252	074210	EMT146
	003254	076470	EHT1
	003256	076614	EDT1
	003260	076704	EFT1
312			
313			:ERROR 147 RMER2 NOT CLEARED BY DRIVE CLEAR
314			
	003262	074220	EMT147
	003264	076470	EHT1
	003266	076614	EDT1
	003270	076704	EFT1
315			
316			:ERROR 150 RMEC2 NOT CLEARED BY DRIVE CLEAR
317			
	003272	074230	EMT150
	003274	076470	EHT1
	003276	076614	EDT1
	003300	076704	EFT1
318			
319			:ERROR 151 MEDIUM NOT ON LINE
320			

ERROR POINTER TABLE				
003302	074240		EMT151	
003304	076470		EHT1	
003306	076614		EDT1	
003310	076704		EFT1	
321				
322		:ERROR 152	DRIVE FAULT	
323				
003312	074252		EMT152	
003314	076470		EHT1	
003316	076614		EDT1	
003320	076704		EFT1	
324				
325		:ERROR 153	UNSAFE SHOULD BE SET BECAUSE DVC IS SET	
326				
003322	074264		EMT153	
003324	076470		EHT1	
003326	076614		EDT1	
003330	076704		EFT1	
327				
328		:ERROR 154	UNSAFE SHOULD NOT BE SET, AC IS LOW	
329				
003332	074302		EMT154	
003334	076470		EHT1	
003336	076614		EDT1	
003340	076704		EFT1	
330				
331		:ERROR 155	VOLUME VALID NOT SET BY PACK ACK	
332				
003342	074320		EMT155	
003344	076470		EHT1	
003346	076614		EDT1	
003350	076704		EFT1	
333				
334		:ERROR 156	OFFSET MODF NOT SET BY OFFSET COMMAND	
335				
003352	074332		EMT156	
003354	076470		EHT1	
003356	076614		EDT1	
003360	076704		EFT1	
336				
337		:ERROR 157	OFFSET MODE NOT RESET BY RTC COMMAND	
338				
003362	074344		EMT157	
003364	076470		EHT1	
003366	076614		EDT1	
003370	076704		EFT1	
339				
340		:ERROR 160	RMOF NOT RESET BY RIP COMMAND	
341				
003372	074356		EMT160	

	003374	076470	EHT1	
	003376	076614	EDT1	
	00340C	076704	EFT1	
342				
343				;ERROR 161 RMDA NOT RESET BY RIP COMMAND
344				
	003402	074366	EMT161	
	003404	076470	EHT1	
	003406	076614	EDT1	
	003410	076704	EFT1	
345				
346				;ERROR 162 RMDC NOT RESET BY RIP COMMAND
347				
	003412	074400	EMT162	
	003414	076470	EHT1	
	003416	076614	EDT1	
	003420	076704	EFT1	
348				
349				;ERROR 163 DATA WAS ECC CORRECTED BUT DOES NOT COMPARE WITH
350				WRITE BUFFER
351				
	003422	076264	EMT336	
	003424	076552	EHT336	
	003426	076650	EDT336	
	003430	076740	EFT336	
352				
353				;ERROR 164 OPI SHOULD NOT BE SET
354				
	003432	074422	EMT164	
	003434	076470	EHT1	
	003436	076614	EDT1	
	003440	076704	EFT1	
355				
356				;ERROR 165 IVC SHOULD NOT BE SET
357				
	003442	074430	EMT165	
	003444	076470	EHT1	
	003446	076614	EDT1	
	003450	076704	EFT1	
358				
359				;ERROR 166 IAE SHOULD NOT BE SET
360				
	003452	074436	EMT166	
	003454	076470	EHT1	
	003456	076614	EDT1	
	003460	076704	EFT1	
361				
362				;ERROR 167 NEM SHOULD NOT BE SET
363				
	003462	074444	EMT167	

	003464	076470	EHT1	
	003466	076614	EDT1	
	003470	076704	EFT1	
364				
365				:ERROR 170 INCORRECT 'MOL' STATUS DURING DIAGNOSTIC MODE
366				
	003472	074452	EMT170	
	003474	076470	EHT1	
	003476	076614	EDT1	
	003500	076704	EFT1	
367				
368				:ERROR 171 'ATA' NOT SET DURING RETURN TO CENTERLINE
369				
	003502	074464	EMT171	
	003504	076470	EHT1	
	003506	076614	EDT1	
	003510	076704	EFT1	
370				
371				:ERROR 172 'ATA' NOT SET BY OFFSET COMMAND
372				
	003512	074474	EMT172	
	003514	076470	EHT1	
	003516	076614	EDT1	
	003520	076704	EFT1	
373				
374				:ERROR 173 RMER2 NOT INITIALIZED BY UNIBUS INIT
375				
	003522	074504	EMT173	
	003524	076470	EHT1	
	003526	076614	EDT1	
	003530	076704	EFT1	
376				
377				:ERROR 174 RMER2 NOT INITIALIZED BY CONTROLLER CLEAR
378				
	003532	074514	EMT174	
	003534	076470	EHT1	
	003536	076614	EDT1	
	003540	076704	EFT1	
379				
380				:ERROR 175 SELECTED DEVICE IS IN WRITE PROTECT
381				
	003542	074526	EMT175	
	003544	076470	EHT1	
	003546	076614	EDT1	
	003550	076704	EFT1	
382				
383				:ERROR 176 CANNOT SET DIAGNOSTIC MODE
384				
	003552	074534	EMT176	
	003554	076470	EHT1	

	003556	076614	EDT1	
	003560	076704	EFT1	
385				
386				
387				
	003562	000000	0	
	003564	000000	0	
	003566	000000	0	
	003570	000000	0	
388				
389				
390				
	003572	074544	EMT200	
	003574	076470	EHT1	
	003576	076614	EDT1	
	003600	076704	EFT1	
391				
392				
393				
	003602	074556	EMT201	
	003604	076470	EHT1	
	003606	076614	EDT1	
	003610	076704	EFT1	
394				
395				
396				
	003612	074570	EMT202	
	003614	076470	EHT1	
	003616	076614	EDT1	
	003620	076704	EFT1	
397				
398				
399				
	003622	074602	EMT203	
	003624	076470	EHT1	
	003626	076614	EDT1	
	003630	076704	EFT1	
400				
401				
402				
	003632	074614	EMT204	
	003634	076470	EHT1	
	003636	076614	EDT1	
	003640	076704	EFT1	
403				
404				
405				
	003642	074632	EMT205	
	003644	076470	EHT1	
	003646	076614	EDT1	

;ERROR 177 --RESERVED FOR POWER MONITOR BIT FAILURE--

;ERROR 200 INCORRECT 'PIP' STATUS DURING DIAGNOSTIC MODE

;ERROR 201 INCORRECT 'WRL' STATUS DURING DIAGNOSTIC MODE

;ERROR 202 INCORRECT 'SKI' STATUS DURING DIAGNOSTIC MODE

;ERROR 203 INCORRECT 'DVC' STATUS DURING DIAGNOSTIC MODE

;ERROR 204 'VV' WAS NOT RESET BY MAINTENANCE UNIT READY

;ERROR 205 SELECTED DEVICE HAS A PERSISTENT 'SKI' ERROR

Line	Code	Address	Module	Description
		003650 076704	EFT1	
406				
407				
408				
		003652 074642	EMT206	
		003654 076470	EHT1	
		003656 076614	EDT1	
		003660 076704	EFT1	
409				
410				
411				
		003662 074652	EMT207	
		003664 076470	EHT1	
		003666 076614	EDT1	
		003670 076704	EFT1	
412				
413				
414				
		003672 074664	EMT210	
		003674 076470	EHT1	
		003676 076614	EDT1	
		003700 076704	EFT1	
415				
416				
417				
		003702 074672	EMT211	
		003704 076470	EHT1	
		003706 076614	EDT1	
		003710 076704	EFT1	
418				
419				
420				
		003712 074706	EMT212	
		003714 076470	EHT1	
		003716 076614	EDT1	
		003720 076704	EFT1	
421				
422				
423				
		003722 074722	EMT213	
		003724 076470	EHT1	
		003726 076614	EDT1	
		003730 076704	EFT1	
424				
425				
426				
		003732 074732	EMT214	
		003734 076502	EHT2	
		003736 076624	EDT2	
		003740 076714	EFT2	

427				
428			;ERROR 215	DRIVE DID NOT DETECT "IVC" ERROR DURING RECALIBRATE
429	003742	074752		
	003744	076502	EMT215	
	003746	076624	EHT2	
	003750	076714	EDT2	
			EFT2	
430				
431			;ERROR 216	INCORRECT "IVC" STATUS
432	003752	074764		
	003754	076470	EMT216	
	003756	076614	EHT1	
	003760	076704	EDT1	
			EFT1	
433				
434			;ERROR 217	INCORRECT "IAE" STATUS
435	003762	074774		
	003764	076470	EMT217	
	003766	076614	EHT1	
	003770	076704	EDT1	
			EFT1	
436				
437			;ERROR 220	INCORRECT "WLE" STATUS
438	003772	075004		
	003774	076470	EMT220	
	003776	076614	EHT1	
	004000	076704	EDT1	
			EFT1	
439				
440			;ERROR 221	INCORRECT "OPI" STATUS
441	004002	075014		
	004004	076470	EMT221	
	004006	076614	EHT1	
	004010	076704	EDT1	
			EFT1	
442				
443			;ERROR 222	RM DID NOT DETECT RMR ERROR
444	004012	075024		
	004014	076470	EMT222	
	004016	076614	EHT1	
	004020	076704	EDT1	
			EFT1	
445				
446			;ERROR 223	RM DID NOT DETECT PARITY ERROR ON MASSBUS CONTROL BUS
447	004022	075034		
	004024	076526	EMT223	
	004026	076640	EHT223	
	004030	076730	EDT223	
			EFT223	

448				
449			;ERROR	224 UNUSED
450	004032	000000		0
	004034	000000		0
	004036	000000		0
	004040	000000		0
451				
452			;ERROR	225 UNUSED
453	004042	000000		0
	004044	000000		0
	004046	000000		0
	004050	000000		0
454				
455			;ERROR	226 UNUSED
456	004052	000000		0
	004054	000000		0
	004056	000000		0
	004060	000000		0
457				
458			;ERROR	227 UNUSED
459	004062	000000		0
	004064	000000		0
	004066	000000		0
	004070	000000		0
460				
461			;ERROR	230 UNUSED
462	004072	000000		0
	004074	000000		0
	004076	000000		0
	004100	000000		0
463				
464			;ERROR	231 UNUSED
465	004102	000000		0
	004104	000000		0
	004106	000000		0
	004110	000000		0
466				
467			;ERROR	232 UNUSED
468	004112	000000		0
	004114	000000		0
	004116	000000		0
	004120	000000		0
469				

470 ;ERROR 233 UNUSED
471
004122 000000 0
004124 000000 0
004126 000000 0
004130 000000 0

472 ;ERROR 234 UNUSED
473
474
004132 000000 0
004134 000000 0
004136 000000 0
004140 000000 0

475 ;ERROR 235 UNUSED
476
477
004142 000000 0
004144 000000 0
004146 000000 0
004150 000000 0

478 ;ERROR 236 UNUSED
479
480
004152 000000 0
004154 000000 0
004156 000000 0
004160 000000 0

481 ;ERROR 237 UNUSED
482
483
004162 000000 0
004164 000000 0
004166 000000 0
004170 000000 0

484 ;ERROR 240 UNUSED
485
486
004172 000000 0
004174 000000 0
004176 000000 0
004200 000000 0

487 ;ERROR 241 UNUSED
488
489
004202 000000 0
004204 000000 0
004206 000000 0
004210 000000 0

490 ;ERROR 242 UNUSED
491

Line	Address	Value	Comment
492	004212	000000	0
	004214	000000	0
	004216	000000	0
	004220	000000	0
493			
494			:ERROR 243 UNUSED
495	004222	000000	0
	004224	000000	0
	004226	000000	0
	004230	000000	0
496			
497			:ERROR 244 UNUSED
498	004232	000000	0
	004234	000000	0
	004236	000000	0
	004240	000000	0
499			
500			:ERROR 245 UNUSED
501	004242	000000	0
	004244	000000	0
	004246	000000	0
	004250	000000	0
502			
503			:ERROR 246 'ATA' NOT RESET BY GO WHEN 'ERR' = 0
504	004252	075110	EMT246
	004254	076470	EHT1
	004256	076614	EDT1
	004260	076704	EFT1
505			
506			:ERROR 247 'ATA' NOT RESET BY WRITING RMA5
507	004262	075120	EMT247
	004264	076470	EHT1
	004266	076614	EDT1
	004270	076704	EFT1
508			
509			:ERROR 250 'ATA' WAS RESET BY GO WHEN 'ERR' = 1
510	004272	075132	EMT250
	004274	076470	EHT1
	004276	076614	EDT1
	004300	076704	EFT1
511			
512			:ERROR 251 PROGRAM INTERRUPT WAS NOT GENERATED
513			

004302	075146	EMT251	
004304	076502	EHT2	
004306	076624	EDT2	
004310	076714	EFT2	
514			
515		;ERROR 252	PROGRAM INTERRUPT SHOULD NOT HAVE BEEN GENERATED
516			
004312	075154	EMT252	
004314	076502	EHT2	
004316	076624	EDT2	
004320	076714	EFT2	
517			
518		;ERROR 253	OFFSET MODE WAS NOT RESET BY WRITING RMDC
519			
004322	075162	EMT253	
004324	076470	EHT1	
004326	076614	EDT1	
004330	076704	EFT1	
520			
521		;ERROR 254	INCORRECT 'ILF' STATUS
522			
004332	075200	EMT254	
004334	076470	EHT1	
004336	076614	EDT1	
004340	076704	EFT1	
523			
524		;ERROR 255	INCORRECT 'ATA' STATUS
525			
004342	075210	EMT255	
004344	076470	EHT1	
004346	076614	EDT1	
004350	076704	EFT1	
526			
527		;ERROR 256	INCORRECT 'ILR' STATUS
528			
004352	075220	EMT256	
004354	076540	EHT256	
004356	076640	EDT223	
004360	076730	EFT223	
529			
530		;ERROR 257	INVALID IAE STATUS DURING SEARCH COMMAND
531			
004362	075230	EMT257	
004364	076470	EHT1	
004366	076614	EDT1	
004370	076704	EFT1	
532			
533		;ERROR 260	'IVC' WAS NOT DETECTED DURING SEARCH COMMAND
534			
004372	075242	EMT260	

Line	Code	Address	Pointer	Description
	004374	076470	EHT1	
	004376	076614	EDT1	
	004400	076704	EFT1	
535				
536				;ERROR 261 DRIVE EXECUTED SEARCH WITH ERROR SET
537				
	004402	075254	EMT261	
	004404	076470	EHT1	
	004406	076614	EDT1	
	004410	076704	EFT1	
538				
539				;ERROR 262 'LBC' ERROR NOT SET DURING DIAGNOSTIC MODE
540				
	004412	075274	EMT262	
	004414	076470	EHT1	
	004416	076614	EDT1	
	004420	076704	EFT1	
541				
542				;ERROR 263 'SKI' ERROR DURING SEARCH COMMAND
543				
	004422	075304	EMT263	
	004424	076470	EHT1	
	004426	076614	EDT1	
	004430	076704	EFT1	
544				
545				;ERROR 264 'IVC' ERROR DURING SEARCH - LOST VOLUME VALID
546				
	004432	075314	EMT264	
	004434	076470	EHT1	
	004436	076614	EDT1	
	004440	076704	EFT1	
547				
548				;ERROR 265 ERRONEOUS IVC ERROR DURING SEARCH - VOLUME IS VALID
549				
	004442	075334	EMT265	
	004444	076470	EHT1	
	004446	076614	EDT1	
	004450	076704	EFT1	
550				
551				;ERROR 266 DEVICE FAULT (DVC) DURING SEARCH
552				
	004452	075354	EMT266	
	004454	076470	EHT1	
	004456	076614	EDT1	
	004460	076704	EFT1	
553				
554				;ERROR 267 SKI SHOULD HAVE BEEN SET BECAUSE CYLINDER
555				ADDRESS IS TOO LARGE
556				
	004462	075366	EMT267	

004464	076470	EHT1	
004466	076614	EDT1	
004470	076704	EFT1	
557			
558		:ERROR 270	OPI ERROR DURING SEARCH BECAUSE MOL = 0
559			
004472	075404	EMT270	
004474	076470	EHT1	
004476	076614	EDT1	
004500	076704	EFT1	
560			
561		:ERROR 271	OPI ERROR DURING SEARCH BECAUSE ON CYLINDER
562		:	DIDN'T DROP
563			
004502	075420	EMT271	
004504	076470	EHT1	
004506	076614	EDT1	
004510	076704	EFT1	
564			
565		:ERROR 272	LOST MOL DURING SEARCH, OPI IS NOT SET
566			
004512	075436	EMT272	
004514	076470	EHT1	
004516	076614	EDT1	
004520	076704	EFT1	
567			
568		:ERROR 273	PIP STIL SET AFTER SEARCH
569			
004522	075454	EMT273	
004524	076470	EHT1	
004526	076614	EDT1	
004530	076704	EFT1	
570			
571		:ERROR 274	PARITY ERROR OCCURRED WHILE WRITING REMOTE
572		:	REGISTERS BUT MXF DID NOT SET
573			
004532	075472	EMT274	
004534	076470	EHT1	
004536	076614	EDT1	
004540	076704	EFT1	
574			
575		:ERROR 275	MXF ERROR - COMPOSITE ERROR OCCURRED BEFORE DATA
576		:	COMMAND STARTED
577			
004542	075510	EMT275	
004544	076470	EHT1	
004546	076614	EDT1	
004550	076704	EFT1	
578			
579		:ERROR 276	'OPI' ERROR DURING DATA TRANSFER BECAUSE 'MOL' WAS

Line	Code	Address	Label	Description
580			ZERO	
581	004552	075522	EMT276	
	004554	076470	EHT1	
	004556	076614	EDT1	
	004560	076704	EFT1	
582				
583	:ERROR	277		'DPI' ERROR DURING DATA TRANSFER BECAUSE 1) ON
584	:			CYLINDER DIDN'T DROP OR 2) SEARCH TIMED OUT OR
585	:			3) RUN TIMED OUT
586				
	004562	075536	EMT277	
	004564	076470	EHT1	
	004566	076614	EDT1	
	004570	076704	EFT1	
587				
588	:ERROR	300		'IVC' ERROR DURING DATA TRANSFER BECAUSE VOLUME
589	:			WAS NOT VALID
590				
	004572	075554	EMT300	
	004574	076470	EHT1	
	004576	076614	EDT1	
	004600	076704	EFT1	
591				
592	:ERROR	301		ERRONEOUS 'IVC' ERROR DURING DATA TRANSFER - VOLUME
593	:			IS VALID
594				
	004602	075574	EMT301	
	004604	076470	EHT1	
	004606	076614	EDT1	
	004610	076704	EFT1	
595				
596	:ERROR	302		'ILR' ERROR DURING DATA TRANSFER
597				
	004612	075616	EMT302	
	004614	076470	EHT1	
	004616	076614	EDT1	
	004620	076704	EFT1	
598				
599	:ERROR	303		'ILF' ERROR DURING DATA TRANSFER
600				
	004622	075630	EMT303	
	004624	076470	EHT1	
	004626	076614	EDT1	
	004630	076704	EFT1	
601				
602	:ERROR	304		'RMR' ERROR DURING DATA TRANSFER
603				
	004632	075642	EMT304	
	004634	076470	EHT1	
	004636	076614	EDT1	

ERROR POINTER TABLE				
	004640 076704		EFT1	
604 605 606		:ERROR 305		INCORRECT 'IAE' STATUS DURING DATA TRANSFER
	004642 075654		EMT305	
	004644 076470		EHT1	
	004646 076614		EDT1	
	004650 076704		EFT1	
607 608 609		:ERROR 306		'SKI' ERROR DURING DATA TRANSFER
	004652 075666		EMT306	
	004654 076470		EHT1	
	004656 076614		EDT1	
	004660 076704		EFT1	
610 611 612		:ERROR 307		DRIVE DID NOT DETECT SKI ERROR DUE TO CYLINDER
	004662 075676		EMT307	
	004664 076470		EHT1	
	004666 076614		EDT1	
	004670 076704		EFT1	
613 614 615		:ERROR 310		DEVICE FAULT DURING DATA TRANSFER
	004672 075716		EMT310	
	004674 076470		EHT1	
	004676 076614		EDT1	
	004700 076704		EFT1	
616 617 618		:ERROR 311		LOSS OF BIT CLOCK DURING DATA TRANSFER
	004702 075730		EMT311	
	004704 076470		EHT1	
	004706 076614		EDT1	
	004710 076704		EFT1	
619 620 621		:ERROR 312		LOSS OF SYSTEM CLOCK DURING DATA TRANSFER
	004712 075742		EMT312	
	004714 076470		EHT1	
	004716 076614		EDT1	
	004720 076704		EFT1	
622 623 624		:ERROR 313		UNSAFE ERROR DURING DATA TRANSFER (DVC - 0)
	004722 075754		EMT313	
	004724 076470		EHT1	
	004726 076614		EDT1	
	004730 076704		EFT1	

625				
626			:ERROR 314	DRIVE TIMING ERROR DURING DATA TRANSFER
627	004732	075774		EMT314
	004734	076470		EHT1
	004736	076614		EDT1
	004740	076704		EFT1
628				
629			:ERROR 315	WRITE LOCK ERROR
630	004742	076006		EMT315
	004744	076470		EHT1
	004746	076614		EDT1
	004750	076704		EFT1
631				
632			:ERROR 316	ERRONEOUS WRITE LOCK ERROR
633	004752	076020		EMT316
	004754	076470		EHT1
	004756	076614		EDT1
	004760	076704		EFT1
634				
635			:ERROR 317	HEADER CRC ERROR DURING DATA TRANSFER
636	004762	076032		EMT317
	004764	076470		EHT1
	004766	076614		EDT1
	004770	076704		EFT1
637				
638			:ERROR 320	FORMAT ERROR DURING DATA TRANSFER
639	004772	076042		EMT320
	004774	076470		EHT1
	004776	076614		EDT1
	005000	076704		EFT1
640				
641			:ERROR 321	HEADER COMPARE ERROR DURING DATA TRANSFER
642	005002	076052		EMT321
	005004	076470		EHT1
	005006	076614		EDT1
	005010	076704		EFT1
643				
644			:ERROR 322	HEADER ERRORS SHOULD NOT BE SET
645	005012	076062		EMT322
	005014	076470		EHT1
	005016	076614		EDT1
	005020	076704		EFT1

646			
647			
648			
	005022	076070	
	005024	076470	
	005026	076614	
	005030	076704	
			EMT323
			EHT1
			EDT1
			EFT1
649			
650			
651			
	005032	076100	
	005034	076470	
	005036	076614	
	005040	076704	
			EMT324
			EHT1
			EDT1
			EFT1
652			
653			
654			
	005042	076112	
	005044	076470	
	005046	076614	
	005050	076704	
			EMT325
			EHT1
			EDT1
			EFT1
655			
656			
657			
	005052	076124	
	005054	076470	
	005056	076614	
	005060	076704	
			EMT326
			EHT1
			EDT1
			EFT1
658			
659			
660			
	005062	076142	
	005064	076470	
	005066	076614	
	005070	076704	
			EMT327
			EHT1
			EDT1
			EFT1
661			
662			
663			
	005072	076154	
	005074	076470	
	005076	076614	
	005100	076704	
			EMT330
			EHT1
			EDT1
			EFT1
664			
665			
666			
	005102	076164	
	005104	076470	
	005106	076614	
	005110	076704	
			EMT331
			EHT1
			EDT1
			EFT1

667

668			:ERROR 332	DATA LATE ERROR DURING DATA TRANSFER
669	005112	076176		EMT332
	005114	076470		EHT1
	005116	076614		EDT1
	005120	076704		EFT1
670			:ERROR 333	PIP STIL SET AFTER DATA TRANSFER - SKI = 0
671	005122	076210		EMT333
672	005124	076470		EHT1
	005126	076614		EDT1
	005130	076704		EFT1
673			:ERROR 334	LOST MOL DURING DATA TRANSFER - OPI = 0
674	005132	076226		EMT334
675	005134	076470		EHT1
	005136	076614		EDT1
	005140	076704		EFT1
676			:ERROR 335	LOST VOLUME VALID DURING DATA TRANSFER - IVC - 0
677	005142	076244		EMT335
678	005144	076470		EHT1
	005146	076614		EDT1
	005150	076704		EFT1
679			:ERROR 336	DATA READ DOES NOT COMPARE WITH DATA WRITTEN
680	005152	076264		EMT336
681	005154	076552		EHT336
	005156	076650		EDT336
	005160	076740		EFT336
682			:ERROR 337	WRITE CHECK ERROR NOT DETECTED
683	005162	076274		EMT337
684	005164	076564		EHT337
	005166	076660		EDT337
	005170	076750		EFT337
685			:ERROR 340	WRITE CHECK ERROR AT UNEXPECTED ADDRESS
686	005172	076304		EMT340
687	005174	076552		EHT336
	005176	076650		EDT336
	005200	076740		EFT336
688			:ERROR 341	INCORRECT DATA DURING WRITE CHECK ERROR
689				

Line	Code	Address	Label	Description
690	005202	076316	EMT341	
	005204	076552	EHT336	
	005206	076650	EDT336	
	005210	076740	EFT336	
691				
692			:ERROR 342	'IVC' ERROR NOT DETECTED DURING DATA TRANSFER
693	005212	076324	EMT342	
	005214	076470	EHT1	
	005216	076614	EDT1	
	005220	076704	EFT1	
694				
695			:ERROR 343	'FER' NOT DETECTED DURING DATA TRANSFER
696	005222	076336	EMT343	
	005224	076470	EHT1	
	005226	076614	EDT1	
	005230	076704	EFT1	
697				
698			:ERROR 344	'HCE' NOT DETECTED DURING DATA TRANSFER
699	005232	076350	EMT344	
	005234	076576	EHT344	
	005236	076670	EDT344	
	005240	076760	EFT344	
700				
701			:ERROR 345	'BSE' NOT DETECTED DURING DATA TRANSFER
702	005242	076362	EMT345	
	005244	076470	EHT1	
	005246	076614	EDT1	
	005250	076704	EFT1	
703				
704			:ERROR 346	HEADER ERROR WAS DETECTED W/ HCI SET
705	005252	076372	EMT346	
	005254	076470	EHT1	
	005256	076614	EDT1	
	005260	076704	EFT1	
706				
707			:ERROR 347	DATA TRANSFER NOT ABORTED W/ COMP ERROR SET
708	005262	076406	EMT347	
	005264	076470	EHT1	
	005266	076614	EDT1	
	005270	076704	EFT1	
709				
710			:ERROR 350	LOST VOLUME VALID DURING SEARCH - 'IVC' = 0
711				

005272	076420	EMT350
005274	076470	EHT1
005276	076614	EDT1
005300	076704	EFT1

712
713
714

:ERROR 351 'ATA' DID NOT SET DURING SEARCH

005302	076436	EMT351
005304	076470	EHT1
005306	076614	EDT1
005310	076704	EFT1

715
716
717

:ERROR 352 PROGRAM TIMEOUT WHILE TESTING RMLA

005312	076446	EMT352
005314	000000	0
005316	000000	0
005320	000000	0

718
719
720

:ERROR 353 LOOK AHEAD TEST FAILS

005322	076452	EMT353
005324	076610	EHT353
005326	076702	EDT353
005330	076770	EFT353

721
722
723

:ERROR 354 BSE SHOULD NOT BE SET

005332	076462	EMT354
005334	076470	EHT1
005336	076614	EDT1
005340	076704	EFT1

724
725

:PUT ERROR TABLE HERE

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28

.SBTTL ERROR TABLE USAGE

:THE ERROR TABLE ABOVE CONSISTS OF FOUR WORD ENTRIES FOR EACH ERROR
:NUMBER, I.E.,

:
: EMT - ERROR MESSAGE TABLE ADDRESS
: EHT - ERROR HEADER TABLE ADDRESS
: EDT - ERROR DATA TABLE ADDRESS
: EFT - ERROR FORMAT TABLE ADDRESS
:

:THE EMT ENTRY IS THE ADDRESS OF THE TABLE OF ERROR MESSAGE STRINGS
:FOR THE PARTICULAR ERROR. EACH ERROR MESSAGE TABLE LISTS THE ADDRESS
:OF ONE OR MORE ERROR MESSAGE STRINGS WHICH ARE TO BE FORMATTED AND
:TYPED BY THE ERROR TYPE SUBROUTINE. IF THE EMT ENTRY IS ZERO, THERE IS
:NO MESSAGE TO BE TYPED FOR THE ERROR.

:SIMILARLY, THE EHT, EDT, AND EFT ENTRIES ARE ADDRESSES OF TABLES
:OF HEADER, DATA AND FORMAT INFORMATION FOR A GIVEN ERROR. EACH ENTRY
:IN THE ERROR HEADER TABLE MAY OR MAY NOT HAVE AN ASSOCIATED LINE OF
:DATA, HOWEVER, EACH DATA LINE MUST HAVE AN ASSOCIATED FORMAT AND
:HEADER. THAT IS, A HEADER LINE MAY BE PRINTED WITHOUT ANY DATA,
:BUT A DATA LINE IS NOT PRINTED WITHOUT A HEADER, AND EACH DATA LINE
:MUST ALSO HAVE A FORMAT.

:IN SUMMARY,
: EACH NONZERO ENTRY IS THE ADDRESS OF A TABLE,
: EACH TABLE IS A LIST OF ADDRESSES WHICH DEFINES THE LOCATIONS
: OF MESSAGE STRINGS, HEADERS, DATA OR FORMAT.


```

1          ;THIS ROUTINE HANDLES UNEXPECTED TIMEOUTS
2
3 005342 011600      BADTMO: MOV      (SP),R0          ;SAVE PC WHERE THE TIME OUT OCCURED
4 005344 005740      TST      -(R0)           ;ADJUST PC -2
5 005346 022626      CMP      (SP)+,(SP)+     ;RESTORE STACK POINTER
6 005350 104401 005356  TYPE     ,65$         ;:TYPE ASCIZ STRING
   005354 000417      BR       ,64$         ;:GET OVER THE ASCIZ
   ;:65$: .ASCIZ <CRLF>/UNEXPECTED BUS TIMEOUT, PC=/
   64$:
7 005414 010046      MOV      R0,-(SP)       ;SETUP FOR TYPING OUT PC
8 005416 104402      TYPOC
9 005420 000240      NOP                    ;PUT 'HALT(0)' INSTRUCTION HERE IF YOU WISH
   ;TO STOP ON UNEXPECTED TIMECUT.
10
11
12          .SBTTL  START OF PROGRAM
13
14 005422 012737 177777 001330  START1: MOV      #-1,CHGADR      ;CHANGE RH/RM BUS ADDRESS
15 005430 000402      BR       START2
16
17 005432 005037 001330  START:  CLR      CHGADR      ;NO CHANGE IN ADDRESS
18 005436 000240      START2: NOP
19 005440 005227 000000  INC      #0          ;TTY LOOP, WAIT FOR INCREMENT
20 005444 001375      BNE     ,.-4         ;OF WORD
21 005446 000005      RESET    ,.-4         ;RESET THE WORLD
22
23          .SBTTL  INITIALIZE THE COMMON TAGS
   ;:CLEAR THE COMMON TAGS ($CMTAG) AREA
   MOV      # $CMTAG,R6      ;:FIRST LOCATION TO BE CLEARED
   CLR     (R6)+           ;:CLEAR MEMORY LOCATION
   CMP     # $SWR,R6        ;:DONE?
   BNE    ,.-6            ;:LOOP BACK IF NO
   MOV     # $STACK,SP     ;:SETUP THE STACK POINTER
   ;:INITIALIZE A FEW VECTORS
   MOV     # $SCOPE,@#IOTVEC ;:IOT VECTOR FOR SCOPE ROUTINE
   MOV     #340,@#IOTVEC+2 ;:LEVEL 7
   MOV     # $ERROR,@#EMTVEC ;:EMT VECTOR FOR ERROR ROUTINE
   MOV     #340,@#EMTVEC+2 ;:LEVEL 7
   MOV     # $TRAP,@#TRAPVEC ;:TRAP VECTOR FOR TRAP CALLS
   MOV     #340,@#TRAPVEC+2 ;:LEVEL 7
   MOV     # $PWRDN,@#PWRVEC ;:POWER FAILURE VECTOR
   MOV     #340,@#PWRVEC+2 ;:LEVEL 7
   MOV     $ENDCT,$EOPCT   ;:SETUP END-OF-PROGRAM COUNTER
   CLR     $TIMES          ;:INITIALIZE NUMBER OF ITERATIONS
   CLR     $ESCAPE        ;:CLEAR THE ESCAPE ON ERROR ADDRESS
   MOVB   #1,$ERMAX       ;:ALLOW ONE ERROR PER TEST
   MOV     #,$SLPADR      ;:INITIALIZE THE LOOP ADDRESS FOR SCOPE
   MOV     #,$SLPERR      ;:SETUP THE ERROR LOOP ADDRESS
   ;:SIZE FOR A HARDWARE SWITCH REGISTER, IF NOT FOUND OR IT IS
   ;:EQUAL TO A '-1', SETUP FOR A SOFTWARE SWITCH REGISTER.
   MOV     @#ERRVEC,-(SP)  ;:SAVE ERROR VECTOR
   MOV     #64$,@#ERRVEC  ;:SET UP ERROR VECTOR
   MOV     # $DSWR,$SWR   ;:SETUP FOR A HARDWARE SWICH REGISTER
   MOV     # $DDISP,$DISPLAY ;:AND A HARDWARE DISPLAY REGISTER
   CMP     #-1,@$SWR      ;:TRY TO REFERENCE HARDWARE SWR
   BNE    ,66$           ;:BRANCH IF NO TIMEOUT TRAP OCCURRED
   ;:AND THE HARDWARE SWR IS NOT = -1
   BR     ,65$           ;:BRANCH IF NO TIMEOUT
005450 012706 001114  MOV     # $CMTAG,R6      ;:FIRST LOCATION TO BE CLEARED
005454 005026  CLR     (R6)+           ;:CLEAR MEMORY LOCATION
005456 022706 001154  CMP     # $SWR,R6        ;:DONE?
005462 001374  BNE    ,.-6            ;:LOOP BACK IF NO
005464 012706 001100  MOV     # $STACK,SP     ;:SETUP THE STACK POINTER
005470 012737 064054 000020  MOV     # $SCOPE,@#IOTVEC ;:IOT VECTOR FOR SCOPE ROUTINE
005476 012737 000340 000022  MOV     #340,@#IOTVEC+2 ;:LEVEL 7
005504 012737 064640 000030  MOV     # $ERROR,@#EMTVEC ;:EMT VECTOR FOR ERROR ROUTINE
005512 012737 000340 000032  MOV     #340,@#EMTVEC+2 ;:LEVEL 7
005520 012737 067674 000034  MOV     # $TRAP,@#TRAPVEC ;:TRAP VECTOR FOR TRAP CALLS
005526 012737 000340 000036  MOV     #340,@#TRAPVEC+2 ;:LEVEL 7
005534 012737 070002 000024  MOV     # $PWRDN,@#PWRVEC ;:POWER FAILURE VECTOR
005542 012737 000340 000026  MOV     #340,@#PWRVEC+2 ;:LEVEL 7
005550 013737 037100 037072  MOV     $ENDCT,$EOPCT   ;:SETUP END-OF-PROGRAM COUNTER
005556 005037 001206  CLR     $TIMES          ;:INITIALIZE NUMBER OF ITERATIONS
005562 005037 001210  CLR     $ESCAPE        ;:CLEAR THE ESCAPE ON ERROR ADDRESS
005566 112737 000001 001131  MOVB   #1,$ERMAX       ;:ALLOW ONE ERROR PER TEST
005574 012737 005574 001122  MOV     #,$SLPADR      ;:INITIALIZE THE LOOP ADDRESS FOR SCOPE
005602 012737 005602 001124  MOV     #,$SLPERR      ;:SETUP THE ERROR LOOP ADDRESS
005610 013746 000004  MOV     @#ERRVEC,-(SP)  ;:SAVE ERROR VECTOR
005614 012737 005650 000004  MOV     #64$,@#ERRVEC  ;:SET UP ERROR VECTOR
005622 012737 177570 001154  MOV     # $DSWR,$SWR   ;:SETUP FOR A HARDWARE SWICH REGISTER
005630 012737 177570 001156  MOV     # $DDISP,$DISPLAY ;:AND A HARDWARE DISPLAY REGISTER
005636 022777 177777 173310  CMP     #-1,@$SWR      ;:TRY TO REFERENCE HARDWARE SWR
005644 001012  BNE    ,66$           ;:BRANCH IF NO TIMEOUT TRAP OCCURRED
   ;:AND THE HARDWARE SWR IS NOT = -1
005646 000403  BR     ,65$           ;:BRANCH IF NO TIMEOUT

```

```

INITIALIZE THE COMMON TAGS

005650 012716 005656 64$: MOV #65$, (SP) ;;SET UP FOR TRAP RETURN
005654 000002 RTI
005656 012737 000176 001154 65$: MOV #SWREG,SWR ;;POINT TO SOFTWARE SWR
005664 012737 000174 001156 MOV #DISPREG,DISPLAY
005672 012637 000004 66$: MOV (SP)+,@#ERRVEC ;;RESTORE ERROR VECTOR

005676 005037 001230 CLR $PASS ;;CLEAR PASS COUNT
005702 132737 000200 001243 BITB #APTSIZE,$ENVM ;;TEST USER SIZE UNDER APT
005710 001403 BEQ 67$ ;;YES,USE NON-APT SWITCH
005712 012737 001244 001154 MOV #$$SWREG,SWR ;;NO,USE APT SWITCH REGISTER
005720 67$:
24 ;SETUP 'TIMEOUT' TRAP VECTOR FOR UNEXPECTED BUS TIMEOUTS
25 005720 012737 005342 000004 MOV #BADTMO,ERRVEC ;;SETUP FOR UNEXPECTED TIMEOUT
26 005726 012737 000300 000006 MOV #PR6,ERRVEC+2 ;;LEVEL 6
27
28 .SBTTL TYPE PROGRAM NAME
;;TYPE THE NAME OF THE PROGRAM IF FIRST PASS
005734 005227 177777 INC #-1 ;;FIRST TIME?
005740 001035 BNE 68$ ;;BRANCH IF NO
005742 022737 037242 000042 CMP #SENDAD,@#42 ;;ACT-11?
005750 001431 BEQ 68$ ;;BRANCH IF YES
005752 104401 005760 TYPE ,69$ ;;TYPE ASCIZ STRING
005756 000426 BR 68$ ;;GET OVER THE ASCIZ
;;69$: .ASCIZ <CRLF>@CZRM080 - RM05/3/2 FUNCTIONAL TEST, PT 3@<CRLF>
68$:
006034 .SBTTL GET VALUE FOR SOFTWARE SWITCH REGISTER
006034 005737 000042 TST @#42 ;;ARE WE RUNNING UNDER XXDP/ACT?
006040 001012 BNE 70$ ;;BRANCH IF YES
006042 123727 001242 000001 CMPB $ENV,#1 ;;ARE WE RUNNING UNDER APT?
006050 001406 BEQ 70$ ;;BRANCH IF YES
006052 023727 001154 000176 CMP SWR,#SWREG ;;SOFTWARE SWITCH REG SELECTED?
006060 001005 BNE 71$ ;;BRANCH IF NO
006062 104407 GTSWR ;;GET SOFT-SWR SETTINGS
006064 000403 BR 71$
006066 112737 000001 001150 70$: MOVB #1,$AUTOB ;;SET AUTO-MODE INDICATOR
006074 71$:

29
30 ;THE FOLLOWING FINDS OUT THE PROGRAM CONTROL MODE:
31 ;PAPER TAPE (MANUAL), ACT11, XXDP CHAIN OR DUMP
32
33 006074 005037 001332 CLR XXDP ;;CLEAR 'XXDP' LOAD DEVICE STORAGE
34 006100 122737 000016 000041 CMPB #16,@#41 ;;LOADED FROM AN RM05/3/2 ?
35 006106 001160 BNE 3$ ;;BRANCH IF NOT
36 006110 013737 000040 001332 MOV @#40,XXDP ;;GET DEVICE INDICATOR AND NUMBER
37 006116 122737 000007 001332 CMPB #7,XXDP ;;IS IT A VALID NUMBER ?
38 006124 103002 BHIS 1$ ;;YES
39 006126 105037 001332 CLRB XXDP ;;NO, DEFAULT TO DRIVE 0
40 006132 005737 000042 1$: TST @#42 ;;CHAIN MODE OR ACT11 AUTO ACCEPT ?
41 006136 001425 BEQ 2$ ;;BR IF NEITHER
42 006140 104401 006146 TYPE ,73$ ;;TYPE ASCIZ STRING
006144 000412 BR 72$ ;;GET OVER THE ASCIZ
;;73$: .ASCIZ <CRLF>/NOT TESTING DRIVE /
72$:
43 006172 005046 CLR -(SP) ;;CLEAR WORD ON STACK
44 006174 113716 001332 MOVB XXDP,(SP) ;;GET DRIVE ADDRESS
45 006200 104403 TYPOS ;;TYPE THE ADDRESS
46 006202 001 .BYTE 1 ;;ONLY 1 CHARACTER

```

```

GET VALUE FOR SOFTWARE SWITCH REGISTER

47 006203      000
48 006204 104401 001217
49 006210 000517
50
51 006212 005227 177777 2$: INC #-1 ;FIRST TIME THRU HERE ?
52 006216 001114 BNE 3$ ;NO
53 006220 104401 006226 TYPE 75$ ;:TYPE ASCIZ STRING
    006224 000410 BR 74$ ;:GET OVER THE ASCIZ
    ;:75$: .ASCIZ <CRLF>/TO TEST DRIVE /
    74$:

54 006246 005046 CLR -(SP) ;CLEAR WORD ON STACK
55 006250 113716 001332 MOVB XXDP,(SP) ;GET DRIVE ADDRESS
56 006254 104403 TYPOS ;TYPE DRIVE ADDRFS
57 006256 001 .BYTE 1 ;ONLY 1 CHARACTER
58 006257 000 .BYTE 0 ;SUPPRESS LEADING ZEROS
59 006260 104401 006266 TYPE 77$ ;:TYPE ASCIZ STRING
    006264 000431 BR 76$ ;:GET OVER THE ASCIZ
    ;:77$: .ASCIZ /, HALT PROGRAM, REMOVE RRDPAK AND REPLACE IT/<CRLF>
    76$:

60 006350 TYPE 78$ ;:TYPE ASCIZ STRING
    C06350 104401 006356 BR 3$ ;:GET OVER THE ASCIZ
    006354 000435 ;:78$: .ASCIZ /WITH A WORK PAK, CLEAR LOCATION 40 AND RESTART PROGRAM./<CRLF>
    3$:

64 006450 ;CHECK FOR AUTO MODE OR STANDLONE MODE
65 006450 005737 000042 TST @#42 ;RUNNING IN AUTO MODE ?
66 006454 001561 BEQ STANDALONE ;BR IF NO
67 006456 012737 000377 001300 MOV #377,$DEV ;SET DEVICE MAP FOR ALL DRIVES
68
69 ;PROGRAM IS RUNNING IN AUTO MODE - SEE IF SIZING IS ALLOWED
70 006464 XSIZ:
71 006464 132737 000200 001243 BITB #BIT7,$ENVM ;SIZING ALLOWED ?
72 006472 001146 BNE 12$ ;NO
73
74 006474 005001 CLR R1 ;START FROM DRIVE 0
75 006476 013700 001276 MOV $BASE,R0 ;LOAD THE BASE ADDRESS
76 006502 104401 071430 TYPE ,SYSTAT ;TYPE 'UNIT STATUS:'
77

78 006506 136137 071746 001300 1$: BITB ATNTBL(R1),$DEV ;IS DEVICE PRESENT IN MAP ?
79 006514 001531 BEQ 11$ ;BR IF NO
80 006516 104401 001217 TYPE ,CRLF ;CR-LF
81 006522 010146 MOV R1,-(SP) ;SAVE R1 FOR TYPEOUT
    006524 104403 TYPOS ;GO TYPE--OCTAL ASCII
    006526 002 .BYTE 2 ;:TYPE 2 DIGIT(S)
    006527 000 .BYTE 0 ;:SUPPRESS LEADING ZEROS
82 006530 104401 071640 TYPE ,BLNKS4 ;TYPE 4 BLANKS
83

84 006534 012760 000040 000010 MOV #CLR,RMCS2(R0) ;CLEAR MASS BUS
85 006542 010160 000010 MOV R1,RMCS2(R0) ;LOAD THE DRIVE ADDRESS
86 006546 005760 000012 TST RMD5(R0) ;ACCESS DRIVE REGISTER
87 006552 032760 010000 000010 BIT #NED,RMCS2(R0) ;IS DRIVE PRESENT ?
88 006560 001051 BNE 3$ ;BR IF NO
89 006562 032760 004000 000000 BIT #DVA,RMCS1(R0) ;IS DRIVE AVAILABLE ?
90 006570 001450 BEQ 4$ ;BR IF NO
91 006572 016002 000026 MOV RMDT(R0),R2 ;SAVE DRIVE TYPE REGISTER IN R2
92 006576 012737 071446 006776 MOV #RMO2,10$ ;ASSUME RM02 DEVICE
93 006604 022702 020025 CMP #20025,R2 ;SINGLE PORT RM02 ?
94 006610 001430 BEQ 2$ ;BR IF YES

```

95	006612	022702	024025		CMP	#24025,R2	:DUAL PORT RM02 ?
96	006616	001425			BEQ	2\$:BR IF YES
97	006620	012737	071453	006776	MOV	#\$RM03,10\$:ASSUME RM03 DEVICE
98	006626	022702	020024		CMP	#20024,R2	:SINGLE PORT RM03 ?
99	006632	001417			BEQ	2\$:BR IF YES
100	006634	022702	024024		CMP	#24024,R2	:DUAL PORT RM03 ?
101	006640	001414			BEQ	2\$:BR IF YES
102	006642	012737	071460	006776	MOV	#\$RM05,10\$:ASSUME RM05 DEVICE
103	006650	022702	020027		CMP	#20027,R2	:SINGLE PORT RM05 ?
104	006654	001406			BEQ	2\$:BR IF YES
105	006656	022702	024027		CMP	#24027,R2	:DUAL PORT RM05 ?
106	006662	001403			BEQ	2\$:BR IF YES
107	006664	104401	071465		TYPE	,NOTRM	:DRIVE NOT AN RM05/3/2
108	006670	000412			BR	5\$:CHECK NEXT DRIVE
109	006672	032760	010000	000012	2\$: BIT	#MOL,RMDS(R0)	:IS MEDIUM ON LINE ?
110	006674	001412			BEQ	6\$:BR IF NO
111	006676	000417			BR	7\$	
112							
113	006704	104401	071523		3\$: TYPE	,NOTPRS	:DRIVE NOT PRESENT
114	006710	000402			BR	5\$:CHECK NEXT DRIVE
115							
116	006712	104401	071540		4\$: TYPE	,NOTAVL	:DRIVE NOT AVAILABLE
117	006716	146137	071746	001300	5\$: BICB	ATNTBL(R1), \$DEVM	:CLEAR DEVICE FROM BIT MAP
118	006724	000425			BR	11\$:CHECK NEXT DRIVE
119							
120	006726	104401	071557		6\$: TYPE	,UNTOFF	:DRIVE OFFLINE
121	006732	146137	071746	001300	BICB	ATNTBL(R1), \$DEVM	:CLEAR DEVICE FROM BIT MAP
122	006740	000413			BR	9\$:PRINT DRIVE TYPE
123							
124	006742	005737	001332		7\$: TST	XXDP	:LOADED FROM RM05/3/2 ?
125	006746	001406			BEQ	8\$:NO
126	006750	123701	001332		CMPB	XXDP,R1	:IS THIS THE DRIVE ?
127	006754	001360			BNE	5\$:BR IF NO
128	006756	104401	071506		TYPE	,LODEV	:DRIVE IS LOAD DEVICE
129	006762	000755			BR	5\$	
130							
131	006764	104401	071570		8\$: TYPE	,UNTON	:DRIVE ONLINE
132	006770	104401	071642		9\$: TYPE	,BLNKS2	:TYPE 2 BLANKS
133	006774	104401			TYPE		:PRINT DRIVE TYPE
134	006776	000000			10\$: .WORD	0	:MESSAGE ADDRESS HERE
135							
136	007000	005201			11\$: INC	R1	:INCREMENT THE DRIVE ADDRESS
137	007002	020127	000007		CMP	R1,#7	:ALL DRIVES ARE CHECKED ?
138	007006	003637			BLE	1\$:BRANCH IF NOT
139							
140	007010	104401	001217		12\$: TYPE	,\$CRLF	:CR-LF
141	007014	000137	007476		JMP	CMNSTART	:JUMP TO COMMON START

```

1          .SBTTL  STANDALONE INPUT ROUTINES
2
3          STANDALONE:
4 007020   004737   066310   JSR      PC,$TKINT      ;INITIALIZE CONSOLE
5
6 007024   005227   177777   INC      #-1           ;FIRST TIME THRU HERE ?
7 007030   001023           BNE      2$           ;BR IF NO
8
9          ;SEE IF OPERATOR WANTS HELP TEXT
10
11 007032   104401   070530   TYPE     ,MSHELP      ;WANT HELP ?
12 007036   104411           RDCHR           ;GET RESPONSE
13 007040   012637   001176   MOV      (SP)+,$TMP1   ;SAVE AND ECHO RESPONSE
14 007044   123727   001176   000131   CMPB    $TMP1,#'Y     ;WAS IT A YES RESPONSE ?
15 007052   001005           BNE      1$           ;NO
16 007054   104401   001176   TYPE     , $TMP1      ;TYPE 'Y'
17 007060   104401   106436   TYPE     ,HELP        ;YES - TYPE HELP TEXT
18 007064   000414           BR       3$           ;
19 007066   104401   071634   1$:     TYPE     ,N       ;TYPE 'N'
20 007072   104401   001217   TYPE     , $CRLF      ;CR-LF
21 007076   000407           BR       3$           ;
22
23          ;SEE IF USER WANTS TO CHANGE UNIBUS ADDRESS
24 007100           2$:
25 007100   005737   001330   TST     CHGADR        ;CHANGE RH/RM BUS ADDRESS ?
26 007104   001457           BEQ      7$           ;BR IF NO
27 007106   005037   001330   CLR     CHGADR        ;NO CHANGE NEXT TIME
28 007112   104401   001217   TYPE     , $CRLF      ;CR-LF
29
30          ;DIALOGUE TO CHANGE THE UNIBUS ADDRESS, VECTOR ADDRESS AND INTERRUPT PRIORITY
31 007116           3$:
32 007116   104401   071105   TYPE     ,CNSLO1      ;TYPE CURRENT BUS ADDRESS
33 007122   013746   001276   MOV     $BASE,-(SP)   ;:SAVE $BASE FOR TYPEOUT
34 007126   104402           TYPOC           ;:GO TYPE--OCTAL ASCII(ALL DIGITS)
35 007130   104401   071642   TYPE     ,BLNKS2     ;TYPE 2 BLANKS
36 007134   104413           RDOCT          ;GET NEW BUS ADDRESS
37 007136   012637   001176   MOV     (SP)+,$TMP1   ;CARRIAGE RETURN ?
38 007142   001412           BEQ      5$         ;YES-SKIP TO NEXT ENTRY
39 007144   022737   160000   001176   CMP     #160000,$TMP1 ;BASE ADDRESS IN I/O PAGE ?
40 007152   101403           BLOS     4$         ;YES
41 007154   104401   071115   TYPE     ,CNSLO2     ;TYPE WARNING MESSAGE
42 007160   000756           BR       3$         ;TRY AGAIN
43 007162   013737   001176   001276   4$:     MOV     $TMP1,$BASE   ;STORE NEW BUS ADDRESS
44 007170           5$:
45 007174   005046           CLR     -(SP)        ;
46 007176   113716   001272   MOVB   $VECT1,(SP)   ;GET CURRENT VECTOR ADDRESS
47 007202   104402           TYPOC           ;
48 007204   104401   071642   TYPE     ,BLNKS2     ;TYPE 2 BLANKS
49 007210   104413           RDOCT          ;GET NEW VECTOR ADDRESS
50 007212   012637   001176   MOV     (SP)+,$TMP1   ;CARRIAGE RETURN?
51 007216   001412           BEQ      7$         ;YES-SKIP TO NEXT ENTRY
52 007220   022737   0010C0   001176   CMP     #1000,$TMP1  ;VECTOR ADDRESS < 1000 ?
53 007226   101003           BHI     6$         ;YES!!
54 007230   104401   071166   TYPE     ,CNSLO4     ;TYPE WARNING MESSAGE
55 007234   000755           BR       5$         ;RETRY
56 007236   113737   001176   001272   6$:     MOVB   $TMP1,$VECT1  ;STORE NEW VECTOR ADDRESS

```

```

57
58 ;DIALOGUE TO INPUT DEVICE NUMBERS
59 007244 005227 177777
60 007250 001002
61 007252 104401 071222
62 007256 104401 001217
63 007262 005037 001300
64 007266 104401 071406
65 007272 104411
66 007274 012637 001176
67 007300 023727 001176 000101
68 007306 001007
69 007310 104401 070514
70 007314 012737 000377 001300
71 007322 000137 006464
72
73 007326 023727 001176 000015 10$:
74 007334 001436
75 007336 104401 001176
76 007342 023727 001176 000060
77 007350 002430
78 007352 023727 001176 000067
79 007360 003427
80 007362 000423
81
82 007364 104411
83 007366 012637 001176
84 007372 023727 001176 000015
85 007400 001432
86 007402 104401 070525
87 007406 104401 001176
88 007412 023727 001176 000060
89 007420 002404
90 007422 023727 001176 000067
91 007430 003403
92 007432 104401 071364
93 007436 000711
94
95 007440 013701 001176
96 007444 042701 177770
97 007450 156137 071746 001300
98 007456 122737 000377 001300
99 007464 101337
100 007466 104401 001217
101 007472 000137 006464

```

```

7$: INC #-1 ;FIRST TIME THRU ?
    BNE 8$ ;BR IF NO
    TYPE ,CNSL07 ;TYPE INPUT INSTRUCTIONS
8$: TYPE ,$CRLF ;CR-LF
9$: CLR $DEV ;CLEAR DEVICE MAP
    TYPE ,MSDRVS ;TYPE 'DRIVE(S): '
    RDCHR
    MOV (S?)+,$TMP1 ;GET RESPONSE
    CMP $TMP1,#'A ;IS INPUT 'A' ?
    BNE 10$ ;NO
    TYPE ,ALL ;YES, TYPE 'ALL' AND GO
    MOV #377,$DEV ;SET DEVICE MAP FOR ALL DRIVES
    JMP XSIZ ;AUTO SIZE.

10$: CMP $TMP1,#CR ;CARRIAGE RETURN ?
    BEQ 12$ ;YES
    TYPE , $TMP1 ;ECHO RESPONSE
    CMP $TMP1,#'0 ;NUMBER < 0 ?
    BLT 12$ ;YES
    CMP $TMP1,#'7 ;NUMBER > 7 ?
    BLE 13$ ;NO
    BR 12$ ;ILLEGAL INPUT

11$: RDCHR
    MOV (SP)+,$TMP1 ;GET RESPONSE
    CMP $TMP1,#CR ;CARRIAGE RETURN ?
    BEQ 14$ ;YES
    TYPE ,COMMA ;TYPE ','
    TYPE , $TMP1 ;ECHO RESPONSE
    CMP $TMP1,#'0 ;NUMBER < 0 ?
    BLT 12$ ;YES
    CMP $TMP1,#'7 ;NUMBER > 7 ?
    BLE 13$ ;NO
    TYPE ,CNSL08 ;TYPE CR-LF '' ?ILLEGAL INPUT''
    BR 9$ ;RETRY

13$: MOV $TMP1,R1 ;R1 = DRIVE NUMBER
    BIC #^C7,R1
    BISB ATNTBL(R1),$DEV ;SET DEVICE IN MAP
    CMPB #377,$DEV ;DONE ?
    BHI 11$ ;NO
    TYPE , $CRLF ;CR-LF
    JMP XSIZ ;GO SIZE DEVICES

```

```

1
2 007476
3 007476 104401 071600
4 007502 013700 001300
5 007506 001004
6 007510 104401 070525
7 007514 104401 071627
8 007520 012701 001470
9 007524 010137 001466
10 007530 012702 000001
11 007534 005003
12 007536 030200
13 007540 001413
14 007542 104401 070525
15 007546 010311
16 007550 010346
    007552 104403
    007554 001
    007555 000
17 007556 116361 071746 000001
18 007564 062701 000002
19 007570 006302
20 007572 105702
21 007574 001402
22 007576 005203
23 007600 000756
24 007602 005011
25 007604 104401 001217
26
27
28 007610 004737 043550
29 007614 000425
30 007616 104401 007624
    007622 000413
    007652
31 007652 005737 000042
32 007656 001002
33 007660 000137 005432
34 007664 000137 037232
35 007670
36
37 007670 000240
38 007672 105737 001300
39 007676 001007
40 007700 005737 000042
41 007704 001002
42 007706 000137 005432
43 007712 000137 037232
44
45 007716 105037 001116
46 007722 005037 001206
47 007726 005037 001326
48 007732 004737 066310
49 007736 012746 000240
    007742 012746 007750
    007746 000002
;ASSEMBLE TEST QUE FROM DEVICE MAP
CMNSTART:
    TYPE ,DRIVES ;TYPE 'DRIVE(S) TO BE TESTED'
    MOV $DEVN,R0 ;R0 = DEVICE MAP
    BNE 1$ ;BR IF DRIVES TO TEST ;
    TYPE ,COMMA ;TYPE ' ,'
    TYPE ,NONE ;TYPE 'NONE'
1$: MOV #TSTQUE+2,R1 ;R1 = ADDRESS OF FIRST ENTRY IN QUE
    MOV R1,TSTQUE ;INITIALIZE ENTRY POINTER
    MOV #1,R2 ;R2 = DEVICE POINTER
    CLR R3 ;R3 = DEVICE NUMBER
2$: BIT R2,R0 ;IS THIS DEVICE IN MAP ?
    BEQ 3$ ;NO !
    TYPE ,COMMA ;TYPE ' ,'
    MOV R3,(R1) ;YES - ENTER DEVICE NUMBER IN QUE
    MOV R3,-(SP) ;SAVE R3 FOR TYPEOUT
    TYPOS ;GO TYPE--OCTAL ASCII
    .BYTE 1 ;TYPE 1 DIGIT(S)
    .BYTE 0 ;SUPPRESS LEADING ZEROS
    MOVB ATNTBL(R3),1(R1) ;ENTER ATTENTION BIT IN QUE
    ADD #2,R1 ;ADVANCE ENTRY POINTER
3$: ASL R2 ;ADVANCE DEVICE POINTER
    TSTB R2 ;DONE ALL DEVICES ?
    BEQ 4$ ;YES
    INC R3 ;ADVANCE DEVICE NUMBER
    BR 2$ ;ENTER NEXT DEVICE
4$: CLR (R1) ;TERMINATE TEST QUE
    TYPE ,$CRLF ;TYPE CR-LF

;SIZE FOR CLOCK
    JSR PC,$IZCLK ;SEE IF CLOCK PRESENT
    BR 6$ ;YES - CLOCK IS PRESENT
    TYPE ,65$ ;TYPE ASCII STRING
    BR 64$ ;GET OVER THE ASCIIZ
65$: .ASCIIZ <CRLF>/NO 'L' OR 'P' CLOCK/
64$:
    TST @#42 ;ANY MONITOR PRESENT ?
    BNE 5$ ;BR IF YES
    JMP START ;JUMP TO START
5$: JMP $GET42 ;RETURN CONTROL TO MONITOR
6$:

READY: NOP ;READY TO START TEST
    TSTB $DEVN ;ANY DRIVES IN MAP ?
    BNE 2$ ;BR IF YES
    TST @#42 ;ANY MONITOR PRESENT ?
    BNE 1$ ;BR IF YES
    JMP START ;JUMP TO START
1$: JMP $GET42 ;RETURN CONTROL TO MONITOR

2$: CLRB $TSTNM ;RESET TEST NUMBER
    CLR $TIMES ;INITIALIZE NUMBER OF ITERATIONS
    CLR CTLFG ;CLEAR CONTROL-C FLAG
    JSR PC,$TKINT ;INITIALIZE TTY
    MOV #PR5,-(SP) ;PUT NEW PS ON STACK
    MOV #64$,-(SP) ;PUT NEW PC ON STACK
    RTI ;POP NEW PC AND PS

```

```

007750
50 007750 117737 171512 001234 64$: MOVB @TSTQUE,$UNIT ;LOAD DRIVE NUMBER
51 007756 005037 001512 CLR MEDENB ;CLEAR MEDIA ENABLE
52
53 ;CLEAR MASSBUS CONTROLLER, SELECT DRIVE AND DETERMINE THE LAST TRACK
54 ;OF THE DIFFERENT DRIVE TYPES
55
56 007762 012737 002000 001334 MOV #TA4,LSTRK ;ASSUME LAST TRACK FOR RM02/3 = 4.
57 007770 013700 001276 MCV $BASE,R0 ;R0 = UNIBUS ADDRESS
58 007774 012760 000040 000010 MOV #CLR,RMCS2(R0) ;CLEAR MASSBUS
59 010002 117760 171460 000010 MOVB @TSTQUE,RMCS2(R0) ;SELECT DEVICE UNDER TEST
60 010010 016002 000026 MOV RMDT(R0),R2 ;GET RMDT AND
61 010014 042702 177770 BIC #177770,R2 ;SAVE DRIVE TYPE BITS
62 010020 022702 000007 CMP #7,R2 ;IS IT AN RM05 ?
63 010024 001003 BNE 3$ ;NO, MUST BE AN RM02 OR RM03
64 010026 012737 011000 001334 MOV #TA16.TA2,LSTRK ;YES--SET LAST TRACK - 18.
65
66 ;TYPE DRIVE NUMBER TO BE TESTED($UNIT)
67
68 C10034 104401 0C1217 3$: TYPE $CRLF ;CR-LF
69 010040 104401 071422 TYPE $MSGDRV ;TYPE 'DRIVE'
70 010044 013746 001234 MOV $UNIT,-(SP) ;;SAVE $UNIT FOR TYPEOUT
;;TYPE DRIVE NUMBER
;;GO TYPE--OCTAL ASCII
;;TYPE ? DIGIT(S)
;;SUPPRESS LEADING ZEROS
;;THESE TWO LOOPS ARE ADDED TO
;;WAIT FOR TTY
010050 104403 TYPOS
010052 002 .BYTE 2
010053 000 .BYTE 0
71 010054 005004 CLR R4
72 010056 005304 DEC R4
73 010060 001376 BNE .-2
74 010062 005304 DEC R4
75 010064 001376 BNE .-2

```


1
2

```

*****
*TEST 1          CONTROLLER ACCESS TEST
*****
TST1:

```

010066				SCOPE	;SCOPE CALL
010066	000004			NOP	;START OF TEST
010070	000240				
010072	012706	001100		MOV #STACK,SP	;INITIALIZE STACK POINTER
010076	013700	001276		MOV \$BASE,R0	;R0 = UNIBUS ADDRESS
010102	013701	001466		MOV TSTQUE,R1	;(R1) = DEVICE BEING TESTED
010106	012737	000001	001226	MOV #1,\$TESTN	;;SET TEST NUMBER IN APT MAIL BOX
3					
4	010114	005001		CLR R1	
5	010116	013746	000004	MOV ERRVEC,-(SP)	;;PUSH ERRVEC ON STACK
	010122	013746	000006	MOV ERRVEC+2,-(SP)	;;PUSH ERRVEC+2 ON STACK
6	010126	012737	010230	MOV #1\$,ERRVEC	
7	010134	012737	000300	MOV #PR6,ERRVEC+2	
8					
9	010142	110160	000001	MOVB R1,RMCS1+1(R0)	;MOVE HI BYTE TO RMCS1
10	010146	010160	000002	MOV R1,RMWC(R0)	;MOVE WORD COUNT REGISTER
11	010152	016002	000002	MOV RMWC(R0),R2	
12	010156	010160	000004	MOV R1,RMBA(R0)	;MOVE BUS ADDRESS REGISTER
13	010162	016002	000004	MOV RMBA(R0),R2	
14	010166	016046	000010	MOV RMCS2(R0),-(SP)	;;PUSH RMCS2(R0) ON STACK
15	010172	010160	000010	MOV R1,RMCS2(R0)	;MOVE CONTROL STATUS REGISTER
16	010176	016002	000010	MOV RMCS2(R0),R2	
17	010202	012660	000010	MOV (SP)+,RMCS2(R0)	;;POP STACK INTO RMCS2(R0)
18	010206	010160	000022	MOV R1,RMDB(R0)	;MOVE DATA BUFFER
19	010212	016002	000022	MOV RMDB(R0),R2	
20	010216	012637	000006	MOV (SP)+,ERRVEC+2	;;POP STACK INTO ERRVEC+2
	010222	012637	000004	MOV (SP)+,ERRVEC	;;POP STACK INTO ERRVEC
21	010226	000417		BR 3\$;NO BUS TIMEOUT OCCURRED
22					
23	010230	022626		1\$: CMP (SP)+,(SP)+	;ADJUST STACK
24	010232	012637	000006	MOV (SP)+,ERRVEC+2	;;POP STACK INTO ERRVEC+2
	010236	012637	000004	MOV (SP)+,ERRVEC	;;POP STACK INTO ERRVEC
25	010242	104110		EMT 110	
26	010244	005737	000042	TST @#42	;STAND ALONE MODE ?
27	010250	001002		BNE 2\$;NO!!
28	010252	000137	005422	JMP START1	;YES-GO GET \$BASE
29	010256	005037	001300	2\$: CLR \$DEVM	;FUDGE NO DRIVES IN MAP
30	010262	000137	037044	JMP \$EOP	;RETURN TO \$EOP
31	010266			3\$:	

```

*****
*TEST 2          WRITE, READ ZEROS
*****
TST2:

```

010266				SCOPE	;SCOPE CALL
010266	000004			NOP	;START OF TEST
010270	000240				
010272	012706	001100		MOV #STACK,SP	;INITIALIZE STACK POINTER
010276	013700	001276		MOV \$BASE,R0	;R0 = UNIBUS ADDRESS
010302	013701	001466		MOV TSTQUE,R1	;(R1) = DEVICE BEING TESTED
010306	012737	000002	001226	MOV #2,\$TESTN	;;SET TEST NUMBER IN APT MAIL BOX
34					
35					
36					

```

*****
;LOOP #1          FORMAT,WRITE,READ
*****

```

```

37
38 010314          1$:
39
40
41 010314 004737 037316 ;PREPARE DEVICE FOR TEST
    010320 154130          JSR PC,TSTPRP          ;PREPARE DEVICE FOR TEST
                                .WORD 154130          ;TASK DESCRIPTOR AS FOLLOWS:
                                ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
                                ;CLEAR CONTROLLER & SELECT DEVICE
                                ;VERIFY CONTROLLER CLEAR OPERATION
                                ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
                                ;VERIFY PACK ACKNOWLEDGE
                                ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
                                ;VERIFY RECALIBRATION
                                ;GO TO 2$ IF NO ERROR
                                ;RETURN HERE IF ERROR
                                ;ERROR # DEFINED BY TSTPRP SUBROUTINE
                                ;GO TO 25$ IF ERROR

    010322 000404          BR          2$
    010324 000240          NOP
    010326 104000          EMT
    010330 000137 011274  JMP          25$

42
43          ;LOAD PARAMETERS AND GENLRATE DATA BUFFER
44          2$:
45 010334 012737 000000 001446      MOV          #0,RMDCO          ;CYLINDER = 0
46 010342 012737 000000 001420      MOV          #0,RMDAO          ;TRACK - 0, SECTOR 0
47 010350 012737 106436 001416      MOV          #BUFONE,RMBAO      ;BUS ADDRESS
48 010356 012737 177376 001414      MOV          #-258.,RMWCO       ;2 + 256. WORDS (2'S COMP)
49 010364 012737 010000 001444      MOV          #FMT16,RMOFO       ;16 BIT FORMAT
50 010372 012737 000063 001412      MOV          #WH!GO,RMCS10      ;WRITE HEADER AND DATA COMMAND
51
52          ;VERIFY THAT SECTOR IS NOT BAD
    010400 004737 040242          JSR          PC,BADSCT          ;CALL BAD SECTOR MODULE
    010404 000405          BR          3$                ;GO TO 3$ IF NO ERROR
    010406 104401 070426          TYPE          ,SCTMSG          ;TYPE BAD SECTOR MESSAGE
    010412 104000          EMT
    010414 000137 011274          JMP          25$                ;ERROR # DEFINED BY BADSCT SUBROUTINE
                                ;GO TO 25$ IF ERROR

53          3$:
54 010420 012737 072060 001174      MOV          #ZEROS,$TMP0       ;STARTING ADDRESS OF PATTERN
55 010426 012737 000001 001176      MOV          #1,$TMP1          ;RANGE OF PATTERN
56 010434 004737 042174          JSR          PC,GENBUF          ;GO GENERATE BUFFER FOR FORMAT
57
58          ;SETUP PARAMETERS AND EXECUTE COMMAND
59 010440 012702 001553          MOV          #PUTINX,R2          ;R2 BYTE ENTRY POSITION
60 010444 112722 000034          MOVVB       #RMDC,(R2)+
61 010450 112722 000006          MOVVB       #RMDA,(R2)+
62 010454 112722 000004          MOVVB       #RMBA,(R2)+
63 010460 112722 000002          MOVVB       #RMWC,(R2)+
64 010464 112722 000032          MOVVB       #RMOF,(R2)+
65 010470 112722 000000          MOVVB       #RMCS1,(R2)+
66 010474 112712 000200          MOVVB       #200,(R2)          ;TERMINATE TABLE
67 010500
68 010500 004737 043330          4$:
    010504 000404          JSR          PC,PUT            ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
    010506 000240          BR          5$                ;GO TO 5$ IF NO ERROR
    010510 104000          NOP
    010512 000137 011274          EMT
                                ;RETURN HERE IF ERROR
                                ;ERROR # DEFINED BY PUT SUBROUTINE
                                ;GO TO 25$ IF ERROR

69 010516          5$:
70
71 010516 004737 042774          ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
                                JSR          PC,GETSTS          ;GO TO GETSTS SUBROUTINE
    
```

```

72
73 ;WAIT FOR COMMAND TO COMPLETE
010522 004737 043672 JSR PC,TIMOUT ;GO TO TIMEOUT SUBROUTINE
74
75 ;GO GET REGISTER STATUS
76 010526 004737 043060 JSR PC,GET ;GO READ REGISTER(S) WITH GET SUBROUTINE
010532 000404 BR 6$ ;GO TO 6$ IF NO ERROR
010534 000240 NOP ;RETURN HERE IF ERROR
010536 104000 EMT ;ERROR # DEFINED BY GET SUBROUTINE
010540 000137 011274 JMP 25$ ;GO TO 25$ IF ERROR
77 010544 6$:
78
79 ;VERIFY RESULTS OF WRITE COMMAND
80 010544 004737 056572 JSR PC,DTASTS ;GO VERIFY RESULTS OF DATA TRANSFER
010550 000405 BR 7$ ;GO TO 7$ IF NO ERROR
010552 000240 NOP ;RETURN HERE IF ERROR
010554 104000 EMT ;ERROR # DEFINED BY DTASTS SUBROUTINE
010556 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
010560 000137 011274 JMP 25$ ;GO TO 25$ IF ERROR
81 010564 7$:
82
83 ;MOVE LOOP ADDRESSES TO NEXT OPERATION
84 010564 012737 010574 001124 MOV #8$, $LPERR
85 010572 000410 BR 9$ ;SKIP TO WRITE OPERATION
86
87 ;*****
88 ;LOOP #2 WRITE,READ
89
90 010574 8$:
91
92 ;PREPARE DEVICE FOR TEST
93 010574 004737 037316 JSR PC,TSTPRP ;PREPARE DEVICE FOR TEST
010600 154130 .WORD 154130 ;TASK DESCRIPTOR AS FOLLOWS:
;SELECT DEVICE & VERIFY DEVICE AVAILABLE
;CLEAR CONTROLLER & SELECT DEVICE
;VERIFY CONTROLLER CLEAR OPERATION
;PACK ACKNOWLEDGE IF VOLUME NOT VALID
;VERIFY PACK ACKNOWLEDGE
;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
;VERIFY RECALIBRATION
;GO TO 9$ IF NO ERROR
;RETURN HERE IF ERROR
;ERROR # DEFINED BY TSTPRP SUBROUTINE
;GO TO 25$ IF ERROR
010602 000404 BR 9$
010604 000240 NOP
010606 104000 EMT
010610 000137 011274 JMP 25$
94 010614 9$:
95
96 ;SETUP PARAMETERS AND EXECUTE COMMAND
97 010614 10$:
98 010614 012737 106442 001416 MOV #BUFONE+4, RMBAD ;MOVE MEMORY ADDRESS
99 010622 012737 177400 001414 MOV #-256, RMWCO ;CHANGE WORD COUNT
100 010630 012737 000061 001412 MOV #WD!GO, RMCS10 ;WRITE DATA COMMAND
101 010636 012702 001553 MOV #PUTINX, R2 ;LOAD PUT REGISTER INDEX TABLE
102 010642 112722 000006 MOVB #RMDA, (R2)+
103 010646 112722 000034 MOVB #RMDC, (R2)+
104 010652 112722 000032 MOVB #RMOF, (R2)+
105 010656 112722 000004 MOVB #RMBA, (R2)+
106 010662 112722 000002 MOVB #RMWC, (R2)+

```

```
107 010666 112722 000000      MOVB   #RMCS1,(R2)+
108 010672 112722 000200      MOVB   #200,(R2)+           ;TERMINATE TABLE
109
110 010676 004737 043330      JSR    PC,PUT              ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
    010702 000404              BR     11$                 ;GO TO 11$ IF NO ERROR
    010704 000240              NOP                    ;RETURN HERE IF ERROR
    010706 104000              EMT                    ;ERROR # DEFINED BY PUT SUBROUTINE
    010710 000137 011274      JMP    25$                 ;GO TO 25$ IF ERROR
111 010714                      11$:
112
113                          ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
    010714 004737 042774      JSR    PC,GETSTS           ;GO TO GETSTS SUBROUTINE
114
115                          ;WAIT FOR COMMAND TO COMPLETE
    010720 004737 043672      JSR    PC,TIMOUT          ;GO TO TIMOUT SUBROUTINE
116
117                          ;GO GET REGISTER STATUS
118 010724 004737 043060      JSR    PC,GET              ;GO READ REGISTER(S) WITH GET SUBROUTINE
    010730 000404              BR     12$                 ;GO TO 12$ IF NO ERROR
    010732 000240              NOP                    ;RETURN HERE IF ERROR
    010734 104000              EMT                    ;ERROR # DEFINED BY GET SUBROUTINE
    010736 000137 011274      JMP    25$                 ;GO TO 25$ IF ERROR
119 010742                      12$:
120
121                          ;VERIFY RESULTS OF WRITE COMMAND
122 010742 004737 044056      JSR    PC,PRIERR          ;GO CHECK FOR PRIMARY ERRORS
    010746 000405              BR     13$                 ;GO TO 13$ IF NO ERROR
    010750 000240              NOP                    ;RETURN HERE IF ERROR
    010752 104000              EMT                    ;ERROR # DEFINED BY PRIERR SUBROUTINE
    010754 004736              JSR    PC,@(SP)+          ;GO BACK FOR MORE ERROR CHECKS
    010756 000137 011274      JMP    25$                 ;GO TO 25$ IF ERROR
123 010762                      13$:
124 010762 004737 056572      JSR    PC,DTASTS          ;GO VERIFY RESULTS OF DATA TRANSFER
    010766 000405              BR     14$                 ;GO TO 14$ IF NO ERROR
    010770 000240              NOP                    ;RETURN HERE IF ERROR
    010772 104000              EMT                    ;ERROR # DEFINED BY DTASTS SUBROUTINE
    010774 004736              JSR    PC,@(SP)+          ;GO BACK FOR MORE ERROR CHECKS
    010776 000137 011274      JMP    25$                 ;GO TO 25$ IF ERROR
125 011002                      14$:
126 011002 004737 044710      JSR    PC,SECERR          ;GO CHECK FOR SECONDARY ERRORS
    011006 000405              BR     15$                 ;GO TO 15$ IF NO ERROR
    011010 000240              NOP                    ;RETURN HERE IF ERROR
    011012 104000              EMT                    ;ERROR # DEFINED BY SECERR SUBROUTINE
    011014 004736              JSR    PC,@(SP)+          ;GO BACK FOR MORE ERROR CHECKS
    011016 000137 011274      JMP    25$                 ;GO TO 25$ IF ERROR
127 011022                      15$:
128
129                          ;CHANGE LOOP ADDRESSES
130 011022 012737 011032 001124  MOV    #16$,$LPERR
131 011030 000410              BR     17$                 ;SKIP TO NEXT OPERATION
132
133                          ;*****
134                          ;LOOP #3      READ
135
136 011032                      16$:
137
138                          ;PREPARE DEVICE FOR TEST
```

```

139 011032 004737 037316 JSR PC,TSTPRP ;PREPARE DEVICE FOR TEST
    011036 154130 .WORD 154130 ;TASK DESCRIPTOR AS FOLLOWS:
                                           ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
                                           ;CLEAR CONTROLLER & SELECT DEVICE
                                           ;VERIFY CONTROLLER CLEAR OPERATION
                                           ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
                                           ;VERIFY PACK ACKNOWLEDGE
                                           ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
                                           ;VERIFY PE CALIBRATION
    011040 000404 BR 17$ ;GO TO 17$ IF NO ERROR
    011042 000240 NOP ;RETURN HERE IF ERROR
    011044 104000 EMT ;ERROR # DEFINED BY TSTPRP SUBROUTINE
    011046 000137 011274 JMP 25$ ;GO TO 25$ IF ERROR
140 011052 17$:
141
142 ;SETUP PARAMETERS AND EXECUTE COMMAND
143 011052 18$:
144 011052 012737 107446 001416 MOV #BUFTWO+4,RMBA0 ;CHANGE MEMORY ADDRESS
145 011060 012737 000071 001412 MOV #RD!GO,RMCS10 ;READ DATA COMMAND
146 011066 012702 001553 MOV #PUTINX,R2 ;LOAD PUT REGISTER INDEX TABLE
147 011072 112722 000006 MOVB #RMDA,(R2)+
148 011076 112722 000032 MOVB #RMOF,(R2)+
149 011102 112722 000034 MOVB #RMDC,(R2)+
150 011106 112722 000004 MOVB #RMBA,(R2)+
151 011112 112722 000002 MOVB #RMWC,(R2)+
152 011116 112722 000000 MOVB #RMCS1,(R2)+
153 011122 112712 000200 MOVB #200,(R2)
154
155 011126 004737 043330 JSR PC,PUT ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
    011132 000404 BR 19$ ;GO TO 19$ IF NO ERROR
    011134 000240 NOP ;RETURN HERE IF ERROR
    011136 104000 EMT ;ERROR # DEFINED BY PUT SUBROUTINE
    011140 000137 011274 JMP 25$ ;GO TO 25$ IF ERROR
156 011144 19$:
157
158 ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
    011144 004737 042774 JSR PC,GETSTS ;GO TO GETSTS SUBROUTINE
159
160 ;WAIT FOR COMMAND TO COMPLETE
    011150 004737 043672 JSR PC,TIMOUT ;GO TO TIMOUT SUBROUTINE
161
162 ;GO GET REGISTER STATUS
163 011154 004737 043060 JSR PC,GET ;GO READ REGISTER(S) WITH GET SUBROUTINE
    011160 000404 BR 20$ ;GO TO 20$ IF NO ERROR
    011162 000240 NOP ;RETURN HERE IF ERROR
    011164 104000 EMT ;ERROR # DEFINED BY GET SUBROUTINE
    011166 000137 011274 JMP 25$ ;GO TO 25$ IF ERROR
164 011172 20$:
165
166 ;VERIFY RESULTS OF READ COMMAND
167 011172 004737 044056 JSR PC,PRIERR ;GO CHECK FOR PRIMARY ERRORS
    011176 000405 BR 21$ ;GO TO 21$ IF NO ERROR
    011200 000240 NOP ;RETURN HERE IF ERROR
    011202 104000 EMT ;ERROR # DEFINED BY PRIERR SUBROUTINE
    011204 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
    011206 000137 011274 JMP 25$ ;GO TO 25$ IF ERROR
168 011212 21$:

```

```

169 011212 004737 056572      JSR    PC,DTASTS      ;GO VERIFY RESULTS OF DATA TRANSFER
      011216 000405          BR     22$           ;GO TO 22$ IF NO ERROR
      011220 000240          NOP                    ;RETURN HERE IF ERROR
      011222 104000          EMT                    ;ERROR # DEFINED BY DTASTS SUBROUTINE
      011224 004736          JSR    PC,@(SP)+      ;GO BACK FOR MORE ERROR CHECKS
      011226 000137 011274    JMP     25$           ;GO TO 25$ IF ERROR
170 011232 000000 011274    22$:
171 011232 004737 044710      JSR    PC,SECERR     ;GO CHECK FOR SECONDARY ERRORS
      011236 000405          BR     23$           ;GO TO 23$ IF NO ERROR
      011240 000240          NOP                    ;RETURN HERE IF ERROR
      011242 104000          EMT                    ;ERROR # DEFINED BY SECERR SUBROUTINE
      011244 004736          JSR    PC,@(SP)+      ;GO BACK FOR MORE ERROR CHECKS
      011246 000137 011274    JMP     25$           ;GO TO 25$ IF ERROR
172 011252 000000 011274    23$:
173
174
175 011252 004737 042432      ;GO VERIFY DATA
      011256 106442          JSR    PC,CMPBUF     ;GO COMPARE WRITE, READ DATA BUFFERS
      011260 107446          .WORD  BUFOFF+4      ;STARTING ADDRESS OF WRITE BUFFER
      011262 000404          .WORD  BUFOFF+4      ;STARTING ADDRESS OF READ BUFFER
      011264 000240          BR     24$           ;GO TO 24$ IF NO ERROR
      011266 104000          NOP                    ;RETURN HERE IF ERROR
      011270 000137 011274    EMT                    ;ERROR # DEFINED BY CMPBUF SUBROUTINE
      011274 000000 011274    JMP     25$           ;GO TO 25$ IF ERROR
176 011274 000000 011274    24$:
177
178 011274 000000 011274    25$:
179
180
      ;*****
      ;*TEST 3      WRITE, WRITE CHECK ZEROS
      ;*****
      TST3:
      011274 000004          SCOPE                    ;SCOPE CALL
      011276 000240          NOP                    ;START OF TEST
      011300 012706 001100    MOV     #STACK,SP     ;INITIALIZE STACK POINTER
      011304 013700 001276    MOV     $BASE,R0      ;R0 = UNIBUS ADDRESS
      011310 013701 001466    MOV     TSTQUE,R1     ;(R1) = DEVICE BEING TESTED
      011314 012737 000003 001226  MOV     #3,$TESTN     ;;SET TEST NUMBER IN APT MAIL BOX
181
182
183
184
185 011322 000000 011322    ;*****
186
187
188 011322 004737 037316      ;LOOP #1      FORMAT,WRITE,WRITE CHECK DATA
      011326 154130          1$:
      ;PREPARE DEVICE FOR TEST
      JSR    PC,TSTPRP   ;PREPARE DEVICE FOR TEST
      .WORD 154130      ;TASK DESCRIPTOR AS FOLLOWS:
                        ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
                        ;CLEAR CONTROLLER & SELECT DEVICE
                        ;VERIFY CONTROLLER CLEAR OPERATION
                        ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
                        ;VERIFY PACK ACKNOWLEDGE
                        ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
                        ;VERIFY RECALIBRATION
      011330 000404          BR     2$           ;GO TO 2$ IF NO ERROR
      011332 000240          NOP                    ;RETURN HERE IF ERROR
      011334 104000          EMT                    ;ERROR # DEFINED BY TSTPRP SUBROUTINE
      011336 000137 012252    JMP     24$           ;GO TO 24$ IF ERROR

```

```

189
190 ;LOAD PARAMETERS AND GENERATE DATA BUFFER
191 011342 2$:
192 011342 012737 000000 001446 MOV #0,RMDC0 ;CYLINDER = 0
193 011350 012737 000000 001420 MOV #0,RMDAO ;TRACK = 0, SECTOR - 0
194 011356 012737 106436 001416 MOV #BUFONE,RMBA0 ;BUS ADDRESS
195 011364 012737 177376 001414 MOV #-258.,RMWCO ;2 + 256. WORDS (2'S COMP)
196 011372 012737 010000 001444 MOV #FMT16,RMOFO ;16 BIT FORMAT
197 011400 012737 000063 001412 MOV #WH!GO,RMCS10 ;WRITE HEADER AND DATA COMMAND
198
199 ;VERIFY THAT SECTOR IS NOT BAD
011406 004737 040242 JSR PC,BADSCT ;CALL BAD SECTOR MODULE
011412 000405 BR 3$ ;GO TO 3$ IF NO ERROR
011414 104401 070426 TYPE ,SCTMSG ;TYPE BAD SECTOR MESSAGE
011420 104000 EMT ;ERROR # DEFINED BY BADSCT SUBROUTINE
011422 000137 012252 JMP 24$ ;GO TO 24$ IF ERROR
200 011426 3$:
201 011426 012737 072060 001174 MOV #ZEROS,$TMP0 ;STARTING ADDRESS OF PATTERN
202 011434 012737 000001 001176 MOV #1,$TMP1 ;RANGE OF PATTERN
203 011442 004737 042174 JSR PC,GENBUF ;GO GENERATE BUFFER FOR FORMAT
204
205 ;SETUP PARAMETERS AND EXECUTE COMMAND
206 011446 012702 001553 MOV #PUTINX,R2 ;R2 = BYTE ENTRY POSITION
207 011452 112722 000034 MOVB #RMDC,(R2)+
208 011456 112722 000006 MOVB #RMDA,(R2)+
209 011462 112722 000004 MOVB #RMBA,(R2)+
210 011466 112722 000002 MOVB #RMWC,(R2)+
211 011472 112722 000032 MOVB #RMOF,(R2)+
212 011476 112722 000000 MOVB #RMCS1,(R2)+
213 011502 112712 000200 MOVB #200,(R2) ;TERMINATE TABLE
214 011506
215 011506 004737 043330 4$: JSR PC,PUT ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
011512 000404 BR 5$ ;GO TO 5$ IF NO ERROR
011514 000240 NOP ;RETURN HERE IF ERROR
011516 104000 EMT ;ERROR # DEFINED BY PUT SUBROUTINE
011520 000137 012252 JMP 24$ ;GO TO 24$ IF ERROR
216 011524
217
218 ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
011524 004737 042774 JSR PC,GETSTS ;GO TO GETSTS SUBROUTINE
219
220 ;WAIT FOR COMMAND TO COMPLETE
011530 004737 043672 JSR PC,TIMOUT ;GO TO TIMOUT SUBROUTINE
221
222 ;GO GET REGISTER STATUS
223 011534 004737 043060 JSR PC,GET ;GO READ REGISTER(S) WITH GET SUBROUTINE
011540 000404 BR 6$ ;GO TO 6$ IF NO ERROR
011542 000240 NOP ;RETURN HERE IF ERROR
011544 104000 EMT ;ERROR # DEFINED BY GET SUBROUTINE
011546 000137 012252 JMP 24$ ;GO TO 24$ IF ERROR
224 011552
225
226 ;VERIFY RESULTS OF WRITE COMMAND
227 011552 004737 056572 JSR PC,DTASTS ;GO VERIFY RESULTS OF DATA TRANSFER
011556 000405 BR 7$ ;GO TO 7$ IF NO ERROR
011560 000240 NOP ;RETURN HERE IF ERROR
011562 104000 EMT ;ERROR # DEFINED BY DTASTS SUBROUTINE

```

```

011564 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
011566 000137 G12252 JMP 24$ ;GO TO 24$ IF ERROR
228 011572 7$:
229
230 ;MOVE LOOP ADDRESSES TO NEXT OPERATION
231 011572 012737 011602 001124 MOV #8$, $LPERR
232 011600 000410 BR 9$ ;SKIP TO WRITE OPERATION
233
234 ;*****
235 ;LOOP #2 WRITE,WRITE CHECK DATA
236
237 011602 8$:
238
239 ;PREPARE DEVICE FOR TEST
240 011602 004737 037316 JSR PC,TSTPRP ;PREPARE DEVICE FOR TEST
011606 154130 .WORD 154130 ;TASK DESCRIPTOR AS FOLLOWS:
;SELECT DEVICE & VERIFY DEVICE AVAILABLE
;CLEAR CONTROLLER & SELECT DEVICE
;VERIFY CONTROLLER CLEAR OPERATION
;PACK ACKNOWLEDGE IF VOLUME NOT VALID
;VERIFY PACK ACKNOWLEDGE
;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
;VERIFY RECALIBRATION
;GO TO 9$ IF NO ERROR
;RETURN HERE IF ERROR
;ERROR # DEFINED BY TSTPRP SUBROUTINE
;GO TO 24$ IF ERROR
011610 000404 BR 9$
011612 000240 NOP
011614 104000 EMT
011616 000137 012252 JMP 24$
241 011622 9$:
242
243 ;SETUP PARAMETERS AND EXECUTE COMMAND
244 011622 10$:
245 011622 012737 106442 001416 MOV #BUFONE+4, RMBA0 ;CHANGE MEMORY ADDRESS
246 011630 012737 177400 001414 MOV #-256, RMWCO ;CHANGE WORD COUNT
247 011636 012737 000061 001412 MOV #WD!GO, RMCS10 ;WRITE DATA COMMAND
248 011644 012702 001553 MOV #PUTINX, R2 ;LOAD PUT REGISTER INDEX TABLE
249 011650 112722 000006 MOVB #RMDA, (R2)+
250 011654 112722 000034 MOVB #RMDC, (R2)+
251 011660 112722 000032 MOVB #RMOF, (R2)+
252 011664 112722 000004 MOVB #RMBA, (R2)+
253 011670 112722 000002 MOVB #RMWC, (R2)+
254 011674 112722 000000 MOVB #RMCS1, (R2)+
255 011700 112722 000200 MOVB #200, (R2)+ ;TERMINATE TABLE
256
257 011704 004737 043330 JSR PC,PUT ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
011710 000404 BR 11$ ;GO TO 11$ IF NO ERROR
011712 000240 NOP ;RETURN HERE IF ERROR
011714 104000 EMT ;ERROR # DEFINED BY PUT SUBROUTINE
011716 000137 012252 JMP 24$ ;GO TO 24$ IF ERROR
258 011722 11$:
259
260 ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
011722 004737 042774 JSR PC,GETSTS ;GO TO GETSTS SUBROUTINE
261
262 ;WAIT FOR COMMAND TO COMPLETE
011726 004737 043672 JSR PC,TIMOUT ;GO TO TIMOUT SUBROUTINE
263
264 ;GO GET REGISTER STATUS

```



```

265 011732 004737 043060      JSR    PC.GET          ;GO READ REGISTER(S) WITH GET SUBROUTINE
    011736 000404              BR     12$            ;GO TO 12$ IF NO ERROR
    011740 000240              NOP                    ;RETURN HERE IF ERROR
    011742 104000              EMT                    ;ERROR # DEFINED BY GET SUBROUTINE
    011744 000137 012252      JMP    24$            ;GO TO 24$ IF ERROR
266 011750                      12$:
267
268
269 011750 004737 044056      ;VERIFY RESULTS OF WRITE COMMAND
    011754 000405              JSR    PC.PRIERR      ;GO CHECK FOR PRIMARY FRROPS
    011756 000240              BR     13$            ;GO TO 13$ IF NO ERROR
    011760 104000              NOP                    ;RETURN HERE IF ERROR
    011762 004736              EMT                    ;ERROR # DEFINED BY PRIERR SUBROUTINE
    011764 000137 012252      JSR    PC,@(SP)+      ;GO BACK FOR MORE ERROR CHECKS
    011764 000137 012252      JMP    24$            ;GO TO 24$ IF ERROR
270 011770                      13$:
271 011770 004737 0565/2      JSR    PC.DTASTS      ;GO VERIFY RESULTS OF DATA TRANSFER
    011774 000405              BR     14$            ;GO TO 14$ IF NO ERROR
    011776 000240              NOP                    ;RETURN HERE IF ERROR
    012000 104000              EMT                    ;ERROR # DEFINED BY DTASTS SUBROUTINE
    012002 004736              JSR    PC,@(SP)+      ;GO BACK FOR MORE ERROR CHECKS
    012004 000137 012252      JMP    24$            ;GO TO 24$ IF ERROR
272 012010                      14$:
273 012010 004737 044710      JSR    PC.SECERR      ;GO CHECK FOR SECONDARY ERRORS
    012014 000405              BR     15$            ;GO TO 15$ IF NO ERROR
    012016 000240              NOP                    ;RETURN HERE IF ERROR
    012020 104000              EMT                    ;ERROR # DEFINED BY SECERR SUBROUTINE
    012022 004736              JSR    PC,@(SP)+      ;GO BACK FOR MORE ERROR CHECKS
    012024 000137 012252      JMP    24$            ;GO TO 24$ IF ERROR
274 012030                      15$:
275
276
277 012030 012737 012040 001124 ;CHANGE LOOP ADDRESSES
    012036 000410              MOV    #16$,$LPERR
    012036 000410              BR     17$
                                ;SKIP TO NEXT OPERATION
279
280
281
282
283 012040                      ;*****
284
285
286 012040 004737 037316      ;PREPARE DEVICE FOR TEST
    012044 154130              JSR    PC.TSTPRP      ;PREPARE DEVICE FOR TEST
                                ;TASK DESCRIPTOR AS FOLLOWS:
                                ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
                                ;CLEAR CONTROLLER & SELECT DEVICE
                                ;VERIFY CONTROLLER CLEAR OPERATION
                                ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
                                ;VERIFY PACK ACKNOWLEDGE
                                ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
                                ;VERIFY RECALIBRATION
    012046 000404              BR     17$            ;GO TO 17$ IF NO ERROR
    012050 000240              NOP                    ;RETURN HERE IF ERROR
    012052 104000              EMT                    ;ERROR # DEFINED BY TSTPRP SUBROUTINE
    012054 000137 012252      JMP    24$            ;GO TO 24$ IF ERROR
287 012060                      17$:
288
289
290 012060                      ;SETUP PARAMETERS AND EXECUTE COMMAND
    012060                      18$:
    
```

```
291 012060 012737 000051 001412      MOV      #WCD!GO,RMCS10      ;WRITE CHECK DATA DATA COMMAND
292 012066 012702 001553              MOV      #PUTJNX,R2        ;LOAD PUT REGISTER INDEX TABLE
293 012072 112722 000006              MOVVB   #RMDA,(R2)+
294 012076 112722 000032              MOVVB   #RMOF,(R2)+
295 012102 112722 000034              MOVVB   #RMDC,(R2)+
296 012106 112722 000004              MOVVB   #RMEBA,(R2)+
297 012112 112722 000002              MOVVB   #RMWC,(R2)+
298 012116 112722 000000              MOVVB   #RMCS1,(R2)+
299 012122 112712 000200              MOVVB   #200,(R2)
300
301 012126 004737 043330              JSR     PC,PUT              ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      012132 000404              BR      19$                ;GO TO 19$ IF NO ERROR
      012134 000240              NOP
      012136 104000              EMT
      012140 000137 012252              JMP     24$                ;ERROR # DEFINED BY PUT SUBROUTINE
      ;GO TO 24$ IF ERROR
302 012144              19$:
303
304              ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
      012144 004737 042774              JSR     PC,GETSTS          ;GO TO GETSTS SUBROUTINE
305
306              ;WAIT FOR COMMAND TO COMPLETE
      012150 004737 043672              JSR     PC,TIMOUT         ;GO TO TIMOUT SUBROUTINE
307
308              ;GO GET REGISTER STATUS
309 012154 004737 043060              JSR     PC,GET              ;GO READ REGISTER(S) WITH GET SUBROUTINE
      012160 000404              BR      20$                ;GO TO 20$ IF NO ERROR
      012162 000240              NOP
      012164 104000              EMT
      012166 000137 012252              JMP     24$                ;ERROR # DEFINED BY GET SUBROUTINE
      ;GO TO 24$ IF ERROR
310 012172              20$:
311
312              ;VERIFY RESULTS OF WRITE CHECK COMMAND
313 012172 004737 044056              JSR     PC,PRIERR          ;GO CHECK FOR PRIMARY ERRORS
      012176 000405              BR      21$                ;GO TO 21$ IF NO ERROR
      012200 000240              NOP
      012202 104000              EMT
      012204 004736              JSR     PC,@(SP)+          ;GO BACK FOR MORE ERROR CHECKS
      012206 000137 012252              JMP     24$                ;GO TO 24$ IF ERROR
314 012212              21$:
315 012212 004737 056572              JSR     PC,DTASTS          ;GO VERIFY RESULTS OF DATA TRANSFER
      012216 000405              BR      22$                ;GO TO 22$ IF NO ERROR
      012220 000240              NOP
      012222 104000              EMT
      012224 004736              JSR     PC,@(SP)+          ;GO BACK FOR MORE ERROR CHECKS
      012226 000137 012252              JMP     24$                ;GO TO 24$ IF ERROR
316 012232              22$:
317 012232 004737 044710              JSR     PC,SECERR          ;GO CHECK FOR SECONDARY ERRORS
      012236 000405              BR      23$                ;GO TO 23$ IF NO ERROR
      012240 000240              NOP
      012242 104000              EMT
      012244 004736              JSR     PC,@(SP)+          ;GO BACK FOR MORE ERROR CHECKS
      012246 000137 012252              JMP     24$                ;GO TO 24$ IF ERROR
318 012252              23$:
319
320 012252              24$:
321
322              ;*****
```

```

; *TEST 4 WRITE, WRITE CHECK ZEROS W/ WCE ERROR
;*****
;ST4:
012252 000004 SCOPE ;SCOPE CALL
012252 000240 NOP ;START OF TEST
012254 000240 MOV #STACK,SP ;INITIALIZE STACK POINTER
012256 012706 001100 MOV $BASE,R0 ;R0 = UNIBUS ADDRESS
012262 013700 001276 MOV TSTQUE,R1 ;(R1) = DEVICE BEING TESTED
012266 013701 001466 MOV #4,$TESTN ;;SET TEST NUMBER IN APT MAIL BOX
012272 012737 000004 001226

323
324
325
326
327 012300
328
329
330 012300 004737 037316 ;PREPARE DEVICE FOR TEST
012304 154130 JSR PC,TSTPRP ;PREPARE DEVICE FOR TEST
;TASK DESCRIPTOR AS FOLLOWS:
;SELECT DEVICE & VERIFY DEVICE AVAILABLE
;CLEAR CONTROLLER & SELECT DEVICE
;VERIFY CONTROLLER CLEAR OPERATION
;PACK ACKNOWLEDGE IF VOLUME NOT VALID
;VERIFY PACK ACKNOWLEDGE
;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
;VERIFY RECALIBRATION
;GO TO 2$ IF NO ERROR
;RETURN HERE IF ERROR
;ERROR # DEFINED BY TSTPRP SUBROUTINE
;GO TO 29$ IF ERROR

012306 000404 BR 2$
012310 000240 NOP
012312 104000 EMT
012314 000137 013446 JMP 29$

331
332 ;LOAD PARAMETERS AND GENERATE DATA BUFFER
333 012320 2$:
334 012320 012737 000000 001446 MOV #0,RMDCO ;CYLINDER = 0
335 012326 012737 000000 001420 MOV #0,RMDAO ;TRACK = 0, SECTOR 0
336 012334 012737 106436 001416 MOV #BUFONE,RMBAO ;BUS ADDRESS
337 012342 012737 177376 001414 MOV #-258,RMWCO ;2 + 256. WORDS (2'S COMP)
338 012350 012737 010000 001444 MOV #FMT16,RMOFO ;16 BIT FORMAT
339 012356 012737 000063 001412 MOV #WH!GO,RMCS10 ;WRITE HEADER AND DATA COMMAND

340
341 ;VERIFY THAT SECTOR IS NOT BAD
012364 004737 040242 JSR PC,BADSCT ;CALL BAD SECTOR MODULE
012370 000405 BR 3$ ;GO TO 3$ IF NO ERROR
012372 104401 070426 TYPE ,SCTMSG ;TYPE BAD SECTOR MESSAGE
012376 104000 EMT ;ERROR # DEFINED BY BADSCT SUBROUTINE
012400 000137 013446 JMP 29$ ;GO TO 29$ IF ERROR

342 012404 3$:
343 012404 012737 072060 001174 MOV #ZEROS,$TMP0 ;STARTING ADDRESS OF PATTERN
344 012412 012737 000001 001176 MOV #1,$TMP1 ;RANGE OF PATTERN
345 012420 004737 042174 JSR PC,GENBUF ;GO GENERATE BUFFER FOR FORMAT

346
347 012424 012702 001553 MOV #PUTINX,R2 ;R2 - BYTE ENTRY POSITION
348 012430 112722 000034 MOVB #RMDC,(R2)+
349 012434 112722 000006 MOVB #RMDA,(R2)+
350 012440 112722 000004 MOVB #RMBA,(R2)+
351 012444 112722 000002 MOVB #RMWC,(R2)+
352 012450 112722 000032 MOVB #RMOF,(R2)+
353 012454 112722 000000 MOVB #RMCS1,(R2)+
  
```

```

354 012460 112712 000200          MOVB    #200,(R2)          ;TERMINATE TABLE
355 012464                                4$:
355 012464 004737 043330          JSR     PC,PUT          ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
                                BR      5$              ;GO TO 5$ IF NO ERROR
                                NOP                    ;RETURN HERE IF ERROR
                                EMT                    ;ERROR # DEFINED BY PUT SUBROUTINE
                                JMP     29$            ;GO TO 29$ IF ERROR
357 012502                                5$:
358
359                                ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
                                JSR     PC,GETSTS       ;GO TO GETSTS SUBROUTINE
360
361                                ;WAIT FOR COMMAND TO COMPLETE
                                JSR     PC,TIMOUT      ;GO TO TIMEOUT SUBROUTINE
362
363                                ;GO EGT REGISTER STATUS
364 012512 004737 043060          JSR     PC,GET          ;GO READ REGISTER(S) WITH GET SUBROUTINE
                                BR      6$              ;GO TO 6$ IF NO ERROR
                                NOP                    ;RETURN HERE IF ERROR
                                EMT                    ;ERROR # DEFINED BY GET SUBROUTINE
                                JMP     29$            ;GO TO 29$ IF ERROR
365 012530                                6$:
366
367                                ;VERIFY RESULTS OF WRITE COMMAND
368 012530 004737 056572          JSR     PC,DTASTS      ;GO VERIFY RESULTS OF DATA TRANSFER
                                BR      7$              ;GO TO 7$ IF NO ERROR
                                NOP                    ;RETURN HERE IF ERROR
                                EMT                    ;ERROR # DEFINED BY DTASTS SUBROUTINE
                                JSR     PC,@(SP)+      ;GO BACK FOR MORE ERROR CHECKS
                                JMP     29$            ;GO TO 29$ IF ERROR
369 012550                                7$:
370
371                                ;MOVE LOOP ADDRESSES TO NEXT OPERATION
372 012550 012737 012560 001124  MOV     #8$,$LPERR
373 012556 000410          BR      9$              ;SKIP TO WRITE OPERATION
374
375                                ;*****
376                                ;LOOP #2      WRITE,WRITE CHECK DATA
377
378 012560                                8$:
379
380                                ;PREPARE DEVICE FOR TEST
381 012560 004737 037316          JSR     PC,TSTPRP     ;PREPARE DEVICE FOR TEST
                                .WORD   154130        ;TASK DESCRIPTOR AS FOLLOWS:
                                                    ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
                                                    ;CLEAR CONTROLLER & SELECT DEVICE
                                                    ;VERIFY CONTROLLER CLEAR OPERATION
                                                    ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
                                                    ;VERIFY PACK ACKNOWLEDGE
                                                    ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
                                                    ;VERIFY RECALIBRATION
                                BR      9$              ;GO TO 9$ IF NO ERROR
                                NOP                    ;RETURN HERE IF ERROR
                                EMT                    ;ERROR # DEFINED BY TSTPRP SUBROUTINE
                                JMP     29$            ;GO TO 29$ IF ERROR
                                012566 000404          BR      9$
                                012570 000240          NOP
                                012572 104000          EMT
                                012574 000137 013446  JMP     29$
382 012600                                9$:
383

```

```

384 ; SETUP PARAMETERS AND EXECUTE COMMAND
385 012600 10$:
386 012600 012737 177400 001414 MOV #-256, RMWCO ; CHANGE WORD COUNT
387 012606 012737 106442 001416 MOV #BUFONE+4, RMBAO ; CHANGE MEMORY ADDRESS
388 012614 012737 000061 001412 MOV #WD!GO, RMCS10 ; WRITE DATA COMMAND
389 012622 012702 001553 MOV #PUTINX, R2 ; LOAD PUT REGISTER INDEX TABLE
390 012626 112722 000006 MOVB #RMDA, (R2)+
391 012632 112722 000034 MOVB #RMDC, (R2)+
392 012636 112722 000032 MOVB #RMOF, (R2)+
393 012642 112722 000004 MOVB #RMBB, (R2)+
394 012646 112722 000002 MOVB #RMWC, (R2)+
395 012652 112722 000000 MOVB #RMCS1, (R2)+
396 012656 112722 000200 MOVB #200, (R2)+ ; TERMINATE TABLE
397
398 012662 004737 043330 JSR PC, PUT ; GO WRITE REGISTER(S) WITH PUT SUBROUTINE
012666 000404 BR 11$ ; GO TO 11$ IF NO ERROR
012670 000240 NOP ; RETURN HERE IF ERROR
012672 104000 EMT ; ERROR # DEFINED BY PUT SUBROUTINE
012674 000137 013446 JMP 29$ ; GO TO 29$ IF ERROR
399 012700 11$:
400
401 ; SETUP GET INDEX TABLE TO READ ALL REGISTERS
012700 004737 042774 JSR PC, GETSTS ; GO TO GETSTS SUBROUTINE
402
403 ; WAIT FOR COMMAND TO COMPLETE
012704 004737 043672 JSR PC, TIMEOUT ; GO TO TIMEOUT SUBROUTINE
404
405 ; GO READ STATUS FOR WRITE COMMAND
406 012710 004737 043060 JSR PC, GET ; GO READ REGISTER(S) WITH GET SUBROUTINE
012714 000404 BR 12$ ; GO TO 12$ IF NO ERROR
012716 000240 NOP ; RETURN HERE IF ERROR
012720 104000 EMT ; ERROR # DEFINED BY GET SUBROUTINE
012722 000137 013446 JMP 29$ ; GO TO 29$ IF ERROR
407 012726 12$:
408
409 ; CHECK FOR ERRORS DURING WRITE OPERATION
410 012726 004737 044056 JSR PC, PRIERR ; GO CHECK FOR PRIMARY ERRORS
012732 000405 BR 13$ ; GO TO 13$ IF NO ERROR
012734 000240 NOP ; RETURN HERE IF ERROR
012736 104000 EMT ; ERROR # DEFINED BY PRIERR SUBROUTINE
012740 004736 JSR PC, @ (SP)+ ; GO BACK FOR MORE ERROR CHECKS
012742 000137 013446 JMP 29$ ; GO TO 29$ IF ERROR
411 012746 13$:
412 012746 004737 056572 JSR PC, DTASTS ; GO VERIFY RESULTS OF DATA TRANSFER
012752 000405 BR 14$ ; GO TO 14$ IF NO ERROR
012754 000240 NOP ; RETURN HERE IF ERROR
012756 104000 EMT ; ERROR # DEFINED BY DTASTS SUBROUTINE
012760 004736 JSR PC, @ (SP)+ ; GO BACK FOR MORE ERROR CHECKS
012762 000137 013446 JMP 29$ ; GO TO 29$ IF ERROR
413 012766 14$:
414 012766 004737 044710 JSR PC, SECERR ; GO CHECK FOR SECONDARY ERRORS
012772 000405 BR 15$ ; GO TO 15$ IF NO ERROR
012774 000240 NOP ; RETURN HERE IF ERROR
012776 104000 EMT ; ERROR # DEFINED BY SECERR SUBROUTINE
013000 004736 JSR PC, @ (SP)+ ; GO BACK FOR MORE ERROR CHECKS
013002 000137 013446 JMP 29$ ; GO TO 29$ IF ERROR
415 013006 15$:

```

```

416
417
418 013006 012737 013014 001124 ;CHANGE LOOP ADDRESSES
      MOV      #16$, $LPERR
419
420 ;*****
421 ;LOOP #3      WRITE CHECK DATA
422
423 013014      16$:
424
425 013014 012703 000001      MOV      #1, R3      ;R3+WCE BIT POSITION
426 013020 050337 107440      17$:      BIS      R3, BUFTWO-2      ;CHANGE LAST WORD OF BUFFER
427
428 ;PREPARE DEVICE FOR TEST
429 013024 004737 037316      JSR      PC, TSTPRP      ;PREPARE DEVICE FOR TEST
      .WORD 154130      ;TASK DESCRIPTOR AS FOLLOWS:
      ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
      ;CLEAR CONTROLLER & SELECT DEVICE
      ;VERIFY CONTROLLER CLEAR OPERATION
      ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
      ;VERIFY PACK ACKNOWLEDGE
      ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
      ;VERIFY RECALIBRATION
      ;GO TO 18$ IF NO ERROR
      ;RETURN HERE IF ERROR
      ;ERROR # DEFINED BY TSTPRP SUBROUTINE
      ;GO TO 29$ IF ERROR
      013032 000404      BR      18$
      013034 000240      NOP
      013036 104000      EMT
      013040 000137 013446      JMP      29$
430 013044      18$:
431
432 ;READ DATA FROM DEVICE
433 013044      19$:
434 013044 012737 000051 001412      MOV      #WCD!GO, RMCS10      ;WRITE CHECK DATA DATA COMMAND
435 013052 012702 001553      MOV      #PUTINX, R2      ;LOAD PUT REGISTER INDEX TABLE
436 013056 112722 000006      MOVB    #RMDA, (R2)+
437 013062 112722 000032      MOVB    #RMOF, (R2)+
438 013066 112722 000034      MOVB    #RMDC, (R2)+
439 013072 112722 000004      MOVB    #RMBA, (R2)+
440 013076 112722 000002      MOVB    #RMWC, (R2)+
441 013102 112722 000000      MOVB    #RMCS1, (R2)+
442 013106 112712 000200      MOVB    #200, (R2)
443
444 013112 004737 043330      JSR      PC, PUT      ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      013116 000404      BR      20$      ;GO TO 20$ IF NO ERROR
      013120 000240      NOP      ;RETURN HERE IF ERROR
      013122 104000      EMT      ;ERROR # DEFINED BY PUT SUBROUTINE
      013124 000137 013446      JMP      29$      ;GO TO 29$ IF ERROR
445 013130      20$:
446
447 ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
      JSR      PC, GETSTS      ;GO TO GETSTS SUBROUTINE
448
449 ;WAIT FOR COMMAND TO COMPLETE
      JSR      PC, TIMEOUT      ;GO TO TIMEOUT SUBROUTINE
450
451 ;GO READ STATUS FOR WRITE CHECK DATA OPERATION
452 013140 004737 043060      JSR      PC, GET      ;GO READ REGISTER(S) WITH GET SUBROUTINE
      013144 000404      BR      21$      ;GO TO 21$ IF NO ERROR
      013146 000240      NOP      ;RETURN HERE IF ERROR
  
```

```

013150 104000 EMT ;ERROR # DEFINED BY GET SUBROUTINE
013152 000137 013446 JMP 29$ ;GO TO 29$ IF ERROR
453 013156 21$:
454
455 ;CHECK FOR ERRORS DURING WRITE CHECK DATA OPERATION
456 013156 004737 044056 JSR PC,PRIERR ;GO CHECK FOR PRIMARY ERRORS
013162 000405 BR 22$ ;GO TO 22$ IF NO ERROR
013164 000240 NOP ;RETURN HERE IF ERROR
013166 104000 EMT ;ERROR # DEFINED BY PRIERR SUBROUTINE
013170 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
013172 000137 013446 JMP 29$ ;GO TO 29$ IF ERROR
457 013176 22$:
458 013176 032737 040000 001346 BIT #WCE,RMCS2I ;WAS 'WCE' DETECTED??
459 013204 001030 BNE 24$ ;YES!!
460
461 013206 004737 056572 JSR PC,DTASTS ;GO VERIFY RESULTS OF DATA TRANSFER
013212 000405 BR 23$ ;GO TO 23$ IF NO ERROR
013214 000240 NOP ;RETURN HERE IF ERROR
013216 104000 EMT ;ERROR # DEFINED BY DTASTS SUBROUTINE
013220 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
013222 000137 013446 JMP 29$ ;GO TO 29$ IF ERROR
462 013226 23$:
463 013226 013737 001346 001140 MOV RMCS2I,$GDDAT ;EXPECTED STATUS
464 013234 052737 040000 001140 BIS #WCE,$GDDAT
465 013242 013737 001346 001142 MOV RMCS2I,$BDDAT ;RECEIVED STATUS
466 013250 010337 001174 MOV R3,$TMP0 ;FAILING BIT POSITION
467 013254 012737 107440 001176 MOV #BUFTWO-2,$IMP1 ;FAILING ADDRESS
468 013262 104337 EMT 337
469 013264 000470 BR 29$
470 013266 24$:
471 013266 112737 000022 001524 MOVB #RMDB,GETINX ;SETUP GET INDEX TABLE
013274 112737 000200 001525 MOVB #200,GETINX+1 ;SETUP TERMINATOR BYTE
013302 004737 043060 JSR PC,GET ;GO READ RMDB VIA GET SUBROUTINE
013306 000404 BR 25$ ;GO TO 25$ IF NO ERROR
013310 000240 NOP ;RETURN HERE IF ERROR
013312 104000 EMT ;ERROR DEFINED BY GET SUBROUTINE
013314 000137 013446 JMP 29$ ;GO TO 29$ IF ERROR
472 013320 25$:
473 013320 013737 001360 001142 MOV RMDBI,$BDDAT ;RECEIVED DATA
474 013326 013737 107440 001140 MOV BUFTWO-2,$GDDAT ;EXPECTED DATA
475 013334 040337 001140 BIC R3,$GDDAT
476 013340 012737 107440 001134 MOV #BUFTWO-2,$GDADR ;EXPECTED ADDRESS
477 013346 013737 001342 001136 MOV RMBAI,$BDADR ;RECEIVED ADDRESS
478 013354 162737 0000C2 001136 SUB #2,$BDADR ;ADJUST BUS ADDRESS
479 013362 023737 001134 001136 CMP $GDADR,$BDADR ;ADDRESSES OK??
480 013370 001402 BEQ 26$ ;YES.!
481 013372 104340 EMT 340
482 013374 000424 BR 29$
483 013376 023737 001140 001142 26$: CMP $GDDAT,$BDDAT ;DATA OK??
484 013404 001402 BEQ 27$ ;YES.!
485 013406 104341 EMT 341
486 013410 000416 BR 29$
487 013412 27$:
488
489 013412 004737 044710 JSR PC,SECERR ;GO CHECK FOR SECONDARY ERRORS
013416 000405 BR 28$ ;GO TO 28$ IF NO ERROR
013420 000240 NOP ;RETURN HERE IF ERROR

```

```

013422 104000          EMT          ;ERROR # DEFINED BY SECERR SUBROUTINE
013424 004736          JSR          PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
013426 000137 013446    JMP          29$      ;GO TO 29$ IF ERROR
490 013432          28$:
491 013432 040337 107440    BIC          R3,BUFTWO-2 ;RESTORE DATA PATTERN
492 013436 006303          ASL          R3          ;SHIFT TO NEXT BIT
493 013440 001402          BEQ          29$      ;EXIT IF DONE
494 013442 000137 013020    JMP          17$      ;REPEAT TEST FOR NEXT DATA BIT
495 013446          29$:
496
497
;*****
;*TEST 5          WRITE, READ ONES
;*****
TST5:
013446          SCOPE          ;SCOPE CALL
013446 000004          NOP          ;START OF TEST
013450 000240          MOV          #STACK,SP ;INITIALIZE STACK POINTER
013452 012706 001100    MOV          $BASE,R0   ;R0 = UNIBUS ADDRESS
013456 013700 001276    MOV          TSTQUE,R1  ;(R1) = DEVICE BEING TESTED
013462 013701 001466    MOV          #5,$TESTN  ;;SET TEST NUMBER IN APT MAIL BOX
013466 012737 000005 001226

;*****
;LOOP #1          FORMAT,WRITE,READ
;*****
500
501
502 013474          1$:
503
504
505 013474 004737 037316    ;PREPARE THE DEVICE FOR TEST
013500 154130          JSR          PC,TSTPRP ;PREPARE DEVICE FOR TEST
                          .WORD 154130 ;TASK DESCRIPTOR AS FOLLOWS:
                          ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
                          ;CLEAR CONTROLLER & SELECT DEVICE
                          ;VERIFY CONTROLLER CLEAR OPERATION
                          ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
                          ;VERIFY PACK ACKNOWLEDGE
                          ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
                          ;VERIFY RECALIBRATION
                          ;GO TO 2$ IF NO ERROR
                          ;RETURN HERE IF ERROR
                          ;ERROR # DEFINED BY TSTPRP SUBROUTINE
                          ;GO TO 25$ IF ERROR
013502 000404          BR          2$
013504 000240          NOP
013506 104000          EMT
013510 000137 014454    JMP          25$

;LOAD PARAMETERS AND GENERATE DATA BUFFER
2$:
508 013514          MOV          #0,RMDCO   ;CYLINDER = 0
509 013514 012737 000000 001446    MOV          #0,RMDAO   ;TRACK = 0, SECTOR 0
510 013522 012737 000000 001420    MOV          #BUFONE,RMBAO ;BUS ADDRESS
511 013530 012737 106436 001416    MOV          #-258.,RMWCO ;2 + 256. WORDS (2'S COMP)
512 013536 012737 177376 001414    MOV          #FMT16,RMOFO ;16 BIT FORMAT
513 013544 012737 010000 001444    MOV          #WH!GO,RMCS10 ;WRITE HEADER AND DATA COMMAND
514 013552 012737 000063 001412
515
516
;VERIFY THAT SECTOR IS NOT BAD
013560 004737 040242    JSR          PC,BADSCT ;CALL BAD SECTOR MODULE
013564 000405          BR          3$      ;GO TO 3$ IF NO ERROR
013566 104401 070426    TYPE          ,SCTMSG  ;TYPE BAD SECTOR MESSAGE
013572 104000          EMT
013574 000137 014454    JMP          25$      ;ERROR # DEFINED BY BADSCT SUBROUTINE
                          ;GO TO 25$ IF ERROR
517 013600          3$:
    
```



```

518 013600 012737 072016 001174      MOV    #ONES,$TMP0      ;STARTING ADDRESS OF PATTERN
519 013606 012737 000001 001176      MOV    #1,$TMP1        ;RANGE OF PATTERN
520 013614 004737 042174      JSR    PC,GENBUF       ;GO GENERATE BUFFER FOR FORMAT
521
522      ;LOAD PUT REGISTER INDEX TABLE FOR FORMAT OPERATION
523 013620 012702 001553      MOV    #PUTINX,R2      ;R2 = BYTE ENTRY POSITION
524 013624 112722 000034      MOVB  #RMDC,(R2)+
525 013630 112722 000006      MOVB  #RMDA,(R2)+
526 013634 112722 000004      MOVB  #RMBB,(R2)+
527 013640 112722 000002      MOVB  #RMWC,(R2)+
528 013644 112722 000032      MOVB  #RMOF,(R2)+
529 013650 112722 000000      MOVB  #RMCS1,(R2)+
530 013654 112712 000200      MOVB  #200,(R2)       ;TERMINATE TABLE
531 013660
532
533      ;FORMAT THE DRIVE
534 013660 004737 043330      JSR    PC,PUT         ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      013664 000404      BR     5$             ;GO TO 5$ IF NO ERROR
      013666 000240      NOP                    ;RETURN HERE IF ERROR
      013670 104000      EMT                    ;ERROR # DEFINED BY PUT SUBROUTINE
      013672 000137 014454      JMP    25$            ;GO TO 25$ IF ERROR
535 013676
536
537      ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
      013676 004737 042774      JSR    PC,GETSTS      ;GO TO GETSTS SUBROUTINE
538
539      ;WAIT FOR COMMAND TO COMPLETE
      013702 004737 043672      JSR    PC,TIMOUT      ;GO TO TIMOUT SUBROUTINE
540
541      ;GO READ STATUS FOR FORMAT OPERATION
542 013706 004737 043060      JSR    PC,GET         ;GO READ REGISTER(S) WITH GET SUBROUTINE
      013712 000404      BR     6$             ;GO TO 6$ IF NO ERROR
      013714 000240      NOP                    ;RETURN HERE IF ERROR
      013716 104000      EMT                    ;ERROR # DEFINED BY GET SUBROUTINE
      013720 000137 014454      JMP    25$            ;GO TO 25$ IF ERROR
543 013724
544
545      ;VERIFY NO ERRORS DURING FORMAT
546 013724 004737 056572      JSR    PC,DTASTS      ;GO VERIFY RESULTS OF DATA TRANSFER
      013730 000405      BR     7$             ;GO TO 7$ IF NO ERROR
      013732 000240      NOP                    ;RETURN HERE IF ERROR
      013734 104000      EMT                    ;ERROR # DEFINED BY DTASTS SUBROUTINE
      013736 004736      JSR    PC,@(SP)+      ;GO BACK FOR MORE ERROR CHECKS
      013740 000137 014454      JMP    25$            ;GO TO 25$ IF ERROR
547 013744
548
549      ;MOVE LOOP ADDRESSES TO NEXT OPERATION
550 013744 012737 013754 001124      MOV    #8$,$LPERR
551 013752 000410      BR     9$             ;SKIP TO WRITE OPERATION
552
553      ;*****
554      ;LOOP #2      WRITE,READ
555
556 013754
557
558
559      ;PREPARE DEVICE FOR TEST
  
```

```

560 013754 004737 037316      JSR    PC,TSTPRP      ;PREPARE DEVICE FOR TEST
      013760 154130          .WORD   154130      ;TASK DESCRIPTOR AS FOLLOWS:
                                           ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
                                           ;CLEAR CONTROLLER & SELECT DEVICE
                                           ;VERIFY CONTROLLER CLEAR OPERATION
                                           ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
                                           ;VERIFY PACK ACKNOWLEDGE
                                           ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
                                           ;VERIFY RECALIBRATION
                                           ;GO TO 9$ IF NO ERROR
                                           ;RETURN HERE IF ERROR
                                           ;ERROR # DEFINED BY TSTPRP SUBROUTINE
                                           ;GO TO 25$ IF ERROR

      013762 000404          BR      9$
      013764 000240          NOP
      013766 104000          EMT
      013770 000137 014454    JMP     25$
561 013774          9$:
562
563          ;WRITE DATA TO THE DRIVE
564 013774          10$:
565 013774 012737 106442 001416    MOV     #BUFONE+4,RMBA0      ;CHANGE MEMORY ADDRESS
566 014002 012737 177400 001414    MOV     #-256.,RMWCO        ;CHANGE WORD COUNT
567 014010 012737 000061 001412    MOV     #WD!GO,RMCS10      ;WRITE DATA COMMAND
568 014016 012702 001553          MOV     #PUTINX,R2         ;LOAD PUT REGISTER INDEX TABLE
569 014022 112722 000006          MOVB   #RMDA,(R2)+
570 014026 112722 000034          MOVB   #RMDC,(R2)+
571 014032 112722 000032          MOVB   #RMOF,(R2)+
572 014036 112722 000004          MOVB   #RMEA,(R2)+
573 014042 112722 000002          MOVB   #RMWC,(R2)+
574 014046 112722 000000          MOVB   #RMCS1,(R2)+
575 014052 112722 000200          MOVB   #200,(R2)+        ;TERMINATE TABLE
576
577 014056 004737 043330      JSR    PC,PUT           ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      014062 000404          BR      11$
      014064 000240          NOP
      014066 104000          EMT
      014070 000137 014454    JMP     25$
      11$:
578 014074          ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
579
580          JSR    PC,GETSTS      ;GO TO GETSTS SUBROUTINE
581 014074 004737 042774
582          ;WAIT FOR COMMAND TO COMPLETE
583          JSR    PC,TIMOUT      ;GO TO TIMOUT SUBROUTINE
584
585          ;GO READ STATUS FOR WRITE COMMAND
586 014104 004737 043060      JSR    PC,GET           ;GO READ REGISTER(S) WITH GET SUBROUTINE
      014110 000404          BR      12$
      014112 000240          NOP
      014114 104000          EMT
      014116 000137 014454    JMP     25$
      12$:
587
588          ;CHECK FOR ERRORS DURING WRITE OPERATION
589 014122 004737 044056      JSR    PC,PRIERR        ;GO CHECK FOR PRIMARY ERRORS
      014126 000405          BR      13$
      014130 000240          NOP
      014132 104000          EMT
      014134 004736          JSR    PC,@(SP)+        ;GO BACK FOR MORE ERROR CHECKS
      014136 000137 014454    JMP     25$
  
```

```

590 014142          13$:
591 014142 004737 056572      JSR    PC,DTASTS      ;GO VERIFY RESULTS OF DATA TRANSFER
    014146 000405          BR     14$           ;GO TO 14$ IF NO ERROR
    014150 000240          NOP                    ;RETURN HERE IF ERROR
    014152 104000          EMT                    ;ERROR # DEFINED BY DTASTS SUBROUTINE
    014154 004736          JSR    PC,@(SP)+      ;GO BACK FOR MORE ERROR CHECKS
    014156 000137 014454      JMP     25$           ;GO TO 25$ IF ERROR

592 014162          14$:
593 014162 004737 044710      JSR    PC,SECERR     ;GO CHECK FOR SECONDARY ERRORS
    014166 000405          BR     15$           ;GO TO 15$ IF NO ERROR
    014170 000240          NOP                    ;RETURN HERE IF ERROR
    014172 104000          EMT                    ;ERROR # DEFINED BY SECERR SUBROUTINE
    014174 004736          JSR    PC,@(SP)+      ;GO BACK FOR MORE ERROR CHECKS
    014176 000137 014454      JMP     25$           ;GO TO 25$ IF ERROR

594 014202          15$:
595
596
597 014202 012737 014212 001124 ;CHANGE LOOP ADDRESSES
598 014210 000410          MOV     #16$,$LPERR
    .          BR     17$           ;SKIP TO NEXT OPERATION

599
600
601
602
603 014212          ;:*****
604
605
606 014212 004737 037316      ;:LOOP #3      READ
    014216 154130          ;PREPARE DEVICE FOR TEST
    .          JSR    PC,TSTPRP      ;PREPARE DEVICE FOR TEST
    .          .WORD 154130         ;TASK DESCRIPTOR AS FOLLOWS:
    .                                     ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
    .                                     ;CLEAR CONTROLLER & SELECT DEVICE
    .                                     ;VERIFY CONTROLLER CLEAR OPERATION
    .                                     ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
    .                                     ;VERIFY PACK ACKNOWLEDGE
    .                                     ;RECALIBRATE IF 'SKI' OR 'PIP' IS SFT
    .                                     ;VERIFY RECALIBRATION
    .                                     ;GO TO 17$ IF NO ERROR
    .                                     ;RETURN HERE IF ERROR
    .                                     ;ERROR # DEFINED BY TSTPRP SUBROUTINE
    .                                     ;GO TO 25$ IF ERROR

    014220 000404          BR     17$
    014222 000240          NOP
    014224 104000          EMT
    014226 000137 014454      JMP     25$

607 014232          17$:
608
609
610 014232          ;READ DATA FROM DEVICE
611 014232 012737 107446 001416 ;18$:
612 014240 012737 000071 001412      MOV     #BUFTWO+4,RMBA0      ;CHANGE MEMORY ADDRESS
613 014246 012702 001553          MOV     #RD!GO,RMCS10      ;READ DATA COMMAND
614 014252 112722 000006          MOV     #PUTINX,R2        ;LOAD PUT REGISTER INDEX TABLE
615 014256 112722 000032          MOVB   #RMDA,(R2)+
616 014262 112722 000034          MOVB   #RMOF,(R2)+
617 014266 112722 000004          MOVB   #RMDC,(R2)+
618 014272 112722 000002          MOVB   #RMBA,(R2)+
619 014276 112722 000000          MOVB   #RMWC,(R2)+
620 014302 112712 000200          MOVB   #RMCS1,(R2)+
621
622 014306 004737 043330      JSR    PC,PUT        ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
    014312 000404          BR     19$           ;GO TO 19$ IF NO ERROR
    014314 000240          NOP                    ;RETURN HERE IF ERROR
    
```

```

014316 104000 EMT ;ERROR # DEFINED BY PUT SUBROUTINE
014320 000137 014454 JMP 25$ ;GO TO 25$ IF ERROR
623 014324 19$:
624
625 ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
014324 004737 042774 JSR PC,GETSTS ;GO TO GETSTS SUBROUTINE
626
627 ;WAIT FOR COMMAND TO COMPLETE
014330 004737 043672 JSR PC,TIMOUT ;GO TO TIMEOUT SUBROUTINE
628
629 ;GO READ STATUS FOR READ OPERATION
630 014334 004737 043060 JSR PC,GET ;GO READ REGISTER(S) WITH GET SUBROUTINE
014340 000404 BR 20$ ;GO TO 20$ IF NO ERROR
014342 000240 NOP ;RETURN HERE IF ERROR
014344 104000 EMT ;ERROR # DEFINED BY GET SUBROUTINE
014346 000137 014454 JMP 25$ ;GO TO 25$ IF ERROR
631 014352 20$:
632
633 ;CHECK FOR ERRORS DURING READ OPERATION
634 014352 004737 044056 JSR PC,PRIERR ;GO CHECK FOR PRIMARY ERRORS
014356 000405 BR 21$ ;GO TO 21$ IF NO ERROR
014360 000240 NOP ;RETURN HERE IF ERROR
014362 104000 EMT ;ERROR # DEFINED BY PRIERR SUBROUTINE
014364 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
014366 000137 014454 JMP 25$ ;GO TO 25$ IF ERROR
635 014372 21$:
636 014372 004737 056572 JSR PC,DTASTS ;GO VERIFY RESULTS OF DATA TRANSFER
014376 000405 BR 22$ ;GO TO 22$ IF NO ERROR
014400 000240 NOP ;RETURN HERE IF ERROR
014402 104000 EMT ;ERROR # DEFINED BY DTASTS SUBROUTINE
014404 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
014406 000137 014454 JMP 25$ ;GO TO 25$ IF ERROR
637 014412 22$:
638 014412 004737 044710 JSR PC,SECERR ;GO CHECK FOR SECONDARY ERRORS
014416 000405 BR 23$ ;GO TO 23$ IF NO ERROR
014420 000240 NOP ;RETURN HERE IF ERROR
014422 104000 EMT ;ERROR # DEFINED BY SECERR SUBROUTINE
014424 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
014426 000137 014454 JMP 25$ ;GO TO 25$ IF ERROR
639 014432 23$:
640 014432 004737 042432 JSR PC,CMPBUF ;GO COMPARE WRITE, READ DATA BUFFERS
014436 106442 .WORD BUFONE+4 ;STARTING ADDRESS OF WRITE BUFFER
014440 107446 .WORD BUFTWO+4 ;STARTING ADDRESS OF READ BUFFER
014442 000404 BR 24$ ;GO TO 24$ IF NO ERROR
014444 000240 NOP ;RETURN HERE IF ERROR
014446 104000 EMT ;ERROR # DEFINED BY CMPBUF SUBROUTINE
014450 000137 014454 JMP 25$ ;GO TO 25$ IF ERROR
641 014454 24$:
642
643 014454 25$:
644
645
;*****
;*TEST 6 WRITE, WRITE CHECK ONES
;*****
TST6:
014454 SCOPE ;SCOPE CALL
014454 000004 ;START OF TEST
014456 000240 NOP

```

```

014460 012706 001100      MOV      #STACK,SP      ;INITIALIZE STACK POINTER
014464 013700 001276      MOV      $BASE,R0      ;R0 = UNIBUS ADDRESS
014470 013701 001466      MOV      TSTQUE,R1     ;(R1) = DEVICE BEING TESTED
014474 012737 000006 001226  MOV      #6,$TESTN     ;:SET TEST NUMBER IN APT MAIL BOX

646
647
648
649
650 014502
651
652
653 014502 004737 037316    JSR      PC,TSTPRP     ;PREPARE DEVICE FOR TEST
                                .WORD 154130                    ;TASK DESCRIPTOR AS FOLLOWS:
                                ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
                                ;CLEAR CONTROLLER & SELECT DEVICE
                                ;VERIFY CONTROLLER CLEAR OPERATION
                                ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
                                ;VERIFY PACK ACKNOWLEDGE
                                ;RECALIBRATE IF 'SKI' OR 'PIP' IS SFT
                                ;VERIFY RECALIBRATION
                                ;GO TO 2$ IF NO ERROR
                                ;RETURN HERE IF ERROR
                                ;ERROR # DEFINED BY TSTPRP SUBROUTINE
                                ;GO TO 24$ IF ERROR

                                BR      2$
                                NOP
                                EMT
                                JMP      24$

014510 000404      BR      2$
014512 000240      NOP
014514 104000      EMT
014516 000137 015432    JMP      24$

654
655
656 014522
657 014522 012737 000000 001446    ;LOAD PARAMETERS AND GENERATE DATA BUFFER
658 014530 012737 000000 001420    2$:      MOV      #0,RMDCO      ;CYLINDER = 0
659 014536 012737 106436 001416    MOV      #0,RMDAO      ;TRACK = 0, SECTOR = 0
660 014544 012737 177376 001414    MOV      #BUFONE,RMBAO ;BUS ADDRESS
661 014552 012737 010000 001444    MOV      #-258.,RMWCO  ;2 + 256. WORDS (2'S COMP)
662 014560 012737 000063 001412    MOV      #FMT16,RMOFO  ;16 BIT FORMAT
663
664
665 014566 004737 040242    ;VERIFY THAT SECTOR IS NOT BAD
666 014606 012737 072016 001174    JSR      PC,BADSCT     ;CALL BAD SECTOR MODULE
667 014614 012737 000001 001176    BR      3$             ;GO TO 3$ IF NO ERROR
668 014622 004737 042174    TYPE     ,SCTMSG       ;TYPE BAD SECTOR MESSAGE
669
670
671 014606 012737 072016 001174    EMT
672 014614 012737 000001 001176    JMP      24$          ;ERROR # DEFINED BY BADSCT SUBROUTINE
673
674
675 014606 012737 072016 001174    3$:      MOV      #ONES,$TMP0   ;STARTING ADDRESS OF PATTERN
676 014614 012737 000001 001176    MOV      #1,$TMP1     ;RANGE OF PATTERN
677 014622 004737 042174    JSR      PC,GENBUF    ;GO GENERATE BUFFER FOR FORMAT
678
679
680
681
682
683
684
685
686
687
688
689
690
691
692
693
694
695
696
697
698
699
700
701
702
703
704
705
706
707
708
709
710
711
712
713
714
715
716
717
718
719
720
721
722
723
724
725
726
727
728
729
730
731
732
733
734
735
736
737
738
739
740
741
742
743
744
745
746
747
748
749
750
751
752
753
754
755
756
757
758
759
760
761
762
763
764
765
766
767
768
769
770
771
772
773
774
775
776
777
778
779
780
781
782
783
784
785
786
787
788
789
790
791
792
793
794
795
796
797
798
799
800
801
802
803
804
805
806
807
808
809
810
811
812
813
814
815
816
817
818
819
820
821
822
823
824
825
826
827
828
829
830
831
832
833
834
835
836
837
838
839
840
841
842
843
844
845
846
847
848
849
850
851
852
853
854
855
856
857
858
859
860
861
862
863
864
865
866
867
868
869
870
871
872
873
874
875
876
877
878
879
880
881
882
883
884
885
886
887
888
889
890
891
892
893
894
895
896
897
898
899
900
901
902
903
904
905
906
907
908
909
910
911
912
913
914
915
916
917
918
919
920
921
922
923
924
925
926
927
928
929
930
931
932
933
934
935
936
937
938
939
940
941
942
943
944
945
946
947
948
949
950
951
952
953
954
955
956
957
958
959
960
961
962
963
964
965
966
967
968
969
970
971
972
973
974
975
976
977
978
979
980
981
982
983
984
985
986
987
988
989
990
991
992
993
994
995
996
997
998
999

```

:FORMAT THE DRIVE

```

682 014666 004737 043330      JSR    PC,PUT      ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      014672 000404          BR     5$         ;GO TO 5$ IF NO ERROR
      014674 000240          NOP                    ;RETURN HERE IF ERROR
      014676 104000          EMT                    ;ERROR # DEFINED BY PUT SUBROUTINE
      014700 000137 015432      JMP     24$        ;GO TO 24$ IF ERROR
683 014704          5$:
684
685          ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
      014704 004737 042774      JSR    PC,GFTSTS   ;GO TO GETSTS SUBROUTINE
686
687          ;WAIT FOR COMMAND TO COMPLETE
      014710 004737 043672      JSR    PC,TIMOUT   ;GO TO TIMOUT SUBROUTINE
688
689          ;GO READ STATUS FOR FORMAT OPERATION
690 014714 004737 043060      JSR    PC,GET      ;GO READ REGISTER(S) WITH GET SUBROUTINE
      014720 000404          BR     6$         ;GO TO 6$ IF NO ERROR
      014722 000240          NOP                    ;RETURN HERE IF ERROR
      014724 104000          EMT                    ;ERROR # DEFINED BY GET SUBROUTINE
      014726 000137 015432      JMP     24$        ;GO TO 24$ IF ERROR
691 014732          6$:
692
693          ;VERIFY NO ERRORS DURING FORMAT
694 014732 004737 056572      JSR    PC,DTASTS   ;GO VERIFY RESULTS OF DATA TRANSFER
      014736 000405          BR     7$         ;GO TO 7$ IF NO ERROR
      014740 000240          NOP                    ;RETURN HERE IF ERROR
      014742 104000          EMT                    ;ERROR # DEFINED BY DTASTS SUBROUTINE
      014744 004736          JSR    PC,@(SP)+    ;GO BACK FOR MORE ERROR CHECKS
      014746 000137 015432      JMP     24$        ;GO TO 24$ IF EPROH
695 014752          7$:
696
697          ;MOVE LOOP ADDRESSES TO NEXT OPERATION
698 014752 012737 014762 001124  MOV    #8$,SLPERR
699 014760 000410          BR     9$         ;SKIP TO WRITE OPERATION
700
701          ;*****
702          ;LOOP #2      WRITE,WRITE CHECK DATA
703
704 014762          8$:
705
706          ;PREPARE DEVICE FOR WRITE OPERATION
707
708 014762 004737 037316      JSR    PC,TSTPRP   ;PREPARE DEVICE FOR TEST
      014766 154130          .WORD 154130      ;TASK DESCRIPTOR AS FOLLOWS:
      ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
      ;CLEAR CONTROLLER & SELECT DEVICE
      ;VERIFY CONTROLLER CLEAR OPERATION
      ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
      ;VERIFY PACK ACKNOWLEDGE
      ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
      ;VERIFY RECALIBRATION
      014770 000404          BR     9$         ;GO TO 9$ IF NO ERROR
      014772 000240          NOP                    ;RETURN HERE IF ERROR
      014774 104000          EMT                    ;ERROR # DEFINED BY TSTPRP SUBROUTINE
      014776 000137 015432      JMP     24$        ;GO TO 24$ IF ERROR
709 015002          9$:
710
711          ;WRITE DATA TO THE DRIVE

```

```

712 015002          10$:
713 015002 012737 106442 001416  MOV   #BUFONE+4,RMBA0      ;CHANGE MEMORY ADDRESS
714 015010 012737 177400 001414  MOV   #-256.,RMWCO      ;CHANGE WORD COUNT
715 015016 012737 000061 001412  MOV   #WD!GO,RMCS10    ;WRITE DATA COMMAND
716 015024 012702 001553          MOV   #PUTINX,R2       ;LOAD PUT REGISTER INDEX TABLE
717 015030 112722 000006          MOVB  #RMDA,(R2)+
718 015034 112722 000034          MOVB  #RMDC,(R2)+
719 015040 112722 000032          MOVB  #RMOF,(R2)+
720 015044 112722 000004          MOVB  #RMBA,(R2)+
721 015050 112722 000002          MOVB  #RMWC,(R2)+
722 015054 112722 000000          MOVB  #RMCS1,(R2)+
723 015060 112722 000200          MOVB  #200,(R2)+      ;TERMINATE TABLE
724
725 015064 004737 043330          JSR   PC,PUT           ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      015070 000404          BR    11$            ;GO TO 11$ IF NO ERROR
      015072 000240          NOP                    ;RETURN HERE IF ERROR
      015074 104000          EMT                    ;ERROR # DEFINED BY PUT SUBROUTINE
      015076 000137 015432          JMP   24$            ;GO TO 24$ IF ERROR
726 015102          11$:
727
728          ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
      015102 004737 042774          JSR   PC,GETSTS       ;GO TO GETSTS SUBROUTINE
729
730          ;WAIT FOR COMMAND TO COMPLETE
      015106 004737 043672          JSR   PC,TIMOUT       ;GO TO TIMOUT SUBROUTINE
731
732          ;GO READ STATUS FOR WRITE COMMAND
733 015112 004737 043060          JSR   PC,GET          ;GO READ REGISTER(S) WITH GET SUBROUTINE
      015116 000404          BR    12$            ;GO TO 12$ IF NO ERROR
      015120 000240          NOP                    ;RETURN HERE IF ERROR
      015122 104000          EMT                    ;ERROR # DEFINED BY GET SUBROUTINE
      015124 000137 015432          JMP   24$            ;GO TO 24$ IF ERROR
734 015130          12$:
735
736          ;CHECK FOR ERRORS DURING WRITE OPERATION
737 015130 004737 044056          JSR   PC,PRIERR       ;GO CHECK FOR PRIMARY ERRORS
      015134 000405          BR    13$            ;GO TO 13$ IF NO ERROR
      015136 000240          NOP                    ;RETURN HERE IF ERROR
      015140 104000          EMT                    ;ERROR # DEFINED BY PRIERR SUBROUTINE
      015142 004736          JSR   PC,@(SP)+      ;GO BACK FOR MORE ERROR CHECKS
      015144 000137 015432          JMP   24$            ;GO TO 24$ IF ERROR
738 015150          13$:
739 015150 004737 056572          JSR   PC,DTASTS       ;GO VERIFY RESULTS OF DATA TRANSFER
      015154 000405          BR    14$            ;GO TO 14$ IF NO ERROR
      015156 000240          NOP                    ;RETURN HERE IF ERROR
      015160 104000          EMT                    ;ERROR # DEFINED BY DTASTS SUBROUTINE
      015162 004736          JSR   PC,@(SP)+      ;GO BACK FOR MORE ERROR CHECKS
      015164 000137 015432          JMP   24$            ;GO TO 24$ IF ERROR
740 015170          14$:
741 015170 004737 044710          JSR   PC,SECERR       ;GO CHECK FOR SECONDARY ERRORS
      015174 000405          BR    15$            ;GO TO 15$ IF NO ERROR
      015176 000240          NOP                    ;RETURN HERE IF ERROR
      015200 104000          EMT                    ;ERROR # DEFINED BY SECERR SUBROUTINE
      015202 004736          JSR   PC,@(SP)+      ;GO BACK FOR MORE ERROR CHECKS
      015204 000137 015432          JMP   24$            ;GO TO 24$ IF ERROR
742 015210          15$:
743

```

```

744 ;CHANGE LOOP ADDRESSES
745 015210 012737 015220 001124 MOV #16$, $LPERR
746 015216 000410 BR 17$ ;SKIP TO NEXT OPERATION
747
748 ;*****
749 ;LOOP #3 WRITE CHECK DATA
750
751 015220 16$:
752
753 ;PREPARE DEVICE FOR WRITE CHECK DATA OPERATION
754 015220 004737 037316 JSR PC, TSTPRP ;PREPARE DEVICE FOR TEST
    015224 154130 .WORD 154130 ;TASK DESCRIPTOR AS FOLLOWS:
    ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
    ;CLEAR CONTROLLER & SELECT DEVICE
    ;VERIFY CONTROLLER CLEAR OPERATION
    ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
    ;VERIFY PACK ACKNOWLEDGE
    ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
    ;VERIFY RECALIBRATION
    ;GO TO 17$ IF NO ERROR
    ;RETURN HERE IF ERROR
    ;ERROR # DEFINED BY TSTPRP SUBROUTINE
    ;GO TO 24$ IF ERROR
    BR 17$
    015226 000404 BR 17$
    015230 000240 NOP
    015232 104000 EMT
    015234 000137 015432 JMP 24$
755 015240 17$:
756
757 ;WRITE CHECK DATA DATA FROM DEVICE
758 015240 18$:
759 015240 012737 000051 001412 MOV #WCD!GO, RMCS10 ;WRITE CHECK DATA DATA COMMAND
760 015246 012702 001553 MOV #PUTINX, R2 ;LOAD PUT REGISTER INDEX TABLE
761 015252 112722 000006 MOVB #RMDA, (R2)+
762 015256 112722 000032 MOVB #RMOF, (R2)+
763 015262 112722 000034 MOVB #RMDC, (R2)+
764 015266 112722 000004 MOVB #RMBA, (R2)+
765 015272 112722 000002 MOVB #RMWC, (R2)+
766 015276 112722 000000 MOVB #RMCS1, (R2)+
767 015302 112712 000200 MOVB #200, (R2)
768
769 015306 004737 043330 JSR PC, PUT ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
    015312 000404 BR 19$ ;GO TO 19$ IF NO ERROR
    015314 000240 NOP ;RETURN HERE IF ERROR
    015316 104000 EMT ;ERROR # DEFINED BY PUT SUBROUTINE
    015320 000137 015432 JMP 24$ ;GO TO 24$ IF ERROR
770 015324 19$:
771
772 ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
    015324 004737 042774 JSR PC, GETSTS ;GO TO GETSTS SUBROUTINE
773
774 ;WAIT FOR COMMAND TO COMPLETE
    015330 004737 043672 JSR PC, TIMEOUT ;GO TO TIMEOUT SUBROUTINE
775
776 ;GO READ STATUS FOR WRITE CHECK DATA OPERATION
777 015334 004737 043060 JSR PC, GET ;GO READ REGISTER(S) WITH GET SUBROUTINE
    015340 000404 BR 20$ ;GO TO 20$ IF NO ERROR
    015342 000240 NOP ;RETURN HERE IF ERROR
    015344 104000 EMT ;ERROR # DEFINED BY GET SUBROUTINE
    015346 000137 015432 JMP 24$ ;GO TO 24$ IF ERROR
778 015352 20$:
    
```



```

779
780 ;CHECK FOR ERRORS DURING WRITE CHECK DATA OPERATION
781 015352 004737 044056 JSR PC,PRIERR ;GO CHECK FOR PRIMARY ERRORS
    015356 000405 BR 21$ ;GO TO 21$ IF NO ERROR
    015360 000240 NOP ;RETURN HERE IF ERROR
    015362 104000 EMT ;ERROR # DEFINED BY PRIERR SUBROUTINE
    015364 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
    015366 000137 015432 JMP 24$ ;GO TO 24$ IF ERROR
782 015372 21$: JSR PC,DTASTS ;GO VERIFY RESULTS OF DATA TRANSFER
783 015372 004737 056572 BR 22$ ;GO TO 22$ IF NO ERROR
    015376 000405 NOP ;RETURN HERE IF ERROR
    015400 000240 EMT ;ERROR # DEFINED BY DTASTS SUBROUTINE
    015402 104000 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
    015404 004736 JMP 24$ ;GO TO 24$ IF ERROR
    015406 000137 015432
784 015412 22$: JSR PC,SECERR ;GO CHECK FOR SECONDARY ERRORS
785 015412 004737 044710 BR 23$ ;GO TO 23$ IF NO ERROR
    015416 000405 NOP ;RETURN HERE IF ERROR
    015420 000240 EMT ;ERROR # DEFINED BY SECERR SUBROUTINE
    015422 104000 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
    015424 004736 JMP 24$ ;GO TO 24$ IF ERROR
    015426 000137 015432
786 015432 23$:
787
788 015432 24$:
789
790 ;*****
    ;*TEST 7 WRITE, WRITE CHECK ONES W/ WCE ERROR
    ;*****
    TST7:
    015432 SCOPE ;SCOPE CALL
    015432 000004 NOP ;START OF TEST
    015434 000240 MOV #STACK,SP ;INITIALIZE STACK POINTER
    015436 012706 001100 MOV $BASE,R0 ;R0 = UNIBUS ADDRESS
    015442 013700 001276 MOV TSTQUE,R1 ;(R1) = DEVICE BEING TESTED
    015446 013701 001466 MOV #7,$TESTN ;SET TEST NUMBER IN APT MAIL BOX
    015452 012737 000007 001226
791
792 ;*****
793 ;LOOP #1 FORMAT,WRITE,WRITE CHECK DATA
794
795 015460 1$:
796
797 ;PREPARE THE DEVICE FOR FORMAT OPERATION
798 015460 004737 037316 JSR PC,TSTPRP ;PREPARE DEVICE FOR TEST
    015464 154130 .WORD 154130 ;TASK DESCRIPTOR AS FOLLOWS:
    ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
    ;CLEAR CONTROLLER & SELECT DEVICE
    ;VERIFY CONTROLLER CLEAR OPERATION
    ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
    ;VERIFY PACK ACKNOWLEDGE
    ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
    ;VERIFY RECALIBRATION
    015466 000404 BR 2$ ;GO TO 2$ IF NO ERROR
    015470 000240 NOP ;RETURN HERE IF ERROR
    015472 104000 EMT ;ERROR # DEFINED BY TSTPRP SUBROUTINE
    015474 000137 016630 JMP 29$ ;GO TO 29$ IF ERROR
799 015500 2$:
    
```

```

800
801 ;LOAD PARAMETERS AND GENERATE DATA BUFFER
802 015500 012737 000000 001446 MOV #0,RMDCO ;CYLINDER = 0
803 015506 012737 000000 001420 MOV #0,RMDAO ;TRACK = 0, SECTOR = 0
804 015514 012737 106436 001416 MOV #BUFONE,RMBAD ;BUS ADDRESS
805 015522 012737 177376 001414 MOV #-258,RMWCO ;WORD COUNT = 1 SECTOR
806 015530 012737 010000 001444 MOV #FMT16,RMOFO ;16 BIT FORMAT
807 015536 012737 000063 001412 MOV #WH!GO,RMCS10 ;WRITE HEADER AND DATA COMMAND
808
809 ;VERIFY THAT SECTOR IS NOT BAD
015544 004737 040242 JSR PC,BADSCT ;CALL BAD SECTOR MODULE
015550 000405 BR 3$ ;GO TO 3$ IF NO ERROR
015552 104401 070426 TYPE ,SCTMSG ;TYPE BAD SECTOR MESSAGE
015556 104000 EMT ;ERROR # DEFINED BY BADSCT SUBROUTINE
015560 000137 016630 JMP 29$ ;GO TO 29$ IF ERROR
3$:
810 015564 MOV #ONES,$TMP0 ;STARTING ADDRESS OF PATTERN
811 015564 012737 072016 001174 MOV #1,$TMP1 ;RANGE OF PATTERN
812 015572 012737 000001 001176 JSR PC,GENBUF ;GO GENERATE BUFFER FOR FORMAT
813 015600 004737 042174
814
815 ;LOAD PUT REGISTER INDEX TABLE FOR FORMAT OPERATIION
816 015604 012702 001553 MOV #PUTINX,R2 ;R2 = BYTE ENTRY POSITION
817 015610 112722 000034 MOVB #RMDC,(R2)+
818 015614 112722 000006 MOVB #RMDA,(R2)+
819 015620 112722 000004 MOVB #RMBAD,(R2)+
820 015624 112722 000002 MOVB #RMWC,(R2)+
821 015630 112722 000032 MOVB #RMOF,(R2)+
822 015634 112722 000000 MCVB #RMCS1,(R2)+
823 015640 112712 000200 MOVB #200,(R2) ;TERMINATE TABLE
824 015644
825
826 ;FORMAT THE DRIVE
827 015644 004737 043330 JSR PC,PUT ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
015650 000404 BR 5$ ;GO TO 5$ IF NO ERROR
015652 000240 NOP ;RETURN HERE IF ERROR
015654 104000 EMT ;ERROR # DEFINED BY PUT SUBROUTINE
015656 000137 016630 JMP 29$ ;GO TO 29$ IF ERROR
5$:
828 015662 ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
829 JSR PC,GETSTS ;GO TO GETSTS SUBROUTINE
830
831 ;WAIT FOR COMMAND TO COMPLETE
832 JSR PC,TIMOUT ;GO TO TIMOUT SUBROUTINE
833
834 ;GO READ STATUS FOR FORMAT OPERATION
835 015672 004737 043060 JSR PC,GET ;GO READ REGISTER(S) WITH GET SUBROUTINE
015676 000404 BR 6$ ;GO TO 6$ IF NO ERROR
015700 000240 NOP ;RETURN HERE IF ERROR
015702 104000 EMT ;ERROR # DEFINED BY GET SUBROUTINE
015704 000137 016630 JMP 29$ ;GO TO 29$ IF ERROR
6$:
836 015710 ;VERIFY NO ERRORS DURING FORMAT
837 JSR PC,DTASTS ;GO VERIFY RESULTS OF DATA TRANSFER
838 BR 7$ ;GO TO 7$ IF NO ERROR
839 015710 004737 056572 NOP ;RETURN HERE IF ERROR
015714 000405
015716 000240

```

```

015720 104000          EMT          ;ERROR # DEFINED BY DTASTS SUBROUTINE
015722 004736          JSR          PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
015724 000137 016630  JMP          29$      ;GO TO 29$ IF ERROR
840 015730          7$:
841
842          ;MOVE LOOP ADDRESSES TO NEXT OPERATION
843 015730 012737 015740 001124  MOV          #8$,$LPERR
844 015736 000410          BR          9$          ;SKIP TO WRITE OPERATION
845
846          ;*****
847          ;LOOP #2          WRITE,WRITE CHECK DATA
848
849 015740          8$:
850
851          ;PREPARE DEVICE FOR WRITE OPERATION
852 015740 004737 037316  JSR          PC,TSTPRP ;PREPARE DEVICE FOR TEST
015744 154130          .WORD 154130 ;TASK DESCRIPTOR AS FOLLOWS:
          ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
          ;CLEAR CONTROLLER & SELECT DEVICE
          ;VERIFY CONTROLLER CLEAR OPERATION
          ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
          ;VERIFY PACK ACKNOWLEDGE
          ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
          ;VERIFY RECALIBRATION
015746 000404          BR          9$          ;GO TO 9$ IF NO ERROR
015750 000240          NOP          ;RETURN HERE IF ERROR
015752 104000          EMT          ;ERROR # DEFINED BY TSTPRP SUBROUTINE
015754 000137 016630  JMP          29$      ;GO TO 29$ IF ERROR
853 015760          9$:
854
855          ;WRITE DATA TO THE DRIVE
856 015760          10$:
857 015760 012737 177400 001414  MOV          #-256.,RMWCO ;CHANGE WORD COUNT
858 015766 012737 106442 001416  MOV          #BUFONE+4,RMBAO ;CHANGE MEMORY ADDRESS
859 015774 012737 000061 001412  MOV          #WD!GO,RMCS10 ;WRITE DATA COMMAND
860 016002 012702 001553          MOV          #PUTINX,R2 ;LOAD PUT REGISTER INDEX TABLE
861 016006 112722 000006          MOVB         #RMDA,(R2)+
862 016012 112722 000034          MOVB         #RMDC,(R2)+
863 016016 112722 000032          MOVB         #RMOF,(R2)+
864 016022 112722 000004          MOVB         #RMEA,(R2)+
865 016026 112722 000002          MOVB         #RMWC,(R2)+
866 016032 112722 000000          MOVB         #RMCS1,(R2)+
867 016036 112722 000200          MOVB         #200,(R2)+ ;TERMINATE TABLE
868
869 016042 004737 043330  JSR          PC,PUT ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
016046 000404          BR          11$      ;GO TO 11$ IF NO ERROR
016050 000240          NOP          ;RETURN HERE IF ERROR
016052 104000          EMT          ;ERROR # DEFINED BY PUT SUBROUTINE
016054 000137 016630  JMP          29$      ;GO TO 29$ IF ERROR
870 016060          11$:
871
872          ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
016060 004737 042774  JSR          PC,GETSTS ;GO TO GETSTS SUBROUTINE
873
874          ;WAIT FOR COMMAND TO COMPLETE
016064 004737 043672  JSR          PC,TIMOUT ;GO TO TIMOUT SUBROUTINE
875

```

```

876 ;GO READ STATUS FOR WRITE COMMAND
877 016070 004737 043060 JSR PC,GET ;GO READ REGISTER(S) WITH GET SUBROUTINE
      016074 000404 BR 12$ ;GO TO 12$ IF NO ERROR
      016076 000240 NOP ;RETURN HERE IF ERROR
      016100 104000 EMT ;ERROR # DEFINED BY GET SUBROUTINE
      016102 000137 016630 JMP 29$ ;GO TO 29$ IF ERROR
878 016106 12$:
879
880 ;CHECK FOR ERRORS DURING WRITE OPERATION
881 016106 004737 044056 JSR PC,PRIERR ;GO CHECK FOR PRIMARY ERRORS
      016112 000405 BR 13$ ;GO TO 13$ IF NO ERROR
      016114 000240 NOP ;RETURN HERE IF ERROR
      016116 104000 EMT ;ERROR # DEFINED BY PRIERR SUBROUTINE
      016120 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
      016122 000137 016630 JMP 29$ ;GO TO 29$ IF ERROR
882 016126 13$:
883 016126 004737 056572 JSR PC,DTASTS ;GO VERIFY RESULTS OF DATA TRANSFER
      016132 000405 BR 14$ ;GO TO 14$ IF NO ERROR
      016134 000240 NOP ;RETURN HERE IF ERROR
      016136 104000 EMT ;ERROR # DEFINED BY DTASTS SUBROUTINE
      016140 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
      016142 000137 016630 JMP 29$ ;GO TO 29$ IF ERROR
884 016146 14$:
885 016146 004737 044710 JSR PC,SECERR ;GO CHECK FOR SECONDARY ERRORS
      016152 000405 BR 15$ ;GO TO 15$ IF NO ERROR
      016154 000240 NOP ;RETURN HERE IF ERROR
      016156 104000 EMT ;ERROR # DEFINED BY SECERR SUBROUTINE
      016160 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
      016162 000137 016630 JMP 29$ ;GO TO 29$ IF ERROR
886 016166 15$:
887
888 ;CHANGE LOOP ADDRESSES
889 016166 012737 016174 001124 MOV #16$,$LPERR
890
891 ;*****
892 ;LOOP #3 WRITE CHECK DATA
893
894 016174 16$:
895
896 016174 012703 000001 MOV #1,R3 ;R3+WCE BIT POSITION
897 016200 040337 107440 BIC R3,BUFTWO-2 ;CHANGE LAST WORD OF BUFFER
898
899 ;PREPARE DEVICE FOR WRITE CHECK DATA OPERATION
900 016204 004737 037316 JSR PC,TSTPRP ;PREPARE DEVICE FOR TEST
      016210 154130 .WORD 154130 ;TASK DESCRIPTOR AS FOLLOWS:
      ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
      ;CLEAR CONTROLLER & SELECT DEVICE
      ;VERIFY CONTROLLER CLEAR OPERATION
      ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
      ;VERIFY PACK ACKNOWLEDGE
      ;RECALIBRATE IF "SKI" OR "PIP" IS SET
      ;VERIFY RECALIBRATION
      016212 000404 BR 18$ ;GO TO 18$ IF NO ERROR
      016214 000240 NOP ;RETURN HERE IF ERROR
      016216 104000 EMT ;ERROR # DEFINED BY TSTPRP SUBROUTINE
      016220 000137 016630 JMP 29$ ;GO TO 29$ IF ERROR
901 016224 18$:
  
```

```

902
903 ;READ DATA FROM DEVICE
904 016224 012737 000051 001412 19$: MOV #WCD!GO, RMCS10 ;WRITE CHECK DATA DATA COMMAND
905 016224 012702 001553 MOV #PUTINX, R2 ;LOAD PUT REGISTER INDEX TABLE
906 016232 112722 000006 MOVB #RMDA, (R2)+
907 016236 112722 000032 MOVB #RMOF, (R2)+
908 016242 112722 000034 MOVB #RMDC, (R2)+
909 016246 112722 000004 MOVB #RMB A, (R2)+
910 016252 112722 000002 MOVB #RMWC, (R2)+
911 016256 112722 000000 MOVB #RMCS1, (R2)+
912 016262 112722 000200 MOVB #200, (R2)
913 016266 112712 000200
914
915 016272 004737 043330 JSR PC, PUT ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
016276 000404 BR 20$ ;GO TO 20$ IF NO ERROR
016300 000240 NOP ;RETURN HERE IF ERROR
016302 104000 EMT ;ERROR # DEFINED BY PUT SUBROUTINE
016304 000137 016630 JMP 29$ ;GO TO 29$ IF ERROR
916 016310 20$:
917
918 016310 004737 042774 ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
JSR PC, GETSTS ;GO TO GETSTS SUBROUTINE
919
920 016314 004737 043672 ;WAIT FOR COMMAND TO COMPLETE
JSR PC, TIMEOUT ;GO TO TIMEOUT SUBROUTINE
921
922 ;GO READ STATUS FOR WRITE CHECK DATA OPERATION
923 016320 004737 043060 JSR PC, GET ;GO READ REGISTER(S) WITH GET SUBROUTINE
016324 000404 BR 21$ ;GO TO 21$ IF NO ERROR
016326 000240 NOP ;RETURN HERE IF ERROR
016330 104000 EMT ;ERROR # DEFINED BY GET SUBROUTINE
016332 000137 016630 JMP 29$ ;GO TO 29$ IF ERROR
924 016336 21$:
925
926 ;CHECK FOR ERRORS DURING WRITE CHECK DATA OPERATION
927 016336 004737 044056 JSR PC, PRIERR ;GO CHECK FOR PRIMARY ERRORS
016342 000405 BR 22$ ;GO TO 22$ IF NO ERROR
016344 000240 NOP ;RETURN HERE IF ERROR
016346 104000 EMT ;ERROR # DEFINED BY PRIERR SUBROUTINE
016350 004736 JSR PC, @ (SP)+ ;GO BACK FOR MORE ERROR CHECKS
016352 000137 016630 JMP 29$ ;GO TO 29$ IF ERROR
928 016356 22$:
929 016356 032737 040000 001346 BIT #WCE, RMCS2I ;WAS 'WCE' DETECTED??
930 016364 001030 BNE 24$ ;YES!!
931 016366 004737 056572 JSR PC, DTASTS ;GO VERIFY RESULTS OF DATA TRANSFER
016372 000405 BR 23$ ;GO TO 23$ IF NO ERROR
016374 000240 NOP ;RETURN HERE IF ERROR
016376 104000 EMT ;ERROR # DEFINED BY DTASTS SUBROUTINE
016400 004736 JSR PC, @ (SP)+ ;GO BACK FOR MORE ERROR CHECKS
016402 000137 016630 JMP 29$ ;GO TO 29$ IF ERROR
932 016406 23$:
933 016406 013737 001346 001140 MOV RMCS2I, $GDDAT ;EXPECTED STATUS
934 016414 052737 040000 001140 BIS #WCE, $GDDAT
935 016422 013737 001346 001142 MOV RMCS2I, $BDDAT ;RECEIVED STATUS
936 016430 010337 001174 MOV R3, $TMP0 ;FAILING BIT POSITION
937 016434 012737 107440 001176 MOV #BUFTWO-2, $TMP1 ;FAILING ADDRESS
938 016442 104337 EMT 337

```

```

939 016444 000471 BR 29$
940
941 016446 24$:
942 016446 112737 000022 001524 MOV#B #RMDB,GETINX ;SETUP GET INDEX TABLE
    016454 112737 000200 001525 MOV#B #200,GETINX+1 ;SETUP TERMINATOR BYTE
    016462 012737 016630 001360 MOV #29$,RMDB; ;SET RMDB INPUT BUFFER = 29$
    016470 004737 043060 JSR PC,GET ;GO READ RMDB VIA GET SUBROUTINE
    016474 000402 BR 25$ ;GO TO 25$ IF NO ERROR
    016476 000240 NOP ;RETURN HERE IF ERROR
    016500 104000 EMT ;ERROR DEFINED BY GET SUBROUTINE
943
944 016502 25$:
945 016502 013737 001360 001142 MOV RMDBI,$BDDAT ;RECEIVED DATA
946 016510 013737 107440 001140 MOV BUFTWO-2,$GDDAT ;EXPECTED DATA
947 016516 050337 001140 BIS R3,$GDDAT
948 016522 012737 107440 001134 MOV #BUFTWO-2,$GDADR ;EXPECTED ADDRESS
949 016530 013737 001342 001136 MOV RMBAI,$BDADR ;RECEIVED ADDRESS
950 016536 162737 000002 001136 SUB #2,$BDADR ;CORRECT MEMORY ADDRESS
951 016544 023737 001134 001136 CMP $GDADR,$BDADR ;ADDRESSES OK??
952 016552 001402 BEQ 26$ ;YES!!
953 016554 104340 EMT 340
954 016556 000424 BR 29$
955 016560 023737 001140 001142 26$: CMP $GDDAT,$BDDAT ;DATA OK??
956 016566 001402 BEQ 27$ ;YES!
957 016570 104341 EMT 341
958 016572 000416 BR 29$
959 016574 27$:
960
961 016574 004737 044710 JSR PC,SECERR ;GO CHECK FOR SECONDARY ERRORS
    016600 000405 BR 28$ ;GO TO 28$ IF NO ERROR
    016602 000240 NOP ;RETURN HERE IF ERROR
    016604 104000 EMT ;ERROR # DEFINED BY SECERR SUBROUTINE
    016606 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
    016610 000137 016630 JMP 29$ ;GO TO 29$ IF ERROR
962 016614 28$:
963 016614 050337 107440 BIS R3,BUFTWO-2 ;RESTORE DATA PATTERN
964 016620 006303 ASL R3 ;SHIFT TO NEXT BIT
965 016622 001402 BEQ 29$ ;EXIT IF DONE
966 016624 000137 016200 JMP 17$ ;REPEAT TEST FOR NEXT DATA BIT
967 016630 29$:
968
969
    ;*****
    ;*TEST 10 WRITE, WRITE CHECK MULTIPLE SECTORS
    ;*****
    TST10:
    016630 000004 SCOPE ;SCOPE CALL
    016632 000240 NOP ;START OF TEST
    016634 012706 001100 MOV #STACK,SP ;INITIALIZE STACK POINTER
    016640 013700 001276 MOV $BASE,R0 ;R0 = UNIBUS ADDRESS
    016644 013701 001466 MOV TSTQUE,R1 ;(R1) = DEVICE BEING TESTED
    016650 012737 000010 001226 MOV #10,$TESTN ;;SET TEST NUMBER IN APT MAIL BOX
970
971
972
973
974 016656 1$:
975
    ;*****
    LOOP #1 FORMAT,WRITE,WRITE CHECK
  
```

```

976                                     ;PREPARE THE DEVICE FOR FORMAT OPERATION
977 016656 004737 037316                JSR   PC,TSTPRP      ;PREPARE DEVICE FOR TEST
    016662 154130                        .WORD 154130          ;TASK DESCRIPTOR AS FOLLOWS:
                                           ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
                                           ;CLEAR CONTROLLER & SELECT DEVICE
                                           ;VERIFY CONTROLLER CLEAR OPERATION
                                           ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
                                           ;VERIFY PACK ACKNOWLEDGE
                                           ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
                                           ;VERIFY RECALIBRATION
                                           ;GO TO 2$ IF NO ERROR
                                           ;RETURN HERE IF ERROR
                                           ;ERROR # DEFINED BY TSTPRP SUBROUTINE
                                           ;GO TO 24$ IF ERROR

    016664 000404                        BR     2$
    016666 000240                        NOP
    016670 104000                        EMT
    016672 000137 017634                JMP    24$
978 016676                               2$:
979
980                                     ;LOAD PARAMETERS AND GENERATE DATA BUFFER
981 016676 012737 000000 001446          MOV    #0,RMDCO      ;CYLINDER = 0
982 016704 012737 000000 001420          MOV    #0,RMDAO      ;TRACK = 0, SECTOR - 0
983 016712 012737 106436 001416          MOV    #BUFONE,RMBAO ;BUS ADDRESS
984 016720 012737 176774 001414          MOV    #-258.*2,RMWCO ;WORD COUNT FOR 2 SECTORS (2'S COMP)
985 016726 012737 010000 001444          MOV    #FMT16,RMOFO  ;16 BIT FORMAT
986 016734 012737 000063 001412          MOV    #WH!GO,RMC$10 ;WRITE HEADER AND DATA COMMAND
987
988                                     ;VERIFY THAT SECTOR IS NOT BAD
    016742 004737 040242                JSR    PC,BADSCT     ;CALL BAD SECTOR MODULE
    016746 000405                        BR     3$            ;GO TO 3$ IF NO ERROR
    016750 104401 070426                TYPE   ,SCTMSG      ;TYPE BAD SECTOR MESSAGE
    016754 104000                        EMT
    016756 000137 017634                JMP    24$          ;ERROR # DEFINED BY BADSCT SUBROUTINE
                                           ;GO TO 24$ IF ERROR
989 016762                               3$:
990 016762 012737 072060 001174          MOV    #ZEROS,$TMP0  ;STARTING ADDRESS OF PATTERN
991 016770 012737 000001 001176          MOV    #1,$TMP1     ;RANGE OF PATTERN
992 016776 004737 042174                JSR    PC,GENBUF     ;GO GENERATE BUFFER FOR FORMAT
993
994                                     ;LOAD PUT REGISTER INDEX TABLE FOR FORMAT OPERATION
995 017002 012702 001553                  MOV    #PUTINX,R2    ;R2 = BYTE ENTRY POSITION
996 017006 112722 000034                  MOVB   #RMDC,(R2)+
997 017012 112722 000006                  MOVB   #RMDA,(R2)+
998 017016 112722 000004                  MOVB   #RMBA,(R2)+
999 017022 112722 000002                  MOVB   #RMWC,(R2)+
1000 017026 112722 000032                  MOVB   #RMOF,(R2)+
1001 017032 112722 000000                  MOVB   #RMCS1,(R2)+
1002 017036 112712 000200                  MOVB   #200(R2)     ;TERMINATE TABLE
1003 017042                               4$:
1004
1005                                     ;FORMAT THE DRIVE
1006 017042 004737 043330                JSR    PC,PUT        ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
    017046 000404                        BR     5$            ;GO TO 5$ IF NO ERROR
    017050 000240                        NOP
    017052 104000                        EMT
    017054 000137 017634                JMP    24$          ;RETURN HERE IF ERROR
                                           ;ERROR # DEFINED BY PUT SUBROUTINE
                                           ;GO TO 24$ IF ERROR
1007 017060                               5$:
1008
1009                                     ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
    017060 004737 042774                JSR    PC,GETSTS     ;GO TO GETSTS SUBROUTINE
1010

```

```

1011      ;WAIT FOR COMMAND TO COMPLETE
          JSR      PC,TIMOUT      ;GO TO TIMEOUT SUBROUTINE
017064 004737 043672
1012
1013      ;GO READ STATUS FOR FORMAT OPERATION
1014      JSR      PC,GET          ;GO READ REGISTER(S) WITH GET SUBROUTINE
          BR      6$             ;GO TO 6$ IF NO ERROR
          NOP      000404        ;RETURN HERE IF ERROR
          EMT      104000        ;ERROR # DEFINED BY GET SUBROUTINE
          JMP      000137 017634 ;GO TO 24$ IF ERROR
017074 000404
017076 000240
017100 104000
017102 000137 017634
1015      6$:
1016
1017      ;VERIFY NO ERRORS DURING FORMAT
1018      JSR      PC,DTASTS      ;GO VERIFY RESULTS OF DATA TRANSFER
          BR      7$             ;GO TO 7$ IF NO ERROR
          NOP      000240        ;RETURN HERE IF ERROR
          EMT      104000        ;ERROR # DEFINED BY DTASTS SUBROUTINE
          JSR      PC,@(SP)+      ;GO BACK FOR MORE ERROR CHECKS
          JMP      000137 017634 ;GO TO 24$ IF ERROR
017106 004737 056572
017112 000405
017114 000240
017116 104000
017120 004736
017122 000137 017634
1019      7$:
1020
1021      ;MOVE LOOP ADDRESSES TO NEXT OPERATION
1022      MOV      #8$, $LPERR
017126 012737 017200 001124
1023
1024      ;REGENERATE DATA BUFFER
1025      MOV      #-256.*2,RMWCO ;CHANGE WORD COUNT
1026      MOV      #BUFONE,RMBAO  ;CHANGE BUS ADDRESS
1027      MOV      #WD,RMCS10     ;WRITE DATA
1028      MOV      #ONES,$TMP0    ;STARTING ADDRESS OF PATTERN
1029      MOV      #1,$TMP1       ;RANGE OF PATTERN
1030      JSR      PC,GENBUF
1031      BR      9$              ;SKIP TO WRITE OPERATION
017134 012737 177000 001414
017142 012737 106436 001416
017150 012737 000060 001412
017156 012737 072016 001174
017164 012737 000001 001176
017172 004737 042174
017176 000410
1032
1033      ;:*****
1034      ;LOOP #2      WRITE,WRITE CHECK
1035
1036      8$:
017200
1037
1038
1039      ;PREPARE DEVICE FOR WRITE OPERATION
1040      JSR      PC,TSTPRP      ;PREPARE DEVICE FOR TEST
          .WORD 154130          ;TASK DESCRIPTOR AS FOLLOWS:
          ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
          ;CLEAR CONTROLLER & SELECT DEVICE
          ;VERIFY CONTROLLER CLEAR OPERATION
          ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
          ;VERIFY PACK ACKNOWLEDGE
          ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
          ;VERIFY RECALIBRATION
          BR      9$             ;GO TO 9$ IF NO ERROR
          NOP      000404        ;RETURN HERE IF ERROR
          EMT      104000        ;ERROR # DEFINED BY TSTPRP SUBROUTINE
          JMP      000137 017634 ;GO TO 24$ IF ERROR
017206 000404
017210 000240
017212 104000
017214 000137 017634
1041      9$:
1042
1043      ;WRITE DATA TO THE DRIVE
1044      10$:
1045      MOV      #WD!GO,RMCS10 ;WRITE DATA COMMAND
017220 012737 000061 001412
  
```



```

1046 017226 012702 001553      MOV      #PUTINX,R2          ;LOAD PUT REGISTER INDEX TABLE
1047 017232 112722 000006      MOVB    #RMDA,(R2)+
1048 017236 112722 000034      MOVB    #RMDC,(R2)+
1049 017242 112722 000032      MOVB    #RMOF,(R2)+
1050 017246 112722 000004      MOVB    #RMBA,(R2)+
1051 017252 112722 000002      MOVB    #RMWC,(R2)+
1052 017256 112722 000000      MOVB    #RMCS1,(R2)+
1053 017262 112722 000200      MOVB    #200,(R2)+          ;TERMINATE TABLE
1054
1055 017266 004737 043330      JSR     PC,PUT              ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      017272 000404      BR     11$                 ;GO TO 11$ IF NO ERROR
      017274 000240      NOP
      017276 104000      EMT
      017300 000137 017634      JMP    24$                 ;ERROR # DEFINED BY PUT SUBROUTINE
      ;GO TO 24$ IF ERROR
1056 017304      11$:
1057
1058      ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
      JSR     PC,GETSTS       ;GO TO GETSTS SUBROUTINE
1059 017304 004737 042774
1060      ;WAIT FOR COMMAND TO COMPLETE
      JSR     PC,TIMOUT       ;GO TO TIMOUT SUBROUTINE
1061 017310 004737 043672
1062      ;GO READ STATUS FOR WRITE COMMAND
1063 017314 004737 043060      JSR     PC,GET             ;GO READ REGISTER(S) WITH GET SUBROUTINE
      017320 000404      BR     12$                 ;GO TO 12$ IF NO ERROR
      017322 000240      NOP
      017324 104000      EMT
      017326 000137 017634      JMP    24$                 ;ERROR # DEFINED BY GET SUBROUTINE
      ;GO TO 24$ IF ERROR
1064 017332      12$:
1065
1066      ;CHECK FOR ERRORS DURING WRITE OPERATION
1067 017332 004737 044056      JSR     PC,PRIERR         ;GO CHECK FOR PRIMARY ERRORS
      017336 000405      BR     13$                 ;GO TO 13$ IF NO ERROR
      017340 000240      NOP
      017342 104000      FMT
      017344 004736      JSR     PC,@(SP)+         ;GO BACK FOR MORE ERROR CHECKS
      017346 000137 017634      JMP    24$                 ;GO TO 24$ IF ERROR
1068 017352      13$:
1069 017352 004737 056572      JSR     PC,DTASTS        ;GO VERIFY RESULTS OF DATA TRANSFER
      017356 000405      BR     14$                 ;GO TO 14$ IF NO ERROR
      017360 000240      NOP
      017362 104000      EMT
      017364 004736      JSR     PC,@(SP)+         ;GO BACK FOR MORE ERROR CHECKS
      017366 000137 017634      JMP    24$                 ;GO TO 24$ IF ERROR
1070 017372      14$:
1071 017372 004737 044710      JSR     PC,SECERR        ;GO CHECK FOR SECONDARY ERRORS
      017376 000405      BR     15$                 ;GO TO 15$ IF NO ERROR
      017400 000240      NOP
      017402 104000      EMT
      017404 004736      JSR     PC,@(SP)+         ;GO BACK FOR MORE ERROR CHECKS
      017406 000137 017634      JMP    24$                 ;GO TO 24$ IF ERROR
1072 017412      15$:
1073
1074      ;CHANGE LOOP ADDRESSES
1075 017412 012737 017422 001124      MOV     #16$,$LPERR
1076 017420 000410      BR     17$
1077      ;SKIP TO NEXT OPERATION

```

```

1078      ;*****
1079      ;LOOP #3      WRITE CHECK
1080
1081 017422      16$:
1082
1083      ;PREPARE DEVICE FOR READ OPERATION
1084 017422 004737 037316      JSR      PC,TSTPRP      ;PREPARE DEVICE FOR TEST
      017426 154130      .WORD 154130      ;TASK DESCRIPTOR AS FOLLOWS:
      ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
      ;CLEAR CONTROLLER & SELECT DEVICE
      ;VERIFY CONTROLLER CLEAR OPERATION
      ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
      ;VERIFY PACK ACKNOWLEDGE
      ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
      ;VERIFY RECALIBRATION
      017430 000404      BR      17$      ;GO TO 17$ IF NO ERROR
      017432 000240      NOP
      017434 104000      EMT
      017436 000137 017634      JMP     24$      ;RETURN HERE IF ERROR
      ;ERROR # DEFINED BY TSTPRP SUBROUTINE
      ;GO TO 24$ IF ERROR
1085 017442      17$:
1086
1087      ;READ DATA FROM DEVICE
1088 017442      18$:
1089 017442 012737 000051 001412      MOV     #WCD!GO,RMCS10      ;READ DATA COMMAND
1090 017450 012702 001553      MOV     #PUTINX,R2      ;LOAD PUT REGISTER INDEX TABLE
1091 017454 112722 000006      MOVB   #RMDA,(R2)+
1092 017460 112722 000032      MOVB   #RMOF,(R2)+
1093 017464 112722 000034      MOVB   #RMDC,(R2)+
1094 017470 112722 000004      MOVB   #RMBA,(R2)+
1095 017474 112722 000002      MOVB   #RMWC,(R2)+
1096 017500 112722 000000      MOVB   #RMCS1,(R2)+
1097 017504 112712 000200      MOVB   #200,(R2)
1098
1099 017510 004737 043330      JSR     PC,PUT      ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      017514 000404      BR      19$      ;GO TO 19$ IF NO ERROR
      017516 000240      NOP
      017520 104000      EMT
      017522 000137 017634      JMP     24$      ;RETURN HERE IF ERROR
      ;ERROR # DEFINED BY PUT SUBROUTINE
      ;GO TO 24$ IF ERROR
1100 017526      19$:
1101
1102      ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
      017526 004737 042774      JSR     PC,GETSTS      ;GO TO GETSTS SUBROUTINE
1103
1104      ;WAIT FOR COMMAND TO COMPLETE
      017532 004737 043672      JSR     PC,TIMOUT      ;GO TO TIMOUT SUBROUTINE
1105
1106      ;GO READ STATUS FOR READ OPERATION
1107 017536 004737 043060      JSR     PC,GET      ;GO READ REGISTER(S) WITH GET SUBROUTINE
      017542 000404      BR      20$      ;GO TO 20$ IF NO ERROR
      017544 000240      NOP
      017546 104000      EMT
      017550 000137 017634      JMP     24$      ;RETURN HERE IF ERROR
      ;ERROR # DEFINED BY GET SUBROUTINE
      ;GO TO 24$ IF ERROR
1108 017554      20$:
1109
1110      ;CHECK FOR ERRORS DURING READ OPERATION
1111 017554 004737 044056      JSR     PC,PRIERR      ;GO CHECK FOR PRIMARY ERRORS
      017560 000405      BR      21$      ;GO TO 21$ IF NO ERROR

```

```

10 WRITE, WRITE CHECK MULTIPLE SECTORS

017562 000240      NOP      ;RETURN HERE IF ERROR
017564 104000      EMT      ;ERROR # DEFINED BY TSTPR SUBROUTINE
017566 004736      JSR      ;GO BACK FOR MORE ERROR CHECKS
017570 000137 017634 JMP      ;GO TO 24$ IF ERROR
1112 017574      21$:      JSR      PC,@(SP)+
1113 017574 004737 056572 BR      24$      ;GO VERIFY RESULTS OF DATA TRANSFER
017600 000405      BR      ;GO TO 22$ IF NO ERROR
017602 000240      NOP      ;RETURN HERE IF ERROR
017604 104000      EMT      ;ERROR # DEFINED BY DTASTS SUBROUTINE
017606 004736      JSR      ;GO BACK FOR MORE ERROR CHECKS
017610 000137 017634 JMP      ;GO TO 24$ IF ERROR
1114 017614      22$:      JSR      PC,SECERR
1115 017614 004737 044710 BR      23$      ;GO CHECK FOR SECONDARY ERRORS
017620 000405      BR      ;GO TO 23$ IF NO ERROR
017622 000240      NOP      ;RETURN HERE IF ERROR
017624 104000      EMT      ;ERROR # DEFINED BY SECERR SUBROUTINE
017626 004736      JSR      ;GO BACK FOR MORE ERROR CHECKS
017630 000137 017634 JMP      ;GO TO 24$ IF ERROR
1116 017634      23$:
1117
1118 017634      24$:
1119
1120
;*****
;*TEST 11      WRITE, READ W/ IMPLIED SEEK
;*****
TST11:
017634      SCOPE      ;SCOPE CALL
017634 000004      NOP      ;START OF TEST
017636 000240      MOV      #STACK,SP ;INITIALIZE STACK POINTER
017640 012706 001100 MOV      $BASE,R0    ;R0 = UNIBUS ADDRESS
017644 013700 001276 MOV      TSTQUE,R1   ;(R1) = DEVICE BEING TESTED
017650 013701 001466 MOV      #11,$TESTN ;SET TEST NUMBER IN APT MAIL BOX
017654 012737 000011 001226

1121
1122
;*****
;LOOP #1      FORMAT,WRITE,READ
;*****
1123
1124
1125 017662      1$:
1126
1127
;PREPARE THE DEVICE FOR FORMAT OPERATION
1128 017662 004737 037316 JSR      PC,TSTPRP ;PREPARE DEVICE FOR TEST
017666 154130      .WORD 154130 ;TASK DESCRIPTOR AS FOLLOWS:
;SELECT DEVICE & VERIFY DEVICE AVAILABLE
;CLEAR CONTROLLER & SELECT DEVICE
;VERIFY CONTROLLER CLEAR OPERATION
;PACK ACKNOWLEDGE IF VOLUME NOT VALID
;VERIFY PACK ACKNOWLEDGE
;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
;VERIFY RECALIBRATION
017670 000404      BR      2$      ;GO TO 2$ IF NO ERROR
017672 000240      NOP      ;RETURN HERE IF ERROR
017674 104000      EMT      ;ERROR # DEFINED BY TSTPRP SUBROUTINE
017676 000137 021054 JMP      31$      ;GO TO 31$ IF ERROR
1129
1130
;LOAD PARAMETERS AND GENERATE DATA BUFFER
1131 017702      2$:
1132 017702 012737 000000 001446 MOV      #0,RMDCO    ;CYLINDER = 0
1133 017710 012737 000000 001420 MOV      #0,RMDAO    ;TRACK = 0, SECTOR = 0

```

```

1134 017716 013737 001446 021056      MOV      RMDCO,32$          ;SAVE DESIRED CYLINDER
1135 017724 012737 106436 001416      MOV      #BUFONE,RMBA0    ;BUS ADDRESS
1136 017732 012737 177376 001414      MOV      #-256,RMWCO     ;2 + 256. WORDS (2'S COMP)
1137 017740 012737 010000 001444      MOV      #FMT16,RMOFU    ;16 BIT FORMAT
1138 017746 012737 000063 001412      MOV      #WH!GO,RMCS10   ;WRITE HEADER AND DATA COMMAND
1139
1140                                     ;VERIFY THAT SECTOR IS NOT BAD
      017754 004737 040242      JSR      PC,BADSCT       ;CALL BAD SECTOR MODULE
      017760 000405              BR       3$              ;GO TO 3$ IF NO ERROR
      017762 104401 070426      TYPE    ,SLTMSG         ;TYPE BAD SECTOR MESSAGE
      017766 104000              EMT                     ;ERROR # DEFINED BY BADSCT SUBROUTINE
      017770 000137 021054      JMP      31$            ;GO TO 31$ IF ERROR
1141 017774                                     3$:
1142 017774 012737 072016 001174      MOV      #ONES,$TMP0     ;STARTING ADDRESS OF PATTERN
1143 020002 012737 000001 001176      MOV      #1,$TMP1       ;RANGE OF PATTERN
1144 020010 004737 042174      JSR      PC,GENBUF       ;GO GENERATE BUFFER FOR FORMAT
1145
1146                                     ;LOAD PUT REGISTER INDEX TABLE FOR FORMAT OPERATION
      020014 012702 001553      MOV      #PUTINX,R2      ;R2 = BYTE ENTRY POSITION
1148 020020 112722 000034      MOVB    #RMDC,(R2)+
1149 020024 112722 000006      MOVB    #RMDA,(R2)+
1150 020030 112722 000004      MOVB    #RMBA,(R2)+
1151 020034 112722 000002      MOVB    #RMWC,(R2)+
1152 020040 112722 000032      MOVB    #RMOF,(R2)+
1153 020044 112722 000000      MOVB    #RMCS1,(R2)+
1154 020050 112712 000200      MOVB    #200,(R2)       ;TERMINATE TABLE
1155 020054                                     4$:
1156
1157                                     ;FORMAT THE DRIVE
1158 020054 004737 043330      JSR      PC,PUT          ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      020060 000404              BR       5$              ;GO TO 5$ IF NO ERROR
      020062 000240              NOP                     ;RETURN HERE IF ERROR
      020064 104000              EMT                     ;ERROR # DEFINED BY PUT SUBROUTINE
      020066 000137 021054      JMP      31$            ;GO TO 31$ IF ERROR
1159 020072                                     5$:
1160
1161                                     ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
      020072 004737 042774      JSR      PC,GETSTS       ;GO TO GETSTS SUBROUTINE
1162
1163                                     ;WAIT FOR COMMAND TO COMPLETE
      020076 004737 043672      JSR      PC,TIMOUT       ;GO TO TIMOUT SUBROUTINE
1164
1165                                     ;GO READ STATUS FOR FORMAT OPERATION
1166 020102 004737 043060      JSR      PC,GET          ;GO READ REGISTER(S) WITH GET SUBROUTINE
      020106 000404              BR       6$              ;GO TO 6$ IF NO ERROR
      020110 000240              NOP                     ;RETURN HERE IF ERROR
      020112 104000              EMT                     ;ERROR # DEFINED BY GET SUBROUTINE
      020114 000137 021054      JMP      31$            ;GO TO 31$ IF ERROR
1167 020120                                     6$:
1168
1169                                     ;VERIFY NO ERRORS DURING FORMAT
1170 020120 004737 056572      JSR      PC,DTASTS       ;GO VERIFY RESULTS OF DATA TRANSFER
      020124 000405              BR       7$              ;GO TO 7$ IF NO ERROR
      020126 000240              NOP                     ;RETURN HERE IF ERROR
      020130 104000              EMT                     ;ERROR # DEFINED BY DTASTS SUBROUTINE
      020132 004736              JSR      PC,@(SP)+       ;GO BACK FOR MORE ERROR CHECKS
      020134 000137 021054      JMP      31$            ;GO TO 31$ IF ERROR

```

```

1171 020140      7$:
1172
1173      ;MOVE LOOP ADDRESSES TO NEXT OPERATION
1174 020140 012737 020150 001124      MOV      #8$, $LPERR
1175 020146 000410      BR        9$      ;SKIP TO WRITE OPERATION
1176
1177      ;*****
1178      ;LOOP #2      WRITE,READ
1179
1180 020150      8$:
1181
1182      ;PREPARE DEVICE FOR WRITE OPERATION
1183 020150 004737 037316      JSR      PC, TSTPRP      ;PREPARE DEVICE FOR TEST
      020154 154130      .WORD    154130      ;TASK DESCRIPTOR AS FOLLOWS:
      ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
      ;CLEAR CONTROLLER & SELECT DEVICE
      ;VERIFY CONTROLLER CLEAR OPERATION
      ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
      ;VERIFY PACK ACKNOWLEDGE
      ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
      ;VERIFY RECALIBRATION
      ;GO TO 9$ IF NO ERROR
      ;RETURN HERE IF ERROR
      ;ERROR # DEFINED BY TSTPRP SUBROUTINE
      ;GO TO 31$ IF ERROR
      BR        9$
      NOP
      EMT
      JMP      31$
1184 020170      9$:
1185 020170 012737 001466 001446      MOV      #822, RMDCO      ;SEEK TO LAST CYLINDER
1186 020176 012737 000005 001412      MOV      #SEEK!GO, RMCS10 ;WRITE SEEK COMMAND
1187
1188 020204 004737 043330      JSR      PC, PUT      ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      020210 000404      BR        10$      ;GO TO 10$ IF NO ERROR
      020212 000240      NOP
      020214 104000      EMT
      020216 000137 021054      JMP      31$      ;ERROR # DEFINED BY PUT SUBROUTINE
      ;GO TO 31$ IF ERROR
1189 020222      10$:
1190
1191      ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
      JSR      PC, GETSTS      ;GO TO GETSTS SUBROUTINE
1192 020222 004737 042774
1193      ;WAIT FOR COMMAND TO COMPLETE
      JSR      PC, TIMEOUT      ;GO TO TIMEOUT SUBROUTINE
1194
1195      ;GO GET REGISTER STATUS
1196 020232 004737 043060      JSR      PC, GET      ;GO READ REGISTER(S) WITH GET SUBROUTINE
      020236 000404      BR        11$      ;GO TO 11$ IF NO ERROR
      020240 000240      NOP
      020242 104000      EMT
      020244 000137 021054      JMP      31$      ;RETURN HERE IF ERROR
      ;ERROR # DEFINED BY GET SUBROUTINE
      ;GO TO 31$ IF ERROR
1197 020250      11$:
1198
1199      ;VERIFY RESULTS OF SEEK COMMAND
1200 020250 004737 051174      JSR      PC, SEKSTS      ;GO VERIFY RESULTS OF SEEK OPERATION
      020254 000405      BR        12$      ;GO TO 12$ IF NO ERROR
      020256 000240      NOP
      020260 104000      EMT
      020262 004736      JSR      PC, @(SP)+      ;RETURN HERE IF ERROR
      020264 000137 021054      JMP      31$      ;ERROR # DEFINED BY SEKSTS SUBROUTINE
      ;GO BACK FOR MORE ERROR CHECKS
      ;GO TO 31$ IF ERROR
  
```

```

1201 020270          12$:
1202
1203          ;SETUP PARAMETERS AND EXECUTE WRITE DATA COMMAND
1204 020270          13$:
1205 020270 013737 021056 001446      MOV      32$,RMDCO          ;RESTORE CYLINDER
1206 020276 012737 177400 001414      MOV      #-256.,RMWCO      ;CHANGE WORD COUNT
1207 020304 012737 106442 001416      MOV      #BUFONE+4,RMBAO   ;CHANGE BUS ADDRESS
1208 020312 012737 000061 001412      MOV      #WD!GO,RMCS10    ;WRITE DATA COMMAND
1209 020320 012702 001553              MOV      #PUTINX,R2       ;LOAD PUT REGISTER INDEX TABLE
1210 020324 112722 000006              MOVB     #RMDA,(R2)+
1211 020330 112722 000034              MOVB     #RMDC,(R2)+
1212 020334 112722 000032              MOVB     #RMOF,(R2)+
1213 020340 112722 000004              MOVB     #RMBA,(R2)+
1214 020344 112722 000002              MOVB     #RMWC,(R2)+
1215 020350 112722 000000              MOVB     #RMCS1,(R2)+
1216 020354 112722 000200              MOVB     #200,(R2)+          ;TERMINATE TABLE
1217
1218 020360 004737 043330              JSR      PC,PUT           ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      020364 000404              BR       14$            ;GO TO 14$ IF NO ERROR
      020366 000240              NOP
      020370 104000              EMT      ;ERROR # DEFINED BY PUT SUBROUTINE
      020372 000137 021054              JMP      31$            ;GO TO 31$ IF ERROR
1219 020376          14$:
1220
1221          ;WAIT FOR COMMAND TO COMPLETE
      020376 004737 043672              JSR      PC,TIMOUT       ;GO TO TIMEOUT SUBROUTINE
1222
1223          ;GO READ STATUS FOR WRITE COMMAND
1224 020402 004737 043060              JSR      PC,GET          ;GO READ REGISTER(S) WITH GET SUBROUTINE
      020406 000404              BR       15$            ;GO TO 15$ IF NO ERROR
      020410 000240              NOP
      020412 104000              EMT      ;ERROR # DEFINED BY GET SUBROUTINE
      020414 000137 021054              JMP      31$            ;GO TO 31$ IF ERROR
1225 020420          15$:
1226
1227          ;CHECK FOR ERRORS DURING WRITE OPERATION
1228 020420 004737 044056              JSR      PC,PRIERR       ;GO CHECK FOR PRIMARY ERRORS
      020424 000405              BR       16$            ;GO TO 16$ IF NO ERROR
      020426 000240              NOP
      020430 104000              EMT      ;ERROR # DEFINED BY PRIERR SUBROUTINE
      020432 004736              JSR      PC,@(SP)+      ;GO BACK FOR MORE ERROR CHECKS
      020434 000137 021054              JMP      31$            ;GO TO 31$ IF ERROR
1229 020440          16$:
1230 020440 004737 056572              JSR      PC,DTASTS       ;GO VERIFY RESULTS OF DATA TRANSFER
      020444 000405              BR       17$            ;GO TO 17$ IF NO ERROR
      020446 000240              NOP
      020450 104000              EMT      ;ERROR # DEFINED BY DTASTS SUBROUTINE
      020452 004736              JSR      PC,@(SP)+      ;GO BACK FOR MORE ERROR CHECKS
      020454 000137 021054              JMP      31$            ;GO TO 31$ IF ERROR
1231 020460          17$:
1232 020460 004737 044710              JSR      PC,SECERR       ;GO CHECK FOR SECONDARY ERRORS
      020464 000405              BR       18$            ;GO TO 18$ IF NO ERROR
      020466 000240              NOP
      020470 104000              EMT      ;ERROR # DEFINED BY SECERR SUBROUTINE
      020472 004736              JSR      PC,@(SP)+      ;GO BACK FOR MORE ERROR CHECKS
      020474 000137 021054              JMP      31$            ;GO TO 31$ IF ERROR
1233 020500          18$:
    
```

```

1234
1235
1236 020500 012737 020510 001124 ;CHANGE LOOP ADDRESSES
1237 020506 000410          MOV #19$,SLPERR
1238                                     BR 20$ ;SKIP TO NEXT OPERATION
1239
1240 ;*****
1241 ;LOOP #3 READ
1242 020510 19$:
1243
1244 ;PREPARE DEVICE FOR READ OPERATION
1245 020510 004737 037316 JSR PC,TSTPRP ;PREPARE DEVICE FOR TEST
020514 154130 .WORD 154130 ;TASK DESCRIPTOR AS FOLLOWS:
;SELECT DEVICE & VERIFY DEVICE AVAILABLE
;CLEAR CONTROLLER & SELECT DEVICE
;VERIFY CONTROLLER CLEAR OPERATION
;PACK ACKNOWLEDGE IF VOLUME NOT VALID
;VERIFY PACK ACKNOWLEDGE
;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
;VERIFY RECALIBRATION
;GO TO 20$ IF NO ERROR
;RETURN HERE IF ERROR
;ERROR # DEFINED BY TSTPRP SUBROUTINE
;GO TO 31$ IF ERROR
020516 000404 BR 20$
020520 000240 NOP
020522 104000 EMT
020524 000137 021054 JMP 31$
1246 020530 20$:
1247 020530 012737 001466 001446 MOV #822.,RMDCO ;SEEK TO LAST CYLINDER
1248 020536 012737 000005 001412 MOV #SEEK!GO,RMCS10 ;WRITE SEEK COMMAND
1249
1250 020544 004737 043330 JSR PC,PUT ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
020550 000404 BR 21$ ;GO TO 21$ IF NO ERROR
020552 000240 NOP ;RETURN HERE IF ERROR
020554 104000 EMT ;ERROR # DEFINED BY PUT SUBROUTINE
020556 000137 021054 JMP 31$ ;GO TO 31$ IF ERROR
1251 020562 21$:
1252
1253 ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
020562 004737 042774 JSR PC,GETSTS ;GO TO GETSTS SUBROUTINE
1254
1255 ;WAIT FOR COMMAND TO COMPLETE
020566 004737 043672 JSR PC,TIMOUT ;GO TO TIMOUT SUBROUTINE
1256
1257 ;GO GET REGISTER STATUS
1258 020572 004737 043060 JSR PC,GET ;GO READ REGISTER(S) WITH GET SUBROUTINE
020576 000404 BR 22$ ;GO TO 22$ IF NO ERROR
020600 000240 NOP ;RETURN HERE IF ERROR
020602 104000 EMT ;ERROR # DEFINED BY GET SUBROUTINE
020604 000137 021054 JMP 31$ ;GO TO 31$ IF ERROR
1259 020610 22$:
1260
1261 ;VERIFY RESULTS OF SEEK COMMAND
1262 020610 004737 051174 JSR PC,SEKSTS ;GC VERIFY RESULTS OF SEEK OPERATION
020614 000405 BR 23$ ;GO TO 23$ IF NO ERROR
020616 000240 NOP ;RETURN HERE IF ERROR
020620 104000 EMT ;ERROR # DEFINED BY SEKSTS SUBROUTINE
020622 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
020624 000137 021054 JMP 31$ ;GO TO 31$ IF ERROR
1263 020630 23$:

```

```

1264
1265          ;SETUP PARAMETERS AND EXECUTE READ DATA COMMAND
1266 020630          24$:
1267 020630 013737 021056 001446      MOV      32$,RMDCO          ;RESTORE CYLINDER
1268 020636 012737 000071 001412      MOV      #RD!GO,RMCS10      ;READ DATA COMMAND
1269 020644 012737 107446 001416      MOV      #BUF TWO+4,RMBA0    ;LOAD STARTING BUFFER ADDRESS
1270 020652 012702 001553              MOV      #PUTINX,R2         ;LOAD PUT REGISTER INDEX TABLE
1271 020656 112722 000006              MOVB     #RMDA,(R2)+
1272 020662 112722 000032              MOVB     #RMOF,(R2)+
1273 020666 112722 000034              MOVB     #RMDC,(R2)+
1274 020672 112722 000004              MOVB     #RMBA,(R2)+
1275 020676 112722 000002              MOVB     #RMWC,(R2)+
1276 020702 112722 000000              MOVB     #RMCS1,(R2)+
1277 020706 112712 000200              MOVB     #200,(R2)
1278
1279 020712 004737 043330              JSR      PC,PUT             ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
          020716 000404              BR       25$               ;GO TO 25$ IF NO ERROR
          020720 000240              NOP                      ;RETURN HERE IF ERROR
          020722 104000              EMT                      ;ERROR # DEFINED BY PUT SUBROUTINE
          020724 000137 021054              JMP      31$               ;GO TO 31$ IF ERROR
1280 020730          25$:
1281
1282          ;WAIT FOR COMMAND TO COMPLETE
          020730 004737 043672              JSR      PC,TIMOUT         ;GO TO TIMEOUT SUBROUTINE
1283
1284          ;GO READ STATUS FOR READ OPERATION
1285 020734 004737 043060              JSR      PC,GET            ;GO READ REGISTER(S) WITH GET SUBROUTINE
          020740 000404              BR       26$               ;GO TO 26$ IF NO ERROR
          020742 000240              NOP                      ;RETURN HERE IF ERROR
          020744 104000              EMT                      ;ERROR # DEFINED BY GET SUBROUTINE
          020746 000137 021054              JMP      31$               ;GO TO 31$ IF ERROR
1286 020752          26$:
1287
1288          ;CHECK FOR ERRORS DURING READ OPERATION
1289 020752 004737 044056              JSR      PC,PRIERR         ;GO CHECK FOR PRIMARY ERRORS
          020756 000405              BR       27$               ;GO TO 27$ IF NO ERROR
          020760 000240              NOP                      ;RETURN HERE IF ERROR
          020762 104000              EMT                      ;ERROR # DEFINED BY PRIERR SUBROUTINE
          020764 004736              JSR      PC,@(SP)+         ;GO BACK FOR MORE ERROR CHECKS
          020766 000137 021054              JMP      31$               ;GO TO 31$ IF ERROR
1290 020772          27$:
1291 020772 004737 056572              JSR      PC,DTASTS         ;GO VERIFY RESULTS OF DATA TRANSFER
          020776 000405              BR       28$               ;GO TO 28$ IF NO ERROR
          021000 000240              NOP                      ;RETURN HERE IF ERROR
          021002 104000              EMT                      ;ERROR # DEFINED BY DTASTS SUBROUTINE
          021004 004736              JSR      PC,@(SP)+         ;GO BACK FOR MORE ERROR CHECKS
          021006 000137 021054              JMP      31$               ;GO TO 31$ IF ERROR
1292 021012          28$:
1293 021012 004737 044710              JSR      PC,SECERR         ;GO CHECK FOR SECONDARY ERRORS
          021016 000405              BR       29$               ;GO TO 29$ IF NO ERROR
          021020 000240              NOP                      ;RETURN HERE IF ERROR
          021022 104000              EMT                      ;ERROR # DEFINED BY SECERR SUBROUTINE
          021024 004736              JSR      PC,@(SP)+         ;GO BACK FOR MORE ERROR CHECKS
          021026 000137 021054              JMP      31$               ;GO TO 31$ IF ERROR
1294 021032          29$:
1295 021032 004737 042432              JSR      PC,CMPBUF         ;GO COMPARE WRITE, READ DATA BUFFERS
          021036 106442              .WORD   BUF ONE+4         ;STARTING ADDRESS OF WRITE BUFFER
  
```



```

021040 107446          .WORD BUFTWO+4          ;STARTING ADDRESS OF READ BUFFER
021042 000404          BR      30$          ;GO TO 30$ IF NO ERROR
021044 000240          NOP          ;RETURN HERE IF ERROR
021046 104000          EMT          ;ERROR # DEFINED BY CMPBUF SUBROUTINE
021050 000137 021054  JMP      31$          ;GO TO 31$ IF ERROR
1296 021054          30$:
1297
1298 021054          31$:
1299 021054 000401          BR      33$
1300
1301 021056 000000          .WORD 0          32$:
1302
1303 021060          33$:
1304
1305
;*****
;*TEST 12 WRITE, WRITE CHECK W/ HEAD SWITCHING
;*****
TST12:
021060 000004          SCOPE          ;SCOPE CALL
021062 000240          NOP          ;START OF TEST
021064 012706 001100      MOV      #STACK,SP  ;INITIALIZE STACK POINTER
021070 013700 001276      MOV      $BASE,R0   ;R0 = UNIBUS ADDRESS
021074 013701 001466      MOV      TSTQUE,R1  ;(R1) = DEVICE BEING TESTED
021100 012737 000012 001226  MOV      #12,$TESTN ;:SET TEST NUMBER IN APT MAIL BOX
1306
1307
;*****
;LOOP #1 FORMAT,WRITE,WRITE CHECK
;*****
;LOAD PARAMETERS AND GENERATE DATA BUFFER
1$:
1311 021105
1312 021106 012737 000000 001446      MOV      #0,RMDCO          ;CYLINDER = 0
1313 021114 112737 000000 001421      MOV      #0,RMDAO+1       ;TRACK 0
1314 021122 112737 000037 001420 2$:      MOV      #31,RMDAO        ;SECTOR = 31.
1315 021130 012737 010000 001444      MOV      #FMT16,RMOFO     ;16 BIT FORMAT
1316 021136 012737 106436 001416      MOV      #BUFONE,RMBAO    ;BUS ADDRESS
1317 021144 012737 176774 001414      MOV      #-258.*2,RMWCO   ;WORD COUNT FOR 2 SECTORS (2'S COMP)
1318 021152 012737 000063 001412      MOV      #WH!GO,RMCS10    ;WRITE HEADER AND DATA COMMAND
1319
1320
;VERIFY THAT SECTOR IS NOT BAD
021160 004737 040242      JSR      PC,BADSCT        ;CALL BAD SECTOR MODULE
021164 000405          BR      3$              ;GO TO 3$ IF NO ERROR
021166 104401 070426      TYPE     ,SCTMSG         ;TYPE BAD SECTOR MESSAGE
021172 104000          EMT          ;ERROR # DEFINED BY BADSCT SUBROUTINE
021174 000137 022266      JMP      30$           ;GO TO 30$ IF ERROR
1321 021200          3$:
1322 021200 123727 001420 000037      CMPB     RMDAO,#31.      ;IS LAST TRACK ASSIGNED ?
1323 021206 001345          BNE     2$              ;BR IF NO
1324 021210 012737 072016 001174      MOV      #ONES,$TMP0     ;STARTING ADDRESS OF PATTERN
1325 021216 012737 000001 001176      MOV      #1,$TMP1        ;RANGE OF PATTERN
1326 021224 004737 042174          JSR     PC,GENBUF        ;GO GENERATE BUFFER FOR FORMAT
1327
1328
;PREPARE THE DEVICE FOR FORMAT OPERATION
1329 021230 004737 037316      JSR     PC,TSTPRP        ;PREPARE DEVICE FOR TEST
021234 154130          .WORD 154130           ;TASK DESCRIPTOR AS FOLLOWS:
;SELECT DEVICE & VERIFY DEVICE AVAILABLE
;CLEAR CONTROLLER & SELECT DEVICE
;VERIFY CONTROLLER CLEAR OPERATION

```

```

                                :PACK ACKNOWLEDGE IF VOLUME NOT VALID
                                :VERIFY PACK ACKNOWLEDGE
                                :RECALIBRATE IF 'SKI' OR 'PIP' IS SET
                                :VERIFY RECALIBRATION
                                :GO TO 4$ IF NO ERROR
                                :RETURN HERE IF ERROR
                                :ERROR # DEFINED BY TSTPRP SUBROUTINE
                                :GO TO 30$ IF ERROR
021236 000404 BR 4$
021240 000240 NOP
021242 104000 EMT
021244 000137 022266 JMP 30$
1330 021250 4$:
1331
1332 ;LOAD PUT REGISTER INDEX TABLE FOR FORMAT OPERATIION
1333 021250 012702 001553 MOV #PUTINX,R2 ;R2 - BYTE ENTRY POSITION
1334 021254 112722 000034 MOVB #RMDC,(R2)+
1335 021260 112722 000006 MOVB #RMDA,(R2)+
1336 021264 112722 000004 MOVB #RMBA,(R2)+
1337 021270 112722 000002 MOVB #RMWC,(R2)+
1338 021274 112722 000032 MOVB #RMOF,(R2)+
1339 021300 112722 000000 MOVB #RMCS1,(R2)+
1340 021304 112712 000200 MOVB #200,(R2) ;TERMINATE TABLE
1341
1342 ;FORMAT THE DRIVE
1343 021310 004737 043330 JSR PC,PUT ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
021314 000404 BR 5$ ;GO TO 5$ IF NO ERROR
021316 000240 NOP ;RETURN HERE IF ERROR
021320 104000 EMT ;ERROR # DEFINED BY PUT SUBROUTINE
021322 000137 022266 JMP 30$ ;GO TO 30$ IF ERROR
1344 021326 5$:
1345
1346 ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
021326 004737 042774 JSR PC,GETSTS ;GO TO GETSTS SUBROUTINE
1347
1348 ;WAIT FOR COMMAND TO COMPLETE
021332 004737 043672 JSR PC,TIMOUT ;GO TO TIMOUT SUBROUTINE
1349
1350 ;GO READ STATUS FOR FORMAT OPERATION
1351 021336 004737 043060 JSR PC,GET ;GO READ REGISTER(S) WITH GET SUBROUTINE
021342 000404 BR 6$ ;GO TO 6$ IF NO ERROR
021344 000240 NOP ;RETURN HERE IF ERROR
021346 104000 EMT ;ERROR # DEFINED BY GET SUBROUTINE
021350 000137 022266 JMP 30$ ;GO TO 30$ IF ERROR
1352 021354 6$:
1353
1354 ;VERIFY NO ERRORS DURING FORMAT
1355 021354 004737 056572 JSR PC,DTASTS ;GO VERIFY RESULTS OF DATA TRANSFER
021360 000405 BR 7$ ;GO TO 7$ IF NO ERROR
021362 000240 NOP ;RETURN HERE IF ERROR
021364 104000 EMT ;ERROR # DEFINED BY DTASTS SUBROUTINE
021366 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
021370 000137 022266 JMP 30$ ;GO TO 30$ IF ERROR
1356 021374 7$:
1357
1358 ;MOVE LOOP ADDRESSES TO NEXT OPERATION
1359 021374 012737 021446 001124 MOV #8$,$LPERR
1360
1361 ;REGENERATE BUFFER
1362 021402 012737 177000 001414 MOV #-256,*2,RMWCO ;CHANGE WORD COUNT
1363 021410 012737 106436 001416 MOV #BUFONE,RMBAO ;CHANGE BUS ADDRESS

```

```

1364 021416 012737 072060 001174      MOV      #ZEROS,$TMP0      ;STARTING ADDRESS
1365 021424 012737 000001 001176      MOV      #1,$TMP1         ;RANGE
1366 021432 012737 000060 001412      MOV      #WD,$RMCS10      ;WRITE DATA
1367 021440 004737 042174      JSR      PC,GENBUF        ;GENERATE BUFFER
1368 021444 000410      BR       9$              ;SKIP TO WRITE OPERATION
1369
1370      ;*****
1371      ;LOOP #?              WRITE,WRITE CHECK
1372
1373 021446      8$:
1374
1375      ;PREPARE DEVICE FOR WRITE OPERATION
1376 021446 004737 037316      JSR      PC,TSTPRP        ;PREPARE DEVICE FOR TEST
      021452 154130      .WORD   154130           ;TASK DESCRIPTOR AS FOLLOWS:
      ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
      ;CLEAR CONTROLLER & SELECT DEVICE
      ;VERIFY CONTROLLER CLEAR OPERATION
      ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
      ;VERIFY PACK ACKNOWLEDGE
      ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
      ;VERIFY RECALIBRATION
      ;GO TO 9$ IF NO ERROR
      ;RETURN HERE IF ERROR
      ;ERROR # DEFINED BY TSTPRP SUBROUTINE
      ;GO TO 30$ IF ERROR
      021454 000404      BR       9$
      021456 000240      NOP
      021460 104000      EMT
      021462 000137 022266      JMP      30$
1377 021466      9$:
1378 021466 012737 000005 001412      MOV      #SEEK!GO,$RMCS10 ;LOAD SEEK COMMAND
1379
1380 021474 004737 043330      JSR      PC,PUT           ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      021500 000404      BR       10$            ;GO TO 10$ IF NO ERROR
      021502 000240      NOP                    ;RETURN HERE IF ERROR
      021504 104000      EMT                    ;ERROR # DEFINED BY PUT SUBROUTINE
      021506 000137 022266      JMP      30$            ;GO TO 30$ IF ERROR
1381 021512      10$:
1382
1383      ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
      JSR      PC,GETSTS      ;GO TO GETSTS SUBROUTINE
1384
1385      ;WAIT FOR COMMAND TO COMPLETE
      JSR      PC,TIMOUT      ;GO TO TIMOUT SUBROUTINE
1386
1387      ;GO GET REGISTER STATUS
1388 021522 004737 043060      JSR      PC,GET           ;GO READ REGISTER(S) WITH GET SUBROUTINE
      021526 000404      BR       11$            ;GO TO 11$ IF NO ERROR
      021530 000240      NOP                    ;RETURN HERE IF ERROR
      021532 104000      EMT                    ;ERROR # DEFINED BY GET SUBROUTINE
      021534 000137 022266      JMP      30$            ;GO TO 30$ IF ERROR
1389 021540      11$:
1390
1391      ;VERIFY RESULTS OF SEEK COMMAND
1392 021540 004737 051174      JSR      PC,SEKSTS        ;GO VERIFY RESULTS OF SEEK OPERATION
      021544 000405      BR       12$            ;GO TO 12$ IF NO ERROR
      021546 000240      NOP                    ;RETURN HERE IF ERROR
      021550 104000      EMT                    ;ERROR # DEFINED BY SEKSTS SUBROUTINE
      021552 004736      JSR      PC,@(SP)+        ;GO BACK FOR MORE ERROR CHECKS
      021554 000137 022266      JMP      30$            ;GO TO 30$ IF ERROR
1393 021560      12$:

```

```

1394
1395           ;WRITE DATA TO THE DRIVE
1396 021560           13$:
1397 021560 012737 000061 001412      MOV      #WD!GO, RMCS10      ;WRITE DATA COMMAND
1398 021566 012702 001553              MOV      #PUTINX, R2        ;LOAD PUT REGISTER INDEX TABLE
1399 021572 112722 000006              MOVB     #RMDA, (R2)+
1400 021576 112722 000034              MOVB     #RMDC, (R2)+
1401 021602 112722 000032              MOVB     #RMOF, (R2)+
1402 021606 112722 000004              MOVB     #RMB A, (R2)+
1403 021612 112722 000002              MOVB     #RMWC, (R2)+
1404 021616 112722 000000              MOVB     #RMCS1, (R2)+
1405 021622 112722 000200              MOVB     #200, (R2)+      ;TERMINATE TABLE
1406
1407 021626 004737 043330              JSR      PC, PUT          ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
                                BR      14$          ;GO TO 14$ IF NO ERROR
                                NOP          ;RETURN HERE IF ERROR
                                EMT          ;ERROR # DEFINED BY PUT SUBROUTINE
                                JMP      30$          ;GO TO 30$ IF ERROR
                                1408 021644           14$:
1409
1410           ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
                                JSR      PC, GETSTS      ;GO TO GETSTS SUBROUTINE
1411 021644 004737 042774
1412           ;WAIT FOR COMMAND TO COMPLETE
                                JSR      PC, TIMOUT      ;GO TO TIMOUT SUBROUTINE
1413 021650 004737 043672
1414           ;GO READ STATUS FOR WRITE COMMAND
1415 021654 004737 043060              JSR      PC, GET          ;GO READ REGISTER(S) WITH GET SUBROUTINE
                                BR      15$          ;GO TO 15$ IF NO ERROR
                                NOP          ;RETURN HERE IF ERROR
                                EMT          ;ERROR # DEFINED BY GET SUBROUTINE
                                JMP      30$          ;GO TO 30$ IF ERROR
                                1416 021672           15$:
1417
1418           ;CHECK FOR ERRORS DURING WRITE OPERATION
1419 021672 004737 044056              JSR      PC, PRIERR      ;GO CHECK FOR PRIMARY ERRORS
                                BR      16$          ;GO TO 16$ IF NO ERROR
                                NOP          ;RETURN HERE IF ERROR
                                EMT          ;ERROR # DEFINED BY PRIERR SUBROUTINE
                                JSR      PC, @ (SP)+      ;GO BACK FOR MORE ERROR CHECKS
                                JMP      30$          ;GO TO 30$ IF ERROR
                                1420 021712           16$:
1421 021712 004737 056572              JSR      PC, DTASTS      ;GO VERIFY RESULTS OF DATA TRANSFER
                                BR      17$          ;GO TO 17$ IF NO ERROR
                                NOP          ;RETURN HERE IF ERROR
                                EMT          ;ERROR # DEFINED BY DTASTS SUBROUTINE
                                JSR      PC, @ (SP)+      ;GO BACK FOR MORE ERROR CHECKS
                                JMP      30$          ;GO TO 30$ IF ERROR
                                1422 021732           17$:
1423 021732 004737 044710              JSR      PC, SECERR      ;GO CHECK FOR SECONDARY ERRORS
                                BR      18$          ;GO TO 18$ IF NO ERROR
                                NOP          ;RETURN HERE IF ERROR
                                EMT          ;ERROR # DEFINED BY SECERR SUBROUTINE
                                JSR      PC, @ (SP)+      ;GO BACK FOR MORE ERROR CHECKS
                                JMP      30$          ;GO TO 30$ IF ERROR
1424 021752           18$:
1425

```

```

1426 ;CHANGE LOOP ADDRESSES
1427 021752 012737 021762 001124 MOV #19$, $LPERR
1428 021760 000410 BR 20$ ;SKIP TO NEXT OPERATION
1429
1430 ;*****
1431 ;LOOP #3 WRITE CHECK
1432
1433 021762 19$:
1434
1435 ;PREPARE DEVICE FOR READ OPERATION
1436 021762 004737 037316 JSR PC, TSTPRP ;PREPARE DEVICE FOR TEST
021766 154130 .WORD 154130 ;TASK DESCRIPTOR AS FOLLOWS:
;SELECT DEVICE & VERIFY DEVICE AVAILABLE
;CLEAR CONTROLLER & SELECT DEVICE
;VERIFY CONTROLLER CLEAR OPERATION
;PACK ACKNOWLEDGE IF VOLUME NOT VALID
;VERIFY PACK ACKNOWLEDGE
;RECALIBRATE IF 'SKI' OR 'PIP' IS SFT
;VERIFY RECALIBRATION
;GO TO 20$ IF NO ERROR
;RETURN HERE IF ERROR
;ERROR # DEFINED BY TSTPRP SUBROUTINE
;GO TO 30$ IF ERROR
021770 000404 BR 20$
021772 000240 NOP
021774 104000 EMT
021776 000137 022266 JMP 30$
1437 022002 20$:
1438 022002 012737 000005 001412 MOV #SEEK!GO, RMCS10 ;LOAD SEEK COMMAND
1439
1440 022010 004737 043330 JSR PC, PUT ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
022014 000404 BR 21$ ;GO TO 21$ IF NO ERROR
022016 000240 NOP ;RETURN HERE IF ERROR
022020 104000 EMT ;ERROR # DEFINED BY PUT SUBROUTINE
022022 000137 022266 JMP 30$ ;GO TO 30$ IF ERROR
1441 022026 21$:
1442
1443 ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
022026 004737 042774 JSR PC, GETSTS ;GO TO GETSTS SUBROUTINE
1444
1445 ;WAIT FOR COMMAND TO COMPLETE
022032 004737 043672 JSR PC, TIMEOUT ;GO TO TIMEOUT SUBROUTINE
1446
1447 ;GO READ REGISTER STATUS
1448 022036 004737 043060 JSR PC, GET ;GO READ REGISTER(S) WITH GET SUBROUTINE
022042 000404 BR 22$ ;GO TO 22$ IF NO ERROR
022044 000240 NOP ;RETURN HERE IF ERROR
022046 104000 EMT ;ERROR # DEFINED BY GET SUBROUTINE
022050 000137 022266 JMP 30$ ;GO TO 30$ IF ERROR
1449 022054 22$:
1450
1451 ;GO VERIFY RESULTS OF SEEK
1452 022054 004737 051174 JSR PC, SEKSTS ;GO VERIFY RESULTS OF SEEK OPERATION
022060 000405 BR 23$ ;GO TO 23$ IF NO ERROR
022062 000240 NOP ;RETURN HERE IF ERROR
022064 104000 EMT ;ERROR # DEFINED BY SEKSTS SUBROUTINE
022066 004736 JSR PC, @ (SP)+ ;GO BACK FOR MORE ERROR CHECKS
022070 000137 022266 JMP 30$ ;GO TO 30$ IF ERROR
1453 022074 23$:
1454
1455 ;READ DATA FROM DEVICE
  
```

```

1456 022074          24$:
1457 022074 012737 000051 001412  MOV   #WCD.GO, RMCS10      ;READ DATA COMMAND
1458 022102 012702 001553          MOV   #PUTINX, R2         ;LOAD PUT REGISTER INDEX TABLE
1459 022106 112722 000006          MOVB  #RMDA, (R2)+
1460 022112 112722 000032          MOVB  #RMOF, (R2)+
1461 022116 112722 000034          MOVB  #RMDC, (R2)+
1462 022122 112722 000004          MOVB  #RMB A, (R2)+
1463 022126 112722 000002          MOVB  #RMWC, (R2)+
1464 022132 112722 000000          MOVB  #RMCS1, (R2)+
1465 022136 112712 000200          MOVB  #200, (R2)
1466
1467 022142 004737 043330          JSR   PC, PUT             ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      022146 000404          BR    25$                ;GO TO 25$ IF NO ERROR
      022150 000240          NOP                    ;RETURN HERE IF ERROR
      022152 104000          EMT                    ;ERROR # DEFINED BY PUT SUBROUTINE
      022154 000137 022266          JMP   30$                ;GO TO 30$ IF ERROR
1468 022160          25$:
1469
1470          ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
      022160 004737 042774          JSR   PC, GETSTS         ;GO TO GETSTS SUBROUTINE
1471
1472          ;WAIT FOR COMMAND TO COMPLETE
      022164 004737 043672          JSR   PC, TIMEOUT        ;GO TO TIMEOUT SUBROUTINE
1473
1474          ;GO READ STATUS FOR READ OPERATION
1475 022170 004737 043060          JSR   PC, GET            ;GO READ REGISTER(S) WITH GET SUBROUTINE
      022174 000404          BR    26$                ;GO TO 26$ IF NO ERROR
      022176 000240          NOP                    ;RETURN HERE IF ERROR
      022200 104000          EMT                    ;ERROR # DEFINED BY GET SUBROUTINE
      022202 000137 022266          JMP   30$                ;GO TO 30$ IF ERROR
1476 022206          26$:
1477
1478          ;CHECK FOR ERRORS DURING READ OPERATION
1479 022206 004737 044056          JSR   PC, PRIERR         ;GO CHECK FOR PRIMARY ERRORS
      022212 000405          BR    27$                ;GO TO 27$ IF NO ERROR
      022214 000240          NOP                    ;RETURN HERE IF ERROR
      022216 104000          EMT                    ;ERROR # DEFINED BY PRIERR SUBROUTINE
      022220 004736          JSR   PC, @ (SP)+        ;GO BACK FOR MORE ERROR CHECKS
      022222 000137 022266          JMP   30$                ;GO TO 30$ IF ERROR
1480 022226          27$:
1481 022226 004737 056572          JSR   PC, DTASTS         ;GO VERIFY RESULTS OF DATA TRANSFER
      022232 000405          BR    28$                ;GO TO 28$ IF NO ERROR
      022234 000240          NOP                    ;RETURN HERE IF ERROR
      022236 104000          EMT                    ;ERROR # DEFINED BY DTASTS SUBROUTINE
      022240 004736          JSR   PC, @ (SP)+        ;GO BACK FOR MORE ERROR CHECKS
      022242 000137 022266          JMP   30$                ;GO TO 30$ IF ERROR
1482 022246          28$:
1483 022246 004737 044710          JSR   PC, SECERR         ;GO CHECK FOR SECONDARY ERRORS
      022252 000405          BR    29$                ;GO TO 29$ IF NO ERROR
      022254 000240          NOP                    ;RETURN HERE IF ERROR
      022256 104000          EMT                    ;ERROR # DEFINED BY SECERR SUBROUTINE
      022260 004736          JSR   PC, @ (SP)+        ;GO BACK FOR MORE ERROR CHECKS
      022262 000137 022266          JMP   30$                ;GO TO 30$ IF ERROR
1484 022266          29$:
1485
1486          30$:
1487

```

```

1488          022266          000004          001100          001226
022266          000240
022270          012706          001276
022272          013700          001466
022276          013701          000013
022302          012737
022306          000013          001226

1489
1490
1491
1492
1493
1494 022314
1495 022314 012737 000000 001446
1496 022322 013737 001334 001420
1497 022330 112737 000037 001420
1498 022336 012737 010000 001444
1499 022344 012737 106436 001416
1500 022352 012737 176774 001414
1501 022360 012737 000063 001412
1502
1503
022366 004737 040242
022372 000405
022374 104401 070426
022400 104000
022402 000137 023310
1504 022406
1505 022406 123737 001421 001335
1506 022414 001342
1507 022416 012737 072060 001174
1508 022424 012737 000001 001176
1509 022432 004737 042174
1510
1511
1512 022436 004737 037316
022442 154130

022444 000404
022446 000240
022450 104000
022452 000137 023310
1513 022456
1514
1515
1516 022456 012702 001553
1517 022462 112722 000034
1518 022466 112722 000006

*****
*TEST 13 WRITE, WRITE CHECK W/ MID-TRANSFER SEEK
*****
TST13:
SCOPE ;SCOPE CALL
NOP ;START OF TEST
MOV #STACK,SP ;INITIALIZE STACK POINTER
MOV $BASE,R0 ;R0 = UNIBUS ADDRESS
MOV TSTQUE,R1 ;(R1) = DEVICE BEING TESTED
MOV #13,$TESTN ;;SET TEST NUMBER IN APT MAIL BOX

*****
;LOOP #1 FORMAT,WRITE,WRITE CHECK

;LOAD PARAMETERS AND GENERATE DATA BUFFER
1$:
MOV #0,RMDCO ;CYLINDER = 0
LSTRK,RMDAO ;SET LAST TRACK AND
MOV #31,RMDAO ;LAST SECTOR
MOV #FMT16,RMFO ;16 BIT FORMAT
MOV #BUFONE,RMBAO ;BUS ADDRESS
MOV #-258,*2,RMWCO ;WORD COUNT FOR 2 SECTORS (2* COMP)
MOV #WH!GO,RMCS10 ;WRITE HEADER AND DATA COMMAND

;VERIFY THAT SECTOR IS NOT BAD
JSR PC,BADSCT ;CALL BAD SECTOR MODULE
BR 3$ ;GO TO 3$ IF NO ERROR
TYPE ,SCTMSG ;TYPE BAD SECTOR MESSAGE
EMT ;ERROR # DEFINED BY BADSCT SUBROUTINE
JMP 25$ ;GO TO 25$ IF ERROR

3$:
CMPB RMDAO+1,LSTRK+1 ;IS LAST TRACK ASSIGNED ?
BNE 2$ ;BR IF NO
MOV #ZEROS,$TMP0 ;STARTING ADDRESS OF PATTERN
MOV #1,$TMP1 ;RANGE OF PATTERN
JSR PC,GENBUF ;GO GENERATE BUFFER FOR FORMAT

;PREPARE THE DEVICE FOR FORMAT OPERATION
JSR PC,TSTPRP ;PREPARE DEVICE FOR TEST
.WORD 154130 ;TASK DESCRIPTOR AS FOLLOWS:
;SELECT DEVICE & VERIFY DEVICE AVAILABLE
;CLEAR CONTROLLER & SELECT DEVICE
;VERIFY CONTROLLER CLEAR OPERATION
;PACK ACKNOWLEDGE IF VOLUME NOT VALID
;VERIFY PACK ACKNOWLEDGE
;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
;VERIFY RECALIBRATION
BR 4$ ;GO TO 4$ IF NO ERROR
NOP ;RETURN HERE IF ERROR
EMT ;ERROR # DEFINED BY TSTPRP SUBROUTINE
JMP 25$ ;GO TO 25$ IF ERROR

4$:

;LOAD PUT REGISTER INDEX TABLE FOR FORMAT OPERATION
MOV #PUTINX,R2 ;R2 - BYTE ENTRY POSITION
MOV #RMDC,(R2)+
MOV #RMDA,(R2)+
  
```

```

1519 022472 112722 000004      MOVB  #RMSA,(R2)+
1520 022476 112722 000002      MOVB  #RMWC,(R2)+
1521 022502 112722 000032      MOVB  #RMOF,(R2)+
1522 022506 112722 000000      MOVB  #RMCS1,(R2)+
1523 022512 112712 000200      MOVB  #200,(R2)                ;TERMINATE TABLE
1524 022516
1525 022516 004737 043330      5$: JSR  PC,PUT                ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      022522 000404          BR   6$                    ;GO TO 6$ IF NO ERROR
      022524 000240          NOP                    ;RETURN HERE IF ERROR
      022526 104000          EMT                    ;ERROR # DEFINED BY PUT SUBROUTINE
      022530 000137 023310      JMP  25$                   ;GO TO 25$ IF ERROR
1526 022534
1527
1528                                ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
      022534 004737 042774      JSR  PC,GETSTS              ;GO TO GETSTS SUBROUTINE
1529
1530                                ;WAIT FOR COMMAND TO COMPLETE
      022540 004737 043672      JSR  PC,TIMOUT              ;GO TO TIMEOUT SUBROUTINE
1531
1532                                ;GO READ STATUS FOR FORMAT OPERATION
1533 022544 004737 043060      JSR  PC,GET                ;GO READ REGISTER(S) WITH GET SUBROUTINE
      022550 000404          BR   7$                    ;GO TO 7$ IF NO ERROR
      022552 000240          NOP                    ;RETURN HERE IF ERROR
      022554 104000          EMT                    ;ERROR # DEFINED BY GET SUBROUTINE
      022556 00013  023310      JMP  25$                   ;GO TO 25$ IF ERROR
1534 022562
1535
1536                                ;VERIFY NO ERRORS DURING FORMAT
1537 022562 004737 056572      JSR  PC,DTASTS              ;GO VERIFY RESULTS OF DATA TRANSFER
      022566 000405          BR   8$                    ;GO TO 8$ IF NO ERROR
      022570 000240          NOP                    ;RETURN HERE IF ERROR
      022572 104000          EMT                    ;ERROR # DEFINED BY DTASTS SUBROUTINE
      022574 004736          JSR  PC,@(SP)+              ;GO BACK FOR MORE ERROR CHECKS
      022576 000137 023310      JMP  25$                   ;GO TO 25$ IF ERROR
1538 022602
1539
1540                                ;MOVE LOOP ADDRESSES TO NEXT OPERATION
1541 022602 012737 022654 001124      MOV  #9$,SLPERR
1542
1543                                ;REGENERATE BUFFER
1544 022610 012737 000060 001412      MOV  #WD,RMCS10            ;WRITE DATA
1545 022616 012737 177000 001414      MOV  #-256,*2,RMWC0        ;CHANGE WORD COUNT
1546 022624 012737 106436 001416      MOV  #BUFONE,RMBA0         ;CHANGE BUS ADDRSS
1547 022632 012737 072016 001174      MOV  #ONES,$TMP0           ;PATTERN ADDRESS
1548 022640 012737 000001 001176      MOV  #1,$TMP1              ;PATTERN RANGE
1549 022646 004737 042174          JSR  PC,GENBUF
1550 022652 000410          BR   10$                   ;SKIP TO WRITE OPERATION
1551
1552                                ;*****
1553                                ;LOOP #2      WRITE,WRITE CHECK
1554
1555 022654      9$:
1556
1557                                ;PREPARE DEVICE FOR WRITE OPERATION
1558 022654 004737 037316      JSR  PC,ISTPRP             ;PREPARE DEVICE FOR TEST
      022660 154130          .WOR 154130           ;TASK DESCRIPTOR AS FOLLOWS:
                                                    ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
  
```


;CLEAR CONTROLLER & SELECT DEVICE
;VERIFY CONTROLLER CLEAR OPERATION
;PACK ACKNOWLEDGE IF VOLUME NOT VALID
;VERIFY PACK ACKNOWLEDGE
;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
;VERIFY RECALIBRATION
;GO TO 10\$ IF NO ERROR
;RETURN HERE IF ERROR
;ERROR # DEFINED BY TSTPRP SUBROUTINE
;GO TO 25\$ IF ERROR

022662 000404
022664 000240
022666 104000
022670 0C0137 023310
1559 022674

BR 10\$
NOP
EMT
JMP 25\$

10\$:

1560
1561
1562 022674
1563 022674 012737 000061 001412
1564 022702 012702 001553
1565 022706 112722 000006
1566 022712 112722 000034
1567 022716 112722 000032
1568 022722 112722 0C0004
1569 022726 112722 000002
1570 022732 112722 000000
1571 022736 112722 000200
1572

;WRITE DATA TO THE DRIVE

11\$:

MOV #WD!GO,RMCS10
MOV #PUTINX,R2
MOVB #RMDA,(R2)+
MOVB #RMDC,(R2)+
MOVB #RMOF,(R2)+
MOVB #RMB A,(R2)+
MOVB #RMWC,(R2)+
MOVB #RMCS1,(R2)+
MOVB #200,(R2)+

;WRITE DATA COMMAND
;LOAD PUT REGISTER INDEX TABLE

;TERMINATE TABLE

1573 022742 004737 043330
022746 000404
022750 000240
022752 104000
022754 000137 023310
1574 022760

JSR PC,PUT
BR 12\$
NOP
EMT
JMP 25\$

;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
;GO TO 12\$ IF NO ERROR
;RETURN HERE IF ERROR
;ERROR # DEFINED BY PUT SUBROUTINE
;GO TO 25\$ IF ERROR

12\$:

1575
1576 022760 004737 042774

;SETUP GET INDEX TABLE TO READ ALL REGISTERS

JSR PC,GETSTS

;GO TO GETSTS SUBROUTINE

1577
1578 022764 004737 043672

;WAIT FOR COMMAND TO COMPLETE

JSR PC,TIMOUT

;GO TO TIMOUT SUBROUTINE

1579
1580
1581 022770 004737 043060
022774 000404
022776 000240
023000 104000
023002 000137 023310

;GO READ STATUS FOR WRITE COMMAND

JSR PC,GET
BR 13\$
NOP
EMT
JMP 25\$

;GO READ REGISTER(S) WITH GET SUBROUTINE
;GO TO 13\$ IF NO ERROR
;RETURN HERE IF ERROR
;ERROR # DEFINED BY GET SUBROUTINE
;GO TO 25\$ IF ERROR

13\$:

1582 023006
1583
1584

;CHECK FOR ERRORS DURING WRITE OPERATION

JSR PC,PRIERR
BR 14\$
NOP
EMT
JSR PC,@(SP)+
JMP 25\$

;GO CHECK FOR PRIMARY ERRORS
;GO TO 14\$ IF NO ERROR
;RETURN HERE IF ERROR
;ERROR # DEFINED BY PRIERR SUBROUTINE
;GO BACK FOR MORE ERROR CHECKS
;GO TO 25\$ IF ERROR

1585 023006 004737 044056
023012 000405
023014 000240
023016 104000
023020 004736
023022 000137 023310

14\$:

1586 023026
1587 023026 004737 056572
023032 000405
023034 000240
023036 104000

JSR PC,DTASTS
BR 15\$
NOP
EMT

;GO VERIFY RESULTS OF DATA TRANSFER
;GO TO 15\$ IF NO ERROR
;RETURN HERE IF ERROR
;ERROR # DEFINED BY DTASTS SUBROUTINE

```

023040 004736      JSR    PC,@(SP)+      ;GO BACK FOR MORE ERROR CHECKS
023042 000137 023310  JMP    25$                      ;GO TO 25$ IF ERROR
1588 023046      JSR    PC,SECERR      ;GO CHECK FOR SECONDARY ERRORS
1589 023046 004737 044710  BR    16$                      ;GO TO 16$ IF NO ERROR
023052 000405      NOP                               ;RETURN HERE IF ERROR
023054 000240      EMT                               ;ERROR # DEFINED BY SECERR SUBROUTINE
023056 104000      JSR    PC,@(SP)+      ;GO BACK FOR MORE ERROR CHECKS
023060 004736      JMP    25$                      ;GO TO 25$ IF ERROR
023062 000137 023310
1590 023066
1591
1592
1593 023066 012737 023076 001124  ;CHANGE LOOP ADDRESSES
1594 023074 000410      MOV    #17$,SLPERR
1595
1596
1597
1598
1599 023076      BR    18$                      ;SKIP TO NEXT OPERATION
1600
1601
1602 023076 004737 037316  ;*****
023102 154130      ;LOOP #3      WRITE CHECK
17$:
;PREPARE DEVICE FOR READ OPERATION
      JSR    PC,TSTPRP      ;PREPARE DEVICE FOR TEST
      .WORD 154130          ;TASK DESCRIPTOR AS FOLLOWS:
                          ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
                          ;CLEAR CONTROLLER & SELECT DEVICE
                          ;VERIFY CONTROLLER-CLEAR OPERATION
                          ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
                          ;VERIFY PACK ACKNOWLEDGE
                          ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
                          ;VERIFY RECALIBRATION
023104 000404      BR    18$                      ;GO TO 18$ IF NO ERROR
023106 000240      NOP                               ;RETURN HERE IF ERROR
023110 104000      EMT                               ;ERROR # DEFINED BY TSTPRP SUBROUTINE
023112 000137 023310  JMP    25$                      ;GO TO 25$ IF ERROR
1603 023116
1604
1605
1606 023116      ;READ DATA FROM DEVICE
1607 023116 012737 000051 001412  19$:      MOV    #WCD!GO,RMCS10      ;READ DATA COMMAND
1608 023124 012702 001553      MOV    #PUTINX,R2        ;LOAD PUT REGISTER INDEX TABLE
1609 023130 112722 000006      MOVB  #RMDA,(R2)+
1610 023134 112722 000032      MOVB  #RMOF,(R2)+
1611 023140 112722 000034      MOVB  #RMDC,(R2)+
1612 023144 112722 000004      MOVB  #RMB A,(R2)+
1613 023150 112722 000002      MOVB  #RMWC,(R2)+
1614 023154 112722 000000      MOVB  #RMCS1,(R2)+
1615 023160 112712 000200      MOVB  #200,(R2)
1616
1617 023164 004737 043330      JSR    PC,PUT            ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
023170 000404      BR    20$                      ;GO TO 20$ IF NO ERROR
023172 000240      NOP                               ;RETURN HERE IF ERROR
023174 104000      EMT                               ;ERROR # DEFINED BY PUT SUBROUTINE
023176 000137 023310  JMP    25$                      ;GO TO 25$ IF ERROR
1618 023202
1619
1620 023202 004737 042774      20$:      ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
      JSR    PC,GETSTS      ;GO TO GETSTS SUBROUTINE

```

```

1621
1622 023206 004737 043672      ;WAIT FOR COMMAND TO COMPLETE
      JSR    PC,TIMOUT      ;GO TO TIMEOUT SUBROUTINE
1623
1624      ;GO READ STATUS FOR READ OPERATION
1625 023212 004737 043060      JSR    PC,GET      ;GO READ REGISTER(S) WITH GET SUBROUTINE
      023216 000404      BR    21$      ;GO TO 21$ IF NO ERROR
      023220 000240      NOP      ;RETURN HERE IF ERROR
      023222 104000      EMT      ;ERROR # DEFINED BY GET SUBROUTINE
      023224 000137 023310      JMP    25$      ;GO TO 25$ IF ERROR
1626 023230      21$:
1627
1628      ;CHECK FOR ERRORS DURING READ OPERATION
1629 023230 004737 044056      JSR    PC,PRIERR   ;GO CHECK FOR PRIMARY ERRORS
      023234 000405      BR    22$      ;GO TO 22$ IF NO ERROR
      023236 000240      NOP      ;RETURN HERE IF ERROR
      023240 104000      EMT      ;ERROR # DEFINED BY PRIERR SUBROUTINE
      023242 004736      JSR    PC,@(SP)+  ;GO BACK FOR MORE ERROR CHECKS
      023244 000137 023310      JMP    25$      ;GO TO 25$ IF ERROR
1630 023250      22$:
1631 023250 004737 056572      JSR    PC,DTASTS   ;GO VERIFY RESULTS OF DATA TRANSFER
      023254 000405      BR    23$      ;GO TO 23$ IF NO ERROR
      023256 000240      NOP      ;RETURN HERE IF ERROR
      023260 104000      EMT      ;ERROR # DEFINED BY DTASTS SUBROUTINE
      023262 004736      JSR    PC,@(SP)+  ;GO BACK FOR MORE ERROR CHECKS
      023264 000137 023310      JMP    25$      ;GO TO 25$ IF ERROR
1632 023270      23$:
1633 023270 004737 044710      JSR    PC,SECERR   ;GO CHECK FOR SECONDARY ERRORS
      023274 000405      BR    24$      ;GO TO 24$ IF NO ERROR
      023276 000240      NOP      ;RETURN HERE IF ERROR
      023300 104000      EMT      ;ERROR # DEFINED BY SECERR SUBROUTINE
      023302 004736      JSR    PC,@(SP)+  ;GO BACK FOR MORE ERROR CHECKS
      023304 000137 023310      JMP    25$      ;GO TO 25$ IF ERROR
1634 023310      24$:
1635
1636 023310      25$:
1637
1638      ;*****
      ;*TEST 14      WRITE, READ W/ HCE ERROR
      ;*****
      TST14:
      023310 000004      SCOPE      ;SCOPE CALL
      023312 000240      NOP      ;START OF TEST
      023314 012706 001100      MOV    #STACK,SP  ;INITIALIZE STACK POINTER
      023320 013700 001276      MOV    $BASE,R0    ;R0 = UNIBUS ADDRESS
      023324 013701 001466      MOV    TSTQUE,R1   ;(R1) = DEVICE BEING TESTED
      023330 012737 000014 001226      MOV    #14,$TESTN ;SET TEST NUMBER IN APT MAIL BOX
1639
1640      ;*****
1641      ;LOOP #1      FORMAT,WRITE,READ
1642
1643 023336 012704 000000      MOV    #0,R4      ;R4 = 1ST HEADER WORD
1644 023342 012703 000001      1$:      MOV    #1,R3      ;R3 = HCE BIT
1645 023346
1646
1647      ;PREPARE THE DEVICE FOR FORMAT OPERATION
1648 023346 004737 037316      JSR    PC,TSTPRP  ;PREPARE DEVICE FOR TEST
  
```

```

023352 154130 .WORD 154130 ;TASK DESCRIPTOR AS FOLLOWS:
;SELECT DEVICE & VERIFY DEVICE AVAILABLE
;CLEAR CONTROLLER & SELECT DEVICE
;VERIFY CONTROLLER CLEAR OPERATION
;PACK ACKNOWLEDGE IF VOLUME NOT VALID
;VERIFY PACK ACKNOWLEDGE
;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
;VERIFY RECALIBRATION
;GO TO 3$ IF NO ERROR
;RETURN HERE IF ERROR
;ERROR # DEFINED BY 'STPRP' SUBROUTINE
;GO TO 46$ IF ERROR

023354 000404 BR 3$
023356 000240 NOP
023360 104000 EMT
023362 000137 025156 JMP 46$

1649
1650 ;LOAD PARAMETERS AND GENERATE DATA BUFFER
1651 023366 3$:
1652 023366 012737 000000 001446 MOV #0,RMDCO ;CYLINDER = 0
1653 023374 012737 000000 001420 MOV #0,RMDAO ;TRACK = 0, SECTOR = 0
1654 023402 012737 106436 001416 MOV #BUFONE,RMBAO ;BUS ADDRESS
1655 023410 012737 177376 001414 MOV #-258.,RMWCO ;2 + 256. WORDS (2'S COMP)
1656 023416 012737 010000 001444 MOV #FMT16,RMOFO ;16 BIT FORMAT
1657 023424 012737 000063 001412 MOV #WH!GO,RMCS10 ;WRITE HEADER AND DATA COMMAND
1658
1659 ;VERIFY THAT SECTOR IS NOT BAD
023432 004737 040242 JSR PC,BADSCT ;CALL BAD SECTOR MODULE
023436 000405 BR 4$ ;GO TO 4$ IF NO ERROR
023440 104401 070426 TYPE ,SCTMSG ;TYPE BAD SECTOR MESSAGE
023444 104000 EMT ;ERROR # DEFINED BY BADSCT SUBROUTINE
023446 000137 025004 JMP 42$ ;GO TO 42$ IF ERROR

1660 023452 4$:
1661 023452 012737 072060 001174 MOV #ZEROS,$TMP0 ;STARTING ADDRESS OF PATTERN
1662 023460 012737 000001 001176 MOV #1,$TMP1 ;RANGE OF PATTERN
1663 023466 004737 042174 JSR PC,GENBUF ;GO GENERATE BUFFER FOR FORMAT
1664
1665 ;CHANGE HEADER WORD TO FORCE HCE DURING WRITE & READ
1666 023472 030364 106436 BIT R3,BUFONE(R4) ;SET OR RESET FOR HCE??
1667 023476 001403 BEQ 5$
1668 023500 040364 106436 BIC R3,BUFONE(R4) ;RESET BIT FOR HCE
1669 023504 000402 BR 6$
1670 023506 050364 106436 5$: BIS R3,BUFONE(R4) ;SET FOR HCE
1671
1672 ;LOAD PUT REGISTER INDEX TABLE FOR FORMAT OPERATION
1673 023512 6$:
1674 023512 MOV #PUTINX,R2 ;R2 - BYTE ENTRY POSITION
1675 023516 MOVB #RMDC,(R2)+
1676 023522 MOVB #RMDA,(R2)+
1677 023526 MOVB #RMBA,(R2)+
1678 023532 MOVB #RMWC,(R2)+
1679 023536 MOVB #RMOF,(R2)+
1680 023542 MOVB #RMCS1,(R2)+
1681 023546 MOVB #200,(R2) ;TERMINATE TABLE
1682 023552 7$:
1683 023552 004737 043330 JSR PC,PUT ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
023556 000404 BR 8$ ;GO TO 8$ IF NO ERROR
023560 000240 NOP ;RETURN HERE IF ERROR
023562 104000 EMT ;ERROR # DEFINED BY PUT SUBROUTINE
023564 000137 025004 JMP 42$ ;GO TO 42$ IF ERROR
1684 023570 8$:
  
```

```

1685
1686 023570 004737 042774 ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
      JSR PC,GETSTS ;GO TO GETSTS SUBROUTINE
1687
1688 ;WAIT FOR COMMAND TO COMPLETE
1688 023574 004737 043672 JSR PC,TIMOUT ;GO TO TIMOUT SUBROUTINE
1689
1690 ;GO READ STATUS FOR FORMAT OPERATION
1691 023600 004737 043060 JSR PC,GET ;GO READ REGISTER(S) WITH GET SUBROUTINE
      023604 000404 BR 9$ ;GO TO 9$ IF NO ERROR
      023606 000240 NOP ;RETURN HERE IF ERROR
      023610 104000 EMT ;ERROR # DEFINED BY GET SUBROUTINE
      023612 000137 025004 JMP 42$ ;GO TO 42$ IF ERROR
1692 023616 9$:
1693
1694 ;VERIFY NO ERRORS DURING FORMAT
1695 023616 004737 056572 JSR PC,DTASTS ;GO VERIFY RESULTS OF DATA TRANSFER
      023622 000405 BR 10$ ;GO TO 10$ IF NO ERROR
      023624 000240 NOP ;RETURN HERE IF ERROR
      023626 104000 EMT ;ERROR # DEFINED BY DTASTS SUBROUTINE
      023630 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
      023632 000137 025004 JMP 42$ ;GO TO 42$ IF ERROR
1696 023636 10$:
1697
1698 ;MOVE LOOP ADDRESSES TO NEXT OPERATION
1699 023636 012737 023646 00124 MOV #11$, $LPERR
1700 023644 000410 BR 12$ ;SKIP TO WRITE OPERATION
1701
1702 ;*****
1703 ;LOOP #2 WRITE,READ
1704
1705 023646 11$:
1706
1707 ;PREPARE DEVICE FOR WRITE OPERATION
1708 023646 004737 037316 JSR PC,TSTPRP ;PREPARE DEVICE FOR TEST
      023652 154130 .WORD 154130 ;TASK DESCRIPTOR AS FOLLOWS:
      ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
      ;CLEAR CONTROLLER & SELECT DEVICE
      ;VERIFY CONTROLLER CLEAR OPERATION
      ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
      ;VERIFY PACK ACKNOWLEDGE
      ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
      ;VERIFY RECALIBRATION
      023654 000404 BR 12$ ;GO TO 12$ IF NO ERROR
      023656 000240 NOP ;RETURN HERE IF ERROR
      023660 104000 EMT ;ERROR # DEFINED BY TSTPRP SUBROUTINE
      023662 000137 025004 JMP 42$ ;GO TO 42$ IF ERROR
1709 023666 12$:
1710
1711 ;WRITE DATA TO THE DRIVE
1712 023666 13$:
1713 023666 012737 106442 001416 MOV #BUFONE+4,RMBAD ;CHANGE BUS ADDRESS
1714 023674 012737 177400 001414 MOV #-256.,RMWCO ;CHANGE WORD COUNT
1715 023702 012737 000061 001412 MOV #WD.GO,RMCS10 ;WRITE DATA COMMAND
1716 023710 012702 001553 MOV #PUTINX,R2 ;LOAD PUT REGISTER INDEX TABLE
1717 023714 112722 000006 MOVB #RMDA,(R2)+
1718 023720 112722 000034 MOVB #RMDC,(R2)+

```

```

1719 023724 112722 000032      MOVB  #RMOF,(R2)+
1720 023730 112722 000004      MOVB  #RMBA,(R2)+
1721 023734 112722 000002      MOVB  #RMWC,(R2)+
1722 023740 112722 000000      MOVB  #RMCS1,(R2)+
1723 023744 112722 000200      MOVB  #200,(R2)+      ;TERMINATE TABLE
1724
1725 023750 004737 043330      JSR   PC,PUT          ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      023754 000404      BR    14$            ;GO TO 14$ IF NO ERROR
      023756 000240      NOP                    ;RETURN HERE IF ERROR
      023760 104000      EMT                    ;ERROR # DEFINED BY PUT SUBROUTINE
      023762 000137 025004      JMP   42$            ;GO TO 42$ IF ERROR
1726 023766      14$:
1727
1728      ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
      JSR   PC,GETSTS    ;GO TO GETSTS SUBROUTINE
1729
1730      ;WAIT FOR COMMAND TO COMPLETE
      JSR   PC,TIMOUT    ;GO TO TIMEOUT SUBROUTINE
1731
1732      ;GO READ STATUS FOR WRITE COMMAND
1733 023776 004737 043060      JSR   PC,GET          ;GO READ REGISTER(S) WITH GET SUBROUTINE
      024002 000404      BR    15$            ;GO TO 15$ IF NO ERROR
      024004 000240      NOP                    ;RETURN HERE IF ERROR
      024006 104000      EMT                    ;ERROR # DEFINED BY GET SUBROUTINE
      024010 000137 025004      JMP   42$            ;GO TO 42$ IF ERROR
1734 024014      15$:
1735
1736      ;CHECK FOR ERRORS DURING WRITE OPERATION
1737 024014 004737 044056      JSR   PC,PRIERR      ;GO CHECK FOR PRIMARY ERRORS
      024020 000405      BR    16$            ;GO TO 16$ IF NO ERROR
      024022 000240      NOP                    ;RETURN HERE IF ERROR
      024024 104000      EMT                    ;ERROR # DEFINED BY PRIERR SUBROUTINE
      024026 004736      JSR   PC,@(SP)+      ;GO BACK FOR MORE ERROR CHECKS
      024030 000137 025004      JMP   42$            ;GO TO 42$ IF ERROR
1738
1739      ;DECODE THE TYPE OF ERROR PRODUCED BY THE BIT POSITION OF R3
1740 024034      16$:
1741 024034 005704      TST   R4              ;IS THIS THE FIRST HEADER WORD ?
1742 024036 001006      BNE   17$            ;NO !!
1743
1744 024040 032703 010000      BIT   #FMT16,R3      ;SHOULD FER BE SET ?
1745 024044 001037      BNE   20$            ;YES !
1746 024046 032703 140000      BIT   #MSE.USE,R3    ;SHOULD BSE BE SET ?
1747 024052 001061      BNE   22$            ;YES !
1748
1749      ;VERIFY THAT A HEADER COMPARE ERROR WAS DETECTED
1750 024054      17$:
1751 024054 032737 000200 001352      BIT   #HCE,RMER11    ;WAS HCE DETECTED ??
1752 024062 001102      BNE   24$            ;YES !!
1753
1754 024064 004737 056572      JSR   PC,DTASTS      ;GO VERIFY RESULTS OF DATA TRANSFER
      024070 000405      BR    18$            ;GO TO 18$ IF NO ERROR
      024072 000240      NOP                    ;RETURN HERE IF ERROR
      024074 104000      EMT                    ;ERROR # DEFINED BY DTASTS SUBROUTINE
      024076 004736      JSR   PC,@(SP)+      ;GO BACK FOR MORE ERROR CHECKS
      024100 000137 025004      JMP   42$            ;GO TO 42$ IF ERROR
1755 024104      18$:

```

WRITE, READ W/ HCE ERROR

```

1756 024104 013737 001352 001142      MOV      RMER1I,$BDDAT      ;RECEIVED STATUS
1757 024112 012737 000200 001140      MOV      #HCE,$GDDAT      ;EXPECTED STATUS
1758 024120 010437 001174              MOV      R4,$TMP0         ;R4 = HEADER WORD NUMBER AND
1759 024124 001002              BNE      19$              ;ADJUST NUMBER.
1760 024126 005237 001174              INC      $TMP0
1761 024132 010337 001176      19$:    MOV      R3,$TMP1         ;R3 = BIT POSITION
1762 024136 010344              EMT      344
1763 024140 000137 025004              JMP      42$
1764
1765      ;VERIFY THAT A FORMAT ERROR WAS DETECTED
1766 024144      20$:
1767 024144 032737 000020 001352      BIT      #FER,RMER1I      ;WAS FER DETECTED ??
1768 024152 001046              BNE      24$              ;YES !!
1769
1770 024154 004737 056572              JSR      PC,DTASTS        ;GO VERIFY RESULTS OF DATA TRANSFER
024160 000405              BR       21$              ;GO TO 21$ IF NO ERROR
024162 000240              NOP                      ;RETURN HERE IF ERROR
024164 010400              EMT                      ;ERROR # DEFINED BY DTASTS SUBROUTINE
024166 004736              JSR      PC,@(SP)+        ;GO BACK FOR MORE ERROR CHECKS
024170 000137 025004              JMP      42$              ;GO TO 42$ IF ERROR
1771 024174      21$:
1772 024174 012737 000020 001140      MOV      #FER,$GDDAT      ;EXPECTED STATUS
1773 024202 013737 001352 001142      MOV      RMER1I,$BDDAT    ;RECEIVED STATUS
1774 024210 010434              EMT      343
1775 024212 000137 025004              JMP      42$
1776
1777      ;VERIFY THAT A BAD SECTOR ERROR WAS DETECTED
1778 024216      22$:
1779 024216 032737 100000 001400      BIT      #BSE,RMER2I      ;WAS BSE DETECTED ??
1780 024224 001021              BNE      24$              ;YES !!
1781
1782 024226 004737 056572              JSR      PC,DTASTS        ;GO VERIFY RESULTS OF DATA TRANSFER
024232 000405              BR       23$              ;GO TO 23$ IF NO ERROR
024234 000240              NOP                      ;RETURN HERE IF ERROR
024236 010400              EMT                      ;ERROR # DEFINED BY DTASTS SUBROUTINE
024240 004736              JSR      PC,@(SP)+        ;GO BACK FOR MORE ERROR CHECKS
024242 000137 025004              JMP      42$              ;GO TO 42$ IF ERROR
1783 024246      23$:
1784 024246 013737 001400 001142      MOV      RMER2I,$BDDAT    ;RECEIVED STATUS
1785 024254 012737 100000 001140      MOV      #BSE,$GDDAT      ;EXPECTED STATUS
1786 024262 010435              EMT      345
1787 024264 000137 025004              JMP      42$
1788
1789      ;CHECK FOR OTHER ERRORS
1790 024270      24$:
1791 024270 004737 044710              JSR      PC,SECERR        ;GO CHECK FOR SECONDARY ERRORS
024274 000405              BR       25$              ;GO TO 25$ IF NO ERROR
024276 000240              NOP                      ;RETURN HERE IF ERROR
024300 010400              EMT                      ;ERROR # DEFINED BY SECERR SUBROUTINE
024302 004736              JSR      PC,@(SP)+        ;GO BACK FOR MORE ERROR CHECKS
024304 000137 025004              JMP      42$              ;GO TO 42$ IF ERROR
1792 024310      25$:
1793
1794      ;CHANGE LOOP ADDRESSES
1795 024310 012737 024316 001124      MOV      #26$,$LPERR
1796
1797      ;*****

```

```

1798          ;LOOP #3          READ
1799
1800 024316    26$:
1801
1802          ;PREPARE DEVICE FOR READ OPERATION
1803 024316 004737 037316      JSR PC,TSTPRP      ;PREPARE DEVICE FOR TEST
      024322 154130          .WORD 154130      ;TASK DESCRIPTOR AS FOLLOWS:
                                          ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
                                          ;CLEAR CONTROLLER & SELECT DEVICE
                                          ;VERIFY CONTROLLER CLEAR OPERATION
                                          ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
                                          ;VERIFY PACK ACKNOWLEDGE
                                          ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
                                          ;VERIFY RECALIBRATION
                                          ;GO TO 27$ IF NO ERROR
                                          ;RETURN HERE IF ERROR
                                          ;ERROR # DEFINED BY TSTPRP SUBROUTINE
                                          ;GO TO 42$ IF ERROR
      024324 000404          BR 27$
      024326 000240          NOP
      024330 104000          EMT
      024332 000137 025004    JMP 42$
1804 024336    27$:
1805
1806          ;READ DATA FROM DEVICE
1807 024336    28$:
1808 024336 012737 107446 001416    MOV #BUFTWO+4,RMBA0 ;CHANGE BUS ADDRESS
1809 024344 012737 177400 001414    MOV #-256.,RMWCO   ;CHANGE WORD COUNT
1810 024352 012737 000071 001412    MOV #RD!GO,RMCST0 ;READ DATA COMMAND
1811 024360 012702 001553          MOV #PUTINX,R2     ;LOAD PUT REGISTER INDEX TABLE
1812 024364 112722 000006          MOVB #RMDA,(R2)+
1813 024370 112722 000032          MOVB #RMOF,(R2)+
1814 024374 112722 000034          MOVB #RMDC,(R2)+
1815 024400 112722 000004          MOVB #RMB A,(R2)+
1816 024404 112722 000002          MOVB #RMWC,(R2)+
1817 024410 112722 000000          MOVB #RMCS1,(R2)+
1818 024414 112712 000200          MOVB #200,(R2)
1819
1820 024420 004737 043330          JSR PC,PUT        ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      024424 000404          BR 29$           ;GO TO 29$ IF NO ERROR
      024426 000240          NOP             ;RETURN HERE IF ERROR
      024430 104000          EMT
      024432 000137 025004    JMP 42$           ;ERROR # DEFINED BY PUT SUBROUTINE
      ;GO TO 42$ IF ERROR
1821 024436    29$:
1822
1823          ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
      024436 004737 042774      JSR PC,GETSTS     ;GO TO GETSTS SUBROUTINE
1824
1825          ;WAIT FOR COMMAND TO COMPLETE
      024442 004737 043672      JSR PC,TIMCUT     ;GO TO TIMEOUT SUBROUTINE
1826
1827          ;GO READ STATUS FOR READ OPERATION
1828 024446 004737 043060          JSR PC,GET        ;GO READ REGISTER(S) WITH GET SUBROUTINE
      024452 000404          BR 30$           ;GO TO 30$ IF NO ERROR
      024454 000240          NOP             ;RETURN HERE IF ERROR
      024456 104000          EMT
      024460 000137 025004    JMP 42$           ;ERROR # DEFINED BY GET SUBROUTINE
      ;GO TO 42$ IF ERROR
1829 024464    30$:
1830
1831          ;CHECK FOR ERRORS DURING READ OPERATION
1832 024464 004737 044056          JSR PC,PRIERR    ;GO CHECK FOR PRIMARY ERRORS

```


14 WRITE, READ W/ HCE ERROR

```

024470 000405 BR 31$ ;GO TO 31$ IF NO ERROR
024472 000240 NOP ;RETURN HERE IF ERROR
024474 104000 EMT ;ERROR # DEFINED BY PRIERR SUBROUTINE
024476 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
024500 000137 025004 JMP 42$ ;GO TO 42$ IF ERROR
1833 024504 31$:
1834 024504 005704 TST R4 ;IS THIS THE FIRST HEADER WORD ?
1835 024506 001006 BNE 32$ ;NO !!
1836
1837 024510 032703 010000 BIT #FMT16,R3 ;SHOULD FER BE SET ?
1838 024514 001037 BNE 35$ ;YES !!
1839 024516 032703 140000 BIT #MSE.USE,R3 ;SHOULD BSE BE SET ?
1840 024522 001061 BNE 37$ ;YES !!
1841
1842 ;VERIFY THAT A HEADER COMPARE ERROR WAS DETECTED
1843 024524 32$:
1844 024524 032737 000200 001352 BIT #HCE,RMER11 ;WAS HCE DETECTED ??
1845 024532 001102 BNE 39$ ;YES !!
1846
1847 024534 004737 056572 JSR PC,DTASTS ;GO VERIFY RESULTS OF DATA TRANSFER
024540 000405 BR 33$ ;GO TO 33$ IF NO ERROR
024542 000240 NOP ;RETURN HERE IF ERROR
024544 104000 EMT ;ERROR # DEFINED BY DTASTS SUBROUTINE
024546 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
024550 000137 025004 JMP 42$ ;GO TO 42$ IF ERROR
1848 024554 33$:
1849 024554 013737 001352 001142 MOV RMER11,$BDDAT ;RECEIVED STATUS
1850 024562 012737 000200 001140 MOV #HCE,$GDDAT ;EXPECTED STATUS
1851 024570 010437 001174 MOV R4,$TMP0 ;R4 = HEADER WORD NUMBER AND
1852 024574 001002 BNE 34$ ;ADJUST NUMBER.
1853 024576 025237 001174 INC $TMP0
1854 024602 010337 001176 34$: MOV R-, $TMP1 ;R3 = BIT POSITION
1855 024606 104344 EMT 344
1856 024610 000137 025004 JMP 42$
1857
1858 ;VERIFY THAT A FORMAT ERROR WAS DETECTED
1859 024614 35$:
1860 024614 032737 000020 001352 BIT #FER,RMER11 ;WAS FER DETECTED ??
1861 024622 001046 BNE 39$ ;YES !!
1862
1863 024624 004737 056572 JSR PC,DTASTS ;GO VERIFY RESULTS OF DATA TRANSFER
024630 000405 BR 36$ ;GO TO 36$ IF NO ERROR
024632 000240 NOP ;RETURN HERE IF ERROR
024634 104000 EMT ;ERROR # DEFINED BY DTASTS SUBROUTINE
024636 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
024640 000137 025004 JMP 42$ ;GO TO 42$ IF ERROR
1864 024644 36$:
1865 024644 012737 000020 00 MOV #FER,$GDDAT ;EXPECTED STATUS
1866 024652 013737 001352 001142 MOV RMER11,$BDDAT ;RECEIVED STATUS
1867 024660 104343 EMT 343
1868 024662 000137 025004 JMP 42$
1869
1870 ;VERIFY THAT A BAD SECTOR ERROR WAS DETECTED
1871 024666 37$:
1872 024666 032737 100000 001400 BIT #BSE,RMER21 ;WAS BSE DETECTED ??
1873 024674 001021 BNE 39$ ;YES !!
1874

```

```

1875 024676 004737 056572      JSR    PC,DTASTS      ;GO VERIFY RESULTS OF DATA TRANSFER
      024702 000405      BR     38$           ;GO TO 38$ IF NO ERROR
      024704 000240      NOP                    ;RETURN HERE IF ERROR
      024706 104000      EMT                    ;ERROR # DEFINED BY DTASTS SUBROUTINE
      024710 004736      JSR    PC,@(SP)+     ;GO BACK FOR MORE ERROR CHECKS
      024712 000137 025004      JMP    42$           ;GO TO 42$ IF ERROR

1876 024716      38$:
1877 024716 013737 001400 001142      MOV    RMER2I,$BDDAT ;RECEIVED STATUS
1878 024724 012737 100000 001140      MOV    #BSE,$GDDAT  ;EXPECTED STAIUS
1879 024732 104345      EMT    345
1880 024734 000137 000350      JMP    350

1881
1882      ;CHECK FOR OTHER ERRORS
1883      39$:
1884 024740 004737 044710      JSR    PC,SECERR     ;GO CHECK FOR SECONDARY ERRORS
      024744 000405      BR     40$           ;GO TO 40$ IF NO ERROR
      024746 000240      NOP                    ;RETURN HERE IF ERROR
      024750 104000      EMT                    ;ERROR # DEFINED BY SECERR SUBROUTINE
      024752 004736      JSR    PC,@(SP)+     ;GO BACK FOR MORE ERROR CHECKS
      024754 000137 025004      JMP    42$           ;GO TO 42$ IF ERROR

1885 024760      40$:
1886 024760 006303      ASL    R3             ;SHIFT TO NEXT BIT
1887 024762 001006      BNE    41$           ;REPEAT IF NOT DONE

1888
1889 024764 005704      TST    R4             ;SECOND HEADER WORD DONE??
1890 024766 001006      BNE    42$           ;YES!!
1891 024770 012704 000002      MOV    #2,R4         ;SETUP FOR 2ND HEADER WORD
1892 024774 012703 000001      MOV    #1,R3         ;SETUP FOR HCE
1893 025000      41$:
1894 025000 000137 023346      JMP    2$
1895 025004      42$:
1896 025004 000464      BR     46$           ;EXIT IF ERROR
1897
1898      ;*****
1899      ;*REFORMAT SECTOR THAT WAS WRITTEN WITH BAD HEADER
1900      ;*****
1900 025006      43$:
1901 025006 012737 177776 001414      MOV    #-2,RMWCO     ;ONLY TWO HEAD WORDS
1902 025014 012737 010000 001444      MOV    #FMT16,RMOFO ;ALWAYS IN 16 BITS MODE
1903 025022 012737 106436 001416      MOV    #BUFONE,RMBAO ;BUFFER ADDRESS,REFORMAT THE SECTOR
1904 025030 012737 000062 001412      MOV    #WH,RMCS10   ;WRITE HEAD AND DATA COMMAND
1905 025036 004737 042174      JSR    PC,GENBUF     ;SET UP THE BUFFER
1906
1907 025042 004737 037316      JSR    PC,TSTPRP     ;PREPARE DEVICE FOR TEST
      025046 054130      .WORD 054130        ;TASK DESCRIPTOR AS FOLLOWS:
      ;CLEAR CONTROLLER & SELECT DEVICE
      ;VERIFY CONTROLLER CLEAR OPERATION
      ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
      ;VERIFY PACK ACKNOWLEDGE
      ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
      ;VERIFY RECALIBRATION
      025050 000404      BR     44$           ;GO TO 44$ IF NO ERROR
      025052 000240      NOP                    ;RETURN HERE IF ERROR
      025054 104000      EMT                    ;ERROR # DEFINED BY TSTPRP SUBROUTINE
      025056 000137 025062      JMP    44$           ;GO TO 44$ IF ERROR

1908 025062      44$:
1909 025062 012737 000063 001412      MOV    #WH!GO,RMCS10 ;FORMAT THE SECTOR
1910 025070 012702 001553      MOV    #PUTINX,R2   ;SET UP THE REGS
    
```

T14 WRITE, READ W/ HCE ERROR

```

1911 025074 112722 000006      MOVB  #RMDA,(R2)+
1912 025100 112722 000032      MOVB  #RMOF,(R2)+
1913 025104 112722 000034      MOVB  #RMDC,(R2)+
1914 025110 112722 000004      MOVB  #RMBA,(R2)+
1915 025114 112722 000002      MOVB  #RMWC,(R2)+
1916 025120 112722 000000      MOVB  #RMCS1,(R2)+
1917 025124 112722 000200      MOVB  #200,(R2)+
1918 025130 004737 043330      JSR   PC,PUT          ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      025134 000404      BR    45$            ;GO TO 45$ IF NO ERROR
      025136 000240      NOP                    ;RETURN HERE IF ERROR
      025140 104000      EMT                    ;ERROR # DEFINED BY PUT SUBROUTINE
      025142 000137 025156      JMP   46$            ;GO TO 46$ IF ERROR
1919 025146 000240      45$: NOP
1920 025150 004737 043672      JSR   PC,TIMOUT      ;WAIT FOR FINISH
1921 025154 000240      NOP
1922 025156      46$:
1923
1924

```

```

:*****
:*TEST 15      WRITE, READ W/ HCI
:*****
TST15:

```

```

025156      SCOPE          ;SCOPE CALL
025156 000004      NOP          ;START OF TEST
025160 000240      MOV   #STACK,SP ;INITIALIZE STACK POINTER
025162 012706 001100      MOV   $BASE,R0  ;R0 = UNIBUS ADDRESS
025166 013700 001276      MOV   TSTQUE,R1 ;(R1) = DEVICE BEING TESTED
025172 013701 001466      MOV   #15,$TESTN ;:SET TEST NUMBER IN APT MAIL BOX
025176 012737 000015 001226      MOV

```

```

1925
1926
1927
1928
:*****
:LOOP #1      FORMAT,WRITE,READ

```

```

1929 025204 012704 000000      1$: MOV   #0,R4      ;HEADER WORD
1930 025210 012703 000001      MOV   #1,R3      ;HCE BIT
1931 025214
1932
1933
1934 025214 004737 037316      ;PREPARE THE DEVICE FOR FORMAT OPERATION
      025220 154130      JSR   PC,TSTPRP   ;PREPARE DEVICE FOR TEST
      .WORD 154130      .WORD 154130      ;TASK DESCRIPTOR AS FOLLOWS:
      ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
      ;CLEAR CONTROLLER & SELECT DEVICE
      ;VERIFY CONTROLLER CLEAR OPERATION
      ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
      ;VERIFY PACK ACKNOWLEDGE
      ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
      ;VERIFY RECALIBRATION
      025222 000404      BR    3$          ;GO TO 3$ IF NO ERROR
      025224 000240      NOP                    ;RETURN HERE IF ERROR
      025226 104000      EMT                    ;ERROR # DEFINED BY TSTPRP SUBROUTINE
      025230 000137 026562      JMP   41$            ;GO TO 41$ IF ERROR

```

```

1935
1936
1937 025234
1938 025234 012737 000000 001446      3$: MOV   #0,RMDCO    ;CYLINDER = 0
1939 025242 012737 000000 001420      MOV   #0,RMDAO    ;TRACK = 0, SECTOR - 0
1940 025250 012737 106436 001416      MOV   #BUFONE,RMBAO ;BUS ADDRESS
1941 025256 012737 177376 001414      MOV   #-258.,RMWCO ;2 + 256. WORDS (2' COMP)
1942 025264 012737 010000 001444      MOV   #FMT16,RMOFO ;16 BIT FORMAT

```

```

1943 025272 012737 000063 001412      MOV      #WH!GO, RMCS10 ;WRITE HEADER AND DATA COMMAND
1944
1945      ;VERIFY THAT SECTOR IS NOT BAD
      025300 004737 040242      JSR      PC, BADSCT    ;CALL BAD SECTOR MODULE
      025304 000405                BR       4$           ;GO TO 4$ IF NO ERROR
      025306 104401 070426      TYPE    ,SCTMSG      ;TYPE BAD SECTOR MESSAGE
      025312 104000                EMT     ;ERROR # DEFINED BY BADSCT SUBROUTINE
      025314 000137 026410      JMP     37$          ;GO TO 37$ IF ERROR
1946 025320      4$:
1947 025320 012737 072016 001174      MOV      #ONES, $TMP0 ;STARTING ADDRESS OF PATTERN
1948 025326 012737 000001 001176      MOV      #1, $TMP1   ;RANGE OF PATTERN
1949 025334 004737 042174      JSR      PC, GENBUF  ;GO GENERATE BUFFER FOR FORMAT
1950
1951      ;CHANGE HEADER WORD TO FORCE ERROR DURING WRITE
1952 025340 030364 106436      BIT     R3, BUFONE(R4) ;SET OR RESET BIT??
1953 025344 001403                BEQ     5$           ;
1954 025346 040364 106436      BIC     R3, BUFONE(R4) ;RESET BIT
1955 025352 000402                BR      6$           ;
1956 025354 050364 106436      5$:     BIS     R3, BUFONE(R4) ;SET BIT
1957
1958      ;LOAD PUT REGISTER INDEX TABLE FOR FORMAT OPERATIION
1959 025360      6$:
1960 025360 012702 001553      MOV      #PUTINX, R2 ;R2 = BYTE ENTRY POSITION
1961 025364 112722 000034      MOVB    #RMDC, (R2)+
1962 025370 112722 000006      MOVB    #RMDA, (R2)+
1963 025374 112722 000004      MOVB    #RMBA, (R2)+
1964 025400 112722 000002      MOVB    #RMWC, (R2)+
1965 025404 112722 000032      MOVB    #RMOF, (R2)+
1966 025410 112722 000000      MOVB    #RMCS1, (R2)+
1967 025414 112712 000200      MOVB    #200, (R2) ;TERMINATE TABLE
1968 025420      7$:
1969
1970      ;FORMAT THE DRIVE
1971 025420 004737 043330      JSR      PC, PUT     ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      025424 000404                BR      8$           ;GO TO 8$ IF NO ERROR
      025426 000240                NOP     ;RETURN HERE IF ERROR
      025430 104000                EMT     ;ERROR # DEFINED BY PUT SUBROUTINE
      025432 000137 026410      JMP     37$          ;GO TO 37$ IF ERROR
1972 025436      8$:
1973
1974      ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
      025436 004737 042774      JSR      PC, GETSTS ;GO TO GETSTS SUBROUTINE
1975
1976      ;WAIT FOR COMMAND TO COMPLETE
      025442 004737 043672      JSR      PC, TIMEOUT ;GO TO TIMEOUT SUBROUTINE
1977
1978      ;GO READ STATUS FOR FORMAT OPERATION
1979 025446 004737 043060      JSR      PC, GET     ;GO READ REGISTER(S) WITH GET SUBROUTINE
      025452 000404                BR      9$           ;GO TO 9$ IF NO ERROR
      025454 000240                NOP     ;RETURN HERE IF ERROR
      025456 104000                EMT     ;ERROR # DEFINED BY GET SUBROUTINE
      025460 000137 026410      JMP     37$          ;GO TO 37$ IF ERROR
1980 025464      9$:
1981
1982      ;VERIFY NO ERRORS DURING FORMAT
1983 025464 004737 056572      JSR      PC, DASTS  ;GO VERIFY RESULTS OF DATA TRANSFER
      025470 000405                BR      10$         ;GO TO 10$ IF NO ERROR
  
```

```

025472 000240      NOP      ;RETURN HERE IF ERROR
025474 104000      EMT      ;ERROR # DEFINED BY DTASTS SUBROUTINE
025476 004736      JSR      PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
025500 000137 026410 JMP      37$      ;GO TO 37$ IF ERROR
1984 025504      10$:
1985
1986
1987 025504 012737 025514 001124 ;MOVE LOOP ADDRESSES TO NEXT OPERATION
1988 025512 000410      MOV      #11$, $LPERR
1989
1990
1991
1992
1993 025514      BR      12$      ;SKIP TO WRITE OPERATION
1994
1995
1996 025514 004737 037316 ;PREPARE DEVICE FOR WRITE OPERATION
025520 154130      JSR      PC,TSTPRP ;PREPARE DEVICE FOR TEST
                                .WORD 154130 ;TASK DESCRIPTOR AS FOLLOWS:
                                ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
                                ;CLEAR CONTROLLER & SELECT DEVICE
                                ;VERIFY CONTROLLER CLEAR OPERATION
                                ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
                                ;VERIFY PACK ACKNOWLEDGE
                                ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
                                ;VERIFY RECALIBRATION
                                ;GO TO 12$ IF NO ERROR
025522 000404      BR      12$      ;RETURN HERE IF ERROR
025524 000240      NOP      ;ERROR # DEFINED BY TSTPRP SUBROUTINE
025526 104000      EMT      ;GO TO 37$ IF ERROR
025530 000137 026410 JMP      37$
1997 025534      12$:
1998
1999
2000 025534      ;WRITE DATA TO THE DRIVE
2001 025534 012737 012000 001444 13$:
2002 025542 012737 000061 001412      MOV      #FMT16!HCI,RMOFO ;INHIBIT HEADER COMPARE
2003 025550 012737 106442 001416      MOV      #WD!GO,RMCS10 ;WRITE DATA COMMAND
2004 025556 012702 001553      MOV      #BUFONE+4,RMBA0 ;LOAD STARTING BUFFER ADDRESS
2005 025562 112722 000006      MOV      #PUTINX,R2 ;LOAD PUT REGISTER INDEX TABLE
2006 025566 112722 000034      MOV      #RMDA,(R2)+
2007 025572 112722 000032      MOV      #RMDC,(R2)+
2008 025576 112722 000004      MOV      #RMOF,(R2)+
2009 025602 112722 000002      MOV      #RMBA,(R2)+
2010 025606 112722 000000      MOV      #RMWC,(R2)+
2011 025612 112722 000200      MOV      #RMCS1,(R2)+
2012
2013 025616 004737 043330      MOV      #200,(R2)+ ;TERMINATE TABLE
025622 000404      JSR      PC,PUT ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
025624 000240      BR      14$      ;GO TO 14$ IF NO ERROR
025626 104000      NOP      ;RETURN HERE IF ERROR
025630 000137 026410 JMP      37$      ;ERROR # DEFINED BY PUT SUBROUTINE
                                ;GO TO 37$ IF ERROR
2014 025634      14$:
2015
2016 025634 004737 042774 ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
2017
2018 025640 004737 043672 ;WAIT FOR COMMAND TO COMPLETE
                                JSR      PC,GETSTS ;GO TO GETSTS SUBROUTINE
                                JSR      PC,TIMOUT ;GO TO TIMOUT SUBROUTINE

```

```

20*9
2020 ;GO READ STATUS FOR WRITE COMMAND
2021 025644 004737 043060 JSR PC,GET ;GO READ REGISTER(S) WITH GET SUBROUTINE
    025650 000404 BR 15$ ;GO TO 15$ IF NO ERROR
    025652 000240 NOP ;RETURN HERE IF ERROR
    025654 104000 EMT ;ERROR # DEFINED BY GET SUBROUTINE
    025656 000137 026410 JMP 37$ ;GO TO 37$ IF ERROR
2022 025662 15$:
2023
2024 ;CHECK FOR ERRORS DURING WRITE OPERATION
2025 025662 004737 044056 JSR PC,PRIERR ;GO CHECK FOR PRIMARY ERRORS
    025666 000405 BR 16$ ;GO TO 16$ IF NO ERROR
    025670 000240 NOP ;RETURN HERE IF ERROR
    025672 104000 EMT ;ERROR # DEFINED BY PRIERR SUBROUTINE
    025674 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
    025676 000137 026410 JMP 37$ ;GO TO 37$ IF ERROR
2026 025702 005037 001140 16$: CLR $GDDAT ;EXPECTED STATUS
2027
2028 025706 032737 000220 001352 BIT #HCE!FER,RMER1I ;ANY ERROR?
2029 025714 001407 BEQ 17$
2030 025716 013737 001352 001142 MOV RMER1I,$BDDAT ;RECEIVED STATUS
2031 025724 042737 177557 001142 BIC #^C<HCE!FER>,$BDDAT ;CLEAR DONT CARES
2032 025732 000412 BR 18$
2033 025734 17$:
2034 025734 013737 001400 001142 MOV RMER2I,$BDDAT ;RECEIVED STATUS
2035 025742 032737 100000 001400 BIT #BSE,RMER2I ;ANY BAD SECTOR ERROR ?
2036 025750 001406 BEQ 19$ ;NO !!
2037 025752 042737 077777 001142 BIC #^CBSE,$BDDAT ;SAVE BSE FOR ERROR
2038 025760 18$:
2039 025760 104346 EMT 346
2040 025762 000137 026410 JMP 37$
2041 025766 19$:
2042
2043 20$:
2044 025766 004737 056572 JSR PC,DTASTS ;GO VERIFY RESULTS OF DATA TRANSFER
    025772 000405 BR 21$ ;GO TO 21$ IF NO ERROR
    025774 000240 NOP ;RETURN HERE IF ERROR
    025776 104000 EMT ;ERROR # DEFINED BY DTASTS SUBROUTINE
    026000 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
    026002 000137 026410 JMP 37$ ;GO TO 37$ IF ERROR
2045 026006 21$:
2046 026006 004737 044710 JSR PC,SECERR ;GO CHECK FOR SECONDARY ERRORS
    026012 000405 BR 22$ ;GO TO 22$ IF NO ERROR
    026014 000240 NOP ;RETURN HERE IF ERROR
    026016 104000 EMT ;ERROR # DEFINED BY SECERR SUBROUTINE
    026020 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
    026022 000137 026410 JMP 37$ ;GO TO 37$ IF ERROR
2047 026026 22$:
2048
2049 ;CHANGE LOOP ADDRESSES
2050 026026 012737 026036 001124 MOV #23,$LPERR
2051 026034 000410 BR 24$
2052
2053 ;*****
2054 ;LOOP #3 READ
2055
2056 026036 23$:
  
```

```

2057
2058
2059 026036 004737 037316 ;PREPARE DEVICE FOR READ OPERATION
      026042 154130 JSR PC,TSTPRP ;PREPARE DEVICE FOR TEST
      .WORD 154130 .WORD 154130 ;TASK DESCRIPTOR AS FOLLOWS:
      ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
      ;CLEAR CONTROLLER & SELECT DEVICE
      ;VERIFY CONTROLLER CLEAR OPERATION
      ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
      ;VERIFY PACK ACKNOWLEDGE
      ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
      ;VERIFY RECALIBRATION
      ;GO TO 24$ IF NO ERROR
      ;RETURN HERE IF ERROR
      ;ERROR # DEFINED BY TSTPRP SUBROUTINE
      ;GO TO 37$ IF ERROR

      026044 000404 BR 24$
      026046 000240 NOP
      026050 104000 EMT
      026052 000137 026410 JMP 37$
      026056 24$:

2060
2061
2062 ;READ DATA FROM DEVICE
2063 026056 25$:
2064 026056 012737 000071 001412 MOV #RD!GO, RMCS10 ;READ DATA COMMAND
2065 026064 012737 107446 001416 MOV #BUFTWO+4, RMBAO ;LOAD STARTING BUFFER ADDRESS
2066 026072 012702 001553 MOV #PUTINX, R2 ;LOAD PUT REGISTER INDEX TABLE
2067 026076 112722 000006 MOVB #RMDA, (R2)+
2068 026102 112722 000032 MOVB #RMOF, (R2)+
2069 026106 112722 000034 MOVB #RMDC, (R2)+
2070 026112 112722 000004 MOVB #RMB A, (R2)+
2071 026116 112722 000002 MOVB #RMWC, (R2)+
2072 026122 112722 000000 MOVB #RMCS1, (R2)+
2073 026126 112712 000200 MOVB #200, (R2)
2074
2075 026132 004737 043330 JSR PC,PUT ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      026136 000404 BR 26$ ;GO TO 26$ IF NO ERROR
      026140 000240 NOP ;RETURN HERE IF ERROR
      026142 104000 EMT ;ERROR # DEFINED BY PUT SUBROUTINE
      026144 000137 026410 JMP 37$ ;GO TO 37$ IF ERROR
      026150 26$:

2076
2077
2078 ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
      026150 004737 042774 JSR PC,GETSTS ;GO TO GETSTS SUBROUTINE
2079
2080 ;WAIT FOR COMMAND TO COMPLETE
      026154 004737 043672 JSR PC,TIMOUT ;GO TO TIMEOUT SUBROUTINE
2081
2082 ;GO READ STATUS FOR READ OPERATION
2083 026160 004737 043060 JSR PC,GET ;GO READ REGISTER(S) WITH GET SUBROUTINE
      026164 000404 BR 27$ ;GO TO 27$ IF NO ERROR
      026166 000240 NOP ;RETURN HERE IF ERROR
      026170 104000 EMT ;ERROR # DEFINED BY GET SUBROUTINE
      026172 000137 026410 JMP 37$ ;GO TO 37$ IF ERROR
      026176 27$:

2084
2085
2086 ;CHECK FOR ERRORS DURING READ OPERATION
2087 026176 004737 044056 JSR PC,PRIERR ;GO CHECK FOR PRIMARY ERRORS
      026202 000405 BR 28$ ;GO TO 28$ IF NO ERROR
      026204 000240 NOP ;RETURN HERE IF ERROR
      026206 104000 EMT ;ERROR # DEFINED BY PRIERR SUBROUTINE
      026210 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
  
```

```

2088 026212 000137 026410      JMP      37$      ;GO TO 37$ IF ERROR
2089 026216 005037 001140      CLR      $GDDAT  ;EXPECTED STATUS
2090 026222 032737 000220 001352      BIT      #HCE!FER,RMER1I ;ANY ERROR ?
2091 026230 001407          BEQ      29$      ;NO!!
2092 026232 013737 001352 001142      MOV      RMER1I,$BDDAT  ;RECEIVED STATUS
2093 026240 042737 177557 001142      BIC      #^C<HCE.FER>,$BDDAT ;CLEAR DONT CARES
2094 026246 000412          BR       30$
2095 026250          ;
2096 026250 013737 001400 001142      MOV      RMER2I,$BDDAT  ;RECEIVED STATUS
2097 026256 032737 100000 001400      BIT      #BSE,RMER2I   ;ANY BAD SECTOR ERROR ?
2098 026264 001406          BEQ      31$      ;NO !
2099 026266 042737 077777 001142      BIC      #^CBSE,$BDDAT ;CLEAR DONT CARES
2100 026274          ;
2101 026274 104346          EMT      346
2102 026276 000137 026410      JMP      37$
2103 026302          ;
2104          ;
2105 026302          ;
2106 026302 004737 056572      JSR      PC,DTASTS    ;GO VERIFY RESULTS OF DATA TRANSFER
          026306 000405          BR       33$      ;GO TO 33$ IF NO ERROR
          026310 000240          NOP          ;RETURN HERE IF ERROR
          026312 104000          EMT          ;ERROR # DEFINED BY DTASTS SUBROUTINE
          026314 004736          JSR      PC,@(SP)+   ;GO BACK FOR MORE ERROR CHECKS
          026316 000137 026410      JMP      37$      ;GO TO 37$ IF ERROR
2107 026322          ;
2108 026322 004737 044710      JSR      PC,SECERR   ;GO CHECK FOR SECONDARY ERRORS
          026326 000405          BR       34$      ;GO TO 34$ IF NO ERROR
          026330 000240          NOP          ;RETURN HERE IF ERROR
          026332 104000          EMT          ;ERROR # DEFINED BY SECERR SUBROUTINE
          026334 004736          JSR      PC,@(SP)+   ;GO BACK FOR MORE ERROR CHECKS
          026336 000137 026410      JMP      37$      ;GO TO 37$ IF ERROR
2109 026342          ;
2110 026342 004737 042432      JSR      PC,CMPBUF   ;GO COMPARE WRITE, READ DATA BUFFERS
          026346 106442          .WORD    BUFOUN+4   ;STARTING ADDRESS OF WRITE BUFFER
          026350 107446          .WORD    BUFTWO+4  ;STARTING ADDRESS OF READ BUFFER
          026352 000404          BR       35$      ;GO TO 35$ IF NO ERROR
          026354 000240          NOP          ;RETURN HERE IF ERROR
          026356 104000          EMT          ;ERROR # DEFINED BY CMPBUF SUBROUTINE
          026360 000137 026410      JMP      37$      ;GO TO 37$ IF ERROR
2111 026364          ;
2112 026364 006303          ASL      R3          ;SHIFT HCE BIT
2113 026366 001006          BNE      36$      ;CONTINUE IF NOT DONE
2114 026370 005704          TST      R4          ;SECOND HEADER DONE??
2115 026372 001006          BNE      37$      ;YES.!
2116 026374 012703 000001      MOV      #1,R3      ;START WITH BIT 0
2117 026400 012704 000002      MOV      #2,R4      ;DO SECOND HEADER WORD
2118 026404          ;
2119 026404 000137 025214      JMP      2$
2120 026410          ;
2121 026410 000464          BR       41$      ;EXIT IF ERROR
2122          ;
2123          ;*****
          ;*REFORMAT SECTOR THAT WAS WRITTEN WITH BAD HEADER
          ;*****
2124          ;
2125 026412          ;
2126 026412 012737 177776 001414      MOV      #-2,RMWCO   ;WORD COUNT
2127 026420 012737 010000 001444      MOV      #FMT16,RMOFO ;IN 16 BIT MODE

```



```

2128 026426 012737 106436 001416      MOV      #BUFONE,RMBAO      ;BUFFER ADDRESS
2129 026434 012737 000062 001412      MOV      #WH,RMCS10        ;FORMAT COMMAND
2130 026442 004737 042174          JSR      PC,GENBUF          ;SET UP BUFFER
2131
2132 026446 004737 037316          JSR      PC,TSTPRP          ;PREPARE DEVICE FOR TEST
      026452 054130          .WORD    054130            ;TASK DESCRIPTOR AS FOLLOWS:
      ;CLEAR CONTROLLER & SELECT DEVICE
      ;VERIFY CONTROLLER CLEAR OPERATION
      ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
      ;VERIFY PACK ACKNOWLEDGE
      ;RECALIBRATE IF 'SKI' GR 'PIP' IS SET
      ;VERIFY RECALIBRATION
      ;GO TO 39$ IF NO ERROR
      ;RETURN HERE IF ERROR
      ;ERROR # DEFINED BY TSTPRP SUBROUTINE
      ;GO TO 39$ IF ERROR
      026454 000404          BR       39$
      026456 000240          NOP
      026460 104000          EMT
      026462 000137 026466          JMP      39$
2133 026466          39$:
2134 026466 012737 000063 001412      MOV      #WH!GO,RMCS10
2135 026474 012702 001553          MOV      #PUTINX,R2        ;TABLE ADDRESS
2136 026500 112722 000006          MOVB     #RMDA,(R2)+
2137 026504 112722 000032          MOVB     #RMOF,(R2)+
2138 026510 112722 000034          MOVB     #RMDC,(R2)+
2139 026514 112722 000004          MOVB     #RMBA,(R2)+
2140 026520 112722 000002          MOVB     #RMWC,(R2)+
2141 026524 112722 000000          MOVB     #RMCS1,(R2)+
2142 026530 112722 000200          MOVB     #200,(R2)+
2143 026534 004737 043330          JSR      PC,PUT            ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      026540 000404          BR       40$
      026542 000240          NOP
      026544 104000          EMT
      026546 000137 026562          JMP      41$
2144 026552 000240          40$:
2145 026554 004737 043672          JSR      PC,TIMOUT
2146 026560 000240          NOP
2147 026562          41$:
2148
2149
;*****
;*TEST 16      WRITE, READ W/ IVC ERROR
;*****
TST16:
      026562          000004          SCOPE          ;SCOPE CALL
      026564 000240          NOP            ;START OF TEST
      026566 012706 001100          MOV      #STACK,SP        ;INITIALIZE STACK POINTER
      026572 013700 001276          MOV      $BASE,R0         ;R0 = UNIBUS ADDRESS
      026576 013701 001466          MOV      TSTQUE,R1        ;(R1) = DEVICE BEING TESTED
      026602 012737 000016 001226          MOV      #16,$TESTN       ;SET TEST NUMBER IN APT MAIL BOX
;*****
;LOOP #1      WRITE,READ
;LOAD PARAMETERS AND GENERATE DATA BUFFER
1$:
2150
2151
2152
2153
2154
2155 026610
2156 026610 012737 000000 001446          MOV      #0,RMDCO          ;CYLINDER = 0
2157 026616 012737 000000 001420          MOV      #0,RMDAO          ;TRACK = 0, SECTOR = 0
2158 026624 012737 106436 001416          MOV      #BUFONE,RMBAO     ;BUS ADDRESS
2159 026632 012737 177400 001414          MOV      #-256.,RMWCO      ;256. WORDS (2'S COMP)
2160 026640 012737 010000 001444          MOV      #FMT16,RMOFO      ;16 BIT FORMAT
  
```

```

2161 026646 012737 000060 001412      MOV      #WD,RMCS10      ;WRITE HEADER AND DATA COMMAND
2162
2163      ;VERIFY THAT SECTOR IS NOT BAD
      026654 004737 040242      JSR      PC,BADSCT      ;CALL BAD SECTOR MODULE
      026660 000405      BR      2$              ;GO TO 2$ IF NO ERROR
      026662 104401 070426      TYPE    ,SCTMSG        ;TYPE BAD SECTOR MESSAGE
      026666 104000      EMT     ;ERROR # DEFINED BY BADSCT SUBROUTINE
      026670 000137 027602      JMP     22$            ;GO TO 22$ IF ERROR
2164 026674
2165 026674 012737 001420 001174      2$:      MOV      #RMDAO,$TMP0    ;USE SECTOR FOR DATA PATTERN
2166 026702 012737 000001 001176      MOV      #1,$TMP1
2167 026710 004737 042174      JSR     PC,GENBUF      ;GO GENERATE DATA BUFFER
2168
2169      ;PREPARE DEVICE FOR WRITE OPERATION
2170 026714 004737 037316      JSR     PC,TSTPRP     ;PREPARE DEVICE FOR TEST
      026720 154130      .WORD   154130        ;TASK DESCRIPTOR AS FOLLOWS:
      ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
      ;CLEAR CONTROLLER & SELECT DEVICE
      ;VERIFY CONTROLLER CLEAR OPERATION
      ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
      ;VERIFY PACK ACKNOWLEDGE
      ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
      ;VERIFY RECALIBRATION
      026722 000404      BR      3$              ;GO TO 3$ IF NO ERROR
      026724 000240      NOP     ;RETURN HERE IF ERROR
      026726 104000      EMT     ;ERROR # DEFINED BY TSTPRP SUBROUTINE
      026730 000137 027602      JMP     22$            ;GO TO 22$ IF ERROR
2171 026734
2172
2173      3$:
2174 026734 112737 000024 001553      ;RESET VOLUME VALID
      026742 112737 000200 001554      MOV     #RMMR1,PUTINX  ;SETUP PUT INDEX TABLE
      026750 012737 000001 001436      MOV     #200,PUTINX+1 ;SET TERMINATOR BYTE
      026756 004737 043330      MOV     #DMD,RMMR10   ;SET RMMR1 OUTPUT BUFFER - DMD
      026762 000404      JSR     PC,PUT        ;GO WRITE RMMR1 VIA PUT SUBROUTINE
      026764 000240      BR      4$              ;GO TO 4$ IF NO ERROR
      026766 104000      NOP     ;RETURN HERE IF ERROR
      026770 000137 027602      EMT     ;ERROR DEFINED BY PUT SUBROUTINE
      026774      JMP     22$            ;GO TO 22$ IF ERROR
2175
2176
2177      4$:
2178 026774
2179 026774 012737 000061 001412      ;SETUP PARAMETERS AND EXECUTE WRITE DATA COMMAND
2180 027002 012737 000000 001436      5$:      MOV      #WD!GO,RMCS10  ;WRITE DATA COMMAND
2181 027010 012702 001553      MOV      #0,RMMR10     ;RESET DIAGNOSTIC MODE
2182 027014 112722 000024      MOV      #PUTINX,R2    ;LOAD PUT REGISTER INDEX TABLE
2183 027020 112722 000006      MOV     #RMMR1,(R2)+
2184 027024 112722 000034      MOV     #RMDA,(R2)+
2185 027030 112722 000032      MOV     #RMDC,(R2)+
2186 027034 112722 000002      MOV     #RMOF,(R2)+
2187 027040 112722 000004      MOV     #RMWC,(R2)+
2188 027044 112722 000000      MOV     #RMBA,(R2)+
2189 027050 112722 000200      MOV     #RMCS1,(R2)+
2190
2191 027054 004737 043330      MOV     #200,(R2)+    ;TERMINATE TABLE
      027060 000404      JSR     PC,PUT        ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      027062 000240      BR      6$              ;GO TO 6$ IF NO ERROR
      NOP     ;RETURN HERE IF ERROR
  
```

```

027064 104000 EMT ;ERROR # DEFINED BY PUT SUBROUTINE
027066 000137 027602 JMP 22$ ;GO TO 22$ IF ERROR
2192 027072 6$:
2193
2194 ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
027072 004737 042774 JSR PC,GETSTS ;GO TO GETSTS SUBROUTINE
2195
2196 ;WAIT FOR COMMAND TO COMPLETE
027076 004737 043672 JSR PC,TIMOUT ;GO TO TIMOUT SUBROUTINE
2197
2198 ;GO READ STATUS FOR WRITE COMMAND
2199 027102 004737 043060 JSR PC,GET ;GO READ REGISTER(S) WITH GET SUBROUTINE
027106 000404 BR 7$ ;GO TO 7$ IF NO ERROR
027110 000240 NOP ;RETURN HERE IF ERROR
027112 104000 EMT ;ERROR # DEFINED BY GET SUBROUTINE
027114 000137 027602 JMP 22$ ;GO TO 22$ IF ERROR
2200 027120 7$:
2201
2202 ;CHECK FOR ERRORS DURING WRITE OPERATION
2203 027120 004737 044056 JSR PC,PRIERR ;GO CHECK FOR PRIMARY ERRORS
027124 000405 BR 8$ ;GO TO 8$ IF NO ERROR
027126 000240 NOP ;RETURN HERE IF ERROR
027130 104000 EMT ;ERROR # DEFINED BY PRIERR SUBROUTINE
027132 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
027134 000137 027602 JMP 22$ ;GO TO 22$ IF ERROR
2204 027140 8$:
2205 027140 032737 010000 001400 BIT #IVC,RMER2I ;WAS "IVC" DETECTED??
2206 027146 001024 BNE 10$ ;YES!
2207
2208 027150 004737 056572 JSR PC,DTASTS ;GO VERIFY RESULTS OF DATA TRANSFER
027154 000405 BR 9$ ;GO TO 9$ IF NO ERROR
027156 000240 NOP ;RETURN HERE IF ERROR
027160 104000 EMT ;ERROR # DEFINED BY DTASTS SUBROUTINE
027162 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
027164 000137 027602 JMP 22$ ;GO TO 22$ IF ERROR
2209 027170 9$:
2210 027170 013737 001400 001142 MOV RMER2I,$BDDAT ;RECEIVED STATUS
2211 027176 013737 001400 001140 MOV RMER2I,$GDDAT ;EXPECTED STATUS
2212 027204 052737 010000 001140 BIS #IVC,$GDDAT
2213 027212 104342 EMT 342
2214 027214 000137 027602 JMP 22$
2215 027220 10$:
2216 027220 004737 044710 JSR PC,SECERR ;GO CHECK FOR SECONDARY ERRORS
027224 000405 BR 11$ ;GO TO 11$ IF NO ERROR
027226 000240 NOP ;RETURN HERE IF ERROR
027230 104000 EMT ;ERROR # DEFINED BY SECERR SUBROUTINE
027232 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
027234 000137 027602 JMP 22$ ;GO TO 22$ IF ERROR
2217 027240 11$:
2218
2219 ;CHANGE LOOP ADDRESSES
2220 027240 012737 027250 001124 MOV #12$,$LPERR
2221 027246 000410 BR 13$
2222
2223 ;*****
2224 ;LOOP #2 READ
2225

```

```

2226 027250      12$:
2227
2228
2229 027250 004737 037316      ;PREPARE DEVICE FOR READ OPERATION
      027254 154130      JSR PC,TSTPRP      ;PREPARE DEVICE FOR TEST
      .WORD 154130      .WORD 154130      ;TASK DESCRIPTOR AS FOLLOWS:
      ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
      ;CLEAR CONTROLLER & SELECT DEVICE
      ;VERIFY CONTROLLER CLEAR OPERATION
      ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
      ;VERIFY PACK ACKNOWLEDGE
      ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
      ;VERIFY RECALIBRATION
      ;GO TO 13$ IF NO ERROR
      ;RETURN HERE IF ERROR
      ;ERROR # DEFINED BY TSTPRP SUBROUTINE
      ;GO TO 22$ IF ERROR

      027256 000404      BR 13$
      027260 000240      NOP
      027262 104000      EMT
      027264 000137 027602    JMP 22$

2230 027270      13$:
2231
2232
2233 027270 112737 000024 001553    ;RESET VOLUME VALID
      027276 112737 000200 001554    MOVB #RMMR1,PUTINX      ;SETUP PUT INDEX TABLE
      027304 012737 000001 001436    MOVB #200,PUTINX+1     ;SET TERMINATOR BYTE
      027312 004737 043330      MOV #DMD,RMMR10        ;SET RMMR1 OUTPUT BUFFER - DMD
      027316 000404      JSR PC,PUT             ;GO WRITE RMMR1 VIA PUT SUBROUTINE
      027320 000240      BR 14$               ;GO TO 14$ IF NO ERROR
      027322 104000      NOP                   ;RETURN HERE IF ERROR
      027324 000137 027602    EMT                   ;ERROR DEFINED BY PUT SUBROUTINE
      027330      JMP 22$               ;GO TO 22$ IF ERROR

2234 027330      14$:
2235
2236
2237 027330      ;READ DATA FROM DEVICE
2238 027330 012737 000071 001412    15$:
2239 027336 012737 107442 001416    MOV #RD!GO,RMCS10      ;READ DATA COMMAND
2240 027344 012737 000000 001436    MOV #BUFTWO,RMBA0     ;LOAD STARTING BUFFER ADDRESS
2241 027352 012702 001553      MOV #0,RMMR10         ;RESET DIANOSTIC MODE
2242 027356 112722 000024      MOV #PUTINX,R2        ;LOAD PUT REGISTER INDEX TABLE
2243 027362 112722 000006      MOVB #RMMR1,(R2)+
2244 027366 112722 000032      MOVB #RMDA,(R2)+
2245 027372 112722 000034      MOVB #RMOF,(R2)+
2246 027376 112722 000004      MOVB #RMDC,(R2)+
2247 027402 112722 000002      MOVB #RMBA,(R2)+
2248 027406 112722 000000      MOVB #RMWC,(R2)+
2249 027412 112712 000200      MOVB #RMCS1,(R2)+
2250      MOVB #200,(R2)
2251 027416 004737 043330      JSR PC,PUT            ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      027422 000404      BR 16$               ;GO TO 16$ IF NO ERROR
      027424 000240      NOP                   ;RETURN HERE IF ERROR
      027426 104000      EMT                   ;ERROR # DEFINED BY PUT SUBROUTINE
      027430 000137 027602    JMP 22$               ;GO TO 22$ IF ERROR

2252 027434      16$:
2253
2254 027434 004737 042774      ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
      JSR PC,GETSTS      ;GO TO GETSTS SUBROUTINE

2255
2256 027440 004737 043672      ;WAIT FOR COMMAND TO COMPLETE
      JSR PC,TIMOUT      ;GO TO TIMOUT SUBROUTINE
2257
  
```

```

2258 ;GO READ STATUS FOR READ OPERATION
2259 027444 004737 043060 JSR PC,GET ;GO READ REGISTER(S) WITH GET SUBROUTINE
    027450 000404 BR 17$ ;GO TO 17$ IF NO ERROR
    027452 000240 NOP ;RETURN HERE IF ERROR
    027454 104000 EMT ;ERROR # DEFINED BY GET SUBROUTINE
    027456 000137 027602 JMP 22$ ;GO TO 22$ IF ERROR
2260 027462 17$:
2261
2262 ;CHECK FOR ERRORS DURING READ OPERATION
2263 027462 004737 044056 JSR PC,PRIERR ;GO CHECK FOR PRIMARY ERRORS
    027466 000405 BR 18$ ;GO TO 18$ IF NO ERROR
    027470 000240 NOP ;RETURN HERE IF ERROR
    027472 104000 EMT ;ERROR # DEFINED BY PRIERR SUBROUTINE
    027474 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
    027476 000137 027602 JMP 22$ ;GO TO 22$ IF ERROR
2264 027502 18$:
2265 027502 032737 010000 001400 BIT #IVC,RMER2I ;WAS 'IVC' DETECTED??
2266 027510 001024 BNE 20$ ;YES!!
2267
2268 027512 004737 056572 JSR PC,DTASTS ;GO VERIFY RESULTS OF DATA TRANSFER
    027516 000405 BR 19$ ;GO TO 19$ IF NO ERROR
    027520 000240 NOP ;RETURN HERE IF ERROR
    027522 104000 EMT ;ERROR # DEFINED BY DTASTS SUBROUTINE
    027524 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
    027526 000137 027602 JMP 22$ ;GO TO 22$ IF ERROR
2269 027532 19$:
2270 027532 013737 001400 001140 MOV RMER2I,$GDDAT ;EXPECTED STATUS
2271 027540 052737 010000 001140 BIS #IVC,$GDDAT
2272 027546 013737 001400 001142 MOV RMER2I,$BDDAT ;RECEIVED STATUS
2273 027554 104342 EMT 342
2274 027556 000137 027602 JMP 22$
2275 027562 20$:
2276 027562 004737 044710 JSR PC,SECERR ;GO CHECK FOR SECONDARY ERRORS
    027566 000405 BR 21$ ;GO TO 21$ IF NO ERROR
    027570 000240 NOP ;RETURN HERE IF ERROR
    027572 104000 EMT ;ERROR # DEFINED BY SECERR SUBROUTINE
    027574 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
    027576 000137 027602 JMP 22$ ;GO TO 22$ IF ERROR
2277 027602 21$:
2278
2279 027602 22$:
2280
2281
;*****
;*TEST 17 WRITE, READ W/ ABORT
;*****
TST17:
027602 000004 SCOPE ;SCOPE CALL
027604 000240 NOP ;START OF TEST
027606 012706 001100 MOV #STACK,SP ;INITIALIZE STACK POINTER
027612 013700 001276 MOV $BASE,R0 ;R0 = UNIBUS ADDRESS
027616 013701 001466 MOV TSTQUE,R1 ;(R1) = DEVICE BEING TESTED
027622 012737 000017 001226 MOV #17,$TESTN ;SET TEST NUMBER IN APT MAIL BOX
2282
2283 ;*****
2284 ;LOOP #1 WRITE,READ
2285
2286 ;LOAD PARAMETERS AND GENERATE DATA BUFFER
  
```

```

2287 027630 012737 000000 001446      MOV      #0,RMDCO          ;CYLINDER = 0
2288 027636 012737 000000 001420      MOV      #0,RMDAO          ;TRACK = 0, SECTOR = 0
2289 027644 012737 106436 001416      MOV      #BUFONE,RMBAO     ;BUS ADDRESS
2290 027652 012737 177400 001414      MOV      #-256.,RMWCO      ;256. WORDS (2'S COMP)
2291 027660 012737 010000 001444      MOV      #FMT16,RMFOFO     ;16 BIT FORMAT
2292 027666 012737 000061 001412      MOV      #WD!GO,RMCS10     ;WRITE DATA COMMAND
2293 027674
2294
2295
2296 027674 004737 037316      ;PREPARE DEVICE FOR WRITE OPERATION
      027700 154130      JSR      PC,TSTPRP        ;PREPARE DEVICE FOR TEST
      .WORD 154130      .WORD    ;TASK DESCRIPTOR AS FOLLOWS:
      ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
      ;CLEAR CONTROLLER & SELECT DEVICE
      ;VERIFY CONTROLLER CLEAR OPERATION
      ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
      ;VERIFY PACK ACKNOWLEDGE
      ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
      ;VERIFY RECALIBRATION
      ;GO TO 2$ IF NO ERROR
      ;RETURN HERE IF ERROR
      ;ERROR # DEFINED BY TSTPRP SUBROUTINE
      ;GO TO 21$ IF ERROR
2297 027702 000404      BR      2$
2298 027704 000240      NOP
2299 027706 104000      EMT
2300 027710 000137 030520      JMP      21$
2301 027714
2302
2303
2304 027714 112737 000014 001553      ;SET UNSAFE ERROR
      027722 112737 000200 001554      MOV      #RMER1,PUTINX     ;SETUP PUT INDEX TABLE
      027730 012737 040000 001426      MOV      #200,PUTINX+1     ;SET TERMINATOR BYTE
      027736 004737 043330      MOV      #UNS,RMER10       ;SET RMER1 OUTPUT BUFFER = UNS
      027742 000404      JSR      PC,PUT            ;GO WRITE RMER1 VIA PUT SUBROUTINE
      027744 000240      BR      3$                ;GO TO 3$ IF NO ERROR
      027746 104000      NOP                        ;RETURN HERE IF ERROR
      027750 000137 030520      EMT                        ;ERROR DEFINED BY PUT SUBROUTINE
      027754      JMP      21$              ;GO TO 21$ IF ERROR
2305 027754
2306
2307
2308
2309
2310
2311
2312
2313
2314
2315 030022 004737 043330      ;WRITE DATA TO THE DRIVE
      030026 000404      4$:      MOV      #WD!GO,RMCS10     ;WRITE DATA COMMAND
      030030 000240      MOV      #PUTINX,R2        ;LOAD PUT REGISTER INDEX TABLE
      030032 104000      MOV      #RMDA,(R2)+
      030034 000006      MOV      #RMDC,(R2)+
      030036 112722 000034      MOV      #RMOF,(R2)+
      030038 112722 000032      MOV      #RMBA,(R2)+
      030040 112722 000004      MOV      #RMWC,(R2)+
      030042 112722 000002      MOV      #RMCS1,(R2)+
      030044 112722 000000      MOV      #200,(R2)+
      030046 112722 000200      ;TERMINATE TABLE
      030048 000137 030520      JSR      PC,PUT            ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      030050 000404      BR      5$                ;GO TO 5$ IF NO ERROR
      030052 000240      NOP                        ;RETURN HERE IF ERROR
      030054 104000      EMT                        ;ERROR # DEFINED BY PUT SUBROUTINE
      030056 000137 030520      JMP      21$              ;GO TO 21$ IF ERROR
2316 030040
2317
2318
2319 030040 004737 042774      ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
      JSR      PC,GETSTS      ;GO TO GETSTS SUBROUTINE
  
```

```

2320 ;GO GET REGISTER STATUS
2321 030044 004737 043060 JSR PC,GET ;GO READ REGISTER(S) WITH GET SUBROUTINE
030050 000404 BR 6$ ;GO TO 6$ IF NO ERROR
030052 000240 NOP ;RETURN HERE IF ERROR
030054 104000 EMT ;ERROR # DEFINED BY GET SUBROUTINE
030056 000137 030520 JMP 21$ ;GO TO 21$ IF ERROR
2322 030062 6$:
2323 030062 032737 020000 001350 BIT #PIP,RMDSI ;WAS COMMAND EXECUTED?
2324 030070 001412 BEQ 7$ ;NO, GO WAIT
2325 030072 013737 001350 001140 MOV RMDSI,$GDDAT ;EXPECTED STATUS
2326 030100 042737 020000 001140 BIC #PIP,$GDDAT
2327 030106 013737 001350 001142 MOV RMDSI,$BDDAT ;RECEIVED STATUS
2328 030114 104347 EMT 347
2329 030116 7$:
2330
2331 ;WAIT FOR COMMAND TO COMPLETE
030116 004737 043672 JSR PC,TIMOUT ;GO TO TIMEOUT SUBROUTINE
2332
2333 ;GO GET REGISTER STATUS
2334 030122 004737 043060 JSR PC,GET ;GO READ REGISTER(S) WITH GET SUBROUTINE
030126 000404 BR 8$ ;GO TO 8$ IF NO ERROR
030130 000240 NOP ;RETURN HERE IF ERROR
030132 104000 EMT ;ERROR # DEFINED BY GET SUBROUTINE
030134 000137 030520 JMP 21$ ;GO TO 21$ IF ERROR
2335 030140 8$:
2336 030140 004737 044056 JSR PC,PRIERR ;GO CHECK FOR PRIMARY ERRORS
030144 000405 BR 9$ ;GO TO 9$ IF NO ERROR
030146 000240 NOP ;RETURN HERE IF ERROR
030150 104000 EMT ;ERROR # DEFINED BY PRIERR SUBROUTINE
030152 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
030154 000137 030520 JMP 21$ ;GO TO 21$ IF ERROR
2337 030160 9$:
2338 030160 004737 044710 JSR PC,SECERR ;GO CHECK FOR SECONDARY ERRORS
030164 000405 BR 10$ ;GO TO 10$ IF NO ERROR
030166 000240 NOP ;RETURN HERE IF ERROR
030170 104000 EMT ;ERROR # DEFINED BY SECERR SUBROUTINE
030172 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
030174 000137 030520 JMP 21$ ;GO TO 21$ IF ERROR
2339 030200 10$:
2340
2341 ;CHANGE LOOP ADDRESSES
2342 030200 012737 030210 001124 MOV #11$,$LPERR
2343 030206 000410 BR 12$
2344
2345 ;*****
2346 ;LOOP #2 READ
2347
2348 030210 11$:
2349
2350 ;PREPARE DEVICE FOR READ OPERATION
2351 030210 004737 037316 JSR PC,TSTPRP ;PREPARE DEVICE FOR TEST
030214 154130 .WORD 154130 ;TASK DESCRIPTOR AS FOLLOWS:
;SELECT DEVICE & VERIFY DEVICE AVAILABLE
;CLEAR CONTROLLER & SELECT DEVICE
;VERIFY CONTROLLER CLEAR OPERATION
;PACK ACKNOWLEDGE IF VOLUME NOT VALID
;VERIFY PACK ACKNOWLEDGE
  
```

```
030216 000404 BR 12$ ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
030220 000240 NOP ;VERIFY RECALIBRATION
030222 104000 EMT ;GO TO 12$ IF NO ERROR
030224 000137 030520 JMP 21$ ;RETURN HERE IF ERROR
;ERROR # DEFINED BY TSTPRP SUBROUTINE
;GO TO 21$ IF ERROR
2352 030230 12$:
2353
2354 ;SET UNSAFE ERROR
2355 030230 112737 000014 001553 MOVB #RMER1,PUTINX ;SETUP PUT INDEX TABLE
030236 112737 000200 001554 MOVB #200,PUTINX+1 ;SET TERMINATOR BYTE
030244 012737 040000 001426 MOV #UNS,RMER10 ;SET RMER1 OUTPUT BUFFER = UNS
030252 004737 043330 JSR PC,PUT ;GO WRITE RMER1 VIA PUT SUBROUTINE
030256 000404 BR 13$ ;GO TO 13$ IF NO ERROR
030260 000240 NOP ;RETURN HERE IF ERROR
030262 104000 EMT ;ERROR DEFINED BY PUT SUBROUTINE
030264 000137 030520 JMP 21$ ;GO TO 21$ IF ERROR
2356 030270 13$:
2357
2358 ;READ DATA FROM DEVICE
2359 030270 14$:
2360 030270 012737 000071 001412 MOV #RD!GO,RMCS10 ;READ DATA COMMAND
2361 030276 012702 001553 MOV #PUTINX,R2 ;LOAD PUT REGISTER INDEX TABLE
2362 030302 112722 000006 MOVB #RMDA,(R2)+
2363 030306 112722 000032 MOVB #RMOF,(R2)+
2364 030312 112722 000034 MOVB #RMDC,(R2)+
2365 030316 112722 000004 MOVB #RMBA,(R2)+
2366 030322 112722 000002 MOVB #RMWC,(R2)+
2367 030326 112722 000000 MOVB #RMCS1,(R2)+
2368 030332 112712 000200 MOVB #200,(R2)
2369
2370 030336 004737 043330 JSR PC,PUT ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
030342 000404 BR 15$ ;GO TO 15$ IF NO ERROR
030344 000240 NOP ;RETURN HERE IF ERROR
030346 104000 EMT ;ERROR # DEFINED BY PUT SUBROUTINE
030350 000137 030520 JMP 21$ ;GO TO 21$ IF ERROR
2371 030354 15$:
2372
2373 ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
030354 004737 042774 JSR PC,GETSTS ;GO TO GETSTS SUBROUTINE
2374
2375 ;SEE IF DEVICE STARTED COMMAND
2376 030360 004737 043060 JSR PC,GET ;GO READ REGISTER(S) WITH GET SUBROUTINE
030364 000404 BR 16$ ;GO TO 16$ IF NO ERROR
030366 000240 NOP ;RETURN HERE IF ERROR
030370 104000 EMT ;ERROR # DEFINED BY GET SUBROUTINE
030372 000137 030520 JMP 21$ ;GO TO 21$ IF ERROR
2377 030376 16$:
2378 030376 032737 020000 001350 BIT #PIP,RMDSI ;WAS COMMAND EXECUTED??
2379 030404 001414 BEQ 17$ ;NO!!
2380 030406 013737 001350 001140 MOV RMDSI,$GDDAT ;EXPECTED STATUS
2381 030414 042737 020000 001140 BIC #PIP,$GDDAT
2382 030422 013737 001350 001142 MOV RMDSI,$BDDAT ;RECEIVED STATUS
2383 030430 104347 EMT 347
2384 030432 000137 030520 JMP 21$
2385 030436 17$:
2386
```



```

2387          ;WAIT FOR COMMAND TO COMPLETE
030436 004737 043672      JSR      PC,TIMOUT      ;GO TO TIMEOUT SUBROUTINE
2388
2389          ;GO READ STATUS FOR READ OPERATION
2390 030442 004737 043060      JSR      PC,GET      ;GO READ REGISTER(S) WITH GET SUBROUTINE
030446 000404              BR      18$      ;GO TO 18$ IF NO ERROR
030450 000240              NOP              ;RETURN HERE IF ERROR
030452 104000              EMT              ;ERROR # DEFINED BY GET SUBROUTINE
030454 000137 030520      JMP      21$      ;GO TO 21$ IF ERROR
2391 030460      18$:
2392 030460 004737 044056      JSR      PC,PRIERR    ;GO CHECK FOR PRIMARY ERRORS
030464 000405              BR      19$      ;GO TO 19$ IF NO ERROR
030466 000240              NOP              ;RETURN HERE IF ERROR
030470 104000              EMT              ;ERROR # DEFINED BY PRIERR SUBROUTINE
030472 004736              JSR      PC,@(SP)+    ;GO BACK FOR MORE ERROR CHECKS
030474 000137 030520      JMP      21$      ;GO TO 21$ IF ERROR
2393 030500      19$:
2394 030500 004737 044710      JSR      PC,SECERR    ;GO CHECK FOR SECONDARY ERRORS
030504 000405              BR      20$      ;GO TO 20$ IF NO ERROR
030506 000240              NOP              ;RETURN HERE IF ERROR
030510 104000              EMT              ;ERROR # DEFINED BY SECERR SUBROUTINE
030512 004736              JSR      PC,@(SP)+    ;GO BACK FOR MORE ERROR CHECKS
030514 000137 030520      JMP      21$      ;GO TO 21$ IF ERROR
2395 030520      20$:
2396
2397 030520      21$:
2398
2399
::*****
;*TEST 20      WRITE, READ EACH CURRENT LEVEL
::*****
TST20:
030520          SCOPE          ;SCOPE CALL
030520 000004          NOP          ;START OF TEST
030522 000240          MOV      #STACK,SP    ;INITIALIZE STACK POINTER
030524 012706 001100      MOV      $BASE,R0      ;R0 = UNIBUS ADDRESS
030530 013700 001276      MOV      TSTQUE,R1     ;(R1) = DEVICE BEING TESTED
030534 013701 001466      MOV      #20,$TESTN    ;;SET TEST NUMBER IN APT MAIL BOX
030540 012737 000020 001226  JMP      1$
2400 030546          1$:
2401
2402          ;*****
2403          ;LOOP #1      FORMAT,WRITE,READ
2404
2405          ;PREPARE THE DEVICE FOR FORMAT OPERATION
2406 030546 004737 037316      JSR      PC,TSTPRP    ;PREPARE DEVICE FOR TEST
030552 054130          .WORD 054130 ;TASK DESCRIPTOR AS FOLLOWS:
                                ;CLEAR CONTROLLER & SELECT DEVICE
                                ;VERIFY CONTROLLER CLEAR OPERATION
                                ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
                                ;VERIFY PACK ACKNOWLEDGE
                                ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
                                ;VERIFY RECALIBRATION
030554 000404          BR      2$      ;GO TO 2$ IF NO ERROR
030556 000240          NOP          ;RETURN HERE IF ERROR
030560 104000          EMT          ;ERROR # DEFINED BY TSTPRP SUBROUTINE
030562 000137 031556      JMP      28$      ;GO TO 28$ IF ERROR
2407 030566          2$:
2408

```

```

2409 ;LOAD PARAMETERS AND GENERATE DATA BUFFER
2410 030566 012737 000000 001446 MOV #0,RMDCO ;CYLINDER 0
2411 030574 012737 000000 001420 3$: MOV #0,RMDAO ;TRACK = 0, SECTOR = 0
2412 030602 012737 106436 001416 MOV #BUFONE,RMBAD ;BUS ADDRESS
2413 030610 012737 177376 001414 MOV #-258.,RMWCO ;2 + 256. WORDS (2'S COMP)
2414 030616 012737 010000 001444 MOV #FMT16,RMOFO ;16 BIT FORMAT
2415 030624 012737 000063 001412 MOV #WH!GO,RMCS10 ;WRITE HEADER AND DATA COMMAND
2416
2417 ;VERIFY THAT SECTOR IS NOT BAD
030632 004737 040242 JSR PC,BADSCT ;CALL BAD SECTOR MODULE
030636 000405 BR 4$ ;GO TO 4$ IF NO ERROR
030640 104401 070426 TYPE ,SCTMSG ;TYPE BAD SECTOR MESSAGE
030644 104000 EMT ;ERROR # DEFINED BY BADSCT SUBROUTINE
030646 000137 031556 JMP 28$ ;GO TO 28$ IF ERROR
2418 030652 4$:
2419 030652 012737 072060 001174 MOV #ZEROS,$TMP0 ;STARTING ADDRESS OF PATTERN
2420 030660 012737 000001 001176 MOV #1,$TMP1 ;RANGE OF PATTERN
2421 030666 004737 042174 JSR PC,GENBUF ;GO GENERATE BUFFER FOR FORMAT
2422
2423 ;LOAD PUT REGISTER INDEX TABLE FOR FORMAT OPERATION
2424 030672 012702 001553 MOV #PUTINX,R2 ;R2 = BYTE ENTRY POSITION
2425 030676 112722 000034 MOVB #RMDC,(R2)+
2426 030702 112722 000006 MOVB #RMDA,(R2)+
2427 030706 112722 000004 MOVB #RMBAD,(R2)+
2428 030712 112722 000002 MOVB #RMWCO,(R2)+
2429 030716 112722 000032 MOVB #RMOFO,(R2)+
2430 030722 112722 000000 MOVB #RMCS1,(R2)+
2431 030726 112712 000200 MOVB #200,(R2) ;TERMINATE TABLE
2432 030732 5$:
2433 030732 004737 043330 JSR PC,PUT ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
030736 000404 BR 6$ ;GO TO 6$ IF NO ERROR
030740 000240 NOP ;RETURN HERE IF ERROR
030742 104000 EMT ;ERROR # DEFINED BY PUT SUBROUTINE
030744 000137 031556 JMP 28$ ;GO TO 28$ IF ERROR
2434 030750 6$:
2435
2436 ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
030750 004737 042774 JSR PC,GETSTS ;GO TO GETSTS SUBROUTINE
2437
2438 ;WAIT FOR COMMAND TO COMPLETE
030754 004737 043672 JSR PC,TIMOUT ;GO TO TIMOUT SUBROUTINE
2439
2440 ;GO READ STATUS FOR FORMAT OPERATION
2441 030760 004737 043060 JSR PC,GET ;GO READ REGISTER(S) WITH GET SUBROUTINE
030764 000404 BR 7$ ;GO TO 7$ IF NO ERROR
030766 000240 NOP ;RETURN HERE IF ERROR
030770 104000 EMT ;ERROR # DEFINED BY GET SUBROUTINE
030772 000137 031556 JMP 28$ ;GO TO 28$ IF ERROR
2442 030776 7$:
2443
2444 ;VERIFY NO ERRORS DURING FORMAT
2445 030776 004737 056572 JSR PC,DTASTS ;GO VERIFY RESULTS OF DATA TRANSFER
031002 000405 BR 8$ ;GO TO 8$ IF NO ERROR
031004 000240 NOP ;RETURN HERE IF ERROR
031006 104000 EMT ;ERROR # DEFINED BY DTASTS SUBROUTINE
031010 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
031012 000137 031556 JMP 28$ ;GO TO 28$ IF ERROR
  
```

```

2446 031016      8$:
2447
2448
2449 031016 012737 031026 001124 ;MOVE LOOP ADDRESSES TO NEXT OPERATION
2450 031024 000410      MOV      #9$, $LPERR
2451      BR      10$ ;SKIP TO WRITE OPERATION
2452
2453 ;:*****
2454 ;LOOP #2      WRITE,READ
2455 031026      9$:
2456
2457
2458 ;PREPARE DEVICE FOR WRITE OPERATION
2459 031026 004737 037316      JSR      PC, TSTPRP ;PREPARE DEVICE FOR TEST
      031032 054130      .WORD    054130 ;TASK DESCRIPTOR AS FOLLOWS:
      ;CLEAR CONTROLLER & SELECT DEVICE
      ;VERIFY CONTROLLER CLEAR OPERATION
      ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
      ;VERIFY PACK ACKNOWLEDGE
      ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
      ;VERIFY RECALIBRATION
      ;GO TO 10$ IF NO ERROR
      ;RETURN HERE IF ERROR
      ;ERROR # DEFINED BY TSTPRP SUBROUTINE
      ;GO TO 28$ IF ERROR
      031034 000404      BR      10$
      031036 000240      NOP
      031040 104000      EMT
      031042 000137 031556      JMP      28$
2460 031046      10$:
2461
2462 031046      11$:
2463
2464 ;WRITE DATA TO THE DRIVE
2465 031046 012737 177400 001414      MOV      #-256., RMWCO ;256. WORDS (2'S COMP)
2466 031054 012737 106442 001416      MOV      #BUFONE+4, RMBAO ;CHANGE ADDRESS
2467 031062 012737 000061 001412      MOV      #WD!GO, RMCS10 ;WRITE DATA COMMAND
2468 031070 012702 001553      MOV      #PUTINX, R2 ;LOAD PUT REGISTER INDEX TABLE
2469 031074 112722 000006      MOVB    #RMDA, (R2)+
2470 031100 112722 000034      MOVB    #RMDC, (R2)+
2471 031104 112722 000032      MOVB    #RMOF, (R2)+
2472 031110 112722 000004      MOVB    #RMB A, (R2)+
2473 031114 112722 000002      MOVB    #RMWC, (R2)+
2474 031120 112722 000000      MOVB    #RMCS1, (R2)+
2475 031124 112722 000200      MOVB    #200, (R2)+ ;TERMINATE TABLE
2476
2477 031130 004737 043330      JSR      PC, PUT ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      031134 000404      BR      12$ ;GO TO 12$ IF NO ERROR
      031136 000240      NOP ;RETURN HERE IF ERROR
      031140 104000      EMT ;ERROR # DEFINED BY PUT SUBROUTINE
      031142 000137 031556      JMP      28$ ;GO TO 28$ IF ERROR
2478 031146      12$:
2479
2480 ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
      JSR      PC, GETSTS ;GO TO GETSTS SUBROUTINE
2481
2482 ;WAIT FOR COMMAND TO COMPLETE
      JSR      PC, TIMOUT ;GO TO TIMOUT SUBROUTINE
2483
2484 ;GO READ STATUS FOR WRITE COMMAND
2485 031156 004737 043060      JSR      PC, GET ;GO READ REGISTER(S) WITH GET SUBROUTINE
  
```

```

031162 000404 BR 13$ :GO TO 13$ IF NO ERROR
031164 000240 NOP :RETURN HERE IF ERROR
031166 104000 EMT :ERROR # DEFINED BY GET SUBROUTINE
031170 000137 031556 JMP 28$ :GO TO 28$ IF ERROR
2486 031174 13$:
2487
2488 ;CHECK FOR ERRORS DURING WRITE OPERATION
2489 031174 004737 044056 JSR PC,PRIERR :GO CHECK FOR PRIMARY ERRORS
031200 000405 BR 14$ :GO TO 14$ IF NO ERROR
031202 000240 NOP :RETURN HERE IF ERROR
031204 104000 EMT :ERROR # DEFINED BY PRIERR SUBROUTINE
031206 004736 JSR PC,@(SP)+ :GO BACK FOR MORE ERROR CHECKS
031210 000137 031556 JMP 28$ :GO TO 28$ IF ERROR
2490 031214 14$:
2491 031214 004737 056572 JSR PC,DTASTS :GO VERIFY RESULTS OF DATA TRANSFER
031220 000405 BR 15$ :GO TO 15$ IF NO ERROR
031222 000240 NOP :RETURN HERE IF ERROR
031224 104000 EMT :ERROR # DEFINED BY DTASTS SUBROUTINE
031226 004736 JSR PC,@(SP)+ :GO BACK FOR MORE ERROR CHECKS
031230 000137 031556 JMP 28$ :GO TO 28$ IF ERROR
2492 031234 15$:
2493
2494 031234 16$:
2495 031234 004737 044710 JSR PC,SECERR :GO CHECK FOR SECONDARY ERRORS
031240 000405 BR 17$ :GO TO 17$ IF NO ERROR
031242 000240 NOP :RETURN HERE IF ERROR
031244 104000 EMT :ERROR # DEFINED BY SECERR SUBROUTINE
031246 004736 JSR PC,@(SP)+ :GO BACK FOR MORE ERROR CHECKS
031250 000137 031556 JMP 28$ :GO TO 28$ IF ERROR
2496 031254 17$:
2497
2498 ;CHANGE LOOP ADDRESSES
2499 031254 012737 031264 001124 MOV #18$, $LPERR
2500 031262 000410 BR 19$ ;SKIP TO NEXT OPERATION
2501
2502 ;*****
2503 ;LOOP #3 READ
2504
2505 031264 18$:
2506
2507 ;PREPARE DEVICE FOR READ OPERATION
2508 031264 004737 037316 JSR PC,TSTPRP :PREPARE DEVICE FOR TEST
031270 054130 .WORD 054130 :TASK DFSCRIPTOR AS FOLLOWS:
:CLEAR CONTROLLER & SELECT DEVICE
:VERIFY CONTROLLER CLEAR OPERATION
:PACK ACKNOWLEDGE IF VOLUME NOT VALID
:VERIFY PACK ACKNOWLEDGE
:RECALIBRATE IF "SKI" OR "PIP" IS SET
:VERIFY RECALIBRATION
031272 000404 BR 19$ :GO TO 19$ IF NO ERROR
031274 000240 NOP :RETURN HERE IF ERROR
031276 104000 EMT :ERROR # DEFINED BY TSTPRP SUBROUTINE
031300 000137 031556 JMP 28$ :GO TO 28$ IF ERROR
2509 031304 19$:
2510
2511 031304 20$:
2512

```

```

2513 ;READ DATA FROM DEVICE
2514 031304 012737 107446 001416 MOV #BUFTWO+4,RMBA0 ;CHANGE ADDRESS
2515 031312 012737 177400 001414 MOV #-256.,RMWCO ;256. WORDS (2'S COMP)
2516 031320 012737 000071 001412 MOV #RD!GO,RMCS10 ;READ DATA COMMAND
2517 031326 012702 001553 MOV #PUTINX,R2 ;LOAD PUT REGISTER INDEX TABLE
2518 031332 112722 000006 MOVB #RMDA,(R2)+
2519 031336 112722 000032 MOVB #RMOF,(R2)+
2520 031342 112722 000034 MOVB #RMDC,(R2)+
2521 031346 112722 000004 MOVB #RMBA,(R2)+
2522 031352 112722 000002 MOVB #RMWC,(R2)+
2523 031356 112722 000000 MOVB #RMCS1,(R2)+
2524 031362 112712 000200 MOVB #200,(R2)
2525
2526 031366 004737 043330 JSR PC,PUT ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
031372 000404 BR 21$ ;GO TO 21$ IF NO ERROR
031374 000240 NOP ;RETURN HERE IF ERROR
031376 104000 EMT ;ERROR # DEFINED BY PUT SUBROUTINE
031400 000137 031556 JMP 28$ ;GO TO 28$ IF ERROR
2527 031404 21$:
2528
2529 ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
031404 004737 042774 JSR PC,GETSTS ;GO TO GETSTS SUBROUTINE
2530
2531 ;WAIT FOR COMMAND TO COMPLETE
031410 004737 043672 JSR PC,TIMOUT ;GO TO TIMOUT SUBROUTINE
2532
2533 ;GO READ STATUS FOR READ OPERATION
2534 031414 004737 043060 JSR PC,GET ;GO READ REGISTER(S) WITH GET SUBROUTINE
031420 000404 BR 22$ ;GO TO 22$ IF NO ERROR
031422 000240 NOP ;RETURN HERE IF ERROR
031424 104000 EMT ;ERROR # DEFINED BY GET SUBROUTINE
031426 000137 031556 JMP 28$ ;GO TO 28$ IF ERROR
2535 031432 22$:
2536
2537 ;CHECK FOR ERRORS DURING READ OPERATION
2538 031432 004737 044056 JSR PC,PRIERR ;GO CHECK FOR PRIMARY ERRORS
031436 000405 BR 23$ ;GO TO 23$ IF NO ERROR
031440 000240 NOP ;RETURN HERE IF ERROR
031442 104000 EMT ;ERROR # DEFINED BY PRIERR SUBROUTINE
031444 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
031446 000137 031556 JMP 28$ ;GO TO 28$ IF ERROR
2539 031452 23$:
2540 031452 004737 056572 JSR PC,DTASTS ;GO VERIFY RESULTS OF DATA TRANSFER
031456 000405 BR 24$ ;GO TO 24$ IF NO ERROR
031460 000240 NOP ;RETURN HERE IF ERROR
031462 104000 EMT ;ERROR # DEFINED BY DTASTS SUBROUTINE
031464 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
031466 000137 031556 JMP 28$ ;GO TO 28$ IF ERROR
2541 031472 24$:
2542
2543 031472 25$:
2544 031472 004737 044710 JSR PC,SECERR ;GO CHECK FOR SECONDARY ERRORS
031476 000405 BR 26$ ;GO TO 26$ IF NO ERROR
031500 000240 NOP ;RETURN HERE IF ERROR
031502 104000 EMT ;ERROR # DEFINED BY SECERR SUBROUTINE
031504 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
031506 000137 031556 JMP 28$ ;GO TO 28$ IF ERROR

```

```

2545 031512          26$:
2546 031512 004737 042432      JSR      PC,CMPBUF      ;GO COMPARE WRITE, READ DATA BUFFERS
      031516 106442          .WORD    BUFOne+4      ;STARTING ADDRESS OF WRITE BUFFER
      031520 107446          .WORD    BUFTwo+4     ;STARTING ADDRESS OF READ BUFFER
      031522 000404          BR       27$           ;GO TO 27$ IF NO ERROR
      031524 000240          NOP                    ;RETURN HERE IF ERROR
      031526 104000          EMT                    ;ERROR # DEFINED BY CMPBUF SUBROUTINE
      031530 000137 031556      JMP      28$           ;GO TO 28$ IF ERROR
  
```

```

2547 031534          27$:
2548 031534 062737 000200 001446  ADD     #128.,RMDCO     ;ADVANCE TO NEXT THRESHOLD
2549 031542 023727 001446 001400  CMP     RMDCO,#768.    ;DONE??
2550 031550 101002          BHI     28$           ;YES!!
2551 031552 000137 030574      JMP     3$            ;DO NEXT CURRENT LEVEL
2552 031556
2553
2554
  
```

```

;*****
;*TEST 21      WRITE, WRITE CHECK W/ CURRENT LEVEL SWITCHING
;*****
TST21:
  
```

```

      031556          SCOPE          ;SCOPE CALL
      031556 000004          NOP          ;START OF TEST
      031560 000240          MOV     #STACK,SP  ;INITIALIZE STACK POINTER
      031562 012706 001100      MOV     $BASE,R0     ;R0 = UNIBUS ADDRESS
      031566 013700 001276      MOV     TSTQUE,R1    ;(R1) = DEVICE BEING TESTED
      031572 013701 001466      MOV     #21,$TESTN  ;;SET TEST NUMBER IN APT MAIL BOX
      031576 012737 000021 001226
2555 031604          1$:
2556
2557
2558
2559
  
```

```

;*****
;LOOP #1      FORMAT,WRITE,READ
;*****
  
```

```

2560 031604 004737 037316      JSR     PC,TSTPRP     ;PREPARE DEVICE FOR TEST
      031610 054130          .WORD    054130      ;TASK DESCRIPTOR AS FOLLOWS:
      ;CLEAR CONTROLLER & SELECT DEVICE
      ;VERIFY CONTROLLER CLEAR OPERATION
      ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
      ;VERIFY PACK ACKNOWLEDGE
      ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
      ;VERIFY RECALIBRATION
      031612 000404          BR       2$           ;GO TO 2$ IF NO ERROR
      031614 000240          NOP                    ;RETURN HERE IF ERROR
      031616 104000          EMT                    ;ERROR # DEFINED BY TSTPRP SUBROUTINE
      031620 000137 032562      JMP     26$          ;GO TO 26$ IF ERROR
2561 031624
2562
2563
  
```

```

;LOAD PARAMETERS AND GENERATE DATA BUFFER
      MOV     #383.,RMDCO     ;CYLINDER - 383.
      MOV     LSTRK,RMDAO     ;SET LAST TRACK AND
      MOV     #31.,RMDAO      ;LAST SECTOR
      MOV     #BUFOne,RMBAO   ;BUS ADDRESS
      MOV     #-258.*2,RMWCO  ;2 SECTORS (2'S COMP)
      MOV     #FMT16,RMOFC    ;16 BIT FORMAT
      MOV     #WH!GO,RMCS10   ;WRITE HEADER AND DATA COMMAND
2564 031624 012737 000577 001446
2565 031632 013737 001334 001420
2566 031640 112737 000037 001420
2567 031646 012737 106436 001416
2568 031654 012737 176774 001414
2569 031662 012737 010000 001444
2570 031670 012737 000063 001412
2571
2572
  
```

```

;VERIFY THAT SECTOR IS NOT BAD
      JSR     PC,BADSCT      ;CALL BAD SECTOR MODULE
      BR     3$            ;GO TO 3$ IF NO ERROR
      TYPE   ,SCTMSG        ;TYPE BAD SECTOR MESSAGE
2573
  
```

```

031710 104000 EMT ;ERROR # DEFINED BY BADSC1 SUBROUTINE
031712 000137 032562 JMP 26$ ;GO TO 26$ IF ERROR
2573 031716 3$:
2574 031716 012737 072016 001174 MOV #ONES,$TMP0 ;STARTING ADDRESS OF PATTERN
2575 031724 012737 000001 001176 MOV #1,$TMP1 ;RANGE OF PATTERN
2576 031732 004737 042174 JSR PC,GENBUF ;GO GENERATE BUFFER FOR FORMAT
2577
2578 ;LOAD PUT REGISTER INDEX TABLE FOR FORMAT OPERATION
2579 031736 012702 001553 MOV #PUTINX,R2 ;R2 = BYTE ENTRY POSITION
2580 031742 112722 000034 MOVB #RMDC,(R2)+
2581 031746 112722 000006 MOVB #RMDA,(R2)+
2582 031752 112722 000004 MOVB #RMB A,(R2)+
2583 031756 112722 000002 MOVB #RMWC,(R2)+
2584 031762 112722 000032 MOVB #RMOF,(R2)+
2585 031766 112722 000000 MOVB #RMCS1,(R2)+
2586 031772 112712 000200 MOVB #200,(R2) ;TERMINATE TABLE
2587 031776
2588 031776 004737 043330 4$: JSR PC,PUT ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
032002 000404 BR 5$ ;GO TO 5$ IF NO ERROR
032004 000240 NOP ;RETURN HERE IF ERROR
032006 104000 EMT ;ERROR # DEFINED BY PUT SUBROUTINE
032010 000137 032562 JMP 26$ ;GO TO 26$ IF ERROR
2589 032014 5$:
2590
2591 ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
032014 004737 042774 JSR PC,GETSTS ;GO TO GETSTS SUBROUTINE
2592
2593 ;WAIT FOR COMMAND TO COMPLETE
032020 004737 043672 JSR PC,TIMOUT ;GO TO TIMOUT SUBROUTINE
2594
2595 ;GO READ STATUS FOR FORMAT OPERATION
2596 032024 004737 043060 JSR PC,GET ;GO READ REGISTER(S) WITH GET SUBROUTINE
032030 000404 BR 6$ ;GO TO 6$ IF NO ERROR
032032 000240 NOP ;RETURN HERE IF ERROR
032034 104000 EMT ;ERROR # DEFINED BY GET SUBROUTINE
032036 000137 032562 JMP 26$ ;GO TO 26$ IF ERROR
2597 032042 6$:
2598
2599 ;VERIFY NO ERRORS DURING FORMAT
2600 032042 004737 056572 JSR PC,DTASTS ;GO VERIFY RESULTS OF DATA TRANSFER
032046 000405 BR 7$ ;GO TO 7$ IF NO ERROR
032050 000240 NOP ;RETURN HERE IF ERROR
032052 104000 EMT ;ERROR # DEFINED BY DTASTS SUBROUTINE
032054 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
032056 000137 032562 JMP 26$ ;GO TO 26$ IF ERROR
2601 032062 7$:
2602
2603 ;MOVE LOOP ADDRESSES TO NEXT OPERATION
2604 032062 012737 032072 001124 MOV #8$,$LPERR
2605 032070 000410 BR 9$ ;SKIP TO WRITE OPERATION
2606
2607 ;*****
2608 ;LOOP #2 WRITE,READ
2609
2610 032072 8$:
2611
2612

```

```

2613                                     ;PREPARE DEVICE FOR WRITE OPERATION
2614 032072 004737 037316             JSR   PC,TSTPRP           ;PREPARE DEVICE FOR TEST
                                     .WORD 054130             ;TASK DESCRIPTOR AS FOLLOWS:
                                                                         ;CLEAR CONTROLLER & SELECT DEVICE
                                                                         ;VERIFY CONTROLLER CLEAR OPERATION
                                                                         ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
                                                                         ;VERIFY PACK ACKNOWLEDGE
                                                                         ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
                                                                         ;VERIFY RECALIBRATION
                                                                         ;GO TO 9$ IF NO ERROR
                                                                         ;RETURN HERE IF ERROR
                                                                         ;ERROR # DEFINED BY TSTPRP SUBROUTINE
                                                                         ;GO TO 26$ IF ERROR

      032100 000404                   BR    9$
      032102 000240                   NOP
      032104 104000                   EMT
      032106 000137 032562           JMP   26$

2615 032112                         9$:
2616
2617 032112                         10$:
2618
2619                                     ;WRITE DATA TO THE DRIVE
2620 032112 012737 177000 001414     MOV   #-256.*2,RMWCO       ;2 SECTORS (2'S COMP)
2621 032120 012737 106436 001416     MOV   #BUFONE,RMBAO      ;CHANGE ADDRESS
2622 032126 012737 000061 001412     MOV   #WD!GO,RMCS10     ;WRITE DATA COMMAND
2623 032134 012737 072016 001174     MOV   #ONES,$TMP0       ;STARTING ADDRESS OF PATTERN
2624 032142 012737 000001 001176     MOV   #1,$TMP1          ;RANGE OF PATTERN
2625 032150 004737 042174             JSR   PC,GENBUF          ;GO GENERATE BUFFER FOR FORMAT
2626 032154 012702 001553             MOV   #PUTINX,R2        ;LOAD PUT REGISTER INDEX TABLE
2627 032160 112722 000006             MOVB  #RMDA,(R2)+
2628 032164 112722 000034             MOVB  #RMDC,(R2)+
2629 032170 112722 000032             MOVB  #RMOF,(R2)+
2630 032174 112722 000004             MOVB  #RMBA,(R2)+
2631 032200 112722 000002             MOVB  #RMWC,(R2)+
2632 032204 112722 000000             MOVB  #RMCS1,(R2)+
2633 032210 112722 000200             MOVB  #200,(R2)+       ;TERMINATE TABLE
2634
2635 032214 004737 043330             JSR   PC,PUT             ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      032220 000404                   BR    11$               ;GO TO 11$ IF NO ERROR
      032222 000240                   NOP                       ;RETURN HERE IF ERROR
      032224 104000                   EMT                       ;ERROR # DEFINED BY PUT SUBROUTINE
      032226 000137 032562           JMP   26$               ;GO TO 26$ IF ERROR

2636 032232                         11$:
2637
2638                                     ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
      032232 004737 042774             JSR   PC,GETSTS         ;GO TO GETSTS SUBROUTINE
2639
2640                                     ;WAIT FOR COMMAND TO COMPLETE
      032236 004737 043672             JSR   PC,TIMOUT        ;GO TO TIMOUT SUBROUTINE
2641
2642                                     ;GO READ STATUS FOR WRITE COMMAND
2643 032242 004737 043060             JSR   PC,GET           ;GO READ REGISTER(S) WITH GET SUBROUTINE
      032246 000404                   BR    12$               ;GO TO 12$ IF NO ERROR
      032250 000240                   NOP                       ;RETURN HERE IF ERROR
      032252 104000                   EMT                       ;ERROR # DEFINED BY GET SUBROUTINE
      032254 000137 032562           JMP   26$               ;GO TO 26$ IF ERROR

2644 032260                         12$:
2645
2646                                     ;CHECK FOR ERRORS DURING WRITE OPERATION
2647 032260 004737 044056             JSR   PC,PRIERR        ;GO CHECK FOR PRIMARY ERRORS
      032264 000405                   BR    13$               ;GO TO 13$ IF NO ERROR
  
```



```

032266 000240      NOP      ;RETURN HERE IF ERROR
032270 104000      EMT      ;ERROR # DEFINED BY PRIERR SUBROUTINE
032272 004736      JSR      PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
032274 000137 032562 JMP      26$      ;GO TO 26$ IF ERROR
2648 032300      13$:
2649 032300 004737 056572 JSR      PC,DTASTS ;GO VERIFY RESULTS OF DATA TRANSFER
032304 000405      BR      14$      ;GO TO 14$ IF NO ERROR
032306 000240      NOP      ;RETURN HERE IF ERROR
032310 104000      EMT      ;ERROR # DEFINED BY DTASTS SUBROUTINE
032312 004736      JSR      PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
032314 000137 032562 JMP      26$      ;GO TO 26$ IF ERROR
2650 032320      14$:
2651
2652 032320      15$:
2653 032320 004737 044710 JSR      PC,SECERR ;GO CHECK FOR SECONDARY ERRORS
032324 000405      BR      16$      ;GO TO 16$ IF NO ERROR
032326 000240      NOP      ;RETURN HERE IF ERROR
032330 104000      EMT      ;ERROR # DEFINED BY SECERR SUBROUTINE
032332 004736      JSR      PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
032334 000137 032562 JMP      26$      ;GO TO 26$ IF ERROR
2654 032340      16$:
2655
2656      ;CHANGE LOOP ADDRESSES
2657 032340 012737 032350 001124 MOV      #17$,$LPERR
2658 032346 000410      BR      18$      ;SKIP TO NEXT OPERATION
2659
2660      ;*****
2661      ;LOOP #3      READ
2662
2663 032350      17$:
2664
2665      ;PREPARE DEVICE FOR READ OPERATION
2666 032350 004737 037316 JSR      PC,TSTPRP ;PREPARE DEVICE FOR TEST
032354 054130      .WORD 054130 ;TASK DESCRIPTOR AS FOLLOWS:
;CLEAR CONTROLLER & SELECT DEVICE
;VERIFY CONTROLLER CLEAR OPERATION
;PACK ACKNOWLEDGE IF VOLUME NOT VALID
;VERIFY PACK ACKNOWLEDGE
;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
;VERIFY RECALIBRATION
032356 000404      BR      18$      ;GO TO 18$ IF NO ERROR
032360 000240      NOP      ;RETURN HERE IF ERROR
032362 104000      EMT      ;ERROR # DEFINED BY TSTPRP SUBROUTINE
032364 000137 032562 JMP      26$      ;GO TO 26$ IF ERROR
2667 032370      18$:
2668
2669 032370      19$:
2670
2671      ;READ DATA FROM DEVICE
2672 032370 012737 000051 001412 MOV      #WCD!GO,RMCS10 ;READ DATA COMMAND
2673 032376 012702 001553 MOV      #PUTINX,R2 ;LOAD PUT REGISTER INDEX TABLE
2674 032402 112722 000006 MOVB     #RMDA,(R2)+
2675 032406 112722 000032 MOVB     #RMOF,(R2)+
2676 032412 112722 000034 MOVB     #RMDC,(R2)+
2677 032416 112722 000004 MOVB     #RMBA,(R2)+
2678 032422 112722 000002 MOVB     #RMWC,(R2)+
2679 032426 112722 000000 MOVB     #RMCS1,(R2)+

```

```

2680 032432 112712 000200          MOVB    #200,(R2)
2681
2682 032436 004737 043330          JSR     PC,PUT          ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      032442 000404          BR      20$            ;GO TO 20$ IF NO ERROR
      032444 000240          NOP
      032446 104000          EMT     ;RETURN HERE IF ERROR
      032450 000137 032562          JMP     26$            ;ERROR # DEFINED BY PUT SUBROUTINE
      ;GO TO 26$ IF ERROR
2683 032454          20$:
2684
2685          ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
      032454 004737 042774          JSR     PC,GETSTS      ;GO TO GETSTS SUBROUTINE
2686
2687          ;WAIT FOR COMMAND TO COMPLETE
      032460 004737 043672          JSR     PC,TIMOUT     ;GO TO TIMOUT SUBROUTINE
2688
2689          ;GO READ STATUS FOR READ OPERATION
2690 032464 004737 043060          JSR     PC,GET        ;GO READ REGISTER(S) WITH GET SUBROUTINE
      032470 000404          BR      21$            ;GO TO 21$ IF NO ERROR
      032472 000240          NOP
      032474 104000          EMT     ;RETURN HERE IF ERROR
      032476 000137 032562          JMP     26$            ;ERROR # DEFINED BY GET SUBROUTINE
      ;GO TO 26$ IF ERROR
2691 032502          21$:
2692
2693          ;CHECK FOR ERRORS DURING READ OPERATION
2694 032502 004737 044056          JSR     PC,PRIERR     ;GO CHECK FOR PRIMARY ERRORS
      032506 000405          BR      22$            ;GO TO 22$ IF NO ERROR
      032510 000240          NOP
      032512 104000          EMT     ;RETURN HERE IF ERROR
      032514 004736          JSR     PC,@(SP)+     ;ERROR # DEFINED BY PRIERR SUBROUTINE
      032516 000137 032562          JMP     26$            ;GO BACK FOR MORE ERROR CHECKS
      ;GO TO 26$ IF ERROR
2695 032522          22$:
2696 032522 004737 056572          JSR     PC,DTASTS     ;GO VERIFY RESULTS OF DATA TRANSFER
      032526 000405          BR      23$            ;GO TO 23$ IF NO ERROR
      032530 000240          NOP
      032532 104000          EMT     ;RETURN HERE IF ERROR
      032534 004736          JSR     PC,@(SP)+     ;ERROR # DEFINED BY DTASTS SUBROUTINE
      032536 000137 032562          JMP     26$            ;GO BACK FOR MORE ERROR CHECKS
      ;GO TO 26$ IF ERROR
2697 032542          23$:
2698
2699          24$:
2700 032542 004737 044710          JSR     PC,SECERR     ;GO CHECK FOR SECONDARY ERRORS
      032546 000405          BR      25$            ;GO TO 25$ IF NO ERROR
      032550 000240          NOP
      032552 104000          EMT     ;RETURN HERE IF ERROR
      032554 004736          JSR     PC,@(SP)+     ;ERROR # DEFINED BY SECERR SUBROUTINE
      032556 000137 032562          JMP     26$            ;GO BACK FOR MORE ERROR CHECKS
      ;GO TO 26$ IF ERROR
2701 032562          25$:
2702
2703 032562          26$:
2704
2705          ;*****
          ;*TEST 22      WRITE, READ EARLY PEAK SHIFT
          ;*****
          TST22:
          032562          SCOPE          ;SCOPE CALL
          032562 000004          NOP             ;START OF TEST
          032564 000240          MOV     #STACK,SP ;INITIALIZE STACK POINTER
          032566 012706 001100
  
```

```

032572 013700 001276      MOV    $BASE,R0      ;R0 = UNIBUS ADDRESS
032574 013701 001466      MOV    TSTQUE,R1     ;(R1) = DEVICE BEING TESTED
032602 012737 000022 001226  MOV    #22,$TESTN    ;;SET TEST NUMBER IN APT MAIL BOX

2706
2707
2708
2709
2710 032610
2711
2712
2713 032610 004737 037316
032614 154130
;*****
;LOOP #1      FORMAT,WRITE,READ

1$:
;PREPARE THE DEVICE FOR FORMAT OPERATION
      JSR    PC,TSTPRP  ;PREPARE DEVICE FOR TEST
      .WORD 154130      ;TASK DESCRIPTOR AS FOLLOWS:
                        ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
                        ;CLEAR CONTROLLER & SELECT DEVICE
                        ;VERIFY CONTROLLER CLEAR OPERATION
                        ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
                        ;VERIFY PACK ACKNOWLEDGE
                        ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
                        ;VERIFY RECALIBRATION
                        ;GO TO 2$ IF NO ERROR
                        ;RETURN HERE IF ERROR
                        ;ERROR # DEFINED BY TSTPRP SUBROUTINE
                        ;GO TO 25$ IF ERROR

      BR     2$
      NOP
      EMT
      JMP    25$

2714 032630
2715
2716
2717 032630 012737 000000 001446
2718 032636 012737 000000 001420
2719 032644 012737 106436 001416
2720 032652 012737 177376 001414
2721 032660 012737 010000 001444
2722 032666 012737 000063 001412
2723
2724
;LOAD PARAMETERS AND GENERATE DATA BUFFER
      MOV    #0,RMDCO      ;CYLINDER = 0
      MOV    #0,RMDAO      ;TRACK = 0, SECTOR = 0
      MOV    #BUFONE,RMBAO ;BUS ADDRESS
      MOV    #-258.,RMWCO   ;2 + 256. WORDS (2'S COMP)
      MOV    #FMT16,RMOFO  ;16 BIT FORMAT
      MOV    #WH!GO,RMCS10 ;WRITE HEADER AND DATA COMMAND

;VERIFY THAT SECTOR IS NOT BAD
      JSR    PC,BADSCT     ;CALL BAD SECTOR MODULE
      BR     3$           ;GO TO 3$ IF NO ERROR
      TYPE  ,SCTMSG       ;TYPE BAD SECTOR MESSAGE
      EMT
      JMP    25$         ;ERROR # DEFINED BY BADSCT SUBROUTINE
                        ;GO TO 25$ IF ERROR

3$:
      MOV    #EARLY,$TMP0  ;STARTING ADDRESS OF PATTERN
      MOV    #1,$TMP1      ;RANGE OF PATTERN
      JSR    PC,GENBUF     ;GO GENERATE BUFFER FOR FORMAT

;LOAD PUT REGISTER INDEX TABLE FOR FORMAT OPERATION
      MOV    #PUTINX,R2    ;R2 = BYTE ENTRY POSITION
      MOVB  #RMDC,(R2)+
      MOVB  #RMDA,(R2)+
      MOVB  #RMBA,(R2)+
      MOVB  #RMWC,(R2)+
      MOVB  #RMOF,(R2)+
      MOVB  #RMCS1,(R2)+
      MOVB  #200,(R2)     ;TERMINATE TABLE

4$:
      JSR    PC,PUT        ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      BR     5$           ;GO TO 5$ IF NO ERROR
      NOP                ;RETURN HERE IF ERROR
033002 000240
  
```

```

2741 033004 104000          EMT          ;ERROR # DEFINED BY PUT SUBROUTINE
2742 033006 000137 033570  JMP 25$      ;GO TO 25$ IF ERROR
2743 033012          5$:
                ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
                JSR PC,GETSTS      ;GO TO GETSTS SUBROUTINE
2744 033012 004737 042774
2745          ;WAIT FOR COMMAND TO COMPLETE
                JSR PC,TIMOUT      ;GO TO TIMEOUT SUBROUTINE
2746 033016 004737 043672
2747          ;GO READ STATUS FOR FORMAT OPERATION
2748 033022 004737 043060  JSR PC,GET      ;GO READ REGISTER(S) WITH GET SUBROUTINE
                033026 000404      BR 6$          ;GO TO 6$ IF NO ERROR
                033030 000240      NOP           ;RETURN HERE IF ERROR
                033032 104000      EMT          ;ERROR # DEFINED BY GET SUBROUTINE
                033034 000137 033570 JMP 25$      ;GO TO 25$ IF ERROR
2749 033040          6$:
2750          ;VERIFY NO ERRORS DURING FORMAT
2751          JSR PC,DTASTS      ;GO VERIFY RESULTS OF DATA TRANSFER
2752 033040 004737 056572  BR 7$          ;GO TO 7$ IF NO ERROR
                033044 000405      NOP           ;RETURN HERE IF ERROR
                033046 000240      NOP           ;ERROR # DEFINED BY DTASTS SUBROUTINE
                033050 104000      EMT          ;GO BACK FOR MORE ERROR CHECKS
                033052 004736      JSR PC,@(SP)+  ;GO TO 25$ IF ERROR
                033054 000137 033570 JMP 25$
2753 033060          7$:
2754          ;MOVE LOOP ADDRESSES TO NEXT OPERATION
2755          MOV #8$,$LPERR
2756 033060 012737 033070 001124 BR 9$
2757 033066 000410
2758          ;*****
2759          ;LOOP #2      WRITE,READ
2760
2761          8$:
2762 033070          ;PREPARE DEVICE FOR WRITE OPERATION
2763          JSR PC,TSTPRP      ;PREPARE DEVICE FOR TEST
2764 033070 004737 037316  .WORD 154130 ;TASK DESCRIPTOR AS FOLLOWS:
                ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
                ;CLEAR CONTROLLER & SELECT DEVICE
                ;VERIFY CONTROLLER CLEAR OPERATION
                ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
                ;VERIFY PACK ACKNOWLEDGE
                ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
                ;VERIFY RECALIBRATION
                033076 000404      BR 9$          ;GO TO 9$ IF NO ERROR
                033100 000240      NOP           ;RETURN HERE IF ERROR
                033102 104000      EMT          ;ERROR # DEFINED BY TSTPRP SUBROUTINE
                033104 000137 033570 JMP 25$      ;GO TO 25$ IF ERROR
2766 033110          9$:
2767          ;WRITE DATA TO THE DRIVE
2768          10$:
2769 033110          MOV #-256.,RMWCO ;CHANGE WORD COUNT
2770 033110 012737 177400 001414 MOV #BUFONE+4,RMBAO ;CHANGE ADDRESS
2771 033116 012737 106442 001416 MOV #WD.GO,RMCS10   ;WRITE DATA COMMAND
2772 033124 012737 000061 001412
  
```

```

2773 033132 012702 001553      MOV      #PUTINX,R2          ;LOAD PUT REGISTER INDEX TABLE
2774 033136 112722 000006      MOVB    #RMDA,(R2)+
2775 033142 112722 000034      MOVB    #RMDC,(R2)+
2776 033146 112722 000032      MOVB    #RMOF,(R2)+
2777 033152 112722 000004      MOVB    #RMBA,(R2)+
2778 033156 112722 000002      MOVB    #RMWC,(R2)+
2779 033162 112722 000000      MOVB    #RMCS1,(R2)+
2780 033166 112722 000200      MOVB    #200,(R2)+          ;TERMINATE TABLE
2781
2782 033172 004737 043330      JSR     PC,PUT              ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      033176 000404      BR     11$                 ;GO TO 11$ IF NO ERROR
      033200 000240      NOP
      033202 104000      EMT
      033204 000137 033570      JMP     25$                 ;GO TO 25$ IF ERROR
2783 033210      11$:
2784
2785      ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
      033210 004737 042774      JSR     PC,GETSTS          ;GO TO GETSTS SUBROUTINE
2786
2787      ;WAIT FOR COMMAND TO COMPLETE
      033214 004737 043672      JSR     PC,TIMOUT         ;GO TO TIMOUT SUBROUTINE
2788
2789      ;GO READ STATUS FOR WRITE COMMAND
2790 033220 004737 043060      JSR     PC,GET            ;GO READ REGISTER(S) WITH GET SUBROUTINE
      033224 000404      BR     12$                 ;GO TO 12$ IF NO ERROR
      033226 000240      NOP
      033230 104000      EMT
      033232 000137 033570      JMP     25$                 ;GO TO 25$ IF ERROR
2791 033236      12$:
2792
2793      ;CHECK FOR ERRORS DURING WRITE OPERATION
2794 033236 004737 044056      JSR     PC,PRIERR         ;GO CHECK FOR PRIMARY ERRORS
      033242 000405      BR     13$                 ;GO TO 13$ IF NO ERROR
      033244 000240      NOP
      033246 104000      EMT
      033250 004736      JSR     PC,@(SP)+         ;GO BACK FOR MORE ERROR CHECKS
      033252 000137 033570      JMP     25$                 ;GO TO 25$ IF ERROR
2795 033256      13$:
2796 033256 004737 056572      JSR     PC,DTASTS        ;GO VERIFY RESULTS OF DATA TRANSFER
      033262 000405      BR     14$                 ;GO TO 14$ IF NO ERROR
      033264 000240      NOP
      033266 104000      EMT
      033270 004736      JSR     PC,@(SP)+        ;GO BACK FOR MORE ERROR CHECKS
      033272 000137 033570      JMP     25$                 ;GO TO 25$ IF ERROR
2797 033276      14$:
2798 033276 004737 044710      JSR     PC,SECERR        ;GO CHECK FOR SECONDARY ERRORS
      033302 000405      BR     15$                 ;GO TO 15$ IF NO ERROR
      033304 000240      NOP
      033306 104000      EMT
      033310 004736      JSR     PC,@(SP)+        ;GO BACK FOR MORE ERROR CHECKS
      033312 000137 033570      JMP     25$                 ;GO TO 25$ IF ERROR
2799 033316      15$:
2800
2801      ;CHANGE LOOP ADDRESSES
2802 033316 012737 033326 001124      MOV     #16$,$LPERR
2803 033324 000410      BR     17$
2804

```

```

2805
2806
2807
2808 033326
2809
2810
2811 033326 004737 037316
      033332 154130
      033334 000404
      033336 000240
      033340 104000
      033342 000137 033570
2812 033346
2813
2814
2815 033346
2816 033346 012737 000071 001412
2817 033354 012737 107446 001416
2818 033362 012702 001553
2819 033366 112722 000006
2820 033372 112722 000032
2821 033376 112722 000034
2822 033402 112722 000004
2823 033406 112722 000002
2824 033412 112722 000000
2825 033416 112712 000200
2826
2827 033422 004737 043330
      033426 000404
      033430 000240
      033432 104000
      033434 000137 033570
2828 033440
2829
2830
      033440 004737 042774
2831
2832
      033444 004737 043672
2833
2834
2835 033450 004737 043060
      033454 000404
      033456 000240
      033460 104000
      033462 000137 033570
2836 033466
2837
2838
2839 033466 004737 044056

```

```

*****
:LOOP #3      READ
16$:
:PREPARE DEVICE FOR READ OPERATION
      JSR      PC,TSTPRP      ;PREPARE DEVICE FOR TEST
      .WORD   154130          ;TASK DESCRIPTOR AS FOLLOWS:
                                ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
                                ;CLEAR CONTROLLER & SELECT DEVICE
                                ;VERIFY CONTROLLER CLEAR OPERATION
                                ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
                                ;VERIFY PACK ACKNOWLEDGE
                                ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
                                ;VERIFY RECALIBRATION
                                ;GO TO 17$ IF NO ERROR
                                ;RETURN HERE IF ERROR
                                ;ERROR # DEFINED BY TSTPRP SUBROUTINE
                                ;GO TO 25$ IF ERROR
      BR      17$
      NOP
      EMT
      JMP     25$
17$:
:READ DATA FROM DEVICE
18$:
      MOV     #RD!GO,RMCS10      ;READ DATA COMMAND
      MOV     #BUFTWO-4,RMBA0    ;CHANGE BUFFER
      MOV     #PUTINX,R2        ;LOAD PUT REGISTER INDEX TABLE
      MOVB   #RMDA,(R2)+
      MOVB   #RMOF,(R2)+
      MOVB   #RMDC,(R2)+
      MOVB   #RMBA,(R2)+
      MOVB   #RMWC,(R2)+
      MOVB   #RMCS1,(R2)+
      MOVB   #200,(R2)
      JSR     PC,PUT            ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      BR     19$              ;GO TO 19$ IF NO ERROR
      NOP
      EMT
      JMP     25$              ;GO TO 25$ IF ERROR
19$:
:SETUP GET INDEX TABLE TO READ ALL REGISTERS
      JSR     PC,GETSTS        ;GO TO GETSTS SUBROUTINE
:WAIT FOR COMMAND TO COMPLETE
      JSR     PC,TIMOUT        ;GO TO TIMOUT SUBROUTINE
:GO READ STATUS FOR READ OPERATION
      JSR     PC,GET            ;GO READ REGISTER(S) WITH GET SUBROUTINE
      BR     20$              ;GO TO 20$ IF NO ERROR
      NOP
      EMT
      JMP     25$              ;GO TO 25$ IF ERROR
20$:
:CHECK FOR ERRORS DURING READ OPERATION
      JSR     PC,PRIERR        ;GO CHECK FOR PRIMARY ERRORS

```

```

033472 000405 BR 21$ ;GO TO 21$ IF NO ERROR
033474 000240 NOP ;RETURN HERE IF ERROR
033476 104000 EMT ;ERROR # DEFINED BY PRIERP SUBROUTINE
033500 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
033502 000137 033570 JMP 25$ ;GO TO 25$ IF ERROR
2840 033506 21$:
2841 033506 004737 056572 JSR PC,DTASTS ;GO VERIFY RESULTS OF DATA TRANSFER
033512 000405 BR 22$ ;GO TO 22$ IF NO ERROR
033514 000240 NOP ;RETURN HERE IF ERROR
033516 104000 EMT ;ERROR # DEFINED BY DTASTS SUBROUTINE
033520 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
033522 000137 033570 JMP 25$ ;GO TO 25$ IF ERROR
2842 033526 22$:
2843 033526 004737 044710 JSR PC,SECERR ;GO CHECK FOR SECONDARY ERRORS
033532 000405 BR 23$ ;GO TO 23$ IF NO ERROR
033534 000240 NOP ;RETURN HERE IF ERROR
033536 104000 EMT ;ERROR # DEFINED BY SECERR SUBROUTINE
033540 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
033542 000137 033570 JMP 25$ ;GO TO 25$ IF ERROR
2844 033546 23$:
2845 033546 004737 042432 JSR PC,CMPBUF ;GO COMPARE WRITE, READ DATA BUFFERS
033552 106442 .WORD BUFOFF+4 ;STARTING ADDRESS OF WRITE BUFFER
033554 107446 .WORD BUFTWO+4 ;STARTING ADDRESS OF READ BUFFER
033556 000404 BR 24$ ;GO TO 24$ IF NO ERROR
033560 000240 NOP ;RETURN HERE IF ERROR
033562 104000 EMT ;ERROR # DEFINED BY CMPBUF SUBROUTINE
033564 000137 033570 JMP 25$ ;GO TO 25$ IF ERROR
2846 033570 24$:
2847
2848 033570 25$:
2849
2850

```

```

;*****
;*TEST 23 WRITE, READ MIXED PEAK SHIFT
;*****
TST23:

```

```

033570
033570 000004 SCOPE ;SCOPE CALL
033572 000240 NOP ;START OF TEST
033574 012706 001100 MOV #STACK,SP ;INITIALIZE STACK POINTER
033600 013700 001276 MOV $BASE,R0 ;R0 - UNIBUS ADDRESS
033604 013701 001466 MOV TSTQUE,R1 ;(R1) - DEVICE BEING TESTED
033610 012737 000023 001226 MOV #23,$TESTN ;SET TEST NUMBER IN APT MAIL BOX

```

```

;*****
;LOOP #1 FORMAT,WRITE,READ

```

```

2851
2852
2853
2854
2855 033616 1$:
2856
2857 ;PREPARE THE DEVICE FOR FORMAT OPERATION
2858 033616 004737 037316 JSR PC,TSTPRP ;PREPARE DEVICE FOR TEST
033622 154130 .WORD 154130 ;TASK DESCRIPTOR AS FOLLOWS:
;SELECT DEVICE & VERIFY DEVICE AVAILABLE
;CLEAR CONTROLLER & SELECT DEVICE
;VERIFY CONTROLLER CLEAR OPERATION
;PACK ACKNOWLEDGE IF VOLUME NOT VALID
;VERIFY PACK ACKNOWLEDGE
;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
;VERIFY RECALIBRATION

```

```

033624 000404 BR 2$ ;GO TO 2$ IF NO ERROR
033626 000240 NOP ;RETURN HERE IF ERROR
033630 104000 EMT ;ERROR # DEFINED BY TSTPRP SUBROUTINE
033632 000137 034576 JMP 25$ ;GO TO 25$ IF ERROR
2859 033636 2$:
2860
2861 ;LOAD PARAMETERS AND GENERATE DATA BUFFER
2862 033636 012737 000000 001446 MOV #0,RMDC0 ;CYLINDER = 0
2863 033644 012737 000000 001420 MOV #0,RMDA0 ;TRACK = 0, SECTOR = 0
2864 033652 012737 106436 001416 MOV #BJFONE,RMBA0 ;BUS ADDRESS
2865 033660 012737 177376 001414 MOV #-256.,RMWCO ;2 + 256. WORDS (2'S COMP)
2866 033666 012737 010000 001444 MOV #FMT16,RMOFO ;16 BIT FORMAT
2867 033674 012737 000063 001412 MOV #WH!GO,RMCS10 ;WRITE HEADER AND DATA COMMAND
2868
2869 ;VERIFY THAT SECTOR IS NOT BAD
033702 004737 040242 JSR PC,BADSCT ;CALL BAD SECTOR MODULE
033706 000405 BR 3$ ;GO TO 3$ IF NO ERROR
033710 104401 070426 TYPE ,SCTMSG ;TYPE BAD SECTOR MESSAGE
033714 104000 EMT ;ERROR # DEFINED BY BADSCT SUBROUTINE
033716 000137 034576 JMP 25$ ;GO TO 25$ IF ERROR
2870 033722 3$:
2871 033722 012737 071756 001174 MOV #MIXED,$TMP0 ;STARTING ADDRESS OF PATTERN
2872 033730 012737 000200 001176 MOV #128.,$TMP1 ;RANGE OF PATTERN
2873 033736 004737 042174 JSR PC,GENBUF ;GO GENERATE BUFFER FOR FORMAT
2874
2875 ;LOAD PUT REGISTER INDEX TABLE FOR FORMAT OPERATION
2876 033742 012702 001553 MOV #PUTINX,R2 ;R2 = BYTE ENTRY POSITION
2877 033746 112722 000034 MOVB #RMDC,(R2)+
2878 033752 112722 000006 MOVB #RMDA,(R2)+
2879 033756 112722 000004 MOVB #RMBA,(R2)+
2880 033762 112722 000002 MOVB #RMWC,(R2)+
2881 033766 112722 000032 MOVB #RMOF,(R2)+
2882 033772 112722 000000 MOVB #RMCS1,(R2)+
2883 033776 112712 000200 MOVB #200,(R2) ;TERMINATE TABLE
2884 034002 4$:
2885 034002 004737 043330 JSR PC,PUT ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
034006 000404 BR 5$ ;GO TO 5$ IF NO ERROR
034010 000240 NOP ;RETURN HERE IF ERROR
034012 104000 EMT ;ERROR # DEFINED BY PUT SUBROUTINE
034014 000137 034576 JMP 25$ ;GO TO 25$ IF ERROR
2886 034020 5$:
2887
2888 ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
034020 004737 042774 JSR PC,GETSTS ;GO TO GETSTS SUBROUTINE
2889
2890 ;WAIT FOR COMMAND TO COMPLETE
034024 004737 043672 JSR PC,TIMOUT ;GO TO TIMOUT SUBROUTINE
2891
2892 ;GO READ STATUS FOR FORMAT OPERATION
2893 034030 004737 043060 JSR PC,GET ;GO READ REGISTER(S) WITH GET SUBROUTINE
034034 000404 BR 6$ ;GO TO 6$ IF NO ERROR
034036 000240 NOP ;RETURN HERE IF ERROR
034040 104000 EMT ;ERROR # DEFINED BY GET SUBROUTINE
034042 000137 034576 JMP 25$ ;GO TO 25$ IF ERROR
2894 034046 6$:
2895
2896 ;VERIFY NO ERRORS DURING FORMAT

```



```

2897 034046 004737 056572      JSR    PC,DTASTS      ;GO VERIFY RESULTS OF DATA TRANSFER
      034052 000405          BR      7$           ;GO TO 7$ IF NO ERROR
      034054 000240          NOP          ;RETURN HERE IF ERROR
      034056 104000          EMT          ;ERROR # DEFINED BY DTASTS SUBROUTINE
      034060 004736          JSR    PC,@(SP)+    ;GO BACK FOR MORE ERROR CHECKS
      034062 000137 034576    JMP     25$         ;GO TO 25$ IF ERROR

2898 034066      7$:
2899
2900      ;MOVE LOOP ADDRESSES TO NEXT OPERATION
2901 034066 012737 034076 001124  MOV     #8$, $LPERR
2902 034074 000410          BR      9$           ;SKIP TO WRITE OPERATION
2903
2904      ;*****
2905      ;LOOP #2      WRITE,READ
2906
2907 034076      8$:
2908
2909      ;PREPARE DEVICE FOR WRITE OPERATION
2910 034076 004737 037316  JSR    PC,TSTPRP    ;PREPARE DEVICE FOR TEST
      034102 154130      .WORD 154130      ;TASK DESCRIPTOR AS FOLLOWS:
      ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
      ;CLEAR CONTROLLER & SELECT DEVICE
      ;VERIFY CONTROLLER CLEAR OPERATION
      ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
      ;VERIFY PACK ACKNOWLEDGE
      ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
      ;VERIFY RECALIBRATION
      034104 000404          BR      9$           ;GO TO 9$ IF NO ERROR
      034106 000240          NOP          ;RETURN HERE IF ERROR
      034110 104000          EMT          ;ERROR # DEFINED BY TSTPRP SUBROUTINE
      034112 000137 034576    JMP     25$         ;GO TO 25$ IF ERROR

2911 034116      9$:
2912
2913      ;WRITE DATA TO THE DRIVE
2914 034116      10$:
2915 034116 012737 177400 001414  MOV     #-256, RMWCO ;CHANGE WORD COUNT
2916 034124 012737 106442 001416  MOV     #BUFONE+4, RMBAO ;CHANGE ADDRESS
2917 034132 012737 000061 001412  MOV     #WD!GO, RMCS10 ;WRITE DATA COMMAND
2918 034140 012702 001553          MOV     #PUTINX, R2    ;LOAD PUT REGISTER INDEX TABLE
2919 034144 112722 000006          MOV     #RMDA, (R2)+
2920 034150 112722 000034          MOV     #RMDC, (R2)+
2921 034154 112722 000032          MOV     #RMOF, (R2)+
2922 034160 112722 000004          MOV     #RMBA, (R2)+
2923 034164 112722 000002          MOV     #RMWC, (R2)+
2924 034170 112722 000000          MOV     #RMCS1, (R2)+
2925 034174 112722 000200          MOV     #200, (R2)+ ;TERMINATE TABLE
2926
2927 034200 004737 043330      JSR    PC,PUT        ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      034204 000404          BR      11$         ;GO TO 11$ IF NO ERROR
      034206 000240          NOP          ;RETURN HERE IF ERROR
      034210 104000          EMT          ;ERROR # DEFINED BY PUT SUBROUTINE
      034212 000137 034576    JMP     25$         ;GO TO 25$ IF ERROR

2928 034216      11$:
2929
2930      ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
2931 034216 004737 042774      JSR    PC,GETSTS    ;GO TO GETSTS SUBROUTINE
  
```

```

2932      ;WAIT FOR COMMAND TO COMPLETE
034222 004737 043672      JSR      PC,TIMOUT      ;GO TO TIMEOUT SUBROUTINE
2933
2934      ;GO READ STATUS FOR WRITE COMMAND
2935 034226 004737 043060      JSR      PC,GET          ;GO READ REGISTER(S) WITH GET SUBROUTINE
034232 000404      BR      12$            ;GO TO 12$ IF NO ERROR
034234 000240      NOP                      ;RETURN HERE IF ERROR
034236 104000      EMT                      ;ERROR # DEFINED BY GET SUBROUTINE
034240 000137 034576      JMP      25$            ;GO TO 25$ IF ERROR
2936 034244      12$:
2937
2938      ;CHECK FOR ERRORS DURING WRITE OPERATION
2939 034244 004737 044056      JSR      PC,PRIERR      ;GO CHECK FOR PRIMARY ERRORS
034250 000405      BR      13$            ;GO TO 13$ IF NO ERROR
034252 000240      NOP                      ;RETURN HERE IF ERROR
034254 104000      EMT                      ;ERROR # DEFINED BY PRIERR SUBROUTINE
034256 004736      JSR      PC,@(SP)+      ;GO BACK FOR MORE ERROR CHECKS
034260 000137 034576      JMP      25$            ;GO TO 25$ IF ERROR
2940 034264      13$:
2941 034264 004737 056572      JSR      PC,DTASTS      ;GO VERIFY RESULTS OF DATA TRANSFER
034270 000405      BR      14$            ;GO TO 14$ IF NO ERROR
034272 000240      NOP                      ;RETURN HERE IF ERROR
034274 104000      EMT                      ;ERROR # DEFINED BY DTASTS SUBROUTINE
034276 004736      JSR      PC,@(SP)+      ;GO BACK FOR MORE ERROR CHECKS
034300 000137 034576      JMP      25$            ;GO TO 25$ IF ERROR
2942 034304      14$:
2943 034304 004737 044710      JSR      PC,SECERR      ;GO CHECK FOR SECONDARY ERRORS
034310 000405      BR      15$            ;GO TO 15$ IF NO ERROR
034312 000240      NOP                      ;RETURN HERE IF ERROR
034314 104000      EMT                      ;ERROR # DEFINED BY SECERR SUBROUTINE
034316 004736      JSR      PC,@(SP)+      ;GO BACK FOR MORE ERROR CHECKS
034320 000137 034576      JMP      25$            ;GO TO 25$ IF ERROR
2944 034324      15$:
2945
2946      ;CHANGE LOOP ADDRESSES
2947 034324 012737 034334 001124      MOV      #16$,$LPERR
2948 034332 000410      BR      17$            ;SKIP TO NEXT OPERATION
2949
2950      ;*****
2951      ;LOOP #3      READ
2952
2953 034334      16$:
2954
2955      ;PREPARE DEVICE FOR READ OPERATION
2956 034334 004737 037316      JSR      PC,TSTPRP      ;PREPARE DEVICE FOR TEST
034340 154130      .WORD 154130          ;TASK DESCRIPTOR AS FOLLOWS:
                                ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
                                ;CLEAR CONTROLLER & SELECT DEVICE
                                ;VERIFY CONTROLLER CLEAR OPERATION
                                ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
                                ;VERIFY PACK ACKNOWLEDGE
                                ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
                                ;VERIFY RECALIBRATION
034342 000404      BR      17$            ;GO TO 17$ IF NO ERROR
034344 000240      NOP                      ;RETURN HERE IF ERROR
034346 104000      EMT                      ;ERROR # DEFINED BY TSTPRP SUBROUTINE
034350 000137 034576      JMP      25$            ;GO TO 25$ IF ERROR

```

```

2957 034354      17$:
2958
2959      ;READ DATA FROM DEVICE
2960 034354      18$:
2961 034354 012737 107446 001416      MOV      #BUFTWO+4,RMBA0      ;CHANGE BUFFER
2962 034362 012737 000071 001412      MOV      #RD!GO,RMCS10      ;READ DATA COMMAND
2963 034370 012702 001553      MOV      #PUTINX,R2      ;LOAD PUT REGISTER INDEX TABLE
2964 034374 112722 000006      MOV      #RMDA,(R2)+
2965 034400 112722 000032      MOV      #RMOF,(R2)+
2966 034404 112722 000034      MOV      #RMDC,(R2)+
2967 034410 112722 000004      MOV      #RMBA,(R2)+
2968 034414 112722 000002      MOV      #RMWC,(R2)+
2969 034420 112722 000000      MOV      #RMCS1,(R2)+
2970 034424 112712 000200      MOV      #200,(R2)
2971
2972 034430 004737 043330      JSR      PC,PUT      ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      034434 000404      BR      19$      ;GO TO 19$ IF NO ERROR
      034436 000240      NOP      ;RETURN HERE IF ERROR
      034440 104000      EMT      ;ERROR # DEFINED BY PUT SUBROUTINE
      034442 000137 034576      JMP      25$      ;GO TO 25$ IF ERROR
2973 034446      19$:
2974
2975      ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
      JSR      PC,GETSTS      ;GO TO GETSTS SUBROUTINE
2976
2977      ;WAIT FOR COMMAND TO COMPLETE
      JSR      PC,TIMOUT      ;GO TO TIMEOUT SUBROUTINE
2978
2979      ;GO READ STATUS FOR READ OPERATION
2980 034456 004737 043060      JSR      PC,GET      ;GO READ REGISTER(S) WITH GET SUBROUTINE
      034462 000404      BR      20$      ;GO TO 20$ IF NO ERROR
      034464 000240      NOP      ;RETURN HERE IF ERROR
      034466 104000      EMT      ;ERROR # DEFINED BY GET SUBROUTINE
      034470 000137 034576      JMP      25$      ;GO TO 25$ IF FRROR
2981 034474      20$:
2982
2983      ;CHECK FOR ERRORS DURING READ OPERATION
2984 034474 004737 044056      JSR      PC,PRIERR      ;GO CHECK FOR PRIMARY ERRORS
      034500 000405      BR      21$      ;GO TO 21$ IF NO ERROR
      034502 000240      NOP      ;RETURN HERE IF ERROR
      034504 104000      EMT      ;ERROR # DEFINED BY PRIERR SUBROUTINE
      034506 004736      JSR      PC,@(SP)+      ;GO BACK FOR MORE ERROR CHECKS
      034510 000137 034576      JMP      25$      ;GO TO 25$ IF ERROR
2985 034514      21$:
2986 034514 004737 056572      JSR      PC,DTASTS      ;GO VERIFY RESULTS OF DATA TRANSFER
      034520 000405      BR      22$      ;GO TO 22$ IF NO ERROR
      034522 000240      NOP      ;RETURN HERE IF ERROR
      034524 104000      EMT      ;ERROR # DEFINED BY DTASTS SUBROUTINE
      034526 004736      JSR      PC,@(SP)+      ;GO BACK FOR MORE ERROR CHECKS
      034530 000137 034576      JMP      25$      ;GO TO 25$ IF ERROR
2987 034534      22$:
2988 034534 004737 044710      JSR      PC,SECERR      ;GO CHECK FOR SECONDARY ERRORS
      034540 000405      BR      23$      ;GO TO 23$ IF NO ERROR
      034542 000240      NOP      ;RETURN HERE IF ERROR
      034544 104000      EMT      ;ERROR # DEFINED BY SECERR SUBROUTINE
      034546 004736      JSR      PC,@(SP)+      ;GO BACK FOR MORE ERROR CHECKS
      034550 000137 034576      JMP      25$      ;GO TO 25$ IF ERROR
  
```

```

2989 034554          23$:      JSR      PC,CMPBUF      ;GO COMPARE WRITE, READ DATA BUFFERS
2990 034554 004737 C42432      .WORD   BUFONE+4      ;STARTING ADDRESS OF WRITE BUFFER
      034560 106442      .WORD   BUFTWO+4     ;STARTING ADDRESS OF READ BUFFER
      034562 107446      BR       24$          ;GO TO 24$ IF NO ERROR
      034564 000404      NOP      ;RETURN HERE IF ERROR
      034566 000240      EMT      ;ERROR # DEFINED BY CMPBUF SUBROUTINE
      034570 104000      JMP      25$          ;GO TO 25$ IF ERROR
      034572 000137 034576
2991 034576          24$:
2992
2993 034576          25$:
2994
2995
      ;*****
      ;*TEST 24      WRITE, READ EACH TRACK
      ;*****
      TST24:
      SCOPE          ;SCOPE CALL
      NOP            ;START OF TEST
      MOV      #STACK,SP ;INITIALIZE STACK POINTER
      MOV      $BASE,R0  ;R0 - UNIBUS ADDRESS
      MOV      TSTQUE,R1 ;(R1) = DEVICE BEING TESTED
      MOV      #24,$TESTN ;SET TEST NUMBER IN APT MAIL BOX

      ;*****
      ;LOOP #1      FORMAT,WRITE,READ
      1$:
      ;PREPARE THE DEVICE FOR FORMAT OPERATION
      JSR      PC,TSTPRP ;PREPARE DEVICE FOR TEST
      .WORD   154130    ;TASK DESCRIPTOR AS FOLLOWS:
      ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
      ;CLEAR CONTROLLER & SELECT DEVICE
      ;VERIFY CONTROLLER CLEAR OPERATION
      ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
      ;VERIFY PACK ACKNOWLEDGE
      ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
      ;VERIFY RECALIBRATION
      BR       2$          ;GO TO 2$ IF NO ERROR
      NOP      ;RETURN HERE IF ERROR
      EMT      ;ERROR # DEFINED BY TSTPRP SUBROUTINE
      JMP      26$        ;GO TO 26$ IF ERROR

      2$:
      ;LOAD PARAMETERS AND GENERATE DATA BUFFER
      MOV      #0,RMDCO   ;CYLINDER = 0
      MOV      #0,RMDAO   ;TRACK = 0, SECTOR = 0
      3$:
      MOV      #BUFONE,RMBAO ;BUS ADDRESS
      MOV      #-258,RMWCO  ;2 + 256 WORDS (2'S COMP)
      MOV      #FMT16,RMFO  ;16 BIT FORMAT
      MOV      #WH!GO,RMCS10 ;WRITE HEADER AND DATA COMMAND

      ;VERIFY THAT SECTOR IS NOT BAD
      JSR      PC,BADSECT ;CALL BAD SECTOR MODULE
      BR       4$          ;GO TO 4$ IF NO ERROR
      TYPE    ,SCTMSG     ;TYPE BAD SECTOR MESSAGE
      034600 000240
      034602 012706 001100
      034606 013700 0C1276
      034612 013701 001466
      034616 012737 000024 001226
      034624
      3000 034624
      3001
      3002
      3003 034624 004737 037316
      034630 154130
      034632 000404
      034634 000240
      034636 104000
      034640 000137 035624
      3004 034644
      3005
      3006
      3007 034644 012737 000000 001446
      3008 034652 012737 000000 001420
      3009 034660
      3010 034660 012737 106436 001416
      3011 034666 012737 177376 001414
      3012 034674 012737 010000 001444
      3013 034702 012737 000063 001412
      3014
      3015
      034710 004737 040242
      034714 000405
      034716 104401 070426
  
```

```

034722 104000          EMT          ;ERROR # DEFINED BY BADSC1 SUBROUTINE
034724 000137 035624   JMP          26$          ;GO TO 26$ IF ERROR
3016 034730          4$:
3017 034730 012737 071756 001174   MOV          #MIXED,$TMP0      ;STARTING ADDRESS OF PATTERN
3018 034736 012737 000200 001176   MOV          #128,$TMP1       ;RANGE OF PATTERN
3019 034744 004737 042774          JSR          PC,GENBUF        ;GO GENERATE BUFFER FOR FORMAT
3020
3021          ;LOAD PUT REGISTER INDEX TABLE FOR FORMAT OPERATION
3022 034750 012702 001553          MOV          #PUTINX,R2       ;R2 = BYTE ENTRY POSITION
3023 034754 112722 000034          MOVB        #RMDC,(R2)+
3024 034760 112722 000006          MOVB        #RMDA,(R2)+
3025 034764 112722 000004          MOVB        #RMB A,(R2)+
3026 034770 112722 000002          MOVB        #RMC,(R2)+
3027 034774 112722 000032          MOVB        #RMOF,(R2)+
3028 035000 112722 000000          MOVB        #RMC$1,(R2)+
3029 035004 112712 000200          MOVB        #200,(R2)       ;TERMINATE TABLE
3030 035010          5$:
3031
3032          ;FORMAT THE DRIVE
3033 035010 004737 043330          JSR          PC,PUT          ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
035014 000404          BR          6$              ;GO TO 6$ IF NO ERROR
035016 000240          NOP
035020 104000          EMT
035022 000137 035624          JMP          26$          ;GO TO 26$ IF ERROR
3034 035026          6$:
3035
3036          ;SETJP GET INDFX TABLE TO READ ALL REGISTERS
035026 004737 042774          JSR          PC,GETSTS      ;GO TO GETSTS SUBROUTINE
3037
3038          ;WAIT FOR COMMAND TO COMPLETE
035032 004737 043672          JSR          PC,TIMOUT     ;GO TO TIMOUT SUBROUTINE
3039
3040          ;GO READ STATUS FOR FORMAT OPERATION
3041 035036 004737 043060          JSR          PC,GET        ;GO READ REGISTER(S) WITH GET SUBROUTINE
035042 000404          BR          7$              ;GO TO 7$ IF NO ERROR
035044 000240          NOP
035046 104000          EMT
035050 000137 035624          JMP          26$          ;GO TO 26$ IF ERROR
3042 035054          7$:
3043
3044          ;VERIFY NO ERRORS DURING FORMAT
3045 035054 004737 056572          JSR          PC,DTASTS     ;GO VERIFY RESULTS OF DATA TRANSFER
035060 000405          BR          8$              ;GO TO 8$ IF NO ERROR
035062 000240          NOP
035064 104000          EMT
035066 004736          JSR          PC,@(SP)+     ;GO BACK FOR MORE ERROR CHECKS
035070 000137 035624          JMP          26$          ;GO TO 26$ IF ERROR
3046 035074          8$:
3047
3048          ;MOVE LOOP ADDRESSES TO NEXT OPERATION
3049 035074 012737 035104 001124   MOV          #9$,$LPERR
3050 035102 000410          BR          10$           ;SKIP TO WRITE OPERATION
3051
3052          ;*****
3053          ;LOOP #2          WRITE,READ
3054
3055 035104          9$:

```

```

3056
3057
3058 035104 004737 037316
      035110 154130
      ;PREPARE DEVICE FOR WRITE OPERATION
      JSR PC,TSTPRP ;PREPARE DEVICE FOR TEST
      .WORD 154130 ;TASK DESCRIPTOR AS FOLLOWS:
      ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
      ;CLEAR CONTROLLER & SELECT DEVICE
      ;VERIFY CONTROLLER CLEAR OPERATION
      ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
      ;VERIFY PACK ACKNOWLEDGE
      ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
      ;VERIFY RECALIBRATION
      ;GO TO 10$ IF NO ERROR
      ;RETURN HERE IF ERROR
      ;ERROR # DEFINED BY TSTPRP SUBROUTINE
      ;GO TO 26$ IF ERROR
      035112 000404 BR 10$
      035114 000240 NOP
      035116 104000 EMT
      035120 000137 035624 JMP 26$
3059 035124 10$:
3060
3061 ;WRITE DATA TO THE DRIVE
3062 035124 11$:
3063 035124 012737 106442 001416 MOV #BUFONE+4,RMSAO ;CHANGE BUS ADDRESS
3064 035132 012737 177400 001414 MOV #-256,RMWC0 ;CHANGE WORD COUNT
3065 035140 012737 000061 001412 MOV #WD.GO,RMCS10 ;WRITE DATA COMMAND
3066 035146 012702 001553 MOV #PUTINX,R2 ;LOAD PUT REGISTER INDEX TABLE
3067 035152 112722 000006 MOVB #RMDA,(R2)+
3068 035156 112722 000034 MOVB #RMDC,(R2)+
3069 035162 112722 000032 MOVB #RMOF,(R2)+
3070 035166 112722 000004 MOVB #RMBA,(R2)+
3071 035172 112722 000002 MOVB #RMWC,(R2)+
3072 035176 112722 000000 MOVB #RMCS1,(R2)+
3073 035202 112722 000200 MOVB #200,(R2)+ ;TERMINATE TABLE
3074
3075 035206 004737 043330 JSR PC,PUT ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      035212 000404 BR 12$ ;GO TO 12$ IF NO ERROR
      035214 000240 NOP ;RETURN HERE IF ERROR
      035216 104000 EMT ;ERROR # DEFINED BY PUT SUBROUTINE
      035220 000137 035624 JMP 26$ ;GO TO 26$ IF ERROR
3076 035224 12$:
3077
3078 ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
      JSR PC,GETSTS ;GO TO GETSTS SUBROUTINE
3079
3080 ;WAIT FOR COMMAND TO COMPLETE
      JSR PC,TIMOUT ;GO TO TIMEOUT SUBROUTINE
3081
3082 ;GO READ STATUS FOR WRITE COMMAND
3083 035234 004737 043060 JSR PC,GET ;GO READ REGISTER(S) WITH GET SUBROUTINE
      035240 000404 BR 13$ ;GO TO 13$ IF NO ERROR
      035242 000240 NOP ;RETURN HERE IF ERROR
      035244 104000 EMT ;ERROR # DEFINED BY GET SUBROUTINE
      035246 000137 035624 JMP 26$ ;GO TO 26$ IF ERROR
3084 035252 13$:
3085
3086 ;CHECK FOR ERRORS DURING WRITE OPERATION
3087 035252 004737 044056 JSR PC,PRIERR ;GO CHECK FOR PRIMARY ERRORS
      035256 000405 BR 14$ ;GO TO 14$ IF NO ERROR
      035260 000240 NOP ;RETURN HERE IF ERROR
      035262 104000 EMT ;ERROR # DEFINED BY PRIERR SUBROUTINE
  
```

```

3088 035264 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
035266 000137 035624 JMP 26$ ;GO TO 26$ IF ERROR
14$:
3089 035272 004737 056572 JSR PC,DTASTS ;GO VERIFY RESULTS OF DATA TRANSFER
035276 000405 BR 15$ ;GO TO 15$ IF NO ERROR
035300 000240 NOP ;RETURN HERE IF ERROR
035302 104000 EMT ;ERROR # DEFINED BY DTASTS SUBROUTINE
035304 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
035306 000137 035624 JMP 26$ ;GO TO 26$ IF ERROR
3090 035312 15$:
3091 035312 004737 044710 JSR PC,SECERR ;GO CHECK FOR SECONDARY ERRORS
035316 000405 BR 16$ ;GO TO 16$ IF NO ERROR
035320 000240 NOP ;RETURN HERE IF ERROR
035322 104000 EMT ;ERROR # DEFINED BY SECERR SUBROUTINE
035324 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
035326 000137 035624 JMP 26$ ;GO TO 26$ IF ERROR
3092 035332 16$:
3093
3094 ;CHANGE LOOP ADDRESSES
3095 035332 012737 035342 001124 MOV #17$,$LPERR
3096 035340 000410 BR 18$ ;SKIP TO NEXT OPERATION
3097
3098 ;*****
3099 ;LOOP #3 READ
3100
3101 035342 17$:
3102
3103 ;PREPARE DEVICE FOR READ OPERATION
3104 035342 004737 037316 JSR PC,TSTPRP ;PREPARE DEVICE FOR TEST
035346 154130 .WORD 154130 ;TASK DESCRIPTOR AS FOLLOWS:
;SELECT DEVICE & VERIFY DEVICE AVAILABLE
;CLEAR CONTROLLER & SELECT DEVICE
;VERIFY CONTROLLER CLEAR OPERATION
;PACK ACKNOWLEDGE IF VOLUME NOT VALID
;VERIFY PACK ACKNOWLEDGE
;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
;VERIFY RECALIBRATION
;GO TO 18$ IF NO ERROR
;RETURN HERE IF ERROR
;ERROR # DEFINED BY TSTPRP SUBROUTINE
;GO TO 26$ IF ERROR
035350 000404 BR 18$
035352 000240 NOP
035354 104000 EMT
035356 000137 035624 JMP 26$
3105 035362 18$:
3106
3107 ;READ DATA FROM DEVICE
3108 035362 19$:
3109 035362 012737 107446 001416 MOV #BUFTWO+4,RMBA0 ;CHANGE BUS ADDRESS
3110 035370 012737 000071 001412 MOV #RD.GO,RMCS10 ;READ DATA COMMAND
3111 035376 012702 001553 MOV #PUTINX,R2 ;LOAD PUT REGISTER INDEX TABLE
3112 035402 112722 000006 MOVB #RMDA,(R2)+
3113 035406 112722 000032 MOVB #RMOF,(R2)+
3114 035412 112722 000034 MOVB #RMDC,(R2)+
3115 035416 112722 000004 MOVB #RMBA,(R2)+
3116 035422 112722 000002 MOVB #RMWC,(R2)+
3117 035426 112722 000000 MOVB #RMCS1,(R2)+
3118 035432 112712 000200 MOVB #200,(R2)
3119
3120 035436 004737 043330 JSR PC,PUT ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
    
```

```
035442 000404 BR 20$ ;GO TO 20$ IF NO ERROR
035444 000240 NOP ;RETURN HERE IF ERROR
035446 104000 EMT ;ERROR # DEFINED BY PUT SUBROUTINE
035450 000137 035624 JMP 26$ ;GO TO 26$ IF ERROR
3121 035454 20$:
3122
3123 ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
035454 004737 042774 JSR PC,GETSTS ;GO TO GETSTS SUBROUTINE
3124
3125 ;WAIT FOR COMMAND TO COMPLETE
035460 004737 043672 JSR PC,TIMOUT ;GO TO TIMEOUT SUBROUTINE
3126
3127 ;GO READ STATUS FOR READ OPERATION
3128 035464 004737 043060 JSR PC,GET ;GO READ REGISTER(S) WITH GET SUBROUTINE
035470 000404 BR 21$ ;GO TO 21$ IF NO ERROR
035472 000240 NOP ;RETURN HERE IF ERROR
035474 104000 EMT ;ERROR # DEFINED BY GET SUBROUTINE
035476 000137 035624 JMP 26$ ;GO TO 26$ IF ERROR
3129 035502 21$:
3130
3131 ;CHECK FOR ERRORS DURING READ OPERATION
3132 035502 004737 044056 JSR PC,PRIERR ;GO CHECK FOR PRIMARY ERRORS
035506 000405 BR 22$ ;GO TO 22$ IF NO ERROR
035510 000240 NOP ;RETURN HERE IF ERROR
035512 104000 EMT ;ERROR # DEFINED BY PRIERR SUBROUTINE
035514 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
035516 000137 035624 JMP 26$ ;GO TO 26$ IF ERROR
3133 035522 22$:
3134 035522 004737 056572 JSR PC,DTASTS ;GO VERIFY RESULTS OF DATA TRANSFER
035526 000405 BR 23$ ;GO TO 23$ IF NO ERROR
035530 000240 NOP ;RETURN HERE IF ERROR
035532 104000 EMT ;ERROR # DEFINED BY DTASTS SUBROUTINE
035534 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
035536 000137 035624 JMP 26$ ;GO TO 26$ IF ERROR
3135 035542 23$:
3136 035542 004737 044710 JSR PC,SECERR ;GO CHECK FOR SECONDARY ERRORS
035546 000405 BR 24$ ;GO TO 24$ IF NO ERROR
035550 000240 NOP ;RETURN HERE IF ERROR
035552 104000 EMT ;ERROR # DEFINED BY SECERR SUBROUTINE
035554 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
035556 000137 035624 JMP 26$ ;GO TO 26$ IF ERROR
3137 035562 24$:
3138 035562 004737 042432 JSR PC,CMPBUF ;GO COMPARE WRITE, READ DATA BUFFERS
035566 106442 .WORD BUFOUR+4 ;STARTING ADDRESS OF WRITE BUFFER
035570 107446 .WORD BUFTWO+4 ;STARTING ADDRESS OF READ BUFFER
035572 000404 BR 25$ ;GO TO 25$ IF NO ERROR
035574 000240 NOP ;RETURN HERE IF ERROR
035576 104000 EMT ;ERROR # DEFINED BY CMPBUF SUBROUTINE
035600 000137 035624 JMP 26$ ;GO TO 26$ IF ERROR
3139 035604 25$:
3140 035604 105237 001421 INCB RMDAO+1 ;ADVANCE TO NEXT TRACK
3141 035610 123737 001421 001335 CMPB RMDAO+1,LSTRK+1 ;DONE ?
3142 035616 101002 BHI 26$ ;YES!!
3143 035620 000137 034660 JMP 3$ ;TEST NEXT TRACK
3144 035624 26$:
3145
3146 ;*****
```



```

; *TEST 25 READ, WRITE CHECK MULTIPLE SECTORS IN OFFSET MODE
; *****
TST25:
035624 000004          SCOPE          ;SCOPE CALL
035626 000240          NOP           ;START OF TEST
035630 012706 001100  MOV #STACK,SP ;INITIALIZE STACK POINTER
035634 013700 001276  MOV $BASE,R0  ;R0 = UNIBUS ADDRESS
035640 013701 001466  MOV TSTQUE,R1 ;(R1) = DEVICE BEING TESTED
035644 012737 000025 001226 MOV #25,$TESTN ;:SET TEST NUMBER IN APT MAIL BOX

3147
3148
3149
3150 035652          ; *****
; LOOP #1          FORMAT,READ OFFSET,WRITE CHECK OFFSET IN BOTH DIRECTIONS
1$:
3151
3152          ;PREPARE DEVICE FOR FORMAT OPERATION
3153 035652 004737 037316 JSR PC,TSTPRP ;PREPARE DEVICE FOR TEST
035656 154130 .WORD 154130 ;TASK DESCRIPTOR AS FOLLOWS:
;SELECT DEVICE & VERIFY DEVICE AVAILABLE
;CLEAR CONTROLLER & SELECT DEVICE
;VERIFY CONTROLLER CLEAR OPERATION
;PACK ACKNOWLEDGE IF VOLUME NOT VALID
;VERIFY PACK ACKNOWLEDGE
;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
;VERIFY RECALIBRATION
;GO TO 2$ IF NO ERROR
;RETURN HERE IF ERROR
;ERROR # DEFINED BY TSTPRP SUBROUTINE
;GO TO 28$ IF ERROR

035660 000404          BR 2$
035662 000240          NOP
035664 104000          EMT
035666 000137 037006  JMP 28$

3154
3155          ;LOAD PARAMETERS AND GENERATE DATA BUFFER
3156 035672          2$:
3157 035672 012737 000000 001446 MOV #0,RMDCO ;CYLINDER = 0
3158 035700 012737 000000 001420 MOV #0,RMDAO ;TRACK = 0, SECTOR 0
3159 035706 012737 106436 001416 MOV #BUFONE,RMBAO ;BUFFER ADDRESS
3160 035714 012737 176774 001414 MOV #-258.*2,RMWCO ;WORD COUNT FOR 2 SECTORS (2'S COMP)
3161 035722 012737 010000 001444 MOV #FMT16,RMOFO ;16 BIT MODE
3162 035730 012737 000063 001412 MOV #WH'GO,RMCS10 ;WRITE HEADER
3163
3164          ;VERIFY THAT SECTOR IS NOT BAD
035736 004737 040242 JSR PC,BADSCT ;CALL BAD SECTOR MODULE
035742 000405 BR 3$ ;GO TO 3$ IF NO ERROR
035744 104401 070426 TYPE ,SCTMSG ;TYPE BAD SECTOR MESSAGE
035750 104000 EMT ;ERROR # DEFINED BY BADSCT SUBROUTINE
035752 000137 037006 JMP 28$ ;GO TO 28$ IF ERROR

3165 035756          3$:
3166 035756 012737 072060 001174 MOV #ZEROS,$TMP0 ;DATA PATTERN
3167 035764 012737 000001 001176 MOV #1,$TMP1
3168 035772 004737 042174 JSR PC,GENBUF ;TO GENERATE BUFFER FOR FORMAT
3169
3170          ;LOAD PUT REGISTER INDEX TABLE FOR FORMAT OPERATION
3171 035776 012702 001553 MOV #PUTINX,R2 ;BYTE ENTRY TABLE
3172 036002 112722 000034 MOVB #RMDC,(R2)+
3173 036006 112722 000006 MOVB #RMDA,(R2)+
3174 036012 112722 000004 MOVB #RMBA,(R2)+
3175 036016 112722 000002 MOVB #RMWC,(R2)+
3176 036022 112722 000032 MOVB #RMOF,(R2)+
3177 036026 112722 000000 MOVB #RMCS1,(R2)+

```

```

3178 036032 112712 000200          MOVB   #200,(R2)          ;TABLE TERMINATOR
3179 036036                                4$:
3180 036036 004737 043330          JSR    PC,PUT           ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      036042 000404          BR     5$              ;GO TO 5$ IF NO ERROR
      036044 000240          NOP                    ;RETURN HERE IF ERROR
      036046 104000          EMT                    ;ERROR # DEFINED BY PUT SUBROUTINE
      036050 000137 037006          JMP    28$            ;GO TO 28$ IF ERROR
3181 036054                                5$:
3182
3183                                ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
      036054 004737 042774          JSR    PC,GETSTS       ;GO TO GETSTS SUBROUTINE
3184
3185                                ;WAIT FOR COMMAND TO COMPLETE
      036060 004737 043672          JSR    PC,TIMOUT       ;GO TO TIMOUT SUBROUTINE
3186
3187                                ;GO READ STATUS FOR FORMAT OPERATION
3188 036064 004737 043060          JSR    PC,GET           ;GO READ REGISTER(S) WITH GET SUBROUTINE
      036070 000404          BR     6$              ;GO TO 6$ IF NO ERROR
      036072 000240          NOP                    ;RETURN HERE IF ERROR
      036074 104000          EMT                    ;ERROR # DEFINED BY GET SUBROUTINE
      036076 000137 037006          JMP    28$            ;GO TO 28$ IF ERROR
3189 036102                                6$:
3190
3191                                ;VERIFY NO ERROR DURING FORMAT
3192 036102 004737 056572          JSR    PC,DTASTS       ;GO VERIFY RESULTS OF DATA TRANSFER
      036106 000405          BR     7$              ;GO TO 7$ IF NO ERROR
      036110 000240          NOP                    ;RETURN HERE IF ERROR
      036112 104000          EMT                    ;ERROR # DEFINED BY DTASTS SUBROUTINE
      036114 004736          JSR    PC,@(SP)+      ;GO BACK FOR MORE ERROR CHECKS
      036116 000137 037006          JMP    28$            ;GO TO 28$ IF ERROR
3193
3194                                ;MOV LOOP ADDRESSES TO NEXT OPERATION
3195 036122                                7$:
3196 036122 012737 036144 001124          MOV    #8$,$LPERR     ;ERROR LOOP ADDRESS
3197
3198                                ;LOCATE BUFFER ADDRESS AND WORD COUNT
3199 036130 012737 177000 001414          MOV    #-256.*2,RMWCO ;TWO SECTORS
3200 036136 012737 106436 001416          MOV    #BUFONE,RMBAO  ;BUFFER ADDRESS
3201
3202                                ;*****
3203 036144                                ;LOOP 2 READ AND WRITE CHECK IN OFFSET MODE
3204                                8$:
3205 036144 004737 037316          ;PREPARE DEVICE FOR READ OFFSET OPEATION
      036150 154130          JSR    PC,TSTPRP      ;PREPARE DEVICE FOR TEST
      .WORD 154130          ;TASK DESCRIPTOR AS FOLLOWS:
      ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
      ;CLEAR CONTROLLER & SELECT DEVICE
      ;VERIFY CONTROLLER CLEAR OPERATION
      ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
      ;VERIFY PACK ACKNOWLEDGE
      ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
      ;VERIFY RECALIBRATION
      036152 000404          BR     9$              ;GO TO 9$ IF NO ERROR
      036154 000240          NOP                    ;RETURN HERE IF ERROR
      036156 104000          EMT                    ;ERROR # DEFINED BY TSTPRP SUBROUTINE
      036160 000137 037006          JMP    28$            ;GO TO 28$ IF ERROR
3206 036164                                9$:
3207 036164                                10$:

```

```

3208          ;READ OFFSET
3209 036164 012702 001553      MOV    #PUTINX,R2      ;LOAD THE TABLE
3210 036170 112722 000006      MOVB  #RMDA,(R2)+
3211 036174 112722 000034      MOVB  #RMDC,(R2)+
3212 036200 112722 000032      MOVB  #RMOF,(R2)+
3213 036204 112722 000004      MOVB  #RMBA,(R2)+
3214 036210 112722 000002      MOVB  #RMWC,(R2)+
3215 036214 112722 000200      MOVB  #200,(R2)+      ;TABLE TERMINATOR
3216
3217 036220 004737 043330      JSR   PC,PUT          ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      036224 000404          BR    11$            ;GO TO 11$ IF NO ERROR
      036226 000240          NOP                    ;RETURN HERE IF ERROR
      036230 104000          EMT                    ;ERROR # DEFINED BY PUT SUBROUTINE
      036232 000137 037006      JMP   28$            ;GO TO 28$ IF ERROR
3218 036236 012737 000015 001412 11$: MOV  #OFFSET.GO,RMCS10 ;OFFSET COMMAND
3219 036244 012702 001553      MOV  #PUTINX,R2
3220 036250 112722 000000      MOVB #RMCS1,(R2)+
3221 036254 112722 000200      MOVB #200,(R2)+
3222
3223 036260 004737 043330      JSR   PC,PUT          ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      036264 000404          BR    12$            ;GO TO 12$ IF NO ERROR
      036266 000240          NOP                    ;RETURN HERE IF ERROR
      036270 104000          EMT                    ;ERROR # DEFINED BY PUT SUBROUTINE
      036272 000137 037006      JMP   28$            ;GO TO 28$ IF ERROR
3224 036276          12$:
3225
3226          ;WAIT FOR COMMAND TO COMPLETE
3227 036276 004737 043672      JSR   PC,TIMOUT      ;GO TO TIMOUT SUBROUTINE
3228
3228 036302 012737 000071 001412      MOV  #RD!GO,RMCS10 ;READ DATA COMMAND
3229 036310 012702 001553      MOV  #PUTINX,R2      ;TABLE INDEX
3230 036314 112722 000000      MOVB #RMCS1,(R2)+
3231 036320 112712 000200      MOVB #200,(R2)      ;TABLE TERMINATOR
3232
3233 036324 004737 043330      JSR   PC,PUT          ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      036330 000404          BR    13$            ;GO TO 13$ IF NO ERROR
      036332 000240          NOP                    ;RETURN HERE IF ERROR
      036334 104000          EMT                    ;ERROR # DEFINED BY PUT SUBROUTINE
      036336 000137 037006      JMP   28$            ;GO TO 28$ IF ERROR
3234 036342          13$:
3235
3236          ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
3237 036342 004737 042774      JSR   PC,GETSTS      ;GO TO GETSTS SUBROUTINE
3238
3238          ;WAIT FOR COMMAND TO COMPLETE
3239 036346 004737 043672      JSR   PC,TIMOUT      ;GO TO TIMOUT SUBROUTINE
3240
3240          ;READ STATUS FOR READ OFFSET OPERATION
3241 036352 004737 043060      JSR   PC,GET          ;GO READ REGISTER(S) WITH GET SUBROUTINE
      036356 000404          BR    14$            ;GO TO 14$ IF NO ERROR
      036360 000240          NOP                    ;RETURN HERE IF ERROR
      036362 104000          EMT                    ;ERROR # DEFINED BY GET SUBROUTINE
      036364 000137 037006      JMP   28$            ;GO TO 28$ IF ERROR
3242
3243          ;CHECK ERROR DURING READ OFFSET
3244 036370          14$:
3245 036370 004737 044056      JSR   PC,PRIERR      ;GO CHECK FOR PRIMARY ERRORS
  
```

```

036374 000405 BR 15$ ;GO TO 15$ IF NO ERROR
036376 000240 NOP ;RETURN HERE IF ERROR
036400 104000 EMT ;ERROR # DEFINED BY PRIERR SUBROUTINE
036402 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
036404 000137 037006 JMP 28$ ;GO TO 28$ IF ERROR
3246 036410 15$:
3247 036410 004737 056572 JSR PC,DTASTS ;GO VERIFY RESULTS OF DATA TRANSFER
036414 000405 BR 16$ ;GO TO 16$ IF NO ERROR
036416 000240 NOP ;RETURN HERE IF ERROR
036420 104000 EMT ;ERROR # DEFINED BY DTASTS SUBROUTINE
036422 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
036424 000137 037006 JMP 28$ ;GO TO 28$ IF ERROR
3248 036430 16$:
3249 036430 004737 044710 JSR PC,SECERR ;GO CHECK FOR SECONDARY ERRORS
036434 000405 BR 17$ ;GO TO 17$ IF NO ERROR
036436 000240 NOP ;RETURN HERE IF ERROR
036440 104000 EMT ;ERROR # DEFINED BY SECERR SUBROUTINE
036442 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
036444 000137 037006 JMP 28$ ;GO TO 28$ IF ERROR
3250 036450 17$:
3251
3252 ;CHANGE LOOP ADDRESS
3253 036450 012737 036460 001124 MOV #18$, $LPERR
3254 036456 000410 BR 19$ ;TO NEXT OPERATION
3255
3256 ;*****
3257 ;LOOP 3 WRITE CHECK OFFSET
3258 036460 18$:
3259
3260 ;PREPARE DEVICE FOR READ OPERATION
3261 036460 004737 037316 JSR PC,TSTPRP ;PREPARE DEVICE FOR TEST
036464 154130 .WORD 154130 ;TASK DESCRIPTOR AS FOLLOWS:
;SELECT DEVICE & VERIFY DEVICE AVAILABLE
;CLEAR CONTROLLER & SELECT DEVICE
;VERIFY CONTROLLER CLEAR OPERATION
;PACK ACKNOWLEDGE IF VOLUME NOT VALID
;VERIFY PACK ACKNOWLEDGE
;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
;VERIFY RECALIBRATION
036466 000404 BR 19$ ;GO TO 19$ IF NO ERROR
036470 000240 NOP ;RETURN HERE IF ERROR
036472 104000 EMT ;ERROR # DEFINED BY TSTPRP SUBROUTINE
036474 000137 037006 JMP 28$ ;GO TO 28$ IF ERROR
3262 036500 19$:
3263
3264 ;WRITE CHECK DATA IN OFFSET MODE
3265 036500 20$:
3266 036500 012702 001553 MOV #PUTINX,R2
3267 036504 112722 000006 MOVB #RMDA,(R2)+
3268 036510 112722 000032 MOVB #RMOF,(R2)+
3269 036514 112722 000034 MOVB #RMDC,(R2)+
3270 036520 112722 000004 MOVB #RMB A,(R2)+
3271 036524 112722 000002 MOVB #RMWC,(R2)+
3272 036530 112712 000200 MOVB #200,(R2) ;TABLE TERMINATOR
3273
3274 036534 004737 043330 JSR PC,PUT ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
036540 000404 BR 21$ ;GO TO 21$ IF NO ERROR
  
```

```

036542 000240      NOP      ;RETURN HERE IF ERROR
036544 104000      EMT      ;ERROR # DEFINED BY PUT SUBROUTINE
036546 000137 037006  JMP      28$      ;GO TO 28$ IF ERROR

3275
3276      ;SETUP OFFSET MODE FIRST
3277 036552      21$:
3278 036552 012737 000015 001412  MOV      #OFFSET!GO, RMCS10      ;OUTPUT BUFFER
3279 036560 012702 001553      MOV      #PUTINX, R2
3280 036564 112722 000000      MOVB     #RMCS1, (R2)+
3281 036570 112712 000200      MOVB     #200, (R2)
3282
3283 036574 004737 043330      JSR      PC, PUT      ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
036600 000404      BR      22$      ;GO TO 22$ IF NO ERROR
036602 000240      NOP      ;RETURN HERE IF ERROR
036604 104000      EMT      ;ERROR # DEFINED BY PUT SUBROUTINE
036606 000137 037006  JMP      28$      ;GO TO 28$ IF ERROR

3284 036612      22$:
3285
3286      ;WAIT FOR COMMAND TO COMPLETE
036612 004737 043672  JSR      PC, TIMEOUT      ;GO TO TIMEOUT SUBROUTINE

3287
3288      ;EXECUTE WRITE CHECK DATA COMMAND
3289 036616 012737 000051 001412  MOV      #WCD!GO, RMCS10
3290 036624 012702 001553      MOV      #PUTINX, R2
3291 036630 112722 000000      MOVB     #RMCS1, (R2)+
3292 036634 112712 000200      MOVB     #200, (R2)
3293
3294 036640 004737 043330      JSR      PC, PUT      ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
036644 000404      BR      23$      ;GO TO 23$ IF NO ERROR
036646 000240      NOP      ;RETURN HERE IF ERROR
036650 104000      EMT      ;ERROR # DEFINED BY PUT SUBROUTINE
036652 000137 037006  JMP      28$      ;GO TO 28$ IF ERROR

3295 036656      23$:
3296
3297      ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
036656 004737 042774  JSR      PC, GETSTS      ;GO TO GETSTS SUBROUTINE

3298
3299      ;WAIT FOR COMMAND TO COMPLETE
036662 004737 043672  JSR      PC, TIMEOUT      ;GO TO TIMEOUT SUBROUTINE

3300
3301      ;READ STATUS FOR WRITE CHECK OFFSET OPERATION
3302 036666 004737 043060      JSR      PC, GET      ;GO READ REGISTER(S) WITH GET SUBROUTINE
036672 000404      BR      24$      ;GO TO 24$ IF NO ERROR
036674 000240      NOP      ;RETURN HERE IF ERROR
036676 104000      EMT      ;ERROR # DEFINED BY GET SUBROUTINE
036700 000137 037006  JMP      28$      ;GO TO 28$ IF ERROR

3303 036704      24$:
3304
3305      ;CHECK ERROR DURING WRITE CHECK OFFSET OPERATION
3306 036704 004737 044056      JSR      PC, PRIERR      ;GO CHECK FOR PRIMARY ERRORS
036710 000405      BR      25$      ;GO TO 25$ IF NO ERROR
036712 000240      NOP      ;RETURN HERE IF ERROR
036714 104000      EMT      ;ERROR # DEFINED BY PRIERR SUBROUTINE
036716 004736      JSR      PC, @ (SP)+      ;GO BACK FOR MORE ERROR CHECKS
036720 000137 037006  JMP      28$      ;GO TO 28$ IF ERROR

3307 036724      25$:
3308 036724 004737 056572  JSR      PC, DTASTS      ;GO VERIFY RESULTS OF DATA TRANSFER

```

	036730	000405			BR	26\$:GO TO 26\$ IF NO ERROR
	036732	000240			NOP			:RETURN HERE IF ERROR
	036734	104000			EMT			:ERROR # DEFINED BY DTASTS SUBROUTINE
	036736	004736			JSR	PC,@(SP)+		:GO BACK FOR MORE ERROR CHECKS
	036740	000137	037006		JMP	28\$:GO TO 28\$ IF ERROR
3309	036744			26\$:				
3310	036744	004737	044710		JSR	PC,SECERR		:GO CHECK FOR SECONDARY ERRORS
	036750	000405			BR	27\$:GO TO 27\$ IF NO ERROR
	036752	000240			NOP			:RETURN HERE IF ERROR
	036754	104000			EMT			:ERROR # DEFINED BY SECERR SUBROUTINE
	036756	004736			JSR	PC,@(SP)+		:GO BACK FOR MORE ERROR CHECKS
	036760	000137	037006		JMP	28\$:GO TO 28\$ IF ERROR
3311	036764			27\$:				
3312	036764	032737	000200	001444	BIT	#OFD,RMOFO		:IN FORWARD DIRECTION OF OFFSET ?
3313	036772	001005			BNE	28\$:BRANCH IF SO
3314	036774	052737	000200	001444	BIS	#OFD,RMOFO		:SET TO FORWARD DIRECTION
3315	037002	000137	036122		JMP	7\$:CHANGE OFFSET DIRECTION TEST AGAIN
3316	037006			28\$:				

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20

.SBTTL END OF SUB-PASS ROUTINE

:THIS IS THE END OF SUB-PASS ROUTINE. THIS ROUTINE IS USED TO
:TERMINATE THE OPERATION OF THE CURRENT DEVICE UNDER TEST AND
:SELECT THE NEXT DEVICE FOR TEST. IF THERE ARE NO MORE DEVICES
:TO TEST, EXIT IS MADE TO '\$EOP' ROUTINE. OTHERWISE, RETURN
:IS MADE TO 'SHUT' ROUTINE.

```
9 037006 000004 $EOSP: SCOPE
10 037010 000240 NOP
11 037012 013700 001466 MOV TSTQUE,RO ;GET POINTER TO TSTQUE
12 037016 062700 000002 ADD #2,RO ;ADJUST PCINTER TO NEXT DEVICE
13 037022 010037 001466 MOV RO,TSTQUE ;SAVE POINTER TO TSTQUE
14 037026 005710 TST (RO) ;ANY MORE DEVICES FOR TEST ?
15 037030 001402 BEQ 1$ ;BR IF NO
16 037032 000137 037262 JMP SHUT ;JUMP TO 'SHUT' ROUTINE
17 037036 012737 001470 001466 1$: MOV #TSTQUE+2,TSTQUE ;INITIALIZE POINTER TO FIRST DEVICE IN
;TEST QUE TABLE
```

.SBTTL END OF PASS ROUTINE

:*INCREMENT THE PASS NUMBER (\$PASS)
:*TYPE 'END PASS #XXXXX TOTAL NUMBER OF ERRORS SINCE LAST REPORT YYYYY'
:*WHERE XXXXX AND YYYYY ARE DECIMAL NUMBERS
:*IF THERES A MONITOR GO TO IT
:*IF THERE ISN'T JUMP TO SHUT

```
037044 $EOP: NOP
037044 000240 CLR $TSTNM ;ZERO THE TEST NUMBER
037046 005037 001116 CLR $TIMES ;ZERO THE NUMBER OF ITERATIONS
037052 005037 001206 INC $PASS ;INCREMENT THE PASS NUMBER
037056 005237 001230 BIC #100000,$PASS ;DON'T ALLOW A NEG. NUMBER
037062 042737 100000 001230 DEC (PC)+ ;LOOP?
037070 005327 $EOPCT: .WORD 1
037072 000001 BGT $DOAGN ;YES
037074 003066 MOV (PC)+,@(PC)+ ;RESTORE COUNTER
037076 012737 $ENDCT: .WORD 1
037100 000001 TYPE ,65$ ;TYPE ASCIZ STRING
037102 037072 BR 64$ ;GET OVER THE ASCIZ
037104 104401 037112 ;:65$: .ASCIZ <12><15>/END PASS #/
037110 000407 64$: MOV $PASS,-(SP) ;SAVE $PASS FOR TYPEOUT
;:66$: ;:TYPE PASS NUMBER
;:GO TYPE--DECIMAL ASCII WITH SIGN
037130 037130 013746 001230 TYPDS ;SEE IF ANY ERRORS THIS PASS
037134 104405 TST $ERTTL ;BR IF NO ERRORS TO REPORT
037136 005737 001126 BEQ $GT42P ;TYPE ASCIZ STRING
037142 001431 TYPE ,67$ ;GET OVER THE ASCIZ
037144 104401 037152 BR 66$ ;:67$: .ASCIZ / TOTAL ERRORS SINCE LAST REPORT /
037150 000421 66$: MOV $ERTTL,-(SP) ;SAVE $ERTTL FOR TYPEOUT
;:TOTAL NUMBER OF ERRORS
;:GO TYPE--DECIMAL ASCII WITH SIGN
037214 037214 013746 001126 TYPDS ;CLEAR ERROR TOTAL
037220 104405 CLR $ERTTL
037222 005037 001126
```

037226	104401	001217		\$GT42P: TYPE	,SCLF	::TYPE CARRIAGE RETURN, LINE FEED
037232	013700	000042		\$GET42: MOV	@#42,RO	::GET MONITOR ADDRESS
037236	001405			BEQ	\$DOAGN	::BRANCH IF NO MONITOR
037240	000005			RESET		::CLEAR THE WORLD
037242	004710			\$ENDAD: JSR	PC,(R0)	::GO TO MONITOR
037244	000240			NOP		::SAVE ROOM
037246	000240			NOP		::FOR
037250	000240			NOP		::ACT11
037252				\$DOAGN: JMP	@(PC)+	::RETURN
037252	000137			\$RTNAD: .WORD	SHUT	
037254	037262			\$ENULL: .BYTE	-1,-1,0	::NULL CHARACTER STRING
037256	377	377	000	.EVEN		
21						
22	037262	005737	001326	SHUT: TST	CTLFG	:WAS CONTROL C FLAGGED ?
23	037266	001002		BNE	1\$:BR IF YES
24	037270	000137	007670	JMP	READY	:CONTINUE
25	037274	005737	000042	1\$: TST	@#42	:ANY MONITOR PRESENT ?
26	037300	001002		BNE	2\$:BR IF YES
27	037302	000137	005432	JMP	START	:GO TO START
28	037306	005037	001300	2\$: CLR	\$DEVN	:FUDGE NO DRIVES IN MAP
29	037312	000137	037044	JMP	\$EOP	:RETURN TO \$EOP

.SBTTL TEST PREPARATION MODULE

: THIS MODULE PREPARES THE SUBSYSTEM FOR THE EXECUTION OF A TEST,
: REPORTING AN ERROR TO THE USER IF AN ERROR IS DETECTED. THE USER
: SPECIFIES TASKS TO BE PERFORMED, WHICH THE MODULE EXECUTES
: USING SUBROUTINES.

:CALL:

JSR PC,TSTPRP
.WORD NN'NNN TASK/VERIFY DESCRIPTOR
BR ?? RETURN HERE IF NO ERROR
NOP RETURN HERE IF ERROR
ERROR ERROR DEFINED BY MODULE

:TASK/VERIFY DESCRIPTOR

BIT 15 = 1 SELECT DEVICE AND VERIFY DEVICE IS AVAILABLE

BIT 14 = 1 CLEAR CONTROLLER AND SELECT DEVICE
BIT 13 (RESERVED FOR DRIVE CLEAR)
BIT 12 = 1 PACK ACKNOWLEDGE IF VOLUME NOT VALID

BIT 11 = 1 RECALIBRATE IF POSITIONING IN PROGRESS
BIT 10
BIT 9

BIT 8
BIT 7
BIT 6 = 1 VERIFY CONTROLLER CLEAR OPERATION

BIT 5 (RESERVED FOR DRIVE CLEAR)
BIT 4 = 1 VERIFY PACK ACKNOWLEDGE
BIT 3 = 1 VERIFY RECALIBRATION

BIT 2
BIT 1
BIT 0

TSTPRP:

:STORE TASK DESCRIPTOR AND CLEAR USER'S ERROR CALL
MOV @ (SP),500\$:STORE DESCRIPTOR
ADD #6,(SP) :MOVE SP TO USERS ERROR CALL
CLRB @ (SP) :CLEAR ERROR CALL
SUB #4,(SP) :MOVE SP TO NO ERROR RETURN

JSR PC,GETSTS :SETUP TO READ ALL REGISTERS
JSR PC,GET :GET RMER2
BR 15\$:BR IF NO ERROR DETECTED
BR 10\$:GET OVER ERROR NUMBER
.WORD 0 :ERROR DEFINED BY GET SUBROUTINE
10\$: ADD #4,(SP) :XFER ERROR TO USER AND
MOV 10\$-2,@ (SP) :GET ERROR NUMBER.
JMP 400\$

15\$: MOV RMER2I,505\$:GET RMER2 AND SAVE FOR LATER

:*****

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57

037316
037316 017637 000000 040236
037324 062716 000006
037330 105076 000000
037334 162716 000004
037340 004737 042774
037344 004737 043060
037350 000411
037352 000401
037354 000000
037356 062716 000004 10\$:
037362 113776 037354 000000
037370 000137 040226
037374 013737 001400 040240 15\$:

```

58      ;SELECT DEVICE AND VERIFY DEVICE AVAILABLE IF BIT 15 SET IN TASK
59 037402 005737 040236      TST      500$      ;SELECT DEVICE??
60 037406 100014      BPL      30$      ;NO!!
61
62 037410 004737 050762      JSR      PC,DEVSEL      ;GO SELECT DEVICE
63 037414 000411      BR      30$      ;NO ERROR - CONTINUE
64 037416 000401      BR      20$
65 037420 000000      .WORD   0      ;ERROR NUMBER FROM DEVSEL
66 037422 062716 000004      20$:  ADD      #4,(SP)      ;TRANSFER ERROR TO USER
67 037426 113776 037420 000000      MOVB    20$,2,@(SP)
68 037434 000137 040226      JMP     400$
69
70      ;*****
71      ;CLEAR CONTROLLER IF BIT 14 IS SET IN TASK
72 037440      30$:
73 037440 032737 040000 040236      BIT     #BIT14,500$      ;CLEAR CONTROLLER??
74 037446 001451      BEQ    120$      ;NO!!
75
76 037450 004737 052434      JSR      PC,CNTCLR      ;GO CLEAR CONTROLLER
77 037454 000411      BR      60$      ;CONTINUE - NO ERROR
78 037456 000401      BR      50$
79 037460 000000      40$:  .WORD   0      ;ERROR NUMBER FROM CNTCLR
80 037462 062716 000004      50$:  ADD      #4,(SP)      ;TRANSFER ERROR TO USER
81 037466 113776 037460 000000      MOVB    40$,@ (SP)
82 037474 000137 040226      JMP     400$
83
84      ;*****
85      ;VERIFY CONTROLLER CLEAR IF BIT6 SET IN TASK
86 037500      60$:
87 037500 032737 000100 040236      BIT     #BIT6,500$      ;VERIFY??
88 037506 001431      BEQ    120$      ;NO!!
89
90 037510 004737 043060      JSR      PC,GET      ;GO GET STATUS
91 037514 000411      BR      90$      ;NO ERROR GETTING STATUS
92 037516 000401      BR      80$
93 037520 000000      70$:  .WORD   0      ;ERROR FROM GETTING STATUS
94 037522 062716 000004      80$:  ADD      #4,(SP)      ;TRANSFER ERROR TO USER
95 037526 113776 037520 000000      MOVB    70$,@ (SP)
96 037534 000137 040226      JMP     400$
97
98 037540 004737 052552      90$:  JSR      PC,CLRSTS      ;GO VERIFY STATUS CLEAR
99 037544 000412      BR      120$      ;NO FRROR IN CLEAR
100 037546 000401      BR      110$
101 037550 000000      100$: .WORD   0      ;ERROR IN STATUS CLEAR
102 037552 005726      110$: TST     (SP)+      ;STRIP RETURN ADDRESS TO
103 037554 062716 000004      ADD     #4,(SP)      ;SUBROUTINE AND TRANSFER
104 037560 113776 037550 000000      MOVB    100$,@ (SP)      ;ERROR TO USER
105 037566 000137 040226      JMP     400$
106
107      ;*****
108      ;EXECUTE PACK ACKNOWLEDGE IF BIT12 SET IN TASK AND VOLUME IS
109      ;NOT VALID
110 037572      120$:
111 037572 032737 010000 040236      BIT     #BIT12,500$      ;PACK ACKNOWLEDGE??
112 037600 001503      BEQ    240$      ;NO!!
113
114 037602 004737 043060      JSR      PC,GET

```

```

115 037606 000411 BR 150$ ;NO ERROR GETTING RMDS
116 037610 000401 BR 140$
117 037612 000000 130$: .WORD 0
118 037614 062716 000004 140$: ADD #4,(SP) ;TRANSFER ERROR TO USER
119 037620 113776 037612 000000 MOVB 130$,@ (SP)
120 037626 000137 040226 JMP 400$
121
122 037632 032737 000100 001350 150$: BIT #VV,RMDSI ;IS VOLUME VALID??
123 037640 001063 BNE 240$ ;YES!.
124
125 037642 005037 001512 CLR MEDENB ;CLEAR MEDIA ENABLE
126 037646 012737 000023 001412 MOV #PAKACK!GO,RMCS10 ;LOAD PAK ACK COMMAND
127 037654 112737 000000 001553 MOVB #RMCS1,PUTINX ;SETUP REGISTER INDEX TABLE
128 037662 112737 000200 001554 MOVB #200,PUTINX+1
129 037670 004737 043330 JSR PC,PUT ;GO WRITE COMMAND
130 037674 000410 BR 180$ ;NO ERROR LOADING REGISTER
131 037676 000401 BR 170$
132 037700 000000 160$: .WORD 0 ;ERROR FROM PUT SUB
133 037702 062716 000004 170$: ADD #4,(SP) ;TRANSFER ERROR TO USER
134 037706 113776 037700 000000 MOVB 160$,@ (SP)
135 037714 000544 BR 400$
136
137 037716 004737 043672 180$: JSR PC,TIMOUT ;WAIT FOR COMMAND TO COMPLETE
138
139
140 ;:*****
141 037722 032737 000020 040236 ;VERIFY PACK ACKNOWLEDGE IF #BIT4 SET IN TASK
142 037730 001427 BIT #BIT4,500$ ;VERIFY PACK ACKNOWLEDGE??
143 BEQ 240$ ;NO!.
144 037732 004737 043060 JSR PC,GET ;GO GET STATUS
145 037736 000410 BR 210$ ;NO ERROR GETTING STATUS
146 037740 000401 BR 200$
147 037742 000000 190$: .WORD 0 ;ERROR FROM GET SUB
148 037744 062716 000004 200$: ADD #4,(SP) ;TRANSFER ERROR TO USER
149 037750 113776 037742 000000 MOVB 190$,@ (SP)
150 037756 000523 BR 400$
151
152 037760 004737 053432 210$: JSR PC,ACKSTS ;GO CHECK ACKNOWLEDGE
153 037764 000411 BR 240$ ;NO ERROR
154 037766 000401 BR 230$
155 037770 000000 220$: .WORD 0 ;PACK ACKNOWLEDGE ERROR
156 037772 005726 230$: TST (SP)+ ;STRIP RETURN TO SUB AND
157 037774 062716 000004 ADD #4,(SP) ;TRANSFER ERROR TO USER
158 040000 113776 037770 000000 MOVB 220$,@ (SP)
159 040006 000507 BR 400$
160
161 ;:*****
162 ;RECALIBRATE DRIVE IF BIT 11 IS SET IN TASK AND 'SKI' IS SET
163 ;OR 'PIP' IS ACTIVE.
164 040010 240$: BIT #BIT11,500$ ;RECALIBRATE??
165 040010 032737 004000 040236 BEQ 410$ ;NO!.
166 040016 001505
167
168 040020 004737 043060 JSR PC,GET ;GO GET RMDS
169 040024 000410 BR 270$ ;NO ERROR GETTING RMDS
170 040026 000401 BR 260$
171 040030 000000 250$: .WORD 0 ;ERROR FROM GET SUB
  
```

```

172 040032 062716 000004      260$:  ADD    #4,(SP)      ;TRANSFER ERROR TO USER
173 040036 113776 040030 000000  MOVB   250$,a(SP)
174 040044 000470      BR     400$
175
176 040046 032737 040000 040240 270$:  BIT    #SKI,505$      ;WAS SKI SET ?
177 040054 001004      BNE    280$           ;YES, GO RECALIBRATE
178 040056 032737 020000 001350  BIT    #PIP,RMDSI    ;IS PIP ACTIVE??
179 040064 001462      BEQ    410$           ;NO.!
180
181 040066 012737 000007 001412 280$:  MOV    #RLCAL!GO,RMCS10 ;LOAD RECALIBRATE COMMAND
182 040074 112737 000000 001553  MOVB   #RMCS1,PUTINX ;AND REGISTER INDEX
183 040102 112737 000200 001554  MOVB   #200,PUTINX+1
184 040110 004737 043330      JSR    PC,PUT         ;GO ISSUE RECALIBRATE
185 040114 000410      BR     300$           ;NO ERROR
186 040116 000401      BR     290$
187 040120 000000      .WORD 0              ;ERROR IN REGISTER TRANSFER
188 040122 062716 000004      290$:  ADD    #4,(SP)      ;TRANSFER ERROR TO USER
189 040126 113776 040120 000000  MOVB   290$-2,a(SP)
190 040134 000434      BR     400$
191
192 040136 004737 043672      300$:  JSR    PC,TIMOUT    ;WAIT FOR COMPLETION
193
194
195
196 040142 032737 000010 040236 :*****
197 040150 001430      :VERIFY RECALIBRATE IF BIT 3 SET IN TASK
198
199 040152 004737 043060      BIT    #BIT3,500$    ;VERIFY RECALIBRATE??
200 040156 000410      BEQ    410$           ;NO!!
201 040160 000401      JSR    PC,GET        ;GO GET STATUS
202 040162 000000      BR     330$           ;NO ERROR GETTING STATUS
203 040164 062716 000004      BR     320$
204 040170 113776 040162 000000 310$:  .WORD 0              ;ERROR FROM GET
205 040176 000413      320$:  ADD    #4,(SP)      ;TRANSFER ERROR TO USER
206
207 040200 004737 054226      330$:  MOVB   310$,a(SP)
208 040204 000412      BR     400$
209 040206 000401      BR     350$
210 040210 000000      340$:  .WORD 0              ;ERROR DURING RECALIBRATE
211 040212 005726      350$:  TST    (SP)+        ;STRIP RETURN TO SUB AND
212 040214 062716 000004      ADD    #4,(SP)      ;TRANSFER ERROR TO USER
213 040220 113776 040210 000000  MOVB   340$,a(SP)
214 040226 162716 000002 400$:  SUB    #2,(SP)      ;MOVE SP BACK BEFORE ERROR
215 040232 000240      410$:  NOP
216 040234 000207      RTS    PC            ;RETURN TO USER
217
218 040236 000000      500$:  .WORD 0              ;TASK/VERIFY DESCRIPTOR
219 040240 000000      505$:  .WORD 0              ;CONTAINS RMER2

```

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56

```
.SBTTL  BAD SECTOR MODULE

;THE MODULE IS INTENDED TO BE CALLED PRIOR TO CALLING THE BUFFER
;GENERATOR SUBROUTINE, AND PRESERVES THE 'PUT BUFFER' SO THAT THE
;BUFFER NEED ONLY BE FILLED ONCE FOR THE EXECUTION OF A FORMAT
;OPERATION.

;THE MODULE RETURNS TO THE CALLING TEST WITH THE APPROVED OR ASSIGNED
;SECTOR IN THE PUT BUFFER AND ALSO IN LOCATIONS 'ASNDA' AND 'ASNDC'
;SO THAT A REFERENCE IS AVAILABLE TO THE TEST OUTSIDE OF THE PUT BUFFER.

;THE BAD SECTOR MODULE PERFORMS TWO MAJOR FUNCTIONS:
; (1) RECOVER THE BAD SECTOR FILES AND
; (2) APPROVE THE USAGE OF A SECTOR BASED ON INFORMATION IN
;     THE BAD SECTOR FILES OR ASSIGN A NEW SECTOR IF THE ONE
;     ELECTED IS NOT AVAILABLE FOR USE.

;INFORMATION REQUIRED BY THE MODULE INCLUDES:
; (1) .RMDCO - THE DESIRED CYLINDER,
; (2) .RMDAO - THE TRACK AND SECTOR ADDRESS,
; (3) .RMWCO - THE WORD COUNT,
; (4) .RMCS10 - THE COMMAND,
; (5) .RMOFO - THE FORMAT MODE

;CALL:
;      JSR      PC,BADSCT      ;CALL SUBROUTINE
;      BR       ???           ;RETURN HERE IF NO ERROR
;      TYPE     ,MESSAGE      ;RETURN HERE IF THE BAD SECTOR FILE
;                               ;CANNOT BE RECOVERED.
;      ERROR    N             ;THE EMT OFFSET NUMBER 'N' IS DEFINED
;                               ;BY BAD SECTOR MODULE.

BADSCT:
;      ADD      #6,(SP)       ;CLEAR ERROR NUMBER IN USER'S
;      CLRB     @ (SP)        ;ERROR CALL.
;      SUB      #6,(SP)

;TEST 'MEDIA ENABLE' TO DETERMINE WHETHER OR NOT THE BAD SECTOR FILES
;HAVE BEEN RECOVERED.
;      TST      MEDENB        ;HAS BAD SECTOR FILES BEEN RECOVERED ?
;      BEQ      1$           ;BR IF NO
;      JMP      54$          ;YES, BAD SECTOR FILE IS AVAILABLE

;RECOVER THE MANUFACTURES / USERS BAD SECTOR FILE FROM CYLINDER = 822.,
;TRACK LAST TRACK (RM02/3 = 4 AND RM05 = 18.). ALSO, SAVE THE USER'S
;PUT BUFFER
1$:
;      MOV      R0,-(SP)      ;;PUSH R0 ON STACK
;      CLR      R0           ;START WITH RMCS1
2$:
;      MOV      PUTBUF(R0),BUFFER(R0)
;      ADD      #2,R0        ;ADVANCE TO NEXT BUFFER POSITION
;      CMP      #46,R0       ;END OF BUFFER
;      BHS     2$           ;NO !!

;SET RETRY COUNT AND LOAD PUT BUFFER AND REGISTER INDEX TABLE
;SETUP PARAMETERS TO READ SKIP SECTOR FILE FIRST (3 SECTORS)
;      MOV      #3,68$       ;RETRY COUNT
```

```
040242
040242 062716 000006
040246 105076 000000
040252 162716 000006

040256 005737 001512
040262 001402
040264 000137 041542

040270
040270 010046
040272 005000
040274 016060 001412 106436
040302 062700 000002
040306 022700 000046
040312 103370

040314 012737 000003 042160
```

```

57 040322 012737 001466 001446      MOV      #822.,RMDCO      ;DESIRED CYLINDER = 822.
58 040330 013737 001334 001420      MOV      LSTRK,RMDAO     ;STARTING LAST TRACK, SECTOR = 0
59 040336 012737 177376 001414      MOV      #-258.,RMWCO    ;2 + 256. WORDS (2'S COMP)
60 040344 012737 010000 001444      MOV      #FMT16,RMOFO    ;16 BIT FORMAT
61 040352 012737 110446 001416      MOV      #MFGFIL,RMBAO   ;POINT TO MANUFACTURES FILE BUFFER
62
63 040360 012700 001553                MOV      #PUTINX,R0      ;R0 POINTS TO REGISTER INDEX TABLE
64 040364 112720 000006                MOV      #RMDA,(R0)+
65 040370 112720 000034                MOV      #RMDC,(R0)+
66 040374 112720 000002                MOV      #RMWC,(R0)+
67 040400 112720 000032                MOV      #RMOF,(R0)+
68 040404 112720 000004                MOV      #RMBA,(R0)+
69 040410 112720 000000                MOV      #RMCS1,(R0)+
70 040414 112720 000200                MOV      #200,(R0)+
71 040420 012600                MOV      (SP)+,R0      ;;POP STACK INTO R0
72
73                ;SET GET INDEX TABLE FOR READING STATUS
74 040422 3$:
75 040422 004737 042774                JSR      PC,GETSTS      ;SETUP GET INDEX REGISTER FOR STATUS
76 040426 004737 043060                JSR      PC,GET        ;GET REGISTERS
77 040432 000411                BR       5$            ;BR IF NO ERROR
78 040434 000401                BR       4$            ;JUMP OVER ERROR NUMBER
79 040436 000000                .WORD   0              ;ERROR DEFINED BY GET SUB
80 040440 062716 000006                4$:      ADD      #6,(SP)      ;XFER ERROR TO USER AND
81 040444 113776 040436 000000        MOV      4$-2,@(SP)    ;GET ERROR NUMBER.
82 040452 000137 041246                JMP      42$
83
84 040456 013737 001400 042172        5$:      MOV      RMER2I,73$     ;GET RMER2 AND SAVE FOR LATER
85
86                ;CLEAR THE DEVICE USING DRIVE CLEAR COMMAND
87 040464 012737 000011 001412        MOV      #DRVCLR!GO,RMCS10 ;LOAD COMMAND IN PUT BUFFER
88 040472 004737 043330                JSR      PC,PUT        ;OUTPUT COMMAND
89 040476 000411                BR       8$            ;RETURN HERE IF NO ERROR
90 040500 000401                BR       7$            ;GET AROUND ERROR #
91 040502 000000                6$:      .WORD   0              ;ERROR # GOES HERE
92 040504 062716 000006                7$:      ADD      #6,(SP)      ;MOVE SP TO USERS ERROR CALL
93 040510 113776 040502 000000        MOV      6$,@(SP)    ;MOVE ERROR NUMBER TO USER
94 040516 000137 041246                JMP      42$
95
96 040522 004737 043672                8$:      JSR      PC,TIMOUT     ;WAIT FOR COMPLETION
97 040526 004737 043060                JSR      PC,GET        ;GO GET STATUS
98 040532 000411                BR       11$           ;RETURN HERE IF NO ERROR
99 040534 000401                BR       10$          ;GET AROUND ERROR #
100 040536 000000                9$:      .WORD   0              ;ERROR # GOES HERE
101 040540 062716 000006                10$:     ADD      #6,(SP)      ;MOVE SP TO USERS ERROR CALL
102 040544 113776 040536 000000        MOV      9$,@(SP)    ;MOVE ERROR # TO USERS ERROR CALL
103 040552 000137 041246                JMP      42$
104
105 040556 004737 055770                11$:     JSR      PC,DRVSTS     ;GO VERIFY DRIVE CLEAR COMMAND
106 040562 000412                BR       14$           ;RETURN HERE IF NO ERROR
107 040564 000401                BR       13$          ;GET AROUND ERROR
108 040566 000000                12$:     .WORD   0              ;ERROR # GOES HERE
109 040570 005726                13$:     TST      (SP)+        ;STRIP RETURN TO SUBROUTINE
110 040572 062716 000006                ADD      #6,(SP)      ;MOVE SP TO USERS ERROR CALL
111 040576 113776 040566 000000        MOV      12$,@(SP)   ;MOVE ERROR # TO USER CALL
112 040604 000137 041246                JMP      42$
113

```

```

114 ;ISSUE A PACK ACKNOWLEDGE IF VOLUME VALID IS RESET
115 040610 14$:
116 040610 032737 000100 001350 BIT #VV,RMDSI ;IS VV RESET ??
117 040616 001052 BNE 23$ ;NO ..
118
119 040620 012737 000023 001412 MOV #PACACK.GO,RMCS10 ;LOAD COMMAND
120 040626 004737 043330 JSR PC,PUT ;GO PUT COMMAND TO DRIVE
121 040632 000411 BR 17$ ;RETURN HERE IF NO OUTPUT ERROR
122 040634 000401 BR 16$ ;GET AROUND ERROR #
123 040636 000000 15$: .WORD 0 ;ERROR # GOES HERE
124 040640 062716 000006 16$: ADD #6,(SP) ;MOVE SP TO USERS ERROR CALL
125 040644 113776 040636 000000 MOVB 15$,@ (SP) ;MOVE ERROR # TO ERROR CALL
126 040652 000137 041246 JMP 42$
127
128 040656 004737 043672 17$: JSR PC,TIMOUT ;WAIT FOR COMPLETION
129 040662 004737 043060 JSR PC,GET ;GO GET STATUS FOR PACK ACK
130 040666 000411 BR 20$ ;RETURN HERE IF NO ERROR
131 040670 000401 BR 19$ ;GET AROUND ERROR #
132 040672 000000 18$: .WORD 0 ;ERROR # GOES HERE
133 040674 062716 000006 19$: ADD #6,(SP) ;MOVE SP TO USERS ERROR CALL
134 040700 113776 040672 000000 MOVB 18$,@ (SP) ;MOVE ERROR # TO CALL
135 040706 000137 041246 JMP 42$
136
137 040712 004737 053432 20$: JSR PC,ACKSTS ;GO VERIFY ACKNOWLEDGE STATUS
138 040716 000412 BR 23$ ;RETURN HERE IF NO ERROR
139 040720 000401 BR 22$ ;GET AROUND ERROR #
140 040722 000000 21$: .WORD 0 ;ERROR # GOES HERE
141 040724 005726 22$: TST (SP)+ ;STRIP RETURN TO SUBROUTINE
142 040726 062716 000006 ADD #6,(SP) ;MOVE SP TO USERS ERROR CALL
143 040732 113776 040722 000000 MOVB 21$,@ (SP) ;MOVE ERROR # TO USERS ERROR CALL
144 040740 000137 041246 JMP 42$
145
146 ;RECALIBRATE THE DRIVE IF 'SKI' OR 'PIP IS SET
147 040744 23$:
148 040744 032737 040000 042172 BIT #SKI,73$ ;WAS SKI SET ?
149 040752 001004 BNE 24$ ;YES, GO RECALIBRATE
150 040754 032737 020000 001350 BIT #PIP,RMDSI ;IS PIP SET ??
151 040762 001452 BEQ 32$ ;NO !!
152
153 040764 012737 000007 001412 24$: MOV #RECAL!GO,RMCS10 ;LOAD RECALIBRATE COMMAND
154 040772 004737 043330 JSR PC,PUT ;PUT THE RECAL COMMAND
155 040776 000411 BR 26$ ;RETURN HERE IF NO ERROR
156 041000 000401 BR 25$ ;GET AROUND ERROR #
157 041002 000000 .WORD 0 ;ERROR # GOES HERE
158 041004 062716 000006 25$: ADD #6,(SP) ;MOVE SP TO USERS ERROR CALL
159 041010 113776 041002 000000 MOVB 25$-2,@ (SP) ;MOVE ERROR # TO USERS CALL
160 041016 000137 041246 JMP 42$
161
162 041022 004737 043672 26$: JSR PC,TIMOUT ;WAIT FOR RECALIBRATE TO COMPLETE
163 041026 004737 043060 JSR PC,GET ;GO GET RECAL STATUS
164 041032 000411 BR 29$ ;RETURN HERE IF NO ERROR
165 041034 000401 BR 28$ ;GET AROUND ERROR #
166 041036 000000 27$: .WORD 0 ;ERROR # GOES HERE
167 041040 062716 000006 28$: ADD #6,(SP) ;MOVE SP TO USERS ERROR CALL
168 041044 113776 041036 000000 MOVB 27$,@ (SP) ;MOVE ERROR TO USERS CALL
169 041052 000137 041246 JMP 42$
170

```

```

171 041056 004737 054226      29$: JSR PC,RCLSTS      ;GO VERIFY RECALIBRATE STATUS
172 041062 000412              BR 32$                ;RETURN HERE IF NO ERROR
173 041064 000401              BR 31$                ;GET AROUND ERROR #
174 041066 000000      30$: .WORD 0          ;ERROR # GOES HERE
175 041070 005726      31$: TST (SP)+        ;STRIP RETURN TO SUBROUTINE
176 041072 062716 000006      ADD #6,(SP)          ;MOVE SP TO USERS ERROR CALL
177 041076 113776 041066 000000  MOVB 30$,@ (SP)     ;MOVE ERROR # TO USERS CALL
178 041104 000137 041246      JMP 42$
179
180 ;READ THE SECTOR IDENTIFIED BY RMDAO, INCLUDING HEADER AND DATA
181 041110      32$:
182 041110 012737 000073 001412  MOV #RH!GO,RMCS10   ;LOAD READ HEADER AND DATA COMMAND
183 041116 004737 043330      JSR PC,PUT          ;PUT COMMAND
184 041122 000411              BR 35$                ;RETURN HERE IF NO ERROR
185 041124 000401              BR 34$                ;GET AROUND ERROR #
186 041126 000000      33$: .WORD 0          ;ERROR # GOES HERE
187 041130 062716 000006      34$: ADD #6,(SP)          ;MOVE SP TO USERS ERROR CALL
188 041134 113776 041126 000000  MOVB 33$,@ (SP)     ;MOVE ERROR # TO USERS ERROR CALL
189 041142 000137 041246      JMP 42$
190
191 041146 004737 043672      35$: JSR PC,TIMOUT     ;WAIT FOR READ OPERATION TO COMPLETE
192 041152 004737 043060      JSR PC,GET          ;GO GET STATUS FOR READ OPERATION
193 041156 000411              BR 38$                ;RETURN HERE IF NO ERROR
194 041160 000401              BR 37$                ;GET AROUND ERROR #
195 041162 000000      36$: .WORD 0          ;ERROR # GOES HERE
196 041164 062716 000006      37$: ADD #6,(SP)          ;MOVE SP TO USERS ERROR CALL
197 041170 113776 041162 000000  MOVB 36$,@ (SP)     ;MOVE ERROR # TO CALL
198 041176 000137 041246      JMP 42$
199
200 041202 004737 056572      38$: JSR PC,DTASTS     ;GO VERIFY RESULTS OF READ OPERATION
201 041206 000412              BR 41$                ;RETURN HERE IF NO ERROR
202 041210 000401              BR 40$                ;GET AROUND ERROR #
203 041212 000000      39$: .WORD 0          ;ERROR # GOES HERE
204 041214 005726      40$: TST (SP)+        ;STRIP RETURN ADDRESS TO SUBROUTINE
205 041216 062716 000006      ADD #6,(SP)          ;MOVE SP TO USERS ERROR CALL
206 041222 113776 041212 000000  MOVB 39$,@ (SP)     ;MOVE ERROR # TO USERS CALL
207 041230 000137 041246      JMP 42$
208
209 041234 032737 040000 001336  41$: BIT #TRE,RMCS1I   ;ANY CONTROLLER ERRORS ?
210 041242 001001              BNE 42$                ;BR IF YES
211 041244 000446              BR 48$                ;NO ERRORS DETECTED
212
213 ;*****
214 ;AN ERROR HAS BEEN DETECTED IN TRYING TO READ THE BAD SECTOR FILE.
215 ;THE SECTOR WILL BE RETRIED IF POSSIBLE.
216
217 041246 005337 042160      42$: DEC 68$          ;YES, DECREMENT RETRY COUNT AND
218 041252 100026              BPL 45$                ;RETRY IF COUNT NOT NEGATIVE.
219
220 ;THE RETRY COUNT HAS EXPIRED - SEE IF THE ERROR IS MEDIA RELATED
221
222 041254 032737 100720 001352  43$: BIT #DCK.HCRC!HCE.FER!ECH,RMER1I ;ANY MEDIA RELATED ERRORS ?
223 041262 001004              BNE 44$                ;YES, GO TRY NEXT AVAILABLE SECTOR
224
225 041264 032737 100000 001400  BIT #BSE,RMER2I     ;ANY MEDIA RELATED ERRORS ?
226 041272 001422              BEQ 46$                ;NO, EXIT AND REPORT ERROR ON RETURN
227
    
```



```

228 ;THE ERRORS DETECTED WHILE TRYING TO RECOVER THE BAD SECTOR FILE ARE
229 ;DUE TO THE MEDIA. SEE IF THE BAD SECTOR FILE CAN BE RECOVERED FROM
230 ;ANOTHER AREA ON THE LAST TRACK
231
232 041274 062737 000002 001420 44$: ADD #2,RMDAO ;ADVANCE SECTOR ADDRESS BY 2
233 041302 122737 000012 001420 CMPB #10.,RMDAO ;QUIT IF ALL MFG SECTORS HAVE BEEN
234 041310 001413 BEQ 46$ ;TRIED.
235 041312 122737 000040 001420 CMPB #32.,RMDAO ;QUIT IF ALL USER SECTORS HAVE BEEN
236 041320 001407 BEQ 46$ ;TRIED.
237
238 041322 012737 000003 042160 MOV #3,68$ ;REINSTATE RETRY COUNT FOR THIS SECTOR
239 041330 162716 000006 45$: SUB #6,(SP) ;MOVE SP BACK TO NO ERROR
240 041334 000137 040422 JMP 3$ ;RETRY THE READ OPERATION
241
242 ;THE BAD SECTOR FILE CANNOT BE READ
243
244 041340 000240 46$: NOP
245 041342 032777 020000 137604 BIT #SW13,@SWR ;INHIBIT MESSAGE ?
246 041350 001002 BNE 47$ ;YES
247 041352 162716 000004 SUB #4,(SP) ;MOVE SP TO ERROR RETURN
248 041356 000137 042154 47$: JMP 67$ ;GO TO MODULE EXIT
249
250 ;THE SECTOR WAS RECOVERED WITHOUT ERROR - READ THE USER FILE IF
251 ;THIS IS THE MFG FILE OR ELSE DONE.
252
253 041362 022737 111454 001416 48$: CMP #USRFIL,RMBAO ;WAS THE USER FILE READ ??
254 041370 001446 BEQ 52$ ;YES - READ IS COMPLETE
255 041372 112737 000012 001420 MOVB #10.,RMDAO ;READ THE USER FILE LAST TRACK, SECTOR 10.
256 041400 012737 111454 001416 MOV #USRFIL,RMBAO ;POINT TO USERS FILE BUFFER
257
258 041406 012737 000003 042160 MOV #3,68$ ;RELOAD THE RETRY COUNT FOR THIS SECTOR
259 041414 000137 040422 JMP 3$ ;GO READ THE USER FILE
260
261 ;DUMMY THE BAD SECTOR FILES
262 041420 49$:
263 041420 010046 MOV R0,-(SP) ;;PUSH R0 ON STACK
264 041422 010146 MOV R1,-(SP) ;;PUSH R1 ON STACK
265 041424 012701 000374 MOV #252.,R1 ;R1 = NUMBER OF ENTRIES IN FILES
266 041430 012700 000014 MOV #14,R0 ;R0 = ADDRESS INDEX TO FILE STORAGE
267 041434 012760 177777 110446 50$: MOV #-1,MFGFIL(R0) ;ENTER ALL ONES IN MFG FILE
268 041442 012760 177777 111454 MOV #-1,USRFIL(R0) ;ENTER ALL ONES IN USER FILE
269 041450 005720 TST (R0)+ ;ADVANCE ADDRESS
270 041452 005301 DEC R1 ;DECREMENT COUNT
271 041454 001367 BNE 50$ ;CONTINUE IF NOT DONE
272
273 041456 012701 000006 MOV #6.,R1 ;CLEAR HEADER, CLEAR ID & SERIAL NUMBERS
274 041462 005000 CLR R0
275 041464 005060 110446 51$: CLR MFGFIL(R0)
276 041470 005060 111454 CLR USRFIL(R0)
277 041474 005720 TST (R0)+ ;ADVANCE ADDRESS
278 041476 005301 DEC R1
279 041500 001371 BNE 51$
280 041502 012601 MOV (SP)+,R1 ;;POP STACK INTO R1
281 041504 012600 MOV (SP)+,R0 ;;POP STACK INTO R0
282
283 ;SET MEDIA ENABLE AND RESTORE THE USERS PUT BUFFER
284 52$.
    
```

```

041506 010046      MOV      R0,-(SP)      ;;PUSH R0 ON STACK
282 041510 005000      CLR      R0           ;;R0 IS REGISTER INDEX
283 041512 012737 177777 001512      MOV      #-1,MEDEMB
284 041520 016060 106436 001412 53$:      MOV      BUFFER(R0),PUTBUF(R0)
285 041526 062700 000002      ADD      #2,R0        ;ADVANCE R0
286 041532 022700 000046      CMP      #46,R0       ;DONE ??
287 041536 103370      BRIS    53$
288 041540 012600      MOV      (SP)+,R0     ;;POP STACK INTO R0
289
290
291
292
293
294
295
296
297 041542
041542 010046      MOV      R0,-(SP)      ;;PUSH R0 ON STACK
041544 010146      MOV      R1,-(SP)      ;;PUSH R1 ON STACK
041546 010246      MOV      R2,-(SP)      ;;PUSH R2 ON STACK
298 041550 013737 001446 001514      MOV      RMDCO,ASNDC   ;LOAD REQUESTED CYLINDER, TRACK,
299 041556 013737 001420 001516      MOV      RMDAO,ASNDA   ;AND SECTOR ADDRESS IN ASSIGNED STORAGE
300 041564 005002      CLR      R2           ;R2 = NUMBER OF SECTORS
301 041566 013700 001414      MOV      RMCWC,R0      ;R0 = WORD COUNT
302 041572 005400      NEG      R0           ;MAKE NUMBER POSITIVE
303 041574 012701 000400      MOV      #256.,R1      ;R1 = NUMBER OF WORDS PER SECTOR
304 041600 032737 000002 001412      BIT      #BIT1,RMCS10  ;IS THIS A HEADER AND DATA COMMAND ??
305 041606 001402      BEQ     55$           ;NO !!
306 041610 012701 000402      MOV      #258.,R1      ;CHANGE WORDS PER SECTOR
307 041614 020100 55$:      CMP      R1,R0        ;IS THERE A FULL SECTOR ??
308 041616 101404      BLOS    56$           ;YES !!
309 041620 005700      TST     R0           ;IS R0 ZERO ??
310 041622 001405      BEQ     57$           ;YES !!
311 041624 005202      INC     R2           ;INCREMENT FOR PARTIAL SECTOR
312 041626 000403      BR      57$
313 041630 160100 56$:      SUB     R1,R0        ;SUBTRACT ONE SECTOR FROM WORD COUNT
314 041632 005202      INC     R2           ;INCREMENT SECTOR COUNT
315 041634 000767      BR      55$
316 041636 010237 042160 57$:      MOV     R2,68$       ;SAVE SECTOR COUNT
317
318
319
320
321
322 041642 012737 110462 042170      MOV     #MFGFIL+14,72$ ;THE STARTING ADDRESS OF MFG FILE
323
324 041650 004737 041672      JSR     PC,58$        ;TO BASE ADDRESS STORAGE.
325 041654 012737 111470 042170      MOV     #USRFIL+14,72$ ;LOAD STARTING ADDRESS OF USR FILE
326
327 041662 004737 041672      JSR     PC,58$        ;TO BASE ADDRESS STORAGE.
328 041666 000137 042132      JMP     66$          ;GO SEARCH FILE
329
330 041672 013737 001514 042164 58$:      MOV     ASNDC,70$     ;LOAD COMPARING CYLINDER ADDRESS
331 041700 013737 001516 042166      MOV     ASNDA,71$     ;LOAD COMPARING TRACK, SECTOR ADDRESS
332 041706 013737 042160 042162      MOV     68$,69$      ;LOAD NUMBER OF SECTORS TO CONFIRM
333
334

```

;;SETUP FOR A BINARY SEARCH OF THE CURRENT FILE FOR THE COMPARING

```

335 ;CYLINDER, TRACK AND SECTOR ADDRESS
336 041714 59$:
337 041714 013700 042170 MOV 72$,RO ;LOAD THE BASE ADDRESS IN RO
338 041720 022710 177777 60$: CMP #-1,(RO) ;IS THIS FILE TERMINATOR ?
339 041724 001446 BEQ 64$ ;BR IF YES
340 041726 021037 042164 CMP (RO),70$ ;DOES TABLE ENTRY = COMPARING CYLINDER ?
341 041732 001010 BNE 62$ ;BR IF NO
342
343 ;FILE ENTRY EQUALS COMPARING CYLINDER. SEE IF THE NEXT ENTRY EQUALS
344 ;THE COMPARING TRACK, AND SECTOR.
345 041734 61$:
346 041734 126037 000003 042167 CMPB 3(RO),71$+1 ;DOES TABLE ENTRY = COMPARING TRACK ?
347 041742 001004 BNE 62$ ;BR IF NO
348
349 041744 126037 000002 042166 CMPB 2(RO),71$ ;DOES TABLE ENTRY - COMPARING SECTOR ?
350 041752 001402 BEQ 63$ ;BR IF YES
351
352 041754 022020 62$: CMP (RO)+,(RO)+ ;NO, ADJUST CYLINDER POINTER IN BAD FILE
353 041756 000760 BR 60$ ;AND CONTINUE SEARCH.
354
355 ;THE COMPARING CYLINDER, TRACK AND SECTOR IS IN THE BAD SECTOR FILE.
356 ;ADVANCE THE ASSIGNED SECTOR AND START THE SEARCH ALL OVER.
357 041760 63$:
358 041760 105237 001516 INCB ASNDA ;INCREMENT SECTOR
359 041764 122737 000037 001516 CMPB #31.,ASNDA ;SECTOR OK ??
360 041772 103337 BHIS 58$ ;YES !!
361 041774 105037 001516 CLR ASNDA ;CLEAR SECTOR AND ADVANCE TRACK
362 042000 105237 001517 INCB ASNDA+1
363 042004 123737 001335 001517 CMPB LSTRK+1,ASNDA+1 ;TRACK OK ?
364 042012 103327 BHIS 58$ ;YES !!
365 042014 005037 001516 CLR ASNDA ;CLEAR TRACK AND SECTOR
366 042020 005237 001514 INC ASNDC ;INCREMENT CYLINDER
367 042024 022737 001466 001514 CMP #822.,ASNDC ;CYLINDER OK ??
368 042032 103317 BHIS 58$ ;YES !.
369 042034 005037 001514 CLR ASNDC ;START AT CYLINDER 0
370 042040 000714 BR 58$ ;SEARCH NEXT SECTOR
371
372 ;THE COMPARING SECTOR IS NOT IN THE BAD SECTOR FILES. DECREMENT THE
373 ;NUMBER OF SECTORS TO COMPARE AND SEARCH THE NEXT SECTOR IF THE NUMBER
374 ;IS NOT ZERO.
375 042042 64$:
376 042042 005337 042162 DEC 69$ ;DECREMENT NUMBER OF SECTORS TO COMPARE
377 042046 001442 BEQ 67$ ;DONE IF ZERO
378
379 042050 105237 042166 INCB 71$ ;INCREMENT THE COMPARING SECTOR
380 042054 122737 000037 042166 CMPB #31.,71$ ;SECTOR OK ??
381 042062 103022 BHIS 65$ ;YES !!
382 042064 105037 042166 CLR 71$ ;CLEAR SECTOR
383 042070 105237 042167 INCB 71$+1 ;INCREMENT TRACK
384 042074 123737 001335 042167 CMPB LSTRK+1,71$+1 ;TRACK OK ??
385 042102 103012 BHIS 65$ ;YES !!
386 042104 005037 042166 CLR 71$ ;CLEAR SECTOR TRACK
387 042110 005237 042164 INC 70$ ;INCREMENT CYLINDER
388 042114 022737 001466 042164 CMP #822.,70$ ;CYLINDER OK ??
389 042122 103002 BHIS 65$ ;YES !!
390 042124 005037 042164 CLR 70$ ;START AT CYLINDER 0
391
    
```

```

392 042130 000671      65$:   BR      59$           ;SEARCH NEXT SECTOR
393
394                   ;ASSIGN THE SECTOR AND RETURN TO USER
395 042132
396 042132 013737 001514 001446      66$:   MOV      ASNDC,RMDCO      ;LOAD CYLINDER
397 042140 013737 001516 001420      MOV      ASNDA,RMDAO      ;LOAD TRACK AND SECTOR
398 042146 012602      MOV      (SP)+,R2        ;;POP STACK INTO R2
      042150 012601      MOV      (SP)+,R1        ;;POP STACK INTO R1
      042152 012600      MOV      (SP)+,R0        ;;POP STACK INTO R0
399
400 042154 000240      67$:   NOP
401 042156 000207      RTS      PC
402
403                   ;THE FOLLOWING ARE STORAGE LOCATIONS FOR THE MODULE
404
405 042160 000000      68$:   .WORD  0           ;RETRY COUNT/ NUMBER OF SECTORS REQUIRED
406 042162 000000      69$:   .WORD  0           ;NUMBER OF SECTORS TO COMPARE
407 042164 000000      70$:   .WORD  0           ;COMPARING CYLINDER
408 042166 000000      71$:   .WORD  0           ;COMPARING TRACK AND SECTOR
409 042170 000000      72$:   .WORD  0           ;BASE ADDRESS OF BAD SECTOR FILE BEING SEARCHED
410 042172 000000      73$:   .WORD  0           ;CONTAINS RMER2

```

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52

.SBTTL BUFFER GENERATOR SUBROUTINE

; THIS SUBROUTINE GENERATES A DATA BUFFER FOR WRITE COMMANDS. THE
 ; BUFFER STARTS AT RMBA AND IS RMWC WORDS LONG. THE BUFFER
 ; CONTAINS A REPETITIVE DATA PATTERN CONSISTING OF \$TMP1 WORDS
 ; FROM THE DATA PATTERN TABLE, BEGINNING AT ADDRESS \$TMP0.
 ; HEADER INFORMATION FOR THE BUFFER IS EXTRACTED FROM RMDC,
 ; RMDA AND RMOF.

; R0 = ADDRESS OF DATA BUFFER
 ; R1 = LENGTH OF DATA BUFFER
 ; R2 = ADDRESS OF DATA PATTERN
 ; R3 = LENGTH OF DATA PATTERN
 ; R4 = SECTOR COUNT

; CALL :
 ; (1) JSR PC,GENBUF
 ; (2) ?? RETURN HERE

GENBUF:

MOV R0,-(SP) ;;PUSH R0 ON STACK
 MOV R1,-(SP) ;;PUSH R1 ON STACK
 MOV R2,-(SP) ;;PUSH R2 ON STACK
 MOV R3,-(SP) ;;PUSH R3 ON STACK
 MOV R4,-(SP) ;;PUSH R4 ON STACK
 MOV RMBA,R0 ;LOAD DATA BUFFER ADDRESS
 MOV RMWC,R1 ;LOAD WORD COUNT
 MOV RMDCO,60\$;LOAD STARTING CYLINDER ADDRESS
 MOV RMDAO,65\$;LOAD STARTING TRACK,SECTOR ADDRESS

10\$: BIT #BIT1,RMCS10 ;WRITE HEADER & DATA??
 BEQ 25\$;NO!!
 MOV 60\$,(R0) ;WRITE HEADER WORD #1
 BIS #MSE!USE,(R0) ;SET BAD SECTOR FLAGS FOR GOOD SECTOR
 MOV #29.,R2 ;R2 = MAXIMUM SECTOR ADDRESS (29.)

BIT #FMT16,RMOFO ;18 BIT FORMAT??
 BEQ 15\$;YES !!
 BIS #FMT16,(R0) ;SET 16 FORMAT BIT IN HEADER
 MOV #31.,R2 ;CHANGE MAXIMUM SECTOR ADDRESS (31.)

15\$: INC R1 ;INCREMENT WORD COUNT
 BEQ 50\$;EXIT IF DONE

TST (R0)+ ;MOVE R0 TO HEADER WORD #2
 MOV 65\$,(R0)+ ;WRITE HEADER WORD #2
 INC R1 ;INCREMENT WORD COUNT AND
 BEQ 50\$;EXIT IF DONE
 MOV #65\$,R3 ;ADVANCE SECTOR ADDRESS

INCB (R3) ;SECTOR OVERFLOW ??
 CMPB R2,(R3) ;NO !!
 BHIS 25\$;YES - CLEAR SECTOR ADDRESS
 CLRB (R3) ;ADVANCE TRACK ADDRESS
 INCB 1(R3) ;TRACK OVERFLOW ??
 CMPB LSTRK+1,1(R3) ;NO !!
 BHIS 25\$;YES - CLEAR TRACK ADDRESS
 CLRB 1(R3)

042174
 042174 010046
 042176 010146
 042200 010246
 042202 010346
 042204 010446
 042206 013700 001416
 042212 013701 001414
 042216 013737 001446 042426
 042224 013737 001420 042430
 042232 032737 000002 001412 10\$:
 042240 001445
 042242 013710 042426
 042246 052710 140000
 042252 012702 000035
 042256 032737 010000 001444
 042264 001404
 042266 052710 010000
 042272 012702 000037
 042276 005201 15\$:
 042300 001443
 042302 005720
 042304 013720 042430
 042310 005201
 042312 001436
 042314 012703 042430
 042320 105213
 042322 120213
 042324 103013
 042326 105013
 042330 105263 000001
 042334 123763 001335 000001
 042342 103004
 042344 105063 000001

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53

.SBTTL COMPARE BUFFER SUBROUTINE

:THIS SUBROUTINE COMPARES THE CONTENTS OF BUFONE AND BUFTWO,
 :ASSUMING THAT BUFONE IS THE BUFFER FROM WHICH DATA WAS WRITTEN
 :AND BUFTWO IS THE BUFFER TO WHICH DATA WAS READ. ERRORS IN BUFFER
 :COMPARISON ARE REPORTED TO THE USER VIA THE USER'S ERROR CALL.

:CALL:
 :(1) JSR PC,CMPBUF
 :(2) .WORD WRITE BUFFER ADDRESS
 :(3) .WORD READ BUFFER ADDRESS
 :(4) BR ?? RETURN HERE IF NO ERROR
 :(5) NOP RETURN HERE IF ERROR
 :(6) ERROR ERROR DEFINED BY SUBROUTINE
 :(7) ???

CMPBUF:
 MOV R0,-(SP) ;;PUSH R0 ON STACK
 MOV R1,-(SP) ;;PUSH R1 ON STACK
 MOV R2,-(SP) ;;PUSH R2 ON STACK
 MOV R3,-(SP) ;;PUSH R3 ON STACK
 CLR 150\$;;CLEAR CORRECTION FLAG

:DETERMINE IF DATA SHOULD BE CORRECTED
 BIT ECI,RMOFI ;;WAS ECC CORRECTION ALLOWED ??
 BNE 80\$;;NO !!
 BIT #DCK,RMER1I ;;WAS THERE A DATA CHECK ??
 BEQ 80\$;;NO !!
 BIT #ECH,RMER1I ;;IS ERROR CORRECTION HARD SET ?
 BNE 80\$;;YES !!
 BIT #FMT16,RMOFI ;;IS THIS 16 BIT FORMAT ??
 BEQ 80\$;;NO !!

:CORRECT DATA USING ECC INFORMATION
 MOV RMBAO,R0 ;;R0 = STARTING BUFFER ADDRESS
 MOV RMECI,R1 ;;R1 - ECC POSITION
 BIS #BIT15,150\$;;SET CORRECTION FLAG

:MOVE R0 TO WORD BOUNDARY OF ERROR BURST
 10\$: CMP #16.,R1 ;;IS BIT POSITION > 1 WORD
 BHIS 20\$;;NO !!
 SUB #16.,R1 ;;SUBTRACT 1 WORDS WORTH
 TST (R0)+ ;;ADVANCE BUFFER ADDRESS 1 WORD
 BR 10\$
 20\$: MOV #1,R2 ;;R2 = BIT POINTER
 MOV R2,R3 ;;R3 = BIT NUMBER

:MOVE R2 TO STARTING BIT OF ERROR BURST
 30\$: CMP R3,R1 ;;IS R3 SAME AS R1 ??
 BEQ 35\$;;YES !!
 ASL R2 ;;SHIFT BIT POINTER
 INC R3 ;;INCREMENT BIT NUMBER
 BR 30\$
 35\$: MOV #11.,R3 ;;R3 - LENGTH OF ERROR BURST

:CORRECT THE ERROR BURST
 40\$: BIT R2,RMECI ;;IS THIS BIT SET IN ECC PATTERN ??

042432
 042432 010046
 042434 010146
 042436 010246
 042440 010346
 042442 005037 042772
 042446 033737 004000 001370
 042454 001063
 042456 032737 100000 001352
 042464 001457
 042466 032737 000100 001352
 042474 001053
 042476 032737 010000 001370
 042504 001447
 042506 013700 001416
 042512 013701 001402
 042516 052737 100000 042772
 042524 022701 000020
 042530 103004
 042532 162701 000020
 042536 005720
 042540 000771
 042542 012702 000001
 042546 010203
 042550 020301
 042552 001403
 042554 006302
 042556 005203
 042560 000773
 042562 012703 000013
 042566 030237 001404

```

54 042572 001405      BEQ      60$      ;NO - DO NOT CORRECT THIS BIT
55 042574 030210      BIT      R2,(R0)  ;IS THE BIT PRESENTLY SET ??
56 042576 001402      BEQ      50$      ;NO
57 042600 040210      BIC      R2,(R0)  ;RESET THE BIT
58 042602 000401      BR       60$
59 042604 050210      50$:    BIS      R2,(R0)  ;SET THE BIT
60 042606 006302      60$:    ASL      R2      ;SHIFT TO NEXT BIT
61 042610 001003      BNE      70$
62 042612 012702 000001  MOV      #1,R2    ;CONTINUE WITH FIRST BIT OF NEXT WORD
63 042616 005720      TST      (R0)+
64 042620 005303      70$:    DEC      R3      ;END OF BURST ??
65 042622 001361      BNE      40$      ;NO !
66
67      ;COMPARE WRITE BUFFER TO READ BUFFER
68 042624 017600 000010  80$:    MOV      @10(SP),R0 ;R0 = WRITE BUFFER
69 042630 062766 000002 000010  ADD      #2,10(SP) ;MOVE SP TO READ ADDRESS
70 042636 017601 000010      MOV      @10(SP),R1 ;R1 = READ BUFFER
71 042642 062766 000002 000010  ADD      #2,10(SP) ;MOVE SP TO RETURN ADDRESS
72 042650 013702 001340      MOV      RMWCI,R2 ;R2 = NUMBER OF WORDS TRANSFER
73 042654 163702 001414      SUB      RMWCO,R2
74 042660 022021      90$:    CMP      (R0)+,(R1)+ ;COMPARE DATA WORDS
75 042662 001003      BNE      100$     ;EXIT IF NOT EQUAL
76 042664 005302      DEC      R2      ;DECREMENT WORD COUNT
77 042666 001374      BNE      90$     ;CONTINUE IF NOT DONE
78 042670 000433      BR       110$    ;DONE COMPARE - NO ERROR
79
80      ;DATA COMPARE FAILED
81 042672 014037 001140  100$:   MOV      -(R0),%GDDAT ;STORE GOOD DATA FOR TYPEOUT
82 042676 014137 001142      MOV      -(R1),%BDDAT ;STORE BAD DATA FOR TYPEOUT
83 042702 010037 001134      MOV      R0,%GDADR   ;STORE ADDRESS OF GOOD DATA
84 042706 010137 001136      MOV      R1,%BDADR   ;STORE ADDRESS OF BAD DATA
85 042712 010237 001174      MOV      R2,%TMP0    ;STORE WORD COUNT OF ERROR
86 042716 062766 000004 000010  ADD      #4,10(SP) ;MOVE SP TO USER'S ERROR CALL
87 042724 112776 000336 000010  MOVB     #336,@10(SP) ;WRITE ERROR NUMBER IN CALL
88
89      ;CHANGE ERROR NUMBER IF ECC CORRECTION FAILED
90 042732 032737 100000 042772  BIT      #BIT15,150$ ;WAS ECC CORRECTION USED ??
91 042740 001403      BEQ      105$     ;NO !!
92 042742 112776 000163 000010  MOVB     #163,@10(SP) ;ECC CORRECTION FAILED
93 042750 162766 000002 000010  105$:   SUB      #2,10(SP) ;MOVE SP TO RETURN IF ERROR
94 042756 000240      NOP
95 042760      110$:
96 042760 012603      MOV      (SP)+,R3  ;;POP STACK INTO R3
97 042762 012602      MOV      (SP)+,R2  ;;POP STACK INTO R2
98 042764 012601      MOV      (SP)+,R1  ;;POP STACK INTO R1
99 042766 012600      MOV      (SP)+,R0  ;;POP STACK INTO R0
100 042770 000207      RTS      PC      ;RETURN TO USER
101
102 042772 000000      150$:   .WORD      ;ECC CORRECTION FLAG

```



```

1      .SBTTL  GET STATUS SUBROUTINE
2
3      ;THIS SUBROUTINE SETS UP THE 'GET INDEX TABLE' AND THE 'GET
4      ;BUFFER' FOR READING ALL SUBSYSTEM REGISTERS VIA THE GET SUBROUTINE
5      ;AND THEN RETURNS TO THE USER.
6      ;
7      ;CALL:  JSR      PC,GETSTS
8      ;      ???
9
10     GETSTS:
11     MOV      R0,-(SP)      ;;PUSH R0 ON STACK
12     MOV      R1,-(SP)      ;;PUSH R1 ON STACK
13     MOV      R2,-(SP)      ;;PUSH R2 ON STACK
14     MOV      #GETINX,R0    ;R0 = ADDRESS OF INDEX TABLE
15     MOV      #RMEC2I+2,R1  ;R1 = ADDRESS OF GET BUFFER
16     MOV      #RMEC2,R2     ;R2 = REGISTER INDE
17     2$:     MOVB     R2,(R0)+ ;WRITE REGISTER INDEX IN TABLE
18           CLR      -(R1)    ;CLEAR CORRESPONDING LOCATION
19     3$:     SUB      #2,R2   ;DECREMENT TO NEXT INDEX
20           BMI     4$       ;BRANCH OUT IF DONE
21           CMP     #RMDB,R2 ;DONT WRITE RMDB INDEX
22           BNE     2$
23           CLR     -(R1)
24     4$:     MOVB     #200,(R0)+ ;WRITE TERMINATOR
25           MOV     (SP)+,R2    ;;POP STACK INTO R2
26           MOV     (SP)+,R1    ;;POP STACK INTO R1
27           MOV     (SP)+,R0    ;;POP STACK INTO R0
28           NOP
29           RTS      PC
  
```

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51

.SBTTL GET SUBROUTINE
:THIS SUBROUTINE READS THE REGISTERS WHICH ARE LISTED IN THE
:'GET INDEX TABLE' AND STORES THEIR VALUES IN THE CORRESPONDING
:LOCATION IN THE 'GET REGISTER BUFFER'. FOR EXAMPLE, AN
:ENTRY OF 04 IN THE TABLE WILL CAUSE THE SUBROUTINE TO
:READ 'RMB A' AND STORE ITS CONTENTS AT THE LOCATION IN
:THE BUFFER ASSIGNED TO THAT REGISTER. THE NUMBER OF
:REGISTERS TO BE READ IS VARIABLE FROM 1 TO 22; THE INDEX
:TABLE MUST BE TERMINATED WITH A CONTROL BYTE (200)
:WHICH SHOULD FOLLOW THE LAST ENTRY.

:SUBROUTINE CALL:
:(1) 'GET INDEX TABLE' HAS BEEN LOADED WITH REGISTER INDEX
VALUES AND TERMINATED WITH A CONTROL BYTE
:(2) 'GET INPUT BUFFER' IS AVAILABLE FOR USE. (NOTE THAT
UNUSED LOCATIONS, I.E., ENTRIES IN BUFFER CORRESPONDING
TO REGISTERS NOT READ, ARE NOT CHANGED.)
:(3) JSR PC,GET
BR ??? RETURN HERE IF NO ERROR FOUND
NOP RETURN HERE IF ANY ERROR FOUND
ERROR SUB DEFINES ERROR NUMBER
???

:R0 = REGISTER BASE ADDRESS
:R1 = REGISTER ADDRESS
:R2 = BUFFER BASE ADDRESS
:R3 = BUFFER ADDRESS
:R4 = POINTER TO REGISTER INDEX

GET: NOP
ADD #4,(SP) ;CLEAR ERROR NUMBER IN USER'S
CLR @ (SP) ;ERROR CALL
SUB #4,(SP)
MOV R0,-(SP) ;;PUSH R0 ON STACK
MOV R1,-(SP) ;;PUSH R1 ON STACK
MOV R2,-(SP) ;;PUSH R2 ON STACK
MOV R3,-(SP) ;;PUSH R3 ON STACK
MOV R4,-(SP) ;;PUSH R4 ON STACK
MOV ERRVEC,-(SP) ;;PUSH ERRVEC ON STACK
MOV ERRVEC+2,-(SP) ;;PUSH ERRVEC+2 ON STACK
MOV \$BASE,R0
MOV #GETBUF,R2
MOV #GETINX,R4
MOV #5\$,ERRVEC ;SETUP FOR TIMEOUT
MOV #PR6,ERRVEC+2
1\$: MOV RMCS2(R0),\$TMP0 ;GET 'NED' STATUS
MOV RMCS1(R0),\$TMP1 ;GET 'DVA' STATUS
BIT #DVA,\$TMP1 ;DEVICE AVAILABLE??
BNE 3\$;YES!!
ADD #4,16(SP) ;WRITE ERROR NUMBER IN USER'S
MOVB #112,@16(SP) ;ERROR CALL
BR 7\$
3\$: TSTB (R4) ;DONE??
BMI 9\$;YES!!
MOVB (R4),R1 ;R1 = REGISTER ADDRESS
BIC #^CIDXMSK,R1 ;CLEAR ANY SIGN EXTENSION

043060 000240
043062 062716 000004
043066 105076 000000
043072 162716 000004
043076 010046
043100 010146
043102 010246
043104 010346
043106 010446
043110 013746 000004
043114 013746 000006
043120 013700 001276
043124 012702 001336
043130 012704 001524
043134 012737 043242 000004
043142 012737 000300 000006
043150 016037 000010 001174
043156 016037 000000 001176
043164 032737 004000 001176
043172 001007
043174 062766 000004 000016
043202 112776 000112 000016
043210 000423
043212 105714
043214 100433
043216 111401
043220 042701 177700

52	043224	060001				ADD	R0,R1	
53	043226	112403				MOVB	(R4)+,R3	;R3 - STORAGE ADDRESS FOR REGISTER
54	043230	042703	177700			BIC	#^CIDXMSK,R3	;CLEAR ANY SIGN EXTENSION
55	043234	060203				ADD	R2,R3	
56	043236	011113				MOV	(R1),(R3)	;READ REGISTER
57	043240	000764				BR	3\$	
58								
59	043242	022626			5\$:	CMP	(SP)+,(SP)+	;RESTORE STACK
60	043244	062766	000004	000016		ADD	#4,16(SP)	;WRITE ERROR NUMBER IN
61	043252	112776	000007	000016		MOVB	#7,@16(SP)	;USER'S ERROR CALL
62	043260	162766	000002	000016	7\$:	SUB	#2,16(SP)	
63	043266	105714			8\$:	TSTB	(R4)	;DONE CLEARING??
64	043270	100405				BMI	9\$;YES.!
65	043272	005003				CLR	R3	;CLEAR REMAINING STORAGE
66	043274	112403				MOVB	(R4)+,R3	;LOCATIONS
67	043276	060203				ADD	R2,R3	
68	043300	005013				CLR	(R3)	
69	043302	000771				BR	8\$	
70	043304				9\$:			
	043304	012637	000006			MOV	(SP)+,ERRVEC+2	::POP STACK INTO ERRVEC+2
	043310	012637	000004			MOV	(SP)+,ERRVEC	::POP STACK INTO ERRVEC
	043314	012604				MOV	(SP)+,R4	::POP STACK INTO R4
	043316	012603				MOV	(SP)+,R3	::POP STACK INTO R3
	043320	012602				MOV	(SP)+,R2	::POP STACK INTO R2
	043322	012601				MOV	(SP)+,R1	::POP STACK INTO R1
	043324	012600				MOV	(SP)+,R0	::POP STACK INTO R0
71	043326	000207				RTS	PC	;RETURN

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51

```
.SBTTL PUT SUBROUTINE

;THIS SUBROUTINE WRITES THE REGISTERS WHICH ARE LISTED IN THE
;'PUT INDEX TABLE' WITH THE CONTENTS OF THE CORRESPONDING
;LOCATION IN THE 'PUT REGISTER BUFFER'. THE NUMBER OF
;REGISTERS WRITTEN IS VARIABLE; THE INDEX TABLE MUST
;BE TERMINATED WITH A CONTROL BYTE (200) WHICH SHOULD
;FOLLOW THE LAST ENTRY.

;SUBROUTINE CALL:

(1) 'PUT INDEX TABLE' HAS BEEN LOADED WITH INDEX VALUES
    OF REGISTERS TO BE WRITTEN.
(2) 'PUT REGISTER BUFFER' CONTAINS CONTENTS OF EACH
    REGISTER TO BE WRITTEN.
(3) JSR PC,PUT
    BR ??? RETURN HERE IF NO ERROR FOUND
    NOP RETURN HERE IF ANY ERROR FOUND
    ERROR SUB DEFINES ERROR NUMBER
    ???

;R0 = REGISTER BASE ADDRESS
;R1 = REGISTER ADDRESS
;R2 = BUFFER BASE ADDRESS
;R3 = BUFFER ADDRESS
;R4 = POINTER TO REGISTER INDEX
```

```
PUT:  NOP
      MOV R0,-(SP) ;:PUSH R0 ON STACK
      MOV R1,-(SP) ;:PUSH R1 ON STACK
      MOV R2,-(SP) ;:PUSH R2 ON STACK
      MOV R3,-(SP) ;:PUSH R3 ON STACK
      MOV R4,-(SP) ;:PUSH R4 ON STACK
      MOV ERRVEC,-(SP) ;:PUSH ERRVEC ON STACK
      MOV ERRVEC+2,-(SP) ;:PUSH ERRVEC+2 ON STACK
      MOV $BASE,R0
      MOV #PUTBUF,R2
      MOV #PUTINX,R4
      MOV #5$,ERRVEC ;:SETUP FOR TIMEOUT
      MOV #PR6,ERRVEC+2
1$:  MOV RMCS2(R0),$TMP0 ;:GET 'NED' STATUS
      MOV RMCS1(R0),$TMP1 ;:GET 'DVA' STATUS
      BIT #DVA,$TMP1 ;:DEVICE AVAILABLE??
      BNE 3$ ;:YES!!
      ADD #4,16(SP) ;:WRITE ERROR NUMBER IN
      MOVB #112,@16(SP) ;:USER'S ERROR CALL
      BR 7$
3$:  TSTB (R4) ;:DONE??
      BMI 9$ ;:YES!!
      MOVB (R4),R1 ;:R1 = REGISTER ADDRESS
      BIC #^CIDXMSK,R1 ;:CLEAR ANY SIGN EXTENSION
      ADD R0,R1
      MOVB (R4),R3 ;:R3 = STORAGE ADDRESS
      BIC #^CIDXMSK,R3 ;:CLEAR ANY SIGN EXTENSION
      ADD R2,R3
4$:  MOV (R3),(R1) ;:WRITE REGISTER
      TSTB (R4)+ ;:ADJUST REGISTER POINTER
```

```
043330 000240
043332 010046
043334 010146
043336 010246
043340 010346
043342 010446
043344 013746 000004
043350 013746 000006
043354 013700 001276
043360 012702 001412
043364 012704 001553
043370 012737 043500 000004
043376 012737 000300 000006
043404 016037 000010 001174
043412 016037 000000 001176
043420 032737 004000 001176
043426 001007
043430 062766 000004 000016
043436 112776 000112 000016
043444 000424
043446 105714
043450 100425
043452 111401
043454 042701 177700
043460 060001
043462 111403
043464 042703 177700
043470 060203
043472 011311
043474 105724
```

```

52 043476 000763          BR      3$
53
54 043500 022626          5$:    CMP      (SP)+,(SP)+      ;ADJUST STACK
55 043502 062766 000004 000016  ADD      #4,16(SP)      ;WRITE ERROR NUMBER IN
56 043510 112776 000007 000016  MOVB     #7,@16(SP)     ;USER'S ERROR CALL
57 043516 162766 000002 000016  7$:    SUB      #2,16(SP)
58
59 043524          9$:
   043524 012637 000006  MOV      (SP)+,ERRVEC+2      ;;POP STACK INTO ERRVEC+2
   043530 012637 000004  MOV      (SP)+,ERRVEC      ;;POP STACK INTO ERRVEC
   043534 012604  MOV      (SP)+,R4          ;;POP STACK INTO R4
   043536 012603  MOV      (SP)+,R3          ;;POP STACK INTO R3
   043540 012602  MOV      (SP)+,R2          ;;POP STACK INTO R2
   043542 012601  MOV      (SP)+,R1          ;;POP STACK INTO R1
   043544 012600  MOV      (SP)+,R0          ;;POP STACK INTO R0
60 043546 000207  RTS      PC          ;RETURN
  
```

```

1          .SBTTL  SIZE CLOCK SUBROUTINE
2
3 043550    SIZCLK:
4 043550    013746 000004    MOV     ERRVEC,-(SP)      ;;PUSH ERRVEC ON STACK
5 043554    013746 000006    MOV     ERRVEC+2,-(SP)   ;;PUSH ERRVEC+2 ON STACK
6 043560    012737 043616 000004    MOV     #1$,ERRVEC      ;;SET UP FOR BUS TIMEOUT
7 043566    012737 000300 000006    MOV     #PR6,ERRVEC+2
8 043574    012737 177546 001520    MOV     #177546,CLKADR  ;;LOAD ADDRESSES FOR KW11-L
9 043602    012737 000100 001522    MOV     #100,CLKVCT
10 043610   005777 135704    TST     @CLKADR         ;;TEST FOR KW11-L PRESENT
11 043614   000421    BR      3$             ;;YES - KW11-L IS PRESENT
12 043616   022626    1$:    CMP     (SP)+,(SP)+   ;;RESTORE SP
13 043620   012737 043650 000004    MOV     #2$,ERRVEC     ;;SET UP FOR BUS TIMEOUT
14 043626   012737 172540 001520    MOV     #172540,CLKADR ;;LOAD ADDRESSES FOR KW11-P CLOCK
15 043634   012737 000104 001522    MOV     #104,CLKVCT
16 043642   005777 135652    TST     @CLKADR         ;;TEST FOR KW11-P PRESENT
17 043646   000404    BR      3$             ;;YES - KW11-P IS PRESENT
18 043650   022626    2$:    CMP     (SP)+,(SP)+   ;;RESTORE SP
19 043652   062766 000002 000004    ADD     #2,4(SP)       ;;MOVE RETURN TO ERROR
20 043660   012637 000006    3$:    MOV     (SP)+,ERRVEC+2 ;;POP STACK INTO ERRVEC+2
21 043664   012637 000004    MOV     (SP)+,ERRVEC   ;;POP STACK INTO ERRVEC
22 043670   000207    RTS     PC              ;;RETURN TO USER

```

TIMEOUT SUBROUTINE

```

1      .SBTTL  TIMEOUT SUBROUTINE
2
3      ;THIS SUBROUTINE WAITS FOR RDY  1 AND GO = 0 OR FOR A TIMEOUT
4      ;GREATER THAN APPROX. 500 MSEC AND THEN RETURNS.
5
6      ;CALL:  JSR      PC,TIMOUT
7      ;      ???
8      ;      RETURN HERE
9
10     TIMEOUT:
11     043672 010046      MOV      R0,-(SP)      ;;PUSH R0 ON STACK
12     043672 010146      MOV      R1,-(SP)      ;;PUSH R1 ON STACK
13     043674 010246      MOV      R2,-(SP)      ;;PUSH R2 ON STACK
14     043700 013746 000004  MOV      ERRVEC,-(SP)  ;;PUSH ERRVEC ON STACK
15     043704 013746 000006  MOV      ERRVEC+2,-(SP)  ;;PUSH ERRVEC+2 ON STACK
16     043710 012737 044012 000004  MOV      #4$,ERRVEC    ;SETUP FOR BUS TIMEOUT - 04 TRAP
17     043716 012737 000300 000006  MOV      #PR6,ERRVEC+2
18     043724 013700 001276      MOV      $BASE,R0      ;R0=BASE ADDRESS
19     043730 013701 001520      MOV      CLKADR,R1     ;R1=CLOCK ADDRESS
20     043734 012702 000036      MOV      #30,,R2      ;R2=NUMBER OF CLOCK CYCLES
21     043740 020127 172540      1$:  CMP      R1,#172540    ;KW11-P CLOCK??
22     043744 001003      BNE      2$           ;NO!!
23     043746 012761 000001 000002  MOV      #1,2(R1)     ;SET COUNTER
24     043754 012711 000005      2$:  MOV      #BIT2!BIT0,(R1) ;START COUNTER
25
26     043760 016046 000000      3$:  MOV      RMCS1(R0),-(SP) ;GET STATUS
27     043764 042716 177576      BIC      #^C<RDY!GO>,(SP)
28     043770 022726 000200      CMP      #RDY,(SP)+   ;RDY=1,GO-0??
29     043774 001420      BEQ      5$           ;YES!!
30     043776 032711 000200      BIT      #BIT7,(R1)   ;TIMER DONE??
31     044002 001766      BEQ      3$           ;NO!!
32     044004 005302      DEC      R2           ;DEC NUMBER OF CYCLES
33     044006 001354      BNE      1$           ;CONTINUE IF NOT DONE
34     044010 000412      BR       5$           ;'RDY' DID NOT SET OR 'GO' DID NOT RESET
35     ;WITHIN 500 MSEC AFTER THE COMMAND WAS ISSUED.
36     044012 022626      4$:  CMP      (SP)+,(SP)+  ;ADJUST STACK
37     044014 062766 000004 000012  ADD      #4,12(SP)    ;MOVE SP TO USER'S CALL
38     044022 112776 000007 000012  MOVB    #7,@12(SP)   ;WRITE ERROR NUMBER
39     044030 162766 000002 000012  SUB     #2,12(SP)
40
41     044036      5$:  MOV      (SP)+,ERRVEC+2  ;;POP STACK INTO ERRVEC+2
42     044036 012637 000006      MOV      (SP)+,ERRVEC  ;;POP STACK INTO ERRVEC
43     044042 012637 000004      MOV      (SP)+,R2      ;;POP STACK INTO R2
44     044046 012602      MOV      (SP)+,R1      ;;POP STACK INTO R1
45     044050 012601      MOV      (SP)+,R0      ;;POP STACK INTO R0
46     044052 012600      MOV      (SP)+,R0
47     044054 000207      RTS      PC           ;RETURN TO USER

```

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39 044056
40
41
42 044056 062716 000004
43 044062 105076 000000
44 044066 162716 000004
45
46
47 044072 013737 001346 001142
48 044100 042737 177770 001142
49 044106 013737 001234 001140
50 044114 042737 177770 001140
51 044122 123737 001140 001142
52
53 044130 001415
54 044132 062716 000004
55 044136 112776 000001 000000
56 044144 162716 000002
57 044150 004736

```

.SBTTL PRIMARY ERROR CHECK SUBROUTINE

;THE PURPOSE OF THIS SUBROUTINE IS TO VERIFY THAT STATUS IS VALID AND
;THAT FURTHER ERROR AND STATUS CHECKING SHOULD BE PERFORMED. THE
;FOLLOWING CHECKS ARE MADE:

    .CORRECT UNIT IS SELECTED, I.E., THE UNIT SELECT BITS OF RMCS2
;(BITS 0-2) EQUAL THE UNIT BEING TESTED;

    .SELECTED UNIT IS AVAILABLE, I.E., DVA (BIT 11 OF RMCS1) IS SET
AND NED (BIT 12 OF RMCS2) IS RESET;

    .LAST COMMAND WAS COMPLETED, I.E., THE MASSBUS CONTROLLER IS
READY (BIT 7 OF RMCS1) AND THE GO BIT IS RESET (BIT 0 OF RMCS1) OR THE
DRIVE READY BIT (BIT 7 OF RMDS) IS SET.
    .NO PARITY ERROR OCCURRED WHEN READING REMOTE REGISTERS,
I.E., MCPE = 0.
    .NO PARITY ERROR OCCURRED WHEN WRITING REMOTE REGISTERS,
I.E., PAR = 0, OR, PAR = DPE = 1

;THE SUBROUTINE ASSUMES THAT:

    .STATUS HAS BEEN STORED IN THE REGISTER INPUT BUFFER,
IN PARTICULAR, RMCS1, RMCS2 AND RMDS HAVE BEEN STORED IN THEIR
CORRESPONDING LOCATIONS OF THE 'GET' BUFFER.

    .($UNIT) CONTAINS THE DRIVE NUMBER

;THE SUBROUTINE IS CALLED AS FOLLOWS:

(1)   JSR    PC,PRIERR          RETURN HERE IF NO ERROR
      BR     ???                RETURN HERE TO REPORT AN ERROR
      NOP
      ERROR  ERROR NUMBER DEFINED BY SUB
      JSR    PC,@(SP)+          GO BACK TO SUB FOR MORE ERROR CHECKS
      ???                RETURN HERE IF NO MORE ERRORS

PRIERR:

;CLEAR USER'S ERROR CALL
      ADD    #4,(SP)            ;MOVE (SP) TO ERROR CALL
      CLRB  @(SP)              ;CLEAR ERROR NUMBER
      SUB    #4,(SP)            ;MOVE (SP) TO NO ERROR RETURN

;REPORT AN ERROR IF THE WRONG UNIT IS SELECTED
      MOV    RMCS2I,$BDDAT     ;CORRECT UNIT SELECTED??
      BIC   #^CUNTMSK,$BDDAT
      MOV    $UNIT,$GDDAT     ;GOOD DATA FOR TYPEOUT
      BIC   #^CUNTMSK,$GDDAT
      CMPB  $GDDAT,$BDDAT     ;COMPARE EXPECTED AND RECEIVED
      ;DRIVE NUMBERS
      ;YES..
      BEQ   1$
      ADD    #4,(SP)
      MOVB  #1,@(SP)          ;ERROR 1
      SUB   #2,(SP)          ;MOVE SP TO RETURN FOR ERROR
      JSR   PC,@(SP)+        ;REPORT WRONG UNIT SELECTED
  
```



```

58 044152 162716 000010          SUB    #10,(SP)      ;RESTORE (SP)
59 044156 000240                NOP
60 044160 000137 044700          JMP    10$          ;SKIP OTHER CHECKS
61 044164
62
63                                ;REPORT AN ERROR IF THE DEVICE IS NOT AVAILABLE OR IF
64                                ;THE DEVICE IS NONEXISTANT
65 044164 032737 004000 001336    BIT    #DVA, RMCS1I ;DEVICE AVAILABLE??
66 044172 001045                BNE    5$          ;YES!!
67 044174 013737 001336 001140    MOV    RMCS1I,$GDDAT ;EXPECTED STATUS
68 044202 052737 004000 001140    BIS    #DVA,$GDDAT
69 044210 013737 001336 001142    MOV    RMCS1I,$BDDAT ;RECEIVED STATUS
70 044216 062716 000004                ADD    #4,(SP)
71 044222 112776 000002 000000    MOVB  #2,@(SP)      ;ERROR #2
72 044230 032737 010000 001346    BIT    #NED, RMCS2I ;WAS NED SET??
73 044236 001414                BEQ    2$          ;NO!!
74 044240 013737 001346 001140    MOV    RMCS2I,$GDDAT ;EXPECTED STATUS
75 044246 013737 001346 001142    MOV    RMCS2I,$BDDAT ;RECEIVED STATUS
76 044254 042737 010000 001140    BIC    #NED,$GDDAT
77 044262 112776 000003 000000    MOVB  #3,@(SP)      ;YES - CHANGE ERROR NUMBER
78 044270 162716 000002          2$: SUB    #2,(SP)      ;MOVE SP TO RETURN FOR ERROR
79 044274 004736                JSR    PC,@(SP)+    ;REPORT DEVICE NOT AVAILABLE
80 044276 162716 000010          SUB    #10,(SP)      ;RESTORE (SP)
81 044302 000240                NOP
82 044304 000575                BR     10$          ;SKIP OTHER CHECKS
83 044306
84
85                                ;REPORT AN ERROR IF MASSBUS CONTROLLER IS NOT READY
86 044306 032737 000200 001336    BIT    #RDY, RMCS1I ;CONTROLLER READY??
87 044314 001030                BNE    7$          ;YES!!
88 044316 013737 001336 001140    MOV    RMCS1I,$GDDAT ;EXPECTED STATUS
89 044324 052737 000200 001140    BIS    #RDY,$GDDAT
90 044332 042737 160001 001140    BIC    #SC.TRE!MCPE!GO,$GDDAT
91 044340 013737 001336 001142    MOV    RMCS1I,$BDDAT ;RECEIVED STATUS
92 044346 062716 000004                ADD    #4,(SP)
93 044352 112776 000004 000000    MOVB  #4,@(SP)      ;ERROR #4
94 044360 162716 000002          SUB    #2,(SP)      ;MOVE SP TO RETURN FOR ERROR
95 044364 004736                JSR    PC,@(SP)+    ;REPORT CONTROLLER NOT READY
96 044366 162716 000010          SUB    #10,(SP)      ;RESTORE (SP)
97 044372 000240                NOP
98 044374 000541                BR     10$          ;SKIP OTHER CHECKS
99 044376
100
101                                ;REPORT AN ERROR IF GO IS NOT ZERO AND DRY IS NOT ONE
102 044376 032737 000001 001336    BIT    #GO, RMCS1I  ;GO RESET??
103 044404 001431                BEQ    8$          ;YES!!
104 044406 032737 000200 001350    BIT    #DRY, RMDSI  ;DRIVE READY??
105 044414 001025                BNE    8$          ;YES!!
106 044416 013737 001336 001140    MOV    RMCS1I,$GDDAT ;EXPECTED STATUS
107 044424 042737 160001 001140    BIC    #SC!TRE!MCPE!GO,$GDDAT
108 044432 013737 001336 001142    MOV    RMCS1I,$BDDAT ;RECEIVED STATUS
109 044440 062716 000004                ADD    #4,(SP)
110 044444 112776 000005 000000    MOVB  #5,@(SP)      ;ERROR #5
111 044452 162716 000002          SUB    #2,(SP)      ;MOVE SP TO RETURN FOR ERROR
112 044456 004736                JSR    PC,@(SP)+    ;REPORT DRIVE NOT READY
113 044460 162716 000010          SUB    #10,(SP)      ;RESTORE (SP)
114 044464 000240                NOP

```

```

115 044466 000504          BR      10$
116 044470          8$:
117
118          ;REPORT AN ERROR IF THE RH CONTROLLER DETECTED BAD
119          ;PARITY ON THE MASSBUS CONTROL BUS
120 044470 032737 020000 001336  BIT      #MCPE,RMCS1I  ;PARITY ERROR ??
121 044476 001425          BEQ      9$          ;NO!!
122 044500 013737 001336 001140  MOV      RMCS1I,$GDDAT ;EXPECTED STATUS
123 044506 042737 160001 001140  BIC      #SC!TRE!MCPE!GO,$GDDAT
124 044514 013737 001336 001142  MOV      RMCS1I,$BDDAT ;RECEIVED STATUS
125 044522 062716 000004          ADD      #4,(SP)      ;MOVE SP TO USER'S ERROR
126 044526 112776 000013 000000  MOVVB   #13,@(SP)    ;ERROR #13
127 044534 162716 000002          SUB      #2,(SP)      ;MOVE SP TO RETURN FOR ERROR
128 044540 004736          JSR      PC,@(SP)+   ;REPORT ERROR VIA USER
129 044542 162716 000010          SUB      #10,(SP)    ;RESTORE STACK
130 044546 000240          NOP
131 044550 000453          BR      10$
132 044552          9$:
133
134          ;REPORT AN ERROR IF DETECTED A CONTROL BUS PARITY ERROR
135 044552 032737 000010 001352  BIT      #PAR,RMER1I  ;WAS THERE A PARITY ERROR??
136 044560 001451          BEQ      11$         ;NO!!
137 044562 032737 000010 001400  BIT      #DPE,RMER2I  ;WAS IT THE CONTROL BUS??
138 044570 001045          BNE      11$         ;NOT SURE!!
139 044572 032737 000010 001426  BIT      #PAR,RMER10  ;DID TEST SET PAR ??
140 044600 001413          BEQ      93$         ;NO!!
141 044602 010046          MOV      R0,-(SP)    ;:PUSH R0 ON STACK
142 044604 012700 001553          MOV      #PUTINX,R0  ;R0 POINTS TO INDEX TABLE
143 044610 122710 000014          91$:  CMPB   #RMER1,(R0)  ;SEARCH TABLE FOR RMER1
144 044614 001002          BNE      92$
145 044616 012600          MOV      (SP)+,R0   ;:POP STACK INTO R0
146 044620 000431          BR      11$         ;PAR WAS SET BY TEST
147 044622 105720          92$:  TSTB   (R0)+       ;END OF TABLE??
148 044624 100371          BPL      91$         ;NO!!
149 044626 012600          MOV      (SP)+,R0   ;:POP STACK INTO R0
150 044630 013737 001352 001140  93$:  MOV      RMER1I,$GDDAT ;EXPECTED STATUS
151 044636 042737 000010 001140  BIC      #PAR,$GDDAT
152 044644 013737 001352 001142  MOV      RMER1I,$BDDAT ;RECEIVED STATUS
153 044652 062716 000004          ADD      #4,(SP)      ;MOVE SP TO USER'S ERROR CALL
154 044656 112776 000050 000000  MOVVB   #50,@(SP)    ;WRITE THE ERROR NUMBER
155 044664 162716 000002          SUB      #2,(SP)      ;MOVE SP TO RETURN FOR ERROR
156 044670 004736          JSR      PC,@(SP)+   ;REPORT THE ERROR
157 044672 162716 000010          SUB      #10,(SP)    ;MOVE SP TO NO ERROR RETURN
158 044676 000240          NOP
159 044700 062716 000010          10$:  ADD      #10,(SP)    ;RETURN TO ERROR
160 044704 000240          11$:  NOP
161 044706 000207          RTS      PC
    
```

```

1      .SBTTL  SECONDARY ERROR CHECK SUBROUTINE
2
3      ;THE ERROR CHECK SUBROUTINE PROVIDES DETECTION OF SFCNDARY ERRORS
4      ;SUCH AS UNEXPECTED ERRORS AND UNEXPFCTED REGISTER CONTENTS. THESE
5      ;ERRORS ARE DEEMED SECONDARY IN THAT THEY ARE NOT NECESSARILY
6      ;ASSOCIATED WITH THE OPERATION BEING PERFORMED.
7      ;WHEN THE SUBROUTINE IDENTIFIES SUCH AN ERROR, IT MOVES THE ERROR
8      ;NUMBER TO THE ERROR CALL IN THE TEST ROUTINE AND THEN RETURNS
9      ;TO THE TEST ROUTINE WHICH MAKES THE ERROR CALL. AFTER THE TEST ROUTINE
10     ;MAKES THE ERROR CALL, IT RETURNS TO THE SUBROUTINE WHICH THEN LOOKS FOR
11     ;OTHER ERRORS. WHEN ALL ERRORS HAVE BEEN REPORTED, THE SUBROUTINE
12     ;RETURNS TO THE ADDRESS FOLLOWING THE SUBROUTINE CALL.
13
14     ;CALL:  JSR      PC,SECERR
15             BR       ???          RETURN HERE IF NO ERROR
16             NOP      RETURN HERE TO REPORT AN ERROR
17             ERROR   ERROR NUMBER DEFINED BY SUB
18             JSR     PC,@(SP)+     GO BACK TO SUB FOR MORE ERROR CHECKS
19             ???     RETURN HERE IF NO MORE ERRORS
20
21     ;NOTE:  THE SUBROUTINE ASSUMES THAT REGISTERS HAVE BEEN STORED AT THE
22     ;INPUT REGISTER BUFFER.
23
24     044710  SECERR:
25
26     ;*****
27     ;STORE FUNCTION CODE AND CLEAR USER'S ERROR NUMBER
28     044710  013737  001412  050544  MOV     RMCS10,515$  ;STORE FUNCTION CODE
29     044716  042737  177701  050544  BIC     #^C<F0!F1!F2.F3!F4>,515$
30     044724  062716  000004          ADD     #4,(SP)      ;MOVE (SP) TO ERROR CALL
31     044730  105076  000000          CLR    @(SP)        ;CLEAR ERROR NUMBER
32     044734  162716  000004          SUB     #4,(SP)     ;MOVE (SP) TO NG ERROR RETURN
33
34     ;*****
35     ;CHECK SECONDARY ERRORS COMMON TO ALL COMMANDS
36
37     ;REPORT ERROR IF DRIVE IS NOT READY, I.E., IF DRY = 0
38     044740  032737  000200  001350  BIT     #DRY,RMDSI  ;DRIVE READY??
39     044746  001024          BNE    5$          ;YES!!
40     044750  013737  001350  001142  MOV     RMDSI,$BDDAT ;BAD DATA FOR TYPEOUT
41     044756  042737  177577  001142  BIC     #^CDRY,$BDDAT
42     044764  012737  000200  001140  MOV     #DRY,$GDDAT ;GOOD DATA FOR TYPEOUT
43     044772  062716  000004          ADD     #4,(SP)
44     044776  112776  000010  000000  MOV    #10,@(SP)   ;ERROR NUMBER
45     045004  162716  000002          SUB     #2,(SP)    ;MOVE SP TO RETURN FOR ERROR
46     045010  004736          JSR    PC,@(SP)+  ;REPORT NOT READY
47     045012  162716  000010          SUB     #10,(SP)  ;RESTORE (SP) TO ERROR N
48     045016  000240          NOP
49
50     ;REPORT ERROR IF GO BIT IS NOT RESET
51     045020  032737  000001  001336  5$: BIT     #GO,RMCS11 ;GO BIT RESET??
52     045026  001423          BEQ    10$        ;YES..
53     045030  013737  001336  001142  MOV     RMCS11,$BDDAT ;BAD DATA FOR TYPEOUT
54     045036  042737  177776  001142  BIC     #^CGO,$BDDAT
55     045044  005037  001140          CLR    $GDDAT    ;GOOD DATA FOR TYPEOUT
56     045050  062716  000004          ADD     #4,(SP)
57     045054  112776  000011  000000  MOV    #11,@(SP)  ;ERROR NUMBER
    
```

```

58 045062 162716 000002          SUB      #2,(SP)          ;MOVE SP TO RETURN FOR ERROR
59 045066 004736                JSR      PC,@(SP)+      ;REPORT DEVICE NOT AVAILABLE
60 045070 162716 000010          SUB      #10,(SP)       ;RESTORE (SP)
61 045074 000240                NOP
62
63                                ;REPORT ERROR IF FUNCTION CODE READ FROM DEVICE IS NOT CORRECT
64 045076 013737 001336 001142 10$:  MOV      RMCS1I,$BDDAT  ;IS FUNCTION CODE CORRECT??
65 045104 042737 177701 001142    BIC      #^C76,$BDDAT
66 045112 013737 050544 001140    MOV      515$,$GDDAT    ;EXPECTED FUNCTION CODF
67 045120 023737 001142 001140    CMP      $BDDAT,$GDDAT
68 045126 001413                BEQ      15$            ;YES.!
69 045130 062716 000004          ADD      #4,(SP)
70 045134 112776 000012 000000    MOVB    #12,@(SP)      ;ERROR NUMBER
71 045142 162716 000002          SUB      #2,(SP)       ;MOVE SP TO RETURN FOR ERROR
72 045146 004736                JSR      PC,@(SP)+      ;REPORT WRONG FUNCTION CODE
73 045150 162716 000010          SUB      #10,(SP)      ;RESTORE (SP)
74 045154 000240                NOP
75 045156                15$:
76                                ;REPORT AN ERROR IF COMPOSITE ERROR IS SET AND NO OTHER
77                                ;ERRORS ARE SET, OR IF COMPOSITE ERROR IS NOT SET AND
78                                ;OTHER ERRORS ARE SET
79 045156 005037 001140          CLR      $GDDAT        ;EXPECT 'ERR' - 0
80 045162 005737 001352          TST      RMER1I        ;IS RMER1 = 0??
81 045166 001003                BNE      20$           ;NO!!
82 045170 005737 001400          TST      RMER2I        ;IS RMERZ = 0??
83 045174 001403                BEQ      25$           ;YES.!
84 045176 052737 040000 001140 20$:  BIS      #ERR,$GDDAT    ;'ERR' SOULD BE SET
85 045204 013737 001350 001142 25$:  MOV      RMDSI,$BDDAT
86 045212 042737 137777 001142    BIC      #^CERR,$BDDAT
87 045220 023737 001140 001142    CMP      $GDDAT,$BDDAT ;IS 'ERR' OK??
88 045226 001412                BEQ      30$           ;YES!!
89 045230 062716 000004          ADD      #4,(SP)      ;MOVE SP TO USER'S ERROR
90 045234 112776 000047 000000    MOVB    #47,@(SP)     ;WRITE ERROR NUMBER
91 045242 162716 000002          SUB      #2,(SP)      ;MOVE SP TO ERROR RETURN
92 045246 004736                JSR      PC,@(SP)+      ;REPORT INVALID COMP ERROR
93 045250 162716 000010          SUB      #10,(SP)
94
95                                ;REPORT AN ERROR IF 'TRE' IS SET AND NONE OF THE BITS WHICH SET
96                                ;TRE IS SET, OR IF TRE IS NOT SET AND ONE OR MORE BITS WHICH
97                                ;SET TRE IS SET
98 045254 005037 001140          CLR      $GDDAT        ;EXPECT 'TRE' - 0
99 045260 013746 001346          MOV      RMCS2I,-(SP)  ;WAS DLT, WCE, UPE, NED, NEM
100 045264 042726 000377         BIC      #377,(SP)+    ;PGE, MXF OR MDPE SET
101 045270 001010                BNE      35$           ;YES!
102 045272 032737 040000 001350    BIT      #ERR,RMDSI    ;WAS EXCEPTION RECEIVED??
103 045300 001407                BEQ      40$           ;NO..
104 045302 022737 000030 050544    CMP      #SEARCH,515$  ;WAS DATA TRANSFERRED??
105 045310 103003                BHIS    40$            ;NO.!
106 045312 052737 040000 001140 35$:  BIS      #TRE,$GDDAT    ;'TRE' SHOULD BE SET
107 045320 013737 001336 001142 40$:  MOV      RMCS1I,$BDDAT ;BAD DATA FOR TYPEOUT
108 045326 042737 137777 001142    BIC      #^CTRE,$BDDAT
109 045334 023737 001140 001142    CMP      $GDDAT,$BDDAT ;IS 'TRE' OK??
110 045342 001413                BEQ      45$           ;YES.!
111 045344 062716 000004          ADD      #4,(SP)      ;MOVE SP TO USER'S ERROR CALL
112 045350 112776 000014 000000    MOVB    #14,@(SP)     ;WRITE ERROR NUMBER
113 045356 162716 000002          SUB      #2,(SP)      ;MOVE SP TO RETURN FOR ERROR
114 045362 004736                JSR      PC,@(SP)+      ;REPORT TRE ERROR
    
```

```

115 045364 162716 000010          SUB      #10,(SP)          ;RESTORE (SP)
116 045370 000240          NOP
117 045372          45$:
118
119          ;*****
120          ;USING THE FUNCTION CODE TABLE, CHECK FOR THE FOLLOWING ERRORS:
121          ;      .STATUS BITS NOT SET THAT SHOULD BE SET, E.G., ATA AND ILF
122          ;      .STATUS BITS SET THAT SHOULD NOT BE SET, E.G., WCE AND ECH
123          ;NOTE THAT SOME ERROR BITS ARE CONDITIONAL ON THE COMMAND AND OTHER
124          ;STATUS CONDITIONS, E.G., WRITE LOCK ERROR SHOULD ONLY BE SET IF
125          ;WRITE LOCK IS ON AND THE COMMAND IS A WRITE.
126
127          ;GET AND STORE THE ENTRY FROM THE FUNCTION CODE TABLE
128 045372 010046          MOV      RO,-(SP)          ;;PUSH RO ON STACK
129 045374 013700 050544          MOV      515$,RO          ;GET FUNCTION CODE
130 045400 016037 071646 050536          MOV      FNCDTB(RO),500$ ;STORE ENTRY
131 045406 012600          MOV      (SP)+,RO          ;;POP STACK INTO RO
132
133          ;REPORT AN ERROR IF AN UNEXPECTED ATTENTION OCCURRED OR IF
134          ;ATA IS NOT SET AND SHOULD BE SET.
135 045410 013737 050536 001140          MOV      500$, $GDDAT          ;GET EXPECTED ATA STATUS
136 045416 032737 040000 001350          BIT      #ERR,RMDSI          ;IS COMPOSITE ERROR SET ??
137 045424 001403          BEQ      50$                ;NO !!
138 045426 052737 100000 001140          BIS      #ATA,$GDDAT          ;EXPECT AN ATTENTION
139 045434 042737 077777 001140 50$:          BIC      #^CATA,$GDDAT          ;STRIP DONT CARES
140 045442 013737 001350 001142          MOV      RMDSI,$BDDAT          ;GET RECEIVED ATA
141 045450 042737 077777 001142          BIC      #^CATA,$BDDAT          ;STRIP DONT CARES
142 045456 023737 001140 001142          CMP      $GDDAT,$BDDAT          ;IS ATA OK ??
143 045464 001413          BEQ      55$                ;YES !!
144 045466 062716 000004          ADD      #4,(SP)            ;MOVE SP TO USERS ERROR CALL
145 045472 112776 000006 000000          MOVB    #6,@(SP)            ;LOAD ERROR # IN CALL
146 045500 162716 000002          SUB      #2,(SP)            ;MOVE SP TO ERROR RETURN
147 045504 004736          JSR      PC,@(SP)+          ;REPORT ERROR
148 045506 162716 000010          SUB      #10,(SP)           ;RESTORE SP
149 045512 000240          NOP
150 045514          55$:
151
152          ;REPORT ERROR IF ILF IS INCORRECT, I.E., IF ILF DOES NOT COMPARE
153          ;WITH FUNCTION CODE TABLE
154 045514 013737 050536 001140          MOV      500$, $GDDAT          ;GET EXPECTED ILF
155 045522 042737 177776 001140          BIC      #^CILF,$GDDAT          ;CLEAR ALL OTHER BITS
156 045530 013737 001352 001142          MOV      RMER1I,$BDDAT          ;GET RECEIVED ILF
157 045536 042737 177776 001142          BIC      #^CILF,$BDDAT          ;CLEAR ALL OTHER BITS
158 045544 023737 001140 001142          CMP      $GDDAT,$BDDAT          ;IS ILF OK ??
159 045552 001412          BEQ      60$                ;YES !!
160 045554 062716 000004          ADD      #4,(SP)            ;MOVE SP TO USERS ERROR CALL
161 045560 112776 000254 000000          MOVB    #254,@(SP)          ;WRITE ERROR NUMBER IN CALL
162 045566 162716 000002          SUB      #2,(SP)            ;MOVE SP TO ERROR RETURN
163 045572 004736          JSR      PC,@(SP)+          ;REPORT ERROR AND RETURN
164 045574 162716 000010          SUB      #10,(SP)           ;MOVE SP TO NO ERROR
165 045600 005037 001140 60$:          CLR      $GDDAT              ;CLEAR EXPECTED STATUS
166
167          ;REPORT AN ERROR IF WCE IS SET AND SHOULD NOT BE SET
168 045604 013746 050536          MOV      500$,-(SP)          ;GET WCE STATUS ENABLE
169 045610 052716 137777          BIS      #^CWCE,(SP)          ;SET ALL OTHER BITS
170 045614 013737 001346 001142          MOV      RMCS2I,$BDDAT          ;RECEIVED STATUS
171 045622 042637 001142          BIC      (SP)+,$BDDAT          ;CLEAR WCE IF ENABLED
    
```

```

172 045626 001412          BEQ      90$          ;BRANCH IF WCE OK
173 045630 062716 000004    ADD      #4,(SP)      ;MOVE SP TO USER'S ERROR CALL
174 045634 112776 000026 000000    MOVB    #26,@(SP)    ;WRITE ERROR NUMBER
175 045642 162716 000002          SUB      #2,(SP)      ;MOVE SP TO ERROR RETURN
176 045646 004736          JSR     PC,@(SP)+    ;REPORT ERROR
177 045650 162716 000010          SUB      #10,(SP)     ;RESTORE ERROR
178 045654          90$:
179
180          ;REPORT ERROR IF OPI STATUS IS SET AND SHOULD NOT BE SFT
181 045654 013746 050536    MOV     500$,-(SP)   ;GET OPI STATUS ENABLE
182 045660 052716 157777    BIS    #^COPI,(SP)  ;SET ALL OTHER BITS
183 045664 013737 001352 001142    MOV     RMER1I,$BDDAT ;GET RECEIVED STATUS
184 045672 042637 001142    BIC    (SP)+,$BDDAT ;CLEAR OPI IF ENABLED
185 045676 001412          BEQ     100$         ;BRANCH IF OPI OK
186 045700 062716 000004    ADD     #4,(SP)      ;MOVE SP TO USER'S ERROR CALL
187 045704 112776 000164 000000    MOVB   #164,@(SP)   ;WRITE ERROR NUMBER IN CALL
188 045712 162716 000002          SUB     #2,(SP)      ;MOVE SP TO ERROR RETURN
189 045716 004736          JSR    PC,@(SP)+    ;REPORT ERROR
190 045720 162716 000010          SUB     #10,(SP)     ;RESTORE SP
191 045724          100$:
192
193          ;REPORT ERROR IF IVC IS SET AND IS NOT ENABLED OR IF IVC IS
194          ;SET AND VV IS NOT RESET
195 045724 013746 050536    MOV     500$,-(SP)   ;GET IVC STATUS ENABLE
196 045730 032737 000100 001350    BIT    #VV,RMDSI    ;IS VV SET
197 045736 001402          BEQ     105$         ;NO !!
198 045740 042716 010000    BIC    #IVC,(SP)    ;YES - IVC SHOULD BE 0
199 045744 052716 167777 105$:  BIS    #^CIVC,(SP)  ;SET ALL OTHER BITS
200 045750 013737 001400 001142    MOV     RMER2I,$BDDAT ;GET RECEIVED STATUS
201 045756 042637 001142    BIC    (SP)+,$BDDAT ;CLEAR IVC IF ENABLED
202 045762 001412          BEQ     110$         ;BRANCH IF IVC OK
203 045764 062716 000004    ADD     #4,(SP)      ;MOVE SP TO USERS ERROR CALL
204 045770 112776 000165 000000    MOVB   #165,@(SP)   ;WRITE ERROR NUMBER IN CALL
205 045776 162716 000002          SUB     #2,(SP)      ;MOVE SP TO ERROR RETURN
206 046002 004736          JSR    PC,@(SP)+    ;REPORT ERROR
207 046004 162716 000010          SUB     #10,(SP)     ;RESTORE SP TO NO ERROR
208 046010          110$:
209
210          ;BIT 11 (WLE) OF THE FUNCTION CODE TABLE IS THE ENABLING BIT FOR
211          ; ALL WRITE ERRORS, I.E.,
212          ;     RMER1 - WLE, WCF
213          ;     RMER2 - DPE
214          ;     RMCS2 - UPE.
215          ;EACH OF THESE ERRORS IS CHECKED TO SEE IF AN ERROR IS SET WHEN THE
216          ;WRITE ERROR ENABLE BIT IS RESET.
217
218          ;REPORT AN ERROR IF WLE IS SET AND WRITE ERRORS ARE NOT ENABLED, OR IF
219          ;THE DRIVE IS NOT WRITE PROTECTED
220 046010 012746 177777    MOV     #-1,-(SP)    ;ASSUME WRITE ERRORS ENABLED
221 046014 032737 004000 050536    BIT    #WLF,500$    ;ARE WRITE ERRORS FNABLED ??
222 046022 001404          BEQ     115$         ;NO !
223 046024 032737 004000 001350    BIT    #WRL,RMDSI   ;IS THE DRIVE WRITE PROTECTED ??
224 046032 001002          BNE     120$         ;YES !!
225 046034 042716 004000 115$:  BIC    #WLE,(SP)    ;RESET WLE ENABLE
226 046040 013737 001352 001142 120$:  MOV     RMER1I,$BDDAT ;GET RECEIVED STATUS
227 046046 042637 001142    BIC    (SP)+,$BDDAT ;CLEAR WLE IF ENABLED
228 046052 001412          BEQ     125$         ;BRANCH IF WLE OK
    
```

```

229 046054 062716 000004          ADD    #4,(SP)          ;MOVE SP TO USERS ERROR CALL
230 046060 112776 000023 000000    MOVB  #23,@(SP)        ;WRITE ERROR NUMBER IN CALL
231 046066 162716 000002          SUB    #2,(SP)         ;MOVE SP TO ERROR RETURN
232 046072 004736          JSR   PC,@(SP)+        ;REPORT ERROR AND RETURN
233 046074 162716 000010          SUB    #10,(SP)       ;RESTORE SP TO NO ERROR
234 046100          125$:
235
236          ;REPORT ERROR IF WCF IS SET AND WRITE ERRORS ARE NOT ENABLED
237 046100 012746 177777          MOV    #-1,-(SP)      ;ASSUME WRITE ERRORS ENABLED
238 046104 032737 004000 050536    BIT    #WLE,500$      ;ARE WRITE ERRORS ENABLED ??
239 046112 001002          BNE    130$           ;YES !!
240 046114 042716 000040          BIC    #WCF,(SP)     ;DISABLE WCF ERROR
241 046120 013737 001352 001142 130$:  MOV    RMER1I,$BDDAT  ;GET RECEIVED STATUS
242 046126 042637 001142          BIC    (SP)+,$BDDAT  ;RESET WCF IF ENABLED
243 046132 001412          BEQ    135$           ;BRANCH IF WCF OK
244 046134 062716 000004          ADD    #4,(SP)       ;MOVE SP TO USERS ERROR CALL
245 046140 112776 000025 000000    MOVB  #25,@(SP)        ;WRITE ERROR NUMBER IN CALL
246 046146 162716 000002          SUB    #2,(SP)         ;MOVE SP TO ERROR RETURN
247 046152 004736          JSR   PC,@(SP)+        ;REPORT ERROR
248 046154 162716 000010          SUB    #10,(SP)       ;RESTORE SP TO NO ERROR
249 046160          135$:
250
251          ;REPORT ERROR IF DPE IS SET AND WRITE ERRORS ARE NOT ENABLED
252 046160 012746 177777          MOV    #-1,-(SP)      ;ASSUME WRITE ERRORS ARE ENABLED
253 046164 032737 004000 050536    BIT    #WLE,500$      ;ARE WRITE ERRORS ENABLED ??
254 046172 001002          BNE    140$           ;YES !!
255 046174 042716 000010          BIC    #DPE,(SP)     ;RESET DPE ENABLE
256 046200 013737 001400 001142 140$:  MOV    RMER2I,$BDDAT  ;GET RECEIVED STATUS
257 046206 042637 001142          BIC    (SP)+,$BDDAT  ;RESET DPE IF ENABLED
258 046212 001412          BEQ    145$           ;BRANCH IF DPE OK
259 046214 062716 000004          ADD    #4,(SP)       ;MOVE SP TO USERS ERROR CALL
260 046220 112776 000040 000000    MOVB  #40,@(SP)       ;WRITE ERROR NUMBER IN CALL
261 046226 162716 000002          SUB    #2,(SP)         ;MOVE SP TO ERROR RETURN
262 046232 004736          JSR   PC,@(SP)+        ;REPORT ERROR
263 046234 162716 000010          SUB    #10,(SP)       ;RESTORE SP TO NO ERROR
264 046240          145$:
265
266          ;REPORT AN ERROR IF UPE IS SET AND WRITE ERRORS ARE NOT ENABLED
267 046240 012746 177777          MOV    #-1,-(SP)      ;ASSUME WRITE ERRORS ARE ENABLED
268 046244 032737 004000 050536    BIT    #WLE,500$      ;ARE WRITE ERRORS ENABLED ??
269 046252 001002          BNE    150$           ;YES !!
270 046254 042716 020000          BIC    #UPE,(SP)     ;DISABLE UPE ERROR
271 046260 013737 001346 001142 150$:  MOV    RMCS2I,$BDDAT  ;GET RECEIVED STATUS
272 046266 042637 001142          BIC    (SP)+,$BDDAT  ;RESET UPE IF ENABLED
273 046272 001412          BEQ    155$           ;BRANCH IF UPE OK
274 046274 062716 000004          ADD    #4,(SP)       ;MOVE SP TO USERS ERROR CALL
275 046300 112776 000024 000000    MOVB  #24,@(SP)       ;WRITE ERROR NUMBER IN CALL
276 046306 162716 000002          SUB    #2,(SP)         ;MOVE SP TO ERROR RETURN
277 046312 004736          JSR   PC,@(SP)+        ;REPORT ERROR AND RETURN
278 046314 162716 000010          SUB    #10,(SP)       ;MOVE SP TO NO ERROR
279 046320          155$:
280
281          ;REPORT AN ERROR IF IAE IS SET AND IS NOT ENABLED
282 046320 013746 050536          MOV    500$,-(SP)    ;GET IAE ENABLE
283 046324 052716 175777          BIS    #^CIAE,(SP)   ;SET ALL OTHER BITS
284 046330 013737 001352 001142    MOV    RMER1I,$BDDAT  ;GET RECEIVED STATUS
285 046336 042637 001142          BIC    (SP)+,$BDDAT  ;CLEAR IAE IF ENABLED
    
```

```

286 046342 001412          BEQ      160$          ;BRANCH IF IAE IS OK
287 046344 062716 000004    ADD      #4,(SP)       ;MOVE SP TO USERS ERROR CALL
288 046350 112776 000166 000000  MOVB    #166,@(SP)    ;WRITE ERROR NUMBER
289 046356 162716 000002    SUB      #2,(SP)       ;MOVE SP TO ERROR RETURN
290 046362 004736          JSR      PC,@(SP)+     ;REPORT ERROR AND RETURN
291 046364 162716 000010    SUB      #10,(SP)      ;MOVE SP TO NO ERROR
292 046370          160$:
293
294          ;BIT 09 (AOE) OF THE FUNCTION CODE TABLE IS THE ENABLING BIT FOR
295          ; ALL READ/WRITE ERRORS, I.E.,
296          ;
297          ; RMCS1 - TRE
298          ; RMCS2 - DLT,NEM,MXF
299          ; RMDS - LBT
300          ; RMER1 - AOE
301          ;NOTE:
302          ; LBT IS NOT CHECKED BECAUSE IT ONLY RESETS WHEN THE DESIRED
303          ; CYLINDER REGISTER IS WRITTEN
304          ;NOTE:
305          ; AOE CANNOT BE SET IF LBT IS NOT ALSO SET
306          ;NOTE:
307          ; TRE IS CHECKED AS A FUNCTION OF OTHER ERROR CONDITONS ABOVE
308
309          ;REPORT AN ERROR IF DLT IS SET AND READ/WRITE ERRORS ARE NOT ENABLED
310 046370 012746 177777    MOV      #-1,-(SP)     ;ASSUME ERRORS ARE ENABLED
311 046374 032737 001000 050536  BIT      #AOE,500$     ;ARE ERRORS ENABLED ??
312 046402 001002          BNE      165$          ;YES !!
313 046404 042716 100000    BIC      #DLT,(SP)     ;RESET DLT ENABLE
314 046410 013737 001346 001142 165$:  MOV      RMCS2I,$BDDAT ;GET RECEIVED STATUS
315 046416 042637 001142    BIC      (SP)+,$BDDAT  ;CLEAR DLT IF ENABLED
316 046422 001412          BEQ      170$          ;BRANCH IF DLT IS OK
317 046424 062716 000004    ADD      #4,(SP)       ;MOVE SP TO USERS ERROR CALL
318 046430 112776 000032 000000  MOVB    #32,@(SP)     ;WRITE ERROR NUMBER IN CALL
319 046436 162716 000002    SUB      #2,(SP)       ;MOVE SP TO ERROR RETURN
320 046442 004736          JSR      PC,@(SP)+     ;REPORT ERROR AND RETURN
321 046444 162716 000010    SUB      #10,(SP)      ;MOVE SP TO NO ERROR
322 046450          170$:
323
324          ;REPORT ERROR IF NEM IS SET AND READ/WRITE ERRORS ARE NOT ENABLED
325 046450 012746 177777    MOV      #-1,-(SP)     ;ASSUME ERRORS ARE ENABLED
326 046454 032737 001000 050536  BIT      #AOE,500$     ;ARE ERRORS ENABLED ??
327 046462 001002          BNE      175$          ;YES !!
328 046464 042716 004000    BIC      #NEM,(SP)     ;DISABLE NEM
329 046470 013737 001346 001142 175$:  MOV      RMCS2I,$BDDAT ;GET RECEIVED STATUS
330 046476 042637 001142    BIC      (SP)+,$BDDAT  ;CLEAR NEM IF ENABLED
331 046502 001412          BEQ      180$          ;BRANCH IF NEM IS OK
332 046504 062716 000004    ADD      #4,(SP)       ;MOVE SP TO USERS ERROR CALL
333 046510 112776 000167 000000  MOVB    #167,@(SP)    ;WRITE ERROR NUMBER IN CALL
334 046516 162716 000002    SUB      #2,(SP)       ;MOVE SP TO ERROR RETURN
335 046522 004736          JSR      PC,@(SP)+     ;REPORT ERROR AND RETURN
336 046524 162716 000010    SUB      #10,(SP)      ;MOVE SP TO NO ERROR
337 046530          180$:
338
339          ;REPORT ERROR IF MXF IS SET AND READ/WRITE ERRORS ARE NOT ENABLED
340 046530 012746 177777    MOV      #-1,-(SP)     ;ASSUME ERRORS ARE ENABLED
341 046534 032737 001000 050536  BIT      #AOE,500$     ;ARE DATA ERRORS ENABLED ??
342 046542 001002          BNE      185$          ;YES !!
    
```



```

343 046544 042716 001000      BIC      #MXF,(SP)      ;DISABLE MXF ERROR
344 046550 013737 001346 001142 185$:  MOV      RMCS2I,$BDDAT ;GET RECEIVED STATUS
345 046556 042637 001142      BIC      (SP)+,$BDDAT ;CLEAR MXF IF ENABLED
346 046562 001412      BEQ      190$          ;BRANCH IF MXF IS OK
347 046564 062716 000004      ADD      #4,(SP)       ;MOVE SP TO USERS ERROR CALL
348 046570 112776 000033 000000  MOVB     #33,@(SP)     ;WRITE ERROR NUMBER IN CALL
349 046576 162716 000002      SUB      #2,(SP)       ;MOVE SP TO ERROR RETURN
350 046602 004736      JSR      PC,@(SP)+     ;REPORT ERROR AND RETURN
351 046604 162716 000010      SUB      #10,(SP)      ;MOVE SP TO NO ERROR
352 046610      190$:
353
354      ;REPORT ERROR IF AOE IS SET AND DATA ERRORS ARE NOT ENABLED
355 046610 012746 177777      MOV      #-1,-(SP)    ;ASSUME DATA ERRORS ARE ENABLED
356 046614 032737 001000 050536  BIT      #AOE,500$    ;ARE DATA ERRORS EANBLED ??
357 046622 001404      BEQ      191$          ;NO !!
358 046624 032737 002000 001350  BIT      #LBT,RMDSI   ;IS LBT ALSO SET ??
359 046632 001002      BNE      195$          ;YES !!
360 046634 042716 001000 191$:  BIC      #AOE,(SP)    ;DISABLE AOE
361 046640 013737 001352 001142 195$:  MOV      RMER1I,$BDDAT ;GET RECEIVED STATUS
362 046646 042637 001142      BIC      (SP)+,$BDDAT ;CLEAR AOE IF ENABLED
363 046652 001412      BEQ      200$          ;BRANCH IF AOE IS OK
364 046654 062716 000004      ADD      #4,(SP)       ;MOVE SP TO USERS ERROR CALL
365 046660 112776 000020 000000  MOVB     #20,@(SP)    ;WRITE ERROR NUMBER
366 046666 162716 000002      SUB      #2,(SP)       ;MOVE SP TO ERROR RETURN
367 046672 004736      JSR      PC,@(SP)+     ;REPORT ERROR AND RETURN
368 046674 162716 000010      SUB      #10,(SP)      ;MOVE SP TO NO ERROR
369 046700      200$:
370
371      ;BIT 07 (HCE) OF THE FUNCTION CODE TABLE IS THE ENABLING BIT FOR
372      ;HEADER ERRORS, I.E.,
373      ;      RMER1 - HCRC,HCE,FER
374      ;      RMER2 - BSE
375
376      ;RESET THE ENABLING BIT (HCE) IF HEADER COMPARE INHIBIT IS SET
377 046700 032737 002000 001370  BIT      #HCI,RMOFI   ;IS HCI SET ??
378 046706 001403      BEQ      201$          ;NO !.
379 046710 042737 000200 050536  BIC      #HCE,500$    ;YES - DISABLE ALL HEADER ERRORS
380 046716      201$:
381
382      ;REPORT AN ERROR IF HCRC IS SET AND HEADER ERRORS ARE NOT ENABLED
383 046716 012746 177777      MOV      #-1,-(SP)    ;ASSUME ERRORS ENABLED
384 046722 032737 000200 050536  BIT      #HCE,500$    ;ARE HEADER ERRORS ENABLED ??
385 046730 001002      BNE      205$          ;YES !!
386 046732 042716 000400      BIC      #HCRC,(SP)   ;DISABLE HCRC
387 046736 013737 001352 001142 205$:  MOV      RMER1I,$BDDAT ;GET RECEIVED STATUS
388 046744 042637 001142      BIC      (SP)+,$BDDAT ;RESET HCRC IF ENABLED
389 046750 001412      BEQ      210$          ;BRANCH IF HCRC IS OK
390 046752 062716 000004      ADD      #4,(SP)       ;MOVE SP TO USERS ERROR CALL
391 046756 112776 000035 000000  MOVB     #35,@(SP)    ;WRITE ERROR NUMBER IN CALL
392 046764 162716 000002      SUB      #2,(SP)       ;MOVE SP TO ERROR RETURN
393 046770 004736      JSR      PC,@(SP)+     ;REPORT ERROR AND RETURN
394 046772 162716 000010      SUB      #10,(SP)      ;MOVE SP TO NO ERROR
395 046776      210$:
396
397      ;REPORT ERROR IF HCE IS SET AND HEADER ERRORS ARE NOT ENABLED
398 046776 012746 177777      MOV      #-1,-(SP)    ;ASSUME ERRORS ENABLED
399 047002 032737 000200 050536  BIT      #HCE,500$    ;ARE ERRORS ENABLED ??
    
```

```

400 047010 001002          BNE      215$          :YES !!
401 047012 042716 000200  BIC      #HCE,(SP)    :DISABLE HCE
402 047016 013737 001352 001142 215$  MOV      RMER1I,$BDDAT :GET RECEIVED STATUS
403 047024 042637 001142          BIC      (SP)+,$BDDAT :CLEAR HCE IF ENABLED
404 047030 001412          BEQ      220$          :BRANCH IF HCE IS OK
405 047032 062716 000004          ADD      #4,(SP)      :MOVE SP TO USERS ERROR CALL
406 047036 112776 000036 000000          MOVVB   #36,@(SP)    :WRITE ERROR NUMBER IN CALL
407 047044 162716 000002          SUB      #2,(SP)      :MOVE SP TO ERROR RETURN
408 047050 004736          JSR      PC,@(SP)+    :REPORT ERROR AND RETURN
409 047052 162716 000010          SUB      #10,(SP)    :MOVE SP TO NO ERROR
410 047056          220$:
411
412          ;REPORT ERROR IF FER IS SET AND HEADER ERRORS ARE NOT ENABLED
413 047056 012746 177777          MOV      #-1,-(SP)   :ASSUME FER IS ENABLED
414 047062 032737 000200 050536          BIT      #HCE,500$   :ARE HEADER FRRORS ENABLED ??
415 047070 001002          BNE      225$          :YES !!
416 047072 042716 000020          BIC      #FER,(SP)   :DISABLE FER
417 047076 013737 001352 001142 225$  MOV      RMER1I,$BDDAT :GET RECEIVED STATUS
418 047104 042637 001142          BIC      (SP)+,$BDDAT :RESET FER IF ENABLED
419 047110 001412          BEQ      230$          :BRANCH IF FER OK
420 047112 062716 000004          ADD      #4,(SP)      :MOVE SP TO USERS ERROR CALL
421 047116 112776 000037 000000          MOVVB   #37,@(SP)    :WRITE ERROR NUMBER IN CALL
422 047124 162716 000002          SUB      #2,(SP)      :MOVE SP TO ERROR RETURN
423 047130 004736          JSR      PC,@(SP)+    :REPORT ERROR AND RETURN
424 047132 162716 000010          SUB      #10,(SP)    :MOVE SP TO NO ERROR
425 047136          230$:
426
427          ;REPORT ERROR IF BSE IS SET AND HEADER ERRORS ARE NOT EVABLED
428 047136 012746 177777          MOV      #-1,-(SP)   :ASSUME ERRORS ENABLED
429 047142 032737 000200 050536          BIT      #HCE,500$   :ARE THEY ENABLED ??
430 047150 001002          BNE      235$          :YES !!
431 047152 042716 100000          BIC      #BSE,(SP)   :DISABLE BSE
432 047156 013737 001400 001142 235$  MOV      RMER2I,$BDDAT :GET RECEIVED STATUS
433 047164 042637 001142          BIC      (SP)+,$BDDAT :CLEAR BSE IF ENABLED
434 047170 001412          BEQ      240$          :BRANCH IF BSE OK
435 047172 062716 000004          ADD      #4,(SP)      :MOVE SP TO USERS ERROR CALL
436 047176 112776 000354 000000          MOVVB   #354,@(SP)   :WRITE ERROR NUMBER
437 047204 162716 000002          SUB      #2,(SP)      :MOVE SP TO ERROR RETURN
438 047210 004736          JSR      PC,@(SP)+    :REPORT ERROR AND RETURN
439 047212 162716 000010          SUB      #10,(SP)    :MOVE SP TO NO ERROR
440 047216          240$:
441
442          ;BIT 06 OF THE FUNCTION CODE TABLE IS THE ENABLING BIT FOR DATA
443          ;FIELD ERRORS, I.E.,
444          ;      RMCS2 - MDPE
445          ;      RMER1 - DCK,ECH
446          ;NOTE:
447          ;      ECH CANNOT SET UNLESS IT IS ENABLED AND ECI IS RESET AND
448          ;      DCK IS SET.
449
450          ;REPORT ERROR IF MDPE IS SET AND IS NOT ENABLED
451 047216 012746 177777          MOV      #-1,-(SP)   :ASSUME ENABLED
452 047222 032737 000100 050536          BIT      #ECH,500$   :ARE DATA FIELD ERRORS ENABLED ??
453 047230 001002          BNE      245$          :YES !!
454 047232 042716 000400          BIC      #MDPE,(SP)  :DISBALE MDPE
455 047236 013737 001346 001142 245$  MOV      RMCS2I,$BDDAT :GET RECEIVED STATUS
456 047244 042637 001142          BIC      (SP)+,$BDDAT :CLEAR MDPE IF ENABLED
    
```

```

457 047250 001412          BEQ    250$          ;BRANCH IF MDPE OK
458 047252 062716 000004    ADD    #4,(SP)        ;MOVE SP TO USERS ERROR CALL
459 047256 112776 000027 000000    MOVVB #27,@(SP)      ;WRITE ERROR NUMBER IN CALL
460 047264 162716 000002    SUB    #2,(SP)        ;MOVE SP TO ERROR RETURN
461 047270 004736          JSR    PC,@(SP)+      ;REPORT ERROR AND RETURN
462 047272 162716 000010    SUB    #10,(SP)       ;MOVE SP TO NO ERROR
463 047276          250$:
464
465          ;REPORT ERROR IF DCK IS SET AND DATA FIELD ERRORS ARE NOT ENABLED
466 047276 012746 177777    MOV    #-1,-(SP)      ;ASSUME ENABLED
467 047302 032737 000100 050536    BIT    #ECH,500$      ;ARE THEY ENABLED ??
468 047310 001002          BNE    255$          ;YES !!
469 047312 042716 100000    BIC    #DCK,(SP)      ;DISABLE DCK
470 047316 013737 001352 001142 255$:    MOV    RMER11,$BDDAT  ;GET RECEIVED STATUS
471 047324 042637 001142    BIC    (SP)+,$BDDAT   ;CLEAR DCK IF ENABLED
472 047330 001412          BEQ    260$          ;BRANCH IF DCK IS OK
473 047332 062716 000004    ADD    #4,(SP)        ;MOVE SP TO USERS ERROR CALL
474 047336 112776 000030 000000    MOVVB #30,@(SP)      ;WRITE ERROR NUMBER IN CALL
475 047344 162716 000002    SUB    #2,(SP)        ;MOVE SP TO ERROR RETURN
476 047350 004736          JSR    PC,@(SP)+      ;REPORT ERROR AND RETURN
477 047352 162716 000010    SUB    #10,(SP)       ;MOVE SP TO NO ERROR
478 047356          260$:
479
480          ;REPORT ERROR IF ECH IS SET AND,
481          ;DATA FIELD ERRORS ARE NOT ENABLED, OR
482          ;ECI IS SET, OR
483          ;DCK IS NOT SET.
484 047356 012746 177777    MOV    #-1,-(SP)      ;ASSUME ENABLED
485 047362 032737 000100 050536    BIT    #ECH,500$      ;ARE ERRORS ENABLED ??
486 047370 001410          BEQ    265$          ;NO !!
487 047372 032737 004000 001370    BIT    #ECI,RMOFI     ;IS ECI SET ??
488 047400 001004          BNE    265$          ;YES !!
489 047402 032737 100000 001352    BIT    #DCK,RMER11    ;IS DCK ALSO SET ??
490 047410 001002          BNE    270$          ;YES !!
491 047412 042716 000100 265$:    BIC    #ECH,(SP)      ;DISABLE ECH
492 047416 013737 001352 001142 270$:    MOV    RMER11,$BDDAT  ;GET RECEIVED STATUS
493 047424 042637 001142    BIC    (SP)+,$BDDAT   ;CLEAR ECH IF ENABLED
494 047430 001412          BEQ    275$          ;BRANCH IF ECH IS OK
495 047432 062716 000004    ADD    #4,(SP)        ;MOVE SP TO USERS ERROR CALL
496 047436 112776 000031 000000    MOVVB #31,@(SP)      ;WRITE ERROR NUMBER IN CALL
497 047444 162716 000002    SUB    #2,(SP)        ;MOVE SP TO ERROR RETURN
498 047450 004736          JSR    PC,@(SP)+      ;REPORT ERROR AND RETURN
499 047452 162716 000010    SUB    #10,(SP)       ;MOVE SP TO NO ERROR
500 047456          275$:
    
```

```

1
2
3
4
5 047436 022737 000030 050544      CMP      #SEARCH,515$      ;WAS DATA TRANSFERRED ?
6 047464 103402                    BLO      280$              ;BR IF YES
7 047466 000137 050510            JMP      355$              ;NO - EXIT
8
9      ;REPORT ERROR IF RMWC NOT ZERO AND TRE IS ZERO
10 047472 013737 001340 001142 280$: MOV      RMWCI,$BDDAT      ;WORD COUNT ZERO??
11 047500 001421                    BEQ      285$              ;YES
12 047502 032737 040000 001336    BIT      #TRE,RMCS1I      ;TRANSFER ERROR DETECTED??
13 047510 001015                    BNE      285$              ;YES.!
14 047512 062716 000004                    ADD      #4,(SP)
15 047516 112776 000015 000000    MOVVB   #15,@(SP)         ;ERROR NUMBER
16 047524 005037 001140            CLR      $GDDAT           ;GOOD DATA FOR TYPEOUT
17 047530 162716 000002            SUB      #2,(SP)          ;MOVE SP TO RETURN FOR ERROR
18 047534 004736                    JSR      PC,@(SP)+        ;REPORT WORD COUNT NOT ZERO
19 047536 162716 000010            SUB      #10,(SP)        ;RESTORE (SP)
20 047542 000240                    NOP
21
22      ;REPORT ERROR IF RMBA IS NOT CORRECT
23 047544 013737 001340 001140 285$: MOV      RMWCI,$GDDAT      ;GET WORD COUNT AT END OF TRANSFER AND
24 047552 163737 001414 001140    SUB      RMWCO,$GDDAT     ;SUBTRACT STARTING WORD COUNT.
25 047560 006337 001140            ASL      $GDDAT           ;* 2
26 047564 063737 001416 001140    ADD      RMBA0,$GDDAT     ;ADD STARTING BUS ADDRESS
27
28 047572 032737 000010 001346    BIT      #BAI,RMCS2I      ;WAS BUS ADDRESS INHIBIT (BAI) SET ??
29 047600 001403                    BEQ      290$              ;NO !!
30 047602 013737 001416 001140    MOV      RMBA0,$GDDAT     ;ADDRESS SHOULD NOT HAVE CHANGED
31
32 047610 023737 001140 001342 290$: CMP      $GDDAT,RMBAI      ;BUS ADDRESS OK??
33 047616 001416                    BEQ      295$              ;YES!!
34 047620 013737 001342 001142    MOV      RMBAI,$BDDAT     ;BAD DATA FOR TYPEOUT
35 047626 062716 000004                    ADD      #4,(SP)
36 047632 112776 000016 000000    MOVVB   #16,@(SP)         ;ERROR NUMBER
37 047640 162716 000002            SUB      #2,(SP)          ;MOVE SP TO RETURN FOR ERROR
38 047644 004736                    JSR      PC,@(SP)+        ;REPORT UNEXPECTED ADDRESS
39 047646 162716 000010            SUB      #10,(SP)        ;RESTORE (SP)
40 047652 000240                    NOP
41
42      ;COMPUTE NUMBER OF SECTORS TRANSFERRED FROM WORD COUNT
43 047654 005046                    CLR      -(SP)            ;NUMBER OF SECTORS TRANSFERRED
44 047656 013746 001340 295$: MOV      RMWCI,-(SP)        ;GET WORD COUNT AT END OF TRANSFER AND
45 047662 163716 001414            SUB      RMWCO,(SP)       ;SUBTRACT STARTING WORD COUNT.
46
47 047666 012746 000400                    MOV      #256,-(SP)       ;ASSUME 256. WORDS PER SECTOR
48 047672 032737 000002 001412    BIT      #BIT1,RMCS10     ;HEADER & DATA COMMAND ??
49 047700 001402                    BEQ      300$              ;NO !!
50 047702 062716 000002            ADD      #2,(SP)          ;CHANGE TO 258. WORDS PER SECTOR
51
52 047706 005266 000004 300$: INC      4(SP)            ;INCREMENT SECTOR COUNT
53 047712 161666 000002            SUB      (SP),2(SP)       ;SUBTRACT ONE SECTOR'S WORTH
54 047716 003373                    BGT      300$              ;CONTINUE IF NOT DONE
55 047720 022626                    CMP      (SP)+,(SP)+      ;RESTORE STACK
56
57      ;COMPUTE EXPECTED SECTOR, TRACK AND CYLINDER ADDRESS FROM

```

```

58                                     ;NUMBER OF SECTORS
59 047722 013737 001446 050536      MOV     RMDCO,500$      ;STORE ORIGINAL CYLINDER
60 047730 013737 001420 050540      MOV     RMDAO,505$     ;STORE ORIGINAL TRACK
61 047736 013737 001420 050542      MOV     RMDAO,510$     ;STORE ORIGINAL SECTOR
62 047744 013737 001334 050546      MOV     LSTRK,520$     ;STORE LAST TRACK,
63 047752 000337 050546              SWAB    520$           ;GET TRACK ADDRESS TO LO BYTE AND
64 047756 005237 050546              INC     520$           ;INCREMENT TO GET TOTL # OF TRACKS.
65
66 047762 042737 000377 050540      BIC     #^C<TADMSK>,505$ ;SAVE TRACK ADDRESS BITS AND
67 047770 000337 050540              SWAB    505$           ;SWAP TRACK ADDRESS TO LOW BYTE.
68 047774 042737 177400 050542      BIC     #^C<SADMSK>,510$ ;SAVE SECTOR ADDRESS BITS
69 050002 062637 050542              ADD     (SP)+,510$
70
71 050006 023727 050542 000040 310$:  CMP     510$,#32.      ;SECTOR OVEFLOWED??
72 050014 103406                    BLO    315$           ;NO..
73 050016 005237 050540              INC     505$           ;INCREMENT TRACK
74 050022 162737 000040 050542      SUB     #32.,510$     ;ADJUST SECTOR
75 050030 000766                    BR     310$           ;TRY AGAIN
76
77 050032 023737 050540 050546 315$:  CMP     505$,520$     ;TRACK OVEFLOWED??
78 050040 103407                    BLO    320$           ;NO.!
79 050042 005237 050536              INC     500$           ;INCREMENT CYLINDER
80 050046 163737 050546 050540      SUB     520$,505$     ;ADJUST TRACK
81 050054 000766                    BR     315$           ;TRY AGAIN
82 050056 000240                    NOP
83
84                                     ;REPORT ERROR IF 'LBT' IS NOT CORRECT
85 050060 005037 001140 001466 320$:  CLR     $GDDAT         ;SET GOOD DATA FOR LBT - 0
86 050060 023727 050536 001466      CMP     500$,#822.    ;SHOULD LBT BE SET??
87 050064 101407                    BLOS   325$           ;NO!!
88 050072 032737 002000 001352      BIT     #IAE,RMER11   ;WAS IAE SET ??
89 050074 001003                    BNE    325$           ;YES - LBT SHOULD NOT BE SET
90 050102 012737 002000 001140      MOV     #LBT,$GDDAT   ;SET GOOD DATA FOR LBT = 1
91 050104 013737 001350 001142 325$:  MOV     RMDSI,$BDDAT  ;BAD DATA FOR TYPEOUT
92 050112 042737 175777 001142      BIC     #^CLBT,$BDDAT
93 050120 023737 001140 001142      CMP     $GDDAT,$BDDAT ;IS LBT CORRECT??
94 050126 001413                    BEQ    330$           ;YES!!
95 050134 062716 000004              ADD     #4,(SP)
96 050136 112776 000017 000000      MOVVB  #17,@(SP)     ;ERROR NUMBER
97 050142 162716 000002              SUB     #2,(SP)       ;MOVE SP TO RETURN FOR ERROR
98 050150 004736                    JSR    PC,@(SP)+     ;REPORT LBT IS WRONG
99 050156 162716 000010              SUB     #10,(SP)      ;RESTORE (SP)
100 050162 000240                    NOP
101
102
103                                     ;REPORT ERROR IF 'AOE' IS INCORRECT
104 050164 005037 001140 001352 330$:  CLR     $GDDAT         ;SET FOR AOE = 0
105 050170 032737 002000 001352      BIT     #IAE,RMER11   ;WAS 'IAE' DETECTED??
106 050176 001031                    BNE    340$           ;YES-'AOE' SHOULD BE ZERO
107 050200 023727 050536 001466      CMP     500$,#822.    ;SHOULD AOE BE SET??
108 050206 101425                    BLOS   340$           ;NO!!
109 050210 005737 050540              TST    505$           ;MAYBE
110 050214 001012                    BNE    335$           ;YES
111 050216 005737 050542              TST    510$           ;MAYBE
112 050222 001007                    BNE    335$           ;YES !!
113 050224 032737 000010 050544      BIT     #F2,515$     ;WAS THIS READ OR WRITE CHECK ??
114 050232 001413                    BEQ    340$           ;NO ..
    
```

```

115 050234 005737 001340          TST    RMWCI          ;WAS ALL DATA TRANSFERRED ??
116 050240 001410          BEQ    340$          ;YES !!
117 050242 012737 001000 001140 335$: MOV    #AOE,$GDDAT   ;SET FOR AOE = 1
118 050250 005037 050540          CLR    505$         ;CLEAR EXPECTED TRACK
119 050254 012737 000001 050542    MOV    #1,510$      ;EXPECT SECTOR = 1
120 050262 013737 001352 001142 340$: MOV    RMER1I,$BDDAT ;BAD DATA FOR TYPEOUT
121 050270 042737 176777 001142    BIC    #^CAOE,$BDDAT
122 050276 023737 001140 001142    CMP    $GDDAT,$BDDAT ;IS AOE CORRECT??
123 050304 001413          BEQ    345$         ;YES!!
124 050306 062716 000004          ADD    #4,(SP)
125 050312 112776 000020 000000    MOVB  #20,@(SP)    ;ERROR NUMBER
126 050320 162716 000002          SUB    #2,(SP)     ;MOVE SP TO RETURN FOR ERROR
127 050324 004736          JSR    PC,@(SP)+   ;REPORT AOE IS WRONG
128 050326 162716 000010          SUB    #10,(SP)   ;RESTORE (SP)
129 050332 000240          NOP
130
131          ;REPORT ERROR IF RMDA IS NOT CORRECT
132 050334 032737 002000 001352 345$: BIT    #IAE,RMER1I ;WAS THERE AN IAE ERROR ??
133 050342 001062          BNE    355$         ;YES - DONT CHECK RMDA,RMDC
134 050344 013737 050540 001140    MOV    505$,$GDDAT ;SETUP EXPECTED DISK ADDRESS
135 050352 000337 001140          SWAB  $GDDAT
136 050356 113737 050542 001140    MOVB  510$,$GDDAT
137 050364 013737 001344 001142    MOV    RMDAI,$BDDAT ;SETUP RECEIVED DISK ADDRESS
138 050372 023737 001140 001142    CMP    $GDDAT,$BDDAT ;COMPARE EXPECTED & RECEIVED
139 050400 001413          BEQ    350$         ;BRANCH IF EQUAL
140 050402 062716 000004          ADD    #4,(SP)
141 050406 112776 000021 000000    MOVB  #21,@(SP)    ;ERROR NUMBER
142 050414 162716 000002          SUB    #2,(SP)     ;MOVE SP TO RETURN FOR ERROR
143 050420 004736          JSR    PC,@(SP)+   ;REPORT BAD DISK ADDRESS
144 050422 162716 000010          SUB    #10,(SP)   ;RESTORE (SP)
145 050426 000240          NOP
146
147          ;REPORT ERROR IF RMDC IS INCORRECT
148 050430 013737 050536 001140 350$: MOV    500$,$GDDAT   ;SETUP EXPECTED CYLINDER
149 050436 042737 176000 001140    BIC    #^C1777,$GDDAT
150 050444 013737 001372 001142    MOV    RMDCI,$BDDAT ;SETUP RECEIVED CYLINDER
151 050452 023737 001140 001142    CMP    $GDDAT,$BDDAT ;COMPARE CYLINDERS
152 050460 001413          BEQ    355$         ;BRANCH IF EQUAL
153 050462 062716 000004          ADD    #4,(SP)
154 050466 112776 000022 000000    MOVB  #22,@(SP)    ;ERROR NUMBER
155 050474 162716 000002          SUB    #2,(SP)     ;MOVE SP TO RETURN FOR ERROR
156 050500 004736          JSR    PC,@(SP)+   ;REPORT BAD CYLINDER
157 050502 162716 000010          SUB    #10,(SP)   ;RESTORE (SP)
158 050506 000240          NOP
159
160 050510 062716 000004          355$: ADD    #4,(SP)    ;MOVE (SP) TO ERROR CALL
161 050514 105776 000000          TSTB  @(SP)        ;WAS ERROR FOUND??
162 050520 001403          BEQ    360$
163 050522 062716 000004          ADD    #4,(SP)    ;MOVE (SP) TO ERROR RETURN
164 050526 000402          BR    365$
165 050530 162716 000004          360$: SUB    #4,(SP)    ;MOVE (SP) TO NO ERROR RETURN
166 050534 000207          365$: RTS    PC
167
168 050536 000000          500$: .WORD 0      ;CYLINDER
169 050540 000000          505$: .WORD 0      ;TRACK
170 050542 000000          510$: .WORD 0      ;SECTOR
171 050544 000000          515$: .WORD 0      ;FUNCTION CODE
    
```

050546 000000

5208: .WORD 0

;TOTAL # OF TRACKS = LAST TRACK +1

;

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57

.SBTTL COMPOSITE ERROR CHECK SUBROUTINE

:THIS SUBROUTINE CHECKS THE STORED CONTENTS OF RMER1 AND
:RMER2 AFTER MASKING EACH REGISTER WORD WITH THE USER'S STATUS
:MASKS AND REPORTS AN ERROR IF ANY BITS ARE LEFT ON AFTER
:THE MASKS ARE APPLIED.

:CALL:
:(1) JSR PC,CMPERRSTS ;MASK FOR ERROR REGISTER 1
 .WORD ;MASK FOR ERROR REGISTER 2
 .WORD ;RETURN HERE IF NO ERROR
 BR ??? ;RETURN HERE TO REPORT AN ERROR
 NOP ;ERROR NUMBER DEFINED BY SUB
 ERROR ;GO BACK TO SUB FOR MORE ERROR CHECKS
 JSR PC,@(SP)+ ;RETURN HERE IF NO MORE ERRORS
 ???

:NOTE: BITS TO BE MASKED SHOULD BE ONE; BITS TO BE TESTED SHOULD
:BE ZERO

CMPERRSTS:

:MASK AND STORE THE CONTENTS OF RMER1 AND RMER2
MOV RMER1I,\$TMP1 ;STORE RMER1 AT TEMP STORAGE
BIC @(SP),\$TMP1 ;MASK RMER1
ADD #2,(SP) ;MOVE SP TO NEXT MASK
MOV RMER2I,\$TMP2 ;STORE RMER2 AT TEMP STORAGE
BIC @(SP),\$TMP2 ;MASK RMER2

:CLEAR USER'S ERROR CALL
ADD #6,(SP) ;MOVE SP TO USER'S ERROR CALL
CLRB @(SP) ;CLEAR ERROR NUMBER
SUB #4,(SP) ;LEAVE SP AT NO ERROR RETURN

:SEE IF THERE WERE ANY ERRORS IN RMER1, I.E., \$TMP1
TST \$TMP1 ;ANY ERRORS TO REPORT??
BEQ 5\$;NO!
MOV \$TMP1,\$BDDAT ;RECEIVED STATUS FOR TYPEOUT
CLR \$GDDAT ;EXPECTED STATUS FOR TYPEOUT
ADD #4,(SP) ;MOVE SP TO USER'S ERROR CALL
MOVB #66,@(SP) ;CORRECTABLE DATA CHECK ERROR #
SUB #2,(SP) ;MOVE SP TO RETURN FOR ERROR
JSR PC,@(SP)+ ;REPORT ERROR VIA USER
SUB #10,(SP) ;MOVE SP BACK TO BRANCH
NOP

5\$:
;
;

:SEE IF THERE ARE ANY ERRORS TO REPORT IN RMER2 (\$TMP2)
TST \$TMP2 ;ANY ERRORS IN RMER2?
BEQ 10\$;NO!!
MOV \$TMP2,\$BDDAT ;RECEIVED STATUS FOR TYPEOUT
CLR \$GDDAT ;EXPECTED STATUS FOR TYPEOUT
ADD #4,(SP) ;MOVE SP TO USER'S ERROR CALL
MOVB #67,@(SP) ;WRITE ERROR NUMBER IN USER'S CALL

050550
050550 013737 001352 001176
050556 047637 000000 001176
050564 062716 000002
050570 013737 001400 001200
050576 047637 000000 001200

050604 062716 000006
050610 105076 000000
050614 162716 000004

050620 005737 001176
050624 001420
050626 013737 001176 001142
050634 005037 001140
050640 062716 000004
050644 112776 000066 000000
050652 162716 000002
050656 004736
050660 162716 000010
050664 000240
050666

050666 005737 001200
050672 001420

050674 013737 001200 001142
050702 005037 001140
050706 062716 000004
050712 112776 000067 000000


```

COMPOSITE ERROR CHECK SUBROUTINE
58 050720 162716 000002      SUB      #2,(SP)      :MOVE SP TO RETURN FOR ERROR
59 050724 004736             JSR      PC,@(SP)+    :REPORT ERROR VIA USER
60 050726 162716 000010      SUB      #10,(SP)     :MOVE SP TO NO ERROR RETURN
61 050732 000240             NOP
62 050734
63
64                               ;AUGMENT THE RETURN ADDRESS IF ANY ERROR WAS DETECTED
65 050734 062716 000004      ADD      #4,(SP)      :MOVE SP TO USER'S ERROR CALL
66 050740 105776 000000      TSTB    @ (SP)        :WAS THERE AN ERROR CALLED??
67 050744 001403             BEQ     20$           :NO!!
68 050746 062716 000004      ADD      #4,(SP)      :YES - MOVE SP TO ERROR RETURN
69 050752 000402             BR     30$           :
70 050754 162716 000004      20$:    SUB      #4,(SP)     :MOVE SP TO NO ERROR RETURN
71 050760 000207             30$:    RTS      PL      :RETURN TO USER

```

.SBTTL DEVICE SELECT SUBROUTINE

; THIS SUBROUTINE SELECTS THE DEVICE, GETTING THE DEVICE NUMBER FROM THE
 ; TEST QUEUE.

;CALL:
 ;(1) JSR PC,DEVSEL
 ;(2) BR ?? RETURN IF NO ERROR
 ;(3) NOP RETURN IF ERROR
 ;(4) ERROR ERROR DEFINED BY SUBROUTINE

DEVSEL:

;CLEAR USER'S ERROR CALL
 ADD #4,(SP) ;MOVE SP TO USER'S ERROR
 CLRB @ (SP) ;CLEAR LOW ORDER BYTE OF CALL
 SUB #4,(SP) ;MOVE SP BACK

;SAVE USER'S INFORMATION AND SETUP REGISTERS
 MOV ERRVEC,-(SP) ;:PUSH ERRVEC ON STACK
 MOV ERRVEC+2,-(SP) ;:PUSH ERRVEC+2 ON STACK
 MOV R0,-(SP) ;:PUSH R0 ON STACK
 MOV R1,-(SP) ;:PUSH R1 ON STACK
 MOV #20\$,ERRVEC ;SETUP FOR BUS TIMEOUT
 MOV #PR6,ERRVEC+2
 MOV \$BASE,R0 ;R0 - UNIBUS ADDRESS
 MOV TSTQUE,R1 ;R1 POINTS TO DEVICE NUMBER

;SELECT DEVICE AND VERIFY THAT DEVICE IS AVAILABLE
 MOV (R1),RMCS2(R0) ;WRITE UNIT SELECT BITS
 MOV RMCS1(R0),\$TMP1 ;GET 'DVA' STATUS
 MOV RMCS2(R0),\$TMP0 ;GET 'NED' STATUS

BIT #NED,\$TMP0 ;IS DEVICE NONEXISTENT ?
 BEQ 10\$;NO.
 ADD #4,10(SP) ;MOVE SP TO USERS ERROR CALL
 MOV #111,@10(SP) ;WRITE ERROR NUMBER
 BR 30\$

10\$: BIT #DVA,\$TMP1 ;IS DEVICE AVAILABLE ?
 BNE 35\$;YES!
 ADD #4,10(SP) ;MOVE SP TO USERS ERROR CALL
 MOV #112,@10(SP) ;WRITE ERROR NUMBER
 BR 30\$

;HANDLE BUS TIMEOUT
 20\$: CMP (SP)+,(SP)+ ;ADJUST SP
 ADD #4,10(SP) ;MOVE SP TO USERS ERROR CAL
 MOV #113,@10(SP) ;WRITE BUS TIMEOUT ERROR NUMBER
 30\$: SUB #2,10(SP) ;ADJUST RETURN TO 'NOP' PRECEDING
 ;THE ERROR CALL

;RESTORE USERS DATA AND RETURN TO ADDRESS ON STACK

35\$: MOV (SP)+,R1 ;:POP STACK INTO R1
 MOV (SP)+,R0 ;:POP STACK INTO R0
 MOV (SP)+,ERRVEC+2 ;:POP STACK INTO ERRVEC+2

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51

050762
 050762 062716 000004
 050766 105076 000000
 050772 162716 000004
 050776 013746 000004
 051002 013746 000006
 051008 010046
 051010 010146
 051012 012737 051132 000004
 051020 012737 000300 000006
 051026 013700 001276
 051032 013701 001466
 051036 111160 000010
 051042 016037 000000 001176
 051050 016037 000010 001174
 051056 032737 010000 001174
 051064 001407
 051066 062766 000004 000010
 051074 112776 000111 000010
 051102 000422
 051104 032737 004000 001176 10\$:
 051112 001021
 051114 062766 000004 000010
 051122 112776 000112 000010
 051130 000407
 051132 022626
 051134 062766 000004 000010 20\$:
 051142 112776 000113 000010
 051150 162766 000002 000010 30\$:
 051156
 051156 012601
 051160 012600
 051162 012637 000006

051166 012637 000004
051172 000207

MOV (SP)+,ERRVEC
RTS PC
::POP STACK INTO ERRVEC
:EXIT

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57

```

.SBTTL SEEK STATUS CHECK SUBROUTINE

;THIS SUBROUTINE VERIFIES THE RESULTS OF SEEK TESTS USING STATUS
;STORED IN THE GET BUFFER AND TEST PARAMETERS STORED IN THE PUT BUFFER.

;THE SUBROUTINE RETURNS TO THE CALLING ROUTINE IF AN ERROR IS DETECTED
;AFTER HAVING LOADED THE APPROPRIATE ERROR NUMBER IN THE 'ERROR' TRAP
;OF THE CALLING ROUTINE. SEEK STATUS IS CHECKED AS FOLLOWS:

;CALL:
;(1) JSR PC,SEKSTS
      BR ??? RETURN HERE IF NO ERROR
      NOP RETURN HERE TO REPORT AN ERROR
      ERROR ERROR NUMBER DEFINED BY SUB
      JSR PC,@(SP)+ GO BACK TO SUB FOR MORE ERROR CHECKS
      ??? RETURN HERE IF NO MORE ERRORS

SEKSTS:

;CLEAR USERS' ERROR CALL
NOP
ADD #4,(SP) ;MOVE (SP) TO ERROR CALL
CLRB @(SP) ;CLEAR ERROR NUMBER
SUB #4,(SP) ;MOVE (SP) TO NO ERROR RETURN
CLR 300$ ;CLEAR ERROR FLAGS

;TEST FOR MASSBUS CONTROL BUS PARITY ERROR WHEN WRITING
;LOCAL REGISTERS, I.E., 'PAR' 1 AND 'DPE' - 0
BIT #PAR,RMER1I ;WAS PARITY ERROR DETECTED??
BEQ 1$ ;NO!!
BIT #DPE,RMER2I ;WAS IT DUE TO CONTROL BUS??
BNE 1$ ;NOT SURE!!

;REPORT REGISTER PARITY ERROR VIA USER'S ERROR CALL
CLR $GDDAT ;EXPECTED STATUS
MOV RMER1I,$BDDAT ;RECEIVED STATUS
ADD #4,(SP) ;MOVE STACK TO USER'S ERROR
MOVB #50,@(SP) ;ERROR #50
SUB #2,(SP) ;MOVE SP TO RETURN FOR ERROR
JSR PC,@(SP)+
SUB #10,(SP) ;RESTORE STACK
BR 3$ ;IAE SHOULD BE ZERO

;DETERMINE THE VALUE OF 'IAE' STATUS BASED ON TRACK, SECTOR AND CYLINDER
;ALSO, SET 'SKI' IF CYLINDER ADDRESS IS TOO LARGE.
1$: MOV #IAE,$GDDAT ;SETUP FOR IAE - 1
    BIS #SKI,300$ ;SETUP FOR SKI = 1
    CMP RMDCO,#822. ;GREATER THAN LAST CYLINDER ?
    BHI 3$ ;YES - CYLINDER IS INVALID
    BIC #SKI,300$ ;CLEAR SKI ERROR FLAG

    CMPB RMDAO+1,LSTRK+1 ;GREATER THAN LAST TRACK ?
    BHI 3$ ;YES - TRACK IS INVALID

    CMPB RMDAO,#29. ;SECTOR > 29. ?
    BLOS 2$ ;BR IF NO
  
```

051174				
051174	000240			
051176	062716	000004		
051202	105076	000000		
051206	162716	000004		
051212	005037	052432		
051216	032737	000010	001352	
051224	001424			
051226	032737	000010	001400	
051234	001020			
051236	005037	001140		
051242	013737	001352	001142	
051250	062716	000004		
051254	112776	000050	000000	
051262	162716	000002		
051266	004736			
051270	162716	000010		
051274	000437			
051276	012737	002000	001140	
051304	052737	040000	052432	
051312	023727	001446	001466	
051320	101025			
051322	042737	040000	052432	
051330	123737	001421	001335	
051336	101016			
051340	123727	001420	000035	
051346	101410			

```

58 051350 032737 010000 001444 BIT #FMT16,RM0FO ;18 BIT FORMAT ?
59 051356 001406 BEQ 3$ ;YES - SECTOR IS INVALID FOR 18 BIT MODE
60 051360 123727 001420 000037 CMPB RMDAO,#31. ;SECTOR > 31. ?
61 051366 101002 BHI 3$ ;YES - SECTOR IS INVALID
62
63 051370 005037 001140 2$: CLR $GDDAT ;'IAE' SHOULD = 0
64
65 ;COMPARE EXPECTED AND RECIEVED 'IAE' STATUS
66 051374 013737 001352 001142 3$: MOV RMFR1I,$BDDAT ;IS IAE OK??
67 051402 042737 175777 001142 BIC #^CIAE,$BDDAT ;SAVE IAE BIT FOR COMPARE
68 051410 023737 001140 001142 CMP $GDDAT,$BDDAT ;CORRECT 'IAE' STATUS ?
69 051416 001004 BNE 35$ ;BR IF NO
70 051420 042737 040000 052432 BIC #SKI,300$ ;CLEAR SKI FLAG
71 051426 000413 BR 5$ ;GO CHECK NEXT ERROR
72 051430
73 35$: ;REPORT INCORRECT 'IAE' STATUS VIA USER'S ERROR CALL
74 051430 062716 000004 ADD #4,(SP)
75 051434 112776 000051 000000 MOVB #51,@(SP) ;ERROR 51
76 051442 162716 000002 SUB #2,(SP) ;MOVE SP TO RETURN FOR ERROR
77 051446 004736 JSR PC,@(SP)+ ;REPORT INCORRECT IAE
78 051450 162716 000010 SUB #10,(SP) ;RESTORE (SP)
79 051454 000240 NOP
80 051456
81
82 ;REPORT ANY IVC ERROR AS
83 ; IVC ERROR WITH VOLUME VALID ZERO
84 ; ERRONEOUS IVC ERROR, VOLUME VALID IS SET
85 051456 032737 010000 001400 BIT #IVC,RMER2I ;IVC ERROR??
86 051464 001427 BEQ 52$ ;NO!!
87 051466 005037 001140 CLR $GDDAT ;EXPECTED STATUS
88 051472 013737 001400 001142 MOV RMER2I,$BDDAT ;RECEIVED STATUS
89 051500 062716 000004 ADD #4,(SP) ;MOVE SP TO USER'S ERROR
90 051504 112776 000060 000000 MOVB #60,@(SP) ;ERROR 60 IF VV - 0
91 051512 032737 000100 001350 BIT #VV,RMDSI
92 051520 001403 BEQ 51$
93 051522 112776 000061 000000 MOVB #61,@(SP) ;ERROR 61 IF VV - 1
94 051530 162716 000002 51$: SUB #2,(SP) ;MOVE SP TO RETURN FOR ERROR
95 051534 004736 JSR PC,@(SP)+ ;REPORT ERROR VIA USER
96 051536 162716 000010 SUB #10,(SP) ;RESTORE SP
97 051542 000240 NOP
98
99 051544 013737 001400 001142 52$: MOV RMER2I,$BDDAT ;RECEIVED STATUS
100 051552 042737 137777 001142 BIC #^CSKI,$BDDAT ;CLEAR DONT CARES
101 051560 013737 052432 001140 MOV 300$,$GDDAT ;GET EXPECTED SKI STATUS
102 051566 042737 137777 001140 BIC #^CSKI,$GDDAT ;CLEAR DONT CARES
103 051574 001417 BEQ 53$ ;BRANCH IF 0 EXPECTED
104
105 ;REPORT ERROR IF SKI IS NOT SET (IAE WAS NOT DETECTED)
106 051576 032737 040000 001142 BIT #SKI,$BDDAT ;WAS SKI DETECTED ??
107 051604 001032 BNE 54$ ;YES !!
108 051606 062716 000004 ADD #4,(SP) ;MOVE SP TO USERS ERROR CALL
109 051612 112776 000267 000000 MOVB #267,@(SP) ;WRITE ERROR NUMBER
110 051620 162716 000002 SUB #2,(SP) ;MCVE SP TO ERROR RETURN
111 051624 004736 JSR PC,@(SP)+ ;REPORT ERROR AND RETURN
112 051626 162716 000010 SUB #10,(SP) ;MOVE SP TO NO ERROR
113 051632 000443 BR 6$ ;GO TO NEXT ERROR CHECK
114 051634 53$:

```

```

115
116
117 051634 032737 040000 001142 ;REPORT ERROR IF SKI IS SET
118 051642 001413 BIT #SKI,$BDDAT ;IS SKI SET ??
119 051644 062716 000004 BEQ 54$ ;NO - SKI IS OK
120 051650 112776 000054 000000 ADD #4,(SP) ;MOVE (SP) TO ERROR
121 051656 162716 000002 MOVB #54,@(SP) ;LOAD ERROR NUMBER
122 051662 004736 JSR PC,@(SP)+ ;MOVE SP TO RETURN FOR ERROR
123 051664 162716 000010 SUB #10,(SP) ;REPORT SEEK ERROR
124 051670 000240 NOP ;RESTORE (SP)
125
126 ;REPORT ANY DEVICE CHECK
127 051672 032737 000200 001400 54$: BIT #DVC,$RMR2I ;WAS THERE DVC DURING SEFK??
128 051700 001420 BEQ 6$ ;NO!!
129 051702 005037 001140 CLR $GDDAT ;EXPECTED STATUS
130 051706 013737 001400 001142 MOV $RMR2I,$BDDAT ;RECEIVED STATUS
131 051714 062716 000004 ADD #4,(SP)
132 051720 112776 000055 000000 MOVB #55,@(SP) ;ERROR #55
133 051726 162716 000002 SUB #2,(SP) ;MOVE SP TO RETURN FOR ERROR
134 051732 004736 JSR PC,@(SP)+ ;REPORT ERROR VIA USER
135 051734 162716 000010 SUB #10,(SP) ;RESTORE SP
136 051740 000240 NOP
137
138 ;REPORT ANY 'OPI' ERROR AS OPI WITH MOL 0, OR OPI
139 ;BECAUSE ON CYLINDER LATCH DIDN'T RESET
140 051742 032737 020000 001352 6$: BIT #OPI,$RMR1I ;'OPI' ERROR??
141 051750 001427 BEQ 8$ ;NO!!
142 051752 005037 001140 CLR $GDDAT ;EXPECTED STATUS
143 051756 013737 001352 001142 MOV $RMR1I,$BDDAT ;RECEIVED STATUS
144 051764 062716 000004 ADD #4,(SP) ;MOVE (SP) TO ERROR
145 051770 112776 000052 000000 MOVB #52,@(SP) ;LOAD ERROR NUMBER
146 051776 032737 010000 001350 BIT #MOL,$RMDSI ;WAS MEDIUM ON LINE??
147 052004 001403 BEQ 7$ ;NO!!
148 052006 112776 000053 000000 MOVB #53,@(SP) ;YES - CHANGE ERROR NUMBER
149 052014 162716 000002 7$: SUB #2,(SP) ;MOVE SP TO RETURN FOR ERROR
150 052020 004736 JSR PC,@(SP)+ ;REPORT 'OPI' ERROR
151 052022 162716 000010 SUB #10,(SP) ;RESTORE (SP)
152 052026 000240 NOP
153
154 ;SEE IF 'PIP' = 0, AND 'ATA', 'MOL' AND 'VV' = 1
155 052030 013746 001350 8$: MOV $RMDSI,-(SP)
156 052034 042716 047677 BIC #^C<ATA!PIP.MOL!VV>,(SP)
157 052040 022726 110100 CMP #ATA!MOL!VV,(SP)+
158 052044 001002 BNE 9$ ;ERROR IN RMD5
159 052046 000137 052402 JMP 14$ ;RMD5 IS OK
160
161 ;REPORT ERROR IF MOL = 0 AND OPI = 0
162 052052 032737 010000 001350 9$: BIT #MOL,$RMDSI ;IS MOL RESET??
163 052060 001030 BNE 10$ ;NO - MOL IS SET
164 052062 032737 020000 001352 BIT #OPI,$RMR1I ;WAS OPI SET
165 052070 001024 BNE 10$ ;YES - DONT REPORT ERROR
166 052072 013737 001350 001140 MOV $RMDSI,$GDDAT ;EXPECTED STATUS
167 052100 052737 010000 001140 BIS #MOL,$GDDAT
168 052106 013737 001350 001142 MOV $RMDSI,$BDDAT ;RECEIVED STATUS
169 052114 062716 000004 ADD #4,(SP)
170 052120 112776 000062 000000 MOVB #62,@(SP)
171 052126 162716 000002 SUB #2,(SP) ;MOVE SP TO RETURN FOR ERROR

```

```

172 052132 004736          JSR      PC,@(SP)+      ;REPORT ERROR VIA USER
173 052134 162716 000010  SUB      #10,(SP)
174 052140 000240          NOP
175
176          ;REPORT AN ERROR IF 'PIP' IS STIL SET AND SKI NOT SET
177 052142 032737 020000 001350 10$: BIT      #PIP,RMDSI      ;IS 'PIP' STILL SET??
178 052150 001430          BEQ      11$              ;NO!!
179 052152 032737 040000 001400  BIT      #SKI,RMER2I     ;WAS 'SKI' SET??
180 052160 001024          BNE      11$              ;YES-DONT REPORT PIP
181 052162 013737 001350 001140  MOV      RMDSI,$GDDAT    ;EXPECTED STATUS
182 052170 042737 020000 001142  BIC      #PIP,$BDDAT
183 052176 013737 001350 001142  MOV      RMDSI,$BDDAT    ;RECEIVED STATUS
184 052204 062716 000004          ADD      #4,(SP)         ;MOVE (SP) TO ERROR
185 052210 112776 000056 000000  MOVVB   #56,@(SP)       ;LOAD ERROR NUMBER
186 052216 162716 000002          SUB      #2,(SP)         ;MOVE SP TO RETURN FOR ERROR
187 052222 004736          JSR      PC,@(SP)+      ;REPORT 'PIP' SET AFTER SEEK
188 052224 162716 000010  SUB      #10,(SP)       ;RESTORE (SP)
189 052230 000240          NOP
190
191          ;REPORT AN ERROR IF 'ATA' IS NOT SET
192 052232 032737 100000 001350 11$: BIT      #ATA,RMDSI     ;WAS 'ATA' SET ??
193 052240 001024          BNE      13$              ;YES!!
194 052242 013737 001350 001140  MOV      RMDSI,$GDDAT    ;EXPECTED STATUS
195 052250 052737 110600 001140  BIS      #ATA!MOL!DPR!DRY,$GDDAT
196 052256 013737 001350 001142  MOV      RMDSI,$BDDAT    ;RECEIVED STATUS
197 052264 062716 000004          ADD      #4,(SP)         ;MOVE (SP) TO ERROR
198 052270 112776 000057 000000  MOVVB   #57,@(SP)       ;LOAD ERROR NUMBER
199 052276 162716 000002          SUB      #2,(SP)         ;MOVE SP TO RETURN FOR ERROR
200 052302 004736          JSR      PC,@(SP)+      ;REPORT ATTENTION NOT SET DURING
201          ;SEEK TEST
202 052304 162716 000010  SUB      #10,(SP)       ;RESTORE (SP)
203 052310 000240          NOP
204
205          ;REPORT ERROR IF VOLUME VALID IS RESET AND IVC IS ZERO
206 052312 032737 000100 001350 13$: BIT      #VV,RMDSI      ;IS VV = 0 ??
207 052320 001030          BNE      14$              ;NO!!
208 052322 032737 010000 001400  BIT      #IVC,RMER2I     ;IS IVC ALSO 0 ??
209 052330 001024          BNE      14$              ;NO - IVC IS SET
210 052332 013737 001350 001140  MOV      RMDSI,$GDDAT    ;EXPECTED STATUS
211 052340 052737 000100 001140  BIS      #VV,$GDDAT
212 052346 013737 001350 001142  MOV      RMDSI,$BDDAT    ;RECEIVED STATUS
213 052354 062716 000004          ADD      #4,(SP)         ;ERROR #64
214 052360 112776 000064 000000  MOVVB   #64,@(SP)       ;MOVE SP TO RETURN FOR ERROR
215 052366 162716 000002          SUB      #2,(SP)
216 052372 004736          JSR      PC,@(SP)+
217 052374 162716 000010  SUB      #10,(SP)
218 052400 000240          NOP
219 052402          14$:
220
221          ;MODIFY THE RETURN ADDRESS IF AN ERROR WAS DETECTED
222 052402 000240          NOP
223 052404 062716 000004          ADD      #4,(SP)         ;MOVE (SP) TO ERROR CALL
224 052410 105776 000000  TSTB    @ (SP)          ;WAS ERROR CALLED??
225 052414 001403          BEQ      15$              ;NO!!
226 052416 062716 000004          ADD      #4,(SP)         ;MOVE TO ERROR RETURN
227 052422 000402          BR      16$

```



SEEK STATUS CHECK SUBROUTINE
229 052424 162716 000004
230 052430 000207
231
232 052432 000000

15\$: SUB #4,(SP) ;MOVE (SP) TO NO ERROR RETURN
16\$: RTS PC ;RETURN
300\$: .WORD 0 ;ERROR FLAGS

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26

.SBTTL CONTROLLER CLEAR SUBROUTINE

:THIS SUBROUTINE CLEARS THE MASSBUS CONTROLLER, MASSBUS ADAPTERS,
:AND DRIVES, THEN SELECTS THE DRIVE.

```

:CALL: JSR    PC,CNTCLR
:       BR    ???
:       NOP
:       ERROR
:       ???
    
```

RETURN HERE IF NO ERROR FOUND
RETURN HERE IF ANY ERROR FOUND
SUB DEFINES ERROR NUMBER

CNTCLR:

```

MOV    R0,-(SP)      ;;PUSH R0 ON STACK
MOV    R1,-(SP)      ;;PUSH R1 ON STACK
MOV    ERRVEC,-(SP)  ;;PUSH ERRVEC ON STACK
MOV    ERRVEC+2,-(SP) ;;PUSH ERRVEC+2 ON STACK
MOV    #10$,ERRVEC   ;SETUP FOR BUS TIMEOUT
MOV    #PR6,ERRVEC+2
MOV    $BASE,R0      ;R0 = UNIBUS ADDRESS
MOV    #CLR,RMCS2(R0) ;CLEAR MASSBUS
MOV    TSTQUE,R1     ;GET DEVICE UNDER TEST
MOVB   (R1),RMCS2(R0) ;SELECT DEVICE
BR     20$
    
```

10\$:

```

CMP    (SP)+,(SP)+  ;ADJUST STACK
ADD    #4,10(SP)    ;MOVE SP TO USER'S ERROR CALL
MOVB   #7,@10(SP)  ;WRITE THE ERROR NUMBER
SUB    #2,10(SP)    ;ADJUST SP TO RETURN TO ERROR
    
```

20\$:

```

MOV    (SP)+,ERRVEC+2 ;;POP STACK INTO ERRVEC+2
MOV    (SP)+,ERRVEC  ;;POP STACK INTO ERRVEC
MOV    (SP)+,R1      ;;POP STACK INTO R1
MOV    (SP)+,R0      ;;POP STACK INTO R0
RTS    PC
    
```

```

052434 010046
052434 010146
052436 010146
052440 013746 000004
052444 013746 000006
052450 012737 052510 000004
052456 012737 000300 000006
052464 013700 001276
052470 012760 000040 000010
052476 013701 001466
052502 111160 000010
052506 000412
052510 022626
052512 062766 000004 000010
052520 112776 000007 000010
052526 162766 000002 000010
052534
052534 012637 000006
052540 012637 000004
052544 012601
052546 012600
052550 000207
    
```

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57

```

.SBTTL CONTROLLER CLEAR STATUS CHECK SUBROUTINE

:THIS SUBROUTINE VERIFIES THAT THE SUBSYSTEM IS INITIALIZED BASED ON
:STATUS STORED IN THE GET BUFFER. THIS SUBROUTINE SHOULD ONLY BE
:USED FOLLOWING A CONTROLLER CLEAR OPERATION, I.E., WRITING A 1 IN BIT
:5 OF RMCS2, BECAUSE THE ERROR MESSAGES ARE BASED ON THAT CONDITION.

:STATUS PERTINENT TO THE DEVICE IS NOT CHECKED. IN PARTICULAR, THE
:FOLLOWING STATUS BITS ARE NOT CHECKED:
:
:   ATA,ERR,PIP,MOL,WRL,LBT,PGM,VV,UM,UNS,SKI,DVC
:
:CALL:
:(1) JSR   PC,CLRSTS
:     BR   ???           RETURN HERE IF NO ERROR
:     NOP           RETURN HERE TO REPORT AN ERROR
:     ERROR        ERROR NUMBER DEFINED BY SUB
:     JSR   PC,@(SP)+   GO BACK TO SUB FOR MORE ERROR CHECKS
:     ???           RETURN HERE IF NO MORE ERRORS

CLRSTS:

: CLEAR USER'S ERROR CALL
ADD   #4,(SP)           :MOVE SP TO ERROR
CLPB  @(SP)             :CLEAR ERROR NUMBER
SUB   #4,(SP)           :MOVE SP BACK TO NO ERROR

:REPORT ERROR IF RMCS1 NOT INITIALIZED
4$:  MOV   RMCS1I,$BDDAT :VERIFY RMCS1
     BIC  #SC,$BDDAT    :IGNORE SPECIAL CONDITION
     MOV  #DVA!RDY,$GDDAT :EXPECT DVA & RDY
     CMP  $GDDAT,$BDDAT :COMPARE EXPECTED, RECEIVED
     BEQ  5$           :BRANCH IF EQUAL
     ADD  #4,(SP)       :MOVE SP TO USER'S ERROR CALL
     MOVB #126,@(SP)   :WRITE ERROR NUMBER IN CALL
     SUB  #2,(SP)       :MOVE SP TO RETURN FOR ERROR
     JSR  PC,@(SP)+    :REPORT ERROR VIA USER
     SUB  #10,(SP)     :MOVE SP BACK TO NO ERROR
     NOP

:REPORT ERROR IF RMBA NOT RESET
5$:  CLR  $GDDAT        :VERIFY RMBA IS ZERO
     MOV  RMBAI,$BDDAT
     BEQ  7$           :BRANCH IF ZERO
     ADD  #4,(SP)       :MOVE SP TO USER'S ERROR CALL
     MOVB #127,@(SP)   :WRITE ERROR NUMBER IN CALL
     SUB  #2,(SP)       :MOVE SP TO RETURN FOR ERROR
     JSR  PC,@(SP)+    :REPORT ERROR VIA USER
     SUB  #10,(SP)     :MOVE SP BACK TO NO ERROR
     NOP

:REPORT ERROR IF RMCS2 NOT INITIALIZED
7$:  MOV  RMCS2I,$BDDAT :VERIFY RMCS2
     MOV  R1,-(SP)      :PUSH R1 ON STACK
     CLR  -(SP)         :EXPECT IR & UNIT NUMBER
     MOV  TSTQUE,R1     :R1 = ADDRESS OF TEST QUE
     MOVB (R1),(SP)
     BIS  #IR,(SP)
     MOV  (SP)+,$GDDAT
  
```

052552				
052552	062716	000004		
052556	105076	000000		
052562	162716	000004		
052566	013737	001336	001142	
052574	042737	100000	001142	
052602	012737	004200	001140	
052610	023737	001140	001142	
052616	001413			
052620	062716	000004		
052624	112776	000126	000000	
052632	162716	000002		
052636	004736			
052640	162716	000010		
052644	000240			
052646	005037	001140		
052652	013737	001342	001142	
052660	001413			
052662	062716	000004		
052666	112776	000127	000000	
052674	162716	000002		
052700	004736			
052702	162716	000010		
052706	000240			
052710	013737	001346	001142	
052716	010146			
052720	005046			
052722	013701	001466		
052726	111116			
052730	052716	000100		
052734	012637	001140		

```

58 052740 012601          MOV      (SP)+,R1          ;;POP STACK INTO R1
59 052742 023737 001140 001142  CMP      $GDDAT,$BDDAT    ;;COMPARE EXPECTED & RECEIVED
60 052750 001413          BEQ      9$              ;;BRANCH IF EQUAL
61 052752 062716 000004          ADD      #4,(SP)          ;;MOVE SP TO USER'S ERROR CALL
62 052756 112776 000130 000000  MOVB    #130,@(SP)        ;;WRITE ERROR NUMBER IN CALL
63 052764 162716 000002          SUB      #2,(SP)          ;;MOVE SP TO RETURN FOR ERROR
64 052770 004736          JSR     PC,@(SP)+         ;;REPORT ERROR VIA USER
65 052772 162716 000010          SUB      #10,(SP)        ;;MOVE SP BACK TO NO ERROR
66 052776 000240          NOP
67                                     ;REPORT ERROR IF RMER1 NOT RESET-IGNORE UNS
68 053000 005037 001140 9$: CLR      $GDDAT          ;;VERIFY RMER1
69 053004 013737 001352 001142  MOV      RMER1I,$BDDAT
70 053012 042737 040000 001142  BIC     #UNS,$BDDAT      ;;IGNORE UNSAFE
71 053020 001413          BEQ     13$             ;;BRANCH IF ZERO
72 053022 062716 000004          ADD      #4,(SP)          ;;MOVE SP TO USER'S ERROR CALL
73 053026 112776 000131 000000  MOVB    #131,@(SP)        ;;WRITE ERROR NUMBER IN CALL
74 053034 162716 000002          SUB      #2,(SP)          ;;MOVE SP TO RETURN FOR ERROR
75 053040 004736          JSR     PC,@(SP)+         ;;REPORT ERROR VIA USER
76 053042 162716 000010          SUB      #10,(SP)        ;;MOVE SP BACK TO NO ERROR
77 053046 000240          NOP
78                                     ;REPORT ERROR IF RMMR1 NOT INITIALIZED-IGNORE WC,LS,LST
79 053050 013737 001362 001142 13$: MOV      RMMR1I,$BDDAT    ;;VERIFY RMMR
80 053056 042737 000046 001142  BIC     #WC!LS!LST,$BDDAT ;;IGNORE WORD CLOCK, SCT, TRK
81 053064 012737 000010 001140  MOV      #MWD,$GDDAT      ;;EXPECT WRITE DATA BIT
82 053072 023737 001140 001142  CMP      $GDDAT,$BDDAT    ;;COMPARE EXPECTED AND RECEIVED
83 053100 001413          BEQ     17$             ;;BRANCH IF 0
84 053102 062716 000004          ADD      #4,(SP)          ;;MOVE SP TO USER'S ERROR CALL
85 053106 112776 000133 000000  MOVB    #133,@(SP)        ;;WRITE ERROR NUMBER IN CALL
86 053114 162716 000002          SUB      #2,(SP)          ;;MOVE SP TO RETURN FOR ERROR
87 053120 004736          JSR     PC,@(SP)+         ;;REPORT ERROR VIA USER
88 053122 162716 000010          SUB      #10,(SP)        ;;MOVE SP BACK TO NO ERROR
89 053126 000240          NOP
90                                     ;REPORT AN ERROR IF RMEC2 IS NOT RESET
91 053130 005037 001140 17$: CLR      $GDDAT          ;;EXPECT ZEROS
92 053134 013737 001404 001142  MOV      RMEC2I,$BDDAT    ;;VERIFY RMEC2=0
93 053142 001413          BEQ     19$             ;;BRANCH IF 0
94 053144 062716 000004          ADD      #4,(SP)          ;;MOVE SP TO USER'S ERROR CALL
95 053150 112776 000135 000000  MOVB    #135,@(SP)        ;;WRITE ERROR NUMBER IN CALL
96 053156 162716 000002          SUB      #2,(SP)          ;;MOVE SP TO RETURN FOR ERROR
97 053162 004736          JSR     PC,@(SP)+         ;;REPORT ERROR VIA USER
98 053164 162716 000010          SUB      #10,(SP)        ;;MOVE SP BACK TO NO ERROR
99 053170 000240          NOP
100                                     ;REPORT ERROR IF RMMR2 NOT INITIALIZED-IGNORE RQA,RQB
101 053172 013737 001376 001142 19$: MOV      RMMR2I,$BDDAT    ;;VERIFY RMMR2
102 053200 042737 140000 001142  BIC     #RQA!RQB,$BDDAT
103 053206 012737 011777 001140  MOV      #TST!1777,$GDDAT ;;EXPECT TEST BIT ON
104 053214 023737 001140 001142  CMP      $GDDAT,$BDDAT
105 053222 001413          BEQ     21$             ;;BRANCH IF 0
106 053224 062716 000004          ADD      #4,(SP)          ;;MOVE SP TO USER'S ERROR CALL
107 053230 112776 000136 000000  MOVB    #136,@(SP)        ;;WRITE ERROR NUMBER IN CALL
108 053236 162716 000002          SUB      #2,(SP)          ;;MOVE SP TO RETURN FOR ERROR
109 053242 004736          JSR     PC,@(SP)+         ;;REPORT ERROR VIA USER
110 053244 162716 000010          SUB      #10,(SP)        ;;MOVE SP BACK TO NO ERROR
111 053250 000240          NOP
112                                     ;REPORT ERROR IF RMER2 NOT RESET-IGNORE SKI,DVC
113 053252 005037 001140 21$: CLR      $GDDAT          ;;EXPECT ALL ZEROS
114 053256 013737 001400 001142  MOV      RMER2I,$BDDAT    ;;VERIFY RMER2

```

```

115 053264 042737 040200 001142      BIC      #SKI!DVC,$BDDAT ;IGNORE DEVICE ERRORS
116 053272 001413                    BEQ      215$           ;BRANCH IF OTHER BITS 0
117 053274 062716 000004                    ADD      #4,(SP)       ;MOVE SP TO USER'S ERROR CALL
118 053300 112776 000174 000000      MOVVB   #174,@(SP)    ;WRITE ERROR NUMBER IN CALL
119 053306 162716 000002                    SUB      #2,(SP)      ;MOVE SP TO RETURN FOR ERROR
120 053312 004736                    JSR      PC,@(SP)+    ;REPORT ERKOR VIA USER
121 053314 162716 000010      SUB      #10,(SP)    ;MOVE SP BACK TO NO ERROR
122 053320 000240      NOP
123                                     ;REPORT ERROR IF RMD5 NOT INITIALIZED
124 053322 013737 001350 001142      215$: MOV      RMD5I,$BDDAT ;TEST DRIVE STATUS REGISTER
125 053330 042737 077177 001142      BIC      #^C<DRY!DPR>,$BDDAT
126 053336 012737 000600 001140      MOV      #DPR.DRY,$GDDAT ;EXPECTED DRIVE STATUS
127 053344 023737 001140 001142      CMP      $GDDAT,$BDDAT ;COMPARE EXPECTED & RECEIVED
128 053352 001413                    BEQ      22$           ;BRANCH IF EQUAL
129 053354 062716 000004                    ADD      #4,(SP)       ;MOVE SP TO USER'S ERROR CALL
130 053360 112776 000134 000000      MOVVB   #134,@(SP)    ;WRITE ERROR NUMBER
131 053366 162716 000002                    SUB      #2,(SP)      ;MOVE SP TO RETURN FOR ERROR
132 053372 004736                    JSR      PC,@(SP)+    ;REPORT ERROR TO USER
133 053374 162716 000010      SUB      #10,(SP)    ;MOVE SP BACK TO NO ERROR
134 053400 000240      NOP
135 053402 062716 000004      22$: ADD      #4,(SP)    ;MOVE SP TO ERROR CALL
136 053406 105776 000000      TSTB   @(SP)         ;WAS AN ERROE DETECTED??
137 053412 001403                    BEQ      23$           ;NO!
138 053414 062716 000004                    ADD      #4,(SP)       ;YES - MOVE TO ERROR RETURN
139 053420 000402                    BR       24$
140 053422 162716 000004      23$: SUB      #4,(SP)    ;MOVE SP TO NO ERROR RETURN
141 053426 000240      24$: NOP
142 053430 000207      RTS      PC
  
```

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57

.SBTTL PACK ACKNOWLEDGE STATUS CHECK

: THIS SUBROUTINE CHECKS THE RESULTS OF A PACK ACKNOWLEDGE
 : COMMAND USING THE STATUS STORED IN THE GET BUFFER. ERRORS ARE
 : REPORTED TO THE USER VIA THE USER'S ERROR CALL.

```

:CALL:
:(1) JSR PC,ACKSTS
      BR   ???
      NOP
      ERROR
      JSR PC,@(SP)+
      ???
  
```

RETURN HERE IF NO ERROR
 RETURN HERE TO REPORT AN ERROR
 ERROR NUMBER DEFINED BY SUB
 GO BACK TO SUB FOR MORE ERROR CHECKS
 RETURN HERE IF NO MORE ERRORS

ACKSTS:

```

: CLEAR USER'S ERROR CALL
  ADD #4,(SP)      ;MOVE SP TO ERROR CALL
  CLRB @ (SP)      ;CLEAR LOW ORDER BYTE
  SUB #4,(SP)      ;MOVE SP BACK

: REPORT AN ERROR IF 'VV' IS 0
  BIT #VV,RMDSI    ;IS VOLUME VALID SET??
  BNE 1$           ;YES!!
  MOV RMDSI,$GDDAT ;EXPECTED STATUS
  BIS #VV,$GDDAT
  MOV RMDSI,$BDDAT ;RECEIVED STATUS
  ADD #4,(SP)      ;MOVE SP TO ERROR CALL
  MOVB #155,@(SP)  ;WRITE NUMBER IN ERROR CALL
  SUB #2,(SP)      ;MOVE SP TO RETURN FOR ERROR
  JSR PC,@(SP)+    ;REPORT THE ERROR
  SUB #10,(SP)     ;MOVE SP BACK TO BRANCH
  NOP
  
```

1\$:

```

: REPORT AN ERROR IF 'MOL' IS 0
  BIT #MOL,RMDSI   ;IS MOL SET??
  BNE 2$           ;YES!!
  MOV RMDSI,$GDDAT ;EXPECTED STATUS
  BIS #MOL,$GDDAT
  MOV RMDSI,$BDDAT ;RECEIVED STATUS
  ADD #4,(SP)      ;MOVE SP TO ERROR CALL
  MOVB #41,@(SP)   ;WRITE NUMBER OF ERROR IN CALL
  SUB #2,(SP)      ;MOVE SP TO RETURN FOR ERROR
  JSR PC,@(SP)+    ;REPORT TH ERROR
  SUB #10,(SP)     ;MOVE SP TO BRANCH
  NOP
  
```

2\$:

```

: SEE IF 'UNS','OPI','RMR','ILR', OR 'ILF' IS SET
  BIT #UNS,OPI.RMR.ILR.ILF,RMER1I
  BEQ 7$
  
```

```

: REPORT AN ERROR IF 'UNS' IS SET
  BIT #UNS,RMER1I ;WAS UNS SET??
  BEQ 3$          ;NO.
  MOV RMER1I,$BDDAT ;RECEIVED STATUS
  
```

053432

18	053432	062716	000004	
19	053436	105076	000000	
20	053442	162716	000004	
23	053446	032737	000100	001350
24	053454	001024		
25	053456	013737	001350	001140
26	053464	052737	000100	001140
27	053472	013737	001350	001142
28	053500	062716	000004	
29	053504	112776	000155	000000
30	053512	162716	000002	
31	053516	004736		
32	053520	162716	000010	
33	053524	000240		
34	053526			
37	053526	032737	010000	001350
38	053534	001024		
39	053536	013737	001350	001140
40	053544	052737	010000	001140
41	053552	013737	001350	001142
42	053560	062716	000004	
43	053564	112776	000041	000000
44	053572	162716	000002	
45	053576	004736		
46	053600	162716	000010	
47	053604	000240		
48	053606			
51	053606	032737	060007	001352
52	053614	001570		
55	053616	032737	040000	001352
56	053624	001424		
57	053626	013737	001352	001142

58	053634	013737	001352	001140	MOV	RMER11,\$GDDAT	:EXPECTED STATUS
59	053642	042737	040000	001140	BIC	#UNS,\$GDDAT	
60	053650	062716	000004		ADD	#4,(SP)	:MOVE SP TO ERROR CALL
61	053654	112776	000042	000000	MOVB	#42,@(SP)	:WRITE NUMBER OF ERROR IN CALL
62	053662	162716	000002		SUB	#2,(SP)	:MOVE SP TO RETURN FOR ERROR
63	053666	004736			JSR	PC,@(SP)+	:REPORT THE ERROR VIA USER
64	053670	162716	000010		SUB	#10,(SP)	:MOVE SP TO NO ERROR RETURN
65	053674	000240			NOP		
66	053676				3\$:		
67							
68					:REPORT	ANY OPI ERROR	
69	053676	032737	020000	001352	BIT	#OPI,RMER11	:WAS OPI SET ??
70	053704	001424			BEQ	4\$:NO..
71	053706	013737	001352	001142	MOV	RMER11,\$BDDAT	:RECEIVED STATUS
72	053714	013737	001352	001140	MOV	RMER11,\$GDDAT	:EXPECTED STATUS
73	053722	042737	020000	001140	BIC	#OPI,\$GDDAT	
74	053730	062716	000004		ADD	#4,(SP)	:MOVE SP TO ERROR CALL
75	053734	112776	000043	000000	MOVB	#43,@(SP)	:WRITE NUMBER OF ERROR IN CALL
76	053742	162716	000002		SUB	#2,(SP)	:MOVE SP TO RETURN FOR ERROR
77	053746	004736			JSR	PC,@(SP)+	:REPORT THE ERROR VIA USER
78	053750	162716	000010		SUB	#10,(SP)	:MOVE SP TO NO ERROR RETURN
79	053754	000240			NOP		
80	053756				4\$:		
81							
82					:REPORT	ANY RMR ERROR	
83	053756	032737	000004	001352	BIT	#RMR,RMER11	:WAS RMR SET??
84	053764	001424			BEQ	5\$:NO!
85	053766	013737	001352	001142	MOV	RMER11,\$BDDAT	:RECEIVED STATUS
86	053774	013737	001352	001140	MOV	RMER11,\$GDDAT	:EXPECTED STATUS
87	054002	042737	000004	001140	BIC	#RMR,\$GDDAT	
88	054010	062716	000004		ADD	#4,(SP)	:MOVE SP TO ERROR CALL
89	054014	112776	000044	000000	MOVB	#44,@(SP)	:WRITE NUMBER OF ERROR IN CALL
90	054022	162716	000002		SUB	#2,(SP)	:MOVE SP TO RETURN FOR ERROR
91	054026	004736			JSR	PC,@(SP)+	:REPORT THE ERROR VIA USER
92	054030	162716	000010		SUB	#10,(SP)	:MOVE SP TO NO ERROR RETURN
93	054034	000240			NOP		
94	054036				5\$:		
95							
96					:REPORT	ANY ILR ERROR	
97	054036	032737	000002	001352	BIT	#ILR,RMER11	:WAS ILR SET??
98	054044	001424			BEQ	6\$:NO!!
99	054046	013737	001352	001142	MOV	RMER11,\$BDDAT	:RECEIVED STATUS
100	054054	013737	001352	001140	MOV	RMER11,\$GDDAT	:EXPECTED STATUS
101	054062	042737	000002	001140	BIC	#ILR,\$GDDAT	
102	054070	062716	000004		ADD	#4,(SP)	:MOVE SP TO ERROR CALL
103	054074	112776	000045	000000	MOVB	#45,@(SP)	:WRITE NUMBER OF ERROR IN CALL
104	054102	162716	000002		SUB	#2,(SP)	:MOVE SP TO RETURN FOR ERROR
105	054106	004736			JSR	PC,@(SP)+	:REPORT THE ERROR VIA USER
106	054110	162716	000010		SUB	#10,(SP)	:MOVE SP TO NO ERROR RETURN
107	054114	000240			NOP		
108	054116				6\$:		
109							
110					:REPORT	ANY ILF ERROR	
111	054116	032737	000001	001352	BIT	#ILF,RMER11	:WAS ILF SET??
112	054124	001424			BEQ	7\$:NO..
113	054126	013737	001352	001142	MOV	RMER11,\$BDDAT	:RECEIVED STATUS
114	054134	013737	001352	001140	MOV	RMER11,\$GDDAT	:EXPECTED STATUS

```
115 054142 042737 000001 001140      BIC      #ILF,$GDDAT
116 054150 062716 000004      ADD      #4,(SP)      ;MOVE SP TO ERROR CALL
117 054154 112776 000046 000000      MOVB    #46,@(SP)   ;WRITE NUMBER OF ERROR IN CALL
118 054162 162716 000002      SUB      #2,(SP)     ;MOVE SP TO RETURN FOR ERROR
119 054166 004736      JSR      PC,@(SP)+  ;REPORT THE ERROR VIA USER
120 054170 162716 000010      SUB      #10,(SP)   ;MOVE SP TO NO ERROR RETURN
121 054174 000240      NOP
122 054176
123
124      ;AUGMENT RETURN ADDRESS IF ERROR WAS FOUND
125 054176 062716 000004      ADD      #4,(SP)     ;MOVE SP TO ERROR CALL
126 054202 105776 000000      TSTB    @(SP)       ;WAS ERROR FOUND??
127 054206 001403      BEQ     8$          ;NO!
128 054210 062716 000004      ADD      #4,(SP)     ;YES - MOVE TO ERROR RETURN
129 054214 000402      BR      9$
130 054216 162716 000004      SUB      #4,(SP)     ;MOVE SP TO NO ERROR RETURN
131 054222 000240      NOP
132 054224 000207      RTS      PC
```

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57

```

.SBTTL RECALIBRATE STATUS CHECK SUBROUTINE
;THIS SUBROUTINE CHECKS THE RESULTS OF A RECALIBRATE OPERATION
;USING THE STATUS STORED IN THE GET BUFFER.

;CALL:
:(1) JSR PC,RCLSTS ;CALL SUBROUTINE
      BR ??? ;RETURN HERE IF NO ERROR
      NOP ;RETURN HERE TO REPORT AN ERROR
      ERROR ;ERROR NUMBER DEFINED BY SUB
      JSR PC,@(SP)+ ;GO BACK TO SUB FOR MORE ERROR CHECKS
      ??? ;RETURN HERE IF NO MORE ERRORS

RCLSTS:
;CLEAR USER'S ERROR NUMBER
ADD #4,(SP)
CLRB @(SP) ;CLEAR USER'S ERROR CALL
SUB #4,(SP) ;MOVE SP BACK TO BRANCH

;SEE IF 'PAR' OR 'ILF' OR 'OPI' OR 'IAE' IS SET
BIT #OPI.PAR.ILF.IAE,RMER1I
BEQ 4$ ;NONE ARE SET - GO TO NEXT CHECK

;REPORT ANY MASSBUS CONTROL BUS PARITY ERROR, I.E.,
;'PAR' 1 AND 'DPE' - 0
BIT #PAR,RMER1I ;WAS 'PAR' SET??
BEQ 1$ ;NO!!
BIT #DPE,RMER2I ;WAS 'DPE' SET??
BNE 1$ ;YES - NOT A REGISTER ERROR
MOV RMER1I,$GDDAT ;EXPECTED STATUS
BIC #PAR,$GDDAT
MOV RMER1I,$BDDAT ;RECEIVED STATUS
ADD #4,(SP) ;MOVE SP TO USER'S ERROR CALL
MOVB #50,@(SP) ;WRITE ERROR NUMBER IN CALL
SUB #2,(SP) ;MOVE SP TO RETURN FOR ERROR
JSR PC,@(SP)+ ;GO REPORT ERROR
SUB #10,(SP) ;MOVE SP BACK TO BRANCH
NOP

1$:
;REPORT ANY 'ILF' ERROR
BIT #ILF,RMER1I ;WAS 'ILF' SET??
BEQ 2$ ;NO!!
MOV RMER1I,$GDDAT ;EXPECTED STATUS
BIC #ILF,$GDDAT
MOV RMER1I,$BDDAT ;RECEIVED STATUS
ADD #4,(SP) ;MOVE SP TO USER'S ERROR CALL
MOVB #71,@(SP) ;WRITE ERROR NUMBER IN CALL
SUB #2,(SP) ;MOVE SP TO RETURN FOR ERROR
JSR PC,@(SP)+ ;REPORT ERROR VIA USER
SUB #10,(SP) ;MOVE SP BACK TO BRANCH
NOP

2$:

```

054226	062716	000004	
054232	105076	000000	
054236	162716	000004	
054242	032737	022011	001352
054250	001553		
054252	032737	000010	001352
054260	001430		
054262	032737	000010	001400
054270	001024		
054272	013737	001352	001140
054300	042737	000010	001140
054306	013737	001352	001142
054314	062716	000004	
054320	112776	000050	000000
054326	162716	000002	
054332	004736		
054334	162716	000010	
054340	000240		
054342			
054342	032737	000001	001352
054350	001424		
054352	013737	001352	001140
054360	042737	000001	001140
054366	013737	001352	001142
054374	062716	000004	
054400	112776	000071	000000
054406	162716	000002	
054412	004736		
054414	162716	000010	
054420	000240		
054422			


```

58      ;REPORT ANY 'OPI' ERROR AS
59      :
60      : . OPI DUE TO 'MOL' 0
61      : . OPI BECAUSE ON CYLINDER LATCH DIDN'T RESET
62      BIT      #OPI,RMER1I      ;WAS OPI SET??
63      BEQ      31$              ;NO!!
64      MOV      RMER1I,$GDDAT    ;EXPECTED STATUS
65      BIC      #OPI,$GDDAT
66      MOV      RMER1I,$BDDAT    ;RECEIVED STATUS
67      ADD      #4,(SP)          ;MOVE SP TO USER'S ERROR CALL
68      MOV      #72,@(SP)        ;WRITE ERROR NUMBER IN USER'S CALL
69      BIT      #MOL,RMDSI      ;WAS 'MOL' = 0??
70      BEQ      3$              ;YES!!
71      MOV      #73,@(SP)        ;NO - CHANGE ERROR NUMBER
72      SUB      #2,(SP)          ;MOVE SP TO RETURN FOR ERROR
73      JSR      PC,@(SP)+        ;REPORT ERROR VIA USER
74      SUB      #10,(SP)         ;MOVE SP BACK TO BRANCH
75      NOP
76      31$:
77      :REPORT AN ERROR IF 'IAE' IS SET
78      BIT      #IAE,RMER1I      ;IS 'IAE' SET??
79      BEQ      4$              ;NO!!
80      MOV      RMER1I,$GDDAT    ;EXPECTED STATUS
81      BIC      #IAE,$GDDAT
82      MOV      RMER1I,$BDDAT    ;RECEIVED STATUS
83      ADD      #4,(SP)          ;MOVE SP TO ERROR CALL
84      MOV      #70,@(SP)        ;WRITE ERROR NUMBER IN USER'S CALL
85      SUB      #2,(SP)          ;MOVE SP TO RETURN FOR ERROR
86      JSR      PC,@(SP)+        ;REPORT ERROR
87      SUB      #10,(SP)         ;MOVE SP BACK TO NO ERROR RETURN
88      NOP
89      4$:
90      :SEE IF 'SKI' OR 'IVC' OR 'DVC' IS SET
91      BIT      #SKI!IVC!DVC,RMER2I
92      BEQ      8$              ;NONE OF THE BITS ARE SET
93
94
95
96      :REPORT ANY 'IVC' ERROR AS
97      : . IVC WITH VV = 0
98      : . ERRONEOUS IVC ERROR
99      BIT      #IVC,RMER2I      ;WAS IVC SET??
100     BEQ      6$              ;NO!!
101     MOV      RMER2I,$GDDAT    ;EXPECTED STATUS
102     BIC      #IVC,$GDDAT
103     MOV      RMER2I,$BDDAT    ;RECEIVED STATUS
104     ADD      #4,(SP)          ;MOVE SP TO USER'S ERROR CALL
105     MOV      #74,@(SP)        ;WRITE ERROR NUMBER IN CALL
106     BIT      #VV,RMDSI        ;WAS VV = 0??
107     BEQ      5$              ;YES!!
108     MOV      #75,@(SP)        ;NO - CHANGE ERROR NUMBER
109     SUB      #2,(SP)          ;MOVE SP TO RETURN FOR ERROR
110     JSR      PC,@(SP)+        ;REPORT ERROR VIA USER
111     SUB      #10,(SP)         ;MOVE SP BACK TO BRANCH
112     NOP
113     5$:
114     6$:
    
```

```

115                                     :REPORT A
116 054706 032737 040000 001400      BI          R2I          :WAS SKI SET??
117 054714 001424                                     RE          :NO..
118 054716 013737 001400 001140      MOV          RM, $GDDAT :EXPECTED STATUS
119 054724 042737 040000 001140      BIC          #SK, $DDAT
120 054732 013737 001400 001142      MOV          RMER, $BDDAT :RECEIVED STATUS
121 054740 0627 6 000004               ADD          #, (SP)      :MOVE SP TO USER'S ERROR CALL
122 054744 112776 000076 000000      MOVVB       #76, @ (SP)  :WRITE ERROR NUMBER
123 054752 162716 000002               SUB          #2, (SP)    :MOVE SP TO RETURN FOR ERROR
124 054756 004736                       JSR          PC, @ (SP)+  :REPORT ERROR VIA USER
125 054760 162716 000010               SUB          #10, (SP)   :MOVE SP TO BRANCH
126 054764 000240                       NOP
127 054766
128
129                                     :REPORT ANY 'DVC' ERROR
130 054766 032737 000200 001400      BIT          #DVC, RMER2I :WAS 'DVC' SET??
131 054774 001424                       BEQ          8$          :NO!!
132 054776 013737 001400 001140      MOV          RMER2I, $GDDAT :EXPECTED STATUS
133 055004 042737 000200 001140      BIC          #DVC, $GDDAT
134 055012 013737 001400 001142      MOV          RMER2I, $BDDAT :RECEIVED STATUS
135 055020 062716 000004               ADD          #4, (SP)    :MOVE SP TO USER'S ERROR CALL
136 055024 112776 000077 000000      MOVVB       #77, @ (SP)  :WRITE ERROR NUMBER
137 055032 162716 000002               SUB          #2, (SP)    :MOVE SP TO RETURN FOR ERROR
138 055036 004736                       JSR          PC, @ (SP)+  :REPORT ERROR VIA USER
139 055040 162716 000010               SUB          #10, (SP)   :MOVE SP TO USER'S BRANCH
140 055044 000240                       NOP
141 055046
142
143                                     :SEE IF 'PIP' AND 'OM' ARE 0, AND 'ATA', 'MOL' AND 'VV' ARE 1
144 055046 013746 001350               MOV          RMDSI, -(SP) :PUT RMDS ON STACK
145 055052 042716 047676               BIC          #^C<PIP!MOL!VV!OM!ATA>, (SP)
146 055056 022726 110100               CMP          #ATA!MOL!VV, (SP)+
147 055062 00100?                       BNE          85$
148 055064 00013? 055500               JMP          13$
149 055070
150
151                                     :REPORT AN ERROR IF MOL = 0 AND OPI = 0, I.E., MEDIUM WENT OFF
152                                     :LINE AFTER RECALIBRATE WAS INITIATED
153 055070 032737 010000 001350      BIT          #MOL, RMDSI  :DID MOL DROP??
154 055076 001030                       BNE          9$          :NO!!
155 055100 032737 020000 001352      BIT          #OPI, RMER1I :WAS OPI ERROR REPORTED??
156 055106 001024                       BNE          9$          :YES - DON'T REPORT MOL 0
157 055110 013737 001350 001140      MOV          RMDSI, $GDDAT :EXPECTED STATUS
158 055116 052737 010000 001140      BIS          #MOL, $GDDAT
159 055124 013737 001350 001142      MOV          RMDSI, $BDDAT :RECEIVED STATUS
160 055132 062716 000004               ADD          #4, (SP)    :MOVE SP TO USER'S ERROR CALL
161 055136 112776 000100 000000      MOVVB       #100, @ (SP) :WRITE ERROR NUMBER
162 055144 162716 000002               SUB          #2, (SP)    :MOVE SP TO RETURN FOR ERROR
163 055150 004736                       JSR          PC, @ (SP)+  :REPORT ERROR VIA USER
164 055152 162716 000010               SUB          #10, (SP)   :MOVE SP BACK TO USER'S BRANCH
165 055156 000240                       NOP
166 055160
167
168                                     :REPORT AN ERROR IF 'VV' = 0 AND 'IVC' = 0
169 055160 032737 000100 001350      BIT          #VV, RMDSI   :DID 'VV' DROP??
170 055166 001030                       BNE          10$         :NO!!
171 055170 032737 010000 001400      BIT          #IVC, RMER2I :WAS THERE A IVC ERROR??
    
```

```

172 055176 001024          BNE      10$          :YES - DONT REPORT VV-0
173 055200 013737 001350 001140  MOV      RMDSI,$GDDAT :EXPECTED STATUS
174 055206 013737 001350 001142  MOV      RMDSI,$BDDAT :RECEIVED STATUS
175 055214 052737 000100 001*40  BIS      #VV,$GDDAT
176 055222 062716 000004          ADD      #4,(SP)      :MOVE SP TO USER'S ERROR CALL
177 055226 112776 000101 000000  MOVB    #101,@(SP)   :WRITE ERROR NUMBER IN CALL
178 055234 162716 000002          SUB      #2,(SP)      :MOVE SP TO RETURN FOR ERROR
179 055240 004736          JSR     PC,@(SP)+
180 055242 162716 000010          SUB      #10,(SP)     :MOVE SP BACK TO USER'S BRANCH
181 055246 000240          NOP
182 055250          .0$:
183
184          :REPORT AN ERROR IF ATA IS NOT SET
185 055250 032737 100000 001350  BIT      #ATA,RMDSI   :WAS ATA SET DURING RECALIBRATE??
186 055256 001024          BNE      11$          :YES!!
187 055260 013737 001350 001140  MOV      RMDSI,$GDDAT :EXPECTED STATUS
188 055266 052737 100000 001140  BIS      #ATA,$GDDAT
189 055274 013737 001350 001142  MOV      RMDSI,$BDDAT :RECEIVED STATUS
190 055302 062716 000004          ADD      #4,(SP)      :MOVE SP TO USER'S ERROR CALL
191 055306 112776 000102 000000  MOVB    #102,@(SP)   :WRITE ERROR NUMBER IN CALL
192 055314 162716 000002          SUB      #2,(SP)      :MOVE SP TO USER'S BRANCH
193 055320 004736          JSR     PC,@(SP)+
194 055322 162716 000010          SUB      #10,(SP)
195 055326 000240          NOP
196
197 055330          11$:
198
199          :REPORT AN ERROR IF 'OM' IS NOT ZERO BECAUSE RECALIBRATE SHOULD
200          :ALWAYS CLEAR OFFSET MODE
201 055330 032737 000001 001350  BIT      #OM,RMDSI   :WAS 'OM' RESET??
202 055336 001424          BEQ     12$          :YES!!
203 055340 013737 001350 001140  MOV      RMDSI,$GDDAT :EXPECTED STATUS
204 055346 042737 000001 001140  BIC      #OM,$GDDAT
205 055354 013737 001350 001142  MOV      RMDSI,$BDDAT :RECEIVED STATUS
206 055362 062716 000004          ADD      #4,(SP)      :MOVE SP TO USER'S ERROR CALL
207 055366 112776 000103 000000  MOVB    #103,@(SP)   :WRITE ERROR NUMBER
208 055374 162716 000002          SUB      #2,(SP)      :MOVE SP TO RETURN FOR ERROR
209 055400 004736          JSR     PC,@(SP)+   :REPORT ERROR VIA USER
210 055402 162716 000010          SUB      #10,(SP)     :MOVE SP TO USER'S BRANCH
211 055406 000240          NOP
212 055410          12$:
213
214          :REPORT AN ERROR IF 'PIP' IS STIL ON, I.E., DRIVE NOT ON
215          :CYLINDER
216 055410 032737 020000 001350  BIT      #PIP,RMDSI  :IS DRIVE OFF CYLINDER??
217 055416 001430          BEQ     13$          :NO!!
218 055420 032737 040000 001400  BIT      #SKI,RMER2I :WAS 'SKI' DETECTED??
219 055426 001024          BNE      13$          :YES-DONT REPORT 'PIP'
220 055430 013737 001350 001140  MOV      RMDSI,$GDDAT :EXPECTED STATUS
221 055436 042737 020000 001140  BIC      #PIP,$GDDAT
222 055444 013737 001350 001142  MOV      RMDSI,$BDDAT :RECEIVED STATUS
223 055452 062716 000004          ADD      #4,(SP)      :MOVE SP TO USER'S ERROR CALL
224 055456 112776 000104 000000  MOVB    #104,@(SP)   :WRITE ERROR NUMBER
225 055464 162716 000002          SUB      #2,(SP)      :MOVE SP TO RETURN FOR ERROR
226 055470 004736          JSR     PC,@(SP)+
227 055472 162716 000010          SUB      #10,(SP)     :MOVE SP BACK TO USER'S BRANCH
228 055476 000240          NOP
    
```

```

229 055500          13$:
230
231                ;SEE IF 'ILR' OR 'RMR' OR 'UNS' IS SET
232 055500 032737 040006 001352 BIT #ILR,RMR,UNS,RMER1I
233 055506 001514 BEQ 16$
234
235                ;REPORT AN ERROR IF 'ILR' IS SET
236 055510 032737 000002 001352 BIT #ILR,RMER1I ;WAS ILR SET DURING RECALIBRATE??
237 055516 001424 BEQ 14$ ;NO!!
238 055520 013737 001352 001140 MOV RMER1I,$GDDAT ;EXPECTED STATUS
239 055526 042737 000002 001140 BIC #ILR,$GDDAT
240 055534 013737 001352 001142 MOV RMER1I,$BDDAT ;RECEIVED STATUS
241 055542 062716 000004 ADD #4,(SP) ;MOVE SP TO USER'S ERROR CALL
242 055546 112776 000105 000000 MOVSB #105,@(SP) ;WRITE ERROR NUMBER IN CALL
243 055554 162716 000002 SUB #2,(SP) ;MOVE SP TO RETURN FOR ERROR
244 055560 004736 JSR PC,@(SP)+
245 055562 162716 000010 SUB #10,(SP) ;MOVE SP TO USER'S BRANCH
246 055566 000240 NOP
247 055570          14$:
248
249                ;REPORT AN ERROR IF 'RMR' IS SET
250 055570 032737 000004 001352 BIT #RMR,RMER1I ;WAS RMR SET??
251 055576 001424 BEQ 15$ ;NO!!
252 055600 013737 001352 001140 MOV RMER1I,$GDDAT ;EXPECTED STATUS
253 055606 042737 000004 001140 BIC #RMR,$GDDAT
254 055614 013737 001352 001142 MOV RMER1I,$BDDAT ;RECEIVED STATUS
255 055622 062716 000004 ADD #4,(SP) ;MOVE SP TO USER'S ERROR CALL
256 055626 112776 000106 000000 MOVSB #106,@(SP) ;WRITE ERROR NUMBER IN USER'S CALL
257 055634 162716 000002 SUB #2,(SP) ;MOVE SP TO RETURN FOR ERROR
258 055640 004736 JSR PC,@(SP)+ ;REPORT ERROR VIA USER
259 055642 162716 000010 SUB #10,(SP) ;MOVE SP TO USER'S BRANCH
260 055646 000240 NOP
261 055650          15$:
262
263                ;REPORT AN ERROR IF 'UNS' IS SET AND 'DVC' IS 0
264 055650 032737 040000 001352 BIT #UNS,RMER1I ;WAS UNSAFE ON??
265 055656 001430 BEQ 16$ ;NO!!
266 055660 032737 000200 001400 BIT #DVC,RMER2I ;WAS THERE A DEVICE CHECK??
267 055666 001024 BNE 16$ ;YES - DON'T REPORT UNSAFE
268 055670 013737 001352 001140 MOV RMER1I,$GDDAT ;EXPECTED STATUS
269 055676 042737 040000 001140 BIC #UNS,$GDDAT
270 055704 013737 001352 001142 MOV RMER1I,$BDDAT ;RECEIVED STATUS
271 055712 062716 000004 ADD #4,(SP) ;MOVE SP TO USER'S ERROR CALL
272 055716 112776 000107 000000 MOVSB #107,@(SP) ;WRITE ERROR NUMBER
273 055724 162716 000002 SUB #2,(SP) ;MOVE SP TO RETURN FOR ERROR
274 055730 004736 JSR PC,@(SP)+ ;REPORT ERROR VIA USER
275 055732 162716 000010 SUB #10,(SP) ;MOVE SP BACK TO USER'S BRANCH
276 055736 000240 NOP
277 055740          16$:
278
279                ;AUGMENT THE RETURN ADDRESS IF ANY ERROR WAS DETECTED
280 055740 062716 000004 ADD #4,(SP) ;MOVE SP TO USER'S ERROR CALL
281 055744 105776 000000 TSTB @(SP) ;WAS AN ERROR REPORTED??
282 055750 001403 BEQ 17$ ;NO!!
283 055752 062716 000004 ADD #4,(SP) ;YES - AUGMENT SP RETURN
284 055756 000402 BR 18$
285 055760 162716 000004 ;17$ SUB #4,(SP) ;NO ERROR - RETURN SP TO BRANCH

```

286 055764 000240
287 055766 000207

188: NOP
RTS PC

;STATUS CECK IS COMPLETE

```

1          .SBTTL  DRIVE CLEAR STATUS CHECK SUBROUTINE
2
3          :      BR      ???          RETURN HERE IF NO ERROR
4          :      NOP
5          :      ERROR          RETURN HERE TO REPORT AN ERROR
6          :      JSR      PC,@(SP)+    ERROR NUMBER DEFINED BY SUB
7          :      ???          GO BACK TO SUB FOR MORE ERROR CHECKS
8          :      ???          RETURN HERE IF NO MORE ERRORS
9 055770   DRVSTS:
10
11          ;CLEAR USER'S ERROR CALL
12 055770   062716   000004          ADD      #4,(SP)          ;MOVE SP TO ERROR CALL
13 055774   105076   000000          CLRB    @(SP)          ;CLEAR ERROR CALL
14 056000   162716   000004          SUB      #4,(SP)          ;MOVE SP TO USER'S BRANCH
15
16 056004   013737   001336   001142   4$:      ;REPORT ERROR IF RMCS1 NOT INITIALIZED
17 056012   042737   173700   001142          MOV      RMCS1,$BDDAT      ;CHECK RMCS1
18 056020   012737   004010   001140          BIC     #^C<DVA!FNCMSK>,$BDDAT ;CLEAR DONT CARES
19 056026   023737   001140   001142          MOV      #DVA!DRVCLR,$GDDAT ;EXPECT DVA
20 056034   001443          CMP     $GDDAT,$BDDAT      ;COMPARE EXPECTED & RECEIVED
21 056036   062716   000004          BEQ     6$                ;BRANCH IF EQUAL
22 056042   112776   000141   000000          ADD     #4,(SP)          ;MOVE SP TO ERROR CALL
23 056050   162716   000002          MOVB   #141,@(SP)         ;WRITE NUMBER OF ERROR IN CALL
24 056054   004736          SUB     #2,(SP)          ;MOVE SP TO RETURN FOR ERROR
25 056056   162716   000010          JSR     PC,@(SP)+         ;REPORT THE ERROR VIA USER
26 056067   000240          SUB     #10,(SP)         ;MOVE SP TO NO ERROR RETURN
27          NOP
28 056064   013737   001350   001142   5$:      ;REPORT ERROR IF RMD5 NOT INITIALIZED
29 056072   042737   021101   001142          MOV      RMD5,$BDDAT      ;CHECK RMD5
30 056100   012737   010600   001140          BIC     #PGM!OM!VV!PIP,$BDDAT ;CLEAR DONT CARES
31 056106   023737   001140   001142          MOV      #MOL!DPR!DRY,$GDDAT ;EXPECT DRY & DPR
32 056114   001413          CMP     $GDDAT,$BDDAT      ;COMPARE EXPECTED & RECEIVED
33 056116   062716   000004          BEQ     6$                ;BRANCH IF EQUAL
34 056122   112776   000142   000000          ADD     #4,(SP)          ;MOVE SP TO ERROR CALL
35 056130   162716   000002          MOVB   #142,@(SP)         ;WRITE NUMBER OF ERROR IN CALL
36 056134   004736          SUB     #2,(SP)          ;MOVE SP TO RETURN FOR ERROR
37 056136   162716   000010          JSR     PC,@(SP)+         ;REPORT THE ERROR VIA USER
38 056142   000240          SUB     #10,(SP)         ;MOVE SP TO NO ERROR RETURN
39          NOP
40 056144   005037   001140   6$:      ;REPORT ERROR IF RMER1 NOT INITIALIZED
41 056150   013737   001352   001142          CLR     $GDDAT            ;EXPECT 0'S
42 056156   001413          MOV      RMER1,$BDDAT      ;CHECK RMER1
43 056160   062716   000004          BEQ     8$                ;BRANCH IF EQUAL
44 056164   112776   000143   000000          ADD     #4,(SP)          ;MOVE SP TO ERROR CALL
45 056172   162716   000002          MOVB   #143,@(SP)         ;WRITE NUMBER OF ERROR IN CALL
46 056176   004736          SUB     #2,(SP)          ;MOVE SP TO RETURN FOR ERROR
47 056200   162716   000010          JSR     PC,@(SP)+         ;REPORT THE ERROR VIA USER
48 056204   000240          SUB     #10,(SP)         ;MOVE SP TO NO ERROR RETURN
49          NOP
50 056206   013737   001354   001142   8$:      ;REPORT ERROR IF ATA NOT INITIALIZED
51 056214   010146          MOV      RMAS1,$BDDAT      ;CHECK ATTENTION BIT
52 056216   010246          MOV      R1,-(SP)         ;;PUSH R1 ON STACK
53 056220   013701   001466          MOV      R2,-(SP)         ;;PUSH R2 ON STACK
54 056224   116102   000001          MOV     TSTQUE,R1
55 056230   042702   177400          MOVB   1(R1),R2
56 056234   005102          BIC     #^CATNMSK,R2
57 056236   040237   001142          COM     R2
          BIC     R2,$BDDAT
    
```

```

58 056242 012602      MOV      (SP)+,R2      ;;POP STACK INTO R2
59 056244 012601      MOV      (SP)+,R1      ;;POP STACK INTO R1
60 056246 005737 001142  TST      $BDDAT        ;IS ATTENTION CLEARED??
61 056252 001413      BEQ      9$            ;BRANCH IF ATTENTION CLEARED
62 056254 062716 000004  ADD      #4,(SP)        ;MOVE SP TO ERROR CALL
63 056260 112776 000144 000000  MOVB    #144,@(SP)     ;WRITE NUMBER OF ERROR IN CALL
64 056266 162716 000002      SUB      #2,(SP)        ;MOVE SP TO RETURN FOR ERROR
65 056272 004736      JSR     PC,@(SP)+      ;REPORT THE ERROR VIA USER
66 056274 162716 000010  SUB      #10,(SP)     ;MOVE SP TO NO ERROR RETURN
67 056300 000240      NOP
68                                     ;REPORT ERROR IF RMMR1 NOT INITIALIZED
69 056302 013737 001362 001142 9$:      MOV      RMMR1I,$BDDAT ;CHECK RMMR
70 056310 042737 000046 001142  BIC     #WC!LS!LST,$BDDAT ;CLEAR DONT CARES
71 056316 012737 000010 001140  MOV      #MWD,$GDDAT   ;EXPECT WRITE DATA ON
72 056324 023737 001140 001142  CMP     $GDDAT,$BDDAT  ;COMPARE EXPECTED AND RECEIVED
73 056332 001413      BEQ     11$           ;BRANCH IF ZERO
74 056334 062716 000004  ADD      #4,(SP)        ;MOVE SP TO ERROR CALL
75 056340 112776 000145 000000  MOVB    #145,@(SP)     ;WRITE NUMBER OF ERROR IN CALL
76 056346 162716 000002      SUB      #2,(SP)        ;MOVE SP TO RETURN FOR ERROR
77 056352 004736      JSR     PC,@(SP)+      ;REPORT THE ERROR VIA USER
78 056354 162716 000010  SUB      #10,(SP)     ;MOVE SP TO NO ERROR RETURN
79 056360 000240      NOP
80                                     ;REPORT ERROR IF RMMR2 NOT INITIALIZED
81 056362 013737 001376 001142 11$:    MOV      RMMR2I,$BDDAT ;CHECK RMMR2
82 056370 042737 140000 001142  BIC     #RQA!ROB,$BDDAT ;CLEAR RQA, ROQB
83 056376 012737 011777 001140  MOV      #TST!1777,$GDDAT ;EXPECT TEST BIT ON
84 056404 023737 001140 001142  CMP     $GDDAT,$BDDAT  ;COMPARE EXPECTED & RECEIVED
85 056412 001413      BEQ     15$           ;BRANCH IF EQUAL
86 056414 062716 000004  ADD      #4,(SP)        ;MOVE SP TO ERROR CALL
87 056420 112776 000146 000000  MOVB    #146,@(SP)     ;WRITE NUMBER OF ERROR IN CALL
88 056426 162716 000002      SUB      #2,(SP)        ;MOVE SP TO RETURN FOR ERROR
89 056432 004736      JSR     PC,@(SP)+      ;REPORT THE ERROR VIA USER
90 056434 162716 000010  SUB      #10,(SP)     ;MOVE SP TO NO ERROR RETURN
91 056440 000240      NOP
92 056442 005037 001140 15$:    CLR     $GDDAT        ;EXPECT ZEROS
93                                     ;REPORT ERROR IF RMEC2 NOT RESET
94 056446 013737 001404 001142  MOV      RMEC2I,$BDDAT ;CHECK RMEC2
95 056454 001413      BEQ     17$           ;BRANCH IF 0
96 056456 062716 000004  ADD      #4,(SP)        ;MOVE SP TO ERROR CALL
97 056462 112776 000150 000000  MOVB    #150,@(SP)     ;WRITE NUMBER OF ERROR IN CALL
98 056470 162716 000002      SUB      #2,(SP)        ;MOVE SP TO RETURN FOR ERROR
99 056474 004736      JSR     PC,@(SP)+      ;REPORT THE ERROR VIA USER
100 056476 162716 000010  SUB      #10,(SP)     ;MOVE SP TO NO ERROR RETURN
101 056502 000240      NOP
102                                     ;REPORT ERROR IF RMER2 NOT RESET
103 056504 013737 001400 001142 17$:    MOV      RMER2I,$BDDAT ;CHECK RMER2
104 056512 001413      BEQ     18$           ;BRANCH IF NO ERROR
105 056514 062716 000004  ADD      #4,(SP)        ;MOVE SP TO ERROR CALL
106 056520 112776 000147 000000  MOVB    #147,@(SP)     ;WRITE NUMBER OF ERROR IN CALL
107 056526 162716 000002      SUB      #2,(SP)        ;MOVE SP TO RETURN FOR ERROR
108 056532 004736      JSR     PC,@(SP)+      ;REPORT THE ERROR VIA USER
109 056534 162716 000010  SUB      #10,(SP)     ;MOVE SP TO NO ERROR RETURN
110 056540 000240      NOP
111 056542                                     18$:
112
113 056542                                     19$:
114

```

```
115          .AUGMENT RETURN ADDRESS IF ANY ERROR WAS FOUND
116 056542 062716 000004          ADD     #4,(SP)      ;MOVF SP TO ERROR CALL
117 056546 105776 000000          TSTB   @(SP)       ;WAS AN ERROR DETECTED??
118 056552 001403          BEQ     21$         ;NO.
119 056554 062716 000004          ADD     #4,(SP)      ;YES - MOVE SP TO ERROR RETURN
120 056560 000402          BR     23$
121 056562 162716 000004 21$:   SUB     #4,(SP) ;MOVE SP BACK TO NO ERROR RETURN
122 056566 000240          NOP
123 056570 000207          RTS     PC          ;RETURN TO USER
```



```

1      .SBTTL DATA TRANSFER COMMAND STATUS CHECK SUBROUTINE
2
3      ;THIS SUBROUTINE VERIFIES THE RESULTS OF ALL DATA TRANSFER COMMANDS
4      ;USING STATUS STORED IN THE GET BUFFER AND TEST PARAMETERS
5      ;STORED IN THE PUT BUFFER. ERRORS ARE REPORTED BY WRITING
6      ;THE ERROR NUMBER IN THE USERS ERROR CALL.
7
8      ;USER'S SUBROUTINE CALL:
9      ;(1) JSR PC,DTASTS
10     ;(2) BR ?? RETURN HERE IF NO DATA ERRORS
11     ;(3) NOP RETURN HERE TO REPORT AN ERROR
12     ;(4) ERROR SUB WRITES ERROR NUMBER
13     ;(5) JSR PC,@(SP)+ USER RETURNS FOR MORE CHECKS
14     ;(6) ?? SUB RETURNS HERE AFTER ALL
15     ; ERRORS ARE REPORTED
16
17 056572 DTASTS:
18
19     ;CLEAR USER'S ERROR CALL AND ERROR FLAGS
20 056572 062716 0C0004 ADD #4,(SP) ;MOVE SP TO USER'S ERROR
21 056576 105076 000000 CLRB @(SP) ;CLEAR LOW ORDER BYTE OF TRAP
22 056602 162716 000004 SUB #4,(SP) ;RESTORE SP TO NO ERROR
23 056606 005037 062166 CLR 500$ ;CLEAR ERROR FLAGS
24
25     ;REPORT ANY CONTROL BUS PARITY ERROR WHILE READING REMOTE REGISTERS,
26     ;I.E., MCPE = 1
27 056612 032737 020000 001336 BIT #MCPE,RMCS1I ;WAS THERE A PARITY ERROR??
28 056620 001422 BEQ 10$ ;NO!!
29 056622 013737 001336 001140 MOV RMCS1I,$GDDAT ;EXPECTED STATUS
30 056630 042737 020000 001140 BIC #MCPE,$GDDAT
31 056636 013737 001336 001142 MOV RMCS1I,$BDDAT ;RECEIVED STATUS
32 056644 062716 000004 ADD #4,(SP) ;MOVE SP TO USER'S ERROR CALL
33 056650 112776 000013 000000 MOVB #13,@(SP) ;WRITE ERROR NUMBER
34 056656 162716 000002 SUB #2,(SP) ;MOVE SP TO RETURN IF ERROR
35 056662 004736 JSR PC,@(SP)+ ;REPORT ERROR AND RETURN
36 056664 000466 BR 30$
37 056666
38
39     ;REPORT ANY CONTROL BUS PARITY ERROR WHILE WRITTING REMOTE REGISTERS,
40     ;I.E., PAR = 1 AND DPE = 0
41 056666 032737 000010 001352 BIT #PAR,RMER1I ;WAS THERE A PARITY ERROR??
42 056674 001435 BEQ 20$ ;NO!!
43 056676 032737 000010 001400 BIT #DPE,RMER2I ;DATA PARITY ERROR ?
44 056704 001031 BNE 20$ ;YES!!
45 056706 013737 001352 001140 MOV RMER1I,$GDDAT ;EXPECTED STATUS
46 056714 042737 000010 001140 BIC #PAR,$GDDAT
47 056722 013737 001352 001142 MOV RMER1I,$BDDAT ;RECEIVED STATUS
48 056730 062716 000004 ADD #4,(SP) ;MOVE SP TO USER'S ERROR
49 056734 112776 000050 000000 MOVB #50,@(SP) ;WRITE ERROR NUMBER
50 056742 032737 001000 001346 BIT #MXF,RMCS2I ;DID MXF GET SET??
51 056750 001003 BNE 15$ ;YES!!
52 056752 112776 000274 000000 MOVB #274,@(SP) ;NO - CHANGE ERROR NUMBER
53 056760 162716 000002 SUB #2,(SP) ;MOVE SP TO RETURN IF ERROR
54 056764 004736 JSR PC,@(SP)+ ;REPORT ERROR AND RETURN
55 056766 000425 BR 30$
56
57     ;LOOK FOR ANY ERRORS WHICH MAY HAVE OCCURRED DURING COMMAND INITIATION OR
    
```

```

58      ;MECHANICAL POSITIONING
59
60      ;FIRST TEST MXF WHICH WOULD INDICATE COMPOSITE ERROR SET WHEN FUNCTION
61      ;CODE AND GO BIT WERE LOADED
62      056770
63      056770 032737 001000 001346      20$:      BIT      #MXF,RMCS2I      ;WAS 'MISSED TRANSFER' SET??
64      056776 001425                      BEQ      40$              ;NO..
65      057000 013737 001346 001140      MOV      RMCS2I,$GDDAT    ;EXPECTED STATUS
66      057006 042737 001000 00140      BIC      #MXF,$GDDAT
67      057014 013737 001346 001142      MOV      RMCS2I,$BDDAT    ;RECEIVED STATUS
68      057022 062716 000004              ADD      #4,(SP)          ;MOVE SP TO USER'S ERROR CALL
69      057026 112776 000275 000004      MOVSB   #275,@(SP)        ;WRITE ERROR NUMBER
70      057034 162716 000002              SUB      #2,(SP)          ;MOVE SP TO RETURN IF ERROR
71      057040 004736                      JSR      PC,@(SP)+        ;REPORT ERROR AND RETURN
72      057042
73
74      ;RESTORE SP TO NO ERROR RETURN AND BYPASS FURHTER STATUS CHECKING
75      057042 162716 000010              SUB      #10,(SP)         ;MOVE SP TO NO ERROR
76      057046 000137 062140              JMP      380$             ;SKIP TO END OF SUB
77
78      057052      40$:
79
80      ;REPORT AN ERROR IF 'OPI' ERROR OCCURRED DUE TO 'MOL' - 0, OR IF 'OPI'
81      ;AND 'MOL' ARE SET, BUT 'VV' IS RESET, INDICATING AN INTERMITTENT
82      ;'MOL'
83      057052 032737 020000 001352      BIT      #OPI,RMER1I     ;IS 'OPI' SET??
84      057060 001447                      BEQ      60$              ;NO..
85      057062 013737 001352 001140      MOV      RMER1I,$GDDAT    ;EXPECTED STATUS
86      057070 042737 020000 001140      BIC      #OPI,$GDDAT
87      057076 013737 001352 001142      MOV      RMER1I,$BDDAT    ;RECEIVED STATUS
88      057104 032737 010000 001350      BIT      #MOL,RMDSI      ;WAS MEDIUM OFF LINE??
89      057112 001404                      BEQ      45$              ;YES!!
90      057114 032737 000100 001350      BIT      #VV,RMDSI        ;WAS 'MOL' INTERMITTENT??
91      057122 001013                      BNE      50$              ;NO!!
92      057124 062716 000004              45$:      ADD      #4,(SP)          ;MOVE SP TO USER'S ERROR CALL
93      057130 112776 000276 000000      MOVSB   #276,@(SP)        ;WRITE ERROR NUMBER IN CALL
94      057136 162716 000002              SUB      #2,(SP)          ;MOVE SP TO RETURN IF ERROR
95      057142 004736                      JSR      PC,@(SP)+        ;REPORT ERROR AND RETURN
96      057144 162716 000010              SUB      #10,(SP)         ;RESTORE SP TO NO ERROR
97      057150 000413                      BR       60$
98      057152
99
100     ;REPORT 'OPI' ERROR, WHICH IS DUE TO 'ON CYLINDER' NOT DROPPING OR
101     ;'RUN' TIMEOUT (20 MS) OR SEARCH TIMEOUT (50 MS)
102     057152 062716 000004              ADD      #4,(SP)          ;MOVE SP TO USER'S ERROR CALL
103     057156 112776 000277 000000      MOVSB   #277,@(SP)        ;WRITE ERROR NUMBER IN CALL
104     057164 162716 000002              SUB      #2,(SP)          ;MOVE SP TO RETURN IF ERROR
105     057170 004736                      JSR      PC,@(SP)+        ;REPORT ERROR AND RETURN
106     057172 162716 000010              SUB      #10,(SP)         ;RESTORE SP TO NO ERROR
107     057176 000240                      NOP
108     057200      60$:
109
110     ;LOOK FOR 'IVC' ERROR DURING COMMAND INITIATION
111     057200 032737 010000 001400      BIT      #IVC,RMER2I     ;WAS THERE AN 'IVC' ERROR??
112     057206 001432                      BEQ      70$              ;NO..
113     ;REPORT 'IVC' ERROR DUE TO 'VV' = 0, OR REPORT ERRONEGUS 'I...' [REPR
114     057210 013737 001400 001140      MOV      RMER2I,$GDDAT    ;EXPECTED STATUS
    
```

```

115 057216 042737 010000 001140 BIC #IVC,$GDDAT
116 057224 013737 001400 001142 MOV RMER2I,$BDDAT ;RECEIVED STATUS
117 057232 062716 000004 ADD #4,(SP) ;MOVE SP TO USER'S ERROR
118 057236 112776 000300 000000 MOV#B #300,@(SP) ;WRITE ERROR NUMBER IN CALL
119 057244 032737 000100 001350 BIT #VV,RMDSI ;WAS VOLUME VALID??
120 057252 001403 BEQ 65$ ;NO.
121 057254 112776 000301 000000 MOV#B #301,@(SP) ;CHANGE ERROR NUMBER
122 057262 162716 000002 65$: SUB #2,(SP) ;MOVE SP TO RETURN IF ERROR
123 057266 004736 JSR PC,@(SP)+ ;REPORT 'IVC' ERROR AND RETURN
124 057270 162716 000010 SUB #10,(SP) ;RESTORE SP TO NO ERROR
125 057274 70$:
126
127 ;SEE IF 'ILF' OR 'RMR' IS SET
128 057274 032737 000007 001352 BIT #ILR,ILF.RMR,RMER1I
129 057302 001510 BEQ 100$ ;NO ERRORS DETECTED
130 ;REPORT AN ERROR IF 'ILR' IS SET
131 057304 032737 000002 001352 BIT #ILR,RMER1I ;WAS 'ILR' DETECTED??
132 057312 001424 BFQ 80$ ;NO.
133 057314 013737 001352 001140 MOV RMER1I,$GDDAT ;EXPECTED STATUS
134 057322 042737 000002 001140 BIC #ILR,$GDDAT
135 057330 013737 001352 001142 MOV RMER1I,$BDDAT ;RECEIVED STATUS
136 057336 062716 000004 ADD #4,(SP) ;MOVE SP TO USER'S ERROR CALL
137 057342 112776 000302 000000 MOV#B #302,@(SP) ;WRITE ERROR NUMBER IN CALL
138 057350 162716 000002 SUB #2,(SP) ;MOVE SP TO RETURN IF ERROR
139 057354 004736 JSR PC,@(SP)+ ;REPORT ERROR AND RETURN
140 057356 162716 000010 SUB #10,(SP) ;RESTORE SP TO NO ERROR
141 057362 000240 NOP
142 057364 80$:
143
144 ;REPORT AN ERROR IF 'ILF' IS SET
145 057364 032737 000001 001352 BIT #ILF,RMER1I ;WAS 'ILF' DETECTED??
146 057372 001424 BEQ 90$ ;NO.
147 057374 013737 001352 001140 MOV RMER1I,$GDDAT ;EXPECTED STATUS
148 057402 042737 000001 001140 BIC #ILF,$GDDAT
149 057410 013737 001352 001142 MOV RMER1I,$BDDAT ;RECEIVED STATUS
150 057416 062716 000004 ADD #4,(SP) ;MOVE SP TO USER'S ERROR CALL
151 057422 112776 000303 000000 MOV#B #303,@(SP) ;WRITE ERROR NUMBER IN CALL
152 057430 162716 000002 SUB #2,(SP) ;MOVE SP TO RETURN IF ERROR
153 057434 004736 JSR PC,@(SP)+ ;REPORT ERROR AND RETURN
154 057436 162716 000010 SUB #10,(SP) ;RESTORE SP TO NO ERROR
155 057442 000240 NOP
156 057444 90$:
157
158 ;REPORT AN ERROR IF 'RMR' IS SET
159 057444 032737 000004 001352 BIT #RMR,RMER1I ;WAS 'RMR' DETECTED??
160 057452 001424 BEQ 100$ ;NO.
161 057454 013737 001352 001140 MOV RMER1I,$GDDAT ;EXPECTED STATUS
162 057462 042737 000004 001140 BIC #RMR,$GDDAT
163 057470 013737 001352 001142 MOV RMER1I,$BDDAT ;RECEIVED STATUS
164 057476 062716 000004 ADD #4,(SP) ;MOVE SP TO USER'S ERROR CALL
165 057502 112776 000304 000000 MOV#B #304,@(SP) ;WRITE ERROR NUMBER IN CALL
166 057510 162716 000002 SUB #2,(SP) ;MOVE SP TO RETURN IF ERROR
167 057514 004736 JSR PC,@(SP)+ ;REPORT ERROR AND RETURN
168 057516 162716 000010 SUB #10,(SP) ;RESTORE SP TO NO ERROR
169 057522 000240 NOP
170 057524 100$:
171 ;DETERMINE WHETHER OR NOT 'IAE' SHOULD BE SET AND CHECK FOR ERROR

```

```

172 057524 012737 002000 001140      MOV      #IAE,$GDDAT      ;SETUP FOR 'IAE' - 1
173 057532 052737 040000 062166      BIS      #SKI,500$      ;SETUP FOR 'SKI' - 1
174 057540 023727 001446 001466      CMP      RMDCO,#822.    ;GREATER THAN LAST CYLINDER ?
175 057546 101025          BHI      110$          ;YES - CYLINDER IS INVALID
176 057550 042737 040000 062166      BIC      #SKI,500$      ;RESET SKI FLAG
177
178 057556 123737 001421 001335      CMPB     RMDAO+1,LSTRK+1 ;GREATER THAN LAST TRACK ?
179 057564 101016          BHI      110$          ;YES - TRACK IS INVALID
180
181 057566 123727 001420 000035      CMPB     RMDAO,#29.    ;IS SECTOR > 29. ?
182 057574 101410          BLOS     105$          ;NO
183 057576 032737 010000 001444      BIT      #FMT16,RMOFO  ;18 BIT FORMAT ?
184 057604 001406          BEQ      110$          ;YES - SECTOR IS INVALID FOR 18 BIT MODE
185 057606 123727 001420 000037      CMPB     RMDAO,#31.    ;IS SECTOR > 31. ?
186 057614 101002          BHI      110$          ;YES - SECTOR IS INVALID
187 057616 005037 001140          CLR      $GDDAT        ;'IAE' SHOULD = 0
188
189 057622 013737 001352 001142      110$:    MOV      RMER1I,$BDDAT   ;GET RECEIVED STATUS
190 057630 042737 175777 001142      BIC      #^CIAE,$BDDAT
191 057636 023737 001140 001142      CMP      $GDDAT,$BDDAT ;IS 'IAE' STATUS OK??
192 057644 001004          BNE      115$          ;NO!
193 057646 042737 040000 062166      BIC      #SKI,500$     ;IAE OK - SKI SHOULD BE 0
194 057654 000412          BR       120$
195 057656 062716 000004          115$:    ADD      #4,(SP)        ;MOVE SP TO USER'S ERROR CALL
196 057662 112776 000305 000000      MOVB     #305,@(SP)    ;WRITE ERROR NUMBER
197 057670 162716 000002          SUB      #2,(SP)      ;MOVE SP TO RETURN IF ERROR
198 057674 004736          JSR      PC,@(SP)+    ;REPORT ERROR AND RETURN
199 057676 162716 000010          SUB      #10,(SP)     ;MOVE SP TO NO ERROR
200 057702          120$:
201
202          ;REPORT AN ERROR IF 'SKI' IS SET AND 'IAE' STATUS WAS OK
203 057702 013737 001400 001142      MOV      RMER2I,$BDDAT ;RECEIVED STATUS
204 057710 042737 137777 001142      BIC      #^CSKI,$BDDAT
205 057716 013737 062166 001140      MOV      500$,$GDDAT  ;EXPECTED STATUS
206 057724 042737 137777 001140      BIC      #^CSKI,$GDDAT
207 057732 032737 040000 001400      BIT      #SKI,RMER2I  ;WAS 'SKI' SET??
208 057740 001417          BEQ      140$          ;NO!
209 057742 032737 040000 062166      BIT      #SKI,500$    ;WAS SKI CAUSED BY IAE - 0??
210 057750 001032          BNE      150$          ;YES - DON'T REPORT SKI
211 057752 062716 000004          ADD      #4,(SP)      ;MOVE SP TO USERS ERROR CALL
212 057756 112776 000306 000000      MOVB     #306,@(SP)   ;WRITE ERROR NUMBER
213 057764 162716 000002          SUB      #2,(SP)      ;MOVE SP TO RETURN IF ERROR
214 057770 004736          JSR      PC,@(SP)+    ;REPORT ERROR AND RETURN
215 057772 162716 000010          SUB      #10,(SP)     ;MOVE SP TO NO ERROR
216 057776 000417          BR       150$
217
218 060000          140$:
219
220          ;REPORT AN ERROR IF SKI 0 AND IAE WAS NOT DETECTED
221 060000 032737 040000 062166      BIT      #SKI,500$    ;SHOULD SKI BE SET??
222 060006 001413          BEQ      150$          ;NO!
223 060010 062716 000004          ADD      #4,(SP)      ;MOVE SP TO USER'S ERROR CALL
224 060014 112776 000307 000000      MOVB     #307,@(SP)   ;WRITE ERROR NUMBER IN CALL
225 060022 162716 000002          SUB      #2,(SP)      ;MOVE SP TO RETURN IF ERROR
226 060026 004736          JSR      PC,@(SP)+    ;REPORT ERROR AND RETURN
227 060030 162716 000010          SUB      #10,(SP)     ;RESTORE SP TO NO ERROR
228 060034 000240          NOP
    
```

```

229 060036      150$:
230
231           ;LOOK FOR 'LSC' OR 'LBC' OR 'DVC' IN ERROR REGISTER #2
232 060036 032737 006200 001400      BIT      #LSC!LBC!DVC,RMER2I
233 060044 001512           BEQ      180$           ;NO ERRORS SET
234
235           ;REPORT ANY DEVICE FAULT, I.E., 'DVC' = 1
236 060046 032737 000200 001400      BIT      #DVC,RMER2I      ;IS 'DVC' = 1??
237 060054 001424           BEQ      160$           ;NO!!
238 060056 013737 001400 001140      MOV      RMER2I,$GDDAT      ;EXPECTED STATUS
239 060064 042737 000200 001140      BIC      #DVC,$GDDAT
240 060072 013737 001400 001142      MOV      RMER2I,$BDDAT      ;RECEIVED STATUS
241 060100 062716 000004           ADD      #4,(SP)           ;MOVE SP TO USERS ERROR
242 060104 112776 000310 000000      MOVVB   #310,@(SP)        ;WRITE ERROR NUMBER IN CALL
243 060112 162716 000002           SUB      #2,(SP)          ;MOVE SP TO RETURN IF ERROR
244 060116 004736           JSR      PC,@(SP)+        ;REPORT ERROR AND RETURN
245 060120 162716 000010           SUB      #10,(SP)         ;RESTORE SP TO NO ERROR
246 060124 000240           NOP
247 060126      160$:
248
249           ;REPORT LOSS OF BIT CLOCK, I.E.; 'LBC' = 1, IF 'MOL' = 1
250 060126 032737 002000 001400      BIT      #LBC,RMER2I      ;IS LBC SET??
251 060134 001430           BEQ      170$           ;NO!!
252 060136 032737 010000 001350      BIT      #MOL,RMDSI       ;WAS LBC ERROR BY MOL = 0
253 060144 001424           BEQ      170$           ;YES!!
254 060146 013737 001400 001140      MOV      RMER2I,$GDDAT      ;EXPECTED STATUS
255 060154 042737 002000 001140      BIC      #LBC,$GDDAT
256 060162 013737 001400 001142      MOV      RMER2I,$BDDAT      ;RECEIVED STATUS
257 060170 062716 000004           ADD      #4,(SP)           ;MOVE SP TO USER'S ERROR CALL
258 060174 112776 000311 000000      MOVVB   #311,@(SP)        ;WRITE ERROR NUMBER IN CALL
259 060202 162716 000002           SUB      #2,(SP)          ;MOVE SP TO RETURN IF ERROR
260 060206 004736           JSR      PC,@(SP)+        ;REPORT ERROR AND RETURN
261 060210 162716 000010           SUB      #10,(SP)         ;RESTORE SP TO NO ERROR
262 060214 000240           NOP
263 060216      170$:
264
265           ;REPORT LOS OF SYSTEM CLOCK, I.E., 'LSC' = 1
266 060216 032737 004000 001400      BIT      #LSC,RMER2I      ;IS 'LSC' = 1??
267 060224 001422           BEQ      180$           ;NO!!
268 060226 013737 001400 001140      MOV      RMER2I,$GDDAT      ;EXPECTED STATUS
269 060234 042737 004000 001140      BIC      #LSC,$GDDAT
270 060242 013737 001400 001142      MOV      RMER2I,$BDDAT      ;RECEIVED STATUS
271 060250 062716 000004           ADD      #4,(SP)           ;MOVE SP TO USER'S ERROR CALL
272 060254 112776 000312 000000      MOVVB   #312,@(SP)        ;WRITE ERROR NUMBER
273 060262 004736           JSR      PC,@(SP)+        ;REPORT ERROR AND RETURN
274 060264 162716 000010           SUB      #10,(SP)         ;RESTORE SP TO NO ERROR
275 060270 000240           NOP
276 060272      180$:
277
278           ;LOOK FOR 'UNS' OR 'DTE' OR 'WLE' IN ERROR REGISTER #1
279 060272 032737 054000 001352      BIT      #UNS!DTE!WLE,RMER1I
280 060300 001527           BEQ      220$           ;NO BITS SET
281
282           ;REPORT 'UNS' ERROR IF 'DVC' = 0
282 060302 032737 040000 001352      BIT      #UNS,RMER1I      ;IS 'UNS' SET??
283 060310 001427           BEQ      190$           ;NO!!
284 060312 032737 000200 001400      BIT      #DVC,RMER2I      ;WAS 'UNS' CAUSED BY 'DVC'??
285 060320 001023           BNE      190$           ;YES..
    
```

```

286 060322 013737 001352 001140      MOV      RMER11,$GDDAT      ;EXPECTED STATUS
287 060330 042737 040000 001140      BIC      #UNS,$GDDAT
288 060336 013737 001352 001142      MOV      RMER11,$BDDAT      ;RECEIVED STATUS
289 060344 062716 000004                ADD      #4,(SP)            ;MOVE SP TO USERS ERROR CALL
290 060350 112776 000313 000000      MOVW    #313,@(SP)        ;WRITE ERROR NUMBER
291 060356 162716 000002                SUB      #2,(SP)            ;MOVE SP TO RETURN IF ERROR
292 060362 004736                JSR      PC,@(SP)+         ;REPORT ERROR AND RETURN
293 060364 162716 000010                SUB      #10,(SP)         ;RESTORE SP TO NO ERROR
294 060370
295
296                                     ;REPORT ANY DRIVE TIMING ERROR, I.E., 'DTE' = 1
297 060370 032737 010000 001352      BIT      #DTE,RMER11      ;IS DTE SET??
298 060376 001423                BEQ      200$              ;NO!!
299 060400 013737 001352 001140      MOV      RMER11,$GDDAT      ;EXPECTED STATUS
300 060406 042737 010000 001140      BIC      #DTE,$GDDAT
301 060414 013737 001352 001142      MOV      RMER11,$BDDAT      ;RECEIVED STATUS
302 060422 062716 000004                ADD      #4,(SP)            ;MOVE SP TO USER'S ERROR CALL
303 060426 112776 000314 000000      MOVW    #314,@(SP)        ;WRITE ERROR NUMBER IN CALL
304 060434 162716 000002                SUB      #2,(SP)            ;MOVE SP TO RETURN IF ERROR
305 060440 004736                JSR      PC,@(SP)+         ;REPORT ERROR AND RETURN
306 060442 162716 000010                SUB      #10,(SP)         ;MOVE SP TO NO ERROR
307 060446
308
309                                     ;REPORT AN ERROR IF WRITE LOCK ERROR IS SET. SEE IF DRIVE IS NOT
310                                     ;WRITE PROTECTED, OR IF FUNCTION WAS NOT A WRITE
311 060446 032737 004000 001352      BIT      #WLE,RMER11      ;WAS 'WLE' SET??
312 060454 001441                BEQ      220$              ;NO!!
313 060456 013737 001352 001142      MOV      RMER11,$BDDAT      ;RECEIVED STATUS
314 060464 013737 001352 001140      MOV      RMER11,$GDDAT      ;EXPECTED STATUS
315 060472 052737 004000 001140      BIS      #WLE,$GDDAT
316 060500 062716 000004                ADD      #4,(SP)            ;MOVE SP TO USERS ERROR CALL
317 060504 112776 000315 000000      MOVW    #315,@(SP)        ;WRITE ERROR NUMBER IN CALL
318 060512 032737 004000 001350      BIT      #WRL,RMDSI      ;WAS DRIVE WRITE PROTECTED??
319 060520 001404                BEQ      205$              ;NO!!
320 060522 032737 000010 001412      BIT      #BIT3,RMCS10     ;WAS COMMAND A WRITE??
321 060530 001406                BEQ      210$              ;YES!!
322 060532 112776 000316 000000 205$: MOVW    #316,@(SP)        ;CHANGE ERROR NUMBER
323 060540 042737 004000 001140      BIC      #WLE,$GDDAT
324 060546 162716 000002                SUB      #2,(SP)            ;MOVE SP TO RETURN IF ERROR
325 060552 004736                JSR      PC,@(SP)+         ;REPORT ERROR AND RETURN
326 060554 162716 000010                SUB      #10,(SP)         ;MOVE SP TO NO ERROR
327
328 060560                                     220$:
329
330                                     ;OMIT DATA ERROR CHECKS IF ANY PREVIOUS ERRORS HAVE BEEN DETECTED
331 060560 062716 000004                ADD      #4,(SP)            ;MOVE SP TO USER'S ERROR
332 060564 105776 000000                TSTB    @(SP)              ;WAS ERROR DETECTED??
333 060570 001404                BEQ      225$              ;NO - DO DATA CHECKS
334 060572 162716 000004                SUB      #4,(SP)            ;RESTORE SP
335 060576 000137 061600                JMP      340$              ;SKIP DATA CHECKS
336 060602 162716 000004                SUB      #4,(SP)            ;RESTORE SP
337
338                                     ;CHECK HEADER ERRORS IF FUNCTION WAS NOT WRITE HEADER AND DATA, AND
339                                     ;IF HEADER COMPARE IS NOT INHIBITED
340 060606 013737 001412 062170      MOV      RMCS10,510$      ;STRIP AND STORE FUNCTION CODE
341 060614 042737 177700 062170      BIC      #^CFNCMSK,510$
342 060622 022737 000063 062170      CMP      #WH!GO,510$      ;WAS FUNCTION WRITE HEADER & DATA?
    
```

```

343 060630 001512          BEQ      250$          ;YES - SKIP HEADER CHECKS
344 060632 032737 002000 001370 BIT      #HCI,RMOFI    ;WAS HCI SET??
345 060640 001106          BNE      250$          ;YES - SKIP HEADER CHECKS
346
347          ;SEE IF ANY HEADER ERRORS ARE SET, I.E., 'FER' OR 'HCRC' OR 'HCE'
348 060642 032737 000620 001352 BIT      #HCRC!FER,HCE,RMER11
349 060650 001533          BEQ      270$          ;NO ERRORS SET
350
351          ;REPORT HEADER CRC ERROR IF SET
352 060652 032737 000400 001352 BIT      #HCRC,RMER11    ;WAS HCRC SET??
353 060660 001422          BEQ      230$          ;NO!!
354 060662 013737 001352 001140 MOV      RMER11,$GDDAT ;EXPECTED STATUS
355 060670 042737 000400 001140 BIC      #HCRC,$GDDAT
356 060676 013737 001352 001142 MOV      RMER11,$BDDAT ;RECEIVED STATUS
357 060704 062716 000004          ADD      #4,(SP)        ;MOVE SP TO USERS ERROR
358 060710 112776 000317 000000 MOVVB   #317,@(SP)      ;WRITE ERROR NUMBER
359 060716 162716 000002          SUB      #2,(SP)        ;MOVE SP TO RETURN IF ERROR
360 060722 004736          JSR      PC,@(SP)+     ;REPORT ERROR AND RETURN
361 060724 000501          BR       260$
362 060726          230$:
363
364          ;REPORT FORMAT ERROR IF SET
365 060726 032737 000020 001352 BIT      #FER,RMER11    ;WAS 'FER' SET??
366 060734 001422          BEQ      240$          ;NO!!
367 060736 013737 001352 001140 MOV      RMER11,$GDDAT ;EXPECTED STATUS
368 060744 042737 000020 001140 BIC      #FER,$GDDAT
369 060752 013737 001352 001142 MOV      RMER11,$BDDAT ;RECEIVED STATUS
370 060760 062716 000004          ADD      #4,(SP)        ;MOVE SP TO USERS ERROR
371 060764 112776 000320 000000 MOVVB   #320,@(SP)      ;WRITE ERROR NUMBER
372 060772 162716 000002          SUB      #2,(SP)        ;MOVE SP TO RETURN IF ERROR
373 060776 004736          JSR      PC,@(SP)+     ;REPORT ERROR AND RETURN
374 061000 000453          BR       260$
375 061002          240$:
376
377          ;REPORT HEADER COMPARE ERROR IF SET
378 061002 032737 000200 001352 BIT      #HCE,RMER11    ;WAS 'HCE' SET??
379 061010 001453          BEQ      270$          ;NO!!
380 061012 013737 001352 001140 MOV      RMER11,$GDDAT ;EXPECTED STATUS
381 061020 042737 000200 001140 BIC      #HCE,$GDDAT
382 061026 013737 001352 001142 MOV      RMER11,$BDDAT ;RECEIVED STATUS
383 061034 062716 000004          ADD      #4,(SP)        ;MOVE SP TO USER'S ERROR
384 061040 112776 000321 000000 MOVVB   #321,@(SP)      ;WRITE ERROR NUMBER
385 061046 162716 000002          SUB      #2,(SP)        ;MOVE SP TO RETURN IF ERROR
386 061052 004736          JSR      PC,@(SP)+     ;REPORT ERROR AND RETURN
387 061054 000425          BR       260$
388          ;THERE SHOULD BE NO HEADER ERRORS BECAUSE
389          ;.COMMAND WAS WRITE HEADER AND DATA, OR
390          ;.HEADER COMPARE INHIBIT WAS SET
391 061056 032737 000620 001352 250$: BIT      #HCE!FER!HCRC,RMER11
392 061064 001425          BEQ      270$          ;NO ERRORS WERE SET
393 061066 013737 001352 001140 MOV      RMER11,$GDDAT ;EXPECTED STATUS
394 061074 042737 000620 001140 BIC      #HCE!FER!HCRC,$GDDAT
395 061102 013737 001352 001142 MOV      RMER11,$BDDAT ;RECEIVED STATUS
396 061110 062716 000004          ADD      #4,(SP)        ;MOVE SP TO USER'S ERROR CALL
397 061114 112776 000322 000000 MOVVB   #322,@(SP)      ;WRITE ERROR NUMBER
398 061122 162716 000002          SUB      #2,(SP)        ;MOVE SP TO RETURN IF ERROR
399 061126 004736          JSR      PC,@(SP)+     ;REPORT ERROR AND RETURN

```

```

400 061130 162716 000010      260$: SUB #10,(SP)      ;MOVE SP TO NO ERROR
401 061134 000137 061600      JMP 340$      ;OMIT FURTHER DATA CHECKS
402
403 061140      270$:
404
405      ;IF COMMAND WAS A WRITE COMMAND, GO DO WRITE ERROR CHECKS, OTHERWISE
406      ;DO READ ERROR CHECKS
407 061140 032737 000010 062170      BIT #BIT3,510$      ;WAS THIS A WRITE COMMAND?
408 061146 001002      BNE 275$      ;NO..
409 061150 000137 061366      JMP 310$      ;GO DO WRITE STATUS CHECK
410 061154
411
412      ;REPORT DATA CHECK IF SET
413 061154 032737 100000 001352      BIT #DCK,RMER11      ;DATA CHECK ERROR??
414 061162 001450      BEQ 290$      ;NO!!
415 061164 013737 001352 001140      MOV RMER11,$GDDAT      ;EXPECTED STATUS
416 061172 042737 100000 001140      BIC #DCK,$GDDAT
417 061200 013737 001352 001142      MOV RMER11,$BDDAT      ;RECEIVED STATUS
418 061206 062716 000004      ADD #4,(SP)      ;MOVE SP TO USER'S ERROR
419 061212 112776 000323 000000      MOVB #323,@(SP)      ;WRITE ERROR NUMBER
420 061220 032737 004000 001370      BIT #EC1,RMOFI      ;WAS ECC CORRECTION DISABLED??
421 061226 001021      BNE 280$      ;YES!!
422 061230 112776 000324 000000      MOVB #324,@(SP)      ;CHANGE TO RECOVERABLE ERROR
423 061236 032737 000100 001352      BIT #ECH,RMER11      ;IS ERROR RECOVERABLE??
424 061244 001007      BNE 276$      ;NO!!
425      ;DO NOT REPORT RECOVERABLE ERROR IF READ COMMAND
426 061246 052737 000020 062170      BIT #BIT4,510$      ;WAS THIS A READ COMMAND ??
427 061254 001406      BEQ 280$      ;NO!!
428 061256 162716 000004      SUB #4,(SP)      ;RESTORE SP
429 061262 000410      BR 290$      ;SKIP ERROR - DATA WILL BE CORRECTED
430 061264 112776 000325 000000 276$: MOVB #325,@(SP)      ;CHANGE TO NON RECOVERABLE
431 061272 162716 000002 280$: SUB #2,(SP)      ;MOVE SP TO RETURN IF ERROR
432 061276 004736      JSR PC,@(SP)+      ;REPORT ERROR AND RETURN
433 061300 162716 000010      SUB #10,(SP)      ;RESTORE SP TO NO ERROR
434
435 061304      290$:
436
437      ;REPORT DATA BUS PARITY ERROR IF SET, I.E., MDPE - 1
438 061304 032737 000400 001346      BIT #MDPE,RMCS2I      ;PARITY ERROR SET??
439 061312 001423      BEQ 300$      ;NO!!
440 061314 013737 001346 001140      MOV RMCS2I,$GDDAT      ;EXPECTED STATUS
441 061322 042737 000400 001140      BIC #MDPE,$GDDAT
442 061330 013737 001346 001142      MOV RMCS2I,$BDDAT      ;RECEIVED STATUS
443 061336 062716 000004      ADD #4,(SP)      ;MOVE SP TO USER'S ERROR
444 061342 112776 000326 000000      MOVB #326,@(SP)      ;WRITE ERROR NUMBER
445 061350 162716 000002      SUB #2,(SP)      ;MOVE SP TO RETURN IF ERROR
446 061354 004736      JSR PC,@(SP)+      ;REPORT ERROR AND RETURN
447 061356 162716 000010      SUB #10,(SP)      ;MOVE SP TO NO ERROR
448 061362 000137 061600 300$: JMP 340$      ;SKIP WRITE STATUS CHECK
449
450 061366      310$:
451
452      ;TEST TO SEE THAT OFFSET MODE WAS RESET; REPORT ERROR IF 'OM' 1
453 061366 032737 000001 001350      BIT #OM,RMDSI      ;IS OFFSET ON??
454 061374 001423      BEQ 320$      ;NO
455 061376 013737 001350 001140      MOV RMDSI,$GDDAT      ;EXPECTED STATUS
456 061404 042737 000001 001140      BIC #OM,$GDDAT
    
```



```

457 061412 013737 001350 001142      MOV      RMDSI,SBDDAT      ;RECEIVED STATUS
458 061420 062716 000004              ADD      #4,(SP)          ;MOVE SP TO USER'S ERROR CALL
459 061424 112776 000327 000000      MOVVB   #327,@(SP)       ;WRITE ERROR NUMBER IN CALL
460 061432 162716 000002              SUB      #2,(SP)          ;MOVE SP TO RETURN IF ERROR
461 061436 004736              JSR      PC,@(SP)+        ;REPORT ERROR AND RETURN
462 061440 162716 000010              SUB      #10,(SP)        ;MOVE SP TO NO ERROR
463 061444              320$:
464
465              ;TEST FOR DATA BUS PARITY ERROR: REPORT ERROR IF 'DPE' = 1
466 061444 032737 000010 001400      BIT      #DPE,RMER2I     ;DATA PARITY ERROR??
467 061452 001423              BEQ      330$            ;NO!!
468 061454 013737 001400 001140      MOV      RMER2I,$GDDAT   ;EXPECTED STATUS
469 061462 042737 000010 001140      BIC      #DPE,$GDDAT
470 061470 013737 001400 001142      MOV      RMER2I,SBDDAT   ;RECEIVED STATUS
471 061476 062716 000004              ADD      #4,(SP)          ;MOVE SP TO USER'S ERROR CALL
472 061502 112776 000330 000000      MOVVB   #330,@(SP)       ;WRITE ERROR NUMBER
473 061510 162716 000002              SUB      #2,(SP)          ;MOVE SP TO RETURN IF ERROR
474 061514 004736              JSR      PC,@(SP)+        ;REPORT ERROR AND RETURN
475 061516 162716 000010              SUB      #10,(SP)        ;MOVE SP TO NO ERROR
476 061522              330$:
477
478              ;TEST FOR WRITE CLOCK FAILURE: REPORT ERROR IF 'WCF' = 1
479 061522 032737 000040 001352      BIT      #WCF,RMER1I     ;IS 'WCF' SET??
480 061530 001423              BEQ      340$            ;NO!!
481 061532 013737 001352 001140      MOV      RMER1I,$GDDAT   ;EXPECTED STATUS
482 061540 042737 000040 001140      BIC      #WCF,$GDDAT
483 061546 013737 001352 001142      MOV      RMER1I,SBDDAT   ;RECEIVED STATUS
484 061554 062716 000004              ADD      #4,(SP)          ;MOVE SP TO USERS ERROR CALL
485 061560 112776 000331 000000      MOVVB   #331,@(SP)       ;WRITE ERROR NUMBER
486 061566 162716 000002              SUB      #2,(SP)          ;MOVE SP TO RETURN IF ERROR
487 061572 004736              JSR      PC,@(SP)+        ;REPORT ERROR AND RETURN
488 061574 162716 000010              SUB      #10,(SP)        ;MOVE SP TO NO ERROR
489 061600              340$:
490
491              ;REPORT 'DATA LATE' ERROR IF 'DLT' = 1
492 061600 032737 100000 001346      BIT      #DLT,RMCS2I     ;IS 'DLT' SET??
493 061606 001423              BEQ      350$            ;NO!!
494 061610 013737 001346 001140      MOV      RMCS2I,$GDDAT   ;EXPECTED STATUS
495 061616 042737 100000 001140      BIC      #DLT,$GDDAT
496 061624 013737 001346 001142      MOV      RMCS2I,SBDDAT   ;RECEIVED STATUS
497 061632 062716 000004              ADD      #4,(SP)          ;MOVE SP TO USERS ERROR CALL
498 061636 112776 000332 000000      MOVVB   #332,@(SP)       ;WRITE ERROR NUMBER
499 061644 162716 000002              SUB      #2,(SP)          ;MOVE SP TO RETURN IF ERROR
500 061650 004736              JSR      PC,@(SP)+        ;REPORT ERROR AND RETURN
501 061652 162716 000010              SUB      #10,(SP)        ;MOVE SP TO NO ERROR
502 061656              350$:
503
504              ;LOOK FOR UNEXPECTED CHANGES IN DRIVE STATUS
504 061656 013746 001350              MOV      RMDSI,-(SP)      ;STACK DRIVE STATUS
505 061662 042716 147c77              BIC      #^C<PIP!MOL!VV>,(SP) ;CLEAR DONT CAPES
506 061666 022726 010100              CMP      #MOL!VV,(SP)+   ;IS DRIVE STATUS OK??
507 061672 001522              BEQ      380$            ;YES!
508
509              ;REPORT ERROR IF POSITIONING IN PROGRESS AND NO SEEK INCOMPLETE FRROR,
510              ;I.E. PIP = 1 AND SKI = 0
511 061674 032737 020000 001350      BIT      #PIP,RMDSI      ;IS 'PIP' SET??
512 061702 001430              BEQ      360$            ;NO!!
513 061704 032737 040000 001400      BIT      #SKI,RMER2I     ;WAS 'SKI' ERROR REPORTED??

```

```

514 061712 001024          BNE      360$          :YES-DONT REPORT PIP
515 061714 013737 001350 001140      MOV      RMDSI,$GDDAT  :EXPECTED STATUS
516 061722 042737 020000 001140      BIC      #PIP,$GDDAT
517 061730 013737 001350 001142      MOV      RMDSI,$BDDAT  :RECEIVED STATUS
518 061736 062716 000004          ADD      #4,(SP)       :MOVE SP TO USERS ERROR CALL
519 061742 112776 000333 000000      MOVVB   #333,@(SP)    :WRITE ERROR NUMBER
520 061750 162716 000002          SUB      #2,(SP)       :MOVE SP TO RETURN IF ERROR
521 061754 004736          JSR      PC,@(SP)+    :REPORT ERROR AND RETURN
522 061756 162716 000010          SUB      #10,(SP)     :MOVE SP TO NO ERROR
523 061762 000240
524 061764          360$:
525
526          ;REPORT ERROR IF MEDIUM IS NOT ON LINE AND OPI ERROR WAS NOT
527          ;REPORTED, I.E., MOL = OPI = 0
528 061764 032737 010000 001350      BIT      #MOL,RMDSI   :IS MEDIUM ON LINE??
529 061772 001027          BNE      370$          :YES!!
530 061774 032737 020000 001352      BIT      #OPI,RMER11  :WAS OPI ERROR REPORTED??
531 062002 001023          BNE      370$          :YES..
532 062004 013737 001350 001140      MOV      RMDSI,$GDDAT  :EXPECTED STATUS
533 062012 052737 010000 001140      BIS      #MOL,$GDDAT
534 062020 013737 001350 001142      MOV      RMDSI,$BDDAT  :RECEIVED STATUS
535 062026 062716 000004          ADD      #4,(SP)       :MOVE SP TO USER'S ERROR
536 062032 112776 000334 000000      MOVVB   #334,@(SP)    :WRITE ERROR NUMBER
537 062040 162716 000002          SUB      #2,(SP)       :MOVE SP TO RETURN IF ERROR
538 062044 004736          JSR      PC,@(SP)+    :REPORT ERROR AND RETURN
539 062046 162716 000010          SUB      #10,(SP)     :MOVE SP TO NO ERROR
540 062052          370$:
541
542          ;REPORT ERROR IF VOLUME IS NOT VALID AND "IVC" ERROR WAS NOT
543          ;REPORTED, I.E., VV = IVC = 0
544 062052 032737 000100 001350      BIT      #VV,RMDSI    :IS VOLUME VALID??
545 062060 001027          BNE      380$          :YES!!
546 062062 032737 010000 001400      BIT      #IVC,RMER2I  :WAS IVC ERROR REPORTED??
547 062070 001033          BNE      390$          :YES!!
548 062072 013737 001350 001140      MOV      RMDSI,$GDDAT  :EXPECTED STATUS
549 062100 052737 000100 001140      BIS      #VV,$GDDAT
550 062106 013737 001350 001142      MOV      RMDSI,$BDDAT  :RECEIVED STATUS
551 062114 062716 000004          ADD      #4,(SP)       :MOVE SP TO USERS ERROR CALL
552 062120 112776 000335 000000      MOVVB   #335,@(SP)    :WRITE ERROR NUMBER
553 062126 162716 000002          SUB      #2,(SP)       :MOVE SP TO RETURN IF ERROR
554 062132 004736          JSR      PC,@(SP)+    :REPORT ERROR AND RETURN
555 062134 162716 000010          SUB      #10,(SP)     :MOVE SP TO NO ERROR
556 062140          380$:
557
558          ;AUGMENT THE RETURN ADDRESS IF ANY ERROR WAS FOUND
559 062140 062716 000004          ADD      #4,(SP)       :MOVE SP TO ERROR CALL
560 062144 105776 000000          TSIB    @(SP)         :ANY ERROR??
561 062150 001403          BEQ     390$          :NO!!
562 062152 062716 000004          ADD      #4,(SP)       :YES - MOVE SP TO ERROR RETURN
563 062156 000402          BR      400$
564 062160 162716 000004          390$: SUB      #4,(SP)     :MOVE SP TO NO ERROR RETURN
565
566 062164 000207          400$: RTS      PC      :RETURN TO USER
567
568 062166 000000          500$: .WORD      :ERROR FLAGS
569 062170 000000          510$: .WORD      :TEMPORARY STORAGE
    
```

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57

.SBTTL STATIC DRIVE STATUS CHECK SUBROUTINE

: THIS SUBROUTINE LOOKS FOR UNEXPECTED CHANGES IN DRIVE
 : STATUS, SUCH AS THE DRIVE LOSING VOLUME VALID. THE SUBROUTINE
 : CAN BE USED BY HOUSEKEEPING AND OTHER COMMANDS DURING WHICH THERE
 : SHOULD NOT BE ANY DRIVE ERRORS OR CHANGES IN STATE.

: THE FOLLOWING CONDITIONS ARE TESTED AND REPORTED AS ERRORS
 : IF TRUE:

: .MOL = 0, INDICATES DRIVE WENT OFFLINE, NOTE
 : THAT MOL IS ASSUMED TO HAVE BEEN SET
 : .VV = 0, INDICATES THE DRIVE LOST VOLUME VALID
 : .PIP = 1, INDICATES THAT THE DRIVE IS OFF CYLINDER
 : .SKI = 1, INDICATES THE DRIVE HAS AN UNEXPECTED SKI ERROR
 : .DVC = 1, INDICATES AN UNEXPECTED DEVICE FAULT

: THE SUBROUTINE IS CALLED AFTER STORING STATUS IN THE GET BUFFER.

```
:(1) JSR PC,STCDRVSTS
      BR ??? RETURN HERE IF NO ERROR
      NOP RETURN HERE TO REPORT AN ERROR
      ERROR ERROR NUMBER DEFINED BY SUB
      JSR PC,@(SP)+ GO BACK TO SUB FOR MORE ERROR CHECKS
      ??? RETURN HERE IF NO MORE ERRORS
```

STCDRVSTS:

: CLEAR USER'S ERROR CALL

```
ADD #4,(SP) ;MOVE SP TO USER'S ERROR CALL
CLRB @(SP) ;CLEAR ERROR NUMBER
SUB #4,(SP) ;MOVE SP BACK TO NO ERROR RETURN
```

: SEE IF 'MOL' = 'VV' = 1, AND 'PIP' = 0

```
MOV RMDSI,-(SP) ;PUT DRIVE STATUS ON STACK
BIC #^(<PIP!MOL!VV>,(SP)
CMP #MOL!VV,(SP)+ ;ARE MOL,VV AND PIP O.K.??
BEQ 30$ ;YES!!
```

: REPORT AN ERROR IF MOL = 0 AND 'OPI' = 0

```
BIT #MOL,RMDSI ;IS MOL ON ??
BNE 10$ ;YES!!
BIT #OPI,RMER1I ;WAS 'OPI' SET??
BNE 10$ ;YES-DONT REPORT 'MOL' 0
MOV RMDSI,$GDDAT ;EXPECTED STATUS
BIS #MOL,$GDDAT
MOV RMDSI,$BDDAT ;RECEIVED STATUS
ADD #4,(SP) ;MOVE SP TO USER'S ERROR CALL
MOVB #207,@(SP) ;WRITE ERROR NUMBER IN CALL
SUB #2,(SP) ;MOVE SP TO RETURN FOR ERROR
JSR PC,@(SP)+ ;REPORT ERROR VIA USER
SUB #10,(SP) ;MOVE SP BACK TO NO ERROR RETURN
NOP
```

10\$:

: REPORT AN ERROR IF VOLUME VALID IS NOW ZERO AND 'IVC' 0

```
BIT #VV,RMDSI ;IS 'VV' = 0??
BNE 20$ ;NO.
```

```
062172
062172 062716 000004
062176 105076 000000
062202 162716 000004
062206 013746 001350
062212 042716 147677
062216 022726 010100
062222 001524
062224 032737 010000 001350
062232 001030
062234 032737 020000 001352
062242 001024
062244 013737 001350 001140
062252 052737 010000 001140
062260 013737 001350 001142
062266 062716 000004
062272 112776 000207 000000
062300 162716 000002
062304 004736
062306 162716 000010
062312 000240
062314
062314 032737 000100 001350
062322 001030
```

```

58 062324 032737 010000 001400      BIT      #IVC,RMER2I      ;WAS 'IVC' SET??
59 062332 001024                    BNE      20$            ;YES-DONT REPORT 'VV' 0
60 062334 013737 001350 001140      MOV      RMDSI,$GDDAT   ;EXPECTED STATUS
61 062342 052737 000100 001350      BIS      #VV,RMDSI
62 062350 013737 001350 001142      MOV      RMDSI,$BDDAT   ;RECEIVED STATUS
63 062356 062716 000004                    ADD      #4,(SP)        ;MOVE SP TO USER'S ERROR CALL
64 062362 112776 000210 000000      MOVVB   #210,@(SP)     ;WRITE ERROR NUMBER IN CALL
65 062370 162716 000002                    SUB      #2,(SP)        ;MOVE SP TO RETURN FOR ERROR
66 062374 004736                    JSR      PC,@(SP)+      ;REPORT ERROR VIA USER
67 062376 162716 000010                    SUB      #10,(SP)      ;MOVE SP BACK TO NO ERROR
68 062402 000240                    NOP
69 062404                    20$:
70
71                                ;REPORT AN ERROR IF DRIVE IS OFF CYLINDER AND 'SKI' - 0
72 062404 032737 020000 001350      BIT      #PIP,RMDSI     ;IS DRIVE OFF CYLINDER??
73 062412 001430                    BEQ      30$            ;NO!!
74 062414 032737 040000 001400      BIT      #SKI,RMER2I    ;WAS 'SKI' SET??
75 062422 001024                    BNE      30$            ;YES-DONT REPORT 'PIP' - 1
76 062424 013737 001350 001140      MOV      RMDSI,$GDDAT   ;EXPECTED STATUS
77 062432 042737 020000 001140      BIC      #PIP,$GDDAT
78 062440 013737 001350 001142      MOV      RMDSI,$BDDAT   ;RECEIVED STATUS
79 062446 062716 000004                    ADD      #4,(SP)        ;MOVE SP TO USER'S ERROR CALL
80 062452 112776 000211 000000      MOVVB   #211,@(SP)     ;WRITE ERROR NUMBER IN USER'S CALL
81 062460 162716 000002                    SUB      #2,(SP)        ;MOVE SP TO RETURN FOR ERROR
82 062464 004736                    JSR      PC,@(SP)+      ;REPORT ERROR VIA USER
83 062466 162716 000010                    SUB      #10,(SP)      ;MOVE SP TO NO ERROR RETURN
84 062472 000240                    NOP
85 062474                    30$:
86
87                                ;SEE IF 'SKI' = 'DVC' = 0
88 062474 013746 001400                    MOV      RMER2I,-(SP)   ;PUT ERROR REG 2 ON STACK
89 062500 042726 137577                    BIC      #^C<SKI!DVC>,(SP)+
90 062504 001460                    BEQ      60$            ;BRANCH IF NO ERROR
91 062506                    40$:
92
93                                ;REPORT AN ERROR IF THERE IS A DEVICE FAULT
94 062506 032737 000200 001400      BIT      #DVC,RMER2I    ;ANY DEVICE FAULT??
95 062514 001424                    BEQ      50$            ;NO!!
96 062516 013737 001400 001140      MOV      RMER2I,$GDDAT  ;EXPECTED STATUS
97 062524 042737 000200 001140      BIC      #DVC,$GDDAT
98 062532 013737 001400 001142      MOV      RMER2I,$BDDAT  ;RECEIVED STATUS
99 062540 062716 000004                    ADD      #4,(SP)        ;MOVE SP TO USER'S CALL
100 062544 112776 000212 000000      MOVVB   #212,@(SP)     ;WRITE NUMBER OF ERROR IN CALL
101 062552 162716 000002                    SUB      #2,(SP)        ;MOVE SP TO RETURN FOR ERROR
102 062556 004736                    JSR      PC,@(SP)+      ;REPORT ERROR VIA USER
103 062560 162716 000010                    SUB      #10,(SP)      ;MOVE SP BACK TO NO ERROR
104 062564 000240                    NOP
105 062566                    50$:
106
107                                ;REPORT AN ERROR IF 'SKI' = 1
108 062566 032737 040000 001400      BIT      #SKI,RMER2I    ;IS THERE A SEEK INCOMPLETE ERROR
109 062574 001424                    BEQ      60$            ;NO!!
110 062576 013737 001400 001140      MOV      RMER2I,$GDDAT  ;EXPECTED STATUS
111 062604 042737 040000 001140      BIC      #SKI,$GDDAT
112 062612 013737 001400 001142      MOV      RMER2I,$BDDAT  ;RECEIVED STATUS
113 062620 062716 000004                    ADD      #4,(SP)        ;MOVE SP TO USER'S ERROR CALL
114 062624 112776 000213 000000      MOVVB   #213,@(SP)     ;WRITE ERROR NUMBER IN USER'S ERROR CALL
    
```

115	062632	162716	00000?	SUB	#2,(SP)	;MOVE SP TO RETURN FOR ERROR
116	062636	004736		JSR	PC,@(SP)+	;REPORT ERROR VIA USER
117	062640	162716	000010	SUB	#10,(SP)	;MOVE SP BACK TO NO ERROR
118	062644	000240		NOP		
119	062646					
120						
121						
122	062646	062716	000004	ADD	#4,(SP)	;MOVE SP TO USER'S ERROR CALL
123	062652	105776	000000	TSTB	@(SP)	;WAS AN ERROR DETECTED??
124	062656	001403		BEQ	70\$;NO!
125	062660	062716	000004	ADD	#4,(SP)	;YES - MOVE SP TO USER'S ERROR RETURN
126	062664	000402		BR	80\$	
127	062666	162716	000004	SUB	#4,(SP)	;NO - MOVE SP TO NO ERROR RETURN
128	062672	000240		NOP		
129	062674	000207		RTS	PC	;RETURN TO USER

60\$:

;AUGMENT THE RETURN ADDRESS IF ANY ERROR WAS DETECTED

70\$:

80\$:

.SBTTL SAVE AND RESTORE R0-R5 ROUTINES

```

:*****
:*SAVE R0-R5
:*CALL:
:* SAVREG
:*UPON RETURN FROM $SAVREG THE STACK WILL LOOK LIKE:
:*
:*TOP---(+16)
:* +2---(+18)
:* +4---R5
:* +6---R4
:* +8---R3
:*+10---R2
:*+12---R1
:*+14---R0

```

```

062676
062676 010046
062700 010146
062702 010246
062704 010346
062706 010446
062710 010546
062712 016646 000022
062716 016646 000022
062722 016646 000022
062726 016646 000022
062732 000002

```

```

$SAVREG:
MOV R0,-(SP) ;;PUSH R0 ON STACK
MOV R1,-(SP) ;;PUSH R1 ON STACK
MOV R2,-(SP) ;;PUSH R2 ON STACK
MOV R3,-(SP) ;;PUSH R3 ON STACK
MOV R4,-(SP) ;;PUSH R4 ON STACK
MOV R5,-(SP) ;;PUSH R5 ON STACK
MOV 22(SP),-(SP) ;;SAVE PS OF MAIN FLOW
MOV 22(SP),-(SP) ;;SAVE PC OF MAIN FLOW
MOV 22(SP),-(SP) ;;SAVE PS OF CALL
MOV 22(SP),-(SP) ;;SAVE PC OF CALL
RTI

```

*RESTORE R0-R5

*CALL:

* RESREG

```

062734
062734 012666 000022
062740 012666 000022
062744 012666 000022
062750 012666 000022
062754 012605
062756 012604
062760 012603
062762 012602
062764 012601
062766 012600
062770 000002

```

```

$RESREG:
MOV (SP)+,22(SP) ;;RESTORE PC OF CALL
MOV (SP)+,22(SP) ;;RESTORE PS OF CALL
MOV (SP)+,22(SP) ;;RESTORE PC OF MAIN FLOW
MOV (SP)+,22(SP) ;;RESTORE PS OF MAIN FLOW
MOV (SP)+,R5 ;;POP STACK INTO R5
MOV (SP)+,R4 ;;POP STACK INTO R4
MOV (SP)+,R3 ;;POP STACK INTO R3
MOV (SP)+,R2 ;;POP STACK INTO R2
MOV (SP)+,R1 ;;POP STACK INTO R1
MOV (SP)+,R0 ;;POP STACK INTO R0
RTI

```

.SBTTL BINARY TO ASCII AND TYPE ROUTINE

 *THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 16-BIT
 *BINARY-ASCII NUMBER AND TYPE IT.

*CALL:

* MOV NUMBER,-(SP) ;:NUMBER TO BE TYPED
 * TYPBN ;:TYPE IT

062772	010146			\$TYPBN:	MOV	R1,-(SP)		::SAVE R1 ON THE STACK
062774	016601	000006			MOV	6(SP),R1		::GET THE INPUT NUMBER
063000	000261				SEC			::SET 'C' SO CAN KEEP TRACK OF THE NUMBER OF BITS
063002	112737	000060	063044	1\$:	MOVB	#'0,\$BIN		::SET CHARACTER TO AN ASCII '0'.
063010	006101				ROL	R1		::GET THIS BIT
063012	001406				BEQ	2\$::DONE?
063014	105537	063044			ADCB	\$BIN		::NO--SET THE CHARACTER EQUAL TO THIS BIT
063020	104401	063044			TYPE	,\$BIN		::GO TYPE THIS BIT
063024	000241				CLC			::CLEAR 'C' SO CAN KEEP TRACK OF BITS
063026	000765				BR	1\$::GO DO THE NEXT BIT
063030	012601			2\$:	MOV	(SP)+,R1		::POP THE STACK INTO R1
063032	016666	000002	000004		MOV	2(SP),4(SP)		::ADJUST THE STACK
063040	012616				MOV	(SP)+,(SP)		
063042	000002				RTI			::RETURN TO USER
063044	000	000		\$BIN:	.BYTE	0,0		::STORAGE FOR ASCII CHAR. AND TERMINATOR

.SBTTL CONVERT BINARY TO DECIMAL AND TYPE ROUTINE

```

*****
*THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 5-DIGIT
*SIGNED DECIMAL (ASCII) NUMBER AND TYPE IT. DEPENDING ON WHETHER THE
*NUMBER IS POSITIVE OR NEGATIVE A SPACE OR A MINUS SIGN WILL BE TYPED
*BEFORE THE FIRST DIGIT OF THE NUMBER. LEADING ZEROS WILL ALWAYS BE
*REPLACED WITH SPACES.

```

```

*CALL:
*      MOV      NUM,-(SP)      ;;PUT THE BINARY NUMBER ON THE STACK
*      TYPDS                    ;;GO TO THE ROUTINE

```

```

063046      063046      010046      MOV      R0,-(SP)      ;;PUSH R0 ON STACK
063050      063050      010146      MOV      R1,-(SP)      ;;PUSH R1 ON STACK
063052      063052      010246      MOV      R2,-(SP)      ;;PUSH R2 ON STACK
063054      063054      010346      MOV      R3,-(SP)      ;;PUSH R3 ON STACK
063056      063056      010546      MOV      R5,-(SP)      ;;PUSH R5 ON STACK
063060      063060      012746      020200      MOV      #20200,-(SP)    ;;SET BLANK SWITCH AND SIGN
063064      063064      016605      000020      MOV      20(SP),R5     ;;GET THE INPUT NUMBER
063070      063070      100004      BPL      1$           ;;BR IF INPUT IS POS.
063072      063072      005405      NEG      R5           ;;MAKE THE BINARY NUMBER POS.
063074      063074      112766      000055      000001      MOVB     #'-,1(SP)     ;;MAKE THE ASCII NUMBER NEG.
063102      063102      005000      1$:      CLR      R0           ;;ZERO THE CONSTANTS INDEX
063104      063104      012703      063262      MOV      #SDBLK,R3     ;;SETUP THE OUTPUT POINTER
063110      063110      112723      000040      MOVB     #' ,(R3)+     ;;SET THE FIRST CHARACTER TO A BLANK
063114      063114      005002      2$:      CLR      R2           ;;CLEAR THE BCD NUMBER
063116      063116      016001      063252      MOV      $DTBL(R0),R1  ;;GET THE CONSTANT
063122      063122      160105      3$:      SUB      R1,R5        ;;FORM THIS BCD DIGIT
063124      063124      002402      BLT      4$           ;;BR IF DONE
063126      063126      005202      INC      R2           ;;INCREASE THE BCD DIGIT BY 1
063130      063130      000774      BR       3$
063132      063132      060105      4$:      ADD      R1,R5        ;;ADD BACK THE CONSTANT
063134      063134      005702      TST      R2           ;;CHECK IF BCD DIGIT 0
063136      063136      001002      BNE      5$           ;;FALL THROUGH IF 0
063140      063140      105716      TSTB    (SP)         ;;STILL DOING LEADING 0'S?
063142      063142      100407      BMI      7$           ;;BR IF YES
063144      063144      106316      5$:      ASLB    (SP)         ;;MSD?
063146      063146      103003      BCC      6$           ;;BR IF NO
063150      063150      116663      000001      177777      MOVB     1(SP),-1(R3)  ;;YES--SET THE SIGN
063156      063156      052702      000060      6$:      BIS      #'0,R2       ;;MAKE THE BCD DIGIT ASCII
063162      063162      052702      000040      7$:      BIS      #' ,R2       ;;MAKE IT A SPACE IF NOT ALREADY A DIGIT
063166      063166      110223      MOVB     R2,(R3)+     ;;PUT THIS CHARACTER IN THE OUTPUT BUFFER
063170      063170      005720      TST      (R0)+       ;;JUST INCREMENTING
063172      063172      020027      000010      CMP      R0,#10      ;;CHECK THE TABLE INDEX
063176      063176      002746      BLT      2$           ;;GO DO THE NEXT DIGIT
063200      063200      003002      BGT      8$           ;;GO TO EXIT
063202      063202      010502      MOV      R5,R2       ;;GET THE LSD
063204      063204      000764      BR       6$           ;;GO CHANGE TO ASCII
063206      063206      105726      8$:      TSTB    (SP)+       ;;WAS THE LSD THE FIRST NON-ZERO?
063210      063210      100003      BPL      9$           ;;BR IF NO
063212      063212      116663      177777      177776      MOVB     -1(SP),-2(R3) ;;YES--SET THE SIGN FOR TYPING
063220      063220      105013      9$:      CLRB    (R3)        ;;SET THE TERMINATOR
063222      063222      012605      MOV      (SP)+,R5     ;;POP STACK INTO R5
063224      063224      012603      MOV      (SP)+,R3     ;;POP STACK INTO R3
063226      063226      012602      MOV      (SP)+,R2     ;;POP STACK INTO R2
063230      063230      012601      MOV      (SP)+,R1     ;;POP STACK INTO R1

```


063232	012600			MOV	(SP)+,R0	::POP STACK INTO R0
063234	104401	063262		TYPE	,SDBLK	::NOW TYPE THE NUMBER
063240	016666	000002	000004	MOV	2(SP),4(SP)	::ADJUST THE STACK
063246	012616			MOV	(SF)+,(SP)	
063250	000002			RTI		::RETURN TO USER
063252	023420			\$DTBL:	10000.	
063254	001750				1000.	
063256	000144				100.	
063260	000012				10.	
063262				\$DBLK:	.BLKW 4	

.SRITL BINARY TO OCTAL (ASCII) AND TYPE

```

*****
*THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 6-DIGIT
*OCTAL (ASCII) NUMBER AND TYPE IT.
*$TYPOS---ENTER HERE TO SETUP SUPPRESS ZEROS AND NUMBER OF DIGITS TO TYPE
*CALL:
*   MOV     NUM,-(SP)      ;;NUMBER TO BE TYPED
*   TYPOS   ;;CALL FOR TYPEOUT
*   .BYTE  N              ;;N=1 TO 6 FOR NUMBER OF DIGITS TO TYPE
*   .BYTE  M              ;;M=1 OR 0
*                               ;;1=TYPE LEADING ZEROS
*                               ;;0=SUPPRESS LEADING ZEROS

```

```

*$TYPON----ENTER HERE TO TYPE OUT WITH THE SAME PAMETERS AS THE LAST
*$TYPOS OR $TYPOC
*CALL:
*   MOV     NUM,-(SP)      ;;NUMBER TO BE TYPED
*   TYPON   ;;CALL FOR TYPEOUT

```

```

*$TYPOC---ENTER HERE FOR TYPEOUT OF A 16 BIT NUMBER
*CALL:
*   MOV     NUM,-(SP)      ;;NUMBER TO BE TYPED
*   TYPOC   ;;CALL FOR TYPEOUT

```

063272	017646	000000		\$TYPOS:	MOV	@(SP),-(SP)	;;PICKUP THE MODE
063276	116637	000001	063515		MOVB	1(SP), \$OFILL	;;LOAD ZERO FILL SWITCH
063304	112637	063517			MOVB	(SP)+, \$OMODE+1	;;NUMBER OF DIGITS TO TYPE
063310	062716	000002			ADD	#2,(SP)	;;ADJUST RETURN ADDRESS
063314	000406				BR	\$TYPON	
063316	112737	000001	063515	\$TYPOC:	MOVB	#1, \$OFILL	;;SET THE ZERO FILL SWITCH
063324	112737	000006	063517		MOVB	#6, \$OMODE+1	;;SET FOR SIX(6) DIGITS
063332	112737	000005	063514	\$TYPON:	MOVB	#5, \$OCNT	;;SET THE ITERATION COUNT
063340	010346				MOV	R3,-(SP)	;;SAVE R3
063342	010446				MOV	R4,-(SP)	;;SAVE R4
063344	010546				MOV	R5,-(SP)	;;SAVE R5
063346	113704	063517			MOVB	\$OMODE+1,R4	;;GET THE NUMBER OF DIGITS TO TYPE
063352	005404				NEG	R4	
063354	062704	000006			ADD	#6,R4	;;SUBTRACT IT FOR MAX ALLOWED
063360	110437	063516			MOVB	R4, \$OMODE	;;SAVE IT FOR USE
063364	113704	063515			MOVB	\$OFILL,R4	;;GET THE ZERO FILL SWITCH
063370	016605	000012			MOV	12(SP),R5	;;PICKUP THE INPUT NUMBER
063374	005003				CLR	R3	;;CLEAR THE OUTPUT WORD
063376	006105			1\$:	ROL	R5	;;ROTATE MSB INTO 'C'
063400	000404				BR	3\$;;GO DO MSB
063402	006105			2\$:	ROL	R5	;;FORM THIS DIGIT
063404	006105				ROL	R5	
063406	006105				ROL	R5	
063410	010503				MOV	R5,R3	
063412	006103			3\$:	ROL	R3	;;GET LSB OF THIS DIGIT
063414	105337	063516			DECB	\$OMODE	;;TYPE THIS DIGIT?
063420	100016				BPL	7\$;;BR IF NO
063422	042703	177770			BIC	#177770,R3	;;GET RID OF JUNK
063426	001002				BNE	4\$;;TEST FOR 0
063430	005704				TST	R4	;;SUPPRESS THIS 0?
063432	001403				BEQ	5\$;;BR IF YES
063434	005204			4\$:	INC	R4	;;DON'T SUPPRESS ANYMORE 0'S

063436	052703	000060		BIS	#'0,R3	::MAKE THIS DIGIT ASCII
063442	052703	000040	5\$:	BIS	#',R3	::MAKE ASCII IF NOT ALREADY
063446	110337	063512		MOVB	R3,8\$::SAVE FOR TYPING
063452	104401	063512		TYPE	,8\$::GO TYPE THIS DIGIT
063456	105337	063514	7\$:	DECB	\$OCNT	::COUNT BY 1
063462	003747			BGT	2\$::BR IF MORE TO DO
063464	002402			BLT	0\$::BR IF DONE
063466	005204			INC	R4	::INSURE LAST DIGIT ISN'T A BLANK
063470	000744			BR	2\$::GO DO THE LAST DIGIT
063472	012605		6\$:	MOV	(S)+,R5	::RESTORE R5
063474	012604			MOV	(SP)+,R4	::RESTORE R4
063476	012603			MOV	(SP)+,R3	::RESTORE R3
063500	016666	000002 000004		MOV	2(SP),4(SP)	::SET THE STACK FOR RETURNING
063506	012616			MOV	(SP)+,(SP)	
063510	000002			RTI		::RETURN
063512	000		8\$:	.BYTE	0	::STORAGE FOR ASCII DIGIT
063513	000			.BYTE	0	::TERMINATOR FOR TYPE ROUTINE
063514	000		\$OCNT:	.BYTE	0	::OCTAL DIGIT COUNTER
063515	000		\$OFILL:	.BYTE	0	::ZERO FILL SWITCH
063516	000000		\$OMODE:	.WORD	0	::NUMBER OF DIGITS TO TYPE

.SBTIL TYPE ROUTINE

```

*****
*ROUTINE TO TYPE ASCIZ MESSAGE. MESSAGE MUST TERMINATE WITH A 0 BYTE.
*THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED.
*NOTE1: $NULL CONTAINS THE CHARACTER TO BE USED AS THE FILLER CHARACTER.
*NOTE2: $FILLS CONTAINS THE NUMBER OF FILLER CHARACTERS REQUIRED.
*NOTE3: $FILLC CONTAINS THE CHARACTER TO FILL AFTER.

```

```

*CALL:
*1) USING A TRAP INSTRUCTION
* TYPE ,MESADR ;:MESADR IS FIRST ADDRESS OF AN ASCIZ STRING
*OR
* TYPE
* MESADR

```

063520	105737	001173	\$TYPE:	TSTB	\$TPFLG	:: IS THERE A TERMINAL?
063524	100002			BPL	1\$:: BR IF YES
063526	000000			HALT		:: HALT HERE IF NO TERMINAL
063530	000430			BR	3\$:: LEAVE
063532	010046		1\$:	MOV	RO,-(SP)	:: SAVE RO
063534	017600	000002		MOV	@2(SP),RO	:: GET ADDRESS OF ASCIZ STRING
063540	122737	000001 .001242		CMPB	#APTENV,\$ENV	:: RUNNING IN APT MODE
063546	001011			BNE	62\$:: NO,GO CHECK FOR APT CONSOLE
063550	132737	000100 001243		BITB	#APTSPOOL,\$ENVM	:: SPOOL MESSAGE TO APT
063556	001405			BEQ	62\$:: NO,GO CHECK FOR CONSOLE
063560	010037	063570		MOV	RO,61\$:: SETUP MESSAGE ADDRESS FOR APT
063564	004737	070166		JSR	PC,\$ATY3	:: SPOOL MESSAGE TO APT
063570	000000		61\$:	.WORD	0	:: MESSAGE ADDRESS
063572	132737	000040 001243	62\$:	BITB	#APTCSUP,\$ENVM	:: APT CONSOLE SUPPRESSED
063600	001003			BNE	60\$:: YES,SKIP TYPE OUT
063602	112046		2\$:	MOVB	(RO)+,-(SP)	:: PUSH CHARACTER TO BE TYPED ONTO STACK
063604	001005			BNE	4\$:: BR IF IT ISN'T THE TERMINATOR
063606	005726			TST	(SP)+	:: IF TERMINATOR POP IT OFF THE STACK
063610	012600		60\$:	MOV	(SP)+,RO	:: RESTORE RO
063612	062716	000002	3\$:	ADD	#2,(SP)	:: ADJUST RETURN PC
063616	000002			RTI		:: RETURN
063620	122716	000011	4\$:	CMPB	#HT,(SP)	:: BRANCH IF <HT>
063624	001430			BEQ	8\$	
063626	122716	000200		CMPB	#CRLF,(SP)	:: BRANCH IF NOT <CRLF>
063632	001006			BNE	5\$	
063634	005726			TST	(SP)+	:: POP <CR><LF> EQUIV
063636	104401			TYPE		:: TYPE A CR AND LF
063640	001217			\$CRLF		
063642	105037	064050		CLRB	\$CHARCNT	:: CLEAR CHARACTER COUNT
063646	000755			BR	2\$:: GET NEXT CHARACTER
063650	004737	063732	5\$:	JSR	PC,\$TYPEC	:: GO TYPE THIS CHARACTER
063654	123726	001172	6\$:	CMPB	\$FILLC,(SP)+	:: IS IT TIME FOR FILLER CHARS.?
063660	001350			BNE	2\$:: IF NO GO GET NEXT CHAR.
063662	013746	001170		MOV	\$NULL,-(SP)	:: GET # OF FILLER CHARS. NEEDED
						:: AND THE NULL CHAR.
063666	105366	000001	7\$:	DECB	1(SP)	:: DOES A NULL NEED TO BE TYPED?
063672	002770			BLT	6\$:: BR IF NO--GO POP THE NULL OFF OF STACK
063674	004737	063732		JSR	PC,\$TYPEC	:: GO TYPE A NULL
063700	105337	064050		DECB	\$CHARCNT	:: DO NOT COUNT AS A COUNT
063704	000770			BR	7\$:: LOOP

;HORIZONTAL TAB PROCESSOR

063706	112716	000040		8\$:	MOVB	#' ,(SP)	::REPLACE TAB WITH SPACE
063712	004737	063732		9\$:	JSR	PC,\$TYPEC	::TYPE A SPACE
063716	132737	000007	064050		BITB	#7,\$CHARCNT	::BRANCH IF NOT AT
063724	001372				BNE	9\$::TAB STOP
063726	005726				TST	(SP)+	::POP SPACE OFF STACK
063730	000724				BR	2\$::GET NEXT CHARACTER
063732				\$TYPEC:			
063732	105777	115222			TSTB	@\$TKS	::CHAR IN KYBD BUFFER?
063736	100022				BPL	10\$::BR IF NOT
063740	017746	115216			MOV	@\$TKB,-(SP)	::GET CHAR
063744	042716	177600			BIC	#177600,(SP)	::STRIP EXTRANEIOUS BITS
063750	122716	000023			CMPB	#\$XOFF,(SP)	::WAS CHAR XOFF
063754	001012				BNE	102\$::BR IF NOT
063756				101\$:			
063756	105777	115176			TSTB	@\$TKS	::WAIT FOR CHAR
063762	100375				BPL	101\$	
063764	117716	115172			MOVB	@\$TKB,(SP)	::GET CHAR
063770	042716	177600			BIC	#177600,(SP)	::STRIP IT
063774	122716	000021			CMPB	#\$XON,(SP)	::WAS IT XON?
064000	001366				BNE	101\$::BR IF NOT
064002				102\$:			
064002	005726				TST	(SP)+	::FIX STACK
064004				10\$:			
064004	105777	115154			TSTB	@\$TPS	::WAIT UNTIL PRINTER IS READY
064010	100375				BPL	10\$	
064012	116677	000002	115146		MOVB	2(SP),@\$TPB	::LOAD CHAR TO BE TYPED INTO DATA REG.
064020	122766	000015	000002		CMPB	#CR,2(SP)	::IS CHARACTER A CARRIAGE RETURN?
064026	001003				BNE	1\$::BRANCH IF NO
064030	105037	064050			CLRB	\$CHARCNT	::YES--CLEAR CHARACTER COUNT
064034	000406				BR	\$TYPEX	::EXIT
064036	122766	000012	000002	1\$:	CMPB	#LF,2(SP)	::IS CHARACTER A LINE FEED?
064044	001402				BEQ	\$TYPEX	::BRANCH IF YES
064046	105227				INCB	(PC)+	::COUNT THE CHARACTER
064050	000000			\$CHARCNT:	.WORD	0	::CHARACTER COUNT STORAGE
064052	000207			\$TYPEX:	RTS	PC	

.SBTTL SCOPE HANDLER ROUTINE

*THIS ROUTINE CONTROLS THE LOOPING OF SUBTESTS. IT WILL INCREMENT
*AND LOAD THE TEST NUMBER(\$TSTNM) INTO THE DISPLAY REG.(DISPLAY<7:0>)
*AND LOAD THE ERROR FLAG (\$ERFLG) INTO DISPLAY<15:08>
*THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
*SW14=1 LOOP ON TEST
*SW11=1 INHIBIT ITERATIONS
*SW09=1 LOOP ON ERROR
*SW08=1 LOOP ON TEST IN SWR<7:0>
*CALL
* SCOPE ;:SCOPE-IOT

```
064054          $SCOPE:          CKSWR          ;:TEST FOR CHANGE IN SOFT-SWR
064054 104410          JSR          PC_STOP          ;:
064056 004737 064612          BIT          #BIT14,@SWR          ;:LOOP ON PRESENT TEST?
064062 032777 040000 115064 1$:          BEQ          9$          ;:NO IF SW14=0
064070 001402          JMP          $OVER          ;:JUMP OVER SCOPE ROUTINE
064072 000137 064522          ;:
064076          9$:          ;:
064076 000416          ;:#####START OF CODE FOR THE XOR TESTER#####
          $XTSTR: BR          6$          ;:IF RUNNING ON THE 'XOR' TESTER CHANGE
          ;:THIS INSTRUCTION TO A 'NOP' (NOP=240)
064100 013746 000004          MOV          @#ERRVEC,-(SP)          ;:SAVE THE CONTENTS OF THE ERROR VECTOR
064104 012737 064124 000004          MOV          #5$,@#ERRVEC          ;:SET FOR TIMEOUT
064112 005737 177060          TST          @#177060          ;:TIME OUT ON XOR?
064116 012637 000004          MOV          (SP)+,@#ERRVEC          ;:RESTORE THE ERROR VECTOR
064122 000561          BR          $$VLAD          ;:GO TO THE NEXT TEST
064124 022626          5$:          CMP          (SP)+,(SP)+          ;:CLEAR THE STACK AFTER A TIME OUT
064126 012637 000004          MOV          (SP)+,@#ERRVEC          ;:RESTORE THE ERROR VECTOR
064132 000521          BR          7$          ;:LOOP ON THE PRESENT TEST
064134          6$:;#####END OF CODE FOR THE XOR TESTER#####
064134 032777 000400 115012          BIT          #BIT08,@SWR          ;:LOOP ON SPEC. TEST?
064142 001421          BEQ          2$          ;:BR IF NO
064144 005046          CLR          -(SP)          ;:CLEAR A TEMP. LOCATION
064146 117716 115002          MOVB         @SWR,(SP)          ;:PICKUP THE DESIRED TEST NUMBER
064152 001414          BEQ          8$          ;:BRANCH IF BAD TEST NUMBER IN SWR
064154 022716 000025          CMP          #25,(SP)          ;:CHECK THE NUMBER IN THE SWR
064160 002411          BLT          8$          ;:BRANCH IF TEST NUMBER IS OUT OF RANGE
064162 011637 001116          MOV          (SP),$TSTNM          ;:UPDATE THE TEST NUMBER
064166 005316          DEC          (SP)          ;:BACKUP BY ONE
064170 006316          ASL          (SP)          ;:SCALE THE TEST NUMBER AS AN INDEX
064172 062716 064540          ADD          #$$SW08TBL,(SP)          ;:FORM THE ADDRESS OF TEST POINTER
064176 013637 001122          MOV          @(SP)+,$LPADR          ;:SET LOOP ADDRESS TO DESIRED TEST
064202 000547          BR          $OVER          ;:GO LOOP ON THE TEST
064204 005726          8$:          TST          (SP)+          ;:CLEAN THE BAD TEST NUMBER OFF OF THE STACK
064206 105737 001117          2$:          TSTB         $ERFLG          ;:HAS AN ERROR OCCURRED?
064212 001502          BEQ          3$          ;:BR IF NO
064214 022737 177777 065230          CMP          #-1,CPSAVE          ;:SEE IF TIMEOUT WAS PREVIOUSLY RECORDED
064222 001455          BEQ          2003$          ;:KICK AROUND ROUTINE IF SO
064224 013746 000004          MOV          ERRVEC,-(SP)          ;:SAVE CONTENTS OF ERROR VECTOR
064230 012737 064246 000004          MOV          #2000$,ERRVEC          ;:SETUP 'TRAP' RETURN ADDRESS
064236 013737 177766 065230          MOV          177766,CPSAVE          ;:MOVE CPU ERROR REGISTER TO CPSAVE FOR TEST
064244 000406          BR          2001$          ;:
064246 012737 177777 065230 2000$:          MOV          #-1,CPSAVE          ;:SET CPU ERROR REGISTER TIMEOUT INDICATOR
064254 012716 064262          MOV          #2001$,(SP)          ;:SETUP RETURN ADDRESS
```

```

SCOPE HANDLER ROUTINE

064260 000002 RTI
064262 012637 C00004 2001$: MOV (SP)+,ERRVEC ;;RESTORE CONTENTS OF ERROR VECTOR

064266 022737 177777 065230 2002$: CMP #-1,CPSAVE ;;SEE IF CPSAVE HAS CPU ERR REG TIMEOUT INDICATION
064274 001430 BEQ 2003$ ;;BRANCH IF SO
064276 032737 000001 065230 BIT #BIT00,CPSAVE ;;SEE IF THE POWER MONITOR BIT IS ON
064304 001424 BEQ 2003$ ;;BRANCH TO CONTINUE ROUTINE IF CLEAR
064306 042737 000001 177766 BIC #BIT00,177766 ;;CLEAR THE BIT FOUND TO BE SET
064314 013746 001154 MOV SWR,-(SP) ;;SAVE SWR ADDRESS
064320 017646 000000 MOV @ (SP),-(SP) ;;SAVE SWR VALUE
064324 012737 000176 001154 MOV #176,SWR ;;GET SOFTWARE SWR ADDRESS
064332 011677 114616 MOV (SP),@SWR ;;GET CURRENT SWR VALUE
064336 042777 001000 114610 BIC #BIT09,@SWR ;;DON'T ALLOW LOOP ON ERROR ON THIS ERROR
064344 104177 EMT 177 ;;CALL SPECIAL POWER FAIL BIT ERROR CALL
064346 012676 000000 MOV (SP)+,@(SP) ;;RESTORE SWR TO ORIGINAL VALUE
064352 012637 001154 MOV (SP)+,SWR ;;RESTORE SWR ADDRESS
064356 2003$:
064356 123737 001131 001117 CMPB $ERMAX,$ERFLG ;;MAX. ERRORS FOR THIS TEST OCCURRED?
064364 101015 BHI 3$ ;;BR IF NO
064366 032777 001000 114560 BIT #BIT09,@SWR ;;LOOP ON ERROR?
064374 001404 BEQ 4$ ;;BR IF NO
064376 013737 001124 001122 7$: MOV $LPERR,$LPADR ;;SET LOOP ADDRESS TO LAST SCOPE
064404 000446 BR $OVER
064406 105037 001117 4$: CLRB $ERFLG ;;ZERO THE ERROR FLAG
064412 005037 001206 CLR $TIMES ;;CLEAR THE NUMBER OF ITERATIONS TO MAKE
064416 000415 BR 1$ ;;ESCAPE TO THE NEXT TEST
064420 032777 004000 114526 3$: BIT #BIT11,@SWR ;;INHIBIT ITERATIONS?
064426 001011 BNE 1$ ;;BR IF YES
064430 005737 001230 TST $PASS ;;IF FIRST PASS OF PROGRAM
064434 001406 BEQ 1$ ;; INHIBIT ITERATIONS
064436 005237 001120 INC $ICNT ;;INCREMENT ITERATION COUNT
064442 023737 001206 001120 CMP $TIMES,$ICNT ;;CHECK THE NUMBER OF ITERATIONS MADE
064450 002024 BGE $OVER ;;BR IF MORE ITERATION REQUIRED
064452 012737 000001 001120 1$: MOV #1,$ICNT ;;REINITIALIZE THE ITERATION COUNTER
064460 013737 064536 001206 MOV $MXCNT,$TIMES ;;SET NUMBER OF ITERATIONS TO DO
064466 105237 001116 $SVLAD: INCB $TSTNM ;;COUNT TEST NUMBERS
064472 113737 001116 001226 MOVB $TSTNM,$TESTN ;;SET TEST NUMBER IN APT MAILBOX
064500 011637 001122 MOV (SP),$LPADR ;;SAVE SCOPE LOOP ADDRESS
064504 011637 001124 MOV (SP),$LPERR ;;SAVE ERROR LOOP ADDRESS
064510 005037 001210 CLR $ESCAPE ;;CLEAR THE ESCAPE FROM ERROR ADDRESS
064514 112737 000001 001131 MOVB #1,$ERMAX ;;ONLY ALLOW ONE(1) ERROR ON NEXT TEST
064522 013777 001116 114426 $OVER: MOV $TSTNM,@DISPLAY ;;DISPLAY TEST NUMBER
064530 013716 001122 MOV $LPADR,(SP) ;;FUDGE RETURN ADDRESS
064534 000002 RTI ;;FIXES PS
064536 000005 $MXCNT: 5. ;;MAX. NUMBER OF ITERATIONS
064540 $SW08TBL:
.REPT $TN-1
064540 010070 .WORD TST1+2 ;;STARTING ADDRESS OF TEST 1
064542 010270 .WORD TST2+2 ;;STARTING ADDRESS OF TEST 2
064544 011276 .WORD TST3+2 ;;STARTING ADDRESS OF TEST 3
064546 012254 .WORD TST4+2 ;;STARTING ADDRESS OF TEST 4
064550 013450 .WORD TST5+2 ;;STARTING ADDRESS OF TEST 5
064552 014456 .WORD TST6+2 ;;STARTING ADDRESS OF TEST 6
064554 015434 .WORD TST7+2 ;;STARTING ADDRESS OF TEST 7
064556 016632 .WORD TST10+2 ;;STARTING ADDRESS OF TEST 10
064560 017636 .WORD TST11+2 ;;STARTING ADDRESS OF TEST 11
064562 021062 .WORD TST12+2 ;;STARTING ADDRESS OF TEST 12

```

064564	022270		.WORD	TST13+2	:: STARTING ADDRESS OF TEST 13
064566	023312		.WORD	TST14+2	:: STARTING ADDRESS OF TEST 14
064570	025160		.WORD	TST15+2	:: STARTING ADDRESS OF TEST 15
064572	026564		.WORD	TST16+2	:: STARTING ADDRESS OF TEST 16
064574	027604		.WORD	TST17+2	:: STARTING ADDRESS OF TEST 17
064576	030522		.WORD	TST20+2	:: STARTING ADDRESS OF TEST 20
064600	031560		.WORD	TST21+2	:: STARTING ADDRESS OF TEST 21
064602	032564		.WORD	TST22+2	:: STARTING ADDRESS OF TEST 22
064604	033572		.WORD	TST23+2	:: STARTING ADDRESS OF TEST 23
064606	034600		.WORD	TST24+2	:: STARTING ADDRESS OF TEST 24
064610	035626		.WORD	TST25+2	:: STARTING ADDRESS OF TEST 25
2					
3					
4					
5	064612				
	064612	012746	000140		
	064616	012746	064624		
	064622	000002			
	064624				
6					
7					
8					
9	064624	012746	000240		
	064630	012746	064636		
	064634	000002			
	064636				
10	064636	000207			


```

;DROP PRIORITY TO ALLOW CONSOLE INTERRUPT

STOP:
      MOV     #PR3,-(SP)      ;;PUT NEW PS ON STACK
      MOV     #64$,-(SP)    ;;PUT NEW PC ON STACK
      RTI                          ;;POP NEW PC AND PS
64$:

;RAISE PRIORITY TO INHIBIT CONSOLE INTERRUPT

      MOV     #PR5,-(SP)    ;;PUT NEW PS ON STACK
      MOV     #65$,-(SP)    ;;PUT NEW PC ON STACK
      RTI                          ;;POP NEW PC AND PS
65$:

      RTS     PC              ;RETURN
  
```


.SBTTL ERROR HANDLER ROUTINE

```

*****
*THIS ROUTINE WILL INCREMENT THE ERROR FLAG AND THE ERROR COUNT,
*SAVE THE ERROR ITEM NUMBER AND THE ADDRESS OF THE ERROR CALL
*AND GO TO ERRTP ON ERROR
*THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
*SW15=1      HALT ON ERROR
*SW13=1      INHIBIT ERROR TYPEOUTS
*SW10=1      BELL ON ERROR
*SW09=1      LOOP ON ERROR
*CALL
*          ERROR      N          ;;ERROR=EMT AND N=ERROR ITEM NUMBER
  
```

```

064640 105037 065232 $ERROR: CLRB      IBSAVE      ;;CLEAR THE ITEM BYTE SAVE LOCATION
064644 104410          CKSWR      ;;TEST FOR CHANGE IN SOFT-SWR
064646 105237 001117 7$:      INCB      $ERFLG      ;;SET THE ERROR FLAG
064652 001775          BEQ      7$      ;;DON'T LET THE FLAG GO TO ZERO
064654 013777 001116 114274 MOV      $STNM,@DISPLAY ;;DISPLAY TEST NUMBER AND ERROR FLAG
064662 032777 002000 114264 BIT      #BIT10,@SWR    ;;BELL ON ERROR?
064670 001402          BEQ      1$      ;;NO - SKIP
064672 104401 001212          TYPE      $BELL      ;;RING BELL
064676 005237 001126 1$:      INC      $ERTTL     ;;COUNT THE NUMBER OF ERRORS
064702 011637 001132          MOV      (SP),$ERRPC  ;;GET ADDRESS OF ERROR INSTRUCTION
064706 162737 000002 001132 SUB      #2,$ERRPC
064714 117737 114212 001130 MOV      @ERRPC,$ITEMB  ;;STRIP AND SAVE THE ERROR ITEM CODE
064722 032777 001000 114224 BIT      #BIT09,@SWR   ;;SEE IF LOOP ON ERROR IS SET
064730 001060          BNE      1004$    ;;BRANCH AROUND ROUTINE IF SO
064732 122737 000177 001130 CMP      #177,$ITEMB   ;;SEE IF THIS IS THE POWER FAIL CALL
064740 001454          BEQ      1004$    ;;BRANCH AROUND ROUTINE IF IT IS
064742 105737 065232          TSTB     IBSAVE     ;;SEE IF THIS IS THE 2ND ERROR CALL IN THIS ROUTINE
064746 001047          BNE      1003$    ;;BRANCH IF SO
064750 022737 177777 065230 CMP      #-1,CPSAVE   ;;SEE IF CPSAVE HAS CPU ERR REG TIMEOUT INDICATION
064756 001445          BEQ      1004$    ;;BRANCH IF SO
064760 013746 000004          MOV      ERRVEC,-(SP)  ;;SAVE CONTENTS OF ERROR VECTOR
064764 012737 065002 000004 MOV      #1000$,ERRVEC ;;SETUP 'TRAP' RETURN ADDRESS
064772 013737 177766 065230 MOV      177766,CPSAVE ;;MOVE CPU ERROR REGISTER TO CPSAVE FOR TEST
065000 000406          BR      1001$
065002 012737 177777 065230 1000$: MOV      #-1,CPSAVE   ;;SET CPU ERROR REGISTER TIMEOUT INDICATOR
065010 012716 065016          MOV      #1001$,(SP)  ;;SETUP RETURN ADDRESS
065014 000002          RTI
065016 012637 000004 1001$: MOV      (SP)+,ERRVEC  ;;RESTORE CONTENTS OF ERROR VECTOR

065022 022737 177777 065230 1002$: CMP      #-1,CPSAVE   ;;SEE IF CPSAVE HAS CPU ERR REG TIMEOUT INDICATION
065030 001420          BEQ      1004$    ;;BRANCH IF SO
065032 032737 000001 065230 BIT      #BIT00,CPSAVE  ;;SEE IF POWER MONITOR BIT IS SET IN CPU ERR REG
065040 001414          BEQ      1004$    ;;BRANCH IF OK
065042 042737 000001 177766 BIC      #BIT00,177766 ;;CLEAR THE BIT FOUND SET
065050 113737 001130 065232 MOV      $ITEMB,IBSAVE ;;MAKE IBSAVE NON-ZERO FOR DUAL ERROR CALL
065056 112737 000177 001130 MOV      #177,$ITEMB   ;;SET $ITEMB TO SPECIAL POWER FAIL POINTER
065064 000402          BR      1004$    ;;BRANCH OVER IBSAVE CLEARING

065066 105037 065232 1003$: CLRB      IBSAVE     ;;CLEAR IBSAVE SO 2ND TIME THROUGH EXITS
065072 032777 020000 114054 1004$: BIT      #BIT13,@SWR  ;;SKIP TYPEOUT IF SET
065100 001004          BNE      20$      ;;SKIP TYPEOUTS
065102 004737 065234          JSR      PC,ERRTP   ;;GO TO USER ERROR ROUTINE
  
```

065106	104401	001217		TYPE	.,SCLRF	
065112			20\$:			
065112	122737	000001	001242	CMPB	#APTENV,\$ENV	::RUNNING IN APT MODE
065120	001007			BNE	2\$::NO,SKIP APT ERROR REPORT
065122	113737	001130	065134	MOVB	\$ITEMB,21\$::SET ITEM NUMBER AS ERROR NUMBER
065130	004737	070176		JSR	PC,\$ATY4	::REPORT FATAL ERROR TO APT
065134	000		21\$:	.BYTE	0	
065135	000			.BYTE	0	
065136	000777		22\$:	BR	22\$::APT ERROR LOOP
065140	105737	065232	2\$:	TSTB	IBSAVE	::SEE IF IBSAVE IS LOADED
065144	001005			BNE	3\$::BRANCH IF NOT - NO HALT ON PWR MON BIT ERROR
065146	005777	114002		TST	@SWR	::HALT ON ERROR
065152	100002			BPL	3\$::SKIP IF CONTINUE
065154	000000			HALT		::HALT ON ERROR.
065156	104410			CKSWR		::TEST FOR CHANGE IN SOFT-SWR
065160			3\$:			
065160	032777	001000	113766	BIT	#BIT09,@SWR	::LOOP ON ERROR SWITCH SET?
065166	001402			BEQ	4\$::BR IF NO
065170	013716	001124		MOV	\$LPERR,(SP)	::FUDGE RETURN FOR LOOPING
065174	005737	001210	4\$:	TST	\$ESCAPE	::CHECK FOR AN ESCAPE ADDRESS
065200	001402			BEQ	5\$::BR IF NONE
065202	013716	001210		MOV	\$ESCAPE,(SP)	::FUDGE RETURN ADDRESS FOR ESCAPE
065206			5\$:			
065206	022737	037242	000042	CMP	#SENDAD,@#42	::ACT-11 AUTO-ACCEPT?
065214	001001			BNE	6\$::BRANCH IF NO
065216	000000			HALT		::YES
065220			6\$:			
065220	105737	065232		TSTB	IBSAVE	::SEE IF ITEM BYTE SAVE LOCATION HAS AN ERROR CALL
065224	001210			BNE	7\$::BRANCH BACK TO CALL ORIGINAL ERROR
065226	000002			RTI		::RETURN
065230	000000			CPSAVE: .WORD	0	::LOCATION TO SAVE CPU ERROR REG CONTENTS
065232	000000			IBSAVE: .WORD	0	::LOCATION TO SAVE ITEM BYTE

.SBTTL ERROR TYPEOUT ROUTINE

```

: *THE ERROR TYPEOUT ROUTINE ASSEMBLES AND PRINTS INFORMATION
: *REGARDING THE DETECTION OF AN ERROR AS FOLLOWS:
: *
: *   .UNIT NUMBER, DRIVE TYPE, TEST NUMBER, ERROR NUMBER AND
: *   .PROGRAM COUNTER ARE PRINTED ON THE FIRST LINE;
: *   .ERROR MESSAGE IS ASSEMBLED, FORMATTED AND PRINTED ON
: *   .ONE OR MORE SUCCEEDING LINES;
: *   .PAIRED LINES OF ERROR HEADERS AND ERROR DATA ARE PRINTED
: *   .AFTER THE ERROR MESSAGE.
  
```

3
 4
 5
 6
 7
 8
 9
 10
 11
 12
 13
 14
 15
 16
 17
 18
 19
 20
 21
 22

 23
 24
 25
 26
 27
 28
 29
 30
 31
 32
 33
 34
 35
 36
 37
 38
 39
 40
 41
 42
 43
 44
 45
 46
 47

 48
 49

```

065234 104414
065236 032777 020000 113710
065244 001402
065246 000137 066074
  

065252 104401 001217
065256 104401 066110
065262 013746 001234
  

065266 104403
065270 003
065271 000
  

065272 013700 001276
065276 016000 000026
065302 042700 177740
065306 012737 071453 065360
065314 022700 000024
065320 001414
  

065322 012737 071446 065360
065330 022700 000025
065334 001406
  

065336 012737 071460 065360
065344 022700 000027
065350 001004
065352 104401 066145
065356 104401
065360 000000
  

065404 104403
065406 003
065407 000
065410 005037 066102
065414 113737 001130 066102
  
```

```

ERRRYP: SAVREG
BIT #SW13,@SWR ;INHIBIT TYPEOUTS??
BEQ 1$ ;NO.
JMP 27$ ;YES!!

:TYPE UNIT NUMBER, DRIVE TYPE, TEST NUMBER, ERROR NUMBER, AND
:PROGRAM COUNTER
1$: TYPE .%SRLF ;TYPE 'DRV#'
TYPE .ERTY00 ;:SAVE $UNIT FOR TYPEOUT
MOV $UNIT,-(SP) ;:TYPE DRIVE NUMBER
;:GO TYPE--OCTAL ASCII
TYPOS ;:TYPE 3 DIGIT(S)
.BYTE 3 ;:SUPPRESS LEADING ZEROS
.BYTE 0

:TYPE 'DRIVE TYPE' RM05, RM03 OR RM02 FOR UNIT UNDER TEST
MOV $BASE,R0 ;GET RM BASE ADDRESS
MOV RMDT(R0),R0 ;GET DRIVE TYPE REGISTER
BIC #177740,R0 ;SAVE DRIVE TYPE BITS AND
MOV #$RM03,3$ ;GET ASCII DRIVE TYPE
CMP #24,R0 ;IS DEVICE AN RM03 ?
BEQ 2$ ;YES !!

MOV #$RM02,3$ ;SAVE ASCII DRIVE TYPE
CMP #25,R0 ;IS DEVICE AN RM02 ?
BEQ 2$ ;YES !!

MOV #$RM05,3$ ;SAVE ASCII DRIVE TYPE
CMP #27,R0 ;IS DEVICE AN RM05 ?
BNE 4$ ;NO !!
2$: TYPE " - " ;TYPE DRIVE TYPE
TYPE .ERTY05 ;DRIVE TYPE MESSAGE IS STORED HERE
3$: .WORD 0

:TYPE TEST NUMBER, ERROR NUMBER AND PROGRAM COUNTER
4$: CLR TSTNMB ;LOAD TEST NUMBER FOR
MOV $TESTN,TSTNMB ;TYPE "TST#"
YPE .ERTY01 ;:SAVE TSTNMB FOR TYPEOUT
MOV TSTNMB,-(SP) ;:TYPE TEST NUMBER
;:GO TYPE--OCTAL ASCII
TYPOS ;:TYPE 3 DIGIT(S)
.BYTE 3 ;:SUPPRESS LEADING ZEROS
.BYTE 0 ;LOAD ERROR NUMBER FOR
CLR ERRNMB ;TYPEOUT
MOV $ITEMB,ERRNMB
  
```

```

ERROR TYPEOUT ROUTINE

50 065422 001406      BEQ      5$      ;SKIP IF NO ERROR CALLED
51 065424 104401 066125  TYPE     ,ERTY02 ;TYPE "ERR"
52 065430 013746 066102  MOV     ERRNMB,-(SP) ;SAVE ERRNMB FOR TYPEOUT
                                ;TYPE ERROR NUMBER
                                ;GO TYPE--OCTAL ASCII
                                ;TYPE 3 DIGIT(S)
                                ;SUPPRESS LEADING ZEROS
                                ;TYPE 'PC='
                                ;SAVE $ERRPC FOR TYPEOUT
                                ;TYPE PROGRAM COUNTER
                                ;GO TYPE--OCTAL ASCII
                                ;TYPE 6 DIGIT(S)
                                ;TYPE LEADING ZEROS

    065434 104403      TYPOS
    065436      003      .BYTE 3
    065437      000      .BYTE 0
53 065440 104401 066134 5$:     TYPE     ,ERTY03 ;TYPE 'PC='
54 065444 013746 001132  MOV     $ERRPC,-(SP) ;SAVE $ERRPC FOR TYPEOUT
                                ;TYPE PROGRAM COUNTER
                                ;GO TYPE--OCTAL ASCII
                                ;TYPE 6 DIGIT(S)
                                ;TYPE LEADING ZEROS

    065450 104403      TYPOS
    065452      006      .BYTE 6
    065453      001      .BYTE 1

55
56 ;GENERATE POINTER TO ERROR TABLE UNLESS ERROR NUMBER IS 0
57 065454 005737 066102 6$:     TST     ERRNMB ;WAS AN ERROR CALLED?
58 065460 001002      BNE     7$      ;BR IF YES
59 065462 000137 066074      JMP     27$     ;NO--EXIT

60
61 065466 104401 001217 7$:     TYPE     ,$CRLF ;YES-TYPE CRLF
62 065472 105037 066106      CLRB   BOTFLG ;CLEAR BOT FLAG
63 065476 105037 066107      CLRB   CHRCNT ;CLEAR CHARACTER COUNTER
64 065502 013700 066102      MOV     ERRNMB,R0 ;R0 POINTS TO FIRST OF
65 065506 122700 000177      CMPB   #177,R0 ;SEE IF THIS ERROR CALL IS SPECIAL POWER FAIL CALL
66 065512 001003      BNE     8$      ;BRANCH IF NOT
67 065514 012700 066152      MOV     #PFECH,R0 ;MOVE POWER FAIL ERROR CALL TABLE TO R0
68 065520 000405      BR     9$
69 065522 006300      8$:     ASL     R0 ;FOUR ENTRIES IN ERROR
70 065524 006300      ASL     R0 ;TABLE
71 065526 006300      ASL     R0
72 065530 062700 001572      ADD     #SERRTB-8.,R0
73 065534 011001      9$:     MOV     (R0),R1 ;R1 POINTS TO ERROR MESSAGE
74 ;TABLE
75 065536 001507      BEQ     19$     ;BRANCH IF NO ERROR MESSAGE
76
77 ;TYPE THE ERROR MESSAGE
78 065540 012102      10$:    MOV     (R1)+,R2 ;R2-ADDRESS OF MESSAGE STRING
79 065542 001505      BEQ     19$     ;BRANCH IF END OF MESSAGE
80 065544 010237 065712      MOV     R2,18$ ;LOAD ADDRESS OF STRING
81 065550 005037 066104      CLR   BOTADR ;CLEAR BOT ADDRESS
82 065554 112203      11$:    MOVB   (R2)+,R3 ;END OF STRING??
83 065556 001454      BEQ     17$     ;YES!!
84 065560 122703 000015      CMPB   #CR,R3 ;CARRIAGE RETURN??
85 065564 001003      BNE     12$     ;NO!!
86 065566 105037 066107      CLRB   CHRCNT ;YES-CLEAR CHAR COUNT
87 065572 000770      BR     11$     ;GET NEXT CHARACTER
88 065574 122703 000012      12$:    CMPB   #LF,R3 ;LINE FEED??
89 065600 001765      BEQ     11$     ;YES-GET NEXT CHARACTER
90 065602 122703 000011      CMPB   #HT,R3 ;HORIZONTAL TAB??
91 065606 001007      BNE     14$     ;NO..
92 065610 005237 066107      13$:    INCB   CHRCNT ;ADJUST CHARACTER COUNT
93 065614 132737 000007 066107      BITB   #7,CHRCNT
94 065622 001372      BNE     13$
95 065624 000407      BR     15$
96 065626 105237 066107      14$:    INCB   CHRCNT ;INCREMENT CHARACTER COUNT
97 065632 122703 000040      CMPB   #' ',R3 ;SPACE??
98 065636 001002      BNE     15$     ;NO.

```

```

99 065640 010237 066104      MOV      R2,BOTADR      ;SAVE ADDRESS OF SPACE
100 065644 122737 C00100 066107 15$: CMPB    #64.,CHRCNT    ;END OF LINE??
101 065652 103340      BHIS    11$            ;NO. !
102 065654 013704 066104      MOV      BOTADR,R4     ;GET ADDRESS OF LAST SPACE
103 065660 001007      BNE     16$            ;BRANCH IF SPACE DETECTED
104 065662 104401 001217      TYPE    ,SCRLF        ;TYPE CRLF
105 065666 105037 066107      CLRB   CHRCNT         ;CLEAR CHARACTER COUNT
106 065672 013702 065712      MOV     18$,R2        ;SET UP R2 FOR TESTING
107 065676 000726      BR     11$            ;
108 065700 105044      CLRB   -(R4)         ;REPLACE SPACE
109 065702 112737 177777 066106 16$: MOVB  #-1,BOTFLG     ;SET BOT FLAG
110 065710 104401      TYPE    ,SCRLF        ;TYPE ERROR MESSAGE STRING
111 065712 000000      .WORD  ,STRING        ;STRING ADDRESS GOES HERE
112 065714 105737 066106 18$: TSTB  BOTFLG         ;WAS STRING TRUNCATED??
113 065720 001707      BEQ    10$            ;NO!!
114 065722 104401 001217      TYPE    ,SCRLF        ;YES-TYPE CRLF
115 065726 105037 066106      CLRB   BOTFLG        ;CLEAR BOT FLAG
116 065732 105037 066107      CLRB   CHRCNT        ;CLEAR CHARACTER COUNT
117 065736 013702 066104      MOV     BOTADR,R2     ;SETUP R2 FOR TESTING
118 065742 010237 065712      MOV     R2,18$        ;SETUP 18$ FOR TYPING
119 065746 112742 000040      MOVB   #'-(R2)        ;RESTORE SPACE
120 065752 105722      TSTB   (R2)+         ;RESTORE R2
121 065754 000677      BR     11$            ;TYPE REST OF STRING
122
123      ;TYPE ERROR HEADER AND ERROR DATA
124 065756 016001 000002 19$: MOV     2(R0),R1     ;R1 POINTS TO ERROR HEADER TABLE
125 065762 001444      BEQ    27$            ;BRANCH IF NO HEADER
126 065764 104401 001217      TYPE    ,SCRLF        ;(ASSUME NO DATA)
127 065770 016002 000004      MOV     4(R0),R2     ;R2 POINTS TO DATA ADDRESS TABLE
128 065774 016003 000006      MOV     6(R0),R3     ;R3 POINTS TO FORMAT TABLE
129 066000 012137 066010 20$: MOV     (R1)+,21$     ;PUT HEADER ADDRESS FOR TYPE
130 066004 001433      BEQ    27$            ;BRANCH IF END OF HEADERS
131      ;(ASSUME END OF DATA)
132 066006 104401      TYPE    ,SCRLF        ;
133 066010 000000 21$: .WORD  0            ;HEADER ADDRESS GOES HERE
134 066012 104401 001217      TYPE    ,SCRLF        ;
135 066016 005702      TST    R2            ;DATA WITH HEADER??
136 066020 001767      BEQ    20$           ;NO!!
137 066022 012204      MOV     (R2)+,R4     ;R4 POINTS TO DATA ADDRESS
138 066024 012305      MOV     (R3)+,R5     ;R5 POINTS TO FORMAT
139 066026 105725 22$: TSTB   (R5)+         ;WHAT KIND OF DATA??
140 066030 100407      BMI    24$           ;BINARY
141 066032 001403      BEQ    23$           ;OCTAL
142 066034 013446      MOV     @ (R4)+,-(SP) ;DECIMAL
143 066036 104405      TYPDS
144 066040 000405      BR     25$           ;
145 066042 013446 23$: MOV     @ (R4)+,-(SP) ;
146 066044 104402      TYPDC
147 066046 000402      BR     25$           ;
148 066050 013446 24$: MOV     @ (R4)+,-(SP) ;
149 066052 104406      TYPBN
150 066054 005714 25$: TST    (R4)         ;MORE DATA??
151 066056 001403      BEQ    26$           ;NO. !
152 066060 104401 066142      TYPE    ,ERTY04       ;YES-TYPE 2 SPACES
153 066064 000760      BR     22$           ;AND CONTINUE
154 066066 104401 001217 26$: TYPE    ,SCRLF        ;TYPE ONE BLANK LINE
155 066072 000742      BR     20$           ;BEFORE NEXT HEADER

```

156	066074	104415			278:	RESREG		
157	066076	000207				RTS	PC	
158								
159	066100	000000			TSTNMB:	.WORD	0	;TEST NUMBER
160	066102	000000			ERRNMB:	.WORD	0	;ERROR NUMBER
161	066104	000000			BOTADR:	.WORD	0	;BEGINNING OF TEXT ADDRESS
162	066106	000			BOTFLG:	.BYTE	0	;BOT FLAG
163	066107	000			CHRCNT:	.BYTE	0	;CHARACTER COUNT
164								
165	066110	104	122	126	ERTY00:	.ASCIZ	@D'V#@	
166	066115	054	040	124	ERTY01:	.ASCIZ	@, TEST#@	
167	066125	054	040	105	ERTY02:	.ASCIZ	@, ERR#@	
168	066134	054	040	120	ERTY03:	.ASCIZ	@, PC=@	
169	066142	040	040	000	ERTY04:	.ASCIZ	@ @	
170	066145	040	055	040	ERTY05:	.ASCIZ	@ - @	
171					.EVEN			
172	066152	066162	066250	066266	PFECH:	PFECH1,PFECH2,PFECH3,PFECH4		;WORDS DEFINING TABLES BELOW
173	066162	066166	000000		PFECH1:	+.4,0		
174	066166	120	117	127		.ASCIZ	?POWER MONITOR BIT IN CPU ERROR REGISTER FOUND SET?	
175						.EVEN		
176	066250	066254	000000		PFECH2:	+.4,0		
177	066254	103	120	125		.ASCIZ	?CPUERREG?	
178						.EVEN		
179	066266	066270			PFECH3:	+.2		
180	066270	065230	000000			.WORD	CPSAVE,0	
181	066274	066276			PFECH4:	+.2		
182	066276	000	000			.BYTE	0,0	

.SBTTL TTY INPUT ROUTINE

066300 000000
 066302 000000
 066304 000000
 066306 066307

```

*****
ENABL  LSB
$TKCNT: .WORD 0      ;;NUMBER OF ITEMS IN QUEUE
$TKQIN: .WORD 0      ;;INPUT POINTER
$TKQOUT: .WORD 0     ;;OUTPUT POINTER
$TKQSRV: .BLKB 1     ;;TTY KEYBOARD QUEUE
$TKQEND=.
.EVEN
    
```

```

;*TK INITIALIZE ROUTINE
;*THIS ROUTINE WILL INITIA.LIZE THE TTY KEYBOARD INPUT QUFUE
;*SETUP THE INTERRUPT VECTOR AND TURN ON THE KEYBOARD INTERRUPT
    
```

```

;*CALL:
;*      JSR      PC,$TKINT
;*      RETURN
    
```

066310 005037 066300
 066314 012737 066306 066302
 066322 013737 066302 066304
 066330 012737 066360 000060
 066336 012737 000200 000062
 066344 005777 112612
 066350 012777 000100 112602
 066356 000207

```

$TKINT: CLR      $TKCNT      ;;CLEAR COUNT OF ITEMS IN QUEUE
        MOV      #$TKQSRV,$TKQIN ;;MOVE THE STARTING ADDRESS OF THE
        MOV      $TKQIN,$TKQOUT ;;QUEUE INTO THE INPUT & OUTPUT POINTERS.
        MOV      #$TKQSRV,@TKVEC ;;INITIALIZE THE KEYBOARD VECTOR
        MOV      #200,@TKVEC+2  ;;'BR' LEVEL 4
        TST      @TKKB         ;;CLEAR DONE FLAG
        MOV      #100,@TKKS     ;;ENABLE TTY KEYBOARD INTERRUPT
        RTS      PC           ;;RETURN TO CALLER
    
```

```

;*TK SERVICE ROUTINE
;*THIS ROUTINE WILL SERVICE THE TTY KEYBOARD INTERRUPT
;*BY READING THE CHARACTER FROM THE INPUT BUFFER AND PUTTING
;*IT IN THE QUEUE.
;*IF THE CHARACTER IS A 'CONTROL-C' (^C) $TKINT IS CALLED AND
;*UPON RETURN EXIT IS MADE TO THE 'CONTROL-C' RESTART ADDRESS (SHUT2)
    
```

066360 117746 112576
 066364 042716 177600
 066370 021627 000021
 066374 001002
 066376 005726
 066400 000002
 066402
 066402 021627 000003
 066406 001007
 066410 104401 067506
 066414 004737 066310
 066420 005726
 066422 000137 067550
 066426 021627 000007
 066432 001004
 066434 022737 000176 001154
 066442 001500
 066444
 066444 022737 000001 066300
 066452 001004
 066454 104401 001212

```

$TKSRV: MOV      @TKKB,-(SP)  ;;PICKUP THE CHARACTER
        BIC      #^C177,(SP)  ;;STRIP THE JUNK
        CMP      (SP),#$XON   ;;IS IT A RANDOM XON?
        BNE      30$         ;;BRANCH IF NO
        TST      (SP)+       ;;CLEAN RANDOM XON OFF STACK
        RTI                ;;RETURN
30$:
        CMP      (SP),#3      ;;IS IT A CONTROL C?
        BNE      1$         ;;BRANCH IF NO
        TYPE     ,SCNTLC     ;;TYPE A CONTROL-C (^C)
        JSR      PC,$TKINT   ;;INIT THE KEYBOARD
        TST      (SP)+       ;;CLEAN UP STACK
        JMP      SHUT2       ;;CONTROL C RESTART
1$:
        CMP      (SP),#7      ;;IS IT A CONTROL G?
        BNE      2$         ;;BRANCH IF NO
        CMP      #SWREG,SWR   ;;IS SOFT-SWR SELECTED?
        BEQ      6$         ;;GO TO SWR CHANGE
2$:
        CMP      #1,$TKCNT    ;;IS THE QUEUE FULL?
        BNE      3$         ;;BRANCH IF NO
        TYPE     ,SBELL      ;;RING THE TTY BELL
3$:
        
```

```

066460 005726          TST      (SP)+          ;;CLEAN CHARACTER OFF OF STACK
066462 000451          BR        5$           ;;EXIT
066464 021627 000023  3$:    CMP      (SP),#23        ;;IS IT A CONTROL-S?
066470 001021          BNE      32$          ;;BRANCH IF NO
066472 005077 112462          CLR      @STKS         ;;DISABLE TTY KEYBOARD INTERRUPTS
066476 005726          TST      (SP)+          ;;CLEAN CHAR OFF STACK
066500 105777 112454  31$:    TSTB     @STKS         ;;WAIT FOR A CHAR
066504 100375          BPL      31$           ;;LOOP UNTIL ITS THERE
066506 117746 112450  MOVB     @STKB,-(SP)     ;;GET THE CHARACTER
066512 042716 177600  BIC      #'C177,(SP)   ;;MAKE IT 7-BIT ASCII
066516 022627 000021  CMP      (SP)+,#21     ;;IS IT A CONTROL-Q?
066522 001366          BNE      31$          ;;BRANCH IF NO
066524 012777 000100 112426  MOV      #100,@STKS    ;;REENABLE TTY KEYBOARD INTERRUPTS
066532 000002          RTI                     ;;RETURN
066534 005237 066300  32$:    INC      $TKCNT      ;;COUNT THIS CHARACTER
066540 021627 000140  CMP      (SP),#140     ;;IS IT UPPER CASE?
066544 002405          BLT      4$           ;;BRANCH IF YES
066546 021627 000175  CMP      (SP),#175     ;;IS IT A SPECIAL CHAR?
066552 003002          BGT      4$           ;;BRANCH IF YES
066554 042716 000040  BIC      #40,(SP)      ;;MAKE IT UPPER CASE
066560 112677 177516  4$:    MOVB     (SP)+,@STKQIN ;;AND PUT IT IN QUEUE
066564 005237 066302  INC      $TKQIN        ;;UPDATE THE POINTER
066570 023727 066302 066307  CMP      $TKQIN,$TKQEND ;;GO OFF THE END?
066576 001003          BNE      5$          ;;BRANCH IF NO
066600 012737 066306 066302  MOV      #$TKQSRRT,$TKQIN ;;RESET THE POINTER
066606 000002  5$:    RTI                     ;;RETURN

```

```

*****
;*SOFTWARE SWITCH REGISTER CHANGE ROUTINE.
;*ROUTINE IS ENTERED FROM THE TRAP HANDLER, AND WILL
;*SERVICE THE TEST FOR CHANGE IN SOFTWARE SWITCH REGISTER TRAP
;*CALL WHEN OPERATING IN TTY INTERRUPT MODE.

```

```

066610 022737 000176 001154  $CKSWR: CMP      #SWREG,SWR    ;;IS THE SOFT-SWR SELECTED
066616 001124          BNE      15$          ;;EXIT IF NOT
066620 105777 112334          TSTB     @STKS         ;;IS A CHAR WAITING?
066624 100121          BPL      15$          ;;IF NOT, EXIT
066626 117746 112330  MOVB     @STKB,-(SP)   ;;YES
066632 042716 177600  BIC      #'C177,(SP)   ;;MAKE IT 7-BIT ASCII
066636 021627 000007  CMP      (SP),#7       ;;IS IT A CONTROL-G?
066642 001300          BNE      2$          ;;IF NOT, PUT IT IN THE TTY QUEUE
                                ;;AND EXIT

```

```

*****
;*CONTROL IS PASSED TO THIS POINT FROM EITHER THE TTY INTERRUPT SERVICE
;*ROUTINE OR FROM THE SOFTWARE SWITCH REGISTER TRAP CALL, AS A RESULT OF A
;*CONTROL-G BEING TYPED, AND THE SOFTWARE SWITCH REGISTER BEING SELECTED.

```

```

066644 123727 001150 000001  6$:    CMPB     $AUTOB,#1    ;;ARE WE RUNNING IN AUTO-MODE?
066652 001674          BEQ      2$           ;;BRANCH IF YES
066654 005726          TST      (SP)+          ;;CLEAR CONTROL-G OFF STACK
066656 004737 066310  JSR      PC,$TKINT     ;;FLUSH THE TTY INPUT QUEUE
066662 005077 112272          CLR      @STKS         ;;DISABLE TTY KEYBOARD INTERRUPTS
066666 112737 000001 001151  MOVB     #1,$INTAG     ;;SET INTERRUPT MODE INDICATOR

066674 104401 067520  $GTSWR: TYPE     , $CNTLG    ;;ECHO THE CONTROL-G (^G)
066700 104401 067525          TYPE     , $MSWR      ;;TYPE CURRENT CONTENTS
066704 013746 000176          MOV      SWREG,-(SP)  ;;SAVE SWREG FOR TYPEOUT
066710 104402          TYPOC              ;;GO TYPE--OCTAL ASCII(ALL DIGITS)

```



```

066712 104401 067536          TYPE      ,SMNFW      ;;PROMPT FOR NEW SWR
066716 005046          CLR        -(SP)      ;;CLEAR COUNTER
066720 005046          CLR        -(SP)      ;;THE NEW SWR
066722 105777 112232      7$:      TSTB      @STKS      ;;CHAR THERE?
066726 100375          BPL        7$      ;;IF NOT TRY AGAIN

066730 117746 112226          MOVB      @STKB,-(SP)  ;;PICK UP CHAR
066734 042716 177600          BIC        #^C177,(SP)  ;;MAKE IT 7-BIT ASCII

066740 021627 000003          CMP        (SP),#3      ;;IS IT A CONTROL-C?
066744 001015          BNE        9$          ;;BRANCH IF NOT
066746 104401 067506          TYPE      ,SCNTLC     ;;YES, ECHO CONTROL-C (^C)
066752 062706 000006          ADD        #6,SP       ;;CLEAN UP STACK
066756 123727 001151 000001  CMPB      $INTAG,#1     ;;REENABLE TTY KEYBOARD INTERRUPTS?
066764 001003          BNE        8$          ;;BRANCH IF NO
066766 012777 000100 112164  MOV        #100,@STKS   ;;ALLOW TTY KEYBOARD INTERRUPTS
066774 000137 067550      8$:      JMP        SHUT2       ;;CONTROL-C RESTART

067000 021627 000025          9$:      CMP        (SP),#25     ;;IS IT A CONTROL-U?
067004 001005          BNE        10$         ;;BRANCH IF NOT
067006 104401 067513          TYPE      ,SCNTLU     ;;YES, ECHO CONTROL-U (^U)
067012 062706 000006          20$:     ADD        #6,SP       ;;IGNORE PREVIOUS INPUT
067016 000737          BR        19$         ;;LET'S TRY IT AGAIN

067020 021627 000015          10$:     CMP        (SP),#15     ;;IS IT A <CR>?
067024 001022          BNE        16$         ;;BRANCH IF NO
067026 005766 000004          TST        4(SP)      ;;YES, IS IT THE FIRST CHAR?
067032 001403          BEQ        11$         ;;BRANCH IF YES
067034 016677 000002 112112  MOV        2(SP),@SWR   ;;SAVE NEW SWR
067042 062706 000006          11$:     ADD        #6,SP       ;;CLEAN UP STACK
067046 104401 001217          14$:     TYPE      ,SCRLF     ;;ECHO <CR> AND <LF>
067052 123727 001151 000001  CMPB      $INTAG,#1     ;;RE-ENABLE TTY KBD INTERRUPTS?
067060 001003          BNE        15$         ;;BRANCH IF NOT
067062 012777 000100 112070  MOV        #100,@STKS   ;;RE-ENABLE TTY KBD INTERRUPTS
067070 000002          15$:     RTI          ;;RETURN
067072 004737 063732          16$:     JSR        PC,$TYPEC  ;;ECHO CHAR
067076 021627 000060          CMP        (SP),#60    ;;CHAR < 0?
067102 002420          BLT        18$         ;;BRANCH IF YES
067104 021627 000067          CMP        (SP),#67    ;;CHAR > 7?
067110 003015          BGT        18$         ;;BRANCH IF YES
067112 042726 000060          BIC        #60,(SP)+   ;;STRIP-OFF ASCII
067116 005766 000002          TST        2(SP)      ;;IS THIS THE FIRST CHAR
067122 001403          BEQ        17$         ;;BRANCH IF YES
067124 006316          ASL        (SP)        ;;NO, SHIFT PRESENT
067126 006316          ASL        (SP)        ;;CHAR OVER TO MAKE
067130 006316          ASL        (SP)        ;;ROOM FOR NEW ONE.
067132 005266 000002          17$:     INC        2(SP)      ;;KEEP COUNT OF CHAR
067136 056616 177776          BIS        -2(SP),(SP)  ;;SET IN NEW CHAR
067142 000667          BR        7$          ;;GET THE NEXT ONE
067144 104401 001216          18$:     TYPE      ,SQUES   ;;TYPE ?<CR><LF>
067150 000720          BR        20$         ;;SIMULATE CONTROL-U
.DSABL  LSB

```

```

: *THIS ROUTINE WILL INPUT A SINGLE CHARACTER FROM THE TTY
: *CALL:
: *   RDCHR          ;; GET A CHARACTER FROM THE QUEUE
: *   RETURN HERE   ;; CHARACTER IS ON THE STACK
: *                ;; WITH PARITY BIT STRIPPED OFF
:
067152 011646          $RDCHR: MOV      (SP),-(SP)      ;; PUSH DOWN THE PC AND
067154 016666 000004 000002  MOV      4(SP),2(SP)      ;; THE PS
067162 005066 000004          CLR      4(SP)          ;; GET READY FOR A CHARACTER
067166 005046          CLR      -(SP)          ;; PUT NEW PS ON STACK
067170 012746 067176          MOV      #64$,-(SP)      ;; PUT NEW PC ON STACK
067174 000002          RTI                          ;; POP NEW PC AND PS
067176
067176 005737 066300 64$:  TST      $TKCNT          ;; WAIT ON A CHARACTER
067202 001775 1$:      BEQ      1$
067204 005337 066300          DEC      $TKCNT          ;; DECREMENT THE COUNTER
067210 117766 177070 000004  MOVB   @$TKQOUT,4(SP)      ;; GET ONE CHARACTER
067216 005237 066304          INC      $TKQOUT          ;; UPDATE THE POINTER
067222 023727 066304 066307  CMP     $TKQOUT,#$TKQEND  ;; DID IT GO OFF OF THE END?
067230 001003          BNE     2$          ;; BRANCH IF NO
067232 012737 066306 066304  MOV     #$TKQSRRT,$TKQOUT ;; RESET THE POINTER
067240 000002          RTI                          ;; RETURN
: *****
: *THIS ROUTINE WILL INPUT A STRING FROM THE TTY
: *CALL:
: *   RDLIN          ;; INPUT A STRING FROM THE TTY
: *   RETURN HERE   ;; ADDRESS OF FIRST CHARACTER WILL BE ON THE STACK
: *                ;; TERMINATOR WILL BE A BYTE OF ALL 0'S
:
067242 010346          $RDLIN: MOV      R3, -(SP)          ;; SAVE R3
067244 005046          CLR      -(SP)          ;; CLEAR THE RUBOUT KEY
067246 012703 067476 1$:  MOV     #$TTYIN,R3          ;; GET ADDRESS
067252 022703 067506 2$:  CMP     #$TTYIN+8.,R3      ;; BUFFER FULL?
067256 101456          BLOS   4$          ;; BR IF YES
067260 104411          RDCHR          ;; GO READ ONE CHARACTER FROM THE TTY
067262 112613          MOVB   (SP)+,(R3)          ;; GET CHARACTER
067264 122713 000177 10$:  CMPB   #177,(R3)          ;; IS IT A RUBOUT
067270 001022          BNE   5$          ;; BR IF NO
067272 005716          TST   (SP)          ;; IS THIS THE FIRST RUBOUT?
067274 001007          BNE   6$          ;; BR IF NO
067276 112737 000134 067474  MOVB   #' \,9$          ;; TYPE A BACK SLASH
067304 104401 067474          TYPE  ,9$
067310 012716 177777          MOV   #-1,(SP)          ;; SET THE RUBOUT KEY
067314 005303 6$:      DEC     R3          ;; BACKUP BY ONE
067316 020327 067476          CMP   R3,$$TTYIN          ;; STACK EMP'Y?
067322 103434          BLO   4$          ;; BR IF YES
067324 111337 067474          MOVB (R3),9$          ;; SETUP TO TYPEOUT THE DELETED CHAR.
067330 104401 067474          TYPE ,9$          ;; GO TYPE
067334 000746          BR    2$          ;; GO READ ANOTHER CHAR.
067336 005716 5$:      TST   (SP)          ;; RUBOUT KEY SET?
067340 001406          BEQ   7$          ;; BR IF NO
067342 112737 000134 067474  MOVB   #' \,9$          ;; TYPE A BACK SLASH
067350 104401 067474          TYPE ,9$
067354 005016          CLR   (SP)          ;; CLEAR THE RUBOUT KEY
067356 122713 000025 7$:  CMPB   #25,(R3)          ;; IS CHARACTER A CTRL U?
067362 001003          BNE   8$          ;; BR IF NO

```

067364	104401	067513			TYPE	,\$CNTLU	::TYPE A CONTROL 'U'	
067370	000726				BR	1\$::GO START OVER	
067372	122713	00G022	8\$:		CMPB	#22,(R3)	::IS CHARACTER A '^R'?	
067376	001011				BNE	3\$::BRANCH IF NO	
067400	105013				CLRB	(R3)	::CLEAR THE CHARACTER	
067402	104401	001217			TYPE	,\$SCLF	::TYPE A 'CR' & 'LF'	
067406	104401	067476			TYPE	,\$TTYIN	::TYPE THE INPUT STRING	
067412	000717				BR	2\$::GO PICKUP ANOTHER CHACTER	
067414	104401	001216	4\$:		TYPE	,\$QUES	::TYPE A '?'	
067420	000712				BR	1\$::CLEAR THE BUFFER AND LOOP	
067422	111337	067474	3\$:		MOVB	(R3),9\$::ECHO THE CHARACTER	
067426	104401	067474			TYPE	,9\$		
067432	122723	000015			CMPB	#15,(R3)+	::CHECK FOR RETURN	
067436	001305				BNE	2\$::LOOP IF NOT RETURN	
067440	105063	177777			CLRB	-1(R3)	::CLEAR RETURN (THE 15)	
067444	104401	001220			TYPE	,\$LF	::TYPE A LINE FEED	
067450	005726				TST	(SP)+	::CLEAN RUBOUT KEY FROM THE STACK	
067452	012603				MOV	(SP)+,R3	::RESTORE R3	
067454	011646				MOV	(SP)-,(SP)	::ADJUST THE STACK AND PUT ADDRESS OF THE	
067456	016666	000004	000002		MOV	4(SP),2(SP)	::FIRST ASCII CHARACTER ON IT	
067464	012766	067476	000004		MOV	,\$TTYIN,4(SP)		
067472	000002				RTI		::RETURN	
067474	000			9\$:	.BYTE	0	::STORAGE FOR ASCII CHAR. TO TYPE	
067475	000				.BYTE	0	::TERMINATOR	
067476					,\$TTYIN:	.BLKB	8.	::RESERVE 8 BYTES FOR TTY INPUT
067506	136	103	015		,\$CNTLC:	.ASCIZ	/^C/<15><12>	::CONTROL 'C'
067513	136	125	015		,\$CNTLU:	.ASCIZ	/^U/<15><12>	::CONTROL 'U'
067520	136	107	015		,\$CNTLG:	.ASCIZ	/^G/<15><12>	::CONTROL 'G'
067525	015	012	123		,\$MSWR:	.ASCIZ	<15><12>/SWR - /	
067536	040	040	'16		,\$MNEW:	.ASCIZ	/ NEW = /	
						.EVEN		
3	067550	012737	177777	001326	SHUT2:	MOV	#-1,CILFG	;SET THE CONTROL-C FLAG
4	067556	105737	001116			TSTB	,\$TSTNM	;DOING ANY TESTS ?
5	067562	001002				BNE	1\$;BR IF YES
6	067564	000137	037262			JMP	SHUT	;NO--RESPOND TO ^C
7	067570	000002			1\$:	RTI		;EXIT FROM INTERRUPT

.SBTTL READ AN OCTAL NUMBER FROM THE TTY

```

*****
*THIS ROUTINE WILL READ AN OCTAL (ASCII) NUMBER FROM THE TTY AND
*CHANGE IT TO BINARY.
*CALL:
*      RDOCT          ;;READ AN OCTAL NUMBER
*      RETURN HERE   ;;LOW ORDER BITS ARE ON TOP OF THE STACK
*                  ;;HIGH ORDER BITS ARE IN $HI OCT
SRDOCT: MOV      (SP),-(SP)      ;;PROVIDE SPACE FOR THE
MOV      4(SP),2(SP)          ;;INPUT NUMBER
MOV      R0,-(SP)             ;;PUSH R0 ON STACK
MOV      R1,-(SP)             ;;PUSH R1 ON STACK
MOV      R2,-(SP)             ;;PUSH R2 ON STACK
1$:      RDLIN                    ;;READ AN ASCII LINE
MOV      (SP)+,R0              ;;GET ADDRESS OF 1ST CHARACTER
CLR      R1                    ;;CLEAR DATA WORD
CLR      R2
2$:      MOVB      (R0)+,-(SP)    ;;PICKUP THIS CHARACTER
BEQ      3$                    ;;IF ZERO GET OUT
ASL      R1                      ;;*2
ROL      R2
ASL      R1                      ;;*4
ROL      R2
ASL      R1                      ;;*8
ROL      R2
067640: BIC      #^C7,(SP)        ;;STRIP THE ASCII JUNK
ADD      (SP)+,R1              ;;ADD IN THIS DIGIT
BR       2$                    ;;LOOP
3$:      TST      (SP)+
MOV      R1,12(SP)            ;;SAVE THE RESULT
MOV      R2,$HI OCT
MOV      (SP)+,R2
MOV      (SP)+,R1
MOV      (SP)+,R0
RTI
$HI OCT: .WORD      0

```

```

067572 011646
067574 016666 000004 0000C?
067602 010046
067604 010146
067606 010246
067610 104412
067612 012600
067614 005001
067616 005002
067620 112046
067622 001412
067624 006301
067626 006102
067630 006301
067632 006102
067634 006301
067636 006102
067640 042716 177770
067644 062601
067646 000764
067650 005726
067652 010166 000012
067656 010237 067672
067662 012602
067664 012601
067666 012600
067670 000002
067672 000000

```

.SBTTL TRAP DECODER

 ;*THIS ROUTINE WILL PICKUP THE LOWER BYTE OF THE 'TRAP' INSTRUCTION
 ;*AND USE IT TO INDEX THROUGH THE TRAP TABLE FOR THE STARTING ADDRESS
 ;*OF THE DESIRED ROUTINE. THEN USING THE ADDRESS OBTAINED IT WILL
 ;*GO TO THAT ROUTINE.

067674	016646	000002	\$TRAP:	MOV	2(SP),-(SP)	::ASSUME THE STATUS OF
067700	042716	000020		BIC	#20,(SP)	:: THE CALLER--DO NOT ALLOW
067704	012746	067712		MOV	#1\$,-(SP)	:: T-BIT TRAPS
067710	000002			RTI		::SET THE NEW STATUS
067712	010046		1\$:	MOV	R0,-(SP)	::SAVE R0
067714	016600	000002		MOV	2(SP),R0	::GET TRAP ADDRESS
067720	005740			TST	-(R0)	::BACKUP BY 2
067722	111000			MOVB	(R0),R0	::GET RIGHT BYTE OF TRAP
067724	006300			ASL	R0	::POSITION FOR INDEXING
067726	016000	067746		MOV	\$TRPAD(R0),R0	::INDEX TO TABLE
067732	000200			RTS	R0	::GO TO ROUTINE

::THIS IS USE TO HANDLE THE 'GETPRI' MACRO

067734	011646	000004	000002	\$TRAP2:	MOV	(SP),-(SP)	::MOVE THE PC DOWN
067736	016666				MOV	4(SP),2(SP)	::MOVE THE PSW DOWN
067744	000002				RTI		::RESTORE THE PSW

.SBTTL TRAP TABLE

;*THIS TABLE CONTAINS THE STARTING ADDRESSES OF THE ROUTINES CALLED
 ;*BY THE 'TRAP' INSTRUCTION.

					ROUTINE	

067746	067734			\$TRPAD:	.WORD	\$TRAP2
067750	063520				\$TYPE	::CALL=TYPE TRAP+1(104401) TTY TYPEOUT ROUTINE
067752	063316				\$TYPOC	::CALL=TYPOC TRAP+2(104402) TYPE OCTAL NUMBER (WITH LEADING ZEROS)
067754	063272				\$TYPOS	::CALL=TYPOS TRAP+3(104403) TYPE OCTAL NUMBER (NO LEADING ZEROS)
067756	063332				\$TYPON	::CALL=TYPON TRAP+4(104404) TYPE OCTAL NUMBER (AS PER LAST CALL)
067760	063046				\$TYPDS	::CALL=TYPDS TRAP+5(104405) TYPE DECIMAL NUMBER (WITH SIGN)
067762	062772				\$TYPBN	::CALL=TYPBN TRAP+6(104406) TYPE BINARY (ASCII) NUMBER
067764	066700				\$GTSWR	::CALL=GTSWR TRAP+7(104407) GET SOFT-SWR SETTING
067766	066610				\$CKSWR	::CALL=CKSWR TRAP+10(104410) TEST FOR CHANGE IN SOFT-SWR
067770	067152				\$RDCHR	::CALL=RDCHR TRAP+11(104411) TTY TYPEIN CHARACTER ROUTINE
067772	067242				\$RDLIN	::CALL=RDLIN TRAP+12(104412) TTY TYPEIN STRING ROUTINE
067774	067572				\$RDOCT	::CALL=RDOCT TRAP+13(104413) READ AN OCTAL NUMBER FROM TTY
067776	062676				\$SAVREG	::CALL=SAVREG TRAP+14(104414) SAVE R0-R5 ROUTINE
070000	062734				\$RESREG	::CALL=RESREG TRAP+15(104415) RESTORE R0-R5 ROUTINE

.S5TTL POWER DOWN AND UP ROUTINES

```

*****
:POWER DOWN ROUTINE
070002 012737 070142 000024 $PWRDN: MOV    #$ILLUP,@#PWRVEC ;;SET FOR FAST UP
070010 012737 000340 000026      MOV    #340,@#PWRVEC+2 ;;PRIO:7
070016 010046      MOV    R0,-(SP) ;;PUSH R0 ON STACK
070020 010146      MOV    R1,-(SP) ;;PUSH R1 ON STACK
070022 010246      MOV    R2,-(SP) ;;PUSH R2 ON STACK
070024 010346      MOV    R3,-(SP) ;;PUSH R3 ON STACK
070026 010446      MOV    R4,-(SP) ;;PUSH R4 ON STACK
070030 010546      MOV    R5,-(SP) ;;PUSH R5 ON STACK
070032 017746 111116      MOV    @SWR,-(SP) ;;PUSH @SWR ON STACK
070036 010637 070146      MOV    SP,$SAVR6 ;;SAVE SP
070042 012737 070054 000024      MOV    #$PWRUP,@#PWRVEC ;;SET UP VECTOR
070050 000000      HALT
070052 000776      BR     .-2 ;;HANG UP
*****
:POWER UP ROUTINE
070054 012737 070142 000024 $PWRUP: MOV    #$ILLUP,@#PWRVEC ;;SET FOR FAST DOWN
070062 013706 070146      MOV    $SAVR6,SP ;;GET SP
070066 005037 070146      CLR    $SAVR6 ;;WAIT LOOP FOR THE TTY
070072 005237 070146 1$: INC    $SAVR6 ;;WAIT FOR THE INC
070076 001375      BNE   1$ ;;OF WORD
070100 012677 111050      MOV    (SP)+,@SWR ;;POP STACK INTO @SWR
070104 012605      MOV    (SP)+,R5 ;;POP STACK INTO R5
070106 012604      MOV    (SP)+,R4 ;;POP STACK INTO R4
070110 012603      MOV    (SP)+,R3 ;;POP STACK INTO R3
070112 012602      MOV    (SP)+,R2 ;;POP STACK INTO R2
070114 012601      MOV    (SP)+,R1 ;;POP STACK INTO R1
070116 012600      MOV    (SP)+,R0 ;;POP STACK INTO R0
070120 012737 070002 000024      MOV    #$PWRDN,@#PWRVEC ;;SET UP THE POWER DOWN VECTOR
070126 012737 000340 000026      MOV    #340,@#PWRVEC+2 ;;PRIO:7
070134 104401      TYPE   $POWER ;;REPORT THE POWER FAILURE
070136 070150      $PWRMG: .WORD $POWER ;;POWER FAIL MESSAGE POINTER
070140 000002      RTI
070142 000000      $ILLUP: HALT ;;THE POWER UP SEQUENCE WAS STARTED
070144 000776      BR     .-2 ;;BEFORE THE POWER DOWN WAS COMPLETE
070146 000000      $SAVR6: 0 ;;PUT THE SP HERE
070150 015 012 120 $POWER: .ASCIZ <15><12>'POWER'
          .EVEN

```

.SBTTL APT COMMUNICATIONS ROUTINE

```

*****
070160 112737 000001 070424 $ATY1:  MOVB  #1,$FFLG      ;;TO REPORT FATAL ERROR
070166 112737 000001 070422 $ATY3:  MOVB  #1,$MFLG     ;;TO TYPE A MESSAGE
070174 000403                BR      $ATYC
070176 112737 000001 070424 $ATY4:  MOVB  #1,$FFLG     ;;TO ONLY REPORT FATAL ERROR
070204                $ATYC:
070204 010046                MOV   R0,-(SP)      ;;PUSH R0 ON STACK
070206 010146                MOV   R1,-(SP)      ;;PUSH R1 ON STACK
070210 105737 070422                TSTB  $MFLG      ;;SHOULD TYPE A MESSAGE?
070214 001450                BEQ   5$          ;;IF NOT: BR
070216 122737 000001 001242        CMPB  #APTENV,$ENV  ;;OPERATING UNDER APT?
070224 001031                BNE   3$          ;;IF NOT: BR
070226 132737 000100 001243        BITB  #APTSPOOL,$ENVM ;;SHOULD SPOOL MESSAGES?
070234 001425                BEQ   3$          ;;IF NOT: BR
070236 017600 000004                MOV   @4(SP),R0    ;;GET MESSAGE ADDR.
070242 062766 000002 000004        ADD   #2,4(SP)     ;;BUMP RETURN ADDR.
070250 005737 001222                1$:  TST   $MSGTYPE   ;;SEE IF DONE W/ LAST XMISSION?
070254 001375                BNE   1$          ;;IF NOT: WAIT
070256 010037 001236                MOV   R0,$MSGAD   ;;PUT ADDR IN MAILBOX
070262 105720                2$:  TSTB  (R0)+      ;;FIND END OF MESSAGE
070264 001376                BNE   2$          ;;SUB START OF MESSAGE
070266 163700 001236                SUB   $MSGAD,R0   ;;GET MESSAGE LNTH IN WORDS
070272 006200                ASR   R0          ;;PUT LENGTH IN MAILBOX
070274 010037 001240                MOV   R0,$MSGLGT  ;;TELL APT TO TAKE MSG.
070300 012737 000004 001222        MOV   #4,$MSGTYPE
070306 000413                BR    5$
070310 017637 000004 070334        3$:  MOV   @4(SP),4$   ;;PUT MSG ADDR IN JSR LINKAGE
070316 062766 000002 000004        ADD   #2,4(SP)     ;;BUMP RETURN ADDRESS
070324 013746 177776                MOV   177776,-(SP) ;;PUSH 177776 ON STACK
070330 004737 063520                JSR   PC,$TYPE    ;;CALL TYPE MACRO
070334 000000                4$:  .WORD  0
070336                5$:
070336 105737 070424                10$: TSTB  $FFLG      ;;SHOULD REPORT FATAL ERROR?
070342 001416                BEQ   12$         ;;IF NOT: BR
070344 005737 001242                TST   $ENV        ;;RUNNING UNDER APT?
070350 001413                BEQ   12$         ;;IF NOT: BR
070352 005737 001222                11$: TST   $MSGTYPE   ;;FINISHED LAST MESSAGE?
070356 001375                BNE   11$        ;;IF NOT: WAIT
070360 017637 000004 001224        MOV   @4(SP),$FATAL ;;GET ERROR #
070366 062766 000002 000004        ADD   #2,4(SP)     ;;BUMP RETURN ADDR.
070374 005237 001222                INC   $MSGTYPE    ;;TELL APT TO TAKE ERROR
070400 105037 070424                12$: CLRB  $FFLG      ;;CLEAR FATAL FLAG
070404 105037 070423                CLRB  $LFLG      ;;CLEAR LOG FLAG
070410 105037 070422                CLRB  $MFLG      ;;CLEAR MESSAGE FLAG
070414 012601                MOV   (SP)+,R1    ;;POP STACK INTO R1
070416 012600                MOV   (SP)+,R0    ;;POP STACK INTO R0
070420 000207                RTS   PC          ;;RETURN
070422 000                $MFLG: .BYTE  0   ;;MESSG. FLAG
070423 000                $LFLG: .BYTE  0   ;;LOG FLAG
070424 000                $FFLG: .BYTE  0   ;;FATAL FLAG
                .EVEN
                APTSIZE = 200
                APTENV  = 001
                APTSPOOL = 100
                APTCSUP = 040

```

CONSOLE MESSAGES

.SBTTL CONSOLE MESSAGES

```

2
3 070426      200      103      *01  SCTMSG: .ASCIZ <CRLF>@CANNOT RECOVER THE BAD SECTOR FILES ON THIS DEVICE@
4 070512      075      000      EQUALS: .ASCIZ @=@
5 070514      101      114      114  ALL: .ASCIZ @ALL@<CRLF>
6 070521      040      077      040  QUES: .ASCIZ @ ? @
7 070525      054      040      000  COMMA: .ASCIZ @, @
8 070530      200      124      117  MSHELP: .ASCII <CRLF>@TO ENSURE THAT NO BAD HEADERS ARE LEFT ON THE DISK@
9 070616      200      120      101      .ASCII <CRLF>@PACK, THIS PROGRAM SHOULD BE HALTED BY TYPING A (^C)@
10 070704      200      103      117      .ASCII <CRLF>@CONTROL C. AS A RESULT, THE PROGRAM WILL BE HALTED@
11 070772      200      127      110      .ASCII <CRLF>@WHEN THE DRIVE UNDER TEST HAS COMPLETED TESTING.@<CRLF>
12 071054      200      124      131      .ASCIZ <CRLF>@TYPE HELP TEXT (L) N ? @
13 071105      200      122      115  CNSLO1: .ASCIZ <CRLF>@RMCS1=@
14 071115      040      114      111  CNSLO2: .ASCIZ @ LIMITS - LO= 160000, HI= 17XXXX@<CRLF>
15 071157      122      115      126  CNSLO3: .ASCIZ @RMVEC=@
16 071166      040      114      111  CNSLO4: .ASCIZ @ LIMITS - LO= 0, HI= 1000@<CRLF><LF>
17 071222      200      124      131  CNSLO7: .ASCII <CRLF>@TYPE 'A' TO TEST ALL DRIVES, OR TYPE DRIVE NUMBER(S)@
18 071307      200      101      116      .ASCIZ <CRLF>@AND TERMINATE INPUT WITH A CARRIAGE RETURN.@
19 071364      200      111      111  CNSLO8: .ASCII <CRLF>
20 071365      040      077      111  CNSLO9: .ASCIZ @ ?ILLEGAL INPUT@<CRLF>
21 071406      200      104      122  MSDRVS: .ASCIZ <CRLF>/DRIVE(S): /
22 071422      104      122      111  MSGDRV: .ASCIZ /DRIVE/
23 071430      200      125      116  SYSTAT: .ASCIZ <CRLF>/UNIT STATUS:/
24 071446      122      115      060  $RM02: .ASCIZ /RM02/
25 071453      122      115      060  $RM03: .ASCIZ /RM03/
26 071460      122      115      060  $RM05: .ASCIZ /RM05/
27 071465      040      116      117  NOTRM: .ASCIZ @ NOT AN RM05/3/2@
28 071506      040      114      117  LODEV: .ASCIZ / LOAD DEVICE/
29 071523      040      116      117  NOTPRS: .ASCIZ / NOT PRESENT/
30 071540      040      116      117  NOTAVL: .ASCIZ / NOT AVAILABLE/
31 071557      040      117      106  UNTOFF: .ASCIZ / OFFLINE/
32 071570      040      117      116  UNTON: .ASCIZ / ONLINE/
33 071600      200      104      122  DRIVES: .ASCIZ <CRLF>/DRIVE(S) TO BE TESTED/
34 071627      116      117      116  NONE: .ASCIZ /NONE/
35 071634      116      000      N: .ASCIZ /N/
36 071636      131      000      Y: .ASCIZ /Y/
37 071640      040      BLNKS4: .ASCII //
38 071641      040      BLNKS3: .ASCII //
39 071642      040      BLNKS2: .ASCII //
40 071643      040      000      BLNKS1: .ASCIZ //
41      .EVEN

```


1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57

.SBITL FUNCTION CODE TABLE

;THE FUNCTION CODE TABLE IS USED TO DEFINE STATUS CONDITIONS FOR
 ;EACH FUNCTION CODE. BIT USAGE IS AS FOLLOWS:

; ATA - BIT 15 IS SET IN THE ENTRY FOR A GIVEN FUNCTION CODE
 ;IF ATA SHOULD BE SET WHEN THE FUNCTION CODE IS EXECUTED, OTHERWISE,
 ;BIT 15 IS ZERO, INDICATING THAT ATA SHOULD NOT NORMALLY BE SET.
 ;NOTE THAT ATA MAY BE SET WHEN A COMMAND IS EXECUTED EVEN THOUGH
 ;IT IS NOT EXPECTED AS A RESULT OF THE COMMAND.

; WCE - BIT 14 IS SET IN THE ENTRY FOR A GIVEN FUNCTION CODE
 ;IF WRITE CHECK ERRORS ARE ENABLED AS A FUNCTION OF THE COMMAND.

; OPI - BIT 13 IS SET IN THE ENTRY FOR A GIVEN FUNCTION CODE
 ;IF OPI ERRORS ARE ENABLED DURING THE EXECUTION OF THAT COMMAND.

; IVC - BIT 12 IS SET IN THE ENTRY FOR A GIVEN FUNCTION CODE
 ;IF IVC ERRORS ARE ENABLED DURING THE EXECUTION OF THAT COMMAND.

; WLE - BIT 11 'S SET IN THE ENTRY FOR A GIVEN FUNCTION CODE
 ;IF WRITE ERRORS ARE UNABLED DURING THE EXECUTION OF THAT COMMAND.
 ;THE WRITE ERRORS WHICH ARE ENABLED ARE 'WLE', 'WCF', 'DPE', 'UPE'.

; IAE - BIT 10 IS SET IN THE ENTRY FOR A GIVEN FUNCTION CODE
 ;IF INVALID ADDRESS ERROR IS ENABLED FOR THAT COMMAND.

; AOE - BIT 09 IS SET IN THE ENTRY FOR A GIVEN FUNCTION CODE
 ;IF READ AND WRITE ERRORS ARE ENABLED DURING THE EXECUTION OF THE
 ;COMMAND. THE ERRORS ENABLED BY THIS BIT ARE 'TRE', 'DLT', 'NEM',
 ;'MXF', 'LBT', AND 'AOE'.

; BIT 08 IS NOT USED.

; HCE - BIT 07 IS SET IN THE ENTRY FOR A GIVEN FUNCTION CODE
 ;IF HEADER ERRORS ARE ENABLED DURING THE EXECUTION OF THAT COMMAND.
 ;HEADER ERRORS INCLUDE 'HCRC', 'HCE', 'FER', AND 'BSE'.

; ECH - BIT 06 IS SET IN THE ENTRY FOR A GIVEN FUNCTION CODE
 ;IF DATA FIELD ERRORS ARE ENABLED DURING THE EXECUTION OF THAT
 ;COMMAND. THESE ERRORS INCLUDE 'MDPE', 'DCK', AND 'ECH'.

; BIT 05 IS NOT USED.

; BIT 04 IS NOT USED.

; BIT 03 IS NOT USED.

; BIT 02 IS NOT USED.

; BIT 01 IS NOT USED.

; ILF - BIT 00 IS SET IF THE FUNCTION CODE IS ILLEGAL.

FNCDTB: ;FUNCTION CODE TABLE

.WORD OPI ;NOP

071646
 071646 020000

58	071650	130001	.WORD	OPI:ATA:ILF:IVC	:ILLEGAL FUNCTION (2)
59	071652	132000	.WORD	ATA.OPI:IVC:IAE	:SEEK
60	071654	130000	.WORD	ATA.OPI:IVC	:RECALIBRATE
61	071656	020000	.WORD	OPI	:DRIVE CLEAR
62	071660	030000	.WORD	OPI:IVC	:RELEASE
63	071662	130000	.WORD	OPI:ATA:IVC	:OFFSET
64	071664	130000	.WORD	OPI:ATA:IVC	:RETURN TO CENTERLINE
65	071666	020000	.WORD	OPI	:READ IN PRESET
66	071670	020000	.WORD	OPI	:PACK ACKNOWLEDGE
67	071672	130001	.WORD	OPI:ATA:ILF:IVC	:ILLEGAL FUNCTION (24)
68	071674	130001	.WORD	OPI:ATA:ILF:IVC	:ILLEGAL FUNCTION (26)
69	071676	132000	.WORD	ATA:OPI:IVC:IAE	:SEARCH
70	071700	130001	.WORD	OPI:ATA:ILF:IVC	:ILLEGAL FUNCTION (32)
71	071702	130001	.WORD	OPI:ATA:ILF:IVC	:ILLEGAL FUNCTION (34)
72	071704	130001	.WORD	OPI:ATA:ILF:IVC	:ILLEGAL FUNCTION (36)
73	071706	130001	.WORD	OPI:ATA:ILF:IVC	:ILLEGAL FUNCTION (40)
74	071710	130001	.WORD	OPI:ATA:ILF:IVC	:ILLEGAL FUNCTION (42)
75	071712	130001	.WORD	OPI:ATA:ILF:IVC	:ILLEGAL FUNCTION (44)
76	071714	130001	.WORD	OPI:ATA:ILF:IVC	:ILLEGAL FUNCTION (46)
77	071716	073300	.WORD	WCE:OPI:IVC:IAE:AOE:HCE:ECH	:WRITE CHECK DATA
78	071720	073300	.WORD	WCE:OPI:IVC:IAE:AOE:HCE:ECH	:WRITE CHECK HEADER AND DATA
79	071722	130001	.WORD	OPI:ATA:ILF:IVC	:ILLEGAL FUNCTION (54)
80	071724	130001	.WORD	OPI:ATA:ILF:IVC	:ILLEGAL FUNCTION (56)
81	071726	037200	.WORD	OPI:IVC:WLE:IAE:AOE:HCE	:WRITE DATA
82	071730	037000	.WORD	OPI:IVC:WLE:IAE:AOE	:WRITE HEADER AND DATA
83	071732	130001	.WORD	OPI:ATA:ILF:IVC	:ILLEGAL FUNCTION (64)
84	071734	130001	.WORD	OPI:ATA:ILF:IVC	:ILLEGAL FUNCTION (66)
85	071736	033300	.WORD	OPI:IVC:IAE:AOE:HCE:ECH	:READ DATA
86	071740	033300	.WORD	OPI:IVC:IAE:AOE:HCE:ECH	:READ HEADER AND DATA
87	071742	130001	.WORD	OPI:ATA:ILF:IVC	:ILLEGAL FUNCTION (74)
88	071744	130001	.WORD	OPI:ATA:ILF:IVC	:ILLEGAL FUNCTION (76)

ATTENTION (ATA) TABLE

1		
2		
3	071746	001
4	071747	002
5	071750	004
6	071751	010
7	071752	020
8	071753	040
9	071754	100
C	071755	200

.SBTTL ATTENTION (ATA) TABLE

ATNTBL:	.BYTE	1.
	.BYTE	2.
	.BYTE	4.
	.BYTE	8.
	.BYTE	16.
	.BYTE	32.
	.BYTE	64.
	.BYTE	128.

		.SBTTL DATA PATTERN TABLE	
3	071756	RGDTPT:	
4	071756	MIXED:	
5	071756 000000	.WORD	0.
6	071760 000001	.WORD	1.
7	071762 000003	.WORD	3.
8	071764 000007	.WORD	7.
9	071766 000017	.WORD	15.
10	071770 000037	.WORD	31.
11	071772 000077	.WORD	63.
12	071774 000177	.WORD	127.
13	071776 000377	.WORD	255.
14	072000 000777	.WORD	511.
15	072002 001777	.WORD	1023.
16	072004 003777	.WORD	2047.
17	072006 007777	.WORD	4095.
18	072010 017777	.WORD	8191.
19	072012 037777	.WORD	16383.
20	072014 077777	.WORD	32767.
21	072016 177777	ONES: .WORD	65535.
22	072020 177777	.WORD	65535.
23	072022 077777	.WORD	32767.
24	072024 037777	.WORD	16383.
25	072026 017777	.WORD	8191.
26	072030 007777	.WORD	4095.
27	072032 003777	.WORD	2047.
28	072034 001777	.WORD	1023.
29	072036 000777	.WORD	511.
30	072040 000377	.WORD	255.
31	072042 000177	.WORD	127.
32	072044 000077	.WORD	63.
33	072046 000037	.WORD	31.
34	072050 000017	.WORD	15.
35	072052 000007	.WORD	7.
36	072054 000003	.WORD	3.
37	072056 000001	.WORD	1.
38	072060 000000	ZEROS: .WORD	0.
39	072062 000000	.WORD	0.
40	072064 000001	.WORD	1.
41	072066 000002	.WORD	2.
42	072070 000004	.WORD	4.
43	072072 000010	.WORD	8.
44	072074 000020	.WORD	16.
45	072076 000040	.WORD	32.
46	072100 000100	.WORD	64.
47	072102 000200	.WORD	128.
48	072104 000400	.WORD	256.
49	072106 001000	.WORD	512.
50	072110 002000	.WORD	1024.
51	072112 004000	.WORD	2048.
52	072114 010000	.WORD	4096.
53	072116 020000	.WORD	8192.
54	072120 040000	.WORD	16384.
55	072122 100000	.WORD	32768.
56	072124 100000	.WORD	32768.
57	072126 040000	.WORD	16384.

DATA PATTERN TABLE

58	072130	020000	.WORD	8192.
59	072132	010000	.WORD	4096.
60	072134	004000	.WORD	2048.
61	072136	002000	.WORD	1024.
62	072140	001000	.WORD	512.
63	072142	000400	.WORD	256.
64	072144	000200	.WORD	128.
65	072146	000100	.WORD	64.
66	072150	000040	.WORD	32.
67	07215	000020	.WORD	16.
68	072154	000010	.WORD	8.
69	072156	000004	.WORD	4.
70	072160	000002	.WORD	2.
71	072162	000001	.WORD	1.
72	072164	000000	.WORD	0.
73	072166	177777	.WORD	65535.
74	072170	177776	.WORD	65534.
75	072172	177774	.WORD	65532.
76	072174	177770	.WORD	65528.
77	072176	177760	.WORD	65520.
78	072200	177740	.WORD	65504.
79	072202	177700	.WORD	65472.
80	072204	177600	.WORD	65408.
81	072206	177400	.WORD	65280.
82	072210	177000	.WORD	65024.
83	072212	176000	.WORD	64512.
84	072214	174000	.WORD	63488.
85	072216	170000	.WORD	61440.
86	072220	160000	.WORD	57344.
87	072222	140000	.WORD	49152.
88	072224	100000	.WORD	32768.
89	072226	000000	.WORD	0.
90	072230	000000	.WORD	0.
91	072232	100000	.WORD	32768.
92	072234	140000	.WORD	49152.
93	072236	160000	.WORD	57344.
94	072240	170000	.WORD	61440.
95	072242	174000	.WORD	63488.
96	072244	176000	.WORD	64512.
97	072246	177000	.WORD	65024.
98	072250	177400	.WORD	65280.
99	072252	177600	.WORD	65408.
100	072254	177700	.WORD	65472.
101	072256	177740	.WORD	65504.
102	072260	177760	.WORD	65520.
103	072262	177770	.WORD	65528.
104	072264	177774	.WORD	65532.
105	072266	177776	.WORD	65534.
106	072270	177777	.WORD	65535.
107	072272	125252	.WORD	43690.
108	072274	152525	.WORD	43690./2
109	072276	125252	.WORD	43690.
110	072300	177777	.WORD	65535.
111	072302	177776	.WORD	65534.
112	072304	177775	.WORD	65533.
113	072306	177773	.WORD	65531.
114	072310	177767	.WORD	65527.

EARLY:

DATA PATTERN TABLE				
115	072312	177757	.WORD	65519.
116	072314	177737	.WORD	65503.
117	072316	177677	.WORD	65471.
118	072320	177577	.WORD	65407.
119	072322	177377	.WORD	65279.
120	072324	176777	.WORD	65023.
121	072326	175777	.WORD	64511.
122	072330	173777	.WORD	63487.
123	072332	167777	.WORD	61439.
124	072334	157777	.WORD	57343.
125	072336	137777	.WORD	49151.
126	072340	077777	.WORD	32767.
127	072342	077777	.WORD	32767.
128	072344	137777	.WORD	49151.
129	072346	157777	.WORD	57343.
130	072350	167777	.WORD	61439.
131	072352	173777	.WORD	63487.
132	072354	175777	.WORD	64511.
133	072356	176777	.WORD	65023.
134	072360	177377	.WORD	65279.
135	072362	177577	.WORD	65407.
136	072364	177677	.WORD	65471.
137	072366	177737	.WORD	65503.
138	072370	177757	.WORD	65519.
139	072372	177767	.WORD	65527.
140	072374	177773	.WORD	65531.
141	072376	177775	.WORD	65533.
142	072400	177776	.WORD	65534.
143	072402	177777	.WORD	65535.
144	072404			

ENRGDT:

Line	Code	Code	Code	Code	Label	Text
1					.SBTTL	ERROR MESSAGE TABLE
2						
3	072404	076772	000000		EMT1:	.WORD EMS1,0
4	072410	077041	077056	000000	EMT2:	.WORD EMS2,EMS3,0
5	072416	077041	077121	000000	EMT3:	.WORD EMS2,EMS4,0
6	072424	077164	077214	000000	EMT4:	.WORD EMS5,EMS6,0
7	072432	077164	077326	000000	EMT5:	.WORD EMS5,EMS10,0
8	072440	103766	101205	000000	EMT6:	.WORD EMS167,EMS64,0
9	072446	101753	104013	000000	EMT7:	.WORD EMS110,EMS170,0
10	072454	077261	000000		EMT10:	.WORD EMS7,0
11	072460	077326	000000		EMT11:	.WORD EMS10,0
12	072464	077370	077401	000000	EMT12:	.WORD EMS11,EMS12,0
13	072472	077442	077453	077464	EMT13:	.WORD EMS13,EMS14,EMS15,EMS16,0
14	072504	077536	101205	000000	EMT14:	.WORD EMS17,EMS64,0
15	072512	077370	077621	000000	EMT15:	.WORD EMS11,EMS21,0
16	072520	077370	077644	077773	EMT16:	.WORD EMS11,EMS22,EMS27,0
17	072530	077370	077660	100004	EMT17:	.WORD EMS11,EMS23,EMS30,0
18	072540	077370	077706	100004	EMT20:	.WORD EMS11,EMS24,EMS30,0
19	072550	077370	077735	077773	EMT21:	.WORD EMS11,EMS25,EMS27,0
20	072560	077370	077752	077773	EMT22:	.WORD EMS11,EMS26,EMS27,0
21	072570	077370	100014	100004	EMT23:	.WORD EMS11,EMS31,EMS30,0
22	072600	077370	100043	100004	EMT24:	.WORD EMS11,EMS32,EMS30,0
23	072610	077370	100072	100004	EMT25:	.WORD EMS11,EMS33,EMS30,0
24	072620	077370	100120	100004	EMT26:	.WORD EMS11,EMS34,EMS30,0
25	072630	077370	100171	100004	EMT27:	.WORD EMS11,EMS35,EMS30,0
26	072640	077370	100220	100004	EMT30:	.WORD EMS11,EMS36,EMS30,0
27	072650	077370	100247	100004	EMT31:	.WORD EMS11,EMS37,EMS30,0
28	072660	077370	100275	100004	EMT32:	.WORD EMS11,EMS40,EMS30,0
29	072670	077370	100324	100004	EMT33:	.WORD EMS11,EMS41,EMS30,0
30	072700	077370	100352	100004	EMT34:	.WORD EMS11,EMS42,EMS30,0
31	072710	077370	100401	100004	EMT35:	.WORD EMS11,EMS43,EMS30,0
32	072720	077370	100430	100004	EMT36:	.WORD EMS11,EMS44,EMS30,0
33	072730	077370	100503	100004	EMT37:	.WORD EMS11,EMS45,EMS30,0
34	072740	101271	077576	000000	EMT40:	.WORD EMS66,EMS20,0
35	072746	101457	103170	101465	EMT41:	.WORD EMS75,EMS141,EMS76,0
36	072756	103261	103271	101413	EMT42:	.WORD EMS144,EMS145,EMS72,EMS76,0
37	072770	100575	100711	101465	EMT43:	.WORD EMS47,EMS53,EMS76,0
38	073000	101516	100711	101465	EMT44:	.WORD EMS77,EMS53,EMS76,0
39	073010	101544	100711	101465	EMT45:	.WORD EMS100,EMS53,EMS76,0
40	073020	101572	100711	101465	EMT46:	.WORD EMS101,EMS53,EMS76,0
41	073030	101223	101205	000000	EMT47:	.WORD EMS65,EMS64,0
42	073036	077442	077464	101157	EMT50:	.WORD EMS13,EMS15,EMS63,0
43	073046	077370	100546	100004	EMT51:	.WORD EMS11,EMS46,EMS30,EMS67,0
44	073060	100575	100711	101341	EMT52:	.WORD EMS47,EMS53,EMS67,EMS115,EMS140,EMS141,0
45	073076	100575	100711	101341	EMT53:	.WORD EMS47,EMS53,EMS67,EMS115,EMS141,EMS164,0
46	073114	100624	100711	101341	EMT54:	.WORD EMS50,EMS53,EMS67,0
47	073124	103216	103233	100711	EMT55:	.WORD EMS142,EMS143,EMS53,EMS67,0
48	073136	100653	101413	101341	EMT56:	.WORD EMS51,EMS72,EMS67,EMS115,EMS50,EMS70,0
49	073154	103766	101423	101341	EMT57:	.WORD EMS167,EMS73,EMS67,0
50	073164	100774	101341	102153	EMT60:	.WORD EMS56,EMS67,EMS115,EMS150,EMS152,EMS70,0
51	073202	101400	100774	101341	EMT61:	.WORD EMS71,EMS56,EMS67,EMS115,EMS150,EMS152,EMS72,0
52	073222	103147	101341	102153	EMT62:	.WORD EMS140,EMS67,EMS115,EMS47,EMS70,0
53	073236	000000			EMT63:	.WORD
54	073240	103354	103416	101366	EMT64:	.WORD EMS150,EMS152,EMS70,EMS115,EMS56,EMS73,EMS67,0
55	073260	100701	104413	104574	EMT65:	.WORD EMS52,EMS205,EMS214,EMS206,EMS115,EMS51,EMS72,0
56	073300	103725	101647	101413	EMT66:	.WORD EMS165,EMS103,EMS72,EMS124,0
57	073312	103725	101647	101413	EMT67:	.WORD EMS165,EMS103,EMS72,EMS171,0

58	073324	100546	077576	103620	EMT70:	.WORD	EMS46,EMS20,EMS163,0
59	073334	101400	101572	103620	EMT71:	.WORD	EMS71,EMS101,EMS163,0
60	073344	100575	101413	103620	EMT72:	.WORD	EMS47,EMS72,EMS163,EMS115,EMS140,EMS141,0
61	073362	100575	101413	103620	EMT73:	.WORD	EMS47,EMS72,EMS163,EMS115,EMS141,EMS72,0
62	073400	100774	100711	103620	EMT74:	.WORD	EMS56,EMS53,EMS163,0
63	073410	101400	100774	103620	EMT75:	.WORD	EMS71,EMS56,EMS163,EMS115,EMS150,EMS152,EMS72,0
64	073430	100624	100711	103620	EMT76:	.WORD	EMS50,EMS53,EMS163,0
65	073440	103216	103233	100711	EMT77:	.WORD	EMS142,EMS143,EMS53,EMS163,0
66	073452	101457	103170	103620	EMT100:	.WORD	EMS75,EMS141,EMS163,EMS115,EMS47,EMS70,0
67	073470	101457	103354	103620	EMT101:	.WORD	EMS75,EMS150,EMS163,EMS115,EMS56,EMS73,0
68	073506	103766	101423	103620	EMT102:	.WORD	EMS167,EMS73,EMS163,0
69	073516	103337	103372	101440	EMT103:	.WORD	EMS147,EMS151,EMS74,EMS163,0
70	073530	100653	101440	103620	EMT104:	.WORD	EMS51,EMS74,EMS163,EMS115,EMS50,EMS70,0
71	073546	103725	101544	103620	EMT105:	.WORD	EMS165,EMS100,EMS163,0
72	073556	103725	101516	103620	EMT106:	.WORD	EMS165,EMS77,EMS163,0
73	073566	103261	103271	100711	EMT107:	.WORD	EMS144,EMS145,EMS53,EMS163,EMS115,EMS143,EMS70,0
74	073606	101753	102013	102156	EMT110:	.WORD	EMS110,EMS112,EMS116,EMS111,0
75	073620	102077	077121	000000	EMT111:	.WORD	EMS113,EMS4,0
76	073626	102077	077056	000000	EMT112:	.WORD	EMS113,EMS3,0
77	073634	101753	102153	102156	EMT113:	.WORD	EMS110,EMS115,EMS116,EMS117,EMS114,0
78	073650	102077	102230	000000	EMT114:	.WORD	EMS113,EMS120,0
79	073656	102251	102711	102735	EMT115:	.WORD	EMS121,EMS132,EMS133,0
80	073666	102314	102711	102735	EMT116:	.WORD	EMS122,EMS132,EMS133,0
81	073676	102351	102711	102735	EMT117:	.WORD	EMS123,EMS132,EMS133,0
82	073706	102414	102711	102735	EMT120:	.WORD	EMS124,EMS132,EMS133,0
83	073716	102446	102711	102735	EMT121:	.WORD	EMS125,EMS132,EMS133,0
84	073726	102511	102711	102735	EMT122:	.WORD	EMS126,EMS132,EMS133,0
85	073736	103112	102711	102735	EMT123:	.WORD	EMS137,EMS132,EMS133,0
86	073746	102613	102711	102735	EMT124:	.WORD	EMS130,EMS132,EMS133,0
87	073756	102651	102711	102735	EMT125:	.WORD	EMS131,EMS132,EMS133,0
88	073766	102251	102711	102760	EMT126:	.WORD	EMS121,EMS132,EMS134,EMS123,0
89	074000	102314	102711	102760	EMT127:	.WORD	EMS122,EMS132,EMS134,EMS123,0
90	074012	102351	102711	102760	EMT130:	.WORD	EMS123,EMS132,EMS134,EMS123,0
91	074024	102414	102711	102760	EMT131:	.WORD	EMS124,EMS132,EMS134,EMS123,0
92	074036	102446	102711	102760	EMT132:	.WORD	EMS125,EMS132,EMS134,EMS123,0
93	074050	102511	102711	102760	EMT133:	.WORD	EMS126,EMS132,EMS134,EMS123,0
94	074062	103112	102711	102760	EMT134:	.WORD	EMS137,EMS132,EMS134,EMS123,0
95	074074	102613	102711	102760	EMT135:	.WORD	EMS130,EMS132,EMS134,EMS123,0
96	074106	102651	102711	102760	EMT136:	.WORD	EMS131,EMS132,EMS134,EMS123,0
97	074120	102251	102711	103022	EMT137:	.WORD	EMS121,EMS132,EMS135,0
98	074130	102351	102711	103022	EMT140:	.WORD	EMS123,EMS132,EMS135,0
99	074140	102251	102711	103065	EMT141:	.WORD	EMS121,EMS132,EMS136,0
100	074150	103112	102711	103065	EMT142:	.WORD	EMS137,EMS132,EMS136,0
101	074160	102414	102711	103065	EMT143:	.WORD	EMS124,EMS132,EMS136,0
102	074170	102446	102711	103065	EMT144:	.WORD	EMS125,EMS132,EMS136,0
103	074200	102511	102711	103065	EMT145:	.WORD	EMS126,EMS132,EMS136,0
104	074210	102651	102711	103065	EMT146:	.WORD	EMS131,EMS132,EMS136,0
105	074220	104042	102711	103065	EMT147:	.WORD	EMS171,EMS132,EMS136,0
106	074230	102613	102711	103065	EMT150:	.WORD	EMS130,EMS132,EMS136,0
107	074240	103147	102153	103170	EMT151:	.WORD	EMS140,EMS115,EMS141,EMS70,0
108	074252	103216	102153	103233	EMT152:	.WORD	EMS142,EMS115,EMS143,EMS72,0
109	074264	103261	103271	103320	EMT153:	.WORD	EMS144,EMS145,EMS146,EMS115,EMS143,EMS72,0
110	074302	103261	103271	077576	EMT154:	.WORD	EMS144,EMS145,EMS20,EMS115,EMS143,EMS70,0
111	074320	103354	103416	103464	EMT155:	.WORD	EMS150,EMS152,EMS154,EMS153,0
112	074332	103337	103372	103464	EMT156:	.WORD	EMS147,EMS151,EMS154,EMS155,0
113	074344	103337	103372	103520	EMT157:	.WORD	EMS147,EMS151,EMS156,EMS157,0
114	074356	103570	103520	103553	EMT160:	.WORD	EMS161,EMS156,EMS160,0

115	074366	077735	077773	103520	EMT161:	.WORD	EMS25,EMS27,EMS156,EMS160,0
116	074400	077752	077773	103520	EMT162:	.WORD	EMS26,EMS27,EMS156,EMS160,0
117	074412	100575	103620	103147	EMT163:	.WORD	EMS47,EMS163,EMS140,0
118	074422	100575	077576	000000	EMT164:	.WORD	EMS47,EMS20,0
119	074430	100774	077576	000000	EMT165:	.WORD	EMS56,EMS20,0
120	074436	100546	077576	000000	EMT166:	.WORD	EMS46,EMS20,0
121	074444	105114	077576	000000	EMT167:	.WORD	EMS224,EMS20,0
122	074452	104352	103170	100004	EMT170:	.WORD	EMS203,EMS141,EMS30,EMS202,0
123	074464	103766	103464	103536	EMT171:	.WORD	EMS167,EMS154,EMS157,0
124	074474	103766	103464	103500	EMT172:	.WORD	EMS167,EMS154,EMS155,0
125	074504	104042	102711	102735	EMT173:	.WORD	EMS171,EMS132,EMS133,0
126	074514	104042	102711	102760	EMT174:	.WORD	EMS171,EMS132,EMS134,EMS123,0
127	074526	102077	104215	000000	EMT175:	.WORD	EMS113,EMS177,0
128	074534	104237	104254	000000	EMT176:	.WORD	EMS200,EMS201,0
129	074542	000000			EMT177:	.WORD	
130	074544	104352	100653	100004	EMT200:	.WORD	EMS203,EMS51,EMS30,EMS202,0
131	074556	104352	104365	100004	EMT201:	.WORD	EMS203,EMS204,EMS30,EMS202,0
132	074570	104352	100624	100004	EMT202:	.WORD	EMS203,EMS50,EMS30,EMS202,0
133	074602	104352	103233	100004	EMT203:	.WORD	EMS203,EMS143,EMS30,EMS202,0
134	074614	103354	101440	104322	EMT204:	.WORD	EMS150,EMS74,EMS202,EMS115,EMS152,EMS72,0
135	074632	100624	101647	101413	EMT205:	.WORD	EMS50,EMS103,EMS72,0
136	074642	101656	101423	104322	EMT206:	.WORD	EMS104,EMS73,EMS202,0
137	074652	101457	103170	102153	EMT207:	.WORD	EMS75,EMS141,EMS115,EMS140,0
138	074664	101457	103354	000000	EMT210:	.WORD	EMS75,EMS150,0
139	074672	100653	101413	102153	EMT211:	.WORD	EMS51,EMS72,EMS115,EMS50,EMS70,0
140	074706	103216	100711	102153	EMT212:	.WORD	EMS142,EMS53,EMS115,EMS143,EMS72,0
141	074722	100624	101647	100711	EMT213:	.WORD	EMS50,EMS103,EMS53,0
142	074732	100701	104413	103741	EMT214:	.WORD	EMS52,EMS205,EMS166,EMS206,EMS115,EMS51,EMS72,0
143	074752	100701	102206	100774	EMT215:	.WORD	EMS52,EMS117,EMS56,EMS163,0
144	074764	100774	100004	101205	EMT216:	.WORD	EMS56,EMS30,EMS64,0
145	074774	100546	100004	101205	EMT217:	.WORD	EMS46,EMS30,EMS64,0
146	075004	100014	100004	101205	EMT220:	.WORD	EMS31,EMS30,EMS64,0
147	075014	100575	100004	101205	EMT221:	.WORD	EMS47,EMS30,EMS64,0
148	075024	100701	102206	101516	EMT222:	.WORD	EMS52,EMS117,EMS77,0
149	075034	100701	102206	101157	EMT223:	.WORD	EMS52,EMS117,EMS63,0
150	075044	000000			EMT224:	.WORD	
151	075046	000000			EMT225:	.WORD	
152	075050	000000			EMT226:	.WORD	
153	075052	000000			EMT227:	.WORD	
154	075054	000000			EMT230:	.WORD	
155	075056	000000			EMT231:	.WORD	
156	075060	000000			EMT232:	.WORD	
157	075062	000000			EMT233:	.WORD	
158	075064	000000			EMT234:	.WORD	
159	075066	000000			EMT235:	.WORD	
160	075070	000000			EMT236:	.WORD	
161	075072	000000			EMT237:	.WORD	
162	075074	000000			EMT240:	.WORD	
163	075076	000000			EMT241:	.WORD	
164	075100	000000			EMT242:	.WORD	
165	075102	000000			EMT243:	.WORD	
166	075104	000000			EMT244:	.WORD	
167	075106	000000			EMT245:	.WORD	
168	075110	103766	102711	104452	EMT246:	.WORD	EMS167,EMS132,EMS207,0
169	075120	103766	102711	104477	EMT247:	.WORD	EMS167,EMS132,EMS210,EMS125,0
170	075132	103766	104510	104477	EMT250:	.WORD	EMS167,EMS211,EMS210,EMS207,EMS206,0
171	075146	104526	104551	000000	EMT251:	.WORD	EMS212,EMS213,0

172	075154	103725	104526	000000	EMT252: .WORD	EMS165,EMS212,0
173	075162	103337	103372	103520	EMT253: .WORD	EMS147,EMS151,EMS156,EMS210,EMS26,EMS27,0
174	075200	104352	101572	100004	EMT254: .WORD	EMS203,EMS101,EMS30,0
175	075210	104352	103766	100004	EMT255: .WORD	EMS203,EMS167,EMS30,0
176	075220	104352	101544	100004	EMT256: .WORD	EMS203,EMS100,EMS30,0
177	075230	077370	100546	100004	EMT257: .WORD	EMS11,EMS46,EMS30,EMS102,0
178	075242	100701	102206	100774	EMT260: .WORD	EMS52,EMS117,EMS56,EMS102,0
179	075254	100701	104413	104716	EMT261: .WORD	EMS52,EMS205,EMS220,EMS206,EMS115,EMS51,EMS72,0
180	075274	101656	101423	104322	EMT262: .WORD	EMS104,EMS73,EMS202,0
181	075304	100624	100711	101620	EMT263: .WORD	EMS50,EMS53,EMS102,0
182	075314	100774	100711	101620	EMT264: .WORD	EMS56,EMS53,EMS102,EMS115,EMS150,EMS152,EMS70,0
183	075334	101400	100774	101620	EMT265: .WORD	EMS71,EMS56,EMS102,EMS115,EMS150,EMS152,EMS72,0
184	075354	103216	103233	100711	EMT266: .WORD	EMS142,EMS143,EMS53,EMS102,0
185	075366	100624	103320	102153	EMT267: .WORD	EMS50,EMS146,EMS115,EMS52,EMS117,EMS46,0
186	075404	100575	100711	101620	EMT270: .WORD	EMS47,EMS53,EMS102,EMS115,EMS140,0
187	075420	100575	100711	101620	EMT271: .WORD	EMS47,EMS53,EMS102,EMS115,EMS141,EMS72,0
188	075436	101457	103170	101620	EMT272: .WORD	EMS75,EMS141,EMS102,EMS115,EMS47,EMS73,0
189	075454	100653	101440	101620	EMT273: .WORD	EMS51,EMS74,EMS102,EMS115,EMS50,EMS70,0
190	075472	101157	100711	101051	EMT274: .WORD	EMS63,EMS53,EMS57,EMS115,EMS41,EMS146,0
191	075510	102153	100711	100324	EMT275: .WORD	EMS116,EMS53,EMS41,EMS57,0
192	075522	100575	100711	101051	EMT276: .WORD	EMS47,EMS53,EMS57,EMS115,EMS140,0
193	075536	100575	100711	101051	EMT277: .WORD	EMS47,EMS53,EMS57,EMS115,EMS141,EMS72,0
194	075554	100774	100711	101051	EMT300: .WORD	EMS56,EMS53,EMS57,EMS115,EMS150,EMS152,EMS70,0
195	075574	101400	100774	100711	EMT301: .WORD	EMS71,EMS56,EMS53,EMS57,EMS115,EMS150,EMS152,EMS72,0
196	075616	103725	101544	101647	EMT302: .WORD	EMS165,EMS100,EMS103,EMS57,0
197	075630	103725	101572	101647	EMT303: .WORD	EMS165,EMS101,EMS103,EMS57,0
198	075642	103725	101516	101647	EMT304: .WORD	EMS165,EMS77,EMS103,EMS57,0
199	075654	100546	100004	101205	EMT305: .WORD	EMS46,EMS30,EMS64,EMS57,0
200	075666	100624	100711	101051	EMT306: .WORD	EMS50,EMS53,EMS57,0
201	075676	100624	103320	102153	EMT307: .WORD	EMS50,EMS146,EMS115,EMS52,EMS117,EMS46,EMS57,0
202	075716	103216	103233	100711	EMT310: .WORD	EMS142,EMS143,EMS53,EMS57,0
203	075730	101656	101647	100711	EMT311: .WORD	EMS104,EMS103,EMS53,EMS57,0
204	075742	101705	101647	100711	EMT312: .WORD	EMS105,EMS103,EMS53,EMS57,0
205	075754	103261	103271	101647	EMT313: .WORD	EMS144,EMS145,EMS103,EMS57,EMS115,EMS143,EMS70,0
206	075774	100352	101647	100711	EMT314: .WORD	EMS42,EMS103,EMS53,EMS57,0
207	076006	100014	101647	100711	EMT315: .WORD	EMS31,EMS103,EMS53,EMS57,0
208	076020	101400	100014	101647	EMT316: .WORD	EMS71,EMS31,EMS103,EMS57,0
209	076032	100401	101647	101051	EMT317: .WORD	EMS43,EMS103,EMS57,0
210	076042	100503	101647	101051	EMT320: .WORD	EMS45,EMS103,EMS57,0
211	076052	100430	101647	101051	EMT321: .WORD	EMS44,EMS103,EMS57,0
212	076062	101734	077576	000000	EMT322: .WORD	EMS106,EMS20,0
213	076070	100220	101647	101051	EMT323: .WORD	EMS36,EMS103,EMS57,0
214	076100	104115	100220	101647	EMT324: .WORD	EMS173,EMS36,EMS103,EMS57,0
215	076112	104075	100220	101647	EMT325: .WORD	EMS172,EMS36,EMS103,EMS57,0
216	076124	077442	104132	077464	EMT326: .WORD	EMS13,EMS174,EMS15,EMS35,EMS53,EMS175,0
217	076142	103337	103372	101440	EMT327: .WORD	EMS147,EMS151,EMS74,EMS175,0
218	076154	101271	100711	104140	EMT330: .WORD	EMS66,EMS53,EMS175,0
219	076164	100072	101647	100711	EMT331: .WORD	EMS33,EMS103,EMS53,EMS175,0
220	076176	100275	101647	100711	EMT332: .WORD	EMS40,EMS103,EMS53,EMS57,0
221	076210	100653	101440	101051	EMT333: .WORD	EMS51,EMS74,EMS57,EMS115,EMS50,EMS70,0
222	076226	101457	103170	101051	EMT334: .WORD	EMS75,EMS141,EMS57,EMS115,EMS47,EMS73,0
223	076244	101457	103354	103416	EMT335: .WORD	EMS75,EMS150,EMS152,EMS57,EMS115,EMS56,EMS73,0
224	076264	101077	101112	101141	EMT336: .WORD	EMS60,EMS61,EMS62,0
225	076274	102156	102206	100120	EMT337: .WORD	EMS116,EMS117,EMS34,0
226	076304	100120	100711	100723	EMT340: .WORD	EMS34,EMS53,EMS54,EMS111,0
227	076316	100745	100120	000000	EMT341: .WORD	EMS55,EMS34,0
228	076324	100701	102206	100774	EMT342: .WORD	EMS52,EMS117,EMS56,EMS57,0

229	076336	100701	102206	100503	EMT343: .WORD	EMS52,EMS117,EMS45,EMS57,0
230	076350	100701	102206	100430	EMT344: .WORD	EMS52,EMS117,EMS44,EMS57,0
231	076362	100701	102206	104736	EMT345: .WORD	EMS52,EMS117,EMS221,0
232	076372	101734	077576	102153	EMT346: .WORD	EMS106,EMS20,EMS115,EMS223,EMS72,0
233	076406	100701	104413	105006	EMT347: .WORD	EMS52,EMS205,EMS222,EMS206,0
234	076420	101457	103354	101620	EMT350: .WORD	EMS75,EMS150,EMS102,EMS115,EMS56,EMS73,0
235	076436	103766	101423	101620	EMT351: .WORD	EMS167,EMS73,EMS102,0
236	076446	104612	000000		EMT352: .WORD	EMS215,0
237	076452	104663	104352	104633	EMT353: .WORD	EMS217,EMS203,EMS216,0
238	076462	104736	077576	000000	EMT354: .WORD	EMS221,EMS20,0

1	076470	105166	105772	106047	EHT1:	.WORD	EH1,STSH1,STSH2,STSH4,0
2	076502	105772	106047	106174	EHT2:	.WORD	STSH1,STSH2,STSH4,0
3							
4	076512	105205	000000		EHT110:	.WORD	EH110,0
5	076516	105214	000000		EHT111:	.WORD	EH111,0
6							
7	076522	105233	000000		EHT114:	.WORD	EH114,0
8	076526	105262	105772	106047	EHT223:	.WORD	EH223,STSH1,STSH2,STSH4,0
9	076540	105310	105772	106047	EHT256:	.WORD	EH256,STSH1,STSH2,STSH4,0
10							
11	076552	105364	105772	106047	EHT336:	.WORD	EH336,STSH1,STSH2,STSH4,0
12	076564	105423	105772	106047	EHT337:	.WORD	EH337,STSH1,STSH2,STSH4,0
13	076576	105560	105772	106047	EHT344:	.WORD	EH344,STSH1,STSH2,STSH4,0
14							
15	076610	105716	000000		EHT353:	.WORD	EH353,0

1	076614	106232	106326	106344	EDT1:	.WORD	ED1,STSD1,STSD2,STSD4
2	076624	106326	106344	106376	EDT2:	.WORD	STSD1,STSD2,STSD4
3							
4	076632	106240			EDT110:	.WORD	ED110
5	076634	106244			EDT111:	.WORD	ED111
6							
7	076636	106252			EDT114:	.WORD	ED114
8	076640	106262	106326	106344	EDT223:	.WORD	ED223,STSD1,STSD2,STSD4
9							
10	076650	106272	106326	106344	EDT336:	.WORD	ED336,STSD1,STSD2,STSD4
11	076660	106304	106326	106344	EDT337:	.WORD	ED337,STSD1,STSD2,STSD4
12	076670	106304	106326	106344	EDT344:	.WORD	ED337,STSD1,STSD2,STSD4,0
13							
14	076702	106316			EDT353:	.WORD	ED353

1	076704	106411	106427	106427	EFT1:	.WORD	EF111,STSF,STSF,STSF
2	076714	106427	106427	106427	EFT2:	.WORD	STSF,STSF,STSF
3							
4	076722	106410			EFT110:	.WORD	EF110
5	076724	106411			EFT111:	.WORD	EF111
6							
7	076726	106413			EFT114:	.WORD	EF114
8	076730	106413	106427	106427	EFT223:	.WORD	EF114,STSF,STSF,STSF
9							
10	076740	106416	106427	106427	EFT336:	.WORD	EF336,STSF,STSF,STSF
11	076750	106416	106427	106427	EFT337:	.WORD	EF336,STSF,STSF,STSF
12	076760	106416	106427	106427	EFT344:	.WORD	EF336,STSF,STSF,STSF
13							
14	076770	106413			EFT353:	.WORD	EF114

				.SBTTL ERROR MESSAGE STRINGS	
3	076772	127	122	117	EMS1: .ASCIZ @WRONG UNIT SELECTED (RMCS2, BITS 0-2) @
4	077041	104	105	126	EMS2: .ASCIZ @DEVICE WENT @
5	077056	125	116	101	EMS3: .ASCIZ @UNAVAILABLE 'DVA' (RMCS1, BIT 11) @
6	077121	116	117	116	EMS4: .ASCIZ @NONEXISTENT 'NED' (RMCS2, BIT 12) @
7	077164	103	117	115	EMS5: .ASCIZ @COMMAND NOT COMPLETED, @
8	077214	103	117	116	EMS6: .ASCIZ @CONTROLLER NOT READY (RMCS1, BIT 7) @
9	077261	104	122	111	EMS7: .ASCIZ @DRIVE NOT READY 'DRY' (RMDS, BIT 7) @
10	077326	107	117	040	EMS10: .ASCIZ @GO NOT RESET 'GO' (RMCS1, BIT 0) @
11	077370	111	116	126	EMS11: .ASCIZ @INVALID @
12	077401	106	125	116	EMS12: .ASCIZ @FUNCTION CODE (RMCS1, BITS 1-5) @
13	077442	115	101	123	EMS13: .ASCIZ @MASSBUS @
14	077453	103	117	116	EMS14: .ASCIZ @CONTROL @
15	077464	102	125	123	EMS15: .ASCIZ @BUS PARITY ERROR @
16	077506	042	115	103	EMS16: .ASCIZ @'MCPE' (RMCS1, BIT 13) @
17	077536	124	122	101	EMS17: .ASCIZ @TRANSFER ERROR (RMCS1, BIT 14) @
18	077576	123	110	117	EMS20: .ASCIZ @SHOULD NOT BE SET @
19	077621	127	117	122	EMS21: .ASCIZ @WORD COUNT (RMWC) @
20	077644	102	125	123	EMS22: .ASCIZ @BUS (RMB) @
21	077660	042	114	102	EMS23: .ASCIZ @'LBT' (RMDS, BIT 10) @
22	077706	042	101	117	EMS24: .ASCIZ @'AOE' (RMER1, BIT 09) @
23	077735	104	111	123	EMS25: .ASCIZ @DISK (RMDA) @
24	077752	103	131	114	EMS26: .ASCIZ @CYLINDER (RMDC) @
25	077773	101	104	104	EMS27: .ASCIZ @ADDRESS @
26	100004	123	124	101	EMS30: .ASCIZ @STATUS @
27	100014	042	127	114	EMS31: .ASCIZ @'WLE' (RMER1, BIT 11) @
28	100043	042	125	120	EMS32: .ASCIZ @'UPE' (RMCS2, BIT 13) @
29	100072	042	127	103	EMS33: .ASCIZ @'WCF' (RMER1, BIT 5) @
30	100120	127	122	111	EMS34: .ASCIZ @WRITE CHECK ERROR-'WCE' (RMCS2, BIT 14) @
31	100171	042	115	104	EMS35: .ASCIZ @'MDPE' (RMCS2, BIT 8) @
32	100220	042	104	103	EMS36: .ASCIZ @'DCK' (RMER1, BIT 15) @
33	100247	042	105	103	EMS37: .ASCIZ @'ECH' (RMER1, BIT 6) @
34	100275	042	104	114	EMS40: .ASCIZ @'DLT' (RMCS2, BIT 15) @
35	100324	042	115	130	EMS41: .ASCIZ @'MXF' (RMCS2, BIT 9) @
36	100352	042	104	124	EMS42: .ASCIZ @'DTE' (RMER1, BIT 12) @
37	100401	042	110	103	EMS43: .ASCIZ @'HCRC' (RMER1, BIT 8) @
38	100430	110	105	101	EMS44: .ASCIZ @HEADER COMPARE ERROR 'HCE' (RMER1, BIT 7) @
39	100503	106	117	122	EMS45: .ASCIZ @FORMAT ERROR 'FER' (RMER1, BIT 4) @
40	100546	042	111	101	EMS46: .ASCIZ @'IAE' (RMER1, BIT 10) @
41	100575	042	117	120	EMS47: .ASCIZ @'DPI' (RMER1, BIT 13) @
42	100624	042	123	113	EMS50: .ASCIZ @'SKI' (RMER2, BIT 14) @
43	100653	042	120	111	EMS51: .ASCIZ @'PIP' (RMDS, BIT 13) @
44	100701	124	110	105	EMS52: .ASCIZ @THE RM @
45	100711	104	105	124	EMS53: .ASCIZ @DETECTED @
46	100723	101	124	040	EMS54: .ASCIZ @AT AN UNEXPECTED @
47	100745	111	116	103	EMS55: .ASCIZ @INCORRECT DATA DURING @
48	100774	111	116	126	EMS56: .ASCIZ @INVALID COMMAND ERROR 'IVC' (RMER2, BIT 12) @
49	101051	104	125	122	EMS57: .ASCIZ @DURING DATA TRANSFER @
50	101077	104	101	124	EMS60: .ASCIZ @DATA READ @
51	101112	104	117	105	EMS61: .ASCIZ @DOES NOT COMPARE WITH @
52	101141	104	101	124	EMS62: .ASCIZ @DATA WRITTEN @
53	101157	042	120	101	EMS63: .ASCIZ @'PAR' (RMER1, BIT 3) @
54	101205	111	123	040	EMS64: .ASCIZ @IS INCORRECT @
55	101223	103	117	115	EMS65: .ASCIZ @COMPOSITE ERROR 'ERR' (RMDS, BIT 14) @
56	101271	104	101	124	EMS66: .ASCIZ @DATA PARITY ERROR 'DPE' (RMER2, BIT 3) @
57	101341	104	125	122	EMS67: .ASCIZ @DURING SEEK COMMAND @

58	101366	111	123	.040	EMS70:	.ASCIZ	@IS RESET @
59	101400	105	122	122	EMS71:	.ASCIZ	@ERRONEOUS @
60	101413	111	123	040	EMS72:	.ASCIZ	@IS SET @
61	101423	104	111	104	EMS73:	.ASCIZ	@DID NOT SET @
62	101440	104	111	104	EMS74:	.ASCIZ	@DID NOT RESET @
63	101457	114	117	123	EMS75:	.ASCIZ	@LOST @
64	101465	104	125	122	EMS76:	.ASCIZ	@DURING PACK ACK COMMAND @
65	101516	042	122	115	EMS77:	.ASCIZ	@'RMR' (RMER1, BIT 2) @
66	101544	042	111	114	EMS100:	.ASCIZ	@'ILR' (RMER1, BIT 1) @
67	101572	042	111	114	EMS101:	.ASCIZ	@'ILF' (RMER1, BIT 0) @
68	101620	104	125	122	EMS102:	.ASCIZ	@DURING SEARCH COMMAND @
69	101647	105	122	122	EMS103:	.ASCIZ	@ERROR @
70	101656	042	114	102	EMS104:	.ASCIZ	@'LBC' (RMER2, BIT 10) @
71	101705	042	114	123	EMS105:	.ASCIZ	@'LSC' (RMER2, BIT 11) @
72	101734	110	105	101	EMS106:	.ASCIZ	@HEADER ERRORS @
73	101753	102	125	123	EMS110:	.ASCIZ	@BUS TIMEOUT (04 TRAP) @
74	102002	101	104	104	EMS111:	.ASCIZ	@ADDRESS @
75	102013	127	110	105	EMS112:	.ASCII	@WHEN READING/WRITING RH REGISTERS @
76	102055	101	124	040		.ASCIZ	@AT THE FOLLOWING @
77	102077	124	110	105	EMS113:	.ASCIZ	@THE SELECTED DEVICE IS @
78	102127	116	117	116	EMS114:	.ASCIZ	@NONEXISTENT DEVICE @
79	102153	015	012	000	EMS115:	.ASCIZ	<CR><LF>
80	102156	124	110	105	EMS116:	.ASCIZ	@THE MASSBUS CONTROLLER @
81	102206	106	101	111	EMS117:	.ASCIZ	@FAILED TO DETECT @
82	102230	116	117	124	EMS120:	.ASCIZ	@NOT AN RM05/3/2 @
83	102251	103	117	116	EMS121:	.ASCIZ	@CONTROL STATUS REGISTER 1, RMCS1, @
84	102314	102	125	123	EMS122:	.ASCIZ	@BUS ADDRESS REGISTER, RMAA, @
85	102351	103	117	116	EMS123:	.ASCIZ	@CONTROL STATUS REGISTER 2, RMCS2, @
86	102414	105	122	122	EMS124:	.ASCIZ	@ERROR REGISTER 1, RMER1, @
87	102446	101	124	124	EMS125:	.ASCIZ	@ATTENTION SUMMARY REGISTER, RMAA, @
88	102511	115	101	111	EMS126:	.ASCIZ	@MAINTENANCE REGISTER #1, RMMR #1, @
89	102554	105	103	103	EMS127:	.ASCIZ	@ECC POSITION REGISTER, RMEC1, @
90	102613	105	103	103	EMS130:	.ASCIZ	@ECC PATTERN REGISTER, RMEC2, @
91	102651	115	101	111	EMS131:	.ASCIZ	@MAINTENANCE REGISTER 2, RMMR2, @
92	102711	116	117	124	EMS132:	.ASCIZ	@NOT INITIALIZED BY @
93	102735	125	116	111	EMS133:	.ASCIZ	@UNIBUS INITIALIZE @
94	102760	103	117	116	EMS134:	.ASCIZ	@CONTROLLER CLEAR, I.E. BIT 5 OF @
95	103022	122	110	057	EMS135:	.ASCIZ	@RH/RM ERROR CLEAR (RMCS1, BIT 14) @
96	103065	104	122	111	EMS136:	.ASCIZ	@DRIVE CLEAR COMMAND @
97	103112	104	122	111	EMS137:	.ASCIZ	@DRIVE STATUS REGISTER, RMDS @
98	103147	115	105	104	EMS140:	.ASCIZ	@MEDIUM OFF LINE @
99	103170	042	115	117	EMS141:	.ASCIZ	@'MOL' (RMDS, BIT 12) @
100	103216	104	122	111	EMS142:	.ASCIZ	@DRIVE FAULT @
101	103233	042	104	126	EMS143:	.ASCIZ	@'DVC' (RMER2, BIT 7) @
102	103261	125	116	123	EMS144:	.ASCIZ	@UNSAFE @
103	103271	042	125	116	EMS145:	.ASCIZ	@'UNS' (RMER1, BIT 14) @
104	103320	123	110	117	EMS146:	.ASCIZ	@SHOULD BE SET @
105	103337	117	106	106	EMS147:	.ASCIZ	@OFFSET MODE @
106	103354	126	117	114	EMS150:	.ASCIZ	@VOLUME VALID @
107	103372	042	117	115	EMS151:	.ASCIZ	@'OM' (RMDS, BIT 0) @
108	103416	042	126	126	EMS152:	.ASCIZ	@'VV' (RMDS, BIT 6) @
109	103442	120	101	103	EMS153:	.ASCIZ	@PACK ACK COMMAND @
110	103464	116	117	124	EMS154:	.ASCIZ	@NOT SET BY @
111	103500	117	106	106	EMS155:	.ASCIZ	@OFFSET COMMAND @
112	103520	116	117	124	EMS156:	.ASCIZ	@NOT RESET BY @
113	103536	122	124	103	EMS157:	.ASCIZ	@RTC COMMAND @
114	103553	122	111	120	EMS160:	.ASCIZ	@RIP COMMAND @

Line	Address	Offset	Register	Value	Description
115	103570	117	106	EMS161: .ASCIZ	@OFFSET REGISTER (RMOF) @
116	103620			EMS162:	:<UNUSED>
117	103620	104	125	EMS163: .ASCIZ	@DURING RECALIBRATE @
118	103644	111	123	EMS164: .ASCII	@IS INTERMITTENT OR DRIVE DIDNT DROP ON @
119	103713	103	131	.ASCIZ	@CYLINDER @
120	103725	125	116	EMS165: .ASCIZ	@UNEXPECTED @
121	103741	122	105	EMS166: .ASCIZ	@RECALIBRATE COMMAND @
122	103766	042	101	EMS167: .ASCIZ	@'ATA' (RMDS, BIT15) @
123	104013	127	110	EMS170: .ASCIZ	@WHEN READING REGISTER @
124	104042	105	122	EMS171: .ASCIZ	@ERROR REGISTER #2, RMER2, @
125	104075	116	117	EMS172: .ASCIZ	@NONRECOVERABLE @
126	104115	122	105	EMS173: .ASCIZ	@RECOVERABLE @
127	104132	104	101	EMS174: .ASCIZ	@DATA @
128	104140	104	125	EMS175: .ASCIZ	@DURING WRITE COMMAND @
129	104166	042	117	EMS176: .ASCIZ	@'DPE' (RMER2, BIT 13) @
130	104215	111	116	EMS177: .ASCIZ	@IN WRITE PROTECT @
131	104237	103	101	EMS200: .ASCIZ	@CAN NOT SET @
132	104254	104	111	EMS201: .ASCIZ	@DIAGNOSTIC MODE 'DMD' (RMMR1, BIT 0) @
133	104322	104	125	EMS202: .ASCIZ	@DURING DIAGNOSTIC MODE @
134	104352	111	116	EMS203: .ASCIZ	@INCORRECT @
135	104365	042	127	EMS204: .ASCIZ	@'WRL' (RMDS, BIT 11) @
136	104413	105	130	EMS205: .ASCIZ	@EXECUTED @
137	104425	127	111	EMS206: .ASCIZ	@WITH COMP ERROR SET @
138	104452	042	107	EMS207: .ASCIZ	@'GO' (RMCS1, BIT 0) @
139	104477	127	122	EMS210: .ASCIZ	@WRITING @
140	104510	127	101	EMS211: .ASCIZ	@WAS RESET BY @
141	104526	120	122	EMS212: .ASCIZ	@PROGRAM INTERRUPT @
142	104551	127	101	EMS213: .ASCIZ	@WAS NOT GENERATED @
143	104574	123	105	EMS214: .ASCIZ	@SEEK COMMAND @
144	104612	120	122	EMS215: .ASCIZ	@PROGRAM TIMEOUT @
145	104633	104	125	EMS216: .ASCIZ	@DURING LOOK AHEAD TEST @
146	104663	114	117	EMS217: .ASCIZ	@LOOK AHEAD REGISTER, RMLA, @
147	104716	123	105	EMS220: .ASCIZ	@SEARCH COMMAND @
148	104736	102	101	EMS221: .ASCIZ	@BAD SECTOR ERROR 'BSE' (RMER2, BIT 15) @
149	105006	101	040	EMS222: .ASCIZ	@A DATA TRANSFER COMMAND @
150	105037	110	105	EMS223: .ASCIZ	@HEADER COMPARE INHIBIT 'HCI' (RMOF, BIT 10) @
151	105114	116	117	EMS224: .ASCIZ	@NONEXISTENT MEMORY 'NEM' (RMCS2, BIT 11) @

1	105166	105	130	120	EH1:	.ASCIZ	@EXPCTD	RECEVD@				
2	105205	102	125	123	EH110:	.ASCIZ	@BUSADR@					
3	105214	040	122	115	EH111:	.ASCIZ	@ RMCS2	RMCS1@				
4												
5	105233	122	105	103	EH114:	.ASCIZ	@RECEVD	SNGPRT	DULPRT@			
6	105262	105	130	120	EH223:	.ASCIZ	@EXPCTD	RECEVD	DATA@			
7	105310	105	130	120	EH256:	.ASCII	@EXPCTD	RECEVD	RGSTR@<CRLF>			
8	105336	123	124	101		.ASCIZ	@STATUS	STATUS	INDEX@			
9												
10	105364	107	104	101	EH336:	.ASCIZ	@GDADRS	GDDATA	BDADRS	BDDATA@		
11	105423	122	115	103	EH337:	.ASCII	@RMCS2	STATUS	FAILING	DATA@<CRLF>		
12	105462	137	137	137		.ASCII	@			@<CRLF>		
13	105521	105	130	120		.ASCIZ	@EXPCTD	RECEVD	--BIT--	ADRESS@		
14												
15	105560	122	115	105	EH344:	.ASCII	@RMER1	STATUS	HEADER	FAILING@<CRLF>		
16	105620	137	137	137		.ASCII	@		WORD	BIT@<CRLF>		
17	105656	105	130	120		.ASCIZ	@EXPCTD	RECEVD	NUMBER	POSITION@		
18	105716	105	130	120	EH353:	.ASCII	@EXPCTD	RECEVD@<CRLF>				
19	105735	074	103	122		.ASCIZ	@<CRLF>	RMLA	RMLA	RMOF @		
20												
21	105772	040	122	115	STSH1:	.ASCII	@ RMCS1	RMCS2	RMDS	RMER1	RMER2@	
22	106037	040	040	040		.ASCIZ	@	RMAS@				
23	106047	040	122	115	STSH2:	.ASCII	@ RMWC	RMBA	RMDA	RMOF	RMDCA@	
24	106114	040	040	040		.ASCIZ	@	RMEC1	RMEC2@			
25	106136	040	122	115	STSH3:	.ASCIZ	@ RMDA	RMDC	RMOF	RMLA@		
26	106174	040	122	115	STSH4:	.ASCIZ	@ RMMR1	RMMR2	RMDT	RMSNA@		
27						.EVEN						

1	106232	001140	001142	000000	ED1:	.WORD	\$GDDAT,\$BDDAT,0
2	106240	001276	000000		ED110:	.WORD	\$BASE,0
3	106244	001174	001176	000000	ED111:	.WORD	\$TMP0,\$TMP1,0
4							
5	106252	001364	001176	001200	ED114:	.WORD	RMDTI,\$TMP1,\$TMP2,0
6	106262	001140	001142	001174	ED223:	.WORD	\$GDDAT,\$BDDAT,\$TMP0,0
7							
8	106272	001134	001140	001136	ED336:	.WORD	\$GDADR,\$GDDAT,\$BDADR,\$BDDAT,0
9							
10	106304	001140	001142	001174	ED337:	.WORD	\$GDDAT,\$BDDAT,\$TMP0,\$TMP1,0
11	106316	001140	001142	001444	ED353:	.WORD	\$GDDAT,\$BDDAT,RMOFO,0
12							
13	106326	001336	001346	001350	STSD1:	.WORD	RMCS1I,RMCS2I,RMDSI,RMER1I,RMER2I,RMASI,0
14	106344	001340	001342	001344	STSD2:	.WORD	RMWCI,RMBAI,RMDAI,RMOFI,RMDCI,RMECI
15	106360	001404	000000			.WORD	RMEC2I,0
16	106364	001344	001372	001370	STSD3:	.WORD	RMDAI,RMDCI,RMOFI,RMLAI,0
17	106376	001362	001376	001364	STSD4:	.WORD	RMMR1I,RMMR2I,RMDTI,RMSNI,0

1	106410	000	.	EF110:	.BYTE	0
2	106411	000	000	EF111:	.BYTE	0,0
3	106413	000	000	000	EF114:	.BYTE 0,0,0
4	106416	000	000	000	EF336:	.BYTE 0,0,0,0
5	106422	000	000	000	EF337:	.BYTE 0,0,0,0,0
6						
7	106427	000	000	000	STSF:	.BYTE 0,0,0,0,0,0,0,0
8					.EVEN	

```
1          :STORAGE FOR GENERAL DATA TRANSFERS
2 106436   BUFFER:
3 106436   BUFONE: .BLKW 258.
4 107442   BUFTWO: .BLKW 258.
5
6          :STORAGE FOR MANUFACTURES 16 BIT MODE BAD SECTOR FILE
7 110446   000000 000000 MFGFIL: .WORD 0,0           :2 HEADER WORDS
8 110452   .BLKW 256.           :256. WORDS OF DATA
9 111452   177777           .WORD -1           :TERMINATOR IF FILE IS FULL
10
11         :STORAGE FOR USERS 16 BIT MODE BAD SECTOR FILE
12 111454   000000 000000 USRFIL: .WORD 0,0           :2 HEADER WORDS
13 111460   .BLKW 256.           :256. WORDS OF DATA
14 112460   177777           .WORD -1           :TERMINATOR IF FILE IS FULL
15
16         .=BUFFER
17
18 106436   HELP:
19 106436   200   .ASCII <CRLF>
20 106437   200   .ASCII <CRLF>
21 106440   114   111   123   .ASCII @LIST OF TESTS@<CRLF>
22 106456   055   055   055   .ASCII @-----@<CRLF>
23 106474   124   061   011   .ASCII @T1   CONTROLLER ACCESS TEST@<CRLF>
24 106526   124   062   011   .ASCII @T2   WRITE, READ ZEROS@<CRLF>
25 106553   124   063   011   .ASCII @T3   WRITE, WRITE CHECK ZEROS@<CRLF>
26 106607   124   064   011   .ASCII @T4   WRITE, WRITE CHECK ZEROS W/ WCE ERROR@<CRLF>
27 106660   124   065   011   .ASCII @T5   WRITE, READ ONES@<CRLF>
28 106704   124   066   011   .ASCII @T6   WRITE, WRITE CHECK ONES@<CRLF>
29 106737   124   067   011   .ASCII @T7   WRITE, WRITE CHECK ONES W/ WCE ERROR@<CRLF>
30 107007   124   061   060   .ASCII @T10  WRITE, WRITE CHECK MULTIPLE SECTORS@<CRLF>
31 107057   124   061   061   .ASCII @T11  WRITE, READ W/ IMPLIED SEEK@<CRLF>
32 107117   124   061   062   .ASCII @T12  WRITE, WRITE CHECK W/ HEAD SWITCHING@<CRLF>
33 107170   124   061   063   .ASCII @T13  WRITE, WRITE CHECK W/ MID-TRANSFER SEEK@<CRLF>
34 107244   124   061   064   .ASCII @T14  WRITE, READ W/ HCE ERROR@<CRLF>
35 107301   124   061   065   .ASCII @T15  WRITE, READ W/ HCI@<CRLF>
36 107330   124   061   066   .ASCII @T16  WRITE, READ W/ IVC ERROR@<CRLF>
37 107365   124   061   067   .ASCII @T17  WRITE, READ W/ ABORT@<CRLF>
38 107416   124   062   060   .ASCII @T20  WRITE, READ EACH CURRENT LEVEL@<CRLF>
39 107461   124   062   061   .ASCII @T21  WRITE, WRITE CHECK W/ CURRENT LEVEL SWITCHING@<CRLF>
40 107543   124   062   062   .ASCII @T22  WRITE, READ EARLY PEAK SHIFT@<CRLF>
41 107604   124   062   063   .ASCII @T23  WRITE, READ MIXED PEAK SHIFT@<CRLF>
42 107645   124   062   064   .ASCII @T24  WRITE, READ EACH TRACK@<CRLF>
43 107700   124   062   065   .ASCII @T25  READ, WRITE CHECK MULTIPLE SECTORS IN OFFSET MODE@<CRLF>
44 107766   200   .ASCII <CRLF>
45 107767   117   120   105   .ASCII @OPERATIONAL SWITCH SETTINGS@<CRLF>
46 10023    055   055   055   .ASCII @-----@<CRLF>
47 110057   123   127   111   .ASCII @SWITCH          USE@<CRLF>
48 110074   055   055   055   .ASCII @-----@<CRLF>
49 110131   040   040   061   .ASCII @ 15   HALT ON ERROR@<CRLF>
50 110155   040   040   061   .ASCII @ 14   LOOP ON TEST@<CRLF>
51 110200   040   040   061   .ASCII @ 13   INHIBIT ERROR TYPEOUTS@<CRLF>
52 110235   040   040   061   .ASCII @ 12   @<CRLF>
53 110244   C 0   040   061   .ASCII @ 11   INHIBIT ITERATIONS@<CRLF>
54 110275   040   040   061   .ASCII @ 10   BELL ON ERROR@<CRLF>
55 110321   040   040   040   .ASCII @ 9    LOOP ON ERROR@<CRLF>
56 110345   040   040   040   .ASCII @ 8    LOOP ON TEST IN SWR<7:0>@<CRLF>
57 110404   040   040   040   .ASCII @ 7    TN128@<CRLF>
```

58	110420	040	040	040	.ASCII	@	6	TN64@<CRLF>
59	110433	040	040	040	.ASCII	@	5	TN32@<CRLF>
60	110446	040	040	040	.ASCII	@	4	TN16@<CRLF>
61	110461	040	040	040	.ASCII	@	3	TN8@<CRLF>
62	110473	040	040	040	.ASCII	@	2	TN4@<CRLF>
63	110505	040	040	040	.ASCII	@	1	TN2@<CRLF>
64								
65	000200				.END		200	

ABASE = 176700
 ACDW1 = 000000
 ACDW2 = 000000
 ACKSTS = 053432
 ACPUOP = 000000
 ADDW0 = 000000
 ADDW1 = 000000
 ADDW10 = 000000
 ADDW11 = 000000
 ADDW12 = 000000
 ADDW13 = 000000
 ADDW14 = 000000
 ADDW15 = 000000
 ADDW2 = 000000
 ADDW3 = 000000
 ADDW4 = 000000
 ADDW5 = 000000
 ADDW6 = 000000
 ADDW7 = 000000
 ADDW8 = 000000
 ADDW9 = 000000
 ADEVCT = 000000
 ADEVVM = 000000
 ADR = 000001
 AENV = 000000
 AENVM = 000000
 AFATAL = 000000
 ALL = 070514
 AMADR1 = 000000
 AMADR2 = 000000
 AMADR3 = 000000
 AMADR4 = 000000
 AMAMS1 = 000000
 AMAMS2 = 000000
 AMAMS3 = 000000
 AMAMS4 = 000000
 AMSGAD = 000000
 AMSGLG = 000000
 AMSGTY = 000000
 AMTYP1 = 000000
 AMTYP2 = 000000
 AMTYP3 = 000000
 AMTYP4 = 000000
 AOE = 001000
 APASS = 000000
 APE = 100000
 APRIOR = 000000
 ATCSU = 000040
 APTENV = 000001
 APTSIZ = 000200
 APTSPO = 000100
 ARGS = 000004
 ASNDA = 001516
 ASNDC = 001514
 ASWREG = 000000
 ATA = 100000
 ATESTN = 000000

ATNMSK = 000377
 ATNTBL = 071746
 AUNIT = 000000
 AUSWR = 000000
 AVECT1 = 120254
 AVECT2 = 000000
 A16 = 000400
 A17 = 001000
 BACK = 000001
 BADSCT = 040242
 BADTMO = 005342
 BAI = 000010
 BB00 = 000001
 BB01 = 000002
 BB02 = 000004
 BB03 = 000010
 BB04 = 000020
 BB05 = 000040
 BB06 = 000100
 BB07 = 000200
 BB08 = 000400
 BB09 = 001000
 BIT0 = 000001
 BIT00 = 000001
 BIT01 = 000002
 BIT02 = 000004
 BIT03 = 000010
 BIT04 = 000020
 BIT05 = 000040
 BIT06 = 000100
 BIT07 = 000200
 BIT08 = 000400
 BIT09 = 001000
 BIT1 = 000002
 BIT10 = 002000
 BIT11 = 004000
 BIT12 = 010000
 BIT13 = 020000
 BIT14 = 040000
 BIT15 = 100000
 BIT2 = 000004
 BIT3 = 000010
 BIT4 = 000020
 BIT5 = 000040
 BIT6 = 000100
 BIT7 = 000200
 BIT8 = 000400
 BIT9 = 001000
 BLNKS1 = 071643
 BLNKS2 = 071642
 BLNKS3 = 071641
 BLNKS4 = 071640
 BOTADR = 066104
 BOTFLG = 066106
 BPTVEC = 000014
 BSE = 100000
 BUFFER = 106436

BUFONE = 106436
 BUFTWO = 107442
 CC = 004000
 CH = 002000
 CHGADR = 001330
 CHRCNT = 066107
 CKSWR = 104410
 CLKADR = 001520
 CLKVCT = 001522
 CLR = 000040
 CLRSTS = 052552
 CMNSTA = 007476
 CMPBUF = 042432
 CMPERR = 050550
 CNSL01 = 071105
 CNSL02 = 071115
 CNSL03 = 071157
 CNSL04 = 071166
 CNSL07 = 071222
 CNSL08 = 071364
 CNSL09 = 071365
 CNTCLR = 052434
 COMMA = 070525
 CONT = 000100
 CPSAVE = 065230
 CR = 000015
 CRLF = 000200
 CTLFG = 001326
 CYLSK = 001777
 DBCK = 100000
 DBEN = 040000
 DBL = 002000
 DCK = 100000
 DDISP = 177570
 DEBL = 020000
 DEVSEL = 050762
 DISPLA = 001156
 DISPRE = 000174
 DLT = 100000
 DMU = 000001
 DPE = 000010
 DPEHI = 040000
 DPELO = 020000
 DPR = 000400
 DRIVES = 071600
 DRQ = 004000
 DRVCLR = 000010
 DRVSTS = 055770
 DRY = 000200
 DSWR = 177570
 DTASTS = 056572
 DTE = 010000
 DTO = 010000
 DULPRT = 024024
 DVA = 004000
 DVC = 000200
 EARLY = 072272

EBL = 020000
 ECH = 000100
 ECI = 004000
 ECRC = 001000
 EDT1 = 076614
 EDT110 = 076632
 EDT111 = 076634
 EDT14 = 076636
 EDT2 = 076624
 EDT223 = 076640
 EDT336 = 076650
 EDT337 = 076660
 EDT344 = 076670
 EDT353 = 076702
 ED1 = 106232
 ED110 = 106240
 ED111 = 106244
 ED114 = 106252
 ED223 = 106262
 ED336 = 106272
 ED337 = 106304
 ED353 = 106316
 EECC = 000020
 EFT1 = 076704
 EFT110 = 076722
 EFT111 = 076724
 EFT114 = 076726
 EFT2 = 076714
 EFT223 = 076730
 EFT336 = 076740
 EFT337 = 076750
 EFT344 = 076760
 EFT353 = 076770
 EF110 = 106410
 EF111 = 106411
 EF114 = 106413
 EF336 = 106416
 EF337 = 106422
 EHT1 = 076470
 EHT110 = 076512
 EHT111 = 076516
 EHT114 = 076522
 EHT2 = 076502
 EHT223 = 076526
 EHT256 = 076540
 EHT336 = 076552
 EHT337 = 076564
 EHT344 = 076576
 EHT353 = 076610
 EH1 = 105166
 EH110 = 105205
 EH111 = 105214
 EH114 = 105233
 EH223 = 105262
 EH256 = 105310
 EH336 = 105364
 EH337 = 105423

EH344 = 105560
 EH353 = 105716
 EMS1 = 076772
 EMS10 = 077326
 EMS100 = 101544
 EMS101 = 101572
 EMS102 = 101620
 EMS103 = 101647
 EMS104 = 101656
 EMS105 = 101705
 EMS106 = 101734
 EMS11 = 077370
 EMS110 = 101753
 EMS111 = 102002
 EMS112 = 102013
 EMS113 = 102077
 EMS114 = 102127
 EMS115 = 102153
 EMS116 = 102156
 EMS117 = 102206
 EMS12 = 077401
 EMS120 = 102230
 EMS121 = 102251
 EMS122 = 102314
 EMS123 = 102351
 EMS124 = 102414
 EMS125 = 102446
 EMS126 = 102511
 EMS127 = 102554
 EMS13 = 077442
 EMS130 = 102613
 EMS131 = 102651
 EMS132 = 102711
 EMS133 = 102735
 EMS134 = 102760
 EMS135 = 103022
 EMS136 = 103065
 EMS137 = 103112
 EMS14 = 077453
 EMS140 = 103147
 EMS141 = 103170
 EMS142 = 103216
 EMS143 = 103233
 EMS144 = 103261
 EMS145 = 103271
 EMS146 = 103320
 EMS147 = 103337
 EMS15 = 077464
 EMS150 = 103354
 EMS151 = 103372
 EMS152 = 103416
 EMS153 = 103442
 EMS154 = 103464
 EMS155 = 103500
 EMS156 = 103520
 EMS157 = 103536
 EMS16 = 077506

SYMBOL TABLE

EMS160 103553
 EMS161 103570
 EMS162 103620
 EMS163 103620
 EMS164 103644
 EMS165 103725
 EMS166 103741
 EMS167 103766
 EMS17 077536
 EMS170 104013
 EMS171 104042
 EMS172 104075
 EMS173 104115
 EMS174 104132
 EMS175 104140
 EMS176 104166
 EMS177 104215
 EMS2 077041
 EMS20 077576
 EMS200 104237
 EMS201 104254
 EMS202 104322
 EMS203 104352
 EMS204 104365
 EMS205 104413
 EMS206 104425
 EMS207 104452
 EMS21 077621
 EMS210 104477
 EMS211 104510
 EMS212 104526
 EMS213 104551
 EMS214 104574
 EMS215 104612
 EMS216 104633
 EMS217 104663
 EMS22 077644
 EMS220 104716
 EMS221 104736
 EMS222 105006
 EMS223 105037
 EMS224 105114
 EMS23 077660
 EMS24 077706
 EMS25 077735
 EMS26 077752
 EMS27 077773
 EMS3 077056
 EMS30 100004
 EMS31 100014
 EMS32 100043
 EMS33 100072
 EMS34 100120
 EMS35 100171
 EMS36 100220
 EMS37 100247
 FMS4 077121

EMS40 100275
 EMS41 100324
 EMS42 100352
 EMS43 100401
 EMS44 100430
 EMS45 100503
 EMS46 100546
 EMS47 100575
 EMS5 077164
 EMS50 100624
 EMS51 100653
 EMS52 100701
 EMS53 100711
 EMS54 100723
 EMS55 100745
 EMS56 100774
 EMS57 101051
 EMS6 077214
 EMS60 101077
 EMS61 101112
 EMS62 101141
 EMS63 101157
 EMS64 101205
 EMS65 101223
 EMS66 101271
 EMS67 101341
 EMS7 077261
 EMS70 101366
 EMS71 101400
 EMS72 101413
 EMS73 101423
 EMS74 101440
 EMS75 101457
 EMS76 101465
 EMS77 101516
 EMTVEC= 000030
 EMT1 072404
 EMT10 072454
 EMT100 073452
 EMT101 073470
 EMT102 073506
 EMT103 073516
 EMT104 073530
 EMT105 073546
 EMT106 073556
 EMT107 073566
 EMT11 072460
 EMT110 073606
 EMT111 073620
 EMT112 073626
 EMT113 073634
 EMT114 073650
 EMT115 073656
 EMT116 073666
 EMT117 073676
 EMT12 072464
 EMT120 073706

EMT121 073716
 EMT122 073726
 EMT123 073736
 EMT124 073746
 EMT125 073756
 EMT126 073766
 EMT127 074000
 EMT13 072472
 EMT130 074012
 EMT131 074024
 EMT132 074036
 EMT133 074050
 EMT134 074062
 EMT135 074074
 EMT136 074106
 EMT137 074120
 EMT14 072504
 EMT140 074130
 EMT141 074140
 EMT142 074150
 EMT143 074160
 EMT144 074170
 EMT145 074200
 EMT146 074210
 EMT147 074220
 EMT15 072512
 EMT150 074230
 EMT151 074240
 EMT152 074252
 EMT153 074264
 EMT154 074302
 EMT155 074320
 EMT156 074332
 EMT157 074344
 EMT16 072520
 EMT160 074356
 EMT161 074366
 EMT162 074400
 EMT163 074412
 EMT164 074422
 EMT165 074430
 EMT166 074436
 EMT167 074444
 EMT17 072530
 EMT170 074452
 EMT171 074464
 EMT172 074474
 EMT173 074504
 EMT174 074514
 EMT175 074526
 EMT176 074534
 EMT177 074542
 EMT2 072410
 EMT20 072540
 EMT200 074544
 EMT201 074556
 EMT202 074570

EMT203 074602
 EMT204 074614
 EMT205 074632
 EMT206 074642
 EMT207 074652
 EMT21 072550
 EMT210 074664
 EMT211 074672
 EMT212 074706
 EMT213 074722
 EMT214 074732
 EMT215 074752
 EMT216 074764
 EMT217 074774
 EMT22 072560
 EMT220 075004
 EMT221 075014
 EMT222 075024
 EMT223 075034
 EMT224 075044
 EMT225 075046
 EMT226 075050
 EMT227 075052
 EMT23 072570
 EMT230 075054
 EMT231 075056
 EMT232 075060
 EMT233 075062
 EMT234 075064
 EMT235 075066
 EMT236 075070
 EMT237 075072
 EMT24 072600
 EMT240 075074
 EMT241 075076
 EMT242 075100
 EMT243 075102
 EMT244 075104
 EMT245 075106
 EMT246 075110
 EMT247 075120
 EMT25 072610
 EMT250 075132
 EMT251 075146
 EMT252 075154
 EMT253 075162
 EMT254 075200
 EMT255 075210
 EMT256 075220
 EMT257 075230
 EMT26 072620
 EMT260 075242
 EMT261 075254
 EMT262 075274
 EMT263 075304
 EMT264 075314
 EMT265 075334

EMT266 075354
 EMT267 075366
 EMT27 072630
 EMT270 075404
 EMT271 075420
 EMT272 075436
 EMT273 075454
 EMT274 075472
 EMT275 075510
 EMT276 075522
 EMT277 075536
 EMT3 072416
 EMT30 072640
 EMT300 075554
 EMT301 075574
 EMT302 075616
 EMT303 075630
 EMT304 075642
 EMT305 075654
 EMT306 075666
 EMT307 075676
 EMT31 072650
 EMT310 075716
 EMT311 075730
 EMT312 075742
 EMT313 075754
 EMT314 075774
 EMT315 076006
 EMT316 076020
 EMT317 076032
 EMT32 072660
 EMT320 076042
 EMT321 076052
 EMT322 076062
 EMT323 076070
 EMT324 076100
 EMT325 076112
 EMT326 076124
 EMT327 076142
 EMT33 072670
 EMT330 076154
 EMT331 076164
 EMT332 076176
 EMT333 076210
 EMT334 076226
 EMT335 076244
 EMT336 076264
 EMT337 076274
 EMT34 072700
 EMT340 076304
 EMT341 076316
 EMT342 076324
 EMT343 076336
 EMT344 076350
 EMT345 076362
 EMT346 076372
 EMT347 076406

RMWC = 000002
RMWCI 001340
RMWCO 001414
ROA = 100000
ROB = 040000
RTC = 000016
R6 = 2000006
R7 = 2000007
SADMSK = 000377
SAVREG = 104414
SA1 = 000001
SA16 = 000020
SA2 = 000002
SA4 = 000004
SAB = 000010
SC = 100000
SCOPE = 000004
SCTMSG 070426
SCTMSK = 003700
SCO = 000100
SC1 = 000200
SC2 = 000400
SC3 = 001000
SC4 = 002000
SEARCH = 000030
SEERR 044710
SEEK = 000004
SEKSTS 051174
SHUT 037262
SHUT2 067550
SIZCLK 043550
SKI = 040000
SNGPRT = 020024
STACK 001100
STANDA 007020
START 005432
START1 005422
START2 005436
STCDRV 062172
STKLMT = 177774
STOP 064612
STSD1 106326
STSD2 106344
STSD3 106364
STSD4 106376
STSF 106427
STSH1 105772
STSH2 106047
STSH3 106136
STSH4 106174
SWR 001154
SWREG 000176
SW0 = 000001
SW00 = 000001
SW01 = 000002
SW02 = 000004
SW03 = 000010

SW04 = 000020
SW05 = 000040
SW06 = 000100
SW07 = 000200
SW08 = 000400
SW09 = 001000
SW1 = 000002
SW10 = 002000
SW11 = 004000
SW12 = 010000
SW13 = 020000
SW14 = 040000
SW15 = 100000
SW2 = 000004
SW3 = 000010
SW4 = 000020
SW5 = 000040
SW6 = 000100
SW7 = 000200
SW8 = 000400
SW9 = 001000
SYSTAT 071430
TADMSK = 177400
TAG = 020000
TAGADR 001114
TAP 040000
TA1 = 000400
TA16 = 010000
TA2 = 001000
TA4 = 002000
TA8 = 004000
TBITVE = 000014
TMOU 043672
TKVEC = 000060
TPVEC 000064
TRAPVE = 000034
TRE = 040000
TRTVEC = 000014
TST = 010000
TSTNMB 066100
TSTPRP 037316
TSTQUE 001466
TST1 010066
TST10 016630
TST11 017634
TST12 021060
TST13 022266
TST14 023310
TST15 025156
TST16 026562
TST17 027602
TST2 010266
TST20 030520
TST21 031556
TST22 032562
TST23 033570
TST24 034576

TST25 035624
TST3 011274
TST4 012252
TST5 013446
TST6 014454
TST7 015432
TYPBN = 104406
TYPDS = 104405
TYPE = 104401
TYPOC = 104402
TYPON = 104404
TYPOS = 104403
UNS = 040000
UNTMSK = 000007
UNTOFF 071557
UNTON 071570
UPE = 020000
USE = 040000
USRFIL 111454
U0 = 000001
U1 = 000002
U2 = 000004
VV = 000100
WC = 000040
WCD = 000050
WCE = 040000
WCEHI = 010000
WCELO = 004000
WCF = 000040
WCH = 000052
WD = 000060
WH = 000062
WLE = 004000
WRL = 004000
XSIZ 006464
XXDP 001332
Y 071636
ZEROS 072060
\$APTHD 001100
\$ATYC 070204
\$ATY1 070160
\$ATY3 070166
\$ATY4 070176
\$AUTOB 001150
\$BASE 001276
\$BDADR 001136
\$BDDAT 001142
\$BELL 001212
\$BIN 063044
\$CDW1 001302
\$CDW2 001304
\$CHARC 064050
\$CKSWR 066610
\$CMTAG 001114
\$CM3 = 000000
\$CM4 = 000005
\$CNTLC 067506

\$CNTLG 067520
\$CNTLU 067513
\$CPUOP 001250
\$CRLF 001217
\$DBLK 063262
\$DDW0 001306
\$DDW1 001310
\$DDW2 001312
\$DDW3 001314
\$DDW4 001316
\$DDW5 001320
\$DDW6 001322
\$DDW7 001324
\$DEVCT 001232
\$DEVVM 001300
\$DOAGN 037252
\$DTBL 063252
\$ENDAD 037242
\$ENDCT 037100
\$ENULL 037256
\$ENV 001242
\$ENVM 001243
\$EOP 037044
\$EOPCT 037072
\$EOSP 037006
\$ERFLG 001117
\$ERMAX 001131
\$ERROR 064640
\$ERRPC 001132
\$ERRTB 001602
\$ERTTL 001126
\$ESCAP 001210
\$FTABL 001242
\$ETEND 001326
\$FATAL 001224
\$FFLG 070424
\$FILLC 001172
\$FILLS 001171
\$GDADR 001134
\$GDDAT 001140
\$GET42 037232
\$GTSWR 066700
\$GT42P 037226
\$HD = 000000
\$HIBTS 001100
\$HIOCT 067672
\$ICNT 001120
\$ILLUP 070142
\$INTAG 001151
\$ITEMB 001130
\$LF 001220
\$LFLG 070423
\$LPADR 001122
\$LPERR 001124
\$MADR1 001254
\$MADR2 001260
\$MADR3 001264

\$MADR4 001270
\$MAIL 001222
\$MAMS1 001252
\$MAMS2 001256
\$MAMS3 001262
\$MAMS4 001266
\$MBADR 001102
\$MFLG 070422
\$MNEW 067536
\$MSGAD 001236
\$MSGLG 001240
\$MSGTY 001222
\$MSWR 067525
\$MTYP1 001253
\$MTYP2 001257
\$MTYP3 001263
\$MTYP4 001267
\$MXCNT 064536
\$NULL 001170
\$NWTST = 000001
\$OCNT 063514
\$OMODE 063516
\$OVER 064522
\$PASS 001230
\$PASTM 001106
\$POWER 070150
\$PWDRN 070002
\$PWRMG 070136
\$PWRLP 070054
\$QUES 001216
\$RDCHR 067152
\$RDLIN 067242
\$RDOCT 067572
\$RDSZ = 000010
\$RESRE 062734
\$RM02 071446
\$RM03 071453
\$RM05 071460
\$RTNAD 037254
\$SAVRE 062676
\$SAVR6 070146
\$SCOPE 064054
\$SETUP = 000137
\$STUP = 177777
\$SVLAD 064466
\$SVPC = 000210
\$SWR = 167400
\$SWREG 001244
\$SWRMK = 000000
\$SW08T 064540
\$TESTN 001226
\$TIMES 001206
\$TKB 001162
\$TKCNT 066300
\$TKINT 066310
\$TKQEN 066307
\$TKQIN 066302

\$TKQOU 066304	\$TMP4 001204	\$TRPAD 067746	\$TYPEX 064052	\$VECT2 001274
\$TKQSR 066306	\$TN = 000026	\$TSTM 001104	\$TYPOC 063316	\$XOFF = 000023
\$TKS 001160	\$TPB 001166	\$TSTNM 001116	\$TYPON 063332	\$XON = 000021
\$TKSRV 066360	\$TPFLG 001173	\$TTYIN 067476	\$TYPOS 063272	\$XTSTR 064076
\$TMP0 001174	\$TPS 001164	\$TYPBN 062772	\$UNIT 001234	\$SGT4= 000000
\$TMP1 001176	\$TRAP 067674	\$TYPDS 063046	\$UNITM 001110	\$SSW08= 000026
\$TMP2 001200	\$TRAP2 067734	\$TYPE 063520	\$USWR 001246	\$OFILL 063515
\$TMP3 001202	\$TRP = 000016	\$TYPEC 063732	\$VECT1 001272	.\$X = 001100

. ABS. 112462 000
000000 001
ERRORS DETECTED: 0

VIRTUAL MEMORY USED: 62208 WORDS (243 PAGES)
DYNAMIC MEMORY AVAILABLE FOR 70 PAGES
CZRM08.BIC, CZRM08/C-CZRM08.DOC, CZRM08.SYSMAC/M

	13-J40#	13-J43#	13-J47#	13-J49#	13-J53#	13-J66	13-J66#	13-J82#	13-J85#	13-J87#	13-J90#	13-J94#	13-J96#	13-K00#
	13-K13	13-K13#	13-K24#	13-K40#	13-K43#	13-K45#	13-K48#	13-K52#	13-K65	13-K65#	13-K82#	13-K85#	13-K87#	13-K90#
	13-K94#	13-K96#	13-K98#	13-L11	13-L11#	13-L27#	13-L30#	13-L32#	13-L35#	13-L39#	13-L41#	13-L43#	13-L45#	13-L58
	13-L58#	13-L69#	13-L85#	13-L88#	13-L90#	13-L93#	13-L97#	13-M10	13-M10#	13-M27#	13-M30#	13-M32#	13-M35#	13-M39#
	13-M41#	13-M43#	13-M56	13-M56#	13-M72#	13-M75#	13-M77#	13-M80#	13-M84#	13-M86#	13-M88#	13-M90#	13-N03	13-N03#
	13-N15#	13-N33#	13-N36#	13-N38#	13-N41#	13-N45#	13-N58	13-N58#	13-N75#	13-N78#	13-N80#	13-N83#	13-N87#	13-N89#
	13-N91#	13-004	13-004#	13-020#	13-023#	13-025#	13-028#	13-032#	13-034#	13-036#	13-038#	13-053	13-053#	13-064#
	13-020#	13-083#	13-085#	13-088#	13-092#	13-P05	13-P05#	13-P17#	13-P23#	13-P26#	13-P33#	13-P36#	13-P38#	13-P41#
	13-P45#	13-P47#	13-P49#	13-P61	13-P61#	13-P74#	13-P83#	13-P86#	13-P94#	13-P97#	13-P99#	13-Q02#	13-Q06#	13-Q08#
	13-Q10#													
ASNDA	7-0#	16-299*	16-331	16-358*	16-359	16-361*	16-362*	16-363	16-365*	16-397				
ASNDC	7-0#	16-298*	16-330	16-366*	16-367	16-369*	16-396							
ASWREG	6-0	6-0												
ATA	4-552#	25-138	25-139	25-141	29-156	29-157	29-192	29-195	33-145	33-146	33-185	33-188	51-58	51-59
	51-60	51-63	51-64	51-67	51-68	51-69	51-70	51-71	51-72	51-73	51-74	51-75	51-76	51-79
	51-80	51-83	51-84	51-87	51-88									
ATESTN	6-0	6-0												
ATNSK	4-589#	34-55												
ATNTBL	10-78	10-117	10-121	11-97	12-17	52-3#								
AUNIT	6-0	6-0												
AUSWR	6-0	6-0												
AVECT1	4-773#	6-0	6-0											
AVECT2	6-0	6-0												
BACK	13-41	13-41#	13-52	13-52#	13-68	13-68#	13-71#	13-73#	13-76	13-76#	13-80	13-80#	13-80#	13-93
	13-93#	13-110	13-110#	13-113#	13-115#	13-118	13-118#	13-122	13-122#	13-122#	13-124	13-124#	13-124#	13-126
	13-126#	13-126#	13-139	13-139#	13-155	13-155#	13-158#	13-160#	13-163	13-163#	13-167	13-167#	13-167#	13-169
	13-169#	13-169#	13-171	13-171#	13-171#	13-175	13-175#	13-188	13-188#	13-199	13-199#	13-215	13-215#	13-218#
	13-220#	13-223	13-223#	13-227	13-227#	13-227#	13-240	13-240#	13-257	13-257#	13-260#	13-262#	13-265	13-265#
	13-269	13-269#	13-269#	13-271	13-271#	13-271#	13-273	13-273#	13-273#	13-286	13-286#	13-301	13-301#	13-304#
	13-306#	13-309	13-309#	13-313	13-313#	13-313#	13-315	13-315#	13-315#	13-317	13-317#	13-317#	13-330	13-330#
	13-341	13-341#	13-356	13-356#	13-359#	13-361#	13-364	13-364#	13-368	13-368#	13-368#	13-381	13-381#	13-398
	13-398#	13-401#	13-403#	13-406	13-406#	13-410	13-410#	13-410#	13-412	13-412#	13-412#	13-414	13-414#	13-414#
	13-429	13-429#	13-444	13-444#	13-447#	13-449#	13-452	13-452#	13-456	13-456#	13-456#	13-461	13-461#	13-461#
	13-489	13-489#	13-489#	13-505	13-505#	13-516	13-516#	13-534	13-534#	13-537#	13-539#	13-542	13-542#	13-546
	13-546#	13-546#	13-560	13-560#	13-577	13-577#	13-580#	13-582#	13-585	13-585#	13-589	13-589#	13-589#	13-591
	13-591#	13-591#	13-593	13-593#	13-593#	13-606	13-606#	13-622	13-622#	13-625#	13-627#	13-630	13-630#	13-634
	13-634#	13-634#	13-636	13-636#	13-636#	13-638	13-638#	13-638#	13-640	13-640#	13-653	13-653#	13-664	13-664#
	3-682	13-682#	13-685#	13-687#	13-690	13-690#	13-694	13-694#	13-694#	13-708	13-708#	13-725	13-725#	13-728#
	13-730#	13-733	13-733#	13-737	13-737#	13-737#	13-739	13-739#	13-739#	13-741	13-741#	13-741#	13-754	13-754#
	13-769	13-769#	13-772#	13-774#	13-777	13-777#	13-781	13-781#	13-781#	13-783	13-783#	13-783#	13-785	13-785#
	13-785#	13-798	13-798#	13-809	13-809#	13-827	13-827#	13-830#	13-832#	13-835	13-835#	13-839	13-839#	13-839#
	13-852	13-852#	13-869	13-869#	13-872#	13-874#	13-877	13-877#	13-881	13-881#	13-881#	13-883	13-883#	13-883#
	13-885	13-885#	13-885#	13-900	13-900#	13-915	13-915#	13-918#	13-920#	13-923	13-923#	13-927	13-927#	13-927#
	13-931	13-931#	13-931#	13-961	13-961#	13-961#	13-977	13-977#	13-988	13-988#	13-:06	13-:06#	13-:09#	13-:11#
	13-:14	13-:14#	13-:18	13-:18#	13-:18#	13-:40	13-:40#	13-:55	13-:55#	13-:58#	13-:60#	13-:63	13-:63#	13-:67
	13-:67#	13-:67#	13-:69	13-:69#	13-:69#	13-:71	13-:71#	13-:71#	13-:84	13-:84#	13-:99	13-:99#	13-:02#	13-:04#
	13-:07	13-:07#	13-:11	13-:11#	13-:11#	13-:13	13-:13#	13-:13#	13-:15	13-:15#	13-:15#	13-:28	13-:28#	13-:40
	13-:40#	13-:58	13-:58#	13-:61#	13-:63#	13-:66	13-:66#	13-:70	13-:70#	13-:70#	13-:83	13-:83#	13-:88	13-:88#
	13-:91#	13-:93#	13-:96	13-:96#	13-<00	13-<00#	13-<00#	13-<18	13-<18#	13-<21#	13-<24	13-<24#	13-<28	13-<28#
	13-<28#	13-<30	13-<30#	13-<30#	13-<32	13-<32#	13-<32#	13-<45	13-<45#	13-<50	13-<50#	13-<53#	13-<55#	13-<58
	13-<58#	13-<62	13-<62#	13-<62#	13-<79	13-<79#	13-<82#	13-<85	13-<85#	13-<89	13-<89#	13-<89#	13-<91	13-<91#
	13-<91#	13-<93	13-<93#	13-<93#	13-<95	13-<95#	13-=20	13- 20#	13-=29	13-=29#	13-=43	13-=43#	13-=46#	13-=48#
	13-=51	13-=51#	13-=55	13-=55#	13-=55#	13-=76	13-=76#	13-=80	13-=80#	13-=83#	13-=85#	13-=88	13-=88#	13-=92
	13-=92#	13-=92#	13->07	13->07#	13->10#	13->12#	13->15	13->15#	13->19	13->19#	13->19#	13->21	13->21#	13->21#
	13->23	13->23#	13->23#	13->36	13->36#	13->40	13->40#	13->43#	13->45#	13->48	13->48#	13->52	13->52#	13->52#
	13->7	13->67#	13->70#	13->72#	13->75	13->75#	13->79	13->79#	13->79#	13->81	13->81#	13->81#	13->83	13->83#
	13->83#	13-?03	13-?03#	13-?12	13-?12#	13-?25	13-?25#	13-?28#	13-?30#	13-?33	13-?33#	13-?37	13-?37#	13-?37#

13-258	13-253#	13-273	13-273#	13-276#	13-278#	13-281	13-281#	13-285	13-285#	13-285#	13-287	13-287#	13-287#
13-289	13-289#	13-289#	13-a02	13-a02#	13-a17	13-a17#	13-a20#	13-a22#	13-a25	13-a25#	13-a29	13-a29#	13-a29#
13-a31	13-a31#	13-a31#	13-a33	13-a33#	13-a33#	13-a48	13-a48#	13-a59	13-a59#	13-a83	13-a83#	13-a86#	13-a88#
13-a91	13-a91#	13-a95	13-a95#	13-a95#	13-A08	13-A08#	13-A25	13-A25#	13-A28#	13-A30#	13-A33	13-A33#	13-A37
13-A37#	13-A37#	13-A54	13-A54#	13-A54#	13-A70	13-A70#	13-A70#	13-A82	13-A82#	13-A82#	13-A91	13-A91#	13-A91#
13-B03	13-B03#	13-B20	13-B20#	13-B23#	13-B25#	13-B28	13-B28#	13-B32	13-B32#	13-B32#	13-B47	13-B47#	13-B47#
13-B63	13-B63#	13-B63#	13-B75	13-B75#	13-B75#	13-B84	13-B84#	13-B84#	13-C07	13-C07#	13-C18	13-C18#	13-C34
13-C34#	13-C45	13-C45#	13-C71	13-C71#	13-C74#	13-C76#	13-C79	13-C79#	13-C83	13-C83#	13-C83#	13-C96	13-C96#
13-D13	13-D13#	13-D16#	13-D18#	13-D21	13-D21#	13-D25	13-D25#	13-D25#	13-D44	13-D44#	13-D44#	13-D46	13-D46#
13-D46#	13-D59	13-D59#	13-D75	13-D75#	13-D78#	13-D80#	13-D83	13-D83#	13-D87	13-D87#	13-D87#	13-E06	13-E06#
13-E06#	13-E08	13-E08#	13-E08#	13-E10	13-E10#	13-E32	13-E32#	13-E43	13-E43#	13-E63	13-E63#	13-E70	13-E70#
13-E91	13-E91#	13-E94#	13-E96#	13-E99	13-E99#	13-F03	13-F03#	13-F03#	13-F08	13-F08#	13-F08#	13-F16	13-F16#
13-F16#	13-F29	13-F29#	13-F51	13-F51#	13-F54#	13-F56#	13-F59	13-F59#	13-F63	13-F63#	13-F63#	13-F68	13-F68#
13-F68#	13-F76	13-F76#	13-F76#	13-F96	13-F96#	13-G15	13-G15#	13-G18#	13-G21	13-G21#	13-G31#	13-G34	13-G34#
13-G36	13-G36#	13-G36#	13-G38	13-G38#	13-G38#	13-G51	13-G51#	13-G70	13-G70#	13-G73#	13-G76	13-G76#	13-G87#
13-G90	13-G90#	13-G92	13-G92#	13-G92#	13-G94	13-G94#	13-G94#	13-H06	13-H06#	13-H17	13-H17#	13-H33	13-H33#
13-H36#	13-H38#	13-H41	13-H41#	13-H45	13-H45#	13-H45#	13-H59	13-H59#	13-H77	13-H77#	13-H80#	13-H82#	13-H85
13-H85#	13-H89	13-H89#	13-H89#	13-H91	13-H91#	13-H91#	13-H95	13-H95#	13-H95#	13-I08	13-I08#	13-I26	13-I26#
13-I29#	13-I31#	13-I34	13-I34#	13-I38	13-I38#	13-I38#	13-I40	13-I40#	13-I40#	13-I44	13-I44#	13-I44#	13-I46
13-I46#	13-I60	13-I60#	13-I72	13-I72#	13-I88	13-I88#	13-I91#	13-I93#	13-I96	13-I96#	13-J00	13-J00#	13-J00#
13-J14	13-J14#	13-J35	13-J35#	13-J38#	13-J40#	13-J43	13-J43#	13-J47	13-J47#	13-J47#	13-J49	13-J49#	13-J49#
13-J53	13-J53#	13-J53#	13-J66	13-J66#	13-J82	13-J82#	13-J85#	13-J87#	13-J90	13-J90#	13-J94	13-J94#	13-J94#
13-J96	13-J96#	13-J96#	13-K00	13-K00#	13-K00#	13-K13	13-K13#	13-K24	13-K24#	13-K40	13-K40#	13-K43#	13-K45#
13-K48	13-K48#	13-K52	13-K52#	13-K52#	13-K65	13-K65#	13-K82	13-K82#	13-K85#	13-K87#	13-K90	13-K90#	13-K94
13-K94#	13-K94#	13-K96	13-K96#	13-K96#	13-K98	13-K98#	13-K98#	13-L11	13-L11#	13-L27	13-L27#	13-L30#	13-L32#
13-L35	13-L35#	13-L39	13-L39#	13-L39#	13-L41	13-L41#	13-L41#	13-L43	13-L43#	13-L43#	13-L45	13-L45#	13-L58
13-L58#	13-L69	13-L69#	13-L85	13-L85#	13-L88#	13-L90#	13-L93	13-L93#	13-L97	13-L97#	13-L97#	13-M10	13-M10#
13-M27	13-M27#	13-M30#	13-M32#	13-M35	13-M35#	13-M39	13-M39#	13-M39#	13-M41	13-M41#	13-M41#	13-M43	13-M43#
13-M43#	13-M56	13-M56#	13-M72	13-M72#	13-M75#	13-M77#	13-M80	13-M80#	13-M84	13-M84#	13-M84#	13-M86	13-M86#
13-M86#	13-M88	13-M88#	13-M88#	13-M90	13-M90#	13-N03	13-N03#	13-N15	13-N15#	13-N33	13-N33#	13-N36#	13-N38#
13-N41	13-N41#	13-N45	13-N45#	13-N45#	13-N58	13-N58#	13-N75	13-N75#	13-N78#	13-N80#	13-N83	13-N83#	13-N87
13-N87#	13-N87#	13-N89	13-N89#	13-N89#	13-N91	13-N91#	13-N91#	13-004	13-004#	13-020	13-020#	13-023#	13-025#
13-028	13-028#	13-032	13-032#	13-032#	13-034	13-034#	13-034#	13-036	13-036#	13-036#	13-038	13-038#	13-053
13-053#	13-064	13-064#	13-080	13-080#	13-083#	13-085#	13-088	13-088#	13-092	13-092#	13-092#	13-P05	13-P05#
13-P17	13-P17#	13-P23	13-P23#	13-P26#	13-P33	13-P33#	13-P36#	13-P38#	13-P41	13-P41#	13-P45	13-P45#	13-P45#
13-P47	13-P47#	13-P47#	13-P49	13-P49#	13-P49#	13-P61	13-P61#	13-P74	13-P74#	13-P83	13-P83#	13-P86#	13-P94
13-P94#	13-P97#	13-P99#	13-Q02	13-Q02#	13-Q06	13-Q06#	13-Q06#	13-Q08	13-Q08#	13-Q08#	13-Q10	13-Q10#	13-Q10#
BADSCT	13-52	13-199	13-341	13-516	13-664	13-809	13-988	13-:40	13-=20	13-?03	13-a59	13-C45	13-E63
	13-172	13-K24	13-L69	13-N15	13-064	16-33#							

BADSCT

BADTMO

- BAI 4-739#
- BB00 4-670#
- BB01 4-670#
- BB02 4-670#
- BB03 4-670#
- BB04 4-670#
- BB05 4-670#
- BB06 4-670#
- BB07 4-670#
- BB08 4-670#
- BB09 4-670#
- BIT0 4-484#
- BIT00 4-484#
- BIT01 4-484#
- BIT02 4-484#
- BIT03 4-484#

23-18

4-484	4-484#	4-496	4-544	4-562	4-581	4-618	4-636	4-670	4-742	4-760	42-1	42-1	43-1
43-1													
4-484	4-484#	4-495	4-543	4-580	4-617	4-635	4-670	4-742	4-759				
4-484	4-484#	4-494	4-542	4-579	4-616	4-634	4-670	4-742	4-758				
4-484	4-484#	4-493	4-541	4-578	4-615	4-633	4-670	4-681	4-739	4-757			

EMT127	8-266	54-89#
EMT13	8-33	54-13#
EMT130	8-269	54-90#
EMT131	8-272	54-91#
EMT132	8-275	54-92#
EMT133	8-278	54-93#
EMT134	8-281	54-94#
EMT135	8-284	54-95#
EMT136	8-287	54-96#
EMT137	8-290	54-97#
EMT14	8-36	54-14#
EMT140	8-293	54-98#
EMT141	8-296	54-99#
EMT142	8-299	54-100#
EMT143	8-302	54-101#
EMT144	8-305	54-102#
EMT145	8-308	54-103#
EMT146	8-311	54-104#
EMT147	8-314	54-105#
EMT15	8-39	54-15#
EMT150	8-317	54-106#
EMT151	8-320	54-107#
EMT152	8-323	54-108#
EMT153	8-326	54-109#
EMT154	8-329	54-110#
EMT155	8-332	54-111#
EMT156	8-335	54-112#
EMT157	8-338	54-113#
EMT16	8-42	54-16#
EMT160	8-341	54-114#
EMT161	8-344	54-115#
EMT162	8-347	54-116#
EMT163	54-117#	
EMT164	8-354	54-118#
EMT165	8-357	54-119#
EMT166	8-360	54-120#
EMT167	8-363	54-121#
EMT17	8-45	54-17#
EMT170	8-366	54-122#
EMT171	8-369	54-123#
EMT172	8-372	54-124#
EMT173	8-375	54-125#
EMT174	8-378	54-126#
EMT175	8-381	54-127#
EMT176	8-384	54-128#
EMT177	54-129#	
EMT2	8-6	54-4#
EMT20	8-48	54-18#
EMT200	8-390	54-130#
EMT201	8-393	54-131#
EMT202	8-396	54-132#
EMT203	8-399	54-133#
EMT204	8-402	54-134#
EMT205	8-405	54-135#
EMT206	8-408	54-136#
EMT207	8-411	54-137#
EMT21	8-51	54-19#

EMT210	8-414	54-138#
EMT211	8-417	54-139#
EMT212	8-420	54-140#
EMT213	8-423	54-141#
EMT214	8-426	54-142#
EMT215	8-429	54-143#
EMT216	8-432	54-144#
EMT217	8-435	54-145#
EMT22	8-54	54-20#
EMT220	8-438	54-146#
EMT221	8-441	54-147#
EMT222	8-444	54-148#
EMT223	8-447	54-149#
EMT224	54-150#	
EMT225	54-151#	
EMT226	54-152#	
EMT227	54-153#	
EMT23	8-57	54-21#
EMT230	54-154#	
EMT231	54-155#	
EMT232	54-156#	
EMT233	54-157#	
EMT234	54-158#	
EMT235	54-159#	
EMT236	54-160#	
EMT237	54-161#	
EMT24	8-60	54-22#
EMT240	54-162#	
EMT241	54-163#	
EMT242	54-164#	
EMT243	54-165#	
EMT244	54-166#	
EMT245	54-167#	
EMT246	8-504	54-168#
EMT247	8-507	54-169#
EMT25	8-63	54-23#
EMT250	8-510	54-170#
EMT251	8-513	54-171#
EMT252	8-516	54-172#
EMT253	8-519	54-173#
EMT254	8-522	54-174#
EMT255	8-525	54-175#
EMT256	8-528	54-176#
EMT257	8-531	54-177#
EMT26	8-66	54-24#
EMT260	8-534	54-178#
EMT261	8-537	54-179#
EMT262	8-540	54-180#
EMT263	8-543	54-181#
EMT264	8-546	54-182#
EMT265	8-549	54-183#
EMT266	8-552	54-184#
EMT267	8-555	54-185#
EMT27	8-69	54-25#
EMT270	8-559	54-186#
EMT271	8-563	54-187#
EMT272	8-566	54-188#

EMT273	8-569	54-189#
EMT274	8-573	54-190#
EMT275	8-577	54-191#
EMT276	8-581	54-192#
EMT277	8-586	54-193#
EMT3	8-9	54-5#
EMT30	8-72	54-26#
EMT300	8-590	54-194#
EMT301	8-594	54-195#
EMT302	8-597	54-196#
EMT303	8-600	54-197#
EMT304	8-603	54-198#
EMT305	8-606	54-199#
EMT306	8-609	54-200#
EMT307	8-612	54-201#
EMT31	8-75	54-27#
EMT310	8-615	54-202#
EMT311	8-618	54-203#
EMT312	8-621	54-204#
EMT313	8-624	54-205#
EMT314	8-627	54-206#
EMT315	8-630	54-207#
EMT316	8-633	54-208#
EMT317	8-636	54-209#
EMT32	8-78	54-28#
EMT320	8-639	54-210#
EMT321	8-642	54-211#
EMT322	8-645	54-212#
EMT323	8-648	54-213#
EMT324	8-651	54-214#
EMT325	8-654	54-215#
EMT326	8-657	54-216#
EMT327	8-660	54-217#
EMT33	8-81	54-29#
EMT330	8-663	54-218#
EMT331	8-666	54-219#
EMT332	8-669	54-220#
EMT333	8-672	54-221#
EMT334	8-675	54-222#
EMT335	8-678	54-223#
EMT336	8-351	8-681 54-224#
EMT337	8-684	54-225#
EMT34	8-84	54-30#
EMT340	8-687	54-226#
EMT341	8-690	54-227#
EMT342	8-693	54-228#
EMT343	8-696	54-229#
EMT344	8-699	54-230#
EMT345	8-702	54-231#
EMT346	8-705	54-232#
EMT347	8-708	54-233#
EMT35	8-87	54-31#
EMT350	8-711	54-234#
EMT351	8-714	54-235#
EMT352	8-717	54-236#
EMT353	8-720	54-237#
EMT354	8-723	54-238#

13-091	13-091#	13-091#	13-095	13-095#	13-095#	13-A08	13-A08#	13-A08#	13-A25	13-A25#	13-A25#	13-A28	13-A28#	
13-A30	13-A30#	13-A33	13-A33#	13-A33#	13-A37	13-A37#	13-A37#	13-A54	13-A54#	13-A54#	13-A70	13-A70#	13-A70#	
13-A82	13-A82#	13-A82#	13-A91	13-A91#	13-A91#	13-B03	13-B03#	13-B03#	13-B20	13-B20#	13-B20#	13-B23	13-B23#	
13-B25	13-B25#	13-B28	13-B28#	13-B28#	13-B32	13-B32#	13-B32#	13-B47	13-B47#	13-B47#	13-B63	13-B63#	13-B63#	
13-B75	13-B75#	13-B75#	13-B84	13-B84#	13-B84#	13-C07	13-C07#	13-C07#	13-C18	13-C18#	13-C18#	13-C34	13-C34#	
13-C34#	13-C45	13-C45#	13-C45#	13-C71	13-C71#	13-C71#	13-C74	13-C74#	13-C76	13-C76#	13-C79	13-C79#	13-C79#	
13-C83	13-C83#	13-C83#	13-C96	13-C96#	13-C96#	13-D13	13-D13#	13-D13#	13-D16	13-D16#	13-D18	13-D18#	13-D21	
13-D21#	13-D21#	13-D25	13-D25#	13-D25#	13-D44	13-D44#	13-D44#	13-D46	13-D46#	13-D46#	13-D59	13-D59#	13-D59#	
13-D75	13-D75#	13-D75#	13-D78	13-D78#	13-D80	13-D80#	13-D83	13-D83#	13-D83#	13-D87	13-D87#	13-D87#	13-E06	
13-E06#	13-E06#	13-E08	13-E08#	13-E08#	13-E10	13-E10#	13-E10#	13-E32	13-E32#	13-E32#	13-E43	13-E43#	13-E43#	
13-E63	13-E63#	13-E63#	13-E70	13-E70#	13-E70#	13-E91	13-E91#	13-E91#	13-E94	13-E94#	13-E96	13-E96#	13-E99	
13-E99#	13-E99#	13-F03	13-F03#	13-F03#	13-F08	13-F08#	13-F08#	13-F16	13-F16#	13-F16#	13-F29	13-F29#	13-F29#	
13-F51	13-F51#	13-F51#	13-F54	13-F54#	13-F56	13-F56#	13-F59	13-F59#	13-F59#	13-F59#	13-F63	13-F63#	13-F68	
13-F68#	13-F68#	13-F76	13-F76#	13-F76#	13-F96	13-F96#	13-F96#	13-G15	13-G15#	13-G15#	13-G18	13-G18#	13-G21	
13-G21#	13-G21#	13-G31	13-G31#	13-G34	13-G34#	13-G34#	13-G36	13-G36#	13-G36#	13-G38	13-G38#	13-G38#	13-G51	
13-G51#	13-G51#	13-G70	13-G70#	13-G70#	13-G73	13-G73#	13-G76	13-G76#	13-G76#	13-G87	13-G87#	13-G90	13-G90#	
13-G90#	13-G92	13-G92#	13-G92#	13-G94	13-G94#	13-G94#	13-H06	13-H06#	13-H06#	13-H17	13-H17#	13-H17#	13-H33	
13-H33#	13-H33#	13-H36	13-H36#	13-H38	13-H38#	13-H41	13-H41#	13-H41#	13-H45	13-H45#	13-H45#	13-H59	13-H59#	
13-H59#	13-H77	13-H77#	13-H77#	13-H80	13-H80#	13-H82	13-H82#	13-H85	13-H85#	13-H85#	13-H89	13-H89#	13-H89#	
13-H91	13-H91#	13-H91#	13-H95	13-H95#	13-H95#	13-I08	13-I08#	13-I08#	13-I26	13-I26#	13-I26#	13-I29	13-I29#	
13-I31	13-I31#	13-I34	13-I34#	13-I34#	13-I38	13-I38#	13-I38#	13-I40	13-I40#	13-I40#	13-I44	13-I44#	13-I44#	
13-I46	13-I46#	13-I46#	13-I60	13-I60#	13-I60#	13-I72	13-I72#	13-I72#	13-I88	13-I88#	13-I88#	13-I91	13-I91#	
13-I93	13-I93#	13-I96	13-I96#	13-I96#	13-J00	13-J00#	13-J00#	13-J14	13-J14#	13-J14#	13-J35	13-J35#	13-J35#	
13-J38	13-J38#	13-J40	13-J40#	13-J43	13-J43#	13-J47	13-J47#	13-J47#	13-J49	13-J49#	13-J49#	13-J53	13-J53#	
13-J53#	13-J53#	13-J66	13-J66#	13-J66#	13-J82	13-J82#	13-J85	13-J85#	13-J87	13-J87#	13-J90	13-J90#	13-J90#	
13-J90#	13-J94	13-J94#	13-J94#	13-J96	13-J96#	13-J96#	13-K00	13-K00#	13-K13	13-K13#	13-K13#	13-K24	13-K24#	
13-K24#	13-K24#	13-K40	13-K40#	13-K40#	13-K43	13-K43#	13-K45	13-K45#	13-K48	13-K48#	13-K48#	13-K52	13-K52#	
13-K52#	13-K65	13-K65#	13-K65#	13-K82	13-K82#	13-K82#	13-K85	13-K85#	13-K87	13-K87#	13-K90	13-K90#	13-K90#	
13-K94	13-K94#	13-K94#	13-K96	13-K96#	13-K96#	13-K98	13-K98#	13-K98#	13-L11	13-L11#	13-L11#	13-L27	13-L27#	
13-L27#	13-L30	13-L30#	13-L32	13-L32#	13-L35	13-L35#	13-L35#	13-L39	13-L39#	13-L39#	13-L41	13-L41#	13-L41#	
13-L43	13-L43#	13-L43#	13-L45	13-L45#	13-L45#	13-L58	13-L58#	13-L58#	13-L69	13-L69#	13-L69#	13-L85	13-L85#	
13-L85#	13-L88	13-L88#	13-L90	13-L90#	13-L93	13-L93#	13-L93#	13-L97	13-L97#	13-L97#	13-M10	13-M10#	13-M10#	
13-M27	13-M27#	13-M27#	13-M30	13-M30#	13-M32	13-M32#	13-M35	13-M35#	13-M35#	13-M39	13-M39#	13-M39#	13-M41	
13-M41#	13-M41#	13-M43	13-M43#	13-M43#	13-M56	13-M56#	13-M56#	13-M72	13-M72#	13-M72#	13-M75	13-M75#	13-M77	
13-M77#	13-M80	13-M80#	13-M80#	13-M84	13-M84#	13-M84#	13-M86	13-M86#	13-M86#	13-M88	13-M88#	13-M88#	13-M90	
13-M90#	13-M90#	13-N03	13-N03#	13-N03#	13-N15	13-N15#	13-N15#	13-N33	13-N33#	13-N33#	13-N36	13-N36#	13-N38	
13-N38#	13-N41	13-N41#	13-N41#	13-N45	13-N45#	13-N45#	13-N58	13-N58#	13-N58#	13-N75	13-N75#	13-N75#	13-N78	
13-N78#	13-N80	13-N80#	13-N83	13-N83#	13-N83#	13-N87	13-N87#	13-N87#	13-N89	13-N89#	13-N89#	13-N91	13-N91#	
13-N91#	13-004	13-004#	13-004#	13-020	13-020#	13-020#	13-023	13-023#	13-025	13-025#	13-028	13-028#	13-028#	
13-032	13-032#	13-032#	13-034	13-034#	13-034#	13-036	13-036#	13-036#	13-038	13-038#	13-038#	13-053	13-053#	
13-053#	13-064	13-064#	13-064#	13-080	13-080#	13-080#	13-083	13-083#	13-085	13-085#	13-088	13-088#	13-088#	
13-092	13-092#	13-092#	13-P05	13-P05#	13-P05#	13-P17	13-P17#	13-P17#	13-P23	13-P23#	13-P23#	13-P26	13-P26#	
13-P33	13-P33#	13-P33#	13-P36	13-P36#	13-P38	13-P38#	13-P41	13-P41#	13-P41#	13-P45	13-P45#	13-P45#	13-P47	
13-P47#	13-P47#	13-P49	13-P49#	13-P49#	13-P61	13-P61#	13-P61#	13-P74	13-P74#	13-P74#	13-P83	13-P83#	13-P83#	
13-P86	13-P86#	13-P94	13-P94#	13-P94#	13-P97	13-P97#	13-P99	13-P99#	13-Q02	13-Q02#	13-Q02#	13-Q06	13-Q06#	
13-Q06#	13-Q08	13-Q08#	13-Q08#	13-Q10	13-Q10#	13-Q10#								
FMT16	4-650#	13-49	13-196	13-338	13-513	13-661	13-806	13-985	13-:37	13--15	13->98	13-a56	13-A44	13-B37
	13-C02	13-C42	13-D01	13-E27	13-E60	13-F91	13-H14	13-I69	13-K21	13-L66	13-N12	13-061	16-60	17-32
	17-34	18-27	29-58	35-183										
FNCDTB	25-130	51-55#												
FNCMSK	4-497#	34-17	35-341											
GENRUF	13-56	13-203	13-345	13-520	13-668	13-813	13-992	13-:30	13-:44	13-=26	13--67	13-?09	13-?49	13-a63
GET	13-C05	13-C49	13-E30	13-E67	13-H21	13-I76	13-J25	13-K28	13-L73	13-N19	13-068	17-20#		
	13-76	13-118	13-163	13-223	13-265	13-309	13-364	13-406	13-452	13-471	13-542	13-585	13-630	13-690
	13-733	13-777	13-835	13-877	13-923	13-942	13-:14	13-:63	13-:07	13-:66	13-:96	13-<24	13-<58	13-<85
	13-=51	13-=88	13->15	13->48	13->75	13-?33	13-?81	13-a25	13-a91	13-A33	13-B28	13-C79	13-D21	13-D83
	13-E99	13-F59	13-G21	13-G34	13-G76	13-G90	13-H41	13-H85	13-I34	13-I96	13-J43	13-J90	13-K48	13-K90

OCC	4-62#														
OFFD	4-653#	13-012	13-014												
OFFSET	4-506#	13-P18	13-P78												
OM	4-562#	33-145	33-201	33-204	34-29	35-453	35-456								
ONES	13-518	13-666	13-811	13-:28	13-:42	13-:24	13-:47	13-C47	13-174	13-J23	53-21#				
OPE	4-676#														
OPI	4-568#	25-182	29-140	29-164	32-51	32-69	32-73	33-24	33-61	33-64	33-155	35-83	35-86	35-530	
	36-42	51-57	51-58	51-59	51-60	51-61	51-62	51-63	51-64	51-65	51-66	51-67	51-68	51-69	
	51-70	51-71	51-72	51-73	51-74	51-75	51-76	51-77	51-78	51-79	51-80	51-81	51-82	51-83	
	51-84	51-85	51-86	51-87	51-88										
OR	4-735#														
PACACK	4-510#	16-119													
PAKACK	4-509#	4-510	15-126												
PAR	4-578#	24-135	24-139	24-151	29-30	33-24	33-29	33-34	35-41	35-46					
PAT	4-738#														
PDA	4-628#														
PFECH	44-67	44-172#													
PFECH1	44-172	44-173#													
PFECH2	44-172	44-176#													
PFECH3	44-172	44-179#													
PFECH4	44-172	44-181#													
PGE	4-732#														
PGM	4-558#	34-29													
PHA	4-629#														
PIP	4-554#	13-G23	13-G26	13-G78	13-G81	15-178	16-150	29-156	29-177	29-182	33-145	33-216	33-221	34-29	
	35-505	35-511	35-516	36-35	36-72	36-77									
PIRO	4-484#														
PIROVE	4-484#														
PLFS	4-626#														
PRO	4-484#														
PR1	4-484#														
PR2	4-484#														
PR3	4-484#	42-5													
PR4	4-484#														
PR5	4-484#	12-49	42-9												
PR6	4-484#	10-26	13-7	20-40	21-34	22-7	23-11	28-22	30-14						
PR7	4-484#														
PRIERR	13-122	13-167	13-269	13-313	13-410	13-456	13-589	13-634	13-737	13-781	13-881	13-927	13-:67	13-:11	
	13-<28	13-<89	13->19	13->79	13-?85	13-@29	13-A37	13-B32	13-D25	13-D87	13-F03	13-F63	13-G36	13-G92	
	13-H89	13-I38	13-J47	13-J94	13-K94	13-L39	13-M39	13-M84	13-N87	13-O32	13-P45	13-Q06	24-39#		
PS	4-484	4-484#													
PSEL	4-719#														
PSW	4-484#														
PUT	13-68	13-110	13-155	13-215	13-257	13-301	13-356	13-398	13-444	13-534	13-577	13-622	13-682	13-725	
	13-769	13-827	13-869	13-915	13-:06	13-:55	13-:99	13-:58	13-:88	13-<18	13-<50	13-<79	13-43	13--80	
	13->07	13->40	13->67	13-?25	13-?73	13-@17	13-@83	13-A25	13-B20	13-C18	13-C71	13-D13	13-D75	13-E43	
	13-E74	13-E91	13-F33	13-F51	13-G00	13-G15	13-G55	13-G70	13-H33	13-H77	13-I26	13-I88	13-J35	13-J82	
	13-K40	13-K82	13-L27	13-L85	13-M27	13-M72	13-N33	13-N75	13-O20	13-O80	13-P17	13-P23	13-P33	13-F74	
	13-P83	13-P94	15-129	15-184	16-88	16-120	16-154	16-183	21-28#						
PUTBLF	7-0#	16-49	16-284*	21-31											
PUTINX	7-0#	13-59	13-101	13-146	13-206	13-248	13-292	13-347	13-389	13-435	13-523	13-568	13-613	13-671	
	13-716	13-760	13-816	13-860	13-906	13-995	13-:46	13-:90	13-:47	13-<09	13-<70	13-33	13-=98	13->58	
	13-?16	13-?64	13-@08	13-@74	13-A16	13-B11	13-C10	13-C60	13-D04	13-D66	13-E35	13-E74*	13-E74*	13-E81	
	13-F33*	13-F33*	13-F41	13-G00*	13-G00*	13-G06	13-G55*	13-G55*	13-G61	13-H24	13-H68	13-I17	13-I79	13-J26	
	13-J73	13-K31	13-K73	13-L18	13-L76	13-M18	13-M63	13-N22	13-N66	13-O11	13-O71	13-P09	13-P19	13-P29	
	13-P66	13-P79	13-P90	15-127*	15-128*	15-182*	15-183*	16-63	21-32	24-142					
PWRVEC	4-484#	10-23*	10-23*	48-1*	48-1*	48-1*	48-1*	48-1*	48-1*						

RMCS3	4-770#														
RMCS3I	7-0#														
RMCS3O	7-0#														
RMDA	4-691#	13-61	13-102	13-147	13-208	13-249	13-293	13-349	13-390	13-436	13-525	13-569	13-614	13-673	
	13-717	13-761	13-818	13-861	13-907	13-997	13-:47	13-:91	13-:49	13-<10	13-<71	13-:35	13-:99	13->59	
	13-?18	13-?65	13-@09	13-@76	13-A17	13-B12	13-C11	13-C62	13-D05	13-D67	13-E36	13-E83	13-F43	13-G07	
	13-G62	13-H26	13-H69	13-I18	13-I81	13-J27	13-J74	13-K33	13-K74	13-L19	13-L78	13-M19	13-M64	13-N24	
	13-N67	13-012	13-073	13-P10	13-P67	16-64									
RMDAI	7-0#	26-137	60-14	60-16											
RMDAO	7-0#	13-46*	13-193*	13-335*	13-510*	13-658*	13-803*	13-982*	13-:33*	13-:13*	13-:14*	13-:22	13->96*	13->97*	
	13-?05	13-@53*	13-C39*	13-E57*	13-E65	13-F88*	13-H11*	13-I65*	13-I66*	13-K18*	13-L63*	13-M08*	13-O40*	13-O41	
	13-058*	16-58*	16-232*	16-233	16-235	16-255*	16-299	16-397*	17-24	26-60	26-61	29-53	29-56	29-60	
	35-178	35-181	35-185												
RMDB	4-768#	13-18*	13-19	13-471	13-942	19-20									
RMDBI	7-0#	13-473	13-942*	13-945											
RMDBO	7-0#														
RMDC	4-700#	13-60	13-103	13-149	13-207	13-250	13-295	13-348	13-391	13-438	13-524	13-570	13-616	13-672	
	13-718	13-763	13-817	13-862	13-909	13-996	13-:48	13-:93	13-:48	13-<11	13-<73	13-:34	13->00	13->61	
	13-?17	13-?66	13-@11	13-@75	13-A18	13-B14	13-C13	13-C61	13-D06	13-D69	13-E38	13-E84	13-F45	13-G08	
	13-G64	13-H25	13-H70	13-I20	13-I80	13-J28	13-J76	13-K32	13-K75	13-L21	13-L77	13-M20	13-M66	13-N23	
	13-N68	13-014	13-072	13-P11	13-P69	16-65									
RMDCI	7-0#	26-150	60-14	60-16											
RMDCO	7-0#	13-45*	13-192*	13-334*	13-509*	13-657*	13-802*	13-981*	13-:32*	13-:34	13-:85*	13-<05*	13-<47*	13-<67*	
	13--12*	13->95*	13-@52*	13-C38*	13-E56*	13-F87*	13-H10*	13-I48*	13-I49	13-I64*	13-K17*	13-L62*	13-N07*	13-O57*	
	16-57*	16-298	16-396*	17-23	26-59	29-49	35-174								
RMDS	4-692#	10-86	10-109												
RMDSI	7-0#	13-G23	13-G25	13-G27	13-G78	13-G80	13-G82	15-122	15-178	16-116	16-150	24-104	25-38	25-40	
	25-85	25-102	25-136	25-140	25-196	25-223	25-358	26-92	29-91	29-146	29-155	29-162	29-166	29-168	
	29-177	29-181	29-183	29-192	29-194	29-196	29-206	29-210	29-212	31-124	32-23	32-25	32-27	32-37	
	32-39	32-41	33-68	33-106	33-144	33-153	33-157	33-159	33-169	33-173	33-174	33-185	33-187	33-189	
	33-201	33-203	33-205	33-216	33-220	33-222	34-28	35-88	35-90	35-119	35-252	35-318	35-453	35-455	
	35-457	35-504	35-511	35-515	35-517	35-528	35-532	35-534	35-544	35-548	35-550	36-34	36-40	36-44	
	36-46	36-56	36-60	36-61*	36-62	36-72	36-76	36-78	60-13						
RMDSO	7-0#														
RMDT	4-697#	10-91	12-60	44-26											
RMDTI	7-0#	60-5	60-17												
RMDTO	7-0#														
RMEC1	4-704#														
RMEC1I	7-0#	18-32	60-14												
RMEC1O	7-0#														
RMEC2	4-705#	19-15													
RMEC2I	7-0#	18-53	19-14	31-92	34-94	60-15									
RMEC2O	7-0#														
RMER1	4-693#	13-G00	13-G55	24-143											
RMER1I	7-0#	13-A51	13-A56	13-A67	13-A73	13-B44	13-B49	13-B60	13-B66	13-D28	13-D30	13-D90	13-D92	16-222	
	18-23	18-25	24-135	24-150	24-152	25-80	25-156	25-183	25-226	25-241	25-284	25-361	25-387	25-402	
	25-417	25-470	25-489	25-492	26-89	26-105	26-120	26-132	27-24	29-30	29-37	29-66	29-140	29-143	
	29-164	31-69	32-51	32-55	32-57	32-58	32-69	32-71	32-72	32-83	32-85	32-86	32-97	32-99	
	32-100	32-111	32-113	32-114	33-24	33-29	33-33	33-35	33-45	33-47	33-49	33-61	33-63	33-65	
	33-78	33-80	33-82	33-155	33-232	33-236	33-238	33-240	33-250	33-252	33-254	33-264	33-268	33-270	
	34-41	35-41	35-45	35-47	35-83	35-85	35-87	35-128	35-131	35-133	35-135	35-145	35-147	35-149	
	35-159	35-161	35-163	35-189	35-279	35-282	35-286	35-288	35-297	35-299	35-301	35-311	35-313	35-314	
	35-348	35-352	35-354	35-356	35-365	35-367	35-369	35-378	35-380	35-382	35-391	35-393	35-395	35-413	
	35-415	35-417	35-423	35-479	35-481	35-483	35-530	36-42	60-13						
RMER1O	7-0#	13-G00*	13-G55*	24-139											
RMER2	4-703#														
RMER2I	7-0#	13-A79	13-A84	13-B72	13-B77	13-D34	13-D35	13-D96	13-D97	13-F05	13-F10	13-F11	13-F65	13-F70	

SW4	4-484#													
SW5	4-484#													
SW6	4-484#													
SW7	4-484#													
SW8	4-484#													
SW9	4-484#													
SWR	6-0#	10-23	10-23	10-23*	10-23*	10-23*	10-28	16-245	42-1	42-1	42-1	42-1	42-1	42-1
	42-1*	42-1*	42-1*	42-1*	43-1	43-1	43-	43-1	43-1	44-14	45-1	45-1	45-1*	48-1
	48-1*													
SWREG	5-1#	10-23	10-28	45-1	45-1	45-1								
SYSTAT	10-76	50-23#												
TA1	4-537#													
TA16	4-533#	12-64												
TA2	4-536#	12-64												
TA4	4-535#	12-56												
TA8	4-534#													
TADMSK	4-547#	26-66												
TAG	4-664#													
TAGADR	5-9#	6-0												
TAP	4-641#													
TBITVE	4-484#													
TIMOUT	13-73	13-115	13-160	13-220	13-262	13-306	13-361	13-403	13-449	13-539	13-582	13-627	13-687	13-730
	13-774	13-832	13-874	13-920	13-:11	13-:60	13-:04	13-:63	13-:93	13-<21	13-<55	13-<82	13--48	13--85
	13->12	13->45	13->72	13-?30	13-?78	13-a22	13-a88	13-A30	13-B25	13-C20	13-C76	13-D18	13-D80	13-E45
	13-E96	13-F56	13-G31	13-G87	13-H38	13-H82	13-I31	13-I93	13-J40	13-J87	13-K45	13-K87	13-L32	13-L90
	13-M32	13-M77	13-N38	13-N80	13-025	13-085	13-P26	13-P38	13-P86	13-P99	15-137	15-192	16-96	16-128
	16-162	16-191	23-9#											
TKVEC	4-484#	45-1*	45-1*											
TPVEC	4-484#													
TRAPVE	4-484#	10-23*	10-23*											
TRE	4-717#	16-209	24-90	24-107	24-123	25-106	25-108	26-12						
TRTVEC	4-484#													
TST	4-665#	31-103	34-83											
TST1	13-2#	42-1												
TST10	13-969#	42-1												
TST11	13-:20#	42-1												
TST12	13-=05#	42-1												
TST13	13->88#	42-1												
TST14	13-a38#	42-1												
TST15	13-C24#	42-1												
TST16	13-E49#	42-1												
TST17	13-F81#	42-1												
TST2	13-33#	42-1												
TST20	13-G99#	42-1												
TST21	13-I54#	42-1												
TST22	13-K05#	42-1												
TST23	13-L50#	42-1												
TST24	13-M95#	42-1												
TST25	13-O46#	42-1												
TST3	13-180#	42-1												
TST4	13-322#	42-1												
TST5	13-497#	42-1												
TST6	13-645#	42-1												
TST7	13-790#	42-1												
TSTNMB	44-44*	44-45*	44-47	44-159#										
TSTPRP	13-41	13-93	13-139	13-188	13-240	13-286	13-330	13-381	13-429	13-505	13-560	13-606	13-653	13-708
	13-754	13-798	13-852	13-900	13-977	13-:40	13-:84	13-:28	13-:83	13-<45	13-=29	13-=76	13->36	13-?12

CROSS REFERENCE TABLE (CREF V01-05)

	13-258	13-a02	13-a48	13-A08	13-B03	13-C07	13-C34	13-C96	13-D59	13-E32	13-E70	13-F29	13-F96	13-G51
	13-H06	13-H59	13-I08	13-I60	13-J14	13-J66	13-K13	13-K65	13-L11	13-L58	13-M10	13-M56	13-N03	13-N58
	13-004	13-053	13-P05	13-P61	15-38#									
TSTQUE	7-0#	12-8	12-9*	12-50	12-59	13-2	13-33	13-180	13-322	13-497	13-645	13-790	13-969	13-;20
	13-005	13->88	13-a38	13-C24	13-E49	13-F81	13-G99	13-I54	13-K05	13-L50	13-M95	13-046	14-11	14-13*
	14-17	14-17*	28-24	30-17	31-54	34-53								
TYPBN	44-149	47-1#												
TYPDS	14-20	14-20	44-143	47-1#										
TYPE	10-6	10-28	10-42	10-48	10-53	10-59	10-60	10-76	10-80	10-82	10-107	10-113	10-116	10-120
	10-128	10-131	10-132	10-133	10-140	11-11	11-16	11-17	11-19	11-20	11-28	11-32	11-34	11-40
	11-44	11-48	11-54	11-61	11-62	11-64	11-69	11-75	11-86	11-87	11-92	11-100	12-3	12-6
	12-7	12-14	12-25	12-30	12-68	12-69	13-52	13-199	13-341	13-516	13-664	13-809	13-988	13-;40
	13-20	13-?03	13-a59	13-C45	13-E63	13-H17	13-I72	13-K24	13-L69	13-N15	13-064	14-20	14-20	14-20
	38-1	39-1	40-1	41-1	43-1	43-1	44-20	44-21	44-39	44-40	44-46	44-51	44-53	44-61
	44-104	44-110	44-114	44-126	44-132	44-134	44-152	44-154	45-1	45-1	45-1	45-1	45-1	45-1
	45-1	45-1	45-1	45-1	45-1	45-1	45-1	45-1	45-1	45-1	45-1	45-1	47-1#	48-1
TYPOC	10-8	11-33	11-47	44-146	45-1	47-1#								
TYPON	47-1#													
TYPOS	10-45	10-56	10-81	12-16	12-70	44-22	44-47	44-52	44-54	47-1#				
UO	4-742#													
U1	4-742#													
U2	4-742#													
UNS	4-567#	13-G00	13-G55	31-70	32-51	32-55	32-59	33-232	33-264	33-269	35-279	35-282	35-287	
UNTMSK	4-746#	24-48	24-50											
UNTOFF	10-120	50-31#												
UNTON	10-131	50-32#												
UPE	4-729#	25-270												
USE	4-686#	13-A46	13-B39	17-29										
USRFIL	16-253	16-256	16-266*	16-274*	16-325	62-12#								
VV	4-561#	15-122	16-116	25-196	29-91	29-156	29-157	29-206	29-211	32-23	32-26	33-106	33-145	33-146
	33-169	33-175	34-29	35-90	35-119	35-505	35-506	35-544	35-549	36-35	36-36	36-56	36-61	
WC	4-631#	31-80	34-70											
WCD	4-517#	13-291	13-434	13-759	13-905	13-;89	13->57	13-a07	13-J72	13-P89				
WCE	4-728#	13-458	13-464	13-929	13-934	25-169	51-77	51-78						
WCEHI	4-753#													
WCELO	4-754#													
WCF	4-576#	4-583	25-240	35-479	35-482									
WCH	4-518#													
WD	4-521#	13-100	13-247	13-388	13-567	13-715	13-859	13-;27	13-;45	13-<08	13-;66	13--97	13-?44	13-?63
	13-A15	13-D02	13-E61	13-E79	13-F92	13-G05	13-H67	13-J22	13-K72	13-M17	13-N65			
WH	4-522#	13-50	13-197	13-339	13-514	13-662	13-807	13-986	13-;38	13-;18	13-?01	13-a57	13-C04	13-C09
	13-C43	13-E29	13-E34	13-H15	13-170	13-K22	13-L67	13-N13	13-062	35-342				
WLE	4-570#	4-583	25-221	25-225	25-238	25-253	25-268	35-279	35-311	35-315	35-323	51-81	51-82	
WRL	4-556#	25-223	35-318											
XSIZ	10-70#	11-71	11-101											
XADP	7-0#	10-33*	10-36*	10-37	10-39*	10-44	- 5	10-124	10-126					
Y	50-36#													
ZEROS	13-54	13-201	13-343	13-990	13--64	13-?07	13-a61	13-H19	13-066	53-38#				

SSCMRE	5-10#													
SSCMTM	5-10#	6-0	6-0	6-0	6-0	6-0								
SSESCA	4-484#													
SSNEWI	4-484#	13-2	13-33	13-180	13-322	13-497	13-645	13-790	13-969	13-;20	13-=05	13->88	13-@38	13-C24
	13-E49	13-F81	13-G99	13-I54	13-K05	13-L50	13-M95	13-O46						
SSSET	47-1	47-1	47-1	47-1	47-1	47-1	47-1	47-1	47-1	47-1	47-1	47-1	47-1	47-1#
SSSETM	10-23	10-23#												
SSSKIP	4-484#													
.SACT1	4-476#	5-5												
.SAPTB	4-476#	6-0	6-0#											
.SAPTH	4-476#	5-8												
.SAPTY	4-476#	49-1												
.SCATC	4-472#	5-1												
.SCMTA	4-473#	5-10												
.SEOP	4-473#	14-20												
.SERRO	4-473#	43-1												
.SPOWE	4-475#	48-1												
.SRDDE	4-474#													
.SRDOC	4-474#	46-1												
.SREAD	4-474#	45-1												
.SSAVE	4-475#	37-1												
.SSCOP	4-473#	42-1												
.SSIZE	4-475#													
.STRAP	4-475#	47-1												
.STYPB	4-474#	38-1												
.STYPD	4-474#	39-1												
.STYPE	4-473#	41-1												
.STYPO	4-474#	40-1												
.EQUAT	4-472#	4-484												
.HEADE	4-472#	4-480												
.SETUP	4-472#	4-775												
.SWRHI	4-472#	4-481												
.SWRLO	4-472#	4-481#	4-482											
CALCLR	4-187#													
CALSUB	4-201#	13-41	13-52	13-68	13-71	13-73	13-76	13-80	13-93	13-110	13-113	13-115	13-118	13-122
	13-124	13-126	13-139	13-155	13-158	13-160	13-163	13-167	13-169	13-171	13-175	13-188	13-199	13-215
	13-218	13-220	13-223	13-227	13-240	13-257	13-260	13-262	13-265	13-269	13-271	13-273	13-286	13-301
	13-304	13-306	13-309	13-313	13-315	13-317	13-330	13-341	13-356	13-359	13-361	13-364	13-368	13-381
	13-398	13-401	13-403	13-406	13-410	13-412	13-414	13-429	13-444	13-447	13-449	13-452	13-456	13-461
	13-489	13-505	13-516	13-534	13-537	13-539	13-542	13-546	13-560	13-577	13-580	13-582	13-585	13-589
	13-591	13-593	13-606	13-622	13-625	13-627	13-630	13-634	13-636	13-638	13-640	13-653	13-664	13-682
	13-685	13-687	13-690	13-694	13-708	13-725	13-728	13-730	13-733	13-737	13-739	13-741	13-754	13-769
	13-772	13-774	13-777	13-781	13-783	13-785	13-798	13-809	13-827	13-830	13-832	13-835	13-839	13-852
	13-869	13-872	13-874	13-877	13-881	13-883	13-885	13-900	13-915	13-918	13-920	13-923	13-927	13-931
	13-961	13-977	13-988	13-:06	13-:09	13-:11	13-:14	13-:18	13-:40	13-:55	13-:58	13-:60	13-:63	13-:67
	13-:69	13-:71	13-:84	13-:99	13-:02	13-:04	13-:07	13-:11	13-:13	13-:15	13-:28	13-:40	13-:58	13-:61
	13-:63	13-:66	13-:70	13-:83	13-:88	13-:91	13-:93	13-:96	13-<00	13-<18	13-<21	13-<24	13-<28	13-<30
	13-<32	13-<45	13-<50	13-<53	13-<55	13-<58	13-<62	13-<79	13-<82	13-<85	13-<89	13-<91	13-<93	13-<95
	13-=20	13-=29	13--43	13--46	13-=48	13-=51	13-=55	13-=76	13-=80	13-=83	13-=85	13-=88	13-=92	13->07
	13->10	13->12	13->15	13->19	13->21	13->23	13->36	13->40	13->43	13->45	13->48	13->52	13->67	13->70
	13->72	13->75	13->79	13->81	13->83	13-?03	13-?12	13-?25	13-?28	13-?30	13-?33	13-?37	13-?58	13-?73
	13-?76	13-?78	13-?81	13-?85	13-?87	13-?89	13-@02	13-@17	13-@20	13-@22	13-@25	13-@29	13-@31	13-@33
	13-@48	13-@59	13-@83	13-@86	13-@88	13-@91	13-@95	13-A08	13-A25	13-A28	13-A30	13-A33	13-A37	13-A54
	13-A70	13-A82	13-A91	13-B03	13-B20	13-B23	13-B25	13-B28	13-B32	13-B47	13-B63	13-B75	13-B84	13-C07
	13-C18	13-C34	13-C45	13-C71	13-C74	13-C76	13-C79	13-C83	13-C96	13-D13	13-D16	13-D18	13-D21	13-D25
	13-D44	13-D46	13-D59	13-D75	13-D78	13-D80	13-D83	13-D87	13-E06	13-E08	13-E10	13-E32	13-E43	13-E63

	13-E70	13-E91	13-E94	13-E96	13-E99	13-F03	13-F08	13-F16	13-F29	13-F51	13-F54	13-F56	13-F59	13-F63
	13-F68	13-F76	13-F96	13-G15	13-G18	13-G21	13-G31	13-G34	13-G36	13-G38	13-G51	13-G70	13-G73	13-G76
	13-G87	13-G90	13-G92	13-G94	13-H06	13-H17	13-H33	13-H36	13-H38	13-H41	13-H45	13-H59	13-H77	13-H80
	13-H82	13-H85	13-H89	13-H91	13-H95	13-I08	13-I26	13-I29	13-I31	13-I34	13-I38	13-I40	13-I44	13-I46
	13-I60	13-I72	13-I88	13-I91	13-I93	13-I96	13-J00	13-J14	13-J35	13-J38	13-J40	13-J43	13-J47	13-J49
	13-J53	13-J66	13-J82	13-J85	13-J87	13-J90	13-J94	13-J96	13-K00	13-K13	13-K24	13-K40	13-K43	13-K45
	13-K48	13-K52	13-K65	13-K82	13-K85	13-K87	13-K90	13-K94	13-K96	13-K98	13-L11	13-L27	13-L30	13-L32
	13-L35	13-L39	13-L41	13-L43	13-L45	13-L58	13-L69	13-L85	13-L89	13-L90	13-L93	13-L97	13-M10	13-M27
	13-M30	13-M32	13-M35	13-M39	13-M41	13-M43	13-M56	13-M72	13-M75	13-M77	13-M80	13-M84	13-M86	13-M88
	13-M90	13-N03	13-N15	13-N33	13-N36	13-N38	13-N41	13-N45	13-N58	13-N75	13-N78	13-N80	13-N83	13-N87
	13-N89	13-N91	13-004	13-020	13-023	13-025	13-028	13-032	13-034	13-036	13-038	13-053	13-064	13-080
	13-083	13-085	13-088	13-092	13-P05	13-P17	13-P23	13-P26	13-P33	13-P36	13-P38	13-P41	13-P45	13-P47
	13-P49	13-P61	13-P74	13-P83	13-P86	13-P94	13-P97	13-P99	13-Q02	13-Q06	13-Q08	13-Q10		
COMMEN	4-484#													
ENDCOM	4-484#													
ERROR	4-484#	13-25	13-41	13-52	13-68	13-76	13-80	13-93	13-110	13-118	13-122	13-124	13-126	13-139
	13-155	13-163	13-167	13-169	13-171	13-175	13-188	13-199	13-215	13-223	13-227	13-240	13-257	13-265
	13-269	13-271	13-273	13-286	13-301	13-309	13-313	13-315	13-317	13-330	13-341	13-356	13-364	13-368
	13-381	13-398	13-406	13-410	13-412	13-414	13-429	13-444	13-452	13-456	13-461	13-468	13-471	13-481
	13-485	13-489	13-505	13-516	13-534	13-542	13-546	13-560	13-577	13-585	13-589	13-591	13-593	13-606
	13-622	13-630	13-634	13-636	13-638	13-640	13-653	13-664	13-682	13-690	13-694	13-708	13-725	13-733
	13-737	13-739	13-741	13-754	13-769	13-777	13-781	13-783	13-785	13-798	13-809	13-827	13-835	13-839
	13-852	13-869	13-877	13-881	13-883	13-885	13-900	13-915	13-923	13-927	13-931	13-938	13-942	13-953
	13-957	13-961	13-977	13-988	13-:06	13-:14	13-:18	13-:40	13-:55	13-:63	13-:67	13-:69	13-:71	13-:84
	13-:99	13-:07	13-:11	13-:13	13-:15	13-:28	13-:40	13-:58	13-:66	13-:70	13-:83	13-:88	13-:96	13-<00
	13-<18	13-<24	13-<28	13-<30	13-<32	13-<45	13-<50	13-<58	13-<62	13-<79	13-<85	13-<89	13-<91	13-<93
	13-<95	13-=20	13=-29	13-=43	13-=51	13-=55	13-=76	13-=80	13-=88	13-=92	13->07	13->15	13->19	13->21
	13->23	13->36	13->40	13->48	13->52	13->67	13->75	13->79	13->81	13->83	13-?03	13-?12	13-?25	13-?33
	13-?37	13-?58	13-?73	13-?81	13-?85	13-?87	13-?89	13-@02	13-@17	13-@25	13-@29	13-@31	13-@33	13-@48
	13-@59	13-@83	13-@91	13-@95	13-A08	13-A25	13-A33	13-A37	13-A54	13-A62	13-A70	13-A74	13-A82	13-A86
	13-A91	13-B03	13-B20	13-B28	13-B32	13-B47	13-B55	13-B63	13-B67	13-B75	13-B79	13-B84	13-C07	13-C18
	13-C34	13-C45	13-C71	13-C79	13-C83	13-C96	13-D13	13-D21	13-D25	13-D39	13-D44	13-D46	13-D59	13-D75
	13-D83	13-D87	13-E01	13-E06	13-E08	13-E10	13-E32	13-E43	13-E63	13-E70	13-E74	13-E91	13-E99	13-F03
	13-F08	13-F13	13-F16	13-F29	13-F33	13-F51	13-F59	13-F63	13-F68	13-F73	13-F76	13-F96	13-G00	13-G15
	13-G21	13-G28	13-G34	13-G36	13-G38	13-G51	13-G55	13-G70	13-G76	13-G83	13-G90	13-G92	13-G94	13-H06
	13-H17	13-H33	13-H41	13-H45	13-H59	13-H77	13-H85	13-H89	13-I.91	13-H95	13-I08	13-I26	13-I34	13-I38
	13-I40	13-I44	13-I46	13-I60	13-I72	13-I88	13-I96	13-J00	13-J14	13-J35	13-J43	13-J47	13-J49	13-J53
	13-J66	13-J82	13-J90	13-J94	13-J96	13-K00	13-K13	13-K24	13-K40	13-K48	13-K52	13-K65	13-K82	13-K90
	13-K94	13-K96	13-K98	13-L11	13-L27	13-L35	13-L39	13-L41	13-L43	13-L45	13-L58	13-L69	13-L85	13-L93
	13-L97	13-M10	13-M27	13-M35	13-M39	13-M41	13-M43	13-M56	13-M72	13-M80	13-M84	13-M86	13-M88	13-M90
	13-N03	13-N15	13-N33	13-N41	13-N45	13-N58	13-N75	13-N83	13-N87	13-N89	13-N91	13-004	13-020	13-028
	13-032	13-034	13-036	13-038	13-053	13-064	13-080	13-088	13-092	13-P05	13-P17	13-P23	13-P33	13-P41
	13-P45	13-P47	13-P49	13-P61	13-P74	13-P83	13-P94	13-Q02	13-Q06	13-Q08	13-Q10	42-1		
ESCAPE	4-484#													
GETPRI	4-484#													
GETREG	4-164#	13-471	13-942											
GETSWR	4-484#	10-28	10-28#											
MSG	4-8#													
MULT	4-484#													
NEWST	4-484#	13-2	13-33	13-180	13-322	13-497	13-645	13-790	13-969	13-:20	13-=05	13->88	13-@38	13-C24
	13-E49	13-F81	13-G99	13-I54	13-K05	13-L50	13-M95	13-046						
NEWST	4-36#	13-2	13-33	13-180	13-322	13-497	13-645	13-790	13-969	13-:20	13-=05	13->88	13-@38	13-C24
	13-E49	13-F81	13-G99	13-I54	13-K05	13-L50	13-M95	13-046						
POP	4-484#	13-17	13-20	13-24	16-71	16-278	16-288	16-398	17-65	18-95	19-25	19-26	19-27	20-70
	21-59	22-20	22-21	23-35	24-145	24-149	25-131	28-51	30-25	31-58	34-58	34-59	37-1	39-1
	46-1	48-1	48-1	49-1	49-1									
PUSH	4-484#	13-5	13-14	16-47	16-262	16-281	16-297	17-20	18-17	19-10	19-11	19-12	20-35	21-29

	22-4	22-5	23-9	24-141	25-128	28-20	30-12	31-52	34-51	34-52	37-1	39-1	46-1	48-1
PUTREG	48-1	49-1	49-1	49-1										
REPORT	4-442#	13-E74	13-F33	13-G00	13-G55									
RGBFMC	4-69#	7-0	7-0											
SETPRI	4-484#	12-49	42-5	42-9	45-1									
SETTRA	47-1	47-1	47-1	47-1	47-1	47-1	47-1	47-1	47-1	47-1	47-1	47-1	47-1	47-1#
SETUP	4-484#	10-23												
SKIP	4-484#													
SLASH	4-484#													
STARS	4-484#	5-5	5-8	5-8	5-8	6-0	6-0	6-0	13-2	13-2	13-33	13-33	13-35	13-87
	13-133	13-180	13-180	13-182	13-234	13-280	13-322	13-322	13-324	13-375	13-420	13-497	13-497	13-499
	13-553	13-600	13-645	13-645	13-647	13-701	13-748	13-790	13-790	13-792	13-846	13-891	13-969	13-969
	13-971	13-:33	13-:78	13-:20	13-:20	13-:22	13-:77	13-<39	13-=05	13-=05	13-=07	13-=70	13->30	13->88
	13->88	13->90	13-?52	13-?96	13-@38	13-@38	13-@40	13-A02	13-A97	13-B97	13-B99	13-C24	13-C24	13-C26
	13-C90	13-D53	13-E22	13-E24	13-E49	13-E49	13-E51	13-F23	13-F81	13-F81	13-F83	13-G45	13-G99	13-G99
	13-H02	13-H52	13-I02	13-I54	13-I54	13-I57	13-J07	13-J60	13-K05	13-K05	13-K07	13-K59	13-L05	13-L50
	13-L50	13-L52	13-M04	13-M50	13-M95	13-M95	13-M97	13-N52	13-N98	13-O46	13-O46	13-O48	13-P01	13-P56
	14-20	15-57	15-70	15-84	15-107	15-139	15-161	15-194	16-213	16-290	16-294	25-26	25-34	25-119
	26-1	26-3	37-1	38-1	39-1	40-1	41-1	42-1	43-1	45-1	45-1	45-1	45-1	45-1
	46-1	47-1	48-1	48-1	49-1									
SWRSU	4-484#	10-23	10-23#											
TAGS	4-103#	6-0												
TRMTRP	47-1#													
TYPBIN	4-484#													
TYPDEC	4-484#	14-20	14-20											
TYPNAM	4-472#	4-484#	10-28											
TYPNUM	4-484#													
TYPOCS	4-484#	10-81	12-16	12-70	44-22	44-47	44-52	44-54						
TYPOCT	4-484#	11-33	45-1											
TYPTXT	4-484#	10-6	10-42	10-53	10-59	10-60	12-30	14-20	14-20					
XPER	4-12#	8-3	8-6	8-9	8-12	8-15	8-18	8-21	8-24	8-27	8-30	8-33	8-36	8-39
	8-42	8-45	8-48	8-51	8-54	8-57	8-60	8-63	8-66	8-69	8-72	8-75	8-78	8-81
	8-84	8-87	8-90	8-93	8-96	8-99	8-102	8-105	8-108	8-111	8-114	8-117	8-120	8-123
	8-126	8-130	8-133	8-136	8-139	8-142	8-146	8-150	8-154	8-157	8-160	8-163	8-166	8-169
	8-172	8-175	8-178	8-182	8-185	8-188	8-191	8-194	8-197	8-200	8-203	8-206	8-209	8-212
	8-215	8-218	8-221	8-224	8-227	8-230	8-233	8-236	8-239	8-242	8-245	8-248	8-251	8-254
	8-257	8-260	8-263	8-266	8-269	8-272	8-275	8-278	8-281	8-284	8-287	8-290	8-293	8-296
	8-299	8-302	8-305	8-308	8-311	8-314	8-317	8-320	8-323	8-326	8-329	8-332	8-335	8-338
	8-341	8-344	8-347	8-351	8-354	8-357	8-360	8-363	8-366	8-369	8-372	8-375	8-378	8-381
	8-384	8-387	8-390	8-393	8-396	8-399	8-402	8-405	8-408	8-411	8-414	8-417	8-420	8-423
	8-426	8-429	8-432	8-435	8-438	8-441	8-444	8-447	8-450	8-453	8-456	8-459	8-462	8-465
	8-468	8-471	8-474	8-477	8-480	8-483	8-486	8-489	8-492	8-495	8-498	8-501	8-504	8-507
	8-510	8-513	8-516	8-519	8-522	8-525	8-528	8-531	8-534	8-537	8-540	8-543	8-546	8-549
	8-552	8-556	8-559	8-563	8-566	8-569	8-573	8-577	8-581	8-586	8-590	8-594	8-597	8-600
	8-603	8-606	8-609	8-612	8-615	8-618	8-621	8-624	8-627	8-630	8-633	8-636	8-639	8-642
	8-645	8-648	8-651	8-654	8-657	8-660	8-663	8-666	8-669	8-672	8-675	8-678	8-681	8-684
	8-687	8-690	8-693	8-696	8-699	8-702	8-705	8-708	8-711	8-714	8-717	8-720	8-723	