

RM02/03/05

RM05/3/2 DRV CMPT TST  
CZRMTB0

AH-F943B-MC  
FICHE 1 OF 1

AUG 1981  
COPYRIGHT © 80-81  
MADE IN USA



.REM    a

1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44

IDENTIFICATION  
-----

PRODUCT CODE:    AC-F942B-MC  
PRODUCT NAME:    CZRMTBO RM05/3/2 DRIVE COMPATIBILITY TEST  
PRODUCT DATE:    APRIL 1981  
MAINTAINER:      CX DIAGNOSTIC GROUP  
AUTHOR:          MIKE LEAVITT

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS MANUAL.

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED UNDER A LICENSE AND MAY ONLY BE USED OR COPIED IN ACCORDANCE WITH THE TERMS OF SUCH LICENSE.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

COPYRIGHT (C) 1980,1981 DIGITAL EQUIPMENT CORPORATION

CONTENTS  
-----

1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57

- 1.0 ABSTRACT
- 2.0 HARDWARE REQUIREMENTS
- 3.0 PRELIMINARY PROGRAM REQUIREMENTS
- 4.0 GENERAL PROGRAM CONSIDERATIONS
  - 4.1 SYSMAC
  - 4.2 XXDP
  - 4.3 ACT
  - 4.4 APT
  - 4.5 DUAL-ACCESS
  - 4.6 MEMORY MANAGEMENT
  - 4.7 MEMORY PARITY OPTION
  - 4.8 BAD SECTORS
  - 4.9 EXECUTION TIME
- 5.0 PROGRAM LOAD MEDIA
- 6.0 PROGRAM OPTIONS
  - 6.1 STARTING ADDRESSES
  - 6.2 'SOFTWARE' SWITCH REGISTER
  - 6.3 OPERATIONAL SWITCH SETTINGS
- 7.0 RUNNING THE PROGRAM
- 8.0 OPERATIONAL DIALOGUE
  - 8.1 DIALOGUE FOR ADDRESS 200 START
  - 8.2 DIALOGUE FOR ADDRESS 204 START
  - 8.3 DIALOGUE FOR ADDRESS 210 START
  - 8.4 PASS 1 DIALOGUE
  - 8.5 PASS 2 DIALOGUE
- 9.0 DESCRIPTION OF TESTS
  - 9.1 DESCRIPTION OF PASS 1 TESTS
  - 9.2 DESCRIPTION OF PASS 2 TESTS
- 10.0 PRINTOUT OF TEST RESULTS
  - 10.1 OVERWRITE AND DRIVE COMPATIBILITY DATA TEST RESULTS
- 11.0 ERROR REPORTING
  - 11.1 COMMON ERRORS
  - 11.2 ERROR HANDLING
  - 11.3 ERROR PRINTOUT EXAMPLE
- 12.0 TABLE DESCRIPTIONS
  - 12.1 TABLE A - BASIC READ/WRITE TEST SECTORS

58  
59  
60  
61  
62  
63  
64  
65

12.2 TABLE B - WORSE CASE DATA PATTERN  
12.3 TABLE C - CYLINDER BLOCK ASSIGNMENT FOR A GIVEN SURFACE  
12.4 TABLE D - BASIC CYLINDER BLOCK LAYOUT EXAMPLE  
12.5 TABLE E - OVERWRITE CYLINDERS  
12.6 TABLE F - SELF-TEST CYLINDERS  
12.7 TABLE G - PSEUDO-RANDOM DATA PATTERN

13.0 RM SOFTWARE DRIVER DOCUMENT

1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57

## 1.0 ABSTRACT

THE PURPOSE OF THIS PROGRAM IS TO VERIFY THE COMPATIBILITY OF UP TO 16 RM05/3/2 DRIVES WHICH MAY RESIDE ON 1 OR MORE RH/RM SUBSYSTEMS. COMPATIBILITY IS DEFINED HERE AS THE ABILITY OF A DRIVE TO WRITE DATA WHICH CAN BE READ SUCCESSFULLY BY ALL OTHER DRIVES, AND ADDITIONALLY THE ABILITY OF A DRIVE TO COMPLETELY OVER-WRITE DATA WRITTEN BY ALL OTHER DRIVES.

THE PROGRAM IS DESIGNED TO DETECT THE FOLLOWING CONDITIONS WHICH MOST COMMONLY CAUSE INCOMPATIBILITY BETWEEN DRIVES:

1. HEAD MIS-ALIGNMENT
2. POSITIONER LATERAL MISALIGNMENT
3. SPINDLE-CARTRIDGE INTERFACE RUNOUT
4. IMPROPER LEVELS OF WRITE CURRENT
5. INCORRECT ADDRESSING OF READ/WRITE HEADS

THE TESTING IS DONE IN TWO PASSES. IN PASS 1, COMPATIBILITY DATA PATTERNS ARE WRITTEN BY ALL THE DRIVES UPON THE SAME DISK CARTRIDGE, AND THE BASIC READ/WRITE CAPABILITY OF EACH DRIVE IS DEMONSTRATED. IN PASS 2, THE COMPATIBILITY DATA FROM ALL DRIVES IS READ BY EACH DRIVE, WITH HEAD OFFSET, AND THIS IS COMPARED WITH EACH DRIVE'S ABILITY TO READ ITS OWN DATA. IN ADDITION, EACH DRIVE'S CAPABILITY TO OVERWRITE DATA WRITTEN BY ALL OTHER DRIVES IS TESTED ON THE SECOND PASS. (FOR THE REMAINDER OF THIS SPECIFICATION, THE ABOVE DEFINITIONS OF THE FIRST AND SECOND PASS SHALL APPLY).

IN BOTH PASSES, THE PROGRAM DIRECTS THE OPERATOR IN THE LOADING AND UNLOADING OF DRIVES AND THE MOVEMENT OF THE CARTRIDGE FROM DRIVE TO DRIVE, THROUGH MESSAGES AT THE CONSOLE TERMINAL. AT THE COMPLETION OF TESTING ON EACH DRIVE DURING THE SECOND PASS A SUMMARY IS PRINTED OF COMPATIBILITY TEST RESULTS FOR THAT DRIVE.

WITHIN THE VARIOUS TESTS OF BOTH PASSES, THE CAPABILITY IS PROVIDED TO LOOP ON CURRENT OPERATIONS, AND SWITCH REGISTER OPTIONS ARE PROVIDED, FOR A VARIETY OF LOOPING, RUNNING, AND REPORTING MODES (SEE SECTION 6.2).

UNEXPECTED ERRORS WILL BE REPORTED AS THEY OCCUR. THE REPORT WILL INCLUDE DESCRIPTION AND APPLICABLE DEVICE REGISTER CONTENTS.

## 2.0 HARDWARE REQUIREMENTS

THE FOLLOWING HARDWARE IS REQUIRED TO RUN THE RM05/3/2 DRIVE COMPATIBILITY PROGRAM.

PDP-11 PROCESSOR  
12K MEMORY

58  
59  
60  
61  
62  
63  
64  
65  
66  
67  
68  
69  
70  
71  
72  
73  
74  
75  
76  
77  
78  
79  
80  
81  
82  
83  
84  
85  
86  
87  
88  
89  
90  
91  
92  
93  
94  
95  
96  
97  
98  
99  
100  
101  
102  
103  
104  
105  
106  
107  
108  
109  
110  
111  
112  
113  
114

KW11-L OR KW11-P CLOCK  
PROGRAM LOADING DEVICE  
TERMINAL  
RH11 OR RH70 CONTROLLER  
1 TO 8 DISK DRIVES PER CONTROLLER (ANY COMBINATION OF RM05'S, RM03'S OR RM02'S)

ANY COMBINATION OF DRIVE TYPES MAY BE MIXED TOGETHER ON A CONTROLLER. BUT, DO TO THE PHYSICAL SIZE OF THE DISK PACKS, THE RM03/2'S AND THE RM05'S CANNOT BE SELECTED FOR COMPATIBILITY TOGETHER. IF FOR SOME REASON AN RM03/2 AND AN RM05 ARE SELECTED FOR COMPATIBILITY TOGETHER, THE PROGRAM WILL RECOGNIZE THIS UPON THE DIFFERENT DRIVE TYPE AND TYPE THE FOLLOWING MESSAGE:

?CANNOT SELECT RM03/2'S AND RM05'S TOGETHER (NOT COMPATIBLE)

IN ADDITION, A SINGLE RM03/2 OR RM05 DISK CARTRIDGE IS REQUIRED WHICH MUST BE FORMATTED IN 32 SECTOR FORMAT, ON A RELIABLE WELL-ALIGNED(REFERENCE PACK) RM03/2 OR RM05 DRIVE. THIS CARTRIDGE WILL BE MOVED FROM DRIVE TO DRIVE, (ON UP TO 16 DRIVES) ON EACH OF THE TWO PASSES.

### 3.0 PRELIMINARY PROGRAM REQUIREMENTS

BEFORE RUNNING THE RM05/3/2 DRIVE COMPATIBILITY PROGRAM, THE SUBSYSTEM(S) UNDER TEST SHOULD BE CAPABLE OF PASSING THE DISKLESS TESTS AND THE THE FUNCTIONAL TESTS. IN ADDITION, THE CARTRIDGE MUST BE FORMATTED IN 32 SECTOR FORMAT USING THE PACK FORMATTER.

### 4.0 GENERAL PROGRAM CONSIDERATIONS

#### 4.1 SYSMAC

THIS PROGRAM USES PORTIONS OF THE SYSMAC DIAGNOSTIC SYSTEM MACRO PACKAGE.

#### 4.2 XXDP

THIS PROGRAM MAY BE LOADED UNDER XXDP, AND MAY BE RUN IN DUMP MODE ONLY. DUE TO MANUAL INTERVENTION AND LACK OF END-OF-PASS HOOKS, THE PROGRAM IS NOT XXDP CHAINABLE.

#### 4.3 ACT

THIS PROGRAM MAY BE LOADED UNDER ACT AND MAY BE RUN IN DUMP MODE ONLY. IT IS NOT CHAINABLE UNDER ACT.

#### 4.4 APT

THIS PROGRAM MAY BE LOADED BY THE APT SYSTEM, BUT MAY BE RUN IN

115  
116  
117  
118  
119  
120  
121  
122  
123  
124  
125  
126  
127  
128  
129  
130  
131  
132  
133  
134  
135  
136  
137  
138  
139  
140  
141  
142  
143  
144  
145  
146  
147  
148  
149  
150  
151  
152  
153  
154  
155  
156  
157  
158  
159  
160  
161  
162  
163  
164  
165  
166  
167  
168  
169  
170  
171

PROGRAM (DUMP) MODE ONLY. IT CANNOT BE RUN IN APT SCRIPT MODE.

#### 4.5 DUAL-ACCESS

THIS PROGRAM DOES NOT UTILIZE THE DUAL-ACCESS OPTION IN ANY WAY, AND ALL DRIVES UNDER TEST SHOULD BE DE-SELECTED THROUGH THE PORT WHICH IS NOT IN USE, OR LOCKED ON THE PORT BEING TESTED.

#### 4.6 MEMORY MANAGEMENT

MEMORY MANAGEMENT IS NOT UTILIZED IN THIS PROGRAM. IF IT IS INSTALLED, IT IS DISABLED BY THE PROGRAM.

#### 4.7 MEMORY PARITY OPTION

IF PARITY MEMORY IS INSTALLED, MEMORY PARITY TRAPS ARE DISABLED BY THE PROGRAM.

#### 4.8 BAD SECTORS

THE LIST OF BAD SECTORS ON THE CARTRIDGE IS OBTAINED FROM THE FIRST DRIVE TO BE TESTED ON THE CURRENT SUBSYSTEM. ACCORDING TO A SWITCH REGISTER OPTION (SEE SECTION 6.2) THIS LIST MAY BE TYPED AT THE CONSOLE AT THE START OF THE FIRST PASS. AFTER READING THE BAD SECTOR FILE, THE PROGRAM SEARCHES THE LIST OF BAD SECTORS TO DETERMINE IF ANY BAD SPOTS EXIST IN ANY TEST AREAS ON THE DISK PACK. IF A BAD SPOT IS FOUND TO BE PRESENT IN ANY OF THE TEST AREAS, THE FOLLOWING MESSAGE WILL BE TYPED:

PACK IS NOT ACCEPTABLE, CHANGE PACK AND TRY AGAIN.

#### 4.9 EXECUTION TIME

THE TOTAL TIME REQUIRED TO RUN THE DRIVE COMPATIBILITY PROGRAM IS DIRECTLY PROPORTIONAL TO THE NUMBER OF DRIVES TO BE TESTED AND REQUIRES ABOUT 2 MINUTES PER RM03/2 DRIVE AND ABOUT 5 MINUTES PER RM05 DRIVE, NOT INCLUDING OPERATOR INTERVENTION.

#### 5.0 PROGRAM LOAD MEDIA

THIS PROGRAM CAN BE LOADED FROM PAPER TAPE USING THE ABSOLUTE LOADER OR FROM THE ACT OR APT SYSTEMS OR FROM ANY MEDIA SUPPORTED BY XXDP.

172  
173  
174  
175  
176  
177  
178  
179  
180  
181  
182  
183  
184  
185  
186  
187  
188  
189  
190  
191  
192  
193  
194  
195  
196  
197  
198  
199  
200  
201  
202  
203  
204  
205  
206  
207  
208  
209  
210  
211  
212  
213  
214  
215  
216  
217  
218  
219  
220  
221  
222  
223  
224  
225  
226  
227  
228

## 6.0 PROGRAM OPTIONS

### 6.1 STARTING ADDRESSES

- 200 - THIS IS THE STARTING ADDRESS FOR DEFAULT PARAMETERS AND RUNNING OF PASS 1 AND PASS 2 ON A SINGLE SUBSYSTEM. THE PROGRAM WILL USE DEFAULT RH/RM BASE ADDRESS, INTERRUPT VECTOR AND PRIORITY. THE PROGRAM WILL ASSUME ALL DRIVES TO BE TESTED RESIDE ON ONE RH/RM SUBSYSTEM ONLY.
- 204 - THIS IS THE STARTING ADDRESS TO RUN PASS 1 ON ALL RH/RM SUBSYSTEMS WHICH RESIDE ON THIS PDP-11 SYSTEM. THE PROGRAM WILL ASK FOR THE RH/RM BASE ADDRESS, INTERRUPT VECTOR, AND PRIORITY FOR EACH SUBSYSTEM ON THIS SYSTEM, AND IT ASKS FOR THE LETTER NAMES (A THRU H) ASSIGNED TO ALL OTHER SUBSYSTEMS, AND THE DRIVE(S) WHICH WILL BE TESTED ON EACH.
- 210 - THIS IS THE STARTING ADDRESS TO RUN PASS 2 ON ALL RH/RM SUBSYSTEMS WHICH RESIDE ON THIS PDP-11 SYSTEM. THE PROGRAM WILL ASK FOR THE RH/RM BASE ADDRESS, INTERRUPT VECTOR FOR EACH SUBSYSTEM ON THIS SYSTEM, AND IT ASKS FOR THE LETTER NAMES (A THRU H) ASSIGNED TO ALL OTHER SUBSYSTEMS, AND THE DRIVE(S) WHICH WILL BE TESTED ON EACH.

### 6.2 'SOFTWARE' SWITCH REGISTER

IF THE PROGRAM IS BEING RUN ON A SWITCHLESS PROCESSOR THE PROGRAM WILL DETERMINE THAT THE HARDWARE SWITCH REGISTER IS NOT PRESENT AND WILL USE A 'SOFTWARE' SWITCH REGISTER. THE 'SOFTWARE' SWITCH REGISTER IS LOCATED AT LOCATION 176 (8). THE SETTINGS OF THE 'SOFTWARE' SWITCHES ARE CONTROLLED THROUGH A KEYBOARD ROUTINE WHICH IS CALLED BY TYPING A 'CONTROL G'. THE PROGRAM WILL RECOGNIZE THE 'CONTROL G' AT ANY TIME EXCEPT WHEN THE PROGRAM IS AT A HIGHER PRIORITY PROCESSING AN RM80 INTERRUPT. THE 'SOFTWARE' SWITCH VALUES ARE ENTERED AS AN OCTAL NUMBER IN RESPONSE TO THE PROMPT FROM THE SWITCH ENTRY ROUTINE:

'SWR = NNNNNN NEW ='

EACH TIME SWITCH SETTING ARE ENTERED, THE ENTIRE SWITCH REGISTER IMAGE MUST BE ENTERED. LEADING ZEROS ARE NOT REQUIRED., 'RUBOUT' AND 'CONTROL U' FUNCTIONS MAY BE USED TO CORRECT TYPING ERRORS DURING SWITCH ENTRY.

ON PROCESSORS WITH HARDWARE SWITCH REGISTERS, THE 'SOFTWARE' SWITCH REGISTER MAY BE USED, IF THE PROGRAM FINDS ALL 1'S IN THE SWITCHES. ALL SWITCH REGISTER REFERENCES WILL BE TO THE 'SOFTWARE' REGISTER AND THE PROCEDURES DESCRIBED ABOVE MUST BE FOLLOWED.

### 6.3 OPERATIONAL SWITCH SETTINGS

WITH ALL SWITCHES SET TO ZERO, THE PROGRAM WILL TYPE ALL ERRORS AND CONTINUE TESTING.



229  
230  
231  
232  
233  
234  
235  
236  
237  
238  
239  
240  
241  
242  
243  
244  
245  
246  
247  
248  
249  
250  
251  
252  
253  
254  
255  
256  
257  
258  
259  
260  
261  
262  
263  
264  
265  
266  
267  
268  
269  
270  
271  
272  
273  
274  
275  
276  
277  
278  
279  
280  
281  
282  
283  
284  
285

THE SWITCH SETTINGS ARE:

BIT	OPTION
---	-----
15	HALT ON ERROR
14	LOOP ON CURRENT TEST
13	INHIBIT ERROR REPOPTS
12	REPORT DESCRIPTION ONLY, ON ERRORS
11	JNUSED
10	BELL ON ERROR
09	LOOP ON ERROR
08	APPLY RANDOM STALL BETWEEN OPERATIONS
07	TYPE BAD SECTOR FILES (BSF'S) AT START
06-00	UNUSED

## 7.0 RUNNING THE PROGRAM

ONCE THE PROGRAM HAS BEEN LOADED INTO CORE (IN A GIVEN SYSTEM, IF THERE ARE MULTIPLE SYSTEMS) THE FOLLOWING STEPS MUST BE TAKEN TO RUN THE PROGRAM:

1. INSURE THAT ALL DRIVES TO BE TESTED ARE POWERED UP AND SINGLE PORT SELECTED.
2. LOAD THE DESIRED START ADDRESS.
3. SET ANY DESIRED BITS IN THE HARDWARE SWITCH REGISTER (IF PRESENT).
4. START THE PROGRAM.
5. FOLLOW ALL INSTRUCTIONS TYPED BY THE PROGRAM PERTAINING TO THE MANUAL INTERVENTION REQUIRED, AND THE ALTERNATE USE OF MULTIPLE SYSTEMS (IF THERE ARE ANY).

## 8.0 OPERATIONAL DIALOGUE

THIS SECTION DESCRIBES THE CONSOLE TERMINAL DIALOGUE THROUGH WHICH THE PROGRAM DIRECTS THE OPERATOR, IN THE SELECTION OF OPTIONS AND THE LOADING AND UNLOADING OF DRIVES, AND THE MOVEMENT OF THE TEST CARTRIDGE. THE EXACT DIALOGUE WHICH IS USED DEPENDS UPON THE STARTING ADDRESS WHICH WAS CHOSEN (SEE SECTION 6.1).

IN THE FOLLOWING DISCUSSION AND IN THE PRINTOUT OF TEST RESULTS, DRIVES TO BE TESTED WILL BE REFERRED TO BY A LETTER AND A NUMBER. THE LETTER IS THE SUBSYSTEM LETTER NAME (OPERATOR ASSIGNED), AND THE NUMBER IS THE DRIVE NUMBER ON THAT SUBSYSTEM. FOR EXAMPLE, DRIVE C6 REFERS TO DRIVE 6 ON SUBSYSTEM C.

### 8.1 DIALOGUE FOR ADDRESS 200 START

286  
287  
288  
289  
290  
291  
292  
293  
294  
295  
296  
297  
298  
299  
300  
301  
302  
303  
304  
305  
306  
307  
308  
309  
310  
311  
312  
313  
314  
315  
316  
317  
318  
319  
320  
321  
322  
323  
324  
325  
326  
327  
328  
329  
330  
331  
332  
333  
334  
335  
336  
337  
338  
339  
340  
341  
342

THIS STARTING ADDRESS MAY BE USED FOR DEFAULTING PARAMETERS ON ONE SUB-SYSTEM.

THE PROGRAM FIRST IDENTIFIES ITSELF AS FOLLOWS:

CZRMTB0 - RM05/3/2 DRIVE COMPATIBILITY TEST

THEN, THE PROGRAM ASKS THE DRIVES TO BE TESTED.

THE PROGRAM TYPES THE DRIVE LIST, AS IN THE FOLLOWING EXAMPLE:

DRIVES = 2,5,7<CR>

THE PROGRAM NOW PROCEEDS WITH PASS 1, AND DIRECTS THE OPERATOR IN THE MOUNTING OF THE PACK, AS DESCRIBED IN SECTION 8.4.

PLEASE NOTE THAT THERE IS ONLY ONE SUBSYSTEM ON AN ADR. 200 START, AND IT IS NAMED SUBSYSTEM A. THE DRIVES IN THE ABOVE EXAMPLE WOULD BE REFERRED TO AS A2,A5,A7 IN THE TEST RESULTS PRINTOUT AT THE END OF PASS 2.

## 8.2 DIALOGUE FOR ADDRESS 204 START

THIS STARTING ADDRESS MUST BE USED ON EACH SYSTEM, WHEN THERE IS MORE THAN ONE SUBSYSTEM, BUT IT MAY ALSO BE USED WHEN THERE IS JUST ONE SUBSYSTEM (TOTAL), TO SPECIFY DRIVES TO TEST AND NON-DEFAULT PARAMETER VALUES, FOR PASS 1.

THE PROGRAM IDENTIFIES ITSELF AS FOLLOWS:

CZRMTB0 - RM05/3/2 DRIVE COMPATIBILITY TEST

THEN, THE PROGRAM ASKS THE OPERATOR FOR THE DRIVES TO BE TESTED ON EACH OF THE POSSIBLE SUBSYSTEMS (STARTING WITH A - THE NAMES RANGE FROM SUBSYS A TO SUBSYS H. THERE COULD BE UP TO 8 SUBSYSTEMS, WITH A DRIVE ON EACH):

SUBSYS A DRIVE(S) =

THE OPERATOR THEN TYPES THE DESIRED DRIVE NUMBERS, AS IN THE FOLLOWING EXAMPLE:

SUBSYS A DRIVE(S) = 2,5,7<CR>

THE PROGRAM THEN VERIFIES THE DRIVE NUMBERS BY TYPING:

WILL TEST DRIVE(S) 2,5,7 ON SUBSYS A.

NEXT, THE PROGRAM ASKS THE FOLLOWING QUESTION:

IS THERE ANOTHER SUBSYS (Y OR N)?

THE OPERATOR TYPES 'Y' OR 'N'. (IF JUST <CR> IS TYPED, THE PROGRAM ASSUMES THAT 'N' WAS TYPED). IF THE OPERATOR TYPED 'N', THE PROGRAM PROCEEDS WITH PASS 1, AND DIRECTS THE OPERATOR IN THE MOUNTING OF THE

343  
344  
345  
346  
347  
348  
349  
350  
351  
352  
353  
354  
355  
356  
357  
358  
359  
360  
361  
362  
363  
364  
365  
366  
367  
368  
369  
370  
371  
372  
373  
374  
375  
376  
377  
378  
379  
380  
381  
382  
383  
384  
385  
386  
387  
388  
389  
390  
391  
392  
393  
394  
395  
396  
397  
398  
399

PACK, AS DESCRIBED IN SECTION 8.4. IF 'Y' WAS TYPED, THE PROGRAM ASKS FOR THE NUMBERS OF THE DRIVES TO BE TESTED ON THE NEXT SUBSYSTEM (SUBSYS B) AS FOLLOWS:

SUBSYS B DRIVE(S) =

THE OPERATOR TYPES THE DRIVE NUMBERS, AS IN THE FOLLOWING EXAMPLE:

SUBSYS B DRIVE(S) = 2,3<CR>

THE PROGRAM THEN VERIFIES THE DRIVE NUMBERS. BY TYPING:

WILL TEST DRIVE(S) 2,3 ON SUBSYS B.

NEXT, THE PROGRAM WILL ASK:

IS THERE ANOTHER SUBSYS (Y OR N)?

AND IN THE SAME MANNER, THE OPERATOR SPECIFIES THE DRIVES ON EACH OF THE REMAINING SUBSYSTEMS, UNTIL ALL HAVE BEEN SPECIFIED.

ALL SUBSYSTEMS MUST BE TESTED IN THE ORDER IN WHICH THE LETTERS ARE ASSIGNED (A THRU H). NEXT, THE PROGRAM ALLOWS THE OPERATOR TO ALTER THE RH/RM BUS ADDRESS, VECTOR ADDRESS FOR THIS SUBSYSTEM. FOR EACH PARAMETER THE CURRENT VALUE IS TYPED, AND THE OPERATOR IS GIVEN THE OPPORTUNITY TO TYPE IN A NEW VALUE, PLUS <CR>. IF JUST <CR> IS TYPED, THE PARAMETER IS NOT CHANGED. WHEN THE PROGRAM IS FIRST LOADED, THE FOLLOWING DEFAULT VALUES ARE ASSIGNED: RH/RM BUS ADDRESS = 177670, VECTOR ADDRESS = 240, (IF 200 START). THE FOLLOWING EXAMPLE SHOWS A PRINTOUT IN WHICH BUS ADDRESS AND VECTOR WERE CHANGED:

```
RMCS1 = 000000 177670
RMVEC = 000 254
```

THEN THE PROGRAM PROCEEDS WITH PASS 1, AND DIRECTS THE OPERATOR IN THE MOUNTING OF THE PACK, AS DESCRIBED IN SECTION 8.4. AT THE COMPLETION OF PASS 1 ON THE SUBSYSTEM, THE PROGRAM WILL INFORM THE OPERATOR HOW TO PERFORM PASS 1 ON THE NEXT SUBSYSTEM.

### 8.3 DIALOGUE FOR ADDRESS 210 START

THIS STARTING ADDRESS MUST BE USED ON EACH SYSTEM, WHEN THERE IS MORE THAN 1 SUBSYSTEM, BUT IT MAY ALSO BE USED WHEN THERE IS JUST ONE SUBSYSTEM (TOTAL), TO SPECIFY DRIVES TO TEST AND NON-DEFAULT PARAMETER VALUES, FOR PASS 2. THE PROGRAM IDENTIFIES ITSELF, AS FOLLOWS:

CZRMTB0 - RM05/3/2 DRIVE COMPATIBILITY TEST

THE DIALOGUE FOR 210 START IS IDENTICAL TO THE DIALOGUE FOR THE 204 START DESCRIBED ABOVE (SECTION 8.2), FOR THE SELECTION OF SUBSYSTEM PARAMETERS AND THE SPECIFICATION OF ALL DRIVES TO BE TESTED ON THE VARIOUS SUBSYSTEMS. HOWEVER, AFTER THIS DIALOGUE IS COMPLETED, THE

400  
401  
402  
403  
404  
405  
406  
407  
408  
409  
410  
411  
412  
413  
414  
415  
416  
417  
418  
419  
420  
421  
422  
423  
424  
425  
426  
427  
428  
429  
430  
431  
432  
433  
434  
435  
436  
437  
438  
439  
440  
441  
442  
443  
444  
445  
446  
447  
448  
449  
450  
451  
452  
453  
454  
455  
456

PROGRAM PROCEEDS WITH PASS 2, AND DIRECTS THE OPERATOR IN THE MOVEMENT OF THE PACK, AS DESCRIBED IN SECTION 8.5.

NOTE THAT SINCE THE APPROPRIATE PROCESSOR MUST BE STARTED AT THE STARTING ADDRESS FOR EACH SUBSYSTEM TO BE TESTED, THE COMPATIBILITY TEST MAY BE PERFORMED IN STEPS, AT VARIOUS TIMES AND BETWEEN VARIOUS DISTANT LOCATIONS, BY MOVING THE TEST PACK AND SAVING THE PRINTOUT FROM EACH PASS ON EACH PDP-11 SYSTEM INVOLVED.

#### 8.4 PASS 1 DIALOGUE

AFTER THE SELECTION OF PARAMETERS AND DRIVES HAS BEEN COMPLETED ON THE CURRENT SUBSYSTEM (SECTIONS 8.1-8.2), THE PROGRAM INDICATES THE START OF PASS 1 AS FOLLOWS:

\*\* STARTING PASS 1 ON SUBSYS A

NOTE: THAT SUB-SYSTEM 'A' IS ALWAYS THE FIRST SUB-SYSTEM TO BE TESTED REGARDLESS OF HOW MANY SUB-SYSTEMS ARE TO BE TESTED.

NEXT, THE PROGRAM SELECTS THE FIRST DRIVE TO BE TESTED ON THIS SUBSYSTEM, AND INSTRUCTS THE OPERATOR TO MOUNT THE TEST CARTRIDGE AND LOAD THE HEADS ON THAT DRIVE, AS IN THE FOLLOWING EXAMPLE:

MOUNT PACK ON DRIVE A2 AND LOAD.  
TYPE <CR> WHEN DRIVE READY.

THE OPERATOR PERFORMS THIS TASK AND TYPES <CR> WHEN THE DRIVE IS READY. THE PROGRAM PERFORMS PASS 1 FUNCTIONS ON THIS DRIVE (SEE SECTION 9.1) AND THEN INSTRUCTS THE OPERATOR TO UNLOAD THE DRIVE AND REMOVE THE PACK AS FOLLOWS:

UNLOAD DRIVE A2 AND REMOVE PACK.  
TYPE <CR> WHEN DONE.

THE OPERATOR PERFORMS THESE FUNCTIONS AND TYPES <CR> AFTER THE PACK HAS BEEN REMOVED.

IN THE SAME MANNER, THE PROGRAM INSTRUCTS THE OPERATOR IN THE MOVEMENT OF THE PACK THROUGHOUT THE REST OF THE DRIVES ON THE CURRENT SUBSYSTEM. WHEN THIS HAS BEEN COMPLETED, THE PROGRAM DOES ONE OF THREE THINGS: (1) IF THERE IS ONLY ONE SUBSYSTEM (FROM ADR 200 START) THE PROGRAM BEGINS PASS 2 (SEE SECTION 8.5). (2) IF THERE IS ANOTHER SUBSYSTEM, THE PROGRAM DIRECTS THE OPERATOR TO PERFORM PASS 1 ON THE NEXT SUBSYS AS FOLLOWS:

\*\* STARTING PASS 1 ON SUBSYS B

(3) IF THERE ARE NO MORE DRIVES TO TEST IN PASS 1 ON ANY SUBSYS, THE PROGRAM DIRECTS THE OPERATOR TO BEGIN PASS 2 ON THE FIRST SUBSYS (SEE SECT. 8.5) AS FOLLOWS:

\*\* STARTING PASS 2 ON SUBSYS A

457  
458  
459  
460  
461  
462  
463  
464  
465  
466  
467  
468  
469  
470  
471  
472  
473  
474  
475  
476  
477  
478  
479  
480  
481  
482  
483  
484  
485  
486  
487  
488  
489  
490  
491  
492  
493  
494  
495  
496  
497  
498  
499  
500  
501  
502  
503  
504  
505  
506  
507  
508  
509  
510  
511  
512  
513

NOTE: THAT SUB-SYSTEM 'A' IS ALWAYS THE FIRST SUB-SYSTEM TO BE TESTED REGARDLESS OF HOW MANY SUB-SYSTEMS ARE TO BE TESTED.

#### 8.5 PASS 2 DIALOGUE

THE OPERATOR RETURNS TO THE FIRST SUBSYSTEM TO PERFORM PASS 2 EITHER THROUGH THE DIALOGUE OF THE ADR 200 START, OR AFTER THE SELECTION OF PARAMETERS AND DRIVES HAS BEEN COMPLETED IN ACCORDANCE WITH THE DIALOGUE OF THE ADR 210 START (SEE SECTION 8.3). IN EITHER CASE, THE PROGRAM INDICATES THE START OF PASS 2 BY TYPING:

\*\* STARTING PASS 2 ON SUBSYS A

THE PROGRAM THEN DIRECTS THE OPERATOR IN THE UNLOADING, PACK MOVEMENT, AND LOADING OF ALL DRIVES ON THE FIRST SUBSYSTEM, IN THE SAME MANNER AS DESCRIBED FOR PASS 1 (SEE SECTION 8.4).

HOWEVER, AFTER PASS 2 TESTING (SEE SECTION 9.2) IS COMPLETED ON A GIVEN DRIVE, THE ENTIRE TEST RESULTS FOR THAT DRIVE ARE TYPED. THE DETAILS OF THIS PRINTOUT ARE DESCRIBED IN SECTION 10, AFTER THE DETAILS OF THE TESTING ARE DESCRIBED.

WHEN PASS 2 HAS BEEN COMPLETED FOR ALL DRIVES ON THE FIRST SUBSYSTEM, THE PROGRAM DOES ONE OF TWO THINGS: (1) IF THERE IS ONLY ONE SUBSYSTEM (FROM ADR 200 START) OR IF ALL DRIVES ON ALL SUBSYSTEMS HAVE BEEN TESTED IN PASS 2 (FROM ADR 210 START), THE ENTIRE TESTING AND REPORTING HAVE BEEN COMPLETED, AND THE PROGRAM TYPES:

TEST COMPLETE  
\*\*\*\*\*

(2) IF THERE IS ANOTHER SUBSYSTEM, HOWEVER, THE PROGRAM DIRECTS THE OPERATOR TO PERFORM PASS 2 ON THE NEXT SUBSYSTEM AS FOLLOWS:

\*\* STARTING PASS 2 ON SUBSYS B

#### 9.0 DESCRIPTION OF TESTS

THE MAIN FUNCTIONAL BLOCKS OF CODE IN THE PROGRAM ARE ASSIGNED TEST NUMBERS, FOR THE PURPOSE OF IDENTIFICATION IN ERROR PRINTOUTS. TEST 0 REFERS TO THE OPERATOR INPUT DIALOGUE ROUTINES DESCRIBED IN SECTIONS 8.1-8.3. THE OTHER TEST NUMBERS ARE ASSIGNED BELOW, IN THE DESCRIPTION OF PASS 1 AND PASS 2 TESTING.

IN THE FOLLOWING SECTIONS, TABLES A-G ARE REFERRED TO. IN THESE TABLES, DRIVES ARE NAMED FROM 0-7 FOR ILLUSTRATIVE PURPOSES, ALTHOUGH THE DRIVES ARE NAMED THE FOLLOWING WAY IN AN ACTUAL SITUATION:

A0,A1, A2,...B0,B1,B2,...C0,C1,C2,... ETC. (SEE SECTION 8.0).

514  
515  
516  
517  
518  
519  
520  
521  
522  
523  
524  
525  
526  
527  
528  
529  
530  
531  
532  
533  
534  
535  
536  
537  
538  
539  
540  
541  
542  
543  
544  
545  
546  
547  
548  
549  
550  
551  
552  
553  
554  
555  
556  
557  
558  
559  
560  
561  
562  
563  
564  
565  
566  
567  
568  
569  
570

### 9.1 DESCRIPTION OF PASS 1 TESTS

IN PASS 1, THE BASIC READ/WRITE CAPABILITY OF EACH DRIVE IS DEMONSTRATED, AND COMPATIBILITY DATA PATTERNS ARE WRITTEN BY ALL DRIVES UPON THE SAME TEST CARTRIDGE.

THE SEQUENCE OF OPERATIONS PERFORMED ON EACH DRIVE IS AS FOLLOWS:

1. TEST 1 - MOUNTING OF TEST CARTRIDGE FOR PASS 1 - THE OPERATOR MOUNTS THE PACK ON THIS DRIVE AND MANUALLY LOADS THE HEADS, AS DIRECTED BY THE PROGRAM (SEE SECTION 8.4).
2. TEST 2 - BASIC READ/WRITE DATA TEST - THE PROGRAM PERFORMS A WRITE AND WRITE CHECK OPERATION USING A 'WORST CASE' DATA PATTERN, AT THE APPROPRIATE SECTOR FOR THIS DRIVE (SEE TABLE A) ON ALL SURFACES. THE PURPOSE OF THIS OPERATION IS TO VERIFY THE BASIC READ/WRITE CAPABILITY OF THE DRIVE ON PASS 1. THE ENTIRE SECTOR IS WRITTEN WITH THE REPETITION OF THE DATA PATTERN SHOWN IN TABLE B.
3. TEST 3 - THE PROGRAM WRITES ALL SECTORS FOR THIS DRIVE WITHIN THE CYLINDER BLOCKS SHOWN IN TABLE C ON ALL SURFACES USING A SINGLE REPEATED WORD OF THE PATTERN IN TABLE G. DRIVE 0 USES WORD 0, DRIVE 1 USES WORD 1, DRIVE 7 USES WORD 7, ETC. THUS, THE DATA FROM EACH DRIVE IS UNIQUE. TABLE C HAS BEEN DETERMINED AS FOLLOWS:

IN EACH OF THE SEVEN WRITE CURRENT ZONES ON EACH SURFACE, SECTORS ARE WRITTEN WITHIN TWO DISTINCT CYLINDER BLOCKS. THE FIRST 16 CYLINDERS OF EACH WRITE CURRENT ZONE IS THE FIRST BLOCK USED FOR WRITE TEST IN PASS 2. THE LAST 16 CYLINDERS OF EACH CURRENT ZONE (EXCEPT THE INNERMOST ZONE) IS THE SECOND BLOCK USED FOR READ TEST IN PASS 2. WITHIN EACH CURRENT ZONE, THESE TWO BLOCKS ARE IDENTICALLY WRITTEN. HOWEVER, THE SECTORS DESIGNATED TO EACH DRIVE ARE ROTATED FROM ZONE TO ZONE SO THAT THE DATA APPEARS AT VARIOUS ANGULAR POSITIONS ON THE PACK.

WITHIN EACH CYLINDER BLOCK, UP TO 32 SECTORS ARE WRITTEN (DEPENDING ON THE NUMBER OF DRIVES BEING TESTED) ON EACH CYLINDER.

THE BASIC LAYOUT OF A TYPICAL CYLINDER BLOCK IS SHOWN IN TABLE D, WHERE THE BLOCK SHOWN IS THE READ TEST BLOCK FOR ZONE 1, WHICH STARTS ON CYLINDER 112, AND HAS THE ROTATING STARTING SECTOR = SECTOR 0. EACH NUMBER INSIDE THE BLOCK IS THE NUMBER OF THE DRIVE WHICH WRITES THAT SECTOR. TABLE D SHOWS THE BLOCKS WRITTEN BY EACH OF 16 DRIVES. IF ANY OF THE DRIVES SHOWN ARE NOT PRESENT, HOWEVER, THE BLOCKS RESERVED FOR THE MISSING DRIVES ARE SIMPLY NOT WRITTEN.

THE ABOVE PATTERN OF SECTOR WRITES INSURES THAT DATA FROM EACH DRIVE IS WRITTEN ON ADJACENT CYLINDERS TO DATA FROM EVERY OTHER DRIVE, IN BOTH DIRECTIONS. IN ADDITION, THE ROTATION OF THE ABOVE SECTORS FROM CURRENT ZONE TO CURRENT

571  
572  
573  
574  
575  
576  
577  
578  
579  
580  
581  
582  
583  
584  
585  
586  
587  
588  
589  
590  
591  
592  
593  
594  
595  
596  
597  
598  
599  
600  
601  
602  
603  
604  
605  
606  
607  
608  
609  
610  
611  
612  
613  
614  
615  
616  
617  
618  
619  
620  
621  
622  
623  
624  
625  
626  
627

ZONE INSURES THAT WRITE TEST AND READ TEST ARE DONE AT SEVERAL DIFFERENT ANGULAR POSITIONS WITH RESPECT TO THE CARTRIDGE.

4. TEST 4 - DISMOUNTING OF TEST CARTRIDGE IN PASS 1 - THE OPERATOR UNLOADS THE DRIVE AND DISMOUNTS THE PACK, AS DIRECTED BY THE PROGRAM (SEE SECTION 8.4), TO PROCEED WITH THE ABOVE STEPS ON THE NEXT DRIVE.

## 9.2 DESCRIPTION OF PASS 2 TESTS

IN PASS 2, THE ABILITY OF EACH DRIVE TO COMPLETELY OVERWRITE DATA WRITTEN BY ALL OTHER DRIVES AND TO READ DATA WRITTEN BY ALL OTHER DRIVES, IS TESTED.

THE SEQUENCE OF OPERATIONS PERFORMED BY EACH DRIVE IS AS FOLLOWS:

1. TEST 5 - MOUNTING OF TEST CARTRIDGE FOR PASS 2 - THE OPERATOR MOUNTS THE PACK ON THIS DRIVE AND MANUALLY LOADS THE HEADS, AS DIRECTED BY THE PROGRAM (SEE SECTION 8.5).
2. TEST 6 - WRITE TEST - NEXT, THE PROGRAM PROCEEDS TO TEST THIS DRIVE'S OVERWRITE CAPABILITY. FIRST, THE APPROPRIATE CYLINDERS IN TABLE E FOR THIS DRIVE ARE OVERWRITTEN, ON EACH SURFACE. THE DATA USED IS A REPETITION OF A SINGLE WORD OF THE PATTERN IN TABLE G, DRIVE 0 USES WORD 0, DRIVE 1 USES WORD 1, DRIVE 7 USES WORD 7, ETC.

THEN, EACH CYLINDER OVERWRITTEN IS READ BACK BY THIS DRIVE IN EACH OFFSET DIRECTION (+ AND -). THE PROGRAM SCANS FOR READ ERRORS (DCK, HCRC, ETC.) DURING THIS READ, AND IF ONE OCCURS, THE PROGRAM DETERMINES WHICH DRIVE'S DATA HAS NOT BEEN CORRECTLY OVERWRITTEN, AND A SCORE FOR THAT DRIVE IS DECREMENTED. THEN, THE TRANSFER IS CONTINUED AT THE NEXT SECTOR, WITH THAT OFFSET VALUE. THE READS ARE DONE WITH ALL OF THE ABOVE OFFSETS APPLIED, AND A SEPARATE SCORE FOR EACH DRIVE IS KEPT, WHILE THE CURRENT DRIVE IS PERFORMING THE OVERWRITES. FOR EACH TRACK, SCORES ARE AVERAGED OVER ALL CYLS TESTED, IN EACH OFFSET DIRECTION. AT THE COMPLETION OF THE OVERWRITE TEST ON THIS DRIVE, THE SCORES OF ALL THE DRIVES ARE CONVERTED AND STORED, FOR PRINTING AT THE END OF PASS 2 (AS DESCRIBED IN SECTION 10.2). EACH SCORE PROPORTIONAL TO THE OFFSET IN A GIVEN DIRECTION BY THE CURRENT DRIVE WHILE

SUCCESSFULLY READING THE DATA IT WROTE OVER ONE OF THE OTHER DRIVE'S DATA. THUS, THE PRINTOUT REVEALS WHICH DRIVES ARE INVOLVED, IN A SITUATION IN WHICH A DRIVE CANNOT OVERWRITE ONE OR SEVERAL OTHER DRIVE'S DATA.

3. TEST 7 - DRIVE SELF-TEST - THE PROGRAM NEXT EVALUATES THE DRIVE'S ABILITY TO WRITE AND READ ITS OWN DATA, AT VARIOUS POSITIONS ON THE PACK. FIRST, ALL SECTORS OF THE APPROPRIATE CYLINDERS SHOWN IN TABLE F FOR THIS DRIVE ARE WRITTEN WITH THE DATA PATTERN SHOWN IN TABLE B, FOR ALL SURFACES. THEN, THE SECTORS ARE READ WITH OFFSET

628  
629  
630  
631  
632  
633  
634  
635  
636  
637  
638  
639  
640  
641  
642  
643  
644  
645  
646  
647  
648  
649  
650  
651  
652  
653  
654  
655  
656  
657  
658  
659  
660  
661  
662  
663  
664  
665  
666  
667  
668  
669  
670  
671  
672  
673  
674  
675  
676  
677  
678  
679  
680  
681  
682  
683  
684

IN EACH DIRECTION.  
THE PROGRAM SCANS FOR READ ERRORS DURING EACH READ, AND IT COMPUTES A SCORE WHICH IS PROPORTIONAL TO THE FAILING OFFSET. THEN, THE SCORES FOR ALL SECTORS READ IN THIS CYLINDER BLOCK ARE AVERAGED, TO COME UP WITH A DRIVE SELF-TEST SCORE FOR EACH SURFACE FOR EACH OFFSET DIRECTION. THIS SCORE IS SAVED FOR LATER USE, TO BECOME THE STANDARD FOR THE READS WHICH ARE TO FOLLOW.

- 4. TEST 10(OCTAL) - COMPATIBILITY DATA READ TEST - HAVING ESTABLISHED A SELF-TEST SCORE FOR THIS DRIVE, THE PROGRAM PROCEEDS TO PERFORM THE COMPATIBILITY DATA READS OF THE PATTERNS WRITTEN BY ALL THE DRIVES IN EACH CYLINDER BLOCK (ON EACH SURFACE). EACH COMPATIBILITY CYLINDER BLOCK SHOWN IN TABLE C IS READ, A CYLINDER AT A TIME IN EACH OFFSET DIRECTION. THE PROGRAM SCANS FOR READ ERRORS DURING EACH READ AND IF ONE OCCURS, THE PROGRAM DETERMINES WHICH DRIVE'S DATA WAS BEING READ AT THAT INSTANT AND A SCORE FOR THAT DRIVE IS DECREMENTED. THEN, THE TRANSFER IS CONTINUED AT THE NEXT SECTOR, WITH THAT OFFSET VALUE. THE READS ARE DONE WITH OFFSETS IN EACH DIRECTION. AND A SEPARATE SCORE FOR EACH DRIVE IS KEPT, WHILE THE CURRENT DRIVE IS READING THE COMPATIBILITY DATA. THEN, EACH SCORE IS APPROPRIATELY ADJUSTED TO REFLECT THE SELF-TEST SCORE FOR THE CURRENT DRIVE AT THAT PARTICULAR CYLINDER BLOCK. THE SCORES ARE THEN AVERAGED OVER ALL CYLINDER BLOCKS. EACH SCORE IS PROPORTIONAL TO THE CAPABILITY OF THE CURRENT DRIVE TO SUCCESSFULLY READ THE DATA WRITTEN BY ONE OF THE OTHER DRIVES, AND SCORES ARE COMPUTED SEPARATELY FOR EACH SURFACE (TRACK), FOR EACH OFFSET DIRECTION. THUS, THE PRINTOUT REVEALS WHICH DRIVES ARE INVOLVED IN A SITUATION IN WHICH A PARTICULAR DRIVE HAS DIFFICULTY IN READING THE DATA OF ONE OR SEVERAL OTHER DRIVES.
- 5. TEST 11(OCTAL) - TYPE TEST SCORES AND DISMOUNT PACK IN PASS 2 - THE OVERWRITE AND COMPATIBILITY DATA READ TEST SCORES FOR THIS DRIVE ARE CONVERTED AND TYPED. THEN, THE OPERATOR UNLOADS THE DRIVE AND DISMOUNTS THE PACK AS DIRECTED BY THE PROGRAM (SEE SECTION 8.5), TO PROCEED WITH THE ABOVE STEPS ON THE NEXT DRIVE.

### 10.0 PRINTOUT OF TEST RESULTS

THE TEST RESULTS ARE PRINTED AT THE END OF PASS 2 ON EACH DRIVE BEING TESTED. THESE RESULTS PERTAIN TO THE OVERWRITE TEST AND THE COMPATIBILITY DATA READ TEST.

### 10.1 TEST RESULTS

THE RESULTS OF BOTH THE OVERWRITE AND OF THE COMPATIBILITY DATA READ ARE PRINTED, REGARD OF DEGREE OF SUCCESS. IF THE TEST IS SUCCESSFUL, THE MESSAGES:



685  
686  
687  
688  
689  
690  
691  
692  
693  
694  
695  
696  
697  
698  
699  
700  
701  
702  
703  
704  
705  
706  
707  
708  
709  
710  
711  
712  
713  
714  
715  
716  
717  
718  
719  
720  
721  
722  
723  
724  
725  
726  
727  
728  
729  
730  
731  
732  
733  
734  
735  
736  
737  
738  
739  
740  
741

\*\* ALL DRIVES ARE COMPATIBLE \*\*

IS PRINTED. IF THE TEST IS FAILURE, THE TEST RESULTS ARE TABULAR IN FORM AS SHOWN.

IN THE FOLLOWING EXAMPLE, THERE ARE 2 SYSTEMS, AND THE DRIVES BEING TESTED ARE A0,A1,A2,B0, AND B5. THE TEST RESULTS FOR DRIVE A1 ARE SHOWN BELOW:

SCORES FOR DRIVE A1:

TRACK NO.	DRIVE READ	OVRWRT OFST-	OVRWRT OFST+	READ OFST-	READ OFST+
0	A2	* 0	* 0		

THE ABOVE EXAMPLE REVEALS A POSSIBLE COMPATIBILITY PROBLEM EXISTS BETWEEN DRIVES A1 AND A2. NOTICE THAT ON TRACK 0, THAT THE OVERWRITE SCORES WERE UNACCEPTABLY LOW (0), AND THE PROGRAM NOTED THESE BAD SCORES WITH AN ASTERISK (\*). ALL ACCEPTABLE TEST RESULTS ARE NOT PRINTED.

11.0 ERROR REPORTING

11.1 COMMON ERRORS

THE FOLLOWING IS A LIST OF COMMON ERROR MESSAGES WHICH ACCOMPANY ERROR TYPEOUTS FROM THE RM05/3/2 DRIVE COMPATIBILITY PROGRAM. THE ERRORS ARE SELF-EXPLANATORY.

- ADDRESS PLUG CHANGE BIT SET
- RH DIDN'T RESPOND TO ADDRESSING
- UNCORRECTABLE MASSBUS PARITY ERROR
- FATAL MASSBUS PARITY ERROR
- PERSISTENT DEVICE UNSAFE
- OPERATION NOT COMPLETED WITHIN TIME LIMIT
- DRIVE WENT OFFLINE
- NO RESPONSE TO PORT REQUEST
- HEADER CRC ERROR
- DATA CHECK 'DCK' ERROR
- WRITE CHECK ERROR - DATA CHECK 'DCK' SET
- WRITE CHCKE ERROR - DATA CHECK 'DCK' NOT SET
- HEADER READ ERROR - 'FMT' BIT DROPPED

742	HEADER READ ERROR - HEADER COMPARE 'HCE' ERROR
743	
744	FORMAT ERROR 'FER'
745	
746	HEADER COMPARE 'HCE' ERROR
747	
748	MISCELLANEOUS DRIVE ERROR
749	
750	OPERATION INCOMPLETE 'OPI' ERROR
751	
752	DRIVE TIMING 'DTE' ERROR
753	
754	PARITY 'PAR' ERROR AFTER OPERATION STARTED
755	
756	WRITE CLOCK FAILURE 'WCF' ERROR
757	
758	INVALID ADDRESS 'IAE' ERROR
759	
760	WRITE LOCK 'WLE' ERROR
761	
762	DATA CHECK 'DCK' SET DURING WRITE CHECK COMMAND
763	
764	RH OR UNIBUS TRANSFER ERROR
765	
766	BUS ADDRESS OR WORD COUNT INCORRECT
767	
768	DATA COMPARE ERRORS - NO OTHER ERROR(S) DETECTED
769	
770	CAN'T MATCH DATA READ WITH A PATTERN
771	
772	ERROR BIT(S) SET, BUT NO ERROR SIGNALLED BY THE RH
773	
774	ECC LOGIC FAILURE - POSITION REGISTER VALUE NOT VALID
775	
776	BUS ADDRESS AND WORD COUNT NOT CONSISTENT
777	
778	SEEK INCOMPLETE 'SKI' ERROR
779	
780	PROGRAM DETECTED POSITIONING ERROR
781	
782	DRIVE UNSAFE ERROR

## 785 11.2 ERROR HANDLING

787 ERRORS REPORTED BY THE PROGRAM CONSIST OF COMMON FAILURES RESULTING  
 788 FROM ATTEMPTED SUBSYSTEM FUNCTIONS, AS WELL AS CERTAIN ERRORS UNIQUE  
 789 TO PARTICULAR TESTS. EACH ERROR PRINTOUT CONSISTS OF AN ERROR  
 790 DESCRIPTION AND TEST NUMBER, POSSIBLY FOLLOWED BY HEADER LINES, COLUMN  
 791 HEADINGS, AND COLUMNS OF REGISTER CONTENTS IN OCTAL. AS MUCH  
 792 MEANINGFUL REGISTER DATA AS POSSIBLE (FOR EXAMPLE, RH/RM REGISTERS,  
 793 ARE REPORTED IN A GIVEN ERROR. OTHER ERROR REPORTS MAY CONSIST OF A  
 794 SINGLE DESCRIPTIVE LINE.

## 798 11.3 ERROR PRINTOUT EXAMPLE

799  
800  
801  
802  
803  
804  
805  
806  
807  
808  
809  
810  
811  
812  
813  
814  
815  
816  
817  
818  
819  
820  
821  
822  
823  
824  
825  
826  
827  
828  
829  
830  
831  
832  
833  
834  
835  
836  
837  
838  
839  
840  
841  
842  
843  
844  
845  
846  
847  
848  
849  
850  
851  
852  
853  
854  
855

RH OR UNIBUS TRANSFER ERROR  
 DRIVE RMCS1 RMWC RMBA RMDA  
 000001 144250 174400 0055030 000431

RMCS2 RMD5 RMER1 RMAS RMDB  
 000100 010700 000000 000000 000000

RMMR1 RMDT RMOF RMDC RMMR2  
 000050 024024 010000 000716 011777

RMER2 RMEC1 RMEC2  
 000000 004066 000000

12.0 TABLE DESCRIPTIONS

12.1 TABLE A - BASIC READ/WRITE TEST SECTORS

ADDRESS OF SECTOR ON EACH SURFACE

DRIVE NO.	CYLINDER	SECTORS
0	620	0
1	620	1
2	620	2
3	620	3
4	620	4
5	620	5
6	620	6
7	620	7
8	620	8
9	620	9
10	620	10
11	620	11
12	620	12
13	620	13
14	620	14
15	620	15

12.2 TABLE B - WORST CASE DATA PATTERN (REPEATS EVERY 16 WORDS)

WORD NO.	DATA (OCTAL)
0	066666
1	155554
2	133331
3	066663
4	155546
5	133315

856  
857  
858  
859  
860  
861  
862  
863  
864  
865  
866  
867  
868  
869  
870  
871  
872  
873  
874  
875  
876  
877  
878  
879  
880  
881  
882  
883  
884  
885  
886  
887  
888  
889  
890  
891  
892  
893  
894  
895  
896  
897  
898  
899  
900  
901  
902  
903  
904  
905  
906  
907  
908  
909  
910  
911  
912

6 066633  
7 155466  
8 133155  
9 066333  
10 154666  
11 131555  
12 063333  
13 146666  
14 115555  
15 033333

12.3 TABLE C - CYLINDER BLOCK ASSIGNMENT FOR A GIVEN SURFACE

CURRENT ZONE - RANGE	OVERWRITE CYL BLOCK RANGE	COMPATIBILITY CYL BLOCK RANGE
1 - CYL 0-127	CYL 0-15	CYL 112-127
2 - 128-255	128-143	240-255
3 - 256-383	256-271	368-383
4 - 384-511	384-399	496-511
5 - 512-639	512-527	624-639
6 - 640-767	640-655	752-767
7 - 768-822	768-783	---

12.4 TABLE D - BASIC CYLINDER BLOCK LAYOUT EXAMPLE

CYLINDER NUMBERS	SECTOR NUMBERS															
	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
112	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15 ->
113	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	0 ->
114	3	4	5	6	7	8	9	10	11	12	13	14	15	0	1	2 ->
115	6	7	8	9	10	11	12	13	14	15	0	1	2	3	4	5 ->
116	10	11	12	13	14	15	0	1	2	3	4	5	6	7	8	9 ->
117	15	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14 ->
118	5	6	7	8	9	10	11	12	13	14	15	0	1	2	3	4 ->
119	12	13	14	15	0	1	2	3	4	5	6	7	8	9	10	11 ->
120	4	5	6	7	8	9	10	11	12	13	14	15	0	1	2	3 ->
121	13	14	15	0	1	2	3	4	5	6	7	8	9	10	11	12 ->
122	7	8	9	10	11	12	13	14	15	0	1	2	3	4	5	6 ->
123	2	3	4	5	6	7	8	9	10	11	12	13	14	15	0	1 ->
124	14	15	0	1	2	3	4	5	6	7	8	9	10	11	12	13 ->
125	11	12	13	14	15	0	1	2	3	4	5	6	7	8	9	10 ->
126	9	10	11	12	13	14	15	0	1	2	3	4	5	6	7	8 ->
127	8	9	10	11	12	13	14	15	0	1	2	3	4	5	6	7 ->
	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31

913	->	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
914	->	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	0
915	->	3	4	5	6	7	8	9	10	11	12	13	14	15	0	1	2
916	->	6	7	8	9	10	11	12	13	14	15	0	1	2	3	4	5
917	->	10	11	12	13	14	15	0	1	2	3	4	5	6	7	8	9
918	->	15	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14
919	->	5	6	7	8	9	10	11	12	13	14	15	0	1	2	3	4
920	->	12	13	14	15	0	1	2	3	4	5	6	7	8	9	10	11
921	->	4	5	6	7	8	9	10	11	12	13	14	15	0	1	2	3
922	->	13	14	15	0	1	2	3	4	5	6	7	8	9	10	11	12
923	->	7	8	9	10	11	12	13	14	15	0	1	2	3	4	5	6
924	->	2	3	4	5	6	7	8	9	10	11	12	13	14	15	0	1
925	->	14	15	0	1	2	3	4	5	6	7	8	9	10	11	12	13
926	->	11	12	13	14	15	0	1	2	3	4	5	6	7	8	9	10
927	->	9	10	11	12	13	14	15	0	1	2	3	4	5	6	7	8
928	->	8	9	10	11	12	13	14	15	0	1	2	3	4	5	6	7

12.5 TABLE E - OVERWRITE CYLINDERS

DRIVE #	CYLINDERS OVERWRITTEN
0	0,128,256,384,512,640,768
1	1,129,257,385,513,641,769
2	2,130,258,386,514,642,770
3	3,131,259,387,515,643,771
4	4,132,260,388,516,644,772
5	5,133,261,389,517,645,773
6	6,134,262,390,518,646,774
7	7,135,263,391,519,647,775
8	8,136,264,392,520,648,776
9	9,137,265,393,521,649,777
10	10,138,266,394,522,650,778
11	11,139,267,395,523,651,779
12	12,140,268,396,524,652,780
13	13,141,269,397,525,653,781
14	14,142,270,398,526,654,782
15	15,143,271,399,527,655,783

12.6 TABLE F - SELF-TEST CYLINDERS

DRIVE #	CYLINDERS
0	17,145,273,401,529,657,785
1	18,146,274,402,530,658,786
2	19,147,275,403,531,659,787
3	20,148,276,404,532,660,788
4	21,149,277,405,533,661,789
5	22,150,278,406,534,662,790
6	23,151,279,407,535,663,791
7	24,152,280,408,536,664,792
8	25,153,281,409,537,665,793
9	26,154,282,410,538,666,794
10	27,155,283,411,539,667,795

913  
914  
915  
916  
917  
918  
919  
920  
921  
922  
923  
924  
925  
926  
927  
928  
929  
930  
931  
932  
933  
934  
935  
936  
937  
938  
939  
940  
941  
942  
943  
944  
945  
946  
947  
948  
949  
950  
951  
952  
953  
954  
955  
956  
957  
958  
959  
960  
961  
962  
963  
964  
965  
966  
967  
968  
969

970  
971  
972  
973  
974  
975  
976  
977  
978  
979  
980  
981  
982  
983  
984  
985  
986  
987  
988  
989  
990  
991  
992  
993  
994  
995  
996  
997  
998  
999  
1000  
1001  
1002  
1003  
1004  
1005  
1006  
1007  
1008  
1009  
1010  
1011  
1012  
1013  
1014  
1015  
1016  
1017  
1018  
1019  
1020  
1021  
1022  
1023  
1024  
1025  
1026

11 28,156,284,412,540,668,796  
12 29,157,285,413,541,669,797  
13 30,158,286,414,542,670,798  
14 31,159,287,415,543,671,799  
15 32,160,288,416,544,672,800

12.8 TABLE G - PSEUDO-RANDOM DATA PATTERN

WORD #	DATA (OCTAL)
0	040135
1	177070
2	070414
3	064531
4	174473
5	062422
6	114352
7	036620
8	010031
9	052336
10	017310
11	011347
12	102367
13	152567
14	001246
15	160073

13.0 RM SOFTWARE DRIVER DOCUMENT

THIS DOCUMENT IS THE USER'S GUIDE FOR THE RM DRIVER.

13.1 TO INITIALIZE THE DRIVER:

```

JSR   PC,RMINIT
RETURN

```

UPON RETURN YOU MUST EXAMINE THE 'DRVSTA' TABLE TO DETERMINE THE DRIVES THAT ARE ONLINE FOR TESTING. THE 'DRVSTA' TABLE IS EIGHT BYTES; ONE BYTE PER DRIVE. THE STATE OF EACH DRIVE WILL BE INDICATED AS FOLLOWS:

DRVSTA	DRIVE STATE
>0	ONLINE
=0	OFFLINE, DRIVE IS NOT AN RM05/3/2, OR NONEXISTENT DRIVE
<0	UNSAFE

THE DRIVE TYPE IS DEFINED IN AN 8 BYTE LONG TABLE TAGGED 'DRVTYP'. THE TABLE CONTAINS ONE BYTE FOR EACH DRIVE AND IS INDEXED BY THE DRIVE NUMBER. ENTRIES ARE ENCODED AS FOLLOWS:

1027  
1028  
1029  
1030  
1031  
1032  
1033  
1034  
1035  
1036  
1037  
1038  
1039  
1040  
1041  
1042  
1043  
1044  
1045  
1046  
1047  
1048  
1049  
1050  
1051  
1052  
1053  
1054  
1055  
1056  
1057  
1058  
1059  
1060  
1061  
1062  
1063  
1064  
1065  
1066  
1067  
1068  
1069  
1070  
1071  
1072  
1073  
1074  
1075  
1076  
1077  
1078  
1079  
1080  
1081  
1082  
1083

DRV TYP	CONDITION
0	NONEXISTENT DRIVE
5	RM02
4	RM03
7	RM05
-1	NOT AN RM05/3/2

THE 'RMINIT' ROUTINE WILL DO A READIN PRESET AND WILL SET FMT16.

13.2 AFTER THE DRIVER HAS BEEN INITIALIZED, IT IS CALLED USING THE FOLLOWING SEQUENCE.

CALL:

JSR	RO, RM05	:MAKE THE CALL
PNTDPB		:ADDRESS OF DPB*
RETURN1		:RETURN IF QUEUE IS FULL
RETURN2		:RETURN IF REQUEST IS IN
		:QUEUE OR THERE IS AN
		:ERROR CONDITION

\*DPB (DATA PARAMETER BLOCK)

PNTDPB:	.BYTE	0	:(0) DRIVE NUMBER
	.BYTE	0	:(1) OFFSET VALUE OR FMT16, ECT, AND HCI
	.BYTE	0	:(2) COMMAND
	.BYTE	0	:(3) PSEL AND A17 AND A16
	.WORD	0	:(4) WORD COUNT (MUST BE NEG.)
	.WORD	0	:(6) BUFFER ADDRESS OR
			:REGISTER TABLE POINTER
	.BYTE	0	:(10) SECTOR ADDRESS OR
			:FIRST REG. INDEX
	.BYTE	0	:(11) TRACK ADDRESS OR
			:LAST REG. INDEX
	.WORD	0	:(12) CYLINDER ADDRESS
	.WORD	0	:(14) ERROR TABLE POINTER
			:POINTS TO THE FIRST OF TWENTY
			:LOCATIONS OF WHERE THE DRIVER
			:IS TO STORE THE RH/RM
			:REGISTERS ON AN ERROR. IF LEFT
			:ZERO REGISTERS ARE NOT SAVED.
	.WORD	0	:(16) STATUS/ERROR INDICATOR
			:BIT15=1=>ERROR OCCURRED
			:BIT07=1=>DONE
			:BIT14-BIT09 AND BIT06-BIT03
			:INDICATE TYPE OF ERROR

13.3 THE DRIVER PROVIDES A SOFTWARE TIMEOUT CAPABILITY. TO UTILIZE THIS CAPABILITY YOU MUST SUPPLY THE 'RM TIMER' ROUTINE WITH THE ELAPSED TIME IN THE FOLLOWING MANNER:

MOV	#16., -(SP)	:16 MILLISECONDS BETWEEN
		:CLOCK TICKS
JSR	PC, RMTMR	:CALL THE TIMER ROUTINE

1084  
1085  
1086  
1087  
1088  
1089  
1090  
1091  
1092  
1093  
1094  
1095  
1096  
1097  
1098  
1099  
1100  
1101  
1102  
1103  
1104  
1105  
1106  
1107  
1108  
1109  
1110  
1111  
1112  
1113  
1114  
1115  
1116  
1117  
1118  
1119  
1120  
1121  
1122  
1123  
1124  
1125  
1126  
1127  
1128  
1129  
1130  
1131  
1132  
1133  
1134  
1135  
1136  
1137  
1138  
1139  
1140

IT SHOULD BE NOTED THAT YOU MUST PROVIDE THE CODE TO DRIVE THE CLOCK. AND THE ELAPSED TIME MUST BE IN MILLISECONDS. THE DRIVER WILL SET THE TIMEOUT TO 1 SECOND FOR ALL POSITIONING AND DATA TRANSFER OPERATIONS AND WILL SET THE TIMEOUT TO 30 SECONDS FOR ERROR RECOVERY OPERATIONS.

#### 13.4 EXAMPLE - WRITE 1000. WORDS

```
1$: JSR    RO,RM05      ;CALL THE DRIVER
    WRDPB      ;DPB ADDRESS
    BR      1$         ;WAIT FOR QUEUE IF FULL
2$: TST    WRDPB+16    ;WAIT FOR COMMAND TO COMPLETE
    BEQ    2$
    BMI    ERROR1     ;ERROR OCCURRED
    .
    .
    .
```

```
WRDPB: .BYTE  5      ;DRIVE #5
       .BYTE  0
       .BYTE 161    ;WRITE COMMAND
       .BYTE  0
       .WORD -1000. ;WORD COUNT
       .WORD  WRBUF ;BUFFER ADDRESS
       .BYTE  3     ;SECTOR
       .BYTE  5     ;TRACK
       .WORD  400   ;CYLINDER
       .WORD  ERRTB5 ;ERROR TABLE
       .WORD   0    ;STATUS/ERROR INDICATOR
```

#### ALTERNATE DPB SETUP

```
WRDPB: .WORD  5      ;THIS SETUP ACHIEVED
       .WORD  WRITE  ;EVERYTHING THE
       .WORD -1000.  ;ABOVE TABLE DID, BUT
       .WORD  WRBUF  ;IN A CLEANER FORMAT
       .BYTE  3,5
       .WORD  400,ERRTB5,0
```

#### 13.5 RH/RM REGISTERS

MNEMONIC	INDEX
-----	-----
RMCS1	0
RMWC	2
RMBA	4
RMDA	6
RMCS2	10
RMDS	12
RMER1	14
RMAS	16
RMLA	20
RMDB	22
RMMR1	24
RMDT	26



1141	RMSN	30
1142	RMOF	32
1143	RMDC	34
1144	RMHR	36
1145	RMMR2	40
1146	RMER2	42
1147	RMEC1	44
1148	RMEC2	46

13.6 COMMANDS PERFORMED BY THE DRIVER

	COMMAND -----	CODE ----	COMMAND TYPE -----
1151			
1152			
1153			
1154			
1155	SEEK	105	P
1156	RECALIRATE	107	P
1157	DRIVE CLEAR	111	N
1158	RELEASE	113	N
1159	OFFSET	115	P
1160	RETURN TO CENTER	117	P
1161	READIN PRESET	121	N
1162	PACK ACKNOWLEDGE	123	N
1163	SEARCH	131	P
1164	GET REGISTER(S)	141	S
1165	SET FORMAT	143	S
1166	SELECT DRIVE	145	S
1167	WRITE CHECK DATA	151	D
1168	WRITE CHK HEADER & DATA	153	D
1169	WRITE DATA	161	D
1170	WRITE HEADER & DATA	163	D
1171	READ DATA	171	D
1172	READ HEADER & DATA	173	D
1173			
1174			

N = HOUSEKEEPING  
P = POSITIONING  
D = DATA TRANSFER  
S = SPECIAL PROVIDED BY THE DRIVER

13.7 DPB STATUS/ERROR INDICATOR WORD

THIS INDICATOR WILL INFORM THE USER OF THE RESULTS OF THE REQUEST. THIS IS ACCOMPLISHED BY SETTING VARIES BITS OF THE INDICATOR TO A ONE.

	BIT NO. -----	MEANING IF ON A '1' -----
1175		
1176		
1177		
1178		
1179		
1180		
1181		
1182		
1183		
1184		
1185		
1186		
1187		
1188		
1189	15	ERROR OCCURRED DONE (BIT07=0); BITS 14-9 SPECIFIES TYPE DONE (BIT07=1); BITS 6-3 SPECIFIES TYPE
1190		
1191		
1192		
1193	14(1)	USER MADE A REQUEST FOR A FUNCTION TO BE PERFORMED ON AN OFFLINE OR UNSAFE DRIVE
1194		
1195		
1196	13(1)	USER MADE A REQUEST FOR A FUNCTION TO BE PERFORMED ON A DRIVE THAT HAS AN
1197		

1198		UNLOAD REQUEST IN QUEUE.
1199		
1200	12(2)	PERSISTENT UNSAFE CONDITION EXIST.
1201		
1202	11(2)	UNCORRECTABLE PARITY ERROR OCCURRED
1203		
1204	10(2)(4)	FATAL PARITY ERROR. A MASSBUS CLEAR WAS PERFORMED, ALL QUEUES WERE EMPTIED, AND ALL DRVACT'S SET TO THE IDLE STATE
1205		
1206		
1207		
1208	9(3)(4)	SOFTWARE TIMEOUT OCCURRED ON THIS DRIVE
1209		
1210	8(4)	SOFTWARE TIMEOUT OCCURRED ON ANOTHER DRIVE
1211		
1212	7	DONE
1213		
1214	6(2)	ERROR OCCURRED DURING AN I/O OPERATION
1215		
1216	5(2)	ERROR OCCURRED DURING AN OPERATION OTHER THAN I/O.
1217		
1218		
1219	4(2)	CORRECTABLE UNSAFE CONDITION OCCURRED
1220		
1221	3(2)	DRIVE ERROR OCCURRED THAT CAUSED AN AUTOMATIC 'RECALIBRATE' SEQUENCE
1222		
1223		
1224	2	PORT REQUEST TIMEOUT. THE DRIVER REQUESTED THE DRIVE BUT THE OPPOSITE PORT DID NOT RELEASE THE DRIVE WITHIN 15. SECONDS.
1225		
1226		
1227		
1228	1	NON-EXISTENT DRIVE REQUESTED. USER MADE A REQUEST FOR A NON-EXISTENT DRIVE.
1229		
1230		

-----  
 NOTES FOR ABOVE  
 -----

1231	(1) =	REQUEST WASN'T PUT IN QUEUE. (RH/RM REGISTERS WERE NOT SAVED)
1232		
1233	(2) =	REQUEST QUEUE HAS BEEN EMPTIED. THE DRIVER ISSUED A 'DRIVE CLEAR' TO THE DRIVE. NOTE: ALL RH/RM REGISTERS ARE SAVED AS PER DPB+14 BEFORE THE 'DRIVE CLEAR'.
1234		
1235	(3) =	REQUEST QUEUE HAS BEEN EMPTIED. THE DRIVER ISSUED A MASSBUS INIT. ALL RH/RM REGISTERS FOR THE DRIVE WERE SAVED AS PER DPB+14 BEFORE THE INIT.
1236		
1237	(4) =	A 'RECALIBRATE' SHOULD BE ISSUED BEFORE ANY OTHER COMMAND.
1238		
1239		
1240		
1241		
1242		
1243		
1244		
1245		
1246		
1247		
1248		
1249		

13.8 ERROR CALLS MADE BY THE DRIVER.  
 THERE ARE A FEW ERRORS THAT CAN OCCUR THAT CAN NOT BE INDICATED IN A DPB.

1250  
 1251  
 1252  
 1253  
 1254

1255  
1256  
1257  
1258  
1259  
1260  
1261  
1262  
1263  
1264  
1265  
1266  
1267  
1268  
1269  
1270  
1271  
1272  
1273  
1274  
1275  
1276  
1277  
1278  
1279  
1280  
1281  
1282  
1283  
1284  
1285  
1286  
1287  
1288  
1289  
1290  
1291  
1292  
1293

WHEN THIS TYPE OF ERROR IS DETECTED BY THE DRIVER IT WILL MAKE AN ERROR CALL OF THE FORM 'ERROR N', WHERE 'N' IS THE ERROR NUMBER AND THE ERROR WILL BE AN EMT INSTRUCTION.

N	TYPE	DATA AVAILAB_L_E
-	----	-----
1	RH70 INTERRUPT OCCURRED (RHAS=0)	*R4= RMCS1'S ADDRESS
2	UNEXPECTED ATTENTION OCCURRED	R1= DRIVE NUMBER R3= ATA BIT *R4= RMCS1'S ADDRESS R5= (RMAS) RMERRS =RMDS RMERRS+2=RMER1 RMERRS+4=RMER2 RMERRS+6=RMMR2
3	MASSBUS PARITY ERROR (MCPE=1)	RD.ADR= ADDRESS OF REG. READ RD.WRD= WORD READ
4	MASSBUS PARITY ERROR (PAR=1)	WRT.AD= ADDRESS OF REG. WRITTEN WRT.WD= WORD WRITTEN RD.WRD= WORD READ BACK
5	ADDRESS PLUG CHANGE BIT SET ('OPE' ERROR)	R1= DRIVE NUMBER R3= ATA BIT *R4= RMCS1'S ADDRESS R5= (RMAS) RMERRS =RMDS RMERRS+2=RMER1 RMERRS+4=RMER2 RMERRS+6=RMMR2

\* THIS IS THE ACTUAL UNIBUS ADDRESS (176700)

a

0014

1  
53  
54

```

;*LAST REVISION 04-APR-81
.TITLE CZRMTBO RM05/3/2 DR CMPT TST
;*COPYRIGHT (C) 1981
;*DIGITAL EQUIPMENT CORPORATION
;*COLORADO SPGS., CO. 80919
;*
;*PROGRAM BY MIKE LEAVITT
;*
;*THIS PROGRAM WAS ASSEMBLED USING THE PDP-11 MAINDEC SYSMAC
;*PACKAGE (MAINDEC-11-DZQAC-C5), 18-MAR-81
    
```

55

```

.SBTTL OPERATIONAL SWITCH SETTINGS
;*
;*      SWITCH      USE
;*      -----      -----
;*      15          HALT ON ERROR
;*      14          LOOP ON TEST
;*      13          INHIBIT ERROR TYPEOUTS
;*      12          INHIBIT TRACE TRAP
;*      11          INHIBIT ITERATIONS
;*      10          BELL ON ERROR
;*      9           LOOP ON ERROR
;*      8           LOOP ON TEST IN SWR<7:0>
;*      7           TYPE THE BAD SECTOR FILE
    
```

56  
57  
58

.SBTTL BASIC DEFINITIONS

```

;*INITIAL ADDRESS OF THE STACK POINTER *** 1100 ***
001100 STACK = 1100
104000 ERROR = EMT          ;;BASIC DEFINITION OF ERROR CALL
000004 SCOPE = IOT        ;;BASIC DEFINITION OF SCOPE CALL
    
```

\*MISCELLANEOUS DEFINITIONS

```

000011 HT = 11          ;;CODE FOR HORIZONTAL TAB
000012 LF = 12          ;;CODE FOR LINE FEED
000015 CR = 15          ;;CODE FOR CARRIAGE RETURN
000200 CRLF = 200       ;;CODE FOR CARRIAGE RETURN-LINE FEED
177776 PS = 177776     ;;PROCESSOR STATUS WORD
177776 PSW=PS
177774 STKLMT = 177774  ;;STACK LIMIT REGISTER
177772 PIRQ = 177772    ;;PROGRAM INTERRUPT REQUEST REGISTER
177570 DSWR = 177570    ;;HARDWARE SWITCH REGISTER
177570 DDISP = 177570  ;;HARDWARE DISPLAY REGISTER
    
```

\*GENERAL PURPOSE REGISTER DEFINITIONS

```

000000 R0 - %0          ;;GENERAL REGISTER
000001 R1 - %1          ;;GENERAL REGISTER
000002 R2 - %2          ;;GENERAL REGISTER
000003 R3 - %3          ;;GENERAL REGISTER
000004 R4 - %4          ;;GENERAL REGISTER
000005 R5 - %5          ;;GENERAL REGISTER
000006 R6 - %6          ;;GENERAL REGISTER
000007 R7 - %7          ;;GENERAL REGISTER
000006 SP - %6          ;;STACK POINTER
000007 PC - %7          ;;PROGRAM COUNTER
    
```

```

: *PRIORITY LEVEL DEFINITIONS
000000 PR0 = 0 ;: PRIORITY LEVEL 0
000040 PR1 = 40 ;: PRIORITY LEVEL 1
000100 PR2 = 100 ;: PRIORITY LEVEL 2
000140 PR3 = 140 ;: PRIORITY LEVEL 3
000200 PR4 = 200 ;: PRIORITY LEVEL 4
000240 PR5 = 240 ;: PRIORITY LEVEL 5
000300 PR6 = 300 ;: PRIORITY LEVEL 6
000340 PR7 = 340 ;: PRIORITY LEVEL 7

```

```

: *'SWITCH REGISTER' SWITCH DEFINITIONS
100000 SW15 = 100000
040000 SW14 = 40000
020000 SW13 = 20000
010000 SW12 = 10000
004000 SW11 = 4000
002000 SW10 = 2000
001000 SW09 = 1000
000400 SW08 = 400
000200 SW07 = 200
000100 SW06 = 100
000040 SW05 = 40
000020 SW04 = 20
000010 SW03 = 10
000004 SW02 = 4
000002 SW01 = 2
000001 SW00 = 1
001000 SW9=SW09
000400 SW8=SW08
000200 SW7=SW07
000100 SW6=SW06
000040 SW5=SW05
000020 SW4=SW04
000010 SW3=SW03
000004 SW2=SW02
000002 SW1=SW01
000001 SW0=SW00

```

```

: *DATA BIT DEFINITIONS (BIT00 TO BIT15)
100000 BIT15 = 100000
040000 BIT14 = 40000
020000 BIT13 = 20000
010000 BIT12 = 10000
004000 BIT11 = 4000
002000 BIT10 = 2000
001000 BIT09 = 1000
000400 BIT08 = 400
000200 BIT07 = 200
000100 BIT06 = 100
000040 BIT05 = 40
000020 BIT04 = 20
000010 BIT03 = 10
000004 BIT02 = 4
000002 BIT01 = 2
000001 BIT00 = 1
001000 BIT9=BIT09
000400 BIT8=BIT08

```

```

000200 BIT7=BIT07
000100 BIT6=BIT06
000040 BIT5=BIT05
000020 BIT4=BIT04
000010 BIT3=BIT03
000004 BIT2=BIT02
000002 BIT1=BIT01
000001 BIT0=BIT00

;*BASIC "CPU" TRAP VECTOR ADDRESSES
000004 ERRVEC = 4 ;:TIME OUT AND OTHER ERRORS
000010 RESVEC = 10 ;:RESERVED AND ILLEGAL INSTRUCTIONS
000014 TBITVEC = 14 ;: 'T' BIT
000014 TRTVEC = 14 ;:TRACE TRAP
000014 BPTVEC = 14 ;:BREAKPOINT TRAP (BPT)
000020 IOTVEC = 20 ;:INPUT/OUTPUT TRAP (IOT) **SCOPE**
000024 PWRVEC = 24 ;:POWER FAIL
000030 EMTVEC = 30 ;:EMULATOR TRAP (EMT) **ERROR**
000034 TRAPVEC = 34 ;:'TRAP' TRAP
000060 TKVEC = 60 ;:TTY KEYBOARD VECTOR
000064 TPVEC = 64 ;:TTY PRINTER VECTOR
000240 PIRQVEC = 240 ;:PROGRAM INTERRUPT REQUEST VECTOR

.SBTTL RM REGISTERS

;INDEX OF STATUS AND REGISTER WORDS RELATIVE TO FMTDPB
64 000016 STATUS = 16
65 000020 SRMCS1 = STATUS+2
66 000022 SRMWC = SRMCS1+2
67 000024 SRMBA = SRMWC+2
68 000026 SRMDA = SRMBA+2
69 000030 SRMCS2 = SRMDA+2
70 000032 SRMDS = SRMCS2+2
71 000034 SRMER1 = SRMDS+2
72 000036 SRMAS = SRMER1+2
73 000040 SRMLA = SRMAS+2
74 000042 SRMDB = SRMLA+2
75 000044 SRMMR1 = SRMDB+2
76 000046 SRMDT = SRMMR1+2
77 000050 SRMSN = SRMDT+2
78 000052 SRMOF = SRMSN+2
79 000054 SRMDC = SRMOF+2
80 000056 SRMHR = SRMDC+2
81 000060 SRMMR2 = SRMHR+2
82 000062 SRMER2 = SRMMR2+2
83 000064 SRMEC1 = SRMER2+2
84 000066 SRMEC2 = SRMEC1+2

.SBTTL RM DRIVER COMMANDS
88 000101 RNOP = 101 ;:NO OPERATION
89 000105 SEEK = 105 ;:SEEK
90 000107 RECAL = 107 ;:RECALIBRATE
91 000111 DRVCLR = 111 ;:DRIVE CLEAR
92 000113 RELSE = 113 ;:RELEASE
93 000115 OFFSET = 115 ;:OFFSET

```

94 000117  
 95 000121  
 96 000123  
 97 000131  
 98 000141  
 99 000143  
 100 000145  
 101 000151  
 102 000153  
 103 000161  
 104 000163  
 105 000171  
 106 000173  
 107  
 108 176700  
 109 000254  
 110

RTC = 117  
 READIN = 121  
 ACK = 123  
 SEARCH = 131  
 GETREG = 141  
 SETFMT = 143  
 SELDRV = 145  
 WCKD = 151  
 WCKHD = 153  
 WRTDAT = 161  
 WRTHD = 163  
 RDDAT = 171  
 RDHD = 173  
  
 ABASE = 176700  
 AVECT1 = 254

;RETURN TO CENTER LINE  
 ;READ IN PRESET  
 ;PACK ACKNOWLEDGE  
 ;SEARCH  
 ;GET REGISTERS  
 ;SET FORMAT (& ECI OR HCI)  
 ;SELECT DRIVE  
 ;WRITE CHECK DATA  
 ;WRITE CHECK HEADER & DATA  
 ;WRITE DATA  
 ;WRITE HEADER & DATA  
 ;READ DATA  
 ;READ HEADER & DATA

1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13

U00000  
000174 000174  
000174 000000  
000176 000000  
000200 000137 005566  
000204 000137 005604  
000210 000137 005622  
000214 000046  
000046 023544  
000052 000052  
000052 040000  
000214 000214  
001100  
000024 000200  
000044 000044  
000044 001100  
001100 001100  
001100 000000  
001102 001212  
001104 000454  
001106 000454  
001110 000454  
001112 000032  
001114

```
.SBTTL TRAP CATCHER
.=0
;*ALL UNUSED LOCATIONS FROM 4 - 776 CONTAIN A ".+2,HALT"
;*SEQUENCE TO CATCH ILLEGAL TRAPS AND INTERRUPTS
;*LOCATION 0 CONTAINS 0 TO CATCH IMPROPERLY LOADED VECTORS
DISPREG: .WORD 0      ;;SOFTWARE DISPLAY REGISTER
SWREG:   .WORD 0      ;;SOFTWARE SWITCH REGISTER

.SBTTL STARTING ADDRESS(ES)
JMP @#START      ;;JUMP TO STARTING ADDRESS OF PROGRAM
JMP @#START1     ;;CHANGE THE RH/RM UNIBUS ADDRESS
JMP @#START2     ;;SECOND PASS STARTING ADDRESS

.SBTTL ACT11 HOOKS
;*****
;HOOKS REQUIRED BY ACT11
$SVPC=.          ;;SAVE PC
.=46             ;;1)SET LOC.46 TO ADDRESS OF $ENDAD IN .SEOP
$ENDAD           ;;
.=52             ;;2)SET LOC.52 TO 40000
.WORD 40000     ;;
.-$SVPC         ;;RESTORE PC

.-1100
.SBTTL APT PARAMETER BLOCK
;*****
;SET LOCATIONS 24 AND 44 AS REQUIRED FOR APT
;*****
.$X=.           ;;SAVE CURRENT LOCATION
.=24           ;;SET POWER FAIL TO POINT TO START OF PROGRAM
200           ;;FOR APT START UP
.=44           ;;POINT TO APT INDIRECT ADDRESS PNTR.
$APTHDR       ;;POINT TO APT HEADER BLOCK
.=.$X         ;;RESET LOCATION COUNTER
;*****
;SETUP APT PARAMETER BLOCK AS DEFINED IN THE APT-PDP11 DIAGNOSTIC
;INTERFACE SPEC.

$APTHD:
$HIBTS: .WORD 0      ;;TWO HIGH BITS OF 18 BIT MAILBOX ADDR.
$MBADR: .WORD $MAIL  ;;ADDRESS OF APT MAILBOX (BITS 0-15)
$TSTM:  .WORD 300.   ;;RUN TIM OF LONGEST TEST
$PASTM: .WORD 300.   ;;RUN TIME IN SECS. OF 1ST PASS ON 1 UNIT (QUICK VERIFY)
$UNITM: .WORD 300.   ;;ADDITIONAL RUN TIME (SECS) OF A PASS FOR EACH ADDED UNIT
          .WORD $ETEND-$MAIL/2 ;;LENGTH MAILBOX-ETABLE (WORDS)

TAB.XY .
```



0

.SBTTL COMMON TAGS

\*\*\*\*\*  
\*THIS TABLE CONTAINS VARIOUS COMMON STORAGE LOCATIONS  
\*USED IN THE PROGRAM.

001114	001114			\$CMTAG:	.=TAB.XY		::START OF COMMON TAGS
001114	000000				.WORD	0	
001116	000			\$TSTNM:	.BYTE	0	::CONTAINS THE TEST NUMBER
001117	000			\$ERFLG:	.BYTE	0	::CONTAINS ERROR FLAG
001120	000000			\$ICNT:	.WORD	0	::CONTAINS SUBTEST ITERATION COUNT
001122	000000			\$LPADR:	.WORD	0	::CONTAINS SCOPE LOOP ADDRESS
001124	000000			\$LPERR:	.WORD	0	::CONTAINS SCOPE RETURN FOR ERRORS
001126	000000			\$ERTTL:	.WORD	0	::CONTAINS TOTAL ERRORS DETECTED
001130	000			\$ITEMB:	.BYTE	0	::CONTAINS ITEM CONTROL BYTE
001131	001			\$ERMAX:	.BYTE	1	::CONTAINS MAX. ERRORS PER TEST
001132	000000			\$ERRPC:	.WORD	0	::CONTAINS PC OF LAST ERROR INSTRUCTION
001134	000000			\$GDADR:	.WORD	0	::CONTAINS ADDRESS OF 'GOOD' DATA
001136	000000			\$BDADR:	.WORD	0	::CONTAINS ADDRESS OF 'BAD' DATA
001140	000000			\$GDDAT:	.WORD	0	::CONTAINS 'GOOD' DATA
001142	000000			\$BDDAT:	.WORD	0	::CONTAINS 'BAD' DATA
001144	000000				.WORD	0	::RESERVED--NOT TO BE USED
001146	000000				.WORD	0	
001150	000			\$AUTOB:	.BYTE	0	::AUTOMATIC MODE INDICATOR
001151	000			\$INTAG:	.BYTE	0	::INTERRUPT MODE INDICATOR
001152	000000				.WORD	0	
001154	177570			\$WR:	.WORD	DSWR	::ADDRESS OF SWITCH REGISTER
001156	177570			\$DISPLAY:	.WORD	DDISP	::ADDRESS OF DISPLAY REGISTER
001160	177560			\$TKS:	177560		::TTY KBD STATUS
001162	177562			\$TKB:	177562		::TTY KBD BUFFER
001164	177564			\$TPS:	177564		::TTY PRINTER STATUS REG. ADDRESS
001166	177566			\$TPB:	177566		::TTY PRINTER BUFFER REG. ADDRESS
001170	000			\$NULL:	.BYTE	0	::CONTAINS NULL CHARACTER FOR FILLS
001171	002			\$FILLS:	.BYTE	2	::CONTAINS # OF FILLER CHARACTERS REQUIRED
001172	012			\$FILLC:	.BYTE	12	::INSERT FILL CHARS. AFTER A 'LINE FEED'
001173	000			\$TPFLG:	.BYTE	0	::'TERMINAL AVAILABLE' FLAG (BIT<07>-0-YES)
001174	000000			\$TMP0:	.WORD	0	::USER DEFINED
001176	000000			\$TIMES:	0		::MAX. NUMBER OF ITERATIONS
001200	000000			\$ESCAPE:	0		::ESCAPE ON ERROR ADDRESS
001202	207	377	377	\$BELL:	.ASCIZ	<207><377><377>	::CODE FOR BELL
001206	077			\$QUES:	.ASCII	/?/	::QUESTION MARK
001207	015			\$CRLF:	.ASCII	<15>	::CARRIAGE RETURN
001210	012	000		\$LF:	.ASCIZ	<12>	::LINE FEED

\*\*\*\*\*  
.SBTTL APT MAILBOX-ETABLE

001212				.EVEN			
001212	000000			\$MAIL:			::APT MAILBOX
001214	000000			\$MSGTY:	.WORD	AMSGTY	::MESSAGE TYPE CODE
001216	000000			\$FATAL:	.WORD	AFATAL	::FATAL ERROR NUMBER
001220	000000			\$TESTN:	.WORD	ATESTN	::TEST NUMBER
001222	000000			\$PASS:	.WORD	APASS	::PASS COUNT
001224	000000			\$DEVCT:	.WORD	ADEVCT	::DEVICE COUNT
001226	000000			\$UNIT:	.WORD	AUNIT	::I/O UNIT NUMBER
				\$MSGAD:	.WORD	AMSGAD	::MESSAGE ADDRESS

001230	000000	\$MSGLG: .WORD	AMSGLG	::MESSAGE LENGTH
001232		\$ETABLE:		::APT ENVIRONMENT TAB. E
001232	000	\$ENV: .BYTE	AENV	::ENVIRONMENT BYTE
001233	000	\$ENVM: .BYTE	AENVM	::ENVIRONMENT MODE BITS
001234	000000	\$SWREG: .WORD	ASWREG	::APT SWITCH REGISTER
001236	000000	\$USWR: .WORD	AUSWR	::USER SWITCHES
001240	000000	\$CPUOP: .WORD	ACPUOP	::CPU TYPE,OPTIONS
		.*		BITS 15-11=CPU TYPE
		.*		11/04=01,11/05=02,11/20=03,11/40=04,11/45=05
		.*		11/70=06,PDQ=07,Q=10
		.*		BIT 10=REAL TIME CLOCK
		.*		BIT 9=FLOATING POINT PROCESSOR
		.*		BIT 8=MEMORY MANAGEMENT
001242	000	\$MAMS1: .BYTE	AMAMS1	::HIGH ADDRESS,M.S. BYTE
001243	000	\$MTYP1: .BYTE	AMTYP1	::MEM. TYPE,BLK#1
		.*		MEM. TYPE BYTE -- (HIGH BYTE)
		.*		900 NSEC CORE=001
		.*		300 NSEC BIPOLAR=002
		.*		500 NSEC MOS=003
001244	000000	\$MADR1: .WORD	AMADR1	::HIGH ADDRESS,BLK#1
		.*		MEM.LAST ADDR.=3 BYTES,THIS WORD AND LOW OF 'TYPE' ABOVE
001246	000	\$MAMS2: .BYTE	AMAMS2	::HIGH ADDRESS,M.S. BYTE
001247	000	\$MTYP2: .BYTE	AMTYP2	::MEM. TYPE,BLK#2
001250	000000	\$MADR2: .WORD	AMADR2	::MEM.LAST ADDRESS,BLK#2
001252	000	\$MAMS3: .BYTE	AMAMS3	::HIGH ADDRESS,M.S.BYTE
001253	000	\$MTYP3: .BYTE	AMTYP3	::MEM. TYPE,BLK#3
001254	000000	\$MADR3: .WORD	AMADR3	::MEM.LAST ADDRESS,BLK#3
001256	000	\$MAMS4: .BYTE	AMAMS4	::HIGH ADDRESS,M.S.BYTE
001257	000	\$MTYP4: .BYTE	AMTYP4	::MEM. TYPE,BLK#4
001260	000000	\$MADR4: .WORD	AMADR4	::MEM.LAST ADDRESS,BLK#4
001262	000254	\$VECT1: .WORD	AVECT1	::INTERRUPT VECTOR#1,BUS PRIORITY#1
001264	000000	\$VECT2: .WORD	AVECT2	::INTERRUPT VECTOR#2BUS PRIORITY#2
001266	176700	\$BASE: .WORD	ABASE	::BASE ADDRESS OF EQUIPMENT UNDER TEST
001270	000000	\$DEVN: .WORD	ADEVN	::DEVICE MAP
001272	000000	\$CDW1: .WORD	ACDW1	::CONTROLLER DESCRIPTION WORD#1
001274	000000	\$CDW2: .WORD	ACDW2	::CONTROLLER DESCRIPTION WORD#2
001276		\$ETEND:		
		.MEXIT		

.SBTTL USER DEFINED TAGS

001276	176700	\$RMADR:	.WORD	176700	:FIRST ADDRESS OF RH/RM REGISTERS
001300	000254	\$RMVEC:	.WORD	254	:VECTOR ADDRESS
001302	172540	\$LKCSR:	.WORD	172540	:ADDR OF KW11-P STATUS REGISTER
001304	172542	\$LKCSB:	.WORD	172542	:ADDR OF KW11-P COUNTER BUFFER
001306	000104	\$LPVEC:	.WORD	104	:ADDR OF KW11-P VECTOR
001310	177546	\$LKS:	.WORD	177546	:ADDR OF KW11-L STATUS REGISTER
001312	000100	\$LLVEC:	.WORD	100	:ADDR OF KW11-L VECTOR
001314	177777	PCLOCK:	.WORD	-1	: '0' IF KW11-P IS ON SYSTEM
001316	177777	CLKFLG:	.WORD	-1	: '0' IF A CLOCK IS AVAILABLE
001320	000074	HZ:	.WORD	74	:74 (8) IF 60 HZ SYSTEM; 62 (8) IF 50 HZ SYSTEM
001322	000000	STATIN:	.WORD	0	: 'TYPE STATISTICS' INDICATOR
001324	000000	PACK:	.WORD	0	: ENTRY TO THE TABLE D
	001224	DRIVE	= \$UNIT		: DRIVE # STORAGE:
001326	000000	ATTN:	.WORD	0	: ATTN REG STORAGE:
001330	000000	UNIT:	.WORD	0	: DRIVE # STORAGE FOR PRINTOUT
					: RETRY COUNT IN THE UPPER BYTE
001332	000000	LSTAD:	.WORD	0	: STORE LAST MEMORY ADDRESS HERE
001334	000000	CHGADR:	.WORD	0	: CHANGE RH/RM UNIBUS ADDRESS FLAG
001336	000000	CFLAG:	.WORD	0	: 'CONTROL C' FLAG
001340	000000	TSTNM:	.WORD	0	: TEST NUMBER FOR PRINT AND SCORE RT.
001342	000000	BADSEC:	.WORD	0	: BAD SECTOR/TRACK FLAG
001344	000000	HOUR:	.WORD	0	: HOUR COUNT STORED HERE (MAXIMUM - 999.)
001346	000000	MINUTE:	.WORD	0	: MINUTE'S COUNT STORED HERE
001350	000000	SECOND:	.WORD	0	: SECOND'S COUNT STORED HERE
001352	000000	SIXTEE:	.WORD	0	: TIMER ROUTINE COUNTER (FOR ONE SECOND)
001354	000000	CMCNT:	.WORD	0	: ZONE COUNT
001356	000000	CMCYL:	.WORD	0	: CYLINDER ADDRESS
001360	000000	STARSC:	.WORD	0	: STARTING SECTOR (FOR TEST 6,8)
001362	000000	CMSEC:	.WORD	0	: DALTA CYLINDER COUNT
001364	000000	CMTRK:	.WORD	0	: TRACK ADDRESS
001366	000000	MULINE:	.WORD	0	: NEW LINE FLAG AND COLUMN CTR
001370	000037	SECLMT:	.WORD	31.	: SECTOR ADDRESS LIMIT
001372	000000	TRKLMT:	.WORD	0	: TRACK ADDRESS LIMIT, RM03/2 = 4. AND RM05 18.
001374	001466	CYLIMT:	.WORD	822.	: CYLINDER ADDRESS LIMIT
001376	000000	FAULT:	.WORD	0	: =1, IF ALL DRIVES NOT COMPATIBLE
001400	000000	RSTART:	.WORD	0	: CONTAINS PROGRAM RESTARTING ADDRESS
001402	000000	DTYP:	.WORD	0	: CONTAINS DRIVE TYPE CODE OF DRIVE BEING TESTED
001404	000000	XXDP:	.WORD	0	: THE LOW BYTE CONTAINS THE DRIVE NUMBER FROM WHICH : THE PROGRAM WAS LOADED. THE HIGH BYTE CONTAINS THE : 'XXDP' DEVICE CODE THE RM05/3/2.

.SBTTL TABLES, CONSTANTS, AND VARIABLE LOCATIONS

:TABLE D  
:TABLE LISTED BELOW SPECIFIES THE SECTORS TO BE WRITTEN  
:BY A LOGICAL DRIVE. EACH LOGICAL DRIVE WRITES TWO SECTORS ON ONE  
:CYLINDER, 16 CYLINDERS IN ONE BLOCK, 2 BLOCKS IN ONE WRITE-CURRENT  
:ZONE AND 7 CURRENT ZONES IN A PACK.

001406	000	017	015	LOG0:	.BYTE	0,15,13,10,6,1,11,4,12,13,9,14,2,5,7,8.
001426	001	000	016	LOG1:	.BYTE	1,0,14,11,7,2,12,5,13,4,10,15,3,6,8,9.
001446	002	001	017	LOG2:	.BYTE	2,1,15,12,8,3,13,6,14,5,11,0,4,7,9,10.
001466	003	002	000	LOG3:	.BYTE	3,2,0,13,9,4,14,7,15,6,12,1,5,8,10,11.
001506	004	003	001	LOG4:	.BYTE	4,3,1,14,10,5,15,8,0,7,13,2,6,9,11,12.
001526	005	004	002	LOG5:	.BYTE	5,4,2,15,11,6,0,9,1,8,14,3,7,10,12,13.



003116 000 000 000 OVWP15: .BYTE 0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0 ; TRACK 15  
003136 000 000 000 OVWP16: .BYTE 0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0 ; TRACK 16  
003156 000 000 000 OVWP17: .BYTE 0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0 ; TRACK 17  
003176 000 000 000 OVWP18: .BYTE 0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0 ; TRACK 18

;TABLE OF READ SCORE,NEGATIVE OFFSET SCORE

003216 000 000 000 RDN0: .BYTE 0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0 ; TRACK 0  
003236 000 000 000 RDN1: .BYTE 0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0 ; TRACK 1  
003256 000 000 000 RDN2: .BYTE 0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0 ; TRACK 2  
003276 000 000 000 RDN3: .BYTE 0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0 ; TRACK 3  
003316 000 000 000 RDN4: .BYTE 0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0 ; TRACK 4  
003336 000 000 000 RDN5: .BYTE 0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0 ; TRACK 5  
003356 000 000 000 RDN6: .BYTE 0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0 ; TRACK 6  
003376 000 000 000 RDN7: .BYTE 0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0 ; TRACK 7  
003416 000 000 000 RDN8: .BYTE 0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0 ; TRACK 8  
003436 000 000 000 RDN9: .BYTE 0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0 ; TRACK 9  
003456 000 000 000 RDN10: .BYTE 0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0 ; TRACK 10  
003476 000 000 000 RDN11: .BYTE 0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0 ; TRACK 11  
003516 000 000 000 RDN12: .BYTE 0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0 ; TRACK 12  
003536 000 000 000 RDN13: .BYTE 0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0 ; TRACK 13  
003556 000 000 000 RDN14: .BYTE 0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0 ; TRACK 14  
003576 000 000 000 RDN15: .BYTE 0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0 ; TRACK 15  
003616 000 000 000 RDN16: .BYTE 0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0 ; TRACK 16  
003636 000 000 000 RDN17: .BYTE 0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0 ; TRACK 17  
003656 000 000 000 RDN18: .BYTE 0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0 ; TRACK 18

;TABLE OF READ SCORE,POSITIVE OFFSET SCORE

003676 000 000 000 RDP0: .BYTE 0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0 ; TRACK 0  
003716 000 000 000 RDP1: .BYTE 0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0 ; TRACK 1  
003736 000 000 000 RDP2: .BYTE 0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0 ; TRACK 2  
003756 000 000 000 RDP3: .BYTE 0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0 ; TRACK 3  
003776 000 000 000 RDP4: .BYTE 0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0 ; TRACK 4  
004016 000 000 000 RDP5: .BYTE 0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0 ; TRACK 5  
004036 000 000 000 RDP6: .BYTE 0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0 ; TRACK 6  
004056 000 000 000 RDP7: .BYTE 0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0 ; TRACK 7  
004076 000 000 000 RDP8: .BYTE 0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0 ; TRACK 8  
004116 000 000 000 RDP9: .BYTE 0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0 ; TRACK 9  
004136 000 000 000 RDP10: .BYTE 0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0 ; TRACK 10  
004156 000 000 000 RDP11: .BYTE 0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0 ; TRACK 11  
004176 000 000 000 RDP12: .BYTE 0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0 ; TRACK 12  
004216 000 000 000 RDP13: .BYTE 0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0 ; TRACK 13  
004236 000 000 000 RDP14: .BYTE 0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0 ; TRACK 14  
004256 000 000 000 RDP15: .BYTE 0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0 ; TRACK 15  
004276 000 000 000 RDP16: .BYTE 0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0 ; TRACK 16  
004316 000 000 000 RDP17: .BYTE 0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0 ; TRACK 17  
004336 000 000 000 RDP18: .BYTE 0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0 ; TRACK 18

;TABLE OF SELF TEST SCORE

004356 000 000 SELF0: .BYTE 0,0 ; TRACK 0  
004360 000 000 SELF1: .BYTE 0,0 ; TRACK 1  
004362 000 000 SELF2: .BYTE 0,0 ; TRACK 2  
004364 000 000 SELF3: .BYTE 0,0 ; TRACK 3  
004366 000 000 SELF4: .BYTE 0,0 ; TRACK 4  
004370 000 000 SELF5: .BYTE 0,0 ; TRACK 5

004372	000	000	SELF6:	.BYTE	0,0	; TRACK 6
004374	000	000	SELF7:	.BYTE	0,0	; TRACK 7
004376	000	000	SELF8:	.BYTE	0,0	; TRACK 8
004400	000	000	SELF9:	.BYTE	0,0	; TRACK 9
004402	000	000	SELF10:	.BYTE	0,0	; TRACK 10
004404	000	000	SELF11:	.BYTE	0,0	; TRACK 11
004406	000	000	SELF12:	.BYTE	0,0	; TRACK 12
004410	000	000	SELF13:	.BYTE	0,0	; TRACK 13
004412	000	000	SELF14:	.BYTE	0,0	; TRACK 14
004414	000	000	SELF15:	.BYTE	0,0	; TRACK 15
004416	000	000	SELF16:	.BYTE	0,0	; TRACK 16
004420	000	000	SELF17:	.BYTE	0,0	; TRACK 17
004422	000	000	SELF18:	.BYTE	0,0	; TRACK 18

;THE START LOGICAL DRIVE # TO WRITE ON EACH CYLINDER OF A BLOCK  
;16 CYLINDERS,2 BLOCKS,TOTAL 32 CYLINDERS IN ONE ZONE

004424 000 001 003 INDST: .BYTE 0,1,3,6,10,,15,,5,12,,4,13,,7,2,14,,11,,9,,8.

004444			BLKADR:			
004444	004622		.WORD	DRIV0		; ADDRESS OF THE PARAMETER BLOCK FOR DRIVE 0
004446	004644		.WORD	DRIV1		; ADDRESS OF THE PARAMETER BLOCK FOR DRIVE 1
004450	004666		.WORD	DRIV2		; ADDRESS OF THE PARAMETER BLOCK FOR DRIVE 2
004452	004710		.WORD	DRIV3		; ADDRESS OF THE PARAMETER BLOCK FOR DRIVE 3
004454	004732		.WORD	DRIV4		; ADDRESS OF THE PARAMETER BLOCK FOR DRIVE 4
004456	004754		.WORD	DRIV5		; ADDRESS OF THE PARAMETER BLOCK FOR DRIVE 5
004460	004776		.WORD	DRIV6		; ADDRESS OF THE PARAMETER BLOCK FOR DRIVE 6
004462	005020		.WORD	DRIV7		; ADDRESS OF THE PARAMETER BLOCK FOR DRIVE 7
004464	005042		.WORD	DRIV10		; ADDRESS OF THE PARAMETER BLOCK FOR DRIVE 10
004466	005064		.WORD	DRIV11		; ADDRESS OF THE PARAMETER BLOCK FOR DRIVE 11
004470	005106		.WORD	DRIV12		; ADDRESS OF THE PARAMETER BLOCK FOR DRIVE 12
004472	005130		.WORD	DRIV13		; ADDRESS OF THE PARAMETER BLOCK FOR DRIVE 13
004474	005152		.WORD	DRIV14		; ADDRESS OF THE PARAMETER BLOCK FOR DRIVE 14
004476	005174		.WORD	DRIV15		; ADDRESS OF THE PARAMETER BLOCK FOR DRIVE 15
004500	005216		.WORD	DRIV16		; ADDRESS OF THE PARAMETER BLOCK FOR DRIVE 16
004502	005240		.WORD	DRIV17		; ADDRESS OF THE PARAMETER BLOCK FOR DRIVE 17

004504 000000 OFFCOD: .WORD 0 ;OFFSET CODE TABLE  
;NUMBER FOR NEGATIVE OFFSET (DIR = OUT)  
;NUMBER FOR POSITIVE OFFSET (DIR = IN)

;DATA/PARAMETER BLOCK

004506	000		FMTDPB:	.BYTE	0	;DRIVER PARAMETER BLOCK, DRIVE #
004507	000		.BYTE	0		;OFFSET VALUE OR FMT16, HCI OR ECI
004510	000		.BYTE	0		;COMMAND CODE
004511	000		.BYTE	0		;PSEL, A16 AND A17
004512	000000		.WORD	0		;WORD COUNT (NEG)
004514	043456		.WORD	BUFFER		;BUFFER ADDRESS
004516	000		.BYTE	0		;SECTOR ADDRESS
004517	000		.BYTE	0		;TRACK ADDRESS
004520	000000		.WORD	0		;CYLINDER ADDRESS
004522	004526		.WORD	RM.REG		;ADDRESS TO SAVE ALL RH/RM REG'S
004524	000000		.WORD	0		;STATUS WORD

004526	000000	RM.REG:	.WORD	0	.RMCS1
004530	000000		.WORD	0	:RMWC
004532	000000		.WORD	0	:RMBA
004534	000000		.WORD	0	:RMDA
004536	000000		.WORD	0	:RMCS2
004540	000000		.WORD	C	:RMDS
004542	000000		.WORD	0	:RMER1
004544	000000		.WORD	0	:RMAS
004546	000000		.WORD	0	:RMLA
004550	000000		.WORD	0	:RMDB
004552	000000		.WORD	0	:RMMR1
004554	000000		.WORD	0	:RMDT
004556	000000		.WORD	0	:RMSN
004560	000000		.WORD	0	:RMOF
004562	000000		.WORD	0	:RMCA
004564	000000		.WORD	0	:RMDC
004566	000000		.WORD	0	:RMER2
004570	000000		.WORD	0	:RMMR2
004572	000000		.WORD	0	:RMEC1
004574	000000		.WORD	0	:RMEC2

:GENERAL PURPOSE PARAMETER BLOCK

004576	000	GENDPB:	.BYTE	0	:DRIVER PARAMETER BLOCK, DRIVE #
004577	000		.BYTE	0	:OFFSET VALUE OR FMT16, HCI OR ECI
004600	000		.BYTE	0	:COMMAND CODE
004601	000		.BYTE	0	:PSEL, A16 AND A17
004602	177776		.WORD	-2	:WORD COUNT (NEG)
004604	004616		.WORD	CYLNR	:BUFFER ADDRESS
004606	000		.BYTE	0	:SECTOR ADDRESS
004607	000		.BYTE	0	:TRACK ADDRESS
004610	000000		.WORD	0	:CYLINDER ADDRESS
004612	004526		.WORD	RM.REG	:ADDRESS TO SAVE ALL RH/RM REG'S
004614	000000		.WORD	0	:STATUS WORD

004616 CYLNR: .BLKW 2 :BUFFER

:HISTORY FILE FOR 16 LOGICAL DRIVES:(0-17 OCTAL)

000001	\$FMT	=	1	
000002	\$COMND	=	\$FMT+1	:COMMAND CODE
000003	\$PSEL	=	\$FMT+2	:PROT SELECT AND A16,A17
000004	\$WRDM	=	\$FMT+3	:WORD COUNT
000006	\$BLF	=	\$FMT+5	:BUFFER ADDRESS
000010	\$SEC	=	\$FMT+7	:SECTOR ADDRESS
000011	\$TRK	=	\$FMT+10	:TRACK ADDRESS
000012	\$CYL	=	\$FMT+11	:CYLINDER ADDRESS
000014	\$SYSNM	=	\$FMT+13	:SUB SYSTEM A-H
000015	\$PHYDR	=	\$FMT+14	:PHYSICAL DRIVE CODE (ASCII)
000016	\$GAP	=	\$FMT+15	:LEFT TWO NULL BYTES
000022	\$EMTAB	=	\$GAP+4	:END OF HISTORY TABLE

004622	000	000	DRIV0:	.BYTE 780,0	:HISTORY BLOCK OF LOGICAL DRIVE 0
004624				.BLKB \$EMTAB-\$COMND	
004644	001	000	DRIV1:	.BYTE 781,0	:HISTORY BLOCK OF LOGICAL DRIVE 1
004646				.BLKB \$EMTAB-\$COMND	
004666	002	000	DRIV2:	.BYTE 782,0	:HISTORY BLOCK OF LOGICAL DRIVE 2

004670			.BLKB	SEMTAB-\$COMND	
004710	003	000	DRIV3:	.BYTE 783,0	;HISTORY BLOCK OF LOGICAL DRIVE 3
004712			.BLKB	SEMTAB-\$COMND	
004732	004	000	DRIV4:	.BYTE 784,0	;HISTORY BLOCK OF LOGICAL DRIVE 4
004734			.BLKB	SEMTAB-\$COMND	
004754	005	000	DRIV5:	.BYTE 785,0	;HISTORY BLOCK OF LOGICAL DRIVE 5
004756			.BLKB	SEMTAB-\$COMND	
004776	006	000	DRIV6:	.BYTE 786,0	;HISTORY BLOCK OF LOGICAL DRIVE 6
005000			.BLKB	SEMTAB-\$COMND	
005020	007	000	DRIV7:	.BYTE 787,0	;HISTORY BLOCK OF LOGICAL DRIVE 7
005022			.BLKB	SEMTAB-\$COMND	
005042	000	000	DRIV10:	.BYTE 7810,0	;HISTORY BLOCK OF LOGICAL DRIVE 10
005044			.BLKB	SEMTAB-\$COMND	
005064	001	000	DRIV11:	.BYTE 7811,0	;HISTORY BLOCK OF LOGICAL DRIVE 11
005066			.BLKB	SEMTAB-\$COMND	
005106	002	000	DRIV12:	.BYTE 7812,0	;HISTORY BLOCK OF LOGICAL DRIVE 12
005110			.BLKB	SEMTAB-\$COMND	
005130	003	000	DRIV13:	.BYTE 7813,0	;HISTORY BLOCK OF LOGICAL DRIVE 13
005132			.BLKB	SEMTAB-\$COMND	
005152	004	000	DRIV14:	.BYTE 7814,0	;HISTORY BLOCK OF LOGICAL DRIVE 14
005154			.BLKB	SEMTAB-\$COMND	
005174	005	000	DRIV15:	.BYTE 7815,0	;HISTORY BLOCK OF LOGICAL DRIVE 15
005176			.BLKB	SEMTAB-\$COMND	
005216	006	000	DRIV16:	.BYTE 7816,0	;HISTORY BLOCK OF LOGICAL DRIVE 16
005220			.BLKB	SEMTAB-\$COMND	
005240	007	000	DRIV17:	.BYTE 7817,0	;HISTORY BLOCK OF LOGICAL DRIVE 17
005242			.BLKB	SEMTAB-\$COMND	

;STANDARD DATA PATTERN

005262	066666	STNDAT:	.WORD	066666
005264	155554		.WORD	155554
005266	133331		.WORD	133331
005270	066663		.WORD	066663
005272	155546		.WORD	155546
005274	133315		.WORD	133315
005276	066633		.WORD	066633
005300	155466		.WORD	155466
005302	133155		.WORD	133155
005304	066333		.WORD	066333
005306	154666		.WORD	154666
005310	131555		.WORD	131555
005312	063333		.WORD	063333
005314	146666		.WORD	146666
005316	115555		.WORD	115555
005320	033333		.WORD	033333

005322	040135	PSEUDO:	.WORD	040135
005324	177070		.WORD	177070
005326	070414		.WORD	070414
005330	064531		.WORD	064531
005332	174473		.WORD	174473
005334	062422		.WORD	062422
005336	114352		.WORD	114352
005340	036620		.WORD	036620
005342	010031		.WORD	010031
005344	052336		.WORD	052336



005346	017310	.WORD	017310
005350	011347	.WORD	011347
005352	102367	.WORD	102367
005354	152567	.WORD	152567
005356	001246	.WORD	001246
005360	160073	.WORD	160073

.SBTTL ERROR POINTER TABLE

;\*THIS TABLE CONTAINS THE INFORMATION FOR EACH ERROR THAT CAN OCCUR.  
;\*THE INFORMATION IS OBTAINED BY USING THE INDEX NUMBER FOUND IN  
;\*LOCATION \$ITEMB. THIS NUMBER INDICATES WHICH ITEM IN THE TABLE IS PERTINENT.  
;\*NOTE1: IF \$ITEMB IS 0 THE ONLY PERTINENT DATA IS (\$ERRPC).  
;\*NOTE2: EACH ITEM IN THE TABLE CONTAINS 4 POINTERS EXPLAINED AS FOLLOWS:

;\* EM ;;POINTS TO THE ERROR MESSAGE  
;\* DH ;;POINTS TO THE DATA HEADER  
;\* DT ;;POINTS TO THE DATA  
;\* DF ;;POINTS TO THE DATA FORMAT

1	005362				
2					
3					
4	005362	036576	EM1		;RH CONTROLLER INTERRUPT OCCURRED (RMAS 0)
5	005364	041212	DH1		
6	005366	041634	DT1		
7	005370	041760	DF1		
8					
9					
10					
11	005372	036635	EM2		;UNEXPECTED ATTENTION OCCURRED
12	005374	041221	DH2		
13	005376	041640	DT2		
14	005400	041761	DF2		
15					
16					
17					
18	005402	036673	EM3		;MASSBUS PARITY ERROR (MCPE 1)
19	005404	041303	DH3		
20	005406	041656	DT3		
21	005410	041767	DF3		
22					
23					
24					
25	005412	036731	EM4		;MASSBUS PARITY ERROR (PAR-1)
26	005414	041334	DH4		
27	005416	041666	DT4		
28	005420	041772	DF4		
29					
30					
31					
32	005422	036766	EM5		;ADDRESS PLUG BIT CHANGED
33	005424	041221	DH2		
34	005426	041640	DT2		
35	005430	041761	DF2		
36					
37					
38					
39	005432	037022	EM6		;RH CONTROLLER DIDN'T RESPOND TO ADDRESSING
40	005434	041376	DH6		
41	005436	041700	DT6		
42	005440	041760	DF1		

```

43
44      ;* ERRORS 7 - 12 ARE PART OF THE 'DUMP' SUBROUTINE
45
46      ;ERROR 7
47
48 005442 000000      0
49 005444 041407      DH7
50 005446 041704      DT7
51 005450 000000      0
52
53      ;ERROR 10
54
55 005452 000000      0
56 005454 041460      DH10
57 005456 041720      DT10
58 005460 000000      0
59
60      ;ERROR 11
61
62 005462 000000      0
63 005464 041531      DH11
64 005466 041734      DT11
65 005470 000000      0
66
67      ;ERROR 12
68
69 005472 000000      0
70 005474 041602      DH12
71 005476 041750      DT12
72 005500 000000      0

```

```

1          ; THIS ROUTINE HANDLES UNEXPECTED TIMEOUTS
2
3 005502 011600 BADTMO: MOV (SP),R0 ;SAVE PC WHERE THE TIME OUT OCCURED
4 005504 005740 TST -(R0) ;ADJUST PC -2
5 005506 022626 CMP (SP)+,(SP)+ ;RESTORE STACK POINTER
6 005510 104401 005516 TYPE ,65$ ;:TYPE ASCIZ STRING
005514 000417 BR 64$ ;:GET OVER THE ASCIZ
;:65$: .ASCIZ <CRLF>/UNEXPECTED BUS TIMEOUT, PC=/
64$:
7 005554 010046 MOV R0,-(SP) ;SETUP FOR TYPING OUT PC
8 005556 104402 TYPOC
9 005560 000240 NOP ;PUT 'HALT(0)' INSTRUCTION HERE IF YOU WISH
;TO STOP ON UNEXPECTED TIMEOUT.
10
11 005562 000177 173612 JMP @RSTART ;JUMP TO RESTART
12
13 .SBTTL START OF PROGRAM
14
15 005566 012737 005566 001400 START: MOV #,RSTART ;SETUP RESTART ADDRESS
16 005574 012737 000400 001334 MOV #400,CHGADR ;200 START ADDRESS FLAG
17 005602 000414 BR START3
18
19 005604 012737 005604 001400 START1: MOV #,RSTART ;SETUP RESTART ADDRESS
20 005612 012737 177777 001334 MOV #-1,CHGADR ;204 START ADDRESS FLAG
21 005620 000405 BR START3
22
23 005622 012737 005622 001400 START2: MOV #,RSTART ;SETUP RESTART ADDRESS
24 005630 005037 001334 CLR CHGADR ;210 START ADDRESS FLAG
25
26 005634 000240 START3: NOP
27 005636 005227 000000 INC #0 ;TTY LOOP, WAIT FOR INCREMENT
28 005642 001375 BNE -4 ;OF WORD
29 005644 000005 RESET ;CLEAR THE WORLD
30
31 .SBTTL INITIALIZE THE COMMON TAGS
;:CLEAR THE COMMON TAGS ($CMTAG) AREA
005646 012706 001114 MOV #CMTAG,R6 ;:FIRST LOCATION TO BE CLEARED
005652 005026 CLR (R6)+ ;:CLEAR MEMORY LOCATION
005654 022706 001154 CMP #SWR,R6 ;:DONE?
005660 001374 BNE -6 ;:LOOP BACK IF NO
005662 012706 001100 MOV #STACK,SP ;:SETUP THE STACK POINTER
;:INITIALIZE A FEW VECTORS
005666 012737 027320 000020 MOV #SCOPE,@IOTVEC ;:IOT VECTOR FOR SLOPE ROUTINE
005674 012737 000340 000022 MOV #340,@IOTVEC+2 ;:LEVEL 7
005702 012737 023662 000030 MOV #ERROR,@EMTVEC ;:EMT VECTOR FOR ERROR ROUTINE
005710 012737 000340 000032 MOV #340,@EMTVEC+2 ;:LEVEL 7
005716 012737 030100 000034 MOV #TRAP,@TRAPVEC ;:TRAP VECTOR FOR TRAP CALLS
005724 012737 000340 000036 MOV #340,@TRAPVEC+2 ;:LEVEL 7
005732 012737 025400 000024 MOV #SPWRDN,@PWRVEC ;:POWER FAILURE VECTOR
005740 012737 000340 000026 MOV #340,@PWRVEC+2 ;:LEVEL 7
005746 013737 023512 023504 MOV $ENDT,$EOPCT ;:SETUP END-OF-PROGRAM COUNTER
005754 005037 001176 CLR $TIMES ;:INITIALIZE NUMBER OF ITERATIONS
005760 005037 001200 CLR $ESCAPE ;:CLEAR THE ESCAPE ON ERROR ADDRESS
005764 112737 000001 001131 MOVB #1,$ERMAX ;:ALLOW ONE ERROR PER TEST
;:INITIALIZE THE 'T-BIT' TRAP VECTOR. THEN LOAD LOCATION '$RTRN', IN
;:THE 'END-OF-PASS' ($EOP) ROUTINE, WITH A 'RTI' OR 'RTT'.
005772 012737 023610 000014 MOV #RTRN,@TBITVEC ;:SET 'T' BIT VECTOR TO $RTRN
006000 012737 000340 000016 MOV #340,@TBITVEC+2 ;:LEVEL 7

```

```

006006 012737 000002 023610      MOV      #RTI,$RTRN      ;;SET $RTRN TO A RTI
006014 012737 006042 000010      MOV      #65$,@#RESVEC  ;;TRY TO DO A RTT
006022 005046                    CLR      -(SP)          ;;DUMMY PS
006024 012746 006032                    MOV      #64$,-(SP)    ;;AND PC
006030 000006                    RTT                      ;;TRY THE RTT
006032 012737 000006 023610 64$:  MOV      #RTT,$RTRN    ;;RTT IS LEGAL--SET $RTRN TO A RTT
006040 000402                    BR       66$
006042 062706 000010 65$:  ADD      #10,SP        ;;RTT ILLEGAL--CLEAN OFF THE STACK
006046 012737 000012 000010 66$:  MOV      #RESVEC+2,@#RESVEC ;;RESTORE TRAP CATCHER
006054 005037 023616                    CLR      $TBIT        ;;CLEAR 'T' BIT SWITCH
006060 012737 006060 001122      MOV      #,$LPADR      ;;INITIALIZE THE LOOP ADDRESS FOR SCOPE
006066 012737 006066 001124      MOV      #,$LPERR      ;;SETUP THE ERROR LOOP ADDRESS
                                ;;SIZE FOR A HARDWARE SWITCH REGISTER. IF NOT FOUND OR IT IS
                                ;;EQUAL TO A '-1', SETUP FOR A SOFTWARE SWITCH REGISTER.
006074 013746 000004                    MOV      @#ERRVEC, -(SP) ;;SAVE ERROR VECTOR
006100 012737 006134 000004      MOV      #67$,@#ERRVEC  ;;SET UP ERROR VECTOR
006106 012737 177570 001154      MOV      #DSWR,SWR      ;;SETUP FOR A HARDWARE SWICH REGISTER
006114 012737 177570 001156      MOV      #DDISP,DISPLAY ;;AND A HARDWARE DISPLAY REGISTER
006122 022777 177777 173024      CMP      #-1,@SWR       ;;TRY TO REFERENCE HARDWARE SWR
006130 001012                    BNE     69$            ;;BRANCH IF NO TIMEOUT TRAP OCCURRED
                                ;;AND THE HARDWARE SWR IS NOT = -1
006132 000403                    BR       68$            ;;BRANCH IF NO TIMEOUT
006134 012716 006142 67$:  MOV      #68$, (SP)    ;;SET UP FOR TRAP RETURN
006140 000002                    RTI
006142 012737 000176 001154 68$:  MOV      #SWREG,SWR     ;;POINT TO SOFTWARE SWR
006150 012737 000174 001156      MOV      #DISPREG,DISPLAY
006156 012637 000004 69$:  MOV      (SP)+,@#ERRVEC ;;RESTORE ERROR VECTOR
006162 005037 001220                    CLR      $PASS        ;;CLEAR PASS COUNT
006166 132737 000200 001233      BITB    #APTSIZE,$ENVM  ;;TEST USER SIZE UNDER APT
006174 001403                    BEQ     70$            ;;YES,USE NON-APT SWITCH
006176 012737 001234 001154      MOV      #SSWREG,SWR   ;;NO,USE APT SWITCH REGISTER
006204                    70$:
32  ;;SETUP 'TIMEOUT' TRAP VECTOR FOR UNEXPECTED BUS TIMEOUTS
33 006204 012737 005502 000004      MOV      #BADTMO,ERRVEC ;;SETUP FOR UNEXPECTED TIMEOUT
34 006212 012737 000300 000006      MOV      #PR6,ERRVEC+2 ;;LEVEL 6
35
36 .SBTTL TYPE PROGRAM NAME
   ;;TYPE THE NAME OF THE PROGRAM IF FIRST PASS
006220 005227 177777                    INC      #-1          ;;FIRST TIME?
006224 001036                    BNE     71$          ;;BRANCH IF NO
006226 022737 023544 000042      CMP      #SENDAD,@#42 ;;ACT-11?
006234 001432                    BEQ     71$          ;;BRANCH IF YES
006236 104401 006244                    TYPE    ,72$        ;;TYPE ASCIZ STRING
006242 000427                    BR       71$        ;;GET OVER THE ASCIZ
   ;;72$: .ASCIZ <CRLF>@CZRMTBO - RM05/3/2 DRIVE COMPATIBILITY TST@<CRLF>
   71$:
.SBTTL GET VALUE FOR SOFTWARE SWITCH REGISTER
006322 005737 000042                    TST     @#42        ;;ARE WE RUNNING UNDER XXDP/ACT?
006326 001012                    BNE     73$        ;;BRANCH IF YES
006330 123727 001232 000001      CMPB    $ENV,#1     ;;ARE WE RUNNING UNDER APT?
006336 001406                    BEQ     73$        ;;BRANCH IF YES
006340 023727 001154 000176      CMP     SWR,#SWREG  ;;SOFTWARE SWITCH REG SELECTED?
006346 001005                    BNE     74$        ;;BRANCH IF NO
006350 104406                    GTSWR           ;;GET SOFT-SWR SETTINGS
006352 000403                    BR       74$
006354 112737 000001 001150 73$:  MOVB    #1,$AUTOB    ;;SET AUTO-MODE INDICATOR

```

```

006362
37
38
39
40
41 006362 005037 001404          CLR      XXDP          ;CLEAR 'XXDP' LOAD DEVICE STORAGE
42 006366 122737 000016 000041  CMPB    #16,@#41      ;LOADED FROM AN RM05/3/2 ?
43 006374 001160          BNE     3$            ;ER IF NOT
44 006376 013737 000040 001404  MOV     @#40,XXDP     ;GET DEVICE INDICATOR AND NUMBER
45 006404 122737 000007 001404  CMPB    #7,XXDP      ;IS IT A VALID NUMBER ?
46 006412 103002          BHIS    1$            ;YES
47 006414 105037 001404          CLRB    XXDP          ;NO, DEFAULT TO DRIVE 0
48 006420 005737 000042          1$:    TST     @#42      ;CHAIN MODE OR ACT11 AUTO ACCEPT ?
49 006424 001425          BEQ     2$            ;BR IF NEITHER
50 006426 104401 006434          TYPE   ,76$         ;:TYPE ASCIZ STRING
    006432 000412          BR      75$         ;:GET OVER THE ASCIZ
    ;:76$: .ASCIZ <CRLF>/NOT TESTING DRIVE /
    75$:
51 006460 005046          CLR     -(SP)         ;CLEAR WORD ON STACK
52 006462 113716 001404          MOVB   XXDP,(SP)     ;GET DRIVE ADDRESS
53 006466 104403          TYPOS  ;TYPE THE ADDRESS
54 006470 001          .BYTE  1            ;ONLY 1 CHARACTER
55 006471 000          .BYTE  0            ;SUPRESS LEADING ZEROS
56 006472 104401 001207          TYPE   ,S$CRLF      ;:CR-LF
57 006476 000517          BR     3$            ;GET NUMBER OF DRIVES
58
59 006500 005227 177777          2$:    INC     #-1         ;FIRST TIME THRU HERE ?
60 006504 001114          BNE     3$            ;NO
61 006506 104401 006514          TYPE   ,78$         ;:TYPE ASCIZ STRING
    006512 000410          BR     77$         ;:GET OVER THE ASCIZ
    ;:78$: .ASCIZ <CRLF>/TO TEST DRIVE /
    77$:
62 006534 005046          CLR     -(SP)         ;CLEAR WORD ON STACK
63 006536 113716 001404          MOVB   XXDP,(SP)     ;GET DRIVE ADDRESS
64 006542 104403          TYPOS  ;TYPE DRIVE ADDRESS
65 006544 001          .BYTE  1            ;ONLY 1 CHARACTER
66 006545 000          .BYTE  0            ;SUPRESS LEADING ZEROS
67 006546 104401 006554          TYPE   ,80$         ;:TYPE ASCIZ STRING
    006552 000431          BR     79$         ;:GET OVER THE ASCIZ
    ;:80$: .ASCIZ /, HALT PROGRAM, REMOVE RRD P ACK AND REPLACE IT/<CRLF>
    79$:
68 006636 104401 006644          TYPE   ,81$         ;:TYPE ASCIZ STRING
    006642 000435          BR     3$            ;:GET OVER THE ASCIZ
    ;:81$: .ASCIZ /WITH A WORK PACK, CLEAR LOCATION 40 AND RESTART PROGRAM./<CRLF>
    3$:
72 006736 004737 022754          JSR    PC,$TKINT     ;TURN ON THE KEYBOARD INTERRUPT
73 006742 013737 001276 030324  MOV     $RMADR,RMADR ;RH/RM ADDRESS
74 006750 013737 001300 030326  MOV     $RMVEC,RMVEC ;VECTOR ADDRESS
75 006756 012705 002006          MOV     #ASNLST,R5   ;START OF AREA TO CLEAR
76 006762 005025          CLR    (R5)+
77 006764 022705 004424          CMP    #INDST,R5     ;LOOK FOR END OF CLEAR AREA
78 006770 001374          BNE    4$            ;BR IF NOT FINISHED
79 006772 012706 001100          MOV    #STACK,SP     ;SETUP THE STACK POINTER
80 006776 005037 177776          CLR    PS            ;CLEAR THE PROCESSOR STATUS WORD
81 007002 013737 001320 001352  MOV    HZ,SIXTEE     ;1/60 TH OR 1/50 TH SECOND COUNTER VALUE
82 007010 005037 001344          CLR    HOUR          ;CLEAR THE HOUR'S COUNTER
83 007014 005037 001346          CLR    MINUTE        ;CLEAR THE MINUTE'S COUNTER

```

```

84 007020 005037 001350          CLR    SECOND      ;CLEAR THE SECOND'S COUNTER
85 007024 005037 001336          CLR    CFLAG       ;CLEAR THE 'CONTROL C' FLAG
86
87                               ;ROUTINE TO DETERMINE BUFFER AREA SIZE
88
89 007030 005227 177777          SIZMEM: INC    #-1      ;SEE IF TIME TO SIZE MEMORY
90 007034 001002                    BNE    1$           ;BR IF NOT
91 007036 004737 027746          JSR    PC,$SIZE     ;SEE HOW MUCH MEMORY ON SYSTEM
92 007042 013737 030076 001332 1$:  MOV    $LSTAD,LSTAD ;SAVE THE LAST ADDRESS
93 007050 023727 001332 160000  CMP    LSTAD,#160C00 ;OVER 28K ?
94 007056 101403                    BLOS   2$           ;NO, THEN DON'T SET THE NEW LIMIT
95 007060 012737 160000 001332  MOV    #160000,LSTAD ;SET NEW LIMIT
96 007066 162737 005670 001332 2$:  SUB    #1500.*2,LSTAD ;SAVE XXDP LOADER AND ABSOLUTE LOADER
97
98                               ;SET UP THE OTHER SYSTEM DEVICES THAT THE PROGRAM WILL USE
99
100 007074 004737 021234          SETVEC: JSR    PC,CKCLK ;START THE CLOCK
101 007100 012737 177777 030264  MOV    #-1,SAVEFG   ;SET THE SAVE REGISTERS FLAG
102
103                               ;SETUP IF 'XXDP' OR 'ACT11' OPERATION
104
105 007106 005001                    MONTR: CLR    R1      ;DRIVE #
106 007110 005002                    CLR    R2      ;AVAIL TABLE INDEX
107 007112 005003                    CLR    R3      ;DRIVE# X 2
108 007114 016300 004444          1$:  MOV    BLKADR(R3),R0 ;LOAD DPB ADDRESS
109 007120 004737 021720          JSR    PC,CLRDPB   ;CLEAR DPB BLOCK
110 007124 022322                    2$:  CMP    (R3)+,(R2)+ ;INCREMENT INDEX
111 007126 005201                    INC    R1      ;NEXT DRIVE
112 007130 022701 000007          CMP    #7,R1      ;ALL DRIVE ASSIGN ?
113 007134 002367                    BGE    1$        ;NO
114
115
116                               ;ASSIGN LOGICAL DRIVES TO BE TEST IN THE PASS1 AND PASS 2
117                               ;THREE WORDS ARE USED IN THE BIT MAPS:
118                               ; ASNLST = SPECIFIES THE LOGICAL DRIVES ASSIGNED
119                               ; ASSGN1 = SPECIFIES THE LOGICAL DRIVES WILL BE TESTED IN PASS1.
120                               ; ASSGN2 = SPECIFIES THE LOGICAL DRIVES WILL BE TESTED IN PASS2.
121
122                               ;EACH LOGICAL DRIVE HAS A HISTORY FILE LABELED DIRV'Z (Z=0 TO 17)
123                               ;THE LOCATIONS LABELED $SYSNM AND $PHYRD IN THE HISTORY FILE
124                               ;STORE THE SYSTEM NAME (A TO H) AND PHYSICAL DRIVE NUMBER
125                               ; (0 TO 7).
126                               ;THE SUB-SYSTEM ADDRESS AND INTERRUPT VECTOR ARE STORED
127                               ;IN THE TABLE LABELED 'SYSADR:'.
128
129                               ;THE LOCATIONS SYSADR AND SYSADR+2 FOR SUB-SYSTEM A, SYSADR+4
130                               ;AND SYSADR+6 FOR SUBSYSTEM B , ETC, THE FIRST WORD
131                               ;IS THE SUB SYSTEM ADDRESS WHILE THE SECOND WORD IS THE VECTOR
132
133                               ;THE LOGICAL DRIVES ARE ASSIGNED FROM CONSOLE KEYBOARD.
134
135 007136 012700 002006          MOD00: MOV    #ASNLST,R0 ;ADDRESS OF 1ST BIT MAPS IN R0
136 007142 012701 004424          MOV    #INDST,R1   ;LAST ADDRESS TO CLEAR
137 007146 005020                    1$:  CLR    (R0)+      ;CLEAR CURRENT POINTED ADDRESS
138 007150 020100                    CMP    R1,R0        ;ALL DONE ?
139 007152 101375                    BHI    1$           ;NO, THEN BRANCH BACK
140 007154 012737 000101 001274  MOV    #'A,$CDW2    ;TEMP STORAGE OF SYS NAME
    
```

141							
142							
143	007162	005037	001224	MOD21	CLR	DRIVE	:TEMP STORAGE OF PHYSICAL DRIVE BIT MAP
144	007166	104401	001207		TYPE	,\$CRLF	:CR-LF
145	007172	104401	041776		TYPE	,\$MSG1	:SUB-SYSTEM
146	007176	104401	042644		TYPE	,\$QUOTM	:TYPE '' QUOTATION MARK
147	007202	104401	001274		TYPE	,\$CDW2	:SYS-NAME(A TO H)
148	007206	104401	042644		TYPE	,\$QUOTM	:TYPE '' QUOTATION MARK
149	007212	104401	042752		TYPE	,\$BLNKS1	:TYPE 1 BLANK
150	007216	104401	042006		TYPE	,\$MSG2	:DRIVE(S)
151							
152	007222	104411			RDLIN		:READ IN THE DRIVE NUMBERS
153	007224	012601			MOV	(SP)+,R1	:GET THE INPUT LINE ADDRESS
154	007226	105711		1\$:	TSTB	(R1)	:END OF STRING <CR> ?
155	007230	001437			BEQ	3\$	:YES
156	007232	004537	022410		JSR	R5,CK.OCT	:CHECK THE DIGIT MUST 0 TO 7,RETURN VALUE IN R2
157	007236	000751			BR	MOD21	:INCORRECT DRIVE NUMBER,ENTER AGAIN
158	007240	156237	030312	001224	BISB	ATABIT(R2),DRIVE	:SET THE PHYS. DRIVE BIT, R2 - DRIVE NUMBER
159	007246	022737	176700	001276	CMF	#176700,\$RMADR	:IS IT STANDARD RH/RM ADDRESS ?
160	007254	001016			BNE	2\$	:BR IF NO
161	007256	005737	001404		TST	XXDP	:IS THIS LOAD DEVICE ?
162	007262	001413			BEQ	2\$	:BR IF NO
63	007264	123702	001404		CMFB	XXDP,R2	:IS THIS THE DRIVE ?
164	007270	001010			BNE	2\$	:BR IF NO
165	007272	104401	043326		TYPE	,\$QDRIV	:TYPE ' ?DRIVE'
166	007276	010246			MOV	R2,-(SP)	:SAVE R2 FOR TYPEOUT
	007300	104403			TYPOS		:GO TYPE--OCTAL ASCII
	007302	002			.BYTE	2	:TYPE 2 DIGIT(S)
	007303	000			.BYTE	0	:SUPPRESS LEADING ZEROS
167	007304	104401	043336		TYPE	,\$LODEV	:TYPE 'IS LOAD DEVICE'
168	007310	000724			BR	MOD21	:TRY AGAIN
169	007312	005201		2\$:	INC	R1	
170	007314	105711			TSTB	(R1)	:END OF STRING <CR> ?
171	007316	001404			BEQ	3\$	:YES
172	007320	122721	000054		CMFB	#',(R1)+	:MUST BE A COMMA
173	007324	001316			BNE	MOD21	:ENTER AGAIN ,IF NOT
174	007326	000737			BR	1\$	:LOCATE NEXT DRIVE
175							
176	007330	005737	001334	3\$:	TST	CHGADR	:START AT 200 ?
177	007334	003035			BGT	MOD22	:BRANCH IF SO
178	007336	013701	001274		MOV	,\$CDW2,R1	:SYS NAME ASCII FROM A TO H
179	007342	042701	177760		BIC	#177760,R1	:LEFT ONLY 4 BITS
180	007346	005301			DEC	R1	:ADJUST INDEX VALUE
181	007350	006301			ASL	R1	:2 WORD INDEX VALUE
182	007352	006301			ASL	R1	
183	007354	062701	002014		ADD	,\$SYSADR,R1	:SYS ADDRESS TABLE ADDRESS
184	007360	010137	001272		MOV	R1,\$CDW1	:SYS ADDRESS TABLE'S ENTRY TO CDW1
185							
186	007364	005737	001224	MOD23:	TST	DRIVE	:CHECK IF ANY PHYSICAL DRIVE(S) ASSIGNED
187	007370	001416			BEQ	2\$	:BRANCH IF NONE
188	007372	013700	001272	1\$:	MOV	,\$CDW1,R0	:SYS ADDRESS TABLE ENTRY
189	007376	011037	001276		MOV	(R0),\$RMADR	:SYS ADDRESS
190	007402	016037	000002	001300	MOV	2(R0),\$RMVEC	:SYS VECTOR
191	007410	004737	036300		JSR	PC,BUSADR	:CHECK THE ADDRESS WITH THE OPERATOR
192	007414	013710	001276		MOV	,\$RMADR,(R0)	:NEW RH/RM ADDRESS INTO TABLE
193	007420	013760	001300	000002	MOV	,\$RMVEC,2(R0)	:NEW VECTOR OF RH/RM INTO TABLE
194	007426	000406		2\$:	BR	MOD11	:BRANCH TO NEXT MODULE



```

195
196 007430 013737 001276 002014 MOD22: MOV $RMADR,SYSADR ;LOAD THE SYSTEM ADDRESS TABLE
197 007436 013737 001300 002016 MOV $RMVEC,SYSADR+2 ;LOAD THE VECTOR
198
199 ;$CDW2 = ASCII NAME OF SUB SYSTEM (A TO H)
200 ;$CDW1 = ENTRY TO THE SYS ADDRESS TABLE
201 ;DRIVE = PHYSICAL DRIVES TO BE ASSIGNED
202
203 ;THIS SECTION OF CODING USES THE ABOVE PARAMETERS
204 ;TO SET UP THE BIT MAP OF ASNLST,ASSGN1,ASSGN2
205
206 007444 005737 001224 MOD11: TST DRIVE ;ANY DRIVE ASSIGN ?
207 007450 001002 BNE MOD30 ;BR IF YES
208 007452 000137 007624 JMP MOD12 ;BRANCH,IF NONE
209
210 007456 022737 177777 002006 MOD30: CMP #-1,ASNLST ;HAVE ALL 16 LOGICAL DRIVES BEEN ASSIGNED ?
211 007464 001457 BEQ 5$ ;BR IF YES
212 007466 013700 002006 MOV ASNLST,R0 ;FOUND THE AVAILABLE LOGICAL DRIVE LOCATION
213 007472 012701 000001 MOV #1,R1 ;START FROM LOGICAL DRIVE 0
214 007476 005002 CLR R2 ;INDEX VALUE
215 007500 030100 1$: BIT R1,R0 ;IS THE LOGICAL DRIVE AVAILABLE ?
216 007502 001406 BEQ 2$ ;YES
217 007504 000241 CLC
218 007506 006101 ROL R1 ;NEXT LOGICAL DRIVE
219 007510 103445 BCS 5$ ;BRANCH IF NONE IS AVAIL'ABLE
220 007512 062702 000002 ADD #2,R2 ;INCREMENT INDEX VALUE
221 007516 000770 BR 1$ ;LOCATE NEXT LOGICAL DRIVE
222 007520 016204 004444 2$: MCVB BLKADR(R2),R4 ;GET THE LOGICAL DRIVE'S HISTORY FILE
223 007524 113764 001274 000014 MOV $CDW2,$SYSNM(R4) ;LOAD THE ASCII SYS NAME
224 007532 050137 002006 BIS R1,ASNLST ;SET LOGICAL DRIVE ASSIGN BIT
225 007536 050137 002010 BIS R1,ASSGN1 ;SET PASS 1 BIT
226 007542 050137 002012 BIS R1,ASSGN2 ;SET PASS 2 BIT
227 007546 005002 CLR R2 ;DRIVE #
228 007550 136237 030312 001224 3$: BITB ATABIT(R2),DRIVE ;IS THIS DRIVE ASSIGNED ?
229 007556 001005 BNE 4$ ;BR IF YES
230 007560 005202 INC R2 ;PHYSICAL DRIVE NUMBER
231 007562 020227 000007 CMP R2,#7 ;ALL DRIVES DONE YET ?
232 007566 003770 BLE 3$ ;BR IF NO
233 007570 000415 BR 5$ ;YES, EXIT
234 007572 110214 4$: MOV R2,(R4) ;LOAD THE PHYSICAL DRIVE # INTO HISTORY FILE
235 007574 111464 000015 MOV (R4),$PHYDR(R4) ;GET PHYSICAL DRIVE NUMBER AND
236 007600 152764 000060 000015 BISB #0,$PHYDR(R4) ;MAKE IT ASCII.
237 007606 112764 000011 000016 MCVB #HT,$GAP(R4) ;MAKE UP FOR SCORE TYPE
238 007614 146237 030312 001224 BICB ATABIT(R2),DRIVE ;DEASSIGN DRIVE BIT FROM LIST
239 007622 001315 BNE MOD30 ;BRANCH IF NOT ALL DONE
240 007624 5$:
241
242 007624 005737 001334 MOD12: TST CHGADR ;200 START ?
243 007630 003100 BGT 7$ ;YES, THEN EXIT
244 007632 022737 177777 002006 1$: CMP #-1,ASNLST ;FULL HOUSE
245 007640 001474 BEQ 7$ ;YES, THEN EXIT
246 007642 104401 042651 2$: TYPE ,MSG5 ;WILL TEST
247 007646 104401 042006 TYPE ,MSG2 ;DRIVE(S)
248 007652 005003 CLR R3 ;INDEX TO LOGICAL DRIVE HISTORY FILE
249 007654 012704 000001 MOV #1,R4 ;BIT MAP OF ASNLST
250 007660 030437 002006 3$: BIT R4,ASNLST ;ASSIGNED LOGICAL DRIVE ?
251 007664 001421 BEQ 5$ ;NO
    
```

```

252 007666 016305 004444      MOV     BLKADR(R3),R5      ;LOAD THE HISTORY FILE ADDRESS
253 007672 126537 000014 001274  CMPB   $SYSNM(R5),$CDW2  ;ON THE SAME SYSTEM ?
254 007700 001005              BNE    4$                ;NO
255 007702 111546              MOVVB  (R5),-(SP)        ;TYPE THE PHYSICAL DRIVE #
256 007704 104403              TYPOS  ;
257 007706 001                .BYTE  1
258 007707 000                .BYTE  0
259 007710 104401 042752              TYPE  ,BLNKS1          ;TYPE 1 BLANK
260 007714 062703 000002 4$:    ADD   #2,R3          ;INCREMENT TO NEXT LOGICAL DRIVE
261 007720 000241              CLC
262 007722 006104              ROL   R4                ;BIT MAP OF THE NEXT LOGICAL DRIVE
263 007724 103401              BCS   5$                ;BRANCH IF ALL LOGICAL DRIVE'S CHECKED
264 007726 000754              BR    3$                ;BRANCH BACK
265 007730 104401 042664 5$:    TYPE  ,MSG6           ;ON
266 007734 104401 041776              TYPE  ,MSG1           ;SUB SYSTEM
267 007740 104401 042644              TYPE  ,QUOTM          ;TYPE "" QUOTATION MARK
268 007744 104401 001274              TYPE  ,SCDW2          ; A TO H
269 007750 104401 042644              TYPE  ,QUOTM          ;TYPE "" QUOTATION MARK
270
271 007754 005237 001274      INC    $CDW2            ;CHECK NEXT SUB SYSTEM
272 007760 122737 000110 001274  CMPB   #'H,$CDW2        ;ALL EIGHT SUB SYSTEMS CHECKED?
273 007766 103421              BLO   7$                ;YES
274 007770 104401 001207              TYPE  ,$CRLF          ;CR-LF
275 007774 104401 042670              TYPE  ,MSG7           ;ASK FOR OTHER SUB SYSTEM
276 010000 104410              RDCHR ;
277 010002 012637 001174      MOV   (SP)+,$TMP0       ;GET INPUT CHARACTER
278 010006 023727 001174 000131  CMP   $TMP0,#'Y         ;IS IT INPUT 'YES' ?
279 010014 001004              BNE   6$                ;BR IF NO
280 010016 104401 042741              TYPE  ,Y              ;TYPE 'Y' CHARACTER
281 010022 000137 007162              JMP   MOD21            ;SET UP OTHER SUB SYSTEM
282 010026 104401 042744 6$:    TYPE  ,N              ;TYPE 'N' CHARACTER
283 010032 005737 001334 7$:    TST   CHGADR           ;START AT 210
284 010036 001402              BEQ   8$                ;YES,EXECUTE PASS2 ONLY
285 010040 000137 010054              JMP   XPASS1           ;TO PASS1
286 010044 005037 002010 8$:    CLR   ASSGN1           ;CLEAR THE PASS1 BIT MAP
287 010050 000137 012460              JMP   XPASS2           ;BRANCH TO PASS2
288
289      ;PASS ONE, THE VARIABLES ARE ASSIGNED AS FOLLOWS:
290      ; $CDW1 = ADDRESS OF THE CURRENT LOGICAL DRIVE HISTORY FILE
291      ; $CDW2 = SYSTEM NAME A THROUGH H
292      ; $DEV# = CURRENT LOGICAL DRIVE #
293      ; ASNLST = ASSIGNED LOGICAL DRIVES
294      ; ASSGN1 = ASSIGNED LOGICAL DRIVES IN THIS PASS
295      ; R0 = ADDRESS OF DPB BLOCK FEEDED INTO DRIVER-HANDLER
296      ; R1 = TEMP STORAGE OF ADDRESS OF THE LOGICAL BLOCK
297
298 010054 005737 002010  XPASS1: TST   ASSGN1       ;ANY DRIVES ASSIGNED FOR PASS1
299 010060 001002              BNE   1$                ;BR IF YES, ELSE GO TO
300 010062 000137 011004              JMP   ENDX1             ;END OF PASS 1
301
302 010066 005037 001270 1$:    CLR   $DEV#            ;INDEX OF LOGICAL BLOCK
303 010072 013737 004444 001272  MOV   BLKADR,$CDW1      ;ADDRESS OF LOGICAL BLOCK 0
304 010100 112737 000101 001274  MOVR  #'A,$CDW2         ;SYS NAME STARTS FRGM A
305 010106 013737 002014 030324  MOV   SYSADR,RMADR      ;LOAD SYS-TEM A INTO
306 010114 013737 002016 030326  MOV   SYSADR+2,RMVEC    ;DIRVER-HANDLER
307 010122 013701 001272              MOV   $CDW1,R1         ;R1=ADDRESS OF LOGICAL BLOCK 1
308 010126 012777 017444 020172  MOV   #IDLEX,$RMVEC     ;RESET ALL INTERRUPT VECTOR
    
```

309	010134	005077	020170		CLR	@RMVEC+2		:CLEAR THE INTERRUPT LEVEL
310	010140	104401	001207		TYPE	,\$CRLF		:CR-LF
311	010144	104401	042021		TYPE	,\$MSG3		:** STARTING PASS 1
312	010150	104401	042664		TYPE	,\$MSG6		:ON
313	010154	104401	041776		TYPE	,\$MSG1		:SUB-SYSTEM
314	010160	104401	042644		TYPE	,\$QUOTM		:TYPE ''' QUOTATION MARK
315	010164	104401	001274		TYPE	,\$CDW2		:SYS-NAME(A TO H)
316	010170	104401	042644		TYPE	,\$QUOTM		:TYPE ''' QUOTATION MARK
317	010174	111137	001224		MOVB	(R1),DRIVE		:LOAD THE PHYSICAL DRIVE #
318	010200	104401	001207		TYPE	,\$CRLF		:CR-LF
319	010204	104401	042045		TYPE	,\$MSG4		:MOUNT PACK ON THE DRIVE
320	010210	104401	001274		TYPE	,\$CDW2		:SYS-NAME(A - H)
321	010214	113746	001224		MOVB	DRIVE,-(SP)		:TYPE THE DRIVE #
322	010220	104403			TYPOS			
323	010222	001			.BYTE	1		
324	010223	000			.B TE	0		
325	010224	104401	042752		TYPE	,\$BLNKS1		:TYPE 1 BLANK
326	010230	104401	042073		TYPE	,\$MSG8		
327	010234	104401	001207		TYPE	,\$CRLF		:CR-LF
328	010240	104401	042106		TYPE	,\$MSG9		
329	010244	104401	042752		TYPE	,\$BLNKS1		:TYPE 1 BLANK
330								
331	010250	104411		2\$:	RDLIN			:CHECK IF O.P. READY
332	010252	012602			MOV	(SP)+,R2		:LOCATE THE INPUT LINE
333	010254	105712			TSTB	(R2)		:FOLLOW BY <CR> ?
334	010256	001374			BNE	2\$		:BRANCH IF NOT
335	010260	004737	030334		JSR	PC,RMINIT		:INITIALIZE THE SUB SYSTEM
336	010264	012737	177777	030264	MOV	#-1,SAVEFG		:SAVE ALL RH/RM REGISTERS
337	010272	012737	177777	030266	MOV	#-1,SEEKFG		:DON'T DO IMPLY SEEK
338	010300	013700	001224		MOV	DRIVE,R0		:R0=PHYSICAL DRIVE # OF THE SUB SYSTEM
339	010304	105760	030206		TSTB	DRVSTA(R0)		:DRIVE EXIST AND ON LINE ?
340	010310	003467			BLE	6\$		:BRANCH IF NOT
341	010312	105760	030216		TSTB	DRVTYP(R0)		:DRIVE IS AN RM05/3/2 ?
342	010316	003464			BLE	6\$		:BRANCH IF NOT
343	010320	116037	030216	001402	MOVB	DRVTYP(R0),DTYP		:GET DRIVE TYPE TO BE TESTED
344	010326	012737	000022	001372	MOV	#18,TRKLMT		:GET LAST TRACK FOR AN RM05
345	010334	122760	000007	030216	CMPEB	#7,DRVTYP(R0)		:IS DRIVE AN RM05 ?
346	010342	001403			BEQ	3\$		:BR IF YES
347	010344	012737	000004	001372	MOV	#4,TRKLMT		:GET LAST TRACK FOR AN RM03/2
348								
349	010352	012700	004506	3\$:	MOV	#FMTDPB,R0		:DPB ADDRESS
350	010356	113710	001224		MOVB	DRIVE,(R0)		:LOAD THE DRIVE NUMBER
351	010362	012760	043456	000006	MOV	#BUFFER,\$BUF(R0)		:LOAD BUFFER ADDRESS
352	010370	012760	004526	000014	MOV	#RM.REG,14(R0)		:AREA TO SAVE ALL RH/RM REG'S
353	010376	012760	177400	000004	MOV	#-256,,\$WRDM(R0)		:WORD COUNT (NEG)
354	010404	013760	001374	000012	MOV	CYLIMT,\$CYL(R0)		:CYLINDER 822.
355	010412	113760	001372	000011	MOVB	TRKLMT,\$TRK(R0)		:GET TRACK ADDRESS
356	010420	105060	000010		CLRB	\$SEC(R0)		:SEC 0
357	010424	112760	000171	000002	MOVB	#RDDAT,\$COMND(R0)		:READ DATA COMMAND
358								
359	010432	004037	031062	4\$:	JSR	R0,RM05		:CALL THE DRIVER-HANDLER
360	010436	004506			FMTDPB			:PARAMETER ADDRESS
361	010440	000774			BR	4\$		:LOOPING IF QUEUE IS NOT SUCCESSFUL
362	010442	005737	004524	5\$:	TST	FMTDPB+16		:COMMAND DONE ?
363	010446	001775			BEQ	5\$		:BRANCH IF NOT
364	010450	100015			BPL	7\$		:BRANCH IF DONE, WITHOUT ERROR
365	010452	062737	000002	004516	ADD	#2,FMTDPB+10		:TRY NEXT SECTOR (0,2,4,6,8)

```

366 010460 122737 000010 004516      CMPB    #8.,FMTDPB+10    ;ALL FIVE SECTORS CHECKED ?
367 010466 101361                    BHI     4$              ;NO, THEN TRY AGAIN
368
369 010470 104401 001207      6$:    TYPE    ,SCRLF      ;CR-LF
370 010474 104401 042142      TYPE    ,MSG10         ;DRIVE IS NOT READY
371 010500 000137 011004      JMP     ENDX1          ;STOP THE TEST
372
373
374
375
376
377 010504 012704 043466      7$:    MOV     #BUFFER+10,R4 ;R4 ADDRESS OF BAD SPOT FILE
378 010510 022714 177777      8$:    CMP     #-1,(R4)     ;END OF BAD SPOT FILE ?
379 010514 001411                    BEQ     9$              ;YES
380 010516 022704 044456      CMP     #BUFFER+1000,R4 ;END OF BAD SPOT FILE ?
381 010522 101406                    BLS     9$              ;BRANCH IF IT IS
382 010524 004537 010636      JSR     R5,SPOTX       ;CHECK THE CYLINDER POINTED BY (R4)
383 010530 000422                    BR     11$             ;BRANCH IF BAD SPOT IN THE TEST ZONES
384 010532 062704 000004      ADD     #4,R4          ;NEXT BAD SPOT ADDRESS
385 010536 000764                    BR     8$              ;LOOPING BACK
386
387 010540 032777 000200 170406  9$:    BIT     #BIT7,@SWR    ;SWITCH 7 SET ?
388 010546 001404                    BEQ     10$            ;BRANCH IF NOT SET
389 010550 012700 004506      MOV     #FMTDPB,R0     ;DPB ADDRESS
390 010554 004737 020702      JSR     PC,PRTBAD      ;PRINT THE BAD SPOT FILE
391 010560 105760 000010      10$:   TSTB    $SEC(R0)   ;SECTOR 10 HAS BEEN READ ?
392 010564 001022                    BNE     13$            ;BRANCH IF SO
393 010566 112760 000012 000010      MOVB   #10.,$SEC(R0)  ;READ SECTOR 10
394 010574 000716                    BR     4$              ;LOOPING BACK
395
396 010576 104401 042207      11$:   TYPE    ,MSG11     ;PACK NOT ACCEPTABLE
397 010602 104401 001207      TYPE    ,SCRLF      ;CR-LF
398 010606 032777 000200 170340  BIT     #BIT7,@SWR    ;SWITCH 7 SET ?
399 010614 001404                    BEQ     12$            ;BRANCH IF NOT SET
400 010616 012700 004506      MOV     #FMTDPB,R0     ;DPB ADDRESS
401 010622 004737 020702      JSR     PC,PRTBAD      ;TYPE THE BAD SPOT FILE
402 010626 000137 010054      12$:   JMP     XPASS1       ;RESTART PASS 1
403 010632 000137 011020      13$:   JMP     TST1         ;PROCEED TO TEST 1
404
405
406
407
408
409
410
411
412
413
414
415
416
417
418
419 010636 010146      SPOTX: MOV     R1,-(SP)     ;SAVE R1 THROUGH R3
420 010640 010246      MOV     R2,-(SP)
421 010642 010346      MOV     R3,-(SP)
422

```

```

;SUBROUTINE SPOTX
;SEE IF THE CYLINDER POINTED BY (R4) IS IN THE TESTING ZONES
;BELOW:
;(0-15, 128-143, 256-271, 384-399, 512-527, 640-655, 768-783,
;112-127, 240-255, 368-383, 496-511, 624-639, 752-767, 17-32,
;145-160, 273-288, 401-416, 529-544, 657-672, 785-800 AND 620)
;CALL
;
;      JSR     R5,SPOTX     ;R4=POINT TO CYLINDER NUMBER
;      RET1    ;ERROR RET
;      RET2    ;NORMAL RET1

```

0039

SE

```

423 010644 005003          CLR      R3          ;ERROR FLAG
424 010646 005046          CLR      -(SP)       ;DUMMY PAIR
425 010650 005046          CLR      -(SP)       ;DUMMY PAIR
426 010652 005046          CLR      -(SP)       ;ZONE STARTING ADDRESS
427 010654 012746 000007  MOV      #7, -(SP)   ;SEGMENT NUMBER
428 010660 012746 000021  MOV      #17, -(SP)  ;ZONE STARTING ADDRESS
429 010664 012746 000007  MOV      #7, -(SP)   ;SEGMENT NUMBER
430 010670 012701 000160  MOV      #12, R1     ;R1=ZONE STARTING ADDRESS
431 010674 012702 000006  MOV      #6, R2      ;R2=SEGMENT NUMBER
432 010700 021401          1$:  CMP      (R4), R1   ;CYL IN THE ZONE ?
433 010702 103410          BLO     3$           ;BRANCH IF NOT
434 010704 062701 000017  ADD      #15, R1     ;CHECK WITH THE UPPER BOND
435 010710 021401          CMP      (R4), R1   ;CYL IN THE ZONE ?
436 010712 101002          BHI     2$           ;BRANCH IF NOT
437 010714 052703 000002  BIS      #BIT1, R3   ;SET THE ERROR FLAG
438
439 010720 162701 000017  2$:  SUB      #15, R1   ;RESTORE TO THE LOWER BOND
440 010724 005302          3$:  DEC      R2         ;DECREMENT THE SEGMENT COUNT
441 010726 001403          BEQ     4$           ;ALL SEGMENT CHECKED ?
442 010730 062701 000200  ADD      #128, R1    ;ADJUST ZONE STARTING ADDRESS
443 010734 000761          BR      1$           ;LOOPING BACK UNTIL ALL SEGMENTS ARE CHECKED
444
445 010736 012602          4$:  MOV      (SP)+, R2   ;POP THE NEXT SET OF ZONE PARAMETERS
446 010740 012601          MOV      (SP)+, R1
447 010742 005702          TST     R2           ;DUMMY PAIR
448 010744 001355          BNE     1$           ;BRANCH IF NOT
449 010746 005701          TST     R1           ;DUMMY PAIR
450 010750 001353          BNE     1$           ;BRANCH IF NOT
451
452 010752 021427 001154  5$:  CMP      (R4), #620. ;ON CYLINDER 620 ?
453 010756 001002          BNE     6$           ;NO
454 010760 052703 000002  BIS      #BIT1, R3   ;SET ERROR FLAG
455 010764 005703          6$:  TST     R3           ;ANY ERROR ?
456 010766 001002          BNE     7$           ;YES
457 010770 062705 000002  ADD      #2, R5      ;ADJUST FOR NORMAL RETURN
458 010774 012603          7$:  MOV      (SP)+, R3   ;RESTORE R3 THROUGH R1
459 010776 012602          MOV      (SP)-, R2
460 011000 012601          MOV      (SP)+, R1
461 011002 000205          RTS      R5          ;EXIT
462
463 011004 104401 001207  ENDX1: TYPE  , $CRLF   ;CR-LF
464 011010 104401 043044  TYPE      , $MSG21  ;DRIVE NOT ONLINE OR NOT ASSIGNED
465 011014 000177 170360  JMP      @RSTART    ;JUMP TO RESTART
466
467          ;THE FOLLOWING CODING FOR TEST 1 THROUGH TEST 4
468          ;PARAMETER IN TST 1
469          ; $CDW1 = ADDRESS OF LOGICAL DRIVE BLOCK
470          ; DRIVE = PHYSICAL DRIVE #
471          ; $DEV# = LOGICAL DRIVE # 0-17
472          ; ASSGN1 - ASSIGN LOGICAL DRIVE BIT MAP
473          ; ASNLST = ASSIGNED LOGICAL DRIVE MAP INDICATOR
474          ; $CDW2 = SYS-NAME
475
476          ; $CDW2, DRIVE ARE ONLY CHANGED IN TST1 DURING PASS 1
477          ; $DEV#, ASSGN1, $CDW1 ARE CHANGED BY THE TEST 4
478
479          ;TST 1: DIRECT OPERATOR TO MOUNT AND LOAD PACKS
    
```

```

480
481
    011020 000004
482 011022 012737 000001 001176
483 011030 012737 000001 001340
484 011036 012706 001100
485 011042 023737 001272 004444
486 011050 001551
487 011052 013701 001272
488 011056 126137 000014 001274
489 011064 001426
490 011066 116137 000014 001274
491 011074 012777 017444 017224
492 011102 005077 017222
493 011106 104401 001207
494 011112 104401 042021
495 011116 104401 042664
496 011122 104401 041776
497 011126 104401 042644
498 011132 104401 001274
499 011136 104401 042644
500 011142 111137 001224
501 011146 104401 001207
502 011152 104401 042045
503 011156 104401 001274
504 011162 113746 001224
505 011166 104403
506 011170 001
507 011171 000
508 011172 104401 042752
509 011176 104401 042073
510 011202 104401 001207
511 011206 104401 042106
512 011212 104411
513 011214 012605
514 011216 105715
515 011220 001374
516 011222 113701 001274
517 011226 042701 177760
518 011232 005301
519 011234 006301
520 011236 006301
521 011240 016137 002014 030324
522 011246 016137 002016 030326
523 011254 004737 030334
524 011260 012737 177777 030264
525 011266 012737 177777 030266
526 011274 013700 001224
527 011300 105760 030206
528 011304 003426
529 011306 105760 030216
530 011312 003423
531 011314 122737 000007 001402
532 011322 001005
533 011324 122760 000007 030216
534 011332 001420

```

.....

```

TST1: SCOPE
MOV #1,STIMES ;:DO 1 ITERATION
MOV #1,TSTNM ;:LOAD THE TEST NUMBER
MOV #STACK,SP ;:INITIALIZE THE STACK POINT
CMP $CDW1,BLKADR ;:LOGICAL DRIVE 0
BEQ 6$ ;:THEN EXIT
MOV $CDW1,R1 ;:R1=LOGICAL DRIVE BLOCK ADDRESS
CMPB $SYSNM(R1),$CDW2 ;:STILL ON THE SAME SYSTEM ?
BEQ 1$ ;:THEN ,EXIT
MOVB $SYSNM(R1),$CDW2 ;:LOAD THE NEW SUB SYSTEM NAME
MOV #IDLEX,@RMVEC ;:RESET THE INTERRUPT VECTOR
CLR @RMVEC+2 ;:CLEAR THE INTERRUPT LEVEL
TYPE ,$CRLF ;:CR-LF
TYPE ,MSG3 ;:** STARTING PASS 1
TYPE ,MSG6 ;:ON
TYPE ,MSG1 ;:SUB-SYSTEM
TYPE ,QUOTM ;:TYPE "" QUOTATION MARK
TYPE , $CDW2 ;:SYS-NAME(A TO H)
TYPE ,QUOTM ;:TYPE "" QUOTATION MARK
1$: MOVB (R1),DRIVE ;:LOAD THE PHYSICAL DRIVE #
TYPE , $CRLF ;:CR-LF
TYPE ,MSG4 ;:MOUNT PACK ON THE DRIVE
TYPE , $CDW2 ;:SYS-NAME(A TO H)
MOVB DRIVE,-(SP) ;:THE PHYSICAL DRIVE #
TYPOS
.BYTE 1
.BYTE 0
TYPE ,BLNKS1 ;:TYPE 1 BLANK
TYPE ,MSG8 ;:AND LOAD
TYPE , $CRLF ;:CR-LF
TYPE ,MSG9

2$: RDLIN
MOV (SP)+,R5 ;:LOCATE THE READIN LINE
TSTB (R5) ;:NOT CORRECT INPUT LINE FORMAT
BNE 2$ ;:BRANCH IF NOT
MOVB $CDW2,R1 ;:LOCATE THE SYSTEM ADDRESS TABLE
BIC #177760,R1 ;:LEFT ON 4 BITS
DEC R1 ;:ADJUST THE INDEX VALUE
ASL R1 ;:FOUR WORD INDEX VALUE
ASL R1
MOV SYSADR(R1),RMADR ;:LOAD THE SYSTEM ADDRESS
MOV SYSADR+2(R1),RMVEC ;:LOAD THE SYSTEM INTERRUPT VECTOR
JSR PC,RMINIT ;:INITIALIZE THE SYSTEM
MOV #-1,SAVEFG ;:SAVE ALL RH/RM REGISTER
MOV #-1,SEEKFG ;:DON'T DO ANY IMPLY SEEK
MOV DRIVE,R0 ;:R0=PHYSICAL DRIVE #
TSTB DRVSTA(R0) ;:ON-LINE ?
BLE 5$ ;:BRANCH IF NOT
TSTB DRVTP(R0) ;:CHECK DRIVE TYPE
BLE 5$ ;:BR IF NOT AN RM05/3/2
CMPB #7,DTYP ;:WHAT WAS FIRST DRIVE TESTED ?
BNE 3$ ;:BRANCH IF AN RM02 OR RM03, ELSE
CMPB #7,DRVTP(R0) ;:SEE IF DRIVE IS STILL AN RM05.
BEQ 6$ ;:BR IF YES

```

```

535 011334 000404          BR      4$          ;ERROR ENCOUNTERED
536 011336 122760 000007 030216 3$:  CMPB   #7,DRVTP(R0) ;SEE IF DRIVE IS STILL AN RM02 OR RM03.
537 011344 001013          BNE    6$          ;BR IF YES
538 011346 104401 001207          TYPE  ,%$CRLF      ;CR-LF
539 011352 104401 043356          TYPE  ,%NOTST      ;CANNOT SELECT RM03/2'S AND RM05'S TOGETHER
540 011356 000177 170016          JMP    @RSTART     ;JUMP TO RESTART
541
542 011362 104401 001207          TYPE  ,%$CRLF      ;CR-LF
543 011366 104401 042142          TYPE  ,%MSG10     ;DRIVE NOT READY
544 011372 000612          BR     TST1        ;TRY AGAIN
545 011374          6$:

```

```

546
547          ;TEST 2
548          ;BASIC READ AND WRITE TEST
549          ;ALL LOGICAL DRIVE ACCESS CYLINDER 620
550          ;AND SECTOR ADDRESS IS CORRESPONDING TO THE LOGICAL DRIVE #
551          ;EACH LOGICAL DRIVE PERFORM WRITE AND WRITE CHECK ON ALL TRACKS,
552          ;(TRK0 - TRK4 ON AN RM03/2 AND TRK0 - TRK18 ON AN RM05)
553
554

```

```

          ;*****
          TST2:  SCOPE
555 011374 000004          MOV    #1,$TIMES      ;;DO 1 ITERATION
          011376 012737 000001 001176  MOV    #2,TSTNM      ;LOAD TEST NUMBER
556 011404 012737 000002 001340  MOV    #STACK,SP     ;INITIAL THE STACK POINTER
557 011412 012706 001100          MOV    #FMTDPB,R0    ;DPB BLOCK ADDRESS
558 011416 012700 004506          MOV    #CDW1,R1      ;ADDRESS OF THE LOGICAL DRIVE BLOCK
559 011422 013701 001272          MOV    DRIVE,(R0)    ;PHYSICAL DRIVE #
560 011426 113710 001224          MOV    $DEVM,$SEC(R0) ;LOAD THE SECTOR #,FROM THE LOGICAL DRIVE NUMBER.
561 011432 013760 001270 000010  MOV    #620,%CYL(R0) ;LOAD CYLINDER NUMBER
562 011436 012760 001154 000012  MOV    #-256,%$WRDM(R0) ;LOAD NEG WORD COUNT
563 011440 012760 001154 000012  MOV    #BUFFER,$BUF(R0) ;LOAD BUFFER ADDRESS
564 011446 012760 177400 000004  MOV    #RM.REG,14(R0) ;ADDRESS TO SAVE ALL RH/RM REG'S
565 011454 012760 043456 000006  CLR    $TRK(R0)      ;START FROM TRACK 0
566 011462 012760 004526 000014  MOV    #WRDAT,$COMND(R0) ;WRITE DATA COMMAND
567 011470 105060 000011          JSR    PC,FILBUF     ;FILL THE BUFFER WITH STANDARD PATTERN
568 011474 112760 000161 000002  JSR    R0,RM05      ;CALL THE DRIVER
569 011502 004737 021042          FMTDPB
570 011506 004037 031062          BR     2$          ;BRANCH IF NOT QUEUE SUCCESSFULLY
571 011512 004506          2$:  JSR    R0,RM05
572 011514 000774          BR     2$          ;BRANCH IF NOT QUEUE SUCCESSFULLY
573 011516 005737 004524          3$:  TST    FMTDPB+16
574 011522 001775          BEQ    3$          ;BRANCH IF NOT DONE
575 011524 012700 004506          MOV    #FMTDPB,R0    ;R0=FMTDPB ADDRESS
576 011530 004737 017452          JSR    PC,PROCESS    ;CHECK THE TERMINATION
577 011534 005760 000016          TST    16(R0)        ;ERROR FLAG SET ?
578 011542 100433          BMI    6$          ;BRANCH IF SO
579 011546 112760 000151 000002  MOV    #WCKD,$COMND(R0) ;CHANGE TO THE WRITE CHECK DATA COMMAND
580 011550 004037 031062          4$:  JSR    R0,RM05      ;CALL THE DRIVER
581 011554 004506          FMTDPB
582 011556 000774          BR     4$          ;BRANCH IF NOT QUEUE SUCCESSFULLY
583 011560 005737 004524          5$:  TST    FMTDPB+16
584 011564 001775          BEQ    5$          ;DONE ?
585 011566 012700 004506          MOV    #FMTDPB,R0    ;BRANCH IF NOT DONE
586 011572 004737 017452          JSR    PC,PROCES    ;PROCESS IF ANY ERROR HAPPENS ?
587 011576 005760 000016          TST    16(R0)        ;ERROR FLAG SET ?
588 011602 100412          BMI    6$          ;BRANCH IF SO
589 011604 112760 000161 000002  MOV    #WRDAT,$COMND(R0) ;RESET TO WRITE DATA COMMAND
590 011612 105260 000011          INCB   $TRK(R0)      ;INCREMENT TO THE NEXT TRACK
591 011616 126037 000011 001372  CMPB   $TRK(R0),TRKLMT ;ALL TRACKS DONE ?

```

```

590 011624 003730          BLE      2$          :NO
591 011626 000410          BR       TST3        :BRANCH TO NEXT TEST
592 011630 104401 001207 6$:      TYPE    ,SCLF    :CR-LF
593 011634 104401 043125          TYPE    ,HALT1
594 011640 104401 043106          TYPE    ,HALTX
595 011644 000177 167530          JMP     @RSTART     :JUMP TO RESTART
596
597
598          :TEST 3
599          :WRITE 7 ZONES FOR WRITE TEST IN PASS 2
600          :WRITE 6 ZONES FOR READ TEST IN PASS2
601          :      $DEV# = LOGICAL DRIVE #
602          :      $CDW1 = ADDRESS OF LOGICAL DRIVE HISTORY BLOCK FILE
603          :      $CDW2 = SYS NAME
604          :      DRIVE = PHYSICAL DRIVE # OF THIS LOGICAL DRIVE
605          :      PACK  = ENTRY OF TABLE-D
606          :      CMCNT = ZONE COUNT
607          :      CMSEC = DELTA CYLINDER COUNT
608          :      R4   = ENTRY POINTER OF TABLE-D, CANNOT BE DESTROYED.
609          :      R0   = ADDRESS OF FMTDPB
610
        :*****
        TST3: SCOPE
611 011650 000004          MOV     #1,$TIMES    ;;DO 1 ITERATION
        011652 012737 000001 001176  MOV     #3,TSTNM     ;LOAD THE TEST NUMBER
612 011660 012737 000003 001340  MOV     #STACK,SP    ;INITIAL THE STACK POINTER
613 011666 012706 001100          MOV     #LOGO,R4     ;ADDRESS OF TABLE-D
614 011672 012704 001406          MOV     $DEV# ,R0    ;LOGICAL DRIVE #
615 011702 001404          BEQ    2$           ;BRANCH IF LOGICAL DRIVE 0
616 011704 062704 000020 1$:      ADD     #16.,R4    ;EACH LOGICAL DRIVE TAKES 16 BYTES IN THE TABLE
617 011710 005300          DEC     R0          ;DECREMENT THE DRIVE # COUNT
618 011712 001374          BNE    1$           ;BRANCH ,UNTIL THE ENTRY IS LOCATED
619 011714 010437 001324 2$:      MOV     R4,PACK     ;SAVE THE TABLE-D ENTRY IN PACK
620          :SET UP THE FMTDPB BLOCK
621 011720 012700 004506          MOV     #FMTDPB,R0  ;ADDRESS OF FMTDPB
622 011724 113710 001224          MOV#B  DRIVE,(R0)   ;PHYSICAL DRIVE NUMBER
623 011730 112760 000161 000002  MOV#B  #WRTDAT,$COMND(R0) ;WRITE DATA COMMAND
624 011736 012760 043456 000006  MOV     #BUFFER,$BUF(R0) ;BUFFER ADDRESS
625 011744 012760 004526 000014  MOV     #RM.REG,14(R0) ;ADDRESS TO SAVE ALL RH/RM REG'S
626 011752 012760 177400 000004  MOV     #-256.,$WRDM(R0) ;NEG WORD COUNT
627 011760 013701 001270          MOV     $DEV#,R1    ;LOGICAL DRIVE #
628 011764 006301          ASL    R1           ;WORD INDEX
629 011766 016104 005322          MOV     PSEUDO(R1),R4 ;LOAD THE DATA PATTERN
630 011772 016002 000006          MOV     $BUF(R0),R2 ;BUFFER ADDRESS IN R2
631 011776 012703 000400          MOV     #256.,R3    ;POS WORD COUNT
632 012002 010422 3$:      MOV     R4,(R2)+    ;FULL THE BUFFER WITH SIGLE WORD PATTERN
633 012004 005303          DEC     R3          ;DECREMENT THE WORD COUNT
634 012006 001375          BNE    3$           ;BRANCH,UNTIL IT IS FULL
635
636
637 012010 005046          CLR     -(SP)        ;DUMY PAIR OF ZONE COUNT
638 012012 005046          CLR     -(SP)        ;DUMY STARTING CYLINDER NUMBER
639 012014 012746 000006          MOV     #6,-(SP)    ;ZONE COUNT
640 012020 012746 000160          MOV     #112.,-(SP) ;STARTING CYLINDER NUMBER
641 012024 012737 000007 001354  MOV     #7,CMCNT     ;ZONE COUNT
642 012032 005037 001356          CLR     CMCYL       ;STARTING CYLINDER NUMBER
643 012036 012737 000020 001362 4$:      MOV     #16.,CMSEC   ;DELTA CYLINDER NUMBER
644 012044 012700 004506          MOV     #FMTDPB,R0  ;R0 DPB ADDRESS
    
```



```

645 012050 013704 001324      MOV      PACK,R4      ;R4 ENTRY TO TABLE-D
646 012054 013760 001356 000012 5$:  MOV      (CMCYL,$CYL(RO) ;STARTING CYLINDER
647 012062 105060 000011      CLR      $TRK(RO)    ;STARTS FROM TRACK 0
648 012066 111460 000010 6$:  MOV      (R4),$SEC(RO) ;LOAD SECTOR NUMBER FROM TABLE-D
649 012072 004037 031062 7$:  JSR      RO,RM05     ;CALL THE DRIVER
650 012076 004506      FMTDPB
651 012100 000774      BR       7$         ;BRANCH IF QUEU IS NOTSUCCESSFUL
652 012102 005737 004524 8$:  TST      FMTDPB+16   ;DONE ?
653 012106 001775      BEQ      8$         ;BRANCH IF NOT
654 012110 012700 004506      MOV      #FMTDPB,RO
655 012114 004737 017452      JSR      PC,PROCES  ;PROCESS TO CHECK IF ANY ERROR
656 012120 005760 000016      TST      16(RO)     ;ERROR FLAG SET ?
657 012124 100453      BMI     9$         ;BRANCH IF SO
658 012126 062760 000020 000010 ADD      #16,$SEC(RO) ;WRITE TWO SECTORS ON ONE CYLINDER
659 012134 122760 000037 000010 CMP      #31,$SEC(RO) ;ALL DONE-TWO SECTORS
660 012142 103353      BHS     7$         ;BRANCH IF NOT
661 012144 111460 000010      MOV      (R4),$SEC(RO) ;RESTORE SECTOR #
662 012150 105260 000011      INCB    $TRK(RO)    ;INCREMENT TO NEXT TRACK
663 012154 126037 000011 001372 CMP      $TRK(RO),TRKLMT ;LAST TRACK ?
664 012162 003743      BLE     7$         ;NO, THEN BRANCH
665 012164 105060 000011      CLR      $TRK(RO)    ;RESTORE TO TRACK-0
666 012170 005260 000012      INC     $CYL(RO)    ;INCREMENT CYLINDER NUMBER
667 012174 005204      INC     R4         ;INCREMENT TABLE-D ENTRY
668 012176 005337 001362      DEC     CMSEC      ;DECREMENT THE DELTA CYLINDER COUNT
669 012202 001331      BNE     6$         ;BRANCH IF NOT END OF THIS BLOCK
670 012204 062760 000160 000012 ADD      #112,$CYL(RO) ;INCREMENT THE CYLINDER NUMBER TO NEXT ZONE
671 012212 016037 000012 001356 MOV      $CYL(RO),CMCYL ;INITAIL THE STARTING CYLINDER IN THE BLOCK
672 012220 005337 001354      DEC     CMCNT      ;DECREMENT THE ZONE COUNT
673 012224 001304      BNE     4$         ;LOOPING IF NOT END OF ZONE
674 012226 012637 001356      MOV      (SP)+,CMCYL ;LOAD NEW PAIR OF STARTING CYLINDER
675 012232 012637 001354      MOV      (SP)+,CMCNT ;AND ZONE COUNT
676 012236 005737 001356      TST     CMCYL      ;NOT END YET ?
677 012242 001275      BNE     4$         ;BRANCH IF NOT
678 012244 005737 001354      TST     CMCNT      ;BRANCH IF NOT END
679 012250 001272      BNE     4$         ;LOOPING BACK
680
681 012252 000410      BR      TST4       ;BRANCH TO THE NEXT TEST
682 012254 104401 001207 9$:  TYPE    ,SCLF      ;CR-LF
683 012260 104401 043176      TYPE    ,HALT2
684 012264 104401 043106      TYPE    ,HALTX
685 012270 000177 167104      JMP     @RSTART    ;JUMP TO RESTART
686
687
688
689
690
691
692
693

```

```

:TEST 4
:UPDATE THE PARAMETERS,$CDW1,$DEVM,ASSGN1
:DIRECT THE OPERATOR TO DISMOUNT PACK AND LOAD TO OTHER DRIVE
:
:$CDW2,DRIVE ARE CHANGED BY TEST ONE ONLY AFTER THE TEST LOOPING TO TEST1
:
:*****

```

```

012274 000004
694 012276 012737 000001 001176 TST4: SCOPE
012276 012737 000004 001340      MOV      #1,$TIMES ;:DO 1 ITERATION
695 012304 012737 000004      MOV      #4,TSTNM  ;:LOAD THE TEST NUMBER
696 012312 012706 001100      MOV      #STACK,SP ;:LOAD THE STACK POINTER
697 012316 012777 017444 016002      MOV      #IDLE,@RMVEC ;:RESET THE INTERRUPT VECTOR
698 012324 005077 016000      CLR      @RMVEC+2  ;:CLEAR THE INTERRUPT LEVEL
699 012330 104401 001207      TYPE    ,SCLF      ;:CR-LF
012334 104401 042272      TYPE    ,MESG12    ;:UNLOAD DRIVE

```

```

700 012340 104401 001274      TYPE      ,SCDW2      ;SYS-NAME(A - H)
701 012344 013746 001224      MOV        DRIVE,-(SP) ;PHYSICAL DRIVE #
702 012350 104403              TYPOS
703 012352      001          .BYTE      1
704 012353      000          .BYTE      0
705 012354 104401 042310      TYPE      ,MSG13
706 012360 012701 000001      MOV        #1,R1
707 012364 005002              CLR        R2
708 012366 020237 001270      1$:      CMP        R2,$DEVM  ;LOCATE THE CORESPONDING BIT MAP
709 012372 001404              BEQ        2$          ;BRANCH IF LOCATED
710 012374 000241              CLC
711 012376 006101              ROL        R1          ;LOCATE NEXT DRIVE
712 012400 005202              INC        R2          ;
713 012402 000771              BR         1$          ;NEXT DRIVE #
714 012404 040137 002010      2$:      BIC        R1,ASSGN1 ;LOCATE THE BIT MAP
715 012410 001410              BEQ        4$          ;DEASSIGN THE LOGICAL DRIVE FOR PASS 1
716 012412 005202              3$:      INC        R2          ;NO MORE DRIVES
717 012414 006302              ASL        R2          ;GET NEXT LOGICAL DRIVE #
718 012416 016237 004444 001272      MOV        BLKADR(R2),SCDW1 ;WORD INDEX
719 012424 006202              ASR        R2          ;LOAD THE NEW DPB ADDRESS
720 012426 010237 001270      MOV        R2,$DEVM   ;RESTORE R2
721                                ;LOAD THE NEW LOGICAL DRIVE #
722 012432 104411      4$:      RDLIN
723 012434 012605      MOV        (SP)+,R5   ;WAIT UNTIL IT IS DONE
724 012436 105715      TSTB      (R5)       ;LOCATE THE INPUT LINE
725 012440 001374      BNE       4$         ;TERMINATOR ?
726 012442 005737 002010      TST      ASSGN1     ;BRANCH IF NOT
727 012446 001002              BNE       5$         ;OTHER DRIVES ?
728 012450 000137 012460      JMP      XPASS2     ;BRANCH IF MORE DRIVES IN TEST
729 012454 000137 011020      5$:      JMP      TST1       ;BRANCH TO PASS 2
730                                ;JUMP TO TEST 1
731
732                                ;XPASS2
733                                INITILIZE FOR PASS 2 TEST
734                                ;
735                                $CDW1 = ADDRESS OF THE CURRENT LOGICAL DRIVE HISTORY FILE
736                                $CDW2 = SYSTEM NAME A THROUGH H
737                                $DEVM = CURRENT LOGICAL DRIVE # 0 TO 15.
738                                ASSGN2 = ASSIGNED LOGICAL DRIVE FOR PASS 2
739                                ASNLST = ASSIGNED LOGICAL DRIVE
740                                DRIVE = PHYSICAL DRIVE # OF CURRENT RH/RM SYSTEM
741 012460 005737 002012      XPASS2: TST      ASSGN2 ;ANYTHING IN TEST FOR PASS 2
742 012464 001002              BNE       1$         ;YES, THEN GO ON
743 012466 000137 017146      JMP      XEND2      ;JUMP TO END OF PASS 2
744
745 012472 005037 001270      1$:      CLR        $DEVM     ;START FROM LOGICAL DRIVE 0
746 012476 013737 004444 001272      MOV        BLKADR,$CDW1 ;ADDRESS OF LOGICAL BLOCK DRIVE 0
747 012504 112737 000101 001274      MOVB      #'A,$CDW2   ;LOAD SYSTEM NAME 'A'
748 012512 013737 000114 030324      MOV        SYSADR,RMADR ;LOAD SYSTEM-A ADDRESS TO DRIVER
749 012520 013737 002016 030326      MOV        SYSADR+2,RMVEC ;LOAD SYSTEM-A VECTOR TO DRIVER
750 012526 013701 001272      MOV        $CDW1,R1   ;R1=ADDRESS OF LOGICAL BLOCK
751 012532 012777 017444 015566      MOV        #IDLEX,@RMVEC ;RESET THE INTERRUPT VECTOR
752 012540 005077 015564      CLR        @RMVEC+2  ;RESET THE INTERRUPT LEVEL
753 012544 005037 001376      CLR        FAULT     ;CLEAR THE NOT COMPATIBLE FLAG
754 012550 104401 001207      TYPE      ,SCRLF    ;CR-LF
755 012554 104401 042356      TYPE      ,MSG14    ;START THE PASS 2
756 012560 104401 042664      TYPE      ,MSG6     ;ON
    
```

0045

SEQ 0056

```

757 012564 104401 041776      TYPE      ,MSG1      ;SUB-SYSTEM
758 012570 104401 042644      TYPE      ,QUOTM     ;TYPE "" QUOTATION MARK
759 012574 104401 001274      TYPE      ,SCDW2     ;SYS-NAME(A TO H)
760 012600 104401 042644      TYPE      ,QUOTM     ;TYPE "" QUOTATION MARK
761 012604 111137 001224      MOVVB    (R1),DRIVE ;LOCATE THE PHYSICAL DRIVE #
762 012610 104401 001207      TYPE      ,SCRLF     ;CR-LF
763 012614 104401 042045      TYPE      ,MSG4      ;MOUNT PACK ON DRIVE
764 012620 104401 001274      TYPE      ,SCDW2     ;SYSTEM NAME
765 012624 111146      MOVVB    (R1),-(SP)
766 012626 104403      TYPOS
767 012630      .BYTE    1
768 012631      .BYTE    0
769 012632 104401 042752      TYPE      ,B_NKS1     ;TYPE 1 BLANK
770 012636 104401 042073      TYPE      ,MSG8      ;AND LOAD
771 012642 104401 001207      TYPE      ,SCRLF     ;CR-LF
772 012646 104401 042106      TYPE      ,MSG9      ;TYPE <CR> WHEN DRIVE IS READY
773
774 012652 104411      2$:      RDLIN
775 012654 012602      MOV      (SP)+,R2    ;LOCATE THE HEAD IN LINE
776 012656 105712      TSTB    (R2)        ;CARRIAGE RETURN ?
777 012660 001374      BNE     2$          ;BR IF NO
778 012662 004737 030334      JSR     PC,RMINIT
779 012666 012737 177777 030264      MOV     #-1,SAVEFG  ;SAVE ALL RH/RM REGISTERS
780 012674 012737 177777 030266      MOV     #-1,SEEKFG  ;DON'T DO IMPLY SEEK
781 012702 013700 001224      MOV     DRIVE,RO    ;LOAD THE PHYSICAL DRIVE NUMBER
782 012706 105760 030206      TSTB    DRVSTA(RO)  ;DRIVE EXISTS AND ON-LINE ?
783 012712 003421      BLE     4$          ;BRANCH IF NOT
784 012714 105760 030216      TSTB    DRVTyp(RO)  ;CHECK DRIVE TYPE
785 012720 003416      BLE     4$          ;BR IF NOT AN RM05/3/2
786 012722 116037 030216 001402 3$:      MOVVB   DRVTyp(RO),DTYP ;GET DRIVE TYPE TO BE TESTED
787 012730 012737 000022 001372      MOV     #18,,TRKLMT ;GET LAST TRACK FOR AN RM05
788 012736 122760 000007 030216      CMPB    #7,DRVTyp(RO) ;IS DRIVE AN RM05 ?
789 012744 001412      BEQ     5$          ;BR IF YES
790 012746 012737 000004 001372      MOV     #4,,TRKLMT  ;GET LAST TRACK FOR AN RM03/2
791 012754 000406      BR      5$
792
793 012756 104401 001207      4$:      TYPE    ,SCRLF     ;CR-LF
794 012762 104401 042142      TYPE    ,MSG10     ;DRIVE IS NOT READY
795 012766 000137 011004      JMP     ENDX1
796 012772      5$:
797
798      ;      $CDW1    = ADDRESS OF CURRENT LOGICAL DRIVE BLOCK,ONLY CHANGED BY TST9
799      ;      $CDW2    = SYSTEM-NAME, ONLY CHANGED BY TEST 5
800      ;      $DEVM    = CURRENT LOGICAL DRIVE #
801      ;      ASSGN2   = ASSIGNED LOGICAL DRIVE'S BIT MAP FOR PASS 2
802      ;      DRIVE    = PHYSICAL DRIVE #
803      ;      ASNLST   = ASSIGNED LOGICAL DRIVE IN THE TEST
804
805      ;IN TEST 5 DIRECT OPERATOR TO CHANGE, LOAD THE PACK
806
807      ;*****
TSTS:  SCOPE
808 012772 000004      MOV     #1,$TIMES   ;;DO 1 ITERATION
809 012774 012737 000001 001176      MOV     #5,TSTNM    ;LOAD THE TEST NUMBER
810 013002 012737 000005 001340      MOV     #STACK,SP   ;LOAD THE STACK POINTER
811 013010 012706 001100      CMP     $CDW1,BLKADR ;LOGICAL DRIVE 0
013014 023737 001272 004444      BEQ     6$          ;THEN EXIT
    
```

812	013024	013701	001272		MOV	\$CDW1,R1	:ADDRESS OF THE HISTORY FILE
813	013030	126137	000014	001274	(MPB	\$SYSNM(R1),\$CDW2	:ON THE SAME SUB-SYSTEM
814	013036	001443			BEQ	1\$	:THEN DON'T UPDATE SYSTEM ADDRESS
815	013040	116137	000014	001274	MOVB	\$SYSNM(R1),\$CDW2	
816	013046	012777	017444	015252	MOV	#IDLEX,@RMVEC	:RESET THE INTERRUPT VECTOR
817	013054	005077	015250		CLR	@RMVEC+2	:CLEAR THE INTERRUPT LEVEL
818	013060	013700	001274		MOV	\$CDW2,R0	:LOCATE SYSTEM ADDRESS TABLE
819	013064	005300			DEC	R0	:ADJUST FOR INDEX FORM 0
820	013066	042700	177760		BIC	#177760,R0	:LEFT ON FOUR BITS
821	013072	006300			ASL	R0	
822	013074	006300			ASL	R0	:INDEX FOR TWO WORD
823	013076	016037	002014	030324	MOV	SYSADR(R0),RMADR	:SYSTEM ADDRESS
824	013104	016037	002016	030326	MOV	SYSADR+2(R0),RMVEC	:SYSTEM INTERRUPT VECTOR
825	013112	104401	001207		TYPE	,\$CRLF	:CR-LF
826	013116	104401	042356		TYPE	,\$MSG14	:START THE PASS 2
827	013122	104401	042664		TYPE	,\$MSG6	:ON
828	013126	104401	041776		TYPE	,\$MSG1	:SUB-SYSTEM
829	013132	104401	042644		TYPE	,\$QUOTM	:TYPE "" QUOTATION MARK
830	013136	104401	001274		TYPE	,\$CDW2	:SYS-NAME(A TO H)
831	013142	104401	042644		TYPE	,\$QUOTM	:TYPE "" QUOTATION MARK
832	013146	111137	001224	1\$:	MOVB	(R1),DRIVE	:LOCATE THE PHYSICAL DRIVE #
833	013152	104401	001207		TYPE	,\$CRLF	:CR-LF
834	013156	104401	042045		TYPE	,\$MSG4	:MOUNT PACK ON DRIVE
835	013162	104401	001274		TYPE	,\$CDW2	:SYSTEM NAME
836	013166	111146			MOVB	(R1),-(SP)	
837	013170	104403			TYPOS		
838	013172	001			.BYTE	1	
839	013173	000			.BYTE	0	
840	013174	104401	042752		TYPE	,\$BLNKS1	:TYPE 1 BLANK
841	013200	104401	042073		TYPE	,\$MSG8	:AND LOAD
842	013204	104401	001207		TYPE	,\$CRLF	:CR-LF
843	013210	104401	042106		TYPE	,\$MSG9	:TYPE <CR> WHEN DRIVE IS READY
844							
845	013214	104411		2\$:	RDLIN		
846	013216	012602			MOV	(SP)+,R2	:LOCATE THE READ IN LINE
847	013220	105712			TSTB	(R2)	:CARRIAGE RETURN ?
848	013222	001374			BNE	2\$	:BR IF NO
849	013224	004737	030334		JSR	PC,RMINIT	
850	013230	012737	177777	030264	MOV	#-1,SAVEFG	:SAVE ALL RH/RM REGISTERS
851	013236	012737	177777	030266	MOV	#-1,SEEKFG	:DON'T DO IMPLY SEEK
852	013244	013700	001224		MOV	DRIVE,R0	:LOAD THE PHYSICAL DRIVE NUMBER
853	013250	105760	030206		TSTB	DRVSTA(R0)	:DRIVE EXISTS AND ON-LINE ?
854	013254	003426			BLE	5\$	:BRANCH IF NOT
855	013256	105760	030216		TSTB	DRVTYP(R0)	:CHECK DRIVE TYPE
856	013262	003423			BLE	5\$	:BR IF NOT AN RM05/3/2
857	013264	122737	000007	001402	(MPB	#7,DTYP	:WHAT WAS FIRST DRIVE TESTED ?
858	013272	001005			BNE	3\$	:BRANCH IF AN RM02 OR RM03, ELSE
859	013274	122760	000007	030216	(MPB	#7,DRVTYP(R0)	:SEE IF DRIVE IS STILL AN RM05.
860	013302	001420			BEQ	6\$	:BR IF YES
861	013304	000404			BR	4\$	:ERROR ENCOUNTERED
862	013306	122760	000007	030216	3\$:	(MPB	#7,DRVTYP(R0)
863	013314	001013			BNE	6\$	:BR IF YES
864	013316	104401	001207	4\$:	TYPE	,\$CRLF	:CR-LF
865	013322	104401	043356		TYPE	,\$NOTST	:CANNOT SELECT RM03/2'S AND RM05'S TOGETHER
866	013326	000177	165046		JMP	@RSTART	:JUMP TO RESTART
867							
868	013332	104401	001207	5\$:	TYPE	,\$CRLF	:CR-LF

869 013336 104401 042142  
 870 013342 000613  
 871 013344  
 872  
 873  
 874  
 875  
 876  
 877  
 878  
 879  
 880  
 881  
 882  
 883  
 884  
 885  
 886  
 887  
 888  
 889  
 890  
 891  
 892  
 893  
 894  
 895  
 896  
 013344 000004  
 013346 012737 000001 001176  
 897 013354 012737 000006 001340  
 898 013362 012706 001100  
 899 013366 012703 002056  
 900 013372 012704 003216  
 901 013376 005023  
 902 013400 020403  
 903 013402 101375  
 904  
 905 013404 012700 004506  
 906 013410 013701 001272  
 907 013414 113710 001224  
 908 013420 012760 160000 000004  
 909 013426 005060 000010  
 910 013432 112760 000161 000002  
 911 013440 013760 001270 000012  
 912 013446 012760 043456 000006  
 913 013454 012760 004526 00C014  
 914 013462 013702 001270  
 915 013466 006302  
 916 013470 016202 005322  
 917 013474 016003 000006  
 918 013500 012704 020000  
 919 013504 010223  
 920 013506 005304  
 921 013510 001375  
 922  
 923

```

TYPE .MSG10 ;DRIVE IS NOT READY
BR IST5 ;TRY AGAIN

6$:
: DRIVE = PHYSICAL DRIVE NUMBER
: $CDW1 = DPB BLOCK OF THIS LOGICAL DRIVE
: $DEV# = LOGICAL DRIVE #
: $CDW2 = SUB-SYSTEM NAME
: RMADR = SUB-SYSTEM BASE REGISTER ADDRESS
: RMVEC = SUB-SYSTEM INTERRUPT VECTOR

:THE ABOVE PARAMETERS CANNOT BE MODIFIED BY THIS TEST (TST6)
:THE FOLLOWING REG'S ARE ASSIGNED AS:
: R0 = ADDRESS OF DPB FIELD INTO DRIVER HANDLER=FMTDPB
: R1 = ADDRESS OF THE HISTORY FILE BLOCK OF THE LOGICAL DRIVE-$CDW1

:IN TEST 6, EACH LOGICAL DRIVE WRITES 7 CYLINDERS ON EACH TRACK WITH
:A UNIQUE DATA PATTERN. THESE 7 CYLINDERS HAVE BEEN WRITTEN BY OTHER
:DRIVES IN PASS 1.
:THEN, THIS LOGICAL DRIVE EXECUTES 'WRITE CHECK DATA' TO SEE IF THIS
:LOGICAL DRIVE CAN OVER-WRITE ALL DATA WRITTEN BY OTHER DRIVES.

:THESE 7 CYLINDERS ARE SPECIFIED AS $DEV#, $DEV#+128, $DEV#+256, $DEV#+384,
:$DEV#+512, $DEV#+640 AND $DEV#+768.

:THE OVER-WRITE TEST IS PERFORMED WITH OFFSETS IN BOTH DIRECTIONS.

:*****
TST6: SCOPE
MOV #1,$TIMES ;DO 1 ITERATION
MOV #6,$TIM# ;LOAD TEST NUMBER
MOV #STACK,$SP ;INITIAL THE STACK POINT
MOV #OVWNO,$R3 ;1 ST ADDRESS TO CLEAR
MOV #RDNO,$R4 ;LAST ADDRESS+?
1$: CLR (R3)+ ;RESET ALL SCORE BOARD
CMP R4,$R3 ;ALL LOCATIONS ARE CLEARED ?
BHI 1$ ;BRANCH IF NOT

MOV #FMTDPB,$R0 ;SET UP STARTING ADDRESS OF DPB
MOV $CDW1,$R1 ;HISTORY FILE BLOCK
MOVB DRIVE,$(R0) ;LOAD THE PHYSICAL DRIVE #
MOV #-8192,$WRDM,$R0 ;LOAD THE WORD COUNT (ONE TRACK)
CLR $SEC,$(R0) ;START FROM TRACK = 0, SECTOR 0
MOVB #WRDAT,$COMND,$(R0) ;WRITE DATA COMMAND
MOV $DEV#,$CYL,$(R0) ;LOAD THE STARTING CYLINDER
MOV #BUFFER,$BUF,$(R0) ;LOAD THE BUFFER ADDRESS
MOV #RM,$REG,14,$(R0) ;REG'S SAVE ADDRESS
MOV $DEV#,$R2 ;LOCATE THE DATA PATTERN
ASL R2 ;WORD INDEX
MOV PSEUDO,$(R2),R2 ;LOAD R2 WITH THE DATA PATTERN POINTER
MOV $BUF,$(R0),R3 ;BUFFER ADDRESS
MOV #-8192,$R4 ;WORD COUNT
2$: MOV R2,$(R3)+ ;FILL THE BUFFER
DEC R4 ;DECREMENT WORD CTR
BNE 2$ ;BRANCH IF NOT DONE

;START TO WRITE ONE CYLINDER ON EACH TRACK OF EACH WRITE CURRENT ZONE
  
```

```

924                                     ;(7 ZONES ON EACH PACK)
925
926 013512 004037 031062 3$: JSR    RO,RM05      ;CALL THE DRIVER
927 013516 004506          FMTDPB      ;PARAMETER BLOCK
928 013520 000774          BR        3$      ;BRANCH IF QUEUE FAIL
929 013522 005737 004524 4$: TST    FMTDPB+16    ;WRITE COMMAND DGNF ?
930 013526 001775          BEQ        4$      ;NO, THEN WAIT
931 013530 012700 004506          MOV    #FMTDPB,RO    ;PROCESS IF ANY ERROR
932 013534 004737 017452          JSR    PC,PROCES
933 013540 005760 000016          TST    16(RO)      ;ERROR FLAG SET ?
934 013544 100010          BPL        22$     ;BRANCH IF NOT
935 013546 004737 030334          JSR    PC,RMINIT   ;INITIAL THE DRIVE
936 013552 012737 177777 030264          MOV    #-1,SAVEFG
937 013560 012737 177777 030266          MOV    #-1,SEEKFG
938 013566 105260 000011 22$: INCB   $TRK(RO)      ;NEXT TRACK
939 013572 126037 000011 001372          CMPB  $TRK(RO),TRKLMT ;LAST TRACK IS DONE ?
940 013600 003744          BLE        3$      ;NO, THEN BRANCH
941 013602 105060 000011          CLRB  $TRK(RO)      ;RESET TRACK NUMBER
942 013606 062760 000200 000012          ADD   #128,$CYL(RO) ;MOVE TO NEXT ZONE
943 013614 022760 001417 000012          CMP   #783,$CYL(RO) ;LAST ZONE IS DONE ?
944 013622 103333          BHIS  3$          ;BRANCH IF NOT
945
946                                     ;RESET THE FMTDPB BLOCK AND EXECUTE WRITE-CHECK COMMAND TO DETECT ANY
947                                     ;COMPATIBLE PROBLEM. THE FOLLOWING SUBROUTINE ARE CALLED SCORE, OFFST
948                                     ;AND MAKEUP.
949
950 013624 005037 004504          CLR   OFFCOD      ;SET NEGATIVE OFFSET DIRECTION FLAG
951 013630 012700 004506          MOV   #FMTDPB,RO  ;RO=FMTDPB ADDRESS
952 013634 005060 000010          CLR   $SEC(RO)    ;START FROM SECTOR 0, TRACK 0
953 013640 013760 001270 000012          MOV   $DEVM,$CYL(RO) ;STARTING CYLINDER NUMBER
954                                     ;TOTAL ? CYLINDERS ON ONE TRACK
955 013646 112760 000151 000002          MOVB  #WCKD,$COMND(RO) ;WRITE-CHECK-DATA COMMAND
956 013654 012760 043456 000006          MOV   #BUFFER,$BUF(RO) ;RESET BUFFER ADDRESS
957 013662 012760 004526 000014          MOV   #RM.REG,14(RO) ;ADDRESS TO SAVE RH/RM REG'S
958 013670 004037 031062 1$: JSR    RO,RM05      ;CALL THE DRIVER
959 013674 004506          FMTDPB      ;PARAMETER BLOCK ADDRESS
960 013676 000774          BR        1$      ;BRANCH IF QUEUE FAILURE
961 013700 005737 004524 2$: TST    FMTDPB+16    ;TEST IF COMMAND IS DONE ?
962 013704 001775          BEQ        2$      ;BRANCH, IF NOT
963 013706 012700 004506          MOV   #FMTDPB,RO  ;LOAD THE PARAMETER BLOCK ADDRESS
964 013712 004737 017452          JSR    PC,PROCES  ;REPORT IF ANY ERROR
965 013716 004737 015034          JSR    PC,LABAD   ;LOCATE STARTING AND ENDING SECTORS
966 013722 005760 000016          TST    16(RO)      ;ANY ERROR ?
967 013726 100011          BPL        3$      ;BRANCH IF NONE
968 013730 004737 030334          JSR    PC,RMINIT   ;INITIAL THE SYSTEM
969 013734 012737 177777 030264          MOV   #-1,SAVEFG
970 013742 012737 177777 030266          MOV   #-1,SEEKFG
971 013750 000414          BR        5$
972 013752 004737 014614 3$: JSR    PC,SCORE    ;NOT UPDATE THE SCORE
973 013756 005760 000022 4$: TST    $RMWC(RO)   ;INCREMENT SCORE
974 013762 001407          BEQ        5$      ;WORD COUNT = 0 /
975 013764 116060 000026 000010          MOVB  $RMDA(RO),$SEC(RO) ;BRANCH, IF WORD COUNT IS 0
976 013772 016060 000022 000004          MOV   $RMWC(RO),$WRDM(RO) ;UPDATE STARTING SECTOR
977 014000 000733          BR        1$      ;UPDATE WORD COUNT
978                                     ;TO READ THE REST SECTORS
979
980                                     ;THE FOLLOWING CODING TEST THE COMPATIBLE PROBLEM IN OFFSET MODE OFFCOD = 0
                                     ;(NEGATIVE) AND OFFCOD = 1(POSITIVE).
    
```

```

981
982 014002 012700 004506 5$: MOV #FMIDPB,RO ;RESET THE DPB BLOCK
983 014006 012760 160000 000004 MOV #-8192, $WRDM(RO) ;FULL TRACK WORD COUNT
984 014014 105060 000010 CLR B $SEC(RO) ;RESET TO SECTOR 0, TRACK NOT CHANGED
985 014020 012760 043456 000006 MOV #BUFFER, $BUF(RO) ;BUFFER ADDRESS
986 014026 012760 004526 000014 MOV #RM.REG, 14(RO) ;ADDRESS TO SAVE ALL RH/RM REG'S
987 014034 004537 014244 6$: JSR R5, OFFST ;CALL OFFSET
988 014040 000443 BR 10$ ;BRANCH TO NEXT CYLINDER, IF OFFSET FAILS
989 014042 004737 014476 JSR PC, MAKEUP ;CALL WRITE CHECK IN OFFSET MODE
990 014046 005737 004524 7$: TST FMIDPB+16 ;OFFSET WRITE CHECK IS DONE ?
991 014052 001775 BEQ 7$ ;BRANCH IF NOT
992
993 014054 012700 004506 MOV #FMIDPB,RO ;LOAD THE DPB ADDRESS
994 014060 004737 017452 JSR PC, PROCES ;REPORT , IF ANY ERROR
995 014064 004737 015034 JSR PC, LABAD ;LOCATE STARTING AND ENDING SECTORS
996 014070 005760 000016 TST 16(RO) ;ANY ERROR ?
997 014074 100011 BPL 8$ ;BRANCH, IF NONE
998 014076 004737 030334 JSR PC, RMINIT ;INITIAL THE SYSTEM
999 014102 012737 177777 030264 MOV #-1, SAVEFG
1000 014110 012737 177777 030266 MOV #-1, SEEKFG
1001 014116 000414 RR 10$ ;NOT UPDATE THE SCORE
1007 014120 004737 014614 8$: JSR PC, SCORE ;UPDATE THE TEST SCORE
1008 014124 005760 000022 9$: TST $RMWC(RO) ;WORD CTR = 0 ?
1009 014130 001407 BEQ 10$ ;IF WORD CTR = 0 ,BRANCH TO NEXT OP
1010 014132 116060 000026 000010 MOV B $RMDA(RO), $SEC(RO) ;UPDATE THE NEW STARTING ADDRESS
1011 014140 016060 000022 000004 MOV $RMWC(RO), $WRDM(RO) ;UPDATE THE NEW WORD COUNT
1012 014146 000732 BR 6$
1013 014150 062760 000200 000012 10$: ADD #128, $CYL(RO) ;ADJUST CYLINDER ADDRESS TO NEXT ZONE
1014 014156 022760 001417 000012 CMP #783, $CYL(RO) ;ALL 7 ZONES HAVE BEEN TESTED ?
1015 014164 103402 BLO 11$ ;BRANCH, IF ALL DONE
1016 014166 000137 013646 JMP LOOP2 ;TO NEXT WRITE CURRENT ZONE
1017 014172 013760 001270 000012 11$: MOV $DEVM, $CYL(RO) ;RESET CYLINDER ADDRESS
1018 014200 105260 000011 INCB $TRK(RO) ;INCREMENT TO NEXT TRACK
1019 014204 126037 000011 001372 CMPB $TRK(RO), TRKLMT ;ALL TRACKS ARE TESTED ?
1020 014212 003002 BGT 12$ ;BRANCH IF ALL DONE
1021 014214 000137 013646 JMP LOOP2 ;TO NEXT TRACK
1022 014220 005737 004504 12$: TST OFFCOD ;FINISHING TEST THE POSITIVE OFFSET ?
1023 014224 001005 BNE 13$ ;BRANCH IF ALL DONE
1024 014226 012737 000001 004504 MOV #1, OFFCOD ;SET POSITIVE OFFSET DIRECTION FLAG
1025 014234 000137 013630 JMP LOOP1 ;RESTART LOCATION
1026 014240 000137 015140 13$: JMP TST7 ;BRANCH TO NEXT TEST
1027
1028 ;OFFST ROUTINE
1029 ;OFFSET THE HEAD IN THE DIRECTION TOWARD SPINDLE OR AWAY FROM THE SPINDLE
1030 ;
1031 ; OFFCOD = 1, TOWARD SPINDLE (POSITIVE)
1032 ; OFFCOD = 0, AWAY FROM SPINDLE (NEGATIVE)
1033 ; DRIVE = PHYSICAL DRIVE NUMBER
1034 ; RO = DPB ADDRESS
1035 ; RETRY = 3 TIMES
1036 ;CALL
1037 ; JSR R5, OFFST
1038 ; RET1 OFFSET FAIL RETURN ADDRESS
1039 ; RET2 OFFSET SUCCESSFUL RETURN
1040
1041 014244 010146 OFFST: MOV R1, -(SP) ;SAVE ALL REGISTERS
1042 014246 010246 MOV R2, -(SP)

```

```

1043 014250 010346      MOV      R3,-(SP)
1044 014252 010446      MOV      R4,-(SP)
1045 014254 012700 004506  MOV      #FMTDPB,R0      ;R0 DPB ADDRESS
1046 014260 116046 000002  MOVVB   $COMND(R0),-(SP) ;SAVE THE I/O COMMAND
1047 014264 113710 001224  MOVVB   DRIVE,(R0)      ;LOAD THE DRIVE NUMBER
1048 014270 112760 000117 000002  MOVVB   #117,$COMND(R0) ;RETURN TO CENTER COMMAND
1049 014276 004037 031062  JSR     R0,RM05         ;CALL THE DRIVE HANDLE
1050 014302 004506      FMTDPB
1051 014304 000465      BR      6$             ;BRANCH IF QUEUE FAILS
1052 014306 005737 004524 1$:     TST     FMTDPB+16    ;COMMAND DONE ?
1053 014312 001775      BEQ     1$             ;BRANCH IF NOT
1054 014314 100461      BMI     6$             ;BRANCH IF ERROR EXIST
1055 014316 013746 177776      MOV     @#PS,-(SP)     ;SAVE THE PSW
1056 014322 012737 000240 177776  MOV     #<5*32.>,@#PS  ;LOAD PS 5
1057 014330 012700 004506      MOV     #FMTDPB,R0    ;DPB ADDRESS
1058 014334 013704 030324      MOV     RMADR,R4      ;MUSS BUS ADDRESS
1059 014340 013701 001224      MOV     DRIVE,R1      ;DRIVE NUMBER
1060 014344 010164 000010      MOV     R1,RMCS2(R4)  ;LOAD THE DRIVE NUMBER INTO CONTROLLER
1061 014350 016064 000012 000034  MOV     $CYL(R0),RMDC(R4) ;CYLINDER NUMBER
1062 014356 016064 000010 000006  MOV     $SEC(R0),RMDA(R4) ;SECTOR AND TRACK NUMBER
1063 014364 016064 000004 000002  MOV     $WRDM(R0),RMWC(R4) ;WORD COUNT
1064 014372 016064 000006 000004  MOV     $BUF(R0),RMBR(R4) ;BUFFER ADDRESS
1065 014400 012637 177776      MOV     (SP)+,@#PS    ;LOAD THE PSW BACK
1066 014404 112760 000200 000001  MOVVB   #BIT7,$FMT(R0) ;LOAD THE OFFSET DIRECTION
1067 014412 005737 004504      TST     OFFCOD        ;NEG ?
1068 014416 001003      BNE     2$             ;BRANCH IF NOT
1069 014420 112760 000000 000001  MOVVB   #0,$FMT(R0)   ;CHANGE TO OTHER DIRECTION
1070 014426 112760 000115 000002 2$:     MOVVB   #115,$COMND(R0) ;LOAD THE OFFSET COMMAND
1071 014434 004037 031062  JSR     R0,RM05         ;CALL THE DRIVE HANDLE
1072 014440 004506      FMTDPB
1073 014442 000406      BR      6$             ;BRANCH IF QUEUE FAILS
1074 014444 005737 004524 3$:     TST     FMTDPB+16    ;OFFSET DONE ?
1075 014450 001775      BEQ     3$             ;BRANCH IF SO
1076 014452 100402      BMI     6$             ;BRANCH IF ERROR
1077 014454 062705 000002  ADD     #2,R5          ;ADJUST RETURN ADDRESS
1078 014460 3$:
1079 014460 112637 004510 6$:     MOVVB   (SP)+,FMTDPB+$COMND ;RESTORE THE I/O COMMAND
1080 014464 012604      MOV     (SP)+,R4      ;RESTORE REG
1081 014466 012603      MOV     (SP)+,R3
1082 014470 012602      MOV     (SP)+,R2
1083 014472 012601      MOV     (SP)+,R1
1084 014474 000205      RTS     R5            ;EXIT
1085
1086
1087      ;MAKEUP ROUTINE
1088      ;THIS ROUTINE ISSUES A WRITE CHECK OR READ COMMAND TO THE SELECTED DRIVE
1089      ;IN OFFSET MODE.
1090      ;AND SET UP THE FOLLOWING PARAMETERS
1091      :
1092      :
1093      : DTUW      = PHYSICAL DRIVE NUMBER
1094      : TRNSWT   = FMTDPB
1095      : DRVACT   = 1
1096      : TIMER    = 1 SECOND
1097      :
1098      ;CALL
1099      : JSR     PC,MAKEUP
          : RET

```



```

1100
1101      ; MAIN PURPOSE OF THIS ROUTINE, TO EXECUTE A COMMAND WHILE ASSURE THAT
1102      ; THIS READ OR WRITE-CHECK COMMAND BEING EXECUTED IN OFFSET MODE.
1103      ; ROUTINES USED TD, SC, STO, ( IN DRIVE HANDLER )
1104
1105 014476 010146      MAKEUP: MOV      R1, -(SP)
1106 014500 010246      MOV      R2, -(SP)
1107 014502 010446      MOV      R4, -(SP)
1108 014504 012702 000151  MOV      #WCKD, R2      ; WRITE CHECK DATA IN TEST 6
1109 014510 022737 000010 001340  CMP      #10, TSTNM    ; ON TEST 8 ?
1110 014516 001002      BNE      1$           ; BRANCH IF NOT
1111 014520 012702 000171  MOV      #RDDAT, R2    ; READ DATA COMMAND IN TEST 8
1112 014524 005037 004524 1$: CLR      FMTDPB+16    ; CLEAR THE STATUS WORD
1113 014530 110237 004510  MOV      R2, FMTDPB+$COMND ; LOAD THE COMMAND INTO PDB
1114 014534 013737 001224 030310  MOV      DRIVE, DTUW   ; ACTIVE DRIVE NUMBER
1115 014542 012737 004506 030246  MOV      #FMTDPB, TRNSWT ; TRANSFER UNDERWAY FLAG
1116 014550 013701 001224      MOV      DRIVE, R1    ; DRIVE NUMBER
1117 014554 013704 030324      MOV      RMADR, R4    ; RH/RM BASE ADDRESS
1118 014560 112761 000001 030176  MOV      #1, DRVACT(R1) ; ACTIVE DRIVE FLAG
1119 014566 006301      ASL      R1           ; WORD INDEX
1120 014570 012761 060000 030270  MOV      #60000, TIMER(R1) ; ONE SECOND TIMER
1121 014576 006201      ASR      R1
1122 014600 010264 000000      MOV      R2, RMCS1(R4) ; ISSURE WRITE CHECK OR READ COMMAND
1123 014604 012604      MOV      (SP)+, R4    ; RESTORE REG 4, 1
1124 014606 012602      MOV      (SP)+, R2
1125 014610 012601      MOV      (SP)+, R1
1126 014612 000207      RTS      PC          ; EXIT
1:27
1128      ; SCORE ROUTINE
1129      ; ROUTINE TO UPDATE THE TEST SCORE
1130      ; TABLEX = ADDRESS OF CURRENT SCORE BOARD
1131      ; $DEV# = LOGICAL DRIVE #
1132      ; DRIVE = PHYSICAL DRIVE NUMBER
1133      ; CMSEC = END SECTOR ADDRESS
1134      ; STARSC = START SECTOR ADDRESS
1135
1136      ; CALL
1137      ; JSR      PC, SCORE
1138      ; RET
1139
1140      SCORE:
1141 014614 010146      MOV      R1, -(SP)    ;: PUSH R1 ON STACK
1142 014616 010246      MOV      R2, -(SP)    ;: PUSH R2 ON STACK
1143 014620 010346      MOV      R3, -(SP)    ;: PUSH R3 ON STACK
1144 014622 010446      MOV      R4, -(SP)    ;: PUSH R4 ON STACK
1145 014624 023737 001362 001360  CMP      CMSEC, STARSC ;: CORRECT START AND STOP ADDRESSES
1146 014632 003473      BLE      9$           ;: BRANCH IF NOT
1147 014634 022737 000010 001340  CMP      #10, TSTNM    ;: ON TEST 8
1148 014642 001011      BNE      2$           ;: BRANCH IF NOT (MUST BE TEST 6)
1149 014644 005737 004504      TST      OFFCOD       ;: NEGATIVE OFFSET ?
1150 014650 001403      BEQ      1$           ;: BRANCH IF NEGATIVE OFFSET
1151 014652 012703 003676      MOV      #RDPO, R3    ;: SCORE BOARD ADDRESS
1152 014656 000413      BR      4$
1153 014660 012703 003216 1$: MOV      #RDNO, R3    ;: SCORE BOARD ADDRESS
1154 014664 000410      BR      4$
1155 014666 005737 004504 2$: TST      OFFCOD       ;: NEGATIVE OFFSET
1156 014672 001403      BEQ      3$           ;: BRANCH, IF NEGATIVE OFFSET

```

```

1153 014674 012703 002536      MOV      #OVWPO,R3      ;SCORE BOARD ADDRESS
1154 014700 000402      BR       4$
1155 014702 012703 002056      3$: MOV      #OVWNO,R3      ;SCORE BOARD ADDRESS
1156 014706 113702 004517      4$: MOVVB   FMTDPB+$STRK,R2 ;LOAD THE TRACK NUMBER
1157 014712 005702      TST     R2             ;ON TRACK 0
1158 014714 001404      BEQ     6$             ;BRANCH IF IT IS
1159 014716 062703 000020      5$: ADD     #16.,R3      ;EACH SCORE BOARD TAKES 16 BYTES
1160 014722 005302      DEC     R2             ;LOCATED ?
1161 014724 001374      BNE     5$             ;BRANCH IF NOT
1162 014726 010337 002054      6$: MOV     R3,TABLEX    ;STORE THE TABLE STARTING ADDRESS
1163 014732 010301      MOV     R3,R1          ;RE ASSIGN REGISTERS
1164 014734 013702 001270      MOV     $DEVM,R2      ;LOGICAL DRIVE #
1165 014740 013703 001360      MOV     STARSC,R3     ;START SECTOR
1166 014744 116204 004424      MOVVB   INDST(R2),R4  ;LOCATE THE STARTING POINT FOR SCORE BOARD
1167 014750 060304      ADD     R3,R4          ;UPDATE POINTER
1168 014752 022704 000017      11$: CMP    #15.,R4     ;SHOULD POINTER BE ADJUSTED ?
1169 014756 003003      BGT     7$             ;BR IF NO
1170 014760 162704 000020      SUB     #16.,R4      ;ENTRY POINT AT THE SCORE BOARD
1171 014764 000772      BR      11$
1172 014766 060401      7$: ADD     R4,R1
1173 014770 023703 001362      8$: CMP    CMSEC,R3    ;ENDING SECTOR REACHED ?
1174 014774 002412      BLT     9$             ;BRANCH IF IT IS
1175 014776 105221      INCB   (R1)+          ;INC SCORE AND POINT TO NEXT LOGICAL DRIVE
1176 015000 005204      INC     R4             ;INCREMENT LOGICAL DRIVE #
1177 015002 005203      INC     R3             ;INCREMENT SECTOR COUNT
1178 015004 022704 000017      CMP    #15.,R4      ;TIME TO RESET TABLE ?
1179 015010 002367      BGE     8$             ;BRANCH IF NOT
1180 015012 013701 002054      MOV     TABLEX,R1   ;RESET TABLE ADDRESS
1181 015016 005004      CLR    R4             ;LOGICAL DRIVE 0
1182 015020 000763      BR      8$             ;LOOPING BACK
1183 015022      9$:
      015022 012604      MOV     (SP)+,R4      ;;POP STACK INTO R4
      015024 012603      MOV     (SP)+,R3      ;;POP STACK INTO R3
      015026 012602      MOV     (SP)+,R2      ;;POP STACK INTO R2
      015030 012601      MOV     (SP)+,R1      ;;POP STACK INTO R1
1184 015032 000207      RTS     PC
1185
1186
1187      ;LABAD ROUTINE
1188      ;LOCATE THE START SECTOR AND THE TERMINATE SECTOR OF THE PREVIOUS
1189      ;OPERATION.
1190      ; STARSC = STARTING SECTOR
1191      ; CMSEC = ENDING SECTOR
1192
1193      ; INFORMATION FROM $RMDA(FMTDPB), $RMWC(FMTDPB), $SEC(FMTDPB)
1194      ; $SEC(FMTDPB), $WRDM(FMTDPB)
1195      ;CALL
1196      ; JSR     PC,LABAD
1197      ; RET
1198
1199      LABAD:
      015034 010046      MOV     R0,-(SP)      ;;PUSH R0 ON STACK
      015036 010246      MOV     R2,-(SP)      ;;PUSH R2 ON STACK
1200 015040 012700 004506      MOV     #FMTDPB,R0   ;DPB ADDRESS
1201 015044 116002 000026      MOVVB   $RMDA(R0),R2 ;HARDWARE TERMINATING SECTOR
1202 015050 042702 177740      BIC    #177740,R2    ;CHOP OFF HIGH ORDER BITS IF ANY
1203 015054 116037 000010 001360      MOVVB   $SEC(R0),STARSC ;STARTING SECTOR ADDRESS
    
```

```

1204 015062 005702          TST      R2          ; TERMINATOR AT 0 SECTOR
1205 015064 001404          BEQ      1$          ; BRANCH IF IT IS
1206 015066 005302          DEC      R2          ; DECREMENT ONE SECTOR COUNT
1207 015070 010237 001362    MOV      R2,CMSEC    ; ENDING SECTOR ADDRESS
1208 015074 000416          BR       3$          ; EXIT
1209 015076 005760 000022    1$:      TST      $RMC(R0) ; WORD COUNT = 0
1210 015102 001410          BEQ      2$          ; BRANCH IF IT IS
1211 015104 026060 000022 000004    CMP      $RMC(R0), $RDM(R0) ; WORD COUNT CHANGED AT ALL ?
1212 015112 001004          BNE      2$          ; BRANCH IF CHANGED
1213 015114 116037 000010 001362    MOV      $SEC(R0), CMSEC ; END SECTOR = START SECTOR
1214 015122 000403          BR       3$          ; EXIT
1215 015124 112737 000037 001362    2$:      MOV      #31., CMSEC ; END AT SECTOR 31
1216 015132          3$:
015132 0126C          MOV      (SP)+, R2    ; POP STACK INTO R2
015134 012600        MOV      (SP)+, R0    ; POP STACK INTO R0
1217 015136 000207        RTS      PC
1218
1219          ; TEST 7
1220          ; SELF TEST: WRITE CYLINDERS $DEV+17, $DEV+17+128, $DEV+17+128X2, ETC.
1221          ; THEN EXECUTE WRITE CHECK TO DETECT ANY DATA OR HEADER PROBLEM
1222          ; FOR THE SELECTED LOGICAL DRIVE
1223          ; $DEV: LOGICAL DRIVE #
1224          ; DRIVE: PHYSICAL DRIVE #
1225
1226          ; *****
          TST7:  SCOPE
1227 015140 000004          MOV      #1, $TIMES ; DO 1 ITERATION
1228 015142 012737 000001 001176    JSR      PC, RMINIT ; INITIAL THE DRIVE
1229 015150 004737 030334          MOV      #-1, $SAVEFG ; SAVE THE RH/RM REG'S
1230 015154 012737 177777 030264    MOV      #-1, $SEEKFG
1231 015162 012737 177777 030266    MOV      #7, $TSTNM ; LOAD TEST NUMBER
1232 015170 012737 000007 001340    MOV      #STACK, SP ; INITIAL THE STACK
1233 015176 012706 001100          MOV      #SELF0, R2 ; CLEAR THE SELF TEST SCORE BOARDS
1234 015202 012702 004356          1$:      CLR      (R2)+
1235 015206 005022          CMP      #SELF18, R2 ; ALL DONE ?
1236 015210 022702 004422          BHIS    1$          ; BRANCH IF NOT
1237 015214 103374          MOV      #FMTDPB, R0 ; SET UP DPB
1238 015216 012700 004506          MOV      #-8192., $RDM(R0) ; LOAD FULL TRACK WORD COUNT
1239 015222 012760 160000 000004    MOV      #WRTDAT, $COMND(R0) ; WRITE DATA COMMAND
1240 015230 112760 000161 000002    CLR      $SEC(R0) ; SECTOR 0, TRACK 0
1241 015236 005060 000010          MOV      DRIVE, (R0) ; LOAD PHY. DRIVE
1242 015242 113710 001224          MOV      $DEV, R2 ; LOCATE THE STARTING CYLINDER
1243 015246 013702 001270          ADD      #17., R2
1244 015252 062702 003021          MOV      R2, $CYL(R0) ; CYLINDER ADDRESS
1245 015256 010260 000012          MOV      #BUFFER, $BUF(R0) ; RESET BUFFER ADDRESS
1246 015262 012760 043456 000006    MOV      #RM.REG, 14(R0) ; ADDRESS TO SAVE ALL RH/RM REG'S
1247 015270 012760 004526 000014    JSR      PC, FILBUF ; FILL THE BUFFER WITH WORSE CASE PATTERN
1248 015276 004737 021042          2$:      JSR      R0, RM05 ; CALL DRIVER HANDLER
1249 015302 004037 031062          FMTDPB
1250 015306 004506          BR       2$          ; BRANCH IF QUEUE FAILS
1251 015310 000774          3$:      TST      FMTDPB+16 ; ALL DONE ?
1252 015312 005737 004524          BEQ      3$          ; BRANCH IF NOT
1253 015316 001775          MOV      #FMTDPB, R0 ; REPORT IF ANY ERROR
1254 015320 012700 004506          JSR      PC, PROCES
1255 015324 004737 017452          TST      16(R0) ; ERROR FLAG SET ?
1256 015330 005760 000016          BPL     22$         ; BRANCH IF NOT
1257 015334 100010          JSR      PC, RMINIT ; INITIAL THE DRIVE

```

```

1257 015342 012737 177777 030264      MOV      #-1,SAVEFG
1258 015350 012737 177777 030266      MOV      #-1,SEEKFG
1259 015356 105260 000011      22$:    INCB     $TRK(R0)      ;NEXT TRACK
1260 015362 126037 000011 001372    CMPB     $TRK(R0),TRKLMT ;ALL TRACK ARE DONE ?
1261 015370 003744          BLE      2$              ;BRANCH IF NOT
1262 015372 005060 000010      CLR      $SEC(R0)       ;RESET SECTOR AND TRACK
1263 015376 062760 000200 000012    ADD      #128.,$CYL(R0) ;ADVANCE TO NEXT ZONE
1264 015404 022760 001440 000012    CMP      #800.,$CYL(R0) ; ALL 7 ZONES ARE DONE ?
1265 015412 103333          BHS      2$              ;BRANCH IF NOT
1266
1267          ;EXECUTE WRITE CHECK TO DETECT ANY DATA OR HEADER PROBLEM
1268
1269 015414 112760 000151 000002    MOVB     #WCKD,$COMND(R0) ;CHANGE TO WRITE CHECK COMMAND
1270 015422 012702 004356          MOV      #SELF0,R2      ;R2 POINTS TO SCORE BOARD
1271          ;CAN NOT BE DESTORIED
1272 015426 013703 001270          MOV      $DEV0,R3       ;LOCATE STARTING ADDRESS
1273 015432 062703 000021          ADD      #17.,R3
1274 015436 010360 000012          MOV      R3,$CYL(R0)    ;STARTING CYLINDER
1275 015442 005037 004504          CLR      OFFCOD        ;SET NEGATIVE OFFSET FLAG
1276 015446 004037 031062          4$:     JSR      R0,RM05  ;CALL DRIVE HANDLER
1277 015452 004506          FMTDPB
1278 015454 000774          BR       4$             ;BRANCH IF QUEUE FAILS
1279 015456 005737 004524          5$:     TST      FMTDPB+16 ;ALL DONE ?
1280 015462 001775          BEQ      5$             ;BRANCH IF NOT
1281 015464 012700 004506          MOV      #FMTDPB,R0
1282 015470 004737 017452          JSR      PC,PROCES
1283 015474 005760 000016          TST      16(R0)        ;ANY ERROR
1284 015500 100401          BMI     6$             ;YES,THEN DON'T INCREMENT SCORE
1285 015502 105212          INCB     (R2)           ;INCREMENT SCORE
1286 015504 004537 014244          6$:     JSR      R5,OFFST  ;OFFSET
1287 015510 000415          BR       8$             ;BRANCH IF OFFSET FAILS
1288 015512 004737 014476          JSR      PC,MAKEUP     ;EXECUTE WRITE CHECK IN OFFSET MODE
1289 015516 005737 004524          7$:     TST      FMTDPB+16 ;ALL DONE /
1290 015522 001775          BEQ      7$             ;BRANCH IF NOT
1291 015524 012700 004506          MOV      #FMTDPB,R0
1292 015530 004737 017452          JSR      PC,PROCES
1293 015534 005760 000016          TST      16(R0)        ;REPORT IF ANY ERROR
1294 015540 100401          BMI     8$             ;ERROR BIT SET ?
1295 015542 105212          INCB     (R2)           ;DON'T INCREMENT SCORE
1296 015544 005737 004504          8$:     TST      OFFCOD   ;INCREMENT SCORE
1297 015550 001006          BNE     9$             ;POSITIVE OFFSET IS DONE ?
1298 015552 005202          INC     R2              ;BRANCH ,IF DONE
1299 015554 012737 000001 004504    MOV      #1,OFFCOD     ;INCREMENT SCORE BOARD POINTER
1300 015562 000137 015446          JMP      4$             ;SET POSITIVE OFFSET FLAG
1301 015566 105260 000011          9$:     INCB     $TRK(R0) ;POSITIVE OFFSET TEST
1302 015572 005202          INC     R2              ;INCREMENT TO NEXT TRACK
1303 015574 126037 000011 001372    CMPB     $TRK(R0),TRKLMT ;ADVANCE SCORE BOARD POINTER
1304 015602 003004          BGT     10$            ;ALL TRACKS ARE DONE ?
1305 015604 005037 004504          CLR     OFFCOD        ;BRANCH , IF ALL DONE
1306 015610 000137 015446          JMP     4$             ;RESET OFFSET DIRECTION
1307 015614 005060 000010          10$:    CLR     $SEC(R0)    ;TRY THE NEXT TRACK
1308 015620 012702 004356          MOV     #SELF0,R2      ;TRACK 0, SECTOR 0
1309 015624 062760 000200 000012    ADD     #128.,$CYL(R0) ;RESET SCORE BOARD
1310 015632 022760 001440 000012    CMP     #800.,$CYL(R0) ;ADVANCE TO NEXT ZONE
1311 015640 103404          BLO     11$            ;ALL 7 ZONES ARE DONE ?
1312 015642 005037 004504          CLR     OFFCOD        ;BRANCH ,IF ALL DONE
1313 015646 000137 015446          JMP     4$             ;RESET OFFSET FLAG
                        ;TO NEXT ZONE

```

1314 015652 000240  
1315  
1316  
1317  
1318  
1319  
1320  
1321  
1322  
1323  
1324

11\$: NOP ;TO NEXT TEST

;TEST10 TEST 8 READ COMPATIBLE TEST  
;CYLINDERS TESTED : \$DEVN+112,\$DEVN+112+128XN N=1 TO 5  
;THIS TEST SELECT ONE CYLINDER FOR EACH LOGICAL DRIVE FROM  
;ZONE 1 TO ZONE 6

;\$DEVN = LOGICAL DRIVE #  
;DRIVE = PHYSICAL DRIVE #

::\*\*\*\*\*

015654 000004  
015656 012737 000001 001176  
1325 015664 012737 000010 001340  
1326 015672 012706 001100  
1327 015676 012702 003216  
1328 015702 005022  
1329 015704 022702 004356  
1330 015710 101374  
1331 015712 005037 004504  
1332 015716 012700 004506  
1333 015722 012760 160000 000004  
1334 015730 005060 000010  
1335 015734 112760 000171 000002  
1336 015742 012760 043456 000006  
1337 015750 012760 004526 000014  
1338 015756 113710 001224  
1339 015762 013703 001270  
1340 015766 062703 000160  
1341 015772 010360 000012  
1342 015776 004037 031062  
1343 016002 004506  
1344 016004 000774  
1345 016006 005737 004524  
1346 016012 001775  
1347 016014 012700 004506  
1348 016020 004737 017452  
1349 016024 004737 015034  
1350 016030 005760 000016  
1351 016034 100011  
1352 016036 004737 030334  
1353 016042 012737 177777 030264  
1354 016050 012737 177777 030266  
1355 016056 000414  
1361 016060 004737 014614  
1362 016064 005760 000022  
1363 016070 001407  
1364 016072 116060 000026 000010  
1365 016100 016060 000022 000004  
1366 016106 000733  
1367 016110 012700 004506  
1368 016114 012760 160000 000004  
1369 016122 105060 000010  
1370 016126 004537 014244  
1371 016132 000443  
1372 016134 004737 014476  
1373 016140 005737 004524

TST10: SCOPE  
MOV #1,\$TIMES ;:DO 1 ITERATION  
MOV #10,TSTNM ;:LOAD TEST NUMBER  
MOV #STACK,SP ;:INITAIL THE STACK POINTER  
MOV #RDNO R2 ;:CLEAR THE SCORE BOARD OF READ TEST  
1\$: CLR (R2)+  
CMP #RDP18+16.,R2 ;:ALL DONE  
BHI 1\$ ;:BRANCH IF NOT  
CLR OFFCOD ;:SET NEGATIVE OFFSET FLAG  
LOOP3: MOV #FMTDPB,R0 ;:SET UP DPB BLOCK  
MOV #-8192.,\$WRDM(R0) ;:LOAD THE WORD CTR,FULL TRACK  
CLR \$SEC(R0) ;:TRACK 0 AND SECTOR 0  
MOVB #RDDAT,\$COMND(R0) ;:LOAD THE READ DATA COMMAND  
MOV #BUFFER,\$BUF(R0) ;:RESET BUFFER ADDRESS  
MOV #RM.REG.14(R0) ;:ADDRESS TO SAVE ALL RH/RM ADDRESS  
MOVB DRIVE,(R0) ;:LOAD PHY. DRIVE ADDRESS  
MOV \$DEVN,R3 ;:LOCATE STARTING CYL  
ADD #112.,R3  
MOV R3,\$CYL(R0) ;:STARTING CYL ADDRESS  
1\$: JSR R0,RM05 ;:CALL THE DRIVE HANDLER  
FMTDPB  
BR 1\$  
2\$: TST FMTDPB+16 ;:COMMAND DONE ?  
BEQ 2\$ ;:BRANCH IF NOT  
MOV #FMTDPB,R0  
JSR PC,PROCES ;:REPORT IF ANY ERROR  
JSR PC,LABAD ;:LOACATE START AND STOP ADDRESS  
TST 16(R0) ;:ANY ERROR ?  
BPL 3\$ ;:BRANCH,IF NONE  
JSR PC,RMINIT ;:INITIAL THE SYSTEM  
MOV #-1,SAVEFG  
MOV #-1,SEEKFG  
BR 5\$ ;:NOT INCREMENT THE SCORE  
3\$: JSR PC,SCORE ;:UPDATE THE SCORE  
4\$: TST \$RMWC(R0) ;:WORD COUNT= 0  
BEQ 5\$ ;:BRANCH IIF IT IS  
MOVB \$RMDA(R0),\$SEC(R0) ;:UPDATE THE NEW STARTING SECTOR  
MOV \$RMWC(R0),\$WRDM(R0) ;:UPDATE WORD COUNT  
BR 1\$ ;:CONTINUE  
5\$: MOV #FMTDPB,R0 ;:RESET THE DPB BLOCK  
MOV #-8192.,\$WRDM(R0) ;:FULL TRACK WORD COUNT  
CLRB \$SEC(R0) ;:RESET TO SECTOR 0,TRACK NOT CHANGED  
6\$: JSR R5,OFFST ;:CALL OFFSET  
BR 10\$ ;:BRANCH IF OFFSET FAILS  
7\$: JSR PC,MAKEUP ;:EXECUTE READ DATA IN OFFSET MODE  
TST FMTDPB+16 ;:OFFSET READ IS DONE ?

```

1374 016144 001775      BEQ      7$      ;BRANCH IF NOT
1375 016146 012700 004506  MOV      #FMTDPB,R0 ;REPORT IF ANY ERROR
1376 016152 004737 017452  JSR      PC,PROCES
1377 016156 004737 015034  JSR      PC,LABAD   ;LOCATE THE START AND STOP ADDRESSES
1378 016162 005760 000016  TST      16(R0)    ;ANY ERROR ?
1379 016166 100011      BPL      8$      ;BRANCH,IF NONE
1380 016170 004737 030334  JSR      PC,RMINIT ;INITIAL THE SYSTEM
1381 016174 012737 177777 030264  MOV      #-1,SAVEFG
1382 016202 012737 177777 030266  MOV      #-1,SEEKFG
1383 016210 000414      BR       10$     ;NOT UPDATE THE SCORE
1389 016212 004737 014614 8$:      JSR      PC,SCORE ;UPDATE THE SCORE
1390 016216 005760 000022 9$:      TST      $RMWC(R0) ;WORD COUNT IS 0
1391 016222 001407      BEQ      10$     ;BRANCH IF IT IS
1392 016224 116060 000026 000010  MOVVB   $RMDA(R0),$SEC(R0) ;UPDATE SECTOR ADDRESS
1393 016232 016060 000022 000004  MOV     $RMWC(R0),$WRDM(R0) ;UPDATE WORD COUNT
1394 016240 000732      BR       6$      ;LOOPING UNTIL CURRENT TRACK IS DONE
1395 016242 062760 000200 000012 10$:     ADD     #128,$CYL(R0) ;ADJUST CYLINDER TO NEXT ZONE
1396 016250 022760 001377 000012  CMP     #767,$CYL(R0) ;ALL 6 ZONES ARE DONE ?
1397 016256 103402      BLO     1$      ;BRANCH IF ALL DONE
1398 016260 000137 015776  JMP     1$
1399
1400 016264 013703 001270 11$:     MOV     $DEV#R3      ;LOCATE STARTING CYLINDER
1401 016270 062703 000160      ADD     #112,R3
1402 016274 010360 000012      MOV     R3,$CYL(R0) ;STARTING CYLINDER
1403 016300 105260 000011      INCB   $TRK(R0)    ;TO NEXT TRACK
1404 016304 126037 000011 001372  CMPB   $TRK(R0),TRKLMT ;ALL SURFACE ARE DONE ?
1405 016312 003002      BGT     12$     ;BRANCH IF ALL DONE
1406 016314 000137 015776  JMP     1$      ;LOOPING UNTIL CURRENT TRACK IS DONE
1407
1408 016320 005737 004504 12$:     TST     OFFCOD     ;OFFSET CODE = POSITIVE ?
1409 016324 001005      BNE     13$     ;IF EQUAL,THEN ALL DONE
1410 016326 012737 000001 004504  MOV     #1,OFFCOD  ;SET POSITIVE OFFSET FLAG
1411 016334 000137 015716  JMP     LOOP3
1412 016340 000240 13$:     NOP
1413
1414      ;TEST11 TEST 9
1415      ;REPORT THE TEST SCORES
1416      ;DIRECT THE OPERATOR TO CHANGE PACK AND MOUNT TO OTHER DIRVE
1417      ;
1418      ; $DEV# = LOGICAL DRIVE #, SHOULD NOT BE UPDATED BEFORE THE
1419      ; REPORT IS COMPLETED.
1420      ;
1421      ; BADSEC = 0, (DRIVES ARE COMPATIBLE)
1422      ; = -1, (DRIVES NOT COMPATIBLE)
1423      ;
1424      ; CMTRK = TRACK NUMBER FOR CONTROLLING THE SCORE TYPING.
1425      ;
1426      ;*****
1427      TST11: SCOPE
1428      MOV     #1,$TIMES ;DO 1 ITERATION
1429      MOV     #11,TSTNM ;LOAD THE TEST NUMBER
1430      MOV     #STACK,SP ;LOAD THE STACK POINTER
1431      CLR     -(SP) ;DUMMY SCORE BOARD ADDRESSES
1432      CLR     -(SP) ;
1433      MOV     #SELF0+1,-(SP) ;POSITIVE OFFSET READ TEST SCORE ADDRESS
1434      MOV     #RDPO,-(SP) ;POSITIVE OFFSET TEST SCORE
1435      MOV     #SELF0,R2 ;NEGATIVE OFFSET READ TEST SCORE

```

```

1434 016404 012703 003216      MOV      #RDNO,R3      ;NEGATIVE OFFSET READ COMPATIBLE TEST SCORE
1435 016410 013701 001372      1$:      MOV      TRKLM1,R1      ;R1= TRACK NUMBER
1436 016414 122712 000007      2$:      CMPB     #7,(R2)      ;SELF READ TEST SCORE IS TOO LOW
1437 016420 101411                BLOS     4$            ;BRANCH IF NOT
1438 016422 012705 000020      MOV      #16.,R5      ;INCREMENT READ COMPATIBLE SCORE FOR ALL 16 DIRVES
1439 016426 111304                3$:      MOVB     (R3),R4      ;ADJUST SCORE BY ADDING 6
1440 016430 062704 000006      ADD      #6,R4
1441 016434 110423                MOVB     R4,(R3)+     ;UPDATE SCORE AND POINTS TO NEXT DRIVE
1442 016436 005305                DEC      R5            ;ALL DRIVES ARE UPDATED ?
1443 016440 001372                BNE      3$           ;BRANCH IF NOT
1444 016442 000402                BR       5$
1445 016444 062703 000020      4$:      ADD      #16.,R3      ;ADJUST POINTER OF SCORE BOARD ADDRESS
1446 016450 062702 000002      5$:      ADD      #2,R2        ;UPDATE THE SELF TEST SCORE ADDRESS
1447 016454 005301                DEC      R1            ;ALL TRACKS DONE ?
1448 016456 002356                BGE     2$            ;BRANCH IF NOT
1449 016460 012603                MOV      (SP)+,R3     ;GET NEXT PAIR
1450 016462 012602                MOV      (SP)+,R2
1451 016464 001351                BNE     1$
1452
1453
1454                                ;SET ACCEPTANCE FLAG, INITIALIZE THE TABLE POINTERS AND TRACK NUMBER
1455 016466 005037 001342      CLR      BADSEC      ;SET ACCEPTANCE FLAG
1456 016472 005037 001364      CLR      CMTRK      ;START FROM TRACK 0
1457 016476 005001                CLR      R1          ;START FROM LOG DRV 0
1458 016500 012702 002056      MOV      #OVWNO,R2   ;SCORE BOARD BASE ADDRESS
1459 016504 012703 000001      MOV      #BIT0,R3    ;BIT POSITION FOR LOG DRV 0
1460 016510 030337 002006      LOOP4:  BIT      R3,ASNLST ;IS THE LOG DRV UNDER TEST ?
1461 016514 001502                BEQ     LOOPS        ;BRANCH IF NOT
1462 016516 005037 001366      CLR      NULINE     ;NEW LINE INDICATOR
1463 016522 123701 001270      CMPB     $DEVN,R1    ;SELF SCORE ?
1464 016526 001434                BEQ     SPATH        ;BRANCH IF IT IS
1465 016530 122712 000016      KPATH:  CMPB     #14.,(R2) ;OVERWRITE NEG OFFSET < 14 ?
1466 016534 101403                BLOS     1$          ;BRANCH IF NOT
1467 016536 004537 017152      JSR      R5,PRINT    ;REPORT EXCEPTIONS
1468 016542 000001                000001 ;COLUMN POSITION ON REPORT
1469 016544 122762 000016 000460 1$:      CMPB     #14.,OVWPO-OVWNO(R2) ;OVERWRITE POS OFFSET < 14 ?
1470 016552 101403                BLOS     2$          ;BRANCH IF NOT
1471 016554 004537 017152      JSR      R5,PRINT    ;REPORT EXECPTIONS
1472 016560 000002                000002 ;COLUMN POSITION ON REPORT
1473 016562 122762 000014 001140 2$:      CMPB     #12.,RDNO-OVWNO(R2) ;READ NEG OFFSET < 6
1474 016570 101403                BLOS     3$          ;BRANCH IF NOT
1475 016572 004537 017152      JSR      R5,PRINT    ;REPORT EXCEPTIONS
1476 016576 000003                000003 ;COLUMN POSITION ON REPORT
1477 016600 122762 000014 001620 3$:      CMPB     #12.,RDPO-OVWNO(R2) ;READ POS OFFSET < 12 ?
1478 016606 101403                BLOS     4$          ;BRANCH IF NOT
1479 016610 004537 017152      JSR      R5,PRINT    ;REPORT EXECPTIONS
1480 016614 000004                000004 ;COLUMN POSITION ON REPORT
1481 016616 000441                4$:      BR       LOOPS      ;EXIT
1482
1483 016620 122712 000016      SPATH:  CMPB     #14.,(R2) ;OVERWRITE NEG OFF < 14
1484 016624 101403                BLOS     1$          ;BRANCH IF NOT
1485 016626 004537 017152      JSR      R5,PRINT    ;REPORT EXECPTION
1486 016632 000001                000001 ;COLUMN POSITION ON REPORT
1487 016634 122762 000016 000460 1$:      CMPB     #14.,OVWPO-OVWNO(R2) ;OVERWRITE POS OFFSET < 14
1488 016642 101403                BLOS     2$          ;BRANCH IF NOT
1489 016644 004537 017152      JSR      R5,PRINT    ;REPORT EXCEPTION
1490 016650 000002                000002 ;COLUMN POSITION ON REPORT

```

```

1491 016652 013704 001364      2$:  MOV    CMTRK,R4      ;LOCATE THE SELF TEST SCORE
1492 016656 006304              ASL    R4              ;WORD INDEX
1493 016660 122764 000006 004356  CMPB   #6,SELF0(R4)   ;SELF READ NEG OFFSET < 6 ?
1494 016666 101403              BLOS   3$              ;BRANCH IF NOT
1495 016670 004537 017152      JSR    R5,PRINT
1496 016674 000003              000003 ;REPORT EXCEPTIONS
1497 016676 013704 001364      3$:  MOV    CMTRK,R4      ;LOCATE THE SELF TEST SCORE
1498 016702 006304              ASL    R4              ;WORD INDEX
1499 016704 122764 000006 004357  CMPB   #6,SELF0+1(R4) ;SELF READ POS OFFSET < 6 ?
1500 016712 101403              BLOS   4$              ;BRANCH IF NOT
1501 016714 004537 017152      JSR    R5,PRINT
1502 016720 000004              000004 ;REPORT EXCEPTIONS
1503 016722              4$:              ;COLUMN POSITION FOR REPORT PRINTING
1504
1505 016722 005201      LOOP5: INC    R1              ;INCREASE THE LOGICAL DRIVE #
1506 016724 000241              CLC
1507 016726 006103              ROL    R3              ;ADJUST THE BIT POSITION
1508 016730 005202              INC    R2              ;POINTS TO NEXT DRIVE
1509 016732 022701 000017      CMP    #15.,R1        ;UPDATE SCORE BOARD BASE ADDRESS
1510 016736 103264              BHIS   LOOP4          ;ALL DRIVES ARE CHECK ?
1511 016740 005237 001364      LOOP6: INC    CMTRK     ;BRANCH IF NOT ALL DONE
1512 016744 012702 002056      MOV    #OVWNO,R2     ;NEXT TRACK
1513 016750 005001              CLR    R1              ;RESET SCORE BOARD BASE ADDRESS
1514 016752 013703 001364      MOV    CMTRK,R3     ;LOGICAL DRIVE START FROM 0
1515 016756 001404              BEQ    2$              ;LOCATE THE SCORE BOARD BASE ADDRESS
1516 016760 062702 000020      1$:  ADD    #16.,R2     ;BRANCH IF ON TRACK 0
1517 016764 005303              DEC    R3              ;FOR EACH TRACK, 16 BYTES
1518 016766 001374              BNE    1$              ;ALL TRACK DONE ?
1519 016770 012703 000001      2$:  MOV    #BIT0,R3     ;BRANCH IF NOT
1520              ;BIT MAP POSITION FOR DRIVE 0
1521              ;AT THIS POIN :
1522              : R1 = LOGICAL DRIVE # START FROM 0
1523              : R2 = ADDRESS OF SCORE BOARD BASE ADDRESS
1524              : R3 = BIT MAP, INDICATE LOGICAL DRIVE 0 1
1525
1526 016774 123737 001364 001372  CMPB   CMTRK,TRKLMT  ;ALL TRACKS ARE DONE ?
1527 017002 003642              BLF    LOOP4          ;NO
1528 017004 005737 001342      TST    @ADSEC        ;WAS SCORE PRINTED ?
1529 017010 001402              BEQ    DISMNT        ;BR IF NO
1530 017012 104401 001207      TYPE   ,SCLRF        ;CR-LF
1534
1535 017016 104401 001207      DISMNT: TYPE   ,SCLRF ;CR-LF
1536 017022 012777 017444 011276  MOV    #IDLEX,@RMVEC ;RESET THE INTERRUPT VECTOR
1537 017030 005077 011274      CLR    @RMVEC+2     ;CLEAR THE INTERRUPT VECTOR
1538 017034 104401 042272      TYPE   ,MSG12        ;UNLOAD AND DISMOUNT MESSAGE
1539 017040 104401 001274      TYPE   ,SCDW2        ;SYSTEM NAME
1540 017044 013746 001224      MOV    DRIVE,-(SP)  ;PHYSICAL DRIVE NUMBER
1541 017050 104403              TYPOS
1542 017052 001              .BYTE 1
1543 017053 000              .BYTE 0
1544 017054 104401 042310      TYPE   ,MSG13        ;MESSAGE TYPE <CR> WHEN READY
1545
1546 017060 104411      1$:  RDLIN              ;READ IN ONE LINE
1547 017062 012605      MOV    (SP)+,R5     ;LOCATE THE READ IN LINE
1548 017064 105715      TSTB   (R5)         ;CARRIAGE RETURN ?
1549 017066 001374      BNE    1$           ;BR IF NO
1550 017070 005002      DEASG: CLR    R2     ;LOGICAL DRIVE NUMBER
    
```



```

1551 017072 012703 000001      MOV      #BIT0,R3      ;BIT MAP OF ASSIGNED DRIVE
1552 017076 020237 001270      1$:     CMP      R2,$DEV      ;IS THE LOGICAL DRIVE UNDER TEST ?
1553 017102 001404              BEQ      2$           ;BRANCH IF IT IS
1554 017104 000241              CLC                    ;SHIFT THE BIT MAP FOR
1555 017106 006103              ROL      R3           ;NEXT DRIVE
1556 017110 005202              INC      R2           ;INCRFMET THE LOGICAL DRIVE #
1557 017112 000771              BR      1$           ;LOOPING ,UNTIL THE LOGICAL DRIVE LOCATED
1558 017114 040337 002012      2$:     BIC      R3,ASSGN2  ;CLEAR THE ASSIGNED BIT
1559 017120 001412              BEQ      XEND2        ;BRANCH IF NO MORE DRIVES
1560 017122 005237 001270      INC      $DEV         ;INCREMENT THE LOGICAL DRIVE #
1561 017126 013702 001270      MOV      $DEV,R2      ;UPDATE SYSTEM BLOCK ADDRESS
1562 017132 006302              ASL      R2
1563 017134 016237 004444 001272  MOV      BLKADR(R2),$CDW1 ;SYSTEM BLOCK ADDRESS
1564 017142 000137 012772      JMP      TST5         ;JUMP TO TEST 5 FOR OTHER DRIVE
1565
1566 017146 000137 023456      ^ND2:   JMP      $EOP    ;END OF PASS
1567
1568
1569      ;PRINT ROUTINE
1570      ;NAME PRINT
1571      ;PRINT EXCEPTIONS FOR TEST SCORE
1572      ;PARAMETER USED
1573      ;      NULINE = 0      A NEW LINE TO PRINT
1574      ;      = 1 - 4 COLUMN NUMBER TO PRINT THE EXCEPTION MARK
1575
1576      ;      BADSEC = 0      FIRST EXCEPTION DETECTED
1577      ;      = -1      NOT FIRST EXCEPTION (DON'T PRINT THE TITLE)
1578
1579      ;CALL
1580      JSR      R5,PRINT  COLUMN NUMBER
1581      NUMBER
1582      RET
1583
1584      ;      R1 = LOGICAL DRIVE #
1585      ;      $DEV = LOGICAL DRIVE UNDER TEST
1586      ;      R3 = BIT POSITION OF LOGICAL DRIVE IN R1
1587
1588
1589      PRINT:
1590      MOV      R1,-(SP)  ;:PUSH R1 ON STACK
1591      MOV      R2,-(SP)  ;:PUSH R2 ON STACK
1592      MOV      R3,-(SP)  ;:PUSH R3 ON STACK
1593      MOV      R4,-(SP)  ;:PUSH R4 ON STACK
1594      TST      BADSEC    ;:FIRST EXCEPTION
1595      BMI      1$        ;:BRANCH IF NOT,DON'T HAVE TO PRINT
1596      ;TITLE
1597      TYPE     ,$CRLF    ;:CRLF
1598      TYPE     ,MSG16   ;:SCORES FOR DRIVE --
1599      TYPE     ,$CDW2   ;:SYSTEM NAME
1600      MOV      DRIVE,-(SP) ;:TYPE THE PHYSICAL DRIVE #
1601      TYPOS
1602      .BYTE   1
1603      .BYTE   0
1604      TYPE     ,$CRLF    ;:CR-LF
1605      TYPE     ,$CRLF    ;:CR-LF
1606      TYPE     ,MSG17   ;:SUB TITLE 1
1607      TYPE     ,$CRLF    ;:CR-LF
    
```

```

1604 017234 104401 042546      TYPE      ,MSG18      :SUB TITLE 2
1605 017240 104401 001207      TYPE      ,$CRLF      :CR-LF
1606 017244 012737 177777 001342      MOV      #-1,BADSEC  :RESET THE ACCEPTANCE FLAG
1607 017252 012737 000001 001376      MOV      #1,FAULT   :NOT COMPATIBLE FLAG
1608 017260 005737 001366      1$:      TST      NULINE     :NEW LINE ?
1609 017264 001042      BNE      5$         :BRANCH IF NOT
1610 017266 104401 001207      TYPE      , $CRLF      :CR-LF
1611 017272 013746 001364      MOV      (MTRK,-(SP) :SAVE CMTRK FOR TYPEOUT
      017276 104405      TYPDS      :GO TYPE--DECIMAL ASCII WITH SIGN
1612 017300 104401 042635      TYPE      ,TAB       :TYPE 'TAB' CHARACTER
1613 017304 123701 001270      CMPB     $DEVN,R1   :SCORE FOR $DEVN ITSELF ?
1614 017310 001007      BNE      2$         :BRANCH IF NOT
1615 017312 104401 042750      TYPE      ,BLNKS3   :TYPE 3 BLANKS
1616 017316 104401 042630      TYPE      ,SELFX    :MESSAGE 'SEL'
1617 017322 104401 042635      TYPE      ,TAB       :TYPE TAB
1618 017326 000416      BR       4$         :NEXT STEP
1619 017330 006301      2$:      ASL      R1         :LOCATE THE SYS HISTORY FILE
1620 017332 016137 004444 017356      MOV      BLKADR(R1),3$ :LOCATE THE SYSTEM NAME AND DRIVE #
1621 017340 006201      ASR      R1         :RESTORE DRIVE #
1622 017342 062737 000014 017356      ADD      # $SYSNM,3$ :LOCATE THE SYSTEM NAME AND DRIVE #
1623 017350 104401 042750      TYPE      ,BLNKS3   :TYPE 3 BLANKS
1624 017354 104401      TYPE      :TYPE THE SYSTEM AND DRIVE
1625 017356 000000      3$:      .WORD    0         :ADDRESS FOR TYPING MESSAGE
1626 017360 104401 042635      TYPE      ,TAB       :TYPE TAB
1627 017364 012737 000001 001366      4$:      MOV      #1,NULINE  :INDICATE PRINTER STOPS AT COLUMN 1
1628 017372 012504      5$:      MOV      (R5)+,R4   :RETRIEVE THE DESIRED COLUMN # FROM
1629      :CALLING ROUTINE
1630 017374 020437 001366      6$:      CMP      R4,NULINE  :ON THE RIGHT COLUMN ?
1631 017400 103414      BLO      8$         :IF LOW NOT PRINT
1632 017402 001405      BEQ      7$         :BRANCH IF LOCATED
1633 017404 104401 042635      TYPE      ,TAB       :ADVANCE TO NEXT COLUMN
1634 017410 005237 001366      INC      NULINE     :INCREMENT COLUMN CTR
1635 017414 000767      BR       6$         :CHECK AGAIN
1636 017416 104401 042747      7$:      TYPE      ,BLNKS4   :TYPE 4 BLANKS
1637 017422 104401 042637      TYPE      ,MARKX    :THE EXCEPTION MARK '* 0'
1638 017426 005237 001366      INC      NULINE     :NEXT COLUMN
1639 017432      8$:      MOV      (SP)+,R4   :POP STACK INTO R4
      017432 012604      MOV      (SP)+,R3   :POP STACK INTO R3
      017434 012603      MOV      (SP)+,R2   :POP STACK INTO R2
      017436 012602      MOV      (SP)+,R1   :POP STACK INTO R1
1640 017442 000205      RTS      R5         :EXIT
1641      :
1642 017444 000240      IDLEX:  NOP         :RESET ALL RH/RM VECTOR FOR MOUNT AND DISMOUNT
1643 017446 000240      NOP
1644 017450 000002      RTI         :EXIT
1645      :
1646      :PROCESS THE ORDER TERMINATION
1647      :
1648 017452 111037 001330      PROCES: MOVNB     (R0),UNIT :DRIVE NUMBER FOR ANY ERROR MESSAGES
1649 017456 005760 000016      TST      $STATUS(R0) :SEE IF DRIVER SIGNALLED AN ERROR
1650 017462 100431      BMI      ERPROC     :BR IF ERROR
1651 017464 032760 100000 000020      BIT      #BIT15,$RMCS1(R0) :SEE IF 'SC' SET
1652 017472 001410      BEQ      1$         :BR IF NOT SET
1653 017474 032760 040000 000020      BIT      #BIT14,$RMCS1(R0) :SEE IF 'TRE' SET
1654 017502 001021      BNE      ERPROC     :BR IF SET
1655 017504 032760 040000 000032      BIT      #BIT14,$RMDS(R0) :SEE IF 'ERR' SET

```

```

1656 017512 001015
1657 017514 004737 020572
1658 017520 004737 020640
1659 017524 004737 030334
1660 017530 012737 177777 030264
1661 017536 012737 177777 030266
1662 017544 000207
1663
1664
1665
1666 017546 032760 000200 000016 ERPROC: BIT #BIT07,$STATUS(R0) ;DONE BIT SET ?
1667 017554 001402 BEQ ERPRC1 ;BR IF ORDER DIDN'T COMPLETE NORMALLY
1668 017556 000137 017744 JMP DONE ;PROCESS ERROR WITH 'DONE' BIT SET
1669
1670 ;PROCESS ORDER COMPLETION WITH 'ERROR' & 'DONE NOT' BITS
1671
1672 017562 032760 010000 000016 ERPRC1: BIT #BIT12,$STATUS(R0) ;SEE IF DRIVE WAS UNSAFE
1673 017570 001025 BNE PUNSAF ;BR IF YES
1674 017572 032760 004000 000016 BIT #BIT11,$STATUS(R0) ;PARITY ERROR OCCURRED
1675 017600 001025 BNE UCPAR ;BR IF IT DID
1676 017602 032760 002000 000016 BIT #BIT10,$STATUS(R0) ;FATAL PARITY ERROR?
1677 017610 001025 BNE FALPAR ;BR IF THERE IS ONE
1678 017612 032760 001000 000016 BIT #BIT09,$STATUS(R0) ;TIMEOUT?
1679 017620 001025 BNE SWTIM ;BR IF YES
1680 017622 032760 040002 000016 BIT #BIT14!BIT01,$STATUS(R0) ;DRIVE WENT OFFLINE ?
1681 017630 001025 BNE OFLIN ;BR IF IT DID
1682 017632 032760 000004 000016 BIT #BIT2,$STATUS(R0) ;PORT REQUEST TIME OUT ?
1683 017640 001025 BNE PRIM ;BR IF IT DID
1684 017642 000207 RTS PC ;ERROR. RETURN
1685
1686 ;DRIVE IS PERSISTENTLY UNSAFE
1687
1688 017644 PUNSAF:
1689 017644 104414 037160 DISPLY ,EM12
1690 017650 000137 017720 JMP DUMP2
1691
1692 ;UNCORRECTABLE MASSBUS PARITY ERROR OCCURRED
1693
1694 017654 UCPAR:
1695 017654 104414 037062 DISPLY ,EM10
1696 017660 000137 017720 JMP DUMP2
1697
1698 ;'FATAL' MASSBUS PARITY ERROR OCCURRED
1699
1700 017664 FALPAR:
1701 017664 104414 037125 DISPLY ,EM11
1702 017670 000137 017720 JMP DUMP2
1703
1704 ;SOFTWARE TIMEOUT OCCURRED
1705
1706 017674 SWTIM:
1707 017674 104414 037211 DISPLY ,EM13
1708 017700 000137 017720 JMP DUMP2
1709
1710 ;DRIVE WENT OFFLINE
1711
1712 017704 OFLIN:

```

1713	017704	104414	037263			DISPLY	EM14	
1714	017710	000137	017720			JMP	DUMP2	
1715								:PORT REQUEST TIMEOUT ERROR
1716								
1717	017714					PRTIM:		
1718	017714	104414	037306			DISPLY	EM15	
1719	017720	104401	001207			DUMP2:	TYPE	:CR-LF
1720	017724	104401	043243				TYPE	:CR-LF
1721	017730	104401	001207				TYPE	:CR-LF
1722	017734	104401	043106				TYPE	:CR-LF
1723	017740	000177	161434				JMP	:JUMP TO RESTART
1724								
1725								:PROCESS ORDER COMPLETION WITH 'ERROR' & 'DONE' BITS SET
1726								
1727	017744	032760	000030	000016	DONE:	BIT	#BIT04!BIT03,\$STATUS(R0)	:UNSAFE OCCURRED
1728	017752	001402				BEQ	+.6	:BR IF NOT
1729	017754	000137	020530			JMP	UNSAF	:REPORT UNSAFE
1730	017760	032760	040000	000030		BIT	#BIT14,\$RMCS2(R0)	:IS 'WCE' SET?
1731	017766	001402				BEQ	+.6	:BRANCH IF NOT SET
1732	017770	000137	020310			JMP	WCKER	:WRITE CHECK ERROR
1733	017774	032760	040000	000032		BIT	#BIT14,\$RMDS(R0)	:CHECK 'ERR'
1734	020002	001002				BNE	1\$	:BR IF SET
1735	020004	000137	020500			JMP	TRFER	:PROCESS 'TRE'
1736	020010	032760	000400	000034	1\$:	BIT	#BIT08,\$RMER1(R0)	: 'HCRC' SET?
1737	020016	001402				BEQ	+.6	:BR IF NOT
1738	020020	000137	020340			JMP	HRCRCR	:PROCESS 'HCRC'
1739	020024	032760	000020	000034		BIT	#BIT04,\$RMER1(R0)	: 'FMT' SET?
1740	020032	001402				BEQ	+.6	:BR IF NOT SET
1741	020034	000137	020360			JMP	CKFMT	:CHECK FORMAT ERROR
1742	020040	032760	000200	000034		BIT	#BIT07,\$RMER1(R0)	: 'HCE' SET?
1743	020046	001402				BEQ	+.6	:BR IF NOT SET
1744	020050	000137	020370			JMP	CKHCE	:CHECK 'HCE' ERROR
1745	020054	032760	020300	000034		BIT	#BIT13,\$RMER1(R0)	: 'OPI' SET?
1746	020062	001402				BEQ	+.6	:BR IF NOT SET
1747	020064	000137	020410			JMP	OPIER	:REPORT 'OPI'
1748	020070	032760	000010	000034		BIT	#BIT3,\$RMER1(R0)	: 'PAR' SET?
1749	020076	001402				BEQ	+.6	:BR IF NOT SET
1750	020100	000137	020430			JMP	PARER	:REPORT 'PAR'
1751	020104	032760	000040	000034		BIT	#BIT5,\$RMER1(R0)	: 'WCF' SET?
1752	020112	001402				BEQ	+.6	:BR IF NOT SET
1753	020114	000137	020520			JMP	WCFER	:REPORT 'WCF'
1754	020120	032760	002000	000034		BIT	#BIT10,\$RMER1(R0)	: 'IAE' SET?
1755	020126	001402				BEQ	+.6	:BR IF NOT SET
1756	020130	000137	020440			JMP	IAEER	:REPORT 'IAE'
1757	020134	032760	004000	000034		BIT	#BIT11,\$RMER1(R0)	: 'WLE' SET?
1758	020142	001402				BEQ	+.6	:BR IF NOT SET
1759	020144	000137	020450			JMP	WLEER	:REPORT 'WLE'
1760	020150	032760	001000	000034		BIT	#BIT9,\$RMER1(R0)	: 'AOE' SET?
1761	020156	001405				BEQ	2\$	:BR IF NOT SET
1762	020160	032760	002000	000032		BIT	#BIT10,\$RMDS(R0)	: 'LST' SET?
1763	020166	001401				BEQ	2\$	:BR IF NOT SET
1764	020170	000207				RTS	PC	: 'AOE' & 'LST' SET, EXIT
1765	020172	032760	010000	000034	2\$:	BIT	#BIT12,\$RMER1(R0)	:SEE IF 'DTE' SET
1766	020200	001402				BEQ	+.6	:BR IF NOT
1767	020202	000137	020420			JMP	DTEER	:REPORT 'DTE' ERROR
1768	020206	005760	000034			TST	\$RMER1(R0)	:SEE IF 'DCK' SET
1769	020212	100002				BPL	+.6	:BR IF NOT

```

1770 020214 000137 020300      JMP      DCKER          ;PROCESS 'DCK'
1771 020220 032760 060000 000062  BIT      #BIT14!BIT13,$RMER2(R0) ;'SKI' OR 'OCYL' SET
1772 020226 001006          BNL      3$           ;BR IF IT IS
1773 020230 032760 100000 000062  BIT      #BIT15,$RMER2(R0)      ;BAD SPOT ?
1774 020236 001004          BNE      4$           ;BRANCH IF SO
1775 020240 000137 020350      JMP      DRIVER        ;REPORT ERROR
1776 020244 000137 020510 3$:     JMP      SKIER      ;REPORT DRIVE ERROR
1777 020250 104401 001207 4$:     TYPE     ,SCLF     ;CR-LF
1778 020254 104401 042207      TYPE     ,MSG11
1779 020260 104007          EMT      7
1780 020262 104010          EMT      10
1781 020264 104011          EMT      11
1782 020266 104012          EMT      12
1783 020270 104401 043106      TYPE     ,HALTX
1784 020274 000177 061100      JMP      @RSTART      ;JUMP TO RESTART
1785
1786          ;PROCESS DATA ('DCK') CHECK ERROR
1787
1788 020300      DCKER:
1789 020300 104414 037363      DISPLY   ,EM21
1790 020304 000137 020540      JMP      DUMP
1791
1792          ;WRITE CHECK ERROR PROCESSING
1793
1794 020310      WCKER:
1795 020310 032760 100000 000034  BIT      #BIT15,$RMER1(R0)      ;DCK BIT SET ?
1796 020316 001004          BNE      1$           ;BRANCH IF SET
1797 020320 104414 037467      DISPLY   ,EM23
1798 020324 000137 020540      JMP      DUMP
1799 020330 104414 037414 1$:     DISPLY   ,EM22
1800 020334 000137 020540      JMP      DUMP
1801
1802          ;REPORT 'HCRC' ERROR
1803
1804 020340      HRCER:
1805 020340 104414 037342      DISPLY   ,EM20
1806 020344 000137 020540      JMP      DUMP
1807
1808          ;REPORT DRIVE ERROR
1809
1810 020350      DRIVER:
1811 020350 104414 037757      DISPLY   ,EM30
1812 020354 000137 020540      JMP      DUMP
1813
1814          ;PROCESS FORMAT ('FER') ERROR
1815
1816 020360      CKFMT:
1817 020360 104414 037546      DISPLY   ,EM24
1818 020364 000137 020540      JMP      DUMP
1819
1820          ;PROCESS HEADER COMPARE ('HCE') ERROR
1821
1822 020370      CKHCE:
1823 020370 104414 037614      DISPLY   ,EM25
1824 020374 000137 020540      JMP      DUMP
1825          ;POSSIBLE POSITIONING ERROR
1826

```

1827	020400	104414	041120	POSER:	DISPLY	,EM51
1828	020404	000137	020540		JMP	DUMP
1829						
1830				:REPORT	'OPI' ERROR	
1831	020410			OPIER:		
1832	020410	104414	040011		DISPLY	,EM31
1833	020414	000137	020540		JMP	DUMP
1834						
1835				:REPORT	'DTE' ERROR	
1836						
1837	020420			DTEER:		
1838	020420	104414	040054		DISPLY	,EM32
1839	020424	000137	020540		JMP	DUMP
1840						
1841				:REPORT	'PAR' ERROR	
1842						
1843	020430			PARER:		
1844	020430	104414	040107		DISPLY	,EM33
1845	020434	000137	020540		JMP	DUMP
1846						
1847				:REPORT	'IAE' ERROR	
1848						
1849	020440			IAEER:		
1850	020440	104414	040226		DISPLY	,EM35
1851	020444	000137	020540		JMP	DUMP
1852						
1853				:REPORT	WLE ERROR	
1854						
1855	020450			WLEER:		
1856	020450	104414	040264		DISPLY	,EM36
1857	020454	000137	020540		JMP	DUMP
1858						
1859				:REPORT	FORMAT ERROR	
1860						
1861	020460			FMTER:		
1862	020460	104414	037675		DISPLY	,EM26
1863	020464	000137	020540		JMP	DUMP
1864						
1865				:REPORT	HEADER COMPARE ERROR	
1866						
1867	020470	104414	037722	HCEER:	DISPLY	,EM27
1868	020474	000137	020540		JMP	DUMP
1869						
1870				:PROCESS CONTROL/INTERFACE TRANSFER ERROR		
1871						
1872	020500			TRFER:		
1873	020500	104414	040377		DISPLY	,EM40
1874	020504	000137	020540		JMP	DUMP
1875						
1876				:PROCESS	'SKI' OR 'OCYL'	
1877						
1878	020510			SKIER:		
1879	020510	104414	041062		DISPLY	,EM50
1880	020514	000137	020540		JMP	DUMP
1881						
1882				:REPORT	WRITE CLOCK FAILURE	
1883						

```

1884 020520
1885 020520 104414 040164
1886 020524 000137 020540
1887
1888
1889
1890 020530
1891 020530 104414 041163
1892 020534 000137 020540
1893
1894 020540
      020540 104007
1895 020542 104010
1896 020544 104011
1897 020546 104012
1898
1899 020550 004737 030334
1900 020554 012737 177777 030264
1901 020562 012737 177777 030266
1902 020570 000207
1903
1904
1905
1906
1907 020572 032760 060000 000020
1908 020600 001012
1909 020602 032760 177400 000030
1910 020610 001006
1911 020612 005760 000034
1912 020616 001003
1913 020620 005760 000062
1914 020624 001404
1915 020626 104414 040640
1916 020632 000137 020540
1917 020636 000207
1918
1919
1920
1921 020640 005760 000022
1922 020644 001011
1923 020646 016046 000004
1924 020652 005416
1925 020654 006316
1926 020656 066016 000006
1927 020662 022660 000024
1928 020666 001404
1929 020670 104414 040446
1930 020674 000137 020540
1931 020700 000207
1932
1933
1934 020702 104401 001207
1935 020706 104401 042764
1936 020712 104401 001207
1937 020716 016001 000024
1938 020722 016046 000004
1939 020726 005416

```

WCFER: DISPLY ,EM34  
JMP DUMP

;REPORT DRIVE UNSAFE ERROR

UNSAF: DISPLY ,EM60  
JMP DUMP

DUMP: EMT 7  
EMT 10  
EMT 11  
EMT 12

JSR PC,RMINIT ;CLEAR THE SUB-SYSTEM  
MOV #-1,SAVEFG  
MOV #-1,SEEKFG  
RTS PC

;CHECK ERROR BITS IN THE RH/RM REGISTERS

CKERR: BIT #60000,\$RMCS1(R0) ;SEE IF 'TRE' OR 'MCPE'  
BNE 1\$ ;YES  
BIT #177400,\$RMCS2(R0) ;ERROR BITS IN CS2 /  
BNE 1\$ ;YES  
TST \$RMER1(R0) ;ANY ERROR IN ER1  
BNE 1\$ ;YES  
TST \$RMER2(R0) ;ANY ERROR IN ER2  
BEQ 2\$ ;BRANCH IF NO ERROR

1\$: DISPLY ,EM44  
JMP DUMP ;TYPE ALL REGISTERS

2\$: RTS PC

;CHECK BUS ADDRESS REGISTER AND WORD COUNT REGISTER

CKBUS: TST \$RMWC(R0) ;WORD COUNT = 0  
BNE 1\$ ;NO  
MOV \$WRDM(R0),-(SP) ;WORD LENGTH  
NEG (SP) ;GET THE POSITIVE NUMBER OF WORD COUNT  
ASL (SP) ;BYTE COUNT  
ADD \$BUF(R0),(SP)  
CMP (SP)+,\$RMBA(R0)  
BEQ 2\$

1\$: DISPLY ,EM41  
JMP DUMP ;TYPE ALL REGISTERS

2\$: RTS PC

;ROUTINE TO DISPLAY THE SECTOR WHICH GAVE THE HARD ERROR

PRTBAD: TYPE ,\$CRLF ;CR-LF  
TYPE ,MSG19  
TYPE ,\$CRLF ;CR-LF  
MOV \$RMBA(R0),R1 ;PUT THE END ADDRESS INTO R1  
MOV \$WRDM(R0),-(SP) ;FIND THE BEGINNING OF THE SECTOR  
NEG (SP) ;GET THE POSITIVE NUMBER OF WORD COUNT

```

1940 020730 066016 000022      ADD    $RMWC(R0),(SP)  :SUBTRACT THE WORDS NOT TRANSFERED
1941 020734 005046              CLR    -(SP)          :MAKE THE UPPER DIVIDEND 0
1942 020736 012746 000400      MOV    #256,-(SP)    :DIVIDE THE WORDS TRANSFERED BY THE SECTOR SIZE
1943 020742 004737 021764      JSR    PC,LINKDV     :DIVIDE
1944 020746 005716              TST    (SP)          :REMANDER = 0 ?
1945 020750 001403              BEQ    1$           :BR IF IT IS - COMPLETE SECTOR TRANSFERED
1946 020752 006316              ASL    (SP)          :CONVERT THE RESIDUAL SECTOR SIZE INTO BYTE COUNT
1947 020754 161601              SUB    (SP),R1      :SUBTRACT IT FROM THE END ADDRESS
1948 020756 000402              BR     2$           :FINISH THE SIZING
1949 020760 162701 001000      1$:  SUB    #1000,R1   :SUBTRACT FULL SECTOR SIZE FROM END ADDR
1950 020764 062706 000004      2$:  ADD    #4,SP     :RESTORE THE STACK POINTER
1951 020770 012702 000007      3$:  MOV    #7,R2     :R2 CONTAINS THE WORDS/LINE COUNT
1952 020774 020160 000024      4$:  CMP    R1,$RMBA(R0) :PRINTED ALL THE SECTOR ?
1953 021000 001415              BEQ    5$           :BR IF ALL PRINTED
1954 021002 104414 042752      DISPLY ,BLNKS1      :TYPE 1 BLANK
1955 021006 012146              MOV    (R1)+,-(SP)  :PUT THE DATA ON THE STACK
1956 021010 004737 021162      JSR    PC,LINOC     :TYPE THE DATA
1957 021014 022711 177777      CMP    #-1,(R1)    :END OF FILE ?
1958 021020 001405              BEQ    5$           :BRANCH IF SO
1959 021022 005302              DEC    R2           :DECREMENT THE HORIZONTAL COUNT
1960 021024 001363              BNE    4$           :BR IF NOT AT THE END OF THE LINE
1961 021026 104414 001207      DISPLY ,$CRLF      :CR-LF
1962 021032 000756              BR     3$           :RESTORE THE WORDS/LINE COUNT
1963 021034 104414 001207      5$:  DISPLY ,$CRLF      :PRINT WHAT REMAINS IN THE BUFFER
1964 021040 000207      6$:  RTS    PC         :RETURN
1965
1966
1967
1968 021042 104412      FILBUF: SAVREG      :SAVE THE REGISTERS
1969 021044 016001 000006      MOV    $BUF(R0),R1  :BUFFER ADDRESS
1970 021050 016002 000004      MOV    $WRDM(R0),R2 :POSITIVE WORD COUNT
1971 021054 005402              NEG    R2           :
1972 021056 012705 005262      MOV    #STNDAT,R5   :PATTERN ADDRESS
1973 021062 012703 000020      MOV    #20,R3       :PATTERN COUNT
1974 021066 012521 3$:  MOV    (R5)+,(R1)+  :MOVE THE PATTERN INTO THE BUFFER
1975 021070 005302              DEC    R2           :DECREMENT THE WORD COUNT
1976 021072 003407              BLE    4$           :BR IF DONE (WORD COUNT = 0)
1977 021074 005303              DEC    R3           :DECREMENT THE PATTERN COUNT
1978 021076 001373              BNE    3$           :BR IF MORE PATTERN
1979 021100 012703 000020      MOV    #20,R3       :RESTORE PATTERN COUNT
1980 021104 012705 005262      MOV    #STNDAT,R5   :RESTORE THE ADDRESS
1981 021110 000766              BR     3$           :CONTINUE DISTRIBUTING THE PATTERN
1982 021112 104413      4$:  RESREG          :RESTORE THE REGISTERS
1983 021114 000207      RTS    PC         :RETURN
1984
1985
1986      .SBTTL  ERROR MESSAGE GENERATION ROUTINES
1987
1988      ;PRINT LINE 1 OF ERROR MESSAGE:
1989      ;'HH:MM:SS'
1990
1991 021116 032777 002000 160030  LINE1: BIT    #SW10,@SWR  :SWITCH 10 SET ?
1992 021124 001402              BEQ    1$           :BR IF NOT
1993 021126 104401 001202              TYPE    ,$BELL     :RING THE BELL
1994 021132 032777 020000 160014  1$:  BIT    #SW13,@SWR  :INHIBIT TYPEOUT ?
1995 021140 001403              BEQ    2$           :BR IF NOT
1996 021142 104414 001207      DISPLY , $CRLF     :CR-LF

```



```

1997 021146 000404
1998 021150 004737 021430
1999 021154 104414 042752
2000 021160 000207
2001
2002
2003
2004
2005
2006
2007
2008 021162 016646 000002
2009 021166 004737 022724
2010 021172 012637 021206
2011 021176 062737 000005 021206
2012 021204 104414
2013 021206 000000
2014 021210 012616
2015 021212 000207
2016
2017
2018
2019
2020
2021
2022
2023
2024 021214 016646 000002
2025 021220 004737 022674
2026 021224 004737 022300
2027 021230 012616
2028 021232 000207
2029
2030
2031
2032
2033
2034
2035
2036 021234 012737 177777 001316
2037 021242 012737 177777 001314
2038 021250 012737 021330 000004
2039 021256 005037 000006
2040 021262 005777 160014
2041 021266 005037 001316
2042 021272 005037 001314
2043 021276 013701 001306
2044 021302 012721 021526
2045 021306 012711 000300
2046 021312 012777 174575 157764
2047 021320 012777 000131 157754
2048 021326 000434
2049 021330 062706 000004
2050 021334 012737 021376 000004
2051 021342 005777 157742
2052 021346 005037 001316
2053 021352 013701 001312

BR 3$ :EXIT
2$: JSR PC,$TIME :TYPE THE TIME
DISPLY ,BLNKS1 :TYPE 1 BLANK
3$: RTS PC :RETURN & TYPE DESCRIPTION

;OCTAL TYPEOUT ROUTINE
;CALL:
; MOV NUM,-(SP) ;PUT THE NUMBER ON THE STACK
; JSR PC,LINOCT
; RETURN

LINOCT: MOV 2(SP),-(SP) ;PUT NUMBER IN PROPER LOCATION ON STACK
JSR PC,$SB20 ;CONVERT THE NUMBER TO OCTAL
MOV (SP)+,1$ ;GET THE ADDRESS OF THE ASCII STRING
ADD #5.,1$ ;ADDRESS THE LAST 6 ASCII DIGITS
DISPLY :TYPE IT
1$: .WORD 0 ;ADDRESS
MOV (SP)+,(SP) ;CORRECT THE STACK
RTS PC ;RETURN

;ROUTINE TO CONVERT THE INPUT NUMBER TO DECIMAL AND YPE IT WITH
;LEADING ZERO SUPPRESSION
;CALL:
; MOV NUM,-(SP) ;PUT THE NUMBER ON THE STACK
; JSR PC,LINDEC
; RETURN

LINDEC: MOV 2(SP),-(SP) ;SET UP STACK FOR CONVERT
JSR PC,$SB2D ;CONVERT IT TO DECIMAL
JSR PC,$SUPRS ;TYPE IT (WITH LEADING ZEROS SUPRESSED)
MOV (SP)+,(SP) ;RESTORE STACK POINTER
RTS PC

.SBTTL GENFRAL SUPPORT SUBROUTINES

;ROUTINE TO CHECK FOR KW11-L OR KW11-P CLOCKS
CKCLK: MOV #-1,CLKFLG ;CLEAR CLOCK AVAILABILITY FLAG
MOV #-1,PCLOCK ;CLEAR KW11-P CLOCK AVAILABILITY FLAG
MOV #CKCLK1,ERRVEC ;SET UP VECTOR FOR CLOCK CHECK
CLR @#ERRVEC+2 ;NEW PSW
TST @CLKCSR ;CHECK FOR KW11-P
CLR CLKFLG ;SET CLOCK AVAILABILITY FLAG
CLR PCLOCK ;SET KW11-P CLOCK FLAG
MOV $LPVEC,R1 ;KW11-P VECTOR ADDRESS
MOV #CLOCK,(R1)+ ;SET UP KW11-P VECTOR
MOV #300,(R1) ;PSW - PRI 6
MOV #-1667.,@CLKCSB ;LOAD COUNTER BUFFER WITH 16.67
MOV #131,@CLKCSR ;SET CLOCK - CNT UP, 10US, CONT INT
BR CKCLK3

CKCLK1: ADD #4,SP ;RESTORE THE STACK POINTER
MOV #CKCLK2,@ERRVEC ;CHANGE ERROR VECTOR TO CHECK FOR KW11-L
TST @CLKS ;LOOK FOR KW11-L
CLR CLKFLG ;SET CLOCK FLAG
MOV $LLVEC,R1 ;KW11-L VECTOR ADDRESS

```



```

2111          :CALL:
2112          :      MOV      #-1,CFLAG      ;'CFLAG' IS NORMALLY SET BY THE TTY SERVICE
2113          :      :      :ROUTINE IN INTERRUPT MODE
2114          :      JSR      PC,KSR
2115          :      RETURN1      ;SYSTEM BUSY RETURN
2116          :      RETURN2      ;RETURN AFTER KEYBOARD SERVICED
2117
2118 021634 104412      KSR:  SAVREG      ;SAVE THE REGISTERS
2119 021636 012737 000200 177776      MOV      #PR4,PS      ;SET PRIORITY TO 4
2120 021644 005037 001336      CLR      CFLAG      ;CLEAR THE 'CONTROL C' FLAG
2121 021650 004737 021430      JSR      PC,$TIME      ;TYPE THE TIME
2122 021654 005777 157302      TST      @STKB      ;CLEAR ANY GARBAGE IN THE TTY BUFFER
2123 021660 005737 001336      TST      CFLAG      ;CHECK THE CONTROL C FLAG
2124 021664 001002      BNE      7$      ;EXIT IF 'CONTROL C' ENTERED
2125 021666 000240      NOP      ;DUMP CODING FOR LATER USE 3/8/77
2126 021670 000240      NOP
2127 021672 104413      7$:  RESREG      ;RESTORE R0 - R5
2128 021674 062716 000002      ADD      #2,(SP)      ;INCREMENT THE RETURN ADDRESS
2129 021700 005777 157256      TST      @STKB      ;CLEAR THE TTY BUFFER
2130 021704 052777 000100 157246      BIS      #BIT06,@STKS      ;SET TTY INTERRUPT ENABLE
2131 021712 005037 177776      CLP      PS      ;SET PRIORITY BACK TO ZERO
2132 021716 000207      RTS      PC      ;RETURN
2133
2134          :ROUTINE TO CLEAR THE DPB FOR THE ASSIGNED DRIVE
2135          :CALL:
2136          :      MOV      #DPB,R0      ;DPB ADDRESS
2137          :      JSR      PC,CLRDPB
2138          :      RETURN
2139
2140          CLRDPB:
2141 021720 010146      MOV      R1,-(SP)      ;;PUSH R1 ON STACK
2142 021722 010346      MOV      R3,-(SP)      ;;PUSH R3 ON STACK
2143 021724 010446      MOV      R4,-(SP)      ;;PUSH R4 ON STACK
2144 021726 010546      MOV      R5,-(SP)      ;;PUSH R5 ON STACK
2145 021730 010004      MOV      R0,R4      ;GET THE DPB ADDRESS
2146 021732 062704 000002      ADD      #2,R4      ;ADDRESS OF FIRST LOCN TO BE CLEARED
2147 021736 012703 000020      MOV      #SEMTAB-2,R3      ;NUMBER OF LOCATIONS TO CLEAR
2148 021742 005024      1$:  CLR      (R4)+      ;CLEAR THE STORAGE LOCATION
2149 021744 162703 000002      SUB      #2,R3      ;DECREMENT THE BYTE COUNT
2150 021750 001374      BNE      1$      ;LOOPING BACK
2151 021752 012605      MOV      (SP)+,R5      ;;POP STACK INTO R5
2152 021754 012604      MOV      (SP)+,R4      ;;POP STACK INTO R4
2153 021756 012603      MOV      (SP)+,R3      ;;POP STACK INTO R3
2154 021760 012601      MOV      (SP)+,R1      ;;POP STACK INTO R1
2155 021762 000207      RTS      PC      ;RETURN
2156
2157 021764 104412      LINKDV: SAVREG      ;STORE R0 - R5
2158 021766 016605 000026      MOV      26(SP),R5      ;DIVISOR
2159 021772 005004      CLR      R4      ;OTHER DIVISOR WORD
2160 021774 016602 000030      MOV      30(SP),R2      ;UPPER DIVIDEND WORD
2161 022000 016603 000032      MOV      32(SP),R3      ;LOWER DIVIDEND WORD
2162 022004 005000      CLR      R0      ;CLEAR OTHER DIVIDEND REGISTERS
2163 022006 005001      CLR      R1
2164 022010 004737 022032      JSR      PC,M.DPID      ;GO TO THE DIVIDE ROUTINE
2165 022014 010166 000030      MOV      R1,30(SP)      ;REMAINDER ON THE STACK
2166 022020 010366 000032      MOV      R3,32(SP)      ;QUOTIENT ON THE STACK
2167 022024 104413      RESREG      ;RESTORE R0 - R5

```

```

2161 022026 012616      MOV      (SP)+,(SP)      ;MOVE RETURN UP THE STACK
2162 022030 000207      RTS      PC
2163
2164      :      DIVISION UTILITY SUBROUTINE
2165      :      R0-R1-R2-R3=DIVIDEND
2166      :      R4-R5=DIVISOR
2167      :      R0-R1=REMAINDER AFTER DIVISION
2168      :      R2-R3=QUOTIENT AFTER DIVISION
2169      :      ENTER WITH JSR PC,M.DPID
2170
2171 022032 012746 000040  M.DPID: MOV      #40,-(SP)      ;COUNTER FOR DIVISION CYCLES
2172 022036 010446      MOV      R4,-(SP)      ;HIGH ORDER
2173 022040 010546      MOV      R5,-(SP)      ;LOW ORDER DIVISOR TO THE STACK
2174 022042 005466 000002  NEG      2(SP)          ;FORM NEGATIVE
2175 022046 005416      NEG      @SP            ;VERSION OF THE DIVISOR
2176 022050 005666 000002  SBC      2(SP)
2177 022054 061601      ADD      @SP,R1
2178 022056 005500      ADC      R0            ;PERFORM THE INITIAL SUBTRACTION
2179 022060 066600 000002  ADD      2(SP),R0
2180 022064 103445      BCS      M.DP50        ;IF CARRY THEN OVERFLOW HAS OCCURRED
2181 022066 005046      CLR      -(SP)        ;THIS IS A LONGER LASTING CARRY BIT
2182 022070 006103  M.DP40: ROL      R3
2183 022072 006102      ROL      R2
2184 022074 006101      ROL      R1
2185 022076 006100      ROL      R0
2186 022100 005716      TST      @SP            ;TEST "CARRY" INDICATOR
2187 022102 001410      BEQ      M.DP41        ;IF NO "CARRY" THEN ADD ELSE SUBTRACT
2188 022104 005016      CLR      @SP            ;CLEAR UP FOR NEXT TIME
2189 022106 066601 000002  ADD      2(SP),R1
2190 022112 005500      ADC      R0            ;ADD -(DIVISOR)
2191 022114 005516      ADC      @SP            ;SET "CARRY"
2192 022116 066600 000004  ADD      4(SP),R0;<-
2193 022122 000404      BR      M.DP42
2194 022124 060501  M.DP41: ADD      R5,R1
2195 022126 005500      ADC      R0            ;ADD +(DIVISOR)
2196 022130 005516      ADC      @SP            ;SET "CARRY"
2197 022132 060400      ADD      R4,R0        ;<-
2198 022134 005516  M.DP42: ADC      @SP            ;SET "CARRY"
2199 022136 005716      TST      @SP            ;TEST THE UPDATE INDICATOR
2200 022140 001401      BEQ      .+4          ;-> ;IF ZERO FORGET IT
2201 022142 005203      INC      R3            ; I ;NO CARRY POSSIBLE HERE
2202 022144 005366 000006  DEC      6(SP)        ;<- ;DECREMENT COUNTER
2203 022150 003347      BGT      M.DP40        ;BRANCH IF MORE TO DO
2204 022152 006003      ROR      R3
2205 022154 103404      BCS      M.DP44
2206 022156 060501      ADD      R5,R1
2207 022160 005500      ADC      R0
2208 022162 060400      ADD      R4,R0
2209 022164 000241      CLC
2210 022166 006103  M.DP44: ROL      R3
2211 022170 062706 000010  ADD      #10,SP        ;ADJUST STACK BY 4 WORDS
2212 022174 000242      CLV
2213 022176 000207      RTS      PC
2214 022200 062706 000006  M.DP50: ADD      #6,SP
2215 022204 000262      SEV
2216 022206 060207      RTS      PC
2217

```

```

2218
2219 ;ROUTINE TO REPLACE LEADING ZEROS IN A NUMERIC STRING WITH SPACES
2220 ;CALL
2221 ;:      MOV      #ADR,-(SP)      ;ADDRESS OF NUMBER (IN ASCII)
2222 ;:      JSR      R5,REPLZ
2223 ;:      .WORD    N                ;'N' IS NUMBER OF DIGITS TO BE TYPED
2224
2225 022210 010046 REPLZ: MOV      R0,-(SP)      ;SAVE R0
2226 022212 012746 000012 MOV      #10,-(SP)      ;MAXIMUM NUMBER OF DIGITS TO BE TYPED
2227 022216 162516 SUB      (R5)+,(SP)      ;SUBTRACT DIGITS TO FORM INDEX
2228 022220 016600 000006 MOV      6(SP),R0        ;ADDRESS OF NUMBER TO R0
2229 022224 122710 000060 1$: CMPB   #'0',(R0)      ;BYTE EQUAL TO ASCII '0' ?
2230 022230 001004 BNE     2$              ;BR IF NOT
2231 022232 112710 000040 MOVB    #40,(R0)        ;REPLACE THE ZERO WITH A SPACE
2232 022236 005200 INC      R0              ;INCREMENT THE BYTE ADDRESS
2233 022240 000771 BR      1$              ;GO BACK AND LOOK FOR MORE LEADING ZEROS
2234 022242 105710 2$: TSTB   (R0)              ;SEE IF ZERO BYTE TERMINATOR
2235 022244 001003 BNE     3$              ;BR IF NOT
2236 022246 005300 DEC      R0              ;BACKUP STRING POINTER
2237 022250 112710 000060 MOVB    #'0',(R0)        ;PUT A ZERO BACK IN
2238 022254 016637 000006 022270 3$: MOV     6(SP),4$      ;PUT ADDRESS IN LOCATION FOR TYPEOUT
2239 022262 062637 022270 ADD      (SP)+,4$      ;BEGINNING OF SIGNIFICANT DIGITS
2240 022266 104401 TYPE     0              ;TYPE THE NUMBER
2241 022270 000000 4$: .WORD   0              ;ADDRESS OF NUMBER
2242 022272 012600 MOV      (SP)+,R0        ;RESTORE R0
2243 022274 012616 MOV      (SP)+,(SP)      ;MOVE RETURN ADDRESS
2244 022276 000205 RTS      R5              ;RETURN
2245
2246 ;TYPE NUMERICAL ASCII STRING SUPPRESS LEADING ZEROS
2247
2248 ;CALL
2249 ;:      MOV      #NUMADR,-(SP)    ;FIRST ADDRESS OF ASCII STRING
2250 ;:      JSR      PC,$SUPRS
2251
2252 022300 010046 $SUPRS: MOV     R0,-(SP)      ;SAVE R0
2253 022302 016600 000004 MOV     4(SP),R0        ;PICKUP THE POINTER
2254 022306 105710 1$: TSTB   (R0)              ;TERMINATOR ?
2255 022310 001403 BEQ     2$              ;BR IF YES
2256 022312 122720 000060 CMPB    #'0',(R0)+      ;IS THIS AN ASCII '0' ?
2257 022316 001773 BEQ     1$              ;BR IF YES
2258 022320 005300 2$: DEC     R0              ;BACKUP BY '1'
2259 022322 010037 022330 MOV     R0,3$          ;SAVE FOR TYPING
2260 022326 104414 DISPLY  0              ;GO PRINT
2261 022330 000000 3$: .WORD   0              ;ASCII POINTER GOES HERE
2262 022332 012600 MOV     (SP)+,R0        ;RESTORE R0
2263 022334 012616 MOV     (SP)+,(SP)      ;RESTORE THE STACK
2264 022336 000207 RTS      PC              ;RETURN
2265
2266 ;ROUTINE TO TYPE AT PRIORITY 4
2267
2268 022340 013746 177776 TYPR14: MOV    @#PS,-(SP)      ;SAVE THE PRESENT STATUS
2269 022344 012737 000200 177776 MOV    #200,@#PS        ;CHANGE THE PRIORITY TO 4
2270 022352 012537 022362 MOV    (R5)+,1$        ;MESSAGE ADDRESS
2271 022356 004737 024576 JSR    PC,$TYPE        ;TYPE THE MESSAGE
2272 022362 000000 1$: .WORD   0              ;MESSAGE ADDRESS GOES HERE
2273 022364 000205 RTS      R5              ;RETURN
2274

```

```

2275 ;ROUTINE TO TYPE ERRORS
2276 ;CALL
2277 ;       DISPLY           ;MUST DEFINED IN 'TRAP' TABLE
2278 ;       MESADR           ;ADDRESS OF MESSAGE
2279 ;       RETURN
2280
2281 022366 032777 020000 156560 $DSPLY: BIT    #BIT13,@SWR   ;INHIBIT ERROR TIMEOUT ?
2282 022374 001002                BNE     1$           ;BR IF YES
2283 022376 000137 024576        JMP     $TYPE       ;TYPE THE MESSAGE
2284 022402 062716 000002        1$:  ADD     #2,(SP)    ;INCREMENT THE RETURN
2285 022406 000002                RTI              ;RETURN
2286
2287 ;THIS ROUTINE IS USED TO CHECK IF AN
2288 ;ASCII CHARACTER IS A DIGIT BETWEEN 0 AND 7.
2289 ;CALL
2290 ;       MOV     #ADR,R1    ;ADDRESS OF ASCII CHARACTER
2291 ;       JSR    R5,CK.OCT  ;CHECK THE CHARACTER
2292 ;       RETURN1          ;CHARACTER IS NOT BETWEEN 0-7
2293 ;       RETURN2          ;CHARACTER IS IN R2 AS A
2294 ;                       ;OCTAL DIGIT
2295
2296 022410 121127 000060        CK.OCT: CMPB   (R1),#'0    ;LESS THAN ZERO?
2297 022414 103407                BLO     1$           ;YES -- BRANCH
2298 022416 121127 000067        CMPB   (R1),#'7    ;GREATER THAN SEVEN?
2299 022422 101004                BHI     1$           ;YES -- BRANCH
2300 022424 111102                MOVB   (R1),R2      ;GET THE CHARACTER
2301 022426 042702 177770        BIC    #'C7,R2     ;STRIP AWAY THE ASCII
2302 022432 005725                TST    (R5)+       ;ADJUST FOR RETURN
2303 022434 000205        1$:  RTS     R5           ;RETURN
2304
2305 ;THIS ROUTINE IS USED TO CHECK AN ASCII CHARACTER
2306 ;AND DETERMINE IF IT IS A DIGIT BETWEEN 0 AND 9.
2307 ;CALL
2308 ;       MOV     #ADR,R1    ;ADDRESS OF ASCII CHARACTER
2309 ;       JSR    R5,CK.DEC  ;CHECK THE CHARACTER
2310 ;       RETURN1          ;NOT BETWEEN 0 AND 9
2311 ;       RETURN2          ;BETWEEN 0 AND 9
2312 ;                       ;R2 = DIGIT
2313
2314 022436 121127 000060        CK.DEC: CMPB   (R1),#'0    ;LESS THAN ZERO?
2315 022442 103407                BLO     1$           ;YES -- BRANCH
2316 022444 121127 000071        CMPB   (R1),#'9    ;GREATER THAN NINE?
2317 022450 101004                BHI     1$           ;YES -- BRANCH
2318 022452 111102                MOVB   (R1),R2      ;GET THE CHARACTER
2319 022454 042702 000060        BIC    #'0,R2     ;STRIP AWAY THE ASCII
2320 022460 005725                TST    (R5)+       ;ADJUST FOR RETURN
2321 022462 000205        1$:  RTS     R5           ;RETURN
2322
2323 ;THIS ROUTINE WILL CHECK AN ASCII CHARACTER TO
2324 ;DETERMINE WHAT IT IS.
2325 ;CALL
2326 ;       MOV     #ADR,R1    ;ADDRESS OF ASCII CHARACTER
2327 ;       JSR    R5,CK.CHR  ;CHECK CHARACTER
2328 ;       RETURN ADR1       ;UNKNOWN CHARACTER
2329 ;       RETURN ADR2       ;CARRIAGE RETURN * (R1)=ADR+1
2330 ;       RETURN ADR3       ;COMMA * (R1)-ADR+1
2331 ;       RETURN ADR4       ;PERIOD * (R1)-ADR+1

```

```

2332      :      RETURN  ADR5      ;DIGIT BETWEEN 0 AND 7.
2333      :      RETURN  ADR6      ;DIGIT BETWEEN 8 AND 9.
2334      :      :                ;R2 = DIGIT * (R1)=ADR*
2335
2336 022464 105711      CK.CHR: TSTB   (R1)      ;'CARRIAGE RETURN'?
2337 022466 001417      BEQ     3$      ;YES -- BRANCH
2338 022470 121127 000054  CMPB   (R1),#',', ;'COMMA'?
2339 022474 001413      BEQ     2$      ;YES -- BRANCH
2340 022476 121127 000056  CMPB   (R1),#'.', ;'PERIOD'?
2341 022502 001407      BEQ     1$      ;YES -- BRANCH
2342 022504 004537 022436  JSR    R5,CK.DEC   ;'DIGIT'?
2343 022510 000410      BR     4$      ;NO -- BRANCH
2344 022512 004537 022410  JSR    R5,CK.OCT   ;OCTAL ?
2345 022516 005725      TST   (R5)+     ;DIGIT BETWEEN 8-9
2346 022520 005725      TST   (R5)+     ;DIGIT BETWEEN 0-7
2347 022522 005725      1$:   TST   (R5)+     ;PERIOD
2348 022524 005725      2$:   TST   (R5)+     ;COMMA
2349 022526 005725      3$:   TST   (R5)+     ;CARRIAGE RETURN
2350 022530 005201      INC    R1      ;MOVE POINTER TO NEXT CHARACTER
2351 022532 011505      4$:   MOV   (R5),R5 ;UNKNOWN CHARACTER
2352 022534 000205      RTS     R5      ;RETURN
2353
2354      :THIS ROUTINE CHECKS AN ASCII STRING FOR LEGAL
2355      :CHARACTERS AND FORMS A DECIMAL VALUE BINARY NUMBER IN R2.
2356      :CALL
2357      :      MOV     #ADR,R1      ;ADDRESS OF ASCII STRING
2358      :      MOV     #NUM,R2      ;MAX. MAGNITUDE OF INPUT NUMBER
2359      :      JSR    R5,CK.DIG     ;CHECK DIGITS
2360      :      RETURN  ADR1      ;'CR' ONLY ENTERED -- R2=0
2361      :      RETURN  ADR2      ;'PERIOD' ONLY ENTERED -- R2=0
2362      :      RETURN  ADR3      ;ILLEGAL CHARACTER OR INPUT TOO LARGE -- R2 ?
2363      :      RETURN  ADR4      ;'CR' -- R2 = NUMBER
2364      :      RETURN  ADR5      ;'COMMA' -- R2 = NUMBER
2365      :      RETURN  ADR6      ;'PERIOD' -- R2 = NUMBER
2366
2367 022536 010446      CK.DIG: MOV   R4,-(SP)   ;SAVE R4
2368 022540 010346      MOV   R3,-(SP)   ;SAVE R3
2369 022542 010246      MOV   R2,-(SP)   ;SAVE THE MAX. SIZE ON THE STACK
2370 022544 005002      CLR   R2      ;START WITH 0
2371 022546 005003      CLR   R3
2372 022550 005004      CLR   R4
2373 022552 004537 022464  JSR    R5,CK.CHR   ;CHECK ONE CHARACTER
2374      :      6$      ;ILLEGAL CHARACTER
2375      :      9$      ;CARRIAGE RETURN
2376      :      6$      ;
2377      :      7$      ;
2378      :      1$      ;DIGIT 0-7
2379      :      1$      ;DIGIT 8-9
2380 022572 062705 000004  1$:   ADD   #4,R5     ;STEP RETURN POINTER PAST 'CR' & 'PERIOD' RETURNS
2381 022576 006303      2$:   ASL   R3      ;INPUT NUMBER *2
2382 022600 010346      MOV   R3,-(SP)   ;SAVE *2
2383 022602 006303      ASL   R3      ;*4
2384 022604 006303      ASL   R3      ;*8
2385 022606 062603      ADD   (SP)+,R3   ;(*2)+(*8) = *10
2386 022610 060203      ADD   R2,R3     ;UPDATE THE INPUT NUMBER
2387 022612 004537 022464  JSR    R5,CK.CHR   ;CHECK ONE CHARACTER
2388 022616 022656      8$      ;ILLEGAL CHARACTER

```

```

022620 022642 5$ :CARRIAGE RETURN
022622 022640 4$ :
022624 022632 3$ :
022626 022576 2$ :DIGIT 0-7
022630 022576 2$ :DIGIT 8-9
2382 022632 105711 3$: TSTB (R1) :DOES A 'CR' FOLLOW THE 'PERIOD'
2383 022634 001010 BNE 8$ :IF NOT
2384 022636 005724 TST (R4)+ :INCREMENT THE RETURN
2385 022640 005724 4$: TST (R4)+ :INCREMENT THE RETURN
2386 022642 005724 5$: TST (R4)+ :INCREMENT THE RETURN
2387 022644 020316 CMP R3,(SP) :CHECK THE MAGNITUDE OF THE NUMBER
2388 022646 101004 BHI 9$ :BR IF ENTERED NUMBER TOO LARGE
2389 022650 000402 BR 8$ :BYPASS INCREMENT
2390 022652 005725 6$: TST (R5)+ :INCREMENT RETURN PAST INVALID RETURN
2391 022654 005725 7$: TST (R5)+ :INCREMENT RETURN
2392 022656 060405 8$: ADD R4,R5 :SETUP RETURN POINTER
2393 022660 010302 9$: MOV R3,R2 :ENTERED VALUE
2394 022662 005726 TST (SP)+ :CLEAN MAX. SIZE OFF OF STACK
2395 022664 012603 MOV (SP)+,R3 :RESTORE R3
2396 022666 012604 MOV (SP)+,R4 :RESTORE R4
2397 022670 011505 MOV (R5),R5 :GET RETURN ADDRESS
2398 022672 000205 RTS R5 :RETURN
2399
2400 ;THIS ROUTINE WILL CONVERT A 16-BIT UNSIGNED BINARY NUMBER TO AN
2401 ;UNSIGNED DECIMAL ASCIZ NUMBER.
2402 ;CALL
2403 ; MOV NUMBER,-(SP) ;PUT THE NUMBER ON THE STACK
2404 ; JSR PC,$SB2D ;CALL
2405 ; RETURN ;ADDRESS OF THE 1ST ASCIZ CHAR IS ON THE STACK
2406
2407 ;NOTE: THE PROGRAM REQUIRES THIS FORM OF '$SB2D', NOT THE VERSION ON
2408 ; THE SYSMAC LIBRARY, REV C AND LATER
2409
2410 022674 016637 000002 022720 $SB2D: MOV 2(SP),1$ ;SAVE THE BINARY NUMBER
2411 022702 012746 022720 MOV #1$,-(SP) ;SET THE POINTER
2412 022706 004737 027004 JSR PC,$DB2D ;CALL THE DOUBLE LENGTH CONVERT
2413 022712 012666 000002 MOV (SP)+,2(SP) ;PICKUP THE POINTER
2414 022716 000207 RTS PC ;RETURN
2415 022720 000000 000000 1$: .WORD 0,0
2416
2417 ;THIS ROUTINE WILL CONVERT A 16-BIT UNSIGNED BINARY NUMBER TO AN
2418 ;UNSIGNED OCTAL ASCIZ NUMBER.
2419 ;CALL
2420 ; MOV NUMBER,-(SP) ;PUT THE NUMBER ON THE STACK
2421 ; JSR PC,$SB20 ;CALL
2422 ; RETURN ;ADDRESS OF THE 1ST ASCIZ CHAR IS ON THE STACK
2423
2424 ;NOTE: THE PROGRAM REQUIRES THIS FORM OF '$SB20', NOT THE VERSION ON
2425 ; THE SYSMAC LIBRARY, REV C AND LATER
2426
2427 022724 016637 000002 022750 $SB20: MOV 2(SP),1$ ;SAVE THE BINARY NUMBER
2428 022732 012746 022750 MOV #1$,-(SP) ;SET THE POINTER
2429 022736 004737 027200 JSR PC,$DB20 ;CALL THE DOUBLE LENGTH CONVERT
2430 022742 012666 000002 MOV (SP)+,2(SP) ;PICKUP THE POINTER
2431 022746 000207 RTS PC ;RETURN
2432 022750 000000 000000 1$: .WORD 0,0
2433

```



```

2434 ;KEYBOARD INTERRUPT INITIALIZATION ROUTINE
2435 ;CALL
2436 ; JSR PC,$TKINT
2437 ; RETURN
2438
2439 022754 012737 023004 000060 $TKINT: MOV # $TKSRV,TKVEC ;SETUP VECTOR
2440 022762 012737 000240 000062 MOV #PR5,TKVEC+2 ;PRIORITY TO 5
2441 022770 005777 156166 TST @ $TKB ;CLEAR THE BUFFER
2442 022774 012777 000100 156156 MOV #BIT06,@ $TKS ;SET INTERRUPT ENABLE
2443 023002 000207 RTS PC ;RETURN
2444
2445 ;KEYBOARD INTERRUPT SERVICE ROUTINE
2446 ;CALL
2447 ; ENTER VIA INTERRUPT
2448
2449 023004 104410 $TKSRV: RDCHR ;READ THE KEYBOARD
2450 023006 112637 023146 MOVB (SP)+,5$ ;GET THE CHARACTER
2451 023012 023727 023146 000003 CMP 5$,#3 ;'CONTROL C' ?
2452 023020 001017 BNE 1$ ;BR IF NOT
2453 023022 104401 001207 TYPE , $CRLF ;CR-LF
2454 023026 104401 023452 TYPE , $CNTLC ;'^C'
2455 023032 012737 177777 001336 MOV #-1,CFLAG ;SET THE 'CONTROL C' FLAG
2456 023040 005077 156114 CLR @ $TKS ;CLEAR THE TTY INTERRUPT
2457 023044 104401 001207 TYPE , $CRLF ;CR-LF
2458 023050 104401 043106 TYPE ,HALTX ;HALT THE PROGRAM
2459 023054 000177 156320 JMP @RSTART ;JUMP TO RESTART
2460
2461 023060 023727 001154 000176 1$: CMP SWR,#SWREG ;SOFTWARE SWITCH REGISTER IN USE ?
2462 023066 001024 BNE 3$ ;BR IF NOT
2463 023070 023727 023146 000007 CMP 5$,#7 ;'CONTROL G' ?
2464 023076 001020 BNE 3$ ;BR IF NOT
2465 023100 104401 001207 TYPE , $CRLF ;CR-LF
2466 023104 104401 026661 TYPE , $CNTLG ;'^G'
2467 023110 013746 177776 MOV PS,-(SP) ;PUT THE STATUS WORD ON THE STACK
2468 023114 012746 023130 MOV #2$,-(SP) ;RETURN ADDRESS
2469 023120 005077 156034 CLR @ $TKS ;CLEAR THE TTY INTERRUPT ENABLE
2470 023124 000137 026312 JMP $GTSWR ;GET THE SWITCH REGISTER ENTRY
2471 023130 012777 000100 156022 2$: MOV #100,@ $TKS ;ENABLE TTY KEYBOARD INTERRUPT
2472 023136 000402 BR 4$ ;EXIT
2473 023140 104401 023146 3$: TYPE ,5$ ;ECHO THE CHARACTER
2474 023144 000002 4$: RTI ;RETURN
2475
2476 023146 000000 5$: .WORD 0 ;ENTERED CHARACTER
2477
2478 ;THIS ROUTINE WILL INPUT A STRING FROM THE TTY
2479 ;CALL:
2480 ; RDLIN ;: INPUT A STRING FROM THE TTY
2481 ; RETURN HERE ;: ADDRESS OF FIRST CHARACTER WILL BE ON THE STACK
2482 ; ;: TERMINATOR WILL BE A BYTE OF ALL 0'S
2483
2484 023150 010346 $RDLIN: MOV R3,-(SP) ;SAVE R3
2485 023152 005046 CLR -(SP) ;CLEAR THE RUBOUT KEY
2486 023154 012703 023426 1$: MOV # $TTYIN,R3 ;GET ADDRESS
2487 023160 022703 023452 2$: CMP # $TTYIN+20.,R3 ;BUFFER FULL?
2488 023164 101467 BLOS 8$ ;BR IF YES
2489 023166 104410 RDCHR ;GO READ ONE CHARACTER FROM THE TTY
2490 023170 112613 MOVB (SP)+,(R3) ;GET CHARACTER

```

```

GENERAL SUPPORT SUBROUTINES
2491 023172 12273 000177      CMPB    #177,(R3)      ;IS IT A RUBOUT
2492 023176 001022      BNE     4$            ;BR IF NO
2493 023200 005716      TST     (SP)         ;IS THIS THE FIRST RUBOUT?
2494 023202 0C1007      BNE     3$            ;BR IF NO
2495 023204 112737 000134 023424      MOVVB   #'\,11$      ;TYPE A BACK SLASH
2496 023212 104401 023424      TYPE   ,11$
2497 023216 012716 177777      MOV     #-1,(SP)     ;SET THE RUBOUT KEY
2498 023222 005303      3$:    DEC     R3       ;BACKUP BY ONE
2499 023224 020327 023426      CMP     R3,#$TTYIN  ;STACK EMPTY?
2500 023230 103445      BLO     8$            ;BR IF YES
2501 023232 111337 023424      MOVVB   (R3),11$    ;SETUP TO TYPEOUT THE DELETED CHAR.
2502 023236 104401 023424      TYPE   ,11$
2503 023242 000746      BR      2$            ;GO TYPE
2504 023244 005716      4$:    TST     (SP)     ;GO READ ANOTHER CHAR.
2505 023246 001406      BEQ     5$            ;RUBOUT KEY SET?
2506 023250 112737 000134 023424      MOVVB   #'\,11$    ;TYPE A BACK SLASH
2507 023256 104401 023424      TYPE   ,11$
2508 023262 005016      CLR     (SP)         ;CLEAR THE RUBOUT KEY
2509 023264 122713 000025      5$:    CMPB   #25,(R3)   ;IS CHARACTER A CTRL U?
2510 023270 001003      BNE     6$            ;BR IF NO
2511 023272 104401 026654      TYPE   ,SCNTLU      ;TYPE A CONTROL 'U'
2512 023276 000726      BR      1$            ;GO START OVER
2513 023300 122713 000003      6$:    CMPB   #3,(R3)   ;IS CHARACTER A CTRL C ?
2514 023304 001006      BNE     7$            ;BR IF NOT
2515 023306 012737 177777 001336      MOV     #-1,CFLAG   ;SET CNTRL C FLAG
2516 023314 104401 023452      TYPE   ,SCNTLC      ;ECHO IT
2517 023320 000427      BR      10$         ;EXIT
2518 023322 122713 000012      7$:    CMPB   #12,(R3)  ;IS CHARACTER A 'LF'?
2519 023326 001011      BNE     9$            ;BRANCH IF NO
2520 023330 105013      CLRB   (R3)         ;CLEAR THE CHARACTER
2521 023332 104401 001207      TYPE   ,SCRLF       ;TYPE A 'CR' & 'LF'
2522 023336 104401 023426      TYPE   ,STTYIN      ;TYPE THE INPUT STRING
2523 023342 000706      BR      2$            ;GO PICKUP ANOTHER CHACTER
2524 023344 104401 001206      8$:    TYPE   ,SQUES    ;TYPE A '?'
2525 023350 000701      BR      1$            ;CLEAR THE BUFFER AND LOOP
2526 023352 111337 023424      9$:    MOVVB   (R3),11$ ;ECHO THE CHARACTER
2527 023356 104401 023424      TYPE   ,11$
2528 023362 122723 000015      CMPB   #15,(R3)+    ;CHECK FOR RETURN
2529 023366 001274      BNE     2$            ;LOOP IF NOT RETURN
2530 023370 105063 177777      CLRB   -1(R3)       ;CLEAR RETURN (THE 15)
2531 023374 104401 001210      TYPE   ,SLF         ;TYPE A LINE FEED
2532 023400 005726      10$:   TST     (SP)+      ;CLEAN RUBOUT KEY FROM THE STACK
2533 023402 012603      MOV     (SP)+,R3    ;RESTORE R3
2534 023404 011646      MOV     (SP)-,(SP)  ;ADJUST THE STACK AND PUT ADDRESS OF THE
2535 023406 016666 000004 000002      MOV     4(SP),2(SP) ;FIRST ASCII CHARACTER ON IT
2536 023414 012766 023426 000004      MOV     #$TTYIN,4(SP)
2537 023422 000002      RTI
2538 023424 000      11$:  .BYTE   0          ;RETURN
2539 023425 000      .BYTE   0          ;STORAGE FOR ASCII CHAR. TO TYPE
2540 023426      .BLKB  20         ;TERMINATOR
2541 023452 136 103 200  $TTYIN: .ASCIZ  /^C/<CRLF> ;RESERVE 20 BYTES FOR TTY INPUT
2542      .EVEN          ;CONTROL 'C'

```

1

.SBTTL END OF PASS ROUTINE

\*\*\*\*\*  
\*INCREMENT THE PASS NUMBER (\$PASS)  
\*IF SW12=1 INHIBIT TRACE TRAP  
\*IF THERES A MONITOR GO TO IT  
\*IF THERE ISN'T JUMP TO FINISH

023456  
023456 000240  
023460 005037 001116  
023464 005037 001176  
023470 005237 001220  
023474 042737 100000 001220  
023502 005327  
023504 000001  
023506 003022  
023510 012737  
023512 000001  
023514 023504  
023516 013700 000042  
023522 001414  
023524 005046  
023526 012746 023534  
023532 000426

\$EOP:  
NOP  
CLR \$TSTNM ;;ZERO THE TEST NUMBER  
CLR \$TIMES ;;ZERO THE NUMBER OF ITERATIONS  
INC \$PASS ;;INCREMENT THE PASS NUMBER  
BIC #100000,\$PASS ;;DON'T ALLOW A NEG. NUMBER  
DEC (PC)+ ;;LOOP?  
\$EOPCT: .WORD 1  
BGT \$DOAGN ;;YES  
MOV (PC)+,@(PC)+ ;;RESTORE COUNTER  
\$ENDCT: .WORD 1  
\$GET42: MOV @#42,R0 ;;GET MONITOR ADDRESS  
BEQ \$DOAGN ;;BRANCH IF NO MONITOR  
CLR -(SP) ;;INSURE THE 'T' BIT IS CLEAR  
MOV #SCLR.T,-(SP) ;;SETUP FOR AN RTI OR RTT  
BR \$RTRN ;;GO DO AN RTI OR RTT TO LOAD THE PSW  
;;WITH A CLEARED 'T' BIT

023534  
023534 013700 000042  
023540 001405  
023542 000005  
023544 004710  
023546 000240  
023550 000240  
023552 000240  
023554

\$CLR.T:  
MOV @#42,R0 ;;INSURE R0 CONTAINS THE MONITORS  
BEQ \$DOAGN ;;RETURN ADDRESS  
RESET ;;CLEAR THE WORLD  
\$ENDAD: JSR PC,(R0) ;;GO TO MONITOR  
NOP ;;SAVE ROOM  
NOP ;;FOR  
NOP ;;ACT11

023554 104400  
023556 042716 000020  
023562 032777 010000 155364  
023570 001005  
023572 005137 023616  
023576 100402  
023600 052716 000020  
023604 012746 023612  
023610 000002

\$DOAGN:  
TRAP ;;PUSH OLD PSW AND PC ON STACK  
BIC #20,(SP) ;;CLEAR THE 'T' BIT  
BIT #BIT12,@SWR ;;RUN WITH TRACE TRAP?  
BNE 1\$ ;;BR IF NO  
COM \$TBIT ;;IS IT TIME FOR TRACE TRAP  
BMI 1\$ ;;BR IF NO  
BIS #20,(SP) ;;SET TRACE TRAP  
1\$: MOV #SLOOP,-(SP) ;;JUMP TO START OF TEST  
\$RTRN: RTI ;;RETURN--THIS IS CHANGED TO  
;;AN 'RTI' IF 'RTT' IS A LEGAL  
;;INSTRUCTION

023612  
023612 000137  
023614 023620  
023616 000000

\$LOOP:  
JMP @(PC)+ ;;RETURN  
\$RTNAD: .WORD FINISH  
\$TBIT: .WORD 0 ;;'T' BIT STATE INDICATOR

2  
3 023620 005737 001376  
4 023624 001004  
5 023626 104401 001207  
6 023632 104401 042402  
7 023636 104401 001207  
8 023642 104401 043004

FINISH: TST FAULT ;;COMPATIBLE ?  
BNE 1\$ ;;BRANCH IF NOT  
TYPE ,SCLF ;;CR-LF  
TYPE ,MSG15 ;;MESSAGE: ALL DRIVE COMPATIBLE  
1\$: TYPE ,SCLF ;;CR-LF  
TYPE ,MSG20

078

END OF PASS ROUTINE  
9 023646 104401 043022  
10 023652 104401 001207  
11 023656 000177 155516

TYPE ,STARS :TYPE STARS MESSAGE  
TYPE ,\$CRLF :CR-LF  
JMP @RSTART :JUMP TO RESTART

.SBTTL ERROR HANDLER ROUTINE

```

*****
*THIS ROUTINE WILL INCREMENT THE ERROR FLAG AND THE ERROR COUNT.
*SAVE THE ERROR ITEM NUMBER AND THE ADDRESS OF THE ERROR CALL
*AND GO TO $ERRTYP ON ERROR
*THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
*SW15=1      HALT ON ERROR
*SW13=1      INHIBIT ERROR TYPEOUTS
*SW10=1      BELL ON ERROR
*SW09=1      LOOP ON ERROR
*CALL
*
*      ERROR      N      ;;ERROR=EMT AND N=ERROR ITEM NUMBER
$ERROR:  CLRB      IBSAVE      ;;CLEAR THE ITEM BYTE SAVE LOCATION
          CKSWR
          7$:      INCB      $ERFLG      ;;TEST FOR CHANGE IN SOFT-SWR
          BEQ      7$      ;;SET THE ERROR FLAG
          MOV      $STNM,@DISPLAY      ;;DON'T LET THE FLAG GO TO ZERO
          BIT      #BIT10,@SWR      ;;DISPLAY TEST NUMBER AND ERROR FLAG
          BEQ      1$      ;;BELL ON ERROR?
          TYPE     ,SBELL      ;;NO - SKIP
          INC      $ERTTL      ;;RING BELL
          MOV      (SP), $ERRPC      ;;COUNT THE NUMBER OF ERRORS
          SUB      #2, $ERRPC      ;;GET ADDRESS OF ERROR INSTRUCTION
          MOVB     @ $ERRPC, $ITEMB      ;;STRIP AND SAVE THE ERROR ITEM CODE
          BIT      #BIT09,@SWR      ;;SEE IF LOOP ON ERROR IS SET
          BNE      1004$      ;;BRANCH AROUND ROUTINE IF SO
          CMPB     #177, $ITEMB      ;;SEE IF THIS IS THE POWER FAIL CALL
          BEQ      1004$      ;;BRANCH AROUND ROUTINE IF IT IS
          TSTB     IBSAVE      ;;SEE IF THIS IS THE 2ND ERROR CALL IN THIS ROUTINE
          BNE      1003$      ;;BRANCH IF SO
          CMP      #-1, CPSAVE      ;;SEE IF CPSAVE HAS CPU ERR REG TIMEOUT INDICATION
          BEQ      1004$      ;;BRANCH IF SO
          MOV      ERRVEC, -(SP)      ;;SAVE CONTENTS OF ERROR VECTOR
          MOV      #1000$, ERRVEC      ;;SETUP 'TRAP' RETURN ADDRESS
          MOV      177766, CPSAVE      ;;MOVE CPU ERROR REGISTER TO CPSAVE FOR TEST
          BR      1001$
          1000$:  MOV      #-1, CPSAVE      ;;SET CPU ERROR REGISTER TIMEOUT INDICATOR
          MOV      #1001$, (SP)      ;;SETUP RETURN ADDRESS
          RTI
          1001$:  MOV      (SP)+, ERRVEC      ;;RESTORE CONTENTS OF ERROR VECTOR
          1002$:  CMP      #-1, CPSAVE      ;;SEE IF CPSAVE HAS CPU ERR REG TIMEOUT INDICATION
          BEQ      1004$      ;;BRANCH IF SO
          BIT      #BIT00, CPSAVE      ;;SEE IF POWER MONITOR BIT IS SET IN CPU ERR REG
          BEQ      1004$      ;;BRANCH IF OK
          BIC      #BIT00, 177766      ;;CLEAR THE BIT FOUND SET
          MOVB     $ITEMB, IBSAVE      ;;MAKE IBSAVE NON-ZERO FOR DUAL ERROR CALL
          MOVB     #177, $ITEMB      ;;SET $ITEMB TO SPECIAL POWER FAIL POINTER
          BR      1004$      ;;BRANCH OVER IBSAVE CLEARING
          1003$:  CLRB      IBSAVE      ;;CLEAR IBSAVE SO 2ND TIME THROUGH EXITS
          1004$:  BIT      #BIT13,@SWR      ;;SKIP TYPEOUT IF SET
          BNE      20$      ;;SKIP TYPEOUTS
          JSR      PC, $ERRTYP      ;;GO TO USER ERROR ROUTINE
  
```

```

023662 105037 024254
023666 104407
023670 105237 001117
023674 001775
023676 013777 001116 155252
023704 032777 002000 155242
023712 001402
023714 104401 001202
023720 005237 001126
023724 011637 001132
023730 162737 000002 001132
023736 117737 155170 001130
023744 032777 001000 155202
023752 001060
023754 122737 000177 001130
023762 001454
023764 105737 024254
023770 001047
023772 022737 177777 024252
024000 001445
024002 013746 000004
024006 012737 024024 000004
024014 013737 177766 024252
024022 000406
024024 012737 177777 024252
024032 012716 024040
024036 000002
024040 012637 000004
          1000$:
024044 022737 177777 024252
024052 001420
024054 032737 000001 024252
024062 001414
024064 042737 000001 177766
024072 113737 001130 024254
024100 112737 000177 001130
024106 000402
          1001$:
024110 105037 024254
024114
024114 032777 020000 155032
024122 001004
024124 004737 024256
  
```

```

024130 104401 001207          TYPE      ,SCLRF
024134          20$:          CMPB      #APTENV,SENV      ;;RUNNING IN APT MODE
024134 122737 000001 001232  BNE          2$          ;;NO,SKIP APT ERROR REPORT
024142 001007          MOVB      $ITEMB,21$      ;;SET ITEM NUMBER AS ERROR NUMBER
024144 113737 001130 024156  JSR          PC,$ATY4      ;;REPORT FATAL ERROR TO APT
024152 004737 025150          .BYTE     0
024156      000          21$:          .BYTE     0
024157      000          22$:          BR          22$          ;;APT ERROR LOOP
024160 000777          2$:          TSTB      IBSAVE          ;;SEE IF IBSAVE IS LOADED
024162 105737 024254          BNE          3$          ;;BRANCH IF NOT - NO HALT ON PWR MON BIT ERROR
024166 001005          TST          @SWR          ;;HALT ON ERROR
024170 005777 154760          BPL          3$          ;;SKIP IF CONTINUE
024174 100002          HALT          ;;HALT ON ERROR!
024176 000000          CKSWR          ;;TEST FOR CHANGE IN SOFT-SWR
024200 104407          3$:          BIT          #BIT09,@SWR      ;;LOOP ON ERROR SWITCH SET?
024202          BEQ          4$          ;;BR IF NO
024210 001402          MOV          $LPERR,(SP)      ;;FUDGE RETURN FOR LOOPING
024212 013716 001124          4$:          TST          $ESCAPE      ;;CHECK FOR AN ESCAPE ADDRESS
024216 005737 001200          BEQ          5$          ;;BR IF NONE
024222 001402          MOV          $ESCAPE,(SP)      ;;FUDGE RETURN ADDRESS FOR ESCAPE
024224 013716 001200          5$:          CMP          #SENDAD,@#42      ;;ACT-11 AUTO-ACCEPT?
024230 022737 023544 000042  BNE          6$          ;;BRANCH IF NO
024236 001001          HALT          ;;YES
024240 000000          6$:          TSTB      IBSAVE          ;;SEE IF ITEM BYTE SAVE LOCATION HAS AN ERROR CALL
024242          BNE          7$          ;;BRANCH BACK TO CALL ORIGINAL ERROR
024242 105737 024254          RTI          ;;RETURN
024246 001210          CPSAVE: .WORD    0          ;;LOCATION TO SAVE CPU ERROR REG CONTENTS
024250 000002          IBSAVE: .WORD    0          ;;LOCATION TO SAVE ITEM BYTE
024252 000000
024254 000000

```

.SBTTL ERROR MESSAGE TYPEOUT ROUTINE

\*\*\*\*\*  
\*THIS ROUTINE USES THE 'ITEM CONTROL BYTE' (\$ITEMB) TO DETERMINE WHICH  
\*ERROR IS TO BE REPORTED. IT THEN OBTAINS, FROM THE 'ERROR TABLE' (\$ERRTB),  
\*AND REPORTS THE APPROPRIATE INFORMATION CONCERNING THE ERROR.

```

024256                                $ERRTYP:
024256 104401 001207                    TYPE      ,SCLRF      ;;'CARRIAGE RETURN' & 'LINE FEED'
024262 010046                          MOV      RO,-(SP)   ;;SAVE RO
024264 005000                          CLR      RO        ;;PICKUP THE ITEM INDEX
024266 153700 001130                    BISB    @($ITEMB,RO
024272 001004                          BNE     1$        ;;IF ITEM NUMBER IS ZERO, JUST
;;TYPE THE PC OF THE ERROR
024274 013746 001132                    MOV     $ERRPC,-(SP) ;;SAVE $ERRPC FOR TYPEOUT
;;ERROR ADDRESS
024300 104402                          TYPOC
024302 000437                          BR      6$        ;;GO TYPE--OCTAL ASCII(ALL DIGITS)
024304 122700 000177                    1$:      CMPB    #177,RO  ;;GET OUT
024310 001006                          BNE     1000$     ;;SEE IF THIS ERROR CALL IS SPECIAL POWER FAIL CALL
024312 013737 001216 024574            MOV     $TESTN,PFTSTN ;;BRANCH IF NOT
024320 012700 024434                    MOV     #PFECH,RO ;;GET TEST NUMBER
024324 000406                          BR      1001$    ;;MOVE POWER FAIL ERROR CALL TABLE TO RO
024326 005300                          1000$:  DEC     RO      ;;BRANCH TO CALL ERROR
024330 006300                          ASL     RO        ;;ADJUST THE INDEX SO THAT IT WILL
024332 006300                          ASL     RO        ;;WORK FOR THE ERROR TABLE
024334 006300                          ASL     RO
024336 062700 005362                    ADD     #$ERRTB,RO ;;FORM TABLE POINTER
024342 012037 024352                    1001$:  MOV     (RO)+,2$  ;;PICKUP 'ERROR MESSAGE' POINTER
024346 001404                          BEQ     3$        ;;SKIP TYPEOUT IF NO POINTER
024350 104401                          TYPE
024352 000000                          2$:      .WORD 0     ;;TYPE THE 'ERROR MESSAGE'
024354 104401 001207                    TYPE    ,SCLRF   ;;'ERROR MESSAGE' POINTER GOES HERE
024360 012037 024370                    3$:      MOV     (RO)+,4$ ;;'CARRIAGE RETURN' & 'LINE FEED'
024364 001404                          BEQ     5$        ;;PICKUP 'DATA HEADER' POINTER
024366 104401                          TYPE
024370 000000                          4$:      .WORD 0     ;;SKIP TYPEOUT IF 0
024372 104401 001207                    TYPE    ,SCLRF   ;;TYPE THE 'DATA HEADER'
024376 011000                          5$:      MOV     (RO),RO ;;'DATA HEADER' POINTER GOES HERE
024400 001004                          BNE     7$        ;;'CARRIAGE RETURN' & 'LINE FEED'
024402 012600                          6$:      MOV     (SP)+,RO ;;PICKUP 'DATA TABLE' POINTER
024404 104401 001207                    TYPE    ,SCLRF   ;;GO TYPE THE DATA
024410 000207                          RTS     PC        ;;RESTORE RO
024412                                7$:      ;;'CARRIAGE RETURN' & 'LINE FEED'
024412 013046                          MOV     @ (RO)+,-(SP) ;;RETURN
024414 104402                          TYPOC           ;;SAVE @ (RO)+ FOR TYPEOUT
024416 005710                          TST     (RO)     ;;GO TYPE--OCTAL ASCII(ALL DIGITS)
024420 001770                          BEQ     6$        ;;IS THERE ANOTHER NUMBER?
024422 104401 024430                    TYPE    ,8$      ;;BR IF NO
024426 000771                          BR      7$        ;;TYPE TWO(2) SPACES
024430 040 040 000 8$: .ASCIZ / /      ;;LOOP
;;TWO(2) SPACES
024434 024444 024526 024560 PFECH: PFECH1,PFECH2,PFECH3,PFECH4 ;;WORDS DEFINING TABLES BELOW
024444 120 117 127 PFECH1: .ASCIZ ?POWER MONITOR BIT IN CPU ERROR REGISTER FOUND SET?
024526 124 105 123 PFECH2: .ASCIZ ?TESTNO ERR PC CPUERREG?
;;TWO(2) SPACES
024560 024574 001132 024252 PFECH3: .WORD PFTSTN,$ERRPC,CPSAVE,0

```

2  
CZRMTBO RM05/3/2 DR CMPT TST  
ERROR MESSAGE TYPEOUT ROUTINE

MACRO V04.00 4-APR-81 18:12:15 PAGE 12-1 <sup>E 8</sup>

SEQ 0095

024570 000 000  
024574 000000

000 PFECH4: .BYTE 0,0,0,0  
PFTSTN: .WORD 0

:::CONTAINS TEST NUMBER FOR PF BI ERROR



.SBTTL TYPE ROUTINE

```

*****
*ROUTINE TO TYPE ASCIZ MESSAGE. MESSAGE MUST TERMINATE WITH A 0 BYTE.
*THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED.
*NOTE1: $NULL CONTAINS THE CHARACTER TO BE USED AS THE FILLER CHARACTER.
*NOTE2: $FILLS CONTAINS THE NUMBER OF FILLER CHARACTERS REQUIRED.
*NOTE3: $FILLC CONTAINS THE CHARACTER TO FILL AFTER.

```

```

*CALL:
*1) USING A TRAP INSTRUCTION
*      TYPE      ,MESADR      ;;MESADR IS FIRST ADDRESS OF AN ASCIZ STRING
*OR
*      TYPE
*      MESADR

```

```

024576 105737 001173 $TYPE: TSTB $TPFLG      ;; IS THERE A TERMINAL?
024602 100002          BPL 1$          ;; BR IF YES
024604 000000          HALT          ;; HALT HERE IF NO TERMINAL
024606 000430          BR 3$          ;; LEAVE
024610 010046          1$: MOV R0,-(SP)  ;; SAVE R0
024612 017600 000002  MOV @2(SP),R0  ;; GET ADDRESS OF ASCIZ STRING
024616 122737 000001 001232  CMPB #APTENV,$ENV  ;; RUNNING IN APT MODE
024624 001011          BNE 62$       ;; NO, GO CHECK FOR APT CONSOLE
024626 132737 000100 001233  BITB #APTSPOOL,$ENVM ;; SPOOL MESSAGE TO APT
024634 001405          BEQ 62$       ;; NO, GO CHECK FOR CONSOLE
024636 010037 024646  MOV R0,61$    ;; SETUP MESSAGE ADDRESS FOR APT
024642 004737 025140  JSR PC,$ATY3  ;; SPOOL MESSAGE TO APT
024646 000000          61$: .WORD 0    ;; MESSAGE ADDRESS
024650 132737 000040 001233 62$: BITB #APTCSUP,$ENVM ;; APT CONSOLE SUPPRESSED
024656 001003          BNE 60$       ;; YES, SKIP TYPE OUT
024660 112046          2$: MOVB (R0)+,-(SP) ;; PUSH CHARACTER TO BE TYPED ONTO STACK
024662 001005          BNE 4$          ;; BR IF IT ISN'T THE TERMINATOR
024664 005726          TST (SP)+     ;; IF TERMINATOR POP IT OFF THE STACK
024666 012600          60$: MOV (SP)+,R0  ;; RESTORE R0
024670 062716 000002  3$: ADD #2,(SP)  ;; ADJUST RETURN PC
024674 000002          RTI          ;; RETURN
024676 122716 000011  4$: CMPB #HT,(SP)  ;; BRANCH IF <HT>
024702 001430          BEQ 8$          ;;
024704 122716 000200  CMPB #CRLF,(SP)  ;; BRANCH IF NOT <CRLF>
024710 001006          BNE 5$          ;;
024712 005726          TST (SP)+     ;; POP <CR><LF> EQUIV
024714 104401          TYPE          ;; TYPE A CR AND LF
024716 001207          $CRLF
024720 105037 025126  CLRB $CHARCNT  ;; CLEAR CHARACTER COUNT
024724 000755          BR 2$          ;; GET NEXT CHARACTER
024726 004737 025010  5$: JSR PC,$TYPEC  ;; GO TYPE THIS CHARACTER
024732 123726 001172  6$: CMPB $FILLC,(SP)+  ;; IS IT TIME FOR FILLER CHARS.?
024736 001350          BNE 2$          ;; IF NO GO GET NEXT CHAR.
024740 013746 001170  MOV $NULL,-(SP)  ;; GET # OF FILLER CHARS. NEEDED
                                ;; AND THE NULL CHAR.
024744 105366 000001  7$: DECB 1(SP)    ;; DOES A NULL NEED TO BE TYPED?
024750 002770          BLT 6$          ;; BR IF NO--GO POP THE NULL OFF OF STACK
024752 004737 025010  JSR PC,$TYPEC  ;; GO TYPE A NULL
024756 105337 025126  DECB $CHARCNT  ;; DO NOT COUNT AS A COUNT
024762 000770          BR 7$          ;; LOOP

```

;HORIZONTAL TAB PROCESSOR

```

024764 112716 000040      8$:  MOVB  #',(SP)      ;;REPLACE TAB WITH SPACE
024770 004737 025010      9$:  JSR   PC,$TYPEC    ;;TYPE A SPACE
024774 132737 000007 025126 BITB  #7,$CHARCNT    ;;BRANCH IF NOT AT
025002 001372           BNE   9$             ;;TAB STOP
025004 005726           TST   (SP)+         ;;POP SPACE OFF STACK
025006 000724           BR    2$             ;;GET NEXT CHARACTER
025010                                     $TYPEC:
025010 105777 154144       TSTB  @STKS         ;;CHAR IN KYBD BUFFER?
025014 100022           BPL   10$           ;;BR IF NOT
025016 017746 154140       MOV   @STKB,-(SP)   ;;GET CHAR
025022 042716 177600       BIC   #177600,(SP) ;;STRIP EXTRANEIOUS BITS
025026 122716 000023       CMPB  #$XOFF,(SP)  ;;WAS CHAR XOFF
025032 001012           BNE   102$          ;;BR IF NOT
025034                                     101$:
025034 105777 154120       TSTB  @STKS         ;;WAIT FOR CHAR
025040 100375           BPL   101$          ;;GET CHAR
025042 117716 154114       MOVB  @STKB,(SP)   ;;STRIP IT
025046 042716 177600       BIC   #177600,(SP) ;;WAS IT XON?
025052 122716 000021       CMPB  #$XON,(SP)  ;;BR IF NOT
025056 001366           BNE   101$          ;;FIX STACK
025060                                     102$:
025060 005726           TST   (SP)+         ;;WAIT UNTIL PRINTER IS READY
025062                                     10$:
025062 105777 154076       TSTB  @STPS         ;;LOAD CHAR TO BE TYPED INTO DATA REG.
025066 100375           BPL   10$           ;;IS CHARACTER A CARRIAGE RETURN?
025070 116677 000002 154070 MOVB  2(SP),@STPB   ;;BRANCH IF NO
025076 122766 000015 000002 CMPB  #(CR,2(SP)    ;;YES--CLEAR CHARACTER COUNT
025104 001003           BNE   1$           ;;EXIT
025106 105037 025126       CLRB  $CHARCNT    ;;IS CHARACTER A LINE FEED?
025112 000406           BR    $TYPEX      ;;BRANCH IF YES
025114 122766 000012 000002 1$:  CMPB  #LF,2(SP)    ;;COUNT THE CHARACTER
025122 001402           BEQ   $TYPEX      ;;CHARACTER COUNT STORAGE
025124 105227           INCB  (PC)+
025126 000000       $CHARCNT: .WORD 0
025130 000207       $TYPEX: RTS      PC

```

.SBTTL APT COMMUNICATIONS ROUTINE

```

*****
025132 112737 000001 025376 $ATY1: MOVB #1,$FFLG ;;TO REPORT FATAL ERROR
025140 112737 000001 025374 $ATY3: MOVB #1,$MFLG ;;TO TYPE A MESSAGE
025146 000403
025150 112737 000001 025376 $ATY4: MOVB #1,$FFLG ;;TO ONLY REPORT FATAL ERROR
025156 $ATYC:
025156 010046 MOV R0,-(SP) ;;PUSH R0 ON STACK
025160 010146 MOV R1,-(SP) ;;PUSH R1 ON STACK
025162 105737 025374 TSTB $MFLG ;;SHOULD TYPE A MESSAGE?
025166 001450 BEQ 5$ ;;IF NOT: BR
025170 122737 000001 001232 CMPB #APTENV,$ENV ;;OPERATING UNDER APT?
025176 001031 BNE 3$ ;;IF NOT: BR
025200 132737 000100 001233 BITB #APTSPOOL,$ENVM ;;SHOULD SPOOL MESSAGES?
025206 001425 BEQ 3$ ;;IF NOT: BR
025210 017600 000004 MOV @4(SP),R0 ;;GET MESSAGE ADDR.
025214 062766 000002 000004 ADD #2,4(SP) ;;BUMP RETURN ADDR.
025222 005737 001212 1$: TST $MSGTYPE ;;SEE IF DONE W/ LAST XMISSION?
025226 001375 BNE 1$ ;;IF NOT: WAIT
025230 010037 001226 MOV R0,$MSGAD ;;PUT ADDR IN MAILBOX
025234 105720 2$: TSTB (R0)+ ;;FIND END OF MESSAGE
025236 001376 BNE 2$
025240 163700 001226 SUB $MSGAD,R0 ;;SUB START OF MESSAGE
025244 006200 ASR R0 ;;GET MESSAGE LGTH IN WORDS
025246 010037 001230 MOV R0,$MSGGLT ;;PUT LENGTH IN MAILBOX
025252 012737 000004 001212 MOV #4,$MSGTYPE ;;TELL APT TO TAKE MSG.
025260 000413 BR 5$
025262 017637 000004 025306 3$: MOV @4(SP),4$ ;;PUT MSG ADDR IN JSR LINKAGE
025270 062766 000002 000004 ADD #2,4(SP) ;;BUMP RETURN ADDRESS
025276 013746 177776 MOV 177776,-(SP) ;;PUSH 177776 ON STACK
025302 004737 024576 JSR PC,$TYPE ;;CALL TYPE MACRO
025306 000000 4$: .WORD 0
025310 5$:
025310 105737 025376 10$: TSTB $FFLG ;;SHOULD REPORT FATAL ERROR?
025314 001416 BEQ 12$ ;;IF NOT: BR
025316 005737 001232 TST $ENV ;;RUNNING UNDER APT?
025322 001413 BEQ 12$ ;;IF NOT: BR
025324 005737 001212 11$: TST $MSGTYPE ;;FINISHED LAST MESSAGE?
025330 001375 BNE 11$ ;;IF NOT: WAIT
025332 017637 000004 001214 MOV @4(SP),$FATAL ;;GET ERROR #
025340 062766 000002 000004 ADD #2,4(SP) ;;BUMP RETURN ADDR.
025346 005237 001212 INC $MSGTYPE ;;TELL APT TO TAKE ERROR
025352 105037 025376 12$: CLRB $FFLG ;;CLEAR FATAL FLAG
025356 105037 025375 CLRB $LFLG ;;CLEAR LOG FLAG
025362 105037 025374 CLRB $MFLG ;;CLEAR MESSAGE FLAG
025366 012601 MOV (SP)+,R1 ;;POP STACK INTO R1
025370 012600 MOV (SP)+,R0 ;;POP STACK INTO R0
025372 000207 RTS PC ;;RETURN
025374 000 $MFLG: .BYTE 0 ;;MESSG. FLAG
025375 000 $LFLG: .BYTE 0 ;;LOG FLAG
025376 000 $FFLG: .BYTE 0 ;;FATAL FLAG
.EVEN
000200 APTSIZE = 200
000001 APTENV = 001
000100 APTSPOOL = 100
000040 APTCSUP = 040

```

.SBTTL POWER DOWN AND UP ROUTINES

```

*****
:POWER DOWN ROUTINE
025400 012737 025552 000024 $PWRDN: MOV    $SILLUP,@#PWRVEC ;;SET FOR FAST UP
025406 012737 000340 000026      MOV    #340,@#PWRVEC+2 ;;PPIO:7
025414 010046      MOV    R0,-(SP) ;;PUSH R0 ON STACK
025416 010146      MOV    R1,-(SP) ;;PUSH R1 ON STACK
025420 010246      MOV    R2,-(SP) ;;PUSH R2 ON STACK
025422 010346      MOV    R3,-(SP) ;;PUSH R3 ON STACK
025424 010446      MOV    R4,-(SP) ;;PUSH R4 ON STACK
025426 010546      MOV    R5,-(SP) ;;PUSH R5 ON STACK
025430 017746 153520      MOV    @SWR,-(SP) ;;PUSH @SWR ON STACK
025434 010637 025556      MOV    SP,$SAVR6 ;;SAVE SP
025440 012737 025452 000024      MOV    #SPWRUP,@#PWRVEC ;;SET UP VECTOR
025446 000000      HALT
025450 000776      BR     .-2 ;;HANG UP

*****
:POWER UP ROUTINE
025452 012737 025552 000024 $PWRUP: MOV    $SILLUP,@#PWRVEC ;;SET FOR FAST DOWN
025460 013706 025556      MOV    $SAVR6,SP ;;GET SP
025464 005037 025556      CLR    $SAVR6 ;;WAIT LOOP FOR THE ITY
025470 005237 025556 1$: INC    $SAVR6 ;;WAIT FOR THE INC
025474 001375      BNE   1$ ;;OF WORD
025476 012677 153452      MOV    (SP)+,@SWR ;;POP STACK INTO @SWR
025502 012605      MOV    (SP)+,R5 ;;POP STACK INTO R5
025504 012604      MOV    (SP)+,R4 ;;POP STACK INTO R4
025506 012603      MOV    (SP)+,R3 ;;POP STACK INTO R3
025510 012602      MOV    (SP)+,R2 ;;POP STACK INTO R2
025512 012601      MOV    (SP)+,R1 ;;POP STACK INTO R1
025514 012600      MOV    (SP)+,R0 ;;POP STACK INTO R0
025516 012737 025400 000024      MOV    #SPWRDN,@#PWRVEC ;;SET UP THE POWER DOWN VECTOR
025524 012737 000340 000026      MOV    #340,@#PWRVEC+2 ;;PPIO:7
025532 104401      TYPE   ;;REPORT THE POWER FAILURE
025534 025560      $PWKMG: .WORD $POWER ;;POWER FAIL MESSAGE POINTER
025536 042766 000020 000002      BIC   #20,2(SP) ;;CLEAR 'T' BIT
025544 005037 023616      CLR   $TBIT ;;CLEAR THE 'T' BIT FLAG
025550 000002      RTI
025552 000000      $SILLUP: HALT ;;THE POWER UP SEQUENCE WAS STARTED
025554 000776      BR     .-2 ;; BEFORE THE POWER DOWN WAS COMPLETE
025556 000000      $SAVR6: 0 ;;PUT THE SP HERE
025560 015 012 120 $POWER: .ASCIZ <15><12>'POWER'
          .EVEN

```

.SBTTL BINARY TO OCTAL (ASCII) AND TYPE

```

*****
*THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 6-DIGIT
*OCTAL (ASCII) NUMBER AND TYPE IT.
*$TYPOS---ENTER HERE TO SETUP SUPPRESS ZEROS AND NUMBER OF DIGITS TO TYPE
*CALL:
*   MOV   NUM,-(SP)      ;;NUMBER TO BE TYPED
*   TYPOS          ;;CALL FOR TYPEOUT
*   .BYTE  N           ;;N=1 TO 6 FOR NUMBER OF DIGITS TO TYPE
*   .BYTE  M           ;;M=1 OR 0
*                           ;;1=TYPE LEADING ZEROS
*                           ;;0=SUPPRESS LEADING ZEROS
*$TYPON---ENTER HERE TO TYPE OUT WITH THE SAME PARAMETERS AS THE LAST
*$TYPOS OR $TYPOC
*CALL:
*   MOV   NUM,-(SP)      ;;NUMBER TO BE TYPED
*   TYPON          ;;CALL FOR TYPEOUT
*$TYPOC---ENTER HERE FOR TYPEOUT OF A 16 BIT NUMBER
*CALL:
*   MOV   NUM,-(SP)      ;;NUMBER TO BE TYPED
*   TYPOC          ;;CALL FOR TYPEOUT
    
```

025570	017646	000000		\$TYPOS:	MOV	@(SP),-(SP)	;;PICKUP THE MODE
025574	116637	000001	026013		MOVB	1(SP), \$OFILL	;;LOAD ZERO FILL SWITCH
025602	112637	026015			MOVB	(SP)+, \$OMODE+1	;;NUMBER OF DIGITS TO TYPE
025606	062716	000002			ADD	#2, (SP)	;;ADJUST RETURN ADDRESS
025612	000406				BR	\$TYPON	
025614	112737	000001	026013	\$TYPOC:	MOVB	#1, \$OFILL	;;SET THE ZERO FILL SWITCH
025622	112737	000006	026015		MOVB	#6, \$OMODE+1	;;SET FOR SIX(6) DIGITS
025630	112737	000005	026012	\$TYPON:	MOVB	#5, \$OCNT	;;SET THE ITERATION COUNT
025636	010346				MOV	R3, -(SP)	;;SAVE R3
025640	010446				MOV	R4, -(SP)	;;SAVE R4
025642	010546				MOV	R5, -(SP)	;;SAVE R5
025644	113704	026015			MOVB	\$OMODE+1, R4	;;GET THE NUMBER OF DIGITS TO TYPE
025650	005404				NEG	R4	
025652	062704	000006			ADD	#6, R4	;;SUBTRACT IT FOR MAX. ALLOWED
025656	110437	026014			MOVB	R4, \$OMODE	;;SAVE IT FOR USE
025662	113704	026013			MOVB	\$OFILL, R4	;;GET THE ZERO FILL SWITCH
025666	016605	000012			MOV	12(SP), R5	;;PICKUP THE INPUT NUMBER
025672	005003				CLR	R3	;;CLEAR THE OUTPUT WORD
025674	006105			1\$:	ROL	R5	;;ROTATE MSB INTO 'C'
025676	000404				BR	3\$	;;GO DO MSB
025700	006105			2\$:	ROL	R5	;;FORM THIS DIGIT
025702	006105				ROL	R5	
025704	006105				ROL	R5	
025706	010503				MOV	R5, R3	
025710	006103			3\$:	ROL	R3	;;GET LSB OF THIS DIGIT
025712	105337	026014			DECB	\$OMODE	;;TYPE THIS DIGIT?
025716	100016				BPL	7\$	;;BR IF NO
025720	042703	177770			BIC	#177770, R3	;;GET RID OF JUNK
025724	001002				BNE	4\$	;;TEST FOR 0
025726	005704				TST	R4	;;SUPPRESS THIS 0?
025730	001403				BEQ	5\$	;;BR IF YES
025732	005204			4\$:	INC	R4	;;DON'T SUPPRESS ANYMORE 0'S

025734	052703	000060		BIS	#'0,R3	::MAKE THIS DIGIT ASCII
025740	052703	000040	5\$:	BIS	#',R3	::MAKE ASCII IF NOT ALREADY
025744	110337	026010		MOVB	R3,8\$	::SAVE FOR TYPING
025750	104401	026010		TYPE	,8\$	::GO TYPE THIS DIGIT
025754	105337	026012	7\$:	DECB	\$OCNT	::COUNT BY 1
025760	003347			BGT	2\$	::BR IF MORE TO DO
025762	002402			BLT	6\$	::BR IF DONE
025764	005204			INC	R4	::INSURE LAST DIGIT ISN'T A BLANK
025766	000744			BR	2\$	::GO DO THE LAST DIGIT
025770	012605		6\$:	MOV	(SP)+,R5	::RESTORE R5
025772	012604			MOV	(SP)+,R4	::RESTORE R4
025774	012603			MOV,	(SP)+,R3	::RESTORE R3
025776	016666	000002 000004		MOV	2(SP),4(SP)	::SET THE STACK FOR RETURNING
026004	012616			MOV	(SP)+,(SP)	
026006	000002			RTI		::RETURN
026010	000		8\$:	.BYTE	0	::STORAGE FOR ASCII DIGIT
026011	000			.BYTE	0	::TERMINATOR FOR TYPE ROUTINE
026012	000		\$OCNT:	.BYTE	0	::OCTAL DIGIT COUNTER
026013	000		\$OFILL:	.BYTE	0	::ZERO FILL SWITCH
026014	000000		\$OMODE:	.WORD	0	::NUMBER OF DIGITS TO TYPE

.SBTTL CONVERT BINARY TO DECIMAL AND TYPE ROUTINE

\*\*\*\*\*  
 \*THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 5-DIGIT  
 \*SIGNED DECIMAL (ASCII) NUMBER AND TYPE IT. DEPENDING ON WHETHER THE  
 \*NUMBER IS POSITIVE OR NEGATIVE A SPACE OR A MINUS SIGN WILL BE TYPED  
 \*BEFORE THE FIRST DIGIT OF THE NUMBER. LEADING ZEROS WILL ALWAYS BE  
 \*REPLACED WITH SPACES.

\*CALL:  
 \* MOV NUM,-(SP) ;;PUT THE BINARY NUMBER ON THE STACK  
 \* TYPDS ;;GO TO THE ROUTINE

026016				\$TYPDS:	MOV	R0,-(SP)	::PUSH R0 ON STACK
026016	010046				MOV	R1,-(SP)	::PUSH R1 ON STACK
026020	010146				MOV	R2,-(SP)	::PUSH R2 ON STACK
026022	010246				MOV	R3,-(SP)	::PUSH R3 ON STACK
026024	010346				MOV	R5,-(SP)	::PUSH R5 ON STACK
026026	010546				MOV	#20200,-(SP)	::SET BLANK SWITCH AND SIGN
026030	012746	020200			MOV	20(SP),R5	::GET THE INPUT NUMBER
026034	016605	000020			BPL	1\$	::BR IF INPUT IS POS.
026040	100004				NEG	R5	::MAKE THE BINARY NUMBER POS.
026042	005405				MOV	#'-,1(SP)	::MAKE THE ASCII NUMBER NEG.
026044	112766	000055	000001	1\$:	CLR	R0	::ZERO THE CONSTANTS INDEX
026052	005000				MOV	#\$DBLK,R3	::SETUP THE OUTPUT POINTER
026054	012703	026232			MOV	#',(R3)+	::SET THE FIRST CHARACTER TO A BLANK
026060	112723	000040		2\$:	CLR	R2	::CLEAR THE BCD NUMBER
026064	005002				MOV	\$DTBL(R0),R1	::GET THE CONSTANT
026066	016001	026222		3\$:	SUB	R1,R5	::FORM THIS BCD DIGIT
026072	160105				BLT	4\$	::BR IF DONE
026074	002402				INC	R2	::INCREASE THE BCD DIGIT BY 1
026076	005202				BR	3\$	
026100	000774				ADD	R1,R5	::ADD BACK THE CONSTANT
026102	060105			4\$:	TST	R2	::CHECK IF BCD DIGIT=0
026104	005702				BNE	5\$	::"ALL THROUGH" IF 0
026106	001002				TSTB	(SP)	::STILL DOING LEADING 0'S?
026110	105716				BMI	7\$	::BR IF YES
026112	100407				ASLB	(SP)	::MSD?
026114	106316			5\$:	BCC	6\$	::BR IF NO
026116	103003				MOV	1(SP),-1(R3)	::YES--SET THE SIGN
026120	116663	000001	177777		BIS	#'0,R2	::MAKE THE BCD DIGIT ASCII
026126	052702	000060		6\$:	BIS	#',R2	::MAKE IT A SPACE IF NOT ALREADY A DIGIT
026132	052702	000040		7\$:	MOV	R2,(R3)+	::PUT THIS CHARACTER IN THE OUTPUT BUFFER
026136	110223				TST	(R0)+	::JUST INCREMENTING
026140	005720				CMP	R0,#10	::CHECK THE TABLE INDEX
026142	020027	000010			BLT	2\$	::GO DO THE NEXT DIGIT
026146	002746				BGT	8\$	::GO TO EXIT
026150	003002				MOV	R5,R2	::GET THE LSD
026152	010502				BR	6\$	::GO CHANGE TO ASCII
026154	000764				TSTB	(SP)+	::WAS THE LSD THE FIRST NON-ZERO?
026156	105726			8\$:	BPL	9\$	::BR IF NO
026160	100003				MOV	-1(SP),-2(R3)	::YES--SET THE SIGN FOR TYPING
026162	116663	177777	177776		CLRB	(R3)	::SET THE TERMINATOR
026170	105013			9\$:	MOV	(SP)+,R5	::POP STACK INTO R5
026172	012605				MOV	(SP)+,R3	::POP STACK INTO R3
026174	012603				MOV	(SP)+,R2	::POP STACK INTO R2
026176	012602				MOV	(SP)+,R1	::POP STACK INTO R1
026200	012601						

026202	012600			MOV	(SP)+,R0	::POP STACK INTO R0
026204	104401	G26232		TYPE	,SDBLK	::NOW TYPE THE NUMBER
026210	016666	000002	000004	MOV	2(SP),4(SP)	::ADJUST THE STACK
026216	012616			MOV	(SP)+,(SP)	
026220	000002			RTI		::RETURN TO USER
026222	023420		\$DTBL:	10000.		
026224	001750			1000.		
026226	000144			100.		
026230	000012			10.		
026232			\$DBLK:	.BLKW	4	



.SBTTL TTY INPUT ROUTINE

\*\*\*\*\*  
.ENABL LSB

\*\*\*\*\*  
\*SOFTWARE SWITCH REGISTER CHANGE ROUTINE.  
\*ROUTINE IS ENTERED FROM THE TRAP HANDLER, AND WILL  
\*SERVICE THE TEST FOR CHANGE IN SOFTWARE SWITCH REGISTER TRAP CALL  
\*WHEN OPERATING IN TTY FLAG MODE.

026242	022737	000176	001154	\$CKSWR: CMP	#SWREG,SWR	::: I. THE SOFT-SWR SELECTED?
026250	001074			BNE	15\$	::: BRANCH IF NO
026252	105777	152702		TSTB	@\$TKS	::: CHAR THERE?
026256	100071			BPL	15\$	::: IF NO, DON'T WAIT AROUND
026260	117746	152676		MOVB	@\$TKB,-(SP)	::: SAVE THE CHAR
026264	042716	177600		BIC	#^C177,(SP)	::: STRIP-OFF THE ASCII
026270	022726	000007		CMP	#7,(SP)+	::: IS IT A CONTROL G?
026274	001062			BNE	15\$	::: NO, RETURN TO USER
026276	123727	001150	000001	CMPB	\$AUTOB,#1	::: ARE WE RUNNING IN AUTO-MODE?
026304	001456			BEQ	15\$	::: BRANCH IF YES
026306	104401	026661		TYPE	,\$CNTLG	::: ECHO THE CONTROL-G (^G)
026312	104401	026666		\$GTSWR: TYPE	,\$MSWR	::: TYPE CURRENT CONTENTS
026316	013746	000176		MOV	SWREG,-(SP)	::: SAVE SWREG FOR TYPEOUT
026322	104402			TYPOC		::: GO TYPE--OCTAL ASCII(ALL DIGITS)
026324	104401	026677		TYPE	,\$MNEW	::: PROMPT FOR NEW SWR
026330	005046			19\$: CLR	-(SP)	::: CLEAR COUNTER
026332	005046			CLR	-(SP)	::: THE NEW SWR
026334	105777	152620		7\$: TSTB	@\$TKS	::: CHAR THERE?
026340	100375			BPL	7\$	::: IF NOT TRY AGAIN
026342	117746	152614		MOVB	@\$TKB,-(SP)	::: PICK UP CHAR
026346	042716	177600		BIC	#^C177,(SP)	::: MAKE IT 7-BIT ASCII
026352	021627	000025		9\$: CMP	(SP),#25	::: IS IT A CONTROL-U?
026356	001005			BNE	10\$	::: BRANCH IF NOT
026360	104401	026654		TYPE	,\$CNTLU	::: YES, ECHO CONTROL-U (^U)
026364	062706	000006		20\$: ADD	#6,SP	::: IGNORE PREVIOUS INPUT
026370	000757			BR	19\$	::: LET'S TRY IT AGAIN
026372	021627	000015		10\$: CMP	(SP),#15	::: IS IT A <CR>?
026376	001022			BNE	16\$	::: BRANCH IF NO
026400	005766	000004		TST	4(SP)	::: YES, IS IT THE FIRST CHAR?
026404	001403			BEQ	11\$	::: BRANCH IF YES
026406	016677	000002	152540	MOV	2(SP),@SWR	::: SAVE NEW SWR
026414	062706	000006		11\$: ADD	#6,SP	::: CLEAR UP STACK
026420	104401	001207		14\$: TYPE	,\$CRLF	::: ECHO <CR> AND <LF>
026424	123727	001151	000001	CMPB	\$INTAG,#1	::: RE-ENABLE TTY KBD INTERRUPTS?
026432	001003			BNE	15\$	::: BRANCH IF NOT
026434	012777	000100	152516	MOV	#100,@\$TKS	::: RE-ENABLE TTY KBD INTERRUPTS
026442	000002			15\$: RTI		::: RETURN
026444	004737	025010		16\$: JSR	PC,\$TYPEC	::: ECHO CHAR
026450	021627	000060		CMP	(SP),#60	::: CHAR < 0?
026454	002420			BLT	18\$	::: BRANCH IF YES

026456	021627	000067		CMP	(SP),#67	::CHAR > 7?
026462	003015			BGT	18\$	::BRANCH IF YES
026464	042726	000060		BIC	#60,(SP)+	::STRIP-OFF ASCII
026470	005766	000002		TST	2(SP)	::IS THIS THE FIRST CHAR
026474	001403			BEQ	17\$	::BRANCH IF YES
026476	006316			ASL	(SP)	::NO, SHIFT PRESENT
026500	006316			ASL	(SP)	::CHAR OVER TO MAKE
026502	006316			ASL	(SP)	::ROOM FOR NEW ONE.
026504	005266	000002	17\$:	INC	2(SP)	::KEEP COUNT OF CHAR
026510	056616	177776		BIS	-2,(SP),(SP)	::SET IN NEW CHAR
026514	000707			BR	7\$	::GET THE NEXT ONE
026516	104401	001206	18\$:	TYPE	\$QUES	::TYPE ?<CR><LF>
026522	000720			BR	20\$	::SIMULATE CONTROL-U
			.DSABL	LSB		

\*\*\*\*\*

\*THIS ROUTINE WILL INPUT A SINGLE CHARACTER FROM THE TTY

\*CALL:

*	RDCHR	::INPUT A SINGLE CHARACTER FROM THE TTY
*	RETURN HERE	::CHARACTER IS ON THE STACK
*		::WITH PARITY BIT STRIPPED OFF

026524	011646			*RDCHR: MOV	(SP),-(SP)	::PUSH DOWN THE PC	
026526	016666	000004	000002	MOV	4(SP),2(SP)	::SAVE THE PS	
026534	105777	152420		1\$:	TSTB	@\$TKS	::WAIT FOR
026540	100375			BPL	1\$	::A CHARACTER	
026542	117766	152414	000004	MOVB	@\$TKB,4(SP)	::READ THE TTY	
026550	042766	177600	000004	BIC	#^C<177>,4(SP)	::GET RID OF JUNK IF ANY	
026556	026627	000004	000023	CMP	4(SP),#23	::IS IT A CONTROL-S?	
026564	001013			BNE	3\$	::BRANCH IF NO	
026566	105777	152366		2\$:	TSTB	@\$TKS	::WAIT FOR A CHARACTER
026572	100375			BPL	2\$	::LOOP UNTIL ITS THERE	
026574	117746	152362		MOVB	@\$TKB,-(SP)	::GET CHARACTER	
026600	042716	177600		BIC	#^C<177>,(SP)	::MAKE IT 7-BIT ASCII	
026604	022627	000021		CMP	(SP)+,#21	::IS IT A CONTROL-Q?	
026610	001366			BNE	2\$	::IF NOT DISCARD IT	
026612	000750			BR	1\$	::YES, RESUME	
026614	026627	000004	000021	3\$:	CMP	4(SP),#\$XON	::IS IT A RANDOM XON?
026622	001744			BEQ	1\$	::BRANCH IF YES	
026624	026627	000004	000140	CMP	4(SP),#140	::IS IT UPPER CASE?	
026632	002407			BLT	4\$	::BRANCH IF YES	
026634	026627	000004	000175	CMP	4(SP),#175	::IS IT A SPECIAL CHAR?	
026642	003003			BGT	4\$	::BRANCH IF YES	
026644	042766	000040	000004	BIC	#40,4(SP)	::MAKE IT UPPER CASE	
026652	000002			4\$:	RTI	::GO BACK TO USER	
026654	136	125	015	\$CNTLU:	.ASCIZ /^U/<15><12>	::CONTROL 'U'	
026661	136	107	015	\$CNTLG:	.ASCIZ /^G/<15><12>	::CONTROL 'G'	
026666	015	012	123	\$MSWR:	.ASCIZ <15><12>/SWR = /		
026677	040	040	116	\$MNEW:	.ASCIZ / NEW = /		

.SBTTL SAVE AND RESTORE R0-R5 ROUTINES

```

*****
*SAVE R0-R5
*CALL:
*   SAVREG
*UPON RETURN FROM $SAVREG THE STACK WILL LOOK LIKE:
*
*TOP---(+16)
* +2---(+18)
* +4---R5
* +6---R4
* +8---R3
*+10---R2
*+12---R1
*+14---R0
  
```

```

026710
026710 010046
026712 010146
026714 010246
026716 010346
026720 010446
026722 010546
026724 016646 000022
026730 016646 000022
026734 016646 000022
026740 016646 000022
026744 000002
  
```

```

$SAVREG:
      MOV      R0,-(SP)      ;;PUSH R0 ON STACK
      MOV      R1,-(SP)      ;;PUSH R1 ON STACK
      MOV      R2,-(SP)      ;;PUSH R2 ON STACK
      MOV      R3,-(SP)      ;;PUSH R3 ON STACK
      MOV      R4,-(SP)      ;;PUSH R4 ON STACK
      MOV      R5,-(SP)      ;;PUSH R5 ON STACK
      MOV      22(SP),-(SP)   ;;SAVE PS OF MAIN FLOW
      MOV      22(SP),-(SP)   ;;SAVE PC OF MAIN FLOW
      MOV      22(SP),-(SP)   ;;SAVE PS OF CALL
      MOV      22(SP),-(SP)   ;;SAVE PC OF CALL
      RTI
  
```

```

*RESTORE R0-R5
*CALL:
*   RESREG
  
```

```

026746
026746 012666 000022
026752 012666 000022
026756 012666 000022
026762 012666 000022
026766 012605
026770 012604
026772 012603
026774 012602
026776 012601
027000 012600
027002 000002
  
```

```

$RESREG:
      MOV      (SP)+,22(SP)   ;;RESTORE PC OF CALL
      MOV      (SP)+,22(SP)   ;;RESTORE PS OF CALL
      MOV      (SP)+,22(SP)   ;;RESTORE PC OF MAIN FLOW
      MOV      (SP)+,22(SP)   ;;RESTORE PS OF MAIN FLOW
      MOV      (SP)+,R5       ;;POP STACK INTO R5
      MOV      (SP)+,R4       ;;POP STACK INTO R4
      MOV      (SP)+,R3       ;;POP STACK INTO R3
      MOV      (SP)+,R2       ;;POP STACK INTO R2
      MOV      (SP)+,R1       ;;POP STACK INTO R1
      MOV      (SP)+,R0       ;;POP STACK INTO R0
      RTI
  
```

.SBTTL DOUBLE LENGTH BINARY TO DECIMAL ASCII CONVERT ROUTINE

\*\*\*\*\*  
 \*THIS ROUTINE WILL CONVERT A 32-BIT BINARY NUMBER TO AN UNSIGNED  
 \*DECIMAL (ASCII) NUMBER. THE SIGN OF THE BINARY NUMBER MUST BE  
 \*POSITIVE.  
 \*CALL

```

*      MOV      #PNTR,-(SP)      ;; POINTER TO LOW WORD OF BINARY NUMBER
*      JSR      PC,@#$DB2D
*      RETURN
    ;; THE FIRST ADDRESS OF ASCII
    ;; IS ON THE STACK
    
```

```

027004 104412          $DB2D: SAVREG      ;; SAVE REGISTERS
027006 016602 000002  MOV      2(SP),R2      ;; PICKUP THE DATA POINTER
027012 012700 027164  MOV      #$DECVL,R0      ;; GET ADDRESS OF '$DECVL' STRING
027016 010666 000002  MOV      R0,2(SP)        ;; PUT ADDRESS OF ASCII STRING ON STACK
027022 012201          MOV      (R2)+,R1      ;; PICKUP THE BINARY NUMBER
027024 012202          MOV      (R2)+,R2
027026 012737 000012 027102  MOV      #10.,4$        ;; SET UP TO DO 10 CONVERSIONS
027034 012704 027114  MOV      #$TNPWR,R4      ;; ADDRESS OF TEN POWER
027040 012705 027116  MOV      #$TNPWR+2,R5
027044 005003          1$: CLR      R3              ;; CLEAR PARTIAL
027046 161401          2$: SUB      (R4),R1      ;; SUBTRACT TEN POWER
027050 005602          SEC      R2
027052 161502          SUB      (R5),R2
027054 002402          BLT      3$
027056 005203          INC      R3              ;; BR IF TEN POWER TO LARGE
027060 000772          BR      2$              ;; ADD 1 TO PARTIAL
027062 062401          3$: ADD      (R4)+,R1      ;; LOOP
027064 005502          ADC      R2              ;; RESTORE SUBTRACTED VALUE
027066 062402          ADD      (R4)+,R2
027070 022525          CMP      (R5)+,(R5)+      ;; MOVE TO NEXT TEN POWER
027072 052703 000060  BIS      #0,R3          ;; CHANGE PARTIAL TO ASCII
027076 110320          MOVB   R3,(R0)+      ;; SAVE IT
027100 005327          DEC      (PC)+          ;; DONE?
027102 000000          4$: .WORD   0
027104 001357          BNE     1$              ;; BR IF NO
027106 105020          CLRB   (R0)+          ;; TERMINATOR
027110 104413          RESREG      ;; RESTORE REGISTERS
027112 000207          RTS     PC          ;; RETURN
027114 145000          $TNPWR: 145000      ;; 1.0E09
027116 035632          35632
027120 160400          160400      ;; 1.0E08
027122 002765          2765
027124 113200          113200      ;; 1.0E07
027126 000230          230
027130 041100          041100      ;; 1.0E06
027132 000017          17
027134 103240          103240      ;; 1.0E05
027136 000001          1
027140 023420          23420      ;; 1.0E04
027142 000000          0
027144 001750          1750      ;; 1.0E03
027146 000000          0
027150 000144          144      ;; 1.0E02
027152 000000          0
    
```

027154 J00012  
027156 000000  
027160 000001  
027162 000000  
027164

12  
0  
1  
0  
\$DECVL: .BLKB 12.

:::1.0E01  
:::1.0E00  
:::RESERVE STORAGE FOR ASCII STRING

.SBTTL DOUBLE LENGTH BINARY TO OCTAL ASCII CONVERT ROUTINE

```

*****
*THIS ROUTINE WILL CONVERT A 32-BIT UNSIGNED BINARY NUMBER TO AN
*UNSIGNED OCTAL ASCIIZ NUMBER.
*CALL
*   MOV   #PNTR,-(SP)   ;; POINTER TO LOW WORD OF BINARY NUMBER
*   JSR   PC,@#$DB20   ;; CALL THE ROUTINE
*   RETURN              ;; THE ADDRESS OF THE FIRST ASCIIZ CHAR. IS ON THE STACK
    
```

027200	104412		\$DB20:	SAVREG		;; SAVE ALL REGISTERS
027202	016601	000002		MOV	2(SP),R1	;; PICKUP THE POINTER TO LOW WORD
027206	012705	027317		MOV	#\$OCTVL+13.,R5	;; POINTER TO DATA TABLE
027212	012704	000014		MOV	#12.,R4	;; DO ELEVEN CHARACTERS
027216	012703	177770		MOV	^C7,R3	;; MASK
027222	012100			MOV	(R1)+,R0	;; LOWER WORD
027224	012101			MOV	(R1)+,R1	;; HIGH WORD
027226	005002			CLR	R2	;; TERMINATOR
027230	110245		1\$:	MOV#	R2,-(R5)	;; PUT CHARACTER IN DATA TABLE
027232	010002			MOV	R0,R2	;; GET THIS DIGIT
027234	005304			DEC	R4	;; COUNT THIS CHARACTER
027236	003007			BGT	3\$	;; BR IF NOT THE LAST DIGIT
027240	001405			BEQ	2\$	;; BR IF IT IS THE LAST DIGIT
027242	005205			INC	R5	;; ALL DIGITS DONE-ADJUST POINTER FOR FIRST
027244	010566	000002		MOV	R5,2(SP)	;; ASCIIZ CHAR. & PUT IT ON THE STACK
027250	104413			RESREG		;; RESTORE ALL REGISTERS
027252	000207			RTS	PC	;; RETURN TO USER
027254	006203		2\$:	ASR	R3	;; POSITION THE MASK FOR THE LAST DIGIT
027256	006001		3\$:	ROR	R1	;; POSITION THE BINARY NUMBER FOR
027260	006000			ROR	R0	;; THE NEXT OCTAL DIGIT
027262	006001			ROR	R1	
027264	006000			ROR	R0	
027266	006001			ROR	R1	
027270	006000			ROR	R0	
027272	040302			BIC	R3,R2	;; MASK OUT ALL JUNK
027274	062702	000060		ADD	#0,R2	;; MAKE THIS CHAR. ASCII
027300	000753			BR	1\$	;; GO PUT IT IN THE DATA TABLE
027302			\$OCTVL:	.BLKB	14.	;; RESERVE DATA TABLE

.SBTTL SCOPE HANDLER ROUTINE

```

*****
*THIS ROUTINE CONTROLS THE LOOPING OF SUBTESTS. IT WILL INCREMENT
*AND LOAD THE TEST NUMBER($TSTNM) INTO THE DISPLAY REG.(DISPLAY<7:0>)
*AND LOAD THE ERROR FLAG ($ERFLG) INTO DISPLAY<15:08>
*THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
*SW14=1      LOOP ON TEST
*SW11=1      INHIBIT ITERATIONS
*SW09=1      LOOP ON ERROR
*SW08=1      LOOP ON TEST IN SWR<7:0>
*CALL
*          SCOPE          ;;SCOPE=IOT
    
```

```

027320          $SCOPE:
027320 104407          CKSWR
027322 032777 040000 151624 1$: BIT #BIT14,@SWR ;;TEST FOR CHANGE IN SOFT-SWR
027330 001402          BEQ 9$ ;;LOOP ON PRESENT TEST?
027332 000137 027730          JMP $OVER ;;NO IF SW14=0
027336          9$: ;;JUMP OVER SCOPE ROUTINE
          ;;*****START OF CODE FOR THE XOR TESTER*****
027336 000416 $XTSTR: BR 6$ ;;IF RUNNING ON THE 'XOR' TESTER (CHANGE
          ;;THIS INSTRUCTION TO A 'NOP' (NOP=240)
027340 013746 000004          MOV @ERRVEC,-(SP) ;;SAVE THE CONTENTS OF THE ERROR VECTOR
027344 012737 027364 000004          MOV #5$,@ERRVEC ;;SET FOR TIMEOUT
027352 005737 177060          TST @#177060 ;;TIME OUT ON XOR?
027356 012637 000004          MOV (SP)+,@ERRVEC ;;RESTORE THE ERROR VECTOR
027362 000544          BR $SVLAD ;;GO TO THE NEXT TEST
027364 022626          5$: CMP (SP)+,(SP)+ ;;CLEAR THE STACK AFTER A TIME OUT
027366 012637 000004          MOV (SP)+,@ERRVEC ;;RESTORE THE ERROR VECTOR
027372 000504          BR 7$ ;;LOOP ON THE PRESENT TEST
027374          6$:;*****END OF CODE FOR THE XOR TESTER*****
027374 032777 000400 151552          BIT #BIT08,@SWR ;;LOOP ON SPEC. TEST?
027402 001404          BEQ 2$ ;;BR IF NO
027404 127737 151544 001116          CMPB @SWR,$TSTNM ;;ON THE RIGHT TEST? SWR<7:0>
027412 001546          BEQ $OVER ;;BR IF YES
027414 105737 001117          2$: TSTB $ERFLG ;;HAS AN ERROR OCCURRED?
027420 001502          BEQ 3$ ;;BR IF NO
027422 022737 177777 024252          CMP #-1,CPSAVE ;;SEE IF TIMEOUT WAS PREVIOUSLY RECORDED
027430 001455          BEQ 2003$ ;;KICK AROUND ROUTINE IF SO
027432 013746 000004          MOV ERRVEC,-(SP) ;;SAVE CONTENTS OF ERROR VECTOR
027436 012737 027454 000004          MOV #2000$,ERRVEC ;;SETUP 'TRAP' RETURN ADDRESS
027444 013737 177766 024252          MOV 177766,CPSAVE ;;MOVE CPU ERROR REGISTER TO CPSAVE FOR TEST
027452 000406          BR 2001$
027454 012737 177777 024252 2000$: MOV #-1,CPSAVE ;;SET CPU ERROR REGISTER TIMEOUT INDICATOR
027462 012716 027470          MOV #2001$,(SP) ;;SETUP RETURN ADDRESS
027466 000002          RTI
027470 012637 000004          2001$: MOV (SP)+,ERRVEC ;;RESTORE CONTENTS OF ERROR VECTOR

027474 022737 177777 024252 2002$: CMP #-1,CPSAVE ;;SEE IF CPSAVE HAS CPU ERR REG TIMEOUT INDICATION
027502 001430          BEQ 2003$ ;;BRANCH IF SO
027504 032737 000001 024252          BIT #BIT00,CPSAVE ;;SEE IF THE POWER MONITOR BIT IS ON
027512 001424          BEQ 2003$ ;;BRANCH TO CONTINUE ROUTINE IF CLEAR
027514 042737 000001 177766          BIC #BIT00,177766 ;;CLEAR THE BIT FOUND TO BE SET
027522 013746 001154          MOV SWR,-(SP) ;;SAVE SWR ADDRESS
027526 017646 000000          MOV @($P),-(3P) ;;SAVE SWR VALUE
027532 012737 000176 001154          MOV #176,SWR ;;GET SOFTWARE SWR ADDRESS
    
```





.SBTTL ROUTINE TO SIZE MEMU.Y

```

*****
*CALL:
*   JSR   PC,$SIZE
*   RETURN
* $LSTAD WILL CONTAIN THE LAST AVAILABLE MEMORY LOCATION

027746 010046          $SIZE: MOV   R0,-(SP)      ;;SAVE R0 ON THE STACK
027750 010146          MOV   R1,-(SP)      ;;SAVE R1 ON THE STACK
027752 013746 000114   MOV   @#114,-(SP)    ;;SAVE MEMORY ERROR VECTOR PS & PC
027756 013746 000116   MOV   @#116,-(SP)
027762 012737 000116 000114   MOV   #116,@#114      ;;IGNORE PARITY ERRORS WHILE SIZING
027770 012737 000002 000116   MOV   #RTI,@#116
027776 013746 000004          MOV   @#ERRVEC,-(SP)  ;;SAVE PRESENT ERROR VECTOR PS & PC
030002 013746 000006   MOV   @#ERRVEC+2,-(SP)
030006 010600          MOV   SP,R0          ;;SAVE THE STACK POINTER
;;SET THE ERRVEC PS TO THE PRESENT PS
030010 104400          TRAP
030012 012637 000006          MOV   (SP)+,@#ERRVEC+2 ;;PUSH OLD PSW AND PC ON STACK
030016 012737 030036 000004   MOV   #2,@#ERRVEC    ;;SAVE THE PSW IN @#ERRVEC+2
030024 012701 020000          MOV   #2$,@#ERRVEC   ;;SET FOR TIMEOUT
030030 005711          MOV   #20000,R1     ;;FIRST ADDRESS
030032 005721          1$: TST   (R1)         ;;TEST THIS ADDRESS
030034 000775          TST   (R1)+        ;;STEP TO NEXT ADDRESS
030036 162701 000002          BR    1$          ;;TRY ANOTHER
030042 010006          2$: SUB   #2,R1     ;;DROP BACK
030044 012637 000006          MOV   R0,SP        ;;RESTORE THE STACK
030050 012637 000004          MOV   (SP)+,@#ERRVEC+2 ;;RESTORE ERROR VECTOR
030054 012637 000116          MOV   (SP)+,@#ERRVEC
030060 012637 000114          MOV   (SP)+,@#116   ;;RESTORE MEMORY ERROR VECTOR
030064 010137 030076          MOV   (SP)+,@#114
030070 012601          MOV   R1,$LSTAD    ;;LAST ADDRESS
030072 012600          MOV   (SP)+,R1     ;;RESTORE R1
030074 000207          MOV   (SP)+,R0     ;;RESTORE R0
030076 000000          RTS   PC
$LSTAD: .WORD 0          ;;CONTAINS THE LAST ADDRESS
  
```

.SBTTL TRAP DECODER

\*\*\*\*\*  
 : \*THIS ROUTINE WILL PICKUP THE LOWER BYTE OF THE "TRAP" INSTRUCTION  
 : \*AND USE IT TO INDEX THROUGH THE TRAP TABLE FOR THE STARTING ADDRESS  
 : \*OF THE DESIRED ROUTINE. THEN USING THE ADDRESS OBTAINED IT WILL  
 : \*GO TO THAT ROUTINE.

030100	010046		\$TRAP: MOV	R0,-(SP)	::SAVE R0	
030102	016600	000002		MOV	2(SP),R0	::GET TRAP ADDRESS
030106	005740			TST	-(R0)	::BACKUP BY 2
030110	111000			MOVB	(R0),R0	::GET RIGHT BYTE OF TRAP
030112	006300			ASL	R0	::POSITION FOR INDEXING
030114	016000	030134		MOV	\$TRPAD(R0),R0	::INDEX TO TABLE
030120	000200			RTS	R0	::GO TO ROUTINE

::THIS IS USE TO HANDLE THE "GETPRI" MACRO

030122	011646		\$TRAP2: MOV	(SP),-(SP)	::MOVE THE PC DOWN	
030124	016666	000004		MOV	4(SP),2(SP)	::MOVE THE PSW DOWN
030132	000002	000002		RTI		::RESTORE THE PSW

.SBTTL TRAP TABLE

: \*THIS TABLE CONTAINS THE STARTING ADDRESSES OF THE ROUTINES CALLED  
 : \*BY THE "TRAP" INSTRUCTION.

			:	ROUTINE	
			:	-----	
030134	030122		\$TRPAD:	.WORD	\$TRAP2
030136	024576			\$TYPE	::CALL=TYPE TRAP+1(104401) TTY TYPEOUT ROUTINE
030140	025614			\$TYPOC	::CALL=TYPOC TRAP+2(104402) TYPE OCTAL NUMBER (WITH LEADING ZEROS)
030142	025570			\$TYPOS	::CALL=TYPOS TRAP+3(104403) TYPE OCTAL NUMBER (NO LEADING ZEROS)
030144	025630			\$TYPON	::CALL=TYPON TRAP+4(104404) TYPE OCTAL NUMBER (AS PER LAST CALL)
030146	026016			\$TYPDS	::CALL=TYPDS TRAP+5(104405) TYPE DECIMAL NUMBER (WITH SIGN)
030150	026312			\$GTSWR	::CALL=GTSWR TRAP+6(104406) GET SOFT-SWR SETTING
030152	026242			\$CKSWR	::CALL=CKSWR TRAP+7(104407) TEST FOR CHANGE IN SOFT-SWR
030154	026524			\$RDCHR	::CALL=RDCHR TRAP+10(104410) TTY TYPEIN CHARACTER ROUTINE
030156	023150			\$RDLIN	::CALL=RDLIN TRAP+11(104411) TTY TYPEIN STRING ROUTINE
030160	026710			\$SAVREG	::CALL=SAVREG TRAP+12(104412) SAVE R0-R5 ROUTINE
030162	026746			\$RESREG	::CALL=RESREG TRAP+13(104413) RESTORE R0-R5 ROUTINE
2 030164	022366			\$DSPLY	::CALL=DISPLY TRAP+14(104414) ROUTINE TO TYPE ERROR MESSAGES
3	000032			\$TERM=.	-\$TRPAD

1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
33  
34  
35  
36  
37  
38  
39  
40  
43  
44  
45  
46  
47  
48  
49

```
.SBTTL SINGLE/DUAL PORT RH/RM DRIVER (REV 6.5) 1981

;NEW DRIVE TYPE ID FOR RM02 *****
;10-AUG-77 *****
;10-MAR-78 THE SC, SC5 CHANGES
;NEW DRIVE TYPE ID FOR RM05 *****
;1980 *****

;COPYRIGHT (C) 1977,1981
;DIGITAL EQUIPMENT CORP.
;MAYNARD, MA 01754
;AUTHOR(S): JIM LACEY/CHUCK HESS
;REVISED BY: MIKE LEAVITT 11-APR-80, 27-MAR-81

;*****

;STORAGE FOR RMDs, RMER1, RMER2, AND RMMR2 ON AN ERROR '2'
;RMERRS = RMDs
;RMERRS+2 = RMER1
;RMERRS+4 = RMER2
;RMERRS+6 = RMMR2
030166 000000 000000 000000 RMERRS: .WORD 0,0,0,0

;TABLE OF DRIVE ACTIVE INDICATORS (DRVACT=8 BYTES)
;DRVACT=0 IF DRIVE IS IDLE
;DRVACT>0 IF DRIVE IS ACTIVE WITH A COMMAND
;DRVACT<0 IF DRIVE IS ACTIVE WITH AN ERROR RECOVERY OPERATION

DRVACT: .BYTE 0 ;DRIVE 0
        .BYTE 0 ;DRIVE 1
        .BYTE 0 ;DRIVE 2
        .BYTE 0 ;DRIVE 3
        .BYTE 0 ;DRIVE 4
        .BYTE 0 ;DRIVE 5
        .BYTE 0 ;DRIVE 6
        .BYTE 0 ;DRIVE 7

;TABLE OF DRIVE STATUS INDICATORS (DRVSTA=8 BYTES)
;DRVSTA=0 IF DRIVE IS OFFLINE OR NONEXSITENT
;DRVSTA>0 IF DRIVE IS ONLINE
;DRVSTA<0 IF DRIVE IS UNSAFE

DRVSTA: .BYTE 0 ;DRIVE 0
        .BYTE 0 ;DRIVE 1
        .BYTE 0 ;DRIVE 2
        .BYTE 0 ;DRIVE 3
        .BYTE 0 ;DRIVE 4
        .BYTE 0 ;DRIVE 5
        .BYTE 0 ;DRIVE 6
        .BYTE 0 ;DRIVE 7

;TABLE OF DRIVE TYPES (DRV TYP=8 BYTES)
;DRV TYP=0 IF DRIVE IS NONEXISTENT (DRVSTA=0, ALSO)
;DRV TYP=7 IF DRIVE IS RM05 *****
;DRV TYP=5 IF DRIVE IS RM02 *****
;DRV TYP=4 IF DRIVE IS RM03
```

```

50                                     ;DRV TYP=-1 IF NOT RM05/3/2
51
52 030216      000      DRV TYP: .BYTE 0      ;DRIVE 0
55 030217      000      .BYTE 0      ;DRIVE 1
    030220      000      .BYTE 0      ;DRIVE 2
    030221      000      .BYTE 0      ;DRIVE 3
    030222      000      .BYTE 0      ;DRIVE 4
    030223      000      .BYTE 0      ;DRIVE 5
    030224      000      .BYTE 0      ;DRIVE 6
    030225      000      .BYTE 0      ;DRIVE 7
56
57                                     ;TABLE OF DUAL PORT INITIALIZATION INDICATORS
58                                     ;DPINT=0 IF INITIALIZATION IS NOT ACTIVE ON THE DRIVE
59                                     ;DPINT<0 IF INITIALIZATION IS IN PROGRESS
60
61 030226      000      DPINT: .BYTE ^      ;DRIVE 0
64 030227      000      .BYTE U      ;DRIVE 1
    030230      000      .BYTE 0      ;DRIVE 2
    030231      000      .BYTE 0      ;DRIVE 3
    030232      000      .BYTE 0      ;DRIVE 4
    030233      000      .BYTE 0      ;DRIVE 5
    030234      000      .BYTE 0      ;DRIVE 6
    030235      000      .BYTE 0      ;DRIVE 7
65
66                                     ;TABLE OF PENDING DUAL PORT REQUESTS
67                                     ;DPRQS=0 IF THAT A DUAL PORT REQUEST IS NOT PENDING FOR THAT DRIVE
68                                     ;DPRQS<0 IF THAT A DUAL PORT REQUEST IS PENDING FOR THAT DRIVE
69
70 030236      000      DPRQS: .BYTE 0      ;DRIVE 0
73 030237      000      .BYTE 0      ;DRIVE 1
    030240      000      .BYTE 0      ;DRIVE 2
    030241      000      .BYTE 0      ;DRIVE 3
    030242      000      .BYTE 0      ;DRIVE 4
    030243      000      .BYTE 0      ;DRIVE 5
    030244      000      .BYTE 0      ;DRIVE 6
    030245      000      .BYTE 0      ;DRIVE 7
74
75                                     ;TRANSFER WAIT FLAG (TRNSWT=1 WORD)
76                                     ;THIS IS A ONE WORD QUEUE. IT WILL CONTAIN THE ADDRESS OF
77                                     ;'DPB' OF THE I/O OPERATION.
78
79 030246      000000    TRNSWT: .WORD 0
80
81                                     ;SEARCH WAIT KEYS (SRCHWT=1 WORD)
82                                     ;THIS IS A ONE WORD QUEUE THAT WILL CONTAIN A KEY FOR EACH OF
83                                     ;THE DRIVES THAT ARE PERFORMING A SEARCH COMMAND FOR THE I/O
84                                     ;REQUEST THAT IS AT THE TOP OF THEIR REQUEST QUEUE.
85                                     ;EACH DRIVE IS ASSIGNED ONE BIT, STARTING AT BIT00 FOR DRIVE 0.
86
87 030250      000000    SRCHWT: .WORD 0
88
89                                     ;RM DRIVER ACTIVE FLAG (ACTDRV=1 BYTE)
90                                     ;ACTDRV=0 IF DRIVER IS INACTIVE
91                                     ;ACTDRV>0 IF DRIVER IS ACTIVE
92
93 030252      000      ACTDRV: .BYTE 0
94
    
```

```

95 ;SOFTWARE TIMER ROUTINE ACTIVE FLAG (ACTSTR=1 BYTE)
96 ;ACTSTR=0 IF SOFTWARE TIMER ROUTINE IS INACTIVE
97 ;ACTSTR>0 IF SOFTWARE TIMER ROUTINE IS ACTIVE
98
99 030253 000 ACTSTR: .BYTE 0
100
101 ;UNLOAD FLAG (ULDFLG=8 BYTES)
102 ;ULDFLG=0 IF NO UNLOAD COMMAND
103 ;ULDFLG>0 IF UNLOAD COMMAND IN PROGRESS
104 ;ULDFLG<0 IF UNLOAD COMMAND IN WAIT QUEUE
105
106 030254 000 ULDFLG: .BYTE 0 ;DRIVE 0
109 030255 000 .BYTE 0 ;DRIVE 1
    030256 000 .BYTE 0 ;DRIVE 2
    030257 000 .BYTE 0 ;DRIVE 3
    030260 000 .BYTE 0 ;DRIVE 4
    030261 000 .BYTE 0 ;DRIVE 5
    030262 000 .BYTE 0 ;DRIVE 6
    030263 000 .BYTE 0 ;DRIVE 7
110
111 ;SAVE REGISTERS FLAG (SAVEFG =1 WORD)
112 ;SAVEFG <0 IF SAVE THE RH/RM REGISTERS WHEN THE
113 ;OPERATION IS COMPLETED AS PER (DPB+14).
114 ;SAVEFG=0 IF SAVE THE RH/RM REGISTERS, AS PER
115 ;(DPB+14), AFTER AN ERROR.
116
117 030264 000000 SAVEFG: .WORD 0
118
119 ;SEEK FLAG (SEEKFG=1 WORD)
120 ;SEEKFG=0 IF WHEN THE DISK ADDRESS ISN'T IN THE WINDOW
121 ;FOR A DATA TRANSFER START A SEARCH COMMAND
122 ;SEEKFG<0 IF DATA TRANSFER WILL DO IMPLIED SEEKS.
123 ;DISREGARD THE WINDOW
124
125 030266 177777 SEEKFG: .WORD -1
126
127 ;TIMEOUT TABLE (TIMER=8 WORDS)
128 ;THIS TABLE CONTAINS THE TIME ALLOWED FOR AN OPERATION
129
130 030270 177777 TIMER: .WORD -1 ;DRIVE 0
133 030272 177777 .WORD -1 ;DRIVE 1
    030274 177777 .WORD -1 ;DRIVE 2
    030276 177777 .WORD -1 ;DRIVE 3
    030300 177777 .WORD -1 ;DRIVE 4
    030302 177777 .WORD -1 ;DRIVE 5
    030304 177777 .WORD -1 ;DRIVE 6
    030306 177777 .WORD -1 ;DRIVE 7
134
135 ;DATA TRANSFER UNDERWAY INDICATOR (DTUW=1 WORD)
136 ;DTUW<0 IF NO DATA TRANSFER UNDERWAY
137 ;DTUW=+N (WHERE N=0 TO 7) IMPLIES DATA TRANSFER UNDERWAY ON DRIVE N
138
139 030310 177777 DTUW: .WORD -1
140
141 ;ATTENTION BITS TABLE (ATABIT=8 BYTES)
142 ;THIS TABLE CONTAINS THE CORRESPONDING BIT TO EACH DRIVES
143 ;ATTENTION BIT

```

```

144
145 030312 001          ATABIT: .BYTE 1          ;DRIVE 0
146 030313 002          .BYTE 2          ;DRIVE 1
147 030314 004          .BYTE 4          ;DRIVE 2
148 030315 010          .BYTE 10         ;DRIVE 3
149 030316 020          .BYTE 20         ;DRIVE 4
150 030317 040          .BYTE 40         ;DRIVE 5
151 030320 100          .BYTE 100        ;DRIVE 6
152 030321 200          .BYTE 200        ;DRIVE 7
153
154          ;NUMBER OF 'MASSBUS CONTROL PARITY ERRORS' (MCPE) ALLOWED BEFORE
155          ;CALLING IT FATAL (MCPEMX=1 WORD)
156
157 030322 000003      MCPEMX: .WORD 3
158
159          ;STORAGE FOR RMADR (THE FIRST ADDRESS (776700) OF THE RH/RM),
160          ;RMVEC (THE VECTOR ADDRESS (254)), AND RMVEC+2 (THE BR LEVEL (5)).
161
162 030324 176700      RMADR: .WORD 176700
163 030326 000254 000240 RMVEC: .WORD 254,5*32.
164
165          ;MAXIMUM SEARCH FOR I/O WINDOW IS 5 SECTORS (MXWNDW-1 WORD)
166 030332 000005      MXWNDW: .WORD 5
167
168          ;DEFINITIONS OF THE RH/RM ADDRESS INDEXES
169
170
171
172
173          000000      RMCS1 = 0          ;CONTROL AND STATUS REGISTER #1 (DRIVE REG. 0)
174          000002      RMWC = 2          ;WORD COUNT REGISTER (NOT A DRIVE REG)
175          000004      RMBA = 4          ;UNIBUS ADDRESS REGISTER (NOT A DRIVE REG)
176          000006      RMDA = 6          ;DESIRED SECTOR/TRACK ADDRESS REGISTER (DRIVE REG. 5)
177          000010      RMCS2 = 10         ;CONTROL AND STATUS REGISTER #2 (NOT A DRIVE REG)
178          000012      RMDS = 12         ;DRIVE STATUS REGISTER (DRIVE REG 1)
179          000014      RMER1 = 14        ;ERROR REGISTER #1 (DRIVE REG. 2)
180          000016      RMAS = 16         ;ATTENTION SUMMARY PSEUDO REGISTER (DRIVE REG. 4)
181          000020      RMLA = 20         ;LOOK AHEAD REGISTER (DRIVE REG. 7)
182          000022      RMDB = 22         ;DATA BUFFER REGISTER (NOT A DRIVE REG.)
183          000024      RMR1 = 24         ;MAINTAINABILITY REGISTER (DRIVE REG. 3)
184          000026      RMDT = 26         ;DRIVE TYPE REGISTER (DRIVE REG. 6)
185          000030      RMSN = 30         ;SERIAL NUMBER REGISTER (DRIVE REG. 10)
186          000032      RMOF = 32         ;OFFSET REGISTER (DRIVE REG. 11)
187          000034      RMDC = 34         ;DESIRED CYLINDER ADDRESS REGISTER (DRIVE REG. 12)
188          000036      RMHR = 36         ;DUMMY ADDRESS REGISTER (DRIVE REG. 13)
189          000040      RMR2 = 40         ;MAINTENANCE REGISTER #2
190          000042      RMER2 = 42        ;ERROR REGISTER #2 (DRIVE REG. 15)
191          000044      RMEC1 = 44        ;ECC POSITION REGISTER (DRIVE REG. 16)
192          000046      RMEC2 = 46        ;ECC PATTERN REGISTER (DRIVE R-G. 17)
193
194
195
196
197
198          .SBTTL RH/RM DRIVER INITIALIZATION CODE
199
200          ;THIS ROUTINE WILL DETERMINE WHICH RM DRIVES ARE
201          ;AVAILABLE FOR TESTING AND SET THE DRVSTA INDICATOR
202          ;TO THE PROPER STATE FOR EACH DRIVE.
203          ;NOTE: THIS ROUTINE CALLS DRVINT
204          ;
205          ;CALL
206          ;
207          ;          JSR          PL,RMINIT
    
```

```

208
209
210
211
212 030334 104412
213 030336 013746 177776
214 030342 012737 000240 177776
215 030350 004737 036012
216 030354 012701 030166
217 030360 012702 030266
218 030364 005021
219 030366 020102
220 030370 103775
221 030372 012702 030310
222 030376 012721 177777
223 030402 020102
224 030404 101774
225 030406 005037 030206
226 030412 005037 030210
227 030416 005037 030212
228 030422 005037 030214
229 030426 013703 030326
230 030432 012723 032762
231 030436 013713 030330
232 030442 013704 030324
233 030446 012764 005000 000010
234 030454 005001
235 030456 004037 030546
236 030462 000401
237 030464 000402
238 030466 105061 030206
239 030472 005201
240 030474 042701 177770
241 030500 001366
242 030502 012701 000007
243 030506 005037 177776
244 030512 105761 030226
245 030516 001405
246 030520 004737 035446
247 030524 105761 030226
248 030530 001375
249 030532 005301
250 030534 100366
251 030536 012637 177776
252 030542 104413
253 030544 000207
254
255
256
257
258
259
260
261
262
263
264

```

```

RETURN
NOTE: THE 'P' OR 'L' CLOCK MUST BE STARTED
RMINIT: SAVREG
MOV PS, -(SP)
MOV #<5=32>, PS
JSR PC, CLRQUE
MOV #RMERRS, R1
MOV #SLEKFG, R2
1$: CLR (R1)+
CMP R1, R2
BLO 1$
MOV #DTLW, R2
2$: MOV #-1, (R1)+
CMP R1, R2
BLOS 2$
CLR DRVSTA
CLR DRVSTA+2
CLR DRVSTA+4
CLR DRVSTA+6
MOV RMVEC, R3
MOV #ISR, (R3)+
MOV RMVEC+2, (R3)
MOV RMADR, R4
MOV #CLR, RMCS2(R4)
3$: CLR R1
JSR R0, DRVINT
BR 4$
BR 5$
4$: CLRB DRVSTA(R1)
5$: INC R1
BIC #^C7, R1
BNE 3$
MOV #7, R1
CLR PS
6$: TSTB DPINT(R1)
BEQ 8$
JSR PC, SET.IE
7$: TSTB DPINT(R1)
BNE 7$
8$: DEC R1
BPL 6$
MOV (SP)+, PS
RESREG
RTS PC
:SAVE R0 - R5
:SAVE THE PRESENT PROCESSOR STATUS
:CHANGE THE PRIORITY TO 5
:CLEAR ALL REQUEST QUEUES
:FIRST ADDRESS TO BE CLEARED
:LAST ADDRESS TO BE CLEARED
:CLEAR
:ARE WE DONE?
:BR IF NO
:LAST ADDRESS
:INITIALIZE
:DONE?
:LOOP IF NO
:SET ALL DRIVES TO OFFLINE
:SETUP THE RH/RM VECTOR
:FIRST ADDRESS OF RH/RM
:MASSBUS INIT
:START WITH DRIVE 0
:INIT THE DRIVE
:'DVA' NOT SET OR PARITY ERROR
:NORMAL RETURN
:SET DRIVE STATUS TO OFFLINE
:GO TO NEXT DRIVE
:MASK OUT UNUSED BITS
:BR IF MORE DRIVES TO GO
:START WITH DRIVE 7
:CLEAR THE PROCESSOR STATUS
:WAITING FOR DRIVE TO SWITCH PORTS ?
:BR NOT WAITING
:SET INTERRUPT
:DRIVE SWITCHED PORTS ?
:BR IF NOT
:GO TO THE NEXT DRIVE
:CHECK NEXT DRIVE
:RESTORE THE PROCESSOR STATUS
:RESTORE R0 - R5
:BYE-BYE
:DRIVE INITIALIZATION ROUTINE
:THIS ROUTINE DETERMINES IF A DRIVE EXIST AND IF IT IS
:AN RM05/3/2. IF IT IS, A 'READ-IN PRESET' IS ISSUED AND FMT16
:IS SET TO A '1'. THEN MOL, DPR, DRY, AND VV ARE CHECKED TO
:INSURE THEY ARE ALL ON A '1'. AND DEPENDING ON THEIR STATE,
:DRVSTA IS SET TO THE PROPER CONDITION.
:CALL
MOV #DRVNUM, R1
MOV RMADR, R4
JSR R0, DRVINT
:DRIVE NUMBER TO R1
:UNIBUS ADDRESS OF RH/RM (RMCS1)
:CALLED BY A JSR

```

```

265          :          RETURN1          :ERROR OCCURRED (PARITY)
266          :          RETURN2          :NORMAL RETURN
267          :
268          :
269 030546 010546          DRVINT: MOV    R5,-(SP)          :SAVE R5
270 030550 05061 030206  CLR    DRVSTA(R1)      :START DRIVE STATUS AS OFFLINE
271 030554 105061 030216  CLR    DRVSTYP(R1)     :CLEAR 1 DRIVE TYPE INDICATOR
272 030560 105061 030254  CLR    ULDFLG(R1)     :CLEAR THE UNLOAD FLAG
273 030564 010164 000010  MOV    R1,RMCS2(R4)    :SELECT A DRIVE
274 030570 112764 000111 000000  MOV    #11,RMCS1(R4)   :DO A DRIVE CLEAR COMMAND (& SEIZE DRIVE)
275 030576 032764 010000 000010  BIT    #BIT12,RMCS2(R4) :NONEXISTENT DRIVE?
276 030604 001403          BEQ    1$              :NO
277 030606 004737 035446  JSR    PC,SET.IE       :GO SET 'IE' WITHOUT A 'TRE'
278 030612 000520          BR     4$              :LEAVE THIS ROUTINE
279
280 030614 105061 030206 1$:  CLR    DRVSTA(R1)     :SET DRIVE STATUS TO OFFLINE
281 030620 032764 004000 000000  BIT    #BIT11,RMCS1(R4) :SEE IF DRIVE AVAILABLE
282 030626 001512          BEQ    4$              :BR IF DRIVE NOT AVAILABLE
283 030630 004037 034756  JSR    R0,RD.RM        :READ THE DRIVE TYPE REG.
284 030634 000026          RMDT
285 030636 031056          S$
286 030640 012605          MOV    (SP)+,R5        :ERROR RETURN ADDRESS
287 030642 112761 000004 030216  MOV    #4,DRVSTYP(R1)  :PUT DRIVE TYPE IN R5
288 030650 022705 020024          MOV    #20024,R5       :SET RM03 INDICATOR
289 030654 001431          CMP    #20024,R5       :SINGLE PORT RM03 ?
290 030656 022705 024024          BEQ    2$              :BR IF YES
291 030662 001426          CMP    #24024,R5       :DUAL PORT RM03 ?
292 030664 112761 000005 030216  BEQ    2$              :BR IF YES
293 030672 022705 020025          MOV    #5,DRVSTYP(R1)  :SET RM02 INDICATOR
294 030676 001420          CMP    #20025,R5       :SINGLE PORT RM02 ?
295 030700 022705 024025          BEQ    2$              :BR IF SO
296 030704 001415          CMP    #24025,R5       :DUAL PORT RM02 ?
297 030706 112761 000007 030216  BEQ    2$              :BR IF SO
298 030714 022705 020027          MOV    #7,DRVSTYP(R1)  :SET RM05 INDICATOR
299 030720 001407          CMP    #20027,R5       :SINGLE PORT RM05 ?
300 030722 022705 024027          BEQ    2$              :BR IF YES
301 030726 001404          CMP    #24027,R5       :DUAL PORT RM05 ?
302 030730 112761 177777 030216  BEQ    2$              :BR IF YES
303 030736 000446          MOV    #-1,DRVSTYP(R1) :SET INDICATOR TO 'OTHER'
304          BR     4$              :EXIT
305 030740 012746 000121 2$:  MOV    #121,-(SP)      :DO A 'READ-IN PRESET'
306 030744 004037 035136  JSR    R0,WRT.RM
307 030750 000000          RMCS1
308 030752 031056          S$
309 030754 012746 010000          MOV    #BIT12,-(SP)    :SET FMT16=1
310 030760 004037 035136  JSR    R0,WRT.RM
311 030764 000032          RMOF
312 030766 031056          S$
313 030770 004037 034756  JSR    R0,RD.RM        :READ RMDS
314 030774 000012          RMDS
315 030776 031056          S$
316 031000 012605          MOV    (SP)+,R5        :AND SAVE IT IN R5
317 031002 100015          BPL    3$              :BR IF ATA=0
318 031004 116164 030312 000016  MOV    ATABIT(R1),RMAS(R4) :CLEAR ATTENTION BIT
319 031012 004037 034756  JSR    R0,RD.RM        :FIND OUT WHY ATA=1
320 031016 000014          RMER1
321 031020 031056          S$
  
```



```

322 031022 006126          ROL      (SP)+          ;IS IT UNSAFE?
323 031024 100004          BPL      3$              ;BR IF NOT
324 031026 112761 177777 030206  MOVB    #-1,DRVSTA(R1) ;SET UNSAFE INDICATOR
325 031034 000407          BR       4$              ;EXIT
326
327 031036 005105          3$:     COM      R5              ;CHECK MOL, DPR, DRY, AND VV
328 031040 042705 167077          BIC      #*(C<BIT12:BIT08:BIT07:BIT06>,R5
329 031044 001003          BNE      4$              ;BR IF MOL, DPR, DRY, OR VV IS CLEAR
330 031046 112761 000001 030206  MOVB    #1,DRVSTA(R1) ;SET DRIVE STATUS TO ONLINE
331 031054 005720          4$:     TST      (R0)+          ;STEP OVER THE ERROR RETURN
332 031056 012605          5$:     MOV      (SP)+,R5      ;RESTORE R5
333 031060 000200          RTS      R0              ;EXIT
334
335                          ;REQUEST PRE-PROCESSOR-HANDLES SUBSYSTEM REQUEST
336
337                          ;CALL
338
339                          ;
340                          JSR      R0,RM05          ;CALL THE RM05 DRIVER
341                          PNTADR          ;ADDRESS OF POINTER OF DRIVES PARAMETER BLOCK
342                          RETURN1         ;RETURN HERE IF QUEUE IS FULL
343                          RETURN2         ;RETURN HERE IF REQUEST IS IN QUEUE OR THERE
344                          ;IS AN ERROR CONDITION
345 031062 013746 177776          RM05:   MOV      PS,-(SP)          ;SAVE THE CALLING STATUS
346 031066 013737 030330 177776   MOV      RMVEC+2,PS      ;DON'T ALLOW ANY RM INTERRUPTS
347 031074 112737 000001 030252   MOVB    #1,ACTDRV        ;SET 'ACTIVE DRIVER' FLAG
348 031102 104412          SAVREG          ;SAVE R0 - R5
349 031104 011002          MOV      (R0),R2        ;PICKUP THE DRIVE PARAMETER BLOCK POINTER
350 031106 005062 000016          CLR      16(R2)         ;CLEAR THE STATUS/ERROR INDICATOR
351 031112 111201          MOVB    (R2),R1         ;PICKUP THE DRIVE NUMBER
352 031114 013704 030324          MOV      RMADR,R4        ;UNIBUS ADDRESS OF RMCS1
353 031120 105761 030206          TSTB    DRVSTA(R1)      ;CHECK DRIVES STATUS
354 031124 003014          BGT      1$              ;BR IF ONLINE
355 031126 105761 030254          TSTB    ULDFLG(R1)      ;UNLOAD COMMAND IN QUEUE?
356 031132 001036          BNE      3$              ;BR IF YES
357 031134 105761 030226          TSTB    DPINT(R1)       ;TRYING TO INIT THE DRIVE
358 031140 001042          BNE      5$              ;BR IF YES
359 031142 004037 030546          JSR      R0,DRVINT       ;GO INIT. THE DRIVE
360 031146 000434          BR       4$              ;ERROR RETURN
361 031150 105761 030206          TSTB    DRVSTA(R1)      ;IS DRIVE STATUS ONLINE?
362 031154 003445          BLE      6$              ;BR IF NOT
363 031156 105761 030236          1$:     TSTB    DPRQS(R1)      ;OUTSTANDING PORT REQUEST FOR THE DRIVE ?
364 031162 001031          BNE      5$              ;BR IF YES
365 031164 010164 000010          MOV      R1,RMCS2(R4)    ;SELECT THE DRIVE
366 031170 004037 036110          JSR      R0,DRVQUE       ;PUT THIS REQUEST IN QUEUE
367 031174 000460          BR       9$              ;QUEUE IS FULL
368 031176 122762 000103 000002   CMPB    #103,2(R2)       ;IS THIS REQ. FOR AN UNLOAD?
369 031204 001003          BNE      2$              ;BR IF NO
370 031206 112761 177777 030254   MOVB    #-1,ULDFLG(R1) ;SET THE 'UNLOAD IN QUEUE' FLAG
371 031214 105761 030176          2$:     TSTB    DRVACT(R1)      ;IS THIS DRIVE ACTIVE?
372 031220 001043          BNE      8$              ;BR IF YES
373 031222 004737 031354          JSR      PC,OPT          ;CALL THE OPTIMIZER
374 031226 000440          BR       8$
375 031230 012762 120000 000016   3$:     MOV      #BIT15:BIT13,16(R2) ;SET THE 'UNLOAD IN QUEUE' ERROR FLAG
376 031236 000434          BR       8$              ;EXIT
377 031240 004737 032432          4$:     JSR      PC,C17        ;GO HANDLE THE PARITY ERROR
378 031244 000431          BR       8$
  
```

```

379 031246 004037 036110 98: JSR R0,DRVQUE ;PUT REQUEST IN QUEUE
380 031252 000431 BR 98 ;QUEUE IS FULL
381 031254 032714 000100 BIT #BIT06,(R4) ;IE BIT SET?
382 031260 001023 BNE 88 ;YES
383 031262 004737 035446 JSR PC,SET.IE ;SET THE INTERRUPT
384 031266 000420 BR 88 ;RETURN
385 031270 105761 030206 68: TSTB DRVSTA(R1) ;SEE IF DRIVE OFFLINE OR UNSAFE
386 031274 002412 BLT 78 ;BR IF UNSAFE
387 031276 012762 140000 000016 MOV #BIT15:BIT14,16(R2) ;SET OFFLINE ERROR INDICATOR
388 031304 105761 030216 *STB DRVTP(R1) ;SEE IF OFFLINE OR NONEXISTENT
389 031310 001007 BNE 88 ;BR IF OFFLINE
390 031312 012762 100002 000016 MOV #BIT15:BIT01,16(R2) ;REPORT DRIVE NONEXISTENT
391 031320 000403 BR 88 ;GO TO EXIT
392 031322 012762 110000 000016 78: MOV #BIT15:BIT12,16(R2) ;DRIVE IS UNSAFE
393 031330 104413 88: RESREG ;RESTORE R0 - R5
394 031332 005720 TST (R0)* ;SETUP FOR NORMAL RETURN
395 031334 000401 BR 108 ;FINISH UP, THEN EXIT
396 031336 104413 98: RESREG ;RESTORE R0 - R5
397 031340 005720 108: *ST (R0)* ;CORRECT THE RETURN ADDRESS
398 031342 105037 030252 CLRB ACTDRV ;CLEAR 'ACTIVE DRIVER' FLAG
399 031346 012637 177776 MOV (SP)*,PS ;RETURN 'PS' TO USER LEVEL
400 031352 000200 RTS R0 ;RETURN TO CALLER
401
402 ;OPTIMIZER-CALLED FOR A PARTICULAR DRIVE
403
404 ;CALL
405
406 ; MOV #DRVNUM,R1 ;DRIVE NUMBER TO R1
407 ; JSR PC,OPT ;SETUP A COMMAND
408 031354 104412 OPT: SAVREG ;SAVE R0 - R5
409 031356 013746 177776 MOV PS,-(SP) ;SAVE PROC. STATUS
410 031362 146137 030312 030250 BICB ATABIT(R1),SRCHWT ;CLEAR LA SEACH FLAG
411 031370 105061 030236 CLRB DPRQS(R1) ;RESET THE PORT REQ FLAG ****
412 031374 004737 036164 JSR PC,GETREQ ;GET 'DPB' POINTER OF REQUEST
413 031400 005702 TST R2 ;IS THERE A REQUEST IN QUEUE?
414 031402 001466 BEQ 78 ;NO--BR TO EXIT
415 031404 010164 000010 MOV R1,RMCS2(R4) ;LOAD THE DRIVE ADDRESS *****
416 031410 012764 000111 000000 MOV #111,RMCS1(R4) ;CLEAR THE DRIVE
417 031416 032764 004000 000000 BIT #BIT11,RMCS1(R4) ;DVA SET?
418 031424 001442 BEQ 58 ;TO PORT REQUEST, IF NOT
419 031426 105761 030206 78: TSTB DRVSTA(R1) ;IS DRIVE ONLINE?
420 031432 003014 BGT 28 ;YES
421 031434 004737 036206 JSR PC,POPOUE ;NO--REMOVE REQUEST FROM QUEUE
422 031440 012762 140000 000016 MOV #BIT15:BIT14,16(R2) ;SET OFFLINE STATUS/ERROR INDICATOR
423 031446 105761 030206 *STB DRVSTA(R1) ;IS DRIVE UNSAFE?
424 031452 100047 BPL 88 ;BR TO EXIT IF NOT
425 031454 012762 110000 000016 MOV #BIT15:BIT12,16(R2) ;SET UNSAFE STATUS/ERROR INDICATOR
426 031462 000443 BR 88 ;BR TO EXIT
427 031464 28:
436 031464 122762 000150 000002 CMPB #150,2(R2) ;IS THE REQUEST FOR I/O?
437 031472 002403 BLT 38 ;YES
438 031474 004737 032016 JSR PC,C14 ;CALL THE COMMAND INITIATOR
439 031500 000434 BR 88 ;BR TO EXIT
440 031502 005737 030310 38: TST DTUW ;DATA TRANSFER UNDERWAY?
441 031506 002006 BGE 48 ;YES--GO START A SEARCH
442 031510 005737 030266 *ST SEEKFG ;DO IMPLIED SEEKS?
443 031514 100003 BPL 48 ;NO, DO A SEARCH

```

```

444 031516 004737 031602      JSR    PC,C11      ;START A DATA TRANSFER
445 031522 000423              BR     8$          ;
446 031524 004737 031710      4$:   JSR    PC,C13      ;START A SEARCH
447 031530 000420              BR     8$          ;GO TO THE EXIT
448 031532 112761 177777 030236 5$:   MOV/B  #-1,DPRQS(R1) ;SET PORT REQUEST INDICATOR
449 031540 010103              MOV    R1,R3      ;SET UP TO ADDRESS WORDS
450 031542 006303              ASL   R3          ;CONVERT TO WORD INDEX
451 031544 012763 035230 030270      MOV    #15000.,TIMER(R3) ;START 15. SECOND TIMER
452 031552 000402              BR     7$          ;EXIT
453 031554 004737 032432      6$:   JSR    PC,C17      ;PROCESS THE PARITY ERROR
454 031560 032714 000100      7$:   BIT    #B106,(R4) ;SEE IF 'IE' ALREADY SET
455 031564 001002              BNE   8$          ;BR IF SET
456 031566 004737 035446      JSR    PC,SET,IE  ;SET 'IE' WITHOUT A 'TRE'
457 031572 012637 177776      8$:   MOV    (SP)+,PS  ;RESTORE PROC. STATUS
458 031576 104413              RESREG ;RESTORE RC - R5
459 031600 000207              RTS    PC
460
461      ;COMMAND INITIATOR
462
463      ;CALL
464      ;
465      ;MOV    #DRYNUM,R1      ;DRIVE NUMBER
466      ;MOV    #DPB,R2        ;ADDRESS OF DPB
467      ;JSR    PC,C1?        ;C1?= C11,C13, OR C14
468      ;WHERE:
469      ;C11=DATA TRANSFER
470      ;C13=SEARCH REQUESTED BY DATA XFER
471      ;C14=NOT DATA TRANSFER
472 031602 004737 036206      11$:  JSR    PC,PCPQUE  ;REMOVE REQUEST FROM 'DRIVES WAIT' QUEUE
473 031606 010237 030246      MOV    R2,TRNSWT ;PUT REQ. IN TRANSFER WAIT QUEUE
474 031612 010203              MOV    R2,R3      ;DPB ADDRESS TO R3
475 031614 013704 030324      MOV    RMADR,R4   ;RMCS1 ADDRESS
476 031620 010164 000010      MOV    R1,RMCS2(R4) ;SELECT DRIVE
477 031624 062703 000004      ADD   #4,R3       ;DESIRED WORD COUNT
478 031630 062704 000002      ADD   #2,R4       ;RMWC ADDRESS
479 031634 012324              MOV    (R3)+,(R4)+ ;LOAD WORD COUNT
480 031636 012324              MOV    (R3)+,(R4)+ ;LOAD BUFFER ADDRESS
481 031640 012346              MOV    (R3)+,-(SP) ;LOAD SECTOR AND TRACK
482 031642 004037 035136      JSR    R0,WRT,RM  ;CALL THE LOAD(WRITE) ROUTINE
483 031646 000006              RMDA  C17        ;INDEX OF REGISTER TO LOAD
484 031650 032432              C17   ;ERROR RETURN ADDRESS
485 031652 012346              MOV    (R3)+,-(SP) ;LOAD CYLINDER ADDRESS
486 031654 004037 035136      JSR    R0,WRT,RM
487 031660 000034              RMDC  C17
488 031662 032432              C17
489 031664 016246 000002      MOV    2(R2),-(SP) ;LOAD 'COMMAND+GO', 'A17&A16', AND 'PSEL'
490 031670 004037 035136      JSR    R0,WRT,RM
491 031674 000000              RMCS1
492 031676 032432              C17
493 031700 010137 030310      MOV    R1,DTUW   ;SET 'DATA TRANSFER UNDERWAY'
494 031704 000137 032374      JMP   C15
495
496 031710 013704 030324      13$:  MOV    RMADR,R4   ;RMCS1 ADDRESS
497 031714 010164 000010      MOV    R1,RMCS2(R4) ;SELECT DRIVE
498 031720 016246 000012      MOV    12(R2),-(SP) ;DESIRED CYLINDER ADDRESS
499 031724 004037 035136      JSR    R0,WRT,RM
500 031730 000034              RMDC

```

RM05 DRIVER INITIALIZATION CODE

```

501 031732 032432 C17
502 031734 116203 000010 MOV# 10(R2),R3 ;PICKUP SECTOR ADDRESS
503 031740 163703 030332 SUB MXWINDW,R3 ;BACKUP BY MAX. SEARCH FOR I/O WINDOW
504 031744 002002 BGE 1$
505 031746 062703 000040 ADD #32,R3
506 031752 010346 1$: MOV R3,-(SP) ;COMBINE THE ADJUSTED SECTOR WITH
507 031754 116266 000011 0000C1 MOV# 11(R2),1(SP) ;THE DESIRED TRACK
508 031762 004037 035136 JSR R0,WRT.RM ;LOAD DESIRED TRACK & SECTOR
509 031766 000006 RMDA
510 031770 032432 C17
511 031772 012746 000131 MOV #131,-(SP) ;START A SEARCH
512 031776 004037 035136 JSR R0,WRT.RM
513 032002 000000 RMCS1
514 032004 032432 C17
515 032006 156137 030312 030250 BISB ATABIT(R1),SRCHWT ;SET 'SEARCH WAIT' KEY
516 032014 000567 BR C15
517
518 032016 013704 030324 C14: MOV RMADR,R4 ;RMCS1 ADDRESS
519 032022 010164 000010 MOV R1,RMCS2(R4) ;SELECT DRIVE
520 032026 116203 000002 MOV# 2(R2),R3 ;PICKUP THE REQUESTED COMMAND
521 032032 122703 000131 CMPB #131,R3 ;IS IT A SEARCH COMMAND?
522 032036 001007 BNE 1$ ;BR IF NO
523 032040 016246 000010 MOV 10(R2),-(SP) ;LOAD DESIRED TRACK & SECTOR
524 032044 004037 035136 JSR R0,WRT.RM
525 032050 000006 RMDA
526 032052 032432 C17
527 032054 000403 BR 2$
528 032056 122703 000105 1$: CMPB #105,R3 ;GO LOAD CYLINDER
529 032062 001007 BNE 3$ ;IS IT A SEEK COMMAND
530 032064 016246 000012 2$: MOV 12(R2),-(SP) ;BR IF NO
531 032070 004037 035136 JSR R0,WRT.RM ;LOAD DESIRED CYLINDER
532 032074 000034 RMD(
533 032076 032432 C17
534 032100 000546 BR C16
535 032102 122703 000115 3$: CMPB #115,R3 ;IS IT AN 'OFFSET' COMMAND?
536 032106 001013 BNE 4$ ;BR IF NO
537 032110 004037 034756 JSR R0,RD.RM ;MERGE THE OFFSET VALUE INTO RMOF
538 032114 000032 RMOF ;BUT DON'T CHANGE THE UPPER
539 032116 032432 C17
540 032120 116216 000001 MOV# 1(R2),(SP) ;BYTE WHEN LOADING THE
541 032124 004037 035136 JSR R0,WRT.RM ;REGISTER (RMOF)
542 032130 000032 RMOF
543 032132 032432 C17
544 032134 000530 BR C16
545 032136 122703 000107 4$: CMPB #107,R3 ;GO START THE COMMAND
546 032142 001525 BEQ C16 ;IS IT A 'RECALIBRATE' COMMAND?
547 032144 122703 000117 CMPB #117,R3 ;BR IF YES
548 032150 001522 BEQ C16 ;IS IT A RETURN TO CENTER?
549 032152 122703 000103 CMPB #103,R3 ;BR IF YES
550 032156 001016 BNE 5$ ;IS IT AN 'UNLOAD' COMMAND?
551 032160 112761 000001 030176 MOV# #1,DRVACT(R1) ;BR IF NO
552 032166 105061 030206 CLR# DRVSTA(R1) ;SET THE DRIVE ACTIVE INDICATOR
553 032172 112761 000001 030254 MOV# #1,ULDFLG(R1) ;PUT DRIVE STATUS TO OFFLINE
554 032200 010346 MOV R3,-(SP) ;SET 'UNLOAD IN PROGRESS' FLAG
555 032202 004037 035136 JSR R0,WRT.RM ;START THE 'UNLOAD' COMMAND
556 032206 000000 RMCS1
557 032210 032432 C17

```

```

558 032212 000207          RTS      PC          ;RETURN TO USER
559 032214 122703 000143 68:      (MPB      #143,R3      ;IS IT A 'SET FORMAT' COMMAND?
560 032220 001014          BNE      68          ;BR IF NO
561 032222 004037 034756      JSR      R0,RD,RM    ;READ THE OFFSET REGISTER
562 032226 000032          RMOF     C17
563 032230 032432          C17
564 032232 116266 000001 000001  MOVB     1(R2),1(SP) ;COMBINE 'FMT16','ECI', AND 'HCI'
565 032240 004037 035136      JSR      R0,WRT,RM   ;LOAD 'FMT16','ECI', AND/OR 'HCI'
566 032244 000032          RMOF     C17
567 032246 032432          C17
568 032250 000436          BR       128
569 032252 122703 000141 68:      (MPB      #141,R3      ;IS IT A 'GET REGISTER' COMMAND?
570 032256 001023          BNE      108        ;BR IF NO
571 032260 016203 000006 78:      MOV      6(R2),R3    ;POINTS TO 1ST ADDRESS OF WHERE
572                                ;TO PUT THE REGISTER(S)
573 032264 116237 000010 032302  MOVB     10(R2),98   ;INIT. THE INDEX FOR THE FIRST REG.
574 032272 116205 000011  MOVB     11(R2),R5   ;INDEX OF LAST REG. TO MOVE
575 032276 004037 034756 88:      JSR      R0,RD,RM    ;READ RH/RM REGISTER
576 032302 000000 68:      RMCS1    ;INDEX OF REG. TO READ
577 032304 032432          C17
578 032306 012623          MOV      (SP),*(R3) ;GET THE CONTENTS OF RH/RM REG.
579 032310 023705 032302      CMP      98,R5      ;LAST REG. BEEN READ?
580 032314 001414          BEQ      128        ;GET OUT IF YES
581 032316 062737 000002 032302  ADD      #2,98       ;INCREASE THE INDEX BY 2
582 032324 000764          BR       88         ;LOOP--MORE TO READ
583 032326 122703 000145 108:     (MPB      #145,R3      ;IS IT A 'SELECT DRIVE' COMMAND?
584 032332 001405          BEQ      128        ;BR IF YES
585 032334 010346 118:      MOV      R3,-(SP)   ;LOAD THE COMMAND
586 032336 004037 035136      JSR      R0,WRT,RM
587 032342 000000          RMCS1
588 032344 032432          C17
589 032346 004737 036206 128:     JSR      PC,POPQUE   ;REMOVE REQ. FROM QUEUE
590 032352 052762 000200 000016  BIS      #BIT7,16(R2) ;SET THE 'DONE' BIT
591 032360 005737 030264          TST     SAVEFG      ;SAVE THE RH/RM REGISTERS?
592 032364 100002          BPL     138        ;BR IF NO
593 032366 004737 035330 138:     JSR      PC,SVRW70   ;YES--GO SAVE THE REGISTERS
594 032372 000207          RTS      PC          ;RETURN TO USER
595
596 032374 006301 015:     ASL     R1
597 032376 012761 023420 030270  MOV      #10000.,TIMER(R1) ;START 10. SECOND TIMER
598 032404 006201          ASR     R1
599 032406 112761 000001 030176  MOVB     #1,DRVACT(R1) ;SET THE DRIVE ACTIVE
600 032414 000207          RTS      PC          ;RETURN TO THE USER
601
602 032416 010346 016:     MOV      R3,-(SP)   ;LOAD THE COMMAND
603 032420 004037 035136      JSR      R0,WRT,RM
604 032424 000000          RMCS1
605 032426 032432          C17
606 032430 000761          BR       C15
607
608 032432 032764 010000 000010  C17:     BIT      #BIT12,RMCS2(R4) ;DRIVE NON-EXISTENT ?
612 032440 005702 18:      TST     R2          ;ANYTHING IN QUEUE ?
616 032442 001001          BNE     28          ;BR IF QUEUE IS THERE
617 032444 000207          RTS     PC          ;OTHERWISE EXIT
618 032446 012762 104000 000016 28:      MOV      #BIT15.BIT11,16(R2) ;SET 'PARITY' ERROR INDICATOR
622
623 032454 012746 000111  C17B:    MOV      #111,-(SP) ;DO A 'DRIVE CLEAR'

```

```

624 032460 004037 035136      JSR      RC,WRT,RM
625 032464 000000      RMCS1
626 032466 032532      CIB
627 032470 004737 036070      1$: JSR      PC,EMPTYQ      ;EMPTY THE QUEUE
628 032474 105061 030236      CLR      DPRQS(R1)      ;CLEAR THE PORT REQUEST FLAG
629 032500 105061 030254      CLR      ULDFLG(R1)     ;CLEAR THE UNLOAD IN QUEUE FLAG
630 032504 105061 030176      CLR      DRVACT(R1)     ;DRIVE IS IDLE
631 032510 020237 030246      CMP      R2,TRNSWT      ;IF THIS DRIVE HAD AN I/O REQUEST
635 032514 001005      BNE      2$              ;IN PROGRESS CLEAR ALL OF THE FLAGS
636 032516 005037 030246      CLR      TRNSWT
637 032522 012737 177777 030310      MOV      #-1,DTUW
638 032530 000207      RTS      PC              2$:
639
640 032532 104412      CIB: SAVREG              ;SAVE R0 - R5
641 032534 005001      CLR      R1
642 032536 005003      CLR      R3
643 032540 105761 030176      1$: TST      DRVACT(R1)   ;DRIVE ACTIVE?
644 032544 001003      BNE      2$              ;BR IF IN ACTIVE
645 032546 105761 030236      TST      DPRQS(R1)     ;PORT REQUEST
646 032552 001443      BEQ      6$              ;BR IF NOT
647 032554 013702 030246      2$: MOV      TRNSWT,R2     ;GET THE 'TRANSFER WAIT' QUEUE
648 032560 020137 030310      CMP      R1,DTUW        ;DID THIS DRIVE HAVE AN I/O IN PROGRESS?
649 032564 001402      BEQ      3$              ;BR IF YES
650 032566 004737 036164      JSR      PC,GETREQ      ;GET THE DPB POINTER
651 032572 005702      3$: TST      R2          ;QUEUE ENTRY FOR DRIVE ?
652 032574 001413      BEQ      5$              ;BR IF NOT
653 032576 032764 010000 000010      BIT      #BIT12,RMCS2(R4) ;'NED' SET ?
654 032604 001404      BEQ      4$              ;BR IF NOT
655 032606 012762 100002 000016      MOV      #BIT15:BIT01,16(R2) ;SET 'DRIVE NON-EXISTENT' INDICATOR
656 032614 000403      BR      5$              ;CONTINUE
657 032616 012762 102000 000016 4$: MOV      #BIT15:BIT10,16(R2) ;SET 'NON-CLEARABLE PARITY' ERROR INDICATOR
661 032624 012763 177777 030270 5$: MOV      #-1,TIMER(R3)   ;STOP THE TIMER
662 032632 105061 030176      CLR      DRVACT(R1)     ;SET 'DRIVE ACTIVE' TO IDLE
663 032636 105061 030236      CLR      DPRQS(R1)     ;CLEAR PORT REQUEST FLAG
664 032642 020137 030310      CMP      R1,DTUW        ;IS THIS DRIVE SETUP FOR A TRANSFER
665 032646 001005      BNE      6$              ;BR IF NOT
666 032650 012737 177777 030310      MOV      #-1,DTUW        ;RESET THE INDICATOR
667 032656 005037 030246      CLR      TRNSWT         ;CLEAR THE TRANSFER QUEUE
668 032662 105061 030254      6$: CLR      ULDFLG(R1)   ;CLEAR UNLOAD FLAG
669 032666 032764 010000 000010      BIT      #BIT12,RMCS2(R4) ;'NED' SET ?
673 032674 005201      INC      R1              ;MOVE TO THE NEXT DRIVE
674 032676 062703 000002      ADD      #2,R3
675 032702 042701 177770      BIC      #^7,R1
676 032706 001314      BNE      1$              ;BR IF MORE DRIVES
677 032710 012737 177777 030310      MOV      #-1,DTUW        ;NO DATA TRANSFERS UNDERWAY
678 032716 005037 030246      CLR      TRNSWT         ;CLEAR THE 'TRANSFER WAIT' QUEUE
679 032722 004737 036012      JSR      PC,CLRQUE      ;CLEAR ALL OF THE REQUEST QUEUES
680 032726 012764 005000 000010      MOV      #CLR,RMCS2(R4) ;DO A MASSBUS INIT.
681 032734 000406      BR      8$              ;CONTINUE
682 032736 004737 036070      7$: JSR      PC,EMPTYQ   ;CLEAR THE DRIVE'S QUEUE
683 032742 105061 030206      CLR      DRVSTA(R1)     ;SET DRIVE TO OFFLINE
684 032746 105061 030216      CLR      DRVTYP(R1)    ;CLEAR THE DRIVE TYPE INDICATOR
685 032752 004737 035446      8$: JSR      PC,SET.IE   ;SET 'IE' WITHOUT 'TRE'
686 032756 104413      RESREG
687 032760 000207      RTS      PC              ;RESTORE R0 - R5
688
689
; INTERRUPT SERVICE ROUTINE

```

```

690
691 032762 112737 00000 030252 1SR:  MOV# ,ACTDRV      ;SET 'ACTIVE DRIVER' FLAG
692 032770 104412                SAVREG        ;SAVE R0 - R5
693 032772 013704 030324        MOV  RMADR,R4  ;ADDRESS OF RMCS1
694 032776 013701 030310        MOV  DTUW,R1   ;GET 'DATA TRANSFER UNDERWAY' INDICATOR
695 033002 002402                BLT  1$        ;BR IF NO DATA TRANSFER UNDERWAY
696 033004 004737 033024        JSR  PC,TD     ;CALL TRANSFER DONE
697 033010 004737 033174        1$: JSR  PC,SC   ;CALL SPECIAL CONDITIONS
698 033014 104413                2$: RESREG     ;RESTORE R0 - R5
699 033016 105037 030252        CLRB AC'DRV   ;CLEAR 'ACTIVE DRIVER' FLAG
700 033022 000002                RTI                    ;RETURN
701
702                ;TRANSFER DONE ROUTINE
703
704 033024 105061 030176        TD:  CLRB  DRVACT(R1) ;SET DRIVE ACTIVE INDICATOR TO IDLE
705 033030 012737 177777 030310  MOV  #-1,DTUW   ;NO DATA TRANSFERS UNDERWAY
706 033036 006301                ASL  R1
707 033040 012761 177777 030270  MOV  #-1,TIMER(R1) ;CANCEL TIMEOUT
708 033046 006201                ASR  R1
709 033050 013702 030246        MOV  TRNSWT,R2 ;GET 'DPB' ADDRESS FROM THE
710 033054 005037 030246        CLR  TRNSWT    ;TRANSFER WAIT QUEUE--CLEAR QUEUE
711 033060 052762 000200 000016  BIS  #BIT07,16(R2) ;SET DONE
712 033066 010164 000010        MOV  R1,RMCS2(R4) ;SELECT THE DRIVE
713 033072 004037 034756        JSR  R0,RD.RM  ;TRANSFER ERROR(TRE=1)?
714 033076 000000                RMCS1
715 033100 032432                C17
716 033102 006126                ROL  (SP)+     ;IS TRE=1 ?
717 033104 100417                BMI  3$        ;BR IF YES
718 033106 005737 030264        TST  SAVEFG    ;SAVE THE RH/RM REGISTERS?
719 033112 100002                BPL  1$        ;BR IF NO
720 033114 004737 035330        JSR  PC,SVRH70 ;YES--SAVE THE REGISTERS
721 033120 004737 036164        1$: JSR  PC,GETREQ ;GET DPB POINT=R
722 033124 005702                TST  R2        ;ENTRY FOR DRIVE ?
723 033126 001403                BEQ  2$        ;BR IF NOT
724 033130 004737 031354        JSR  PC,OPT    ;CALL OPTIMIZER
725 033134 000207                RTS  PC        ;RETURN
726 033136 012714 000113        2$: MOV  #113,(R4) ;RELEASE THE DRIVE
727 033142 000207                RTS  PC        ;RETURN
728
729 033144 052762 100100 000016  3$: BIS  #BIT15:BIT06,16(R2) ;SET DATA ERROR FLAG
730 033152 004737 036070        JSR  PC,EMPTYQ ;EMPTY THE 'DRIVE'S WAIT' QUEUE
731 033156 004737 035330        JSR  PC,SVRH70 ;SAVE THE PH/RM REGISTERS
732 033162 012714 040111        MOV  #40111,(R4) ;ISSUE A 'DRIVE CLEAR'
733 033166 012714 000113        MOV  #113,(R4)  ;ISSUE A RELEASE TO THE DRIVE
734 033172 000207                RTS  PC        ;RETURN
735
736                ;SPECIAL CONDITION ROUTINE
737
738 033174 116403 000016        SC:  MOV#  RMAS(R4),R3 ;READ 'RMAS'
739 033200 001014                BNE  2$        ;BR IF ANY 'ATA' BITS SET
740 033202 004037 034756        JSR  R0,RD.RM  ;READ CONTROL AND STATUS REGISTER
741 033206 000000                RMCS1
742 033210 032532                C18
743 033212 106126                ROLB (SP)+     ;IS 'IE'=1?
744 033214 100405                BMI  1$        ;YES, NO DRIVES TO CHECK
745 033216 004037 036254        JSR  R0,ES.SAV ;SAVE THE ADDRESS IN '$ESCAPE'
746 033222 104001                EMT  1        ;REPORT AN ILLEGAL INTERRUPT

```

RH/RM DRIVER INITIALIZATION CODE

```

773 033224 004737 035446      JSR      PC,SET.IE      ;SET INTERRUPT ENABLE
774 033230 000207      1$:     RTS      PC      ;RETURN
775 033232 005046      2$:     CLR      -(SP)   ;PROCESS ALL DRIVES THAT HAVE
776 033234 110316      MOV      R3,(SP)      ;AN 'ATA'=1
777 033236 012703 000001      MOV      #1,R3
778 033242 005001      CLR      R1
779
780 033244 030316      SC3:    BIT      R3,(SP)  ;ATA=1?
781 033246 001005      BNE     SC5           ;YES
782
783 033250 005201      SC4:    INC      R1      ;MOVE TO THE NEXT DRIVE
784 033252 106303      ASLB    R3
785 033254 001373      BNE     SC3          ;BR IF MORE TO CHECK?
786 033256 005726      TST     (SP)+       ;CLEAN OFF THE STACK
787 033260 000207      RTS     PC          ;RETURN TO USER
788
789 033262 105761 030226      SC5:    TSTB    DPINT(R1) ;INITIALIZING THE DRIVE ?
790 033266 001402      BEQ     1$          ;BR IF NOT
791 033270 000137 034206      JMP     SC13        ;PROCESS THE DRIVE
792 033274 105761 030236      1$:     TSTB    DPRQS(R1) ;PORT REQUEST OUTSTANDING ?
793 033300 001402      BEQ     2$          ;BR IF NOT
794 033302 000137 034206      JMP     SC13        ;START THE OUTSTANDING COMMAND
795 033306 105761 030206      2$:     TSTB    DRVSTA(R1) ;CHECK THE DRIVE STATUS
796 033312 003023      BGT     4$          ;BR IF ONLINE
797 033314 105761 030254      TSTB    ULDFLG(R1)   ;UNLOAD IN PROGRESS?
798 033320 003420      BLE     4$          ;BR IF NOT
799 033322 004737 036164      JSR     PC,GETREQ    ;GET DPB POINTER
800 033326 004737 035330      JSR     PC,SVRH70    ;SAVE THE RH/RM REGISTERS
801 033332 004737 034136      JSR     PC,SC12     ;SAVE RMD5, RMER1, RMER2, AND RMMR2
802
803 033336 105761 030206      TSTB    DRVSTA(R1)   ;ALSO DO A DRIVE INIT (DRVINT)
804 033342 003414      BLE     5$          ;DID DRIVE COME ONLINE?
805 033344 032737 040000 030166      BIT     #BIT14,RMERRS ;NO
806 033352 001000      BNE     3$          ;WAS THERE AN ERROR?
807
808 033354 013705 030170      3$:     MOV      RMERRS+2,R5 ;BR IF ERROR
809 033360 000504      BR      SC6A        ;YES -- PICKUP RMER1 AND
810 033362 105761 030176      4$:     TSTB    DRVACT(R1) ;GO PROCESS THE ERROR
811 033366 001033      BNE     SC6         ;DRIVE ACTIVE WITH COMMAND OR ERROR RECOVERY ?
812 033370 004737 034136      JSR     PC,SC12     ;BR IF EITHER
813
814 033374 105761 030226      5$:     TSTB    DPINT(R1)   ;SAVE RMD5, RMER1, RMER2, AND RMMR2
815 033400 001323      BNE     SC4         ;ALSO DO A DRVINT
816 033402 105761 030206      TSTB    DRVSTA(R1)   ;TRYING TO INIT THE DRIVE ?
817 033406 100412      BMI     6$          ;BR IF YES, CHECK ON MORE DRIVES
818 033410 032737 020000 030172      BIT     #BIT13,RMERRS+4 ;CHECK ON DRIVE'S STATUS
819 033416 001013      BNE     7$          ;BR IF UNSAFE
820 033420 012746 000111      MOV     #111,-(SP)  ;ADDRESS PLUG CHANGED ?
821 033424 004037 035136      JSR     R0,WRT.RM   ;BR IF YES
822 033430 000000      RMCST  SC8         ;DRIVE CLEAR
823 033432 033776      SC8     ;WRITE THE COMMAND INTO RMCS1
824 033434 011605      6$:     MOV     (SP),R5   ;REGISTER INDEX
825 033436 004037 036254      JSR     R0,ES.SAV   ;PARITY EXIT ADDRESS
826 033442 104002      EMT     2           ;PICKUP (RMAS) BEFORE THE ERROR CALL
827 033444 000701      BR      SC4         ;SAVE THE ADDRESS IN '$ESCAPE'
828
829 033446 004037 036254      7$:     JSR     R0,ES.SAV ;REPORT THE UNEXPECTED ATTENTION
830 033452 104005      EMT     5           ;GO CHECK FOR MORE ATA'S
831
832
833

```



```

833 033454 000675 BR SC4 ;CHECK FOR MORE DRIVES
834
835 033456 006301 SC6: ASL R1 ;SETUP TO ADDRESS WORDS
836 033460 012761 177777 030270 MOV #-1,TIMER(R1) ;STOP THE TIMER
837 033466 006201 ASR R1 ;RESTORE THE DRIVE ADDRESS
838 033470 004737 036164 JSR PC,GETREQ ;GET THE DPB POINTER FROM THE QUEUE
839 033474 010164 000010 MOV R1,RMCS2(R4) ;SELECT DRIVE
840 033500 000137 034026 JMP SC11 ;PROCESS THE SEARCH
841 033504 004037 034756 JSR R0,RD.RM ;READ THE RM'S STATUS REG.
842 033510 000012 RMD5
843 033512 033776 SC8
844 033514 011605 MOV (SP),R5 ;AND PUT IT IN R5
845 033516 006126 ROL (SP)+ ;WAS THERE AN ERROR?
846 033520 100407 BMI 1$ ;BR IF ERROR
847 033522 105761 030176 TSTB DRVACT(R1) ;CHECK DRIVE'S STATE
848 033526 003137 BGT SC11 ;BR IF DRIVE ACTIVE WITH ORDER
849 033530 052762 100210 000016 BIS #BIT15!BIT07!BIT03,16(R2) ;INFORM USER OF ERROR RECOVER COMPLETION
850 033536 000470 BR SC7
851 033540 004037 034756 1$: JSR R0,RD.RM ;READ ERROR REGISTER #1
852 033544 000014 RMR1
853 033546 033776 SC8
854 033550 012605 MOV (SP)+,R5 ;AND SAVE IT IN R5
855 033552 004737 035330 JSR PC,SVRH70 ;SAVE RH/RM REGISTERS
856 033556 012746 000111 MOV #111,-(SP) ;ISSUE A DRIVE CLEAR
857 033562 004037 035136 JSR R0,WRT.RM
858 033566 000000 RMCS1
859 033570 033776 SC8
860
861 033572 006105 SC6A: ROL R5 ;WAS 'UNSAFE' CONDITION =1?
862 033574 100406 BMI 1$ ;BR IF YES
863 033576 005702 TST R2 ;ANYTHING IN QUEUE ?
864 033600 001447 BEQ SC7 ;BR IF NOT
865 033602 052762 100240 000016 BIS #BIT15!BIT07!BIT05,16(R2) ;INFORM USER OF ERROR
866 033610 000443 BR SC7
867 033612 004037 034756 1$: JSR R0,RD.RM ;READ DRIVE STATUS REG. #1
868 033616 000012 RMD5
869 033620 033776 SC8
870 033622 011605 MOV (SP),R5 ;SAVE RMD5 IN R5
871 033624 006126 ROL (SP)+ ;'ERR'=1?
872 033626 100011 BPL 2$ ;BR IF NO--UNSAFE CLEARED
873 033630 112761 177777 030206 MOVB #-1,DRVSTA(R1) ;DRIVE IS UNSAFE
874 033636 004737 035330 JSR PC,SVRH70 ;SAVE RH/RM REGISTERS
875 033642 052762 110000 000016 BIS #BIT15!BIT12,16(R2) ;INFORM USER OF UNSAFE ERROR
876 033650 000423 BR SC7
877 033652 032705 010000 2$: BIT #BIT12,R5 ;'MOL' = 1 ?
878 033656 001015 BNE 3$ ;BR IF YES
879 033660 112761 177777 030176 MOVB #-1,DRVACT(R1) ;ACTIVE ERROR RECOVER
880 033666 112761 000001 030206 MOVB #1,DRVSTA(R1) ;ONLINE
881 033674 006301 ASL R1
882 033676 012761 035230 030270 MOV #15000.,TIMER(R1) ;START 15. SECOND TIMER
883 033704 006201 ASR R1
884 033706 000137 033250 JMP SC4
885 033712 052762 100220 000016 3$: BIS #BIT15!BIT07!BIT04,16(R2) ;INFORM USER OF ERROR
886
887 033720 105061 030176 SC7: CLRB DRVACT(R1) ;DRIVE IS IDLE
889 033724 004737 036206 JSR PC,POPQUE ;REMOVE THE QUEUE
892 033730 105761 030254 TSTB ULDFLG(R1) ;UNLOAD IN PROGRESS OR QUEUE?
  
```

```

893 033734 003002          BGT      1$          ;BR IF NOT
894 033736 105061 030254   CLR      ULDFLG(R1) ;CLEAR UNLOAD FLAG
895 033742 116164 030312 000016 1$:   MOV      ATABIT(R1),RMAS(R4) ;CLEAR ATTENTION BIT
896 033750 105761 030206          TST      DRVSTA(R1) ;IS THE DRIVE UNSAFE ?
897 033754 100406          BMI      2$          ;BR IF IT IS
901 033756 012746 000111          MOV      #111,-(SP) ;DRIVE CLEAR COMMAND
902 033762 004037 035136          JSR      RO,WRT.RM ;WRITE THE COMMAND INTO RPCS1
903 033766 000000          RMCS1 ;REGISTER INDEX
904 033770 033776          SC8 ;PARITY EXIT ADDRESS
905 033772 000137 033250 2$:   JMP      SC4 ;CHECK FOR MORE DRIVES
906
907 033776 105761 030176  SC8:   TST      DRVACT(R1) ;IS DRIVE IDLE?
908 034002 001405          BEQ      1$          ;YES
909 034004 004737 036164          JSR      PC,GETREQ ;GET DPB POINTER
910 034010 004737 032432          JSR      PC,C17 ;PROCESS THE PARITY ERROR
911 034014 000402          BR       2$          ;CONTINUE
912 034016
916 034016 004737 032454          JSR      PC,C17B ;PROCESS THE UNCORRECTABLE PARITY ERROR
917 034022 000137 033250 2$:   JMP      SC4 ;CHECK MORE DRIVES
918
919 034026 105761 030254  SC11:  TST      ULDFLG(R1) ;'UNLOAD IN PROGRESS'?
920 034032 003402          BLE      1$          ;BR IF NO
921 034034 105061 030254          CLR      ULDFLG(R1) ;CLEAR UNLOAD FLAG
922 034040 105061 030176 1$:   CLR      DRVACT(R1) ;SET DRIVE IDLE
923 034044 136137 030312 030250  BITB    ATABIT(R1),SRCHWT ;DOING A SEARCH OPERATION FOR
924                                     ;AN I/O COMMAND?
925 034052 001012          BNE      2$          ;BR IF YES
926 034054 004737 036206          JSR      PC,POPQUE ;REMOVE REQUEST FROM QUEUE
927 034060 052762 000200 000016  BIS      #BIT07,16(R2) ;SET 'DONE' BIT
928 034066 005737 030264          TST      SAVEFG ;SAVE THE REGISTERS?
929 034072 100002          BPL      2$          ;BR IF NO
930 034074 004737 035330          JSR      PC,SVRH70 ;YES--SAVE ALL OF THE RH/RM REG'S
931 034100 116164 030312 000016 2$:   MOV      ATABIT(R1),RMAS(R4) ;CLEAR ATTENTION BIT
932 034106 146137 030312 030250  BICB    ATABIT(R1),SRCHWT ;CLEAR IMPLIED SEEK SET
933 034114 006301          ASL      R1 ;WORD INDEX
934 034116 012761 177777 030270  MOV      #-1,TIMER(R1) ;STOP CLOCK
935 034124 006201          ASR      R1 ;RESTORE R1
936 034126 004737 031354          JSR      PC,OPT ;START A REQUEST
937 034132 000137 033250          JMP      SC4 ;CHECK FOR MORE DRIVES
938
939 034136 010164 000010  SC12:  MOV      R1,RMCS2(R4) ;SELECT DRIVE
940 034142 016437 000012 030166  MOV      RMD5(R4),RMERRS ;SAVE THE FOUR REGISTERS THAT
941 034150 016437 000014 030170  MOV      RMER1(R4),RMERRS+2 ;WILL TELL US SOMETHING
942 034156 016437 000042 030172  MOV      RMER2(R4),RMERRS+4
943 034164 016437 000040 030174  MOV      RMMR2(R4),RMERRS+6
944 034172 004037 030546          JSR      RO,DRVINT ;INIT. THE STATE OF THE DRIVE
945 034176 000401          BR       1$          ;TAKE ERROR EXIT
946 034200 000207          RTS      PC ;RETURN
947 034202 005726 1$:   TST      (SP)+ ;POP PC OFF OF THE STACK
948 034204 000674          BR       SC8 ;PROCESS THE PARITY ERROR
949
950 034206 006301  SC13:  ASL      R1 ;SETUP TO ADDRESS WORDS
951 034210 012761 177777 030270  MOV      #-1,TIMER(R1) ;STOP THE TIMER
952 034216 006201          ASR      R1 ;
953 034220 010164 000010          MOV      R1,RMCS2(R4) ;SELECT THE DRIVE
954 034224 116164 030312 000016  MOV      ATABIT(R1),RMAS(R4) ;CLEAR THE ATTENTION BIT
955 034232 105761 030226 1$:   TST      DPINT(R1) ;INITIALIZING THE DRIVE ?

```

```

956 034236 001424 BEQ 2$ ;BR IF NOT
957 034240 105061 030226 CLRB DPINT(R1) ;CLEAR THE INIT INDICATOR
958 034244 004037 030546 JSR RO,DRVINT ;GO INIT THE DRIVE
959 034250 000240 NOP ;DUMMY PARITY ERROR RETURN
960 034252 105761 030206 TSTB DRVSTA(R1) ;DRIVE ONLINE ?
961 034256 003014 BGT 2$ ;BR IF YES -- START ORDER
962 034260 005702 TST R2 ;QUEUE ENTRY FOR THE DRIVE
963 034262 001426 BEQ 3$ ;BR IF NOT
964 034264 004737 036164 JSR PC,GETREQ ;GET DPB ADDRESS
965 034270 052762 140000 000016 BIS #BIT15:BIT14,16(R2) ;INFORM USER THAT DRIVE OFFLINE
966 034276 004737 035330 JSR PC,SVRH70 ;SAVE THE REGISTERS
970 034302 004737 036206 JSR PC,POPQUE ;REMOVE THE QUEUE
971 034306 000414 BR 3$
972 034310 032764 004000 000000 2$: BIT #BIT11,RMCS1(R4) ;DVA SET ?
973 034316 001006 BNE 4$ ;SET THEN CALL OPT
974 034320 006301 ASL R1
975 034322 012761 035230 030270 MOV #15000.,TIMER(R1) ;START 15. SECOND TIMER
976 034330 006201 ASR R1
977 034332 000402 BR 3$
978 034334 004737 031354 4$: JSR PC,OPT ;START THE PENDING REQUEST
979 034340 000137 033250 3$: JMP SC4 ;PROCESS OTHER DRIVES
980
981 ;RM TIMER ROUTINE
982 ;CALL
983 ;
984 ; MOV #TIME,-(SP) ;ELAPSED TIME IN MILLISECONDS ON THE STACK
985 ; JSR PC,RMTMR ;CALL RM05 TIME ROUTINE
986 034344 005737 030252 RMTMR: TST ACTDRV ;CHECK 'ACTDRV & ACTSTR'
987 034350 001027 BNE 4$ ;IF NON ZERO EXIT
988 034352 112737 000001 030253 MOVB #1,ACTSTR ;SET 'ACTSTR'
989 034360 104412 SAVREG ;SAVE R0 - R5
990 034362 005001 CLR R1 ;START WITH DRIVE 0
991 034364 005003 CLR R3
992 034366 005763 030270 1$: TST TIMER(R3) ;IS THE TIMER RUNNING?
993 034372 002406 BLT 2$ ;BR IF NO
994 034374 166663 000002 030270 SUB 2(SP),TIMER(R3) ;COUNT THE INTERVAL
995 034402 003002 BGT 2$ ;BR IF NO SOFTWARE TIMEOUT
996 034404 004737 034434 JSR PC,STO ;CALL SOFTWARE TIMEOUT ROUTINE
997 034410 005201 2$: INC R1 ;MOVE TO NEXT DRIVE
998 034412 005723 TST (R3)+
999 034414 022701 000010 CMP #8.,R1 ;OUT OF DRIVES?
1000 034420 003362 BGT 1$ ;BR IF NO
1001 034422 104413 3$: RESREG ;RESTORE R0 - R5
1002 034424 105037 030253 CLRB ACTSTR ;ZERO ACTIVE SOFTWARE TIMEOUT ROUTINE FLAG
1003 034430 012616 4$: MOV (SP)+,(SP) ;ADJUST THE STACK
1004 034432 000207 RTS PC ;RETURN
1005
1006 ;SOFTWARE TIMEOUT ROUTINE
1007 ;
1008 ;NOTE: THIS ROUTINE MUST BE ENTERED AT PRIORITY 6
1009 ; OR GREATER
1010 ;
1011 ;CALL: STO
1012 ; MOV #DRVNUM,R1 ;DRIVE NUMBER
1013 ; JSR PC,STO ;CALL
1014 ;
1015 ; RETURN
    
```

```

1016 034434 010176          STO:  MOV    R1,-(SP)      :SAVE R1
1017 034436 010246          MOV    R2,-(SP)      :SAVE R2
1018 034440 010346          MOV    R3,-(SP)      :SAVE R3
1019 034442 010446          MOV    R4,-(SP)      :SAVE R4
1020 034444 013704 030324    MOV    RMADR,R4      :GET ADDRESS OF 'RMCS1'
1021 034450 010164 000010    MOV    R1,RMCS2(R4)  :SELECT THE DRIVE
1022 034454 004037 034756    JSR    R0,RD.RM      :READ 'DRIVE STATUS REG'
1023 034460 000012          RMD5
1027 034462 034744          ST09
1028 034464 105726          TSTB   (SP)+         :IS 'DRY'=1?
1029 034466 100436          BMI    ST02          :BR IF YES
1030 034470 105761 030226    ST01: TSTB   DPINT(R1)  :TRYING TO INITIALIZE THE DRIVE ?
1031 034474 001033          BNE    ST02          :BR IF YES
1032 034476 105761 030236    TSTB   DPRQS(R1)    :OUTSTANDING PORT REQUEST OR THE DRIVE ?
1033 034502 001030          BNE    ST02          :BR IF YES
1034 034504 013702 030246    MOV    TRNSWT,R2     :PICKUP TRANSFER WAIT QUEUE
1035 034510 020137 030310    CMP    R1,DTUW       :TRANSFER UNDERWAY ON THIS DRIVE?
1036 034514 001404          BEQ    1$           :BR IF YES
1037 034516 000137 034744          JMP    ST09         :IF NOT DON'T BOTHER DRIVES
1038 034522 004737 036164          JSR    PC,GETREQ     :GET DPB ADDRESS
1039 034526 052762 101000 000016 1$:  BIS    #BIT15!BIT09,16(R2) :SET THE ERROR FLAGS
1040 034534 004737 035330          JSR    PC,SVRH70     :SAVE RH/RM REGISTERS
1044 034540 105061 030176    CLRB   DRVACT(R1)    :DRIVE IS IDLE
1045 034544 105061 030254    CLRB   ULDFLG(R1)    :CLEAR THE UNLOAD FLAG
1046 034550 005037 030246    CLR    TRNSWT       :CLEAR DPB ADDRESS
1047 034554 012737 177777 030310    MOV    #-1,DTUW     :CLEAR THE TRANSFER DRIVE #
1048 034562 000470          BR     ST09         :DON'T BOTHER OTHER DRIVES
1049
1050 034564 116405 000016    ST02: MOVB   RMAS(R4),R5  :READ ATTENTION REG
1051 034570 136105 030312    BITB   ATABIT(R1),R5 :IS ATTENTION FOR THIS DRIVE UP ?
1052 034574 001007          BNE    ST03          :YES
1053 034576 105761 030226    TSTB   DPINT(R1)    :TRYING TO INITIALIZE THE DRIVE ?
1054 034602 001021          BNE    ST06          :BR IF YES - DRIVE NOT ONLINE
1055 034604 105761 030236    TSTB   DPRQS(R1)    :OUTSTANDING PORT REQUEST FOR THE DRIVE ?
1056 034610 001035          BNE    ST07          :BR IF YES - NO RESPONSE TO REQUEST
1057 034612 000454          BR     ST09         :OTHER WISE EXIT
1058
1059 034614 105761 030226    ST03: TSTB   DPINT(R1)  :INITIALIZING THE DRIVE ?
1060 034620 001003          BNE    1$           :BR IF INIT PENDING
1061 034622 105761 030236    TSTB   DPRQS(R1)    :PORT REQUEST PENDING ?
1062 034626 001446          BEQ    ST09         :BR IF NOT
1063 034630 012763 177777 030270 1$:  MOV    #-1,TIMER(R3) :STOP THE TIMER
1064 034636 000442          BR     ST09         :EXIT
1065
1066 034640 004737 032532    ST05: JSR    PC,C18      :GO HANDLE THE PARITY ERROR
1067 034644 000437          BR     ST09
1068
1069 034646 105061 030226    ST06: CLRB   DPINT(R1)    :CLEAR THE INITIALIZE INDICATOR
1070 034652 105061 030206    CLRB   DRVSTA(R1)   :SET UNIT OFFLINE
1071 034656 012763 177777 030270    MOV    #-1,TIMER(R3) :STOP THE TIMER
1072 034664 004737 036164          JSR    PC,GETREQ     :GET THE DPB ADDRESS
1073 034670 005702          TST    R2           :REQUEST IN QUEUE ?
1074 034672 001424          BEQ    ST09         :BR IF NOT
1075 034674 052762 140000 000016    BIS    #BIT15!BIT14,16(R2) :INFORM THE USER DRIVE NOT AVAILABLE
1076 034702 000414          BR     ST08
1077
1078 034704 012763 177777 030270    ST07: MOV    #-1,TIMER(R3) :STOP THE TIMER

```

```

1079 034712 105061 030236      CLR8   DPRQS(R1)      ;CLEAR PORT REQUEST INDICATOR
1080 034716 004737 036164      JSR    PC,GETREQ     ;GET DPB ADDRESS
1081 034722 005702              TST    R2            ;QUEUE ENTRY FOR DRIVE ?
1082 034724 001407              BEQ    ST09          ;BR IF NONE
1083 034726 012762 100004 000016  ST08:  MOV    #BIT15!BIT2,16(R2) ;INFORM USER OF PORT REQUEST ERROR
1084 034734 004737 036070      JSR    PC,EMPTYQ    ;CLEAR THE QUEUE FOR THE DRIVE
1085 034740 004737 035330      JSR    PC,SVRH70    ;SAVE THE REGISTERS
1086 034744 012604  ST09:  MOV    (SP)+,R4      ;RESTORE R4
1087 034746 012603      MOV    (SP)+,R3      ;RESTORE R3
1088 034750 012602      MOV    (SP)+,R2      ;RESTORE R2
1089 034752 012601      MOV    (SP)+,R1      ;RESTORE R1
1090 034754 000207      RTS    PC            ;RETURN
1091
1092      ;ROUTINE TO READ A RH/RM REGISTER
1093      ;CALL
1094      ;CALL
1095      JSR    R0,RD.RM   ;GO READ A REGISTER
1096      INDEX  ;REG. INDEX FROM BASE
1097      ERRADR ;ERROR ADDRESS--PROCESS ERROR STARTING
1098      ;AT THIS ADDRESS
1099      ;CONTENTS OF REG. IS ON THE STACK
1100      RETURN
1101 034756 013737 030322 035124  RD.RM:  MOV    MCPEMX,RD.RM2 ;MAX. RETRYS ALLOWED
1102 034764 011646      MOV    (SP),-(SP)   ;SAVE R0 FOR RETURN
1103 034766 013737 030324 035002      MOV    RMADR,RD.ADR ;FORM THE DESIRED ADDRESS
1104 034774 062037 035002      ADD    (R0)+,RD.ADR ;USING THE BASE AND THE INDEX
1105 035000 013727      RD.RM1: MOV    @ (PC)+,(PC)+ ;READ THE DESIRED REGISTER OF THE RM DRIVE
1106 035002 000000      RD.ADR: .WORD 0     ;ADDRESS IS FORMED HERE
1107 035004 000000      RD.WRD: .WORD 0     ;REG. CONTENTS PUT HERE
1108 035006 013766 035004 000002      MOV    RD.WRD,2(SP) ;RETURN IT TO THE USER
1109 035014 013746 030324      MOV    RMADR,-(SP)  ;PUT THE ADDRESS ON THE STACK
1110 035020 062716 000010      ADD    #RMCS2,(SP) ;FORM THE ADDRESS OF RMCS2
1111 035024 032736 010000      BIT    #BIT12,@(SP)+ ;CHECK THE 'NED' BIT
1112 035030 001037      BNE    RD.RM3       ;BR IF DRIVE NON-EXISTENT
1113 035032 017746 173266      MOV    @RMADR,-(SP) ;READ RMCS1
1114 035036 032716 020000      BIT    #BIT13,(SP) ;DID MCPE SET?
1115 035042 001002      BNE    1$          ;BR IF YES
1116 035044 022620      CMP    (SP)+,(R0)+ ;ADJUST FOR RETURN
1117 035046 000432      BR     RD.RM4      ;EXIT
1118 035050 1$:
1118 035050 004037 036254      JSR    R0,ES.SAV    ;SAVE THE ADDRESS IN '$ESCAPE'
1118 035054 104003      EMT    3            ;REPORT 'MCPE' ERROR
1119 035056 005737 030310      TST    DTUW         ;DATA TRANSFER UNDERWAY?
1120 035062 100405      BMI    2$          ;NO
1121 035064 032716 040000      BIT    #BIT14,(SP) ;'TRE' = 1 ?
1122 035070 001402      BEQ    2$          ;NO
1123 035072 005726      TST    (SP)+       ;YES--CLEAN OFF THE STACK AND
1124 035074 000415      BR     RD.RM3      ;TAKE THE FATAL ERROR EXIT
1125 035076 052716 040000 2$:  BIS    #BIT14,(SP) ;CLEAR 'MCPE' BY SENDING A '1' TO 'TRE'
1126 035102 000316      SWAB   (SP)        ;POSITION BEFORE WRITING
1127 035104 013737 030324 035120  MOV    RMADR,3$    ;FORM ADDRESS OF HIGH BYTE
1128 035112 005237 035120      INC    3$          ;
1129 035116 112637      MOVB  (SP)+,@(PC)+ ;WRITE THE HIGH BYTE OF RMCS1
1130 035120 000000 3$:  .WORD 0           ;ADDRESS STORAGE
1131 035122 005327      DEC   (PC)+       ;EXCEEDED MAX. RETRYS
1132 035124 000003      RD.RM2: .WORD 3   ;
1133 035126 002324      BGE   RD.RM1      ;BR IF NO
  
```

```

1134 035130 011000 RD.RM3: MOV (R0),R0 ;FATAL ERROR EXIT
1135 035132 012616 MOV (SP)+,(SP)
1136 035134 000200 RD.RM4: RTS R0
1137
1138 ;ROUTINE TO WRITE A REGISTER
1139
1140 ;CALL
1141 ;CALL MOV DATA,-(SP) ;DATA TO BE LOADED ON THE STACK
1142 ;CALL JSR R0,WRT.RM ;CALL THE ROUTINE TO LOAD(WRITE) THE REG.
1143 ;CALL INDEX ;INDEX OF THE REGISTER TO BE LOADED
1144 ;CALL ERRADR ;ADDRESS TO RETURN TO ON AN ERROR
1145 ;CALL RETURN ;ERROR FREE RETURN
1146
1147 035136 013737 030322 035314 WRT.RM: MOV MCPEMX,WRT.R2 ;MAX RETRYS ALLOWED
1148 035144 016637 000002 035224 MOV 2(SP),WRT.WD ;SAVE THE WORD TO WRITE
1149 035152 012616 MOV (SP)+,(SP) ;ADJUST THE STACK
1150 035154 012037 035226 MOV (R0)+,WRT.AD ;GET INDEX OF REGISTER TO BE WRITTEN
1151 035160 001015 BNE 1$ ;BR IF NOT RMCS1
1152 035162 122737 000150 035224 (MPB #150,WRT.WD ;IS THE COMMAND FOR DATA TRANSFERS?
1153 035170 002411 BLT 1$ ;YES--DON'T GET THE OLD A16 & A17, & PSEL
1154 035172 004037 034756 JSR R0,RD.RM ;NO---COMBINE A16&A17, & PSEL WITH
1155 035176 000000 RMCS1 ;THE COMMAND BEFORE SENDING IT TO
1156 035200 035320 WRT.R3 ;THE RH/RM
1157 035202 000316 SWAB (SP)
1158 035204 042716 177770 BIC #^C7,(SP)
1159 035210 112637 035225 MOV (SP)+,WRT.WD+1
1160 035214 063737 030324 035226 1$: ADD RMADR,WRT.AD ;FORM THE ADDRESS OF THE DISK REG.
1161 035222 012737 WRT.R1: MOV (PC)+,@(PC)+ ;LOAD THE DESIRED REG.
1162 035224 000000 WRT.WD: .WORD 0 ;WORD TO WRITE GOES HERE
1163 035226 000000 WRT.AD: .WORD 0 ;ADDRESS IS FORMED HERE
1164 035230 013746 030324 MOV RMADR,-(SP) ;PUT THE ADDRESS ON THE STACK
1165 035234 062716 000010 ADD #RMCS2,(SP) ;FORM THE ADDRESS OF RMCS2
1166 035240 032736 010000 BIT #BIT12,@(SP)+ ;CHECK THE 'NED' BIT
1167 035244 001025 BNE WRT.R3 ;BR IF DRIVE NON-EXISTENT
1168 035246 004037 034756 JSR R0,RD.RM ;CHECK FOR PARITY ERROR ON WRITE
1169 035252 000014 RMER1
1170 035254 035320 WRT.R3
1171 035256 032726 000010 BIT #BIT03,(SP)+
1172 035262 001420 BEQ WRT.R4 ;BR IF 'PAR=0'
1173 035264 016037 177776 035276 MOV -2(R0),1$ ;PICKUP THE INDEX
1174 035272 004037 034756 JSR R0,RD.RM ;READ THE REG.
1175 035276 000000 1$: .WORD 0 ;REG. INDEX
1176 035300 035320 WRT.R3 ;RETURN TO THIS ADDRESS ON ERROR
1177 035302 004037 036254 JSR R0,ES.SAV ;SAVE THE ADDRESS IN '$ESCAPE'
1178 035306 104004 EMT 4 ;REPORT THE PARITY ON WRITE ERROR
1179 035310 005726 TST (SP)+ ;CLEAR OFF THE STACK
1180 035312 005327 DEC (PC)+ ;DECREMENT THE ERROR COUNT
1181 035314 000003 WRT.R2: .WORD 3 ;RETRY COUNTER
1182 035316 002341 BGE WRT.R1 ;TRY AGAIN IF NOT FINISHED
1183 035320 011000 WRT.R3: MOV (R0),R0 ;TAKE THE 'PARITY ON WRITE' ERROR EXIT
1184 035322 000401 BR WRT.R5 ;EXIT
1185 035324 005720 WRT.R4: TST (R0)+ ;ADJUST FOR ERROR FREE EXIT
1186 035326 000200 WRT.R5: RTS R0
1187
1188 ;ROUTINE TO SAVE THE RH/RM REGISTERS AS PER DPB+14
1189 ;CALL

```

```

1190      :      MOV      #DPBNUM,R2      :DPB POINTER TO R2
1191      :      JSR      PC,SVRH70        :SAVE THE DRIVES REG'S
1192
1193 035330 104412      SVRH70: SAVREG      :SAVE R0 - R5
1194 035332 005702      TST      R2          :QUEUE ENTRY FOR THE DRIVE ?
1195 035334 001442      BEQ      6$          :BR IF NONE
1196 035336 013704 030324      MOV      RMADR,R4
1197 035342 111264 000010      MOVVB   (R2),RMCS2(R4) :SELECT DRIVE
1198 035346 016203 000014      MOV      14(R2),R3    :GET THE ERROR TABLE POINTER
1199 035352 001433      BEQ      6$          :EXIT IF NO ADDRESS
1200 035354 005037 035410      CLR      3$          :COUNTER & POINTER
1201 035360 023727 035410 000022 1$:      CMP      3$,#RMDDB    :REACHED THE BUFFER REGISTER ?
1202 035366 001006      BNE      2$          :BR IF NOT
1203 035370 032764 000200 000010      BIT      #BIT07,RMCS2(R4) :'OR' SET ?
1204 035376 001002      BNE      2$          :BR IF SET
1205 035400 005023      CLR      (R3)+        :STORE RMDDB AS ZEROES
1206 035402 000405      BR      4$          :CONTINUE
1207 035404 004037 034756      2$:      JSR      R0,RD.RM    :READ THE SELECTED REGISTER
1208 035410 000000      3$:      .WORD   0          :REGISTER INDEX
1209 035412 035436      5$:      .ERR    :ERROR RETURN ADDRESS
1210 035414 012623      MOV      (SP)+,(R3)+  :STORE THE REGISTER CONTENTS
1211 035416 023727 035410 000046 4$:      CMP      3$,#RMEC2   :REACHED THE END ?
1212 035424 001406      BEQ      6$          :BR IF YES
1213 035426 062737 000002 035410      ADD      #2,3$       :INCREMENT THE REGISTER INDEX
1214 035434 000751      BR      1$          :CONTINUE READING THE REGISTERS
1215 035436 004737 032432      5$:      JSR      PC,C17     :PROCESS THE UNCORRECTABLE PARITY ERROR
1226 035442 104413      6$:      RESREG
1228 035444 000207      RTS      PC          :RESTORE R0 - R5
1229
1230      :ROUTINE TO SET THE INTERRUPT WITHOUT GETTING A "TRE"
1231      :CALL
1232      :      MOV      #DRVNUM,R1      :DRIVE NUMBER TO R1
1233      :      JSR      PC,SET.IE      :SET "IE"
1234      :      RETURN
1235
1236 035446 010446      SET.IE: MOV      R4,-(SP)    :SAVE R4
1237 035450 013704 030324      MOV      RMADR,R4    :PICKUP ADDRESS OF RMCS1
1238 035454 010164 000010      MOV      R1,RMCS2(R4) :SELECT DRIVE
1239 035460 011446      MOV      (R4),-(SP)  :READ RMCS1
1240 035462 052716 040000      BIS      #BIT14,(SP) :SET THE "TRE" BIT OF THE WORD READ
1241 035466 000316      SWAB   (SP)         :ADJUST FOR DATO
1242 035470 112714 000100      MOVVB   #BIT06,(R4)  :SET "IE"
1243 035474 032764 010000 000010      BIT      #BIT12,RMCS2(R4) :IS "NED"=1?
1244 035502 001002      BNE      1$          :YES--CLEAR "TRE"
1245 035504 005726      TST      (SP)+        :CLEAN OFF THE STACK
1246 035506 000402      BR      2$          :
1247 035510 112664 000001      1$:      MOVVB   (SP)+,1(R4)  :CLEAR "TRE"
1248 035514 012604      2$:      MOV      (SP)+,R4    :RESTORE R4
1249 035516 000207      RTS      PC          :RETURN TO CALLER
1250
1251      :QUEUE COUNT
1252
1253 035520      000      QCNT: .BYTE   0          :DRIVE 0
1254 035521      000      .BYTE   0          :DRIVE 1
1255 035522      000      .BYTE   0          :DRIVE 2
1256 035523      000      .BYTE   0          :DRIVE 3
1257 035524      000      .BYTE   0          :DRIVE 4

```

```

035525 000 .BYTE 0 ;DRIVE 5
035526 000 .BYTE 0 ;DRIVE 6
035527 000 .BYTE 0 ;DRIVE 7
1257
1258 ;QUEUE INPUT POINTERS
1259
1260 035530 035612 QINPT: .WORD QDRV0 ;DRIVE 0
1263 035532 035632 .WORD QDRV1 ;DRIVE 1
035534 035652 .WORD QDRV2 ;DRIVE 2
035536 035672 .WORD QDRV3 ;DRIVE 3
035540 035712 .WORD QDRV4 ;DRIVE 4
035542 035732 .WORD QDRV5 ;DRIVE 5
035544 035752 .WORD QDRV6 ;DRIVE 6
035546 035772 .WORD QDRV7 ;DRIVE 7
1264
1265 ;QUEUE OUTPUT POINTERS
1266
1267 035550 035612 QOUTPT: .WORD QDRV0 ;DRIVE 0
1270 035552 035632 .WORD QDRV1 ;DRIVE 1
035554 035652 .WORD QDRV2 ;DRIVE 2
035556 035672 .WORD QDRV3 ;DRIVE 3
035560 035712 .WORD QDRV4 ;DRIVE 4
035562 035732 .WORD QDRV5 ;DRIVE 5
035564 035752 .WORD QDRV6 ;DRIVE 6
035566 035772 .WORD QDRV7 ;DRIVE 7
1271
1272 035570 035612 QSTART: .WORD QDRV0 ;DRIVE 0 START ADDRESS
1273 035572 035632 QSTOP: .WORD QDRV1 ;DRIVE 0 STOP ADDRESS & DRIVE 1 START ADDRESS
1274 035574 035652 .WORD QDRV2 ;STOP DRIVE 1--START DRIVE 2
1275 035576 035672 .WORD QDRV3 ;STOP DRIVE 2--START DRIVE 3
1276 035600 035712 .WORD QDRV4 ;STOP DRIVE 3--START DRIVE 4
1277 035602 035732 .WORD QDRV5 ;STOP DRIVE 4--START DRIVE 5
1278 035604 035752 .WORD QDRV6 ;STOP DRIVE 5--START DRIVE 6
1279 035606 035772 .WORD QDRV7 ;STOP DRIVE 6--START DRIVE 7
1280 035610 036012 .WORD QTERM ;STOP DRIVE 7
1281
1282 ;DRIVE REQUEST QUEUES
1283
1286 035612 QDRV0: .BLKW 10
035632 QDRV1: .BLKW 10
035652 QDRV2: .BLKW 10
035672 QDRV3: .BLKW 10
035712 QDRV4: .BLKW 10
035732 QDRV5: .BLKW 10
035752 QDRV6: .BLKW 10
035772 QDRV7: .BLKW 10
1287 036012 QTERM=.
1288
1289 ;ROUTINE TO CLEAR ALL OF THE REQUEST QUEUES
1290
1291 ;CALL
1292 ; JSR PC,CLRQUE
1293
1294 036012 104412 CLRQUE: SAVREG ;SAVE R0 - R5
1295 036014 012702 035520 MOV #QCNT,R2 ;ZERO THE QUEUE COUNTS
1296 036020 005022 CLR (R2)+ ;DRIVES 0 & 1
1297 036022 005022 CLR (R2)+ ;DRIVES 2 & 3

```





```

1355 036164 005002          GETREQ: CLR      R2
1356 036166 105761 035520  TSTB     QCNT(R1)      ;IS THERE ANY REQUEST IN QUEUE?
1357 036172 001404          BEQ      2$           ;NO
1358 036174 006301          1$:     ASL      R1
1359 036176 017102 035550  MOV      @QOUTPT(R1),R2 ;PICKUP 'DPB' POINTER FOR THIS DRIVE
1360 036202 006201          ASR      R1
1361 036204 000207          2$:     RTS      PC           ;RETURN TO USER
1362
1363          ;ROUTINE TO 'POP' THE REQUEST FROM QUEUE
1364          ;CALL
1365          ;
1366          ;     MOV      #DRVNUM,R1      ;DRIVE NUMBER TO R1
1367          ;     JSR      PC,POPQUE     ;CALL TO REMOVE REQUEST
1368          ;     RETURN                   ;R2=ADDRESS OF DPB REMOVED
1369
1370 036206 105361 035520  POPQUE: DECB     QCNT(R1)      ;DECREMENT QUEUE COUNT
1371 036212 006301          ASL      R1
1372 036214 017102 035550  MOV      @QOUTPT(R1),R2 ;GET THE 'DPB' POINTER
1373 036220 005071 035550  CLR      @QOUTPT(R1)    ;REMOVE DPB ADDRESS FROM THE QUEUE
1374 036224 062761 000002 035550  ADD      #2,QOUTPT(R1)  ;UPDATE THE QUEUE POINTER
1375 036232 026161 035550 035572  CMP      QOUTPT(R1),QSTOP(R1) ;TIME TO RESET THE POINTER?
1376 036240 001003          BNE     1$           ;NO--BR TO EXIT
1377 036242 016161 035570 035550  MOV      QSTART(R1),QOUTPT(R1) ;YES--RESET THE POINTER
1378 036250 006201          1$:     ASR      R1
1379 036252 000207          RTS      PC           ;RETURN TO USER
1380
1382          ;ROUTINE TO SAVE THE CONTENTS OF '$ESCAPE' WHEN THE DRIVER
1383          ;REPORTS AN ERROR DIRECTLY.
1384          ;CALL
1385          ;
1386          ;     JSR      R0,ES.SAV      ;:THE ERROR CALL
1387          ;     ERROR   N              ;:THE RETURN IS PAST THE ERROR CALL
1388          ;     RETURN
1389
1390 036254 012037 036270  ES.SAV: MOV      (R0)+,1$      ;GET THE ERROR CALL
1391 036260 013746 001200  MOV      $ESCAPE,-(SP)  ;SAVE THE ADDRESS IN '$ESCAPE'
1392 036264 005037 001200  CLR      $ESCAPE       ;CLEAR THE ESCAPE RETURN
1393 036270 000000          .WORD   0             ;THE ERROR CALL IS MOVED HERE
1394 036272 012637 001200  MOV      (SP)+,$ESCAPE ;RESTORE THE ESCAPE ADDRESS
1395 036276 000200          RTS      R0          ;RETURN
  
```

```

1      .SBTTL  BUSADR - GET BUS ADDRESS AND VECTOR ADDRESS
2
3      ;THIS ROUTINE IS USED TO INSURE THE BUS ADDRESS
4      ;OF THE RH/RM IS SETUP FOR THE PROPER ADDRESS.
5      ;IT WILL ALSO READ THE ADDRESS FROM THE TTY IF
6      ;REQUIRED.
7      ;NOTE: THIS ROUTINE DESTROYS R0-R4
8      ;CALL
9      :
10     :       JSR      PC,BUSADR
11     :       RETURN
12
13     BUSADR: SAVREG      ;SAVE ALL REG
14     1$:  MOV      #SRMADR,R0      ;FIRST ADDRESS
15           TYPE     ,MRMCS1      ;'RMCS1='
16           MOV      (R0),-(SP)    ;PRESENT RMCS1 ADDRESS
17           TYPOC   ,BLNKS1      ;TYPE IT
18           TYPE     ,BLNKS1      ;TYPE 1 BLANK
19           RDLIN   ;GET THE ENTRY
20           MOV      (SP)+,R1      ;ADDRESS OF ASCII TEXT
21           JSR      R5,CK.NUM     ;ENTER AND STORE THE NEW ADDRESS
22           BR       1$          ;ERROR EXIT
23     2$:  MOV      #SRMVEC,R0     ;VECTOR ADDRESS
24           TYPE     ,MRMVEC      ;'RMVEC='
25           MOV      (R0),-(SP)    ;PRESENT RH/RM VECTOR ADDRESS ON THE STACK
26           TYPOC   ,BLNKS1      ;TYPE IT
27           TYPE     ,BLNKS1      ;TYPE 1 BLANK
28           RDLIN   ;READ THE ENTRY
29           MOV      (SP)+,R1      ;ASCII TEXT ADDRESS
30           JSR      R5,CK.NUM     ;ENTER AND STORE NEW ADDRESS
31           BR       2$          ;ERROR EXIT
32     3$:  MOV      #SRMADR,R0     ;FIRST ADDRESS OF NEW PARAMETERS
33           MOV      #RMADR,R1     ;FIRST ADDRESS OF WHERE TO PUT THEM
34           MOV      @#ERRVEC,R5   ;SAVE ERROR VECTOR
35           MOV      #4$,@#ERRVEC  ;LOAD NEW VECTOR ADDRESS
36           TST     @SRMADR        ;LEGAL I/O ADDRESS ?
37           MOV      R5,@#ERRVEC   ;YES,IF NOT TRAP TO TIMEOUT
38           MOV      (R0)+,(R1)+  ;LOAD THE BUS ADDRESS
39           MOV      (R0)+,(R1)+  ;LOAD VECTOR ADDRESS
40           BR       6$          ;COMMON EXIT
41     4$:  MOV      #5$, (SP)     ;SET RETURN ADDRESS
42           RTI                    ;RETRUN FROM TIME OUT TRAP
43     5$:
44           EMT      6
45           MOV      R5,@#ERRVEC   ;RESTORE THE TIME OUT TRAP
46           BR       1$          ;TRY AGAIN
47     6$:  RESREG   ;RESTORE ALL REG
48           RTS      PC
49     MRMCS1: .ASCIZ @RMCS1=@
50     MRMVEC: .ASCIZ @RMVEC=@
51
52     .SBTTL  CK.NUM - CHECK NUMBER (OCTAL)
53     ;THIS ROUTINE CHECKS AN ASCIZ STRING FOR LEGAL CHARACTERS
54     ;AND FORMS AN OCTAL NUMBER IN R2
55     ;CALL:
56     :       MOV      #ADR,R1      ;ADDRESS OF ASCIZ STRING
  
```

13	036300	104412			
14	036302	012700	001276		
15	036306	104401	036450		
16	036312	011046			
17	036314	104402			
18	036316	104401	042752		
19	036322	104411			
20	036324	012601			
21	036326	004537	036466		
22	036332	000763			
23	036334	012700	001300		
24	036340	104401	036457		
25	036344	011046			
26	036346	104402			
27	036350	104401	042752		
28	036354	104411			
29	036356	012601			
30	036360	004537	036466		
31	036364	000763			
32	036366	012700	001276		
33	036372	012701	030324		
34	036376	013705	000004		
35	036402	012737	036426	000004	
36	036410	005777	142662		
37	036414	010537	000004		
38	036420	012021			
39	036422	012021			
40	036424	000407			
41	036426	012716	036434		
42	036432	000002			
43	036434				
44	036436	104006			
45	036442	010537	000004		
46	036444	000717			
47	036446	104413			
48	036446	000207			
49	036450	122	115	103	
50	036457	122	115	126	

57			:	JSR	R5,CK.NUM	:R5 CHANGED
58			:	RET		:ERROR EXIT
59			:	RET		:NORMAL EXIT
60	036466	010246	CK.NUM:	MOV	R2,-(SP)	:SAVE R2
61	036470	010346		MOV	R3,-(SP)	:SAVE R3
62	036472	010446		MOV	R4,-(SP)	:SAVE R4
63	036474	012703	000006	MOV	#6,R3	:MAX OCTAL DIGITS IN THE NUMBER
64	036500	005002		CLR	R2	:FINAL OCTAL VALUE
65	036502	112104	1\$:	MOVB	(R1)+,R4	:GET CURRENT POINTED BYTE
66	036504	001424		BEQ	3\$	:BRANCH,IF TERMINATOR DETECTED
67	036506	120427	000060	CMPB	R4,#'0	:SMALLER THAN ASCII-0 ?
68	036512	103425		BLO	5\$	:YES,ERROR EXIT
69	036514	120427	000067	CMPB	R4,#'7	:LARGER THAN ASCII-7 ?
70	036520	101022		BHI	5\$	:YES,ERROR EXIT
71	036522	006302		ASL	R2	:SHIFT LEFT
72	036524	103420		BCS	5\$	
73	036526	006302		ASL	R2	:ONE
74	036530	103416		BCS	5\$	
75	036532	006302		ASL	R2	:OCTAL DIGIT
76	036534	103414		BCS	5\$	:ERROR IF CARRY BIT SET
77	036536	042704	177770	BIC	#177770,R4	:CHOP OFF HIGHER BITS
78	036542	060402		ADD	R4,R2	:APPENDING CURRENT DIGIT TO NUMBER
79	036544	005303		DEC	R3	:DECREMENT BYTE COUNT
80	036546	001401		BEQ	2\$	:BRANCH,IF LAST BYTE
81	036550	000754		BR	1\$	:LOOPING BACK
82	036552	112104	2\$:	MOVB	(R1)+,R4	:CHECK TERMINATOR
83	036554	001004		BNE	5\$	:ERROR EXIT
84	036556	005702	3\$:	TST	R2	:FINAL VALUE = 0
85	036560	001402		BEQ	5\$	:YES, TAKE ERROR EXIT
86	036562	010210		MOV	R2,(R0)	:REPLACE THE ORIGINAL VALUE
87	036564	005725	4\$:	TST	(R5)+	:ADJUST FOR NORMAL RETURN
88	036566	012604	5\$:	MOV	(SP)+,R4	:RESTORE R4
89	036570	012603		MOV	(SP)+,R3	:RESTORE R3
90	036572	012602		MOV	(SP)+,R2	:RESTORE R2
91	036574	000205		RTS	R5	:EXIT

```

1          .SBTTL  ERROR MESSAGES
2
3 036576    122    110    040  EM1:  .ASCIZ  /RH INTERRUPT OCCURRED (RMAS=0)/
4 036635    125    116    105  EM2:  .ASCIZ  /UNEXPECTED ATTENTION OCCURRED/
5 036673    115    101    123  EM3:  .ASCIZ  /MASSBUS PARITY ERROR (MCPE=1)/
6 036731    115    101    123  EM4:  .ASCIZ  /MASSBUS PARITY ERROR (PAR=1)/
7 036766    101    104    104  EM5:  .ASCIZ  /ADDRESS PLUG CHANGE BIT SET/
8 037022    122    110    040  EM6:  .ASCIZ  /RH DIDN'T RESPOND TO ADDRESSING/
9 037062    125    116    103  EM10: .ASCIZ  /UNCORRECTABLE MASSBUS PARITY ERROR/
10 037125   106    101    124  EM11: .ASCIZ  /FATAL MASSBUS PARITY ERROR/
11 037160   120    105    122  EM12: .ASCIZ  /PERSISTENT DEVICE UNSAFE/
12 037211   117    120    105  EM13: .ASCIZ  /OPERATION NOT COMPLETED WITHIN TIME LIMIT/
13 037263   104    122    111  EM14: .ASCIZ  /DRIVE WENT OFFLINE/
14 037306   116    117    040  EM15: .ASCIZ  /NO RESPONSE TO PORT REQUEST/
15 037342   110    105    101  EM20: .ASCIZ  /HEADER CRC ERROR/
16 037363   104    101    124  EM21: .ASCIZ  /DATA CHECK ('DCK') ERROR/
17 037414   127    122    111  EM22: .ASCIZ  /WRITE CHECK ERROR - DATA CHECK ('DCK') SET/
18 037467   127    122    111  EM23: .ASCIZ  /WRITE CHECK ERROR - DATA CHECK ('DCK') NOT SET/
19 037546   110    105    101  EM24: .ASCIZ  /HEADER READ ERROR - 'FMT' BIT DROPPED/
20 037614   110    105    101  EM25: .ASCIZ  /HEADER READ ERROR - HEADER COMPARE ('HCE') ERROR/
21 037675   106    117    122  EM26: .ASCIZ  /FORMAT ERROR ('FER')/
22 037722   110    105    101  EM27: .ASCIZ  /HEADER COMPARE ('HCE') ERROR/
23 037757   115    111    123  EM30: .ASCIZ  /MISCELLANEOUS DRIVE ERROR/
24 040011   117    120    105  EM31: .ASCIZ  /OPERATION INCOMPLETE ('OPI') ERROR/
25 040054   104    122    111  EM32: .ASCIZ  /DRIVE TIMING ('DTE') ERROR/
26 040107   120    101    122  EM33: .ASCIZ  /PARITY ('PAR') ERROR AFTER OPERATION STARTED/
27 040164   127    122    111  EM34: .ASCIZ  /WRITE CLOCK FAILURE ('WCF') ERROR/
28 040226   111    116    126  EM35: .ASCIZ  /INVALID ADDRESS ('IAE') ERROR/
29 040264   127    122    111  EM36: .ASCIZ  /WRITE LOCK ('WLE') ERROR/
30 040315   104    101    124  EM37: .ASCIZ  /DATA CHECK ('DCK') SET DURING WRITE CHECK COMMAND/
31 040377   122    110    040  EM40: .ASCIZ  /RH CONTROLLER OR UNIBUS TRANSFER ERROR/
32 040446   102    125    123  EM41: .ASCIZ  /BUS ADDRESS OR WORD COUNT INCORRECT/
33 040512   104    101    124  EM42: .ASCIZ  /DATA COMPARE ERRORS - NO OTHER ERROR(S) DETECTED/
34 040573   103    101    116  EM43: .ASCIZ  /CAN'T MATCH DATA READ WITH A PATTERN/
35 040640   105    122    122  EM44: .ASCIZ  /ERROR BIT(S) SET, BUT NO ERROR SIGNALLED BY THE RH/
36 040722   105    103    103  EM45: .ASCIZ  /ECC LOGIC FAILURE - POSITION REGISTER VALUE NOT VALID/
37 041010   102    125    123  EM46: .ASCIZ  /BUS ADDRESS AND WORD COUNT NOT CONSISTENT/
38 041062   123    105    105  EM50: .ASCIZ  /SEEK INCOMPLETE ('SKI') ERROR/
39 041120   120    122    117  EM51: .ASCIZ  /PROGRAM DETECTED POSITIONING ERROR/
40 041163   104    122    111  EM60: .ASCIZ  /DRIVE UNSAFE ERROR/
41 041206   040    040    000  EM61: .ASCIZ  / /
42          .EVEN
  
```



```

1 041776      123      125      102  MSG1:  .ASCIZ  /SUBSYS /
2 042006      104      122      111  MSG2:  .ASCIZ  /DRIVE(S): /
3 042021      052      052      040  MSG3:  .ASCIZ  /** STARTING PASS 1 /
4 042045      200      115      117  MSG4:  .ASCIZ  <CRLF>/MOUNT PACK ON DRIVE /
5 042073      101      116      104  MSG8:  .ASCIZ  /AND LOAD. /
6 042106      124      131      120  MSG9:  .ASCIZ  /TYPE <CR> WHEN DRIVE READY./
7 042142      200      104      122  MSG10: .ASCIZ  <CRLF>/DRIVE IS NOT READY, TEST IS ABORTED/
8 042207      200      120      101  MSG11: .ASCIZ  <CRLF>/PACK IS NOT ACCEPTABLE, CHANGE PACK AND TRY AGAIN/
9 042272      125      116      114  MSG12: .ASCIZ  /UNLOAD DRIVE /
10 042310     040      101      116  MSG13: .ASCII  / AND REMOVE PACK/<CRLF>
11 042331     124      131      120  .ASCIZ  /TYPE <CR> WHEN DONE./
12 042356     052      052      040  MSG14: .ASCIZ  /** STARTING PASS 2 /
13 042402     052      052      040  MSG15: .ASCIZ  /** ALL DRIVES ARE COMPATIBLE **/<CRLF>
14 042443     123      103      117  MSG16: .ASCIZ  /SCORES FOR DRIVE /
15 042465     040      040      040  MSG17: .ASCIZ  / TRACK DRIVE OVRWRT OVRWRT READ READ/
16 042546     040      040      040  MSG18: .ASCIZ  / NUMBR READ OFST- OFST+ OFST- OFST+/
17 042630     123      105      114  SELFX: .ASCIZ  /SELF/
18 042635     011      000      TAB:   .ASCIZ  <HT>
19 042637     052      040      060  MARKX: .ASCIZ  /* 0/<HT>
20 042644     042      000      QUOTM: .ASCIZ  /'/
21 042646     054      040      000  COMMA: .ASCIZ  /./
22 042651     127      111      114  MSG5:  .ASCIZ  /WILL TEST /
23 042664     117      116      040  MSG6:  .ASCIZ  /ON /
24 042670     200      111      123  MSG7:  .ASCIZ  <CRLF>/IS THERE ANOTHER SUB-SYSTEM (Y OR N) ? /
25 042741     131      200      000  Y:    .ASCIZ  /Y/<CRLF>
26 042744     116      200      000  N:    .ASCIZ  /N/<CRLF>
27 042747     040      BLNK4: .ASCII  / /
28 042750     040      BLNK3: .ASCII  / /
29 042751     040      BLNK2: .ASCII  / /
30 042752     040      000      BLNK1: .ASCIZ  / /
31 042754     072      000      COLON: .ASCIZ  /:/
32 042756     040      057      040  SLASH: .ASCIZ  @ / @
33 042762     077      000      QUES:  .ASCIZ  /?/
34 042764     040      102      101  MSG19: .ASCIZ  / BAD SPOT FILE /
35 043004     124      105      123  MSG20: .ASCIZ  /TEST COMPLETE/
36 043022     200      052      052  STARS: .ASCIZ  <CRLF>/*****/<CRLF>
37 043044     104      122      111  MSG21: .ASCII  /DRIVE NOT ON-LINE OR NOT ASSIGNED/<CRLF>
41 043106     007      120      122  HALTX: .ASCIZ  <07>/PROGRAM HALT/<CRLF>
42 043125     104      122      111  HALT1: .ASCIZ  /DRIVE FAILED ON BASIC READ & WRITE TEST/<CRLF>
43 043176     104      122      111  HALT2: .ASCIZ  /DRIVE FAILED ON WRITE TEST (TEST 4)/<CRLF>
44 043243     106      101      124  XFATL: .ASCIZ  /FATAL ERROR/
45 043257     200      040      047  NEDCLK: .ASCIZ  <CRLF>/ 'L' OR 'P' CLOCK REQUIRED ON SYSTEM/<CRLF>
46 043326     040      077      104  QDRIV: .ASCIZ  / ?DRIVE/
47 043336     040      111      123  LODEV: .ASCIZ  / IS LOAD DEVICE/
48 043356     040      077      103  NOTST: .ASCIZ  @ ?CANNOT SELECT RM03/2'S AND RM05'S TOGETHER (NOT COMPATIBLE)@<CRLF>
49
50
51
52 043456
53
54
000200
.END 200

```

ABASE = 176700	AJSWR = 000000	CKSWR = 104407	DRIV4 = 004732	EM43 = 040573
ACDW1 = 000000	AVECT1 = 000254	CK.CHR = 022464	DRIV5 = 004754	EM44 = 040640
ACDW2 = 000000	AVECT2 = 000000	CK.DEC = 022436	DRIV6 = 004776	EM45 = 040722
ACK = 000123	BADSEC = 001342	CK.DIG = 022536	DRIV7 = 005020	EM46 = 041010
ACPUOP = 000000	BADTMO = 005502	CK.NUM = 036466	DRVACT = 030176	EM5 = 036766
ACTDRV = 030252	BIT0 = 000001	CK.OCT = 022410	DRVCLR = 000111	EM50 = 041062
ACTSTR = 030253	BIT00 = 000001	CLKFLG = 001316	DRVER = 020350	EM51 = 041120
ADDW0 = 000000	BIT01 = 000002	CLOCK = 021526	DRVINT = 030546	EM6 = 037022
ADDW1 = 000000	BIT02 = 000004	CLRDPB = 021720	DRVQUE = 036110	EM60 = 041163
ADDW10 = 000000	BIT03 = 000010	CLRQUE = 036012	DRVSTA = 030206	EM61 = 041206
ADDW11 = 000000	BIT04 = 000020	CMCNT = 001354	DRV TYP = 030216	ENDX1 = 011004
ADDW12 = 000000	BIT05 = 000040	CMCYL = 001356	DSWR = 177570	ERPRC1 = 017562
ADDW13 = 000000	BIT06 = 000100	CMSEC = 001362	DTEER = 020420	ERPROC = 017546
ADDW14 = 000000	BIT07 = 000200	CMTRK = 001364	DTUW = 030310	ERROR = 104000
ADDW15 = 000000	BIT08 = 000400	COLON = 042754	DTYP = 001402	ERRVEC = 000004
ADDW2 = 000000	BIT09 = 001000	COMMA = 042646	DT1 = 041634	ES.SAV = 036254
ADDW3 = 000000	BIT1 = 000002	CPSAVE = 024252	DT10 = 041720	FALPAR = 017664
ADDW4 = 000000	BIT10 = 002000	CR = 000015	DT11 = 041734	FAULT = 001376
ADDW5 = 000000	BIT11 = 004000	CRLF = 000200	DT12 = 041750	FILBUF = 021042
ADDW6 = 000000	BIT12 = 010000	CYLIMT = 001374	DT2 = 041640	FINISH = 023620
ADDW7 = 000000	BIT13 = 020000	CYLNR = 004616	DT3 = 041656	FMTDPB = 004506
ADDW8 = 000000	BIT14 = 040000	DCKER = 020300	DT4 = 041666	FMTER = 020460
ADDW9 = 000000	BIT15 = 100000	DDISP = 177570	DT6 = 041700	GENDPB = 004576
ADEVCT = 000000	BIT2 = 000004	DEASG = 017070	DT7 = 041704	GETREG = 000141
ADEVM = 000000	BIT3 = 000010	DF1 = 041760	DUMP = 020540	GETREQ = 036164
AENV = 000000	BIT4 = 000020	DF2 = 041761	DUMP2 = 017720	GTSWR = 104406
AENVM = 000000	BIT5 = 000040	DF3 = 041767	EMPTYQ = 036070	HALTX = 043106
AFATAL = 000000	BIT6 = 000100	DF4 = 041772	EMTVEC = 000030	HALT1 = 043125
AMADR1 = 000000	BIT7 = 000200	DH1 = 041212	EM1 = 036576	HALT2 = 043176
AMADR2 = 000000	BIT8 = 000400	DH10 = 041460	EM10 = 037062	HCEER = 020470
AMADR3 = 000000	BIT9 = 001000	DH11 = 041531	EM11 = 037125	HCR CER = 020340
AMADR4 = 000000	BLKADR = 004444	DH12 = 041602	EM12 = 037160	HOURL = 001344
AMAMS1 = 000000	BLNKS1 = 042752	DH2 = 041221	EM13 = 037211	HT = 000011
AMAMS2 = 000000	BLNKS2 = 042751	DH3 = 041303	EM14 = 037263	HZ = 001320
AMAMS3 = 000000	BLNKS3 = 042750	DH4 = 041334	EM15 = 037306	IAEER = 020440
AMAMS4 = 000000	BLNKS4 = 042747	DH6 = 041376	EM2 = 036635	IBSAVE = 024254
AMSGAD = 000000	BPTVEC = 000014	DH7 = 041407	EM20 = 037342	IDLEX = 017444
AMSGLG = 000000	BUFFER = 043456	DISMNT = 017016	EM21 = 037363	INDST = 004424
AMSGTY = 000000	BUSADR = 036300	DISPLA = 001156	EM22 = 037414	IOTVEC = 000020
AMTYP1 = 000000	CFLAG = 001336	DISPLY = 104414	EM23 = 037467	ISR = 032762
AMTYP2 = 000000	CHGADR = 001334	DISPRE = 000174	EM24 = 037546	KPATH = 016530
AMTYP3 = 000000	CI1 = 031602	DONE = 017744	EM25 = 037614	KSR = 021634
AMTYP4 = 000000	CI3 = 031710	DPINT = 030226	EM26 = 037675	LABAD = 015034
APASS = 000000	CI4 = 032016	DPRQS = 030236	EM27 = 037722	LF = 000012
APRIOR = 000000	CI5 = 032374	DRIVE = 001224	EM3 = 036673	LINDEC = 021214
APTCSU = 000040	CI6 = 032416	DRIVO = 004622	EM30 = 037757	LINE1 = 021116
APTENV = 000001	CI7 = 032432	DRIV1 = 004644	EM31 = 040011	LINKDV = 021764
APTSIZ = 000200	CI7B = 032454	DRIV10 = 005042	EM32 = 040054	LINOCT = 021162
APTSP0 = 000100	CI8 = 032532	DRIV11 = 005064	EM33 = 040107	LODEV = 043336
ASNLST = 002006	CKBUS = 020640	DRIV12 = 005106	EM34 = 040164	LOG0 = 001406
ASSGN1 = 002010	CKCLK = 021234	DRIV13 = 005130	EM35 = 040226	LOG1 = 001426
ASSGN2 = 002012	CKCLK1 = 021330	DRIV14 = 005152	EM36 = 040264	LOG10 = 001646
ASWREG = 000000	CKCLK2 = 021376	DRIV15 = 005174	EM37 = 040315	LOG11 = 001666
ATABIT = 030312	CKCLK3 = 021420	DRIV16 = 005216	EM4 = 036731	LOG12 = 001706
ATESTN = 000000	CKERR = 020572	DRIV17 = 005240	EM40 = 040377	LOG13 = 001726
ATIN = 001326	CKFMT = 020360	DRIV2 = 004666	EM41 = 040446	LOG14 = 001746
AWNT = 000000	CKHLE = 020370	DRIV3 = 004710	EM42 = 040512	LOG15 = 001766



SYMBOL TABLE

LOG2	001446	N	042744	PIRO	= 177772	RDN6	003356	RMSN	= 000030
LOG3	001466	MEDCLK	043257	PIRQVE	= 000240	RDN7	003376	RMTMR	034344
LOG4	001506	NOTST	043356	POPOUE	036206	RDN8	003416	RMVEC	030326
LOG5	001526	MULINE	001366	POSER	020400	RDN9	003436	RMVC	= 000002
LOG6	001546	OFFCOD	004504	PRINT	017152	RDP0	003676	RM.REG	004526
LOG7	001566	OFFSET=	000115	PROCES	017452	RDP1	003716	RMOS	031062
LOG8	001606	OFFST	014244	PRTBAD	020702	RDP10	004136	RNOP	= 000101
LOG9	001626	DFLIN	017704	PRTIM	017714	RDP11	004156	RSTART	001400
LOOP1	013630	OPIER	020410	PRO	= 000000	RDP12	004176	RTC	= 000117
LOOP2	013646	OPT	031354	PR1	= 000040	RDP13	004216	R6	= 000006
LOOP3	015716	OVWNO	002056	PR2	= 000100	RDP14	004236	R7	= 000007
LOOP4	016510	OVWN1	002076	PR3	= 000140	RDP15	004256	SAVEFG	030264
LOOP5	016722	OVWN10	002316	PR4	= 000200	RDP16	004276	SAVREG=	104412
LOOP6	016740	OVWN11	002336	PR5	= 000240	RDP17	004316	SC	033174
LISTAD	001332	OVWN12	002356	PR6	= 000300	RDP18	004336	SCOPE	= 000004
MAKEUP	014476	OVWN13	002376	PR7	= 000340	RDP2	003736	SCORE	014614
MARKX	042637	OVWN14	002416	PS	= 177776	RDP3	003756	SC11	034026
MCPEMY	030322	OVWN15	002436	PSEUDO	005322	RDP4	003776	SC12	034136
MESG1	041776	OVWN16	002456	PSW	= 177776	RDP5	004016	SC13	034206
MESG10	042142	OVWN17	002476	PUNSAF	017644	RDP6	004036	SC3	033244
MESG11	042207	CJWN18	002516	PWRVEC	000024	RDP7	004056	SC4	033250
MESG12	042272	OVWN2	002116	QCNT	035520	RDP8	004076	SC5	033262
MESG13	042310	OVWN3	002136	QDRIV	043326	RDP9	004116	SC6	033456
MESG14	042356	OVWN4	002156	QDRV0	035612	RD.ADR	035002	SC6A	033572
MESG15	042402	OVWN5	002176	QDRV1	035632	RD.RM	034756	SC7	033720
MESG16	042443	OVWN6	002216	QDRV2	035652	RD.RM1	035000	SC8	033776
MESG17	042465	OVWN7	002236	QDRV3	035672	RD.RM2	035124	SEARCH=	000131
MESG18	042546	OVWN8	002256	QDRV4	035712	RD.RM3	035130	SECLMT	001370
MESG19	042764	OVWN9	002276	QDRV5	035732	RD.RM4	035134	SECOND	001350
MESG2	042006	OVWP0	002536	QDRV6	035752	RD.WRD	035004	SEEK	= 000105
MESG20	043004	OVWP1	002556	QDRV7	035772	READIN-	000121	SEEKFG	030266
MESG21	043044	OVWP10	002776	QINPT	035530	RECAL	= 000107	SELDRV=	000145
MESG3	042021	OVWP11	003016	QOUTPT	035550	RELSE	= 000113	SELFX	042630
MESG4	042045	OVWP12	003036	QSTART	035570	REPLZ	022210	SELF0	004356
MESG5	042651	OVWP13	003056	QSTOP	035572	RESREG=	104413	SELF1	004360
MESG6	042664	OVWP14	003076	QTERM	= 036012	RESVEC=	000010	SELF10	004402
MESG7	042670	OVWP15	003116	QUES	042762	RMADR	030324	SELF11	004404
MESG8	042073	OVWP16	003136	QUOTM	042644	RMAS	= 000016	SELF12	004406
MESG9	042106	OVWP17	003156	RDCHR	= 104410	RMBA	= 000004	SELF13	004410
MINUTE	001346	OVWP18	003176	RDDAT	= 000171	RMCS1	= 000000	SELF14	004412
MOD00	007136	OVWP2	002576	RDHD	= 000173	RMCS2	= 000010	SELF15	004414
MOD11	007444	OVWP3	002616	RDLIN	= 104411	RMDA	= 000006	SELF16	004416
MOD12	007624	OVWP4	002636	RDN0	003216	RMDB	= 000022	SELF17	004420
MOD21	007162	OVWP5	002656	RDN1	003236	RMDC	= 000034	SELF18	004422
MOD22	007430	OVWP6	002676	RDN10	003456	RMDS	= 000012	SELF2	004362
MOD23	007364	OVWP7	002716	RDN11	003476	RMDT	= 000026	SELF3	004364
MOD30	007456	OVWP8	002736	RDN12	003516	RMEC1	= 000044	SELF4	004366
MONTR	007106	OVWP9	002756	RDN13	003536	RMEC2	= 000046	SELF5	004370
MRMCS1	036450	PACK	001324	RDN14	003556	RMERRS	030166	SELF6	004372
MRMVEC	036457	PARER	020430	RDN15	003576	RMER1	= 000014	SELF7	004374
MXWINDW	030332	PCLOCK	001314	RDN16	003616	RMER2	= 000042	SELF8	004376
M.DP10	022032	PFECH	024434	RDN17	003636	RMHR	= 000036	SELF9	004400
M.DP40	022070	PFECH1	024444	RDN18	003656	RMINIT	030334	SETFMT=	000143
M.DP41	022124	PFECH2	024526	RDN2	003256	RMLA	000020	SETVEC	007074
M.DP42	022134	PFECH3	024560	RDN3	003276	RMMR1	= 000024	SET.IE	035446
M.DP44	022166	PFECH4	024570	RDN4	003316	RMMR2	= 000040	SIXTEE	001352
M.DP50	022200	PFTSTN	024574	RDN5	003336	RMOF	= 000032	SIZMEM	007030

SKIER 020510  
 SLASH 042756  
 JPATH 016620  
 SPOTX 010636  
 SRCHWT 030250  
 STACK = 001100  
 STARS 043022  
 STARSC 001360  
 START 005566  
 START1 005604  
 START2 005622  
 START3 005634  
 STATIN 001322  
 STKLMT= 177774  
 STNDAT 005262  
 STO 034434  
 STO1 034470  
 STO2 034564  
 STO3 034614  
 STO5 034640  
 STO6 034646  
 STO7 034704  
 STO8 034734  
 STO9 034744  
 SVRH70 035330  
 SWR 001154  
 SWREG 000176  
 SWTIM 017674  
 SWO = 000001  
 SWO0 = 000001  
 SWO1 = 000002  
 SWO2 = 000004  
 SWO3 = 000010  
 SWO4 = 000020  
 SWO5 = 000040  
 SWO6 = 000100  
 SWO7 = 000200  
 SWO8 = 000400  
 SWO9 = 001000  
 SW1 = 000002  
 SW10 = 002000  
 SW11 = 004000  
 SW12 = 010000  
 SW13 = 020000  
 SW14 = 040000  
 SW15 = 100000  
 SW2 = 000004  
 SW3 = 000010  
 SW4 = 000020  
 SW5 = 000040  
 SW6 = 000100  
 SW7 = 000200  
 SW8 = 000400  
 SW9 = 001000  
 SYSADR 002014  
 TAB 042635  
 TABL EX 002054

TAB.XV= 001114  
 TBITIVE= 000014  
 TD 033024  
 TIMER 030270  
 TKVEC = 000060  
 TPVEC = 000064  
 TRAPVE= 000034  
 TRFER 020500  
 TRKLMT 001372  
 TRNSWT 030246  
 TRTVEC= 000014  
 TSTNM 001340  
 TST1 011020  
 TST10 015654  
 TST11 016342  
 TST2 011374  
 TST3 011650  
 TST4 012274  
 TST5 012772  
 TST6 013344  
 TST7 015140  
 TYPDS = 104405  
 TYPE = 104401  
 TYPOC = 104402  
 TYPON = 104404  
 TYPOS = 104403  
 TYPRI4 022340  
 UCPAR 017654  
 ULDFLG 030254  
 UNIT 001330  
 UNSAF 020530  
 WCFER 020520  
 WCKD = 000151  
 WCKER 020310  
 WCKHD = 000153  
 WLEER 020450  
 WRTDAT= 000161  
 WRTHD = 000163  
 WRT.AD 035226  
 WRT.RM 035136  
 WRT.R1 035222  
 WRT.R2 035314  
 WRT.R3 035320  
 WRT.R4 035324  
 WRT.R5 035326  
 WRT.WD 035224  
 XEND2 017146  
 XFATL 043243  
 XPASS1 010054  
 XPASS2 012460  
 XXDP 001404  
 Y 042741  
 \$APTHD 001100  
 \$ATYC 025156  
 \$ATY1 025132  
 \$ATY3 025140  
 \$ATY4 025150

\$AUTOB 001150  
 \$BASE 001266  
 \$BDADR 001136  
 \$BDDAT 001142  
 \$BELL 001202  
 \$BUF = 000006  
 \$CDW1 001272  
 \$CDW2 001274  
 \$CHARC 025126  
 \$CKSWR 025242  
 \$CLR.T 023534  
 \$CMTAG 001114  
 \$CM3 = 000000  
 \$CM4 = 000001  
 \$CNTLC 023452  
 \$CNTLG 026661  
 \$CNTLU 026654  
 \$COMND= 000002  
 \$CPUOP 001240  
 \$CRLF 001207  
 \$CYL = 000012  
 \$DBLK 026232  
 \$DB2D 027004  
 \$DB20 027200  
 \$DECVL 027164  
 \$DEVCT 001222  
 \$EVM 001270  
 \$DOAGN 023554  
 \$DSPLY 022366  
 \$DTBL 026222  
 \$EMTAB= 000022  
 \$ENDAD 023544  
 \$ENDCT 023512  
 \$ENV 001232  
 \$ENVM 001233  
 \$EOP 023456  
 \$EOPCT 023504  
 \$ERFLG 001117  
 \$ERMAX 001131  
 \$ERROR 023662  
 \$ERRPC 001132  
 \$ERRTB 005362  
 \$ERRTY 024256  
 \$ERTTL 001126  
 \$ESCAP 001200  
 \$ETABL 001232  
 \$ETEND 001276  
 \$FATAL 001214  
 \$FFLG 025376  
 \$FILLC 001172  
 \$FILLS 001171  
 \$FMT = 000001  
 \$GAP = 000016  
 \$GDADR 001134  
 \$GDDAT 001140  
 \$GET42 023516  
 \$GTSWR 026312

\$HD = 000000  
 \$HIBTS 001100  
 \$ICNT 001120  
 \$ILLUP 025552  
 \$INTAG 001151  
 \$ITEMB 001130  
 \$LF 001210  
 \$LFLG 025375  
 \$LKCSB 001304  
 \$LKCSR 001302  
 \$LKS 001310  
 \$LLVEC 001312  
 \$LOOP 023612  
 \$LPADR 001122  
 \$LPERR 001124  
 \$LPVEC 001306  
 \$LSTAD 030076  
 \$MADR1 001244  
 \$MADR2 001250  
 \$MADR3 001254  
 \$MADR4 001260  
 \$MAIL 001212  
 \$MAMS1 001242  
 \$MAMS2 001246  
 \$MAMS3 001252  
 \$MAMS4 001256  
 \$MBADR 001102  
 \$MFLG 025374  
 \$MNEW 026677  
 \$MSGAD 001226  
 \$MSGLG 001230  
 \$MSGTY 001212  
 \$MSWR 026666  
 \$MTYP1 001243  
 \$MTYP2 001247  
 \$MTYP3 001253  
 \$MTYP4 001257  
 \$MXCNT 027744  
 \$NULL 001170  
 \$NWTST= 000000  
 \$OCNT 026012  
 \$OCTVL 027302  
 \$OMODE 026014  
 \$OVER 027730  
 \$PASS 001220  
 \$PASTM 001106  
 \$PHYDR= 000015  
 \$POWER 025560  
 \$PSEL = 000003  
 \$PWRDN 025400  
 \$PWRMG 025534  
 \$PWRUP 025452  
 \$QUES 001206  
 \$RDCHR 026524  
 \$RDLIN 023150  
 \$RDSZ = 000001  
 \$RESRE 026746

\$RMADR 001276  
 \$RMAS = 000036  
 \$RMBA = 000024  
 \$RMCS1= 000020  
 \$RMCS2= 000030  
 \$RMDA = 000026  
 \$RMDB = 000042  
 \$RMDC = 000054  
 \$RMD5 = 000032  
 \$RMDT = 000046  
 \$RMEC1= 000064  
 \$RMEC2= 000066  
 \$RMER1= 000034  
 \$RMER2= 000062  
 \$RMHR = 000056  
 \$RMLA = 000040  
 \$RMMR1= 000044  
 \$RMMR2= 000060  
 \$RMOF = 000052  
 \$RMSN = 000050  
 \$RMVEC 001300  
 \$RMWC = 000022  
 \$RTNAD 023614  
 \$RTRN 023610  
 \$SAVRE 026710  
 \$SAVR6 025556  
 \$SB2D 022674  
 \$SB20 022724  
 \$SCOPE 027320  
 \$SEC = 000010  
 \$SETUP= 000137  
 \$SIZE 027746  
 \$STUP = 177777  
 \$SUPRS 022300  
 \$SVLAD 027674  
 \$SVPC = 000214  
 \$SWR = 177600  
 \$SWREG 001234  
 \$SWRMK= 000000  
 \$SYSNM= 000014  
 \$STATUS= 000016  
 \$TBIT 023616  
 \$TERM = 000032  
 \$TESTN 001216  
 \$TIME 021430  
 \$TIMES 001176  
 \$TKB 001162  
 \$TKINT 022754  
 \$TKS 001160  
 \$TKSRV 023004  
 \$TMPO 001174  
 \$TN - 000012  
 \$TNPWR 027114  
 \$TPB 001166  
 \$TPFLG 001173  
 \$TPS 001164  
 \$TRAP 030100

\$TRAP2 030122	\$TTYIN 023426	\$TYPOC 025614	\$USWR 001236	\$XON = 000021
\$TRK = 000011	\$TYPDS 026016	\$TYPON 025630	\$VECT1 001262	\$XTSTR 027336
\$TRP = 000015	\$TYPE 024576	\$TYPOS 025570	\$VECT2 001264	\$SGE14= 000001
\$TRPAD 030134	\$TYPEC 025010	\$UNIT 001224	\$WRDM = 000004	\$OFILL 026013
\$STM 001104	\$TYPEX 025130	\$UNITM 001110	\$XOFF = 000023	.\$X = 001100
\$STM 001116				

. ABS. 043456 000  
000000 001  
ERRORS DETECTED: 0

VIRTUAL MEMORY USED: 60416 WORDS ( 236 PAGES)  
DYNAMIC MEMORY AVAILABLE FOR 70 PAGES  
CZRMTB.BIN,CZRMTB/C=CZRMTB.DOC,CZRMTB,SYSMAC/M





SMTYP3	6-0#																			
SMTYP4	6-0#																			
SMXCNT	22-1	22-1	22-1	22-1#																
SNULL	6-0#	13-1	13-1	13-1																
SNWTS	9-481#	9-554#	9-610#	9-693#	9-807#	9-896#	9-<26#	9-=24#	9->26#											
SOCNT	16-1#	16-1*	16-1*																	
SOCTVL	21-1	21-1#																		
SOMODE	16-1	16-1#	16-1*	16-1*	16-1*	16-1*														
SOVER	22-1	22-1	22-1	22-1	22-1#															
SPASS	6-0#	9-31*	10-1	10-1	10-1*	10-1*	22-1	22-1	22-1											
SPASTM	5-11#																			
SPHYDR	7-0#	9-235*	9-236*																	
SPOWER	15-1	15-1#																		
SPSEL	7-0#																			
SPWRDN	9-31	15-1	15-1#																	
SPWRMG	15-1#																			
SPWR:JP	15-1	15-1#																		
SQUES	6-0#	9-124	11-1	11-1	13-1	13-1	18-1													
SR2A	24-1																			
SRDCHR	18-1#	24-1	24-1																	
SRDDEC	24-1																			
SRDLIN	9-H84#	24-1	24-1																	
SRDOCT	24-1																			
SRDSZ	18-1	18-1#																		
SRESRE	19-1#	24-1																		
SRHEXT	25-164	25-193	25-<16																	
SRMADR	7-0#	9-73	9-159	9-189*	9-192	9-196	26-14	26-32	26-36											
SRMAS	4-72#	4-73																		
SRMBA	4-67#	4-68	9-C27	9-C37	9-C52															
SRMCS1	4-65#	4-66	9-a51	9-a53	9-C07															
SRMCS2	4-69#	4-70	9-A30	9-C09																
SRMDA	4-68#	4-69	9-975	9-:10	9-<01	9-=64	9-=92													
SRMDB	4-74#	4-75																		
SRMDC	4-79#	4-80																		
SRMDS	4-70#	4-71	9-a55	9-A33	9-A62															
SRMDT	4-76#	4-77																		
SRMEC1	4-83#	4-84																		
SRMEC2	4-84#																			
SRMER1	4-71#	4-72	9-A36	9-A39	9-A42	9-A45	9-A48	9-A51	9-A54	9-A57	9-A60	9-A65	9-A68	9-A95						
	9-C11																			
SRMER2	4-82#	4-83	9-A71	9-A73	9-C13															
SRMHR	4-80#	4-81																		
SRMLA	4-73#	4-74																		
SRMMR1	4-75#	4-76																		
SRMMR2	4-81#	4-82																		
SRMOF	4-78#	4-79																		
SRMSN	4-77#	4-78																		
SRMVEC	7-0#	9-74	9-190*	9-193	9-197	26-23														
SRMVC	4-66#	4-67	9-973	9-976	9-:08	9-:11	9-<09	9-<11	9-=62	9-=65	9-=90	9-=93	9-r2*	9-(40						
SRTNAD	10-1#																			
SRTRN	9-31	9-31*	9-31*	10-1	10-1#															
SSAVR6	15-1	15-1#	15-1*	15-1*	15-1*															
SSAVRE	19-1#	24-1	24-1																	
SSB2D	9-D25	9-D74	9-D79	9-D84	9-H10#															
SSB2O	9-D09	9-H27#																		
SSCGPE	9-31	22-1#																		
SSEC	7-0#	9-356*	9-391	9-393*	9-560*	9-648*	9-658*	9-659	9-661*	9-909*	9-952*	9-975*	9-984*	9-:10*						



































SSCMRE	5-250#													
SSCMTM	5-250#	6-0												
SSESCA	4-58#													
SSNEWT	4-58#	9-481	9-554	9-610	9-693	9-807	9-896	9-<26	9-=24	9->26				
SSSET	24-1	24-1	24-1	24-1	24-1	24-1	24-1	24-1	24-1	24-1	24-1	24-1#	24-2	
SSSETM	9-31	9-31#												
SSSETU	9-31	9-31#												
SSSKIP	4-58#													
.SACT1	4-47#	5-8												
.SAPT8	4-50#	6-0	6-0#											
.SAPTH	4-50#	5-11												
.SAPTY	4-50#	14-1												
.SCATC	4-48#	5-1												
.SCMTA	4-48#	5-250												
.SDB2D	4-49#	20-1												
.SDB2O	4-49#	21-1												
.SEOP	4-50#	10-1												
.SERRO	4-48#	11-1												
.SERRT	4-48#	12-1												
.SPOWE	4-50#	15-1												
.SREAD	4-47#	18-1												
.SSAVE	4-49#	19-1												
.SSCOP	4-50#	22-1												
.SSIZE	4-49#	23-1												
.STRAP	4-49#	24-1												
.STYPD	4-48#	17-1												
.STYPE	4-47#	13-1												
.STYPO	4-48#	16-1												
.EQUAT	4-47#	4-58												
.HEADE	4-47#	4-54												
.SETUP	4-47#	4-111												
.SWRHI	4-47#	4-55												
.SWRLO	4-47#	4-55#	4-56											
CKCHR	4-8#	9-673	9-681											
CKDIG	4-18#													
CKNUM	4-31#													
COMMEN	4-58#													
ENDCOM	4-58#													
ERRCAL	24-4#	25-772	25-830	25-832	25-:18	25-:77								
ERROR	4-58#	9-A79	9-A80	9-A81	9-A82	9-B94	9-B95	9-B96	9-B97	22-1	26-43			
ESCAPE	4-58#													
GETPRI	4-58#	10-1	23-1											
GETSWR	4-58#	9-36	9-36#											
MORETA	5-14#	6-0												
MULT	4-58#													
NEWTST	4-58#	9-481	9-554	9-610	9-693	9-807	9-896	9-<26	9-=24	9->26				
POP	4-58#	9-:83	9-<16	9-@39	9-E47	14-1	14-1	15-1	15-1	17-1	19-1			
PUSH	4-58#	9-:40	9-:99	9-?89	9-E40	14-1	14-1	14-1	15-1	15-1	17-1	19-1		
REPORT	4-58#													
SETPRI	4-58#													
SETTRA	24-1	24-1	24-1	24-1	24-1	24-1	24-1	24-1	24-1	24-1	24-1	24-1#	24-2	
SETUP	4-58#	9-31												
SKIP	4-58#													
SLASH	4-58#													
STARS	4-58#	5-8	5-11	5-11	5-11	6-0	6-0	6-0	9-481	9-554	9-610	9-693	9-807	9-896
	9-<26	9-=24	9->26	10-1	11-1	12-1	13-1	14-1	15-1	15-1	16-1	17-1	18-1	18-1

	18-1	19-1	20-1	21-1	22-1	23-1	24-1	25-15
SWRSU	4-58#	9-31	9-31#					
TRMTRP	24-1#	24-3						
TYPBIN	4-58#							
TYPDEC	4-58#	9-211						
TYPNAM	4-58#	9-36						
TYPNUM	4-58#							
TYPOCS	4-58#	9-166						
TYPOCT	4-58#	12-1	12-1	18-1				
TYPTXT	4-58#	9-6	9-50	9-61	9-67	9-68		