

RABO

PDP-11 UDA DRV FMTR AH-S837B-MC
CZUDEBO FICHE 1 OF 1

SEP 1982
COPYRIGHT © 81-82
MADE IN USA

00000000

.REM ~

IDENTIFICATION

PRODUCT CODE: AC-S836B-MC
PRODUCT NAME: CZUDEBO UDA DISK FORMATTER
PRODUCT DATE: 14-APR-82
MAINTAINER: DIAGNOSTIC ENGINEERING
AUTHOR: DALE KECK

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS DOCUMENT.

NO RESPONSIBILITY IS ASSUMED FOR THE USE OR RELIABILITY OF SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL OR ITS AFFILIATED COMPANIES.

COPYRIGHT (C) 1981,1982 BY DIGITAL EQUIPMENT CORPORATION

THE FOLLOWING ARE TRADEMARKS OF DIGITAL EQUIPMENT CORPORATION:

DIGITAL
DEC

PDP
DECUS

UNIBUS
DECTAPE

MASSBUS

TABLE OF CONTENTS

	Page
1.0 GENERAL INFORMATION	3
1.1 PROGRAM ABSTRACT	3
1.2 SYSTEM REQUIREMENTS	4
2.0 OPERATING INSTRUCTIONS	4
2.1 COMMANDS	4
2.2 SWITCHES	5
2.3 FLAGS	6
2.4 HARDWARE QUESTIONS	7
2.5 SOFTWARE QUESTIONS	8
2.6 MANUAL INTERVENTION QUESTIONS	9
2.7 EXTENDED P-TABLE DIALOGUE	9
2.8 QUICK STARTUP PROCEDURE	12
3.0 ERROR INFORMATION	14
3.1 TYPES OF ERROR MESSAGES	14
3.2 SPECIFIC ERROR MESSAGES	15
3.2.1 HOST PROGRAM ERROR MESSAGES	15
3.2.2 DUP PROGRAM ERROR MESSAGES	22
4.0 PERFORMANCE AND PROGRESS REPORTS	25
5.0 TEST SUMMARIES	26

1.0 GENERAL INFORMATION

1.1 PROGRAM ABSTRACT

This program will format any disk drive connected to a UDA-50 disk controller. There are three ways to format a disk with this program:

1. Reformat - Format the disk with the bad sector information that was written onto the disk at the factory. This is the normal way to format a disk.
2. Reconstruct - Format the disk without using any bad sector information. This should be used only when the bad sector information has been destroyed or for some reason can no longer be read from the disk. This method may also be specified in the disk drive's maintenance manual for special cases (eg. changing an RM/RAM80 spare HDA from RM80 format to RA80 format).
3. Restore - Format the disk using bad sector information obtained from a disk file on the XXDP+ system load device. This method is provided for use by manufacturing. No files are provided, nor any method of obtaining the files, at this time.

The format operation is performed by a Diagnostic Utilities and Protocol (DUP) program loaded into the UDA-50 disk controller. The host program simply downline loads the DUP program in the UDA-50 and monitors its execution. The DUP program obtains parameters from the host program (eg. drive number and format mode) and requests the host program to print error and summary messages. The DUP program is also commonly called a "diagnostic machine" (DM) program.

This program can only format in one mode at a time. In RESTORE mode, only one disk may be selected in the hardware questions or an error message will result and the program will stop.

In REFORMAT and RECONSTRUCT modes, any number of disk drives may be selected. A UDA-50 can only format one disk at a time, so each disk on a UDA-50 will be selected sequentially. If the disk drives to be formatted are connected to different UDA-50s, all UDA-50s will be run simultaneously. For example, lets assume three units are selected for formatting in the hardware questions, units 1 and 2 are connected to one UDA-50 and unit 3 is connected to a different UDA-50 (Unibus addresses are different). This program will automatically start simultaneous format operations on units 1 and 3. When unit 1 finishes (or errors), unit 2 will be started. After units 2 and 3 are finished, the program stops.

This program will stop after each pass (all units formatted once). There is no need to specify a PASS switch on the command line to the Diagnostic Runtime Services (eg. START/PASS:1).

Special provisions have been made to allow this program to run under an APT system in manufacturing. This system does not allow questions to be asked of an operator. Such a condition also exists under XXDP+ when the UAM flag is set. In this condition, only reformat mode can be selected. Selecting RECONSTRUCT or RESTORE will result in an error. Also, a date of 1-JAN-70 will be written on the disk.

1.2 SYSTEM REQUIREMENTS

This program was designed using the PDP-11 Diagnostic Runtime Services revision C. Run time environments are determined by the Runtime Services and may change as new versions of the Services are developed. The initial version will require the following:

PDP-11 Unibus processor
28K words of memory (minimum)
Console terminal
XXDP+ load media containing this program
One or more UDA-50 subsystems

A system clock - either type L or P - will be used to time the DUP program and report runtime, if available. If no system clock is available, this program cannot detect a hung DUP program.

2.0 OPERATING INSTRUCTIONS

This section contains a brief description of the Runtime Services. For detailed information, refer to the XXDP+ User's Manual (CHQUS).

2.1 COMMANDS

There are eleven legal commands for the Diagnostic Runtime Services (Supervisor). This section lists the commands and gives a very brief description of them. The XXDP+ User's Manual has more details.

COMMAND	EFFECT
START	Start the diagnostic from an initial state
RESTART	Start the diagnostic without initializing
CONTINUE	Continue at test that was interrupted (after ^C)
PROCEED	Continue from an error halt
EXIT	Return to XXDP+ Monitor (XXDP+ OPERATION ONLY!)
ADD	Activate a unit for testing (all units are considered to be active at start time)
DROP	Deactivate a unit
PRINT	Print statistical information (see section 4.0)

DISPLAY	Type a list of all device information
FLAGS	Type the state of all flags (see section 2.3)
ZFLAGS	Clear all flags (see section 2.3)

A command can be recognized by the first three characters. So you may, for example, type "STA" instead of "START".

2.2 SWITCHES

There are several switches which are used to modify supervisor operation. These switches are appended to the legal commands. All of the legal switches are tabulated below with a brief description of each. In the descriptions below, a decimal number is designated by "DDDDD".

SWITCH	EFFECT
/TESTS:LIST	Execute only those tests specified in the list. List is a string of test numbers, for example - /TESTS:1:5:7-10. This list will cause tests 1,5,7,8,9,10 to be run. All other tests will not be run.
/PASS:DDDDD	Execute DDDDD passes (DDDDD = 1 to 64000)
/FLAGS:FLGS	Set specified flags. Flags are described in section 2.3.
/EOP:DDDDD	Report end of pass message after every DDDDD passes only. (DDDDD = 1 to 64000)
/UNITS:LIST	TEST/ADD/DROP only those units specified in the list. List example - /UNITS:0:5:10-12 use units 0,5,10,11,12 (unit numbers = 0-63).

Example of switch usage:

START/TESTS:1-5/PASS:1000/EOP:100

The effect of this command will be: 1) tests 1 through 5 will be executed, 2) all units will tested 1000 times and 3) the end of pass messages will be printed after each 100 passes only. A switch can be recognized by the first three characters. You may, for example, type "/TES:1-5" instead of "/TESTS:1-5".

Below is a table that specifies which switches can be used by each command.

	TESTS	PASS	FLAGS	EOP	UNITS
START	X	X	X	X	X
RESTART	X	X	X	X	X
CONTINUE		X	X	X	
PROCEED			X		
DROP					X
ADD					X
PRINT					
DISPLAY					X
FLAGS					
ZFLAGS					
EXIT					

2.3 FLAGS

Flags are used to set up certain operational parameters such as looping on error. All flags are cleared at startup and remain cleared until explicitly set using the flags switch. Flags are also cleared after a START or RESTART command unless set using the flag switch. The ZFLAGS command may also be used to clear all flags. With the exception of the START, RESTART and ZFLAGS commands, no commands affect the state of the flags; they remain set or cleared as specified by the last flag switch.

FLAG	EFFECT
HOE	Halt on error - control is returned to runtime services command mode
LOE	Loop on error
IER*	Inhibit all error reports
IBE*	Inhibit all error reports except first level (first level contains error type, number, PC, test and unit)
IXE*	Inhibit extended error reports (those called by PRINTX macro's)
PRI	Direct messages to line printer
PNT	Print test number as test executes
BOE	'BELL' on error
UAM	Unattended mode (no manual intervention)
IDU	Inhibit program dropping of units
LOT	Loop on test

*Error messages are described in section 3.1

See the XXDP+ User's Manual for more details on flags. You may specify more than one flag with the FLAG switch. For example, to cause the program to loop on error, inhibit error reports and type a 'BELL' on error, you may use the following string:

/FLAGS:LOE:IER:BOE

2.4 HARDWARE QUESTIONS

When a diagnostic is STARTed, the Runtime Services will prompt the user for hardware information by typing "[CHANGE HW (L) ?]". When you answer this question with a "Y", the Runtime Services will ask for the number of units (in decimal). You will then be asked the following questions for each unit. When you answer this question with an "N", the Runtime Services will use the answers built into the program by the SETUP utility (see chapter 6 of the XXDP+ User's Manual). If you have never run the SETUP utility on this program file, the default values listed below (just before the question mark) will be used.

UNIBUS ADDRESS OF UDA (0) 172150 ?

Answer with the address of the UDAIP register of one UDA as addressed by the processor with memory management turned off (i.e., an even 16-bit address in the range of 160000 to 177774).

VECTOR (0) 154 ?

Answer with the interrupt vector address of the UDA. A vector address in the range of 4 to 774 may be specified. The UDA does not have a vector "hard wired" to it, so any vector not being used by this program and XXDP+ may be used.

BR LEVEL (D) 5 ?

Answer with the interrupt priority used by the UDA. Levels 4 to 7 are accepted. This level must match the level "hard wired" in the UDA by the priority plug.

UNIBUS BURST RATE (D) 63 ?

The UDA allows the ability to control the maximum number of words transferred across the UNIBUS each time the UDA becomes master. The default answer of 63 will allow for the fastest execution of this diagnostic program. You may answer with the value your operating system uses or use zero which will tell the UDA to supply a value that should work on any system. A decimal number in the range of 0 to 63 may be specified and all values should work on any system. A larger value will allow for a faster running program. The value will be passed directly to the UDA during initialization.

DRIVE NUMBER (D) 0 ?

Answer with the drive number of the drive you wish to test. This is the number which appears on the "unit plug" on the front of the disk drive. On a multi-unit drive, each sub-unit number on the drive must be tested as a separate unit to completely test the drive. A maximum of eight logical drives may be tested on one UDA at a time (UDA configuration limit).

2.5 SOFTWARE QUESTIONS

After you have answered the hardware questions or after a RESTART or CONTINUE command, the Runtime Services will ask for software parameters. You will be prompted by "CHANGE SW (L) ?" If you wish to change any parameters, answer by typing "Y". The software questions and the default values are described in the next paragraphs. You may change the default values with the SETUP utility.

REFORMAT USING EXISTING BAD SECTOR INFORMATION (L) Y ?

If this question is answered "YES", then the user wants the REFORMAT mode format operation. REFORMAT mode will use the bad sector information that is already on the disk. Any other mode will destroy this information. If this question is answered "NO", the following will be asked to be sure the user knows what he is doing.

NOT USING EXISTING INFORMATION WILL DESTROY THE FACTORY BAD SECTOR INFORMATION ON THE DISK.

AGAIN - REFORMAT USING EXISTING BAD SECTOR INFORMATION (L) Y ?

This is asked to verify that the user does want to destroy the bad sector information on the disk and run another format mode. If this is answered "YES", then the user wants the REFORMAT mode format operation and use the existing bad block information. If again answered "NO", the following question will be asked.

RECONSTRUCT BAD SECTOR INFORMATION (L) Y ?

A "YES" answer will cause a reconstruct mode format operation. If answered "NO", the following will be asked to verify the user really wants the restore mode format.

DO YOU HAVE A FILE ON THE SYSTEM LOAD DEVICE
CONTAINING BAD SECTOR INFORMATION (L) N ?

Note that such a file will not be provided with the diagnostic and this mode is not recommended. The format will begin only on a "YES" answer. Otherwise the following message will be printed and the program will abort.

YOU CANNOT PROCEED WITHOUT SUCH A FILE.
RESTART PROGRAM AND SELECT TO REFORMAT OR RECONSTRUCT DISK.

2.6 MANUAL INTERVENTION QUESTIONS

Once the program is started, the date will be asked for in the format used by the XXDP+ system.

ENTER DATE AS DD-MMM-YY (A) 1-JAN-70 :

The default is provided so the user need not supply the date. The date question will normally only be asked one time. If an improper answer is typed, "INPUT ERROR" is printed and the question is asked again. A two or four digit year may be typed. A four digit year must be 1900 or greater (eg. 14-APR-1982). If only two digits are typed, the year is determined as follows:

1. If the number typed is 70 or greater, a 19 is prefixed. Eg., 1-JAN-70 translates to year 1970 and 25-DEC-99 translates to year 1999.
2. If the number typed is less than 70, a 20 is prefixed. Eg.. 1-APR-21 is translated to year 2021.

If RECONSTRUCT mode is selected, the following question will be asked for each disk to be formatted before the format operation begins.

SERIAL NUMBER FOR UNIT xx UDA AT xxxxxxx DRIVE xxx
(A) ?

A decimal number in the range of 0 to 18446744073709551615 must be entered (no default).

If RESTORE mode is selected, the following question will be asked.

NAME OF FILE CONTAINING BAD SECTOR INFORMATION FOR
DISK TO BE FORMATTED (A) ?

If the file named does not exist on the system load device, the program will abort back to the XXDP+ prompt after printing an error message.

2.7 EXTENDED P-TABLE DIALOGUE

When you answer the hardware questions, you are building entries in a table that describes the devices under test. The simplest way to build this table is to answer all questions for each unit to be tested. If you have a multiplexed device such as a mass storage controller with several drives or a communication device with several lines, this becomes tedious since most of the answers are repetitious.

To illustrate a more efficient method, suppose you are testing a fictional device, the XY11. Suppose this device consists of a control module with eight units (sub-devices) attached to it. These units are described by the octal numbers 0 through 7. There is one hardware parameter that can vary among units called the Q-factor. This Q-factor may be 0 or 1. Below is a simple way to build a table for one XY11 with eight units.

```
# UNITS (D) ? 8<CR>

UNIT 1
CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 0<CR>
Q-FACTOR (0) 0 ? 1<CR>

UNIT 2
CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 1<CR>
Q-FACTOR (0) 1 ? 0<CR>

UNIT 3
CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 2<CR>
Q-FACTOR (0) 0 ? <CR>

UNIT 4
CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 3<CR>
Q-FACTOR (0) 0 ? <CR>

UNIT 5
CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 4<CR>
Q-FACTOR (0) 0 ? <CR>

UNIT 6
CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 5<CR>
Q-FACTOR (0) 0 ? <CR>

UNIT 7
CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 6<CR>
Q-FACTOR (0) 0 ? 1<CR>

UNIT 8
CSR ADDRESS (0) 160000<CR>
SUB-DEVICE # (0) ? 7<CR>
Q-FACTOR (0) 1 ? <CR>
```

Notice that the default value for the Q-factor changes when a non-default response is given. Be careful when specifying multiple units!

As you can see from the above example, the hardware parameters do not vary significantly from unit to unit. The procedure shown is not very efficient.

The Runtime Services can take multiple unit specifications however.
Let's build the same table using the multiple specification feature.

UNITS (D) ? 8<CR>

UNIT 1

CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 0,1<CR>
Q-FACTOR (0) 0 ? 1,0<CR>

UNIT 3

CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 2-5<CR>
Q-FACTOR (0) 0 ? 0<CR>

UNIT 7

CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 6,7<CR>
Q-FACTOR (0) 0 ? 1<CR>

As you can see in the above dialogue, the runtime services will build as many entries as it can with the information given in any one pass through the questions. In the first pass, two entries are built since two sub-devices and q-factors were specified. The Services assume that the CSR address is 160000 for both since it was specified only once. In the second pass, four entries were built. This is because four sub-devices were specified. The "-" construct tells the Runtime Services to increment the data from the first number to the second. In this case, sub-devices 2, 3, 4 and 5 were specified. (If the sub-device were specified by addresses, the increment would be by 2 since addresses must be on an even boundary.) The CSR addresses and Q-factors for the four entries are assumed to be 160000 and 0 respectively since they were only specified once. The last two units are specified in the third pass.

The whole process could have been accomplished in one pass as shown below.

UNITS (D) ? 8<CR>

UNIT 1

CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 0-7<CR>
Q-FACTOR (0) 0 ? 0,1,0...,1,1<CR>

As you can see from this example, null replies (commas enclosing a null field) tell the Runtime Services to repeat the last reply.

2.8 QUICK START-UP PROCEDURE

To start-up this program:

1. Boot XXDP+
2. Give the date and answer the LSI and 50HZ (if there is a clock) questions
3. Type 'R ZUDEBO'
4. Type "START"
5. Answer the "CHANGE HW" question with "Y"
6. Answer all the hardware questions
7. Answer the "CHANGE SW" question with "N"

When you follow this procedure you will be using only the defaults for flags and software parameters. These defaults are described in sections 2.3 and 2.5.

Sample of terminal dialogue to test two disks on one UDA-50:

```
DR>STA  
CHANGE HW (L) ? Y  
# UNITS (D) ? 2  
UNIT 0  
UNIBUS ADDRESS OF UDA (0) 172150 ?  
VECTOR (0) 154 ?  
BR LEVEL (D) 5 ?  
UNIBUS BURST RATE (D) 63 ?  
DRIVE NUMBER (D) 0 ? 0,1  
CHANGE SW (L) ? N
```

ENTER DATE AS DD-MMM-YY (A) 1-JAN-70 ? 14-APR-82

UNIT 0 UDA AT 172150 DRIVE 0 RUNTIME 0:12:20

Format completed

2 Revectored LBNS

2 Primary revectored LBNS

0 Secondary/tertiary revectored LBNS

0 Bad blocks in the RCT area due to data errors

0 Bad blocks in the DBN area due to data errors

0 Bad blocks in the XBN area due to data errors

2 Blocks retried on the check pass

FCT used successfully

UNIT 1 UDA AT 172150 DRIVE 1 RUNTIME 0:25:18

Format completed

6 Revectored LBNS

5 Primary revectored LBNS

1 Secondary/tertiary revectored LBNS

0 Bad blocks in the RCT area due to data errors

0 Bad blocks in the DBN area due to data errors

0 Bad blocks in the XBN area due to data errors

4 Blocks retried on the check pass

FCT used successfully

CZUDE EOP 1

0 CUMULATIVE ERRORS

DR>

Sample of terminal dialogue going through software questions.
Only one disk is being tested.

DR>STA

CHANGE HW (L) ? N

CHANGE SW (L) ? Y

REFORMAT USING EXISTING BAD SECTOR INFORMATION (L) Y ? Y

ENTER DATE AS DD-MMM-YY (A) 1-JAN-70 ? 14-APR-82

RUNTIME 0:12:45

Format completed

2 Revectored LBNS

2 Primary revectored LBNS

0 Secondary/tertiary revectored LBNS

0 Bad blocks in the RCT area due to data errors

0 Bad blocks in the DBN area due to data errors

0 Bad blocks in the XBN area due to data errors

2 Blocks retried on the check pass

FCT used successfully

CZUDE EOP 1

0 CUMULATIVE ERRORS

DR>

3.0 ERROR INFORMATION

3.1 TYPES OF ERROR MESSAGES

There are three levels of error messages that may be issued by a diagnostic: general, basic and extended. General error messages are always printed unless the "IER" flag is set (section 2.3). The general error message is of the form:

NAME TYPE NUMBER ON UNIT NUMBER TST NUMBER PC:XXXXXX
error message

where: NAME = diagnostic name
TYPE = error type (SYS FTL ERR, DEV FTL ERR)
NUMBER = error number
UNIT NUMBER = 0 - N (N is last unit in PTABLE)
TST NUMBER = test and subtest where error occurred
PC:XXXXXX = address of error message call

System fatal errors (SYS FTL ERR) are used to report errors that are fatal to the entire diagnostic program. The diagnostic stops and the Runtime Services prompt is printed.

Device fatal errors (DVC FTL ERR) are used to report errors that are fatal to the device (may be either a UDA-50 or disk drive). Testing stops on that device for the remainder of the current test.

Basic error messages are messages that contain some additional information about the error. These are always printed unless the "IER" or "IBE" flags are set (section 2.3). These messages are printed after the associated general message.

Extended error messages contain supplementary error information such as register contents or good/bad data. These are always printed unless the "IER", "IBE" or "IXE" flags are set (section 2.3). These messages are printed after the associated general error message and any associated basic error messages.

The general and basic error messages from this diagnostic are always one line each. The basic message defines what program detected the error, the UDA-50 being used and the time of the error:

HOST PROGRAM UDA AT xxxxxx RUNTIME hhh:mm:ss

The host program (PDP-11) detected the error. UDA AT xxxxxx identifies the address of the UDA-50 being tested. It may be omitted if the error is not specific to one UDA-50.

Sample error message:

CZUDE DVC FTL ERR 00021 ON UNIT 00 TST 001 SUB 000 PC:xxxxxx
HOST PROGRAM UDA AT 172150 RUNTIME 0:00:12
UDA RESIDENT DIAGNOSTICS DETECTED FAILURE
UDASA CONTAINS 104041
REPLACE UDA MODULE M7161

| - general message
| - basic message
| : - extended message

The DUP program may also print error messages. They are printed exactly as presented by the DUP program and cannot be suppressed by any flags.

3.2 SPECIFIC ERROR MESSAGES

3.2.1 HOST PROGRAM ERROR MESSAGES

Following is a list of the error messages that may be printed by the diagnostic program. In the list, some of the numbers that may vary with execution or program version are shown as "xxx". These include program counters and runtime. Other numbers, such as unit number, drive number, UDA-50 address and data in registers are filled with sample numbers. Additional information about the error may follow the error message.

00001 CZUDE SYS FTL ERR 00001 ON UNIT 00 TST 001 SUB 000 PC:xxxxxx
HOST PROGRAM UDA AT 172150 RUNTIME x:xx:xx
I DON'T LIKE THE ANSWERS YOU GAVE TO THE HARDWARE QUESTIONS
UDA HAS MORE THAN ONE VECTOR, BR LEVEL OR BURST RATE

When the hardware questions were answered, two units were selected with the same UNIBUS address but with a different vector, BR level or burst rate. A single UDA-50 can have only one vector, BR level or burst rate. The program is aborted and returns to the Runtime Services prompt so that you can change the hardware questions.

00002 CZUDE SYS FTL ERR 00002 ON UNIT 00 TST 001 SUB 000 PC:xxxxxx
HOST PROGRAM UDA AT 172150 RUNTIME x:xx:xx
I DON'T LIKE THE ANSWERS YOU GAVE TO THE HARDWARE QUESTIONS
TWO UNITS SELECT THE SAME DRIVE

The hardware questions for two units were exactly the same. The program is aborted and returns to the Runtime Services prompt so that you can change the hardware questions.

00003 CZUDE SYS FTL ERR 00003 ON UNIT 00 TST 001 SUB 000 PC: xxxxxx
HOST PROGRAM UDA AT 172150 RUNTIME x:xx:xx
I DON'T LIKE THE ANSWERS YOU GAVE TO THE HARDWARE QUESTIONS
MORE THAN EIGHT DRIVES SELECTED ON THIS UDA

Up to four physical disk drives can be attached to a UDA-50 at one time. A physical disk drive may be from one to four logical disk drives. Each logical disk drive is considered one unit to the diagnostic program. Even though more than eight logical disk drives can be attached to one UDA-50, the UDA-50 only supports eight. The program is aborted and returns to the Runtime Services prompt so that you can change the hardware questions.

00004 CZUDE SYS FTL ERR 00004 ON UNIT 00 TST 001 SUB 000 PC: xxxxxx
HOST PROGRAM RUNTIME x:xx:xx
NOT ENOUGH ROOM IN MEMORY TO TEST THE UNITS SELECTED
PLEASE START PROGRAM OVER AND TEST FEWER UNITS AT A TIME

This program does not limit the number of units that can be tested by specifying a maximum number. What limits the number is the amount of memory used to store data on each unit. You have exceeded the number of units that are testable at one time. Start program over and select fewer units.

00008 CZUDE SYS FTL ERR 00008 ON UNIT 00 TST 001 SUB 000 PC: xxxxxx
HOST PROGRAM UDA AT 172150 RUNTIME x:xx:xx
I DON'T LIKE THE ANSWERS YOU GAVE TO THE HARDWARE QUESTIONS
TWO UDA'S USE THE SAME VECTOR

The hardware questions for two units specified different UDA-50 Unibus addresses but identical vector addresses. The program is aborted and returns to the Runtime Services prompt so that you can change the hardware questions.

00009 CZUDE DVC FTL ERR 00009 ON UNIT 00 TST 001 SUB 000 PC: xxxxxx
HOST PRGGRAM RUNTIME x:xx:xx
ONLY ONE DISK CAN BE SELECTED IN HW QUESTIONS IN RESTORE MODE.
PLEASE START PROGRAM OVER AND SELECT ONLY ONE DISK.

If the operator chooses to run the formatter in RESTORE mode, then only one disk can be selected in the hardware questions. RESTORE mode is run in this way because a file containing the bad block information is used and that information matches only one drive.

00010 CZUDE DVC FTL ERR 00010 ON UNIT 00 TST 001 SUB 000 PC: xxxxxx
HOST PROGRAM RUNTIME x:xx:xx
THIS PROGRAM CAN ONLY REFORMAT A DISK IN UNATTENDED MODE

This program needs to ask questions of the operator. It refuses to run in RECONSTRUCT and RESTORE modes because the questions obtain data that is absolutely necessary. REFORMAT mode is allowed to run because only a date is needed. The default date of 1-JAN-70 is used.

00020 CZUDE DVC FTL ERR 00020 ON UNIT 00 TST 001 SUB 000 PC: xxxxxx
HOST PROGRAM UDA AT 172150 RUNTIME x:xx:xx
MEMORY ERROR TRYING TO READ UDA REGISTERS
CHECK UNIBUS SELECTION SWITCHES ON UDA MODULE M7161
OR UNIBUS
OR REPLACE UDA MODULE M7161

A non-existant memory error occurred when the host program tried to access the UDAIP and UDASA registers. The UDA is at another address (check the UNIBUS selection switches) or module M7161 is broken or the UNIBUS is broken.

00021 CZUDE DVC FTL ERR 00021 ON UNIT 00 TST 001 SUB 000 PC: xxxxxx
HOST PROGRAM UDA AT 172150 RUNTIME x:xx:xx
UDA RESIDENT DIAGNOSTICS DETECTED FAILURE
UDASA CONTAINS 105154
REPLACE UDA MODULE M7162

The UDA Resident diagnostic detected a failure. The error is displayed in the UDASA. Here are the possible error values and their meaning:

104000 - Fatal sequencer error
104040 - D processor ALU error
104041 - D proc ROM parity error
105102 - D proc with no Board #2 or RAM parity error
105105 - D proc RAM buffer error
105152 - D proc SDI error
105153 - D proc write mode wrap SERDES error
105154 - D proc read mode SERDES, RSGEN, and ECC error
106040 - U proc ALU error
106041 - U proc Control Register error
106042 - U proc DFAIL/ROM parity error/Board #1 test count is wrong
106047 - U proc Constant ROM error with D proc running SDI test
106055 - Unexpectant trap found, aborted diagnostic
106071 - U proc ROM error
106072 - U proc ROM parity error
106200 - Step 1 data error (MSB not set)
107103 - U proc RAM parity error
107107 - U proc RAM buffer error
107115 - Board #2 test count was wrong
112300 - Step 2 error
122240 - NPR error
122300 - Step 3 error
142300 - Step 4 error

Replace the board specified. M7161 is the Unibus interface board.
M7162 is the SDI interface board.

F 2
00022 CZUDE DVC FTL ERR 00022 ON UNIT 00 TST 001 SUB 000 PC: xxxxxx
HOST PROGRAM UDA AT 172150 RUNTIME x:xx:xx
STEP BIT DID NOT SET IN UDASA REGISTER DURING INITIALIZATION
STEP BIT EXPECTED 004000
UDASA CONTAINS 000000
REPLACE UDA MODULE M7161

The UDA did not respond as expected during the initialization sequence which communicates using data in the UDASA register. A normal response from the UDA contains either a STEP bit or an ERROR bit defined as follows:

Bit 15 (100000)	Error bit
Bit 14 (040000)	Step 4 bit
Bit 13 (020000)	Step 3 bit
Bit 12 (010000)	Step 2 bit
bit 11 (004000)	Step 1 bit

The expected step bit nor the error bit set within the expected time.

00023 CZUDE DVC FTL ERR 00023 ON UNIT 00 TST 001 SUB 000 PC: xxxxxx
HOST PROGRAM UDA AT 172150 RUNTIME x:xx:xx
UDA DID NOT CLEAR RING STRUCTURE IN HOST MEMORY DURING INITIALIZATION
6 WORDS WERE TO BE CLEARED STARTING AT ADDRESS 040644
FIRST SEVERAL WORDS NOT CLEARED (UP TO 6):
ADDRESS CONTENTS
040644 000010
040650 000010
040652 000010
REPLACE UDA MODULE M7161

The UDA is to clear the ring structure (a communications area used by the UDA to talk to the host) in host memory before Step 4 of initialization. If the UDA diagnostics did not clear memory and did not flag an error, then error message 00023 is displayed. The contents of each word in memory is set to 177777 before the test. Failure of the UDA to clear each word indicates a fault in the address interface to the Unibus.

00024 CZUDE DVC FTL ERR 00024 ON UNIT 00 TST 001 SUB 000 PC: xxxxxx
HOST PROGRAM UDA AT 172150 RUNTIME x:xx:xx
UDASA REGISTER DID NOT GO TO ZERO AFTER STEP 3 WRITE OF INITIALIZATION
PURGE/POLE DIAGNOSTICS WERE REQUESTED
UDASA CONTENTS 004400

For better testing, the host can test the PURGE and POLE mechanism of the UDA. To do so the host sets bit15 of the step 3 data and sends the data to the UDA. The UDA must go to zero and wait for the purge and pole. If the UDA never went to zero, then error message 00024 is displayed. The UDA may have a bad M7161 module or the UNIBUS may be broken.

G 2
00025 CZUDE DVC FTL ERR 00025 ON UNIT 00 TST 001 SUB 000 PC:xxxxxx
HOST PROGRAM UDA AT 172150 RUNTIME x:xx:xx
UDA DID NOT RETURN CORRECT DATA IN UDASA REGISTER DURING INITIALIZATION
UDASA EXPECTED 004400
UDASA CONTAINS 004000
REPLACE UDA MODULE M7161

For each step of initialization, specific data is expected to be displayed in the UDASA. If the UDASA does not match the expected data, then error message 00025 is displayed.
Replace UDA module M7161.

00030 CZUDE DVC FTL ERR 00030 ON UNIT 00 TST 001 SUB 000 PC:xxxxxx
HOST PROGRAM UDA AT 172150 RUNTIME x:xx:xx
UDA REPORTED FATAL ERROR IN UDASA REGISTER WHILE RUNNING DM PROGRAM
UDASA CONTAINS 100004

A message from the UDA firmware reports an unexpected failure. An error code is presented in the UDASA. Here is a list of the codes and their meanings:

- 004400 - UDA has been initied by either a bus init or by writing into the UDAIP.
- 100001 - UNIBUS envelope/packet read error (parity or timeout)
- 100002 - UNIBUS envelope/packet write error (parity or timeout)
- 100003 - UDA ROM and RAM parity error
- 100004 - UDA RAM parity error
- 100005 - UDA ROM parity error
- 100006 - UNIBUS ring read error
- 100007 - UNIBUS ring write error
- 100010 - UNIBUS interrupt master failure
- 100011 - Host access timeout error
- 100012 - Host exceeded credit limit
- 100013 - UDA SDI hardware fatal error
- 100014 - DM XFC fatal error
- 100015 - Hardware timeout of instruction loop
- 100016 - Invalid virtual circuit identifier
- 100017 - Interrupt write error on UNIBUS

00031 CZUDE DVC FTL ERR 00031 ON UNIT 00 TST 001 SUB 000 PC:xxxxxx
HOST PROGRAM UDA AT 172150 RUNTIME x:xx:xx
NO INTERRUPT RECEIVED FROM DM PROGRAM FOR 3 MINUTES
ASSUME PROGRAM IS HUNG

All DM programs are required to communicate with the host program; so as to assure the host program that the DM program is not hung up or in an endless loop. If the DM program has not done so, the host program assumes the DM is hung and this message appears.

00032 CZUDE DVC FTL ERR 00032 ON UNIT 00 TST 001 SUB 000 PC: xxxxxx
HOST PROGRAM UDA AT 172150 RUNTIME x:xx:xx
MESSAGE BUFFER RECEIVED FROM DM PROGRAM WITH UNKNOWN REQUEST NUMBER
MESSAGE BUFFER CONTAINS:
000001 000002 000003 000004 000005 000006 000007
000008 000009 000010 000011 000012 000013 000014
000015 000016 000017 000018 000019 000020 000021
000022 000023 000024 000025 000026 000027 000028
000029 000030 000031 000032 000033 000034 000035

The DM program and the host program communicate with each other using packets. Each packet must have a request number set up by the DM program and interpreted by the host program. This request number is not a known request number. The problem may be the UNIBUS or either one of the UDA modules or a corrupted DM program. Word 1 contains the DM request number, and word 2 typically contains the drive number. The rest of the buffer contains information specific to a DM request. The numbers in the example show the order in which words are displayed.

00033 CZUDE DVC FTL ERR 00033 ON UNIT 00 TST 001 SUB 000 PC: xxxxxx
00034 HOST PROGRAM UDA AT 172150 RUNTIME x:xx:xx
RESPONSE PACKET FROM UDA DOES NOT CONTAIN EXPECTED DATA
EITHER UDA RETURNED ERROR STATUS OR PACKET WAS NOT RECEIVED CORRECTLY
COMMAND PACKET SENT RESPONSE PACKET RECEIVED
000000 000020 000000 000020
000000 000000 000000 000000
000000 000002 000000 000202
000000 014336 000000 014336
000000 034674 000000 034674
000000 000000 000000 000000
000000 000000 000000 000000
000000 051232 000000 051232
000000 000000 000000 000000
000000 000000 000000 000000
000000 000000 000000 000000

The host program inspected the response packet which was given by to UDA. The response packet may have been in error with one of the following points:

- 1) The end code was not as expected.
- 2) The status code showed an error occurred with the last command.
- 3) The command reference numbers (the first word) did not match.

If 1 or 3 occurred, there may have been a transmission problem between the UDA and the host program. If 2 occurred, check the error code in the MSCP specification for further information. The packets are displayed two long words per line, low order word and byte to the right (corresponding to the MSCP long-word entity).

00036 CZUDE DVC FTL ERR 00036 ON UNIT 00 TST 001 SUB 000 PC: xxxxxx
HOST PROGRAM UDA AT 172150 RUNTIME x:xx:xx
NO INTERRUPT RECEIVED FROM UDA FOR 30 SECONDS
WHILE LOADING DM PROGRAM

After a DM program has been sent to the UDA, the host program expects an interrupt within 30 seconds. The interrupt is used to assure the host program that the DM program is sane. If no interrupt occurred, then error message 00036 is displayed and the DM program is assumed to be hung.

00037 CZUDE DVC FTL ERR 00037 ON UNIT 00 TST 001 SUB 000 PC: xxxxxx
HOST PROGRAM UDA AT 172150 RUNTIME x:xx:xx
UDA REPORTED FATAL ERROR IN UDASA REGISTER WHILE LOADING DM PROGRAM
UDASA CONTAINS 100004
REPLACE UDA MODULE M7161

While loading the DM program to the UDA, the UDASA became non-zero. When this occurs, it signifies that the UDA microcode has run across a fatal error. The displayed value is in octal. Check the error code with the list in 00030.

00100 CZUDE DVC FTL ERR 00100 ON UNIT 00 TST 001 SUB 000 PC: xxxxxx
HOST PROGRAM UDA AT 172150 RUNTIME x:xx:xx
DUP PROGRAM ASKED UNEXPECTED QUESTION (25)

The DUP program sends a value that corresponds to a specific question or message. If this value does not fit into the range of questions, then this error appears.

00101 CZUDE DVC FTL ERR 00101 ON UNIT 00 TST 001 SUB 000 PC: xxxxxx
HOST PROGRAM UDA AT 172150 RUNTIME x:xx:xx
DUP PROGRAM REJECTED ANSWER TO DATE OR SERIAL NUMBER QUESTION

After the operator inputs the date/serial number, the DUP program will ask the host program for them. If for some reason the date/serial number was unacceptable to the DUP program, this error message will appear. Retry the program and if this error appears again, get out of the diagnostic runtime services and back to the XXDP+ prompt and reload the program.

3.2.2 DUP PROGRAM ERROR MESSAGES

Error messages returned by the UDA formatter are as follows:

GET STATUS failure

This could be caused by a number of reasons. Examples: the RUN/STOP switch is out, the WRITE PROTECT switch is in, or the DIAGNOSTIC REQUEST bit is set by the drive.

SDI send error

An attempt to send an SDI command failed. The signal RECEIVER READY was not asserted.

Unsuccessful SDI command

The response from an SDI command was unsuccessful and all commands should be successful for the formatter to work. There may be a cable problem, drive receiver problem or UDA transmitter problem.

SDI receive error

This message is presented for several reasons. The drive timed out, the first word from the drive was not a start frame, there was a framing error on the SDI level 0 read (cable/receiver/transmitter problem), checksum error, or the buffer size given by the formatter wasn't large enough for the UDA. Again, there may be a cable/receiver/transmitter problem.

UNIBUS read error

This is caused by one of two problems. While trying to read an overlay into the UDA buffer memory, the formatter came across a nonexistent memory error. Or, there was a failure while downline loading the bad block information. There may be something wrong with the UNIBUS or the UDA module M7161.

Formatter initialization error

For this error to occur, the UDA must be processing the DM code improperly.

Nonexistent unit number

The desired disk drive wasn't attached to the UDA.

DBN/XBN format error (drive FORMAT command failed)

All attempts and retries to format a track failed. There may have been a timeout of drive signals, the drive dropped the READ/WRITE READY signal during the format operation or the drive clock timed out (which indicates cable/transmitter/receiver failures).

FCT does not have enough good copies of each block

There must at least two good copies of every block in the FCT. For this error to occur, the media is badly corrupted or the read/write logic is failing.

SEEK error

After a seek command completed successfully, the READ/WRITE READY signal was never set or the ATTENTION signal was set.

RCT does not have enough good copies of each block

There must be at least two good copies of every block in the RCT. For this error to occur, the media is badly corrupted or the read/write logic is failing.

LBN format error (drive FORMAT command failed)

All attempts and retries to format a track failed. There may have been a timeout of drive signals, the drive dropped the READ/WRITE READY signal during the format operation or the drive clock timed out (which indicates cable/transmitter/receiver failures).

FCT write error

A particular block failed to be written into every copy of the FCT. There is either terribly bad media or a write logic failure.

RCT read error

The formatter could not read at least one good copy of a particular block in the RCT area.

RCT write error

A particular block failed to be written into every copy of the RCT. There is either terribly bad media or a write logic failure.

RCT full

There were so many bad blocks on the media that the RCT area was filled and could no longer hold any more. There could be read/write logic failure or bad cable connection.

FCT read error

The formatter could not read at least one good copy of a particular block in the FCT area.

FCT downline-load error

The formatter was led to believe that a bad block information file was larger than it really was. There may be a UNIBUS or M7161 problem.

Drive init timeout

After the drive was initied, the RECEIVER READY signal never asserted.

Illegal response to start-up question

An overflow occurred when the serial number went over 64 bits.

An example of how the errors are presented is below:

RUNTIME 0:00:18
Nonexistant unit number

4.0 PERFORMANCE AND PROGRESS REPORTS

There is no statistical report that can be printed using the Diagnostic Runtime Services PRINT command.

The DUP program issues the following messages upon normal completion:

Format completed

n Revectored LBNS

Where n is the number of LBNS revectored in the user data area.

n Primary revectored LBNS

Where n is the number of LBNS in message #2 which were primary revector.

n Secondary/tertiary revectored LBNS

Where n is the number of the LBNS in message #2 which were secondary or tertiary revector.

n Bad blocks in the RCT area due to data errors

Where n is the number of blocks in the total RCT area which were bad.

n Bad blocks in the DBN area due to data errors

Where n is the number of blocks in the total DBN area which were bad.

n Bad blocks in the XBN area due to data errors

Where n is the number of blocks in the total XBN area which were bad.

n Blocks retried on the check pass

Where n is the number of blocks which had an error on the first read attempt after formatting.

FCT used successfully or
FCT was not used

Depending on the answers to the software questions and the availability of the bad sector information (FCT), one of these messages will be printed.

An example of how the messages are presented is below.

RUNTIME 0:24:57
Format completed
5 Revectored LBNS
5 Primary revectored LBNS
0 Secondary/tertiary revectored LBNS
0 Bad blocks in the RCT area due to data errors
0 Bad blocks in the DBN area due to data errors
0 Bad blocks in the XBN area due to data errors
5 Blocks retried on the check pass
FCT was not used

5.0 TEST SUMMARIES

There is only one test in this program - Test #1. Its only purpose is to load and run the format program in a UDA-50.

```

1           .SBTTL PROGRAM HEADER
25          002000
26          BGNMOD
27
28          :++ THE PROGRAM HEADER IS THE INTERFACE BETWEEN
29          THE DIAGNOSTIC PROGRAM AND THE SUPERVISOR.
30          :--
31
32          002000      POINTER BGNST, BGNSETUP
33
34          002000      HEADER CZUDE,B,P,O,1,PRI07    ;FIELD SERVICE
35          002000
36          002000      103
37          002001      132
38          002002      125
39          002003      104
40          002004      105
41          002005      000
42          002006      000
43          002007      000
44
45          002010      102
46
47          002011      120
48
49          002012      000001
50
51          002014      000000
52
53          002016      021064
54
55          002020      021252
56
57          002022      002130
58
59          002024      002144
60
61          002026      000124
62
63          002030      000000
64
65          002030      000000
66
67          002032      000000
68
69          002034      000001
70
71          002036      000000
72
73          002040      002124
74
75          002042      000340
76
77          002044      000000
78
79          002046      000000
80
81          002050      003
82
83          002051      003

          LSNAME::      .ASCII /C/
          LSREV::       .ASCII /B/
          LSDEPO::      .ASCII /P/
          LSUNIT::      .WORD TSPTHV
          LSTIML::      .WORD 0
          LSHPCP::      .WORD LSHARD
          LSSPCP::      .WORD LSSOFT
          LSHPTP::      .WORD LSHW
          LSSPTP::      .WORD LSSW
          LSLADP::      .WORD LSLAST
          LSSTA::       .WORD 0
          LSCO::        .WORD 0
          LSDTYP::      .WORD 1
          LSAPT::       .WORD 0
          LSDTP::       .WORD LSDISPATCH
          LSPRIO::      .WORD PRI07
          LSENVI::       .WORD 0
          LSEXP1::       .WORD 0
          LSMREV::      .BYTE CSREVISION
                           .BYTE CSEDIT

```

002052
002052 000000
002054 000000
002056
002056 000000
002060
002060 003442
002062
002062 000000
002064
002064 000000
002066
002066 000000
002070
002070 000000
002072
002072 000000
002074
002074 000000
002076
002076 003464
002100
002100 104035
002102
002102 000000
002104
002104 017036
002106
002106 020454
002110
002110 020452
002112
002112 017030
002114
002114 000000
002116
002116 000000
002120
002120 000000

L\$EF:: .WORD 0
L\$SPC:: .WORD 0
L\$DEV:: .WORD 0
L\$REPP:: .WORD L\$DVTYPE
L\$EXP4:: .WORD 0
L\$EXP5:: .WORD 0
L\$AUT:: .WORD 0
L\$DUT:: .WORD 0
L\$LUN:: .WORD 0
L\$DESC:: .WORD 0
L\$LOAD:: EMT E\$LOAD
L\$TP:: .WORD 0
L\$ICP:: .WORD LSINIT
L\$CCP:: .WORD L\$CLEAN
L\$ACP:: .WORD L\$AUTO
L\$PRT:: .WORD L\$PROT
L\$TEST:: .WORD 0
L\$DLY:: .WORD 0
L\$HIME:: .WORD 0

1
2
3
4
5
6
7
8

.SBTTL DISPATCH TABLE

++
: THE DISPATCH TABLE CONTAINS THE STARTING ADDRESS OF EACH TEST.
: IT IS USED BY THE SUPERVISOR TO DISPATCH TO EACH TEST.
--

DISPATCH 1

9 002122 000001
002122 000001
002124 020462

L\$DISPATCH: .WORD 1
.WORD T1

```
1 .SBTTL DEFAULT HARDWARE P-TABLE
2
3 ++
4 : THE DEFAULT HARDWARE P-TABLE CONTAINS DEFAULT VALUES OF
5 : THE TEST-DEVICE PARAMETERS. THE STRUCTURE OF THIS TABLE
6 : IS IDENTICAL TO THE STRUCTURE OF THE HARDWARE P-TABLES,
7 : AND IS USED AS A "TEMPLATE" FOR BUILDING THE P-TABLES.
8 ;--
9
10 002126      BGNHW DFPTBL          .WORD   L10000-L$HW/2
11    002126 000005
12    002130
13    002130
14 002130      .WORD   172150        : UNIBUS ADDRESS
15 002132      .WORD   154           : VECTOR ADDRESS
16 002134      .WORD   5             : BR LEVEL
17 002136      .WORD   63            : UNIBUS BURST RATE
18 002138      .WORD   0             : LOGICAL DRIVE NUMBER
19 002140      ENDHW
20 002142      .WORD   0             L10000:
21 002142
```

```
1          .SBTTL SOFTWARE P-TABLE
2
3          :+++
4          : THE SOFTWARE TABLE CONTAINS VARIOUS DATA USED BY THE
5          : PROGRAM AS OPERATIONAL PARAMETERS. THESE PARAMETERS ARE
6          : SET UP AT ASSEMBLY TIME AND MAY BE VARIED BY THE OPERATOR
7          : AT RUN TIME.
8          :--
9
10         BGNSTW SFPTBL
11
12         .WORD      L10001-LSSW/2
13         002142 000001
14
15         LSSW::      SFPTBL::      USE
16         002144
17
18         .WORD      7
19         002144
20         :OFFSET    YES/NO ANSWERS
21         002146
22         002146
23         L10001:
24
25         ENDSW
26
27         ENDMOD
```

```
1 .SBTTL GLOBAL EQUATES SECTION
2
3 002146          BGNMOD
4
5      ++ THE GLOBAL EQUATES SECTION CONTAINS PROGRAM EQUATES THAT
6      ARE USED IN MORE THAN ONE TEST.
7      --
8
9
10 002146         EQUALS
11      : BIT DIFINITIONS
12
13 100000          BIT15== 100000
14 040000          BIT14== 40000
15 020000          BIT13== 20000
16 010000          BIT12== 10000
17 004000          BIT11== 4000
18 002000          BIT10== 2000
19 001000          BIT09== 1000
20 000400          BIT08== 400
21 000200          BIT07== 200
22 000100          BIT06== 100
23 000040          BIT05== 40
24 000020          BIT04== 20
25 000010          BIT03== 10
26 000004          BIT02== 4
27 000002          BIT01== 2
28 000001          BIT00== 1
29
30 001000          BIT9==  BIT09
31 000400          BIT8==  BIT08
32 000200          BIT7==  BIT07
33 000100          BIT6==  BIT06
34 000040          BIT5==  BIT05
35 000020          BIT4==  BIT04
36 000010          BIT3==  BIT03
37 000004          BIT2==  BIT02
38 000002          BIT1==  BIT01
39 000001          BIT0==  BIT00
40
41      : EVENT FLAG DEFINITIONS
42      EF32:EF17 RESERVED FOR SUPERVISOR TO PROGRAM COMMUNICATION
43
44 000040          EF.START==    32.          : START COMMAND WAS ISSUED
45 000037          EF.RESTART==   31.          : RESTART COMMAND WAS ISSUED
46 000036          EF.CONTINUE==  30.          : CONTINUE COMMAND WAS ISSUED
47 000035          EF.NEW==      29.          : A NEW PASS HAS BEEN STARTED
48 000034          EF.PWR==      28.          : A POWER-FAIL/POWER-UP OCCURRED
49
50      : PRIORITY LEVEL DEFINITIONS
51
52 000340          PRI07== 340
53 000300          PRI06== 300
54 000240          PRI05== 240
55 000200          PRI04== 200
```

000140 PRI03== 140
000100 PRI02== 100
000040 PRI01== 40
000000 PRI00== 0

:OPERATOR FLAG BITS

000004 EVL== 4
000010 LOT== 10
000020 ADR== 20
000040 IDU== 40
000100 ISR== 100
000200 UAM== 200
000400 BOE== 400
001000 PNT== 1000
002000 PRI== 2000
004000 IXE== 4000
010000 IBE== 10000
020000 IER== 20000
040000 LOE== 40000
100000 HOE== 100000

11

12

CR= 15

;VALUE TO PASS TO PRINT MACRO TO END LINE

```
1 ;MACRO DEFINITIONS FOR GLOBAL EQUATES
2 ;THESE MACROS ARE USED TO DEFINE INDEXES INTO A TABLE
3 ;CALLING SEQUENCE MUST BE
4
5     TABLE
6         ITEM   NAME    BYTES
7         ITEM   NAME    BYTES
8         ITEM   NAME    BYTES
9         END     SIZE
10
11
12
13 :TABLE DEFINES THAT A TABLE IS ABOUT TO BE DEFINED AND END TERMINATES THE DEFINITION.
14 :ANY NUMBER OF ITEM LINES CAN APPEAR. NAME IS THE NAME OF THE SYMBOL BEING EQUATED TO
15 :THE INDEX. THE INDEX ALWAYS STARTS AT ZERO. BYTES SPECIFIES THE SIZE OF THE VALUE TO BE
16 :STORED AT THAT INDEX IN BYTES. THE SIZE ARGUMENT TO THE END STATEMENT IS OPTIONAL, IT
17 :BE EQUATED TO THE SIZE OF THE TABLE IN BYTES. THE SYMBOL TINDEX IS USED TO KEEP TRACK
18 :OF THE INDEX VALUE AND WILL BE EQUAL TO THE SIZE OF THE TABLE AFTER THE END STATEMENT.
19
20 .MACRO TABLE
21     TINDEX=0
22 .ENDM
23
24 .MACRO ITEM NAME BYTES
25     NAME=TINDEX
26     TINDEX=TINDEX+BYTES
27 .ENDM
28
29 .MACRO END SIZE
30     .IF NB SIZE
31     SIZE=TINDEX
32 .ENDC
33 .ENDM
```

```

1          ;UDA BIT DEFINITIONS
2          ;UDASA REGISTER UNIVERSAL READ BITS
3
4          004000      SA.S1= 004000      ;STEP 1 STATUS BIT
5          010000      SA.S2= 010000      ;STEP 2 STATUS BIT
6          020000      SA.S3= 020000      ;STEP 3 STATUS BIT
7          040000      SA.S4= 040000      ;STEP 4 STATUS BIT
8          100000      SA.ERR= 100000    ;ERROR INDICATOR
9
10         ;UDASA REGISTER ERROR STATUS BITS
11
12         003777      SA.ERC= 003777    ;ERROR CODE
13
14         ;UDASA REGISTER STEP ONE READ BITS
15
16         002000      SA.NV= 002000    ;NON SETTABLE INTERRUPT VECTOR
17         001000      SA.A2= 001000    ;22 BIT ADDRESS BUS
18         000400      SA.DI= 000400    ;ENHANCED DIAGNOSTICS
19         :           000377      ;ALL BITS RESERVED
20
21         ;UDASA REGISTER STEP ONE WRITE BITS
22
23         000177      SA.VEC= 000177   ;INTERRUPT VECTOR (DIVIDED BY 4)
24         000200      SA.INT= 000200   ;INTERRUPT ENABLE DURING INITIALIZATION
25         003400      SA.MSG= 003400   ;MESSAGE RING LENGTH
26         034000      SA.CMD= 034000   ;COMMAND RING LENGTH
27         040000      SA.WRP= 040000   ;WRAP BIT
28         100000      SA.STP= 100000   ;STEP - MUST ALWAYS BE WRITTEN A ONE
29
30         000400      SA.MS1= 000400   ;LSB OF MESSAGE RING LENGTH
31         004000      SA.CM1= 004000   ;LSB OF COMMAND RING LENGTH
32
33         ;UDASA REGISTER STEP TWO READ BITS
34
35         000007      SA.MSE= 000007   ;MESSAGE RING LENGTH ECHO
36         000070      SA.CME= 000070   ;COMMAND RING LENGTH ECHO
37         :           000100      ;RESERVED
38         000200      SA.STE= 000200   ;STEP ECHO
39         003400      SA.CTP= 003400   ;CONTROLLER TYPE
40
41         ;UDASA REGISTER STEP TWO WRITE BITS
42
43         000001      SA.PRG= 000001   ;ENABLE VAX UNIBUS ADAPTER PURGE INTERRUPT
44         :           177776      ;LOW ORDER MESSAGE RING BYTE ADDRESS
45

```

1 ;UDASA REGISTER STEP THREE READ BITS
2
3 000177 SA.VCE= 000177 :INTERRUPT VECTOR ECHO
4 000200 SA.INE= 000200 :INTERRUPT ENABLE ECHO
5 000400 SA.NVE= 000400 :VECTOR NOT PROGRAMMABLE
6 : 003000 :RESERVED
7
8 ;UDASA REGISTER STEP THREE WRITE BITS
9
10 100000 : 077777 :HIGH ORDER MESSAGE RING BYTE ADDRESS
11 :SA.TST= 100000 :PURGE POLE TEST ENABLE
12
13 ;UDASA REGISTER STEP FOUR READ BITS
14
15 000377 SA.MCV= 000377 :UDA MICROCODE VERSION
16 : 003400 :RESERVED
17
18 ;UDASA REGISTER STEP FOUR WRITE BITS
19
20 000001 SA.GO= 000001 :GO BIT TO START UDA FIRMWARE
21 000002 SA.LFC= 000002 :LAST FAILURE CODE REQUEST
22 000374 SA.BST= 000374 :BURST LEVEL

1 ;COMMAND/MESSAGE DESCRIPTOR BIT DEFINITIONS
2
3 100000 RG.DWN= 100000 :SET WHEN UDA OWNS RING
4 040000 RG.FLG= 040000 :FLAG BIT
5
6 ;OFFSETS INTO HOST COMMUNICATIONS AREA WITH ONE DESCRIPTOR TO EACH RING
7 ;AND TWO PACKET AND BUFFER AREAS.
8
9 000004 HC.ISZ= 4. :SIZE OF INTERRUPT INDICATOR WORDS
10 000004 HC.RSZ= 4. :SIZE OF RING IN BYTES
11 000004 HC.ESZ= 4. :SIZE OF ENVELOPE WORDS BEFORE PACKET
12 000060 HC.PSZ= 48. :SIZE OF COMMAND AND MESSAGE PACKETS
13 000122 HC.BSZ= 82. :SIZE OF BUFFER
14
15 000000 HC.INT= 0. :INTERRUPT INDICATOR WORDS START
16 000004 HC.MSG= HC.INT+HC.ISZ :MESSAGE RING START
17 000006 HC.MCT= HC.MSG+2. :MESSAGE RING CONTROL WORD
18 000010 HC.CMD= HC.MSG+HC.RSZ :COMMAND RING START
19 000012 HC.CCT= HC.CMD+2. :COMMAND RING CONTROL WORDS
20 000014 HC.MEV= HC.CMD+HC.RSZ :MESSAGE ENVELOPE START
21 000020 HC.MPK= HC.MEV+HC.ESZ :MESSAGE PACKET START
22 000100 HC.CEV= HC.MPK+HC.PSZ :COMMAND ENVELOPE START
23 000104 HC.CPK= HC.CEV+HC.ESZ :COMMAND PACKET START
24 000164 HC.BF1= HC.CPK+HC.PSZ :FIRST BUFFER
25 000306 HC.BF2= HC.BF1+HC.BSZ :SECOND BUFFER
26
27 000430 HC.SIZ= HC.BF2+HC.BSZ :TOTAL SIZE OF HOST COMM AREA
28
29 ;VIRTUAL CIRCUIT IDENTIFIERS
30
31 000000 MSCP= 0 :MSCP CIRCUIT
32 000001 LOG= 1 :LOG CIRCUIT
33 177777 DIAG= -1 :DIAGNOSTIC CIRCUIT
34 001000 DUP= 1000 :DIAGNOSTIC AND UTILITIES PROTOCOL

1	HC.INT	INTERRUPT INDICATORS	4 BYTES
2	HC.MSG	MESSAGE RING	4 BYTES
3	HC.MCT		
4	HC.CMD	COMMAND RING	4 BYTES
5	HC.CCT		
6	HC.MEV	MESSAGE ENVELOPE	52 BYTES
7	HC.MPK		
8	HC.CEV	COMMAND ENVELOPE	52 BYTES
9	HC.CPK		
10	HC.BF1	BUFFER # 1 (RESPONSE TO DM PROGRAM)	82 BYTES
11	HC.BF2	BUFFER # 2 (REQUEST FROM DM PROGRAM)	82 BYTES
12			
13			
14			
15			
16			
17			
18			
19			
20			
21			
22			
23			
24			
25			
26			
27			
28			
29			
30			
31			
32			
33			
34			

1 ;COMMAND PACKET OPCODES
2
3 000001 OP.ABO= 1 :ABORT COMMAND
4 000020 OP.ACC= 20 :ACCESS COMMAND
5 000010 OP.AVL= 10 :AVAILABLE COMMAND
6 000021 OP.CCD= 21 :COMPARE CONTROLLER DATA COMMAND
7 000040 OP.CMP= 40 :COMPARE HOST DATA COMMAND
8 000022 OP.ERS= 22 :ERASE COMMAND
9 000023 OP.FLU= 23 :FLUSH COMMAND
10 000002 OP.GCS= 2 :GET COMMAND STATUS COMMAND
11 000003 OP.GUS= 3 :GET UNIT STATUS COMMAND
12 000011 OP.ONL= 11 :ONLINE COMMAND
13 000041 OP.RD= 41 :READ COMMAND
14 000024 OP.RPL= 24 :REPLACE COMMAND
15 000004 OP.SCC= 4 :SET CONTROLLER CHARACTERISTICS COMMAND
16 000012 OP.SUC= 12 :SET UNIT CHARACTERISTICS COMMAND
17 000042 OP.WR= 42 :WRITE COMMAND
18 000030 OP.MRD= 30 :MAINTENANCE READ COMMAND
19 000031 OP.MWR= 31 :MAINTENANCE WRITE COMMAND
20 000200 OP.END= 200 :END PACKET FLAG
21 000007 OP.SEX= 7 :SERIOUS EXCEPTION END PACKET
22 000100 OP.AVA= 100 :AVAILABLE ATTENTION MESSAGE
23 000101 OP.DUP= 101 :DUPLICATE UNIT NUMBER ATTENTION MESSAGE
24 000102 OP.SHG= 102 :SHADOW COPY COMPLETE ATTENION MESSAGE
25 000103 OP.RLC= 103 :RESET COMMAND LIMIT ATTENTION MESSAGE
26
27 000001 OP.GDS= 1 :DUP GET DUST STATUS
28 000002 OP.ESP= 2 :DUP EXECUTE SUPPLIED PROGRAM
29 000003 OP.ELP= 3 :DUP EXECUTE LOCAL PROGRAM
30 000004 OP.SD= 4 :DUP SEND STUD DATA
31 000005 OP.RSD= 5 :DUP RECEIVE STUD DATA
32
33 :NOTE: END PACKET OPCODES (ALSO CALLED ENDCODES) ARE FORMED BY ADDING THE END
34 :PACKET FLAG TO THE COMMAND OPCODE. FOR EXAMPLE, A READ COMMAND'S END PACKET
35 :CONTAINS THE VALUE OP.RD+OP.END IN ITS OPCODE FIELD. THE INVALID COMMAND END
36 :PACKET CONTAINS JUST THE END PACKET FLAG (I.E., OP.END) IN ITS OPCODE FIELD.
37 :THE SERIOUS EXCEPTION END PACKET CONTAINS THE SUM OF THE END PACKET FLAG
38 :PLUS THE SERIOUS EXCEPTION OPCODE SHOWN ABOVE (I.E., OP.SEX+OP.END) IN ITS
39 :OPCODE FIELD.
40
41 :COMMAND OPCODE BITS 3 THROUGH 5 INDICATE THE COMMAND CLASS, WHICH IS ENCODED
42 :AS FOLLOWS:
43 : 000 IMMEDIATE COMMANDS
44 : 001 SEQUENTIAL COMMANDS
45 : 010 NON-SEQUENTIAL COMMANDS THAT DO NOT INCLUDE A BUFFER DESCRIPTOR
46 : 100 NON-SEQUENTIAL COMMANDS THAT DO INCLUDE A BUFFER DESCRIPTOR

GLOBAL EQUATES SECTION

```

1          ;COMMAND MODIFIERS
2
3          : = 020000      ;CLEAR SERIOUS EXCEPTION
4          MD.CMP= 040000  ;COMPARE
5          MD.EXP= 100000  ;EXPRESS REQUEST
6          MD.ERR= 010000  ;FORCE ERROR
7          MD.SCH= 004000  ;SUPPRESS CACHING (HIGH SPEED)
8          MD.SCL= 002000  ;SUPPRESS CACHING (LOW SPEED)
9          MD.SEC= 000100  ;SUPPRESS ERROR CORRECTION
10         MD.SER= 000400  ;SUPPRESS ERROR RECOVERY
11         MD.SSH= 000200  ;SUPPRESS SHADOWING
12         MD.WBN= 000100  ;WRITE-BACK (NON-VOLATILE)
13         MD.WBV= 000400  ;WRITE BACK (VOLATILE)
14         MD.SEQ= 000020  ;WRITE SHADOW SET ONE UNIT AT A TIME
15         MD.SPD= 000001  ;SPIN-DOWN
16         MD.FEU= 000001  ;FLUSH ENTIRE UNIT
17         MD.VOL= 000002  ;VOLATILE ONLY
18         MD.NXU= 000001  ;NEXT UNIT
19         MD.RIP= 000001  ;ALLOW SELF DESTRUCTION
20         MD.IMF= 000002  ;IGNORE MEDIA FORMAT ERROR
21         MD.SWP= 000004  ;SET WRITE PROTECT
22         MD.CWB= 000010  ;CLEAR WRITE-BACK DATA LOST
23         MD.PRI= 000001  ;PRIMARY REPLACEMENT BLOCK
24
25          ;END PACKET FLAGS
26
27         000200      ;BAD BLOCK REPORTED
28         000100      ;BAD BLOCK UNREPORTED
29         000040      ;ERROR LOG GENERATED
30         000020      ;SERIOUS EXCEPTION
31
32          ;CONTROLLER FLAGS
33
34         000200      ;ENABLE ATTENTION MESSAGES
35         000100      ;ENABLE MISCELLANEOUS ERROR LOG MESSAGES
36         000040      ;ENABLE OTHER HOST'S ERROR LOG MESSAGES
37         000020      ;ENABLE THIS HOST'S ERROR LOG MESSAGES
38         000002      ;SHADOWING
39         000001      ;576 BYTE SECTORS

```

1 ;UNIT FLAGS
2
3 000001 UF.CMR= 000001 :COMPARE READS
4 000002 UF.CMW= 000002 :COMPARE WRITES
5 100000 UF.RPL= 100000 :HOST INITIATED BAD BLOCK REPLACEMENT
6 040000 UF.INA= 040000 :INACTIVE SHADOW SET UNIT
7 004000 UF.SCH= 004000 :SUPPRESS CACHING (HIGH SPEED)
8 002000 UF.SCL= 002000 :SUPPRESS CACHING (LOW SPEED)
9 000100 UF.WBN= 000100 :WRITE-BACK (NON-VOLATILE)
10 020000 UF.WPH= 020000 :WRITE PROTECT (HARDWARE)
11 001000 UF.WPS= 001000 :WRITE PROTECT (SOFTWARE OR VOLUME)
12 000004 UF.576= 000004 :576 BYTE SECTORS
13
14 ;COMMAND PACKET OFFSETS
15
16 ; GENERIC COMMAND PACKET OFFSETS:
17 000000 P.CRF= 0. :COMMAND REFERENCE NUMBER
18 000004 P.UNIT= 4. :UNIT NUMBER
19 000010 P.OPCD= 8. :OPCODE
20 000012 P.MOD= 10. :MODIFIERS
21 000014 P.BCNT= 12. :BYTE COUNT
22 000020 P.BUFF= 16. :BUFFER DESCRIPTOR
23 000020 P.UADR= 16. :UNIBUS ADDRESS OF BUFFER DESCRIPTOR
24 000034 P.LBN= 28. :LOGICAL BLOCK NUMBER
25
26 ; ABORT AND GET COMMAND STATUS COMMAND PACKET OFFSETS:
27 000014 P.OTRF= 12. :OUTSTANDING REFERENCE NUMBER
28
29 ; ONLINE AND SET UNIT CHARACTERISTICS COMMAND PACKET OFFSETS:
30 000016 P.UNFL= 14. :UNIT FLAGS
31 000020 P.HSTI= 16. :HOST IDENTIFIER / RESERVED
32 000034 P.ELGF= 28. :ERROR LOG FLAGS
33 000040 P.SHUN= 32. :SHADOW UNIT
34 000042 P.CPSP= 34. :COPY SPEED
35
36 000014 P.RBN= 12. :REPLACE COMMAND PACKET OFFSETS:
37 :REPLACEMENT BLOCK NUMBER
38
39 000014 P.VRSN= 12. :SET CONTROLLER CHARACTERISTICS COMMAND PACKET OFFSETS:
40 000016 P.CNTF= 14. :MSCP VERSION
41 000020 P.HTMO= 16. :CONTROLLER FLAGS
42 000022 P.USEF= 18. :HOST TIMEOUT
43 000024 P.TIME= 20. :USE FRACTION
44 :QUAD-WORD TIME AND DATE
45
46 000034 P.RGID= 28. :MAINTENANCE READ AND MAINTENANCE WRITE COMMAND PACKET OFFSETS:
47 000040 P.RGOF= 32. :REGION ID
48
49 000024 P.DMDT= 20. :EXECUTE SUPPLIED PROGRAM COMMAND PACKET OFFSETS:
50 000034 P.OVRL= 28. :DMDT TERMINAL ADDRESS (MAINT WRITE ONLY)
51 :BUFFER DESCRIPTOR FOR OVERLAYS

1 :END PACKET OFFSETS
2
3 :
4 000000 P.CRF= 0. :COMMAND REFERENCE NUMBER
5 000004 P.UNIT= 4. :UNIT NUMBER
6 000010 P.OPCD= 8. :OPCODE (ALSO CALLED ENDCODE)
7 000011 P.FLGS= 9. :END PACKET FLAGS
8 000012 P.STS= 10. :STATUS
9 000014 P.BCNT= 12. :BYTE COUNT
10 000034 P.FBBK= 28. :FIRST BAD BLOCK
11
12 :
13 000014 P.OTRF= 12. :GET COMMAND STATUS END PACKET OFFSETS:
14 000020 P.CMST= 16. :OUTSTANDING REFERENCE NUMBER
15 :
16 :
17 000014 P.MLUN= 12. :GET UNIT STATUS END PACKET OFFSETS:
18 000016 P.UNFL= 14. :MULTI-UNIT CODE
19 000020 P.HSTI= 16. :UNIT FLAGS
20 000024 P.UNTI= 20. :HOST IDENTIFIER
21 000034 P.MEDI= 28. :UNIT IDENTIFIER
22 000040 P.SHUN= 32. :MEDIA TYPE IDENTIFIER
23 000042 P.SHST= 34. :SHADOW UNIT
24 000044 P.TRCK= 36. :SHADOW STATUS
25 000046 P.GRP= 38. :TRACK SIZE
26 000050 P.CYL= 40. :GROUP SIZE
27 000054 P.RCTS= 44. :CYLINDER SIZE
28 000056 P.RBNS= 46. :RCT TABLE SIZE
29 000057 P.RCTC= 47. :RBNS / TRACK
30 :
31 :
32 :
33 000014 P.MLUN= 12. :ONLINE AND SET UNIT CHARACTERISTICS END PACKET AND AVAILABLE
34 000016 P.UNFL= 14. :ATTENTION MESSAGE OFFSETS:
35 000020 P.HSTI= 16. :MULTI-UNIT CODE
36 000024 P.UNTI= 20. :UNIT FLAGS
37 000034 P.MEDI= 28. :HOST IDENTIFIER
38 000040 P.SHUN= 32. :UNIT IDENTIFIER
39 000042 P.SHST= 34. :MEDIA TYPE IDENTIFIER
40 000044 P.UNCL= 36. :SHADOW UNIT
41 000050 P.UNSZ= 40. :SHADOW STATUS
42 000054 P.VSER= 44. :UNIT COMMAND LIMIT
43 :
44 :
45 000014 P.VRSN= 12. :SET CONTROLLER CHARACTERISTICS END PACKET OFFSETS:
46 000016 P.CNTF= 14. :MSCP VERSION
47 000020 P.CTMO= 16. :CONTROLLER FLAGS
48 000022 P.CNCL= 18. :CONTROLLER TIMEOUT
49 000024 P.CNTI= 20. :CONTROLLER COMMAND LIMIT
50 :
51 :
52 000014 P.DEXT= 12. :GET DUST STATUS END PACKET OFFSETS:
53 000017 P.DFLG= 15. :DUST PROGRAM EXTENSION
54 000020 P.DPI= 16. :STATUS FLAGS
55 000024 P.DTO= 20. :PROGRESS INDICATOR
56 :
57 :
58 :
59 :
60 :
61 :
62 :
63 :
64 :
65 :
66 :
67 :
68 :
69 :
70 :
71 :
72 :
73 :
74 :
75 :
76 :
77 :
78 :
79 :
80 :
81 :
82 :
83 :
84 :
85 :
86 :
87 :
88 :
89 :
90 :
91 :
92 :
93 :
94 :
95 :
96 :
97 :
98 :
99 :
100 :
101 :
102 :
103 :
104 :
105 :
106 :
107 :
108 :
109 :
110 :
111 :
112 :
113 :
114 :
115 :
116 :
117 :
118 :
119 :
120 :
121 :
122 :
123 :
124 :
125 :
126 :
127 :
128 :
129 :
130 :
131 :
132 :
133 :
134 :
135 :
136 :
137 :
138 :
139 :
140 :
141 :
142 :
143 :
144 :
145 :
146 :
147 :
148 :
149 :
150 :
151 :
152 :
153 :
154 :
155 :
156 :
157 :
158 :
159 :
160 :
161 :
162 :
163 :
164 :
165 :
166 :
167 :
168 :
169 :
170 :
171 :
172 :
173 :
174 :
175 :
176 :
177 :
178 :
179 :
180 :
181 :
182 :
183 :
184 :
185 :
186 :
187 :
188 :
189 :
190 :
191 :
192 :
193 :
194 :
195 :
196 :
197 :
198 :
199 :
200 :
201 :
202 :
203 :
204 :
205 :
206 :
207 :
208 :
209 :
210 :
211 :
212 :
213 :
214 :
215 :
216 :
217 :
218 :
219 :
220 :
221 :
222 :
223 :
224 :
225 :
226 :
227 :
228 :
229 :
230 :
231 :
232 :
233 :
234 :
235 :
236 :
237 :
238 :
239 :
240 :
241 :
242 :
243 :
244 :
245 :
246 :
247 :
248 :
249 :
250 :
251 :
252 :
253 :
254 :
255 :
256 :
257 :
258 :
259 :
260 :
261 :
262 :
263 :
264 :
265 :
266 :
267 :
268 :
269 :
270 :
271 :
272 :
273 :
274 :
275 :
276 :
277 :
278 :
279 :
280 :
281 :
282 :
283 :
284 :
285 :
286 :
287 :
288 :
289 :
290 :
291 :
292 :
293 :
294 :
295 :
296 :
297 :
298 :
299 :
300 :
301 :
302 :
303 :
304 :
305 :
306 :
307 :
308 :
309 :
310 :
311 :
312 :
313 :
314 :
315 :
316 :
317 :
318 :
319 :
320 :
321 :
322 :
323 :
324 :
325 :
326 :
327 :
328 :
329 :
330 :
331 :
332 :
333 :
334 :
335 :
336 :
337 :
338 :
339 :
340 :
341 :
342 :
343 :
344 :
345 :
346 :
347 :
348 :
349 :
350 :
351 :
352 :
353 :
354 :
355 :
356 :
357 :
358 :
359 :
360 :
361 :
362 :
363 :
364 :
365 :
366 :
367 :
368 :
369 :
370 :
371 :
372 :
373 :
374 :
375 :
376 :
377 :
378 :
379 :
380 :
381 :
382 :
383 :
384 :
385 :
386 :
387 :
388 :
389 :
390 :
391 :
392 :
393 :
394 :
395 :
396 :
397 :
398 :
399 :
400 :
401 :
402 :
403 :
404 :
405 :
406 :
407 :
408 :
409 :
410 :
411 :
412 :
413 :
414 :
415 :
416 :
417 :
418 :
419 :
420 :
421 :
422 :
423 :
424 :
425 :
426 :
427 :
428 :
429 :
430 :
431 :
432 :
433 :
434 :
435 :
436 :
437 :
438 :
439 :
440 :
441 :
442 :
443 :
444 :
445 :
446 :
447 :
448 :
449 :
450 :
451 :
452 :
453 :
454 :
455 :
456 :
457 :
458 :
459 :
460 :
461 :
462 :
463 :
464 :
465 :
466 :
467 :
468 :
469 :
470 :
471 :
472 :
473 :
474 :
475 :
476 :
477 :
478 :
479 :
480 :
481 :
482 :
483 :
484 :
485 :
486 :
487 :
488 :
489 :
490 :
491 :
492 :
493 :
494 :
495 :
496 :
497 :
498 :
499 :
500 :
501 :
502 :
503 :
504 :
505 :
506 :
507 :
508 :
509 :
510 :
511 :
512 :
513 :
514 :
515 :
516 :
517 :
518 :
519 :
520 :
521 :
522 :
523 :
524 :
525 :
526 :
527 :
528 :
529 :
530 :
531 :
532 :
533 :
534 :
535 :
536 :
537 :
538 :
539 :
540 :
541 :
542 :
543 :
544 :
545 :
546 :
547 :
548 :
549 :
550 :
551 :
552 :
553 :
554 :
555 :
556 :
557 :
558 :
559 :
560 :
561 :
562 :
563 :
564 :
565 :
566 :
567 :
568 :
569 :
570 :
571 :
572 :
573 :
574 :
575 :
576 :
577 :
578 :
579 :
580 :
581 :
582 :
583 :
584 :
585 :
586 :
587 :
588 :
589 :
590 :
591 :
592 :
593 :
594 :
595 :
596 :
597 :
598 :
599 :
600 :
601 :
602 :
603 :
604 :
605 :
606 :
607 :
608 :
609 :
610 :
611 :
612 :
613 :
614 :
615 :
616 :
617 :
618 :
619 :
620 :
621 :
622 :
623 :
624 :
625 :
626 :
627 :
628 :
629 :
630 :
631 :
632 :
633 :
634 :
635 :
636 :
637 :
638 :
639 :
640 :
641 :
642 :
643 :
644 :
645 :
646 :
647 :
648 :
649 :
650 :
651 :
652 :
653 :
654 :
655 :
656 :
657 :
658 :
659 :
660 :
661 :
662 :
663 :
664 :
665 :
666 :
667 :
668 :
669 :
670 :
671 :
672 :
673 :
674 :
675 :
676 :
677 :
678 :
679 :
680 :
681 :
682 :
683 :
684 :
685 :
686 :
687 :
688 :
689 :
690 :
691 :
692 :
693 :
694 :
695 :
696 :
697 :
698 :
699 :
700 :
701 :
702 :
703 :
704 :
705 :
706 :
707 :
708 :
709 :
710 :
711 :
712 :
713 :
714 :
715 :
716 :
717 :
718 :
719 :
720 :
721 :
722 :
723 :
724 :
725 :
726 :
727 :
728 :
729 :
730 :
731 :
732 :
733 :
734 :
735 :
736 :
737 :
738 :
739 :
740 :
741 :
742 :
743 :
744 :
745 :
746 :
747 :
748 :
749 :
750 :
751 :
752 :
753 :
754 :
755 :
756 :
757 :
758 :
759 :
760 :
761 :
762 :
763 :
764 :
765 :
766 :
767 :
768 :
769 :
770 :
771 :
772 :
773 :
774 :
775 :
776 :
777 :
778 :
779 :
780 :
781 :
782 :
783 :
784 :
785 :
786 :
787 :
788 :
789 :
790 :
791 :
792 :
793 :
794 :
795 :
796 :
797 :
798 :
799 :
800 :
801 :
802 :
803 :
804 :
805 :
806 :
807 :
808 :
809 :
810 :
811 :
812 :
813 :
814 :
815 :
816 :
817 :
818 :
819 :
820 :
821 :
822 :
823 :
824 :
825 :
826 :
827 :
828 :
829 :
830 :
831 :
832 :
833 :
834 :
835 :
836 :
837 :
838 :
839 :
840 :
841 :
842 :
843 :
844 :
845 :
846 :
847 :
848 :
849 :
850 :
851 :
852 :
853 :
854 :
855 :
856 :
857 :
858 :
859 :
860 :
861 :
862 :
863 :
864 :
865 :
866 :
867 :
868 :
869 :
870 :
871 :
872 :
873 :
874 :
875 :
876 :
877 :
878 :
879 :
880 :
881 :
882 :
883 :
884 :
885 :
886 :
887 :
888 :
889 :
890 :
891 :
892 :
893 :
894 :
895 :
896 :
897 :
898 :
899 :
900 :
901 :
902 :
903 :
904 :
905 :
906 :
907 :
908 :
909 :
910 :
911 :
912 :
913 :
914 :
915 :
916 :
917 :
918 :
919 :
920 :
921 :
922 :
923 :
924 :
925 :
926 :
927 :
928 :
929 :
930 :
931 :
932 :
933 :
934 :
935 :
936 :
937 :
938 :
939 :
940 :
941 :
942 :
943 :
944 :
945 :
946 :
947 :
948 :
949 :
950 :
951 :
952 :
953 :
954 :
955 :
956 :
957 :
958 :
959 :
960 :
961 :
962 :
963 :
964 :
965 :
966 :
967 :
968 :
969 :
970 :
971 :
972 :
973 :
974 :
975 :
976 :
977 :
978 :
979 :
980 :
981 :
982 :
983 :
984 :
985 :
986 :
987 :
988 :
989 :
990 :
991 :
992 :
993 :
99

```

1      ;STATUS AND EVENT CODE DEFINITIONS
2
3      000037      ST.MSK= 37          ;STATUS / EVENT CODE MASK
4      000040      ST.SUB= 40          ;SUB-CODE MULTIPLIER
5      000000      ST.SUC= 0           ;SUCCESS
6      000001      ST.CMD= 1           ;INVALID COMMAND
7      000002      ST.ABO= 2           ;COMMAND ABORTED
8      000003      ST.OFL= 3           ;UNIT-OFFLINE
9      000004      ST.AVL= 4           ;UNIT-AVAILABLE
10     000005      ST.MFE= 5           ;MEDIA FORMAT ERROR
11     000006      ST.WPR= 6           ;WRITE PROTECTED
12     000007      ST.CMP= 7           ;COMPARE ERROR
13     000010      ST.DAT= 10          ;DATA ERROR
14     000011      ST.HST= 11          ;HOST BUFFER ACCESS ERROR
15     000012      ST.CNT= 12          ;CONTROLLER ERROR
16     000013      ST.DRV= 13          ;DRIVE ERROR
17     000037      ST.DIA= 37          ;MESSAGE FROM AN INTERNAL DIAGNOSTIC
18
19      ;GET DUST STATUS FLAGS
20
21     000010      DF.ACT= 010          ;SET IF THIS DUST CURRENTLY ACTIVE
22     000004      DF.NES= 004          ;SET IF THIS DUST WILL NOT ACCEPT THE EXECUTE
23
24     000002      DF.LCL= 002          ;SUPPLIED PROGRAM COMMAND
25
26     000001      DF.SA= 001          ;SET IF THIS DUST HAS A LOCAL LOAD MEDIA FOR LOADING
27                                         ;DIAGNOSTICS AND OTHER UTILITIES
28                                         ;SET IF ANY PROGRAM EXECUTION UNDER THIS DUST
29                                         ;DISABLES THE OPERATION OF ALL OTHER SERVERS IN THE
30                                         ;SAME SYSTEM AS THE DUST
31
32      ;DUP MESSAGE TYPES
33
34     010000      DU.QUE = 10000        ;QUESTION
35     020000      DU.DFL = 20000        ;DEFAULT QUESTION
36     030000      DU.INF = 30000        ;INFORMATION
37     040000      DU.TER = 40000        ;TERMINATOR
38     050000      DU.FTL = 50000        ;FATAL ERROR
39     060000      DU.SPC = 60000        ;SPECIAL
40
41     170000      DU.TYP= 170000       ;MESSAGE TYPE FIELD
42
43      ;DM PROGRAM HEADER DEFINITIONS
44
45     000000      DMTRLN= 0           ;OFFSET TO SIZE OF PROGRAM NEEDING DOWNLINE LOAD
46     000004      DMOVRL= 4           ;OFFSET TO SIZE OF OVERLAY
47     000021      DMTMO= 21          ;TIMEOUT VALUE IN SECONDS (ONE BYTE)
48     000040      DMMAIN= 40          ;OFFSET TO FIRST WORD OF MAIN PROGRAM
49     001000      DMFRST= 1000         ;ADDRESS IN DM FILE CONTAINING FIRST BYTE OF HEADER

```

```

1      ;CONTROLLER TABLE DEFINITIONS
2
3      ;ONE TABLE WILL BE SET UP BY INITIALIZE SECTION FOR EACH UDA SELECTED
4      ;FOR TESTING. TABLES ARE CONTIGUOUS. THE END OF THE TABLES IS
5      ;MARKED BY A WORD OF ZEROS.
6
7      ;THE FIRST TABLE IS POINTED TO BY THE CONTENTS OF CTABS.
8      ;THE NUMBER OF TABLES IS CONTAINED IN CTRLRS.
9
10     002146          TABLE                      ;START A TABLE DEFINITION
11
12     002146          ITEM C.UADR    2           ;UNIBUS ADDRESS OF UDAIP REGISTER
13     002146          ITEM C.UNIT    2           ;LOGICAL UNIT NUMBER (FIRST)
14     000077          CT.UNT= 000077
15     100000          CT.AVL= BIT15        ;SET WHEN NOT AVAILABLE FOR TESTING
16     002146          ITEM C.VEC     2           ;VECTOR ADDRESS
17     000777          CT.VEC= 000777
18     007000          CT.BRL= 007000        ;BR LEVEL
19     002146          ITEM C.BST     2           ;BURST LEVEL
20     002146          ITEM C.JSR     2           ;INTERRUPT SERVICE ROUTINE FOR CONTROLLER
21     002146          ITEM C.JAD     2           ;THESE TWO WORDS LOADED WITH [JSR R0,UDASRV]
22     002146          ITEM C.FLG     2           ;FLAGS
23     000002          CT.RN= BIT1
24     000004          CT.CMD= BIT2        ;DM PROGRAM RUNNING
25     000010          CT.MSG= BIT3        ;COMMAND ISSUED, WAITING FOR RESPONSE
26
27     000020          CT.REQ= BIT4        ;MESSAGE RESPONSE RECEIVED
28
29
30     000040          CT.STA= BIT5        ;WHENEVER THIS BIT IS SET, CT.CMD IS CLEARED
31     000100          CT.TM1= BIT6        ;BUFFER HAS BEEN GIVEN TO UDA FOR REQUEST
32
33     000200          CT.TM2= BIT7        ;SET WHENEVER READ STUD DATA COMMAND
34     002146          ITEM C.RING    2           ;GIVEN TO UDA
35     002146          ITEM C.DRO     2           ;GET DUST STATUS COMMAND HAS BEEN SENT
36     002146          ITEM C.DR1     2           ;ONE TIMEOUT PERIOD HAS EXPIRED BETWEEN SEND OR
37     002146          ITEM C.DR2     2           ;RECEIVE DATA RESPONSE
38     002146          ITEM C.DR3     2           ;SECOND TIMEOUT HAS EXPIRED
39     002146          ITEM C.DR4     2           ;RING BUFFER ADDRESS
40     002146          ITEM C.DR5     2           ;POINTER TO DRIVE TABLES
41     002146          ITEM C.DR6     2           ;IF ZERO, NO DRIVE TABLE EXISTS
42     002146          ITEM C.DR7     2
43     002146          ITEM C.TO      2           ;TIMEOUT COUNTER
44     002146          ITEM C.TOH     2           ;(TWO WORDS)
45     002146          ITEM C.TOT     2           ;DUP PROGRAM TIMEOUT VALUE IN SECONDS
46     002146          ITEM C.PRI     4           ;DUP PROGRAM PROGRESS INDICATOR
47     002146          ITEM C.REF     2           ;COMMAND REFERENCE NUMBER
48
49     002146          END C.SIZE      ;SIZE OF CONTROLLER TABLE IN BYTES

```

G 4

1 :DRIVE TABLE DEFINITIONS
2
3 :ONE DRIVE TABLE WILL BE SET UP BY THE INITIALIZE SECTION FOR EACH
4 :DRIVE SELECTED FOR TESTING. EACH TABLE IS POINTED TO BY A
5 :WORD IN THE CONTROLLER TABLE ON WHICH THE DRIVE EXISTS.
6
7 002146 TABLE :START A TABLE DEFINITION
8
9 002146 ITEM D.DRV 2 :DRIVE NUMBER
10 002146 ITEM D.UNIT 2
11 000077 DT.UNT= 000077 : LOGICAL UNIT NUMBER OF DRIVE
12 100000 DT.AVL= BIT15 : SET WHEN NOT AVAILABLE FOR TESTING
13 002146 ITEM D.SERN 22. :DISK SERIAL NUMBER
14
15 002146 END D.SIZE :SIZE OF DRIVE TABLE IN BYTES

```
1          ;USEFUL INSTRUCTION DEFINITIONS
2
3          .MACRO AND ARG,ADR           ;LOGICAL AND INSTRUCTION
4          .LIST                         BIC #^C<ARG>,ADR
5
6          .NLIST
7
8          .ENDM
9
10         .MACRO OR ARG,ADR          ;LOGICAL OR INSTRUCTION
11         .LIST                         BIS #ARG,ADR
12         .NLIST
13
14         .ENDM
15         .MACRO PUSH ARG            ;PUSH INSTRUCTION
16         .IRP X,<ARG>
17         .LIST
18
19         .NLIST
20         .ENDM
21
22         .MACRO POP ARG             ;POP INSTRUCTION
23         .IRP X,<ARG>
24         .LIST                         MOV X,-(SP)
25
26         .NLIST
27         .ENDM
28
29         .MACRO BR ADR              ;A BRANCH TO THE NEXT LOCATION
30         .IF P2
31         .IF NE .-ADR
32             ERROR ;ILLEGAL .BR TO ADR
33         .ENDIF
34         .ENDC
35
36         .ENDM
37
38         .MACRO ASSUME FIRST CONDITION SECOND
39         .IF CONDITION <FIRST>-<SECOND>
40         .IFF
41             ERROR ;BAD ASSUME OF <FIRST> CONDITION <SECOND>
42         .ENDIF
43
44         .ENDM
```

1 PRINT CHARACTER
2 ARGUMENT MUST BE SOURCE STATEMENT TO MOVE CHARACTER TO PRINT (MOV ARG, R0)
3 EX: 'PRINT R1' WILL PRINT THE CHARACTER IN R1
4 SPECIAL CASE: 'PRINT #CR' WILL PRINT END OF LINE SEQUENCE
5 THE PRINTING IS DONE AT THE MODE OF THE LAST PRINT LINE CALL
6 IE., PNTX, PNTB, PNTX, PNTS

7
8 .MACRO PRINT ARG1
9 .IF DIF <ARG1>,R0
10 .LIST
11 .NLIST
12 .ENDC
13 .LIST
14 .NLIST
15 .ENDM
16
17 ;PROCESSING MACRO FOR NEXT SET OF FORMATTED MESSAGE MACROS
18
19 .MACRO PNT... RTN,ADR,ARG1,ARG2,ARG3,ARG4,ARG5,ARG6,ARG7,ARG8
20 PNT.CT=0
21 .IRP AA,<ARG8,ARG7,ARG6,ARG5,ARG4,ARG3,ARG2,ARG1>
22 .IF NB,<AA>
23 .LIST
24 .NLIST
25 .ENDC
26 .LIST
27 .NLIST
28 PNT.CT=PNT.CT+2
29 .ENDM
30 .LIST
31
32 .NLIST
33 .ENDM
34
35
36 .ENDM

MOV B ARG1,R0
CALL CPNT
MOV AA,-(SP)
JSR R1,RTN
.WORD ADR
.WORD PNT.CT

```
1 PRINT FORMATTED MESSAGE MACROS
2 : USE THESE MACROS TO PRINT A FORMATTED MESSAGE
3 : FIRST ARGUMENT MUST BE ADDRESS OF FIRST CHARACTER OF MESSAGE STRING
4 : TO BE PUT INTO WORD (.WORD ARG)
5 : UP TO 8 SOURCE STATEMENTS MAY FOLLOW TO SPECIFY PARAMETERS TO BE
6 : USED BY THE FORMAT
7
8 .MACRO PNTF ADR ARG1,ARG2,ARG3,ARG4,ARG5,ARG6,ARG7,ARG8
9     PNT... LPNTF ADR ARG1,ARG2,ARG3,ARG4,ARG5,ARG6,ARG7,ARG8
10    .ENDM
11 .MACRO PNTB ADR ARG1,ARG2,ARG3,ARG4,ARG5,ARG6,ARG7,ARG8
12     PNT... LPNTB ADR ARG1,ARG2,ARG3,ARG4,ARG5,ARG6,ARG7,ARG8
13    .ENDM
14 .MACRO PNTX ADR ARG1,ARG2,ARG3,ARG4,ARG5,ARG6,ARG7,ARG8
15     PNT... LPNTX ADR ARG1,ARG2,ARG3,ARG4,ARG5,ARG6,ARG7,ARG8
16    .ENDM
17 .MACRO PNTS ADR ARG1,ARG2,ARG3,ARG4,ARG5,ARG6,ARG7,ARG8
18     PNT... LPNTS ADR ARG1,ARG2,ARG3,ARG4,ARG5,ARG6,ARG7,ARG8
19    .ENDM
20 .MACRO PNT ADR ARG1,ARG2,ARG3,ARG4,ARG5,ARG6,ARG7,ARG8
21     PNT... LPNT ADR ARG1,ARG2,ARG3,ARG4,ARG5,ARG6,ARG7,ARG8
22    .ENDM
```

1 .SBTTL GLOBAL DATA SECTION
2
3 :++
4 : THE GLOBAL DATA SECTION CONTAINS DATA THAT ARE USED
5 : IN MORE THAN ONE TEST.
6 :--
7
8 002146 FFREE:: .BLKW 1 :FIRST FREE WORD IN MEMORY
9 002150 FSIZE:: .BLKW 1 :SIZE OF FREE MEMORY IN WORDS
10 002152 FMEM: .BLKW 1 :COPY OF FFREE AT END OF INIT SECTION
11 002154 FMEMS: .BLKW 1 :COPY OF FSIZE AT END OF INIT SECTION
12 002156 CTABS:: .BLKW 1 :START OF CONTROLLER TABLE STORAGE
13 002160 CTRLRS: .BLKW 1 :COUNT OF UDA CONTROLLERS IN PTABLES
14 002162 TSTTAB: .BLKW 1 :POINTER TO FIRST CONTROLLER TABLE UNDER TEST
15
16 002164 000000G GLOBL UDAFM
17 002166 DMPROG: .WORD UDAFM :START ADDRESS OF DM PROGRAM
18 002170 DMEND: .BLKW 1 :END ADDRESS OF DM PROGRAM(FIRST FREE MEMORY ADR)
19 002172 DMENDS: .BLKW 1 :FREE MEMORY SIZE FROM END OF DM PROGRAM
20 002174 URUN: .BLKW 1 :NUMBER OF UNITS TO RUN AT ONE TIME
21 002176 URNING: .BLKW 1 :NUMBER OF UNITS STILL RUNNING
22 002200 UCNT: .BLKW 1 :COUNTER OF UNITS UNDER TEST
23 002202 UFREEZ: .BLKW 1 :FREEZE ON UNIT WHEN NOT ZERO
24 002204 000000 NXMAD: .BLKW 1 :SET TO ALL ONES BY NON-EXISTANT ADDRESS
25 002206 FCTBUF: .BLKB 512. :STORAGE FOR FCT BLOCK
26 003206 FCTNUM: .BLKW 1 ;FCT BLOCK NUMBER
27 003210 MODE: .BLKW 1 ;MODE WORD, SAME BIT DEFS AS SO.BIT
28
29 :CLOCK CONTROL
30
31 003212 000000 KW.CSR: .WORD 0 :CSR OF CLOCK
32 003214 KW.BRL: .BLKW 1 :BR LEVEL
33 003216 KW.VEC: .BLKW 1 :VECTOR
34 003220 KW.HZ: .BLKW 1 :HERTZ (50. OR 60.)
35 003222 KW.EL: .BLKW 2 :ELAPSED TIME
36
37 003226 014526 PTYPE: .WORD PF :PRINT TYPE
38 003230 000 ERRCHR: .BYTE 0,0 :FIRST BYTE LOADED WITH OUTPUT CHARACTER
39 003232 000000 NULL: .WORD 0 :USED TO PRINT A NULL CHARACTER
40 003234 000000 FNAME: .WORD 0 :SPACE FOR DATA FILE NAME
41 003236 .BLKB 10.

L 4

1 003250				TEMP:	.BLKB 22.	:USED TO GET ANSWER FROM GMANID CALL
2 003276	061	055	112	DATEI:	.ASCII\1-JAN-70\	:DEFAULT DATE
3 003307					.BLKB 3	
4 003312	000000			DATEO:	.WORD 0 ;DATE STRING IN FORMATTER FORMAT	
5 003314					.BLKB 10. ;(FIRST WORD ZERO SAYS NO DATE HERE YET)	
6 003326	061	070	064	HIGHEST:	.ASCII\18446744073709551615\	:HIGHEST DISK SERIAL NUMBER
7 003353	104	105	103	MONTHS:	.ASCII\DEC\	;NAME OF MONTHS
8 003356	116	117	126		.ASCII\NOV\	
9 003361	117	103	124		.ASCII\OCT\	
10 003364	123	105	120		.ASCII\SEP\	
11 003367	101	125	107		.ASCII\AUG\	
12 003372	112	125	114		.ASCII\JUL\	
13 003375	112	125	116		.ASCII\JUN\	
14 003400	115	101	131		.ASCII\MAY\	
15 003403	101	120	122		.ASCII\APR\	
16 003406	115	101	122		.ASCII\MAR\	
17 003411	106	105	102		.ASCII\FEB\	
18 003414	112	101	116		.ASCII\JAN\	
19 003417	037			DAYS:	.BYTE 31.	;NUMBER OF DAYS IN EACH MONTH
20 003420	035				.BYTE 29.	
21 003421	037				.BYTE 31.	
22 003422	036				.BYTE 30.	
23 003423	037				.BYTE 31.	
24 003424	036				.BYTE 30.	
25 003425	037				.BYTE 31.	
26 003426	037				.BYTE 31.	
27 003427	036				.BYTE 30.	
28 003430	037				.BYTE 31.	
29 003431	036				.BYTE 30.	
30 003432	037				.BYTE 31.	
31 003433	061	071	000	YEAR19:	.ASCII\19\	
32 003436	062	060	000	YEAR20:	.ASCII\20\	
33					.EVEN	

1 .SBTTL GLOBAL TEXT SECTION
2
3
4 ::+
5 :: THE GLOBAL TEXT SECTION CONTAINS FORMAT STATEMENTS,
6 :: MESSAGES, AND ASCII INFORMATION THAT ARE USED IN
7 :: MORE THAN ONE TEST.
8 ::--
9
10 :: NAMES OF DEVICES SUPPORTED BY PROGRAM
11 ::
12 003442 DEVTYPE <UDA-50 CONTROLLER> L\$DVTYPE::
13 003442 125 104 101 .ASCIZ /UDA-50 CONTROLLER/
14 003442 .EVEN
15
16 003464 :: TEST DESCRIPTION L\$DESC::
17 003464 ::
18 003464 DESCRIPT <CZUDEBP UDA-50 DISK DRV FORMATTER> .ASCIZ /CZUDEBP UDA-50 DISK/
19 103 132 125 .EVEN

1 ;UNFORMATTED MESSAGES

2
3 003526 105 116 124 DATEQ: .ASCIZ\ENTER DATE AS DD-MMM-YY\
4 003556 040 106 117 FILNAQ: .ASCIZ\ FOR DISK TO BE FORMATTED\
5 003610 040 000 SERNQ: .ASCIZ\ \

1 ; FORMAT STATEMENTS USED IN PRINT CALLS
2
3 003612 045 124 000 ERRONE: .ASCIZ\%T\
4 003615 045 116 000 ERRNL: .ASCIZ\%N\
5 003620 042 040 040 RNTIM: .ASCIZ\" RUNTIME 'D16':"\\"
6 003643 104 071 042 RNTIM1: .ASCIZ\%D9'":\"\\"
7 003651 104 071 000 RNTIM2: .ASCIZ\%D9\
8 003654 042 040 040 ERRME1: .ASCIZ\" * * * ERROR PROCESSING MESSAGE STRING * * *'\%N\
9 003743 116 042 125 MESSG: .ASCIZ\%N'UNIT 'D6' UDA AT '016' DRIVE 'D9\\$\
10 004007 042 116 117 NOCLOCK:.ASCIZ\%NO LINE CLOCK AVAILABLE FOR TIMING EVENTS'\%N\
11
12 004064 042 110 117 BASNO: .ASCIZ\%HOST PROGRAM'\%
13 004103 042 040 040 BASL2: .ASCIZ\%UDA AT '016'\%
14 004122 042 040 040 BASL3: .ASCIZ\%DRIVE 'D9'\%
15 004137 000 000 000 BAS: .BYTE 0 ;NULL TO PRINT NOTHING
16
17 004140 122 066 122 BASLN: .ASCIZ\%R6R6R6R6\
18 004151 116 042 123 SERNUM: .ASCIZ\%N'SERIAL NUMBER FOR UNIT 'D6' UDA AT '016' DRIVE 'D9'\%

1 004236				X1A:	
2 004236				X2A:	
3 004236				X3A:	
4 004236	042	111	040	X8A:	.ASCIIZ\''I DON'T LIKE THE ANSWERS YOU GAVE TO THE HARDWARE QUESTIONS'\n\
5 004335	122	065	122	X1:	.ASCIIZ\R5R6'UDA HAS MORE THAN ONE VECTOR, BR LEVEL OR BURST RATE'\n\
6 004431	122	065	122	X2:	.ASCIIZ\R5R6'TWO UNITS SELECT THE SAME DRIVE'\n\
7 004500	122	065	122	X3:	.ASCIIZ\R5R6'MORE THAN EIGHT DRIVES SELECTED ON THIS UDA'\n\
8 004563	122	064	042	X4:	.ASCII\''R4'NOT ENOUGH ROOM IN MEMORY TO TEST THE UNITS SELECTED'\n\
9 004654	042	120	114		.ASCII\''PLEASE START PROGRAM OVER AND TEST FEWER UNITS AT A TIME'\n\
10 004750	122	065	122	X8:	.ASCIIZ\R5R6'TWO UDA'S USE THE SAME VECTOR'\n\
11 005015	122	064	042	X9:	.ASCII\''R4'ONLY ONE DISK CAN BE SELECTED IN HW QUESTIONS IN RESTORE MODE.'\n\
12 005120	042	120	114		.ASCII\''PLEASE START PROGRAM OVER AND SELECT ONLY ONE DISK.'\n\
13 005207	122	064	042	X10:	.ASCIIZ\R4'THIS PROGRAM CAN ONLY REFORMAT A DISK IN UNATTENDED MODE.'\n\
14 005306	122	065	042	X20:	.ASCII\''R5'MEMORY ERROR TRYING TO READ UDA REGISTERS'\n\
15 005364	042	103	110		.ASCII\''CHECK UNIBUS SELECTION SWITCHES ON UDA MODULE M7161'\n\
16 005452	042	117	122		.ASCII\''OR UNIBUS'\n\
17 005466	042	117	122		.ASCII\''OR 'R7'\n\
18 005476	122	065	042	X21:	.ASCII\''R5'UDA RESIDENT DIAGNOSTICS DETECTED FAILURE'\nNR8\
19 005556	042	122	105		.ASCIIZ\''REPLACE UDA MODULE M716'02N\
20 005613	122	065	042	X22:	.ASCII\''R5'STEP BIT DID NOT SET IN UDASA REGISTER DURING INITIALIZATION'\n\
21 005714	042	123	124		.ASCIIZ\''STEP BIT EXPECTED '016NR8R7'\n\
22 005751	122	065	042	X23A:	.ASCII\''R5'UDA DID NOT CLEAR RING STRUCTURE IN HOST MEMORY DURING INITIALIZATION'\n\
23 006063	104	071	042		.ASCII\''D9'' WORDS WERE TO BE CLEARED STARTING AT ADDRESS '016N'\n\
24 006151	042	106	111		.ASCII\''FIRST SEVERAL WORDS NOT CLEARED (UP TO 6):'\n\
25 006226	123	066	042		.ASCIIZ\S6''ADDRESS'S4''CONTENTS'\n\
26 006257	123	067	117	X23B:	.ASCIIZ\S7016S5016N\
27 006273	122	065	042	X24:	.ASCII\''R5'UDASA REGISTER DID NOT GO TO ZERO AFTER STEP 3 WRITE OF INITIALIZATION'\n\
28 006406	042	120	125		.ASCIIZ\''PURGE/POLE DIAGNOSTICS WERE REQUESTED'\nNR8R7\
29 006463	122	065	042	X25:	.ASCII\''R5'UDA DID NOT RETURN CORRECT DATA IN UDASA REGISTER DURING INITIALIZATION'\n\
30 006577	042	040	040		.ASCIIZ\'' UDASA EXPECTED '016NR8R7'\n\
31 006634	122	065	042	X30:	.ASCIIZ\R5'UDA REPORTED FATAL ERROR IN UDASA REGISTER WHILE RUNNING DM PROGRAM'\nNR8\
32 006747	122	065	042	X31:	.ASCIIZ\R5'DUP PROGRAM IS HUNG'\n\
33 007000	122	065	042	X32:	.ASCIIZ\R5'MESSAGE BUFFER RECEIVED FROM DM PROGRAM WITH UNKNOWN REQUEST NUMBER'\n\
34 007111	122	065	042	X36:	.ASCII\''R5'NO INTERRUPT RECEIVED FROM UDA FOR 30 SECONDS'\n\
35 007173	042	127	110		.ASCIIZ\''WHILE LOADING DM PROGRAM'\n\
36 007227	122	065	042	X37:	.ASCIIZ\R5'UDA REPORTED FATAL ERROR IN UDASA REGISTER WHILE LOADING DM PROGRAM'\nNR8R7\
37 007344	122	065	042	X100:	.ASCIIZ\R5'DUP PROGRAM ASKED UNEXPECTED QUESTION ('D12')'\n\
38 007427	122	065	042	X101:	.ASCIIZ\R5'DUP PROGRAM REJECTED ANSWER TO DATE OR SERIAL NUMBER QUESTION'\n\

GLOBAL TEXT SECTION

1 007532 042 115 105 XMSG1: .ASCIZ\''MESSAGE BUFFER CONTAINS:'\n'
2 007566 123 063 117 XMSG2: .ASCIZ\S3016S1016S1016S1016S1016S1016N\
3 007633 122 065 042 XPKT1: .ASCII\R5'RESPONSE PACKET FROM UDA DOES NOT CONTAIN EXPECTED DATA'\n\
4 007727 042 105 111 .ASCII\EITHER UDA RETURNED ERROR STATUS OR PACKET WAS NOT RECEIVED CORRECTLY'\n\
5 010037 123 063 042 .ASCIZ\S3'COMMAND PACKET SENT'S6'RESPONSE PACKET RECEIVED'\n\
6 010124 123 066 117 XPKT2: .ASCIZ\S6016S1016S14016S1016N\
7 010153 042 040 040 XSA: .ASCIZ\" UDASA CONTAINS '016N\
8 010204 042 122 105 XFRU: .ASCIZ\''REPLACE UDA MODULE M7161'\n\
9
10
11 010240 045 101 111 SERNX: .ASCIZ\%INPUT ERROR. ANSWER WITH DECIMAL NUMBER LO= 0 HI= %T\
12 010330 042 111 116 DATEX: .ASCIZ\''INPUT ERROR.'\
13 010347 042 116 101 FILNAM: .ASCIZ\''NAME OF FILE CONTAINING BAD SECTOR INFORMATION'\n.EVEN

1 .SBTTL GLOBAL ERROR REPORT SECTION
2
3 :++
4 : THE GLOBAL ERROR REPORT SECTION CONTAINS MESSAGE PRINTING AREAS
5 : USED BY MORE THAN TEST TO OUTPUT ADDITIONAL ERROR INFORMATION. PRINTB
6 : (BASIC) AND PRINTX (EXTENDED) CALLS ARE USED TO CALL PRINT SERVICES.
7 :--
8 177777 SVCINS= -1 : LIST INSTRUCTIONS, SHIFTED RIGHT
9 177777 SVCTST= -1 : LIST TEST TAGS, SHIFTED RIGHT
10 177777 SVCSUB= -1 : LIST SUBTEST TAGS, SHIFTED RIGHT
11 177777 SVCGBL= -1 : LIST GLOBAL TAGS, SHIFTED RIGHT
12 177777 SVCTAG= -1 : LIST OTHER TAGS, SHIFTED RIGHT
13
14 010430 BGNMSG ERR001
15 010430 PNTB X1,#X1A
16 010430 012746 004236
17 010434 004137 014660
18 010440 004335
19 010442 000002
20 010444 ENDMMSG
21 010446 BGNMSG ERR002
22 010446 PNTB X2,#X2A
23 010446 012746 004236
24 010452 004137 014660
25 010456 004431
26 010460 000002
27 010462 ENDMMSG
28 010464 BGNMSG ERR003
29 010464 PNTB X3,#X3A
30 010464 012746 004236
31 010470 004137 014660
32 010474 004500
33 010476 000002
34 010500 ENDMMSG
35 010502 BGNMSG ERR004
36 010502 PNTB X4
37 010502 004137 014660
38 010506 004563
39 010510 000000
40 010512 ENDMMSG
41 010514 BGNMSG ERR009
42 010514 PNTB X9
43 010514 004137 014660
44 010520 005015
45 010522 000000
46 010524 ENDMMSG
47 010526 BGNMSG ERR010
48 010526 PNTB X10
49 010526 004137 014660
50 010532 005207
51 010534 000000
52 010536 ENDMMSG

37
 38 010540 BGNMSG ERR008
 39 010540 PNTB X8,#X8A
 010540 012746 004236
 010544 004137 014660
 010550 004750
 010552 000002
 40 010554 ENDMMSG
 41
 42 010556 BGNMSG ERR020
 43 010556 PNTB X20
 010556 004137 014660
 010562 005306
 010564 000000
 44 010566 ENDMMSG
 45
 46 010570 BGNMSG ERR021
 47 010570 010201 MOV R2,R1
 48 010572 000301 SWAB R1
 49 010574 010201 AND 2,R1
 010574 042701 177775
 50 010600 006201 ASR R1
 51 010602 005201 INC R1
 52 010604 010146 PNTB X21,R2,R1
 010606 010246
 010610 004137 014660
 010614 005476
 010616 000004
 53 010620 ENDMMSG
 54
 55 010622 BGNMSG ERR022
 56 010622 042737 100000 016572 BIC #SA.ERR,UDARSD
 57 010630 010246 PNTB X22,UDARSD,R2
 010630 013746
 010632 016572
 010636 004137 014660
 010642 005613
 010644 000004
 58 010646 PRINTX #XFRU
 59 010666 ENDMMSG
 60
 61 010670 BGNMSG ERR023
 62 010670 PNTB X23A,R1,FFREE
 010670 013746 002146
 010674 010146
 010676 004137 014660
 010702 005751
 010704 000004
 63 010706 005742 TST -(R2)
 64 010710 005712 TST (R2)
 65 010712 001410 BEQ ERR23B
 66 010714 011246 PNTB X23B,R2,(R2)
 010714 010246
 010716 004137 014660
 010720 006257
 010724 006257

MOV #X8A,-(SP)
 JSR R1,LPNTB
 .WORD X8
 .WORD PNT.CT
 JSR R1,LPNTB
 .WORD X20
 .WORD PNT.CT
 BIC #^C<2>,R1
 MOV R1,-(SP)
 MOV R2,-(SP)
 JSR R1,LPNTB
 .WORD X21
 .WORD PNT.CT
 MOV R2,-(SP)
 MOV UDARSD,-(SP)
 JSR R1,LPNTB
 .WORD X22
 .WORD PNT.CT
 MOV FFREE,-(SP)
 MOV R1,-(SP)
 JSR R1,LPNTB
 .WORD X23A
 .WORD PNT.CT
 MOV (R2),-(SP)
 MOV R2,-(SP)
 JSR R1,LPNTB
 .WORD X23B

G 5

010726	000004		.WORD PNT.CT
67 010730	005304	DEC R4	
68 010732	001403	BEQ ERR23C	
69 010734	005722	ERR23B: TST (R2)+	
70 010736	005303	DEC R3	
71 010740	001363	BNE ERR23A	
72 010742		ERR23C: PNTB XFRU	
010742	004137	014660	
010746	010204		JSR R1,LPNTB
010750	000000		.WORD XFRU
73 010752			.WORD PNT.CT
74		ENDMSG	
75 010754		BGNMSG ERR024	
76 010754		PNTB X24,R2	
010754	010246		MOV R2,-(SP)
010756	004137	014660	JSR R1,LPNTB
010762	006273		.WORD X24
010764	000002		.WORD PNT.CT
77 010766		ENDMSG	
78		BGNMSG ERR025	
79 010770		PNTB X25,R1,R2	
80 010770			MOV R2,-(SP)
010770	010246		MOV R1,-(SP)
010772	010146		JSR R1,LPNTB
010774	004137	014660	.WORD X25
011000	006463		.WORD PNT.CT
011002	000004		
81 011004		ENDMSG	
82		BGNMSG ERR030	
83 011006		PNTB X30,R1	
84 011006			MOV R1,-(SP)
011006	010146		JSR R1,LPNTB
011019	004137	014660	.WORD X30
011014	006634		.WORD PNT.CT
011016	000002		
85 011020		ENDMSG	
86		BGNMSG ERR031	
87 011022		PNTB X31	
88 011022			JSR R1,LPNTB
011022	004137	014660	.WORD X31
011026	006747		.WORD PNT.CT
011030	000000		
89 011032		ENDMSG	
90		BGNMSG ERR032	
91 011034		PNTB X32	
92 011034			JSR R1,LPNTB
011034	004137	014660	.WORD X32
011040	007000		.WORD PNT.CT
011042	000000		
93 011044	004737	011234	CALL MSGPKT
94 011050		ENDMSG	
95		BGNMSG ERR033	
96 011052		CALL PNTPKT	
97 011052	004737	011142	ENDMSG
98 011056			BGNMSG ERR034
99			
100 011060			

101	011060	004737	011142	CALL PNPKT	
102	011064			ENDMSG	
103				BGNMSG ERR036	
104	011066			PNTB X36	
105	011066	004137	014660		JSR R1,LPNTB
	011066	007111			.WORD X36
	011074	000000			.WORD PNT.CT
106	011076			ENDMSG	
107				BGNMSG ERR037	
108	011100			PNTB X37,R1	
109	011100	010146			MOV R1,-(SP)
	011102	004137	014660		JSR R1,LPNTB
	011106	007227			.WORD X37
	011110	000002			.WORD PNT.CT
110	011112			ENDMSG	
111				BGNMSG ERR100	
112	011114			PNTB X100,(R4)	
113	011114	011446			MOV (R4),-(SP)
	011116	004137	014660		JSR R1,LPNTB
	011122	007344			.WORD X100
	011124	000002			.WORD PNT.CT
114	011126			ENDMSG	
115				BGNMSG ERR101	
116	011130			PNTB X101	
117	011130	004137	014660		JSR R1,LPNTB
	011134	007427			.WORD X101
	011136	000000			.WORD PNT.CT
118	011140			ENDMSG	
119				PNTPKT: PNTB XPKT1	
120	011142	004137	014660		JSR R1,LPNTB
	011142	007633			.WORD XPKT1
	011146	000000			.WORD PNT.CT
121	011152	010401		MOV R4,R1	
122	011154	062701	000104	ADD #HC.CPK,R1	
123	011160	010402		MOV R4,R2	
124	011162	062702	000020	ADD #HC.MPK,R2	
125	011166	012703	000014	MOV #12.,R3	
126	011172			PNTPKL: PNTB XPKT2,2(R1),(R1),2(R2),(R2)	
	011172	011246			MOV (R2),-(SP)
	011174	016246	000002		MOV 2(R2),-(SP)
	011200	011146			MOV (R1),-(SP)
	011202	016146	000002		MOV 2(R1),-(SP)
	011206	004137	014660		JSR R1,LPNTB
	011212	010124			.WORD XPKT2
	011214	000010			.WORD PNT.CT
127	011216	062701	000004	ADD #4,R1	
128	011222	062702	000004	ADD #4,R2	
129	011226	005303		DEC R3	
130	011230	001360		BNE PNTPKL	
131	011232	000207		RETURN	
132					
133	011234			MSGPKT: PNTB XMSG1	

011234	004137	014660	JSR R1,LPNTB
011240	007532		.WORD XMSG1
011242	000000		.WORD PNT.CT
134 011244	016504	000016	MOV C.RING(R5),R4
135 011250	062704	000306	ADD #HC.BF2,R4
136 011254	012703	000005	MOV #5,R3
137 011260			MSGPKL: PNTB XMSG2,(R4),2(R4),4(R4),6(R4),8.(R4),10.(R4),12.(R4)
011260	016446	000014	MOV 12.(R4),-(SP)
011264	016446	000012	MOV 10.(R4),-(SP)
011270	016446	000010	MOV 8.(R4),-(SP)
011274	016446	000006	MOV 6(R4),-(SP)
011300	016446	000004	MOV 4(R4),-(SP)
011304	016446	000002	MOV 2(R4),-(SP)
011310	011446		MOV (R4),-(SP)
011312	004137	014660	JSR R1,LPNTB
011316	007566		.WORD XMSG2
011320	000016		.WORD PNT.CT
138 011322	062704	000016	ADD #14.,R4
139 011326	005303		DEC R3
140 011330	001353		BNE MSGPKL
141 011332	000207		RETURN

1	000001	SVCINS= 1	: LIST INSTRUCTIONS, SHIFTED RIGHT
2	000001	SVCTST= 1	: LIST TEST TAGS, SHIFTED RIGHT
3	000001	SVCSUB= 1	: LIST SUBTEST TAGS, SHIFTED RIGHT
4	000001	SVCGBL= 1	: LIST GLOBAL TAGS, SHIFTED RIGHT
5	000001	SVCTAG= 1	: LIST OTHER TAGS, SHIFTED RIGHT

1 .SBTTL GLOBAL SUBROUTINES SECTION
2
3 :MEMORY ALLOCATION ERROR
4
5 :THIS ROUTINE PRINTS A SYSTEM FATAL ERROR AND EXITS THE TEST
6
7 011334 FMERR: ERRSF 4,,ERR004 TRAP C\$ERSF
011334 104454 .WORD 4
011336 000004 .WORD 0
011340 000000 .WORD ERR004
011342 010502
8 011344 DOCLN :ABORT TRAP C\$DCLN
011344 104444


```
1          :HCOMM
2
3          :ALLOCATES MEMORY FOR HOST COMM AREA AND PACKET BUFFERS WITH ONE
4          :DESCRIPTOR IN EACH RING. TO BE CALLED WHEN INITIALIZING
5          :A CONTROLLER WITH SA.MSG=0 AND SA.CMD=0.
6
7          :INPUTS:
8          R5 - ADDRESS OF CONTROLLER TABLE
9
10         :OUTPUTS:
11         CONTROLLER TABLE POINTING TO HOST COMM AREA
12         R4 - ADDRESS OF HOST COMM AREA
13 011372  012701  000214      HCOMM:  MOV #HC.SIZ/2,R1           :GET SIZE OF AREA TO ALLOCATE
14 011376  004737  011346      CALL ALOCM                 :ALLOCATE THE MEMORY
15 011402  010165  000016      MOV R1,C.RING(R5)        :GET ADDRESS OF HOST COMM AREA
16
17 011406  000207      RETURN                         :PLACE IN CONTROLLER TABLE
```


GLOBAL SUBROUTINES SECTION

```

1          ;RESPDM
2          ;:RESPOND TO DM REQUESTS. RETURN WHEN ALL DM PROGRAMS
3          ;HAVE TERMINATED.
4
5          011522 013705 002162      RESPDM: MOV TSTTAB,R5           ;GET CONTROLLER TABLE ADDRESS
6          011526 013737 002172 002176    MOV URUN,UCNT            ;SET COUNTER OF UNITS
7          011534 104422             RESPCT: BREAK   ;ALLOW DRS TO SEE TERMINAL INPUT      TRAP      CSBRK
8          011534 104422             MOV C.RING(R5),R4          ;GET HOST COMM AREA ADDRESS
9          011536 016504 000016       BIT #CT.RN,C.FLG(R5)        ;CHECK IF PROGRAM RUNNING
10         011542 032765 000002 000014    BEQ RSPNXT              ;IF NOT, LOOK AT NEXT
11         011550 001502             MOVB C.UNIT(R5),L$LUN      ;STORE UNIT NUMBER UNDER TEST
12         011552 116537 000002 002074    BIT #CT.MSG,C.FLG(R5)     ;SEE IF INTERRUPT RECEIVED
13         011560 032765 000010 000014    BNE RSPIN               ;IF SO, LOOK AT PACKET
14         011566 001150             BIT #CT.CMD,C.FLG(R5)      ;SEE IF COMMAND HAS BEEN SENT
15         011570 032765 000004 000014    BNE 1$                  ;IF NOT, SEND ONE
16         011576 001002             JMP RSPOUT              ;CHECK IF UDA STILL RUNNING
17         011600 000137 012346
18
19          1$:                   MOV (R5),R3           ;GET ADDRESS OF UDAIP
20          011604 011503             MOV 2(R3),R1           ;LOOK AT UDASA REGISTER
21          011606 016301 000002       BEQ RSPTM              ;IF ZERO, UDA STILL RUNNING
22          011612 001405             ERRDF 30.,ERR030      ;REPORT UDA HAS FATAL ERROR      TRAP      CSERDF
23          011614 104455             .WORD 30
24          011616 000036             .WORD 0
25          011620 000000             .WORD ERRO30
26          011622 011006             .WORD
27          011624 000465             BR RSPDRP              ;DROP CONTROLLER FROM TESTING
28
29          011626 005765 000044      RSPTM: TST C.TOT(R5)      ;SEE IF DUP PROGRAM TO BE TIMED
30          011632 001451             BEQ RSPNTO              ;SEE IF A CLOCK ON SYSTEM
31          011634 005737 003212       TST KW.CSR             ;DON'T TIME IF NO CLOCK
32          011640 001446             BEQ RSPNTO              ;COMPARE TO TIMEOUT COUNTER
33          011642 023765 003224 000042    CMP KW.EL+2,C.TOH(R5)
34          011650 101005             BHI RSPTMO              ;IF TOO MUCH TIME ELAPSED SINCE LAST INTERRUPT
35          011652 001041             BNE RSPNTO              ;SEE IF A GET DUST STATUS COMMAND OUTSTANDING
36          011654 023765 003222 000040    CMP KW.EL,C.TO(R5)
37          011662 103435             BLO RSPNTO              ;REPORT ERROR IF SO
38          011664 032765 000040 000014  RSPTMO: BIT #CT.STA,C.FLG(R5) ;SEE IF UDA TOOK LAST COMMAND PACKET
39          011672 001101             BNE RSPTOE              ;REPORT ERROR IF NOT
40          011674 005764 000012             TST HC.CCT(R4)        ;SEE IF FIRST TIMEOUT ALREADY HAPPENED
41          011700 100476             BMI RSPTOE              ;IF SO,
42          011702 012700 000100             MOV #CT.TM1,RO          ;SET SECOND TIME OUT FLAG
43          011706 032765 000100 000014    BIT #CT.TM1,C.FLG(R5) ;SET THE PROPER TIMEOUT BIT
44          011714 001401             BEQ 1$                  ;AND STATUS REQUESTED BIT
45          011716 006300             ASL RO                 ;BUILD GET DUST STATUS COMMAND
46          011720 052700 000040             1$: BIS #CT.STA,RO      ;MARK COMMAND TO UDA
47          011724 050065 000014             BIS RO,C.FLG(R5)        ;TELL UDA COMMAND IS THERE
48          011730 012700 000001             MOV #OP.GDS,RO
49          011734 004737 015214             CALL BLDCMD
50          011740 012764 100000 000012       MOV #RG.OWN,HC.CCT(R4)
51          011746 005775 000000             TST @R5
52          011752 000137 012426             JMP RSPOU4

```

CZUDEBO UDA-50 DISK FORMATTER MACRO V04.00 14-APR-82 16:50:39 PAGE 60-1
GLOBAL SUBROUTINES SECTION

SEQ 0067

53 011756

RSPNTO:

C 6

GLOBAL SUBROUTINES SECTION

```

1 ;SWITCH TO NEXT CONTROLLER
2
3 011756 005737 002200 RSPNXT: TST UFREEZ :FROZEN TO ONE UNIT?
4 011762 001264 BNE RESPCT :STAY THERE IF SO
5 011764 062705 000054 ADD #C.SIZE,R5 :MOVE TO NEXT TABLE
6 011770 005337 002176 DEC UCNT :CHECK IF MORE CONTROLLERS
7 011774 001257 BNE RESPCT :LOOK AT NEXT CONTROLLER
8 011776 000651 BR RESPDM :LOOK AT FIRST CONTROLLER AGAIN
9
10 ;REMOVE A CONTROLLER FROM TESTING
11
12 012000 005065 000014 RSPDRP: CLR C.FLG(R5) :CLEAR PROGRAM RUNNING
13 012004 005037 002200 CLR UFREEZ
14 012010 010504 MOV R5,R4
15 012012 062704 000020 ADD #C.DR0,R4
16 012016 012702 000010 MOV #8,,R2
17 012022 012403 1$: MOV (R4)+,R3
18 012024 001420 BEQ 3$
19 012026 005763 000002 TST D.UNIT(R3)
20 012032 ASSUME DT.AVL EQ BIT15
21 012032 100003 BPL 2$
22 012034 005302 DEC R2
23 012036 001371 BNE 1$
24 012040 000412 BR 3$
25 012042 052763 100000 000002 2$: BIS #DT.AVL,D.UNIT(R3)
26 012050 005302 DEC R2
27 012052 001405 BEQ 3$
28 012054 005714 TST (R4)
29 012056 001403 BEQ 3$
30 012060 004737 015012 CALL LOADDM :START DM PROGRAM AGAIN
31 012064 001223 BNE RESPCT
32 012066 005337 002174 3$: DEC URNING :REDUCE RUNNING CONTROLLERS COUNT
33 012072 001331 BNE RSPNXT :IF ANY STILL RUNNING, LOOK AT THEM
34 012074 000207 RETURN :ELSE RETURN TO TEST SECTION
35
36 012076 RSPTOE: ERRDF 31.,ERR031 :REPORT TIMEOUT ERROR
012076 104455 TRAP C$ERDF
012100 000037 .WORD 31
012102 000000 .WORD 0
012104 011022 .WORD ERR031
37 012106 000734 BR RSPDRP :DROP CONTROLLER FROM TESTING

```

1 :CONTROLLER HAS RESPONDED, LOOK AT MESSAGE PACKET
2
3 :CHECK FOR PROPER OPCODE IN END PACKET
4
5 012110 012700 000204 RSPIN: MOV #OP.END+OP.SSD,R0 :GET SEND DATA END PACKET OPCODE
6 012114 032765 000020 000014 BIT #CT.REQ,C.FLG(R5) :LOOK IF SEND DATA OR RECEIVE DATA
7 012122 001402 BEQ RSPMWR
8 012124 012700 000205 MOV #OP.END+OP.RSD,R0 :CHANGE TO RECEIVE DATA END PACKET OPCODE
9 012130 120064 000030 RSPMWR: CMPB R0,HC.MPK+P.OPCD(R4) :COMPARE TO OPCODE IN END PACKET
10 012134 001145 BNE RSPERR
11
12 :LOOK AT STATUS CODE
13
14 012136 032764 000037 000032 BIT #ST.MSK,HC.MPK+P.STS(R4) :CHECK FOR STATUS CODE ST.SUC (ZERO)
15 012144 001004 BNE RSPERW
16
17 :CHECK FOR EXPECTED REFERENCE NUMBER
18
19 012146 026564 000052 000020 CMP C.REF(R5),HC.MPK+P.CRF(R4) :CHECK IF CORRECT REF NUMBER
20 012154 001405 BEQ RSPPTW
21 012156 RSPERW: ERRDF 33.,ERR033 TRAP C\$ERDF
012156 104455 .WORD 33
012160 000041 .WORD 0
012162 000000 .WORD ERR033
012164 011052
22 012166 000704 BR RSPDRP :DROP UNIT FROM TESTING
23
24 :CHECK IF RESPONSE FROM SEND OR RECEIVE DATA COMMAND
25
26 012170 032765 000020 000014 RSPPTW: BIT #CT.REQ,C.FLG(R5) :CHECK IF RESPONSE FROM DM PROGRAM
27 012176 001463 RSPOU: BEQ RSPOUT :LOOK AT REQUEST NUMBER IF SO

GLOBAL SUBROUTINES SECTION

```

1          ;MAINTENANCE READ END PACKET RECEIVED, LOOK AT REQUEST FROM DM PROGRAM
2
3 012200 016401 000306
4 012204 042701 007777
5 012210 001403
6 012212 020127 060000
7 012216 101405
8 012220
  012220 104455
  012222 000040
  012224 000000
  012226 011034
9 012230 000663
10
11 012232 016403 000034
12 012236 162703 000002
13 012242 012700 000004
14 012246 004737 015214
15 012252 012700 000164
16 012256 004737 015356
17 012262 010402
18 012264 062704 000122
19 012270 042724 170000
20 012274 000301
21 012276 006201
22 012300 006201
23 012302 006201
24 012304 010100
25 012306 005001
26 012310 004770 012574
27 012314 001231
28
29 012316 016504 000016
30 012322 032701 000001
31 012326 001401
32 012330 005201
33 012332 010164 000120
34 012336 100003
35 012340 042765 000020 000014
36
37          ;SEND COMMAND BACK TO UDA
38
39 012346 042765 000350 000014
40 012354 032765 000020 000014
41 012362 001014
42
43 012364 012700 000005
44 012370 004737 015214
45 012374 012700 000306
46 012400 004737 015356
47 012404 052765 000020 000014
48 012412 000403
49
50 012414 042765 000020 000014
51 012422
52 012422 004737 015300
53 012426 016500 000044

RSPPPT2: MOV HC.BF2(R4),R1      ;GET REQUEST NUMBER
          BIC #^C<DU.TYP>,R1
          BEQ 1$              ;CHECK TYPE
          CMP R1,#DU.SPC       ;IF ZERO, ERROR
          BLOS RSPPT3           ;CHECK IF IN EXPECTED RANGE
1$:     ERRDF 32.,ERR032        ;BAD REQUEST NUMBER
          TRAP    CSERDF
          .WORD   32
          .WORD   0
          .WORD   ERR032

          BR RSPDRP            ;DROP UNIT FROM TESTING

RSPPPT3: MOV HC.MPK+P.BCNT(R4),R3  ;GET BYTE COUNT OF CHARACTERS RECEIVED IN R3
          SUB #2,R3             ;(FIRST TWO CHARACTERS ARE TYPE WORD)
          MOV #OP.SSD,RO         ;BUILD A SEND DATA COMMAND PACKET
          CALL BLDCMD            ;FOR ANSWER TO DM PROGRAM
          MOV #HC.BF1,RO          ;POINT TO BUFFER IN PACKET
          CALL CLRBUF             ;AND CLEAR BUFFER
          MOV R4,R2               ;R2 POINTS TO SEND BUFFER
          ADD #HC.BSZ,R4          ;R4 POINTS TO CHARACTERS IN RECEIVE BUFFER
          BIC #DU.TYP,(R4)+       ;CLEAR TYPE FIELD IN BUFFER
          SWAB R1                ;GET TYPE RIGHT JUSTIFIED
          ASR R1                 ;TIMES TWO

          CALL @RSPDSP-2(RO)      ;COPY MESSAGE TYPE TO RO
          CLR R1                 ;R1 CONTAINS ZERO SEND BYTE COUNT
          BNE RSPDRP              ;CALL REQUESTED ROUTINE
                                ;ROUTINE RETURNS Z CLEAR TO DROP UNIT FROM TESTING
                                ;Z SET IF UNIT TO CONTINUE RUNNING
                                ;GET RING ADDRESS
                                ;LOOK AT CHARACTER COUNT TO SEND TO DUP PROGRAM
                                ;IF AN ODD COUNT
                                ;INCREASE BY ONE
                                ;PUT CHARACTER COUNT IN COMMAND PACKET
                                ;IF NEGATIVE BYTE COUNT RETURNED
                                ;DON'T SEND ANY DATA TO UDA

          MOV C.RING(R5),R4
          BIT #1,R1
          BEQ 1$              ;SEND COMMAND BACK TO UDA
          INC R1
          MOV R1,HC.CPK+P.BCNT(R4)
          BPL RSPOUT             ;CLEAR MESSAGE RECEIVED FLAG
          BIC #CT.REQ,C.FLG(R5)  ;CHECK WHICH COMMAND TO SEND
          BNE RSPOU2              ;BRANCH IF RESPONSE TO REQUEST

          MOV #OP.RSD,RO          ;BUILD RECEIVE DATA COMMAND
          CALL BLDCMD            ;POINT TO MESSAGE BUFFER
          MOV #HC.BF2,RO          ;AND CLEAR IT
          CALL CLRBUF             ;SET REQUEST BIT
          BIS #CT.REQ,C.FLG(R5)
          BR RSPOU3

          RSPOU2: BIC #CT.REQ,C.FLG(R5) ;CLEAR REQUEST BIT
          RSPOU3: CALL SNDCMD        ;SEND COMMAND TO UDA
          RSPOU4: MOV C.TOT(R5),RO  ;SET TIMEOUT

```

54 012432	010501		MOV R5,R1	
55 012434	062701	000040	ADD #C.TO,R1	:PUT TIME IN CONTROLLER TABLE
56 012440	004737	015612	CALL SETTO	
57 012444	000137	011756	JMP RSPNXT	:NOW WAIT FOR END PACKET
58 012450	122764	000201	RSPERR: CMPB #OP.END+OP.GDS,HC.MPK+P.OPCD(R4)	;SEE IF GET DUST STATUS OPCODE
59 012456	001237		BNE RSPERW	
60 012460	132764	000010	000037	BITB #DF.ACT,HC.MPK+P.DFLG(R4) :IF DUST NO LONGER RUNNING
61 012466	001603		BEQ RSPTOE	: REPORT ERROR
62 012470	042765	000050	000014	BIC #CT.STA+CT.MSG,C.FLG(R5) :CLEAR CONTROL BITS
63 012476	032765	000200	000014	BIT #CT.TM2,C.FLG(R5) :IF AT SECOND TIMEOUT
64 012504	001413		BEQ 1\$	
65 012506	026465	000040	000046	CMP HC.MPK+P.DPI(R4),C.PRI(R5) :COMPARE PROGRESS INDICATOR
66 012514	001004		BNE 2\$	
67 012516	026465	000042	000050	CMP HC.MPK+P.DPI+2(R4),C.PRI+2(R5) :COMPARE PROGRESS INDICATOR
68 012524	001422		BEQ 4\$:REPORT ERROR IF NOT CHANGED
69 012526	042765	000200	000014	2\$: BIC #CT.TM2,C.FLG(R5) :CLEAR TIMEOUT 2 FLAG
70 012534	032765	000100	000014	1\$: BIT #CT.TM1,C.FLG(R5) :IF AT FIRST TIMEOUT
71 012542	001406		BEQ 3\$	
72 012544	016465	000040	000046	MOV HC.MPK+P.DPI(R4),C.PRI(R5) :GET COPY OF PROGRESS INDICATOR
73 012552	016465	000042	000050	MOV HC.MPK+P.DPI+2(R4),C.PRI+2(R5) :GET COPY OF PROGRESS INDICATOR
74 012560	012764	140000	000006	3\$: MOV #RG.OWN+RG.FLG,HC.MCT(R4) :GIVE MESSAGE BUFFER BACK TO UDA
75 012566	000137	011756		JMP RSPNXT
76 012572	000137	012076		4\$: JMP RSPTOE

1

:RESPONSE REQUEST DISPATCH TABLE

2

3 012576 012612
4 012600 012664
5 012602 013036
6 012604 013126
7 012606 013136
8 012610 013146
9 000006

RSPDSP: .WORD QUEST
.WORD DQUEST
.WORD INFO
.WORD TERM
.WORD ERRTRM
.WORD SPEC1
DSPSIZ=<.-RSPDSP>/2

:QUESTION
:QUESTION WITH DEFAULT ANSWER
:INFORMATION MESSAGE FOR OPERATOR
:NORMAL TERMINATION
:FATAL ERROR TERMINATION
:SPECIAL
:LEGAL NUMBERS ARE LOWER THAN THIS

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38

:NORMAL DUP RECEIVE DATA BUFFER DESCRIPTION

:BYTE OFFSET FROM
:START OF BUFFER

	TYPE !	MESSAGE NUMBER
0		DATA BYTES
2		DATA BYTES
4		DATA BYTES
6		DATA BYTES
8		DATA BYTES
10		DATA BYTES
12		DATA BYTES
14		DATA BYTES
16		DATA BYTES
18		DATA BYTES
20		DATA BYTES
22		DATA BYTES
.		.
.		.
.		.
80		DATA BYTES

USED TO SELECT ROUTINE
R4 CONTAINS THIS ADDRESS

1 ;NORMAL DUP SEND DATA BUFFER DESCRIPTION GIVEN IN RESPONSE TO ABOVE PACKET
2
3 :BYTE OFFSET FROM
4 :START OF BUFFER
5 0 +-----+
6 2 | DATA BYTES |
7 4 +-----+
8 6 | DATA BYTES |
9 8 +-----+
10 10 | DATA BYTES |
11 12 +-----+
12 14 | DATA BYTES |
13 16 +-----+
14 18 | DATA BYTES |
15 20 +-----+
16 22 | DATA BYTES |
17 +-----+
18 . .
19 . .
20 . .
21 . .
22 . .
23 . .
24 . .
25 . .
26 . .
27 . .
28 . .
29 . .
30 . .
31 . .
32 . .
33 . .
34 . .
35 . .
36 . .
37 . .
38 . .
80 +-----+
| DATA BYTES |
+-----+

R2 CONTAINS THIS ADDRESS

```

1 :MESSAGE TYPE 1
2 :ANSWER QUESTION FOR DUP PROGRAM
3
4 :INPUT:
5   R5 - ADDRESS OF CONTROLLER TABLE
6   R4 - POINTER TO DATA IN RECEIVE BUFFER
7   R3 - CHARACTER COUNT IN RECEIVE BUFFER
8   R2 - POINTER TO SEND BUFFER (BUFFER IS CLEARED)
9   R1 - ZERO
10
11 :OUTPUT:
12   R1 - COUNT OF CHARACTERS IN SEND BUFFER
13   Z SET TO CONTINUE RUNNING DUP PROGRAM
14   Z CLEAR TO STOP THE DUP PROGRAM
15
16 012612 004737 013300 QUEST: CALL GTDRV T :GET POINTER TO DRIVE TABLE
17 012616 062700 000004           ADD #D.SERN, R0 :BUMP POINTER TO SERIAL NUMBER
18 012622 014403               MOV -(R4), R3 :GET QUESTION NUMBER
19 012624 001411               BEQ QUE0 :BRANCH IF QUESTION NUMBER 0
20 012626 020327 000007           CMP R3, #7 :IF NOT, SEE IF QUESTION NUMBER 7
21 012632 001410               BEQ QUE7
22 012634 104455               ERRDF 100.,ERR100 :ANY OTHER NUMBER IS AN ERROR
23 012634 104455               TRAP    CSERDF
24 012636 000144               .WORD   100
25 012640 000000               .WORD   0
26 012642 011114               .WORD   ERR100
27 012644 000244
28 012646 000207             CLZ      :CLEAR Z TO STOP DUP PROGRAM
29
30 012650 012700 003312             RETURN
31 012654 005201 QUEST: MOV #DATE0,R0 :POINT TO DATE STRING
32 012654 005201 QUE7: INC R1 :COUNT THE CHARACTERS
33 012656 112022               MOVB (R0)+,(R2)+ : AND PUT THEM IN OUTPUT BUFFER
34 012660 001375               BNE QUEL : UNTIL A NUL CHARACTER FOUND
35 012662 000207               RETURN :RETURN WITH Z SET

```

GLOBAL SUBROUTINES SECTION

```

1      :MESSAGE TYPE 2
2      :ANSWER QUESTION FOR DUP PROGRAM WITH DEFAULT ANSWER
3      :INPUT:
4          R5 - ADDRESS OF CONTROLLER TABLE
5          R4 - POINTER TO DATA IN RECEIVE BUFFER
6          R3 - CHARACTER COUNT IN RECEIVE BUFFER
7          R2 - POINTER TO SEND BUFFER (BUFFER IS CLEARED)
8          R1 - ZERO
9
10     :OUTPUT:
11         R1 - COUNT OF CHARACTERS IN SEND BUFFER
12         Z SET TO CONTINUE RUNNING DUP PROGRAM
13         Z CLEAR TO STOP THE DUP PROGRAM
14
15
16 012664 004737 013300 DQUEST: CALL GTDRVT    ;GET DRIVE TABLE ADDRESS INTO R0
17 012670 014403           MOV -(R4),R3   ;GET QUESTION NUMBER
18 012672 020327 000006           CMP R3,#DQUESZ
19 012676 101035           BHI DQUEX
20 012700 006303           ASL R3
21 012702 000173 012706 DQUEJP: .WORD DQUEX    : 0 (NOT USED)
22 012706 012772           .WORD DQUNIT   : 1 ENTER UNIT NUMBER TO FORMAT
23 012710 012724           .WORD DQUEX    : 2 (NOT USED)
24 012712 012772           .WORD DQUEX    : 3 (NOT USED)
25 012714 012772           .WORD DQRFMT   : 4 USE EXISTING BAD SECTOR INFORMATION
26 012716 012776           .WORD DQRSTR   : 5 DOWN-LINE LOAD BAD SECTOR BLOCK INFORMATION
27 012720 013016           .WORD DQCONT   : 6 CONTINUE IF BAD BLOCK INFO INACCESSIBLE
28 012722 013026           DQUESZ=<. -DQUEJP>/2>-1
29 000006
30
31     ;ENTER UNIT NUMBER TO FORMAT
32
33 012724 010546 DQUNIT: PUSH R5           MOV R5,-(SP)
34 012726 005004           CLR R4
35 012730 011003           MOV (R0),R3   ;GET DRIVE NUMBER
36 012732           ASSUME D.DRV EQ 0
37 012732 012700 000012 DQUNL1: CALL DIVIDE
38 012736 004737 014754           MOV #10.,R0   ;RADIX 10.
39 012742 010546           PUSH R5           MOV R5,-(SP)
40 012744 005201           INC R1
41 012746 005703           TST R3
42 012750 001372           BNE DQUNL1
43 012752 010100           MOV R1,R0
44 012754 012605 DQUNL2: POP R5           MOV (SP)+,R5
45 012756 062705 000060           ADD #'0,R5
46 012762 110522           MOVB R5,(R2) +
47 012764 005300           DEC R0
48 012766 001372           BNE DQUNL2
49 012770 012605           POP R5           MOV (SP)+,R5
50 012772 000264 DQUEX: SEZ
51 012774 000207           RETURN
52
53 012776 032737 000003 003210 DQRFMT: BIT #SO.FMT,MODE

```

54 013004	001410			BEQ DQNO
55 013006	112712	000131	DQYES:	MOVB #'Y,(R2)
56 013012	005201			INC R1
57 013014	000766			BR DQUEX
58				
59 013016	032737	000010 003210	DQRSTR:	BIT #SO.STR,MODE
60 013024	001370			BNE DQYES
61 013026			DQCONT:	
62 013026	112712	000116	DQNO:	MOVB #'N,(R2)
63 013032	005201			INC R1
64 013034	000756			BR DQUEX

1 MESSAGE TYPE 3
2 PRINT INFORMATION FROM DUP PROGRAM
3
4 INPUT:
5 R5 - POINTER TO CONTROLLER TABLE
6 R4 - POINTER TO DATA IN RECEIVE BUFFER
7 R3 - CHARACTER COUNT IN RECEIVE BUFFER
8 R2 - POINTER TO SEND BUFFER (BUFFER IS CLEARED)
9 R1 - ZERO
10
11 OUTPUT:
12 R1 - BIT 15 SET TO PREVENT SENDING DATA TO DUP PROGRAM
13 Z SET TO CONTINUE RUNNING DUP PROGRAM
14
15 013036 016400 177776 INFO: MOV -2(R4),R0 ;GET MESSAGE NUMBER
16 013042 001417 BEQ INFOX ;IF ZERO, IGNORE IT
17 013044 020027 000100 CMP R0,#100 ;IF OCTAL 100
18 013050 001420 BEQ INFOE ; PRINT ERROR MESSAGE
19 013052 005737 002200 TST UFREEZ
20 013056 001007 BNE INFOP
21 013060 005237 002200 INC UFREEZ
22 013064 004737 013300 CALL GTDRV
23 013070 010002 MOV R0,R2
24 013072 004737 013324 CALL HEADER
25 013076 004737 013244 INFO: CALL MESG ;PRINT THE MESSAGE
26 013102 012701 100000 INFOX: MOV #BIT15,R1 ;RETURN A NEGATIVE BYTE COUNT
27 013106 000264 SEZ
28 013110 000207 RETURN ;RETURN WITH Z SET
29
30 013112 INFOE: ERRDF 101,,ERR101 ;ANSWER WAS REJECTED BY DUP PROGRAM
31 013112 104455 TRAP C\$ERDF
32 013114 000145 .WORD 101
33 013116 000000 .WORD 0
34 013120 011130 .WORD ERR101
35 013122 000244 CLZ ;RETURN WITH Z CLEAR TO STOP DUP PROGRAM
36 013124 000207 RETURN

1 :MESSAGE TYPE 4
2 :TERMINATION MESSAGE
3 :
4 :INPUT:
5 R5 - POINTER TO CONTROLLER TABLE
6 R4 - POINTER TO DATA IN RECEIVE BUFFER
7 R3 - CHARACTER COUNT IN RECEIVE BUFFER
8 R2 - POINTER TO SEND BUFFER (BUFFER IS CLEARED)
9 R1 - ZERO
10 :
11 :OUTPUT:
12 Z CLEAR TO TERMINATE DUP PROGRAM
13 :
14 013126 004737 013036 TERM: CALL INFO ;PRINT THE MESSAGE
15 013132 000244 CLZ RETURN ;RETURN Z CLEAR TO TERMINATE DUP PROGRAM
16 013134 000207

1 :MESSAGE TYPE 5
2
3 :ERROR TERMINATION MESSAGE
4
5 :INPUT:
6 R5 - POINTER TO CONTROLLER TABLE
7 R4 - POINTER TO DATA IN RECEIVE BUFFER
8 R3 - CHARACTER COUNT IN RECEIVE BUFFER
9 R2 - POINTER TO SEND BUFFER (BUFFER IS CLEARED)
10 R1 - ZERO
11 :OUTPUT:
12 Z CLEAR TO TERMINATE DUP PROGRAM
13
14 013136 004737 013036
15 013142 000244
16 013144 000207
ERRTRM: CALL INFO
CLZ
RETURN :RETURN Z CLEAR TO TERMINATE DUP PROGRAM

```

1      :MESSAGE TYPE 6
2      :SPECIAL TYPE - READ FCT BLOCK FROM FILE
3      :INPUT:
4          R5 - POINTER TO CONTROLLER TABLE
5          R4 - POINTER TO DATA IN RECEIVE BUFFER
6          R3 - CHARACTER COUNT IN RECEIVE BUFFER
7          R2 - POINTER TO SEND BUFFER (BUFFER IS CLEARED)
8          R1 - ZERO
9
10     :OUTPUT:
11         Z SET TO SEND DATA TO PROGRAM
12
13
14 013146 023714 003206   SPECL: CMP FCTNUM,(R4) ;SEE IF DESIRED BLOCK IS IN MEMORY
15 013152 001425           BEQ SPECLEX ; IF SO, SEND TO DUP PROGRAM
16 013154 002407           BLT SPECCLR ; IF LOWERED NUMBERED BLOCK IN MEMORY,
17                           ; GO READ NEXT BLOCK
18 013156 104435           SPECLC: CLOSE ;OTHERWISE, START READING FROM BEGINNING AGAIN
19 013160               OPEN #FNAME
20 013166 012700 003234           TRAP    CSCLOS
21 013174 012703 001000           MOV     #FNAME,RO
22 013200 012701 002206           TRAP    CSOPEN
23 013204 104426           SPECLR: MOV #512,,R3 ;GET BYTE COUNT IN A BLOCK
24 013206 110021           MOV #FCTBUF,R1 ;POINT TO STORAGE AREA
25 013210 103005           SPELL: GETBYTE (R1)+ ;READ THE FILE
26 013212 005303           BNCOMPLETE SPECLE ;PRINT ERROR IF NO MORE BYTES IN FILE
27 013214 001373           DEC R3 ;COUNT THE BYTES
28 013216 005237 003206           BNE SPELL
29 013222 000751           INC FCTNUM ;KEEP COUNT OF BLOCK IN MEMORY
30 013224 005212           BR SPECL
31 013226 012762 002206 000002   SPECLE: INC (R2) ;TELL DUP PROGRAM DATA NOT AVAILABLE
32 013234 012701 000006           SPECLEX: MOV #FCTBUF,2(R2) ;PUT ADDRESS OF DATA IN OUTPUT BUFFER
33 013240 000264           MOV #6,R1 ;SEND 3 WORDS TO DUP PROGRAM
34 013242 000207           SEZ
                           RETURN ;RETURN WITH Z SET TO SEND DATA TO DUP PROGRAM

```

E 7

```

1          ;PRINT A MESSAGE IN THE RECEIVE BUFFER FROM THE DUP PROGRAM
2
3          :INPUT:
4              R4 - POINTER TO DATA IN RECEIVE BUFFER
5              R3 - CHARACTER COUNT IN RECEIVE BUFFER
6
7          :OUTPUT:
8              R4 - POINTER TO CHARACTER AFTER MESSAGE IN RECEIVE BUFFER
9              R3 - ZERO
10             R1 - BIT 15 SET TO PREVENT SENDING DATA TO DUP PROGRAM
11             R0 - CONTENTS DESTROYED
12             Z SET TO CONTINUE RUNNING DUP PROGRAM
13
14      013244      112700    000015      MESG: PRINT #CR
15      013244      004737    014476      MOVBL #CR,R0
16      013250      004737    014476      CALL CPNT
17      013254      112400
18      013256      001405      1$:   MOVB (R4)+,R0      ;PRINT CHARACTERS FROM DUP PROGRAM
19      013260      020027    000012      BEQ 2$      ; DISCARDING LF AND NULL CHARACTERS
20      013264      001402
21      013266      004737    014476      CMP R0,#12
22      013266      004737    014476      BEQ 2$      PRINT R0
23      013272      005303
24      013274      003367      2$:   DEC R3      ;COUNT THE CHARACTERS
25      013276      000207      BGT 1$
26
27      RETURN

```



```

1          :HEADER
2          :PRINT A HEADER IN FRONT OF EACH MESSAGE FROM DUP PROGRAM.
3          :A UDA ADDRESS IS PRINTED IF MORE THAN ONE JDA IS IN HARDWARE P-TABLE.
4          :A RUNTIME IS PRINTED IF A CLOCK IS BEING USED TO TIME PROGRAM EXECUTION.
5
6          :INPUT:   R5 - POINTER TO CONTROLLER TABLE
7          :OUTPUT:  R0 - POINTER TO DRIVE TABLE
8          :           PRINTED MESSAGE
9
10         013324 022737 000001 002012 HEADER: CMP #1,L$UNIT      ;IF MORE THAN ONE UNIT BEING TESTED
11         013332 001411
12         013334 011246
13         013334 011546
14         013336 011546
15         013340 016246 000002
16         013344 004137 014650
17         013350 003743
18         013352 000006
19         013354 000407
20         013354 005737 003212
21         013356 001406
22         013362 112700 000015
23         013364 004737 014476
24         013370 004737 016636
25         013400 000207
26
27         013334 011246
28         013336 011546
29         013340 016246 000002
30         013344 004137 014650
31         013350 003743
32         013352 000006
33
34         013354 000407
35         013354 005737 003212
36         013356 001406
37         013362 112700 000015
38         013364 004737 014476
39         013370 004737 016636
40         013400 000207
41
42         013334 011246
43         013336 011546
44         013340 016246 000002
45         013344 004137 014650
46         013350 003743
47         013352 000006
48
49         013354 000407
50         013354 005737 003212
51         013356 001406
52         013362 112700 000015
53         013364 004737 014476
54         013370 004737 016636
55         013400 000207
56
57         013334 011246
58         013336 011546
59         013340 016246 000002
60         013344 004137 014650
61         013350 003743
62         013352 000006
63
64         013354 000407
65         013354 005737 003212
66         013356 001406
67         013362 112700 000015
68         013364 004737 014476
69         013370 004737 016636
70         013400 000207
71
72         013334 011246
73         013336 011546
74         013340 016246 000002
75         013344 004137 014650
76         013350 003743
77         013352 000006
78
79         013354 000407
80         013354 005737 003212
81         013356 001406
82         013362 112700 000015
83         013364 004737 014476
84         013370 004737 016636
85         013400 000207
86
87         013334 011246
88         013336 011546
89         013340 016246 000002
90         013344 004137 014650
91         013350 003743
92         013352 000006
93
94         013354 000407
95         013354 005737 003212
96         013356 001406
97         013362 112700 000015
98         013364 004737 014476
99         013370 004737 016636
100        013400 000207
101
102        013334 011246
103        013336 011546
104        013340 016246 000002
105        013344 004137 014650
106        013350 003743
107        013352 000006
108
109        013354 000407
110        013354 005737 003212
111        013356 001406
112        013362 112700 000015
113        013364 004737 014476
114        013370 004737 016636
115        013400 000207
116
117        013334 011246
118        013336 011546
119        013340 016246 000002
120        013344 004137 014650
121        013350 003743
122        013352 000006
123
124        013354 000407
125        013354 005737 003212
126        013356 001406
127        013362 112700 000015
128        013364 004737 014476
129        013370 004737 016636
130        013400 000207
131
132        013334 011246
133        013336 011546
134        013340 016246 000002
135        013344 004137 014650
136        013350 003743
137        013352 000006
138
139        013354 000407
140        013354 005737 003212
141        013356 001406
142        013362 112700 000015
143        013364 004737 014476
144        013370 004737 016636
145        013400 000207
146
147        013334 011246
148        013336 011546
149        013340 016246 000002
150        013344 004137 014650
151        013350 003743
152        013352 000006
153
154        013354 000407
155        013354 005737 003212
156        013356 001406
157        013362 112700 000015
158        013364 004737 014476
159        013370 004737 016636
160        013400 000207
161
162        013334 011246
163        013336 011546
164        013340 016246 000002
165        013344 004137 014650
166        013350 003743
167        013352 000006
168
169        013354 000407
170        013354 005737 003212
171        013356 001406
172        013362 112700 000015
173        013364 004737 014476
174        013370 004737 016636
175        013400 000207
176
177        013334 011246
178        013336 011546
179        013340 016246 000002
180        013344 004137 014650
181        013350 003743
182        013352 000006
183
184        013354 000407
185        013354 005737 003212
186        013356 001406
187        013362 112700 000015
188        013364 004737 014476
189        013370 004737 016636
190        013400 000207
191
192        013334 011246
193        013336 011546
194        013340 016246 000002
195        013344 004137 014650
196        013350 003743
197        013352 000006
198
199        013354 000407
200        013354 005737 003212
201        013356 001406
202        013362 112700 000015
203        013364 004737 014476
204        013370 004737 016636
205        013400 000207
206
207        013334 011246
208        013336 011546
209        013340 016246 000002
210        013344 004137 014650
211        013350 003743
212        013352 000006
213
214        013354 000407
215        013354 005737 003212
216        013356 001406
217        013362 112700 000015
218        013364 004737 014476
219        013370 004737 016636
220        013400 000207
221
222        013334 011246
223        013336 011546
224        013340 016246 000002
225        013344 004137 014650
226        013350 003743
227        013352 000006
228
229        013354 000407
230        013354 005737 003212
231        013356 001406
232        013362 112700 000015
233        013364 004737 014476
234        013370 004737 016636
235        013400 000207
236
237        013334 011246
238        013336 011546
239        013340 016246 000002
240        013344 004137 014650
241        013350 003743
242        013352 000006
243
244        013354 000407
245        013354 005737 003212
246        013356 001406
247        013362 112700 000015
248        013364 004737 014476
249        013370 004737 016636
250        013400 000207
251
252        013334 011246
253        013336 011546
254        013340 016246 000002
255        013344 004137 014650
256        013350 003743
257        013352 000006
258
259        013354 000407
260        013354 005737 003212
261        013356 001406
262        013362 112700 000015
263        013364 004737 014476
264        013370 004737 016636
265        013400 000207
266
267        013334 011246
268        013336 011546
269        013340 016246 000002
270        013344 004137 014650
271        013350 003743
272        013352 000006
273
274        013354 000407
275        013354 005737 003212
276        013356 001406
277        013362 112700 000015
278        013364 004737 014476
279        013370 004737 016636
280        013400 000207
281
282        013334 011246
283        013336 011546
284        013340 016246 000002
285        013344 004137 014650
286        013350 003743
287        013352 000006
288
289        013354 000407
290        013354 005737 003212
291        013356 001406
292        013362 112700 000015
293        013364 004737 014476
294        013370 004737 016636
295        013400 000207
296
297        013334 011246
298        013336 011546
299        013340 016246 000002
300        013344 004137 014650
301        013350 003743
302        013352 000006
303
304        013354 000407
305        013354 005737 003212
306        013356 001406
307        013362 112700 000015
308        013364 004737 014476
309        013370 004737 016636
310        013400 000207
311
312        013334 011246
313        013336 011546
314        013340 016246 000002
315        013344 004137 014650
316        013350 003743
317        013352 000006
318
319        013354 000407
320        013354 005737 003212
321        013356 001406
322        013362 112700 000015
323        013364 004737 014476
324        013370 004737 016636
325        013400 000207
326
327        013334 011246
328        013336 011546
329        013340 016246 000002
330        013344 004137 014650
331        013350 003743
332        013352 000006
333
334        013354 000407
335        013354 005737 003212
336        013356 001406
337        013362 112700 000015
338        013364 004737 014476
339        013370 004737 016636
340        013400 000207
341
342        013334 011246
343        013336 011546
344        013340 016246 000002
345        013344 004137 014650
346        013350 003743
347        013352 000006
348
349        013354 000407
350        013354 005737 003212
351        013356 001406
352        013362 112700 000015
353        013364 004737 014476
354        013370 004737 016636
355        013400 000207
356
357        013334 011246
358        013336 011546
359        013340 016246 000002
360        013344 004137 014650
361        013350 003743
362        013352 000006
363
364        013354 000407
365        013354 005737 003212
366        013356 001406
367        013362 112700 000015
368        013364 004737 014476
369        013370 004737 016636
370        013400 000207
371
372        013334 011246
373        013336 011546
374        013340 016246 000002
375        013344 004137 014650
376        013350 003743
377        013352 000006
378
379        013354 000407
380        013354 005737 003212
381        013356 001406
382        013362 112700 000015
383        013364 004737 014476
384        013370 004737 016636
385        013400 000207
386
387        013334 011246
388        013336 011546
389        
```


1 ;CONTROL CHARACTER WAS A QUOTE. PRINT ALL CHARACTERS TO THE NEXT QUOTE.
2
3 013452 112200 000042 CON.QU: MOV B (R2)+,R0 :GET CHARACTER
4 013454 120027 000042 CMPB R0,""
5 013460 001403 BEQ CON.QX :CHECK IF ENDING QUOTE
6 013462 004737 014476 PRINT R0 :IF SO, GO GET NEXT CONTROL CHARACTER
7 013466 000771 BR CON.QU :PRINT THE CHARACTER
8 013470 000207 CON.QX: RETURN CALL CPNT :CONTINUE PRINTING
9
10 ;CONTROL CHARACTER WAS AN A. PRINT ASCII CHARACTERS FROM PARAMETERS.
11
12 013472 004737 014156 CON.A: CALL GETCNT :GET COUNT OF CHARACTERS
13 013476 112400 014476 CON.A1: PRINT (R4)+ :PRINT THE CHARACTER
14 013476 004737 014476 MOV B (R4)+,R0
15 013500 004737 014476 CALL CPNT :COUNT THE CHARACTERS
16 013504 005301 DEC R1 :PRINT UNTIL COUNT REACHES ZERO
17 013506 001373 BNE CON.A1 :CHECK IF R4 NOW ODD
18 013510 032704 000001 BIT #1,R4
19 013514 001401 BEQ CON.A2 :IF SO, INCREMENT TO NEXT EVEN ADDRESS
20 013516 005204 INC R4 :NOW GET NEXT CONTROL CHARACTER
21 013520 000207 CON.A2: RETURN
22
23 013522 012701 000012 CON.D: MOV #10.,R1 :LOAD RADIX
24 013526 004737 014234 CALL PNTNUM :PRINT NUMBER
25 013532 000207 RETURN :NOW GET NEXT CONTROL CHARACTER
26
27 ;CONTROL CHARACTER WAS AN H. PRINT HEX NUMBER.
28
29 013534 012701 000020 CON.H: MOV #16.,R1 :LOAD RADIX
30 013540 004737 014234 CALL PNTNUM :PRINT NUMBER
31 013544 000207 RETURN :NOW GET NEXT CONTROL CHARACTER

```

1           ;CONTROL CHARACTER WAS AN O. PRINT OCTAL NUMBER.
2
3 013546 012701 000010      CON.O: MOV #8.,R1          ;LOAD RADIX
4 013552 004737 014234      CALL PNTRNUM        ;PRINT NUMBER
5 013556 000207      RETURN      ;NOW GET NEXT CONTROL CHARACTER
6
7           ;CONTROL CHARACTER WAS AN N. PRINT NEW LINE SEQUENCE.
8
9 013560 004737 014156      CON.N: CALL GETCNT    ;GET COUNT
10 013564 112700 000015     CON.N1: PRINT #CR      ;PRINT NEW LINE SEQUENCE
11 013564 004737 014476      DEC R1             ;MOVB #CR,RO
12 013570 000207      BNE CON.N1      CALL CPNT
13 013574 005301      RETURN      ;COUNT THE SEQUENCES
14 013576 001372      ;NOW GET NEXT CONTROL CHARACTER
15 013600 000207
16
17 013602 004737 014156      CON.R: CALL GETCNT    ;GET ROUTINE NUMBER
18 013606 020127 000011      CMP R1,#ERRRSZ    ;CHECK IF DEFINED ROUTINE NUMBER
19 013612 101004      BHI CON.R1
20 013614 060101      ADD R1,R1
21 013616 004771 013660      CALL @ERRRTB-2(R1) ;DOUBLE COUNT TO GET WORD INDEX
22 013622 000207      RETURN      ;CALL ROUTINE
23 013624 004137 014650      CON.R1: PNTF ERRME1 ;NOW GET NEXT CONTROL CHARACTER
24 013624 003654      JSR R1,LPNTF    ;REPORT BAD MESSAGE STRING
25 013630 000000      .WORD ERRME1
26 013632 000000      .WORD PNT.CT
27 013634 012601      POP R1       ;FIX THE STACK
28 013636 000207      RETURN      ;MOV (SP)+,R1
29
30 013640 004737 014156      CON.S: CALL GETCNT    ;GET COUNT
31 013644 112700 000040     CON.S1: PRINT <#>      ;PRINT A SPACE
32 013650 004737 014476      DEC R1             ;MOVB #' ,RO
33 013654 005301      BNE CON.S1      CALL CPNT
34 013656 001372      RETURN      ;COUNT THE SPACES
35 013660 000207      ;NOW GET NEXT CONTROL CHARACTER

```

```
1          ;ERROR ROUTINE DISPATCH TABLE
2
3 013662 013736      ERRRTB: .WORD CALRE           ;NOT USED
4 013664 013736      .WORD CALRE           ;NOT USED
5 013666 013736      .WORD CALRE           ;NOT USED
6 013670 013750      .WORD CALR4            ;PRINT BASIC LINE WITHOUT UDA ADDRESS
7 013672 014024      .WORD CALR5            ;PRINT BASIC LINE WITH UDA ADDRESS
8 013674 014102      .WORD CALR6            ;CALL ALTERNATE PRINT STRING IN PDP-11 MEMORY
9 013676 014116      .WORD CALR7            ;PRINT "REPLACE UDA MODULE M7161"
10 013700 014134     .WORD CALR8            ;PRINT " UDASA CONTAINS XXXXXX"
11 013702 014152     .WORD CALR9            ;REPRINT LAST NUMBER
12 000C11              ERRRSZ=<.-ERRRTB>/2
13
14          ;BUILD TWO TABLES
15          ;    FIRST CONTAINING CONTROL CHARACTERS
16          ;    SECOND CONTAINING ROUTINE ADDRESSES
17
18          .MACRO BUILD
19          ENTRY ",CON.QU
20          ENTRY A,CON.A
21          ENTRY D,CON.D
22          ENTRY H,CON.H
23          ENTRY O,CON.O
24          ENTRY N,CON.N
25          ENTRY R,CON.R
26          ENTRY S,CON.S
27          .ENDM
```

```
1          ;HERE IS FIRST TABLE
2
3          .MACRO ENTRY ARG1,ARG2
4              .LIST
5                  .BYTE ''ARG1
6                  .NLIST
7
8          .ENDM
9
10         013704      042        ERRC:    BUILD
11         013704      101        .BYTE  ''
12         013705      104        .BYTE  'A
13         013706      104        .BYTE  'D
14         013707      110        .BYTE  'H
15         013710      117        .BYTE  'O
16         013711      116        .BYTE  'N
17         013712      122        .BYTE  'R
18         013713      123        .BYTE  'S
19         013714      000        .BYTE  0
20
21         013714      000        .EVEN
22
23         ;FOLLOW WITH A NULL BYTE
24
25         ;HERE IS SECOND TABLE
26
27         .MACRO ENTRY ARG1,ARG2
28             .LIST
29                 .WORD ARG2
30                 .NLIST
31
32         .ENDM
33
34         013716      013452     ERRD:    BUILD
35         013716      013452     .WORD  CON.QU
36         013720      013472     .WORD  CON.A
37         013722      013522     .WORD  CON.D
38         013724      013534     .WORD  CON.H
39         013726      013546     .WORD  CON.O
40         013730      013560     .WORD  CON.N
41         013732      013602     .WORD  CON.R
42         013734      013640     .WORD  CON.S
```

1 ;PRE-PROGRAMMED ROUTINES 1, 2 AND 3
2 ;NOT USED - PRINTS ERROR MESSAGE
3
4 013736 004137 014650 CALRE: PNTF ERRME1 :PRINT ERROR MESSAGE
 013736 003654
 013742 000000
 013744 000207 RETURN
5
JSR R1,LPNTF
.WORD ERRME1
.WORD PNT.CT

1 :PRE-PROGRAMMED ROUTINE 4
2 :PRINT BASIC LINE FOR HOST PROGRAM ERROR WITHOUT UDA ADDRESS
3 :THEN SWITCH TO EXTENDED FORMAT
4
5 013750 CALR4: PNTB BASLN,#BASNO,#BAS,#BAS,
6 013750 012746 004137 MOV #BAS,-(SP)
7 013754 012746 004137 MOV #BAS,-(SP)
8 013760 012746 004137 MOV #BAS,-(SP)
9 013764 012746 004064 MOV #BASNO,-(SP)
0 013770 004137 014660 JSR R1,LPNTB
1 013774 004140 .WORD BASLN
2 013776 000010 .WORD PNT.CT
3
4 014000 004737 016636 CALL RNTIME
5 014004 012700 000015 PRINT #CR
6 014004 112700 000015 MOVB #CR,RO
7 014010 004737 014476 CALL CPNT
8 014014 012737 014576 003226 MOV #PX,PTYPE
9 014022 000207 RETURN

1 ;PRE-PROGRAMMED ROUTINE 5
2 ;PRINT BASIC LINE FOR HOST PROGRAM ERROR WITH UDA ADDRESS
3 ;THEN SWITCH TO EXTENDED FORMAT
4
5 014024 012746 004137 CALR5: PNTB BASLN,#BASNO,#BASL2,(R5),#BAS,#BAS
6 014024 012746 004137 MOV #BAS,-(SP)
7 014030 012746 004137 MOV #BAS,-(SP)
8 014034 011546 004137 MOV (R5),-(SP)
9 014036 012746 004103 MOV #BASL2,-(SP)
014042 012746 004064 MOV #BASNO,-(SP)
014046 004137 014660 JSR R1,LPNTB
014052 004140 .WORD BASLN
014054 000012 .WORD PNT.CT
014056 004737 016636 CALL RNTIME
014062 112700 000015 PRINT #CR
014066 004737 014476 MOVB #CR,RO
014072 012737 014576 003226 CALL CPNT
9 014100 000207 RETURN

```

1          ;PRE-PROGRAMMED ROUTINE 6
2          ;CALL ALTERNATE PRINT ROUTINE IN PDP-11 MEMORY
3
4 014102      CALR6: PUSH R2           ;SAVE CURRENT STRING POINTER
5 014102      010246                 MOV R2,-(SP)
6 014104      012402
7 014106      004737     013402      MOV (R4)+,R2           ;GET NEW STRING POINTER
8 014112      012602                 CALL OSTRNG          ;OUTPUT USING THIS STRING
9 014114      000207                 POP R2              ;GET OLD POINTER BACK
10          RETURN                  MOV (SP)+,R2         ;NOW CONTINUE THE OLD STRING

```

```
1          ;PRE-PROGRAMMED ROUTINE 7
2          ;PRINT 'REPLACE UDA MODULE M7161'
3
4 014116      CALR7: PUSH R2
5 014116      MOV R2,-(SP)
6 014120      010246
7 014120      012702  010204
8 014124      004737  013402
9 014130      MOV #XFRU,R2
10 014130     CALL OSTRNG
11 014132     POP R2
12 014132     RETURN
13 000207
```

1 ;PRE-PROGRAMMED ROUTINE 8
2 ;PRINT " UDASA CONTAINS XXXXXX"
3
4 014134 010246 CALR8: PUSH R2 MOV R2,-(SP)
5 014136 012702 010153 MOV #XSA,R2
6 014142 004737 013402 CALL OSTRNG
7 014146 012602 POP R2 MOV (SP)+,R2
8 014150 000207 RETURN

1 : REPRINT LAST NUMBER
2 : R4 -> TABLE
3 014152 005744 CALR9: TST -(R4)
4 014154 000207 RETURN

GLOBAL SUBROUTINES SECTION

```

1      :GETCNT
2
3      :GET COUNT IN NEXT CHARACTERS OF STRING POINTED TO BY R2.
4      :NUMBER WILL BE IN DECIMAL. IF NO NUMBER, RETURN A
5      :DEFAULT OF 1.
6
7      :INPUTS:
8          R2 - POINTER TO ASCII STRING
9
10     :OUTPUTS:
11         R1 - NUMBER READ OR A ONE
12         R2 - POINTING TO CHARACTER AFTER NUMBER
13
14      014156 010046
15      014160 005001
16      014162 121227 000060
17      014166 103415
18      014170 121227 000071
19      014174 101012
20      014176 006301
21      014200 010100
22      014202 006301
23      014204 006301
24      014206 060001
25      014210 112200
26      014212 162700 000060
27      014216 060001
28      014220 000760
29      014222 005701
30      014224 001001
31      014226 005201
32      014230 012600
33      014232 000207

13      GETCNT: PUSH R0
14          CLR R1
15          CMPB (R2), #'0
16          BLO GETCDN
17          CMPB (R2), #'9
18          BHI GETCDN
19          ASL R1
20          MOV R1,R0
21          ASL R1
22          ASL R1
23          ADD R0,R1
24          MOVB (R2)+,R0
25          SUB #'0,R0
26          ADD R0,R1
27          BR GETCNX
28          TST R1
29          BNE GETCXX
30          INC R1
31          GETCXX: POP R0
32          RETURN

13      ;MOV R0,-(SP)
14      ;START WITH ZERO COUNT
15      ;CHECK IF CHARACTER A DIGIT
16      ;BRANCH IF LOWER THAN ZERO
17      ;BRANCH IF HIGHER THAN NINE
18      ;MULTIPLY NUMBER BY 10
19      ;SAVE 2N
20      ;COMPUTE 4N
21      ;COMPUTE 8N
22      ;8N + 2N = 10N
23      ;GET DIGIT FROM STING
24      ;GET RID OF ASCII
25      ;ADD TO NUMBER
26      ;GO TO NEXT CHARACTER
27      ;CHECK IF NUMBER IS ZERO
28      ;IF ZERO, CHANGE
29      ;TO DEFAULT OF ONE
30      ;MOV (SP)+,R0

```

```

1          :PNTNUM
2          :PRINT A NUMBER
3          :INPUTS:
4          R1 - RADIX OF NUMBER
5          R2 - ASCII STRING TO COUNT OF BITS IN NUMBER
6          R4 - POINTER TO NUMBER (LOW WORD)
7          :OUTPUTS:
8          NUMBER IS PRINTED. LEADING ZEROS ARE PRINTED EXCEPT FOR
9          DECIMAL NUMBERS.
10         ; R0 - CONTENTS DESTROYED
11
12
13
14 014234 010100          PNTNUM: MOV R1,R0           :SAVE RADIX
15 014236 004737 014156    CALL GETCNT          :GET COUNT OF BITS
16 014242 010246          PNTNUS: PUSH <R2,R3,R5>      MOV R2,-(SP)
17 014242 010246          MOV (R4)+,R3          MOV R3,-(SP)
18 014244 010346          CLR R5
19 014246 010546          CMP R1,#16.
20 014250 012403          BLE 1$              MORE THAN 16 BITS IN NUMBER?
21 014252 005005          1$:                 YES, GET SECOND PARAMETER WORD
22 014254 020127 000020    MOV (R4)+,R5          MOV R5,-(SP)
23 014260 003401          PUSH R4
24 014262 012405          1$:                 PUT HIGH WORD IN R4
25 014264 010446          MOV R5,R4
26 014266 010504          MOV #16.,R2          COMPUTE BITS NOT WANTED
27 014270 012702 000020    SUB R1,R2          BY SUBTRACTING BITS TO USE
28 014274 160102          BGE 2$              FROM 16.
29 014276 002002          ADD #16.,R2          IF NEGATIVE, ADD 16 FOR FIRST WORD
30 014300 062702 000020    2$:                 IF ZERO, NO BITS NEED BE CLEARED
31 014304 001414          BEQ 6$              START MASK WITH SIGN BIT SET
32 014306 012705 100000    MOV #BIT15,R5        COUNT BITS IN MASK
33 014312 005302          3$:                 SHIFT MORE BITS TO RIGHT
34 014314 001402          DEC R2
35 014316 006205          ASR R5
36 014320 000774          BR 3$              MORE THAN 16 BITS IN NUMBER?
37 014322 020127 000020    4$:                 YES, CLEAR IN HIGH WORD
38 014326 003402          CMP R1,#16.
39 014330 040504          BLE 5$              NO, CLEAR IN LOW WORD
40 014332 000401          BIC R5,R4          DIVIDE BY RADIX IN R0
41 014334 040503          BR 6$              PUSH REMAINDER ON STACK
42 014336 004737 014754    5$:                 COUNT DIGITS ON STACK
43 014342 010546          CALL DIVIDE        CHECK IF QUOTIENT IS ZERO
44 014342 010546          PUSH R5
45 014344 005202          INC R2
46 014346 005703          TST R3
47 014350 001372          BNE 6$              MOV R5,-(SP)
48 014352 005704          TST R4
49 014354 001370          BNE 6$
```

GLOBAL SUBROUTINES SECTION

1 014356	020027	000012	CMP R0,#10.	:IF RADIX IS DECIMAL
2 014362	001423		BEQ 10\$: JUST GO PRINT DIGITS ON STACK
3 014364	010103		MOV R1,R3	: OTHERWISE COMPUTE NUMBER OF LEADING ZEROS
4 014366	162700	000014	SUB #12.,R0	: DIVIDEND IS BITS IN NUMBER
5 014372	003002		BGT 7\$: DIVISOR IS BITS PER DIGIT PRINTED
6 014374	012700	000003	MOV #3,R0	: (3 OR 4)
7 014400	004737	014754	CALL DIVIDE	
8 014404	005705		TST R5	:IF REMAINDER NOT ZERO
9 014406	001401		BEQ 8\$:INCREMENT QUOTIENT
10 014410	005203		INC R3	
11 014412	160203		SUB R2,R3	:SUBTRACT DIGITS ON STACK
12 014414	001406		BEQ 10\$:NO LEADING ZEROS IF ZERO
13 014416	014416	112700	PRINT #'0	:PRINT A ZERO
	014422	004737	014476	MOV B #'0,R0 CALL CPNT
14 014426	005303		DEC R3	
15 014430	001372		BNE 9\$:REPEAT UNTIL COUNT REACHES ZERO
16			10\$: POP R5	:GET CHARACTER FROM STACK
17 014432	012605			MOV (SP)+,R5
18 014434	062705	000060	ADD #'0,R5	:CONVERT TO ASCII DIGIT
19 014440	020527	000071	CMP R5,#'9	:IF GREATER THAN A 9
20 014444	003402		BLE 11\$: CONVERT TO A OR HIGHER
21 014446	062705	000007	ADD #<'A-'9-1>,R5	: FOR HEX DIGIT
22 014452	014452	110500	PRINT R5	:PRINT THE CHARACTER
	014454	004737	014476	MOV B R5,R0 CALL CPNT
23 014460	005302		DEC R2	:REPEAT FOR ALL DIGITS
24 014462	001363		BNE 10\$: ON STACK
25 014464	014464	012604	POP <R4,R5,R3,R2>	MOV (SP)+,R4 MOV (SP)+,R5 MOV (SP)+,R3 MOV (SP)+,R2
	014466	012605		
	014470	012603		
	014472	012602		
26 014474	000207		RETURN	

				:PRINT ONE CHARACTER
				:CALL WITH MACRO PRINT
5	014476	110037	003230	CPNT: MOVB R0,ERRCHR
6	014502	010146		PUSH R1
7	014502	012701	003612	
8	014504	120027	000015	MOV #ERRONE,R1
9	014510	001002		CMPB R0,#CR
10	014514	012701	003615	BNE 1\$
11	014516	000177	166500	MOV #ERRNL,R1
12	014522	012746	003230	1\$: JMP @PTYPE
	014526	000002		PF: PRINTF R1,#ERRCHR
	014526	010146		
	014532	012746	000002	
	014534	010600		
	014540	104417		
	014542	062706	000006	
13	014544	000435		
14	014552	012746	003230	PB: BR CPNTX
	014552	010146		PRINTB R1,#ERRCHR
	014556	012746	000002	
	014560	010600		
	014564	104414		
	014566	062706	000006	
15	014574	000423		
16	014576	012746	003230	PX: BR CPNTX
	014576	010146		PRINTX R1,#ERRCHR
	014602	012746	000002	
	014604	010600		
	014610	104415		
	014612	062706	000006	
17	014620	000411		
18	014622	012746	003230	PS: BR CPNTX
	014622	010146		PRINTS R1,#ERRCHR
	014626	012746	000002	
	014630	010600		
	014634	104416		
	014636	062706	000006	
19	014644	012601		CPNTX: POP R1
20	014644	000207		RETURN
				MOV (SP)+,R1

K 8

```
1          ;PRINT FORMATTED MESSAGE
2
3          ;CALL WITH MACRO PNT, PNTF, PNTB, PNTX, OR PNTS
4
5 014650  012737  014526  003226  LPNTF:  MOV #PF,PTYPE
6 014656  000413
7 014660  012737  014552  003226  LPNTB:  MOV #PB,PTYPE
8 014666  000407
9 014670  012737  014576  003226  LPNTX:  MOV #PX,PTYPE
10 014676 000403
11 014700  012737  014622  003226  LPNTS:  MOV #PS,PTYPE
12 014706
    014706  010246
    014710  010346
    014712  010446
    014714  010546
13 014716  012102          MOV (R1)+,R2
14 014720  010604          MOV SP,R4
15 014722  062704  000012          ADD #10.,R4
16 014726
    014726  010146          PUSH R1
17 014730  004737  013402          CALL OSTRNG
18 014734
    014734  012600          POP <R0,R5,R4,R3,R2,R1>
    014736  012605
    014740  012604
    014742  012603
    014744  012602
    014746  012601
19 014750  062006          ADD (R0)+,SP
20 014752  000110          JMP @R0          ;GET ADDRESS OF STRING
                                ;COMPUTE ADDRESS OF ARGUMENTS
                                ; WHICH ARE NOW ON STACK (IF ANY)
                                ;SAVE RETURN ADDRESS
                                ;PRINT THE FORMATTED MESSAGE
                                ;RESTORE ALL REGISTERS
                                ;ADJUST STACK POINTER OVER ARGUMENTS
                                ;RETURN
                                MOV R2,-(SP)
                                MOV R3,-(SP)
                                MOV R4,-(SP)
                                MOV R5,-(SP)
                                MOV R1,-(SP)
                                MOV (SP)+,R0
                                MOV (SP)+,R5
                                MOV (SP)+,R4
                                MOV (SP)+,R3
                                MOV (SP)+,R2
                                MOV (SP)+,R1
```

1 :DIVIDE
2
3 :DIVIDE A 32 BIT UNSIGNED NUMBER BY A 16 BIT UNSIGNED NUMBER.
4 :REPLACE DIVIDEND WITH QUOTIENT AND RETURN REMAINDER.
5 :WILL NOT CHECK FOR DIVIDE BY ZERO.
6
7 :INPUTS:
8 R3 - LOW 16 BITS OF DIVIDEND
9 R4 - HIGH 16 BITS OF DIVIDEND
10 R0 - DIVISOR
11 :OUTPUTS:
12 R3 - LOW 16 BITS OF QUOTIENT
13 R4 - HIGH 16 BITS OF QUOTIENT
14 R5 - REMAINDER
15
16 014754 DIVIDE: PUSH R2 MOV R2,-(SP)
17 014754 010246
18 014756 012702 000040
19 014762 005005
20 014764 006303
21 014766 006104
22 014770 006105
23 014772 020005
24 014774 101002
25 014776 160005
26 015000 005203
27 015002 005302
28 015004 001367
29 015006 012602
30 015010 000207
1\$: MOV #32.,R2 :SET UP SHIFT COUNT
CLR R5 :START WITH ZERO REMAINDER
ASL R3 :SHIFT LEFT INTO R5
ROL R4
ROL R5
CMP R0,R5 :WILL DIVISOR GO INTO REMAINDER
BHI 2\$:ONLY SUBTRACT IF IT WILL
SUB R0,R5 :SUBTRACT DIVISOR
INC R3 :PUT A ONE INTO QUOTIENT
2\$: DEC R2 :COUNT THE SHIFTS
BNE 1\$
POP R2
RETURN MOV (SP)+,R2

```

1          :LOADDM
2          :LOAD AND START A DM PROGRAM INTO A CONTROLLER
3          :INPUTS:
4          R5 - CONTROLLER TABLE ADDRESS
5          DMPROG - POINTER TO START OF DM PROGRAM IN MEMORY
6          :OUTPUTS:
7          IF LOAD SUCCEEDS - Z CLEAR
8          CONTROLLER TABLE MARKED LOADED
9          IF ERROR - Z SET
10         :
11         :LOADDM: MOV DMPROG,R1           ;GET STORAGE ADDRESS OF DM PROGRAM
12         :          MOVB DMTMO(R1),C.TOT(R5)    ;GET TIMEOUT VALUE
13 015012 013701 002164      000044       CLRB C.TOT+1(R5)
14 015016 116165 000021      000044       MOV C.VEC(R5),R4      ;GET VECTOR OF UDA
15 015024 105065 000045      000044       AND CT.VEC,R4
16 015030 016504 000004      000044
17 015034          042704 177000
18 015040 010501          000010       MOV R5,R1
19 015042 062701          000010       ADD #C.JSR,R1
20 015046          012746 000340       SETVEC R4,R1,#PRI07   ;SET UP INTERRUPT VECTOR
21          :          MOV #PRI07,-(SP)
22          :          MOV R1,-(SP)
23          :          MOV R4,-(SP)
24          :          MOV #3,-(SP)
25          :          TRAP C$VEC
26          :          ADD #10,SP
27          :INITIALIZE UDA WITH SMALLEST
28          :RING BUFFER AND INTERRUPTS ENABLED
29          :BRANCH IF AN ERROR
30          CALL UDAINT
31          BEQ LOADER

```

1 015076	017701	165062		MOV @DMPROG,R1	:GET SIZE OF PROGRAM
2 015102	012700	000002		MOV #OP.ESP,RO	:BUILD EXECUTE SUPPLIED PROGRAM COMMAND PACKET
3 015106	004737	015214		CALL BLDCMD	
4 015112	013764	002164	000124	MOV DMPROG,HC.CPK+P.UADR(R4)	:LOAD MAIN PROGRAM ADDRESS
5 015120	010164	000120		MOV R1,HC.CPK+P.BCNT(R4)	: AND SIZE
6 015124	013764	002164	000140	MOV DMPROG,HC.CPK+P.OVRL(R4)	:LOAD OVERLAY ADDRESS
7 015132	067764	165026	000140	ADD @DMPROG,HC.CPK+P.OVRL(R4)	
8 015140	004737	015300		CALL SNDCMD	:SEND COMMAND TO UDA
9 015144	004737	015420		CALL WAITMS	:WAIT FOR MESSAGE RESPONSE
10 015150	001417			BEQ LOADER :ABORT IF NO RESPONSE	
11 015152	032764	000037	000032	BIT #ST.MSK,HC.MPK+P.STS(R4)	:CHECK FOR ERRORS
12 015160	001007			BNE LOADE1	
13 015162	042765	000024	000014	BIC #CT.CMD+CT.REQ,C.FLG(R5)	:CLEAR COMMAND OUTSTANDING FLAG
14 015170	052765	000002	000014	BIS #CT.RN,C.FLG(R5)	:SET DM PROGRAM RUNNING FLAG
15 015176	000207			RETURN	

1 ;UDA FAILED TO DOWNLINE LOAD DM PROGRAM
2
3 015200 LOADE1: ERRDF 34.,ERR034
015200 104455 TRAP C\$ERDF
015202 000042 .WORD 34
015204 000000 .WORD 0
015206 011060 .WORD ERR034
4 015210 000264 LOADER: SEZ
5 015212 000207 RETURN ;SET Z TO INDICATE ERROR OCCURRED

```

1      :BLDCMD
2      BUILD A COMMAND IN COMMAND PACKET
3      INPUTS:
4          R5 - CONTROLLER TABLE ADDRESS
5          R0 - COMMAND CODE
6      OUTPUTS:
7          R4 - ADDRESS OF HOST COMM AREA
8          COMMAND PACKET CONTAINING REF NUMBER AND OPCODE. ALL OTHER FIELDS CLEARED.
9          CMD REFERRENCE NUMBER IN CONTROLLER TABLE INCREMENTED AND RESULT
10         IN COMMAND PACKET.
11         R0 - CONTENTS DESTROYED
12
13
14
15 015214
16 015214 010146
17 015216 010046
18 015220 016504 000016
19 015224 010400
20 015226 062700 000100
21 015232 012720 000060
22 015236 012701 001000
23 015242 022716 000031
24 015246 001002
25 015250 012701 177777
26 015254 010120
27 015256 012701 000030
28 015262 005020
29 015264 005301
30 015266 001375
31 015270 012664 000114
32 015274 012601
33 015274 000207

BLDCMD: PUSH <R1,R0>
          MOV R1,-(SP)
          MOV R0,-(SP)

MOV C.RING(R5),R4           ;GET ADDRESS OF HOST COMM AREA
MOV R4,R0                   ;COPY TO R0
ADD #HC.CEV,R0              ;COMPUTE ADDRESS OF COMMAND ENVELOPE
MOV #HC.PSZ,(R0)+            ;LOAD PACKET LENGTH
MOV #DUP,R1                 ;LOAD DIAG CIRCUIT IDENTIFIER
CMP #OP.MWR,(SP)            ;IF CODE IS MAINTENANCE WRITE
BNE BLDC0                   ;    GET OTHER CIRCUIT IDENTIFIER

MOV #DIAG,R1                ;PUT IDENTIFIER INTO PACKET
BLDC0:  MOV R1,(R0)+          ;GET WORDS TO CLEAR
        MOV #<HC.PSZ>/2,R1
BLDC1:  CLR (R0)+            ;CLEAR PACKET
        DEC R1
        BNE BLDC1
        POP HC.CPK+P.OPCD(R4)   ;PUT OPCODE IN PACKET
        POP R1                  ;RESTORE R1
        RETURN                  ;MOV (SP)+,HC.CPK+P.OPCD(R4)
                                ;MOV (SP)+,R1

```

1 :SNDCMD
2
3 :SEND A COMMAND TO THE UDA.
4 :MARK BOTH PACKETS AVAILABLE TO THE
5 :UDA. SET COMMAND ISSUED BIT IN CONTROLLER TABLE AND INITIALIZE
6 :TIMEOUT COUNTER.
7
8 :INPUTS:
9 : R5 - CONTROLLER TABLE ADDRESS
10 :OUTPUTS:
11 : R4 - ADDRESS OF HOST COMM AREA
12
13
14 015300 SNDCMD: PUSH <R0,R1>
15 015300 010046 MOV R0,-(SP)
16 015302 010146 MOV R1,-(SP)
17 015304 016504 000016 MOV C.RING(R5),R4 ;LOAD R4 WITH HOST COMM AREA ADDRESS
18 015310 005265 000052 INC C.REF(R5) ;INCREMENT CMD REFERENCE NUMBER
19 015314 016564 000052 000104 MOV C.REF(R5),HC.CPK+P.CRF(R4) ;PUT IN PACKET
20 015322 012764 140000 000006 MOV #RG.OWN+RG.FLG,HC.MCT(R4) ;MARK MESSAGE PACKET AVAILABLE
21 015330 012764 100000 000012 MOV #RG.OWN,HC.CCT(R4) ;MARK COMMAND TO UDA
22 015336 005775 000000 TST a(R5) ;TELL UDA COMMAND IS THERE
23 015342 052765 000004 000014 BIS #CT.CMD,C.FLG(R5) ;MARK COMMAND ISSUED
24 015350 012601 POP <R1,R0>
25 015352 012600 MOV (SP)+,R1
26 015354 000207 MOV (SP)+,R0
27
28 RETURN


```

1          :WAITMS
2          :WAIT FOR UDA TO RESPOND WITH A MESSAGE PACKET
3          :INPUTS: R5 - ADDRESS OF CONTROLLER TABLE
4          :OUTPUTS: Z CLEAR IF NO ERROR
5          :                  Z SET IF ERROR, MESSAGE PRINTED
6
7
8
9
10
11 015420          WAITMS: PUSH <R0,R1>
12 015420          010046          MOV R0,-(SP)
13 015422          010146          MOV R1,-(SP)
14 015424          012700          000036          MOV #30.,R0      :SET TIME OUT VALUE OF 30 SECONDS
15 015430          010501          MOV R5,R1      :POINT TO TIME OUT COUNTER
16 015432          062701          000040          ADD #C.TO,R1
17 015436          004737          015612          CALL SETTO
18 015442          011500          000010          000014          1$:    MOV (R5),R0      :GET ADDRESS OF UDAIP REGISTER
19 015444          032765          000010          000014          BIT #CT.MSG,C.FLG(R5) :LOOK IF INTERRUPT OCCURRED
20 015452          001030          000002          BNE 3$          :BRANCH IF SO
21 015454          016001          000002          MOV 2(R0),R1      :LOOK AT UDASA REGISTER
22 015460          001034          BNE 4$          :BRANCH IF ERROR CODE PRESENT
23 015462          104422          BREAK
24 015464          005737          003212          TST KW.CSR      TRAP      C$BRK
25 015470          001764          BEQ 1$          CMP KW.EL+2,C.TOH(R5) :SEE IF A CLOCK ON SYSTEM
26 015500          101005          BHI 2$          BNE 1$          :CHECK IF TIMEOUT HAS HAPPENED
27 015502          001357          023765          003224          000042          CMP KW.EL,C.TO(R5)
28 015504          023765          003222          000040          BLO 1$          2$:    ERRDF 36.,ERR036
29 015512          103753          TRAP      C$ERDF
30 015514          104455          015514          000044          .WORD    36
31 015516          000044          015520          000000          .WORD    0
32 015520          000000          015522          011066          .WORD    ERR036
33 015524          012601          POP <R1,R0>
34 015526          012600          SEZ
35 015530          000264          RETURN          MOV (SP)+,R1
36 015532          000207          MOV (SP)+,R0

```

6 9

SEQ 0110

```
1 015534 042765 000010 000014 3$: BIC #CT.MSG,C.FLG(R5) ;CLEAR MESSAGE RECEIVED FLAG
2 015542          POP <R1,R0>
015542 012601
015544 012600
3 015546 000244 CLZ ;GIVE NO ERROR RETURN
4 015550 000207 RETURN
5 015552          ERRDF 37.,ERR037
015552 104455
015554 000045
015556 000000
015560 011100
6 015562          POP <R1,R0>
015562 012601
015564 012600
7 015566 000264 SEZ ;TRAP C$ERDF
8 015570 000207 RETURN .WORD 37
                           .WORD 0
                           .WORD ERR037
                           MOV (SP)+,R1
                           MOV (SP)+,R0
```

```
1      :NXMI
2      :NON-EXISTANT MEMORY SERVICE ROUTINE
3      :INPUTS:
4          NXMAD SET TO ZERO
5      :OUTPUTS:
6          NXMAD SET TO ONES IF NON-EXISTANT TRAP OCCURED
7
8
9
10 015572      BGNSRV NXMI
11 015572      NXMI:::
12 015572 012737 177777 002202      MOV #-1,NXMAD
13
14 015600      ENDSRV
15 015600      L10030:
16 015600 000002      RTI
```



```

1      :SETTO
2      :SET TIMEOUT COUNTER TO SOME NUMBER OF SECONDS FROM CURRENT TIME.
3
4      :INPUTS:
5          R0 - NUMBER OF SECONDS FOR TIMEOUT
6          R1 - ADDRESS WHERE TWO WORD TIME TO BE PUT
7
8      :OUTPUTS:
9          R0 - CONTENTS DESTROYED
10         R1 - INCREMENTED BY 2
11
12      :COMPUTE CLOCK TICKS TIL TIMEOUT
13
14 015612      SETTO: PUSH <R2,R3>                                MCV R2,-(SP)
15 015612      010246                                         MOV R3,-(SP)
16 015614      010346
17 015616      005002
18 015620      013703 003220
19 015624      006200
20 015626      103001
21 015630      060302
22 015632      006303
23 015634      005700
24 015636      001372
25
26 015640      013700 003222
27 015644      013703 003224
28 015650      020037 003222
29 015654      001371
30
31      :GET CURRENT TIME
32
33 015656      060200
34 015660      005503
35
36      :PUT RESULT IN STORAGE
37
38 015662      010021
39 015664      010311
40
41 015666      POP <R3,R2>                                MOV (SP)+,R3
42 015666      012603
43 015670      012602
44 015672      000207
45
46      RETURN                                MOV (SP)+,R2

```

CLR R2 ;CLEAR PRODUCT
MOV KW.HZ,R3 ;GET MULTIPLICAND
SET00: ASR R0 ;SHIFT MULTIPLIER TO RIGHT
 BCC SET01 ;IF A ONE BIT SHIFTED OUT
 ADD R3,R2 ;ADD MULTIPLICAND TO PRODUCT
SET01: ASL R3 ;DOUBLE THE MULTIPLICAND
 TST R0 ;CONTINUE UNTIL MULTIPLIER IS ZERO
 BNE SET00

SET02: MOV KW.EL,R0 ;GET TIME
 MOV KW.EL+2,R3
 CMP R0,KW.EL ;IF CHANGED DURING RETRIEVAL
 BNE SET02 ; GET IT AGAIN

ADD R2,R0 ;ADD

```

1          :UDAINT
2
3          :FUNCTIONAL DESCRIPTION:
4          :      SUBROUTINE TO INITIALIZE A UDA AND BRING IT ON-LINE.
5          :      ALL STEPS ARE CHECKED. AN ERROR MESSAGE IS REPORTED IF ANY ERROR
6          :      DETECTED.
7
8          :INPUTS:
9          :      R5 - ADDRESS OF CONTROLLER TABLE.
10         :IMPLICIT INPUTS:
11         :      C.RING(R5) - ADDRESS GIVEN TO UDA AS START OF RING BUFFER.
12         :      LENGTH OF RING STRUCTURE IS ONE ENTRY EACH.
13         :OUTPUTS:
14         :      CONDITION Z - SET IF ANY ERROR REPORTED. CLEAR IF NO ERROR.
15         :      R4 - ADDRESS OF UDAIP REGISTER IN UDA
16         :      R5 - UNCHANGED.
17
18         :FILL HOST COMMUNICATION AREA WITH ALL ONES
19
20 015674 016502 000016          UDAINT: MOV C.RING(R5),R2           ;GET FIRST ADDRESS OF RING BUFFER
21 015700 012703 000006          MOV #<HC.RSZ*2+HC.ISZ>/2,R3    ;GET SIZE OF RING BUFFER
22 015704 012722 177777          UDAI1L: MOV #-1,(R2)+          ;WRITE ONES TO BUFFER
23 015710 005303               DEC R3                         ;COUNT THE WORDS IN BUFFER
24 015712 003374               BGT UDAI1L                 ;LOOP UNTIL ENTIRE BUFFER WRITTEN
25
26         :DO THE INITIALIZATION
27
28 015714 004737 016110          CALL UDAIST                ;DO FIRST THREE STEPS
29 015720 103471               BCS UDAIEX                ;GET OUT IF UDA MICROCODE REPORTED FAILURE
30 015722 012364 000002          MOV (R3)+,2(R4)          ;WRITE NEXT WORD TO UDASA REGISTER
31 015726 012703 000310          MOV #200.,R3            ;GET TRY COUNTER
32 015732 016402 000002          UDAI1A: MOV 2(R4),R2        ;LOOK AT UDASA
33 015736 001410               BEQ UDAI1C
34 015740 100005               BPL UDAI1B
35 015742 104455               ERRDF 24.,ERR024
36 015744 000030
37 015746 000000
38 015750 010754
39 015752 000454
40 015754 005303
41 015756 001365
42 015760 010264 000002          UDAI1B: BR UDAIEX
43 015764 011402               DEC R3
44 015766 004737 016434          UDAI1C: BNE UDAI1A
45 015772 103444               MOV R2,2(R4)
46                           MOV (R4),R2
47                           CALL UDARSP
48                           BCS UDAIEX
49
50                           TRAP    CSERDF
51                           .WORD   24
52                           .WORD   0
53                           .WORD   ERR024
54
55                           :WRITE 0 TO UDASA (PURGE)
56                           :READ FROM UDAIP (POLL)
57                           :WAIT FOR STEP OR ERROR BIT
58                           :GET OUT IF UDA MICROCODE REPORTED FAILURE

```

```

1          ;CHECK HOST COMMUNICATION AREA FOR ALL ZEROS
2
3 015774 016502 000016
4 016000 012703 000006
5 016004 005722
6 016006 001003
7 016010 005303
8 016012 003374
9 016014 000405

10         UDAI2: MOV C.RING(R5),R2           ;GET FIRST ADDRESS OF RING BUFFER
11        MOV #<HC.RSZ*2+HC.ISZ>/2,R3      ;GET SIZE OF RING BUFFER
12        UDAI2L: TST (R2)+                 ;CHECK WORD IN BUFFER
13        BNE UDAI2E                   ;GO TO ERROR REPORTER IF NOT ZERO
14        DEC R3                      ;COUNT THE WORDS IN BUFFER
15        BGT UDAI2L                  ;LOOP UNTIL ALL WORDS CHECKED
16        BR UDAI3                    ;REPORT BUFFER NOT CLEARED
17        UDAI2E: ERRDF 23,,ERR023      ;TRAP     CSERDF
18        .WORD    23
19        .WORD    0
20        .WORD    ERR023
21        016016 104455
22        016020 000027
23        016022 000000
24        016024 010670
25        016026 000426
26
27        BR UDAIEX
28
29        ;SEND GO BIT TO UDASA REGISTER TO END INITIALIZATION
30
31        UDAI3:                         ;SET THE GO BIT
32        MOV C.BST(R5),R0             ;GET BURST VALUE
33        ASL R0                      ;SHIFT TO POSITION
34        016030 016500 000006
35        016034 006300
36        016036 006300
37        016040 052700 000001
38        016044 010064 000002
39        016050 016501 000016
40        016054 010161 000004
41        016060 062761 000020 000004
42        016066 010161 000010
43        016072 062761 000104 000010
44        CLZ
45        RETURN
46
47        ;ERROR RETURN
48
49        UDAIEX: SEZ                  ;SET Z TO INDICATE ERROR OCCURRED
50        RETURN

```

```

1          :UDAIST
2          :START THE INITIALIZATION PROCESS ON THE SELECTED UDA.
3          :STOP BEFORE WRITING THE THIRD WORD SO UDA DOES NOT
4          :ATTEMPT ANY UNIBUS TRANSFERS.
5
6          :INPUTS:
7          ;      R5 - ADDRESS OF CONTROLLER TABLE
8
9          ;LOAD TABLE OF DATA TO SEND TO UDASA REGISTER
10
11         UDAIST: BREAK
12         016110 104422
13         016112
14         016114 010146
15         016120 016504 000004
16         016124 042704 177000
17         016126 006204
18         016130 052704 100000
19         016134 010437 016326
20         016140 016537 000016 016332
21         016146 062737 000004 016332
22
23         ;START THE INITIALIZATION BY WRITING TO UDAIP REGISTER
24
25         016154 016504 000000
26         016160 005037 002202
27         016164
28         016164 012746 000340
29         016170 012746 015572
30         016174 012746 000004
31         016200 012746 000003
32         016204 104437
33         016206 062706 000010
34         016212 005764 000002
35         016216 005014
36         016220
37         016220 012700 000004
38         016224 104436
39         016226 005737 002202
40         016232 001406
41         016234
42         016234 104455
43         016236 000024
44         016240 000000
45         016242 010556
46         016244 000261
47         016246 000424
48
49         SEC
50         BR UDAISE
51
52         :UDAIST
53         :START THE INITIALIZATION PROCESS ON THE SELECTED UDA.
54         :STOP BEFORE WRITING THE THIRD WORD SO UDA DOES NOT
55         :ATTEMPT ANY UNIBUS TRANSFERS.
56
57         :INPUTS:
58         ;      R5 - ADDRESS OF CONTROLLER TABLE
59
60         ;LOAD TABLE OF DATA TO SEND TO UDASA REGISTER
61
62         UDAIST: BREAK
63
64         PUSH R1
65
66         MOV C.VEC(R5),R4
67         AND CT.VEC,R4
68
69         ASR R4
70         ASR R4
71         BIS #SA.STP,R4
72         MOV R4,UDAID1
73         MOV C.RING(R5),UDAID2
74         ADD #HC.MSG,UDAID2
75
76         ;SET STEP BIT IN DATA WORD
77         ;LOAD INTERRUPT VECTOR
78         ;LOAD MEMORY ADDRESS
79         ;   OF FIRST RESPONSE RING
80
81         ;START THE INITIALIZATION BY WRITING TO UDAIP REGISTER
82
83         MOV C.UADR(R5),R4
84         CLR NXMAD
85         SETVEC #4,#NXMI,#PRI07
86
87         ;GET ADDRESS OF UDAIP REGISTER
88         ;CLEAR MEMORY ERROR FLAG
89         ;SET UP VECTOR 4
90
91         MOV #PRI07,-(SP)
92         MOV #NXMI,-(SP)
93         MOV #4,-(SP)
94         MOV #3,-(SP)
95         TRAP CSSVEC
96         ADD #10,SP
97
98         TST 2(R4)
99         CLR (R4)
100        CLRVEC #4
101
102        ;ACCESS UDASA REGISTER
103        ;WRITE TO UDAIP
104        ;GIVE UP THE VECTOR
105
106        MOV #4,RO
107        TRAP CSCVEC
108
109        TST NXMAD
110        BEQ UDAISG
111        ERRDF 20,,ERR020
112
113        ;SEE IF A MEMORY ERROR OCCURRED
114
115        TRAP C$ERDF
116        .WORD 20
117        .WORD 0
118        .WORD ERR020

```

```

1          ;SET UP LOOP PARAMETERS TO EXECUTE THE FOUR STEPS OF INITIALIZATION
2
3 016250 012737 004000 016572 UDAISG: MOV #SA.S1,UDARSD           ;STORE RESPONSE MASK
4 016256 012703 016324 MOV #UDAIDT,R3                         ;AND INDEX TO TABLE
5
6          ;WAIT FOR AND CHECK RESPONSE DATA
7
8 016262 004737 016434 UDAISL: CALL UDARSP                  ;WAIT FOR STEP OR ERROR BITS
9 016266 103414          BCS UDAISE                            ;EXIT IF ERROR
10 016270 004733          CALL @R3+                             ;CALL RESPONSE CHECKER FOR STEP
11 015272 103412          BCS UDAISE                            ;GET OUT IF ERROR
12 016274 006337 016572 ASL UDARSD                           ;SHIFT TO NEXT STEP BIT
13 016300 032737 040000 016572 BIT #SA.S4,UDARSD             ;CHECK IF NOW AT STEP 4
14 016306 001003          BNE UDAISX                           ;GET OUT IF SO
15 016310 012364 000002 MOV R3+,2(R4)                         ;WRITE DATA TO UDASA REGISTER
16 016314 000762          BR UDAISL                            ;STAY IN LOOP
17
18 016316 000241          UDAISX: CLC                         ;CLEAR CARRY FOR NO ERROR INDICATION
19 016320          UDAISE: POP R1
20 016320 012601          RETURN
21          MOV (SP)+,R1

```

GLOBAL SUBROUTINES SECTION

SEQ 0118

```

1          ;DATA TO BE SENT AND RECEIVED BY UDA INITIALIZATION
2
3 016324 016342      UDAIDT: .WORD UDAIR1      :FIRST WORD RESPONSE CHECK ROUTINE
4 016326 000000      UDAID1: .WORD 0           :FIRST WORD TO SEND TO UDASA
5 016330 016350      UDAID2: .WORD UDAIR2      :SECOND WORD RESPONSE CHECK ROUTINE
6 016332 000000      UDAID3: .WORD 0           :SECOND WORD TO SEND TO UDASA
7 016334 016370      UDAIR3: .WORD UDAIR3      :THIRD WORD RESPONSE CHECK ROUTINE
8 016336 100000      UDAIR4: .WORD SA.TST      :THIRD WORD TO SEND TO UDASA
9 016340 016406      .WORD UDAIR4      :FOURTH WORD RESPONSE CHECK ROUTINE
10
11          ;RESPONSE CHECK FOR FIRST WORD FROM UDASA
12          ;CHECK FOR PROPER CONTROLLER TYPE
13
14 016342 012701 004400    UDAIR1: MOV #SA.S1+SA.DI,R1      :SET STEP ONE BIT
15 016346 000422          BR UDAIRC      :NOW COMPARE
16
17          ;RESPONSE CHECK FOR SECOND WORD FROM UDASA
18          ;CHECK FOR ECHO OF INTI AND VECTOR
19
20 016350 013701 016326    UDAIR2: MOV UDAID1,R1      :GET WORD SENT TO UDASA
21 016354 000301          SWAB R1      :GET HIGH 8 BITS
22 016356 042701 177400      BIC #177400,R1
23 016362 052701 010000      BIS #SA.S2,R1      :SET STEP 2 BIT
24 016366 000412          BR UDAIRC      :NOW COMPARE
25
26          ;RESPONSE CHECK FOR THIRD WORD FROM UDASA
27          ;CHECK FOR ECHO OF MESSAGE AND COMMAND RING LENGTHS
28
29 016370 013701 016326    UDAIR3: MOV UDAID1,R1      :GET WORD SENT TO UDASA
30 016374 042701 177400      BIC #177400,R1
31 016400 052701 020000      BIS #SA.S3,R1      :SET STEP 3 BIT
32 016404 000403          BR UDAIRC      :NOW COMPARE
33
34          ;RESPONSE CHECK FOR FOURTH WORD FROM UDASA
35          ;CHECK FOR ECHO OF PURGE AND LFAIL BITS
36
37 016406 010201          UDAIR4: MOV R2,R1      :GET RESPONSE FROM UDA
38 016410 042701 137400      BIC #^C<SA.S4+SA.MCV>,R1      :KEEP MICROCODE VERSION AND STEP 4
39
40          ;COMPARE EXPECTED DATA IN R1 WITH ACTUAL DATA IN R2
41
42 016414 020102          UDAIRC: CMP R1,R2      :COMPARE THE DATA
43 016416 001405          BEQ UDAIRX      :EXIT IF COMPARED CORRECTLY
44 016420          ERRDF 25.,ERR025      :REPORT ERROR
45 016420 104455          TRAP CSE RDF
46 016422 000031          .WORD 25
47 016424 000000          .WORD 0
48 016426 010770          .WORD ERR025
49 016430 000261          SEC
50 016432 000207          UDAIRX: RETURN

```

```

1  UDARSP
2
3  :WAIT FOR UDA TO RESPOND WITH DATA IN UDASA REGISTER.
4  :EITHER STEP BIT FROM MASK IN LOCATION UDARSD OR ERROR BIT
5  :WILL CAUSE A TERMINATION.
6  :AN ERROR MESSAGE WILL BE PRINTED IF THE UDA DOES NOT RESPOND
7  :IN 10 SECONDS OR IF ERROR SETS.
8
9  :INPUTS:
10 :    UDASRD - MASK OF STEP BIT TO LOOK FOR
11 :    R5 - ADDRESS OF CONTROLLER TABLE
12 :    R4 - ADDRESS OF UDAIP REGISTER
13  :OUTPUTS:
14 :    ERROR MESSAGE IF TIME OUT ON RESPONSE OR ERROR BIT SETS
15 :    R2 - DATA FROM UDASA REGISTER
16 :    CARRY SET IF ERROR BIT SETS OR TIME OUT
17
18 016434          UDARSP: PUSH R1
19 016434          010146      MOV R1,-(SP)
20 016436          052737      100000  016572      BIS #SA.ERR,UDARSD   ;SET ERROR BIT IN MASK WORD
21 016444          012700      000012      MOV #10.,R0           ;SET UP FOR 10 SECOND TIMEOUT
22 016450          010501      000040      MOV R5,R1           ;POINT TO COUNTER IN CONTROLLER TABLE
23 016456          004737      015612      ADD #C.TO,R1
24 016462          012601      CALL SETTO
25 016464          033764      016572  000002      POP R1
26 016472          001024      UDARS1: BIT UDARSD,2(R4)   ;LOOK AT ERROR AND STEP BIT
27 016474          104422      BNE UDARS2   ;BRANCH IF EITHER SET
28 016476          005737      003212      BREAK
29 016502          001770      TST KW.CSR   ;SEE IF CLOCK ON SYSTEM
30 016504          023765      003224  000042      BEQ UDARS1
31 016512          101005      CMP KW.EL+2,C.TOH(R5) ;CHECK IF TIME OUT OCCURRED
32 016514          001363      BHI 1$       ;TIME OUT OCCURRED
33 016516          023765      BNE UDARS1
34 016524          103757      CMP KW.EL,C.TO(R5)
35 016526          016402      BLO UDARS1
36 016532          000002      1$: MOV 2(R4),R2   ;GET REGISTER CONTENTS
37 016532          104455      ERRDF 22,,ERR022 ;REPORT TIME OUT ERROR
38 016534          000026      TRAP .WORD 22
39 016536          000000      .WORD 0
40 016540          010622      .WORD ERR022
41 016542          000407      BR UDARSE

```

D 10

1 ;CHECK IF ERROR BIT SET
2
3 016544 016402 000002 UDARS2: MOV 2(R4),R2 ;GET REGISTER CONTENTS
4 016550 100006 BPL UDARSX ;EXIT IF ERROR NOT SET
5 016552 016552 ERRDF 21,,ERR021 ;REPORT ERROR INFO
6 016552 104455 TRAP C\$ERDF
7 016554 000025 .WORD 21
8 016556 000000 .WORD 0
9 016560 010570 .WORD ERR021
10 016562 000261
11 016564 000207 UDARSE: SEC
12 016566 000241 RETURN
13 016570 000207 ;NORMAL EXIT
14 UDARSX: CLC ;CLEAR CARRY AS NO ERROR INDICATION
15 RETURN
16 016572 000000 ;LOCATION FOR STEP BIT MASK
UDARSD: .WORD 0 ;LOAD BY CALLING ROUTINE

F 10

```
1 ;KW11I
2
3 ;CLOCK INTERRUPT SERVICE ROUTINE
4
5 016614
6 016614
7 016614 062737 000001 003222 ADD #1,KW.EL
8 016622 005537 003224 ADC KW.EL+2
9 016626 012777 000105 164356 MOV #KWOUT.,@KW.CSR
 016634 ENDSRV
 016634
 016634 000002

KW11I::: ;COUNT THE INTERRUPT
          ;RESTART THE CLOCK
L10032:   RTI
```

GLOBAL SUBROUTINES SECTION

```

1      ;RNTIME
2      ;PRINT RUNTIME
3      ;INPUTS:
4          KW.EL - CONTAINS ELAPSED TIME
5          KW.HZ - HERTZ OF CLOCK
6      ;OUTPUTS:
7          IF CLOCK ON SYSTEM:
8              " RUNTIME HH:MM:SS " PRINTED
9          IF NO CLOCK: ONE SPACE IS PRINTED
10
11
12
13 016636 005737 003212    RNTIME: TST KW.CSR           ;CHECK IF A CLOCK PRESENT
14 016642 001465             BEQ RNTIMX
15 016644 010046             PUSH <R0,R3,R4,R5>       ;BRANCH IF NOT
16 016644 010046             MOV R0,-(SP)
17 016646 010346             MOV R3,-(SP)
18 016650 010446             MOV R4,-(SP)
19 016652 010546             MOV R5,-(SP)
20
21 016654 013703 003222     MOV KW.EL,R3           ;GET ELAPSED TIME
22 016660 013704 003224     MOV KW.EL+2,R4
23 016664 013700 003220     MOV KW.HZ,R0
24 016670 004737 014754     CALL DIVIDE
25 016674 012700 000074     MOV #60.,R0
26 016700 004737 014754     CALL DIVIDE
27 016704 010546             PUSH R5
28 016704 010546             CALL DIVIDE
29 016706 004737 014754     PNT RNTIM,R3           ;DIVIDE BY 60 AGAIN
30 016712 010346             ;PRINT HOURS
31 016714 004137 014706     MOV R3,-(SP)
32 016720 003620             JSR R1,LPNT
33 016722 000002             .WORD RNTIM
34 016724 020527 000011     .WORD PNT.CT
35 016730 003004             ;IF MINUTES 9 OR LESS
36 016732 0112700 000060    BGT 1$               ;PRINT A LEADING ZERO
37 016736 004737 014476     CMP R5,#9.
38 016742 010546             POP R5
39 016744 004137 014706     ;GET SECONDS
40 016750 003643             CMP R5,#9.
41 016752 000002             BGT 2$               ;IF 9 OR LESS
42 016754 012605             POP R5
43 016756 020527 000011     PRINT #'0
44 016762 003004             ;PRINT A LEADING ZERO
45 016764 0112700 000060    1$:   PNT RNTIM1,R5
46 016770 004737 014476     ;NOW PRINT MINUTES
47 016774 010546             POP R5
48 016776 004137 014706     ;GET SECONDS
49 017002 003651             CMP R5,#9.
50 017004 000002             BGT 2$               ;IF 9 OR LESS
51 017006 012605             POP <R5,R4,R3,R0>
52 017006 012605             PRINT #'0
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117
118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167
168
169
170
171
172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196
197
198
199
200
201
202
203
204
205
206
207
208
209
210
211
212
213
214
215
216
217
218
219
220
221
222
223
224
225
226
227
228
229
230
231
232
233
234
235
236
237
238
239
240
241
242
243
244
245
246
247
248
249
250
251
252
253
254
255
256
257
258
259
260
261
262
263
264
265
266
267
268
269
270
271
272
273
274
275
276
277
278
279
280
281
282
283
284
285
286
287
288
289
290
291
292
293
294
295
296
297
298
299
300
301
302
303
304
305
306
307
308
309
310
311
312
313
314
315
316
317
318
319
320
321
322
323
324
325
326
327
328
329
330
331
332
333
334
335
336
337
338
339
340
341
342
343
344
345
346
347
348
349
350
351
352
353
354
355
356
357
358
359
360
361
362
363
364
365
366
367
368
369
370
371
372
373
374
375
376
377
378
379
380
381
382
383
384
385
386
387
388
389
390
391
392
393
394
395
396
397
398
399
400
401
402
403
404
405
406
407
408
409
410
411
412
413
414
415
416
417
418
419
420
421
422
423
424
425
426
427
428
429
430
431
432
433
434
435
436
437
438
439
440
441
442
443
444
445
446
447
448
449
450
451
452
453
454
455
456
457
458
459
460
461
462
463
464
465
466
467
468
469
470
471
472
473
474
475
476
477
478
479
480
481
482
483
484
485
486
487
488
489
490
491
492
493
494
495
496
497
498
499
500
501
502
503
504
505
506
507
508
509
510
511
512
513
514
515
516
517
518
519
520
521
522
523
524
525
526
527
528
529
530
531
532
533
534
535
536
537
538
539
540
541
542
543
544
545
546
547
548
549
550
551
552
553
554
555
556
557
558
559
560
561
562
563
564
565
566
567
568
569
570
571
572
573
574
575
576
577
578
579
580
581
582
583
584
585
586
587
588
589
589
590
591
592
593
594
595
596
597
598
599
600
601
602
603
604
605
606
607
608
609
610
611
612
613
614
615
616
617
618
619
620
621
622
623
624
625
626
627
628
629
630
631
632
633
634
635
636
637
638
639
640
641
642
643
644
645
646
647
648
649
650
651
652
653
654
655
656
657
658
659
660
661
662
663
664
665
666
667
668
669
669
670
671
672
673
674
675
676
677
678
679
679
680
681
682
683
684
685
686
687
688
689
689
690
691
692
693
694
695
696
697
698
699
700
701
702
703
704
705
706
707
708
709
709
710
711
712
713
714
715
716
717
718
719
719
720
721
722
723
724
725
726
727
728
729
729
730
731
732
733
734
735
736
737
738
739
739
740
741
742
743
744
745
746
747
748
749
749
750
751
752
753
754
755
756
757
758
759
759
760
761
762
763
764
765
766
767
768
769
769
770
771
772
773
774
775
776
777
778
779
779
780
781
782
783
784
785
786
787
787
788
789
789
790
791
792
793
794
795
796
797
797
798
799
799
800
801
802
803
804
805
806
807
808
809
809
810
811
812
813
814
815
816
817
817
818
819
819
820
821
822
823
824
825
826
827
827
828
829
829
830
831
832
833
834
835
836
837
837
838
839
839
840
841
842
843
844
845
846
846
847
848
848
849
849
850
851
852
853
854
855
856
857
857
858
859
859
860
861
862
863
864
865
866
866
867
868
868
869
869
870
871
872
873
874
875
876
876
877
878
878
879
879
880
881
882
883
884
885
886
886
887
888
888
889
889
890
891
892
893
894
895
895
896
896
897
897
898
898
899
899
900
901
902
903
904
905
906
907
907
908
909
909
910
911
912
913
914
915
915
916
917
917
918
918
919
919
920
921
922
923
924
925
925
926
927
927
928
928
929
929
930
931
932
933
934
935
935
936
936
937
937
938
938
939
939
940
941
942
943
944
944
945
945
946
946
947
947
948
948
949
949
950
951
952
953
954
954
955
955
956
956
957
957
958
958
959
959
960
961
962
963
964
964
965
965
966
966
967
967
968
968
969
969
970
971
972
973
974
974
975
975
976
976
977
977
978
978
979
979
980
981
982
983
984
984
985
985
986
986
987
987
988
988
989
989
990
991
992
993
993
994
994
995
995
996
996
997
997
998
998
999
999
1000
1000
1001
1001
1002
1002
1003
1003
1004
1004
1005
1005
1006
1006
1007
1007
1008
1008
1009
1009
1010
1010
1011
1011
1012
1012
1013
1013
1014
1014
1015
1015
1016
1016
1017
1017
1018
1018
1019
1019
1020
1020
1021
1021
1022
1022
1023
1023
1024
1024
1025
1025
1026
1026
1027
1027
1028
1028
1029
1029
1030
1030
1031
1031
1032
1032
1033
1033
1034
1034
1035
1035
1036
1036
1037
1037
1038
1038
1039
1039
1040
1040
1041
1041
1042
1042
1043
1043
1044
1044
1045
1045
1046
1046
1047
1047
1048
1048
1049
1049
1050
1050
1051
1051
1052
1052
1053
1053
1054
1054
1055
1055
1056
1056
1057
1057
1058
1058
1059
1059
1060
1060
1061
1061
1062
1062
1063
1063
1064
1064
1065
1065
1066
1066
1067
1067
1068
1068
1069
1069
1070
1070
1071
1071
1072
1072
1073
1073
1074
1074
1075
1075
1076
1076
1077
1077
1078
1078
1079
1079
1080
1080
1081
1081
1082
1082
1083
1083
1084
1084
1085
1085
1086
1086
1087
1087
1088
1088
1089
1089
1090
1090
1091
1091
1092
1092
1093
1093
1094
1094
1095
1095
1096
1096
1097
1097
1098
1098
1099
1099
1100
1100
1101
1101
1102
1102
1103
1103
1104
1104
1105
1105
1106
1106
1107
1107
1108
1108
1109
1109
1110
1110
1111
1111
1112
1112
1113
1113
1114
1114
1115
1115
1116
1116
1117
1117
1118
1118
1119
1119
1120
1120
1121
1121
1122
1122
1123
1123
1124
1124
1125
1125
1126
1126
1127
1127
1128
1128
1129
1129
1130
1130
1131
1131
1132
1132
1133
1133
1134
1134
1135
1135
1136
1136
1137
1137
1138
1138
1139
1139
1140
1140
1141
1141
1142
1142
1143
1143
1144
1144
1145
1145
1146
1146
1147
1147
1148
1148
1149
1149
1150
1150
1151
1151
1152
1152
1153
1153
1154
1154
1155
1155
1156
1156
1157
1157
1158
1158
1159
1159
1160
1160
1161
1161
1162
1162
1163
1163
1164
1164
1165
1165
1166
1166
1167
1167
1168
1168
1169
1169
1170
1170
1171
1171
1172
1172
1173
1173
1174
1174
1175
1175
1176
1176
1177
1177
1178
1178
1179
1179
1180
1180
1181
1181
1182
1182
1183
1183
1184
1184
1185
1185
1186
1186
1187
1187
1188
1188
1189
1189
1190
1190
1191
1191
1192
1192
1193
1193
1194
1194
1195
1195
1196
1196
1197
1197
1198
1198
1199
1199
1200
1200
1201
1201
1202
1202
1203
1203
1204
1204
1205
1205
1206
1206
1207
1207
1208
1208
1209
1209
1210
1210
1211
1211
1212
1212
1213
1213
1214
1214
1215
1215
1216
1216
1217
1217
1218
1218
1219
1219
1220
1220
1221
1221
1222
1222
1
```

017010	012604		MOV (SP)+,R4
017012	012603		MOV (SP)+,R3
017014	012600		MOV (SP)+,R0
35 017016	112700 000040	RNTIMX: PRINT <#>	
017022	004737 014476		PRINT A SOURCE
36 017026	000207	RETURN	MOVB #*,R0
37			CALL CPNT
38 017030		ENDMOD	

1 .SBTTL PROTECTION TABLE
2
3 017030 BGNMOD
4
5 :++
6 : THIS TABLE IS USED BY THE RUNTIME SERVICES
7 : TO PROTECT THE LOAD MEDIA.
8 :--
9
10 017030 BGNPROT
11 017030 LSPROT::
12 017030 177777 -1 :OFFSET INTO P-TABLE FOR CSR ADDRESS
13 017032 177777 -1 :OFFSET INTO P-TABLE FOR MASSBUS ADDRESS
14 017034 177777 -1 :OFFSET INTO P-TABLE FOR DRIVE NUMBER
15
16 017036 ENDPROT
17

J 10

```

1 .SBttl INITIALIZE SECTION
2
3 :++ THE INITIALIZE SECTION CONTAINS THE CODING THAT IS PERFORMED
4 ; AT THE BEGINNING OF EACH PASS.
5 :--
6
7
8 017036
9 017036
10 017036      012700 000040      BGNINIT
11 017042      104447
12 017044      103415      LSINIT::
13 017044
14 017046      012700 000037      READEF #EF.START      :CHECK IF STARTED BY OPERATOR
15 017046      104447      BCOMPLETE INIT1      : IF NOT.
16 017052      103411      READEF #EF.RESTART
17 017054      012700 000036      BCOMPLETE INIT1
18 017054      104447      READEF #EF.CONTINUE
19 017056      103405      BCOMPLETE INIT1
20 017062      012700 000036      READEF #EF.PWR
21 017064      104447      BCOMPLETE INIT1
22 017066      103405      INITQT: DOCLN      ; ABORT PROGRAM
23 017066      012700 000034      INIT1: MOV #SO.FMT,RO      ;BUILD MODE WORD FROM SOFTWARE QUESTIONS
24 017072      104447      BIT RO,SFPTBL      ;SEE IF REFORMAT
25 017074      103401      BNE INIT2      ; BRANCH IF SO
26 017076      104444      MOV #SO.CNS,RO      ;SEE IF RECONSTRUCT
27 017100      012700 000003      BIT RO,SFPTBL
28 017104      030037 002144      BNE INIT2      ; BRANCH IF SO
29 017110      001011      ASL RO      ; SEE IF RESTORE
30 017112      012700 000004      ASSUME SO.STR EQ SO.CNS*2
31 017116      030037 002144      INIT2: BIT RO,SFPTBL
32 017122      001004      BEQ INITQT      ;IF NOT, ABORT PROGRAM
33 017124      006300      MOV RO,MODE      ;SAVE MODE FLAGS
34 017126      030037 002144      TST DATEO      ;SEE IF ALREADY ASKED FOR DATE
35 017132      001761      BNE INIT3      ;BRANCH IF SO
36 017134      010037 003210      INIT3: CALL DATE      ;IF NOT, GET IT NOW
37 017140      005737 003312      BRESET      ;RESET ALL UNITS
38 017144      001002      MEMORY FFREE      ;RESET START OF FREE MEMORY
39 017146      004737 020012      INIT2: TRAP      CSRESET
40 017152      104433      MOV @FFREE,FSIZE      ;RESET SIZE OF FREE MEMORY
41 017154      104431      INIT2: TRAP      CSMEM
42 017156      010037 002146      MOV RO,FFREE      RO,FFREE
43 017162      017737 162760 002150      ;INITIALIZE CLOCK
44 017170      000105      KWOUT.=105      ;DATA TO SEND TO KW11 TO START CLOCK
45 005037 003212      CLR KW.CSR      ;MARK CLOCK AS NOT ON SYSTEM

```

41 017174 005037 003222	CLR KW.EL	:CLEAR ELAPSED TIME	
42 017200 005037 003224	CLR KW.EL+2	:SEE IF AN L CLOCK PRESENT	
43 017204 012700 000114	CLOCK L,RO	MOV TRAP #L,RO CSCLK	
017210 104462			
44 017212 103413	BCOMPLETE KYES	BCS KYES	
017212			
45 017214 012700 000120	CLOCK P,RO	:SEE IF A P CLOCK PRESENT	
017214			
017220 104462		MOV TRAP #P,RO CSCLK	
46 017222 103407	BCOMPLETE KYES	BCS KYES	
017222			
47 017224 005037 003212	CLR KW.CSR	:IF NEITHER, CLEAR CSR STORAGE WORD	
017224			
48 017230 004137 014650	PNTF NOCLOCK	JSR R1,LPNTF .WORD NOCLOCK .WORD PNT.CT	
017230			
017234 004007			
017236 000000			
49 017240 000426	KYES: BR KNO	:STORE DATA RETURNED	
50 017242 012037 003212	MOV (R0)+,KW.CSR		
51 017246 012037 003214	MOV (R0)+,KW.BRL		
52 017252 012037 003216	MOV (R0)+,KW.VEC		
53 017256 012037 003220	MOV (R0)+,KW.HZ		
54 017262	SETVEC KW.VEC,#KW11I,KW.BRL	:SET THE VECTOR	
017262 013746 003214		MOV KW.BRL,-(SP)	
017266 012746 016614		MOV #KW11I,-(SP)	
017272 013746 003216		MOV KW.VEC,-(SP)	
017276 012746 000003		MOV #3,-(SP)	
017302 104437		TRAP CSSVEC	
017304 062706 000010		ADD #10,SP	
55 017310 012777 000105 163674	KNO: MOV #KWOUT.,@KW.CSR	:START THE CLOCK	
56 017316			

INITIALIZE SECTION

```

1          ;INITIALIZE CONTROLLER TABLE STORAGE WITH A WORD OF ZEROS
2
3 017316 013737 002146 002156      MOV FFREE,CTABS           ;STORE START OF CONTROLLER TABLES
4 017324 005077 162626             CLR OCTABS            ;ZEROS MARKS END CONTROLLER TABLES
5 017330 005037 002160             CLR CTRLRS             ;CLEAR CONTROLLER COUNT
6
7
8          ;GET A P-TABLE FROM DRS
9 017334 005002
10 017336 010200
11 017340 104442
12 017342 103075
13
14          ;SEE IF A CONTROLLER TABLE ALREADY EXISTS FOR CONTROLLER IN P-TABLE
15 017344 013703 002156      INIT5:    MOV CTABS,R3          ;GET ADDRESS OF CONTROLLER TABLES
16 017350 005713             TST (R3)            ;CHECK IF ANY MORE TABLES
17 017352 001416             BEQ NEWTAB          ;BUILD NEW TABLE IF FOUND ZERO WORD
18 017354 021013             CMP (R0),(R3)        ;CHECK IF SAME UNIBUS ADDRESS
19 017356
20 017356             ASSUME C.UADR EQ 0
21 017356             ASSUME HO.UBA EQ 0
22 017360 016301 000004
23 017364 042701 177000
24 017370 026001 000002
25 017374 001002
26 017376 000137 017776
27 017402 062703 000054
28 017406 000760
1$:          BEQ SAMTAB          ;CHECK TABLE IF ALREADY EXISTS
          MOV C.VEC(R3),R1      ;GET VECTOR FROM EXISTING CONTROLLER TABLE
          BIC #^C<CT.VEC>,R1
          CMP HO.VEC(R0),R1
          BNE 1$              ;SEE IF DIFFERENT VECTOR
          JMP SAMVEC          ;ERROR, CAN'T HAVE TWO UDA'S WITH SAME VECTOR
          ADD #C.SIZE,R3
          BR INIT5            ;MOVE TO NEXT TABLE

```

1		;BUILD A CONTROLLER TABLE	
2			
3	017410	012701	000026
4	017414	004737	011346
5	017420	011021	
6	017422	010221	
7	017424	016004	000004
8	017430	000304	
9	017432	006104	
10	017434	056004	000002
11	017440	010421	
12	017442	016021	000006
13	017446	012721	004037
14	017452	012721	015602
15	017456	012703	000020
16			
17	017462	005021	
18	017464	005303	
19	017466	001375	
20	017470	005237	002160
21	017474	005011	
22	017476	000417	

```

;NEWTAB: MOV #C.SIZE/2,R1          ;GET WORDS IN CONTROLLER TABLE
        CALL ALOCM                ;ALLOCATE SPACE FOR IT
        MOV (R0), (R1)+              ;STORE UNIBUS ADDRESS
        MOV R2, (R1)+                ;UNIT NUMBER
        MOV H0.BRL(R0), R4           ;GET BR LEVEL
        SWAB R4                     ;SWAP TO HIGH BYTE
        ROL R4                      ;SHIFT ONE MORE TO LEFT
        BIS H0.VEC(R0), R4           ;ADD VECTOR ADDRESS
        MOV R4, (R1)+                ;TO TABLE
;PUT [JSR R0,UDASRV]             ;PUT [JSR R0,UDASRV]
;INTO TABLE                      ;INTO TABLE
;CLEAR POINTERS TO DRIVE TABLES,;CLEAR POINTERS TO DRIVE TABLES,
;TIMEOUT COUNTER, FLAGS, REF. NUMBER;TIMEOUT COUNTER, FLAGS, REF. NUMBER

;INIT7: CLR (R1)+                 ;LOOP TIL ALL CLEARED
      DEC R3                     ;COUNT THE CONTROLLER
      BNE INIT7                  ;CLEAR TABLE END MARKER
      INC CTRLRS                 ;NOW GO TO NEXT P-TABLE
      CLR (R1)
      BR NXTTAB

```

1 ;SHOULD BE SAME CONTROLLER, CHECK THAT OTHER PARAMETERS MATCH
2
3 017500 016004 000004
4 017504 000304
5 017506 006104
6 017510 056004 000002
7 017514 020463 000004
8 017520 001004
9 017522 026063 000006 000006
10 017530 001402
11 017532 000137 017726
12
13 ;GET NEXT P-TABLE
14
15 017536 005202
16 017540 023702 002012
17 017544 003274
18
19 017546 012701 000001
20 017552 004737 011346
SAMTAB: MOV HO.BRL(R0),R4 :GET BR LEVEL FROM P-TABLE
SWAB R4 :SWAP TO HIGH BYTE
ROL R4 :SHIFT ONE MORE TO LEFT
BIS HO.VEC(R0),R4 :ADD VECTOR ADDRESS
CMP R4,C.VEC(R3) :COMPARE WITH CONTROLLER TABLE
BNE 1\$:COMPARE BURST RATES
BEQ NXTTAB :FATAL ERROR IF NOT SAME
1\$: JMP CTABER

NXTTAB: INC R2 :INCREMENT LOGICAL UNIT NUMBER
CMP L\$UNIT,R2 :CHECK IF GOT ALL TABLES
BGT INIT4 :IF NOT, GO BACK FOR NEXT

MOV #1,R1 :ALLOCATE SPACE FOR ZERO END WORD
CALL ALOCM :AFTER CONTROLLER TABLES

INITIALIZE SECTION

1 ;NOW BUILD DRIVE TABLES
2
3 017556 005002
4 017560 INIT8: CLR R2 ;LOGICAL UNIT NUMBER IN R2
5 017560 010200 GPHARD R2,R0 ;GET POINTER TO A P-TABLE
6 017562 104442
7 017564 BNCOMPLETE INIT14 ;IF NOT AVAILABLE, GO GET NEXT
8 017564 103040 BCC R2,R0
INIT14 C\$GPHRD
INIT14
9 017566 013703 002156
10 017572 021013 INIT10: MOV CTABS,R3 ;GET ADDRESS OF CONTROLLER TABLES
11 017574 001403 CMP (R0), (R3) ;CHECK IF SAME UNIBUS ADDRESS
12 017576 062703 BEQ INIT11 ;BRANCH IF TABLE FOUND
13 017602 000773 ADD #C.SIZE,R3 ;MOVE TO NEXT TABLE
BR INIT10

INITIALIZE SECTION

```

1 ;BUILD DRIVE TABLE
2
3 017604 012701 000015 INIT11: MOV #D.SIZE/2,R1      ;GET SIZE OF DRIVE TABLE
4 017610 004737 011346   CALL ALOCM          ;ALLOCATE SPACE FROM FREE MEMORY
5           ; R0 POINTS TO P-TABLE
6           ; R1 POINTS TO DRIVE TABLE
7           ; R3 POINTS TO CONTROLLER TABLE
8           ; R2 IS UNIT NUMBER
9 017614 010337 003250   MOV R3,TEMP        ;SAVE CONTROLLER TABLE ADDRESS
10          ;IN CASE AN ERROR IS DETECTED
11 017620 062703 000020   ADD #C.DR0,R3      ;BUILD POINTER TO C.DR ENTRY IN CONTROLLER TABLE
12 017624 012704 000010   MOV #8,,R4        ;GET MAX COUNT OF DRIVES ON ONE CONTROLLER
13 017630 005713          INIT12: TST (R3)      ;CHECK IF ENTRY CONTAINS POINTER TO DRIVE TABLE
14 017632 0C1411          BEQ INIT13        ;CHECK DRIVE NUMBER IN DRIVE TABLE
15 017634 026033 000010   CMP HO.LDR(R0),@R3+    ;IF SAME, TWO P-TABLES POINT TO SAME DRIVE
16 017640 001002          BNE 1$           ;COUNT DRIVES
17 017642 000137 017742   JMP MLDRER        ;IF EIGHT DRIVE TABLES EXIST,
18 017646 005304          1$: DEC R4         ;THEN REPORT ERROR
19 017650 001367          BNE INIT12        ;LOAD DRIVE TABLE POINTER
20 017652 000137 017760   JMP TOOMER        ;LOAD DRIVE NUMBER
21 017656 010113          INIT13: MOV R1,(R3)    ;LOAD UNIT NUMBER
22 017660 016021 000010   MOV HO.LDR(R0),(R1)+  ;LOAD UNIT NUMBER
23 017664 010221

```

INITIALIZE SECTION

1 ;GO TO NEXT DRIVE TABLE
2
3 017666 005202 INIT14: INC R2 ;INCREMENT LOGICAL UNIT NUMBER
4 017670 023702 002012 CMP L\$UNIT,R2 ;CHECK IF GOT ALL TABLES
5 017674 003331 BGT INIT8 ;IF NOT, GET NEXT TABLE
6
7 ;SAVE CURRENT PARAMETERS TO FREE MEMORY
8
9 017676 013737 002146 002152 INIT15: MOV FFREE,FMEM ;SAVE START ADDRESS
10 017704 013737 002150 002154 MOV FSIZE,FMEMS ;SAVE SIZE
11
12 017712 012700 000000 INITXX: SETPRI #PRI00 ;SET RUNNING PRIORITY TO ZERO
017712 012700 000000 MOV #PRI00,RO
017716 104441 TRAP CSSPRI
13 017720 104435 CLOSE ;MAKE SURE DATA FILE IS CLOSED
017720 104435 TRAP CSCLOS
14 017722 104432 EXIT INIT ;EXIT INIT
017722 104432 TRAP CSEXIT
017724 000524 .WORD L10034-.

INITIALIZE SECTION

1			;DIFFERENT VECTORS, BR LEVELS OR BURST RATES FOR ONE CONTROLLER			
2	017726	010305	;TABER: MOV R3,R5 ERRSF 1.,ERR001 :GET CONTROLLER ADDRESS			
3	017730			TRAP	C\$ERSF	
	017730	104454		.WORD	1	
	017732	000001		.WORD	0	
	017734	000000		.WORD	ERR001	
	017736	010430				
4	017740		DOCLN			
	017740	104444		TRAP	C\$DCLN	
5						
6			;TWO P-TABLES FOR SAME DRIVE			
7	017742	013705	003250	MLDRER: MOV TEMP,R5 ERRSF 2.,ERR002 :GET CONTROLLER ADDRESS		
8	017746				TRAP	C\$ERSF
	017746	104454		.WORD	2	
	017750	000002		.WORD	0	
	017752	000000		.WORD	ERR002	
	017754	010446		.WORD		
9	017756		DOCLN			
	017756	104444		TRAP	C\$DCLN	
10						
11			;MORE THAN EIGHT DRIVES SELECTED ON ONE CONTROLLER			
12						
13	017760	013705	003250	TOOMER: MOV TEMP,R5 ERRSF 3.,ERR003 :GET CONTROLLER ADDRESS		
14	017764				TRAP	C\$ERSF
	017764	104454		.WORD	3	
	017766	000003		.WORD	0	
	017770	000000		.WORD	ERR003	
	017772	010464		.WORD		
15	017774		DOCLN			
	017774	104444		TRAP	C\$DCLN	
16						
17			;TWO UDA'S USE THE SAME VECTOR			
18						
19	017776	010305		SAMVEC: MOV R3,R5 ERRSF 8.,ERR008 :GET CONTROLLER ADDRESS		
20	020000				TRAP	C\$ERSF
	020000	104454		.WORD	8	
	020002	000010		.WORD	ERR008	
	020004	010540		.WORD	0	
	020006	000000				
21	020010		DOCLN			
	020010	104444		TRAP	C\$DCLN	

1 020012			DATE: GMANID DATEQ,DATEI,A,-1,1,11.,YES	;GET DATE	
020012	104443			TRAP	CSGMAN
020014	000406			BR	10000\$
020016	003276			.WORD	DATEI
020020	000152			.WORD	TSCODE
020022	003526			.WORD	DATEQ
020024	177777			.WORD	-1
020026	000001			.WORD	TSLOLIM
020030	000013			.WORD	TSHILIM
020032					10000\$:
2 020032	012705	003276	MOV #DATEI,R5 :GET POINTER TO ANSWER		
3 020036	121527	000060	CMPB (R5),#0		
4 020042	103443		BLO DERR		
5 020044	122527	000071	CMPB (R5)+,#9		
6 020050	101040		BHI DERR		
7 020052	121527	000055	CMPB (R5),#-		
8 020056	001406		BEQ DAS1		
9 020060	121527	000060	CMPB (R5),#0		
10 020064	103432		BLO DERR		
11 020066	122527	000071	CMPB (R5)+,#9		
12 020072	101027		BHI DERR		
13 020074	122527	000055	DAS1: CMPB (R5)+,#-		
14 020100	001024		BNE DERR		
15 020102	012704	000014	MOV #12.,R4 :GET NUMBER OF MONTH		
16 020106	012703	003353	MOV #MONTHS,R3 :GET POINTER TO MONTH NAMES		
17 020112	005000		MON1: CLR R0		
18 020114	121523		CMPB (R5),(R3)+		
19 020116	001401		BEQ MON2		
20 020120	005200		INC R0		
21 020122	126523	000001	MON2: CMPB 1(R5),(R3)+		
22 020126	001401		BEQ MON3		
23 020130	005200		INC R0		
24 020132	126523	000002	MON3: CMPB 2(R5),(R3)+		
25 020136	001401		BEQ MON4		
26 020140	005200		INC R0		
27 020142	005700		MON4: TST R0		
28 020144	001407		BEQ MON5		
29 020146	005304		DEC R4		
30 020150	001360		BNE MON1		
31 020152			DERR: PNTF DATEX		
020152	004137	014650			JSR R1,LPNTF
020156	010330				.WORD DATEX
020160	000000				.WORD PNT.CT
32 020162	000713		MON5: BR DATE		
33 020164	012701	003312	MOV #DATE0,R1 :GET POINTER TO DATE FOR FORMATTER		
34 020170	010403		MOV R4,R3 :GET COPY OF MONTH NUMBER		
35 020172	020327	000012	CMP R3,#10. ; IF 10 OR GREATER		
36 020176	103404		BLO MON6		
37 020200	112721	000061	MOV B #'1,(R1)+ ;PUT A "1" IN OUTPUT		
38 020204	162703	000012	SUB #10.,R3		
39 020210	062703	000060	MON6: ADD #'0,R3 :CONVERT MONTH NUMBER TO ASCII		
40 020214	110321		MOV B R3,(R1)+ ;PUT A NUMBER IN OUTPUT		
41 020216	112721	000055	MOV B #'-,R1+ ;PUT A "-" IN OUTPUT		
42 020222	062704	003416	ADD #DAY\$-1,R4 :GET POINTER TO DAYS IN MONTH		
43					,INDEXED BY NUMBER OF MONTH
44 020226	012703	003276	MOV #DATEI,R3 :GET POINTER TO DATE INPUT		
45 020232	005000		CLR R0		

INITIALIZE SECTION

SEQ 0136

46 020234	121327	000055	DAY1:	CMPB (R3),#'- BEQ DAY2 MOVB (R3),(R1)+ ;PUT DAY CHARACTER IN OUTPUT ASL R0 MOV R0,R2 ASL R0 ASL R0 ADD R2,R0 MOVB (R3)+,R2 SUB #'0,R2 ADD R2,R0 BR DAY1 CMPB R0,(R4) BHI DERR TST R0 ;SEE IF DATE IS ZERO BEQ DERR ;ERROR IF SO ADD #3,R5 CMPB (R5),#'- ;CHECK FOR "--" BETWEEN DAY BNE DERR ; AND YEAR IN OUTPUT MOVB (R5)+,(R1)+ ;PUT "--" IN OUTPUT MOV R5,R4 ;GET COPY OF INPUT STRING POINTER CLR R0 CLR R2
47 020240	001413			
48 020242	111321			
49 020244	006300			
50 020246	010002			
51 020250	006300			
52 020252	006300			
53 020254	060200			
54 020256	112302			
55 020260	162702	000060	DAY2:	
56 020264	060200			
57 020266	000762			
58 020270	120014			
59 020272	101327			
60 020274	005700			
61 020276	001725			
62 020300	062705	000003		
63 020304	121527	000055		
64 020310	001320			
65 020312	112521			
66 020314	010504			
67 020316	005000			
68 020320	005002			
69 020322	121427	000060	YER1:	CMPB (R4),#'0 BLO YER2 CMPB (R4),#'9 BHI YER2 ASL R0 MOV R0,R3 ASL R0 ASL R0 ADD R3,R0 MOVB (R4)+,R3 SUB #'0,R3 ADD R3,R0 INC R2 BR YER1
70 020326	103416			
71 020330	121427	000071		
72 020334	101013			
73 020336	006300			
74 020340	010003			
75 020342	006300			
76 020344	006300			
77 020346	060300			
78 020350	112403			
79 020352	162703	000060		
80 020356	060300			
81 020360	005202			
82 020362	000757		YER2:	TSTB (R4) BNE DERR CMP R2,#2 BEQ YER3 CMP R2,#4 BNE DERR CMP R0,#1900. BLO DERR BR YERS
83 020364	105714			
84 020366	001271			
85 020370	020227	000002		
86 020374	001407			
87 020376	020227	000004		
88 020402	001263			
89 020404	020027	003554		
90 020410	103660			
91 020412	000413		YER3:	MOV #YEAR19,R2 CMP R0,#70. BHIS YER4 MOV #YEAR20,R2
92 020414	012702	003433		
93 020420	020027	000106		
94 020424	103002		YER4:	TSTB (R2) BEQ YERS MOVB (R2)+,(R1)+ BR YER4
95 020426	012702	003436		
96 020432	105712		YER5:	MOVB (R5)+,(R1)+ BNE YERS RETURN
97 020434	001402			
98 020436	112221			
99 020440	000774			
100 020442	112521			
101 020444	001376			
102 020446	000207			

CZUDEBO UDA-50 DISK FORMATTER MACRO V04.00 14-APR-82 16:50:39 PAGE 124-2
INITIALIZE SECTION

103
104 020450
020450
020450 104411

ENDINIT

H 11
L10034: TRAP C\$INIT

SEQ 0137

1 .SBTL AUTODROP SECTION
2
3 :++
4 : THIS CODE IS EXECUTED IMMEDIATELY AFTER THE INITIALIZE CODE IF
5 : THE "ADR" FLAG WAS SET. THE UNIT(S) UNDER TEST ARE CHECKED TO
6 : SEE IF THEY WILL RESPOND. THOSE THAT DON'T ARE IMMEDIATELY
7 : DROPPED FROM TESTING.
8 :--
9
10 020452 BGNAUTO L\$AUTO::
11 020452
12 020452 ENDAUTO L10035:
12 020452 104461 TRAP C\$AUTO

1 .SBttl CLEANUP CODING SECTION
2
3 :++
4 : THE CLEANUP CODING SECTION CONTAINS THE CODING THAT IS PERFORMED
5 : AFTER THE HARDWARE TESTS HAVE BEEN PERFORMED.
6 :--
7
8 020454 BGNCLN L\$CLEAN::
9 020454
10 020454 104435 CLOSE ;CLOSE DATA FILE TRAP CSCLOS
11 020456 BRESET ;RESET ALL UDAS TRAP CSRESET
12 020456 104433
13 020460 ENDCLN L10036: TRAP CSCLEAN
14 020460 104412
15 020462 ENDMOD

```

1 .SBTTL TEST 1: DUP PROGRAM DRIVER
2
3 020462 BGNMOD
4
5 020462 BGNST
6 020462 032737 000003 003210 BIT #SO.FMT,MODE
7 020470 001157 BNE T1FMT
8 020472 MANUAL
9 020472 104450 TRAP C$MANI
10 020474 103406 BCS T1GO
11 020476 020476 104454 TRAP CSERSF
12 020500 000012 .WORD 10
13 020502 000000 .WORD 0
14 020504 010526 .WORD ERR010
15 020506 EXIT TST
16 020506 104432 TRAP C$EXIT
17 020510 000350 .WORD L10037-
18 020512 032737 000010 003210 T1GO: BIT #SO.STR,MODE
19 020520 001432 BEQ T1CNS
20 020522 023727 002012 000001 CMP LSUNIT,#1
21 020530 001406 BEQ T1RST
22 020532 104454 TRAP CSERSF
23 020534 000011 .WORD 9
24 020536 000000 .WORD 0
25 020540 010514 .WORD ERR009
26 020542 104432 EXIT TST
27 020542 000314 TRAP C$EXIT
28 020544 000314 .WORD L10037-
29 020546 T1RST: PNTF FILNAM JSR R1,LPNTF
30 020546 004137 014650 .WORD FILNAM
31 020552 010347 .WORD PNT.CT
32 020554 000000
33 020556 GMANID FILNAQ,FNAME,A,-1,1,10.,NO ;GET FILE NAME
34 020556 104443 TRAP C$GMAN
35 020560 000406 BR 10000$,
36 020562 003234 .WORD FNAME
37 020564 000142 .WORD TS$CODE
38 020566 003556 .WORD FILNAQ
39 020570 177777 .WORD -1
40 020572 000001 .WORD T$LOLIM
41 020574 000012 .WORD T$HILIM
42 020576 OPEN #FNAME 10000$:
43 020576 012700 003234 MOV #FNAME,RO
44 020602 104434 TRAP C$OPEN
45 020604 000511 T1CNS: BR T1FMT
46 020606 013705 002156 T1SER1: MOV CTABS,R5
47 020612 010504 MOV R5,R4
48 020614 062704 ADD #C.DR0,R4
49 020620 012703 000020 MOV #8.,R3
50 020624 011402 T1SER2: MOV (R4),R2 ;GET DRIVE TABLE POINTER
51 020626 001474 BEQ T1SERN

```

29 020630		PNTF SERNUM,D.UNIT(R2),(R5),(R2)		
020630	011246		MOV (R2),-(SP)	
020632	011546		MOV (R5),-(SP)	
020634	016246	000002	MOV D.UNIT(R2),-(SP)	
020640	004137	014650	JSR R1,LPNTF	
020644	004151		.WORD SERNUM	
020646	000006		.WORD PNT.CT	
30 020650		ASSUME C.UADR EQ 0		
31 020650		ASSUME D.DRV EQ 0		
32 020650		T1SER3: GMANID SERNQ,TEMP,A,-1,1,20.,NO ;GET SERIAL NUMBER		
020650	104443		TRAP CSGMAN	
020652	000406		BR 10001\$	
020654	003250		.WORD TEMP	
020656	000142		.WORD T\$CODE	
020660	003610		.WORD SERNQ	
020662	177777		.WORD -1	
020664	000001		.WORD T\$LOLIM	
020666	000024		.WORD T\$HILIM	
020670			10001\$:	
33 020670	012701	003250		
34 020674	005000		MOV #TEMP,R1	
35 020676	105711		CLR R0	
36 020700	001410		T1SER4: TSTB (R1)	
37 020702	005200		BEQ T1SER5	
38 020704	121127	000060	INC R0	
39 020710	103416		CMPB (R1),#0	
40 020712	122127	000071	BLO T1SER7	
41 020716	101767		CMPB (R1)+,#9	
42 020720	000412		BLOS T1SER4	
43 020722	020027	000024	BR T1SER7	
44 020726	103422		T1SER5: CMP R0,#20.	
45 020730	012701	003250	BLO T1SER8	
46 020734	012700	003326	MOV #TEMP,R1	
47 020740	122120		MOV #HIGHEST,R0	
48 020742	001776		T1SER6: CMPB (R1)+(R0)+	
49 020744	103413		BEQ T1SER6	
50 020746	012746	003326	BLO T1SER8	
	012746	010240	T1SER7: PRINTF #SERNX,#HIGHEST	
	012746	000002		
	020756		MOV #HIGHEST,-(SP)	
	020762		MOV #SERNX,-(SP)	
	020764		MOV #2,-(SP)	
	020766	062706	MOV SP,R0	
	020772	000726	TRAP CSPNTF	
	020774	062702	ADD #2,SP	
	53 021000	012701	003250	ADD #D.SERN,R2 ;PUT ANSWER INTO DRIVE TABLE
	54 021004	112122	MOV #TEMP,R1	
	55 021006	001376	T1SER8: MOVVB (R1)+(R2)+	
	56 021010	005303	BNE T1SER9	
	57 021012	001402	DEC R3	
	58 021014	005724	BEQ T1SERN	
	59 021016	000702	TST (R4)+	
	60 021020	062705	BR T1SER2	
	61 021024	005715	T1SERN: ADD #C.SIZE,R5	
	62 021026	001271	TST (R5)	
	63 021030	013737	BNE T1SER1	
	64 021036	013701	MOV CTABS,TSTTAB	
		002156 002162 T1FMT: MOV CTRLRS,R1	:GET FIRST TABLE ADDRESS	
			;RUN DM PROGRAM ON ALL CONTROLLERS	

65 021042	004737	011410	CALL RUNDM	: AT ONCE	
66 021046	001402		BEQ 6\$		
67 021050	004737	011522	CALL RESPDM		
68 021054			EXIT TST		
021054	104432				TRAP C\$EXIT
021056	000002				.WORD L10037-.
69 021060			ENDTST	L10037:	
021060					TRAP C\$SETST
021060	104401				
70 021062			ENDMOD		

1 .SBTTL HARDWARE PARAMETER CODING SECTION
2
3 021062
4
5 :++
6 : THE HARDWARE PARAMETER CODING SECTION CONTAINS MACROS
7 : THAT ARE USED BY THE SUPERVISOR TO BUILD P-TABLES. THE
8 : MACROS ARE NOT EXECUTED AS MACHINE INSTRUCTIONS BUT ARE
9 : INTERPRETED BY THE SUPERVISOR AS DATA STRUCTURES. THE
10 : MACROS ALLOW THE SUPERVISOR TO ESTABLISH COMMUNICATIONS
11 : WITH THE OPERATOR.
12 :--
13
14 021062 000027 BGNMOD .WORD L10040-L\$HARD/2
15 021062
16 021064 L\$HARD::
17
18 021064 TABLE ;START A TABLE DEFINITION
19
20 021064 ITEM HO.UBA 2 : UNIBUS ADDRESS
21 021064 ITEM HO.VEC 2 : UDA VECTOR
22 021064 ITEM HO.BRL 2 : BR LEVEL
23 021064 ITEM HO.BST 2 : BURST RATE
24 021064 ITEM HO.LDR 2 : DRIVE NUMBER
25 021064 END

HARDWARE PARAMETER CODING SECTION

1 021064				GPRMA	H.UBA,HO.UBA,O,160000,177774,YES	:BUS ADDRESS		
021064	000031					.WORD	T\$CODE	
021066	021142					.WORD	H.UBA	
021070	160000					.WORD	T\$LOLIM	
021072	177774					.WORD	T\$HILIM	
2 021074				GPRMA	H.VEC,HO.VEC,O,4,774,YES	: VECTOR		
021074	001031					.WORD	T\$CODE	
021076	021170					.WORD	H.VEC	
021100	000004					.WORD	T\$LOLIM	
021102	000774					.WORD	T\$HILIM	
3 021104				GPRMD	H.BRL,HO.BRL,D,-1,4.,7.,YES	: BR LEVEL		
021104	002052					.WORD	T\$CODE	
021106	021177					.WORD	H.BRL	
021110	177777					.WORD	-1	
021112	000004					.WORD	T\$LOLIM	
021114	000007					.WORD	T\$HILIM	
4 021116				GPRMD	H.BST,HO.BST,D,-1,0.,63.,YES	: BURST RATE		
021116	003052					.WORD	T\$CODE	
021120	021210					.WORD	H.BST	
021122	177777					.WORD	-1	
021124	000000					.WORD	T\$LOLIM	
021126	000077					.WORD	T\$HILIM	
5 021130				GPRMD	H.LDR,HO.LDR,D,-1,0.,255.,YES	: DRIVE SELECT NUMBER		
021130	004052					.WORD	T\$CODE	
021132	021232					.WORD	H.LDR	
021134	177777					.WORD	-1	
021136	000000					.WORD	T\$LOLIM	
021140	000377					.WORD	T\$HILIM	
6 021142				ENDHRD				
7								
8 021142	125	116	111	H.UBA:	.ASCIZ \UNIBUS ADDRESS OF UDA\			
9 021170	126	105	103	H.VEC:	.ASCIZ \VECTOR\			
10 021177	102	122	040	H.BRL:	.ASCIZ \BR LEVEL\			
11 021210	125	116	111	H.BST:	.ASCIZ \UNIBUS BURST RATE\			
12 021232	104	122	111	H.LDR:	.ASCIZ \DRIVE NUMBER\			
13				.EVEN				
						EVEN		
						L10040:		

SOFTWARE PARAMETER CODING SECTION

1 .SBTTL SOFTWARE PARAMETER CODING SECTION
2
3
4 :++
5 : THE SOFTWARE PARAMETER CODING SECTION CONTAINS MACROS
6 : THAT ARE USED BY THE SUPERVISOR TO BUILD P-TABLES. THE
7 : MACROS ARE NOT EXECUTED AS MACHINE INSTRUCTIONS BUT ARE
8 : INTERPRETED BY THE SUPERVISOR AS DATA STRUCTURES. THE
9 : MACROS ALLOW THE SUPERVISOR TO ESTABLISH COMMUNICATIONS
10 : WITH THE OPERATOR.
11 :--
12 021250 000022 BGNSFT .WORD L10041-L\$SOFT/2
13 021252 L\$SOFT::
14 :FORMAT OF SOFTWARE P-TABLE IS AS FOLLOWS:
15
16 021252 TABLE :START A TABLE DEFINITION
17
18 021252 ITEM SO.BIT 2 :YES/NO ANSWERS
19 000001 SO.FM1 = BIT0 : REFORMAT MODE
20 000002 SO.FM2 = BIT1 : (AGAIN)
21 000003 SO.FMT = SO.FM1+SO.FM2
22 000004 SO.CNS = BIT2 : RECONSTRUCT MODE
23 000010 SO.STR = BIT3 : RESTORE MODE
24
25 021252 END

1 021252			GPRML S.FMT,SO.BIT,SO.FM1,YES ;REFORMAT?		
021252	000130			.WORD	T\$CODE
021254	021467			.WORD	S.FMT
021256	000001			.WORD	SO.FM1
2 021260			XFERT SWEND		
021260	017024			.WORD	T\$CODE
3 021262			GPRML S.NRF,SO.BIT,SO.FM2,YES ;AGAIN - REFORMAT?		
021262	000130			.WORD	T\$CODE
021264	021316			.WORD	S.NRF
021266	000002			.WORD	SO.FM2
4 021270			XFERT SWEND		
021270	013024			.WORD	T\$CODE
5 021272			GPRML S.CNS,SO.BIT,SO.CNS,YES ;RECONSTRUCT		
021272	000130			.WORD	T\$CODE
021274	021546			.WORD	S.CNS
021276	000004			.WORD	SO.CNS
6 021300			XFERT SWEND		
021300	007024			.WORD	T\$CODE
7 021302			GPRML S.RST,SO.BIT,SO.STR,YES ;RESTORE?		
021302	000130			.WORD	T\$CODE
021304	021611			.WORD	S.RST
021306	000010			.WORD	SO.STR
8 021310			XFERT SWEND		
021310	003024			.WORD	T\$CODE
9 021312			DISPLAY S.NOF ;WARNING		
021312	000003			.WORD	T\$CODE
021314	021732			.WORD	S.NOF
10 021316			SWEND: ENDSFT		.EVEN
021316				L10041:	
11					
12 021316	015	012	S.NRF: .BYTE 15,12		
13 021320	116	117	.ASCII\NOT USING EXISTING INFORMATION WILL DESTROY THE FACTORY BAD SECTOR\		
14 021422	015	012	.BYTE 15,12		
15 021424	111	116	.ASCII\INFORMATION ON THE DISKS.\		
16 021455	015	012	.BYTE 15,12		
17 021457	101	107	.ASCII\AGAIN - \		
18 021467	122	105	S.FMT: .ASCIZ\REFORMAT USING EXISTING BAD SECTOR INFORMATION\		
19 021546	122	105	S.CNS: .ASCIZ\RECONSTRUCT BAD SECTOR INFORMATION\		
20 021611	104	117	S.RST: .ASCII\DO YOU HAVE A FILE ON THE SYSTEM LOAD DEVICE\		
21 021665	015	012	.BYTE 15,12		
22 021667	040	103	.ASCIZ\ CONTAINING BAD SECTOR INFORMATION\		
23 021732	131	117	S.NOF: .ASCIZ\YOU CANNOT PROCEED WITHOUT SUCH A FILE.\		
24 022002	122	105	.ASCIZ\RESTART PROGRAM AND SELECT TO REFORMAT OR RECONSTRUCT DISK.\		
25 022076	000	123	.BYTE 0		
26			.EVEN		
27					
28					
29 000000			.DSABL AMA		
			.PSECT END		

1 .SBttl PATCH AREA
2
3 000000 000050 \$PATCH::
4 .REPT 40.
5 .WORD 0
6 .ENDR
7
8 000120 LASTAD
9
10 000124 000142' L\$LAST::
000122 000007
000124
10 000124 ENDMOD
11 .EVEN
12 .WORD T\$FREE
13 .WORD T\$SIZE

F 12

1 000124 BGNSETUP 1
2
3 000124 BGNPTAB .WORD 0
000124 000000 .WORD L10044-. /2-1
000126 000005
000130
4
5 000130 172150 .WORD 172150 : UNIBUS ADDRESS
6 000132 000154 .WORD 154 : VECTOR ADDRESS
7 000134 000005 .WORD 5 : BR LEVEL
8 000136 000077 .WORD 63. : UNIBUS BURST RATE
9 000140 000000 .WORD 0. : LOGICAL DRIVE NUMBER
10
11 000142 ENDPTAB L10044:
000142
12
13 000142 ENDSETUP
14
15
16
17
18
19
20
21 000001 .END
ERRORS DETECTED: 0

VIRTUAL MEMORY USED: 29184 WORDS (114 PAGES)
DYNAMIC MEMORY AVAILABLE FOR 70 PAGES
ZUDEBO,A:ZUDEBO/C=[20,0]SVC34R.MLB/P:1,ZUDEBO.DOC,ZUDEBO.MAC

	110-36	111-5													
C\$ERHR	27-8#														
C\$ERRO	27-8#														
C\$ERSF	27-8#	56-7	123-3	123-8	123-14	123-20	127-10	127-16							
C\$ERSO	27-8#														
C\$ESCA	27-8#														
C\$ESEG	27-8#														
C\$E\$UB	27-8#														
C\$ETST	27-8#	127-69													
C\$EXIT	27-8#	122-14	127-11	127-17	127-68										
C\$GETB	27-8#	72-23													
C\$GETW	27-8#														
C\$GMAN	27-8#	124-1	127-20	127-32											
C\$GPHR	27-8#	117-10	120-4												
C\$GPLO	27-8#														
C\$GPRI	27-8#														
C\$INIT	27-8#	124-104													
C\$INLP	27-8#														
C\$MANI	27-8#	127-8													
C\$MEM	27-8#	116-34													
C\$MSG	27-8#	54-16	54-20	54-24	54-28	54-32	54-36	54-40	54-44	54-53	54-59	54-73	54-77	54-81	
	54-85	54-89	54-94	54-98	54-102	54-106	54-110	54-114	54-118						
C\$OPEN	27-8#	72-19	127-21												
C\$PNTB	27-8#	91-14													
C\$PNTF	27-8#	91-12	127-50												
C\$PNTS	27-8#	91-18													
C\$PNTX	27-8#	54-58	91-16												
C\$QIO	27-8#														
C\$RDBU	27-8#														
C\$REFG	27-8#	116-10	116-12	116-14	116-16										
C\$RESE	27-8#	27-8#	116-33	126-11											
C\$REVI	27-8#	27-34													
C\$RFLA	27-8#														
C\$RPT	27-8#														
C\$SEFG	27-8#														
C\$SPRI	27-8#	122-12													
C\$SVEC	27-8#	94-20	107-27	116-54											
C\$TPRI	27-8#														
C.BST	42-19#	106-17	119-9												
C.DR0	42-35#	61-15	74-12	121-11	127-25										
C.DR1	42-36#														
C.DR2	42-37#														
C.DR3	42-38#														
C.DR4	42-39#														
C.DR5	42-40#														
C.DR6	42-41#														
C.DR7	42-42#														
C.FLG	42-22#	59-23*	60-10	60-13	60-15	60-38	60-43	60-47*	61-12*	62-6	62-26	63-35*	63-39*	63-40	
	63-47*	63-50*	63-62*	63-63	63-69*	63-70	95-13*	95-14*	98-21*	100-17	101-1*				
C.JAD	42-21#														
C.JSR	42-20#	94-19													
C.PRI	42-46#	63-65	63-67	63-72*	63-73*										
C.REF	42-47#	62-19	98-16*	98-17											
C.RING	42-34#	54-134	58-15*	60-9	63-29	97-16	98-15	105-20	106-3	106-22	107-20				
C.SIZE	42-49#	59-32	61-5	117-27	118-3	120-12	127-60								
C.TO	42-43#	60-36	63-55	100-14	100-27	110-22	110-33								

INFOP	69-20	69-25#
INFOX	69-16	69-26#
INIT1	116-11	116-13 116-15 116-17 116-19#
INIT10	120-10#	120-13
INIT11	120-11	121-3#
INIT12	121-13#	121-19
INIT13	121-14	121-21#
INIT14	120-5	122-3#
INIT15	122-9#	
INIT2	116-21	116-24 116-29#
INIT3	116-31	116-33#
INIT4	117-10#	119-17
INIT5	117-16#	117-28
INIT7	118-17#	118-19
INIT8	120-4#	122-5
INITQT	116-18#	116-28
INITXX	122-12#	
ISR	31-10#	
IXE	31-10#	
J\$JMP	27-8#	
KNO	116-49	116-56#
KW.BRL	47-32#	116-51* 116-54
KW.CSR	47-31#	60-31 75-19 100-22 110-28 113-8* 114-13 116-40* 116-47* 116-50* 116-55* 113-7* 114-16 114-17
KW.EL	47-35#	60-33 60-36 100-24 100-27 104-26 104-27 104-28 110-30 110-33 113-6*
	116-41*	116-42*
KW.HZ	47-34#	104-16 114-18 116-53*
KW.VEC	47-33#	116-52* 116-54
KW11I	113-5#	116-54
KWOUT.	113-8	116-39# 116-55
KYES	116-44	116-46 116-50#
L\$ACP	27-34#	
L\$APT	27-34#	
L\$AUT	27-34#	
L\$AUTO	27-34	125-10#
L\$CCP	27-34#	
L\$CLEA	27-34	126-8#
L\$CO	27-34#	
L\$DEPO	27-34#	
L\$DESC	27-34	49-16#
L\$DESP	27-34#	
L\$DEVP	27-34#	
L\$DISP	27-34	28-9#
L\$DLY	27-34#	
L\$DTP	27-34#	
L\$DTYP	27-34#	
L\$DUT	27-34#	
L\$DVY	27-34	49-12#
L\$EF	27-34#	
L\$ENVI	27-34#	
L\$ETP	27-34#	
L\$EXP1	27-34#	
L\$EXP4	27-34#	
L\$EXP5	27-34#	
L\$HARD	27-34	128-14 128-14#
L\$HIME	27-34#	
L\$HPCP	27-34#	

CROSS REFERENCE TABLE (CREF V04.00)

L\$HPTP	27-34#				
LSHW	27-34	29-10	29-10#		
LSICP	27-34#				
LSINIT	27-34	116-8#			
LSLADP	27-34#				
LSLAST	27-34	132-8#	133-13		
LSLOAD	27-34#				
LSLUN	27-34#	59-24*	60-12*	74-14*	
LSMREV	27-34#				
LSNAME	27-34#				
LSPRIO	27-34#				
LSPROT	27-34	115-10#			
LSprt	27-34#				
LSREPP	27-34#				
LSREV	27-34#				
LSsoft	27-34	130-12	130-12#		
LSSPC	27-34#				
LSSPCP	27-34#				
LSsptp	27-34#				
LSSTA	27-34#				
LSSW	27-34	30-10	30-10#		
LSTEST	27-34#				
LSTIML	27-34#				
LSUNIT	27-34#	75-13	119-16	122-4	127-14
L10000	29-10	29-17#			
L10001	30-10	30-14#			
L10002	54-16#				
L10003	54-20#				
L10004	54-24#				
L10005	54-28#				
L10006	54-32#				
L10007	54-36#				
L10010	54-40#				
L10011	54-44#				
L10012	54-53#				
L10013	54-59#				
L10014	54-73#				
L10015	54-77#				
L10016	54-81#				
L10017	54-85#				
L10020	54-89#				
L10021	54-94#				
L10022	54-98#				
L10023	54-102#				
L10024	54-106#				
L10025	54-110#				
L10026	54-114#				
L10027	54-118#				
L10030	102-14#				
L10031	103-21#				
L10032	113-9#				
L10034	122-14	124-104#			
L10035	125-12#				
L10036	126-13#				
L10037	127-11	127-17	127-68	127-69#	
L10040	128-14	129-6#			

L10041	130-12	131-10#
L10042	133-3#	
L10044	133-3	133-11#
LDDM	59-22#	59-34
LDNEXT	59-26	59-30
LOADB	95-2#	
LOADDM	59-29	61-30
LOADE1	95-12	96-3#
LOADER	94-23	95-10
LOE	31-10#	
LOG	35-32#	
LOT	31-10#	
LPNT	92-6	
LPNTB	54-15 54-80 92-7#	54-19 54-84
LPNTF	75-15	76-41
LPNTS	92-11#	
LPNTX	92-9#	
MD.CMP	38-4#	
MD.CWB	38-22#	
MD.ERR	38-6#	
MD.EXP	38-5#	
MD.FEU	38-16#	
MD.IMF	38-20#	
MD.NXU	38-18#	
MD.PRI	38-23#	
MD.RIP	38-19#	
MD.SCH	38-7#	
MD.SCL	38-8#	
MD.SEC	38-9#	
MDSEQ	38-14#	
MD.SER	38-10#	
MD.SPD	38-15#	
MD.SSH	38-11#	
MD.SWP	38-21#	
MD.VOL	38-17#	
MD.WBN	38-12#	
MD.WBV	38-13#	
MESG	69-25	73-13#
MESSG	51-9#	75-15
MIDRER	121-17	123-7#
MODE	47-27#	68-53
MON1	124-17#	124-30
MON2	124-19	124-21#
MON3	124-22	124-24#
MON4	124-25	124-27#
MON5	124-28	124-33#
MON6	124-36	124-39#
MONTHS	48-7#	124-16
MSCP	35-31#	
MSGPKL	54-137#	54-140
MSGPKT	54-93	54-133#
NCONF	76-38	76-43#
NCONS	76-37#	76-40
NEWTAB	117-17	118-3#

NOCLOC	51-10#	116-48				
NULL	47-39#					
NXMAD	47-23#	102-12*	107-26*	107-31		
NXMI	102-10#	107-27				
NXTTAB	117-11	118-22	119-10	119-15#		
OSAPTS	27-8#	27-34				
OSAU	27-8#	27-34				
OSBGNR	27-8#	27-34				
OSBGNS	27-8#	27-32#	27-34			
OSDU	27-8#	27-34				
OSEERRT	27-8#	27-34				
OSGNSW	27-8#	27-32#	27-34			
OSPOIN	27-8#	27-32	27-32#	27-32#	27-34	
OSSETU	27-8#	27-32#	27-34	132-8		
OP.ABO	37-3#					
OP.ACC	37-4#					
OP.AVA	37-22#					
OP.AVL	37-5#					
OP.CCD	37-6#					
OP.CMP	37-7#					
OP.DUP	37-23#					
OP.ELP	37-29#					
OP.END	37-20#	62-5	62-8	63-58		
OP.ERS	37-8#					
OP.ESP	37-28#	95-2				
OP.FLU	37-9#					
OP.GCS	37-10#					
OP.GDS	37-27#	60-48	63-58			
OP.GUS	37-11#					
OP.MRD	37-18#					
OP.MWR	37-19#	97-21				
OP.ONL	37-12#					
OP.RD	37-13#					
OP.RLC	37-25#					
OP.RPL	37-14#					
OP.RSD	37-31#	62-8	63-43			
OP.SCC	37-15#					
OP.SEX	37-21#					
OP.SHG	37-24#					
OP.SSD	37-30#	62-5	63-13			
OP.SUC	37-16#					
OP.WR	37-17#					
OSTRE	76-35	76-42	76-47#			
OSTRNG	76-34#	76-46	84-6	85-6	86-6	92-17
P.BCNT	39-21#	40-9#	63-11	63-33*	95-5*	99-19*
P.BUFF	39-22#					
P.CMST	40-14#					
P.CNCL	40-48#					
P.CNTF	39-40#	40-46#				
P.CNTI	40-49#					
P.CPSP	39-34#					
P.CRF	39-17#	40-4#	62-19	98-17*		
P.CTMO	40-47#					
P.CYL	40-26#					
P.DEXT	40-52#					
P.DFLG	40-53#	63-60				

SA.CM1	33-32#
SA.CMD	33-27#
SA.CME	33-37#
SA.CTP	33-40#
SA.DI	33-19# 109-14
SA.ERC	33-13#
SA.ERR	33-9# 54-56 110-19
SA.GO	34-20# 106-20
SA.INE	34-4#
SA.INT	33-25#
SA.LFC	34-21#
SA.MCV	34-15# 109-38
SA.MS1	33-31#
SA.MSE	33-36#
SA.MSG	33-26#
SA.NV	33-17#
SA.NVE	34-5#
SA.PRG	33-44#
SA.S1	33-5# 108-3 109-14
SA.S2	33-6# 109-23
SA.S3	33-7# 109-31
SA.S4	33-8# 108-13 109-38
SA.STE	33-39#
SA.STP	33-29# 107-18
SA.TST	34-11# 109-8
SA.VCE	34-3#
SA.VEC	33-24#
SA.WRP	33-28#
SAMTAB	117-21 119-3#
SAMVEC	117-26 123-19#
SERNQ	50-5# 127-32
SERNUM	51-18# 127-29
SERNX	53-11# 127-50
SET00	104-17# 104-22
SET01	104-18 104-20#
SET02	104-26# 104-29
SETTO	63-56 100-15 104-14# 110-23
SFPTBL	30-10# 116-20 116-23 116-27
SNDCMD	63-52 95-8 98-14#
SO.BIT	130-18# 131-1 131-1 131-1 131-3 131-3 131-3 131-5 131-5 131-5 131-7 131-7 131-7
SO.CNS	116-22 116-26 130-22# 131-5
SO.FM1	130-19# 130-21 131-1
SO.FM2	130-20# 130-21 131-3
SO.FMT	68-53 116-19 127-6 130-21#
SO.STR	68-59 116-26 127-12 130-23# 131-7
SPECL	64-8 72-14# 72-28
SPECLC	72-18#
SPECLE	72-24 72-30#
SPECLL	72-23# 72-26
SPECLR	72-16 72-21#
SPECLX	72-15 72-31#
ST.ABO	41-7#
ST.AVL	41-9#
ST.CMD	41-6#
ST.CMP	41-12#
ST.CNT	41-15#

ST.DAT	41-13#
ST.DIA	41-17#
ST.DRV	41-16#
ST.HST	41-14#
ST.MFE	41-10#
ST.MSK	41-3# 62-14 95-11

62-14 95-11

109-44	109-44	109-44	109-44	109-44	109-44	109-44	109-44	109-44	109-44	109-44	110-27	110-27	110-27	110-36
110-36	110-36	110-36	110-36	110-36	110-36	110-36	110-36	110-36	110-36	110-36	111-5	111-5	111-5	111-5
111-5	111-5	111-5	111-5	111-5	111-5	111-5	111-5	111-5	111-5	113-9	113-9	113-9	113-9	113-9
116-10	116-10	116-10	116-10	116-11	116-11	116-11	116-12	116-12	116-12	116-12	116-12	116-12	116-12	116-13
116-13	116-13	116-14	116-14	116-14	116-14	116-14	116-14	116-14	116-15	116-15	116-15	116-16	116-16	116-16
116-16	116-16	116-16	116-17	116-17	116-17	116-18	116-18	116-18	116-33	116-33	116-33	116-34	116-34	116-34
116-34	116-34	116-34	116-34	116-43	116-43	116-43	116-43	116-43	116-43	116-44	116-44	116-44	116-44	116-45
116-45	116-45	116-45	116-45	116-45	116-46	116-46	116-46	116-54	116-54	116-54	116-54	116-54	116-54	116-54
116-54	116-54	116-54	116-54	116-54	116-54	116-54	116-54	116-54	116-54	116-54	116-54	116-54	116-54	116-54
117-10	117-10	117-10	117-10	117-11	117-11	117-11	120-4	120-4	120-4	120-4	120-4	120-4	120-4	120-5
120-5	120-5	122-12	122-12	122-12	122-12	122-12	122-12	122-13	122-13	122-13	122-14	122-14	122-14	122-14
122-14	122-14	122-14	123-3	123-3	123-3	123-3	123-3	123-3	123-3	123-3	123-3	123-3	123-3	123-3
123-3	123-4	123-4	123-4	123-8	123-8	123-8	123-8	123-8	123-8	123-8	123-8	123-8	123-8	123-8
123-8	123-8	123-9	123-9	123-9	123-14	123-14	123-14	123-14	123-14	123-14	123-14	123-14	123-14	123-14
123-14	123-14	123-14	123-15	123-15	123-15	123-20	123-20	123-20	123-20	123-20	123-20	123-20	123-20	123-20
123-20	123-20	123-20	123-20	123-21	123-21	123-21	124-1	124-1	124-1	124-1	124-1	124-1	124-1	124-1
124-1	124-1	124-1	124-1	124-1	124-1	124-1	124-1	124-1	124-1	124-1	124-1	124-1	124-1	124-1
124-1	124-1	124-1	124-104	124-104	124-104	125-12	125-12	125-12	126-10	126-10	126-10	126-10	126-11	126-11
126-11	126-13	126-13	126-13	127-8	127-8	127-8	127-9	127-9	127-9	127-9	127-10	127-10	127-10	127-10
127-10	127-10	127-10	127-10	127-10	127-10	127-10	127-10	127-11	127-11	127-11	127-11	127-11	127-11	127-11
127-16	127-16	127-16	127-16	127-16	127-16	127-16	127-16	127-16	127-16	127-16	127-16	127-16	127-17	127-17
127-17	127-17	127-17	127-17	127-20	127-20	127-20	127-20	127-20	127-20	127-20	127-20	127-20	127-20	127-20
127-20	127-20	127-20	127-20	127-20	127-20	127-20	127-20	127-20	127-20	127-20	127-20	127-20	127-20	127-20
127-21	127-21	127-21	127-21	127-21	127-21	127-32	127-32	127-32	127-32	127-32	127-32	127-32	127-32	127-32
127-32	127-32	127-32	127-32	127-32	127-32	127-32	127-32	127-32	127-32	127-32	127-32	127-32	127-32	127-32
127-32	127-32	127-50	127-50	127-50	127-50	127-50	127-50	127-50	127-50	127-50	127-50	127-50	127-50	127-50
127-50	127-50	127-50	127-50	127-50	127-50	127-68	127-68	127-68	127-68	127-68	127-68	127-68	127-69	127-69
127-69	128-14	128-14	128-14	129-1	129-1	129-1	129-1	129-1	129-1	129-1	129-1	129-1	129-1	129-1
129-1	129-1	129-2	129-2	129-2	129-2	129-2	129-2	129-2	129-2	129-2	129-2	129-2	129-2	129-2
129-3	129-3	129-3	129-3	129-3	129-3	129-3	129-3	129-3	129-3	129-3	129-3	129-3	129-3	129-3
129-3	129-4	129-4	129-4	129-4	129-4	129-4	129-4	129-4	129-4	129-4	129-4	129-4	129-4	129-4
129-4	129-4	129-5	129-5	129-5	129-5	129-5	129-5	129-5	129-5	129-5	129-5	129-5	129-5	129-5
129-5	129-5	129-5	129-6	129-6	129-6	130-12	130-12	130-12	131-1	131-1	131-1	131-1	131-1	131-1
131-1	131-1	131-1	131-1	131-2	131-2	131-2	131-3	131-3	131-3	131-3	131-3	131-3	131-3	131-3
131-3	131-3	131-4	131-4	131-4	131-5	131-5	131-5	131-5	131-5	131-5	131-5	131-5	131-5	131-5
131-6	131-6	131-6	131-7	131-7	131-7	131-7	131-7	131-7	131-7	131-7	131-7	131-7	131-8	131-8
131-8	131-9	131-9	131-9	131-9	131-9	131-9	131-10	131-10	131-10	131-10	132-8	132-8	132-8	132-8
132-8	132-8	132-8	132-8	132-8	133-3	133-3	133-3	133-3	133-3	133-3	133-3	133-3	133-3	133-3
SVCSUB	27-8#	27-12#	54-10#	55-3#										
	27-8#	27-14#	29-17	30-14	54-12#	54-16	54-16	54-16	54-20	54-20	54-20	54-24	54-24	54-24
	54-28	54-28	54-28	54-32	54-32	54-36	54-36	54-36	54-40	54-40	54-40	54-44	54-44	54-44
	54-44	54-53	54-53	54-53	54-59	54-59	54-59	54-73	54-73	54-73	54-77	54-77	54-77	54-81
	54-81	54-81	54-85	54-85	54-85	54-89	54-89	54-89	54-94	54-94	54-94	54-98	54-98	54-98
	54-102	54-102	54-102	54-106	54-106	54-110	54-110	54-110	54-114	54-114	54-114	54-118	54-118	54-118
	54-118	55-5#	102-14	103-21	113-9	124-1	124-104	125-12	126-13	127-20	127-32	127-69	129-6	1

	54-87#	54-89	54-91#	54-94	54-96#	54-98	54-100#	54-102	54-104#	54-106	54-108#	54-110	54-112#	54-114
TSSPC	54-116#	54-118												
TSSPRO	133-1#	133-13												
TSSPTA	133-1#	133-3	133-3#											
TSSSOF	130-12	130-12#	131-10											
TSSSRV	102-10#	102-14	103-18#	103-21	113-5#	113-9								
TSSSW	30-10	30-10#	30-14											
TSSTES	127-5#	127-11	127-17	127-68	127-69									
TSARGC	27-34	27-34	27-34	27-34	27-34	27-34	27-34	27-34	27-34	27-34	27-34#	27-34#	27-34#	
	27-34#	27-34#	27-34#	54-58	54-58	54-58#	91-12	91-12	91-12	91-12#	91-12#	91-14	91-14	91-14
	91-14#	91-14#	91-16	91-16	91-16	91-16#	91-16#	91-18	91-18	91-18	91-18#	91-18#	127-50	127-50
	127-50	127-50#	127-50#											
TSCODE	124-1	124-1	124-1	124-1#	124-1#	124-1#	127-20	127-20	127-20	127-20#	127-20#	127-20#	127-32	127-32
	127-32	127-32#	127-32#	127-32#	129-1	129-1	129-1#	129-1#	129-1#	129-1#	129-2	129-2	129-2	129-2#
	129-2#	129-2#	129-3	129-3	129-3	129-3#	129-3#	129-4	129-4	129-4	129-4#	129-4#	129-4#	129-4#
	129-5	129-5	129-5	129-5#	129-5#	129-5#	131-1	131-1	131-1	131-1#	131-1#	131-2	131-2	
	131-2	131-2	131-2	131-2	131-2#	131-2#	131-2#	131-3	131-3	131-3	131-3#	131-3#	131-3#	131-3#
	131-4	131-4	131-4	131-4	131-4	131-4	131-4#	131-4#	131-4#	131-4#	131-5	131-5	131-5	131-5#
	131-5#	131-5#	131-6	131-6	131-6	131-6	131-6	131-6	131-6#	131-6#	131-6#	131-7	131-7	131-7
	131-7	131-7#	131-7#	131-7#	131-8	131-8	131-8	131-8	131-8	131-8	131-8#	131-8#	131-8#	131-8#
	131-9	131-9#												
TSERRN	27-8#	56-7	56-7#	60-24	60-24#	61-36	61-36#	62-21	62-21#	63-8	63-8#	67-22	67-22#	69-30
	69-30#	96-3	96-3#	100-29	100-29#	101-5	101-5#	105-35	105-35#	106-11	106-11#	107-33	107-33#	109-44
	109-44#	110-36	110-36#	111-5	111-5#	123-3	123-3#	123-8	123-8#	123-14	123-14#	123-20	123-20#	127-10
TSEXCP	127-10#	127-16	127-16#		127-20#	127-32	127-32#	129-1	129-1#	129-2	129-2#	129-4	129-4#	
	124-1	124-1#	127-20		127-20#	127-32								
	129-5	129-5#												
TSFLAG	122-14	122-14	122-14#	122-14#	127-11	127-11	127-11#	127-11#	127-17	127-17	127-17#	127-17#	127-68	127-68
	127-68#	127-68#												
TSFREE	132-8	133-13#												
TSGMAN	27-8#	124-1	124-1#	124-1#	127-20	127-20#	127-20#	127-32	127-32#	127-32#	127-32#			
TSHILI	124-1	124-1#	127-20		127-20#	127-32	127-32#	129-1	129-1#	129-2	129-2#	129-3	129-3#	129-4
	129-5	129-5#												
TSLAST	27-8#	132-8#	133-1											
TSLOLI	124-1	124-1#	127-20		127-20#	127-32	127-32#	129-1	129-1#	129-2	129-2#	129-3	129-3#	129-4
	129-5	129-5#												
TSLSYM	27-8	27-8#	29-17	30-14	54-16	54-20	54-24	54-28	54-32	54-36	54-40	54-44	54-53	54-59
	54-73	54-77	54-81	54-85	54-89	54-94	54-98	54-102	54-106	54-110	54-114	54-118	102-14	103-21
	113-9	124-104	125-12	126-13	127-69	129-6	131-10							
TSLTNO	132-8#													
TSNEST	27-8#	27-26	27-26	27-26#	29-10	29-10	29-10#	29-17	29-17	29-17	29-17#	30-10	30-10	30-10#
	30-14	30-14	30-14	30-14#	30-16	30-16	30-16#	31-3	31-3	31-3	31-3#	54-14	54-14	54-14#
	54-16	54-16	54-16	54-16#	54-18	54-18	54-18#	54-20	54-20	54-20	54-20#	54-22	54-22	54-22#
	54-24	54-24	54-24	54-24#	54-26	54-26	54-26#	54-28	54-28	54-28	54-28#	54-30	54-30	54-30#
	54-32	54-32	54-32	54-32#	54-34	54-34	54-34#	54-36	54-36	54-36	54-36#	54-38	54-38	54-38#
	54-40	54-40	54-40	54-40#	54-42	54-42	54-42#	54-44	54-44	54-44	54-44#	54-46	54-46	54-46#
	54-53	54-53	54-53	54-53#	54-55	54-55	54-55#	54-59	54-59	54-59	54-59#	54-61	54-61	54-61#
	54-73	54-73	54-73	54-73#	54-75	54-75	54-75#	54-77	54-77	54-77	54-77#	54-79	54-79	54-79#
	54-81	54-81	54-81	54-81#	54-83	54-83	54-83#	54-85	54-85	54-85	54-85#	54-87	54-87	54-87#
	54-89	54-89	54-89	54-89#	54-91	54-91	54-91#	54-94	54-94	54-94	54-94#	54-96	54-96	54-96#
	54-98	54-98	54-98	54-98#	54-100	54-100	54-100#	54-102	54-102	54-102	54-102#	54-104	54-104	54-104#
	54-106	54-106	54-106	54-106#	54-108	54-108	54-108#	54-110	54-110	54-110	54-110#	54-112	54-112	54-112#
	54-114	54-114	54-114	54-114#	54-116	54-116	54-116#	54-118	54-118	54-118	54-118#	102-10	102-10	102-10#
	102-14	102-14	102-14	102-14#	103-18	103-18	103-18#	103-21	103-21	103-21	103-21#	113-5	113-5	113-5#
	113-9	113-9	113-9											

UF.CMR	39-3#					
UF.CMW	39-4#					
UF.INA	39-6#					
UF.RPL	39-5#					
UF.SCH	39-7#					
UF.SCL	39-8#					
UF.WBN	39-9#					
UF.WPH	39-10#					
UF.WPS	39-11#					
UFREEZ	47-22#	59-35*	61-3	61-13*	69-19	69-21*
URNING	47-20#	59-16*	59-31*	59-40	61-32*	
URUN	47-19#	59-15*	59-20	60-7		
WAITMS	95-9	100-11#				
X\$ALWA	27-8#					
X\$FALS	27-8#					
X\$OFFS	27-8#	131-2	131-4	131-6	131-8	
X\$TRUE	27-8#	131-2	131-4	131-6	131-8	
X1	52-5#	54-15				
X10	52-13#	54-35				
X100	52-37#	54-113				
X101	52-38#	54-117				
X1A	52-1#	54-15				
X2	52-6#	54-19				
X20	52-14#	54-43				
X21	52-18#	54-52				
X22	52-20#	54-57				
X23A	52-22#	54-62				
X23B	52-26#	54-66				
X24	52-27#	54-76				
X25	52-29#	54-80				
X2A	52-2#	54-19				
X3	52-7#	54-23				
X30	52-31#	54-84				
X31	52-32#	54-88				
X32	52-33#	54-92				
X36	52-34#	54-105				
X37	52-36#	54-109				
X3A	52-3#	54-23				
X4	52-8#	54-27				
X8	52-10#	54-39				
X8A	52-4#	54-39				
X9	52-11#	54-31				
XFRU	53-8#	54-58	54-72	85-5		
XMSG1	53-1#	54-133				
XMSG2	53-2#	54-137				
XPKT1	53-3#	54-120				
XPKT2	53-6#	54-126				
XSA	53-7#	86-5				
YEAR19	48-31#	124-92				
YEAR20	48-32#	124-95				
YER1	124-69#	124-82				
YER2	124-70	124-72	124-83#			
YER3	124-86	124-92#				
YER4	124-94	124-96#	124-99			
YERS	124-91	124-97	124-100#	124-101		

MSGGETS	29-17	29-17#	30-14	30-14#	30-16	30-16#	54-16	54-16#	54-20	54-20#	54-24	54-24#	54-28	54-28#
	54-32	54-32#	54-36	54-36#	54-40	54-40#	54-44	54-44#	54-53	54-53#	54-59	54-59#	54-73	54-73#
	54-77	54-77#	54-81	54-81#	54-85	54-85#	54-89	54-89#	54-94	54-94#	54-98	54-98#	54-102	54-102#
	54-106	54-106#	54-110	54-110#	54-114	54-114#	54-118	54-118#	102-14	102-14#	103-21	103-21#	113-9	113-9#
114-38	114-38#	115-16	115-16#	124-104	124-104#	125-12	125-12#	126-13	126-13#	126-15	126-15#	127-69	127-69#	
127-70	127-70#	129-6	129-6#	131-2	131-2#	131-4	131-4#	131-6	131-6#	131-8	131-8#	131-10	131-10#	
132-10	132-10#													
MSGGETT	122-14#	127-11#	127-17#	127-68#	131-2	131-2#	131-4	131-4#	131-6	131-6#	131-8	131-8#		
MSGNGB	27-26#	27-34	27-34	27-34	27-34	27-34	27-34	27-34	27-34	27-34	27-34	27-34	27-34	27-34
	27-34	27-34	27-34	27-34	27-34	27-34	27-34	27-34	27-34	27-34	27-34	27-34	27-34	27-34
	27-34	27-34	27-34	27-34	27-34	27-34	27-34	27-34	27-34	27-34	27-34	27-34	27-34	27-34
	27-34#	27-34#	27-34#	27-34#	27-34#	27-34#	27-34#	27-34#	27-34#	27-34#	27-34#	27-34#	27-34#	27-34#
	27-34#	27-34#	27-34#	27-34#	27-34#	27-34#	27-34#	27-34#	27-34#	27-34#	27-34#	27-34#	27-34#	27-34#
	27-34#	27-34#	27-34#	27-34#	27-34#	27-34#	27-34#	27-34#	27-34#	27-34#	27-34#	27-34#	27-34#	27-34#
	27-34#	27-34#	27-34#	27-34#	27-34#	27-34#	27-34#	27-34#	27-34#	27-34#	27-34#	27-34#	27-34#	27-34#
	30-10#	31-3#	49-12	49-12#	49-16	49-16#	54-14	54-14#	54-18	54-18#	54-22	54-22#	54-26	54-26#
	54-30	54-30#	54-34	54-34#	54-38	54-38#	54-42	54-42#	54-46	54-46#	54-55	54-55#	54-61	54-61#
	54-75	54-75#	54-79	54-79#	54-83	54-83#	54-87	54-87#	54-91	54-91#	54-96	54-96#	54-100	54-100#
	54-104	54-104#	54-108	54-108#	54-112	54-112#	54-116	54-116#	102-10	102-10#	103-18	103-18#	113-5	113-5#
115-3#	115-10	115-10#	116-8	116-8#	125-10	125-10#	126-8	126-8#	127-3#	127-3#	128-3#	128-3#	128-14	128-14#
130-12#	132-8	132-8#												130-12
MSGNIN	27-34	27-34	27-34	27-34	27-34	27-34	27-34	27-34	27-34	27-34	27-34	27-34	27-34	27-34
	27-34	27-34	27-34	27-34	27-34	27-34	27-34	27-34	27-34	27-34	27-34	27-34	27-34	27-34
	27-34	27-34	27-34	27-34	27-34	27-34	27-34	27-34	27-34	27-34	27-34	27-34	27-34	27-34
	27-34	27-34	27-34	27-34	27-34	27-34	27-34	27-34	27-34	27-34	27-34	27-34	27-34	27-34
	27-34#	27-34#	27-34#	27-34#	27-34#	27-34#	27-34#	27-34#	27-34#	27-34#	27-34#	27-34#	27-34#	27-34#
	27-34#	27-34#	27-34#	27-34#	27-34#	27-34#	27-34#	27-34#	27-34#	27-34#	27-34#	27-34#	27-34#	27-34#
	27-34#	27-34#	27-34#	27-34#	27-34#	27-34#	27-34#	27-34#	27-34#	27-34#	27-34#	27-34#	27-34#	27-34#
	49-12	49-12	49-12#	49-12#	49-16	49-16#	49-16	49-16#	54-16	54-16#	54-20	54-20#	54-24	54-24#
	54-28	54-28#	54-32	54-32#	54-36	54-36#	54-40	54-40#	54-44	54-44#	54-53	54-53#	54-58	54-58#
	54-58	54-58	54-58	54-58#	54-58#	54-58#	54-59	54-59#	54-73	54-73#	54-77	54-77#	54-81	
	54-81#	54-85	54-85#	54-89	54-89#	54-94	54-94#	54-98	54-98#	54-102	54-102#	54-106	54-106#	54-110
	54-110#	54-114	54-114#	54-118	54-118#	56-7	56-7	56-7	56-7	56-7#	56-7#	56-7#	56-7#	56-7#
	56-8	56-8#	60-8	60-8#	60-24	60-24	60-24	60-24	60-24#	60-24#	60-24#	60-24#	60-24#	61-36
	61-36	61-36	61-36	61-36#	61-36#	61-36#	61-36#	61-36#	62-21	62-21	62-21	62-21	62-21	62-21#
	62-21#	62-21#	62-21#	63-8	63-8	63-8	63-8	63-8#	63-8#	63-8#	63-8#	63-8#	67-22	67-22
	67-22	67-22	67-22#	67-22#	67-22#	67-22#	67-22#	69-30	69-30	69-30	69-30	69-30	69-30#	69-30#
	69-30#	69-30#	72-18	72-18#	72-19	72-19	72-19	72-19#	72-23	72-23	72-23	72-23#	72-24	72-24#
	91-12	91-12	91-12	91-12	91-12	91-12	91-12#	91-12#	91-12#	91-12#	91-12#	91-12#	91-14	91-14
	91-14	91-14	91-14	91-14#	91-14#	91-14#	91-14#	91-14#	91-16	91-16	91-16	91-16	91-16	91-16
	91-16#	91-16#	91-16#	91-16#	91-16#	91-18	91-18	91-18	91-18	91-18	91-18	91-18#	91-18#	91-18#
	91-18#	91-18#	94-20	94-20	94-20	94-20	94-20	94-20#	94-20#	94-20#	94-20#	94-20#	94-20#	94-20#
	96-3	96-3	96-3	96-3#	96-3#	96-3#	96-3#	96-3#	100-21	100-21#	100-29	100-29	100-29	100-29
100-29	100-29#	100-29#	100-29#	100-29#	100-29#	101-5	101-5	101-5	101-5	101-5#	101-5#	101-5#	101-5#	
101-5#	102-14	102-14#	103-21	103-21#	105-35	105-35	105-35	105-35	105-35#	105-35#	105-35#	105-35#	105-35#	105-35#
106-11	106-11	106-11	106-11	106-11#	106-11#	106-11#	106-11#	106-11#	107-12	107-12#	107-27	107-27	107-27	107-27
107-27	107-27	107-27	107-27#	107-27#	107-27#	107-27#	107-27#	107-27#	107-30	107-30	107-30#	107-30#	107-30#	107-33
107-33	107-33	107-33	107-33	107-33#	107-33#	107-33#	107-33#	107-33#	109-44	109-44	109-44	109-44	109-44	109-44#
109-44#	109-44#	109-44#	110-27	110-27#	110-36	110-36	110-36	110-36	110-36#	110-36#	110-36#	110-36#	110-36#	110-36#
	111-5	111-5	111-5	111-5#	111-5#	111-5#	111-5#	111-5#	113-9	113-9#	116-10	116-10	116-10	116-10#
	116-10#	116-11	116-11#	116-12	116-12	116-12#	116-12#	116-13	116-13#	116-14	116-14	116-14#	116-14#	116-15
	116-15#	116-16	116-16	116-16#	116-16#	116-17	116-17#	116-18	116-18#	116-33	116-33#	116-34	116-34	116-34#
	116-34#	116-43	116-43	116-43#	116-43#	116-43#	116-44	116-44#	116-45	116-45	116-45#	116-45#	116-45#	116-46
	116-46#	116-54	116-54	116-54	116-54	116-54	116-54	116-54#	116-54#	116-54#	116-54#	116-54#	116-54#	117-10
	117-10	117-10#	117-10#	117-10#	117-11	117-11#	117-11#	120-4	120-4	120-4#	120-4#	120-4#	120-5	122-12
	122-12	122-12#	122-12#	122-13	122-13#	122-14	122-14	122-14#	122-14#	123-3	123-3	123-3	123-3	123-3#
	123-3#	123-3#	123-3#	123-4	123-4#	123-8	123-8	123-8	123-8	123-8#	123-8#	123-8#	123-8#	123-8#

D 14														
123-8#	123-9	123-9#	123-14	123-14	123-14	123-14	123-14#	123-14#	123-14#	123-14#	123-14#	123-14#	123-15	123-15#
123-20	123-20	123-20	123-20	123-20#	123-20#	123-20#	123-20#	123-20#	123-21	123-21#	124-1	124-1	124-1	124-1
124-1	124-1	124-1	124-1	124-1	124-1#	124-1#	124-1#	124-1#	124-104	124-104#	125-12	125-12#	126-10	126-10#
126-10#	126-11	126-11#	126-13	126-13#	127-8	127-8#	127-9	127-9#	127-10	127-10	127-10	127-10	127-10	127-10#
127-10#	127-10#	127-10#	127-10#	127-11	127-11	127-11#	127-11#	127-16	127-16	127-16	127-16	127-16	127-16#	127-16#
127-16#	127-16#	127-16#	127-17	127-17	127-17#	127-17#	127-20	127-20	127-20	127-20	127-20	127-20	127-20	127-20
127-20	127-20#	127-20#	127-20#	127-20#	127-21	127-21	127-21#	127-21#	127-32	127-32	127-32	127-32	127-32	127-32
127-32	127-32	127-32	127-32#	127-32#	127-32#	127-32#	127-50	127-50	127-50	127-50	127-50	127-50	127-50	127-50#
127-50#	127-50#	127-50#	127-50#	127-68	127-68	127-68#	127-68#	127-69	127-69#	128-14	128-14#	129-1	129-1	129-1
129-1	129-1	129-1#	129-2	129-2	129-2	129-2	129-2#	129-3	129-3	129-3	129-3	129-3	129-3	129-3#
129-4	129-4	129-4	129-4	129-4	129-4#	129-5	129-5	129-5	129-5	129-5	129-5	129-5#	129-6	129-6#
130-12	130-12#	131-1	131-1	131-1	131-1#	131-2	131-2#	131-3	131-3	131-3	131-3	131-3#	131-4	131-4#
131-5	131-5	131-5	131-5#	131-6	131-6#	131-7	131-7	131-7	131-7#	131-8	131-8#	131-9	131-9	131-9
131-9#	131-9#	131-10	131-10#	132-8	132-8	132-8	132-8#	133-3	133-3	133-3#	133-3#	133-3#	133-3#	133-3#
MSGNLS	124-1	124-1#	127-20	127-20#	127-32	127-32#	127-32#	127-32#	127-32#	127-32#	127-32#	127-32#	127-32#	127-32#
MSGNTA	29-17	29-17#	30-14	30-14#	54-16	54-16#	54-20	54-20#	54-24	54-24#	54-28	54-28#	54-32	54-32#
	54-36	54-36#	54-40	54-40#	54-44	54-44#	54-53	54-53#	54-59	54-59#	54-73	54-73#	54-77	54-77#
	54-81	54-81#	54-85	54-85#	54-89	54-89#	54-94	54-94#	54-98	54-98#	54-102	54-102#	54-106	54-106#
	54-110	54-110#	54-114	54-114#	54-118	54-118#	102-14	102-14#	103-21	103-21#	113-9	113-9#	124-104	124-104#
	125-12	125-12#	126-13	126-13#	127-69	127-69#	129-6	129-6#	131-10	131-10#	133-3	133-3#	133-11	133-11#
MSGNTE	127-5	127-5#												
MSHAPT	27-34	27-34#												
MSHNAP	27-34	27-34#												
MSINCR	27-26	27-26#	29-10	29-10	29-10#	29-10#	30-10	30-10#	30-10#	31-3	31-3#	54-14	54-14	54-14
	54-14#	54-14#	54-16#	54-18	54-18	54-18#	54-18#	54-20	54-22	54-22#	54-22#	54-24#	54-24#	54-26
	54-26	54-26#	54-26#	54-28#	54-30	54-30	54-30#	54-32#	54-34	54-34	54-34#	54-34#	54-36#	54-36#
	54-38	54-38	54-38#	54-38#	54-40#	54-42	54-42	54-42#	54-44#	54-46	54-46	54-46#	54-46#	54-46#
	54-53#	54-55	54-55	54-55#	54-55#	54-58#	54-59#	54-61	54-61#	54-61#	54-61#	54-61#	54-73#	54-75
	54-75#	54-75#	54-77#	54-79	54-79	54-79#	54-79#	54-81#	54-83	54-83	54-83#	54-83#	54-85#	54-87
	54-87	54-87#	54-87#	54-89#	54-91	54-91	54-91#	54-94#	54-96	54-96	54-96#	54-96#	54-98#	54-98#
	54-100	54-100	54-100#	54-100#	54-102#	54-104	54-104	54-104#	54-104#	54-106#	54-108	54-108	54-108#	54-108#
	54-110#	54-112	54-112	54-112#	54-112#	54-114#	54-116	54-116	54-116#	54-116#	54-118#	56-7#	56-8#	60-8#
	60-24#	61-36#	62-21#	63-8#	67-22#	69-30#	72-18#	72-19#	72-23#	91-12#	91-14#	91-16#	91-18#	94-20#
	96-3#	100-21#	100-29#	101-5#	102-10	102-10	102-10#	102-10#	103-18	103-18#	103-18#	103-18#	105-35#	106-11#
	107-12#	107-27#	107-30#	107-33#	109-44#	110-27#	110-36#	111-5#	113-5	113-5#	113-5#	113-5#	115-3	115-3#
	115-10	115-10	115-10#	115-10#	116-8	116-8	116-8#	116-8#	116-10#	116-12#	116-14#	116-16#	116-18#	116-33#
	116-34#	116-43#	116-45#	116-54#	117-10#	120-4#	122-12#	122-13#	122-14#	123-3#	123-4#	123-8#	123-9#	123-14#
	123-15#	123-20#	123-21#	124-1	124-1#	124-1#	124-104#	125-10	125-10	125-10#	125-10#	125-12#	126-8	126-8
	126-8#	126-8#	126-10#	126-11#	126-13#	127-3	127-3#	127-5	127-5	127-5	127-5#	127-5#	127-5#	127-8#
	127-10#	127-11#	127-16#	127-17#	127-20	127-20#	127-20#	127-21#	127-32	127-32#	127-32#	127-50#	127-68#	127-69#
	128-3	128-3#	128-14	128-14	128-14#	128-14#	130-12	130-12	130-12#	130-12#	133-1	133-1#	133-3	133-3
	133-3	133-3#												
MSLDRO	72-19	72-19#	107-30	107-30#	116-10	116-10#	116-12	116-12#	116-14	116-14#	116-16	116-16#	116-43	116-43#
	116-45	116-45#	117-10	117-10#	120-4	120-4#	122-12	122-12#	127-21	127-21#				
MSMCII	27-8	27-8#												
MSMCLO	27-8	27-8#												
MSPOP	29-17	29-17#	30-14	30-14#	30-16	30-16#	54-16	54-16#	54-20	54-20#	54-24	54-24#	54-28	54-28#

	54-100	54-100#	54-104	54-104#	54-108	54-108#	54-112	54-112#	54-116	54-116#	102-10	102-10#	103-18	103-18#
	113-5	113-5#	115-3	115-3#	115-10	115-10#	116-8	116-8#	125-10	125-10#	126-8	126-8#	127-3	127-3#
	127-5	127-5#	128-3	128-3#	128-14	128-14#	130-12	130-12#						
MSPUT	54-58	54-58	54-58#	91-12	91-12	91-12	91-12#	91-14	91-14	91-14	91-14#	91-16	91-16	91-16
	91-16#	91-18	91-18	91-18	91-18#	94-20	94-20	94-20	94-20	94-20#	107-27	107-27	107-27	107-27
	107-27#	116-54	116-54	116-54	116-54	116-54#	127-50	127-50	127-50	127-50#				
MSPUT1	54-58	54-58	54-58#	54-58#	91-12	91-12	91-12#	91-12#	91-12#	91-12#	91-14	91-14	91-14	91-14#
	91-14#	91-14#	91-16	91-16	91-16	91-16#	91-16#	91-16#	91-18	91-18	91-18#	91-18#	91-18#	91-18#
	94-20	94-20	94-20	94-20	94-20	94-20#	94-20#	94-20#	94-20#	107-27	107-27	107-27	107-27#	107-27#
	107-27#	107-27#	116-54	116-54	116-54	116-54#	116-54#	116-54#	116-54#	116-54#	127-50	127-50	127-50	127-50#
	127-50#													
MSRADI	124-1	124-1#	127-20	127-20#	127-32	127-32#	129-1	129-1#	129-2	129-2#	129-3	129-3#	129-4	129-4#
	129-5	129-5#	131-1	131-1#	131-3	131-3#	131-5	131-5#	131-7	131-7#				
MSRBRO	72-23	72-23#												
MSRNRO	116-34	116-34#	116-43	116-43#	116-45	116-45#	117-10	117-10#	120-4	120-4#				
MSSETS	27-26	27-26#	29-10	29-10#	30-10	30-10#	31-3	31-3#	54-14	54-14#	54-18	54-18#	54-22	54-22#
	54-26	54-26#	54-30	54-30#	54-34	54-34#	54-38	54-38#	54-42	54-42#	54-46	54-46#	54-55	54-55#
	54-61	54-61#	54-75	54-75#	54-79	54-79#	54-83	54-83#	54-87	54-87#	54-91	54-91#	54-96	54-96#
	54-100	54-100#	54-104	54-104#	54-108	54-108#	54-112	54-112#	54-116	54-116#	102-10	102-10#	103-18	103-18#
	113-5	113-5#	115-3	115-3#	115-10	115-10#	116-8	116-8#	125-10	125-10#	126-8	126-8#	127-3	127-3#
	127-5	127-5#	128-3	128-3#	128-14	128-14#	130-12	130-12#						
MSSVC	54-16	54-16#	54-20	54-20#	54-24	54-24#	54-28	54-28#	54-32	54-32#	54-36	54-36#	54-40	54-40#
	54-44	54-44#	54-53	54-53#	54-58	54-58#	54-59	54-59#	54-73	54-73#	54-77	54-77#	54-81	54-81#
	54-85	54-85#	54-89	54-89#	54-94	54-94#	54-98	54-98#	54-102	54-102#	54-106	54-106#	54-110	54-110#
	54-114	54-114#	54-118	54-118#	56-7	56-8	56-8#	60-8	60-8#	60-24	61-36	62-21	63-8	67-22
	69-30	72-18	72-18#	72-19	72-19#	72-23	72-23#	91-12	91-12#	91-14	91-14#	91-16	91-16#	91-18
	91-18#	94-20	94-20#	96-3	100-21	100-21#	100-29	101-5	105-35	106-11	107-12	107-12#	107-27	107-27#
	107-30	107-30#	107-33	109-44	110-27	110-27#	110-36	111-5	116-10	116-10#	116-12	116-12#	116-14	116-14#
	116-16	116-16#	116-18	116-18#	116-33	116-33#	116-34	116-34#	116-43	116-43#	116-45	116-45#	116-54	116-54#
	117-10	117-10#	120-4	120-4#	122-12	122-12#	122-13	122-13#	122-14	122-14#	123-3	123-4#	123-8	
	123-9	123-9#	123-14	123-15	123-15#	123-20	123-21	123-21#	124-1	124-1#	124-104	124-104#	125-12	125-12#
	126-10	126-10#	126-11	126-11#	126-13	126-13#	126-13#	127-8	127-8#	127-10	127-11	127-11#	127-16	127-17#
	127-20	127-20#	127-21	127-21#	127-32	127-32#	127-50	127-50#	127-68	127-68#	127-59	127-69#		
MSTLAB	54-16#	54-20#	54-24#	54-28#	54-32#	54-36#	54-40#	54-44#	54-53#	54-58#	54-59#	54-73#	54-77#	54-81#
	54-85#	54-89#	54-94#	54-98#	54-102#	54-106#	54-110#	54-114#	54-118#	56-7#	56-8#	60-8#	60-24#	61-36#
	62-21#	63-8#	67-22#	69-30#	72-18#	72-19#	72-23#	91-12#	91-14#	91-16#	91-18#	94-20#	96-3#	100-21#
	100-29#	101-5#	105-35#	106-11#	107-12#	107-27#	107-30#	107-33#	109-44#	110-27#	110-36#	111-5#	116-10#	116-12#
	116-14#	116-16#	116-18#	116-33#	116-34#	116-43#	116-45#	116-54#	117-10#	120-4#	122-12#	122-13#	122-14#	123-3#
	123-4#	123-8#	123-9#	123-14#	123-15#	123-20#	123-21#	124-1#	124-104#	125-12#	126-10#	126-11#	126-13#	127-8#
	127-10#	127-11#	127-16#	127-17#	127-20#	127-21#	127-32#	127-50#	127-68#	127-69#				
MSTSTL	54-16	54-16#	54-20	54-20#	54-24	54-24#	54-28	54-28#	54-32	54-32#	54-36	54-36#	54-40	54-40#
	54-44	54-44#	54-53	54-53#	54-58	54-58#	54-59	54-59#	54-73	54-73#	54-77	54-77#	54-81	54-81#
	54-85	54-85#	54-89	54-89#	54-94	54-94#	54-98	54-98#	54-102	54-102#	54-106	54-106#	54-110	54-110#
	54-114	54-114#	54-118	54-118#	56-7	56-7#	56-7#	56-8	56-8#	60-8	60-8#	60-24	60-24#	60-24#
	61-36	61-36#	61-36#	62-21	62-21#	62-21#	63-8	63-8#	63-8#	67-22	67-22#	67-22#	69-30	69-30#
	69-30#	72-18	72-18#	72-19	72-19#	72-23	72-23#	91-12	91-12#	91-14	91-14#	91-16	91-16#	91-18
	91-18#	94-20	94-20#	96-3	96-3#	96-3#	100-21	100-21#	100-29	100-29#	100-29#	101-5	101-5#	101-5#
</														

