

Micro Fiche Scan

Name of device(s) tested:

UDA

Test description:

PDP-11 UDA DRIVE FMTR

MAINDEC Number or Package Identifier (after SEP 1977):

CZUDED0

Fiche Document Part Number:

AH-S837D-MC

Fiche preparation date unknown, using copyright year:

1984

Image resolution:

1-bit black&white, compressed for minimal file size

COPYRIGHT (C) 1984 by d|i|g|i|t|a|l

.REM .TITLE ZUDED0 PDP-11 UDA DRV FMTR

IDENTIFICATION

PRODUCT CODE: AC-S836D-MC
PRODUCT NAME: CZUDED0 PDP 11 UDA DRV FMTR
PRODUCT DATE: 24 MAY-83
MAINTAINER: DIAGNOSTIC ENGINEERING
AUTHOR: DALE KECK

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS DOCUMENT.

NO RESPONSIBILITY IS ASSUMED FOR THE USE OR RELIABILITY OF SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL OR ITS AFFILIATED COMPANIES.

COPYRIGHT (C) 1981, 1983 BY DIGITAL EQUIPMENT CORPORATION

THE FOLLOWING ARE TRADEMARKS OF DIGITAL EQUIPMENT CORPORATION:

DIGITAL PDP UNIBUS MASSBUS
DEC DECUS DECTAPE

TABLE OF CONTENTS

	Page
1.0 GENERAL INFORMATION	3
1.1 PROGRAM ABSTRACT	3
1.2 SYSTEM REQUIREMENTS	4
2.0 OPERATING INSTRUCTIONS	4
2.1 COMMANDS	4
2.2 SWITCHES	5
2.3 FLAGS	6
2.4 HARDWARE QUESTIONS	7
2.5 SOFTWARE QUESTIONS	8
2.6 MANUAL INTERVENTION QUESTIONS	9
2.7 EXTENDED P-TABLE DIALOGUE	10
2.8 QUICK STARTUP PROCEDURE	12
3.0 ERROR INFORMATION	15
3.1 TYPES OF ERROR MESSAGES	15
3.2 SPECIFIC ERROR MESSAGES	16
3.2.1 HOST PROGRAM ERROR MESSAGES	16
3.2.2 DUP PROGRAM ERROR MESSAGES	24
4.0 PERFORMANCE AND PROGRESS REPORTS	28
5.0 TEST SUMMARIES	29

## 1.0 GENERAL INFORMATION

### 1.1 PROGRAM ABSTRACT

This program will format any disk drive connected to a UDA50 disk controller. At the time of this writing, there are three such drives in existence - the RA60, RA80 and RA81. No changes to this program will be needed to format new disk drives as they become available.

There are three ways to format a disk with this program:

1. Reformat - Format the disk with the bad sector information that was written onto the disk at the factory. This is the normal way to format a disk.
2. Reconstruct - Format the disk without using any bad sector information. This should be used only when the bad sector information has been destroyed or for some reason can no longer be read from the disk. This method may also be specified in the disk drive's maintenance manual for special cases (eg. changing an RM/RA80 spare HDA from RM80 format to RA80 format).
3. Restore - Format the disk using bad sector information obtained from a disk file on the XXDP system load device. This method is provided for use by manufacturing. No files are provided, nor any method of obtaining the files, at this time.

The format operation is performed by a Diagnostic Utilities and Protocol (DUP) program loaded into the UDA50 disk controller. The host program simply downline loads the DUP program into the UDA50 and monitors its execution. The DUP program obtains parameters from the host program (eg. drive number and format mode) and requests the host program to print error and summary messages. The DUP program is also commonly called a "diagnostic machine" (DM) program.

This program can only format in one mode at a time. In RESTORE mode, only one disk may be selected in the hardware questions or an error message will result and the program will stop.

In REFORMAT and RECONSTRUCT modes, any number of disk drives may be selected. A UDA50 can only format one disk at a time, so each disk on a UDA50 will be selected sequentially. If the disk drives to be formatted are connected to different UDA50s, all UDA50s will be run simultaneously. For example, lets assume three units are selected for formatting in the hardware questions, units 1 and 2 are connected to one UDA50 and unit 3 is connected to a different UDA50 (Unibus addresses are different). This program will automatically start simultaneous format operations on units 1 and 3. When unit 1 finishes (or errors), unit 2 will be started. After units 2 and 3 are finished, the program stops.

This program will stop after each pass (all units formatted once). There is no need to specify a PASS switch on the command line to the Diagnostic Runtime Services (eg. START/PASS:1).

Special provisions have been made to allow this program to run under an APT system in manufacturing. This system does not allow questions to be asked of an operator. Such a condition also exists under XXDP when the UAM flag is set. In this condition, only reformat mode can be selected. Selecting RECONSTRUCT or RESTORE will result in an error. Also, a date of 1-JAN 70 will be written on the disk.

## 1.2 SYSTEM REQUIREMENTS

This program was designed using the PDP-11 Diagnostic Runtime Services revision C. Run time environments are determined by the Runtime Services and may change as new versions of the Services are developed. The initial version will require the following:

- PDP 11 Unibus processor
- 28K words of memory (minimum)
- Console terminal
- XXDP load media containing this program
- One or more UDA50 subsystems. The subsystem controllers type UDA50-A with microcode level 3 or greater.

A system clock - either type L or P - will be used to time the DUP program and report runtime, if available. If no system clock is available, this program cannot detect a hung DUP program.

## 2.0 OPERATING INSTRUCTIONS

This section contains a brief description of the Runtime Services. For detailed information, refer to the XXDP User's Manual (CHQUS).

### 2.1 COMMANDS

There are eleven legal commands for the Diagnostic Runtime Services (Supervisor). This section lists the commands and gives a very brief description of them. The XXDP User's Manual has more details.

COMMAND	EFFECT
START	Start the diagnostic from an initial state
RESTART	Start the diagnostic without initializing
CONTINUE	Continue at test that was interrupted (after ^C)

PROCEED	Continue from an error halt
EXIT	Return to XXDP, Monitor (XXDP, OPERATION ONLY!)
ADD	Activate a unit for testing (all units are considered to be active at start time)
DROP	Deactivate a unit
PRINT	Print statistical information (see section 4.0)
DISPLAY	Type a list of all device information
FLAGS	Type the state of all flags (see section 2.3)
ZFLAGS	Clear all flags (see section 2.3)

A command can be recognized by the first three characters. So you may, for example, type 'STA' instead of 'START'.

## 2.2 SWITCHES

There are several switches which are used to modify supervisor operation. These switches are appended to the legal commands. All of the legal switches are tabulated below with a brief description of each. In the descriptions below, a decimal number is designated by "DDDDD".

SWITCH	EFFECT
/TESTS:LIST	Execute only those tests specified in the list. List is a string of test numbers, for example /TESTS:1:5:7-10. This list will cause tests 1,5,7,8,9,10 to be run. All other tests will not be run.
/PASS:DDDDD	Execute DDDDD passes (DDDDD = 1 to 64000)
/FLAGS:FLGS	Set specified flags. Flags are described in section 2.3.
/EOP:DDDDD	Report end of pass message after every DDDDD passes only. (DDDDD = 1 to 64000)
/UNITS:LIST	TEST/ADD/DROP only those units specified in the list. List example - /UNITS:0:5:10-12 use units 0,5,10,11,12 (unit numbers = 0-63).

Example of switch usage:

START/TESTS:1-5/PASS:1000/EOP:100

The effect of this command will be: 1) tests 1 through 5 will be executed, 2) all units will tested 1000 times and 3) the end of pass messages will be printed after each 100 passes only. A switch can be recognized by the first three characters. You may, for example, type "/TES:1 5" instead of "/TESTS:1-5".

Below is a table that specifies which switches can be used by each command.

	TESTS	PASS	FLAGS	EOP	UNITS
START	X	X	X	X	X
RESTART	X	X	X	X	X
CONTINUE		X	X	X	
PROCEED			X		
DROP					X
ADD					X
PRINT					
DISPLAY					X
FLAGS					
ZFLAGS					
EXIT					

### 2.3 FLAGS

Flags are used to set up certain operational parameters such as looping on error. All flags are cleared at startup and remain cleared until explicitly set using the flags switch. Flags are also cleared after a START or RESTART command unless set using the flag switch. The ZFLAGS command may also be used to clear all flags. With the exception of the START, RESTART and ZFLAGS commands, no commands affect the state of the flags; they remain set or cleared as specified by the last flag switch.

FLAG	EFFECT
HOE	Halt on error - control is returned to runtime services command mode
LOE	Loop on error
IER*	Inhibit all error reports
IBE*	Inhibit all error reports except first level (first level contains error type, number, PC, test and unit)
IXE*	Inhibit extended error reports (those called by PRINTX macro's)
PRI	Direct messages to line printer
PNT	Print test number as test executes
BOE	"BELL" on error
UAM	Unattended mode (no manual intervention)
IDU	Inhibit program dropping of units
LOT	Loop on test

\*Error messages are described in section 3.1

See the XXDP User's Manual for more details on flags. You may specify more than one flag with the FLAG switch. For example, to cause the program to loop on error, inhibit error reports and type a "BELL" on error, you may use the following string:

```
/FLAGS:LOE:IER:BOE
```

## 2.4 HARDWARE QUESTIONS

When a diagnostic is STARTed, the Runtime Services will prompt the user for hardware information by typing "CHANGE HW (L) ?". When you answer this question with a "\", the Runtime Services will ask for the number of units (in decimal). You will then be asked the following questions for each unit. When you answer this question with an 'N', the Runtime Services will use the answers built into the program by the SETUP utility (see chapter 6 of the XXDP User's Manual). If you have never run the SETUP utility on this program file, the default values listed below (just before the question mark) will be used.

UNIBUS ADDRESS OF UDA (0) 172150 ?

Answer with the address of the UDAIP register of one UDA as addressed by the processor with memory management turned off (i.e., an even 16-bit address in the range of 160000 to 177774).

VECTOR (0) 154 ?

Answer with the interrupt vector address of the UDA. A vector address in the range of 4 to 774 may be specified. The UDA does not have a vector "hard wired" to it, so any vector not being used by this program and XXDP, may be used.

BR LEVEL (0) 5 ?

Answer with the interrupt priority used by the UDA. Levels 4 to 7 are accepted. This level must match the level "hard wired" in the UDA by the priority plug.

UNIBUS BURST RATE (0) 63 ?

The UDA allows the ability to control the maximum number of words transferred across the UNIBUS each time the UDA becomes master. The default answer of 63 will allow for the fastest execution of this diagnostic program. You may answer with the value your operating system uses or use zero which will tell the UDA to supply a value that should work on any system. A decimal number in the range of 0 to 63 may be specified and all values should work on any system. A larger value will allow for a faster running program. The value will be passed directly to the UDA during initialization.

DRIVE NUMBER (0) 0 ?

Answer with the drive number of the drive you wish to test. This is the number which appears on the "unit plug" on the front of the disk drive. On a multi-unit drive, each sub-unit number on the drive must be tested as a separate unit to completely test the drive. A maximum of eight logical drives may be tested on one UDA at a time (UDA configuration limit).



## 2.5 SOFTWARE QUESTIONS

After you have answered the hardware questions or after a RESTART or CONTINUE command, the Runtime Services will ask for software parameters. You will be prompted by 'CHANGE SW (L) ?' If you wish to change any parameters, answer by typing "Y". The software questions and the default values are described in the next paragraphs. You may change the default values with the SETUP utility.

REFORMAT USING EXISTING BAD SECTOR INFORMATION (L) Y ?

If this question is answered "YES", then the user wants the REFORMAT mode format operation. REFORMAT mode will use the bad sector information that is already on the disk. Any other mode will destroy this information. If this question is answered "NO", the following will be asked to be sure the user knows what he is doing.

NOT USING EXISTING INFORMATION WILL DESTROY THE FACTORY BAD SECTOR INFORMATION ON THE DISK.  
AGAIN REFORMAT USING EXISTING BAD SECTOR INFORMATION (L) Y ?

This is asked to verify that the user does want to destroy the bad sector information on the disk and run another format mode. If this is answered "YES", then the user wants the REFORMAT mode format operation and use the existing bad block information. If again answered "NO", the following question will be asked.

RECONSTRUCT BAD SECTOR INFORMATION (L) Y ?

A "YES" answer will cause a reconstruct mode format operation. If answered "NO", the following will be asked to verify the user really wants the restore mode format.

DO YOU HAVE A FILE ON THE SYSTEM LOAD DEVICE CONTAINING BAD SECTOR INFORMATION (L) N ?

Note that such a file will not be provided with the diagnostic and this mode is not recommended. The format will begin only on a "YES" answer. Otherwise the following message will be printed and the program will abort.

YOU CANNOT PROCEED WITHOUT SUCH A FILE.  
RESTART PROGRAM AND SELECT TO REFORMAT OR RECONSTRUCT DISK.

## 2.6 MANUAL INTERVENTION QUESTIONS

When the program starts a warning message is printed to warn of improper use of this formatter.

### WARNING:

THIS FORMATTER PROGRAM SHOULD NOT BE USED AS A DIAGNOSTIC TOOL. RUN THIS PROGRAM ONLY AS INSTRUCTED IN THE DISK DRIVE'S SERVICE MANUAL.

ARE YOU SURE YOU WANT TO RUN THIS FORMATTER (L) N ?

You must answer "YES" or the program will abort immediately. This family of disk drives uses a powerful bad block revectoring mechanism to replace blocks that fall on defective areas of the disk media. As a disk is used and defective blocks are detected, DEC operating systems replace the blocks with other blocks on the disk (reserved for this purpose and otherwise inaccessible) so that the disk constantly appears to have its full storage capacity of error free disk blocks. Formatting a disk of this type destroys this history information and is absolutely not recommended except in the cases specifically described in the disk drive's service manual. These disks are fully formatted when shipped from the factory, therefore there is no reason to run this formatter program at installation.

Upon answering "YES" to the above question, the date will be asked for in the format used by the XXDP+ system.

ENTER DATE AS DD-MMM-YY (A) 1-JAN-70 ?

The default is provided so the user need not supply the date. The date question will normally only be asked one time. If an improper answer is typed, "INPUT ERROR" is printed and the question is asked again. A two or four digit year may be typed. A four digit year must be 1900 or greater (eg. 14-APR-1982). If only two digits are typed, the year is determined as follows:

1. If the number typed is 70 or greater, a 19 is prefixed. Eg., 1-JAN-70 translates to year 1970 and 25-DEC-99 translates to year 1999.
2. If the number typed is less than 70, a 20 is prefixed. Eg., 1-APR-21 is translated to year 2021.

If RECONSTRUCT mode is selected, the following question will be asked for each disk before the format operation begins.

SERIAL NUMBER FOR UNIT xx UDA AT xxxxxx DRIVE xxx  
(A) ?

A decimal number in the range of 0 to 18446744073709551615 must be entered (no default).

If RESTORE mode is selected, the following question will be asked.

NAME OF FILE CONTAINING BAD SECTOR INFORMATION FOR  
DISK TO BE FORMATTED (A) ?

If the file named does not exist on the system load device,  
the program will abort back to the XXDP prompt after printing  
an error message.

## 2.7 EXTENDED P-TABLE DIALOGUE

When you answer the hardware questions, you are building entries in a table that describes the devices under test. The simplest way to build this table is to answer all questions for each unit to be tested. If you have a multiplexed device such as a mass storage controller with several drives or a communication device with several lines, this becomes tedious since most of the answers are repetitious.

To illustrate a more efficient method, suppose you are testing a fictional device, the XY11. Suppose this device consists of a control module with eight units (sub-devices) attached to it. These units are described by the octal numbers 0 through 7. There is one hardware parameter that can vary among units called the Q-factor. This Q-factor may be 0 or 1. Below is a simple way to build a table for one XY11 with eight units.

# UNITS (0) ? 8<CR>

UNIT 1  
CSR ADDRESS (0) ? 160000<CR>  
SUB-DEVICE # (0) ? 0<CR>  
Q-FACTOR (0) 0 ? 1<CR>

UNIT 2  
CSR ADDRESS (0) ? 160000<CR>  
SUB-DEVICE # (0) ? 1<CR>  
Q-FACTOR (0) 1 ? 0<CR>

UNIT 3  
CSR ADDRESS (0) ? 160000<CR>  
SUB-DEVICE # (0) ? 2<CR>  
Q-FACTOR (0) 0 ? <CR>

UNIT 4  
CSR ADDRESS (0) ? 160000<CR>  
SUB-DEVICE # (0) ? 3<CR>  
Q-FACTOR (0) 0 ? <CR>

UNIT 5  
CSR ADDRESS (0) ? 160000<CR>  
SUB-DEVICE # (0) ? 4<CR>  
Q FACTOR (0) 0 ? <CR>

UNIT 6  
CSR ADDRESS (0) ? 160000<CR>  
SUB-DEVICE # (0) ? 5<CR>  
Q-FACTOR (0) 0 ? <CR>

UNIT 7  
CSR ADDRESS (0) ? 160000<CR>  
SUB-DEVICE # (0) ? 6<CR>  
Q-FACTOR (0) 0 ? 1<CR>

UNIT 8  
CSR ADDRESS (0) 160000<CR>  
SUB-DEVICE # (0) ? 7<CR>  
Q-FACTOR (0) 1 ? <CR>

Notice that the default value for the Q factor changes when a non-default response is given. Be careful when specifying multiple units!

As you can see from the above example, the hardware parameters do not vary significantly from unit to unit. The procedure shown is not very efficient.

The Runtime Services can take multiple unit specifications however. Let's build the same table using the multiple specification feature.

# UNITS (0) ? 8<CR>

UNIT 1  
CSR ADDRESS (0) ? 160000<CR>  
SUB-DEVICE # (0) ? 0,1<CR>  
Q-FACTOR (0) 0 ? 1,0<CR>

UNIT 3  
CSR ADDRESS (0) ? 160000<CR>  
SUB-DEVICE # (0) ? 2-5<CR>  
Q-FACTOR (0) 0 ? 0<CR>

UNIT 7  
CSR ADDRESS (0) ? 160000<CR>  
SUB-DEVICE # (0) ? 6,7<CR>  
Q-FACTOR (0) 0 ? 1<CR>

As you can see in the above dialogue, the runtime services will build as many entries as it can with the information given in any one pass through the questions. In the first pass, two entries are built since two sub-devices and q-factors were specified. The Services assume that the CSR address is 160000 for both since it was specified only once. In the second pass, four entries were built. This is because four sub-devices were specified. The "-" construct tells the Runtime Services to increment the data from the first number to the second. In this case, sub-devices 2, 3, 4 and 5 were specified. (If the sub device were specified by addresses, the increment would be by 2 since addresses must be on an even boundary.) The CSR addresses and Q factors for the four entries are assumed to be 160000 and 0 respectively since they were only specified once. The last two units are specified in the third pass.

The whole process could have been accomplished in one pass as shown below.

```
* UNITS (0) ? 8<CR>
UNIT 1
CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE * (0) ? 0-7<CR>
Q-FACTOR (0) 0 ? 0.1,0,...,1.1<CR>
```

As you can see from this example, null replies (commas enclosing a null field) tell the Runtime Services to repeat the last reply.

## 2.8 QUICK START UP PROCEDURE

To start-up this program:

1. Boot XXDP.
2. Give the date and answer the LSI and 50HZ (if there is a clock) questions
3. Type "R ZUDED0"
4. Type "START"
5. Answer the "CHANGE HW" question with "Y"
6. Answer all the hardware questions
7. Answer the "CHANGE SW" question with "N"
8. Answer "Y" to the "ARE YOU SURE ..." question following the warning. Please read the disk drive's service manual before answering this question.
9. Type today's date.

When you follow this procedure you will be using only the defaults for flags and software parameters. These defaults are described in sections 2.3 and 2.5.

Sample of terminal dialogue to test two disks on one UDA50:

DR>STA

CHANGE MW (L) ? Y

# UNITS (D) ? 2

UNIT 0

UNIBUS ADDRESS OF UDA (0) 172150 ?

VECTOR (0) 154 ?

BR LEVEL (D) 5 ?

UNIBUS BURST RATE (D) 63 ?

DRIVE NUMBER (D) 0 ? 0.1

CHANGE SW (L) ? N

WARNING:

THIS FORMATTER PROGRAM SHOULD NOT BE USED AS A DIAGNOSTIC  
TOOL. RUN THIS PROGRAM ONLY AS INSTRUCTED IN THE DISK  
DRIVE'S SERVICE MANUAL.

ARE YOU SURE YOU WANT TO RUN THIS FORMATTER (L) N ? Y

ENTER DATE AS DD-MMM-YY (A) 1-JAN-70 ? 14-APR-82

UNIT 0 UDA AT 172150 DRIVE 0 RUNTIME 0:00:20

Format begun Version 8

STOPPING THIS FORMAT AFTER THIS POINT WILL MAKE THE DISK  
UNUSABLE, AND WILL CAUSE THE DISK TO BE SPUN DOWN WHEN  
BROUGHT ONLINE.

UNIT 1 UDA AT 172150 DRIVE 1 RUNTIME 0:00:23

Format begun Version 8

STOPPING THIS FORMAT AFTER THIS POINT WILL MAKE THE DISK  
UNUSABLE, AND WILL CAUSE THE DISK TO BE SPUN DOWN WHEN  
BROUGHT ONLINE.

UNIT 0 UDA AT 172150 DRIVE 0 RUNTIME 0:42:20

Format completed

2 Revectorized LBNS

2 Primary revectorized LBNS

0 Secondary/tertiary revectorized LBNS

0 Bad RBNS

0 Bad blocks in the RCT area due to data errors

0 Bad blocks in the DBN area due to data errors

0 Bad blocks in the XBN area due to data errors

2 Blocks retried on the check pass

FCT used successfully

UNIT 1 LDA AT 172150 DRIVE 1    RUNTIME 1:25:18  
Format completed  
  131 Revectored LBNS  
  131 Primary revectored LBNS  
    0 Secondary/tertiary revectored LBNS  
    0 Bad RBNS  
    1 Bad blocks in the RCT area due to data errors  
    0 Bad blocks in the DBN area due to data errors  
    0 Bad blocks in the XBN area due to data errors  
  249 Blocks retried on the check pass  
FCT used successfully

CZUDE EOP    1  
          0 CUMULATIVE ERRORS  
DR>

Sample of terminal dialogue going through software questions.  
Only one disk is being tested.

DR>STA

CHANGE MW (L) ? N

CHANGE SW (L) ? Y

REFORMAT USING EXISTING BAD SECTOR INFORMATION (L) Y ? Y

WARNING:  
  THIS FORMATTER PROGRAM SHOULD NOT BE USED AS A DIAGNOSTIC  
  TOOL.  RUN THIS PROGRAM ONLY AS INSTRUCTED IN THE DISK  
  DRIVE'S SERVICE MANUAL.

ARE YOU SURE YOU WANT TO RUN THIS FORMATTER (L) N ? Y

ENTER DATA AS DD-MMM-YY (A) 1 JAN-70 ? 14-APR 82

  RUNTIME 0:00:20  
Format begun Version 8  
STOPPING THIS FORMAT AFTER THIS POINT WILL MAKE THE DISK  
UNUSABLE, AND WILL CAUSE THE DISK TO BE SPUN DOWN WHEN  
BROUGHT ONLINE.

  RUNTIME 1:33:45  
Format completed  
    2 Revectored LBNS  
    2 Primary revectored LBNS  
    0 Secondary/tertiary revectored LBNS  
    0 Bad RBNS  
    0 Bad blocks in the RCT area due to data errors  
    0 Bad blocks in the DBN area due to data errors  
    0 Bad blocks in the XBN area due to data errors  
    2 Blocks retried on the check pass  
FCT used successfully

CZUDE EOP    1  
          0 CUMULATIVE ERRORS  
DR>

### 3.0 ERROR INFORMATION

#### 3.1 TYPES OF ERROR MESSAGES

There are three levels of error messages that may be issued by a diagnostic: general, basic and extended. General error messages are always printed unless the "IER" flag is set (section 2.3). The general error message is of the form:

```
NAME TYPE NUMBER ON UNIT NUMBER TST NUMBER PC:XXXXXX  
error message
```

where: NAME = diagnostic name  
TYPE = error type (SYS FTL ERR, DEV FTL ERR)  
NUMBER = error number  
UNIT NUMBER = 0 - N (N is last unit in PTABLE)  
TST NUMBER = test and subtest where error occurred  
PC:XXXXXX = address of error message call

System fatal errors (SYS FTL ERR) are used to report errors that are fatal to the entire diagnostic program. The diagnostic stops and the Runtime Services prompt is printed.

Device fatal errors (DVC FTL ERR) are used to report errors that are fatal to the device (may be either a UDA50 or disk drive). Testing stops on that device for the remainder of the current test.

Basic error messages are messages that contain some additional information about the error. These are always printed unless the "IER" or "IBE" flags are set (section 2.3). These messages are printed after the associated general message.

Extended error messages contain supplementary error information such as register contents or good/bad data. These are always printed unless the "IER", "IBE" or "IXE" flags are set (section 2.3). These messages are printed after the associated general error message and any associated basic error messages.

The general and basic error messages from this diagnostic are always one line each. The basic message defines what program detected the error, the UDA50 being used and the time of the error:

```
HOST PROGRAM UDA AT XXXXXX RUNTIME hh:mm:ss
```

The host program (PDP-11) detected the error. UDA AT XXXXX identifies the address of the UDA50 being tested. It may be omitted if the error is not specific to one UDA50.



Sample error message:

```
CZUDE DVC FTL ERR 00021 ON UNIT 00 TST 001 SUB 000 PC: xxxxxx      general message
MOST PROGRAM UDA AT 172150 RUNTIME 0:00:12                       basic message
UDA RESIDENT DIAGNOSTICS DETECTED FAILURE
  UDASA CONTAINS 104041
REPLACE UDA MODULE M7485                                         extended message
```

The DUP program may also print error messages. They are printed exactly as presented by the DUP program and cannot be suppressed by any flags.

### 3.2 SPECIFIC ERROR MESSAGES

#### 3.2.1 MOST PROGRAM ERROR MESSAGES

Following is a list of the error messages that may be printed by the diagnostic program. In the list, some of the numbers that may vary with execution or program version are shown as "xxx". These include program counters and runtime. Other numbers, such as unit number, drive number, UDASA address and data in registers are filled with sample numbers. Additional information about the error may follow the error message.

```
00001 CZUDE SYS FTL ERR 00001 ON UNIT 00 TST 001 SUB 000 PC: xxxxxx
      MOST PROGRAM UDA AT 172150 RUNTIME x:xx:xx
      I DON'T LIKE THE ANSWERS YOU GAVE TO THE HARDWARE QUESTIONS
      UDA HAS MORE THAN ONE VECTOR, BR LEVEL OR BURST RATE
```

When the hardware questions were answered, two units were selected with the same UNIBUS address but with a different vector, BR level or burst rate. A single UDASA can have only one vector, BR level or burst rate. The program is aborted and returns to the Runtime Services prompt so that you can change the hardware questions.

```
00002 CZUDE SYS FTL ERR 00002 ON UNIT 00 TST 001 SUB 000 PC: xxxxxx
      MOST PROGRAM UDA AT 172150 RUNTIME x:xx:xx
      I DON'T LIKE THE ANSWERS YOU GAVE TO THE HARDWARE QUESTIONS
      TWO UNITS SELECT THE SAME DRIVE
```

The hardware questions for two units were exactly the same. The program is aborted and returns to the Runtime Services prompt so that you can change the hardware questions.

00003 CZUDE SYS FTL ERR 00003 ON UNIT 00 TST 001 SUB 000 PC: XXXXXX  
HOST PROGRAM UDA AT 172150 RUNTIME X:XX:XX  
I DON'T LIKE THE ANSWERS YOU GAVE TO THE HARDWARE QUESTIONS  
MORE THAN EIGHT DRIVES SELECTED ON THIS UDA

Up to four physical disk drives can be attached to a UDA50 at one time. A physical disk drive may be from one to four logical disk drives. Each logical disk drive is considered one unit to the diagnostic program. Even though more than eight logical disk drives can be attached to one UDA50, the UDA50 only supports eight. The program is aborted and returns to the Runtime Services prompt so that you can change the hardware questions.

00004 CZUDE SYS FTL ERR 00004 ON UNIT 00 TST 001 SUB 000 PC: XXXXXX  
HOST PROGRAM RUNTIME X:XX:XX  
NOT ENOUGH ROOM IN MEMORY TO TEST THE UNITS SELECTED  
PLEASE START PROGRAM OVER AND TEST FEWER UNITS AT A TIME

This program does not limit the number of units that can be tested by specifying a maximum number. What limits the number is the amount of memory used to store data on each unit. You have exceeded the number of units that are testable at one time. Start program over and select fewer units.

00008 CZUDE SYS FTL ERR 00008 ON UNIT 00 TST 001 SUB 000 PC: XXXXXX  
HOST PROGRAM UDA AT 172150 RUNTIME X:XX:XX  
I DON'T LIKE THE ANSWERS YOU GAVE TO THE HARDWARE QUESTIONS  
TWO UDA'S USE THE SAME VECTOR

The hardware questions for two units specified different UDA50 Unibus addresses but identical vector addresses. The program is aborted and returns to the Runtime Services prompt so that you can change the hardware questions.

00009 CZUDE DVC FTL ERR 00009 ON UNIT 00 TST 001 SUB 000 PC: XXXXXX  
HOST PROGRAM RUNTIME X:XX:XX  
ONLY ONE DISK CAN BE SELECTED IN HW QUESTIONS IN RESTORE MODE.  
PLEASE START PROGRAM OVER AND SELECT ONLY ONE DISK.

If the operator chooses to run the formatter in RESTORE mode, then only one disk can be selected in the hardware questions. RESTORE mode is run in this way because a file containing the bad block information is used and that information matches only one drive.

00010 CZUDE DVC FTL ERR 00010 ON UNIT 00 TST 001 SUB 000 PC: XXXXXX  
HOST PROGRAM RUNTIME X:XX:XX  
THIS PROGRAM CAN ONLY REFORMAT A DISK IN UNATTENDED MODE

This program needs to ask questions of the operator. It refuses to run in RECONSTRUCT and RESTORE modes because the questions obtain data that is absolutely necessary. REFORMAT mode is allowed to run because only a date is needed. The default date of 1 JAN 70 is used.

00014 CZUDE DVC FTL ERR 00014 ON UNIT 00 TST 001 SUB 000 PC: xxxxxx  
HOST PROGRAM UDA AT 172150 RUNTIME x:xx:xx  
UDASO CONTROLLER IS AT A REVISION LEVEL NO LONGER SUPPORTED  
BY THIS FORMATTER PROGRAM. THIS PROGRAM REQUIRES A UDASO-A  
CONTROLLER (MODEL 6) WITH MICROCODE VERSION AT 3 OR GREATER.

CONTROLLER REPORTED MODEL CODE xx AND MICROCODE VERSION xx

All UDASO-0's (modules M7161-2) are not supported by this diagnostic. The module set M7485-6 is the only one that can be tested by this diagnostic. If the controller is a UDASO-0 (M7161-2) it will not be tested. If the controller is a UDASO-A (M7485-6) and it has old microcode (the microcode version is less than 3) this message will be printed but testing will go on. If the controller consists of the M7161-2 modules, install one with M7485-6 modules. Do not intermix the two, it will not work!

00020 CZUDE DVC FTL ERR 00020 ON UNIT 00 TST 001 SUB 000 PC: xxxxxx  
HOST PROGRAM UDA AT 172150 RUNTIME x:xx:xx  
MEMORY ERROR TRYING TO READ UDA REGISTERS  
CHECK UNIBUS SELECTION SWITCHES ON UDA MODULE M7485  
OR UNIBUS  
OR REPLACE UDA MODULE M7485

A non-existent memory error occurred when the host program tried to access the UDAIP and UDASA registers. The UDA is at another address (check the UNIBUS selection switches) or module M7485 is broken or the UNIBUS is broken.

00021 CZUDE DVC FTL ERR 00021 ON UNIT 00 IST 001 SUB 000 PC: -xxxxx  
HOST PROGRAM UDA AT 172150 RUNTIME x'x'x'  
UDA RESIDENT DIAGNOSTICS DETECTED FAILURE  
UDASA CONTAINS 105154  
REPLACE UCA MODULE M7486

The UDA Resident diagnostic detected a failure. The error is displayed in the UDASA. Here are the possible error values and their meaning:

104000 Fatal sequencer error  
104040 D processor ALU error  
104041 - D proc ROM parity error  
105102 - D proc with no Board #2 or RAM parity error  
105105 - D proc RAM buffer error  
105152 - D proc SDI error  
105153 - D proc write mode wrap SERDES error  
105154 - D proc read mode SERDES, RSGEN, and ECC error  
106040 - U proc ALU error  
106041 - U proc Control Register error  
106042 - U proc DFIL/ROM parity error/Board #1 test count is wrong  
106047 - U proc Constant ROM error with D proc running SDI test  
106055 - Unexpected trap found, aborted diagnostic  
106071 - U proc ROM error  
106072 - U proc ROM parity error  
106200 - Step 1 data error (MSB not set)  
107103 - U proc RAM parity error  
107107 - U proc RAM buffer error  
107115 - Board #2 test count was wrong  
112300 - Step 2 error  
122240 - NPR error  
122300 - Step 3 error  
142300 - Step 4 error

Replace the board specific: M7485 is the Unibus interface board. M7486 is the SDI interface board.

00022 CZUDE DVC FTL ERR 00022 ON UNIT 00 TST 001 SUB 000 PC: XXXXXX  
HOST PROGRAM UDA AT 172150 RUNTIME X:XX:XX  
STEP BIT DID NOT SET IN UDASA REGISTER DURING INITIALIZATION  
STEP BIT EXPECTED 004000  
UDASA CONTAINS 000000  
REPLACE UDA MODULE M7485

The UDA did not respond as expected during the initialization sequence which communicates using data in the UDASA register. A normal response from the UDA contains either a STEP bit or an ERROR bit defined as follows:

Bit 15 (100000)	Error bit
Bit 14 (040000)	Step 4 bit
Bit 13 (020000)	Step 3 bit
Bit 12 (010000)	Step 2 bit
bit 11 (004000)	Step 1 bit

The expected step bit nor the error bit set within the expected time.

00023 CZUDE DVC FTL ERR 00023 ON UNIT 00 TST 001 SUB 000 PC: XXXXXX  
HOST PROGRAM UDA AT 172150 RUNTIME X:XX:XX  
UDA DID NOT CLEAR RING STRUCTURE IN HOST MEMORY DURING INITIALIZATION  
6 WORDS WERE TO BE CLEARED STARTING AT ADDRESS 040644  
FIRST SEVERAL WORDS NOT CLEARED (UP TO 6):

ADDRESS	CONTENTS
040644	000010
040650	000010
040652	000010

REPLACE UDA MODULE M7485

The UDA is to clear the ring structure (a communications area used by the UDA to talk to the host) in host memory before Step 4 of initialization. If the UDA diagnostics did not clear memory and did not flag an error, then error message 00023 is displayed. The contents of each word in memory is set to 177777 before the test. Failure of the UDA to clear each word indicates a fault in the address interface to the Unibus.

00024 CZUDE DVC FTL ERR 00024 ON UNIT 00 TST 001 SUB 000 PC: XXXXXX  
HOST PROGRAM UDA AT 172150 RUNTIME X:XX:XX  
UDASA REGISTER DID NOT GO TO ZERO AFTER STEP 3 WRITE OF INITIALIZATION  
PURGE/POLE DIAGNOSTICS WERE REQUESTED  
UDASA CONTENTS 004400

For better testing, the host can test the PURGE and POLE mechanism of the UDA. To do so the host sets bit15 of the step 3 data and sends the data to the UDA. The UDA must go to zero and wait for the purge and pole. If the UDA never went to zero, then error message 00024 is displayed. The UDA may have a bad M7485 module or the UNIBUS may be broken.

00025 CZUDE DVC FTL ERR 00025 ON UNIT 00 TST 001 SUB 000 PC: xxxxxx  
HOST PROGRAM UDA AT 172150 RUNTIME x:xx:xx  
UDA DID NOT RETURN CORRECT DATA IN UDASA REGISTER DURING INITIALIZATION  
UDASA EXPECTED 004400  
UDASA CONTAINS 004000  
REPLACE UDA MODULE M7485

For each step of initialization, specific data is expected to be displayed in the UDASA. If the UDASA does not match the expected data, then error message 00025 is displayed. Replace UDA module M7485.

00030 CZUDE DVC FTL ERR 00030 ON UNIT 00 TST 001 SUB 000 PC: xxxxxx  
HOST PROGRAM UDA AT 172150 RUNTIME x:xx:xx  
UDA REPORTED FATAL ERROR IN UDASA REGISTER WHILE RUNNING DM PROGRAM  
UDASA CONTAINS 100004

A message from the UDA firmware reports an unexpected failure. An error code is presented in the UDASA. Here is a list of the codes and their meanings:

004400 UDA has been init'd by either a bus init or by writing into the UDAIP.  
100001 - UNIBUS envelope/packet read error (parity or timeout)  
100002 - UNIBUS envelope/packet write error (parity or timeout)  
100003 - UDA ROM and RAM parity error  
100004 - UDA RAM parity error  
100005 - UDA ROM parity error  
100006 - UNIBUS ring read error  
100007 - UNIBUS ring write error  
100010 - UNIBUS interrupt master failure  
100011 - Host access timeout error  
100012 - Host exceeded credit limit  
100013 - UDA SDI hardware fatal error  
100014 - DM XFC fatal error  
100015 - Hardware timeout of instruction loop  
100016 - Invalid virtual circuit identifier  
100017 - Interrupt write error on UNIBUS

00031 CZUDE DVC FTL ERR 00031 ON UNIT 00 TST 001 SUB 000 PC: xxxxxx  
HOST PROGRAM UDA AT 172150 RUNTIME x:xx:xx  
NO INTERRUPT RECEIVED FROM DM PROGRAM FOR 3 MINUTES  
ASSUME PROGRAM IS HUNG

All DM programs are required to communicate with the host program, so as to assure the host program that the DM program is not hung up or in an endless loop. If the DM program has not done so, the host program assumes the DM is hung and this message appears.

00032 CZUDE DVC FTL ERR 00032 ON UNIT 00 TST 001 SUB 000 PC: xxxxxx  
HOST PROGRAM UDA AT 172150 RUNTIME x:xx:xx  
MESSAGE BUFFER RECEIVED FROM DM PROGRAM WITH UNKNOWN REQUEST NUMBER  
MESSAGE BUFFER CONTAINS:  
000001 000002 000003 000004 000005 000006 000007  
000008 000009 000010 000011 000012 000013 000014  
000015 000016 000017 000018 000019 000020 000021  
000022 000023 000024 000025 000026 000027 000028  
000029 000030 000031 000032 000033 000034 000035

The DM program and the host program communicate with each other using packets. Each packet must have a request number set up by the DM program and interpreted by the host program. This request number is not a known request number. The problem may be the UNIBUS or either one of the UDA modules or a corrupted DM program. Word 1 contains the DM request number, and word 2 typically contains the drive number. The rest of the buffer contains information specific to a DM request. The numbers in the example show the order in which words are displayed.

00033 CZUDE DVC FTL ERR 00033 ON UNIT 00 TST 001 SUB 000 PC: xxxxxx  
00034 HOST PROGRAM UDA AT 172150 RUNTIME x:xx:xx  
RESPONSE PACKET FROM UDA DOES NOT CONTAIN EXPECTED DATA  
EITHER UDA RETURNED ERROR STATUS OR PACKET WAS NOT RECEIVED CORRECTLY  
COMMAND PACKET SENT            RESPONSE PACKET RECEIVED  
000000 000020                    000000 000020  
000000 000000                    000000 000000  
000000 000002                    000000 0000202  
000000 014336                    000000 014336  
000000 034674                    000000 034674  
000000 000000                    000000 000000  
000000 000000                    000000 000000  
000000 051232                    000000 051232  
000000 000000                    000000 000000  
000000 000000                    000000 000000  
000000 000000                    000000 000000  
000000 000000                    000000 000000

The host program inspected the response packet which was given by to UDA. The response packet may have been in error with one of the following points:

- 1) The end code was not as expected.
- 2) The status code showed an error occurred with the last command.
- 3) The command reference numbers (the first word) did not match.

If 1 or 3 occurred, there may have been a transmission problem between the UDA and the host program. If 2 occurred, check the error code in the MSCP specification for further information. The packets are displayed two long words per line, low order word and byte to the right (corresponding to the MSCP long-word entity).

00036 CZUDE DVC FTL ERR 00036 ON UNIT 00 TST 001 SUB 000 PC: xxxxxx  
HOST PROGRAM UDA AT 172150 RUNTIME x:xx:xx  
NO INTERRUPT RECEIVED FROM UDA FOR 30 SECONDS  
WHILE LOADING DM PROGRAM

After a DM program has been sent to the UDA, the host program expects an interrupt within 30 seconds. The interrupt is used to assure the host program that the DM program is sane. If no interrupt occurred, then error message 00036 is displayed and the DM program is assumed to be hung.

00037 CZUDE DVC FTL ERR 00037 ON UNIT 00 TST 001 SUB 000 PC: xxxxxx  
HOST PROGRAM UDA AT 172150 RUNTIME x:xx:xx  
UDA REPORTED FATAL ERROR IN UDASA REGISTER WHILE LOADING DM PROGRAM  
UDASA CONTAINS 100004  
REPLACE UDA MODULE M7485

While loading the DM program to the UDA, the UDASA became non-zero. When this occurs, it signifies that the UDA microcode has run across a fatal error. The displayed value is in octal. Check the error code with the list in 00030.

00100 CZUDE DVC FTL ERR 00100 ON UNIT 00 TST 001 SUB 000 PC: xxxxxx  
HOST PROGRAM UDA AT 172150 RUNTIME x:xx:xx  
DUP PROGRAM ASKED UNEXPECTED QUESTION (25)

The DUP program sends a value that corresponds to a specific question or message. If this value does not fit into the range of questions, then this error appears.

00101 CZUDE DVC FTL ERR 00101 ON UNIT 00 TST 001 SUB 000 PC: xxxxxx  
HOST PROGRAM UDA AT 172150 RUNTIME x:xx:xx  
DUP PROGRAM REJECTED ANSWER TO DATE OR SERIAL NUMBER QUESTION

After the operator inputs the date/serial number, the DUP program will ask the host program for them. If for some reason the date/serial number was unacceptable to the DUP program, this error message will appear. Retry the program and if this error appears again, get out of the diagnostic runtime services and back to the XXDP prompt and reload the program.



### 3.2.2 DUP PROGRAM ERROR MESSAGES

Error messages returned by the UDA formatter are as follows:

#### GET STATUS failure

This could be caused by a number of reasons. Examples: the RUN/STOP switch is out, the WRITE PROTECT switch is in, or the DIAGNOSTIC REQUEST bit is set by the drive.

#### SDI send error

An attempt to send an SDI command failed. The signal RECEIVER READY was not asserted.

#### Unsuccessful SDI command

The response from an SDI command was unsuccessful and all commands should be successful for the formatter to work. There may be a cable problem, drive receiver problem or UDA transmitter problem.

#### SDI receive error

This message is presented for several reasons. The drive timed out, the first word from the drive was not a start frame, there was a framing error on the SDI level 0 read (cable/receiver/transmitter problem), checksum error, or the buffer size given by the formatter wasn't large enough for the UDA. Again, there may be a cable/receiver/transmitter problem.

#### UNIBUS read error

This is caused by one of two problems. While trying to read an overlay into the UDA buffer memory, the formatter came across a nonexistent memory error. Or, there was a failure while downline loading the bad block information. There may be something wrong with the UNIBUS or the UDA module M7485.

#### Formatter initialization error

For this error to occur, the UDA must be processing the DM code improperly.

#### Non-existent unit number

The desired disk drive wasn't attached to the UDA.

DBN/XBN format error (drive FORMAT command failed)

All attempts and retries to format a track failed. There may have been a timeout of drive signals, the drive dropped the READ/WRITE READY signal during the format operation or the drive clock timed out (which indicates cable/transmitter/receiver failures).

FCT does not have enough good copies of each block

There must at least two good copies of every block in the FCT. For this error to occur, the media is badly corrupted or the read/write logic is failing.

SEEK error

After a seek command completed successfully, the READ/WRITE READY signal was never set or the ATTENTION signal was set.

RCT does not have enough good copies of each block

There must be at least two good copies of every block in the RCT. For this error to occur, the media is badly corrupted or the read/write logic is failing.

LBN format error (drive FORMAT command failed)

All attempts and retries to format a track failed. There may have been a timeout of drive signals, the drive dropped the READ/WRITE READY signal during the format operation or the drive clock timed out (which indicates cable/transmitter/receiver failures).

FCT write error

A particular block failed to be written into every copy of the FCT. There is either terribly bad media or a write logic failure.

RCT read error

The formatter could not read at least one good copy of a particular block in the RCT area.

RCT write error

A particular block failed to be written into every copy of the RCT. There is either terribly bad media or a write logic failure.

N<sub>2</sub>

#### RCT full

There were so many bad blocks on the media that the RCT area was filled and could not hold any more. There could be read/write logic failure or bad cable connection.

#### FCT read error

The formatter could not read at least one good copy of a particular block in the FCT area.

#### FCT downline load error

The formatter was led to believe that a bad block information file was larger than it really was. There may be a UNIBUS or M7485 problem.

#### Drive init timeout

After the drive was inited, the RECEIVER READY signal never asserted.

#### Illegal response to start-up question

An overflow occurred when the serial number went over 64 bits.

#### FCT corrupted Format Invalid

A problem was detected while using the data in the FCT. Either the data was not written properly or it has been corrupted since the last format. The format on the disk is no good and the disk will not be usable by any DEC operating system. Running the formatter again may have a slight chance of succeeding. Otherwise, replace the disk or HDA. If you do not have a spare disk or HDA you may try to format the disk in RECONSTRUCT mode. If the disk is not an RAB0, order a replacement disk or HDA immediately.

DRIVE ERROR ENCOUNTERED - STATUS RESPONSE:  
STATUS (R TO L): 1AF1 0304 E100 8800 0080 0013 1000  
LAST BLOCK ACCESSED (16 BIT OCTAL): 000000 000000

The disk drive reported an error. You may see the drive's fault light come on. The formatter will attempt to clear the error in the drive and continue. This error does not mean that anything is necessarily wrong unless this error is printed many times. If you see many of these errors, you may wish to stop the format and run diagnostics on the disk drive. But remember, if you stop the formatter the disk will not be usable and the diagnostics will report the format is bad. The drive's status is presented in hexadecimal in the same format as the diagnostic programs. The last block accessed is a representation of the last block header written onto the disk.

#### MORE THAN 12.5% OF TRACK IS BAD

The formatter found more than one eighth of the blocks on a single track bad. This error does not mean that anything is necessarily wrong unless this error is printed many times. If you see many of these errors, you may wish to stop the format and run diagnostics on the disk drive. But remember, if you stop the formatter the disk will not be usable and the diagnostics will report the format is bad.

An example of how the errors are presented is below:

RUNTIME 0:00:18  
Non-existent unit number

#### 4.0 PERFORMANCE AND PROGRESS REPORTS

There is no statistical report that can be printed using the Diagnostic Runtime Services PRINT command.

The DUP program issues the following messages upon normal completion:

Format completed

n Revectored LBNS

Where n is the number of LBNS revectored in the user data area.

n Primary revectored LBNS

Where n is the number of LBNS which were primary revectorors.

n Secondary/teritary revectored LBNS

Where n is the number of the LBNS which were secondary or tertiary revectorors.

n Bad RBNS

Where n is the number of RBNS which were bad.

n Bad blocks in the RCT area due to data errors

Where n is the number of blocks in the total RCT area which were bad.

n Bad blocks in the DBN area due to data errors

Where n is the number of blocks in the total DBN area which were bad.

n Bad blocks in the XBN area due to data errors

Where n is the number of blocks in the total XBN area which were bad.

n Blocks retried on the check pass

where n is the number of blocks which had an error on the first read attempt after formatting.

FCT used successfully or  
FCT was not used

Depending on the answers to the software questions and the availability of the bad sector information (FCT), one of these messages will be printed.

An example of how the messages are presented is below.

```
RUNTIME 1:24:57
Format completed
  5 Revectored LBNS
  5 Primary revectored LBNS
  0 Secondary/tertiary revectored LBNS
  0 Bad RBNS
  0 Bad blocks in the RCT area due to data errors
  0 Bad blocks in the DBN area due to data errors
  0 Bad blocks in the XBN area due to data errors
  5 Blocks retried on the check pass
FCT was not used
```

## 5.0 TEST SUMMARIES

There is only one test in this program - Test #1. Its only purpose is to load and run the format program in a UDA50.

```

1
25
26 002000
27
28
29
30
31
32 002000
33
34 002000
002000
002000 103
002001 132
002002 125
002003 104
002004 105
002005 000
002006 000
002007 000
002010
002010 104
002011
002011 060
002012
002012 000001
002014
002014 016040
002016
002016 022620
002020
002020 023006
002022
002022 002130
002024
002024 002144
002026
002026 000124
002030
002030 000000
002032
002032 000000
002034
002034 000001
002036
002036 000000
002040
002040 002124
002042
002042 000340
002044
002044 000000
002046
002046 000000
002050
002050 003
002051 003

```

```

.SBTTL PROGRAM HEADER
      BGNMOD
      ***
      ; THE PROGRAM HEADER IS THE INTERFACE BETWEEN
      ; THE DIAGNOSTIC PROGRAM AND THE SUPERVISOR.
      ;
      POINTER BGNSW, BGN3FT, BGNSETUP
      HEADER CZUDE,D,0,7200.,1,PRI07

```

```

L$NAME::
      .ASCII /C/
      .ASCII /Z/
      .ASCII /U/
      .ASCII /D/
      .ASCII /E/
      .BYTE 0
      .BYTE 0
      .BYTE 0
L$REV::
      .ASCII /D/
L$DEPG::
      .ASCII /O/
L$UNIT::
      .WORD T&PTHV
L$TIML::
      .WORD 7200.
L$MPCP::
      .WORD L$HARD
L$SPCP::
      .WORD L$SOFT
L$MPTP::
      .WORD L$MW
L$SPTP::
      .WORD L$SW
L$LADP::
      .WORD L$LAST
L$STA::
      .WORD 0
L$CO::
      .WORD 0
L$DTYP::
      .WORD 1
L$APT::
      .WORD 0
L$JTP::
      .WORD L$DISPATCH
L$PRIO::
      .WORD PRI07
L$ENVI::
      .WORD 0
L$EXPI::
      .WORD 0
L$MREV::
      .BYTE C$REVISION
      .BYTE C$EDIT

```

002052  
 002052 000000  
 002054 000000  
 002056  
 002056 000000  
 002060  
 002060 003456  
 002062  
 002062 000000  
 002064  
 002064 000000  
 002066  
 002066 000000  
 002070  
 002070 000000  
 002072  
 002072 000000  
 002074  
 002074 000000  
 002076  
 002076 003500  
 002100  
 002100 104035  
 002102  
 002102 000000  
 002104  
 002104 021100  
 002106  
 002106 022116  
 002110  
 002110 022114  
 002112  
 002112 021072  
 002114  
 002114 000000  
 002116  
 002116 000000  
 002120  
 002120 000000

L\$EF:: .WORD 0  
 .WORD 0  
 L\$SPC:: .WORD 0  
 L\$DEVP:: .WORD L\$DVTYP  
 L\$REPP:: .WORD 0  
 L\$EXP4:: .WORD 0  
 L\$EXPS:: .WORD 0  
 L\$AUT:: .WORD 0  
 L\$DUT:: .WORD 0  
 L\$LUN:: .WORD 0  
 L\$DESP:: .WORD L\$DESC  
 L\$LOAD:: EMT E\$LOAD  
 L\$ETP:: .WORD 0  
 L\$ICP:: .WORD L\$INIT  
 L\$CCP:: .WORD L\$CLEAN  
 L\$ACP:: .WORD L\$AUTO  
 L\$PRT:: .WORD L\$PROT  
 L\$TEST:: .WORD 0  
 L\$DLV:: .WORD 0  
 L\$HME:: .WORD 0



1  
2  
3  
4  
5  
6  
7  
8  
9

.SBTTL DISPATCH TABLE

\*\*\*  
; THE DISPATCH TABLE CONTAINS THE STARTING ADDRESS OF EACH TEST.  
; IT IS USED BY THE SUPERVISOR TO DISPATCH TO EACH TEST.  
;

DISPATCH 1

002122  
002122 000001  
002124  
002124 022130

.WORD 1  
L\$DISPATCH::  
.WORD \*1

```
1          .SBTTL  DEFAULT HARDWARE P TABLE
2
3          ;**
4          ; THE DEFAULT HARDWARE P-TABLE CONTAINS DEFAULT VALUES OF
5          ; THE TEST DEVICE PARAMETERS.  THE STRUCTURE OF THIS TABLE
6          ; IS IDENTICAL TO THE STRUCTURE OF THE HARDWARE P TABLES,
7          ; AND IS USED AS A "TEMPLATE" FOR BUILDING THE P TABLES.
8          ;
9
10         BGNHW  DFPTBL
11
12         002126          .WORD  L10000-L$HW/2
13         002126  000005          DFPTBL::
14         002130
15         002130
16
17         11  002130  172150          .WORD  172150          ; UNIBUS ADDRESS
18         12  002132  000154          .WORD  154           ; VECTOR ADDRESS
19         13  002134  000005          .WORD  5.           ; BR LEVEL
20         14  002136  000077          .WORD  63.         ; UNIBUS BURST RATE
21         15  002140  000000          .WORD  0.           ; LOGICAL DRIVE NUMBER
22         16  002142
23         17  002142
24
25         ENDHW
26
27         L10000:
```

```
1          .SBTTL  SOFTWARE P TABLE
2
3          ;**
4          ; THE SOFTWARE TABLE CONTAINS VARIOUS DATA USED BY THE
5          ; PROGRAM AS OPERATIONAL PARAMETERS.  THESE PARAMETERS ARE
6          ; SET UP AT ASSEMBLY TIME AND MAY BE VARIED BY THE OPERATOR
7          ; AT RUN TIME.
8          ;
9
10         002142          BGNSW  SFPTBL
11         002142          000001
12         002144
13         002144
14         002144          .WORD  L10001-L10001/2
15         002144
16         002144          SFPTBL::
17
18         ;OFFSET          USE
19         ; 0.            YES/NO ANSWERS
20
21         .WORD  7
22         ENDSW
23
24         L10001:
25
26         ENDMOD
```

1  
 2  
 3 00214f  
 4  
 5  
 6  
 7  
 8  
 9  
 10 002146

.SBTTL GLOBAL EQUATES SECTION

BGNMOD

\*\*\*  
 ; THE GLOBAL EQUATES SECTION CONTAINS PROGRAM EQUATES THAT  
 ; ARE USED IN MORE THAN ONE TEST.  
 ;

EQUALS

; BIT DEFINITIONS

100000	BIT15--	100000
040000	BIT14--	40000
020000	BIT13--	20000
010000	BIT12--	10000
004000	BIT11--	4000
002000	BIT10--	2000
001000	BIT09--	1000
000400	BIT08--	400
000200	BIT07--	200
000100	BIT06--	100
000040	BIT05--	40
000020	BIT04--	20
000010	BIT03--	10
000004	BIT02--	4
000002	BIT01--	2
000001	BIT00--	1

001000	BIT9--	BIT09
000400	BIT8--	BIT08
000200	BIT7--	BIT07
000100	BIT6--	BIT06
000040	BIT5--	BIT05
000020	BIT4--	BIT04
000010	BIT3--	BIT03
000004	BIT2--	BIT02
000002	BIT1--	BIT01
000001	BIT0--	BIT00

; EVENT FLAG DEFINITIONS

; EF32:EF17 RESERVED FOR SUPERVISOR TO PROGRAM COMMUNICATION

000040	EF.START--	32.	; START COMMAND WAS ISSUED
000037	EF.RESTART--	31.	; RESTART COMMAND WAS ISSUED
000036	EF.CONTINUE--	30.	; CONTINUE COMMAND WAS ISSUED
000035	EF.NEW--	29.	; A NEW PASS HAS BEEN STARTED
000034	EF.PWR--	28.	; A POWER-FAIL/POWER-UP OCCURRED

; PRIORITY LEVEL DEFINITIONS

000340	PRI07--	340
000300	PRI06--	300
000240	PRI05--	240
000200	PRI04--	200

```

000140      PRI03== 140
000100      PRI02== 100
000040      PRI01== 40
000000      PRI00== C

;
; OPERATOR FLAG BITS
;
000004      EVL==      4
000010      LOT==     10
000020      ADR==     20
000040      IDU==     40
000100      ISR==    100
000200      JAM==    200
000400      BOE==    400
001000      PNT==   1000
002000      PRI==   2000
004000      IXE==   4000
010000      IBE==  10000
020000      IER==  20000
040000      LOE==  40000
100000      HOE== 100000

```

```

11
12      000015

```

```

CR=      15

```

```

;VALUE TO PASS TO PRINT MACRO TO END LINE

```

1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33

```
;MACRO DEFINITIONS FOR GLOBAL EQUATES  
;THESE MACROS ARE USED TO DEFINE INDFXES INTO A TABLE  
;CALLING SEQUENCE MUST BE  
;  
;      TABLE  
;      ITEM      NAME      BYTES  
;      ITEM      NAME      BYTES  
;      ITEM      NAME      BYTES  
;      END      SIZE  
;  
;TABLE DEFINES THAT A TABLE IS ABOUT TO BE DEFINED AND END TERMINATES THE DEFINITION.  
;ANY NUMBER OF ITEM LINES CAN APPEAR. NAME IS THE NAME OF THE SYMBOL BEING EQUATED TO  
;THE INDEX. THE INDEX ALWAYS STARTS AT ZERO. BYTES SPECIFIES THE SIZE OF THE VALUE TO BE  
;STORED AT THAT INDEX IN BYTES. THE SIZE ARGUMENT TO THE END STATEMENT IS OPTIONAL, IT  
;BE EQUATED TO THE SIZE OF THE TABLE IN BYTES. THE SYMBOL TINDEX IS USED TO KEEP TRACK  
;OF THE INDEX VALUE AND WILL BE EQUAL TO THE SIZE OF THE TABLE AFTER THE END STATEMENT.  
  
.MACRO TABLE  
      TINDEX=0  
.ENDM  
  
.MACRO ITEM NAME BYTES  
      NAME=TINDEX  
      TINDEX=TINDEX+BYTES  
.ENDM  
  
.MACRO END SIZE  
      .IF NB SIZE  
      SIZE=TINDEX  
      .ENOC  
.ENDM
```

```

1      ;UDA BIT DEFINITIONS
2
3      ;UDASA REGISTER UNIVERSAL READ BITS
4
5      004000      SA.S1= 004000      ;STEP 1 STATUS BIT
6      010000      SA.S2= 010000      ;STEP 2 STATUS BIT
7      020000      SA.S3= 020000      ;STEP 3 STATUS BIT
8      040000      SA.S4= 040000      ;STEP 4 STATUS BIT
9      100000      SA.ERR= 100000     ;ERROR INDICATOR
10
11     ;UDASA REGISTER ERROR STATUS BITS
12
13     003777      SA.ERC= 003777     ;ERROR CODE
14
15     ;UDASA REGISTER STEP ONE READ BITS
16
17     002000      SA.NV= 002000     ;NON SETTABLE INTERRUPT VECTOR
18     001000      SA.A2= 001000     ;22 BIT ADDRESS BUS
19     000400      SA.DI= 000400     ;ENHANCED DIAGNOSTICS
20     ;           ;           000377     ;ALL BITS RESERVED
21
22     ;UDASA REGISTER STEP ONE WRITE BITS
23
24     000177      SA.VEC= 000177     ;INTERRUPT VECTOR (DIVIDED BY 4)
25     000200      SA.INT= 000200     ;INTERRUPT ENABLE DURING INITIALIZATION
26     003400      SA.MSG= 003400     ;MESSAGE RING LENGTH
27     034000      SA.CMD= 034000     ;COMMAND RING LENGTH
28     040000      SA.WRP= 040000     ;WRAP BIT
29     100000      SA.STP= 100000     ;STEP - MUST ALWAYS BE WRITTEN A ONE
30
31     000400      SA.MS1= 000400     ;LSB OF MESSAGE RING LENGTH
32     004000      SA.CM1= 004000     ;LSB OF COMMAND RING LENGTH
33
34     ;UDASA REGISTER STEP TWO READ BITS
35
36     000007      SA.MSE= 000007     ;MESSAGE RING LENGTH ECHO
37     000070      SA.CME= 000070     ;COMMAND RING LENGTH ECHO
38     ;           ;           000100     ;RESERVED
39     000200      SA.STE= 000200     ;STEP ECHO
40     003400      SA.CTP= 003400     ;CONTROLLER TYPE
41
42     ;UDASA REGISTER STEP TWO WRITE BITS
43
44     000001      SA.PRG= 000001     ;ENABLE VAX UNIBUS ADAPTER PURGE INTERRUPT
45     ;           ;           177776     ;LOW ORDER MESSAGE RING BYTE ADDRESS
    
```

```

1      ;UDASA REGISTER STEP THREE READ BITS
2
3      000177      SA.VCE= 000177      ;INTERRUPT VECTOR ECHO
4      000200      SA.INE= 000200      ;INTERRUPT ENABLE ECHO
5      000400      SA.NVE= 000400      ;VECTOR NOT PROGRAMMABLE
6      ;          003000      ;RESERVED
7
8      ;UDASA REGISTER STEP THREE WRITE BITS
9
10     ;          077777      ;HIGH ORDER MESSAGE RING BYTE ADDRESS
11     100000      SA.TST= 100000      ;PURGE POLE TEST ENABLE
12
13     ;UDASA REGISTER STEP FOUR READ BITS
14
15     000017      SA.MCV= 000017      ;UDA MICROCODE VERSION
16     000360      SA.CNT= 000360      ;CONTROLLER MODEL
17     ;          003400      ;RESERVED
18
19     ;UDASA REGISTER STEP FOUR WRITE BITS
20
21     000001      SA.GO= 000001      ;GO BIT TO START UDA FIRMWARE
22     000002      SA.LFC= 000002      ;LAST FAILURE CODE REQUEST
23     000374      SA.BST= 000374      ;BURST LEVEL
    
```



```

1      ;COMMAND/MESSAGE DESCRIPTOR BIT DEFINITIONS
2
3      100000      RG.OWN= 100000      ;SET WHEN UDA OWNS RING
4      040000      RG.FLG= 040000      ;FLAG BIT
5
6      ;OFFSETS INTO HOST COMMUNICATIONS AREA WITH ONE DESCRIPTOR TO EACH RING
7      ;AND TWO PACKET AND BUFFER AREAS.
8
9      000004      MC.ISZ= 4.          ;SIZE OF INTERRUPT INDICATOR WORDS
10     000004      MC.RSZ= 4.          ;SIZE OF RING IN BYTES
11     000004      MC.ESZ= 4.          ;SIZE OF ENVELOPE WORDS BEFORE PACKET
12     000060      MC.PSZ= 48.         ;SIZE OF COMMAND AND MESSAGE PACKETS
13     000244      MC.BSZ= 164.        ;SIZE OF BUFFER
14
15     000000      MC.INT= 0.           ;INTERRUPT INDICATOR WORDS START
16     000004      MC.MSG= MC.INT+MC.ISZ ;MESSAGE RING START
17     000006      MC.MCT= MC.MSG+2.    ;MESSAGE RING CONTROL WORD
18     000010      MC.CMD= MC.MSG+MC.RSZ ;COMMAND RING START
19     000012      MC.CCT= MC.CMD+2.    ;COMMAND RING CONTROL WORDS
20     000014      MC.MEV= MC.CMD+MC.RSZ ;MESSAGE ENVELOPE START
21     000020      MC.MPK= MC.MEV+MC.ESZ ;MESSAGE PACKET START
22     000100      MC.CEV= MC.MPK+MC.PSZ ;COMMAND ENVELOPE START
23     000104      MC.CPK= MC.CEV+MC.ESZ ;COMMAND PACKET START
24     000164      MC.BF1= MC.CPK+MC.PSZ ;FIRST BUFFER
25     000430      MC.BF2= MC.BF1+MC.BSZ ;SECOND BUFFER
26
27     000674      MC.SIZ= MC.BF2+MC.BSZ ;TOTAL SIZE OF HOST COMM AREA
28
29     ;VIRTUAL CIRCUIT IDENTIFIERS
30
31     000000      MSCP= 0              ;MSCP CIRCUIT
32     000001      LOG= 1              ;LOG CIRCUIT
33     177777      DIAG= 1             ;DIAGNOSTIC CIRCUIT
34     001000      DUP= 1000           ;DIAGNOSTIC AND UTILITIES PROTOCOL
    
```

Line	Label	Description	Size
1	MC.INT	INTERRUPT INDICATORS	4 BYTES
2			
3			
4	MC.MSG	MESSAGE RING	4 BYTES
5	MC.MCT		
6			
7			
8	MC.CMD	COMMAND RING	4 BYTES
9	MC.CCT		
10			
11	MC.MEV	MESSAGE ENVELOPE	52 BYTES
12	MC.MPK		
13			
14			
15			
16			
17			
18	MC.CEV	COMMAND ENVELOPE	52 BYTES
19	MC.CPK		
20			
21			
22			
23			
24			
25	MC.BF1	BUFFER # 1 (RESPONSE TO DM PROGRAM)	82 BYTES
26			
27			
28			
29			
30	MC.BF2	BUFFER # 2 (REQUEST FROM DM PROGRAM)	82 BYTES
31			
32			
33			
34			

```

1      ;COMMAND PACKET OPCODES
2
3      000001      OP.ABO= 1      ;ABORT COMMAND
4      000020      OP.ACC= 20     ;ACCESS COMMAND
5      000010      OP.AVL= 10     ;AVAILABLE COMMAND
6      000021      OP.CCD= 21     ;COMPARE CONTROLLER DATA COMMAND
7      000040      OP.CMP= 40     ;COMPARE HOST DATA COMMAND
8      000022      OP.ERS= 22     ;ERASE COMMAND
9      000023      OP.FLU= 23     ;FLUSH COMMAND
10     000002      OP.GCS= 2      ;GET COMMAND STATUS COMMAND
11     000003      OP.GUS= 3      ;GET UNIT STATUS COMMAND
12     000011      OP.ONL= 11     ;ONLINE COMMAND
13     000041      OP.RD= 41      ;READ COMMAND
14     000024      OP.RPL= 24     ;REPLACE COMMAND
15     000004      OP.SCC= 4      ;SET CONTROLLER CHARACTERISTICS COMMAND
16     000012      OP.SLC= 12     ;SET UNIT CHARACTERISTICS COMMAND
17     000042      OP.WR= 42      ;WRITE COMMAND
18     000030      OP.MRD= 30     ;MAINTENANCE READ COMMAND
19     000031      OP.MWR= 31     ;MAINTENANCE WRITE COMMAND
20     000200      OP.END= 200    ;END PACKET FLAG
21     000007      OP.SEX= 7      ;SERIOUS EXCEPTION END PACKET
22     000100      OP.AVA= 100    ;AVAILABLE ATTENTION MESSAGE
23     000101      OP.DUP= 101    ;DUPLICATE UNIT NUMBER ATTENTION MESSAGE
24     000102      OP.SMC= 102    ;SHADOW COPY COMPLETE ATTENTION MESSAGE
25     000103      OP.RLC= 103    ;RESET COMMAND LIMIT ATTENTION MESSAGE
26
27     000001      OP.GDS= 1      ;DUP GET DUST STATUS
28     000001      OP.GSS= 1      ;DUP GET DUST STATUS
29     000002      OP.ESP= 2      ;DUP EXECUTE SUPPLIED PROGRAM
30     000003      OP.ELP= 3      ;DUP EXECUTE LOCAL PROGRAM
31     000004      OP.SSD= 4      ;DUP SEND STUD DATA
32     000005      OP.RSD= 5      ;DUP RECEIVE STUD DATA
33
34     ;NOTE: END PACKET OPCODES (ALSO CALLED ENDCODES) ARE FORMED BY ADDING THE END
35     ;PACKET FLAG TO THE COMMAND OPCODE. FOR EXAMPLE, A READ COMMAND'S END PACKET
36     ;CONTAINS THE VALUE OP.RD+OP.END IN ITS OPCODE FIELD. THE INVALID COMMAND END
37     ;PACKET CONTAINS JUST THE END PACKET FLAG (I.E., OP.END) IN ITS OPCODE FIELD.
38     ;THE SERIOUS EXCEPTION END PACKET CONTAINS THE SUM OF THE END PACKET FLAG
39     ;PLUS THE SERIOUS EXCEPTION OPCODE SHOWN ABOVE (I.E., OP.SEX+OP.END) IN ITS
40     ;OPCODE FIELD.
41
42     ;COMMAND OPCODE BITS 3 THROUGH 5 INDICATE THE COMMAND CLASS, WHICH IS ENCODED
43     ;AS FOLLOWS:
44     ; 000 IMMEDIATE COMMANDS
45     ; 001 SEQUENTIAL COMMANDS
46     ; 010 NON-SEQUENTIAL COMMANDS THAT DO NOT INCLUDE A BUFFER DESCRIPTOR
47     ; 100 NON-SEQUENTIAL COMMANDS THAT DO INCLUDE A BUFFER DESCRIPTOR
    
```

```
1          ;COMMAND MODIFIERS
2
3          ;          * 020000
4          MD.CMP= 040000          ;CLEAR SERIOUS EXCEPTION
5          MD.EXP= 100000          ;COMPARE
6          MD.ERR= 010000          ;EXPRESS REQUEST
7          MD.GCH= 004000          ;FORCE ERROR
8          MD.SCL= 002000          ;SUPPRESS CACHING (HIGH SPEED)
9          MD.SEC= 000100          ;SUPPRESS CACHING (LOW SPEED)
10         MD.SER= 000400          ;SUPPRESS ERROR CORRECTION
11         MD.SSH= 000200          ;SUPPRESS ERROR RECOVERY
12         MD.WBN= 000100          ;SUPPRESS SHADOWING
13         MD.WBV= 000400          ;WRITE-BACK (NON-VOLATILE)
14         MD.SEQ= 000020          ;WRITE BACK (VOLATILE)
15         MD.SPD= 000001          ;WRITE SHADOW SET ONE UNIT AT A TIME
16         MD.FEU= 000001          ;SPIN-DOWN
17         MD.VOL= 000002          ;FLUSH ENTIRE UNIT
18         MD.NXU= 000001          ;VOLATILE ONLY
19         MD.RIP= 000001          ;NEXT UNIT
20         MD.IMF= 000002          ;ALLOW SELF DESTRUCTION
21         MD.SWP= 000004          ;IGNORE MEDIA FORMAT ERROR
22         MD.CWB= 000010          ;SET WRITE PROTECT
23         MD.PRI= 000001          ;CLEAR WRITE-BACK DATA LOST
24                                     ;PRIMARY REPLACEMENT BLOCK
25         ;END PACKET FLAGS
26
27         EF.BBR= 000200          ;BAD BLOCK REPORTED
28         EF.BBU= 000100          ;BAD BLOCK UNREPORTED
29         EF.LOG= 000040          ;ERROR LOG GENERATED
30         EF.SEX= 000020          ;SERIOUS EXCEPTION
31
32         ;CONTROLLER FLAGS
33
34         CF.ATN= 000200          ;ENABLE ATTENTION MESSAGES
35         CF.MSC= 000100          ;ENABLE MISCELLANEOUS ERROR LOG MESSAGES
36         CF.OTH= 000040          ;ENABLE OTHER HOST S ERROR LOG MESSAGES
37         CF.THS= 000020          ;ENABLE THIS HOST'S ERROR LOG MESSAGES
38         CF.SHD= 000002          ;SHADOWING
39         CF.576= 000001          ;576 BYTE SECTORS
```



```

1      ;END PACKET OFFSETS
2
3
4      000000      ; P.CRF = 0.      ; COMMAND REFERENCE NUMBER
5      000004      ; P.UNIT = 4.     ; UNIT NUMBER
6      000010      ; P.OPCD = 8.    ; OPCODE (ALSO CALLED ENCODE)
7      000011      ; P.FLGS = 9.    ; END PACKET FLAGS
8      000012      ; P.STS = 10.   ; STATUS
9      000014      ; P.BCNT = 12.  ; BYTE COUNT
10     000034      ; P.FBBK = 28.  ; FIRST BAD BLOCK

11
12     ;
13     000014      ; P.OTRF = 12.  ; GET COMMAND STATUS END PACKET OFFSETS:
14     000020      ; P.CMST = 16.  ; OUTSTANDING REFERENCE NUMBER
15                                     ; COMMAND STATUS
16     ;
17     000014      ; P.MLUN = 12.  ; GET UNIT STATUS END PACKET OFFSETS:
18     000016      ; P.UNFL = 14.  ; MULTI UNIT CODE
19     000020      ; P.HSTI = 16.  ; UNIT FLAGS
20     000024      ; P.UNTI = 20.  ; HOST IDENTIFIER
21     000034      ; P.MEDI = 28.  ; UNIT IDENTIFIER
22     000040      ; P.SHUN = 32.  ; MEDIA TYPE IDENTIFIER
23     000042      ; P.SHST = 34.  ; SHADOW UNIT
24     000044      ; P.TRCK = 36.  ; SHADOW STATUS
25     000046      ; P.GRP = 38.   ; TRACK SIZE
26     000050      ; P.CYL = 40.  ; GROUP SIZE
27     000054      ; P.RCTS = 44.  ; CYLINDER SIZE
28     000056      ; P.RBNS = 46.  ; RCT TABLE SIZE
29     000057      ; P.RCTC = 47.  ; RBNS / TRACK
30                                     ; RCT COPIES
31     ;
32     ;
33     000014      ; P.MLUN = 12.  ; ONLINE AND SET UNIT CHARACTERISTICS END PACKET AND AVAILABLE
34     000016      ; P.UNFL = 14.  ; ATTENTION MESSAGE OFFSETS:
35     000020      ; P.HSTI = 16.  ; MULTI-UNIT CODE
36     000024      ; P.UNTI = 20.  ; UNIT FLAGS
37     000034      ; P.MEDI = 28.  ; HOST IDENTIFIER
38     000040      ; P.SHUN = 32.  ; UNIT IDENTIFIER
39     000042      ; P.SHST = 34.  ; MEDIA TYPE IDENTIFIER
40     000044      ; P.UNCL = 36.  ; SHADOW UNIT
41     000050      ; P.UNSZ = 40.  ; SHADOW STATUS
42     000054      ; P.VSER = 44.  ; UNIT COMMAND LIMIT
43                                     ; UNIT SIZE
44                                     ; VOLUME SERIAL NUMBER
45     ;
46     000014      ; P.VRSN = 12.  ; SET CONTROLLER CHARACTERISTICS END PACKET OFFSETS:
47     000016      ; P.CNTF = 14.  ; MSCP VERSION
48     000020      ; P.CTMO = 16.  ; CONTROLLER FLAGS
49     000022      ; P.CNCL = 18.  ; CONTROLLER TIMEOUT
50     000024      ; P.CNTI = 20.  ; CONTROLLER COMMAND LIMIT
51                                     ; CONTROLLER ID
52     ;
53     000014      ; P.DEXT = 12.  ; GET DUST STATUS END PACKET OFFSETS:
54     000017      ; P.DFLG = 15.  ; DUST PROGRAM EXTENSION
55     000020      ; P.DPI = 16.   ; STATUS FLAGS
56     000024      ; P.DTO = 20.  ; PROGRESS INDICATOR
57                                     ; TIMEOUT VALUE

```

```

1          ;STATUS AND EVENT CODE DEFINITIONS
2
3          000037      ST.MSK= 37          ;STATUS / EVENT CODE MASK
4          000040      ST.SUB= 40          ;SUB-CODE MULTIPLIER
5          000000      ST.SUC= 0           ;SUCCESS
6          000001      ST.CMD= 1           ;INVALID COMMAND
7          000002      ST.ABO= 2           ;COMMAND ABORTED
8          000003      ST.OFL= 3           ;UNIT-OFFLINE
9          000004      ST.AVL= 4           ;UNIT-AVAILABLE
10         000005      ST.MFE= 5           ;MEDIA FORMAT ERROR
11         000006      ST.WPR= 6           ;WRITE PROTECTED
12         000007      ST.CMP= 7           ;COMPARE ERROR
13         000010      ST.DAT= 10          ;DATA ERROR
14         000011      ST.HST= 11          ;HOST BUFFER ACCESS ERROR
15         000012      ST.CNT= 12          ;CONTROLLER ERROR
16         000013      ST.DRV= 13          ;DRIVE ERROR
17         000037      ST.DIA= 37          ;MESSAGE FROM AN INTERNAL DIAGNOSTIC
18
19         ;GET DUST STATUS FLAGS
20
21         000010      DF.ACT= 010         ;SET IF THIS DUST CURRENTLY ACTIVE
22         000004      DF.NES= 004         ;SET IF THIS DUST WILL NOT ACCEPT THE EXECUTE
23                                     ;SUPPLIED PROGRAM COMMAND
24         000002      DF.LCL= 002         ;SET IF THIS DUST HAS A LOCAL LOAD MEDIA FOR LOADING
25                                     ;DIAGNOSTICS AND OTHER UTILITIES
26         000001      DF.SA= 001         ;SET IF ANY PROGRAM EXECUTION UNDER THIS DUST
27                                     ;DISABLES THE OPERATION OF ALL OTHER SERVERS IN THE
28                                     ;SAME SYSTEM AS THE DUST
29
30         ;DUP MESSAGE TYPES
31
32         010000      DU.QUE = 10000      ;QUESTION
33         020000      DU.DFL = 20000      ;DEFAULT QUESTION
34         030000      DU.INF = 30000      ;INFORMATION
35         040000      DU.TER = 40000      ;TERMINATOR
36         050000      DU.FTL = 50000      ;FATAL ERROR
37         060000      DU.SPC = 60000      ;SPECIAL
38
39         170000      DU.TYP= 170000      ;MESSAGE TYPE FIELD
40
41         ;DM PROGRAM HEADER DEFINITIONS
42
43         000000      DMTRLN= 0           ;OFFSET TO SIZE OF PROGRAM NEEDING DOWNLINE LOAD
44         000004      DMOVRL= 4           ;OFFSET TO SIZE OF OVERLAY
45         000021      DMTMO= 21          ;TIMEOUT VALUE IN SECONDS (ONE BYTE)
46         000040      DMMAIN= 40          ;OFFSET TO FIRST WORD OF MAIN PROGRAM
47         001000      DMFRST= 1000        ;ADDRESS IN DM FILE CONTAINING FIRST BYTE OF HEADER
    
```

```

1      ;CONTROLLER TABLE DEFINITIONS
2      ;
3      ;ONE TABLE WILL BE SET UP BY INITIALIZE SECTION FOR EACH UDA SELECTED
4      ;FOR TESTING. TABLES ARE CONTIGUOUS. THE END OF THE TABLES IS
5      ;MARKED BY A WORD OF ZEROS.
6      ;
7      ;THE FIRST TABLE IS POINTED TO BY THE CONTENTS OF STABS.
8      ;THE NUMBER OF TABLES IS CONTAINED IN CTRLRS.
9
10     002146      TABLE      ;START A TABLE DEFINITION
11
12     002146      ITEM C.UADR    2      ;UNIBUS ADDRESS OF UDAIP REGISTER
13     002146      ITEM C.UNIT    2
14             000077          CT.UNT= 000077      ; LOGICAL UNIT NUMBER (FIRST)
15             100000          CT.AVL= BIT15      ; SET WHEN NOT AVAILABLE FOR TESTING
16     002146      ITEM C.VEC     2
17             000777          CT.VEC= 000777      ; VECTOR ADDRESS
18             007000          CT.BRL= 007000      ; BR LEVEL
19     002146      ITEM C.BST     2      ; BURST LEVEL
20     002146      ITEM C.JSR     2      ; INTERRUPT SERVICE ROUTINE FOR CONTROLLER
21     002146      ITEM C.JAD     2      ; THESE TWO WORDS LOADED WITH (JSR RO,UDASRV)
22     002146      ITEM C.FLG     2      ; FLAGS
23             000002          CT.RN= BIT1        ; DM PROGRAM RUNNING
24             000004          CT.CMD= BIT2       ; COMMAND ISSUED, WAITING FOR RESPONSE
25             000010          CT.MSG= BIT3       ; MESSAGE RESPONSE RECEIVED
26
27             000020          CT.REQ= BIT4       ; WHENEVER THIS BIT IS SET, CT.CMD IS CLEARED
28
29
30             000040          CT.STA= BIT5       ; BUFFER HAS BEEN GIVEN TO UDA FOR REQUEST
31             000100          CT.TM1= BIT6       ; SET WHENEVER READ STUD DATA COMMAND
32
33             000200          CT.TM2= BIT7       ; GIVEN TO UDA
34     002146      ITEM C.RING    2      ; GET DUST STATUS COMMAND HAS BEEN SENT
35     002146      ITEM C.DR0     2      ; ONE TIMEOUT PERIOD HAS EXPIRED BETWEEN SEND OR
36     002146      ITEM C.DR1     2      ; RECEIVE DATA RESPONSE
37     002146      ITEM C.DR2     2      ; SECOND TIMEOUT HAS EXPIRED
38     002146      ITEM C.DR3     2      ; RING BUFFER ADDRESS
39     002146      ITEM C.DR4     2      ; POINTER TO DRIVE TABLES
40     002146      ITEM C.DR5     2      ; IF ZERO, NO DRIVE TABLE EXISTS
41     002146      ITEM C.DR6     2
42     002146      ITEM C.DR7     2
43     002146      ITEM C.TO      2      ; TIMEOUT COUNTER
44     002146      ITEM C.TOH     2      ; (TWO WORDS)
45     002146      ITEM C.TOT     2      ; DUP PROGRAM TIMEOUT VALUE IN SECONDS
46     002146      ITEM C.PRI     4      ; DUP PROGRAM PROGRESS INDICATOR
47     002146      ITEM C.REF     2      ; COMMAND REFERENCE NUMBER
48
49     002146      END C.SIZE      ;SIZE OF CONTROLLER TABLE IN BYTES
    
```



```
1          ;DRIVE TABLE DEFINITIONS
2
3          ;
4          ;ONE DRIVE TABLE WILL BE SET UP BY THE INITIALIZE SECTION FOR EACH
5          ;DRIVE SELECTED FOR TESTING. EACH TABLE IS POINTED TO BY A
6          ;WORD IN THE CONTROLLER TABLE ON WHICH THE DRIVE EXISTS.
7 00214E   TABLE          ;START A TABLE DEFINITION
8
9 002146   ITEM D.DRV      2          ;DRIVE NUMBER
10 002146  ITEM D.UNIT     2
11          DT.UNT= 000077          ; LOGICAL UNIT NUMBER OF DRIVE
12          DT.AVL= BIT15          ; SET WHEN NOT AVAILABLE FOR TESTING
13 002146  ITEM D.SERN    22.       ;DISK SERIAL NUMBER
14
15 002146  END D.SIZE          ;SIZE OF DRIVE TABLE IN BYTES
```

```

1      ;USEFUL INSTRUCTION DEFINITIONS
2
3      .MACRO AND ARG,ADR          ;LOGICAL AND INSTRUCTION
4      .LIST                      BIC #C<ARG>,ADR
5
6      .NLIST
7      .ENDM
8
9      .MACRO OR ARG,ADR          ;LOGICAL OR INSTRUCTION
10     .LIST                       BIS #ARG,ADR
11
12     .NLIST
13     .ENDM
14
15     .MACRO PUSH ARG            ;PUSH INSTRUCTION
16     .IRP X,<ARG>
17     .LIST                       MOV X,-(SP)
18
19     .NLIST
20     .ENDM
21     .ENDM
22
23     .MACRO POP ARG            ;POP INSTRUCTION
24     .IRP X,<ARG>
25     .LIST                       MOV (SP),X
26
27     .NLIST
28     .ENDM
29     .ENDM
30
31     .MACRO .BR ADR             ;A BRANCH TO THE NEXT LOCATION
32     .IF P2
33         .IF NE .-ADR
34             .ERROR ;ILLEGAL .BR TO ADR
35         .ENDC
36     .ENDC
37     .ENDM
38
39     .MACRO ASSUME FIRST CONDITION SECOND
40         .IF CONDITION <FIRST>-<SECOND>
41         .IFF
42             .ERROR ;BAD ASSUME OF <FIRST> CONDITION <SECOND>
43         .ENDC
44     .ENDM
    
```

```
1      ;PRINT CHARACTER
2      ; ARGUMENT MUST BE SOURCE STATEMENT TO MOVE CHARACTER TO PRINT (MOV ARG,R0)
3      ; EX: "PRINT R1" WILL PRINT THE CHARACTER IN R1
4      ; SPECIAL CASE: "PRINT @CR" WILL PRINT END OF LINE SEQUENCE
5      ; THE PRINTING IS DONE AT THE MODE OF THE LAST PRINT LINE CALL
6      ; IE., PNTX, PNTB, PNTY, PNTS
7
8      .MACRO PRINT ARG1
9          .IF DIF <ARG1>,R0
10             .LIST
11
12             .NLIST
13
14             .ENDC
15             .LIST
16
17             .NLIST
18
19             .ENDM
20
21      ;PROCESSING MACRO FOR NEXT SET OF FORMATTED MESSAGE MACROS
22
23      .MACRO PNT... RTN,ADR,ARG1,ARG2,ARG3,ARG4,ARG5,ARG6,ARG7,ARG8
24          PNT.CT=0
25          .IRP AA,<ARG8,ARG7,ARG6,ARG5,ARG4,ARG3,ARG2,ARG1>
26              .IF NB,<AA>
27                  .LIST
28
29                  .NLIST
30                  PNT.CT=PNT.CT+2
31
32              .ENDC
33
34          .ENDM
35          .LIST
36
37          .NLIST
38
39          .ENDM
40
41          JSR R1,RTN
42          .WORD ADR
43          .WORD PNT.CT
```

```
1 ;PRINT FORMATTED MESSAGE MACROS
2 ; USE THESE MACROS TO PRINT A FORMATTED MESSAGE
3 ; FIRST ARGUMENT MUST BE ADDRESS OF FIRST CHARACTER OF MESSAGE STRING
4 ; TO BE PUT INTO WORD (.WORD ARG)
5 ; UP TO 8 SOURCE STATEMENTS MAY FOLLOW TO SPECIFY PARAMETERS TO BE
6 ; USED BY THE FORMAT
7
8 .MACRO PNTF ADR ARG1,ARG2,ARG3,ARG4,ARG5,ARG6,ARG7,ARG8
9 PNT... LPNTF ADR ARG1,ARG2,ARG3,ARG4,ARG5,ARG6,ARG7,ARG8
10 .ENDM
11 .MACRO PNTB ADR ARG1,ARG2,ARG3,ARG4,ARG5,ARG6,ARG7,ARG8
12 PNT... LPNTB ADR ARG1,ARG2,ARG3,ARG4,ARG5,ARG6,ARG7,ARG8
13 .ENDM
14 .MACRO PNTX ADR ARG1,ARG2,ARG3,ARG4,ARG5,ARG6,ARG7,ARG8
15 PNT... LPNTX ADR ARG1,ARG2,ARG3,ARG4,ARG5,ARG6,ARG7,ARG8
16 .ENDM
17 .MACRO PNTS ADR ARG1,ARG2,ARG3,ARG4,ARG5,ARG6,ARG7,ARG8
18 PNT... LPNTS ADR ARG1,ARG2,ARG3,ARG4,ARG5,ARG6,ARG7,ARG8
19 .ENDM
20 .MACRO PNT ADR ARG1,ARG2,ARG3,ARG4,ARG5,ARG6,ARG7,ARG8
21 PNT... LPNT ADR ARG1,ARG2,ARG3,ARG4,ARG5,ARG6,ARG7,ARG8
22 .ENDM
```

```

1      .SBTTL GLOBAL DATA SECTION
2
3
4      ;**
5      ; THE GLOBAL DATA SECTION CONTAINS DATA THAT ARE USED
6      ; IN MORE THAN ONE TEST.
7      ;
8 002146 FFREE:: .BLKW 1 ;FIRST FREE WORD IN MEMORY
9 002150 FSIZE:: .BLKW 1 ;SIZE OF FREE MEMORY IN WORDS
10 002152 FMEM: .BLKW 1 ;COPY OF FFREE AT END OF INIT SECTION
11 002154 FMEMS: .BLKW 1 ;COPY OF FSIZE AT END OF INIT SECTION
12 002156 CTABS:: .BLKW 1 ;START OF CONTROLLER TABLE STORAGE
13 002160 CTRLRS: .BLKW 1 ;COUNT OF UDA CONTROLLERS IN PTABLES
14 002162 TSTTAB: .BLKW 1 ;POINTER TO FIRST CONTROLLER TABLE UNDER TEST
15      .GLOBL UDAFM
16 002164 000000G DMPROG: .WORD UDAFM ;START ADDRESS OF DM PROGRAM
17 002166 URUN: .BLKW 1 ;NUMBER OF UNITS TO RUN AT ONE TIME
18 002170 URNING: .BLKW 1 ;NUMBER OF UNITS STILL RUNNING
19 002172 UCNT: .BLKW 1 ;COUNTER OF UNITS UNDER TEST
20 002174 000000 FILOPN: .WORD 0 ; FILE OPEN
21 002176 UFREEZ: .BLKW 1 ;FREEZE ON UNIT WHEN NOT ZERO
22 002200 NXMAD: .BLKW 1 ;SET TO ALL ONES BY NON-EXISTANT ADDRESS
23 002202 000000 FDATA: .WORD 0
24 002204 FCTBUF: .BLKB 512. ;STORAGE FOR FCT BLOCK
25 003204 FCTNUM: .BLKW 1 ;FCT BLOCK NUMBER
26 003206 MODE: .BLKW 1 ;MODE WORD, SAME BIT DEFS AS SO.BIT
27
28      ;CLOCK CONTROL
29
30 003210 000000 KW.CSR: .WORD 0 ;CSR OF CLOCK
31 003212 KW.BRL: .BLKW 1 ;BR LEVEL
32 003214 KW.VEC: .BLKW 1 ;VECTOR
33 003216 KW.HZ: .BLKW 1 ;HERTZ (50. OR 60.)
34 003220 KW.EL: .BLKW 2 ;ELAPSED TIME
35
36 003224 016104 PTYPE: .WORD PF ;PRINT TYPE
37 003226 000 000 ERRCHR: .BYTE 0,0 ;FIRST BYTE LOADED WITH OUTPUT CHARACTER
38 003230 000000 NULL: .WORD 0 ;USED TO PRINT A NULL CHARACTER
39 003232 FNAME: .BLKB 10.

```

1	003244				TEMP:	.BLKB 22.		USED TO GET ANSWER FROM GMANID CALL
2	003272	061	055	112	DATE1:	.ASCIZ\1-JAN 70\		DEFAULT DATE
3	003303					.BLKB 3		
4	003306	000000			DATE0:	.WORD 0	DATE STRING IN FORMATTER FORMAT	
5	003310					.BLKB 10.	(FIRST WORD ZERO SAYS NO DATE HERE YET)	
6	003322	061	070	064	HIGHEST:	.ASCIZ\18446744073'09551615\	HIGHEST DISK SERIAL NUMBER	
7	003347	104	105	103	MONTHS:	.ASCII\DEC\	NAME OF MONTHS	
8	003352	116	117	126		.ASCII\NOV\		
9	003355	117	103	124		.ASCII\OCT\		
10	003360	123	105	120		.ASCII\SEP\		
11	003363	101	125	107		.ASCII\AUG\		
12	003366	112	125	114		.ASCII\JUL\		
13	003371	112	125	116		.ASCII\JUN\		
14	003374	115	101	131		.ASCII\MAY\		
15	003377	101	120	122		.ASCII\APR\		
16	003402	115	101	122		.ASCII\MAR\		
17	003405	106	105	:02		.ASCII\FEB\		
18	003410	112	101	116		.ASCII\JAN\		
19	003413	037			DAYS:	.BYTE 31.	NUMBER OF DAYS IN EACH MONTH	
20	003414	035				.BYTE 29.		
21	003415	037				.BYTE 31.		
22	003416	036				.BYTE 30.		
23	003417	037				.BYTE 31.		
24	003420	036				.BYTE 30.		
25	003421	037				.BYTE 31.		
26	003422	037				.BYTE 31.		
27	003423	036				.BYTE 30.		
28	003424	037				.BYTE 31.		
29	003425	036				.BYTE 30.		
30	003426	037				.BYTE 31.		
31	003427	061	071	000	YEAR19:	.ASCIZ\19\		
32	003432	062	060	000	YEAR20:	.ASCIZ\20\		
33						.EVEN		
34	003436	000000			IPADRS:	.WORD 0		
35	003440	000000				.WORD 0		
36	003442	000000				.WORD 0		
37	003444	000000				.WORD 0		
38	003446	000000				.WORD 0		
39	003450	000000				.WORD 0		
40	003452	000000				.WORD 0		
41	003454	000000				.WORD 0		

GLOBAL TEXT SECTION

.SBTTL GLOBAL TEXT SECTION

THE GLOBAL TEXT SECTION CONTAINS FORMAT STATEMENTS,  
MESSAGES, AND ASCII INFORMATION THAT ARE USED IN  
MORE THAN ONE TEST.

NAMES OF DEVICES SUPPORTED BY PROGRAM

DEV TYP <LDA 50 CONTROLLER>

L'DVTYP::  
.ASCIZ /LDA 50 CONTROLLER  
.EVEN

TEST DESCRIPTION

DESCRIPT <ZUDED0 PDP 11 LDA DRV FMTR>

L'DESC::  
.ASCIZ /ZUDED0 PDP 11 LDA  
.EVEN

1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11

12 003456  
003456  
003456

125 104 101

13  
14  
15

16 003500  
003500  
003500

103 132 125

DRV FMTR/

)

UNFORMATTED MESSAGES

1				
2				
3	005536	105	116	124 DATEQ: .ASCIZ\ENTER DATE AS DD-MMM-YY\
4	003566	040	106	117 FILNAQ: .ASCIZ\ FOR DISK TO BE FORMATTED\
5	003620	040	000	SERNQ: .ASCIZ\ \
6	003622	101	122	105 WQUES: .ASCIZ\ARE YOU SURE YOU WANT TO RUN THIS FORMATTER\



```

1          ; FORMAT STATEMENTS USED IN PRINT CALL
2
3 003676    045    124    000  ERRONE: .ASCIZ\BT\
4 003701    045    116    000  ERRNL. .ASCIZ\BN\
5 003704    042    040    040  RNTIM: .ASCIZ\"  RUNTIME "D16": "\
6 003727    104    071    042  RNTIM1: .ASCIZ\D9' ; "\
7 003735    104    071    000  RNTIM2: .ASCIZ\D9\
8 003740    042    040    040  ERRME1: .ASCIZ\" * * * ERROR PROCESSING MESSAGE STRING * * *\N
9 004027    116    042    125  MESSG: .ASCIZ\N"UNIT "D6" UDA AT "D16" DRIVE 'D9S\
10 004073   042    116    117  NOCLOCK: .ASCIZ\N"NO LINE CLOCK AVAILABLE FOR TIMING EVENTS"N\
11 004150   042    110    117  BASNO: .ASCIZ\N"HOST PROGRAM"\
12 004167   042    040    040  BASL2: .ASCIZ\"  UDA AT "D16\
13 004206   042    040    040  BASL3: .ASCIZ\"  DRIVE "D9\
14 004223   000                    BAS: .BYTE 0          ;NULL TO PRINT NOTHING
15
16 004224   122    066    122  BASLN: .ASCIZ\R6R6R6R6\          ;USED TO PRINT BASIC LINE OF ERROR MESSAGE
17 004235   116    042    123  SERNUM: .ASCIZ\N"SERIAL NUMBER FOR UNIT "D6" UDA AT "D16" DRIVE "D9\
18 004322   042    123    124  WNSTOP: .ASCIZ\"STOPPING THIS FORMAT AFTER THIS POINT WILL MAKE THE DISK"N\
19 004415   042    125    116  .ASCIZ\"UNUSABLE, AND WILL CAUSE THE DISK TO BE SPUN DOWN WHEN"N\
20 004506   042    102    122  .ASCIZ\N"BROUGHT ONLINE."MN\
21 004532   116    042    127  WNSTRT: .ASCIZ\N"WARNING:"N\
22 004546   042    040    040  .ASCIZ\" THIS FORMATTER PROGRAM SHOULD NOT BE USED AS A DIAGNOSTIC"N\
23 004650   042    040    040  .ASCIZ\" TOOL. RUN THIS PROGRAM ONLY AS INSTRUCTED IN THE DISK"N\
24 004747   042    040    040  .ASCIZ\" DRIVE'S SERVICE MANUAL."N\
    
```

1	005010				X1A:	
2	005010				X2A:	
3	005010				X3A:	
4	005010	042	111	040	X8A:	.ASCIZ\ "I DON'T LIKE THE ANSWERS YOU GAVE TO THE HARDWARE QUESTIONS" N
5	005107	122	065	122	X1:	.ASCIZ\R5R6 "UDA HAS MORE THAN ONE VECTOR, BR LEVEL OR BURST RATE" N
6	005203	122	065	122	X2:	.ASCIZ\R5R6 "TWO UNITS SELECT THE SAME DRIVE" N
7	005252	122	065	122	X3:	.ASCIZ\R5R6 "MORE THAN EIGHT DRIVES SELECTED ON THIS UDA" N
8	005335	122	064	042	X4:	.ASCII\R4 "NOT ENOUGH ROOM IN MEMORY TO TEST THE UNITS SELECTED" N
9	005426	042	120	114		.ASCIZ\ "PLEASE START PROGRAM OVER AND TEST FEWER UNITS AT A TIME" N
10	005522	122	065	122	X8:	.ASCIZ\R5R6 "TWO UDA'S USE THE SAME VECTOR" N
11	005567	122	064	042	X9:	.ASCII\R4 "ONLY ONE DISK CAN BE SELECTED IN HW QUESTIONS IN RESTORE MODE." N
12	005672	042	120	114		.ASCIZ\ "PLEASE START PROGRAM OVER AND SELECT ONLY ONE DISK." N
13	005761	122	064	042	X10:	.ASCIZ\R4 "THIS PROGRAM CAN ONLY REFORMAT A DISK IN UNATTENDED MODE." N
14	006060	122	065	042	X14:	.ASCII\R5 "UDASO CONTROLLER IS AT A REVISION LEVEL NO LONGER SUPPORTED BY" N
15	006163	042	124	110		.ASCII\ "THIS FORMATTER PROGRAM, THIS PROGRAM REQUIRES A UDASO-A" N
16	006256	042	103	117		.ASCII\ "CONTROLLER (MODEL 6) WITH MICROCODE VERSION AT 3 OR GREATER." N
17	006356	042	103	117		.ASCIZ\ "CONTROLLER REPORTED MODEL CODE "04" AND MICROCODE VERSION "04". N
18	006461	122	065	042	X20:	.ASCII\R5 "MEMORY ERROR TRYING TO READ UDA REGISTERS" N
19	006537	042	103	110		.ASCII\ "CHECK UNIBUS SELECTION SWITCHES ON UDA MODULE M7485" N
20	006625	042	117	122		.ASCII\ "OR UNIBUS" N
21	006641	042	117	122		.ASCIZ\ "OR "R7"
22	006651	122	065	042	X21:	.ASCII\R5 "UDA RESIDENT DIAGNOSTICS DETECTED FAILURE" NR8\
23	006731	042	122	105		.ASCIZ\ "REPLACE UDA MODULE M748" 03N\
24	006766	122	065	042	X22:	.ASCII\R5 "STEP BIT DID NOT SET IN UDASA REGISTER DURING INITIALIZATION" N
25	007067	042	123	124		.ASCIZ\ "STEP BIT EXPECTED "016NR8R7"
26	007124	122	065	042	X23A:	.ASCII\R5 "UDA DID NOT CLEAR RING STRUCTURE IN MOST MEMORY DURING INITIALIZATION" N
27	007236	104	071	042		.ASCII\ 09 " WORDS WERE TO BE CLEARED STARTING AT ADDRESS "016N\
28	007324	042	106	111		.ASCII\ "FIRST SEVERAL WORDS NOT CLEARED (UP TO 6):" N
29	007401	123	066	042		.ASCIZ\ S6 "ADDRESS" S4 "CONTENTS" N
30	007432	123	067	117	X23B:	.ASCIZ\ S701655016N\
31	007446	122	065	042	X24:	.ASCII\R5 "UDASA REGISTER DID NOT GO TO ZERO AFTER STEP 3 WRITE OF INITIALIZATION" N
32	007561	042	120	125		.ASCIZ\ "PURGE/POLE DIAGNOSTICS WERE REQUESTED" NR8R7\
33	007636	122	065	042	X25:	.ASCII\R5 "UDA DID NOT RETURN CORRECT DATA IN UDASA REGISTER DURING INITIALIZATION" N
34	007752	042	040	040		.ASCIZ\ " UDASA EXPECTED "016NR8R7"
35	010007	122	065	042	X30:	.ASCIZ\R5 "UDA REPORTED FATAL ERROR IN UDASA REGISTER WHILE RUNNING DM PROGRAM" NR8
36	010122	122	065	042	X31:	.ASCIZ\R5 "DUP PROGRAM IS HUNG" N
37	010153	122	065	042	X32:	.ASCIZ\R5 "MESSAGE BUFFER RECEIVED FROM DM PROGRAM WITH UNKNOWN REQUEST NUMBER" N
38	010264	122	065	042	X36:	.ASCII\R5 "NO INTERRUPT RECEIVED FROM UDA FOR 30 SECONDS" N
39	010346	042	127	110		.ASCIZ\ "WHILE LOADING DM PROGRAM" N
40	010402	122	065	042	X37:	.ASCIZ\R5 "UDA REPORTED FATAL ERROR IN UDASA REGISTER WHILE LOADING DM PROGRAM" NR8R7
41	010517	122	065	042	X100:	.ASCIZ\R5 "DUP PROGRAM ASKED UNEXPECTED QUESTION ("D12")" N
42	010602	122	065	042	X101:	.ASCIZ\R5 "DUP PROGRAM REJECTED ANSWER TO DATE OR SERIAL NUMBER QUESTION" N

1	010705	042	115	105	XMSG1:	.ASCIZ\ "MESSAGE BUFFER CONTAINS;"N\
2	010741	123	063	117	XMSG2:	.ASCIZ\S3016S1016S1016S1016S1016S1016S1016N\
3	011006	122	065	042	XPKT1:	.ASCII\R5"RESPONSE PACKET FROM UDA DOES NOT CONTAIN EXPECTED DATA"N
4	011102	042	105	111		.ASCII\ "EITHER UDA RETURNED ERROR STATUS OR PACKET WAS NOT RECEIVED CORRECTLY"N
5	011212	123	063	042		.ASCIZ\S3"COMMAND PACKET SENT S6"RESPONSE PACKET RECEIVED"N\
6	011277	123	066	117	XPKT2:	.ASCIZ\S6016S1016S14016S1016N\
7	011326	042	040	040	XSA:	.ASCIZ\ " UDASA CONTAINS '016N\
8	011357	042	122	105	XFRU:	.ASCIZ\ 'REPLACE UDA MODULE M7485'N\
9						
10						
11	011413	045	101	111	SERNX:	.ASCIZ\MAINPUT ERROR. ANSWER WITH DECIMAL NUMBER LOG MI. #I
12	011503	042	111	116	DATEX:	.ASCIZ\ "INPUT ERROR."N\
13	011522	042	116	101	FILNAM:	.ASCIZ\ "NAME OF FILE CONTAINING BAD SECTOR INFORMATION"N\
14						.EVEN

```

1          .SBTTL GLOBAL ERROR REPORT SECTION
2
3          ;**
4          ; THE GLOBAL ERROR REPORT SECTION CONTAINS MESSAGE PRINTING AREAS
5          ; USED BY MORE THAN TEST TO OUTPUT ADDITIONAL ERROR INFORMATION. PRINTB
6          ; (BASIC) AND PRINTX (EXTENDED) CALLS ARE USED TO CALL PRINT SERVICES.
7
8          ;
9          ;
10         ;
11         ;
12         ;
13         ;
14         ;
15         ;
16         ;
17         ;
18         ;
19         ;
20         ;
21         ;
22         ;
23         ;
24         ;
25         ;
26         ;
27         ;
28         ;
29         ;
30         ;
31         ;
32         ;
33         ;
34         ;
35         ;
    
```

8	177777			SVCINS= 1	; LIST INSTRUCTIONS, SHIFTED RIGHT
9	177777			SVCTST= 1	; LIST TEST TAGS, SHIFTED RIGHT
10	177777			SVCSUB= 1	; LIST SUBTEST TAGS, SHIFTED RIGHT
11	177777			SVCGBL= 1	; LIST GLOBAL TAGS, SHIFTED RIGHT
12	177777			SVCTAG= 1	; LIST OTHER TAGS, SHIFTED RIGHT

```

14         BGNMSG ERRO01
15         PNTB X1,@X1A
16         MOV @X1A,(SP)
17         JSR R1,LPNTB
18         .WORD X1
19         .WORD PNT.CT
20         ENDMSG
21
22         BGNMSG ERRO02
23         PNTB X2,@X2A
24         MOV @X2A,(SP)
25         JSR R1,LPNTB
26         .WORD X2
27         .WORD PNT.CT
28         ENDMSG
29
30         BGNMSG ERRO03
31         PNTB X3,@X3A
32         MOV @X3A,(SP)
33         JSR R1,LPNTB
34         .WORD X3
35         .WORD PNT.CT
36         ENDMSG
37
38         BGNMSG ERRO04
39         PNTB X4
40         JSR R1,LPNTB
41         .WORD X4
42         .WORD PNT.CT
43         ENDMSG
44
45         BGNMSG ERRO08
46         PNTB X8,@X8A
47         MOV @X8A,.(SP)
48         JSR R1,LPNTB
49         .WORD X8
50         .WORD PNT.CT
51         ENDMSG
52
53         BGNMSG ERRO09
54         PNTB X9
55         JSR R1,LPNTB
56         .WORD X9
57         .WORD PNT.CT
    
```

14	011604				
15	011604				
	011604	012746	005010		
	011610	004137	016236		
	011614	005107			
	011616	000002			
16	011620				
17					
18	011622				
19	011622				
	011622	012746	005010		
	011626	004137	016236		
	011632	005203			
	011634	000002			
20	011636				
21					
22	011640				
23	011640				
	011640	012746	005010		
	011644	004137	016236		
	011650	005252			
	011652	000002			
24	011654				
25					
26	011656				
27	011656				
	011656	004137	016236		
	011662	005335			
	011664	000000			
28	011666				
29					
30	011670				
31	011670				
	011670	012746	005010		
	011674	004137	016236		
	011700	005522			
	011702	000002			
32	011704				
33					
34	011706				
35	011706				
	011706	004137	016236		
	011712	005567			
	011714	000000			

36	011716			ENDMSG	
37					
38	011720			BGNMSG ERRO10	
39	011720			PNTB X10	
	011720	004137	016236		JSR R1,LPNTB
	011724	005761			.WORD X10
	011726	000000			.WORD PNT.CT
40	011730			ENDMSG	
41					
42	011732			BGNMSG ERRO14	
43	011732			PNTB X14,R3,R2	
	011732	010246			MOV R2,-(SP)
	011734	010346			MOV R3,(SP)
	011736	004137	016236		JSR R1,LPNTB
	011742	006060			.WORD X14
	011744	000004			.WORD PNT.CT
44	011746			ENDMSG	
45					
46	011750			BGNMSG ERRO20	
47	011750			PNTB X20	
	011750	004137	016236		JSR R1,LPNTB
	011754	006461			.WORD X20
	011756	000000			.WORD PNT.CT
48	011760			ENDMSG	
49					
50	011762			BGNMSG ERRO21	
51	011762	010201		MOV R2,R1	
52	011764	000301		SWAB R1	
53	011766			AND 2,R1	
	011766	042701	177775		BIC #C<2>,R1
54	011772	006201		ASR R1	
55	011774	062701	000005	ADD #5,R1	
56	012000			PNTB X21,R2,R1	
	012000	010146			MOV R1,-(SP)
	012002	010246			MOV R2,-(SP)
	012004	004137	016236		JSR R1,LPNTB
	012010	006651			.WORD X21
	012012	000004			.WORD PNT.CT
57	012014			ENDMSG	
58					
59	012016			BGNMSG ERRO22	
60	012016	042737	100000 020216	BIC #SA.ERR,UDARSD	
61	012024			PNTB X22,UDARSD,R2	
	012024	010246			MOV R2,-(SP)
	012026	013746	020216		MOV UDARSD,(SP)
	012032	004137	016236		JSR R1,LPNTB
	012036	006766			.WORD X22
	012040	000004			.WORD PNT.CT
62	012042			ENDMSG	
63					
64	012044			BGNMSG ERRO23	
65	012044			PNTB X23A,R1,FFREE	
	012044	013746	002146		MOV FFREE,(SP)
	012050	010146			MOV R1,(SP)
	012052	004137	016236		JSR R1,LPNTB
	012056	007124			.WORD X23A
	012060	000004			.WORD PNT.CT

66	012062	00574c		TST (R2)	
67	012064	005712		ERR23A: TST (R2)	
68	012066	001410		BEQ ERR23B	
69	012070			PNTB X23B,R2,(R2)	
	012070	011246			MOV (R2), (SP)
	012072	010246			MOV R2, -(SP)
	012074	004137	016236		JSR R1,LPNTB
	012100	007432			.WORD X23B
	012102	000004			.WORD PNT.C*
70	012104	005304		DEC R4	
71	012106	001403		BEQ ERR23C	
72	012110	005722		ERR23B: TST (R2)	
73	012112	005303		DEC R3	
74	012114	001363		BNE ERR23A	
75	012116			ERR23C: PNTB XFRU	
	012116	004137	016236		JSR R1,LPNTB
	012122	011357			.WORD XFRU
	012124	000000			.WORD PNT.C*
76	012126			ENDMSG	
77					
78	012130			BGNMSG ERR024	
79	012130			PNTB X24,R2	
	012130	010246			MOV R2, -(SP)
	012132	004137	016236		JSR R1,LPNTB
	012136	007446			.WORD X24
	012140	000002			.WORD PNT.C*
80	012142			ENDMSG	
81					
82	012144			BGNMSG ERR025	
83	012144			PNTB X25,R1,R2	
	012144	010246			MOV R2, (SP)
	012146	010146			MOV R1, -(SP)
	012150	004137	016236		JSR R1,LPNTB
	012154	007636			.WORD X25
	012156	000004			.WORD PNT.C*
84	012160			ENDMSG	
85					
86	012162			BGNMSG ERR030	
87	012162			PNTB X30,R1	
	012162	010146			MOV R1, (SP)
	012164	004137	016236		JSR R1,LPNTB
	012170	010007			.WORD X30
	012172	000002			.WORD PNT.C*
88	012174			ENDMSG	
89					
90	012176			BGNMSG ERR031	
91	012176			PNTB X31	
	012176	004137	016236		JSR R1,LPNTB
	012202	010122			.WORD X31
	012204	000000			.WORD PNT.C*
92	012206			ENDMSG	
93					
94	012210			BGNMSG ERR032	
95	012210			PNTB X32	
	012210	004137	016236		JSR R1,LPNTB
	012214	010153			.WORD X32
	012216	000000			.WORD PNT.C*

96	012220	004737	012410	CALL MSGPKT	
97	012224			ENDMSG	
98					
99	012226			BGNMSG ERR033	
100	012226	004737	012316	CALL PNTPKT	
101	012232			ENDMSG	
102					
103	012234			BGNMSG ERR034	
104	012234	004737	012316	CALL PNTPKT	
105	012240			ENDMSG	
106					
107	012242			BGNMSG ERR036	
108	012242			PNTB X36	
	012242	004137	016236		JSR R1,LPNTB
	012246	010264			.WORD X36
	012250	000000			.WORD PNT.CT
109	012252			ENDMSG	
110					
111	012254			BGNMSG ERR037	
112	012254			PNTB X37,R1	
	012254	010146			MOV R1, (SP)
	012256	004137	016236		JSR R1,LPNTB
	012262	010402			.WORD X37
	012264	000002			.WORD PNT.CT
113	012266			ENDMSG	
114					
115	012270			BGNMSG ERR100	
116	012270			PNTB X100,(R4)	
	012270	011446			MOV (R4), (SP)
	012272	004137	016236		JSR R1,LPNTB
	012276	010517			.WORD X100
	012300	000002			.WORD PNT.CT
117	012302			ENDMSG	
118					
119	012304			BGNMSG ERR101	
120	012304			PNTB X101	
	012304	004137	016236		JSR R1,LPNTB
	012310	010602			.WORD X101
	012312	000000			.WORD PNT.CT
121	012314			ENDMSG	
122					
123	012316			PNTPKT: PNTB XPKT1	
	012316	004137	016236		JSR R1,LPNTB
	012322	011006			.WORD XPKT1
	012324	000000			.WORD PNT.CT
124	012326	010401		MOV R4,R1	
125	012330	062701	000104	ADD #HC.CPK,R1	
126	012334	010402		MOV R4,R2	
127	012336	062702	000020	ADD #HC.MPK,R2	
128	012342	012703	000014	MOV #12.,R3	
129	012346			PNTPKL: PNTB XPKT2,2(R1),(R1),2(R2),(R2)	
	012346	011246			MOV (R2), (SP)
	012350	016246	000002		MOV 2(R2),-(SP)
	012354	011146			MOV (R1), (SP)
	012356	016146	000002		MOV 2(R1),-(SP)
	012362	004137	016236		JSR R1,LPNTB
	012366	011277			.WORD XPKT2

	012370	000010				.WORD PNT.CT
130	012372	062701	000004	ADD #4,R1		
131	012376	062702	000004	ADD #4,R2		
132	012402	005303		DEC R3		
133	012404	001360		BNE PNTPKL		
134	012406	000207		RETURN		
135						
136	012410			MSGPKT: PNTB XMSG1		
	012410	004137	016236			JSR R1,LPNTB
	012414	010705				.WORD XMSG1
	012416	000000				.WORD PNT.CT
137	012420	016504	000016	MOV C.RING(R5),R4		
138	012424	062704	000430	ADD #HC.BF2,R4		
139	012430	012703	000005	MOV #5,R3		
140	012434			MSGPKL: PNTB XMSG2,(R4),2(R4),4(R4),6(R4),8.(R4),10.(R4),,12.(R4)		
	012434	016446	000014			MOV 12.(R4), (SP)
	012440	016446	000012			MOV 10.(R4), (SP)
	012444	016446	000010			MOV 8.(R4), -(SP)
	012450	016446	000006			MOV 6(R4), (SP)
	012454	016446	000004			MOV 4(R4), (SP)
	012460	016446	000002			MOV 2(R4), (SP)
	012464	011446				MOV (R4), -(SP)
	012466	004137	016236			JSR R1,LPNTB
	012472	010741				.WORD XMSG2
	012474	000016				.WORD PNT.CT
141	012476	062704	000016	ADD #14.,R4		
142	012502	005303		DEC R3		
143	012504	001353		BNE MSGPKL		
144	012506	000207		RETURN		



11)

1	000001	SVCINS= 1
2	000001	SVCTST= 1
3	000001	SVCSUB= 1
4	000001	SVCGBL= 1
5	000001	SVCTAG= 1

; LIST INSTRUCTIONS, SHIFTED RIGHT  
; LIST TEST TAGS, SHIFTED RIGHT  
; LIST SUBTEST TAGS, SHIFTED RIGHT  
; LIST GLOBAL TAGS, SHIFTED RIGHT  
; LIST OTHER TAGS, SHIFTED RIGHT

```

1      .SBTTL GLOBAL SUBROUTINES SECTION
2
3      ;MEMORY ALLOCATION ERROR
4      ;
5      ;THIS ROUTINE PRINTS A SYSTEM FATAL ERROR AND EXITS THE TEST
6
7      FMERR:  ERRSF 4,,ERR004
8
9      012510      104454
10     012510      000004
11     012512      000000
12     012514      000000
13     012516      011656
14
15     DOCLN      ,ABORT
16
17     TRAP      C:ERSF
18     .WORD      4
19     .WORD      0
20     .WORD      ERR004
21
22     TRAP      C:DCLN

```

```

1      ;ALOCM
2      ;
3      ;ALLOCATE A BLOCK OF FREE MEMORY.  REPORT ERROR IF MEMORY EXHAUSTED.
4      ;
5      ;INPUTS:
6      ;   R1 - NUMBER OF WORDS TO ALLOCATE
7      ;   FFREE - FIRST FREE WORD IN MEMORY
8      ;   FSIZE - SIZE OF FREE MEMORY AVAILABLE IN WORDS
9      ;
10     ;OUTPUTS:
11     ;   R1 - ADDRESS OF FIRST WORD OF ALLOCATED MEMORY
12     ;   FFREE - NEW FIRST FREE WORD IN MEMORY
13     ;   FSIZE - SIZE OF FREE MEMORY LEFT AFTER ALLOCATION
14     ;SYSTEM FATAL ERROR WILL BE REPORTED IF NOT ENOUGH MEMORY AVAILABLE
15     ;AND ENTIRE PROGRAM WILL BE STOPPED.
16     ALOCM:  PUSH FFREE                ;SAVE FFREE AT ENTRY
17             SUB R1,FSIZE              ;REDUCE SIZE OF FREE MEMORY
18             BLT FMERR                ;REPORT ERROR IF NOT ENOUGH MEMORY
19             ADD R1,R1                ;CHANGE WORDS TO BYTES
20             ADD R1,FFREE             ;CALCULATE NEW START OF FREE MEMORY
21             POP R1                  ;GET START OF ALLOCATED MEMORY
22             RETURN                  ;MOV (SP),R1
    
```

```

16 012522      013746  002146
17 012526      160137  002150
18 012532      002766
19 012534      060101
20 012536      060137  002146
21 012542      012601
22 012544      000207
    
```

```
1      ;HCOMM
2      ;
3      ; ALLOCATES MEMORY FOR HOST COMM AREA AND PACKET BUFFERS WITH ONE
4      ; DESCRIPTOR IN EACH RING, TO BE CALLED WHEN INITIALIZING
5      ; A CONTROLLER WITH SA.MSG=0 AND SA.CMD=0.
6      ;
7      ; INPUTS:
8      ; R5 - ADDRESS OF CONTROLLER TABLE
9      ;
10     ; OUTPUTS:
11     ; CONTROLLER TABLE POINTING TO HOST COMM AREA
12     ; R4 - ADDRESS OF HOST COMM AREA
13     HCOMM:  MOV #MC.SIZ/2,R1      ;GET SIZE OF AREA TO ALLOCATE
14             CALL ALOCM          ;ALLOCATE THE MEMORY
15             MOV R1,C.RING(R5)   ;GET ADDRESS OF HOST COMM AREA
16             ;PLACE IN CONTROLLER TABLE
17     RETURN
```



```

1      ;RUNDM
2
3      ;LOAD AND RUN A DM PROGRAM IN THE CONTROLLERS. RETURN WHEN ALL
4      ;DM PROGRAMS HAVE TERMINATED.
5
6      ;INPUTS:
7      ;   TSTTAB  POINTER TO FIRST CONTROLLER TABLE
8      ;   R1     NUMBER OF CONTROLLERS TO TEST
9      ;IMPLICIT INPUTS:
10     ;   DMPROG - POINTER TO START OF DM PROGRAM IN MEMORY
11     ;OUTPUTS:
12     ;   Z SET IF NO CONTROLLERS SUCCESSFULLY STARTED
13     ;ALL REGISTERS ARE USED AND PREVIOUS CONTENTS DESTROYED.
14
15 012710 010137 002166      RUNDM:  MOV R1,URUN          ;SAVE NUMBER OF UNITS TO RUN
16 012714 005037 002170          CLR URNING        ;CLEAR NUMBER OF UNITS RUNNING
17
18     ;LOAD DM PROGRAM INTO EACH CONTROLLER
19
20 012720 013737 002166 002172      MOV URUN,UCNT      ;SET COUNTER OF UNITS
21 012726 013705 002162          MOV TSTTAB,R5      ;GET FIRST CONTROLLER TABLE
22 012732          LDDM:
23 012732 005065 000014          CLR C.FLG(R5)     ;CLEAR ALL FLAGS
24 012736 016537 000002 002074      MOVB C,UNIT(R5),L1LUN ;SEE IF UNIT TO BE TESTED
25 012744 005765 000002          TST C,UNIT(R5)
26 012750 100407          BMI LDNEXT        ;IF NOT, DON'T LOAD THIS UNIT
27 012752          ASSUME CT,AVL EQ BIT15
28 012752 004737 012546          CALL HCOMP        ;ALLOCATE SPACE FOR HOST COMM AREA
29 012756 004737 016370          CALL LOADDM      ;LOAD THE DM PROGRAM
30 012762 001402          BEQ LDNEXT        ;IF ERROR, GO TO NEXT CONTROLLER
31 012764 005237 002170          INC URNING       ;IF NO ERROR, COUNT UNIT RUNNING
32 012770 062705 000054      LDNEXT: ADD #C.SIZE,R5 ;MOVE TO NEXT CONTROLLER TABLE
33 012774 005337 002172          DEC UCNT        ;CHECK IF MORE CONTROLLERS
34 013000 001354          BNE LDDM        ;LOAD NEXT
35 013002 005037 002176          CLR UFREEZ      ;CLEAR UNIT FREEZE FLAG
36 013006 012737 177777 003204      MOV #-1,FCNUM    ;INVALIDATE FCT BLOCK NUMBER (BLOCK IN MEMORY)
37
38     ;CHECK IF ANY CONTROLLERS LOADED
39
40 013014 005737 002170          TST URNING       ;ANY UNITS LOADED?
41
42     ;THE DM PROGRAMS ARE NOW IN CONTROL
43     ;RESPDM MUST BE CALLED TO RESPOND TO THEIR REQUESTS
44
45 013020 000207          RETURN
    
```

```
1      ;CLOSEF
2      ;
3      ;CLOSE DATA FILE FOR DM PROGRAMS
4      ;
5      ;INPUTS:
6      ;      FILOPN  ZERO IF FILE NOT OPEN
7      ;OUTPUTS:
8      ;      NONE
9
10     013022 005737 002174      CLOSEF: TST FILOPN      ;SEE IF FILE CURRENTLY OPEN
11     013026 001403              BEQ 18
12     013030              CLOSE      ; IF SO, CLOSE IT
13     01303C 104435              ;AND MARK AS SO      TRAP  C8CLOS
14     013032 005037 002174      18: CLR FILOPN
14     013036 000207              RETURN
```

```

1      ;RESPDM
2
3      ;RESPOND TO DM REQUESTS. RETURN WHEN ALL DM PROGRAMS
4      ;HAVE TERMINATED.
5
6 013040 013705 002162      RESPDM: MOV TSITAB,R5      ;GET CONTROLLER TABLE ADDRESS
7 013044 013737 002166 002172      MOV URUN,UCNT      ;SET COUNTER OF UNITS
8 013052      RESPCT: BREAK      ;ALLOW DRS TO SEE TERMINAL INPUT
9 013052 104422      ;
10 013054 016504 000016      MOV C.RING(R5),R4      ;GET MOST COMM AREA ADDRESS
11 013060 032765 000002 000014      BIT #CT.RN,C.FLG(R5)      ;CHECK IF PROGRAM RUNNING
12 013070 116537 000002 002074      BEQ RSPNXT      ;IF NOT, LOOK AT NEXT
13 013076 032765 000010 000014      MOV C.UNIT(R5),L#LUN      ;STORE UNIT NUMBER UNDER TEST
14 013104 001150      BNE RSPIN      ;SEE IF INTERRUPT RECEIVED
15 013106 032765 000004 000014      BIT #CT.CMD,C.FLG(R5)      ;IF SO, LOOK AT PACKET
16 013114 001002      BNE 1#      ;SEE IF COMMAND HAS BEEN SENT
17 013116 000137 013664      JMP RSPOUT      ;IF NOT, SEND ONE
18
19      ;CHECK IF UDA STILL RUNNING
20
21 013122 011503      1#: MOV (R5),R3      ;GET ADDRESS OF UDAIP
22 013124 016301 000002      MOV 2(R3),R1      ;LOOK AT UDASA REGISTER
23 013130 001405      BEQ RSPTM      ;IF ZERO, UDA STILL RUNNING
24 013132      ERROF 30,ERR030      ;REPORT UDA HAS FATAL ERROR
25 013132 104455      ;
26 013134 000036      ;
27 013136 000000      ;
28 013140 012162      ;
29 013142 000465      BR RSPDRP      ;DROP CONTROLLER FROM TESTING
30
31      ;CHECK FOR TIMEOUT OF RESPONSE
32
33 013144 005765 000044      RSPTM: TST C.TOT(R5)      ;SEE IF DUP PROGRAM TO BE TIMED
34 013150 001451      BEQ RSPNTO
35 013152 005737 003210      TST KW.CSR      ;SEE IF A CLOCK ON SYSTEM
36 013156 001446      BEQ RSPNTO      ;DON'T TIME IF NO CLOCK
37 013160 023765 003222 000042      CMP KW.EL+2,C.TOM(R5)      ;COMPARE TO TIMEOUT COUNTER
38 013166 101005      BHI RSPTHO
39 013170 001041      BNE RSPNTO
40 013172 023765 003220 000040      CMP KW.EL,C.TO(R5)
41 013200 103435      BLO RSPNTO      ;IF TOO MUCH TIME ELAPSED SINCE LAST INTERRUPT
42 013202 032765 000040 000014      RSPTHO: BIT #CT.STA,C.FLG(R5)      ;SEE IF A GET DUST STATUS COMMAND OUTSTANDING
43 013210 001101      BNE RSPTOE      ;REPORT ERROR IF SO
44 013212 005764 000012      TST MC.CCT(R4)      ;SEE IF UDA TOOK LAST COMMAND PACKET
45 013216 100476      BHI RSPTOE      ;REPORT ERROR IF NOT
46 013220 012700 000100      MOV #CT.TM1,R0      ;SEE IF FIRST TIMEOUT ALREADY HAPPENED
47 013224 032765 000100 000014      BIT #CT.TM1,C.FLG(R5)
48 013232 001401      BEQ 1#
49 013234 006300      ASL R0      ;IF SO,
50 013236 052700 000040      1#: BIS #CT.STA,R0      ;SET SECOND TIME OUT FLAG
51 013242 050065 000014      BIS R0,C.FLG(R5)      ;SET THE PROPER TIMEOUT BIT
52 013246 012700 000001      MOV #OP.GDS,R0      ; AND STATUS REQUESTED BIT
53 013252 004737 016570      CALL BLD CMD      ;BUILD GET DUST STATUS COMMAND
54 013256 012764 102700 000012      MOV #RG.DWN,MC.CCT(R4)      ;MARK COMMAND TO UDA
55 013264 005775 000000      TST #R5      ;TELL UDA COMMAND IS THERE
56 013270 000137 013744      JMP RSPOUT
    
```



H6

53 013274

RSPNT0:

```

1          ;SWITCH TO NEXT CONTROLLER
2
3 013274 005737 002176      RSPNXT: TST UFREEZ          ;FROZEN TO ONE UNIT?
4 013300 001264              BNE RESPCT          ;STAY THERE IF SO
5 013302 062705 000054      ADD #C.SIZE,R5          ;MOVE TO NEXT TABLE
6 013306 005337 002172      DEC UCNT              ;CHECK IF MORE CONTROLLERS
7 013312 001257              BNE RESPCT          ;LOOK AT NEXT CONTROLLER
8 013314 000651              BR RESPDM           ;LOOK AT FIRST CONTROLLER AGAIN
9
10         ;REMOVE A CONTROLLER FROM TESTING
11
12 013316 005065 000014      RSPDRP: CLR C.FLG(R5)    ;CLEAR PROGRAM RUNNING
13 013322 005037 002176      CLR UFREEZ
14 013326 010504              MOV R5,R4
15 013330 062704 000020      ADD #C.DRO,R4
16 013334 012702 000010      MOV #8.,R2
17 013340 012403              1$: MOV (R4),R3
18 013342 001420              BEQ 3$
19 013344 005763 000002      TST D.UNIT(R3)
20 013350                      ASSUME DT.AVL EQ BIT15
21 013350 100003              BPL 2$
22 013352 005302              DEC R2
23 013354 001371              BNE 1$
24 013356 000412              BR 3$
25 013360 052763 100000 000002 2$: BIS #DT.AVL,D.UNIT(R3)
26 013366 005302              DEC R2
27 013370 001405              BEQ 3$
28 013372 005714              TST (R4)
29 013374 001403              BEQ 3$
30 013376 004737 016370      CALL LOADDM          ;START DM PROGRAM AGAIN
31 013402 001223              BNE RESPCT
32 013404 005337 002170      3$: DEC URNING          ;REDUCE RUNNING CONTROLLERS COUNT
33 013410 001331              BNE RSPNXT          ;IF ANY STILL RUNNING, LOOK AT THEM
34 013412 000207              RETURN          ;ELSE RETURN TO TEST SECTION
35
36 013414                      RSPTCE: ERROF 31.,ERRO31          ;REPORT TIMEOUT ERROR
37 013414 104455                      TRAP          C1ERDF
38 013416 000037                      .WORD          31
39 013420 000000                      .WORD          0
40 013422 012176                      .WORD          ERRO31
41 013424 000734                      BR RSPDRP          ;DROP CONTROLLER FROM TESTING
    
```

```

1          ;CONTROLLER HAS RESPONDED, LOOK AT MESSAGE PACKET
2
3          ;CHECK FOR PROPER OPCODE IN END PACKET
4
5 013426 012700 000204          RSPIN:  MOV #OP.END.OP.SSD,R0          ;GET SEND DATA END PACKET OPCODE
6 013432 032765 000020 000014  BIT #CT.REQ.C.FLG(R5)          ;LOOK IF SEND DATA OR RECEIVE DATA
7 013440 001402          BEQ RSPMWR
8 013442 012700 000205          MOV #OP.END.OP.RSD,R0          ;CHANGE TO RECEIVE DATA END PACKET OPCODE
9 013446 120064 000030  RSPMWR:  CMPB R0,HC.MPK.P.OP_LD(R4)          ;COMPARE TO OPCODE IN END PACKET
10 013452 001145          BNE RSPERR
11
12          ;LOOK AT STATUS CODE
13
14 013454 032764 000037 000032  BIT #ST.MSK,HC.MPK.P.ST5(R4)          ;CHECK FOR STATUS CODE ST.SUC (ZERO)
15 013462 001004          BNE RSPERR
16
17          ;CHECK FOR EXPECTED REFERENCE NUMBER
18
19 013464 026564 000052 000020  CMP C.REF(R5),HC.MPK.P.CRF(R4)          ;CHECK IF CORRECT REF NUMBER
20 013472 001405          BEQ RSPPTW
21 013474          RSPERR:  ERRDF 33,,ERR033
22 013474 104455          TRAP CERRDF
23 013476 000041          .WORD 33
24 013500 000000          .WORD 0
25 013502 012226          .WORD ERR033
26 013504 000704          BR RSPDRP          ;DROP UNIT FROM TESTING
27
28          ;CHECK IF RESPONSE FROM SEND OR RECEIVE DATA COMMAND
29
30 013506 032765 000020 000014  RSPPTW: BIT #CT.REQ.C.FLG(R5)          ;CHECK IF RESPONSE FROM DM PROGRAM
31 013514 001463          RSPOU:  BEQ RSPOUT          ;LOOK AT REQUEST NUMBER IF SO
    
```

```

1      ;MAINTENANCE READ END PACKET RECEIVED, LOOK AT REQUEST FROM DM PROGRAM
2
3 013516 016401 000430 RSPPT2: MOV HC.BF2(R4),R1      ;GET REQUEST NUMBER
4 013522 042701 007777    ;IC      @?C<DU.TYP>,R1      ;CHECK TYPE
5 013526 001403          BEQ 18      ;IF ZERO, ERROR
6 013530 020127 060000    CMP R1,@DU.SPC      ;CHECK IF IN EXPECTED RANGE
7 013534 101405          BLOS RSPPT3
8 013536          18:          ERRDF 32,,ERR032      ;BAD REQUEST NUMBER
          013536 104455          TRAP      C1ERRDF
          013540 000040          .WORD      32
          013542 000000          .WORD      0
          013544 012210          .WORD      ERR032
9 013546 000663          BR RSPDRP      ;DROP UNIT FROM TESTING
10
11 013550 016403 000034 RSPPT3: MOV HC.MPK.P.BCNT(R4),R3 ;GET BYTE COUNT OF CHARACTERS RECEIVED IN R4
12 013554 162703 000002    SUB #2,R3          ;(FIRST TWO CHARACTERS ARE TYPE WORD)
13 013560 012700 000004    MOV #OP.SSD,R0     ;BUILD A SEND DATA COMMAND PACKET
14 013564 004737 016570    CALL BLDCHD      ; FOR ANSWER TO DM PROGRAM
15 013570 012700 000164    MOV #HC.BF1,R0   ;POINT TO BUFFER IN PACKET
16 013574 004737 016732    CALL CLRBUF     ; AND CLEAR BUFFER
17 013600 010402          MOV R4,R2        ;R2 POINTS TO SEND BUFFER
18 013602 062704 000244    ADD #HC.BSZ,R4   ;R4 POINTS TO CHARACTERS IN RECEIVE BUFFER
19 013606 042724 170000    BIC #DU.TYP,(R4) ;CLEAR TYPE FIELD IN BUFFER
20 013612 000301          SWAB R1          ;GET TYPE RIGHT JUSTIFIED
21 013614 006201          ASR R1          ;TIMES TWO
22 013616 006201          ASR R1
23 013620 006201          ASR R1
24 013622 010100          MOV R1,R0        ;COPY MESSAGE TYPE TO R0
25 013624 005001          CLR R1          ;R1 CONTAINS ZERO SEND BYTE COUNT
26 013626 004770 014112    CALL @RSPDSP-2(R0) ;CALL REQUESTED ROUTINE
27 013632 001231          BNE RSPDRP      ;ROUTINE RETURNS Z CLEAR TO DROP UNIT FROM TESTING
28                                ; Z SET IF UNIT TO CONTINUE RUNNING
29 013634 016504 000016    MOV C.RING(R5),R4 ;GET RING ADDRESS
30 013640 032701 000001    BIT #1,R1        ;LOOK AT CHARACTER COUNT TO SEND TO DUP PROGRAM
31 013644 001401          BEQ 18          ;IF AN ODD COUNT
32 013646 005201          INC R1          ; INCREASE BY ONE
33 013650 010164 000120    18:          MOV R1,HC.CPK.P.BCNT(R4) ;PUT CHARACTER COUNT IN COMMAND PACKET
34 013654 100003          BPL RSPOUT      ;IF NEGATIVE BYTE COUNT RETURNED
35 013656 042765 00002C 000014 BIC #CT.REQ,C.FLG(R5) ; DON'T SEND ANY DATA TO UDA
36
37 ;SEND COMMAND BACK TO UDA
38
39 013664 042765 000350 000014 RSPOUT: BIC #CT.MSG+CT.STA+CT.TM1+CT.TM2,C.FLG(R5) ;CLEAR MESSAGE RECEIVED FLAG
40 013672 032765 000020 000014 BIT #CT.REQ,C.FLG(R5) ;CHECK WHICH COMMAND TO SEND
41 013700 001014          BNE RSPDU2      ;BRANCH IF RESPONSE TO REQUEST
42
43 013702 012700 000005          MOV #OP.RSD,R0   ;BUILD RECEIVE DATA COMMAND
44 013706 004737 016570    CALL BLDCHD
45 013712 012700 000430    MOV #HC.BF2,R0   ;POINT TO MESSAGE BUFFER
46 013716 004737 016732    CALL CLRBUF     ; AND CLEAR IT
47 013722 052765 000020 000014 BIS #CT.REQ,C.FLG(R5) ;SET REQUEST BIT
48 013730 000403          BR RSPDU3
49
50 013732 042765 000020 000014 RSPDU2: BIC #CT.REQ,C.FLG(R5) ;CLEAR REQUEST BIT
51 013740          RSPDU3:
52 013740 004737 016654          CALL SNDCHD     ;SEND COMMAND TO UDA
53 013744 016500 000044          RSPDU4: MOV C.TOT(R5),R0 ;SET TIMEOUT
    
```

```

54 013750 010501          MOV R5,R1
55 013752 062701 000040    ADD #C.TO,R1          ;PUT TIME IN CONTROLLER TABLE
56 013756 004737 017166    CALL SETTO
57 013762 000137 013274    JMP RSPNXT           ;NOW WAIT FOR END PACKET
58 013766 122764 000201 000030 RSPERR: CMPB #OP.END+OP.GDS,HC.MPK+P.OPCD(R4) ;SEE IF GET DUST STATUS OPCODE
59 013774 001237          BNE RSPERW
60 013776 132764 000010 000037 BITB #DF.ACT,HC.MPK+P.DFLG(R4) ;IF DUST NO LONGER RUNNING
61 014004 001603          BEQ RSPTOE           ;REPORT ERROR
62 014006 042765 000050 000014 BIC #CT.STA+CT.MSG,C.FLG(R5) ;CLEAR CONTROL BITS
63 014014 032765 000200 000014 BIT #CT.TM2,C.FLG(R5) ;IF AT SECOND TIMEOUT
64 014022 001413          BEQ 1#
65 014024 026465 000040 000046 CMP HC.MPK+P.DPI(R4),C.PRI(R5) ;COMPARE PROGRESS INDICATOR
66 014032 001004          BNE 2#
67 014034 026465 000042 000050 CMP HC.MPK+P.DPI+2(R4),C.PRI+2(R5) ;COMPARE PROGRESS INDICATOR
68 014042 001422          BEQ 4#              ;REPORT ERROR IF NOT CHANGED
69 014044 042765 000200 000014 2#: BIC #CT.TM2,C.FLG(R5) ;CLEAR TIMEOUT 2 FLAG
70 014052 032765 000100 000014 1#: BIT #CT.TM1,C.FLG(R5) ;IF AT FIRST TIMEOUT
71 014060 001406          BEQ 3#
72 014062 016465 000040 000046 MOV HC.MPK+P.DPI(R4),C.PRI(R5) ;GET COPY OF PROGRESS INDICATOR
73 014070 016465 000042 000050 MOV HC.MPK+P.DPI+2(R4),C.PRI+2(R5) ;GET COPY OF PROGRESS INDICATOR
74 014076 012764 140000 000006 3#: MOV #RG.OWN+RG.FLG,HC.HCT(R4) ;GIVE MESSAGE BUFFER BACK TO UDA
75 014104 000137 013274          JMP RSPNXT
76 014110 000137 013414          JMP PSPTOE
    
```

1  
2  
3 014114 014130  
4 014116 014202  
5 014120 014354  
6 014122 014502  
7 014124 014512  
8 014126 014522  
9 000006

;RESPONSE REQUEST DISPATCH TABLE

RSPDSP: .WORD QUEST  
.WORD DQUEST  
.WORD INFO  
.WORD TERM  
.WORD ERRTRM  
.WORD SPECL  
DSPSIZ=«. RSPDSP»/2

;QUESTION  
;QUESTION WITH DEFAULT ANSWER  
;INFORMATION MESSAGE FOR OPERATOR  
;NORMAL TERMINATION  
;FATAL ERROR TERMINATION  
;SPECIAL  
;LEGAL NUMBERS ARE LOWER THAN THIS



!NORMAL DUP SEND DATA BUFFER DESCRIPTION GIVEN IN RESPONSE TO ABOVE PACKET

1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38

!BYTE OFFSET FROM  
!START OF BUFFER

0	DATA BYTES
2	DATA BYTES
4	DATA BYTES
6	DATA BYTES
8	DATA BYTES
10	DATA BYTES
12	DATA BYTES
14	DATA BYTES
16	DATA BYTES
18	DATA BYTES
20	DATA BYTES
22	DATA BYTES
.	.
.	.
.	.
80	DATA BYTES

R2 CONTAINS THIS ADDRESS



1  
 2  
 3  
 4  
 5  
 6  
 7  
 8  
 9  
 10  
 11  
 12  
 13  
 14  
 15  
 16 014130 004737 014654  
 17 014134 062700 000004  
 18 014140 014403  
 19 014142 001411  
 20 014144 020327 000007  
 21 014150 001410  
 22 014152  
 014152 104455  
 014154 000144  
 014156 000000  
 014160 012270  
 23 014162 000244  
 24 014164 000207  
 25  
 26 014166 012700 003306  
 27 014172  
 28 014172 005201  
 29 014174 112022  
 30 014176 001375  
 31 014200 000207

```

;MESSAGE TYPE 1
;ANSWER QUESTION FOR DUP PROGRAM
;INPUT:
;   R5 ADDRESS OF CONTROLLER TABLE
;   R4 POINTER TO DATA IN RECEIVE BUFFER
;   R3 CHARACTER COUNT IN RECEIVE BUFFER
;   R2 POINTER TO SEND BUFFER (BUFFER IS CLEARED)
;   R1 ZERO
;OUTPUT:
;   R1 COUNT OF CHARACTERS IN SEND BUFFER
;   Z SET TO CONTINUE RUNNING DUP PROGRAM
;   Z CLEAR TO STOP THE DUP PROGRAM
QUEST: CALL GDRVT      ;GET POINTER TO DRIVE TABLE
        ADD #D.SERN,R0 ;BUMP POINTER TO SERIAL NUMBER
        MOV -(R4),R3   ;GET QUESTION NUMBER
        BEQ QUE0       ;BRANCH IF QUESTION NUMBER 0
        CMP R3,#7      ;IF NOT, SEE IF QUESTION NUMBER 7
        BEQ QUE7
        ERDF 100.,ERR100 ;ANY OTHER NUMBER IS AN ERROR
        CLZ            ;CLEAR Z TO STOP DUP PROGRAM
        RETURN
QUE0:  MOV #DATE0,R0   ;POINT TO DATE STRING
QUE7:
QUE1:  INC R1          ;COUNT THE CHARACTERS
        MOVB (R0)+,(R2)+ ; AND PUT THEM IN OUTPUT BUFFER
        BNE QUE1      ; UNTIL A NUL CHARACTER FOUND
        RETURN        ;RETURN WITH Z SET
    
```

```

TRAP    CERRDF
.WORD   100
.WORD   0
.WORD   ERR100
    
```

```

1      ;MESSAGE TYPE 2
2
3      ;ANSWER QUESTION FOR DUP PROGRAM WITH DEFAULT ANSWER
4
5      ;INPUT:
6      ;      R5 ADDRESS OF CONTROLLER TABLE
7      ;      R4 POINTER TO DATA IN RECEIVE BUFFER
8      ;      R3 CHARACTER COUNT IN RECEIVE BUFFER
9      ;      R2 - POINTER TO SEND BUFFER (BUFFER IS CLEARED)
10     ;      R1 ZERO
11     ;OUTPUT:
12     ;      R1 COUNT OF CHARACTERS IN SEND BUFFER
13     ;      Z SET TO CONTINUE RUNNING DUP PROGRAM
14     ;      Z CLEAR TO STOP THE DUP PROGRAM
15
16 014202 004737 014654 DQUEST: CALL GTDRVT      ;GET DRIVE TABLE ADDRESS INTO R0
17 014206 014403      MOV -(R4),R3      ;GET QUESTION NUMBER
18 014210 020327 000006      CMP R3,#DQUESZ
19 014214 101035      BHI DQUEX
20 014216 006303      ASL R3
21 014220 000173 014224      JMP @DQUEJP(R3)
22 014224 014310 DQUEJP: .WORD DQUEX      ; 0 (NOT USED)
23 014226 014242      .WORD DQUNIT      ; 1 ENTER UNIT NUMBER TO FORMAT
24 014230 014310      .WORD DQUEX      ; 2 (NOT USED)
25 014232 014310      .WORD DQUEX      ; 3 (NOT USED)
26 014234 014314      .WORD DQRFMT      ; 4 USE EXISTING BAD SECTOR INFORMATION
27 014236 014334      .WORD DQRSTR      ; 5 DOWN-LINE LOAD BAD SECTOR BLOCK INFORMATION
28 014240 014344      .WORD DQCONT      ; 6 CONTINUE IF BAD BLOCK INFO INACCESSIBLE
29      000006      DQUESZ=<<.-DQUEJP>/2>-1
30
31     ;ENTER UNIT NUMBER TO FORMAT
32
33 014242      DQUNIT: PUSH R5
34 014242 010546      CLR R4
35 014244 005004      MOV (R0),R3      ;GET DRIVE NUMBER
36 014250 011003      ASSUME D.DRV EQ 0
37 014250 012700 000012      MOV #10.,R0      ;RADIX 10.
38 014254 004737 016332 DQUNL1: CALL DIVIDE
39 014260      PUSH R5
40 014262 010546      MOV R5,(SP)
41 014264 005201      INC R1
42 014266 005703      TST R3
43 014270 001372      BNE DQUNL1
44 014272 010100      MOV R1,R0
45 014272 012605      DQUNL2: POP R5
46 014274 062705 000060      MOV (SP),.R5
47 014300 110522      ADD #0,R5
48 014302 005300      MOV R5,(R2).
49 014306 001372      DEC R0
50 014306 012605      BNE DQUNL2
51 014310 000264      POP R5
52 014312 000207      MOV (SP),.R5
53 014314 032737 000003 003206 DQRFMT: BIT #50.FMT,MODE
    
```

54	014322	001410				BEQ DQNO
55	014324	112712	000131		DQYES:	MOVW 0'Y,(R2)
56	014330	005201				INC R1
57	014332	000766				BR DQUEX
58						
59	014334	032737	000010	003206	DQRSTR:	BIT #50,S1R,MODE
60	014342	001370				BNE DQYES
61	014344				DQCONT:	
62	014344	112712	000116		DQNO:	MOVW 0'N,(R2)
63	014350	005201				INC R1
64	014352	000756				BR DQUEX

```

1      ;MESSAGE TYPE 3
2      ;
3      ;PRINT INFORMATION FROM DUP PROGRAM
4      ;
5      ;INPUT:
6      ;
7      ;   R5 - POINTER TO CONTROLLER TABLE
8      ;   R4 - POINTER TO DATA IN RECEIVE BUFFER
9      ;   R3 - CHARACTER COUNT IN RECEIVE BUFFER
10     ;   R2 - POINTER TO SEND BUFFER (BUFFER IS CLEARED)
11     ;   R1 - ZERO
12     ;OUTPUT:
13     ;
14     ;   R1 - BIT 15 SET TO PREVENT SENDING DATA TO DUP PROGRAM
15     ;   Z SET TO CONTINUE RUNNING DUP PROGRAM
16
17     INFO:  MOV -2(R4),R0      ;GET MESSAGE NUMBER
18           BEQ INFOB         ;IF ZERO, PRINT BEGUN MESSAGE
19           CMP R0,#100       ;IF OCTAL 100
20           BEQ INFOE         ;PRINT ERROR MESSAGE
21           CMP R0,#200       ;SEE IF 200 OR GREATER
22           BGE INFOH         ;IF SO, PRINT WITHOUT FREEZING
23           TST UFREEZ
24           BNE INFOF
25           INC UFREEZ
26
27     INFOH: CALL GTDRVT
28           MOV R0,R2
29           CALL HEADER
30           CALL MMSG         ;PRINT THE MESSAGE
31           MOV #BIT15,R1     ;RETURN A NEGATIVE BYTE COUNT
32           SEZ
33           RETURN           ;RETURN WITH Z SET
34
35     INFOE: ERRDF 101,,ERR101 ;ANSWER WAS REJECTED BY DUP PROGRAM
36
37           TRAP             C#ERDF
38           .WORD            101
39           .WORD            0
40           .WORD            ERR101
41
42     CLZ      ;RETURN WITH Z CLEAR TO STOP DUP PROGRAM
43     RETURN
44
45     INFOB: CALL GTDRVT         ;PRINT FORMAT BEGUN MESSAGE
46           MOV R0,R2
47           CALL HEADER
48           CALL MMSG
49           PNT WNSTOP         ;PRINT WARNING NOT TO STOP NOW
50
51           JSR R1,LPNT
52           .WORD WNSTOP
53           .WORD PNT.C*
54
55     BR INFOX

```

```
1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14 014502 004737 014354  
15 014506 000244  
16 014510 000207  
;MESSAGE TYPE ..  
;  
; TERMINATION MESSAGE  
;  
; INPUT:  
; R5 - POINTER TO CONTROLLER TABLE  
; R4 - POINTER TO DATA IN RECEIVE BUFFER  
; R3 - CHARACTER COUNT IN RECEIVE BUFFER  
; R2 - POINTER TO SEND BUFFER (BUFFER IS CLEARED)  
; R1 - ZERO  
; OUTPUT:  
; Z CLEAR TO TERMINATE DUP PROGRAM  
TERM: CALL INFO ;PRINT THE MESSAGE  
CLZ  
RETURN ;RETURN Z CLEAR TO TERMINATE DUP PROGRAM
```

```
1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14 014512 004737 014354  
15 014516 000244  
16 014520 000207  
;MESSAGE TYPE 5  
;ERROR TERMINATION MESSAGE  
;INPUT:  
; R5 - POINTER TO CONTROLLER TABLE  
; R4 - POINTER TO DATA IN RECEIVE BUFFER  
; R3 - CHARACTER COUNT IN RECEIVE BUFFER  
; R2 - POINTER TO SEND BUFFER (BUFFER IS CLEARED)  
; R1 - ZERO  
;OUTPUT:  
; Z CLEAR TO TERMINATE DUP PROGRAM  
ERRTRM: CALL INFO  
CLZ  
RETURN ;RETURN Z CLEAR TO TERMINATE DUP PROGRAM
```

```

1      ;MESSAGE TYPE 6
2
3      ;SPECIAL TYPE - READ FCT BLOCK FROM FILE
4
5      ;INPUT:
6      ;      R5  POINTER TO CONTROLLER TABLE
7      ;      R4  POINTER TO DATA IN RECEIVE BUFFER
8      ;      R3  CHARACTER COUNT IN RECEIVE BUFFER
9      ;      R2  POINTER TO SEND BUFFER (BUFFER IS CLEARED)
10     ;      R1  ZERO
11     ;OUTPUT:
12     ;      Z  SET TO SEND DATA TO PROGRAM
13
14 014522 023714 003204  SPECL:  CMP FCTNUM,(R4) ;SEE IF DESIRED BLOCK IS IN MEMORY
15 014526 001425          BEQ SPECLX   ; IF SO, SEND TO DUP PROGRAM
16 014530 002407          BLT SPECLR   ; IF LOWER NUMBERED BLOCK IN MEMORY,
17                                     ; GO READ NEXT BLOCK
18 014532          SPECLC:
19 014532          CLOSE   ;OTHERWISE, START READING FROM BEGINNING AGAIN
20 014534          OPEN  #FNAME
21 014542 012700 003232          MOV #1,FCTNUM
22 014540 104434          TRAP   C:CLOSE
23 014542 012737 177777 003204  SPECLR:  MOV #512,R3   ;GET BYTE COUNT IN A BLOCK
24 014550 012703 001000          MOV #FCTBUF,R1 ;POINT TO STORAGE AREA
25 014554 012701 002204          SPECLL: GETBYTE (R1). ;READ THE FILE
26 014560 104426          TRAP   C:GETB
27 014562 110021          MOV#   RO,(R1).
28 014564          BNCOMPLETE SPECLE ;PRINT ERROR IF NO MORE BYTES IN FILE
29 014566 005303          BCC   SPECLE
30 014566 005303          DEC R3 ;COUNT THE BYTES
31 014570 001373          BNE SPECLL
32 014572 005237 003204          INC FCTNUM ;KEEP COUNT OF BLOCK IN MEMORY
33 014576 000751          BR  SPECL
34
35 014600 005212          SPECLE:  INC (R2) ;TELL DUP PROGRAM DATA NOT AVAILABLE
36 014602 012762 002204 000002  SPECLX:  MOV #FCTBUF,2(R2) ;PUT ADDRESS OF DATA IN OUTPUT BUFFER
37 014610 012701 000006          MOV #6,R1 ;SEND 3 WORDS TO DUP PROGRAM
38 014614 000264          SEZ
39 014616 000207          RETURN ;RETURN WITH Z SET TO SEND DATA TO DUP PROGRAM
    
```

```

1      ;PRINT A MESSAGE IN THE RECEIVE BUFFER FROM THE DUP PROGRAM
2
3      ;INPUT:
4      ;      R4 - POINTER TO DATA IN RECEIVE BUFFER
5      ;      R3 - CHARACTER COUNT IN RECEIVE BUFFER
6
7      ;OUTPUT:
8      ;      R4 - POINTER TO CHARACTER AFTER MESSAGE IN RECEIVE BUFFER
9      ;      R3 - ZERO
10     ;      R1 - BIT 15 SET TO PREVENT SENDING DATA TO DUP PROGRAM
11     ;      R0 - CONTENTS DESTROYED
12     ;      Z SET TO CONTINUE RUNNING DUP PROGRAM
13     MSG:
14     014620 112400      18:      MOVB (R4),R0      ;PRINT CHARACTERS FROM DUP PROGRAM
15     014622 001405      BEQ 21      ; DISCARDING LF AND NULL CHARACTERS
16     014624 020027 000012      CMP R0,#12
17     014630 001402      BEQ 21
18     014632 004737 016054      PRINT R0
19     014636 005303      21:      DEC R3      ;COUNT THE CHARACTERS      CALL CPNT
20     014640 003367      BGT 18
21     014642 000015      PRINT @CR
22     014642 112700 000015      MOVB @CR,R0
23     014646 004737 016054      CALL CPNT
24     014652 000207      RETURN
    
```



```
1      ;GDRV1
2      ;
3      ;GET DRIVE TABLE ADDRESS FROM CONTROLLER TABLE
4      ;
5      ;INPUTS:
6      ;      R5 - CONTROLLER TABLE ADDRESS
7      ;
8      ;OUTPUTS:
9      ;      R0 - ADDRESS OF FIRST DRIVE TABLE AVAILABLE FOR TESTING
10     ;          (WITH DT.AVL BIT CLEAR)
11     ;
12     ;GDRV1: PUSH R5
13     ;
14     ;      ADD #C.DR0,R5
15     ;      MOV (R5),R0
16     ;      MOV D.UNIT(R0),L&LUN
17     ;      ASSUME DT.AVL EQ BIT15
18     ;      BMI GDRV1
19     ;      POP R5
20     ;
21     ;      MOV (SP),R5
22     ;
23     ;      RETURN
```

```

1      ;HEADER
2      ;
3      ;PRINT A HEADER IN FRONT OF EACH MESSAGE FROM DUP PROGRAM.
4      ;A UDA ADDRESS IS PRINTED IF MORE THAN ONE UDA IS IN HARDWARE P TABLE.
5      ;A RUNTIME IS PRINTED IF A CLOCK IS BEING USED TO TIME PROGRAM EXECUTION.
6      ;
7      ;INPUT:
8      ;   R5 - POINTER TO CONTROLLER TABLE
9      ;OUTPUT:
10     ;   R0 - POINTER TO DRIVE TABLE
11     ;   PRINTED MESSAGE
12     ;
13 014700 022737 000001 002012 HEADER: CMP #1,L#UNIT          ;IF MORE THAN ONE UNIT BEING TESTED
14 014706 001411                      BEQ 1#
15 014710 011246 000002 016226 PNTF MESSG,D.UNIT(R2),(R5),(R2) ;PRINT UDA ADDRESS
16     014710 011246                      MOV (R2), (SP)
17     014712 011546                      MOV (R5), -(SP)
18     014714 016246 000002                MOV D.UNIT(R2), (SP)
19     014720 004137 016226                JSR R1,LPNTF
20     014724 004027                      .WORD MESSG
21     014726 000006                      .WORD PNT.CT
22     014730                      ASSUME C.UADR EQ 0
23     014730                      ASSUME D.DRV FQ 0
24 014730 000407 000015 016054 BR 2#
25 014732 005737 003210 1#: TST KW.CSR          ;IF NO CLOCK BEING USED
26 014736 001406                      BEQ 3#          ;BYPASS RUNTIME MESSAGE
27     014740 112700 000015                PRINT #CR
28     014744 004737 016054                MOVB #CR,R0
29 014750 004737 020242 2#: CALL RNTIME          ;PRINT RUNTIME IF A CLOCK IN USE
30 014754 112700 000015 3#: PRINT #CR
31     014754 112700 000015                MOVB #CR,R0
32     014760 004737 016054                CALL CPNT
33 014764 000207                      RETURN
    
```

```

1      ;OSTRNG
2
3      ;FORMAT OF THE ASCIZ STRING IS AS FOLLOWS:
4
5      ;CHARACTERS ENCLOSED IN QUOTES ARE TO BE PRINTED AS THEY ARE.
6
7      ;OTHERWISE CODE IS A SINGLE LETTER FOLLOWED BY AN OPTIONAL DECIMAL
8      ;NUMBER:
9      ; ON - PRINT OCTAL NUMBER. N REPRESENTS SIZE OF BINARY NUMBER PASSED
10     ;      IN PARAMETER IN BITS. MAY BE IN RANGE 1 TO 32. IF N>16, TWO PARAMETER
11     ;      WORDS ARE USED, OTHERWISE ONLY ONE WORD. LEADING ZEROS ARE PRINTED.
12     ;      N IS ALWAYS SPECIFIED.
13     ; ON - PRINT UNSIGNED DECIMAL NUMBER FROM N BIT PARAMETER. LEADING ZEROS
14     ;      ARE NOT PRINTED. A 16 BIT NUMBER EQUAL TO ZERO WILL PRINT '0'.
15     ; MN - PRINT HEX NUMBER FROM PARAMETER OF N BITS. IF N>16 TWO PARAMETERS
16     ;      ARE USED, OTHERWISE ONLY ONE PARAMETER. LEADING ZEROS ARE PRINTED.
17     ; SN - PRINT N SPACES. N ASSUMED TO BE 1.
18     ; NF - START NEW LINE (CR-LF SEQUENCE). N ASSUMED TO BE 1.
19     ; AN - PRINT N ASCII CHARACTERS FROM PARAMETERS, N ASSUMED TO BE 1.
20     ;      N/2 PARAMETER WORDS USED.
21     ; RN - EXECUTE ROUTINE #N. N MUST BE GIVEN AND DEFINED IN HOST PROGRAM.
22
23     ;A NULL CHARACTER MEANS END OF MESSAGE. A NULL AS FIRST CHARACTER IN STRING
24     ;MUST BE IGNORED.
25
26     ;OUTPUT A MESSAGE ACCORDING TO A FORMAT STRING
27
28     ;INPUTS:
29     ;      R2 - ADDRESS OF START OF FORMAT STRING
30     ;      R4 - ADDRESS OF PARAMETERS
31     ;OUTPUTS:
32     ;      R2 AND R4 UPDATED TO END OF STRING AND PARAMETERS
33
34 014766 112201      OSTRNG: MOV8 (R2),R1      ;GET CONTROL CHARACTER
35 014770 001421      BEQ OSTRE      ;EXIT IF NULL CHARACTER
36 014772 012700 015266  MOV #ERRC,R0      ;GET POINTER TO CHARACTER TABLE
37 014776 120110      NCONS: CMPB R1,(R0)      ;COMPARE CHARACTER WITH TABLE ENTRY
38 015000 001407      BEQ NCONF      ;BRANCH IF MATCH FOUND
39 015002 105720      TSTB (R0),      ;INCREMENT POINTER
40 015004 001374      BNE NCONS      ;CONTINUE SEARCH IF NOT END OF TABLE
41 015006      PNTF ERRME1      ;REPORT BAD CONTROL CHARACTER
42      015006 004137 016226      JSR R1,LPNTF
43      015012 003740      .WORD ERRME1
44      015014 000000      .WORD PNT.CT
45 015016 000406      NCONF: BR OSTRE      ;GET INCREMENT INTO TABLE
46 015020 162700 015266  SUB #ERRC,R0      ;DOUBLE TO WORD COUNT
47 015024 006300      ASL R0
48 015026 004770 015300  CALL BERRD(R0)      ;DISPATCH TO PRINT ROUTINE
49 015032 000755      BR OSTRNG      ;GET NEXT
50 015034 000207      OSTRE: RETURN
    
```

```

1          ;CONTROL CHARACTER WAS A QUOTE. PRINT ALL CHARACTERS TO THE NEXT QUOTE.
2
3 015036 112200          CON.QU: MOVB (R2),R0          ;GET CHARACTER
4 015040 120027 000042  CMPB R0,' '          ;CHECK IF ENDING QUOTE
5 015044 001403          BEQ CON.QX          ;IF SO, GO GET NEXT CONTROL CHARACTER
6 015046          PRINT R0          ;PRINT THE CHARACTER
7 01504E 004737 016054          BR CON.QU          ;CONTINUE PRINTING          CALL CPNT
8 015052 000771          CON.QX: RETURN
9 015054 000207
10         ;CONTROL CHARACTER WAS AN A. PRINT ASCII CHARACTERS FROM PARAMETERS.
11
12 015056 004737 015534  CON.A: CALL GETCNT          ;GET COUNT OF CHARACTERS
13 015062          CON.A1: PRINT (R4).          ;PRINT THE CHARACTER
14 015064 112400          ;COUNT THE CHARACTERS          MOVB (R4),R0
15 015066 004737 016054          CALL CPNT
16 015070          DEC R1          ;PRINT UNTIL COUNT REACHES ZERO
17 015072          BNE CON.A1          ;CHECK IF R4 NOW ODD
18 015074 001373          BIT #1,R4
19 015076 032704 000001  BEQ CON.A2          ;IF SO, INCREMENT TO NEXT EVEN ADDRESS
20 015100          INC R4          ;NOW GET NEXT CONTROL CHARACTER
21 015102 005204          CON.A2: RETURN
22 015104 000207
23         ;CONTROL CHARACTER WAS A D. PRINT DECIMAL NUMBER.
24
25 015106 012701 000012  CON.D: MOV #10.,R1          ;LOAD RADIX
26 015112 004737 015612  CALL PNTNUM          ;PRINT NUMBER
27 015116 000207          RETURN          ;NOW GET NEXT CONTROL CHARACTER
28
29         ;CONTROL CHARACTER WAS AN H. PRINT HEX NUMBER.
30
31 015120 012701 000020  CON.H: MOV #16.,R1          ;LOAD RADIX
32 015124 004737 015612  CALL PNTNUM          ;PRINT NUMBER
33 015130 000207          RETURN          ;NOW GET NEXT CONTROL CHARACTER
    
```

```

1          ;CONTROL CHARACTER WAS AN O. PRINT OCTAL NUMBER.
2
3 015132 012701 000010      CON.O:  MOV #8.,R1          ;LOAD RADIX
4 015136 004737 015612      CALL PNTNUM          ;PRINT NUMBER
5 015142 000207              RETURN          ;NOW GET NEXT CONTROL CHARACTER
6
7          ;CONTROL CHARACTER WAS AN N. PRINT NEW LINE SEQUENCE.
8
9 015144 004737 015534      CON.N:  CALL GETCNT          ;GET COUNT
10 015150              CON.N1: PRINT #CR      ;PRINT NEW LINE SEQUENCE
11 015150 112700 000015      MOV #CR,R0          ;COUNT THE SEQUENCES
12 015154 004737 016054      CALL CPNT          ;NOW GET NEXT CONTROL CHARACTER
13 015160 005301              DEC R1
14 015162 001372              BNE CON.N1
15 015164 000207              RETURN
16
17          ;CONTROL CHARACTER WAS AN R. CALL A PRE-PROGRAMMED ROUTINE.
18
19 015166 004737 015534      CON.R:  CALL GETCNT          ;GET ROUTINE NUMBER
20 015172 020127 000010      CMP R1,#ERRRSZ      ;CHECK IF DEFINED ROUTINE NUMBER
21 015176 101004              BHI CON.R1
22 015200 060101              ADD R1,R1            ;DOUBLE COUNT TO GET WORD INDEX
23 015202 004771 015244      CALL BERRRTB 2(R1)  ;CALL ROUTINE
24 015206 000207              RETURN          ;NOW GET NEXT CONTROL CHARACTER
25 015210              CON.R1: PNTF ERRME1          ;REPORT BAD MESSAGE STRING
26 015210 004137 016226      JSR R1,L.PNTF
27 015214 003740              .WORD ERRME1
28 015216 000000              .WORD PNT.CT
29 015220              POP R1          ;FIX THE STACK
30 015220 012601              MOV (SP),R1
31 015222 000207              RETURN
32
33          ;CONTROL CHARACTER WAS AN S. PRINT SPACES.
34
35 015224 004737 015534      CON.S:  CALL GETCNT          ;GET COUNT
36 015230              CON.S1: PRINT '<0' >      ;PRINT A SPACE
37 015230 112700 000040      MOV # ,R0          ;COUNT THE SPACES
38 015234 004737 016054      CALL CPNT
39 015240 005301              DEC R1
40 015242 001372              BNE CON.S1
41 015244 000207              RETURN          ;NOW GET NEXT CONTROL CHARACTER

```

1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26

;ERROR ROUTINE DISPATCH TABLE

```

ERRRTB: .WORD CALRE      ;NOT USED
        .WORD CALRE      ;NOT USED
        .WORD CALRE      ;NOT USED
        .WORD CALR4      ;PRINT BASIC LINE WITHOUT UDA ADDRESS
        .WORD CALR5      ;PRINT BASIC LINE WITH UDA ADDRESS
        .WORD CALR6      ;CALL ALTERNATE PRINT STRING IN PDP-11 MEMORY
        .WORD CALR7      ;PRINT "REPLACE UDA MODULE M7485"
        .WORD CALR8      ;PRINT " UDA5A CONTAINS xxxxxx"
ERRRSZ=<<.-ERRRTB>>/2

```

```

;BUILD TWO TABLES
; FIRST CONTAINING CONTROL CHARACTERS
; SECOND CONTAINING ROUTINE ADDRESSES

```

```

.MACRO BUILD
ENTRY ".CON.QU
ENTRY A.CON.A
ENTRY D.CON.D
ENTRY H.CON.H
ENTRY O.CON.O
ENTRY N.CON.N
ENTRY R.CON.R
ENTRY S.CON.S

```

.ENDM

1  
2  
3  
4  
5  
6  
7  
8  
9 015266  
015266 042  
015267 101  
015270 104  
015271 110  
015272 117  
015273 116  
015274 122  
015275 123  
10 015276 000  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21 015300  
015300 015036  
015302 015056  
015304 015106  
015306 015120  
015310 0' '32  
015312 0' '144  
015314 0' '166  
015316 015224

;HERE IS FIRST TABLE  
.MACRO ENTRY ARG1,ARG2  
.LIST  
.BYTE ARG1  
.MLIST  
.ENDM  
ERRC: BUILD  
.BYTE  
.BYTE A  
.BYTE D  
.BYTE H  
.BYTE O  
.BYTE N  
.BYTE R  
.BYTE S  
.BYTE O  
.EVEN

;FOLLOW WITH A NULL BYTE

;HERE IS SECOND TABLE  
.MACRO ENTRY ARG1,ARG2  
.LIST  
.WORD ARG2  
.MLIST  
.ENDM  
ERRD: BUILD  
.WORD CON.QU  
.WORD CON.A  
.WORD CON.D  
.WORD CON.H  
.WORD CON.O  
.WORD CON.N  
.WORD CON.R  
.WORD CON.S

1  
2  
3

;PRE-PROGRAMMED ROUTINES 1, 2 AND 3  
;NOT USED PRINTS ERROR MESSAGE

4 015320  
015320 004137 016226  
015324 003740  
015326 000000  
5 015330 000207

CALRE: PNTF ERRMEI

;PRINT ERROR MESSAGE

JSR R1,LPNTF  
.WORD ERRMEI  
.WORD PNT,CT

RETURN



```

1      ;PRE-PROGRAMMED ROUTINE 4
2      ;PRINT BASIC LINE FOR HOST PROGRAM ERROR WITHOUT UDA ADDRESS
3      ;THEN SWITCH TO EXTENDED FORMAT
4
5      CALR4:  PNTB BASLN,@BASNO,@BAS,@BAS,@BAS
6
7      MOV @BAS,-(SP)
      MOV @BAS,-(SP)
      MOV @BAS,-(SP)
      MOV @BASNO,(SP)
      JSR R1,LPNTB
      .WORD BASLN
      .WORD PNT,CT
8
9      CALL RNTIME
      PRINT @CR
10     MOV @PX,PTYPE
11     RETURN
12
13     MOV @CR,RC
14     CALL @PNT

```

```

5 015332 012746 004223
015336 012746 004223
015342 012746 004223
015346 012746 004150
015352 004137 016236
015356 004224
015360 000010
6 015362 004737 020242
7 015366
015366 112700 000015
015372 004737 016054
8 015376 012737 016154 003224
9 015404 000207

```

```
1 ;PRE PROGRAMMED ROUTINE 5
2 ;PRINT BASIC LINE FOR MOST PROGRAM ERROR WITH UDA ADDRESS
3 ;THEN SWITCH TO EXTENDED FORMAT
4
5 CALRS: PNTB BASLN,@BASNO,@BASL2,(R5),@BAS,@BAS
        MOV @BAS,-(SP)
        MOV @BAS,-(SP)
        MOV (R5),-(SP)
        MOV @BASL2,(SP)
        MOV @BASNO,-(SP)
        JSR R1,LPNTB
        .WORD BASLN
        .WORD PNT,CT
6 015406 012746 004223
   015406 012746 004223
   015412 012746 004223
   015416 011546
   015420 012746 004167
   015424 012746 004150
   015430 004137 016236
   015434 004224
   015436 000012
7 015440 004737 020242      CALL RNTIME
   015444      PRINT @CR
   015444 112700 000015
   015450 004737 016054
8 015454 012737 016154 003224      MOV @PX,PTYPE
9 015462 000207      RETURN
        MOV @CR,R0
        CALL CPNT
```

```

1
2
3
4 015464          ;PRE PROGRAMMED ROUTINE 6
   015464 010246  ;CALL ALTERNATE PRINT ROUTINE IN PDP 11 MEMORY
5 015466 012402
6 015470 004737 014766 CALR6. PUSH R2          ;SAVE CURRENT STRING POINTER
   015474          MOV R2, (SP)
   015474 012602  ;GET NEW STRING POINTER
   015476 000207  ;OUTPUT USING THIS STRING
   ;GET OLD POINTER BACK
   MOV (SP),R2
   ;NOW CONTINUE THE OLD STRING
7 015474
8 015476          RETURN

```

```
1  
2  
3  
4 015500  
   015500 010246  
5 015502 012702 011357  
6 01550E 004737 014766  
7 015512  
   015512 012602  
8 015514 000207  
  
;PRE-PROGRAMMED ROUTINE 7  
;PRINT "REPLACE UDA MODULE M7485"  
  
CALR7.  PUSH R2  
  
        MOV R2, (SP)  
  
        MOV @XFRU,R2  
        CALL OSTRNG  
        POP R2  
  
        MOV (SP),R2  
  
        RETURN
```

Jr3

```
1  
2  
3  
4 015516          ;PRE-PROGRAMMED ROUTINE 8  
   015516 010246 ;PRINT ' UDASA CONTAINS "XXXXXX"  
5 015520 012702 011326  
6 015524 004737 014766  
   015530          CALRB. PUSH R2  
   015530          MOV #XSA,R2  
   015530          CALL OSTRNG  
   015530          POP R2  
8 015532 000207   MOV (SP),R2  
   015532          RETURN
```



```

1      ;PNTNUM
2      ;
3      ;PRINT A NUMBER
4      ;
5      ;INPUTS:
6      ;      R1  RADIX OF NUMBER
7      ;      R2  ASCII STRING TO COUNT OF BITS IN NUMBER
8      ;      R4  POINTER TO NUMBER (LOW WORD)
9      ;OUTPUTS:
10     ;      NUMBER IS PRINTED. LEADING ZEROS ARE PRINTED EXCEPT FOR
11     ;      DECIMAL NUMBERS.
12     ;      R0  CONTENTS DESTROYED
13
14 015612 010100      PNTNUM: MOV R1,R0          ;SAVE RADIX
15 015614 004737 015534      CALL GETCNT        ;GET COUNT OF BITS
16 015620      015620 010246      PNTNUS: PUSH <R2,R3,R5>
17 015622      015622 010346      ;MOV R2,(SP)
18 015624      015624 010546      ;MOV R3,(SP)
19 015626      012403      MOV (R4),R3        ;GET ONE PARAMETER WORD
20 015630      005005      CLR R5            ;CLEAR STORAGE FOR OTHER
21 015632      020127 000020      CMP R1,#16.      ;MORE THAN 16 BITS IN NUMBER?
22 015636      003401      BLE 18
23 015640      012405      MOV (R4),R5        ;YES, GET SECOND PARAMETER WORD
24 015642      015642 010446      18:  PUSH R4
25 015644      010504      ;MOV R4,(SP)
26 015646      012702 000020      MOV R5,R4        ;PUT HIGH WORD IN R4
27 015652      160102      MOV #16.,R2      ;COMPUTE BITS NOT WANTED
28 015654      002002      SUB R1,R2        ;BY SUBTRACTING BITS TO USE
29 015656      062702 000020      BGE 28          ;FROM 16.
30 015662      001414      ADD #16.,R2      ;IF NEGATIVE, ADD 16 FOR FIRST WORD
31 015664      012705 100000      28:  BEQ 68          ;IF ZERO, NO BITS NEED BE CLEARED
32 015670      005302      MOV #BIT15,R5   ;START MASK WITH SIGN BIT SET
33 015672      001402      38:  DEC R2          ;COUNT BITS IN MASK
34 015674      006205      BEQ 48
35 015676      000774      ASR R5          ;SHIFT MORE BITS TO RIGHT
36 015700      020127 000020      BR 38
37 015704      003402      48:  CMP R1,#16.      ;MORE THAN 16 BITS IN NUMBER?
38 015706      040504      BLE 58
39 015710      000401      BIC R5,R4       ;YES, CLEAR IN HIGH WORD
40 015712      040503      BR 68
41 015714      004737 016332      58:  BIC R5,R3       ;NO, CLEAR IN LOW WORD
42 015720      010546      68:  CALL DIVIDE     ;DIVIDE BY RADIX IN R0
43 015722      005202      PUSH R5         ;PUSH REMAINDER ON STACK
44 015724      005703      ;MOV R5,(SP)
45 015726      001372      INC R2          ;COUNT DIGITS ON STACK
46 015730      005704      TST R3          ;CHECK IF QUOTIENT IS ZERO
47 015732      001370      BNE 68
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95

```

1	015734	020027	000012		CMP R0,#10.		; IF RADIX IS DECIMAL
2	015740	001423			BEQ 10:		; JUST GO PRINT DIGITS ON STACK
3	015742	010103			MOV R1,R3		; OTHERWISE COMPUTE NUMBER OF LEADING ZEROS
4	015744	162700	000014		SUB #12.,R0		; DIVIDEND IS BITS IN NUMBER
5	015750	003002			BGT 7:		; DIVISOR IS BITS PER DIGIT PRINTED
6	015752	012700	000003		MOV #3,R0		; (3 OR 4)
7	015756	004737	016332	7:	CALL DIVIDE		
8	015762	005705			TST R5		; IF REMAINDER NOT ZERO
9	015764	001401			BEQ 8:		; INCREMENT QUOTIENT
10	015766	005203			INC R3		
11	015770	160203		8:	SUB R2,R3		; SUBTRACT DIGITS ON STACK
12	015772	001406			BEQ 10:		; NO LEADING ZEROS IF ZERO
13	015774			9:	PRINT #'0		; PRINT A ZERO
	015774	112700	000060				MOV #0,R0
	016000	004737	016054				CALL CPNT
14	016004	005303			DEC R3		
15	016006	001372			BNE 9:		; REPEAT UNTIL COUNT REACHES ZERO
16							
17	016010			10:	POP R5		; GET CHARACTER FROM STACK
	016010	012605					MOV (SP),R5
18	016012	062705	000060		ADD #'0,R5		; CONVERT TO ASCII DIGIT
19	016016	020527	000071		CMP R5,#'9		; IF GREATER THAN A 9
20	016022	003402			BLE 11:		; CONVERT TO A OR HIGHER
21	016024	062705	000007		ADD #'A-'9 1,R5		; FOR HEX DIGIT
22	016030			11:	PRINT R5		; PRINT THE CHARACTER
	016030	110500					MOV R5,R0
	016032	004737	016054				CALL CPNT
23	016036	005302			DEC R2		; REPEAT FOR ALL DIGITS
24	016040	001363			BNE 10:		; ON STACK
25	016042				POP <R4,R5,R3,R2>		
	016042	012604					MOV (SP),R4
	016044	012605					MOV (SP),R5
	016046	012603					MOV (SP),R3
	016050	012602					MOV (SP),R2
26	016052	000207			RETURN		



```

1      ;PRINT ONE CHARACTER
2
3      ;CALL WITH MACRO PRINT
4
5 016054 110037 003226      CPNT:  MOV B R0,ERRCHR
6 016060 010146 000000      PUSH R1
7 016062 012701 003676      MOV @ERRONE,R1
8 016066 120027 000015      CMP B R0,@CR
9 016072 001002 000000      BNE 1$
10 016074 012701 003701      MOV @ERRNL,R1
11 016100 000177 165120      1$:  JMP @PTYPE
12 016104 012746 003226      PF:  PRINTF R1,@ERRCHR
13 016126 000435 000006      BR CPNTX
14 016130 012746 003226      PB:  PRINTB R1,@ERRCHR
15 016152 000423 000006      BR CPNTX
16 016154 012746 003226      PX:  PRINTX R1,@ERRCHR
17 016176 000411 000006      BR CPNTX
18 016200 012746 003226      PS:  PRINTS R1,@ERRCHR
19 016222 012601 000000      CPNTX: POP R1
20 016224 000207 000000      RETURN

```

```

MOV R1, (SP)

MOV @ERRCHR, -(SP)
MOV R1, (SP)
MOV @2, (SP)
MOV SP, R0
TRAP C$PNTF
ADD @6, SP

MOV @ERRCHR, (SP)
MOV R1, -(SP)
MOV @2, -(SP)
MOV SP, R0
TRAP C$PNTB
ADD @6, SP

MOV @ERRCHR, (SP)
MOV R1, -(SP)
MOV @2, -(SP)
MOV SP, R0
TRAP C$PNTX
ADD @6, SP

MOV @ERRCHR, (SP)
MOV R1, (SP)
MOV @2, -(SP)
MOV SP, R0
TRAP C$PNTS
ADD @6, SP

MOV (SP), R1

```

```

1          ;PRINT FORMATTED MESSAGE
2
3          ;CALL WITH MACRO PNT, PNTI, PNTB, PNTX, OR PNTS
4
5 016226 012737 016104 003224 LPNTF: MOV @PF,PTYPE
6 016234 000413                BR LPNT
7 016236 012737 01613C 003224 LPNTB: MOV @PB,PTYPE
8 016244 000407                BR LPNT
9 016246 012737 016154 003224 LPNTX: MOV @PX,PTYPE
10 016254 000403                BR LPNT
11 016256 012737 016200 003224 LPNTS: MOV @PS,PTYPE
12 016264                LPNT:  PUSH <R2,R3,R4,R5>
13 016264 010246                MOV R2, (SP)
14 016266 010346                MOV R3, (SP)
15 016270 010446                MOV R4, (SP)
16 016272 010546                MOV R5, (SP)
17 016274 012102                MOV (R1),R2
18 016276 010604                MOV SP,R4
19 016300 062704 000012        ADD #10.,R4
20 016304                PUSH R1
21 016304 010146                MOV R1, (SP)
22 016306 004737 014766        CALL OSTRING
23 016312                POP <R0,R5,R4,R3,R2,R1>
24 016312 012600                ;PRINT THE FORMATTED MESSAGE
25 016314 012605                ;RESTORE ALL REGISTERS
26 016316 012604                MOV (SP),R0
27 016320 012603                MOV (SP),R5
28 016322 012602                MOV (SP),R4
29 016324 012601                MOV (SP),R3
30 016326 062006                MOV (SP),R2
31 016330 000110                MOV (SP),R1
32                ADD (R0),SP
33                JMP @R0
34                ;ADJUST STACK POINTER OVER ARGUMENTS
35                ;RETURN
    
```

```

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16 016332
17 016332 010246
18 016334 012702 000040
19 016340 005005
20 016342 006303
21 016344 006104
22 016346 006105
23 016350 020005
24 016352 101002
25 016354 160005
26 016356 005203
27 016360 005302
28 016362 001367
29 016364 012602
    016366 000207

```

```

;DIVIDE
;
;DIVIDE A 32 BIT UNSIGNED NUMBER BY A 16 BIT UNSIGNED NUMBER.
;REPLACE DIVIDEND WITH QUOTIENT AND RETURN REMAINDER.
;WILL NOT CHECK FOR DIVIDE BY ZERO.
;
;INPUTS:
;   R3  LOW 16 BITS OF DIVIDEND
;   R4  HIGH 16 BITS OF DIVIDEND
;   R0  DIVISOR
;
;OUTPUTS:
;   R3  LOW 16 BITS OF QUOTIENT
;   R4  HIGH 16 BITS OF QUOTIENT
;   R5  REMAINDER
;
DIVIDE: PUSH R2
;
;SET UP SHIFT COUNT
MOV R2, (SP)
;START WITH ZERO REMAINDER
;SHIFT LEFT INTO R5
MOV #32, R2
CLR R5
18: ASL R3
    ROL R4
    ROL R5
;WILL DIVISOR GO INTO REMAINDER
;ONLY SUBTRACT IF IT WILL
;SUBTRACT DIVISOR
;PUT A ONE INTO QUOTIENT
;COUNT THE SHIFTS
CMP R0, R5
BHI 28
SUB R0, R5
INC R3
28: DEC R2
    BNE 18
    POP R2
;
    MOV (SP), R2
;
    RETURN

```

```

1      ;L0ADDM
2      ;
3      ;LOAD AND START A DM PROGRAM INTO A CONTROLLER
4      ;
5      ;INPUTS:
6      ;   R5 - CONTROLLER TABLE ADDRESS
7      ;   DMPROG - POINTER TO START OF DM PROGRAM IN MEMORY
8      ;OUTPUTS:
9      ;   IF LOAD SUCCEEDS - Z CLEAR
10     ;   CONTROLLER TABLE MARKED LOADED
11     ;   IF ERROR - Z SET
12     ;
13     016370 013701 002164      ;L0ADDM: MOV DMPROG,R1          ;GET STORAGE ADDRESS OF DM PROGRAM
14     016374 116165 000021      000044      MOVB DMTMO(R1),C.TOT(R5)      ;GET TIMEOUT VALUE
15     016402 105065 000045      CLR B C.TOT+1(R5)
16     016406 016504 000004      MOV C.VEC(R5),R4           ;GET VECTOR OF UDA
17     016412      AND CT.VEC,R4
18     016412 042704 177000      MOV R5,R1                 BIC #C-CT.VEC,R4
19     016416 010501      MOV R5,R1                 ;GET INTERRUPT SERVICE LINK
20     016420 062701 000010      ADD #C.JSR,R1
21     016424      SETVEC R4,R1,#PRI07      ;SET UP INTERRUPT VECTOR
22     016424 012746 000340      MOV #PRI07,(SP)
23     016430 010146      MOV R1,(SP)
24     016432 010446      MOV R4,(SP)
25     016434 012746 000003      MOV #3,(SP)
26     016440 104437      TRAP C$VEC
27     016442 062706 000010      ADD #10,SP
28     ;INITIALIZE UDA WITH SMALLEST
29     ;PING BUFFER AND INTERRUPTS ENABLED
30     ;BRANCH IF AN ERROR
31     016446 004737 017250      CALL UDAINIT
32     016452 001444      BEQ LOADER
    
```

1	016454	012700	000002	MOV #OP.ESP,R0	;BUILD EXECUTE SUPPLIED PROGRAM COMMAND PACKET
2	016460	004737	016570	CALL BLUCHD	
3	016464	013764	002164 000124	MOV DMPROG,HC.CPK.P.UADR(R4)	;LOAD MAIN PROGRAM ADDRESS
4	016472	017764	163466 000120	MOV BDMPROG,HC.CPK.P.BCNT(R4)	; AND SIZE
5	016500	013764	002164 000140	MOV DMPROG,HC.CPK.P.OVRI(R4)	;LOAD OVERLAY ADDRESS
6	016506	0E7764	163452 000140	ADD BDMPROG,HC.CPK.P.OVRL(R4)	
7	016514	004737	016654	CALL SNOCHD	;SEND COMMAND TO UDA
8	016520	004737	016774	CALL WAITMS	;WAIT FOR MESSAGE RESPONSE
9	016524	001417		BEG LOADER	;ABORT IF NO RESPONSE
10	016526	032764	000037 000032	BIT #ST,MSK,HC.MPK.P.STS(R4)	;CHECK FOR ERRORS
11	016534	001007		BNE LOADE1	
12	016536	042765	000024 000014	BIC #CT.CMD.CT.REQ,C.FLG(R5)	;CLEAR COMMAND OUTSTANDING FLAG
13	016544	052765	000002 000014	BIS #C*.RN,C.FLG(R5)	;SET DM PROGRAM RUNNING FLAG
14	016552	000207		RETURN	

1  
2  
3 016554  
016554 104455  
016556 000042  
016560 000000  
016562 012234  
4 016564 000264  
5 016566 000207

UDA FAILED TO DOWNLINE LOAD DM PROGRAM  
LOADE1: ERRDF 34,,ERR034

LOADER: SEZ  
RETURN

TRAP CERRDF  
.WORD 34  
.WORD 0  
.WORD ERR034  
;SET 2 TO INDICATE ERROR OCCURRED

```

1      ;BLDCMD
2      ;
3      ;BUILD A COMMAND IN COMMAND PACKET
4      ;
5      ;INPUTS:
6      ;   R5 - CONTROLLER TABLE ADDRESS
7      ;   R0  COMMAND CODE
8      ;
9      ;OUTPUTS:
10     ;   R4  ADDRESS OF HOST COMM AREA
11     ;   COMMAND PACKET CONTAINING REF NUMBER AND OPCODE, ALL OTHER FIELDS CLEARED.
12     ;   CMD REFERENCE NUMBER IN CONTROLLER TABLE INCREMENTED AND RESULT
13     ;   IN COMMAND PACKET.
14     ;   R0  CONTENTS DESTROYED
15
16 016570      BLDCMD: PUSH <R1,R0>
17 016570      010146
18 016572      010046
19 016574      016504      000016
20 016600      010400
21 016602      062700      000100
22 016606      012720      000060
23 016612      012701      001000
24 016616      022716      000031
25 016622      001002
26 016624      012701      177777
27 016630      010120
28 016632      012701      000030
29 016636      005020
30 016640      005301
31 016642      001375
32 016644      012664      000114
33 016650      012601
34 016652      000207

```

```

;BLDCMD:
;BUILD A COMMAND IN COMMAND PACKET
;INPUTS:
;   R5 - CONTROLLER TABLE ADDRESS
;   R0  COMMAND CODE
;OUTPUTS:
;   R4  ADDRESS OF HOST COMM AREA
;   COMMAND PACKET CONTAINING REF NUMBER AND OPCODE, ALL OTHER FIELDS CLEARED.
;   CMD REFERENCE NUMBER IN CONTROLLER TABLE INCREMENTED AND RESULT
;   IN COMMAND PACKET.
;   R0  CONTENTS DESTROYED
BLDCMD: PUSH <R1,R0>
;GET ADDRESS OF HOST COMM AREA
;COPY TO R0
;COMPUTE ADDRESS OF COMMAND ENVELOPE
;LOAD PACKET LENGTH
;LOAD DIAG CIRCUIT IDENTIFIER
;IF CODE IS MAINTENANCE WRITE
; GET OTHER CIRCUIT IDENTIFIER
MOV R1, -(SP)
MOV R0, (SP)
MOV C,RING(R5),R4
MOV R4,R0
ADD #HC.CEV,R0
MOV #HC.PSZ,(R0)
MOV #DUP,R1
CMP #OP.MWR,(SP)
BNE BLDC0
MOV #DIAG,R1
BLDC0: MOV R1,(R0)
;PUT IDENTIFIER INTO PACKET
;GET WORDS TO CLEAR
BLDC1: CLR (R0)
;CLEAR PACKET
DEC R1
BNE BLDC1
POP HC.CPK+P.OPCD(R4)
;PUT OPCODE IN PACKET
POP R1
;RESTORE R1
MOV (SP),HC.CPK+P.OPCD(R4)
MOV (SP),R1
RETURN

```

```

1      ;SNDCMD
2
3      ; SEND A COMMAND TO THE UDA.
4      ; MARK BOTH PACKETS AVAILABLE TO THE
5      ; UDA. SET COMMAND ISSUED BIT IN CONTROLLER TABLE AND INITIALIZE
6      ; TIMEOUT COUNTER.
7
8      ;
9      ; INPUTS:
10     ; R5  CONTROLLER TABLE ADDRESS
11     ; OUTPUTS:
12     ; R4  ADDRESS OF HOST COMM AREA
13
14     SNDCMD: PUSH <R0,R1>
15     016654      010046      MOV R0, (SP)
16     016656      010146      MOV R1, (SP)
17     016660      016504      000016      MOV C.RING(R5),R4      ;LOAD R4 WITH HOST COMM AREA ADDRESS
18     016664      005265      000052      INC C.REF(R5)          ;INCREMENT CMD REFERENCE NUMBER
19     016670      016564      000052      000104      MOV C.REF(R5),HC.CPK.P.CRF(R4) ;PUT IN PACKET
20     016676      012764      140000      000006      MOV @RG.OWN+RG.FLG,HC.MCT(R4) ;MARK MESSAGE PACKET AVAILABLE
21     016704      012764      100000      000012      MOV @RG.OWN,HC.CCT(R4)   ;MARK COMMAND TO UDA
22     016712      005775      000000      TST @C(R5)             ;TELL UDA COMMAND IS THERE
23     016716      052765      000004      000014      BIS @CT.CMD,C.FLG(R5)   ;MARK COMMAND ISSUED
24     016724      012601
25     016726      012600
26     016730      000207      RETURN
27
28     MOV (SP)+,R1
29     MOV (SP)+,R0
    
```



```

1      : CLRBUF
2      :
3      : CLEAR THE SPECIFIED DATA BUFFER IN THE HOST COMM AREA
4      : AND LOAD BUFFER DESCRIPTOR IN COMMAND PACKET TO THE BUFFER
5      :
6      : INPUTS:
7      :     R5  CONTROLLER TABLE ADDRESS
8      :     R4  ADDRESS OF HOST COMM AREA
9      :     R0  OFFSET INTO HOST COMM AREA TO DATA BUFFER
10     : OUTPUTS:
11     :     DATA BUFFER CLEARED
12     :     COMMAND PACKET POINTING TO BUFFER
13     :     BYTE COUNT SET TO SIZE OF BUFFER
14     :     R4 - ADDRESS OF DATA BUFFER
15
16 016732 CLRBUF: PUSH <R0,R1>
17 016732 010046
18 016734 010146
19 016736 060400
20 016740 010064 000124
21 016744 012764 000244 000120
22 016752 010004
23 016754 012701 000122
24 016760 005020
25 016762 005301
26 016764 001375
27 016766 012601
28 016770 012600
29 016772 000207
    
```

```

    ADD R4,R0
    MOV R0,HC.CPK.P.UADR(R4)
    MOV #HC.BSZ,HC.CPK.P.BCNT(R4)
    MOV R0,R4
    MOV #HC.BSZ/2,R1
    CLR (R0)
    DEC R1
    BNE CLRBFL
    POP <R1,R0>
    RETURN
    
```

```

    MOV R0,-(SP)
    MOV R1,(SP)
    ;ADD START OF HOST COMM AREA TO OFFSET
    ;PUT BUFFER ADDRESS IN COMMAND PACKET
    ;PUT SIZE OF BUFFER IN COMMAND PACKET
    ;PUT BUFFER ADDRESS IN R4
    ;GET SIZE OF BUFFER IN WORDS
    ;CLEAR ALL THE WORDS
    MOV (SP),R1
    MOV (SP),R0
    
```

```

1      ;WAITMS
2      ;
3      ;WAIT FOR UDA TO RESPOND WITH A MESSAGE PACKET
4      ;
5      ;INPUTS:
6      ;      R5 - ADDRESS OF CONTROLLER TABLE
7      ;
8      ;OUTPUTS:
9      ;      Z CLEAR IF NO ERROR
10     ;      Z SET IF ERROR, MESSAGE PRINTED
11     016774      ;WAITMS: PUSH <R0,R1>
12     016774      010046      MOV R0, (SP)
13     016776      010146      MOV R1, (SP)
14     017000      012700      000036      MOV #30, R0      ;SET TIME OUT VALUE OF 30 SECONDS
15     017004      010501      MOV R5, R1      ;POINT TO TIME OUT COUNTER
16     017006      062701      000040      ADD #C.TO, R1
17     017012      004737      017166      CALL SETTO
18     017016      011500      18:      MOV (R5), R0      ;GET ADDRESS OF UDAIP REGISTER
19     017020      032765      000010      000014      BIT #CT.MSG.C.FLG(R5)      ;LOOK IF INTERRUPT OCCURRED
20     017026      001030      BNE 38      ;BRANCH IF SO
21     017030      016001      000002      MOV 2(R0), R1      ;LOOK AT UDASA REGISTER
22     017034      001034      BNE 48      ;BRANCH IF ERROR CODE PRESENT
23     017036      104422      BREAK
24     017040      005737      003210      TST KW.CSR      TRAP C8BRK      ;SEE IF A CLOCK ON SYSTEM
25     017044      001764      BEQ 18
26     017046      023765      003222      000042      CMP KW.EL+2,C.TOM(R5)      ;CHECK IF TIMEOUT HAS HAPPENED
27     017054      101005      BHI 28
28     017056      001357      BNE 18
29     017060      023765      003220      000040      CMP KW.EL.C.TO(R5)
30     017066      103753      BLO 18
31     017070      28:      ERROF 36, .ERR036
32     017070      104455      TRAP C8ERDF
33     017072      000044      .WORD 36
34     017074      000000      .WORD 0
35     017076      012242      .WORD ERRO36
36     017100      POP <R1,R0>
37     017100      012601      MOV (SP)+, R1
38     017102      012600      MOV (SP)+, R0
39     017104      000264      SEZ
40     017106      000207      RETURN
    
```

1	017110	042765	000010	000014	31:	BIC @CT.MSG.C.FLG(R5)	;CLEAR MESSAGE RECEIVED FLAG	
2	017116					POP <R1,R0>		MOV (SP),R1
	017116	012601						MOV (CP),R1
	017120	012600						
3	017122	000244				CLZ	;GIVE NO ERROR RETURN	
4	017124	000207				RETURN		
5	017126				41:	ERRDF 37,,ERR037		
	017126	104455						TRAP CERRDF
	017130	000045						.WORD 37
	017132	000000						.WORD 0
	017134	012254						.WORD ERR037
6	017136					POP <R1,R0>		
	017136	012601						MOV (SP),R1
	017140	012600						MOV (SP),R0
7	017142	000264				SEZ		
8	017144	000207				RETURN		

```
1      ;NXMI
2      ;
3      ;NON-EXISTANT MEMORY SERVICE ROUTINE
4      ;
5      ;INPUTS:
6      ;      NXMAD SET TO ZERO
7      ;OUTPUTS:
8      ;      NXMAD SET TO ONES IF NON EXISTANT TRAP OCCURED
9
10     017146      BGNSRV NXMI
11     017146
12     017146      012737 177777 002200      MOV @ 1,NXMAD
13
14     017154      ENDSRV
15     017154
16     017154      000002
```

NXMI::  
  
L10031: RTI

```

1      ;UDASRV
2      ;
3      ;UDA INTERRUPT SERVICE ROUTINE. MARKS UDA CONTROLLER TABLE THAT AN
4      ;INTERRUPT HAS BEEN RECEIVED.
5      ;
6      ;THIS ROUTINE IS CALLED BY A (JSR R0,UDASRV) INSTRUCTION FROM WITHIN
7      ;THE CONTROLLER TABLE. THE PC STORED IN R0 IS THE ADDRESS OF THE C.FLG
8      ;WORD IN THE CONTROLLER TABLE. THE STACK CONTAINS THE SAVED CONTENTS
9      ;OF R0 FOLLOWED BY THE INTERRUPTED PC AND PS.
10     ;
11     ;INPUTS:
12     ;   R0 - ADDRESS OF C.FLG WORD IN CONTROLLER TABLE
13     ;   STACK  SAVED CONTENTS OF R0
14     ;OUTPUTS:
15     ;   CT.CMD CLEARED AND CT.MSG SET IN C.FLG WORD OF CONTROLLER TABLE
16     ;   R0  RESTORED FROM STACK
17
18     BGNSRV UDASRV
19     017156      052710  000010      BIS #CT.MSG,(R0)      ;SET CT.MSG
20     017162      012600                      POP R0                ;RESTORE R0
21     017164
22     017164
23     017164      000002
24
25     ENDSRV
26
27     UDASRV::
28
29     L10032:
30     RTI
31
32     MOV (SP),R0
    
```

```

1      ;SETTO
2
3      ;SET TIMEOUT COUNTER TO SOME NUMBER OF SECONDS FROM CURRENT TIME.
4
5      ;INPUTS:
6      ;      R0 - NUMBER OF SECONDS FOR TIMEOUT
7      ;      R1 - ADDRESS WHERE TWO WORD TIME TO BE PUT
8
9      ;OUTPUTS:
10     ;      R0 - CONTENTS DESTROYED
11     ;      R1 - INCREMENTED BY 2
12
13     ;COMPUTE CLOCK TICKS TIL TIMEOUT
14     SETTO:  PUSH <R2,R3>
15             MOV R2,(SP)
16             MOV R3,(SP)
17
18             CLR R2
19             MOV KW,HZ,R3
20             ;CLEAR PRODUCT
21             ;GET MULTIPLICAND
22             ;SHIFT MULTIPLIER TO RIGHT
23             ;IF A ONE BIT SHIFTED OUT
24             ; ADD MULTIPLICAND TO PRODUCT
25             ;DOUBLE THE MULTIPLICAND
26
27             SET00:  ASR R0
28                     BCC SET01
29                     ADD R3,R2
30                     ;CONTINUE UNTIL MULTIPLIER IS ZERO
31
32             SET01:  ASL R3
33                     TST R0
34                     BNE SET00
35
36             ;GET CURRENT TIME
37
38             SET02:  MOV KW,EL,R0
39                     MOV KW,EL+2,R3
40                     ;GET TIME
41                     CMP R0,KW,EL
42                     ;IF CHANGED DURING RETRIEVAL
43                     ; GET IT AGAIN
44
45             ;ADD TIME TIL TIMEOUT
46
47             ADD R2,R0
48             ADC R3
49             ;ADD
50
51             ;PUT RESULT IN STORAGE
52
53             MOV R0,(R1)
54             MOV R3,(R1)
55
56             POP <R3,R2>
57
58             MOV (SP),R3
59             MOV (SP),R2
60
61             RETURN
62
63     017166 010246
64     017170 010346
65     017172 005002
66     017174 013703 003216
67     017200 006200
68     017202 103001
69     017204 060302
70     017206 006303
71     017210 005700
72     017212 001372
73
74     017214 013700 003220
75     017220 013703 003222
76     017224 020037 003220
77     017230 001371
78
79     017232 060200
80     017234 005503
81
82     017236 010021
83     017240 010311
84
85     017242
86     017242 012603
87     017244 012602
88     017246 000207

```

```

1      ;UDAINI
2
3      ;
4      ;FUNCTIONAL DESCRIPTION:
5      ;   SUBROUTINE TO INITIALIZE A UDA AND BRING IT ON LINE.
6      ;   ALL STEPS ARE CHECKED. AN ERROR MESSAGE IS REPORTED IF ANY ERROR
7      ;   DETECTED.
8
9      ;
10     ;INPUTS:
11     ;   R5 - ADDRESS OF CONTROLLER TABLE.
12     ;IMPLICIT INPUTS:
13     ;   C.RING(R5) - ADDRESS GIVEN TO UDA AS START OF RING BUFFER.
14     ;   LENGTH OF RING STRUCTURE IS ONE ENTRY EACH.
15     ;OUTPUTS:
16     ;   CONDITION Z SET IF ANY ERROR REPORTED. CLEAR IF NO ERROR.
17     ;   R4 - ADDRESS OF UDAIP REGISTER IN UDA
18     ;   R5 - UNCHANGED.
19
20     ;FILL MOST COMMUNICATION AREA WITH ALL ONES
21
22     UDAINI: MOV C.RING(R5),R2                ;GET FIRST ADDRESS OF RING BUFFER
23             MOV #C.MC.RSZ*2+C.MC.ISZ>/2,R3    ;GET SIZE OF RING BUFFER
24     UDAI1L: MOV #-1,(R2)                    ;WRITE ONES TO BUFFER
25             DEC R3                            ;COUNT THE WORDS IN BUFFER
26             BGT UDAI1L                        ;LOOP UNTIL ENTIRE BUFFER WRITTEN
27
28     ;DO THE INITIALIZATION
29
30     CALL UDAIST                               ;DO FIRST THREE STEPS
31     BCS UDAIEX                               ;GET OUT IF UDA MICROCODE REPORTED FAILURE
32     MOV (R3),2(R4)                            ;WRITE NEXT WORD TO UDASA REGISTER
33     MOV #200,R3                               ;GET TRY COUNTER
34     UDAI1A: MOV 2(R4),R2                      ;LOOK AT UDASA
35             BEQ UDAI1C
36             BPL UDAI1B
37             ERROF 24,,ERR024
38
39             TRAP C8ERDF
40             .WORD 24
41             .WORD 0
42             .WORD ERR024
43
44     BR UDAIEX
45     UDAI1B: DEC R3
46             BNE UDAI1A
47     UDAI1C: MOV R2,2(R4)                      ;WRITE 0 TO UDASA (PURGE)
48             MOV (R4),R2                      ;READ FROM UDAIP (POLL)
49             CALL UDARSP                       ;WAIT FOR STEP OR ERROR BIT
50             BCS UDAIEX                       ;GET OUT IF UDA MICROCODE REPORTED FAILURE
51             MOV R2,R3                        ;GET COPY OF MODEL CODE
52             BIC #C<SA.CNT>,R3                ;CLEAR OTHER BITS
53             ASR R3                            ;MOVE TO RIGHT OF REGISTER
54             ASR R3
55             ASR R3
56             ASR R3
57             BIC #C<SA.MCV>,R2                ;MICROCODE VERSION IN R2
58             CMP R3,#6                        ;CONTROLLER MODEL MUST BE 6
59             BNE UDAI1D
60             CMP R2,#3                          ;MICROCODE VERSION MUST BE
61             BGE UDAI2                          ; 3 OR GREATER

```

54 017406  
017406 104455  
017410 000016  
017412 000000  
017414 011732  
55 017416 000444

UDAIID: ERRDF 14,,ERR014

BR UDAIEX

REPORT CONTROLLER NEEDS NEW REVISION  
TRAP C#ERRDF  
.WORD 14  
.WORD 0  
.WORD ERR014



```

1          ;CHECK MOST COMMUNICATION AREA FOR ALL ZEROS
2
3 017420 016502 000016      UDAI2:  MOV C.RING(R5),R2          ;GET FIRST ADDRESS OF RING BUFFER
4 017424 012703 000006      MOV @<MC.RSZ*2+MC.ISZ>/2,R3      ;GET SIZE OF RING BUFFER
5 017430 005722              UDAI2L: TST (R2)          ;CHECK WORD IN BUFFER
6 017432 001003              BNE UDAI2E          ;GO TO ERROR REPORTER IF NOT ZERO
7 017434 005303              DEC R3          ;COUNT THE WORDS IN BUFFER
8 017436 003374              BGT UDAI2L          ;LOOP UNTIL ALL WORDS CHECKED
9 017440 000405              BR UDAI3
10
11 017442              UDAI2E: ERRDF 23,,ERR023      ;REPORT BUFFER NOT CLEARED
12 017442 104455              TRAP CSEDF
13 017444 000027              .WORD 23
14 017446 000000              .WORD C
15 017450 012044              .WORD ERR023
16 017452 000426              BR UDAIEX
17
18          ;SEND GO BIT TO UDASA REGISTER TO END INITIALIZATION
19
20 UDAI3:
21 MOV C.BST(R5),R0          ;GET BURST VALUE
22 ASL R0                    ;SHIFT TO POSITION
23 ASL R0
24 BIS @SA.GO,R0            ;SET THE GO BIT
25 MOV R0,2(R4)              ;SEND TO UDA
26 MOV C.RING(R5),R1
27 MOV R1,MC.MSG(R1)
28 ADD @MC.MPK,MC.MSG(R1)
29 MOV R1,MC.CMD(R1)
30 ADD @MC.CPK,MC.CMD(R1)
31 CLZ                        ;CLEAR Z AS NO ERROR INDICATION
32 RETURN
33
34          ;ERROR RETURN
35
36 UDAIEX: SEZ                ;SET Z TO INDICATE ERROR OCCURRED
37 RETURN
    
```

```

1      ;UDAIST
2      ;
3      ; START THE INITIALIZATION PROCESS ON THE SELECTED UDA.
4      ; STOP BEFORE WRITING THE THIRD WORD SO UDA DOES NOT
5      ; ATTEMPT ANY UNIBUS TRANSFERS.
6      ;
7      ; INPUTS:
8      ;     R5  ADDRESS OF CONTROLLER TABLE
9      ;
10     ; LOAD TABLE OF DATA TO SEND TO UDASA REGISTER
11
12     017534      UDAIST: BREAK
13     017534      104422                                TRAP    C$BRK
14     017536      010146                                PUSH R1
15     017540      016504 000004                        MOV C.VEC(R5),R4
16     017544      042704 177000                        AND CT.VEC,R4
17     017550      006204                                BIC #C<CT.VEC.,R4
18     017552      006204                                ASR R4
19     017554      052704 100000                        ASR R4
20     017560      010437 017752                        BIS #SA.STP,R4      ;SET STEP BIT IN DATA WORD
21     017564      016537 000016 017756                MOV R4,UDAID1       ;LOAD INTERRUPT VECTOR
22     017572      062737 000004 017756                MOV C.RING(R5),UDAID2 ;LOAD MEMORY ADDRESS
23     ; START THE INITIALIZATION BY WRITING TO UDAIP REGISTER
24
25     017600      016504 000000                        MOV C.UADR(R5),R4   ;GET ADDRESS OF UDAIP REGISTER
26     017604      005037 002200                        CLR NXMAD           ;CLEAR MEMORY ERROR FLAG
27     017610      012746 000340                        SETVEC #4,#NXMI,#PRI07 ;SET UP VECTOR 4
28     017614      012746 017146                        MOV #PRI07,(SP)
29     017620      012746 000004                        MOV #NXMI,(SP)
30     017624      012746 000003                        MOV #4,(SP)
31     017630      104437                                MOV #3,(SP)
32     017632      062706 000010                        TRAP C$SVEC
33     017636      005764 000002                        ADD #10,SP
34     017642      005014                                TST 2(R4)           ;ACCESS UDASA REGISTER
35     017644      012700 000004                        CLR (R4)            ;WRITE TO UDAIP
36     017650      104436                                CLRVEC #4           ;GIVE UP THE VECTOR
37     017652      005737 002200                        MOV #4,R0
38     017656      001406                                TRAP C$CVEC
39     017660      104455                                ;SEE IF A MEMORY ERROR OCCURRED
40     017662      000024                                TST NXMAD
41     017664      000000                                BEQ UDAISG
42     017666      011750                                ERROF 20,.,ERRO20
43     017670      000261                                TRAP C$ERDF
44     017672      000424                                .WORD 20
45     ; SEC
46     ; BR UDAISE
47     ;
48     ;
49     ;
50     ;
51     ;
52     ;
53     ;
54     ;
55     ;
56     ;
57     ;
58     ;
59     ;
60     ;
61     ;
62     ;
63     ;
64     ;
65     ;
66     ;
67     ;
68     ;
69     ;
70     ;
71     ;
72     ;
73     ;
74     ;
75     ;
76     ;
77     ;
78     ;
79     ;
80     ;
81     ;
82     ;
83     ;
84     ;
85     ;
86     ;
87     ;
88     ;
89     ;
90     ;
91     ;
92     ;
93     ;
94     ;
95     ;
96     ;
97     ;
98     ;
99     ;
100    ;
    
```

```

1          ;SET UP LOOP PARAMETERS TO EXECUTE THE FOUR STEPS OF INITIALIZATION
2
3 017674 012737 004000 020216 UDAISG: MOV @SA.S1,UDARSD          ;STORE RESPONSE MASK
4 017702 012703 017750          MOV @UDAIDT,R3          ;AND INDEX TO TABLE
5
6          ;WAIT FOR AND CHECK RESPONSE DATA
7
8 017706 044737 020060          UDAISL: CALL UDARSP          ;WAIT FOR STEP OR ERROR BITS
9 017712 103414          BCS UDAISE          ;EXIT IF ERROR
10 017714 004733          CALL @R3          ;CALL RESPONSE CHECKER FOR STEP
11 017716 103412          BCS UDAISE          ;GET OUT IF ERROR
12 017720 006337 020216          ASL UDARSD          ;SHIFT TO NEXT STEP BIT
13 017724 032737 040000 020216          BIT @SA.S4,UDARSD          ;CHECK IF NOW AT STEP 4
14 017732 001003          BNE UDAISX          ;GET OUT IF SO
15 017734 012364 000002          MOV (R3),2(R4)          ;WRITE DATA TO UDASA REGISTER
16 017740 000762          BR UDAISL          ;STAY IN LOOP
17
18 017742 000241          UDAISX: CLC          ;CLEAR CARRY FOR NO ERROR INDICATION
19 017744          UDAISE: POP R1
          ;
          MOV (SP),R1
20 017746 000207          RETURN

```

```

1          ;DATA TO BE SENT AND RECEIVED BY UDA INITIALIZATION
2
3 017750 017766      UDAID1: .WORD UDAIR1          ;FIRST WORD RESPONSE CHECK ROUTINE
4 017752 000000      UDAID1: .WORD 0              ;FIRST WORD TO SEND TO UDASA
5 017754 017774      UDAID2: .WORD UDAIR2          ;SECOND WORD RESPONSE CHECK ROUTINE
6 017756 000000      UDAID2: .WORD 0              ;SECOND WORD TO SEND TO UDASA
7 017760 020014      UDAID3: .WORD UDAIR3          ;THIRD WORD RESPONSE CHECK ROUTINE
8 017762 100000      UDAID3: .WORD SA.TST         ;THIRD WORD TO SEND TO UDASA
9 017764 020032      UDAID3: .WORD UDAIR4          ;FOURTH WORD RESPONSE CHECK ROUTINE
10
11          ;RESPONSE CHECK FOR FIRST WORD FROM UDASA
12          ;CHECK FOR PROPER CONTROLLER TYPE
13
14 017766 012701 004400  UDAIR1: MOV #SA.S1+SA.DI,R1      ;SET STEP ONE BIT
15 017772 000422          BR UDAIRC                      ;NOW COMPARE
16
17          ;RESPONSE CHECK FOR SECOND WORD FROM UDASA
18          ;CHECK FOR ECHO OF INTI AND VECTOR
19
20 017774 013701 017752  UDAIR2: MOV UDAID1,R1          ;GET WORD SENT TO UDASA
21 020000 000301          SWAB R1                        ;GET HIGH 8 BITS
22 020002 042701 177400  BIC #177400,R1
23 020006 052701 010000  BIS #SA.S2,R1                ;SET STEP 2 BIT
24 020012 000412          BR UDAIRC                      ;NOW COMPARE
25
26          ;RESPONSE CHECK FOR THIRD WORD FROM UDASA
27          ;CHECK FOR ECHO OF MESSAGE AND COMMAND RING LENGTHS
28
29 020014 013701 017752  UDAIR3: MOV UDAID1,R1          ;GET WORD SENT TO UDASA
30 020020 042701 177400  BIC #177400,R1                ;JUST LOW 8 BITS
31 020024 052701 020000  BIS #SA.S3,R1                ;SET STEP 3 BIT
32 020030 000403          BR UDAIRC                      ;NOW COMPARE
33
34          ;RESPONSE CHECK FOR FOURTH WORD FROM UDASA
35          ;CHECK FOR ECHO OF PURGE AND LFAIL BITS
36
37 020032 010201 137760  UDAIR4: MOV R2,R1              ;GET RESPONSE FROM UDA
38 020034 042701          BIC #C<SA.S4+SA.MCV>,R1      ;KEEP MICROCODE VERSION AND STEP 4
39
40          ;COMPARE EXPECTED DATA IN R1 WITH ACTUAL DATA IN R2
41
42 020040 020102      UDAIRC: CMP R1,R2                ;COMPARE THE DATA
43 020042 001405      BEQ UDAIRX                       ;EXIT IF COMPARED CORRECTLY
44 020044          ERRDF 25,ERR025                     ;REPORT ERROR
45 020044 104455      TRAP C8ERDF
46 020046 000031      .WORD 25
47 020050 000000      .WORD 0
48 020052 012144      .WORD ERR025
49 020054 000261      SEC
50 020056 000207      UDAIRX: RETURN
    
```

```

1      ;UDARSP
2      ;
3      ;WAIT FOR UDA TO RESPOND WITH DATA IN UDASA REGISTER.
4      ;EITHER STEP BIT FROM MASK IN LOCATION UDARSD OR ERROR BIT
5      ;WILL CAUSE A TERMINATION.
6      ;AN ERROR MESSAGE WILL BE PRINTED IF THE UDA DOES NOT RESPOND
7      ;IN 10 SECONDS OR IF ERROR SETS.
8      ;
9      ;INPUTS:
10     ; UDASRD - MASK OF STEP BIT TO LOOK FOR
11     ; R5 - ADDRESS OF CONTROLLER TABLE
12     ; R4 - ADDRESS OF UDAIP REGISTER
13     ;OUTPUTS:
14     ; ERROR MESSAGE IF TIME OUT ON RESPONSE OR ERROR BIT SETS
15     ; R2 - DATA FROM UDASA REGISTER
16     ; CARRY SET IF ERROR BIT SETS OR TIME OUT
17
18 020060 UDARSP: PUSH R1
19 020060 010146                                MOV R1, (SP)
20 020062 052737 100000 020216                BIS #SA.ERR,UDARSD      ;SET ERROR BIT IN MASK WORD
21 020070 012700 000012                        MOV #10.,R0            ;SET UP FOR 10 SECOND TIMEOUT
22 020074 010501                                MOV R5,R1              ;POINT TO COUNTER IN CONTROLLER TABLE
23 020076 062701 000040                        ADD #C.TO,R1
24 020102 004737 017166                        CALL SETTO
25 020106 012601                                POP R1
26 020110 033764 020216 000002 UDARS1: BIT UDARSD,2(R4)      ;LOOK AT ERROR AND STEP BIT
27 020116 001024                                BNE UDARS2            ;BRANCH IF EITHER SET
28 020120 104422                                BREAK
29 020122 005737 003210                        TST KW.CSR            TRAP C$BRK
30 020126 001770                                BEQ UDARS1            ;SEE IF CLOCK ON SYSTEM
31 020130 023765 003222 000042                CMP KW.EL+2,C.TO(R5)  ;CHECK IF TIME OUT OCCURRED
32 020136 101005                                BHI 1$
33 020140 001363                                BNE UDARS1
34 020142 023765 003220 000040                CMP KW.EL,C.TO(R5)
35 020150 103757                                BLO UDARS1
36 020152 016402 000002 1$: MOV 2(R4),R2      ;GET REGISTER CONTENTS
37 020156 104455                                ERROF 22,ERR022      ;REPORT TIME OUT ERROR
38 020160 000026                                TRAP C$ERDF
39 020162 000000                                .WORD 22
40 020164 012016                                .WORD 0
41 020166 000407                                .WORD ERR022
42                                BR UCARSE
    
```

```

1      ;CHECK IF ERROR BIT SET
2
3      020170 016402 000002      UDARS2: MOV 2(R4),R2      ;GET REGISTER CONTENTS
4      020174 100006              BPL UDARSX              ;EXIT IF ERROR NOT SET
5      020176              ERRDF 21,,ERR021      ;REPORT ERROR INFO
        020176 104455              TRAP      C$ERRDF
        020200 000025              .WORD    21
        020202 000000              .WORD    0
        020204 011762              .WORD    ERR021
6      020206 000261      UDARSE: SEC
7      020210 000207              RETURN
8
9      ;NORMAL EXIT
10
11     020212 000241      UDARSX: CLC      ;CLEAR CARRY AS NO ERROR INDICATION
12     020214 000207              RETURN
13
14     ;LOCATION FOR STEP BIT MASK
15
16     020216 000000      UDARSD: .WORD 0      ;LOAD BY CALLING ROUTINE

```

```

1      ;KW111
2      ;
3      ;CLOCK INTERRUPT SERVICE ROUTINE
4
5      020220      BGNSRV KW111
6      020220      062737 000001 003220      ADD #1,KW.EL      ;COUNT THE INTERRUPT      KW111::
7      020226      005537 003222      ADC KW.EL+2
8      020232      012777 000105 162750      MOV #KWOUT.,@KW.CSR      ;RESTART THE CLOCK
9      020240      ENDSRV
10     020240      000002      L10033;      RTI

```

```

1      ;RNTIME
2
3      ;PRINT RUNTIME
4
5      ;INPUTS:
6      ;       KW.EL - CONTAINS ELAPSED TIME
7      ;       KW.HZ - HERTZ OF CLOCK
8
9      ;OUTPUTS:
10     ;       IF CLOCK ON SYSTEM:
11     ;           " RUNTIME HH:MM:SS " PRINTED
12     ;       IF NO CLOCK: ONE SPACE IS PRINTED
13 020242 005737 003210  RNTIME: TST KW.CSR           ;CHECK IF A CLUCK PRESENT
14 020246 001465          BEQ RNTIMX           ;BRANCH IF NOT
15 020250          PUSH <R0,R3,R4,R5>
16 020250 010046          MOV R0, (SP)
17 020252 010346          MOV R3, (SP)
18 020254 010446          MOV R4, (SP)
19 020256 010546          MOV R5, (SP)
20 020260 013703 003220  MOV KW.EL,R3           ;GET ELAPSED TIME
21 020264 013704 003222  MOV KW.EL*2,R4
22 020270 013700 003216  MOV KW.HZ,R0           ;GET SPEED OF CLOCK
23 020274 004737 016332  CALL DIVIDE           ;COMPUTE SECONDS OF ELAPSED TIME
24 020300 012700 000074  MOV .60.,R0           ;NOW DIVIDE BY 60
25 020304 004737 016332  CALL DIVIDE           ; TO COMPUTE MINUTES
26 020310          PUSH R5           ;SAVE REMAINDER AS SECONDS
27 020310 010546          MOV R5, -(SP)
28 020312 004737 016332  CALL DIVIDE           ;DIVIDE BY 60 AGAIN
29 020316          PNT RNTIM,R3       ;PRINT HOURS
30 020316 010346          MOV R3, -(SP)
31 020320 004137 016264  JSR R1,LPNT
32 020324 003704          .WORD RNTIM
33 020326 000002          .WORD PNT.CT
34 020330 020527 000011  CMP R5,#9           ;IF MINUTES 9 OR LESS
35 020334 003004          BGT 18
36 020336          PRINT #'0       ;PRINT A LEADING ZERO
37 020336 112700 000060  MOVB #'0,R0
38 020342 004737 016054  CALL CPNT
39 020346          18: PNT RNTIM1,R5   ;NOW PRINT MINUTES
40 020346 010546          MOV R5, -(SP)
41 020350 004137 016264  JSR R1,LPNT
42 020354 003727          .WORD RNTIM1
43 020356 000002          .WORD PNT.CT
44 020360          POP R5           ;GET SECONDS
45 020360 012605          MOV (SP),R5
46 020362 020527 000011  CMP R5,#9           ;IF 9 OR LESS
47 020366 003004          BGT 21
48 020370          PRINT #'0       ;PRINT A LEADING ZERO
49 020370 112700 000060  MOVB #'0,R0
50 020374 004737 016054  CALL CPNT
51 020400          21: PNT RNTIM2,R5   ;NOW PRINT SECONDS
52 020400 010546          MOV R5, -(SP)
53 020402 004137 016264  JSR R1,LPNT
54 020406 003735          .WORD RNTIM2
55 020410 000002          .WORD PNT.CT
56 020412          POP <R5,R4,R3,R0> ;HOURS IN R3
57 020412 012605          MOV (SP),R5
    
```



020414 012604  
020416 012603  
020420 012600  
35 020422 112700 000040  
020426 004737 016054  
36 020432 000207

RNTIMX: PRINT '0 '

PRINT A SPACE

RETURN

MOV (SP),R4  
MOV (SP),R3  
MOV (SP),R0

MOVB @,R0  
CALL CPNT

```

1 020434      DATE:  GMANID DATEQ,DATEI,A, 1,1,11,,(E5)      ;GET DATE
   020434      104443
   020436      000406
   020440      003272
   020442      000152
   020444      003536
   020446      177777
   020450      000001
   020452      000013
   020454
2 020454      012705      003272      MOV #DATEI,R5      ;GET POINTER TO ANSWER
3 020460      121527      000060      CMPB (R5),#0
4 020464      103443      BLO DERR
5 020466      122527      000071      DAY:  CMPB (R5),#9
6 020472      101040      BHI DERR
7 020474      121527      000055      CMPB (R5),#-
8 020500      001406      BEQ DAS1
9 020502      121527      000060      CMPB (R5),#0
10 020506     103432      BLO DERR
11 020510     122527      000071      CMPB (R5),#9
12 020514     101027      BHI DERR
13 020516     122527      000055      DAS1:  CMPB (R5),#-
14 020522     001024      BNE DERR
15 020524     012704      000014      MOV #12,R4      ;GET NUMBER OF MONTH
16 020530     012703      003347      MON1:  MOV #MONTHS,R3  ;GET POINTER TO MONTH NAMES
17 020534     005000      CLR R0
18 020536     121523      CMPB (R5),(R3)
19 020540     001401      BEQ MON2
20 020542     005200      INC R0
21 020544     126523      000001      MON2:  CMPB 1(R5),(R3)
22 020550     001401      BEQ MON3
23 020552     005200      INC R0
24 020554     126523      000002      MON3:  CMPB 2(R5),(R3)
25 020560     001401      BEQ MON4
26 020562     005200      INC R0
27 020564     005700      MON4:  TST R0
28 020566     001407      BEQ MON5
29 020570     005304      DEC R4
30 020572     001360      BNE MON1
31 020574     DERR:  PNT# DATEX
   020574     004137      016226
   020600     011503
   020602     000000
32 020604     000713
33 020606     012701      003306      MON5:  BR DATE
34 020612     010403      MOV #DATEQ,R1  ;GET POINTER TO DATE FOR FORMATTER
35 020614     020327      000012      MON6:  MOV R4,R3      ;GET COPY OF MONTH NUMBER
36 020620     103404      CMP R3,#10     ; IF 10 OR GREATER
37 020622     112721      000061      BLO MON6
38 020626     162703      000012      MOVB #'1,(R1)  ;PUT A "1" IN OUTPUT
39 020632     062703      000060      SUB #10,R3
40 020636     110321      MON6:  ADD #0,R3      ;CONVERT MONTH NUMBER TO ASCII
41 020640     112721      000055      MOV R3,(R1)    ;PUT A NUMBER IN OUTPUT
42 020644     062704      003412      MOVB #'-(R1)   ;PUT A "-" IN OUTPUT
43          ADD #DAYS-1,R4 ;GET POINTER TO DAYS IN MONTH
44          ;INDEXED BY NUMBER OF MONTH
45 020650     012703      003272      MOV #DATEI,R3  ;GET POINTER TO DATE INPUT
   020654     005000      CLR R0
    
```

100000:

TRAP  
 BR  
 .WORD  
 .WORD  
 .WORD  
 .WORD  
 .WORD  
 .WORD

C:GMAN  
 100000  
 DATEI  
 T:CODE  
 DATEQ  
 -1  
 T:BL0LIM  
 T:SHLIM

JSR R1,LPNT#  
 .WORD DATEX  
 .WORD PNT.CT

```

46 020656 121327 000055      DAY1:  CMPB (R3),0'
47 020662 001413              BEQ DAY2
48 020664 111321              MOVB (R3),(R1). ;PUT DAY CHARACTER IN OUTPUT
49 020666 006300              ASL R0
50 020670 01000?              MOV R0,R2
51 020672 006300              ASL R0
52 020674 006300              ASL R0
53 020676 060200              ADD R2,R0
54 020700 112302              MOVB (R3),R2
55 020702 162702 000060      SUB #0,R2
56 020706 060200              ADD R2,R0
57 020710 000762              BR DAY1
58 020712 120014      DAY2:  CMPB R0,(R4)
59 020714 101327              BHI DERR
60 020716 005700              TST R0 ;SEE IF DATE IS ZERO
61 020720 001725              BEQ DERR ;ERROR IF SO
62 020722 062705 000003      ADD #3,R5
63 020726 121527 000055      CMPB (R5),0' ;CHECK FOR " " BETWEEN DAY
64 020732 001320              BNE DERR ; AND YEAR IN OUTPUT
65 020734 112521              MOVB (R5),R1) ;PUT "-" IN OUTPUT
66 020736 010504              MOV R5,R4 ;GET COPY OF INPUT STRING POINTER
67 020740 005000              CLR R0
68 020742 005002              CLR R2
69 020744 121427 000060      YER1:  CMPB (R4),0'0
70 020750 103416              BLO YER2
71 020752 121427 000071      CMPB (R4),0'9
72 020756 101013              BHI YER2
73 020760 006300              ASL R0
74 020762 010003              MOV R0,R3
75 020764 006300              ASL R0
76 020766 006300              ASL R0
77 020770 060300              ADD R3,R0
78 020772 112403              MOVB (R4),R3
79 020774 162703 000060      SUB #0,R3
80 021000 060300              ADD R3,R0
81 021002 005202              INC R2
82 021004 000757              BR YER1
83 021006 105714      YER2:  TSTB (R4)
84 021010 001271              BNE DERR
85 021012 020227 000002      CMP R2,#2
86 021016 001407              BEQ YER3
87 021020 020227 000004      CMP R2,#4
88 021024 001263              BNE DERR
89 021026 020027 003554      CMP R0,#1900.
90 021032 103660              BLO DERR
91 021034 000413              BR YER5
92 021036 012702 003427      YER3:  MOV #YEAR19,R2
93 021042 020027 000106      CMP R0,#70.
94 021046 103002              BHS YER4
95 021050 012702 003432      MOV #YEAR20,R2
96 021054 105712      YER4:  TSTB (R2)
97 021056 001402              BEQ YER5
98 021060 112221              MOVB (R2),R1)
99 021062 000774              BR YER4
100 021064 112521      YER5:  MOVB (R5),R1)
101 021066 001376              BNE YER5
102 021070 000207              RETURN

```

103  
104 021072

ENDMOD

1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17

.SBTTL PROTECTION TABLE

BGNMOD

\*\*\*  
; THIS TABLE IS USED BY THE RUNTIME SERVICES  
; TO PROTECT THE LOAD MEDIA.  
\*\*\*

BGNPROT

..SPROT::

1  
1  
-1

;OFFSET INTO P-TABLE FOR CSR ADDRESS  
;OFFSET INTO P-TABLE FOR MASSBUS ADDRESS  
;OFFSET INTO P-TABLE FOR DRIVE NUMBER

ENDPROT

021072  
021072  
021072 177777  
021074 177777  
021076 177777  
021100

```

1          .SBTTL INITIALIZE SECTION
2
3          ;**
4          ; THE INITIALIZE SECTION CONTAINS THE CODING THAT IS PERFORMED
5          ; AT THE BEGINNING OF EACH PASS.
6          ;
7
8          021100          BGNINIT
9
10         021100          L0INIT::
11         021100          HEADF @EF.START          ;CHECK IF STARTED BY OPERATOR
12         021100          012700 000040          MOV @EF.START,RO
13         021104          104447          TRAP C0REFG
14         021106          BCOMPLETE INIT1          ; IF NOT,
15         021106          103415          BCS INIT1
16         021110          READF @EF.RESTART
17         021110          012700 000037          MOV @EF.RESTART,RO
18         021114          104447          TRAP C0REFG
19         021116          BCOMPLETE INIT1
20         021116          103411          BCS INIT1
21         021120          READF @EF.CONTINUE
22         021120          012700 000036          MOV @EF.CONTINUE,RO
23         021124          104447          TRAP C0REFG
24         021126          BCOMPLETE INIT1
25         021126          103405          BCS INIT1
26         021130          READF @EF.PWR
27         021130          012700 000034          MOV @EF.PWR,RO
28         021134          104447          TRAP C0REFG
29         021136          BCOMPLETE INIT1
30         021136          103401          BCS INIT1
31         021140          INITQT: DOCLN          ; ABORT PROGRAM
32         021140          104444          TRAP C0DCLN
33
34         021142          012700 000003          INIT1: MOV #SO.FMT,RO ;BUILD MODE WORD FROM SOFTWARE QUESTIONS
35         021146          030037 002144          BIT RO,SFPTBL ;SEE IF REFORMAT
36         021152          001011          BNE INIT2 ; BRANCH IF SO
37         021154          012700 000004          MOV #SO.CNS,RO ;SEE IF RECONSTRUCT
38         021160          030037 002144          BIT RO,SFPTBL
39         021164          001004          BNE INIT2 ; BRANCH IF SO
40         021166          006300          ASL RO ;SEE IF RESTORE
41         021170          ;ASSUME SO.STR EQ SO.CNS*2
42         021170          030037 002144          BIT RO,SFPTBL
43         021174          001761          BEQ INITQT ;IF NOT, ABORT PROGRAM
44         021176          010037 003206          INIT2: MOV RO,MODE ;SAVE MODE FLAGS
45         021202          004737 012564          INIT3: CALL RESET ;RESET ALL UNITS
46         021206          MEMORY FFREE          ;RESET START OF FREE MEMORY
47         021206          104431          TRAP C0MEM
48         021210          010037 002146          MOV RO,FFREE
49         021214          017737 160726 002150          MOV @FFREE,FSIZE ;RESET SIZE OF FREE MEMORY
50
51         ;INITIALIZE CLOCK
52
53         000105          KWOUT.=105 ;DATA TO SEND TO KW11 TO START CLOCK
54         021222          005037 003210          CLR KW.CSR ;MARK CLOCK AS NOT ON SYSTEM
55         021226          005037 003220          CLR KW.EL ;CLEAR ELAPSED TIME
56         021232          005037 003222          CLR KW.EL*2
57         021236          CLOCK L,RO          ;SEE IF AN L CLOCK PRESENT
    
```

021236	012700	000114				MOV	#L,R0
021242	104462					TRAP	C1C1CM
43 021244			BCOMplete KYES				
021244	103413					BCS	KYES
43 021246			CLOCK P,R0		;SEE IF A P CLOCK PRESENT		
021246	012700	000120				MOV	#P,R0
021252	104462					TRAP	C8CLCK
44 021254			BCOMplete KYES				
021254	103407					BCS	KYES
45 021256	005037	003210	CLR KW.CSR		;IF NEITHER, CLEAR CSR STORAGE WORD		
46 021262			PNTF NOCLOCK				
021262	004137	016226				JSR R1,L,PNTF	
021266	004073					.WORD NOCLOCK	
021270	000000					.WORD PNT.CT	
47 021272	000426		BR KNO				
48 021274	012037	003210	KYES: MOV (R0),KW.CSR		;STORE DATA RETURNED		
49 021300	012037	003212	MOV (R0),KW.BRL				
50 021304	012037	003214	MOV (R0),KW.VEC				
51 021310	012037	003216	MOV (R0),KW.MZ				
52 021314			SETVEC KW.VEC,#KW1'I,KW.BRL		;SET THE VECTOR		
021314	013746	003212				MOV	KW.BRL,-(SP)
021320	012746	020220				MOV	#KW1'I,(SP)
021324	013746	003214				MOV	KW.VEC,(SP)
021330	012746	000003				MOV	#3,(SP)
021334	104437					TRAP	C8SVEC
021336	062706	000010				ADD	#10,SP
53 021342	012777	000105	161640		MOV #KWOUT.,#KW.CSR		
54 021350			KNO:		;START THE CLOCK		

```

1
2
3 021350 013737 002146 002156      MOV #FREE,CTABS      ;STORE START OF CONTROLLER TABLES
4 021356 005077 160574              CLR #CTABS          ;ZEROS MARKS END CONTROLLER TABLES
5 021362 005037 002160              CLR CTRLRS         ;CLEAR CONTROLLER COUNT
6 021366 012701 003436              MOV #IPADRS,R1     ; R1 -> IP ADDRESS
7 021372 012702 000010              MOV #8,R2         ; R2 IS A COUNTER
8 021376 005021 11:              CLR (R1)          ; CLEAR ENTRY
9 021400 005302                      DEC R2             ; DONE?
10 021402 001375                      BNE 11            ; IF NOT, BRANCH
11
12 ;GET A P TABLE FROM DR5
13
14 021404 005002                      CLR R2            ;LOGICAL UNIT NUMBER IN R2
15 021406 021406 010200              INIT4: GPHARD R2,R0 ;GET POINTER TO A P TABLE
16 021412 021412 104442              BNCOMPLETE NXTTAB ;IGNORE IF NO TABLE RETURNED
17
18 ;SEE IF A CONTROLLER TABLE ALREADY EXISTS FOR CONTROLLER IN P-TABLE
19
20 021414 013703 002156              MOV CTABS,R3      ;GET ADDRESS OF CONTROLLER TABLES
21 021420 005713                      INIT5: TST (R3)    ;CHECK IF ANY MORE TABLES
22 021422 001416                      BEQ NEWTAB        ;BUILD NEW TABLE IF FOUND ZERO WORD
23 021424 021013                      CMP (R0),(R3)     ;CHECK IF SAME UNIBUS ADDRESS
24 021426                      ASSUME C.UADR EQ 0
25 021426                      ASSUME MO.UBA EQ 0
26 021426 001463                      BEQ SAMTAB        ;CHECK TABLE IF ALREADY EXISTS
27 021430 016301 000004              MOV C.VEC(R3),R1 ;GET VECTOR FROM EXISTING CONTROLLER TABLE
28 021434 042701 177000              BIC #C<CT.VEC>,R1
29 021440 026001 000002              CMP MO.VEC(R0),R1 ;SEE IF DIFFERENT VECTOR
30 021444 001002                      BNE 11
31 021446 000137 022076              JMP SAMVEC        ;ERROR, CAN'T HAVE TWO UDA'S WITH SAME VECTOR
32 021452 062703 000054              11: ADD #C.SIZE,R3 ;MOVE TO NEXT TABLE
33 021456 000760                      BR INIT5
    
```



```

1
2
3 021460 012703 000010
4 021464 012704 003436
5 021470 005714
6 021472 001404
7 021474 005724
8 021476 005303
9 021500 001373
10 021502 000401
11 021504 011014
12 021506 012701 000026
13 021512 004737 012522
14 021516 011021
15 021520 010221
16 021522 016004 000004
17 021526 000304
18 021530 006104
19 021532 056004 000002
20 021536 010421
21 021540 016021 000006
22 021544 012721 004037
23 021550 012721 017156
24 021554 012703 000020
25
26 021560 005021
27 021562 005303
28 021564 001375
29 021566 005237 002160
30 021572 005011
31 021574 000417
    
```

;BUILD A CONTROLLER TABLE

```

NEWTAB: MOV    #8.,R3
        MOV    #IPADRS,R4
1$:     TST    (R4)
        BEQ    2$
        TST    (R4).
        DEC    R3
        BNE    1$
        BR     3$
2$:     MOV    (R0),(R4)
3$:     MOV    #C.SIZE/2,R1
        CALL  ALOCM
        MOV    (R0),(R1).
        MOV    R2,(R1).
        MOV    MO.BRL(R0),R4
        SWAB  R4
        ROL   R4
        BIS   MO.VEC(R0),R4
        MOV   R4,(R1).
        MOV   MO.BST(R0),(R1).
        MOV   #4037,(R1).
        MOV   #UDASRV,(R1).
        MOV   #16.,R3

INIT7:  CLR   (R1).
        DEC  R3
        BNE INIT7
        INC  CTRLRS
        CLR (R1)
        BR  NXXTAB
    
```

```

;R3 IS A COUNTER
;R4 -> IP ADDRESSES
; FOUND AN OPEN ENTRY?
; IF SO, GO FILL ENTRY
; NEXT ENTRY
; SEARCH THROUGH ENTIRE TABLE?
; IF NOT, BRANCH
; ELSE, TABLE FULL
; STORE ENTRY INTO TABLE
;GET WORDS IN CONTROLLER TABLE
;ALLOCATE SPACE FOR IT
;STORE UNIBUS ADDRESS
;UNIT NUMBER
;GET BR LEVEL
;SWAP TO HIGH BYTE
;SHIFT ONE MORE TO LEFT
;ADD VECTOR ADDRESS
; TO TABLE

;PUT {JSR R0,UDASRV}
; INTO TABLE
;CLEAR POINT'RS TO DRIVE TABLES.
; TIMEOUT COUNTER, FLAGS, REF. NUMBER

;LOOP TIL ALL CLEARED
;COUNT THE CONTROLLER
;CLEAR TABLE END MARKER
;NOW GO TO NEXT P TABLE
    
```

```

1
2
3 021576 016004 000004          ; SHOULD BE SAME CONTROLLER, CHECK THAT OTHER PARAMETERS MATCH
4 021602 000304          SAHTAB: MOV MO.BRL(R0),R4          ; GET BR LEVEL FROM P TABLE
5 021604 006104          SWAB R4          ; SWAP TO HIGH BYTE
6 021606 056004 000002          ROL R4          ; SHIFT ONE MORE TO LEFT
7 021612 020463 000004          BIS MO.VEC(R0),R4          ; ADD VECTOR ADDRESS
8 021616 001004          CMP R4,C.VEC(R3)          ; COMPARE WITH CONTROLLER TABLE
9 021620 026063 000006 000006          BNE 18          ; COMPARE BURST RATES
10 021626 001402          CMP MO.BST(R0),C.BST(R3)
11 021630 000137 022026          BEQ NXTTAB          ; FATAL ERROR IF NOT SAME
12
13          ; GET NEXT P TABLE
14
15 021634 005202          NXTTAB: INC R2          ; INCREMENT LOGICAL UNIT NUMBER
16 021636 023702 002012          CMP LUNIT,R2          ; CHECK IF GOT ALL TABLES
17 021642 003261          BGT INIT4          ; IF NOT, GO BACK FOR NEXT
18
19 021644 012701 000001          MOV #1,R1          ; ALLOCATE SPACE FOR ZERO END WORD
20 021650 004737 012522          CALL ALOCM          ; AFTER CONTROLLER TABLES

```

```
1
2
3      ;NOW BUILD DRIVE TABLES
4 021654 005002      CLR R2
5 021656 010200      INIT8. GPHARD R2,R0      ;LOGICAL UNIT NUMBER IN R2
6 021660 104442      ;GET POINTER TO A P-TABLE
7 021662 103040      ;IF NOT AVAILABLE, GO GET NEXT
8
9 021664 013703 002156      ;FIND CONTROLLER TABLE
10 021670 021013      MOV CTABS,R3
11 021672 001403      INIT10: CMP (R0),(R3)
12 021674 062703 000054      BEQ INIT11
13 021700 000773      ADD #C.SIZE,R3
                        BR INIT10
                        ;GET ADDRESS OF CONTROLLER TABLES
                        ;CHECK IF SAME UNIBUS ADDRESS
                        ;BRANCH IF TABLE FOUND
                        ;MOVE TO NEXT TABLE
                        MOV R2,R0
                        TRAP CIGPHRD
                        BCC INIT14
```

```

1          ;BUILD DRIVE TABLE
2
3 021702 012701 000015  INIT11: MOV #D.SIZE/2,R1      ;GET SIZE OF DRIVE TABLE
4 021706 004737 012522  CALL ALOCM          ;ALLOCATE SPACE FROM FREE MEMORY
5          ;
6          ; R0 POINTS TO P-TABLE
7          ; R1 POINTS TO DRIVE TABLE
8          ; R3 POINTS TO CONTROLLER TABLE
9          ; R2 IS UNIT NUMBER
9 021712 010337 003244  MOV R3,TEMP        ;SAVE CONTROLLER TABLE ADDRESS
10         ;IN CASE AN ERROR IS DETECTED
11 021716 062703 000020  ADD #C.DR0,R3     ;BUILD POINTER TO C.DR ENTRY IN CONTROLLER TABLE
12 021722 012704 000010  MOV #8.,R4        ;GET MAX COUNT OF DRIVES ON ONE CONTROLLER
13 021726 005713          INIT12: TST (R3)      ;CHECK IF ENTRY CONTAINS POINTER TO DRIVE TABLE
14 021730 001411          BEQ INIT13
15 021732 026033 000010  CMP MO.LDR(R0),@(R3). ;CHECK DRIVE NUMBER IN DRIVE TABLE
16 021736 001002          BNE 1$
17 021740 000137 022042  JMP MLDREX        ;IF SAME, TWO P TABLES POINT TO SAME DRIVE
18 021744 005304          1$: DEC R4          ;COUNT DRIVES
19 021746 001367          BNE INIT12        ;IF EIGHT DRIVE TABLES EXIST,
20 021750 000137 022060  JMP TOOMER        ; THEN REPORT ERROR
21 021754 010113          INIT13: MOV R1,(R3)   ;LOAD DRIVE TABLE POINTER
22 021756 016021 000010  MOV MO.LDR(R0),(R1). ;LOAD DRIVE NUMBER
23 021762 010221          MOV R2,(R1).      ;LOAD UNIT NUMBER

```

```

1          ;GO TO NEXT DRIVE TABLE
2
3 021764 005202          INIT14: INC R2          ;INCREMENT LOGICAL UNIT NUMBER
4 021766 023702 002012      CMP L$UNIT,R2          ;CHECK IF GOT ALL TABLES
5 021772 003331          BGT INIT8          ;IF NOT, GET NEXT TABLE
6
7          ;SAVE CURRENT PARAMETERS TO FREE MEMORY
8
9 021774 013737 002146 002152 INIT15: MOV FFREE,FMEM      ;SAVE START ADDRESS
10 022002 013737 002150 002154      MOV FSIZE,FMEMS      ;SAVE SIZE
11
12 022010          INITXX: SETPRI @PRI00          ; SET RUNNING PRIORITY TO ZERO
13 022010 012700 000000          MOV @PRI00,R0
14 022014 104441          TRAP C$SPRI
15 022016 004737 013022          CALL CLOSEF          ;MAKE SURE DATA FILE IS CLOSED
16 022022          EXIT INIT
17 022022 104432          TRAP C$EXIT
18 022024 000066          .WORD L!0035
    
```

```

1          ;DIFFERENT VECTORS, BR LEVELS OR BURST RATES FOR ONE CONTROLLER
2 022026 010305 CTABER: MOV R3,R5 ;GET CONTROLLER ADDRESS
3 022030 104454 ERRSF 1,,ERR001
4 022030 104454 TRAP C$ERSF
5 022032 000001 .WORD 1
6 022034 000000 .WORD 0
7 022036 011604 .WORD ERR001
8 022040 DOCLN TRAP C$DCLN
9 022040 104444

5          ;TWO P TABLES FOR SAME DRIVE
6          MLDRE: MOV TEMP,R5 ;GET CONTROLLER ADDRESS
7 022042 013705 003244 ERRSF 2,,ERR002
8 022046 104454 TRAP C$ERSF
9 022046 104454 .WORD 2
10 022050 000002 .WORD 0
11 022052 000000 .WORD ERR002
12 022054 011622 DOCLN TRAP C$DCLN
13 022056 104444

10         ;MORE THAN EIGHT DRIVES SELECTED ON ONE CONTROLLER
11         TOOMER: MOV TEMP,R5 ;GET CONTROLLER ADDRESS
12         ERRSF 3,,ERR003
13 022060 013705 003244 TRAP C$ERSF
14 022064 104454 .WORD 3
15 022066 000003 .WORD 0
16 022070 000000 .WORD ERR003
17 022072 011640 DOCLN TRAP C$DCLN
18 022074 104444

16         ;TWO UDA'S USE THE SAME VECTOR
17         SAMVEC: MOV R3,R5 ;GET CONTROLLER ADDRESS
18         ERRSF 8,,ERR008
19 022076 010305 TRAP C$ERSF
20 022100 104454 .WORD 8
21 022102 000010 .WORD ERR008
22 022104 011670 .WORD 0
23 022106 000000 .WORD 0
24 022110 DOCLN TRAP C$DCLN
25 022110 104444

22         ENDINIT
23         L10035: TRAP C$INIT
24 022112 104411
    
```

.SBTTL AUTODROP SECTION

;;  
; THIS CODE IS EXECUTED IMMEDIATELY AFTER THE INITIALIZE CODE IF  
; THE "ADR" FLAG WAS SET. THE UNIT(S) UNDER TEST ARE CHECKED TO  
; SEE IF THEY WILL RESPOND. THOSE THAT DON'T ARE IMMEDIATELY  
; DROPPED FROM TESTING.  
;

1  
2  
3  
4  
5  
6  
7  
8  
9  
10 022114 BGNAUTO L\$AUTO::  
022114  
11  
12 022114 ENDAUTO L10036: TRAP C\$AUTO  
022114  
022114 104461

```

1      .SBTTL  CLEANUP CODING SECTION
2
3
4      ;**
5      ; THE CLEANUP CODING SECTION CONTAINS THE CODING THAT IS PERFORMED
6      ; AFTER THE HARDWARE TESTS HAVE BEEN PERFORMED.
7      ;
8 022116      BGNCLN
9      022116
10 022116 004737 013022      CALL CLOSEF      ;CLOSE DATA FILE
11 022122 004737 012564      CALL   RESET      ;RESET ALL JOBS
12
13 022126      ENDCLN
14 022126      104412      L10037:      TRAP      C$CLEAN
15 022130      ENDMOD

```



```

1          .SBTTL TEST 1: DUP PROGRAM DRIVER
2
3 022130          BGNMOD
4
5 022130          BGN1ST
6 022130          PNTX WNSTRT          ;PRINT WARNING MESSAGE          T1::
   022130          004137 016246          JSR R1,LPNTX
   022134          004532          .WORD WNSTRT
   022136          000000          .WORD PNT.CT
7 022140          MANUAL          ;SEE IF MANUAL INTERVENTION ALLOWED
   022140          104450          TRAP          C1MANI
8 022142          BNCOMPLETE TIMODE          ;IF NOT, JUST RUN THE PROGRAM
   022142          103020          BCC          TIMODE
9 022144          005037 003244          CLR TEMP          ;CLEAR WORD FOR ANSWER
10 022150          GMANIL WNUQUES,TEMP,1,YES          ;ASK IF STILL WANT TO RUN
   022150          104443          TRAP          C1GMAN
   022152          000404          BR          100008
   022154          003244          .WORD          TEMP
   022156          000130          .WORD          TSCODE
   022160          003622          .WORD          WNUQUES
   022162          000001          .WORD          1
   022164          100008:
11 022164          005737 003244          TST TEMP          ;LOOK AT ANSWER
12 022170          001417          BEQ T1QUIT          ;IF NO, QUIT NOW
13 022172          005737 003306          TST DATED          ;SEE IF ALREADY ASKED FOR DATE
14 022176          001002          BNE TIMODE
15 022200          004737 020034          CALL DATE          ;IF NOT, GET IT NOW
16
17 022204          032737 000003 003206 TIMODE: BIT #50,FMT,MODE
18 022212          001164          BNE T1FMT
19 022214          022214          104450          MANUAL          TRAP          C1MANI
20 022216          022216          103406          BCOMPLETE T1GO          BCS          T1GO
21 022220          022220          104454          ERRSF 10,,ERR010          TRAP          C1ERSF
   022222          000012          .WORD          10
   022224          000000          .WORD          0
   022226          011720          .WORD          ERR010
22 022230          022230          104432          T1QUIT: EXIT TST          TRAP          C1EXIT
   022232          000362          .WORD          L10040
23 022234          032737 000010 003206 T1GO: BIT #50,STR,MODE
24 022242          001435          BEQ T1CNS
25 022244          023727 002012 000001          CMP LBUNIT,#1
26 022252          001406          BEQ T1RST
27 022254          022254          104454          ERRSF 9,,ERR009          TRAP          C1ERSF
   022256          000011          .WORD          9
   022260          000000          .WORD          0
   022262          011706          .WORD          ERR009
28 022264          022264          104432          EXIT TST          TRAP          C1EXIT
   022266          000326          .WORD          L10040
29
30 022270          T1RST: PNTF FILNAM
    
```



59	022470	105710		T1SER6:	TSTB (R0)		
60	022472	001416			BEQ T1SER8		
61	022474	122120			CMPB (R1), (R0)		
62	022476	001774			BEQ T1SER6		
63	022500	103413			BLO T1SER8		
64	022502			T1SER7:	PRINTF @SERNX, @HIGHEST		
	022502	012746	003322			MOV	@HIGHEST, (SP)
	022506	012746	011413			MOV	@SERNX, -(SP)
	022512	012746	000002			MOV	@2, (SP)
	022516	010600				MOV	SP, R0
	022520	104417				TRAP	C@PRINTF
	022522	062706	000006			ADD	@6, SP
65	022526	000724			BR T1SER3		
66	022530	062702	000004	T1SER8:	ADD @D.SERN, R2 ;PUT ANSWER INTO DRIVE TABLE		
67	022534	012701	003244		MOV @TEMP, R1		
68	022540	112122		T1SER9:	MOVB (R1), (R2)		
69	022542	001376			BNE T1SER9		
70	022544	005303			DEC R3		
71	022546	001402			BEQ T1SERN		
72	022550	005724			TST (R4)		
73	022552	000700			BR T1SER2		
74	022554	062705	000054	T1SERN:	ADD @C.SIZE, R5		
75	022560	005715			TST (R5)		
76	022562	001267			BNE T1SER1		
77	022564	013737	002156	002162	T1FMT:	MOV CTABS, TSTTAB	;GET FIRST TABLE ADDRESS
78	022572	013701	002160		MOV CTRLRS, R1		;RUN DM PROGRAM ON ALL CONTROLLERS
79	022576	004737	012710		CALL RUNDM		; RUN ALL CONTROLLERS OF ONE TYPE AT ONCE
80	022602	001402			BEQ 68		
81	022604	004737	013040		CALL RESPDM		
82	022610			68:	EXIT TST		
	022610	104432				TRAP	C@EXIT
	022612	000002				.WORD	L10040
83	022614				ENDTST		
	022614					L10040:	
	022614	104401				TRAP	C@ETST
84	022616				ENDMOD		

```
1          .SBTTL  HARDWARE PARAMETER CODING SECTION
2
3          022616          BGNMOD
4
5
6          ;
7          ; THE HARDWARE PARAMETER CODING SECTION CONTAINS MACROS
8          ; THAT ARE USED BY THE SUPERVISOR TO BUILD P TABLES.  THE
9          ; MACROS ARE NOT EXECUTED AS MACHINE INSTRUCTIONS BUT ARE
10         ; INTERPRETED BY THE SUPERVISOR AS DATA STRUCTURES.  THE
11         ; MACROS ALLOW THE SUPERVISOR TO ESTABLISH COMMUNICATIONS
12         ; WITH THE OPERATOR.
13         ;
14         022616          BGNHRD
15         022616          000027
16         022620
17
18         ;FORMAT OF HARDWARE P-TABLE IS AS FOLLOWS:
19
20         TABLE          ;START A TEBLE DEFINITION
21         ITEM NO.UBA      2          ; UNIBUS ADDRESS
22         ITEM NO.VEC      2          ; UDA VECTOR
23         ITEM NO.BRL      2          ; BR LEVEL
24         ITEM NO.BST      2          ; BURST RATE
25         ITEM NO.LDR      2          ; DRIVE NUMBER
26         END
27
28         .WORD L10041 LSHARD/2
29         LSHARD::
```

1	022620				GPRMA	H.UBA,MO.UBA,0,160000,177774,YES		UNIBUS ADDRESS	
	022620	000031						.WORD	T%CODE
	022622	022676						.WORD	M.UBA
	022624	160000						.WORD	T%LOLIM
	022626	177774						.WORD	T%NILIM
2	022630				GPRMA	H.VEC,MO.VEC,0,4,774,YES	; VECTOR		
	022630	001031						.WORD	T%CODE
	022632	022724						.WORD	M.VEC
	022634	000004						.WORD	T%LOLIM
	022636	000774						.WORD	T%NILIM
3	022640				GPRMD	H.BRL,MO.BRL,0,1,4,,7,,YES	; BR LEVEL		
	022640	002052						.WORD	T%CODE
	022642	022733						.WORD	M.BRL
	022644	177777						.WORD	-1
	022646	000004						.WORD	T%LOLIM
	022650	000007						.WORD	T%NILIM
4	022652				GPRMD	H.BST,MO.BST,D,1,0,,63,,YES	; BURST RATE		
	022652	003052						.WORD	T%CODE
	022654	022744						.WORD	M.BST
	022656	177777						.WORD	-1
	022660	000000						.WORD	T%LOLIM
	022662	000077						.WORD	T%NILIM
5	022664				GPRMD	H.LDR,MO.LDR,D,1,0,,255,,YES	; DRIVE SELECT NUMBER		
	022664	004052						.WORD	T%CODE
	022666	022766						.WORD	M.LDR
	022670	177777						.WORD	-1
	022672	000000						.WORD	T%LOLIM
	022674	000377						.WORD	T%NILIM
6	022676				ENDMRD				
	022676							.EVEN	
								L10041:	
7									
8	022676	125	116	111	H.UBA:	.ASCIZ	\UNIBUS ADDRESS OF UDA		
9	022724	126	105	103	H.VEC:	.ASCIZ	\VECTOR\		
10	022733	102	122	040	H.BRL:	.ASCIZ	\BR LEVEL\		
11	022744	125	116	111	H.BST:	.ASCIZ	\UNIBUS BURST RATE\		
12	022766	104	122	111	H.LDR:	.ASCIZ	\DRIVE NUMBER\		
13						.EVEN			

```
1
2
3
4
5
6
7
8
9
10
11
12 023004          BGNSFT
    023004 000022
    023006
13
14
15
16 023006          ;FORMAT OF SOFTWARE P-TABLE IS AS FOLLOWS:
17
18 023006          TABLE
19
20 000001          ;START A TABLE DEFINITION
21 000002          ;YES/NO ANSWERS
22 000003          ; REFORMAT MODE
23 000004          ; (AGAIN)
24 000010          ; RECONSTRUCT MODE
25 023006          ; RESTORE MODE
                SO.FM1 = BIT0
                SO.FM2 = BIT1
                SO.FMT = SO.FM1 + SO.FM2
                SO.CNS = BIT2
                SO.STR = BIT3
                END
                                .WORD L10042-L$SOFT/2
                                L$SOFT::;
```

```

1 023006          GPRML S.FMT,SO.BIT,SO.FM1,YES  ;REFORMAT?          .WORD  T%CODE
  023006 000130          .WORD  S.FMT
  023010 023223          .WORD  SO.FM1
  023012 000001
2 023014          XFERT SWEND          .WORD  T%CODE
  023014 017024          GPRML S.NRF,SO.BIT,SO.FM2,YES  ;AGAIN REFORMAT?        .WORD  T%CODE
3 023016          .WORD  S.NRF
  023016 000130          .WORD  SO.FM2
  023020 023052          .WORD  T%CODE
  023022 000002          .WORD  S.NRF
4 023024          XFERT SWEND          .WORD  T%CODE
  023024 013024          GPRML S.CNS,SO.BIT,SO.CNS,YES  ;RECONSTRUCT          .WORD  T%CODE
5 023026          .WORD  S.CNS
  023026 000130          .WORD  SO.CNS
  023030 023302          .WORD  T%CODE
  023032 000004          .WORD  S.CNS
6 023034          XFERT SWEND          .WORD  T%CODE
  023034 007024          GPRML S.RST,SO.BIT,SO.STR,YES  ;RESTORE?          .WORD  T%CODE
  023036          .WORD  S.RST
  023036 000130          .WORD  SO.STR
  023040 023345          .WORD  T%CODE
  023042 000010          .WORD  S.RST
8 023044          XFERT SWEND          .WORD  T%CODE
  023044 003024          DISPLAY S.NOF  ;WARNING          .WORD  T%CODE
9 023046          .WORD  S.NOF
  023046 000003          .WORD  T%CODE
  023050 023466          .WORD  S.NOF
10 023052          SWEND: ENDSFT          .EVEN
      023052          L:0042:
11
12 023052          015      012      S.NRF: .BYTE 15,12
13 023054          116      117      124      .ASCII\NOT USING EXISTING INFORMATION WILL DESTROY THE FACTORY BAD SECTOR\
14 023156          015      012          .BYTE 15,12
15 023160          111      116      106      .ASCII\INFORMATION ON THE DISKS.\
16 023211          015      012          .BYTE 15,12
17 023213          101      107      101      .ASCII\AGAIN - \
18 023223          122      105      106      S.FMT: .ASCII\REFORMAT USING EXISTING BAD SECTOR INFORMATION\
19 023302          122      105      103      S.CNS: .ASCII\RECONSTRUCT BAD SECTOR INFORMATION\
20 023345          104      117      040      S.RST: .ASCII\DO YOU HAVE A FILE ON THE SYSTEM LOAD DEVICE\
21 023421          015      012          .BYTE 15,12
22 023423          040      103      117      .ASCII\ CONTAINING BAD SECTOR INFORMATION\
23 023466          131      117      125      S.NOF: .ASCII\YOU CANNOT PROCEED WITHOUT SUCH A FILE.\
24 023536          122      105      123      .ASCII\RESTART PROGRAM AND SELECT TO REFORMAT OR RECONSTRUCT DISK.\
25 023632          000          .BYTE 0
26          .EVEN
27
28          .DSABL AMA
29 000000          .PSECT END
    
```

1  
2  
3 000000  
4 000050  
5  
6  
7  
8 000120  
9 000120 000142  
10 000122 000007  
11 000124  
12  
13  
14  
15  
16  
17  
18  
19  
20 000124

.SBTTL PATCH AREA  
\$PATCH::  
.REPT 40.  
.WORD 0  
.ENDR  
LASTAD  
L\$LAST::  
ENDMOD

.EVEN  
.WORD T\$FREE  
.WORD T\$SIZE



```
1 000124          BGNSETUP          1
2
3 000124          BGNPTAB
  000124 000000
  000126 000005
  000130
4
5 000130 172150   .WORD 172150      ; UNIBUS ADDRESS
6 000132 000154   .WORD 154          ; VECTOR ADDRESS
7 000134 000005   .WORD 5           ; BR LEVEL
8 000136 000077   .WORD 63          ; UNIBUS BURST RATE
9 000140 000000   .WORD 0           ; LOGICAL DRIVL NUMBER
10
11 000142          ENDPTAB
  000142
12
13 000142          ENDSETUP
14
15
16
17
18
19
20
21          000001      .END
```

L10043: .WORD 0  
.WORD L10045 ./2-1

L10045:

Errors detected: 0

\*\*\* Assembler statistics

Work file reads: 276  
Work file writes: 268  
Size of work file: 28936 Words ( 114 Pages)  
Size of core pool: 17152 Words ( 67 Pages)  
Operating system: RT-11 (Under RSTS/E)

Elapsed time: 00:02:44.47  
ZUDED0.OBJ,ZUDED0/C-[20,0]SVC34R.MLB/P:1,ZUDED0.DOC,ZUDED0

SPATCH	135 30																			
ADR	34-100																			
ALOCM	60-160	61-14	122-13	123-20	125 4															
ASSEMB	30-8	30-8																		
BAS	54-140	87-5	87-5	87-5	88-5	88-5														
BASL2	54-120	88-5																		
BASL3	54-130																			
BASLN	54-160	87-5	88-5																	
BASNO	54-110	87-5	88-5																	
BIT0	34-100	133-19																		
BIT00	34-10	34-100																		
BIT01	34-10	34-100																		
BIT02	34-10	34-100																		
BIT03	34-10	34-100																		
BIT04	34-10	34-100																		
BIT05	34-10	34-100																		
BIT06	34-10	34-100																		
BIT07	34-10	34-100																		
BIT08	34-10	34-100																		
BIT09	34-10	34-100																		
BIT1	34-100	45-23	133-20																	
BIT10	34-100																			
BIT11	34-100																			
BIT12	34-100																			
BIT13	34-100																			
BIT14	34-100																			
BIT15	34-100	45-15	46-12	63-27	66-20	74-28	79-15	93-29												
BIT2	34-100	45-24	133-22																	
BIT3	34-100	45-25	133-23																	
BIT4	34-100	45-27																		
BIT5	34-100	45-30																		
BIT6	34-100	45-31																		
BIT7	34-100	45-33																		
BIT8	34-100																			
BIT9	34-100																			
BLDC0	101-22	101-240																		
BLDC1	101-260	101-28																		
BLDCMD	65-49	68-14	68 44	99-2	101-150															
BOE	34-100																			
C#AU	30-80																			
C#AUTC	30-80	128-12																		
C#BRK	30-80	62-12	65-8	104-21	111 12	114-27														
C#BSEG	30-80																			
C#BSUB	30-80																			
C#CEFG	30-80																			
C#CLCK	30-80	120-41	120-43																	
C#CLEA	30-80	129-13																		
C#CLOS	30-80	64-12	77-19																	
C#CLP1	30-80																			
C#CVEC	30-80	62 22	111-30																	
C#DLN	30-80	59-8	62-30	120 18	127 4	127-9	127-15	127-21												
C#DODU	30-80																			
C#DRPT	30-80																			
C#DU	30-80																			
C#EDIT	30-80	30 34																		
C#ERDF	30-80	62 28	65-24	66-36	67 21	68-8	72-22	74 32	100 3	104-29	105-5	109-35	109 54	110-11						

















L\$HIME	30 340				
L\$HPCF	30-340				
L\$HPTP	30 340				
L\$HM	30 34	32-10	32-100		
L\$ICP	30 340				
L\$INIT	30 34	120-80			
L\$LADP	30 340				
L\$LAST	30 34	135-80	136 13		
L\$LOAD	30-340				
L\$LUN	30-340	63-240	65 120	79 140	
L\$MREV	30 340				
L\$NAME	30 340				
L\$PRIO	30-340				
L\$PROT	30-34	119 100			
L\$PRT	30-340				
L\$REPP	30 340				
L\$REV	30 340				
L\$SOFT	30-34	133-12	133 120		
L\$SPC	30-340				
L\$SPCP	30-340				
L\$SPTP	30 340				
L\$S/A	30-340				
L\$SW	30-34	33 10	33-100		
L\$TEST	30-340				
L\$TML	30-340				
L\$UNIT	30 340	80-13	123-16	126-4	130-25
L10000	32-10	32-170			
L10001	33-10	33-140			
L10002	57-160				
L10003	57-200				
L10004	57-240				
L10005	57-280				
L10006	57-320				
L10007	57-360				
L10010	57-400				
L10011	57-440				
L10012	57 480				
L10013	57-570				
L10014	57-620				
L10015	57-760				
L10016	57-800				
L10017	57-840				
L10020	57-880				
L10021	57-920				
L10022	57-970				
L10023	57 1010				
L10024	57-1050				
L10025	57-1090				
L10026	57 1130				
L10027	57-1170				
L10030	57-1210				
L10031	106-140				
L10032	107-210				
L10033	116-90				
L10035	126-14	127-230			
L10036	128-120				



NCONS	81-37*	81-40				
NEWTAB	121-22	122-3*				
NOCLOC	54-10*	120-46				
NUL	50-38*					
NXMAD	50-22*	62-10*	62-18	106-12*	111-26*	111-31
NXMI	62-11	106-10*	111-27			
NXTTAB	121-16	122-31	123-10	123-15*		
O&APTS	30-8*	30-34				
O&AU	30-8*	30-34				
O&BGR	30-8*	30-34				
O&BHS	30-8*	30-32*	30-34			
O&DU	30-8*	30-34				
O&ERRT	30-8*	30-34				
O&GNSW	30-8*	30-32*	30-34			
O&POIN	30-8*	30-32	30-32*	30-32*	30-32*	30-34
O&SETU	30-8*	30-32*	30-34	135-8		
OP.ABO	40-3*					
OP.ACC	40-4*					
OP.AVA	40-22*					
OP.AVL	40-5*					
OP.CCD	40-6*					
OP.CMP	40-7*					
OP.DUP	40-23*					
OP.ELP	40-30*					
OP.END	40-20*	67-5	67-8	68-58		
OP.ERS	40-8*					
OP.ESP	40-29*	99-1				
OP.FLU	40-9*					
OP.GCS	40-10*					
OP.GDS	40-27*	65-48	68-58			
OP.GSS	40-28*					
OP.GUS	40-11*					
OP.HRD	40-18*					
OP.MWR	40-19*	101-21				
OP.ONL	40-12*					
OP.RD	40-13*					
OP.RLC	40-25*					
OP.RPL	40-14*					
OP.RSD	40-32*	67-8	68-43			
OP.SCC	40-15*					
OP.SEX	40-21*					
OP.SMC	40-24*					
OP.SSD	40-31*	67-5	68-13			
OP.SJC	40-16*					
OP.WR	40-17*					
OSTRE	81-35	81-42	81-47*			
OSTRING	81-34*	81-46	89-6	90-6	91-6	96-17
P.BCNT	42-21*	43-9*	68-11	68-33*	99-4*	103-19*
P.BUFF	42-22*					
P.CMST	43-14*					
P.CNCL	43-48*					
P.CNCF	42-40*	43-46*				
P.CNTI	43-49*					
P.CPSP	42-34*					
P.CRF	42-17*	43-4*	67-19	102-17*		
P.CTMO	43-47*					













SVCTST	30-80	30-110	57-90	58-20	130-5									
SWEND	134-2	134-4	134-6	134-8	134-100									
T#AUT	128-100	128-12												
T#CLE	129-80	129-13												
T#DAT	136-3	136-30	136-11											
T#HAR	131-14	131-140	132-6											
T#HM	32-10	32-100	32-17											
T#INI	120-80	126-14	127-23											
T#MSG	57-140	57-16	57-180	57-20	57-220	57-24	57-260	57-28	57-300	57-32	57-340	57-36	57-380	57-40
	57-420	57-44	57-460	57-48	57-500	57-57	57-590	57-62	57-640	57-76	57-780	57-80	57-820	57-84
	57-860	57-88	57-900	57-92	57-940	57-97	57-990	57-101	57-1030	57-105	57-1070	57-109	57-1110	57-113
	57-1150	57-117	57-1190	57-121										
T#PC	136-10	136-13												
T#PRO	119-100													
T#PTA	136-10	136-3	136-30											
T#SOF	133-12	133-120	134-10											
T#SRV	106-100	106-14	107-180	107-21	116-50	116-9								
T#SH	33-10	33-100	33-14											
T#TES	130-50	130-22	130-28	130-82	130-83									
T#ARGC	30-34	30-34	30-34	30-34	30-34	30-34	30-34	30-34	30-34	30-34	30-34	30-340	30-340	30-340
	30-340	30-340	30-340	95-12	95-12	95-12	95-120	95-120	95-14	95-14	95-14	95-140	95-140	95-16
	95-16	95-16	95-160	95-160	95-18	95-18	95-18	95-180	95-180	130-64	130-64	130-64	130-640	130-640
T#CODE	118-1	118-1	118-1	118-10	118-10	118-10	130-10	130-10	130-10	130-100	130-100	130-100	130-31	130-31
	130-31	130-310	130-310	130-310	130-44	130-44	130-44	130-440	130-440	130-440	132-1	132-1	132-1	132-10
	132-10	132-10	132-2	132-2	132-2	132-20	132-20	132-20	132-3	132-3	132-3	132-30	132-30	132-30
	132-4	132-4	132-4	132-40	132-40	132-40	132-5	132-5	132-5	132-50	132-50	132-50	134-1	134-1
	134-1	134-10	134-10	134-10	134-2	134-2	134-2	134-2	134-2	134-2	134-20	134-20	134-20	134-20
	134-3	134-3	134-3	134-30	134-30	134-30	134-4	134-4	134-4	134-4	134-4	134-4	134-40	134-40
	134-40	134-40	134-5	134-5	134-5	134-50	134-50	134-50	134-6	134-6	134-6	134-6	134-6	134-6
	134-60	134-60	134-60	134-60	134-7	134-7	134-7	134-70	134-70	134-70	134-8	134-8	134-8	134-8
	134-8	134-8	134-80	134-80	134-80	134-80	134-9	134-90						
T#ERRN	30-80	59-7	59-70	62-28	62-280	65-24	65-240	66-36	66-360	67-21	67-210	68-8	68-80	72-22
	72-220	74-32	74-320	100-3	100-30	104-29	104-290	105-5	105-50	109-35	109-350	109-54	109-540	110-11
	110-110	111-33	111-330	113-44	113-440	114-36	114-360	115-5	115-50	127-3	127-30	127-8	127-80	127-14
	127-140	127-20	127-200	130-21	130-210	130-27	130-270							
T#EXCP	118-1	118-10	130-31	130-310	130-44	130-440	132-1	132-10	132-2	132-20	132-3	132-30	132-4	132-40
	132-5	132-50												
T#FLAG	126-14	126-14	126-140	126-140	130-22	130-22	130-220	130-220	130-28	130-28	130-280	130-280	130-82	130-82
	130-820	130-820												
T#FREE	135-8	136-130												
T#GMAN	30-80	118-1	118-10	118-10	130-31	130-310	130-310	130-44	130-440	130-440				
T#HILI	118-1	118-10	130-31	130-310	130-44	130-440	132-1	132-10	132-2	132-20	132-3	132-30	132-4	132-40
	132-5	132-50												
T#LAST	30-80	135-80	136-1											
T#LOLI	118-1	118-10	130-31	130-310	130-44	130-440	132-1	132-10	132-2	132-20	132-3	132-30	132-4	132-40
	132-5	132-50												
T#LSYM	30-8	30-80	32-17	33-14	57-16	57-20	57-24	57-28	57-32	57-36	57-40	57-44	57-48	57-57
	57-62	57-76	57-80	57-84	57-88	57-92	57-97	57-101	57-105	57-109	57-113	57-117	57-121	106-14
	107-21	116-9	127-23	128-12	129-13	130-83	132-6	134-10						
T#LTNO	135-80													
T#NEST	30-80	30-26	30-26	30-260	32-10	32-10	32-100	32-17	32-17	32-17	32-170	33-10	33-10	33-100
	33-14	33-14	33-14	33-140	33-16	33-16	33-160	33-16	34-3	34-3	34-30	57-14	57-14	57-140
	57-16	57-16	57-16	57-160	57-18	57-18	57-180	57-20	57-20	57-20	57-200	57-22	57-22	57-220
	57-24	57-24	57-24	57-240	57-26	57-26	57-260	57-28	57-28	57-28	57-280	57-30	57-30	57-300
	57-32	57-32	57-32	57-320	57-34	57-34	57-340	57-36	57-36	57-36	57-360	57-38	57-38	57-380
	57-40	57-40	57-40	57-400	57-42	57-42	57-420	57-44	57-44	57-44	57-440	57-46	57-46	57-460

	57-48	57-48	57-48	57-480	57-50	57-50	57-500	57-57	57-57	57-57	57-570	57-59	57-59	57-590
	57-62	57-62	57-62	57-620	57-64	57-64	57-640	57-76	57-76	57-76	57-760	57-78	57-78	57-780
	57-80	57-80	57-80	57-800	57-82	57-82	57-820	57-84	57-84	57-84	57-840	57-86	57-86	57-860
	57-88	57-88	57-88	57-880	57-90	57-90	57-900	57-92	57-92	57-92	57-920	57-94	57-94	57-940
	57-97	57-97	57-97	57-970	57-99	57-99	57-990	57-101	57-101	57-101	57-1010	57-103	57-103	57-1030
	57-105	57-105	57-105	57-1050	57-107	57-107	57-1070	57-109	57-109	57-109	57-1090	57-111	57-111	57-1110
	57-113	57-113	57-113	57-1130	57-115	57-115	57-1150	57-117	57-117	57-117	57-1170	57-119	57-119	57-1190
	57-121	57-121	57-121	57-1210	106-10	106-10	106-100	106-14	106-14	106-14	106-140	107-18	107-18	107-180
	107-21	107-21	107-21	107-210	116-5	116-5	116-50	116-9	116-9	116-9	116-90	118-104	118-104	118-1040
	118-1040	119-3	119-3	119-30	119-10	119-10	119-100	119-16	119-16	119-16	119-160	120-8	120-8	120-80
	127-23	127-23	127-23	127-230	128-10	128-10	128-100	128-12	128-12	128-12	128-120	129-8	129-8	129-80
	129-13	129-13	129-13	129-130	129-15	129-15	129-150	130-3	130-3	130-3	130-30	130-5	130-5	130-50
	130-83	130-83	130-83	130-830	130-84	130-84	130-840	130-840	131-3	131-3	131-30	131-14	131-14	131-140
	132-6	132-6	132-6	132-60	133-12	133-12	133-120	134-2	134-2	134-2	134-20	134-8	134-10	134-100
	134-100	135-10	135-10	135-100	135-10	135-100	135-100	135-10	135-10	135-10	135-100	135-10	135-10	135-100
T8NSO	30-260	33-16	34-30	118-104	119-30	129-15	130-30	130-84	131-30	135-10	57-260	57-28	57-300	57-32
T8NSI	32-100	32-17	33-100	33-14	57-140	57-16	57-180	57-20	57-220	57-24	57-260	57-28	57-300	57-32
	57-340	57-36	57-380	57-40	57-420	57-44	57-460	57-48	57-500	57-57	57-590	57-62	57-640	57-76
	57-760	57-80	57-820	57-84	57-860	57-88	57-900	57-92	57-940	57-97	57-990	57-101	57-1030	57-105
	57-1070	57-109	57-1110	57-113	57-1150	57-117	57-1190	57-121	106-100	106-14	107-180	107-21	116-50	116-9
	119-100	119-16	120-80	127-23	128-100	128-12	129-80	129-13	130-50	130-83	131-140	132-6	133-120	134-2
	134-4	134-6	134-8	134-10										
T8PCNT	136-10	136-3	136-3	136-30										
T8PTAB	136-3	136-30												
T8PTHV	30-34	136-130												
T8PTNU	30-80	136-3	136-30	136-13	136-13									
T8SAVL	30-80													
T8SEGL	30-80													
T8SIZE	135-8	136-130												
T8SUBN	30-80	130-50												
T8TAGL	30-80													
T8TAGN	30-80	32-10	32-10	32-100	33-10	33-10	33-100	57-14	57-14	57-140	57-18	57-18	57-180	57-22
	57-22	57-220	57-26	57-26	57-260	57-30	57-30	57-300	57-34	57-34	57-340	57-38	57-38	57-380
	57-42	57-42	57-420	57-46	57-46	57-460	57-50	57-50	57-500	57-59	57-59	57-590	57-64	57-64
	57-640	57-78	57-78	57-780	57-82	57-82	57-820	57-86	57-86	57-860	57-90	57-90	57-900	57-94
	57-94	57-940	57-99	57-99	57-990	57-103	57-103	57-1030	57-107	57-107	57-1070	57-111	57-111	57-1110
	57-115	57-115	57-1150	57-119	57-119	57-1190	106-10	106-10	106-100	107-18	107-18	107-180	116-5	116-5
	116-50	119-10	119-10	119-100	120-8	120-8	120-80	128-10	128-10	128-100	129-8	129-8	129-80	130-5
	130-5	130-50	131-14	131-14	131-140	133-12	133-12	133-120	136-1	136-1	136-10	136-3	136-3	136-3
	136-3	136-30	136-30											
T8TEMP	31-9	31-9	31-90	31-90	32-17	32-170	33-14	33-140	33-16	33-160	57-16	57-160	57-20	57-200
	57-24	57-240	57-28	57-280	57-32	57-320	57-36	57-360	57-40	57-400	57-44	57-440	57-48	57-480
	57-57	57-570	57-62	57-620	57-76	57-760	57-80	57-800	57-84	57-840	57-88	57-880	57-92	57-920
	57-97	57-970	57-101	57-1010	57-105	57-1050	57-109	57-1090	57-113	57-1130	57-117	57-1170	57-121	57-1210
	106-14	106-140	107-21	107-210	116-9	116-90	118-1	118-1	118-1	118-10	118-10	118-10	118-100	118-1000
	119-16	119-160	126-14	126-140	127-23	127-230	128-12	128-120	129-13	129-130	129-15	129-150	130-10	130-100
	130-10	130-100	130-100	130-100	130-22	130-220	130-28	130-280	130-31	130-31	130-31	130-310	130-310	130-3100
	130-44	130-44	130-44	130-440	130-440	130-440	130-82	130-820	130-83	130-830	130-84	130-840	132-1	132-1
	132-1	132-10	132-10	132-10	132-2	132-2	132-2	132-20	132-20	132-20	132-3	132-3	132-3	132-30
	132-30	132-30	132-4	132-4	132-4	132-40	132-40	132-40	132-5	132-5	132-5	132-50	132-50	132-50
	132-6	132-60	134-1	134-1	134-1	134-10	134-10	134-10	134-3	134-3	134-3	134-30	134-30	134-30
	134-5	134-5	134-5	134-50	134-50	134-50	134-7	134-7	134-7	134-70	134-70	134-70	134-10	134-100
	135-10	135-100												
T8TEST	30-80	130-5	130-5	130-50	135-8									
T8STM	30-80	57-16	57-20	57-24	57-28	57-32	57-36	57-40	57-44	57-48	57-57	57-62	57-76	57-80
	57-84	57-88	57-92	57-97	57-101	57-105	57-109	57-113	57-117	57-121	59-7	59-8	62-11	62-12



UDAIRA	113-9	113-37					
UDAIRC	113-15	113-24	113-37	113-42			
UDAIRX	113-43	113-46					
UDAISE	111-35	112-9	112-11	112-19			
UDAISG	111-32	112-5					
UDAISL	112-8	112-16					
UDAIST	109-28	111-12					
UDAISX	112-14	112-18					
UDARS1	114-25	114-29	114-32	114-34			
UDARS2	114-26	115-3					
UDARSD	57-60	57-61	112-3	112-12	112-13	114-19	114-25 115-16
UDARSE	114-37	115-6					
UDARSP	109-41	112-8	114-18				
UDARSX	115-4	115-11					
UDASRV	107-18	122-23					
UF.576	42-12						
UF.CMR	42-3						
UF.CMW	42-4						
UF.INA	42-6						
UF.RPL	42-5						
UF.SCH	42-7						
UF.SCL	42-8						
UF.MBN	42-9						
UF.WPH	42-10						
UF.WPS	42-11						
UFREEZ	50-21	63-35	66-5	66-13	74-21	74-23	
URNING	50-18	63-16	63-31	63-40	66-32		
URUN	50-17	63-15	63-20	65-7			
WAITHS	99-8	104-11					
WQUES	53-6	130-10					
WSTOP	54-18	74-40					
WSTRT	54-21	130-6					
X1ALMA	30-8						
X1FALS	30-8						
X1OFFS	30-8	134-2	134-4	134-6	134-8		
X1TRUE	30-8	134-2	134-4	134-6	134-8		
X1	55-5	57-15					
X10	55-13	57-39					
X100	55-41	57-116					
X101	55-42	57-120					
X14	55-14	57-43					
X1A	55-1	57-15					
X2	55-6	57-19					
X20	55-18	57-47					
X21	55-22	57-56					
X22	55-24	57-61					
X23A	55-26	57-65					
X23B	55-30	57-69					
X24	55-31	57-79					
X25	55-33	57-83					
X2A	55-2	57-19					
X3	55-7	57-23					
X30	55-35	57-87					
X31	55-36	57-91					
X32	55-37	57-95					
X36	55-38	57-108					

X37	55 40*	57-112	
X3A	55-3*	57-23	
X4	55-8*	57-27	
X8	55 10*	57-31	
X8A	55-4*	57-31	
X9	55-11*	57-35	
XFRU	56-8*	57-75	90-5
XMSG1	56-1*	57-136	
XMSG2	56-2*	57-140	
XPKT1	56-3*	57-123	
XPKT2	56-6*	57-129	
XSA	56-7*	91-5	
YEAR19	51-31*	118-92	
YEAR20	51-32*	118-95	
YER1	118-69*	118-82	
YER2	118-70	118-72	118-83*
YER3	118-86	118-92*	
YER4	118-94	118-96*	118-99
YER5	118-91	118-97	118-100* 118-101



GPHARD	121 15	124 4												
GPRMA	132 1	132 2												
GPRMD	118 1	118 10	130 31	130 310	130 44	130 440	132 3	132 4	132 5					
GPRML	130 10	130 100	134 1	134 3	134 5	134 7								
HEADER	30 34													
ITEM	35 240	45 12	45 13	45 16	45 19	45 20	45 21	45 22	45 34	45 35	45 36	45 37	45 38	45 39
	45 40	45 41	45 42	45 43	45 44	45 45	45 46	45 47	46 9	46 10	46 13	131 20	131 21	131 22
	131 23	131 24	133 18											
LASTAD	135 8													
M8BYTE	30 34	30 34	30 34	30 340										
M8CMC	126 14	126 140	130 22	130 220	130 28	130 280	130 82	130 820						
M8CNT0	118 1	118 10	130 10	130 100	130 31	130 310	130 44	130 440	132 1	132 10	132 2	132 20	132 3	132 30
	132 4	132 40	132 5	132 50	134 1	134 10	134 3	134 30	134 5	134 50	134 7	134 70		
M8COUN	95 12	95 120	95 14	95 140	95 16	95 160	95 18	95 180	130 64	130 640				
M8DATA	30 34	30 34	30 34	30 34	30 34	30 34	30 34	30 34	30 34	30 34	30 34	30 34	30 34	30 34
	30 34	30 34	30 34	30 34	30 34	30 34	30 34	30 34	30 34	30 34	30 34	30 34	30 34	30 34
	30 34	30 34	30 34	30 34	30 34	30 34	30 34	30 34	30 34	30 340	30 340	52 12	52 120	52 16
M8DECR	52 160													
	32 17	32 170	33 14	33 140	33 16	33 160	57 16	57 160	57 20	57 200	57 24	57 240	57 28	57 280
	57 32	57 320	57 36	57 360	57 40	57 400	57 44	57 440	57 48	57 480	57 57	57 570	57 62	57 620
	57 76	57 760	57 80	57 800	57 84	57 840	57 88	57 880	57 92	57 920	57 97	57 970	57 101	57 1010
	57 105	57 1050	57 109	57 1090	57 113	57 1130	57 117	57 1170	57 121	57 1210	106 14	106 140	107 21	107 210
	116 9	116 90	118 104	118 1040	119 16	119 160	127 23	127 230	128 12	128 120	129 13	129 130	129 15	129 150
M8DEFA	130 83	130 830	130 84	130 840	132 6	132 60	134 10	134 100	135 10	135 100	136 3	136 30		
	118 1	118 10	130 10	130 100	130 31	130 310	130 44	130 440	132 1	132 10	132 2	132 20	132 3	132 30
	132 4	132 40	132 5	132 50	134 1	134 10	134 3	134 30	134 5	134 50	134 7	134 70		
M8ENDE	32 170	33 140	33 160	57 160	57 200	57 240	57 280	57 320	57 360	57 400	57 440	57 480	57 570	57 620
	57 760	57 800	57 840	57 880	57 920	57 970	57 1010	57 1050	57 1090	57 1130	57 1170	57 1210	106 140	107 210
M8ERRI	116 90	118 1040	127 230	128 120	129 130	129 150	130 830	130 840	132 60	134 100	135 100			
	59 7	59 70	62 28	62 280	65 24	65 240	66 36	66 360	67 21	67 210	68 8	68 80	72 22	72 220
	74 32	74 320	100 3	100 30	104 29	104 290	105 5	105 50	109 35	109 350	109 54	109 540	110 11	110 110
	111 33	111 330	113 44	113 440	114 36	114 360	115 5	115 50	127 3	127 30	127 8	127 80	127 14	127 140
M8EXCP	127 20	127 200	130 21	130 210	130 27	130 270								
	118 1	118 1	118 10	130 31	130 31	130 310	130 44	130 44	130 440	132 1	132 1	132 10	132 2	132 2
	132 20	132 3	132 3	132 30	132 4	132 4	132 40	132 5	132 5	132 50				
M8EXIT	126 14	126 140	130 22	130 220	130 28	130 280	130 82	130 820						
M8FXSE	126 140	130 220	130 280	130 820										
M8EXTJ	126 140	130 220	130 280	130 820										
M8GEN	30 34	30 34	30 34	30 34	30 34	30 34	30 34	30 34	30 34	30 34	30 34	30 34	30 34	30 34
	30 34	30 34	30 34	30 34	30 34	30 34	30 34	30 34	30 34	30 34	30 34	30 34	30 34	30 34
	30 34	30 34	30 34	30 34	30 34	30 34	30 34	30 34	30 34	30 34	30 340	30 340	30 340	30 340
	30 340	30 340	30 340	30 340	30 340	30 340	30 340	30 340	30 340	30 340	30 340	30 340	30 340	30 340
	30 340	30 340	30 340	30 340	30 340	30 340	30 340	30 340	30 340	30 340	30 340	30 340	30 340	30 340
	30 340	30 340	30 340	30 340	30 340	30 340	30 340	30 340	30 340	30 340	30 340	30 340	30 340	30 340
	33 10	33 10	33 100	33 100	33 14	33 140	52 12	52 120	52 16	52 160	57 14	57 140	57 16	57 160
	57 18	57 180	57 20	57 200	57 22	57 220	57 24	57 240	57 26	57 260	57 28	57 280	57 30	57 300
	57 32	57 320	57 34	57 340	57 36	57 360	57 38	57 380	57 40	57 400	57 42	57 420	57 44	57 440
	57 46	57 460	57 48	57 480	57 50	57 500	57 57	57 570	57 59	57 590	57 62	57 620	57 64	57 640
	57 76	57 760	57 78	57 780	57 80	57 800	57 82	57 820	57 84	57 840	57 86	57 860	57 88	57 880
	57 90	57 900	57 92	57 920	57 94	57 940	57 97	57 970	57 99	57 990	57 101	57 1010	57 103	57 1030
	57 105	57 1050	57 107	57 1070	57 109	57 1090	57 111	57 1110	57 113	57 1130	57 115	57 1150	57 117	57 1170
	57 119	57 1190	57 121	57 1210	106 10	106 100	106 14	106 140	107 18	107 180	107 21	107 210	116 5	116 50
	116 9	116 90	118 1	118 10	119 10	119 100	120 8	120 80	127 23	127 230	128 10	128 100	128 12	128 120
	129 8	129 80	129 13	129 130	130 5	130 50	130 10	130 100	130 31	130 310	130 44	130 440	130 83	130 830
	131 14	131 140	132 6	132 60	133 12	133 120	134 10	134 100	135 8	135 80	136 3	136 30	136 11	136 110
M8GENE	118 1	118 10	130 10	130 100	130 31	130 310	130 44	130 440						





	121 15	121 15	121-150	121-150	121-150	121 16	121-160	124-4	124-4	124-40	124 40	124-40	124-5	124 50
	126 12	126-12	126-120	126-120	126-14	126-14	126-140	127-3	127-3	127-3	127-3	127-3	127-30	127-30
	127-30	127-30	127-30	127-4	127 40	127-8	127-8	127-8	127-8	127-80	127-80	127-80	127-80	127-80
	127 9	127-90	127-14	127-14	127-14	127 14	127-140	127-140	127-140	127-140	127-140	127-15	127-150	127-20
	127 20	127-20	127-20	127-200	127-200	127-200	127-200	127-21	127-210	127-23	127-230	127-230	128-12	128-120
	129 13	129-130	130-7	130-70	130-8	130-80	130-10	130 10	130-10	130-10	130-10	130-10	130-100	130-100
	130 100	130-100	130-19	130-190	130-20	130-200	130-21	130-21	130-21	130 21	130-210	130 210	130-210	130-210
	130 210	130-22	130-22	130-220	130-220	130-27	130 27	130-27	130-27	130-270	130 270	130 270	130-270	130-270
	130 28	130-28	130-280	130-280	130-31	130-31	130-31	130-31	130-31	130-31	130-31	130-31	130-310	130-310
	130 310	130-310	130-32	130-32	130-320	130-320	130-44	130-44	130-44	130-44	130-44	130-44	130-44	130-44
	130-440	130-440	130-440	130-440	130-64	130-64	130-64	130-64	130-64	130-64	130-640	130-640	130-640	130 640
	130-640	130-82	130-82	130-820	130-820	130-83	130-830	131-14	131-140	132 1	132-1	132-1	132-1	132-10
	132-2	132-2	132-2	132-2	132-20	132 3	132-3	132-3	132-3	132-3	132-30	132-4	132-4	132-4
	132-4	132 4	132-40	132-5	132-5	132-5	132-5	132-5	132-50	132-6	132-60	133-12	133-120	134-1
	134-1	134-1	134-10	134-2	134-20	134-3	134-3	134-3	134-30	134-4	134-40	134-5	134-5	134-5
	134 50	134-6	134-60	134-7	134-7	134 7	134-70	134-8	134-80	134-9	134-9	134-90	134-90	134 10
	134 100	135-8	135-8	135-8	135-80	136-3	136-3	136-30	136-30					
MIGNLS	118-1	118-10	130-10	130-100	130-31	130-310	130-44	130-440						
MIGNTA	32-17	32-170	33-14	33 140	57-16	57-160	57-20	57-200	57-24	57-240	57-28	57-280	57-32	57-320
	57 36	57-360	57-40	57-400	57-44	57-440	57-48	57-480	57-57	57-570	57-62	57-620	57-76	57-760
	57-80	57-800	57-84	57-840	57-88	57-880	57-92	57-920	57-97	57-970	57-101	57-1010	57-105	57-1050
	57-109	57-1090	57-113	57-1130	57-117	57-1170	57-121	57-1210	106-14	106-140	107-21	107-210	116-9	116-90
	127 23	127-230	128-12	128-120	129-13	129-130	130-83	130-830	132-6	132-60	134-10	134-100	136 3	136-30
	136-11	136-110												
MIGNTE	130-5	130-50												
MHNAPT	30-34	30-340												
MHNAP	30-34	30-340												
MSINCR	30 26	30-260	32-10	32-10	32-100	32-100	33-10	33-10	33-100	33-100	34-3	34-30	57-14	57-14
	57-140	57-140	57-160	57-18	57-18	57-180	57-180	57-200	57-22	57-22	57-220	57-220	57-240	57-26
	57-26	57-260	57-260	57-280	57-30	57-30	57-300	57-300	57-320	57-34	57-34	57-340	57-340	57-360
	57-38	57-38	57-380	57-380	57-400	57-42	57-42	57-420	57-420	57-440	57-46	57-46	57-460	57-460
	57-480	57-50	57-50	57-500	57-500	57-570	57-59	57-59	57-590	57-590	57-620	57-64	57-64	57-640
	57-640	57-760	57-78	57-78	57-780	57-780	57-800	57-82	57-82	57-820	57-820	57-840	57-86	57-86
	57-860	57-860	57-880	57-90	57-90	57-900	57-900	57-920	57-94	57-94	57-940	57-940	57-970	57-99
	57-99	57-990	57-990	57-1010	57-103	57-103	57-1030	57-1030	57-1050	57-107	57 107	57-1070	57-1070	57 1090
	57-111	57-111	57-1110	57-1110	57-1130	57-115	57-115	57-1150	57-1150	57-1170	57-119	57-119	57-1190	57 1190
	57 1210	59-70	59 80	62-110	62-120	62-220	62-280	62-300	64-120	65-80	65-240	66-360	67 210	68-80
	72-220	74-320	77-190	77-200	77-240	95-120	95-140	95-160	95-180	98-200	100-30	104-210	104-290	105 50
	106-10	106-10	106-100	106-100	107-18	107-18	107-180	107-180	109-350	109-540	110-110	111-120	111 270	111-300
	111-330	113-440	114-270	114-360	115-50	116-5	116-5	116-50	116-50	118-1	118-10	118 10	119-3	119-30
	119-10	119-10	119-100	119-100	120-8	120-8	120-80	120-80	120-100	120-120	120-140	120 160	120-180	120-320
	120-410	120-430	120-520	121-150	124-40	126-120	126-140	127-30	127-40	127-80	127-90	127-140	127 150	127-200
	127-210	127-230	128-10	128-10	128-100	128-100	128-120	129-8	129-8	129-80	129-80	129-130	130 3	130-30
	130-5	130-5	130-5	130-50	130-50	130-50	130-70	130-10	130-100	130-100	130-190	130-210	130-220	130 270
	130-280	130-31	130-310	130-310	130-320	130-44	130-440	130-440	130-640	130-820	130-830	131-3	131-30	131-14
	131-14	131-140	131-140	133-12	133-12	133-120	133-120	136-1	136-10	136-3	136-3	136-3	136-30	136-30
MSLDRO	62-22	62-220	77-20	77-200	111-30	111-300	120-10	120-100	120-12	120-120	120-14	120-140	120-16	120-160
	120-41	120-410	120-43	120-430	121-15	121-150	124-4	124-40	126-12	126-120	130-32	130 320		
MSMCHI	30-8	30-80												
MSMCLO	30-8	30-80												
MSPOP	32-17	32-170	33-14	33-140	33-16	33-160	57-16	57-160	57-20	57-200	57-24	57-240	57-28	57-280
	57-32	57-320	57-36	57-360	57-40	57-400	57-44	57-440	57-48	57-480	57 57	57-62	57-620	57-620
	57-76	57-760	57-80	57-800	57-84	57-840	57-88	57-880	57-92	57-920	57-97	57-970	57-101	57-1010
	57-105	57-1050	57-109	57-1090	57-113	57-1130	57-117	57-1170	57-121	57-1210	106-14	106-140	107-21	107-210
	116-9	116-90	118-104	118-1040	119-16	119-160	127-23	127-230	128-12	128-120	129-13	129-130	129-15	129-150
	130-83	130-830	130 84	130-840	132-6	132-60	134-10	134-100	135-10	135-100				

MSPRIN	95-12	95-120	95-14	95-140	95-16	95-160	95-18	95-180	130-64	130-640				
MSPUSH	30-26	30-260	32-10	32-100	33-10	33-100	34-3	34-30	57-14	57-140	57-18	57-180	57-22	57-220
	57-26	57-260	57-30	57-300	57-34	57-340	57-38	57-380	57-42	57-420	57-46	57-460	57-50	57-500
	57-59	57-590	57-64	57-640	57-78	57-780	57-82	57-820	57-86	57-860	57-90	57-900	57-94	57-940
	57-99	57-990	57-103	57-1030	57-107	57-1070	57-111	57-1110	57-115	57-1150	57-119	57-1190	106-10	106-100
	107-18	107-180	116-5	116-50	119-3	119-30	119-10	119-100	120-8	120-80	128-10	128-100	129-8	129-80
	130-3	130-30	130-5	130-50	131-3	131-30	131-14	131-140	133-12	133-120				
MSPUT	62-11	62-11	62-11	62-11	62-110	95-12	95-12	95-12	95-120	95-14	95-14	95-14	95-140	95-16
	95-16	95-16	95-160	95-18	95-18	95-18	95-180	98-20	98-20	98-20	98-20	98-200	111-27	111-27
	111-27	111-27	111-270	120-52	120-52	120-52	120-52	120-520	130-64	130-64	130-64	130-640		
MSPUT1	62-11	62-11	62-11	62-11	62-110	62-110	62-110	62-110	95-12	95-12	95-12	95-120	95-120	95-120
	95-14	95-14	95-14	95-140	95-140	95-140	95-16	95-16	95-16	95-160	95-160	95-160	95-18	95-18
	95-18	95-180	95-180	95-180	98-20	98-20	98-20	98-20	98-200	98-200	98-200	98-200	111-27	111-27
	111-27	111-27	111-270	111-270	111-270	111-270	120-52	120-52	120-52	120-52	120-520	120-520	120-520	120-520
	130-64	130-64	130-64	130-640	130-640	130-640								
MIRACI	118-1	118-10	130-10	130-100	130-31	130-310	130-44	130-440	132-1	132-10	132-2	132-20	132-3	132-30
	132-4	132-40	132-5	132-50	134-1	134-10	134-3	134-30	134-5	134-50	134-7	134-70		
MIRBRO	77-24	77-240												
MIRBRO	120-32	120-320	120-41	120-410	120-43	120-430	121-15	121-150	124-4	124-40				
MIRBRO	30-26	30-260	32-10	32-100	33-10	33-100	34-3	34-30	57-14	57-140	57-18	57-180	57-22	57-220
MIRBRO	57-26	57-260	57-30	57-300	57-34	57-340	57-38	57-380	57-42	57-420	57-46	57-460	57-50	57-500
MIRBRO	57-59	57-590	57-64	57-640	57-78	57-780	57-82	57-820	57-86	57-860	57-90	57-900	57-94	57-940
MIRBRO	57-99	57-990	57-103	57-1030	57-107	57-1070	57-111	57-1110	57-115	57-1150	57-119	57-1190	106-10	106-100
MIRBRO	107-18	107-180	116-5	116-50	119-3	119-30	119-10	119-100	120-8	120-80	128-10	128-100	129-8	129-80
MIRBRO	130-3	130-30	130-5	130-50	131-3	131-30	131-14	131-140	133-12	133-120				
MIRBRO	57-16	57-160	57-20	57-200	57-24	57-240	57-28	57-280	57-32	57-320	57-36	57-360	57-40	57-400
MIRBRO	57-44	57-440	57-48	57-480	57-52	57-520	57-56	57-560	57-60	57-600	57-64	57-640	57-68	57-680
MIRBRO	57-88	57-880	57-92	57-920	57-96	57-960	57-100	57-1000	57-104	57-1040	57-108	57-1080	57-112	57-1120
MIRBRO	57-117	57-1170	57-121	57-1210	59-7	59-70	59-8	59-80	62-11	62-110	62-12	62-120	62-16	62-160
MIRBRO	62-30	62-300	64-12	64-120	65-8	65-80	65-24	65-240	66-36	66-360	67-21	67-210	68-8	68-80
MIRBRO	77-20	77-200	77-24	77-240	95-12	95-120	95-14	95-140	95-16	95-160	95-18	95-180	98-20	98-200
MIRBRO	100-3	104-21	104-210	104-29	105-5	109-35	109-54	110-11	111-12	111-120	111-27	111-270	111-30	111-300
MIRBRO	111-33	113-44	114-27	114-270	114-36	115-5	118-1	118-10	120-10	120-100	120-12	120-120	120-14	120-140
MIRBRO	120-16	120-160	120-18	120-180	120-32	120-320	120-41	120-410	120-43	120-430	120-52	120-520	121-15	121-150
MIRBRO	124-4	124-40	126-12	126-120	126-14	126-140	127-3	127-4	127-40	127-8	127-9	127-90	127-14	127-15
MIRBRO	127-150	127-20	127-21	127-210	127-23	127-230	128-12	128-120	129-13	129-130	130-7	130-70	130-10	130-100
MIRBRO	130-19	130-190	130-21	130-210	130-22	130-220	130-27	130-270	130-31	130-310	130-32	130-320	130-44	130-440
MIRBRO	130-64	130-640	130-82	130-820	130-83	130-830								
MIRBRO	57-160	57-200	57-240	57-280	57-320	57-360	57-400	57-440	57-480	57-520	57-560	57-600	57-640	57-680
MIRBRO	57-880	57-920	57-960	57-1000	57-1040	57-1080	57-1120	57-1160	57-1200	59-70	59-80	62-110	62-120	62-220
MIRBRO	62-280	62-300	64-120	65-80	65-240	66-360	67-210	68-80	72-220	74-320	77-190	77-200	77-240	95-120
MIRBRO	95-140	95-160	95-180	98-200	100-30	104-210	104-290	105-50	109-350	109-540	110-110	111-120	111-270	111-300
MIRBRO	111-330	113-440	114-270	114-360	115-50	118-10	120-100	120-120	120-140	120-160	120-180	120-320	120-410	120-430
MIRBRO	120-520	121-150	124-40	126-120	126-140	127-30	127-40	127-80	127-90	127-140	127-150	127-200	127-210	127-230
MIRBRO	128-120	129-130	130-70	130-100	130-190	130-210	130-220	130-270	130-280	130-310	130-320	130-440	130-640	130-820
MIRBRO	130-830													
MIRBRO	57-16	57-160	57-20	57-200	57-24	57-240	57-28	57-280	57-32	57-320	57-36	57-360	57-40	57-400
MIRBRO	57-44	57-440	57-48	57-480	57-52	57-520	57-56	57-560	57-60	57-600	57-64	57-640	57-68	57-680
MIRBRO	57-88	57-880	57-92	57-920	57-96	57-960	57-100	57-1000	57-104	57-1040	57-108	57-1080	57-112	57-1120
MIRBRO	57-117	57-1170	57-121	57-1210	59-7	59-70	59-8	59-80	62-11	62-110	62-12	62-120	62-16	62-160
MIRBRO	62-220	62-28	62-280	62-280	62-30	62-300	64-12	64-120	65-8	65-80	65-24	65-240	65-240	66-36
MIRBRO	66-360	66-360	67-21	67-210	67-210	68-8	68-80	68-80	72-22	72-220	72-220	74-32	74-320	74-320
MIRBRO	77-19	77-190	77-20	77-200	77-24	77-240	95-12	95-120	95-14	95-140	95-16	95-160	95-18	95-180
MIRBRO	98-20	98-200	100-3	100-30	100-30	104-21	104-210	104-29	104-290	104-290	105-5	105-50	105-50	109-35
MIRBRO	109-350	109-350	109-54	109-540	109-540	110-11	110-110	110-110	111-12	111-120	111-27	111-270	111-30	111-300
MIRBRO	111-33	111-330	111-330	113-44	113-440	113-440	114-27	114-270	114-36	114-360	114-360	115-5	115-50	115-50

