


VT06

DISPLAY TERMINAL TESTS
MD-11-D6D-B

EP-D6D-DL
COPYRIGHT © 1971
FICHE 1 OF 1

FEB 1978
digital
MADE IN USA



IDENTIFICATION

PRODUCT CODE: MAINDEC-11-D6DB-D
PRODUCT NAME: VT06 DISPLAY TERMINAL TESTS
DATE: JULY, 1971
MAINTAINER: DIAGNOSTIC GROUP
AUTHOR: J. FRIEDRICH

COPYRIGHT © 1971
DIGITAL EQUIPMENT CORPORATION

NOTE: THIS PROGRAM IS A MODIFIED VERSION OF THE TELETYPE DIAGNOSTIC
MAINDEC-11-D2AA

1. ABSTRACT

THE VT06 DISPLAY TERMINAL TESTS CONSISTS OF A PACKAGE OF TEST
PROGRAMS DESIGNED TO TEST THE VT06 INPUT-OUTPUT LOGIC, THE VT06
DISPLAY, AND THE KEYBOARD, ALL TESTS ARE INCLUDED IN ONE OBJECT
TAPE.

THE AVAILABLE TEST PROGRAMS ARE LISTED HERE IN NUMERICAL ORDER:

PRG0-COMBINED INPUT-OUTPUT LOGIC TESTS

PRG1-DISPLAY TEST

PRG2-KEYBOARD TEST

PRG3-PRINTER EXERCISER

PRG4-CLOCK ADJUSTMENT ROUTINE

PRG5-CLOCK ADJUSTMENT ROUTINE

PRG6-MAINTENANCE MODE SINGLE CHARACTER DATA TEST,

PRG7-MAINTENANCE MODE SPECIAL BINARY COUNT PATTERN TEST,

PRG10-ROLL-UP DISPLAY TEST

2. REQUIREMENTS

2.1 EQUIPMENT

A. PDP-11,20 SYSTEM, (4 K CORE),

B. VT06 DISPLAY TERMINAL

C. HIGH SPEED READER

THE VT06 MUST HAVE STANDARD TELETYPE ADDRESSES, REFER TO
SECTION 7.3 IF THE VT06 DOES NOT HAVE STANDARD PERIPHERAL
ADDRESSES,

2.2 STORAGE

THIS PROGRAM USES LOCATION 00200 THROUGH 11672.

3. LOADING PROCEDURE

THIS PROGRAM'S OBJECT TAPE IS PUNCHED IN ABSOLUTE FORMAT,
THE ABS LOADER IS USED TO LOAD THE PROGRAM,

4. USE PROCEDURE
-----4.1 VT06 IDENTIFICATION

THIS TEST DIAGNOSTIC ASSUMES THE VT06 IS A KSR35 WITH CURSOR CHARACTERS AND LOCATION 000224 IS SET TO 000001.

4.2 PRGM USE PROCEDURE

- A, SET VT06 TO ON-LINE.
- B, LOAD ADDRESS 000200
- C, SET SR TO 000000, PRESS START
- D, THE PROGRAM STOPS AT COMMON HALT.
- E, SET ANY DESIRED SR OPTIONS, NORMAL RUN IS WITH SR = 000000.

THIS PROGRAM'S SR OPTIONS ARE:

SR15	HALT AT END OF ROUTINE
SR14	ENTER SCOPE MODE AFTER ERROR
SR11	INHIBIT ITERATION
SR10	LOOP PROGRAM
SR9	SELECT ROUTINE
SR6 THROUGH SR0	= NUMBER OF ROUTINE TO BE SELECTED.

SECTION 7.2 GIVES A COMPLETE EXPLANATION OF SR OPTIONS.

- F, PRESS CONTINUE, THE PROGRAM IS EXECUTED AND STOPS AT PROGRAM END HALT WHEN COMPLETED, PROVIDED NO ERRORS OCCUR.
- G, REFER TO SECTION 6, IF ERRORS OCCUR.

A DESCRIPTION OF THIS PROGRAM IS GIVEN IN SECTION 8.1

EXECUTION TIME:

ONE NORMAL ERROR FREE PASS TAKES APPROXIMATELY 4 MINUTES.

4.3 PRG1 USE PROCEDURE

- A. SET VT06 TO ON-LINE
- B. LOAD ADDRESS 000200.
- C. SET SR TO 000001; PRESS START
- D. PROGRAM STOPS AT COMMON HALT.
- E. SET ANY DESIRED SR OPTIONS, NORMAL RUN IS WITH SR = 000000.

THIS PROGRAM'S SR OPTIONS ARE:

- SR15 HALT AT END OF ROUTINE
- SR10 LOOP PROGRAM
- SR9 SELECT ROUTINE
- SR6 THROUGH SR8 = NUMBER OF ROUTINE TO BE SELECTED.

SECTION 7.2 GIVES A COMPLETE EXPLANATION OF SR OPTIONS.

- F. PRESS CONTINUE, THE VT06 WILL BE EXERCISED AND THE PROGRAM WILL STOP AT PROGRAM END HALT WHEN COMPLETED.
- G. ERROR DETECTION IS BY VISUAL INSPECTION OF DISPLAY.

A DESCRIPTION OF THIS PROGRAM IS GIVEN IN SECTION 8.3

EXECUTION TIME:

ONE NORMAL PASS TAKES APPROXIMATELY 12 MINUTES.

4.2

PRG2 USE PROCEDURE

-
- A. SET VT06 ON-LINE.
 - B. LOAD ADDRESS 000200.
 - C. SET SR TO 000002; PRESS START
 - D. THE PROGRAM TYPES "KEYBOARD TEST" AND STOPS AT COMMON HALT.
 - E. SET ANY DESIRED SR OPTIONS, NORMAL RUN IS WITH SR = 000000.
THIS PROGRAM'S SR OPTIONS ARE:

SR15 HALT AT END OF ROUTINE
SR10 LOOP PROGRAM
SR9 SELECT ROUTINE
SR6 THROUGH SR0 = NUMBER OF ROUTINE TO BE SELECTED.

SECTION 7.2 GIVES A COMPLETE EXPLANATION OF SR OPTIONS.

- F. PRESS CONTINUE, FOLLOW TYPED INSTRUCTIONS, WHEN DONE PROGRAM STOPS AT PROGRAM END HALT.

A DESCRIPTION OF THIS PROGRAM IS GIVEN IN SECTION 8.5

EXECUTION TIME:

PROGRAM IS USER DEPENDENT.

4.3

PRG3 USE PROCEDURE

- A. SET VT06 TO ON-LINE
- B. LOAD ADDRESS 000200
- C. SET SR TO 000003, PRESS START
- D. THE PROGRAM TYPES "TYPE IN DATA"
- E. KEY IN ANY FIVE CHARACTERS TO BE TYPED.
- F. KEY IN EITHER A RUBOUT FOR FULL SPEED TYPING, OR ANY OTHER CHARACTER FOR RANDOM STALLS BETWEEN CHARACTERS.
- G. THE PROGRAM TYPES CONTINUOUSLY LINES CONTAINING THE FIVE CHARACTERS SPECIFIED, UNTIL SR15 IS SET TO A 1. AT THAT POINT THE PROGRAM GOES TO STEP E.

A DESCRIPTION OF THIS PROGRAM IS GIVEN IN SECTION 0.0

4.4 PRG4 USE PROCEDURE

PRG4 IS USED AS AN AID IN ADJUSTING THE TRANSMITTER CLOCK,
AND IN OBSERVING THE DATA BITS AS THEY ARE SHIFTED OUT OF THE
TRANSMITTER BUFFER, A SCOPE IS REQUIRED.

TO ADJUST THE PUNCH CLOCK PROCEED AS FOLLOWS!

- A. LOAD ADDRESS 000200
- B. SET SR TO 00004, PRESS START,
- C. PROGRAM STOPS AT COMMON HALT,
- D. SET ANY DESIRED ASCII CODE IN LEFT HALF OF SR,
- E. SET NUMBER OF MILLISECONDS TO DELAY BETWEEN PUNCH COMMANDS
IN RIGHT HALF OF SR, THE NUMBER OF MILLISECONDS SELECTED
SHOULD BE LONG ENOUGH FOR THE ENTIRE PUNCH OPERATION TO
COMPLETE, A SUGGESTED STARTING NUMBER IS 177,
- F. PRESS CONTINUE, THE PROGRAM RUNS CONTINUOUSLY, FIRST IT
LOADS THE PUNCH BUFFER WITH THE CHARACTER IN SR LEFT, AND
THEN DELAYS FOR THE NUMBER OF MILLISECONDS SPECIFIED IN SR
RIGHT BEFORE RELOADING THE PUNCH BUFFER AGAIN,
- G. SET UP A SCOPE AND DISPLAY THE PUNCH CLOCK PULSES, ADJUST
THE PUNCH CLOCK ACCORDING TO SPECIFICATIONS,

A DESCRIPTION OF THIS PROGRAM IS GIVEN IN SECTION 8.10

4,5

PRG5 USE PROCEDURE

PRG5 IS USED AS AN AID IN ADJUSTING THE RECEIVER CLOCK, AND IN OBSERVING THE DATA BITS AS THEY ARE SHIFTED INTO THE RECEIVER BUFFER, A SCOPE IS REQUIRED.

THE PROGRAM MAKES USE OF THE TRANSMIT MAINTENANCE BIT FEATURE IN ORDER TO CAUSE THE DATA OUTPUTTED TO THE TRANSMITTER BUFFER TO BE SHIFTED INTO THE RECEIVER BUFFER.

TO ADJUST THE RECEIVER CLOCK PROCEED AS FOLLOWS:

- A. LOAD ADDRESS 000200
- B. SET SR TO 000005, PRESS START,
- C. PROGRAM STOPS AT COMMON HALT,
- D. SET ANY DESIRED ASCII CODE IN LEFT HALF OF SR,
- E. SET NUMBER OF MILLISECONDS TO DELAY BETWEEN TRANSMIT COMMANDS IN RIGHT HALF OF SR, THE SELECTED NUMBER SHOULD BE LONG ENOUGH FOR THE ENTIRE TRANSMIT/RECEIVE OPERATION TO COMPLETE, A SUGGESTED STARTING NUMBER IS 177,
- F. PRESS CONTINUE, THE PROGRAM RUNS CONTINUOUSLY, FIRST IT LOADS THE TRANSMITTER BUFFER WITH THE CHARACTER IN SR LEFT, AND THEN DELAYS THE NUMBER OF MILLISECONDS SPECIFIED IN SR RIGHT, AS THE DATA BITS ARE SHIFTED OUT OF THE TRANSMITTER BUFFER, THE RECEIVER CLOCK STARTS, AND THE DATA BITS ARE SHIFTED INTO THE RECEIVER BUFFER, AT THE END OF THE DELAY THE PROGRAM MOVES THE RECEIVER BUFFER CONTENTS TO REG B, AND ISSUES 5 RESET INSTRUCTIONS IN ORDER TO MAKE THE RECEIVER BUFFER CONTENTS VISIBLE IN THE RIGHT HALF OF THE DATA LIGHTS.
- G. SET UP A SCOPE AND DISPLAY THE RECEIVER CLOCK PULSES, ADJUST THE RECEIVER CLOCK ACCORDING TO SPECIFICATIONS.

A DESCRIPTION OF THIS PROGRAM IS GIVEN IN SECTION 8.11

4.6 PRG6 USE PROCEDURE

-
- A. LOAD ADDRESS 000200.
 - B. SET SR TO 000006; PRESS START
 - C. THE PROGRAM STOPS AT COMMON MALT.
 - D. SET CODE FOR CHARACTER TO BE TESTED IN THE LEFT HALF OF THE SR.
 - E. PRESS CONTINUE, THE PROGRAM RUNS CONTINUOUSLY, OUTPUTTING THE CHARACTER TO THE OUTPUT BUFFER AND CHECKING THAT THE RECEIVE BUFFER CONTAINS THE SAME CHARACTER WHEN THE RECEIVE DONE BIT BECOMES SET.
 - F. REFER TO SECTION 6, ERRORS, IF ERRORS OCCUR.

A DESCRIPTION OF THIS PROGRAM IS GIVEN IN SECTION 8.12

EXECUTION TIME:

CONTINUOUS RUNNING PROGRAM,

4.7 PRG7 USE PROCEDURE

-
- A. LOAD ADDRESS 000200.
 - B. SET SR TO 000007; PRESS START
 - C. THE PROGRAM RUNS CONTINUOUSLY, THE SPECIAL BINARY COUNT PATTERN IS OUTPUTTED TO THE OUTPUT BUFFER, EACH TIME THE RECEIVE DONE BIT BECOMES SET THE CHARACTER IN THE RECEIVE BUFFER IS CHECKED TO SEE THAT IT MATCHES THE PREVIOUSLY OUTPUTTED CHARACTER, THE PROGRAM STALLS RANDOMLY BETWEEN CHARACTERS, TO RUN AT FULL SPEED, SET SR0 TO A 1.
 - D. REFER TO SECTION 6, ERRORS, IF ERRORS OCCUR.

A DESCRIPTION OF THIS PROGRAM IS GIVEN IN SECTION 8.13

EXECUTION TIME:

CONTINUOUS RUNNING PROGRAM,

4.10 PRG10 USER PROCEDURE

-
- A. LOAD ADDRESS 000200.
 - B. SET SR TO 000007; PRESS START
 - C. PROGRAM RUNS CONTINUOUSLY, THE SCREEN IS FILLED WITH ALTERNATE LINES OF A CHARACTER AND ITS COMPLEMENT AND A LINE OF THE COMPLEMENT OF THE CHARACTER FOLLOWED BY THE CHARACTER. THIS TEST VERIFIES THE ROLL-UP CAPABILITY OF THE VT06.
 - D. REFER TO SECTION 6, ERRORS, IF ERRORS OCCUR.

A DESCRIPTION OF THIS PROGRAM IS GIVEN IN SECTION 8.14

EXECUTION TIME:

CONTINUOUS RUNNING PROGRAM,

5. PROGRAM AND/OR OPERATOR ACTION

5.1 NORMAL HALTS

- LOC 001374 COMMON HALT, THIS HALT OCCURS WHENEVER THE PROGRAM IS AWAITING USER INTERVENTION. THE DATA LIGHTS CONTAIN THE ADDRESS OF INSTRUCTION THAT GENERATED THE CALL TO THE COMMON HALT.
- LOC 001504 END OF ROUTINE HALT, THIS HALT OCCURS AT THE END OF A TEST ROUTINE IF SR15 IS SET TO A 1. TO PROCEED, PRESS CONTINUE. PROGRAMS PRG0, PRG1, AND PRG2 USE THE ROUTINE END OPTION.
- LOC 002012 PROGRAM END HALT, THIS HALT NORMALLY OCCURS AT THE END OF PROGRAMS PRG0, PRG1, AND UNLESS THE LOOP PROGRAM OPTION IS SET, (SR10)

6. ERRORS

6.1 ERROR HALTS

- LOC 001406 UNCONDITIONAL ERROR HALT, DATA LIGHTS CONTAIN ADDRESS OF INSTRUCTION THAT GENERATED THE ERROR CALL, REFER TO PROGRAM LISTING.
- LOC 001466 CONDITIONAL ERROR HALT, THIS CALL WILL ALWAYS OCCUR, UNLESS SR14 IS SET TO A 1 (SCOPE MODE) AND THE ERROR HAS OCCURRED AT LEAST ONCE, DATA LIGHTS CONTAIN ADDRESS OF INSTRUCTION THAT GENERATED ERROR CALL, REFER TO PROGRAM LISTING.
- LOC 001426 DATA ERROR HALT, OCCURS WHEN A PROGRAM OR ROUTINE CHECKING DATA FINDS THAT THE EXPECTED AND THE RECEIVED DATA DO NOT AGREE, THE LEFT HALF OF THE DATA LIGHTS CONTAIN THE EXPECTED 8 BIT DATA, THE RIGHT HALF CONTAINS THE RECEIVED 8 BIT DATA.

6.2 NON RECOVERABLE ERROR HALTS

.....
 A NON-RECOVERABLE ERROR HALT WILL OCCUR AT THE ADDRESSES LISTED BELOW IF THROUGH HARDWARE OR SOFTWARE FAILURE, PROGRAM CONTROL IS TRANSFERRED TO AN UNEXPECTED AREA BETWEEN 000000 AND 000176.

000002 RESERVED AREA
 000006 ERROR TRAP
 000012 RESERVED INSTRUCTION TRAP
 000016 DEBUG TRAP
 000022 IOT TRAP
 000026 POWER FAIL TRAP
 000040 THROUGH 000176 SYSTEM SOFTWARE AND INTERRUPT VECTOR AREA, EXCEPT FOR KL11 INTERRUPT VECTORS,

TO FIND OUT WHERE THE PROGRAM WAS AT THE TIME THE FAILURE OCCURRED, PERFORM THE FOLLOWING STEPS:

- A. EXAMINE THE CONTENTS OF REGISTER 6 (ADDRESS 177706),
- B. TRANSFER THE CONTENTS OF REGISTER 6 TO THE SR, LOAD ADDRESS, AND EXAMINE,
- C. THE DATA SHOWN IN THE DATA LIGHTS IS THE VALUE OF THE PC WHEN THE FAILURE OCCURRED,
- D. LOCATE IN THE PROGRAM LISTING THE DISPLAYED PC VALUE,
- E. THE INSTRUCTION THAT IMMEDIATELY PRECEDES THE ONE REFERENCED BY THE DISPLAYED PC VALUE IS THE INSTRUCTION THAT WAS BEING EXECUTED WHEN THE FAILURE OCCURRED,

A NON-RECOVERABLE ERROR HALT FAILURE IS AN ABNORMAL CONDITION INDICATING A HARDWARE FAILURE, OR MOST UNLIKELY, A PROGRAM FAILURE. THIS PROGRAM ASSUMES THAT THE PROCESSOR IS IN OPERATING CONDITION IN ORDER TO TEST THE VTO6, ANY FURTHER STEPS TO DIAGNOSE A NON-RECOVERABLE ERROR ARE NOT WITHIN THE SCOPE OF THIS PROGRAM.

7. MISCELLANEOUS

7.1 SR OPTIONS

THE STANDARD SR OPTIONS ARE DESCRIBED HERE.

SR13 - HALT AT END OF ROUTINE, FOR THESE PROGRAMS CONSISTING OF A SET OF SEPARATE TEST ROUTINES, SR13 SET TO A 1 CAUSES THE PROGRAM TO HALT UPON COMPLETION OF THE ROUTINE CURRENTLY BEING EXECUTED. THREE POSSIBLE USES OF THIS OPTION ARE:

- A. TO STEP THROUGH A PROGRAM ONE ROUTINE AT A TIME;
- B. WHEN AN UNPREDICTED FAILURE HAS OCCURRED (BLOW UP, HANG UP), TO ADVANCE THROUGH THE PROGRAM ONE ROUTINE AT A TIME UNTIL THE FAILURE OCCURS, THE ROUTINE FOLLOWING THE LAST IDENTIFIED ROUTINE WOULD BE THE FAILING ROUTINE.
- C. WHEN A PROGRAM IS IN EXECUTION, TO DETERMINE HOW FAR THE PROGRAM HAS PROGRESSED.

SR14 - SCOPE, THIS OPTION IS USED ONLY BY PRGB. THE OPTION CAUSES THE PROGRAM TO BYPASS ERROR HALTS, AND TO STAY IN THE FAILING ROUTINE. THIS OPTION WILL NOT BECOME ACTIVE UNTIL AN ERROR OCCURS. SR14 MUST BE ON BEFORE THE ERROR OCCURS, OR AT LEAST IT MUST BE SET BEFORE PRESSING CONTINUE AFTER AN ERROR HALT.

(7,2 CONT'D)

- SR13** - INHIBIT ITERATION COUNT, THIS OPTION IS USED BY PRG0, PRG1, AND PRG3, THESE PROGRAMS CONSIST OF A SET OF ROUTINES EACH OF WHICH SPECIFIES THE NUMBER OF TIMES A TEST IS TO BE PERFORMED BY MEANS OF AN ITERATION COUNT. SETTING SR13 TO A 1 CAUSES THE PROGRAM TO DISREGARD THE ITERATION COUNT AND PERFORM THE TEST ONLY ONCE FOR EACH ROUTINE. TWO POSSIBLE USES OF THIS OPTION ARE:
- A. QUICK PASS, THE USER MAY ELECT TO RUN THROUGH A PROGRAM QUICKLY TO FIND OUT IF ANY FAILURES SHOW IMMEDIATELY. A SUCCESSFUL QUICK PASS HOWEVER, DOES NOT GUARANTEE THAT THE SAME PROGRAM WILL RUN ERROR-FREE WHEN PERFORMING A NORMAL ITERATION PASS.
 - B. SKIP OVER FAILING ROUTINE, WHEN A ROUTINE HAS DETECTED A SOLID FAILURE, THE ERROR WILL BE REPORTED MANY TIMES. TO GO ON TO THE NEXT ROUTINE, THE USER CAN INHIBIT ITERATION. IT WILL BE NECESSARY TO CAUSE THE PROGRAM TO STOP AT THE END OF THE ROUTINE BY SETTING SR15 TO A 1. OTHERWISE THE PROGRAM WOULD QUICKLY RUN THROUGH THE NEXT ROUTINE(S) ALSO.
- SR10** - LOOP PROGRAM, THIS OPTION IS USED BY PROGRAMS PRG0, PRG1, AND PRG4. SETTING SR10 TO A 1 CAUSES THE PROGRAM TO REPEAT ITSELF UPON COMPLETION, INSTEAD OF STOPPING AT PROGRAM END HALT.
- SR9** - SELECT ROUTINE, THIS OPTION IS USED BY PROGRAMS PRG0, PRG1 AND PRG4. THE USER MAY ELECT TO RUN ONLY ONE SPECIFIC ROUTINE BY SETTING SR9 TO A 1, AND SR6 THROUGH SR8 TO THE NUMBER OF THE DESIRED ROUTINE. REFER TO THE INDIVIDUAL PROGRAM DESCRIPTION IN SECTION 8 TO OBTAIN THE ROUTINE NUMBER. THE ROUTINE NUMBER SELECTED MUST BE A VALID NUMBER, OR AN ERROR HALT WILL OCCUR. THE SELECT ROUTINE OPTION WILL BE HONORED BY THE PROGRAM UPON COMPLETION OF THE CURRENT ROUTINE, OR UPON STARTING THE PROGRAM.
- SR8** - DISABLE STALL MODE AND RUN FULL SPEED, USED BY PROGRAM PRG10. THIS PROGRAM OPERATES NORMALLY IN STALL MODE (TESTS OR EXERCISES ARE NOT FULL SPEED, BUT RANDOM DURATION DELAYS ARE INTRODUCED). SETTING SR8 TO A 1 CAUSE THE PROGRAM TO PERFORM THEIR TESTS AT FULL SPEED.

7.3

TESTING VT06 AT NON-STANDARD ADDRESSES AND/OR VECTORS

THIS PROGRAM CAN TEST A KL11 ASSIGNED TO NON-STANDARD ADDRESSES AND VECTORS PROVIDED THESE ADDRESSES ARE PROVIDED TO THE PROGRAM AS FOLLOWS:

- A. IMMEDIATELY AFTER LOADING THE PROGRAM CHANGE THE FOLLOWING LOCATIONS, REFER TO PROGRAM LISTING,

LOCATION	FROM STANDARD	TO NON-STANDARD
001206	177560	RECEIVER CSR ADDRESS
001210	177562	RECEIVER BUFFER ADDRESS
001212	177564	TRANSMITTER CSR ADDRESS
001214	177566	TRANSMITTER BUFFER ADDRESS
001216	000060	RECEIVER VECTOR ADDRESS
001220	000200	RECEIVER PRIORITY LEVEL
001222	000064	TRANSMITTER VECTOR ADDRESS
001224	000200	TRANSMITTER PRIORITY LEVEL

- B. PROCEED TO USE PROGRAM, OR
- C. USING STANDARD DUMP ROUTINES, DUMP OUT THE ENTIRE PROGRAM IN ABSOLUTE FORMAT, TO HAVE AN UPDATED OBJECT TAPE THAT REFLECTS YOUR SYSTEM, OR
- D. DUMP OUT ONLY LOCATIONS 000204 THROUGH 000222, AND SPLICE THE TAPE TO THE END OF THE STANDARD OBJECT TAPE; THIS PROCEDURE WOULD REQUIRE THAT THE SHORT LENGTH OF TAPE BE LOADED IMMEDIATELY AFTER THE MAIN PROGRAM, IN ORDER TO OVERLAY LOCATIONS 000204 THROUGH 000222.

8. DESCRIPTION

NOTE: THIS TEXT WAS ORIGINALLY WRITTEN TO DESCRIBE A TELETYPE;
THEREFORE, INTERPRET READER/KYBD AS RECEIVER AND PUNCH
AS TRANSMITTER.

8.1 PRGB PROGRAM DESCRIPTION

PRGB TESTS THE INPUT AND OUTPUT LOGIC IN ONE PROGRAM, THE PROGRAM
CONSISTS OF 35 TEST ROUTINES NUMBERED FROM 00 TO 42(8),

RTN0 TESTS ABILITY TO REFERENCE THE READER/KYBD STATUS WORD (TKS)
WITHOUT TRAPPING,
RTN1 TESTS ABILITY TO REFERENCE THE READER/KYBD BUFFER (TKB)
WITHOUT TRAPPING,
RTN2 TESTS ABILITY TO REFERENCE THE PRINTER/PUNCH STATUS WORD (TPS)
WITHOUT TRAPPING,
RTN3 TESTS ABILITY TO REFERENCE THE PRINTER/PUNCH BUFFER (TPB)
WITHOUT TRAPPING,
RTN4 TESTS ABILITY TO SET AND CLEAR THE READER/KYBD ID BIT,
RTN5 CHECKS THAT READER /KYBD ID BIT CAN BE CLEARED WITH RESET INSTRUCTION,
RTN6 CHECKS THAT 30 MSECS AFTER READER ENABLE THE BUSY BIT WAS SET,
RTN7 CHECKS THAT READER/KYBD BUSY BIT CAN BE READ RELIABLY,
RTN10 CHECKS THAT 8 MSECS AFTER THE BUSY BIT WAS SET THE READ
BUFFER IS RESET TO 200,
RTN11 CHECKS THAT READER DONE BIT SETS NO LATER THAN 200 MSECS
AFTER READER ENABLE,
RTN12 TESTS THAT READER/KYBD DONE BIT CAN BE READ RELIABLY,
RTN13 CHECKS THAT RESET INSTRUCTION CLEARS THE READER DONE BIT,
RTN14 CHECKS THAT REFERENCING READER BUFFER CLEARS DONE BIT,
RTN15 TESTS THAT READER DONE BIT IS CLEARED BY START BIT, (WHEN
BUSY BECOMES SET,)
RTN16 CHECKS THAT WHEN READER DONE BIT BECOMES SET, BUSY BIT IS
STILL SET,
RTN17 TESTS THAT READ BUFFER CAN BE READ RELIABLY,
RTN20 CHECKS THAT READER DONE BIT IS ABLE TO CAUSE AN INTERRUPT, IF THE
INTERRUPT IS SERVICED, IT WILL HAVE OCCURRED AT CORRECT VECTOR,
RTN21 TESTS THAT READER DONE DOES NOT CAUSE AN INTERRUPT WHEN THE PROCESSOR
IS AT THE SAME PRIORITY AS THE READER'S INTERRUPT REQUEST LEVEL,
RTN22 TESTS THAT READER DONE CAUSES INTERRUPT WHEN THE PROCESSOR IS AT A
PRIORITY ONE LEVEL LOWER THAN THE READER'S INTERRUPT REQUEST LEVEL,
RTN23 CHECKS THAT READER DONE DOES NOT REINTERRUPT AFTER RTI
INSTRUCTION WHEN DONE BIT IS LEFT S.T,

(8,1 CONT'D)

RTN24 TESTS ABILITY TO SET AND CLEAR THE PUNCH ID BIT.
RTN25 CHECKS THAT PUNCH ID BIT CAN BE CLEARED WITH RESET INSTRUCTION.
RTN26 TESTS ABILITY TO SET AND CLEAR PUNCH MAINTENANCE BIT.
RTN27 CHECKS THAT RESET INSTRUCTION CLEARS THE MAINTENANCE BIT.
RTN30 TESTS THAT RESET SETS THE PUNCH READY BIT, AND THAT THE
READY BIT CAN BE READ RELIABLY.
RTN31 TESTS THAT PUNCH READY IS CLEARED BY LOADING THE PUNCH BUFFER.
RTN32 TESTS THAT BYTE LOADING PUNCH BUFFER+1 DOES NOT CLEAR THE
PUNCH READY BIT.
RTN33 CHECKS THAT THE PUNCH BECOMES READY NO LATER THAN 200 MSECS
AFTER BUFFER LOAD.
RTN34 CHECKS THAT PUNCH READY BIT CAN CAUSE INTERRUPT, IF THE INTERRUPT
IS SERVICED, IT WILL HAVE OCCURRED AT THE CORRECT VECTOR
RTN35 TESTS THAT PUNCH READY DOES NOT CAUSE AN INTERRUPT WHEN THE
PROCESSOR IS AT A PRIORITY AS THE READER'S INTERRUPT REQUEST
LEVEL.
RTN36 TESTS THAT PUNCH READY CAUSES AN INTERRUPT WHEN THE PROCESSOR
IS AT PRIORITY ONE LEVEL LOWER THAN THE PUNCH INTERRUPT
REQUEST LEVEL.
RTN40 CHECKS THAT PUNCH READY CAUSES AN INTERRUPT IMMEDIATELY UPON
LOWERING PROCESSOR PRIORITY TO 0.
RTN41 CHECKS FOR CORRECT OPERATION OF WAIT INSTRUCTION, (REFER TO
PROGRAM LISTING).
RTN42 TESTS THAT LOADING PUNCH BUFFER WITH MAINTENANCE BIT SET
CAUSES READER DONE BIT TO SET NO LATER THAN 200 MSECS.

(8,2 CONT'D)

RTN5 TYPES LINE OF CHARACTERS ABC
 RTN6 TYPES LINE OF CHARACTERS DEF
 RTN7 TYPES LINE OF CHARACTERS GHI
 RTN8 TYPES LINE OF CHARACTERS JKL
 RTN9 TYPES LINE OF CHARACTERS MNO
 RTN10 TYPES LINE OF CHARACTERS PQR
 RTN11 TYPES LINE OF CHARACTERS STU
 RTN12 TYPES LINE OF CHARACTERS VWX
 RTN13 TYPES LINE OF CHARACTERS YZ0
 RTN14 TYPES LINE OF CHARACTERS 123
 RTN15 TYPES LINE OF CHARACTERS 456
 RTN16 TYPES LINE OF CHARACTERS 789
 RTN17 TYPES LINE OF CHARACTERS !"#\$
 RTN18 TYPES LINE OF CHARACTERS %&'
 RTN19 TYPES LINE OF CHARACTERS ()
 RTN20 TYPES LINE OF CHARACTERS *+,
 RTN21 TYPES LINE OF CHARACTERS -./
 RTN22 TYPES LINE OF CHARACTERS :;<
 RTN23 TYPES LINE OF CHARACTERS =>?
 RTN24 TYPES LINE OF CHARACTERS @[\
 RTN25 TYPES LINE OF CHARACTERS]^ AND LEFT ARROW
 RTN26 TYPES 2 LINES OF ALL CHARACTERS; FIRST LINE IS TYPED AT
 FULL SPEED; SECOND LINE IS TYPED WITH RANDOM STALLS;
 RTN27 TYPES 12 LINES OF ASR33 (001224-10) WORST CASE PATTERN;
 EVERY OTHER LINE IS TYPED WITH RANDOM STALLS; THE ASR33
 WORST CASE PATTERN IS /-W/Ho
 RTN28 TYPES 12 LINES OF ASR35 (001224-11) WORST CASE PATTERN;
 EVERY OTHER LINE IS TYPED WITH RANDOM STALLS; THE ASR35
 WORST CASE PATTERN IS 'L9C7E

8.3

PRG2 PROGRAM DESCRIPTION

PRG2 IS USED TO TEST THE TELETYPE KEYBOARD, THE PROGRAM CONTAINS
3 ROUTINES NUMBERED FROM 00 TO 02.

RTN0 TESTS THAT TELETYPE CONTROL RESPONDS WHEN USER DEPRESSES
A KEYBOARD KEY.

RTN1 ECHO TEST, THE TEST ECHOES ONTO THE TELEPRINTER THE CHARACTER
RECEIVED FROM THE KEYBOARD, WHEN THE TEST SENSES A RUBOUT
CHARACTER THE TEST IS ENDED, THE TEST ENABLES THE USER TO
DETERMINE IF ALL PRINTABLE CODES CAN BE SUCCESSFULLY SENT
TO THE VT06 CONTROL. THE FOLLOWING SECTIONS (8.3.1, 8.3.2)
DESCRIBE HOW THIS ROUTINE SHOULD BE USED TO TEST THE
SPECIAL CHARACTERS.

8.3.1 CURSOR TEST

- A. USING "SPACES" AND "LINE FEEDS" PUT THE LETTER "A" AT A KNOWN POSITION (5 "SPACES" AND 5 "LINE FEEDS")
- B. PLACE A "B" AT ANOTHER KNOWN POSITION (10 MORE "SPACES" AND 5 MORE "LINE FEEDS")
- C. HOME UP
- D. USING "CURSOR RIGHT" AND "CURSOR DOWN" POSITION THE CURSOR OVER THE "B"; IT SHOULD REQUIRE EXACTLY 15 "CURSOR RIGHT'S" AND 10 "CURSOR DOWN'S",
- E. USING "CURSOR LEFT" AND "CURSOR UP" POSITION THE CURSOR OVER THE "A"; IT SHOULD REQUIRE EXACTLY 5 "CURSOR-UP'S" AND 10 "CURSOR LEFT'S",

8.3.2 ERASE TEST

- A. FILL THE SCREEN WITH ANY CHARACTER AND RETURN CURSOR TO LEFT SIDE OF SCREEN,
- B. TYPE EOL (ERASE LINE) AND "CURSOR UP",
- C. REPEAT B 25 TIMES AND SCREEN SHOULD BE CLEAR,
- D. FILL SCREEN WITH ANY CHARACTER,
- E. "HOME UP" AND TYPE "EOF" (ERASE FIELD) AND SCREEN SHOULD BE CLEAR,

DESCRIPTION OF CURSOR CONTROL CODES AND SPECIAL FUNCTION CODES

TABLE 8-3

OCTAL CODE	CORRESPONDING KEY	DESCRIPTION
07	BELL	CAUSES A "BEEP" TO SOUND IN THE SPEAKER INSIDE THE DISPLAY.
12	LINE FEED	CAUSES THE CURSOR TO MOVE DOWN ONE LINE POSITION UNTIL THE CURSOR REACHES THE BOTTOM LINE. WHEN THE CURSOR IS ON THE BOTTOM LINE, THE CODE WILL CAUSE THE TEXT TO ROLL UP ONE LINE (TOP LINE IS LOST).
15	RETURN	CAUSES THE CURSOR TO RETURN TO THE FIRST CHARACTER POSITION ON THE SAME LINE. CARRIAGE RETURN/ LINE FEED WILL NOT AUTOMATICALLY OCCUR AFTER THE SEVENTY-SECOND CHARACTER IS WRITTEN.
18	BACK SPACE	CAUSES THE CURSOR TO MOVE BACKWARD ONE CHARACTER SPACE. IF THE CURSOR IS AT CHARACTER POSITION ONE, THIS CODE HAS NO EFFECT.
37	ERASE EOF	CAUSES THE SCREEN TO BE ERASED FROM THE CURSOR POSITION TO THE END OF THE SCREEN.
36	ERASE EOL	CAUSES THE PORTION OF THE LINE FROM THE CURSOR POSITION TO THE END OF THAT LINE TO BE ERASED.
35	HOME UP	PLACES THE CURSOR IN THE FIRST CHARACTER POSITION OF THE FIRST LINE ON THE SCREEN.
34	HOME DOWN	PLACES THE CURSOR IN THE FIRST CHARACTER POSITION OF THE LAST LINE ON THE SCREEN.
32	CURSOR UP	MOVES THE CURSOR VERTICALLY UPWARD TO THE NEXT HIGHER LINE. IF THE CURSOR IS ON THE TOP LINE, THIS CODE HAS NO EFFECT.
13	CURSOR DOWN	MOVES THE CURSOR VERTICALLY DOWNWARD ONE LINE. IF THE CURSOR IS ON THE BOTTOM LINE, THIS HAS NO EFFECT.
OCTAL CODE	CORRESPONDING KEY	DESCRIPTION

31 CURSOR LEFT MOVES THE CURSOR HORIZONTALLY
LEFT ONE POSITION. IF THE CURSOR
IS AT CHARACTER POSITION ONE,
THIS CODE HAS NO EFFECT.

38 CURSOR RIGHT MOVES THE CURSOR HORIZONTALLY
RIGHT ONE POSITION. IF THE
CURSOR IS AT CHARACTER POSITION
72, THIS CODE HAS NO EFFECT.

48 SPACE THE CHARACTER AT THE CURSOR
POSITION WHEN THE SPACE COMMAND
IS ISSUED WILL BE ERASED THE
CURSOR MOVES HORIZONTALLY ONE
CHARACTER POSITION TO THE RIGHT
IF THE CURSOR IS IN CHARACTER
POSITION 72, THAT CHARACTER AT
THE 72ND POSITION IS ERASED, BUT
THE CURSOR WILL REMAIN AT THE
72ND POSITION.

THE CURSOR SWITCH AT THE REAR OF THE UNIT WILL CAUSE THE VTB6
TO IGNORE (NO RESPONSE ON THE SCREEN) THE FOLLOWING CODES

18 BACK SPACE
37 ERASE EOF
36 ERASE EOL
35 HOME UP
34 HOME DOWN
32 CURSOR UP
13 CURSOR DOWN
31 CURSOR LEFT
38 CURSOR RIGHT WHEN IN THE "OFF" POSITION.

22

RTN2 OCTAL EQUIVALENT TEST, THE OCTAL EQUIVALENT OF ANY CHARACTER RECEIVED BY THE CONTROL IS TYPED, SENSING A RUBOUT ENDS THE TEST, THIS TEST ENABLES THE USER TO DETERMINE THAT ALL CODES INCLUDING NON-PRINTABLE CONTROL CODES ARE BEING CORRECTLY SENT TO THE TELETYPE CONTROL,

8.8

PRG3 PROGRAM DESCRIPTION

PRG3 IS A PRINTER EXERCISER DESIGNED AS AN AID IN MAKING VT86
ADJUSTMENTS. THE PROGRAM PERMITS THE USER TO TYPE IN FIVE TEST CHARACTERS
AND ONE FINAL CHARACTER THAT SIGNIFIES WHETHER FULL SPEED OR STALL
OPERATION IS DESIRED. THE PROGRAM THEN TYPES LINES CONTAINING THE
FIVE SELECTED CHARACTERS. WHEN THE USER WISHES TO CHANGE THE TEST
CHARACTERS SR15 IS SET TO A 1. THE PROGRAM TERMINATES TYPING THE LINE
BEFORE ACCEPTING NEW DATA.

THIS TEST CAN ALSO BE USED FOR ALIGNMENT BY FILLING THE SCREEN
WITH E'S.

8.4 PRG4 PROGRAM DESCRIPTION
.....

PRG11 IS USED AS AN AID IN ADJUSTING THE TRANSMITTER CLOCK WITH THE AID OF A SCOPE, THE PROGRAM PERFORMS THE FOLLOWING SEQUENCE:

- A. LOAD TRANSMITTER BUFFER WITH ASCII CODE IN SR LEFT,
- B. DELAY NUMBER OF MILLISECONDS SET IN SR RIGHT,
- C. GO TO STEP A,

8.5 PRG5 PROGRAM DESCRIPTION
.....

PRG5 IS USED AS AN AID IN ADJUSTING THE RECEIVER CLOCK, A SCOPE IS REQUIRED, THE PROGRAM PERFORMS THE FOLLOWING SEQUENCE:

- A. SET PUNCH MAINTENANCE BIT,
- B. LOAD PUNCH BUFFER WITH CODE IN SR LEFT,
- C. DELAY NUMBER OF MILLISECONDS SET IN SR RIGHT,
- D. MOVE CONTENTS OF READ BUFFER TO REGISTER B,
- E. ISSUE 9 RESET INSTRUCTIONS TO "FIX" READ BUFFER CONTENTS IN RIGHT HALF OF DATA LIGHTS,
- F. GO TO STEP A,

8.6 PRG6 PROGRAM DESCRIPTION
.....

USING THE PUNCH MAINTENANCE BIT FEATURE, PRG13 TAKES THE ASCII CODE SET IN SR LEFT AND USES IT TO CHECK THE ABILITY OF THE CONTROL TO OUTPUT AND RECEIVE DATA, THE PROGRAM PERFORMS THE FOLLOWING SEQUENCE:

- A. SET PUNCH MAINTENANCE BIT,
- B. LOAD PUNCH BUFFER WITH CODE IN SR LEFT,
- C. WHEN READER DONE BIT SETS, COMPARE CODE IN SR LEFT WITH DATA IN READER BUFFER, HALT IF NOT SAME,
- D. WAIT FOR PUNCH DONE BIT TO SET AND GO TO STEP B,

8.7 PRG7 PROGRAM DESCRIPTION
.....

USING THE PUNCH MAINTENANCE BIT FEATURE PRG14 USES THE SPECIAL BINARY COUNT PATTERN TO CHECK ABILITY OF THE CONTROL TO OUTPUT AND RECEIVE DATA, THE PROGRAM PERFORMS THE FOLLOWING STEPS:

- A. INITIALIZE BINARY COUNT PATTERN,
- B. SET PUNCH MAINTENANCE BIT,
- C. LOAD PUNCH BUFFER WITH BINARY COUNT CHARACTER,
- D. WHEN READER DONE BIT SETS, COMPARE BINARY CHARACTER WITH DATA IN READ BUFFER, HALT IF NOT SAME,
- E. WAIT FOR PUNCH DONE BIT TO SET AND GO TO STEP C,

8.10 PROGRAM 10 DESCRIPTION
.....

THE PURPOSE OF THIS TEST IS TO VERIFY THAT THE VTB0 MEMORY HAS
ROLL-UP CAPABILITIES. THE TEST FUNCTIONS AS FOLLOWS:

- A. A LINE I, AND ITS COMPLEMENT , IS DISPLAYED
- B. THIS LINE IS FOLLOWED BY A LINE OF ITS EXACT COMPLEMENT

THIS PROCEDURE RUNS CONTINUOUSLY. IF SWITCH 15 IS HELD UP
MOMENTARILY THE ASCII CODE FOR THE CHARACTER IS INCREMENTED
BY ONE. BY UTILIZING SWITCH 15 IN THIS MANNER, PROGRAM 10 CAN
TEST THE ROLL-UP CAPABILITY OF ALL CHARACTERS.


```

IEQUATE STATEMENTS
SR=177570
CC=177776
PSW=177776
NOP=240
OPEN=0
HLTSH=BIT15
SCOPSH=BIT14
NPRSH=BIT13
NTRCSH=BIT12
NITRSH=BIT11
LPRGSH=BIT10
SRTSH=BIT9
BYPMAN=BIT8
MANUAL=BIT15
BIT15=100000
BIT14=40000
BIT13=20000
BIT12=10000
BIT11=4000
BIT10=2000
BIT9=1000
BIT8=400
BIT7=200
BIT6=100
BIT5=40
BIT4=20
BIT3=10
BIT2=4
BIT1=2
BIT0=0
POPSP=5726
POPSP2=022626
PRTY7=340
PRTY6=300
PRTY5=240
PRTY4=200
PRTY3=140
PRTY2=100
PRTY1=40
PRTY0=0
TYPE=EMT+0
TYPES=EMT+1
STALL=EMT+2
ERROR=EMT+3
DATCHK=EMT+4
CHALT=EMT+5
STRDRV=EMT+6
STPCHV=EMT+7
EHALT=EMT+10
SRESET=EMT+11
CHAIN=EMT+12
CK33=EMT+13

```

```

IHALT SWITCH DEFINITION
ISCOPE SWITCH DEFINITION
IINHBIT PRINT SWITCH DEFINITION
IINHBIT TRACE SWITCH DEFINITION
IINHBIT ITERATION SWITCH DEFINITION
ILOOP PROGRAM SWITCH DEFINITION
ISELECT ROUTINE SWITCH DEFINITION
IBYPASS MANUAL INTERVENTION DEFINITION.

```

```

IPOP THE STACK, SAME AS TST (6)+
IPOP STACK TWICE, SAME AS CMP (6)+,(6)+
IPRIORITY LEVEL DEFINITIONS

```

```

177570
177776
177776
000240
000000
100000
040000
020000
010000
004000
002000
001000
000400
100000
100000
040000
020000
010000
004000
002000
001000
000400
000200
000100
000040
000020
000010
000004
000002
000000
005726
022626
000340
000300
000240
000200
000140
000100
000040
000000
104000
104001
104002
104003
104004
104005
104006
104007
104010
104011
104012
104013

```

104014
 104016
 104017
 104020
 104021
 104022
 104400
 000007
 011671
 011673
 012003
 012014
 012005
 012016
 012115
 012126

CK35=EMT+14
 TYPLN3=EMT+16
 DATHLT=EMT+17
 SAVREG=EMT+20
 RSTREG=EMT+21
 CHKASR=EMT+22
 DELAY=TRAP+0
 BELL=007
 BLOCKA=DEND
 BLOCK1=BLOCKA+2
 BLOCK8=BLOCKA+112
 BLK8B=BLOCKA+123
 BLOCK2=BLOCKA+114
 BLK2=BLOCKA+125
 BLOCKC=BLOCKA+224
 BLKCC=BLOCKA+235

000200 000200
 000200 000167 001304
 001204 001204
 001204 000000
 001206 177560
 001210 177562
 001212 177564
 001214 177566
 001216 000060
 001220 000200
 001222 000064
 001224 000200
 001226 000001
 001230 000000
 001232 000000
 001234 000000
 001236 000000
 001240 000000
 001242 000000
 001244 000000
 001246 000000
 001250 004526
 001252 006210
 001254 007604
 001256 010104
 001260 010264
 001262 010274
 001264 010364
 001266 010436
 001270 010540

,=200
 JMP START
 ,=+1000
 SPBOTI 0
 TKS1 177560
 TKB1 177562
 TPS1 177564
 TPB1 177566
 TKVTR1 60
 TKLVL1 PRTY4
 TPVTR1 64
 TPLVL1 PRTY4
 TTYTYP1 01
 PRGNUM1 OPEN
 KSTART1 OPEN
 CURTST1 OPEN
 RTNNO1 OPEN
 NXTST1 OPEN
 ICTRI1 OPEN
 SCOPTRI1 OPEN
 PRGIDI1 OPEN
 PRGTAB1 PRG0
 PRG1
 PRG2
 PRG3
 PRG4
 PRG5
 PRG6
 PRG7
 PRG10

IGO TO START OF PROGRAM,
 IGET CODE OUT OF VECTOR AREA
 IBOTTOM OF STACK
 ILSR CSR
 ILSR BUFFER
 ILSP CSR
 ILSP BUFFER
 ILSR INTERRUPT VECTOR
 ILSR PRIORITY LEVEL
 ILSP INTERRUPT VECTOR
 ILSP PRIORITY LEVEL
 ITTY = KSR35
 ICONTAINS CURRENT PROGRAMS
 ICURRENT PROGRAM START ADDRESS,
 ICONTAINS ADDR OF CURRENT TEST,
 ICONTAINS CURRENT TEST #,
 ICONTAINS ADDR OF NEXT TEST,
 ICONTAINS CURRENT ITERATION COUNT
 ICONTAINS CURRENT SCOPE POINTER,
 ICONTAINS PROGRAM INDICATORS
 IPRG0 START ADDRESS
 IPRG1 START ADDRESS
 IPRG2 START ADDRESS
 IPRG3 START ADDRESS
 IPRG4 START ADDRESS
 IPRG5 START ADDRESS
 IPRG6 START ADDRESS
 IPRG7 START ADDRESS
 IPRG10 START ADDRESS

001272 002744
 001274 003066
 001276 003164
 001300 001432
 001302 001412
 001304 001366
 001306 002474
 001310 002524
 001312 001400
 001314 002554
 001316 001672
 001320 002256
 001322 002272
 001324 002270
 001326 004244
 001330 001422
 001332 002334
 001334 002374
 001336 002310
 001340 003120
 001342 000000
 001344 000000
 001346 000000
 001350 000000
 001352 000000
 001354 000000
 001356 000000
 001360 000000
 001362 000000
 001364 000000

EMTTAB: TYP
 TYP
 STAL
 ERR
 DTCHK
 CHLT
 STLSRV
 STLSPV
 EHLT
 SRSETT
 CHAINN
 CHK33
 CHK35
 CHK330
 TYPL3
 DTHLT
 SAVRG
 RSTRG
 CKASR

 TRPTAB: DLY
 RCNT: OPEN
 CRBUF: OPEN
 CHR1: OPEN
 CHR2: OPEN
 CHR3: OPEN
 ERCTR: OPEN
 CTRAI: OPEN
 CTRBI: OPEN
 CTRCI: OPEN
 CTRDI: OPEN

IPOINTER TO TIMEOUT ROUTINE
 IPOINTER TO CHAINED MESSAGES ROUTINE
 IPOINTER TO RANDOM STALL ROUTINE
 IPOINTER TO ERROR ROUTINE

ICOMMON HALT

IPOINTER TO ERROR HALT ROUTINE;

ICHARACTER COUNT
 I HOLDS ONE CHARACTER FROM READER.

001510	012700	001204		STARTI	MOV	#SPBOT,X6	ISET BOTTOM OF SP STACK,
001514	005067	176256			CLR	PSW	
001520	012767	000000	176256		MOV	#0,MACHER	
001526	005067	177504			CLR	RTNNO	
001532	016700	176032			MOV	SR,X0	I(SR) TO R0
001536	042700	177760			BIC	#177760,X0	I LIMIT (SR) TO BITS 3-0
001542	020027	000014			CHP	X0,#14	I COMPARE (SR) TO PROGRAM LIMIT
001546	101402				BLOS	CRTA	I VALID PROGRAM NUMBER?
001550	104010			INCPRGI	EHALT		INO, INCORRECT PRG NUMBER
001552	000750				BR	START	I START OVER,
001554	005067	177466		CRTAI	CLR	PRGID	
001560	010067	177444			MOV	X0,PRGNUM	I SAVE PROGRAM NUMBER AT PRGNUM
001564	006100				ROL	X0	I RBX2
001566	000170	001250			JMP	@PRGTAB(0)	I GO TO SELECTED PROGRAM,
001572	104009			SRSETI	CHALT		I SET SR OPTIONS DESIRED
001574	016767	177432	177436	GETRDYI	MOV	KSTART,NXTST	I ADDR OF 1ST ROUTINE TO NXTST
001602	000167	000314			JMP	CLEAN	I GO CLEAN UP,
001606	004767	000204		GTRDYAI	JSR	X7,FORWD	I ROLL FORWARD TO "NEXT" ROUTINE,
001612	032767	001000	175750	GTRDYBI	BIT	#SRTSW,SR	I CHECK FOR SELECT ROUTINE SWITCH
001620	001003				BNE	GTRDYC	I BRANCH IF SELECT ROUTINE SWITCH IS SET,
001622	004767	000246			JSR	X7,GOTST	I GO RUN CURRENT ROUTINE,
001626	000455				BR	CHNB	INO GO, MANUAL RTN BYPASSED,
001630	016700	175734		GTRDYCI	MOV	SR,X0	I (SR) TO R0
001634	042700	177600			BIC	#177600,X0	I MASK UNDESIRE BITS
001640	126700	177372			CHPB	RTNNO,X0	I COMPARE RTNNO TO (R0)
001644	001004				BNE	GTRDYD	I BRANCH IF ROUTINE NOT FOUND YET,
001646	004767	000222			JSR	X7,GOTST	I GO RUN ROUTINE,
001652	104010				EHALT		INO GO, MANUAL RTN SELECTED BYPASSED,
001654	000747				BR	GETRDY	
001656	022767	177777	177354	GTRDYDI	CHP	#-1,NXTST	INO, CHECK FOR LAST ROUTINE,
001664	001350				BNE	GTRDYA	I LAST ROUTINE?
001666	104010			INCRNI	EHALT		I YES, INCORRECT ROUTINE SELECTED,
001670	000741				BR	GETRDY	I START OVER,
001672	005767	177350		CHAINNI	TST	PRGID	I TEST ERROR BIT IN PRGID,
001676	100013				BPL	CHNA	I BRANCH IF ERROR BIT NOT SET,
001700	032767	040000	175662		BIT	#SCOPSW,SR	I ERROR BIT SET, CHECK FOR SCOPE OPTION,
001706	001407				BEG	CHNA	I SCOPE SWITCH SET IN SR?
001710	022767	177777	177326		CHP	#-1,SCOPTR	I YES, CHECK SCOPE ENTRY POINTER
001716	001403				BEG	CHNA	I BRANCH IF SCOPE ENTRY IS -1,
001720	017716	177320			MOV	@SCOPTR,@X6	I SET UP TO GO SCOPING
001724	000002				RTI		I GO TO SCOPE ENTRY,
001726	042767	100000	177312	CHNAI	BIC	#BIT15,PRGID	I CLEAR ERROR BIT IN PRGID,
001734	032767	004000	175626		BIT	#NITRSH,SR	I TEST INHIBIT ITERATION SWITCH
001742	001004				BNE	CHNAA	I INHIBIT ITERATION?
001744	005367	177272			DEC	ICTR	INO
001750	001401				BEG	CHNAA	I COUNT 0?
001752	000002				RTI		INO, RETURN TO TEST ROUTINE
001754	022626			CHNAAI	POPSP2		I POP STACK TWICE
001756	004767	177510			JSR	X7,SHALT	I GO HALT IF HALT SWITCH IS SET

001762	032767	001000	175600	CHNDI	BIT	#SRTSW,SR	ICHECK SELECT ROUTINE SWITCH
001770	001301				BNE	GETRDY	ISELECT ROUTINE SWITCH SET?
001772	022767	177777	177240		CHP	#-1,NXTST	INO,
002000	001300				BNE	GTRDYA-4	ILAST TEST?
002002	032767	002000	175560		BIT	#LPRGSH,SR	IYES, TEST LOOP PROGRAM SWITCH,
002010	001271				BNE	GETRDY	ILOOP PROGRAM?
002012	000000			PRGENDI	HALT		INO, PROGRAM END.
002014	000762				BR	CHNB	
002016	016709	177216		FORWDI	MOV	NXTST,X5	IADDR OF NEXT ROUTINE TO R5,
002022	012567	177210			MOV	(5)+,R1NNO	IGET NEXT ROUTINE NUMBER,
002026	012567	177206			MOV	(5)+,NXTST	IGET ADDR OF NEXT "NEXT" ROUTINE,
002032	105767	177210			TSTB	PRGID	ICHECK IF PROGRAM SCOPE AND I COUNT
002036	100407				BMI	FORWDB	IPARAMETERS, BRANCH IF NOT,
002040	012567	177176			MOV	(5)+,ICTR	IGET ITERATION COUNT,
002044	012567	177174			MOV	(5)+,SCOPTR	IGET SCOPE LOOP ENTRY POINTER,
002050	010567	177160		FORWDAI	MOV	X5,CURTST	IADDR OF NOW CURRENT TEST TO CURTST,
002054	000207				RTS	X7	IEXIT FORWD SUBROUTINE,
002056	012767	177777	177160	FORWDBI	MOV	#-1,SCOPTR	IFORCE "NO SCOPE"
002064	012767	000001	177150		MOV	#1,ICTR	IFORCE I COUNT OF 1
002072	000766				BR	FORWDA	
002074	005767	177136		GOTSTI	TST	R1NNO	ICHECK FOR MANUAL RTN,
002100	100009				BPL	GOTSTA	IBRANCH IF NOT MANUAL RTN,
002102	032767	000400	175460		BIT	#BYPHAN,SR	IMANUAL RTN, BYPASS IT?
002110	001401				BEO	GOTSTA	INO, RUN IT,
002112	000207				RTS	X7	IBYPASS MANUAL ROUTINE.
002114	005726			GOTSTAI	POPSP		
002116	000177	177112			JMP	@CURTST	IGO RUN TEST,
002122	012767	000006	175654	CLEANI	MOV	#6,MACHER	IRESET MACHER TRAP,
002130	005067	175642			CLR	PSW	
002134	012706	001204			MOV	#SPBOT,X6	ISET UP BOTTOM OF STACK,
002140	104011				SRESET		
002142	000167	177440			JMP	GTRDYA	
002146	011646			EMTINTI	MOV	0X6,-(6)	IGET SAVED PC,
002150	162716	000002			SUB	#2,0X6	IDECREMENT PC BY 2,
002154	017616	000000			MOV	0(6),0X6	
002160	121627	000022			CMPB	0X6,#22	ICHECK THAT CALL IS
002164	101402				BLOS	EMTA	WITHIN LIMITS,
002166	000000				HALT		ICALL NOT WITHIN LIMITS,
002170	000776				BR	,-2	
002172	006116			EMTAI	ROL	0X6	IEMT ARG X 2,
002174	042716	177001			BIC	#177001,0X6	IREMOVE 7 MSB,
002200	062716	001272			ADD	#EMTTAB,0X6	IFORM EMT RTN ADDR,
002204	017616	000000			MOV	0(6),0X6	
002210	000136				JMP	0(6)+	IGO TO EMT ROUTINE,
002212	011646			TRPINTI	MOV	0X6,-(6)	IGET SAVED PC,
002214	162716	000002			SUB	#2,0X6	IDECREMENT PC BY 2,
002220	017616	000000			MOV	0(6),0X6	
002224	121627	000000			CMPB	0X6,#0	ICHECK THAT EMT
002230	101402				BLOS	TRPA	IS WITHIN LIMITS,
002232	000000				HALT		ITRAP CALL NOT IN LIMIT,
002234	000776				BR	,-2	


```

002236 006116 TRPAI ROL 0X6 ITRAP ARG X 2,
002240 042716 177001 BIC #177001,0X6 IREMOVE 7 MSB,
002244 062716 001340 ADD @TRPTAB,0X6 IFORM TRAP RTN ADDR,
002250 017616 000000 MOV 0(0),0X6
002254 000136 JMP 0(0)+ IGO TO TRAP ROUTINE,
002256 009767 176744 CHK331 TST TTYTYP ICHECK FOR 33,
002262 001002 BNE ,+0 IBRANCH IF NOT 33,
002264 062716 000002 ADD #2,0X6 I+2 TO EXIT POINTER
002270 000002 RTI IEXIT
002272 022767 000001 176720 CHK331 CMP #1,TTYTYP ICHECK FOR 35,
002300 001002 BNE ,+0 IBRANCH IF NOT 35,
002302 062716 000002 ADD #2,0X6 I+2 TO EXIT POINTER
002306 000002 RTI IEXIT
002310 032767 000010 176710 CKASRI BIT #BIT3,TTYTYP ICHECK FOR ASR TTY,
002316 001001 BNE ,+4 IBRANCH IF NOT ASR,
002320 000002 RTI IASR, EXIT,
002322 022626 POPSP2 IPOP STACK TWICE,
002324 012767 000001 176710 MOV #1,ICTR IFORCE I COUNT TO A 1,
002332 104012 CHAIN ICHAIN TO BYPASS ROUTINE,

002334 012667 000030 ISAVE REGS 0 TO 4 SUBROUTINE,
SAVRGI MOV (0)+,SVRPC ISAVE PC AND PSW,
002340 012667 000026 MOV (0)+,SVRPSW
002344 010446 MOV X4,-(6) ISAVE REGS 0 - 4
002346 010346 MOV X3,-(6) IIN STACK,
002350 010246 MOV X2,-(6)
002352 010146 MOV X1,-(6)
002354 010046 MOV X0,-(6)
002356 016746 000010 MOV SVRPSW,-(6) IRESTORE PC AND PSW,
002362 016746 000002 MOV SVRPC,-(6)
002366 000002 RTI IEXIT,
002370 000000 SVRPCI OPEN
002372 000000 SVRPSWI OPEN

002374 012667 000030 IRESTORE REGS 0 TO 4 SUBROUTINE,
RSTRGI MOV (6)+,RSTPC ISAVE PC AND PSW,
002400 012667 000026 MOV (6)+,RSTPSW
002404 012600 MOV (6)+,X0 IRESTORE REGS 0 - 4
002406 012601 MOV (6)+,X1 IFROM STACK,
002410 012602 MOV (6)+,X2
002412 012603 MOV (6)+,X3
002414 012604 MOV (6)+,X4

002416 016746 000010 MOV RSTPSW,-(6) IRESTORE PC AND PSW,
002422 016746 000002 MOV RSTPC,-(6)
002426 000002 RTI IEXIT
002430 000000 RSTPCI OPEN
002432 000000 RSTPSWI OPEN

```

```

002434 012767 000310 000300  IROUTINE TO FETCH A CHARACTER
002442 005277 176540  AREADI  MOV    #200,,BRCTR  ISET UP DELAY COUNT.
002446 105777 176534  ARDAI  INC    @TKS          IENABLE READER.
002452 100407  BM!    @TKS          ICHECK DONE BIT.
002454 104400  DELAY  ARDB          IBRANCH IF DONE.
002456 000001  1      IDELAY 1 MILLISECOND.
002460 005367 000256  DEC    BRCTR          ITIME UP?
002464 001370  BNE    ARDA          IBRANCH IF TIME NOT UP YET.
002466 104010  EHALT  IERROR, NO RESPONSE FROM READER.
002470 000761  BR     AREAD         ITRY AGAIN.
002472 000207  ARDBI  RTS    X7      IEXIT
IROUTINE TO SET LSR INTERRUPT VECTOR AND PRIORITY
002474 017667 000000 000012  STLSRVI MOV    @($),STPRA+2  IMOVE VECTOR ADDR TO STPRA+2
002502 062716 000002  ADD    #2,@X6        ISET UP EXIT
002506 016701 176504  MOV    TKVTR,X1
002512 012721 000000  STPRAI MOV    #OPEN,(1)+  ISET VECTOR ADDRESS
002516 016721 176476  MOV    TKLVL,(1)+    ISET PRIORITY
002522 000002  RTI    IEXIT
IROUTINE TO SET LSP INTERRUPT VECTOR AND PRIORITY.
002524 017667 000000 000012  STLSPVI MOV    @($),STPPA+2  IMOVE VECTOR ADDR TO STPPA+2
002532 062716 000002  ADD    #2,@X6        ISET UP EXIT
002536 016701 176460  MOV    TPVTR,X1
002542 012721 000000  STPPAI MOV    #OPEN,(1)+  ISET VECTOR ADDRESS.
002546 016721 176452  MOV    TPLVL,(1)+    ISET PRIORITY
002552 000002  RTI    IEXIT.
IROUTINE TO ISSUE RESET.
002554 012700 052525  SRSETTI MOV    #52525,X0  IDATA TO R0.
002560 005100  COM    X0             ICOMPLEMENT (R0).
002562 010067 177770  MOV    X0,SRSETT+2  I(R0) TO SRSETT+2.
002566 000005  RESET  IISSUE RESET, (R0) IS
002570 000002  RTI    IDISPLAYED, EXIT.
IRANDOM NUMBER GENERATOR, ROUTINE EXITS WITH NUMBER IN REGISTER 0.
002572 016700 000042  RNGENI MOV    RP1,X0
002576 006100  ROL    X0
002600 006100  ROL    X0
002602 066700 000034  ADD    RP2,X0
002606 010067 000026  MOV    X0,RP1
002612 006100  ROL    X0
002614 006100  ROL    X0
002616 066700 000020  ADD    RP2,X0
002622 006100  ROL    X0
002624 006100  ROL    X0
002626 010067 000010  MOV    X0,RP2
002632 016700 000002  MOV    RP1,X0
002636 000207  RTS    X7             IEXIT, NUMBER IN R0
002640 001233  RP1I  1233
002642 007622  RP2I  7622

```



```

003120 011667 000036      ;SUBROUTINE TO DELAY A SPECIFIED NUMBER OF MILLISECONDS
003124 062716 000002      DLYI  MOV  0X6,DLCNT      IGET DELAY COUNT ADDRESS,
003130 017746 000026      ADD  #2,0X6          ISET UP EXIT ADDRESS
003134 009067 174636      MOV  0DLCNT,-(6)    IDELAY COUNT TO STACK
003140 012746 000226      CLR  PSW           ISET PRIORITY 0
003144 009316      DLYAI MOV  #226,-(6)   I1 MSEC COUNT TO STACK
003146 001376      DLYBI DEC  0X6        IDECREMENT 1 MSEC COUNT
003150 009726      BNE  DLYB         IBRANCH IF NOT 0,
003152 009316      POPSP              IZERO, UNCOVER MSECS. COUNT,
003154 001371      DEC  0X6          IDECREMENT IT
003156 009726      BNE  DLYA         IBR IF NOT DONE DELAYING
003160 000002      POPSP              IDONE
003162 000000      RTI              IEXIT,
                                ICONTAINS MILLISECONDS COUNT ADDRESS.
                                ;SUBROUTINE TO STALL A RANDOM NUMBER OF MILLISECONDS, MAXIMUM STALL
                                ;DETERMINED BY CONTENTS OF LOC STLMSK,
003164 032767 040000 176054      STALI BIT  #BIT14,PRGID  ITEST FOR STALLS ALLOWED,
003172 001001      BNE  STALAA       IALLOWED,
003174 000002      RTI              INOT ALLOWED,
003176 004767 177370      STALAAI JSR  X7,RNGEN     IGO GET RANDOM NUMBER,
003202 046700 000014      BIC  STLMSK,X0    I# IN R0, APPLY STALL MASK,
003206 001404      BEQ  STALB       IBRANCH IF RESULT IS 0,
003210 010067 000002      MOV  X0,STALA
                                IDELAY
003214 104400      DELAY            IDELAY COUNT
003216 000000      STALAI OPEN      IDONE, EXIT,
003220 000002      STALBI RTI       ISTALL MASK,
003222 000000      STLMSKI OPEN
                                ;SUBROUTINE TO GENERATE RANDOM CHARACTER COUNT
003224 004767 177342      GRCNTI JSR  X7,RNGEN     IGET RANDOM NUMBER
003230 046700 000010      BIC  RCHMSK,X0   IAPPLY MASK
003234 001773      BEQ  GRCNT       ITRY AGAIN IF RESULT 0
003236 010067 000004      MOV  X0,RNCNT    ICOUNT TO RNCNT
003242 000207      RTS  X7          IEXIT,
003244 000000      RCHMSKI OPEN    IRANDOM CHARACTER MASK,
003246 000000      RNCNTI OPEN     IRANDOM CHARACTER COUNT,
                                ;SUBROUTINE TO COMPARE DATA READ FROM READER AGAINST EXPECTED DATA AND REPORT ERRORS,
003250 004767 000260      BCHECKI JSR  X7,GTBIN     IGET BIN CHARACTER(IN R0)
003254 110067 176063      MOV  X0,CRBUF+1  IS70 CHAR TO CRBUF+1
003260 126767 176060 176057      CMPB CRBUF,CRBUF+1 ICOMPARE S/B AND WAS CHARS,
003266 001001      BNE  ,+6         IBRANCH IF NOT SAME,
003270 000207      RTS  X7          ISAME, EXIT,
003272 104017      DATHLT          IGO HALT AND DISPLAY DATA,
003274 005367 176054      DEC  ERCTR       I3 ERRORS?
003300 001002      BNE  ,+6         IBRANCH IF NOT 3 YET,
003302 004767 000002      JSR  X7,BSYNC    I3 ERRORS, RESYNC READER,
003306 000207      RTS  X7          IEXIT,

```



```

SUBROUTINE TO SYNC THE LSR TO A SPECIAL BINARY COUNT PATTERN TEST TAPE;
BSYNCI JSR X7,INBIN IINITIALIZE BINARY PATTERN
        JSR X7,BREAD IREAD CHAR AND STORE AT CHR1
        MOVB CRBUF,CHR1
        JSR X7,BREAD IREAD CHAR AND STORE AT CHR2
        MOVB CRBUF,CHR2
        JSR X7,BREAD IREAD CHAR AND STORE AT CHR3;
        MOVB CRBUF,CHR3
        JSR X7,SYNCA IGO SYNC
        BR BSYNC INO SYNC, TRY AGAIN;
        MOV #3,ERCTR
        RTS X7
        MOV #512,,SYCTRA ISUCCESS,EXIT;
        MOV #10,,SYCTRB I512 TO SYCTRA
        JSR X7,GTBIN I10 TO SYCTRB
        CMPB X0,CHR1 IGET BIN CHARACTER(CHAR IN RB)
        BNE SYNCC ICOMPARE TO CHR1
        JSR X7,GTBIN IBRANCH IF NOT EQUAL
        CMPB X0,CHR2 ISAME, GET ANOTHER BIN CHAR;
        BNE SYNCC ICOMPARE TO CHR2
        BEQ SYNCD IBRANCH IF EQUAL
        DEC SYCTRA IDECREMENT SYCTRA
        BNE SYNCC IBRANCH IF NOT DONE 512 TIMES;
        EHALT IDONE 512, SYNC ERROR;
        RTS X7 IERROR EXIT
        JSR X7,GTBIN IGET BIN CHARACTER
        CMPB X0,CHR3 ICOMPARE TO CHR3
        BEQ SYNCE IBRANCH IF SAME
        DEC SYCTRB IDECREMENT SYCTRB;
        BNE SYNCC IBRANCH IF NOT DONE 10 TIMES
        BR SYNCC ISYNC ERROR, BRANCH
        ADD #2,0X6 ISET UP SUCCESS EXIT
        RTS X7 IEXIT;
SYCTRAI OPEN
SYCTRB: OPEN
SUBROUTINE TO INITIALIZE BINARY COUNT PATTERNS
INBINI MOV #-1,RIND ISET ALL VARIABLES
        JSR X5,BMOVE ITO MINUS 1;
        RIND
        RIND+1
        LI 11
        RTS X7 IEXIT
RINDI OPEN
PT0I OPEN
PT1I OPEN
PINDI OPEN
PT0PI OPEN
PT1PI OPEN

```

```

003310 004767 000162
003314 004767 177324
003320 116767 176020 176020
003326 004767 177312
003332 116767 176006 176010
003340 004767 177300
003344 116767 175774 176000
003352 004767 000012
003356 000754
003360 012767 000003 175766
003366 000207
003370 012767 001000 000074
003376 012767 000012 000070
003404 004767 000124
003410 120067 175732
003414 001373
003416 004767 000112
003422 120067 175722
003426 001409
003430 005367 000036
003434 001363
003436 104010
003440 000207
003442 004767 000066
003446 120067 175700
003452 001404
003454 005367 000014
003460 001351
003462 000765
003464 062716 000002
003470 000207
003472 000000
003474 000000

```

```

003476 012767 177777 000014
003504 004567 000300
003510 003520
003512 003521
003514 000013
003516 000207
003520 000000
003522 000000
003524 000000
003526 000000
003530 000000
003532 000000

```

```

;SPECIAL BINARY COUNT PATTERN SUBROUTINE, EXITS WITH BIN CHAR IN R0
003534 016767 177762 177762 GTBINI MOV PT0,PT1 ;PREVIOUS BIN CHAR TO PT1
003542 005167 177756 COM PT1
003546 005167 177746 COM RIND
003552 001002 BNE ,+6
003554 005267 177744 INC PT1
003560 042767 177400 177736 BIC #177400,PT1 ;MASK TO 8 BITS
003566 016767 177732 177726 MOV PT1,PT0 ;SAVE BIN CHAR IN PT0
003574 016700 177724 MOV PT1,X0 ;BIN CHAR TO R0,
003600 000207 RTS X7 ;EXIT
003602 016767 177722 177722 GTBINPI MOV PT0P,PT1P ;PREVIOUS BIN CHAR TO PT1P
003610 005167 177716 COM PT1P
003614 005167 177706 COM PIND
003620 001002 BNE ,+6
003622 005267 177704 INC PT1P
003626 042767 177400 177676 BIC #177400,PT1P ;MASK TO 8 BITS,
003634 016767 177672 177666 MOV PT1P,PT0P ;SAVE BIN CHAR IN PT0P,
003642 016701 177664 MOV PT1P,X1 ;BIN CHAR TO R1,
003646 000207 RTS X7 ;EXIT

;OCTAL TO ASCII CONVERT ROUTINES
003650 012500 ACNV6I MOV (5)+,X0 ;CONVERT TO 6 ASCII, GET OCTAL ADDRESS
003652 012567 000012 MOV (5)+,ACNV6 ;GET ASCII ADDRESS
003656 004767 000052 JSR X7,ACNV ;CONVERT TO ASCII
003662 004567 000122 JSR X9,BMOVE ;MOVE 6 CHARS TO ASCII ADDRESS
003666 003724 ACNVBI OPEN
003670 000000 ACNVBI OPEN
003672 000006 ACNVBI OPEN
003674 000205 ACNVBI OPEN
003676 012500 ACNV4I MOV (5)+,X0 ;EXIT
003700 012567 000012 MOV (5)+,ACNV4 ;CONVERT TO 4 ASCII, GET OCTAL ADDRESS
003704 004767 000024 JSR X7,ACNV ;GET ASCII ADDRESS
003710 004567 000074 JSR X9,BMOVE ;CONVERT TO ASCII
003714 003726 ACNVCI OPEN ;MOVE 4 CHARS TO ASCII ADDRESS
003716 000000 ACNVCI OPEN
003720 000004 ACNVCI OPEN
003722 000205 ACNVCI OPEN
003724 000000 A1STI OPEN
003726 000000 A1STI OPEN
003730 000000 A1STI OPEN
003732 000000 A1STI OPEN
003734 012701 003732 ACNVXI OPEN
003740 012702 000006 ACNVI MOV #A1ST+6,X1 ;ADDR TO STORE ASCII TO R1
003744 011067 177762 MOV #6,X2 ;6 TO R2
003750 016703 177756 MOV #X0,ACNVX ;OCTAL WORD TO ACNVX
003754 042703 177770 ACNVM1 MOV ACNVX,X3
003760 062703 000060 BIC #177770,X3 ;ISOLATE LEAST SIGNIFICANT OCTAL #
003764 110341 MOV #60,X3 ;ADD 60 TO CONVERT TO ASCII
003766 006067 177740 ROR X3,-(1) ;STORE ASCII BYTE
003772 006067 177734 ROR ACNVX ;MOVE NEXT OCTAL DIGIT TO LEAST
003776 006067 177730 ROR ACNVX ;SIGNIFICANT POSITION
004002 005302 DEC X2 ;DONE 6 TIMES?
004004 001361 BNE ACNVM ;NO, REPEAT
004006 000207 RTS X7 ;YES, EXIT

```



```

;SUBROUTINE TO MOVE A VARIABLE NUMBER OF BYTES,
BMOVEI SAVREG          ;SAVE REGS,
          MOV          (5)+,X1      ;GET FROM ADDRESS
          MOV          (5)+,X2      ;GET TO ADDRESS
          MOV          (5)+,X3      ;GET COUNT
BMOVAI MOVB           (1)+,(2)+    ;MOVE BYTE
          DEC          X3           ;DECREMENT COUNT
          BNE          BMOVA        ;BRANCH IF NOT DONE
          RSTREG          ;RESTORE REGS,
          RTS           X5         ;DONE EXIT

;SUBROUTINE TO CHECK FOR PUNCH READY
CPRDYI TSTB           @TPS         ;TEST FOR READY BIT
          BPL          CPRDYA       ;BRANCH IF READY NOT SET
          RTS           X7         ;OK, EXIT
CPRDYAI EHALT        ;NOT READY, HALT
          BR           CPRDY

;SUBROUTINE TO PUNCH ON LSP CHARACTER IN REG B.
LSPCHI JSR           X7,CPRDY      ;GO CHECK FOR PUNCH READY
          MOV          X8,@TPB      ;LOAD PUNCH BUFFER
          TSTB         @TPS         ;WAIT FOR DONE
          BPL          ,-4
          CLR          X8
          RTS           X7

;BINARY TO DECIMAL ASCII CONVERT SUBROUTINE
BDCNVI MOV            #DECVAL,X0   ;SET UP ADDR TO STORE DECIMAL ASCII IN R2
          MOV          @5+,X1      ;BINARY VALUE TO R1
          MOV          #ADTENP,X2  ;ADDR OF TEN POWER STRING TO R2
          MOV          #5,CNVCTR    ;SET UP FOR 5 POWER CONVERSIONS
BDCNVAI MOV          (2)+,TENPWR    ;MOVE POWER OF TEN VALUE TO TENPWR
          JSR          X7,SUBTEN    ;PERFORM CONVERSION
          DEC          CNVCTR       ;DONE 5 CONVERSIONS?
          BNE          BDCNVA      ;BRANCH IF NOT YET 5
          RTS           X5         ;YES, EXIT
SUBTENI CLR          DIGIT         ;CLEAR DIGIT
SUBTNAI SUB          TENPWR,X1     ;SUBTRACT TEN POWER FROM BINARY VALUE
          BCS          SUBTNB      ;BRANCH IF UNSUCCESSFUL SUBTRACTION
          INC          DIGIT
          BR          SUBTNA
SUBTNBI ADD          TENPWR,X1     ;RESTORE SUBTRACTED VALUE
          ADD          #60,DIGIT   ;CONVERT (DIGIT) TO ASCII
          MOVB        DIGIT,(0)+   ;MOVE ASCII CHAR TO DECVAL FIELD
          RTS           X7         ;EXIT

CNVCTR: OPEN
DIGITI: OPEN
TENPWR: OPEN
ADTENP: 10000,
        1000,
        100,
        10,
        1

```

```

004010 104020
004012 012501
004014 012502
004016 012503
004020 112122
004022 005303
004024 001375
004026 104021
004030 000205

```

```

004032 105777 175154
004036 100001
004040 000207
004042 104010
004044 000772

```

```

004046 004767 177760
004052 010077 175136
004056 105777 175130
004062 100375
004064 005000
004066 000207

```

```

004070 012700 011664
004074 013501
004076 012702 004176
004102 012767 000005 000060
004110 012267 000060
004114 004767 000010
004120 005367 000044
004124 001371
004126 000205
004130 005067 000036
004134 106701 000034
004140 103403
004142 005267 000024
004146 000772
004150 066701 000020
004154 062767 000060 000010
004162 116720 000004
004166 000207
004170 000000
004172 000000
004174 000000
004176 023420
004200 001750
004202 000144
004204 000012
004206 000001

```

```

004210 012767 000112 000024  ISUBROUTINE TO TYPE A LINE OF CHARACTERS
004216 012704 011671          TYPLNI  MOV    #74,,TCTR      I72 TO CHAR COUNT +CR,LF
004222 104002          TYPLAI  MOV    #BLOCKA,X4    ISET LINE ADDRESS IN R4'
004224 112400          TYPLBI  STALL                ISTALL IF ALLOWED.
004226 004767 177614          MOVB   (4)+,X0          IGET CHARACTER
004232 005367 000004          JSR    X7,LSPCH        IGO OUTPUT CHARACTER.
004236 001371          DEC    TCTR            IDONE?
004240 000207          BNE   TYPLB           IBRANCH IF NOT DONE.
004242 000000          RTS    X7            IDONE, EXIT

TCTRI  OPEN
ISUBROUTINE TO TYPE LINE OF 3 CHARACTERS
004244 011667 000016 000010  TYPL3I  MOV    #X6,TPL3A      IDEVELOP AND SET ADDRESS OF
004250 017767 000012 000010  TYPL3I  MOV    #TPL3A,TPL3A   IATA IN TPL3A,
004256 062716 000002          ADD    #2,#X6          ISET UP EXIT.
004262 004567 000034          JSR    X5,FBF3        IFILL BUFFER WITH 3 CHARACTERS
004266 000000          TPL3AI  OPEN
004270 042767 040000 174750  BIC    #BIT14,PRGID    IDISABLE STALLS,
004276 004767 177706          JSR    X7,TYPLN      IGO TYPE LINE OF CHARACTERS.
004302 000002          RTI
004304 112767 000019 005357  STBFI  MOVB   #15,BLOCKA  ISUB TO SET UP BUFFER AREA.
004312 112767 000012 005352  STBFI  MOVB   #12,BLOCKA+1
004320 000207          RTS    X7            IEXIT

ISUBROUTINE TO FILL CHARACTER BUFFER WITH 3 CHARACTERS.
004322 012567 000004  FBF3I  MOV    (3)+,FBF3A      IMOVE 3 CHARS TO BUFFER.
004326 004567 177456          JSR    X5,BMOVE
004332 000000          FBF3AI  OPEN
004334 011673          BLOCK1
004336 000003          3
004340 004567 177444          FBF3BI  JSR    X5,BMOVE      IFILL 72 CHARACTERS BUFFER
004344 011673          BLOCK1              WITH 3 CHARACTERS
004346 011676          BLOCK1+3
004350 000105          69,
004352 004567 177432          JSR    X5,BMOVE
004356 011673          BLOCK1
004360 012005          BLOCK2
004362 000110          72,
004364 000205          RTS    X5            IEXIT

```



```

004366 004567 177416      JSUBROUTINE TO FILL BUFFER WITH ALL CHARACTERS
FBALL1 JSR      X5,BMOVE      IFILL 92 CHAR BUFFER WITH
                                A      IALL CHARACTERS,
                                BLOCK1
                                63,
004372 010714
004374 011673
004376 000077
004400 004567 177404      JSR      X5,BMOVE
004404 010714      A
004406 011772      BLOCK1+63,
004410 000011      9,
004412 004567 177372      JSR      X5,BMOVE
004416 011673      BLOCK1
004420 012005      BLOCK2
004422 000110      72,
004424 000207      RTS      X7      IEXIT,

004426 004567 177356      JSUB TO FILL BUFFER WITH 33 WORST CASE PATTERN,
FW3361 JSR      X5,BMOVE      I6 CHARACTER PATTERN TO BUFFER
                                A33WP6
                                BLOCK1
                                6
004432 010700
004434 011673
004436 000006
004440 004567 177344      JSR      X5,BMOVE      IFILL BUFFER WITH PATTERN,
004444 011673      BLOCK1
004446 011701      BLOCK1+6
004450 000102      60,
004452 004567 177332      JSR      X5,BMOVE
004456 011673      BLOCK1
004460 012005      BLOCK2
004462 000110      72,
004464 000207      RTS      X7      IEXIT,

004466 004567 177316      JSUB TO FILL BUFFER WITH 35 WORST CASE PATTERN,
FW3561 JSR      X5,BMOVE      I6 CHARACTER PATTERN TO BUFFER
                                A35WP6
                                BLOCK1
                                6
004472 010706
004474 011673
004476 000006
004500 004567 177304      JSR      X5,BMOVE      IFILL BUFFER WITH PATTERN,
004504 011673      BLOCK1
004506 011701      BLOCK1+6
004510 000102      60,
004512 004567 177272      JSR      X5,BMOVE
004516 011673      BLOCK1
004520 012005      BLOCK2
004522 000110      72,
004524 000207      RTS      X7      IEXIT,

```

```

;PRGB = INPUT-OUTPUT LOGIC TESTS
004526 012767 004540 174470 PRGB01 MOV #AT0,KSTART ;ADDRESS OF 1ST ROUTINE TO KSTART,
004534 000167 175032 JMP SRSET ;GO GET STARTED,
;TEST ABILITY TO REFERENCE THE KEYBOARD/READER STATUS WORD (TKS)
004540 000000 AT01 0 ;TEST #,
004542 004572 AT1 ;NEXT TEST,
004544 001750 1000, ;! COUNT,
004546 004556 AT0A ;SCOPE ENTRY,
004550 012767 004566 173220 MOV #AT0E,MACHER ;SET UP MACHINE ERROR TRAP,
004556 005777 174424 AT0A1 TST 0TKS ;REFERENCE CODER STATUS WORD,
004562 104012 AT0B1 CHAIN ;CHAIN
004564 000774 BR AT0A ;REPEAT TEST,
004566 104003 AT0E1 ERROR ;ERROR, TRAPPED WHEN REFERENCING READER,
004570 000774 BR AT0B ;STATUS WORD (TKS),
;TEST ABILITY TO REFERENCE THE KEYBOARD/READER BUFFER (TKB),
004572 000001 AT11 1 ;TEST #,
004574 004624 AT2 ;NEXT TEST,
004576 001750 1000, ;! COUNT,
004600 004610 AT1A ;SCOPE ENTRY,
004602 012767 004620 173174 MOV #AT1E,MACHER ;SET UP MACHINE ERROR TRAP
004610 005777 174374 AT1A1 TST 0TKB ;REFERENCE READER BUFFER,
004614 104012 AT1B1 CHAIN ;CHAIN
004616 000774 BR AT1A ;REPEAT TEST,
004620 104003 AT1E1 ERROR ;ERROR, TRAPPED WHEN REFERENCING
004622 000774 BR AT1B ;READER BUFFER, (TKB),
;TEST ABILITY TO REFERENCE PUNCH/PRINTER STATUS WORD (TPS),
004624 000002 AT21 2 ;TEST #,
004626 004656 AT3 ;NEXT TEST,
004630 001750 1000, ;! COUNT,
004632 004642 AT2A ;SCOPE ENTRY,
004634 012767 004652 173142 MOV #AT2E,MACHER ;SETUP MACHINE ERROR TRAP,
004642 005777 174344 AT2A1 TST 0TPS ;REFERENCE PUNCH/PRINTER STATUS WORD,
004646 104012 AT2B1 CHAIN ;CHAIN
004650 000774 BR AT2A ;REPEAT TEST,
004652 104003 AT2E1 ERROR ;ERROR, TRAPPED WHEN REFERENCING
004654 000774 BR AT2B ;PUNCH/PRINTER STATUS WORD (TPS),
;TEST ABILITY TO REFERENCE PUNCH/PRINTER BUFFER (TPB),
004656 000003 AT31 3 ;TEST #,
004660 004710 AT4 ;NEXT TEST,
004662 001750 1000, ;! COUNT,
004664 004674 AT3A ;SCOPE ENTRY,
004666 012767 004704 173110 MOV #AT3E,MACHER ;SETUP MACHINE ERROR TRAP,
004674 005777 174314 AT3A1 TST 0TPB ;REFERENCE PUNCH/PRINTER BUFFER,
004700 104012 AT3B1 CHAIN ;CHAIN
004702 000774 BR AT3A ;REPEAT TEST,
004704 104003 AT3E1 ERROR ;ERROR, TRAPPED WHEN REFERENCING
004706 000774 BR AT3B ;PUNCH/PRINTER BUFFER, (TPS),

```



```

)TEST ABILITY TO SET AND CLEAR READER/KYBD ID BIT
004710 000004 AT4I 4 )TEST #
004712 004774 AT5 )NEXT TEST
004714 001750 1000, )I COUNT
004716 004726 AT4A )SCOPE ENTRY
004720 012767 000340 173050 MOV #PRTY7,PSW )SET PRIORITY 7,
004726 052777 000100 174252 AT4AI BIS #BIT6,0TKS )SET ID BIT IN TKS,
004734 032777 000100 174244 BIT #BIT6,0TKS )CHECK ID BIT IN TKS
004742 001002 BNE AT4B )BRANCH IF ID BIT IS SET,
004744 104003 AT4E1I ERROR )ERROR 1 ID BIT NOT SET,
004746 000410 BR AT4C
004750 042777 000100 174230 AT4BI BIC #BIT6,0TKS )CLEAR ID BIT IN TKS
004756 032777 000100 174222 BIT #BIT6,0TKS )CHECK ID BIT IN TKS,
004764 001401 BEQ AT4C )BRANCH IF ID BIT IS CLEARED,
004766 104003 AT4E2I ERROR )ERROR, ID BIT FAILED TO CLEAR,
004770 104012 AT4CI CHAIN )CHAIN
004772 000755 BR AT4A )REPEAT TEST.

)TEST ABILITY TO CLEAR ID BIT WITH RESET INSTRUCTION.
004774 000005 AT5I 5 )TEST #
004776 005040 AT24 )NEXT TEST
005000 000144 100, )I COUNT
005002 005012 AT5A )SCOPE ENTRY,
005004 012767 000340 172764 MOV #PRTY7,PSW )SET PRIORITY 7,
005012 052777 000100 174166 AT5AI BIS #BIT6,0TKS )SET ID BIT IN TKS
005020 104011 SRESET )RESET
005022 032777 000100 174156 BIT #BIT6,0TKS )TEST ID BIT,
005030 001401 BEQ AT5B )BRANCH IF ID BIT IS CLEAR,
005032 104003 AT5E1 ERROR )ERROR, RESET FAILED TO CLEAR ID BIT,
005034 104012 AT5BI CHAIN )CHAIN
005036 000765 BR AT5A )REPEAT TEST.

```



```

005246 000027
005250 005304
005252 000144
005254 005250
005256 052777 000004 173726
005264 104011
005266 032777 000004 173716
005274 001401
005276 104003
005300 104012
005302 000765

005304 000030
005306 005330
005310 001750
005312 005314
005314 105777 173672
005320 100401
005322 104003
005324 104012
005326 000772

005330 000031
005332 005366
005334 000024
005336 005340
005340 104400
005342 000226
005344 104011
005346 005077 173642
005352 105777 173634
005356 100001

005360 104003
005362 104012
005364 000765

005366 000032
005370 005430
005372 000024
005374 005376
005376 104400
005400 000226
005402 104011
005404 016700 173604
005410 005200
005412 105010
005414 105777 173572
005420 100401
005422 104003
005424 104012
005426 000765

JTEST THAT RESET INSTRUCTION CLEARS THE MAINTENANCE BIT;
AT27I 27
      AT30
      100,
      AT27A
AT27AI BIS #BIT2,0TPS
      SRESET
      BIT #BIT2,0TPS
      BEQ AT27B
AT27EI ERROR
AT27BI CHAIN
      BR AT27A

JTEST THAT RESET SETS THE PUNCH READY BIT, AND THAT READY CAN BE READ RELIABLY.
AT30I 30
      AT31
      1000,
      AT30A
AT30AI TSTB 0TPS
      BMI AT30B
AT30EI ERROR
AT30BI CHAIN
      BR AT30A

JTEST THAT PUNCH READY RESETS BY LOADING PUNCH BUFFER.
AT31I 31
      AT32
      20,
      AT31A
AT31AI DELAY
      150,
      SRESET
      CLR 0TPB
      TSTB 0TPS
      BPL AT31B

AT31EI ERROR
AT31BI CHAIN
      BR AT31A

JTEST THAT BYTE LOAD OF PUNCH BUFFER +1 DOES NOT RESET READY.
AT32I 32
      AT33
      20,
      AT32A
AT32AI DELAY
      150,
      SRESET
      MOV TPB,X0
      INC X0
      CLRB 0X0
      TSTB 0TPS
      BMI AT32B
AT32EI ERROR
AT32BI CHAIN
      BR AT32A

JTEST#
INEXT TEST
I! COUNT
ISCOPE ENTRY
ISET MAINTENANCE BIT.
ISSUE RESET
ICHECK MAINTENANCE BIT
IBRANCH IF MAINTENANCE BIT CLEAR.
IERROR; RESET FAILED TO CLEAR
ITHE MAINTENANCE BIT; CHAIN.
IREPEAT TEST.

JTEST#
INEXT TEST
I! COUNT
ISCOPE ENTRY
ICHECK PUNCH READY.
IBRANCH IF PUNCH READY IS SET.
IERROR; RESET FAILED TO SET READY, OR FAILED TO READ IT.
ICHAIN
IREPEAT TEST.

JTEST#
INEXT TEST
I! COUNT
ISCOPE ENTRY
IWAIT 150 MSEC

IRESET
ILOAD PUNCH BUFFER
ICHECK PUNCH READY BIT.
IBRANCH IF PUNCH READY IS CLEAR.

IERROR; BUFFER LOAD FAILED TO CLEAR READY.
ICHAIN
IREPEAT TEST.

JTEST#
INEXT TEST
I! COUNT
ISCOPE ENTRY
IWAIT 150 MSEC

IRESET

IBYTE LOAD PUNCH BUFFER+1
ICHECK PUNCH READY BIT
IBRANCH IF PUNCH READY STILL SET.
IERROR; BYTE LOAD OF PUNCH BUFFER+1
ICLEARED READY; CHAIN
IREPEAT TEST.

```

```

005430 000033
005432 005470
005434 000024
005436 005440
005440 104400
005442 000226
005444 005077 173544
005450 104400
005452 000310
005454 105777 173532
005460 100401
005462 104003
005464 104012
005466 000764

ITEST THAT PUNCH BECOMES READY BY 200 MSECS AFTER BUFFER LOAD,
AT33I 33
AT33A 20,
AT33A1 AT33A
DELAY 150,
CLR 0TPB
DELAY 200,
TSTB 0TPS
BHI AT33B
AT33E1 ERROR
AT33B1 CHAIN
BR AT33A

ITEST #
INEXT TEST
II COUNT
ISCOPE ENTRY,
IWAIT 150 MSECS,
ILOAD PUNCH BUFFER,
IWAIT 200 MSECS,
ICHECK PUNCH READY BIT,
IBRANCH IF PUNCH READY IS SET,
IERROR, READY NOT SET 200 MSECS AFTER BUFFER LOAD,
ICHAIN
IREPEAT TEST,

ITEST THAT PUNCH READY BIT CAN CAUSE AN INTERRUPT, IF THE INTERRUPT
IS SERVICED, IT WILL HAVE OCCURRED AT THE CORRECT VECTOR,
AT34I 34
AT34 1000,
AT34A STPCHV
AT34C
AT34A1 CLR 0TPS
CLR PSW
BIS 0BIT6,0TPS
NOP
AT34E1 ERROR
AT34B1 CHAIN
BR AT34A
AT34C1 POPSP2
BR AT34B

ITEST THAT PUNCH READY DOES NOT CAUSE AN INTERRUPT WITH PROCESSOR
AT SAME PRIORITY LEVEL AS THE PUNCH INTERRUPT REQUEST LEVEL,
AT35I 35
AT35 1000,
AT35A STPCHV
AT35E
AT35A1 MOV TPLVL,PSW
CLR 0TPS
BIS 0BIT6,0TPS
NOP
AT35B1 CLR 0TPS
CHAIN
BR AT35A
AT35E1 POPSP2
ERROR
BR AT35B

ITEST #
INEXT TEST
II COUNT
ISCOPE ENTRY
ISET PUNCH INTERRUPT SERVICE
ITO AT34C
IDISABLE PUNCH INTERRUPTS
ISET PRIORITY 0,
IENABLE PUNCH INTERRUPTS,
IPUNCH READY FAILED TO CAUSE
INTERRUPT, CHAIN
IREPEAT TEST,
IHERE IF INTERRUPT OCCURS, POP THE
ISTOCK TWICE,
ISET PROCESSOR TO SAME PRIORITY AS PUNCH,
IDISABLE PUNCH INTERRUPTS,
IENABLE PUNCH INTERRUPTS,
IOK IF NO INTERRUPT OCCURS,
ICHAIN
IREPEAT TEST,
IERROR, PUNCH INTERRUPTED WITH PROCESSOR
ISET TO SAVE PRIORITY AS THE PUNCH,

```


TEST THAT THE PUNCH INTERRUPTS IMMEDIATELY UPON LOWERING
PROCESSOR PRIORITY TO 0.

```

005770 000040
005772 006054
005774 001750
005776 006004
006000 104007
006002 006042
006004 012767 000340 171764 AT40A1 MOV #PRTY7,PSW
006012 005077 173174 CLR #TPS
006016 052777 000100 173166 BIS #BIT6,#TPS
006024 005067 171746 CLR PSW
006030 012767 000340 171740 MOV #PRTY7,PSW
006036 104003 ERROR
006040 000401 BR AT40C
006042 022626 AT40B1 POPSP2
006044 005077 173142 AT40C1 CLR #TPS
006050 104012 CHAIN
006052 000754 BR AT40A
    
```

```

TEST #
NEXT TEST
COUNT
SCOPE ENTRY
SET PUNCH INTERRUPT
SERVICE TO AT40B
SET PROCESSOR PRIORITY TO 7.
DISABLE PUNCH INTERRUPTS
ENABLE PUNCH INTERRUPTS
LOWER PROCESSOR PRIORITY TO 0.
RAISE PRIORITY TO 7.
ERROR, PUNCH FAILED TO INTERRUPT
IMMEDIATELY AFTER CP PRIORITY WAS SET TO 0.
HERE IF INTERRUPT OCCURS
DISABLE PUNCH INTERRUPTS
CHAIN
REPEAT TEST
    
```

TEST FOR CORRECT OPERATION OF THE WAIT INSTRUCTION. A WAIT INSTRUCTION
IS PERFORMED WHILE WAITING FOR A PUNCH INTERRUPT. WHEN THE INTERRUPT
OCCURS, THE SERVICE ROUTINE CHANGES THE WAIT INSTRUCTION TO AN ERROR
CALL AND THEN EXITS THE INTERRUPT WITH AN RTI, EXITING THE INTERRUPT
SHOULD RETURN CONTROL TO THE INSTRUCTION FOLLOWING THE WAIT INSTRUCTION.
IF CONTROL IS INSTEAD RETURNED TO THE SAME LOCATION WHERE THE WAIT
INSTRUCTION WAS LOCATED AN ERROR CALL WILL OCCUR, INDICATING A FAILURE
OF THE WAIT INSTRUCTION.

```

006054 000041
006056 006142
006060 000062
006062 006074
006064 104400
006066 000226
006070 104007
006072 006132
006074 012767 000001 000010 AT41A1 MOV #WAIT,AT41B
006102 005077 173106 CLR #TPB
006106 052777 000100 173070 BIS #BIT6,#TPS
006114 005067 171656 CLR PSW
006120 000000 AT41B1 OPEN

006122 005077 173064 CLR #TPS
006126 104012 CHAIN
006130 000761 BR AT41A
006132 012767 104003 177760 AT41C1 MOV #ERROR,AT41B
006140 000002 RTI
    
```

```

TEST#
NEXT TEST
COUNT
SCOPE ENTRY
WAIT 150 MSECS

SET PUNCH INTERRUPT SERVICE
TO AT41C
MOVE WAIT INSTRUCTION TO AT41B
LOAD PUNCH BUFFER (ENABLES PUNCH)
ENABLE PUNCH INTERRUPTS
SET PRIORITY 0.
THIS LOCATION CAN BE EITHER
A WAIT INSTRUCTION OR AN ERROR CALL.
IF AN ERROR CALL IS EXECUTED, IT
INDICATES A FAILURE OF THE WAIT INSTRUCTION.
DISABLE PUNCH INTERRUPTS
CHAIN
REPEAT TEST
MOVE ERROR CALL TO AT41B.
EXIT INTERRUPT.
    
```



```

ITEST THAT LOADING THE PUNCH BUFFER WITH THE MAINTENANCE BIT SET
ICAUSES THE READER DONE BIT TO SET AFTER APPROX, 200 MSECS
006142 000042 AT42I 42 ITEST 0
006144 177777 -1 ILAST TEST
006146 000062 90, I! COUNT
006150 006156 AT42A DELAY ISCOPE ENTRY
006152 104400 150,
006154 000226 150,
006156 052777 000204 173026 AT42A1 BIS #BIT2,OTPS ISET MAINTENANCE BIT
006164 005077 173024 CLR #TPB ILOAD PUNCH BUFFER
006170 104400 DELAY IWAIT 200 MSECS
006172 000310 200,
006174 105777 173006 TSTB @TKS ITEST READER DONE BIT
006200 100401 BMI AT42B IBRANCH IF READER DONE BIT SET;
006202 104003 AT42E1 ERROR IERROR, 200 MSECS AFTER PUNCH
IBUFFER LOAD WITH MAINTENANCE BIT
ISET THE READER DONE BIT WAS NOT SET
006204 104012 AT42B1 CHAIN ICHAIN
006206 000763 BR AT42A IREPEAT TEST

```

```

I PRG2-PRINTER TESTS
006210 012767 006242 173014 PRG11 MOV #CT0,KSTART ISET ADDRESS IF 1ST ROUTINE,
006216 052767 000200 173022 015 #017,PRCID IBYPASS SCOPE AND ICNT,
006224 012767 177600 174770 MOV #177600,STLMSK ISET STALL LIMIT
006232 004767 176046 JSR X7,STBF ISET UP BUFFER AREA,
006236 000167 173330 JMP SRSET IGO GET STARTED,

ICARRIAGE RETURN TEST,
006242 000000 CT01 0 ITEST#
006244 006344 CT1 INEXT TEST ADDRESS,
006246 104000 TYPE ITYPE TITLE,
006250 011100 CRTST
006252 012767 000110 173062 MOV #72,,RCNT
006260 016767 173056 173070 MOV RCNT,CTRA IRCNT TO CTRA
006266 005367 173064 CT0A1 DEC CTRA IDECREMENT CTRA
006272 001001 BNE CT0B IBRANCH IF NOT 0
006274 104012 CHAIN IB, CHAIN
006276 016767 173054 173054 CT0B1 MOV CTRA,CTRB ISPACE COUNT TO CTRB,
006304 112700 000105 CT0C1 MOVB #105,X0 ICHAR#E
006310 004767 175532 JSR X7,LSPCH ISPACE,
006314 005367 173040 DEC CTRB IDECREMENT CTRB,
006320 001371 BNE CT0C IBRANCH IF NOT DONE SPACING,
006322 112700 000015 MOVB #15,X0
006326 004767 175514 JSR X7,LSPCH ICARRIAGE RETURN,
006332 012700 000012 MOV #12,X0 ILINE FEED
006336 004767 175504 JSR X7,LSPCH
006342 000751 BR CT0A I

IRIGHT MARGIN TEST
006344 000001 CT11 1 ITEST#
006346 006410 CT2 INEXT TEST,
006350 104000 TYPE ITYPE TITLE
006352 011137 RMTST
006354 012767 000016 172774 MOV #14,,CTRA ISET UP FOR 33/35
006362 012767 011067 000014 MOV #RM330,RMB
006370 104000 CT1A1 TYPE
006372 011061 RM33A
006374 005367 172756 DEC CTRA IDONE N TIMES,
006400 001373 BNE CT1A IBRANCH IF NOT N TIMES
006402 104000 TYPE ITYPE=-,
006404 000000 RMB1 OPEN
006406 104012 CHAIN ICHAIN,

```



```

006410 000002
006412 006562
006414 104000
006416 011165
006420 012767 000044 172730
006426 104000
006430 011103
006432 005367 172720
006436 001373
006440 012767 000044 172710
006446 012767 000001 172704
006454 016767 172700 172700
006462 112700 000015
006466 004767 175354
006472 004767 175350
006476 005000
006500 004767 175342
006504 004767 175336
006510 004767 175332
006514 112700 000030
006520 004767 175322
006524 005367 172632
006530 001362
006532 112700 000057
006536 004767 175304
006542 005367 172610
006546 001001
006550 104012
006552 062767 000002 172600
006560 000735

006562 000003
006564 006642
006566 104000
006570 011213
006572 052767 040000 172446
006600 012767 000110 172550
006606 112700 000134
006612 004767 175230
006616 112700 000012
006622 004767 175220
006626 005367 172524
006632 001001
006634 104012
006636 104002
006640 000762

```

```

ICURSOR RIGHT TEST
CT2I 2
CT3
TYPE
SPTST
MOV #36,,CTRA
CT2AI TYPE
SPTSTC
DEC CTRA
BNE CT2A
MOV #36,,CTRA
CT2BI MOV #1,CTRB
CT2CI MOV CTRB,CTRC
MOV #15,X0
JSR X7,LSPCH
JSR X7,LSPCH
CT2DI CLR X0
JSR X7,LSPCH
JSR X7,LSPCH
JSR X7,LSPCH
MOV #30,X0
JSR X7,LSPCH
DEC CTRC
BNE CT2D
MOV #1,X0
JSR X7,LSPCH
DEC CTRA
BNE CT2E
CHAIN
CT2EI ADD #2,CTRB
BR CT2C

ILINE FEED TEST
CT3I 3
CT4
TYPE
LFTST
BIS #BIT14,PRGID
MOV #72,,CTRA
CT3AI MOV #'\,X0
JSR X7,LSPCH
MOV #12,X0
JSR X7,LSPCH
DEC CTRA
BNE CT3B
CHAIN
CT3BI STALL
BR CT3A

ITEST#
INEXT TEST
ITYPE TITLE,
I33/35 COUNT TO CTRA,
ITYPE SPACE,\,
IDONE TIMES SET IN CTRA?
IBRANCH IF NOT DONE
ISET UP CTRA COUNT FOR 33/35

ICARRIAGE RETURN,
IDUMMY CYCLE,
INULL CHAR FOR FILLER
ITRANSMIT NULL CHAR
ITRANSMIT NULL CHAR
ITRANSMIT NULL CHAR
ICURSOR RIGHT
ISET IN CTRC,
IDONE SPACING,
IBRANCH IF NOT DONE SPACING,
IDONE, TYPE A "/",
IDONE 36 TIMES?
IBRANCH IF NOT DONE,
IDONE, CHAIN,
IMODIFY CTRB FOR NEXT TRY,
IGO DO IT AGAIN,
ITEST #
INEXT TEST,
ITYPE TITLE
IALLOW STALLS,
ISET 33/35 LINE FEED COUNT,
ITYPE "\,
ILINE FEED,
IDONE N TIMES?
IBRANCH IF NOT DONE,
IDONE, CHAIN
ISTALL
IREPEAT

```


007054	000005	ITYPE LINE OF CHARACTERS ABC	ITEST #
007056	007072	CT51 5	INEXT TEST
007060	104000	CT6	ITYPE "CHARACTER TESTS"
007062	011236	TYPE	
007064	104016	CHRTST	
007066	010714	TYPLN3	ITYPE LINE
007070	104012	A	
		CHAIN	ICHAIN
007072	000006	ITYPE LINE OF CHARACTERS DEF	ITEST #
007074	007104	CT61 6	INEXT TEST
007076	104016	CT7	ITYPE LINE
007100	010717	TYPLN3	
007102	104012	D	
		CHAIN	ICHAIN
007104	000007	ITYPE LINE OF CHARACTERS GHI	ITEST#
007106	007116	CT71 7	INEXT TEST.
007110	104016	CT10	ITYPE LINE
007112	010722	TYPLN3	
007114	104012	G	
		CHAIN	ICHAIN
007116	000010	ITYPE LINE OF CHARACTERS OF JKL	ITEST #
007120	007130	CT101 10	INEXT TEST.
007122	104016	CT11	ITYPELINE
007124	010725	TYPLN3	
007126	104012	J	
		CHAIN	ICHAIN
007130	000011	ITYPE LINE OF CHARACTERS MNO	ITEST #
007132	007142	CT111 11	INEXT TEST
007134	104016	CT12	ITYPE LINE
007136	010730	TYPLN3	
007140	104012	M	
		CHAIN	ICHAIN
007142	000012	ITYPE LINE OF CHARACTERS PQR	ITEST #
007144	007154	CT121 12	INEXT TEST
007146	104016	CT13	ITYPE LINE
007150	010733	TYPLN3	
007152	104012	P	
		CHAIN	ICHAIN
007154	000013	ITYPE LINE OF CHARACTERS STU	ITEST #
007156	007166	CT131 13	INEXT TEST
007160	104016	CT14	
007162	010736	TYPLN3	
007164	104012	S	
		CHAIN	

007166	000014	ITYPE LINE OF CHARACTERS VHX	ITYEST #
007170	007200	CT141 14	INEXT TEST
007172	104016	CT15	ITYPE LINE
007174	010741	TYPLN3	
007176	104012	V	
		CHAIN	ICHAIN
007200	000015	ITYPE LINE OF CHARACTERS YEB	ITYEST #
007202	007212	CT151 15	INEXT TEST
007204	104016	CT16	ITYPE LINE
007206	010744	TYPLN3	
007210	104012	Y	
		CHAIN	ICHAIN
007212	000016	ITYPE LINE OF CHARACTERS 123	ITYEST #
007214	007224	CT161 16	INEXT TEST
007216	104016	CT17	ITYPE LINE
007220	010747	TYPLN3	
007222	104012	ONE	
		CHAIN	ICHAIN
007224	000017	ITYPE LINE OF CHARACTERS 456	ITYEST #
007226	007236	CT171 17	INEXT TEST
007230	104016	CT20	ITYPE LINE
007232	010752	TYPLN3	
007234	104012	FOUR	
		CHAIN	ICHAIN
007236	000020	ITYPE LINE OF CHARACTERS 789	ITYEST #
007240	007250	CT201 20	INEXT TEST
007242	104016	CT21	ITYPE LINE
007244	010755	TYPLN3	
007246	104012	SEVEN	
		CHAIN	ICHAIN
007250	000021	ITYPE LINE OF CHARACTERS!"#	ITYEST #
007252	007262	CT211 21	INEXT TEST
007254	104016	CT22	ITYPE LINE
007256	010760	TYPLN3	
007260	104012	C41	
		CHAIN	ICHAIN
007262	000022	ITYPE LINE OF CHARACTERS \$%&	ITYEST #
007264	007274	CT221 22	INEXT TEST
007266	104016	CT23	ITYPE LINE
007270	010763	TYPLN3	
007272	104012	C44	
		CHAIN	ICHAIN
007274	000023	ITYPE LINE OF CHARACTERS '()	ITYEST #
007276	007306	CT231 23	INEXT TEST
007300	104016	CT24	ITYPE LINE
007302	010766	TYPLN3	
007304	104012	C47	
		CHAIN	ICHAIN

007440 000033
 007442 007522
 007444 104013
 007446 104012
 007450 104000
 007452 011262
 007454 004767 174746
 007460 012767 000000 171670
 007466 042767 040000 171552
 007474 004767 174510
 007500 052767 040000 171540
 007506 004767 174476
 007512 005367 171640
 007516 001363
 007520 104012

ITYPE 12 LINES OF ASR33 WORST CASE PATTERN, ALTERNATE LINES WITH STALLS.

CT33I J3
 CT34
 CK33
 CHAIN
 TYPE
 WCPTST
 JSR X7,FH336
 MOV #6,CTRA
 CT33AI BIC #BIT14,PRGID
 JSR X7,TYPLN
 BIS #BIT14,PRGID
 JSR X7,TYPLN
 DEC CTRA
 BNE CT33A
 CHAIN

ITEST #
 INEXT TEST
 I33?
 INO, BYPASS TEST.
 ITYPE "WORST CASE PATTERN TEST"
 IPATTERN TO BUFFER.
 ISET COUNT TO 6
 ICLEAR STALL BIT IN PRGID.
 ITYPE LINE
 ISET STALL BIT IN PRGID.
 ITYPE LINE.
 IDONE 6 TIMES?
 IBRANCH IF NOT 6 TIMES YET.
 IDONE, CHAIN.

007522 000034
 007524 177777
 007526 104014
 007530 104012
 007532 104000
 007534 011262
 007536 004767 174724
 007542 012767 000000 171600
 007550 042767 040000 171470
 007556 004767 174420
 007562 052767 040000 171450
 007570 004767 174414
 007574 005367 171550
 007600 001363
 007602 104012

ITYPE 12 LINES OF ASR33 WORST CASE PATTERN, ALTERNATE LINES WITH STALLS.

CT34I J4
 -1
 CK33
 CHAIN
 TYPE
 WCPTST
 JSR X7,FH336
 MOV #6,CTRA
 CT34AI BIC #BIT14,PRGID
 JSR X7,TYPLN
 BIS #BIT14,PRGID
 JSR X7,TYPLN
 DEC CTRA
 BNE CT34A
 CHAIN

ITEST #
 ILAST TEST.
 I35?
 INO, BYPASS TEST.
 ITYPE "WORST CASE PATTERN TEST"
 IPATTERN TO BUFFER.
 ISET COUNT TO 6.
 ICLEAR STALL BIT IN PRGID.
 ITYPE LINE.
 ISET STALL BIT IN PRGID.
 ITYPE LINE
 IDONE 6 TIMES?
 IBRANCH IF NOT 6 TIMES YET.
 IDONE, CHAIN.


```

)PRG2=KEYBOARD TEST
007604 012767 007630 171420 PRG21 MOV #ET0,KSTART
007612 052767 000200 171420 BIS #BIT7,PRG1D
007620 104000 TYPE
007622 011316 KMSG1
007624 000167 171742 JMP SRSET
)TEST THAT PRESSING KEY SETS DONE FLAG.
007630 000000 ET01 0 )TEST #
007632 007734 ET1 )NEXT TEST.
007634 012767 000005 171514 MOV #5,CTRA
007642 104000 ET0A1 STRDRV
007644 007700 ET00
007646 104000 TYPE )TYPE "PRESS A KEY WITHIN 10 SECS,"
007650 011334 KMSG2 )ENABLE KYBD INTERRUPT.
007652 052777 000100 171326 BIS #BIT6,@TKS
007660 005067 170112 CLR PSH
007664 104400 DELAY )WAIT 10 SECONDS
007666 023420 10000,
007670 104000 TYPE )TYPE "NO KEYBOARD REQUEST,"
007672 011536 KMSG6
007674 104010 EHALT )HALT.
007676 000411 BR ET0CA
007700 105777 171302 ET001 TSTB @TKS
007704 100403 BHI ET0C )TEST FOR DONE BIT ON
007706 104000 TYPE )BRANCH IF DONE BIT SET.
007710 011564 KMSG7 )DONE BIT NOT SET, TYPE IF FALSE KEY-
007712 104010 EHALT )BOARD OR READER INTERRUPT.
007714 012716 007722 ET0C1 MOV #ET0CA,@X6 )HALT
007720 000002 RTI )EXIT INTERRUPT.
007722 104011 ET0CA1 SRESET
007724 005367 171426 DEC CTRA )DONE 5 TIMES?
007730 001344 BNE ET0A )BRANCH IF NOT DONE.
007732 104012 CHAIN )CHAIN
)ECHO TEST, KEYED CHARACTER IS TYPED, RUBOUT ENDS ROUTINE.
007734 000001 ET11 1 )TEST #
007736 010014 ET2 )NEXT TEST.
007740 104000 TYPE )TYPE TITLE AND INSTRUCTIONS.
007742 011374 KMSG3
007744 105777 171236 ET1A1 TSTB @TKS
007750 100375 BPL ,-4 )WAIT FOR DONE FLAG
007752 117767 171232 171364 MOVB @TKB,CRBUF )MOVE KYBD CHAR TO CRBUF.
007760 116777 171360 171226 MOVB CRBUF,@TPB )ECHO CHAR READ.
007766 105777 171220 TSTB @TPS )WAIT FOR PRINTER DONE.
007772 100375 BPL ,-4
007774 042767 000200 171342 BIC #BIT7,CRBUF )CLEAR BIT 7 FROM CRBUF.
010002 122767 000177 171334 CMPB #177,CRBUF )COMPARE CRBUF TO RUBOUT (177)
010010 001355 BNE ET1A )BRANCH IF NOT RUBOUT (177)
010012 104012 CHAIN )CHAIN

```

IOCTAL EQUIVALENT TEST, THE OCTAL EQUIVALENT OF ANY CHARACTER KEYED
 IIS PRINTED, RUBOUT ENDS ROUTINE:

010014 000002
 010016 177777
 010020 104001
 010022 011470
 010024 011407
 010026 177777
 010030 009067 171310
 010034 109777 171146
 010040 100379
 010042 117767 171142 171274
 010050 004567 173622
 010054 001344
 010056 011530
 010060 104000
 010062 011526
 010064 042767 000200 171252
 010072 022767 000177 171244
 010100 001355
 010102 104012

ET2I 2
 -1
 TYPES
 KMSG4
 KMSG3A
 -1
 CLR CRBUF
 ET2A1 TSTB 0TKS
 BPL ,=4
 MOVB 0TKB,CRBUF
 JSR XS,ACNV4
 CRBUF
 OCTEQV
 TYPE
 KMSG5
 BIC #BIT7,CRBUF
 CMP #177,CRBUF
 BNE ET2A
 CHAIN

I*TEST #
 I*LAST TEST
 I*TYPE TITLE AND INSTRUCTIONS.

I*WAIT FOR DONE FLAG.

I*CHARACTER TO CRBUF
 I*CONVERT CHAR IN CRBUF TO
 I*PRINTABLE OCTAL

I*TYPE OCTAL EQUIVALENT

I*CLEAR BIT 7 FROM CRBUF
 I*TEST FOR RUBOUT CHARACTER.
 I*BRANCH IF NOT RUBOUT (177).
 I*CHAIN.


```

|PRG3=PRINTER EXERCISER, KEYBOARD CONTROLLED,
|TYPES LINES WITH ANY 5 CHARACTERS, STALLS OR FULL SPEED,
PRG3: JSR X7,STBF ISET UP BUFFER,
TYPE ITYPE TITLE
P7MG1
HTA: BIS #BIT14,PRGID ISET STALL BIT IN PRGID.
MOV #177600,STLMSK ISET STALL MASK
MOV #BLOCK1,X3
TYPE ITYPE "TYPE IN DATA".
P7MG2
HTB: MOV #6,CTRA ICHAR COUNT TO CTRA.
JSR X7,GKBCR IGET AND STORE KYBD CHARACTER.
DEC CTRA IGET 6 CHARACTERS?
BNE HTB IBRANCH IF NOT 6 CHARS YET.
BIC #BIT7,CRBUF
CMPB #177,CRBUF ICHECK 6TH CHAR FOR RUBOUT.
BNE HTC IBRANCH IF NOT A RUBOUT.
BIC #BIT14,PRGID IRUBOUT. CLEAR STALL BIT IN PRGID.
JSR X9,BMOVE IFILL 92 CHAR LINE.
BLOCK1
BLOCK1+5
67.
HTD: JSR X7,TYPLN ITYPE LINE.
TST SR ICHANGE DATA? (SR15=1).
BHI HTA IYES. GO CHANGE DATA
BR HTD INO CONTINUE WITH SAME DATA.
GKBCR: TSTB #TKS IWAIT FOR DONE FLAG.
EPL ,=4
MOVB #TKB,CRBUF ICHARACTER TO CRBUF.
MOVB CRBUF,(3)+ ICHARACTER TO LINE BUFFER.
MOVB CRBUF,X0
JSR X7,LSPCH IECHO CHARACTER.
RTS X7

```

Handwritten mark or signature in the bottom right corner.

010264 104005
 010266 004767 000036
 010272 000775

```

|
|
|PRG4=PUNCH CLOCK ADJUSTMENT ROUTINE.
|OUTPUTS CHARACTER SET IN LEFT HALF OF SR, AND
|STALLS FOR NUMBER OF MILLISECONDS SET IN RIGHT HALF OF SR.
PRG4I  CHALT          IHALT TO SET SR,
|TAI   JSR           X7,C1112  IGO OUTPUT CHARACTER SET IN LEFT
|      BR            ITA      IHALF OF SR AND STALL PER SR RIGHT.
    
```

010274 104005
 010276 004767 000020
 010302 017700 170702
 010306 000005
 010310 000005
 010312 000005
 010314 000005
 010316 000005
 010320 000766

```

|
|
|PRG5=READER CLOCK ADJUSTMENT ROUTINE.
|PERFORMS SAME FUNCTION AS PRG11, AND IN ADDITION,
|USING THE PUNCH MAINTENANCE BIT, SHIFTS OUTPUT OF PUNCH
|SHIFT REGISTER ONTO THE READER BUFFER, THE CONTENTS OF THE
|READER BUFFER ARE THEN "FIXED" ON THE CONSOLE DATA LIGHTS
|BY ISSUING A RESET WITH CONTENTS OF READER BUFFER LOADED IN R0.
PRG5I  CHALT          IHALT TO SET SR,
|TAI   JSR           X7,C1112M  IGO OUTPUT CHARACTER FROM SR LEFT AND
|      MOV           0TKB,X0    ISTALL PER SR RIGHT, (TKB) TO R0,
|      RESET                          I"FIX" (TKB) IN DATA LIGHTS.
|      RESET
|      RESET
|      RESET
|      RESET
|      BR            JTA      IREPEAT.
    
```

010322 052777 000004 170662
 010330 116767 107234 000022
 010336 005767 000016
 010342 001002
 010344 005267 000010
 010350 116777 107215 170636
 010356 104400
 010360 000000
 010362 000207

```

|
|C1112M1 BIS #4,0TPS ISET MAINTENANCE MODE (PUNCH).
|C1112I MOVB SR,XTY ISTALL COUNT TO XTY.
|      TST XTY IDISREGARD 0 DELAY.
|      BNE C1112A
|      INC XTY
|C1112A1 MOVB SR+1,0TPB ILOAD PUNCH BUFFER.
|      DELAY IDELAY (APPROXIMATELY) THE NUMBER OF
|XTYI OPEN INSECS, SPECIFIED AT SR RIGHT
|      RTS X7 IEXIT
    
```


IPRG6=MAINTENANCE MODE SINGLE CHARACTER DATA TEST,
 WITH MAINTENANCE MODE SET, OUTPUTS ONTO PUNCH BUFFER AND BACK ONTO
 READER BUFFER THE CHARACTER SET IN SR LEFT, THE CHARACTER IN THE
 READER BUFFER IS COMPARED TO THE CHARACTER IN SR LEFT, IF THE 2 CHARACTERS
 DISAGREE THE PROGRAM HALTS, THE DATA LIGHTS WILL THEN CONTAIN

010364 104005
 010366 052777 000004 170610
 010374 105777 170612
 010400 100375
 010402 116767 107163 170735
 010410 116777 170731 170570
 010416 105777 170564
 010422 100375
 010424 117767 170560 170712
 010432 104004
 010434 000754

LEFT HALF: THE EXPECTED CHARACTER (SR LEFT),
 RIGHT HALF: THE CHARACTER IN THE READER BUFFER,
 PRG6: CHALT ;HALT TO SET SR,
 KTA: BIS #4,OTPS ;SET MAINTENANCE MODE,
 KTB: TSTB 0TPS ;WAIT FOR READY,
 BPL ;=4
 MOVB SR+1,CRBUF+1 ;S/B CHAR TO CRBUF+1,
 MOVB CRBUF+1,0TPB ;OUTPUT CHARACTER,
 TSTB 0TKS ;WAIT FOR READER DONE FLAG,
 BPL ;=4
 MOVB 0TKB,CRBUF ;CHAR READ TO CRBUF,
 DATCHK ;GO CHECK AGAINST S/B CHAR,
 BR KTA ;REPEAT,

IPRG7=MAINTENANCE MODE SPECIAL BINARY COUNT PATTERN DATA TEST,
 PERFORMS SAME OPERATION AS PRG13, EXCEPT THAT SPECIAL BINARY COUNT
 PATTERN IS USED,

010436 004767 173034
 010442 012767 177600 172552
 010450 052767 040000 170570
 010456 052777 000004 170526
 010464 032767 000400 167076
 010472 001001
 010474 104002
 010476 105777 170510
 010502 100375
 010504 004767 173072
 010510 110167 170631
 010514 110177 170474
 010520 105777 170462
 010524 100375
 010526 117767 170456 170610
 010534 104004
 010536 000747

PRG7: JSR X7,INBIN ;INITIALIZE BINARY COUNT
 MOV #177600,STLMSK ;SET STALL LIMIT
 BIS #BIT14,PRGID ;ALLOW STALLS
 LTA: BIS #4,OTPS ;SET MAINTENANCE MODE,
 BIT #BIT0,SR ;CHECK STALL SWITCH
 BNE LTB ;BRANCH IF NO STALL WANTED
 STALL ;STALL
 LTB: TSTB 0TPS ;WAIT FOR READY,
 BPL ;=4
 JSR X7,GTBINP ;GET BIN CHARACTER,
 MOVB X1,CRBUF+1 ;MOVE TO S/B CHAR,
 MOVB X1,0TPB ;OUTPUT BIN CHARACTER,
 TSTB 0TKS ;WAIT FOR READER DONE,
 BPL ;=4
 MOVB 0TKB,CRBUF ;CHAR IN READ BUFFER TO CRBUF,
 DATCHK ;GO CHECK AGAINST S/B CHAR,
 BR LTA ;CONTINUE,

IPRG10 ROLE UP TEST

THE FUNCTION OF THIS TEST IS TO TEST THE ROLL-UP CAPABILITY
 OF THE VT06
 TO DO THIS A LINE OF A CHARACTER AND IT'S COMPLEMENT FOLLOWED
 BY A LINE OF THE COMPLEMENT AND THE CHARACTER IS TRANSMITTED
 THIS SCHEME IS CONTINUED UNTIL SWITCH 15 IS RAISED
 THE CHARACTER SHOULD NOT BE CHANGED UNTIL THE SCREEN HAS BEEN
 COMPLETELY FILLED

010540 012767 177736 000126
 010546 016767 000122 000122
 010554 012767 177670 000110
 010562 005167 000110

PRG10: MOV #42,TCHAR ;INIT TEMP CHAR
 RENIT: MOV TCHAR,CHAR ;COMPLEMENT OF "I"
 PRG10C: MOV #72,,CNT ;72 CHAR/LINE
 PRG10D: COM CHAR ;

010566	016700	000104		PRG10A1	MOV	CHAR,X0	ILOAD "!"
010572	004767	173250			JSR	X7,LSPCH	IPUNCH "!"
010576	005167	000074			COM	CHAR	ICOMPLEMENT TO "!"
010602	016700	000070			MOV	CHAR,X0	ILOAD "!"
010606	004767	173234			JSR	X7,LSPCH	IPUNCH "!"
010612	005167	000060			COM	CHAR	I "!"
010616	062767	000002	000046		ADD	#2,CNT	IEND OF LINE?
010624	001360				BNE	PRG10A	INO
010626	012700	000015			MOV	#15,X0	ICR
010632	004767	173210			JSR	X7,LSPCH	
010636	012700	000012			MOV	#12,X0	ILF
010642	004767	173200			JSR	X7,LSPCH	
010646	005767	166716			TST	SR	INEXT CHAR
010652	100340				BPL	PRG10C	INO
010654	005367	000014			DEC	TCHAR	IYES CHANGE TCHAR
010660	022767	177677	000006		CMP	#177677,TCHAR	ICCHAR STRING COMPLETE
010666	001724				BEO	PRG10	
010670	000726				BR	RENIT	
010672	000000						
010674	177736						
010676	000041						

CNT:	0
TCHAR:	-42
CHAR:	41

30

010700 047
010701 137
010702 127
010703 057
010704 127
010705 137
010706 047
010707 133
010710 077
010711 103
010712 077
010713 133
010714 101
010715 102
010716 103
010717 104
010720 105
010721 106
010722 107
010723 110
010724 111
010725 112
010726 113
010727 114
010730 115
010731 116
010732 117
010733 120
010734 121
010735 122
010736 123
010737 124
010740 125
010741 126
010742 127
010743 130
010744 131
010745 132
010746 060
010747 061
010750 062
010751 063
010752 064
010753 065
010754 066
010755 067
010756 070
010757 071
010760 041
010761 042
010762 043
010763 044
010764 045
010765 046

ASSHP61 ,BYTE 047,137,127,057,127,137

ASSHP61 ,BYTE 047,133,077,103,077,133

AI ,BYTE 101,102,103

DI ,BYTE 104,105,106

GI ,BYTE 107,110,111

J1 ,BYTE 112,113,114

MI ,BYTE 115,116,117

PI ,BYTE 120,121,122

SI ,BYTE 123,124,125

VI ,BYTE 126,127,130

YI ,BYTE 131,132,060

ONEI ,BYTE 061,062,063

FOURI ,BYTE 064,065,066

SEVENI ,BYTE 067,070,071

C41I ,BYTE 041,042,043

C44I ,BYTE 044,045,046

PALX11	V003	20-JUL-71	16102	PAGE 37-1
010766	047		C471	,BYTE 047,050,051
010767	050			
010770	051		C521	,BYTE 052,053,054
010771	052			
010772	053			
010773	054		C551	,BYTE 055,056,057
010774	055			
010775	056			
010776	057		C721	,BYTE 072,073,074
010777	072			
011000	073			
011001	074		C751	,BYTE 075,076,077
011002	075			
011003	076			
011004	077			
011005	100		C1001	,BYTE 100,133,134
011006	133			
011007	134			
011010	135		C1351	,BYTE 135,136,137
011011	136			
011012	137			
011013	377		C3771	,BYTE 377,000,377
011014	000			
011015	377			
011016	045		T0TST1	,ASCII 'X0SPACE TESTX0'
011017	043			
011020	123			
011021	120			
011022	101			
011023	103			
011024	105			
011025	040			
011026	124			
011027	105			
011030	123			
011031	124			
011032	045			
011033	043			
011034	040		T0MRK1	,ASCII ' /0'
011035	040			
011036	040			
011037	040			
011040	040			
011041	040			
011042	040			
011043	040			
011044	057			
011045	100			
011046	040		T0MRK11	,ASCII ' /0'
011047	040			
011050	040			
011051	040			
011052	040			

PALX11 V003 26-JUL-71

16102 PAGE 37-2

011053 040
011054 040
011055 057
011056 100

011057 045
011060 100

011061 055
011062 055
011063 055
011064 055
011065 111
011066 100

011067 055
011070 111
011071 055
011072 100

011073 055
011074 055
011075 055
011076 055
011077 111
011100 055
011101 111
011102 100

011103 134
011104 040
011105 100

011106 045
011107 043
011110 103
011111 101
011112 122
011113 122
011114 111
011115 101
011116 107
011117 105
011120 040
011121 122
011122 105
011123 124
011124 125
011125 122
011126 116
011127 040
011130 124
011131 105
011132 123
011133 124

CRLF1 ,ASCII 'X0'

RM33A1 ,ASCII '----|0'

RM33B1 ,ASCII '=|=0'

RM37A1 ,ASCII '----|=|0'

SPTSTC1 ,ASCII '\ 0'

CRTST1 ,ASCII '%CARRIAGE RETURN TEST%00'

011134 045
011135 043
011136 100

011137 045
011140 043
011141 122
011142 111
011143 107
011144 110
011145 124
011146 040
011147 115
011150 101
011151 122
011152 107
011153 111
011154 116
011155 040
011156 124
011157 105
011160 123
011161 124
011162 045
011163 043
011164 100

RMTST: ,ASCII 'XRIGHT MARGIN TESTX00'

011165 045
011166 043
011167 103
011170 125
011171 122
011172 123
011173 117
011174 122
011175 040
011176 122
011177 111
011200 107
011201 110
011202 124
011203 040
011204 124
011205 105
011206 123
011207 124
011210 045
011211 043
011212 100

SPTST: ,ASCII 'XCURSOR RIGHT TESTX00'

011213 045
011214 043
011215 114
011216 111
011217 116

LPTST: ,ASCII 'XLINE FEED TESTX00'

31

011220 105
011221 040
011222 106
011223 105
011224 105
011225 104
011226 040
011227 124
011230 105
011231 123
011232 124
011233 045
011234 043
011235 100

CHRTSTI ,ASCII 'X0CHARACTER TESTSX00'

011236 045
011237 043
011240 103
011241 110
011242 101
011243 122
011244 101
011245 103
011246 124
011247 105
011250 122
011251 040
011252 124
011253 105
011254 123
011255 124
011256 123
011257 045
011260 043
011261 100

WCPTSTI ,ASCII 'X0WORST CASE PATTERN TESTX00'

011262 045
011263 043
011264 127
011265 117
011266 122
011267 123
011270 124
011271 040
011272 103
011273 101
011274 123
011275 105
011276 040
011277 120
011300 101
011301 124
011302 124
011303 105
011304 122

011305 116
011306 040
011307 124
011310 105
011311 123
011312 124
011313 045
011314 043
011315 100

011316 045
011317 043
011320 113
011321 131
011322 102
011323 104
011324 040
011325 124
011326 105
011327 123
011330 124
011331 045
011332 043
011333 100

KMSG11 ,ASCII 'X0KY0D TESTX00'

011334 045
011335 120
011336 122
011337 105
011340 123
011341 123
011342 040
011343 101
011344 040
011345 113
011346 105
011347 131
011350 040
011351 127
011352 111
011353 124
011354 110
011355 111
011356 110
011357 040
011360 061
011361 060
011362 040
011363 123
011364 105
011365 103
011366 117
011367 116
011370 104
011371 123

KMSG21 ,ASCII 'XPRESS A KEY WITHIN 10 SECONDS,0'

011372 056
011373 100

011374 045
011375 043
011376 105
011377 103
011400 110
011401 117
011402 040
011403 124
011404 105
011405 123
011406 124

KMSG31 ,ASCII 'X#ECHO TEST'

011407 045
011410 103
011411 110
011412 101
011413 122
011414 101
011415 103
011416 124
011417 105
011420 122
011421 040
011422 113
011423 105
011424 131
011425 105
011426 104
011427 040
011430 127
011431 111
011432 114
011433 114
011434 040
011435 102
011436 105
011437 040
011440 124
011441 131
011442 120
011443 105
011444 104
011445 056

KMSG3A1 ,ASCII 'X#CHARACTER KEYED WILL BE TYPED, '

011446 045
011447 122
011450 125
011451 102
011452 117
011453 125
011454 124
011455 040

,ASCII 'XRUBOUT ENDS ROUTINE,X##'

011456 105
011457 116
011460 104
011461 123
011462 040
011463 122
011464 117
011465 125
011466 124
011467 111
011470 116
011471 105
011472 056
011473 045
011474 043
011475 100

011476 045
011477 043
011500 117
011501 103
011502 124
011503 101
011504 114
011505 040
011506 105
011507 121
011510 125
011511 111
011512 126
011513 101
011514 114
011515 105
011516 116
011517 124
011520 040
011521 124
011522 105
011523 123
011524 124
011525 100

011526 045
011527 040

011530 040
011531 040
011532 040
011533 040
011534 045
011535 100

011536 045
011537 116
011540 117

KMSG41 ,ASCII 'X#OCTAL EQUIVALENT TEST#'

KMSG51 ,ASCII 'X '

OCTEQVI ,ASCII ' X#'

KMSG61 ,ASCII 'XNO KEYBOARD REQUEST,0'

PALX11

V003

20-JUL-71

16102

PAGE 37-8

011541 040
011542 113
011543 105
011544 131
011545 102
011546 117
011547 101
011550 122
011551 104
011552 040
011553 122
011554 105
011555 121
011556 125
011557 105
011560 123
011561 124
011562 056
011563 100

011564 045
011565 106
011566 101
011567 114
011570 123
011571 105
011572 040
011573 113
011574 131
011575 102
011576 104
011577 040
011000 111
011001 110
011002 124
011003 105
011004 122
011005 122
011006 125
011007 120
011010 124
011011 100

011012 045
011013 043
011014 104
011015 111
011016 123
011017 120
011020 114
011021 101
011022 131
011023 040
011024 105
011025 130

KMSG71 ,ASCII 'XFALSE KYBD INTERRUPT0'

P7MG11 ,ASCII 'XDISPLAY EXERCISERX00'

29 77

011026 105
011027 122
011030 103
011031 111
011032 123
011033 105
011034 122
011035 045
011036 043
011037 100

011040 045
011041 043
011042 124
011043 131
011044 120
011045 105
011046 040
011047 111
011050 110
011051 040
011052 104
011053 101
011054 124
011055 101
011056 040
011057 072
011060 100

011061 125
011062 040
011063 100

011064 040
011065 040
011066 040
011067 040
011070 040

000001

P7MG21 ,ASCII 'X#TYPE IN DATA 10'

BKSUI ,ASCII 'U 0'

DECVLI ,ASCII ' ' ,

DENDI ,END

65
79

A	010714	AT31	005330	AT4E2	004766	C52	010771
A1ST	003724	AT31A	005340	AT5	004774	C59	010774
A33WP6	010700	AT31B	005362	AT5A	005012	C72	010777
A35WP6	010706	AT31E	005360	AT5B	005034	C75	011002
ACNV	003734	AT32	005366	AT5E	005032	CC	177776
ACNV4	003676	AT32A	005376	BCHECK	003250	CHAIN	104012
ACNV6	003650	AT32B	005424	BDCNV	004070	CHAINN	001672
ACNVB	003670	AT32E	005422	BDCNVA	004110	CHALT	104005
ACNVC	003716	AT33	005430	BELL	000007	CHAR	010676
ACNVM	003750	AT33A	005440	BIT0	002000	CHK33	002256
ACNVX	003732	AT33B	005464	BIT1	000002	CHK33B	002270
ADTENP	004176	AT33E	005462	BIT10	002000	CHK35	002272
ARDA	002446	AT34	005470	BIT11	004000	CHKASR	104022
ARDB	002472	AT34A	005504	BIT12	010000	CHLY	001366
AREAD	002434	AT34B	005526	BIT13	020000	CMNA	001726
AT0	004540	AT34C	005532	BIT14	040000	CMNAA	001754
AT0A	004556	AT34E	005524	BIT15	100000	CMNB	001762
AT0B	004562	AT35	005536	BIT2	000004	CMR1	001346
AT0E	004566	AT35A	005552	BIT3	000010	CMR2	001350
AT1	004572	AT35B	005574	BIT4	000020	CMR3	001352
AT1A	004610	AT35E	005604	BIT5	000040	CMRTST	011236
AT1B	004614	AT36	005612	BIT6	000100	CK33	104013
AT1E	004620	AT36A	005626	BIT7	000200	CK35	104014
AT2	004624	AT36B	005662	BIT8	000400	CKASR	002310
AT24	005040	AT36C	005664	BIT9	001000	CLEAN	002122
AT24A	005056	AT37	005674	BKSU	011661	CNT	010672
AT24B	005100	AT37A	005704	BLK2	012016	CNVCTR	004170
AT24C	005120	AT37B	005732	BLKBB	012014	CPRDY	004032
AT24E1	005074	AT37C	005742	BLKCC	012126	CPRDYA	004042
AT24E2	005116	AT37D	005756	BLOCK1	011673	CRBUF	001344
AT25	005124	AT37E1	005730	BLOCK2	012005	CRLF	011057
AT25A	005142	AT37E2	005762	BLOCKA	011671	CRTA	001554
AT25B	005164	AT3A	004674	BLOCKB	012003	CRTST	011106
AT25E	005162	AT3B	004700	BLOCKC	012119	CT0	006242
AT26	005170	AT3E	004704	BMOVA	004020	CT0A	006266
AT26A	005200	AT4	004710	BMOVE	004010	CT0B	006276
AT26B	005222	AT40	005770	BRCYR	002742	CT0C	006304
AT26C	005242	AT40A	006004	BREAD	002644	CT1	006344
AT26E1	005216	AT40B	006042	BREADA	002702	CT10	007116
AT26E2	005240	AT40C	006044	BREADB	002712	CT11	007130
AT27	005246	AT41	006054	BREADC	002732	CT12	007142
AT27A	005256	AT41A	006074	BSYNC	003310	CT13	007154
AT27B	005300	AT41B	006120	BYPHAN	000400	CT14	007166
AT27E	005276	AT41C	006132	C100	011005	CT15	007200
AT2A	004642	AT42	006142	C1112	010330	CT16	007212
AT2B	004646	AT42A	006156	C1112A	010350	CT17	007224
AT2E	004652	AT42B	006204	C1112M	010322	CT1A	006370
AT3	004656	AT42E	006202	C135	011010	CT2	006410
AT30	005304	AT4A	004726	C377	011013	CT20	007236
AT30A	005314	AT4B	004750	C41	010760	CT21	007250
AT30B	005324	AT4C	004770	C44	010763	CT22	007262
AT30E	005322	AT4E1	004744	C47	010766	CT23	007274

CT24	007306	ERROR	104003	KSTART	001232	PT1	003524
CT25	007320	ET0	007630	KTA	010366	PT1P	003532
CT26	007332	ET0A	007642	KTB	010374	RCMSK	003244
CT27	007344	ET0B	007700	LFTST	011213	RCNT	001342
CT2A	006426	ET0C	007714	LPRGSW	002000	RENIT	010546
CT2B	006446	ET0CA	007722	LSPCH	004046	RIND	003520
CT2C	006454	ET1	007734	LTA	010456	RH33A	011061
CT2D	006476	ET1A	007744	LTB	010476	RH33B	011067
CT2E	006552	ET2	010014	M	010730	RH37A	011073
CT3	006562	ET2A	010034	MACHER	000004	RMB	006404
CT3B	007356	FBALL	004366	MANUAL	100000	RMTST	011137
CT31	007370	FBF3	004322	NITRSH	004000	RNCNT	003246
CT32	007402	FBF3A	004332	NOP	000240	RNGEN	002572
CT33	007440	FBF3B	004340	NPRTSH	020000	RP1	002640
CT33A	007466	FORWD	002016	NTRCSW	010000	RP2	002642
CT34	007522	FORWDA	002050	NXTST	001240	RSTPC	002430
CT34A	007550	FORWDB	002056	OCTEQV	011530	RSTPSW	002432
CT3A	006606	FOUR	010752	ONE	010747	RSTREG	104021
CT3B	006636	FW336	004426	OPEN	000000	RSTRG	002374
CT4	006642	FW356	004466	P	010733	RYNNO	001236
CT4A	006672	G	010722	P7MG1	011612	S	010736
CT4B	006704	GETRDY	001574	P7MG2	011640	SAVREG	104020
CT5	007054	GKBCR	010232	PIND	003526	SAVRG	002334
CT6	007072	GOTST	002074	POPSP	009726	SCOPSW	040000
CT7	007104	GUTSTA	002114	POPSP2	022626	SCOPTR	001244
CTRA	001356	GRCNT	003224	PRG0	004526	SEVEN	010755
CTRB	001360	GTBIN	003534	PRG1	006210	SHALT	001472
CTRC	001362	GTBINP	003602	PRG10	010540	SHLTA	001506
CTRD	001364	GTRDYA	001606	PRG10A	010566	SPOOT	001204
CURIST	001234	GTRDYB	001612	PRG10C	010554	SPCNT	000752
D	010717	GTRDYC	001630	PRG10D	010562	SPYST	011165
DATCHK	104004	GTRDYD	001656	PRG2	007604	SPYSTC	011103
DATHLT	104017	HLTSH	100000	PRG3	010104	SR	177570
DECVAL	011664	HTA	010114	PRG4	010264	SRESEY	104011
DELAY	104400	HTB	010146	PRG5	010274	SRSET	001572
DEND	011671	HTC	010204	PRG6	010364	SRSETY	002554
DIGIT	004172	HTD	010216	PRG7	010436	SRTSH	001000
DLCNT	003162	ICTR	001242	PRGEN0	002012	STAL	003164
OLY	003120	INBIN	003476	PRG10	001246	STALA	003216
OLYA	003140	INCPRG	001550	PRGNUM	001230	STALAA	003176
OLYB	003144	INCRN	001666	PRGTAB	001290	STALB	003220
OTCHK	001412	ITA	010266	PRTY0	000000	STALL	104002
OTCHKA	001430	J	010725	PRTY1	000040	START	001510
OTHLT	001422	JTA	010276	PRTY2	000100	STBF	004304
EHALT	104010	KMSG1	011316	PRTY3	000140	STLMSK	003222
EHLT	001400	KMSG2	011334	PRTY4	000200	STLSPV	002524
EMTA	002172	KMSG3	011374	PRTY5	000240	STLSRV	002474
EMTINT	002146	KMSG3A	011407	PRTY6	000300	STPCHV	104007
EMTTAB	001272	KMSG4	011476	PRTY7	000340	STPPA	002542
ERCYR	001354	KMSG5	011526	PSW	177776	STPRA	002512
ERR	001432	KMSG6	011536	PT0	003522	STRDRV	104006
ERRA	001452	KMSG7	011564	PT0P	003530	SUBTEN	004130

SUBTNA	004134	TYPSA	003112
SUBYNB	004150	TYPSB	003114
SVRPC	002370	V	010741
SVRPSW	002372	WCPTST	011262
SYCTRA	003472	XTY	010360
SYCTRB	003474	Y	010744
SYNCA	003370		
SYNCB	003404		
SYNCC	003436		
SYNCD	003442		
SYNCE	003464		
TABP	006754		
TABPA	006766		
TABPB	006776		
TABPC	007014		
TBCNT	006750		
TBMNK	011034		
TBMNK1	011046		
TBTST	011016		
TCHAR	010674		
TCTH	004242		
TENPWR	004174		
TKB	001210		
TKLVL	001220		
TKS	001206		
TKVIR	001216		
TPB	001214		
TPBM	006724		
TPBMA	006734		
TPLJA	004266		
TPLVL	001224		
TPS	001212		
TPVIR	001222		
TRPA	002236		
TRPINT	002212		
TRPTAB	001340		
TTYTYP	001226		
TYP	002744		
TYPA	002754		
TYPC	002772		
TYPD	003020		
TYPDAT	003064		
TYPE	104000		
TYPES	104001		
TYPF	003036		
TYPG	003050		
TYPLJ	004244		
TYPLA	004216		
TYPLB	004222		
TYPLN	004210		
TYPLN3	104016		
TYPS	003066		

ERRORS DETECTED: 0

RUN-TIME: 24 SECONDS

5K CORE USED

49