

# KWV11A

DIAGNOSTIC  
MD-11-DVKWA-A

EP-DVKWA-A-DL-A

COPYRIGHT © 1976

FICHE 1 OF 1

NOV 1976

digital

MADE IN U.S.A.

[Chart 1]	[Chart 2]	[Chart 3]	[Chart 4]	[Chart 5]	[Chart 6]	[Chart 7]	[Chart 8]	[Chart 9]	[Chart 10]	[Chart 11]	[Chart 12]
[Chart 13]	[Chart 14]	[Chart 15]	[Chart 16]	[Chart 17]	[Chart 18]	[Chart 19]	[Chart 20]	[Chart 21]	[Chart 22]	[Chart 23]	[Chart 24]
[Chart 25]	[Chart 26]	[Chart 27]	[Chart 28]	[Chart 29]	[Chart 30]	[Chart 31]	[Chart 32]	[Chart 33]	[Chart 34]	[Chart 35]	[Chart 36]
[Chart 37]	[Chart 38]	[Chart 39]	[Chart 40]	[Chart 41]	[Chart 42]	[Chart 43]	[Chart 44]	[Chart 45]	[Chart 46]	[Chart 47]	[Chart 48]
[Chart 49]	[Chart 50]	[Chart 51]	[Chart 52]	[Chart 53]	[Chart 54]	[Chart 55]	[Chart 56]	[Chart 57]	[Chart 58]	[Chart 59]	[Chart 60]
[Chart 61]	[Chart 62]	[Chart 63]	[Chart 64]	[Chart 65]	[Chart 66]	[Chart 67]	[Chart 68]	[Chart 69]	[Chart 70]	[Chart 71]	[Chart 72]
[Chart 73]	[Chart 74]	[Chart 75]	[Chart 76]	[Chart 77]	[Chart 78]	[Chart 79]	[Chart 80]	[Chart 81]	[Chart 82]	[Chart 83]	[Chart 84]
[Chart 85]	[Chart 86]	[Chart 87]	[Chart 88]	[Chart 89]	[Chart 90]	[Chart 91]	[Chart 92]	[Chart 93]	[Chart 94]	[Chart 95]	[Chart 96]
[Chart 97]	[Chart 98]	[Chart 99]	[Chart 100]	[Chart 101]	[Chart 102]	[Chart 103]	[Chart 104]	[Chart 105]	[Chart 106]	[Chart 107]	[Chart 108]
[Chart 109]	[Chart 110]	[Chart 111]	[Chart 112]	[Chart 113]	[Chart 114]	[Chart 115]	[Chart 116]	[Chart 117]	[Chart 118]	[Chart 119]	[Chart 120]

[Small text block, likely a legend or reference table]

.REM x

IDENTIFICATION

PRODUCT CODE:	MAINDEC-11-DVKWA-A-0
PRODUCT NAME:	KWV11A DIAGNOSTIC
DATE CREATED:	OCTOBER 1976
MAINTAINER:	DIAGNOSTIC ENGINEERING

COPYRIGHT (C) 1976  
DIGITAL EQUIPMENT CORPORATION

THIS SOFTWARE IS FURNISHED UNDER A LICENSE FOR USE ONLY ON A SINGLE COMPUTER SYSTEM; AND MAY BE COPIED ONLY WITH THE INCLUSION OF THE ABOVE COPYRIGHT NOTICE. THIS SOFTWARE, OR ANY OTHER COPIES THEREOF, MAY NOT BE PROVIDED OR OTHERWISE MADE AVAILABLE TO ANY OTHER PERSON EXCEPT FOR USE ON SUCH SYSTEM AND TO ONE WHO AGREES TO THESE LICENSE TERMS. TITLE TO AND OWNERSHIP OF THE SOFTWARE SHALL AT ALL TIMES REMAIN IN DEC.

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION.

DEC ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT WHICH IS NOT SUPPLIED BY DEC.

10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50



100.98  
101  
102  
103  
104  
105  
106  
107  
108  
109  
110  
111  
112  
113  
114  
115  
116  
117  
118  
119  
120  
121  
122  
123  
124  
125  
126  
127  
128  
129  
130  
131  
132  
133  
134  
135  
136  
137  
138  
139  
140

1.0 ABSTRACT

-----  
THIS PROGRAM ALLOWS THE USER CHECK-OUT OR DEBUG THE KVV11A, PROGRAMMABLE REAL-TIME CLOCK. THE LOGIC TEST IS SELF CONTAINED AND NEEDS NO EXTERNAL MAINTENANCE HARDWARE OR OPEATOR INTERVENTION WITH ONLY ONE EXCEPTION: IF THE CUSTOMER HARDWARE CONNECTED TO THE KVV11 COULD INJECT SIGNALS ON ST2, ST1, OR SLAVE IN INPUTS, IT MUST BE DISCONNECTED.

EVEN THOUGH THE KVV11 IS A Q BUS OPTION, THIS PROGRAM WAS DESIGNED TO RUN ON ANY PDP-11 FAMILY COMPUTER. IF THE USER IS UNFAMILAR WITH AN LSI-11 HE SHOULD REVIEW SECTIONS 8.4 AND 8.5. A SOFTWARE SWITCH REGISTER IS INCLUDED WITH THIS PROGRAM. IT CAN BE USED ON AN LSI-11 OR BY CPU'S THAT HAVE HARDWARE SWITCH REGISTERS, SEE SECTION 8.6.

EVERY EFFORT WAS MADE TO MAKE THIS PROGRAM CONFORM TO LSI-11 PROGRAMMING RESTRICTIONS, HOWEVER; THE USER SHOULD READ SECTIONS 7.2 AND 7.3.

2.0 REQUIREMENTS

2.1 EQUIPMENT

- 1. PDP-11 FAMILY COMPUTER WITH 4K OF MEMORY (OR MORE) AND I/O FACILITIES (A SWITCH REGISTER OR TTY).  
2. KVV11 UNDER TEST.

2.2 STORAGE

THIS PROGRAM OCCUPIES AND USES ONLY THE LOWER 4K OF MEMORY.

151  
152  
153  
154  
155  
156  
157  
158  
159  
160  
161  
162  
163  
164  
165  
166  
167  
168  
169  
170  
171  
172  
173  
174  
175  
176  
177  
178  
179  
180  
181  
182  
183  
184  
185  
186  
187  
188  
189  
190  
191

3.0 LOADING PROCEDURE

3.1 METHOD

STANDARDS PROCEDURE FOR NORMAL BINARY TAPES SHOULD BE FOLLOWED.

1. ABSOLUTE LOADER MUST BE IN MEMORY.
2. PLACE BINARY TAPE IN READER.
3. \*\* LOAD ADDRESS \*7500 (5\* DETERMINE BY LOCATION OF LOADER).
4. \*\* PRESS "START" (PROGRAM WILL BE LOADED INTO MEMORY).

THE PROGRAM CAN ALSO BE LOADED BY XXDP, ACT, OR APT.

\*\* THESE STEPS VARY ON AN LSI-11 (OR EQUAL) CPU. SEE SECTIONS 8.4 AND 8.5.

3.2 NON-STANDARD ADDRESS, VECTOR, OR USE OF SOFTWARE SWITCH REGISTER

THIS PROGRAM IS SET TO TEST A KVV11 WITH A STANDARD ADDRESS AND VECTOR. IF ANY OF THESE ARE DIFFERENT ON THE KVV11 YOU ARE TESTING, CHANGE THE CORRESPONDING LOCATION IN MEMORY BEFORE STARTING THIS TEST.

LOCATION	TAG	CURRENT CONTENTS	COMMENTS
1250	\$BASE:	170420	:: BASE ADDRESS OF EQUIPMENT :: UNDER TEST
1244	\$VECT1:	000440	:: INTERRUPT VECTOR #1
176	\$SWREG:	000000	:: MANUAL SWR.
1157	\$TPFLG:	.BYTE 0	:: "TERMINAL AVAILABLE" :: FLAG (BIT<0:7>=0=YES)

NOTE

IF NO HARDWARE SWITCH REGISTER EXISTS, YOU MAY SET ANY BIT IN "\$SWREG" AS YOU WOULD HAVE SET IT IN THE SWR.

192  
193  
194  
195  
196  
197  
198  
199  
200  
201  
202  
203  
204  
205  
206  
207  
208  
209  
210  
211  
212  
213  
214  
215  
216  
217  
218  
219  
220  
221  
222  
223  
224  
225  
226  
227  
228  
229  
230  
231  
232  
233  
234  
235  
236  
237  
238  
239  
240

4.0 STARTING PROCEDURE  
-----

4.1 CONTROL SWITCH SETTING

BEFORE STARTING THE DIAGNOSTIC, SET ALL SWITCH REGISTER BITS AS DESIRED, SEE SECTION 5.1.

4.2 STARTING ADDRESSES

200 START OF LOGIC TESTS  
204 RESTART ADDRESS FOR LOGIC TEST  
210 I/O SIGNAL TEST #1  
214 I/O SIGNAL TEST #2  
220 I/O SIGNAL TEST #3  
230 PRODUCTION STARTING ADDRESS  
240 TESTOR STARTING ADDRESS

4.3 PROGRAM AND/OR OPERATOR ACTION

4.3.1 WITH A HARDWARE SWITCH REGISTER

1. LOAD PROGRAM INTO MEMORY.
2. SET SWITCH REGISTER TO STARTING ADDRESS.
3. LOAD ADDRESS.
4. SET SWITCHES TO DESIRED SETTINGS - SEE SECTION 5.1.
5. PRESS START.

4.3.2 WITHOUT A HARDWARE SWITCH REGISTER

1. LOAD PROGRAM INTO MEMORY.
2. ENTER KEYBOARD "ODT".
3. ALTER LOCATION "SWREG" TO REFLECT DESIRED OPTIONS OF A SWITCH REGISTER - SEE SECTION 5.1.
4. TYPE STARTING ADDRESS, FOLLOWED BY "G" TO START PROGRAM.

27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57  
58  
59  
60  
61  
62  
63  
64  
65  
66  
67  
68  
69  
70  
71  
72  
73  
74  
75  
76  
77  
78  
79  
80  
81  
82  
83  
84  
85  
86  
87  
88  
89  
90  
91  
92

5.0 OPERATING PROCEDURE

5.1 SWITCH REGISTER FUNCTION

SWR BIT	OCTAL	FUNCTION WHEN SET
15	100000	HALT ON ERROR
14	040000	LOOP ON TEST
13	020000	INHIBIT ERROR TYPEOUT
12	010000	ENABLE LINE FREQ. RATE TESTING
11	004000	INHIBIT ITERATIONS (SHORT PASS)
10	002000	BELL ON ERROR
09	001000	LOOP ON ERROR
08	000400	LOOP ON TEST IN SWR <7:0>

5.2 SCOPE LOOPS

5.2.1 SCOPE LOOPS WITH A HARDWARE SWITCH REGISTER

IF AN ERROR OCCURS AND THE USER WISHES TO SCOPE THE ERROR, HE (OR SHE) SHOULD SET SW15=1 TO HALT ON ERROR, THEN WHEN THE PROGRAM HALTS ON ERROR, SW15=0, SET SW14=1. TO LOOP ON CURRENT TEST, SET SW13=1 TO INHIBIT ERROR PRINTOUT, AND PRESS CONTINUE ON THE CPU'S CONSOLE.

5.2.2 SCOPE LOOPS WITHOUT A HARDWARE SWITCH REGISTER

IF AN ERROR OCCURS AND THE USER WISHES TO SCOPE THE ERROR, "\$SWREG" SHOULD BE ALTERED TO "100000" AT THE START OF THE TEST TO HALT ON ERROR, THEN WHEN THE PROGRAM HALTS ON ERROR AND THE CPU ENTERS "ODT", "\$SWREG" SHOULD BE ALTERED TO "060000" TO LOOP ON CURRENT TEST AND INHIBIT ERROR TYPEOUT, THEN TYPE "P" TO CONTINUE PROGRAM EXECUTION.

293  
294  
295  
296  
297  
298  
299  
300  
301  
302  
303  
304  
305  
306  
307  
308  
309  
310  
311  
312  
313  
314  
315  
316  
317  
318  
319  
320  
321  
322  
323  
324  
325  
326  
327  
328  
329  
330  
331  
332  
333

5.3 PROGRAM AND/OR OPERATOR ACTION

5.3.1 LOGIC TEST

THE FIRST PASS THROUGH THE PROGRAM WILL BE MADE WITH ITERATIONS INHIBITED. SUCCESSIVE PASSES WILL ENABLE ITERATIONS IF SWR11=0.

IF NOT INHIBITED BY APT, THE PROGRAM WILL LOOK FOR MORE KVV11'S TO EXERCISE, ONE PASS WILL EXERCISE ALL KVV11'S.

IF FOUR UNITS ARE DETECTED, THE FOLLOWING WILL BE TYPED:

UNIT #000001 COMPLETED TESTING UNIT #000002  
UNIT #000002 COMPLETED TESTING UNIT #000003  
UNIT #000003 COMPLETED TESTING UNIT #000004  
UNIT #000004 COMPLETED

AT END OF PASS WHEN ALL UNITS HAVE BEEN TESTED, THE FOLLOWING TYPEOUT WILL OCCUR:

"ENDPASS 12 - TOTAL ERRORS 4 - GOOD UNITS 000000000001011"

THIS INDICATES THAT THE PROGRAM HAS COMPLETED 12 OCTAL (10 DECIMAL) PASSES. DURING THAT TIME 4(OCTAL) ERRORS WERE DETECTED. ALSO WE TESTED 4 UNITS AND THE THIRD UNIT WAS THE ONLY UNIT TO FAIL.

5.4 INHIBITING AUTO-SIZE FEATURE

THIS PROGRAM WILL AUTOMATICALLY AUTO-SIZE AND TEST EACH KVV11 IT DETECTS ON THE SYSTEM. TO INHIBIT THIS FEATURE, SET BIT 15 OF LOCATION "SENV11". ALSO, TO TEST AN INDIVIDUAL KVV11 IN A GROUP, SET THIS BIT AND REFER TO SECTION 3.2 FOR CHANGING THE BASE ADDRESS OF THE KVV11 UNDER TEST.



334  
335  
336  
337  
338  
339  
340  
341  
342  
343  
344  
345  
346  
347  
348  
349  
350  
351  
352  
353  
354  
355  
356  
357  
358  
359  
360  
361  
362  
363  
364  
365  
366  
367  
368  
369  
370  
371  
372  
373  
374  
375  
376  
377  
378  
379  
380  
381  
382  
383

6.0 ERRORS  
-----

6.1 ERROR PRINTOUT

PRINTOUT VARIES WITH THE ERROR DETECTED. THE ERROR PC TYPED OUT IS THE ACTUAL LOCATION OF THE ERROR CALL.

A HALT AT LOCATION "STYPE"+10 WHEN RUNNING WITH NO TERMINAL INDICATES AN ERROR HAS OCCURRED. TO FIND OUT THE NUMBER OF THE ERROR, EXAMINE LOCATION "STSTNM". THIS IS THE ITEM NUMBER OF THE ERROR. TO FIND OUT WHAT THE ERROR TYPEOUT WOULD HAVE BEEN GOTO TO THE ERROR POINTER TABLE BEGINNING AT LOCATION "ERRTB".

6.1.1 EXAMPLE

IF WE EXAMINED LOCATION "STSTNM" AND FOUND A 5(101) WE GO TO LOCATION "ERRTB" AND LOOK THROUGH THE ERROR POINTER TABLE UNTIL WE FOUND ITEM 5. THE INFORMATION WOULD LOOK LIKE:

```
;ITEM 5
      EMS      :CLOCK SR DATA ERROR
      DHS      :ERRPC ASR WAS S/B
      DTS      :SERRPC,ASR,$BODAT,$GDOAT
      DFO      :ALL NUMBERS ARE IN OCTAL FORM
```

TO FIND OUT THE INFORMATION SPECIFIED BY DTS (SERRPC,BSR,\$BODAR,\$BODAR) FOLLOW THESE STEPS:

1. LOOK UP THE ADDRESS OF THE LABEL (I.E., SERRPC) IN THE SYMBOL TABLE WHICH FOLLOWS THE LISTING.
2. \* PUT THIS ADDRESS IN THE SWITCH REGISTER AND DEPRESS THE LOAD ADDRESS SWITCH ON THE PROCESSOR'S CONSOLE.
3. \* NOW DEPRESS THE EXAMINE SWITCH.
4. \* THE DATA DISPLAYED IN THE DATA LIGHTS IS THE INFORMATION THAT WOULD HAVE BEEN PRINTED FOR HIS LABEL IF YOU HAD A INPUT/OUTPUT TERMINAL.

\* SEE SECTION 8.4 FOR LSI-11 ODT COMMANDS.

394  
395  
396  
397  
398  
399  
400  
401  
402  
403  
404  
405  
406  
407  
408  
409  
410  
411  
412  
413  
414  
415  
416  
417  
418  
419  
420  
421  
422  
423  
424  
425  
426  
427  
428

## 6.2 NON-STANDARD ERROR HALTS

ANY HALT IN THE TRAP CATCHER AREA LOCATIONS 000000-001000, INDICATES:

1. THE KHV11 INTERRUPTED TO A WRONG VECTOR ADDRESS,  
OR
2. TIME-OUT OR ILLEGAL INSTRUCTION HARDWARE TRAP.

## 7.0 RESTRICTIONS

-----

### 7.1 EXTERNAL INPUTS

EXTERNAL INPUTS SUCH AS "SLAVE IN", "ST1" AND "ST2" MUST NOT BE CONNECTED TO ANY CUSTOMER HARDWARE THAT MIGHT GENERATE THESE SIGNAL WHILE THE DIAGNOSTIC IS RUNNING.

### 7.2 STARTING RESTRICTION

IF A FREE-RUNNING CLOCK, SUCH AS 60HZ FROM THE POWER SUPPLY, IS ATTACHED TO THE "BEVNT" BUS LINE ON BOTH REV LEVEL C/D AND E SYSTEMS, AN INTERRUPT TO LOCATION 100 WILL OCCUR WHEN USING THE "G" AND "L" COMMANDS PRIOR TO EXECUTING THE FIRST INSTRUCTION. THEREFORE THIS PROGRAM CAN NOT DISABLE THE BEVNT BUS LINE BY INHIBITING INTERRUPTS.

USER SYSTEMS REQUIRING A FREE-RUNNING CLOCK ATTACHED TO THE BEVNT BUS LINE CAN TEMPORARILY AVOID THIS SITUATION BY SETTING THE PSW(R5) TO 200, LOADING THE PC WITH THE STARTING ADDRESS INSTEAD OF USING THE "G" COMMAND, AND THEN USING THE "P" COMMAND. BEFORE USING THE "L" COMMAND, THE PSW(R5) CAN BE SET TO 200, THEREBY INHIBITING INTERRUPTS, TO AVOID RECEIVING THE EVENT INTERRUPT AFTER LOADING THE ABS LOADER.



475  
476  
477  
478  
479  
480  
481  
482  
483  
484  
485  
486  
487  
488  
489  
490  
491  
492  
493  
494  
495  
496  
497  
498  
499  
500  
501  
502  
503  
504  
505  
506  
507  
508  
509  
510  
511  
512  
513  
514  
515  
516  
517  
518  
519  
520  
521  
522  
523  
524  
525  
526  
527  
528  
529  
530

8.4 LSI-11 "ODT" COMMANDS

<u>FORMAT</u>	<u>DESCRIPTION</u>
<CR> RETURN	CLOSE OPENED LOCATION AND ACCEPT NEXT COMMAND.
<LF> LINE FEED	CLOSE CURRENT LOCATION; OPEN NEXT SEQUENTIAL LOCATION.
↑(UPARROW)	OPEN PREVIOUS LOCATION.
← (LEFT ARROW)	TAKE CONTENTS OF OPENED LOCATION, INDEXED BY CONTENTS OF PC, AND OPEN THAT LOCATION.
⌘	TAKE CONTENTS OF OPENED LOCATION AS ABSOLUTE ADDRESS AND OPEN THAT LOCATION.
R/	OPEN THE WORD AT LOCATION R.
/	REOPEN THE LAST LOCATION.
SN/ OR RN/	OPEN GENERAL REGISTER N(0-7) OR S(PS REGISTER).
R;G OR RG	GOTO LOCATION R AND START PROGRAM.
NL	EXECUTE BOOTSTRAP LOADER USING N AS DEVICE CSR. CONSOLE DEVICE IS 177560.
;P OR P	PROCEED WITH PROGRAM EXECUTION.
RUBOUT	ERASES PREVIOUS NUMERIC CHARACTER. RESPONSE IS A BACKSLASH ( ).

8.5 ENTERING LSI-11 "ODT"

THE HALT OR ODT MICROCODE STATE OF THE KDIIF (LSI-11 MODULE) CAN BE ENTERED IN FIVE DIFFERENT WAYS (OTHERS ARE A SUBSET OF THESE) FROM THE RUN STATE:

1. EXECUTION OF A LSI-11 HALT INSTRUCTION,
2. A DOUBLE BUS ERROR,
3. AS A POWER UP OPTION,
4. ASCII BREAK WITH DLV11 FRAMING ERROR ASSERTING THE B HALT LINE (ENABLED BY JUMPER OF DLV11).

MO1

MAINDEC-11-DVKWA-A  
DVKWA.P11

MACY11 27(732) 04-OCT-76 14:57 PAGE 13

531  
532

UPON ENTERING THE HALT STATE, THE KD11F RESPONDS THROUGH THE SET  
OF COMMAND LISTED IN SECTION 8.4.

533  
534  
535  
536  
537  
538  
539  
540  
541  
542  
543  
544  
545  
546  
547  
548  
549  
550  
551  
552  
553  
554  
555  
556  
557  
558  
559  
560  
561  
562  
563  
564  
565  
566  
567  
568  
569  
570  
571  
572  
573  
574  
575  
576  
577  
578  
579  
580  
581  
582  
583  
584  
585  
586  
588

8.6 USE OF PROGRAM SOFTWARE SWR

THE PROGRAM SOFTWARE SWITCH REGISTER IS ENABLED IF

1. NO HARDWARE SWR EXISTS;
2. IF YOU START WITH ALL ONES (SWR=177777) IN THE SWITCH REGISTER.

THE SOFTWARE SWITCH REGISTER MAY BE CHANGED BY TYPING  $\uparrow$ G (CONTROL AND LETTER G KEYS TYPED SIMULTANEOUSLY). WHEN  $\uparrow$ G IS TYPED, THE PROGRAM RESPONDS BY TYPING "SWR=XXXXXX" WHERE XXXXXX EQUALS THE FORMER CONTENTS OF THE SWITCH REGISTER.

IF YOU WISH TO KEEP THE CURRENT VALUE, TYPE <CR>. IF YOU WISH TO CHANGE THE VALUE, TYPE THE NEW VALUE FOLLOWED BY A <CR>.

IT IS IMPORTANT TO NOTE THAT THE DIAGNOSTIC IS NOT RUNNING AFTER THE  $\uparrow$ G UNTIL A <CR> IS TYPED.

8.7 SPECIAL I/O SIGNAL TESTS

THREE TESTS WERE INCLUDED TO ENABLE CHECKOUT OF I/O SIGNALS: ST1, ST2, AND CLOCK OVERFLOW. THESE TESTS HAVE A SPECIAL STARTING ADDRESS. SINCE END-PASSES ARE IMMEDIATE, NO "END OF PASS" MESSAGE IS REPORTED. ERRORS ARE REPORTED BY TYPING OUT THE PC WHERE THE ERROR WAS DETECTED. WHEN STARTED, THE PROGRAM REMAINS IN A LOOP GENERATING AND DETECTING THE SPECIFIED SIGNALS. HALT ON ERROR AND INHIBIT ERROR TIMEOUT OPTIONS MAY BE USED.

LOGIC TEST MUST HAVE ALREADY BEEN RUN ON THE K4V11.

8.7.1 I/O SIGNAL TEST #1 ST1 IN, ST2 OUT

SWITCH PACK S2 MUST BE SET UP AS FOLLOWS:

SWITCH STATE

-----

1	OFF
2	ON
3	OFF
4	OFF
5	ON
6	ON
7	NOT USED

THE FOLLOWING JUMPER MUST BE INSTALLED.

MAINDEC-11-DVKWA-A  
DVKWA.P11

MACY11 27(732) 04-OCT-76 14:57 PAGE 15

802

589

J1-SS (ST2 OUT) TO J1-WV (ST1 IN)

590  
591  
592  
593  
594  
595  
596  
597  
598  
599  
600  
601  
602  
603  
604  
605  
606  
607  
608  
609  
610  
611  
612  
613  
614  
615  
616  
617  
618  
619  
620  
621  
622  
623  
624  
625  
626  
627  
628  
629  
630  
631  
632  
633  
634  
635  
636  
637  
638  
639

LOAD AND START THE PROGRAM AT 210.

8.7.2 I/O SIGNAL TEST #2 CLOCK OVERFLOW TEST  
SWITCH PACK S2 MUST BE SET UP AS FOLLOWS:

SWITCH STATE

1	OFF
2	OFF
3	OFF
4	OFF
5	OFF
6	OFF
7	NOT USED

THE FOLLOWING JUMPER MUST BE INSTALLED.

J1-RR (CLOCK OVERFLOW) TO J1-TT (ST2 IN)

LOAD AND START AT LOCATION 214.

8.7.3 I/O SIGNAL TEST #3 ST1 OUT AND ST2 IN  
SWITCH PACK S2 MUST BE SET UP AS FOLLOWS:

SWITCH STATE

1	OFF
2	OFF
3	OFF
4	ON
5	ON
6	ON
7	NOT USED

THE FOLLOWING JUMPER MUST BE INSTALLED:

J1-UU (ST1 OUT) TO J1-TT (ST2 IN)

LOAD AND START AT LOCATION 220.



640  
641  
642  
643  
644  
645  
646  
647  
648  
649  
650  
651  
652  
653  
654  
655  
656  
657  
658  
659  
660  
661  
662  
663  
664  
665  
666  
667  
668  
669  
670  
671  
672  
673  
674  
675  
676  
677  
678  
679  
680  
681  
682  
683  
684  
685  
686  
687  
688  
689  
690  
691  
692  
693  
694  
695

B.8 PRODUCTION STARTING ADDRESS

A SPECIAL STARTING ADDRESS HAS BEEN PROVIDED FOR IN-HOUSE PRODUCTION TO USE TO START THE LOGIC DIAGNOSTIC AND INFORM THE TEST THAT PRODUCTION IS USING IT.

IN THE FIELD ONLY ENOUGH ADDRESSES WERE ALLOTTED FOR 4 SEQUENTIAL KWV11S. WHEN THE LOGIC TESTS ARE STARTED AT LOCATION 200, WE ONLY AUTO-SIZE UP TO 4 KWV11S.

IN HOUSE TESTING MAY WISH TO EXERCISE UP TO 16 KWV11S AT ONE TIME. THE LOGIC TESTS MAY BE STARTED AT LOCATION 230 AND THE PROGRAM WILL AUTO SIZE UP TO 16 KWV11S.

B.9 TESTOR STARTING ADDRESS

A SPECIAL STARTING ADDRESS HAS BEEN PROVIDED FOR MANUFACTURING TO USE TO START THE LOGIC DIAGNOSTIC AND INFORM THE PROGRAM THAT THE CLOCK MODULE IS CABLED TO AN IN-HOUSE TESTOR.

MANUAL INTERVENTION IS NEEDED IN THIS SEQUENCE OF TESTING. THE PROGRAM WILL TYPE OUT ALL INSTRUCTIONS. A CABLE SHOULD CONNECT J1 ON THE CLOCK MODULE TO J10 ON THE TESTOR. SWITCHES 1 AND 3 OF S2 (ON THE CLOCK MODULE) SHOULD BE ON, ALL OTHER SWITCHES ON S2 SHOULD BE OFF.

```
%  
.MLIST MC,MD,CND  
.LIST ME  
.ENABL ABS  
.ENABL AMA  
.MCALL .HEADER,.SETUP,.SETTRAP,.TRMTRP,.STRAP,.SRDOCT,.STYPBIN  
.MCALL TYPOCS,$POWER,$SCATCH,$STYPOCT,$EQUAT,$CMTAG,$SWRMI  
.MCALL $SEOP,$ERROR,$ERRTYP,$STYPDEC,$SCOPE,$SREAD,$STYPE  
.MCALL $SACT11,$SAPTHOR,$SAPTYPE  
$SWR= 167400
```

167400

```
.TITLE MAINDEC-11-DVKWA-A  
*COPYRIGHT (C) 1976  
*DIGITAL EQUIPMENT CORP.  
*MAYNARD, MASS. 01754  
*  
*PROGRAM BY EDWARD C. BADGER  
*  
*THIS PROGRAM WAS ASSEMBLED USING THE POP-11 MAINDEC SYSMAC  
*PACKAGE (MAINDEC-11-DZQAC-CO), MAR 21, 1976.
```

```

696          000001      ;*
697          ;$TN=1
698
699 000000      ;SWR:
700          .SBTTL TRAP CATCHER
701
702          000000      ;=0
703          ;*ALL UNUSED LOCATIONS FROM 4 - 776 CONTAIN A "+2,HALT"
704          ;*SEQUENCE TO CATCH ILLEGAL TRAPS AND INTERRUPTS
705          ;*LOCATION 0 CONTAINS 0 TO CATCH IMPROPERLY LOADED VECTORS
706          000174
707 000174 000000      ;=174
708 000176 000000      DISPRG: .WORD 0      ;; SOFTWARE DISPLAY REGISTER
709          000100      SWREG: .WORD 0      ;; SOFTWARE SWITCH REGISTER
710 000100 000102 000002      ;=100
711          .WORD 102,2      ;IF "B EVENT" ON Q-BUS IS CONNECTED
712          ;WE NEED WAY OF IGNORING ITS INTERRUPTS.
713
714 000200 000137 001472      ;=200
715 000204 000137 002070      JMP      @#START
716 000210 000137 013322      JMP      @#RSTART
717 000214 000137 013400      JMP      @#IOTST1
718 000220 000137 013446      JMP      @#IOTST2
719          JMP      @#IOTST3
720
721 000230 000137 001456      ;=230
722          JMP      @#WSTART      ;WESTFIELD STARTING ADDRESS
723 000240 000137 001442      ;=240
724          JMP      @#TSTSTR      ;ALL TESTER TESTS
725          ;IF STARTED HERE.
726          ;ALLOWS PRODUCTION TO EXERCISE
727          ;UP TO 16 CLOCKS.NORMAL=4.
728          .SBTTL BASIC DEFINITIONS
729
730          ;*INITIAL ADDRESS OF THE STACK POINTER *** 1100 ***
731          001100      STACK= 1100
732          .EQUIV EMT,ERROR      ;;BASIC DEFINITION OF ERROR CALL
733          .EQUIV IOT,SCOPE      ;;BASIC DEFINITION OF SCOPE CALL
734
735          ;*MISCELLANEOUS DEFINITIONS
736          000011      HT= 11      ;;CODE FOR HORIZONTAL TAB
737          000012      LF= 12      ;;CODE FOR LINE FEED
738          000015      CR= 15      ;;CODE FOR CARRIAGE RETURN
739          000200      CRLF= 200      ;;CODE FOR CARRIAGE RETURN-LINE FEED
740          177776      PS= 177776      ;;PROCESSOR STATUS WORD
741          .EQUIV PS,PSW
742          177774      STKLM= 177774      ;;STACK LIMIT REGISTER
743          177772      PIRQ= 177772      ;;PROGRAM INTERRUPT REQUEST REGISTER
744          177570      DSWR= 177570      ;;HARDWARE SWITCH REGISTER
745          177570      DDISP= 177570      ;;HARDWARE DISPLAY REGISTER
746
747          ;*GENERAL PURPOSE REGISTER DEFINITIONS
748          000000      R0= %0      ;;GENERAL REGISTER
749          000001      R1= %1      ;;GENERAL REGISTER
750          000002      R2= %2      ;;GENERAL REGISTER
751          000003      R3= %3      ;;GENERAL REGISTER

```

752	000004	R4=	%4	:: GENERAL REGISTER
753	000005	R5=	%5	:: GENERAL REGISTER
754	000006	R6=	%6	:: GENERAL REGISTER
755	000007	R7=	%7	:: GENERAL REGISTER
756		.EQUIV	R6, SP	:: STACK POINTER
757		.EQUIV	R7, PC	:: PROGRAM COUNTER
758				
759		.*PRIORITY LEVEL DEFINITIONS		
760	000000	PR0=	0	:: PRIORITY LEVEL 0
761	000040	PR1=	40	:: PRIORITY LEVEL 1
762	000100	PR2=	100	:: PRIORITY LEVEL 2
763	000140	PR3=	140	:: PRIORITY LEVEL 3
764	000200	PR4=	200	:: PRIORITY LEVEL 4
765	000240	PR5=	240	:: PRIORITY LEVEL 5
766	000300	PR6=	300	:: PRIORITY LEVEL 6
767	000340	PR7=	340	:: PRIORITY LEVEL 7
768				
769		.*"SWITCH REGISTER" SWITCH DEFINITIONS		
770	100000	SW15=	100000	
771	040000	SW14=	40000	
772	020000	SW13=	20000	
773	010000	SW12=	10000	
774	004000	SW11=	4000	
775	002000	SW10=	2000	
776	001000	SW09=	1000	
777	000400	SW08=	400	
778	000200	SW07=	200	
779	000100	SW06=	100	
780	000040	SW05=	40	
781	000020	SW04=	20	
782	000010	SW03=	10	
783	000004	SW02=	4	
784	000002	SW01=	2	
785	000001	SW00=	1	
786		.EQUIV	SW09, SW9	
787		.EQUIV	SW08, SW8	
788		.EQUIV	SW07, SW7	
789		.EQUIV	SW06, SW6	
790		.EQUIV	SW05, SW5	
791		.EQUIV	SW04, SW4	
792		.EQUIV	SW03, SW3	
793		.EQUIV	SW02, SW2	
794		.EQUIV	SW01, SW1	
795		.EQUIV	SW00, SW0	
796				
797		.*DATA BIT DEFINITIONS (BIT00 TO BIT15)		
798	100000	BIT15=	100000	
799	040000	BIT14=	40000	
800	020000	BIT13=	20000	
801	010000	BIT12=	10000	
802	004000	BIT11=	4000	
803	002000	BIT10=	2000	
804	001000	BIT09=	1000	
805	000400	BIT08=	400	
806	000200	BIT07=	200	
807	000100	BIT06=	100	

808 000040  
809 000020  
810 000010  
811 000004  
812 000002  
813 000001  
814  
815  
816  
817  
818  
819  
820  
821  
822  
823  
824  
825  
826 000004  
827 000010  
828 000014  
829 000014  
830 000014  
831 000020  
832 000024  
833 000030  
834 000034  
835 000060  
836 000064  
837 000240  
838  
839 170420  
840 000440  
841 000200  
842  
843 167400  
844 000001  
845  
846  
847  
848  
849  
850 000244  
851 000046  
852 000046 013302  
853 000052 000052  
854 000052 000000  
855 000244 000244  
856 001000 001000  
857  
858  
859  
860  
861  
862 001000  
863 000024

BIT05= 40  
BIT04= 20  
BIT03= 10  
BIT02= 4  
BIT01= 2  
BIT00= 1  
.EQUIV BIT09,BIT9  
.EQUIV BIT08,BIT8  
.EQUIV BIT07,BIT7  
.EQUIV BIT06,BIT6  
.EQUIV BIT05,BIT5  
.EQUIV BIT04,BIT4  
.EQUIV BIT03,BIT3  
.EQUIV BIT02,BIT2  
.EQUIV BIT01,BIT1  
.EQUIV BIT00,BIT0

::#BASIC "CPU" TRAP VECTOR ADDRESSES  
ERRVEC= 4 ;: TIME OUT AND OTHER ERRORS  
RESVEC= 10 ;: RESERVED AND ILLEGAL INSTRUCTIONS  
TBITVEC= 14 ;: "T" BIT  
TRTVEC= 14 ;: TRACE TRAP  
BPTVEC= 14 ;: BREAKPOINT TRAP (BPT)  
IOTVEC= 20 ;: INPUT/OUTPUT TRAP (IOT) \*\*SCOPE\*\*  
PWRVEC= 24 ;: POWER FAIL  
EMTVEC= 30 ;: EMULATOR TRAP (EMT) \*\*ERROR\*\*  
TRAPVEC= 34 ;: "TRAP" TRAP  
TKVEC= 60 ;: TTY KEYBOARD VECTOR  
TPVEC= 64 ;: TTY PRINTER VECTOR  
PIRQVEC= 240 ;: PROGRAM INTERRUPT REQUEST VECTOR

ABASE= 170420  
AVECT1= 440  
APRIOR= 200

SSWR= 167400  
\$TN= 1

.SBTTL ACT11 HOOKS

::\*\*\*\*\*

;HOOKS REQUIRED BY ACT11

\$SVPC= ;SAVE PC  
.=46 ;:1)SET LOC.46 TO ADDRESS OF SENDAD IN .SEOP  
SENDAD  
.=52 ;:2)SET LOC.52 TO ZERO  
.WORD 0 ;: RESTORE PC  
.=1000

.SBTTL APT PARAMETER BLOCK

::\*\*\*\*\*

;SET LOCATIONS 24 AND 44 AS REQUIRED FOR APT

::\*\*\*\*\*

.\$X= ;:SAVE CURRENT LOCATION  
.=24 ;:SET POWER FAIL TO POINT TO START OF PROGRAM

864	000024	000200
865		000044
866	000044	001000
867		001000
868		
869		
870		
871		
872	001000	
873	001000	000000
874	001002	001174
875	001004	000002
876	001006	000170
877	001010	000170
878	001012	000031

```

200      ;; FOR APT START UP
.=44     ;; POINT TO APT INDIRECT ADDRESS PNTR.
$APTHDR  ;; POINT TO APT HEADER BLOCK
.=.SX    ;; RESET LOCATION COUNTER
;*****
; SETUP APT PARAMETER BLOCK AS DEFINED IN THE APT-POP11 DIAGNOSTIC
; INTERFACE SPEC.

$APTHD:
$HIBTS: .WORD 0      ;; TWO HIGH BITS OF 18 BIT MAILBOX ADDR.
$MBAOR: .WORD $MAIL  ;; ADDRESS OF APT MAILBOX (BITS 0-15)
$TSTM:  .WORD 2      ;; RUN TIM OF LONGEST TEST
$PASTM: .WORD 120.   ;; RUN TIME IN SECS. OF 1ST PASS ON 1 UNIT (QUICK VERIFY)
$UNITM: .WORD 120.   ;; ADDITIONAL RUN TIME (SECS) OF A PASS FOR EACH ADDITIONAL UNIT
          .WORD $ETEND-$MAIL/2 ;; LENGTH MAILBOX-ETABLE(WORDS)

```

879  
880  
881  
882  
883  
884  
885 001100  
886 001100  
887 001100 000000  
888 001102 000  
889 001103 000  
890 001104 000000  
891 001106 000000  
892 001110 000000  
893 001112 000000  
894 001114 000  
895 001115 001  
896 001116 000000  
897 001120 000000  
898 001122 000000  
899 001124 000000  
900 001126 000000  
901 001130 000000  
902 001132 000000  
903 001134 000  
904 001135 000  
905 001136 000000  
906 001140 177570  
907 001142 177570  
908 001144 177560  
909 001146 177562  
910 001150 177564  
911 001152 177566  
912 001154 000  
913 001155 002  
914 001156 012  
915 001157 000  
916 001160 000000  
917 001162 000000  
918 001164 177607 000377  
919 001170 077  
920 001171 015  
921 001172 000012  
922  
923  
924  
925  
926  
927 001174  
928 001174 000000  
929 001176 000000  
930 001200 000000  
931 001202 000000  
932 001204 000000  
933 001206 000000  
934 001210 000000

.SBTTL COMMON TAGS

\*\*\*\*\*  
: THIS TABLE CONTAINS VARIOUS COMMON STORAGE LOCATIONS  
: USED IN THE PROGRAM.

      .=1100  
\$CHTAG:          ;; START OF COMMON TAGS  
      .WORD      0  
\$TSTNM: .BYTE   00      ;; CONTAINS THE TEST NUMBER  
\$ERFLG: .BYTE   00      ;; CONTAINS ERROR FLAG  
\$ICNT:  .WORD   00      ;; CONTAINS SUBTEST ITERATION COUNT  
\$LPADR: .WORD   00      ;; CONTAINS SCOPE LOOP ADDRESS  
\$LPERR: .WORD   00      ;; CONTAINS SCOPE RETURN FOR ERRORS  
\$ERTTL: .WORD   00      ;; CONTAINS TOTAL ERRORS DETECTED  
\$ITEMB: .BYTE   0      ;; CONTAINS ITEM CONTROL BYTE  
\$ERMAX: .BYTE   1      ;; CONTAINS MAX. ERRORS PER TEST  
\$ERRPC: .WORD   00      ;; CONTAINS PC OF LAST ERROR INSTRUCTION  
\$GDADR: .WORD   00      ;; CONTAINS ADDRESS OF 'GOOD' DATA  
\$BDADR: .WORD   00      ;; CONTAINS ADDRESS OF 'BAD' DATA  
\$GDADR: .WORD   00      ;; CONTAINS 'GOOD' DATA  
\$BDADR: .WORD   00      ;; CONTAINS 'BAD' DATA  
      .WORD   00      ;; RESERVED--NOT TO BE USED  
\$AUTOB: .BYTE   0      ;; AUTOMATIC MODE INDICATOR  
\$INTAG: .BYTE   0      ;; INTERRUPT MODE INDICATOR  
      .WORD   0  
\$SWR:  .WORD   DSWR      ;; ADDRESS OF SWITCH REGISTER  
\$DISPLAY: .WORD   DDISP   ;; ADDRESS OF DISPLAY REGISTER  
\$TKS:  177560      ;; TTY KBD STATUS  
\$TKB:  177562      ;; TTY KBD BUFFER  
\$TPS:  177564      ;; TTY PRINTER STATUS REG. ADDRESS  
\$TPB:  177566      ;; TTY PRINTER BUFFER REG. ADDRESS  
\$NULL: .BYTE   0      ;; CONTAINS NULL CHARACTER FOR FILLS  
\$FILLS: .BYTE   2      ;; CONTAINS # OF FILLER CHARACTERS REQUIRED  
\$FILLC: .BYTE   12      ;; INSERT FILL CHARS. AFTER A "LINE FEED"  
\$TPFLG: .BYTE   0      ;; "TERMINAL AVAILABLE" FLAG (BIT<07>=0=YES)  
\$TIMES: 0          ;; MAX. NUMBER OF ITERATIONS  
\$ESCAPE: 0          ;; ESCAPE ON ERROR ADDRESS  
\$BELL: .ASCIZ  <207><377><377>  ;; CODE FOR BELL  
\$QUES: .ASCII  '?'      ;; QUESTION MARK  
\$CRLF: .ASCII  <15>      ;; CARRIAGE RETURN  
\$LF:   .ASCIZ  <12>      ;; LINE FEED

\*\*\*\*\*  
.SBTTL APT MAILBOX-ETABLE

\*\*\*\*\*  
: EVEN  
\$MAIL:          ;; APT MAILBOX  
\$MSGTY: .WORD   AMSGTY  ;; MESSAGE TYPE CODE  
\$FATAL: .WORD   AFATAL  ;; FATAL ERROR NUMBER  
\$TESTN: .WORD   ATESTN  ;; TEST NUMBER  
\$PASS:  .WORD   APASS   ;; PASS COUNT  
\$DEVCT: .WORD   ADEVCT  ;; DEVICE COUNT  
\$UNIT:  .WORD   AUNIT   ;; I/O UNIT NUMBER  
\$MSGAD: .WORD   AMSGAD  ;; MESSAGE ADDRESS

935	001212	000000	\$MSGLG: .WORD	RMSGLG	:: MESSAGE LENGTH
936	001214		\$ETABLE:		:: APT ENVIRONMENT TABLE
937	001214	000	\$ENV: .BYTE	AENV	:: ENVIRONMENT BYTE
938	001215	000	\$ENVM: .BYTE	AENVM	:: ENVIRONMENT MODE BITS
939	001216	000000	\$SWREG: .WORD	ASWREG	:: APT SWITCH REGISTER
940	001220	000000	\$USWR: .WORD	AUSWR	:: USER SWITCHES
941	001222	000000	\$CPUOP: .WORD	ACPUOP	:: CPU TYPE, OPTIONS
942			*		BITS 15-11=CPU TYPE
943			*		11/04=01, 11/05=02, 11/20=03, 11/40=04, 11/45=05
944			*		11/70=06, PDQ=07, Q=10
945			*		BIT 10=REAL TIME CLOCK
946			*		BIT 9=FLOATING POINT PROCESSOR
947			*		BIT 8=MEMORY MANAGEMENT
948	001224	000	\$MAMS1: .BYTE	AMAMS1	:: HIGH ADDRESS, M.S. BYTE
949	001225	000	\$MTYP1: .BYTE	AMTYP1	:: MEM. TYPE, BLK#1
950			*		MEM. TYPE BYTE -- (HIGH BYTE)
951			*		900 NSEC CORE=001
952			*		300 NSEC BIPOLAR=002
953			*		500 NSEC MOS=003
954	001226	000000	\$MADR1: .WORD	AMADR1	:: HIGH ADDRESS, BLK#1
955			*		MEM. LAST ADDR.=3 BYTES, THIS WORD AND LOW OF "TYPE" ABOVE
956	001230	000	\$MAMS2: .BYTE	AMAMS2	:: HIGH ADDRESS, M.S. BYTE
957	001231	000	\$MTYP2: .BYTE	AMTYP2	:: MEM. TYPE, BLK#2
958	001232	000000	\$MADR2: .WORD	AMADR2	:: MEM. LAST ADDRESS, BLK#2
959	001234	000	\$MAMS3: .BYTE	AMAMS3	:: HIGH ADDRESS, M.S. BYTE
960	001235	000	\$MTYP3: .BYTE	AMTYP3	:: MEM. TYPE, BLK#3
961	001236	000000	\$MADR3: .WORD	AMADR3	:: MEM. LAST ADDRESS, BLK#3
962	001240	000	\$MAMS4: .BYTE	AMAMS4	:: HIGH ADDRESS, M.S. BYTE
963	001241	000	\$MTYP4: .BYTE	AMTYP4	:: MEM. TYPE, BLK#4
964	001242	000000	\$MADR4: .WORD	AMADR4	:: MEM. LAST ADDRESS, BLK#4
965	001244	000440	\$VECT1: .WORD	AVECT1	:: INTERRUPT VECTOR#1, BUS PRIORITY#1
966	001246	000000	\$VECT2: .WORD	AVECT2	:: INTERRUPT VECTOR#2, BUS PRIORITY#2
967	001250	170420	\$BASE: .WORD	ABASE	:: BASE ADDRESS OF EQUIPMENT UNDER TEST
968	001252	000000	\$DEVN: .WORD	ADEVN	:: DEVICE MAP
969	001254	000000	\$CDW1: .WORD	ACDW1	:: CONTROLLER DESCRIPTION WORD#1
970	001256		\$ETEND:		
971			.MEXIT		

.SB\*TL ERROR POINTER TABLE

;\*THIS TABLE CONTAINS THE INFORMATION FOR EACH ERROR THAT CAN OCCUR.  
;\*THE INFORMATION IS OBTAINED BY USING THE INDEX NUMBER FOUND IN  
;\*LOCATION SITEMB. THIS NUMBER INDICATES WHICH ITEM IN THE TABLE IS PERTINENT.  
;\*NOTE1: IF SITEMB IS 0 THE ONLY PERTINENT DATA IS (SERRPC).  
;\*NOTE2: EACH ITEM IN THE TABLE CONTAINS 4 POINTERS EXPLAINED AS FOLLOWS:

;\* EM ::POINTS TO THE ERROR MESSAGE  
;\* DH ::POINTS TO THE DATA HEADER  
;\* DT ::POINTS TO THE DATA  
;\* DF ::POINTS TO THE DATA FORMAT

SERRTB:

;ITEM 1

972  
973  
974  
975  
976  
977  
978  
979  
980  
981  
982  
983  
984  
985  
986 001256  
987  
988  
989  
990  
991 001256 016364 EM1 ;CLOCK SR FUNCTION ERROR  
992 001260 016716 DH1 ;ERRPC ASR WAS S/B  
993 001262 017114 DT1 ;SERRPC, ASR, SBDDAT, SGDDAT  
994 001264 017202 DF0 ;ALL NUMBERS ARE IN OCTAL FORM  
995  
996  
997

;ITEM 2

998  
999 001266 016416 EM2 ;CLOCK SR DATA ERROR  
1000 001270 016716 DH1 ;ERRPC ASR WAS S/B  
1001 001272 017114 DT1 ;SERRPC, ASR, SBDDAT, SGDDAT  
1002 001274 017202 DF0 ;ALL NUMBERS ARE IN OCTAL FORM  
1003  
1004

;ITEM 3

1005  
1006  
1007 001276 016444 EM3 ;CLOCK BR DATA ERROR  
1008 001300 016742 DH3 ;ERRPC ABR WAS  
1009 001302 017126 DT3 ;SERRPC, ABR, SBDDAT, SGDDAT  
1010 001304 017202 DF0 ;ALL NUMBERS ARE IN OCTAL FORM  
1011  
1012

;ITEM 4

1013  
1014  
1015 001306 000000 0 ;RESERVED FOR FUTURE ERROR.  
1016 001310 000000 0 ;RESERVED.  
1017 001312 000000 0  
1018 001314 017202 DF0 ;ALL NUMBERS ARE IN OCTAL FORM  
1019  
1020

;ITEM 5

1021  
1022  
1023 001316 016472 EM5 ;CLOCK COUNT REG ERROR  
1024 001320 016766 DH4 ;ERRPC ACR WAS S/B  
1025 001322 017114 DT1 ;SERRPC, ACR, SBDDAT, SGDDAT  
1026 001324 017202 DF0 ;ALL NUMBERS ARE IN OCTAL FORM  
1027



1028					
1029			;ITEM	6	
1030					
1031	001326	016542		EM12	;CLOCK COUNT FUNCTION ERROR
1032	001330	017012		DH12	;ERRPC ASR
1033	001332	017140		DT12	;ERRPC ASR
1034	001334	017202		DF0	;ALL NUMBERS ARE IN OCTAL FORM
1035					
1036					
1037			;ITEM	7	
1038					
1039	001336	016577		EM16	;CLOCK INTERRUPT ERROR
1040	001340	017012		DH12	;ERRPC ASR
1041	001342	017140		DT12	;ERRPC ASR
1042	001344	017202		DF0	;ALL NUMBERS ARE IN OCTAL FORM
1043					
1044					
1045			;ITEM	10	
1046					
1047	001346	016630		EM20	;CLOCK REPEATABILITY ERROR
1048	001350	017027		DH20	;ERROR ASR 2ND CNT 1ST CNT 3RD CNT
1049	001352	017146		DT20	;ERRPC ASR \$BDDAT \$GDDAT \$TMPO
1050	001354	017202		DF0	;ALL NUMBERS ARE IN OCTAL FORM
1051					
1052					
1053			;ITEM	11	
1054					
1055	001356	016515		EM11	;CLOCK COUNT ERROR
1056	001360	016766		DH4	;ERRPC ASR WAS S/B
1057	001362	017162		DT22	;ERRPC ASR \$BDDAT \$TMPO
1058	001364	017202		DF0	;ALL NUMBERS ARE IN OCTAL FORM
1059					
1060					
1061			;ITEM	12	
1062					
1063	001366	016665		EM26	;CLOCK ADDRESSING ERROR
1064	001370	017070		DH26	;ERRPC CLOCK ADDR.
1065	001372	017174		DT26	;ERRPC \$TMPO
1066	001374	017202		DF0	;ALL NUMBERS ARE IN OCTAL FORM
1067					
1068					
1069	001376	170420	ASR:	.WORD	ABASE
1070	001400	170422	ASR:	.WORD	ABASE+2
1071	001402	000440	VECT1:	.WORD	AVECT1
1072	001404	000442	VECTP:	.WORD	AVECT1+2
1073	001406	000444	VECT2:	.WORD	AVECT1+4
1074	001410	000446	VECT2P:	.WORD	AVECT1+6
1075	001412	000200	PRIOR:	.WORD	APRIOR
1076	001414	167774	DR:	.WORD	167774
1077	001416	167772	DR2:	.WORD	167772
1078	001420	000000	\$TMPO:	.WORD	0
1079	001422	000000	\$TMP1:	.WORD	0
1080	001424	000000	\$TMP3:	.WORD	0
1081	001426	000000	ROTATE:	.WORD	0
1082	001430	000000	UTEST:	.WORD	0
1083	001432	000000	ERCNT:	.WORD	0

; VECTOR ADDR. OF ST2 INTR.

; TEMP STORAGE.  
; TMP STORAGE.

; POINT TO DEVICE UNDER TEST.  
; KEEPS TRACK OF GOOD UNITS.  
; COUNTS ERRORS.

# M02

```
1084 001434 000000 MDEVCT: .WORD - ;COUNTS DEVICES TESTED.
1085 001436 000000 TSTCNT: .WORD 0 ;MAX DEVICES TO BE TESTED.
1086 001440 000000 EXS: .WORD 0 ;=0, NORMAL: =1 SPECIAL TESTOR START, BY L+S 2 2
1088
1089 001442 005237 001440 TSTSTR: INC EXS ;SET FOR TESTOR.
1090 001446 012737 000020 001436 MOV #16.,TSTCNT ;ALLOW 16 UNITS
1091 001454 000413 BR 1$
1092 001456 001456 WSTART=.
1093 001456 012737 000020 001436 MOV #16.,TSTCNT ;TEST UP TO 16 UNITS.
1094 001464 005037 001440 CLR EXS
1095 001470 000405 BR 1$
1096 001472 001472 START=.
1097 001472 012737 000004 001436 MOV #4,TSTCNT ;TEST UP TO FOUR UNITS.
1098 001500 005037 001440 CLR EXS
1099 001504
1100 .SBTTL INITIALIZE THE COMMON TAGS
1101 ;;CLEAR THE COMMON TAGS (SCMTAG) AREA
1102 001504 012706 001100 MOV #SCMTAG,R6 ;:FIRST LOCATION TO BE CLEARED
1103 001510 005026 CLR (R6)+ ;:CLEAR MEMORY LOCATION
1104 001512 022706 001140 CMP #SWR,R6 ;:DONE?
1105 001516 001374 BNE -6 ;:LOC? BACK IF NO
1106 001520 012706 001100 MOV #STACK,SP ;:SETUP THE STACK POINTER
1107 ;;INITIALIZE A FEW VECTORS
1108 001524 012737 014354 000020 MOV #SCOPE,#IOTVEC ;:IOT VECTOR FOR SCOPE ROUTINE
1109 001532 012737 000340 000022 MOV #340,#IOTVEC+2 ;:LEVEL 7
1110 001540 012737 014012 000030 MOV #ERROR,#EMTVEC ;:EMT VECTOR FOR ERROR ROUTINE
1111 001546 012737 000340 000032 MOV #340,#EMTVEC+2 ;:LEVEL 7
1112 001554 012737 016320 000034 MOV #TRAP,#TRAPVEC ;:TRAP VECTOR FOR TRAP CALLS
1113 001562 012737 000340 000036 MOV #340,#TRAPVEC+2 ;:LEVEL 7
1114 001570 012737 016142 000024 MOV #SPWRDN,#PWRVEC ;:POWER FAILURE VECTOR
1115 001576 012737 000340 000026 MOV #340,#PWRVEC+2 ;:LEVEL 7
1116 001604 005037 001160 CLR $TIMES ;:INITIALIZE NUMBER OF ITERATIONS
1117 001610 005037 001162 CLR $ESCAPE ;:CLEAR THE ESCAPE ON ERROR ADDRESS
1118 001614 012737 000001 001115 MOVB #1,$ERMAX ;:ALLOW ONE ERROR PER TEST
1119 001622 012737 001622 001106 MOV #,$LPADR ;:INITIALIZE THE LOOP ADDRESS FOR SCOPE
1120 001630 012737 001630 001110 MOV #,$LPERR ;:SETUP THE ERROR LOOP ADDRESS
1121 ;;SIZE FOR A HARDWARE SWITCH REGISTER. IF NOT FOUND OR IT IS
1122 ;;EQUAL TO A "-1", SETUP FOR A SOFTWARE SWITCH REGISTER.
1123 001636 013746 000004 MOV #ERRVEC,-(SP) ;:SAVE ERROR VECTOR
1124 001642 012737 001676 000004 MOV #64,$ERRVEC ;:SET UP ERROR VECTOR
1125 001650 012737 177570 001140 MOV #OSWR,SWR ;:SETUP FOR A HARDWARE SWICH REGISTER
1126 001656 012737 177570 001142 MOV #DISP,DISPLAY ;:AND A HARDWARE DISPLAY REGISTER
1127 001664 022777 177777 177246 CMP #-1,$SWR ;:TRY TO REFERENCE HARDWARE SWR
1128 001672 001012 BNE 66$ ;:BRANCH IF NO TIMEOUT TRAP OCCURRED
1129 ;:AND THE HARDWARE SWR IS NOT = -1
1130 001674 000403 BR 65$ ;:BRANCH IF NO TIMEOUT
1131 001676 012716 001704 64$: MOV #65$,(SP) ;:SET UP FOR TRAP RETURN
1132 001702 000002 RTI
1133 001704 012737 000176 001140 65$: MOV #SWREG,SWR ;:POINT TO SOFTWARE SWR
1134 001712 012737 000174 001142 MOV #DISPREG,DISPLAY
1135 001720 012637 000004 66$: MOV (SP)+,#ERRVEC ;:RESTORE ERROR VECTOR
1136
1137 001724 005037 001202 CLR $PASS ;:CLEAR PASS COUNT
1138 001730 012737 000200 001215 BITB #APTSIZE,$ENVM ;:TEST USER SIZE UNDER APT
1139 001736 001403 BEQ 67$ ;:YES,USE NON-APT SWITCH
```

```

1140 001740 012737 001216 001140      MOV      #SSWREG,SWR      ;;NO,USE APT SWITCH REGISTER
1141 001746                                67$:
1142
1143
1144 001746 012746 000340      MOV      #340,-(SP)      ;SET CPU PRIORITY ON RETURN.
1145 001752 012746 001760      MOV      #68$,-(SP)      ;SHOW RETURN ADDRESS.
1146 001756 000002      RTI                          ;CAUSE A RETURN(PUTS STATUS IN STATUS REG.).
1147 001760                                68$:
1148
1149 001760 013737 001244 001402      MOV      $VECT1,VECT1    ;NOW FIX VECTOR ADDR.
1150 001766 013737 001250 001376      MOV      $BASE,ASR      ;FIX ADDRESS OF CSR.
1151
1152      .SBTTL  TYPE PROGRAM NAME
1153      ;;TYPE THE NAME OF THE PROGRAM IF FIRST PASS
1154 001774 005227 177777      INC      #-1              ;FIRST TIME?
1155 002000 001033      BNE      69$              ;BRANCH IF NO
1156 002002 104400 002050      TYPE     70$              ;TYPE ASCIZ STRING
1157      .SBTTL  GET VALU FOR SOFTWARE SWITCH REGISTER
1158 002006 005737 000042      TST     #42              ;ARE WE RUNNING UNDER XXDP/ACT?
1159 002012 001012      BNE      71$              ;BRANCH IF YES
1160 002014 123727 001214 000001      CMPEB   $ENV,#1          ;ARE WE RUNNING UNDER APT?
1161 002022 001406      BEQ     71$              ;BRANCH IF YES
1162 002024 023727 001140 000176      CMP     SWR,#SWREG        ;SOFTWARE SWITCH REG SELECTED?
1163 002032 001005      BNE      72$              ;BRANCH IF NO
1164 002034 104405      GETSWR                    ;GET SOFT-SWR SETTINGS
1165 002036 000403      BR      72$
1166 002040 112737 000001 001134 71$:  MOV     #1,$AUTOB        ;;SET AUTO-MODE INDICATOR
1167 002046                                72$:
1168 002046 000410      BR      69$              ;GET OVER THE ASCIZ
1169      ;;70$: .ASCIZ <CRLF>#MD11-DVKWA-A<CRLF>
1170 002070      69$:
1171 002070      RSTART:
1172 002070 005737 001440      TST     EXS              ;TESTOR MODE ENABLED??
1173 002074 001441      BEQ     1$              ;NO DON'T TYPE NEXT MESSAGE.
1174 002076 104400 002104      TYPE     65$              ;TYPE ASCIZ STRING
1175 002102 000436      BR      64$              ;GET OVER THE ASCIZ
1176      ;;65$: .ASCIZ <15><12>#TESTOR MODE ENABLED--SEE DOCUMENTATION FOR INSTRUCTIONS.#
1177 002200      64$:
1178 002200      1$:
1179 002200 104400 002206      TYPE     67$              ;TYPE ASCIZ STRING
1180 002204 000411      BR      66$              ;GET OVER THE ASCIZ
1181      ;;67$: .ASCIZ <15><12>#TEST RUNNING...#
1182 002230      66$:
1183 002230 005037 001434      CLR     MDEVCT           ;TESTING FIRST UNIT.
1184 002234 005037 001432      CLR     ERcnt           ;NO ERRORS.
1185 002240 005037 001202      CLR     $PASS           ;NO PASSES.
1186 002244 012737 000001 001426      MOV     #1,ROTATE        ;POINT TO FIRST UNIT.
1187 002252 013737 001426 001430      MOV     ROTATE,UTEST
1188 002260      LOOP:
1189
1190 002260 042737 170000 001402      BIC     #170000,VECT1    ;CLEAR OUT PRIORITY BITS.
1191 002266 013737 001402 001404      MOV     VECT1,VECTP      ;NOW FIX VECTOR +2 ADDR.
1192 002274 062737 000002 001404      ADD     #2,VECTP
1193 002302 013737 001402 001406      MOV     VECT1,VECT2      ;LETS FIX ST2 VECTOR ADDR.
1194 002310 062737 000004 001406      ADD     #4,VECT2         ;ITS 4 GREATER THEN THE 1ST.
1195 002316 013737 001406 001410      MOV     VECT2,VECT2P     ;VECTOR +2 ADDR.
  
```





D03

MAINDEC-11-DVKWA-A  
DVKWA.P11 T2

MACY11 27(732) 04-OCT-76 14:57 PAGE 30  
\*TEST THE ADDRESSABILITY OF CLOCK BUFFER REG.

1280  
1281  
1282  
1283

E03

MAINDEC-11-DVKWA-A  
DVKWA.P11 T2

MACY11 27(732) 04-OCT-76 14:57 PAGE 31  
\*TEST THE ADDRESSABILITY OF CLOCK BUFFER REG.

1294  
1295  
1296  
1297  
1298  
1299  
1300  
1301  
1302  
1305  
1306  
1307  
1310  
1311  
1312  
1313  
1314  
1315  
1316  
1317  
1320  
1321  
1322  
1323  
1326  
1327

	002502	00C004			
	002504	012737	000100	001160	
	002512	005077	176660		
	002516	052777	040000	176652	
	002524	012737	040000	001124	
	002532	017737	176640	001126	
	002540	023737	001124	001126	
	002546	001402			
	002550	104002			
	002552	000412			
	002554	042777	040000	176614	
	002562	005037	001124		
	002566	017737	176604	001126	
	002574	001401			
	002576	104002			
	002600				

```

:*****i/0*****
:*TEST 3           *TEST THAT CLOCK A STATUS REGISTER BIT 14 CAN BE SET AND CLEARED
:*
:*CLOCK STATUS REGISTER BIT EXERCISE. ON FAILURE-SUSPECT INDIVIDUAL
:*F/FS OR GATES
:*
:*****
:ST3: SCOPE
      MOV      #100,$TIMES       ;; DO 100 ITERATIONS
      CLR      2ASR              ;/CLEAR THE STATUS REGISTER
      BIS      #BIT14,2ASR       ;/SET BIT 14.
      MOV      #BIT14,$GDOAT     ;/SET FOR ERROR TYPEOUT S/B.
      MOV      2ASR,$SDDAT       ;/READ THE STATUS REGISTER.
      CMP      $GDOAT,$SDDAT     ;/DID BIT 14 AND ONLY BIT 14 SET?
      BEQ      1$                ;/IF SO-LETS TRY CLEARING IT.

;; ***** ERROR <<< *****
      ERROR   2                   ;/ERROR CLOCK AS STATUS REGISTER
                                   ;/BIT 14 FAILED TO BIT SET.

;; ***** ERROR <<< *****
      BR      2$                   ;/BR TO END SUBTEST.
1$:   BIC      #BIT14,2ASR        ;/TRY CLEARING BIT 14.
      CLR      $GDOAT             ;/CLEAR S/S FOR TYPEOUT IF ANY.
      MOV      2ASR,$SDDAT       ;/NOW READ IT BACK.
      BEQ      2$                   ;/IF ZERO - NO ERROR!

;; ***** ERROR <<< *****
      ERROR   2                   ;/ERROR - CLOCK A STATUS REGISTER.
                                   ;/BIT 14 FAILED TO CLEAR.

;; ***** ERROR <<< *****
2$:

```

F03

MAINDEC-11-DVKWA-A  
DVKWA.P11 T3

MACY11 27(732) 04-OCT-76 14:57 PAGE 32  
\*TEST THAT CLOCK A STATUS REGISTER BIT 14 CAN BE SET AND CLEARED

1328





H03

MAINDEC-11-DVQWA-A  
DVQWA.P11 T4

MAY11 27(732) 04-OCT-76 14:57 PAGE 34  
\*TEST THAT CLOCK A STATUS REGISTER BIT 13 CAN BE SET AND CLEARED

1373

MAINDEC-11-DVKWA-A  
DVKWA.P11 T4

MACY11 27(732) 04-OCT-76 14:57 PAGE 35  
\*TEST THAT CLOCK A STATUS REGISTER BIT 13 CAN BE SET AND CLEARED

1374  
1375  
1376  
1377  
1378  
1379  
1380  
1381  
1382  
1383 002676 000004  
1384 002700 012737 000100 001160  
1385  
1386 002706 005077 176464  
1387 002712 052777 004000 176456  
1388 002720 012737 004000 001124  
1389 002726 017737 176444 001126  
1390 002734 023737 001124 001126  
1391 002742 001402  
1392  
  
1395 002744 104002  
1396  
1397  
  
1400 002746 000412  
1401  
1402 002750 042777 004000 176410  
1403 002756 005037 001124  
1404 002762 017737 176410 001126  
1405 002770 001401  
1406  
1407  
  
1410 002772 104002  
1411  
1412  
1413  
  
1416 002774  
1417

```
                ;/0  
*****  
*TEST 5          *TEST THAT CLOCK A STATUS REGISTER BIT 11 CAN BE SET AND CLEARED  
*  
*CLOCK STATUS REGISTER BIT EXERCISE. ON FAILURE-SUSPECT INDIVIDUAL  
*F/FS OR GATES  
*  
*****  
|ST5:  SCOPE  
      MOV      #100,STIMES      ;;DO 100 ITERATIONS  
  
      CLR      @ASR              ;/CLEAR THE STATUS REGISTER.  
      BIS      @BIT11,@ASR      ;/SET BIT 11.  
      MOV      @BIT11,$GDDAT    ;/SET FOR ERROR TYPEOUT S/B.  
      MOV      @ASR,@SDDAT     ;/READ THE STATUS REGISTER.  
      CMP      $GDDAT,@SDDAT   ;/DID BIT 11 AND ONLY BIT 11 SET?  
      BEQ      IS              ;/IF SO-LETS TRY CLEARING IT.  
  
;;SSSSSSSSSSSSSSSSSSSSSSSSSSS)) ERROR <<<SSSSSSSSSSSSSSSSSSSSSSSSSSSSSSSSSSSSSSS  
      ERROR 2                      ;/ERROR CLOCK AS STATUS REGISTER  
                                   ;/BIT 11 FAILED TO BIT SET.  
  
;;SSSSSSSSSSSSSSSSSSSSSSSSSSS)) ERROR <<<SSSSSSSSSSSSSSSSSSSSSSSSSSSSSSSSSSSSSSS  
      BR      2S                      ;/BR TO END SUBTEST.  
IS:  BIC      @BIT11,@ASR      ;/TRY CLEARING BIT 11.  
      CLR      @SDDAT          ;/CLEAR S/B FOR TYPEOUT IF ANY.  
      MOV      @ASR,@SDDAT     ;/NOW READ IT BACK.  
      BEQ      2S              ;/IF ZERO - NO ERROR!  
  
;;SSSSSSSSSSSSSSSSSSSSSSSSSSS)) ERROR <<<SSSSSSSSSSSSSSSSSSSSSSSSSSSSSSSSSSSSSSS  
      ERROR 2                      ;/ERROR - CLOCK A STATUS REGISTER.  
                                   ;/BIT 11 FAILED TO CLEAR.  
  
;;SSSSSSSSSSSSSSSSSSSSSSSSSSS)) ERROR <<<SSSSSSSSSSSSSSSSSSSSSSSSSSSSSSSSSSSSSSS  
2S:
```

J03

MAINDEC-11-DVKWA-A  
DVKWA.P11 TS

MACY11 27(732) 04-OCT-76 14:57 PAGE 36  
\*TEST THAT CLOCK A STATUS REGISTER BIT 11 CAN BE SET AND CLEARED

1418



L03

MAINDEC-11-DVKWA-A  
D-KWA.P11 T6

MACY11 27(732) 04-OCT-76 14:57 PAGE 38  
\*TEST THAT CLOCK A STATUS REGISTER BIT 6 CAN BE SET AND CLEARED

1463

M03

MAINDEC-11-DVKWA-A  
DVKWA.P11 T6

MACY11 27(732) 04-OCT-76 14:57 PAGE 39  
\*TEST THAT CLOCK A STATUS REGISTER BIT 6 CAN BE SET AND CLEARED

```

1464 ;/
1465 ;*****
1466 ;TEST 7 *TEST THAT CLOCK A STATUS REGISTER BIT 5 CAN BE SET AND CLEARED
1467 ;*
1468 ;*CLOCK STATUS REGISTER BIT EXERCISE. ON FAILURE-SUSPECT INDIVIDUAL
1469 ;*F/FS OR GATES
1470 ;*
1471 ;*****
1472 ;*****
1473 003072 000004 1ST7: SCOPE
1474 003074 012737 000100 001160 MOV #100,STIMES ;;DO 100 ITERATIONS
1475
1476 003102 005077 176270 CLR @ASR ;/CLEAR THE STATUS REGISTER.
1477 003106 052777 000040 176262 BIS #BITS,@ASR ;/SET BIT 5.
1478 003114 012737 000040 001124 MOV #BITS,$GDDAT ;/SET FOR ERROR TYPEOUT S/B.
1479 003122 017737 176250 001126 MOV @ASR,$BDDAT ;/READ THE STATUS REGISTER.
1480 003130 023737 001124 001126 CMP $GDDAT,$BDDAT ;/DID BIT 5 AND ONLY BIT 5 SET?
1481 003136 001402 BEQ IS ;/IF SO-LETS TRY CLEARING IT.
1482
;;*****
1485 003140 104002 ERROR 2 ;/ERROR CLOCK AS STATUS REGISTER
1486 ;/BIT 5 FAILED TO BIT SET.
1487
;;*****
1490 003142 000412 BR 2S ;/BR TO END SUBTEST.
1491
1492 003144 042777 000040 176224 1S: BIC #BITS,@ASR ;/TRY CLEARING BIT 5.
1493 003152 005037 001124 CLR $GDDAT ;/CLEAR S/B FOR TYPEOUT IF ANY.
1494 003156 017737 176214 001126 MOV @ASR,$BDDAT ;/NOW READ IT BACK.
1495 003164 001401 BEQ 2S ;/IF ZERO - NO ERROR!
1496
1497
;;*****
1500 003166 104002 ERROR 2 ;/ERROR - CLOCK A STATUS REGISTER.
1501 ;/BIT 5 FAILED TO CLEAR.
1502
1503
;;*****
1506 003170 2S:
1507

```

N03

MAINDEC-11-DVKWA-A  
DVKWA.P11 T7

M3CY11 27(732) 04-OCT-76 14:57 PAGE 40  
\*TEST THAT CLOCK A STATUS REGISTER BIT 5 CAN BE SET AND CLEARED

1508

1..

:



```

1509 ;/8
1510 ;*****
1511 ;*TEST 10 *TEST THAT CLOCK A STATUS REGISTER BIT 4 CAN BE SET AND CLEARED
1512 ;*
1513 ;*CLOCK STATUS REGISTER BIT EXERCISE. ON FAILURE-SUSPECT INDIVIDUAL
1514 ;*F/FS OR GATES
1515 ;*
1516 ;*****
1517 ;ST10: SCOPE
1518 003170 000004          MOV      #100,$TIMES      ;;DO 100 ITERATIONS
1519 003172 012737 000100 001160          CLR      @ASR            ;/CLEAR THE STATUS REGISTER.
1520 ;
1521 003200 005077 176172          BIS      @BIT4,@ASR      ;/SET BIT 4.
1522 003204 052777 003C20 176164          MOV      @BIT4,$GDOAT    ;/SET FOR ERROR TIMEOUT S/B.
1523 003212 012737 000020 001124          MOV      @ASR,$BDOAT     ;/READ THE STATUS REGISTER.
1524 003220 017737 176152 001126          CMP      $GDOAT,$BDOAT   ;/DID BIT 4 AND ONLY BIT 4 SET?
1525 003226 023737 001124 001126          BEQ      IS              ;/IF SO-LETS TRY CLEARING IT.
1526 003234 001402
1527 ;*****
1530 003236 104002          ERROR 2                ;/ERROR CLOCK AS STATUS REGISTER
1531 ;
1532 ;*****
1535 003240 000412          BR      2S              ;/BR TO END SUBTEST.
1536 ;
1537 003242 042777 000020 176126 1S:    BIC      @BIT4,@ASR      ;/TRY CLEARING BIT 4.
1538 003250 005037 001124          CLR      $GDOAT         ;/CLEAR S/B FOR TIMEOUT IF ANY.
1539 003254 017737 176116 001126          MOV      @ASR,$BDOAT     ;/NOW READ IT BACK.
1540 003262 001401          BEQ      2S              ;/IF ZERO - NO ERROR!
1541 ;
1542 ;*****
1545 003264 104002          ERROR 2                ;/ERROR - CLOCK A STATUS REGISTER.
1546 ;
1547 ;*****
1548 ;*****
1551 003266          2S:
1552 ;*****

```

C04

MAINDEC-11-DVKWA-A  
DVKWA.P11 T10

MACY11 27(732) 04-OCT-76 14:57 PAGE 42  
\*TEST THAT CLOCK A STATUS REGISTER BIT 4 CAN BE SET AND CLEARED

1553

```

1554 ;/8
1555 ;*****
1556 ;*TEST 11 *TEST THAT CLOCK A STATUS REGISTER BIT 3 CAN BE SET AND CLEARED
1557 ;*
1558 ;*CLOCK STATUS REGISTER BIT EXERCISE. ON FAILURE-SUSPECT INDIVIDUAL
1559 ;*F/FS OR GATES
1560 ;*
1561 ;*****
1562 ;*****
1563 003266 000004          †ST11: SCOPE
1564 003270 012737 000100 001160      MOV      #100,$TIMES      ;;DO 100 ITERATIONS
1565
1566 003276 005077 176074          CLR      2ASR            ;/CLEAR THE STATUS REGISTER.
1567 003302 052777 000010 176066      BIS      #BIT3,2ASR     ;/SET BIT 3.
1568 003310 012737 000010 001124      MOV      #BIT3,$GDDAT   ;/SET FOR ERROR TYPEOUT S/B.
1569 003316 017737 176054 001126      MOV      2ASR,$BDDAT    ;/READ THE STATUS REGISTER.
1570 003324 023737 001124 001126      CMP      $GDDAT,$BDDAT  ;/DID BIT 3 AND ONLY BIT 3 SET?
1571 003332 001402          BEQ      15              ;/IF SO-LETS TRY CLEARING IT.
1572
;;*****
1575 003334 104002          ERROR    2              ;/ERROR CLOCK AS STATUS REGISTER
1576                                     ;/BIT 3 FAILED TO BIT SET.
1577
;;*****
1580 003336 000412          BR       25              ;/BR TO END SUBTEST.
1581
1582 003340 042777 000010 176030 15:   BIC      #BIT3,2ASR     ;/TRY CLEARING BIT 3.
1583 003346 005037 001124          CLR      $GDDAT        ;/CLEAR S/B FOR TYPEOUT IF ANY.
1584 003352 017737 176020 001126      MOV      2ASR,$BDDAT    ;/NOW READ IT BACK.
1585 003360 001401          BEQ      25              ;/IF ZERO - NO ERROR!
1586
1587
;;*****
1590 003362 104002          ERROR    2              ;/ERROR - CLOCK A STATUS REGISTER.
1591                                     ;/BIT 3 FAILED TO CLEAR.
1592
1593
;;*****
1596 003364          25:
1597

```

E04

MAINDEC-11-DVKWA-A  
DVKWA.P11 T11

MACY11 27(732) 04-OCT-76 14:57 PAGE 44  
\*TEST THAT CLOCK A STATUS REGISTER BIT 3 CAN BE SET AND CLEARED

1598

F04

MAINDEC-11-DVKWA-A  
DVKWA.P11 T11

MACY11 27(732) 04-OCT-76 14:57 PAGE 45  
\*TEST THAT CLOCK A STATUS REGISTER BIT 3 CAN BE SET AND CLEARED

1599  
1600  
1601  
1602  
1603  
1604  
1605  
1606  
1607  
1608 003364 000004  
1609 003366 012737 000100 001160  
1610  
1611 003374 005077 175776  
1612 003400 052777 000004 175770  
1613 003406 012737 000004 001124  
1614 003414 017737 175756 001126  
1615 003422 023737 001124 001126  
1616 003430 001402  
1617  
  
1620 003432 104002  
1621  
1622  
  
1625 003434 000412  
1626  
1627 003436 042777 000004 175732  
1628 003444 005037 001124  
1629 003450 017737 175722 001126  
1630 003456 001401  
1631  
1632  
  
1635 003460 104002  
1636  
1637  
1638  
  
1641 003462  
1642

```
;/8  
*****  
*TEST 12 *TEST THAT CLOCK A STATUS REGISTER BIT 2 CAN BE SET AND CLEARED  
*  
*CLOCK STATUS REGISTER BIT EXERCISE. ON FAILURE-SUSPECT INDIVIDUAL  
*F/FS OR GATES  
*  
*****  
↑ST12: SCOPE  
MOV #100,$TIMES ;;DO 100 ITERATIONS  
  
CLR @ASR ;/CLEAR THE STATUS REGISTER.  
BIS #BIT2,@ASR ;/SET BIT 2.  
MOV #BIT2,$GDDAT ;/SET FOR ERROR TYPEOUT S/B.  
MOV @ASR,$BDDAT ;/READ THE STATUS REGISTER.  
CMP $GDDAT,$BDDAT ;/DID BIT 2 AND ONLY BIT 2 SET?  
BEQ IS ;/IF SO-LETS TRY CLEARING IT.  
  
*****  
ERROR <<<*****  
  
ERROR 2 ;/ERROR CLOCK AS STATUS REGISTER  
;/BIT 2 FAILED TO BIT SET.  
  
*****  
ERROR <<<*****  
  
BR 2$ ;/BR TO END SUBTEST.  
IS: BIC #BIT2,@ASR ;/TRY CLEARING BIT 2.  
CLR $GDDAT ;/CLEAR S/B FOR TYPEOUT IF ANY.  
MOV @ASR,$BDDAT ;/NOW READ IT BACK.  
BEQ 2$ ;/IF ZERO - NO ERROR!  
  
*****  
ERROR <<<*****  
  
ERROR 2 ;/ERROR - CLOCK A STATUS REGISTER.  
;/BIT 2 FAILED TO CLEAR.  
  
*****  
ERROR <<<*****  
  
2$:
```

G04

MAINDEC-11-DMQA-A  
DMQA.P11 T12

MACY11 27(732) 04-OCT-76 14:57 PAGE 46  
\*TEST THAT CLOCK A STATUS REGISTER BIT 2 CAN BE SET AND CLEARED

1643

```

1644
1645
1646
1647
1648
1649
1650
1651
1652
1653 003462 000004
1654 003464 012737 000100 001160
1655
1656 003472 005077 175700          CLR    2ASR          ;/CLEAR THE STATUS REGISTER.
1657 003476 052777 000002 175672     BIS    #BIT1,2ASR   ;/SET BIT 1.
1658 003504 012737 000002 001124     MOV    #BIT1,$GDDAT ;/SET FOR ERROR TYPEOUT S/B.
1659 003512 017737 175660 001126     MOV    2ASR,$BDDAT  ;/READ THE STATUS REGISTER.
1660 003520 023737 001124 001126     CMP    $GDDAT,$BDDAT ;/DID BIT 1 AND ONLY BIT 1 SET?
1661 003526 001402          BEQ    1$           ;/IF SO-LETS TRY CLEARING IT.
1662
1663
1664
1665 003530 104002          ERROR 2            ;/ERROR CLOCK AS STATUS REGISTER
1666
1667
1670 003532 000412          BR     2$           ;/BR TO END SUBTEST.
1671
1672 003534 042777 000002 175634 1$:    BIC    #BIT1,2ASR   ;/TRY CLEARING BIT 1.
1673 003542 005037 001124          CLR    $GDDAT      ;/CLEAR S/B FOR TYPEOUT IF ANY.
1674 003546 017737 175624 001126     MOV    2ASR,$BDDAT ;/NOW READ IT BACK.
1675 003554 001401          BEQ    2$           ;/IF ZERO - NO ERROR!
1676
1677
1680 003556 104002          ERROR 2            ;/ERROR - CLOCK A STATUS REGISTER.
1681
1682
1683
1686 003560          2$:
1687

```

MAINDEC-11-DVKWA-A  
DVKWA.P11 T13

MACY11 27(732) 04-OCT-76 14:57 PAGE 48  
\*TEST THAT CLOCK A STATUS REGISTER BIT 1 CAN BE SET AND CLEARED

1688



1689  
1690  
1691  
1692  
1693  
1694  
1695  
1696  
1697  
1698  
1699  
1700  
1701  
1702  
1703  
1704  
1705  
1706  
1707

003560 000004  
003562 012737 000100 001160  
003570 005077 175602  
003574 052777 000001 175574  
003602 012737 000001 001124  
003610 017737 175562 001126  
003616 023737 001124 001126  
003624 001402

:/#  
\*\*\*\*\*  
\*TEST 14 \*TEST THAT CLOCK A STATUS REGISTER BIT 0 CAN BE SET AND CLEARED  
\*  
\*CLOCK STATUS REGISTER BIT EXERCISE. ON FAILURE-SUSPECT INDIVIDUAL  
\*F/FS OR GATES  
\*

\*\*\*\*\*

↑ST14: SCOPE  
MOV #100, \$TIMES ;;DO 100 ITERATIONS  
CLR @ASR ;/CLEAR THE STATUS REGISTER.  
BIS @BIT0, @ASP ;/SET BIT 0.  
MOV @BIT0, \$GDCAT ;/SET FOR ERROR TYPEOUT S/B.  
MOV @ASR, @BDDAT ;/READ THE STATUS REGISTER.  
CMP \$GDDAT, @BDDAT ;/DID BIT 0 AND ONLY BIT 0 SET?  
BEQ IS ;/IF SO-LETS TRY CLEARING IT.

;;\*\*\*\*\*>>> ERROR <<<\*\*\*\*\*

1710  
1711  
1712

003626 104002

ERROR 2 ;/ERROR CLOCK AS STATUS REGISTER  
;/BIT 0 FAILED TO BIT SET.

;;\*\*\*\*\*>>> ERROR <<<\*\*\*\*\*

1715  
1716  
1717  
1718  
1719  
1720  
1721  
1722

003630 000412  
003632 042777 000001 175536  
003640 005037 001124  
003644 017737 175526 001126  
003652 001401

BR 25 ;/BR TO END SUBTEST.  
15: BIC @BIT0, @ASR ;/TRY CLEARING BIT 0.  
CLR \$GDDAT ;/CLEAR S/B FOR TYPEOUT IF ANY.  
MOV @ASR, @BDDAT ;/NOW READ IT BACK.  
BEQ 25 ;/IF ZERO - NO ERROR!

;;\*\*\*\*\*>>> ERROR <<<\*\*\*\*\*

1725  
1726  
1727  
1728

003654 104002

ERROR 2 ;/ERROR - CLOCK A STATUS REGISTER.  
;/BIT 0 FAILED TO CLEAR.

;;\*\*\*\*\*>>> ERROR <<<\*\*\*\*\*

1731  
1732

003656

25:













MAINDEC-11-DVKWA-A  
DVKWA.P11 T24

MACY11 27(732) 04-OCT-76 14:57 PAGE 56  
\*TEST THAT INIT CLEARS BUFFER REGISTER

2069 004576 001403  
2070 004600 052777 016000 174610  
2071  
2072  
2073  
2074  
2075 004606 000004  
2076  
2077 004610 012777 000001 174560  
2078 004616 052777 001000 174552  
2079  
2080 004624 005777 174546  
2081 004630 100402  
2082  
2083

BEQ TST25  
BIS #BIT11!BIT12!BIT10,20R2 ;ENABLE THEM  
;\*\*\*\*\*  
; \*TEST 25 \*TEST THE SETTING OF MAINTENANCE ST2 IN CLOCK BIT 15 TO SET  
;\*\*\*\*\*  
TST25: SCOPE  
MOV #1,20ASR ;SET THE GO BIT(ENABLES ST2 TO SET FLG).  
BIS #BIT9,20ASR ;SET MAINTENANCE ST2.  
TST 20ASR ;DID BIT15 (ST2 FLAG) SET?  
BMI 15 ;BR IF YES - NEXT TEST  
;\*\*\*\*\*  
;\*\*\*\*\*  
;\*\*\*\*\*

2086 004632 104001  
2087  
2088  
2089

ERROR 1 ;ERROR - MAINTENANCE ST2 (BIT9)  
;DID NOT SET BIT15 (ST2 FLAG).  
;\*\*\*\*\*  
;\*\*\*\*\*  
;\*\*\*\*\*

2092 004634 000410  
2093 004636 005737 001440  
2094 004642 001405  
2095 004644 032777 000004 174542  
2096 004652 001001  
2097

BR TST26 ;;  
TST EXS ;TEST EXTERNAL SIGNALS?  
BEQ TST26 ;;  
BIT #BIT2,20R ;DID EXTERNAL ST2 GET SET?  
BNE TST26 ;;  
;\*\*\*\*\*  
;\*\*\*\*\*  
;\*\*\*\*\*

2100 004654 104006  
2101  
2102

ERROR 6 ;ST2 OUT NOT DETECTED  
;BY TESTOR  
;\*\*\*\*\*  
;\*\*\*\*\*  
;\*\*\*\*\*

2105  
2106  
2107  
2108  
2109  
2110 004656 000004  
2111  
2112 004660 012777 020000 174510  
2113 004666 052777 001000 174502  
2114 004674 032777 000001 174474  
2115 004702 001001  
2116  
2117

;\*\*\*\*\*  
; \*TEST 26 \*TEST THAT BIT00 IN CLOCK STATUS REG. WILL SET WHEN BIT13 AND MAIN. ST2  
;\*\*\*\*\*  
TST26: SCOPE  
MOV #BIT13,20ASR ;SET "ST2 ENB COUNTER" IN CLK STATUS REG.  
BIS #BIT9,20ASR ;GENERATE A MAINTENANCE ST2.  
BIT #BIT00,20ASR ;DID BIT00 (GO) SET?  
BNE 15 ;BR IF YES - NEXT TEST.  
;\*\*\*\*\*  
;\*\*\*\*\*  
;\*\*\*\*\*

2120 004704 104001  
2121  
2122  
2123  
2124

ERROR 1 ;ERROR - BIT00 OF CLOCK'S STATUS REGISTER  
;FAILED TO SET WHEN BIT13 WAS SET  
;AND A MAINTENANCE ST2 GENERATED.









H05

MAINDEC-11-DVKWA-A  
DVKWA.P11 T32

MACY11 27(732) 04-OCT-76 14:57 PAGE 60  
\*TEST THAT OVERFLOW WILL CLEAR THE GO BIT

2293  
2294  
;;SSSSSSSSSSSSSSSSSSSSSSSSSSSS>> ERROR <<SSSSSSSSSSSSSSSSSSSSSSSSSSSSSSSSSSSSSS

2297 005276 104006 ERROR 6 ;ERROR - OVERFLOW FAILED  
2298 ;TO CLEAR ENABLE (CSR BITDC)  
2299

2300 005400 IS:

2301  
2302  
2303  
2304  
2305 005400 000004  
2306  
2307  
2308  
2309  
2310  
2311  
2312  
2313  
2314  
2315

```

*****
: *TEST 33      *TEST THAT GO BIT DOES NOT CLEAR ON OVERFLOW, IF MODE 1
*****
↑ST33: SCOPE
      CLR      QASR          ;CLEAR THE CSR.
      MOV      #-1,QABR      ;PRESET BUFFER=ONE COUNT FROM OVERFLOW.
      BIS      #63,QASR      ;MODE 1, RATE:ST1, GO.
      BIS      #BIT8,QASR    ;GENERATE MAINTENANCE ST1.
      BIT      #BIT0,QASR    ;DID ENABLE (GO BIT) CLEAR?
      BNE      IS           ;NO (GOOD) NEXT TEST.

```

2318 005440 104006 ERROR 6 ;GO BIT CLEARED ON OVERFLOW  
2319 ;WHEN MODE 1 WAS SELECTED  
2320

;;SSSSSSSSSSSSSSSSSSSSSSSSSSSS>> ERROR <<SSSSSSSSSSSSSSSSSSSSSSSSSSSSSSSSSSSSSS

2323  
2324 005442 005077 173730 IS: CLR QASR ;CLEAR THE CLOCK.  
2325  
2326  
2327  
2328

2329  
2330  
2331  
2332  
2333  
2334  
2335  
2336  
2337  
2338  
2339  
2340

```

*****
: *TEST 34      *TEST THE ABILITY OF CLOCK TO COUNT AT 1MHZ RATE
*****
: *
: *THIS TEST IS DESIGNED TO TEST THE CLOCK'S ABILITY
: *TO COUNT AT 1MHZ RATE.
: *
: *****
↑ST34: SCOPE
      MOV      #5,STIMES    ;;DO 5 ITERATIONS

```

2341 005456 005077 173714 CLR QASR ;/CLEAR CLOCK  
2342 005462 005077 173712 CLR QABR ;/CLEAR PRESET BUFFER  
2343 005466 012777 000011 173702 MOV #BIT0!10,QASR ;/START CLOCK, MODE0, RATE:1MHZ  
2344 005474 005000 CLR R0 ;/NOW WE'LL DO A LITTLE DELAY. THIS DELAY  
2345  
2346 005476 005200 IS: INC R0 ;/WILL AMOUNT TO APPROXIMATELY  
2347 005500 001376 BNE IS ;/369 MS.  
2348



J05

MAINDEC-11-DVKWA-A  
DVKWA.P11 T35

MAY11 27(732) 04-OCT-76 14:57 PAGE 62  
\*TEST THE ABILITY OF CLOCK TO COUNT AT 100KHZ RATE

05  
06  
07  
08  
09  
10  
11  
12  
13  
14  
15  
16  
17  
18

```

005664 052777 001000 173504      BIS      #BIT9,2ASR
005672 017737 173502 001126      MOV      2ABR,$BDDAT
005700 012677 173472      MOV      (6)+,2ASR
005704 005737 001126      TST     $BDDAT
005710 001004      BNE     2$
005712 105766 177776      TSTB    -2(6)
005716 100401      BMI     2$

```

```

;/THIS MUST BE DONE IN
;/ORDER TO XFERR COUNTER
;/TO BUFFER ON ST2
;/GENERATE ON ST2 PULSE
;/READ THE PRESET BUFFER,
;/PREVIOUS COUNTER
;/CONTENTS ARE IN $BDDAT.
;/RESTORE CSR
;/YES - NEXT TEST.
;/AT HIGH RATE MAY HAVE HAD OVERFLOW
;/NOTE: CSR HAS BEEN PUT ON STACK.
;/NEXT TEST IF OVERFLOW.

```

;; \$ ERROR <<< \$

21  
22  
23

```

005720 104006      ERROR 6

```

```

;/CLOCK FAILED TO COUNT AT
;/RATE:100KHZ

```

;; \$ ERROR <<< \$

26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50

```

005722 005077 173450      2$: CLR 2ASR ;/CLEAR THE CLOCK.

```

```

;*****
; *TEST 36 *TEST THE ABILITY OF CLOCK TO COUNT AT 10KHZ RATE

```

```

; *THIS TEST IS DESIGNED TO TEST THE CLOCK'S ABILITY
; *TO COUNT AT 10KHZ RATE.
; *
;*****

```

```

005726 000004      1$T36: SCOPE
005730 012737 000005 001160      MOV #5,$TIMES ;;DO 5 ITERATIONS

```

```

005736 005077 173434      CLR 2ASR ;/CLEAR CLOCK
005742 005077 173432      CLR 2ABR ;/CLEAR PRESET BUFFER
005746 012777 000031 173422      MOV #BIT0!30,2ASR ;/START CLOCK, MODE0, RATE:10KHZ
005754 005000      CLR R0 ;/NOW WE'LL DO A LITTLE DELAY. THIS DELAY

```

```

1$: INC R0 ;/WILL AMOUNT TO APPROXIMATELY
BNE 1$ ;/369 MS.

```

```

005762 017746 173410      MOV 2ASR,-(6) ;/SAVE CSR
005766 011637 001424      MOV (6),$TMP3 ;/GET CSR.
005772 042737 177707 001424      BIC #177707,$TMP3 ;/SAVE RATE BITS.
006000 052737 004005 001424      BIS #BIT1!BIT2!BIT0,$TMP3 ;/SET MODE 2, NO RATE,DISABLE INTERNAL OSC
006006 013777 001424 173362      MOV $TMP3,2ASR ;/LOAD CSR.

```

```

;/THIS MUST BE DONE IN
;/ORDER TO XFERR COUNTER
;/TO BUFFER ON ST2.
;/GENERATE ON ST2 PULSE
;/READ THE PRESET BUFFER,

```

```

006014 052777 001000 173354      BIS #BIT9,2ASR
006022 017737 173352 001126      MOV 2ABR,$BDDAT

```

# K05

MAINDEC-11-DVKWA-A  
DVKWA.P11 T36

MACY11 27(732) 04-OCT-76 14:57 PAGE 63  
\*TEST THE ABILITY OF CLOCK TO COUNT AT 10KHZ RATE

```

2461 006030 012677 173342          MOV     (6)+,DASR      ;/PREVIOUS COUNTER
2462 006034 005737 001126          TST     $BDDAT        ;/CONTENTS ARE IN $BDDAT.
2463 006040 001004              BNE     25             ;/RESTORE CSR
2464 006042 105766 177776          TSTB   -2(6)         ;/YES - NEXT TEST.
2465 006046 100401              BMI     25             ;/AT HIGH RATE MAY HAVE HAD OVERFLOW
2466 006046 100401              BMI     25             ;/NOTE: CSR HAD BEEN PUT ON STACK.
2467 006046 100401              BMI     25             ;/NEXT TEST IF OVERFLOW.
2468
2469
                ;; $$$$$$$$$$$$$$$$$$$$$$$$$$$$$$ ERROR <<< $$$$$$$$$$$$$$$$$$$$$$$$$$$$$$
2472 006050 104006          ERROR   6             ;/CLOCK FAILED TO COUNT AT
2473                                   ;/RATE:10KHZ
2474
                ;; $$$$$$$$$$$$$$$$$$$$$$$$$$$$$$ ERROR <<< $$$$$$$$$$$$$$$$$$$$$$$$$$$$$$
2477
2478 006052 005077 173320          25:    CLR     DASR      ;/CLEAR THE CLOCK.
2479
2480
                ;; *****
2481                ; *TEST 37             *TEST THE ABILITY OF CLOCK TO COUNT AT 1KHZ RATE
2482
2483                ; *
2484                ; *THIS TEST IS DESIGNED TO TEST THE CLOCK'S ABILITY
2485                ; *TO COUNT AT 1KHZ RATE.
2486                ; *
2487                ; *****
2488
2489                ST37:  SCOPE
2490                ; *****
2491                006056 000004          MOV     #5,$TIMES      ;; DO 5 ITERATIONS
2492                006060 012737 000005 001160
2493
2494                006066 005077 173304          CLR     DASR          ;/CLEAR CLOCK
2495                006072 005077 173302          CLR     DABR          ;/CLEAR PRESET BUFFER
2496                006076 012777 000041 173272          MOV     #BIT0!40,DASR ;/START CLOCK, MODE0, RATE:1KHZ.
2497                006104 005000          CLR     R0            ;/NOW WE'LL DO A LITTLE DELAY. 4IS DELAY
2498
2499                006106 005200          15:    INC     R0            ;/WILL AMOUNT TO APPROXIMATELY
2500                006110 001376          BNE     15            ;/369 MS.
2501
2502                006112 017746 173260          MOV     DASR,-(6)     ;/SAVE CSR
2503                006116 011637 001424          MOV     (6),$TMP3     ;/GET CSR.
2504                006122 042737 177707 001424          BIC     #177707,$TMP3 ;/SAVE RATE BITS.
2505                006130 052737 004005 001424          BIS     #BIT1!BIT2!BIT0,$TMP3 ;/SET MODE 2, NO RATE,DISABLE INTERNAL OSC
2506                006136 013777 001424 173232          MOV     $TMP3,DASR   ;/LOAD CSR.
2507
2508                ;/THIS MUST BE DONE IN
2509                ;/ORDER TO XFERR COUNTER
2510                006144 052777 001000 173224          BIS     #BIT9,DASR   ;/TO BUFFER ON ST2.
2511                006152 017737 173222 001126          MOV     DABR,$BDDAT  ;/GENERATE ON ST2 PULSE
2512
2513                006160 012677 173212          MOV     (6)+,DASR   ;/READ THE PRESET BUFFER,
2514                006164 005737 001126          TST     $BDDAT      ;/PREVIOUS COUNTER
2515                006170 001004              BNE     25            ;/CONTENTS ARE IN $BDDAT.
2516                006172 105766 177776          TSTB   -2(6)         ;/RESTORE CSR
                ;/YES - NEXT TEST.
                ;/AT HIGH RATE MAY HAVE HAD OVERFLOW
    
```

















MAINDEC-11-DVKWA-A  
DVKWA.P11 TS1

MACY11 27(732) 04-OCT-76 14:57 PAGE 71  
\*TEST THAT FOR BIT WILL CLEAR IF GO BIT IS SET

2909								
2910	007440	042777	000001	171730	BIC	#BIT0, @ASR		; FOR BIT SETS HERE.
2911								; CLEAR GO BIT.
2912	007446	052777	000001	171722	BIS	#BIT0, @ASR		; SET THE "GO" BIT AGAIN -

G06

MAINDEC-11-DVKWA-A  
DVKWA.P11 T51

MACY11 27(732) 04-OCT-76 14:57 PAGE 72  
\*TEST THAT FOR BIT WILL CLEAR IF GO BIT IS SET

2913  
2914  
2915

007454 017737 171716 001126

MOV 2ASR, \$BDOAT

; SHOULD CLEAR FOR BIT.

; READ THE CSR.





MAINDEC-11-DVKWA-A  
DVKWA.P11 T52

MACY11 27(732) 04-OCT-76 14:57 PAGE 74  
\*TEST THAT WE CAN DISABLE THE INTERNAL OSC

2929				
2930				
2931				
2932	007506	000004		
2933	007510	012737	000005	001160
2934				
2935	007516	005077	171654	

```

:*****
: *TEST 52      *TEST THAT WE CAN DISABLE THE INTERNAL OSC
:*****
†ST52: SCOPE
      MOV      #5,$TIMES      ;;DO 5 ITERATIONS
      CLR      @ASR          ;CLEAR THE CSR

```

J06

MAINDEC-11-DVKWA-A  
DVKWA.P11 T52

MFCY11 27(732) 04-OCT-76 14:57 PAGE 75  
\*TEST THAT WE CAN DISABLE THE INTERNAL OSC

2936 007522 005077 171652

CLR 2ABR

;CLEAR THE PRESET BUFFER

K06

MAINDEC-11-DVKWA-A  
DVKWA.P11 T52

MACY11 27(732) 04-OCT-76 14:57 PAGE 76  
\*TEST THAT WE CAN DISABLE THE INTERNAL OSC

2937 007526 005037 001124  
2938

CLR \$GDDAT

;CLEAR EXPED.

MAINDEC-11-DVKWA-A  
DVKWA.P11 T52

MACY11 27(732) 04-OCT-76 14:57 PAGE 77  
\*TEST THAT WE CAN DISABLE THE INTERNAL OSC

```
2939 007532 012777 004000 171636      MOV      #BIT11,2ASR      ;DISABLE THE INTERNAL OSC.
2940 007540 052777 000011 171630      BIS      #BIT3!BIT0,2ASR ;START CLOCK:RATE 1MHZ.
2941 007546 005000                      CLR      RO
2942 007550 105200                      IS:     INCB      RO      ;DELAY A SHORT TIME.
2943 007552 001376                      BNE     IS
2944 007554 017746 171616      MOV      2ASR,-(6)      ;/SAVE CSR
2945 007560 011637 001424      MOV      (6),$TMP3      ;/GET CSR.
2946 007564 042737 177707 001424      BIC      #177707,$TMP3  ;/SAVE RATE BITS.
2947 007572 052737 004005 001424      BIS      #BIT11!BIT2!BIT0,$TMP3 ;/SET MODE 2, NO RATE.DISABLE INTERNAL OSC
2948 007600 013777 001424 171570      MOV      $TMP3,2ASR    ;/LOAD CSR.
2949                      ;/THIS MUST BE DONE IN
2950                      ;/ORDER TO XFERR COUNTER
2951                      ;/TO BUFFER ON ST2.
2952 007606 052777 001000 171562      BIS      #BIT9,2ASR    ;/GENERATE ON ST2 PULSE
2953 007614 017737 171560 001126      MOV      2ABR,$BDDAT  ;/READ THE PRESET BUFFER,
2954                      ;/PREVIOUS COUNTER
2955 007622 012677 171550      MOV      (6)+,2ASR     ;/CONTENTS ARE IN $BDDAT.
2956 007626 005737 001126      TST     $BDDAT        ;/RESTORE CSR
2957 007632 001401                      BEQ     2S            ;NO - GOOD - NEXT TEST.
2958                      ;/NO - GOOD - NEXT TEST.

;:SSSSSSSSSSSSSSSSSSSSSSSSSSSSSS)) ERROR ((SSSSSSSSSSSSSSSSSSSSSSSSSSSSSSSSSSSSSSSS
2961 007634 104011                      ERROR    11          ;CLOCK DISABLE INTERNAL
2962                      ;OSC. DID NOT WORK.
2963                      ;:SSSSSSSSSSSSSSSSSSSSSSSSSSSSSS)) ERROR ((SSSSSSSSSSSSSSSSSSSSSSSSSSSSSSSSSSSSSSSS
2966 007636 005077 171534      2S:     CLR      2ASR      ;CLEAR THE CSR.
2967
2968 ;:*****
2969 ;:TEST 53      *TEST THAT CLOCK CAN BE COUNTED USING MAINTENANCE OSC
2970 ;:*****
2971 007642 000004      †ST53: SCOPE
2972
2973 007644 005077 171526      CLR      2ASR          ;CLEAR THE CSR.
2974 007650 005077 171524      CLR      2ABR          ;CLEAR THE PRESET BUFFER.
2975 007654 052777 004000 171514      BIS      #BIT11,2ASR   ;DISABLE THE INTERNAL OSC.
2976 007662 052777 000011 171506      BIS      #BIT3!BIT0,2ASR ;START CLOCK, 1MHZ, GO.
2977 007670 012700 177754      MOV      #-20.,RO     ;SET TO COUNT 20 TIMES
2978
2979 007674 052777 002000 171474      IS:     BIS      #BIT10,2ASR ;GENERATE 1 MAINTENANCE OSC.
2980                      ;NOTE: AT 1MHZ, IT TAKES 10
2981                      ;MAINT. OSC TO EQUAL 1 COUNT
2982                      ;DO 20 MAINTENANCE OSC.
2982 007702 005200                      INC      RO
2983 007704 001373                      BNE     IS
2984
2985 007706 017746 171464      MOV      2ASR,-(6)    ;/SAVE CSR
2986 007712 011637 001424      MOV      (6),$TMP3    ;/GET CSR.
2987 007716 042737 177707 001424      BIC      #177707,$TMP3 ;/SAVE RATE BITS.
2988 007724 052737 004005 001424      BIS      #BIT11!BIT2!BIT0,$TMP3 ;/SET MODE 2, NO RATE,DISABLE INTERNAL OSC
2989 007732 013777 001424 171436      MOV      $TMP3,2ASR  ;/LOAD CSR.
2990                      ;/THIS MUST BE DONE IN
2991                      ;/ORDER TO XFERR COUNTER
2992                      ;/TO BUFFER ON ST2.
2993 007740 052777 001000 171430      BIS      #BIT9,2ASR   ;/GENERATE ON ST2 PULSE
2994 007746 017737 171426 001126      MOV      2ABR,$BDDAT  ;/READ THE PRESET BUFFER,
```





MA:MOE(-11-DVKWA-A  
DVKWA.P11 T54

MAY11 27(732) 04-OCT-76 14:57 PAGE 80  
\*TEST THE CLOCK'S 1MHZ DIVIDER

```

3056 010166 005300          DEC      R0          ;/WHAT WE WANT TO CHECK
3057 010170 001373          BNE      45          ;/1MHZ PULSE ON 9 OSC PULSES.
3058
3059
3070 010172 017746 171200    MOV      2ASR, -(6)   ;/SAVE CSR
3071 010176 011637 001424    MOV      (6), $TMP3  ;/GET CSR.
3072 010202 042737 177707 001424 BIC      #177707, $TMP3 ;/SAVE RATE BITS.
3073 010210 052737 004005 001424 BIS      #BIT11!BIT2!BIT0, $TMP3 ;/SET MODE 2, NO RATE, DISABLE INTERNAL OSC
3074 010216 013777 001424 171152 MOV      $TMP3, 2ASR ;/LOAD CSR.
3075
3076                          ;/THIS MUST BE DONE IN
3077                          ;/ORDER TO XFERR COUNTER
3078 010224 052777 001000 171144 BIS      #BIT9, 2ASR  ;/TO BUFFER ON ST2.
3079 010232 017737 171142 001126 MOV      2ASR, $BDDAT ;/GENERATE ON ST2 PULSE
3080                          ;/READ THE PRESET BUFFER,
3081 010240 012677 171132    MOV      (6)+, 2ASR  ;/PREVIOUS COUNTER
3082 010244 005737 001126    TST      $BDDAT      ;/CONTENTS ARE IN $BDDAT.
3083 010250 022737 001124 001126 CMP      $GDDAT, $BDDAT ;/RESTORE CSR
3084 010256 001401          BEQ      55          ;/WAS ANOTHER 1MHZ PULSE GENERATED?
3085                          ;/NO - NEXT TEST.
```

;; \$ ERROR <<< \$

```

3088 010250 104011          ERROR      11          ;/WE SEEM TO HAVE GENERATED
3089                                ;/ANOTHER 1MHZ PULSE ON
3090                                ;/ONLY 9 MAINTENANCE
3091                                ;/OSC PULSES.
3092
```

;; \$ ERROR <<< \$

```

3095 010262 005077 171110    55:      CLR      2ASR          ;/CLEAR THE CSR.
```

```

;: *****
;: *TEST 55          *TEST THE CLOCK'S 100KHZ DIVIDER
;: *****
†T55: SCOPE
```

```

3101 010266 000004          MOV      #5, $TIMES  ;/DO 5 ITERATIONS
3102 010270 012737 000005 001160
3103
3104 010276 005077 171074    CLR      2ASR        ;/CLEAR THE CSR.
3105 010302 005077 171072    CLR      2ABR        ;/CLEAR THE PRESET BUFFER.
3106 010306 052777 004000 171062 BIS      #BIT11, 2ASR ;/DISABLE THE INTERNAL OSC.
3107 010314 052777 000021 171054 BIS      #1!20, 2ASR ;/ENABLE CLOCK, RATE:100KHZ
3108
3109
3110
```

```

3111 010322 012700 177634    10$:     MOV      #-100., R0   ;/SET TO GENERATE 100 OSC PULSES.
3112
3113 010326 052777 002000 171042 1$:      BIS      #BIT10, 2ASR ;/GENERATE ONE OSC PULSE.
3114 010334 005200          INC      R0          ;/DONE 100 OSC PULSES?
3115 010336 001373          BNE      18          ;/NO - DO ANOTHER ONE.
```

```

3118 010340 012737 000001 001124 2$:      MOV      #1, $GDDAT ;/SET FOR ERROR TYPEOUT - IF ANY.
3119 010346 017746 171024    MOV      2ASR, -(6)  ;/SAVE CSR
3120 010352 011637 001424    MOV      (6), $TMP3  ;/GET CSR.
3121 010356 042737 177707 001424 BIC      #177707, $TMP3 ;/SAVE RATE BITS.
```















3459  
3460  
3461  
3462  
3463  
3464  
3465  
3466  
3467  
3468  
3469  
3470  
3471  
3472  
3473  
3474  
3475  
3476  
3477  
3478  
3479  
3480  
3481  
3482  
3483  
3484  
3485

011656 000004  
011660 012737 000020 001160  
011666 005077 167504  
011672 005077 167502  
011676 012777 004015 167472  
011704 012700 177754  
011710 052777 002000 167460  
011716 005200  
011720 001373  
011722 052777 001000 167446  
011730 012737 000002 001124  
011736 017737 167436 001126  
011744 023737 001126 001124  
011752 001402

```
*OVERFLOW. AN EXTERNAL PULSE FROM SCHMITZ TRIGGER 2
*(WHEN ST2 GO ENABLE IS A "0") CAUSES DATA TO
*TRANSFER FROM THE COUNTER TO THE BUFFER/PRESET REG.
*WHILE THE COUNTER CONTINUES TO RUN.
*
*TO TEST THIS MODE, WE'LL DISABLE THE INTERNAL OSC AND USE
*MAINTENANCE OSC PULSES AS WELL AS A MAINTENANCE
*ST2.
*****
†ST61: SCOPE
MOV #20,STIMES ;;DO 20 ITERATIONS
CLR QASR ;;CLEAR THE CSR.
CLR QABR ;;CLEAR THE PRESET REG.
MOV #004015,QASR ;;START CLOCK.
15: MOV #20,R0 ;;SET TO GIVE 20 MAINTENANCE OSC.
25: BIS #BIT10,QASR ;;GENERATE A MAINTENANCE OSC.
INC R0
BNE 25 ;;IF NOT DONE 20 TIMES, LOOP.
35: BIS #BIT9,QASR ;;HERE'S THE BIGGIE! AN ST2 HAS BEEN GENERATED
MOV #2,$GDOAT ;;THE PRESET BUFFER SHOULD BE 2.
MOV QABR,$BDOAT ;;READ THE PRESET BUFFER.
CMP $BDOAT,$GDOAT ;;DID A COUNTER TO PRESET BUFFER OCCUR?
BEQ 45 ;;YES - NEXT SUBTEST.
```

;;;\*\*\*\*\*)) ERROR (((\*\*\*\*\*))

3488  
3489  
3490

011754 104005

```
ERROR 5 ;A COUNTER TO PRESET BUFFER DID NOT
HAPPEN PROPERLY.
```

;;;\*\*\*\*\*)) ERROR (((\*\*\*\*\*))

3493  
3494  
3495  
3496  
3497  
3498  
3499  
3500  
3501  
3502  
3503  
3504  
3505  
3506  
3507  
3508  
3509  
3510  
3511

011756 000434  
011760  
011760 017746 167412  
011764 011637 001424  
011770 042737 177707 001424  
011776 052737 004005 001424  
012004 013777 001424 167364  
012012 052777 001000 167356  
012020 017737 167354 001126  
012026 012677 167344  
012032 005737 001126  
012036 023737 001124 001126  
012044 001401

```
BR 55
45: MOV QASR,-(6) ;/SAVE CSR
MOV (6),$TMP3 ;/GET CSR.
BIC #177707,$TMP3 ;/SAVE RATE BITS.
BIS #BIT11!BIT2!BIT0,$TMP3 ;/SET MODE 2, NO RATE,DISABLE INTERNAL OSC
MOV $TMP3,QASR ;/LOAD CSR.
;/THIS MUST BE DONE IN
;/ORDER TO XFERR COUNTER
;/TO BUFFER ON ST2.
BIS #BIT9,QASR ;/GENERATE ON ST2 PULSE
MOV QABR,$BDOAT ;/READ THE PRESET BUFFER,
;/PREVIOUS COUNTER
MOV (6)+,QASR ;/CONTENTS ARE IN $BDOAT.
TST $BDOAT ;/STORE CSR
CMP $GDOAT,$BDOAT ;/WAS THE COUNTER ACCIDENTLY ZEROED?
BEQ 55 ;/NO - NEXT TEST.
```

;;;\*\*\*\*\*)) ERROR (((\*\*\*\*\*))









```

3682                                     ;IF HERE, ANOTHER CLOCK FOUND.
3683 012622 005737 001202             TST    $PASS                ;IS THIS 1ST PASS?
3684 012626 001003                   BNE    3$                    ;NO-GET OUT.
3695 012630 053737 001426 001430     BIS    ROTATE,UTEST        ;YES-RECORD THIS UNIT.
3686 012636                               3$:
3687 012636 104400 012644             TYPE   65$                  ;:TYPE ASCIZ STRING
3688 012642 000405                   BR     64$                  ;:GET OVER THE ASCIZ
3689                                     ;:65$: .ASCIZ <15><12>"UNIT #"  
3690                                     64$:
3691 012656 013746 001204             MOV    $DEVCT,-(SP)        ;:SAVE $DEVCT FOR TYPEOUT
3692 012662 104401                   TYPOC                                ;:GO TYPE--OCTAL ASCII(ALL DIGITS)
3693 012664 104400 012672             TYPE   67$                  ;:TYPE ASCIZ STRING
3694 012670 000406                   BR     66$                  ;:GET OVER THE ASCIZ
3695                                     ;:67$: .ASCIZ " COMPLETED "  
3696                                     66$:
3697 012706 005237 001204             INC    $DEVCT              ;:TYPE ASCIZ STRING
3698 012712 104400 012720             TYPE   69$                  ;:GET OVER THE ASCIZ
3699 012716 000410                   BR     68$                  ;:TYPE ASCIZ STRING
3700                                     ;:69$: .ASCIZ " TESTING UNIT #"  
3701                                     68$:
3702 012740 013746 001204             MOV    $DEVCT,-(SP)        ;:SAVE $DEVCT FOR TYPEOUT
3703 012744 104401                   TYPOC                                ;:GO TYPE--OCTAL ASCII(ALL DIGITS)
3704 012746 012637 000004             MOV    (6)+,ERRVEC        ;:RESET LOC 4.
3705 012752 062737 000010 001402     ADD    #10,VECT1          ;:UPDATE VECTOR ADDR.
3706 012760 000137 002260             JMP    LOOP                ;:TEST NEW UNIT.
3707
3708 012764                               1$:
3709 012764 062706 000004             ADD    #4,SP                ;:/ADD #4 TO STACK POINTER.
3710 012770 012637 000004             MOV    (6)+,ERRVEC        ;:RESTORE LOC 4
3711 012774 022737 000001 001204     CMP    #1,$DEVCT          ;:TESTED ONLY ONE UNIT?
3712 013002 001424                   BEQ    2$                    ;:YES - NO NEED FOR TYPEOUT.
3713
3714                               4$:
3715 013004 104400 013012             TYPE   71$                  ;:TYPE ASCIZ STRING
3716 013010 000405                   BR     70$                  ;:GET OVER THE ASCIZ
3717                                     ;:71$: .ASCIZ <15><12>"UNIT #"  
3718                                     70$:
3719 013024 013746 001204             MOV    $DEVCT,-(SP)        ;:SAVE $DEVCT FOR TYPEOUT
3720 013030 104401                   TYPOC                                ;:GO TYPE--OCTAL ASCII(ALL DIGITS)
3721 013032 104400 013040             TYPE   73$                  ;:TYPE ASCIZ STRING
3722 013036 000406                   BR     72$                  ;:GET OVER THE ASCIZ
3723                                     ;:73$: .ASCIZ " COMPLETED "  
3724                                     72$:
3725 013054
3726 013054 013737 001250 001376     2$: MOV    $BASE,ASR
3727 013062 013737 001244 001402     MOV    $VECT1,VECT1
3728 013070 012737 000001 001204     MOV    #1,$DEVCT
3729
3730 013076 005037 001434             CLR    $DEVCT              ;:BEGIN TESTING 1ST UNIT.
3731 013102 012737 000001 001426     MOV    #1,ROTATE          ;:POINT TO IT.
3732
3733                                     .SBTTL  END OF PASS ROUTINE
3734
3735                                     ;:*****  
3736                                     ;:INCREMENT THE PASS NUMBER ($PASS)
3737

```

```

3738                                     ;*IF THERES A MONITOR GO TO IT
3739                                     ;*IF THERE ISN'T JUMP TO LOOP
3740
3741 013110                               SEOP:
3742 013110 000240                       NOP
3743 013112 005037 001102                 CLR      $STNM           ;; ZERO THE TEST NUMBER
3744 013116 005037 001160                 CLR      $TIMES        ;; ZERO THE NUMBER OF ITERATIONS
3745 013122 005237 001202                 INC      $PASS         ;; INCREMENT THE PASS NUMBER
3746 013126 042737 100000 001202         BIC      #100000,$PASS ;; DON'T ALLOW A NEG. NUMBER
3747 013134 005327                       DEC      (PC)+          ;; LOOP?
3748 013136 000001                       SEOPCT: .WORD          1
3749 013140 003064                       BGT      $DOAGN        ;; YES
3750 013142 012737                       MOV      (PC)+,2(PC)+ ;; RESTORE COUNTER
3751 013144 000001                       SENDCT: .WORD          1
3752 013146 013136                       SEOPCT
3753 013150 104400 013156                 TYPE     65$           ;; TYPE ASCIZ STRING
3754 013154 000406                       BR       64$           ;; GET OVER THE ASCIZ
3755                                     ;;65$: .ASCIZ <15><12>#ENDPASS #
3756 013172                               64$:
3757 013172 013746 001202                 MOV      $PASS,-(SP)   ;; SAVE $PASS FOR TYPEOUT
3758 013176 104401                       TYPOC    ;; GO TYPE--OCTAL ASCII(ALL DIGITS)
3759 013200 104400 013206                 TYPE     67$           ;; TYPE ASCIZ STRING
3760 013204 000411                       BR       66$           ;; GET OVER THE ASCIZ
3761                                     ;;67$: .ASCIZ # TOTAL ERRORS #
3762                               66$:
3763 013230 013746 001432                 MOV      ERCNT,-(SP)   ;; SAVE ERCNT FOR TYPEOUT
3764 013234 104401                       TYPOC    ;; GO TYPE--OCTAL ASCII(ALL DIGITS)
3765 013236 104400 013244                 TYPE     69$           ;; TYPE ASCIZ STRING
3766 013242 000410                       BR       68$           ;; GET OVER THE ASCIZ
3767                                     ;;69$: .ASCIZ # GOOD UNITS #
3768                               68$:
3769 013264 013746 001430                 MOV      UTEST,-(SP)  ;; SAVE UTEST FOR TYPEOUT
3770 013270 104404                       TYPBN    ;; GO TYPE--BINARY ASCII
3771 013272 013700 000042                 $GET42: MOV      2#42,R0 ;; GET MONITOR ADDRESS
3772 013276 001405                       BEQ      $DOAGN        ;; BRANCH IF NO MONITOR
3773 013300 000005                       RESET    ;; CLEAR THE WORLD
3774 013302 004710                       SENDAD: JSR      PC,(R0) ;; GO TO MONITOR
3775 013304 000240                       NOP      ;; SAVE ROOM
3776 013306 000240                       NOP      ;; FOR
3777 013310 000240                       NOP      ;; ACT11
3778 013312
3779 013312 000137                       $DOAGN: JMP      2(PC)+      ;; RETURN
3780 013314 002260                       $RTNAD: .WORD      LOOP
3781 013316 377 377 000 $ENULL: .BYTE  -1,-1,0 ;; NULL CHARACTER STRING
3782 013322
3783
3784
3785
3786                                     .SBTTL
3787                                     ;; I/O SIGNAL TEST #1 ST1 IN AND ST2 OUT IN AND OUT
3788
3789
3790                                     ;; SWITCH PACK S2 MUST BE SET UP AS FOLLOWS:
3791
3792                                     SWITCH 1 - OFF
3793                                     2 - ON

```

3794  
3795  
3796  
3797  
3798  
3799  
3800  
3801  
3802  
3803  
3804  
3805  
3806  
3807  
3808  
3809  
3810  
3811  
3812  
3813  
3814  
3815  
3816  
3817  
3818  
3819  
3820  
3821  
3822  
3823  
3824  
3825  
3826  
3827  
3828  
3829  
3830  
3831  
3832  
3833  
3834  
3835  
3836  
3837  
3838  
3839  
3840  
3841  
3842  
3843  
3844  
3845  
3846  
3847  
3848  
3849

013322 104406  
013324 005077 166046  
013330 005077 166044  
012334 012777 000061 166034  
013342 052777 001000 166026  
013350 012777 000005 166020  
013356 052777 001000 166012  
013364 027727 166010 000001  
013372 007753  
013374 104000  
013376 000751

IOTST1: CKSWR  
IS: CLR 2ASR  
CLR 2ABR  
MOV #61,2ASR  
BIS #819,2ASR  
MOV #5,2ASR  
BIS #819,2ASR  
CMP 2ABR,#1  
BEQ IOTST1  
ERROR  
BR IOTST1

3 - OFF  
4 - OFF  
5 - ON  
6 - ON  
7 - NOT USED

THIS SELECTS TTL THRESHOLDS AND POSITIVE SLOPE FOR SCHMITT TRIGGER 1.

PLEASE REMOVE ANY PREVIOUS JUMPER.

JUMPER THE FOLLOWING PINS TOGETHER:  
J1 - SS (ST2 OUT) TO J1 - VW (ST1-IN)

LOAD AND START AT LOCATION 210  
END PASSES OCCUR IMMEDIATELY AND ARE NOT REPORTED  
ERRORS ARE REPORTED AS IN THE REGULAR LOGIC TEST AND THEIR PRINTOUT MAY BE INHIBITED

CHECK THE SWR  
CLEAR THE CSR  
CLEAR THE BUFFER REG.  
RATE ST1, MODE 0, GO.  
GENERATE A MAINTENANCE ST2.  
NOW SET TO READ COUNT REG  
FORCE COUNT -> BUFFER REG.  
DID COUNT REG ADVANCE ONCE?  
YES - LOOP.  
ST2 OUT TO ST1 IN FAILED.

.SBTTL :I/O SIGNAL TEST #2 CLOCK OVFLOW OUT TEST.

SWITCH PACK S2 MUST BE SET UP AS FOLLOWS:

SWITCH 1 - OFF  
2 - OFF  
3 - OFF  
4 - ON  
5 - ON  
6 - OFF  
7 - NOT USED

THIS SELECTS TTL THRESHOLDS AND POSITIVE SLOPE FOR SCHMITT TRIGGER 2.

PLEASE REMOVE ANY PREVIOUS JUMPER.

JUMPER THE FOLLOWING PINS TOGETHER:  
J1 - RR (CLK OV) TO J1 - TT (ST2-IN)

3850  
3851  
3852  
3853  
3854  
3855  
3856  
3857  
3858  
3859  
3860  
3861  
3862  
3863  
3864  
3865  
3866  
3867  
3868  
3869  
3870  
3871  
3872  
3873  
3874  
3875  
3876  
3877  
3878  
3879  
3880  
3881  
3882  
3883  
3884  
3885  
3886  
3887  
3888  
3889  
3890  
3891  
3892  
3893  
3894  
3895  
3896  
3897  
3898  
3899  
3900  
3901  
3902  
3903  
3904  
3905

```
013400 104405
013402 005077 165770
013406 012777 177777 165764
013414 012777 000063 165754
013422 052777 000400 165746
013430 000240
013432 000240
013434 005777 165736
013440 100757
013442 104000
013444 000755

. . .

013446 104406
013450 012777 000001 165720
013456 052777 000400 165712
013464 005777 165706
013470 100401
013472 104000

013474 032777 010000 165674 1S:
013502 001761
013504 104000
013506 000757
```

```
IOTST2: CKSWR      ;CHECK THE SWR.
CLR        ;CLEAR THE CSR.
MOV        #-1, @ABR ;PRELOAD PRESET BUFFER.
MOV        @B3, @ASR ;RATE ST1, MODE 1, GO.
BIS        @BIT8, @ASR ;GENERATE A MAIN. ST1.
NOP
NOP
TST        @ASR      ;DID OVERFLOW SET ST2 FLAG?
BMI        IOTST2    ;YES - LOOP
ERROR      ;CLK OV OUT TO ST2 IN FAILED.
BR         IOTST2    ;LOOP

.SBTTL      ;

; I/O SIGNAL TEST #3 ST1 OUT AND ST2 IN

; SWITCH PACK S2 MUST BE SET UP AS FOLLOWS:
; SWITCH 1 - OFF
; SWITCH 2 - OFF
; SWITCH 3 - OFF
; SWITCH 4 - ON
; SWITCH 5 - ON
; SWITCH 6 - ON
; SWITCH 7 - NOT USED
; THIS SELECTS TTL THRESHOLD AND POSITIVE SLOPE FOR
; SCHMITT TRIGGER 2.
; PLEASE REMOVE ANY PREVIOUS JUMPERS.
; JUMPER THE FOLLOWING PINS TOGETHER:
; J1 - UU (ST1 OUT) TO J1 - TT (ST2-IN)

; LOAD AND START AT LOCATION 220
; END PASSES OCCUR IMMEDIATELY AND ARE NOT REPORTED
; ERRORS ARE REPORTED AS IN THE REGULAR LOGIC TEST AND
; THEIR PRINTOUT MAY BE INHIBITED

IOTST3: CKSWR      ;CHECK THE SWR
MOV        @B1, @ASR ;SET GO BIT.
BIS        @BIT8, @ASR ;GENERATE A MAIN. ST1.
TST        @ASR      ;DID ST2 FLAG SET?
BMI        IS
ERROR      ;ST1 OUT TO ST2 IN FAILED

IS:        BIT        @BIT12, @ASR ;DID "FOR" BIT SET?
BEQ        IOTST3    ;NO - GOOD!
ERROR      ;"FOR" BIT SET ON ONLY 1 ST2.
BR         IOTST3    ;LOOP

.SBTTL
```

.SBTTL

```

3906
3907
3908
3909
3910
3911
3912
3913
3914
3915
3916
3917
3918
3919
3920
3921
3922
3923
3924
3925
3926
3927
3928
3929
3930
3931
3932
3933
3934 013510 017646 000000
3935 013514 116637 000001 013733
3936 013522 112637 013735
3937 013526 062716 000002
3938 013532 000406
3939 013534 112737 000001 013733
3940 013542 112737 000006 013735
3941 013550 112737 000005 013732
3942 013556 010346
3943 013560 010446
3944 013562 010546
3945 013564 113704 013735
3946 013570 005404
3947 013572 062704 000006
3948 013576 110437 013734
3949 013602 113704 013733
3950 013606 016605 000012
3951 013612 005003
3952 013614 006105 1S:
3953 013616 000404 2S:
3954 0 320 006105
3955 013622 006105
3956 013624 006105
3957 013626 010503
3958 013630 006103 3S:
3959 013632 105337 013734
3960 013636 100016
3961 013640 042703 177770

```

```

.SBTTL *SYSMAC ROUTINES
.SBTTL

.SBTTL BINARY TO OCTAL (ASCII) AND TYPE
*****
*THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 6-DIGIT
*OCTAL (ASCII) NUMBER AND TYPE IT.
*STYPOS---ENTER HERE TO SETUP SUPPRESS ZEROS AND NUMBER OF DIGITS TO TYPE
*CALL:
*   MOV     NUM,-(SP)      ;; NUMBER TO BE TYPED
*   TYPOS   ;; CALL FOR TYPEOUT
*   .BYTE  N               ;; N=1 TO 6 FOR NUMBER OF DIGITS TO TYPE
*   .BYTE  M               ;; M=1 OR 0
*                               ;; 1=TYPE LEADING ZEROS
*                               ;; 0=SUPPRESS LEADING ZEROS
*STYPON---ENTER HERE TO TYPE OUT WITH THE SAME PARAMETERS AS THE LAST
*STYPOS OR STYPOC
*CALL:
*   MOV     NUM,-(SP)      ;; NUMBER TO BE TYPED
*   TYPON   ;; CALL FOR TYPEOUT
*STYPOC---ENTER HERE FOR TYPEOUT OF A 16 BIT NUMBER
*CALL:
*   MOV     NUM,-(SP)      ;; NUMBER TO BE TYPED
*   TYPOC   ;; CALL FOR TYPEOUT
*STYPOS: MOV     2(SP),-(SP) ;; PICKUP THE MODE
*         MOV    1(SP),SOFILL ;; LOAD ZERO FILL SWITCH
*         MOV    (SP)+,SOMODE+1 ;; NUMBER OF DIGITS TO TYPE
*         ADD    #2,(SP)    ;; ADJUST RETURN ADDRESS
*         BR    STYPON
*STYPOC: MOV    #1,SOFILL   ;; SET THE ZERO FILL SWITCH
*         MOV    #6,SOMODE+1 ;; SET FOR SIX(6) DIGITS
*STYPON: MOV    #5,SOCNT    ;; SET THE ITERATION COUNT
*         MOV    R3,-(SP)   ;; SAVE R3
*         MOV    R4,-(SP)   ;; SAVE R4
*         MOV    R5,-(SP)   ;; SAVE R5
*         MOV    SOMODE+1,R4 ;; GET THE NUMBER OF DIGITS TO TYPE
*         NEG    R4
*         ADD    #6,R4     ;; SUBTRACT IT FOR MAX. ALLOWED
*         MOV    R4,SOMCDE  ;; SAVE IT FOR USE
*         MOV    SOFILL,R4  ;; GET THE ZERO FILL SWITCH
*         MOV    12(SP),R5  ;; PICKUP THE INPUT NUMBER
*         CLR    R3        ;; CLEAR THE OUTPUT WORD
*         ROL   R5        ;; ROTATE MSB INTO "C"
*         BR    3S        ;; GO DO MSB
*         ROL   R5        ;; FORM THIS DIGIT
*         ROL   R5
*         ROL   R5
*         MOV   R5,R3
*         ROL   R3        ;; GET LSB OF THIS DIGIT
*         DECB  SOMODE    ;; TYPE THIS DIGIT?
*         BPL  7S        ;; BR IF NO
*         BIC  #177770,R3 ;; GET RID OF JUNK

```

```

3962 013644 001002           BNE      4$
3963 013646 005704           TST     R4
3964 013650 001403           BEQ    5$
3965 013652 005204           4$: INC     R4
3966 013654 052703 000060         BIS     #'0,R3
3967 013660 052703 000040         5$: BIS     #' ,R3
3968 013664 110337 013730         MOVB   R3,B$
3969 013670 104400 013730         TYPE   B$
3970 013674 105337 013732         7$: DECB  $OCNT
3971 013700 003347           BGT    2$
3972 013702 002402           BLT    6$
3973 013704 005204           INC     R4
3974 013706 003744           BR     2$
3975 013710 012605           6$: MOV    (SP)+,R5
3976 013712 012604           MOV    (SP)+,R4
3977 013714 012603           MOV    (SP)+,R3
3978 013716 016666 000002 000004         MOV    2(SP),4(SP)
3979 013724 012616           MOV    (SP)+,(SP)
3980 013726 000002           RTI
3981 013730           8$: .BYTE 0
3982 013731           .BYTE 0
3983 013732           $OCNT: .BYTE 0
3984 013733           $OFILL: .BYTE 0
3985 013734 000000           $OMODE: .WORD 0
3986           .SBTTL BINARY TO ASCII AND TYPE ROUTINE
3987
3988           ;*****
3989           ;*THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 16-BIT
3990           ;*BINARY-ASCII NUMBER AND TYPE IT.
3991           ;*CALL:
3992           ;*   MOV     NUMBER,-(SP)   ;;NUMBER TO BE TYPED
3993           ;*   TYPBN
3994           ;*                               ;;TYPE IT
3995 013736 010146           $TYPBN: MOV    R1,-(SP)
3996 013740 016601 000006         MOV    6(SP),R1
3997 013744 000261           SEC
3998 013746 112737 000060 014010 1$: MOVB   #'0,$BIN
3999 013754 006101           ROL    R1
4000 013756 001406           BEQ    2$
4001 013760 105537 014010         ADCB   $BIN
4002 013764 104400 014010         TYPE   , $BIN
4003 013770 000241           CLC
4004 013772 000765           BR     1$
4005 013774 012601           2$: MOV    (SP)+,R1
4006 013776 016666 000002 000004         MOV    2(SP),4(SP)
4007 014004 012616           MOV    (SP)+,(SP)
4008 014006 000002           RTI
4009 014010           8$: .BYTE 0,0
4010
4011           .SBTTL ERROR HANDLER ROUTINE
4012
4013           ;*****
4014           ;*THIS ROUTINE WILL INCREMENT THE ERROR FLAG AND THE ERROR COUNT,
4015           ;*SAVE THE ERROR ITEM NUMBER AND THE ADDRESS OF THE ERROR CALL
4016           ;*AND GO TO $ERRTYP ON ERROR
4017

```



```

4018
4019
4020
4021
4022
4023
4024
4025
4026 014012
4027 014012 104406
4028 014014 105237 001103
4029 014020 001775
4030 014022 013777 001102 165112
4031 014030 032777 002000 165102
4032 014036 001402
4033 014040 104400 001164
4034 014044 005237 001112
4035 014050 011637 001116
4036 014054 162737 000002 001116
4037 014062 117737 165030 001114
4038 014070 032777 020000 165042
4039 014076 001004
4040 014100 004737 014220
4041 014104 104400 001171
4042 014110
4043 014110 122737 000001 001214
4044 014116 001007
4045 014120 113737 001114 014132
4046 014126 004737 015712
4047 014132 000
4048 014133 000
4049 014134 000777
4050 014136 005777 164776
4051 014142 100002
4052 014144 000000
4053 014146 104406
4054 014150 032777 001000 164762
4055 014156 001402
4056 014160 013716 001110
4057 014164 005737 001162
4058 014170 001402
4059 014172 013716 001162
4060 014176
4061
4062 014176 005237 001432
4063 014202 001002
4064 014204 005337 001432
4065 014210
4066 014210 043737 001426 001430
4067 014216 000002
4068
4069
4070
4071
4072
4073

; *THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
; *SW15=1 HALT ON ERROR
; *SW13=1 INHIBIT ERROR TYPEOUTS
; *SW10=1 BELL ON ERROR
; *SW09=1 LOOP ON ERROR
; *CALL
; * ERROR N ;;ERROR=EMT AND N=ERROR ITEM NUMBER

SERROR:
7S: CKSWR ;: TEST FOR CHANGE IN SOFT-SWR
INCB $ERFLG ;: SET THE ERROR FLAG
BEQ 7S ;: DON'T LET THE FLAG GO TO ZERO
MOV $STNM, $DISPLAY ;: DISPLAY TEST NUMBER AND ERROR FLAG
BIT #BIT10, $SWR ;: BELL ON ERROR?
BEQ 1S ;: NO - SKIP
TYPE $BELL ;: RING BELL
1S: INC $ERTTL ;: COUNT THE NUMBER OF ERRORS
MOV (SP), $ERRPC ;: GET ADDRESS OF ERROR INSTRUCTION
SUB #2, $ERRPC
MOVB $ERRPC, $ITEMB ;: STRIP AND SAVE THE ERROR ITEM CODE
BIT #BIT13, $SWR ;: SKIP TYPEOUT IF SET
BNE 20S ;: SKIP TYPEOUTS
JSR PC, $ERRTYP ;: GO TO USER ERROR ROUTINE
TYPE , $CRLF

20S: CMPB #APTENV, $ENV ;: RUNNING IN APT MODE
BNE 2S ;: NO SKIP APT ERROR REPORT
MOVB $ITEMB, 21S ;: SET ITEM NUMBER AS ERROR NUMBER
JSR PC, $ATY4 ;: REPORT FATAL ERROR TO APT

21S: .BYTE 0
.BYTE 0

22S: BR 22S ;: APT ERROR LOOP
2S: TST $SWR ;: HALT ON ERROR
BPL ;: SKIP IF CONTINUE
HALT ;: HALT ON ERROR!
CKSWR ;: TEST FOR CHANGE IN SOFT-SWR
3S: BIT #BIT09, $SWR ;: LOOP ON ERROR SWITCH SET?
BEQ 4S ;: BR IF NO
MOV $LPERR, (SP) ;: FUDGE RETURN FOR LOOPING
4S: TST $ESCAPE ;: CHECK FOR AN ESCAPE ADDRESS
BEQ 5S ;: BR IF NONE
MOV $ESCAPE, (SP) ;: FUDGE RETURN ADDRESS FOR ESCAPE

5S:
INC ERCNT ;: /UPDATE ERROR COUNT.
BNE 10S ;: /BUT DON'T LET IT OVERFLOW.
DEC ERCNT ;: /KEEP AT 177777 IF OVERFLOW.

10S: BIC ROTATE, UTEST ;: /REMOVE UNIT FROM LIST OF GOOD ONES.
RTI ;: /EXIT.

.SBTTL ERROR MESSAGE TYPEOUT ROUTINE

; *****
; *THIS ROUTINE USES THE "ITEM CONTROL BYTE" ($ITEMB) TO DETERMINE WHICH
; *ERROR IS TO BE REPORTED. IT THEN OBTAINS, FROM THE "ERROR TABLE" ($ERRTB),
    
```

```

4074
4075
4076 014220
4077 014220 104400 001171
4078 014224 010046
4079 014226 005000
4080 014230 153700 001114
4081 014234 001004
4082
4083 014236 013746 001116
4084
4085 014242 104401
4086 014244 000426
4087 014246 005300
4088 014250 006300
4089 014252 006300
4090 014254 006300
4091 014256 062700 001256
4092 014252 012037 014272
4093 014256 001404
4094 014270 104400
4095 014272 000400
4096 014274 104400 001171
4097 014300 012037 014310
4098 014304 001404
4099 014306 104400
4100 014310 000000
4101 014312 104400 001171
4102 014316 011000
4103 014320 001004
4104 014322 012600
4105 014324 104400 001171
4106 014330 000207
4107 014332
4108 014332 013046
4109 014334 104401
4110 014336 005710
4111 014340 001770
4112 014342 104400 014350
4113 014346 000771
4114 014350 020040 000
4115 014354

```

;\*AND REPORTS THE APPROPRIATE INFORMATION CONCERNING THE ERROR.

```

SERRTYP:
      TYPE      $CRLF      ;; "CARRIAGE RETURN" & "LINE FEED"
      MOV      RO,-(SP)    ;; SAVE RO
      CLR      RO          ;; PICKUP THE ITEM INDEX
      BISB     @($ITEMB,RO
      BNE      IS         ;; IF ITEM NUMBER IS ZERO, JUST
                          ;; TYPE THE PC OF THE ERROR
      MOV      $ERRPC,-(SP) ;; SAVE $ERRPC FOR TYPEOUT
                          ;; ERROR ADDRESS
      TYPCC    GO TYPE--OCTAL ASCII(ALL DIGITS)
      BR       6$         ;; GET OUT
1$:    DEC      RO          ;; ADJUST THE INDEX SO THAT IT WILL
      ASL      RO          ;; WORK FOR THE ERROR TABLE
      ASL      RO
      ASL      RO
      ADD      @($ERRTB,RO ;; FORM TABLE POINTER
      MOV      (RO)+,2$    ;; PICKUP "ERROR MESSAGE" POINTER
      BEQ      3$         ;; SKIP TYPEOUT IF NO POINTER
      TYPE     "ERROR MESSAGE" ;; TYPE THE "ERROR MESSAGE"
      WORD     0           ;; "ERROR MESSAGE" POINTER GOES HERE
      TYPE     $CRLF      ;; "CARRIAGE RETURN" & "LINE FEED"
3$:    MOV      (RO)+,4$    ;; PICKUP "DATA HEADER" POINTER
      BEQ      5$         ;; SKIP TYPEOUT IF 0
      TYPE     "DATA HEADER" ;; TYPE THE "DATA HEADER"
      WORD     0           ;; "DATA HEADER" POINTER GOES HERE
      TYPE     $CRLF      ;; "CARRIAGE RETURN" & "LINE FEED"
5$:    MOV      (RO),RO     ;; PICKUP "DATA TABLE" POINTER
      BNE      7$         ;; GO TYPE THE DATA
      MOV      (SP)+,RO     ;; RESTORE RO
      TYPE     $CRLF      ;; "CARRIAGE RETURN" & "LINE FEED"
      RTS      PC         ;; RETURN
7$:    MOV      @((RO)+,-(SP) ;; SAVE @((RO)+ FOR TYPEOUT
      TYPCC    GO TYPE--OCTAL ASCII(ALL DIGITS)
      TST      (RO)       ;; IS THERE ANOTHER NUMBER?
      BEQ      6$         ;; BR IF NO
      TYPE     2$         ;; TYPE TWO(2) SPACES
      BR       7$         ;; LOC
8$:    .ASCIZ  / /        ;; TWO(2) SPACES
      .EVEN

```

.SBTTL SCOPE HANDLER ROUTINE

```

4116
4117
4118
4119
4120
4121
4122
4123
4124
4125
4126
4127
4128
4129

```

```

*****
; THIS ROUTINE CONTROLS THE LOOPING OF SUBTESTS. IT WILL INCREMENT
; AND LOAD THE TEST NUMBER($TSTNM) INTO THE DISPLAY REGISTER.(DISPLAY<7:0>)
; AND LOAD THE ERROR FLAG ($ERFLG) INTO DISPLAY<15:08>
; THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
; $SW14=1 LOOP ON TEST
; $SW11=1 INHIBIT ITERATIONS
; $SW09=1 LOOP ON ERROR
; $SW08=1 LOOP ON TEST IN SWR<7:0>
; CALL
; * SCOPE ;; SCOPE=IOT

```

```

4130 014354
4131 014354 104406
4132 014356 104406
4133 014360 032777 040000 164552
4134 014366 001114
4135
4136 014370 000416
4137
4138 014372 013746 000004
4139 014376 012737 014416 000004
4140 014404 005737 177060
4141 014410 012637 000004
4142 014414 000463
4143 014416 022626
4144 014420 012637 000004
4145 014424 000423
4146 014426
4147 014426 032777 000400 164504
4148 014434 001404
4149 014436 127737 164476 001102
4150 014444 001465
4151 014446 105737 001103
4152 014452 001421
4153 014454 123737 001115 001103
4154 014462 101015
4155 014464 032777 001000 164446
4156 014472 001404
4157 014474 013737 001110 001106
4158 014502 000446
4159 014504 105037 001103
4160 014510 005037 001160
4161 014514 000415
4162 014516 032777 004000 164414
4163 014524 001011
4164 014526 005737 001202
4165 014532 001406
4166 014534 005237 001104
4167 014540 023737 001160 001104
4168 014546 002024
4169 014550 012737 000001 001104
4170 014556 013737 014634 001160
4171 014564 105237 001102
4172 014570 113737 001102 001200
4173 014576 011637 001106
4174 014602 011637 001110
4175 014606 005037 001162
4176 014612 112737 000001 001115
4177 014620 013777 001102 164314
4178 014626 013716 001106
4179 014632 000002
4180 014634 003720
4181
4182
4183
4184
4185

```

```

$SCOPE:
      CKSWR
      CKSWR
1$: BIT #BIT14,2SWR
      BNE $OVER
:*****START OF CODE FOR THE XOR TESTER*****
$XTSTR: BR 6$
      MOV 2#ERRVEC, -(SP)
      MOV 2$,$2#ERRVEC
      TST 2#177060
      MOV (SP)+,2#ERRVEC
      BR 5$VLAD
5$: CMP (SP)+,(SP)+
      MOV (SP)+,2#ERRVEC
      BR 7$
6$:;*****END OF CODE FOR THE XOR TESTER*****
      BIT #BIT08,2SWR
      BEQ 2$
      CMPB 2SWR,$STSTNM
      BEQ $OVER
2$: TSTB $ERFLG
      BEQ 3$
      CMPB $ERMAX,$ERFLG
      BHI 3$
      BIT #BIT09,2SWR
      BEQ 4$
7$: MOV $LPERR,$LPADR
      BR $OVER
4$: CLRB $ERFLG
      CLR $TIMES
      BR 1$
3$: BIT #BIT11,2SWR
      BNE 1$
      TST $PASS
      BEQ 1$
      INC $ICNT
      CMP $TIMES,$ICNT
      BGE $OVER
1$: MOV #1,$ICNT
      MOV $MXCNT,$TIMES
$SVLAD: INCB $STSTNM
      MOVB $STSTNM,$STSTNM
      MOV (SP),$LPADR
      MOV (SP),$LPERR
      CLR $ESCAPE
      MOVB #1,$ERMAX
$OVER: MOV $STSTNM,$DISPLAY
      MOV $LPADR,(SP)
      RTI
$MXCNT: 2000.
.SBTTL TTY INPUT ROUTINE
:*****
:ENABL LSB

```

```

;;TEST FOR CHANGE IN SOFT-SWR
;;LOOP ON PRESENT TEST?
;;YES IF SW14=1
TESTER*****
;;IF RUNNING ON THE "XOR" TESTER CHANGE
THIS INSTRUCTION TO A "NOP" (NOP=240)
SAVE THE CONTENTS OF THE ERROR VECTOR
SET FOR TIMEOUT
TIME OUT ON XOR?
RESTORE THE ERROR VECTOR
GO TO THE NEXT TEST
CLEAR THE STACK AFTER A TIME OUT
RESTORE THE ERROR VECTOR
LOOP ON THE PRESENT TEST
TESTER*****
;;LOOP ON SPEC. TEST?
BR IF NO
ON THE RIGHT TEST? SWR<7:0>
BR IF YES
HAS AN ERROR OCCURRED?
BR IF NO
MAX. ERRORS FOR THIS TEST OCCURRED?
BR IF NO
LOOP ON ERROR?
BR IF NO
SET LOOP ADDRESS TO LAST SCOPE
ZERO THE ERROR FLAG
CLEAR THE NUMBER OF ITERATIONS TO MAKE
ESCAPE TO THE NEXT TEST
INHIBIT ITERATIONS?
BR IF YES
IF FIRST PASS OF PROGRAM
INHIBIT ITERATIONS
INCREMENT ITERATION COUNT
CHECK THE NUMBER OF ITERATIONS MADE
BR IF MORE ITERATION REQUIRED
REINITIALIZE THE ITERATION COUNTER
SET NUMBER OF ITERATIONS TO DO
COUNT TEST NUMBERS
SET TEST NUMBER IN APT MAILBOX
SAVE SCOPE LOOP ADDRESS
SAVE ERROR LOOP ADDRESS
CLEAR THE ESCAPE FROM ERPR ADDRESS
ONLY ALLOW ONE(1) ERROR ON NEXT TEST
DISPLAY TEST NUMBER
FUDGE RETURN ADDRESS
FIXES PS
MAX. NUMBER OF ITERATIONS

```

```

4186
4187
4188
4189
4190
4191 014636 022737 000176 001140 $CKSWR: CMP      #SWREG,SWR      ;; IS THE SOFT-SWR SELECTED?
4192 014644 001074          BNE      15$      ;; BRANCH IF NO
4193 014646 105777 164272          TSTB     2$TKS    ;; CHAR THERE?
4194 014652 100071          BPL      15$      ;; IF NO, DON'T WAIT AROUND
4195 014654 117746 164266          MOVB     2$TKB,-(SP) ;; SAVE THE CHAR
4196 014660 042716 177600          BIC      #1C177,(SP) ;; STRIP-OFF THE ASCII
4197 014664 022726 000007          CMP      #7,(SP)+  ;; IS IT A CONTROL G?
4198 014670 001062          BNE      15$      ;; NO, RETURN TO USER
4199 014672 123727 001134 000001          CMPB     $AUTOB,#1 ;; ARE WE RUNNING IN AUTO-MODE?
4200 014700 001456          BEQ      15$      ;; BRANCH IF YES
4201
4202 014702 104400 015363          TYPE     , $CNTLG  ;; ECHO THE CONTROL-G (↑G)
4203 014706 104400 015370          SGT$WR: TYPE     , $MSWR  ;; TYPE CURRENT CONTENTS
4204 014712 013746 000176          MOV      SWREG,-(SP) ;; SAVE SWREG FOR TYPEOUT
4205 014716 104401          TYPOC   ;; GO TYPE--OCTAL ASCII(ALL DIGITS)
4206 014720 104400 015401          TYPE     , $MNEW  ;; PROMPT FOR NEW SWR
4207 014724 005046          19$: CLR      -(SP)  ;; CLEAR COUNTER
4208 014726 005046          CLR      -(SP)  ;; THE NEW SWR
4209 014730 105777 164210          7$: TSTB     2$TKS  ;; CHAR THERE?
4210 014734 100375          BPL      7$      ;; IF NOT TRY AGAIN
4211
4212 014736 117746 164204          MOVB     2$TKB,-(SP) ;; PICK UP CHAR
4213 014742 042716 177600          BIC      #1C177,(SP) ;; MAKE IT 7-BIT ASCII
4214
4215
4216
4217 014746 021627 000025          9$: CMP      (SP),#25  ;; IS IT A CONTROL-U?
4218 014752 001005          BNE      10$     ;; BRANCH IF NOT
4219 014754 104400 015356          TYPE     , $CNTLU  ;; YES, ECHO CONTROL-U (↑U)
4220 014760 062706 000006          20$: ADD     #6,SP  ;; IGNORE PREVIOUS INPUT
4221 014764 000757          BR       19$     ;; LET'S TRY IT AGAIN
4222
4223
4224 014766 021627 000015          10$: CMP     (SP),#15  ;; IS IT A <CR>?
4225 014772 001022          BNE      16$     ;; BRANCH IF NO
4226 014774 005766 000004          TST      4(SP)   ;; YES, IS IT THE FIRST CHAR?
4227 015000 001403          BEQ      11$     ;; BRANCH IF YES
4228 015002 016677 000002 164130          MOV      2(SP),2$SWR ;; SAVE NEW SWR
4229 015010 062706 000006          11$: ADD     #6,SP  ;; CLEAR UP STACK
4230 015014 104400 001171          14$: TYPE     , $CRLF  ;; ECHO <CR> AND <LF>
4231 015020 123727 001135 000001          CMPB     $INTAG,#1 ;; RE-ENABLE TTY KBD INTERRUPTS?
4232 015026 001003          BNE      15$     ;; BRANCH IF NOT
4233 015030 012777 000100 164106          MOV      #100,2$TKS ;; RE-ENABLE TTY KBD INTERRUPTS
4234 015036 000002          15$: RTI      ;; RETURN
4235 015040 004737 015624          16$: JSR     PC,$TYPEC ;; ECHO CHAR
4236 015044 021627 000060          CMP      (SP),#60 ;; CHAR < 0?
4237 015050 002420          BLT      18$     ;; BRANCH IF YES
4238 015052 021627 000067          CMP      (SP),#67 ;; CHAR > 7?
4239 015056 003015          BGT      18$     ;; BRANCH IF YES
4240 015060 042726 000060          BIC      #60,(SP)+ ;; STRIP-OFF ASCII
4241 015064 005766 000002          TST      2(SP)   ;; IS THIS THE FIRST CHAR

```

```

4242 015070 001403          BEQ      17$          ;; BRANCH IF YES
4243 015072 006316          ASL      (SP)        ;; NO, SHIFT PRESENT
4244 015074 006316          ASL      (SP)        ;; CHAR OVER TO MAKE
4245 015076 006316          ASL      (SP)        ;; ROOM FOR NEW ONE.
4246 015100 005266 000002    17$: INC      2(SP)    ;; KEEP COUNT OF CHAR
4247 015104 056616 177776    BIS      -2(SP), (SP) ;; SET IN NEW CHAR
4248 015110 000707          BR       7$          ;; GET THE NEXT ONE
4249 015112 104400 001170    18$: TYPE   $QUES    ;; TYPE ?(CR)(LF)
4250 015116 000720          BR       20$        ;; SIMULATE CONTROL-U
4251
4252
4253
4254
4255
4256
4257
4258
4259
4260
4261
4262 015120 011646          $RDCHR: MOV      (SP), -(SP) ;; PUSH DOWN THE PC
4263 015122 016666 000004 000002  MOV      4(SP), 2(SP) ;; SAVE THE PS
4264 015130 105777 164010    1$: TSTB   2$TKS    ;; WAIT FOR
4265 015134 100375          BPL      1$          ;; A CHARACTER
4266 015136 117766 164004 000004  MOVB     2$TKB, 4(SP) ;; READ THE TTY
4267 015144 042766 177600 000004  BIC      #1C(177), 4(SP) ;; GET RID OF JUNK IF ANY
4268 015152 026627 000004 000023  CMP      4(SP), #23  ;; IS IT A CONTROL-S?
4269 015160 001013          BNE      3$          ;; BRANCH IF NO
4270 015162 105777 163756    2$: TSTB   2$TKS    ;; WAIT FOR A CHARACTER
4271 015166 100375          BPL      2$          ;; LOOP UNTIL ITS THERE
4272 015170 117746 163752    MOVB     2$TKB, -(SP) ;; GET CHARACTER
4273 015174 042716 177600    BIC      #1C177, (SP) ;; MAKE IT 7-BIT ASCII
4274 015200 022627 000021    CMP      (SP)+, #21  ;; IS IT A CONTROL-Q?
4275 015204 001366          BNE      2$          ;; IF NOT DISCARD IT
4276 015206 000750          BR       1$          ;; YES, RESUME
4277 015210 026627 000004 000140  3$: CMP      4(SP), #140 ;; IS IT UPPER CASE?
4278 015216 002407          BLT      4$          ;; BRANCH IF YES
4279 015220 026627 000004 000175  CMP      4(SP), #175 ;; IS IT A SPECIAL CHAR?
4280 015226 003003          BGT      4$          ;; BRANCH IF YES
4281 015230 042766 000040 000004  BIC      #40, 4(SP)  ;; MAKE IT UPPER CASE
4282 015236 000002          RTI          ;; GO BACK TO USER
4283
4284
4285
4286
4287
4288
4289
4290 015240 010346          $RDLIN: MOV      R3, -(SP) ;; SAVE R3
4291 015242 012703 015346    1$: MOV      #1TYIN, R3 ;; GET ADDRESS
4292 015246 022703 015356    2$: CMP      #1TYIN+8, R3 ;; BUFFER FULL?
4293 015252 101405          BLOS     4$          ;; BR IF YES
4294 015254 104407          RDCHR    ;; GO READ ONE CHARACTER FROM THE TTY
4295 015256 112613          MOVB     (SP)+, (R3) ;; GET CHARACTER
4296 015260 122713 000177    10$: CMPB   #177, (R3) ;; IS IT A RUBOUT
4297 015264 001003          BNE      3$          ;; SKIP IF NOT

```

\*\*\*\*\*  
THIS ROUTINE WILL INPUT A SINGLE CHARACTER FROM THE TTY

\*CALL:  
\* RDCHR INPUT A SINGLE CHARACTER FROM THE TTY  
\* RETURN HERE CHARACTER IS ON THE STACK  
\* WITH PARITY BIT STRIPPED OFF

\*\*\*\*\*  
THIS ROUTINE WILL INPUT A STRING FROM THE TTY

\*CALL:  
\* RDLIN INPUT A STRING FROM THE TTY  
\* RETURN HERE ADDRESS OF FIRST CHARACTER WILL BE ON THE STACK  
\* TERMINATOR WILL BE A BYTE OF ALL 0'S

```

4298 015266 104400 001170 45: TYPE $QUES ;; TYPE A '?'
4299 015272 000763 BR 15 ;; CLEAR THE BUFFER AND LOOP
4300 015274 111337 015344 35: MOVB (R3),95 ;; ECHO THE CHARACTER
4301 015300 104400 015344 TYPE 95
4302 015304 122723 000015 CMPB 15,(R3)+ ;; CHECK FOR RETURN
4303 015310 001356 BNE 25 ;; LOOP IF NOT RETURN
4304 015312 105063 177777 CLRB -1(R3) ;; CLEAR RETURN (THE 15)
4305 015316 104400 001172 TYPE $LF ;; TYPE A LINE FEED
4306 015322 012603 MOV (SP)+,R3 ;; RESTORE R3
4307 015324 011646 MOV (SP)-,(SP) ;; ADJUST THE STACK AND PUT ADDRESS OF THE
4308 015326 016666 000004 000002 MOV 4(SP),2(SP) ;; FIRST ASCII CHARACTER ON IT
4309 015334 012766 015346 000004 MOV $TTYIN,4(SP)
4310 015342 000002 RTI ;; RETURN
4311 015344 000 95: .BYTE 0 ;; STORAGE FOR ASCII CHAR. TO TYPE
4312 015345 000 .BYTE 0 ;; TERMINATOR
4313 015346 000010 $TTYIN: .BLKB 8. ;; RESERVE 8 BYTES FOR TTY INPUT
4314 015356 052536 005015 000 $CNTLU: .ASCIZ /↑U/<15><12> ;; CONTROL "U"
4315 015363 136 006507 000012 $CNTLG: .ASCIZ /↑G/<15><12> ;; CONTROL "G"
4316 015370 005015 053523 020122 $MSWR: .ASCIZ <15><12>/SWR = /
4317 015376 020075 000
4318 015401 040 047040 053505 $MNEW: .ASCIZ / NEW = /
4319 015406 036440 000040
4320 .SBTTL TYPE ROUTINE
4321
4322 *****
4323 *ROUTINE TO TYPE ASCIZ MESSAGE. MESSAGE MUST TERMINATE WITH A 0 BYTE.
4324 *THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED.
4325 *NOTE1: $NULL CONTAINS THE CHARACTER TO BE USED AS THE FILLER CHARACTER.
4326 *NOTE2: $FILLS CONTAINS THE NUMBER OF FILLER CHARACTERS REQUIRED.
4327 *NOTE3: $FILLC CONTAINS THE CHARACTER TO FILL AFTER.
4328 *
4329 *CALL:
4330 *1) USING A TRAP INSTRUCTION
4331 * TYPE ,MESADR ;; MESADR IS FIRST ADDRESS OF AN ASCIZ STRING
4332 *OR
4333 * TYPE
4334 * MESADR
4335 *
4336
4337 015412 105737 001157 $TYPE: TSTB $TPFLG ;; IS THERE A TERMINAL?
4338 015416 100002 BPL 15 ;; BR IF YES
4339 015420 000000 HALT ;; HALT HERE IF NO TERMINAL
4340 015422 000430 BR 35 ;; LEAVE
4341 015424 010046 15: MOV RO,-(SP) ;; SAVE RO
4342 015426 017600 000002 MOV 22(SP),RO ;; GET ADDRESS OF ASCIZ STRING
4343 015432 122737 000001 001214 CMPB $APTENV,$ENV ;; RUNNING IN APT MODE
4344 015440 001011 BNE 625 ;; NO GO CHECK FOR APT CONSOLE
4345 015442 132737 000100 001215 BITB $APTSPOOL,$ENVM ;; SPOOL MESSAGE TO APT
4346 015450 001405 BEQ 625 ;; NO GO CHECK FOR CONSOLE
4347 015452 010037 015462 MOV RO,615 ;; SETUP MESSAGE ADDRESS FOR APT
4348 015456 004737 015702 JSR PC,$ATY3 ;; SPOOL MESSAGE TO APT
4349 015462 000000 615: .WORD 0 ;; MESSAGE ADDRESS
4350 015464 132737 000040 001215 625: BITB $APTCSUP,$ENVM ;; APT CONSOLE SUPPRESSED
4351 015472 001013 BNE 605 ;; YES, SKIP TYPE OUT
4352 015474 112046 25: MOVB (RO)+,-(SP) ;; PUSH CHARACTER TO BE TYPED ONTO STACK
4353 015476 001005 BNE 45 ;; BR IF IT ISN'T THE TERMINATOR

```

```

4354 015500 005726          TST      (SP)+          ;; IF TERMINATOR POP IT OFF THE STACK
4355 015502 012600          60S:   MOV      (SP)+,R0      ;; RESTORE R0
4356 015504 062716 000002   3S:    ADD      #2,(SP)      ;; ADJUST RETURN PC
4357 015510 000002          RTI                      ;; RETURN
4358 015512 122716 000011   4S:    CMPB     #HT,(SF)      ;; BRANCH IF <HT>
4359 015516 001430          BEQ      B$              ;;
4360 015520 122716 000200          CMPB     #CRLF,(SP)      ;; BRANCH IF NOT <CRLF>
4361 015524 001006          BNE      B$              ;;
4362 015526 005726          TST      (SP)+          ;; POP <CR><LF> EQUIV
4363 015530 104400          TYPE                     ;; TYPE A CR AND LF
4364 015532 001171          SCRLF                     ;;
4365 015534 105037 015670          CLRB     $CHARCNT        ;; CLEAR CHARACTER COUNT
4366 015540 000755          BR                      ;; GET NEXT CHARACTER
4367 015542 004737 015624   5S:    JSR      PC,$TYPEC      ;; GO TYPE THIS CHARACTER
4368 015546 123726 001156   6S:    CMPB     $FILLC,(SP)+  ;; IS IT TIME FOR FILLER CHARS.?
4369 015552 001350          BNE      B$              ;; IF NO GO GET NEXT CHAR.
4370 015554 013746 001154          MOV      $NULL,-(SP)     ;; GET # OF FILLER CHARS. NEEDED
4371                                AND THE NULL CHAR.
4372 015560 105366 000001   7S:    DECB     1(SP)        ;; DOES A NULL NEED TO BE TYPED?
4373 015564 002770          BLT      B$              ;; BR IF NO--GO POP THE NULL OFF OF STACK
4374 015566 004737 015624          JSR      PC,$TYPEC      ;; GO TYPE A NULL
4375 015572 105337 015670          DECB     $CHARCNT        ;; DO NOT COUNT AS A COUNT
4376 015576 000770          BR                      ;; LOOP
    
```

;HORIZONTAL TAB PROCESSOR

```

4377
4378
4379
4380 015600 112716 000040   8S:    MOVB     #' (SP)      ;; REPLACE TAB WITH SPACE
4381 015604 004737 015624   9S:    JSR      PC,$TYPEC      ;; TYPE A SPACE
4382 015610 132737 000007 015670          BITB     #7,$CHARCNT    ;; BRANCH IF NOT AT
4383 015616 001372          BNE      9S              ;; TAB STOP
4384 015620 005726          TST      (SP)+          ;; POP SPACE OFF STACK
4385 015622 000724          BR                      ;; GET NEXT CHARACTER
4386 015624 105777 163320          STYPEC: TSTB     #STPB    ;; WAIT UNTIL PRINTER IS READY
4387 015630 100375          BPL      STYPEC          ;;
4388 015632 116677 000002 163312          MOVB     2(SP),#STPB    ;; LOAD CHAR TO BE TYPED INTO DATA REG.
4389 015640 122766 000015 000002          CMPB     #CR,2(SP)      ;; IS CHARACTER A CARRIAGE RETURN?
4390 015646 001003          BNE      B$              ;; BRANCH IF NO
4391 015650 105037 015670          CLRB     $CHARCNT        ;; YES--CLEAR CHARACTER COUNT
4392 015654 000406          BR                      ;; EXIT
4393 015656 122766 000012 000002   1S:    CMPB     #LF,2(SP)      ;; IS CHARACTER A LINE FEED?
4394 015664 001402          BEQ      STYPEX          ;; BRANCH IF YES
4395 015666 105227          INCB     (PC)+          ;; COUNT THE CHARACTER
4396 015670 000000          $CHARCNT: .WORD 0      ;; CHARACTER COUNT STORAGE
4397 015672 000207          STYPEX: RTS             PC
    
```

.SBTTL APT COMMUNICATIONS ROUTINE

```

4398
4399
4400
4401 *****
4402 015674 112737 000001 016140 $ATY1: MOVB     #1,$FFLG      ;; TO REPORT FATAL ERROR
4403 015702 112737 000001 016136 $ATY3: MOVB     #1,$MFLG      ;; TO TYPE A MESSAGE
4404 015710 000403          BR                      ;;
4405 015712 112737 000001 016140 $ATY4: MOVB     #1,$FFLG      ;; TO ONLY REPORT FATAL ERROR
4406 015720          $ATYC:
4407 015720 010046          MOV      R0,-(SP)        ;; PUSH R0 ON STACK
4408 015722 010146          MOV      R1,-(SP)        ;; PUSH R1 ON STACK
4409 015724 105737 016136          TSTB     $MFLG          ;; SHOULD TYPE A MESSAGE?
    
```

```

4410 015730 001450      BEQ      55      ;; IF NOT: BR
4411 015732 122737 000001 001214    CMPB    #APTENV,SENV ;; OPERATING UNDER APT?
4412 015740 001031      BNE     35      ;; IF NOT: BR
4413 015742 132737 000100 001215    BITB    #APTPOOL,SENVM ;; SHOULD SPOOL MESSAGES?
4414 015750 001425      BEQ     35      ;; IF NOT: BR
4415 015752 017600 000004      MOV     24(SP),R0 ;; GET MESSAGE ADDR.
4416 015756 062766 000002 000004      ADD     #2,4(SP)  ;; BUMP RETURN ADDR.
4417 015764 005737 001174      TST    $MSGTYPE ;; SEE IF DONE W/ LAST XMISSION?
4418 015770 001375      BNE     15      ;; IF NOT: WAIT
4419 015772 012037 001210      MOV     R0,$MSGAD ;; PUT ADDR IN MAILBOX
4420 015776 105720      TSTB   (R0)+    ;; FIND END OF MESSAGE
4421 016000 001376      BNE     25      ;;
4422 016002 163700 001210      SUB     $MSGAD,R0 ;; SUB START OF MESSAGE
4423 016006 006200      ASR     R0      ;; GET MESSAGE LGTH IN WORDS
4424 016010 010037 001212      MOV     R0,$MSGLGT ;; PUT LENGTH IN MAILBOX
4425 016014 012737 000004 001174      MOV     #4,$MSGTYPE ;; TELL APT TO TAKE MSG.
4426 016022 000413      BR     55      ;;
4427 016024 017637 000004 016050 35:      MOV     24(SP),45 ;; PUT MSG ADDR IN JSR LINKAGE
4428 016032 062766 000002 000004      ADD     #2,4(SP)  ;; BUMP RETURN ADDRESS
4429 016040 013746 177776      MOV     177776-(SP) ;; PUSH 177776 ON STACK
4430 016044 004737 015412      JSR    PC,$TYPE  ;; CALL TYPE MACRO
4431 016050 000000      .WORD  0
4432 016052      55:
4433 016052 105737 016140 105:      TSTB   $FFLG    ;; SHOULD REPORT FATAL ERROR?
4434 016056 001416      BEQ     125     ;; IF NOT: BR
4435 016060 005737 001214      TST    $SENV    ;; RUNNING UNDER APT?
4436 016064 001413      BEQ     125     ;; IF NOT: BR
4437 016066 005737 001174 115:      TST    $MSGTYPE ;; FINISHED LAST MESSAGE?
4438 016072 001375      BNE     115     ;; IF NOT: WAIT
4439 016074 017637 000004 001176      MOV     24(SP),$FATAL ;; GET ERROR #
4440 016102 062766 000002 000004      ADD     #2,4(SP)  ;; BUMP RETURN ADDR.
4441 016110 005237 001174      INC     $MSGTYPE ;; TELL APT TO TAKE ERROR
4442 016114 105037 016140 125:      CLRB   $FFLG    ;; CLEAR FATAL FLAG
4443 016120 105037 016137      CLRB   $LFLG    ;; CLEAR LOG FLAG
4444 016124 105037 016136      CLRB   $MFLG    ;; CLEAR MESSAGE FLAG
4445 016130 012601      MOV     (SP)+,R1 ;; POP STACK INTO R1
4446 016132 012600      MOV     (SP)+,R0 ;; POP STACK INTO R0
4447 016134 000207      RTS    PC      ;; RETURN
4448 016136      000      $MFLG: .BYTE 0 ;; MESSG. FLAG
4449 016137      000      $LFLG: .BYTE 0 ;; LOG FLAG
4450 016140      000      $FFLG: .BYTE 0 ;; FATAL FLAG
4451      016142      .EVEN
4452      000200      APTSIZE=200
4453      000001      APTENV=001
4454      000100      APTPOOL=100
4455      000040      APTCSUP=040
4456      .SBTTL POWER DOWN AND JP ROUTINES
4457
4458      ;*****
4459      ;POWER DOWN ROUTINE
4460 016142 012737 016302 000024 $PWDRN: MOV     #SILLUP,#PWVVEC ;; SET FOR FAST UP
4461 016150 012737 000340 000026      MOV     #340,#PWVVEC+2 ;; PRIO:7
4462 016156 010046      MOV     R0,-(SP) ;; PUSH R0 ON STACK
4463 016160 010146      MOV     R1,-(SP) ;; PUSH R1 ON STACK
4464 016162 010246      MOV     R2,-(SP) ;; PUSH R2 ON STACK
4465 016164 010346      MOV     R3,-(SP) ;; PUSH R3 ON STACK

```



```

4466 016166 010446      MOV      R4,-(SP)      ;; PUSH R4 ON STACK
4467 016170 010546      MOV      R5,-(SP)      ;; PUSH R5 ON STACK
4468 016172 017746 162742  MOV      @SWR,-(SP)    ;; PUSH @SWR ON STACK
4469 016176 010637 016306  MOV      SP,$$SAVR6    ;; SAVE SP
4470 016202 012737 016214 000024  MOV      @SPWRUP,@@PWVVEC ;; SET UP VECTOR
4471 016210 000000      HALT
4472 016212 000776      BR      -2            ;; HANG UP
4473
4474
4475
4476 016214 012737 016302 000024  $PWUP: MOV      @SILLUP,@@PWVVEC ;; SET FOR FAST DOWN
4477 016222 013706 016306      MOV      $$SAVR6,SP    ;; GET SP
4478 016226 005037 016306      CLR      $$SAVR6       ;; WAIT LOOP FOR THE TTY
4479 016232 005237 016306 1$: INC      $$SAVR6     ;; WAIT FOR THE INC
4480 016236 001375      BNE     1$            ;; OF WORD
4481 016240 012677 162674      MOV      (SP)+,@SWR    ;; POP STACK INTO @SWR
4482 016244 012605      MOV      (SP)+,R5     ;; POP STACK INTO R5
4483 016246 012604      MOV      (SP)+,R4     ;; POP STACK INTO R4
4484 016250 012603      MOV      (SP)+,R3     ;; POP STACK INTO R3
4485 016252 012602      MOV      (SP)+,R2     ;; POP STACK INTO R2
4486 016254 012601      MOV      (SP)+,R1     ;; POP STACK INTO R1
4487 016256 012600      MOV      (SP)+,R0     ;; POP STACK INTO R0
4488 016260 012737 016142 000024  MOV      @SPWRDN,@@PWVVEC ;; SET UP THE POWER DOWN VECTOR
4489 016266 012737 000340 000026  MOV      @340,@@PWVVEC+2 ;; @RIO:7
4490 016274 104400      TYPE
4491 016276 016310  $PWMSG: .WORD    $POWER    ;; REPORT THE POWER FAILURE
4492 016300 000002      RTI                    ;; POWER FAIL MESSAGE POINTER
4493 016302 000000      $SILLUP: HALT
4494 016304 000776      BR      -2            ;; THE POWER UP SEQUENCE WAS STARTED
4495 016306 000000      $$SAVR6: 0            ;; BEFORE THE POWER DOWN WAS COMPLETE
4496 016310 005015 047520 042527  $POWER: .ASCIZ <15><12>"POWER" ;; PUT THE SP HERE
4497 016316 000122
4498
4499
4500
4501
4502
4503
4504
4505
4506
4507 016320 010046      $TRAP: MOV      R0,-(SP)    ;; SAVE R0
4508 016322 016600 000002  MOV      2(SP),R0     ;; GET TRAP ADDRESS
4509 016326 005740      TST     -(R0)        ;; BACKUP BY 2
4510 016330 111000      MOV     B(R0),R0     ;; GET RIGHT BYTE OF TRAP
4511 016332 006300      ASL    R0            ;; POSITION FOR INDEXING
4512 016334 016000 016342  MOV     $TRAPAD(R0),R0 ;; INDEX TO TABLE
4513 016340 000200      RTS     R0           ;; GO TO ROUTINE
4514
4515
4516
4517
4518
4519
4520
4521

```

\*\*\*\*\*

POWER UP ROUTINE

SPWRMG: .WORD \$POWER

;; THE POWER UP SEQUENCE WAS STARTED  
;; BEFORE THE POWER DOWN WAS COMPLETE  
;; PUT THE SP HERE

\*\*\*\*\*  
; THIS ROUTINE WILL PICKUP THE LOWER BYTE OF THE "TRAP" INSTRUCTION  
; AND USE IT TO INDEX THROUGH THE TRAP TABLE FOR THE STARTING ADDRESS  
; OF THE DESIRED ROUTINE. THEN USING THE ADDRESS OBTAINED IT WILL  
; GO TO THAT ROUTINE.

.SBTTL TRAP TABLE

;; THIS TABLE CONTAINS THE STARTING ADDRESSES OF THE ROUTINES CALLED  
; BY THE "TRAP" INSTRUCTION.

ROUTINE  
-----

```

4522 016342
4523 016342 015412
4524 016344 013534
4525 016346 013510
4526 016350 013550
4527 016352 013736
4528
4529 016354 014706
4530
4531 016356 014636
4532 016360 015120
4533 016362 015240
4534 016364 005015 046103 041517
4535 016372 020113 051123 043040
4536 016400 047125 052103 047511
4537 016406 020116 051105 047522
4538 016414 000122
4539 016416 005015 046103 041517
4540 016424 020113 051123 042040
4541 016432 052101 020101 051105
4542 016440 047522 000122
4543 016444 005015 046103 041517
4544 016452 020113 051102 042040
4545 016460 052101 020101 051105
4546 016466 047522 000122
4547 016472 005015 047503 047125
4548 016500 020124 042522 027107
4549 016506 042440 051122 051117
4550 016514 000
4551 016515 015 041412 047514
4552 016522 045503 041440 052517
4553 016530 052116 042440 051122
4554 016536 051117 000040
4555 016542 005015 046103 041517
4556 016550 020113 047503 047125
4557 016556 020124 052506 041516
4558 016564 044524 047117 042440
4559 016572 051122 051117 000
4560 016577 015 041412 047514
4561 016604 045503 044440 052116
4562 016612 051105 052522 052120
4563 016620 042440 051122 051117
4564 016626 000040
4565 016630 005015 046103 041517
4566 016636 020113 042522 042520
4567 016644 052101 041101 046111
4568 016652 052111 020131 051105
4569 016660 047522 020122 000
4570 016665 015 041412 047514
4571 016672 045503 040440 042104
4572 016700 042522 051523 047111
4573 016706 020107 051105 047522
4574 016714 000122
4575
4576 016716 005015 051105 050122
4577 016724 004503 051501 004522

```

```

*TRPAD:
$TYPE      ::CALL=TYPE      TRAP+0(104400)  TTY TYPEOUT ROUTINE
$TYPOC     ::CALL=TYPOC     TRAP+1(104401)  TYPE OCTAL NUMBER (WITH LEADING ZEROS)
$TYPOS     ::CALL=TYPOS     TRAP+2(104402)  TYPE OCTAL NUMBER (NO LEADING ZEROS)
$TYPCN     ::CALL=TYPCN     TRAP+3(104403)  TYPE OCTAL NUMBER (AS PER LAST CALL)
$TYPCN     ::CALL=TYPCN     TRAP+4(104404)  TYPE BINARY (ASCII) NUMBER
$GTSWR     ;;CALL=GTSWR     TRAP+5(104405)  GET SOFT-SWR SETTING
$CKSWR     ::CALL=CKSWR     TRAP+6(104406)  TEST FOR CHANGE IN SOFT-SWR
$RDCHR     ::CALL=RDCHR     TRAP+7(104407)  TTY TYPEIN CHARACTER ROUTINE
$RDLIN     ::CALL=RDLIN     TRAP+10(104410) TTY TYPEIN STRING ROUTINE
.ASCIZ     <15><12>/CLOCK SR FUNCTION ERROR/

```

```

EM1:
.ASCIZ <15><12>/CLOCK SR DATA ERROR/
EM2:
.ASCIZ <15><12>/CLOCK BR DATA ERROR/
EM3:
.ASCIZ <15><12>/COUNT REG. ERROR/
EM5:
.ASCIZ <15><12>/CLOCK COUNT ERROR #
EM12:
.ASCIZ <15><12>/CLOCK COUNT FUNCTION ERROR#
EM16:
.ASCIZ <15><12>/CLOCK INTERRUPT ERROR #
EM20:
.ASCIZ <15><12>/CLOCK REPEATABILITY ERROR #
EM26:
.ASCIZ <15><12>/CLOCK ADDRESSING ERROR#
DM1:
.ASCIZ <15><12>/ERRPC ASR WAS S/Bx

```

DVKWA.P11 TRAP TABLE

4578	016732	040527	004523	027523						
4579	016740	000102								
4580	016742	005015	051105	050122	DM3:	.ASCIZ	<15><12>	#ERRPC	ABR	WAS S/B#
4581	016750	004503	041101	004522						
4582	016756	040527	004523	027523						
4583	016764	000102								
4584	016766	005015	051105	050122	DM4:	.ASCIZ	<15><12>	#ERRPC	ASR	WAS S/B#
4585	016774	004503	051501	004522						
4586	017002	040527	004523	027523						
4587	017010	000102								
4588	017012	005015	051105	050122	DM12:	.ASCIZ	<15><12>	#ERRPC	ASR	#
4589	017020	004503	051501	004522						
4590	017026	000								
4591	017027	015	042412	051122	DM20:	.ASCIZ	<15><12>	#ERRPC	ASR	2NDCNT 1STNCT 3RD CNT#
4592	017034	041520	040411	051123						
4593	017042	031011	042116	047103						
4594	017050	004524	051461	047124						
4595	017056	052103	031411	042122						
4596	017064	047103	000124							
4597	017070	005015	051105	050122	DM26:	.ASCIZ	<15><12>	#ERRPC	CLOCK ADDR.#	
4598	017076	004503	046103	041517						
4599	017104	020113	042101	051104						
4600	017112	000056								
4601										
4602										
4603										
4604	017114	001116	001376	001126	DT1:	.WORD		\$ERRPC, ASR, \$BODAT, \$GDDAT, 0		
4605	017122	001124	000000							
4606	017126	001116	001400	001126	DT3:	.WORD		\$ERRPC, ABR, \$BODAT, \$GDDAT, 0		
4607	017134	001124	000000							
4608	017140	001116	001376	000000	DT12:	.WORD		\$ERRPC, ASR, 0		
4609	017146	001116	001376	001126	DT20:	.WORD		\$ERRPC, ASR, \$BODAT, \$GDDAT, \$TMPD, 0		
4610	017154	001124	001420	000000						
4611	017162	001116	001376	001126	DT22:	.WORD		\$ERRPC, ASR, \$BODAT, \$TMPD, 0		
4612	017170	001420	000000							
4613	017174	001116	001420	000000	DT26:	.WORD		\$ERRPC, \$TMPD, 0		
4614										
4615	017202	000000	000000		DF0:	.WORD		0, 0		
4616										
4617		000001								.END









	4147	4149	4155	4162	4191	4228*	4468	4481*
SWREG	000176	708#	1133	1162	4191	4204		
SW0	= 000001	795#						
SW00	= 000001	785#	795					
SW01	= 000002	784#	794					
SW02	= 000004	783#	793					
SW03	= 000010	782#	792					
SW04	= 000020	781#	791					
SW05	= 000040	780#	790					
SW06	= 000100	779#	789					
SW07	= 000200	778#	788					
SW08	= 000400	777#	787					
SW09	= 001000	776#	786					
SW1	= 000002	794#						
SW10	= 002000	775#						
SW11	= 004000	774#						
SW12	= 010000	773#						
SW13	= 020000	772#						
SW14	= 040000	771#						
SW15	= 100000	770#						
SW2	= 000004	793#						
SW3	= 000010	792#						
SW4	= 000020	791#						
SW5	= 000040	790#						
SW6	= 000100	789#						
SW7	= 000200	788#						
SW8	= 000400	787#						
SW9	= 001000	786#						
TBITVE	= 000014	828#						
TKVEC	= 000060	835#						
TPVEC	= 000064	836#						
TRAPVE	= 000034	834#	1112*	1113*				
TRTVEC	= 000014	829#						
TSTCNT	001436	1085#	1090*	1093*	1097*	3671		
TSTSTR	001442	723	1089#					
TST1	002346	1207#						
TST10	003170	1518#						
TST11	003266	1563#						
TST12	003364	1608#						
TST13	003462	1653#						
TST14	003560	1698#						
TST15	003656	1739#						
TST16	003746	1778#						
TST17	004036	1829#						
TST2	002440	1248#						
TST20	004110	1868#						
TST21	004172	1905#						
TST22	004320	1950#						
TST23	004446	2000#						
TST24	004534	2022	2025	2028	2046#			
TST25	004606	2069	2075#					
TST26	004656	2092	2094	2096	2110#			
TST27	004712	2136#						
TST3	002502	1293#						
TST30	005022	2176#						
TST31	005232	2200	2236#					

















.SRAND	18		
.SRDE	18		
.SRDOC	18	675#	
.SREAO	18	677#	4181
.SRZAZ	18		
.SSAVE	18		
.SSB20	18		
.SSB20	18		
.SSCOP	18	677#	4116
.SSITE	18		
.SSUPR	18		
.STRAP	18	675#	4499
.STYPB	18	675#	3986
.STYPO	18	677#	
.STYFE	18	677#	4320
.STYPO	18	676#	3909
.S400A	18		
.1170	18		



# D10

ROCB	4001														
ROO	1192	1194	1196	1200	1226	1262	2802	2841	3676	3705	3709	3937	3947	4091	4220
	4229	4356	4416	4428	4440										
ASL	3673	4088	4089	4090	4243	4244	4245	4511							
XSR	4423														
BEQ	1139	1161	1173	1301	1315	1346	1360	1391	1405	1436	1450	1481	1495	1526	1540
	1571	1585	1516	1630	1661	1675	1706	1720	1747	1762	1786	1801	1845	1889	1933
	1978	2010	2025	2028	2056	2069	2094	2189	2217	2239	2262	2292	2598	2918	2957
	3051	3084	3137	3170	3223	3256	3310	3343	3398	3435	3484	3510	3547	3572	3586
	3603	3635	3672	3712	3772	3822	3901	3964	4000	4029	4032	4055	4058	4093	4098
	4111	4148	4150	4152	4156	4165	4200	4227	4242	4346	4359	4394	4410	4414	4434
	4436														
BGE	4168														
BGT	5749	3971	4239	4290											
BHI	4154														
BIC	1190	1312	1357	1402	1447	1492	1537	1582	1627	1672	1717	1759	1798	1919	1964
	2145	2204	2351	2402	2453	2504	2555	2610	2657	2705	2910	2946	2987	3035	3072
	3121	3158	3207	3244	3294	3331	3383	3423	3498	3561	3623	3746	3961	4066	4196
	4213	4240	4267	4273	4281										
BIS	1297	1342	1387	1432	1477	1522	1567	1612	1657	1702	1913	1920	1925	1958	1965
	1970	2026	2070	2078	2113	2140	2141	2146	2151	2184	2186	2205	2210	2243	2248
	2250	2285	2287	2309	2311	2352	2357	2403	2408	2454	2459	2505	2510	2556	2561
	2611	2616	2654	2658	2663	2695	2697	2706	2711	2739	2779	2819	2855	2856	2881
	2907	2908	2912	2940	2947	2952	2975	2976	2979	2988	2993	3020	3021	3027	3036
	3041	3065	3073	3078	3106	3107	3113	3122	3127	3151	3159	3164	3192	3193	3199
	3208	3213	3237	3245	3250	3279	3280	3286	3295	3300	3324	3302	3337	3365	3366
	3373	3384	3389	3414	3424	3429	3476	3480	3499	3504	3539	3543	3562	3567	3624
	3629	3685	3818	3820	3859	3895	3966	3967	4247						
BISB	4230														
BIT	2027	2095	2114	2190	2291	2313	2595	2858	2887	2917	3900	4031	4038	4054	4133
	4147	4155	4162												
BITB	1138	4345	4350	4382	4413										
BLOS	4293														
BLT	3972	4237	4278	4373											
BMI	2081	2253	2265	2365	2416	2467	2518	2569	2624	2671	2745	3648	3568	3863	3897
BME	1105	1128	1155	1159	1163	2096	2115	2156	2191	2230	2314	2347	2362	2398	2413
	2449	2464	2500	2515	2551	2566	2606	2621	2668	2701	2716	2742	2859	2884	2888
	2943	2983	2998	3029	3067	3115	3153	3201	3239	3288	3326	3375	3378	3416	3418
	3478	3541	3684	3962	4039	4044	4063	4081	4103	4134	4163	4192	4198	4218	4225
	4232	4269	4275	4297	4303	4344	4351	4353	4361	4369	4383	4390	4412	4418	4421
	4438	4480													
BPL	2718	3614	3960	4051	4194	4210	4265	4271	4338	4387					
BR	1091	1095	1130	1165	1168	1175	1180	1223	1259	1310	1355	1400	1445	1490	1535
	1580	1625	1670	1715	1757	1796	2022	2092	2200	2225	2260	2800	2839	3061	3147
	3233	3320	3409	3493	3556	3582	3610	3617	3644	3688	3694	3699	3716	3722	3754
	3760	3766	3824	3855	3903	3938	3953	3974	4004	4049	4096	4113	4136	4142	4145
	4158	4161	4221	4248	4250	4276	4299	4340	4366	4376	4385	4392	4404	4426	4472
	4494														
CLC	4003														
CLR	1094	1098	1103	1116	1117	1137	1183	1184	1185	1296	1313	1341	1358	1386	1403
	1431	1448	1476	1493	1521	1538	1566	1583	1611	1628	1656	1673	1701	1718	1741
	1760	1780	1799	1832	1871	1908	1953	2003	2049	2127	2138	2139	2179	2180	2227
	2241	2245	2281	2307	2324	2341	2342	2344	2376	2392	2393	2395	2427	2443	2444
	2446	2478	2494	2495	2497	2529	2545	2546	2548	2580	2600	2601	2603	2635	2651
	2652	2682	2692	2693	2698	2720	2729	2737	2740	2775	2803	2816	2842	2853	2879
	2862	2927	2935	2936	2937	2941	2966	2973	2974	3008	3018	3019	3095	3104	3105

	2181	3190	3191	3267	3277	3278	3354	3363	3364	3446	3471	3472	3534	3535	3558
	3584	3587	3635	3620	3730	3743	3744	3815	3816	3856	3951	4079	4160	4175	4207
	4208	4478													
CLRB	1841	1887	4159	4304	4365	4391	4442	4443	4444						
CMP	1124	1127	1162	1300	1345	1390	1435	1480	1525	1570	1615	1660	1705	1746	1795
	1931	1976	2216	3048	3083	3134	3169	3220	3255	3307	3342	3396	3434	3483	3509
	3546	3671	3711	3821	4143	4167	4191	4197	4217	4224	4236	4238	4268	4274	4277
	4279	4292													
CMPB	1160	4043	4149	4153	4199	4231	4296	4302	4343	4358	4360	4368	4389	4393	4411
DEC	1883	3066	3152	3238	3325	3377	3415	3417	3747	4064	4087				
DECB	3959	3970	4372	4375											
EMT	732														
HALT	706	4052	4339	4471	4493										
INC	1089	1154	1873	2215	2346	2397	2448	2499	2550	2605	2700	2854	2982	3028	3114
	3200	3287	3374	3477	3540	3674	3697	3745	3965	3973	4034	4062	4166	4246	4441
	4479														
INCB	2741	2883	2942	4028	4171	4395									
IOT	733														
JMP	714	715	716	717	718	721	723	3706	3779						
JSR	3774	4040	4046	4235	4348	4367	4374	4381	4430						
MOV	1090	1093	1097	1102	1106	1108	1109	1110	1111	1112	1113	1114	1115	1119	1120
	1123	1124	1125	1126	1131	1133	1134	1135	1140	1144	1145	1149	1150	1186	1187
	1191	1193	1195	1199	1208	1209	1211	1215	1216	1227	1242	1251	1252	1263	1278
	1294	1296	1299	1314	1339	1343	1344	1359	1384	1388	1389	1404	1429	1433	1434
	1445	1474	1478	1479	1494	1519	1523	1524	1539	1564	1568	1569	1584	1609	1613
	1614	1629	1654	1658	1659	1674	1699	1703	1704	1719	1742	1743	1744	1761	1781
	1782	1783	1800	1830	1838	1840	1869	1885	1886	1906	1909	1915	1917	1918	1921
	1926	1928	1951	1954	1960	1962	1963	1966	1971	1973	2001	2004	2008	2047	2050
	2054	2077	2112	2143	2144	2147	2152	2154	2177	2191	2182	2202	2203	2206	2211
	2213	2228	2246	2283	2308	2338	2343	2349	2350	2353	2358	2360	2389	2394	2400
	2401	2404	2409	2411	2440	2445	2451	2452	2455	2460	2462	2491	2496	2502	2503
	2506	2511	2513	2542	2547	2553	2554	2557	2562	2564	2593	2602	2608	2609	2612
	2617	2619	2648	2653	2655	2656	2659	2664	2666	2690	2703	2704	2707	2712	2714
	2738	2767	2770	2771	2776	2778	2780	2782	2783	2789	2790	2811	2812	2817	2818
	2821	2822	2828	2829	2961	2862	2877	2880	2890	2891	2906	2915	2916	2933	2939
	2944	2945	2948	2953	2955	2977	2985	2986	2989	2994	2996	3016	3025	3032	3033
	3034	3037	3042	3044	3046	3062	3070	3071	3074	3079	3081	3102	3111	3118	3119
	3120	3123	3128	3130	3132	3148	3156	3157	3160	3165	3167	3198	3197	3204	3205
	3206	3209	3214	3216	3218	3234	3242	3243	3246	3251	3253	3275	3294	3291	3292
	3293	3296	3301	3303	3305	3321	3329	3330	3333	3338	3340	3361	3369	3371	3380
	3381	3382	3385	3390	3392	3394	3410	3411	3421	3422	3425	3430	3432	3469	3473
	3475	3481	3482	3496	3497	3500	3505	3507	3532	3536	3538	3544	3545	3559	3560
	3563	3568	3570	3585	3600	3606	3607	3621	3622	3625	3630	3632	3677	3678	3691
	3702	3704	3710	3719	3726	3727	3728	3731	3750	3757	3763	3769	3771	3817	3819
	3857	3858	3894	3934	3942	3943	3944	3950	3957	3975	3976	3977	3978	3979	3995
	3996	4005	4006	4007	4030	4035	4056	4059	4078	4083	4092	4097	4102	4104	4108
	4138	4139	4141	4144	4157	4169	4170	4173	4174	4177	4178	4204	4228	4233	4262
	4263	4290	4291	4306	4307	4308	4309	4341	4342	4347	4355	4370	4407	4408	4415
	4419	4424	4425	4427	4429	4439	4445	4446	4460	4461	4462	4463	4464	4465	4466
	4467	4468	4469	4470	4476	4477	4481	4482	4483	4484	4485	4486	4487	4488	4489
	4507	4508	4512												
MOV8	1118	1166	1210	1833	1877	3935	3936	3939	3940	3941	3945	3948	3949	3968	3998
	4037	4045	4172	4176	4195	4212	4266	4272	4295	4300	4352	4380	4388	4402	4403
	4405	4510													
NEG	3946														
NOP	1207	2787	2826	3742	3775	3776	3777	3860	3861						

RESET	2006	2052	3773												
RXL	3952	3954	3955	3956	3958	3999									
RTI	1132	1146	2772	2784	2791	2813	2823	2830	3980	4008	4067	4179	4234	4282	4310
	4357	4492													
RTS	4106	4397	4447	4513											
SEC	3997														
SUB	4036	4422													
TRAP	4515	4524	4525	4526	4527	4529	4531	4532	4533						
TST	1158	1172	1219	1255	1929	1974	2024	2068	2080	2093	2155	2188	2214	2229	2238
	2242	2261	2361	2412	2463	2514	2565	2620	2667	2715	2956	2997	3045	3082	3131
	3168	3217	3254	3304	3341	3393	3433	3508	3571	3602	3608	3615	3633	3647	3680
	3683	3862	3896	3963	4050	4057	4110	4140	4164	4226	4241	4354	4362	4384	4417
	4435	4437	4509												
TSTB	1843	1888	2252	2263	2363	2414	2465	2516	2567	2622	2669	2717	2744	3613	3667
	4151	4193	4209	4264	4270	4337	4386	4409	4420	4433					
.ASCII	919	920													
.ASCIZ	918	921	1170	1177	1182	3612	3619	3690	3696	3701	3718	3724	3756	3762	3768
	4114	4314	4315	4316	4318	4496	4534	4539	4543	4547	4551	4555	4560	4565	4570
	4576	4580	4584	4588	4591	4597									
.BLKB	4313														
.BYTE	898	889	894	895	903	904	912	913	914	915	937	938	948	949	956
	957	959	960	962	963	3781	3981	3982	3983	3984	4009	4047	4048	4311	4312
	4448	4449	4450												
.DSABL	4251														
.ENABL	1	673	674	4184											
.END	4617														
.ENDC	692	709	732	824	838	849	853	855	860	862	869	882	886	898	916
	917	918	919	923	926	948	956	959	962	965	966	967	968	969	972
	1089	1106	1107	1110	1112	1114	1116	1117	1119	1121	1142	1156	1162	1168	1170
	1177	1182	1205	1206	1207	1208	1209	1210	1213	1246	1247	1248	1249	1296	1287
	1292	1293	1294	1295	1331	1332	1337	1338	1339	1340	1376	1377	1382	1383	1384
	1395	1421	1422	1427	1428	1429	1430	1466	1467	1472	1473	1474	1475	1511	1512
	1517	1518	1519	1520	1556	1557	1562	1563	1564	1565	1601	1602	1607	1608	1609
	1610	1646	1647	1652	1653	1654	1655	1691	1692	1697	1698	1699	1700	1737	1738
	1739	1740	1776	1777	1778	1779	1821	1822	1828	1829	1830	1831	1860	1861	1867
	1868	1969	1870	1903	1904	1905	1906	1907	1948	1949	1950	1951	1952	1994	1995
	1999	2000	2001	2002	2023	2026	2029	2039	2040	2045	2046	2047	2048	2070	2073
	2074	2075	2076	2093	2095	2097	2108	2109	2110	2111	2134	2135	2136	2137	2168
	2169	2175	2176	2177	2178	2201	2234	2235	2236	2237	2261	2263	2266	2277	2278
	2279	2290	2303	2304	2305	2306	2330	2331	2336	2337	2338	2339	2340	2349	2381
	2382	2387	2388	2389	2390	2391	2400	2432	2433	2438	2439	2440	2441	2442	2451
	2483	2484	2489	2490	2491	2492	2493	2502	2534	2535	2540	2541	2542	2543	2544
	2553	2585	2586	2591	2592	2593	2594	2599	2608	2640	2641	2646	2647	2648	2649
	2650	2655	2687	2688	2689	2690	2691	2733	2734	2735	2736	2764	2765	2766	2767
	2768	2906	2807	2908	2909	2849	2950	2951	2852	2874	2875	2876	2877	2878	2902
	2903	2904	2905	2930	2931	2932	2933	2934	2969	2970	2971	2972	3013	3014	3015
	3016	3017	3024	3031	3052	3062	3068	3099	3100	3101	3102	3103	3110	3117	3138
	3148	3154	3185	3186	3187	3188	3189	3196	3203	3224	3234	3240	3272	3273	3274
	3275	3276	3283	3290	3311	3321	3327	3358	3359	3360	3361	3362	3370	3379	3400
	3411	3419	3451	3452	3467	3468	3469	3470	3524	3525	3530	3531	3532	3533	3557
	3583	3587	3597	3598	3599	3600	3601	3612	3619	3630	3696	3701	3718	3724	3737
	3738	3740	3743	3749	3752	3753	3756	3762	3768	3771	3773	3779	3781	3782	3912
	3989	4015	4018	4028	4035	4040	4041	4042	4050	4061	4069	4072	4087	4116	4119
	4122	4127	4133	4135	4146	4149	4150	4151	4153	4155	4162	4166	4171	4173	4177
	4180	4181	4184	4185	4187	4215	4251	4255	4283	4284	4291	4293	4296	4298	4314
	4320	4323	4352	4402	4403	4406	4433	4448	4459	4468	4469	4475	4481	4482	4492

	4499	4502	4508	4511	4523	4524	4525	4526	4527	4528	4529	4530	4531	4532	4533
.EQUIV	4534 732 814	733 815	741 816	756 817	757 818	786 819	787 820	788 821	789 822	790 823	791	792	793	794	795
.EVEN	926	1170	1177	1182	3612	3619	3690	3696	3701	3718	3724	3756	3762	3768	3782
.IF	4115 688 917 372 1160 1292 1427 1562 1697 1861 2001 2394 2235 2339 2442 2548 2654 2848 2970 3110 3273 3410 3596 3740 4014 4118 4174 4297 4481 4532	4451 709 918 1089 1169 1294 1429 1564 1699 1867 2002 2096 2237 2340 2446 2584 2696 2850 2972 3117 3275 3417 3598 3742 4017 4121 4179 4313 4482 4533	4498 730 922 1101 1176 1295 1430 1565 1700 1869 2022 2107 2260 2344 2482 2586 2698 2852 3012 3136 3276 3450 3600 3748 4028 4126 4180 4314 4490 4534	4602 796 923 1106 1181 1330 1465 1600 1736 1870 2025 2109 2262 2330 2484 2591 2690 2873 3014 3148 3283 3452 3601 3751 4031 4132 4181 4320 4492	824 925 1108 1203 1332 1467 1602 1738 1902 2028 2111 2265 2382 2439 2593 2691 2875 3016 3154 3290 3467 3611 3753 4038 4133 4183 4322 4496	848 948 1110 1204 1337 1472 1607 1740 1904 2038 2132 2276 2387 2491 2594 2732 2877 3017 3184 3309 3469 3618 3755 4040 4145 4186 4343 4501	851 956 1112 1206 1339 1474 1609 1775 1906 2040 2127 2278 2389 2492 2595 2734 2878 3024 3186 3321 3470 3619 3761 4041 4147 4186 4401 4507	853 959 1114 1208 1340 1475 1610 1777 1907 2045 2137 2280 2390 2493 2598 2736 2901 3031 3188 3327 3470 3619 3767 4043 4148 4187 4403 4511	859 962 1116 1209 1375 1510 1645 1779 1947 2047 2167 2302 2391 2497 2603 2763 2903 3050 3189 3357 3525 3700 3771 4050 4149 4215 4406 4515	861 965 1117 1210 1377 1512 1647 1820 1949 2048 2169 2304 2395 2497 2639 2765 2905 3062 3196 3359 3525 3717 3773 4054 4151 4254 4433 4524	868 966 1119 1245 1382 1517 1652 1822 1951 2069 2175 2306 2431 2533 2641 2767 2929 3068 3196 3361 3532 3723 3779 4061 4152 4255 4448 4525	891 967 1137 1247 1384 1519 1654 1828 1952 2072 2177 2329 2433 2540 2646 2768 2931 3098 3222 3362 3533 3736 3781 4069 4153 4293 4458 4526	895 968 1155 1249 1385 1520 1655 1830 1993 2074 2178 2331 2438 2542 2648 2805 2933 3100 3234 3369 3556 3737 3782 4071 4162 4291 4468 4527	887 969 1156 1285 1420 1555 1690 1831 1995 2076 2178 2336 2440 2543 2649 2807 2934 3102 3240 3377 3582 3738 3911 4086 4164 4292 4469 4529	916 970 1157 1287 1422 1557 1692 1859 1999 2092 2233 2338 2441 2544 2650 2809 2968 3103 3271 3398 3586 3739 3988 4102 4172 4296 4474 4531
.IFF	730 1156 1294 1473 1647 1821 1951 2075 2176 2304 2439 2592 2735 2875 3013 3272 3525 3781 4180 4475	849 1204 1331 1474 1653 1822 1994 2076 2177 2305 2440 2593 2736 2876 3014 3273 3531 3912 4181 4492	853 1205 1332 1511 1654 1829 1995 2093 2201 2306 2446 2599 2764 2877 3015 3274 3532 3989 4184 4502	855 1206 1338 1512 1691 1830 2000 2095 2234 2330 2483 2603 2765 2902 3016 3275 3557 4015 4187 4508	860 1207 1339 1518 1692 1850 2001 2097 2235 2331 2484 2640 2766 2904 3050 3309 3583 4017 4255 3619	862 1208 1376 1519 1698 1861 2023 2108 2236 2337 2490 2641 2767 2905 3099 3358 3587 4031 4257 3690	869 1213 1377 1556 1699 1868 2026 2109 2237 2338 2491 2647 2806 2905 3100 3359 3597 4061 4262 3696	882 1245 1383 1557 1737 1869 2029 2110 2261 2344 2497 2648 2807 2930 3101 3360 3598 4072 4283 3701	885 1246 1384 1563 1738 1869 2039 2111 2263 2381 2497 2655 2808 2931 3102 3361 3599 4087 4284 3718	888 1247 1385 1564 1739 1903 2040 2134 2266 2382 2534 2687 2809 2932 3136 3400 3599 4087 4293 3724	916 1248 1422 1601 1740 1905 2046 2135 2277 2388 2541 2688 2849 2933 3185 3451 3737 4116 4297 3756	923 1249 1428 1602 1776 1906 2047 2136 2278 2389 2542 2689 2850 2969 3186 3452 3739 4119 4314 3762	926 1286 1429 1608 1777 1948 2070 2137 2279 2395 2548 2690 2851 2970 3187 3468 3742 4146 4323 3768	1106 1287 1466 1609 1778 1949 2073 2168 2280 2432 2585 2733 2852 2971 3188 3469 3749 4150 4402 4041	1155 1293 1467 1646 1779 1950 2074 2169 2303 2433 2586 2734 2874 2972 3222 3524 3752 4153 4459 4161
.IFT	1170	1177	1182	3612	3619	3690	3696	3701	3718	3724	3756	3762	3768	4041	4161

.IFTF	4257 1170 4202	4262 1177 4255	1182 4258 697	3612 698	3619 706	3690 922	3696 926	3701 1107	3718 1110	3724 1116	3756 1117	3762 1119	3768 1120	4040 1156	4159 3692
.IIF	687 3703 4027 4177 4531	692 3720 4053 4180 4532	697 3738 4061 4181 4533	698 3743 4069 4184	706 3744 4084 4205	922 3758 4109 4306	926 3764 4122 4314	1107 3770 4123 4320	1110 3781 4124 4399	1116 3792 4125 4523	1117 4018 4126 4524	1119 4019 4127 4525	1120 4020 4131 4526	1156 4021 4160 4527	3692 4022 4161 4529
.IRP	1089 1820 2431 3098 4462	1204 1859 2482 3184 4468	1245 1902 2533 3271 4481	1285 1947 2584 3357 4482	1330 1993 2639 3450	1375 2038 2686 3523	1420 2072 2732 3596	1465 2107 2763 3742	1510 2133 2805 4061	1555 2167 2848 4132	1600 2233 2873 4407	1645 2276 2901 4408	1690 2302 2929 4429	1736 2329 2968 4445	1775 2380 3012 4446
.LIST	1 1208 1303 1355 1414 1465 1528 1580 1639 1690 1755 1811 1936 2022 2090 2160 2256 2323 2470 2579 2722 2800 2893 2966 3093 3227 3352 3488 3580 3652 4283	672 1230 1305 1363 1416 1474 1530 1588 1641 1699 1757 1820 1938 2030 2092 2163 2258 2329 2472 2584 2724 2805 2895 2968 3095 3231 3354 3491 3582 3655 4515	706 1232 1308 1365 1419 1476 1533 1590 1644 1701 1765 1830 1943 2032 2098 2165 2267 2338 2475 2593 2727 2809 2898 2972 3098 3233 3357 3493 3589 3657 4523	838 1240 1310 1369 1420 1483 1535 1594 1645 1708 1767 1848 1945 2035 2100 2167 2269 2368 2477 2627 2729 2833 2900 3001 3102 3258 3361 3512 3591 3690 4524	916 1242 1318 1371 1429 1485 1543 1596 1654 1710 1770 1850 1947 2037 2103 2177 2272 2370 2482 2629 2732 2835 2901 3003 3139 3260 3401 3514 3593 3696 4525	923 1245 1320 1374 1431 1488 1545 1599 1656 1713 1772 1855 1951 2038 2105 2193 2274 2373 2491 2632 2736 2837 2905 3006 3141 3265 3403 3518 3595 3701 4526	926 1249 1324 1375 1438 1498 1549 1599 1663 1715 1775 1857 1981 2047 2107 2195 2276 2375 2521 2634 2748 2839 2920 3008 3145 3267 3407 3520 3596 3718 4527	1089 1266 1326 1384 1440 1498 1551 1609 1665 1723 1779 1859 1983 2059 2111 2198 2280 2380 2523 2639 2750 2848 2922 3012 3147 3271 3409 3523 3600 3724 4528	1121 1268 1329 1386 1443 1500 1554 1611 1668 1725 1789 1869 1988 2061 2118 2200 2295 2389 2528 2648 2753 2852 2925 3016 3172 3275 3437 3532 3612 3743 4529	1156 1276 1330 1393 1445 1504 1555 1618 1678 1729 1794 1894 1990 2065 2120 2209 2297 2389 2528 2674 2755 2864 2927 3053 3174 3275 3439 3549 3619 3756 4530	1157 1278 1339 1395 1453 1506 1564 1618 1678 1731 1794 1894 1993 2067 2125 2221 2302 2419 2528 2674 2755 2866 2929 3055 3179 3275 3444 3551 3637 3762 4531	1170 1284 1341 1398 1453 1509 1566 1620 1680 1731 1796 1898 1993 2072 2127 2223 2306 2424 2533 2679 2763 2869 2933 3059 3181 3275 3446 3554 3639 3768 4532	1177 1285 1348 1398 1455 1510 1566 1623 1680 1736 1796 1898 1993 2076 2133 2225 2316 2426 2572 2681 2794 2871 2933 3061 3184 3275 3450 3556 3642 3773 4533	1182 1294 1350 1408 1461 1519 1575 1633 1686 1750 1804 1900 2001 2076 2137 2233 2318 2431 2574 2686 2796 2873 2959 3061 3188 3275 3469 3574 4061 4534	1204 1296 1353 1410 1464 1521 1578 1635 1689 1752 1809 1906 2006 2086 2158 2237 2321 2440 2577 2690 2798 2877 2964 3088 3225 3347 3486 3576 4126
.MACRO	1 2167 4011	682 2326 4515	683 2328	684 2379	685 2430	879 2481	988 2532	1137 2583	1201 2638	1281 2762	1282 3010	1734 3449	1819 3522	1992 3732	2037 3784
.MCALL	675	676	677	678	838	923	1121	1157							
.MEYIT	971														
.MLIST	1 1208 1303 1355 1414 1465 1528	671 1230 1305 1363 1416 1474 1530	706 1232 1308 1365 1419 1476 1533	838 1240 1310 1369 1420 1483 1535	916 1242 1318 1371 1429 1485 1543	923 1245 1320 1374 1431 1488 1545	926 1249 1324 1375 1438 1498 1549	1089 1266 1326 1384 1440 1498 1551	1121 1268 1329 1386 1443 1500 1554	1156 1276 1330 1393 1445 1504 1555	1157 1278 1339 1395 1453 1506 1564	1170 1284 1341 1398 1455 1509 1566	1177 1285 1348 1400 1459 151 1575	1182 1294 1350 1408 1461 1519 1575	1204 1296 1353 1410 1464 1521 1578

	1580	1588	1590	1594	1596	1593	1600	1609	1611	1618	1620	1623	1625	1633	1635
	1639	1641	1644	1645	1654	1656	1663	1668	1670	1678	1680	1680	1694	1696	1699
	1690	1699	1701	1708	1710	1713	1715	1723	1729	1731	1736	1740	1750	1752	1752
	1755	1757	1765	1767	1770	1772	1775	1779	1789	1791	1794	1796	1804	1806	1809
	1811	1820	1830	1848	1850	1855	1857	1859	1869	1892	1894	1898	1900	1902	1906
	1936	1938	1943	1945	1947	1951	1981	1983	1988	1990	1993	2001	2013	2015	2020
	2022	2030	2032	2035	2037	2038	2047	2059	2061	2065	2067	2072	2076	2084	2086
	2090	2092	2098	2100	2103	2105	2107	2111	2118	2120	2125	2127	2133	2137	2158
	2160	2163	2165	2167	2177	2193	2195	2198	2200	2219	2221	2223	2225	2233	2237
	2256	2258	2267	2269	2272	2274	2276	2280	2285	2297	2302	2306	2316	2318	2321
	2323	2329	2338	2368	2370	2373	2375	2380	2389	2419	2421	2424	2426	2431	2440
	2470	2472	2475	2477	2482	2491	2521	2523	2526	2529	2533	2542	2572	2574	2577
	2579	2584	2593	2627	2629	2632	2634	2639	2648	2674	2676	2679	2681	2686	2690
	2722	2724	2727	2729	2732	2736	2748	2750	2753	2755	2763	2767	2794	2796	2798
	2800	2805	2809	2833	2835	2837	2839	2848	2852	2864	2866	2869	2871	2873	2877
	2893	2895	2899	2900	2901	2905	2920	2922	2925	2927	2929	2933	2959	2961	2964
	2966	2968	2972	3001	3003	3006	3008	3012	3016	3053	3055	3059	3061	3086	3088
	3093	3095	3098	3102	3139	3141	3145	3147	3172	3174	3179	3181	3184	3188	3225
	3227	3231	3233	3258	3260	3255	3267	3271	3275	3312	3314	3318	3320	3345	3347
	3352	3354	3357	3361	3401	3403	3407	3409	3437	3439	3444	3446	3450	3469	3486
	3488	3491	3493	3512	3514	3518	3520	3523	3532	3549	3551	3554	3556	3574	3576
	3580	3582	3589	3591	3593	3595	3596	3600	3612	3619	3637	3639	3642	3644	3650
	3652	3655	3657	3690	3696	3701	3718	3724	3743	3756	3762	3768	3773	4061	4126
.PAGE	4283	4515	4523	4524	4525	4526	4527	4528	4529	4530	4531	4532	4533	4534	
.RADIX	879	972	1244	1230	1284	1328	1329	1373	1374	1418	1419	1463	1464	1508	1509
.REM	1553	1554	1598	1599	1643	1644	1688	1689	1733	1733	1733	1733	1733	1733	1733
.REPT	1284	1296	1329	1341	1374	1386	1419	1431	1464	1476	1509	1521	1554	1566	1599
.SBTTL	1611	1644	1656	1689	1701	1733									
.TITLE	1														
.WORD	706	2848													
	700	728	846	857	879	923	972	1100	1152	1157	1204	1245	1285	1330	1375
	1420	1465	1510	1555	1600	1645	1690	1736	1775	1815	1816	1817	1820	1859	1902
	1947	1993	2038	2072	2107	2129	2130	2131	2133	2167	2233	2276	2302	2329	2380
	2431	2482	2533	2584	2639	2686	2732	2758	2759	2760	2763	2905	2844	2845	2846
	2848	2873	2901	2929	2968	3012	3098	3184	3271	3357	3450	3523	3596	3734	3786
	3827	3868	3905	3906	3907	3909	3986	4012	4069	4116	4181	4320	4399	4456	4499
	4515														
.TITLE	687														
.WORD	706	707	708	710	854	873	874	875	876	877	878	887	890	891	892
	893	896	897	898	899	900	901	902	905	906	907	928	929	930	931
	932	933	934	935	939	940	941	954	958	961	964	965	966	967	968
	969	1069	1070	1071	1072	1073	1074	1075	1076	1077	1078	1079	1080	1081	1082
	1083	1084	1085	1086	3748	3751	3780	3985	4095	4100	4349	4396	4431	4491	4604
	4606	4608	4609	4611	4613	4615									

ERRORS DETECTED: 0  
 DEFAULT GLOBALS GENERATED: 0

\* DVKWA.SEQ/SOL/CRF/PAGNUM/ML:TOC=DVKWA.SML,DVKWA.P11  
 RUN-TIME: 50 65 8 SECONDS  
 RUN-TIME RATIO: 285/125=2.2  
 CORE USED: 35K (69 PAGES)

