

DQ11

RECEIVER AND XMT TESTS
MD-11-DZDQD-D

EP-DZDQD-D-DL-B

APR 1977

COPYRIGHT © 1977

digital

FICHE 1 OF 1

MADE IN USA

TEST NAME	TEST 1	TEST 2	TEST 3	TEST 4	TEST 5	TEST 6	TEST 7	TEST 8	TEST 9	TEST 10
TEST 1	100	100	100	100	100	100	100	100	100	100
TEST 2	100	100	100	100	100	100	100	100	100	100
TEST 3	100	100	100	100	100	100	100	100	100	100
TEST 4	100	100	100	100	100	100	100	100	100	100
TEST 5	100	100	100	100	100	100	100	100	100	100
TEST 6	100	100	100	100	100	100	100	100	100	100
TEST 7	100	100	100	100	100	100	100	100	100	100
TEST 8	100	100	100	100	100	100	100	100	100	100
TEST 9	100	100	100	100	100	100	100	100	100	100
TEST 10	100	100	100	100	100	100	100	100	100	100
TEST 11	100	100	100	100	100	100	100	100	100	100
TEST 12	100	100	100	100	100	100	100	100	100	100
TEST 13	100	100	100	100	100	100	100	100	100	100
TEST 14	100	100	100	100	100	100	100	100	100	100
TEST 15	100	100	100	100	100	100	100	100	100	100

100

BC1

EOF1DZD9CDSEQ

00010000

770325

PDP10 411

COHDR1DZD9DDSEQ

00010000

770325

CO1

DZDGD MACY11 27(1006) 22-DEC-76 11:14 PAGE 2
DZDQDD.P11 21-DEC-76 16:32

IDENTIFICATION

PRODUCT CODE: MAINDEC-11-DZDGD-D-D
PRODUCT NAME: RECEIVER AND TRANSMITTER TESTS
DATE: MARCH 1977
MAINTAINER: DIAGNOSTIC GROUP

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS DOCUMENT.

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED UNDER A LICENSE AND MAY ONLY BE USED OR COPIED IN ACCORDANCE WITH THE TERMS OF SUCH LICENSE.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

COPYRIGHT (C) 1974, 1977 BY DIGITAL EQUIPMENT CORPORATION

1. ABSTRACT

THE FUNCTION OF THE DQ11 DIAGNOSTICS ARE TO VERIFY THAT THE OPTION OPERATES ACCORDING TO SPECIFICATIONS.

THIS TEST TEST TRANSMITTER AND RECEIVER CHARACTER LENGTHS FROM 00 TO 16 BITS PER CHARACTER.
 ALSO DATA REALIBILITY FOR TRANSMITTER, RECEIVER AND TRANSMITTER AND RECEIVER TOGETHER.
 CABLE TEST TRANSFERS 400 CHARACTERS THROUGHT THE CABLE TO VERIFY CABLE.

WHEN THE PROGRAM ENTERS TEST #56 ON EACH FIRST TIME AFTER STARTING OR IF THERE ARE MULTIPLE DQ11'S UNDER TEST; A MESSAGE WILL BE PRINTED:

"CHARACTERS DETECTED"
 "CHAR ADDRESS"

THIS TEST IS DONE ONLY IF THE DQ11-BB OPTION IS NOT INSTALLED. THIS TEST IS DETERMINING THE STRAP-SELECTABLE CHARS ON THE M7818 MODULE. DEFAULT CHAR AND ADDRESS IS "CHAR 177777" AND "ADDRESS 17". THIS MAY BE CHANGED AS PER CUSTOMER PREFERANCES AND SHOULD BE PRINTED OUT ACCORDINGLY. IF THERE IS ONLY ONE DQ11 UNDER TEST THIS MESSAGE WILL BE PRINTED ONLY ONCE AFTER EACH START OF PROGRAM. IF THERE ARE MULTIPLE DQ11'S THIS WILL BE PRINTER EACH TIME THROUGHT THE TEST. THE ABOVE DESCRIBED MESSAGE IS #NOT# AN ERROR BUT MUST BE VERIFIED TO "WHAT WAS PRINTED OUT MATCHES THE M7818 MODULE". SEE TEST #56 FOR MORE DETAIL.

CURRENTLY THERE ARE SEVEN OFF LINE DIAGNOSTICS THAT ARE TO BE RUN IN SEQUENCE TO INSURE THAT IF AN ERROR SHOULD OCCUR IT WILL BE DETECTED AT AN EARLY STAGE AND INSURING THAT DIAGNOSIS OF ERROR WILL BE IMMEDIATE TO PROBLEM
 NOTE: ADDITIONAL DIAGNOSTICS MAY BE ADDED IN THE FUTURE.

THE SEVEN DIAGNOSTICS ARE:

1. DZDQA [REV] BASIS R/W TEST #1
2. DZDQB [REV] BASIS R/W TEST #2
3. DZDQC [REV] BASIC NPR AND INTERRUPT TEST
4. DZDQD [REV] RECEIVER TRANSMITTER EXERCISER TEST
5. DZDQE [REV] MISC. RX AND TX TESTS. PLUS BCC TESTS.
6. DZDQF [REV] CHARACTER DETECT TESTS.
7. DZDQH [REV] CHARACTER LENGTH AND INTERRUPT TESTS.

THERE IS ALSO AN ONLINE TEST TO BE DISCUSSED LATER.
 1. DZDQO [REV] ONLINE TEST. (ITEP OVERLAY)

DZDQD MACY11 27(1006) 22-DEC-76 11:14 PAGE 4
 DZDQDD.P11 21-DEC-76 16:32

AND A PARAMETER INPUT PROGRAM IS AVAILABLE
 1. DZDQG [REV] DQ11 TRIAL PROGRAM (PARAMETER INPUT)

2. REQUIREMENTS

2.1 EQUIPMENT

ANY PDP11 FAMILY CPU (WITH MINIMUM 8K MEMORY)-WITH
 OR WITHOUT A HARDWARE SWITCH REGISTER (LOC. 177570)
 ASR 33 (OR EQUIVALENT)
 DQ11
 SYNC MODEM (ONLY REQUIRED FOR ONLINE TEST)

2.2 STORAGE

PROGRAM WILL LOAD AND RUN
 IN 8K OF MEMORY.
 LOCATION 1400 THRU 1600 ARE ESPECIALLY TO
 BE NOTED AND TO BE UNTOUCHED BY OPERATOR
 AFTER DQ11 TRIAL PROGRAM HAS BEEN EXECUTED.
 OR AFTER THE "AUTO SIZING" HAS BEEN DONE.

3. LOADING PROCEEDURE

3.1 METHOD

ALL PROGRAMS ARE IN ABSOLUTE FORMAT AND
 ARE LOADED USING THE ABSOLUTE LOADER.

ABSOLUTE LOADER STARTING ADDRESS #500

MEMORY *
 SIZE

4K	17
8K	37
12K	57
16K	77
20K	117
24K	137
28K	157

3.1.1 LOAD THE ADDRESS OF ABS. LOADER (LOC.XXX500)

3.1.2 THEN START

4. STARTING PROCEEDURE

A. LOAD LOC. 200
 B. SET SWR TO ZERO FOR "AUTO SIZING" OR LEAVE
 LEAVE SWR BIT 7=1 TO USE EXISTING PARAMETERS SET UP
 BY DQ11 TRIAL PROGRAM OR A PREVIOUSLY RUN DQ11 DIAGNOSTIC

DZDGD MACY11 27(1006) 22-DEC-76 11:14 PAGE 5
 DZDQDD.P11 21-DEC-76 16:32

THAT USED THE "AUTO SIZING".
 ****REFER TO SECTION 4.1 FOR SOFTWARE SWITCH REGISTER OPERATION
 AND OPTIONS.****
 NOTE: THE SOFTWARE SWITCH REGISTER IS LOCATED AT LOC.176
 SOFTWARE DISPLAY REGISTER IS LOCATED AT LOC.174

C. THEN START
 THE PROGRAM WILL TYPE MAINDEC NAME AND PROGRAM NAME
 IF THIS WAS THE FIRST START UP OF THE PROGRAM) AND ALSO
 THE FOLLOWING:

"MAP OF DQ11 STATUS"
 1400 160010
 1402 152300
 1404 160020
 1406 150310

THE ABOVE IS ONLY AN EXAMPLE!
 THIS WOULD INDICATE THE STATUS TABLE STARTING AT ADD.
 1400 IN THE PROGRAM. THE STATUS TABLE MUST BE VERIFIED BY THE
 USER IF AUTO SIZING IS DONE. FOR INFORMATION OF STATUS
 TABLE SEE SECTION 8.4 FOR HELP.

****IF THE SOFTWARE SWITCH REGISTER IS SELECTED THEN THE FOLLOWING
 WILL BE TYPED AFTER THE PROGRAM IDENTIFIES ITSELF:
 SWR=XXXXXX NEW= (REFER TO SECTION 4.1 FOR OPERATOR'S OPTION)****
 NOTE: IF USING THE SOFTWARE SWITCH REGISTER WHEN A HARDWARE
 SWITCH REGISTER IS AVAILABLE THE PROGRAM WILL NOT
 TYPE OUT THE TITLE.

THE PROGRAM WILL TYPE "R"
 AND PROCEED TO RUN THE DIAGNOSTIC

4.1 CONTROL SWITCH SETTINGS

IF THE DIAGNOSTIC IS RUN ON A CPU WITHOUT A SWITCH
 REGISTER THEN A SOFTWARE SWITCH REGISTER IS USED WHICH ALLOWS
 THE USER THE SAME SWITCH OPTIONS AS THE HARDWARE SWITCH REGISTER.
 IF THE HARDWARE SWITCH REGISTER DOES NOT EXIST OR IF ONE DOES
 AND IT CONTAINS ALL ONES (177777) THEN THE SOFTWARE SWITCH
 REGISTER (LOC. 176) IS USED.

CONTROL:

THIS PROGRAM ALSO SUPPORTS THE DYNAMIC LOADING OF THE SOFTWARE SWITCH
 REGISTER (LOC. 176) FROM THE TTY. THIS CAN BE ACCOMPLISHED BY
 DOING THE FOLLOWING:

- 1) TYPE CONTROL G (<1G>); THIS WILL ALLOW THE TTY TO ENTER DATA INTO
 LOC. 176 AT SELECTED POINTS WITHIN THE PROGRAM.
- 2) THE MACHINE WILL THEN TYPE: SWR=XXXXXXNEW= (XXXXXX IS THE OCTAL CONTENTS
 OF THE SOFTWARE SWITCH REGISTER.)

- 3) AFTER THE 'NEW=' HAS BEEN TYPED THEN THE OPERATOR CAN DO ONE OF THE FOLLOWING AT THE TTY:
- A) TYPE A NUMBER TO BE LOADED INTO LOC. 176 FOLLOWED BY A <CR>. (ONLY NUMBERS BETWEEN 0-7 WILL BE ACCEPTED AND ONLY 6 NUMBERS WILL BE ALLOWED) IF A <CR> IS THE FIRST KEY DEPRESSED THE SOFTWARE SWITCH REGISTER CONTENTS WILL NOT BE CHANGED.
 - B) IF A CONTROL U <↑U> IS DEPRESSED THEN THE PROGRAM WILL SEND YOU BACK TO STEP 2.

SW 15 SET: HALT ON ERROR
 SW 14 SET: LOOP ON CURRENT TEST
 SW 13 SET: INHIBIT ERROR PRINT OUT
 SW 12 SET: INHIBIT TYPE OUT/BELL ON ERROR.
 SW 11 SET: INHIBIT ITERATIONS
 SW 10 SET: ESCAPE TO NEXT TEST
 SW 09 SET: LOOP WITH CURRENT DATA
 SW 08 SET: CATCH ERROR AND LOOP ON IT
 SW 07 SET: USE PREVIOUS STATUS TABLE. CLR-DO AUTO SIZE.
 SW 06 SET:
 SW 05 SET:
 SW 04 SET:
 SW 03 SET:
 SW 02 SET: LOCK ON SELECTED TEST
 SW 01 SET: RESTART PROGRAM AT SELECTED TEST
 SW 00 SET: RESELECT DQ11'S DESIRED ACTIVE.

4.1.2 SWITCH REGISTER RESTRICTIONS

SW 00 RESELECT DQ11'S DESIRED ACTIVE.
 PLEASE NOTE THAT A MESSAGE IS TYPED OUT FOR SWITCH REGISTER BEING EQUAL TO DQ11'S ACTIVE. THIS MEANS IF THE SYSTEM HAS FOUR DQ11S; BITS 00,01,02,03 WILL BE SET IN LOC "DQACTV". USING THIS SWITCH ALTERS THAT LOCATION; THEREFORE IF FOUR DQ11S ARE IN THE SYSTEM ***DO NOT*** SET SWITCHS GREATER THAN SW 03 IN THE UP POSITION. THIS WOULD BE A FATAL ERROR. DO NOT SELECT MORE ACTIVE DQ11S THAN HAS BEEN GIVEN INFORMATION ABOUT IN TRIAL PROGRAM.

METHOD: A: LOAD ADDRESS 200
 B: START WITH SW 00=1
 C: PROGRAM WILL TYPE MESSAGE
 D: CONTINUE THE BINARY NUMBER OF DQ11S DESIRED ACTIVE
 EXAMPLE: 1=1 DQ11; 3=2 DQ11; 7=3 DQ11; 17=4 DQ11 37=5 DQ11 ETC.
 E: NUMBER (IF VALID) WILL BE IN DATA LIGHTS (EXCLUDING 11/05, 11/04, 11/34)
 F: CONTINUE WITH ANY OTHER SWITCH SETTINGS DESIRED.

SW 01 IT IS STRONGLY SUGGESTED THAT AT LEAST ONE PASS HAS BEEN MADE BEFORE TRYING TO SELECT A TEST

THAT IS NOT IN THE ORDER OF SEQUENCE
THE REASON BEING IS THAT THE
PROGRAM HAS TO CLEAR AREAS AND SET
UP PARAMETERS. ALSO WHEN A TEST IS
SELECTED ALWAYS START AT THE VERY
BEGINNING OF THAT TEST.

SW 09 LOOP ON CURRENT DATA:
THIS SWITCH WILL ONLY WORK IF
CALL "SCOPI" IS IN THAT TEST.
THE REASON BEING THAT MOST TESTS
DEAL WITH BLOCKS OF DIFFERENT DATA
TO BE SENT OR RECEIVED ALL AT ONCE
THUS IN BLOCK DATA; ONE PATTERN CANN'T BE SINGLED OUT.

4.1.3 SWITCH REGISTER PRIORITYS

ERROR SWITCHES

1. SW 12 DELETE PRINT OUT/BELL ON ERROR.
2. SW 13 DELETE ERROR PRINTOUT.
3. SW 15 HALT ON THE ERROR.
4. SW 08 GOTO BEGINNING OF THE TEST.
5. SW 10 GOTO NEXT TEST ON ERROR.

****HLT (ERROR) ROUTINE SUPPORTS <↑G> OPERATION****

SCOPE SWITCHES

1. SW 09 (IF ENABLED BY "SCOPI")
2. SW 14
3. SW 11

****SCOPE ROUTINE WILL SUPPORT <↑G> OPERATION****

4.2 STARTING ADDRESS

STARTING ADDRESS IS AT 000200
THERE ARE NO OTHER STARTING ADDRESSES
FOR THE DQ11 DIAGNOSTICS PREVIOUSLY MENTIONED

NOTE: IF ADDRESS 000042 IS NON-ZERO
THE PROGRAM ASSUMES IT IS UNDER
ACT11 OR DDP CONTROL AND WILL ACT ACCORDINGLY
AFTER *ALL* AVAILABLE DQ11'S ARE TESTED
THE PROGRAM WILL RETURN TO "DDP2" OR "ACT-11".

5. OPERATING PROCEDURE

WHEN PROGRAM IS INITIALLY STARTED MESSAGES AS DESCRIBED IN SECTION
FOUR WILL BE PRINTED.

AND PROGRAM WILL BEGIN RUNNING THE
DIAGNOSTIC

5.2 PROGRAM AND/OR OPERATOR ACTION

THE TYPICAL APPROACH SHOULD BE

1. HALT ON ERROR (VIA SW 15=1)
WHEN EVER AN ERROR OCCURS
2. CLEAR SW 15
3. SET SW 14: (LOOP ON THIS TEST)
4. SET SW 13: (INHIBIT ERROR PRINT OUT)

THE TEST NUMBER AND PC WILL BE TYPED OUT AND POSSIBLY AN ERROR MESSAGE (THIS DEPENDS ON THE TEST) TO GIVE THE OPERATOR AN IDEA AS TO THE SOURCE OF THE PROBLEM. IF IT IS NECESSARY TO KNOW MORE INFORMATION CONCERNING THE ERROR REPORT; LOOK IN THE LISTING FOR THAT TEST NUMBER WHICH WAS TYPED OUT AND THEN NOTE THE PC OF THE ERROR REPORT THIS WAY THE EXACT FUNCTIONING OF THE TEST CAN BE INTERPEDITED

6. ERRORS

AS DESCRIBED PREVIOUSLY THERE WILL ALWAYS BE A TEST NUMBER AND PC TYPED OUT AT THE TIME OF AN ERROR (PROVIDING SW 13=0 AND SW 12=0). IN MOST CASES ADDITIONAL INFORMATION WILL BE SUPPLIED THE THE ERROR MESSAGE WHICH IS TO GIVE THE OPERATOR AN INDICATION OF THE ERROR.

6.2 ERROR RECOVERY

IF FOR SOME REASON THE DQ11 SHOULD "HANG THE BUS" (GAIN CONTROL OF BUS SO THAT CONSOLE MANUAL FUNCTIONS ARE INHIBITED) AN INIT OR POWER DOWN/UP IS NECESSARY FOR OPERATOR TO REGAIN CONTROL OF CPU. IF THIS SHOULD HAPPEN; LOOK IN LOCATION "TSTNO" (ADDRESS 1226) FOR THE NUMBER OF THE TEST THAT WAS RUNNING AT THE TIME OF THE CATASTROPHIC ERROR.

IN THIS WAY THE OPERATOR WILL HAVE AN IDEA AS TO WHAT THE DQ11 WAS DOING AT THE TIME OF THE ERROR.

6.3 ****HALT RECOVERY WHEN USING SOFTWARE SWITCH REGISTER****

IF THE SOFTWARE SWITCH REGISTER IS TO BE CHANGED AFTER A HALT THE THE OPERATOR IS REQUIRED TO TYPE A <IG> BEFORE DEPRESSING CONTINUE. THE FOLLOWING WILL BE TYPED:
SWR=XXXXXX NEW= (REFER TO SECTION 4.1 FOR OPERATOR OPTION)

7. RESTRICTIONS

7.1 STARTING RESTRICTIONS

SEE SECTION 4. (PLEASE)

7.2 OPERATING RESTRICTIONS

DQ11 TRIAL PROGRAM MUST BE RUN PRIOR TO THE FIRST AND ONLY THE FIRST RUNNING OF ANY DQ11 DIAGNOSTIC

NOTE: IF NO PROGRAM OTHER THAN A DQ11 DIAGNOSTIC WAS LOADED AFTER DQ11 TRIAL OR IF CORE MEMORY HAS NOT BEEN CHANGED; OR IF THERE IS NO DQ11 CONFIGURATION CHANGES; THE DQ11 TRIAL PROGRAM NEED NEVER BE RUN AGAIN. HOWEVER IF ANY OF THE ABOVE HAVE BEEN VIOLATED THE DQ11 TRIAL PROGRAM MUST BE RUN AGAIN BEFORE RUNNING THE DIAGNOSTICS

NOTE: AN ALTERNATIVE TO THE ABOVE IS ATTEMPTING THE "AUTO SIZING" WHEN PROGRAM IS INITIALLY STARTED WITH SW07=0.

B. MISCELLANEOUS

B.1 EXECUTION TIME

B.2 PASS COMPLETE

WHEN THE DIAGNOSTIC HAS COMPLETED A PASS THE FOLLOWING IS AN EXAMPLE OF THE PRINT OUT TO BE EXPECTED.

END PASS DZDQD-D CSR: 160000 VEC: 300 PASSES: 000001 ERRORS: 000000

NOTE: THE NUMBERS FOR CSR AND VEC ARE NOT NECESSARILY THE VALUES FOR THE DEVICE THEY ARE ONLY FOR THIS EXAMPLE.

B.3 TST1 (MINI MONITOR)

THE VERY FIRST "TEST" (TST1) IS *NOT* A TEST OF THE DQ11 HARDWARE IT IS A MINI-MONITOR USED TO CYCLE DQ11 IN THE SYSTEM THROUGH THE DIAGNOSTIC.

REMEMBER: TST1 IS NOT A TEST OF DQ11 HARDWARE!!!!!!!

B.4 KEY LOCATIONS

RETURN (1214)	CONTAINS THE ADDRESS WHERE PROGRAM WILL RETURN WHEN ITERATION COUNT IS REACHED OR IF LOOP ON TEST IS ASSERTED.
NEXT (1216)	CONTAINS THE ADDRESS OF THE NEXT TEST TO BE PERFORMED.
TSTNO (1226)	CONTAINS THE NUMBER OF THE TEST NOW BEING PERFORMED.
RUN (1304)	THE BIT IN "RUN" ALWAYS POINTS ONE PAST THE DQ11 CURRENTLY BEING TESTED.

EXAMPLE:
(RUN) 1304/0000000001000000
MEANS THAT DQ11 NO.05 IS THE DQ11 NOW RUNNING.

DQCROO-DQCR17

DQST00-DQST17
(1400)-(1476)

THESE LOCATIONS CONTAIN THE INFORMATION NEEDED TO TEST UP TO 16 (DECIMAL) DQ11S SEQUENTIALLY. THEY CONTAIN THE CSR VECTOR AND STATUS CONCERNING THE CONFIGURATION OF EACH DQ11.

DQACTV (1500)

EACH BIT SET IN THIS LOCATION INDICATES THAT THE ASSOCIATED DQ11 WILL BE TESTED IN TURN.

EXAMPLE:

(DQACTV) 1500/0000000000011111

MEANS THAT DQ11 NO. 00,01,02,03,04 WILL BE TESTED.

EXAMPLE:

(DQACTV) 1500/0000000000010001

MEANS THAT DQ11 NO. 00,04 WILL BE TESTED.

DQCSR (1506)

CONTAINS THE RECEIVER CSR OF THE CURRENT DQ11 UNDER TEST.

DQSTAT (1510)

CONTAINS THE STATUS OF THE CURRENT DQ11 UNDER TEST.

BIT 15	SET:	TWO SYNC CHARS/ONE SYNC CHAR
BIT 14	SET:	TEST JUMPER INSTALLED/NOT INSTALLED
BIT 13	SET:	BB OPTION INSTALLED/NOT INSTALLED
BIT 12	SET:	BA OPTION INSTALLED/NOT INSTALLED
BIT 11	SET:	ACTIVE ON FIRST NON-SYNC/ACTIVE AFTER NO. OF SYNC
BIT 10	SET:	AB OPTION INSTALLED/NOT INSTALLED
BIT 09	SET:	ODD VRC/EVEN VRC
BIT 00-08		VECTOR "A" OF DEVICE

8.5 *** METHOD OF AUTO SIZING ***

8.5.1 FINDING THE CONTROL STATUS REGISTER.

WHEN LOOKING FOR THE CSR IT IS NECESSARY TO TAKE CARE THAT WHEN A CSR IS FOUND THAT IT IS INDEED A DQ11. THAT IS THE METHOD OF MY MADNESS FOR THIS ROUTINE. AN ATTEMPT TO CLEAR THE MISC. REGISTER IS TRIED IF A TIME-OUT TRAP OCCURS POINTERS ARE UPDATED AND ATTEMPTED AGAIN. IF NO TIME-OUT; THE RECEIVER "ACTIVE BIT" (BIT 12) IS SET AND A #COMPARE# FOR BOTH SYNC1 AND SYNC 2 IS DONE AT THE MISC. REGISTER. IF THEY ARE THERE THIS IS A DQ11. THE INFORMATION IS STORED AWAY.

8.5.2 ONE SYNC BIT OR TWO?

SINCE TOO MUCH HARDWARE MUST BE TURNED ON TO SENSE THE PRESENTS OF ONE SYNC OR TWO. THE PROGRAM ASSUMES TWO SYNC CHARS. NOTE: THIS ASSUMPTION MAY BE ALTERED AFTER AUTO SIZING BY ALTERING BIT 15 IN APPRIORATE DQSTXX: LOCATION.

8.5.3 "BB" OPTION INSTALLED?

TO SENSE FOR THE "BB" OPTION THE PROGRAM SELECTS THE CHARACTER DET. REGISTER AND THE LOADS IN ALL 1'S; IF

ANY ONE OR COMBINATION OF BITS ARE SET THE BB OPTION IS ASSUMED TO EXIST.

8.5.4 "AB" OPTION INSTALLED?

TO SENSE FOR THE "AB" OPTION THE PROGRAM SELECTS THE POLYNOMIAL REGISTER AND WRITES ALL 1'S INTO IT; IF ANY ONE OR COMBINATION OF BITS ARE SET THE AB OPTION IS ASSUMED TO EXIST.

8.5.5 "BA" OPTION INSTALLED?

TO SENSE FOR "BA" OPTION REQUEST TO SEND AND DATA TERMINAL READY ARE SET; IF EITHER ONE OR BOTH ARE SET THE PROGRAM ASSUMES THE BA OPTION EXISTS

8.5.6 JUMPER ON END OF CABLE?

THE PROGRAM CHECKS TO SEE IF EITHER OR BOTH CLEAR TO SEND AND CARRIER ARE SET; IF SO THE PROGRAM ASSUMES THE TEST JUMPER IS ON THE END OF THE CABLE.

8.5.7 ACTIVE ON FIRST NON-SYNC?

SINCE TOO MUCH HARDWARE MUST BE TURNED ON TO SENSE FOR WHEN THE DQ11 GOES ACTIVE THE PROGRAM ASSUMES "ACTIVE ON FIRST NON-SYNC". NOTE: THIS CAN BE CHANGED BY ALTERING BIT 11 IN THE APPRIORATE DQSTXX: AFTER AUTO SIZING

8.5.8 SET FOR ODD OR EVEN PARITY?

AS ABOVE TOO MUCH HARDWARE IS NEED TO SENSE WHICH PARITY WAS SELECTED. SO THE PROGRAM ASSEMES ODD PARITY. NOTE: THIS CAN BE CHANGED BY ALTERING BIT 9 IN APPRIORATE DQSTXX: LOCATION. AFTER AUTO SIZING

8.5.9 FINDING THE VECTOR.

THE PROGRAM SETS "PRIMARY DONE", "SECONDAY DONE", AND "INTERUPT ENABLE" AND LOOKS FOR AN INTERUPT. IF IT INTERUPTS IT IS PICKED UP AND STORED AWAY. IF NO INTERUPT OCCURES THE PROGRAM ASSUMES VECTOR =300. THIS PROBLEM WILL BE FIXED IN ONE OF THE DIAGNOSTICS AND #AUTO SIZING# SHOULD BE REDONE TO GET THE CORRECT VECTOR.

9. PROGRAM DESCRIPTION

CONTAINED WITHIN LISTING

10. LISTING

FOLLOWING

DZDGD MACY11 27(1006) 22-DEC-76 11:14 PAGE 12
DZDQDD.P11 21-DEC-76 16:32

MO1

DZDQD MACY11 27(1006) 22-DEC-76 11:14 PAGE 13
 DZDQDD.P11 21-DEC-76 16:32

```

549 .ENABLE AMA
550
551 ;MAINDEC-11-DZDQD-D/<377>/TRANSMITTER AND RECEIVER EXERCISER
552 ;COPYRIGHT 1975, DIGITAL EQUIPMENT CORP., MAYNARD, MASS. 01754
553
554 ;REVISED 16-DEC-76 BY R. BLACK
555 ;A)SUPPORTS SOFTWARE SWITCH REGISTER
556 ;B)SUPPORTS THE DYNAMIC LOADING OF THE SOFTWARE SWITCH REGISTER
557 ;BY <↑G>.
558 ;STARTING PROCEDURE
559 ;LOAD PROGRAM
560 ;LOAD ADDRESS 000200
561 ;PRESS START
562 ;PROGRAM WILL TYPE "MAINDEC-11-DZDQD-D/<377>/TRANSMITTER AND RECEIVER EXERCISER"
563 ;PROGRAM WILL TYPE "R" TO INDICATE THAT TESTING HAS STARTED
564 ;AT THE END OF A PASS, PROGRAM WILL TYPE PASS COMPLETE MESSAGE
565 ;AND THEN RESUME TESTING
566
567
568 ;SWITCH REGISTER OPTIONS
569
570 100000 SW15=100000 ;=1, HALT ON ERROR
571 040000 SW14=40000 ;=1, LOOP ON CURRENT TEST
572 020000 SW13=20000 ;=1, INHIBIT ERROR TYPEOUT
573 010000 SW12=10000 ;=1, DELETE TYPEOUT/BELL ON ERROR.
574 004000 SW11=4000 ;=1, INHIBIT ITERATIONS
575 002000 SW10=2000 ;=1, ESCAPE TO NEXT TEST ON ERROR
576 001000 SW09=1000 ;=1, LOOP WITH CURRENT DATA
577 000400 SW08=400 ;=1, LOOP ON ERROR
578 000100 SW06=100
579 000040 SW05=40
580 000020 SW04=20
581 000010 SW03=10
582 000004 SW02=4
583 000002 SW01=2
584 000001 SW00=1
585
;LOCK ON TEST SELECT
;RESTART PROGRAM AT SELECTED TEST
;RESELECT DQ11 DESIRED ACTIVE
;NOTE: THIS MUST NOT EXCEED ORIGINAL COUNT

```



```

586
587
588           ;REGISTER DEFINITIONS
589
590           000000      R0=%0           ;GENERAL REGISTER
591           000001      R1=%1           ;GENERAL REGISTER
592           000002      R2=%2           ;GENERAL REGISTER
593           000003      R3=%3           ;GENERAL REGISTER
594           000004      R4=%4           ;GENERAL REGISTER
595           000005      R5=%5           ;GENERAL REGISTER
596           000006      SP=%6          ;PROCESSOR STACK POINTER
597           000007      PC=%7          ;PROGRAM COUNTER
598
599           ;LOCATION EQUIVALENCIES
600
601           177570      DSWR= 177570    ;HARDWARE SWITCH REGISTER LOC.
602           177570      DLIGHTS=177570 ;HARDWARE DISPLAY REGISTER LOC.
603           177776      PS=177776     ;PROCESSOR STATUS WORD
604           001200      STACK=1200     ;START OF PROCESSOR STACK
605
606           ;INSTRUCTION DEFINITIONS
607
608           005746      PUSH1SP=5746    ;DECREMENT PROCESSOR STACK 1 WORD
609           005726      POP1SP=5726    ;INCREMENT PROCESSOR STACK 1 WORD
610           010046      PUSHRO=10046   ;SAVE R0 ON STACK
611           012600      POPRO=12600    ;RESTORE R0 FROM STACK
612           024646      PUSH2SP=24646  ;DECREMENT STACK TWICE
613           022626      POP2SP=22626   ;INCREMENT STACK TWICE
614           .EQUIV ENT,MLT ;BASIC DEFINITION OF ERROR CALL
615
616
617           100000      BIT15=100000
618           040000      BIT14=40000
619           020000      BIT13=20000
620           010000      BIT12=10000
621           004000      BIT11=4000
622           002000      BIT10=2000
623           001000      BIT9=1000
624           000400      BIT8=400
625           000200      BIT7=200
626           000100      BIT6=100
627           000040      BIT5=40
628           000020      BIT4=20
629           000010      BIT3=10
630           000004      BIT2=4
631           000002      BIT1=2
632           000001      BIT0=1
633
634           ;DQ11 OPTIONAL DEFINITIONS
635
636
637           002000      ABBIT=2000
638           004000      ACTBIT=4000
639           010000      BABIT=10000
640           020000      BBBIT=20000
641           040000      JUMBIT=40000

```

DZD00 MACY11 27(1006) 22-DEC-76 11:14 PAGE 15
 DZD00.P11 21-DEC-76 16:32 GENERAL DEFINATIONS AND EQUIVALENCIES

642	001000	ODDBIT=1000	
643	100000	SYNBIT=100000	
644			
645			
646			
647			
648	000000		
649	000001		
650	000002		
651	000003		
652	000004		
653	000005		
654	000006		
655	000007		
656			
657	000010		
658	000011		
659	000012		
660	000013		
661	000014		
662	000015		
663	000016		
664	000017		
665			
666			

;DQ11 SECONDARY REGISTER DEFINATIONS

RXBA.P=0	:RECEIVER BUS ADDRESS PRIMARY.
RXWC.P=1	:RECEIVER WORD COUNT PRIMARY.
TXBA.P=2	:TRANSMITTER BUS ADDRESS PRIMARY.
TXWC.P=3	:TRANSMITTER BUS ADDRESS PRIMARY.
RXBA.S=4	:RECEIVER BUS ADDRESS SECONDARY.
RXWC.S=5	:RECEIVER WORD COUNT SECONDARY.
TXBA.S=6	:TRANSMITTER BUS ADDRESS SECONDARY.
TXWC.S=7	:TRANSMITTER WORD COUNT SECONDARY.
CHARDT=10	:CHARACTER DETECT REGISTER.
SYNC.=11	:SYNC REGISTER.
MISC.=12	:MISCELLANEOUS REGISTER.
TX.MUX=13	:TRANSMITTER MUX REGISTER.
SEQ.=14	:SEQUENCE REGISTER.
RX.BCC=15	:RECEIVER BCC REGISTER.
TX.BCC=16	:TRANSMITTER BCC REGISTER.
POLY.=17	:POLYNOMIAL REGISTER.

723	000154	000156	.+2	:UNEXPECTED TRAP TO THIS LOCATION
724	000156	000000	HALT	:EXAMINE STACK TO FIND CAUSE
725	000160	000162	.+2	:UNEXPECTED TRAP TO THIS LOCATION
726	000162	000000	HALT	:EXAMINE STACK TO FIND CAUSE
727	000164	000166	.+2	:UNEXPECTED TRAP TO THIS LOCATION
728	000166	000000	HALT	:EXAMINE STACK TO FIND CAUSE
729	000170	000172	.+2	:UNEXPECTED TRAP TO THIS LOCATION
730	000172	000000	HALT	:EXAMINE STACK TO FIND CAUSE
731	000174	000176	.+2	:UNEXPECTED TRAP TO THIS LOCATION
732	000176	000000	HALT	:EXAMINE STACK TO FIND CAUSE
733	000200	000202	.+2	:UNEXPECTED TRAP TO THIS LOCATION
734	000202	000000	HALT	:EXAMINE STACK TO FIND CAUSE
735	000204	000206	.+2	:UNEXPECTED TRAP TO THIS LOCATION
736	000206	000000	HALT	:EXAMINE STACK TO FIND CAUSE
737	000210	000212	.+2	:UNEXPECTED TRAP TO THIS LOCATION
738	000212	000000	HALT	:EXAMINE STACK TO FIND CAUSE
739	000214	000216	.+2	:UNEXPECTED TRAP TO THIS LOCATION
740	000216	000000	HALT	:EXAMINE STACK TO FIND CAUSE
741	000220	000222	.+2	:UNEXPECTED TRAP TO THIS LOCATION
742	000222	000000	HALT	:EXAMINE STACK TO FIND CAUSE
743	000224	000226	.+2	:UNEXPECTED TRAP TO THIS LOCATION
744	000226	000000	HALT	:EXAMINE STACK TO FIND CAUSE
745	000230	000232	.+2	:UNEXPECTED TRAP TO THIS LOCATION
746	000232	000000	HALT	:EXAMINE STACK TO FIND CAUSE
747	000234	000236	.+2	:UNEXPECTED TRAP TO THIS LOCATION
748	000236	000000	HALT	:EXAMINE STACK TO FIND CAUSE
749	000240	000242	.+2	:UNEXPECTED TRAP TO THIS LOCATION
750	000242	000000	HALT	:EXAMINE STACK TO FIND CAUSE
751	000244	000246	.+2	:UNEXPECTED TRAP TO THIS LOCATION
752	000246	000000	HALT	:EXAMINE STACK TO FIND CAUSE
753	000250	000252	.+2	:UNEXPECTED TRAP TO THIS LOCATION
754	000252	000000	HALT	:EXAMINE STACK TO FIND CAUSE
755	000254	000256	.+2	:UNEXPECTED TRAP TO THIS LOCATION
756	000256	000000	HALT	:EXAMINE STACK TO FIND CAUSE
757	000260	000262	.+2	:UNEXPECTED TRAP TO THIS LOCATION
758	000262	000000	HALT	:EXAMINE STACK TO FIND CAUSE
759	000264	000266	.+2	:UNEXPECTED TRAP TO THIS LOCATION
760	000266	000000	HALT	:EXAMINE STACK TO FIND CAUSE
761	000270	000272	.+2	:UNEXPECTED TRAP TO THIS LOCATION
762	000272	000000	HALT	:EXAMINE STACK TO FIND CAUSE
763	000274	000276	.+2	:UNEXPECTED TRAP TO THIS LOCATION
764	000276	000000	HALT	:EXAMINE STACK TO FIND CAUSE
765	000300	000302	.+2	:UNEXPECTED TRAP TO THIS LOCATION
766	000302	000000	HALT	:EXAMINE STACK TO FIND CAUSE
767	000304	000306	.+2	:UNEXPECTED TRAP TO THIS LOCATION
768	000306	000000	HALT	:EXAMINE STACK TO FIND CAUSE
769	000310	000312	.+2	:UNEXPECTED TRAP TO THIS LOCATION
770	000312	000000	HALT	:EXAMINE STACK TO FIND CAUSE
771	000314	000316	.+2	:UNEXPECTED TRAP TO THIS LOCATION
772	000316	000000	HALT	:EXAMINE STACK TO FIND CAUSE
773	000320	000322	.+2	:UNEXPECTED TRAP TO THIS LOCATION
774	000322	000000	HALT	:EXAMINE STACK TO FIND CAUSE
775	000324	000326	.+2	:UNEXPECTED TRAP TO THIS LOCATION
776	000326	000000	HALT	:EXAMINE STACK TO FIND CAUSE
777	000330	000332	.+2	:UNEXPECTED TRAP TO THIS LOCATION
778	000332	000000	HALT	:EXAMINE STACK TO FIND CAUSE

DZDGD MACY11 27(1006) 22-DEC-76 11:14 PAGE 18
 DZDGD.P11 21-DEC-76 16:32 TRAPCATCHER FOR UNEXPECTED INTERRUPTS

779	000334	000336	.+2	:UNEXPECTED TRAP TO THIS LOCATION
780	000336	000000	HALT	:EXAMINE STACK TO FIND CAUSE
781	000340	000342	.+2	:UNEXPECTED TRAP TO THIS LOCATION
782	000342	000000	HALT	:EXAMINE STACK TO FIND CAUSE
783	000344	000346	.+2	:UNEXPECTED TRAP TO THIS LOCATION
784	000346	000000	HALT	:EXAMINE STACK TO FIND CAUSE
785	000350	000352	.+2	:UNEXPECTED TRAP TO THIS LOCATION
786	000352	000000	HALT	:EXAMINE STACK TO FIND CAUSE
787	000354	000356	.+2	:UNEXPECTED TRAP TO THIS LOCATION
788	000356	000000	HALT	:EXAMINE STACK TO FIND CAUSE
789	000360	000362	.+2	:UNEXPECTED TRAP TO THIS LOCATION
790	000362	000000	HALT	:EXAMINE STACK TO FIND CAUSE
791	000364	000366	.+2	:UNEXPECTED TRAP TO THIS LOCATION
792	000366	000000	HALT	:EXAMINE STACK TO FIND CAUSE
793	000370	000372	.+2	:UNEXPECTED TRAP TO THIS LOCATION
794	000372	000000	HALT	:EXAMINE STACK TO FIND CAUSE
795	000374	000376	.+2	:UNEXPECTED TRAP TO THIS LOCATION
796	000376	000000	HALT	:EXAMINE STACK TO FIND CAUSE
797	000400	000402	.+2	:UNEXPECTED TRAP TO THIS LOCATION
798	000402	000000	HALT	:EXAMINE STACK TO FIND CAUSE
799	000404	000406	.+2	:UNEXPECTED TRAP TO THIS LOCATION
800	000406	000000	HALT	:EXAMINE STACK TO FIND CAUSE
801	000410	000412	.+2	:UNEXPECTED TRAP TO THIS LOCATION
802	000412	000000	HALT	:EXAMINE STACK TO FIND CAUSE
803	000414	000416	.+2	:UNEXPECTED TRAP TO THIS LOCATION
804	000416	000000	HALT	:EXAMINE STACK TO FIND CAUSE
805	000420	000422	.+2	:UNEXPECTED TRAP TO THIS LOCATION
806	000422	000000	HALT	:EXAMINE STACK TO FIND CAUSE
807	000424	000426	.+2	:UNEXPECTED TRAP TO THIS LOCATION
808	000426	000000	HALT	:EXAMINE STACK TO FIND CAUSE
809	000430	000432	.+2	:UNEXPECTED TRAP TO THIS LOCATION
810	000432	000000	HALT	:EXAMINE STACK TO FIND CAUSE
811	000434	000436	.+2	:UNEXPECTED TRAP TO THIS LOCATION
812	000436	000000	HALT	:EXAMINE STACK TO FIND CAUSE
813	000440	000442	.+2	:UNEXPECTED TRAP TO THIS LOCATION
814	000442	000000	HALT	:EXAMINE STACK TO FIND CAUSE
815	000444	000446	.+2	:UNEXPECTED TRAP TO THIS LOCATION
816	000446	000000	HALT	:EXAMINE STACK TO FIND CAUSE
817	000450	000452	.+2	:UNEXPECTED TRAP TO THIS LOCATION
818	000452	000000	HALT	:EXAMINE STACK TO FIND CAUSE
819	000454	000456	.+2	:UNEXPECTED TRAP TO THIS LOCATION
820	000456	000000	HALT	:EXAMINE STACK TO FIND CAUSE
821	000460	000462	.+2	:UNEXPECTED TRAP TO THIS LOCATION
822	000462	000000	HALT	:EXAMINE STACK TO FIND CAUSE
823	000464	000466	.+2	:UNEXPECTED TRAP TO THIS LOCATION
824	000466	000000	HALT	:EXAMINE STACK TO FIND CAUSE
825	000470	000472	.+2	:UNEXPECTED TRAP TO THIS LOCATION
826	000472	000000	HALT	:EXAMINE STACK TO FIND CAUSE
827	000474	000476	.+2	:UNEXPECTED TRAP TO THIS LOCATION
828	000476	000000	HALT	:EXAMINE STACK TO FIND CAUSE
829	000500	000502	.+2	:UNEXPECTED TRAP TO THIS LOCATION
830	000502	000000	HALT	:EXAMINE STACK TO FIND CAUSE
831	000504	000506	.+2	:UNEXPECTED TRAP TO THIS LOCATION
832	000506	000000	HALT	:EXAMINE STACK TO FIND CAUSE
833	000510	000512	.+2	:UNEXPECTED TRAP TO THIS LOCATION
834	000512	000000	HALT	:EXAMINE STACK TO FIND CAUSE

DZD00 MACY11 27(1006) 22-DEC-76 11:14 PAGE 19
 DZD000.P11 21-DEC-76 16:32

TRAPCATCHER FOR UNEXPECTED INTERRUPTS

835	000514	000516	.+2	:UNEXPECTED TRAP TO THIS LOCATION
836	000516	000000	HALT	:EXAMINE STACK TO FIND CAUSE
837	000520	000522	.+2	:UNEXPECTED TRAP TO THIS LOCATION
838	000522	000000	HALT	:EXAMINE STACK TO FIND CAUSE
839	000524	000526	.+2	:UNEXPECTED TRAP TO THIS LOCATION
840	000526	000000	HALT	:EXAMINE STACK TO FIND CAUSE
841	000530	000532	.+2	:UNEXPECTED TRAP TO THIS LOCATION
842	000532	000000	HALT	:EXAMINE STACK TO FIND CAUSE
843	000534	000536	.+2	:UNEXPECTED TRAP TO THIS LOCATION
844	000536	000000	HALT	:EXAMINE STACK TO FIND CAUSE
845	000540	000542	.+2	:UNEXPECTED TRAP TO THIS LOCATION
846	000542	000000	HALT	:EXAMINE STACK TO FIND CAUSE
847	000544	000546	.+2	:UNEXPECTED TRAP TO THIS LOCATION
848	000546	000000	HALT	:EXAMINE STACK TO FIND CAUSE
849	000550	000552	.+2	:UNEXPECTED TRAP TO THIS LOCATION
850	000552	000000	HALT	:EXAMINE STACK TO FIND CAUSE
851	000554	000556	.+2	:UNEXPECTED TRAP TO THIS LOCATION
852	000556	000000	HALT	:EXAMINE STACK TO FIND CAUSE
853	000560	000562	.+2	:UNEXPECTED TRAP TO THIS LOCATION
854	000562	000000	HALT	:EXAMINE STACK TO FIND CAUSE
855	000564	000566	.+2	:UNEXPECTED TRAP TO THIS LOCATION
856	000566	000000	HALT	:EXAMINE STACK TO FIND CAUSE
857	000570	000572	.+2	:UNEXPECTED TRAP TO THIS LOCATION
858	000572	000000	HALT	:EXAMINE STACK TO FIND CAUSE
859	000574	000576	.+2	:UNEXPECTED TRAP TO THIS LOCATION
860	000576	000000	HALT	:EXAMINE STACK TO FIND CAUSE
861	000600	000602	.+2	:UNEXPECTED TRAP TO THIS LOCATION
862	000602	000000	HALT	:EXAMINE STACK TO FIND CAUSE
863	000604	000606	.+2	:UNEXPECTED TRAP TO THIS LOCATION
864	000606	000000	HALT	:EXAMINE STACK TO FIND CAUSE
865	000610	000612	.+2	:UNEXPECTED TRAP TO THIS LOCATION
866	000612	000000	HALT	:EXAMINE STACK TO FIND CAUSE
867	000614	000616	.+2	:UNEXPECTED TRAP TO THIS LOCATION
868	000616	000000	HALT	:EXAMINE STACK TO FIND CAUSE
869	000620	000622	.+2	:UNEXPECTED TRAP TO THIS LOCATION
870	000622	000000	HALT	:EXAMINE STACK TO FIND CAUSE
871	000624	000626	.+2	:UNEXPECTED TRAP TO THIS LOCATION
872	000626	000000	HALT	:EXAMINE STACK TO FIND CAUSE
873	000630	000632	.+2	:UNEXPECTED TRAP TO THIS LOCATION
874	000632	000000	HALT	:EXAMINE STACK TO FIND CAUSE
875	000634	000636	.+2	:UNEXPECTED TRAP TO THIS LOCATION
876	000636	000000	HALT	:EXAMINE STACK TO FIND CAUSE
877	000640	000642	.+2	:UNEXPECTED TRAP TO THIS LOCATION
878	000642	000000	HALT	:EXAMINE STACK TO FIND CAUSE
879	000644	000646	.+2	:UNEXPECTED TRAP TO THIS LOCATION
880	000646	000000	HALT	:EXAMINE STACK TO FIND CAUSE
881	000650	000652	.+2	:UNEXPECTED TRAP TO THIS LOCATION
882	000652	000000	HALT	:EXAMINE STACK TO FIND CAUSE
883	000654	000656	.+2	:UNEXPECTED TRAP TO THIS LOCATION
884	000656	000000	HALT	:EXAMINE STACK TO FIND CAUSE
885	000660	000662	.+2	:UNEXPECTED TRAP TO THIS LOCATION
886	000662	000000	HALT	:EXAMINE STACK TO FIND CAUSE
887	000664	000666	.+2	:UNEXPECTED TRAP TO THIS LOCATION
888	000666	000000	HALT	:EXAMINE STACK TO FIND CAUSE
889	000670	000672	.+2	:UNEXPECTED TRAP TO THIS LOCATION
890	000672	000000	HALT	:EXAMINE STACK TO FIND CAUSE

891	000674	000676	.+2	:UNEXPECTED TRAP TO THIS LOCATION
892	000676	000000	HALT	:EXAMINE STACK TO FIND CAUSE
893	000700	000702	.+2	:UNEXPECTED TRAP TO THIS LOCATION
894	000702	000000	HALT	:EXAMINE STACK TO FIND CAUSE
895	000704	000706	.+2	:UNEXPECTED TRAP TO THIS LOCATION
896	000706	000000	HALT	:EXAMINE STACK TO FIND CAUSE
897	000710	000712	.+2	:UNEXPECTED TRAP TO THIS LOCATION
898	000712	000000	HALT	:EXAMINE STACK TO FIND CAUSE
899	000714	000716	.+2	:UNEXPECTED TRAP TO THIS LOCATION
900	000716	000000	HALT	:EXAMINE STACK TO FIND CAUSE
901	000720	000722	.+2	:UNEXPECTED TRAP TO THIS LOCATION
902	000722	000000	HALT	:EXAMINE STACK TO FIND CAUSE
903	000724	000726	.+2	:UNEXPECTED TRAP TO THIS LOCATION
904	000726	000000	HALT	:EXAMINE STACK TO FIND CAUSE
905	000730	000732	.+2	:UNEXPECTED TRAP TO THIS LOCATION
906	000732	000000	HALT	:EXAMINE STACK TO FIND CAUSE
907	000734	000736	.+2	:UNEXPECTED TRAP TO THIS LOCATION
908	000736	000000	HALT	:EXAMINE STACK TO FIND CAUSE
909	000740	000742	.+2	:UNEXPECTED TRAP TO THIS LOCATION
910	000742	000000	HALT	:EXAMINE STACK TO FIND CAUSE
911	000744	000746	.+2	:UNEXPECTED TRAP TO THIS LOCATION
912	000746	000000	HALT	:EXAMINE STACK TO FIND CAUSE
913	000750	000752	.+2	:UNEXPECTED TRAP TO THIS LOCATION
914	000752	000000	HALT	:EXAMINE STACK TO FIND CAUSE
915	000754	000756	.+2	:UNEXPECTED TRAP TO THIS LOCATION
916	000756	000000	HALT	:EXAMINE STACK TO FIND CAUSE
917	000760	000762	.+2	:UNEXPECTED TRAP TO THIS LOCATION
918	000762	000000	HALT	:EXAMINE STACK TO FIND CAUSE
919	000764	000766	.+2	:UNEXPECTED TRAP TO THIS LOCATION
920	000766	000000	HALT	:EXAMINE STACK TO FIND CAUSE
921	000770	000772	.+2	:UNEXPECTED TRAP TO THIS LOCATION
922	000772	000000	HALT	:EXAMINE STACK TO FIND CAUSE
923	000774	000776	.+2	:UNEXPECTED TRAP TO THIS LOCATION
924	000776	000000	HALT	:EXAMINE STACK TO FIND CAUSE

```

925                                     ;STANDARD INTERRUPT VECTORS
926
927                                     . =24
928 000024 017042                       .PFAIL                       ;POWER FAIL HANDLER
929 000026 000340                       340                          ;SERVICE AT LEVEL 7
930 000030 016512                       .HLT                           ;ERROR HANDLER
931 000032 000340                       340                          ;SERVICE AT LEVEL 7
932 000034 016460                       .TRPSRV                        ;GENERAL HANDLER DISPATCH SERVICE
933 000036 000340                       340                          ;SERVICE AT LEVEL 7
934
935 000046 015240                       . =46                          LOGICAL                       ;ACT HOOKS
936
937 000052 000000                       . =52                          .WORD 0
938                                     ;THIS ROUTINE TRIES TO FORCE THE RECEIVER TO INTERRUPT
939                                     ;TO ITS VECTOR WHERE IT WILL PICK UP THE STATUS LOCATION
940                                     ;FOR ITS NEW PC; AND PICK UP AN IOT INSTRUCTION FOR ITS
941                                     ;NEW PS. WHEN THE NEW PC IS FETCHED AN IOT INSTRUCTION IS
942                                     ;EXECUTED, TRAPPING TO LOCATION 20 WHERE A ROUTINE IS EXECUTED
943                                     ;TO TAKE THE PC FROM THE STACK AND US IT AS THE VECTOR ADDRESS
944                                     . =56
945
946 000056
947 000056 010120                       VECMAP:
948 000060 012721 000004                1$:  MOV      R1,(R0)+           ;START FILLING THE VECTOR AREA
949 000064 022021                       MOV      #4,(R1)+           ;WITH +2; IOT (4)
950 000066 020127 001000                CMP      (R0)+,(R1)+       ;UPDATE THE POINTERS
951 000072 101771                       CMP      R1,#1000          ;IS ALL FLOATING VECTOR AREA DONE
952 000074 012737 000146 000020        BLOS    1$                 ;BR IF NOT ALL DONE
953 000102 013737 001500 001244        MOV      #45,2#20          ;SET FOR IOT TRAP BY DQ11
954 000110 006037 001244                MOV      DQACTV,TEMP1      ;GET THE ACTIVE DQ11 S
955 000114 103023                       2$:  ROR      TEMP1          ;ARE YOU ACTIVE.. DQ11
956 000116 005037 177776                BCC     5$                 ;IF CARRY CLEAR.. NO MORE DQ11S
957 000122 005722                       CLR     PS                  ;CLEAR PS
958 000124 012772 000340 177776        TST     (R2)+              ;PUT POINTER TO STATUS TABLE
959 000132 105200                       MOV     #340,2-2(R2)       ;TRY AND SET PRI/SEC DONE AND IE
960 000134 001376                       INCB    RO                  ;DELAY.....
961 000136 112712 000300                BNE     -2                 ;.....DELAY
962 000142 005722                       MOV     #300,(R2)          ;NO INTERRUPT ASSUME 300 FIX IN TEST C
963 000144 000761                       3$:  TST     (R2)+           ;UPDATE POINTERS
964 000146 051612                       BR      2$                 ;GO DO IT AGAIN
965 000150 042712 000007                4$:  BIS     (SP),(R2)       ;ENTERD BY IOT TRAP BY DQ11
966 000154 022626                       BIC     #7,(R2)           ;CLEAR UNWANTED BITS
967 000156 012716 000142                CMP     (SP)+,(SP)+       ;POP IOT JUNK OFF STACK
968 000162 000002                       MOV     #3$, (SP)         ;SET RETURN PC ON STACK
969 000164 000207                       RTI                          ;GO HOME
970
971                                     ;****SOFTWARE SWITCH REGISTER****
972                                     . =174
973 000174 000000                       DISPREG: 0                   ;SOFTWARE DISPLAY REGISTER
974 000176 000000                       SWREG:   0                   ;SOFTWARE SWITCH REGISTER
975
976                                     ;PROGRAM START
977
978                                     . =200
979 000200 000137 001512                JMP     .START             ;GO TO START OF PROGRAM
980
    
```


981		000220			.=220					
982	000220	012702	001400		CSRMAP:	MOV	#1400,R2	:	CLEAR ALL STATUS TABLE	
983	000224	005022				CLR	(R2)+	:	DO CLEAR	
984	000226	022702	001512			CMP	#1512,R2	:	ALL TABLE DONE	
985	000232	001374				BNE	-6	:	BR IF MORE TO GO	
986	000234	005037	001504			CLR	DQNUM	:	SET NUMBER OF DQ11S TO 0	
987	000240	012702	001400			MOV	#1400,R2	:	SET TABLE POINTER	
988	000244	012701	160000			MOV	#160000,R1	:	GET FIRST FLOATING ADDRESS	
989	000250	012737	000614	000004		MOV	#55,3#4	:	SET FOR TIME OUT TRAP--NO DEVICE--	
990	000256	112761	000012	000005	1S:	MOVB	#12,5(R1)	:	TRY AND SEL MISC REGISTER	
991	000264	005061	000006			CLR	6(R1)	:	TRY AND CLEAR MISC REG	
992	000270	012711	010000			MOV	#10000,(R1)	:	TRY AND SET RX ACTIVE	
993	000274	022761	030000	000006		CMP	#30000,6(R1)	:	LOOK FOR SYNC 1 AND SYNC 2	
994	000302	001071				BNE	2\$:	THIS IS NOT A DQ11 IF I BRANCH	
995	000304	010122				MOV	R1,(R2)+	:	NOW THIS IS A DQ11 --STORE CSR	
996	000306	052712	100000			BIS	#SYMBIT,(R2)	:	SET FOR TWO SYNC CHARS	
997	000312	005011				CLR	(R1)	:	CLEAR DQ ACTIVE BIT	
998	000314	112761	000010	000005		MOVB	#10,5(R1)	:	SEL CHAR DET REGISTER	
999	000322	012761	177777	000006		MOV	#-1,6(R1)	:	WRITE INTO CHAR DET REG	
1000	000330	005761	000006			TST	6(R1)	:	WAS THE REGISTER WRITTEN?	
1001	000334	001402				BEQ	+6	:	APPARENTLY NO BB OPTION.	
1002	000336	052712	020000			BIS	#BBBIT,(R2)	:	SET FOR BB OPTION	
1003	000342	112761	000017	000005		MOVB	#17,5(R1)	:	SEL POLYNO. REGISTER	
1004	000350	012761	177777	000006		MOV	#-1,6(R1)	:	WRITE POLYNO.REGISTER	
1005	000356	005761	000006			TST	6(R1)	:	WAS REG WRITTEN??	
1006	000362	001402				BEQ	+6	:	BR IF NO AB OPTION	
1007	000364	052712	002000			BIS	#ABBIT,(R2)	:	SET FOR AB OPTION	
1008	000370	012761	001400	000002		MOV	#1400,2(R1)	:	TRY TO SET .DTR. .RS.	
1009	000376	032761	001400	000002		BIT	#1400,2(R1)	:	DID ANY OF THEM SET	
1010	000404	001402				BEQ	+6	:	BR IF NO BA OPTION	
1011	000406	052712	010000			BIS	#BABBIT,(R2)	:	SET FOR BA OPTION	
1012	000412	032761	030000	000002		BIT	#30000,2(R1)	:	DID .CS. .CO. SET	
1013	000420	001402				BEQ	+6	:	BR IF NO JUMPER	
1014	000422	052712	040000			BIS	#JUMBIT,(R2)	:	SET FOR JUMPER	
1015	000426	052712	004000			BIS	#ACTBIT,(R2)	:	SET FOR ACTIVE ON FIRST NON-SYNC	
1016	000432	052712	001000			BIS	#000BIT,(R2)	:	SET FOR ODD VRC.....	
1017	000436	005722				TST	(R2)+	:	POP POINTER	
1018	000440	005011				CLR	(R1)	:	CLEAR RCSR	
1019	000442	005061	000002			CLR	2(R1)	:	CLEAR TCSR	
1020	000446	005061	000002			CLR	2(R1)	:	CLEAR AGAIN	
1021	000452	005061	000004			CLR	4(R1)	:	CLEAR ERROR REG	
1022	000456	005061	000006			CLR	6(R1)	:	CLEAR SEC REG	
1023	000462	005237	001504			INC	DQNUM	:	UPDATE NUMBER OF DQ11S	
1024	000466	062701	000010	2\$:		ADD	#10,R1	:	UPDATE CSR POINTER BY 10 (8)	
1025	000472	022701	164000			CMP	#164000,R1	:	HAVE ALL FLOATING ADDRESSES BEEN CHECKED??	
1026	000476	001267				BNE	1\$:	BR IF NOT ALL DONE	
1027	000500	005037	001500			CLR	DQACTV	:	ZERO ACTIVE DQ11S	
1028	000504	005737	001504			TST	DQNUM	:	WERE ANY DQ11S FOUND	
1029	000510	001434				BEQ	4\$:	HEY BUDDY. NO DQ11S FOUND IN SYSTEM	
1030	000512	013701	001504			MOV	DQNUM,R1	:	SAVE NUMBER OF DQ11S	
1031	000516	010137	001276			MOV	R1,SAVNUM	:	SAVE NUMBER FOR ACT11	
1032	000522	000241		3\$:		CLC		:	CLEAR CARRY	
1033	000524	006137	001500			ROL	DQACTV	:	***** ACTIVE ADDRESS	
1034	000530	005237	001500			INC	DQACTV	:	SET BIT 0	
1035	000534	005301				DEC	R1	:	DEC NUMBER OF DQ11S	
1036	000536	001371				BNE	3\$:	BR IF MORE TO GO	

```

1037 000540 012737 000006 000004      MOV      #6, #4      ;RESET TIME OUT VECTOR
1038 000546 013737 001500 001502      MOV      DQACTV, SAVACT ;SAVE ACTIVE
1039 000554 012737 000340 000022      MOV      #340, #22   ;SET IOT TRAP PRIORITY TO 7
1040 000562 012702 001400      MOV      #1400, R2    ;SET TABLE POINTER
1041 000566 012700 000300      MOV      #300, R0     ;SET VECTOR START
1042 000572 012701 000302      MOV      #302, R1     ;SET VECTOR+2 START
1043 000576 000137 000056      JMP      VECHAP       ;GO FIND THE VECTORS
1044 000602 104402      4S:     TYPE          ;TYPE MESSAGE
1045 000604 017402      MERR2          ;I DIDN'T FIND ANY DQ11S. DON'T USE AUTO SIZE.
1046 000606 005000      CLR      R0
1047 000610 000000      HALT
1048 000612 000776      BR      #-2
1049 000614 012716 000466      5S:     MOV      #25, (SP) ;HOW CAN I TEST NO DQ11S
1050 000620 000002      RTI            ;DON'T LET OPR HIT CONT. SW
1051
1052
1053
1054 001000 005377 040515 047111      .=1000      MTITLE: .ASCIZ <377><12>/MAINDEC-11-DZDQD-D/<377>/TRANSMITTER AND RECEIVER EXERCISER/<3
1055 001006 042504 026503 030461
1056 001014 042055 042132 042121
1057 001022 042055 052377 040522
1058 001030 051516 044515 052124
1059 001036 051105 040440 042116
1060 001044 051040 041505 044505
1061 001052 042526 020122 054105
1062 001060 051105 044503 042523
1063 001066 177522      000
1064
1065      001200      .=1200
1066      ;INDIRECT POINTERS
1067
1068 001200 177570      SWR:      177570      ;SWITCH REGISTER POINTER
1069 001202 177570      LIGHTS:   177570     ;DISPLAY REGISTER POINTER
1070 001204 177560      TKCSR:    177560     ;TELETYPE KEYBOARD CONTROL REGISTER
1071 001206 177562      TKDBR:    177562     ;TELETYPE KEYBOARD DATA BUFFER
1072 001210 177564      TPCSR:    177564     ;TELEPRINTER CONTROL REGISTER
1073 001212 177566      TPDBR:    177566     ;TELEPRINTER DATA BUFFER
1074
1075      ;PROGRAM CONTROL PARAMETERS
1076
1077 001214 000000      RETURN:   0          ;SCOPE ADDRESS FOR LOOP ON TEST
1078 001216 000000      NEXT:     0          ;ADDRESS OF NEXT TEST TO BE EXECUTED
1079 001220 000000      LOCK:     0          ;ADDRESS FOR LOCK ON CURRENT DATA
1080 001222 000003      ICOUNT:   3          ;NUMBER OF ITERATIONS THAT CURRENT TEST WILL BE EXECUTED
1081 001224 000000      LPCNT:    0          ;NUMBER OF ITERATIONS COMPLETED
1082 001226 000000      TSTNO:    0          ;NUMBER OF TEST IN PROGRESS
1083 001230 000000      PASCNT:   0          ;NUMBER OF PASSES COMPLETED
1084 001232 000000      ERRCNT:   0          ;TOTAL NUMBER OF ERRORS
1085 001234 000000      LSTERR:   0          ;PC OF LAST ERROR CALL
1086
1087      ;PROGRAM VARIABLES
1088
1089 001236 000000      CHAR1:    0
1090 001240 000000      CHAR2:    0
1091 001242 000000      CHAR3:    0
1092 001244 000000      TEMP1:    0          ;TEMPORARY STORAGE
    
```


DZDQD MACY11 27(1006) 22-DEC-76 11:14 PAGE 24
DZDQDD.P11 21-DEC-76 16:32

PROGRAM PARAMETERS, VARIABLES, AND TRAP CALLS.

1093 001246 000000
1094 001250 000000
1095 001252 000000
1096 001254 000000
1097 001256 000000
1098 001260 000000
1099 001262 000000
1100 001264 000000
1101 001266 000000
1102 001270 000000
1103 001272 000000
1104 001274 000000
1105 001276 000000
1106 001300 000001
1107 001302 000000
1108 001304 000000
1109 001306 000000

TEMP2: 0
TEMP3: 0
TEMP4: 0
TEMPS: 0
SAVR0: 0
SAVR1: 0
SAVR2: 0
SAVR3: 0
SAVR4: 0
SAVRS: 0
SAVSP: 0
SAVPC: 0
SAVNUM: 0
CREAM: .BLKW 1
RUNFLG: 0
RUN: 0
RUNCNT: 0

: TEMPORARY STORAGE
: TEMPORARY STORAGE
: TEMPORARY STORAGE
: TEMPORARY STORAGE
: R0 STORAGE
: R1 STORAGE
: R2 STORAGE
: R3 STORAGE
: R4 STORAGE
: R5 STORAGE
: STACK POINTER STORAGE
: PROGRAM COUNTER STORAGE

M02

DZDQD MACY11 27(1006) 22-DEC-76 11:14 PAGE 25
 DZDQD.P11 21-DEC-76 16:32 PROGRAM PARAMETERS, VARIABLES, AND TRAP CALLS.

```

1110
1111
1112
1113 001310 000
1114 001311 000
1115 001312 000
1116 001313 000
1117 000000
1118
1119
1120
1121
1122
1123
1124
1125 001314
1126 104400
1127 001314 015314
1128 104401
1129 001316 015426
1130 104402
1131 001320 015446
1132 104403
1133 001322 015554
1134 104404
1135 001324 015672
1136 104405
1137 001326 015724
1138 104406
1139 001330 016140
1140 104407
1141 001332 016200
1142 104410
1143 001334 016232
1144 104411
1145 001336 016236
1146 104412
1147 001340 012114
1148 104413
1149 001342 011770
1150 104414
1151 001344 017140
1152 104415
1153 001346 017214
1154
1155
1156
1157
1158
1159
1160 001350 000000
1161 001352 000000
1162 001354 000000
1163 001356 000000
1164 001360 000000
1165 001362 000000

;PROGRAM CONTROL FLAGS
INIFLG: .BYTE 0 ;PROGRAM INITIALIZATION FLAG
STFLG: .BYTE 0 ;TEST START FLAG
ERRFLG: .BYTE 0 ;ERROR OCCURED FLAG
LOKFLG: .BYTE 0 ;LOCK ON CURRENT TEST FLAG
SY=0

;DEFINITIONS FOR TRAP SUBROUTINE CALLS
;POINTERS TO SUBROUTINES CAN BE FOUND
;IN THE TABLE IMMEDIATLY FOLLOWING THE DEFINITIONS

;*****
;*****
;TRPTAB:
SCOPE=TRAP+0 ;CALL TO SCOPE LOOP AND ITERATION HANDLER
;SCOPE
SCOPI=TRAP+1 ;CALL TO LOOP ON CURRENT DATA HANDLER
;SCOPI
TYPE=TRAP+2 ;CALL TO TELETYPE OUTPUT ROUTINE
;TYPE
INSTR=TRAP+3 ;CALL TO ASCII STRING INPUT ROUTINE
;INSTR
INSTER=TRAP+4 ;CALL TO INPUT ERROR HANDLER
;INSTER
PARAM=TRAP+5 ;CALL TO NUMERICAL DATA INPUT ROUTINE
;PARAM
SAVOS=TRAP+6 ;CALL TO REGISTER SAVE ROUTINE
;SAVOS
RESOS=TRAP+7 ;CALL TO REGISTER RESTORE ROUTINE
;RESOS
CONVRT=TRAP+10 ;CALL TO DATA OUTPUT ROUTINE
;CONVRT
CNVRT=TRAP+11 ;CALL TO DATA OUTPUT ROUTINE WITHOUT CR/LF.
;CNVRT
MSTCLR=TRAP+12 ;CALL TO ISSUE MASTER CLEAR
;MSTCLR
MEMCLR=TRAP+13 ;CALL TO CLEAR ALL SCRATCH PAD MEMORIES
;MEMCLR
CKSWR=TRAP+14 ;CALL TO ALLOW SWREG TO BE LOADED FROM TTY
;CKSWR
CNTLU=TRAP+15 ;CALL TO ALLOW LOADING OF SWREG FROM TTY
;CNTLU

;*****
;*****

;DQ11 VECTOR AND REGISTER INDIRECT POINTERS
DGRVEC: 0 ;POINTER TO DQ11 RECEIVER INTERRUPT VECTOR
DQRLVL: 0 ;POINTER TO DQ11 RECEIVER INTERRUPT SERVICE PS
DQTVEC: 0 ;POINTER TO DQ11 TRANSMITTER INTERRUPT VECTOR
DQTLVL: 0 ;POINTER TO DQ11 TRANSMITTER INTERRUPT SERVICE PS
DQRC SR: 0 ;POINTER TO DQ11 RECEIVER CONTROL REGISTER
DQRC SH: 0 ;POINTER TO HIGH BYTE OF DQ11 RECEIVER CONTROL REGISTER
  
```


PROGRAM PARAMETERS, VARIABLES, AND TRAP CALLS.

1166 001364 000000
 1167 001366 000000
 1168 001370 000000
 1169 001372 000000
 1170 001374 000000

DQTCR: 0 ; POINTER TO DQ11 TRANSMITTER CONTROL REGISTER
 DQERR: 0 ; POINTER TO DQ11 ERROR REGISTER
 DQREG: 0 ; POINTER TO HIGH BYTE OF ERROR REGISTER
 DQSEC: 0 ; POINTER TO DQ11 SECONDARY REGISTER
 DQSECH: 0 ; POINTER TO HIGH BYTE OF DQ11 SECONDARY REGISTER

;DQ11 STATUS TABLE AND ADDRESS ASSIGNMENTS

1171
 1172
 1173
 1174
 1175
 1176 001400
 1177 001400 000001
 1178 001402 000001
 1179 001404 000001
 1180 001406 000001
 1181 001410 000001
 1182 001412 000001
 1183 001414 000001
 1184 001416 000001
 1185 001420 000001
 1186 001422 000001
 1187 001424 000001
 1188 001426 000001
 1189 001430 000001
 1190 001432 000001
 1191 001434 000001
 1192 001436 000001
 1193 001440 000001
 1194 001442 000001
 1195 001444 000001
 1196 001446 000001
 1197 001450 000001
 1198 001452 000001
 1199 001454 000001
 1200 001456 000001
 1201 001460 000001
 1202 001462 000001
 1203 001464 000001
 1204 001466 000001
 1205 001470 000001
 1206 001472 000001
 1207 001474 000001
 1208 001476 000001
 1209 001500 000001
 1210 001502 000001
 1211 001504 000001
 1212 001506 000001
 1213 001510 000001

. =1400
 DQCR00: .BLKW 1 ; CONTROL STATUS REGISTER FOR DEVICE NO: 00
 DQST00: .BLKW 1 ; VECTOR AND CONFIGURATION STATUS FOR DEVICE NO: 00
 DQCR01: .BLKW 1 ; CONTROL STATUS REGISTER FOR DEVICE NO: 01
 DQST01: .BLKW 1 ; VECTOR AND CONFIGURATION STATUS FOR DEVICE NO: 01
 DQCR02: .BLKW 1 ; CONTROL STATUS REGISTER FOR DEVICE NO: 02
 DQST02: .BLKW 1 ; VECTOR AND CONFIGURATION STATUS FOR DEVICE NO: 02
 DQCR03: .BLKW 1 ; CONTROL STATUS REGISTER FOR DEVICE NO: 03
 DQST03: .BLKW 1 ; VECTOR AND CONFIGURATION STATUS FOR DEVICE NO: 03
 DQCR04: .BLKW 1 ; CONTROL STATUS REGISTER FOR DEVICE NO: 04
 DQST04: .BLKW 1 ; VECTOR AND CONFIGURATION STATUS FOR DEVICE NO: 04
 DQCR05: .BLKW 1 ; CONTROL STATUS REGISTER FOR DEVICE NO: 05
 DQST05: .BLKW 1 ; VECTOR AND CONFIGURATION STATUS FOR DEVICE NO: 05
 DQCR06: .BLKW 1 ; CONTROL STATUS REGISTER FOR DEVICE NO: 06
 DQST06: .BLKW 1 ; VECTOR AND CONFIGURATION STATUS FOR DEVICE NO: 06
 DQCR07: .BLKW 1 ; CONTROL STATUS REGISTER FOR DEVICE NO: 07
 DQST07: .BLKW 1 ; VECTOR AND CONFIGURATION STATUS FOR DEVICE NO: 07
 DQCR10: .BLKW 1 ; CONTROL STATUS REGISTER FOR DEVICE NO: 10
 DQST10: .BLKW 1 ; VECTOR AND CONFIGURATION STATUS FOR DEVICE NO: 10
 DQCR11: .BLKW 1 ; CONTROL STATUS REGISTER FOR DEVICE NO: 11
 DQST11: .BLKW 1 ; VECTOR AND CONFIGURATION STATUS FOR DEVICE NO: 11
 DQCR12: .BLKW 1 ; CONTROL STATUS REGISTER FOR DEVICE NO: 12
 DQST12: .BLKW 1 ; VECTOR AND CONFIGURATION STATUS FOR DEVICE NO: 12
 DQCR13: .BLKW 1 ; CONTROL STATUS REGISTER FOR DEVICE NO: 13
 DQST13: .BLKW 1 ; VECTOR AND CONFIGURATION STATUS FOR DEVICE NO: 13
 DQCR14: .BLKW 1 ; CONTROL STATUS REGISTER FOR DEVICE NO: 14
 DQST14: .BLKW 1 ; VECTOR AND CONFIGURATION STATUS FOR DEVICE NO: 14
 DQCR15: .BLKW 1 ; CONTROL STATUS REGISTER FOR DEVICE NO: 15
 DQST15: .BLKW 1 ; VECTOR AND CONFIGURATION STATUS FOR DEVICE NO: 15
 DQCR16: .BLKW 1 ; CONTROL STATUS REGISTER FOR DEVICE NO: 16
 DQST16: .BLKW 1 ; VECTOR AND CONFIGURATION STATUS FOR DEVICE NO: 16
 DQCR17: .BLKW 1 ; CONTROL STATUS REGISTER FOR DEVICE NO: 17
 DQST17: .BLKW 1 ; VECTOR AND CONFIGURATION STATUS FOR DEVICE NO: 17
 DQACTV: .BLKW 1 ; HOLD ACTIVE BITS FOR TESTING
 SAVACT: .BLKW 1 ; SAVE NUMBER OF ACTIVE DQ11S
 DQNUM: .BLKW 1 ; OCTAL NUMBER OF TOTAL NUMBER OD DQ11S
 DQCSR: .BLKW 1 ; CSR OF DQ11 UNDER TEST
 DQSTAT: .BLKW 1 ; VECTOR AND CONFIGURATION STATUS OF DQ11 UNDER TEST

1214
 1215 ; PROGRAM INITIALIZATION
 1216 ; LOCK OUT INTERRUPTS
 1217 ; SET UP PROCESSOR STACK
 1218 ; SET UP POWER FAIL VECTOR
 1219 ; CLEAR PROGRAM CONTROL FLAGS AND COUNTS
 1220 ; TYPE TITLE MESSAGE
 1221

1222	001512	012737	000340	177776	.START:	MOV	0340,PS		;LOCK OUT INTERRUPTS
1223	001520	012706	001200			MOV	0STACK,SP		;SET UP STACK
1224	001524	012737	017042	000024		MOV	0.PFAIL,0024		;SET UP POWER FAIL VECTOR
1225	001532	013737	001504	001276		MOV	0ANUM,0AVNUM		
1226	001540	105037	001311			CLRB	STFLG		;CLEAR START FLAG
1227	001544	005037	001230			CLR	PASCNT		;CLEAR PASS COUNT
1228	001550	105037	001312			CLRB	ERRFLG		;CLEAR ERROR FLAG
1229	001554	005037	001302			CLR	RUNFLG		
1230	001560	012737	001400	001300		MOV	01400,CREAM		
1231	001566	005037	001232			CLR	ERRCNT		;CLEAR ERROR COUNT
1232	001572	005037	001234			CLR	LSTERR		;CLEAR LAST ERROR POINTER
1233	001576	012737	000001	001226		MOV	01,TSTNO		;SET UP FOR TEST 1
1234	001604	012737	001512	001214		MOV	0.START,RETURN		;SET UP FOR POWER FAIL BEFORE
1235									;TESTING STARTS
1236	001612	105737	001310			TSTB	INIFLG		;HAS INITIALIZATION BEEN PERFORMED
1237	001616	001075				BNE	125		
1238	001620	104402	001000			TYPE	MTITLE		;TYPE TITLE MESSAGE
1239	001624	105137	001310			COMB	INIFLG		;IF NOT SET FLAG AND DO
1240									
1241	001630	012737	177570	001200		MOV	0DSWR,SWR		;MOV HARDWARE SWR TO SWR
1242	001636	012737	177570	001202		MOV	0DLIGHTS,LIGHTS		;MOV DISPLAY LIGHTS TO LIGHTS
1243	001644	013746	000006			MOV	006,-(SP)		;SAVE VECTORS
1244	001650	013746	000004			MOV	004,-(SP)		
1245	001654	012737	001674	000004		MOV	0648,004		;SET UP FOR TIMEOUT
1246	001662	022777	177777	177310		CMP	0-1,0SWR		;REFERENCE HARDWARE SWITCH REGISTER
1247	001670	001402				BEQ	658		
1248	001672	000407				BR	668		
1249	001674	022626			648:	CMP	(SP)+,(SP)+		;ADJUST STACK
1250	001676	012737	000176	001200	658:	MOV	0SWREG,SWR		;POINT TO SOFTWARE SWITCH REG
1251	001704	012737	000174	001202		MOV	0DISPREG,LIGHTS		;POINT TO SOFT DISPLAY REG
1252	001712	012637	000004		668:	MOV	(SP)+,004		;RESTORE VECTORS
1253	001716	012637	000006			MOV	(SP)+,006		
1254	001722	005737	000042			TST	0042		;UNDER MONITOR
1255	001726	001005				BNE	678		
1256	001730	022737	000176	001200		CMP	0SWREG,SWR		;IS SWREG USED
1257	001736	001001				BNE	678		
1258	001740	104415				CNTLU			
1259	001742	105777	177232		678:	TSTB	0SWR		
1260	001746	100402				BMI	+6		
1261	001750	004737	000220			JSR	PC,CSRMAP		
1262	001754	104402	017667			TYPE	XHEAD		
1263	001760	012737	001400	001244		MOV	01400,TEMP1		
1264	001766	017737	177252	001246		MOV	0TEMP1,TEMP2		
1265	001774	001406				BEQ	+16		
1266	001776	104410				CONVRT			
1267	002000	017714				XSTAT0			
1268	002002	062737	000002	001244		ADD	02,TEMP1		
1269	002010	000766				BR	-22		
1270	002012	032777	000001	177160	128:	BIT	0SW00,0SWR		
1271	002020	001424				BEQ	15		
1272	002022	104402				TYPE			
1273	002024	017610				MNEW			
1274	002026	005000				CLR	RO		
1275	002030	000000				HALT			
1276	002032	104414				CKSWR			
1277	002034	027737	177140	001502		CMP	0SWR,0SAVACT		


```

1278 002042 101404      BLOS      115
1279 002044 104402      TYPE
1280 002046 017451      MERR3
1281 002050 000000      HALT
1282 002052 000776      BR      -2
1283 002054 017737 177120 001500 115:  MOV      @SWR,DQACTV
1284 002062 013700 001500      MOV      DQACTV,RO
1285 002066 000000      HALT
1286 002070 104414      CKSWR
1287 002072 012700 000300 15:  MOV      @300,RO
1288 002076 012701 000302      MOV      @302,R1
1289 002102 010120 25:  MOV      R1,(R0)+
1290 002104 005021      CLR      (R1)+
1291 002106 022021      CMP      (R0)+,(R1)+
1292 002110 022700 001000      CMP      @1000,RO
1293 002114 001372      BNE      25
1294
1295      ;TEST START AND RESTART
1296
1297 002116 012737 000340 177776 .BEGIN: MOV      @340,PS      ;LOCK OUT INTERRUPTS
1298 002124 012706 001200      MOV      @STACK,SP  ;SET UP STACK
1299 002130 005737 000042      TST      @#42      ;IS PROGRAM UNDER MONITOR CONTROL
1300 002134 001040      BNE      35
1301 002136 104414      CKSWR      ;CHECK FOR <IG>
1302 002140 032777 000004 177032  BIT      @BIT2,@SWR  ;CHECK FOR LOCK ON TEST
1303 002146 001411      BEQ      15
1304 002150 104402 017507      TYPE      MLOCK
1305 002154 012737 000240 015324  MOV      @NOP,TTST
1306 002162 012737 000240 015326  MOV      @NOP,TTST+2  ;SET UP TO LOCK
1307 002170 000406      BR      25
1308 002172 013737 015422 015324 15:  MOV      BRW,TTST
1309 002200 013737 015424 015326  MOV      BRX,TTST+2  ;LOCK NOT SELECTED, SET UP FOR NORMAL SCOPE LOOP
1310 002206 032777 000002 176764 25:  BIT      @SW01,@SWR  ;IF SW01=1, GET STARTING PC
1311 002214 001410      BEQ      35
1312 002216 104403      INSTR
1313 002220 017475      MTSTPC
1314 002222 104405      PARAM
1315 002224 002254      TST1
1316 002226 007754      TLAST
1317 002230 001214      @RETURN
1318 002232 001      .BYTE 1
1319 002233 001      .BYTE 1
1320 002234 000403      BR      45
1321 002236 012737 002254 001214 35:  MOV      @TST1,RETURN  ;START AT TEST 1
1322 002244 104402 017377 45:  TYPE      MR      ;TYPE R
1323 002250 000177 176740      JMP      @RETURN  ;START TESTING
1324
1325      ; TEST 1
1326 002254 012737 000001 001226  TST1:  MOV      @1,TSTNO
1327 002262 012737 002644 001214  MOV      @TST2,RETURN
1328 002270 012737 002644 001216  MOV      @TST2,NEXT
1329 002276 105737 001302      TSTB      RUNFLG      ;IS THIS MY FIRST TIME HERE?
1330 002302 001010      BNE      15      ;BR IF FLAG IS SET
1331 002304 012737 000001 001304  MOV      @BIT0,RUN  ;SET RUN POINTER.
1332 002312 012737 000020 001306  MOV      @16,RUNCNT  ;SET FOR MAX OF 16 DQ11'S PER SYSTEM
1333 002320 105137 001302      COMB      RUNFLG      ;SET RUN FLAG

```

```

1334 002324 033737 001304 001500 1S: BIT RUN,DQACTV ;FIND AN ACTIVE DQ11 TO TEST.
1335 002332 001032 BNE 3S ;BR IF I FOUND ONE TO TEST.
1336 002334 005737 001500 TST DQACTV ;FIND OUT IF THERE ARE NO DQ11 ACTIVE.
1337 002340 001423 BEQ 2S ;BR TO FATAL ERROR. WHY AM I HERE IF NO ACTIVE DQ11'S???
1338 002342 000257 CCC ;CLEAR ALL THE CONDITION CODES OF CPU
1339 002344 006137 001304 ROL RUN ;UPDATE RUN POINTER
1340 002350 062737 000004 001300 ADD #4,CREAM ;UPDATE ADDRESS POINTER.
1341 002356 005337 001306 DEC RUNCNT ;DEC NUMBER OF TIMES I LOOKED AT ACTIVE.
1342 002362 001360 BNE 1S ;BR AND KEEP LOOKING.
1343 002364 012737 000020 001306 MOV #16,RUNCNT ;START RESTORING MY POINTERS.
1344 002372 012737 001400 001300 MOV #1400,CREAM ;RESTORE ADDRESS POINTER
1345 002400 012737 000001 001304 MOV #1,RUN ;RESTORE RUN POINTER.
1346 002406 000746 BR 1S ;KEEP ON TESTING.
1347 002410 104402 2S: TYPE ;ALERT OPERATOR OF FATAL ERROR
1348 002412 017402 MERR2 ;NO DQ11 ACTIVE. WHY AM I HERE???
1349 002414 000000 HALT ;YOU MUST RELOAD DQ11 DIAGNOSTIC!!
1350 002416 000776 BR .-2 ;STICK HERE ON CONT.
1351 002420 000257 3S: CCC ;CLEAR CPU COND. CODES
1352 002422 006137 001304 ROL RUN ;UPDATE RUN. ACTIVE DQ11 FOUND.
1353 002426 017737 176646 001506 MOV #2,CREAM,DQCSR ;PLACE ADDRESS OF DQ11 AT DQCSR
1354 002434 062737 000002 001300 ADD #2,CREAM ;UPDATE ADDRESS POINTER
1355 002442 017737 176632 001510 MOV #2,CREAM,DQSTAT ;PLACE STATUS OF DQ11 IN DQSTAT
1356 002450 062737 000002 001300 ADD #2,CREAM ;UPDATE ADDRESS POINTER
1357 002456 013737 001506 001360 MOV DQCSR,DQRCR
1358 002464 013737 001510 001350 MOV DQSTAT,DQVEC
1359 002472 042737 177007 001350 BIC #177007,DQVEC
1360 002500 013737 001350 001352 MOV DQVEC,DQRLVL ;GENERATE ADDRESS OF RECEIVER INTERRUPT SERVICE PS
1361 002506 062737 000002 001352 ADD #2,DQRLVL
1362 002514 013737 001352 001354 MOV DQRLVL,DQTEC ;GENERATE ADDRESS OF TRANSMITTER INTERRUPT VECTOR
1363 002522 062737 000002 001354 ADD #2,DQTEC
1364 002530 013737 001354 001356 MOV DQTEC,DQTLVL ;GENERATE ADDRESS OF TRANSMITTER INTERRUPT SERVICE PS
1365 002536 062737 000002 001356 ADD #2,DQTLVL
1366 002544 013737 001360 001362 MOV DQCSR,DQCSH
1367 002552 005237 001362 INC DQCSH ;GENERATE ADDRESS OF HIGH BYTE
1368 002556 013737 001360 001364 MOV DQCSR,DQCSR ;GENERATE ADDRESS OF TRANSMITTER CONTROL REGISTER
1369 002564 062737 000002 001364 ADD #2,DQCSR
1370 002572 013737 001364 001366 MOV DQCSR,DQERR ;GENERATE ADDRESS OF ERROR REGISTER
1371 002600 062737 000002 001366 ADD #2,DQERR
1372 002606 013737 001366 001370 MOV DQERR,DQREG ;GENERATE ADDRESS OF HIGH BYTE OF ERROR REGISTER
1373 002614 005237 001370 INC DQREG
1374 002620 013737 001370 001372 MOV DQREG,DQSEC ;GENERATE ADDRESS OF SECONDARY REGISTER
1375 002626 005237 001372 INC DQSEC
1376 002632 013737 001372 001374 MOV DQSEC,DQSECH ;GENERATE ADDRESS OF HIGH BYTE
1377 002640 005237 001374 INC DQSECH
1378 ;
1379 ;TEST TO SEE IF TRANSMITTER ACTIVE
1380 ;CAN SET.
1381 ;AND IF IT DOES SET CHECK TO
1382 ;SEE IF IT CAN BE CLEARED BY
1383 ;MASTER CLEAR.
1384 ;
1385 ; TEST 2
1386 ;*****
1387 002644 012737 000002 001226 TST2: MOV #2,TSTNO
1388 002652 012737 003002 001216 MOV #CKSYN1,NEXT
1389 002660 112777 000002 176502 MOV# #2,DQREG ;SEL TX BA PRI

```


E03

DZDGD MACY11 27(1006) 22-DEC-76 11:14 PAGE 30
 DZDGD0.P11 21-DEC-76 16:32 DQ11 TRANSMITTER AND RECEIVER EXERCISER.

```

1390 002666 012777 014066 176476      MOV      #TMPBUF,200SEC ;LOAD TX BA
1391 002674 105277 176470      INCB    200REG          ;SEL TTX CC PRI
1392 002700 012777 000200 176464      MOV      #200,200SEC   ;LOAD WITH 200
1393 002706 112777 000012 176454      MOVVB   #MISC.,200REG ;SEL MISC REGISTER
1394 002714 012777 004012 176450      MOV      #4012,200SEC ;SELECT 8 BITS TEST LOOP AUTO STEP
1395 002722 005277 176436      INC     200TCSR        ;SET TX GO
1396 002726 005277 176440      INC     200SEC         ;PRIM THE
1397 002732 005377 176434      DEC     200SEC         ;TRANSMITTER
1398 002736 005277 176430      INC     200SEC         ;CLOCK THE TRANSMITTER
1399 002742 032777 040000 176422      BIT     #BIT14,200SEC ;CHECK TX ACTIVE.
1400 002750 001001                BNE     .+4            ;BRANCH IF ACTIVE SET
1401 002752 104024                HLT 24                ;ERROR TX ACTIVE NOT SET!!
1402 002754 104412      MSTCLR ;ISSUE
1403 002756 104412      MSTCLR ;TWO MASTER CLEARS
1404 002760 112777 000012 176402      MOVVB   #MISC.,200REG ;RESELECT THE MISC REGISTER
1405 002766 032777 040000 176376      BIT     #BIT14,200SEC ;DID TX ACTIVE CLEAR BY MST CLR
1406 002774 001401                BEQ     .+4            ;BRANCH IF ACTIVE CLEAR
1407 002776 104001                HLT 1                 ;ERROR TX ACTIVE NOT CLEARED BY MST CLR
1408 003000 104400      SCOPE ;SCOPE TEST
1409
1410      ;ROUTINE TO SET
1411      ;TRANSMITTER POINTER
1412      ;CORRECTLY DEPENDING
1413      ;UPON THE NUMBER OF SYNC
1414      ;CHARACTERS.
1415
1416 003002 032737 100000 001510 CKSYN1: BIT     #SYNBIT,DQSTAT ;CHECK TO FIND OUT IF ONE SYNC OR TWO.
1417 003010 001003                BNE     15            ;BRANCH IF TWO SYNC CHARS REQUIRED
1418 003012 105037 014522      CLRB   SYNC           ;CLEAR THE FIRST SYNC CHAR
1419 003016 000403                BR      25            ;BR TO LEAVE ROUTINE
1420 003020 112737 000026 014522 15:  MOVVB  #26,SYNC       ;RESET SYNC CHAR TO 26
1421 003026 000240 25:  NOP                ;FALL IN TO NEXT TEST
1422
1423      ;TEST TO TRANSMITT ONE CHARACTER.
1424
1425      ;TESTING TO MAKE SURE THAT THE
1426      ;CHARACTER COUNT INCREMENTS BY ONE.
1427      ;TESTING THAT THE CURRENT ADDRESS
1428      ;INCREMENTS BY ONE
1429      ;ALSO MAKING SURE THE PRI/SEC BIT SETS.
1430
1431      ; TEST 3
1432      ;*****
1433 003030 012737 000003 001226 TST3: MOV      #3,TSTNO
1434 003036 012737 003054 001214      MOV     #A15,RETURN
1435 003044 012737 003370 001216      MOV     #TST4,NEXT
1436 003052 104413                MEMCLR ;CLEAR ALL THE DQ11
1437 003054 104412      MSTCLR
1438 003056 112777 000002 176304      MOVVB  #2,200REG     ;SELECT TX CURRENT ADD.
1439 003064 012777 014524 176300      MOV     #TXBUF,200SEC ;SET THE TX CURRENT ADD.
1440 003072 105277 176272      INCB   200REG        ;SELECT THE TX CHAR CNT.
1441 003076 012777 177777 176266      MOV     #-1,200SEC   ;SET TX CHAR CNT FOR 1 CHARACTER.
1442 003104 112777 000012 176256      MOVVB  #MISC.,200REG ;SELECT THE MISC REGISTER.
1443 003112 012777 004010 176252      MOV     #4010,200SEC ;SET FOR EIGHT BITS. AND TEST LOOP
1444 003120 005037 014060      CLR    DELAY         ;CLEAR THE DELAY
1445 003124 005277 176234      INC     200TCSR      ;SET THE GO BIT AND GO!!

```

DZDQD MACY11 27(1006) 22-DEC-76 11:14 PAGE 31
 DZDQDD.P11 21-DEC-76 16:32

DQ11 TRANSMITTER AND RECEIVER EXERCISER.

```

1446 003130 105777 176230 1S: TSTB 200TCSR ;PRIMARY DONE??
1447 003134 100405 BMI 25 ;BRANCH IF DONE
1448 003136 062737 000001 014060 ADD #1,DELAY ;STALL FOR DONE
1449 003144 001371 BNE 15 ;TO SET.
1450 003146 104002 HLT 2 ;TX PRI DONE FAILED TO SET.
1451 003150 112777 000003 176212 2S: MOVB #3,200REG ;SELECT TX CHAR CNT
1452 003156 005777 176210 TST 200SEC ;MAKE SURE IT INCREMENTED
1453 003162 001401 BEQ .+4 ;BY ONE TO ZERO.
1454 003164 104003 HLT 3 ;TX PRI CHAR CNT NOT ZERO.
1455 003166 112777 000002 176174 MOVB #2,200REG ;SELECT TX CURRENT ADD.(PRI)
1456 003174 022777 014525 176170 3S: CMP #TXBUFF+1,200SEC ;
1457 003202 001401 BEQ .+4 ;
1458 003204 104005 HLT 5 ;CHAR CNT NOT INC BY +1
1459 003206 032777 000004 176150 4S: BIT #BIT2,200TCSR ;DID PRI/SEC SET?
1460 003214 001001 BNE .+4 ;
1461 003216 104006 HLT 6 ;TX PRI/SEC NOT SET.
1462
1463 ;TEST THAT WITH A CHARACTER
1464 ;COUNT THAT IS EVEN THAT THE
1465 ;CURRENT ADDRESS INCREMENTS BY +2
1466 ;AND THAT THE CHAR CNT GOES TO ZERO.
1467
1468
1469
1470 003220 112777 000006 176142 SECND: MOVB #6,200REG ;SELECT TX CURRENT ADD.
1471 003226 012777 014524 176136 MOV #TXBUFF,200SEC ;SET THE TX CURRENT ADD.
1472 003234 105277 176130 INCB 200REG ;SELECT THE TX CHAR CNT.
1473 003240 012777 177776 176124 MOV #2,200SEC ;SET TX CHAR CNT FOR TWO CHARS.
1474 003246 112777 000012 176114 MOVB #MISC,200REG ;SELECT THE MISC REGISTER.
1475 003254 012777 004010 176110 MOV #4010,200SEC ;SET FOR EIGHT BITS AND TEST LOOP
1476 003262 005037 014060 CLR DELAY ;CLEAR THE DELAY
1477 003266 005277 176072 INC 200TCSR ;SET THE GO BIT AND GO!!
1478 003272 032777 000100 176064 1S: BIT #BIT6,200TCSR ;SECONDARY DONE??
1479 003300 001005 BNE 25 ;BRANCH IF DONE
1480 003302 062737 000001 014060 ADD #1,DELAY ;STALL FOR DONE
1481 003310 001370 BNE 15 ;TO SET.
1482 003312 104002 HLT 2 ;TX SEC DONE FAILED TO SET.
1483 003314 112777 000007 176046 2S: MOVB #7,200REG ;SELECT TX CHAR CNT
1484 003322 005777 176044 TST 200SEC ;MAKE SURE IT INCREMENTED
1485 003326 001401 BEQ .+4 ;BY ONE TO ZERO.
1486 003330 104003 HLT 3 ;TX SEC CHAR CNT NOT ZERO.
1487 003332 112777 000006 176030 MOVB #6,200REG ;SELECT TX CURRENT ADD.(PRI)
1488 003340 022777 014526 176024 3S: CMP #TXBUFF+2,200SEC ;
1489 003346 001401 BEQ .+4 ;
1490 003350 104004 HLT 4 ;CHAR CNT NOT INC BY +2
1491 003352 032777 000004 176004 4S: BIT #BIT2,200TCSR ;DID PRI/SEC SET?
1492 003360 001401 BEQ .+4 ;
1493 003362 104006 HLT 6 ;TX PRI/SEC NOT SET.
1494 003364 104413 MEMCLR
1495 003366 104400 SCOPE
1496
1497 ;TRANSMITTER CHARACTER LENGTH TESTS.
1498
1499 ;TEST TO TRANSMITT A CHARACTER
1500 ;2 BITS LONG MAKING SURE THAT
1501 ;THE CHARACTER IS ALL ZERO'S

```


G03

DZD90 MACY11 27(1006) 22-DEC-76 11:14 PAGE 32
DZD900.P11 21-DEC-76 16:32

DQ11 TRANSMITTER AND RECEIVER EXERCISER.

1502
1503
1504
1505
1506
1507
1508
1509
1510
1511
1512
1513
1514
1515
1516
1517
1518
1519
1520
1521
1522
1523
1524
1525
1526
1527
1528
1529
1530
1531
1532
1533
1534
1535
1536
1537
1538
1539
1540
1541
1542
1543
1544
1545
1546
1547
1548
1549
1550
1551
1552
1553
1554
1555
1556
1557

003370 012737 000004 001226
003376 012737 003416 001216
003404 004537 010720
003410 000002
003412 007000
003414 104400

003416 012737 000005 001226
003424 012737 003444 001216
003432 004537 010720
003436 000003
003440 006400
003442 104400

003444 012737 000006 001226
003452 012737 003472 001216
003460 004537 010720
003464 000004
003466 006000
003470 104400

: AND THAT THE TX LINE GOES BACK TO
: A MARK STATE WHEN DONE.
:
: TEST 4
: *****
TST4: MOV #4,TSTNO
MOV #TST5,NEXT
JSR R5, TXSTRB ;JSR TO ROUTINE
2 ;NUMBER OF TIMES CHAR IS TO BE SHIFTED
7000 ;BIT SELECTION TO BE PLACED INTO MISC REG
SCOPE ;SCOPE TEST

: TEST TO TRANSMITT A CHARACTER
: 3 BITS LONG MAKING SURE THAT
: THE CHARACTER IS ALL ZERO'S
: AND THAT THE TX LINE GOES BACK TO
: A MARK STATE WHEN DONE.
:
: TEST 5
: *****
TST5: MOV #5,TSTNO
MOV #TST6,NEXT
JSR R5, TXSTRB ;JSR TO ROUTINE
3 ;NUMBER OF TIMES CHAR IS TO BE SHIFTED
6400 ;BIT SELECTION TO BE PLACED INTO MISC REG
SCOPE ;SCOPE TEST

: TEST TO TRANSMITT A CHARACTER
: 4 BITS LONG MAKING SURE THAT
: THE CHARACTER IS ALL ZERO'S
: AND THAT THE TX LINE GOES BACK TO
: A MARK STATE WHEN DONE.
:
: TEST 6
: *****
TST6: MOV #6,TSTNO
MOV #TST7,NEXT
JSR R5, TXSTRB ;JSR TO ROUTINE
4 ;NUMBER OF TIMES CHAR IS TO BE SHIFTED
6000 ;BIT SELECTION TO BE PLACED INTO MISC REG
SCOPE ;SCOPE TEST

: TEST TO TRANSMITT A CHARACTER
: 5 BITS LONG MAKING SURE THAT
: THE CHARACTER IS ALL ZERO'S
: AND THAT THE TX LINE GOES BACK TO
: A MARK STATE WHEN DONE.
:
: TEST 7
: *****
TST7: MOV #7,TSTNO
MOV #TST10,NEXT

H03

DZD00 MACY11 27(1006) 22-DEC-76 11:14 PAGE 33
DZD000.P11 21-DEC-76 16:32 D011 TRANSMITTER AND RECEIVER EXERCISER.

```
1558 003506 004537 010720 JSR R5, TXSTRB ;JSR TO ROUTINE
1559 003512 000005 5 ;NUMBER OF TIMES CHAR IS TO BE SHIFTED
1560 003514 005400 5400 ;BIT SELECTION TO BE PLACED INTO MISC REG
1561 003516 104400 SCOPE ;SCOPE TEST
1562
1563 ;TEST TO TRANSMITT A CHARACTER
1564 ; 6 BITS LONG MAKING SURE THAT
1565 ; THE CHARACTER IS ALL ZERO'S
1566 ; AND THAT THE TX LINE GOES BACK TO
1567 ; A MARK STATE WHEN DONE.
1568
1569
1570 ; TEST 10
1571 ; *****
1572 003520 012737 000010 001226 TST10: MOV #10, TSTNO
1573 003526 012737 003546 001216 MOV #TST11, NEXT
1574 003534 004537 010720 JSR R5, TXSTRB ;JSR TO ROUTINE
1575 003540 000006 6 ;NUMBER OF TIMES CHAR IS TO BE SHIFTED
1576 003542 005000 5000 ;BIT SELECTION TO BE PLACED INTO MISC REG
1577 003544 104400 SCOPE ;SCOPE TEST
1578
1579 ;TEST TO TRANSMITT A CHARACTER
1580 ; 7 BITS LONG MAKING SURE THAT
1581 ; THE CHARACTER IS ALL ZERO'S
1582 ; AND THAT THE TX LINE GOES BACK TO
1583 ; A MARK STATE WHEN DONE.
1584
1585
1586 ; TEST 11
1587 ; *****
1588 003546 012737 000011 001226 TST11: MOV #11, TSTNO
1589 003554 012737 003574 001216 MOV #TST12, NEXT
1590 003562 004537 010720 JSR R5, TXSTRB ;JSR TO ROUTINE
1591 003566 000007 7 ;NUMBER OF TIMES CHAR IS TO BE SHIFTED
1592 003570 004400 4400 ;BIT SELECTION TO BE PLACED INTO MISC REG
1593 003572 104400 SCOPE ;SCOPE TEST
1594
1595 ;TEST TO TRANSMITT A CHARACTER
1596 ; 8 BITS LONG MAKING SURE THAT
1597 ; THE CHARACTER IS ALL ZERO'S
1598 ; AND THAT THE TX LINE GOES BACK TO
1599 ; A MARK STATE WHEN DONE.
1600
1601
1602 ; TEST 12
1603 ; *****
1604 003574 012737 000012 001226 TST12: MOV #12, TSTNO
1605 003602 012737 003622 001216 MOV #TST13, NEXT
1606 003610 004537 010720 JSR R5, TXSTRB ;JSR TO ROUTINE
1607 003614 000010 0 ;NUMBER OF TIMES CHAR IS TO BE SHIFTED
1608 003616 004000 4000 ;BIT SELECTION TO BE PLACED INTO MISC REG
1609 003620 104400 SCOPE ;SCOPE TEST
1610
1611 ;TEST OF CHARACTER LENGTH
1612 ;FOR CHARACTERS OVER 8 BITS LONG.
1613
```



```

1614
1615
1616      ; TEST TO TRANSMITT A CHARACTER
1617      ; 9 BITS LONG MAKING SURE THAT
1618      ; THE CHARACTER IS ALL ZERO'S
1619      ; AND THAT THE TX LINE GOES BACK TO
1620      ; A MARK STATE WHEN DONE.
1621
1622
1623      ; TEST 13
1624      ; *****
1625      003622 012737 000013 001226  †ST13: MOV      #13,TSTNO
1626      003630 012737 003650 001216  MOV      #TST14,NEXT
1627      003636 004537 010720          JSR      R5, TXSTRB      ; DO JSR TO THE SUBROUTINE
1628      003642 000011          9.          ; NUMBER OF TIMES CHAR IS TO BE SHIFTED
1629      003644 003400          3400       ; BIT SELECTION TO BE PLACED INTO MISC REG
1630      003646 104400          SCOPE       ; SCOPE THE TEST
1631
1632
1633      ; TEST TO TRANSMITT A CHARACTER
1634      ; 10 BITS LONG MAKING SURE THAT
1635      ; THE CHARACTER IS ALL ZERO'S
1636      ; AND THAT THE TX LINE GOES BACK TO
1637      ; A MARK STATE WHEN DONE.
1638
1639
1640      ; TEST 14
1641      ; *****
1642      003650 012737 000014 001226  †ST14: MOV      #14,TSTNO
1643      003656 012737 003676 001216  MOV      #TST15,NEXT
1644      003664 004537 010720          JSR      R5, TXSTRB      ; DO JSR TO THE SUBROUTINE
1645      003670 000012          10.          ; NUMBER OF TIMES CHAR IS TO BE SHIFTED
1646      003672 003000          3000       ; BIT SELECTION TO BE PLACED INTO MISC REG
1647      003674 104400          SCOPE       ; SCOPE THE TEST
1648
1649
1650      ; TEST TO TRANSMITT A CHARACTER
1651      ; 11 BITS LONG MAKING SURE THAT
1652      ; THE CHARACTER IS ALL ZERO'S
1653      ; AND THAT THE TX LINE GOES BACK TO
1654      ; A MARK STATE WHEN DONE.
1655
1656
1657      ; TEST 15
1658      ; *****
1659      003676 012737 000015 001226  †ST15: MOV      #15,TSTNO
1660      003704 012737 003724 001216  MOV      #TST16,NEXT
1661      003712 004537 010720          JSR      R5, TXSTRB      ; DO JSR TO THE SUBROUTINE
1662      003716 000013          11.          ; NUMBER OF TIMES CHAR IS TO BE SHIFTED
1663      003720 002400          2400       ; BIT SELECTION TO BE PLACED INTO MISC REG
1664      003722 104400          SCOPE       ; SCOPE THE TEST
1665
1666
1667      ; TEST TO TRANSMITT A CHARACTER
1668      ; 12 BITS LONG MAKING SURE THAT
1669      ; THE CHARACTER IS ALL ZERO'S
    
```

J03

DZD00 MACY11 27(1006) 22-DEC-76 11:14 PAGE 35
DZD000.P11 21-DEC-76 16:32

D011 TRANSMITTER AND RECEIVER EXERCISER.

1670 ; AND THAT THE TX LINE GOES BACK TO
1671 ; A MARK STATE WHEN DONE.
1672 ;

1673 ; TEST 16
1674 ; *****
1675 ;

1676 003724 012737 000016 001226 TST16: MOV #16,TSTNO
1677 003732 012737 003752 001216 MOV #TST17,NEXT
1678 003740 004537 010720 JSR R5, TXSTRB ; DO JSR TO THE SUBROUTINE
1679 003744 000014 12. ; NUMBER OF TIMES CHAR IS TO BE SHIFTED
1680 003746 002000 2000 ; BIT SELECTION TO BE PLACED INTO MISC REG
1681 003750 104400 SCOPE ; SCOPE THE TEST

1682 ;
1683 ; TEST TO TRANSMITT A CHARACTER
1684 ; 13 BITS LONG MAKING SURE THAT
1685 ; THE CHARACTER IS ALL ZERO'S
1686 ; AND THAT THE TX LINE GOES BACK TO
1687 ; A MARK STATE WHEN DONE.
1688 ;

1689 ; TEST 17
1690 ; *****
1691 ;

1692 003752 012737 000017 001226 TST17: MOV #17,TSTNO
1693 003760 012737 004000 001216 MOV #TST20,NEXT
1694 003766 004537 010720 JSR R5, TXSTRB ; DO JSR TO THE SUBROUTINE
1695 003772 000015 13. ; NUMBER OF TIMES CHAR IS TO BE SHIFTED
1696 003774 001400 1400 ; BIT SELECTION TO BE PLACED INTO MISC REG
1697 003776 104400 SCOPE ; SCOPE THE TEST

1698 ;
1699 ; TEST TO TRANSMITT A CHARACTER
1700 ; 14 BITS LONG MAKING SURE THAT
1701 ; THE CHARACTER IS ALL ZERO'S
1702 ; AND THAT THE TX LINE GOES BACK TO
1703 ; A MARK STATE WHEN DONE.
1704 ;

1705 ; TEST 20
1706 ; *****
1707 ;

1708 004000 012737 000020 001226 TST20: MOV #20,TSTNO
1709 004006 012737 004026 001216 MOV #TST21,NEXT
1710 004014 004537 010720 JSR R5, TXSTRB ; DO JSR TO THE SUBROUTINE
1711 004020 000016 14. ; NUMBER OF TIMES CHAR IS TO BE SHIFTED
1712 004022 001000 1000 ; BIT SELECTION TO BE PLACED INTO MISC REG
1713 004024 104400 SCOPE ; SCOPE THE TEST

1714 ;
1715 ; TEST TO TRANSMITT A CHARACTER
1716 ; 15 BITS LONG MAKING SURE THAT
1717 ; THE CHARACTER IS ALL ZERO'S
1718 ; AND THAT THE TX LINE GOES BACK TO
1719 ; A MARK STATE WHEN DONE.
1720 ;

1721 ; TEST 21
1722 ;
1723 ;
1724 ;
1725 ;

K03

DZDQD MACY11 27(1006) 22-DEC-76 11:14 PAGE 36
 DZDQDD.P11 21-DEC-76 16:32 DQ11 TRANSMITTER AND RECEIVER EXERCISER.

```

1726
1727 004026 012737 000021 001226 *****
1728 004034 012737 004054 001216 †ST21: MOV #21,TSTNO
1729 004042 004537 010720 JSR #TST22,NEXT ;DO JSR TO THE SUBROUTINE
1730 004046 000017 15. ;NUMBER OF TIMES CHAR IS TO BE SHIFTED
1731 004050 000400 400 ;BIT SELECTION TO BE PLACED INTO MISC REG
1732 004052 104400 SCOPE ;SCOPE THE TEST
1733
1734 ;
1735 ;TEST TO TRANSMITT A CHARACTER
1736 ; 16 BITS LONG MAKING SURE THAT
1737 ; THE CHARACTER IS ALL ZERO'S
1738 ; AND THAT THE TX LINE GOES BACK TO
1739 ; A MARK STATE WHEN DONE.
1740 ;
1741 ;
1742 ; TEST 22
1743 *****
1744 004054 012737 000022 001226 †ST22: MOV #22,TSTNO
1745 004062 012737 004102 001216 MOV #TST23,NEXT
1746 004070 004537 010720 JSR R5,TXSTRB ;DO JSR TO THE SUBROUTINE
1747 004074 000020 16. ;NUMBER OF TIMES CHAR IS TO BE SHIFTED
1748 004076 000000 0 ;BIT SELECTION TO BE PLACED INTO MISC REG
1749 004100 104400 SCOPE ;SCOPE THE TEST
1750
1751 ;
1752 ;
1753 ;
1754 ;
1755 ;TEST OF TRANSMITTER IDLE SYNC
1756 ;TEST THAT THE TRANSMITTER CAN
1757 ;REALLY IDLE SYNC CHARACTERS
1758
1759 ;
1760 ; TEST 23
1761 *****
1762 004102 012737 000023 001226 †ST23: MOV #23,TSTNO
1763 004110 012737 004436 001216 MOV #TST24,NEXT
1764 004116 005077 175242 CLR #DQTCR ;CLR TX STATUS
1765 004122 032777 000002 175234 BIT #BIT1,DQTCR ;IDLE SET?
1766 004130 001401 BEQ .+4
1767 004132 104000 HLT ;IDLE SHOULD NOT BE SET!
1768 004134 052777 000002 175222 BIS #BIT1,DQTCR ;SET IDLE BIT
1769 004142 032777 000002 175214 BIT #BIT1,DQTCR ;IS IDLE SET?
1770 004150 001001 BNE .+4 ;BR IF SET.
1771 004152 104000 HLT ;IDLE BIT SHOULD BE SET!
1772 004154 042777 000002 175202 BIC #BIT1,DQTCR ;CLEAR IDLE BIT.
1773 004162 032777 000002 175174 BIT #BIT1,DQTCR ;IS IDLE BIT SET?
1774 004170 001401 BEQ .+4 ;BR IF CLEAR.
1775 004172 104000 HLT ;IDLE BIT NOT CLEARED.
1776 004174 052777 000002 175162 BIS #BIT1,DQTCR ;SET IDLE
1777 004202 104412 MSTCLR
1778 004204 032777 000002 175152 BIT #BIT1,DQTCR ;IS IDLE SET?
1779 004212 001401 BEQ .+4
1780 004214 104000 HLT ;IDLE BIT NOT CLEARED BY INIT!
1781 004216 012737 000005 001250 MOV #5,TEMP3
  
```

```

1782 004224 012737 000377 014056
1783 004232 112777 000011 175130
1784 004240 013777 014520 175124
1785 004246 012737 000010 014062
1786 004254 012737 004000 014064
1787 004262 112777 000002 175100
1788 004270 012777 014056 175074
1789 004276 105277 175066
1790 004302 012777 177777 175062
1791 004310 112777 000012 175052
1792 004316 053777 014064 175046
1793 004324 052777 000012 175040
1794 004332 052777 000002 175024
1795 004340 005037 001252
1796 004344 006037 001252
1797 004350 005277 175016
1798 004354 005377 175012
1799 004360 017702 175006
1800 004364 042702 177577
1801 004370 050237 001252
1802 004374 005337 014062
1803 004400 001361
1804 004402 005137 001252
1805 004406 012737 000026 001254
1806 004414 123737 001254 001252
1807 004422 001401
1808 004424 104012
1809 004426 005337 001250
1810 004432 001274
1811 004434 104400

```

```

1S:  MOV      #377,WORD
      MOVB   #11,2DQREG
      MOV    .SYNCR,2DQSEC
      MOV    #10,COUNT
      MOV    #4000,BITSEL
      MOVB   #2,2DQREG
      MOV    #WORD,2DQSEC
      INCB   2DQREG
      MOV    #-1,2DQSEC
      MOVB   #MISC.,2DQREG
      BIS    BITSEL,2DQSEC
      BIS    #12,2DQSEC
      BIS    #BIT1,2DQCSR
      CLR    TEMP4
2S:  ROR     TEMP4
      INC    2DQSEC
      DEC    2DQSEC
      MOV    2DQSEC,R2
      BIC   #177577,R2
3S:  BIS    R2,TEMP4
      DEC    COUNT
      BNE   2S
      COM   TEMP4
      MOV   #26,TEMP5
      CMPB TEMP5,TEMP4
      BEQ   .+4
      HLT  12
      DEC  TEMP3
      BNE  1S
      SCOPE

```

```

;PICK UP THE NUMBER OF SHIFTS
;PICK UP NUMBER OF BIT PER CHAR.
;SELECT THE TRANSMITTER BA PRI.
;LOAD THE BA
;SELECT THE TRANSMITTER CC PRI.
;LOAD THE CC WITH -1
;SELECT THE MISC REGISTER.
;LOAD MISC REG WITH NUMBER OF BITS PER CHAR.
;ADD TO THAT TEST LOOP AND AUTO STEP.
;SET TRANSMITTER IDLE MODE.

;SHIFT THE STORAGE OF DATA FROM THE TRANSMITTER.
;CLOCK THE TRANSMITTER -UP-
;CLOCK THE TRANSMITTER -DOWN-
;MOVE THE MISC REG TO R2
;CLEAR ALL BUT THE BIT WINDOW.
;PLACE DATA INTO TEMPORY LOCATION
;IS CHARACTER COMPLETELY SHIFTED OUT?
;BRANCH IF MORE BITS TO GO.
;COMPLIMENT DATA STORAGE

```

```

;
;TRANSMITTER DATA REALIBILITY TEST.
;TEST TO TRANSMITT AN EIGHT
;BIT BINARY COUNT PATTERN (000-377)
;
;NOTE THIS TEST IS FOR UP TO EIGHT BITS PER CHARACTER.
;PARITY WILL BE ENABLED WHEN "PARFLG" IS NON-ZERO
;

```

```

1827
1828
1829 004436 012737 000024 001226
1830 004444 012737 004570 001216
1831 004452 012737 004472 001220
1832 004460 105037 012602
1833 004464 005000
1834 004466 005037 014052
1835 004472 010037 014056
1836 004476 005037 001252
1837 004502 104412

```

```

; TEST 24
;*****
TST24: MOV    #24,TSTNO
        MOV    #TST25,NEXT
        MOV    #25,LOCK
1S:     CLRB   PARFLG
        CLR   RO
2S:     CLR   EXTFLG
        MOV   RO,WORD
        CLR   TEMP4
        MSTCLR

```

```

;SET DATA TO ZERO
;TELL SUBROUTINE THIS IS FOR EIGHT BITS
;PLACE DATA FOR WORK.
;CCLEAR WHERE CHAR IS TO BE STORED
;MASTER CLEAR

```


M03

DZD00 MACY11 27(1006) 22-DEC-76 11:14 PAGE 38
 DZD000.P11 21-DEC-76 16:32 DQ11 TRANSMITTER AND RECEIVER EXERCISER.

1838	004504	004537	011266		JSR	R5, TXSTRD	;GO TO ROUTINE
1839	004510	000010			B.	4000	;NUMBER OF SHIFTS REQUIRED
1840	004512	004000			TSTB	PARFLG	;EIGHT BITS
1841	004514	105737	012602		BEQ	.+6	
1842	004520	001402			JSR	PC, GENPAR	
1843	004522	004737	012444		MOV	WORD, TEMPS	;STORE GOOD CHARACTER
1844	004526	013737	014056	001254	CMPB	TEMPS, TEMP4	;COMPARE GOOD CHAR TO TX CHAR
1845	004534	123737	001254	001252	BEQ	.+4	;BR IF SAME
1846	004542	001401			HLT	12	;DATA COMPARISON ERROR
1847	004544	104012			SCOPI		;DOES USER WANT TO LOCK ON THIS CHAR?
1848	004546	104401			INCB	R0	;UPDATE GOOD CHARACTER
1849	004550	105200			BNE	2S	;IF NOT ALL CHARACTERS GO DO AGAIN
1850	004552	001347			MOV	#200, R0	
1851	004554	012700	000200		COMB	PARFLG	
1852	004560	105137	012602		BNE	2S	
1853	004564	001342			SCOPE		;SCOPE THIS TEST
1854	004566	104400					
1855							
1856							;TRANSMITTER DATA REALIBILITY TEST
1857							;TEST TO TRANSMITT AN EIGHT BIT
1858							;BINARY COUNT PATTERN (000400-177400)
1859							
1860							;PARITY WILL BE ENABLED WHEN "PARFLG" IS NON-ZERO
1861							;NOTE THIS IS FOR 16 BITS PER CHAR. (LOW BYTE IS=0; THE HIGH BYTE =BINARY COUNT.
1862							
1863							
1864							
1865	004570	012737	000025	001226			
1866	004576	012737	004730	001216	TST25:	MOV #25, TSTNO	
1867	004604	012737	004626	001220		MOV #TST26, NEXT	
1868	004612	112737	000377	014052		MOV #2S, LOCK	
1869	004620	105037	012602			MOVB #377, EXTFLG	;TELL SUBROUTINE THIS IS FOR 16 BITS PER CHAR
1870	004624	005000				CLRB PARFLG	;NO PARITY CHECKING NOW
1871	004626	010037	014056		1S:	CLR R0	;ZERO DATA POINTER
1872	004632	000337	014056		2S:	MOV R0, WORD	;PREPARE DATA FOR SUBROUTINE
1873	004636	005037	001252			SWAB WORD	;PUT DATA IN HIGH BYTE
1874	004642	104412				CLR TEMP4	;ZERO STORE AREA
1875	004644	004537	011266			MSTCLR	;INIT DQ11
1876	004650	000020				JSR R5, TXSTRD	;GOTO SUBROUTINE
1877	004652	000000				16.	;THIS IS NUMBER OF SHIFTS.
1878	004654	105737	012602			0	;THIS IS BITS/PER/CHARACTER SELECT
1879	004660	001402				TSTB PARFLG	;IS PARITY ENABLED?
1880	004662	004737	012444			BEQ .+6	;BR IF NOT ENABLED
1881	004666	013737	014056	001254		JSR PC, GENPAR	;GO CALCULATE THE PARITY
1882	004674	023737	001254	001252		MOV WORD, TEMPS	;STORE THE CHARACTER
1883	004702	001401				CMP TEMPS, TEMP4	;IS THE CHARACTER CORRECT
1884	004704	104012				BEQ .+4	;BR IF GOOD
1885	004706	104401				HLT 12	;DATA COMPARISON ERROR.
1886	004710	105200				SCOPI	;LOCK ON DATA? (SW09=1)
1887	004712	001345				INCB R0	;UPDATE DATA POINTER
1888	004714	012700	000200			BNE 2S	;BR IF MORE TO GO
1889	004720	105137	012602			MOV #200, R0	
1890	004724	001340				COMB PARFLG	;NOW ENABLE THE PARITY TEST.
1891	004726	104400				BNE 2S	;BR IF FIRST TIME FOR PARITY
						SCOPE	;SCOPE THE TEST.

N03

DZD00 MACY11 27(1006) 22-DEC-76 11:14 PAGE 39
 DZD000.P11 21-DEC-76 16:32 D011 TRANSMITTER AND RECEIVER EXERCISER.

```

1892
1893
1894
1895
1896
1897
1898
1899
1900
1901
1902 004730 012737 000026 001226
1903 004736 012737 004756 001216
1904 004744 004537 012132
1905 004750 007000
1906 004752 000002
1907 004754 104400
1908
1909
1910
1911
1912
1913 004756 012737 000027 001226
1914 004764 012737 005004 001216
1915 004772 004537 012132
1916 004776 006400
1917 005000 000004
1918 005002 104400
1919
1920
1921
1922
1923
1924 005004 012737 000030 001226
1925 005012 012737 005032 001216
1926 005020 004537 012132
1927 005024 006000
1928 005026 000010
1929 005030 104400
1930
1931
1932
1933
1934
1935 005032 012737 000031 001226
1936 005040 012737 005060 001216
1937 005046 004537 012132
1938 005052 005400
1939 005054 000020
1940 005056 104400
1941
1942
1943
1944
1945
1946 005060 012737 000032 001226
1947 005066 012737 005106 001216

;RECEIVER CHARACTER LENGTH TEST
;TEST THAT ALL CHARACTER
;LENGTHS WORK CORRECTLY.
;TEST OF RX CHARACTER LENGTH 2 BITS LONG.
;TEST 26
;*****
TST26: MOV #26,TSTNO
MOV #TST27,NEXT
JSR R5,RXLNG ;GOTO JSR SUBROUTINE
7000 ;CHARACTER EXPECTED TO FIND
2 ;BITS/PER/CHAR TO BE PLACED INTO MISC REG
SCOPE ;SCOPE THIS TEST
;TEST OF RX CHARACTER LENGTH 3 BITS LONG.
;TEST 27
;*****
TST27: MOV #27,TSTNO
MOV #TST30,NEXT
JSR R5,RXLNG ;GOTO JSR SUBROUTINE
6400 ;CHARACTER EXPECTED TO FIND
4 ;BITS/PER/CHAR TO BE PLACED INTO MISC REG
SCOPE ;SCOPE THIS TEST
;TEST OF RX CHARACTER LENGTH 4 BITS LONG.
;TEST 30
;*****
TST30: MOV #30,TSTNO
MOV #TST31,NEXT
JSR R5,RXLNG ;GOTO JSR SUBROUTINE
6000 ;CHARACTER EXPECTED TO FIND
10 ;BITS/PER/CHAR TO BE PLACED INTO MISC REG
SCOPE ;SCOPE THIS TEST
;TEST OF RX CHARACTER LENGTH 5 BITS LONG.
;TEST 31
;*****
TST31: MOV #31,TSTNO
MOV #TST32,NEXT
JSR R5,RXLNG ;GOTO JSR SUBROUTINE
5400 ;CHARACTER EXPECTED TO FIND
20 ;BITS/PER/CHAR TO BE PLACED INTO MISC REG
SCOPE ;SCOPE THIS TEST
;TEST OF RX CHARACTER LENGTH 6 BITS LONG.
;TEST 32
;*****
TST32: MOV #32,TSTNO
MOV #TST33,NEXT

```



```

1948 005074 004537 012132 JSR RS,RXLNG ;GOTO JSR SUBROUTINE
1949 005100 005000 5000 ;CHARACTER EXPECTED TO FIND
1950 005102 000040 40 ;BITS/PER/CHAR TO BE PLACED INTO MISC REG
1951 005104 104400 SCOPE ;SCOPE THIS TEST
1952
1953 ;TEST OF RX CHARACTER LENGTH 7 BITS LONG.
1954
1955 ; TEST 33
1956 ;*****
1957 005106 012737 000033 001226 TST33: MOV #33,TSTNO
1958 005114 012737 005134 001216 MOV #TST34,NEXT
1959 005122 004537 012132 JSR RS,RXLNG ;GOTO JSR SUBROUTINE
1960 005126 004400 4400 ;CHARACTER EXPECTED TO FIND
1961 005130 000100 100 ;BITS/PER/CHAR TO BE PLACED INTO MISC REG
1962 005132 104400 SCOPE ;SCOPE THIS TEST
1963
1964 ;TEST OF RX CHARACTER LENGTH 8 BITS LONG.
1965
1966 ; TEST 34
1967 ;*****
1968 005134 012737 000034 001226 TST34: MOV #34,TSTNO
1969 005142 012737 005162 001216 MOV #TST35,NEXT
1970 005150 004537 012132 JSR RS,RXLNG ;GOTO JSR SUBROUTINE
1971 005154 004000 4000 ;CHARACTER EXPECTED TO FIND
1972 005156 000200 200 ;BITS/PER/CHAR TO BE PLACED INTO MISC REG
1973 005160 104400 SCOPE ;SCOPE THIS TEST
1974
1975 ;RECEIVER CHARACTER LENGTH TEST
1976 ;FOR CHARACTERS OVER EIGHT BITS LONG.
1977
1978 ;TEST OF CHARACTER LENGTH 9 BITS LONG.
1979
1980 ; TEST 35
1981 ;*****
1982
1983 005162 012737 000035 001226 TST35: MOV #35,TSTNO
1984 005170 012737 005210 001216 MOV #TST36,NEXT
1985 005176 004537 012302 JSR RS,RXLNG ;GOTO SUBROUTINE
1986 005202 003400 3400 ;CHARACTER EXPECTED TO BE FOUND
1987 005204 000400 400 ;BITS/PER/CHAR TO BE PLACED INTO MISC REG
1988 005206 104400 SCOPE ;SCOPE THIS TEST
1989
1990 ;TEST OF CHARACTER LENGTH 10 BITS LONG.
1991
1992 ; TEST 36
1993 ;*****
1994
1995 005210 012737 000036 001226 TST36: MOV #36,TSTNO
1996 005216 012737 005236 001216 MOV #TST37,NEXT
1997 005224 004537 012302 JSR RS,RXLNG ;GOTO SUBROUTINE
1998 005230 003000 3000 ;CHARACTER EXPECTED TO BE FOUND
1999 005232 001000 1000 ;BITS/PER/CHAR TO BE PLACED INTO MISC REG
2000 005234 104400 SCOPE ;SCOPE THIS TEST
2001
2002 ;TEST OF CHARACTER LENGTH 11 BITS LONG.
2003

```

2004
2005
2006
2007
2008
2009
2010
2011
2012
2013
2014
2015
2016
2017
2018
2019
2020
2021
2022
2023
2024
2025
2026
2027
2028
2029
2030
2031
2032
2033
2034
2035
2036
2037
2038
2039
2040
2041
2042
2043
2044
2045
2046
2047
2048
2049
2050
2051
2052
2053
2054
2055
2056
2057
2058
2059

```

; TEST 37
;*****
TST37:  MOV      #37,TSTNO
        MOV      #TST40,NEXT
        JSR      RS,RXELNG      ;GOTO SUBROUTINE
        2400      ;CHARACTER EXPECTED TO BE FOUND
        2000      ;BITS/PER/CHAR TO BE PLACED INTO MISC REG
        SCOPE      ;SCOPE THIS TEST

;TEST OF CHARACTER LENGTH 12 BITS LONG.

; TEST 40
;*****
TST40:  MOV      #40,TSTNO
        MOV      #TST41,NEXT
        JSR      RS,RXELNG      ;GOTO SUBROUTINE
        2000      ;CHARACTER EXPECTED TO BE FOUND
        4000      ;BITS/PER/CHAR TO BE PLACED INTO MISC REG
        SCOPE      ;SCOPE THIS TEST

;TEST OF CHARACTER LENGTH 13 BITS LONG.

; TEST 41
;*****
TST41:  MOV      #41,TSTNO
        MOV      #TST42,NEXT
        JSR      RS,RXELNG      ;GOTO SUBROUTINE
        1400      ;CHARACTER EXPECTED TO BE FOUND
        10000     ;BITS/PER/CHAR TO BE PLACED INTO MISC REG
        SCOPE      ;SCOPE THIS TEST

;TEST OF CHARACTER LENGTH 14 BITS LONG.

; TEST 42
;*****
TST42:  MOV      #42,TSTNO
        MOV      #TST43,NEXT
        JSR      RS,RXELNG      ;GOTO SUBROUTINE
        1000      ;CHARACTER EXPECTED TO BE FOUND
        20000     ;BITS/PER/CHAR TO BE PLACED INTO MISC REG
        SCOPE      ;SCOPE THIS TEST

;TEST OF CHARACTER LENGTH 15 BITS LONG.

; TEST 43
;*****
TST43:  MOV      #43,TSTNO
        MOV      #TST44,NEXT
        JSR      RS,RXELNG      ;GOTO SUBROUTINE
        400      ;CHARACTER EXPECTED TO BE FOUND
        40000    ;BITS/PER/CHAR TO BE PLACED INTO MISC REG
        SCOPE      ;SCOPE THIS TEST

;TEST OF CHARACTER LENGTH 16 BITS LONG.

; TEST 44

```

005236	012737	000037	001226
005244	012737	005264	001216
005252	004537	012302	
005256	002400		
005260	002000		
005262	104400		
005264	012737	000040	001226
005272	012737	005312	001216
005300	004537	012302	
005304	002000		
005306	004000		
005310	104400		
005312	012737	000041	001226
005320	012737	005340	001216
005326	004537	012302	
005332	001400		
005334	010000		
005336	104400		
005340	012737	000042	001226
005346	012737	005366	001216
005354	004537	012302	
005360	001000		
005362	020000		
005364	104400		
005366	012737	000043	001226
005374	012737	005414	001216
005402	004537	012302	
005406	000400		
005410	040000		
005412	104400		


```

2060
2061 005414 012737 000044 001226 *****
2062 005422 012737 005442 001216 †TST44: MOV #44,TSTNO
2063 005430 004537 012302 JSR #TST45,NEXT
2064 005434 000000 0 JSR RS,RXELNG ;GOTO SUBROUTINE
2065 005436 100000 0 ;CHARACTER EXPECTED TO BE FOUND
2066 005440 104400 100000 ;BITS/PER/CHAR TO BE PLACED INTO MISC REG
2067 ;SCOPE THIS TEST
2068
2069 ;
2070 ;TEST THAT SYNC1 AND SYNC2
2071 ;SET WHEN RECEIVER ACTIVE SET
2072 ;AND IF THEY DO THE TEST THAT THEY
2073 ;CLEAR BY MASTER CLEAR.
2074
2075 ; TEST 45
2076 *****
2077 005442 012737 000045 001226 †TST45: MOV #45,TSTNO
2078 005450 012737 005546 001216 MOV #TST46,NEXT
2079 005456 112777 000012 173704 MOVB #MISC.,DQREG ;SELECT THE MISC REGISTER
2080 005464 012777 000012 173700 MOV #12,DQSEC ;SET TEST LOOP AND AUTO/STEP
2081 005472 052777 010000 173660 BIS #BIT12,DQRCR ;SET RX ACTIVE
2082 005500 017700 173666 MOV DQSEC,R0 ;READ THE DQSEC
2083 005504 042700 147777 BIC #147777,R0 ;CLEAR ALL BUT SYNC 1 AND SYNC 2
2084 005510 022700 030000 CMP #30000,R0 ;DID BOTH OF THEM SET?
2085 005514 001401 BEQ .+4 ;BR IF GOOD
2086 005516 104016 HLT 16 ;SYNC 1 AND SYNC 2 NOT SET.
2087 005520 052777 000040 173644 BIS #BITS,DQSEC ;SET MASTER CLEAR
2088 005526 112777 000012 173634 MOVB #MISC.,DQREG ;RESELECT THE MISC REGISTER
2089 005534 005777 173632 TST DQSEC ;IS THE DQSEC =0
2090 005540 001401 BEQ .+4 ;BR IF YES
2091 005542 104017 HLT 17 ;DQSEC NOT=0
2092 ;SCOPE THIS TEST.
2093
2094
2095 ;
2096 ;SYNC TESTS.
2097 ;TEST THAT RECEIVER ACTIVE AND SYNC 1 AND SYNC 2
2098 ;ASSERT AT THE PROPER TIME.
2099 ;TEST INVOLVES BOTH SYNCING AN AN EIGHT BIT CHAR
2100 ;AND A SIXTEEN BIT CHAR.
2101
2102 ;LOOK AT LOCATION "WORD"
2103 ;IF "WORD IS EQUAL TO 377 THE THE EIGHT
2104 ;BIT PER CHAR IS BEING EXECUTED.
2105 ;IF "WORD" IS EQUAL TO 177777 THEN THE SYXTEEN
2106 ;BIT PER CHAR IS BEING EXECUTED.
2107
2108 ; TEST 46
2109 *****
2110 005546 012737 000046 001226 †TST46: MOV #46,TSTNO
2111 005554 012737 005576 001216 MOV #TST47,NEXT
2112 005562 004537 005626 JSR RS,SYNST ;GOTO THE ACTUAL TEST.
2113 005566 000377 0 ;DATA CHAR FOR EIGHT BITS PER CHAR.
2114 005570 000010 0 ;SHIFTS PER CHAR. NEEDED FOR TEST
2115 005572 004000 4000 ;BITS PER CHAR SELECTION FOR DQSEC.
2116 005574 104400 ;SCOPE
    
```

2116
2117
2118
2119
2120
2121
2122
2123
2124
2125
2126
2127
2128
2129
2130
2131
2132
2133
2134
2135
2136
2137
2138
2139
2140
2141
2142
2143
2144
2145
2146
2147
2148
2149
2150
2151
2152
2153
2154
2155
2156
2157
2158
2159
2160
2161
2162
2163
2164
2165
2166
2167
2168
2169
2170
2171

005576 012737 000047 001226
005604 012737 006236 001216
005612 004537 005626
005616 177777
005620 000020
005622 000000
005624 104400

005626
005626 012537 014056
005632 011537 005722
005636 011537 006044
005642 162737 000002 006044
005650 012537 006166
005654 005337 006166
005660 011537 005724
005664 011537 006046
005670 012537 006170
005674 010537 006234
005700 104412
005702 112777 000011 173460
005710 012777 177777 173454
005716 004537 011522
005722 000001
005724 000001
005726 112777 000012 173434
005734 032777 020000 173430
005742 001401
005744 104000
005746 032777 010000 173404
005754 001401
005756 104000
005760 005277 173406
005764 005377 173402
005770 032737 100000 001510
005776 001003
006000 005337 006166
006004 000442
006006 017700 173360
006012 042700 147777
006016 022700 020000
006022 001401
006024 104000

: ABOVE TEST FOR EIGHT BITS PER CHAR.
: BELOW TEST FOR SIXTEEN BITS PER CHAR.

: TEST 47
: *****
TST47: MOV #47, TSTNO
MOV #TST50, NEXT
JSR RS, SYNTST ; GOTO THE ACTUAL TEST
177777 ; DATA FOR 16 BITS PER CHAR.
16. ; SHIFTS PER CHAR.
0000 ; SELECTION FOR DQSEC BITS/PER CHAR.
SCOPE ; SCOPE THIS TEST

: TEST THAT SYNC 1 AND SYNC 2
: SET WHEN DATA IS RECEIVED
: THIS TEST WILL CHECK FOR EITHER
: 1 OR 2 SYNC CHARACTERS.

SYNTST: MOV (RS)+, WORD ; GET DATA CHARACTER
MOV (RS), 4\$; GET NUMBER OF SHIFTS.
MOV (RS), 6\$
SUB #2, 6\$; ADJUST SHIFTS.
MOV (RS)+, 8\$; GET THE SHIFTS
DEC 8\$; ADJUST THE SHIFTS.
MOV (RS), 5\$; GET THE BITS/PER CHAR.
MOV (RS), 7\$
MOV (RS)+, 9\$
MOV RS, 10\$; SAVE THE PC TO RETURN
MSTCLR ; INIT THE D011
MOV #11, 2DQREG ; SEL THE SYNC REG
MOV #-1, 2DQSEC ; SET SYNC CHAR TO ALL 1'S
JSR RS, RXSTRA ; GOTO THE SUBROUTINE
4\$: .BLKW 1 ; NUMBER OF SHIFTS
5\$: .BLKW 1 ; MISC FUNCTION
MOV #MISC, 2DQREG ; SELECT THE MISC REGISTER
BIT #BIT13, 2DQSEC ; IS SYNC 1 UP YET
BEQ .+4 ; BR IF NO
HLT ; SYNC 1 UP TOO SOON
BIT #BIT12, 2DQRCR ; ACTIVE UP??
BEQ .+4 ; BR IF ACTIVE NOT UP
HLT ; ACTIVE UP TOO SOON.
INC 2DQSEC ; CLOCK UP
DEC 2DQSEC ; CLOCK DN
BIT #SYNBIT, DQSTAT ; NUMBER OF SYNC CHARS=?
BNE .+10 ; BR IF TWO SYNC CHAR.
DEC 8\$; ADJUST COUNT WHEN ONE SYNC SELECTED.
BR 1\$; BR TO TEST ONE SYNC CHAR.
MOV 2DQSEC, R0 ; READ DQSEC
BIC #147777, R0 ; CLEAR GARBAGE
CMP #20000, R0 ; IS SYNC 1 UP?
BEQ .+4 ; BR IF YES
HLT ; SYNC ONE NOT SET OR SYNC 2 IS SET

2172	006026	032777	010000	173324	BIT	#BIT12, @DQRC	: ACTIVE UP?
2173	006034	001401			BEQ	.+4	: BR IF ACTIVE =0
2174	006036	104000			HLT		: ACTIVE UP TOO SOON
2175	006040	004537	011522		JSR	RS, RXSTRA	: GOTO THE SUBROUTINE
2176	006044	000001			6S: .BLKW 1		: NUMBER OF SHIFTS MINUS 2
2177	006046	000001			7S: .BLKW 1		: MISC FUNCTION (PERS PER CHAR).
2178	006050	017700	173316		MOV	@DQSEC, R0	: READ THE DQSEC
2179	006054	042700	147777		BIC	#147777, R0	: CLEAR ALL BUT SYNC 1 AND SYNC 2
2180	006060	022700	020000		CMP	#20000, R0	: ARE BOTH SYNC 1 *AND* SYNC 2 SET?
2181	006064	001401			BEQ	.+4	: BR IF YES
2182	006066	104000			HLT		: EITHER OR BOTH SYNC 1 OR SYNC 2 NOT SET.
2183	006070	032777	010000	173262	BIT	#BIT12, @DQRC	: ACTIVE UP??
2184	006076	001401			BEQ	.+4	: BR IF ACTIVE NOT SET.
2185	006100	104000			HLT		: ACTIVE UP TOO SOON
2186	006102	005277	173264		INC	@DQSEC	: CLOCK UP.
2187	006106	005377	173260		DEC	@DQSEC	: CLOCK DN
2188	006112	017700	173254		1S: MOV	@DQSEC, R0	: READ AND SAVE DQSEC
2189	006116	042700	147777		BIC	#147777, R0	: CLEAR ALL BUT SYNC 1 AND SYNC 2
2190	006122	022700	030000		CMP	#30000, R0	: ARE BOTH SYNC 1 AND SYNC 2 SET?
2191	006126	001401			BEQ	.+4	: BR IF YES
2192	006130	104000			HLT		: EITHER OR BOTH SYNC 1 OR SYNC 2 NOT SET.
2193	006132	032737	004000	001510	BIT	#ACTBIT, DQSTAT	: WHEN DO YOU GO ACTIVE??
2194	006140	001006			2S: BNE	2S	: BR IF ACTIVE ON FIRST NON-SYNC.
2195	006142	032777	010000	173210	BIT	#BIT12, @DQRC	: IS ACTIVE UP?
2196	006150	001001			BNE	.+4	: *** NOW ACTIVE SHOULD BE SET***
2197	006152	104000			HLT		: NOW ACTIVE SHOULD BE UP..
2198	006154	000424			BR	3S	: ALL DONE GO HOME
2199	006156	005037	014056		2S: CLR	WORD	: SET DATA TO NON-SYNC
2200	006162	004537	011522		JSR	RS, RXSTRA	: PUSH IT INTO THE RECEIVER
2201	006166	000001			8S: .BLKW 1		: NUMBER OF SHIFTS MINUS 1
2202	006170	000001			9S: .BLKW 1		: MISC FUNCTION.
2203	006172	032777	010000	173160	BIT	#BIT12, @DQRC	: ACTIVE UP
2204	006200	001401			BEQ	.+4	: ONE MORE SHIFT BEFORE ACTIVE=1
2205	006202	104000			HLT		: ACTIVE IS UP TOO SOON
2206	006204	005277	173162		INC	@DQSEC	: FINAL CLOCK UP
2207	006210	005377	173156		DEC	@DQSEC	: CLOCK DN
2208	006214	032777	010000	173136	BIT	#BIT12, @DQRC	: **** NOW ACTIVE SHOULD BE SET **
2209	006222	001001			BNE	.+4	: BR IF ACTIVE =1
2210	006224	104000			HLT		: ACTIVE ON FIRST NON-SYNC NOT WORKING.
2211	006226	013705	006234		3S: MOV	10S, R5	: RESTORE PC POINTER
2212	006232	000205			RTS	R5	: GOTO MAIN TEST
2213	006234	000000			10S: 0		: STORE R5 (PC) HERE.

: TEST OF RECEIVER CHARACTER COUNT AND BUSS
 : ADDRESS. TEST TO MAKE SURE
 : THAT THEY INCREMENT PROPERELY.

: TEST WITH CHARACTER COUNT OF -1 (ODD)

: TEST 50
 : *****

2214
 2215
 2216
 2217
 2218
 2219
 2220
 2221
 2222
 2223
 2224
 2225
 2226
 2227

```

2228 006236 012737 000050 001226 TST50: MOV      #50,TSTNO
2229 006244 012737 006364 001216      MOV      @TST51,NEXT
2230 006252 104412                MSTCLR
2231 006254 105077 173110          CLRB    @DQREG      ;INIT D01!
2232 006260 012777 014116 173104      MOV      @RXBUFF,@DQSEC ;SEL RX BA PRI.
2233 006266 105277 173076          INCB    @DQREG      ;SET RX BA PRI.
2234 006272 012777 177777 173072      MOV      @-1,@DQSEC   ;SEL RX WC PRI.
2235 006300 112777 000012 173062      MOV      @MISC,@DQREG ;ONE CHAR RECEIVE
2236 006306 012777 004010 173056      MOV      @4010,@DQSEC ;SELECT THE MISC REG.
2237 006314 012777 010001 173036      MOV      @10001,@DQRC ;SET EIGHT BITS AND TEST LOOP
2238 006322 105777 173032          TSTB    @DQRC       ;SET RX ACTIVE AND RX GO!!
2239 006326 100375                BPL     .-4         ;RX PRI DONE?
2240 006330 105077 173034          CLRB    @DQREG      ;HANG HERE TILL DONE.
2241 006334 022777 014117 173030      CMP     @RXBUFF+1,@DQSEC ;GET RA BA PRI.
2242 006342 001401                BEQ     .+4         ;DID BA INC RIGHT?
2243 006344 104000                HLT
2244 006346 105277 173016          INCB    @DQREG      ;BR IF BA GOOD
2245 006352 005777 173014          TST     @DQSEC     ;RX BA ERROR.
2246 006356 001401                BEQ     .+4         ;GET RX WC PRI.
2247 006360 104000                HLT             ;DID IT GOTO ZERO?
2248 006362 104400                SCOPE          ;BR IF YES
2249
2250
2251
2252
2253
2254
2255
2256
2257
2258
2259
2260
2261
2262
2263
2264
2265
2266
2267
2268
2269
2270
2271
2272
2273
2274
2275
2276
2277
2278
2279
2280
2281
2282
2283

```

```

;
; TEST OF RECEIVER CHARACTER COUNT
; AND BUSS ADDRESS
; WITH A CHARACTER COUNT OF -2 (EVEN)
; MAKING SURE THAT THE CC AND BA
; INCREMENT CORRECTLY.

```

```

; TEST 51
; *****
TST51: MOV      #51,TSTNO
      MOV      @TST52,NEXT
      MSTCLR
      CLRB    @DQREG      ;ISSUE CLEAR
      MOV      @RXBUFF,@DQSEC ;SELECT THE RX BA PRI
      INCB    @DQREG      ;SET RX BA PRI.
      MOV      @-2,@DQSEC   ;SELECT RX WC PRI.
      MOV      @MISC,@DQREG ;SET FOR TWO CHARS
      MOV      @4010,@DQSEC ;SELECT THE MISC REGISTER
      MOV      @10001,@DQRC ;SET EIGHT BITS AND TEST LOOP
      TSTB    @DQRC       ;SET RX ACTIVE AND GO!!
      BPL     .-4         ;WAIT FOR RX PRI DONE.
      CLRB    @DQREG      ;HANG HERE TILL DONE
      CMP     @RXBUFF+2,@DQSEC ;SELECT THE RX BA PRI
      BEQ     .+4         ;DID RX BA INCREMENT RIGHT?
      HLT
      INCB    @DQREG      ;BR IF GOOD
      TST     @DQSEC     ;RX BA ERROR
      BEQ     .+4         ;SELECT THE RX WC PRI.
      HLT             ;DID IF GOTO ZERO
      SCOPE          ;BR IF YES
                   ;RX WC NOT =ZERO
                   ;SCOPE THE TEST

```


2284
2285
2286
2287
2288
2289
2290
2291
2292
2293
2294
2295
2296
2297
2298
2299
2300
2301
2302
2303
2304
2305
2306
2307
2308
2309
2310
2311
2312
2313
2314
2315
2316
2317
2318
2319
2320
2321
2322
2323
2324
2325
2326
2327
2328
2329
2330
2331
2332
2333
2334
2335
2336
2337
2338
2339

006512 012737 000052 001226
006520 012737 006660 001216
006526 012737 006550 001220
006534 105037 012602
006540 112737 000377 014052
006546 005000
006550 104412
006552 010037 014056
006556 105737 012602
006562 001402
006564 004737 012444
006570 004537 011522
006574 000020
006576 000000
006600 013737 014116 001252
006606 013737 014056 001254
006614 005777 172546
006620 100001
006622 104000
006624 023737 001254 001252
006632 001401
006634 104020
006636 104401
006640 005200
006642 001342
006644 012700 177400
006650 105137 012602
006654 001335
006656 104400

```

:RECEIVER DATA REALIBILITY TEST.
:TEST TO RECEIVE A SIXTEEN
:BIT BINARY COUNT PATTERN (000000-177777)
:NOTE: IF PARFLG IS NON-ZERO THE PARITY TEST IS
:IN PROGRESS. THERE ARE NO ERRORS EXPECTED
:PARITY TEST DATA (177400-177777)
:
: TEST S2
:*****
TST52: MOV #52,TSTNO
MOV #TST53,NEXT
MOV #1$,LOCK
CLRB PARFLG ;SET FOR NO PARITY NOW
MOVB #377,EXTFLG ;TELL SUBROUTINE 16 BIT CHAR.
CLR RO ;ZERO DATA POINTER
MSTCLR ;ISSUE CLEAR DQ11
NOV RO,WORD ;LOAD DATA FOR SUB ROUTINE
TSTB PARFLG ;IS PARITY ENABLED?
BEQ .+6 ;BR IF NO
JSR PC,GENPAR ;GO AND FIGURE PARITY.
JSR RS,RXSTRA ;GO PUSH CHARACTER INTO RECEIVER.
16. ;NUMBER OF SHIFTS NEEDED
0000 ;BITS PER/CHAR FOR MISC REG
MOV RXBUFF,TEMP4 ;GET EXPECTED
MOV WORD,TEMP5 ;GET EXPECTED
25: TST DQERR ;ANY ERRORS?
BPL .+4 ;BR IF NO ERRORS
HLT ;DQ11 ERROR FLAG SET CHECK SEL 4
CMP TEMP5,TEMP4 ;DATA OK??
BEQ .+4 ;BR IF GOOD DATA
HLT 20 ;RECEIVER DATA COMPARISON ERROR.
SCOPI ;LOCK ON SLECTED DATA (SW09=1)
INC RO ;UPDATE DATA POINTER.
BNE 1$ ;BR IF MORE CHARS TO GO.
MOV #177400,RO ;SET FOR PARITY TEST.
COMB PARFLG ;TURN PARITY ON NOW
BNE 1$ ;DO TEST WITH PARITY ENABLED NOW.
SCOPE ;SCOPE THE TEST.

```

:RECEIVER PARITY ERROR TEST.
:THE PARITY WILL PURPOSELY BE MADE INCORRECT AND
:AN ERROR WILL BE EXPECTED EVERY TIME.

:TEST TO RECEIVE A SIXTEEN
:BIT BINARY COUNT PATTERN (000000-000177)

```

: TEST S3
:*****

```

2340	006660	012737	000053	001226	TST53:	MOV	#53,TSTNO	
2341	006666	012737	007032	001216		MOV	#TST54,NEXT	
2342	006674	012737	006720	001220		MOV	#15,LOCK	
2343	006702	112737	000377	012602		MOV#B	#377,PARFLG	: TELL SUBROUTINE PARITY IS ENABLED.
2344	006710	112737	000377	014052		MOV#B	#377,EXTFLG	: TELL SUBROUTINE THIS IS A 16 BIT CHAR.
2345	006716	005000				CLR	RO	: CLEAR DATA POINTER
2346	006720	104412			15:	MSTCLR		: INIT DQ11
2347	006722	012737	000377	011766		MOV	#377,NPRFLG	: SET FOR SUBROUTINE.
2348	006730	010037	014056			MOV	RO,WORD	: LOAD DATA
2349	006734	004737	012444			JSR	PC,GENPAR	: CALCULATE PARITY.
2350	006740	032737	100000	014056		BIT	#BIT15,WORD	: CHECK PARITY BIT
2351	006746	001404				BEQ	+.12	: BR IF PARITY BIT CLEARED
2352	006750	042737	100000	014056		BIC	#BIT15,WORD	: PARITY BIT SET ;; SO CLEAR IT.
2353	006756	000403				BR	+.10	: CONTINUE TEST
2354	006760	052737	100000	014056		BIS	#BIT15,WORD	: PARITY BIT CLR ;; SO SET IT.
2355	006766	004537	011522			JSR	RS,RXSTRA	: PUSH CHARACTER INTO RECEIVER
2356	006772	000020				16.		: SHIFTS NEEDED.
2357	006774	000000				0000		: BITS PER CHAR SELECT.
2358	006776	013737	014116	001252		MOV	RXBUFF,TEMP4	: GET ACTUAL..
2359	007004	013737	014056	001254		MOV	WORD,TEMPS	: GET EXPECTED..
2360	007012	005777	172350		25:	TST	#DQERR	: DID THE ERROR FLAG SET..**..
2361	007016	100401				BMI	+.4	: BR IF AN ERROR OCCURED.
2362	007020	104000				HLT		: ERROR NO ERROR (PARITY ERROR)
2363	007022	104401				SCOPI		: LOCK ON CHARACTER? (SM09=1)
2364	007024	105200				INCB	RO	: UPDATE DATA POINTER.
2365	007026	100334				BPL	15	: BR IF NOT 200(8) CHARS DONE.
2366	007030	104400				SCOPE		: SCOPE THIS TEST
2367								
2368								
2369								
2370								: TEST OF RECEIVER HALF DUPLEX
2371								: TEST TO TRANSMITT
2372								: A TWO HUNDRED CHARACTER BURST OF DATA CHARACTERS
2373								: WITH THE RECEIVER IN HALF DUPLEX
2374								: MAKING SURE THAT THE RECEIVER
2375								: DOESNT RECEIVE ANY CHARACTERS.
2376								
2377								
2378								
2379								
2380	007032	012737	000054	001226		TST54:	MOV	#54,TSTNO
2381	007040	012737	007434	001216			MOV	#TST55,NEXT
2382	007046	005000					CLR	RO
2383	007050	012704	014524				MOV	#TXBUFF,R4
2384	007054	110024			15:	MOV#B	RO,(R4)+	: INIT DATA REG
2385	007056	105200				INCB	RO	: PREPARE TO FILL TX BUFFER WITH BINARY COUNT.
2386	007060	100375				BPL	15	: START FILLING TX BUFF
2387	007062	104413				MEMCLR		: UPDATE DATA REG
2388	007064	005000			25:	CLR	RO	: BRANCH IF BUFFER HASN'T BEEN FILLED
2389	007066	012704	014116			MOV	#RXBUFF,R4	: INIT THE DEVICE
2390	007072	105024				CLRB	(R4)+	: CLEAR COUNT REG
2391	007074	105200			35:	INCB	RO	: PREPARE TO CLEAR THE RECEIVER BUFFER.
2392	007076	001375				BNE	35	: START CLEARING RX BUFF
2393	007100	105077	172264			CLRB	#DQREG	: UPDATE THE COUNTER
2394	007104	012777	014116	172260		MOV	#RXBUFF,#DQSEC	: IS RX BUFF ALL CLEARED?
2395	007112	105277	172252			INCB	#DQREG	: SELECT THE RECEIVER BA PRI
								: LOAD THE BA
								: SELECT THE RECEIVER CC PRI

2396	007116	012777	177600	172246	MOV	#-200,200SEC	:LOAD THE CC WITH -200 (I WANT TO RECEIVE 200 CHARACTERS
2397	007124	105277	172240		INCB	200REG	:SELECT THE TX BA PRI
2398	007130	012777	014522	172234	MOV	#SYNC,200SEC	:LOAD THE TX BA WITH STARTING ADD OF TX DATA PLUS THE SY
2399	007136	105277	172226		INCB	200REG	:SELECT THE TX CC PRI
2400	007142	012777	177576	172222	MOV	#-202,200SEC	:LOAD THE TX CC WITH -202 (FOUR HUNDRED CHARACTERS AND T
2401	007150	112777	000011	172212	MOVB	#11,200REG	:SELECT THE SYNC REGISTER
2402	007156	013777	014520	172206	MOV	.SYNC,200SEC	:LOAD IT WITH THE SYNC CHAR
2403	007164	105277	172200		INCB	200REG	:SELECT THE MISC REGISTER
2404	007170	012777	004010	172174	MOV	#4010,200SEC	:LOAD IT WITH EIGHT BITS PER/CHAR AND TEST LOOP
2405	007176	005037	001244		CLR	TEMP1	:ZERO DELAY LOC1
2406	007202	012737	000020	001246	MOV	#20,TEMP2	:SET DELAY FOR 20X177777 (8)
2407	007210	012777	000011	172142	MOV	#11,200RCSR	:SET RECEIVER HALF DUPLEX AND GO!!
2408	007216	005277	172142		INC	200TCSR	:SET TRANSMITTER GO!!!
2409	007222	105777	172136		4S: TSTB	200TCSR	:TRANSMITTER DONE??
2410	007226	100407			BMI	5S	:BRANCH IF TRANSMITTER IS DONE.
2411	007230	005237	001244		INC	TEMP1	:START THE DELAY
2412	007234	001372			BNE	4S	:DELAY-----
2413	007236	005337	001246		DEC	TEMP2	:DELAY-----TRANSMITTER DONE?
2414	007242	001367			BNE	4S	:DELAY-----
2415	007244	104000			HLT		:TRANSMITTER DONE NEVER SET (PRI)
2416	007246	005000			5S: CLR	RO	:INIT COUNT REG
2417	007250	012705	014116		MOV	#RXBUFF,R5	:SET REC DATA POINTER
2418	007254	105725			6S: TSTB	(R5)+	:START THE DATA CHECK
2419	007256	001401			BEQ	.+4	:DATA GOOD SO FAR
2420	007260	104000			HLT		:DATA COMPARISON ERROR
2421	007262	105200			INCB	RO	:UPDATE COUNTER
2422	007264	100373			BPL	6S	:BRANCH IF MORE DATA TO CHECK

:RECEIVER HALF DUPLEX TEST. PART 2
 :TEST THAT WHEN TX IS NOT ACTIVE THAT THE RECEIVER
 :CAN RECEIVE CHARS.

2423							
2424							
2425							
2426							
2427							
2428							
2429							
2430	007266	104412			MSTCLR		:INIT DQ11
2431	007270	005000			CLR	RO	:ZERO DATA POINTER
2432	007272	012704	014116		MOV	#RXBUFF,R4	:PREPARE TO ZERO RX BUFFER.
2433	007276	105024			7S: CLRB	(R4)+	:START CLEARING.
2434	007300	105200			INCB	RO	:DONE?
2435	007302	100375			BPL	7S	:BR IF MORE TO DO.
2436	007304	105077	172060		CLRB	200REG	:SEL RX BA PRI.
2437	007310	012777	014116	172054	MOV	#RXBUFF,200SEC	:LOAD IT
2438	007316	105277	172046		INCB	200REG	:SEL RX MC PRI.
2439	007322	012777	177600	172042	MOV	#-200,200SEC	:LOAD FOR 200 CHARS.
2440	007330	112777	000012	172032	MOVB	#MISC,200REG	:SLE MISC REGISTER.
2441	007336	012777	004010	172026	MOV	#4010,200SEC	:SET EIGHT BITS AND TEST LOOP
2442	007344	005037	001244		CLR	TEMP1	:SET DELAY
2443	007350	012737	000002	001246	MOV	#2,TEMP2	: " "
2444	007356	012777	010011	171774	MOV	#10011,200RCSR	:SET ACTIVE HALF DUPLEX,GO
2445	007364	105777	171770		8S: TSTB	200RCSR	:RX DONE PRI?
2446	007370	100407			BMI	9S	:BR IF YES
2447	007372	005237	001244		INC	TEMP1	:DELAY
2448	007376	001372			BNE	8S	: " "
2449	007400	005337	001246		DEC	TEMP2	: " "
2450	007404	001367			BNE	8S	: " "
2451	007410	005000			9S: HLT		:RX PRI. DONE NOT SET..
					CLR	RO	:INIT COUNTER

```

007412 012705 014116      MOV    #RXBUFF,R5      ;GET RX BUFFER.
007416 122725 000377      CMPB  #377,(R5)+      ;MARK STATE IN BUFFER?
007422 001401              BEQ   .+4             ;BR IF YES
007424 104000              HLT   .               ;ERROR
007426 105200              INCB  R0              ;ALL DONE?
007430 100372              BPL  10S             ;BR IF NO.
007432 104400              SCOPE                ;SCOPE THIS TEST.

```

```

:TEST OF D011 TRANSMITTER AND RECEIVER
:DATA REALIBILITY.
:DATA IS TRANSFERED FULL RATE
:AT A FOUR HUNDRED CHARACTER BURST

```

```

:TEST 55
:*****
007434 012737 000055 001226 10S:  MOV    #55,TSTNO
007442 012737 007754 001216      MOV    #TST56,NEXT
007450 005000              CLR   R0              ;INIT DATA REG
007452 012704 014524      MOV    #TXBUFF,R4      ;PREPARE TO FILL TX BUFFER WITH BINARY COUNT.
007456 110024              MOVB  R0,(R4)+         ;START FILLING TX BUFF
007460 105200              INCB  R0              ;UPDATE DATA REG
007462 001375              BNE  1S               ;BRANCH IF BUFFER HASN'T BEEN FILLED
007464 104413              MEMCLR
007466 005000              CLR   R0              ;INIT THE DEVICE
007470 012704 014116      MOV    #RXBUFF,R4      ;CLEAR COUNT REG
007474 105024              CLRB  (R4)+           ;PREPARE TO CLEAR THE RECEIVER BUFFER.
007476 105200              INCB  R0              ;START CLEARING RX BUFF
007500 001375              BNE  3S               ;UPDATE THE COUNTER
007502 105077 171662      CLRB  #00REG          ;IS RX BUFF ALL CLEARED?
007506 012777 014116 171656      MOV    #RXBUFF,#00SEC ;SELECT THE RECEIVER BA PRI
007514 105277 171650      INCB  #00REG          ;LOAD THE BA
007520 012777 177400 171644      MOV    #-400,#00SEC   ;SELECT THE RECEIVER CC PRI
007526 105277 171636      INCB  #00REG          ;LOAD THE CC WITH -400 (I WANT TO RECEIVE 400 CHARACTERS)
007532 012777 014522 171632      MOV    #SYNC,#00SEC   ;SELECT THE TX BA PRI
007540 105277 171624      INCB  #00REG          ;LOAD THE TX BA WITH STARTING ADD OF TX DATA PLUS THE SY
007544 012777 177376 171620      MOV    #-402,#00SEC   ;SELECT THE TX CC PRI
007552 112777 000011 171610      MOVB  #11,#00REG      ;LOAD THE TX CC WITH -402 (FOUR HUNDRED CHARACTERS AND T
007560 013777 014520 171604      MOV    .SYNC,#00SEC   ;SELECT THE SYNC REGISTER
007566 105277 171576      INCB  #00REG          ;LOAD IT WITH THE SYNC CHAR
007572 012777 004010 171572      MOV    #4010,#00SEC   ;SELECT THE MISC REGISTER
007600 005037 001244      CLR   TEMP1           ;LOAD IT WITH EIGHT BITS PER/CHAR AND TEST LOOP
007604 012737 000020 001246      MOV    #20,TEMP2      ;ZERO DELAY LOC1
007612 005277 171542      INC   #00ACSR         ;SET DELAY FOR 20X177777 (8)
007616 005277 171542      INC   #00TCSR         ;SET RECEIVER GO!!
007622 105777 171532      INC   #00QCSR         ;SET TRANSMITTER GO!!!
007626 100407              BMI  4S               ;RECEIVER DONE??
007630 005237 001244      INC   TEMP1           ;BRANCH IF RECEIVER IS DONE.
007634 001372              BNE  4S               ;START THE DELAY
007636 005337 001246      DEC   TEMP2           ;DELAY-----
007642 001367              BNE  4S               ;DELAY----- REC DONE?
007644 104000              HLT   .               ;DELAY-----
007646 005777 171514      TST   #00ERR          ;RECEIVER DONE NEVER SET (PRI)

```



```

008 007652 100001 BPL .+4
009 007654 104000 HLT
010 007656 122777 000204 171474 CMPB #204,20GRCSR
011 007664 001401 BEQ .+4
012 007666 104000 HLT
013 007670 122777 000204 171466 CMPB #204,20GTCSR
014 007676 001401 BEQ .+4
015 007700 104000 HLT
016 007702 005000 CLR RO ;INIT COUNT REG
017 007704 012704 014524 MOV #TXBUFF,R4 ;SET GOOD DATA POINTER
018 007710 012705 014116 MOV #RXBUFF,R5 ;SET REC DATA POINTER
019 007714 005037 001254 6S: CLR TEMPS
020 007720 005037 001252 CLR TEMP4
021 007724 112437 001254 MOVB (R4)+,TEMPS
022 007730 112537 001252 MOVB (R5)+,TEMP4
023 007734 023737 001254 001252 CMP TEMPS,TEMP4
024 007742 001401 BEQ .+4 ;DATA GOOD SO FAR
025 007744 104025 HLT 25 ;DATA COMPARISON ERROR
026 007746 105200 INCB RO ;UPDATE COUNTER
027 007750 001361 BNE 6S ;BRANCH IF MORE DATA TO CHECK
028 007752 104400 SCOPE

```

```

: TEST OF THE THREE STRAP SELECTABLE
: CHARACTERS
: ON THE FIRST PASS THE CHARACTERS
: WILL BE TYPED OUT FOR VERIFICATION
: ON PASSES AFTER THAT THE CHARACTERS WILL BE VERIFIED
: BY THE PROGRAM.

```

```

: NOTE: IF THE BB OPTION IS INSTALLED
: PROCEED TO NEXT TEST.

```

```

: TEST 56
: *****

```

```

007754 012737 000056 001226 TST56: MOV #56,TSTNO
007762 012737 015126 001216 MOV #EOP,NEXT
007770 012737 010134 001220 MOV #15,LOCK
007776 104413 MEMCLR ;CLEAR ALL
010000 005037 011766 CLR NPRFLG
010004 032737 020000 001510 BIT #8BIT,DQSTAT ;DOES BB OPTION EXIST?
010012 001405 BEQ .+14 ;BR IF BB NOT THERE.
010014 013737 001216 001214 MOV NEXT,RETURN ;DO NEXT TEST.
010022 000177 171166 JMP #RETURN
010026 012737 000010 010154 MOV #8,5S ;EIGHT SHIFTS.
010034 012737 004000 010156 MOV #400,6S ;EIGHT BITS PER CHAR.
010042 012737 000400 010272 MOV #400,15S ;LAST CHARACTER.
010050 005000 CLR RO ;ZERO DATA POINTER

```

```

: *****
: MAINTAINANCE AID.
: THE FOLLOWING IS TO HELP TROBLE SHOOT
: PROBLEMS IN THE CHARACTER DET. LOGIC
: FASTER.
: *****

```

008
009
010
011
012
013
014
015
016
017
018
019
020
021
022
023
024
025
026
027
028
029
030
031
032
033
034
035
036
037
038
039
040
041
042
043
044
045
046
047
048
049
050
051
052
053
054
055
056
057
058
059
060
061
062

2564										
2565	010052	000416			BR	36\$: CHANGE THIS LOCATION TO "240" (NOP)
2566										: TO LOCK ON SELECTED 8 BIT CHAR.
2567	010054	000000			HALT					: PUT SELECTED CHARACTER IN SWR.
2568										: HIT CONT.
2569	010056	104414			CKSWR					: CHECK FOR (<G>
2570	010060	017700	171114		MOV	2SWR, R0				: LOAD CHARACTER.
2571	010064	000000			HALT					: PUT DYNAMIC SWR SETTINGS IN SWR AND
2572										: HIT CONT.
2573	010066	104414			CKSWR					: CHECK FOR (<G>
2574	010070	000407			BR	36\$: CHANGE THIS LOCATION TO "240" (NOP)
2575										: ALONG WITH THE ABOVE FOR 16 BIT CHAR
2576										: NOTE: BOTH LOCATIONS ARE TO BE CHANGED
2577										: FOR A 16 BIT CHAR.
2578	010072	012737	000020	010154	MOV	#16., 5\$: SET FOR 16 SHIFTS.
2579	010100	005037	010156		CLR	6\$: SET "BITS/PER/CHAR"
2580	010104	005037	010272		CLR	15\$: SET LAST LIMIT.
2581										
2582										
2583										
2584										
2585										
2586	010110	012704	014066		36\$: MOV	#TMPBUF, R4				: STORAGE POINTER.
2587	010114	005024			CLR	(R4)+				: ZERO STORAGE
2588	010116	022704	014104		CMP	#TMPBUF+16, R4				: ALL CLEAR?
2589	010122	001374			BNE	-6				: BR IF NO.
2590	010124	005037	014114		CLR	NUMBER				: HOW MANY FOUND.
2591	010130	012704	014066		MOV	#TMPBUF, R4				: PREPARE POINTER
2592	010134	005137	011766		1\$: COM	NPRFLG				: TELL SUBROUTINE NOT TO FORCE RX NPR.
2593	010140	005077	171214		CLR	2DQRCR				: CLEAR RX CSR
2594	010144	010037	014056		MOV	R0, WORD				: LOAD CHARACTER
2595	010150	004537	011522		JSR	R5, RXSTRA				: PUSH CHARACTER INTO RECEIVER.
2596	010154	000010			5\$: 8.					: BEWARE THIS LOCATION WILL CHANGE.
2597	010156	004000			6\$: 4000					: BEWARE THIS LOCATION WILL CHANGE.
2598	010160	005777	171174		TST	2DQRCR				: WAS A CHARACTER DETECTED?
2599	010164	100037			BPL	2\$: BR IF NO CHAR FOUND.
2600	010166	042777	100000	171164	BIC	#BIT15, 2DQRCR				: CLEAR DETECED CHAR FLAG
2601	010174	005700			TST	R0				: WAS THE CHAR=0
2602	010176	001003			BNE	18\$: BR IF NO.
2603	010200	005737	014114		TST	NUMBER				: HOW MANY WERE FOUND?
2604	010204	001410			BEQ	19\$: BR IF NONE YET.
2605	010206	012702	014066		18\$: MOV	#TMPBUF, R2				: POINTER STORE.
2606	010212	020022			13\$: CMP	R0, (R2)+				: WAS THIS CHARACTER FOUND BEFORE?
2607	010214	001423			BEQ	2\$: BR IF YES
2608	010216	005722			TST	(R2)+				: POP POINTER
2609	010220	022702	014106		CMP	#TMPBUF+20, R2				: ALL CHARS CHECKED?
2610	010224	001372			BNE	13\$: BR IF NO.
2611	010226	010024			19\$: MOV	R0, (R4)+				: STORE CHARACTER
2612	010230	017714	171124		MOV	2DQRCR, (R4)				: GET ADDRESS FOUND IN.
2613	010234	042714	170377		BIC	#170377, (R4)				: CLEAR ALL GARBAGE.
2614	010240	000324			SWAB	(R4)+				: SWAP AROUND.
2615	010242	005237	014114		INC	NUMBER				: UPDATE COUNTER.
2616	010246	022737	000005	014114	CMP	#5, NUMBER				: TOO MANY CHARS FOUND??
2617	010254	001003			BNE	2\$: BR IF OK.
2618	010256	104000			HLT					: ERROR MORE THAN 4 CHARS. WERE DETECTED.
2619	010260	000177	170730		JMP	2RETURN				: RESTART TEST. DO NOT CONTINUE IN THIS TEST

NOTE SWR BIT 9 MUST BE SET TO LOCK ON THAT CHAR. SELECTED.

2620	010264	104401			25:	SCOP1			LOCK ON CHAR (SW09=1)
2621	010266	005200				INC	RO		UPDATE CHARACTER
2622	010270	020027				CMP	RO,(PC)+		ALL DONE?
2623	010272	000000			155:	0			LAST CHAR STORED HERE.
2624	010274	001317				BNE	15		BR IF NOT DONE
2625	010276	005737	014114			TST	NUMBER		ANY CHARS FOUND?
2626	010302	001024				BNE	305		BR IF NONE FOUND
2627	010304	022737	000020	010154	315:	CMP	#16.,55		IS TEST ALL DONE?
2628	010312	001434				BEQ	75		BR IF YES
2629	010314	012737	000020	010154		MOV	#16.,55		DO A 16 BIT CHAR NOW
2630	010322	005037	010156			CLR	65		SET FOR 16 BITS PER CHAR.
2631	010326	112777	000012	171034		MOVB	#MISC.,30QREG		SEL MISC REG
2632	010334	042777	177400	171030		BIC	#177400,30QSEC		CLEAR THE HIGH BYTE
2633	010342	005037	010272			CLR	155		SET LAST CHAR TO 0
2634	010346	005000				CLR	RO		ZERO DATA POINTER
2635	010350	000137	010134			JMP	15		GO AND DO IT AGAIN
2636	010354	022737	000001	014114	305:	CMP	#1,NUMBER		WAS 1 CHAR FOUND?
2637	010362	001010				BNE	75		BR IF NO.
2638	010364	022737	000010	014070		CMP	#10,TMPBUF+2		WAS "SYNC DET" ENABLED?
2639	010372	001004				BNE	75		BR IF NO.
2640	010374	005337	014114			DEC	NUMBER		ZERO NUMBER.
2641	010400	024444				CMP	-(R4),-(R4)		ADJUST POINTERS
2642	010402	000740				BR	315		KEEP GOING.
2643	010404	005737	014114		75:	TST	NUMBER		ANY FOUND?
2644	010410	001004				BNE	+.12		BR IF YES
2645	010412	104402	013116			TYPE	EM4		ALLERT OPERATOR NONE FOUND.
2646	010416	000137	010626			JMP	105		LEAVE
2647	010422	105737	014112			TSTB	XYZFLG		WAS THIS DONE BEFORE?
2648	010426	001050				BNE	35		BR IF TEST WAS DONE BEFORE
2649	010430	012704	014066			MOV	#TMPBUF,R4		POINTER
2650	010434	012437	010700			MOV	(R4)+,CHAR1		STORE CHARACTER 1
2651	010440	012437	010702			MOV	(R4)+,ADDR1		STORE ADDRESS 1
2652	010444	012437	010704			MOV	(R4)+,CHAR2		STORE CHARACTER 2
2653	010450	012437	010706			MOV	(R4)+,ADDR2		STORE ADDRESS 2
2654	010454	012437	010710			MOV	(R4)+,CHAR3		STORE CHARACTER 3
2655	010460	012437	010712			MOV	(R4)+,ADDR3		STORE ADDRESS 3
2656	010464	012437	010714			MOV	(R4)+,CHAR4		STORE CHARACTER 4
2657	010470	012437	010716			MOV	(R4)+,ADDR4		STORE ADDRESS 4
2658	010474	013737	014114	001252		MOV	NUMBER,TEMP4		STORE NUMBER OF CHARACTER FOUND.
2659	010502	104402				TYPE			
2660	010504	013724				MDETCH			
2661	010506	104410				CONVRT			
2662	010510	010630				XCHAR1			
2663	010512	005337	001252			DEC	TEMP4		
2664	010516	001414				BEQ	35		
2665	010520	104410				CONVRT			
2666	010522	010642				XCHAR2			
2667	010524	005337	001252			DEC	TEMP4		
2668	010530	001407				BEQ	35		
2669	010532	104410				CONVRT			
2670	010534	010654				XCHAR3			
2671	010536	005337	001252			DEC	TEMP4		
2672	010542	001402				BEQ	35		
2673	010544	104410				CONVRT			
2674	010546	010666				XCHAR4			
2675	010550	022737	000001	001504	35:	CMP	#1,DQNUM		

2676	010556	001003			BNE	.+10
2677	010560	012737	177777	014112	MOV	8-1,XYZFLG
2678	010566	013737	014114	001252	MOV	NUMBER,TEMP4
2679	010574	012704	014066		MOV	8TMPBUF,R4
2680	010600	012705	010700		MOV	8.CHAR1,R5
2681	010604	022425			45: CMP	(R4)+,(R5)+
2682	010606	001401			BEQ	.+4
2683	010610	104022			HLT	22
2684	010612	022425			CMP	(R4)+,(R5)+
2685	010614	001401			BEQ	.+4
2686	010616	104022			HLT	22
2687	010620	005337	001252		DEC	TEMP4
2688	010624	001367			BNE	45
2689	010626	104400			105: SCOPE	
2690	010630	000002			XCHAR1: 2	
2691	010632	006	002		.BYTE	6,2
2692	010634	010700			.CHAR1	
2693	010636	004	002		.BYTE	4,2
2694	010640	010702			.ADDR1	
2695	010642	000002			XCHAR2: 2	
2696	010644	006	002		.BYTE	6,2
2697	010646	010704			.CHAR2	
2698	010650	004	002		.BYTE	4,2
2699	010652	010706			.ADDR2	
2700	010654	000002			XCHAR3: 2	
2701	010656	006	002		.BYTE	6,2
2702	010660	010710			.CHAR3	
2703	010662	004	002		.BYTE	4,2
2704	010664	010712			.ADDR3	
2705	010666	000002			XCHAR4: 2	
2706	010670	006	002		.BYTE	6,2
2707	010672	010714			.CHAR4	
2708	010674	004	002		.BYTE	4,2
2709	010676	010716			.ADDR4	
2710	010700	000000			.CHAR1: 0	
2711	010702	000000			.ADDR1: 0	
2712	010704	000000			.CHAR2: 0	
2713	010706	000000			.ADDR2: 0	
2714	010710	000000			.CHAR3: 0	
2715	010712	000000			.ADDR3: 0	
2716	010714	000000			.CHAR4: 0	
2717	010716	000000			.ADDR4: 0	


```

2718
2719
2720
2721
2722
2723
2724
2725
2726
2727 010720 104412 TXSTRB: MSTCLR
2728 010722 005037 014056 CLR WORD
2729 010726 010537 014054 MOV R5,SAVEPC
2730 010732 012537 014062 MOV (R5)+,COUNT
2731 010736 012537 014064 MOV (R5)+,BITSEL
2732 010742 112777 000002 170420 MOVB #2,ADQREG
2733 010750 012777 014056 170414 MOV #WORD,ADQSEC
2734 010756 105277 170406 INCB ADQREG
2735 010762 012777 177777 170402 MOV #-1,ADQSEC
2736 010770 112777 000012 170372 MOVB #MISC.,ADQREG
2737 010776 013777 014064 170366 MOV BITSEL,ADQSEC
2738 011004 052777 000012 170360 BIS #12,ADQSEC
2739 011012 005277 170346 INC ADQTCR
2740 011016 027777 170342 170340 CMP ADQTCR,ADQTCR ;WAIST TIME
2741 011024 027777 170334 170332 CMP ADQTCR,ADQTCR ;WAIST TIME
2742 011032 027777 170326 170324 CMP ADQTCR,ADQTCR ;WAIST TIME
2743 011040 005277 170326 INC ADQSEC
2744 011044 005377 170322 DEC ADQSEC
2745 011050 005277 170316 IS: INC ADQSEC
2746 011054 005377 170312 DEC ADQSEC
2747 011060 032777 000200 170304 BIT #BIT7,ADQSEC
2748 011066 001001 BNE .+4
2749 011070 104023 HLT 23
2750 011072 005337 014062 DEC COUNT
2751 011076 001364 BNE IS
2752 011100 005277 170266 INC ADQSEC
2753 011104 005377 170262 DEC ADQSEC
2754 011110 032777 000200 170254 BIT #BIT7,ADQSEC
2755 011116 001401 BEQ .+4
2756 011120 104007 HLT 7
2757 011122 000205 RTS R5
2758
2759
2760
2761
2762
2763 011124 010537 014054 TXSTRC: MOV R5,SAVEPC
2764 011130 012537 014062 MOV (R5)+,COUNT
2765 011134 012537 014064 MOV (R5)+,BITSEL
2766 011140 112777 000002 170222 MOVB #2,ADQREG
2767 011146 012777 014056 170216 MOV #WORD,ADQSEC
2768 011154 105277 170210 INCB ADQREG
2769 011160 012777 177777 170204 MOV #-1,ADQSEC
2770 011166 112777 000012 170174 MOVB #MISC.,ADQREG
2771 011174 013777 014064 170170 MOV BITSEL,ADQSEC
2772 011202 052777 000012 170162 BIS #12,ADQSEC
2773 011210 005277 170150 INC ADQTCR
    
```

2774	011214	027777	170144	170142		CMP	300TCSR,300TCSR	:WAIST TIME
2775	011222	027777	170136	170134		CMP	300TCSR,300TCSR	:WAIST TIME
2776	011230	027777	170130	170126		CMP	300TCSR,300TCSR	:WAIST TIME
2777	011236	005277	170130			INC	300SEC	
2778	011242	005377	170124			DEC	300SEC	
2779	011246	005277	170120		15:	INC	300SEC	
2780	011252	005377	170114			DEC	300SEC	
2781	011256	005337	014062			DEC	COUNT	
2782	011262	001371				BNE	15	
2783	011264	000205				RTS	R5	
2784								
2785								
2786								
2787								
2788								
2789	011266	010537	014054			TXSTRD: MOV	R5,SAVEPC	:SAVE PC OF ROUTINE CALL
2790	011272	012537	014062			MOV	(R5)+,COUNT	:PICK UP THE NUMBER OF SHIFTS
2791	011276	012537	014064			MOV	(R5)+,BITSEL	:PICK UP NUMBER OF BITS PER CHARACTER
2792	011302	112777	000002	170060		MOV	#2,300REG	:SELECT THE TRANSMITTER BA PRI.
2793	011310	012777	014056	170054		MOV	#WORD,300SEC	:LOAD THE BA
2794	011316	105277	170046			INCB	300REG	:SELECT THE TRANSMITTER CC PRI.
2795	011322	012777	177777	170042		MOV	#-1,300SEC	:LOAD THE CC WITH -1
2796	011330	112777	000012	170032		MOV	#MISC.,300REG	:SELECT THE MISC REGISTER.
2797	011336	013777	014064	170026		MOV	BITSEL,300SEC	:LOAD MISC REG WITH NUMBER OF BITS PER CHAR.
2798	011344	052777	000012	170020		BIS	#12,300SEC	:ADD TO THAT TEST LOOP AND AUTO STEP.
2799	011352	105737	012602			TSTB	PARFLG	:IS PARITY TO BE TURNED ON?
2800	011356	001403				BEQ	.+10	:BR IF NO
2801	011360	052777	100000	170004		BIS	#BIT15,300SEC	:TURN PARITY ON.....
2802	011366	005277	167772			INC	300TCSR	:SET TRANSMITTER GO!!!!
2803	011372	027777	167766	167764		CMP	300TCSR,300TCSR	:WAIST TIME
2804	011400	027777	167760	167756		CMP	300TCSR,300TCSR	:WAIST TIME
2805	011406	027777	167752	167750		CMP	300TCSR,300TCSR	:WAIST TIME
2806	011414	005277	167752			INC	300SEC	:PRIME THE
2807	011420	005377	167746			DEC	300SEC	:TRANSMITTER.
2808	011424	006037	001252		15:	ROR	TEMP4	:SHIFT THE STORAGE OF DATA FROM THE TRANSMITTER.
2809	011430	005277	167736			INC	300SEC	:CLOCK THE TRANSMITTER -UP-
2810	011434	005377	167732			DEC	300SEC	:CLOCK THE TRANSMITTER -DOWN-
2811	011440	017702	167726			MOV	300SEC,R2	:MOVE THE MISC REG TO R2
2812	011444	042702	177577			BIC	#177577,R2	:CLEAR ALL BUT THE BIT WINDOW.
2813	011450	105737	014052			TSTB	EXTFLG	:FIND OUT IF BIT PER CHAR >8
2814	011454	001404				BEQ	25	:BRANCH IF BOR<8
2815	011456	106102				ROLB	R2	:SHIFT BIT WINDOW INTO CARRY BIT.
2816	011460	006002				ROR	R2	:SHIFT CARRY INTO R2 (BIT 15 OF R2)
2817	011462	042702	077777			BIC	#77777,R2	:CLEAR ALL BUT THAT BIT OF DATA
2818	011466	050237	001252		25:	BIS	R2,TEMP4	:PLACE DATA INTO TEMPORARY LOCATION
2819	011472	005337	014062			DEC	COUNT	:IS CHARACTER COMPLETELY SHIFTED OUT?
2820	011476	001352				BNE	15	:BRANCH IF MORE BITS TO GO.
2821	011500	105737	014052			TSTB	EXTFLG	
2822	011504	001003				BNE	35	
2823	011506	105137	001252			COMB	TEMP4	
2824	011512	000402				BR	45	
2825	011514	005137	001252		35:	COM	TEMP4	:COMPLIMENT DATA STORAGE
2826	011520	000205			45:	RTS	R5	:LEAVE THE ROUTINE.
2827								
2828								
2829								

2830									
2831	011522	010537	014054			RXSTRA:	MOV	RS	SAVEPC
2832	011526	012537	014062				MOV	(RS)+	COUNT
2833	011532	012537	014064				MOV	(RS)+	BITSEL
2834	011536	013737	014056	017770			MOV	WORD,	TEMP
2835	011544	005137	017770				COM	TEMP	
2836	011550	105077	167614				CLRB	20QREG	
2837	011554	012777	014116	167610			MOV	8RXBUFF,	20QSEC
2838	011562	105277	167602				INCB	20QREG	
2839	011566	012777	000200	167576			MOV	8200,	20QSEC
2840	011574	112777	000011	167566			MOVB	811,	20QREG
2841	011602	012777	177777	167562			MOV	8-1,	20QSEC
2842	011610	105277	167554				INCB	20QREG	
2843	011614	053777	014064	167550			BIS	BITSEL,	20QSEC
2844	011622	052777	000012	167542			BIS	812,	20QSEC
2845	011630	105737	012602				TSTB	PARFLG	
2846	011634	001403					BEQ	+.10	
2847	011636	052777	100000	167526			BIS	8BIT15,	20QSEC
2848	011644	052777	000001	167506			BIS	80001,	20QRCSR
2849	011652	005737	011766				TST	NPRFLG	
2850	011656	001403					BEQ	+.10	
2851	011660	052777	010000	167472			BIS	8BIT12,	20QRCSR
2852	011666	112777	000012	167474			MOVB	8MISC,	20QREG
2853	011674	042777	000200	167470	25:		BIC	8BIT7,	20QSEC
2854	011702	006037	017770				ROR	TEMP	
2855	011706	106037	001244				RORB	TEMP1	
2856	011712	042737	177577	001244			BIC	8177577,	TEMP1
2857	011720	053777	001244	167444			BIS	TEMP1,	20QSEC
2858	011726	005277	167440				INC	20QSEC	
2859	011732	005377	167434				DEC	20QSEC	
2860	011736	005337	014062				DEC	COUNT	
2861	011742	001354					BNE	25	
2862	011744	005737	011766				TST	NPRFLG	
2863	011750	001003					BNE	+.10	
2864	011752	052777	000020	167412			BIS	8BIT4,	20QSEC
2865	011760	005037	011766				CLR	NPRFLG	
2866	011764	000205					RTS	RS	
2867	011766	000000							
2868	011770					NPRFLG:	0		
2869	011770	005077	167364			.MEMCLR:	CLR	20QRCSR	
2870	011774	005077	167364				CLR	20QTCSR	
2871	012000	005077	167362				CLR	20QERR	
2872	012004	012705	000020				MOV	816,	RS
2873	012010	152777	000020	167352	15:		BISB	8BIT4,	20QREG
2874	012016	142777	000140	167344			BICB	8140,	20QREG
2875	012024	005077	167342				CLR	20QSEC	
2876	012030	105277	167334				INCB	20QREG	
2877	012034	005305					DEC	RS	
2878	012036	001364					BNE	15	
2879	012040	105077	167324				CLRB	20QREG	
2880	012044	105077	167312				CLRB	20QRCSR	
2881	012050	012705	000020				MOV	816,	RS
2882	012054	112777	000010	167306	25:		MOVB	810,	20QREG
2883	012062	005077	167304				CLR	20QSEC	
2884	012066	112777	000014	167274			MOVB	814,	20QREG
2885	012074	005077	167272				CLR	20QSEC	

: IS PARITY TO BE TURNED ON?
: BR IF NO
: TURN PARITY ON.....

F05

DZDGD MACY11 27(1006) 22-DEC-76 11:14 PAGE 57
 DZDGD.P11 21-DEC-76 16:32 DQ11 TRANSMITTER AND RECEIVER EXERCISER.

2886	012100	105277	167256		INCB	200RCSH	
2887	012104	005305			DEC	R5	
2888	012106	001362			BNE	2\$	
2889	012110	105077	167246		CLRB	200RCSH	
2890	012114						
2891	012114	112777	000012	167246	.MSTCLR:	MOV#	#MISC, 200REG
2892	012122	012777	000040	167242		MOV	#BITS, 200SEC
2893	012130	000002				RTI	
2894	012132	010537	014054		RXLNG:	MOV	R5, SAVEPC
2895	012136	104412				MSTCLR	
2896	012140	105077	167224			CLRB	200REG
2897	012144	012777	014116	167220		MOV	#RXBUFF, 200SEC
2898	012152	005037	014116			CLR	RXBUFF
2899	012156	105277	167206			INCB	200REG
2900	012162	012777	000200	167202		MOV	#200, 200SEC
2901	012170	112777	000011	167172		MOV#	#11, 200REG
2902	012176	013777	014520	167166		MOV	.SYNC 200SEC
2903	012204	105277	167160			INCB	200REG
2904	012210	012577	167156			MOV	(R5)+, 200SEC
2905	012214	052777	000012	167150		BIS	#12, 200SEC
2906	012222	052777	000001	167130		BIS	#0001, 200RCSR
2907	012230	042777	000200	167134		BIC	#BIT7, 200SEC
2908	012236	005277	167130			INC	200SEC
2909	012242	005377	167124			DEC	200SEC
2910	012246	052777	000020	167116		BIS	#BIT4, 200SEC
2911	012254	000240				NOP	
2912	012256	000240				NOP	
2913	012260	000240				NOP	
2914	012262	000337	014116			SWAB	RXBUFF
2915	012266	122537	014116		IS:	CMPB	(R5)+, RXBUFF
2916	012272	001401				BEQ	.+4
2917	012274	104015				HLT	15
2918	012276	005205				INC	R5
2919	012300	000205				RTS	R5
2920	012302	010537	014054		RXLNG:	MOV	R5, SAVEPC
2921	012306	104412				MSTCLR	
2922	012310	105077	167054			CLRB	200REG
2923	012314	012777	014116	167050		MOV	#RXBUFF, 200SEC
2924	012322	005037	014116			CLR	RXBUFF
2925	012326	105277	167036			INCB	200REG
2926	012332	012777	000200	167032		MOV	#200, 200SEC
2927	012340	112777	000011	167022		MOV#	#11, 200REG
2928	012346	013777	014520	167016		MOV	.SYNC 200SEC
2929	012354	105277	167010			INCB	200REG
2930	012360	012577	167006			MOV	(R5)+, 200SEC
2931	012364	052777	000012	167000		BIS	#12, 200SEC
2932	012372	052777	000001	166760		BIS	#0001, 200RCSR
2933	012400	042777	000200	166764		BIC	#BIT7, 200SEC
2934	012406	005277	166760			INC	200SEC
2935	012412	005377	166754			DEC	200SEC
2936	012416	052777	000020	166746		BIS	#BIT4, 200SEC
2937	012424	000240				NOP	
2938	012426	000240				NOP	
2939	012430	000240				NOP	
2940	012432	022537	014116			CMP	(R5)+, RXBUFF
2941	012436	001401				BEQ	.+4

G05

DZD00 MACY11 27(1006) 22-DEC-76 11:14 PAGE 58
DZD000.P11 21-DEC-76 16:32 DQ11 TRANSMITTER AND RECEIVER EXERCISER.

2942	012440	104015				HLT	15
2943	012442	000205				RTS	R5
2944	012444				GENPAR:		
2945	012444	010146			MOV	R1,-(SP)	
2946	012446	010246			MOV	R2,-(SP)	
2947	012450	010346			MOV	R3,-(SP)	
2948	012452	105737	014052		TSTB	EXTFLG	
2949	012456	001003			BNE	.+10	
2950	012460	042737	000200	014056	BIC	#BIT7,WORD	
2951	012466	042737	100000	014056	BIC	#BIT15,WORD	
2952	012474	005002			CLR	R2	
2953	012476	012703	000020		MOV	#16.,R3	
2954	012502	013701	014056		MOV	WORD,R1	
2955	012506	000241			CLC		
2956	012510	006001			1\$:	ROR	R1
2957	012512	005502				ADC	R2
2958	012514	005303				DEC	R3
2959	012516	001374				BNE	1\$
2960							
2961	012520	032737	001000	001510		BIT	#00DBIT,DQSTAT
2962	012526	001404				BEQ	2\$
2963	012530	032702	000001			BIT	#BIT0,R2
2964	012534	001016				BNE	4\$
2965	012536	000403				BR	3\$
2966	012540	032702	000001		2\$:	BIT	#BIT0,R2
2967	012544	001412				BEQ	4\$
2968	012546	105737	014052		3\$:	TSTB	EXTFLG
2969	012552	001004				BNE	.+12
2970	012554	052737	000200	014056		BIS	#BIT7,WORD
2971	012562	000403				BR	4\$
2972	012564	052737	100000	014056		BIS	#BIT15,WORD
2973	012572	012603			4\$:	MOV	(SP)+,R3
2974	012574	012602				MOV	(SP)+,R2
2975	012576	012601				MOV	(SP)+,R1
2976	012600	000207				RTS	PC
2977	012602	000000			PARFLG:	0	

H05

DZD00 MACY11 27(1006) 22-DEC-76 11:14 PAGE 59
DZD000.P11 21-DEC-76 16:32 DQ11 TRANSMITTER AND RECEIVER EXERCISER.

```
.ERRTAB:
2978 012604 000000 0
2979 012604 000000 0 ;HALT 0
2980 012606 000000 0
2981 012610 000000 0
2982 012612 013010 EMO
2983 012614 013326 DH1 ;HALT 1
2984 012616 000000 0
2985 012620 013010 EMO
2986 012622 013347 DH2 ;HALT 2
2987 012624 000000 0
2988 012626 013026 EM1
2989 012630 013364 DH3 ;HALT 3
2990 012632 000000 0
2991 012634 013026 EM1
2992 012636 013375 DH4 ;HALT 4
2993 012640 000000 0
2994 012642 013026 EM1
2995 012644 013431 DHS ;HALT 5
2996 012646 000000 0
2997 012650 013010 EMO
2998 012652 013465 DH6 ;HALT 6
2999 012654 000000 0
3000 012656 013010 EMO
3001 012660 013505 DH7 ;HALT 7
3002 012662 000000 0
3003 012664 013173 EM6
3004 012666 013540 DH9 ;HALT 10
3005 012670 000000 0
3006 012672 000000 0
3007 012674 013534 DHS ;HALT 11
3008 012676 000000 0
3009 012700 013010 EMO
3010 012702 013546 DH10 ;HALT 12
3011 012704 014040 DTO
3012 012706 013064 EM3
3013 012710 013540 DH9 ;HALT 13
3014 012712 000000 0
3015 012714 013064 EM3
3016 012716 013534 DHS ;HALT 14
3017 012720 000000 0
3018 012722 013173 EM6
3019 012724 013675 DH13 ;HALT 15
3020 012726 000000 0
3021 012730 013150 EMS
3022 012732 013534 DHS ;HALT 16
3023 012734 000000 0
3024 012736 013150 EMS
3025 012740 013540 DH9 ;HALT 17
3026 012742 000000 0
3027 012744 013173 EM6
3028 012746 013546 DH10 ;HALT 20
3029 012750 014040 DTO
3030 012752 013116 EM4
3031 012754 000000 0 ;HALT 21
3032 012756 000000 0
3033 012760 013206 EM7
```


3034	012762	000000			0	;HALT 22
3035	012764	000000			0	
3036	012766	013254			EMB	
3037	012770	000000			0	;HALT 23
3038	012772	000000			0	
3039	012774	013010			EMO	
3040	012776	013306			DHO	;HALT 24
3041	013000	000000			0	
3042	013002	000000			0	
3043	013004	013546			DH10	;HALT 25
3044	013006	014040			DTO	
3045	013010	052377	040522	051516	EMO:	.ASCIZ <377>/TRANSMITTER /
	013026	052377	040522	051516	EM1:	.ASCIZ <377>/TRANSMITTER CHARACTER COUNT /
	013064	053377	041522	042440	EM3:	.ASCIZ <377>/VRC ERROR BIT SHOULD BE /
	013116	047377	020117	044103	EM4:	.ASCIZ <377>/NO CHARACTERS DETECTED./<0>
	013150	051777	047131	020103	EM5:	.ASCIZ <377>/SYNC 1 AND 2 NOT /
	013173	377	042522	042503	EM6:	.ASCIZ <377>/RECEIVER /
	013206	041777	040510	040522	EM7:	.ASCIZ <377>/CHARACTER DETECTION COMPARISON ERROR/
	013254	041777	040510	040522	EM8:	.ASCIZ <377>/CHARACTER NOT ALL ZERO'S/
	013306	041501	044524	042526	DHO:	.ASCIZ /ACTIVE NOT SET./
	013326	041501	044524	042526	DH1:	.ASCIZ /ACTIVE NOT CLEAR/
	013347	104	047117	020105	DH2:	.ASCIZ /DONE NOT SET/
	013364	047516	020124	042532	DH3:	.ASCIZ /NOT ZERO/
	013375	116	052117	044440	DH4:	.ASCIZ /NOT INCREMENTED BY PLUS TWO/
	013431	116	052117	044440	DH5:	.ASCIZ /NOT INCREMENTED BY PLUS ONE/
	013465	120	044522	051452	DH6:	.ASCIZ /PRI#SEC NOT SET/
	013505	114	047111	020105	DH7:	.ASCIZ /LINE NOT AT MARK STATE/
	013534	042523	000124		DH8:	.ASCIZ /SET/
	013540	046103	040505	000122	DH9:	.ASCIZ /CLEAR/
	013546	040504	040524	041440	DH10:	.ASCII /DATA COMPARISON ERROR/
	013573	377	054105	042520		.ASCIZ <377>/EXPECTED RECEIVED /
	013621	123	052105	053440	DH11:	.ASCIZ /SET WHEN ACTIVE SET/
	013645	103	042514	051101	DH12:	.ASCIZ /CLEARED BY MASTER CLEAR/
	013675	103	040510	040522	DH13:	.ASCIZ /CHARACTER LENGTH ERROR/
	013724	051777	042505	040440	MDETCH:	.ASCII <377>/SEE ABSTRACT OR TEST #56 FOR DETAILS/
	013771	377	044103	051101		.ASCII <377>/CHARACTERS DETECTED: /
	014020	041777	040510	027122		.ASCIZ <377>/CHAR. ADDR. /
	014040	000002			.EVEN	
3046	014042	006	004		OTO:	2
3047	014044	001254			.BYTE	6,4
3048	014046	006	002			TEMP5
3049	014050	001252			.BYTE	6,2
3050	014052	000000				TEMP4
3051	014054	000000			EXTFLG:	0
3052	014056	000000			SAVEPC:	0
3053	014060	000000			WORD:	0
3054	014062	000000			DELAY:	0
3055	014064	000000			COUNT:	0
3056	014066	000012			BITSEL:	0
3057	014112	000000			TMPBUF:	.BLKW 12
3058	014114	000000			XYZFLG:	0
3059	014116	000000			NUMBER:	0
3060		014520			RXBUF:	0
3061	014520	026	026		.SYNC:	.+400
3062	014522	026	026		SYNC:	.BYTE 26,26

```

3063 014524 000000 TXBUFF: 0
3064 015126 015126 .=.+400
3065
3066 :END OF PASS
3067 :TYPE NAME OF TEST
3068 :UPDATE PASS COUNT
3069 :CHECK FOR EXIT TO ACT-11
3070 :RESTART TEST
3071
3072 015126 005037 001234 .EOP: CLR LSTERR ;CLEAR LAST ERROR PC
3073 015132 005037 001312 CLR ERRFLG ;CLEAR ERROR FLAG
3074 015136 005237 001230 INC PASCNT ;UPDATE PASS COUNT
3075 015142 104402 TYPE
3076 015144 017356 MEPASS
3077 015146 104402 TYPE
3078 015150 017536 MCSRX
3079 015152 104411 CNVRT
3080 015154 015264 XCSR
3081 015156 104402 TYPE
3082 015160 017544 MVECX
3083 015162 104411 CNVRT
3084 015164 015272 XVEC
3085 015166 104402 TYPE
3086 015170 017552 MPASSX
3087 015172 104411 CNVRT
3088 015174 015300 XPASS
3089 015176 104402 TYPE
3090 015200 017563 MERRX
3091 015202 104411 CNVRT
3092 015204 015306 XERR
3093 015206 013777 001230 163766 MOV PASCNT,ALIGHTS ;DISPLAY PASS COUNT
3094 015214 005337 001276 DEC SAVNUM
3095 015220 001013 BNE RESTRT
3096 015222 013737 001504 001276 MOV DQNUM,SAVNUM
3097 015230 013701 000042 MOV #42,R1 ;CHECK FOR ACT-11 OR DOP
3098 015234 001405 BEQ RESTRT ;IF NOT, CONTINUE TESTING
3099 015236 000005 RESET
3100 015240 LOGICAL:
3101 015240 004711 JSR PC,(R1)
3102 015242 000240 NOP
3103 015244 000240 NOP
3104 015246 000240 NOP
3105 015250 104414 RESTRT: CKSMR
3106 015252 012737 002254 001214 MOV #TST1,RETURN
3107 015260 000137 002254 JMP TST1
3108 015264 000001 XCSR: 1
3109 015266 006 002 .BYTE 6,2
3110 015270 001360 DQRCSR
3111 015272 000001 XVEC: 1
3112 015274 003 002 .BYTE 3,2
3113 015276 001350 XPASS: 1
3114 015300 000001 DQARVEC
3115 015302 006 002 .BYTE 6,2
3116 015304 001230 XERR: 1
3117 015306 000001 PASCNT
3118 015310 006 002 .BYTE 6,2
    
```



```

3119 015312 001232          ERRCNT
3120
3121          ;SCOPE LOOP AND INTERATION HANDLER
3122
3123 015314 104414          .SCOPE: CKSWR
3124 015316 032777 040000 163654  BIT      #BIT14,@SWR
3125 015324 001407          TTST:  BEQ      1$
3126 015326 000432          BR      3$
3127 015330 105777 163650  TSTB    @TKCSR
3128 015334 100027          BPL     3$
3129 015336 017700 163644  MOV     @TKDBR,R0
3130 015342 000412          BR      2$
3131 015344 032777 004000 163626  1$:   BIT      #SW11,@SWR
3132 015352 001006          BNE     2$
3133 015354 005237 001224  INC     LPCNT
3134 015360 023737 001224 001222  CMP     LPCNT,ICOUNT
3135 015366 001012          BNE     3$
3136 015370 105037 001312  2$:   CLRB   ERRFLG
3137 015374 005037 001224  CLR     LPCNT
3138 015400 012737 000010 001222  MOV     #10,ICOUNT
3139 015406 013737 001216 001214  MOV     NEXT,RETURN
3140 015414 013716 001214  3$:   MOV     RETURN,(SP)
3141 015420 000002          RTI
3142 015422 001407          BRW:   1407
3143 015424 000432          BRX:   432
3144
3145          ;CHECK FOR FREEZE ON CURRENT DATA
3146
3147 015426 104414          .SCOPE1: CKSWR
3148 015430 032777 001000 163542  BIT      #SW09,@SWR
3149 015436 001402          BEQ     1$
3150 015440 013716 001220  MOV     LOCK,(SP)
3151 015444 000002          1$:   RTI
3152
3153          ;TELETYPE OUTPUT ROUTINE
3154
3155 015446 010546          .TYPE:  MOV     R5, -(SP)
3156 015450 017605 000002  MOV     @2(SP),R5
3157 015454 062766 000002 000002  ADD     #2,@(SP)
3158 015462 005737 017136  1$:   TST    @RDSW
3159 015466 001004          BNE     300$
3160 015470 032777 010000 163502  BIT     #SW12,@SWR
3161 015476 001024          BNE     3$
3162 015500 105715          300$: TSTB   (R5)
3163 015502 100014          BPL     2$
3164 015504 105777 163500  TSTB   @TPCSR
3165 015510 100375          BPL     -4
3166 015512 012777 000015 163472  MOV     #15,@TPDBR
3167 015520 105777 163464  TSTB   @TPCSR
3168 015524 100375          BPL     -4
3169 015526 012777 000012 163456  MOV     #12,@TPDBR
3170 015534 105777 163450  2$:   TSTB   @TPCSR
3171 015540 100375          BPL     2$
3172 015542 112577 163444  MOVB   (R5)+,@TPDBR
3173 015546 001345          BNE     1$
3174 015550 012605          3$:   MOV     (SP)+,R5
    
```

```

3175 015552 000002 RTI
3176
3177 ;ASCII STRING INPUT ROUTINE
3178
3179 015554 010346 .INSTR: MOV R3,-(SP)
3180 015556 010446 MOV R4,-(SP)
3181 015560 017637 000004 015576 MOV 24(SP),MSG
3182 015566 062766 000002 000004 ADD #2,4(SP)
3183 015574 104402 .INST1: TYPE
3184 015576 000000 .MSG: 0
3185 015600 012704 017726 MOV #INBUF,R4
3186 015604 012703 000007 MOV #7,R3
3187 015610 105777 163370 1$: TST @TKCSR
3188 015614 100375 BPL 1$
3189 015616 117714 163364 MOVB @TKDBR,(R4)
3190 015622 142714 000200 BICB #200,(R4)
3191 015626 121427 000025 CMPB (R4),#25 ;IS IT <IG>
3192 015632 001003 BNE 200$
3193 015634 104402 017316 TYPE,MCRLF
3194 015640 000755 BR .INST1
3195 015642 122427 000015 200$: CMPB (R4)+,#15
3196 015646 001423 BEQ INSTR2
3197 015650 117777 163332 163334 MOVB @TKDBR,@TPDBR
3198 015656 105777 163326 2$: TST @TPCSR
3199 015662 100375 BPL 2$
3200 015664 005303 DEC R3
3201 015666 001350 BNE 1$
3202 015670 000402 BR .INSTG
3203 015672 010346 .INSTE: MOV R3,-(SP)
3204 015674 010446 MOV R4,-(SP)
3205 015676 104402 .INSTG: TYPE
3206 015700 017312 MQM
3207 015702 005737 017136 TST @RDSW
3208 015706 001402 BEQ 400$
3209 015710 104402 017316 TYPE,MCRLF
3210 015714 000727 400$: BR .INST1
3211 015716 012604 INSTR2: MOV (SP)+,R4
3212 015720 012603 MOV (SP)+,R3
3213 015722 000002 RTI
3214
3215 ;CONVERT ASCII STRING TO OCTAL
3216
3217 015724 010546 .PARAM: MOV R5,-(SP)
3218 015726 010446 MOV R4,-(SP)
3219 015730 016605 000004 MOV 4(SP),R5
3220 015734 012537 016130 MOV (R5)+,LOLIM
3221 015740 012537 016132 MOV (R5)+,HILIM
3222 015744 012537 016134 MOV (R5)+,DEVADR
3223 015750 112537 016136 MOVB (R5)+,LOBITS
3224 015754 112537 016137 MOVB (R5)+,ADRCNT
3225 015760 010566 000004 MOV R5,4(SP)
3226 015764 005005 PARAM1: CLR R5
3227 015766 012704 017726 MOV #INBUF,R4
3228 015772 122714 000015 CMPB #15,(R4)
3229 015776 001420 BEQ PARERR
3230 016000 121427 000060 1$: CMPB (R4),#60
    
```


M05

DZD90 MACY11 27(1006) 22-DEC-76 11:14 PAGE 64
 DZD900.P11 21-DEC-76 16:32 GENERAL UTILITIES (TYPE OUT, ERROR, SCOPE, ETC.)

3231	016004	002415		BLT	PARERR	
3232	016006	121427	000067	CMPB	(R4), #67	
3233	016012	003012		BGT	PARERR	
3234	016014	142714	000060	BICB	#60, (R4)	
3235	016020	152405		BISB	(R4)+, R5	
3236	016022	122714	000015	CMPB	#15, (R4)	
3237	016026	001414		BEQ	LIMITS	
3238	016030	006305		ASL	R5	
3239	016032	006305		ASL	R5	
3240	016034	006305		ASL	R5	
3241	016036	000760		BR	1\$	
3242	016040	122714	000015	PARERR: CMPB	#15, (R4)	; IS FIRST CHARACTER A <CR>
3243	016044	001003		BNE	120\$	
3244	016046	005737	017136	TST	#RDSW	; IS CKSWR ROUTINE BEING USED
3245	016052	001023		BNE	PARTI	
3246	016054	104404		120\$: INSTER		
3247	016056	000742		BR	PARAM1	
3248						
3249						
3250						; TEST TO SEE IF NUMBER IS WITHIN LIMITS
3251	016060	020537	016132	LIMITS: CMP	R5, HILIM	
3252	016064	101365		BHI	PARERR	
3253	016066	020537	016130	CMP	R5, LOLIM	
3254	016072	103762		BLO	PARERR	
3255	016074	133705	016136	BITB	LOBITS, R5	
3256	016100	001357		BNE	PARERR	
3257						
3258						; STORE NUMBER AT SPECIFIED ADDRESS
3259						
3260	016102	013704	016134	1\$: MOV	DEVADR, R4	
3261	016106	010524		MOV	R5, (R4)+	
3262	016110	062705	000002	ADD	#2, R5	
3263	016114	105337	016137	DECB	ADRCNT	
3264	016120	001372		BNE	1\$	
3265	016122	012604		PARTI: MOV	(SP)+, R4	
3266	016124	012605		MOV	(SP)+, R5	
3267	016126	000002		RTI		
3268	016130	000000		LOLIM:	0	
3269	016132	000000		HILIM:	0	
3270	016134	000000		DEVADR:	0	
3271	016136	000000		LOBITS:	0	
3272		016137		ADRCNT=LOBITS+1		
3273						
3274						; SAVE PC OF TEST THAT FAILED AND RO-R5
3275						
3276	016140	016637	000004 001274	.SAV05: MOV	4(SP), SAVPC	
3277						
3278						; SAVE RO-R5
3279						
3280	016146	010537	001270	SV05: MOV	R5, SAVR5	
3281	016152	010437	001266	MOV	R4, SAVR4	
3282	016156	010337	001264	MOV	R3, SAVR3	
3283	016162	010237	001262	MOV	R2, SAVR2	
3284	016166	010137	001260	MOV	R1, SAVR1	
3285	016172	010037	001256	MOV	RO, SAVRO	
3286	016176	000002		RTI		

N05

DZD00 MACY11 27(1006) 22-DEC-76 11:14 PAGE 65
 DZD000.P11 21-DEC-76 16:32 GENERAL UTILITIES (TYPE OUT,ERROR,SCOPE,ETC.)

```

3287
3288                                     ;RESTORE R0-R5
3289
3290 016200 013700 001256      .RES05: MOV     SAVR0,R0
3291 016204 013701 001260      MOV     SAVR1,R1
3292 016210 013702 001262      MOV     SAVR2,R2
3293 016214 013703 001264      MOV     SAVR3,R3
3294 016220 013704 001266      MOV     SAVR4,R4
3295 016224 013705 001270      MOV     SAVR5,R5
3296 016230 000002      RTI
3297
3298                                     ;CONVERT OCTAL NUMBER TO ASCII AND OUTPUT TO TELEPRINTER
3299
3300 016232 104402      .CONVR: TYPE
3301 016234 017316      MCRLF
3302 016236 010046      .CNVRT: MOV     R0,-(SP)
3303 016240 010146      MOV     R1,-(SP)
3304 016242 010346      MOV     R3,-(SP)
3305 016244 010446      MOV     R4,-(SP)
3306 016246 010546      MOV     R5,-(SP)
3307 016250 017601 000012      MOV     @12(SP),R1
3308 016254 013737 017770 001250      MOV     TEMP,TEMP3
3309 016262 062766 000002 000012      ADD     #2,12(SP)
3310 016270 012137 016452      MOV     (R1)+,WRDCNT
3311 016274 112137 016454      1S:  MOVB  (R1)+,CHRCNT
3312 016300 112137 016455      MOVB  (R1)+,SPACNT
3313 016304 013137 016456      MOV     @2(R1)+,BINWRD
3314 016310 013704 016456      2S:  MOV     BINWRD,R4
3315 016314 113705 016454      MOVB  CHRCNT,R5
3316 016320 012700 017770      MOV     #TEMP,R0
3317 016324 010403      3S:  MOV     R4,R3
3318 016326 042703 177770      BIC     #177770,R3
3319 016332 062703 000060      ADD     #060,R3
3320 016336 110320      MOVB  R3,(R0)+
3321 016340 000241      CLC
3322 016342 006004      ROR     R4
3323 016344 000241      CLC
3324 016346 006004      ROR     R4
3325 016350 000241      CLC
3326 016352 006004      ROR     R4
3327 016354 005305      DEC     R5
3328 016356 001362      BNE     3S
3329 016360 012703 020032      MOV     @MDATA,R3
3330 016364 114023      4S:  MOVB  -(R0),(R3)+
3331 016366 105337 016454      DECB  CHRCNT
3332 016372 001374      BNE     4S
3333 016374 105737 016455      TSTB  SPACNT
3334 016400 001405      BEQ     6S
3335 016402 112723 000040      5S:  MOVB  #040,(R3)+
3336 016406 105337 016455      DECB  SPACNT
3337 016412 001373      BNE     5S
3338 016414 105013      6S:  CLRB  (R3)
3339 016416 104402      TYPE
3340 016420 020032      MDATA
3341 016422 005337 016452      DEC     WRDCNT
3342 016426 001322      BNE     1S

```



```

3343 016430 013737 001250 017770      MOV      TEMP3,TEMP
3344 016436 012605      MOV      (SP)+,R5
3345 016440 012604      MOV      (SP)+,R4
3346 016442 012603      MOV      (SP)+,R3
3347 016444 012601      MOV      (SP)+,R1
3348 016446 012600      MOV      (SP)+,R0
3349 016450 000002      RTI
3350 016452 000000      WRDCNT: 0
3351 016454 000000      CHRCNT: 0
3352          016455      SPACNT=CHRCNT+1
3353 016456 000000      BINWRD: 0
3354          ;TRAP DISPATCH SERVICE
3355          ;ARGUMENT OF TRAP IS EXTRACTED
3356          ;AND USED AS OFFSET TO OBTAIN POINTER
3357          ;TO SELECTED SUBROUTINE
3358
3359 016460 011646      .TRPSR: MOV      (SP)-(SP)      ;GET PC OF RETURN
3360 016462 162716 000002      SUB      #2,(SP)        ;=PC OF TRAP
3361 016466 017616 000000      MOV      @2(SP),(SP)    ;GET TRP
3362 016472 006316      TRPOK: ASL      (SP)      ;MULTIPLY TRAP ARG BY 2
3363 016474 042716 177001      BIC      #177001,(SP)   ;CLEAR UNWANTED BITS
3364 016500 062716 001314      ADD      #.TRPTAB,(SP)  ;POINTER TO SUBROUTINE ADDRESS
3365 016504 017616 000000      MOV      @2(SP),(SP)   ;SUBROUTINE ADDRESS
3366 016510 000136      JMP      @2(SP)+        ;GO TO SUBROUTINE
3367
3368          ;ERROR HANDLER
3369
3370 016512 104414      .HLT:  CKSWR
3371 016514 032777 010000 162456      BIT      #SW12,@SWR
3372 016522 001406      BEQ      XBX
3373 016524 105777 162460      TSTB    @TPCSR
3374 016530 100003      BPL      XBX
3375 016532 112777 000207 162452      MOVB    #207,@TPDBR
3376 016540 032777 020000 162432  XBX:  BIT      #SW13,@SWR
3377 016546 001074      BNE      HALTS
3378 016550 021637 001234      CMP      (SP),LSTERR
3379 016554 001404      BEQ      IS
3380 016556 011637 001234      MOV      (SP),LSTERR
3381 016562 105037 001312      CLRB    ERRFLG
3382 016566 104406      IS:    SAVOS
3383 016570 011605      MOV      (SP),R5
3384 016572 162705 000002      SUB      #2,R5
3385 016576 011504      MOV      (R5),R4
3386 016600 006304      ASL      R4
3387 016602 061504      ADD      (R5),R4
3388 016604 006304      ASL      R4
3389 016606 042704 177001      BIC      #177001,R4
3390 016612 062704 012604      ADD      #.ERRTAB,R4
3391 016616 012437 016710      MOV      (R4)+,ERRMSG
3392 016622 012437 016722      MOV      (R4)+,DATAHD
3393 016626 011437 016734      MOV      (R4),DATABP
3394 016632 105737 001312      TSTB    ERRFLG
3395 016636 001403      BEQ      TYPMSG
3396 016640 005737 016734      TST     DATABP
3397 016644 001027      BNE     TYPDAT
3398 016646 104402      TYPMSG: TYPE

```

3399	016650	017574				MTSTN	
3400	016652	104411				CNVRT	
3401	016654	017034				XTSTN	
3402	016656	104402				TYPE	
3403	016660	017662				MERRPC	
3404	016662	104411				CNVRT	
3405	016664	017026				ERTAB0	
3406	016666	104402				TYPE	
3407	016670	017316				MCRLF	
3408	016672	112737	177777	001312		NOVB	#-1,ERRFLG
3409	016700	005737	016710			TST	ERRMSG
3410	016704	001402				BEQ	WRKO.FM
3411	016706	104402				TYPE	
3412	016710	000000				ERRMSG: 0	
3413	016712					WRKO.FM:	
3414	016712	005737	016722			TST	DATAHD
3415	016716	001402				BEQ	TYPDAT
3416	016720	104402				TYPE	
3417	016722	000000				DATAHD: 0	
3418	016724	005737	016734			TYPDAT: TST	DATABP
3419	016730	001402				BEQ	RESREG
3420	016732	104410				CONVRT	
3421	016734	000000				DATABP: 0	
3422	016736	104407				RESREG: RESOS	
3423	016740	005777	162234			HALTS: TST	QSWR
3424	016744	100005				BPL	EXITER
3425	016746	010046				PUSHRO	
3426	016750	016600	000002			MOV	2(SP),RO
3427	016754	000000				HALT	
3428	016756	012600				POPPO	
3429	016760	104414				EXITER: CKSWR	
3430	016762	005237	001232			INC	ERRCNT
3431	016766	032777	000400	162204		BIT	#SW08,QSWR
3432	016774	001007				BNE	1\$
3433	016776	032777	002000	162174		BIT	#SW10,QSWR
3434	017004	001407				BEQ	2\$
3435	017006	013737	001216	001214		MOV	NEXT,RETURN
3436	017014	012706	001200			1\$: MOV	#STACK,SP
3437	017020	000177	162170			JMP	QRETURN
3438	017024	000002				2\$: RTI	
3439	017026	000001				ERTAB0: 1	
3440	017030	006	002			.BYTE	6,2
3441	017032	001274				SAVPC	
3442	017034	000001				XTSTN: 1	
3443	017036	003	002			.BYTE	3,2
3444	017040	001226				TSTNO	
3445						;ENTER HERE ON POWER FAILURE	
3446							
3447							
3448	017042					.PFAIL:	
3449	017042	012737	017054	000024		MOV	#RESTART,24
3450	017050	000000				HALT	;SET UP FOR POWER UP TRAP
3451	017052	000777				BR	;HALT ON POWER DOWN NORMAL
3452							
3453						;PROCESSOR WILL TRAP HERE WHEN POWER IS RESTORED	
3454							


```

3455 017054          RESTAR:
3456 017054 012737 017042 000024  MOV      #.PFAIL,24          ;SET UP FOR POWER FAILURE
3457 017062 012706 001200          MOV      #STACK,SP
3458 017066 005037 017770          CLR      TEMP
3459 017072 005237 017770          INC      TEMP
3460 017076 001375          BNE     .-4
3461 017100 104402          TYPE
3462 017102 017320          MPFAIL
3463 017104 104411          CNVRT
3464 017106 017130          PFTAB
3465 017110 005037 001312          CLR      ERRFLG
3466 017114 005037 001234          CLR      LSTERR
3467 017120 104412          MSTCLR
3468 017122 104413          MEMCLR
3469 017124 000177 162064          JMP      @RETURN
3470 017130 000001          PFTAB: 1
3471 017132 003 002          .BYTE  3,2
3472 017134 001226          TSTNO

3473
3474
3475          ;CHECK SWITCH REGISTER ROUTINE. CHECKS FOR !G TO ALLOW CHANGING
3476          ;OF LOC.176.
3477          ;LOCATIONS USED:
3478 017136 000000          RDSW:  .WORD  0
3479
3480
3481 017140 005737 000042          .CKSWR: TST      @#42
3482 017144 001042          BNE     OUT
3483 017146 022737 000176 001200          CMP      @SWREG,SWR          ;SOFTWARE SWITCH REGISTER PRESENT
3484 017154 001036          BNE     OUT          ;NO, GET OUT
3485 017156 105777 162022          TSTB    @TKCSR          ;YES, WAIT FOR
3486 017162 100033          BPL     OUT          ;READY, GET CHARACTER
3487 017164 017737 162016 015576          MOV      @TKDBR,.MSG          ;AND STRIP OFF
3488 017172 042737 177600 015576          BIC      @177600,.MSG          ;THE GARBAGE
3489 017200 122737 000007 015576          CMPB    @7,.MSG          ;IS IT A (!G)
3490 017206 001021          BNE     OUT
3491 017210 104402 017266          TYPE,SCNTG
3492 017214 005137 017136          .CNTLU: COM      @RDSW
3493 017220 104402 017272          TYPE,SMSWR
3494 017224 104411 017260          CNVRT,SWREGC
3495 017230 104403 017301          INSTR,SMNEW
3496 017234 104405          PARAM
3497 017236 000000          0
3498 017240 177777          177777
3499 017242 000176          SWREG
3500 017244 000 001          .BYTE  0,1
3501 017246 104402 017316          TYPE,MCRLF
3502 017252 005037 017136          OUT:  CLR      @RDSW
3503 017256 000002          RTI
3504 017260 000001          SWREGC: 1
3505 017262 006 002          .BYTE  6,2
3506 017264 000176          SWREG
3507 017266 057377 000107          SCNTG:  .ASCIZ  (<377>)/!G/
3508 017272 051777 051127 020075          SMSWR:  .ASCIZ  (<377>/SWR= /
3509 017300 000          SMNEW:  .ASCIZ  / NEW= /
3510 017301 040 047040 053505

```

E06

DZDQD MACY11 27(1006) 22-DEC-76 11:14 PAGE 69
DZDQD.P11 21-DEC-76 16:32

GENERAL UTILITIES (TYPE OUT,ERROR,SCOPE,ETC.)

3511	017306	020075	000
3512		017312	
3513	017312	020040	000077
3514	017316	000377	
3515	017320	050377	051127 043040
3516	017326	044501	042514 027104
3517	017334	051040	051505 040524
3518	017342	052122	040440 020124
3519	017350	042524	052123 000040
3520	017356	042777	042116 050040
3521	017364	051501	020123 055104
3522	017372	050504	020104 000
3523	017377	377	000122
3524	017402	050377	047522 051107
3525	017410	046501	044440 042116
3526	017416	041511	052101 051505
3527	017424	047040	020117 042504
3528	017432	044526	042503 020123
3529	017440	051120	051505 047105
3530	017446	027124	000
3531	017451	377	047111 052523
3532	017456	043106	041511 042511
3533	017464	052116	042040 052101
3534	017472	020501	000
3535	017475	377	042524 052123
3536	017502	050040	026503 000
3537	017507	377	047514 045503
3538	017514	047440	020116 042523
3539	017522	042514	052103 042105
3540	017530	052040	051505 000124
3541	017536	051503	035122 000040
3542	017544	042526	035103 000040
3543	017552	040520	051523 051505
3544	017560	020072	000
3545	017563	105	051122 051117
3546	017570	035123	000040
3547	017574	177777	042524 052123
3548	017602	047040	035117 000040
3549	017610	051777	052105 051440
3550	017616	044527	041524 020110
3551	017624	042522	020107 047524
3552	017632	042040	030521 023461
3553	017640	020123	042504 044523
3554	017646	042522	020104 041501
3555	017654	044524	042526 000056
3556	017662	041520	020072 000
3557	017667	377	040515 020120
3558	017674	043117	042040 030521
3559	017702	020061	052123 052101
3560	017710	051525	000377
3561			
3562	017714	000002	
3563	017716	006	003
3564	017720	001244	
3565	017722	006	002
3566	017724	001246	

```

.EVEN
MGM: .ASCIZ / ?/
MCRLF: .ASCIZ <377>
MPFAIL: .ASCIZ <377>/PWR FAILED. RESTART AT TEST /

MYPASS: .ASCIZ <377>/END PASS DZDQD /

MR: .ASCIZ <377>/R/
MERR2: .ASCIZ <377>/PROGRAM INDICATES NO DEVICES PRESENT./

MERR3: .ASCIZ <377>/INSUFFICIENT DATA!/

MTSTPC: .ASCIZ <377>/TEST PC-/

MLOCK: .ASCIZ <377>/LOCK ON SELECTED TEST/

MCSRX: .ASCIZ /CSR: /
MVECX: .ASCIZ /VEC: /
MPASSX: .ASCIZ /PASSES: /

MERRX: .ASCIZ /ERRORS: /

MTSTN: .ASCIZ <377><377> /TEST NO: /

MNEW: .ASCIZ <377>/SET SWITCH REG TO DQ11'S DESIRED ACTIVE./

MERRPC: .ASCIZ /PC: /
XHEAD: .ASCIZ <377>/MAP OF DQ11 STATUS/<377>

.EVEN
XSTATQ: 2
        .BYTE 6,3
        TEMP1
        .BYTE 6,2
        TEMP2

```


DZ000 MACY11 27(1006) 22-DEC-76 11:14 PAGE 70
DZ000.P11 21-DEC-76 16:32 GENERAL UTILITIES (TYPE OUT,ERROR,SCOPE,ETC.)

```
3567 .EVEN  
3568  
3569 ;BUFFERS FOR INPUT-OUTPUT  
3570  
3571 017726 000000 INBUF: 0  
3572 017770 017770 .=. +40  
3573 017770 000000 TEMP: 0  
3574 020032 020032 .=. +40  
3575 020032 000000 MDATA: 0  
3576 020074 .=. +40  
3577 000001 .END
```


K06

DZD00 MACY11 27(1006) 22-DEC-76 11:14 PAGE 76
 DZD00.P11 21-DEC-76 16:32 CROSS REFERENCE TABLE -- USER SYMBOLS

RKSTRA	011522	2151	2175	2200	2308	2355	2595	2831*												
RKMC.P=	000001	649#																		
RKMC.S=	000005	653#																		
RX.BCC=	000015	662#																		
SAVACT	001502	1038#	1210#	1277																
SAVEPC	014054	2729#	2763#	2789#	2831*	2894*	2920*	3051#												
SAVNUM	001276	1031#	1105#	1225#	3094*	3096*														
SAVPC	001274	1104#	3276#	3441																
SAVR0	001256	1097#	3285#	3290																
SAVR1	001260	1098#	3284#	3291																
SAVR2	001262	1099#	3283#	3292																
SAVR3	001264	1100#	3282#	3293																
SAVR4	001266	1101#	3281#	3294																
SAVR5	001270	1102#	3280#	3295																
SAVSP	001272	1103#																		
SAVOS =	104406	1138#	3382																	
SCOPE =	104400	1126#	1408	1495	1513	1529	1545	1561	1577	1593	1609	1630	1647	1664						
		1681	1698	1715	1732	1749	1811	1854	1891	1907	1918	1929	1940	1951						
		1962	1973	1989	2000	2011	2022	2033	2044	2055	2066	2091	2115	2128						
		2248	2283	2325	2366	2458	2528	2689												
SCOPI =	104401	1128#	1848	1885	2319	2363	2620													
SECND	003220	1470#																		
SEQ. =	000014	661#																		
SPACNT=	016455	3312#	3333	3336#	3352#															
STACK =	001200	604#	1223	1298	3436	3457														
STFLG	001311	1114#	1226#																	
SVOS	016146	3280#																		
SWR	001200	1068#	1241#	1246	1250#	1256	1259	1270	1277	1283	1302	1310	2570	3124						
		3131	3148	3160	3371	3376	3423	3431	3433	3483										
SWREG	000176	974#	1250	1256	3483	3499	3506													
SWREGC	017260	3494	3504#																	
SW00 =	000001	584#	1270																	
SW01 =	000002	583#	1310																	
SW02 =	000004	582#																		
SW03 =	000010	581#																		
SW04 =	000020	580#																		
SW05 =	000040	579#																		
SW06 =	000100	578#																		
SW08 =	000400	577#	3431																	
SW09 =	001000	576#	3148																	
SW10 =	002000	575#	3433																	
SW11 =	004000	574#	3131																	
SW12 =	010000	573#	3160	3371																
SW13 =	020000	572#	3376																	
SW14 =	040000	571#																		
SW15 =	100000	570#																		
SYMBIT=	100000	643#	996	1416	2163															
SYNC	014522	1418#	1420#	2398	2489	3062#														
SYNC. =	000011	658#																		
SYNTST	005626	2111	2124	2137#																
TEMP	017770	2834#	2835#	2854#	3308	3316	3343#	3458#	3459#	3573#										
TEMP1	001244	953#	954#	1092#	1263#	1264	1268#	2405#	2411#	2441#	2446#	2496#	2502#	2855#						
		2856#	2857	3564																
TEMP2	001246	1093#	1264#	2406#	2413#	2442#	2448#	2497#	2504#	3566										
TEMP3	001250	1094#	1781#	1809#	3308#	3343														
TEMP4	001252	1095#	1795#	1796#	1801#	1804#	1806	1836#	1845	1873#	1882	2311#	2316	2358#						

MO6

DZD00 MACY11 27(1006) 22-DEC-76 11:14 PAGE 78
 DZD000.P11 21-DEC-76 16:32 CROSS REFERENCE TABLE -- USER SYMBOLS

TST54	007032	2341	2380#																
TST55	007434	2381	2471#																
TST56	007754	2472	2543#	3066															
TST57	= ##### U	2544																	
TST6	003444	1525	1540#																
TST7	003472	1541	1556#																
TTST	015324	1305#	1306#	1308#	1309#	3125#													
TXBA.P=	000002	650#																	
TXBA.S=	000006	654#																	
TXBUFF	014524	1439	1456	1471	1488	2383	2474	2517	3063#	1644	1661	1678	1695	1712					
TXSTRB	010720	1510	1526	1542	1558	1574	1590	1606	1627										
		1729	1746	2727#															
TXSTRC	011124	2763#																	
TXSTRD	011266	1838	1875	2789#															
TXMC.P=	000003	651#																	
TXMC.S=	000007	655#																	
TX.BCC=	000016	663#																	
TX.MUX=	000013	660#																	
TYPDAT	016724	3397	3415	3418#															
TYPE =	104402	1044	1130#	1238	1262	1272	1279	1304	1322	1347	2645	2659	3075	3077					
		3081	3085	3089	3183	3193	3205	3209	3300	3339	3398	3402	3406	3411					
		3416	3461	3491	3493	3501													
TYPMSG	016646	3395	3398#																
VECMAP	000056	946#	1043																
WORD	014056	1782#	1788	1835#	1844	1871#	1872#	1881	2138#	2199#	2304#	2312	2348#	2350					
		2352#	2354#	2359	2594#	2728#	2733	2767	2793	2834	2950#	2951#	2954	2970#					
		2972#	3052#																
MRDCNT	016452	3310#	3341#	3350#															
MRKO.F	016712	3410	3413#																
XBX	016540	3372	3374	3376#															
XCHAR1	010630	2662	2690#																
XCHAR2	010642	2666	2695#																
XCHAR3	010654	2670	2700#																
XCHAR4	010666	2674	2705#																
XCSR	015264	3080	3108#																
XERR	015306	3092	3117#																
XHEAD	017667	1262	3557#																
XPASS	015300	3088	3114#																
XSTAT0	017714	1267	3562#																
XTSTN	017034	3401	3442#																
XVEC	015272	3084	3111#																
XYZFLG	014112	2647	2677#	3057#															
SCNTG	017266	3491	3507#																
SE =	000060	1#	1328	1329#	1389#	1435	1436#	1509	1510#	1525	1526#	1541	1542#	1557					
		1558#	1573	1574#	1589	1590#	1605	1606#	1626	1627#	1643	1644#	1660	1661#					
		1677	1678#	1694	1695#	1711	1712#	1728	1729#	1745	1746#	1763	1764#	1830					
		1832#	1866	1868#	1903	1904#	1914	1915#	1925	1926#	1936	1937#	1947	1948#					
		1958	1959#	1969	1970#	1985	1986#	1996	1997#	2007	2008#	2018	2019#	2029					
		2030#	2040	2041#	2051	2052#	2062	2063#	2077	2078#	2110	2111#	2123	2124#					
		2229	2230#	2264	2265#	2298	2300#	2341	2343#	2381	2382#	2472	2473#	2544					
		2546#																	
SMNEW	017301	3495	3510#																
SMNR	017272	3493	3508#																
SN =	000056	1#	1324	1329#	1385	1389#	1431	1436#	1506	1510#	1522	1526#	1538	1542#					
		1554	1558#	1570	1574#	1586	1590#	1602	1606#	1623	1627#	1640	1644#	1657					
		1661#	1674	1678#	1691	1695#	1708	1712#	1725	1729#	1742	1746#	1760	1764#					

B07

DZDQD MACY11 27(1006) 22-DEC-76 11:14 PAGE 80
DZDQDD.P11 21-DEC-76 16:32 CROSS REFERENCE TABLE -- USER SYMBOLS

.SCOP1	015426	1129	3147#				
.START	001512	979	1222#	1234			
.SYNC	014520	1784	2402	2493	2902	2928	3061#
.TRPSR	016460	932	3359#				
.TRPTA	001314	1125#	3364				
.TYPE	015446	1131	3155#				

C07

DZD00 MACY11 27(1006) 22-DEC-76 11:14 PAGE 82
 DZD000.P11 21-DEC-76 16:32 CROSS REFERENCE TABLE -- MACRO NAMES

DOEND	18	3065													
DOFRNT	18	550													
HLT	6148	1401	1407	1450	1454	1458	1461	1482	1486	1490	1493	1767	1771	1775	1780
	1808	1847	1884	2085	2090	2157	2160	2171	2174	2182	2185	2192	2197	2205	2210
	2243	2247	2278	2282	2315	2318	2362	2415	2420	2450	2455	2506	2509	2512	2515
	2525	2618	2683	2686	2749	2756	2917	2942							
IDENT	18														
ORANGE	18	1324													
TESTA1	18														
TESTB1	18														
TESTC1	18														
TESTD1	18	50													
TESTE1	18														
TESTF1	18														
TESTH1	18														
TESTH2	18														
SAAA	14998	1515	1531	1547	1563	1579	1595								
SBBB	16158	1632	1649	1666	1683	1700	1717	1734							
SBEGIN	18	1294													
SBUFFE	18	3568													
SCATCH	18	667													
SCCC	18988	1909	1920	1931	1942	1953	1964								
SCLAVE	18	1259													
SCONVR	18	3297													
SDDD	19808	1991	2002	2013	2024	2035	2046	2057							
SEOP	18	3065													
SGETFL	18														
SGETPA	18	1312													
SHEADE	18	550													
SHLT	18	3367													
SINSTR	18	3176													
SINTNP	18														
SMAINT	18														
SMSG	18	3513													
SPARAM	18	3214													
SPFAIL	18	3445													
SREG	18	3273													
SSCOPE	18	3120													
SSCOPI	18	3144													
SSETFL	18														
SSETVE	18	925													
SSTART	18	1214													
SSYMO	18	567													
STRAPS	18	1117													
STRPDE	18	1126	1128	1130	1132	1134	1136	1138	1140	1142	1144	1146	1148	1150	1152
STRPSR	18	3354													
STSTN	18	1324	1385	1431	1506	1522	1538	1554	1570	1586	1602	1623	1640	1657	1674
	1691	1708	1725	1742	1760	1827	1863	1900	1911	1922	1933	1944	1955	1966	1982
	1993	2004	2015	2026	2037	2048	2059	2074	2107	2120	2226	2261	2295	2338	2378
	2469	2541													
STYPE	18	3152													
SVARIA	18	1052													

. ABS. 020074 000

D07

DZDQD MACY11 27(1006) 22-DEC-76 11:14 PAGE 83
DZDQDD.P11 21-DEC-76 16:32 CROSS REFERENCE TABLE -- MACRO NAMES

ERRORS DETECTED: 0
DEFAULT GLOBALS GENERATED: 0

MULE:DZDQDD.BIN,MULE:DZDQDD.SEG/SOL/CRF=DSKZ:UNIV.P11,DSKZ:DZDQDD.P11
RUN-TIME: 21 34 3 SECONDS
RUN-TIME RATIO: 263/60=4.3
CORE USED: 19K (37 PAGES)