



150-1111-01
150-1111-02
150-1111-03

000000

LIST SEQ
UNIT 0

IDENTIFICATION

PRODUCT CODE: MAINDEC-11-DZOKB-G-D
 PRODUCT NAME: T17-4K SYSTEM EXERCISER
 THIS VERSION TEST DECTAPE UNIT 1 (NOT UNIT 0)
 DATE: 01-OCTOBER-1977
 MAINTAINER: DIAGNOSTIC GROUP
 AUTHOR: JOHN MITTELL
 REVISED BY: W.F. KELICKER 25-FEB-74
 AL LOSCHAK 21-DEC-75
 BARRY SUSSMAN 01-OCT-77

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSIDERED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS DOCUMENT.

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED UNDER A LICENSE AND MAY ONLY BE USED OR COPIED IN ACCORDANCE WITH THE TERMS OF SUCH LICENSE.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

COPYRIGHT (C) 1970, 1977 BY DIGITAL EQUIPMENT CORPORATION

1. ABSTRACT

THIS PROGRAM IS A MEMORY EXPANDABLE INTERACTIVE BUS EXERCISER FOR A PAPER TAPE ORIENTED PDP-11. IT PERFORMS A TEST OF INSTRUCTIONS AND CONCURRENT OPERATIONS OF I/O EQUIPMENT SIMULTANEOUSLY. IT MAY ALSO PERFORM THE SAME OPERATION INDEPENDENTLY. THIS PROGRAM IS NOT TO BE CONSIDERED A TOTAL CHECK OF THE SYSTEM. IF AN ERROR IS DETECTED IN AN I/O DEVICE, IT WILL PROBABLY BE NECESSARY TO CORRECT THE MALFUNCTION WITH THE RESPECTIVE DIAGNOSTIC FOR THAT DEVICE.

IN THIS VERSION THE INTERRUPT SERVICE ROUTINE FOR THE DISKS, K111, PLUS THE STACK AND THE NPR DATA BUFFERS ARE RELOCATED TO THE CURRENT BANK.

2. REQUIREMENTS

2.1 EQUIPMENT

PDP-11 STANDARD COMPUTER

2.1.1 OPTIONAL HARDWARE THAT THE PROGRAM WILL EXERCISE

MM11	UP TO 28KH OF MEMORY
RC11	DISK
RK11	DISK
RP11	DISK
RF11	DISK (256K)
TC11	DECTAPE-TRANSPORT ONE
KE11A	EXTENDED ARITHMETIC UNIT
KH11L	LINE CLOCK
PC11	HIGH SPEED READER/PUNCH
BL11	ASR33 OR ASR35 TELEPRINTER-LC11.VTOS
LP11	LINE PRINTER
LS11	LINE PRINTER...SEE 5.2.11

2.2 STORAGE

2.2.1 PROGRAM STORAGE - THE ROUTINE USES
4K OF MEMORY

3. LOADING PROCEDURE

3.1 METHOD

PROCEDURE FOR NORMAL ABSOLUTE TAPES SHOULD BE FOLLOWED.

4. STARTING PROCEDURE

THIS PROGRAM HAS BEEN MODIFIED TO RUN WITH OR WITHOUT A CONSOLE PROCESSOR. IF A CONSOLE MACHINE IS USED; THEN THE PROGRAM LOOKS AT THE SOFTWARE SWITCH REGISTER. IF A CONSOLE-LESS MACHINE IS USED; THEN THE PROGRAM AUTOMATICALLY LOOKS AT THE CONTENTS OF LOCATION SOF1SR (176) AS A SWITCH REGISTER.

IT'S THE RESPONSIBILITY OF THE OPERATOR TO SET UP THIS LOCATION PRIOR TO STARTING THE PROGRAM.

THE PROGRAM REQUIRES TWO BELLS ON THE TTY TO MAKE ONE TRUE PASS OF THE PROGRAM. THE FIRST BELL OCCURS AFTER ONE PASS OF THE INSTRUCTION TEST WITH THE TRACE BIT CLEARED. THE SECOND BELL MARKS THE END OF AN INSTRUCTION TEST PASS WITH THE TRACE BIT SET.

4.1 CONTROL SWITCH SETTING

STARTING AT SA 200 ALL SWITCHES SHOULD BE SET AS INDICATED.

4.2 STARTING ADDRESS OR ADDRESSES

- (A) 200 = SR = 000777 TEST PROCESSOR ONLY-WITH CORE EXPANSION
- (B) 200 = SR = 001777 TEST PROCESSOR ONLY-4K-INHIBIT
- CORE EXPANSION
- (C) 200 = SR = 002XXX TEST I/O ONLY
- (D) 200 = SR = 000000 -CORE EXPAND AND TEST ALL AVAILABLE I/O DEVICES

- SW0 = 1 INHIBIT TTY OUTPUT
 - SW1 = 1 INHIBIT TTY INPUT
 - SW2 = 1 INHIBIT HSP
 - SW3 = 1 INHIBIT MSR
 - SW4 = 1 INHIBIT LINE CLOCK
 - SW5 = 1 INHIBIT RP11, RX11, RC11 AND RP11 DISK(S)
 - SW6 = 1 INHIBIT TC11 DECTAPE
 - SW7 = 1 INHIBIT LINE PRINTER --- IF LINE PRINTER IS USED. MUST RESTART AT 502
- IF EAE EXIST IT WILL BE AUTOMATICALLY SELECTED

4.3 PROGRAM AND/OR OPERATOR ACTION

LOAD PROGRAM INTO MEMORY.
 SET SWITCH REGISTER TO STARTING ADDRESS.
 LOAD ADDRESS.
 SET SWITCHES TO INHIBIT NON EXISTANT DEVICES
 PRESS START.
 THE PROGRAM WILL LOOP AND
 BELL WILL RING ONCE PER PASS OF THE PROGRAM.
 A MINIMUM OF TWO PASSES SHOULD
 ALWAYS BE RUN.

5. OPERATING PROCEDURE

5.1 OPERATIONAL SWITCH SETTINGS

5.1.1 AT SA 200 ... THE INSTRUCTION AND LOGIC TEST. WITH ALL SWITCHES
 DOWN THE PROGRAM WILL TEST ALL DEVICES AND PRINT OUT CN ERRORS
 AND CONTINUE IN TEST. (BELL WILL RING AT COMPLETION OF A PASS)

5.1.2 SWITCH SETTINGS ARE

SW15 = 1 OR UP ... HALT ON ERROR
 SW14 = 1 OR UP ... SCOPE LOOP
 SW13 = 1 OR UP ... INHIBIT PRINTOUT
 SW12 = 1 OR UP ... INHIBIT TRACE TRAPPING
 SW11 = 1 OR UP ... INHIBIT ITERATION LOOP
 SW10 = 1 OR UP ... INHIBIT PROCESSOR TEST
 SW09 = 1 OR UP ... INHIBIT VARIABLE CORE EXPANSION
 SW08 = 1 OR UP ... RESTART ON ERROR

5.1.3

5.2. SUBROUTINE ABSTRACTS

5.2.1 BEGIN SA 200

5.2.2 SCOPE

 THIS SUBROUTINE CALL IS PLACED BETWEEN EACH SUBTEST IN THE
 INSTRUCTION SECTION. IT RECORDS THE STARTING ADDRESS OF EACH
 SUB-TEST AS IT IS BEING ENTERED.
 IF A SCOPE LOOP IS REQUESTED WITH SW14=1; THEN
 IT WILL JUMP TO THE START OF THE SUBTEST THAT THE SCOPE LOOP
 IS REQUESTED FOR. IF SCOPE LOOP IS NOT REQUESTED, THERE WILL
 BE EITHER A FIXED OR RANDOM NUMBER OF ITERATIONS ON THAT SUB-
 TEST BEFORE THE NEXT SUBTEST IS ENTERED. SWITCH 11 ON A 1
 INHIBITS ITERATION OF SUBTESTS.

5.2.3 HLT

IS A ROUTINE THAT PRINTS-OUT AN ADDRESS THAT TAGS THE FAILING TEST, THE STATUS REGISTER AT THE TIME OF THE FAILURE, AND THE PROCESSOR TEST BEING EXECUTED AT THE TIME OF FAILURE.

5.2.4 TRTRAP

THIS ROUTINE WILL ALLOW THE TRACE BIT TRAP TO BE SET AFTER FIRST LOOP OF THE PROGRAM. UNDER NORMAL TESTING THE TRACE BIT WILL BE SET ON ALTERNATE LOOPS OF THE PROGRAM. WHEN SET IT CAUSES A TRAP AFTER EACH INSTRUCTION. THE FIRST INSTRUCTION EXECUTED UPON TRAPPING IS AN "RTI" WHICH RETURNS TO THE INTERRUPTED SEQUENCE OF INSTRUCTION.

5.2.5 TRAPCATCHER

THIS IS A SERIES OF INSTRUCTIONS STARTING AT LOCATION 0, DESIGNED TO DETECT AND ISOLATE UNEXPECTED TRAPS AND INTERRUPTS TO THE TRAP AND INTERRUPT VECTOR AREA OF MEMORY.

THE PRINCIPLE OF THIS ROUTINE IS: THE VECTOR ENTRANCE ADDRESS POINTS TO THE NEXT SEQUENTIAL WORD WHICH CONTAINS A HALT (00000). (THIS LOCATION IS ALSO THE STATUS FOR THAT VECTOR ENTRANCE, BUT THIS HAS NO EFFECT ON IT ALSO BEING THE NEXT INSTRUCTION).

IF A HALT OCCURS IN THE TRAP OR INTERRUPT VECTOR AREA, REGISTER SIX SHOULD BE EXAMINED TO DETERMINE ITS CONTENTS, THEN USE REGISTER SIX CONTENTS AS AN ADDRESS TO DETERMINE THE LOCATION WHERE THE PROGRAM WAS AT WHEN THE INTERRUPT OR TRAP OCCURRED. (MEMORY AS SPECIFIED BY R6 CONTAINS THE PC OF THE INSTRUCTION FOLLOWING THE INSTRUCTION WHERE THE TRAP OCCURRED).

5.2.6 TTYINI (TTY INPUT)

THIS ROUTINE OPERATES IN THE INTERRUPT MODE AND CHECKS FOR A COUNT PATTERN IN THE READER OF THE TTY. THE ROUTINE WILL ACCEPT AN INFINITE NUMBER OF ZERO BYTES (BLANK TAPE). BUT THE FIRST BYTE THAT IS NOT A ZERO MUST BE A ONE AND ALL SEQUENTIAL BYTES MUST BE ONE GREATER. IF THE ROUTINE DETECTS AN ERROR IN THE COUNT PATTERN, IT CHECKS TO SEE IF IT IS A 207 (BELL). IF SO IT IS IGNORED. IF NOT A COMPARISON ERROR IS FLAGED.
WHEN TESTING THE TTY READER THE TAPE MUST HAVE A COUNT PATTERN AND BE LOCATED ON THE LEADER PORTION WHEN STARTING TEST.

5.2.7 TYOUT (TTY OUTPUT)

THIS IS A ROUTINE THAT OUTPUTS A COUNT PATTERN IN THE INTERRUPT MODE TO THE TELEPRINTER. IF A PAPER TAPE IS PUNCHED IT MAY HAVE 207'S (BELLS) IN IT. PUNCHED WHEN THE BELL FOR PASS COMPLETE RINGS.

5.2.8 RFSTART (RF-11 DISK)

THIS ROUTINE PERFORMS A WRITE AND A WRITE CHECK OF THE DISK. THE DATA THAT IS WRITTEN ON THE DISK IS PART OF TEST PROGRAM CODE THAT IS NEVER MODIFIED. THIS SEGMENT OF CORE IS WRITTEN IN CONTIGUOUS BLOCK THRU THE DISK MEMORY. AFTER THE TOTAL DISK(S) HAS BEEN WRITTEN, A WRITE CHECK IS USED TO VERIFY THAT THE DATA HAS BEEN WRITTEN CORRECTLY ON THE DISK. NOTE THAT NO "DATA" ARE USED IN EXERCISING THE DISK (DATA IS NOT TRANSFERRED INTO CORE).
THE INTERRUPT SERVICE ROUTINE AND DATA BUFFER IS TRANSFERRED TO THE CURRENT BANK THAT INSTRUCTIONS ARE BEING EXECUTED IN.

5.2.9 FENDZ (TC11 FORWARD END ZONE)

FENDZ IS THE FIRST ADDRESS IN THE DECTAPE INTERRUPT VECTOR (214). THIS ROUTINE WILL READ, IN REVERSE, BLOCK NUMBERS UNTIL THE REVERSE END ZONE IS FOUND. AT THIS POINT THE INTERRUPT VECTOR AND COMMAND REGISTER ARE MODIFIED TO READ ALL BLOCK NUMBERS IN THE FORWARD DIRECTION. EACH BLOCK NUMBER READ IS COMPARED WITH THE EXPECTED BLOCK NUMBER COUNT AND MISCOMPARISONS REPORTED. WHEN EACH BLOCK IS FOUND (WITH THE EXCEPTION OF BLOCK 0) A BLOCK (400 WORDS) OF TEST DATA IS WRITTEN ONTO TAPE. AFTER ALL BLOCK NUMBERS HAVE BEEN READ THE TAPE IS DRIVEN INTO THE FORWARD END ZONE. HERE THE DIRECTION IS REVERSED AND ALL BLOCK NUMBERS ARE READ IN REVERSE. STARTING WITH BLOCK 1100(8) THROUGH BLOCK 1 THE DATA IS READ FROM TAPE. THE SAME BUFFER IS USED FOR BOTH READ AND WRITE OPERATIONS.
IF THE DATA-BUFFER IS DESTROYED DURING A READ OPERATION IT MAY BE NECESSARY TO RELOAD THE PROGRAM.

5.2.10 LCLK (LINE CLOCK)

THIS TEST OF THE LINE CLOCK IS IN THE INTERRUPT MODE. IF OPERATING CORRECTLY THE SYSTEM I/O WILL RUN AT FULL SPEED FOR 55 SECONDS THEN ALL I/O AT LEVEL SIX OR LESS WILL STALL FOR 5 SECONDS. THIS IS BASED ON 60 CYCLES AS THE LINE FREQUENCY.

5.2.11 LPI (LINE PRINTER)

THIS ROUTINE OUTPUTS TO THE LINE PRINTER IN THE FLAG MODE WHILE FILLING THE BUFFER IN THE INTERRUPT MODE WHILE THE BUFFER IS BEING PRINTED.
FOR 132 COLUMN PRINTER CHANGE LOCATION LP80 FROM 117 TO 203.

5.2.12 HSRINI (PC11 INPUT)

THIS ROUTINE OPERATES IN THE INTERRUPT MODE AND CHECKS FOR A COUNT PATTERN IN THE PC11 READER. THE ROUTINE WILL ACCEPT AN INFINITE NUMBER OF ZERO BYTES (BLANK TAPE). BUT THE FIRST BYTE THAT IS NOT A ZERO MUST BE A ONE AND ALL SEQUENTIAL BYTES MUST BE ONE GREATER. IF THE ROUTINE DETECTS AN ERROR IN THE COUNT PATTERN, A DATA ERROR IS FLAGED.
WHEN TESTING THE MSR READER THE TAPE MUST HAVE A COUNT PATTERN AND BE LOCATED ON THE LEADER PORTION WHEN STARTING TEST.

5.2.13 HPOUT (PC11 OUTPUT)

THIS IS A ROUTINE THAT OUTPUTS A COUNT PATTERN IN THE INTERRUPT MODE TO THE HIGH SPEED PUNCH.

5.2.14 RKSTART (RK-11 DISK)

THIS ROUTINE PERFORMS A WRITE AND A WRITE CHECK OF THE DISK. THE DATA THAT IS WRITTEN ON THE DISK IS PART OF TEST PROGRAM CODE THAT IS NEVER MODIFIED. THIS SEGMENT OF CORE IS WRITTEN IN CONTIGUOUS BLOCK THRU THE DISK MEMORY. AFTER THE TOTAL DISK HAS BEEN WRITTEN, A WRITE CHECK IS USED TO VERIFY THAT THE DATA HAS BEEN WRITTEN CORRECTLY ON THE DISK. NOTE THAT NO "DATA" ARE USED IN EXERCISING THE DISK (DATA IS NOT TRANSFERRED INTO CORE). THE INTERRUPT SERVICE ROUTINE AND DATA BUFFER ARE TRANSFERRED TO THE CURRENT BANK THAT INSTRUCTIONS ARE BEING EXECUTED IN.

5.2.15 RCSTART (RC-11 DISK)

THIS ROUTINE PERFORMS A WRITE AND A WRITE CHECK OF THE DISK. THE DATA THAT IS WRITTEN ON THE DISK IS PART OF TEST PROGRAM CODE THAT IS NEVER MODIFIED. THIS SEGMENT OF CORE IS WRITTEN IN CONTIGUOUS BLOCK THRU THE DISK MEMORY. AFTER THE TOTAL DISK(S) HAS BEEN WRITTEN, A WRITE CHECK IS USED TO VERIFY THAT THE DATA HAS BEEN WRITTEN CORRECTLY ON THE DISK. NOTE THAT NO "DATA" ARE USED IN EXERCISING THE DISK (DATA IS NOT TRANSFERRED INTO CORE). THE INTERRUPT SERVICE ROUTINE AND DATA BUFFER IS TRANSFERRED TO THE CURRENT BANK THAT INSTRUCTIONS ARE BEING EXECUTED IN.

5.2.16 RPSTART (RP-11 DISK)

THIS ROUTINE PERFORMS A WRITE AND A WRITE CHECK OF THE DISK. THE DATA THAT IS WRITTEN ON THE DISK IS PART OF TEST PROGRAM CODE THAT IS NEVER MODIFIED. THIS SEGMENT OF CORE IS WRITTEN IN CONTIGUOUS BLOCK THRU THE DISK MEMORY. AFTER THE TOTAL DISK(S) HAS BEEN WRITTEN, A WRITE CHECK IS USED TO VERIFY THAT THE DATA HAS BEEN WRITTEN CORRECTLY ON THE DISK. NOTE THAT NO "DATA" ARE USED IN EXERCISING THE DISK (DATA IS NOT TRANSFERRED INTO CORE). THE INTERRUPT SERVICE ROUTINE AND DATA BUFFER IS TRANSFERRED TO THE CURRENT BANK THAT INSTRUCTIONS ARE BEING EXECUTED IN. (FOR THE RPO3 THE ISR MUST BE MODIFIED TO TEST THE FULL SURFACE:

5.2.17 CORE EXPANSION (DET1)

THIS ROUTINE IS CONTROLLED BY SWITCH 9. THE PROCESSOR MAINLINE CODE WILL BE EITHER 4KW OR EXPANDS TO THE MAXIMUM CORE THAT IS AVAILABLE. THE ROUTINE DETERMINES THE MAXIMUM CORE SIZE BY DOING A "DATO" TO A LOCATION IN EACH BANK. IF THE BANK DOES NOT EXIST, A TIME OUT WILL OCCUR. WHEN CORE SIZE IS DETERMINED AN IMAGE OF BANK 0 IS TRANSFERRED TO EACH EXISTING BANK. THEN THE CODE IN EACH BANK IS MODIFIED SO THAT, WHEN THE LAST SUB TEST IN A MEMORY BANK IS EXECUTED THERE IS A JUMP INSERTED TO THE FIRST SUB TEST OF THE NEXT BANK. WHEN IN THE LAST BANK THE MODIFIED INSTRUCTION WILL TRANSFER YOU TO BANK 0.

THE LISTING SHOWS ONLY THE CODE OF BANK ZERO. WHEN AN ERROR OCCURS THAT IS NOT IN BANK ZERO, IGNORE THE BANK BITS OF THE PRINT OUT AND USE THE LISTING FOR BANK ZERO.

5.3 PROGRAM AND/OR OPERATOR ACTION

- 5.3.1 LOADING AND STARTING AT 200 WITH ALL SWITCHES DOWN IS WORSE CASE TESTING. IF AN ERROR IS DETECTED HERE, THERE WILL BE A PRINTOUT. WHEN AN ERROR IS DETECTED AND IT IS NECESSARY TO SCOPE ON IT, SET SW15 TO HALT ON ERROR, THEN SW14 TO LOOP ON ERROR, THEN SW13 TO DELETE PRINTOUTS. THEN THE MACHINE MUST BE CONTINUED.

6. ERRORS

6.1 ERROR PRINTOUT

ARE IN A THREE WORD FORMAT. THE 1ST IS PC+2 OF THE DETECTED ERROR, THE 2ND, IS THE STATUS REGISTER. THE 3RD IS THE PROCESSOR TEST AT THE TIME OF THE ERROR (CONTENTS OF RETURN). REFER TO THE LISTING FOR DETAILED INFORMATION.

6.2 ERROR RECOVERY

FOR TTY READER AND HSR, TAPE MUST BE REPOSITIONED TO LEADER BEFORE RESTARTING TEST. IF YOU DESIRE TO HAVE THE PROGRAM RESTART ON AN ERROR MAKE SWITCH REGISTER BIT8 AN ONE.

7. RESTRICTIONS

7.1 STARTING RESTRICTION

IF LINE PRINTER IS USED RESTART ADDRESS MUST BE 400 FOR HSR AND TTY READER. TAPE MUST BE ON LEADER.

7.2 OPERATIONAL RESTRICTION

IF OPERATION UNDER MONITORS, THE CONSOLE DEVICE, LINE PRINTERS AND THE SYSTEM DEVICE ARE NOT TESTED.

B. MISCELLANEOUS

TRACKING DOWN UNUSUAL FAILURES

FAILURES THAT MAY OCCUR BECAUSE OF A FALSE ENTRY INTO A SUBTEST, OR A FAILURE IN A CONTROL ROUTINE RATHER THAN A SUBTEST. DETECTION OF THESE MAY BE ACCOMPLISHED BY SEVERAL PROCEDURES. THERE IS A LOCATION CALLED "RETURN" THAT RECORDS THE LAST SUCCESSFUL SUBTEST COMPLETED. THERE IS ANOTHER LOCATION CALLED "SCOPE" THAT SHOWS HOW MANY TIMES THE SUBTEST HAS BEEN EXECUTED. THERE IS ANOTHER LOCATION CALLED "ICOUNT" THAT CONTAINS THE ITERATION COMPARISON VALUE. THE STACK "R6" SHOULD BE EQUAL TO "BUFF" WHEN THE FIRST INSTRUCTION OF THE SUBTEST IS ENTERED. TO REDUCE INSTRUCTION EXECUTION IN CONFUSING SITUATION, THE "SCOPE" LOCATION FOLLOWING THE SUBTEST SHOULD BE CHANGED TO A BRANCH TO THE FIRST INSTRUCTION OF THE SUBTEST (THE FIRST LOCATION FOLLOWING THE PREVIOUS SCOPE LOCATION) AND THE "HLT" LOCATION MAY BE REPLACED WITH A "NOP".

A USER MAY ADD A UNIQUE ROUTINE TO THIS TEST TO EXERCISE A NON DEC OPTION, FOR CHECKING BUS INTERACTION WITH HIS EXISTING DEC OPTIONS.

FOR TROUBLE FREE INTERACTION THERE ARE A FEW GROUND RULES THAT SHOULD BE FOLLOWED.

1. USE NO REGISTERS.
2. THE ROUTINE SHOULD BE STAND ALONE.
3. THE EXISTING "HLT" SHOULD BE USED FOR ERROR DETECTION.
4. CODE IN THE PRIMING AREA SHOULD SET INTERRUPT ENABLE, INITIALIZE DATA AND RAISE A FLAG IF NECESSARY.
5. THE INTERRUPT VECTOR STATUS WORD SHOULD CONTAIN THE PRIORITY LEVEL OF THE DEVICE.
6. THE INTERRUPT VECTOR SHOULD POINT TO YOUR STAND ALONE ROUTINE.
7. THE STAND ALONE ROUTINE WHEN COMPLETING ALL HOUSE KEEPING OPERATION AND DATA COMPARISONS SHOULD THEN EXECUTE A "RTI" TO RETURN TO MAINLINE CODE.

INSERTION OF USER I/O ROUTINES

1. MAY BE INSERTED IN BANK ZERO WHERE I/O ROUTINES EXIST. FOR DEVICES THAT THE USER DOES NOT HAVE. IF CORE EXPANSION

- IS TO BE INHIBITED, THE USER MAY OVERLAY THE EXPANSION CODE.
2. IF THE USER HAS MORE THAN 4KW OF CORE, THE ROUTINE MAY BE PLACED IN ANY OF THE EXTRA BANKS AND CORE EXPANSION BE INHIBITED.
 3. IN THE PRIMING CODE SEVERAL INSTRUCTIONS BEFORE THE TAG "MAINLINE" THERE IS AN INSTRUCTION JSR %7 J#USER. THE SECOND WORD OF THAT INSTRUCTION IS AN ABSOLUTE ADDRESS THAT THE USER MAY CHANGE TO POINT TO HIS ROUTINE. THE USER SHOULD EXIT HIS PRIMING ROUTINE WITH A RTS %7 INSTRUCTION.

8.1 EXECUTION TIME

EXECUTION VARIES WITH NUMBER OF DEVICES, FOR 4KW SYSTEMS WITH TTY AND HSR ONLY, ABOUT 1 MINUTE WITH THE TRACE BIT CLEARED ABOUT 1.5 MINUTES WITH THE TRACE BIT SET.

9. PROGRAM DESCRIPTION

THE DESIGN OF THIS SYSTEM EXERCISER IS PREDICATED UPON IT BEING PRIMARILY INTENDED FOR A PAPER TAPE SYSTEM WITH FOUR KW OF CORE, AND THAT IT BE EASY TO RUN AND UNDERSTAND. ALSO, THAT IT MAY BE MODIFIED EASILY TO EXERCISE A WIDE MULTITUDE OF PERIPHERALS, INCLUDING THOSE OF THE CUSTOMER'S OWN DESIGN. THE CONCEPT IS TO HAVE ALL DESIRED I/O RUNNING CONCURRENTLY WITH THE PROCESSOR TEST FOR BACKGROUND. THE DECISION WHICH I/O DEVICES TO BE USED IS MADE AT START UP TIME. THE DATA PATTERNS USED IN THE EXERCISER ARE FIXED. FOR MECHANICAL DEVICES, SUCH AS THE TTY READER, THERE IS NO AUTOMATIC RE-SYNCHRONIZATION IF IT'S TAPE BECOMES OUT OF PHASE WITH THE DATA. IT WILL BECOME NECESSARY TO STOP THE EXERCISER AND MANUALLY RESYNCHRONIZE THE TAPE AND RESTART THE EXERCISER.

THERE IS NO MONITOR IN THE CONVENTIONAL SENSE. EACH DEVICE THAT IS TO BE EXERCISED HAS IT'S OWN STAND ALONE ROUTINE THAT OPERATES IN THE INTERRUPT MODE. THESE ROUTINES NEED NO SUPERVISION OR MONITORING AFTER THEY ARE INITIATED. THERE IS A PRIMER AREA THAT CHECKS THE SWITCH REGISTER TO SEE WHAT DEVICES ARE TO BE INITIATED. THE PRIMER AREA SETS THE INTERRUPT ENABLE BIT IN THE DEVICE STATUS REGISTER, INITIALIZES THE DATA PATTERN AND INITIATES AN OPERATION TO RAISE DATA FLAGS ON DEVICES THAT CAN NOT INITIATE THEM THEMSELVES. THEN, THE PRIMER JUMPS TO THE PROCESSOR TEST WHERE THE INDIVIDUAL DEVICES ARE SERVICED AT THE INTERRUPT RATE.

THE INSTRUCTION EXERCISER IS A STRAIGHT LINE TEST OF INSTRUCTIONS. THE SEQUENCE IN WHICH THEY ARE EXECUTED IS THE SAME SEQUENCE IN WHICH THEY ARE

SHOWN IN THE LISTING. EACH AREA OF CODE FROM "SCOPE TO SCOPE" IS AN INDIVIDUAL SUB-TEST. WITH SWITCH 11 UP THE SUB-TEST IS EXECUTED ONE TIME AND THEN THE NEXT SUB-TEST IS EXECUTED, AND SO ON TILL ALL SUB-TESTS ARE EXECUTED. HOWEVER IF SWITCH 11 IS DOWN THE SUB-TEST WILL BE EXECUTED SOME "N" NUMBER OF TIMES BEFORE ENTERING THE NEXT SUB-TEST. IF SWITCH 14 IS UP YOU WILL NEVER LEAVE THE CURRENT SUB-TEST YOU ARE IN. THIS USE IS INTENDED FOR TROUBLE SHOOTING A MALFUNCTION IN A SUB-TEST. THE FIRST GROUP OF SUB-TESTS ARE THE BINARYS AND UNARYS. THOSE INSTRUCTIONS ARE TESTED IN THE INDEX MODE: SOURCE ONLY, DESTINATION ONLY, THEN BOTH SOURCE AND DESTINATION. THE SAME INSTRUCTIONS ARE THEN TESTED USING THE IMMEDIATE MODE INDIRECT. THESE MODES ARE TESTED AGAINST OTHER MODES: WHICH MAY USE A REGISTER OR MEMORY LOCATION. THESE WILL BE SWAPPED BETWEEN SOURCE AND DESTINATION.

AFTER THE MODES AND INSTRUCTION HAVE BEEN PROVEN IN THE WORD MODE, THEY ARE THEN TESTED IN THE BYTE MODE. OTHER TESTING IS ALSO DONE WHERE THE "JSR" INSTRUCTION IS TESTED IN NESTED COMBINATIONS. ALL COMBINATIONS OF NUMBERS ARE TESTED USING THE COMPARE, ROTATE, ADD AND COMPLIMENT INSTRUCTIONS. THERE IS ALSO A MINIMUM TEST OF POWER FAIL AND AUTO RECOVERY WHICH IS NOT ENABLED UNTIL AFTER THE FIRST PASS OF THE PROGRAM. THE REASON FOR EXECUTING ALL INSTRUCTIONS WITH THE TRACE BIT SET IS TO TAKE US INTO SERVICE AT THE END OF EACH INSTRUCTION.

THE CORE LAYOUT IS BROKEN INTO FIVE DISTINCT PARTS:

- (1) THE TRAP CATCHER,
- (2) THE SET UP AND I/O PRIMER AREA AND I/O TEST ROUTINES
- (3) THE PROCESSOR TESTS AND
- (4) CONTROL AND UTILITY ROUTINES.
- (5) CORE DETECTOR AND EXPANSION ROUTINE.

10. LISTING

11. FLOW CHART(S)

.ENDR
 .ENABLE ABS

```

;PDP11 PRELIMINARY SYSTEM TEST --- TTY-PC11-LP11 RF11 TC11 KW11L RK11 RC11 RP11 AND KE11
;TEST SIMULTANEOUS RUNNING OF I/O, WITH PROCESSOR INSTRUCTION TEST AND WITH
;WITH TRACE BIT ENABLED TO BE CONSIDER MAINLINE CODE
NOP=240 ;SYSTEM NULL OPERATION
HLT=EMT ;TRAP USED FOR ERROR PRINTOUT
SCOPE=TRAP ;TRAP USED SCOPE LOOP AND ITERATION OF SUB PROBLEMS
CC=177776
    
```

000240
 104000
 104400
 177776

```

016062      TDSB=ICSR
016063      BUFT=FYN
000000      R100=%0
000001      R101=%1
000002      RSR=%2
176000      BKWORDCT=-2000
176000      BFWORDCT=-2000
176040      RCWORDCT=-2000+40
176040      RFWORDCT=-2000+40
000000      XX=0
000000      =0
000100      .REPT 100
                .+2
                HALT ; TRAP ENTRANCE
                .ENDR ; TRAPPED TO PREVIOUS LOCATION
                .LIST SEQ,ME
                =14
                .+2
                HALT ; FALSE TRACE TRAP
                =24
                PFAIL
                340
                =30
                PRINT ; FOR HALT TRAPS
                340 ; HIGHEST PRIORITY
                =34
                SCOPEC ; USER TRAP
                0
                =46
                LOGICA ; RETURN TO MONITOR ADDRESS
                =52
                040000 ; EXECUTION TIME IS MEMORY SIZE DEPENDENT

600
601
602 000014 000014
603 000016 000016
604 000000 000000
605 000024 000024
606 000026 000340
607 000030 000030
608 000030 015564
609 000032 000340
610 000034 000034
611 000034 016364
612 000036 000000
613 000046 000046
614 000046 015534
615 000052 000052
616 000052 040000
617
618
619
620
621 ((R6)) IS THE STACK POINTER
622 ((R6)) IS THE PC+2 OF LOCATION WHERE THE TRAP ORIGINATED
623 FOR NORMAL OPERATION RUN WITH ALL SWITCHES DOWN
624 SR 15=1 OR UP---HALT ON ERROR
625 SR 14=1 OR UP---SCOPE LOOP
626 SR 13=1 OR UP---INHIBIT PRINT OUT
627 SR 12=1 OR UP---INHIBIT TRACE TRAPPING
628 SR 11=1 OR UP---INHIBIT SUB-PROBLEM ITERATION
629 SR 10=1 OR UP---INHIBIT PROCESSOR TEST
630 SR 09=1 OR UP INHIBIT VARIABLE CORE EXPANSION
631 SR 08=1 OR UP RESTART ON ERROR
632 SPECIAL DELETE SWITCHES-SET RESPECTIVE SWITCH TO A 1 TO INHIBIT INITIATION OF DEVICE
633
634 SW 0=1 INHIBIT TTY OUTPUT
635 SW 1=1 INHIBIT TTY INPUT
636 SW 2=1 INHIBIT HSP
637 SW 3=1 INHIBIT HSR
638 SW 4=1 INHIBIT LINE CLOCK
639 SW 5=1 INHIBIT RC RF RK RP DISKS
640 SW 6=1 INHIBIT TC11 DECTAPE
641 SW 7=1 INHIBIT LINE PRINTER --- IF LINE PRINTER IS USED. MUST RESTART AT 502
642 IF EAE EXIST IT WILL BE AUTOMATICALLY SELECTED.

```

```

;PDP11 SIMULTANEOUS I/O
641                                     =60
642 000060 001522                      †TTYINR                      ;TTY IN INTERRUPT VECTOR
643 000062 000200                      200
644 000064 001576                      TTYOUTR                      ;TTY OUT INTERRUPT VECTOR
645 000066 000200                      200
646 000070 001624                      HSRINR                       ;HSR INTERRUPT VECTOR
647 000072 000200                      200
648 000074 001716                      HPOUTR                       ;HSP INTERRUPT VECTOR
649 000076 000200                      200
650                                     . =100
651 000100 002022                      LK3                          ; INTERRUPT VECTOR LINE CLOCK
652 000102 000300                      300                          ; LEVEL SIX PRIORITY
653                                     . =4
654 000004 017456                      .PARSRV                      ; MEMORY PARITY
655 000006 000340                      340
656
657
658                                     . =174
659 000174 177570                      SRPTR: 177570
660 000176 000000                      SOFTSR: 000000
661                                     . =200
662 000200 000137 000502                JMP 200                       @*START
663                                     . =204
664 000204 002610                      IRF                          ; RFI1 DISK
665 000206 000240                      240                          ; LEVEL 5
666 000210 002512                      IRC                          ; RC DISK
667 000212 000240                      240
668
669                                     . =214
670 000214 002674                      FENDZ                        ; DEC TAPE
671 000216 000300                      300                          ; LEVEL 6
672                                     . =220
673 000220 002322                      IRK                          ; RK DISK
674 000222 000240                      240
675
676                                     . =254
677 000254 002426                      IRP                          ; RP DISK
678 000256 000240                      240
679
680 STATUS=177776
681 000260 177560                      TRCSR: 177560
682 000262 177562                      TRDR: 177562
683 000264 177564                      TTCSR: 177564
684 000266 177566                      TTDR: 177566
685 000270 177550                      HRCSR: 177550
686 000272 177552                      HRDR: 177552
687 000274 177554                      HPCSR: 177554
688 000276 177556                      HPDR: 177556
689 000300 177546                      LKCSR: 177546
690 000302 177514                      LPCSR: 177514
691 000304 177516                      LPOBR: 177516
692 000306 177470                      RFDAR: 177470                ; DISK ADDRESS AND ERROR
693 000310 177466                      RFDAR: 177466                ; DISK ADDRESS REGISTER
694 000312 177462                      RFWC: 177462                 ; WORD COUNT REGISTER
695 000314 177464                      RFCAR: 177464                ; CURRENT ADDRESS REGISTER
696 000316 177460                      RFCSR: 177460                ; STATUS REGISTER

```



```

753 000472 012767 000240 014232 NOEAE: MOV      #240,EAE$AT      ;BRANCH AROUND EAE ROUTINE
754 000500 000002                               RTI                ;JUMP OVER EAE SECTION
755
756                               ;START UP FOR MINI MONITOR
757                               ;RESTART HERE IF LINE PRINTER WAS ENABLED
758
759 000502 012767 016504 177314 START:  MOV      #PF$AIL,24      ;SET POWER FAIL VECTOR
760 000510 012706 016762                               MOV      #BUFF,%6      ;SET UP STACK
761 000514 012767 000530 177262       MOV      #18,4          ;SET UP TIME OUT VECTOR
762 000522 005777 177446       TST      @SAPTR        ;TRY TO REFERENCE THE
                               ;HARDWARE SWITCH REGISTER
763
764 000526 000404                               BR         25          ;BRANCH IF NO TIME OUT TRAP OCCURS
765 000530 012767 000176 177436 18:    MOV      #SOFTSR,SRPTR ;CHANGE THE SWITCH REGISTER POINTER
                               ;TO POINT TO A SOFTWARE SWITCH REGISTER
766
767 000536 022626                               CMP      (6)+,(6)+    ;RESTORE THE STACK
768 000540 012767 000006 177236 28:    MOV      #6,4         ;RESTORE TIME OUT VECTOR
769 000546 017767 177422 000742       MOV      @SAPTR,REG1  ;MOV SR TO REGISTER
770 000554 005737 016570       TST      @BSAVR6      ;SET ON POWER FAIL
771 000558 001403       BEQ      $START
772 000562 005037 016570       CLR      @BSAVR6
773 000566 104000       HLT
774 000570 005067 015644       ESTART: CLR      ICOUNT ;A POWER FAIL OCCURRED
775 000574 012706 016762       MOV      #BUFF,%6    ;SET UP STACK
776 000580 012767 000642 015636       MOV      #START2,RETURN
777 000586 005067 015630       CLR      SCOPE
778 000590 012767 000340 177156       MOV      #340,STATUS ;LOCK OUT INTERRUPTS
779 000594 005067 014736       CLR      #PFLAG      ;PRINT ROUTINE BUSY
780 000598 016702 000666       MOV      REG1,RSR     ;SAVE SWITCHES
781 000602 012700 000100       MOV      #100,R100   ;INTERRUPT ENABLE
782 000606 012701 000101       MOV      #101,R101   ;INTERRUPT ENABLE AND GO
783 000610 104400       SCOPE
784 000614 050077 177412       START2: BIS      R100,@TRCSR
785 000618 000005       RESET
786 000622 030077 177404       BIT      R100,@TRCSR ;INTERRUPT ENABLE
787 000626 001401       BEQ      .+4
788 000630 104000       HLT                ;RESET DID NOT CLEAR INTERRUPT ENABLE
789 000634 104400       SCOPE
790 000638 000660       ;DOES "RESET" ON THE BUS LAST TOO LONG
791 000642 012706 016762       MOV      #BUFF,%6    ;SET UP STACK
792 000646 000005       RESET
793 000650 050077 177370       BIS      R100,@TTCSR ;SET A BIT
794 000654 030077 177364       BIT      R100,@TTCSR ;IS IT SET
795 000658 001001       BNE      .+4
796 000662 104000       HLT                ;RESET IS ON BUS TOO LONG
797 000666 005077 177354       CLR      @TTCSR
798 000670 104400       SCOPE
799 000674 050077 177346       BIS      R100,@TTCSR
800 000678 005077 177342       CLR      @TTCSR     ;IF BUS HANG, CHECK NO SACK TIMEOUT
801 000682 104400       SCOPE
802 000686 000005       RESET
803 000690 012767 004416 015510       MOV      #BEGIN,RETURN
804 000694 012737 000472 000004       MOV      #NOEAE,284
805 000698 005777 177402       TST      #240
806 000702 012767 001520 177030       MOV      #RTIA,4
807 000706 012767 000340 177024       MOV      #340,6
808 000710 012767 000001 000604       MOV      #1,DAT1     ;BASE DATA FOR TTY READER OR KE'BOARD
    
```


809	000770	005067	000626		CLR	DATA2	:BASE DATA FOR TTY PUNCH OR TELEPRINTER
810	000771	012767	000001	000674	MOV	#1 DATA3	:BASE DATA FOR MSR
811	000100	005067	000764		CLR	DATA4	:BASE DATA FOR MSP
812	000101	012767	016762		MOV	DEBUF,%6	
813	000102	005067	000760		CLR	DELAY	:FOR READER STALL - MSR -
814	000103	012767	000340	176752	MOV	#340 STATUS	:LOCK OUT INTERRUPTS
815	000104	030227	000001		BIT	RSR,#1	
816	000105	001004			BNE	ST1	
817	000106	050077	177226		MOV	R100,@TTCSR	:TTY OUT
818	000107	030227	000002	ST1:	BIT	RSR,#2	
819	000108	001004			BNE	ST2	
820	000109	050177	177210		MOV	R101,@TRCSR	:TTY IN
821	000110	050177	177220	ST2:	ST	CSR	:TEST FOR OUT OF TAPE
822	000111	100440			BIT	RSR,#4	
823	000112	030227	000004		BIT	RSR,#4	
824	000113	001004			BNE	ST3	
825	000114	050077	177204		MOV	R100,@MPCSR	:MSP
826	000115	050177	177174	ST3:	ST	CSR	:TEST FOR OUT OF TAPE
827	000116	100440			BIT	ST4	
828	000117	000402			BNE	ST3A	:RESERVED FOR OVERLAYS
829	000118	017416			GET3		:1020 GTP OVER LAY
830	000119	017416			GET3		:1022 GTP OVER LAY
831	000120	030227	000010	ST3A:	BIT	RSR,#10	
832	000121	001004			BNE	ST4	
833	000122	010067	000660		MOV	R100,DELAY	:FOR STALL MSR
834	000123	050177	177146		BIT	R101,@TRCSR	:MSR
835	000124	030227	000020	ST4:	BIT	RSR,#20	
836	000125	001004			BNE	ST5	
837	000126	005067	000762		CLR	TIME	
838	000127	050077	177140		BIT	R100,@LKCSR	:LINE CLOCK 50 OR 60 CYCLES
839	000128	030227	000040	ST5:	BIT	RSR,#40	
840	000129	001004			BNE	ST6	
841	000130	012767	001210	176630	MOV	ST5A,4	
842	000131	105777	177246		TSTB	@MPCSR	:WAIT FOR CONTROLLER READY
843	000132	100375			BPL	ST4	
844	000133	012777	000015	177236	MOV	#15,@MPCSR	:RESET DRIVE
845	000134	105777	177232		TSTB	@MPCSR	:WAIT FOR CONTROLLER READY
846	000135	100375			BPL	ST4	
847	000136	005777	177214		TST	@MPCSR	:WAIT FOR ACCESS READY
848	000137	100375			BPL	ST4	
849	000138	005077	177206		CLR	@MPCSR	:CLR ATTENTION
850	000139	012767	001520	176566	MOV	RTIA,4	
851	000140	012777	000037	177076	MOV	#37,@ACDAR	
852	000141	012767	043503	001426	MOV	#43503,@RFUNCTION	:WRITE CHECK/WRITE RF
853	000142	012767	043503	001310	MOV	#43503,@RCFUNCTION	
854	000143	012767	043503	001116	MOV	#43503,@RFUNCTION	
855	000144	012767	043503	177156	MOV	#43503,@PFUNCTION	
856	000145	110077	177036		MOV	R100,@MPCSR	:TELL DISK TO READ OR WRITE
857	000146	110077	177060		MOV	R100,@MKCSR	
858	000147	110077	177040		MOV	R100,@MCCSR	
859	000148	110077	177132		MOV	R100,@MPCSR	
860	000149	030200		ST6:	BIT	RSR,#100	:TEST FOR DECTAPE
861	000150	001011			BNE	ST7	
862	000151	012767	002664	001364	MOV	STCFIRST,TCEXPE	:FIRST BLOCK SHOULD BE ZERC
863	000152	012777	002674	177072	MOV	#FEND2,@TCIV	:GO TO END ZONE ON INTERRUPT
864	000153	012777	004503	177050	MOV	#R+IE+AB+DO,@TCCM	:MOVE REVERSE

```

865 001322 105702 ST7: TSTB RSR ;LINE PRINTER
866 001324 100429 BMI STB
867 001326 012767 001404 176450 MOV #STB,4 ;DON'T CHANGE 200
868 001328 012767 000137 000724 MOV #137,SOLPAT ;RESET FOR START OF LINE PATTERN
869 001330 012767 000612 000720 MOV LPA+4,CLINCT ;LINE COUNT
870 001332 012767 000040 000706 MOV #40,CURPAT
871 001334 012777 000014 176720 MOV #14,LPDDR ;LINE FEED TO POSITION BUFFER
872 001336 012737 002144 000200 MOV #LPINTR,200 ;INTERRUPT VECTOR
873 001338 012737 000200 000202 MOV #200,202 ;PROCESSOR LEVEL 4
874 001400 010077 176676 MOV #100,2LPCSR ;INTERRUPT ENABLE
875 001402 005037 015550 ST8: CLR #STRAP ;NO "T" BIT FIRST PASS
;IF OPERATION WITH DIAGNOSTIC PACKAGE OR ACT11
876
877 001410 005767 176426 TST 42
878 001414 001415 BEQ ST8A ;BRANCH IF NO MONITOR
879 001416 012767 001520 176360 MOV #RTIA,4
880 001418 005077 176652 CLR #LPCSR ;NO LINE PRINTER WITH MONITOR
881 001420 005077 176630 CLR #TTCSR ;NO CONSOLE TEST WITH MONITOR
882 001422 122767 000002 176377 CMPB #2,41 ;IS IT RKDP
883 001424 001002 BNE ST8A
884 001426 005077 176674 CLR #RKCSR ;YES DON'T TEST RK DISK
885 001428 004737 016764 ST8A: JSR %7,2USER ;FOR USER I/O PROGRAM
886 001430 004767 015306 JSR %7,DETI ;CHECK FOR CORE EXPANSION
887 001432 005067 176322 CLR 6 ;HALT FOR BUS ERROR
888 001434 012767 000006 176312 MOV #6,4 ;FOR USER I/O PROGRAM
889 001436 005067 176300 CLR STATUS ;ALLOW INTERRUPTS
890 001438 000401 BR +4
891 001500 000001 MAINLINE: WAIT ;WAIT HERE FOR INTERRUPTS
892 001502 037727 176466 002000 BIT #STRAP,2000 ;INHIBIT PROCESSOR TEST
893 001510 001373 BNE MAINLINE
894 001512 000167 002700 JMP BEGIN
895 001516 000000 REG1: 0 ;STATUS OF SELECTED DEVICES
896 001520 000002 RTIA: RTI ;AN RTI FOR NON EXISTANT I/O
897
898
899
900
901 ;TTY RECEIVER VALUES 0 TO 377
902
903 001522 105777 176532 TTYINR: TSTB #TRCSR ;IS DONE SET
904 001526 100401 BMI .+4
905 001530 104000 HLT ;FALSE RETURN FROM MAINLINE
906 001532 105777 176524 TSTB #TRDR ;TEST DATA FOR LEADER
907 001536 001413 BEQ TTYIN2 ;IF LEADER GO BACK
908 001540 127767 176516 000026 CMPB #TRDR,DATA1 ;NOT LEADER TEST FOR DATA
909 001546 001401 BEQ TTYIN3
910 001550 104000 HLT ;DATA COMPARISON ERROR
911 001552 105267 000016 TTYIN3: INCB DATA1 ;INCREMENT DATA
912 001556 001003 TTYIN4: BNE TTYIN2
913 001560 012767 000001 000006 TTYIN1: MOV #1,DATA1 ;BASE DATA
914 001566 005277 176466 TTYIN2: INC #TRCSR ;START READER
915 001572 000002 RTI ;RETURN TO MAINLINE
916
917 001574 000000 DATA1: XX ;EXPECTED DATA
918
919 ;TTY TRANSMITTER PRINT VALUES 0 TO 377
920

```

```

921 001576 105777 176462 TYOUTR: TSTB @TTCSR ; TEST FOR DONE
922 001602 100401 BMI .+4 ; BRANCH IF FLAG FOUND
923 001604 104000 HLT ; FALSE INTERRUPT RETURN
924 001606 105267 000010 INCB DATA2 ; INCREMENT DATA
925 001612 016777 000004 176446 TYOUT1: MOV DATA2,@TTDBR ; OUTPUT TO DEVICE
926 001620 000002 RTI ; RETURN TO MAINLINE
927
928 001622 000000 DATA2: XX ; TRANSMITTED DATA
929 ;HSR SECTION VALUES 0 TO 377
930
931 001624 105777 176440 HSRINR: TSTB @HRCR ; IS DONE SET
932 001630 100401 BMI .+4
933 001632 104000 HLT ; FALSE RETURN FROM MAINLINE
934 001634 105777 176432 TSTB @HROBR ; TEST DATA FOR LEADER
935 001640 001413 BEQ HSRIN2 ; IF LEADER GO BACK
936 001642 127767 176424 000026 CMPB @HROBR,DATA3 ; NOT LEADER TEST FOR DATA
937 001650 001401 BEQ .+4
938 001652 104000 HLT ; DATA COMPARISON ERROR
939 001654 105267 000016 INCB DATA3 ; INCREMENT DATA
940 001660 001003 BNE HSRIN2
941 001662 012767 000001 000006 HSRIN1: MOV #1,DATA3 ; BASE DATA
942 001670 005277 176374 HSRIN2: INC @HRCR ; START READER
943 RTI ; RETURN TO MAINLINE
944
945 001676 000000 DATA3: XX ; EXPECTED DATA
946
947 ;HS PUNCH SECTION, VALUES 0 TO 377
948 ;ENABLE READER ON FIX COUNT OF PUNCH ONLY (14 TIMES)
949 001700 012767 000000 000064 HPOUT: MOV #0,DATA4 ; INITIAL DATA
950 001706 016777 000060 176362 HPOUT1: MOV DATA4,@HPDBR ; OUTPUT TO DEVICE
951 001714 000002 RTI ; RETURN TO MAINLINE
952 001716 105777 176352 HPOUTR: TSTB @HPCSR ; TEST FOR DONE
953 001722 100401 BMI .+4 ; BRANCH IF FLAG FOUND
954 001724 104000 HLT ; FALSE INTERRUPT RETURN
955 001726 046777 000044 176334 BIC DELAY,@HRCR ; CLEAR HSR INTERRUPT ENABLE
956 001734 005267 000034 INC INTCNT ; COUNT INTERRUPTS
957 001740 026727 000030 000014 CMP INTCNT,#14 ; SAVE TO TURN READER ON?
958 001746 001005 BNE HPOUT2 ; NO-NEED MORE TIME
959 001750 005067 000020 CLR INTCNT ; YES RESET COUNTER
960 001754 056777 000016 176306 BIS DELAY,@HRCR ; SET READER INT ENABLE
961 001762 105267 000004 HPOUT2: INCB DATA4 ; INCREMENT DATA
962 001766 001744 BEQ HPOUT ; AT UPPER LIMIT START OVER
963 001770 000746 BR HPOUT1 ; FINISH REST OF DATA
964
965 001772 000000 DATA4: XX
966 001774 000000 INTCNT: 0
967 001776 000000 DELAY: 0 ; EQUAL 100 IF HSR RUNNING
968
969 ;TEST OF LINE CLOCK INTERRUPT FOR 55 SECONDS THEN STALL FOR 5 SECONDS.
970 002000 005037 002116 LK1: CLR @TIME ; CLEAR LINE CLOCK TIMER
971 002004 052777 000100 176266 BIS #100,@LKCSR
972 002012 052737 000100 177776 BIS #100,@STATUS
973 002020 000002 RTI ; RETURN TO MAINLINE
974 002022 105777 176252 LK2: TSTB @LKCSR ; TEST FOR DONE
975 002026 100401 BMI .+4
976 002030 104000 HLT ; FALSE INTERRUPT
  
```

```

977 002032 042777 000200 176240      BIC      #200,2LKCSR
978 002040 005237 002116      LK4:    INC      @TIME      ; ON INTERRUPTS ENTER HERE
979 002044 022737 006344 002116      CMP      #3300.,@TIME  ; A LAPS OF 55 SECONDS
980 002052 103362      BHIS     LK2      ; BRANCH IF TIME LESS THAN 55 SECONDS
981 002054 042777 000100 176216      BIC      #100,2LKCSR
982 002058 042737 000100 177776      BIC      #100,@STATUS  ; LOWER PRIORITY
983 002070 022737 007020 002116      CMP      #3600.,@TIME  ; ONE MINUTE UP
984 002076 001740      BEQ     LK1      ; YES-RESET TIMER
985 002100 105777 176174      TSTB    2LKCSR    ; NO-SKIP ON FLAG TILL IT IS.
986 002104 100375      BPL     -4
987 002106 042777 000200 176164      BIC      #200,2LKCSR  ; CLEARS THE FLAG
988 002114 000751      BR      LK4      ; FOUND FLAG GO INCREMENT COUNTER
989 002116 000000      TIME:    0
990
991      ;LINE PRINTER SHOULD RAISE PROCESSOR PRIORITY TO LEVEL OF LINE PRINTER
992      ;INTERRUPT VECTOR IS 200
993      LP80=LP6+4
994      002160
995 002120 016767 000142 000136      LP1:    MOV      SOLPAT,CURPAT  ; START OF LINE TO CURRENT
996 002126 016777 000132 176150      LP2:    MOV      CURPAT,2LPD8R ; CURRENT PATTERN TO LINE PRINTER
997 002134 105777 176142      TSTB    2LPCSR
998 002140 100405      BMI     LP6
999 002142 000002      RTI
1000 002144 105777 176132      LPINTR: TSTB    2LPCSR      ; RETURN TO MAIN LINE
1001 002150 100401      BMI     .+4      ; TEST FOR FLAG
1002 002152 104000      HLT
1003 002154 026727 000110 000117      LP6:    CMP      CLINCT,#79.  ; FALSE RETURN FROM MAIN LINE
1004      ; TEST FOR END OF LINE
1005 002162 001415      BEQ     LP4      ; CHANGE THIS VALUE FOR 132 COLUMN PRINTER
1006 002164 005267 000100      INC     CLINCT    ; GO GENERATE CR/LF
1007 002170 026727 000070 000137      CMP     CURPAT,#137 ; INCREMENT LINE POSITION COUNT
1008 002176 001403      BEQ     LP3      ; TEST FOR MAXIMUM PATTERN
1009 002200 005267 000060      INC     CURPAT    ; YES - GO TO LP3 AND RESET
1010 002204 000750      BR      LP2      ; NO - INCREMENT TO NEXT PATTERN
1011 002206 012767 000040 000050      LP3:    MOV      #40,CURPAT  ; GO SEND IT TO LINE PRINTER
1012 002214 000744      BR      LP2      ; RESET PATTERN AND SEND TO PRINTER
1013 002216 005067 000046      LP4:    CLR     CLINCT    ; SENT TO LINE PRINTER
1014 002222 012777 000012 176054      MOV     #12,2LPD8R ; RESET LINE COUNT
1015 002230 105777 176046      TSTB    2LPCSR    ; LINE FEED
1016 002234 100375      BPL     -4
1017 002236 026727 000024 000137      CMP     SOLPAT,#137 ; START OF LINE PATTERN
1018 002244 001403      BEQ     LP5
1019 002246 005267 000014      INC     SOLPAT    ; INCREMENT START OF LINE
1020 002252 000722      BR      LP1
1021 002254 012767 000040 000004      LP5:    MOV      #40,SOLPAT  ; RESET START OF LINE
1022 002262 000716      BR      LP1      ; PRINT
1023 002264 000000      CURPAT: 0      ; CURRENT CHARACTER BEING PRINTED
1024 002266 000000      SOLPAT: 0      ; START OF LINE CHARACTER
1025 002270 000000      CLINCT: 0      ; POSITION OF LINE
1026
1027      ;RK11 DISK TEST INTERRUPT LEVEL 5. 2000 WORD TRANSFERS
1028 002272 005077 176040      RKSTART: CLR     2RKDAE    ; INITIALIZE DISK - DAR-DAE
1029 002276 016777 000360 176036      RK1:   MOV     LLIMIT,2RKBAR ; CORE BASE
1030 002304 012777 176000 176026      MOV     #RKWORDCT,2RKWC  ; LENGTH OF TRANSFER
1031 002312 113777 002364 176024      MOV     2RKFUNCTION,2RKCSR ; WRITE OR WRITE CHECK TO DISK
1032 002320 000002      RTI      ; RETURN TO MAINLINE CODE

```

```

1033 002322 032777 100200 176014 IRK: BIT #100200, @RKCSR ; INTERRUPT VECTOR POINTS HERE
1034 002330 003002 BGT .+6
1035 002332 104000 HLT ; RK-11 ERROR FLAG UP OR READY NOT UP
1036 002334 000756 BR RKSTART
1037 002336 032777 000037 175772 BIT #37, @RKDAE ; DISK AT UPPER LIMIT?
1038 002344 001354 BNE RK1 ; NO
1039 002346 122777 000031 175760 CMPB #31, @RKDAH
1040 002354 001354 BNE RK1 ; NO
1041 002356 000337 002364 SWAB @@RKFUNCTION ; CHANGE COMMAND
1042 002362 000743 BR RKSTART ; RESTART NEW TRANSFER OF DISK
1043
1044 002364 000000 RKFUNCTION: 0 ; DISK COMMAND
1045 :RP11 DISK SERVICE ROUTINE
1046 002366 112777 000001 176032 RPSTART: MOVB #1, @RPCSR ; INITIALIZE DISK - DAR-DAE
1047 002374 105777 176026 TSTB @RPCSR
1048 002400 100375 BPL .-4
1049 002402 016777 000254 176014 RP1: MOV LLIMIT, @RPBAR ; INITIAL CORE ADDRESS
1050 002410 012777 176000 176004 MOV #@RWORDCT, @RPWC ; LENGTH OF TRANSFER
1051 002416 113777 000432 176002 MOVB @@RPFUNCTION, @RPCSR ; WRITE OR WRITE CHECK TO DISK
1052 002424 000002 RTI ; RETURN TO MAINLINE CODE
1053 002426 032777 100200 175772 IRP: BIT #100200, @RPCSR ; INTERRUPT VECTOR POINTS HERE
1054 002434 003002 BGT .+6
1055 002436 104000 HLT ; RP11 READY NOT UP OR ERROR
1056 002440 000752 BR RPSTART
1057 002442 122777 000312 175740 CMPB #312, @RPCA ; CYLINDER NO. 312, 624 FOR RPC3
1058 002450 001354 BNE RP1 ; NO
1059 002452 000337 000432 SWAB @@RPFUNCTION ; CHANGE COMMAND
1060 002456 000743 BR RPSTART ; RESTART NEW TRANSFER OF DISK
1061 :RC11 DISK SERVICE ROUTINE
1062 002460 012777 000040 175634 RCSTART: MOV #40, @RCOAR ; INITIALIZE DISK - DAR-DAE
1063 002466 016777 000170 175632 RC2: MOV LLIMIT, @RCBAR ; CORE BASE
1064 002474 012777 176040 175622 MOV #@RCWORDCT, @RCWC ; LENGTH OF TRANSFER
1065 002502 113777 002550 175620 MOVB @@RCFUNCTION, @RCCSR ; WRITE OR WRITE CHECK TO DISK
1066 002510 000002 RTI ; RETURN TO MAINLINE CODE
1067 002512 037727 175612 100200 IRC: BIT @RCCSR, #100200 ; INTERRUPT VECTOR POINTS HERE
1068 002520 003002 BGT .+6
1069 002522 104000 HLT ; RC11 READY NOT UP OR ERROR IS JP
1070 002524 000755 BR RCSTART
1071 002526 005277 175570 INC @RCOAR ; TO INCREASE XFER RATE
1072 002532 022777 002000 175562 CMPB #2000, @RCOAR ; DISK AT UPPER LIMIT, 4000=2, 6000=3, 10000=4
1073 002540 001354 BNE RC2 ; NO
1074 002542 000337 002550 SWAB @@RCFUNCTION ; CHANGE COMMAND
1075 002546 000744 BR RCSTART ; RESTART NEW TRANSFER OF DISK
1076 002550 000000 RCFUNCTION: 0 ; DISK COMMAND
1077 :RF11 DISK SERVICE ROUTINE
1078 002552 105277 175542 RFSTART: INCB @RFCSRH ; INITIALIZE DISK - DAR-DAE
1079 002556 062777 000040 175524 ADD #40, @RFDAR ; INCREASE DUTY CYCLE
1080 002564 016777 000072 175522 RF1: MOV LLIMIT, @RFCAR ; CORE BASE
1081 002572 012777 176040 175512 MOV #@RWORDCT, @RFWC ; LENGTH OF TRANSFER
1082 002600 113777 002660 175510 MOVB @@RFFUNCTION, @RFCSR ; WRITE OR WRITE CHECK TO DISK
1083 002606 000002 RTI ; RETURN TO MAINLINE CODE
1084 002610 037727 175502 100200 IRF: BIT @RFCSR, #100200 ; INTERRUPT VECTOR POINTS HERE
1085 002616 003002 BGT .+6
1086 002620 104000 HLT ; RF11 READY NOT UP OR ERROR UP
1087 002622 000753 BR RFSTART
1088 002624 062777 000040 175456 ADD #40, @RFDAR ; INCREASE DUTY CYCLE
    
```

.MAIN. MACY11 30(1046) 16-SEP-77 12:59 PAGE 21
 DZOKBG.P11 16-SEP-77 12:58

SEG 0021

```

1089 002632 122777 000003 175446      CMPB      #3,@RFDAR      ;DISK AT UPPER LIMIT? 7=2, 17=4, 37=8
1090 002640 001351                    @NE      RFI          ;NO
1091 002642 027727 175442 174000      CMP      @RFDAR,#174000 ;AS FAR ON DISK AS WE CAN GO
1092 002650 101745                    BLOS     RFI          ;NO
1093 002652 000337 002660      SWAB     @RFFUNCTION ;CHANGE COMMAND
1094 002656 000735                    BR       RFFSTART    ;RESTART NEW TRANSFER OF DISK
1095 002660 000000      RFFUNCTION: ;DISK COMMAND
1096 002662 004416      LLIMIT: BEGIN ;FIRST CORE ADDRESS OF TRANSFER
1097                    :DT11 DEC TAPE
1098                    RD=4      ;READ DATA
1099                    WD=14     ;WRITE DATA
1100                    RB=2      ;READ BLOCK
1101                    BR=2      ;FORWARD
1102                    F=0       ;INTERRUPT ENABLE AND UNIT - UNIT #1
1103                    IE=500    ;DO - THE FUNCTION
1104                    DO=1      ;REVERSE
1105                    R=4000
1106
1107 002664 000000      TCFIRST: 0      ;FIRST BLOCK TO BE SEARCHED FOR
1108 002666 001101      TCLAST: 577.   ;LAST BLOCK TO BE SEARCHED FOR
1109 002670 000000      TCBLK: 0      ;CURRENT BLOCK FOUND
1110 002672 000000      TCXPE: 0      ;THE BLOCK THAT IS EXPECTED
1111
1112                    :GO TO FORWARD END ZONE
1113 002674 012777 002674 175504      FENDZ: MOV      #FENDZ,@TCIV ;END ZONE VECTOR SETUP
1114 002702 005777 175466                    TST      @TCST      ;TEST FOR END ZONE
1115 002706 100403                    BMI     FEND1      ;AT END ZONE?
1116 002710 105277 175456                    INCB   @TCCM      ;SET DO - NO DELAY
1117 002714 000002                    RTI          ;NO - WAIT SOME MORE
1118 002716 012777 002746 175462      FEND1: MOV      #TCF1,@TCIV ;YES - NEW VECTOR
1119 002724 042777 104000 175440      BIC     #104000,@TCCM ;SEARCH BLOCK FOWARD
1120 002732 016767 177726 177732      MOV     TCFIRST,TCXPE ;COUNT WHEN THIS BLOCK IS FOUND
1121 002740 105277 175426      TCF1A: INCB   @TCCM ;SET DO
1122 002744 000002                    RTI          ;RETURN ON NEXT BLOCK
1123 002746 032777 100200 175416      TCF1:  BIT     #100200,@TCCM ;ANY ERROR ON READ?
1124 002754 003001                    BGT     .+4
1125 002756 104000                    HLT
1126 002760 027767 175412 177704      CMP     @TCDT,TCXPE ;TC ERROR SET - FORWARD READ BLOCK
1127 002766 002764                    BLT    TCF1A      ;IS THIS OUR BLOCK FOR SYNC
1128 002770 001401                    BEQ    TCF2      ;NO-READ SOME MORE BLOCKS
1129 002772 104000                    HLT          ;YES
1130
1131 002774 012777 003010 175404      TCF2:  MOV     #TCF3,@TCIV ;VECTOR FOR SEQUENTIAL READS
1132 003002 105277 175364                    INCB   @TCCM      ;SET DO
1133 003006 000002                    RTI          ;RETURN AND TEST SEQUENTIAL BLOCKS
1134
1135                    :FIND SEQUENTIAL BLOCK AT FOWARD DIRECTION
1136 003010 032777 100200 175354      TCF3:  BIT     #100200,@TCCM ;TEST ERROR AND READY
1137 003016 003001                    BGT     .+4
1138 003020 104000                    HLT
1139 003022 027767 175350 177636      CMP     @TCDT,TCLAST ;FALSE INTERRUPT ON TC-11
1140 003030 001414                    BEQ    RENDZ     ;HAVE WE TESTED ALL BLOCKS
1141 003032 005267 177634                    INC    TCXPE     ;YES DRIVE UNIT IN END ZONE TO START OVER
1142 003036 027767 175334 177626      CMP     @TCDT,TCXPE ;NO-INCREMENT EXPECTED COUNT
1143 003044 001401                    BEQ    .+4      ;IS CURRENT BLOCK CORRECT
1144 003046 104000                    HLT          ;FAILED IN FOWARD READ TO FIND NEXT BLOCK

```

```

1145 003050 000427          BR      TCWBK      ;THIS ROUTINE WRITES A BLOCK
1146 003052 105277 175314  TCF4:  INCB    @TCCM      ;SET DO
1147 003056 000002          RTI
1148 003060 000705          XFENDZ: BR      FENDZ      ;INDIRECT LINK
1149
1150          ;MOVE TAPE TO REVERSE END ZONE
1151 003062 012777 003062 175316  RENDZ:  MOV     @RENDZ,@TCIV  ;END ZONE VECTOR SETUP
1152 003070 016767 177572 177574  MOV     TCLAST,TCEXPE ;SET UP FOR REVERSE SEARCH
1153 003076 005777 175272          TST     @TCST      ;IN END ZONE
1154 003102 100403          BMI     REND1     ;YES - START TO TURN UNIT AROUND
1155 003104 105277 175262          INCB    @TCCM      ;SET DO
1156 003110 000002          RTI      ;NO - WAIT TILL WE ARE
1157 003112 012777 004503 175252  REND1:  MOV     @R+IE+RB+DO,@TCCM ;FUNCTION = READ BLOCK, REVERSE AND GO
1158 003120 012777 003210 175260  MOV     @TCR1,@TCIV ;SET UP NEW INTERRUPT VECTOR
1159 003126 000002          RTI
1160          ;WRITE FORWARD ALL BLOCKS EXCEPT 0
1161
1162 003130 012777 003162 175250  TCWBK:  MOV     @TCWB1,@TCIV  ;INTERRUPT VECTOR FOR WRITE
1163 003136 012777 177400 175236  MOV     #-400,@TCWC   ;ONE BLOCK
1164 003144 012777 003416 175232  MOV     @TCWBUF,@TCBA ;THE WRITE BUFFER ADDRESS
1165 003152 112777 000515 175212  MOV     @IE+WD+DO,@TCCM ;WRITE THE BLOCK
1166 003160 000002          RTI      ;RETURN WHEN BLOCK IS WRITTEN
1167 003162 005777 175204          TCWB1:  TST     @TCCM      ;ANY ERRORS
1168 003166 100001          BPL     .+4
1169 003170 104000          HLT
1170 003172 012777 003010 175206  MOV     @TCF3,@TCIV  ;SEARCH BLOCK VECTOR
1171 003200 112777 000502 175164  MOV     @IE+RB,@TCCM ;READ BLOCK
1172 003206 000721          BR      TCF4      ;FIND THE NEXT BLOCK
1173
1174 003210 032777 100200 175154  TCR1:  BIT     @100200,@TCCM ;TEST FOR ERROR AND READY
1175 003216 003001          BGT     .+4
1176 003220 104000          HLT
1177 003222 027767 175150 177442  CMP     @TCDT,TCEXPE ;DECTAPE ERROR ON READ BLOCK REVERSE
1178 003230 001406          BEQ     TCR2      ;IS IT OUR FIRST BLOCK
1179 003232 002002          BGE     TCR1A     ;YES - GO TEST THE REST
1180 003234 104000          HLT      ;NO - HAVE WE PASSED THE BLOCK
1181 003236 000711          BR      RENDZ     ;WE PASS OUR BLOCK
1182 003240 105277 175126          TCR1A:  INCB    @TCCM      ;GO TO END ZONE AND TRY AGAIN
1183 003244 000002          RTI      ;SET DO
1184 003246 012777 003262 175132  TCR2:  MOV     @TCR3,@TCIV  ;WE FOUND OUR FIRST BLOCK
1185 003254 105277 175112          INCB    @TCCM      ;SET UP INTERRUPT TO TEST ALL BLOCKS
1186 003260 000002          RTI      ;SET DO
1187          ;WAIT FOR NEXT BLOCK TO INTERRUPT
1188          ;FIND SEQUENTIAL BLOCK IN REVERSE DIRECTION
1189 003262 032777 100200 175102  TCR3:  BIT     @100200,@TCCM ;TEST FOR READ AND ERROR
1190 003270 003001          BGT     .+4
1191 003272 104000          HLT      ;ERROR READING SEQUENTIAL BLOCK IN REVERSE

```


1248		000011	Z=N+1	
1249	003456	000011	Z	;DECTAPE READ/WRITE BUFFER
1250	003460	177767	-Z	
1251		000012	Z=N+1	
1252	003462	000012	Z	;DECTAPE READ/WRITE BUFFER
1253	003464	177766	-Z	
1254		000013	Z=N+1	
1255	003466	000013	Z	;DECTAPE READ/WRITE BUFFER
1256	003470	177765	-Z	
1257		000014	Z=N+1	
1258	003472	000014	Z	;DECTAPE READ/WRITE BUFFER
1259	003474	177764	-Z	
1260		000015	Z=N+1	
1261	003476	000015	Z	;DECTAPE READ/WRITE BUFFER
1262	003500	177763	-Z	
1263		000016	Z=N+1	
1264	003502	000016	Z	;DECTAPE READ/WRITE BUFFER
1265	003504	177762	-Z	
1266		000017	Z=N+1	
1267	003506	000017	Z	;DECTAPE READ/WRITE BUFFER
1268	003510	177761	-Z	
1269		000020	Z=N+1	
1270	003512	000020	Z	;DECTAPE READ/WRITE BUFFER
1271	003514	177760	-Z	
1272		000021	Z=N+1	
1273	003516	000021	Z	;DECTAPE READ/WRITE BUFFER
1274	003520	177757	-Z	
1275		000022	Z=N+1	
1276	003522	000022	Z	;DECTAPE READ/WRITE BUFFER
1277	003524	177756	-Z	
1278		000023	Z=N+1	
1279	003526	000023	Z	;DECTAPE READ/WRITE BUFFER
1280	003530	177755	-Z	
1281		000024	Z=N+1	
1282	003532	000024	Z	;DECTAPE READ/WRITE BUFFER
1283	003534	177754	-Z	
1284		000025	Z=N+1	
1285	003536	000025	Z	;DECTAPE READ/WRITE BUFFER
1286	003540	177753	-Z	
1287		000026	Z=N+1	
1288	003542	000026	Z	;DECTAPE READ/WRITE BUFFER
1289	003544	177752	-Z	
1290		000027	Z=N+1	
1291	003546	000027	Z	;DECTAPE READ/WRITE BUFFER
1292	003550	177751	-Z	
1293		000030	Z=N+1	
1294	003552	000030	Z	;DECTAPE READ/WRITE BUFFER
1295	003554	177750	-Z	
1296		000031	Z=N+1	
1297	003556	000031	Z	;DECTAPE READ/WRITE BUFFER
1298	003560	177747	-Z	
1299		000032	Z=N+1	
1300	003562	000032	Z	;DECTAPE READ/WRITE BUFFER
1301	003564	177746	-Z	
1302		000033	Z=N+1	
1303	003566	000033	Z	;DECTAPE READ/WRITE BUFFER

1304	003570	177745	-N	
1305		000034	N=N+1	
1306	003572	000034	-N	; DECTAPE READ/WRITE BUFFER
1307	003574	177744	-N	
1308		000035	N=N+1	
1309	003576	000035	-N	; DECTAPE READ/WRITE BUFFER
1310	003600	177743	-N	
1311		000036	N=N+1	
1312	003602	000036	-N	; DECTAPE READ/WRITE BUFFER
1313	003604	177742	-N	
1314		000037	N=N+1	
1315	003606	000037	-N	; DECTAPE READ/WRITE BUFFER
1316	003610	177741	-N	
1317		000040	N=N+1	
1318	003612	000040	-N	; DECTAPE READ/WRITE BUFFER
1319	003614	177740	-N	
1320		000041	N=N+1	
1321	003616	000041	-N	; DECTAPE READ/WRITE BUFFER
1322	003620	177737	-N	
1323		000042	N=N+1	
1324	003622	000042	-N	; DECTAPE READ/WRITE BUFFER
1325	003624	177736	-N	
1326		000043	N=N+1	
1327	003626	000043	-N	; DECTAPE READ/WRITE BUFFER
1328	003630	177735	-N	
1329		000044	N=N+1	
1330	003632	000044	-N	; DECTAPE READ/WRITE BUFFER
1331	003634	177734	-N	
1332		000045	N=N+1	
1333	003636	000045	-N	; DECTAPE READ/WRITE BUFFER
1334	003640	177733	-N	
1335		000046	N=N+1	
1336	003642	000046	-N	; DECTAPE READ/WRITE BUFFER
1337	003644	177732	-N	
1338		000047	N=N+1	
1339	003646	000047	-N	; DECTAPE READ/WRITE BUFFER
1340	003650	177731	-N	
1341		000050	N=N+1	
1342	003652	000050	-N	; DECTAPE READ/WRITE BUFFER
1343	003654	177730	-N	
1344		000051	N=N+1	
1345	003656	000051	-N	; DECTAPE READ/WRITE BUFFER
1346	003660	177727	-N	
1347		000052	N=N+1	
1348	003662	000052	-N	; DECTAPE READ/WRITE BUFFER
1349	003664	177726	-N	
1350		000053	N=N+1	
1351	003666	000053	-N	; DECTAPE READ/WRITE BUFFER
1352	003670	177725	-N	
1353		000054	N=N+1	
1354	003672	000054	-N	; DECTAPE READ/WRITE BUFFER
1355	003674	177724	-N	
1356		000055	N=N+1	
1357	003676	000055	-N	; DECTAPE READ/WRITE BUFFER
1358	003700	177723	-N	
1359		000056	N=N+1	

1360	003702	000056	-Z	; DECTAPE READ/WRITE BUFFER
1361	003704	177722	-Z	
1362		000057	Z=N+1	
1363	003706	000057	-Z	; DECTAPE READ/WRITE BUFFER
1364	003710	177721	-Z	
1365		000060	Z=N+1	
1366	003712	000060	-Z	; DECTAPE READ/WRITE BUFFER
1367	003714	177720	-Z	
1368		000061	Z=N+1	
1369	003716	000061	-Z	; DECTAPE READ/WRITE BUFFER
1370	003720	177717	-Z	
1371		000062	Z=N+1	
1372	003722	000062	-Z	; DECTAPE READ/WRITE BUFFER
1373	003724	177716	-Z	
1374		000063	Z=N+1	
1375	003726	000063	-Z	; DECTAPE READ/WRITE BUFFER
1376	003730	177715	-Z	
1377		000064	Z=N+1	
1378	003732	000064	-Z	; DECTAPE READ/WRITE BUFFER
1379	003734	177714	-Z	
1380		000065	Z=N+1	
1381	003736	000065	-Z	; DECTAPE READ/WRITE BUFFER
1382	003740	177713	-Z	
1383		000066	Z=N+1	
1384	003742	000066	-Z	; DECTAPE READ/WRITE BUFFER
1385	003744	177712	-Z	
1386		000067	Z=N+1	
1387	003746	000067	-Z	; DECTAPE READ/WRITE BUFFER
1388	003750	177711	-Z	
1389		000070	Z=N+1	
1390	003752	000070	-Z	; DECTAPE READ/WRITE BUFFER
1391	003754	177710	-Z	
1392		000071	Z=N+1	
1393	003756	000071	-Z	; DECTAPE READ/WRITE BUFFER
1394	003760	177707	-Z	
1395		000072	Z=N+1	
1396	003762	000072	-Z	; DECTAPE READ/WRITE BUFFER
1397	003764	177706	-Z	
1398		000073	Z=N+1	
1399	003766	000073	-Z	; DECTAPE READ/WRITE BUFFER
1400	003770	177705	-Z	
1401		000074	Z=N+1	
1402	003772	000074	-Z	; DECTAPE READ/WRITE BUFFER
1403	003774	177704	-Z	
1404		000075	Z=N+1	
1405	003776	000075	-Z	; DECTAPE READ/WRITE BUFFER
1406	004000	177703	-Z	
1407		000076	Z=N+1	
1408	004002	000076	-Z	; DECTAPE READ/WRITE BUFFER
1409	004004	177702	-Z	
1410		000077	Z=N+1	
1411	004006	000077	-Z	; DECTAPE READ/WRITE BUFFER
1412	004010	177701	-Z	
1413		000100	Z=N+1	
1414	004012	000100	-Z	; DECTAPE READ/WRITE BUFFER
1415	004014	177700	-Z	

11		000101	Z	Z	Z	
12		000100	Z	Z	Z	
13			Z	Z	Z	100
14			Z	Z	Z	
15			Z	Z	Z	
16			Z	Z	Z	: DEC TAPE READ/WRITE BUFFER
17			Z	Z	Z	
18			Z	Z	Z	
19			Z	Z	Z	
20	004016	000100	Z	Z	Z	
21	004020	177700	Z	Z	Z	: DEC TAPE READ/WRITE BUFFER
22		000100	Z	Z	Z	
23	004022	000077	Z	Z	Z	
24	004024	177701	Z	Z	Z	: DEC TAPE READ/WRITE BUFFER
25		000077	Z	Z	Z	
26	004026	000077	Z	Z	Z	
27	004030	177702	Z	Z	Z	: DEC TAPE READ/WRITE BUFFER
28		000077	Z	Z	Z	
29	004032	000077	Z	Z	Z	
30	004034	177703	Z	Z	Z	: DEC TAPE READ/WRITE BUFFER
31		000077	Z	Z	Z	
32	004036	000077	Z	Z	Z	
33	004040	177704	Z	Z	Z	: DEC TAPE READ/WRITE BUFFER
34		000074	Z	Z	Z	
35	004042	000073	Z	Z	Z	
36	004044	177705	Z	Z	Z	: DEC TAPE READ/WRITE BUFFER
37		00007	Z	Z	Z	
38	004046	000072	Z	Z	Z	
39	004050	177706	Z	Z	Z	: DEC TAPE READ/WRITE BUFFER
40		000072	Z	Z	Z	
41	004052	000071	Z	Z	Z	
42	004054	177707	Z	Z	Z	: DEC TAPE READ/WRITE BUFFER
43		000071	Z	Z	Z	
44	004056	000070	Z	Z	Z	
45	004060	177710	Z	Z	Z	: DEC TAPE READ/WRITE BUFFER
46		000070	Z	Z	Z	
47	004062	000069	Z	Z	Z	
48	004064	177711	Z	Z	Z	: DEC TAPE READ/WRITE BUFFER
49		000067	Z	Z	Z	
50	004066	000066	Z	Z	Z	
51	004070	177712	Z	Z	Z	: DEC TAPE READ/WRITE BUFFER
52		000066	Z	Z	Z	
53	004072	000065	Z	Z	Z	
54	004074	177713	Z	Z	Z	: DEC TAPE READ/WRITE BUFFER
55		000065	Z	Z	Z	
56	004076	000064	Z	Z	Z	
57	004100	177714	Z	Z	Z	: DEC TAPE READ/WRITE BUFFER
58		000064	Z	Z	Z	
59	004102	000064	Z	Z	Z	
60	004104	177715	Z	Z	Z	: DEC TAPE READ/WRITE BUFFER
61		000063	Z	Z	Z	
62	004106	000063	Z	Z	Z	
63	004110	177716	Z	Z	Z	: DEC TAPE READ/WRITE BUFFER
64		000062	Z	Z	Z	
65	004112	000061	Z	Z	Z	
66	004114	177717	Z	Z	Z	: DEC TAPE READ WRITE BUFFER
67		000061	Z	Z	Z	
68	004116	000060	Z	Z	Z	
69		177720	Z	Z	Z	

1507	004120	000060	Z	:DEC TAPE READ/WRITE BUFFER
1508	004122	000060	Z	:DEC TAPE READ/WRITE BUFFER
1509	004124	000060	Z	:DEC TAPE READ/WRITE BUFFER
1510	004126	000060	Z	:DEC TAPE READ/WRITE BUFFER
1511	004128	000060	Z	:DEC TAPE READ/WRITE BUFFER
1512	004130	000060	Z	:DEC TAPE READ/WRITE BUFFER
1513	004132	000060	Z	:DEC TAPE READ/WRITE BUFFER
1514	004134	000060	Z	:DEC TAPE READ/WRITE BUFFER
1515	004136	000060	Z	:DEC TAPE READ/WRITE BUFFER
1516	004138	000060	Z	:DEC TAPE READ/WRITE BUFFER
1517	004140	000060	Z	:DEC TAPE READ/WRITE BUFFER
1518	004142	000060	Z	:DEC TAPE READ/WRITE BUFFER
1519	004144	000060	Z	:DEC TAPE READ/WRITE BUFFER
1520	004146	000060	Z	:DEC TAPE READ/WRITE BUFFER
1521	004148	000060	Z	:DEC TAPE READ/WRITE BUFFER
1522	004150	000060	Z	:DEC TAPE READ/WRITE BUFFER
1523	004152	000060	Z	:DEC TAPE READ/WRITE BUFFER
1524	004154	000060	Z	:DEC TAPE READ/WRITE BUFFER
1525	004156	000060	Z	:DEC TAPE READ/WRITE BUFFER
1526	004158	000060	Z	:DEC TAPE READ/WRITE BUFFER
1527	004160	000060	Z	:DEC TAPE READ/WRITE BUFFER
1528	004162	000060	Z	:DEC TAPE READ/WRITE BUFFER
1529	004164	000060	Z	:DEC TAPE READ/WRITE BUFFER
1530	004166	000060	Z	:DEC TAPE READ/WRITE BUFFER
1531	004168	000060	Z	:DEC TAPE READ/WRITE BUFFER
1532	004170	000060	Z	:DEC TAPE READ/WRITE BUFFER
1533	004172	000060	Z	:DEC TAPE READ/WRITE BUFFER
1534	004174	000060	Z	:DEC TAPE READ/WRITE BUFFER
1535	004176	000060	Z	:DEC TAPE READ/WRITE BUFFER
1536	004178	000060	Z	:DEC TAPE READ/WRITE BUFFER
1537	004180	000060	Z	:DEC TAPE READ/WRITE BUFFER
1538	004182	000060	Z	:DEC TAPE READ/WRITE BUFFER
1539	004184	000060	Z	:DEC TAPE READ/WRITE BUFFER
1540	004186	000060	Z	:DEC TAPE READ/WRITE BUFFER
1541	004188	000060	Z	:DEC TAPE READ/WRITE BUFFER
1542	004190	000060	Z	:DEC TAPE READ/WRITE BUFFER
1543	004192	000060	Z	:DEC TAPE READ/WRITE BUFFER
1544	004194	000060	Z	:DEC TAPE READ/WRITE BUFFER
1545	004196	000060	Z	:DEC TAPE READ/WRITE BUFFER
1546	004198	000060	Z	:DEC TAPE READ/WRITE BUFFER
1547	004200	000060	Z	:DEC TAPE READ/WRITE BUFFER
1548	004202	000060	Z	:DEC TAPE READ/WRITE BUFFER
1549	004204	000060	Z	:DEC TAPE READ/WRITE BUFFER
1550	004206	000060	Z	:DEC TAPE READ/WRITE BUFFER
1551	004210	000060	Z	:DEC TAPE READ/WRITE BUFFER
1552	004212	000060	Z	:DEC TAPE READ/WRITE BUFFER
1553	004214	000060	Z	:DEC TAPE READ/WRITE BUFFER
1554	004216	000060	Z	:DEC TAPE READ/WRITE BUFFER
1555	004220	000060	Z	:DEC TAPE READ/WRITE BUFFER
1556	004222	000060	Z	:DEC TAPE READ/WRITE BUFFER
1557	004224	000060	Z	:DEC TAPE READ/WRITE BUFFER
1558	004226	000060	Z	:DEC TAPE READ/WRITE BUFFER
1559	004230	000060	Z	:DEC TAPE READ/WRITE BUFFER
1560		000060	Z	:DEC TAPE READ/WRITE BUFFER

1528	004332	177743	Z	
1529	004334	000035	Z	:DEC TAPE READ/WRITE BUFFER
1530		000034	Z	
1531	004336	177744	Z	
1532	004340	000034	Z	:DEC TAPE READ/WRITE BUFFER
1533		000033	Z	
1534	004342	177745	Z	
1535	004346	000033	Z	:DEC TAPE READ/WRITE BUFFER
1536		000032	Z	
1537	004348	177746	Z	
1538	004350	000031	Z	:DEC TAPE READ/WRITE BUFFER
1539		000031	Z	
1540	004352	177747	Z	
1541	004354	000031	Z	:DEC TAPE READ/WRITE BUFFER
1542		000030	Z	
1543	004356	177748	Z	
1544	004360	000030	Z	:DEC TAPE READ/WRITE BUFFER
1545		000029	Z	
1546	004362	177749	Z	
1547	004364	000027	Z	:DEC TAPE READ/WRITE BUFFER
1548		000026	Z	
1549	004366	177750	Z	
1550	004370	000026	Z	:DEC TAPE READ/WRITE BUFFER
1551		000025	Z	
1552	004372	177751	Z	
1553	004374	000025	Z	:DEC TAPE READ/WRITE BUFFER
1554		000024	Z	
1555	004376	177752	Z	
1556	004300	000024	Z	:DEC TAPE READ/WRITE BUFFER
1557		000023	Z	
1558	004302	177753	Z	
1559	004304	000023	Z	:DEC TAPE READ/WRITE BUFFER
1560		000022	Z	
1561	004306	177754	Z	
1562	004310	000022	Z	:DEC TAPE READ/WRITE BUFFER
1563		000021	Z	
1564	004312	177755	Z	
1565	004314	000021	Z	:DEC TAPE READ/WRITE BUFFER
1566		000020	Z	
1567	004316	177756	Z	
1568	004320	000020	Z	:DEC TAPE READ/WRITE BUFFER
1569		000017	Z	
1570	004322	177757	Z	
1571	004324	000017	Z	:DEC TAPE READ/WRITE BUFFER
1572		000016	Z	
1573	004326	177758	Z	
1574	004330	000016	Z	:DEC TAPE READ/WRITE BUFFER
1575		000015	Z	
1576	004332	177759	Z	
1577	004334	000015	Z	:DEC TAPE READ/WRITE BUFFER
1578		000014	Z	
1579	004336	177760	Z	
1580	004340	000014	Z	:DEC TAPE READ WRITE BUFFER
1581		000013	Z	
1582	004342	177761	Z	
1583	004344	000013	Z	:DEC TAPE READ/WRITE BUFFER

```

1599 004346 177762 Z=N-1
1599 004350 000012 Z=N
1599 004352 000011 Z=N-1
1599 004354 177762 Z=N-1
1599 004356 000010 Z=N-1
1599 004360 000010 Z=N-1
1599 004362 000007 Z=N-1
1599 004364 000007 Z=N-1
1599 004366 000006 Z=N-1
1599 004370 000006 Z=N-1
1599 004372 000005 Z=N-1
1600 004374 000005 Z=N-1
1600 004376 000004 Z=N-1
1600 004400 000004 Z=N-1
1600 004402 000003 Z=N-1
1600 004404 000003 Z=N-1
1600 004406 177776 Z=N-1
1610 004410 000002 Z=N-1
1611 004412 000001 Z=N-1
1612 004414 177777 Z=N
1613 004416 000001 Z=N-1
1614
1615 004416 012767 004416 012020 BEGIN: MOV #BEGIN,RETURN ;FOR SCOPING
1616 004424 104400 SCOPE
1617 004426 012737 004000 016440 MOV #4000,#ICOUNT ;ITERATION COUNT
1618 ;TEST COMPARE INSTRUCTION INDEXED
1619 004434 012700 177770 MOV #-10,%0 ;MINUS 10 TO REG 0
1620 004440 026027 016666 125252 CMP A(0),#125252 ;(A INDEX BY MINUS 10) TO #125252
1621 004446 001401 BEQ .+4
1622 004450 104000 HLT ;COMPARE WITH INDEX FAILED
1623 004452 104400 SCOPE
1624
1625 004454 022760 125252 016666 CMP #125252,A(0) ;A INDEXED
1626 004462 001401 BEQ .+4
1627 004464 104000 HLT ;COMPARE FAILED DESTINATION INDEX
1628 004466 104400 SCOPE
1629 ;SET "ISR" FOR DISKS AND KWILL TO CURRENT BANK
1630 004470 010700 MOV %7,%0 ;CURRENT BANK
1631 004472 042700 007777 BIC #007777,%0 ;LEAVE ONLY BANK BITS
1632 004476 062700 002022 ADD #LK3,%0 ;ADD IN CLOCK ENTRANCE
1633 004502 010037 000100 MOV %0,#100 ;LINE CLOCK, KWILL
1634 004506 042700 007777 BIC #007777,%0
1635 004512 062700 002610 ADD #IRF,%0
1636 004516 010037 000204 MOV %0,#204 ;RF11 ISR
1637 004522 042700 007777 BIC #007777,%0
1638 004526 062700 002512 ADD #IRC,%0
1639 004532 010037 000210 MOV %0,#210 ;RC11, ISR

```

1640	004536	042700	007777		BIC	#007777,%0	
1641	004540	062700	002322		AOO	#IRK,%0	
1642	004546	010037	000220		MOV	%0,2#220	:RK11 ISR
1643	004550	042700	007777		BIC	#7777,%0	
1644	004554	063700	002426		AOO	#IRP,%0	
1645	004560	010037	000254		MOV	%0,2#254	:RP11 ISR
1646	004566	042700	007777		BIC	#007777,%0	
1647	004570	063700	002662		AOO	#LLIMIT,%0	
1648	004576	010057	175060		MOV	%0,LLIMIT	:CHANGE DISK NPR BUFFER
1649	004600	042700	007777		BIC	#007777,%0	
1650	004606	062700	016762		AOO	#BUFF,%0	
1651	004612	010006			MOV	%0,%6	:CHANGE STACK TO EXISTING BANK
1652							
1653	004614	012700	000010		MOV	#10,%0	:INDEX
1654	004620	026027	016666	052525	CMP	A(0),#052525	
1655	004626	001401			BEQ	#+4	
1656	004630	104000			HLT		:COMPARE FAILED
1657	004632	104400			SCOPE		
1658							
1659							:REGISTER 0 CONTAINS 000010
1660	004634	022760	052525	016666	CMP	#052525,A(0)	
1661	004642	001401			BEQ	#+4	
1662	004644	104000			HLT		:COMPARE FAILED
1663	004646	104400			SCOPE		
1664							
1665							:REGISTER 0 CONTAINS 000010
1666	004650	026060	016666	016666	CMP	A(0),A(0)	
1667	004656	001401			BEQ	#+4	
1668	004660	104000			HLT		:COMPARE FAILED
1669	004662	104400			SCOPE		
1670							
1671	004664	012700	177770		MOV	#-10,%0	
1672	004670	026060	016666	016666	CMP	A(0),A(0)	
1673	004676	001401			BEQ	#+4	
1674	004700	104000			HLT		:COMPARE FAILED
1675	004702	104400			SCOPE		
1676							
1677							:REGISTER 0 CONTAINS 177770 (-10)
1678	004704	012701	000004		MOV	#+4,%1	
1679	004710	026061	016666	016666	CMP	A(0),A(1)	
1680	004716	001401			BEQ	#+4	
1681	004720	104000			HLT		:COMPARE FAILED
1682	004722	104400			SCOPE		
1683							
1684	004724	026160	016666	016666	CMP	A(1),A(0)	
1685	004732	001401			BEQ	#+4	
1686	004734	104000			HLT		:COMPARE FAILED
1687	004736	104400			SCOPE		
1688							
1689	004740	012700	177774		MOV	#-4,%0	
1690	004744	012701	000010		MOV	#+10,%1	
1691	004750	026061	016666	016666	CMP	A(0),A(1)	
1692	004756	001401			BEQ	#+4	
1693	004760	104000			HLT		:CMP FAILED
1694	004762	104400			SCOPE		
1695							:REGISTER 0 CONTAINS 177774 -4

:REGISTER 1 CONTAINS 000010

```

1696
1697 004764 026160 016666 016666
1698 004772 001401
1699 004774 104000
1700 004776 104400
1701
1702
1703 005000 116700 011677
1704 005004 022700 000035
1705 005010 001401
1706 005012 104000
1707 005014 104400
1708
1709
1710 005016 012700 177770
1711 005022 016067 016666 011660
1712 005030 026727 011654 125252
1713 005036 001401
1714 005040 104000
1715 005042 104400
1716
1717 005044 012700 000010
1718 005050 016067 016666 011632
1719 005056 026727 011626 052525
1720 005064 001401
1721 005066 104000
1722 005070 104400
1723
1724 005072 012700 177770
1725 005076 012760 125252 016710
1726 005104 023727 016700 125252
1727 005112 001401
1728 005114 104000
1729 005116 104400
1730
1731 005120 012700 000010
1732 005124 012760 052525 016710
1733 005132 023727 016720 052525
1734 005140 001401
1735 005142 104000
1736 005144 104400
1737
1738
1739 005146 012767 177777 011534
1740 005154 012700 177770
1741 005160 046067 016666 011522
1742 005166 026727 011516 052525
1743 005174 001401
1744 005176 104000
1745 005200 104400
1746
1747 005202 012767 177777 011500
1748 005210 012700 000010
1749 005214 046067 016666 011466
1750 005222 026727 011462 125252
1751 005230 001401

```

```

CMP      A(1),A(0)
BEQ      .+4
HLT
SCOPE
:TEST MOVE 000 BYTE TO REGISTER
:PROBLEM 1150237-7-MAR-72
MOV      C+3,%0
CMP      #35,%0
BEQ      .+4
HLT
SCOPE
:TEST MOVE INSTRUCTION FOR INDEX
MOV      #-10,%0
MOV      A(0),TEMP
CMP      TEMP,#125252
BEQ      .+4
HLT
SCOPE
:COMPARE FAILED
MOV      #+10,%0
MOV      A(0),TEMP
CMP      TEMP,#052525
BEQ      .+4
HLT
SCOPE
:MOV FAILED
MOV      #-10,%0
MOV      #125252,TEMP(0)
CMP      #0,C,#125252
BEQ      .+4
HLT
SCOPE
:MOV FAILED
MOV      #+10,%0
MOV      #052525,TEMP(0)
CMP      #TEMP+10,#052525
BEQ      .+4
HLT
SCOPE
:MOV FAILED
MOV      #-1,TEMP
MOV      #-10,%0
BIC      A(0),TEMP
CMP      TEMP,#052525
BEQ      .+4
HLT
SCOPE
:TEST BIC INSTRUCTION FOR INDEXING
MOV      #-1,TEMP
MOV      #-10,%0
BIC      A(0),TEMP
CMP      TEMP,#052525
BEQ      .+4
HLT
SCOPE
:COMPARE FAILED
MOV      #-1,TEMP
MOV      #10,%0
BIC      A(0),TEMP
CMP      TEMP,#125252
BEQ      .+4

```

:COMPARE FAILED

:COMPARE FAILED

:MOV FAILED

:MOV FAILED

:MOV FAILED

:BIC FAILED

```

1752 005232 104000 HLT :BIC FAILED
1753 005234 104400 SCOPE
1754
1755 005236 012737 177777 016720 MOV #-1,2#TEMP+10
1756 005244 012700 000010 MOV #10,%0
1757 005250 042760 125252 016710 BIC #125252,TEMP(0)
1758 005256 023727 016720 052525 CMP #TEMP+10,#52525
1759 005264 001401 BEQ .+4
1760 005266 104000 HLT :BIC FAILED
1761 005270 104400 SCOPE
1762
1763 005272 012700 177770 MOV #-10,%0
1764 005276 012767 177777 011374 MOV #-1,TEMP-10
1765 005304 042767 052525 011366 BIC #052525,TEMP-10
1766 005312 026727 011362 125252 CMP TEMP-10,#125252
1767 005320 001401 BEQ .+4
1768 005322 104000 HLT :BIC FAILED
1769 005324 104400 SCOPE
1770 :TEST SUBTRACT INSTRUCTION FOR INDEXING
1771 005326 012767 125252 011354 MOV #125252,TEMP
1772 005334 012700 177770 MOV #-10,%0
1773 005340 166067 016666 011342 SUB A(0),TEMP
1774 005346 001401 BEQ .+4
1775 005350 104000 HLT :SUB FAILED
1776 005352 104400 SCOPE
1777
1778 005354 012737 125252 016710 MOV #125252,2#TEMP
1779 005362 012700 177770 MOV #-10,%0
1780 005366 166760 011264 016720 SUB B,TEMP+10(0)
1781 005374 001401 BEQ .+4
1782 005376 104000 HLT :SUB FAILED
1783 005400 104400 SCOPE
1784
1785 005402 012767 052525 011300 MOV #052525,TEMP
1786 005410 012700 000010 MOV #10,%0
1787 005414 166067 016666 011266 SUB A(0),TEMP
1788 005422 001401 BEQ .+4
1789 005424 104000 HLT :SUB FAILED
1790 005426 104400 SCOPE
1791
1792 005430 012737 052525 016710 MOV #052525,2#TEMP
1793 005436 012700 000010 MOV #10,%0
1794 005442 166760 011230 016700 SUB A+10,C(0)
1795 005450 001401 BEQ .+4
1796 005452 104000 HLT :SUB FAILED
1797 005454 104400 SCOPE
1798
1799 :TEST UNARYS INDEXED
1800 005456 012737 177777 016710 MOV #-1,2#TEMP
1801 005464 012700 177770 MOV #-10,%0
1802 005470 005060 016720 CLR 0(0)
1803 005474 005737 016710 TST 2#TEMP
1804 005500 001401 BEQ .+4
1805 005502 104000 HLT :CLR FAILED
1806 005504 104400 SCOPE
1807
  
```

1808	005506	012737	177777	016710	MOV	#-1,@TEMP	
1809	005514	012700	000010		MOV	#+10,%0	
1810	005520	005060	016700		CLR	C(0)	
1811	005524	005737	016710		TST	@TEMP	
1812	005530	001401			BEQ	+.4	
1813	005532	104000			HLT		:CLR FAILED
1814	005534	104400			SCOPE		
1815							
1816	005536	012737	177777	016710	MOV	#-1,@TEMP	
1817	005544	012700	177770		MOV	#-10,%0	
1818	005550	005160	016720		COM	D(0)	
1819	005554	005737	016710		TST	@TEMP	
1820	005560	001401			BEQ	+.4	
1821	005562	104000			HLT		:COM FAILED
1822	005564	104400			SCOPE		
1823							
1824	005566	012737	177777	016710	MOV	#-1,@TEMP	
1825	005574	012700	000010		MOV	#10,%0	
1826	005600	005160	016700		COM	C(0)	
1827	005604	005737	016710		TST	@TEMP	
1828	005610	001401			BEQ	+.4	
1829	005612	104000			HLT		:COM FAILED
1830	005614	104400			SCOPE		
1831	005616	012737	177777	016710	MOV	#-1,@TEMP	
1832	005624	012700	177770		MOV	#-10,%0	
1833	005630	005260	016720		INC	D(0)	
1834	005634	005737	016710		TST	@TEMP	
1835	005640	001401			BEQ	+.4	
1836	005642	104000			HLT		:INC FAILED
1837	005644	104400			SCOPE		
1838							
1839	005646	012737	177777	016710	MOV	#-1,@TEMP	
1840	005654	012700	000010		MOV	#+10,%0	
1841	005660	005260	016700		INC	C(0)	
1842	005664	005737	016710		TST	@TEMP	
1843	005670	001401			BEQ	+.4	
1844	005672	104000			HLT		:INC FAILED
1845	005674	104400			SCOPE		
1846							
1847	005676	012737	000001	016710	MOV	#1,@TEMP	
1848	005704	012700	177770		MOV	#-10,%0	
1849	005710	005360	016720		DEC	D(0)	
1850	005714	005737	016710		TST	@TEMP	
1851	005720	001401			BEQ	+.4	
1852	005722	104000			HLT		:DEC FAILED
1853	005724	104400			SCOPE		
1854							
1855	005726	012737	000001	016710	MOV	#1,@TEMP	
1856	005734	012700	000010		MOV	#10,%0	
1857	005740	005360	016700		DEC	C(0)	
1858	005744	005737	016710		TST	@TEMP	
1859	005750	001401			BEQ	+.4	
1860	005752	104000			HLT		:DEC FAILED
1861	005754	104400			SCOPE		
1862							
1863	005756	012737	000001	016710	MOV	#1,@TEMP	

1864	005764	012700	177770		MOV	#-10,%0	
1865	005770	005460	016720		NEG	D(0)	
1866	005774	022737	177777	016710	CMP	#-1,@TEMP	
1867	006002	001401			BEQ	+.4	
1868	006004	104000			HLT		:NEG FAILED
1869	006006	104400			SCOPE		
1870							
1871	006010	012737	000001	016710	MOV	#1,@TEMP	
1872	006016	012700	000010		MOV	#+10,%0	
1873	006022	005460	016700		NEG	C(0)	
1874	006026	022737	177777	016710	CMP	#-1,@TEMP	
1875	006034	001401			BEQ	+.4	
1876	006036	104000			HLT		:NEG FAILED
1877	006040	104400			SCOPE		
1878							
1879	006042	012737	177777	016710	MOV	#-1,@TEMP	
1880	006050	012700	177770		MOV	#-10,%0	
1881	006054	000261			SEC		
1882	006056	005560	016720		ADC	D(0)	
1883	006062	005737	016710		TST	@TEMP	
1884	006066	001401			BEQ	+.4	
1885	006070	104000			HLT		:ADC FAILED
1886	006072	104400			SCOPE		
1887							
1888	006074	012737	177777	016710	MOV	#-1,@TEMP	
1889	006102	012700	000010		MOV	#+10,%0	
1890	006106	000261			SEC		
1891	006110	005560	016700		ADC	C(0)	
1892	006114	005737	016710		TST	@TEMP	
1893	006120	001401			BEQ	+.4	
1894	006122	104000			HLT		:ADC FAILED
1895	006124	104400			SCOPE		
1896							
1897	006126	012737	000001	016710	MOV	#1,@TEMP	
1898	006134	012700	177770		MOV	#-10,%0	
1899	006140	000261			SEC		
1900	006142	005660	016720		SBC	D(0)	
1901	006146	005737	016710		TST	@TEMP	
1902	006152	001401			BEQ	+.4	
1903	006154	104000			HLT		:SBC FAILED
1904	006156	104400			SCOPE		
1905							
1906	006160	012737	000001	016710	MOV	#1,@TEMP	
1907	006166	012700	000010		MOV	#+10,%0	
1908	006172	000261			SEC		
1909	006174	005660	016700		SBC	C(0)	
1910	006200	005737	016710		TST	@TEMP	
1911	006204	001401			BEQ	+.4	
1912	006206	104000			HLT		:SBC FAILED
1913	006210	104400			SCOPE		
1914							
1915							
1916	006212	010700					:TEST JMP INDIRECT
1917	006214	062700	000010		MOV	%7,%0	
1918	006220	000110			ADD	#10,%0	
1919	006222	104000			JMP	%0	
					HLT		:JMP FAILED

```

1920 006224 000240      NOP
1921 006226 104400      SCOPE
1922
1923 006230 010600      MOV      %6,%0
1924 006232 010001      MOV      %0,%1
1925 006234 010102      MOV      %1,%2
1926 006236 010203      MOV      %2,%3
1927 006240 010304      MOV      %3,%4
1928 006242 010405      MOV      %4,%5
1929 006244 020605      CMP      %6,%5
1930 006246 001401      BEQ      .+4
1931 006250 104000      HLT
1932 006252 104400      SCOPE      ;MOV REGISTOR FAILED
1933
1934      ;TEST INDIRECT ADDRESSING
1935      ;TEST COMPARE INSTRUCTION
1935 006254 023727 016656 125252      CMP      2#B,#125252
1936 006262 001401      BEQ      .+4
1937 006264 104000      HLT      ;CMP FAILED
1938 006266 104400      SCOPE
1939
1940 006270 022737 125252 016656      CMP      #125252,2#B
1941 006276 001401      BEQ      .+4
1942 006300 104000      HLT      ;CMP FAILED
1943 006302 104400      SCOPE
1944
1945 006304 023737 016656 016656      CMP      2#B,2#B
1946 006312 001401      BEQ      .+4
1947 006314 104000      HLT      ;CMP FAILED
1948 006316 104400      SCOPE
1949
1950      ;TEST MOVE INSTRUCTIONS
1951 006320 013700 016656      MOV      2#B,%0
1952 006324 022700 125252      CMP      #125252,%0

```

1953	006330	001401			BEQ	.+4	
1954	006332	104000			HLT		;MOV FAILED
1955	006334	104400			SCOPE		
1956							
1957	006336	012737	125252	016710	MOV	#125252, @TEMP	
1958	006344	023737	016656	016710	CMP	@B, @TEMP	
1959	006352	001401			BEQ	.+4	
1960	006354	104000			HLT		;MOV FAILED
1961	006356	104400			SCOPE		
1962							
1963	006360	013737	016656	016700	MOV	@B, @C	
1964	006366	023737	016656	016700	CMP	@B, @C	
1965	006374	001401			BEQ	.+4	
1966	006376	104000			HLT		;MOV FAILED
1967	006400	104400			SCOPE		
1968							
1969	006402	012700	177777		;TEST BIC INSTRUCTION INDIRECT		
1970	006406	043700	016656		MOV	#-1, %0	
1971	006412	020027	052525		BIC	@B, %0	
1972	006416	001401			CMP	%0, #052525	
1973	006420	104000			BEQ	.+4	
1974	006422	104400			HLT		;BIC FAILED
1975					SCOPE		
1976	006424	012737	177777	016710	MOV	#-1, @TEMP	
1977	006432	042737	125252	016710	BIC	#125252, @TEMP	
1978	006440	022737	052525	016710	CMP	#052525, @TEMP	
1979	006446	001401			BEQ	.+4	
1980	006450	104000			HLT		;BIC FAILED
1981	006452	104400			SCOPE		
1982							
1983	006454	012737	177777	016700	MOV	#-1, @C	
1984	006462	043737	016656	016700	BIC	@B, @C	
1985	006470	023727	016700	052525	CMP	@C, #52525	
1986	006476	001401			BEQ	.+4	
1987	006500	104000			HLT		;BIC FAILED
1988	006502	104400			SCOPE		
1989							
1990							
1991	006504	012700	125252		;TEST SUBTRACT INSTRUCTION		
1992	006510	163700	016656		MOV	#125252, %0	
1993	006514	020027	000000		SUB	@B, %0	
1994	006520	001401			CMP	%0, #0	
1995	006522	104000			BEQ	.+4	
1996	006524	104400			HLT		;SUB FAILED
1997					SCOPE		
1998	006526	012737	125252	016710	MOV	#125252, @TEMP	
1999	006534	166737	010116	016710	SUB	B, @TEMP	
2000	006542	001401			BEQ	.+4	
2001	006544	104000			HLT		;SUB FAILED
2002	006546	104400			SCOPE		
2003							
2004	006550	012767	125252	010132	MOV	#125252, TEMP	
2005	006556	163767	016656	010124	SUB	@B, TEMP	
2006	006564	005767	010120		TST	TEMP	
2007	006570	001401			BEQ	.+4	
2008	006572	104000			HLT		;SUB FAILED

```

2009 006574 104400          SCOPE
2010          ;TEST UNARYS INDIRECT
2011 006576 012737 177777 016710  MOV    #-1,@#TEMP
2012 006604 005037 016710  CLR    @#TEMP
2013 006610 005737 016710  TST   @#TEMP
2014 006614 001401          BEQ    .+4
2015 006616 104000          HLT
2016 006620 104400          SCOPE          ;TST FAILED
2017
2018 006622 012737 125252 016710  MOV    #125252,@#TEMP
2019 006630 005137 016710  COM   @#TEMP
2020 006634 022737 052525 016710  CMP    #052525,@#TEMP
2021 006642 001401          BEQ    .+4
2022 006644 104000          HLT
2023 006646 104400          SCOPE          ;COM FAILED
2024
2025 006650 005037 016710  CLR    @#TEMP
2026 006654 005237 016710  INC    @#TEMP
2027 006660 022737 000001 016710  CMP    #1,@#TEMP
2028 006666 001401          BEQ    .+4
2029 006670 104000          HLT
2030 006672 104400          SCOPE          ;INC FAILED
2031
2032 006674 005037 016710  CLR    @#TEMP
2033 006700 005377 010006  DEC    @#TEMP+2
2034 006704 023727 016710 177777  CMP    @#TEMP,#-1
2035 006712 001401          BEQ    .+4
2036 006714 104000          HLT
2037 006716 104400          SCOPE          ;DEC FAILED
2038
2039 006720 012737 000001 016710  MOV    #1,@#TEMP
2040 006726 005437 016710  NEG   @#TEMP
2041 006732 022737 177777 016710  CMP    #-1,@#TEMP
2042 006740 001401          BEQ    .+4
2043 006742 104000          HLT
2044 006744 104400          SCOPE          ;NEG FAILED
2045
2046          ;TEST INDIRECT ADDRESSING WITH INDEXING
2047          ;TEST COMPARE INSTRUCTION
2048 006746 027727 007706 125252  CMP    @B+2,#125252
2049 006754 001401          BEQ    .+4
2050 006756 104000          HLT
2051 006760 104400          SCOPE          ;CMP FAILED
2052
2053 006762 022777 125252 007670  CMP    #125252,@B+2
2054 006770 001401          BEQ    .+4
2055 006772 104000          HLT
2056 006774 104400          SCOPE          ;CMP FAILED
2057
2058 006776 027777 007656 007654  CMP    @B+2,@B+2
2059 007004 001401          BEQ    .+4
2060 007006 104000          HLT
2061 007010 104400          SCOPE          ;CMP FAILED
2062
2063          ;TEST MOVE INSTRUCTIONS
2064 007012 017700 007642  MOV    @B+2,%0

```

2065	007016	022700	125252		CMP	#125252,%0	
2066	007022	001401			BEQ	.+4	
2067	007024	104000			HLT		;MOV FAILED
2068	007026	104400			SCOPE		
2069							
2070	007030	012777	125252	007654	MOV	#125252,@TEMP+2	
2071	007036	023737	016656	016710	CMP	@B,@TEMP	
2072	007044	001401			BEQ	.+4	
2073	007046	104000			HLT		;MOV FAILED
2074	007050	104400			SCOPE		
2075							
2076	007052	017777	007602	007622	MOV	@B+2,@C+2	
2077	007060	023737	016656	016700	CMP	@B,@C	
2078	007066	001401			BEQ	.+4	
2079	007070	104000			HLT		
2080	007072	104400			SCOPE		
2081							
2082							
2083	007074	012700	177777		MOV	#-1,%0	
2084	007100	047700	007554		BIC	@B+2,%0	
2085	007104	020027	052525		CMP	%0,#52525	
2086	007110	001401			BEQ	.+4	
2087	007112	104000			HLT		;BIC FAILED
2088	007114	104400			SCOPE		
2089							
2090	007116	012737	177777	016710	MOV	#-1,@TEMP	
2091	007124	042777	125252	007560	BIC	#125252,@TEMP+2	
2092	007132	022737	052525	016710	CMP	#52525,@TEMP	
2093	007140	001401			BEQ	.+4	
2094	007142	104000			HLT		;BIC FAILED
2095	007144	104400			SCOPE		
2096							
2097	007146	012737	177777	016700	MOV	#-1,@C	
2098	007154	047777	007500	007520	BIC	@B+2,@C+2	
2099	007162	026737	007510	016700	CMP	A+10,@C	
2100	007170	001401			BEQ	.+4	
2101	007172	104000			HLT		;BIC FAILED
2102	007174	104400			SCOPE		
2103							
2104	007176	012700	125252		MOV	#125252,%0	
2105	007202	167700	007452		SUB	@B+2,%0	
2106	007206	020027	000000		CMP	%0,#0	
2107	007212	001401			BEQ	.+4	
2108	007214	104000			HLT		;SUB FAILED
2109	007216	104400			SCOPE		
2110							
2111	007220	012737	125252	016710	MOV	#125252,@TEMP	
2112	007226	166777	007424	007456	SUB	B,@TEMP+2	
2113	007234	001401			BEQ	.+4	
2114	007236	104000			HLT		;SUB FAILED
2115	007240	104400			SCOPE		
2116							
2117	007242	012737	125252	016710	MOV	#125252,@TEMP	
2118	007250	167777	007404	007434	SUB	@B+2,@TEMP+2	
2119	007256	005737	016710		TST	@TEMP	
2120	007262	001401			BEQ	.+4	

;TEST BIC INSTRUCTION INDIRECT WITH INDEXING


```

007264 104000          HLT          :SUB FAILED
007266 104400          SCOPE

:TEST ADD INDIRECT WITH INDEXING
007270 005000          CLR          @0
007272 005777          ADD          @0+2,@0
007274 125252          CTR          @125252,@0
007276 001401          BEQ          .+4
007278 104000          HLT          :ADD FAILED
007280 104400          SCOPE

007282 005037          CLR          @TEMP
007284 005277          ADD          @125252,@TEMP+2
007286 125252          CTR          @125252,@TEMP
007288 001401          BEQ          .+4
007290 104000          HLT          :ADD FAILED
007292 104400          SCOPE

007294 012737          MOV          @125252,@TEMP
007296 005477          ADD          @A+6,@TEMP+2
007298 023727          CTR          @TEMP,@-1
007300 001401          BEQ          .+4
007302 104000          HLT          :ADD FAILED
007304 104400          SCOPE

:TEST UNARYS INDIRECT WITH INDEXING
007306 012737          MOV          @-1,@TEMP
007308 005477          CLR          @TEMP+2
007310 016710          TST          @TEMP
007312 001401          BEQ          .+4
007314 104000          HLT          :TST FAILED
007316 104400          SCOPE

007318 012737          MOV          @125252,@TEMP
007320 005477          COM          @TEMP+2
007322 022737          CTR          @052525,@TEMP
007324 001401          BEQ          .+4
007326 104000          HLT          :COM FAILED
007328 104400          SCOPE

007330 005037          CLR          @TEMP
007332 005277          INC          @TEMP+2
007334 022737          CTR          @1,@TEMP
007336 001401          BEQ          .+4
007338 104000          HLT          :INC FAILED
007340 104400          SCOPE

007342 005037          CLR          @TEMP
007344 005377          DEC          @TEMP+2
007346 023727          CTR          @TEMP,@-1
007348 001401          BEQ          .+4
007350 104000          HLT          :DEC FAILED
007352 104400          SCOPE

007354 012737          MOV          @1,@TEMP
007356 005477          NEG          @TEMP+2
007358 022737          CMP          @-1,@TEMP
007360 177777          HLT          :DEC FAILED
007362 104400          SCOPE

```

```

007530 001401 BEQ .+4
007532 104000 HLT ;NEG FAILED
007534 104400 SCOPE

007536 012737 177777 016710 MOV #1, @TEMP
007538 000261 SFC
007540 005577 007140 RDC #TEMP+2
007542 005737 016710 TST @TEMP
007544 001401 BEQ .+4
007546 104000 HLT ;ADC FAILED
007548 104400 SCOPE

007554 012737 000001 016710 MOV #1, @TEMP
007556 000261 SFC
007558 005577 007112 RDC #TEMP+2
007560 005737 016710 TST @TEMP
007562 001401 BEQ .+4
007564 104000 HLT ;SBC FAILED
007566 104400 SCOPE

:TEST OF COMBINED INDEXING AND INDIRECT
007612 012700 177772 MOV #6, %0
007614 027027 016666 125252 CMP @A(0), #125252
007616 001401 BEQ .+4
007618 104000 HLT ;CMP FAILED
007620 104400 SCOPE

007632 012700 177772 MOV #6, %0
007634 022770 125252 016666 CMP #125252, @A(0)
007636 001401 BEQ .+4
007638 104000 HLT ;CMP FAILED
007640 104400 SCOPE

007652 012700 177772 MOV #6, %0
007654 012701 000002 MOV #2, %1
007656 027071 016666 016666 CMP @A(0), @A(1)
007658 001401 BEQ .+4
007660 104000 HLT ;CMP FAILED
007662 104400 SCOPE

:TEST BIC INSTRUCTION
007676 012700 000006 MOV #6, %0
007702 012767 177777 007000 MOV #1, TEMP
007710 047067 016666 006772 BIC @A(0), TEMP
007716 022767 125252 006764 CMP #125252, TEMP
007724 001401 BEQ .+4
007726 104000 HLT ;BIC FAILED
007730 104400 SCOPE

007732 012700 177772 MOV #6, %0
007736 012737 177777 016700 MOV #1, @BC
007744 042770 125252 016710 BIC #125252, @TEMP(0)
007752 023727 016700 052525 CMP @BC, #052525
007760 001401 BEQ .+4
007762 104000 HLT ;BIC FAILED
007764 104400 SCOPE

```

```

22770 007766 012737 177777 016700 MOV      #-1,%0
22771 007774 012700 177777 MOV      #-6,%0
22772 010000 012701 177777 MOV      #-6,%1
22773 010000 012701 016666 BIC      2A(0),TEMP(1)
22774 010000 022737 052525 CMP      #052525,%0
22775 010000 001401 BEQ      .+4
22776 010000 104000 HLT
22777 010000 104400 SCOPE
                                     :BIC FAILED
22778 010026 122727 000000 000001 CMPB     #0,%1          ;T7 FIX
22779 010037 002401 BLT      .+4
22780 010036 104000 HLT
22781 010040 104400 SCOPE          ;CMPB FAILED
                                     :TEST COMPARE INSTRUCTION INDEXED
22782 010042 012700 177770 MOV      #-10,%0          ;MINUS 10 TO REG 0
22783 010046 126027 016666 000252 CMPB     A(0),#000252  ;(A INDEX BY MINUS 10) TO #125252
22784 010054 001401 BEQ      .+4
22785 010056 104000 HLT
22786 010060 104400 SCOPE          ;COMPARE WITH INDEX FAILED
22787 010062 012700 177770 MOV      #-10,%0          ;FOR INDEX
22788 010066 122760 000252 016666 CMPB     #000252,A(0)  ;A INDEXED
22789 010074 001401 BEQ      .+4
22790 010076 104000 HLT
22791 010100 104400 SCOPE          ;CMPB FAILED
22792 010102 012700 000010 MOV      #10,%0          ;INDEX
22793 010106 126027 016666 000125 CMPB     A(0),#000125
22794 010114 001401 BEQ      .+4
22795 010116 104000 HLT
22796 010120 104400 SCOPE          ;CMPB FAILED
22797 010122 012700 000010 MOV      #10,%0
22798 010126 122760 000125 016666 CMPB     #000125,A(0)
22799 010134 001401 BEQ      .+4
22800 010136 104000 HLT
22801 010140 104400 SCOPE          ;CMPB FAILED
22802 010142 012700 177770 MOV      #-10,%0
22803 010146 126060 016666 016666 CMPB     A(0),A(0)
22804 010154 001401 BEQ      .+4
22805 010156 104000 HLT
22806 010160 104400 SCOPE          ;CMPB FAILED
22807 010162 012700 000010 MOV      #+10,%0
22808 010166 126060 016666 016666 CMPB     A(0),A(0)
22809 010174 001401 BEQ      .+4
22810 010176 104000 HLT
22811 010200 104400 SCOPE          ;CMPB FAILED
22812 010202 012700 177770 MOV      #-10,%0
22813 010206 012701 000004 MOV      #+4,%1
22814 010212 126061 016666 016666 CMPB     A(0),A(1)
22815 010220 001401 BEQ      .+4
22816 010222 104000 HLT
22817 010224 104400 SCOPE          ;CMPB FAILED

```

```

010226 126160 016666 016666      CMPB  A(1),A(0)
010227 001401      BEQ   .+4
010228 104000      HLT
010229 104400      SCOPE      ;CMPB FAILED

010230 012700 177774      MOV   #-4,%0
010231 012701 000010      MOV   #-10,%1
010232 126061 016666 016666      CMPB  A(0),A(1)
010233 001401      BEQ   .+4
010234 104000      HLT
010235 104400      SCOPE      ;CMPB FAILED

010236 012700 177774      MOV   #-4,%0
010237 012701 000010      MOV   #-10,%1
010238 126160 016666 016666      CMPB  A(1),A(0)
010239 001401      BEQ   .+4
010240 104000      HLT
010241 104400      SCOPE      ;CMPB FAILED

                                ;TEST MOVE INSTRUCTION FOR INDEX
010312 012700 177770      MOV   #-10,%0
010313 116067 016666 006364      MOVB  A(0),TEMP
010314 126727 006360 000252      CMPB  TEMP,#000252
010315 001401      BEQ   .+4
010316 104000      HLT
010317 104400      SCOPE      ;MOVB FAILED

010318 012700 000010      MOV   #-10,%0
010319 116067 016666 006336      MOVB  A(0),TEMP
010320 126727 006332 000125      CMPB  TEMP,#000125
010321 001401      BEQ   .+4
010322 104000      HLT
010323 104400      SCOPE      ;MOVB FAILED

010324 012700 177770      MOV   #-10,%0
010325 112760 125252 016710      MOVB  #125252,TEMP(0)
010326 123727 016700 125252      CMPB  #0C,#125252
010327 001401      BEQ   .+4
010328 104000      HLT
010329 104400      SCOPE      ;MOVB FAILED

010330 012700 000010      MOV   #-10,%0
010331 112760 052525 016710      MOVB  #052525,TEMP(0)
010332 123727 016720 052525      CMPB  #TEMP+10,#052525
010333 001401      BEQ   .+4
010334 104000      HLT
010335 104400      SCOPE      ;MOVB FAILED

                                ;TEST BIC INSTRUCTION FOR INDEXING
010442 012767 177777 006240      MOV   #-1,TEMP
010443 012700 177770      MOV   #-10,%0
010444 146067 016666 006226      BICB  A(0),TEMP
010445 126727 006222 177525      CMPB  TEMP,#177525
010446 001401      BEQ   .+4
010447 104000      HLT
                                ;BICB FAILED

```

2375	010474	104400			SCOPE	
2376	010476	012767	177777	006204	MOV	#-1,TEMP
2377	010504	012700	000010		MOV	#10,%0
2378	010510	146067	016666	006172	BICB	0(0),TEMP
2379	010516	126727	006166	007652	CMPB	TEMP,#007652
2380	010524	001401			BEG	.+4
2381	010526	104000			HLT	
2382	010530	104400			SCOPE	:BICB FAILED
2383	010532	012737	177777	016720	MOV	#-1,2*TEMP+10
2384	010540	012700	000010		MOV	#10,%0
2385	010544	142760	125252	016710	BICB	#125252,TEMP(0)
2386	010552	123727	016720	002525	CMPB	2*TEMP+10,#2525
2387	010560	001401			BEG	.+4
2388	010562	104000			HLT	
2389	010564	104400			SCOPE	:BICB FAILED
2390	010566	012700	177770		MOV	#-10,%0
2391	010572	012767	177777	006100	MOV	#-1,TEMP-10
2392	010600	142767	052525	006072	BICB	#052525,TEMP-10
2393	010606	126727	006066	125252	CMPB	TEMP-10,#125252
2394	010614	001401			BEG	.+4
2395	010616	104000			HLT	
2396	010620	104400			SCOPE	:BICB FAILED
2397						
2398						
2399						
2400						
2370						
2371						
2372	010622	012737	177777	016710	:TEST UNARYS INDEXED	
2373	010630	012700	177770		MOV	#-1,2*TEMP
2374	010634	105060	016720		MOV	#-10,%0
2375	010640	105737	016710		CLRB	0(0)
2376	010644	001401			TSTB	2*TEMP
2377	010646	104000			BEG	.+4
2378	010650	104400			HLT	
2379					SCOPE	:CLRB FAILED
2380	010652	012737	177777	016710	MOV	#-1,2*TEMP
2381	010660	012700	177770		MOV	#-10,%0
2382	010664	105060	016720		CLRB	0(0)
2383	010670	023727	016710	177400	CMP	2*TEMP,#177400
2384	010676	001401			BEG	.+4
2385	010700	104000			HLT	
2386	010702	104400			SCOPE	:CLRB FAILED
2387						
2388	010704	012737	177777	016710	MOV	#-1,2*TEMP
2389	010712	012700	177771		MOV	#-7,%0
2390	010716	105060	016720		CLRB	0(0)
2391	010722	023727	016710	000377	CMP	2*TEMP,#000377
2392	010730	001401			BEG	.+4
2393	010732	104000			HLT	
2394	010734	104400			SCOPE	:CLRB FAILED
2395						
2396	010736	012737	177777	016710	MOV	#-1,2*TEMP
2397	010744	012700	000010		MOV	#+10,%0
2398	010750	105060	016700		CLRB	0(0)
2399	010754	105737	016710		TSTB	2*TEMP
2400	010760	001401			BEG	.+4

0110762	104000			HLT				:CLRB FAILED
0110764	104400			SCOPE				
0110766	012737	177777	016710	MOV	#-1,@TEMP			
0110770	012700	177770		MOV	#-10,%0			
0111000	105160	016720		COMB	0(0)			
0111000	105737	016710		TSTB	@TEMP			
0111010	001401			BEG	.+4			
0111010	104000			HLT				:COMB FAILED
0111014	104400			SCOPE				
0111016	012737	177777	016710	MOV	#-1,@TEMP			
0111016	012700	000010		MOV	#10,%0			
0111016	105160	016700		COMB	C(0)			
0111016	105737	016710		TSTB	@TEMP			
0111016	001401			BEG	.+4			
0111016	104000			HLT				:COMB FAILED
0111016	104400			SCOPE				
0111016	012737	177777	016710	MOV	#-1,@TEMP			
0111016	012700	177770		MOV	#-10,%0			
0111016	105260	016720		INCB	0(0)			
0111016	105737	016710		TSTB	@TEMP			
0111016	001401			BEG	.+4			
0111016	104000			HLT				:INCB FAILED
0111016	023727	016710	177400	CMF	@TEMP,#177400			
0111016	001401			BEG	.+4			
0111016	104000			HLT				:INCB FAILED
0111016	104400			SCOPE				
0111110	012737	177777	016710	MOV	#-1,@TEMP			
0111110	012700	000010		MOV	#+10,%0			
0111110	105260	016700		INCB	C(0)			
0111110	105737	016710		TSTB	@TEMP			
0111110	001401			BEG	.+4			
0111110	104000			HLT				:INCB FAILED
0111110	104400			SCOPE				
0111140	012737	000001	016710	MOV	#1,@TEMP			
0111140	012700	177770		MOV	#-10,%0			
0111152	105360	016720		DECB	0(0)			
0111156	105737	016710		TSTB	@TEMP			
0111156	001401			BEG	.+4			
0111156	104000			HLT				:DECB FAILED
0111156	104400			SCOPE				
0111170	012737	000001	016710	MOV	#1,@TEMP			
0111176	012700	000010		MOV	#10,%0			
0111202	105360	016700		DECB	C(0)			
0111206	105737	016710		TSTB	@TEMP			
0111212	001401			BEG	.+4			
0111214	104000			HLT				:DECB FAILED
0111216	104400			SCOPE				
0111220	012737	000001	016710	MOV	#1,@TEMP			
0111226	012700	177770		MOV	#-10,%0			
0111232	105460	016720		NEGB	0(0)			

0111236	023727	016710	000377	CMP	@TEMP, #377	
0111240	001401			BEQ	+.4	
0111246	104000			HLT		:NEGB FAILED
0111250	104400			SCOPE		
0111256	012737	000001	016710	MOV	#1, @TEMP	
0111260	012700	000010		MOV	#+10, %0	
0111266	105560	016700		NEGB	C(0)	
0111270	023727	016710	000377	CMP	@TEMP, #377	
0111274	001401			BEQ	+.4	
0111278	104000			HLT		:NEGB FAILED
0111282	104400			SCOPE		
0111304	012737	177777	016710	MOV	#-1, @TEMP	
0111310	012700	177770		MOV	#-10, %0	
0111316	000261			SEC		
0111320	105560	016720		ADCB	D(0)	
0111324	023727	016710	177400	CMP	@TEMP, #177400	
0111328	001401			BEQ	+.4	
0111332	104000			HLT		:ADCB FAILED
0111336	104400			SCOPE		
0111340	012737	177777	016710	MOV	#-1, @TEMP	
0111344	012700	000010		MOV	#+10, %0	
0111348	000261			SEC		
0111352	105560	016700		ADCB	C(0)	
0111356	023727	016710	177400	CMP	@TEMP, #177400	
0111360	001401			BEQ	+.4	
0111364	104000			HLT		:ADCB FAILED
0111368	104400			SCOPE		
0111374	012737	000401	016710	MOV	#401, @TEMP	
0111378	012700	177771		MOV	#-7, %0	
0111382	000261			SEC		
0111386	105560	016720		SBCB	D(0)	
0111390	022737	000001	016710	CMP	#1, @TEMP	
0111394	001401			BEQ	+.4	
0111398	104000			HLT		:SBCB FAILED
0111402	104400			SCOPE		
0111430	012737	000001	016710	MOV	#1, @TEMP	
0111434	012700	000010		MOV	#+10, %0	
0111438	000261			SEC		
0111442	105560	016700		SBCB	C(0)	
0111446	005737	016710		TST	@TEMP	
0111450	001401			BEQ	+.4	
0111454	104000			HLT		:SBCB FAILED
0111458	104400			SCOPE		
0111462	123727	016656	000252	:TEST INDIRECT ADDRESSING		
0111470	001401			:TEST COMPARE INSTRUCTION		
0111474	104000			CMPB	@B, #000252	
0111478	104400			BEQ	+.4	
0111482	104400			HLT		:CMPB FAILED
0111486	104400			SCOPE		

2513	011476	123727	016657	000252	CMPB	2#B+1, #252	
2514	011504	001401			BEQ	.+4	
2515	011506	104000			HLT		:CMPB FAILED
2516	011510	104400			SCOPE		
2517							
2518	011512	122737	125252	016656	CMPB	#125252, 2#B	
2519	011520	001401			BEQ	.+4	
2520	011522	104000			HLT		:CMPB FAILED
2521	011524	104400			SCOPE		
2522							
2523	011526	123737	016656	016656	CMPB	2#B, 2#B	
2524	011534	001401			BEQ	.+4	
2525	011536	104000			HLT		:CMPB FAILED
2526	011540	104400			SCOPE		
2527							
2528							
2529							
2530							
2531	011542	113700	016656		:TEST MOVE INSTRUCTIONS		
2532	011546	122700	000252		MOVB	2#B, %0	
2533	011552	001401			CMPB	#000252, %0	
2534	011554	104000			BEQ	.+4	
2535	011556	104400			HLT		:MOVB FAILED
2536					SCOPE		
2537	011560	112737	125252	016710	MOVB	#125252, 2#TEMP	
2538	011566	126737	005064	016710	CMPB	B, 2#TEMP	
2539	011574	001401			BEQ	.+4	
2540	011576	104000			HLT		:MOVB FAILED
2541	011600	104400			SCOPE		
2542							
2543	011602	113737	016656	016700	MOVB	2#B, 2#C	
2544	011610	126737	005042	016700	CMPB	B, 2#C	
2545	011616	001401			BEQ	.+4	
2546	011620	104000			HLT		:MOVB FAILED
2547	011622	104400			SCOPE		
2548							
2549	011624	012737	177777	016710	:TEST UNARYS INDIRECT		
2550	011632	105037	016710		MOV	#-1, 2#TEMP	
2551	011636	023727	016710	177400	CLRB	2#TEMP	
2552	011644	001401			CMP	2#TEMP, #177400	
2553	011646	104000			BEQ	.+4	
2554	011650	104400			HLT		:CLRB FAILED
2555					SCOPE		
2556	011652	012737	125252	016710	MOV	#125252, 2#TEMP	
2557	011660	105137	016710		COMB	2#TEMP	
2558	011664	022737	125125	016710	CMP	#125125, 2#TEMP	
2559	011672	001401			BEQ	.+4	
2560	011674	104000			HLT		:COMB FAILED
2561	011676	104400			SCOPE		
2562							
2563	011700	012737	125252	016710	MOV	#125252, 2#TEMP	
2564	011706	105137	016711		COMB	2#TEMP+1	
2565	011712	022737	052652	016710	CMP	#052652, 2#TEMP	
2566	011720	001401			BEQ	.+4	
2567	011722	104000			HLT		:COMB FAILED
2568	011724	104400			SCOPE		

2609	011726	005037	016710		CLR	2#TEMP	
2610	011726	105377	016711		INCB	2#TEMP+1	
2611	011736	022737	000400	016710	CMP	400,2#TEMP	
2612	011744	001401			BEQ	+.4	
2613	011746	104000			HLT		:INCB FAILED
2614	011750	104400			SCOPE		
2615	011752	005037	016710		CLR	2#TEMP	
2616	011756	105377	004730		DECB	2#TEMP+2	
2617	011762	023727	016710	000377	CMP	2#TEMP, #377	
2618	011770	001401			BEQ	+.4	
2619	011772	104000			HLT		:DECB FAILED
2620	011774	104400			SCOPE		
2621	011776	005037	016710		CLR	2#TEMP	
2622	012000	112737	000001	016711	MOVB	1,2#TEMP+1	
2623	012010	105437	016711		NEGB	2#TEMP+1	
2624	012014	022737	177400	016710	CMP	177400,2#TEMP	
2625	012022	001401			BEQ	+.4	
2626	012024	104000			HLT		:NEGB FAILED
2627	012026	104400			SCOPE		
2628					:TEST INDIRECT ADDRESSING WITH INDEXING		
2629					:TEST COMPARE INSTRUCTION		
2630	012030	127727	004624	125252	CMPB	2B+2, #125252	
2631	012036	001401			BEQ	+.4	
2632	012040	104000			HLT		:CMPB FAILED
2633	012042	104400			SCOPE		
2634	012044	122777	125252	004606	CMPB	#125252, 2B+2	
2635	012052	001401			BEQ	+.4	
2636	012054	104000			HLT		:CMPB FAILED
2637	012056	104400			SCOPE		
2638	012060	127777	004574	004572	CMPB	2B+2, 2B+2	
2639	012066	001401			BEQ	+.4	
2640	012070	104000			HLT		:CMPB FAILED
2641	012072	104400			SCOPE		
2642					:TEST MOVE INSTRUCTIONS		
2643	012074	117700	004560		MOVB	2B+2,%0	
2644	012100	122700	125252		CMPB	#125252,%0	
2645	012104	001401			BEQ	+.4	
2646	012106	104000			HLT		:MOVB FAILED
2647	012110	104400			SCOPE		
2648	012112	112777	125252	004572	MOVB	#125252, 2#TEMP+2	
2649	012120	126737	004532	016710	CMPB	B, 2#TEMP	
2650	012126	001401			BEQ	+.4	
2651	012130	104000			HLT		:MOVB FAILED
2652	012132	104400			SCOPE		
2653	012134	117777	004520	004540	MOVB	2B+2, 2C+2	
2654	012142	126737	004510	016700	CMPB	B, 2#C	
2655	012150	001401			BEQ	+.4	
2656	012152	104000			HLT		:MOVB FAILED
2657	012154	104400			SCOPE		

```

2625
2626
2627
2628
2629
2630
2631
2632
2633
2634
2635
2636
2637
2638
2639
2640
2641
2642
2643
2644
2645
2646
2647
2648
2649
2650
2651
2652
2653
2654
2655
2656
2657
2658
2659
2660
2661
2662
2663
2664
2665
2666
2667
2668
2669
2670
2671
2672
2673
2674
2675
2676
2677
2678
2679
2680

```

012156	012700	177777		MOV	#-1,%0	
012162	147700	004472		BICB	@B+2,%0	
012166	120027	052525		CMPB	%0,#52525	
012172	001401			BEQ	+.4	
012174	104000			HLT		:BICB FAILED
012176	104400			SCOPE		
012200	012737	177777	016710	MOV	#-1,@TEMP	
012206	147777	125252	004476	BICB	@125252,@TEMP+2	
012214	122737	052525	016710	CMPB	#52525,@TEMP	
012222	001401			BEQ	+.4	
012224	104000			HLT		:BICB FAILED
012226	104400			SCOPE		
012230	012737	177777	016700	MOV	#-1,@BC	
012236	147777	004416	004436	BICB	@B+2,@C+2	
012244	126737	004426	016700	CMPB	A+10,@BC	
012252	001401			BEQ	+.4	
012254	104000			HLT		:BICB FAILED
012256	104400			SCOPE		
012260	012737	177777	016710	MOV	#-1,@TEMP	
012266	105077	004420		CLRB	@TEMP+2	
012272	105737	016710		TSTB	@TEMP	
012276	001401			BEQ	+.4	
012300	104000			HLT		:CLRB FAILED
012302	104400			SCOPE		
012304	012737	125252	016710	MOV	#125252,@TEMP	
012312	105177	004374		COMB	@TEMP+2	
012316	122737	052525	016710	CMPB	#052525,@TEMP	
012324	001401			BEQ	+.4	
012326	104000			HLT		:COMB FAILED
012330	104400			SCOPE		
012332	005037	016710		CLR	@TEMP	
012336	105277	004350		INCB	@TEMP+2	
012342	122737	000001	016710	CMPB	#1,@TEMP	
012350	001401			BEQ	+.4	
012352	104000			HLT		:INCB FAILED
012354	104400			SCOPE		
012356	005037	016710		CLR	@TEMP	
012362	105377	004324		DECB	@TEMP+2	
012366	123727	016710	177777	CMPB	@TEMP,#-1	
012374	001401			BEQ	+.4	
012376	104000			HLT		:DECB FAILED
012400	104400			SCOPE		
012402	012737	000001	016710	MOV	#1,@TEMP	
012410	105477	004276		NEGB	@TEMP+2	
012414	122737	177777	016710	CMPB	#-1,@TEMP	
012422	001401			BEQ	+.4	
012424	104000			HLT		:NEGB FAILED

:TEST BIC INSTRUCTION INDIRECT WITH INDEXING

:TEST UNARYS INDIRECT WITH INDEXING

2681	012426	104400			SCOPE	
2682	012430	012737	177777	016710	MOV	#-1, @TEMP
2683	012430	000261			SEC	
2684	012440	105577	004246		ROCB	@TEMP+2
2685	012444	022737	177400	016710	CMP	#177400, @TEMP
2686	012444	001401			BEQ	+.4
2687	012455	104000			HLT	
2688	012455	105737	016710		TSTB	@TEMP
2689	012455	001401			BEQ	+.4
2690	012464	104000			HLT	
2691	012466	104400			SCOPE	
2692						: ADCB FAILED
2693	012470	012737	000001	016710	MOV	#1, @TEMP
2694	012476	000261			SEC	
2695	012500	105377	004206		DECB	@TEMP+2
2696	012504	005737	016710		TST	@TEMP
2697	012510	001401			BEQ	+.4
2698	012512	104000			HLT	
2699	012514	104400			SCOPE	
2700						: DECIB FAILED
2701						
2702						: TEST OF COMBINED INDEXING AND INDIRECT
2703	012516	012700	177772		MOV	#-6, %0
2704	012522	127027	016666	125252	CMPB	@A(0), #125252
2705	012530	001401			BEQ	+.4
2706	012532	104000			HLT	
2707	012534	104400			SCOPE	
2708						: CMPB FAILED
2709	012536	012700	177772		MOV	#-6, %0
2710	012542	122770	125252	016666	CMPB	#125252, @A(0)
2711	012550	001401			BEQ	+.4
2712	012552	104000			HLT	
2713	012554	104400			SCOPE	
2714						: CMPB FAILED
2715	012556	012700	177772		MOV	#-6, %0
2716	012562	012701	000002		MOV	#+2, %1
2717	012566	127071	016666	016666	CMPB	@A(0), @A(1)
2718	012574	001401			BEQ	+.4
2719	012576	104000			HLT	
2720	012600	104400			SCOPE	
2721						: TEST BIC INSTRUCTION
2722	012602	012700	000006		MOV	#+6, %0
2723	012606	012767	177777	004074	MOV	#-1, TEMP
2724	012614	147067	016666	004066	BICB	@A(0), TEMP
2725	012622	122767	125252	004060	CMPB	#125252, TEMP
2726	012630	001401			BEQ	+.4
2727	012632	104000			HLT	
2728	012634	104400			SCOPE	
2729						: BICB FAILED
2730	012636	012700	177772		MOV	#-6, %0
2731	012642	012737	177777	016700	MOV	#-1, @#C
2732	012650	142770	125252	016710	BICB	#125252, @TEMP(0)
2733	012656	123727	016700	000125	CMPB	@#C, #000125
2734	012664	001401			BEQ	+.4
2735	012666	104000			HLT	
2736	012670	104400			SCOPE	
						: BICB FAILED

2737											
2738	012672	012700	016660								
2739	012676	023067	003754								
2740	012702	001401									
2741	012704	104000									
2742	012706	104400									
2743											
2744	012710	012700	016662								
2745	012714	025067	003736								
2746	012720	001401									
2747	012722	104000									
2748	012724	104400									
2749											
2750	012726	012700	016662								
2751	012732	125067	003720								
2752	012736	001401									
2753	012740	104000									
2754	012742	104400									
2755											
2756	012744	012700	016704								
2757	012750	012737	177777	016700							
2758	012756	105050									
2759	012760	023727	016700	177400							
2760	012766	001401									
2761	012770	104000									
2762	012772	104400									
2763	012774	012737	177777	016700							
2764	013002	012700	177772								
2765	013006	012701	177772								
2766	013012	147071	016666	016710							
2767	013020	022737	177525	016700							
2768	013026	001401									
2769	013030	104000									
2770	013032	104400									
2771											
2772	013034	012700	052525								
2773											
2774											
2775	013040	004767	000002								
2776	013044	000405									
2777	013046	121627	013044								
2778	013052	001401									
2779	013054	104000									
2780	013056	000207									
2781	013060	104400									
2782											
2783	013062	000257									
2784	013064	004717									
2785	013066	121627	013066								
2786	013072	001401									
2787	013074	104000									
2788	013076	005726									
2789	013100	104400									
2790											
2791											
2792	013102	000257									

; ADDRESS OF ADDRESS OF B

; CMP FAILED

; CMP FAILED

; CMPB FAILED

; CLRB FAILED

; BICB FAILED

; TEST THAT R0 IS NOT DESTROYED BY FALSE SELECTION
 ; THIS IS CHECK LATER IN PROGRAM
 ; TEST JSR INSTRUCTION

; PLACE PC ON STACK
 ; RETURN HERE ON RTS %7
 ; CHECK FOR CORRECT PC ON STACK
 ; INCORRECT PC ON STACK
 ; RETURN TO INST AFTER JSR

; INSTRUCTION UNDER TEST
 ; TEST THE STACK
 ; PC OF JSR DID NOT GO TO STACK
 ; REPOSITION THE STACK

; TEST NESTED SUBROUTINES

; CLEAR CONDITION CODES

2793	013104	004767	003366		JSR	%7, SUBR6	
2794	013110	100401			BMI	.+4	
2795	013112	104000			HLT		;JSR OR RTS FAILED
2796	013114	001401			BEQ	.+4	
2797	013116	104000			HLT		;JSR OR RTS FAILED
2798	013120	102401			BVS	.+4	
2799	013122	104000			HLT		;JSR OR RTS FAILED
2800	013124	103401			BCS	.+4	
2801	013126	104000			HLT		;JSR OR RTS FAILED
2802	013130	104400			SCOPE		
2803					:TEST ROTATE ODD BYTE		
2804	013132	104400			SCOPE		
2805	013134	000257			CCC		;CLEAR "C"
2806	013136	012767	123456	003544	MOV	#123456, TEMP	
2807	013144	106067	003541		RORB	TEMP+1	;ROTATE ODD BYTE
2808	013150	103401			BCS	.+4	
2809	013152	104000			HLT		;C NOT SET
2810	013154	102401			BVS	.+4	
2811	013156	104000			HLT		;V NOT SET
2812	013160	022767	051456	003522	CMP	#051456, TEMP	
2813	013166	001401			BEQ	.+4	
2814	013170	104000			HLT		;ROTATE FAILED
2815	013172	104400			SCOPE		
2816	013174	000277			SCC		;SET C
2817	013176	012767	123456	003504	MOV	#123456, TEMP	
2818	013204	106067	003501		RORB	TEMP+1	
2819	013210	103401			BCS	.+4	
2820	013212	104000			HLT		;C NOT SET
2821	013214	102001			BVC	.+4	
2822	013216	104000			HLT		;V NOT CLEARED
2823	013220	022767	151456	003462	CMP	#151456, TEMP	
2824	013226	001401			BEQ	.+4	
2825	013230	104000			HLT		;ROTATE FAILED
2826	013232	104400			SCOPE		
2827							
2828	013234	000257			CCC		
2829	013236	012767	123456	003444	MOV	#123456, TEMP	
2830	013244	106167	003441		ROLB	TEMP+1	
2831	013250	103401			BCS	.+4	
2832	013252	104000			HLT		;C NOT SET
2833	013254	102401			BVS	.+4	
2834	013256	104000			HLT		;V NOT SET
2835	013260	022767	047056	003422	CMP	#047056, TEMP	
2836	013266	001401			BEQ	.+4	
2837	013270	104000			HLT		;ROTATE BYTE FAILED
2838	013272	104400			SCOPE		
2839							
2840	013274	000277			SCC		;SET C
2841	013276	012767	123456	003404	MOV	#123456, TEMP	
2842	013304	106167	003401		ROLB	TEMP+1	
2843	013310	103401			BCS	.+4	
2844	013312	104000			HLT		;C NOT SET
2845	013314	102401			BVS	.+4	
2846	013316	104000			HLT		;V NOT SET
2847	013320	022767	047456	003362	CMP	#047456, TEMP	
2848	013326	001401			BEQ	.+4	

```

013330 104000      HLT
013332 104400      SCOPE
                                ;ROTATE ODD BYTE FAILED

013334 000257      CCC
013336 012767 177777 003344  MOV      B-1 TEMP
013338 102267 003341 003344  ASL      TEMP+1
013340 103740      BCS      .+4
013342 104000      HLT
013344 102001      BVC      .+4
013346 104000      HLT
013348 026727 003324 177777  CMP      TEMP,B-1
013350 001401      BNE
013352 104000      HLT
013354 104000      SCOPE
                                ;SHIFT FAILED

013374 000277      SCC
013376 012767 177777 003304  MOV      B-1 TEMP
013378 102267 003301 003304  ASL      TEMP+1
013380 103740      BCS      .+4
013382 104000      HLT
013384 102001      BVC      .+4
013386 104000      HLT
013388 026727 003264 177377  CMP      TEMP,#177377
013390 001401      BNE
013392 104000      HLT
013394 104000      SCOPE
                                ;SHIFT BYTE FAILED

                                ;TEST COMBINATION OF N, C AND V
                                .MACR
                                TNCV
                                .+12
                                .+20
                                .+30
                                .+24
                                .+16
                                .+20
                                .+14
                                .+12
                                .+6
                                .+4
                                HLT
                                SCOPE
                                .ENOM
                                CLR      @ICOUNT
                                ;NO ITERATION

013434 005037 016440
                                ;TEST ROTATING NUMBERS
                                SCOPE
013440 104400      MOV      B-1 REFF
013442 012767 177777 000142  INC      REFF
013444 005267 000136 000142  JSR      %7 ROTALL
013446 004767 000012 100077  CMP      REFF,#100077
013448 026727 000126 000126  BNE      TSROT
013450 001370      BR      TSRT2A
013470 000452
013472 016767 000114 000114  RTALL: MOV      REFF,TEST

```

```

;ROTATE ODD BYTE FAILED

;CLEAR C

;C NOT SET
;V NOT CLEARED

;SHIFT FAILED

;C NOT SET
;V NOT CLEARED

;SHIFT BYTE FAILED

;Z=1
;Z=1, C=1
;Z=C, BUT V=1

;Z=0
;Z=0, C=1
;Z NOT EQUAL C, V=1

;Z=1, C=0
;Z NOT EQUAL C, V=1

;Z=0, C=0
;Z=C, BUT V=1

;NO ITERATION

;INITIALIZE BASE NUMBER
;INCREMENT NUMBER
;GO TO COMPARE ROUTINE
;TEST ALL VALUES
;NO TEST THEM ALL
;WE ARE DONE

```


2997	014064	104400	
2998			
2999	014066	005227	177776
3000	014072	100002	
3001	014074	000167	000632
3002			
3003			
3004	014100	011667	000072
3005	014104	012767	000001 177500
3006	014112	005267	177474

```

ROTENI: SCOPE
:WILL ALLOW TWO FAST PASSES
      INC      0177776
      BPL      +6
      JMB      ERESRT
:ADD AND SUBTRACT ALL NUMBERS AGAINST FIXED NUMBERS
:A+B=C, C-A=B, BF SHOULD EQUAL BI
↑STARI: MOV    2x6, NUMA
      MOV    BI REF
ARITST: INC    REF

```

3007 014115 004767 000014
 3008 014116 022767 177777 177462
 3009 014130 001370
 3010 014132 000422
 3011 014133 104400
 3012 014134 016767 177450 177450 AOSUB
 3013 014135 066767 000026 177442
 3014 014136 166767 000020 177434
 3015 014137 026767 177426 177426
 3016 014138 001401
 3017 014139 104000
 3018 014172 104400
 3019 014174 000207
 3020 014176 000000
 3021 014200 104400

ISR %7 AOSUB
 CAP # -1 REFF
 BNE ARIST
 BR ARIEND
 SCOPE
 MOV REF TEST
 ADD NUMA TEST
 SUB NUMA TEST
 CMP REF TEST
 BEQ .+4
 HLT
 SCOPE
 RTS %7
 NUMA: 0
 ARIEND: SCOPE

;TEST ALL COMBINATIONS OF NUMBERS WITH COMPARE INSTRUCTION

3023 014202 005002
 3024 014204 005001
 3025 014206 020201
 3026 014210 001401
 3027 014212 104000
 3028 014214 C J227 177777
 3029 014220 001403
 3030 014222 005202
 3031 014224 005201
 3032 014226 000767
 3033 014230 104400

COMPAR: CLR %2 ;INIT %2
 CLR %1 ;INIT %1
 CMP1: CMP %2,%1 ;ARE THE EQUAL
 BEQ .+4
 HLT ;RO AND R1 DID NOT COMPARE
 CMP %2,#-1 ;AT UPPER LIMIT
 BEQ CMP2 ;YES EXIT
 INC %2 ;INCREMENT TO NEXT NUMBER
 INC %1
 BR CMP1
 CMP2: SCOPE

;TEST COMPLIMENTING ALL NUMBERS

3036 014232 005067 002452
 3037 014236 005067 002452
 3038 014240 005167 002442
 3039 014244 005367 002442
 3040 014246 026767 002432 002434
 3041 014250 001401
 3042 014252 104000
 3043 014264 005167 002420
 3044 014270 005267 002414
 3045 014274 001362
 3046 014276 104400

TCOM: CLR TEMP ;BASE DATA
 CLR TEMP+4 ;BASE REFERENCE
 COM TEMP ;COMPLIMENT DATA
 DEC TEMP+4 ;DECREMENT REFERENCE
 CMP TEMP,TEMP+4 ;COMPARE
 BEQ .+4 ;TEST
 HLT ;COMPLIMENT OR DECREMENT FAILED
 COM TEMP ;INCREMENT AND TEST FOR DONE
 INC TEMP ;NOT FINISHED GO LOOP
 BNE TCOM
 SCOPE

;TEST COMB (EVEN BYTE)

3049 014300 005067 002404
 3050 014304 005067 002404
 3051 014310 105167 002374
 3052 014314 005367 002374
 3053 014320 126767 002364 002366
 3054 014326 001401
 3055 014330 104000
 3056 014332 105167 002352
 3057 014336 105267 002346
 3058 014342 001362
 3059 014344 104400

TCOM2: CLR TEMP ;BASE DATA
 CLR TEMP+4 ;REFERENCE DATA
 COMB TEMP ;COMPLIMENT DATA
 DEC TEMP+4 ;DECREMENT REFERENCE
 CMPB TEMP,TEMP+4 ;COMPARE
 BEQ .+4 ;TEST
 HLT ;COMPLIMENT OR INCREMENT BYTE FAILED
 COMB TEMP ;INCREMENT AND TEST FOR DONE
 INCB TEMP ;NOT FINISHED GO LOOP
 BNE TCOM2
 SCOPE

;TEST COMB (ODD BYTE)

3061 014346 005067 002336
 3062 014352 005067 002336

TCOM3: CLR TEMP ;BASE DATA
 CLR TEMP+4 ;REFERENCE DATA

```

30000 014437 105167 002327 TCOM3: COMB TEMP+1 :000 BYTE
30001 014437 105167 002328 DEC TEMP+4
30002 014437 105167 002317 002320 CMPB TEMP+1,TEMP+4
30003 014437 001401 BEQ .+4
30004 014437 104000 HLT ;COMPLIMENT BYTE FAILED
30005 014437 105167 002305 COMB TEMP+1
30006 014437 105167 002301 INCB TEMP+1
30007 014410 001362 BNE TCOM3
30008 014412 104400 SCOPE
30009 014412 104400
30010 014412 104400
30011 014412 104400
30012 014412 104400
30013 014412 104400
30014 014412 104400
30015 014412 104400
30016 014412 104400
30017 014412 104400
30018 014412 104400
30019 014412 104400
30020 014412 104400
30021 014412 104400
30022 014412 104400
30023 014412 104400
30024 014412 104400
30025 014412 104400
30026 014412 104400
30027 014412 104400
30028 014412 104400
30029 014412 104400
30030 014412 104400
30031 014412 104400
30032 014412 104400
30033 014412 104400
30034 014412 104400
30035 014412 104400
30036 014412 104400
30037 014412 104400
30038 014412 104400
30039 014412 104400
30040 014412 104400
30041 014412 104400
30042 014412 104400
30043 014412 104400
30044 014412 104400
30045 014412 104400
30046 014412 104400
30047 014412 104400
30048 014412 104400
30049 014412 104400
30050 014412 104400
30051 014412 104400
30052 014412 104400
30053 014412 104400
30054 014412 104400
30055 014412 104400
30056 014412 104400
30057 014412 104400
30058 014412 104400
30059 014412 104400
30060 014412 104400
30061 014412 104400
30062 014412 104400
30063 014412 104400
30064 014412 104400
30065 014412 104400
30066 014412 104400
30067 014412 104400
30068 014412 104400
30069 014412 104400
30070 014412 104400
30071 014412 104400
30072 014412 104400
30073 014412 104400
30074 014412 104400
30075 014412 104400
30076 014412 104400
30077 014412 104400
30078 014412 104400
30079 014412 104400
30080 014412 104400
30081 014412 104400
30082 014412 104400
30083 014412 104400
30084 014412 104400
30085 014412 104400
30086 014412 104400
30087 014412 104400
30088 014412 104400
30089 014412 104400
30090 014412 104400
30091 014412 104400
30092 014412 104400
30093 014412 104400
30094 014412 104400
30095 014412 104400
30096 014412 104400
30097 014412 104400
30098 014412 104400
30099 014412 104400
31000 014412 104400
31001 014412 104400
31002 014412 104400
31003 014412 104400
31004 014412 104400
31005 014412 104400
31006 014412 104400
31007 014412 104400
31008 014412 104400
31009 014412 104400
31010 014412 104400
31011 014412 104400
31012 014412 104400
31013 014412 104400
31014 014412 104400
31015 014412 104400
31016 014412 104400
31017 014574 005067 177014
31018 014600 005067 177006

```

```

:TEST COMPARE ALL VALUE EVEN BYTE WITH ODD
TSCOMB: CLR TEMP ;BASE VALUE
          CMPB TEMP,TEMP+1 ;COMPARE
          BEQ .+4
          HLT ;COMPARE FAILED
          BGE .+4
          HLT ;V IS NOT = TO N
          BLE .+4
          HLT ;V IS SET
          ADD #401,TEMP
          CMP #-1,TEMP
          BNE TSCOMB
          SCOPE
WAIT3: MOV #4000,2#ICOUNT
        SCOPE
WAIT5: MOV #10,2#ICOUNT
:TEST TO SEE IF I/O DEVICES WERE SELECTED
          CMPB #377,2#REG1 ;SELECTED DEVICES STORED IN REG1
          BEQ WAIT4 ;BRANCH IF NO DEVICES SELECTED
          WAIT ;INTERRUPTS WILL OCCUR
          WAIT ;IF DEVICES ARE SELECTED
WAIT4: SCOPE
        MOV #4000,2#ICOUNT
:TEST SWAB
          MOV #0200,TEST
          SWAB TEST
          BPL .+4
          HLT
          BEQ .+4
          HLT
          SWAB TEST
          BMI .+4
          HLT
          BNE .+4
          HLT
          SCOPE
          CLR 2#ICOUNT
:TEST ALL COMBINATIONS OF SWAB
          CLR TEST ;NUMBER UNDER TEST
          CLR REF ;REFERENCE NUMBER

```

3119	014604	000367	177004		SWABA: SWAB	TEST	: OPERATION UNDER TEST
3120	014610	026767	177000	176774	CMP	TEST, REF	: TEST SWAB INSTRUCTION
3121	014616	001401			BEQ	.+4	
3122	014620	104000			HLT		: SWAB FAILED
3123	014626	000367	176766		SWAB	TEST	
3124	014632	005267	176760		INC	REF	: INCREMENT REFERENCE NUMBER
3125	014638	105267	176757		INCB	TEST+1	: INC TEST NUMBER
3126	014644	001362			BNE	SWABA	: LOOP TILL DONE
3127	014650	104400			SCOPE		
3128	014642	012737	004000	016440	MOV	#4000, @COUNT	
3129		000240					
3130		177776					
3131							
3132							
3133	014650	012767	177777	002032	MOV	#-1, TEMP	
3134	014656	000261			SEC		
3135	014660	105567	002025		ADCB	TEMP+1	
3136	014664	103401			BCS	.+4	
3137	014666	104000			HLT		: ADCB FAILED
3138	014670	022767	000377	002012	CMP	#377, TEMP	
3139	014676	001401			BEQ	.+4	
3140	014700	104000			HLT		: ADCB FAILED
3141	014702	104400			SCOPE		
3142							
3143	014704	012703	000100				
3144	014710	012705	016710		MOV	#100, %3	
3145	014714	012737	177777	016710	MOV	#TEMP, %5	
3146	014722	030315			MOV	#-1, @TEMP	
3147	014724	001001			BIT	%3, @%5	
3148	014726	104000			BNE	.+4	
3149	014730	104400			HLT		: BIT FAILED
3150	014732	000402			SCOPE		
3151	014734	000167	000362		EASRT: BR	.+6	: NOP IF NO EAE
3152					JMP	ENDEAE	
3153							
3154	014740	104400			: TEST LEFT SHIFT		
3155	014742	005077	163402		SCOPE		: TEST OF LOGICAL SHIFT
3156	014746	012777	125252	163376	CLR	@MQ	: LOAD MQ WITH 0
3157	014754	012777	177760	163404	MOV	#125252, @AC	: LOAD AC WITH 125252
3158	014762	005777	163364		MOV	#-16, @LSH	: LOAD SHIFT COUNT (LSH) WITH -16
3159	014770	104000			TST	@AC	: COMPARE AC WITH 0
3160	014772	022777	125252	163350	BEQ	.+4	: GO TO HLT IF BAD
3161	015000	001401			HLT		: COMPARE MQ WITH 125252
3162	015002	104000			CMP	#125252, @MQ	: GO TO HLT IF BAD
3163	015004	122777	000020	163344	BEQ	.+4	
3164	015012	001401			HLT		: COMPARE SR WITH 2
3165	015014	104000			CMPB	#20, @SRE	: SKIP HLT IF GOOD
3166					BEQ	.+4	: HALT ON ERROR (LEFT SHIFT)
3167					HLT		
3168							
3169							
3170	015016	104400			: TEST RIGHT SHIFT		: TEST OF ARITHMETIC SHIFT
3171	015020	005077	163324		SCOPE		
3172	015024	012777	177777	163320	CLR	@MQ	: LOAD MQ WITH 0
3173	015032	012777	000020	163330	MOV	#-1, @AC	: LOAD AC WITH -1
3174	015040	005777	163306		MOV	#16, @ASH	: LOAD SHIFT COUNT (ASH) WITH 16
3175	015044	100401			TST	@AC	: COMPARE AC WITH 100000
3176	015046	104000			BEQ	.+4	: SKIP HLT IF GOOD
3177	015050	005777	163274		BMI	.+4	: HALT ON ERROR
3178					HLT		: HALT ON ERROR
3179					TST	@MQ	: COMPARE MQ WITH 0

3175	015054	001401			BEQ	.+4		: SKIP HLT IF GOOD
3176	015056	104000			HLT			: HALT ON ERROR
3177	015060	122777	000110	163270	CMPB	#110, JSRE		: COMPARE SR WITH 10
3178	015066	001401			BEQ	.+4		: SKIP HLT IF GOOD
3179	015070	104000			HLT			: HALT ON ERROR (RIGHT SHIFT)
3180								
3181					: TEST NORMALIZE			
3182	015072	104400			SCOPE			: TEST OF NORMALIZE
3183	015074	012777	125252	163246	MOV	#125252, MQ		: LOAD MQ WITH 125252
3184	015102	012777	170000	163242	MOV	#170000, AC		: LOAD AC WITH 170000
3185	015110	005777	163250		CLR	#NOR		: START NORMALIZE
3186	015114	022777	100005	163230	CMP	#100005, AC		: COMPARE AC WITH 100005
3187	015122	001401			BEQ	.+4		: SKIP HLT IF GOOD
3188	015124	104000			HLT			: HALT ON ERROR
3189	015126	022777	052520	163214	CMP	#52520, MQ		: COMPARE MQ WITH 52520
3190	015134	001401			BEQ	.+4		: SKIP HLT IF GOOD
3191	015136	104000			HLT			: HALT ON ERROR
3192	015140	122777	000003	163206	CMPB	#3, JSC		: COMPARE SC WITH 3
3193	015146	001401			BEQ	.+4		: SKIP HLT IF GOOD
3194	015150	104000			HLT			: HALT ON ERROR (NORMALIZE)
3195					: TEST MULTIPLY			
3196	015152	104400			SCOPE			: TEST OF MULTIPLY
3197	015154	012777	125252	163166	MOV	#125252, MQ		: LOAD MQ WITH 125252
3198	015162	012777	040000	163170	MOV	#40000, MUL		: LOAD MUL WITH 40000
3199	015170	022777	165252	163154	CMP	#165252, AC		: COMPARE AC WITH 1652
3200	015176	001401			BEQ	.+4		: SKIP IF GOOD
3201	015200	104000			HLT			: HALT ON ERROR
3202	015202	005777	163142		TST	MQ		: COMPARE MQ WITH 10000
3203	015206	100401			BMI	.+4		: SKIP HLT IF GOOD
3204	015210	104000			HLT			: HALT ON ERROR
3205	015212	122777	000300	163136	CMPB	#300, JSRE		: COMPARE SR WITH 300
3206	015220	001401			BEQ	.+4		: SKIP HLT IF GOOD
3207	015222	104000			HLT			: HALT ON ERROR (MULTIPLY)
3208								
3209					: TEST DIVIDE			
3210	015224	104400			SCOPE			: TEST OF DIVIDE
3211	015226	012777	125252	163114	MOV	#125252, MQ		: LOAD MQ WITH 125252
3212	015234	012777	177777	163110	MOV	#-1, AC		: LOAD AC WITH -1
3213	015242	012777	000002	163112	MOV	#2, DIV		: LOAD DIV WITH 2 AND DIVIDE
3214	015250	005777	163076		TST	AC		: COMPARE AC WITH 0 (QUOTIENT)
3215	015254	001401			BEQ	.+4		: SKIP HLT IF GOOD
3216	015256	104000			HLT			: HALT ON ERROR
3217	015260	022777	152525	163062	CMP	#152525, MQ		: COMPARE MQ WITH 152525
3218	015266	001401			BEQ	.+4		: SKIP HLT IF GOOD
3219	015270	104000			HLT			: DIVIDE ERROR
3220	015272	104400			SCOPE			
3221	015274	012767	177777	001406	MOV	#-1, TEMP		
3222	015302	000261			SEC			
3223	015304	105667	001401		SBCB	TEMP+1		
3224	015310	022767	177377	001372	CMP	#177377, TEMP		
3225	015316	001401			BEQ	.+4		
3226	015320	104000			HLT			
3227	015322	104400			SCOPE			
3228	015324	022700	052525		CMP	#52525, %0		
3229	015330	001401			BEQ	.+4		
3230	015332	104000			HLT			: SOME OPERATION DESTROYED %0

ENDERE:

```

3231 015334 012737 016504 000024      MOV      #PFail,2024      ;POWER FAIL VECTOR
3232 015342 012737 000340 000026      MOV      #340,2026      ;PROCESSOR PRIORITY
3233 015350 000401      SKPBEL: BR      +4      ;SKIP OVER BELL-NOP ON CORE EXPANSION
3234 015352 000501      BR      TRPA
3235 015354 032777 000100 162702      BIT      #100,2TCSR
3236 015362 001006      BNE     SBELL      ;DON'T RING BELL IF TTY IS BUSY
3237 015364 012777 000207 000466      .BELL ON PASS COMPLETE
3238 015372 105777 000464      BELL:  MOV     #207,2TOBR
3239 015376 100375      TSTB    2TCSR
3240 015378 005227 000000      BPL     -4
3241 015400 010700      SBELL:  INC     #0      ;PASS COUNT LOCATION
3242 015402 042700 017777      MOV     %7,%0      ;SET UP RESERVED INSTRUCTION
3243 015406 062700 015436      BIC     #17777,%0   ;OFFSET
3244 015412 010037 000010      ADD     #BEG20,%0
3245 015416 006701      MOV     #6701,%0
3246 015422 000240      NOP
3247 015426 012737 000006 015552      MOV     #6,2YESRT   ;ATTEMPT TO EXECUTE SIGN EXTEND
3248 015432 000403      BR      BEGANY      ;NO TRAP, PROCESSOR IS NOT=20.15.05
3249 015436 012737 000002 015552      BEG20: MOV     #2,2YESRT ;TRAP OCCURRED
3250 015444 012737 000012 000010      BEGANY: MOV     #12,20 ;RESTORE HALT FOR RESERVED INC
3251 015444 012737 000012 000010      ;ROUTINE TO CHECK FOR TRACE TRAP TO BE RUN WITH PROGRAM
3252 015444 012737 000012 000010      ;SAVE OLD CONTENTS, SET UP FOR TRACE TRAP
3253 015452 005046      YESTR:  CLR     -(6)
3254 015454 032777 010000 162512      BIT     #1000,2SRPTR ;INHIBIT "T" TRAP IF SET
3255 015462 001013      BNE     ACT
3256 015464 012737 015552 000014      MOV     #YESRT,2014 ;T TRAP VECTOR
3257 015472 005167 000052      COM     TRPB
3258 015476 001405      BEQ     ACT
3259 015500 012716 000020      MOV     #20,(6)
3260 015504 012716 004416      YESTR1: MOV     #BEGIN,-(6) ;SET TRACE TRAP
3261 015510 000002      YESTR2: RTI
3262 015512 013700 000042      ACT:   MOV     #42,%0 ;ARE WE UNDER ACT?
3263 015516 001772      BEQ     YESTR1      ;NO
3264 015520 012737 015532 000014      MOV     #CLEAR,2014 ;TO BANK ZERO
3265 015526 012707 015532      MOV     #CLEAR,%7
3266 015532 000005      CLEAR: RESET
3267 015534 004710      LOGICA: JSR     %7,20 ;CLER THE WORLD
3268 015536 000240      NOP
3269 015538 000240      NOP
3270 015540 000240      NOP
3271 015542 000137 000502      JMP     20START
3272 015550 000000      TRPB:  0
3273 015552 000002      YESRT: RTI
3274 015554 000000      HALT
3275 015556 000137 004416      TRPA:  JMP     20BEGIN ;RETURN TO PROGRAM FROM TRAP - CAN BE AN RTI
3276 015562 000000      PRFLAG: 0 ;RTI FAILED
3277 015562 000000      ;BEGIN MODIFY BY EXPANSION
3278 015562 000000      ;PRINT ROUTINE BUSY IF NOT ZERO
3279 015562 000000
3280
3281 ;ENTERED WITH SYSTEM TRAP CALL(HLT)
3282 ;PRINT OUT THE ERROR PC AND STATUS REGISTER
3283 015564 005767 177772      PRINT: TST     PRFLAG ;IS ROUTINE BUSY
3284 015570 001401      BEQ     +4
3285 015572 000002      RTI
3286 015574 005267 177762      INC     PRFLAG ;YES EXIT
3287 015574 005267 177762 ;NO SET FLAG
    
```

3287	015600	005227	000000		INC	#0		: ERROR COUNT LOCATION
3288	015604	037727	162364	020000	BIT	JSRPTR, #20000		: TEST FOR INHIBIT PRINT OUT
3289	015612	001401			BEG	.+4		: BRANCH TO PRINT
3290	015614	000501			BR	PRINT1		: INHIBIT RETURN TO MAIN STREAM
3291	015616	012667	000242		MOV	(6)+, SAVPC		: PC OF FAILING ROUTINE
3292	015622	012667	000240		MOV	(6)+, SAVCC		: CC OF ERROR CONDITION
3293	015624	024646			CTP	-(6), -(6)		: REPOSITION THE STACK
3294	015626	042767	000140	162140	BIC	#140, STATUS		
3295	015628	105777	000220		TSTB	@TCSA		: WAIT FOR FLAG
3296	015630	100375			BPL	.-4		
3297	015632	012777	000215	000206	MOV	#215, @TDBR		: FILLER CHARACTER.
3298	015634	105777	000204		TSTB	@TCSA		
3299	015636	100375			BPL	.-4		
3300	015638	012777	000212	000172	MOV	#212, @TDBR		: LINE FEED
3301	015640	105777	000170		TSTB	@TCSA		
3302	015642	100375			BPL	.-4		
3303	015644	010267	000152		MOV	%2, SAVR2		: SAVE R2
3304	015646	010367	000150		MOV	%3, SAVR3		: SAVE R3
3305	015648	010467	000146		MOV	%4, SAVR4		: SAVE R4
3306	015650	016702	000150		MOV	SAVPC, %2		
3307	015652	004767	000150		JSR	%7, PRTAB		: PRINT OCTAL NUMBER
3308	015654	012777	000240	000132	MOV	#240, @TDBR		
3309	015656	105777	000130		TSTB	@TCSA		: SPACE BETWEEN WORDS
3310	015658	100375			BPL	.-4		
3311	015660	016702	000126		MOV	SAVCC, %2		
3312	015662	004767	000124		JSR	%7, PRTAB		: PRINT OCTAL NUMBER
3313	015664	012777	000240	000106	MOV	#240, @TDBR		
3314	015666	105777	000104		TSTB	@TCSA		
3315	015668	100375			BPL	.-4		
3316	015670	016702	000460		MOV	RETURN, %2		: WHERE CPU TEST IS AT
3317	015672	004767	000100		JSR	%7, PRTAB		
3318	015674	016702	000056		MOV	SAVR2, %2		: RESTORE REGISTERS
3319	015676	016703	000054		MOV	SAVR3, %3		
3320	016000	016704	000052		MOV	SAVR4, %4		
3321	016004	012777	000377	000046	MOV	#377, @TDBR		
3322	016012	105777	000044		TSTB	@TCSA		
3323	016016	100375			BPL	.-4		
3324	016020	005777	162150		TST	JSRPTR		: TEST FOR HALT SWITCH
3325	016024	100001			BPL	.+4		
3326	016026	000000			HALT			: HALT ON ERROR SET
3327	016030	005067	177526		CLR	PRFLAG		: CLEAR FLAG WHEN DONE
3328	016034	032777	000400	162132	BIT	#400, JSRPTR		
3329	016042	001402			BEG	EXPRINT		
3330	016044	000167	162432		JMP	START		: RESTART ON ERROR
3331	016050	000002			EXPRINT: RTI			: RETURN TO MAIN STREAM
3332	016052	000000			SAVR2: 0			
3333	016054	000000			SAVR3: 0			
3334	016056	000000			SAVR4: 0			
3335	016060	177566			TDBR: 177566			: DATA
3336	016062	177564			TCSR: 177564			: STATUS
3337	016064	000000			SAVPC: 0			
3338	016066	000000			SAVCC: 0			
3339		016762			BUFF=FIN			: END OF PROGRAM-SP AREA.
3340								
3341	016070	005067	000252		PRTAB: CLR	BINCT		
3342	016074	005067	000244		CLR	WGTC		

```

3343 016100 012704 016352          MOV      @LIST,%4          ;GET LIST ADDRESS
3344 016104 012767 000005 000236  MOV      #5,ASCNT
3345 016112 012767 000007 000220  MOV      #7,SEVEN
3346 016120 012767 000001 000214  MOV      #1,DECML
3347 016126 105777 177730          WAIT1:  TSTB      @TCSR
3348 016132 100375          BPL      WAIT1
3349 016134 005702          TST      %2
3350 016136 100404          BMI      MINUS          ;NEG SIGN PRINT 1
3351 016140 012777 000260 177712  MOV      #260,@TOBR    ;POS SIGN PRINT 0
3352 016146 000403          BR       STAR
3353 016150 012777 000261 177702  MINUS:  MOV      #261,@TOBR
3354 016156 016703 000156          STAR:   MOV      SEVEN,%3
3355 016162 010267 000150          MOV      %2,TOODLE
3356 016166 005167 000144          COM     TOODLE
3357 016172 016703 000140          BIC     TOODLE,%3
3358 016176 001410          BEQ     WRTOC
3359 016200 066767 000136 000136  MKNUM:  ADD      DECML,WGTCT
3360 016206 005267 000134          INC     BINCT
3361 016212 026703 000126          CMP     WGTCT,%3
3362 016216 001370          BNE     MKNUM
3363 016220 062767 000260 000120  WRTOC:  ADD      #260,BINCT
3364 016226 016724 000114          MOV     BINCT,(4)+
3365 016232 066767 000102 000102  ADD     SEVEN,DECML
3366 016240 005067 000100          CLR     WGTCT
3367 016244 005067 000076          CLR     BINCT
3368 016250 005367 000074          DEC     ASCNT
3369 016254 001410          BEQ     XLIST
3370 016256 012703 000003          MOV     #3,%3
3371 016262 066767 000052 000050  MOADD:  ADD     SEVEN,SEVEN
3372 016270 005303          DEC     %3
3373 016272 001373          BNE     MOADD
3374 016274 000730          BR      STAR
3375 016276 012767 000005 000044  XLIST:  MOV      #5,ASCNT
3376 016304 105777 177552          WAIT2:  TSTB      @TCSR
3377 016310 100375          BPL      WAIT2
3378 016312 014477 177542          MOV     -(4),@TOBR
3379 016316 005367 000026          DEC     ASCNT
3380 016322 001401          BEQ     HDFHM
3381 016324 000767          BR      WAIT2
3382 016326 105777 177530          HDFHM:  TSTB      @TCSR
3383 016332 100375          BPL      RTS
3384 016334 000207          RTS
3385 016336 000000          TOODLE: 0
3386 016340 000000          SEVEN:  0
3387 016342 000000          DECML:  0
3388 016344 000000          WGTCT:  0
3389 016346 000000          BINCT:  0
3390 016350 000000          ASCNT:  0
3391 016352 000000          LIST:  0
3392 016354 000000
3393 016356 000000
3394 016360 000000
3395 016362 000000
3396
3397
3398
;SCOPE LOOP ROUTINE ENTERED BY USER TRAP
;SCOPE OR/AND ITERATION LOOP FOR EACH TEST 4000 TIMES

```



```

3399 016364 032777 040000 161602 SCOPEC: BIT      #40000,JSRPTR      ;TEST SR FOR SCOPE
3400 016372 001012          BNE      SCOPEB      ;YES SCOPE
3401 016374 032777 004000 161572          BIT      #4000,JSRPTR      ;NO - TEST FOR ITERATION
3402 016402 001011          BNE      SCOPEB      ;INHIBIT ITERATION
3403 016404 026767 000032 000026          CMB      SCOPEB,ICOUNT
3404 016412 001405          BEQ      SCOPEB
3405 016414 005267 000022          INC      SCOPEB
3406 016420 016716 000020          SCOPEB: MOV     RETURN,%6
3407 016422 000002          RTI
3408 016426 005067 000010          SCOPEB: CLR     SCOPEB
3409 016432 011667 000006          MOV     %6,RETURN
3410 016436 000002          RTI
3411 016440 004000          ICOUNT: 4000
3412 016442 000000          SCOPEB: 0
3413 016444 004416          RETURN: BEGIN
3414
3415          ;GROUP OF NESTED SUBROUTINES
3416 016446 000207          SUBR1: RTS     %7      ;ONE INSTRUCTION
3417 016450 000277          SUBR2: SCC     ;ONE DEEP
3418 016452 000205          SUBR3: RTS     %5      ;TWO DEEP
3419 016454 004537 016450          JSR     %5,%SUBR2
3420 016460 000204          SUBR4: RTS     %4      ;THREE DEEP
3421 016462 004467 177766          JSR     %4,SUBR3
3422 016466 000203          SUBR5: RTS     %3      ;FOUR DEEP
3423 016470 004367 177766          JSR     %3,SUBR4
3424 016474 000202          SUBR6: RTS     %2      ;FIVE DEEP
3425 016476 004267 177766          JSR     %2,SUBR5
3426 016502 000207          RTS     %7
3427          ;ENTER HERE OR POWER FAIL
3428
3429 016504 010046          PFAIL: MOV     %0,-(6)      ;SAVE REGISTER OR STACK
3430 016506 010146          MOV     %1,-(6)      ;WHEN POWERING DOWN
3431 016510 010246          MOV     %2,-(6)
3432 016512 010346          MOV     %3,-(6)
3433 016514 010446          MOV     %4,-(6)
3434 016516 010546          MOV     %5,-(6)
3435 016520 016746 161300          MOV     24,-(6)
3436 016524 012737 000002 000006          MOV     #RTI,%6
3437 016532 012700 016572          MOV     #HAC,%0

```

; IN CASE OF NO EAE

```

3470 016570 017720 161602
3471 016571 017720 161602
3472 016572 017720 161602
3473 016573 017720 161602
3474 016574 017720 161602
3475 016575 017720 161602
3476 016576 017720 161602
3477 016577 017720 161602
3478 016578 017720 161602
3479 016579 017720 161602
3480 016580 017720 161602
3481 016581 017720 161602
3482 016582 017720 161602
3483 016583 017720 161602
3484 016584 017720 161602
3485 016585 017720 161602
3486 016586 017720 161602
3487 016587 017720 161602
3488 016588 017720 161602
3489 016589 017720 161602
3490 016590 017720 161602
3491 016591 017720 161602
3492 016592 017720 161602
3493 016593 017720 161602

```

```

000010 161236
016600 161236
016601 161236
016602 161236
016603 161236
016604 161236
016605 161236
016606 161236
016607 161236
016608 161236
016609 161236
016610 161236
016611 161236
016612 161236
016613 161236
016614 161236
016615 161236
016616 161236
016617 161236
016618 161236
016619 161236
016620 161236
016621 161236
016622 161236
016623 161236
016624 161236
016625 161236
016626 161236
016627 161236
016628 161236
016629 161236
016630 161236
016631 161236
016632 161236
016633 161236
016634 161236
016635 161236
016636 161236
016637 161236
016638 161236
016639 161236
016640 161236
016641 161236
016642 161236
016643 161236
016644 161236
016645 161236
016646 005037 016570
016647 104000
016648 000002
016649 125252
016650 016656
016651 052525
016652 016666
016653 177777
016654 016672
016655 016672
016656 016672
016657 125252
016658 016676
016659 052525
016660 000000
016661 016700
016662 016710
016663 000000
016664 016710
016665 016716
016666 016720
016667 000000
016668 016762
016669 000000
016670 000207

```

```

MOV @AC, (%0)+
MOV @SC, (%0)+
MOV @X, (%0)
MOV @Y, SAVR6
MOV @RESTART, 24
HALT
; STORE STACK POSITION, POWER FAIL FLAG
; HALT ON POWER DOWN NORMAL
; STACK IS SAVED HERE

SAVR6: 0
MAC: 0
MMQ: 0
MSC: 0
RESTART: 0
MOV SAVR6, %6
; RESTORE REGISTER OFF STACK
MOV (%6)+, %0
MOV -(%0), @SC
MOV -(%0), @MMQ
MOV -(%0), @AC
CLR @#6
; RESTORE TIME OUT
MOV (6)+, 24
; WHEN POWERING UP
MOV (6)+, %5
MOV (6)+, %4
MOV (6)+, %3
MOV (6)+, %2
MOV (6)+, %1
MOV (6)+, %0
CLR @#SAVR6
; POWER FAIL OCCURRED
; RETURN TO MAIN LINE

B: 125252
; FIXED VALUES FOR USE IN TEST
; ADDRESS OF B
B 052525

.=B+10
A: -1
A+4

.=A+4
125252
A+10
052525
; ADDRESS OF A+10
; FOR STORAGE
C: 0
; ADDRESS OF C

.=C+10
TEMP: 0
TEMP
; ADDRESS OF TEMP

.=TEMP+6
TEMP+10
; ADDRESS OF TEMP+10 OR "D"

D: 0

.=+40
FIN: 0
; BUFFER FOR SP
USER: RTS %7
; OVERLAY USER ROUTINE HERE IF 4KW, USE BANK1 IF 8KW
; PDP-11 MEMORY DETERMINATION AND SETUP
; USE WITH VARIABLE CORE QUANTITY SYSTEMS

```

49
48
47
46
45
44
43
42
41
40
39
38
37
36
35
34
33
32
31
30
29
28
27
26
25
24
23
22
21
20
19
18
17
16
15
14
13
12
11
10
9
8
7
6
5
4
3
2
1

000000	016779	000416	17554	DET1:	MOV	FIN+4	
000001	016778	000401	17554		MOV	TRPA+2	
000002	016777	000418			JSR	SAPBEL	
000042	016766	000418			X7	NAME	
		000042	016766			BOET1	
					X7		
001000	161146				X7	BOET1	
					X7		
		001000	161146			BOET1	
					X7		
017100	160744			DET4:	MOV	BOET2,4	
000740	160740				MOV	BOET2,4	
037770				EIGHT:	MOV	BOET2,4	
057770				TWELVE:	MOV	BOET2,4	
077770				SIXTEEN:	MOV	BOET2,4	
117770				TWENTY:	MOV	BOET2,4	
137770				TWENTYFOUR:	MOV	BOET2,4	
157770				TWOEIG:	MOV	BOET2,4	
					STR	STR28	
				DET2:	(6)+,X2		
					(6)+		
017052					EIGHT+4,X2		
017056					DET3		
017102					TWELVE+4,X2		
017106					STR8		
017110					SIXTEEN+4,X2		
017114					STR12		
017118					TWENTY+4,X2		
017122					STR16		
017126					TWENTYFOUR+4,X2		
017130					STR20		
017134					STR24		
				MOVE:	X0		
017138					(0)+(1)+		
017142					X0	FIN+2	
017146					.-6		
017150					X7		
000040				STR28:	X7	XFER28	
000042				STR24:	X7	XFER24	
000044				STR20:	X7	XFER20	
000046				STR16:	X7	XFER16	
000050				STR12:	X7	XFER12	
000052				STR8:	X7	XFER8	
140000				XFER28:	MOV	BOET2,4	
177710					JSR	MOVE	
120000				XFER24:	MOV	BOET2,4	
177700					JSR	MOVE	
100000				XFER20:	MOV	BOET2,4	
177670					JSR	MOVE	
060000				XFER16:	MOV	BOET2,4	

```

: APPLICABLE TO SYSTEM TEST 2;
: BR .+4
: CHECK FOR DOP1
: NO CORE EXPANSION WITH DOP1
: CHECK VARIABLE CORE SWITCH
: USE VARIABLE CORE ROUTINE
: 4K ONLY
: TRAP VECTOR SETUP
: TRAP STATUS SETUP
: CHECK FOR 4K
: CHECK FOR 8K
: CHECK FOR 12K
: CHECK FOR 16K
: CHECK FOR 20K
: CHECK FOR 24K
: RETRIEVE TRAP PC
: DISCARD TRAP STATUS WORD
: 4K
: 8K
: 12K
: 16K
: 20K
: 24K
: SET UP MAIN CORE CURRENT
: MOVE WORD
: MOVE COMPLETE?
: MOVE ANOTHER WORD
: MOVE COMPLETE
: START 4K TRANSFER
: START 8K MODIFY
: START 12K TRANSFER
: START 16K MODIFY
: START 20K TRANSFER
: START 24K MODIFY
: START 4K TRANSFER
: START 8K MODIFY
: START 12K TRANSFER
: START 16K MODIFY
: START 20K TRANSFER
: START 24K MODIFY
: SET UP MOVE START LOCATION
: GO TO MOVE SUBROUTINE

```

```

0117400 000000 177860
0117401 000000 040000
0117402 000000 177850
0117403 000000 000000
0117404 000000 177840
0117405 000000 144444
0117406 000000 111111
0117407 000000 111111
0117408 000000 111111
0117409 000000 111111
0117410 000000 111111
0117411 000000 111111
0117412 000000 111111
0117413 000000 111111
0117414 000000 111111
0117415 000000 111111
0117416 000000 111111
0117417 000000 111111
0117418 000000 111111
0117419 000000 111111
0117420 000006 000004
0117421 000002 000006
0117422 000000 172100
0117423 000001 000001
0117424 006302
0117425 103374
0117426 000207
0117427 104000
0117428 000137 000502
0117429 000001

```

```

XFER12: JSR X7,MOVE
          MOV @40000,X1
          JSR X7,MOVE
XFER8:   JSR X7,MOVE
          MOV @80000,X1
          JSR X7,MOVE
          X7,MOVE
          :RETURN FROM TRANSFERS
MOD24:   JSR @BEGIN+140006,TRPA+120002
          SNOP @SKIP+120000
MOD20:   JSR @BEGIN+120006,TRPA+100002
          SNOP @SKIP+100000
MOD16:   JSR @BEGIN+100006,TRPA+60002
          SNOP @SKIP+60000
MOD12:   JSR @BEGIN+80006,TRPA+40002
          SNOP @SKIP+40000
MOD8:    JSR @BEGIN+40006,TRPA+20002
          SNOP @SKIP+20000
MOD4:    JSR @BEGIN+20006,TRPA+2
          SNOP @SKIP
DET3:    RTS X7
:ROUTINE TO SET ACTION ENABLE ON MA/MF PARITY MEMORIES
:CALL:   JSR PC,.MAMF
          PARCSR= 172100 :ADDRESS OF FIRST MA/MF PA
          PRVEC= 114 :ADDRESS OF PARITY INTERVAL
          ERRVEC=4
          RO=%0
          SP=%6
          R2=%3
          PC=%7
.MAMF:   MOV @ERRVEC+2,@ERRHVEC
          MOV @ATI,@ERRVEC+2
          MOV @PARCSR,RO :GET FIRST CSR ADDRESS
          MOV @1,R2
          :SET TIME OUT INDICATOR
          :SET ACTION ENABLE IF AVAI
          :BRANCH IF CSR NOT AVAILAB
          :SHIFT AVAILABILITY INDICA
          :PARSRV: HLT
          JMP @START
          .END

```


CROSS REFERENCE TABLE -- USER SYMBOLS

SY4	001122	827	833	835*										
SY5	001140	826	832											
SY6	001140	840	850											
SY7	001322	851	860											
SY8	001404	866	867	875*										
SY9	001450	878	883	885*										
SY10	016446	316												
SY11	016450	317												
SY12	016450	319												
SY13	016462	321												
SY14	016470	323												
SY15	016476	323												
SY16	014604	319												
SXTEEN	017056	3508	3519											
TC	177340	720	721	722	723	725	726							
TCBA	000404	726	1164	1205*										
TCBLK	002670	1109												
TCCM	000372	721	864	1116*	1119*	1121*	1123	1132*	1136	1146*	1155*	1157*	1165*	1167
TCDT	000376	1171	1174	1182*	1185*	1189	1199*	1206*	1209	1213*				
TCEXPE	002672	723	1126	1139	1142	1177	1192	1195						
TCFIRS	002664	862	1110	1120*	1126	1141*	1142	1152*	1177	1194*	1195			
TCF1	002746	1118	1123											
TCF1A	002740	1121	1127											
TCF2	002774	1128	1131											
TCF3	003010	1131	1136	1170										
TCF4	003052	1146	1172											
TCIV	000406	727	863	1113*	1118*	1131*	1151*	1158*	1162*	1170*	1184*	1203*	1212*	
TCLAST	002666	1108	1139	1152										
TCOM	014242	3038	3045											
TCOM2	014310	3051	3058											
TCOM3	014356	3063	3070											
TCR8K	003332	1198	1203											
TCR8UF	003416	743	747	1205	1218*									
TCR81	003370	1203	1209											
TCR1	003210	1158	1174											
TCR1A	003240	1179	1182											
TCR2	003246	1178	1184											
TCR3	003262	1184	1189	1212										
TCR4	003324	1199	1214											
TCR	016062	585	3240	3295	3298	3301	3309	3314	3322	3336*	3347	3376	3382	
TCST	000374	722	1114	1153										
TCMBK	003130	1145	1162											
TCMBUF	003416	1164	1217											
TCMB1	003162	1162	1167											
TCMC	000402	725	1163	1204*										
TC1	000434	740	1207											
TC2	000446	744	746											
TDBR	016060	3239*	3297*	3300*	3308*	3313*	3321*	3335*	3351*	3353*	3378*			
TDSR	016062	585												
TEMP	016710	1711*	1712	1718*	1719	1725*	1732*	1733	1739*	1741*	1742	1747*	1749*	1750
		1755*	1757*	1758	1764*	1765*	1766	1771*	1773*	1778*	1780*	1785*	1787*	1792*
		1800*	1803	1808*	1811	1816*	1819	1824*	1827	1831*	1834	1839*	1842	1847*
		1850	1855*	1858	1863*	1866	1871*	1874	1879*	1883	1888*	1892	1897*	1901
		1906*	1910	1957*	1958	1976*	1977*	1978	1998*	1999*	2004*	2005*	2006	2011*

CROSS REFERENCE TABLE -- USER SYMBOLS

TEST	013614	20112*	20173*	20118*	20199*	20220*	20225*	2026*	2027*	2032*	2033*	2034*	2039*	2040*
TIME	002116	20113*	20174*	20119*	20200*	20221*	20226*	2027*	2032*	2033*	2034*	2039*	2040*	
TJSR1	013044	20114*	20175*	20120*	20201*	20222*	20227*	2028*	2033*	2034*	2039*	2040*		
TJSR2	013046	20115*	20176*	20121*	20202*	20223*	20228*	2029*	2034*	2035*	2040*			
TJSR3	013060	20116*	20177*	20122*	20203*	20224*	20229*	2030*	2035*	2040*				
TOODLE	016336	20117*	20178*	20123*	20204*	20225*	20230*	2031*	2036*	2041*				
TRCSR	00J260	20118*	20179*	20124*	20205*	20226*	20231*	2032*	2037*	2042*				
TROR	000262	20119*	20180*	20125*	20206*	20227*	20232*	2033*	2038*	2043*				
TRPA	015556	20120*	20181*	20126*	20207*	20228*	20233*	2034*	2039*	2044*				
TRPB	015550	20121*	20182*	20127*	20208*	20229*	20234*	2035*	2040*	2045*				
TSCOMB	014420	20122*	20183*	20128*	20209*	20230*	20235*	2036*	2041*					
TSROT	013450	20123*	20184*	20129*	20210*	20231*	20236*	2037*	2042*					
TSROT2	013624	20124*	20185*	20130*	20211*	20232*	20237*	2038*	2043*					
TSRT2A	013616	20125*	20186*	20131*	20212*	20233*	20238*	2039*	2044*					
TSTARI	014100	20126*	20187*	20132*	20213*	20234*	20239*	2040*	2045*					
TTCSR	000264	20127*	20188*	20133*	20214*	20235*	20240*	2041*	2046*					
TTDBR	000266	20128*	20189*	20134*	20215*	20236*	20241*	2042*	2047*					
TTYINR	001522	20129*	20190*	20135*	20216*	20237*	20242*	2043*	2048*					
TTYIN1	001560	20130*	20191*	20136*	20217*	20238*	20243*	2044*	2049*					
TTYIN2	001566	20131*	20192*	20137*	20218*	20239*	20244*	2045*	2050*					
TTYIN3	001552	20132*	20193*	20138*	20219*	20240*	20245*	2046*	2051*					
TTYIN4	001556	20133*	20194*	20139*	20220*	20241*	20246*	2047*	2052*					
TMELVE	017052	20134*	20195*	20140*	20221*	20242*	20247*	2048*	2053*					
TWENTY	017062	20135*	20196*	20141*	20222*	20243*	20248*	2049*	2054*					
TWOEIG	017072	20136*	20197*	20142*	20223*	20244*	20249*	2050*	2055*					
TWOFOR	017066	20137*	20198*	20143*	20224*	20245*	20250*	2051*	2056*					
TYOUTR	001576	20138*	20199*	20144*	20225*	20246*	20251*	2052*	2057*					
TYOUT1	001612	20139*	20200*	20145*	20226*	20247*	20252*	2053*	2058*					
USER	016764	20140*	20201*	20146*	20227*	20248*	20253*	2054*	2059*					
WAIT1	016126	20141*	20202*	20147*	20228*	20249*	20254*	2055*	2060*					
WAIT2	016304	20142*	20203*	20148*	20229*	20250*	20255*	2056*	2061*					
WAIT3	014470	20143*	20204*	20149*	20230*	20251*	20256*	2057*	2062*					
WAIT4	014520	20144*	20205*	20150*	20231*	20252*	20257*	2058*	2063*					
WAIT5	014472	20145*	20206*	20151*	20232*	20253*	20258*	2059*	2064*					
W	000014	20146*	20207*	20152*	20233*	20254*	20259*	2060*	2065*					
WGTCT	016344	20147*	20208*	20153*	20234*	20255*	20260*	2061*	2066*					
WPTOC	016220	20148*	20209*	20154*	20235*	20256*	20261*	2062*	2067*					

L06

.MAIN. MACY11 30(1046) 16-SEP-77 12:59 PAGE 78
DZQKBG.P11 16-SEP-77 12:58 CROSS REFERENCE TABLE -- MACRO NAMES

SEG 0076

TNCV 28768 2913 2951 2977

. ABS. 017464 000

ERRORS DETECTED: 0

DZQKBG.BIN DZQKBG.LST/CRF/SOL/NL:TOC=DZQKBG.P11
RUN-TIME: 3 6 1 SECONDS
RUN-TIME RATIO: 228/11=20.4
CORE USED: 11K (21 PAGES)