

RK11

BASIC LOGIC TEST 2 MD-11-DZRKK-D

EP-DZRKK-D-DL-B
COPYRIGHT © 1976
FICHE 1 OF 1

DEC 1976
digital
MADE IN U.S.A

This page contains a grid of 128 small test diagrams or data tables, arranged in 16 rows and 8 columns. Each cell in the grid contains a small, dense diagram or table, likely representing a logic test or data set. The diagrams are too small to read individually but appear to be organized in a systematic manner. The overall layout is a dense grid of these small components.

IDENTIFICATION

SEQ 0001

PRODUCT CODE: MAINDEC-11-DZRKK-D-D
PRODUCT NAME: RK11 BASIC LOGIC TEST II
DATE CREATED: DECEMBER, 1976
MAINTAINER: DIAGNOSTIC GROUP
AUTHOR: JIM KAPADIA
REVISED BY: PERVEZ ZAKI
TOM SAWYER
CHUCK HESS

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS MANUAL.

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED TO THE PURCHASER UNDER A LICENSE FOR USE ON A SINGLE COMPUTER SYSTEM AND CAN BE COPIED (WITH INCLUSION OF DIGITAL'S COPYRIGHT NOTICE) ONLY FOR USE IN SUCH SYSTEM, EXCEPT AS MAY OTHERWISE BE PROVIDED IN WRITING BY DIGITAL.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

COPYRIGHT (C) 1975, 1976 BY DIGITAL EQUIPMENT CORPORATION

QUICK LOOK-UP OPERATING INSTRUCTIONS

SEG 0002

FOR A QUICK REFERENCE, LOOK UP THE FOLLOWING SECTIONS:

1.0 ABSTRACT
 2.0 REQUIREMENTS
 4.1 LOADING AND OPERATOR ACTION
 7.0 SWITCH OPTIONS
 FOR A MORE COMPLETE EXPLANATION REFER TO THE TABLE OF
 CONTENTS BELOW AND THE FOLLOWING DOCUMENT.

TABLE OF CONTENTS

1.0	ABSTRACT
2.0	REQUIREMENTS
3.0	EQUIPMENT
4.0	PRELIMINARY PROGRAMS
5.0	EXECUTION TIME
6.0	STARTING ADDRESS
7.0	PROGRAM CONTROL MODES & OPERATOR ACTION
8.0	PAPER TAPE
9.0	RKDP DUMP MODE
10.0	RKDP CHAIN MODE
11.0	ACT11
12.0	DRIVE SELECTION
13.0	DRIVE-LESS TEST
14.0	SWITCH OPTIONS
15.0	SCOPE LOOPS
16.0	PROGRAM STRUCTURE
17.0	SET-UP PHASE
18.0	DRIVE DEPENDENT CONTROLLER TESTS
19.0	ERROR REPORTING
20.0	ERROR INTERPRETATION
21.0	HANDLERS AND COMMON ROUTINES
22.0	TRAP HANDLER
23.0	SCOPE HANDLER
24.0	ERROR HANDLER
25.0	CONTROL RESET ROUTINE
26.0	CONTROL READY ROUTINE
27.0	DRIVE RESET ROUTINE
28.0	TIME DELAY ROUTINE
29.0	WAIT FOR INTERRUPT ROUTINE
30.0	OTHER ROUTINES
31.0	TTY HANDLER (I/O), ERROR TYPEOUT ROUTINE
32.0	POWER DOWN/POWER UP ROUTINE
33.0	UNEXPECTED TIMEOUTS & RK11 INTERRUPTS
34.0	QUICK VERIFYING MODE

1.0 ABSTRACT

THE RK11 LOGIC TESTS CONSIST OF A SERIES OF TESTS AIMED AT CHECKING THE BASIC LOGIC OF THE RK11 CONTROLLER. THIS PROGRAM IS THE SECOND PART OF THE TWO-PART RK11 LOGIC TESTS. IT SHOULD BE NOTED THAT LOGIC TEST I AND LOGIC TEST II TOGETHER CONSTITUTE A COMPLETE PROGRAM AND BOTH OF THEM SHOULD BE RUN.

WHEN USED IN CONJUNCTION WITH A DRIVE IT IS CAPABLE OF DETECTING FAULTS IN THE DRIVE ALSO.

USED CORRECTLY THIS PROGRAM CAN BE AN EFFECTIVE ANALYTIC AND DIAGNOSTIC TOOL.

2.0 REQUIREMENTS

2.1 EQUIPMENT

- A. PDP11 WITH CONSOLE TELETYPE.
- B. 8K OF MEMORY
- C. RK11 OR RKV11 CONTROLLER
- D. 1-8 RKDS OR RKDSF DRIVES OR THE RKDS SIMULATOR (DRIVE TYPES MAY BE MIXED)

2.2 PRELIMINARY PROGRAMS

RK11 BASIC LOGIC TEST I (MC-11-DZRKJ)

2.3 EXECUTION TIME

ERROR FREE FIRST PASS ON PDP11/20 WITH CORE MEMORY TAKES APPROXIMATELY TWO MINUTES. CONSIDERABLY LESS FOR FASTER MACHINES OR MEMORIES.

3.0 STARTING ADDRESS

200 FOR ANY MODE OF OPERATION. NORMAL START UP WITH ALL SWITCHES DOWN.

4.0 PROGRAM CONTROL MODES & OPERATOR ACTION

PAPER TAPE LOADING
RKDF DUMP MODE
RKDF CHAIN MODE
ACT11

- 4.1 PAPER TAPE LOADING
- 4.1.1 LOAD PROGRAM INTO MEMORY USING STANDARD PROCEDURE FOR .ABS TAPES.
- 4.1.2 MAKE SURE THAT THE DRIVES TO BE CHECKED ARE LOADED WITH DISKS AND ARE IN "RUN" "WRT ENABLE" THEM. CHECK THAT "WRT PROT" LIGHT ON THESE DRIVES IS OFF. PUT DRIVES THAT ARE NOT TO BE TESTED ON "LOAD".
- 4.1.3 LOAD ADDRESS 200
- 4.1.4 SET SWITCHES IF DESIRED (SEE SEC 7.0) IF TESTING ON SIMULATOR PUT SW 10 UP.
- PRESS START.
- 4.1.5 THE PROGRAM IDENTIFIES ITSELF (NAME, MAINDEC NO.). THEN THE FOLLOWING QUESTION IS ASKED:

DRIVES TO BE TESTED?

THE USER SHOULD TYPE IN THE DRIVE NUMBERS THAT ARE IN "RUN" AND TO BE TESTED. CARRIAGE RETURN SHOULD TERMINATE THE STRING. IF AN RK-DSF IS TO BE TESTED, TYPE THE SUFFIX 'F' WITH THE FIRST DRIVE OF THE PAIR. FOR EXAMPLE, IF DRIVES 2 AND 3 ARE ON AN RK-DSF, TYPE ONLY 2F.

EXMP: DRIVES TO BE TESTED? 0,1,2<CR>

THE DRIVES DO NOT HAVE TO BE IN LOGICAL ORDER.

EXMP: DRIVES TO BE TESTED? 2,4<CR>

IF ANY ONE DRIVE IS TO BE TESTED, TYPE IN THAT NUMBER. IT DOES NOT HAVE TO BE DRIVE 0.

THIS A NORMAL SEQUENCE WITH DRIVES 0,1 WOULD BE:

```

RK!!! LOGIC TEST II
MAINDEC-11-DZPKK-D
DRIVES TO BE TESTED? 0,1<CR>

```

- 4.1.6 THERE IS A "RUBOUT" FEATURE WHICH ALLOWS RUBBING OUT ANY NUMBER OF CHARACTERS THAT WERE TYPED IN WRONG. THE RUBBED OUT CHARACTERS ARE ECHOED BACK WITHIN SLASHES.

"IU" DELETES THE ENTIRE LINE

- 4.1.7 IF REPLY TO ANY OF THE ABOVE QUESTION IS IN A WRONG FORMAT (EX: 012<CR>; 0, B<CR>; 0, A<CR>; M<CR> ETC), IT IS AUTOMATICALLY REJECTED, A "???" IS PRINTED OUT:

THE CORRECT ANSWER CAN NOW BE RETYPED AGAIN.

F01

SEG 0005

4.1.8 THE DRIVE NUMBER BEING TESTED OUT IS PRINTED:

DRIVE N : N=0,1,...,7
IF THE DRIVE IS AN RK-DSF, AN F IS APPENDED

AT THE END OF A PASS THE FOLLOWING TYPE-OUT OCCURS

END PASS # X

WHERE X= PASS NUMBER (1,2,3---), CONTROL IS PASSED TO THE BEGINNING OF THE PROGRAM AND RE-EXECUTION BEGINS. NO QUESTIONS ARE TO BE ANSWERED AGAIN.

4.1.9 ERROR FREE PASSES OF THE PROGRAM APPEAR AS SHOWN BELOW.

```
RK11 LOGIC TEST II
MAINDEC-11-DZRkk-D
DRIVES TO BE TESTED*
J 1<CR>
DRIVE 0
DRIVE 1
END PASS # 1
  0
DRIVE 1
END PASS # 2
...
...
```

4.2 RKDP DUMP MODE

4.2.1 THE PROGRAM IS LOADED INTO THE MEMORY BY THE RKDP MONITOR

4.2.2 START AS NORMALLY USING SA 200

4.2.3 THE PROGRAM IDENTIFIES ITSELF (NAME MAINDEC NO.). ON FINDING OUT THAT THE LOADING WAS BY RKDP (DUMP MODE), THE FOLLOWING MESSAGE APPEARS:

'TO TEST DRIVE 'N' HALT PROGRAM, REMOVE RKDP PACK AND REPLACE IT WITH A WORK PACK, CLEAR LOCATION 40, AND RESTART PROGRAM'

IF DRIVE 'N' IS TO BE TESTED, THE RKDP PACK ON THAT DRIVE SHOULD BE REPLACED BY ANOTHER PACK, THE DRIVE SHOULD BE PUT ON 'WRT ENABL' (BECAUSE RKDP WRITE PROTECTS THE DRIVE).

IF DRIVE 'N' IS NOT TO BE CHECKED, THEN THE MESSAGE SHOULD BE IGNORED.

AFTER THIS, THE SEQUENCE OF QUESTIONING IS AS EXPLAINED IN SEC 4.1.5.

4.3 RKDP CHAIN MODE

THE PROGRAM IS CHAIN-LOADED FROM THE RKDP PACK ON DRIVE 'N'. AFTER THE PROGRAM IDENTIFIES ITSELF THE FOLLOWING PRINTOUT OCCURS.

'DRIVE 'N' NOT TESTED'

THERE IS NO OPERATOR INTERVENTION REQUIRED. THE PROGRAM FINDS OUT THE NUMBER OF DRIVES PRESENT.

4.4 ACT11 MODE

THE PROGRAM IS LOADED BY THE ACT11 MONITOR. ON STARTING, IDENTIFIES ITSELF, ASCERTAINS THE NUMBER OF DRIVES AND PROCEEDS WITH THE EXECUTION OF THE TESTS AS BEFORE.

5.2 DRIVE SELECTION

IF ANY PARTICULAR DRIVE IS TO BE SELECTED FOR TESTING, PUT THAT DRIVE ON 'RUN', 'WRITE ENABLE', 'PU' REST OF THE DRIVES ON 'LOAD', 'WRITE LOCK' AND IN REPLY TO THE QUESTION 'VES TO BE TESTED?') TYPE IN THE DRIVE NUMBER FOLLOWED BY CR. SEE SEC 4.1.5.

6.0 DRIVE-LESS TEST

USE RK11 BASIC LOGIC TEST I, WHICH IS ACTUALLY THE FIRST PART OF THE TWO-PART RK11 BASIC LOGIC TESTS. SEE SEC 1.0. 2.2.

7.0 SWITCH OPTIONS

IF THE PROGRAM IS BEING RUN ON A SWITCHLESS PROCESSOR (I.E. AN 11/34) THE PROGRAM WILL DETERMINE THAT THE HARDWARE SWITCH REGISTER IS NOT PRESENT AND WILL USE A 'SOFTWARE' SWITCH REGISTER. THE 'SOFTWARE' SWITCH REGISTER IS LOCATED AT LOCATION 176 (8). THE SETTINGS OF THE 'SOFTWARE' SWITCHES ARE CONTROLLED THROUGH A KEYBOARD ROUTINE WHICH IS CALLED BY TYPING A 'CONTROL G'. THE PROGRAM WILL RECOGNIZE THE 'CONTROL G' whenever the program enters the scope routine or begins a new test. the 'SOFTWARE' SWITCH VALUES ARE ENTERED AS AN OCTAL NUMBER IN RESPONSE TO THE PROMPT FROM THE SWITCH ENTRY ROUTINE:

'SWR = NNNNNN NEW ='

EACH TIME SWITCH SETTING ARE ENTERED, THE ENTIRE SWITCH REGISTER IMAGE MUST BE ENTERED. LEADING ZEROS ARE NOT REQUIRED. 'RUBOUT' AND 'CONTROL U' FUNCTIONS MAY BE USED TO CORRECT TYPING ERRORS DURING SWITCH ENTRY.

ON PROCESSORS WITH HARDWARE SWITCH REGISTERS, THE 'SOFTWARE' SWITCH REGISTER MAY BE USED. IF THE PROGRAM FINDS ALL 16 SWITCHES IN THE 'UP' POSITION, ALL SWITCH REGISTER REFERENCES WILL BE TO THE 'SOFTWARE' REGISTER AND THE PROCEDURES DESCRIBED ABOVE MUST BE FOLLOWED.

SW<15>=1 HALT ON ERROR
 SW<14>=1 LOOP ON TEST
 SW<13>=1 INHIBIT ERROR PRINTOUTS
 SW<12>=1 CYCLE ON ERROR TO THE PREVIOUS
 'SCOPE' STATEMENT
 SW<11>=1 INHIBIT ITERATIONS
 SW<10>=1 TESTING ON SIMULATOR
 SW<09>=1 LOOP ON SPECIFIC ERROR
 SW<08>=1 LOOP ON TEST AS PER S.1<07:00>
 SW<06>=1 DROP THE DRIVE AFTER MAXIMUM
 ALLOWABLE NUMBER OF ERRORS OCCUR

7.1 SW 15>

THE PROGRAM HALTS ON ENCOUNTERING AN ERROR, AFTER TYPING OUT THE ERROR MESSAGE AND PERTINENT INFORMATION. PRESSING "CONTINUE" RESTORES NORMAL OPERATION OF THE PROGRAM.

7.2 SW<14>

THE PROGRAM LOOPS ON THE SUBTEST THAT IS BEING EXECUTED WHEN THE SWITCH IS PUT ON. THIS SWITCH IS USED NORMALLY ALONG SW 15. SEE SEC 8.0.

7.3 SW <13>

THIS SWITCH INHIBITS ALL ERROR MESSAGES. NORMALLY USED WHEN LOOPING ON TEST (SW 14) OR LOOPING ON ERROR (SW 9).

7.4 SW <12>

THIS SWITCH ALLOWS THE PROGRAM TO CYCLE FROM THE POINT OF ERROR TO THE PREVIOUS SCOPE STATEMENT. NOTE THAT IN DOING SO ANY INITIALIZATION BEING DONE AT THE BEGINING OF THE SUBTEST WILL BE DONE AGAIN AND AGAIN. SEE SEC 8.0 FOR DIFFERENT SCOPE LOOPS AVAILABLE.

7.5 SW <11>

EACH SUBTEST WILL BE EXECUTED ONLY ONCE. NORMALLY AF THE FIRST PASS, EACH SUBTEST IS ITERATED A NUMBER OF TIMES (USUALLY 50, 5 IN SOME CASES). SETTING THIS SWITCH INHIBITS ITERATIONS, SO THAT QUICK PASSES CAN BE MADE.

7.6 SW <10>

THIS SWITCH WHEN SET INDICATES THAT TESTING IS BEING DONE ON A SIMULATOR. THE SWITCH SHOULD BE PUT UP BEFORE START-ING THE PROGRAM. NOTE THAT RK11C IS NOT COMPATIBLE WITH THE SIMULATOR.

7.7 SW <09>

THIS SWITCH PROVIDES THE TIGHTEST POSSIBLE SCOPE LOOP. NOTE THAT THE SW12 THE INITIALIZATION OF PARAMETERS AT THE BEGINNING OF THE SUBTEST MAY NOT BE DONE IN THIS CASE. THIS SWITCH IS HELPFUL WHEN A PARTICULAR PART OF A SUBTEST IS BEING REPEATED USING DIFFERENT PARAMETERS AND YOU WANT TO SCOPE ON THE PARAMETER IN ERROR. (EXAMPLE: RKDA IS BEING WRITTEN AND READ BACK WITH COUNT PATTERNS FROM 1 TO 177777. PATTERN 561 IS GIVING ERROR, YOU MIGHT NOT WANT TO GO THROUGH THE 560 PATTERNS BEFORE HITTING ERROR ON THE 561TH PATTERN. IN THIS CASE SW 9 WILL GIVE YOU A SCOPE LOOP ON THE 561TH PATTERN ONLY

7.8 SW <08>

THIS SWITCH IS USED TO SELECT A PARTICULAR TEST (AS PER SW<00-07>) FOR EXECUTION AND SUBSEQUENT LOOPING. THUS IF TEST 15 IS TO BE SELECTED THE SWITCH SETTING WOULD BE 000415. IT SHOULD BE NOTED THAT BEFORE SELECTING TEST 15, ALL THE PREVIOUS TESTS (1-14) WILL BE EXECUTED.

7.9 SW<06>

THIS SWITCH ALLOWS THE PROGRAM TO DROP A DRIVE FROM THE SELECTION LIST AND TESTING AFTER MAXIMUM ALLOWABLE ERROR COUNT (TOTAL NUMBER OF ERRORS) ON THAT DRIVE IS EXCEEDED. THE MAXIMUM ALLOWABLE ERROR COUNT IS 5, AFTER 5 ERRORS HAVE OCCURED DRIVE IS DROPPED AND A MESSAGE (DRIVE # XXX DROPPED) IS PRINTED.

8.0 SCOPE LOOPS

THERE ARE THREE KINDS OF SCOPE LOOPS AVAILABLE

1. SW14: LOOPING IS DONE FOR THE ENTIRE SUB-TEST
2. SW12: LOOPING IS DONE FROM THE POINT OF ERROR BACK TO THE PREVIOUS 'SCOPE' STATEMENT.
3. SW09: PROVIDE THE TIGHTEST POSSIBLE SCOPE LOOP SEE SEC. 7.7

EXAMPLE:

TST1: SCOPE
:

```

INITIALIZATION
:
ERROR 1
:
ERROR 2
:

```

ERROR 3

ERROR 4

TST2: SCOPE

THE SEQUENCE OF LOOPING FOR DIFFERENT CASES IS EXPLAINED BELOW. NOTE THAT 'TST1' AND 'TST2' ARE TAGS WHICH DEFINE THE BOUNDARY OF A TEST, (IN THIS CASE TEST 1). TEST 1 STARTS AT 'TST1' AND ENDS JUST BEFORE 'TST2'.

IN THE ILLUSTRATION BELOW --> INDICATES THE POINT FROM WHERE RETURN IS MADE AND LOOPING IS DONE.

1. ERROR 2 OCCURS, SW 14 SET.

TST1..ERROR 2..TST2-->TST1..ERROR 2..TST2-->TST1...

2. ERROR 2 OCCURS, SW 12 SET.

TST1...ERROR 2-->TST1...ERROR2-->TST1...

3. ERROR 2,3; SW 14 SET.

TST1..ERROR 2..ERROR 3..TST2-->TST1..ERROR 2..ERROR 3..TST2-->TST1...

4. ERROR 2,3; SW 12 SET.

TST1...ERROR 2-->TST1...ERROR 2-->TST1....

NOTE THAT LOOPING IS DONE FROM THE VERY FIRST ERROR ENCOUNTERED. THE MORE BASIC AND ERROR THE EARLIER IT OCCURS AND IS DETECTED AND SHOULD BE FIXED.

IN THE ABOVE EXAMPLE NO PART OF THE SUB-TEST IS BEING REPEASING DIFFERENT PARAMETERS, HENCE IT SO HAPPENS THAT SW 9 AND 12 GIVE THE SAME KIND OF LOOPS. THE EXAMPLE BELOW WILL DEMONSTRATE THE DIFFERENCE BETWEEN SW 9 AND 12.

TST1: SCOPE
:

INITIALIZATION

ERROR 1

MOV #15,SLPERR

:'SLPERR' CONTAINS
:THE ADDRESS TO LOOP
:BACK ON ERROR- SW 9

IS:

ER

I N REPETITIONS

:

I

TST2: SCOPE ----

1. SW 12 SET, ERROR 2 OCCURS DURING K.TH REPETITIONS

TST1..1.2...K.ERROR 2-->TST1..1.2...K.ERROR 2-->TST1..

2. SW 9 SET, ERROR 2 OCCURS DURING K.TH REPETITION

1S..K..ERROR 2-->1S..K..ERROR 2-->1S...

9.0 PROGRAM STRUCTURE

THERE ARE THREE DISTINCT PARTS OF THE PROGRAM.

SET-UP PHASE
DRIVE-DEPENDENT CONTROLLER TESTS

9.1 SET-UP PHASE

SETTING UP OF INITIAL POINTERS, VECTORS, TABLES IS DONE IN THIS PART. IN THIS SECTION THE DECISION IS MADE ABOUT THE PROGRAM MODE-PAPER TAPE, RKDP DUMP, CHAIN OR ACT11. IF IN A NON-INTERVENTION MODE (CHAIN, ACT11) NUMBER OF DRIVES AND THE TYPE OF CONTROLLER IS FOUND OUT. FLAGS ARE SET TO INDICATE WHICH DRIVES ARE TO BE TESTED, ETC.

9.2 DRIVE DEPENDENT CONTROLLER TESTS

THIS SECTION FORMS A MAJOR PART OF THE PROGRAM WHEREIN MOST OF THE CONTROLLER IS CHECKED.

JUST BEFORE ENTERING THIS SECTION THE PROGRAM FINDS OUT WHICH DRIVE IS TO BE CHECKED. IF IN RKDP CHAIN MODE, DRIVE 'N' IF PRESENT, IS SKIPPED AND THE NEXT AVAILABLE DRIVE IS SELECTED.

THE DRIVE NUMBER BEING TESTED IS PRINTED OUT:

DRIVE N ;N=0,1,2...7

THE TESTING IS DONE IN A LOGICAL HIERCHY, SIMPLER THINGS FIRST, THEN MORE COMPLEX AND SO ON.

IN ONE OF THE TESTS THE ENTIRE DISK PACK IS FORMATTED, CHECKS ARE MADE FOR ERROR CONDITIONS. THE FIRST WORD OF EVERY SECTOR IS WRITTEN AS A PSUEDO-HEADER, REFLECTING THE ABSOLUTE ADDRESS OF THAT SECTOR (DRIVE #, CYLINDER #, SURFACE #, SECTOR #). EXAMPLE: THE PSUEDO-HEADER FOR SECTOR 5, SURFACE 0, CYLINDER 20, DRIVE 0 WOULD BE 001005.

IN THE NEXT TEST THE HEADERS FROM THE ENTIRE PACK ARE READ AND CHECKED FOR CORRECTNESS. IN A SUBSEQUENT TEST ALL THE PSUEDO-HEADERS ARE READ AND VERIFIED.

ALL THE FUNCTIONS ARE CHECKED OUT. 'SEEK' IS CHECKED IN THE THREE DIFFERENT VELOCITY MODES (HIGH, MEDIUM, LOW). VARIOUS ERRORS LIKE 'NXD', 'NXC', ETC. ARE SIMULATED AND CHECKED.

HARDWARE POGIC IS CHECKED USING ALL THE DRIVES THAT HAVE BEEN INDICATED.

AT THE END OF THIS SECTION, A CHECK IS MADE IF ALL INDICATED DRIVES HAVE BEEN TESTED. IF NOT, CONTROL IS TRANSFERRED TO THE BEGINNING OF THIS SECTION.

THUS ONE PASS OF THE PROGRAM INVOLVES DOING

1. SUBTEST #1 ONCE
2. DRIVE-DEPENDENT TESTS FOR ALL THE SELECTED DRIVES.

10.C ERROR REPORTING

THE ERROR TABLE STARTING AT \$ERRTB CONTAINS INFORMATION PERTAINING TO EVERY ERROR THAT CAN OCCUR. EACH ITEM IN THE TABLE CONSISTS OF FOUR ENTRIES.

- A. EM - THIS IS A POINTER TO THE ERROR MESSAGE TO BE TYPED OUT WHEN THE ERROR OCCURS.
- B. DH - THIS IS A POINTER TO THE DATA HEADER TO BE TYPED OUT.
- C. DT - THIS IS A POINTER TO THE DATA WHICH IS TO BE TYPED TYPED OUT UNDER THE HEADERS.
- D. D - THIS IS A TERMINATOR SIGNIFYING THE END OF THE ITEM.

THE ERROR CALL IS AN EMT INSTRUCTION WITH ITS LOWER BYTE ENCODED TO INDICATE THE ERROR NUMBER. THUS OR 1" WOULD BE (EMT+1) IE 104001.

EVERY ERROR CORRESPONDS TO AN ITEM IN THE ERROR TABLE. THUS "ERROR 14" WOULD CORRESPOND TO ITEM 14. AS FAR AS POSSIBLE, THE ERROR MESSAGES HAVE BEEN KEPT SHORT, BUT CLARITY IS NOT SACRIFICED FOR BREVITY. INSPITE OF THIS, IF THE USER FINDS A NEED, HE CAN LOOK UP THE ENTIRE ERROR MESSAGE IN THE ERROR ITEMS TABLE FOUND IN THE BEGINNING OF THE LISTINGS. THUS FOR "ERROR 14", "ITEM 14" IN THE ITEM TABLE CAN BE LOOKED UP. WHEN THE ERROR INSTRUCTION IS EXECUTED A TRAP OCCURS TO THE ERROR HA LOCATED AT \$ERRR WHICH PROCESSES THE ERROR CALL. SEE SEC 12.3

11.C ERROR INTERPRETATION

WHENEVER AN ERROR MESSAGE IS PRINTED OUT, ALL REGISTERS AND OTHER DATA PERTAINING TO THE ERROR ARE

ALSO GIVEN. RKDS, RKER...RKBA INDICATE THE CONTENTS OF THE CORRESPONDING REGISTERS AT THE TIME OF ERROR.

EVERY ERROR MESSAGE CONTAINS A PC. THIS PC INDICATES THE POSITION IN PROGRAM WHERE THE ERROR CALL IS LOCATED. THE ERROR MESSAGE, BECAUSE OF PRACTICAL CONSIDERATIONS IS MADE SHORT AND MEANINGFUL. THE USER IS ADVTO LOOK UP THE PC IN THE PROGRAM LISTING, WHERE HE WILL FIND MORE INFORMATION ABOUT THE ERROR. IN MANY INSTANCES, A SINGLE FAULT WILL GIVE RISE TO MORE THAN ONE ERROR REPORT. A LITTLE DELIBERATION AND CAREFUL EXAMINATION OF THE DATA GIVEN WILL BE CERTAINLY VERY HELPFUL IN PINPOINTING THE FAULT. A BRIEF EXPLANATION OF WHAT IS BEING CHECKED IN THE SUBTEST IS GIVEN AT THE BEGINNING OF EVERY SUBTEST. ALL THE NUMBERS GIVEN WITH ERROR MESSAGES ARE IN OCTAL.

12.0 HANDLERS AND COMMON ROUTINES

THE COMPOSED ROUTINES USED IN THE PROGRAM ARE CALLED IN TWO WAYS.

- A. AS A SUBROUTINE THROUGH 'JSR' CALL
- B. THROUGH A 'TRAP' HANDLER

12.1 TRAP HANDLER

MANY COMMONLY USED ROUTINES IN THE PROGRAM ARE CALLED USING THE TRAP INSTRUCTION AND THE 'TRAP' HANDLER. THE LOWER BYTE OF THE TRAP INSTRUCTION IS ENCODED DIFFERENTLY FOR DIFFERENT ROUTINES. THE TRAP HANDLER IS LOCATED AT '\$TRAP'. WHEN A CALL FOR A ROUTINE IS EXECUTED, A TRAP OCCURS TO THE HANDLER 'TRAP'. THE HANDLER PICKS UP THE LOWER BYTE OF THE "CALL INSTRUCTION" AND USES IT TO FORM THE STARTING ADDRESS OF THE ROUTINE TO GO TO FOR SERVICE.

12.2 SCOPE HANDLER

THE 'IOT' TRAP IS USED BY THE 'SCOPE' STATEMENT. WHEN 'SCOPE' IS EXECUTED, AN IOT TRAP OCCURS TO MEMORY LOCATION '\$SCOPE'. THE SCOPE HANDLER STARTS AT '\$SCOPE'. DEPENDING ON THE SWITCH SETTINGS THE HANDLER DECIDES TO LOOP ON TEXT, INHIBIT ITERATIONS ETC. THERE ARE CERTAIN POINTERS AND FLAGS WHICH ARE ADJUSTED. THUS, IT IS NOT ADVISABLE START THE PROGRAM AT ANY GIVEN LOCATION SINCE THE VARIOUS POINTERS AND FLAGS MAY NOT BE CORRECTLY ADJUSTED.

12.3 ERROR HANDLER

AN EMT TRAP INSTRUCTION IS USED BY THE ERROR CALL. THE LOWER BYTE IS ENCODED TO GIVE DIFFERENT ERROR CALLS. (EX: ERROR 1 = 104000+1; ERROR 16 = 104000+16). WHEN THE ERROR STATEMENT IS EXECUTED, A

TRAP OCCURS TO MEMORY LOCATION '\$ERROR'. THE ERROR HANDLER IS LOCATED AT '\$ERROR'. THE HANDLER FORMS THE POINTER TO ERROR TABLE, WHICH IS USED IF AN ERROR MESSAGE IS TO BE TYPED DEPENDING ON THE SWITCH SETTINGS. A DECISION ABOUT HALTING ON ERROR, INHIBITING TYPEOUT, LOOPING ON ERROR ETC. IS MADE. IF AN ERROR MESSAGE IS TO BE TYPED OUT AN EXIT IS MADE TO THE ERROR MESSAGE TYPEOUT ROUTINE LOCATED AT '\$ERRTYP'.

12.4 CONTROL RESET ROUTINE

THE CALL FOR THIS ROUTINE IS "CNT.RESET" AND IS AN ENCODED 'TRAP' INSTRUCTION. WHEN "CNT.RESET" IS EXECUTED THE CONTROL RESET ROUTINE STARTING AT "CN.RST" IS ENTERED. A CONTROL RESET IS ISSUED. THE PROGRAM WAITS TILL THE CONTROL READY SETS, ON WHICH THE ROUTINE IS EXITED. IF CONTROL READY DOES NOT SET WITHIN A CERTAIN TIME AN ERROR IS REPORTED. THE PC TYPED OUT IS THE LOCATION WHERE THE "CNT.RESET" CALL IS LOCATED. THE WAITING TIME IS 2.8 MS FOR 11/20 AND 560 US FOR 11/45 WITH BIPOLAR MEMORY.

12.5 CONTROL READY ROUTINE

THIS ROUTINE IS CALLED BY "CNT.RDY" (AN ENCODED 'TRAP' INSTRUCTION) AND IS LOCATED AT "CN.RDY". THE ROUTINE WAITS FOR THE CONTROL READY TO SET AND WHEN IT DOES, EXITS. IF CONTROL READY DOES NOT SET WITHIN A SPECIFIED TIME AN ERROR MESSAGE IS GIVEN

CNTRL RDY DIDN'T SET
PC = XXXXXX RKCS = YYYYYY

THE PC IS THE LOCATION AT WHICH THE "CNT.RDY" CALL IS LOCATED. THE WAITING TIME IS 949 MS FOR 11/20 AND 189 MS FOR 11/45 WITH BIPOLAR MEMORY.

12.6 DRIVE RESET ROUTINE

THE DRIVE - RESET ROUTINE IS LOCATED AT "DRESET" AND IS CALLED BY A "JSR". IT ISSUES A DRIVE RESET AND WAITS FOR THE R/W/S RDY TO SET, ON WHICH THE ROUTINE IS EXITED. THE WAITING TIME IS 4959 MS FOR 11/20 AND 991 MS FOR 11/45 WITH BIPOLAR MEMORY.

12.7 TIME DELAY ROUTINE

THIS ROUTINE PROVIDES A VARIABLE TIME DELAY. THE CALL IS DELAY ,N WHERE N=1 TO 177777 (OCTAL) TIME DELAY PROVIDED= 7.5 TIMES(X) N MICRO SECS FOR 11/20, 1.5N US FOR 11/45 (N CONVERTED TO DECIMAL BEFORE COMPUTING DELAY) IF THE USER WANTS TO CHANGE THE DELAY AT ANY POINT IT CAN BE DONE BY SIMPLY CHANGING VARIABLE 'N'.

12.8 WAIT FOR INTERRUPT ROUTINE

THIS ROUTINE PROVIDES A VARIABLE TIME LIMIT DURING WHICH RK11 INTERRUPT MAY OCCUR. THE IS
 MAT.INT N N=1 TO 1777777 (OCTAL)
 WAITING TIME=7.5 TIMES(X) N US FOR 11 20, 1.5N US

FOR 11 45 UPON ENTERING THE ROUTINE CPU PRIORITY IS DROPPED SO THAT RK11 CAN INTERRUPT.

12.9 OTHER ROUTINES

THERE ARE OTHER COMMONLY USED ROUTINES AS LISTED BELOW.

STYPE:
 TYPE ROUTINE FOR TYPING OUT ASCII STRINGS.
 LOCATED AT "STYPE"
 CALLED BY "TYPE"

STYPOC:
 ROUTINE FOR TYPING OUT OCTAL NUMBERS.
 LOCATED AT "STYPOC"
 CALLED BY "TYPOC"

STYPOD:
 ROUTINE FOR TYPING OUT DECIMAL NUMBERS.
 LOCATED AT "STYPOD"
 CALLED BY "TYPOD"

SRDLIN:
 ROUTINE FOR INPUTTING ASCII STRINGS FROM TTY.
 LOCATED AT "SRDLIN"
 CALLED BY "RLIN"

SERRTYP:
 ROUTINE FOR TYPING OUT ERROR MESSAGES.
 LOCATED AT "SERRTYP"
 CALLED BY "JSR SERRTYP"

SPWRON:
 ROUTINE FOR HANDLING POWER FAILURE.
 LOCATED AT "SPWRON"
 CALLED WHEN THERE IS A POWER FAILURE.

SPWRUP:
 ROUTINE FOR HANDLING POWER UP AFTER A POWER FAIL.
 LOCATED AT "SPWRUP"
 CALLED WHEN POWER RETURNS AFTER HAVING GONE DOWN.

13.0 UNEXPECTED TIMEOUTS AND RK11 INTERRUPTS

WHEN AN UNEXPECTED TIMEOUT OCCURS, THE PC AT WHICH TIME OUT OCCURED IS TYPED OUT AND THE PROGRAM HALTS.

IF IT IS INTACT, IT CAN BE RESTARTED BY PRESSING CONTINUE.

IF AN UNEXPECTED RMI INTERRUPT OCCURS THE PROGRAM TYPES OUT THE PC AT WHICH THE INTERRUPT CAME IN AND THEN HALTS. PRESSING CONTINUE WOULD RESTART THE PROGRAM FROM BEGINING. SW 9- LOOPING CAITY IS PROVIDED AS A TROUBLE SHOOTING AID.

14.2 QUICK VERIFYING MODE

THE FIRST PASS OF THE PROGRAM IS A QUICK VERIFYING MODE. ALL THE TESTS ARE DONE ONLY ONCE, ON SUBSEQUENT PASSES THE TESTS ARE ITERATED (NORMALLY 50 TIMES, 5 IN SOME CASES). THUS THE FIRST PASS TAKES A SHORTER TIME TO COMPLETE, WHEREAS SUBSEQUENT PASSES TAKE MORE TIME.

23	OPERATIONAL SWITCH SETTINGS
48	BASIC DEFINITIONS
158	TRAP CATCHER
167	STARTING ADDRESS(ES)
168	ACT11 HOOKS
177	COMMON TAGS
223	ERROR POINTER TABLE
265	INITIALIZE THE COMMON TAGS
1002	TYPE PROGRAM NAME
1007	GET VALUE FOR SOFTWARE SWITCH REGISTER
1312	T1 CHECK THAT THE DRIVES THAT ARE NOT SPECIFIED ARE NOT FOUND TO BE PRESENT
1388	T2 FIND OUT NEXT DRIVE TO BE CHECKED
1442	T3 CHECK THAT DRIVE IS SUPPLIED WITH POWER-DPL BIT
1493	T4 CHECK THAT 'DRIVE UNSAFE' IS CLEAR, 'MDEN' IS SET, 'WPS' IS CLEAR
1528	T5 CHECK THAT 'DRIVE READY' IS SET IN RKDS
1549	T6 CHECK THAT 'SOA' BIT CAN SET
1568	T7 CHECK THAT 'SECTOR COUNTER' CAN COUNT FROM 0-13
1666	T10 CHECK THAT SC-SA CAN BE GENERATED
1704	T11 CHECK THAT 'R/W'S RDY' IS SET & 'SIN' IS CLEAR
1729	T12 CHECK 'DRIVE RESET'
1786	T13 CHECK 'SEEK' TO CYLINDER 0
1850	T14 CHECK R/W'S RDY IS CLEAR WHEN HEADS ARE IN MOTION
1900	T15 CHECK 'WRITE' FORMAT FUNCTION-CYLINDER 0, SECTOR 0
2013	T16 CHECK 'READ FORMAT' FUNCTION-CYLINDER 0, SECTOR 0
2121	T17 CHECK 'READ' FUNCTION-CYLINDER 0, SECTOR 0
2246	T20 CHECK 'WRITE FORMAT' -CYLINDER 0, SECTOR 0-13
2344	T21 CHECK 'READ FORMAT' -CYLINDER 0, SECTOR 0-13
2454	T22 CHECK 'READ', CYLINDER 0, SECTORS 0 TO 13
2616	T23 CHECK 'WRITE FORMAT' OF THE DISK
2742	T24 CHECK 'READ FORMAT' FOR THE ENTIRE DISK
2902	T25 CHECK 'READ' OF THE ENTIRE DISK
3035	T26 CHECK 'SEEK' FUNCTION, WITH DIFFERENT VELOCITY MODES
3145	T27 CHECK DRIVE RESET FROM LAST CYLINDER
3262	T30 'WRITE' - 256 WORD BLOCK ON SECTOR 0, CYLINDER 0
3374	T31 CHECK THAT WRITE WAS DONE CORRECTLY
3454	T32 CHECK 'READ CHECK' FUNCTION - CYLINDER 0, SECTOR 0
3541	T33 CHECK THE 'WRITE CHECK' FUNCTION - ON CYLINDER 0, SECTOR 0
3630	T34 CHECK THAT IBA INHIBITS INCREMENTING OF RKBA
3743	T35 CHECK THAT RK11 INTERRUPTS WHEN IDE IS SET
3808	T36 CHECK THAT WITH IDE SET RK11 INTERRUPTS AFTER INITIATION & COMPLETION OF SEEK
3920	T37 CHECK THAT WITH IDE SET RK11 INTERRUPTS WHEN READ IS DONE
3995	T40 CHECK THAT RK11 INTERRUPTS AT BRS ONLY
4078	T41 SIMULATE & CHECK 'OVR' ERROR
4156	T42 SIMULATE & CHECK PGE ERROR
4222	T43 SIMULATE & CHECK NXM ERROR
4298	T44 SIMULATE & CHECK NXD ERROR
4376	T45 SIMULATE & CHECK NXC ERROR
4452	T46 SIMULATE & CHECK NXS ERROR
4525	T47 SIMULATE & CHECK WCE
4602	T50 CHECK THAT SSE STOPS ALL CONTROL ACTION ON SOFT ERROR
4671	T51 CHECK THAT RK11 INTERRUPTS ON SOFT ERROR WHEN SSE & IDE ARE SET
4738	T52 CHECK THE MEX BITS IN RKCS
4807	T53 TRANSFER FROM DISK TO TTY
4903	T54 CHECK THAT RKBA CAN COUNT CORRECTLY
4963	T55 CHECK FOR RK-05F
4976	T56 END OF PROGRAM

MAINDEC-11-DZRKK-D MACY:1 27(1006) 04-OCT-76 16:06
 DZRKKD.P11 22-SEP-76 08:47 TABLE OF CONTENTS

SEQ 0017

5003	TST	CHECK HARDWARE POLLING LOGIC
5007	END OF	PASS ROUTINE
5008	GT2RG:	ROUTINE FOR GETTING RKCS, RKER
5009	GT3RG:	ROUTINE FOR GETTING RKCS, RKER, RKDS
5010	GT4RG:	ROUTINE FOR GETTING RKCS, RKER, RKDS, RKDA
5015	TYERM:	SPECIAL ERROR MESSAGE ROUTINE
5027	BOAD BOAY:	BREAK DISK ADDRESS INTO SEC, SUR, CYL, DRIVE
5028	SHFTAT:	SHIFT RIGHT ROUTINE
5031	CHKHE:	CHECK FOR 'ERR' OR
5032	CHKHE1:	CHECK FOR 'ERR' OR
5033	CHKDA:	CHECK IF RKDA INCREMENTED CORRECTLY
5034	CHKWC:	CHECK IF RWKC OVERFLOWED
5035	CHKER:	CHECK RKER CONTENTS
5036	TSTRWS:	WAIT FOR R/W/S RDY ROUTINE
5037	DRESET:	DRIVE RESET ROUTINE
5038	TSTSIN:	CHECK 'SIN' ROUTINE
5039	DELAY:	TIME DELAY ROUTINE
5040	WAIT INT:	WAIT FOR INTERRUPT ROUTINE
5041	CHKCRDY:	CHECK CONTROL READY
5042	CON.RESET:	CONTROL REST ROUTINE
5043	CON.RDY:	WAIT FOR CONTROL READY ROUTINE
5044	SCOPE HANDLER:	ROUTINE
5045	ERROR HANDLER:	ROUTINE
5046	ERROR MESSAGE:	TYPEOUT ROUTINE
5047	TYPE:	ROUTINE
5027	CONVERT BINARY:	TO DECIMAL AND TYPE ROUTINE
5048	BINARY TO OCTAL:	(ASCII) AND TYPE
5049	TTY INPUT:	ROUTINE
5050	TRAP DECODER	
5051	TRAP TABLE	
5052	POWER DOWN AND UP:	ROUTINES
5053	ERROR MESSAGES	
5054	ERROR DATA POINTERS	
5055	ERROR HEADERS	

57
58
59
60
61
62
63
64
65
66
67
68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112

000015
000200
177776

177774
177772
177570
177570

000000
000001
000002
000003
000004
000005
000006
000007
000006
000007

000000
000040
000100
000140
000200
000240
000300
000340

100000
040000
020000
010000
004000
002000
001000
000400
000200
000100
000040
000020
000010
000004
000002
000001

CR= 15 :: CODE FOR CARRIAGE RETURN
CRLF= 200 :: CODE FOR CARRIAGE RETURN-LINE FEED
PS= 177776 :: PROCESSOR STATUS WORD
.EQUIV PS,PSW
STKLMT= 177774 :: STACK LIMIT REGISTER
PIRQ= 177772 :: PROGRAM INTERRUPT REQUEST REGISTER
DSWR= 177570 :: HARDWARE SWITCH REGISTER
DDISP= 177570 :: HARDWARE DISPLAY REGISTER

::*GENERAL PURPOSE REGISTER DEFINITIONS

R0= %0 :: GENERAL REGISTER
R1= %1 :: GENERAL REGISTER
R2= %2 :: GENERAL REGISTER
R3= %3 :: GENERAL REGISTER
R4= %4 :: GENERAL REGISTER
R5= %5 :: GENERAL REGISTER
R6= %6 :: GENERAL REGISTER
R7= %7 :: GENERAL REGISTER
SP= %6 :: STACK POINTER
PC= %7 :: PROGRAM COUNTER

::*PRIORITY LEVEL DEFINITIONS

PR0= 0 :: PRIORITY LEVEL 0
PR1= 40 :: PRIORITY LEVEL 1
PR2= 100 :: PRIORITY LEVEL 2
PR3= 140 :: PRIORITY LEVEL 3
PR4= 200 :: PRIORITY LEVEL 4
PR5= 240 :: PRIORITY LEVEL 5
PR6= 300 :: PRIORITY LEVEL 6
PR7= 340 :: PRIORITY LEVEL 7

::*"SWITCH REGISTER" SWITCH DEFINITIONS

SW15= 100000
SW14= 40000
SW13= 20000
SW12= 10000
SW11= 4000
SW10= 2000
SW09= 1000
SW08= 400
SW07= 200
SW06= 100
SW05= 40
SW04= 20
SW03= 10
SW02= 4
SW01= 2
SW00= 1
.EQUIV SW09,SW9
.EQUIV SW08,SW8
.EQUIV SW07,SW7
.EQUIV SW06,SW6
.EQUIV SW05,SW5
.EQUIV SW04,SW4
.EQUIV SW03,SW3
.EQUIV SW02,SW2

```

113 .EQUIV SW01,SW1
114 .EQUIV SW00,SW0
115
116 ;*DATA BIT DEFINITIONS (BIT00 TO BIT15)
117 100000 BIT15= 100000
118 040000 BIT14= 40000
119 020000 BIT13= 20000
120 010000 BIT12= 10000
121 004000 BIT11= 4000
122 002000 BIT10= 2000
123 001000 BIT09= 1000
124 000400 BIT08= 400
125 000200 BIT07= 200
126 000100 BIT06= 100
127 000040 BIT05= 40
128 000020 BIT04= 20
129 000010 BIT03= 10
130 000004 BIT02= 4
131 000002 BIT01= 2
132 000001 BIT00= 1
133
134 .EQUIV BIT09,BIT9
135 .EQUIV BIT08,BIT8
136 .EQUIV BIT07,BIT7
137 .EQUIV BIT06,BIT6
138 .EQUIV BIT05,BIT5
139 .EQUIV BIT04,BIT4
140 .EQUIV BIT03,BIT3
141 .EQUIV BIT02,BIT2
142 .EQUIV BIT01,BIT1
143 .EQUIV BIT00,BIT0
144
145 ;*BASIC "CPU" TRAP VECTOR ADDRESSES
146 ERRVEC= 4 ;: TIME OUT AND OTHER ERRORS
147 RESVEC= 10 ;: RESERVED AND ILLEGAL INSTRUCTIONS
148 TBITVEC=14 ;: "T" BIT
149 TRIVEC= 14 ;: TRACE TRAP
150 BPTVEC= 14 ;: BREAKPOINT TRAP (BPT)
151 IOTVEC= 20 ;: INPUT/OUTPUT TRAP (IOT) **SCOPE**
152 PWRVEC= 24 ;: POWER FAIL
153 EMTVEC= 30 ;: EMULATOR TRAP (EMT) **ERROR**
154 TRAPVEC=34 ;: "TRAP" TRAP
155 TKVEC= 60 ;: TTY KEYBOARD VECTOR
156 TPVEC= 64 ;: TTY PRINTER VECTOR
157 PIRQVEC=240 ;: PROGRAM INTERRUPT REQUEST VECTOR
158 .SBTTL TRAP CATCHER
159
160 ;*ALL UNUSED LOCATIONS FROM 4 - 776 CONTAIN A ".+2.HALT"
161 ;*SEQUENCE TO CATCH ILLEGAL TRAPS AND INTERRUPTS
162 ;*LOCATION 0 CONTAINS 0 TO CATCH IMPROPERLY LOADED VECTORS
163
164 000174 000000 ;:SOFTWARE DISPLAY REGISTER
165 000176 000000 ;:SOFTWARE SWITCH REGISTER
166 .SBTTL STARTING ADDRESS(ES)
167 000200 000137 002636 JMP @*START ;:JUMP TO STARTING ADDRESS OF PROGRAM
168 .SBTTL ACT11 HOOKS
    
```

169
170
171
172
173
174
175
176
177

000204
000046
020646
000052
000000
000204

::*****

:HOOKS REQUIRED BY ACT11

\$.SVPC=
.=46
\$.SENDAD
.=52
.WORD 0
.=\$.SVPC

:SAVE PC

::1)SET LOC.46 TO ADDRESS OF \$.SENDAD IN \$.SECP

::2)SET LOC.52 TO ZERO

::RESTORE PC

178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196
197
198
199
200
201
202
203
204
205
206
207
208
209
210
211
212
213
214
215
216
217
218
219
220
221
222
223
224
225
226
227
228
229
230
231
232
233

001100
001100 000000
001102 000
001103 000
001104 000000
001106 000000
001110 000000
001112 000000
001114 000
001115 001
001116 000000
001120 000000
001122 000000
001124 000000
001126 000000
001130 000000
001132 000000
001134 000
001135 000
001136 000000
001140 177570
001142 177570
001144 177560
001146 177562
001150 177564
001152 177566
001154 000
001155 002
001156 012
001157 000
001160 000000
001162 000000
001164 000000
001166 000000
001170 000000
001172 000000
001174 000000
001176 000000
001200 000000
001202 000000
001204 000000
001206 000000
001210 000000
001212 077
001213 015
001214 000012
001216 005015 051104 053111

.SBTTL COMMON TAGS

*THIS TABLE CONTAINS VARIOUS COMMON STORAGE LOCATIONS
*USED IN THE PROGRAM.

.=1100

\$CMTAG: .WORD 0
\$PASS: .WORD 0
\$STNM: .BYTE 0
\$ERFLG: .BYTE 0
\$ICNT: .WORD 0
\$LPADR: .WORD 0
\$LPERR: .WORD 0
\$ERTTL: .WORD 0
\$ITEMB: .BYTE 0
\$ERMAX: .BYTE 1
\$ERRPC: .WORD 0
\$GDADR: .WORD 0
\$BDADR: .WORD 0
\$GDDAT: .WORD 0
\$BDDAT: .WORD 0
\$AUTOB: .BYTE 0
\$INTAG: .BYTE 0
\$SWR: .WORD DSWR
DISPLAY: .WORD DDISP
\$TKS: 177560
\$TKB: 177562
\$TPS: 177564
\$TPB: 177566
\$NULL: .BYTE 0
\$FILLS: .BYTE 2
\$FILLC: .BYTE 12
\$TPFLG: .BYTE 0
\$REGAD: .WORD 0
\$REG0: .WORD 0
\$REG1: .WORD 0
\$REG2: .WORD 0
\$REG3: .WORD 0
\$REG4: .WORD 0
\$REG5: .WORD 0
\$REG6: .WORD 0
\$REG7: .WORD 0
\$REG10: .WORD 0
\$REG11: .WORD 0
\$TIMES: 0
\$ESCAPE: 0
\$QUES: .ASCII /?/
\$CRLF: .ASCII <15>
\$LF: .ASCIIZ <12>
MSG1: .ASCIIZ <15><12>/DRIVE PRESENT/

;; START OF COMMON TAGS
;; CONTAINS PASS COUNT
;; CONTAINS THE TEST NUMBER
;; CONTAINS ERROR FLAG
;; CONTAINS SUBTEST ITERATION COUNT
;; CONTAINS SCOPE LOOP ADDRESS
;; CONTAINS SCOPE RETURN FOR ERRORS
;; CONTAINS TOTAL ERRORS DETECTED
;; CONTAINS ITEM CONTROL BYTE
;; CONTAINS MAX. ERRORS PER TEST
;; CONTAINS PC OF LAST ERROR INSTRUCTION
;; CONTAINS ADDRESS OF 'GOOD' DATA
;; CONTAINS ADDRESS OF 'BAD' DATA
;; CONTAINS 'GOOD' DATA
;; CONTAINS 'BAD' DATA
;; RESERVED--NOT TO BE USED
;; AUTOMATIC MODE INDICATOR
;; INTERRUPT MODE INDICATOR
;; ADDRESS OF SWITCH REGISTER
;; ADDRESS OF DISPLAY REGISTER
;; TTY KBD STATUS
;; TTY KBD BUFFER
;; TTY PRINTER STATUS REG. ADDRESS
;; TTY PRINTER BUFFER REG. ADDRESS
;; CONTAINS NULL CHARACTER FOR FILLS
;; CONTAINS # OF FILLER CHARACTERS REQUIRE.
;; INSERT FILL CHARS. AFTER A "LINE FEED"
;; "TERMINAL AVAILABLE" FLAG (BIT<07>=0=YES)
;; CONTAINS THE ADDRESS FROM
;; WHICH (\$REG0) WAS OBTAINED
;; CONTAINS ((\$REGAD)+0)
;; CONTAINS ((\$REGAD)+2)
;; CONTAINS ((\$REGAD)+4)
;; CONTAINS ((\$REGAD)+6)
;; CONTAINS ((\$REGAD)+10)
;; CONTAINS ((\$REGAD)+12)
;; CONTAINS ((\$REGAD)+14)
;; CONTAINS ((\$REGAD)+16)
;; CONTAINS ((\$REGAD)+20)
;; CONTAINS ((\$REGAD)+22)
;; MAX. NUMBER OF ITERATIONS
;; ESCAPE ON ERROR ADDRESS
;; QUESTION MARK
;; CARRIAGE RETURN
;; LINE FEED

```

234 001224 020105 051120 051505
235 001232 052116 000
236 001236 001236 .EVEN
237 001236 005015 047516 042516 MSG2: .ASCIZ <15><12>/NONE/
238 001244 000
239
240 001245 015 041412 052116 MSG3: .ASCIZ <15><12>/CNT RDY DIDN'T SE*/
241 001252 051040 054504 042040
242 001260 042111 023516 020124
243 001266 042523 000124
244
245 001272 005015 051104 053111 MSG4: .ASCIZ <15><12>/DRIVE /
246 001300 020105 000
247
248 001303 015 040412 046114 MSG5: .ASCII <15><12>/ALL DRVS/
249 001310 042040 053122 123
250
251 001315 040 051104 050117 MSG6: .ASCIZ / DROPO/<15><12>
252 001322 006504 000012
253 .EVEN
254
255 ;RK11 REGISTERS
256 ;IF FOR ANY REASON THE REGISTER ADDRESSES ARE DIFFERENT FROM THESE
257 ; (GIVEN BELOW), THE CONTENTS OF THE APPROPRIATE POINTERS SHOULD BE
258 ; MODIFIED SO THAT THE CORRECT ADDRESS IS USED.
259 ;
260 ; .EVEN
261 001326 177400 RKDS: 177400
262 001330 177402 RKER: 177402
263 001332 177404 RKCS: 177404
264 001334 177406 RKWC: 177406
265 001336 177410 RKBA: 177410
266 001340 177412 RKDA: 177412
267 001342 177416 RKDB: 177416
268
269
270 ;TAGS AND GENERAL DATA AREA
271 ;
272 ;
273
274 001344 000000 SIMUL: 0 ; FLAG TO BE SET TO 1 WHEN ON SIMULATOR
275 001346 000000 FTITLE: 0 ; FLAG FOR PRINTING PROGRAM TITLE
276 001350 000000 DRIVAD: 0 ; CONTAINS ADDRESS OF THE DRIVE UNDER TEST
277 001352 000000 DRVDON: 0 ; CONTAINS THE NUMBER OF DRIVES CHECKED.
278 ; IT IS INCREMENTED EACH TIME THE TESTS FOR
279 ; A DRIVE IS COMPLETED.
280 001354 000000 DRVPTR: 0 ; CONTAINS THE POINTER TO THE DRIVE FLAG (DRIVED
281 ; -DRIVE?) OF THE DRIVE TO BE CHECKED NEXT.
282 001356 000000 INDX1: 0 ; GENERAL INDEX FOR KEEPING COUNT
283 001360 000000 INDX2: 0 ; GENERAL INDEX
284 001362 000000 COUNT: 0 ; GENERAL COUNT REGISTER
285 001364 000000 COUNT1: 0 ; COUNT REGISTER USED FOR 'DRESET' SUBROUTINE
286 001366 000000 TIMER: 0 ; TIMER REGISTER
287 001370 000000 EFLG1: 0 ; SET TO INDICATE A PARTICULAR
288 ; ERROR CONDITION
289

```


290	001372	000100	SEEK0:	100	; CONTAINS ADDRESS OF CYLINDER 2
291	001374	001000	SEEK1:	1000	; CONTAINS ADDRESS OF CYLINDER 20
292	001376	014500	SEEK2:	14500	; CONTAINS ADDRESS OF CYLINDER 312
293	001400	000200	RKPRI:	200	; CONTAINS THE CPU LEVEL AT WHICH
294					RK11 NORMALLY INTERRUPTS. THIS WORD
295					SHOULD BE CHANGED IF RK11 IS DESINGATED
296					A BR LEVEL OTHER THAN 5. E.G. IF IT IS CHANGED
297					TO 6, THIS WORD SHOULD BE CHANGED TO 240.
298	001402	000220	RKVEC:	220	; CONTAINS THE NORMAL VECTOR ADDRESS TO WHICH
299					RK11 INTERRUPTS. IF THIS IS NOT SO, CHANGE
300					THIS WORD TO CONTAIN MODIFIED VECTOR ADDRESS.
301	001404	000000	FFLAG:	0	
302	001406	000000	ODDEVN:	0	; USED TO DETERMINE WHICH OF RK-OSF DRIVES ACTIVE
303					0 IF EVEN DRIVE
304					-1 IF ODD DRIVE
305	001410	000000	DDPCH:	0	; IF PROGRAM LOADED FROM RK05, CONTAINS
306					ADDRESS OF DRIVE WITH RKDP PACK
307	001412	000000	DRIVS:	0	; CONTAINS THE NUMBER OF DRIVES PRESENT
308					
309					
310					
311					
312					; THE FLAGS BELOW (BIT 0) ARE SET TO 1 TO INDICATE THAT A PARTICULAR DRIVE
313					IS PRESENT AND IS TO BE TESTED. BIT 12, IF SET, INDICATES THAT THE DRIVE
314					WAS DROPPED AFTER MAXIMUM ALLOWABLE NUMBER OF ERRORS OCCURED ON THAT
315					DRIVE (SW 6 SET).
316					; IF MORE THAN 5 ERRORS OCCUR IN THE HARDWARE POLLING TEST (LAST)
317					; THEN ALL DRIVES ARE DROPPED. BUT BIT 12 IS NOT SET.
318					
319	001414	000000	DRIV0:	0	; FLAG SET TO 1 WHEN DRIVE 0 PRESENT
320	001416	000000	DRIV1:	0	; FOR DRIVE 1
321	001420	000000	DRIV2:	0	; FOR DRIVE 2
322	001422	000000	DRIV3:	0	; FOR DRIVE 3
323	001424	000000	DRIV4:	0	; FOR DRIVE 4
324	001426	000000	DRIV5:	0	; FOR DRIVE 5
325	001430	000000	DRIV6:	0	; FOR DRIVE 6
326	001432	000000	DRIV7:	0	; FOR DRIVE 7
327					
328	001434	000000	T56FLG:	0	
329	001436	000000	PHYDRV:	0	
330	001440	000000	SIZYET:	0	

331
332
333
334
335
336
337
338
339
340
341
342
343
344
345
346
347
348
349
350
351
352
353
354
355
356
357
358
359
360
361
362
363
364
365
366
367
368
369
370
371
372
373
374
375
376
377
378
379
380
381
382
383
384
385
386

.SBTTL ERROR POINTER TABLE

;*THIS TABLE CONTAINS THE INFORMATION FOR EACH ERROR THAT CAN OCCUR.
 ;*THE INFORMATION IS OBTAINED BY USING THE INDEX NUMBER FOUND IN
 ;*LOCATION \$ITEMB. THIS NUMBER INDICATES WHICH ITEM IN THE TABLE IS PERTINENT.
 ;*NOTE1: IF \$ITEMB IS 0 THE ONLY PERTINENT DATA IS (\$ERRPC).
 ;*NOTE2: EACH ITEM IN THE TABLE CONTAINS 4 POINTERS EXPLAINED AS FOLLOWS:

;* EM ;:POINTS TO THE ERROR MESSAGE
 ;* DH ;:POINTS TO THE DATA HEADER
 ;* DT ;:POINTS TO THE DATA
 ;* DF ;:POINTS TO THE DATA FORMAT

\$ERRTB:

;THE ERROR ITEMS TABLE CONSISTS OF ALL THE POSSIBLE ERROR MESSAGES
 ;USED IN THIS PROGRAM. AN ERROR CALL IN THE PROGRAM CORRESPONDS TO
 ;THE ITEM NUMBER IN THE ERROR TABLE. THUS 'ERROR 1' IN THE
 ;PROGRAM CORRESPONDS TO 'ITEM 1' IN THE ERROR TABLE.
 ;'EM***' IS THE POINTER TO THE ERROR MESSAGE WHICH WILL BE TYPED
 ;OUT IN CASE THAT ERROR WERE TO OCCUR. THUS FOR 'ERROR 1' THE ERROR
 ;MESSAGE TYPE OUT WILL BE 'TIME OUT ON RK11 REG'.
 ;'DH***' IS THE POINTER TO THE HEADER BLOCK WHICH WILL BE TYPED OUT
 ;IMMEDIATELY AFTER THE ERROR MESSAGE.
 ;'DT***' SERVES AS A POINTER TO THE MEMORY LOCATIONS WHERE
 ;THE INFORMATION RELEVANT TO THE ERROR TYPE OUTS (LIKE PC, CONTENTS
 ;OF RKCS ETC.) WILL BE PICKED UP FROM.
 ;THE LAST ROW CONTAINING '0' SERVES AS A TERMINATOR.
 ;EXAMPLE:
 ;IF ON RUNNING THIS PROGRAM A TIMEOUT WERE TO OCCUR ON ADDRESSING RKDS
 ;(177400), BECAUSE OF SOME FAULT, THE FOLOWING TYPEOUT WOULD
 ;OCCUR ON THE TELETYPE.

```

      TIME OUT ON RK11 REG
      PC      REG
      ***** 177400
  
```

;NOTE THAT ***** WOULD BE THE ACTUAL PC WHERE 'ERROR 1' IS LOCATED.

;THE ERROR HANDLER IS LOCATED AT '\$ERROR'. THE ERROR CALL IS AN 'EMT'
 ;INSTRUCTION WITH ITS LOWER BYTE ENCODED TO PROVIDE INDEXING TO THE
 ;ITEMS IN THE ERROR TABLE.
 ;THUS 'ERROR 1' IS 104001
 ;'ERROR 103' IS 104126 ETC.

;ERROR ITEMS TABLE

001442

387			:ITEM	1					
388					EM12	: 'SIN' IS SET			
389	001442	025300			DH44	:PC RKCS RKER RKDS RKDA			
390	001444	032225			DT20	:SERRPC \$REG0 \$REG1 \$REG2 \$REG3			
391	001446	031640			0				
392	001450	000000							
393			:ITEM	2					
394					EM70	:CNTRL ROY DIDN'T SET ON READ/FMT FROM DISK ADDRESS			
395					DH14	:PC RKCS RKER RKWC			
396	001452	027151			DT26	:SERRPC \$REG0 \$REG1 \$REG2			
397	001454	032011			0				
398	001456	031660							
399	001460	000000							
400			:ITEM	3					
401					EM16	:RKDA WRONG AFTER SSE			
402	001462	025325			DH4	:PC EXPCT RECVD			
403	001464	031745			DT2	:SERRPC \$REG0 \$REG1			
404	001466	031630			0				
405	001470	000000							
406			:ITEM	4					
407					EM21	:RKDS ERROR			
408	001472	025354			DH34	:PC RKDS			
409	001474	032111			DT1	:SERRPC \$REG0			
410	001476	031622			0				
411	001500	000000							
412			:ITEM	5					
413					EM30	: 'DPL' BIT SET, CHECK DRIVE POWER			
414	001502	025366			DH30	:PC RKCS RKER RKDS			
415	001504	032053			DT26	:SERRPC \$REG0 \$REG1 \$REG2			
416	001506	031660			0				
417	001510	000000							
418			:ITEM	6					
419					EM31	: 'DRU' BIT SET, CHECK DRIVE			
420	001512	025376			DH30	:PC RKCS RKER RKDS			
421	001514	032053			DT26	:SERRPC \$REG0 \$REG1 \$REG2			
422	001516	031660			0				
423	001520	000000							
424			:ITEM	7					
425					EM32	: 'RKOS' BIT NOT SET			
426	001522	025406			DH34	:PC RKDS			
427	001524	032111			DT1	:SERRPC \$REG0			
428	001526	031622			0				
429	001530	000000							
430			:ITEM	10					
431					EM33	: 'DRY' NOT SET			
432	001532	025427			DH44	:PC RKCS RKER RKDS RKDA			
433	001534	032225			DT20	:SERRPC \$REG0 \$REG1 \$REG2 \$REG3			
434	001536	031640			0				
435	001540	000000							

463			:ITEM 11		
464	001542	025447		EM34	: 'SOK' DID NOT SET
465	001544	032111		DH34	: PC RKDS
466	001546	031622		DT1	: SERRPC \$REG0
467	001550	000000		0	
468			:ITEM 12		
469	001552	025466		EM35	: 'SEC COUNTR' DIDN'T COUNT TO 0
470	001554	032127		DH35	: PC SEC-CNTR
471	001556	031622		DT1	: SERRPC \$REG0
472	001560	000000		0	
473			:ITEM 13		
474	001562	025521		EM36	: 'SEC COUNTR' DIDN'T INCREMENT
475	001564	032147		DH36	: PC PRSNT-COUNT NXT-COUNT
476	001566	031630		DT2	: SERRPC \$REG0 \$REG1
477	001570	000000		0	
478			:ITEM 14		
479	001572	025551		EM37	: 'SECTOR COUNTER' INCREMENTED WRONG
480	001574	031745		DH4	: PC EXPCTD RECVD
481	001576	031630		DT2	: SERRPC \$REG0 \$REG1
482	001600	000000		0	
483			:ITEM 15		
484	001602	025605		EM40	: DIDN'T GET SC=5A FOR THIS SECTOR
485	001604	032177		DH40	: PC SECTOR RKDS
486	001606	031630		DT2	: SERRPC \$REG0 \$REG1
487	001610	000000		0	
488			:ITEM 16		
489	001612	025645		EM41	: ERROR-'R/W/S RDY' SHOULD BE SET
490	001614	032111		DH34	: PC RKDS
491	001616	031622		DT1	: SERRPC \$REG0
492	001620	000000		0	
493			:ITEM 17		
494	001622	025313		EM13	: RKBA ERROR
495	001624	031745		DH4	: PC EXPCT RECVD
496	001626	031630		DT2	: SERRPC \$REG0 \$REG1
497	001630	000000		0	
498			:ITEM 20		
499	001632	025702		EM43	: UNEXPECTED RK11 INTERRUPT
500	001634	032046		DH21	: PC
501	001636	031654		DT21	: SERRPC
502	001640	000000		0	

498
500
501
502
503
504
505
506
507
508
509
510
511
512
513
514
515
516
517
518
519
520
521
522
523
524
525
526
527
528
529
530
531
532
533
534
535
536
537
538
539
540
541
542
543
544
545
546
547
548
549
550
551
552
553
554
555
556
557
558
559
560
561
562
563
564
565
566
567
568
569
570
571
572
573
574
575
576
577
578
579
580
581
582
583
584
585
586
587
588
589
590
591
592
593
594
595
596
597
598
599
600

:ITEM 21
EM44 : 'CNTRL RDY' DIDN'T SET AFTER SEEK OR DRIVE RESET
DH44 : PC RKCS RKER RKDS RKDA
DT20 : SERRPC \$REG0 \$REG1 \$REG2 \$REG3.
0

:ITEM 22
EM45 : 'ERR' OR 'HE' SET ON SEEK OR DRIVE RESET
DH44 : PC RKCS RKER RKDS RKDA
DT20 : SERRPC \$REG0 \$REG1 \$REG2 \$REG3
0

:ITEM 23
EM46 : RKER BIT, ON SEEK OR DRIVE RESET
DH30 : PC RKCS RKER RKCS
DT26 : SERRPC \$REG0 \$REG1 \$REG2
0

:ITEM 24
EM47 : RKCS CHANGED AFTER FUNCTION WAS DONE
DH4 : PC EXPCT RECVD
DT2 : SERRPC \$REG0 \$REG1
0

:ITEM 25
EM50 : 'R/W/S RDY' DID NOT CLEAR
DH30 : PC RKCS RKER RKDS
DT26 : SERRPC \$REG0 \$REG1 \$REG2
0

:ITEM 26
EM51 : 'R/W/S RDY' DIDN'T SET AFTER SEEK OR DRIVE RESET
DH44 : PC RKCS RKER RKDS RKDA
DT20 : SERRPC \$REG0 \$REG1 \$REG2 \$REG3
0

:ITEM 27
EM52 : RKDA CHANGED AFTER SEEK
DH4 : PC EXPCTD REGVD
DT2 : SERRPC \$REG0 \$REG1
0

:ITEM 30
EM53 : 'CNTRL RDY' DIDN'T CLEAR AS GO WAS SET
DH30 : PC RKCS RKER RKDS
DT26 : SERRPC \$REG0 \$REG1 \$REG2
0

555			:ITEM 31		
556				EMS4	: 'CNTRL RDY' DIDN'T SET ON DOING WRITE/FMT STARTING
557	001742	026350			: FROM <DSK-ADRES>
558				DHS4	: PC RKCS RKER RKDS RKDA
559	001744	032272			: DRV# CYL <DSK-ADRES> SUR SECTR
560				DT54	: \$ERRPC \$REG0 \$REG1 \$REG2 \$REG3
561	001746	031672			: \$REG4 \$REG5 \$REG6 \$REG7
562				0	
563	001750	000000			
564			:ITEM 32		
565				EMS5	: 'HE' OR 'ERR' ON WRITE/FMT STARTING FROM
566	001752	026442			: <DSK-ADRES>
567				DHS4	: PC RKCS RKER RKDS RKDA
568	001754	032272			: DRV# CYL <DSK-ADRES> SUR SECTR
569				DT54	: \$ERRPC \$REG0 \$REG1 \$REG2 \$REG3
570	001756	031672			: \$REG4 \$REG5 \$REG6 \$REG7
571				0	
572	001760	000000			
573			:ITEM 33		
574				EMS6	: RKDA INCREMENTED WRONG ON WRITE OR WRITE FORMAT
575	001762	026521		DHS6	: PC EXPCT: DRV# CYL SUR SECTR
576	001764	032401			: RECVD: DRV# CYL SUR SECTR
577				DT54	: \$ERRPC \$REG0 \$REG1 \$REG2 \$REG3
578	001766	031672			: \$REG4 \$REG5 \$REG6 \$REG7
579				0	
580	001770	000000			
581			:ITEM 34		
582				EMS7	: RKWC DIDN'T OVERFLOW ON WRITE OR WRITE FORMAT
583	001772	026560		DHS	: PC RECVD
584	001774	031773		DT1	: \$ERRPC \$REG0
585	001776	031622		0	
586	002000	000000			
587			:ITEM 35		
588				EMS0	: RKBA INCREMENTED WRONG ON WRITE OR WRITE FORMAT
589	002002	026616		DH4	: PC EXPCT RECVD
590	002004	031745		DT2	: \$ERRPC \$REG0 \$REG1
591	002006	031630		0	
592	002010	000000			
593			:ITEM 36		
594				EMS1	: RKER SET ON WRITE/READ/FORMAT
595	002012	026655		DH30	: PC RKCS RKER RKDS
596	002014	032053		DT26	: \$ERRPC \$REG0 \$REG1 \$REG2
597	002016	031660		0	
598	002020	000000			
599			:ITEM 37		
600				EMS2	: RKDB ERROR
601	002022	026712		DH4	: PC EXPCT RECVD
602	002024	031745		DT2	: \$ERRPC \$REG0 \$REG1
603	002026	031630		0	
604	002030	000000			

E03

611			:ITEM	40								
612					EM63	:RKDA	INCREMENTED	WRONG	ON READ OR READ	FORMAT		
613					DH56	:PC	EXPCT:	DRV#	CYL	SUR	SECTR	
614	002032	026724				:RECVD:	DRV#	CYL	SUR	SECTR		
615	002034	032401				:SERRPC		\$REG0	\$REG1	\$REG2	\$REG3	
616					DT54	:SREG4	\$REG5	\$REG6	\$REG7			
617	002036	031672										
618					0							
619	002040	000000										
620			:ITEM	41								
621					EM64	:RKWC	DID NOT	OVERFLOW	ON READ OR READ	FORMAT		
622	002042	026770			DH64	:PC	RKWC	RKDA				
623	002044	032506				:SERRPC	\$REG0	\$REG1				
624	002046	031630			DT2							
625	002050	000000			0							
626			:ITEM	42								
627					EM65	:RKBA	INCREMENTED	WRONG	ON READ OR READ	FORMAT		
628	002052	027233			DH4	:PC	EXPCT	RECVD				
629	002054	031745				:SERRPC	\$REG0	\$REG1				
630	002056	031630			DT2							
631	002060	000000			0							
632			:ITEM	43								
633					EM66	:INCORRECT	HEADER	FROM	'SECTOR'			
634	002062	027277			DH66	:PC	SECTR	EXPCT	RECVD			
635	002064	032532				:SERRPC	\$REG0	\$REG1	\$REG2.			
636	002066	031660			DT26							
637	002070	000000			0							
638			:ITEM	44								
639					EM67	:DATA	ERROR					
640	002072	027136			DH67	:PC	EXPCT	RECVD	DSK-ADRES			
641	002074	032570				:SERRPC	\$REG0	\$REG1	\$REG2			
642	002076	031660			DT26							
643	002100	000000			0							
644			:ITEM	45								
645					EM70	: 'CNTRL	RDY'	DIDN'T	SET	ON DOING	READ/FMT	STARTING
646	002102	027151				: FROM	<DSK-ADRES>					
647					DH54	:PC	RKCS	RKER	RKDS	RKDA		
648	002104	032272				:DRV#	CYL	<DSK-ADRES>	SUR	SECTR		
649	002106	031672			DT54	:SERRPC	\$REG0	\$REG1	\$REG2	\$REG3		
650						:SREG4	\$REG5	\$REG6	\$REG7			
651	002110	000000			0							
652			:ITEM	46								
653					EM71	: 'HE' OR	'ERR'	BIT	SET	ON READ/FMT	STARTING	
654	002112	027242				: FROM	<DSK-ADRES>					
655					DH54	:PC	RKCS	RKER	RKDS	RKDA		
656	002114	032272				:DRV#	CYL	<DSK-ADRES>	SUR	SECTR		
657	002116	031672			DT54	:SERRPC	\$REG0	\$REG1	\$REG2	\$REG3		
658						:SREG4	\$REG5	\$REG6	\$REG7			

667	002120	000000	0	
668				
669			:ITEM	47
670				
671	002122	027320	EM72	:WRONG DRIVE ID IN RKDS AFTER SEEK
672	002124	031745	DH4	:PC EXPCT RECVD
673	002126	031630	DT2	:SERRPC \$REG0 \$REG1
674	002130	000000	0	
675				
676			:ITEM	50
677				
678	002132	027362	EM73	:HARDWARE POLL, DRIVE ID BITS(13-15) SHOULD BE CLEAR
679	002134	032111	DH34	:PC RKDS
680	002136	031630	DT2	:SERRPC \$REG0
681	002140	000000	0	
682				
683			:ITEM	51
684				
685	002142	027434	EM74	:HARDWARE POLL, INTERRUPTING DRIVE # NOT PRESENT
686	002144	032630	DH74	:PC DRIVE #
687	002146	031622	DT1	:SERRPC \$REG0
688	002150	000000	0	
689				
690			:ITEM	52
691				
692	002152	027504	EM75	: 'DRIVE #' DID NOT INTERRUPT DURING HARDWARE POLL
693	002154	032630	DH74	:PC DRIVE #
694	002156	031622	DT1	:SERRPC \$REG0
695	002160	000000	0	
696				
697			:ITEM	53
698				
699	002162	027554	EM76	:SCP DID NOT SET AFTER WAS DONE
700	002164	033004	DH117	:PC RKCS
701	002166	031622	DT1	:SERRPC \$REG0
702	002170	000000	0	
703				
704			:ITEM	54
705				
706	002172	027617	EM77	:RKDA CHANGED AFTER 'DRIVE RESET'
707	002174	031745	DH4	:PC EXPCT RECVD
708	002176	031630	DT2	:SERRPC \$REG0 \$REG1
709	002200	000000	0	
710				
711			:ITEM	55
712				
713	002202	027654	EM100	:DATA ERROR AT WORD#
714	002204	032651	DH100	:PC WORD# EXPCT RECVD
715	002206	031660	DT26	:SERRPC \$REG0 \$REG1 \$REG2
716	002210	000000	0	
717				
718			:ITEM	56
719				
720	002212	027677	EM101	:CNTRL RDY DID NOT SET AFTER READ CHECK
721	002214	032225	DH44	:PC RKCS RKER RKDS RKDA
722	002216	031640	DT20	:SERRPC \$REG0 \$REG1 \$REG2 \$REG3

723	002220	000000	0	
724				
725			:ITEM	57
726				
727	002222	027741	EM102	: 'ERR' OF 'HE' SET ON READ CHECK
728	002224	032053	DH30	:PC RKCS RKER RKDS
729	002226	031660	DT26	:SERRPC \$REG0 \$REG1 \$REG2
730	002230	000000	0	
731				
732			:ITEM	60
733				
734	002232	027765	EM103	: 'CSE' ON READ CHECK
735	002234	032706	DH103	:PC RKER
736	002236	031622	DT1	:SERRPC \$REG0
737	002240	000000	0	
738				
739			:ITEM	61
740				
741	002242	030003	EM104	:RKWC DID NOT OVERFLOW ON READ CHECK OR WRITE CHECK
742	002244	032722	DH104	:PC RECVD RKCS
743	002246	031630	DT2	:SERRPC \$REG0 \$REG1
744	002250	000000	0	
745				
746			:ITEM	62
747				
748	002252	030054	EM105	:RKDA INCREMENTED WRONG ON READ CHECK
749	002254	031745	DH4	:PC EXPCT RECVD
750	002256	031630	DT2	:SERRPC \$REG0 \$REG1
751	002260	000000	0	
752				
753			:ITEM	63
754				
755	002262	030112	EM106	:RKBA CHANGED AFTER READ CHECK
756	002264	031745	DH4	:PC EXPCT RECVD
757	002266	031630	DT2	:SERRPC \$REG0 \$REG1
758	002270	000000	0	
759				
760			:ITEM	64
761				
762	002272	030143	EM107	:MEMORY WORD CHANGED AFTER READ CHECK
763	002274	032746	DH107	:PC LOC EXPCT RECVD
764	002276	031660	DT26	:SERRPC \$REG0 \$REG1 \$REG2
765	002300	000000	0	
766				
767			:ITEM	65
768				
769	002302	030204	EM110	:CNTRL RDY DID NOT SET AFTER WRITE CHECK
770	002304	032225	DH44	:PC RKCS RKER RKDS RKDA
771	002306	031640	DT20	:SERRPC \$REG0 \$REG1 \$REG2 \$REG3
772	002310	000000	0	
773				
774			:ITEM	66
775				
776	002312	030247	EM111	:HE OR ERR BIT SET AFTER DOING WRITE CHECK
777	002314	032053	DH30	:PC RKCS RKER RKDS
778	002316	031660	DT26	:SERRPC \$REG0 \$REG1 \$REG2

779	002320	000000	0		
780					
781			:ITEM	67	
782					
783	002322	030274	EM112		:WRITE CHECK ERROR
784	002324	032053	DH30		:PC RKCS RKER RKDS
785	002326	031660	DT26		:SERRPC \$REG0 \$REG1 \$REG2
786	002330	000000	0		
787					
788			:ITEM	70	
789					
790	002332	030315	EM113		:RKDA INCREMENTED WRONG ON WRITE CHECK
791	002334	031745	DH4		:PC EXPCT RECVD
792	002336	031630	DT2		:SERRPC \$REG0 \$REG1
793	002340	000000	0		
794					
795			:ITEM	71	
796					
797	002342	030354	EM114		:RKBA INCREMENTED WRONG ON WRITE CHECK
798	002344	031745	DH4		:PC EXPCT RECVD
799	002346	031630	DT2		:SERRPC \$REG0 \$REG1
800	002350	000000	0		
801					
802			:ITEM	72	
803					
804	002352	030413	EM115		:RKBA INCREMENTED WITH IBA SET
805	002354	031745	DH4		:PC EXPCT RECVD
806	002356	031630	DT2		:SERRPC \$REG0 \$REG1
807	002360	000000	0		
808					
809			:ITEM	73	
810					
811	002362	030447	EM116		:WRONG MEMORY LOCATION CHANGED WITH IBA SET
812	002364	032651	DH100		:PC WORD# EXPCT RECVD
813	002366	031660	DT26		:SERRPC \$REG0 \$REG1 \$REG2
814	002370	000000	0		
815					
816			:ITEM	74	
817					
818	002372	030522	EM117		:RK11 DID NOT INTERRUPT WHEN IDE WAS SET
819	002374	033004	DH117		:PC RKCS
820	002376	031622	DT1		:SERRPC \$REG0
821	002400	000000	0		
822					
823			:ITEM	75	
824					
825	002402	030567	EM120		:RK11 DID NOT INTERRUPT AFTER SEEK WAS INITIATED
826	002404	033004	DH117		:PC RKCS
827	002406	031622	DT1		:SERRPC \$REG0
828	002410	000000	0		
829					
830			:ITEM	76	
831					
832	002412	030642	EM121		:SCP SET BEFORE SEEK COMPLETED
833	002414	033004	DH117		:PC RKCS
834	002416	031622	DT1		:SERRPC \$REG0

835	002420	000000	0	
836				
837				; ITEM 77
838				
839	002422	030700	EM122	; RK11 DID NOT INTERRUPT AFTER SEEK COMPLETED
840	002424	032053	DH30	; PC RKCS RKER RKOS
841	002426	031660	DT26	; SERRPC \$REG0 \$REG1 \$REG2
842	002430	000000	0	
843				
844				; ITEM 100
845				
846	002432	030747	EM123	; CNTRL RESET DID NOT CLEAR 'SCP' BIT
847	002434	033004	DH117	; PC RKCS
848	002436	031622	DT1	; SERRPC \$REG0
849	002440	000000	0	
850				
851				; ITEM 101
852				
853	002442	031006	EM124	; RK11 DID NOT INTERRUPT AFTER READ WAS DONE
854	002444	033004	DH117	; PC RKCS
855	002446	031622	DT1	; SERRPC \$REG0
856	002450	000000	0	
857				
858				; ITEM 102
859				
860	002452	031050	EM125	; CNTRL RESET DID NOT CLEAR REGISTER
861	002454	031716	DH2	; PC REGADD RECVD
862	002456	031630	DT2	; SERRPC \$REG0 \$REG1
863	002460	000000	0	
864				
865				; ITEM 103
866				
867	002462	031107	EM126	; RK11 DID NOT INTERRUPT AT CPU LEVEL
868	002464	033020	DH126	; PC LEVEL RKCS
869	002466	031630	DT2	; SERRPC \$REG0 \$REG1
870	002470	000000	0	
871				
872				; ITEM 104
873				
874	002472	031150	EM127	; RK11 INTERRUPTED AT WRONG CPU LEVEL
875	002474	033020	DH126	; PC LEVEL RKCS
876	002476	031630	DT2	; SERRPC \$REG0 \$REG1
877	002500	000000	0	
878				
879				; ITEM 105
880				
881	002502	031212	EM130	; 'ERR BIT' DID NOT SET IN RKER
882	002504	033046	DH130	; PC RKCS RKER ERR BIT
883	002506	031660	DT26	; SERRPC \$REG0 \$REG1 \$REG2
884	002510	000000	0	
885				
886				
887				; ITEM 106
888				
889	002512	031247	EM131	; HE OR ERR DID NOT SET
890	002514	033105	DH131	; PC RKCS RKER

891	002516	031630	DT2	;	SERRPC	\$REG0	\$REG1					
892	002520	000000	0									
893												
894			:ITEM		107							
895												
896	002522	031274	EM132	;	RKER	ERROR						
897	002524	031745	DH4	;	PC	EXPCT	RECVD					
898	002526	031630	DT2	;	SERRPC	\$REG0	\$REG1					
899	002530	000000	0									
900												
901			:ITEM		110							
902												
903	002532	031306	EM133	;	NXC	BIT	DID	NOT	SET			
904	002534	033133	DH133	;	PC	RKCS	RKER	RKDA				
905	002536	031660	DT26	;	PC	\$REG0	\$REG1	\$REG2				
906	002540	000000	0									
907												
908			:ITEM		111							
909												
910	002542	031331	EM134	;	RK11	DIDN'T	INTERRUPT	ON	SOFT	ERROR		
911	002544	033105	DH131	;	PC	RKCS	RKER					
912	002546	031630	DT2	;	SERRPC	\$REG0	\$REG1					
913	002550	000000	0									
914												
915			:ITEM		112							
916												
917	002552	031372	EM135	;	MEX	BITS	INCREMENTED	WRONG	IN	RKCS		
918	002554	031745	DH4	;	PC	EXPCTD	RECVD					
919	002556	031630	DT2	;	SERRPC	\$REG0	\$REG1					
920	002560	000000	0									
921												
922			:ITEM		113							
923												
924	002562	030204	EM110	;	CNTRL	RDY	DID	NOT	SET	AFTER	WRT	CHK
925	002564	032011	DH14	;	PC	RKCS	RKER	RKWC				
926	002566	031660	DT26	;	SERRPC	\$REG0	\$REG1	\$REG2				
927	002570	000000	0									
928												
929			:ITEM		114							
930												
931	002572	031427	EM137	;	'WPS'	NOT	CLEAR					
932	002574	032225	DH44	;	PC	RKCS	RKER	RKDS	RKDA			
933	002576	031640	DT20	;	SERRPC	\$REG0	\$REG1	\$REG2	\$REG3			
934	002600	000000	0									
935												
936			:ITEM		115							
937												
938	002602	031445	EM140	;	DATA	ERROR	ON	TRANSFER	FROM	DISK	TO	TTY
939	002604	033171	DH140	;	PC	EXPCT	RECVD	RKBA	RKCS			
940	002606	031640	DT20	;	SERRPC	\$REG0	\$REG1	\$REG2	\$REG3			
941	002610	000000	0									
942												
943			:ITEM		116							
944												
945	002612	031514	EM141	;	'DRIVE	#'	PRESENT,	BUT	NOT	SPECIFIED		

K03

947	002614	032630	DH74	:PC	DRIVE	*
948	002616	031622	DT1	:SERRPC	\$REGO	
949	002620	000000	0			
950						
951			:ITEM	117		
952						
953	002622	025266	EM11	:RKWC	ERROR	
954	002624	031745	DH4	:PC	EXPCT	RECVD
955	002626	031630	DT2	:SERRPC	\$REGO	\$REG1
956	002630	000000	0			
957			:ITEM	120		
958	002632	031560	EM142			
959	002634	000000	0			
960						
961						
962						
963						
964						
965						
966						
967						
968						
969						
970						

```

963 002636 000005 START: RESET ;CLEAR THE BUS
964 .SBTTL INITIALIZE THE COMMON TAGS
965 ;;CLEAR THE COMMON TAGS ($CMTAG) AREA
966 002640 012706 001100 MOV #CMTAG,R6 ;FIRST LOCATION TO BE CLEARED
967 002644 005026 CLR (R6)+ ;CLEAR MEMORY LOCATION
968 002646 022706 001140 CMP #SWR,R6 ;;DONE?
969 002652 001374 BNE -6 ;;LOOP BACK IF NO
970 002654 012706 001100 MOV #STACK,SP ;SETUP THE STACK POINTER
971 ;;INITIALIZE A FEW VECTORS
972 002660 012737 022046 000020 MOV #SCOPE,@IOTVEC ;IOT VECTOR FOR SCOPE ROUTINE
973 002666 012737 000340 000022 MOV #340,@IOTVEC+2 ;LEVEL 7
974 002674 012737 022320 000030 MOV #ERROR,@EMTVEC ;EMT VECTOR FOR ERROR ROUTINE
975 002702 012737 000340 000032 MOV #340,@EMTVEC+2 ;LEVEL 7
976 002710 012737 024574 000034 MOV #STRAP,@TRAPVEC ;TRAP VECTOR FOR TRAP CALLS
977 002716 012737 000340 000036 MOV #340,@TRAPVEC+2 ;LEVEL 7
978 002724 012737 024674 000024 MOV #SPWRDN,@PWRVEC ;POWER FAILURE VECTOR
979 002732 012737 000340 000026 MOV #340,@PWRVEC+2 ;LEVEL 7
980 002740 005037 001206 CLR TIMES ;INITIALIZE NUMBER OF ITERATIONS
981 002744 005037 001210 CLR $ESCAPE ;CLEAR THE ESCAPE ON ERROR ADDRESS
982 002750 112737 000001 001115 MOVB #1,$ERMAX ;ALLOW ONE ERROR PER TEST
983 002756 012737 002756 001106 MOV #,$LPADR ;INITIALIZE THE LOOP ADDRESS FOR SCOPE
984 002764 012737 002764 001110 MOV #,$LPERR ;SETUP THE ERROR LOOP ADDRESS
985 ;;SIZE FOR A HARDWARE SWITCH REGISTER. IF NOT FOUND OR IT IS
986 ;;EQUAL TO A "-1" SETUP FOR A SOFTWARE SWITCH REGISTER.
987 002772 013746 000004 MOV @ERRVEC-(SP) ;SAVE ERROR VECTOR
988 002776 012737 003032 000004 MOV #64$,@ERRVEC ;SET UP ERROR VECTOR
989 003004 012737 177570 001140 MOV #DSWR,SWR ;SETUP FOR A HARDWARE SWICH REGISTER
990 003012 012737 177570 001142 MOV #DDISP,DISPLAY ;AND A HARDWARE DISPLAY REGISTER
991 003020 022777 177777 176112 CMP #-1,@SWR ;TRY TO REFERENCE HARDWARE SWR
992 003026 001012 BNE 66$ ;BRANCH IF NO TIMEOUT TRAP OCCURRED
993 ;AND THE HARDWARE SWR IS NOT = -1
994 003030 000403 BR 65$ ;BRANCH IF NO TIMEOUT
995 003032 012716 003040 64$: MOV #65$,(SP) ;SET UP FOR TRAP RETURN
996 003036 000002 RTI
997 003040 012737 000176 001140 65$: MOV #SWREG,SWR ;POINT TO SOFTWARE SWR
998 003046 012737 000174 001142 MOV #DISPREG,DISPLAY
999 003054 012637 000004 66$: MOV (SP)+,@ERRVEC ;RESTORE ERROR VECTOR
1000
1001 .SBTTL TYPE PROGRAM NAME
1002 ;;TYPE THE NAME OF THE PROGRAM IF FIRST PASS
1003 003060 005227 177777 INC #-1 ;FIRST TIME?
1004 003064 001044 BNE 67$ ;BRANCH IF NO
1005 003066 104401 003124 TYPE 68$ ;TYPE ASCIZ STRING
1006 .SBTTL GET VALUE FOR SOFTWARE SWITCH REGISTER
1007 003072 005737 000042 TST @#42 ;ARE WE RUNNING UNDER XXDP/ACT?
1008 003076 001006 BNE 69$ ;BRANCH IF YES
1009 003100 023727 001140 000176 CMP SWR,#SWREG ;SOFTWARE SWITCH REG SELECTED?
1010 003106 001005 BNE 70$ ;BRANCH IF NO
1011 003110 104406 GTSWR ;GET SOFT-SWR SETTINGS
1012 003112 000403 BR 70$
1013 003114 112737 000001 001134 69$: MOVB #1,$AUTOB ;SET AUTO-MODE INDICATOR
1014 003122 70$:
1015 003122 000425 BR 67$ ;GET OVER THE ASCIZ
1016 ;;68$: .ASCIZ <CRLF>/RK11 LOGIC TEST II/<15><12>/MAINDEC-11-DZRKK-D/<CRLF>
1017 67$:
1018 003176 012700 001410 MOV #DDPCH,R0

```

M03

MAINDEC-11-DZRKK-D
DZRKKD.P11 22-SEP-76

MACY11 27(1006)
08:47

04-OCT-76 16:06 PAGE 21
GET VALUE FOR SOFTWARE SWITCH REGISTER

SEG 0038

```

1019 003202 012701 177765          MOV    #-13,R1
1020 003206 005020          15:   CLR    (R0)+
1021 003210 005201          INC    R1
1022 003212 001375          BNE    15
1023 003214 005227 177777          INC    #-1          ;FIRST START ?
1024 003220 001020          BNE    START1      ;BR IF NOT
1025 003222 013746 000004          MOV    ERRVEC,-(SP) ;SAVE ERROR VECTOR ADDRESS
1026 003226 012737 003242 000004          MOV    #25,ERRVEC  ;NEW VECTOR ADDRESS
1027 003234 005737 177776          TST    PS          ;SEE IF PROGRAM CAN REFERENCE THE
1028                                ;PROCESSOR STATUS WORD
1029 003240 000406          BR     35          ;BR IF REFERENCE DIDN'T CAUSE TRAP
1030 003242 012737 000140 001400 25:   MOV    #140,RKPRI  ;SETUP INTERRUPTING PRIORITY TO VALUE
1031                                ;WHICH WILL ALLOW INTERRUPT ON AN LSI-11
1032 003250 012716 003256          MOV    #35,(SP)   ;SETUP RETURN ADDRESS
1033 003254 000002          RTI                    ;RETURN
1034 003256 012637 000004          35:   MOV    (SP)+,ERRVEC ;RESTORE THE ERROR VECTOR
1035
1036                                ;FIND OUT IF ACT11, 'XXDP' CHAIN OR DUMP MODE
1037
1038 003262 012700 001410          START1: MOV   #DDPCH,R0
1039 003266 012701 177766          MOV   #-12,R1      ;CLEAR OUT DRIVE TABLE AREA
1040 003272 005020          15:   CLR    (R0)+
1041 003274 005201          INC    R1
1042 003276 001375          BNE    15
1043 003300 122737 000002 000041          CMPB  #2,41      ;LOADED FROM AN RK05 ?
1044 003306 001166          BNE    ST2
1045 003310 013737 000040 001410          MOV   40,DDPCH    ;BR IF NOT
1046                                ;GET DEVICE INDICATOR AND DRIVE ADDRESS OF
1047 003316 122737 000010 001410          CMPB  #10,DDPCH  ;LOADING RK05
1048 003324 101002          BHI    25          ;VALID DRIVE NUMBER IN BYTE 40 ?
1049 003326 105037 001410          CLRB  DDPCH      ;BR IF YES
1050                                ;MUST BE DRIVE ZERO WHICH LOADED
1051 003332 005737 000042          25:   TST   42          ;THIS PROGRAM
1052 003336 001432          BEQ   45          ;CHAIN MODE OR ACT11 AUTO ACCEPT ?
1053 003340 005737 001410          TST   DDPCH      ;BR IF NEITHER
1054 003344 001002          BNE   35          ;RUNNING FROM AN RK05 ?
1055 003346 000137 004210          JMP   ST3        ;BR IF YES
1056 003352          35:
1057 003352 104401 003360          TYPE  ,655      ;TYPE ASCIZ STRING
1058 003356 000413          BR    645      ;GET OVER THE ASCIZ
1059          ;55: .ASCIZ <15><12>/NOT TESTING DRIVE /
1060          645:
1061 003406 005046          CLR   -(SP)     ;CLEAR WORD ON STACK
1062 003410 113716 001410          MOVB  DDPCH,(SP) ;GET DRIVE ADDRESS
1063 003414 104403          TYPOS ;TYPE THE ADDRESS
1064 003416 001          .BYTE 1        ;ONLY 1 CHARACTER
1065 003417 000          .BYTE 0        ;SUPPRESS LEADING ZEROS
1066 003420 000137 004210          JMP   ST3      ;GET NUMBER OF DRIVES
1067 003424 005227 177777          45:   INC   #-1      ;FIRST TIME THROUGH HERE ?
1068 003430 001115          BNE   ST2      ;BR IF NOT
1069 003432 104401 003440          TYPE  ,675      ;TYPE ASCIZ STRING
1070 003436 000411          BR    665      ;GET OVER THE ASCIZ
1071          ;675: .ASCIZ <15><12>/TO TEST DRIVE /
1072          665:
1073 003462 005046          CLR   -(SP)     ;CLEAR WORD ON THE STACK
1074 003464 113716 001410          MOVB  DDPCH,(SP) ;GET DRIVE ADDRESS

```

N03

MAINDEC-11-DZRKK-D
DZRKKD.P11 22-SEP-76

MACY11 27(1006)
08:47

04-OCT-76 16:06 PAGE 22
GET VALUE FOR SOFTWARE SWITCH REGISTER

SEQ 0039

1075	003470	104403		TYP0S	:TYPE THE DRIVE ADDRESS
1076	003472	001		.BYTE 1	:ONLY 1 CHARACTER
1077	003473	000		.BYTE 0	:SUPPRESS LEADING ZEROS
1078	003474	104401	003502	TYPE 69S	:TYPE ASCIZ STRING
1079	003500	000431		BR 68S	:GET OVER THE ASCIZ
1080				::69S: .ASCIZ	/ HALT PROGRAM, REMOVE RKDP PACK AND REPLACE IT/<15><12>
1081	003564			68S:	
1082	003564	104401	003572	TYPE 71S	:TYPE ASCIZ STRING
1083	003570	000435		BR 70S	:GET OVER THE ASCIZ
1084				::71S: .ASCIZ	/WITH A WORK PACK, CLEAR LOCATION 40, AND RESTART PROGRAM/
1085	003664			70S:	
1086					
1087					
1088					
1089					
1090					
1091					
1092	003664	012700	001412	ST2: MOV #DRIVS, R0	
1093	003670	012701	177767	MOV #-11, R1	
1094	003674	005020		13S: CLR (R0)+	
1095	003676	005201		INC R1	
1096	003700	001375		BNE 13S	
1097	003702	104401	003710	TYPE 65S	:TYPE ASCIZ STRING
1098	003706	000415		BR 64S	:GET OVER THE ASCIZ
1099				::65S: .ASCIZ	<15><12> 'DRIVES TO BE TESTED ?'<15><12>
1100	003742			64S:	
1101	003742	104411		RDLIN	
1102	003744	012600		MOV (SP)+, R0	:GET STARTING ADRES OF ASCII STRING
1103	003746	012701	177770	MOV #-10, R1	:SET UP COUNT
1104	003752	112002		15: MOV# (R0)+, R2	:GET ASCII CHARACTER
1105	003754	042702	177400	BIC #177400, R2	:MASK UNWANTED BITS
1106	003760	012703	001414	MOV #DRIVS, R3	
1107	003764	012704	177770	MOV #-10, R4	
1108	003770	012705	000060	MOV #60, R5	
1109	003774	020502		25: CMP R5, R2	:WAS THE TYPED IN CHARACTER
1110					:A NUMBER BETWEEN 0-7?
1111	003776	001414		BEO 3S	:YES, BRANCH
1112	004000	005205		INC R5	:NO, INCREMENT
1113	004002	005723		TST (R3)+	:INCREMENT POINTER TO DRV FLAG
1114	004004	005204		INC R4	:CHARACTER THAT WAS INPUT
1115	004006	001372		BNE 25	:SHOULD BE 0-7, IF ANY OTHER
1116					:TYPE ?? & AGAIN ASK FOR
1117					:DRIVS TO BE TSTD?
1118	004010	005702		TST R2	:IS IT A TERMINATOR?
1119	004012	001461		BEO 6S	:YES, EXIT. NO DRIVES INDICATED.
1120	004014			4S:	
1121	004014	104401	004022	TYPE 67S	:TYPE ASCIZ STRING
1122	004020	000402		BR 66S	:GET OVER THE ASCIZ
1123				::67S: .ASCIZ	'??/'
1124	004026			66S:	
1125	004026	000716		BR ST2	:GO, AGAIN ASK QUESTION
1126	004030	005713		TST #R3	:SEE IF ALL READY SELECTED
1127	004032	001370		BNE 4S	:ERROR IF SELECTED ALL READY
1128	004034	005213		INC #R3	:SET UP FLAG FOR THE DRIVE
1129	004036	005237	001412	INC DRIVS	:INCREMENT TOTAL NO OF DRIVES PRESENT
1130	004042	111002		11S: MOV# 2R0, R2	:GET NEXT CHAR


```

1131 004124 042702 177400 BIC #177400,R2 ; CHARACTER ONLY
1132 004126 022702 000106 CMP #F,R2 ; IS IT F?
1133 004128 001026 BNE #5 ; NO, GO ON
1134 004130 052713 100000 BVS #BIT15,DR3 ; SET BIT 15 TO SHOW RKOSF
1135 004132 032705 000001 BIT #BIT0,R5 ; EVEN DRIVE?
1136 004134 001407 BEQ #5 ; EVEN DRIVE SO BRANCH
1137 004136 005763 177776 TST -2(R3) ; CHECK EVEN DRIVE
1138 004138 001347 BNE #4 ; EVEN ALL READY SELECTED
1139 004140 012763 100001 177776 MOV #BIT15!BIT0,-2(R3) ; SELECT EVEN DRIVE
1140 004142 000406 BR #105 ; CONTINUE
1141 004144 005763 000002 95: TST 2(R3) ; CHECK ODD DRIVE
1142 004146 031340 BNE #4 ; ERROR IF SELECTED BEFORE
1143 004148 012763 100001 000002 MOV #BIT15!BIT0,2(R3) ; SELECT ODD DRIVE
1144 004150 005237 001412 105: INC DRVS ; COUNT DRIVES SELECTED
1145 004152 105720 TS #B ; POINT TO NEXT CHAR
1146 004154 000744 BR #115 ; CHECK FOR COMMA
1147 004156 022702 000054 85: CMP #54,R2 ; IS IT A 'COMMA'?
1148 004158 001403 BEQ #5 ; YES, GO PROCESS NXT WORD
1149 004160 005702 TST R2 ; NO, IS IT A TERMINATOR?
1150 004162 001324 BNE #4 ; IF NOT, SOMETHING WRONG
1151 004164 000404 BR #6 ; GO ASK QUESTION AGAIN
1152 004166 105720 55: TSTB (R0)+ ; EXIT, IF A TERMINATOR
1153 004168 005201 INC R1 ; INCREMENT PTR TO NXT BYTE
1154 004170 001277 BNE #1 ; THERE SHOULD BE NO MORE THAN
1155 004172 000717 BR #4 ; 8 DRIVES, HENCE IF MORE
1156 004174 005037 001440 65: CLR SIZYET ; NO SIZING NEEDED
1157 004176 032777 002000 174750 BIT #SW10,DSWR ; TESTING ON SIMULATOR?
1158 004178 001003 BNE #7 ; YES, BRANCH
1159 004180 005037 001344 CLR SIMUL ; NO, CLR FLAG
1160 004182 000502 BR #54
1161 004200 012737 000001 001344 75: MOV #1,SIMUL ; SET FLAG TO INDICATE SIMULATOR
1162 004202 000476 BR #54
1163
1164
1165
1166
1167
1168
1169
1170
1171 ;CHECK NUMBER OF DRIVES
1172 004210 012737 177777 001440 ST3: MOV #-1,SIZYET ; CHECK FOR RKOSF LATER
1173 004212 012737 004370 000004 MOV #55,DR4 ; SET UP ADRES FOR TIME-OUT VECTOR
1174 004214 005777 175076 TST DRKDS ; REFERENCE RKDS
1175 004216 005777 175104 TST DRKDA ; REFERENCE RKDA
1176 004218 012737 004462 000004 MOV #BADTMO,DR4
1177 004220 104401 TYPE MSG1
1178 004222 001216 MSG1
1179 004224 012700 177770 MOV #-10,R0 ; INITIALIZE COUNT FOR THE 8 DRIVES
1180 004226 005037 001412 CLR DRVS ; INITIALIZE # OF DRIVES PRESENT TO 0
1181 004228 005001 CLR R1 ; INITIALIZE ADDRESS TO DRIVE 0
1182 004230 005004 CLR R4
1183 004232 012702 001414 MOV #DRIV0,R2
1184 004234 010177 175046 15: MOV R1,DRKDA ; ADDRESS THE DRIVE
1185 004236 020177 175042 CMP R1,DRKDA ; CHECK, WAS IT ADDRESSED?
1186 004238 001405 BEQ #3 ; YES

```



```

1243 004460 000465          BR      TST1          :GO TO TEST 1
1244
1245
1246
1247
1248          :THIS ROUTINE HANDLES UNEXPECTED TIME OUTS
1249
1250 004462 011600      BACTMC: MOV      (SP),R0 ;SAVE PC WHERE TIME OUT OCCURED
1251 004464 005740      TST      -(R0)
1252 004466 022626      CMP      (SP)+,(SP)+ ;RESTORE STACK POINTER
1253 004470 104401 004476      TYPE     65$          ;:TYPE ASCIZ STRING
1254 004474 000407      BR      64$          ;:GET OVER THE ASCIZ
1255          ;:65$: .ASCIZ ('S)('2 'TIMEOUT,PC='
1256          ;:64$:
1257 004514 010046      MOV      R0,-(SP) ;SET UP FOR TYPING OUT PC
1258 004516 104402      TYPOC   ;GO TYPE OUT OCTAL PC
1259 004520 000000      HALT
1260 004522 000137 002636      JMP      @START
1261
1262
1263
1264          :THIS ROUTINE HANDLES UNEXPECTED INTERRUPTS FROM RK11
1265          :SW 9 AND 10 FOR LOOPING ON ERROR
1266          :AND LOOPING ON TEST IN WHICH TIMEOUT
1267          :OCCURRED, ARE PROVIDED.
1268
1269 004526 011600      BADINT: MOV      (SP),R0 ;SAVE PC WHERE INTERRUPT OCCURED
1270 004530 005740      TST      -(R0)
1271 004532 032777 020000 17440C      BIT      #20000,@SW9 ;INHIBIT ERROR TYPEOUT?
1272 004540 001014      BNE     1$          ;YES, DON'T TYPE OUT
1273 004542 104401      TYPE
1274 004544 001213      $CRLF
1275 004546 104401      TYPE
1276 004550 025702      EM43          ;:TYPE 'UNEXPEXED RK11 INTERRUPT'
1277          ;:TYPE ' AT PC='
1278 004552 104401 004560      TYPE     65$          ;:TYPE ASCIZ STRING
1279 004556 000403      BR      64$          ;:GET OVER THE ASCIZ
1280          ;:65$: .ASCIZ /,PC='
1281          ;:64$:
1282 004566 010046      MOV      R0,-(SP) ;SET UP FOR TYPING OUT PC
1283 004570 104402      TYPOC   ;GO TYPE OCTAL PC WHERE BAD
1284          ;:INTERUPT OCCURED
1285 004572 032777 001000 174340 1$: BIT      #1000,@SW9 ;LOOP ON ERROR?
1286 004600 001403      BEQ     2$          ;NO, BRANCH
1287 004602 022626      CMP      (SP)+,(SP)+ ;YES, REPOSITION STACK
1288 004604 000177 174276      JMP      @SLPADR ;GO TO THE STARTING ADDRESS OF
1289          ;:THE TEST THAT GAVE UNEXPECTED INTERRUPT
1290 004610 032777 040000 174322 2$: BIT      #40000,@SW9 ;LOOP ON TEST?
1291 004616 001401      BEQ     3$          ;NO, BRANCH
1292 004620 000002      RTI
1293 004622 000000      HALT          ;YES, LOOP. GO BACK WHER U INTERRUPTED FROM.
1294          ;:UNEXPEXED INTERRUPT OCCURED AS
1295          ;:INDICATED IN THE TYPE OUT.U CAN LOOP
1296          ;:ON ERROR, TEST OR INHIBIT TYPEOUT BY
1297 004624 000137 002636      JMP      @START ;SETTING APPROPRIATE SWITCHES.
1298          ;:GO BACK TO THE START OF THE
1299          ;:PROGRAM. THUS PRESSING CONTINUE
    
```

E04

MAINDEC-11-DZRKK-C
DZRKKC.F11

MACY11 27(1006)
22-SEP-76 08:47

04-OCT-76 16:06 PAGE 26
GET VALUE FOR SOFTWARE SWITCH REGISTER

SEQ 0043

: AFTER THE ABOVE HALT WILL
: RESTART THE PROGRAM

1299
1300
1301
1302
1303
1304
1305
1306
1307
1308
1309
1310
1311
1312
1313
1314
1315
1316
1317
1318
1319
1320
1321
1322
1323
1324
1325
1326
1327
1328
1329
1330
1331
1332
1333
1334
1335
1336
1337
1338
1339
1340
1341
1342
1343
1344
1345
1346
1347
1348
1349
1350
1351
1352
1353
1354

: RESTART AFTER POWER FAIL
: THE PROGRAM WOULD RESTART HERE IF POWER CAME BACK AFTER A FALIURE.

004630 004737 021650 PFSTRT: JSR PC,WATIME ;KILL TIME

: *TEST 1 CHECK THAT THE DRIVES THAT ARE NOT SPECIFIED ARE NOT FOUND TO BE PRESENT
: *THIS TEST CHECKS THAT THE DRIVES THAT ARE NOT SPECIFIED
: *(IN RESPONSE TO "DRIVS TO BE TSTD") ARE NOT FOUND TO BE PRESENT.
: *EVERY DRIVE FROM 0 TO 7 IS ADDRESSED. IF A PARTICULAR DRIVE
: *GIVES 'DRY' (IN RKDS), IT IS CHECKED THAT THIS DRIVE
: *WAS SPECIFIED BY THE USER, IF IT WAS NOT AN ERROR IS
: *REPORTED, GIVING THE DRIVE NUMBER. IT IS LIKELY THAT THE USER
: *MAY HAVE FORGOTTEN TO PUT THE DRIVE (THAT IS NOT SPECIFIED) ON
: *'LOAD'. IF THIS IS THE CASE THEN PUT THIS DRIVE ON 'LOAD'.
: *IF THIS IS NOT THE CASE, THERE IS A GENUINE ERROR. (TWO DIFFERENT
: *DRIVE ADDRESSES MAY BE RESULTING IN THE SELECTION OF THE SAME
: *PHYSICAL DRIVE.)

004634 000004

TST1: SCOPE

004636 012700 001414
004642 005001
004644 005002
004646 005737 001410
004652 001403
004654 120237 001410
004660 001435
004662 010177 174452
004666 105777 174434
004672 100005

MOV #DRIVO,R0 ; INITIALIZE POINTER
CLR R1 ; INITIALIZE DRIVE ADRES 0
CLR R2 ; INITIALIZE DRIVE # 0
15: TST DDPCH ; LOADED FROM AN RKDS ?
BEQ 25 ; B IF NOT
CMPB R2,DDPCH ; LOADED FROM THIS DRIVE ?
BEQ 45 ; BR IF YES
25: MOV R1,DRKDA ; ADRES THE DRIVE
TSTB DRKDS ; DRIVE READY?
BPL 35 ; NO, THIS DRIVE NOT PRESENT
; YES, THIS DRIVE SELECTED

004674 005710
004676 001026

TST DR0 ; WAS THIS DRIVE SPECIFIED BY
; THE USER?
BNE 45 ; YES, OK
; NO, THIS DRIVE # WAS NOT SPECIFIED
; BY THE USER, BUT STILL IS GIVING
; 'DRY' WHEN ADRESED. REPORT ERROR.

004700 010237 001162
004704 104116

MOV R2,SREGD ; GET DRIVE #
ERROR 116 ; THIS DRIVE # WAS NOT SPECIFIED BY
; THE USER, BUT WHEN ADRESED GAVE
; 'DRY'. CHECK THAT THIS DRIVE # IF
; PHYSICALLY PRESENT IS ON 'LOAD'. IF
; THIS IS NOT THE CASE, THEN ONE DRIVE
; MAY BE GETTING SELECTED BY TWO DIFFERENT
; LOGICAL ADDRESSES.

004706 005710
004710 001421

35: TST DR0 ; CHECK THAT THIS DRIVE WAS NOT INDICATED
BEQ 45 ; IF IT WAS, & IT IS NOT FOUND TO BE
; PRESENT (DRY CLEAR), REPORT ERROR.

F04

```

1355 004712 004737 020702 JSR PC,GT4RG ;GET RKCS, ER, DS, DA
1356 004716 104010 ERROR 10 ;DRIVE # (AS IN RKDA) WAS INDICATED BY
1357 ;THE USER, BUT WAS NOT FOUND TO BE PRESENT.
1358 ;CHECK THAT THE ROTARY DRIVE SELECTION
1359 ;SWITCH ON THE MODULE IS SET TO THE RIGHT
1360 ;DRIVE #.
1361
1362 004720 00501C CLR 0RD ;THIS DRIVE IS NOT FOUND TO BE PRESENT
1363 ;HENCE DROP IT FROM THE SELECTION TABLE.
1364 004722 010003 MOV R0,R3 ;DRIVE ADDR
1365 004724 162703 001414 SUB #DRIV0,R3 ;MINUS OFFSET FOR TABLE
1366 004730 042703 000003 BIC #3,R3 ;EVEN DRIVE OF PAIR
1367 004734 062703 001414 ADD #DRIV0,R3 ;POINT TO EVEN OF PAIR IF RK05 F
1368 004740 042723 100000 BIC #100000,(R3)+ ;NOT SPECIFIED AS F MODEL
1369 004744 042713 100000 BIC #100000,(R3) ;SAME
1370 004750 005337 001412 DEC DRIVS ;DECREMENT DRIVE COUNT
1371 004754 005202 4S: INC R2 ;INCRMNT DRIVE #
1372 004756 005720 TST (R0)+ ;INCRMNT POINTER
1373 004760 062701 020000 ADD #20000,R1 ;INCRMNT ADRES TO NXT DRIVE
1374 004764 001330 BNE 1S ;LUP BAK IF NOT DONE

```

```

;THIS PART OF THE PROGRAM IS GOING TO BE REPEATED FOR
;EACH DRIVE PRESENT
;
;'DRIVAD' CONTAINS IN BITS 15,14,13 THE ADDRESS OF THE
;DRIVE BEING CURRENTLY CHECKED.
;

```

NUDRV:

```

;*****
;TEST 2 FIND OUT NEXT DRIVE TO BE CHECKED
;THIS CODE FINDS OUT THE NEXT DRIVE THAT IS PRESENT AND THEN SETS UP
;THE ADDRESS IN DRIVAD (BITS 13,14,15). THUS THROUGHOUT THE FOLLOWING TESTS
;THE DRIVE TESTED IS THE DRIVE WHOOSE ADDRESS IS IN 'DRIVAD'.
;*****

```

```

1392 004766 000004 TST2: SCOPE
1393 004770 012737 000001 001206 MOV #1,$TIMES ;DO 1 ITERATION
1394 004776 012737 000002 001102 MOV #2,$TSTNM ;RESET POINTER TO THIS TEST
1395 ;NO. CHANGE THIS (2) IN CASE THE
1396 ;TEST NO. CHANGES
1397 005004 005037 001112 CLR $ERTTL ;CLEAR TOTAL ERROR COUNT
1398 005010 005737 001412 TST DRIVS ;R THERE ANY DRIVES PRESENT?
1399 005014 001002 BNE .+6 ;YES, BRANCH
1400 005016 000137 020560 4S: JMP $EOP ;NO, JMP TO THE END
1401 005022 013701 001354 MOV DRVPTR,R1 ;GET THAT POINTER TO THE NEXT
1402 ;DRIVE FLAG
1403 005026 032721 000001 2S: BIT #BIT0,(R1)+ ;IS THIS DRIVE PRESENT?
1404 005032 001005 BNE 1S ;YES
1405 005034 062737 020000 001350 6S: ADD #20000,DRIVAD ;FORM NXT DRIVE ADRES
1406 005042 001371 BNE 2S
1407 005044 000764 BR 4S
1408 005046 005737 001410 1S: TST DDPCH ;PROGRAM LOADED FROM AN RK05 ^
1409 005052 001413 BEQ 3S ;NO, BRANCH
1410 005054 013746 001350 MOV DRIVAD,-(SP) ;PUT TEST DRIVE ADDRESS ON THE STACK

```

```

1411 005070 000316 SWAB (SP) ;SETUP TO RIGHT JUSTIFY THE ADDRESS
1412 005062 006216 ASR (SP) ;RIGHT JUSTIFY THE ADDRESS
1413 005064 006216 ASR (SP) ;RIGHT JUSTIFY THE ADDRESS
1414 005066 006216 ASR (SP) ;RIGHT JUSTIFY THE ADDRESS
1415 005070 006216 ASR (SP) ;RIGHT JUSTIFY THE ADDRESS
1416 005072 006216 ASR (SP) ;RIGHT JUSTIFY THE ADDRESS
1417 005074 122637 001410 CMPB (SP)+,DPLCH ;PROGRAM LOADED FROM THIS DRIVE ?
1418 005100 001755 BEQ 65 ;BR IF YES, DON'T TEST THE DRIVE
1419 005102 010137 001354 35: MOV R1,DRVPTR ;STORE POINTER TO THE NEXT
1420 ;DRIVE FLAG
1421 005106 104401 001272 TYPE MSG4
1422 005112 013746 001350 MOV DRIVAD, -(R6) ;GET THE DRIVE ADDRESS
1423 005114 004737 021106 JSR PC,SHFTRT ;GO SHIFT IT TO THE RIGHT
1424 005122 005037 001404 CLR FFLAG
1425 005126 011600 MOV (R6),R0 ;DRIVE NUMBER
1426 005130 104403 TYPOS ;GO TYPE THE OCTAL # FOR THE
1427 ;DRIVE THAT IS BEING CHECKED
1428 005132 001 000 .BYTE 1,0
1429 005134 006300 ASL R0 ;INDEX TO TABLE
1430 005136 005760 001414 TST DRIVD(R0) ;SEE IF F
1431 005142 100006 BPL 55 ;NO
1432 005144 104401 005152 TYPE 655 ;TYPE ASCIZ STRING
1433 005150 000401 BR 645 ;GET OVER THE ASCIZ
1434 ;:655: .ASCIZ /F/
1435 005154 645:
1436 005154 005237 001404 INC FFLAG ;SET F FLAG
1437 005160 104401 55: TYPE
1438 005162 001213 $CRLF ;TYPE CR, LF
1439 *****
1440 ;*TEST 3 CHECK THAT DRIVE IS SUPPLIED WITH POWER-DPL BIT
1441 *****
1442 005164 000004 TST3: SCOPE
1443 005166 104413 CNT.RESET ;GO, DO CONTROL RESET
1444 ;THIS IS A CALL FOR THE 'CNTRL-
1445 ;RESET' ROUTINE. A CONTROL RESET IS
1446 ;ISSUED AND AFTER A CERTAIN TIME
1447 ;IF THE 'CNTRL RDY' DOES NOT SET
1448 ;AN ERROR IS REPORTED. NOTE THAT
1449 ;THE PC IN ERROR MESSAGE IS THE
1450 ;PC WHERE 'CNT.RESET' IS LOCATED.
1451 ;THIS IS A VERY BASIC ERR3 IF IT
1452 ;OCCURS GO BACK TO TEST 10
1453 005170 013700 001326 MOV RKDS,R0
1454 005174 013777 001350 174136 MOV DRIVAD,DRKDA ;ADDRESS THE DRIVE UNDER TEST
1455 005202 005710 TST DR0 ;CHECK IF ANY BIT OF RKDS IS SET?
1456 005204 001003 BNE 15 ;IF SET, BRANCH
1457 005206 011037 001162 MOV DR0,$REGO ;GET RKDS
1458 005212 104004 ERROR 4 ;RKDS ERROR! RKDS IF ADDRESSED
1459 ;CORRECTLY SHOULD BE NON-ZERO
1460 005214 012777 000015 174110 15: MOV #15,DRKCS ;ISSUE A DRV RESET, IF DRV
1461 ;POWER IS LO, DPL WILL SET
1462 005222 005001 CLR R1
1463 005224 032710 010000 25: BIT #10000,DR0 ;IS 'DPL' BIT SET?
1464 005230 001003 BNE 35 ;DPL IS SET, BRANCH
1465 005232 005201 INC R1 ;WAIT FOR SOME TIME TO
1466 005234 001373 BNE 25 ;SEE IF DPL WOULD SET

```

H04

MAINDEC-11-DZRKK-D MACY11 27(1006) 04-OCT-76 16:06 PAGE 29
DZRKKD.P11 22-SEP-76 08:47 T3

CHECK THAT DRIVE IS SUPPLIED WITH POWER-DPL BIT

SEG 0046

```

1467 005236 000403          BR      45-2          :OK, DPL NOT SET
1468 005240 004737 020710 35:  JSR    PC,GT3RG      :GO, GET RKCS, ER, DS
1469 005244 104005          ERROR   5            :DPL BIT OF RKDS IS SET. CHECK DRIVE POWER
1470
1471
1472 005246 005001          CLR     R1            :DID R/W/S RDY BIT SET?
1473 005250 032710 000100 45:  BIT    #100,R0       :YES, EXIT
1474 005254 001010          BNE    TS*4          :TIME DELAY
1475 005256 104417 000011          DELAY  11           :WAIT FOR R/W/S RDY
1476 005262 005201          INC    R1            :GET RKDS
1477 005264 001371          BNE    45            :R/W/S RDY DID NOT SET AFTER
1478 005266 017737 174034 001162  MOV    @RKDS,$REGO   :DRIVE RESET. DRIVE RESET WAS DONE
1479 005274 104016          ERROR   16           :TO CHECK 'DPL' BIT. THIS TEST
1480
1481
1482
1483
1484
1485
1486
1487
1488
1489
1490
1491
1492
1493
1494
1495
1496
1497
1498
1499

```

```

:*****
:*TEST 4      CHECK THAT 'DRIVE UNSAFE' IS CLEAR, 'HDEN' IS SET, 'WPS' IS CLEAR
:*****

```

```

1489 005276 000004  TST4:  SCOPE
1490 005300 104413          CNT.RESET
1491
1492
1493
1494
1495
1496
1497
1498
1499
1500 005302 013777 001350 174030  MOV    DRIVAD,@RKDA  :GO, DO CONTROL RESET
1501 005310 017700 174012          MOV    @RKDS,R0      :THIS IS A CALL FOR THE 'CNTRL-
1502 005314 032700 002000          BIT    #2000,R0     :RESET' ROUTINE. A CONTROL RESET IS
1503 005320 001403          BEQ    15            :ISSUED AND AFTER A CERTAIN TIME
1504 005322 004737 020710  JSR    PC,GT3RG      :IF THE 'CNTRL RDY' DOES NOT SET
1505 005326 104006          ERROR   6            :AN ERROR IS REPORTED. NOTE THAT
1506
1507
1508 005330 032700 004000 15:  BIT    #4000,R0     :THE PC IN ERROR MESSAGE IS THE
1509 005334 001004          BNE    25            :PC WHERE 'CNT.RESET' IS LOCATED.
1510 005336 017737 173764 001162  MOV    @RKDS,$REGO   :THIS IS A VERY BASIC ERR & IF IT
1511 005344 104007          ERROR   7            :OCCURS GO BACK TO TEST 10
1512
1513 005346 032777 000040 173752 25:  BIT    #40,@RKDS    :SET DRIVE ADDRESS
1514 005354 001403          BEQ    TST5          :GET RKDS
1515 005356 004737 020702  JSR    PC,GT4RG      :IS 'DRU' BIT OF RKDS SET?
1516 005362 104114          ERROR   114         :NO
1517
1518
1519
1520
1521
1522

```

```

:GO, DO CONTROL RESET
:THIS IS A CALL FOR THE 'CNTRL-
:RESET' ROUTINE. A CONTROL RESET IS
:ISSUED AND AFTER A CERTAIN TIME
:IF THE 'CNTRL RDY' DOES NOT SET
:AN ERROR IS REPORTED. NOTE THAT
:THE PC IN ERROR MESSAGE IS THE
:PC WHERE 'CNT.RESET' IS LOCATED.
:THIS IS A VERY BASIC ERR & IF IT
:OCCURS GO BACK TO TEST 10
:SET DRIVE ADDRESS
:GET RKDS
:IS 'DRU' BIT OF RKDS SET?
:NO
:GO, GET RKCS, ER, DS
:'DRU' BIT OF RKDS IS SET. CHECK
:DRIV BY PUTTING RUN/LOAD SW TO LOAD
:THEN BACK TO RUN
:IS 'HDEN' BIT SET?
:YES, BRANCH
:GET RKDS
:ERROR, 'RKDS' BIT IS NOT SET
:IS 'WPS' CLEAR?
::YES, EXIT
:GET RKCS, ER, DS, DA
:'WPS'-WRITE PROTECT STATUS- BIT OF
:OF RKDS SHOULD BE CLEAR. IF THIS DRIVE
:IS WRITE ENABLED. CHECK & SEE IF THIS
:DRIVE IS WRITE ENABLED, IF IT IS NOT.
:WRITE ENABLE IT.

```

1523
1524
1525
1526
1527
1528
1529
1530
1531
1532
1533
1534
1535
1536
1537
1538
1539
1540
1541
1542
1543
1544
1545
1546
1547
1548
1549
1550
1551
1552
1553
1554
1555
1556
1557
1558
1559
1560
1561
1562
1563
1564
1565
1566
1567
1568
1569
1570
1571
1572
1573
1574
1575
1576
1577
1578

005364 000004
005366 104413

005370 013777 001350 173742
005376 105777 173724
005402 100403
005404 004737 020702
005410 104010

005412 000004
005414 013777 001350 173716
005422 005001
005424 032777 000400 173674
005432 001006
005434 005201
005436 001372
005440 017737 173662 001162
005446 104011

005450 000004

```
*****
*TEST 5 CHECK THAT 'DRIVE READY' IS SET IN RKDS
*****
TST5: SCOPE
      CNT.RESET
      ;GO, DO CONTROL RESET
      ;THIS IS A CALL FOR THE 'CNTRL-
      ;RESET' ROUTINE. A CONTROL RESET IS
      ;ISSUED AND AFTER A CERTAIN TIME
      ;IF THE 'CNTRL RDY' DOES NOT SET
      ;AN ERROR IS REPORTED. NOTE THAT
      ;THE PC IN ERROR MESSAGE IS THE
      ;PC WHERE 'CNT.RESET' IS LOCATED.
      ;THIS IS A VERY BASIC ERR & IF IT
      ;OCCURS GO BACK TO TEST 10
      ;ADDRS THE DRIVE
      ;IS 'DRY' SET?
      ;YES, OK
      ;GO, GET RKCS, ER, DS, DA
      ;'DRY' NOT SET
      ;
*****
*TEST 6 CHECK THAT 'SOK' BIT CAN SET
      ;* THIS TEST CHECKS THAT WITHIN A CERTAIN TIME
      ;* 'SOK' BIT CAN SET, IF IT DOES NOT AN ERROR IS REPORTED
*****
TST6: SCOPE
      MOV DRIVAD, @RKDA ;ADDRS THE DRIVE
      CLR R1 ;INITIALIZE COUNT FOR TIMING WAIT LOOP
      BIT #400, @RKDS ;IS SOK SET?
      BNE TST7 ;EXIT
      INC R1 ;NO, WAIT
      BNE IS ;WAITED LONG?
      MOV @RKDS, $REGD ;GET RKCS
      ERROR 11 ;WAITED LONG BUT 'SEC OK' BIT DID NOT
      ;SET
      ;
*****
*TEST 7 CHECK THAT 'SECTOR COUNTER' CAN COUNT FROM 0-13
      ;* THIS TEST CHECKS THAT THE SECTOR COUNTER CAN COUNT FROM
      ;* 0-13
      ;* 1) FIRST, FOR INITIALIZING PURPOSES THERE IS A TIMED LOOP
      ;* DURING WHICH SECTOR COUNTER SHOULD COUNT DOWN TO 0. IF THIS
      ;* IS NOT DONE AN ERROR IS REPORTED
      ;* 2) AFTER A COUNT OF 0 IS REACHED, THE PROGRAM WAITS
      ;* FOR A CERTAIN TIME, DURING WHICH THE SEC COUNTER
      ;* IS SAMPLED. IF THE COUNTER DOES NOT CHANGE WITHIN THIS
      ;* TIME PERIOD AN ERROR IS REPORTED.
      ;* 3) UPON FINDING THAT THE COUNTER HAS CHANGED, IT IS CHECKED
      ;* IF IT INCREMENTED CORRECTLY. IF IT DID NOT AN ERROR IS REPORTED
      ;* 4) IF IT INCREMENTED CORRECTLY, THE PROGRAM AGAIN WAITS IN A
      ;* LOOP TILL THE COUNTER CHANGES. (STEPS 2,3,4 ARE REPEATED
      ;* TILL THE COUNTER COUNTS UP TO 13)
*****
TST7: SCOPE
```


K04

MAINDEC-11-DZRKK-D
DZRKKC.P11

MACY11 27(1006)
22-SEP-76 08:47

04-OCT-76 16:06 PAGE 32
T7 CHECK THAT 'SECTOR COUNTER' CAN COUNT FROM 0-13

SEQ 0049

```

1635                                     ;DID NOT COUNT TO 0
1636 005624 000421                       BR    TST10                       ;;EXIT
1637
1638 005626 017737 173474 001162 7$:   MOV    DRKDS,$REG0           ;GET RKDS
1639 005634 104011                       ERROR  11                   ;WAITED LONG, BUT 'SOK' BIT DID
1640                                     ;NOT SET
1641 005636 000414                       BR    TST10                       ;;EXIT
1642
1643 005640 010237 001162 8$:   MOV    R2,$REG0           ;GET SEC CNTR (PRESENT COUNT)
1644 005644 110337 001164           MOV    R3,$REG1           ;GET "NEXT COUNT"
1645 005650 104013                       ERROR  13                   ;WAITED LONG, BUT THE SECTOR
1646                                     ;COUNTER DID NOT INCREMENT FROM
1647                                     ;THE PRESENT COUNT TO THE NEXT COUNT
1648 005652 000406                       BR    TST10                       ;;EXIT
1649
1650 005654 010337 001162 9$:   MOV    R3,$REG0           ;GET 'NEXT COUNT' (SEC CNTR SHOULD BE THIS)
1651 005660 010237 001164           MOV    R2,$REG1           ;GET PRESENT COUNT (WHAT SEC CNTR WAS)
1652 005664 104014                       ERROR  14                   ;SEC CNTR INCREMENTED WRONG, DID
1653                                     ;NOT INCREMENT FROM PRESENT COUNT
1654                                     ;TO NEXT COUNT
1655 005666 000747                       BR    5$
1656 ;
1657
1658 ;*****
1659 ;*TEST 10      CHECK THAT SC=SA CAN BE GENERATED
1660 ;* THIS TEST CHECKS THAT SC=SA CAN BE GENERATED FOR
1661 ;* EVERY SECTOR
1662 ;*****
1663 005670 000004  †TST10:  SCOPE
1664 005672 104413          CNT.RESET
1665                                     ;GO, DO CONTROL RESET
1666                                     ;THIS IS A CALL FOR THE 'CNTRL-
1667                                     ;RESET' ROUTINE. A CONTROL RESET IS
1668                                     ;ISSUED AND AFTER A CERTAIN TIME
1669                                     ;IF THE 'CNTRL R-Y' DOES NOT SET
1670                                     ;AN ERROR IS REPORTED. NOTE THAT
1671                                     ;THE PC IN ERROR MESSAGE IS THE
1672                                     ;PC WHERE 'CNT.RESET' IS LOCATED.
1673                                     ;THIS IS A VERY BASIC ERR & IF IT
1674                                     ;OCCURS GO BACK TO TEST 10
1675
1676 005674 013704 001350           MOV    DRIVAD,R4
1677 005700 013700 001326           MOV    RKDS,R0
1678 005704 012703 177764           MOV    #-14,R3
1679 005710 010477 173424 1$:   MOV    R4,DRKDA
1680 005714 005005                       CLR    R5
1681 005716 005205 2$:   INC    R5
1682 005720 001410                       BEQ    3$
1683 005722 011001                       MOV    DR0,R1
1684 005724 032701 000020           BIT    #20,R1
1685 005730 001772                       BEQ    2$
1686 005732 005204 4$:   INC    R4
1687 005734 005203                       INC    R3
1688 005736 001364                       BNE    1$
1689 005740 000406                       BR    TST11
1690
1689 005742 110437 001162 3$:   MOVB   R4,$REG0           ;GET SECTOR ADDRESS
1690 005746 010137 001164           MOV    R1,$REG1           ;GET RKDS

```


1915	006424	012703	033240		MOV	#OUTBUF,R3			
1916									: THIS CODE SETS UP A 256 WORD BUFFER
1917									: WHICH WILL BE USED TO WRITE 1 SECTOR
1918									: ON THE DISK
1919									: 1ST WORD 000001
1920									: 2ND WORD 177777 2'S COMPLEMENT
1921									: 3RD WORD 000002 OF ABOVE
1922									: 4TH WORD 177776
1923									: 253RD WORD 000177
1924									: 254TH WORD 177601
1925									: 255TH WORD 000000
1926									: 256TH WORD 125252
1927	006430	012700	000001		MOV	#1,R0			: SET COUNT
1928									
1929	006434	010023		95:	MOV	R0,(R3)+			: SET JP DATA WORDS
1930	006436	010013			MOV	R0,(R3)			
1931	006440	005423			NEG	(R3)+			
1932	006442	005200			INC	R0			
1933	006444	022700	000200		CMF	#200,R0			: DONE?
1934	006450	001371			BNE	95			
1935	006452	005023			CLR	(R3)+			: SET 255TH WORD TO 0
1936	006454	012713	125252		MOV	#125252,R3			: SET 256TH WORD
1937									
1938	006460	012703	033240		MOV	#OUTBUF,R3			: RESET POINTER TO OUTBUF
1939	006454	013701	001332		MOV	RKCS,R1			
1940	006470	013702	001336		MOV	RKBA,R2			
1941	006474	010312			MOV	R3,R2			: FROM HERE-SET UP CURRENT ADDRESS
1942	006476	012777	177400	17263C	MOV	#-400,RKWC			: SET UP WORD COUNT 400 WORDS
1943	006504	013777	001350	172626	MOV	DRIVAD,RKDA			: SET UP DISK ADDR. SECTOR 0, CYLINDER 0
1944	006512	012711	002003		MOV	#2003,R1			: WRITE FORMAT, GO
1945									
1946	006516	105711		15:	TSTB	R1			: WAS 'CNTRL RDY' CLEARED AS GO WAS SET?
1947	006520	100003			BPL	25			: YES, BRANCH
1948	006522	004737	020710		JSR	PC,GT3RG			: GO, GET RKCS, ER, DS
1949	006526	104030			ERROR	30			: 'CNTRL RDY' DIDN'T CLEAR AS GO
1950									: WAS SET TO 'WRITE FORMAT'
1951									
1952	006530	005000		25:	CLR	R0			: WAS 'CNTRL RDY' SET ON COMPLETION OF WRITE?
1953	006532	105711			TSTB	R1			: YES, BRANCH
1954	006534	100411			BMI	35			: NO, HAVE U WAITED LONG ENOUGH?
1955	006536	005200			INC	R0			: IF NOT, LOOP BACK & WAIT
1956	006540	001374			BNE	25+2			: IF YES, REPORT ERROR
1957									: GO, GET RKCS, ER, DS, DA
1958	006542	004737	020702		JSR	PC,GT4RG			
1959	006546	013737	001350	001202	MOV	DRIVAD,\$REGIO			: GO TO 'BD4H' & BREAK CONTENTS OF
1960	006554	104416			BRKDA4				: \$REGIO INTO DR #,CYL,SUR,SEC BITS
1961									: 'CNTRL RDY' DIDN'T SET ON COMPLETION
1962	006556	104031			ERROR	31			: OF WRITE FORMAT
1963									: WRT FMT WAS DONE STARTING AT <DSK-ADRES>
1964									: INDICATED IN EROR MSGE.
1965									: GO CHECK IF 'HE' OR 'ERR' BIT SET.
1966	006560	004737	021142	35:	JSR	PC,CHKHE			: IF YES, SAVE RKCS, ER, DS, DA.
1967									: RETURN HERE IF ERROR.
1968									: 'HE' OR 'ERR' BIT SET WHILE DOING
1969									
1970	006564	104032			ERROR	32			

1971
1972
1973
1974
1975
1976
1977
1978
1979
1980
1981
1982
1983
1984
1985
1986
1987
1988
1989
1990
1991
1992
1993
1994
1995
1996
1997
1998
1999
2000
2001
2002
2003
2004
2005
2006
2007
2008
2009
2010
2011
2012
2013
2014
2015
2016
2017
2018
2019
2020
2021
2022
2023
2024
2025
2026

006566 004737 021170
006572 104033
006574 004737 021224
006600 104034
006602 022712 034240
006606 001406
006610 012737 034240 001162
006616 011237 001164
006622 104035
006624 004737 021250
006630 104036
006632 022711 002202
006636 001406
006640 012737 002202 001162
006646 011137 001164
006652 104024

48: JSR PC,CHKDA
ERROR 33
55: JSR PC,CHKWC
ERROR 34
65: CMP #OUTBUF+1000,2R2
BEQ 75
MOV #OUTBUF+1000,\$REG0
MOV 2R2,\$REG1
ERROR 35
75: JSR PC,CHKER
ERROR 36
85: CMP #2202,2R1
BEQ TST16
MOV #2202,\$REG0
MOV 2R1,\$REG1
ERROR 24

:A WRITE FORMAT
:WRT FMT WAS DONE STARTING AT 'DSY-ADRES
:INDICATED IN ERGR MSGE.
:GO CHECK IF RKDA INCREMENTED CORRECTLY
:IF NOT, RETURN HERE.
:RKDA SHOULD HAVE INCREMENTED BY
:1 SECTOR, IT DID NOT
:CHECK IF WORD COUNT OVERFLOWED, IF
:NOT RETURN HERE.
:RKWC DID NOT OVERFLOW TO 0, AFTER
:XFER ON WRITE FORMAT
:DID RKBA INCREMENT CORRECTLY?
:YES, BRANCH
:GET EXPCD RKBA
:GET ACTUAL RKBA
:RKBA DIDN'T INCREMENT BY 1000 AFTER
:WRITE FORMAT OF 400 WORDS
:CHECK IOF ANY BIT IN RKER SET.
:IF YES RETURN HERE.
:RKER BIT SET ON DOING 1 WORD
:WRITE FORMAT
:DOES RKCS STILL HAVE 'WRT FMT' BITS?
:YES, EXIT
:SET EXPCD RKCS
:GET ACTUAL RKCS
:RKCS DIDN'T CONTAIN 'WRT FMT' BITS
:AFTER THE FUNCTION WAS COMPLETED

:TEST 16 CHECK 'READ FORMAT' FUNCTION-CYLINDER 0, SECTOR 0
:THIS TEST CHECKS THE LOGIC INVOLVED IN THE WRITE FMT
:FUNCTION. ON ISSUING A WRT FMT, THE FOLLOWING IS CHECKED
:*1) CNTRL RDY WAS CLEARED AS GO WAS SET.
:*2) CNTRL RDY SETS WITHIN A CERTAIN TIME ON COMPLETION OF FUNCTION
:*3) IF 'HE' OR 'ERR' BIT SET?
:*4) IF RKDA INCREMENTED CORRECTLY FROM 0 TO 1?
:*5) IF RKWC OVERFLOWED CORRECTLY TO 0?
:*6) IF RKBA INCREMENTED CORRECTLY BY 2?
:*7) IF ANY BIT IN RKER SET?
:*8) IF THE CORRECT HEADER WAS RECEIVED?
:*9) FOR RK11C, AFTER RD FMT RKDB CONTAINS THE CHECKSUM
:FOR THAT SECTOR. (125252 IN THIS CASE, BECAUSE THE
:*FIRST WORD IN SEC 0 WAS WRITTEN AS 125252 IN
:*THE PREVIOUS TEST)
:*10) FOR RK11D, AFTER RD FMT RKDB SHOULD CONTAIN
:*A ZERO
:*11) IF THE RD FMT FUNCTION BITS ARE STILL IN
:*THE RKCS?

006654 000004
006656 005000
006660 104413

TST16: SCOPE
CLR RD
CNT.RESET

:GO, DO CONTROL RESET
:THIS IS A CALL FOR THE 'CNTRL-
:RESET' ROUTINE. A CONTROL RESET IS
:ISSUED AND AFTER A CERTAIN TIME
:IF THE 'CNTRL RDY' DOES NOT SET

E05

MAINDEC-11-DZRAK-C MACY:1 27:1006) 04-OCT-76 16:06 PAGE 39
 DZRAK.C.P11 22-SEP-76 08:47 T16 CHECK 'READ FORMAT' FUNCTION-CYLINDER 0, SECTOR 0

SEG 0056

2027									:AN ERROR IS REPORTED. NOTE THAT
2028									:THE PC IN ERROR MESSAGE IS THE
2029									:PC WHERE 'CNT.RESET' IS LOCATED.
2030									:THIS IS A VERY BASIC ERR & IF IT
2031									:OCCURS GO BACK TO TEST 10
2032	006662	104421							:GO CHECK IF SIN IS SET
2033									:IF SET, DO DRIVE RESET TO CLR IT
2034	006664	013701	001332						
2035	006670	013702	001336						
2036	006674	012703	033240						
2037	006700	010312							:SETUP ADRS WHERE HEADER WORD IS TO BE
2038									:X-FERRED
2039	006702	012777	177777	172424					:SET UP WORD COUNT
2040	006710	013777	001350	172422					:SET UP DISK ADRS, SECTOR 0, CYLINDER 0
2041	006716	012711	002005						:READ FORMAT, GO
2042									
2043	006722	105711			15:				:WAS 'CNTRL RDY' CLEARED AS GO WAS SET?
2044	006724	100003							:YES, BRANCH
2045	006726	004737	020710						:GO, GET RKCS, RKER
2046	006732	104030							:CNTRL RDY DIDN'T CLEAR AS GO WAS
2047									:SET TO 'READ FORMAT'
2048	006734	005000			25:				
2049	006736	105711							:WAS 'CNTRL RDY' SET ON COMPLETION OF
2050									:TRANSFER
2051	006740	100411							:YES, BRANCH
2052	006742	005200							:NO, HAVE U WAITED LONG ENOUGH?
2053	006744	001374							:IF NOT, LOOP BACK & WAIT
2054									:IF YES, REPORT ERROR
2055	006746	004737	020702						:GO, GET RKCS, ER, DS, DA
2056	006752	013737	001350	001202					
2057	006760	104416							:GO TO 'BDAY' & BREAK CONTENTS OF
2058									:SREGIO INTO DR #, CYL, SUR, SEC BITS
2059	006762	104045							: 'CNTRL RDY' DIDN'T SET ON COMPLETION
2060									:OF READ FORMAT
2061									:READ FMT WAS DONE STARTING AT <DSK-ADRES>
2062									:INDICATED IN EROR MESGE
2063	006764	004737	021142			35:			:CHECK IF 'ERR' OR 'HE' BIT SET, IF
2064									:YES RETURN HERE.
2065	006770	104046							: 'HE' OR 'ERR' BIT SET WHILE
2066									:DOING A 'READ FORMAT'
2067									:READ FMT WAS DONE STARTING AT <DSK-ADRES>
2068									:INDICATED IN EROR MESGE
2069	006772	004737	021170			45:			:CHECK IF RKDA INCREMENTED CORRECTLY
2070									:IF NOT, RETURN HERE.
2071	006776	104040							:RKDA SHOULD HAVE INCREMENTED
2072									:BY 1 SECTOR, IT DID NOT
2073									
2074	007000	004737	021224			55:			:CHECK IF RKWC OVERFLOWED TO 0. IF
2075									:NOT RETURN HERE.
2076	007004	104041							:RKWC DID NOT OVERFLOW TO 0
2077									:AFTER XFER ON READ FORMAT
2078	007006	022712	033242			65:			:DID RKBA INCREMENT TO NXT WORD ADRES?
2079	007012	001406							:YES, BRANCH
2080	007014	012737	033242	001162					:GET EXPCD RKBA
2081	007022	011237	001164						:GET ACTUAL RKBA
2082	007026	104042							:RKBA DIDN'T INCREMENT BY 2 AFTER

F05

```

2083          : 'READ FORMAT' OF 1 WORD
2084 007030 004737 021250 75: JSP PC,CHKR : CHECK IF ANY BIT IN RKER SET. IF
2085          : YES RETURN HERE.
2086 007034 104036          : RKER BIT SET ON DOING
2087          : 1 WORD READ FORMAT
2088 007036 005713 85: TST 0R3 : DOES OUTBUF CONTAIN THE HEADER
2089          : WORD-0
2090 007040 001407          : YES, BRANCH
2091 007042 005037 001162 : GET SECTOR NO.
2092 007046 005037 001164 : EXPCD HEADER
2093 007052 011337 001166 : GET HEADER RECVD
2094 007056 104043          : CORRECT HEADER WORD-0-WAS
2095          : NOT RECEIVED ON READ FORMAT
2096 007060 022711 002204 95: CMP 02204,0R1 : DOES RKCS HAVE THE 'RDFMT' BITS?
2097 007064 001406          : YES, BRANCH
2098 007066 012737 002204 001162 : GET EXPCD RKCS
2099 007074 011137 001164 : GET ACTUAL RKCS
2100 007100 104024          : RKCS DIDN'T CONTAIN 'RD FMT'
                : BITS AFTER FUNCTION WAS
                : COMPLETED
  
```

```

*****
*TEST 17 CHECK 'READ' FUNCTION-CYLINDER 0, SECTOR 0
*THIS IS THE FIRST TIME A PURE READ IS PERFORMED IN THIS
*TEST SEQUENCE. THE FOLLOWING IS CHECKED
*1) CNTRL RDY CLEARS AS GO IS SET
*2) CNTRL RDY SETS WITHIN A CERTAIN TIME ON COMPLETION
*OF FUNCTION
*3) IF 'HE' OR 'ERR' BIT SET?
*4) IF RKDA INCREMENTED CORRECTLY?
*5) IF RKWC OVERFLOWED TO 0?
*6) IF RKBA INCREMENTED CORRECTLY?
*7) IF ANY RKER BIT SET?
*8) IF THE CORRECT PSUEDO-HEADER (FIRST WORD) WAS
*READ FROM SECTOR 0
*9) IF THE 'READ' FUNCTION BITS ARE STILL IN RKCS
*****
  
```

```

2122 007102 000004
2123 007104 104413
2124          : GO, DO CONTROL RESET
2125          : THIS IS A CALL FOR THE 'CNTRL-
2126          : RESET' ROUTINE. A CONTROL RESET IS
2127          : ISSUED AND AFTER A CERTAIN TIME
2128          : IF THE 'CNTRL RDY' DOES NOT SET
2129          : AN ERROR IS REPORTED. NOTE THAT
2130          : THE PC IN ERROR MESSAGE IS THE
2131          : PC WHERE 'CNT.RESET' IS LOCATED.
2132          : THIS IS A VERY BASIC ERR & IF IT
2133 007106 104421          : OCCURS GO BACK TO TEST 10
2134          : GO CHECK IF SIN IS SET
2135          : IF SET, DO DRIVE RESET TO CLR IT
2135 007110 013701 001332 : MOV RKCS,R1
2136 007114 005000          : CLR R0
2137 007116 013702 001336 : MOV RKBA,R2
2138 007122 012703 033240 : MOV 0OUTBUF,R3
  
```

G05

MAINDEC-11-DZRKK-D
DZRKKC.P11 22-SEP-76

MACY11 27(1006)
08:47

04-OCT-76 16:06 PAGE 41
T17 CHECK READ FUNCTION-CYLINDER 0, SECTOR 0

SEQ 0058

2139	007126	010312			MOV	R3,AR2		:SET UP ADDRS WHERE DATA WORD IS
2140								:TO BE X-FERRED
2141	007130	012777	177400	172176	MOV	#-400,ARKWC		:SET UP WORD COUNT
2142	007136	013777	001350	172174	MOV	DRIVAD,ARKDA		:SET UP DISK ADRS. SECTOR 0, CYLINDER 0
2143	007144	012711	000005		MOV	#5,AR1		:READ, GO
2144								
2145	007150	105711			15:	TSTB	AR1	:WAS 'CNTRL RDY' CLEARED AS GO WAS SET?
2146	007152	100003				BPL	25	:YES, BRANCH
2147	007154	004737	020710			JSR	PC,GT3RG	:GO, GET RKCS, ER
2148	007160	104030				ERROR	30	:CNTRL RDY DID NOT CLEAR AS GO
2149								:WAS SET TO 'READ'
2150	007162	005000			25:	CLR	RO	:WAS CNTRL RDY SET ON COMPLETION
2151	007164	105711				TSTB	AR1	:OF TRANSFER?
2152								:YES, BRANCH
2153	007166	100411				BMI	35	:NO, HAVE U WAITED LONG ENOUGH?
2154	007170	005200				INC	RO	:IF NOT, LOOP BACK & WAIT
2155	007172	001374				BNE	25+2	:IF YES, REPORT ERROR
2156								:GO, GET RKCS, ER, DS,DA
2157	007174	004737	020702			JSR	PC,GT4RG	
2158	007200	013737	001350	001202		MOV	DRIVAD,\$REG10	
2159	007206	104416				BRKDA4		:GO TO 'BD4' & BREAK CONTENTS OF
2160								:\$REG10 INTO DR #,CYL,SUR,SEC BITS
2161	007210	104045				ERROR	45	:CNTRL RDY DID NOT SET ON
2162								:COMPLETION OF READ
2163								:READ WAS DONE STARTING AT <DSK-ADRES>
2164								:INDICATED IN EROR MESGE
2165								
2166	007212	004737	021142		35:	JSR	PC,CHKHE	:CHECK IF 'ERR' OR 'HE' BIT IS SET
2167								:IF YES, RETURN HERE.
2168	007216	104046				ERROR	46	: 'HE' OR 'ERR' BIT SET WHILE
2169								:DOING A READ.
2170								:READ WAS DONE STARTING AT <DSK-ADRES>
2171								:INDICATED IN EROR MESGE
2172	007220	004737	021170		45:	JSR	PC,CHKDA	:CHECK IF RKDA INCREMENTED CORRECTLY.
2173								:IF NOT RETURN HERE.
2174	007224	104040				ERROR	40	:RKDA DID NOT INCREMENT
2175								:BY 1 (SECTOR)
2176	007226	004737	021224		55:	JSR	PC,CHKWC	:CHECK IF RKWC OVERFLOWED TO 0,
2177								:IF NOT RETURN HERE.
2178	007232	104041				ERROR	41	:RKWC DID NOT OVERFLOW TO 0,
2179								:AFTER X-FER ON READ
2180	007234	022712	034240		65:	CMP	#OUTBUF+1000,AR2	:DID RKBA INCREMENT CORRECTLY?
2181	007240	001406				BEQ	75	:YES, BRANCH
2182	007242	012737	034240	001162		MOV	#OUTBUF+1000,\$REG0	:GET EXPCTD RKBA
2183	007250	011237	001164			MOV	AR2,\$REG1	:GET ACTUAL RKBA
2184	007254	104042				ERROR	42	:RKBA DID NOT INCREMENT BY 2
2185								:AFTER 'READ' OF 1 WORD
2186	007256	004737	021250		75:	JSR	PC,CHKER	:CHECK IF ANY BIT IN RKER SET,
2187								:IF YES RETURN HERE.
2188	007262	104036				ERROR	36	:RKER BIT SET ON DOING 1
2189								:WORD 'READ'
2190	007264	022713	000001		85:	CMP	#1,AR3	:DOES OUTBUF CONTAIN THE RIGHT
2191								:DATA WORD
2192	007270	001411				BEQ	95	:YES BRANCH
2193	007272	012737	000001	001162		MOV	#1,\$REG0	:GET EXPCTD DATA WORD
2194	007300	011337	001164			MOV	(R3),\$REG1	:GET RECVD DATA WORD

H05

MAINDEC-11-DZRAK-D MACY11 27(1006) 04-OCT-76 16:06 PAGE 42
DZRAK0.P11 22-SEP-76 08:47 T17 CHECK 'READ' FUNCTION-CYLINDER 0, SECTOR 0

SEQ 0059

```

2195 007304 013737 001350 001166      MOV    DRIVAD, $REG2    ;GET DISK ADRS FROM WHICH READ WAS DONE
2196 007312 104044                      ERROR   44             ;DID NOT READ THE CORRECT
2197                                         ;DATA WORD--FROM DISK ADRES,
2198                                         ;
2199                                         ;SEC 0, CYL 0, SUR 0
2200                                         ;
2201                                         ;AFTER 1 SECTOR READ RKDB CONTAINS
2202                                         ;FOR RK11C
2203                                         ;THE CHECKSUM FOR THAT SECTOR
2204                                         ;FOR RK11D
2205                                         ;THE LAST WORD TRANSFERRED TO MEMORY
2206                                         ;
2207                                         ;IT SO HAPPENS THAT WITH THE SECTOR
2208                                         ;THAT WAS READ, RKDB CONTAINS THE
2209                                         ;SAME INFORMATION FOR BOTH RK11C
2210                                         ;AND RK11D
2211 007314 022777 125252 172020 95:      CMP     #125252, @RKDB  ;DOES RKDB CONTAIN THE EXPCTD WORD?
2212 007322 001407                      BEQ     105            ;YES, BRANCH
2213 007324 012737 125252 001162      MOV     #125252, $REG0 ;GET EXPCTD RKDB
2214 007332 017737 172004 001164      MOV     @RKDB, $REG1  ;GET RECD RKDB
2215 007340 104037                      ERROR   37            ;RKDB DOES NOT CONTAIN THE
2216                                         ;EXPCTD WORD AFTER A READ OF SEC 0
2217                                         ;CYL 0
2218 007342 022711 000204 105:      CMP     #204, @R1     ;DOES RKCS HAVE THE 'READ' BITS?
2219 007346 001406                      BEQ     115            ;YES, BRANCH
2220 007350 012737 000204 001162      MOV     #204, $REG0   ;GET EXPCTD RKCS
2221 007356 011137 001164      MOV     @R1, $REG1   ;GET RECD RKCS
2222 007362 104024                      ERROR   24            ;RKCS DID NOT CONTAIN 'READ'
2223                                         ;FUNCTION BITS AFTER OPERATION
2224                                         ;WAS COMPLETED
2225                                         ;GO DO CONTROL RESET
2226 007364 104413 115:      CNT. RESET           ;DID CONTROL RESET CLEAR RKDB?
2227 007366 005777 171750      TST     @RKDB
2228 007372 001407                      BEQ     TST20         ;YES, EXIT
2229 007374 013737 001342 001164      MOV     RKDB, $REG1  ;GET ADRES OF RKDB
2230 007402 017737 171734 001164      MOV     @RKDB, $REG1 ;GET CONTENTS OF RKDB
2231 007410 104102                      ERROR   102          ;CONTROL RESET DIDN'T CLR RKDB

```

```

2232 ;*****
2233 ;*TEST 20 CHECK 'WRITE FORMAT' -CYLINDER 0, SECTOR 0-13
2234 ;*THIS TEST GOES ONE STEP FURTHER & PERFORMS A WRT
2235 ;*FMT ON CYLINDER 0 & CHECKS THE FOLLOWING
2236 ;*1) IF CNTRL RDY SET WITHIN A CERTAIN TIME ON COMPLETION
2237 ;*OF THE FUNCTION
2238 ;*2) IF 'HE' OR 'ERR' BIT SET?
2239 ;*3) IF THE RKDA INCREMENTS CORRECTLY?
2240 ;*4) IF THE RKDB IS CLEAR?
2241 ;*WRT FMT IS DONE ONE SECTOR AT A TIME
2242 ;*THE FIRST WORD OF EVERY SECTOR IS WRITTEN AS A
2243 ;*PSUEDO-HEADER CONSISTING OF DRIVE #, CYLINDER #, SURFACE
2244 ;*# SECTOR #. THIS WILL BE READ & CHECKED IN THE FOLLOWING TEST.
2245 ;*****

```

```

2246 007412 000004      †TST20: SCOPE
2247 007414 013703 001332      MOV     RKCS, R3
2248 007420 012702 177764      MOV     #-14, R2     ;SET UP COUNT FOR 12 SECTORS
2249 007424 013704 001340      MOV     RKDA, R4
2250 007430 013701 001350      MOV     DRIVAD, R1   ;GET DRIVE ADDRESS

```

105

MAINDEC-11-DZRKK-D MACY11 27(1006) 04-OCT-76 16:06 PAGE 43
 DZRKKC.P11 22-SEP-76 08:47 T20 CHECK 'WRITE FORMAT' -CYLINDER 0, SECTOR 0-13

SEQ 0060

2251	007434	010105				MOV	R1,R5	;STORE IT
2252	007436	005205				INC	R5	
2253	007440	012737	007446	001110		MOV	#1\$,SLPERR	;SET RETURN ADRES FOR LUPING
2254								;ON ERROR (SW 9)
2255	007446	104413			1\$:	CNT.RESET		;GO DO CONTROL RESET
2256								;THIS IS A CALL FOR THE 'CNTRL-
2257								;RESET' ROUTINE. A CONTROL RESET IS
2258								;ISSUED AND AFTER A CERTAIN TIME
2259								;IF THE 'CNTRL RDY' DOES NOT SET
2260								;AN ERROR IS REPORTED. NOTE THAT
2261								;THE PC IN ERROR MESSAGE IS THE
2262								;PC WHERE 'CNT.RESET' IS LOCATED.
2263								;THIS IS A VERY BASIC ERR & IF IT
2264								;OCCURS GO BACK TO TEST 10
2265	007450	104421				TST.SIN		;GO CHECK IF SIN IS SET
2266								;IF SET, DO DRIVE RESET TO CLR IT
2267	007452	005000				CLR	RO	
2268	007454	010137	033240			MOV	R1,OUTBJF	;THIS WORD TO BE X-FERRED. FIRST
2269								;WORD OF EACH SECTOR WILL BE THE
2270								;ACTUAL DRIVE-ADRS CONSISTING OF
2271								;DRIVE NO, CYL ADRS, SURFACE
2272								;SECTOR NO.
2273	007460	012777	033240	171650		MOV	#OUTBUF,ARKBA	;ADRS FROM WHICH DATA WORD IS TO
2274								;X-FERRED
2275	007466	012777	177777	171640		MOV	#-1,ARKWC	;SET UP WORD COUNT
2276	007474	010114				MOV	R1,AR4	;ADRS THE DRIVE, CYL 0, & CORRECT SECTOR
2277	007476	012713	002003			MOV	#2003,AR3	;WRITE FORMAT, GO
2278								
2279	007502	105777	171624		2\$:	TSTB	ARKCS	;DID 'CNTRL RDY' SET?
2280	007506	100410				BMI	3\$;YES, BRANCH
2281	007510	005200				INC	RO	;NO, HAVE U WAITED LONG?
2282	007512	001373				BNE	2\$;IF NOT, LOOP BACK & WAIT
2283								;IF YES, REPORT ERROR
2284	007514	004737	020702			JSR	PC,GT4RG	;GO GET RKCS, ER, DS, DA
2285	007520	010137	001202			MOV	R1,\$REG10	;GET DISK ADRS (UNIT,CYL,SUR,SEC) TO WHICH
2286								;WRITE FORMAT WAS DONE
2287	007524	104416				BRKDA4		;GO TO 'BDAY' & BREAK CONTENTS OF
2288								;\$REG10 INTO DR #,CYL,SUR,SEC BITS
2289	007526	104031				ERROR	31	; 'CNTRL RDY' DID NOT SET ON COMPLETION
2290								;OF 'WRITE FORMAT'
2291								;WRT FMT WAS DONE STARTING AT <DSK-ADRES>
2292								;INDICATED IN EROR MSGE.
2293	007530	004737	021134		3\$:	JSR	PC,CHKHE1	;CHECK IF 'ERR' OR 'HE' BIT IS SET.
2294								;IF YES RETURN HERE.
2295	007534	104032				ERROR	32	; 'HE' OR 'ERR' BIT SET WHILE DOING
2296								;WRITE FORMAT ON CYLINDER 0,
2297								;SECTOR IN ERROR IS AS SHOWN IN
2298								;DISK-ADRES BITS 0-3
2299								;WRT FMT WAS DONE STARTING AT <DSK-ADRES>
2300								;INDICATED IN EROR MSGE.
2301								
2302	007536	004737	021176		4\$:	JSR	PC,CHKDA1	;CHECK IF RKDA INCREMENTED CORRECTLY?
2303								
2304	007542	104033				ERROR	33	;RKDA DID NOT INCREMENT CORRECT
2305								;AFTER 1 WORD 'WRITE FORMAT' ON
2306								;CYLINDER 0, SECTOR IN ERROR IS 1

J05

```

2307                                     ;LESS THAN THAT SHOWN IN EXPCTD RKDA
2308 007544 005777 171572 55: TST  DRKDB ;CHECK THAT RKDB DOES CONTAIN A 0
2309                                     ;AFTER WRT BECAUSE LAST WORD WRITTEN
2310                                     ;WAS SERIALLY SHIFTED OUT TO THE DISK
2311 007550 001406          BEQ  65      ;YES, BRANCH
2312 007552 005037 001162  CLR  $REG0 ;THIS IS WHAT RKDB SHOULD CONTAIN
2313 007556 017737 171560 001164  MOV  DRKDB,$REG1 ;GET RKDB
2314 007564 104037          ERROR 37    ;RKDB SHOULD BE 0 AFTER WRT SINCE THE
2315                                     ;LAST WORD WRITTEN WAS SERIALLY SHIFTED
2316                                     ;OUT OF RKDB
2317 007566 005201 65: INC  R1      ;INCREMENT DRIVE ADDR TO NXT SECTOR
2318 007570 005205          INC  R5
2319 007572 122705 000014  CMPB #14,R5 ;R U GOING TO CHECK THE LAST SECTOR?
2320 007576 001092          BNE  .+6   ;IF NOT, BRANCH
2321 007600 062705 000004  ADD  #4,R5 ;IF YES, INCREMENT R5 CORRECTLY TO 'EXPCTD RKDA'
2322                                     ;AFTER HAVING CHECKED THE LAST SECTOR
2323 007604 005202          INC  R2      ;HAVE U FORMATTED ALL 12 SECTORS?
2324 007606 001317          BNE  15    ;IF NOT, BRANCH BACK & LOOP
2325                                     ;IF YES, EXIT
2326
2327
2328
2329
2330
2331
2332
2333
2334
2335
2336
2337
2338
2339
2340
2341
2342
2343
2344
2345
2346 007610 000004
2347 007612 005005
2348 007614 104413
2349
2350
2351
2352
2353
2354
2355
2356
2357
2358 007616 104421          TST.SIN
2359
2360 007620 013701 001332  MOV  RKCS,R1
2361 007624 012700 177764  MOV  #-14,R0 ;SET UP COUNT FOR 12 SECTORS
2362 007630 013702 001340  MOV  RKDA,R2
  
```

```

*****
*TEST 21 CHECK 'READ FORMAT'-CYLINDER 0, SECTOR 0-13
*THIS TEST PERFORMS A RD FMT ON THE 12 SECTORS OF CYLINDER 0
*THE FOLLOWING IS CHECKED
*1) IF CNTRL RDY SET WITHIN A CERTAIN TIME ON COMPLETION
*OF THE FUNCTION
*2) IF 'HE' OR 'ERR' BIT SET?
*3) IF THE RKDA INCREMENTS CORRECTLY?
*4) RKBA INCREMENTED CORRECTLY BY 30 (OCTAL)
*5) RKWC OVERFLOWED TO 0 FROM -14 (OCTAL)
*6) CORRECT HEADER WAS RECEIVED FROM ALL 12 SECTORS.
*7) RKCS STILL CONTAINS THE 'RD FMT' FUNCTION BITS.
*IF THERE IS A READ ERROR IN THIS TEST OR ANY
*OTHER TESTS THE USER SHOULD MAKE SURE THAT
*IT IS AN IRRECOVERABLE ERROR AND NOT A TRANSIENT
*ONE. THIS CAN BE DONE BY LOOPING ON THE TEST
*IN QUESTION. USUALLY A TRANSIENT ERROR
*DISAPPEARS ON RETRIES, WHEREAS A LOGIC ERROR DOES NOT.
*****
  
```

```

*****
†ST21: SCOPE
      CLR  R5
      CNT.RESET
      ;GO, DO CONTROL RESET
      ;THIS IS A CALL FOR THE 'CNTRL-
      ;RESET' ROUTINE. A CONTROL RESET IS
      ;ISSUED AND AFTER A CERTAIN TIME
      ;IF THE 'CNTRL RDY' DOES NOT SET
      ;AN ERROR IS REPORTED. NOTE THAT
      ;THE PC IN ERROR MESSAGE IS THE
      ;PC WHERE 'CNT.RESET' IS LOCATED.
      ;THIS IS A VERY BASIC ERR & IF IT
      ;OCCURS GO BACK TO TEST 10
      ;GO CHECK IF SIN IS SET
      ;IS .SET, DO DRIVE RESET TO CLR IT
  
```

K05

2363	007634	013712	001350			MOV	DRIVAD, R2	: ADDRESS THE DRIVE
2364	007640	012704	033240			MOV	#OUTBUF, R4	
2365	007644	010477	171466			MOV	R4, RKBAB	: ADRS TO WHICH X-FER DATA FROM DSK
2366	007650	012777	177764	171456		MOV	#-14, RKWCC	: SET UP WORD COUNT FOR 12 HEADERS TO BREAD
2367	007656	012777	002005	171446		MOV	#2005, RKCSC	: READ FORMAT, GO
2368								
2369	007664	105777	171442		1S:	TSTB	RKCSC	: DID CNTRL RDY SET ON COMPLETION?
2370	007670	100411				BMI	2S	: YES, BRANCH
2371	007672	005205				INC	R5	: NO, WAIT FOR IT TO SET
2372	007674	001373				BNE	1S	: IF WAITED LONG ENOUGH REPORT
2373								: ERROR, OTHERWISE LOOP BACK & WAIT
2374	007676	004737	020702			JSR	PC, GT4RG	: GO, GET RKCS, ER, DS, DA
2375	007702	013737	001350	001202		MOV	DRIVAD, \$REG10	
2376	007710	104416				BRKDA4		: GO TO 'BD4' & BREAK CONTENTS OF
2377								: \$REG10 INTO DR#, CYL, SUR, SEC BITS
2378	007712	104045				ERROR	45	: CNTRL RDY DID NOT SET ON COMPLETION
2379								: OF READ FORMAT-OF CYLINDER 0,
2380								: SECTORS 0-13
2381								: READ FMT WAS DONE STARTING AT <DSK-ADRES>
2382								: INDICATED IN EROR MESGE
2383	007714	004737	021142		2S:	JSR	PC, CHKHE	: CHECK IF 'ERR' OR 'HE' BIT IS SET,
2384								: IF YES RETURN HERE.
2385	007720	104046				ERROR	46	: 'ERR' OR 'HE' BIT SET ON DOING
2386								: READ FMT-OF CYLINDER 0, SEC 0-13
2387								: READ FMT WAS DONE STARTING AT <DSK-ADRES>
2388								: INDICATED IN EROR MESGE
2389	007722	013705	001350		3S:	MOV	DRIVAD, R5	
2390	007726	062705	000020			ADD	#20, R5	: RKDA SHOULD HAVE INCREMENTD TO (R2)
2391								
2392	007732	004737	021176			JSR	PC, CHKDA1	: CHECK IF RKDA INCREMENTED CORRECTLY,
2393								: IF NOT, RETURN HERE.
2394	007736	104040				ERROR	40	: RKDA DID NOT INCREMENT BY 12
2395								: AFTER A 'RD FMT' OF 12 HEADERS OF
2396								: CYLINDER 0, SECTORS 0-13
2397								: RKBA SHOULD INCREMENT BY 24 BYTES
2398								: AT THE END OF X-FER
2399	007740	022777	033270	171370	4S:	CMP	#OUTBUF+30, RKBAB	: DID RKBA INCREMENT CORRECTLY?
2400	007746	001407				BEQ	5S	: YES, BRANCH
2401	007750	012737	033270	001162		MOV	#OUTBUF+30, \$REG0	: GET EXPCTD RKBA
2402	007756	017737	171354	001164		MOV	RKBAB, \$REG1	: GET ACTUAL RKBA
2403	007764	104042				ERROR	42	: RKBA DID NOT INCREMENT CORRECTLY
2404								: AFTER READ FORMAT OF 12 HEADERS
2405	007766	004737	021224		5S:	JSR	PC, CHKWC	: GO CHECK IF RKWC OVERFLOWED TO 0
2406								: IF NOT RETURN HERE.
2407	007772	104041				ERROR	41	: RKWC DID NOT OVERFLOW TO 0
2408								: AFTER 'RD FMT' OF 12 HEADERS
2409								: OF CYLINDER 0
2410	007774	005724			6S:	TST	(R4)+	: WAS THE CORRECT HEADER RECIEVED?
2411	007776	001413				BEQ	7S	: YES, BRANCH
2412	010000	010037	001162			MOV	R0, \$REG0	: GET SECTOR FOR WHICH THE HEADER
2413	010004	062737	000014	001162		ADD	#14, \$REG0	: COULD NOT BE READ CORRECT
2414	010012	005037	001164			CLR	\$REG1	: EXPCTD HEADER-0, FOR CYL 0
2415	010016	014437	001166			MOV	-(R4), \$REG2	: GET WRONG HEADER RECVD
2416	010022	104043				ERROR	43	: HEADER WAS NOT READ RIGHT FOR
2417								: SECTOR (AS IN ER MSGE), & CYL 0
2418	010024	005724				TST	(R4)+	: WAS THE CORRECT HEADER RECVD?

L05

MAINDEC-11-DZRKK-D MACY11 27(1006) 04-OCT-76 16:06 PAGE 46
DZRKKD.P11 22-SEP-76 08:47

T21 CHECK 'READ FORMAT'-CYLINDER 0, SECTOR 0-13

SEQ 0063

```

2419 010026 005200 75: INC R0 ;YES, HAVE U CHECKED FOR ALL 12 SECTORS?
2420 010030 001361 BNE 65 ;IF NOT, LOOP BACK & CHK HDR FPM NXT SECTR
2421
2422 010032 004737 021250 JSR PC,CHKER ;CHECK IF ANY BIT IN RKER IS SET,
2423 ;IF YES, RETURN HERE.
2424 010036 104036 ERROR 36 ;RKER BIT SET ON DOING RD FMT
2425 ;OF CYL 0, SECTORS 0-13
2426 010040 022711 002204 85: CMP #2204,R1 ;DOES RKCS STILL CONTAIN FUNCTION BITS?
2427 010044 001406 BEQ TST22 ;YES, EXIT
2428 010046 012737 002204 001162 MOV #2204,$REG0 ;GET EXPCTD RKCS
2429 010054 011137 001164 MOV R1,$REG1 ;GET ACTUAL RKCS
2430 010060 104024 ERROR 24 ;RKCS DID NOT CONTAIN 'RD FMT'
;FUNCTION BITS ON COMPETION OF
;THE FUNCTION

```

```

*****
;TEST 22 CHECK 'READ',CYLINDER 0, SECTORS 0 TO 13
;THIS TEST PERFORMS A READ OF ALL THE SECTORS OF CYLINDER 0
; & CHECKS THE FOLLOWING
; *1) CNTRL RDY SETS WITHIN A CERTAIN TIME ON COMPLETION
; *OF THE FUNCTION
; *2) IF 'HE' OR 'ERR' BIT SET?
; *3) IF THE CORRECT PSUEDO-HEADER (FIRST WORD OF EVERY)
; *SECTOR, WRITTEN IN A PREVIOUS TEST) WAS RECEIVED.
; *4) IF RKDS CONTAINS THE CORRECT WORD.
; *4) IF RKDA INCREMENTED CORRECTLY.
; *5) IF REST OF THE (377) WORDS IN EACH SECTOR ARE '0' , NOTE
; *PREVIOUSLY ONE WORD WAS WRITTEN PER SECTOR.
; *6) IF RKCS STILL CONTAINS THE 'READ' FUNCTION BITS
; *7) IF CONTROL RESET CLEARS RKDB.
; * IF TESTING IS BEING DONE ON A SIMULATOR ONLY LAST SECTOR(13)
; *IS READ BECAUSE THE SIMULATOR CAN STORE ONLY 1 SECTOR (256 WORDS).
; *HENCE ONLY THE DATA WRITTEN LAST CAN BE READ BACK.
*****

```

```

2454
2455 010062 000004 TST22: SCOPE
2456 010064 012737 010136 001110 MOV #15,$LPERR ;SET RETURN ADRES FOR LUPING
2457 ;ON ERROR (SW 9)
2458 010072 013703 001332 MOV RKCS,R3
2459 010076 013701 001350 MOV DRIVAD,R1
2460 010102 010105 MOV R1,R5
2461 010104 012704 033240 MOV #OUTBUF,R4
2462 010110 005737 001344 TST SIMUL ;TESTING ON SIMULATOR?
2463 010114 001405 BEQ 95 ;NO, BRANCH
2464 ;IF TESTING ON SIMULATOR READ
2465 ;SECTOR 13 ONLY
2466 010116 052701 000013 BIS #13,R1 ;SET BITS FOR SEC 13
2467 010122 052705 000020 BIS #20,R5 ;RKDA SHOULD INCRMNT TO THIS AFTER READ
2468 010126 000403 BR 15
2469 010130 012702 177764 95: MOV #-14,R2 ;SET COUNT FOR 12 SECTORS
2470 010134 005205 INC R5 ;RKDA SHOULD INCREMENT TO
;THIS AFTER 1 SECTOR READ
2471
2472 010136 104413 15: CNT.RESET ;GO, DO CONTROL RESET
2473 ;THIS IS A CALL FOR THE 'CNTRL-
2474 ;RESET' ROUTINE. A CONTROL RESET IS

```


M05

MAINDEC-11-DZRKK-D
DZRKKD.P11

MACY11 27(1006)
22-SEP-76 08:47

04-OCT-76 16:06 PAGE 47
T22 CHECK 'READ', CYLINDER 0, SECTORS 0 TO 13

SEQ 0064

```

2475 ; ISSUED AND AFTER A CERTAIN TIME
2476 ; IF THE 'CNTRL RDY' DOES NOT SET
2477 ; AN ERROR IS REPORTED. NOTE THAT
2478 ; THE PC IN ERROR MESSAGE IS THE
2479 ; PC WHERE 'CNT.RESET' IS LOCATED.
2480 ; THIS IS A VERY BASIC ERR & IF IT
2481 ; OCCURS GO BACK TO TEST 10
2482 010140 104421          TST.SIN          ; GO CHECK IF SIN IS SET
2483 ; IF SET, DO DRIVE RESET TO CLR IT
2484 010142 010177 171172    MOV R1,ARKDA  ; ADDRESS THE DRIVE
2485 010146 010477 171164    MOV R4,ARKBA  ; ADRS TO WHICH X-FER DATA FROM DISK
2486 010152 012777 177400    MOV #-400,ARKWC ; SETUP WORD COUNT
2487 010160 012713 000005    MOV #5,AR3   ; READ,GO
2488 ;
2489 010164 005000          CLR R0
2490 010166 105713    25:  TSTB AR3      ; DID CNTRL RDY SET ON COMPETION?
2491 010170 100410          BMI 3$       ; YES, BRANCH
2492 010172 005200          INC R0
2493 010174 001374          BNE 2$
2494 ;
2495 010176 004737 020702    JSR PC,GT4RG ; NO, WAIT FOR IT TO SET
2496 010202 010137 001202    MOV R1,$REG10 ; IF WAITED LONG ENOUGH, REPORT
2497 010206 104416          BRKDA4      ; ERROR, OTHERWISE LOOP BAK & WAIT
2498 ;
2499 010210 104045          ERROR 45     ; GO GET RKCS, ER, DS, DA
2500 ;
2501 ;
2502 ;
2503 ;
2504 010212 004737 021134    3$: JSR PC,CHKHE1 ; GET SECTOR ADDRESS WHERE ERROR OCCURED
2505 ;
2506 010216 104046          ERROR 46     ; GO TO 'BDAY' & BREAK CONTENTS OF
2507 ;
2508 ;
2509 ;
2510 ;
2511 010220 020114          4$: CMP R1,(R4) ; $REG10 INTO DR # CYL,SUR,SEC BITS
2512 ;
2513 ;
2514 ;
2515 010222 001407          BEQ 5$
2516 010224 010137 001162    MOV R1,$REG0 ; CNTRL RDY DID NOT SET ON COMPLETION
2517 010230 011437 001164    MOV (R4),$REG1 ; OF READ OF CYLINDER 0, SECTOR
2518 010234 010137 001166    MOV R1,$REG2 ; AS SHOWN IN <DSK-ADRES>
2519 010240 104044          ERROR 44     ; READ WAS DONE STARTING AT <DSK-ADRES>
2520 ;
2521 ;
2522 010242 004737 021176    5$: JSR PC,CHKDA1 ; INDICATED IN EROR MESGE
2523 ;
2524 010246 104040          ERROR 40     ; WAS THE DATA WORD RECVD, CORRECT?
2525 ;
2526 ;
2527 ;
2528 ;
2529 ;
2530 ;

```

```

; THE FIRST DATA WORD OF EACH SECTOR
; IS AN ADRS WORD COMPRISING OF DRIVE NO,
; CYLINDER ADRS, SUR, SECTOR ADRS
; GET EXPCTD DATA WORD FROM DISK
; GET THE DATA WORD RECVD
; GET DISK ADRS
; DID NOT RECIEVE CORRECT DATA WORD ON
; READ, OF CYLINDER 0, SECTOR AS SHOWN IN 'DSK
; ADRS' OF EXPCTD DATA WORD
; CHECK IF RKDA INCREMENTED CORRECTLY.
; IF NOT RETURN HERE.
; RKDA DID NOT INCREMENT CORRECTLY
; AFTER READ OF 1 WORD, FROM CYL 0
; SEC IN ERROR IS 1 LESS THAN THAT
; SHOWN IN EXPCTD RKDA
; AS A RESULT OF 'WRT FMT' IN A PREVIOUS TEST
; FIRST WORD OF EVERY SECTOR IS NON-

```

N05

MAINDEC-11-DZRKK-D
DZRKKD.P11 22-SEP-76

MACY11 27(1006)
08:47

04-OCT-76 16:06 PAGE 48
T22 CHECK 'READ', CYLINDER 0, SECTORS 0 TO 13

SEG 0065

2531							;ZERO (PSUEDO-HDR), REST 377 WORDS
2532							;ARE ALL 0'S.
2533							;CHECK IF THE REST OF THE 377
2534							;WORDS ARE ALL 0'S
2535	010250	012737	177775	001370		MOV #3,EFLG1	;ALLOW ONLY 3 ERRORS
2536	010256	012700	033242			MOV #OUTBUF+2,R0	;INITIALIZE PTR TO 2ND WRD IN BJFR
2537	010262	012737	177401	001362		MOV #-377,COUNT	;CHECK 377 WORDS IN THE BUFFER
2538	010270	005710			11\$:	TST @R0	;IS THIS WRD 0?
2539	010272	001005				BNE 12\$;NO, ERROR
2540	010274	005720				TST (R0)+	;INCRMNT PTR TO NXT WRD
2541	010276	005237	001362			INC COUNT	;CHKD ALL 377 WRDS?
2542	010302	001372				BNE 11\$	
2543	010304	000412				BR 7\$;YES, BRANCH
2544	010306	005037	001162		12\$:	CLR \$REG0	;GET EXPCTD WORD
2545	010312	012037	001164			MOV (R0)+,\$REG1	;GET WORD RECVD
2546	010316	010137	001166			MOV R1,\$REG2	;GET DISK ADRES, ERROR IN THIS
2547							;SECTOR
2548	010322	104044				ERROR 44	;DATA ERROR, THE LAST 377 WORDS
2549							;READ FROM EACH SECTOR SHOULD BE 0
2550							;IN A PREVIOUS TEST, FIRST WORD OF
2551							;EVERY SEC (CYL 0) WAS WRITTEN AS A
2552							;PSUEDO-HDR, REST OF THE WORDS IN THE
2553							;SECTR ARE AUTOMATICALLY WRITTEN AS
2554							;0'S. THIS ERROR MAY MEAN THAT IT
2555							;DIDN'T HAPPEN SO
2556	010324	005237	001370			INC EFLG1	;ALLOW ONLY 3 DATA ERORS OF THIS KIND
2557	010330	001357				BNE 11\$	
2558							
2559							
2560	010332	005737	001344		7\$:	TST SIMUL	;TESTING ON SIMULATOR?
2561	010336	001011				BNE 10\$;YES BRANCH
2562							;IF NOT TESTING ON SIMULATOR GO AHEAD
2563							; & READ ALL 12 SECTORS ON CYL 0
2564	010340	005201				INC R1	;INCREMENT DRIV-ADRES TO NXT SECTOR
2565	010342	005205				INC R5	;INCREMENT 'EXPCTD DRIV-ADRES'
2566	010344	122705	000014			CMPB #14,R5	;R U GOING TO READ THE LAST SECTOR?
2567	010350	001002				BNE .+6	;IF NOT, BRANCH
2568	010352	062705	000004			ADD #4,R5	;IF YES, INCREMENT 'EXPCTD RKDA'
2569							;CORRECTLY
2570	010356	005202				INC R2	;HAVE U READ ALL 12 SECTORS?
2571	010360	001266				BNE 1\$;IF NOT LOOP BACK & READ THE
2572							;NXT SECTOR
2573	010362	022713	000204		10\$:	CMP #204,@R3	;DOES RKCS, STILL HAVE THE 'READ' FUNCTION
2574	010366	001406				BEQ 8\$;YES, BRANCH
2575	010370	012737	000204	001162		MOV #204,\$REG0	;GET EXPCTD RKCS
2576	010376	011337	001164			MOV @R3,\$REG1	;GET RKCS RECVD
2577	010402	104024				ERROR 24	;RKCS SHOULD STILL CONTAIN THE 'READ'
2578							;FUNCTION BITS
2579	010404	104413			8\$:	CNT.RESET	;GO DO CONTROL RESET
2580							;THIS IS A CALL FOR THE 'CNTRL-
2581							;RESET' ROUTINE. A CONTROL RESET IS
2582							;ISSUED AND AFTER A CERTAIN TIME
2583							;IF THE 'CNTRL RDY' DOES NOT SET
2584							;AN ERROR IS REPORTED. NOTE THAT
2585							;THE PC IN ERROR MESSAGE IS THE
2586							;PC WHERE 'CNT.RESET' IS LOCATED.

26087
26088
26089
26090
26091
26092
26093
26094
26095
26096
26097
26098
26099
26100
26101
26102
26103
26104
26105
26106
26107
26108
26109
26110
26111
26112
26113
26114
26115
26116
26117
26118
26119
26120
26121
26122
26123
26124
26125
26126
26127
26128
26129
26130
26131
26132
26133
26134
26135
26136
26137
26138
26139
26140
26141
26142

010406 005777 170730
010412 001407
010414 013737 001342 001162
010422 017737 170714 001164
010430 104102

TST ZAKDB -
BEQ TST23
MOV RKDB, \$REG2
MOV ZRZDB, \$REG1
ERROR 102

: THIS IS A VERY BASIC ERR & IF IT
: OCCURS GO BACK TO TEST 10
: DID CNTRL RESET CLEAR RKDB?
: YES EXIT
: GET ADRES OF RKDB
: GET CONTENTS OF RKDB
: CONTROL RESET DID NOT
: CLEAR RKDB

: *TEST 23 CHECK 'WRITE FORMAT' OF THE DISK
: *THIS TEST WRITE FORMATS THE ENTIRE DISK. THE FIRST
: *WORD OF EVERY SECTOR IS WRITTEN TO BE A PSEUDO-HEADER
: *CONSISTING OF THE DRIVE #, CYLINDER #, SURFACE & SECTOR #.
: *1 SECTOR IS WRITTEN AT A TIME. THE WRITING IS DONE
: *IN THIS ORDER: CYL 0-SUR 0; CYL 0-SUR 1; CYL 1-SUR 0
: *CYL 1-SUR 1; CYL 2-SUR 0; CYL 2-SUR 1----- CYL 312-SUR 1.
: *IMPORTANCE OF THIS TEST SHOULD BE REALIZED, THIS IS
: *THE FIRST TIME EACH & EVERY SECTOR ON THE DISK IS
: *ACCESSED & WRITTEN ON. THIS IS THE FIRST TIME RKDA
: *IS BEING MADE TO INCREMENT OVER THE ENTIRE DISK (FROM
: *000000 TO 014520) IF A 'SIN' OCCURS AT ANY POINT
: *A DRIVE RESET IS DONE BEFORE DOING WRT FMT FOR THE NEXT
: *SECTOR. ANY OTHER ERROR IS CLEARED THROUGH A CONTROL RESET.
: *THE FOLLOWING CHECKING IS DONE AFTER WRITING EACH
: *CYLINDER.
: *1. CNTRL RDY SETS WITHIN A CERTAIN TIME ON COMPLETION
: *OF THE FUNCTION.
: *2. IF 'SIN' OCCURRED?
: *3. IF 'HE' OR 'ERR' BIT SET?
: *4. IF RKDA INCREMENTED CORRECTLY, INCLUDING BOUNDARY
: *CONDITIONS (SECTOR COUNTER BITS OVERFLOWING INTO SURFACE,
: *SURFACE BIT OVERFLOWING INTO CYLINDER BITS) AT THE END
: *OF THIS POINTERS ARE INCREMENTED ADJUSTED, ETC.
: *8 'WRT FMT' ON THE NEXT SECTOR IS DONE.

010432 000004
010434 012737 000001 001206
010442 012737 010472 001110
010450 005003
010452 012704 177465
010456 012702 177764
010462 013701 001350
010466 010105
010470 005205
010472 104413

TST23: SCOPE
MOV #1, \$TIMES
MOV #15, \$SLPERR
CLR R3
MOV #-313, R4
MOV #-14, R2
MOV DRIVAD, R1
MOV R1, R5
INC R5
15: CNT.RESET

: DO 1 ITERATION
: SET RETURN ADRES FOR LUPING
: ON ERROR (SW 9)
: (R3)=0, SURFACE 0 BEING WRITTEN
: (R3)-1, SURFACE 1 BEING WRITTEN
: SET UP COUNT FOR 203 CYLINDERS
: SET UP COUNT FOR 12 SECTORS
: GET DRIVE ADRES
: STORE IT
: GO, DO CONTROL RESET
: THIS IS A CALL FOR THE 'CNTRL-
: RESET' ROUTINE. A CONTROL RESET IS
: ISSUED AND AFTER A CERTAIN TIME
: IF THE 'CNTRL RDY' DOES NOT SET
: AN ERROR IS REPORTED. NOTE THAT
: THE PC IN ERROR MESSAGE IS THE
: PC WHERE 'CNT.RESET' IS LOCATED.

2643									: THIS IS A VERY BASIC EPR & IF IT
2644									: OCCURS GO BACK TO TEST 10
2645									: GO CHECK IF SIN IS SET
2646									: IF SET, DO DRIVE RESET TO CLR IT
2647	010474	104421							
2648	010476	005037	001362		78:	CLR	COUNT		
2649	010502	010137	033240			MOV	R1,OUTBUF		: THIS WORD TO BE WRITTEN. THE FIRST
2650									: WORD OF EACH SECTOR WILL BE THE ACTUAL
2651									: DISK-ADRES, CONSISTING OF THE DRIVE NO,
2652									: CYL ADRES, SURFACE BIT SECTOR ADRES
2653	010506	012777	033240	170622		MOV	#OUTBUF, @RKBA		: ADRES FROM WHICH WORD IS TO B X-FERREC
2654	010514	012777	177777	170612		MOV	#-1, @RKWC		: SET UP WORD COUNT
2655	010522	010177	170612			MOV	R1, @RKDA		: ADRES THE DRIVE, WITH CORRECT CYL
2656									: & SECTOR ADRES
2657	010526	012777	002003	170576		MOV	#2003, @RKCS		: WRITE FORMAT, GO
2658	010534	105777	170572		28:	TSTB	@RKCS		: DID CNTRL RDY SET
2659	010540	100411				BMI	35		: YES, BRANCH
2660	010542	005237	001362			INC	COUNT		: NO, HAVE U WAITED LONG ENOUGH?
2661	010546	001372				BNE	25		: IF NOT, LOOP BACK & WAIT
2662									: IF YES, REPORT ERROR
2663	010550	004737	020702			JSR	PC,GT4RG		: GO GET RKCS, ER, DS, DA
2664	010554	010137	001202			MOV	R1, @REG10		: GET DISK ADRES, WHERE ERROR OCCURED
2665	010560	104416				BRKDA4			: GO TO 'BD4' & BREAK CONTENTS OF
2666									: @REG10 INTO DR # CYL SUR. SEC BITS
2667	010562	104031				ERROR	31		: CNTRL RDY DID NOT SET ON COMPLETION
2668									: OF 'WRITE FORMAT', ON SECTOR AS
2669									: SHOWN IN (DSK-ADRES)
2670									: WRT FMT WAS DONE STARTING AT (DSK-ADRES
2671									: INDICATED IN EROR MSGE.
2672	010564	032777	001000	170534	38:	BIT	#1000, @RKDS		: DID SIN BIT SET?
2673	010572	001405				BEQ	45		: NO, BRANCH
2674	010574	004737	020710			JSR	PC,GT3RG		: GO GET RKCS, ER, DS
2675	010600	010137	001170			MOV	R1, @REG3		: GET, DISK-ADRES WHERE ERROR OCCURED
2676	010604	104001				ERROR	1		: SIN SET WHILE DOING WRT FMT
2677									: TO DISK-ADRES (AS IN @REG3)
2678									
2679	010606	004737	021134		48:	JSR	PC,CHKHE1		: CHECK IF 'ERR' OR 'HE' BIT IS SET
2680									: IF YES, RETURN HERE.
2681	010612	104032				ERROR	32		: HE OR ERR SET WHILE DOING WRITE
2682									: FORMAT ON SECTOR AS INDICATED IN
2683									: (DSK-ADRES)
2684									: WRT FMT WAS DONE STARTING AT (DSK-ADRES)
2685									: INDICATED IN EROR MSGE.
2686	010614	004737	021176		58:	JSR	PC,CHKDA1		: CHECK IF RKDA INCREMENTED CORRECTLY.
2687									: IF NOT, RETURN HERE.
2688	010620	104033				ERROR	33		: RKDA DID NOT INCREMENT CORRECTLY
2689									: AFTER 'WRITE FORMAT' WAS DONE
2690									: TO THE SECTOR PRE.IOUS TO THAT
2691									: INDICATED IN 'EXPTD' RKDA
2692	010622	005201			68:	INC	R1		: INCREMENT TO THE NXT SECTOR
2693	010624	005205				INC	R5		: INCREMENT R5, TO WHAT RKDA WILL INCREMENT
2694	010626	022702	177776			CMP	#-2,R2		: R U GOING TO FORMAT THE LAST SECTOR
2695									: IN THE CYLINDER ?
2696	010632	001002				BNE	+6		: IF NOT, BRANCH
2697	010634	062705	000004			ADD	#4,R5		: INCREMENT R5 CORRECTLY TO 'EXPTD RKDA'
2698	010640	005202				INC	R2		: HAVE U FORMATTED ALL 12 SECTORS

```

2699
2700 010642 001313 BNE 15 ;ON THIS CYLINDER
2701 ;IF NOT, LOOP BACK & FORMAT THE
2702 ;NEXT SECTOR
2703 010644 012702 177764 MOV #14,R2 ;RESET THE COUNT FOR 12 SECTORS
2704 010650 042701 000037 BIC #37,R1 ;CLEAR THE SEC ADRES BITS
2705 010654 005703 *SY R3 ;SURFACE 1?
2706 010656 001006 BNE B5 ;YES, BRANCH
2707 010660 005203 INC R3 ;NO, SET FLAG
2708 010662 062701 000020 ADD #20,R1 ;INCREMENT TO THE NXT SURFACE
2709 010666 010105 MOV R1,R5 ;THIS IS WHAT RKDA SHOULD
2710 010670 005205 INC R5 ;INCREMENT TO.
2711 010672 000677 BR 15 ;GO, DO NXT SURFACE
2712 010674 062701 000040 B5: ADD #40,R1 ;INCREMENT TO NXT CYL
2713 010700 010105 MOV R1,R5 ;POSITION FOR
2714 010702 005205 INC R5 ;EXPCD RKDA
2715 010704 005003 CLR R3
2716 010706 005204 INC R4 ;HAVE U FORMATTED ALL 203 CYLINDERS
2717 010710 001270 BNE 15 ;IF NOT, LOOP BACK & FORMAT THE
2718 ;NEXT CYLINDER
2719
2720
2721
2722
2723
2724
2725
2726
2727
2728
2729
2730
2731
2732
2733
2734
2735
2736
2737
2738
2739
2740

```

```

*****
*TEST 24 CHECK 'READ FORMAT' FOR THE ENTIRE DISK
*THIS TEST READ FORMATS THE ENTIRE DISK, WHICH WAS WRT
*FORMATTED IN THE PREVIOUS TEST. THE FOLLOWING CHECKING
*IS DONE
*1. CNTRL RDY SETS WITHIN A CERTAIN TIME ON COMPLETION
*OF FUNCTION
*2. IF 'SIN' OCCURRED?
*3. IF 'HE' OR 'ERR' OCCURRED?
*4. RKDA INCREMENTED CORRECTLY.
*5. IF THE CORRECT HEADER WAS READ.
*6. IF RKWC OVERFLOWED CORRECTLY.
*12 SECTORS (1 CYLINDER) ARE READ AT A TIME. IF 'SIN'
*OCCURS A DRIVE RESET IS DONE BEFORE READING THE NEXT
*SECTOR. READING IS DONE IN THIS ORDER CYL 0-SUR 0;
*CYL 0-SUR 1; CYL 1-SUR 0; CYL 1-SUR 1; CYL 2-SUR 0;
*CYL 2-SUR 1;-----CYL 312-SUR 1. IF TESTING ON SIM'LATOR, ONLY
*THE LAST CYLINDER (312), LAST SECTOR (13), SURFACE 1 IS REAC.
*****

```

```

2741 010712 000004 *ST24: SCOPE
2742 010714 012737 000001 001206 MOV #1,STIMES ;DO 1 ITERATION
2743 010722 012737 011006 001110 MOV #1,$.SLPEFR ;SET RETURN ADRES FOR LUPING
2744 ;ON ERROR (SW 9)
2745 010730 005037 001356 CLR INDX1 ;INDX1=0, SURFACE 0 BEING READ
2746 ;INDX1=1, SURFACE 1 BEING READ
2747 010734 013701 001350 MOV DRIVAD,R1 ;GET DRIVE ADRES
2748 010740 010102 MOV R1,R2
2749 010742 005737 001344 TST SIMUL ;TESTING ON SIMULATOR?
2750 010746 001410 BEO 125 ;NO, BRANCH
2751 010750 052701 014533 BIS #14533,R1 ;SET BITS FOR CYL 312, SEC 13, SUR 1
2752 ;ON SIMULATOR, CHECK ONLY CYL 312.
2753 ;SECTOR 13, SURFACE 1
2754 010754 052702 014540 BIS #14540,R2 ;RKDA SHOULD INCRMNT TO THIS AFTR

```


MAINDEC-11-DZRKK-D
DZRKKD.P11 22-SEP-76MACY11 27(1006)
08:4704-OCT-76 16:06 PAGE 53
T24

CHECK 'READ FORMAT' FOR THE ENTIRE DISK

SEG 0070

```

2811 011116 104001          ERROR 1       ;SIN ERROR ON DOING RD FMT
2812                          ;TO CYL INDICATED IN $REG3
2813
2814 011120 004737 021134    48:   JSR      PC,CHK4E1 ;CHECK IF 'ERR' OR 'HE' BIT IS SET,
2815                          ;IF YES, RETURN HERE.
2816 011124 104046          ERROR 46       ;HE OR ERR WHILE DOING A READ
2817                          ;FORMAT. 'RKDA' IN EROR MSGE GIVES
2818                          ;THE CONTENTS OF RKDA AT THE TIME OF ERROR
2819                          ;READ FMT WAS DONE STARTING AT 'DSK-ADRES'
2820                          ;INDICATED IN EROR MESGE
2821 011126 020277 170206    55:   CMP      R2,2RKDA  ;DID RKDA INCREMENT CORRECTLY BY 12 SEC
2822 011132 001410          BEQ      65
2823 011134 010237 001202    MOV      R2,$REG10
2824 011140 104415          BRKDA0
2825                          ;GET EXPCTD RKDA
2826 011142 017737 170172 001202  MOV      2RKDA,$REG10
2827 011150 104416          BRKDA4
2828                          ;GO TO 'BD04' & BREAK CONTENTS OF
2829                          ;$REG10 INTO DR #,CYL,SUR,SEC BITS
2830 011152 104040          ERROR 40       ;RKDA DID NOT INCREMENT BY 12 SECTOPS
2831                          ;AFTER RD FMT WAS DONE. ADRES
2832                          ;OF CYLINDER IN ERROR CAN BE OBTAINED
2833                          ;FROM 'EXPCTD' RDDA
2834 011154 013700 001370    65:   MOV      EFLG1,R0 ;SET UP COUNT FOR 12 HEADERS TO B CHKD
2835                          ;(ONLY 1, IF SIMULATOR)
2836 011160 010104          MOV      R1,R4
2837 011162 042704 160037    BIC      #160037,R4 ;GET DRIV-ADRES FROM WHERE RDFMT WAS DONE
2838 011166 020413          75:   CMP      R4,(R3)  ;GET THE CYLINDER ADRES ONLY. (HEADER)
2839 011170 001412          BEQ      85
2840 011172 010437 001164    MOV      R4,$REG1 ;GET EXPCTD HEADER WORD
2841 011176 011337 001166    MOV      (R3),$REG2 ;GET HEADER WORD RECVD
2842 011202 010037 001162    MOV      R0,$REG0
2843 011206 062737 000014 001162  ADD      #14,$REG0
2844                          ;GET THE SECTOR (OCTAL NO) WHICH DID
2845                          ;NOT GIVE THE CORRECT HEADER
2846 011214 104043          ERROR 43       ;DID NOT RECIEVE THE CORRECT HEADER
2847                          ;WORD FROM 'SECTOR' AS INDICATED
2848                          ;(NOTE SECTOR # IS OCTAL)
2849 011216 005723          85:   TST      (R3)+
2850                          ;INCREMENT POINTER TO THE NXT WORD
2851                          ;IN MEMORY WHERE THE RECVD HDR IS STORED
2852 011220 005200          INC      R0
2853 011222 001361          BNE      75
2854                          ;HAVE U CHECKED ALL 12 HEADERS?
2855                          ;IF NOT, LOOP BACK & CHK THE NXT.
2856                          ;YES, ALL HEADERS FOR THIS CYLINDER
2857                          ;CHECKED.
2858 011224 004737 021224    JSR      PC,CHKWC ;CHECK IF RKWC OVERFLOWED TO 0. IF
2859                          ;NOT RETURN HERE.
2860 011230 104041          ERROR 41       ;RKWC DID NOT OVERFLOW AFTER DOING
2861                          ;RDFMT OF 12 SECTORS ON THE CYLINDER
2862                          ;NOTE THAT 'RKDA' IS THE INCREMENTED
2863                          ;RKDA AFTER THE RDFMT
2864 011232 005737 001344    95:   TST      SIMUL
2865 011236 001031          BNE      TST25
2866                          ;TSTING ON SIMULATOR?
2867                          ;IF YES, EXIT
2868                          ;NO
2869 011240 005737 001356    TST      INDX1
2870 011244 001011          BNE      105
2871 011246 005237 001356    INC      INDX1
2872 011252 062701 000020    ADD      #20,R1
2873 011256 010102          MOV      R1,R2
                ;DOING SURFACE 1
                ;YES, BRANCH
                ;NO
                ;INCREMENT DRIV ADRES TO THE NXT SURFACE

```

G06

NOEC-11-DZRKC-D
DZRKC.P11 22-SEP-76

MACY11 27(1006)
08:47

04-OCT-76 16:06 PAGE 54
T24 CHECK 'READ FORMAT' FOR THE ENTIRE DISK

SEG 0071

2867	C11260	062702	000020		ADD	#20,R2	: THIS IS WHAT RKDA SHOULD INCREMENT
2868							: TO, AFTER READ FMT OF THE CYLINDER
2869	011264	000137	011006		JMP	1\$: GO RD FMT THE NXT SURFACE
2870	011270	005037	001356	10\$:	CLR	INDX1	
2871	011274	042701	000037		BIC	#37,R1	: CLR SEC, SURFACE BITS
2872	011300	062701	000040		ADD	#40,R1	: INCREMENT TO NXT CYL
2873	011304	010102			MOV	R1,R2	: THIS IS WHAT RKDA SHOULD BE
2874	011306	062702	00002C		ADD	#20,R2	: AFTER RD FMT OF CYLINDER
2875	011312	005205			INC	R5	: HAVE U DONE ALL CYLINDERS?
2876	011314	001402			BEQ	TST25	: EXIT
2877	C11316	000137	011006		JMP	1\$: IF NOT, LOOP BACK & READ FMT FROM
2878							: THE NXT CYLINDER

```

*****
: *TEST 25 CHECK 'READ' OF THE ENTIRE DISK
: *READ OF THE ENTIRE DISK (ONE WORD PER SECTOR) IS DONE
: *IN THIS TEST. IN A PREVIOUS TEST THE FIRST WORD OF
: *EVERY SECTOR WAS WRITTEN LIKE A PSUEDO-HEADER (DRIVE #,
: *CYLINDER #, SURFACE & SECTOR #). THESE PSUEDO HEADERS
: *WILL BE READ & CHECKED IN THIS TEST, PROVING THAT ANY
: *SECTOR CAN BE ACCESSED AND READ.
: *THE FOLLOWING CHECKING IS DONE
: *1. CNTRL RDY SETS WITHIN A CERTAIN TIME ON COMPLETION
: *OF FUNCTION.
: *2. IF 'SIN' OCCURRED?
: *3. IF 'HE' OR 'ERR' OCCURRED?
: *4. THE CORRECT FIRST WORD FROM EVERY SECTOR
: *WAS RECEIVED. THIS WORD REFLECTS THE ABSOLUTE
: *DISK ADDRESS (DRV #, CYL #, SUR, SEC#) OF THAT SECTOR.
: *5. IF RKDB CONTAINED THE CORRECT WORD.
: *IF 'SIN' OCCURS DRIVE RESET IS DONE BEFORE READING
: *THE NEXT SECTOR. READ IS DONE IN THIS ORDER SEC 0-11
: *CYL 0 SUR 0 -> SEC 0-11 CYL 0 SUR 1 -> SEC 0-11 CYL 1,....
: *IF TESTING ON SIMULATOR ONLY LAST CYLINDER (312), LAS
: *SECTOR (13), SURFACE 1 IS READ.
*****

```

2903					TST25:	SCOPE	
2904	011322	000004			MOV	#1,\$TIMES	: DO 1 ITERATION
2905	011324	012737	000001	001206	MOV	#1\$,\$LPERR	: SET RETURN ADRES FOR
2906	011332	012737	011376	001110			: LOOPING ON ERROR (SW9)
2907							
2908	011340	012703	033240		MOV	#OUTBUF,R3	
2909	011344	005004			CLR	R4	: FLAG, CLEAR WHEN READING SURFACE 0
2910							: SET WHEN READING SURFACE 1
2911	011346	013701	001350		MOV	DRIVAD,R1	: GET DRIVE ADDRESS
2912	011352	005737	001344		TST	SIMUL	: TSTING ON SIMULATOR?
2913	011356	001403			BEQ	10\$: IF NOT BRANCH
2914	011360	052701	014533		BIS	#14533,R1	: SET ADRES BITS FOR LAST CYL (312)
2915	011364	000404			BR	1\$: LAST SECTOR (13), SURFACE 1
2916	011366	012700	177764	10\$:	MOV	#-14,R0	: SET COUNT FOR 12 SECTORS
2917	011372	012705	177465		MOV	#-313,R5	: SET UP COUNT FOR 203 CYLINDERS
2918							
2919	011376	104413		1\$:	CNT.RESET		: GO, DO CONTROL RESET
2920							: THIS IS A CALL FOR THE 'CNTRL-
2921							: RESET' ROUTINE. A CONTROL RESET IS
2922							: ISSUED AND AFTER A CERTAIN TIME

H06

MAINDEC-11-DZRKK-C MACY11 27 1006. 04-OCT-76 16:06 PAGE 55
 DZRKKD.P11 22-SEP-76 08:47 T25 CHECK 'READ' OF THE ENTIRE DISK

SEQ 0072

2923									: IF THE 'CNTRL RDY' DOES NOT SET
2924									: AN ERROR IS REPORTED. NOTE THAT
2925									: THE PC IN ERROR MESSAGE IS THE
2926									: PC WHERE 'CNT.RESET' IS LOCATED.
2927									: THIS IS A VERY BASIC ERR & IF IT
2928									: OCCURS GO BACK TO TEST 10
2929	011400	104421				TST.SIN			: GO CHECK SIN. IF SET DO
2930									: DRIVE RESET TO CLR IT
2931	011402	005037	001356		95:	CLR	INDX1		
2932	011406	010377	167724			MOV	R3,ARKBA		: ADRES TO WHICH DATA IS TO B X-FERRED
2933									: FROM THE DISK
2934	011412	012777	177777	167714		MOV	#-1,ARKWC		: SET UP WORD COUNT
2935	011420	010177	167714			MOV	R1,ARKDA		: ADRES THE DRIVE WITH CORRECT
2936									: CYLINDER & SECTOR ADRES
2937	011424	012777	000005	167700		MOV	#5,ARKCS		: READ, GO
2938									
2939	011432	105777	167674		25:	TSTB	ARKCS		: DID CNTRL RDY SET?
2940	011436	100411				BMI	35		: YES, BRANCH
2941	011440	005237	001356			INC	INDX1		: NO, HAVE U WAITED LONG ENOUGH
2942	011444	001372				BNE	25		: IF NOT, LOOP BACK & WAIT FOR IT
2943									: IF YES, REPORT ERROR
2944	011446	004737	020702			JSR	PC,GT4RG		: GO, GET RKCS, ER, DS,DA
2945	011452	010137	001202			MOV	R1,\$REG10		: GET DISK-ADRES WHERE ERROR OCCURED
2946	011456	104416				BRKDA4			: GO TO 'BDAY' & BREAK CONTENTS OF
2947									: \$REG10 INTO DR #,CYL,SUR,SEC BITS
2948	011460	104045				ERROR	45		: CNTRL RDY DID NOT SET AFTER DOING
2949									: A 1 WORD READ FROM ADRES AS
2950									: INDICATED IN <DISK-ADRES>
2951									: 'RKDA' IN EROR MSGE GIVES THE
2952									: CONTENTS OF RKDA AT THE TIME OF ERROR
2953									
2954	011462	032777	001000	167636	35:	BIT	#1000,ARKDS		: DID 'SIN' SET?
2955	011470	001405				BEQ	45		: NO, BRANCH
2956	011472	004737	020710			JSR	PC,GT3RG		: GO, GET RKCS, ER, DS
2957	011476	010137	001170			MOV	R1,\$REG3		: GET DISK-ADRES WHERE SIN OCCURED3
2958	011502	104001				ERROR	1		: 'SIN' ERROR ON DOING READ FROM
2959									: DISK-ADRES INDICATED IN \$REG3
2960	011504	004737	021134		45:	JSR	PC,CHKHE1		: CHECK IF 'ERR' OR 'HE' BIT IS SET,
2961									: IF YES, RETURN HERE.
2962	011510	104046				ERROR	46		: 'HE' OR 'ERR' ON DOING A READ OF
2963									: 1 WORD FROM ADRES AS INDICATED
2964									: IN <DISK-ADRES>
2965									: 'RKDA' IN EROR MSGE GIVES THE
2966									: CONTENTS OF RKDA AT THE TIME OF EROR
2967	011512	020113			55:	CMP	R1,(R3)		: WAS THE CORRECT DATA WORD RECVD?
2968	011514	001407				BEQ	65		
2969	011516	010137	001162			MOV	R1,\$REG0		: GET EXPCTD DATA WORD
2970	011522	011337	001164			MOV	(R3),\$REG1		: GET DATA WORD RECVD
2971	011526	010137	001166			MOV	R1,\$REG2		: GET DISK-ADRES
2972	011532	104044				ERROR	44		: DID NOT RECIEVE THE CORRECT
2973									: DATA WORD FROM DISK ON DOING
2974									: 1 WORD READ FROM 'DISK-ADRES'
2975									: AS INDICATED BY 'EXPCTD' DATA WORD
2976									: NOTE THAT IN A PREVIOUS TEST THE
2977									: FIRST WORD OF EACH SECTOR IS UNIQUELY
2978									: WRITTEN WITH A WORD GIVING THE

```

2979 ;ABSOLUTE ADDRESS OF THAT SECTOR IN
2980 ;TERMS OF DRIV #, CYL ADRES, SUR, SEC ADRES.
2981 011534 020177 167602 65: CMP R1,ARKDB ;DOES RKDB CONTAIN CORRECT WORD
2982 011540 001406 BEQ 75 ;YES, BRANCH
2983 011542 010137 001162 MOV R1,$REG0 ;NO, GET EXPCD RKDB
2984 011546 017737 167570 001164 MOV ARKDB,$REG1 ;GET RKDB RECVD
2985 011554 104037 ERROR 37 ;RKDB ERROR ON READ.
2986 ;FOR RK11C, AFTER A READ RKDB
2987 ;CONTAINS CHECKSUM FOR THE SECTOR
2988 ;READ.
2989 ;WHEREAS FOR RK11D, AFTER READ
2990 ;RKDB CONTAINS THE LAST WORD
2991 ;READ FROM THAT SECTOR &
2992 ;X-FERRED TO MEMORY
2993 011556 005737 001344 75: TST SIMUL ;TESTING ON SIMULATOR?
2994 011562 001022 BNE TST26 ;IF YES, EXIT
2995 011564 005201 INC R1 ;INCREMENT TO ADRES NEXT SECTOR
2996 011566 005200 INC R0 ;HAVE U CHKD ALL 12 SECTORS?
2997 011570 001302 BNE 15 ;IF NOT, LUP BAK & CHK THE NXT
2998 ;IF YES...
2999 011572 012700 177764 MOV #-14,R0 ;RESET THE COUNT FOR 12 SECTORS
3000 011576 042701 000037 BIC #37,R1 ;CLEAR SECTOR, SURFACE BITS
3001 011602 005704 TST R4 ;DOING SURFACE 1?
3002 011604 001004 BNE 95 ;YES, BRANCH
3003 011606 005204 INC R4 ;NO
3004 011610 062701 000020 ADD #20,R1 ;INCREMENT THE ADRES TO NXT SURFACE
3005 011614 000670 BR 15 ;GO READ SURFACE 1
3006 011616 005004 95: CLR R4
3007 011620 062701 000040 ADD #40,R1 ;INCREMENT TO NXT CYL
3008 011624 005205 INC R5 ;HAVE U CHKD ALL 203 CYLINDERS
3009 011626 001263 BNE 15 ;IF NOT, LOOP BACK & CHK THE NXT CYLINDER
3010 ;YES

```

```

3011 ;*****
3012 ;*TEST 26 CHECK 'SEEK' FUNCTION, WITH DIFFERENT VELOCITY MODES
3013 ;* THIS TEST CHECKS SEEK IN DIFFERENT VELOCITY MODES (DIFF < 3,
3014 ;* 3 < DIFF < 31, DIFF > 31). FOR THESE 3 BASIC VELOCITIES SEEK IS DONE BOTH
3015 ;* IN FWD AND REV DIRECTION TO CHECK THE ADDER & DIFFERENCE LOGIC. IF
3016 ;* WHILE DOING A SEEK 'SIN' OCCURS, A DRIVE RESET IS DONE TO INITIALIZE
3017 ;* THE POSITIONING LOGIC
3018 ;*****

```

```

3019 ;*****
3020 ;*****
3021 011630 000004 15: SCOPE
3022 011632 012737 000005 001206 MOV #5,$TIMES ;DO 5 ITERATIONS
3023 011640 012703 001372 MOV #SEEK0,R3 ;INITIALIZE POINTER TO THE FIRST
3024 ;SEEK ADDRESS
3025 011644 005037 001356 CLR INDX1 ;INDX1, WHEN 0 INDICATES SEEK IN FWD DIRECTION
3026 ;WHEN 1 INDICATES SEEK IN REV DIRECTION
3027 011650 013700 001332 MOV RKCS,R0
3028 011654 013701 001326 MOV RKDS,R1
3029 011660 013702 001330 MOV RKER,R2
3030 011664 012737 011672 001110 MOV #15,$LPERR ;SET RETURN ADRES FOR LUPING ON
3031 ;EROR (SW 9)
3032 011672 000240 15: NOP
3033 011674 104413 25: CNT.RESET ;GO, DO CONTROL RESET
3034 ;THIS IS A CALL FOR THE 'CNTRL-

```

```

3035 ;RESET' ROUTINE. A CONTROL RESET IS
3036 ;ISSUED AND AFTER A CERTAIN TIME
3037 ;IF THE 'CNTRL RDY' DOES NOT SET
3038 ;AN ERROR IS REPORTED. NOTE THAT
3039 ;THE PC IN ERROR MESSAGE IS THE
3040 ;PC WHERE 'CNT.RESET' IS LOCATED.
3041 ;THIS IS A VERY BASIC ERR & IF IT
3042 ;OCCURS GO BACK TO TEST 10
3043 011676 104421          TST.SIN      ;GO, CHECK IF SIN IS SET, IF SET
3044 ;DO DRV-RESET TO CLEAR IT
3045
3046
3047 011700 013704 001350  MOV    DRIVAD,R4      ;GET DRIV-ADRES
3048 011704 051304          BIS    (R3),R4        ;SET CYLINDER BITS
3049 011706 010477 167426  MOV    R4,DRKDA      ;ADDRS THE DRIVE
3050 011712 012710 000011  MOV    #11,ARO      ;SET 'SEEK', 'GO'
3051
3052 011716 104412          CHKCRDY
3053
3054 011720 104021          ERROR  21      ;GO CHECK IF CONTROL RDY IS SET
3055 ;IF SO, SKIP THE EROR MESSAGE.
3056 ;'CNTRL RDY' DID NOT SET AFTER
3057 ;SENDING CYL ADD TO THE DRIV, 'ADD ACK'
3058 ;FROM DRIVE SHLD HAVE COME BACK
3059 ;THEREUPON SETTING 'CNTRL RDY'
3058 011722 005005          4$: CLR    R5
3059 011724 032711 000100  5$: BIT    #100,AR1
3060 011730 001005          BNE    6$
3061 011732 005205          INC    R5
3062 011734 001373          BNE    5$
3063 011736 004737 020702  JSR    PC,GT4RG
3064 011742 104026          ERROR  26
3065
3066 011744 032711 001000  6$: BIT    #1000,AR1
3067 011750 001403          BEQ    7$
3068 011752 004737 020702  JSR    PC,GT4RG
3069 011756 104001          ERROR  1
3070 011760 032710 140000  7$: BIT    #140000,ARO
3071 011764 001403          BEQ    8$
3072 011766 004737 020702  JSR    PC,GT4RG
3073 011772 104022          ERROR  22
3074
3075
3076
3077 011774 022710 000210  8$: CMP    #210,ARO
3078 012000 001406          BEQ    9$
3079 012002 011037 001164  MOV    ARO,$REG1
3080 012006 012737 000210 001162  MOV    #210,$REG0
3081 012014 104024          ERROR  24
3082 ;RKCS SHOULD CONTAIN THE 'SEEK' BITS
3083 ;IF NOT, ERROR
3084 012016 020477 167316  9$: CMP    R4,DRKDA
3085 012022 001406          BEQ    10$
3086 012024 010437 001162  MOV    R4,$REG0
3087 012030 017737 167304 001164  MOV    DRKDA,$REG1
3088 012036 104027          ERROR  27
3089 ;RKDA CHANGED AFTER DOING SEEK
3090
3091
3092
3093
3094 012040 010477 167274 10$: MOV    R4,DRKDA      ;ADRES THE DRIVE,SEC 0

```

K06

3091	012044	012777	033240	157264	MOV	#OUTBUF, DRKBA	; READ ONE HEADER INTO THIS
3092	012052	012777	177777	167254	MOV	#-1, DRKWC	; BUS ADRES
3093	012060	012710	002005		MOV	#2005, DRD	; GO READ FORMAT
3094	012064	104414			CNT.RDY		; WAIT FOR CNTRL RDY
3095	012066	021337	033240		CMP	(R3), OUTBUF	; WAS THE CORRECT READER READ (FROM
3096	012072	001410			BEG	11\$; CYLINDER TO WHICH SEEK WAS DONE BEFORE)
3097	012074	005037	001162		CLR	\$REG0	; STORE SEC # FROME WHERE HDR WAS RD (0)
3098	012100	011337	001164		MOV	(R3), \$REG1	; GET EXPCD HEADER
3099	012104	013737	033240	001166	MOV	OUTBUF, \$REG2	; GET HDR RECVD
3100	012112	104043			ERROR	43	; WRONG HDR WAS RECVD FROM CYLINDER (ADRES
3101							; IN ER MSGE). NOTE THAT A PURE SEEK WAS
3102							; DONE TO THIS CYL BEFORE READING HDR
3103							; USING READ FORMAT
3104	012114	005737	001356		11\$: TST	INDX1	; SEEK IN REVRSE DIRECTION?
3105	012120	001007			BNE	12\$; YES, BRANCH
3106	012122	005723			TST	(R3)+	; NO, INCREMENT PTR TO NXT SEEK ADRES
3107	012124	022703	001400		CMP	#SEEK2+2, R3	; DONE WITH ALL SKS IN FWD DIR?
3108	012130	001260			BNE	1\$; NO, GO & DO NXT ONE
3109	012132	005237	001356		INC	INDX1	; SET FLAG INDICATING SK IN REVRSE
3110	012136	005743			TST	-(R3)	
3111	012140	005743			12\$: TST	-(R3)	; POSITION PTR TO NXT SK IN REV
3112	012142	022703	001370		CMP	#SEEK0-2, R3	; DONE WITH ALL?
3113	012146	001251			BNE	1\$; IF NOT, DO NXT ONE

```

;*****
; *TEST 27 CHECK DRIVE RESET FROM LAST CYLINDER
; *THE HEADS ARE POSITIONED ON THE LAST CYLINDER (DOING
; *AN IMPLIED SEEK-READ). THEN A DRIVE RESET IS ISSUED.
; *IT'S CHECKED IF THE HEADS WERE BROUGHT BACK TO 0 BY
; *DOING A 1 WORD READ & CHECKING THAT THE CORRECT WORD
; *WAS RECEIVED. IF TESTING ON SIMULATOR THIS TEST IS SKIPPED.
;*****

```

3125	012150	000004			†TST27: SCOPE		
3126	012152	012737	000005	001206	MOV	#5, \$TIMES	; DO 5 ITERATIONS
3127	012160	005737	001344		TST	SIMUL	; R U ON A SIMULATOR?
3128	012164	001124			BNE	TST30	; YES, EXIT
3129	012166	013701	001332		MOV	RKCS, R1	
3130	012172	104413			CNT.RESET		; GO, DO CONTROL RESET
3131							; THIS IS A CALL FOR THE 'CNTRL-
3132							; RESET' ROUTINE. A CONTROL RESET IS
3133							; ISSUED AND AFTER A CERTAIN TIME
3134							; IF THE 'CNTRL RDY' DOES NOT SET
3135							; AN ERROR IS REPORTED. NOTE THAT
3136							; THE PC IN ERROR MESSAGE IS THE
3137							; PC WHERE 'CNT.RESET' IS LOCATED.
3138							; THIS IS A VERY BASIC ERR & IF IT
3139							; OCCURS GO BACK TO TEST 10
3140	012174	005000			CLR	R0	
3141	012176	012703	033240		MOV	#OUTBUF, R3	; ADRES WHERE DATA WILL BE READ INTO
3142	012202	013704	001350		MOV	DRIVAD, R4	
3143	012206	010405			MOV	R4, R5	
3144	012210	052705	014500		BIS	#14500, R5	; SET CYL ADRES=312 (OCTAL)
3145	012214	010577	167120		MOV	R5, DRKDA	; ADRES THE DRIVE, LAST CYLINDER
3146	012220	012777	177777	167106	MOV	#-1, DRKWC	; READ 1 WORD

L06

MAINDEC-11-DZRKK-D MACY11 27(1006) 04-OCT-76 16:06 PAGE 59
 DZRKKD.P11 22-SEP-76 08:47 T27 CHECK DRIVE RESET FROM LAST CYLINDER

SEQ 0076

3147	012226	010377	167104		MOV	R3,ARKBA	; INTO THIS MEMORY ADRES
3148							
3149	012232	012711	000005		MOV	#5,AR1	; READ, GO
3150							
3151	012236	005000			CLR	RO	
3152	012240	104414		1S:	CNT.RDY		; THIS IS A CALL FOR CN.RDY ROUTINE
3153							; WHICH WAITS FOR CNTRL RDY TO SET.
3154							; A RETURN IS MADE AFTER CNTRL RDY
3155							; SETS. IF WITHIN A CERTAIN TIME
3156							; CNTRL RDY DOESN'T SET AN ERROR
3157							; MESSAGE IS GIVEN. WAITING TIME
3158							; 883 MS FOR 11/20, 175 MS FOR 11/45
3159	012242	020513		2S:	CMP	R5,AR3	; WAS THE CORRECT WORD READ?
3160	012244	001407			BEG	3S	; YES, SEEK TO 312 WAS DONE CORRECTLY,3
3161	012246	010537	001162		MOV	R5,\$REGO	; GET EXPCD WORD
3162	012252	011337	001164		MOV	AR3,\$REG1	; GET WORD RECVD
3163	012256	010537	001166		MOV	R5,\$REG2	; GET DSK-ADRES FROM WHERE WORD WAS READ
3164	012262	104044			ERROR	44	; DID NOT READ BACK CORRECT WOPD FROM
3165							; LAST CYL, SEC 0. IF TEST 45 & 46
3166							; WERE SUCCESSFULLY DONE THIS
3167							; ERROR MEANS THAT IMPLIED SEEK
3168							; TO CYL 312 COULD NOT B DONE
3169	012264	012711	000015	3S:	MOV	#15,AR1	; DRIVE RESET, GO
3170	012270	104414			CNT.RDY		; THIS IS A CALL FOR CN.RDY ROUTINE
3171							; WHICH WAITS FOR CNTRL RDY TO SET.
3172							; A RETURN IS MADE AFTER CNTRL RDY
3173							; SETS. IF WITHIN A CERTAIN TIME
3174							; CNTRL RDY DOESN'T SET AN ERFOR
3175							; MESSAGE IS GIVEN. WAITING TIME
3176							; 883 MS FOR 11/20, 175 MS FOR 11/45
3177	012272	005000			CLR	RO	
3178	012274	032777	000100 167024	4S:	BIT	#100,ARKDS	; DID R/W/S RDY SET?
3179	012302	001011			BNE	5S	; YES, BRANCH
3180	012304	012702	177763		MOV	#-15,R2	; IF U R ON A SLOWER MACHINE
3181	012310	005202			INC	R2	; & DO NOT NEED SUCH A LARGE MACHINE
3182	012312	001376			BNE	.-2	; TIME LOOP, CHANGE THESE 3
3183							; INSTRUCTIONS TO 'NOP' THE
3184							; LOOP TIME WILL BE REDUCED
3185							; TO 1100 MS
3186							
3187							; THE TOTAL TIME FOR THE ABOVE
3188							; LOOPS (W/O PUTTING 'NOP'S) IS
3189							; 5304 MS FOR 11/20 AND
3190							; 1061 MS FOR 11/45 WITH MOS
3191							; OR BIPOLAR MEMORY
3192	012314	005200			INC	RO	; WAITED LONG?
3193	012316	001366			BNE	4S	; IF NOT, LUP BAK & WAIT
3194							; IF YES, ERROR
3195	012320	004737	020702		JSR	PC,GT4RG	; GET RKCS,ER,DS,DA
3196	012324	104026			ERROR	26	; R/W/S RDY DID NOT SET AFTER
3197							; DOING DRIVE RESET
3198	012326	032711	140000	5S:	BIT	#140000,AR1	; DID HE OR ERR BIT SET?
3199	012332	001403			BEG	6S	; IF NOT, BRANCH
3200							
3201	012334	004737	020702		JSR	PC,GT4RG	; GET RKCS,ER,DS,DA FOR ERROR MESSAGE
3202	012340	104022			ERROR	22	; HE OR ERR BIT SET ON DOING DRIVE

NO6

MAINDEC-11-DZRKK-D MACY11 27(1006) 04-OCT-76 16:06 PAGE 61
 DZRKKD.P11 22-SEP-76 08:47 T30 'WRITE' - 256 WORD BLOCK ON SECTOR 0, CYLINDER 0

SEQ 0078

3259	012444	013704	001332		MOV	RKCS,R4	
3260							; THE FOLLOWING CODE IS FOR SETTING
3261							; UP THE I/O BUFFER IN MEMORY (STARTING AT
3262							; OUTBUF), WITH A PARTICULAR 256 WORD PATTERN.
3263							; STARTING FROM THE FIRST WORD IN THE BUFFER
3264							; THE LO BYTE WILL BE A COUNT PATTERN
3265							; FROM 0 TO 255 (DECIMAL), WHEREAS THE
3266							; HI-BYTE WILL BE THE COMPLEMENT OF LO BYTE,
3267							; A DECREASING COUNT PATTERN FROM 255 TO 0.
3268							; I.E. THE BUFFER WILL LOOK LIKE:
3269							; OUTBUF (1 111 111 1 00 000 000)
3270							; OUTBUF+2 (1 111 111 0 00 000 001)
3271							; LAST WORD (0 000 000 0 11 111 111)
3272							
3273							
3274	012450	012700	033240		MOV	#OUTBUF,R0	
3275	012454	012701	177401		MOV	#177401,R1	; PATTERN GENERATING NUMBER
3276	012460	012702	177400		MOV	#-400,R2	; SET UP COUNT FOR 256 WORDS
3277	012464	012703	177400		MOV	#177400,R3	; SET UP THE FIRST PATTERN TO B WRITTEN
3278							
3279	012470	010320			MOV	R3,(R0)+	; SET UP FIRST WORD IN I/O BUFFER
3280	012472	005202			INC	R2	; INCREMENT COUNT
3281	012474	060103		1\$:	ADD	R1,R3	; SET UP NEXT WORD PATTERN
3282	012476	010320			MOV	R3,(R0)+	; WRITE IT IN NXT I/O BUFFER WORD
3283	012500	005202			INC	R2	; HAVE U WRITTEN ALL 256 WORDS
3284	012502	001374			BNE	1\$; IF NOT GO & WRITE NEXT PATTERN
3285							
3286	012504	012777	177400	166622	MOV	#-400,@RKWC	; WRITE 256 WORDS
3287	012512	012777	033240	166616	MOV	#OUTBUF,@RKBA	; STARTING FROM THIS BUS ADRES
3288	012520	013777	001350	166612	MOV	DRIVAD,@RKDA	; TO THIS DISK ADRES, CYL 0, SEC 0
3289							
3290	012526	012714	000003		MOV	#3,@R4	; WRITE, GO
3291							
3292	012532	105714			TSTB	@R4	; WAS CNTRL RDY CLEARED AS GO WAS SET?
3293	012534	100003		2\$:	BPL	3\$-2	; YES, BRANCH
3294	012536	004737	020710		JSR	PC,GT3RG	; GET RKCS, ER, DS
3295	012542	104030			ERROR	30	; CNTRL RDY DID NOT CLEAR AS GO WAS SET
3296							; TO 'WRITE'
3297							
3298	012544	005002			CLR	R2	
3299	012546	105777	166560		TSTB	@RKCS	; DID CNTRL RDY SET?
3300	012552	100411		3\$:	BMI	4\$; YES, BRANCH
3301	012554	005202			INC	R2	; WAITED LONG ENOUGH?
3302	012556	001373			BNE	3\$; IF NOT, LUP BAK & WAIT
3303							; IF YES, ERROR
3304	012560	004737	020702		JSR	PC,GT4RG	; GO, GET RKCD, ER, DS, DA
3305	012564	013737	001350	001202	MOV	DRIVAD,\$REG10	; GET THE STARING ADRES
3306	012572	104416			BRKDA4		; BREAK CONTENTS OF \$REG10 INTO
3307							; DRV #, CYL, SUR, SEC #
3308	012574	104031			ERROR	31	; CNTRL RDY DID NOT SET ON COMPLETION
3309							; OF WRITE OF 256 WORDS ON CYL 0, SEC 0
3310							; 'RKDA' IN EROR MSGE GIVES THE
3311							; CONTENTS OF RKDA AT THE TIME OF EROR
3312							; WRITE WAS DONE STARTING AT <DSK-ADRES>
3313							; INDICATED IN EROR MSGE
3314	012576	004737	021142	4\$:	JSR	PC,CHKHE	; CHECK IF 'ERR' OR 'HE' BIT IS SET,

33:05
33:06
33:08
33:09
33:10
33:11
33:12
33:13
33:14
33:15
33:16
33:17
33:18
33:19
33:20
33:21
33:22
33:23
33:24
33:25
33:26
33:27
33:28
33:29
33:30
33:31
33:32
33:33
33:34
33:35
33:36
33:37
33:38
33:39
33:40
33:41
33:42
33:43
33:44
33:45
33:46
33:47
33:48
33:49
33:50
33:51
33:52
33:53
33:54
33:55
33:56
33:57
33:58
33:59
33:60
33:61
33:62
33:63
33:64
33:65
33:66
33:67
33:68
33:69
33:70

```

012602 104032          ERROR 32
012604 020077 166526 58:  CMP    RD, RKBA
012610 001406          BEQ    B5
012612 010037 001162     MOV    RD, $REG0
012616 017737 166514 001164  MOV    RKBA, $REG1
012624 104035          ERROR 35
012626 004737 021224 68:  JSR    PC, CHKWC
012632 104034          ERROR 34
012634 004737 021170 78:  JSR    PC, CHKDA
012640 104033          ERROR 33
012642 004737 021250 88:  JSR    PC, CHKER
012646 104036          ERROR 36
012650 022714 000202 98:  CMP    #202, R4
012654 001406          BEQ    TST31
012656 012737 000202 001162  MOV    #202, $REG0
012664 011437 001164     MOV    R4, $REG1
012670 104024          ERROR 24

```

```

: IF YES, RETURN HERE
: HE OR ERR BIT SET ON DOING WRITE OF
: 256 WORDS ON CYL 0, SEC 0
: WRITE WAS DONE STARTING AT 'DSK-ADRES'
: INDICATED IN EROR MSGE
: 'RKDA' IN EROR MSGE GIVES THE
: CONTENTS OF RKDA AT THE TIME OF EROR
: DID RKBA INCREMENT CORRECTLY?
: YES, BRANCH
: GET EXPCTD RKBA
: GET RKBA RECVD
: RKBA DID NOT INCREMENT CORRECTLY
: (BY 1000 OCTAL BYTES, AFTER WRITE
: OF 400 (OCTAL) WORDS ON SEC 0, CYL 0
: CHECK IF RKWC OVERFLOWED TO 0.
: IF NOT RETURN HERE.
: RKWC DID NOT OVERFLOW, AFTER A
: WRITE OF 256 WORDS ON CYL 0, SEC 0
: CHECK IF RKDA INCREMENTED CORRECTLY.
: IF NOT RETURN HERE
: RKDA DID NOT INCREMENT BY 1 AFTER
: A WRITE OF 256 WORDS IN CYL 0, SEC 0
: CHECK IF ANY BIT RKER IS SET
: IF YES RETURN HERE.
: RKER BIT SET ON DOING WRITE ON
: CYLINDER 0, SECTOR 0
: DOES RKCS STILL CONTAIN THE WRITE BITS?
: YES, EXIT
: GET EXPECTED RKCS
: GET RKCS RECVD
: RKCS DID NOT CONTAIN THE 'WRITE'
: BITS AFTER THE FUNCTION WAS DONE.

```

```

:*****
:*TEST 31      CHECK THAT WRITE WAS DONE CORRECTLY
:*THIS TEST CHECKS IF THE 'WRITE' OF 256 WORDS DONE IN PREVIOUS
:*TEST IS GOOD.  THE SEQUENCE OF OPERATIONS IS AS FOLLOWING:
:*1) DO A READ OF 256 WORDS FROM SECTOR 0, CYLINDER 0
:*   INTO A BUFFER STARTING AT 'OUTBUF'
:*2) COMPARE & CHECK THE DATA THAT IS READ (STARTING AT 'OUTBUF')
:*   WITH THE DATA THAT WAS GENERATED PREVIOUSLY
:*3) REPORT AN ERROR IF THE DATA READ BACK FROM DISK DOES
:*   NOT COMPARE WITH DATA THAT WAS SUPPOSE TO HAVE BEEN WRITTEN
:*****

```

```

012672 000304
012674 104413
TST31:  SCOPE
        CNT.RESET

```

```

:GO, DO CONTROL RESET
:THIS IS A CALL FOR THE 'CNTRL-
:RESET' ROUTINE.  A CONTROL RESET IS
:ISSUED AND AFTER A CERTAIN TIME
:IF THE 'CNTRL RDY' DOES NOT SET
:AN ERROR IS REPORTED.  NOTE THAT
:THE PC IN ERROR MESSAGE IS THE
:PC WHERE 'CNT.RESET' IS LOCATED.
:THIS IS A VERY BASIC ERRS IF IT
:OCCURS GO BACK TO TEST 10

```



```

012676 104421          TST SIN          :CHECK IF SIN IS SET, IF SET
012700 012700 177400    MOV #400,R0      :DO DRIVE RESET TO CLEAR I
012704 012701 033240    MOV #OUTBUF,R1   :SET COUNT FOR 400 WORDS
012710 005021          CLR (R1)+        :TO BE CLEARED IN THE BUFFER
012712 005200          INC R0          :CLR THE 400 WORD BUFFER
012714 001375          BNE BS         :STARTING AT 'OUTBUF'
012716 005000          CLR R0
012720 012777 177400 166400 MOV #400,DRKWC   :READ 256 WORDS
012726 012777 033240 166402 MOV #OUTBUF,DRKBA :INTO THIS ADRES
012734 013777 001350 166376 MOV DRIVAD,DRKDA  :STARTING FROM THIS DISK ADRES

012742 012777 000005 166362 MOV #5,DRKCS     :READ, GO

012750 105777 166356          TSTB DRKCS      :DID CNTRL RDY SET?
012754 100411          BMI 25        :YES, BRANCH
012756 005200          INC R0          :WAITED LONG ENOUGH?
012760 001373          BNE 15         :IF NOT, LUP BAK & WAIT
012762 004737 020702          JSR PC,GT4RG   :ERROR, IF YES
012766 013737 001350 001202 MOV DRIVAD,$REG10 :GO GET RKCD, ER, DS, DA
012774 104416          BRKDA4          :GET THE STARTING ADRES
012776 104045          ERROR 45        :GO TO 'BDAM' & BREAK CONTENTS OF
                                :$REG10 INTO DRV #, CYL, SUR, SEC BITS
                                :CNTRL RDY DID NOT SET AFTER REAC
                                :OF 400 WORDS FROM CYL 0, SEC 0
                                :'RKDA' IN EROR MSGE GIVES THE
                                :CONTENTS OF RKDA AT THE TIME OF EROR
                                :READ WAS DONE STARTING AT (DSK-ADRES)
                                :INDICATED IN EROR MESGE
013000 032777 001000 166320 25: BIT #1000,DRKDS
013006 001033          BNE TST32      :IS SIN SET?
013010 012701 177400          MOV #400,R1    :IF YES, EXIT
013014 012702 177777          MOV #177777,R2
013020 012703 033240          MOV #OUTBUF,R3
013024 012705 177773          MOV #5,R5
013030 062702 177401          ADD #177401,R2
013034 025213          CMP R2,(R3)    :WAS THE READ WORD SAME AS THE WORD
                                :THAT WAS SUPPOSE TO BE WRITTEN
013036 001414          BEQ 75        :YES, BRANCH
                                :NO, ERROR
013040 010137 001162          MOV R1,$REG0   :GET THE # OF WORD
013044 062737 000401 001162 ADD #401,$REG0 :THAT IS IN ERROR (EXAMPLE=1,2--376,377,400)
013052 010237 001164          MOV R2,$REG1   :GET EXPTD WORD (THAT WAS SUPPOSED TO
                                :BE WRITTEN)
013056 011337 001166          MOV (R3),$REG2 :GET WORD RECVD (THAT WAS READ BAK)
013062 104055          ERROR 55    :DID NOT READ BACK WORD THAT WAS SUPPOSED
                                :TO HAVE BEEN WRITTEN PREVIOUSLY. POSITION
                                :OF WORD IN ERROR IS AS INDICATED BY
                                :WORD # ($REG0), SEC 0, CYL 0

013064 005205          INC R5
013066 001403          BEQ TST32
013070 005723          TST (R3)+     :EXIT
                                :INCREMENT POINTER TO NXT WORD (THAT
                                :WAS READ BACK)
013072 005201          INC R1
013074 001355          BNE 65        :HAVE U CHKD ALL 256 WORDS?
                                :IF NOT, LUP BAK & CHK THE NXT WORD
                                :IF YES, EXIT

```

3422
3423
3424
3425
3426
3427
3428
3429
3430
3431
3432
3433
3434
3435
3436
3437
3438
3439
3440
3441
3442
3443
3444
3445
3446
3447
3448
3449
3450
3451
3452
3453
3454
3455
3456
3457
3458
3459
3460
3461
3462
3463
3464
3465
3466
3467
3468
3469
3470
3471
3472
3473
3474
3475
3476
3477
3478
3479
3480
3481
3482

:TEST 32 CHECK 'READ CHECK' FUNCTION - (CYL D, SECTOR 0)
:*THIS TEST CHECKS OUT THE BASIC 'READ CHECK' LOGIC, USING THE DATA BLOCK
:*'CYLINDER, SECTOR 0) WRITTEN IN A PREVIOUS TEST. HENCE THE TEST WHICH
:*WRITES THE DATA BLOCK SHOULD BE DONE PRIOR TO THIS TEST.

013076 000004
013100 104413

↑ST32: SCOPE
CNT.RESET

:GO, DO CONTROL RESET
:THIS IS A CALL FOR THE 'CNTRL-
:RESET' ROUTINE. A CONTROL RESET IS
:ISSUED AND AFTER A CERTAIN TIME
:IF THE 'CNTRL RDY' DOES NOT SET
:AN ERROR IS REPORTED. NOTE THAT
:THE PC IN ERROR MESSAGE IS THE
:PC WHERE 'CNT.RESET' IS LOCATED.
:THIS IS A VERY BASIC ERR& IF IT
:OCCURS GO BACK TO TEST 10
:CHECK IF SI'4 IS SET, IF SET
:DO DRIVE RESET TO CLEAR IT

013102 104421

TST.SIM

013104 013701 001332
013110 013702 001334
013114 013703 001340
013120 013704 001336
013124 012737 052525 033240
013132 012712 177400
013136 013713 001350
013142 012714 033240
013146 012711 000013

MOV RKCS,R1
MOV RKWC,R2
MOV RKDA,R3
MOV RKBA,R4
MOV #52525,OUTBUF
MOV #-400,DR2
MOV DRIVAD,DR3
MOV #OUTBUF,DR4
MOV #13,DR1

:READ CHECK 256 WORDS
:STARTING FROM CYL 0, SECTOR 0
:READ CHECK, GO

013152 105711
013154 100003
013156 004737 020710
013162 104030
013164 104412

15: TSTB DR1
BPL 25
JSR PC,GT3RG
ERROR 30
25: CHKCRDY

:DID CNTRL RDY GET CLEARED AS GO WAS SET?
:YES, BRANCH
:GET RKCS, ER, DS
:CNTRL RDY DID NOT CLEAR AS GO
:GO CHECK IF CONTROL RDY IS SET
:IF SO, SKIP THE EROR MESSAGE.
:WAS SET TO 'READ CHECK'

013166 104056

ERROR 56

013170 032711 140000
013174 001403
013176 004737 020710
013202 104057

35: BIT #140000,DR1
BEQ 45
JSR PC,GT3RG
ERROR 57

:CNTRL RDY DID NOT SET ON DOING
:'READ CHECK' FROM CYL 0, SEC 0
:DID 'ERR' OR 'HE' BIT SET?
:NO, BRANCH
:GO, GET RKCS, ER, DS FOR ERROR MESSAGE
:'ERR' OR 'HE' BIT SET ON DOING
:'READ CHECK' ON CYLINDER 0, SEC 0

013204 032777 000002 166116
013212 001404
013214 017737 166110 001162
013222 104060

45: BIT #2,DRKER
BEQ 55
MOV DRKER,\$REGO
ERROR 60

:DID 'CSE' BIT SET IN RKER"
:NO, BRANCH
:GET RKER
:SOFT ERROR - CSE - ON DOING 'READ
:CHECK' ON CYLINDER 0, SECTOR 0
:U SHOULD HAVE GOT ERROR 102 ALSO
:DID WORD COUNT OVERFLOW TO 0?

013224 005712
013226 001405
013230 011237 001162
013234 011137 001164
013240 104061

55: TST DR2
BEQ 65
MOV DR2,\$REGO
MOV DR1,\$REG1
ERROR 61

:YES, BRANCH
:GET RKWC
:GET RKCS
:WORD COUNT DID NOT OVERFLOW
:ON DOING 'READ CHK' ON CYL 0, SEC 0

E07

```

3483 013242 013702 001353 65: MOV DRIVAD,R2 ;RKDA SHOULD INCREMENT
3484 013246 005202 INC R2 ;TO THIS AFTER 'RD CHK' IS DONE
3485 013250 020213 CMP R2,R3 ;DID RKDA INCREMENT CORRECTLY?
3486 013252 001405 BEQ 75
3487 013254 010237 001162 MOV R2,$REG0 ;GET EXPCTD RKDA
3488 013260 011337 001164 MOV R3,$REG1 ;GET RKDA RECVD
3489 013264 104062 ERROR 62 ;RKDA DID NOT INCREMENT CORRECTLY
; (BY 1) ON DOING 'READ CHK' ON
; CYL 0, SEC 0
3490 013266 022714 033240 75: CMP #OUTBUF,R4 ;DID RKBA GET CHANGED?
3491 013272 001406 BEQ 85 ;NO, BRANCH (RKBA WON'T CHANGE, NO NPR'S,
3492 013274 012737 033240 001162 MOV #OUTBUF,$REG0 ;GET EXPCTD RKBA
3493 013302 011437 001164 MOV R4,$REG1 ;GET RKBA RECVD
3494 013306 104063 ERROR 63 ;RKBA CHANGED AFTER DOING 'READ CHK'
; ON CYLINDER 0, SECTOR 0, SHOULD
; NOT CHANGE, FOR, NO NPR'S.
3495 013310 022737 052525 033240 85: CMP #52525,OUTBUF ;'OUTBUF' SHOULD STILL CONTAIN THE
; SAME WORD AS IT DID BEFORE 'RD CHK'
; NOTE THAT AT THE BEGINING OF THIS TEST
; 52525 WAS WRITTEN INTO 'OUTBUF'
3496 013316 001412 BEQ TST33 ;YES, EXIT
; REPORT ERROR IF 'OUTBUF' CHANGED
3497 013320 012737 033240 001162 MOV #OUTBUF,$REG0 ;GET ADRES OF OUTBUF
3498 013326 012737 052525 001164 MOV #52525,$REG1 ;GET EXPCTD WORD IN 'OUTBUF'
3499 013334 013737 033240 001166 MOV OUTBUF,$REG2 ;GET WORD FOUND IN 'OUTBUF'
3500 013342 104064 ERROR 64 ;AS MENTIONED ABOVE, IF 'WRITE' OF
; 256 WORD DATA BLOCK WAS DONE
; CORRECTLY BEFORE, THEN THIS ERROR
; COULD MEAN THAT AN NPR WAS DONE
; ON 'READ CHECK'.

```

```

*****
; *TEST 33 CHECK THE 'WRITE CHECK' FUNCTION - ON CYLINDER 0, SECTOR 0
; *THIS TEST CHECKS OUT THE BASIC 'WRITE CHECK' LOGIC, USING THE 256
; *WORD DATA BLOCK (SECTOR 0, CYLINDER 0) WRITTEN IN A PREVIOUS
; *TEST. THE BUFFER IN MEMORY, USED FOR COMPARISON OF DATA, IS THE
; *ONE STARTING AT 'OUTBUF'. HENCE THE TEST WHICH WRITES THE
; *256 WORD BLOCK ON THE DISK (AS WELL AS CREATING THE 256
; *256 WORD MEMORY BUFFER) SHOULD BE DONE BEFORE THIS TEST.
*****

```

```

3523 013344 000004 TST33: SCOPE ;GO, DO CONTROL RESET
3524 013346 104413 CNT.RESET ;THIS IS A CALL FOR THE 'CNTRL-
; RESET' ROUTINE. A CONTROL RESET IS
; ISSUED AND AFTER A CERTAIN TIME
; IF THE 'CNTRL RDY' DOES NOT SET
; AN ERROR IS REPORTED. NOTE THAT
; THE PC IN ERROR MESSAGE IS THE
; PC WHERE 'CNT.RESET' IS LOCATED.
; THIS IS A VERY BASIC ERR& IF IT
; OCCURS GO BACK TO TEST 10
3525 013350 104421 TST.SIN ;CHECK IF SIN IS SET, IF SET
; DO DRIVE RESET TO CLEAR IT
3526 013352 013701 001332 MOV RKCS,R1
3527 013356 012700 177400 MOV #-400,R0
3528 013362 012702 033240 MOV #OUTBUF,R2

```

F07

MAINDEC-11-DZKRC-C MACY11 27(1006) 04-OCT-76 16:06 PAGE 66
 DZKRC.P11 22-SEP-76 08:47 T33 CHECK THE 'WRITE CHECK' FUNCTION - ON CYLINDER 0, SECTOR 0 SEG 0082

3539	013366	012703	177777		MOV	#177777,R3	
3540	013372	062703	177401	15:	ADD	#177401,R3	
3541	013376	010322			MOV	R3,(R2)+	
3542	013400	005200			INC	R0	
3543	013402	001373			BNE	15	
3544	013404	012777	177400	165722	MOV	#-400,DRKWC	;WRITE CHECK 256 WORDS
3545	013412	012777	033240	165716	MOV	#OUTBUF,DRKBA	;STARTING AT THIS BUS ADRES
3546	013420	013777	001350	165712	MOV	DRIVAD,DRKDA	;WITH THIS DISK DATA BLOCK (CYL 0, SEC 0,
3547	013426	012711	000007		MOV	#7,DR1	;WRITE CHECK, GO
3548							
3549	013432	005000			CLR	R0	;GIVE SOME TIME
3550	013434	105711		25:	TSTB	DR1	;DID CNTRL RDY CLEAR AS GO WAS SET?
3551	013436	100003			BPL	35	;YES BRANCH
3552	013440	004737	020710		JSR	PC,GT3RG	;GET RKCS, ER, DS
3553	013444	104030			ERROR	30	;CNTRL RDY DID NOT CLEAR AS GO WAS
3554							;SET TO DO WRITE CHECK
3555	013446	104412		35:	CHKCRDY		;GO CHECK IF CONTROL RDY IS SET
3556							;IF SO, SKIP THE EROR MESSAGE.
3557	013450	104065			ERROR	65	;CNTRL RDY DID NOT SET AFTER
3558							;COMPLETING WRITE CHECK ON
3559							;CYLINDER 0, SECTOR 0
3560	013452	032711	140000	45:	BIT	#140000,DR1	;DID HE OR ERR BIT SET
3561	013456	001403			BEQ	55	;NO, BRANCH
3562	013460	004737	020710		JSR	PC,GT3RG	;GO GET RKCS ER DS FOR ERROR MESSAGE
3563	013464	104066			ERROR	66	;HE OR LRR BIT SET ON DOING WRITE
3564							;CHK ON CYLINDER 0, SEC 0
3565	013466	032777	000001	165634	55:	BIT	#1,DRKER
3566	013474	001403			BEQ	65	;DID WCE SET IN RKER?
3567	013476	004737	020710		JSR	PC,GT3RG	;NO, BRANCH
3568	013502	104067			ERROR	67	;YES GET RKCS, ER, DS
3569							;WCE ON WRITE CHECK OF CYL 0, SEC 0
3570							;NOTE THAT IF A PREVIOUS TEST
3571							& THEN COMPARED WITH MEMORY BUFFER
3572							TO SEE IF IT WAS WRITTEN CORRECT WAS
3573							DONE RIGHT BEFORE, THIS ERROR SHOULD NOT
3574							HAPPEN UNLESS THERE IS A FAULT IN THE
3575	013504	005777	165624	65:	TST	DRKWC	;COMPARING LOGIC OF 'WRT CHK'
3576	013510	001406			BEQ	75	;DID RKWC OVERFLOW?
3577	013512	017737	165616	001162	MOV	DRKWC,\$REG0	;YES, BRANCH
3578	013520	011137	001164		MOV	DR1,\$REG1	;NO, GET RKWC
3579	013524	104061			ERROR	61	;GET RKCS
3580							;RKWC DID NOT OVERFLOW AFTER
3581	013526	012704	001350	75:	MOV	DRIVAD,R4	;WRITE CHECK ON CYL 0, SEC 0
3582	013532	005204			INC	R4	;RKDA SHOULD INCREMENT
3583	013534	020477	165600		CMP	R4,DRKDA	;TO THIS AFTER WRT CHK
3584	013540	001406			BEQ	85	;DID RKDA INCREMENT CORRECTLY?
3585	013542	010437	001162		MOV	R4,\$REG0	;YES, BRANCH
3586	013546	017737	165566	001164	MOV	DRKDA,\$REG1	;NO, GET EXPCTD RKDA
3587	013554	104070			ERROR	70	;GET RKDA RECVD
3588							;RKDA DID NOT INCREMENT CORRECTLY
3589	013556	022777	034240	165552	85:	CMP	#OUTBUF+1000,DRKBA
3590	013564	001407			BEQ	95	;DID RKBA INCREMENT CORRECTLY?
3591	013566	012737	034240	001162	MOV	#OUTBUF+1000,\$REG0	;YES, EXIT
3592	013574	017737	165536	001164	MOV	DRKBA,\$REG1	;GET EPCTD RKBA
3593	013602	104071			ERROR	71	;GET RKBA RECVD
3594							;RKBA DID NOT INCREMENT CORRECTLY
							; (BY 1000 BYTES) AFTER A WRT CHK

```

3595                                     ; OF 256 WORDS ON CYL 0, SEC 0
3596 013604 022711 000206 35:  CMP      #206, R1      ; DOES RKCS STILL CONTAIN THE WRT CHK BITS?
3597 013610 001406          BEQ      TST34      ; YES, BRANCH
3598 013612 012737 000206 001162  MOV      #206, $REG0 ; NO, GET EXPCTD RKCS
3599 013620 011137 001164  MOV      R1, $REG1  ; GET RKCS RECVD
3600 013624 104024          ERROR    24      ; RKCS BITS CHANGED AFTER WRT CHK
3601                                     ; WAS DONE
3602
3603 ::*****
3604 *TEST 34  CHECK THAT IBA INHIBITS INCREMENTING OF RKBA
3605 ; *THIS TEST CHECKS THAT THE BUS ADDRESS DOES NOT INCREMENT WHEN
3606 ; *THE IBA BIT IS SET. SEQUENCE OF OPERATIONS:
3607 ; *1) CLEAR OUT 256 WORD BUFFER IN MEMORY (OUTBUF)
3608 ; *2) READ FROM SECTOR 0, CYLINDER 0 THE 256 WORD BLOCK THAT WAS
3609 ; *WRITTEN IN A PREVIOUS TEST (NOTE: THAT TEST SHOULD HAVE BEEN
3610 ; *DONE BEFORE THIS). IBA BIT IS SET DURING READ BACK.
3611 ; *3) CHECK THAT RKBA DID NOT INCREMENT
3612 ; *4) CHECK THAT THE ENTIRE BLOCK WAS READ INTO THE SAME MEMORY
3613 ; *WORD (OUTBUF) & THE REST OF THE WORDS IN THAT BUFFER ARE 0
3614 ; *AS PREVIOUSLY CLEARED OUT.
3615 ::*****
3616 *ST34:  SCOPE
3617 013626 000004          CNT.RESET
3618 013630 104413
3619
3620                                     ; GO, DO CONTROL RESET
3621                                     ; THIS IS A CALL FOR THE 'CNTRL-
3622                                     ; RESET' ROUTINE. A CONTROL RESET IS
3623                                     ; ISSUED AND AFTER A CERTAIN TIME
3624                                     ; IF THE 'CNTRL RDY' DOES NOT SET
3625                                     ; AN ERROR IS REPORTED. NOTE THAT
3626                                     ; THE PC IN ERROR MESSAGE IS THE
3627                                     ; PC WHERE 'CNT.RESET' IS LOCATED.
3628                                     ; THIS IS A VERY BASIC ERR& IF IT
3629                                     ; OCCURS GO BACK TO TEST 10
3630                                     ; CHECK IF SIN IS SET, IF SET
3631                                     ; DO DRIVE RESET TO CLEAR IT
3632
3633 013632 104421          TST.SIN
3634
3635 013634 013701 001332  MOV      RKCS, R1
3636 013640 012700 177400  MOV      #-400, R0
3637 013644 012702 033240  MOV      #OUTBUF, R2
3638 013650 010203          MOV      R2, R3
3639                                     ; SET UP COUNT FOR 256 WORDS
3640
3641 15:  CLR      (R3)+
3642       INC     R0
3643       BNE    15
3644       MOV   #-400, R1
3645       MOV   R2, R1
3646       MOV   DRIVAD, R1
3647                                     ; CLEAR OUT THE 256
3648                                     ; WORD MEMORY BUFFER STARTING
3649                                     ; AT 'OUTBUF'
3650                                     ; READ BACK 256 WORDS
3651                                     ; INTO THIS BUS ADRES (IBA WILL B SET)
3652                                     ; FROM THIS DSK ADRES (SEC 0, CYL 0)
3653                                     ; NOTE: SEC 0 HAS BEEN WRITTEN IN A
3654                                     ; PREVIOUS TEST WITH A UNIQUE PATTERN
3655                                     ; READ, GO, IBA SET
3656
3657 013700 012711 004005  MOV      #4005, R1
3658
3659 25:  CLR      COUNT
3660       TSTB   R1
3661       BMI   25
3662       INC   COUNT
3663       BNE   25
3664       JSR   PC, GT4RG
3665       MOV   DRIVAD, $REG10
3666       BRKDAH
3667                                     ; DID CNTRL RDY SET?
3668                                     ; YES, BRANCH
3669                                     ; WAITED LONG ENOUGH?
3670                                     ; IF NOT, LUP BAK & WAIT
3671                                     ; GO, GET RKCS, ER, DS, DA
3672                                     ; GET THE STARTING ADRES
3673                                     ; BREAK CONTENTS OF $REG10
3674
3675 013704 005037 001362
3676 013710 105711
3677 013712 100412
3678 013714 005237 001362
3679 013720 001373
3680 013722 004737 020702
3681 013726 013737 001350 001202
3682 013734 104416

```

H07

MAINDEC-11-DZPKK-D MACY11 27(1006) 04-OCT-76 16:06 PAGE 68
 DZPKK.D.P11 22-SEP-76 08:47 T34 CHECK THAT IBA INHIBITS INCREMENTING OF RKBA

SEG 0085

3651									INTO DR #, CYL, SUR, SEC
3652	013736	104045				ERPOR	45		CNTRL RDY DID NOT SET AFTER DOING
3653									READ
3654	013740	004737	021142		3S:	JSR	PC,CHKHE		CHECK IF 'ERR' OR 'HE' BIT IS SET,
3655									IF YES, RETURN HERE.
3656	013744	104046				ERROR	46		ERR BIT SET ON DOING READ FROM SEC 0,
3657									CYL 0 (INDICATED IN (DSK-ADRES))
3658									'RKDA' IN EROR MSGE GIVES THE
3659									CONTENTS OF RKDA AT THE TIME OF EROR
3660									
3661	013746	020277	165364		4S:	CMP	R2,DRKBA		DID RKBA INCREMENT?
3662	013752	001406				BEQ	5S		OK IF NOT, BRANCH
3663	013754	010237	001162			MOV	R2,\$REGO		GET EXPTD RKBA
3664	013760	017737	165352	001164		MOV	DRKBA,\$REG1		GET RKBA RCVD
3665	013766	104072				ERROR	72		RKBA INCREMNTED WHEN IBA BIT WAS
3666									SET, SHOULD NOT HAVE
3667	013770	032777	001000	165330	5S:	BIT	#1000,DRKDS		IS \$IN SET?
3668	013776	001042				BNE	TST35		IF YES, EXIT
3669	014000	012700	177400			MOV	#-400,R0		
3670	014004	022712	000377			CMP	#377,DR2		CHECK THAT THE FIRST WORD IN
3671									'OUTBUF' IS 377 (LAST WORD OF SEC 0,
3672									CYL 0). NOTE THAT READ WAS DONE
3673	014010	001411				BEQ	6S		INTO THIS SAME WRD WITH IBA SET
3674	014012	012737	000377	001162		MOV	#377,\$REGO		GET EXPTD WORD (LAST WORD OF THE BUFFER
3675	014020	011237	001164			MOV	(R2),\$REG1		GET WORD RCVD (LAST WRD FROM SEC 0)
3676	014024	013737	001350	001166		MOV	DRIVAD,\$REG2		DISK ADRES WHERE ERROR OCCURED
3677									(SEC 0, CYL 0 LAST WORD)
3678									DATA ERROR
3679	014032	104044				ERROR	44		THE FIRST WORD IN MEM BUFFER (OUTBUF)
3680									SHOULD BE NON-ZERO & SHOULD CONTAIN
3681									THE LAST WORD READ BACK FROM SEC 0
3682									CYL 0 THIS DID NOT HAPPEN IF THE ERROR OCCURS
3683	014034	005722			6S:	TST	(R2)+		INCREMENT POINTER TO THE NXT WORD
3684	014036	012705	177773			MOV	#-5,R5		ALLOW ONLY 5 MESSAGES FOR ERR 116
3685	014042	005200			7S:	INC	R0		CHKD ALL 256 WORDS IN THE BUFFER?
3686	014044	001417				BEQ	TST35		YES, EXIT
3687	014046	005722				TST	(R2)+		IS THIS WORD 0?
3688	014050	001774				BEQ	7S		YES, LUP BAK & CHK THE NXT WORD?
3689	014052	005037	001164			CLR	\$REG1		ERROR. GET EXPTD WORD - 0
3690	014056	014237	001166			MOV	-(R2),\$REG2		GET WORD THAT WAS FOUND IN THE BUFFER
3691	014062	010004				MOV	R0,R4		
3692	014064	062704	000401			ADD	#401,R4		
3693	014070	010437	001162			MOV	R4,\$REGO		THIS 'WORD #' IN MEMORY BUFFER
3694									SHOULD HAVE BEEN ZERO
3695	014074	104073				ERROR	73		THE 256 WORD BUFR (STARTING AT
3696									OUTBUF) WAS CLEARED BEFORE READING
3697									BAK SEC 0 INTO IT. SINCE THE IBA
3698									BIT WAS SET DURING THE READ, ONLY
3699									THE FIRST WORD OF (OUTBUF) SHOULD
3700									HAVE CHANGED, THE REST OF THE WORDS
3701									SHOULD BE STILL 0. IF THIS ERROR
3702									OCCURS, 'WORD #' (OF THE BUFFER) AS
3703									INDICATED IN THE EROR MESSAGE) GOT
3704									CHANGED WHEN READ WAS DONE FROM
3705									THE DISK, INDICATING THAT WITH IBA
3706									SET X-FER WAS NOT DONE INTO THE


```

3763 014206 000403 BR 35
3764
3765 014210 022626 25: CMP (SP)+,(SP)+ ;RESTORE STACK PTR (FROM RK11 INTRUPT)
3766 014212 022626 CMP (SP)+,(SP)+ ;RESTORE STACK PTR (FROM WAT.INT)
3767 014214 104020 ERROR 20 ;AN UNEXPECTED RK11 INTERRUPT
3768 ;OCCURED. THERE SHOULD HAVE BEEN
3769 ;ONLY 1 INTERRUPT (TO 15 ABOVE)
3770 014216 012777 004526 165156 35: MOV #BADINT,ARKVEC ;RESTORE VECTOR ADRES FOR
3771 ;UNEXPECTED RK11 INTERRUPT,
3772 014224 012746 000340 MOV #340,-(SP)
3773 014230 012746 014236 MOV #655,-(SP)
3774 014234 000002 RTI
3775 014236 655:
3776
3777
3778
3779
3780
3781
3782
3783
3784
3785
3786
3787 014236 000004
3788 014240 012737 000005 001206
3789 014246 104413
3790
3791
3792
3793
3794
3795
3796
3797
3798
3799 014250 013700 001332
3800 014254 013777 001350 165056
3801 014262 004737 021412
3802 014266 104026
3803
3804 014270 013701 001402
3805 014274 012721 014340
3806 014300 012711 000340
3807 014304 052777 000040 165026
3808 014312 012710 000111
3809 014316 104420 000300
3810
3811
3812
3813
3814
3815 014322 012777 004526 165052
3816 014330 011037 001162
3817 014334 104075
3818

```

```

;*****
;*TEST 36 CHECK THAT WITH IDE SET RK11 INTERRUPTS AFTER INTIATION & COMPLETION OF
;*THIS TEST CHECKS THAT AN INTERRUPT FROM RK11 OCCURS AFTER
;*A SEEK IS INITIATED WITH 'IDE' BIT SET, AND THEN A SECOND
;*INTERRUPT OCCURS AFTER THE SEEK IS DONE. IT ALSO CHECKS THAT
;*AFTER THE FIRST INTERRUPT 'SCP' BIT IS NOT SET, WHEREAS AFTER
;*THE SECOND INTERRUPT 'SCP' IS SET.
;*THIS TEST ALSO CHECKS A PART OF THE POLLING LOGIC.
;*****

```

```

†ST36: SCOPE
MOV #5,$TIMES ;DO 5 ITERATIONS
CNT.RESET ;GO DO CONTROL RESET
;THIS IS A CALL FOR THE 'CNTPL-
;RESET' ROUTINE. A CONTROL RESET IS
;ISSUED AND AFTER A CERTAIN TIME
;IF THE 'CNTRL RDY' DOES NOT SET
;AN ERROR IS REPORTED. NOTE THAT
;THE PC IN ERROR MESSAGE IS THE
;PC WHERE 'CNT.RESET' IS LOCATED.
;THIS IS A VERY BASIC ERR3 IF IT
;OCCURS GO BACK TO TEST 10

```

```

3800 014254 013777 001350 165056 MOV RKCS,R0
3801 014262 004737 021412 MOV DRIVAD,ARKDA ;ADRES THE DRIVE
3802 014266 104026 JSR PC,DRESET ;GO DO DRIVE RESET
3803 ERROR 26 ;R/W/S RDY DIDN'T SET AFTER DOING
;ABOVE DRIVE RESET
3804 014270 013701 001402 25: MOV RKVEC,R1
3805 014274 012721 014340 MOV #35,(R1)+ ;SET UP VECTOR ADRES FOR RK11 INTERUPT
3806 014300 012711 000340 MOV #340,(R1) ;SET UP PSW ON INTERRUPT
3807 014304 052777 000040 165026 BIS #40,ARKDA ;ADRES CYLINDER #1
3808 014312 012710 000111 MOV #111,ARO ;SEEK, GO WITH IDE SET
3809 014316 104420 000300 WAT.INT ,300 ;WAIT FOR THE DRIVE TO
;INTERRUPT AFTER ADRES WAS RECVD
;WAITING TIME= 1.4 MS FOR 11/20
;280 US FOR 11/45
;ERROR, IF INTERUPT DID NOT OCCUR
;BY NOW
3815 014322 012777 004526 165052 MOV #BADINT,ARKVEC ;RESTORE UNEXPECTED RK11 INTERRUPT
3816 014330 011037 001162 MOV ARO,$REGO ;GET RKCS
3817 014334 104075 ERROR 75 ;INTERRUPT DID NOT OCCUR AFTER
;SEEK WAS INITIATED WITH IDE SET

```



```

3875 014516 104413          CNT.RESET          ;GO DO CONTROL RESET
3876 014520 013777 001350 164612  MOV      DRIVAD,DRKDA ;ADRES THE DRIVE
3877 014526 032777 160000 164572  BIT      #160000,DRKDS ;DID CNTRL RESET CLEAR DRIVE ID BITS?
3878 014534 001404          BEQ      B5          ;YES, BRANCH
3879 014536 017737 164564 001162  MOV      DRKDS,$REGO ;GET RKDS
3880 014544 104050          ERROR    50          ;CONTROL RESET DIDN'T CLEAR THE
3881                                     ;DRIVE ID BITS (13-15) IN RKDS
3882
3883
3884 014546 022710 000200 85:  CMP      #200,DR0    ;WAS SCP BIT CLEARED BY CNTRL RESET?
3885 014552 001403          BEQ      TST37      ;:YES, EXIT
3886 014554 011037 001162  MOV      DR0,$REGO  ;GET RKCS
3887 014560 104100          ERROR    100        ;CNTRL RESET DID NOT CLEAR SCP BIT
3888
3889 ;:*****
3890 ;*TEST 37 CHECK THAT WITH IDE SET RK11 INTERRUPTS WHEN READ IS DONE
3891 ;*THIS TEST CHECKS THAT WHEN A DATA TRANSFER FUNCTION IS DONE
3892 ;*WITH IDE BIT SET, RK11 INTERRUPTS WHEN THE FUNCTION IS COMPLETED
3893 ;*FUNCTION USED IN THIS TEST IS READ.
3894 ;:*****
3895 014562 000004  TST37: SCOPE
3896 014564 104413          CNT.RESET          ;GO, DO CONTROL RESET
3897                                     ;THIS IS A CALL FOR THE 'CNTRL-
3898                                     ;RESET' ROUTINE. A CONTROL RESET IS
3899                                     ;ISSUED AND AFTER A CERTAIN TIME
3900                                     ;IF THE 'CNTRL RDY' DOES NOT SET
3901                                     ;AN ERROR IS REPORTED. NOTE THAT
3902                                     ;THE PC IN ERROR MESSAGE IS THE
3903                                     ;PC WHERE 'CNT.RESET' IS LOCATED.
3904                                     ;THIS IS A VERY BASIC ERR& IF IT
3905                                     ;OCCURS GO BACK TO TEST 10
3906 014566 104421          TST.SIN          ;CHECK IF SIN IS SET, IF SET
3907                                     ;DO DRIVE RESET TO CLEAR IT
3908
3909 014570 013700 001332  MOV      RKCS,R0
3910 014574 013702 001340  MOV      RKDA,R2
3911 014600 013704 001336  MOV      RKBA,R4
3912 014604 013701 001350  MOV      DRIVAD,R1
3913 014610 052701 000013  BIS      #13,R1      ;SET BITS FOR SEC 13
3914 014614 012777 177600 164512  MOV      #-200,DRKWC ;READ 200 (OCTAL WORDS)
3915 014622 010112  MOV      R1,DR2     ;FROM THIS DISK ADRES (CYL 0, SEC 13)
3916 014624 012714 033240  MOV      #OUTBUF,DR4 ;INTO THIS BUS ADRES
3917 014630 013705 001402  MOV      RKVEC,R5
3918 014634 012725 014672  MOV      #15,(R5)+  ;SET UP VECTOR ADRES FOR RK11 TO INTRUPT
3919 014640 012715 000340  MOV      #340,(R5) ;SET PSW ON INTERUPT
3920 014644 012710 000105  MOV      #105,DR0  ;READ, GO, IDE SET
3921 014650 104420 127710  WAT.INT ,127710 ;WAIT FOR RK11 TO INTERRUPT ON
3922                                     ;COMPLETION OF READ
3923                                     ;WAITING TIME= 337 MS FOR 11/20
3924                                     ;67 MS FOR 11/45
3925 C' - - : 012777 004526 164520  MOV      #BADINT,DRKVEC ;RESTORE UNEXPTED INTERRUPT VECTOR ADRES
3926 014662 011037 001162  MOV      DR0,$REGO ;GET RKCS
3927 014666 04101          ERROR    101        ;RK11 DID NOT INTERRUPT AFTER READ
3928                                     ;WAS DONE, IDE BIT SET.
3929 014670 000404          BR      15+10
3930 014672 022626 15:  CMP      (SP)+,(SP)+ ;OK, IF RK11 INTERRUPTED TO THIS

```

M07

MAINDEC-11-DZRKK-D MACY11 27(1006) 04-OCT-76 16:06 PAGE 73
DZRKKD.P11 22-SEP-76 08:47

T37 CHECK THAT WITH IDE SET RK11 INTERRUPTS WHEN READ IS DONE

SEQ 0090

```

3931                                     ;RESTORE STACK POINTER (FROM RK11 INTERRUPT)
3932 014674 022626                       CMP      (SP)+,(SP)+ ;RESTORE STACK POINTER (FROM WAT.INT)
3933 014676 012777 004526 164476        MOV      #BADINT,ARKVEC ;RESTORE UNEXPECTED RK11 INTERRUPT
3934                                     ;VECTOR ADRES
3935 014704 004737 021250                JSR      PC,CHKER      ;CHECK IF ANY BIT IN RKER IS SET,
3936                                     ;IF YES, RETURN HERE.
3937 014710 104036                       ERROR    36           ;RKER SET ON DOING READ FROM SEC 0,
3938                                     ;CYL 13 IN INTERRUPT MODE
3939 014712 062701 000005                4S:     ADD      #5,R1   ;RKDA SHOULD HAVE INCREMENTEC TO THIS
3940 014716 020112                       CMP      R1,AR2       ;DID RKDA INCREMENT CORRECTLY?
3941 014720 001405                       BEQ      2S           ;YES BRANCH
3942 014722 010137 001162                MOV      R1,$REG0     ;GET EXPCTD RTDA
3943 014726 011237 001164                MOV      AR2,$REG1    ;GET RKDA RECVD
3944 014732 104040                       ERROR    40           ;RKDA INCREMENTED WRONG ON DOING
3945                                     ;A READ ON CYL 0, SEC 13
3946 014734 004737 021224                2S:     JSR      PC,CHKWC ;CHECK THAT RKWC OVERFLOWED TO 0,
3947                                     ;IF NOT RETURN HERE.
3948 014740 104041                       ERROR    41           ;RKWC DIDN'T OUFLO AFTER
3949                                     ;A READ OF 200 WORDS
3950
3951 014742                                3S:
3952 014742 012746 000340                MOV      #340,-(SP)
3953 014746 012746 014754                MOV      #64S,-(SP)
3954 014752 000002                       RTI
3955 014754                                64S:
3956 014754 022714 033640                CMP      #OUTBUF+400,AR4 ;DID RKBA INCREMENT CORRECTLY?
3957 014760 001406                       BEQ      TST40        ;:YES, EXIT
3958 014762 012737 033640 001162        MOV      #OUTBUF+400,$REG0 ;GET EXPCT RKBA
3959 014770 011437 001164                MOV      AR4,$REG1    ;GET RKBA RECVD
3960 014774 104042                       ERROR    42           ;RKBA DID NOT INCREMENT CORRECTLY
3961                                     ;AFTER A READ OF 200 WORDS
3962
3963                                     ;:*****
3964                                     ;*TEST 40 CHECK THAT RK11 INTERRUPTS AT BRS ONLY
3965                                     ;*THIS TEST CHECKS THAT RK11 CAN ITERRUPT AT BRS ONLY. IF IT
3966                                     ;*INTERRUPTS AT A LEVEL HIGHER THAN BRS AN ERROR IS INDICATED.
3967                                     ;*IF IT DOES NOT INTERRUPT AT BRS ORLOWER THEN ALSO AN
3968                                     ;*ERROR IS INDICATED. IF FOR SOME REASON THE INTERRUPT
3969                                     ;*LEVEL IS CHANGED FROM BRS, THEN CONTENTS OF RKPRI WILL
3970                                     ;*HAVE TO BE CHANGED ACCORDINGLY AND STILL TEXT WILL
3971                                     ;*CHECK FOR THIS BR LEVEL.
3972                                     ;:*****
3973 014776 000004                †TST40: SCOPE
3974 015000 104413                CNT.RESET ;GO, DO CONTROL RESET
3975                                     ;THIS IS A CALL FOR THE 'CNTRL-
3976                                     ;RESET' ROUTINE. A CONTROL RESET IS
3977                                     ;ISSUED AND AFTER A CERTAIN TIME
3978                                     ;IF THE 'CNTRL RDY' DOES NOT SET
3979                                     ;AN ERROR IS REPORTED. NOTE THAT
3980                                     ;THE PC IN ERROR MESSAGE IS THE
3981                                     ;PC WHERE 'CNT.RESET' IS LOCATED.
3982                                     ;THIS IS A VERY BASIC ERR& IF IT
3983                                     ;OCCURS GO BACK TO TEST 10
3984 015002 104421                TST.SIN ;CHECK IF SIN IS SET, IF SET
3985                                     ;DO DRIVE RESET TO CLEAR IT
3986 015004 012737 015040 001110        MOV      #1,$LPERR   ;SET RETURN ADRES FOR LUPING

```

NO7

MAINDEC-11-DZRKK-D
DZRKKD.P11

MACY11 27(1006) 04-OCT-76 16:06 PAGE 74
22-SEP-76 08:47

T40 CHECK THAT RK11 INTERRUPTS AT BR5 ONLY

SEG 0091

```

3987
3988 015012 013700 001332          MOV      RKCS,R0          ;ON ERROR (SW 9)
3989 015016 013777 001350 164314    MOV      DRIVAD,DRKDA
3990 015024 012701 000007          MOV      #7,R1          ;PRIORITY LEVEL 7
3991 015030 012702 000340          MOV      #340,R2        ;BR LEVEL 7 FOR PSW
3992 015034 013703 001400          MOV      RKPRI,R3       ;NOTE, IF RK11 INTERRUPT LEVEL IS
                          ;CHANGED FROM 5 TO ANY OTHER LEVEL
                          ;THEN CHANGE CONTENTS OF 'RKPRI'
                          ; ACCORDINGLY
3993
3994
3995
3996 015040 013704 001402          15:     MOV      RKVEC,R4
3997 015044 012724 015152          MOV      #3$, (R4)+     ;SET UP ADRES FOR RK11 TO INTERUPT
3998 015050 012714 000340          MOV      #340, (R4)     ;SET UP PSW ON INTERUPT
3999 015054 010246                    MOV      R2, -(SP)      ;SET PROCESSOR PRIORITY LEVEL AS
4000 015056 012746 015064          MOV      #4$, -(SP)
4001 015062 000002                    RTI
4002 015064                    45:
4003 015064 012710 000100          MOV      #100,DR0       ;INDICATED BY R2
4004 015070 012705 177760          MOV      #-20,R5        ;SET THE IDE BIT
4005 015074 005205                    INC      R5              ;WAIT FOR THE RK11 INTERRUPT
4006 015076 001376                    BNE     .-2              ;WAITING TIME=78 US FOR 11/20
4007 015100 020203                    CMP     R2,R3            ;13 US FOR 11/45
4008 015102 003005                    BGT     2$              ;WAS THE CPU PRIORITY LEVEL LESS THAN
                          ;THE RK11 LEVEL? IF YES, RK11
                          ;SHOULD HAVE INTERRUPTED. ERROR.
                          ;IF IT DID NOT
4009
4010
4011 015104 010137 001162          MOV      R1,$REG0       ;GET CPU BR LEVEL
4012 015110 011037 001164          MOV      DR0,$REG1     ;GET RKCS
4013 015114 104103                    ERROR   103             ;THOUGH CPU LEVEL WAS LESS THAN
                          ;THE RK11 LEVEL (5), RK11 DID NOT
                          ;INTERRUPT
4014
4015
4016 015116 005010                    25:     CLR     DR0           ;CLEAR RKCS
4017 015120 062702 177740          ADD     #-40,R2         ;DECREASE THE PRIORITY LEVEL (FOR
                          ;CPU) BY 1
4018
4019 015124 005301                    DEC     R1              ;CPU WILL B AT THIS LEVEL
4020 015126 001344                    BNE     1$              ;LUP BAK & CHK FOR THIS BR LEVEL.
4021
4022 015130 012777 004526 164244    MOV     #BADINT,DRKVEC ;DONE WITH CHKING FOR ALL LEVELS.
4023
4024 015136 012746 000340          MOV     #340, -(SP)     ;RESTORE UNEXPECTED RK11 INTERRUPT
4025 015142 012746 015150          MOV     #64$, -(SP)    ;VECTOR
4026 015146 000002                    RTI
4027 015150                    645:
4028 015150 000414                    BR      TST41           ;;EXIT, TO NXT TST
4029
4030 015152 022626                    35:     CMP     (SP)+, (SP)+ ;RESTORE STACK POINTER
4031 015154 012777 004526 164220    MOV     #BADINT,DRKVEC ;RESTORE UNEXPECTED RK11 INTERRUPT
4032
4033 015162 020203                    CMP     R2,R3           ;VECTOR
4034 015164 003754                    BLE     2$              ;IF THIS INTERRUPT OCCURED WHEN
                          ;CPU LEVEL WAS LESS THAN THE
                          ;RK11 PRIORITY LEVEL (5) THEN IT IS
                          ;OK. IF NOT SO, ERROR
4035
4036
4037 015166 010137 001162          MOV     R1,$REG0       ;GET CPU BR LEVEL
4038 015172 011037 001164          MOV     DR0,$REG1     ;GET RKCS
4039 015176 104104                    ERROR   104             ;RK11 INTERRUPTED WHEN THE CPU
                          ;LEVEL (AS POINTED BY R1) WAS
                          ;HIGHER OR SAME AS THE RK11
                          ;LEVEL (5)
4040
4041
4042

```

```

4073 015200 000746 BR 25 :GO BACK & CHY THE NXT LEVEL
4074
4075 :*****
4076 :*TEST 41 SIMULATE & CHECK 'OVR' ERROR
4077 :*THIS TEST SIMULATES OVERRUN ERROR AND CHECKS IF THE OVR
4078 :*BIT IN RKER GETS SET. THEN IT IS CLEARED USING CNTRL RESET
4079 :*& CHECKED THAT IT WAS CLEARED. OVR CONDITION IS SIMULATED
4080 :*BY TRYING TO READ 401(OCTAL) WORDS FROM LAST CYLINDER(312),
4081 :*LAST SECTOR (13), SURFACE 1.
4082 :*****
4083 †S*41: SCOPE
4084 015202 000004 :GO DO CONTROL RESET
4085 015204 104413 :THIS IS A CALL FOR THE 'CNTRL-
4086 :RESET' ROUTINE. A CONTROL RESET IS
4087 :ISSUED AND AFTER A CERTAIN TIME
4088 :IF THE 'CNTRL RDY' DOES NOT SET
4089 :AN ERROR IS REPORTED. NOTE THAT
4090 :THE PC IN ERROR MESSAGE IS THE
4091 :PC WHERE 'CNT.RESET' IS LOCATED.
4092 :THIS IS A VERY BASIC ERRS IF IT
4093 :OCCURS GO BACK TO TEST 10
4094 :CHECK IF SIM IS SET, IF
4095 :SET, DO DRIVE RESET TO CLR IT
4096 :GET ADRES OF DRIVE
4097 :SET BITS FOR LAST CYLINDER (312),
4098 :SUR 1, LAST SECTOR (13)
4099 :READ 401 WORDS
4100 :INTO THIS MEMORY BUFFER
4101 :FROM THIS DSK ADRES, LAST CYL.
4102 :LAS. SEC, SURFACE 1
4103 :READ, GO
4104
4105 015206 104421 TST.SIN
4106
4107 015210 013701 001350 MOV DRIVAD,R1
4108 015214 052701 014533 BIS #14533,R1
4109
4110 015220 012777 177377 164106 MOV #401,DRKWC
4111 015226 012777 033240 164102 MOV #OUTBUF,DRKBA
4112 015234 010177 164100 MOV R1,DRKDA
4113
4114 015240 012777 000005 164064 MOV #5,DRKCS
4115
4116 015246 005002 CLR R2
4117 015250 105777 164056 :S: TSTB DRKCS :DID CNTRL RDY SET?
4118 015254 100410 BMI 25 :YES, BRANCH
4119 015256 005202 INC R2 :NO, WAIT FOR IT
4120 015260 001373 BNE 15 :IF WAITED LONG, REPORT ERROR MESSAGE BECAUSE
4121 :OVR SHOULD HAVE SET HE CAUSING
4122 :CNTRL RDY TO SET BY NOW
4123
4124 015262 017737 164046 001166 MOV DRKWC,$REG2
4125 015270 004737 020716 JSR PC,GT2RG :GO, GET RKCS, ER
4126 015274 104002 ERROR 2 :CNTRL RDY DID NOT SET AFTER DOING
4127 :AN OVR READ. HE SHOULD HAVE OCCURED
4128 :SETTING CNTRL RDY (HE BECAUSE OF
4129 :OVR CONDITIONS)
4130 :DID OVR BIT SET IN RKER?
4131
4132 015276 032777 040000 164024 25: BIT #40000,DRKER
4133 015304 001006 BNE 35
4134 015306 004737 020716 JSR PC,GT2RG :GET RKCS, ER
4135 015312 012737 040000 001166 MOV #40000,$REG2 :THIS BIT (OVR) DID NOT SET.
4136 015320 104105 ERROR 105 :OVR ERROR BIT DID NOT SET IN RKER
4137 :ON SIMULATING OVR CONDITIONS
4138 :DID HE & ERR SET WHEN OVR SET IN RKER?
4139 015322 022777 140204 164002 35: CMP #140204,DRKCS :YES, BRANCH
4140 015330 001403 BEQ 45 :GET RKCS, ER
4141 015332 004737 020716 JSR PC,GT2RG :HE OR ERR BIT DID NOT SET IN RKCS WHEN
4142 015336 104106 ERROR 106 :AN OVR ERROR WAS SIMULATED
4143

```

```

4099
4100 015340 104413 4S: CNT.RESET ;CLEAR OVR, ERR, HE BITS
4101 ;GO, DO CONTROL RESET
4102 ;THIS IS A CALL FOR THE 'CNTL-
4103 ;RESET' ROUTINE. A CONTROL RESET IS
4104 ;ISSUED AND AFTER A CERTAIN TIME
4105 ;IF THE 'CNTRL RDY' DOES NOT SET
4106 ;AN ERROR IS REPORTED. NOTE THAT
4107 ;THE PC IN ERROR MESSAGE IS THE
4108 ;PC WHERE 'CNT.RESET' IS LOCATED.
4109 ;THIS IS A VERY BASIC ERR& IF IT
4110 ;OCCURS GO BACK TO TEST 10
4111 015342 004737 021264 JSR PC,CKKECLR ;CHECK IF 'O.R' BIT WAS CLEARED BY
4112 015346 104102 ERROR 102 ;CON.RESET, IF NOT RETURN HERE.
4113 ;CNTRL RESET DID NOT CLEAR OVR
4114 015350 004737 021310 5S: JSR PC,CHKCLR ;BIT IN RKER
4115 015354 104102 ERROR 102 ;CHECK IF 'ERR' & 'HE' BIT GOT CLEARED BY
4116 015356 004737 021412 6S: JSR PC,DRESET ;CON.RESET, IF NOT RETURN HERE.
4117 015362 104026 ERROR 26 ;CNTRL RESET DID NOT CLEAR
4118 ;HE OR ERR BIT IN RKCS.
4119 ;GO DO DRIVE RESET
4120 ;R/W/S RDY DIDN'T SET
4121 ;AFTER THE ABOVE DRIVE RESET
4122
4123 ::*****
4124 *TEST 42 SIMULATE & CHECK PGE ERROR
4125 ;*THIS TEST SIMULATES 'PROGRAMMING ERROR' & CHECKS IF IT IS
4126 ;*DETECTED BY PGE BIT IN RKER. THEN A CNTRL RESET IS DONE &
4127 ;*IT IS CHECKED IF PGE BIT WAS CLEARED. IT IS ALSO CHECKED IF
4128 ;*THE SETTING & CLEARING OF PGE BIT SETS & CLEARS HE, ERR
4129 ;*BITS IN RKCS.
4130 ::*****
4131 015364 000004 *ST42: SCOPE
4132 01E366 104413 CNT.RESET ;GO, DO CONTROL RESET
4133 ;THIS IS A CALL FOR THE 'CNTRL-
4134 ;RESET' ROUTINE. A CONTROL RESET IS
4135 ;ISSUED AND AFTER A CERTAIN TIME
4136 ;IF THE 'CNTRL RDY' DOES NOT SET
4137 ;AN ERROR IS REPORTED. NOTE THAT
4138 ;THE PC IN ERROR MESSAGE IS THE
4139 ;PC WHERE 'CNT.RESET' IS LOCATED.
4140 ;THIS IS A VERY BASIC ERR& IF IT
4141 ;OCCURS GO BACK TO TEST 10
4142 015370 104421 TST.SIN ;GO CHECK IF SIN IS SET, IF
4143 015372 013701 001330 MOV RKER,R1 ;SET DO DRIVE RESET TO CLR IT
4144 015376 013777 001350 163734 MOV DRIVAD,DRKDA ;ADRES THE DRIVE, CYLINDER 0
4145
4146 015404 012777 002011 163720 *OV #2011,DRKCS ;SEEK, GO WITH FMT SET
4147 ;THIS IS A PGE SIMULATION
4148 015412 104414 CNT.RDY ;THIS IS A CALL FOR 'CN.RDY'
4149 ;ROUTINE WHICH WAITS FOR CNT
4150 ;RDY TO SET. IF CNTRL RDY DOES
4151 ;NOT SET WITHIN 883 MS/ 11-20
4152 ;(176 MS FOR 11-45 WITH BIPOLAR)
4153 ;AN ERROR IS REPORTED
4154 015414 032711 004000 BIT #4000,DR1 ;DID PGE BIT IN RKER SET?

```

```

4155 015420 001006 BNE 15 :YES, BRANCH
4156 015422 012737 004000 001166 MOV 84000, $REG2 :THIS BIT IN RKER 'PGE' DID NOT SET
4157 015430 004737 020716 JSR PC, GT2RG :GO GET RKCS, ER FOR MESSAGE
4158 015434 104105 ERROR 105 :PGE BIT DID NOT SET IN RKER
4159 :ON SIMULATION OF PGE CONDITION
4160 :$REG2 CONTAINS THE RKER BIT (PGE).
4161 :THAT SHOULD HAVE SET.
4162 015436 022777 142210 163666 15: CMP 8142210, 2RKCS :DID HE & ERR BITS SET?
4163 015444 001403 BEQ 25 :YES, BRANCH
4164 015446 004737 020716 JSR PC, GT2RG :GO, GET RKCS, ER
4165 015452 104106 ERROR 106 :HE OR ERR BIT DID NOT SET WHEN
4166 :PGE SET IN RKER.
4167 :CLEAR PGE, HE, ERR BITS
4168 015454 104413 25: CNT.RESET :GO, DO CONTROL RESET
4169 :THIS IS A CALL FOR THE 'CNTRL-
4170 :RESET' ROUTINE. A CONTROL RESET IS
4171 :ISSUED AND AFTER A CERTAIN TIME
4172 :IF THE 'CNTRL RDY' DOES NOT SET
4173 :AN ERROR IS REPORTED. NOTE THAT
4174 :THE PC IN ERROR MESSAGE IS THE
4175 :PC WHERE 'CNT.RESET' IS LOCATED.
4176 :THIS IS A VERY BASIC ERR& IF IT
4177 :OCCURS GO BACK TO TEST 10
4178 015456 004737 021264 JSR PC, CHKECLR :CHECK IF 'PGE' BIT GOT CLEARED BY
4179 :CONTROL RESET, IF NOT RETURN HERE.
4180 015462 104102 ERROR 102 :CNTRL RESET DID NOT CLEAR
4181 :PGE BIT IN RKER
4182 015464 004737 021310 35: JSR PC, CHKCLR :CHECK IF 'ERR' BIT GOT CLEARED BY
4183 :CON.RESET, IF NOT RETURN HERE.
4184 015470 104102 ERROR 102 :RKCS BITS HE OR ERR DID NOT
4185 :GET CLEARED BY CNTRL RESET
4186
4187 :*****
4188 :*TEST 43 SIMULATE & CHECK NXM ERROR
4189 :*THIS TEST SIMULATES A NON-EXISTENT MEMORY ERROR (NXM) AND
4190 :*CHECKS IF IT IS DETECTED BY NXM BIT OR RKER. LOCATION 760000
4191 :*IS REFERENCED & IT HAPPENS TO BE A NON EXISTENT LOCATION
4192 :*(FOR DIAGNOSTIC PURPOSES LIKE THIS). IT IS ALSO CHECKED
4193 :*IF HE & ERR BITS ALSO SET AND ALL 3 BITS CAN BE CLEARED
4194 :* BY CONTROL RESET.
4195 :*****
4196 015472 000004 TST43: SCOPE
4197 015474 104413 CNT.RESET :GO, DO CONTROL RESET
4198 :THIS IS A CALL FOR THE 'CNTRL-
4199 :RESET' ROUTINE. A CONTROL RESET IS
4200 :ISSUED AND AFTER A CERTAIN TIME
4201 :IF THE 'CNTRL RDY' DOES NOT SET
4202 :AN ERROR IS REPORTED. NOTE THAT
4203 :THE PC IN ERROR MESSAGE IS THE
4204 :PC WHERE 'CNT.RESET' IS LOCATED.
4205 :THIS IS A VERY BASIC ERR& IF IT
4206 :OCCURS GO BACK TO TEST 10
4207 015476 104421 TST.SIN :GO CHECK IF SIN IS SET
4208 :IF SET DO DRIVE RESET TO CLR IT
4209 015500 005002 CLR R2
4210 015502 013700 001332 MOV RKCS, R0

```

```

4211 015506 012777 177777 163620      MOV      #1,DRKWC      ;WRITE CHECK 1 WORD
4212 015514 012777 160000 163614      MOV      #160000,DRKBA ;AT THIS BUS ADRES
4213 015522 013777 001350 163610      MOV      DRIVAD,DRKDA  ;WITH THIS DISK ADRES (CYL 0, SEC 0)
4214 015530 012710 000067          MOV      #67,DRD      ;WRT CHK, GO, MEX BITS SET
4215 015534 105777          15:  TSTB    DRKCS        ;DID CNTRL RDY SET AS A RESULT OF HE?
4216 015540 100410          BMI     2$           ;YES, BRANCH
4217 015542 005202          INC     R2           ;WAITED LONG ENOUGH?
4218 015544 001373          BNE     1$           ;IF NOT LUP BAK & WAIT
4219 015546 004737 020716          JSR     PC,GT2RG     ;GET RKCS, ER
4220 015552 017737 163556 001166      MOV      DRKWC,$REG2  ;GET RKWC
4221 015560 104113          ERROR   113         ;CNTRL RDY DID NOT SET ON DOING
4222                                     ;A WRT CHK WITH A NXM LOCATION.
4223                                     ;THIS HE SHOULD HAVE SET THE
4224                                     ;CNTRL RDY BIT IN RKCS
4225 015562 032777 002000 163540 25:  BIT     #2000,DRKER   ;DID NXM BIT IN RKER SET?
4226 015570 001006          BNE     3$           ;YES, BRANCH
4227 015572 004737 020716          JSR     PC,GT2RG     ;GO GET RKCS, RKER
4228 015576 012737 002000 001166      MOV      #2000,$REG2 ;THIS BIT (NXM) DID NOT SET IN RKER
4229 015604 104105          ERROR   105         ;NXM BIT DID NOT SET IN RKER ON
4230                                     ;SIMULATING NXM CONDITION.
4231 015606 022710 140266          35:  CMP     #140266,DRD ;DID HE & ERR BIT SET?
4232 015612 001403          BEQ     4$           ;YES, BRANCH
4233 015614 004737 020716          JSR     PC,GT2RG     ;GO, GET RKCS, RKER
4234 015620 104106          ERROR   106         ;HE OR ERR BIT DID NOT SET WHEN
4235                                     ;NXM ERROR WAS SIMULATED
4236                                     ;CLEAR NXM, HE, ERR BITS
4237 015622 104413          45:  CNT.RESET        ;GO, DO CONTROL RESET
4238                                     ;THIS IS A CALL FOR THE 'CNTPL-
4239                                     ;RESET' ROUTINE. A CONTROL RESET IS
4240                                     ;ISSUED AND AFTER A CERTAIN TIME
4241                                     ;IF THE 'CNTRL RDY' DOES NOT SET
4242                                     ;AN ERROR IS REPORTED. NOTE THAT
4243                                     ;THE PC IN ERROR MESSAGE IS THE
4244                                     ;PC WHERE 'CNT.RESET' IS LOCATED.
4245                                     ;THIS IS A VERY BASIC ERRS IF IT
4246                                     ;OCCURS GO BACK TO TEST 10
4247 015624 004737 021264          JSR     PC,CHKECLR   ;CHECK IF 'NXM' BIT GOT C:LEARED BY
4248                                     ;CON.RESET, IF NOT RETURN HERE.
4249 015630 104102          ERROR   102         ;CNTRL RESET DID NOT CLEAR
4250                                     ;NXM BIT IN RKER
4251 015632 004737 021310          55:  JSR     PC,CHKCLR  ;CHECK IF 'HE' & 'ERR' BITS GOT CLEARED
4252                                     ;BY CON.RESET, IF NOT RETURN HERE.
4253 015636 104102          ERROR   102         ;CNTRL RESET DID NOT CLEAR
4254                                     ;HE OR ERR BIT IN RKCS.
4255 015640 004737 021344          65:  JSR     PC,TSTRWS  ;GO CHECK IF R/W/S RDY IS SET &
4256                                     ;WAIT FOR IT. SKIP ERROR IF IT IS SET
4257 015644 104016          ERROR   16          ;R/W/S RDY IS NOT SET
4258
4259
4260 ;*****
4261 ;*TEST 44 SIMULATE & CHECK NXD ERROR
4262 ;*THIS TEST SIMULATES NON-EXISTENT DISK ERROR & CHECKS IF
4263 ;*IT IS DETECTED BY NXD BIT OF RKER. IF ALL EIGHT ARE PRESENT
4264 ;*THEN THIS TEST IS ABORTED FOR SIMULATION CANNOT BE DONE.
4265 ;*****
4266 015646 000004          TST44: SCOPE
4267 015650 104413          CNT.RESET          ;GO, DO CONTROL RESET

```


F08

4267
4268
4269
4270
4271
4272
4273
4274
4275
4276
4277
4278
4279
4280
4281
4282
4283
4284
4285
4286
4287
4288
4289
4290
4291
4292
4293
4294
4295
4296
4297
4298
4299
4300
4301
4302
4303
4304
4305
4306
4307
4308
4309
4310
4311
4312
4313
4314
4315
4316
4317
4318
4319
4320
4321
4322

015652 104421
015654 013700 001332
015660 012702 160000
015664 010277 163450
015670 104417 000001
015674 105777 163426
015700 100004
015702 062702 160000
015706 001366
015710 000435
015712 012710 000015
015716 104417 000106
015722 105777 163402
015726 001006
015730 004737 020716
015734 012737 000200
015742 104105
022710 140214
001403
004737 020716
104106
015760 104413

15:
25:
35:
45:

TST.SIN
MOV RKCS,R0
MOV #160000,R2
15: MOV R2,DRKDA
DELAY .1
TSTB DRKDS
BPL 25
ADD #-20000,R2
BNE 15
BR TST45
25: MOV #15,DR0
DELAY ,106
TSTB DRKER
BNE 35
JSR PC,GT2RG
MOV #200,\$REG2
ERROR 105
35: CMP #140214,DR0
BEQ 45
JSR PC,GT2RG
ERROR 106
45: CNT.RESET

:THIS IS A CALL FOR THE 'CNTRL-
:RESET' ROUTINE. A CONTROL RESET IS
:ISSUED AND AFTER A CERTAIN TIME
:IF THE 'CNTRL RDY' DOES NOT SET
:AN ERROR IS REPORTED. NOTE THAT
:THE PC IN ERROR MESSAGE IS THE
:PC WHERE 'CNT.RESET' IS LOCATED.
:THIS IS A VERY BASIC ERR& IF IT
:OCCURS GO BACK TO TEST 10
:CHECK IF SIN IS SET, IF SET
:DO DRV RESET TO CLR IT
:ADRES DRIVE 7 TO FIND
:IF IT IS PRESENT
:ADRES DRIVE # POINTED TO BY R2
:TIME DELAY, 7.5 US ON 11/20,
:1.5 US ON 11/45
:IS IT PRESENT?
:NO, BRANCH
:ADRES THE NXT DRIVE IN THE
:REVERSE ORDER. I.E. 7,6,
:LUP BAK & TRY TO FIND A DRIVE
:THAT'S NOT PRESENT
:EXIT TO THE NXT TST
:DRIVE RESE , ON A NX DRIVE
:TIME DELAY, 525 US ON 11/20
:105 US ON 11/45
:DID NXD BIT IN RKER SET?
:YES, BRANCH
:GET RKCS, RKER
:THIS BIT (NXD) IN RKER DID NOT SET
:NXD BIT DID NOT SET ON TRYING
:TO PERFORM A FUNCTION ON A
:NON-EXISTENT DRIVE
:CHECK THAT THE JUMPER CARD CONTAINING
:JUMPERS FOR DRIVES PRESENT IS PROPERLY
:CONNECTED
:NOTE THAT ON RK11C IF A DRIVE
:IS OFFLINE BUT PHYSICALLY PRESENT
:(IE. DRY IS CLR FOR THAT DRIVE)
:& A FUNCTION IS INITIATED ON THAT
:DRIVE NXD WON'T SET, BUT U WILL
:GET ONLY A DRE,HE & ERR.
:DID HE & ERR SET WHEN NXD SET?
:YES BRANCH
:HE OR ERR BIT DID NOT SET
:WHEN NXD WAS SIMULATED
:CLEAR NXD, HE, ERR BITS
:GO, DO CONTROL RESET
:THIS IS A CALL FOR THE 'CNTRL-
:RESET' ROUTINE. A CONTROL RESET IS
:ISSUED AND AFTER A CERTAIN TIME
:IF THE 'CNTRL RDY' DOES NOT SET
:AN ERROR IS REPORTED. NOTE THAT
:THE PC IN ERROR MESSAGE IS THE

```

4323                                     :PC WHERE 'CNT.RESET' IS LOCATED.
4324                                     :THIS IS A VERY BASIC ERR& IF IT
4325                                     :OCCURS GO BACK TO TEST 10
4326 015762 004737 021264                JSR    PC,CHKECLR                :CHECK IF 'NXC' BIT WAS CLEARED BY
4327                                     :CON.RESET. IF NOT, RETURN HERE.
4328 015766 104102                        ERROR  102                :CNTRL RESET DID NOT CLEAR
4329                                     :NXC BIT IN RKER
4330 015770 004737 021310                55:   JSR    PC,CHKCCLR                :CHECK IF 'HE' & 'ERR' BITS WERE CLEARED
4331                                     :BY CON.RESET. IF NOT RETURN HERE.
4332 015774 104102                        ERROR  102                :CNTRL RESET DID NOT CLEAR
4333                                     :HE OR ERR BIT IN RKCS
4334 015776 004737 021344                JSR    PC,TSTRWS                :GO CHECK & WAIT FOR R/W/S RDY
4335                                     :TO SET. IF SET SKIP ERROR
4336 016002 104016                        ERROR  16                :R/W/S SHOULD BE SET. IT'S
4337                                     :NOT

```

```

4338                                     :*****
4339                                     :*TEST 45      SIMULATE & CHECK NXC ERROR
4340                                     :*THIS TEST SIMULATES THE NON-EXISTENT CYLINDER ERROR & CHECKS
4341                                     :*IF IT IS DETECTED BY THE NXC BIT OF RKER, HE & ERR BITS
4342                                     :*OF RKCS. IT IS CHECKED IF THEY CAN BE CLEARED BY CONTROL
4343                                     :*RESET
4344                                     :*****

```

```

4345                                     :*****
4346 016004 000004                        †ST45: SCOPE
4347 016006 013700 001332                MOV    RKCS,R0
4348 016012 012737 177773 001362        25:   MOV    #-5,COUNT                ;ALLOW 'ERROR 133' ONLY 5 TIMES
4349 016020 013702 001350                MOV    DRIVAD,R2                ;GET ADRES OF DRIVE
4350 016024 052702 014540                BIS    #14540,R2                ;SET BITS FOR CYL 313
4351 016030 012737 016036 001110        MOV    #35,$LPERR                ;SET RETURN ADRES FOR
4352                                     :LUPING ON EROR (SW9)
4353 016036 104413                        35:   CNT.RESET                ;GO, DO CONTROL RESET
4354                                     :THIS IS A CALL FOR THE 'CNTRL-
4355                                     :RESET' ROUTINE. A CONTROL RESET IS
4356                                     :ISSUED AND AFTER A CERTAIN TIME
4357                                     :IF THE 'CNTRL RDY' DOES NOT SET
4358                                     :AN ERROR IS REPORTED. NOTE THAT
4359                                     :THE PC IN ERROR MESSAGE IS THE
4360                                     :PC WHERE 'CNT.RESET' IS LOCATED.
4361                                     :THIS IS A VERY BASIC ERR& IF IT
4362                                     :OCCURS GO BACK TO TEST 10
4363 016040 004737 021344                JSR    PC,TSTRWS                :GO CHECK & WAIT FOR R/W/S RDY
4364                                     :TO SET. IF SET SKIP ERROR BELOW
4365 016044 104016                        ERROR  16                :R/W/S RDY IS NOT SET
4366 016046 104421                        TST.SIN                :CHECK IF SIN IS SET, IF SET
4367                                     :DO DRIVE RESET TO CLR IT
4368 016050 010277 163264                MOV    R2,DRKDA                :ADRES DRIVE, NXC CYLINDER
4369 016054 012710 000011                MOV    #11,DR0                :SEEK, GO TO NXC CYL
4370 016060 104412                        CHKCRDY                :GO CHECK IF CONTROL RDY IS SET
4371                                     :IF SO, SKIP THE EROR MESSAGE.
4372 016062 104021                        ERROR  21                :SEEK WAS TRIED TO A NON EXISTENT
4373                                     :CYLINDER, NXC SHOULD HAVE OCCURED
4374                                     :SETTING CNTRL RDY. BUT CNTRL RDY
4375                                     :DID NOT SET.
4376 016064 032777 000100 163236        95:   BIT    #100,DRKER                :DID NXC SET?
4377 016072 001020                        BNE    45                    :YES, BRANCH
4378 016074 004737 020716                JSR    PC,GT2RG                :GO GET RKCS, ER

```


J08

MAINDEC-11-DZRKK-D MACY11 27(1006) 04-OCT-76 16:06 PAGE 83
DZRKKD.P11 22-SEP-76 08:47 T46 SIMULATE & CHECK NXS ERROR

SEQ 0100

4491 016356 004737 021310
4492
4493 016362 104102
4494
4495
4496
4497
4498
4499
4500
4501
4502
4503
4504
4505 016364 000004
4506 016366 013700 001332
4507 016372 104413
4508
4509
4510
4511
4512
4513
4514
4515
4516
4517 016374 104421
4518
4519 016376 012701 033240
4520 016402 012702 177400
4521 016406 012703 177777
4522
4523
4524 016412 062703 177401
4525 016416 010321
4526 016420 005202
4527 016422 001373
4528
4529 016424 012737 170007 033256
4530
4531
4532 016432 012777 177400 162674
4533 016440 012777 033240 162670
4534 016446 013777 001350 162664
4535 016454 012710 000007
4536
4537 016460 104412
4538
4539 016462 104065
4540
4541 016464 032777 000001 162636 35:
4542 016472 001006
4543 016474 004737 020716
4544 016500 012737 000001 001166
4545 016506 104105
4546

45: JSR PC,CHKCLR ;CHECL IF 'HE' & 'ERR' BITS WERE CLEARED
;BY CON RESET. IF NOT, RETURN HERE.
ERROR 102 ;RKCS BITS ERR OR HE WERE NO
;CLEARED BY CNTRL RESET

;*****
;*TEST 47 SIMULATE & CHECK WCE
;*THIS TEST SIMULATES A WRITE CHECK ERROR AND CHECKS THAT IT
;*IS DETECTED BY WCE BIT OF RKER. FOR COMPARISON IT USES
;*THE 256 WORDS DATA BLOCK WRITTEN ON SECTOR 0, CYLINDER 0
;*IN A PREVIOUS TEST. THIS BLOCK IS COMPARED WITH THE 256 WORDS
;*MEMORY BUFFER STARTING AT 'OUTBUF'. WCE IS SIMULATED BY
;*DROPPING A BIT FROM ONE OF THE WORDS IN THE MEMORY BUFFER.
;*****
TST47: SCOPE
MOV RKCS,R0
CNT.RESET ;GO, DO CONTROL RESET
;THIS IS A CALL FOR THE 'CNTRL-
;RESET' ROUTINE. A CONTROL RESET IS
;ISSUED AND AFTER A CERTAIN TIME
;IF THE 'CNTRL RDY' DOES NOT SET
;AN ERROR IS REPORTED. NOTE THAT
;THE PC IN ERROR MESSAGE IS THE
;PC WHERE 'CNT.RESET' IS LOCATED.
;THIS IS A VERY BASIC ERR& IF IT
;OCCURS GO BACK TO TEST 10
;CHECK IF SIN IS SET, IF
;SET DO DRV-RESET TO CLR IT
;THIS CODE SETS UP A MEMORY
;BUFFER OF 256 WORDS STARTING
;AT OUTBUF
;FIRST WORD 177400
;SECOND 177001

15: ADD #177401,R3
MOV R3,(R1)+ ;LAST WORD 000377
INC R2 ;HAVE U GENERATED ALL 256 WORDS?
BNE 15 ;IF NOT, LUP BAK & GENERATE NXT

MOV #170007,OUTBUF+16 ;WCE WILL B SIMULATED BY DROPPING A
;BIT IN THE EIGHTH WORD WHICH IS
;SUPPOSED TO B 174007
MOV #-400,ARKWC ;WRT CHK 400 WORDS
MOV #OUTBUF,ARKBA ;STARTING AT THIS BUS ADRES
MOV DRIVAD,ARKDA ;WITH THIS DISK ADRES, SEC 0, CYL 0
MOV #7,ARO ;WRT CHK, GO

CHKCRDY ;GO CHECK IF CONTROL RDY IS SET
;IF SO, SKIP THE EROR MESSAGE.
ERROR 65 ;CNTRL RDY DID NOT SET
;AFTER WRT CHK
35: BIT #1,ARKER ;DID WCE BIT SET?
BNE 45
JSR PC,GT2RG ;GO, GET RKCS, RKER
MOV #1,\$REG2 ;THIS BIT (WCE) DID NOT SET
ERROR 105 ;WCE DID NOT SET ON SIMULATING
;WCE CONDITIONS

K08

MAINDEC-11-DZRKK-D MACY11 27(1006) 04-OCT-76 16:06 PAGE 94
 CZRKKD.P11 22-SEP-76 08:47 T47 SIMULATE & CHECK WCE

SEQ 0101

```

4547 016510 022710 100206 45:  CMP      #100206,ARO      ;IS RKCS CORRECT?
4548 016514 001403          BEQ      SS              ;YES, BRANCH
4549 016516 004737 020716 JSR      PC,GT2RG       ;GO, GET RKCS, RKER
4550 016522 104106          ERROR    106           ;HE OR ERR BIT DID NOT SET WHEN
4551                                ;WCE WAS SIMULATED
4552 016524 104413          55:  CNT.RESET          ;CNTRL RESET
4553 016526 004737 021264 JSR      PC,CHKECLR     ;WAS 'WCE' BIT CLEARED?
4554                                ;IF NOT, RETURN HERE.
4555 016532 104102          ERROR    102           ;CNTRL RESET DID NOT CLEAR
4556                                ;WCE BIT IN RKER
4557 016534 004737 021310 65:  JSR      PC,CHKCCLR    ;CHECK IF 'ERR' BIT WAS CLEARED. IF
4558                                ;NOT RETURN HEPE.
4559 016540 104102          ERROR    102           ;CNTRL RESET DID NOT CLEAR
4560                                ;RKCS
4561
4562                                ;*****
4563                                ;*TEST 50      CHECK THAT SSE STOPS ALL CONTROL ACTION ON SOFT ERROR
4564                                ;*THIS TEST CHECKS THAT WHEN 'STOP ON SOFT ERROR' BIT IS SET IN
4565                                ;*RKCS AND A SOFT ERROR IS ENCOUNTERED ALL CONTROL ACTION WILL
4566                                ;*STOP AT THE END OF THE CURRENT SECTOR IF IDE BIT IS CLEAR.
4567                                ;*SOFT ERROR IS SIMULATED BY A WCE AS IN THE PREVIOUS
4568                                ;*TEST. THE PREVIOUS TEST & THE TEST WHICH WRITES DATA
4569                                ;*BLOCK ON CYLINDER 0, SECTOR 0, SHOULD BE DONE PRIOR
4570                                ;*TO THIS TEST. A TWO SECTOR 'WRT CHK' WILL BE DONE,
4571                                ;*CONTROL ACTION SHOULD STOP AFTER THE FIRST SECTOR DURING
4572                                ;*WHICH A SOFT ERROR IS SIMULATED.
4573                                ;*****
4574 016542 000004          †TST50: SCOPE
4575 016544 104413          CNT.RESET              ;GO, DO CONTROL RESET
4576                                ;THIS IS A CALL FOR THE 'CNTRL-
4577                                ;RESET' ROUTINE. A CONTROL RESET IS
4578                                ;ISSUED AND AFTER A CERTAIN TIME
4579                                ;IF THE 'CNTRL RDY' DOES NOT SET
4580                                ;AN ERROR IS REPORTED. NOTE THAT
4581                                ;THE PC IN ERROR MESSAGE IS THE
4582                                ;PC WHERE 'CNT.RESET' IS LOCATED.
4583                                ;THIS IS A VERY BASIC ERR& IF IT
4584                                ;OCCURS GO BACK TO TEST 10
4585 016546 104421          TST.SIN                ;CHECK IF SIN IS SET, IF
4586                                ;SET DO DRIVE RESET TO CLR IT
4587 016550 013700 001332          MOV      RKCS,RO
4588 016554 012737 170007 033256 MOV      #170007,OUTBUF+16 ;WCE IS SIMULATED BY DROPPING A BIT
4589                                ;IN THE EIGHTH WORD (WHICH IS ACTUALLY
4590                                ;174007). NOTE THAT 256 WORD MEMORY
4591                                ;BUFFER IS CREATED IN THE PREVIOUS TEST.
4592 016562 013701 001350          MOV      DRIVAD,R1
4593 016566 012777 177000 162540 MOV      #-1000,ARKWC    ;WRT CHK 1000 (OCTAL) WORDS, 2 SECTORS
4594 016574 012777 033240 162534 MOV      #OUTBUF,ARKBA  ;FROM THIS BUS ADRES
4595 016602 010177 162532          MOV      R1,ARKDA      ;WITH THIS DISK ADRES, SEC 0, CYL 0
4596 016606 012710 000407          MOV      #407,ARO     ;WRT CHK, GO, SSE
4597 016612 104412          CHKCRDY              ;GO CHECK IF CONTROL RDY IS SET
4598                                ;IF SO, SKIP THE EROR MESSAGE.
4599 016614 104065          ERROR    65           ;CNTRL RDY DID NOT SET AFTER WRT
4600                                ;CHK. A SOFT ERROR (WCE) IN
4601                                ;SECTOR 0 SHOULD HAVE STOPPED
4602                                ;ALL CONTROL ACTION.

```

```

4603 016616 022777 000001 162504 25:  CMP      #1, RAKER      ;CHECK ONLY 'WCE' BIT SHOULD
4604                                     ;BE SET?
4605 016624 001407                                     ;YES. BRANCH
4606 016626 012737 000001 001162  MOV      #1, $REG0    ;GET EXPCTD RKER
4607 016634 017737 162470 001164  MOV      RAKER, $REG1 ;GET RKER RECVD
4608 016642 104107                                     ;ONLY BIT 'WCE' OF RKER
4609                                     ;SHOULD BE SET (WCE WAS
4610                                     ;SIMULATED ABOVE). ERROR
4611                                     ;IF IT'S NOT
4612 016644 005201 35:  INC      R1          ;CHECK THAT RKDA INCREMENTED BY
4613 016646 029177 162466  CMP      R1, RAKDA    ;1 SECTOR ONLY IMPLYING THAT
4614                                     ;CNTRL ACTION DID STOP AFTER
4615                                     ;SOFT ERROR IN SECTOR 0
4616 016652 001406  BEQ      TST51       ;YES. EXIT
4617 016654 010137 001162  MOV      R1, $REG0    ;GET EXPCTD RKDA
4618 016660 017737 162454 001164  MOV      RAKDA, $REG1 ;GET RAKDA RECVD
4619 016666 104070  ERROR    70         ;RKDA SHOULD HAVE INCRMNTD
4620                                     ;BY 1 SECTOR ONLY, IT DIDN'T.
4621                                     ;WCE WAS SIMULATED IN THE
4622                                     ;FIRST SECTOR & A WRT CHK
4623                                     ;OF 2 SECTORS WAS ISSUED.
4624                                     ;CONTROLLER SHOULD STOP AFTER
4625                                     ;DETECTING WCE IN THE FIRST
4626                                     ;SECTOR. HENCE RAKDA SHOULD
4627                                     ;INCREMENT BY 1 SECTOR ONLY
4628
4629
4630
4631 ;*****
4632 ;*TEST 51 CHECK THAT RK11 INTERRUPTS ON SOFT ERROR WHEN SSE & ICE ARE SET
4633 ;*THIS TEST CHECKS WHEN SSE BIT IS SET WITH IDE SET AND A SOFT
4634 ;*ERROR OCCURS. THEN ALL CONTROL ACTION WILL STOP AND A BUS
4635 ;*REQUEST (INTERRUPT) WILL OCCUR AT THE END OF THE CURRENT
4636 ;*SECTOR. SOFT ERROR IS SIMULATED BY WCE AS IN PREVIOUS
4637 ;*TEST. PREREQUISITES FOR THIS TEST ARE THE SAME AS THOSE
4638 ;*FOR THE PREVIOUS TEST.
4639 ;*****
4640 016670 000004  TST51:  SCOPE
4641 016672 104413  CNT.RESET ;GO. DO CONTROL RESET
4642                                     ;THIS IS A CALL FOR THE 'CNTRL-
4643                                     ;RESET' ROUTINE. A CONTROL RESET IS
4644                                     ;ISSUED AND AFTER A CERTAIN TIME
4645                                     ;IF THE 'CNTRL RDY' DOES NOT SET
4646                                     ;AN ERROR IS REPORTED. NOTE THAT
4647                                     ;THE PC IN ERROR MESSAGE IS THE
4648                                     ;PC WHERE 'CNT.RESET' IS LOCATED.
4649                                     ;THIS IS A VERY BASIC ERR& IF IT
4650                                     ;OCCURS GO BACK TO TEST 10
4651 016674 104421  TST.SIN ;CHECK IF SIN IS SET. IF
4652 016676 012737 170007 033256  MOV      #170007, OUTBUF+16 ;SET DO DRIVE RESET TO CLR IT
4653                                     ;WCE IS SIMULATED BY DROPPING A BIT
4654                                     ;IN THE EIGHTH WORD (WHICH IS 174007)
4655                                     ;NOTE THAT THE 256 WORD MEMORY
4656                                     ;BUFFER (STARTING AT OUTBUF) IS
4657 016704 013701 001350  MOV      DRIVAD, R1   ;CREATED IN A PREVIOUS TEST.
4658 016710 012777 177000 162416  MOV      #-1000, RAKWC ;WRT CHK 1000 (OCTAL) WORDS, 2 SECTORS

```

M08

MAINDEC-11-DZRKK-D MACY11 27(1006) 04-OCT-76 16:06 PAGE 86 SEQ 0103
 DZRKKD.P11 22-SEP-76 08:47 T51 CHECK THAT RK11 INTERRUPTS ON SOFT ERROR WHEN SSE & IDE ARE SET

4659	016716	012777	033240	162412	MOV #OUTBUF, @RKBA	; FROM THIS BUS ADRES
4660	016724	010177	162410		MOV R1, @RKDA	; WITH THIS DISK ADRES, SEC 0, CYL 0
4661	016730	013700	001402		MOV RKVEC, R0	
4662	016734	012720	016766		MOV #1\$, (R0)+	; SET UP INTERRUPT VECTOR FOR RK11
4663	016740	012710	000340		MOV #340, @R0	; SET PSW ON INTERRUPT
4664	016744	012777	000507	162360	MOV #507, @RKCS	; WRT CHK. GO. SSE, IDE SET
4665	016752	104420	177777		WAT. INT. 177777	; WAIT FOR INTERRUPT FROM RK11
4666						; TIME=485 MS FOR 11/20,
4667						; 97 MS FOR 11/45
4668	016756	004737	020716		JSR PC, GT2RG	; 11/05
4669	016762	104111			ERROR 111	; RK11 DID NOT INTERRUPT AFTER A SOFT
4670						; ERROR (SIMULATED) IN SECTOR 0
4671	016764	000417			BR 25	
4672						
4673	016766	022626		15:	CMP (SP)+, (SP)+	; RESTORE STACK POINTER (FROM RK11 INTRUPT,
4674	016770	022626			CMP (SP)+, (SP)+	; POP STACK (FROM WAT. INT)
4675	016772	012777	004526	162402	MOV #BADINT, @RKVEC	; RESTORE RK11 INTERRUPT VECTOR
4676						; ADRES FOR UNEXPECTED INTERRUPTS
4677	017000	005201			INC R1	
4678	017002	020177	162332		CMP R1, @RKDA	; CHECK THAT RKDA INCREMENTED
4679						; BY ONLY 1 SECTOR BEFORE INTERRUPT
4680						; OCCURRED
4681	017006	001406			BEQ 25	
4682	017010	010137	001162		MOV R1, \$REG0	; GET EXPCTD RKDA
4683	017014	017737	162320	001164	MOV @RKDA, \$REG1	; GET RKDA RECVD
4684	017022	104003			ERROR 3	; RKDA SHOULD HAVE INCREMENTED BY
4685						; 1 SECTOR ONLY, IF ALL CNTRL ACTION
4686						; HAD STOPPED AFTER SOFT ERROR
4687						; (SIMULATED) IN SECTOR 0. IT DID NCT.
4688	017024			25:		
4689	017024	012746	000340		MOV #340, -(SP)	
4690	017030	012746	017036		MOV #64\$, -(SP)	
4691	017034	000002			RTI	
4692	017036			64\$:		
4693	017036	005077	162270		CLR @RKCS	; CLEAR THE IDE BIT
4694						
4695						
4696						
4697						
4698						
4699						
4700						
4701						
4702						
4703						
4704						
4705	017042	000004				
4706	017044	013700	001332		†ST52: SCOPE	
4707	017050	012701	177774		MOV RKCS, R0	
4708	017054	005002			MOV #-4, R1	; SET UP THE COUNT
4709	017056	012737	017064	001110	CLR R2	; INITIALIZE MEX BITS TO B SET IN RKCS
4710					MOV #1\$, \$LPERR	; SET RETURN ADRES FOR
4711	017064	104417	000142			; LUPING ON EROR (SW9)
4712	017070	004737	021344		15: DELAY 142	; TIME DELAY
4713	017074	104016			JSR PC, TSTRWS	; WAIT FOR R/W/S RDY
4714	017076	104413			ERROR 16	; R/W/S RDY IS NOT SET
					CNT. RESET	; GO, DO CONTROL RESET


```

4715
4716
4717
4718
4719
4720
4721
4722
4723
4724 017100 010210
4725 017102 012777 177777 162224
4726 017110 013777 001350 162222
4727 017116 012777 177776 162212
4728
4729 017124 052710 000007
4730
4731
4732
4733 017130 104412
4734
4735 017132 104065
4736 017134 010205
4737 017136 062705 000020
4738 017142 042705 000100
4739 017146 011904
4740 017150 042704 177717
4741 017154 020504
4742 017156 001405
4743 017160 010537 001162
4744 017164 010437 001164
4745 017170 104112
4746
4747
4748
4749
4750 017172 017703 162132
4751 017176 010305
4752 017200 042703 003001
4753 017204 001410
4754 017206 042705 177776
4755 017212 010537 001162
4756 017216 017737 162106 001164
4757 017224 104107
4758
4759
4760 017226 062702 000020
4761 017232 005201
4762 017234 001313
4763
4764
4765
4766
4767
4768
4769
4770

```

```

MOV R2,DR0
MOV #-1,DRKWC
MOV DRIVAD,DRKDA
MOV #177776,DRKBA
BIS #7,DR0
CHKCRDY
ERROR 65
35: MOV R2,R5
ADD #20,R5
BIC #100,R5
MOV DR0,R4
BIC #177717,R4
CMP R5,R4
BEQ 45
MOV R5,$REG0
MOV R4,$REG1
ERROR 112
45: MOV DRKER,R3
MOV R3,R5
BIC #3001,R3
BEQ 55
BIC #177776,R5
MOV R5,$REG0
MOV DRKER,$REG1
ERROR 107
55: ADD #20,R2
INC R1
BNE 15

```

```

;THIS IS A CALL FOR THE 'CNTRL-
;RESET' ROUTINE. A CONTROL RESET IS
;ISSUED AND AFTER A CERTAIN TIME
;IF THE 'CNTRL RDY' DOES NOT SET
;AN ERROR IS REPORTED. NOTE THAT
;THE PC IN ERROR MESSAGE IS THE
;PC WHERE 'CNT.RESET' IS LOCATED.
;THIS IS A VERY BASIC ERR& IF IT
;OCCURS GO BACK TO TEST 10
;SET MEX BITS (AS IN R2) IN RKCS
;WRT CHK 1 WORD
;THIS DISK ADRES, SEC 0, CYL 0
;THIS BUS ADRES. NOTE THIS BA
;IN CONJUNCTION WITH MEX BITS OF RKCS
;WRT CHK, GO
;THERE MAY BE A NXM OR WCE BUT
;WHATEVER THE CASE RKBA SHOULD
;OVERFLOW MAKING THE MEX BITS COUNT
;GO CHECK IF CONTROL RDY IS SET
;IF SO, SKIP THE EROR MESSAGE.
;CNTRL RDY DID NOT SET AFTER WRT CHK
;MEX BITS SHOULD INCREMENT BY 1 TO THIS
;MASK OUT IDE BIT POSITION, IF SET
;GET RKCS
;MASK OUT ALL BITS EXCEPT MEX
;DID MEX BITS INCREMENT CORRECTLY?
;YES, BRANCH
;GET EXPCTD MEX BITS
;GET MEX BITS RECVD
;MEX BITS DID NOT INCREMENT AS
;'EXPCTD' WHEN RKBA OVERFLOWED.
;NOTE THAT BIT POSITION 4 & 5
;REFLECT MEX BITS 0 & 1 IN THE
;ERROR MESSAGE.
;GET RKER
;MASK WCE,DLT,NXM BIT, IF SET
;BRANCH IF REST OF RKER CLR
;MASK NON-WCE BITS
;THIS IS THE EXPCTD RKER
;GET RKER RECVD
;ERROR IN RKER. IT SHOULD
;BE AS EXPECTED IN
;ERROR MESSAGE
;INCREMENT TO NXT MEX BIT
;HAVE U CHKD THE MEX BITS 4 TIMES?
;IF NOT, LUP BACK
;*****
;*TEST 53 TRANSFER FROM DISK TO TTY
;* THIS TEST CHECKS THE HIGH ORDER BITS OF THE ADDRESS
;* LINES. FIRST A ONE WORD (100) IS WRITTEN ON SECTOR,
;* 2, CYL 0. THEN IT IS READ BACK, BUT THE NPR IS DONE
;* NOT TO THE MEMORY, BUT THE TELETYPE BUFFER (TKS 177560)
;* AND IT CHECKED THAT THE WORD WAS RECIEVED CORRECTLY.

```

:*IF IT IS NOT, AN ERROR IS REPORTED. THIS TEST IS
:*SKIPPED ON AN 11/05.

4771 017236 000004
4772 017240 012737 000001 001206
4773 017246 012737 012770 000004
4774 017254 005737 177700
4775 017260 012737 004462 000004
4776 017266 000520
4777 017270 022626
4778 017272 012737 004462 000004
4779 017300 012746 000340
4780 017304 012746 017312
4781 017310 000002
4782 017312
4783 017312 013700 001332
4784 017316 104413
4785
4786
4787
4788
4789
4800
4801
4802
4803
4804 017320 012701 033240
4805 017324 013704 001336
4806 017330 012711 000100
4807 017334 012777 177777 161772
4808 017342 013702 001350
4809 017346 052702 000002
4810 017352 010277 161762
4811 017356 010114
4812 017360 012710 000003
4813 017364 005003
4814 017366 105710
4815 017370 100410
4816 017372 005203
4817 017374 001374
4818 017376 004737 020702
4819 017402 010237 001202
4820 017406 104416
4821 017410 104031
4822
4823 017412 012777 177777 161714
4824 017420 010277 161714
4825 017424 013714 001144
4826 017430 005077 161510

TEST3: SCOPE
MOV #1,STIMES
MOV #55,2#4
TST #177700
MOV #BADTMO,2#4
BR TST54
55: CMP (SP)+,(SP)+
MOV #BADTMO,2#4
MOV #340,-(SP)
MOV #645,-(SP)
RTI
645: MOV RKCS,RC
CNT.RESET

:DO 1 ITERATION
:THIS CODE FINDS OUT IF THE CPU
:IS AN 11/05 OR ELSE.
:ON AN 11/05, RO (177700) CAN BE
:ADDRESSED AS A MEMORY LOCATION, BUT
:ON ANY OTHER CPU IF 177700 IS REFERENCED
:A TIME OUT WILL OCCUR.
:SET UP TIME OUT VECTOR
:REFERENCE RO
:RO WAS REFERENCED W/O TIMEOUT
:HENCE 11/05
:SKIP THIS TEST
:RESTORE STACK POINTER
:RESTORE TIMEOUT VECTOR

:GO, DC CONTROL RESET
:THIS IS A CALL FOR THE 'CNTRL-
:RESET' ROUTINE. A CONTROL RESET IS
:ISSUED AND AFTER A CERTAIN TIME
:IF THE 'CNTRL RDY' DOES NOT SET
:AN ERROR IS REPORTED. NOTE THAT
:THE PC IN ERROR MESSAGE IS THE
:PC WHERE 'CNT.RESET' IS LOCATED.
:THIS IS A VERY BASIC ERRS IF IT
:OCCURS GO BACK TO TEST 10

:WRITE THIS WORD
:WRITE 1 WORD
:ON CYL 0, SEC 2
:FROM THIS MEMORY LOC
:WRITE, GO

15: TSTB 2R0
BMI 25
INC R3
BNE 15
JSR PC,GT4RG
MOV R2,\$REGIO
BRKDA4
ERROR 31
25: MOV #-1,2RKWC
MOV R2,2RKDA
MOV \$TKS,2R4
CLR 2\$TKS
:GET RKCS, ER, DS
:GET THE STARTING ADRES
:BREAK IT INTO DRV #, CYL, SUR, SEC #
:CNTRL RDY DID NOT SET AFTER
:WRITE OF 1 WORD ON CYL 0, SEC 2
:READ 1 WORD
:FROM SEC 2, CYL 0
:INTO TTY STAUS REGISTER
:CLEAR TTY KEY BRD STATUS REG

```

4827
4828 017434 012710 000065      MOV      #65,DR0      ;READ, MEX BITS SET
4829 017440 005203      CLR      R3
4830 017442 105710      35:     TSTB     DR0
4831 017444 109410      9MI     45
4832 017446 005203      INC     R3
4833 017450 001374      BNE     35
4834 017452 004737 020702      JSR     PC,GT4RG
4835 017456 010237 001202      MOV     R2,$REG10
4836 017462 104416      BRKDAY
4837 017464 104045      ERROR   45
4838
4839
4840
4841
4842 017466 032737 000100 001144 45:     BIT     #100,$TKS
4843
4844 017474 001015      BNE     T5754
4845 017476 017705 161442      MOV     @TKS,R5
4846 017502 010537 001164      MOV     R5,$REG1
4847 017506 052705 000100      BIS     #100,R5
4848 017512 010537 001162      MOV     R5,$REG0
4849 017516 011437 001166      MOV     DR4,$REG2
4850 017522 011037 001170      MOV     DR0,$REG3
4851 017526 104115      ERROR   115
4852
4853
4854
4855
4856
4857
4858
4859
4860
4861
4862
4863
4864
4865
4866
4867
4868
4869 017530 000004      ;*****
4870 017532 012737 000005 001206  ;*TEST 54 CHECK THAT RKBA CAN COUNT CORRECTLY
4871 017540 104421      ;*THIS TEST CHECKS THAT RKBA CAN COUNT CORRECTLY. IT IS SET
4872 017542 005001      ;*TO THE DESIRED INITIAL VALUE. THEN A ONE WORD WRITE CHECK
4873 017544 012702 000002      ;*IS TRIED, WITH MEX (MEMORY EXTENSION) BITS SET. IF THERE IS
4874
4875 017550 012737 017562 001110      ;*NO MEMORY PRESENT (FOR CERTAIN BUS ADDRESSES), THERE
4876
4877
4878 017556 013705 001336      ;*WILL BE AN NXM ERROR STOPPING CONTROLLER ACTION, BUT RKBA
4879 017562 004737 021344      ;*SHOULD HAVE INCREMENTED BY 1 FROM ITS INITIAL VALUE. IF IT
4880 017566 104016      ;*HAS NOT, AN ERROR IS REPORTED.
4881 017570 104413
4882 017572 012777 177777 161534
4883
4884
4885
4886
4887
4888
4889
4890
4891
4892
4893
4894
4895
4896
4897
4898
4899
4900
4901
4902
4903
4904
4905
4906
4907
4908
4909
4910
4911
4912
4913
4914
4915
4916
4917
4918
4919
4920
4921
4922
4923
4924
4925
4926
4927
4928
4929
4930
4931
4932
4933
4934
4935
4936
4937
4938
4939
4940
4941
4942
4943
4944
4945
4946
4947
4948
4949
4950
4951
4952
4953
4954
4955
4956
4957
4958
4959
4960
4961
4962
4963
4964
4965
4966
4967
4968
4969
4970
4971
4972
4973
4974
4975
4976
4977
4978
4979
4980
4981
4982
4983
4984
4985
4986
4987
4988
4989
4990
4991
4992
4993
4994
4995
4996
4997
4998
4999

```

```

4883 017600 010115      MOV      R1,R5      ;THIS BUS ADRES
4884 017602 013777 001350 161530      MOV      DR1VAD,DRKDA ;SET DISK ADRES
4885 017610 012777 000067 161514      MOV      #67,DRKCS   ;WRITE CHECK, GO, MEX BITS SET
4886 017616 104412      CHKCRDY             ;GO CHECK IF CONTROL RDY IS SET
4887                                     ;IF SO, SKIP THE EROR MESSAGE.
4888 017620 104065      ERROR      65      ;CNTRL RDY DID NOT SET AFTER
4889                                     ;WRT CHK WAS TRIED TO NXM LOC
4890                                     ;U MIGHT WANT TO USE TESTS
4891                                     ;CHECKING MEX BITS & NXM.
4892 017622 005237 001356      INC      INDX1      ;ALLOW ONLY 5 ERRORS OF -BOVE KIND
4893 017626 001417      BEQ      55
4894
4895 017630 020215      35:      CMP      R2,R5      ;DID RKBA INCREMENT BY 1 FROM
4896                                     ;ITS INITIAL VALUE?
4897 017632 001410      BEQ      45      ;YES, BRANCH
4898 017634 010137 001162      MOV      R1,$REG0   ;GET EXPCD RKBA
4899 017640 011537 001164      MOV      R5,$REG1   ;GET RKBA RECVD
4900 017644 104017      ERROR      17      ;RKBA DID NOT INCREMENT BY
4901                                     ;1 FROM ITS INITIAL VALUE.
4902                                     ;ONE WORD WRT CHK WAS TRIED
4903                                     ;TO A NXM LOCATION. THERE
4904                                     ;WILL BE AN NXM ERROR,
4905                                     ;BUT STILL RKBA SHOULD
4906                                     ;INCREMENT BY 1 FROM ITS
4907                                     ;INITIAL VALUE.
4908 017646 005237 001360      INC      INDX2      ;ALLOW ONLY 5 ERRORS OF
4909 017652 001405      BEQ      55      ;THE ABOVE KIND
4910 017654 060201      45:      ADD      R2,R1      ;SET NXT VALUE OF RKBA
4911 017656 010102      MOV      R1,R2
4912 017660 062702 000002      ADD      #2,R2      ;SET EXPCD VALUE OF RKBA
4913 017664 001336      BNE      15      ;ALL DONE?
4914
4915 017666      55:                                     ;DUMMY EXIT POINT
4916
4917
4918
4919
4920
4921
4922
4923
4924 017666 000004      ;*****
4925 017670 012737 000001 001206 ;*TEST 55      CHECK FOR RK-OSF
4926 017676 005737 001404      ;*THIS TEST CHECKS RK-OSF TYPE DRIVES
4927 017702 001403      ;*TO INSURE THAT IF SEEKS ARE ISSUED ON ONE
4928 017704 004537 025056      ;*DRIVE, THE OTHER DRIVE BECOMES BUSY
4929 017710 104120      ;*****
4930
4931 017712      †ST55:      SCOPE
4932                                     MOV      #1,$TIMES      ;DO 1 ITERATION
4933                                     TST      FFLAG          ;SEE IF RK-OSF
4934                                     BEQ      15             ;NOT F
4935                                     JSR      R5,FCHECK      ;SEE IF OTHER GOES BUSY
4936                                     ERROR      120
4937
4938      15:
4939
4940
4941
4942
4943
4944
4945
4946
4947
4948
4949
4950
4951
4952
4953
4954
4955
4956
4957
4958
4959
4960
4961
4962
4963
4964
4965
4966
4967
4968
4969
4970
4971
4972
4973
4974
4975
4976
4977
4978
4979
4980
4981
4982
4983
4984
4985
4986
4987
4988
4989
4990
4991
4992
4993
4994
4995
4996
4997
4998
4999

```

4939
4940
4941
4942
4943
4944
4945
4946
4947
4948
4949
4950
4951
4952
4953
4954
4955
4956
4957
4958
4959
4960
4961
4962
4963
4964
4965
4966
4967
4968
4969
4970
4971
4972
4973
4974
4975
4976
4977
4978
4979
4980
4981
4982
4983
4984
4985
4986
4987
4988
4989
4990
4991
4992
4993
4994

017712 000004
017714 012737 000001 001206
017722 005237 001352
017726 004737 021412
017732 104026
017734 023737 001412 001352 BTEOP:
017742 001405
017744 062737 020000 001350
017752 000137 004766
017756 005037 001412

000004
012737 000005 001206
005237 001440
001002
020000 004737 025202
020004 005037 001436
020010 012700 001414
020014 005710
020016 001405
020020 005237 001436
020024 005710
020026 100001
020030 005720
020032 005720
020034 020027 001433
020040 002765
020042 005037 001406
020046 005737 001412
020052 001002
020054 000137 020560
020060 005237 001434
020064 013700 001332
020070 005037 001356

```
; *DO NOT LOOP ON THIS 'TEST'.
*****
↑T56: SCOPE
MOV #1,STIMES ;:DO 1 ITERATION
INC DRVDM ;:INCREMENT THE COUNT FOR THE NUMSEP
;:OF DRIVES THAT ARE CHECKED
JSR PC,DRESET ;:RESET THE DRIVE
ERROR 26 ;:R/W/S DIDN'T SET AFTER DRIVE RESET
BTEOP: CMP DRVS,DRVDM ;:HAVE U TESTED ALL THE DRIVES
;:THAT ARE PRESENT?
BEQ 1$ ;:IF YES, EXIT
ADD #20000,DRVAD ;:ADRES THE NXT POSSIBLE DRIVE
JMP NUDRV ;:GO BACK AND TEST THE NEXT
;:DRIVE PRESENT
1$: CLR SERTTL
```

```
*****
; *TEST 57 CHECK HARDWARE POLLING LOGIC
; *THIS TEST CHECKS THE HARDWARE POLL LOGIC, USING ALL THE DRIVES
; *PRESENT ON THE RK11. ATLEAST TWO DRIVES SHOULD BE PRESENT
; *TO DO A MEANINGFUL HARDWARE POLL. SEQUENCE OF OPERATIONS IS
; *AS FOLLOWING:
; *1) NUMBER OF DRIVES ON THE RK11 IS ASCERTAINED.
; *2) HAVING LOCKED OUT ALL INTERRUPTS (CPU PR 7), SEEK IS INITIATED
; *FOR ONE DRIVE AT A TIME, ONLY WHEN 'CNTRL RDY' IS SET.
; *3) CPU PRIORITY IS DROPPED TO 4 SO THAT RK11 CAN INTERRUPT. THE INCOMING
; *INTERRUPT IS PROCESSED TO CHECK IF IT WAS DUE TO 'SEEK DONE' BY
; *ONE OF THE DRIVES.
; *4) IF BY THE END OF THE SET TIME A DRIVE HAS NOT INTERRUPTED
; *AN ERROR MESSAGE IS GIVEN INDICATING WHICH DRIVE DID NOT
; *INTERRUPT AFTER SEEK WAS DONE.
```

```
*****
↑T57: SCOPE
MOV #5,STIMES ;:DO 5 ITERATIONS
INC SIZYET ;:FOUNR RK05F YET?
BNE 25$ ;:YES
JSR PC,SIZEF ;:FIND WHICH ARE RK-05F
25$: CLR PHYDRV ;:NUMBER OF ACTUAL DRIVES
MOV #DRIVO,RO ;:TABLE
23$: TST (RO) ;:DRIVE HERE+?
BEQ 22$ ;:NO
INC PHYDRV ;:COUNT DRIVE
TST (RO) ;:RK05F?
BPL 22$ ;:NO
TST (RO)+ ;:DONT COUNT F TWICE
22$: TST (RO)+ ;:NEXT DRIVE
CMP RO,#DRIV7+1 ;:ALL YET
BLT 23$ ;:NO
CLR ODDEVN ;:EVEN DRIVES FIRST IF F
T56: TST DRVS ;:ANY DRIVES PRESENT?
BNE 20$ ;:YES
JMP $EOP ;:NO
20$: INC T56FLG
MOV RKCS,RO
CLR INDX1 ;:FLAG TO INDICATE:
```


5051	020240	001374			BNE	25		: IF WAITED LONG REPORT ERROR
5052	020242	004737	020702		JSP	PC,GT4RG		: GO, GET RKCS, ER, DS, DA
5053	020246	104021			ERROR	21		: CNTRL RDY DID NOT SET AFTER ACCEPTING
5054								: ADRES FROM PREVIOUS SEEK
5055	020250	010277	161064	35:	MOV	R2,2RKDA		: ADRES THIS DRIVE, CYL 0 OR CYL 4
5056								: (WHICHEVER THE CASE MAY BE)
5057	020254	012710	000111		MOV	#111,2RD		: SEEK, GO, IDE SET
5058	020260	005721		45:	TST	(R1)+		: NEXT DRIVE DATA
5059	020262	062702	020000		ADD	#20000,R2		: INCREMENT DRIVE ADRES (BITS 15,14,13)
5060	020266	005203			INC	R3		: TO NEXT ONE
5061	020270	001330			BNE	15		: BRANCH BACK IF ALL DRIVES ARE
5062								: NOT CHECKED TO SEE IF THE NEXT
5063								: DRIVE IS PRESENT (& IF SO ISSUE A
5064								: SEEK TO IT)
5065								: BY NOW SEEKS HAVE BEEN ISSUED
5066								: TO ALL DRIVES PRESENT & POLLING
5067								: HAS BEGUN
5068	020272	005004			CLR	R4		
5069	020274	013702	001402	55:	MOV	RKVEC,R2		
5070	020300	012722	020332		MOV	#65,(R2)+		: SET ADRES FOR RK11 TO INTERRUPT
5071	020304	012712	000340		MOV	#340,(R2)		: SET PSW ON INTERRUPT
5072	020310	013746	001400		MOV	RKPRI,-(SP)		: DROP CPU PRIORITY TO 4 SO THAT
5073	020314	012746	020322		MOV	#185,-(SP)		: RK11 CAN INTERRUPT
5074	020320	000002			RTI			
5075	020322	000240		195:	NOP			: THIS IS A TIME LOOP DURING
5076	020324	005204			INC	R4		: WHICH ALL DRIVES PRESENT SHOULD
5077	020326	001375			BNE	185		: INTERRUPT
5078	020330	000452			BR	115		: BRANCH AND CHECK IF ALL AVAILABLE
5079								: DRIVES INTERRUPTED CORRECTLY
5080	020332	022626		65:	CMP	(SP)+,(SP)+		: RESTORE STACK POINTER
5081	020334	005737	001360		TST	INDX2		: WAS THIS FIRST INTERRUPT
5082								: DUE TO 'ADRES ACK' AFTER INITIATION
5083								: OF SEEK?
5084	020340	001021			BNE	95		: IF YES, CHECK THE FOLLOWING
5085								
5086	020342	032710	020000		BIT	#20000,2RD		: CHECK THAT SCP IS NOT SET
5087	020346	001403			BEQ	75		: BRANCH IF SCP CLEAR
5088	020350	011037	001162		MOV	2RD,\$REGO		: GET RKCS
5089	020354	104076			ERROR	76		: AFTER THE FIRST INTERRUPT WHICH
5090								: IS DUE TO INITIATION OF SEEK, SCP
5091								: SHOULD NOT HAVE SET. IT DID
5092	020356	017701	160744	75:	MOV	2RKDS,R1		
5093	020362	032701	160000		BIT	#160000,R1		: RKDS BITS 15-13 SHLOULD BE CLR
5094	020366	001403			BEQ	85		
5095	020370	010137	001162		MOV	R1,\$REGO		: GET RKDS
5096	020374	104050			ERROR	50		: SEEK, WITH IDE SET WAS ISSUED TO
5097								: ALL AVAILABLE DRIVES. THE FIRST
5098								: INTERRUPT IS DUE TO SEEK INITIATED
5099								: BY FRST DRV. DRV ID BITS 13-15
5100								: SHOULD BE CLR AFTR THIS FRST INRUPT.
5101								: THEY WERE NOT IF THIS ERROR OCCURS.
5102	020376	005237	001360	85:	INC	INDX2		: SET UP FLAG INDICATING
5103								: THAT E FIRST INTERRUPT DUE
5104								: TO INITIATION OF SEEK WAS
5105								: PROCESSED
5106	020402	000734			BR	55		: GO BACK TO THE WAIT LOOP & WAIT

H09

5107								
5108	020404	013703	001436	95:	MOV	PHYDRV,R3		;FOR NEXT INTERRUPT FROM RK11
5109	020410	012705	033240		MOV	#OUTBUF,R5		;SET COUNT OF # OF DRIVES PRESENT
5110	020414	017701	160706		MOV	DRKDS,R1		;INITIALIZE POINTER
5111	020420	042701	017777		BIC	#17777,R1		;GET RKDS
5112								;MASK BITS 0-12
5113								;THE FOLLOWING CODE IS A SOFTWARE
5114								;POLL WHICH FINDS OUT WHICH DRIVE
5115								;CAUSED THE PRESENT INTERRUPT
5116								;AND SETS UP A FLAG BIT FOR
5117								;THE DRIVE #, INDICATING THAT
5118	020424	020125			CMP	R1,(R5),+		;THIS DRIVE # INTERRUPTED
5119	020426	001411			BEQ	10\$;BRANCH IF INTERRUPTING DRIVE WAS FOUND
5120	020430	005303			DEC	R3		;HAVE U CHKD ALL DRVS PRESENT?
5121	020432	001374			BNE	.-6		;IF NOT LUP BAK & CHK
5122								;REPORT ERROR IF THE INTERRUPTING
5123								;DRIVE # (AS IN RKDS 13-15) WAS NOT
5124								;ANY ONE OF THOSE THAT ARE PRESENT
5125	020434	010146			MOV	R1,-(R6)		;GET WORD TO B SHFTD RT
5126	020436	004737	021106		JSR	PC,SHFTRT		;GO SHIFT IT
5127	020442	012637	001162		MOV	(R6)+,\$REGD		;THIS DRIVE # WAS RECD IN RKDS AS
5128								;THE INTERRUPTING DRIVE, BUT THIS
5129								;DRIVE IS NOT PHYSICALLY PRESENT
5130	020446	104051			ERROR	51		;RKDS INDICATES AN INTERRUPTING
5131								;DRIVE # (DURING H'WARE POLL) BUT
5132								;THAT DRIVE IS ACTUALLY NOT PRESENT
5133	020450	000401			BR	10\$+2		
5134	020452	005245		10\$:	INC	-(R5)		;SET UP FLAG INDICATING THAT
5135								;THE INTERRUPT FOR THIS DRIVE
5136								; (AFTER IT HAD COMPLETED ITS SEEK)
5137								; WAS PROCESSED
5138	020454	000707			BR	5\$;GO BAK & WAIT FOR FURTHER INTRUPTS
5139	020456	013703	001436	11\$:	MOV	PHYDRV,R3		;GET # OF DRIVES
5140	020462	012705	033240		MOV	#OUTBUF,R5		;INITIALIZE POINTER
5141								
5142	020466	105715		14\$:	TSTB	(R5)		;DID THIS DRIVE INTERRUPT?
5143	020470	001006			BNE	13\$;YES, BRANCH
5144	020472	011546			MOV	(R5),-(R6)		;GET THIS DRIVE #
5145	020474	004737	021106		JSR	PC,SHFTRT		;SHIFT IT TO THE RIGHT
5146	020500	012637	001162		MOV	(R6)+,\$REGD		;THIS DRIVE # DID NOT INTERRUPT
5147								;DURING H'WARE POLL
5148	020504	104052			ERROR	52		;DRIVE # (AS IN \$REGD) DID NOT
5149								;INTERRUPT DURING HARDWARE POLL
5150	020506	062705	000002	13\$:	ADD	#2,R5		;INCREMENT POINTER TO THE NEXT FLAG
5151	020512	005303			DEC	R3		;CHKD FOR ALL DRIVES?
5152	020514	001364			BNE	14\$;IF NOT LUP BACK
5153								
5154	020516	005737	001356		TST	INDX1		;DONE POLLING FOR SEEKS TO CYL 312?
5155	020522	001004			BNE	TSTEND		;IF YES, EXIT
5156	020524	005237	001356		INC	INDX1		;IF NOT INCREMENT FLAG
5157	020530	000137	020074		JMP	15\$;GO DO IT
5158								
5159								;INDICATOR TABLE
5160								;THE 8-WORD INDICATOR TABLE USED IN
5161								;THE FORMER PART OF THIS SUB-TEST
5162								;IS LOCATED STARTING AT 'OUTBUF'.

5163
5164
5165
5166
5167
5168
5169
5170
5171
5172
5173
5174
5175
5176
5177
5178
5179
5180
5181
5182
5183
5184
5185
5186
5187
5188
5189
5190
5191
5192
5193
5194
5195
5196
5197
5198
5199
5200
5201
5202
5203
5204
5205
5206
5207
5208
5209
5210
5211
5212
5213
5214
5215
5216
5217
5218

020534 005237 001406
020540 022737 C00C02 001406
020546 001402
020550 000137 020046
020554 005037 001434

020560
020560 000004
020562 005037 001102
020566 005037 001206
020572 005237 001100
020576 042737 100000 001100
020604 005327
020606 000001
020610 003022
020612 012737
020614 000001
020616 020606
020620 104401 020665
020624 013746 001100
020630 104405
020632 104401 020662
020636 013700 000042
020642 001405
020644 000005
020646 004710
020650 000240

WORDS ARE SET UP TO INDICATE
PRESENCE OF A DRIVE EG: IF
DRIVES 0,1,2 ARE PRESENT, IT WILL
LOOK LIKE
OUTBUF: 000000 BITS 13,14,15
020000 CONTAIN THE
040000 DRIVE NO.
000000 REST 0'S
WHEN A DRIVE INTERRUPTS AFTER SEEK
IS DONE BIT 0 OF THE CORRESPONDING
INDICATOR WORD IS SET. THUS FOR THE
ABOVE EXAMPLE IF ALL DRIVES INTERRUPTED
CORRECTLY THEN IT WILL LOOK LIKE:
125: 000001 BIT 0 SET
020001 TO INDICATE
040001 DR INTERRUPTED
000000 REST 0'S

TSTEND: INC 0DDEVN ;NOW ODD IF RK05F
CMP #2,0DDEVN ;SEE IF DONE
BEQ 21\$;ALL DONE
JMP T56 ;TEST AGAIN
21\$: CLR T56FLG

.SBTTL END OF PASS ROUTINE

*INCREMENT THE PASS NUMBER (\$PASS)
*INDICATE END-OF-PROGRAM AFTER 1 PASSES THRU THE PROGRAM
*TYPE "END PASS #XXXXX" (WHERE XXXXX IS A DECIMAL NUMBER)
*IF THERES A MONITOR GO TO IT
*IF THERE ISN'T JUMP TO ST4

SEOP: SCOPE
CLR \$TSTNM ;;ZERO THE TEST NUMBER
CLR \$TIMES ;;ZERO THE NUMBER OF ITERATIONS
INC \$PASS ;;INCREMENT THE PASS NUMBER
BIC #100000,\$PASS ;;DON'T ALLOW A NEG. NUMBER
DEC (PC)+ ;;LOOP?
SEOPCT: .WORD 1
BGT \$DOAGN ;;YES
MOV (PC)+,2(PC)+ ;;RESTORE COUNTER
SENDCT: .WORD 1
SEOPCT
TYPE \$SENDMG ;;TYPE "END PASS #"
MOV \$PASS,-(SP) ;;SAVE \$PASS FOR TYPEOUT
TYPDS ;;GO TYPE--DECIMAL ASCII WITH SIGN
TYPE \$NULL ;;TYPE A NULL CHARACTER
\$GET42: MOV #42,R0 ;;GET MONITOR ADDRESS
BEQ \$DOAGN ;;BRANCH IF NO MONITOR
RESET ;;CLEAR THE WORLD
SENDAD: JSR PC,(R0) ;;GO TO MONITOR
NOP ;;SAVE ROOM

5219 020652 000240
 5220 020654 000240
 5221 020656
 5222 020656 000137
 5223 020660 004404
 5224 020662 377 377 000
 5225 020665 015 042412 042116
 5226 020672 050040 051501 020123
 5227 020709 000043

NOP ;:FOR
 NOP ;:PCT11
 \$DOAGN: JMP 2(PC)+ ;:RETURN
 \$RTNAD: .WORD ST4
 \$ENULL: .BYTE -1,-1,0 ;:NULL CHARACTER STRING
 \$ENDMG: .ASCIZ '15><12>'END PASS #/

.SBTTL GT2RG: ROUTINE FOR GETTING RKCS,RKER

;SUBROUTINE FOR TRANSFERRING THE CONTENTS OF RKCS, RKEr,
 ;TO \$REG0, \$REG1 RESPECTIVELY BEFORE TYPING OUT AN ERROR MESSAGE.
 ;CALL: JSR PC,GT2RG

.SBTTL GT3RG: ROUTINE FOR GETTING RKCS, RKER, RKDS

;GT3RG
 ;SUBROUTINE FOR TRANSFERRING THE CONTENTS OF RKCS, RKER, RKDS
 ;TO \$REG0, \$REG1, \$REG2 RESPECTIVELY BEFORE TYPING OUT AN
 ;ERROR MESSAGE.
 ;CALL: JSR PC,GT3RG

.SBTTL GT4RG: ROUTINE FOR GETTING RKCS, RKER, RKDS, RKDA

;GT4RG
 ;SUBROUTINE FOR TRANSFERRING CONTENTS OF RKCS, RKER, RKDS
 ;RKDA TO \$REG0, \$REG1, \$REG2, \$REG3 RESPECTIVELY BEFORE
 ;TYPING OUT AN ERROR MESSAGE.
 ;CALL: JSR PC,GT4RG

5257 020702 017737 160432 001170
 5258 020710 017737 160412 001166
 5259 020716 017737 160406 001164
 5260 020724 017737 160402 001162
 5261 020732 000207

GT4RG: MOV 2RKDA,\$REG3 ;GET RKDA
 GT3RG: MOV 2RKDS,\$REG2 ;GET RKDS
 GT2RG: MOV 2RKER,\$REG1 ;GET RKER
 MOV 2RKCS,\$REG0
 RTS PC

.SBTTL TYERM: SPECIAL ERROR MESSAGE ROUTINE

;TYERM
 ;THIS ROUTINE TYPES OUT 'EROR AT PC=X'
 ;X IS THE PC WHERE THE EXPLANATION AS TO WHAT HAPPENED IS GIVEN. THIS ROUTINE
 ;IS USED ONLY FOR NON-MANUAL MODE OF THE PROGRAM.
 ;CALL: JSR TYERM

5262
 5263
 5264
 5265
 5266
 5267
 5268
 5269
 5270
 5271
 5272
 5273
 5274

K09

MAINDEC-11-DZRKK-D MACY11 27(1006) 04-OCT-76 16:06 PAGE 97
 DZRKKD.P11 22-SEP-76 08:47

TYERM: SPECIAL ERROR MESSAGE ROUTINE

SEQ 0114

5275 020734
 5276 020734 104401 020742
 5277 020740 000406
 5278
 5279 020756
 5280 020756 010346
 5281 020760 104402
 5282 020762 000207
 5283
 5284
 5285
 5286
 5287
 5288
 5289
 5290
 5291
 5292
 5293
 5294
 5295
 5296
 5297
 5298
 5299
 5300
 5301
 5302
 5303
 5304
 5305
 5306
 5307 020764 010046
 5308 020766 012700 001172
 5309 020772 000403
 5310
 5311 020774 010046
 5312 020776 012700 001202
 5313
 5314 021002 032777 020000 160130
 5315 021010 001034
 5316
 5317 021012 010146
 5318 021014 010246
 5319 021016 013701 001202
 5320
 5321 021022 042701 177760
 5322 021026 010140
 5323 021030 013701 001202
 5324 021034 006201
 5325 021036 006201
 5326 021040 006201
 5327 021042 006201
 5328 021044 010102
 5329 021046 042702 177776
 5330 021052 010240

TYERM:
 TYPE 655 ;:TYPE ASCIZ STRING
 BR 645 ;:GET OVER THE ASCIZ
 ;:655: .ASCIZ <15><12>/EROR,PC=
 ;:645: MOV R3,-(SP.
 TYPOC
 RTS PC

.SBTTL BDAQ, BDA4: BREAK DISK ADDRESS INTO SEC, SUR, CYL, DRIVE

;BDAQ, BDA4

; THIS ROUTINE BREAKS A DISK ADDRESS (BITS 0-15) INTO DRIVE #,
 ; CYLINDER #, SURFACE, SECTOR #. THE ROUTINE IS CALLED BY USING EITHER
 ; BRKDAQ OR BRKDA4, BOTH BEING 'TRAP' INSTRUCTIONS WITH THEIR LOWER BYTES
 ; ENCODED TO PROVIDE INDEXING TO 'BDAQ' OR 'BDA4'. BEFORE CALLING
 ; THE ROUTINE THE DISK ADDRESS WHICH IS TO BE BROKEN AS ABOVE
 ; IS DEPOSITED IN \$REG10.

; 'BRKDAQ' PUTS THE
 ; DRIVE # INTO \$REG0
 ; CYLINDER # INTO \$REG1
 ; SURFACE # INTO \$REG2
 ; SECTOR # INTO \$REG3
 ; CALL: BRKDAQ

BRKDA4 PUTS THE
 DRIVE # INTO \$REG4
 CYLINDER # INTO \$REG5
 SURFACE # INTO \$REG6
 SECTOR # INTO \$REG7
 BRKDA4

BDAQ: MOV R0,-(SP) ;PUSH R0 ONTO THE STACK
 MOV # \$REG3+2,R0 ;SET UP POINTER
 BR BDAQ

BDA4: MOV R0,-(SP) ;PUSH R0 ONTO THE STACK
 MOV # \$REG7+2,R0 ;SET UP POINTER

BDA4: BIT #20000,\$SWR ;INHIBIT TYPEOUT?
 BNE 25 ;YES, BRANCH TO EXIT POINT

MOV R1,-(SP) ;PUSH R1 ON STACK
 MOV R2,-(SP) ;PUSH R2 ON STACK
 MOV \$REG10,R1 ;GET THE ADDRESS WHICH
 ;HAS TO BE BROKEN

BIC #177760,R1 ;EXTRACT SECTOR BITS 0-3
 MOV R1,-(R0) ;MOVE SECTOR BITS TO \$REG3 OR \$REG7
 MOV \$REG10,R1 ;GET THE DSK-ADRES TO BE BROKEN
 ASR R1 ;SHIFT RIGHT 4 TIMES
 ASR R1
 ASR R1
 ASR R1

MOV R1,R2 ;STORE THIS
 BIC #177776,R2 ;EXTRACT THE SURFACE BIT
 MOV R2,-(R0) ;MOVE SURFACE BIT TO \$REG3 OR \$REG6

```

5331 021054 006201          ASR      R1
5332 021056 010102          MOV      R1,R2          ;STORE IT
5333 021060 042702 177400  BIC      #177400,R2    ;EXTRACT THE CYLINDER BITS
5334 021064 010240          MOV      R2,-(R0)     ;MOVE CYLINDER BITS TO $REG1 OR $REG5
5335 021066 000301          SWAB    R1            ;SWAB HI-LO BYTES
5336 021070 042701 177770  BIC      #177770,R1    ;EXTRACT THE DRIVE #
5337 021074 010140          MOV      R1,-(R0)     ;MOVE DRIVE # TO $REG3 OR $REG4
5338
5339 021076 012602          MOV      (SP)+,R2     ;RESTORE R2
5340 021100 012601          MOV      (SP)+,R1     ;RESTORE R1
5341 021102 012600 25:    MOV      (SP)+,R0     ;RESTORE R0 FROM THE STACK
5342 021104 000002          RTI                    ;RETURN FROM INTERRUPT, EXIT THIS
5343
5344
5345
5346
5347
5348
5349
5350
5351
5352
5353
5354
5355 021106 012737 177763 021132 SHFTRT: MOV    #-15,25      ;SET UP A COUNT OF 13
5356 021114 000241          CLC                    ;CLEAR THE C BIT
5357 021116 006066 000002 15:    ROR      2(R6)         ;ROTATE RIGHT THE WORD TO B SHFTD
5358 021122 005237 021132          INC      25           ;SHIFTED 13 TIMES?
5359 021126 001373          BNE     15            ;IF NOT LUP BAK & SHIFT
5360 021130 000207          RTS      PC           ;EXIT FROM THIS SUBROUTINE
5361 021132 000000 25:    0
5362
5363
5364
5365
5366
5367
5368
5369
5370
5371
5372
5373
5374
5375
5376
5377
5378
5379
5380
5381
5382
5383
5384
5385
5386

```

.SBTTL SHFTRT: SHIFT RIGHT ROUTINE

```

;SHFTRT
;THIS ROUTINE SHIFTS A WORD TO THE RIGHT 13 TIMES. THE WORD TO BE SHIFTED
;IS PUT ON THE STACK BEFORE ENTERING THIS ROUTINE AND IT IS POPPED UP
;FROM THE STACK AFTER THE SHIFT HAS BEEN DONE.
;CALL: JSR PC,SHFTRT

```

.SBTTL CHKHE: CHECK FOR 'ERR' OR
.SBTTL CHKHE1: CHECK FOR 'ERR' OR

```

;CHKHE
;THIS ROUTINE CHECKS IF 'HE' OR 'ERR' BITS IN RKCS ARE SET. IF ANY OF THE
;TWO BITS ARE SET, THE CONTENTS OF RKCS, ER, DS, AND DA ARE SAVED AND A
;RETURN IS MADE TO THE ERROR MESSAGE FOLLOWING THE 'JSR' CALL.
;AT THE TIME OF ENTRY 'DRIVAD' CONTAINS THE DISK ADDRESS WHICH IS TO
;BE BROKEN DOWN INTO DRIVE #, CYLINDER, SURFACE AND SECTOR #. THIS INFORMATION
;IS SAVED TO BE USED LATER FOR ERROR REPORTING. IF THE BITS ARE NOT SET,
;RETURN IS MADE TO SKIP THE ERROR MESSAGE.

```

```

;CHKHE1
;THIS ROUTINE CHECKS IF 'HE' OR 'ERR' BITS IN RKCS ARE SET. IF ANY OF THE
;TWO BITS ARE SET, THE CONTENTS OF RKCS, ER, DS, AND DA ARE SAVED AND A
;RETURN IS MADE TO THE ERROR MESSAGE FOLLOWING THE 'JSR' CALL.
;AT THE TIME OF ENTRY R1 CONTAINS THE DISK ADDRESS WHICH IS TO BE BROKEN
;DOWN INTO DRIVE #, CYLINDER, SURFACE AND SECTOR #. THIS INFORMATION IS
;SAVED TO BE USED LATER FOR ERROR REPORTING. IF THE BITS ARE NOT SET,
;RETURN IS MADE TO SKIP THE ERROR MESSAGE.

```

```

5387
5388 021134 010137 001202      CHKHE1: MOV      R1,$REG10      ;SAVE THE DISK ADRES
5389 021140 000403              BR          CHE1
5390
5391 021142 013737 001350 001202  CHKHE:  MOV      DRIVAD,$REG10      ;SAVE THE DISK ADRES
5392 021150 032777 140000 160154  CHE1:   BIT      #140000,$RKCS      ;IS 'HE' OR 'ERR' BIT SET?
5393 021156 001467              BEQ      CRETRN              ;NO
5394 021160 004737 020702      JSR      PC,GT4RG            ;GET RKCS,ER,DS, DA
5395 021164 104416              BRKDA4                       ;GO TO 'BDA4' & BREAK CONTENTS 0
5396                                ;$REG10 INTO DR#,CYL,SUR,SEC BITS
5397 021166 000207              RTS      PC                  ;RETURN TO THE ERROR MESSAGE
5398
5399
5400
5401
5402
5403
5404
5405
5406
5407
5408

```

.SBTTL CHKDA: CHECK IF RKDA INCREMENTED CORRECTLY

```

5409 021170 013705 001350      CHKDA:  MOV      DRIVAD,R5      ;RKDA SHOULD INCREMENT TO THIS
5410 021174 005205              INC      R5                  ;AFTER DATA TRANSFER IS DONE
5411 021176 020577 160136      CHKDA1: CMP      R5,$RKDA      ;DID RKDA INCREMENT CORRECTLY?
5412 021202 001455              BEQ      CRETRN              ;IF YES, BRANCH
5413                                ;IF NOT, REPORT ERROR
5414 021204 010537 001202      MOV      R5,$REG10          ;GET EXPTD RKDA
5415 021210 104415              BRKDA0                       ;GO TO 'BDA0' & BREAK CONTENTS OF
5416                                ;$REG10 INTO DR #,CYL,SUR,SEC BITS
5417 021212 017737 160122 001202  MOV      $RKDA,$REG10        ;GET ACTUAL RKDA
5418 021220 104416              BRKDA4                       ;GO TO 'BDA4' & BREAK CONTENTS OF
5419                                ;$REG10 INTO DR #,CYL,SUR,SEC BITS
5420 021222 000207              RTS      PC                  ;RETURN TO THE ERROR MESSAGE
5421
5422
5423
5424
5425
5426
5427
5428
5429 021224 005777 160104      CHKWC:  TST      $RKWC          ;DID WORD COUNT OVERFLOW TO 0?
5430 021230 001442              BEQ      CRETRN              ;IF YES, BRANCH
5431                                ;IF NOT, ERROR
5432 021232 017737 160076 001162  MOV      $RKWC,$REG0          ;GET RKWC
5433 021240 017737 160074 001164  MOV      $RKDA,$REG1          ;GET RKDA
5434 021246 000207              RTS      PC                  ;RETURN TO THE ERROR MESSAGE
5435
5436
5437
5438
5439
5440
5441
5442

```

.SBTTL CHKWC: CHECK IF RKWC OVERFLOWED

```

;CHKWC
;THIS ROUTINE CHECKS IF RKWC OVERFLOWED TO 0. IF IT DID A RETURN IS MADE
;TO SKIP THE ERROR MESSAGE. IF NOT,THE CONTENTS OF RKWC AND RKDA ARE SAVED
;AND A RETURN IS MADE TO THE ERROR MESSAGE FOLLOWING THE 'JSR' CALL.

```

.SBTTL CHKER: CHECK RKER CONTENTS

```

;CHKER
;THIS ROUTINE CHECKS IF ANY BIT IN RKER SET. IF NOT RETURN IS MADE TO SKIP
;THE ERROR MESSAGE. IF ANY BIT IS SET THE CONTENTS OF RKCS, RKER, RKDS ARE
;SAVED AND A RETURN IS MADE TO THE ERROR MESSAGE.

```

MAINDEC-11-DZRKK-D MACY11 27(1006) 04-OCT-76 16:06 PAGE 100
 DZRKKD.P11 22-SEP-76 08:47 CHKER: CHECK RKER CONTENTS

SEQ 0117

```

5443 021250 005777 160054      CHKER: TST      DRKER      ;DID ANY BIT IN RKER SET?
5444 021254 001430              BEQ      CRETRN      ;NO, BRANCH
5445                                ;YES, ERROR
5446 021256 004737 020710      JSR      PC,GT3RG     ;GO, GET RKCS, ER, DS
5447
5448 021262 000207              RTS      PC           ;RETURN TO THE ERROR MESSAGE
5449
5450
5451      ;CHKECLR
5452      ;THIS ROUTINE CHECKS THAT RKER IS CLEAR. IF NOT, THE CONTENTS OF RKER
5453      ;ARE SAVED AND A RETURN IS MADE TO THE ERROR MESSAGE FOLLOWING THE "JSR"
5454      ;CALL. IF RKER IS CLEAR THE ERROR MESSAGE IS SKIPPED ON RETURN.
5455
5456 021264 005777 160040      CHKECLR: TST      DRKER      ;ANY BIT IN RKER SET?
5457 021270 001422              BEQ      CRETRN      ;NO
5458 021272 013737 001330 001162  MOV      RKER,$REG0   ;GET ADRES OF RKER
5459 021300 017737 160024 001164  MOV      DRKER,$REG1  ;GET CONTENTS OF RKER
5460 021306 000207              RTS      PC           ;RETURN TO THE ERROR MESSAGE
5461
5462
5463      ;CHKCCLR
5464      ;THIS ROUTINE CHECKS THAT RKCS IS CLEAR. IF NOT, THE CONTENTS OF RKCS ARE
5465      ;SAVED AND A RETURN IS MADE TO THE ERROR MESSAGE. IF RKCS IS CLEAR THE
5466      ;ERROR MESSAGE IS SKIPPED ON RETURN.
5467 021310 022777 000200 160014  CHKCCLR: CMP      #200,DRKCS ;IS RKCS CLEAR?
5468 021316 001407              BEQ      CRETRN      ;YES
5469 021320 013737 001332 001162  MOV      RKCS,$REG0   ;SAVE ADRES OF RKCS
5470 021326 017737 160000 001164  MOV      DRKCS,$REG1  ;SAVE THE CONTENT OF RKCS
5471 021334 000207              RTS      PC           ;RETURN TO THE ERROR MESSAGE
5472
5473 021336 062716 000002      CRETRN: ADD      #2,(SP) ;SKIP ERROR MESSAGE ON
5474 021342 000207              RTS      PC           ;RETURN
5475
5476
5477      .SBTTL TSTRWS: WAIT FOR R/W/S RDY ROUTINE
5478
5479      ;TSTRWS
5480      ;THIS ROUTINE WAITS FOR R/W/S RDY TO SET. WHEN IT SETS, THE RETURN PC
5481      ;IS INCREMENTED SO THAT ON RETURN (TO THE MAIN PROGRAM) THE ERROR
5482      ;MESSAGE FOLLOWING THE 'JSR' CALL IS SKIPPED. IF R/W/S RDY DOES NOT SET
5483      ;THEN A RETURN IS MADE TO THE ERROR MESSAGE (FOLLOWING THE 'JSR' CALL).
5484      ;WAITING TIME IS APPROX. 1040 MS FOR 11/20, APPROX. 208 MS FOR 11/45
5485      ;CALL: JSR      TSTRWS
5486
5487 021344 013777 001350 157766  TSTRWS: MOV      DRIVAD,DRKDA ;ADRES THE DRIVE
5488 021352 005037 001366              CLR      TIMER       ;INITIALIZE COUNT
5489 021356 032777 000100 157742 1$: BIT      #100,DRKDS   ;DID R/W/S RDY SET?
5490 021364 001007              BNE      2$          ;YES, BRANCH
5491 021366 005237 001366              INC      TIMER       ;WAIT FOR R/W/S RDY
5492 021372 001371              BNE      1$          ;ERROR IF IT'S NOT SET BY NOW
5493 021374 017737 157726 001162  MOV      DRKDS,$REG0  ;GET RKDS
5494 021402 000207              RTS      PC           ;EXIT (TO ERROR FOOLOWING 'JSR TSTRWS')
5495
5496 021404 062716 000002      2$: ADD      #2,(SP)   ;ADJUST RETURN ADRES TO SKIP OVER
5497                                ;ERROR (FOLLOWING 'JSR TSTRWS')
5498 021410 000207              RTS      PC           ;EXIT
  
```

.SBTTL DRESET: DRIVE RESET ROUTINE

```

:DRESET
:THIS ROUTINE DOES A DRIVE RESET ON THE DRIVE WHOOSE ADDRESS IS IN
:RADA. MULTIPLE RETURN ADDRESSES FOR THIS ROUTINE ARE PROVIDED.
:IF THERE IS NO ERROR (R/W/S RDY SETS WITHIN CERTAIN TIME), THEN BEFORE
:EXITING FROM THIS ROUTINE THE RETURN ADDRESS IS INCREMENTED BY 2 TO SKIP
:THE ERROR MESSAGE ON RETURN. IF THERE IS AN ERROR, THE 3 REGISTERS (CS,ER,DS)
:ARE STORED AND THEN A NORMAL EXIT IS MADE FROM THIS ROUTINE TO THE
:ERROR MESSAGE FOLLOWING THE CALL FOR THIS ROUTINE.
:CALL: JSR PC,DRESET

```

021412	005037	001364		DRESET: CLR	COUNT1	: INITIALIZE THE COUNT
021416	013777	001350	157714	MOV	DRIVAD, DRKDA	: ADRES THE DRIVE
021424	012777	000015	157700	MOV	#15, DRKCS	: DRIVE RESET GO
021432	104414			CNT, RDY		: THIS IS A CALL FOR 'CN, RDY'
						: ROUTINE WHICH WAITS FOR CNT
						: RDY TO SET. IF CNTRL RDY DOES
						: NOT SET WITHIN 883 MS/ 11-20
						: (176 MS FOR 11-45 WITH BIPOLAR)
						: AN ERROR IS REPORTED
						: DID R/W/S RDY SET?
021434	032777	000100	157664	:S: BIT	#100, DRKDS	
021442	001013			BNE	25	
021444	012746	177770		MOV	#-10, -(SP)	: PUSH COUNT ON SP
021450	005216			INC	(SP)	: COUNT IT DOWN
021454	001376			BNE	-2	
021458	005726			TST	(SP)+	: POP UP SP
021462	005237	001364		INC	COUNT1	: IF NOT WAIT
021466	001364			BNE	15	: WAITED LONG
021470	004737	020702		JSR	PC, GT4RG	
021474	000402			BR	25+4	
021478	002715	000002		:S: ADD	#2, DR6	
021476	000207			RTS	PC	

.SBTTL TSTSIN: CHECK 'SIN' ROUTINE

```

:TSTSIN
:THIS ROUTINE CHECKS IF 'SIN' IS SET, IF IT IS SET A
:DRIVE RESET IS DONE TO CLEAR 'SIN' AND INITIALIZE POSITIONER.
:CALL: TST.SIN
:IF ON DOING DRIVE RESET R/W/S RDY DOES NOT SET A MESSAGE
:ERROR PC=XXXXXX IS GIVEN.
:XXXXXX=PC IN THE MAIN PROGRAM WHERE 'TST.SIN' CALL IS LOCATED.

```

021500	013777	001350	157632	TSTSIN: MOV	DRIVAD, DRKDA	: ADRES THE DRIVE
021506	032777	001000	157612	BIT	#1000, DRKDS	: IS SIN SET?
021514	001403			BEQ	15	

```

5555 021516 004737 021412 JSR PC,DRESET ;GO DO DRIVE RESET, SIN SET
5556 021522 000401 BR 25 ;REPORT ERROR
5557 021524 000002 ;S: RTI
5558 021526 032777 020000 157404 ;S: BIT #SW13,2SWR ;INHIBIT TYPEOUT?
5559 021534 001373 SNE 15 ;IF YES, SKIP TYPEOUT
5560 021536 104401 021544 TYPE 655 ;TYPE ASCIZ STRING
5561 021542 000406 BR 645 ;GET OVER THE ASCIZ
5562 ;:655: .ASCIZ /ERROR PC= /
5563 645:
5564 021560 C11646 MOV (SP),-(SP)
5565 021562 062716 177776 ADC #-2,(SP) ;GET THE PC WHERE 'TST.SIN' IS LOCATED
5566 021566 104402 TPOC ;GO TYPE OUT PC
5567 021570 000755 BR 15

```

.SBTTL DELAY: TIME DELAY ROUTINE

```

:DELAY
:THIS ROUTINE PROVIDES A VARIABLE TIME DELAY. THE CALL FOR THIS
:ROUTINE IS AN ENCODED 'TRAP' INSTRUCTION.
:CALL: DELAY ,N N IS ANY OCTAL NO. FROM 1 TO 177777
:THE DELAY PROVIDED IS 7.5N US (CONVERT N TO DECIMAL) FOR 11/20
:1.5N US FOR 11/45
:IF THE USER WANTS TO CHANGE THE DELAY TIME (EXMP: SHORTER DELAY TO
:GET A TIGHTER SCOPE LOOP) THE VARIABLE 'N' FOLLOWING 'DELAY' SHOULD
:BE CHANGED TO SUIT THE INDIVIDUAL NEED.

```

```

5583 021572 017637 000000 001366 DELAY: MOV 2(SP),TIMER ;GET 'AMOUNT' (N) FOR WHICH
5584 021600 062716 000002 ADD #2,(SP) ;DELAY IS TO BE PROVIDED
5585 ;ADJUST STACK POINTER TO SKIP OVER 'N'
5586 021604 005337 001366 ;S: DEC TIMER ;COUNT DOWN TO 0
5587 021610 001375 IS
5588
5589 021612 000002 RTI ;RETURN TO MAIN PROGRAM

```

.SBTTL WAT.INT: WAIT FOR INTERRUPT ROUTINE

```

:WAT.INT
:THIS ROUTINE PROVIDES A VARIABLE TIME WAIT LOOP DURING WHICH AN INTERRUPT
:FROM RK11 CAN OCCUR. THE CALL IS AN ENCODED 'TRAP' INSTRUCTION.
:CALL: WAT.INT ,N N IS ANY OCTAL NO. FROM 1 TO 177777
:WAIT LOOP TIME= APPROX. 7.5N US (CONVERT N TO DECIMAL) FOR 11/20
:APPROX. 1.5N US FOR 11/45
:UPON ENTERING THE ROUTINE THE CPU PRIORITY IS DROPPED SO THAT
:RK11 CAN INTERRUPT. NOTE THAT WHEN RK11 INTERRUPTS THIS ROUTINE
:IS EXITED WITHOUT POPPING THE STACK. THIS POPPING IS DONE AFTER GETTING
:TO RK11 INTERRUPT HANDLER.
:IF FOR ANY REASON THE WAIT LOOP TIME HAS TO BE CHANGED IT CAN BE DONE
:BY SIMPLY CHANGING THE VARIABLE 'N' FOLLOWING THE 'WAT.INT'.

```

5600

D10

NOEC-11-DZKk-C MACY:1 27(1006) 04-OCT-76 16:06 PAGE 103
 DZKk.C.P11 22-SEP-76 08:47 WAT.INT: WAIT FOR INTERRUPT ROUTINE SEQ 0120

```

56:01 021614 017637 000000 001366 WATINT: MOV 2(SP),TIMER ;GET 'AMOUNT' (N) FOR WHICH
56:02 021622 062716 000002 ;WAITING IS TO BE DONE
56:03 ;ADJUST STACK POINTER FOR CORRECT RETURN
56:04 021626 013746 001400 MOV RKPRI,-SP ;DROP CPU PRIORITY SO THAT RK11 CAN
56:05 021632 012746 021640 MOV #15,-(SP) ; INTERRUPT
56:06 021636 000002 RTI
56:07 021640 005337 001366 IS: DEC TIMER ;WAIT FOR RK11 TO INTERRUPT
56:08 021644 001375 BNE IS
56:09 ;IF INTERRUPT HAS NOT OCCURED BY NOW
56:10 ;RETURN AND REPORT ERROR
56:11 021646 000002 RTI ;EXIT
  
```

```

;WATIME
WATIME: CLR RO
          CLR RI
IS:      INC RO
          BNE IS
          INCB RI
          BNE IS
          RTS PC
  
```

.SBTTL CHKCRDY: CHECK CONTROL READY

```

;:CH.CRDY
;:THIS ROUTINE WAITS FOR THE CONTROL READY TO SET. IF THE CONTROL READY BIT
;:DOES NOT SET WITHIN A CERTAIN TIME, THEN THE CONTENTS OF RKCS, RKER, RKDS
;:AND RKDA ARE SAVED AND AN EXIT MADE TO THE ERROR MESSAGE FOLLOWING THE
;:JSR CALL FOR THIS ROUTINE.
;:IF CONTROL READY SETS THEN THE RETURN ADDRESS IS ADJUSTED TO SKIP THE
;:ERROR MESSAGE ON RETURN.
;CALL: CHKCRDY
;      ERROR ;RETURN HERE IF ERROR
;      --- ;RETURN HERE IF NO ERROR
  
```

```

56:49 021666 005037 001366 CH.CRDY: CLR TIMER
56:50 021672 105777 157434 IS: TSTB 2RKCS ;CNTRL RDY SET?
56:51 021676 100406 BMI 2S ;YES
56:52 021700 005237 001366 INC TIMER
56:53 021704 001372 BNE IS ;NO, WAIT
56:54 021706 004737 020702 JSR PC,GT4RG ;SAVE RKCS, ER, DS, DA
56:55 021712 000002 RTI
56:56
56:57 021714 062716 000002 2S: ADD #2,(SP) ;ADJUST RETURN ADDRESS TO
56:58 021720 000002 RTI ;SKIP ERROR MESSAGE ON RETURN
  
```

.SBTTL CON.RESET: CONTROL REST ROUTINE

```

;CON.RESET
;THIS ROUTINE ISSUES A CONTROL RESET AND WAITS FOR
;THE 'CNTRL RDY' FLAG TO SET. WHEN THE FLAG SETS
;AN EXIT IS MADE OUT OF THE ROUTINE. IF 'CNTRL-RDY'
  
```

56:59
56:60
56:61
56:62
56:63
56:64
56:65
56:66

E10

MAINDEC-11-DZAKK-D MACY11 27(1006) 04-OCT-76 16:06 PAGE 104
DZAKK.D.P11 22-SEP-76 08:47

CON.RESET: CONTROL REST ROUTINE

SEQ 0121

5667 :DOES NOT SET WITHIN A CERTAIN TIME AN ERROR MESSAGE
5668 : CNT RDY DIDN'T SET
5669 : PC=XXXXXX RKCS=YYYYYY
5670 : IS GIVEN. NOTE THAT XXXXXX IS THE PC WHERE 'CNT.RESET' OR 'CNT.RDY'
5671 : IS CALLED.

5672 :CALL: CNT.RESET
5673
5674
5675
5676
5677

5678 .SBTTL CNT.RDY: WAIT FOR CONTROL READY ROUTINE
5679

5680 :CN.RDY
5681 :THIS ROUTINE WAITS FOR THE CONTROL READY BIT TO SET AND WHEN IT
5682 :SETS EXITS OUT. IF WITHIN A CERTAIN TIME CNTRL RDY DOES
5683 :NOT SET AN ERROR IS REPORTED. WAITING TIME IS 883 MS FOR 11/20
5684 :175 MS FOR 11/45 WITH BIPOLAR MEMORY.
5685 :CALL: CNT.RDY

5686 021722 012777 000001 157402 CN.RST: MOV #1, @RKCS ;ISSUE A CONTROL RESET
5687 021730 012737 177500 001170 MOV #-300, \$REG3 ;SET UP COUNT
5688 021736 003402 BR CN.RDY+4 ;SKIP OVER CN.RDY
5689 021740 005037 001170 CN.RDY: CLR \$REG3
5690 021744 105777 157362 1\$: TSTB @RKCS ;DID CNTRL-RDY SET?
5691 021750 100435 BMI 3\$;YES, EXIT
5692 021752 005237 001170 INC \$REG3 ;WAITED LONG?
5693 021756 001372 BNE 1\$;IF NOT, GO BAK & WAIT
5694 021760 032777 020000 157152 2\$: BIT #SW13, @SWR ;INHIBIT TYPEOUT?
5695 021766 001026 BNE 3\$;IF YES, SKIP TYPEOUT
5696 021770 104401 TYPE
5697 021772 001245 MSG3
5698 021774 104401 022002 TYPE 65\$;:TYPE ASCIZ STRING
5699 022000 000403 BR 64\$;:GET OVER THE ASCIZ

5700 65\$: .ASCIZ <15><12>/PC=
5701 022010 64\$: MOV (SP), -(SP)
5702 022010 011646 SJB #2, (SP)
5703 022012 162716 000002 TYPOC ;GO TYPE PC IN THE MAIN PROGRAM,
5704 022016 104402 ; WHERE ERROR OCCURRED
5705 ;:TYPE ASCIZ STRING
5706 022020 104401 022026 TYPE 67\$;:GET OVER THE ASCIZ
5707 022024 000404 BR 66\$;:TYPE ASCIZ STRING
5708 ;:GET OVER THE ASCIZ

5709 022036 66\$: .ASCIZ / RKCS=
5710 022036 017746 157270 MOV @RKCS, -(SP) ;GET RKCS
5711 022042 104402 TYPOC ;GO TYPE IT
5712
5713 022044 000002 3\$: RTI ;RETURN FROM THIS
5714 ;ROUTINE TO THE MAIN
5715 ;PROGRAM
5716
5717
5718
5719

5720 :THIS PART OF THE PROGRAM CONTAINS THE COMMON ROUTINES CALLED
5721 :FROM THE SYSMAC.SML PACKAGE
5722

.SBTTL SCOPE HANDLER ROUTINE

F10

MAINDEC-11-DZRKK-D MACY11 27(1006) 04-OCT-76 16:06 PAGE 105
DZRKKD.P11 22-SEP-76 08:47 SCOPE HANDLER ROUTINE

SEQ 0122

5723
5724
5725
5726
5727
5728
5729
5730
5731
5732
5733
5734
5735
5736
5737
5738
5739
5740
5741
5742
5743
5744
5745
5746
5747
5748
5749
5750
5751
5752
5753
5754
5755
5756
5757
5758
5759
5760
5761
5762
5763
5764
5765
5766
5767
5768
5769
5770
5771
5772
5773
5774
5775
5776
5777
5778

022046
022046 104407
022050 032777 040000 157062
022056 001111
022060 000416
022062 013746 000004
022066 012737 022106 000004
022074 005737 177060
022100 012637 000004
022104 000463
022106 022626
022110 012637 000004
022114 000423
022116
022116 032777 000400 157014
022124 001404
022126 127737 157006 001102
022134 001462
022136 105737 001103
022142 001421
022144 123737 001115 001103
022152 101015
022154 032777 001000 156756
022162 001404
022164 013737 001110 001106
022172 000443
022174 105037 001103
022200 005037 001206
022204 000415
022206 032777 004000 156724
022214 001011
022216 005737 001100
022222 001406
022224 005237 001104
022230 023737 001206 001104
022236 002021
022240 012737 000001 001104
022246 013737 022316 001206
022254 105237 001102
022260 011637 001106
022264 011637 001110

```
*****  
*THIS ROUTINE CONTROLS THE LOOPING OF SUBTESTS. IT WILL INCREMENT  
*AND LOAD THE TEST NUMBER($STNM) INTO THE DISPLAY REG.(DISPLAY<7:0>)  
*AND LOAD THE ERROR FLAG ($ERFLG) INTO DISPLAY<15:08>  
*THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:  
*SW14=1 LOOP ON TEST  
*SW11=1 INHIBIT ITERATIONS  
*SW09=1 LOOP ON ERROR  
*SW08=1 LOOP ON TEST IN SWR<7:0>  
*CALL  
* SCOPE ;:SCOPE=IOT  
$SCOPE:  
CKSWR ;:TEST FOR CHANGE IN SOFT-SWR  
1$: BIT #BIT14,$SWR ;:LOOP ON PRESENT TEST?  
BNE $OVER ;:YES IF SW14=1  
*****START OF CODE FOR THE XOR TESTER*****  
$XTSTR: BR 6$ ;:IF RUNNING ON THE "XOR" TESTER CHANGE  
 ;:THIS INSTRUCTION TO A "NOP" (NOP=240)  
 ;:SAVE THE CONTENTS OF THE ERROR VECTOR  
MOV 2$ERRVEC,-(SP) ;:SET FOR TIMEOUT  
MOV 2$,$ERRVEC ;:TIME OUT ON XOR?  
TST 2$177060 ;:RESTORE THE ERROR VECTOR  
MOV (SP)+,2$ERRVEC ;:GO TO THE NEXT TEST  
BR $SVLAD ;:CLEAR THE STACK AFTER A TIME OUT  
5$: CMP (SP)+,(SP)+ ;:RESTORE THE ERROR VECTOR  
MOV (SP)+,2$ERRVEC ;:LOOP ON THE PRESENT TEST  
BR 7$  
6$;*****END OF CODE FOR THE XOR TESTER*****  
BIT #BIT08,$SWR ;:LOOP ON SPEC. TEST?  
BEQ 2$ ;:BR IF NO  
CMPB 2$SWR,$STNM ;:ON THE RIGHT TEST? SWR<7:0>  
BEQ $OVER ;:BR IF YES  
2$: TSTB $ERFLG ;:HAS AN ERROR OCCURRED?  
BEQ 3$ ;:BR IF NO  
CMPB $ERMAX,$ERFLG ;:MAX. ERRORS FOR THIS TEST OCCURRED?  
BHI 3$ ;:BR IF NO  
BIT #BIT09,$SWR ;:LOOP ON ERROR?  
BEQ 4$ ;:BR IF NO  
7$: MOV $LPERR,$LPADR ;:SET LOOP ADDRESS TO LAST SCOPE  
BR $OVER  
4$: CLRB $ERFLG ;:ZERO THE ERROR FLAG  
CLR $TIMES ;:CLEAR THE NUMBER OF ITERATIONS TO MAKE  
BR 1$ ;:ESCAPE TO THE NEXT TEST  
3$: BIT #BIT11,$SWR ;:INHIBIT ITERATIONS?  
BNE 1$ ;:BR IF YES  
TST $PASS ;:IF FIRST PASS OF PROGRAM  
BEQ 1$ ;:INHIBIT ITERATIONS  
INC $ICNT ;:INCREMENT ITERATION COUNT  
CMP $TIMES,$ICNT ;:CHECK THE NUMBER OF ITERATIONS MADE  
BGE $OVER ;:BR IF MORE ITERATION REQUIRED  
1$: MOV #1,$ICNT ;:REINITIALIZE THE ITERATION COUNTER  
MOV $MXCNT,$TIMES ;:SET NUMBER OF ITERATIONS TO DO  
$SVLAD: INCB $STNM ;:COUNT TEST NUMBERS  
MOV (SP),$LPADR ;:SAVE SCOPE LOOP ADDRESS  
MOV (SP),$LPERR ;:SAVE ERROR LOOP ADDRESS
```

```

5779 022270 005037 001210          CLR      $ESCAPE      ;; CLEAR THE ESCAPE FROM ERROR ADDRESS
5780 022274 112737 000001 001115      MOV      #1,$ERRMAX   ;; ONLY ALLOW ONE(1) ERROR ON NEXT TEST
5781 022302 013777 001102 156632 $OVER:  MOV      $TSTNM,$DISPLAY ;; DISPLAY TEST NUMBER
5782 022310 013716 001106          MOV      $LPADR,(SP) ;; FUDGE RETURN ADDRESS
5783 022314 000002          RTI                ;; FIXES PS
5784 022316 000050 $MXCNT: 50          ;; MAX. NUMBER OF ITERATIONS
5785
5786
5787
5788
5789
5790
5791
5792
5793
5794
5795
5796
5797
5798
5799 022320 104407          $ERROR: CKSWR      ;; CHECK FOR SOFTWARE SWITCH REGISTER REQUEST
5800 022322 105237 001103      7$:      INCB      $ERFLG      ;; SET THE ERROR FLAG
5801 022326 001775          BEQ      7$          ;; DON'T LET THE FLAG GO TO ZERO
5802 022330 013777 001102 156604      MOV      $TSTNM,$DISPLAY ;DISPLAY TEST NUMBER AND ERROR FLAG
5803 022336 005237 001112      1$:      INC      $ERTTL      ;; COUNT THE NUMBER OF ERRORS
5804
5805 022342 032777 000100 156570      BIT      #BIT6,$SWR      ;; DESELECT DRIVE SW SET?
5806 022350 001404          BEQ      6$          ;; NO
5807 022352 023727 001112 000005      CMP      $ERTTL,#5      ;; MORE THAN 5 ERRORS ON THIS DRIVE?
5808 022360 101047          BHI      8$          ;; YES, DESELC THE DRIVE
5809
5810 022362 011637 001116      6$:      MOV      (SP),$ERRPC      ;; GET ADDRESS OF ERROR INSTRUCTION
5811 022366 162737 000002 001116      SUB      #2,$ERRPC
5812 022374 117737 156516 001114      MOV      #2,$ERRPC      ;; STRIP AND SAVE THE ERROR ITEM CODE
5813 022402 032777 020000 156530      MOV      $ERRPC,$ITEMB ;; SKIP TYPEOUT IF SET
5814 022410 001004          BIT      #SW13,$SWR      ;; SKIP TYPEOUTS
5815 022412 004737 022632      BNE      2$          ;; GO TO USER ERROR ROUTINE
5816 022416 104401 001213      JSR      PC,$ERRRYP
5817 022422 005777 156512      TYPE      $CRLF
5818 022426 100002      2$:      TST      $SWR          ;; HALT ON ERROR
5819 022430 000000          BPL      3$          ;; SKIP IF CONTINUE
5820 022432 104407          HALT
5821 022434 032777 010000 156476      CKSWR      ;; CHECK FOR SOFTWARE SWITCH REGIATER REQUEST
5822 022442 001402      3$:      BIT      #SW12,$SWR      ;; SW 12 SET?
5823 022444 013716 001106          BEQ      .+6          ;; NO, BRANCH
5824 022450 032777 001000 156462      MOV      $LPADR,(SP) ;; ADJUST RETURN ADRES FOR SW12
5825 022456 001402          BIT      #SW09,$SWR      ;; LOOP ON ERROR SWITCH SET?
5826 022460 013716 001110          BEQ      4$          ;; BR IF NO
5827 022464 005737 001210      MOV      $LPERR,(SP) ;; FUDGE RETURN FOR LOOPING
5828 022470 001402      4$:      TST      $ESCAPE      ;; CHECK FOR AN ESCAPE ADDRESS
5829 022472 013716 001210          BEQ      5$          ;; BR IF NONE
5830 022476 000002      MOV      $ESCAPE,(SP) ;; FUDGE RETURN ADDRESS FOR ESCAPE
5831
5832
5833
5834 022500 005737 001434      5$:      RTI                ;; RETURN
5835
5836
5837
5838
5839
5840
5841
5842
5843
5844 022504 001407      8$:      TST      T56FLG      ;; IF EROR WAS IN LAST TEST (POLL)
5845
5846
5847
5848
5849
5850
5851
5852
5853
5854
5855
5856
5857
5858
5859
5860
5861
5862
5863
5864
5865
5866
5867
5868
5869
5870
5871
5872
5873
5874
5875
5876
5877
5878
5879
5880
5881
5882
5883
5884
5885
5886
5887
5888
5889
5890
5891
5892
5893
5894
5895
5896
5897
5898
5899
5900
5901
5902
5903
5904
5905
5906
5907
5908
5909
5910
5911
5912
5913
5914
5915
5916
5917
5918
5919
5920
5921
5922
5923
5924
5925
5926
5927
5928
5929
5930
5931
5932
5933
5934
5935
5936
5937
5938
5939
5940
5941
5942
5943
5944
5945
5946
5947
5948
5949
5950
5951
5952
5953
5954
5955
5956
5957
5958
5959
5960
5961
5962
5963
5964
5965
5966
5967
5968
5969
5970
5971
5972
5973
5974
5975
5976
5977
5978
5979
5980
5981
5982
5983
5984
5985
5986
5987
5988
5989
5990
5991
5992
5993
5994
5995
5996
5997
5998
5999
6000

```

```

5835 022506 104401 001303          TYPE      MSG5
5836 022512 005037 001412          CLR      DRIVS
5837 022516 022626          CMP      (SP)+,(SP)+
5838 022520 000137 020560          JMP      SEOP
5839 022524 013746 001354          10$:    MOV     DRVPT,-(SP)          ;DROP THE DRIVE FROM THE
5840 022530 162716 000002          SUB     #2,(SP)          ;SELECTION LIST
5841 022534 013746 001350          MOV     DRIVAD,-(SP)     ;DRIVE ADDR TO STACK
5842 022540 004737 021106          JSR     PC,SHFRT        ;RIGHT JUSTIFY
5843 022544 042716 000001          BIC     #1,(R6)         ;MAKE EVEN
5844 022550 062716 001414          ADD     #DRIVO,(SP)     ;POINTS TO TABLE FOR EVEN DRIVE
5845 022554 042776 100000 000000          BIC     #BIT15,@(R6)    ;TEST REMAINING DRIVE AS RK05E
5846 022562 062716 000002          ADD     #2,(R6)         ;POINT TO ODD
5847 022566 042736 100000          BIC     #BIT15,@(SP)+   ;TEST AS RK-05E
5848 022572 012736 010000          MOV     #BIT12,@(SP)+   ;INDICATE THIS DRIVE DROPPED
5849 022576 104401 001272          TYPE    MSG4
5850 022602 013746 001350          MOV     DRIVAD,-(R6)    ;PUSH DRIVE # ON STACK
5851 022606 004737 021106          JSR     PC,SHFRT        ;SHIFT IT BEFORE TYPING
5852 022612 104402          TYPOC   ;TYPE OUT DRIVE #
5853 022614 104401 001315          TYPE    MSG6
5854 022620 005337 001412          DEC     DRIVS          ;DECREMENT # OF DRIVES PRESENT
5855 022624 022626          9$:    CMP     (SP)+,(SP)+   ;RESTORE STACK
5856 022626 000137 017734          JMP     BTEOP          ;GO BACK TO THE END OF PROGRAM
5857
5858
5859
5860
5861
5862
5863
5864
5865
5866
5867
5868
5869
5870
5871
5872
5873
5874
5875
5876
5877
5878
5879
5880
5881
5882
5883
5884
5885
5886
5887
5888
5889
5890

```

.SBTTL ERROR MESSAGE TYPEOUT ROUTINE

```

;*****
;THIS ROUTINE USES THE "ITEM CONTROL BYTE" ($ITEMB) TO DETERMINE WHICH
;ERROR IS TO BE REPORTED. IT THEN OBTAINS, FROM THE "ERROR TABLE" ($ERRTB),
;AND REPORTS THE APPROPRIATE INFORMATION CONCERNING THE ERROR.

```

```

$ERRTYP:
          TYPE    $SCRLF          ;; "CARRIAGE RETURN" & "LINE FEED"
          MOV     RO,-(SP)        ;; SAVE RO
          CLR     RO              ;; PICKUP THE ITEM INDEX
          BISB    @#$ITEMB,RO
          BNE     IS
          MOV     $ERRPC,-(SP)    ;; IF ITEM NUMBER IS ZERO, JUST
          ;; TYPE THE PC OF THE ERROR
          ;; SAVE $ERRPC FOR TYPEOUT
          ;; ERROR ADDRESS
          ;; GO TYPE--OCTAL ASCII(ALL DIGITS)
          ;; GET OUT
          1$:    DEC     RO          ;; ADJUST THE INDEX SO THAT IT WILL
          ASL     RO              ;; WORK FOR THE ERROR TABLE
          ASL     RO
          ASL     RO
          ADD     # $ERRTB,RO     ;; FORM TABLE POINTER
          MOV     (RO)+,2$        ;; PICKUP "ERROR MESSAGE" POINTER
          BEQ     3$              ;; SKIP TYPEOUT IF NO POINTER
          TYPE    "ERROR MESSAGE"
          ;; "ERROR MESSAGE" POINTER GOES HERE
          2$:    .WORD 0          ;; "CARRIAGE RETURN" & "LINE FEED"
          TYPE    $SCRLF          ;; "CARRIAGE RETURN" & "LINE FEED"
          3$:    MOV     (RO)+,4$   ;; PICKUP "DATA HEADER" POINTER
          BEQ     5$              ;; SKIP TYPEOUT IF 0
          TYPE    "DATA HEADER"
          4$:    .WORD 0          ;; "DATA HEADER" POINTER GOES HERE

```

5891 022724 104401 001213
5892 022730 011000
5893 022732 001004
5894 022734 012600
5895 022736 104401 001213
5896 022742 000207
5897 022744
5898 022744 013046
5899 022746 104402
5900 022750 005710
5901 022752 001770
5902 022754 104401 022762
5903 022760 000771
5904 022762 020040 000
5905 022766
5906
5907
5908
5909
5910
5911
5912
5913
5914
5915
5916
5917
5918
5919
5920
5921
5922
5923
5924 022766 105737 001157
5925 022772 100002
5926 022774 000000
5927 022776 000407
5928 023000 010046
5929 023002 017600 000002
5930 023006 112046
5931 023010 001005
5932 023012 005726
5933 023014 012600
5934 023016 062716 000002
5935 023022 000002
5936 023024 122716 000011
5937 023030 001430
5938 023032 122716 000200
5939 023036 001006
5940 023040 005726
5941 023042 104401
5942 023044 001213
5943 023046 105037 023202
5944 023052 000755
5945 023054 004737 023136
5946 023060 123726 001156

```

55:   TYPE      $CRLF          ;; "CARRIAGE RETURN" & "LINE FEED"
      MOV      (RO),RO        ;; PICKUP "DATA TABLE" POINTER
      BNE      7$             ;; GO TYPE THE DATA
65:   MOV      (SP)+,RO        ;; RESTORE RO
      TYPE     $CRLF          ;; "CARRIAGE RETURN" & "LINE FEED"
      RTS     PC              ;; RETURN
75:   MOV      2(RO)+,-(SP)    ;; SAVE 2(RO)+ FOR TYPEOUT
      TYPOC                    ;; GO TYPE--OCTAL ASCII(ALL DIGITS)
      TST     (RO)            ;; IS THERE ANOTHER NUMBER?
      BEQ     6$              ;; BR IF NO
      TYPE     8$             ;; TYPE TWO(2) SPACES
85:   BR       7$             ;; LOOP
      .ASCIZ  ' / /          ;; TWO(2) SPACES
      .EVEN

```

.SBTTL TYPE ROUTINE

```

*****
*ROUTINE TO TYPE ASCIZ MESSAGE. MESSAGE MUST TERMINATE WITH A 0 BYTE.
*THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED.
*NOTE1: $NULL CONTAINS THE CHARACTER TO BE USED AS THE FILLER CHARACTER.
*NOTE2: $FILLS CONTAINS THE NUMBER OF FILLER CHARACTERS REQUIRED.
*NOTE3: $FILLC CONTAINS THE CHARACTER TO FILL AFTER.
*
*CALL:
*1) USING A TRAP INSTRUCTION
*   TYPE      ,MESADR        ;;MESADR IS FIRST ADDRESS OF AN ASCIZ STRING
*OR
*   TYPE      MESADR
*
5TYPE: TSTB     $TPFLG        ;; IS THERE A TERMINAL?
      BPL     1$             ;; BR IF YES
      HALT                    ;; HALT HERE IF NO TERMINAL
      BR     3$             ;; LEAVE
1$:   MOV      RO,-(SP)       ;; SAVE RO
      MOV      2(SP),RO      ;; GET ADDRESS OF ASCIZ STRING
2$:   MOVB    (RO)+,-(SP)    ;; PUSH CHARACTER TO BE TYPED ONTO STACK
      BNE     4$             ;; BR IF IT ISN'T THE TERMINATOR
      TST     (SP)+          ;; IF TERMINATOR POP IT OFF THE STACK
60$:  MOV      (SP)+,RO      ;; RESTORE RO
3$:   ADD     #2,(SP)        ;; ADJUST RETURN PC
      RTI                    ;; RETURN
4$:   CMPB    #HT,(SP)       ;; BRANCH IF <HT>
      BEQ     8$             ;; BRANCH IF NOT <CRLF>
      BNE     5$             ;; POP <CR><LF> EQUIV
      TST     (SP)+          ;; TYPE A CR AND LF
5942: TYPE     $CRLF          ;;
      CLRB    $CHARCNT      ;; CLEAR CHARACTER COUNT
      BR     2$             ;; GET NEXT CHARACTER
5945: JSR     PC,$TYPEPC     ;; GO TYPE THIS CHARACTER
6$:   CMPB    $FILLC,(SP)+  ;; IS IT TIME FOR FILLER CHARS.?

```

```

5947 023064 001350      BNE      2$          ;; IF NO GO GET NEXT CHAR.
5948 023066 013746 001154  MOV      $NULL,-(SP) ;; GET # OF FILLER CHARS. NEEDED
5949                                     ;; AND THE NULL CHAR.
5950 023072 105366 000001  7$:  DECB   1(SP)      ;; DOES A NULL NEED TO BE TYPED?
5951 023076 002770      BLT      6$          ;; BR IF NO--GO POP THE NULL OFF OF STACK
5952 023100 004737 023136  JSR     PC,$TYPEC    ;; GO TYPE A NULL
5953 023104 105337 023202  DECB   $CHARCNT     ;; DO NOT COUNT AS A COUNT
5954 023110 000770      BR      7$          ;; LOOP
5955
5956                                     ;HORIZONTAL TAB PROCESSOR
5957
5958 023112 112716 000040  8$:  MOV   #' (SP)      ;; REPLACE TAB WITH SPACE
5959 023116 004737 023136  9$:  JSR   PC,$TYPEC    ;; TYPE A SPACE
5960 023122 132737 000007 023202  BITB  #',$CHARCNT    ;; BRANCH IF NOT AT
5961 023130 001372      BNE     9$          ;; TAB STOP
5962 023132 005726      TST   (SP)+        ;; POP SPACE OFF STACK
5963 023134 000724      BR    2$          ;; GET NEXT CHARACTER
5964 023136 105777 156006  $TYPEC: TSTB  $STPS    ;; WAIT UNTIL PRINTER IS READY
5965 023142 100375      BPL   $TYPEC
5966 023144 116677 000002 156000  MOVB  2(SP),$STPB    ;; LOAD CHAR TO BE TYPED INTO DATA REG.
5967 023152 122766 000015 000002  CMPB  #CR,2(SP)     ;; IS CHARACTER A CARRIAGE RETURN?
5968 023160 001003      BNE   1$          ;; BRANCH IF NO
5969 023162 105037 023202  CLRB  $CHARCNT     ;; YES--CLEAR CHARACTER COUNT
5970 023166 000406      BR    $TYPEX
5971 023170 122766 000012 000002  1$:  CMPB  #LF,2(SP)  ;; IS CHARACTER A LINE FEED?
5972 023176 001402      BEQ   $TYPEX      ;; BRANCH IF YES
5973 023200 105227      INCB (PC)+        ;; COUNT THE CHARACTER
5974 023202 000000  $CHARCNT: .WORD  0 ;; CHARACTER COUNT STORAGE
5975 023204 000207  $TYPEX: RTS      PC
5976
5977
5978                                     .SBTTL CONVERT BINARY TO DECIMAL AND TYPE ROUTINE
5979
5980                                     ;*****
5981                                     ;*THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 5-DIGIT
5982                                     ;*SIGNED DECIMAL (ASCII) NUMBER AND TYPE IT. DEPENDING ON WHETHER THE
5983                                     ;*NUMBER IS POSITIVE OR NEGATIVE A SPACE OR A MINUS SIGN WILL BE TYPED
5984                                     ;*BEFORE THE FIRST DIGIT OF THE NUMBER. LEADING ZEROS WILL ALWAYS BE
5985                                     ;*REPLACED WITH SPACES.
5986                                     ;*CALL:
5987                                     ;*   MOV      NUM,-(SP)      ;; PUT THE BINARY NUMBER ON THE STACK
5988                                     ;*   TYPDS                    ;; GO TO THE ROUTINE
5989
5990 023206  $TYPDS:
5991 023206 010046      MOV   R0,-(SP)      ;; PUSH R0 ON STACK
5992 023210 010146      MOV   R1,-(SP)      ;; PUSH R1 ON STACK
5993 023212 010246      MOV   R2,-(SP)      ;; PUSH R2 ON STACK
5994 023214 010346      MOV   R3,-(SP)      ;; PUSH R3 ON STACK
5995 023216 010546      MOV   R5,-(SP)      ;; PUSH R5 ON STACK
5996 023220 012746 020200  MOV   #20200,-(SP)  ;; SET BLANK SWITCH AND SIGN
5997 023224 016605 000020  MOV   20(SP),R5    ;; GET THE INPUT NUMBER
5998 023230 100004      BPL   1$          ;; BR IF INPUT IS POS.
5999 023232 005405      NEG   R5          ;; MAKE THE BINARY NUMBER POS.
6000 023234 112766 000055 000001  1$:  MOVB  #'-,1(SP)   ;; MAKE THE ASCII NUMBER NEG.
6001 023242 005000      CLR  R0          ;; ZERO THE CONSTANTS INDEX
6002 023244 012703 023422  MOV   #SDBLK,R3    ;; SETUP THE OUTPUT POINTER

```

K10

MAINDEC-11-DZRRK-D
DZRRKC.P11

MACY11 27(1006)
22-SEP-76 08:47

04-JCT-76 16:06 PAGE 110
CONVERT BINARY TO DECIMAL AND TYPE ROUTINE

SEG C127

6003	023250	112723	000040		MOVB	#' ,(R3)+	:: SET THE FIRST CHARACTER TO A BLANK
6004	023254	005002		25:	CLR	R2	:: CLEAR THE BCD NUMBER
6005	023256	016001	023412		MOV	\$DTBL(R0),R1	:: GET THE CONSTANT
6006	023262	160105		35:	SUB	R1,R5	:: FORM THIS BCD DIGIT
6007	023264	002402			BLT	45	:: BR IF DONE
6008	023266	005202			INC	R2	:: INCREASE THE BCD DIGIT BY 1
6009	023270	000774			BR	35	
6010	023272	060105		45:	ADD	R1,R5	:: ADD BACK THE CONSTANT
6011	023274	005702			TST	R2	:: CHECK IF BCD DIGIT=0
6012	023276	001002			BNE	55	:: FALL THROUGH IF 0
6013	023300	105716			TSTB	(SP)	:: STILL DOING LEADING 0'S?
6014	023302	100407			BMI	75	:: BR IF YES
6015	023304	106316		55:	ASLB	(SP)	:: MSD?
6016	023306	103003			BCC	65	:: BR IF NO
6017	023310	116663	000001 177777		MOVB	1(SP),-1(R3)	:: YES--SET THE SIGN
6018	023316	052702	000060	65:	BIS	#'0,R2	:: MAKE THE BCD DIGIT ASCII
6019	023322	052702	000040	75:	BIS	#' ,R2	:: MAKE IT A SPACE IF NOT ALREADY A DIGIT
6020	023326	110223			MOVB	R2,(R3)+	:: PUT THIS CHARACTER IN THE OUTPUT BUFFER
6021	023330	005720			TST	(R0)+	:: JUST INCREMENTING
6022	023332	020027	000010		CMP	R0,#10	:: CHECK THE TABLE INDEX
6023	023336	002746			BLT	25	:: GO DO THE NEXT DIGIT
6024	023340	003002			BGT	85	:: GO TO EXIT
6025	023342	010502			MOV	R5,R2	:: GET THE LSD
6026	023344	000764			BR	65	:: GO CHANGE TO ASCII
6027	023346	105726		85:	TSTB	(SP)+	:: WAS THE LSD THE FIRST NON-ZERO?
6028	023350	100003			BPL	95	:: BR IF NO
6029	023352	116663	177777 177776		MOVB	-1(SP),-2(R3)	:: YES--SET THE SIGN FOR TYPING
6030	023360	105013		95:	CLRB	(R3)	:: SET THE TERMINATOR
6031	023362	012605			MOV	(SP)+,R5	:: POP STACK INTO R5
6032	023364	012603			MOV	(SP)+,R3	:: POP STACK INTO R3
6033	023366	012602			MOV	(SP)+,R2	:: POP STACK INTO R2
6034	023370	012601			MOV	(SP)+,R1	:: POP STACK INTO R1
6035	023372	012600			MOV	(SP)+,R0	:: POP STACK INTO R0
6036	023374	104401	023422		TYPE	\$DBLK	:: NOW TYPE THE NUMBER
6037	023400	016666	000002 000004		MOV	2(SP),4(SP)	:: ADJUST THE STACK
6038	023406	012616			MOV	(SP)+,(SP)	
6039	023410	000002			RTI		:: RETURN TO USER
6040	023412	023420		\$DTBL:	10000.		
6041	023414	001750			1000.		
6042	023416	000144			100.		
6043	023420	000012			10.		
6044	023422	000004		\$DBLK:	.BLKW 4		
6045							
6046				.SBTTL	BINARY TO OCTAL (ASCII) AND TYPE		
6047							
6048				::	*****		
6049				::	*THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 6-DIGIT		
6050				::	*OCTAL (ASCII) NUMBER AND TYPE IT.		
6051				::	*\$TYPOS---ENTER HERE TO SETUP SUPPRESS ZEROS AND NUMBER OF DIGITS TO TYPE		
6052				::	*CALL:		
6053				::	* MOV NUM,-(SP)	::	NUMBER TO BE TYPED
6054				::	* TYPOS	::	CALL FOR TYPEOUT
6055				::	* .BYTE N	::	N=1 TO 6 FOR NUMBER OF DIGITS TO TYPE
6056				::	* .BYTE M	::	M=1 OR 0
6057				::		::	1=TYPE LEADING ZEROS
6058				::		::	0=SUPPRESS LEADING ZEROS

L10

```

6059
6060
6061
6062
6063
6064
6065
6066
6067
6068
6069
6070
6071 023432 017646 000000
6072 023436 116637 000001 023655
6073 023444 112637 023657
6074 023450 062716 000002
6075 023454 000406
6076 023456 112737 000001 023655
6077 023464 112737 000006 023657
6078 023472 112737 000005 023654
6079 023500 010346
6080 023502 010446
6081 023504 010546
6082 023506 113704 023657
6083 023512 005404
6084 023514 062704 000006
6085 023520 110437 023656
6086 023524 113704 023655
6087 023530 016605 000012
6088 023534 005003
6089 023536 006105 1$:
6090 023540 000404 BR
6091 023542 006105 2$:
6092 023544 006105 ROL
6093 023546 006105 ROL
6094 023550 010503 MOV
6095 023552 006103 3$:
6096 023554 105337 023656 ROL
6097 023560 100016 DECB
6098 023562 042703 177770 BPL
6099 023566 001002 BIC
6100 023570 005704 BNE
6101 023572 001403 TST
6102 023574 005204 BEQ
6103 023576 052703 000060 4$:
6104 023602 052703 000040 5$:
6105 023606 110337 023652 MOV
6106 023612 104401 023652 TYPE
6107 023616 105337 023654 7$:
6108 023622 003347 DECB
6109 023624 002402 BGT
6110 023626 005204 BLT
6111 023630 000744 INC
6112 023632 012605 BR
6113 023634 012604 6$:
6114 023636 012603 MOV

```

```

;*
;*STYPON---ENTER HERE TO TYPE OUT WITH THE SAME PARAMETERS AS THE LAST
;*STYPOS OR STYPOC
;*CALL:
;*      MOV      NUM,-(SP)      ;;NUMBER TO BE TYPED
;*      TYPON      ;;CALL FOR TYPEOUT
;*
;*STYPOC---ENTER HERE FOR TYPEOUT OF A 16 BIT NUMBER
;*CALL:
;*      MOV      NUM,-(SP)      ;;NUMBER TO BE TYPED
;*      TYPOC      ;;CALL FOR TYPEOUT
;*
STYPOS: MOV      0(SP),-(SP)      ;;PICKUP THE MODE
        MOV      1(SP),%OFILL    ;;LOAD ZERO FILL SWITCH
        MOV      (SP)+,%SOMODE+1 ;;NUMBER OF DIGITS TO TYPE
        ADD      #2,(SP)         ;;ADJUST RETURN ADDRESS
        BR      STYPON
STYPOC: MOV      #1,%OFILL      ;;SET THE ZERO FILL SWITCH
        MOV      #6,%SOMODE+1    ;;SET FOR SIX(6) DIGITS
STYPON: MOV      #5,%SOCNT      ;;SET THE ITERATION COUNT
        MOV      R3,-(SF)        ;;SAVE R3
        MOV      R4,-(SP)        ;;SAVE R4
        MOV      R5,-(SP)        ;;SAVE R5
        MOV      %SOMODE+1,R4    ;;GET THE NUMBER OF DIGITS TO TYPE
        NEG      R4
        ADD      #6,R4           ;;SUBTRACT IT FOR MAX. ALLOWED
        MOV      R4,%SOMODE      ;;SAVE IT FOR USE
        MOV      %OFILL,R4       ;;GET THE ZERO FILL SWITCH
        MOV      12(SP),R5      ;;PICKUP THE INPUT NUMBER
        CLR      R3              ;;CLEAR THE OUTPUT WORD
        ROL      R5              ;;ROTATE MSB INTO "C"
        BR      3$              ;;GO DO MSB
        ROL      R5              ;;FORM THIS DIGIT
        ROL      R5
        ROL      R5
        MOV      R5,R3
        ROL      R3              ;;GET LSB OF THIS DIGIT
        DECB     %SOMODE         ;;TYPE THIS DIGIT?
        BPL      7$              ;;BR IF NO
        BIC      #177770,R3     ;;GET RID OF JUNK
        BNE     4$              ;;TEST FOR 0
        TST     R4              ;;SUPPRESS THIS 0?
        BEQ     5$              ;;BR IF YES
        INC     R4              ;;DON'T SUPPRESS ANYMORE 0'S
        BIS     #'0,R3          ;;MAKE THIS DIGIT ASCII
        BIS     #' ,R3          ;;MAKE ASCII IF NOT ALREADY
        MOV     R3,%S          ;;SAVE FOR TYPING
        TYPE    %S              ;;GO TYPE THIS DIGIT
        DECB   %SOCNT           ;;COUNT BY 1
        BGT    2$              ;;BR IF MORE TO DO
        BLT    6$              ;;BR IF DONE
        INC    R4              ;;INSURE LAST DIGIT ISN'T A BLANK
        BR    2$              ;;GO DO THE LAST DIGIT
        MOV    (SP)+,R5         ;;RESTORE R5
        MOV    (SP)+,R4         ;;RESTORE R4
        MOV    (SP)+,R3         ;;RESTORE R3

```

M10

```

6115 023640 016666 000002 000004      MOV      2(SP),4(SP)      ;;SET THE STACK FOR RETURNING
6116 023646 012616                MOV      (SP)+,(SP)
6117 023650 000002                RTI
6118 023652 000                8$:      .BYTE      0      ;;RETURN
6119 023653 000                .BYTE      0      ;;STORAGE FOR ASCII DIGIT
6120 023654 000                $OCNT:   .BYTE      C      ;;TERMINATOR FOR TYPE ROUTINE
6121 023655 000                $OFILL:  .BYTE      0      ;;OCTAL DIGIT COUNTER
6122 023656 000000                $OMODE:  .WORD      0      ;;ZERO FILL SWITCH
                                           ;;NUMBER OF DIGITS TO TYPE
6123
6124      .SBTTL  TTY INPUT ROUTINE
6125
6126      ;;*****
6127      .ENABL  LSB
6128
6129      ;;*****
6130      ;;SOFTWARE SWITCH REGISTER CHANGE ROUTINE.
6131      ;;ROUTINE IS ENTERED FROM THE TRAP HANDLER, AND WILL
6132      ;;SERVICE THE TEST FOR CHANGE IN SOFTWARE SWITCH REGISTER TRAP CALL
6133      ;;WHEN OPERATING IN TTY FLAG MODE.
6134 023660 022737 000176 001140  $CKSWR:  CMP      #SWREG,SWR      ;; IS THE SOFT-SWR SELECTED?
6135 023666 001074                BNE      15$              ;; BRANCH IF NO
6136 023670 105777 155250                TSTB    2$TKS            ;; CHAR THERE?
6137 023674 100071                BPL     15$              ;; IF NO, DON'T WAIT AROUND
6138 023676 117746 155244                MOVB    2$TKB,-(SP)      ;; SAVE THE CHAR
6139 023702 042716 177600                BIC     #↑C177,(SP)      ;; STRIP-OFF THE ASCII
6140 023706 022726 000007                CMP     #7,(SP)+        ;; IS IT A CONTROL G?
6141 023712 001062                BNE     15$              ;; NO, RETURN TO USER
6142 023714 123727 001134 000001                CMPB    $AUTOB,#1       ;; ARE WE RUNNING IN AUTO-MODE?
6143 023722 001456                BEQ     15$              ;; BRANCH IF YES
6144
6145 023724 104401 024545                $GTSWR: TYPE    , $CNTLG      ;; ECHO THE CONTROL-G (↑G)
6146 023730 104401 024552                TYPE    , $MSWR         ;; TYPE CURRENT CONTENTS
6147 023734 013746 000176                MOV     SWREG,-(SP)      ;; SAVE SWREG FOR TYPEOUT
6148 023740 104402                TYPOC   , $MNEW         ;; GO TYPE--OCTAL ASCII(ALL DIGITS)
6149 023742 104401 024563                TYPE    , $MNEW         ;; PROMPT FOR NEW SWR
6150 023746 005046 19$:      CLR     -(SP)           ;; CLEAR COUNTER
6151 023750 005046                CLR     -(SP)           ;; THE NEW SWR
6152 023752 105777 155166                7$:     TSTB    2$TKS      ;; CHAR THERE?
6153 023756 100375                BPL     7$              ;; IF NOT TRY AGAIN
6154
6155 023760 117746 155162                MOVB    2$TKB,-(SP)      ;; PICK UP CHAR
6156 023764 042716 177600                BIC     #↑C177,(SP)      ;; MAKE IT 7-BIT ASCII
6157
6158
6159
6160 023770 021627 000025                9$:     CMP     (SP),#25     ;; IS IT A CONTROL-U?
6161 023774 001005                BNE     10$             ;; BRANCH IF NOT
6162 023776 104401 024540                TYPE    , $CNTLU        ;; YES, ECHO CONTROL-U (↑U)
6163 024002 062706 000006                20$:    ADD     #6,SP        ;; IGNORE PREVIOUS INPUT
6164 024006 000757                BR      19$            ;; LET'S TRY IT AGAIN
6165
6166
6167 024010 021627 000015                10$:    CMP     (SP),#15     ;; IS IT A <CR>?
6168 024014 001022                BNE     16$             ;; BRANCH IF NO
6169 024016 005766 000004                TST     4(SP)           ;; YES, IS IT THE FIRST CHAR?
6170 024022 001403                BEQ     11$            ;; BRANCH IF YES

```

```

6171 024024 016677 000002 155106          MOV      2(SP),2SWP      ;;SAVE NEW SWR
6172 024032 062706 000006          11$: ADD      #6,SP      ;;CLEAR UP STACK
6173 024036 104401 001213          14$: TYPE    $CRLF      ;;ECHO <CR> AND <LF>
6174 024042 123727 001135 000001      CMPB    $INTAG,#1      ;;RE-ENABLE TTY KBD INTERRUPTS?
6175 024050 001003          15$: SNE      15$      ;;BRANCH IF NOT
6176 024052 012777 000100 155064      MOV      #100,2STKS    ;;RE-ENABLE TTY KBD INTERRUPTS
6177 024060 000002          15$: RTI      ;;RETURN
6178 024062 004737 023136          16$: JSR      PC,STYPC   ;;ECHO CHAR
6179 024066 021627 000060      CMP      (SP),#60      ;;CHAR < 0?
6180 024072 002420          18$: BLT      18$      ;;BRANCH IF YES
6181 024074 021627 000067      CMP      (SP),#67      ;;CHAR > 7?
6182 024100 003015          18$: BGT      18$      ;;BRANCH IF YES
6183 024102 042726 000060      BIC      #60,(SP)+     ;;STRIP-OFF ASCII
6184 024106 005766 000002      TST      2(SP)         ;;IS THIS THE FIRST CHAR
6185 024112 001403          BEQ      17$          ;;BRANCH IF YES
6186 024114 006316          ASL      (SP)         ;;NO, SHIFT PRESENT
6187 024116 006316          ASL      (SP)         ;;CHAR OVER TO MAKE
6188 024120 006316          ASL      (SP)         ;;ROOM FOR NEW ONE.
6189 024122 005266 000002          17$: INC      2(SP)     ;;KEEP COUNT OF CHAR
6190 024126 056616 177776      BIS      -2(SP),(SP)   ;;SET IN NEW CHAR
6191 024132 000707          BR       7$          ;;GET THE NEXT ONE
6192 024134 104401 001212          18$: TYPE    $QUES     ;;TYPE ?<CR><LF>
6193 024140 000720          BR       20$        ;;SIMULATE CONTROL-U
6194          .DSABL  LSB
6195
6196
6197
6198          ;;*****
6199          ;;THIS ROUTINE WILL INPUT A SINGLE CHARACTER FROM THE TTY
6200          ;;CALL:
6201          ;;      RDCHR          ;;INPUT A SINGLE CHARACTER FROM THE TTY
6202          ;;      RETURN HERE   ;;CHARACTER IS ON THE STACK
6203          ;;                  ;;WITH PARITY BIT STRIPPED OFF
6204          ;;
6205          $RDCHR: MOV      (SP),-(SP)  ;;PUSH DOWN THE PC
6206 024144 016666 000004 000002      MOV      4(SP),2(SP)  ;;SAVE THE PS
6207 024152 105777 154766          1$: TSTB    2STKS     ;;WAIT FOR
6208 024156 100375          BPL      1$          ;;A CHARACTER
6209 024160 117766 154762 000004      MOVB    2STKB,4(SP)   ;;READ THE TTY
6210 024166 042766 177600 000004      BIC      #1C<177>,4(SP) ;;GET RID OF JUNK IF ANY
6211 024174 026627 000004 000023      CMP      4(SP),#23   ;;IS IT A CONTROL-S?
6212 024202 001013          BNE      3$          ;;BRANCH IF NO
6213 024204 105777 154734          2$: TSTB    2STKS     ;;WAIT FOR A CHARACTER
6214 024210 100375          BPL      2$          ;;LOOP UNTIL ITS THERE
6215 024212 117746 154730      MOVB    2STKB,-(SP)  ;;GET CHARACTER
6216 024216 042716 177600      BIC      #1C177,(SP) ;;MAKE IT 7-BIT ASCII
6217 024222 022627 000021      CMP      (SP)+,#21   ;;IS IT A CONTROL-Q?
6218 024226 001366          BNE      2$          ;;IF NOT DISCARD IT
6219 024230 000750          BR       1$          ;;YES, RESUME
6220 024232 026627 000004 000140          3$: CMP      4(SP),#140 ;;IS IT UPPER CASE?
6221 024240 002407          BLT      4$          ;;BRANCH IF YES
6222 024242 026627 000004 000175      CMP      4(SP),#175  ;;IS IT A SPECIAL CHAR?
6223 024250 003003          BGT      4$          ;;BRANCH IF YES
6224 024252 042766 000040 000004      BIC      #40,4(SP)   ;;MAKE IT UPPER CASE
6225 024260 000002          4$: RTI      ;;GO BACK TO USER
6226          ;;*****

```

```

0227          : * THIS ROUTINE WILL INPUT A STRING FROM THE TTY
0228          : * CALL:
0229          : *   RDLIN
0230          : *   RETURN HERE
0231          : * INPUT A STRING FROM THE TTY
0232          : * ADDRESS OF FIRST CHARACTER WILL BE ON THE STACK
0233          : * TERMINATOR WILL BE A BYTE OF ALL 0'S
0234          SRDLIN: MOV     R3, -(SP)      ; SAVE R3
0235          CLR     -(SP)      ; CLEAR THE RUBOUT KEY
0236          15:  MOV     #STTYIN, R3    ; GET ADDRESS
0237          25:  CMP     #STTYIN+22, R3 ; BUFFER FULL?
0238          BLOS   45           ; BR IF YES
0239          RDOCHR ; GO READ ONE CHARACTER FROM THE TTY
0240          MOVB   (SP)+, (R3)    ; GET CHARACTER
0241          105:  CMPB   #177, (R3)   ; IS IT A RUBOUT
0242          BNE   55           ; BR IF NO
0243          TST   (SP)          ; IS THIS THE FIRST RUBOUT?
0244          BNE   65           ; BR IF NO
0245          MOVB   #' \, 95     ; TYPE A BACK SLASH
0246          65:  MOV     #-1, (SP)    ; SET THE RUBOUT KEY
0247          DEC   R3           ; BACKUP BY ONE
0248          CMP   R3, #STTYIN   ; STACK EMPTY?
0249          BLO   45           ; BR IF YES
0250          MOVB   (R3), 95     ; SETUP TO TYPEOUT THE DELETED CHAR.
0251          TYPE  95           ; GO TYPE
0252          BR    25           ; GO READ ANOTHER CHAR.
0253          55:  TST   (SP)          ; RUBOUT KEY SET?
0254          BEQ   75           ; BR IF NO
0255          MOVB   #' \, 95     ; TYPE A BACK SLASH
0256          75:  CLR     (SP)        ; CLEAR THE RUBOUT KEY
0257          CLRB  #25, (R3)     ; IS CHARACTER A CTRL U?
0258          BNE   85           ; BR IF NO
0259          TYPE  $CNTLU       ; TYPE A CONTROL "U"
0260          BR    15           ; GO START OVER
0261          85:  CMPB   #22, (R3)   ; IS CHARACTER A "↑R"?
0262          BNE   35           ; BRANCH IF NO
0263          CLRB  (R3)        ; CLEAR THE CHARACTER
0264          TYPE  $CRLF       ; TYPE A "CR" & "LF"
0265          TYPE  $TTYIN      ; TYPE THE INPUT STRING
0266          BR    25         ; GO PICKUP ANOTHER CHARACTER
0267          45:  TYPE  $QUES     ; TYPE A '?'
0268          BR    15         ; CLEAR THE BUFFER AND LOOP
0269          35:  MOVB   (R3), 95   ; ECHO THE CHARACTER
0270          TYPE  95
0271          CMPB  #15, (R3)+    ; CHECK FOR RETURN
0272          BNE   25         ; LOOP IF NOT RETURN
0273          CLRB  -1(R3)       ; CLEAR RETURN (THE 15)
0274          TYPE  $LF         ; TYPE A LINE FEED
0275          TST  (SP)+        ; CLEAN RUBOUT KEY FROM THE STACK
0276          MOV  (SP)+, R3    ; RESTORE R3
0277          MOV  (SP), -(SP)  ; ADJUST THE STACK AND PUT ADDRESS OF THE
0278          MOV  4(SP), 2(SP) ; FIRST ASCII CHARACTER ON IT
0279          MOV  #STTYIN, 4(SP)
0280          RTI
0281          95:  .BYTE  0
0282

```

6283 024515 000
6284 024516 000022
6285 024540 052536 005015 000
6286 024545 :36 006507 000C12
6287 024552 005015 053523 020122
6288 024560 020075 000
6289 024563 040 047040 053505
6290 024570 036440 000040

.BYTE 0 :: TERMINATOR
\$TTYIN: .BLKB 22 :: RESERVE 22 BYTES FOR TTY INPUT
\$CNTLU: .ASCIZ 'U' <15> <12> :: CONTROL "U"
\$CNTLG: .ASCIZ '<16>' <15> <12> :: CONTROL "G"
\$MSWR: .ASCIZ '<15>' <12> /SWR = /
\$MNEW: .ASCIZ ' / NEW = /

;CONTROL U, RUBOUT CAPABILITY

.SBTTL TRAP DECODER

*THIS ROUTINE WILL PICKUP THE LOWER BYTE OF THE "TRAP" INSTRUCTION
*AND USE IT TO INDEX THROUGH THE TRAP TABLE FOR THE STARTING ADDRESS
*OF THE DESIRED ROUTINE. THEN USING THE ADDRESS OBTAINED IT WILL
*GO TO THAT ROUTINE.

6300 024574 010046
6301 024576 016600 000002
6302 024602 005740
6303 024604 111000
6304 024606 006300
6305 024610 016000 024630
6306 024614 000200

\$TRAP: MOV RO, -(SP) :: SAVE RO
MOV 2(SP), RO :: GET TRAP ADDRESS
TST -(RO) :: BACKUP BY 2
MOV B (RO), RO :: GET RIGHT BYTE OF TRAP
ASL RO :: POSITION FOR INDEXING
MOV \$TRPAD(RO), RO :: INDEX TO TABLE
RTS RO :: GO TO ROUTINE

:: THIS IS USE TO HANDLE THE "GETPRI" MACRO

6311 024616 011646
6312 024620 016666 000004 000002
6313 024626 000002

\$TRAP2: MOV (SP), -(SP) :: MOVE THE PC DOWN
MOV 4(SP), 2(SP) :: MOVE THE PSW DOWN
RTI :: RESTORE THE PSW

.SBTTL TRAP TABLE

*THIS TABLE CONTAINS THE STARTING ADDRESSES OF THE ROUTINES CALLED
*BY THE "TRAP" INSTRUCTION.

6321
6322 024630 024616
6323 024632 022766
6324 024634 023456
6325 024636 023432
6326 024640 023472
6327 024642 023206
6328
6329 024644 023730
6330
6331 024646 023660
6332 024650 024142
6333 024652 024262
6334
6335 024654 021666
6336
6337 024656 021722
6338

ROUTINE

\$TRPAD: .WORD \$TRAP2
\$TYPE :: CALL=TYPE TRAP+1(104401) TTY TYPEOUT ROUTINE
\$TYPOC :: CALL=TYPOC TRAP+2(104402) TYPE OCTAL NUMBER (WITH LEADING ZEROS)
\$TYPOS :: CALL=TYPOS TRAP+3(104403) TYPE OCTAL NUMBER (NO LEADING ZEROS)
\$TYPON :: CALL=TYPON TRAP+4(104404) TYPE OCTAL NUMBER (AS PER LAST CALL,
\$TYPDS :: CALL=TYPDS TRAP+5(104405) TYPE DECIMAL NUMBER (WITH SIGN)
\$GTSWR :: CALL=GTSWR TRAP+6(104406) GET SOFT-SWR SETTING
\$CKSWR :: CALL=CKSWR TRAP+7(104407) TEST FOR CHANGE IN SOFT-SWR
\$RDCHR :: CALL=RDCHR TRAP+10(104410) TTY TYPEIN CHARACTER ROUTINE
\$RDLIN :: CALL=RDLIN TRAP+11(104411) TTY TYPEIN STRING ROUTINE
CH.CRDY :: CALL=CHKCRDY TRAP+12(104412) CHECK CONTROL READY
CN.RST :: CALL=CN*.RESET TRAP+13(104413) CONTROL RESET ROUTINE

6339	024660	021740	CN.RDY	::CALL=CNTR.RDY	TRAP+14(104414)	WAIT FOR CNTRL RDY TO SET
6340						
6341	024662	020764	BDA0	::CALL=BRKDAC	TRAP+15(104415)	BREAK RKDA INTO DR #.CYL,SUR,SEC BITS
6342						
6343	024664	020774	BDA4	::CALL=BRKDA4	TRAP+16(104416)	BREAK RKDA INTO DR #.CYL,SUR,SEC BITS
6344						
6345	024666	021572	DELA.Y	::CALL=DELAY	TRAP+17(104417)	TIME DELAY ROUTINE
6346						
6347	024670	021614	WATINT	::CALL=WAT.INT	TRAP+20(104420)	WAIT FOR RK11 INTERRUPT ROUTINE
6348						
6349	024672	021500	TSTSIN	::CALL=TST.SIN	TRAP+21(104421)	TEST SIN ROUTINE
6350						
6351						
6352						
6353						
6354						
6355						

.SBTTL POWER DOWN AND UP ROUTINES

```

*****
:POWER DOWN ROUTINE
$PWRDN: MOV    $SILLUP, @PWRVEC    ;; SET FOR FAST UP
        MOV    @340, @PWRVEC+2  ;; PRIO:7
        MOV    R0, -(SP)        ;; PUSH R0 ON STACK
        MOV    R1, -(SP)        ;; PUSH R1 ON STACK
        MOV    R2, -(SP)        ;; PUSH R2 ON STACK
        MOV    R3, -(SP)        ;; PUSH R3 ON STACK
        MOV    R4, -(SP)        ;; PUSH R4 ON STACK
        MOV    R5, -(SP)        ;; PUSH R5 ON STACK
        MOV    @SWR, -(SP)      ;; PUSH @SWR ON STACK
        MOV    SP, $SAVR6      ;; SAVE SP
        MOV    @SPWRUP, @PWRVEC  ;; SET UP VECTOR
        HALT
        BR     -2              ;; HANG UP
*****

:POWER UP ROUTINE
$PWRUP: MOV    $SILLUP, @PWRVEC  ;; SET FOR FAST DOWN
        MOV    $SAVR6, SP      ;; GET SP
        CLR    $SAVR6         ;; WAIT LOOP FOR THE TTY
        IS:   INC    $SAVR6     ;; WAIT FOR THE INC
        BNE   IS             ;; OF WORD
        MOV    (SP)+, @SWR     ;; POP STACK INTO @SWR
        MOV    (SP)+, R5      ;; POP STACK INTO R5
        MOV    (SP)+, R4      ;; POP STACK INTO R4
        MOV    (SP)+, R3      ;; POP STACK INTO R3
        MOV    (SP)+, R2      ;; POP STACK INTO R2
        MOV    (SP)+, R1      ;; POP STACK INTO R1
        MOV    (SP)+, R0      ;; POP STACK INTO R0
        MOV    @SPWRDN, @PWRVEC  ;; SET UP THE POWER DOWN VECTOR
        MOV    @340, @PWRVEC+2  ;; PRIO:7
        TYPE   $POWER         ;; REPORT THE POWER FAILURE
        SPWRM: .WORD $POWER    ;; POWER FAIL MESSAGE POINTER
        MOV    (PC)+, (SP)    ;; RESTART AT PFSTR
        SPWRAD: .WORD PFSTR    ;; RESTART ADDRESS
        RTI
        $SILLUP: HALT        ;; THE POWER UP SEQUENCE WAS STARTED
        BR     -2            ;; BEFORE THE POWER DOWN WAS COMPLETE
        $SAVR6: 0            ;; PUT THE SP HERE
        $POWER: .ASCIZ '(15)<12/"POWER"

```

```

6395 025054 000122
6396
6397 .EVEN
6398 025056 004737 021412 FCHECK: JSR PC,DRESET :RESETB DRIVE
6399 025063 104026 ERROR 26
6400 025064 104413 CNT,RESET
6401 025066 013737 001350 025200 MOV DRIVAD,DRHOLD :SAVE DRIVE ADDR
6402 025074 032737 020000 001350 BIT #20000,DRIVAD :SEE IF ODD
6403 025102 001404 BEQ 1$
6404 025104 042737 020000 001350 BIC #20000,DRIVAD :MAKE EVEN
6405 025112 000403 BR 2$
6406 025114 052737 020000 001350 1$: BIS #20000,DRIVAD :MAKE ODD
6407 025122 013777 001350 154210 2$: MOV DRIVAD,ARKDA ;DRIVE ADDR
6408 025130 012777 000011 154174 MOV #11,ARKCS :DRIVE SEEK
6409 025136 104414 CNT,RDY
6410 025140 013777 025200 154172 MOV DRHOLD,ARKDA :OTHER DRIVE
6411 025146 104414 CNT,RDY
6412 025150 032777 000100 154150 BIT #100,ARKDS ;HEADS IN MOTION?
6413 025156 001001 BNE 3$ ;NO 50 RK-05J
6414 025160 005725 TST (R5)+ ;YES RK-05F
6415 025162 013737 025200 001350 3$: MOV DRHOLD,DRIVAD ;RESTORE ADDR
6416 025170 004737 021412 JSR PC,DRESET ;WAIT FOR RESET
6417 025174 104026 ERROR 26
6418 025176 000205 RTS R5
6419 025200 000000 DRHOLD: 0
6420 025202 005037 001350 SIZEF: CLR DRIVAD ;START AT DRO
6421 025206 012700 001414 MOV #DRIVO,RO ;TABLE OF AVAIL DRIVES
6422 025212 005710 4$: TST (RO) ;THIS DRIVE HERE?
6423 025214 001413 BEQ 2$ ;NO
6424 025216 005760 000002 TST 2(RO) ;COMPLEMENT HERE?
6425 025222 001410 BEQ 2$ ;NO
6426 025224 004537 025056 JSR R5,FCHECK ;SEE IF F MODEL
6427 025230 000405 BR 2$ ;J MODEL
6428 025232 052710 100000 BIS #100000,(RO) ;SET SIGN FOR F
6429 025236 052760 100000 000002 BIS #100000,2(RO) ;BOTH DRIVES
6430 025244 005720 2$: TST (RO)+ ;NEXT PAIR OF DRIVES
6431 025246 005720 TST (RO)+ ;NEXT ACTUL ADDR
6432 025250 062737 040000 001350 ADD #40000,DRIVAD ;CHECKED ALL?
6433 025256 022700 001433 CMP #DRIV7+1,RO ;NOT YET
6434 025262 003353 BGT 4$
6435 025264 000207 RTS PC
6436
6437 :ERROR MESSAGES
6438
6439 .SBTTL ERROR MESSAGES
6440
6441 025266 045522 041527 042440 EM11: .ASCIZ /RKWC EROR/
6442 025274 047522 000122
6443
6444
6445 025300 044523 020116 051511 EM12: .ASCIZ /SIN IS SET/
6446 025306 051440 052105 000
6447
6448 025313 122 041113 020101 EM13: .ASCIZ /RKBA EROR/
6449 025320 051105 051117 000
6450

```

6451	025325	122	042113	020101	EM16:	.ASCIZ	/RKDA WRONG AFTER 'SSE' /
6452	025332	051127	047117	020107			
6453	025340	043101	042524	020122			
6454	025346	051447	042523	000047			
6455							
6456	025354	045522	051504	042440	EM21:	.ASCIZ	/RKDS EROR /
6457	025362	047522	000122				
6458							
6459	025366	050104	020114	042523	EM30:	.ASCIZ	/DPL SET /
6460	025374	000124					
6461							
6462	025376	051104	020125	042523	EM31:	.ASCIZ	/DRU SET /
6463	025404	000124					
6464							
6465	025406	045522	032460	041040	EM32:	.ASCIZ	/RKOS BIT NOT SET /
6466	025414	052111	047040	052117			
6467	025422	051440	052105	000			
6468							
6469	025427	104	054522	041040	EM33:	.ASCIZ	/DRY BIT NOT SET /
6470	025434	052111	047040	052117			
6471	025442	051440	052105	000			
6472							
6473	025447	123	045517	042040	EM34:	.ASCIZ	/SOK DIDN'T SET /
6474	025454	042111	023516	020124			
6475	025462	042523	000124				
6476							
6477	025465	042523	026503	047103	EM35:	.ASCIZ	/SEC-CNTR DIDN'T COUNT TO 0 /
6478	025474	051124	042040	042111			
6479	025502	023516	020124	047503			
6480	025510	047125	020124	047524			
6481	025516	030040	000				
6482							
6483	025521	123	041505	041455	EM36:	.ASCIZ	/SEC-CNTR DIDN'T INCRMNT /
6484	025526	052116	020122	044504			
6485	025534	047104	052047	044440			
6486	025542	041516	046522	052116			
6487	025550	000					
6488							
6489	025551	123	041505	041455	EM37:	.ASCIZ	/SEC-COUNTR INCRMENTED WRONG /
6490	025556	052517	052116	020122			
6491	025564	047111	051103	042515			
6492	025572	052116	042105	053440			
6493	025600	047522	043516	000			
6494							
6495	025605	104	042111	023516	EM40:	.ASCIZ	/DIDN'T GET SC=SA FOR THIS SECTR /
6496	025612	020124	042507	020124			
6497	025620	041523	051475	020101			
6498	025626	047506	020122	044124			
6499	025634	051511	051440	041505			
6500	025642	051124	000				
6501							
6502	025645	105	047522	026522	EM41:	.ASCIZ	"EROR-R/W/S RDY SHOULD BE SET"
6503	025652	027522	027527	020123			
6504	025660	042122	020131	044123			
6505	025666	052517	042114	041040			
6506	025674	020105	042523	000124			

6507					
6508	025702	047125	054105	042520	EM43: .ASCIZ /UNEXPECTED RK11 INTERRUPT/
6509	025710	052103	042105	051040	
6510	025716	030513	020061	047111	
6511	025724	042524	051122	050125	
6512	025732	000124			
6513					
6514	025734	047103	051124	020114	EM44: .ASCIZ /CNTRL RDY DIDN'T SET AFTER SEEK OR DR RESET/
6515	025742	042122	020131	044504	
6516	025750	047104	052047	051440	
6517	025756	052105	040440	052106	
6518	025764	051105	051440	042505	
6519	025772	020113	051117	042040	
6520	026000	020122	042522	042523	
6521	026006	000124			
6522					
6523	026010	051105	020122	051117	EM45: .ASCIZ /ERR OR HE BIT SET ON SEEK OR DR RESET/
6524	026016	044040	020105	044502	
6525	026024	020124	042523	020124	
6526	026032	047117	051440	042505	
6527	026040	020113	051117	042040	
6528	026046	020122	042522	042523	
6529	026054	000124			
6530					
6531	026056	045522	051105	041040	EM46: .ASCIZ /RKER BIT, ON SEEK OR DR RESET/
6532	026064	052111	020054	047117	
6533	026072	051440	042505	020113	
6534	026100	051117	042040	020122	
6535	026106	042522	042523	000124	
6536					
6537	026114	045522	051503	041440	EM47: .ASCIZ /RKCS CHNGD AFTR FUNCTION WAS DONE/
6538	026122	047110	042107	040440	
6539	026130	052106	020122	052506	
6540	026136	041516	044524	047117	
6541	026144	053440	051501	042040	
6542	026152	047117	000105		
6543					
6544	026156	027522	027527	020123	EM50: .ASCIZ "R/W/S RDY DIDN'T CLEAR"
6545	026164	042122	020131	044504	
6546	026172	047104	052047	041440	
6547	026200	042514	051101	000	
6548					
6549	026205	122	053457	051457	EM51: .ASCIZ "R/W/S RDY DIDN'T SET AFTR SEEK OR DR RESET"
6550	026212	051040	054504	042040	
6551	026220	042111	023516	020124	
6552	026226	042523	020124	043101	
6553	026234	051124	051440	042505	
6554	026242	020113	051117	042040	
6555	026250	020122	042522	042523	
6556	026256	000124			
6557					
6558	026260	045522	040504	041440	EM52: .ASCIZ /RKDA CHNGD AFTR SEEK/
6559	026266	047110	042107	040440	
6560	026274	052106	020122	042523	
6561	026302	045505	000		
6562					

H11

MAINDEC-11-DZRKK-D
DZRKKD.P11

22-SEP-76

MACY11 27(1006)

04-OCT-76 16:06 PAGE 120
ERROR MESSAGES

SEQ 0137

6563	026305	103	052116	046122	EM53:	.ASCIZ	/CNTRL RDY DIDN'T CLR AS GO WAS SET/
6564	026312	051040	054504	042040			
6565	026320	042111	023516	020124			
6566	026326	046103	020122	051501			
6567	026334	043440	020117	040527			
6568	026342	020123	042523	000124			
6569							
6570	026350	047103	051124	020114	EM54:	.ASCIZ	"CNTRL RDY DIDN'T SET ON WRT/FMT STARTING FROM <DSK-ADRES>"
6571	026356	042122	020131	044504			
6572	026364	047104	052047	051440			
6573	026372	052105	047440	020116			
6574	026400	051127	027524	046506			
6575	026406	020124	052123	051101			
6576	026414	044524	043516	043040			
6577	026422	047522	020115	042074			
6578	026430	045523	040455	051104			
6579	026436	051505	000076				
6580							
6581	026442	042510	047440	020122	EM55:	.ASCIZ	"HE JR ERR ON WRT/FMT STARTING FROM <DSK-ADRES>"
6582	026450	051105	020122	047117			
6583	026456	053440	052122	043057			
6584	026464	052115	051440	040524			
6585	026472	052122	047111	020107			
6586	026500	051106	046517	036040			
6587	026506	051504	026513	042101			
6588	026514	042522	037123	000			
6589							
6590	026521	122	042113	020101	EM56:	.ASCIZ	/RKDA INCRMNTD WRONG ON WRT-FMT/
6591	026526	047111	051103	047115			
6592	026534	042124	053440	047522			
6593	026542	043516	047440	020116			
6594	026550	051127	026524	046506			
6595	026556	000124					
6596							
6597	026560	045522	041527	042040	EM57:	.ASCIZ	/RKWC DIDN'T OVRFLO ON WRT FMT/
6598	026566	042111	023516	020124			
6599	026574	053117	043122	047514			
6600	026602	047440	020116	051127			
6601	026610	020124	046506	000124			
6602							
6603	026616	045522	040502	044440	EM60:	.ASCIZ	/RKBA INCRMNTD WRONG ON WRT FMT/
6604	026624	041516	046522	052116			
6605	026632	020104	051127	047117			
6606	026640	020107	047117	053440			
6607	026646	052122	043040	052115			
6608	026654	000					
6609							
6610	026655	122	042513	020122	EM61:	.ASCIZ	/RKER SET, ON WRT OR RD OR FMT/
6611	026662	042523	026124	047117			
6612	026670	053440	052122	047440			
6613	026676	020122	042122	047440			
6614	026704	020122	046506	000124			
6615							
6616	026712	045522	041104	042440	EM62:	.ASCIZ	/RKOB EROR/
6617	026720	047522	000122				
6618							

6619	026724	045522	040504	044440	EM63:	.ASCIZ /RKDA INCRMNTD WRONG ON RD OR RD FMT/
6620	026732	041516	046522	052116		
6621	026740	020104	051127	047117		
6622	026746	020107	047117	051040		
6623	026754	020104	051117	051040		
6624	026762	020104	046506	000124		
6625						
6626	026770	045522	041527	042040	EM64:	.ASCIZ /RKWC DIDN'T OVRFLO ON RD OR RD FMT/
6627	026776	042111	023516	020124		
6628	027004	053117	043122	047514		
6629	027012	047440	020116	042122		
6630	027020	047440	020122	042122		
6631	027026	043040	052115	000		
6632						
6633	027033	122	041113	020101	EM65:	.ASCIZ /RKBA INCRMNTD WRONG ON RD OR RD FMT/
6634	027040	047111	051103	047115		
6635	027046	042124	053440	047522		
6636	027054	043516	047440	020116		
6637	027062	042122	047440	020122		
6638	027070	042122	043040	052115		
6639	027076	000				
6640						
6641	027077	111	041516	051117	EM66:	.ASCIZ /INCORRECT HEADER FROM 'SECTOR' /
6642	027104	042522	052103	044040		
6643	027112	040505	042504	020122		
6644	027120	051106	046517	023440		
6645	027126	042523	052103	051117		
6646	027134	000047				
6647						
6648	027136	040504	040524	042440	EM67:	.ASCIZ /DATA ERROR/
6649	027144	051122	051117	000		
6650						
6651	027151	103	052116	046122	EM70:	.ASCIZ "CNTRL RDY DIDN'T SET ON RD/FMT STARTING FROM <DSK-ADRES>"
6652	027156	051040	054504	042040		
6653	027164	042111	023516	020124		
6654	027172	042523	020124	047117		
6655	027200	051040	027504	046506		
6656	027206	020124	052123	051101		
6657	027214	044524	043516	043040		
6658	027222	047522	020115	042074		
6659	027230	045523	040455	051104		
6660	027236	051505	000076			
6661						
6662	027242	042510	047440	020122	EM71:	.ASCIZ "HE OR ERR ON RD/FMT STARTING FROM <DSK-ADRES>"
6663	027250	051105	020122	047117		
6664	027256	051040	027504	046506		
6665	027264	020124	052123	051101		
6666	027272	044524	043516	043040		
6667	027300	047522	020115	042074		
6668	027306	045523	040455	051104		
6669	027314	051505	000076			
6670						
6671	027320	051127	047117	020107	EM72:	.ASCIZ /WRONG DRIVE ID IN RKDS AFTER SEEK/
6672	027326	051104	053111	020105		
6673	027334	042111	044440	020116		
6674	027342	045522	051504	040440		

6675	027350	052106	051105	051440	
6676	027356	042505	000113		
6677					
6678	027362	051110	053504	042522	EM73: .ASCIZ /HRDWRE POLL-DRV ID BITS(13-15) SHLD BE CLR/
6679	027370	050040	046117	026514	
6680	027376	051104	020126	042111	
6681	027404	041040	052111	024123	
6682	027412	031461	030455	024465	
6683	027420	051440	046110	041104	
6684	027426	020105	046103	000122	
6685					
6686	027434	051110	053504	042522	EM74: .ASCIZ /HRDWRE POLL-INTRUPTING DRV * NOT PRSNT/
6687	027442	050040	046117	026514	
6688	027450	047111	051124	050125	
6689	027456	044524	043516	042040	
6690	027464	044522	020126	020043	
6691	027472	047516	020124	051120	
6692	027500	047123	000124		
6693					
6694	027504	051104	053111	021440	EM75: .ASCIZ /DRV * DIDN'T INTRUPT AFTER HRDWRE POLL/
6695	027512	042040	042111	023516	
6696	027520	020124	047111	051124	
6697	027526	050125	020124	043101	
6698	027534	042524	020122	051110	
6699	027542	053504	042522	050040	
6700	027550	046117	000114		
6701					
6702	027554	041523	020120	044504	EM76: .ASCIZ /SCP DIDN'T SET AFTER SEEK WAS DONE/
6703	027562	047104	052047	051440	
6704	027570	052105	040440	052106	
6705	027576	051105	051440	042505	
6706	027604	020113	040527	020123	
6707	027612	047504	042516	000	
6708					
6709	027617	122	042113	020101	EM77: .ASCIZ /RKDA CHANGD AFTER DRV RESET/
6710	027624	044103	047101	042107	
6711	027632	040440	052106	051105	
6712	027640	042040	044522	020126	
6713	027646	042522	042523	000124	
6714					
6715	027654	040504	040524	042440	EM100: .ASCIZ /DATA EROR AT WORD#/
6716	027662	047522	020122	052101	
6717	027670	053440	051117	021504	
6718	027676	000			
6719					
6720	027677	103	052116	046122	EM101: .ASCIZ /CNTRL RDY DIDN'T SET AFTER RD CHK/
6721	027704	051040	054504	042040	
6722	027712	042111	023516	020124	
6723	027720	042523	020124	043101	
6724	027726	042524	020122	042122	
6725	027734	041440	045510	000	
6726					
6727	027741	105	051122	047440	EM102: .ASCIZ /ERR OR HE ON RD CHK/
6728	027746	020122	042510	047440	
6729	027754	020116	042122	041440	
6730	027762	045510	000		

K11

6731					
6732	027765	103	042523	047440	EM103: .ASCIZ /CSE ON RD CHK/
6733	027772	020116	042122	041440	
6734	030000	045510	000		
6735					
6736	030003	122	053513	020103	EM104: .ASCIZ /RKWC DIDN'T OVERFLO ON RD CHK OR WRT CHK/
6737	030010	044504	047104	052047	
6738	030016	047440	042526	043122	
6739	030024	047514	047440	020116	
6740	030032	042122	041440	045510	
6741	030040	047440	020122	051127	
6742	030046	020124	044103	000113	
6743					
6744	030054	045522	040504	044440	EM105: .ASCIZ /RKDA INCRMNTD WRONG ON RD CHK/
6745	030062	041516	046522	052116	
6746	030070	020104	051127	047117	
6747	030076	020107	047117	051040	
6748	030104	020104	044103	000113	
6749					
6750	030112	045522	040502	041440	EM106: .ASCIZ /RKBA CHANGD AFTER RD CHK/
6751	030120	040510	043516	020104	
6752	030126	043101	042524	020122	
6753	030134	042122	041440	045510	
6754	030142	000			
6755					
6756	030143	115	046505	051117	EM107: .ASCIZ /MEMORY WORD CHANGED AFTER RD CHK/
6757	030150	020131	047527	042122	
6758	030156	041440	040510	043516	
6759	030164	042105	040440	052106	
6760	030172	051105	051040	020104	
6761	030200	044103	000113		
6762					
6763	030204	047103	051124	020114	EM110: .ASCIZ /CNTRL RDY DIDN'T SET AFTER WRT CHK/
6764	030212	042122	020131	044504	
6765	030220	047104	052047	051440	
6766	030226	052105	040440	052106	
6767	030234	051105	053440	052122	
6768	030242	041440	045510	000	
6769					
6770	030247	110	020105	051117	EM111: .ASCIZ /HE OR ERR ON WRT CHK/
6771	030254	042440	051122	047440	
6772	030262	020116	051127	020124	
6773	030270	044103	000113		
6774					
6775	030274	051127	052111	020105	EM112: .ASCIZ /WRITE CHECK EROR/
6776	030302	044103	041505	020113	
6777	030310	051105	051117	000	
6778					
6779	030315	122	042113	020101	EM113: .ASCIZ /RKDA INCRMNTD WRONG ON WRT CHK/
6780	030322	047111	051103	047115	
6781	030330	042124	053440	047522	
6782	030336	043516	047440	020116	
6783	030344	051127	020124	044103	
6784	030352	000113			
6785					
6786	030354	045522	040502	044440	EM114: .ASCIZ /RKBA INCRMNTD WRONG ON WRT CHK/

6787	030362	041516	046522	052116	
6788	030370	020104	051127	047117	
6789	030376	020107	047117	053440	
6790	030404	052122	041440	045510	
6791	030412	000			
6792					
6793	030413	122	041113	020101	EM115: .ASCIZ /RKBA INCRMNTD, WITH IBA SET/
6794	030420	047111	051103	047115	
6795	030426	042124	020054	044527	
6796	030434	044124	044440	040502	
6797	030442	051440	052105	000	
6798					
6799	030447	127	047522	043516	EM116: .ASCIZ /WRONG MEMORY LOCATION CHANGED WITH IBA SET/
6800	030454	046440	046505	051117	
6801	030462	020131	047514	040503	
6802	030470	044524	047117	041440	
6803	030476	040510	043516	042105	
6804	030504	053440	052111	020110	
6805	030512	041111	020101	042523	
6806	030520	000124			
6807					
6808	030522	045522	030461	042040	EM117: .ASCIZ /RK11 DIDN'T INTRUPT WHEN IDE WAS SET/
6809	030530	042111	023516	020124	
6810	030536	047111	051124	050125	
6811	030544	020124	044127	047105	
6812	030552	044440	042504	053440	
6813	030560	051501	051440	052105	
6814	030566	000			
6815					
6816	030567	122	030513	020061	EM120: .ASCIZ /RK11 DIDN'T INTRUPT AFTER SK WAS INITIATED/
6817	030574	044504	047104	052047	
6818	030602	044440	052116	052522	
6819	030610	052120	040440	052106	
6820	030616	051105	051440	020113	
6821	030624	040527	020123	047111	
6822	030632	052111	040511	042524	
6823	030640	000104			
6824					
6825	030642	041523	020120	042523	EM121: .ASCIZ /SCP SET BEFORE SEEK COMPLETED/
6826	030650	020124	042502	047506	
6827	030656	042522	051440	042505	
6828	030664	020113	047503	050115	
6829	030672	042514	042524	000104	
6830					
6831	030700	045522	030461	042040	EM122: .ASCIZ /RK11 DIDN'T INTRUPT AFTER SK COMPLETED/
6832	030706	042111	023516	020124	
6833	030714	047111	051124	050125	
6834	030722	020124	043101	042524	
6835	030730	020122	045523	041440	
6836	030736	046517	046120	052105	
6837	030744	042105	000		
6838					
6839	030747	103	052116	046122	EM123: .ASCIZ /CNTRL RESET DIDN'T CLEAR 'SCP'/
6840	030754	051040	051505	052105	
6841	030762	042040	042111	023516	
6842	030770	020124	046103	040505	

6843	030776	020122	051447	050103	
6844	031004	000047			
6845					
6846	031006	045522	030461	042040	EM124: .ASCIZ /RK11 DIDN'T INTRUPT AFTER RD DONE/
6847	031014	042111	023516	020124	
6848	031022	047111	051124	050125	
6849	031030	020124	043101	042524	
6850	031036	020122	042122	042040	
6851	031044	047117	000105		
6852					
6853	031050	047103	051124	020114	EM125: .ASCIZ /CNTRL RESET DIDN'T CLR REGISTR/
6854	031056	042522	042523	020124	
6855	031064	044504	047104	052047	
6856	031072	041440	051114	051040	
6857	031100	043505	051511	051124	
6858	031106	000			
6859					
6860	031107	122	030513	020061	EM126: .ASCIZ /RK11 DIDN'T INTRUPT AT CPU LEVEL/
6861	031114	044504	047104	052047	
6862	031122	044440	052116	052522	
6863	031130	052120	040440	020124	
6864	031136	050103	020125	042514	
6865	031144	042526	000114		
6866					
6867	031150	045522	030461	044440	EM127: .ASCIZ /RK11 INTRUPTED AT WRONG CPU LEVEL/
6868	031156	052116	052522	052120	
6869	031164	042105	040440	020124	
6870	031172	051127	047117	020107	
6871	031200	050103	020125	042514	
6872	031206	042526	000114		
6873					
6874	031212	042447	051122	041040	EM130: .ASCIZ ''ERR BIT' DIDN'T SET IN RKER/
6875	031220	052111	020047	044504	
6876	031226	047104	052047	051440	
6877	031234	052105	044440	020116	
6878	031242	045522	051105	000	
6879					
6880	031247	110	020105	051117	EM131: .ASCIZ /HE OR ERR DIDN'T SET/
6881	031254	042440	051122	042040	
6882	031262	042111	023516	020124	
6883	031270	042523	000124		
6884					
6885	031274	045522	051105	042440	EM132: .ASCIZ /RKER EROR/
6886	031302	047522	000122		
6887					
6888	031306	054116	020103	044502	EM133: .ASCIZ /NXC BIT DIDN'T SET/
6889	031314	020124	044	047104	
6890	031322	052047	051	052105	
6891	031330	000			
6892					
6893	031331	122	030513	020061	EM134: .ASCIZ /RK11 DIDN'T INTRUPT ON SOFT EROR/
6894	031336	044504	047104	052047	
6895	031344	044440	052116	052522	
6896	031352	052120	047440	020116	
6897	031360	047523	052106	042440	
6898	031366	047522	000122		

6899					
6900	031372	042515	020130	044502	EM135: .ASCIZ /MEX BITS INCRMNTD WRONG-RKCS/
6901	031400	051524	044440	041516	
6902	031406	046522	052116	020104	
6903	031414	051127	047117	026507	
6904	031422	045522	051503	000	
6905					
6906	031427	127	051520	047040	EM137: .ASCIZ /WFS NOT CLEAR/
6907	031434	052117	041440	042514	
6908	031442	051101	000		
6909					
6910	031445	104	052101	020101	EM140: .ASCIZ /DATA EROR ON TRANSFER FROM DISK TO TTY/
6911	031452	051105	051117	047440	
6912	031460	020116	051124	047101	
6913	031466	043123	051105	043040	
6914	031474	047522	020115	044504	
6915	031502	045523	052040	020117	
6916	031510	052124	000131		
6917					
6918	031514	042047	044522	020126	EM141: .ASCIZ /'DRIV #' PRESENT, BUT NOT INDICATED/
6919	031522	023443	050040	042522	
6920	031530	042523	052116	020054	
6921	031536	052502	020124	047516	
6922	031544	020124	047111	044504	
6923	031552	040503	042524	000104	
6924	031560	047040	020117	052502	EM142: .ASCIZ / NO BUSY ON OTHER HALF OF RK-05F/
6925	031566	054523	047440	020116	
6926	031574	052117	042510	020122	
6927	031602	040510	043114	047440	
6928	031610	020106	045522	030055	
6929	031616	043065	000		
6930					
6931					
6932					
6933					
6934					
6935	031622				.EVEN
6936					.SBTTL ERROR DATA POINTERS
6937					
6938					
6939	031622	001116	001162	000000	DT1: .WORD \$ERRPC,\$REG0,0
6940					
6941	031630	001116	001162	001164	DT2: .WORD \$ERRPC,\$REG0,\$REG1,0
6942	031636	000000			
6943					
6944	031640	001116	001162	001164	DT20: .WORD \$ERRPC,\$REG0,\$REG1,\$REG2,\$REG3,0
6945	031646	001166	001170	000000	
6946					
6947	031654	001116	000000		DT21: .WORD \$ERRPC,0
6948					
6949	031660	001116	001162	001164	DT26: .WORD \$ERRPC,\$REG0,\$REG1,\$REG2,0
6950	031666	001166	000000		
6951					
6952	031672	001116	001162	001164	DT54: .WORD \$ERRPC,\$REG0,\$REG1,\$REG2,\$REG3,\$REG4,\$REG5,\$REG6,\$REG7,0
6953	031700	001166	001170	001172	
6954	031706	001174	001176	001200	

6955	031714	000000							
6956									
6957									
6958									
6959									
6960									
6961							.SBTTL	ERROR	HEADERS
6962	031716	020040	041520	020040	DH2:	.ASCIZ / PC	REGADD	RECVD/	
6963	031724	051040	043505	042101					
6964	031732	020104	020040	051040					
6965	031740	041505	042126	000					
6966									
6967	031745	040	050040	020103	DH4:	.ASCIZ / PC	EXPCT	RECVD/	
6968	031752	020040	042440	050130					
6969	031760	052103	020040	051040					
6970	031766	041505	042126	000					
6971									
6972	031773	040	050040	020103	DH5:	.ASCIZ / PC	RECVD/		
6973	032000	020040	051040	041505					
6974	032006	042126	000						
6975									
6976	032011	040	050040	020103	DH14:	.ASCIZ / PC	RKCS	RKER	RKWC/
6977	032016	020040	051040	041513					
6978	032024	020123	020040	051040					
6979	032032	042513	020122	020040					
6980	032040	051040	053513	000103					
6981									
6982	032046	020040	041520	000	DH21:	.ASCIZ / PC			
6983									
6984	032053	040	050040	020103	DH30:	.ASCIZ / PC	RKCS	RKER	RKDS/
6985	032060	020040	020040	045522					
6986	032066	051503	020040	020040					
6987	032074	045522	051105	020040					
6988	032102	020040	045522	051504					
6989	032110	000							
6990									
6991	032111	040	050040	020103	DH34:	.ASCIZ / PC	RKDS/		
6992	032116	020040	020040	045522					
6993	032124	051504	000						
6994									
6995	032127	040	050040	020103	DH35:	.ASCIZ / PC	SEC-CNTR/		
6996	032134	020040	042523	026503					
6997	032142	047103	051124	000					
6998									
6999	032147	040	050040	020103	DH36:	.ASCIZ / PC	PRSNT	NXT-CNT/	
7000	032154	020040	020040	051120					
7001	032162	047123	020124	047040					
7002	032170	052130	041455	052116					
7003	032176	000							
7004									
7005	032177	040	050040	020103	DH40:	.ASCIZ / PC	SECTOR	RKDS/	
7006	032204	020040	051440	041505					
7007	032212	047524	020122	020040					
7008	032220	045522	051504	000					
7009									
7010	032225	040	050040	020103	DH44:	.ASCIZ / PC	RKCS	RKER	RKDS RKDA/

7011	032232	020040	051040	041513
7012	032240	020123	020040	051040
7013	032246	042513	020122	020040
7014	032254	051040	042113	020123
7015	032262	020040	051040	042113
7016	032270	000101		
7017				
7018	032272	020040	041520	020040
7019	032300	020040	045522	051503
7020	032306	020040	020040	045522
7021	032314	051105	020040	020040
7022	032322	045522	051504	020040
7023	032330	020040	045522	040504
7024	032336	020040	042040	053122
7025	032344	027043	027056	041456
7026	032352	046131	036056	051504
7027	032360	026513	042101	051522
7028	032366	027076	052523	027122
7029	032374	051456	041505	000
7030				
7031	032401	040	041520	020040
7032	032406	054105	041520	020072
7033	032414	051104	020043	020040
7034	032422	054503	020114	020040
7035	032430	020040	052523	020122
7036	032436	020040	051440	041505
7037	032444	020040	042522	053103
7038	032452	020072	051104	020043
7039	032460	020040	054503	020114
7040	032466	020040	020040	052523
7041	032474	020122	020040	020040
7042	032502	042523	000103	
7043				
7044	032506	020040	041520	020040
7045	032514	020040	045522	041527
7046	032522	020040	051040	042113
7047	032530	000101		
7048				
7049	032532	020040	041520	020040
7050	032540	020040	042523	052103
7051	032546	020122	020040	054105
7052	032554	041520	020124	020040
7053	032562	042522	053103	000104
7054				
7055	032570	020040	041520	020040
7056	032576	020040	054105	041520
7057	032604	020124	020040	042522
7058	032612	053103	020104	042040
7059	032620	045523	040455	051104
7060	032626	000123		
7061				
7062	032630	020040	041520	020040
7063	032636	020040	020040	051104
7064	032644	053111	021440	000
7065				
7066	032651	040	050040	020103

DH54: .ASCIZ / PC RKCS RKER RKDS RKDA DRV#...CYL.(DSK-ADRS).SUR..SEC/

DH56: .ASCIZ / PC EXPC: DR# CYL SUR SEC RECV: DR# CYL SUR SEC/

DH64: .ASCIZ / PC RKWC RKDA/

DH66: .ASCIZ PC SECTR EXPCT RECVD.

DH67: .ASCIZ / PC EXPCT RECVD DSK-ADRS/

DH74: .ASCIZ / PC DRIV #/

DH100: .ASCIZ / PC WORD # EXPCT RECVD/

7067	032656	053440	051117	020104						
7068	032664	020040	020040	054105						
7069	032672	041520	020124	020040						
7070	032700	042522	053103	000104						
7071										
7072	032706	020040	041520	020040	DH103:	.ASCIZ	/	PC	RKER/	
7073	032714	051040	042513	000122						
7074										
7075	032722	020040	041520	020040	DH104:	.ASCIZ	/	PC	RECVD	RKCS/
7076	032730	051040	041505	042126						
7077	032736	020040	051040	041513						
7078	032744	000123								
7079										
7080	032746	020040	041520	020040	DH107:	.ASCIZ	/	PC	LOC	EXPCT RECVD/
7081	032754	020040	046040	041517						
7082	032762	020040	020040	054105						
7083	032770	041520	020124	020040						
7084	032776	042522	053103	000104						
7085										
7086	033004	020040	041520	020040	DH117:	.ASCIZ	/	PC	RKCS/	
7087	033012	051040	041513	000123						
7088										
7089	033020	020040	041520	020040	DH126:	.ASCIZ	/	PC	LEVEL	RKCS/
7090	033026	020040	042514	042526						
7091	033034	020114	020040	051040						
7092	033042	041513	000123							
7093										
7094	033046	020040	041520	020040	DH130:	.ASCIZ	/	PC	RKCS	RKER ERR BIT/
7095	033054	020040	051040	041513						
7096	033062	020123	020040	051040						
7097	033070	042513	020122	042440						
7098	033076	051122	041040	052111						
7099	033104	000								
7100										
7101	033105	040	050040	020103	DH131:	.ASCIZ	/	PC	RKCS	RKER/
7102	033112	020040	020040	045522						
7103	033120	051503	020040	020040						
7104	033126	045522	051105	000						
7105										
7106	033133	040	050040	020103	DH133:	.ASCIZ	/	PC	RKCS	RKER RKDA/
7107	033140	020040	020040	045522						
7108	033146	051503	020040	020040						
7109	033154	045522	051105	020040						
7110	033162	020040	045522	040504						
7111	033170	000								
7112										
7113	033171	040	050040	020103	DH140:	.ASCIZ	/	PC	EXPCT	RECVD RKBA RKCS/
7114	033176	020040	042440	050130						
7115	033204	052103	020040	051040						
7116	033212	041505	042126	020040						
7117	033220	020040	045522	040502						
7118	033226	020040	020040	045522						
7119	033234	051503	000							
7120										
7121										
7122		033240				.EVEN				

7123
7124
7125 033240 000400
7126
7127
7128
7129 000001

;DATA BUFFER

OUTBUF: .BLKW 256.

: THIS 256 WORD BUFFER IS FOR
: DATA TRANSFERS FROM AND
: TO THE DISK.

.END

BACINT 004526
 BACTMO 004462
 BQAR 021002
 BQAO 020764
 BQAH 020774
 BIT0 = 000001
 BIT00 = 000001
 BIT01 = 000002
 BIT02 = 000004
 BIT03 = 000010
 BIT04 = 000020
 BIT05 = 000040
 BIT06 = 000100
 BIT07 = 000200
 BIT08 = 000400
 BIT09 = 001000
 BIT1 = 000002
 BIT10 = 002000
 BIT11 = 004000
 BIT12 = 010000
 BIT13 = 020000
 BIT14 = 040000
 BIT15 = 100000
 BIT2 = 000004
 BIT3 = 000010
 BIT4 = 000020
 BIT5 = 000040
 BIT6 = 000100
 BIT7 = 000200
 BIT8 = 000400
 BIT9 = 001000
 BPTVEC = 000014
 BRKDAO = 104415
 BRKDAH = 104416
 BTEOP 017734
 CHE1 021150
 CHKCC 021310
 CHKCRD = 104412
 CHKDA 021170
 CHKDA1 021176
 CHKECL 021264
 CHKER 021250
 CHKHE 021142
 CHKHE1 021134
 CHKWC 021224
 CH.CRD 021666
 CKSWR = 104407
 CNT.RD = 104414
 CNT.RE = 104413
 CN.RDY 021740
 CN.RST 021722
 COUNT 001362
 COUNT1 001364

CR = 000015
 CRETAN 021336
 CRLE = 000200
 CDISP = 177570
 DDPCH 001410
 DELAY = 104417
 DELA.Y 021572
 DH100 032657
 DH103 032706
 DH104 032722
 DH107 032746
 DH117 033004
 DH126 033020
 DH130 033046
 DH131 033125
 DH133 033133
 DH14 032011
 DH140 033171
 DH2 031716
 DH21 032046
 DH30 032053
 DH34 032111
 DH35 032127
 CH36 032147
 DH4 031745
 DH40 032177
 DH44 032225
 DH5 031773
 DH54 032272
 DH56 032401
 DH64 032506
 DH66 032532
 DH67 032570
 CH74 032630
 DISPLA 001142
 DISPRE 000174
 DRESET 021412
 DRHOLD 025200
 DRIVAD 001350
 DRIVS 001412
 DRIVO 001414
 DRIV1 001416
 DRIV2 001420
 DRIV3 001422
 DRIV4 001424
 DRIV5 001426
 DRIV6 001430
 DRIV7 001432
 DRVDRN 001352
 DRVPTR 001354
 DSMR = 177570
 DT1 031622
 DT2 031630

DT20 031640
 DT21 031654
 DT26 031660
 DT54 031672
 EFLAG1 001370
 E*VFC = 000030
 EM100 027654
 EM101 027677
 EM102 027741
 EM103 027765
 EM104 030003
 EM105 030054
 EM106 030112
 EM107 030143
 EM11 025266
 EM110 030204
 EM111 030247
 EM112 030274
 EM113 030315
 EM114 030354
 EM115 030413
 EM116 030447
 EM117 030522
 EM12 025300
 EM120 030567
 EM121 030642
 EM122 030700
 EM123 030747
 EM124 031006
 EM125 031050
 EM126 031107
 EM127 031150
 EM13 025313
 EM130 031212
 EM131 031247
 EM132 031274
 EM133 031306
 EM134 031331
 EM135 031372
 EM137 031427
 EM140 031445
 EM141 031514
 EM142 031560
 EM16 025325
 EM21 025354
 EM30 025366
 EM31 025376
 EM32 025406
 EM33 025427
 EM34 025447
 EM35 025466
 EM36 025521
 EM37 025551

EM40 025605
 EM41 025645
 EM43 025702
 EM44 025734
 EM45 026010
 EM46 026056
 EM47 026114
 EM50 026156
 EM51 026205
 EM52 026260
 EM53 026305
 EM54 026350
 EM55 026442
 EM56 026521
 EM57 026560
 EM60 026616
 EM61 026655
 EM62 026712
 EM63 026724
 EM64 026770
 EM65 027033
 EM66 027077
 EM67 027136
 EM70 027151
 EM71 027242
 EM72 027320
 EM73 027362
 EM74 027434
 EM75 027504
 EM76 027554
 EM77 027617
 ERRVEC = 000004
 FCHECK 025056
 FFLAG 001404
 FTITLE 001346
 GTSWR = 104406
 GT2RG 020716
 GT3RG 020710
 GT4RG 020702
 H* = 000011
 INDX1 001356
 INDX2 001360
 IOTVEC = 000020
 LF = 000012
 MSG1 001216
 MSG2 001236
 MSG3 001245
 MSG4 001272
 MSG5 001303
 MSG6 001315
 NUDRV 004766
 ODDEVN 001406
 OUTBUF 033240

PFSTRT 004630
 PHYDRV 001436
 PIRG = 177772
 PIRGVE = 000240
 PR0 = 000000
 PR1 = 000040
 PR2 = 000100
 PR3 = 000140
 PR4 = 000200
 PR5 = 000240
 PR6 = 000300
 PR7 = 000340
 PS = 177776
 PSW = 177776
 PWRVEC = 000024
 RCHR = 104410
 RDLIN = 104411
 RESVEC = 000010
 RKBP 001336
 RKCS 001332
 RKDA 001340
 RKDB 001342
 RKDS 001326
 RKER 001330
 RKPRI 001400
 RKVEC 001402
 RKWC 001334
 R6 = %000006
 R7 = %000007
 SEEK0 001372
 SEEK1 001374
 SEEK2 001376
 SHFTRT 021106
 S*JUL 001344
 SIZEF 025202
 SIZYET 001440
 STACK = 001100
 START 002636
 START1 003262
 STKLMT = 177774
 ST2 003664
 ST3 004210
 ST4 004404
 SWR 001140
 SWREG 000176
 SWO = 000001
 SWO0 = 000001
 SWO1 = 000002
 SWO2 = 000004
 SWO3 = 000010
 SWO4 = 000020
 SWO5 = 000040
 SWO6 = 000100

SW07 = 000200	TST21 007610	TYPOC = 104402	\$GDADR 001120	\$REG6 001176
SW08 = 000400	TST22 010062	TYPON = 104404	\$GDDAT 001124	\$REG7 001200
SW09 = 001000	TST23 010432	TYPOS = 104403	\$GET42 020636	\$RTNAD 020660
SW1 = 000002	TST24 010712	T56 020046	\$GTSWR 023730	\$SAVR6 025044
SW10 = 002000	TST25 011322	T56FLG 001434	\$HD = 000000	\$SCOPE 022046
SW11 = 004000	TST26 011630	WATIME 021650	\$ICNT 001104	\$SETUP= 000117
SW12 = 010000	TST27 012150	WATINT 021614	\$ILLUP 025040	\$STUP = 177777
SW13 = 020000	TST3 005164	WAT.IN= 104420	\$INTAG 001135	\$SVLAD 022254
SW14 = 040000	TST30 012436	\$AUTOB 001134	\$ITEMB 001114	\$SVPC = 000204
SW15 = 100000	TST31 012672	\$BDADR 001122	\$LF 001214	\$SWR = 165400
SW2 = 000004	TST32 013076	\$BDDAT 001126	\$LPADR 001106	\$SWRMK= 000000
SW3 = 000010	TST33 013344	\$CHARC 023202	\$LPERR 001110	\$TIMES 001206
SW4 = 000020	TST34 013626	\$CKSWR 023660	\$MNEW 024563	\$TKB 001146
SW5 = 000040	TST35 014104	\$CMTAG 001100	\$MSWR 024552	\$TKS 001144
SW6 = 000100	TST36 014236	\$CM1 = 000012	\$MXCNT 022316	\$TN = 000060
SW7 = 000200	TST37 014562	\$CM2 = 000024	\$NULL 001154	\$TPB 001152
SW8 = 000400	TST4 005276	\$CM3 = 000012	\$NWTST= 000001	\$TPFLG 001157
SW9 = 001000	TST40 014776	\$CNTLG 024545	\$OCNT 023654	\$TPS 001150
TBITVE= 000014	TST41 015202	\$CNTLU 024540	\$OMODE 023656	\$TRAP 024574
TIMER 001366	TST42 015364	\$CRLF 001213	\$OVER 022302	\$TRAP2 024616
TKVEC = 000060	TST43 015472	\$DBLK 023422	\$PASS 001100	\$TRP = 000022
TFVEC = 000064	TST44 015646	\$DOAGN 020656	\$POWER 025046	\$TRPAD 024630
TRAPVE= 000034	TST45 016004	\$DTBL 023412	\$PWAD 025034	\$TSTNM 001102
TRTVEC= 000014	TST46 016212	\$ENDAD 020646	\$PWADN 024674	\$TTYIN 024516
TSTEND 020534	TST47 016364	\$ENDCT 020614	\$PWARMG 025030	\$TYPDS 023206
TSTRWS 021344	TST5 005364	\$ENDMG 020665	\$PWUP 024746	\$TYPE 022766
TSTSIN 021500	TST50 016542	\$ENULL 020662	\$QUES 001212	\$TYPEC 023136
*T.SI= 104421	TST51 016670	\$EOP 020560	\$RDCHR 024142	\$TYPEX 023204
TST1 004634	TST52 017042	\$EOPCT 020606	\$RJLN 024262	\$TYPOC 023456
TST10 005670	TST53 017236	\$ERFLG 001103	\$RDSZ = 000022	\$TYPON 023472
TST11 005756	TST54 017530	\$ERMAX 001115	\$REGAD 001160	\$TYPOS 023432
TST12 006032	TST55 017666	\$ERROR 022320	\$REGO 001162	\$XTSTR 022060
TST13 006160	TST56 017712	\$ERRPC 001116	\$REG1 001164	\$SGET4= 000000
TST14 006324	TST57 017762	\$ERRTB 001442	\$REG10 001202	\$OFILL 023655
TST15 006416	TST6 005412	\$ERRTY 022632	\$REG11 001204	. = 034240
*TST16 006654	TST7 005450	\$ERTTL 001112	\$REG2 001166	
TST17 007102	TYERM 020734	\$ESCAP 001210	\$REG3 001170	
TST2 004766	TYPDS = 104405	\$FILLC 001156	\$REG4 001172	
TST20 007412	TYPE = 104401	\$FILLS 001155	\$REG5 001174	

. ABS. 034240 000

ERRORS DETECTED: 0
 DEFAULT GLOBALS GENERATED: 0

DZRKKD, DZRKKD/LI:ME/NL:MC:MD:CND/SOL/NSG+DZRKKD.P11
 RUN-TIME: 65 62 1 SECONDS
 RUN-TIME RATIO: 505/130=3.8
 CORE USED: 24K (47 PAGES)

