

RM03

DRIVE COMPATIBILITY TEST
MD-11-DZRMI-A

EP-DZRMI-A-DL-A

OCT 1977

COPYRIGHT © 1977

digital

FICHE 1 OF 1

MADE IN USA

This microfiche card contains a grid of 144 frames (12 rows by 12 columns) of data. Each frame contains a small, high-contrast image of a drive compatibility test result, likely a barcode or a set of data points. The frames are arranged in a regular grid pattern across the card.

B01

CO1

.REM 2

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48

IDENTIFICATION

PRODUCT CODE: MAINDEC-11-DZRMI-A-D
PRODUCT NAME: RMO3 DRIVE COMPATIBILITY TEST
DATE CREATED: AUGUST 1977
MAINTAINER: DIAGNOSTIC ENGINEERING
AUTHOR: C. CHEN

COPYRIGHT (C) 1977 DIGITAL EQUIPMENT CORP., MAYNARD, MASS.

THE INFORMATION IN THIS STATEMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION.

ACTUAL DISTRIBUTION OF THE SOFTWARE DESCRIBED IN THIS DOCUMENT WILL BE SUBJECT TO TERMS AND CONDITIONS TO BE ANNOUNCED ON SOME FUTURE DATE BY DIGITAL EQUIPMENT CORPORATION.

DEC ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT WHICH IS NOT SUPPLIED BY DEC.

THIS SOFTWARE IS FURNISHED TO PURCHASER UNDER A LICENSE TO USE ON A SINGLE COMPUTER SYSTEM AND CAN BE COPIED (WITH INCLUSION OF DEC'S COPYRIGHT NOTICE) ONLY FOR USE IN SUCH SYSTEM, EXCEPT AS MAY OTHERWISE BE PROVIDED IN WRITING BY DEC.

49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104

TABLE OF CONTENTS

- 1.0 INTRODUCTION
- 2.0 HARDWARE REQUIREMENTS
- 3.0 PRELIMINARY PROGRAM REQUIREMENTS
- 4.0 GENERAL PROGRAM CONSIDERATIONS
 - 4.1 SYSMAC
 - 4.2 XXDP
 - 4.3 ACT
 - 4.4 APT
 - 4.5 DUAL-ACCESS
 - 4.6 MEMORY MANAGEMENT
 - 4.7 MEMORY PARITY OPTION
 - 4.8 BAD SECTORS
 - 4.9 EXECUTION TIME
- 5.0 PROGRAM LOAD MEDIA
- 6.0 PROGRAM OPTIONS
 - 6.1 STARTING ADDRESSES
 - 6.2 SWITCH REGISTER OPTIONS USED
- 7.0 RUNNING THE PROGRAM
- 8.0 OPERATIONAL DIALOGUE
 - 8.1 DIALOGUE FOR ADDRESS 200 START
 - 8.2 DIALOGUE FOR ADDRESS 204 START
 - 8.3 DIALOGUE FOR ADDRESS 220 START
 - 8.4 PASS 1 DIALOGUE
 - 8.5 PASS 2 DIALOGUE
- 9.0 DESCRIPTION OF TESTS
 - 9.1 DESCRIPTION OF PASS 1 TESTS
 - 9.2 DESCRIPTION OF PASS 2 TESTS
- 10.0 PRINTOUT OF TEST RESULTS
 - 10.1 OVERWRITE AND DRIVE COMPATIBILITY DATA TEST RESULTS
- 11.0 ERROR REPORTING
 - 11.1 COMMON ERRORS
 - 11.2 ERROR HANDLING
 - 11.3 ERROR PRINTOUT EXAMPLE

EO1

MAINDEC-11-DZRM1 AQ/00, RM03 DRIVE COMPATIBILITY TEST MACY11 30(1046) 21-JUL-77 16:51 PAGE 4
DZRM1A.P11 21-JUL-77 15:44

SEQ 0003

105
106
107

TABLE A - BASIC READ/WRITE TEST SECTORS

TABLE B - WORSE CASE DATA PATTERN

108
109
110
111
112
113
114
115
116
117
118
119
120
121
122

TABLE C - CYLINDER BLOCK ASSIGNMENT FOR A GIVEN SURFACE

TABLE D - BASIC CYLINDER BLOCK LAYOUT EXAMPLE

TABLE E - OVERWRITE CYLINDERS

TABLE F - SELF-TEST CYLINDERS

TABLE G - PSEUDO-RANDOM DATA PATTERN

12.0 RM03 SOFTWARE DRIVER DOCUMENT

123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167
168
169
170
171

1.0 INTRODUCTION

THE PURPOSE OF THIS PROGRAM IS TO VERIFY THE COMPATIBILITY OF UP TO 16 RMD3S DRIVES WHICH MAY RESIDE ON ONE / MORE RH11(70)/RMD3 SUBSYSTEMS.

COMPATIBILITY IS DEFINED HERE AS THE ABILITY OF A DRIVE TO WRITE DATA WHICH CAN BE READ SUCCESSFULLY BY ALL OTHER DRIVES, AND ADDITIONALLY THE ABILITY OF A DRIVE TO COMPLETELY OVER-WRITE DATA WRITTEN BY ALL OTHER DRIVES.

THE PROGRAM IS DESIGNED TO DETECT THE FOLLOWING CONDITIONS WHICH MOST COMMONLY CAUSE INCOMPATIBILITY BETWEEN DRIVES:

1. HEAD MIS-ALIGNMENT
2. POSITIONER LATERAL MISALIGNMENT
3. SPINDLE-CARTRIDGE INTERFACE RUNOUT
4. IMPROPER LEVELS OF WRITE CURRENT
5. INCORRECT ADDRESSING OF READ/WRITE HEADS

THE TESTING IS DONE IN TWO PASSES. IN PASS 1, COMPATIBILITY DATA PATTERNS ARE WRITTEN BY ALL THE DRIVES UPON THE SAME DISK CARTRIDGE, AND THE BASIC READ/WRITE CAPABILITY OF EACH DRIVE IS DEMONSTRATED. IN PASS 2, THE COMPATIBILITY DATA FROM ALL DRIVES IS READ BY EACH DRIVE, WITH HEAD OFFSET, AND THIS IS COMPARED WITH EACH DRIVE'S ABILITY TO READ ITS OWN DATA. IN ADDITION, EACH DRIVE'S CAPABILITY TO OVERWRITE DATA WRITTEN BY ALL OTHER DRIVES IS TESTED ON THE SECOND PASS. (FOR THE REMAINDER OF THIS SPECIFICATION, THE ABOVE DEFINITIONS OF THE FIRST AND SECOND PASS SHALL APPLY).

IN BOTH PASSES, THE PROGRAM DIRECTS THE OPERATOR IN THE LOADING AND UNLOADING OF DRIVES AND THE MOVEMENT OF THE CARTRIDGE FROM DRIVE TO DRIVE, THROUGH MESSAGES AT THE CONSOLE TERMINAL. AT THE COMPLETION OF TESTING ON EACH DRIVE DURING THE SECOND PASS A SUMMARY IS PRINTED OF COMPATIBILITY TEST RESULTS FOR THAT DRIVE.

WITHIN THE VARIOUS TESTS OF BOTH PASSES, THE CAPABILITY IS PROVIDED TO LOOP ON CURRENT OPERATIONS, AND SWITCH REGISTER OPTIONS ARE PROVIDED, FOR A VARIETY OF LOOPING, RUNNING, AND REPORTING MODES (SEE SECTION 6.2).

UNEXPECTED ERRORS WILL BE REPORTED AS THEY OCCUR. THE REPORT WILL INCLUDE DESCRIPTION AND APPLICABLE DEVICE REGISTER CONTENTS.

172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196
197
198
199
200
201
202
203
204
205
206
207
208
209
210
211
212
213
214
215
216
217
218
219

2.0 HARDWARE REQUIREMENTS

THE FOLLOWING HARDWARE IS REQUIRED TO RUN THE RMO3 DRIVE COMPATIBILITY PROGRAM, FOR EACH SUBSYSTEM WHICH MAY BE PRESENT:

PDP-11/04, (05,10 MFG. ONLY), 20,30,34,35,40,45,50,70
16K MEMORY
CONSOLE TERMINAL
RH11(70) CONTROLLER
1 TO 8 RMO3 DISK DRIVES PER CONTROLLER

IN ADDITION, A SINGLE RMO3 DISK CARTRIDGE IS REQUIRED WHICH MUST BE FORMATTED IN 32 SECTOR FORMAT, ON A RELIABLE WELL-ALIGNED(REFERENCE PACK) RMO3 DRIVE.
THIS CARTRIDGE WILL BE MOVED FROM DRIVE TO DRIVE, (ON UP TO 16 DRIVES) ON EACH OF THE TWO PASSES.

3.0 PRELIMINARY PROGRAM REQUIREMENTS

BEFORE RUNNING THE RMO3 DRIVE COMPATIBILITY PROGRAM, THE SUBSYSTEM(S) UNDER TEST SHOULD BE CAPABLE OF PASSING THE CONTROLLER DIAGNOSTICS AND THE DRIVE DIAGNOSTICS. IN ADDITION, THE CARTRIDGE MUST BE FORMATTED IN 32 SECTOR FORMAT USING THE PACK FORMATTER.

4.0 GENERAL PROGRAM CONSIDERATIONS

4.1 SYSMAC

THIS PROGRAM USES PORTIONS OF THE SYSMAC DIAGNOSTIC SYSTEM MACRO PACKAGE.

4.2 XXDP

THIS PROGRAM MAY BE LOADED UNDER XXDP, AND MAY BE RUN IN DUMP MODE ONLY. DUE TO MANUAL INTERVENTION AND LACK OF END-OF-PASS HOOKS, THE PROGRAM IS NOT XXDP CHAINABLE.

220
221
222
223
224
225
226
227
228
229
230
231
232
233
234
235
236
237
238
239
240
241
242
243
244
245
246
247
248
249
250
251
252
253
254
255
256
257
258
259
260
261
262
263
264
265
266
267
268
269
270
271
272
273

4.3 ACT

THIS PROGRAM MAY BE LOADED UNDER ACT AND MAY BE RUN IN DUMP MODE ONLY.
IT IS NOT CHAINABLE UNDER ACT.

4.4 APT

THIS PROGRAM MAY BE LOADED BY THE APT SYSTEM, BUT MAY BE RUN IN
PROGRAM (DUMP) MODE ONLY. IT CANNOT BE RUN IN APT SCRIPT MODE.

4.5 DUAL-ACCESS

THIS PROGRAM DOES NOT UTILIZE THE DUAL-ACCESS OPTION IN ANY WAY, AND
ALL DRIVES UNDER TEST SHOULD BE DE-SELECTED THROUGH THE PORT WHICH IS
NOT IN USE, OR LOCKED ON THE PORT BEING TESTED.

4.6 MEMORY MANAGEMENT

MEMORY MANAGEMENT IS NOT UTILIZED IN THIS PROGRAM. IF IT IS
INSTALLED, IT IS DISABLED BY THE PROGRAM.

4.7 MEMORY PARITY OPTION

IF PARITY MEMORY IS INSTALLED, MEMORY PARITY TRAPS ARE DISABLED BY THE
PROGRAM.

4.8 BAD SECTORS

THE LIST OF BAD SECTORS ON THE CARTRIDGE IS OBTAINED FROM THE FIRST
DRIVE TO BE TESTED ON THE CURRENT SUBSYSTEM ACCORDING TO A SWITCH
REGISTER OPTION (SEE SECTION 6.2) THIS LIST MAY BE TYPED AT THE
CONSOLE AT THE START OF THE FIRST PASS. ALL DATA ERRORS OCCURING IN
THE PROGRAM ARE IGNORED IF THEY OCCUR IN SECTORS DESIGNATED AS BAD.

4.9 EXECUTION TIME

THE TOTAL TIME REQUIRED TO RUN THE DRIVE COMPATIBILITY PROGRAM IS
DIRECTLY PROPORTIONAL TO THE NUMBER OF DRIVES TO BE TESTED AND
REQUIRES ABOUT 2 MINUTES PER DRIVE, EXCLUDING OPERATOR INTERVENTION

274
275
276
277
278
279
280
281
282
283
284
285
286
287
288
289
290
291
292
293
294
295
296
297
298
299
300
301
302
303
304
305
306
307
308
309
310
311
312
313
314
315
316
317
318
319
320
321
322
323
324
325
326
327
328

5.0 PROGRAM LOAD MEDIA

THIS PROGRAM CAN BE LOADED FROM PAPER TAPE USING THE ABSOLUTE LOADER OR FROM THE ACT OR APT SYSTEMS OR FROM ANY MEDIA SUPPORTED BY XXDP.

6.0 PROGRAM OPTIONS

6.1 STARTING ADDRESSES

200 - THIS IS THE STARTING ADDRESS FOR DEFAULT PARAMETERS AND RUNNING OF PASS 1 AND PASS 2 ON A SINGLE SUBSYSTEM. THE PROGRAM WILL USE DEFAULT RH11(70) BASE ADDRESS, INTERRUPT VECTOR AND PRIORITY.
 THE PROGRAM WILL ASSUME ALL DRIVES TO BE TESTED RESIDE ON ONE RH11(70)/RMO3 SUBSYSTEM ONLY.

204 - THIS IS THE STARTING ADDRESS TO RUN PASS 1 ON ALL RH11(70)/RMO3 SUBSYSTEMS WHICH RESIDE ON THIS PDP-11 SYSTEM. THE PROGRAM WILL ASK FOR THE RH11(70) BASE ADDRESS, INTERRUPT VECTOR, AND PRIORITY FOR EACH SUBSYSTEM ON THIS SYSTEM. AND IT ASKS FOR THE LETTER NAMES (A THRU H) ASSIGNED TO ALL OTHER SUBSYSTEMS, AND THE DRIVE(S) WHICH WILL BE TESTED ON EACH.

220 - THIS IS THE STARTING ADDRESS TO RUN PASS 2 ON ALL RH11(70)/RMO3 SUBSYSTEMS WHICH RESIDE ON THIS PDP-11 SYSTEM. THE PROGRAM WILL ASK FOR THE RH11(70) BASE ADDRESS, INTERRUPT VECTOR FOR EACH SUBSYSTEM ON THIS SYSTEM, AND IT ASKS FOR THE LETTER NAMES (A THRU H) ASSIGNED TO ALL OTHER SUBSYSTEMS, AND THE DRIVE(S) WHICH WILL BE TESTED ON EACH.

6.2 SWITCH REGISTER OPTIONS USED

THIS PROGRAM IS DESIGNED TO ALLOW THE USE OF THE HARDWARE SWITCH REGISTER IF PRESENT, OR THE SYSMAC-SUPPORTED SOFTWARE SWITCH REGISTER (IF HARDWARE SWR IS NOT PRESENT, OR IS SET TO ALL ONES). IN EITHER CASE, THE FOLLOWING OPTIONS ARE IMPLEMENTED WHEN THE APPROPRIATE BITS ARE SET TO 1:

BIT	OPTION
---	-----
15	HALT ON ERROR
14	LOOP ON CURRENT TEST

329
330
331
332
333
334
335
336
337
338
339
340
341
342
343
344
345
346
347
348
349
350
351
352
353
354
355
356
357
358
359
360
361
362
363
364
365
366
367
368
369
370
371
372
373
374
375
376
377
378
379
380
381
382
383

13	INHIBIT ERROR REPORTS
12	REPORT DESCRIPTION ONLY, ON ERRORS
11	UNUSED
10	BELL ON ERROR
09	LOOP ON ERROR
08	APPLY RANDOM STALL BETWEEN OPERATIONS
07	TYPE BAD SECTOR FILES (BSF'S) AT START
06-00	UNUSED

7.0 RUNNING THE PROGRAM

ONCE THE PROGRAM HAS BEEN LOADED INTO CORE (IN A GIVEN SYSTEM, IF THERE ARE MULTIPLE SYSTEMS) THE FOLLOWING STEPS MUST BE TAKEN TO RUN THE PROGRAM:

1. INSURE THAT ALL DRIVES TO BE TESTED ARE POWERED UP AND SINGLE PORT SELECTED.
2. LOAD THE DESIRED START ADDRESS.
3. SET ANY DESIRED BITS IN THE HARDWARE SWITCH REGISTER (IF PRESENT).
4. START THE PROGRAM.
5. FOLLOW ALL INSTRUCTIONS TYPED BY THE PROGRAM PERTAINING TO THE MANUAL INTERVENTION REQUIRED, AND THE ALTERNATE USE OF MULTIPLE SYSTEMS (IF THERE ARE ANY).

8.0 OPERATIONAL DIALOGUE

THIS SECTION DESCRIBES THE CONSOLE TERMINAL DIALOGUE THROUGH WHICH THE PROGRAM DIRECTS THE OPERATOR, IN THE SELECTION OF OPTIONS AND THE LOADING AND UNLOADING OF DRIVES, AND THE MOVEMENT OF THE TEST CARTRIDGE. THE EXACT DIALOGUE WHICH IS USED DEPENDS UPON THE STARTING ADDRESS WHICH WAS CHOSEN (SEE SECTION 6.1).

IN THE FOLLOWING DISCUSSION AND IN THE PRINTOUT OF TEST RESULTS, DRIVES TO BE TESTED WILL BE REFERRED TO BY A LETTER AND A NUMBER. THE LETTER IS THE SUBSYSTEM LETTER NAME (OPERATOR ASSIGNED), AND THE NUMBER IS THE DRIVE NUMBER ON THAT SUBSYSTEM. FOR EXAMPLE, DRIVE C6 REFERS TO DRIVE 6 ON SUBSYSTEM C.

384
385
386
387
388
389
390
391
392
393
394
395
396
397
398
399
400
401
402
403
404
405
406
407
408
409
410
411
412
413
414
415
416
417
418
419
420
421
422
423
424
425
426
427
428
429
430
431
432
433
434
435
436
437
438
439

8.1 DIALOGUE FOR ADDRESS 200 START

THIS STARTING ADDRESS MAY BE USED FOR DEFAULTING PARAMETERS ON ONE SUB-SYSTEM.

THE PROGRAM FIRST IDENTIFIES ITSELF AS FOLLOWS:

(MAINDEC DZRMI-A) - RMO3 DRIVE COMPATIBILITY TEST

THEN, THE PROGRAM ASKS THE DRIVES TO BE TESTED.

THE PROGRAM TYPES THE DRIVE LIST, AS IN THE FOLLOWING EXAMPLE:

DRIVES = 2,5,7<CR>

THE PROGRAM NOW PROCEEDS WITH PASS 1, AND DIRECTS THE OPERATOR IN THE MOUNTING OF THE PACK, AS DESCRIBED IN SECTION 8.4.

PLEASE NOTE THAT THERE IS ONLY ONE SUBSYSTEM ON AN ADR. 200 START, AND IT IS NAMED SUBSYSTEM A. THE DRIVES IN THE ABOVE EXAMPLE WOULD BE REFERRED TO AS A2, A5, A7 IN THE TEST RESULTS PRINTOUT AT THE END OF PASS 2.

8.2 DIALOGUE FOR ADDRESS 204 START

THIS STARTING ADDRESS MUST BE USED ON EACH SYSTEM, WHEN THERE IS MORE THAN ONE SUBSYSTEM, BUT IT MAY ALSO BE USED WHEN THERE IS JUST ONE SUBSYSTEM (TOTAL), TO SPECIFY DRIVES TO TEST AND NON-DEFAULT PARAMETER VALUES, FOR PASS 1.

THE PROGRAM IDENTIFIES ITSELF AS FOLLOWS:

(MAINDEC DZRMI-A)- RMO3 DRIVE COMPATIBILITY TEST

THEN, THE PROGRAM ASKS THE OPERATOR FOR THE DRIVES TO BE TESTED ON EACH OF THE POSSIBLE SUBSYSTEMS (STARTING WITH A - THE NAMES RANGE FROM SUBSYS A TO SUBSYS H. THERE COULD BE UP TO 8 SUBSYSTEMS, WITH A DRIVE ON EACH) :

SUBSYS A DRIVE(S) =

THE OPERATOR THEN TYPES THE DESIRED DRIVE NUMBERS, AS IN THE FOLLOWING EXAMPLE:

SUBSYS A DRIVE(S) = 2,5,7<CR>

THE PROGRAM THEN VERIFIES THE DRIVE NUMBERS BY TYPING :

WILL TEST DRIVE(S) 2,5,7 ON SUBSYS A.

NEXT, THE PROGRAM ASKS THE FOLLOWING QUESTION:

440
441
442
443
444
445
446
447
448
449
450
451
452
453
454
455
456
457
458
459
460
461
462
463
464
465
466
467
468
469
470
471
472
473
474
475
476
477
478
479
480
481
482
483
484
485
486

IS THERE ANOTHER SUBSYS (Y OR N <CR>)?

THE OPERATOR TYPES Y<CR> OR N<CR>. (IF JUST <CR> IS TYPED, THE PROGRAM ASSUMES THAT N<CR> WAS TYPED). IF THE OPERATOR TYPED N, THE PROGRAM PROCEEDS WITH PASS 1, AND DIRECTS THE OPERATOR IN THE MOUNTING OF THE PACK, AS DESCRIBED IN SECTION 8.4. IF Y WAS TYPED, THE PROGRAM ASKS FOR THE NUMBERS OF THE DRIVES TO BE TESTED ON THE NEXT SUBSYSTEM (SUBSYS B) AS FOLLOWS:

SUBSYS B DRIVE(S) =

THE OPERATOR TYPES THE DRIVE NUMBERS, AS IN THE FOLLOWING EXAMPLE:

SUBSYS B DRIVE(S) = 2,3<CR>

THE PROGRAM THEN VERIFIES THE DRIVE NUMBERS. BY TYPING :

WILL TEST DRIVE(S) 2,3 ON SUBSYS B.

NEXT, THE PROGRAM WILL ASK :

IS THERE ANOTHER SUBSYS (Y OR N <CR>)?

AND IN THE SAME MANNER, THE OPERATOR SPECIFIES THE DRIVES ON EACH OF THE REMAINING SUBSYSTEMS, UNTIL ALL HAVE BEEN SPECIFIED.

ALL SUBSYSTEMS MUST BE TESTED IN THE ORDER IN WHICH THE LETTERS ARE ASSIGNED (A THRU H). NEXT, THE PROGRAM ALLOWS THE OPERATOR TO ALTER THE RH11(70) BUS ADDRESS, VECTOR ADDRESS FOR THIS SUBSYSTEM. FOR EACH PARAMETER THE CURRENT VALUE IS TYPED, AND THE OPERATOR IS GIVEN THE OPPORTUNITY TO TYPE IN A NEW VALUE, PLUS <CR>. IF JUST <CR> IS TYPED, THE PARAMETER IS NOT CHANGED. WHEN THE PROGRAM IS FIRST LOADED, THE FOLLOWING DEFAULT VALUES ARE ASSIGNED: RH11(70) BUS ADDRESS = 177670, VECTOR ADDRESS = 240, (IF 200 START). THE FOLLOWING EXAMPLE SHOWS A PRINTOUT IN WHICH BUS ADDRESS AND VECTOR WERE CHANGED:

RMCS1 = 000000 177670
RMVEC = 000 254

THEN THE PROGRAM PROCEEDS WITH PASS 1, AND DIRECTS THE OPERATOR IN THE MOUNTING OF THE PACK, AS DESCRIBED IN SECTION 8.4. AT THE COMPLETION OF PASS 1 ON THE SUBSYSTEM, THE PROGRAM WILL INFORM THE OPERATOR HOW

487
488
489
490
491
492
493
494
495
496
497
498
499
500
501
502
503
504
505
506
507
508
509
510
511
512
513
514
515
516
517
518
519
520
521
522
523
524
525
526
527
528
529
530
531
532
533
534
535
536
537
538
539
540
541
542

TO PERFORM PASS 1 ON THE NEXT SUBSYSTEM.

8.3 DIALOGUE FOR ADDRESS 220 START

THIS STARTING ADDRESS MUST BE USED ON EACH SYSTEM, WHEN THERE IS MORE THAN 1 SUBSYSTEM, BUT IT MAY ALSO BE USED WHEN THERE IS JUST ONE SUBSYSTEM (TOTAL) TO SPECIFY DRIVES TO TEST AND NON-DEFAULT PARAMETER VALUES, FOR PASS 2. THE PROGRAM IDENTIFIES ITSELF, AS FOLLOWS :

(MAINDEC DZRM1-A) - RMO3 DRIVE COMPATIBILITY TEST

THE DIALOGUE FOR 220 START IS IDENTICAL TO THE DIALOGUE FOR THE 204 START DESCRIBED ABOVE (SECTION 8.2), FOR THE SELECTION OF SUBSYSTEM PARAMETERS AND THE SPECIFICATION OF ALL DRIVES TO BE TESTED ON THE VARIOUS SUBSYSTEMS. HOWEVER, AFTER THIS DIALOGUE IS COMPLETED, THE PROGRAM PROCEEDS WITH PASS 2, AND DIRECTS THE OPERATOR IN THE MOVEMENT OF THE PACK, AS DESCRIBED IN SECTION 8.5.

NOTE THAT SINCE THE APPROPRIATE PROCESSOR MUST BE STARTED AT THE STARTING ADDRESS FOR EACH SUBSYSTEM TO BE TESTED, THE COMPATIBILITY TEST MAY BE PERFORMED IN STEPS, AT VARIOUS TIMES AND BETWEEN VARIOUS DISTANT LOCATIONS, BY MOVING THE TEST PACK AND SAVING THE PRINTOUT FROM EACH PASS ON EACH PDP-11 SYSTEM INVOLVED.

8.4 PASS 1 DIALOGUE

AFTER THE SELECTION OF PARAMETERS AND DRIVES HAS BEEN COMPLETED ON THE CURRENT SUBSYSTEM (SECTIONS 8.1-8.2), THE PROGRAM INDICATES THE START OF PASS 1 AS FOLLOWS:

** STARTING PASS 1 **

NEXT, THE PROGRAM SELECTS THE FIRST DRIVE TO BE TESTED ON THIS SUBSYSTEM, AND INSTRUCTS THE OPERATOR TO MOUNT THE TEST CARTRIDGE AND LOAD THE HEADS ON THAT DRIVE, AS IN THE FOLLOWING EXAMPLE:

MOUNT PACK ON DRIVE A2 AND LOAD.
TYPE R<CR> WHEN DRIVE READY:

THE OPERATOR PERFORMS THIS TASK AND TYPES R<CR> WHEN THE DRIVE READY LIGHT IS ON. THE PROGRAM PERFORMS PASS 1 FUNCTIONS ON THIS DRIVE (SEE SECTION 9.1) AND THEN INSTRUCTS THE OPERATOR TO UNLOAD THE DRIVE AND REMOVE THE PACK AS FOLLOWS:

UNLOAD DRIVE A2 AND REMOVE PACK.
TYPE R<CR> WHEN DONE:

543
544
545
546
547
548
549
550
551
552
553
554
555
556
557
558
559
560
561
562
563
564
565
566
567
568
569
570
571
572
573
574
575
576
577
578
579
580
581
582
583
584
585
586
587
588
589
590
591
592
593
594
595
596
597
598

THE OPERATOR PERFORMS THESE FUNCTIONS AND TYPES R<CR> AFTER THE PACK HAS BEEN REMOVED.

IN THE SAME MANNER, THE PROGRAM INSTRUCTS THE OPERATOR IN THE MOVEMENT OF THE PACK THROUGHOUT THE REST OF THE DRIVES ON THE CURRENT SUBSYSTEM. WHEN THIS HAS BEEN COMPLETED, THE PROGRAM DOES ONE OF THREE THINGS: (1) IF THERE IS ONLY ONE SUBSYSTEM (FROM ADR 200 START) THE PROGRAM BEGINS PASS 2 (SEE SECTION 8.5). (2) IF THERE IS ANOTHER SUBSYSTEM, THE PROGRAM DIRECTS THE OPERATOR TO PERFORM PASS 1 ON THE NEXT SUBSYS AS FOLLOWS :

STARTING PASS 1 ON SUBSYS B

(3) IF THERE ARE NO MORE DRIVES TO TEST IN PASS 1 ON ANY SUBSYS, THE PROGRAM DIRECTS THE OPERATOR TO BEGIN PASS 2 ON THE FIRST SUBSYS (SEE SECT. 8.5) AS FOLLOWS :

STARTING PASS 2 ON SUBSYS A

8.5 PASS 2 DIALOGUE

THE OPERATOR RETURNS TO THE FIRST SUBSYSTEM TO PERFORM PASS 2 EITHER THROUGH THE DIALOGUE OF THE ADR 200 START, OR AFTER THE SELECTION OF PARAMETERS AND DRIVES HAS BEEN COMPLETED IN ACCORDANCE WITH THE DIALOGUE OF THE ADR 220 START (SEE SECTION 8.3). IN EITHER CASE, THE PROGRAM INDICATES THE START OF PASS 2 BY TYPING :

** STARTING PASS 2 **

THE PROGRAM THEN DIRECTS THE OPERATOR IN THE UNLOADING, PACK MOVEMENT, AND LOADING OF ALL DRIVES ON THE FIRST SUBSYSTEM, IN THE SAME MANNER AS DESCRIBED FOR PASS 1 (SEE SECTION 8.4).

HOWEVER, AFTER PASS 2 TESTING (SEE SECTION 9.2) IS COMPLETED ON A GIVEN DRIVE, THE ENTIRE TEST RESULTS FOR THAT DRIVE ARE TYPED. THE DETAILS OF THIS PRINTOUT ARE DESCRIBED IN SECTION 10. AFTER THE DETAILS OF THE TESTING ARE DESCRIBED.

WHEN PASS 2 HAS BEEN COMPLETED FOR ALL DRIVES ON THE FIRST SUBSYSTEM, THE PROGRAM DOES ONE OF TWO THINGS: (1) IF THERE IS ONLY ONE SUBSYSTEM (FROM ADR 200 START) OR IF ALL DRIVES ON ALL SUBSYSTEMS HAVE BEEN TESTED IN PASS 2 (FROM ADR 220 START), THE ENTIRE TESTING AND REPORTING HAVE BEEN COMPLETED, AND THE PROGRAM TYPES:

** END OF TESTING **

C02

MAINDEC-11-DZRM1 A0/00, RM03 DRIVE COMPATIBILITY TEST MACY11 30(1046) 21-JUL-77 16:51 PAGE 15
DZRM1A.P11 21-JUL-77 15:44

SEQ 0014

599
600
601
602
603
604
605
606

2) IF THERE IS ANOTHER SUBSYSTEM, HOWEVER, THE PROGRAM DIRECTS THE
OPERATOR TO PERFORM PASS 2 ON THE NEXT SUBSYSTEM AS FOLLOWS
:

STARTING PASS 2 ON SUBSYS B

607
608
609
610
611
612
613
614
615
616
617
618
619
620
621
622
623
624
625
626
627
628
629
630
631
632
633
634
635
636
637
638
639
640
641
642
643
644
645
646
647
648
649
650
651
652
653
654
655
656
657
658

9.0 DESCRIPTION OF TESTS

THE MAIN FUNCTIONAL BLOCKS OF CODE IN THE PROGRAM ARE ASSIGNED TEST NUMBERS, FOR THE PURPOSE OF IDENTIFICATION IN ERROR PRINTOUTS. TEST 0 REFERS TO THE OPERATOR INPUT DIALOGUE ROUTINES DESCRIBED IN SECTIONS 8.1-8.3. THE OTHER TEST NUMBERS ARE ASSIGNED BELOW, IN THE DESCRIPTION OF PASS 1 AND PASS 2 TESTING.

IN THE FOLLOWING SECTIONS, TABLES A-G ARE REFERRED TO. IN THESE TABLES, DRIVES ARE NAMED FROM 0-7 FOR ILLUSTRATIVE PURPOSES, ALTHOUGH THE DRIVES ARE NAMED THE FOLLOWING WAY IN AN ACTUAL SITUATION : A0,A1, A2,...B0,B1,B2,...C0,C1,C2,... ETC. (SEE SECTION 8.0).

9.1 DESCRIPTION OF PASS 1 TESTS

IN PASS 1, THE BASIC READ/WRITE CAPABILITY OF EACH DRIVE IS DEMONSTRATED, AND COMPATIBILITY DATA PATTERNS ARE WRITTEN BY ALL DRIVES UPON THE SAME TEST CARTRIDGE.

THE SEQUENCE OF OPERATIONS PERFORMED ON EACH DRIVE IS AS FOLLOWS:

1. TEST 1 - MOUNTING OF TEST CARTRIDGE FOR PASS 1 - THE OPERATOR MOUNTS THE PACK ON THIS DRIVE AND MANUALLY LOADS THE HEADS, AS DIRECTED BY THE PROGRAM (SEE SECTION 8.4).
2. TEST 2 - BASIC READ/WRITE DATA TEST - THE PROGRAM PERFORMS A WRITE AND WRITE CHECK OPERATION USING A "WORST CASE" DATA PATTERN, AT THE APPROPRIATE SECTOR FOR THIS DRIVE (SEE TABLE A) ON ALL SURFACES. THE PURPOSE OF THIS OPERATION IS TO VERIFY THE BASIC READ/WRITE CAPABILITY OF THE DRIVE ON PASS 1. THE ENTIRE SECTOR IS WRITTEN WITH THE REPETITION OF THE DATA PATTERN SHOWN IN TABLE B.
3. TEST 3 - THE PROGRAM WRITES ALL SECTORS FOR THIS DRIVE WITHIN THE CYLINDER BLOCKS SHOWN IN TABLE C ON ALL SURFACES USING A SINGLE REPEATED WORD OF THE PATTERN IN TABLE G. DRIVE 0 USES WORD 0, DRIVE 1 USES WORD 1, DRIVE 7 USES WORD 7, ETC. THUS, THE DATA FROM EACH DRIVE IS UNIQUE. TABLE C HAS BEEN DETERMINED AS FOLLOWS:

IN EACH OF THE SEVEN WRITE CURRENT ZONES ON EACH SURFACE, SECTORS ARE WRITTEN WITHIN TWO DISTINCT CYLINDER BLOCKS. THE FIRST 16 CYLINDERS OF EACH WRITE CURRENT ZONE IS THE FIRST BLOCK USED FOR WRITE TEST IN PASS 2. THE LAST 16 CYLINDERS OF EACH CURRENT

659
660
661
662
663
664
665
666
667
668
669
670
671
672
673
674
675
676
677
678
679
680
681
682
683
684
685
686
687
688
689
690
691
692
693
694

ZONE (EXCEPT THE INNERMOST ZONE) IS THE SECOND BLOCK USED FOR READ TEST IN PASS 2. WITHIN EACH CURRENT ZONE, THESE TWO BLOCKS ARE IDENTICALLY WRITTEN. HOWEVER, THE SECTORS DESIGNATED TO EACH DRIVE ARE ROTATED FROM ZONE TO ZONE SO THAT THE DATA APPEARS AT VARIOUS ANGULAR POSITIONS ON THE PACK.

WITHIN EACH CYLINDER BLOCK, UP TO 32 SECTORS ARE WRITTEN (DEPENDING ON THE NUMBER OF DRIVES BEING TESTED) ON EACH CYLINDER.

THE BASIC LAYOUT OF A TYPICAL CYLINDER BLOCK IS SHOWN IN TABLE D, WHERE THE BLOCK SHOWN IS THE READ TEST BLOCK FOR ZONE 1, WHICH STARTS ON CYLINDER 112, AND HAS THE ROTATING STARTING SECTOR = SECTOR 0. EACH NUMBER INSIDE THE BLOCK IS THE NUMBER OF THE DRIVE WHICH WRITES THAT SECTOR. TABLE D SHOWS THE BLOCKS WRITTEN BY EACH OF 16 DRIVES. IF ANY OF THE DRIVES SHOWN ARE NOT PRESENT, HOWEVER, THE BLOCKS RESERVED FOR THE MISSING DRIVES ARE SIMPLY NOT WRITTEN.

THE ABOVE PATTERN OF SECTOR WRITES INSURES THAT DATA FROM EACH DRIVE IS WRITTEN ON ADJACENT CYLINDERS TO DATA FROM EVERY OTHER DRIVE, IN BOTH DIRECTIONS. IN ADDITION, THE ROTATION OF THE ABOVE SECTORS FROM CURRENT ZONE TO CURRENT ZONE INSURES THAT WRITE TEST AND READ TEST ARE DONE AT SEVERAL DIFFERENT ANGULAR POSITIONS WITH RESPECT TO THE CARTRIDGE.

4. TEST 4 - DISMOUNTING OF TEST CARTRIDGE IN PASS 1 - THE OPERATOR UNLOADS THE DRIVE AND DISMOUNTS THE PACK, AS DIRECTED BY THE PROGRAM (SEE SECTION B.4), TO PROCEED WITH THE ABOVE STEPS ON THE NEXT DRIVE.

695
696
697
698
699
700
701
702
703
704
705
706
707
708
709
710
711
712
713
714
715
716
717
718
719
720
721
722
723
724
725
726
727
728
729
730
731
732
733
734
735
736
737
738
739
740
741
742
743
744
745
746
747

9.2 DESCRIPTION OF PASS 2 TESTS

IN PASS 2, THE ABILITY OF EACH DRIVE TO COMPLETELY OVERWRITE DATA WRITTEN BY ALL OTHER DRIVES AND TO READ DATA WRITTEN BY ALL OTHER DRIVES, IS TESTED.

THE SEQUENCE OF OPERATIONS PERFORMED BY EACH DRIVE IS AS FOLLOWS:

1. TEST 5 - MOUNTING OF TEST CARTRIDGE FOR PASS 2 - THE OPERATOR MOUNTS THE PACK ON THIS DRIVE AND MANUALLY LOADS THE HEADS, AS DIRECTED BY THE PROGRAM (SEE SECTION 8.5).
2. TEST 6 - WRITE TEST - NEXT, THE PROGRAM PROCEEDS TO TEST THIS DRIVE'S OVERWRITE CAPABILITY. FIRST, THE APPROPRIATE CYLINDERS IN TABLE E FOR THIS DRIVE ARE OVERWRITTEN, ON EACH SURFACE. THE DATA USED IS A REPETITION OF A SINGLE WORD OF THE PATTERN IN TABLE G. DRIVE 0 USES WORD 0, DRIVE 1 USES WORD 1, DRIVE 7 USES WORD 7, ETC.

THEN, EACH CYLINDER OVERWRITTEN IS READ BACK BY THIS DRIVE IN EACH OFFSET DIRECTION (+ AND -). THE PROGRAM SCANS FOR READ ERRORS (DCK, HCRC, ETC.) DURING THIS READ, AND IF ONE OCCURS, THE PROGRAM DETERMINES WHICH DRIVE'S DATA HAS NOT BEEN CORRECTLY OVERWRITTEN, AND A SCORE FOR THAT DRIVE IS DECREMENTED. THEN, THE TRANSFER IS CONTINUED AT THE NEXT SECTOR, WITH THAT OFFSET VALUE. THE READS ARE DONE WITH ALL OF THE ABOVE OFFSETS APPLIED, AND A SEPARATE SCORE FOR EACH DRIVE IS KEPT WHILE THE CURRENT DRIVE IS PERFORMING THE OVERWRITES. FOR EACH TRACK, SCORES ARE AVERAGED OVER ALL CYLS TESTED, IN EACH OFFSET DIRECTION. AT THE COMPLETION OF THE OVERWRITE TEST ON THIS DRIVE, THE SCORES OF ALL THE DRIVES ARE CONVERTED AND STORED, FOR PRINTING AT THE END OF PASS 2 (AS DESCRIBED IN SECTION 10.2). EACH SCORE PROPORTIONAL TO THE OFFSET IN A GIVEN DIRECTION BY THE CURRENT DRIVE WHILE SUCCESSFULLY READING THE DATA IT WROTE OVER ONE OF THE OTHER DRIVE'S DATA. THUS, THE PRINTOUT REVEALS WHICH DRIVES ARE INVOLVED, IN A SITUATION IN WHICH A DRIVE CANNOT OVERWRITE ONE OR SEVERAL OTHER DRIVE'S DATA.

3. TEST 7 - DRIVE SELF-TEST - THE PROGRAM NEXT EVALUATES THE DRIVE'S ABILITY TO WRITE AND READ ITS OWN DATA, AT VARIOUS POSITIONS ON THE PACK. FIRST, ALL SECTORS OF THE APPROPRIATE CYLINDERS SHOWN IN TABLE F FOR THIS DRIVE ARE WRITTEN WITH THE DATA PATTERN SHOWN IN TABLE B, FOR ALL SURFACES. THEN, THE SECTORS ARE READ WITH OFFSET IN EACH DIRECTION. THE PROGRAM SCANS FOR READ ERRORS DURING EACH READ, AND IT COMPUTES A SCORE WHICH IS PROPORTIONAL TO THE FAILING OFFSET.

748
749
750
751
752
753
754
755
756
757
758
759
760
761
762
763
764
765
766
767
768
769
770
771
772
773
774
775
776
777
778
779
780
781
782
783
784
785
786
787
788

THEN, THE SCORES FOR ALL SECTORS READ IN THIS CYLINDER BLOCK ARE AVERAGED, TO COME UP WITH A DRIVE SELF-TEST SCORE FOR EACH SURFACE FOR EACH OFFSET DIRECTION. THIS SCORE IS SAVED FOR LATER USE, TO BECOME THE STANDARD FOR THE READS WHICH ARE TO FOLLOW.

4. TEST 10(OCTAL) - COMPATIBILITY DATA READ TEST - HAVING ESTABLISHED A SELF-TEST SCORE FOR THIS DRIVE, THE PROGRAM PROCEEDS TO PERFORM THE COMPATIBILITY DATA READS OF THE PATTERNS WRITTEN BY ALL THE DRIVES IN EACH CYLINDER BLOCK (ON EACH SURFACE). EACH COMPATIBILITY CYLINDER BLOCK SHOWN IN TABLE C IS READ, A CYLINDER AT A TIME IN EACH OFFSET DIRECTION. THE PROGRAM SCANS FOR READ ERRORS DURING EACH READ AND IF ONE OCCURS, THE PROGRAM DETERMINES WHICH DRIVE'S DATA WAS BEING READ AT THAT INSTANT AND A SCORE FOR THAT DRIVE IS DECREMENTED. THEN, THE TRANSFER IS CONTINUED AT THE NEXT SECTOR, WITH THAT OFFSET VALUE. THE READS ARE DONE WITH OFFSETS IN EACH DIRECTION. AND A SEPARATE SCORE FOR EACH DRIVE IS KEPT, WHILE THE CURRENT DRIVE IS READING THE COMPATIBILITY DATA. THEN, EACH SCORE IS APPROPRIATELY ADJUSTED TO REFLECT THE SELF-TEST SCORE FOR THE CURRENT DRIVE AT THAT PARTICULAR CYLINDER BLOCK. THE SCORES ARE THEN AVERAGED OVER ALL CYLINDER BLOCKS. EACH SCORE IS PROPORTIONAL TO THE CAPABILITY OF THE CURRENT DRIVE TO SUCCESSFULLY READ THE DATA WRITTEN BY ONE OF THE OTHER DRIVES, AND SCORES ARE COMPUTED SEPARATELY FOR EACH SURFACE (TRACK), FOR EACH OFFSET DIRECTION. THUS, THE PRINTOUT REVEALS WHICH DRIVES ARE INVOLVED IN A SITUATION IN WHICH A PARTICULAR DRIVE HAS DIFFICULTY IN READING THE DATA OF ONE OR SEVERAL OTHER DRIVES.
5. TEST 11(OCTAL) - TYPE TEST SCORES AND DISMOUNT PACK IN PASS 2 -
THE OVERWRITE AND COMPATIBILITY DATA READ TEST SCORES FOR THIS DRIVE ARE CONVERTED AND TYPED. THEN, THE OPERATOR UNLOADS THE DRIVE AND DISMOUNTS THE PACK AS DIRECTED BY THE PROGRAM (SEE SECTION B 5), TO PROCEED WITH THE ABOVE STEPS ON THE NEXT DRIVE.

789
790
791
792
793
794
795
796
797
798
799
800
801
802
803
804
805
806
807
808
809
810
811
812
813
814
815
816
817
818
819
820
821
822
823
824
825
826
827

10.0 PRINTOUT OF TEST RESULTS

THE TEST RESULTS ARE PRINTED AT THE END OF PASS 2 ON EACH DRIVE BEING TESTED. THESE RESULTS PERTAIN TO THE OVERWRITE TEST AND THE COMPATIBILITY DATA READ TEST.

10.1 TEST RESULTS

THE RESULTS OF BOTH THE OVERWRITE AND OF THE COMPATIBILITY DATA READ ARE PRINTED, REGARD OF DEGREE OF SUCCESS. IF THE TEST IS SUCCESSFUL, THE MESSAGES :

** ALL DRIVES ARE COMPATIBLE **

IS PRINTED. IF THE TEST IS FAILURE, THE TEST RESULTS ARE TABULAR IN FORM AS SHOWN.

IN THE FOLLOWING EXAMPLE, THERE ARE 2 SYSTEMS, AND THE DRIVES BEING TESTED ARE A0,A1,A2,B0, AND B5. THE TEST RESULTS FOR DRIVE A1 ARE SHOWN BELOW:

SCORES FOR DRIVE A1 :

TRACK NO.	DRIVE READ	OVRWRT OFST-	OVRWRT OFST+	READ OFST-	READ OFST+
0	A2	* 0	* 0		

THE ABOVE EXAMPLE REVEALS A POSSIBLE COMPATIBILITY PROBLEM EXISTS BETWEEN DRIVES A1 AND A2. NOTICE THAT ON TRACK 0, THAT THE OVERWRITE SCORES WERE UNACCEPTABLY LOW (0), AND THE PROGRAM NOTED THESE BAD SCORES WITH AN ASTERISK (*). ALL ACCEPTABLE TEST RESULTS ARE NOT PRINTED.

828
829
830
831
832
833
834
835
836
837
838
839
840
841
842
843
844
845
846
847
848
849
850
851
852
853
854
855
856
857
858
859
860
861
862
863
864
865
866
867
868
869
870
871
872
873
874
875
876
877
878
879
880
881
882
883

11.0 ERROR REPORTING

11.1 COMMON ERRORS

THE FOLLOWING IS A LIST OF COMMON ERROR MESSAGES WHICH ACCOMPANY ERROR TYPEOUTS FROM THE RMO3 DRIVE COMPATIBILITY PROGRAM. THE ERRORS ARE SELF-EXPLANATORY.

ADDRESS PLUG CHANGE BIT SET
RH11(70) DIDN'T RESPOND TO ADDRESSING
UNCORRECTABLE MASSBUS PARITY ERROR
FATAL MASSBUS PARITY ERROR
PERSISTENT DEVICE UNSAFE
OPERATION NOT COMPLETED WITHIN TIME LIMIT
DRIVE WENT OFFLINE
NO RESPONSE TO PORT REQUEST
HEADER CRC ERROR
DATA CHECK 'DCK' ERROR
WRITE CHECK ERROR - DATA CHECK 'DCK' SET
WRITE CHCKE ERROR - DATA CHECK 'DCK' NOT SET
HEADER READ ERROR - 'FMT' BIT DROPPED
HEADER READ ERROR - HEADER COMPARE 'HCE' ERROR
FORMAT ERROR 'FER'
HEADER COMPARE 'HCE' ERROR
MISCELLANEOUS DRIVE ERROR
OPERATION INCOMPLETE 'OPI' ERROR
DRIVE TIMING 'DTE' ERROR
PARITY 'PAR' ERROR AFTER OPERATION STARTED

J02

MAINDEC-11-DZRM1 AO/OO, RMO3 DRIVE COMPATIBILITY TEST MACY11 30(1046) 21-JUL-77 16:51 PAGE 22
DZRM1A.P11 21-JUL-77 15:44

SEQ 0021

884	WRITE CLOCK FAILURE 'WCF' ERROR
885	
886	INVALID ADDRESS 'IAE' ERROR
887	
888	WRITE LOCK 'WLE' ERROR
889	
890	DATA CHECK 'DCK' SET DURING WRITE CHECK COMMAND
891	
892	RH11(70) OR UNIBUS TRANSFER ERROR
893	
894	BUS ADDRESS OR WORD COUNT INCORRECT
895	
896	DATA COMPARE ERRORS - NO OTHER ERROR(S) DETECTED
897	
898	CAN'T MATCH DATA READ WITH A PATTERN
899	
900	ERROR BIT(S) SET, BUT NO ERROR SIGNALLED BY THE RH11(70)
901	
902	ECC LOGIC FAILURE - POSITION REGISTER VALUE NOT VALID
903	
904	BUS ADDRESS AND WORD COUNT NOT CONSISTENT
905	
906	SEEK INCOMPLETE 'SKI' ERROR
907	
908	PROGRAM DETECTED POSITIONING ERROR
909	
910	DRIVE UNSAFE ERROR
911	

912
913
914
915
916
917
918
919
920
921
922
923
924
925
926
927
928
929
930
931
932
933
934
935
936
937
938
939
940
941
942
943
944
945
946
947
948
949
950
951

11.2 ERROR HANDLING

ERRORS REPORTED BY THE PROGRAM CONSIST OF COMMON FAILURES RESULTING FROM ATTEMPTED SUBSYSTEM FUNCTIONS, AS WELL AS CERTAIN ERRORS UNIQUE TO PARTICULAR TESTS. EACH ERROR PRINTOUT CONSISTS OF AN ERROR DESCRIPTION AND TEST NUMBER, POSSIBLY FOLLOWED BY HEADER LINES, COLUMN HEADINGS, AND COLUMNS OF REGISTER CONTENTS IN OCTAL. AS MUCH MEANINGFUL REGISTER DATA AS POSSIBLE (FOR EXAMPLE, RH11(70) REGISTERS) ARE REPORTED IN A GIVEN ERROR. OTHER ERROR REPORTS MAY CONSIST OF A SINGLE DESCRIPTIVE LINE.

11.3 ERROR PRINTOUT EXAMPLE

RH11(70) OR UNIBUS TRANSFER ERROR				
DRIVE	RMCS1	RMWC	RMBA	RMDA
000001	144250	174400	0055030	000431
RMCS2	RMD5	RMER1	RMA5	RMD8
000100	010700	000000	000000	000000
RMMR1	RMDT	RMOF	RMDC	RMMR2
000050	024024	010000	000716	011777
RMER2	RMEC1	RMEC2		
000000	004066	000000		

952
953
954
955
956
957
958
959
960
961
962
963
964
965
966
967
968
969
970
971
972
973
974
975
976
977
978
979
980
981
982
983
984
985
986
987
988
989
990

TABLE A

BASIC READ/WRITE TEST SECTORS

ADDRESS OF SECTOR ON EACH SURFACE

DRIVE NO. -----	CYLINDER -----	SECTORS -----
0	620	0
1	620	1
2	620	2
3	620	3
4	620	4
5	620	5
6	620	6
7	620	7
8	620	8
9	620	9
10	620	10
11	620	11
12	620	12
13	620	13
14	620	14
15	620	15

TABLE B

WORST CASE DATA PATTERN (REPEATS EVERY 16 WORDS)

991
992
993
994
995
996
997
998
999
1000
1001
1002
1003
1004
1005
1006
1007
1008
1009
1010
1011
1012
1013
1014
1015
1016
1017
1018
1019
1020
1021
1022
1023
1024
1025

<u>WORD NO.</u>	<u>DATA (OCTAL)</u>
0	066666
1	155554
2	133331
3	066663
4	155546
5	133315
6	066633
7	155466
8	133155
9	066333
10	154666
11	131555
12	063333
13	146666
14	115555
15	033333

1026
1027
1028
1029
1030
1031
1032
1033
1034
1035
1036
1037
1038
1039
1040
1041
1042
1043
1044
1045
1046
1047
1048
1049
1050
1051
1052
1053

TABLE C

CYLINDER BLOCK ASSIGNMENT FOR A GIVEN SURFACE

CURRENT ZONE - RANGE	OVERWRITE CYL BLK RANGE	COMPATIBILITY CYL BLK RANGE
-----	-----	-----
1 - CYL 0-127	CYL 0-15	CYL 112-127
2 - 128-255	128-143	240-255
3 - 256-383	256-271	368-383
4 - 384-511	384-399	496-511
5 - 512-639	512-527	624-639
6 - 640-767	640-655	752-767
7 - 768-822	768-783	---

1106
1107
1108
1109
1110
1111
1112
1113
1114
1115
1116
1117
1118
1119
1120
1121
1122
1123
1124
1125
1126
1127
1128
1129
1130
1131
1132
1133
1134
1135
1136

TABLE E

OVERWRITE CYLINDERS

DRIVE #	CYLINDERS OVERWRITTEN
0	0, 128, 256, 384, 512, 640, 768
1	1, 129, 257, 385, 513, 641, 769
2	2, 130, 258, 386, 514, 642, 770
3	3, 131, 259, 387, 515, 643, 771
4	4, 132, 260, 388, 516, 644, 772
5	5, 133, 261, 389, 517, 645, 773
6	6, 134, 262, 390, 518, 646, 774
7	7, 135, 263, 391, 519, 647, 775
8	8, 136, 264, 392, 520, 648, 776
9	9, 137, 265, 393, 521, 649, 777
10	10, 138, 266, 394, 522, 650, 778
11	11, 139, 267, 395, 523, 651, 779
12	12, 140, 268, 396, 524, 652, 780
13	13, 141, 269, 397, 525, 653, 781
14	14, 142, 270, 398, 526, 654, 782
15	15, 143, 271, 399, 527, 655, 783

1137
1138
1139
1140
1141
1142
1143
1144
1145
1146
1147
1148
1149
1150
1151
1152
1153
1154
1155
1156
1157
1158
1159
1160
1161
1162
1163
1164
1165
1166
1167
1168
1169
1170
1171

TABLE F

SELF-TEST CYLINDERS

DRIVE #	CYLINDERS
0	17, 145, 273, 401, 529, 657, 785
1	18, 146, 274, 402, 530, 658, 786
2	19, 147, 275, 403, 531, 659, 787
3	20, 148, 276, 404, 532, 660, 788
4	21, 149, 277, 405, 533, 661, 789
5	22, 150, 278, 406, 534, 662, 790
6	23, 151, 279, 407, 535, 663, 791
7	24, 152, 280, 408, 536, 664, 792
8	25, 153, 281, 409, 537, 665, 793
9	26, 154, 282, 410, 538, 666, 794
10	27, 155, 283, 411, 539, 667, 795
11	28, 156, 284, 412, 540, 668, 796
12	29, 157, 285, 413, 541, 669, 797
13	30, 158, 286, 414, 542, 670, 798
14	31, 159, 287, 415, 543, 671, 799
15	32, 160, 288, 416, 544, 672, 800

1172
1173
1174
1175
1176
1177
1178
1179
1180
1181
1182
1183
1184
1185
1186
1187
1188
1189
1190
1191
1192
1193
1194
1195
1196
1197
1198
1199
1200
1201
1202
1203
1204
1205
1206
1207
1208
1209
1210
1211
1212
1213
1214
1215
1216
1217
1218
1219
1220
1221
1222
1223
1224
1225
1226
1227

TABLE G

 PSEUDO-RANDOM DATA PATTERN

WORD #	DATA (OCTAL)
-----	-----
0	040135
1	177070
2	070414
3	064531
4	174473
5	062422
6	114352
7	036E20
8	010031
9	052336
10	017310
11	011347
12	102367
13	152567
14	001246
15	160073

12.1 RH70(11)/RMO3 DRIVER

THIS DOCUMENT IS THE USER'S GUIDE FOR THE RH70/RMO3 DRIVER.

12.2 TO INITIALIZE THE DRIVER:

JSR PC,RMINIT
 RETURN

UPON RETURN YOU MUST EXAMINE THE "DRVSTA" TABLE TO DETERMINE THE DRIVES THAT ARE ONLINE FOR TESTING. THE 'DRVSTA' TABLE IS

1228
1229
1230
1231
1232
1233
1234
1235
1236
1237
1238
1239
1240
1241
1242
1243
1244
1245
1246
1247
1248
1249
1250
1251
1252
1253
1254
1255
1256
1257
1258
1259
1260
1261
1262
1263
1264
1265
1266
1267
1268
1269
1270
1271
1272
1273
1274
1275
1276
1277
1278
1279
1280
1281
1282
1283

EIGHT BYTES; ONE BYTE PER DRIVE. THE STATE OF EACH DRIVE WILL BE INDICATED AS FOLLOWS:

DRVSTA	DRIVE STATE
>0	ONLINE RMO3
=0	OFFLINE RMO3, DRIVE IS NOT AN RMO3, OR NONEXISTENT DRIVE
<0	UNSAFE RMO3

THE DRIVE TYPE IS DEFINED IN AN 8 BYTE LONG TABLE TAGGED 'DRVTYP'. THE TABLE CONTAINS ONE BYTE FOR EACH DRIVE AND IS INDEXED BY THE DRIVE NUMBER. ENTRIES ARE ENCODED AS FOLLOWS:

DRVTYP	CONDITION
0	NONEXISTENT DRIVE
4	RMO3
-1	NOT AN RMO3

THE 'RMINIT' ROUTINE WILL DO A READIN PRESET AND WILL SET FMT22.

12.3 AFTER THE DRIVER HAS BEEN INITIALIZED, IT IS CALLED USING THE FOLLOWING SEQUENCE.

CALL: JSR RD,RMO3 ; MAKE THE CALL
 PNTDPB ; ADDRESS OF DPB*
 RETURN1 ; RETURN IF QUEUE IS FULL
 RETURN2 ; RETURN IF REQUEST IS IN
 ; QUEUE OR THERE IS AN
 ; ERROR CONDITION

*DPB (DATA PARAMETER BLOCK)

PNTDPB: .BYTE 0 ; (0) DRIVE NUMBER
 .BYTE 0 ; (1) OFFSET VALUE OR FMT22, ECT, AND HCI
 .BYTE 0 ; (2) COMMAND
 .BYTE 0 ; (3) PSEL AND A17 AND A16
 .WORD 0 ; (4) WORD COUNT (MUST BE NEG.)
 .WORD 0 ; (6) BUFFER ADDRESS OR
 ; REGISTER TABLE POINTER
 .BYTE 0 ; (10) SECTOR ADDRESS OR
 ; FIRST REG. INDEX
 .BYTE 0 ; (11) TRACK ADDRESS OR
 ; LAST REG. INDEX
 .WORD 0 ; (12) CYLINDER ADDRESS
 .WORD 0 ; (14) ERROR TABLE POINTER
 ; POINTS TO THE FIRST OF TWENTY
 ; LOCATIONS OF WHERE THE DRIVER
 ; IS TO STORE THE RH70/RMO3
 ; REGISTERS ON AN ERROR. IF LEFT
 ; ZERO REGISTERS ARE NOT SAVED.

```

.WORD 0 ;(16) STATUS/ERROR INDICATOR
;BIT15=1=>ERROR OCCURRED
;BIT07=1=>DONE
;BIT14-BIT09 AND BIT06-BIT03
;INDICATE TYPE OF ERROR

```

12.4 THE DRIVER PROVIDES A SOFTWARE TIMEOUT CAPABILITY.
TO UTILIZE THIS CAPABILITY YOU MUST SUPPLY THE "RM TIMER" ROUTINE
WITH THE ELAPSED TIME IN THE FOLLOWING MANNER:

```

MOV #16.,-(SP) ;16 MILLISECONDS BETWEEN
;CLOCK TICKS
JSR PC,RMTMR ;CALL THE TIMER ROUTINE

```

IT SHOULD BE NOTED THAT YOU MUST PROVIDE THE CODE TO DRIVE THE
CLOCK. AND THE ELAPSED TIME MUST BE IN MILLISECONDS.
THE DRIVER WILL SET THE TIMEOUT TO 1 SECOND FOR ALL POSITIONING
AND DATA TRANSFER OPERATIONS AND WILL SET THE TIMEOUT TO 30
SECONDS FOR ERROR RECOVERY OPERATIONS.

12.4.1 EXAMPLE - WRITE 1000. WORDS

```

15: JSR RO,RM03 ;CALL THE DRIVER
;DPB ADDRESS
WRTDPB
BR 15 ;WAIT FOR QUEUE IF FULL
25: TST WRTDPB+16 ;WAIT FOR COMMAND TO COMPLETE
BEQ 25
BMI ERROR1 ;ERROR OCCURRED
.
.
.

```

```

WRTDPB: .BYTE 5 ;DRIVE #5
;BYTE 0
;BYTE 161 ;WRITE COMMAND
;BYTE 0
;WORD -1000. ;WORD COUNT
;WORD WRTBUF ;BUFFER ADDRESS
;BYTE 3 ;SECTOR
;BYTE 5 ;TRACK
;WORD 400 ;CYLINDER
;WORD ERRTB5 ;ERROR TABLE
;WORD 0 ;STATUS/ERROR INDICATOR

```

ALTERNATE DPB SETUP

```

WRTDPB: .WORD 5 ;THIS SETUP ACHIEVED
;WORD WRITE ;EVERYTHING THE
;WORD -1000. ;ABOVE TABLE DID, BUT
;WORD WRTBUF ;IN A CLEANER FORMAT
;BYTE 3,3
;WORD 400,ERRTB5,0

```

12.5 RH70/RM03 REGISTERS

1284
1285
1286
1287
1288
1289
1290
1291
1292
1293
1294
1295
1296
1297
1298
1299
1300
1301
1302
1303
1304
1305
1306
1307
1308
1309
1310
1311
1312
1313
1314
1315
1316
1317
1318
1319
1320
1321
1322
1323
1324
1325
1326
1327
1328
1329
1330
1331
1332
1333
1334
1335
1336
1337
1338
1339

1340	MNEMONIC	INDEX
1341	-----	-----
1342		
1343	RMCS1	0
1344	RMWC	2
1345	RMBA	4
1346	RMDA	6
1347	RMCS2	10
1348	RMD5	12
1349	RMER1	14
1350	RMA5	16
1351	RMLA	20
1352	RMD8	22
1353	RMMR1	24
1354	RMDT	26
1355	RMSN	30
1356	RM0F	32
1357	RMDC	34
1358	RMR	36
1359	RMMR2	40
1360	RMR2	42
1361	RMEC1	44
1362	RMEC2	46

12.6 COMMANDS PERFORMED BY THE DRIVER

1363	COMMAND	CODE	COMMAND TYPE
1364	-----	-----	-----
1365			
1366			
1367			
1368			
1369	NO OPERATION	101	N
1370			
1371	UNLOAD	103	N
1372			
1373	SEEK	105	P
1374			
1375	RECALIRATE	107	P
1376			
1377	DRIVE CLEAR	111	N
1378			
1379	RELEASE	113	N
1380			
1381	OFFSET	115	P
1382			
1383	RETURN TO CENTER	117	P
1384			
1385	READIN PRESET	121	N
1386			
1387	PACK ACKNOWLEDGE	123	N
1388			
1389	SEARCH	131	P
1390			
1391	GET REGISTER(S)	141	S
1392			
1393	SET FORMAT	143	S
1394			
1395	SELECT DRIVE	145	S

1396
1397
1398
1399
1400
1401
1402
1403
1404
1405
1406
1407
1408
1409
1410
1411
1412
1413
1414
1415
1416
1417
1418
1419
1420
1421
1422
1423
1424
1425
1426
1427
1428
1429
1430
1431
1432
1433
1434
1435
1436
1437
1438
1439
1440
1441
1442
1443
1444
1445
1446
1447
1448
1449
1450
1451

WRITE CHECK DATA 151 D
 WRITE CHECK HEADER AND DATA 153 D
 WRITE DATA 161 D
 WRITE HEADER & DATA 163 D
 READ DATA 171 D
 READ HEADER & DATA 173 D

N = HOUSEKEEPING
 P = POSITIONING
 D = DATA TRANSFER
 S = SPECIAL PROVIDED BY THE DRIVER

12.7 DPB STATUS/ERROR INDICATOR WORD

THIS INDICATOR WILL INFORM THE USER OF THE RESULTS OF THE REQUEST. THIS IS ACCOMPLISHED BY SETTING VARIOUS BITS OF THE INDICATOR TO A ONE.

BIT NO.	MEANING IF ON A "1"
15	ERROR OCCURRED DONE (BIT07=0); BITS 14-10 SPECIFIES TYPE DONE (BIT07=1); BITS 06-03 SPECIFIES TYPE
14(1)	USER MADE A REQUEST FOR A FUNCTION TO BE PERFORMED ON AN OFFLINE OR UNSAFE DRIVE
13(1)	USER MADE A REQUEST FOR A FUNCTION TO BE PERFORMED ON A DRIVE THAT HAS AN UNLOAD REQUEST IN QUEUE.
12(2)	PERSISTENT UNSAFE CONDITION EXIST.
11(2)	UNCORRECTABLE PARITY ERROR OCCURRED
10(2)(4)	FATAL PARITY ERROR. A MASSBUS CLEAR WAS PERFORMED, ALL QUEUES WERE EMPTIED, AND ALL DRVACT'S SET TO THE IDLE STATE
9(3)(4)	SOFTWARE TIMEOUT OCCURRED ON THIS DRIVE
8(4)	SOFTWARE TIMEOUT OCCURRED ON ANOTHER DRIVE
7	DONE
6(2)	ERROR OCCURRED DURING AN I/O OPERATION

1452	5(2)	ERROR OCCURRED DURING AN OPERATION OTHER THAN I/O.
1453		
1454		
1455	4(2)	CORRECTABLE UNSAFE CONDITION OCCURRED
1456		
1457	3(2)	DRIVE ERROR OCCURRED THAT CAUSED AN AUTOMATIC "RECALIBRATE" SEQUENCE
1458		
1459		
1460	2	PORT REQUEST TIMEOUT. THE DRIVER REQUESTED THE DRIVE BUT THE OPPOSITE PORT DID NOT RELEASE THE DRIVE WITHIN 20 SECONDS.
1461		
1462		
1463		
1464	1	NON-EXISTENT DRIVE REQUESTED. USER MADE A REQUEST FOR A NON-EXISTENT DRIVE.
1465		
1466		
1467	(1) =>	REQUEST WASN'T PUT IN QUEUE. (RH70/RM03 REGISTERS WERE NOT SAVED)
1468		
1469		
1470	(2) =>	REQUEST QUEUE HAS BEEN EMPTIED. THE DRIVER ISSUED A "DRIVE CLEAR" TO THE DRIVE. NOTE: ALL RH70/RM03 REGISTERS ARE SAVED AS PER DPB+14 BEFORE THE "DRIVE CLEAR".
1471		
1472		
1473		
1474		
1475	(3) =>	REQUEST QUEUE HAS BEEN EMPTIED. THE DRIVER ISSUED A MASSBUS INIT. ALL RH70/RM03 REGISTERS FOR THE DRIVE WERE SAVED AS PER DPB+14 BEFORE THE INIT.
1476		
1477		
1478		
1479		
1480	(4) =>	A "RECALIBRATE" SHOULD BE ISSUED BEFORE ANY OTHER COMMAND.
1481		
1482		

12.8 ERROR CALLS MADE BY THE DRIVER.

THERE ARE A FEW ERRORS THAT CAN OCCUR THAT CAN NOT BE INDICATED IN A DPB. WHEN THIS TYPE OF ERROR IS DETECTED BY THE DRIVER IT WILL MAKE AN ERROR CALL OF THE FORM "ERROR N", WHERE "N" IS THE ERROR NUMBER AND THE ERROR WILL BE AN EMT INSTRUCTION.

N	TYPE	DATA AVAILABLE
-	----	-----
1	RH70 INTERRUPT OCCURRED (RHAS=0)	*R4= RMCS1'S ADDRESS
2	UNEXPECTED ATTENTION OCCURRED	R1= DRIVE NUMBER R3= ATA BIT *R4= RMCS1'S ADDRESS R5= (RMAS) RMERRS =RMDS RMERRS+2=RMER1 RMERRS+4=RMER2 RMERRS+6=RMER2
3	MASSBUS PARITY	RD.ADR= ADDRESS OF REG. READ

1452
1453
1454
1455
1456
1457
1458
1459
1460
1461
1462
1463
1464
1465
1466
1467
1468
1469
1470
1471
1472
1473
1474
1475
1476
1477
1478
1479
1480
1481
1482
1483
1484
1485
1486
1487
1488
1489
1490
1491
1492
1493
1494
1495
1496
1497
1498
1499
1500
1501
1502
1503
1504
1505
1506
1507

K03

1508		ERROR (MCPE=1)	RD.WRD= WORD READ
1509			
1510	4	MASSBUS PARITY	WRT.AD= ADDRESS OF REG. WRITTEN
1511		ERROR (PAR=1)	WRT.WD= WORD WRITTEN
1512			RD.WRD= WORD READ BACK
1513			
1514	5	ADDRESS PLUG CHANGE	R1= DRIVE NUMBER
1515		BIT SET ('OPE' ERROR)	R3= ATA BIT
1516			*R4= RMCS1'S ADDRESS
1517			R5= (RMAS)
1518			RMERRS =RMOS
1519			RMERRS+2=RMER1
1520			RMERRS+4=RMER2
1521			RMERRS+6=RMMR2
1522			
1523		* THIS IS THE ACTUAL UNIBUS ADDRESS (176700)	
1524			
1525			

```

1526
1527 .TITLE MAINDEC-11-DZRMI AO/00, RMO3 DRIVE COMPATIBILITY TEST
1528 ;*COPYRIGHT (C) 1976
1529 ;*DIGITAL EQUIPMENT CORP.
1530 ;*MAYNARD, MASS. 01754
1531 ;*
1532 ;*PROGRAM BY C. CHEN
1533 ;*
1534 ;*THIS PROGRAM WAS ASSEMBLED USING THE PDP-11 MAINDEC SYSMAC
1535 ;*PACKAGE (MAINDEC-11-DZQAC-C3), JAN 19, 1977.
1536 ;*
1537 .SBTTL OPERATIONAL SWITCH SETTINGS
1538 ;*
1539 ;* SWITCH USE
1540 ;* -----
1541 ;* 15 HALT ON ERROR
1542 ;* 14 LOOP ON TEST
1543 ;* 13 INHIBIT ERROR TYPEOUTS
1544 ;* 12 INHIBIT TRACE TRAP
1545 ;* 11 INHIBIT ITERATIONS
1546 ;* 10 BELL ON ERROR
1547 ;* 9 LOOP ON ERROR
1548 ;* 8 LOOP ON TEST IN SWR<7:0>
1549 ;* 7 TYPE THE BAD SECTOR FILE
1550 .SBTTL BASIC DEFINITIONS
1551 ;*INITIAL ADDRESS OF THE STACK POINTER *** 1100 ***
1552 001100 STACK= 1100
1553 ;*EQUIV EMT,ERROR ;;BASIC DEFINITION OF ERROR CALL
1554 ;*EQUIV IOT,SCOPE ;;BASIC DEFINITION OF SCOPE CALL
1555 ;*
1556 ;*MISCELLANEOUS DEFINITIONS
1557 ;*
1558 000011 HT= 11 ;;CODE FOR HORIZONTAL TAB
1559 000012 LF= 12 ;;CODE FOR LINE FEED
1560 000015 CR= 15 ;;CODE FOR CARRIAGE RETURN
1561 000200 CRLF= 200 ;;CODE FOR CARRIAGE RETURN-LINE FEED
1562 177776 PS= 177776 ;;PROCESSOR STATUS WORD
1563 ;*EQUIV PS,PSW
1564 177774 STKLMT= 177774 ;;STACK LIMIT REGISTER
1565 177772 PIRQ= 177772 ;;PROGRAM INTERRUPT REQUEST REGISTER
1566 177570 DSWR= 177570 ;;HARDWARE SWITCH REGISTER
1567 177570 DDISP= 177570 ;;HARDWARE DISPLAY REGISTER
1568 ;*
1569 ;*GENERAL PURPOSE REGISTER DEFINITIONS
1570 000000 R0= %0 ;;GENERAL REGISTER
1571 000001 R1= %1 ;;GENERAL REGISTER
1572 000002 R2= %2 ;;GENERAL REGISTER
1573 000003 R3= %3 ;;GENERAL REGISTER
1574 000004 R4= %4 ;;GENERAL REGISTER
1575 000005 R5= %5 ;;GENERAL REGISTER
1576 000006 R6= %6 ;;GENERAL REGISTER
1577 000007 R7= %7 ;;GENERAL REGISTER
1578 000006 SP= %6 ;;STACK POINTER
1579 0000J7 PC= %7 ;;PROGRAM COUNTER
1580 ;*
1581 ;*PRIORITY LEVEL DEFINITIONS

```


1582	000000	PR0=	0	:: PRIORITY LEVEL 0
1583	000040	PR1=	40	:: PRIORITY LEVEL 1
1584	000100	PR2=	100	:: PRIORITY LEVEL 2
1585	000140	PR3=	140	:: PRIORITY LEVEL 3
1586	000200	PR4=	200	:: PRIORITY LEVEL 4
1587	000240	PR5=	240	:: PRIORITY LEVEL 5
1588	000300	PR6=	300	:: PRIORITY LEVEL 6
1589	000340	PR7=	340	:: PRIORITY LEVEL 7

1591 ; * "SWITCH REGISTER" SWITCH DEFINITIONS

1592	100000	SW15=	100000
1593	040000	SW14=	40000
1594	020000	SW13=	20000
1595	010000	SW12=	10000
1596	004000	SW11=	4000
1597	002000	SW10=	2000
1598	001000	SW09=	1000
1599	000400	SW08=	400
1600	000200	SW07=	200
1601	000100	SW06=	100
1602	000040	SW05=	40
1603	000020	SW04=	20
1604	000010	SW03=	10
1605	000004	SW02=	4
1606	000002	SW01=	2
1607	000001	SW00=	1
1608		.EQUIV	SW09, SW9
1609		.EQUIV	SW08, SW8
1610		.EQUIV	SW07, SW7
1611		.EQUIV	SW06, SW6
1612		.EQUIV	SW05, SW5
1613		.EQUIV	SW04, SW4
1614		.EQUIV	SW03, SW3
1615		.EQUIV	SW02, SW2
1616		.EQUIV	SW01, SW1
1617		.EQUIV	SW00, SW0

1619 ; * DATA BIT DEFINITIONS (BIT00 TO BIT15)

1620	100000	BIT15=	100000
1621	040000	BIT14=	40000
1622	020000	BIT13=	20000
1623	010000	BIT12=	10000
1624	004000	BIT11=	4000
1625	002000	BIT10=	2000
1626	001000	BIT09=	1000
1627	000400	BIT08=	400
1628	000200	BIT07=	200
1629	000100	BIT06=	100
1630	000040	BIT05=	40
1631	000020	BIT04=	20
1632	000010	BIT03=	10
1633	000004	BIT02=	4
1634	000002	BIT01=	2
1635	000001	BIT00=	1
1636		.EQUIV	BIT09, BIT9
1637		.EQUIV	BIT08, BIT8

BASIC DEFINITIONS

1638
1639
1640
1641
1642
1643
1644
1645
1646
1647
1648
1649
1650
1651
1652
1653
1654
1655
1656
1657
1658
1659
1660
1661
1662
1663
1664
1665
1666
1667
1668
1669
1670
1671
1672
1673
1674
1675
1676
1677
1678
1679
1680
1681
1682
1683
1684
1685
1686
1687
1688
1689
1690
1691
1692
1693

```
.EQUIV BIT07,BIT7
.EQUIV BIT06,BIT6
.EQUIV BIT05,BIT5
.EQUIV BIT04,BIT4
.EQUIV BIT03,BIT3
.EQUIV BIT02,BIT2
.EQUIV BIT01,BIT1
.EQUIV BIT00,BIT0
```

```
.;#BASIC "CPU" TRAP VECTOR ADDRESSES
ERRVEC= 4 ;: TIME OUT AND OTHER ERRORS
RESVEC= 10 ;: RESERVED AND ILLEGAL INSTRUCTIONS
TBITVEC=14 ;: "T" BIT
TRTVEC= 14 ;: TRACE TRAP
BPTVEC= 14 ;: BREAKPOINT TRAP (BPT)
IOTVEC= 20 ;: INPUT/OUTPUT TRAP (IOT) **SCOPE**
PMRVEC= 24 ;: POWER FAIL
EMTVEC= 30 ;: EMULATOR TRAP (EMT) **ERROR**
TRAPVEC=34 ;: "TRAP" TRAP
TKVEC= 60 ;: TTY KEYBOARD VECTOR
TPV=C= 64 ;: TTY PRINTER VECTOR
PIRQVEC=240 ;: PROGRAM INTERRUPT REQUEST VECTOR
ABASE=176700
AVECT1=254
```

.SBTTL RMO3 REGISTERS

.SBTTL RMO3 DRIVER COMMANDS

;;*****

```
RNOP = 101 ;: NO OPERATION
SEEK = 105 ;: SEEK
RECAL = 107 ;: RECALIBRATE
DRVCLR = 111 ;: DRIVE CLEAR
RELSE = 113 ;: RELEASE
OFFSET = 115 ;: OFFSET
RTC = 117 ;: RETURN TO CENTER LINE
READIN = 121 ;: READ IN PRESET
ACK = 123 ;: PACK ACKNOWLEDGE
SEARCH = 131 ;: SEARCH
GETREG = 141 ;: GET REGISTERS
SETFMT = 143 ;: SET FORMAT (& ECI OR HCI)
SELDRV = 145 ;: SELECT DRIVE
WCKD = 151 ;: WRITE CHECK DATA
WCKHD = 153 ;: WRITE CHECK HEADER & DATA
WRDAT = 161 ;: WRITE DATA
WRTHD = 163 ;: WRITE HEADER & DATA
RDDAT = 171 ;: READ DATA
RDHD = 173 ;: READ HEADER & DATA
```

.SBTTL TRAP CATCHER

000000 . = 0

```

1694 ;*ALL UNUSED LOCATIONS FROM 4 - 776 CONTAIN A ".+2,HALT"
1695 ;*SEQUENCE TO CATCH ILLEGAL TRAPS AND INTERRUPTS
1696 ;*LOCATION 0 CONTAINS 0 TO CATCH IMPROPERLY LOADED VECTORS
1697      .=174
1698 000174 000000  DISPREG: .WORD 0      ;; SOFTWARE DISPLAY REGISTER
1699 000176 000000  SWREG:   .WORD 0      ;; SOFTWARE SWITCH REGISTER
1700      .SBTTL  STARTING ADDRESS(ES)
1701 000200 000137 003062  JMP      @#START  ;; JUMP TO STARTING ADDRESS OF PROGRAM
1702 000204 000137 003072  JMP      @#START1 ;; CHANGE THE RH11 UNIBUS ADDRESS
1703                                     ;; AFTER INITIAL START
1704
1705      .=220                                     ;; SECOND PASS STARTING ADDRESS
1706 000220 000137 003102  JMP      @#START2
1707      .SBTTL  ACT11 HOOKS
1708
1709 ;;*****
1710 ;;HOOKS REQUIRED BY ACT11
1711      $SVPC=.                                     ;; SAVE PC
1712      .=46
1713 000046 017312  SENDAD   ;; 1)SET LOC.46 TO ADDRESS OF SENDAD IN .SEOP
1714      .=52
1715 000052 040000  .WORD   40000 ;; 2)SET LOC.52 TO 40000
1716      .=$SVPC                                     ;; RESTORE PC
1717      .=1100
1718      .SBTTL  APT PARAMETER BLOCK
1719
1720 ;;*****
1721 ;;SET LOCATIONS 24 AND 44 AS REQUIRED FOR APT
1722 ;;*****
1723      .SX=.                                     ;; SAVE CURRENT LOCATION
1724      .=24                                     ;; SET POWER FAIL TO POINT TO START OF PROGRAM
1725 000024 000200  200     ;; FOR APT START UP
1726      .=44                                     ;; POINT TO APT INDIRECT ADDRESS PNTR.
1727 000044 001100  $APTHOR ;; POINT TO APT HEADER BLOCK
1728      .=$X                                     ;; RESET LOCATION COUNTER
1729 ;;*****
1730 ;;SETUP APT PARAMETER BLOCK AS DEFINED IN THE APT-PDP11 DIAGNOSTIC
1731 ;;INTERFACE SPEC.
1732
1733 $APTHD:
1734 001100 000000  $HIBTS: .WORD 0      ;; TWO HIGH BITS OF 18 BIT MAILBOX ADDR.
1735 001102 001210  $MBAOR: .WORD $MAIL  ;; ADDRESS OF APT MAILBOX (BITS 0-15)
1736 001104 000764  $STMT:  .WORD 500.   ;; RUN TIM OF LONGEST TEST
1737 001106 000764  $PASTM: .WORD 500.   ;; RUN TIME IN SECS. OF 1ST PASS ON 1 UNIT (QUICK VERIFY)
1738 001110 000764  $UNITM: .WORD 500.   ;; ADDITIONAL RUN TIME (SECS) OF A PASS FOR EACH ADDITIONAL UNIT
1739 001112 000032  .WORD   SETEND-$MAIL/2 ;; LENGTH MAILBOX-ETABLE(WORDS)
1740      TAB.XY=.

```

1741
1742
1743
1744
1745
1746
1747 001114
1748 001114 000000
1749 001114 000000
1750 001116 000
1751 001117 000
1752 001120 000000
1753 001122 000000
1754 001124 000000
1755 001126 000000
1756 001130 000
1757 001131 001
1758 001132 000000
1759 001134 000000
1760 001136 000000
1761 001140 000000
1762 001142 000000
1763 001144 000000
1764 001146 000000
1765 001150 000
1766 001151 000
1767 001152 000000
1768 001154 177570
1769 001156 177570
1770 001160 177560
1771 001162 177562
1772 001164 177564
1773 001166 177566
1774 001170 000
1775 001171 002
1776 001172 012
1777 001173 000
1778 001174 000000
1779 001176 000000
1780 001200 177607 000377
1781 001204 077
1782 001205 015
1783 001206 000012
1784
1785
1786
1787
1788
1789
1790
1791
1792
1793 001210
1794 001210 000000
1795 001212 000000
1796 001214 000000

.SBTTL COMMON TAGS

*THIS TABLE CONTAINS VARIOUS COMMON STORAGE LOCATIONS
*USED IN THE PROGRAM.

.=TAB.XY

SCMTAG: .WORD 0 ;; START OF COMMON TAGS
\$TSTNM: .BYTE 0 ;; CONTAINS THE TEST NUMBER
\$ERFLG: .BYTE 0 ;; CONTAINS ERROR FLAG
\$ICNT: .WORD 0 ;; CONTAINS SUBTEST ITERATION COUNT
\$LPADR: .WORD 0 ;; CONTAINS SCOPE LOOP ADDRESS
\$LPERR: .WORD 0 ;; CONTAINS SCOPE RETURN FOR ERRORS
\$ERTTL: .WORD 0 ;; CONTAINS TOTAL ERRORS DETECTED
\$ITEMB: .BYTE 0 ;; CONTAINS ITEM CONTROL BYTE
\$ERMAX: .BYTE 1 ;; CONTAINS MAX. ERRORS PER TEST
\$ERRPC: .WORD 0 ;; CONTAINS PC OF LAST ERROR INSTRUCTION
\$GADR: .WORD 0 ;; CONTAINS ADDRESS OF 'GOOD' DATA
\$BADADR: .WORD 0 ;; CONTAINS ADDRESS OF 'BAD' DATA
\$GDAT: .WORD 0 ;; CONTAINS 'GOOD' DATA
\$BDAT: .WORD 0 ;; CONTAINS 'BAD' DATA
 .WORD 0 ;; RESERVED--NOT TO BE USED
\$AUTOB: .BYTE 0 ;; AUTOMATIC MODE INDICATOR
\$INTAG: .BYTE 0 ;; INTERRUPT MODE INDICATOR
\$SWR: .WORD DSWR ;; ADDRESS OF SWITCH REGISTER
\$DISPLAY: .WORD DDISP ;; ADDRESS OF DISPLAY REGISTER
\$TKS: 177560 ;; TTY KBD STATUS
\$TKB: 177562 ;; TTY KBD BUFFER
\$TPS: 177564 ;; TTY PRINTER STATUS REG. ADDRESS
\$TPB: 177566 ;; TTY PRINTER BUFFER REG. ADDRESS
\$NULL: .BYTE 0 ;; CONTAINS NULL CHARACTER FOR FILLS
\$FILLS: .BYTE 2 ;; CONTAINS # OF FILLER CHARACTERS REQUIRED
\$FILLC: .BYTE 12 ;; INSERT FILL CHARS. AFTER A "LINE FEED"
\$TPFLG: .BYTE 0 ;; "TERMINAL AVAILABLE" FLAG (BIT<07>=0=YES)
\$TIMES: 0 ;; MAX. NUMBER OF ITERATIONS
\$ESCAPE: 0 ;; ESCAPE ON ERROR ADDRESS
\$BELL: .ASCIZ <207><377><377> ;; CODE FOR BELL
\$QUES: .ASCII /?/ ;; QUESTION MARK
\$CRLF: .ASCII <15> ;; CARRIAGE RETURN
\$LF: .ASCIZ <12> ;; LINE FEED

.SBTTL APT MAILBOX-ETABLE

.MLIST ME

.EVEN
\$MAIL: .WORD APT MAILBOX
\$MSGTY: .WORD AMSGTY ;; MESSAGE TYPE CODE
\$FATAL: .WORD AFATAL ;; FATAL ERROR NUMBER
\$TESTN: .WORD ATESTN ;; TEST NUMBER

1797	001216	000000	\$PASS:	.WORD	APASS	::	PASS COUNT
1798	001220	000000	\$DEVCT:	.WORD	ADEVCT	::	DEVICE COUNT
1799	001222	000000	\$UNIT:	.WORD	AUNIT	::	I/O UNIT NUMBER
1800	001224	000000	\$MSGAD:	.WORD	AMSGAD	::	MESSAGE ADDRESS
1801	001226	000000	\$MSGLG:	.WORD	AMSGLG	::	MESSAGE LENGTH
1802	001230		\$ETABLE:			::	APT ENVIRONMENT TABLE
1803	001230	000	\$ENV:	.BYTE	RENV	::	ENVIRONMENT BYTE
1804	001231	000	\$ENVM:	.BYTE	RENVM	::	ENVIRONMENT MODE BITS
1805	001232	000000	\$SWREG:	.WORD	ASWREG	::	APT SWITCH REGISTER
1806	001234	000000	\$USWR:	.WORD	AUSWR	::	USER SWITCHES
1807	001236	000000	\$CPUOP:	.WORD	ACPUOP	::	CPU TYPE, OPTIONS
1808			*			::	BITS 15-11=CPU TYPE
1809			*			::	11/04=01, 11/05=02, 11/20=03, 11/40=04, 11/45=05
1810			*			::	11/70=06, PDQ=07, Q=10
1811			*			::	BIT 10=REAL TIME CLOCK
1812			*			::	BIT 9=FLOATING POINT PROCESSOR
1813			*			::	BIT 8=MEMORY MANAGEMENT
1814	001240	000	\$MAMS1:	.BYTE	AMAMS1	::	HIGH ADDRESS, M.S. BYTE
1815	001241	000	\$MTYP1:	.BYTE	AMTYP1	::	MEM. TYPE, BLK#1
1816			*			::	MEM. TYPE BYTE -- (HIGH BYTE)
1817			*			::	900 NSEC CORE=001
1818			*			::	300 NSEC BIPOLAR=002
1819			*			::	500 NSEC MOS=003
1820	001242	000000	\$MADR1:	.WORD	AMADR1	::	HIGH ADDRESS, BLK#1
1821			*			::	MEM. LAST ADDR.=3 BYTES, THIS WORD AND LOW OF "TYPE" ABOVE
1822	001244	000	\$MAMS2:	.BYTE	AMAMS2	::	HIGH ADDRESS, M.S. BYTE
1823	001245	000	\$MTYP2:	.BYTE	AMTYP2	::	MEM. TYPE, BLK#2
1824	001246	000000	\$MADR2:	.WORD	AMADR2	::	MEM. LAST ADDRESS, BLK#2
1825	001250	000	\$MAMS3:	.BYTE	AMAMS3	::	HIGH ADDRESS, M.S. BYTE
1826	001251	000	\$MTYP3:	.BYTE	AMTYP3	::	MEM. TYPE, BLK#3
1827	001252	000000	\$MADR3:	.WORD	AMADR3	::	MEM. LAST ADDRESS, BLK#3
1828	001254	000	\$MAMS4:	.BYTE	AMAMS4	::	HIGH ADDRESS, M.S. BYTE
1829	001255	000	\$MTYP4:	.BYTE	AMTYP4	::	MEM. TYPE, BLK#4
1830	001256	000000	\$MADR4:	.WORD	AMADR4	::	MEM. LAST ADDRESS, BLK#4
1831	001260	000254	\$VECT1:	.WORD	AVECT1	::	INTERRUPT VECTOR#1 BUS PRIORITY#1
1832	001262	000000	\$VECT2:	.WORD	AVECT2	::	INTERRUPT VECTOR#2 BUS PRIORITY#2
1833	001264	176700	\$BASE:	.WORD	ABASE	::	BASE ADDRESS OF EQUIPMENT UNDER TEST
1834	001266	000000	\$DEVN:	.WORD	ADEVN	::	DEVICE MAP
1835	001270	000000	\$CDW1:	.WORD	ACDW1	::	CONTROLLER DESCRIPTION WORD#1
1836	001272	000000	\$CDW2:	.WORD	ACDW2	::	CONTROLLER DESCRIPTION WORD#2
1837	001274		\$ETEND:			::	
1838			.MEXIT			::	
1839		000015	CR	=	15		
1840		000012	LF	=	12		
1841	001274	176700	\$RMADR:	.WORD	176700	::	FIRST ADDRESS OF RH11/RMO3 REGISTERS
1842	001276	000254	\$RMVEC:	.WORD	254	::	RMO3 VECTOR ADDRESS
1843	001300	172540	\$LKCSR:	.WORD	172540	::	ADDR OF KW11-P STATUS REGISTER
1844	001302	172542	\$LKCSB:	.WORD	172542	::	ADDR OF KW11-P COUNTER BUFFER
1845	001304	000104	\$LPVEC:	.WORD	104	::	ADDR OF KW11-P VECTOR
1846	001306	177546	\$LKS:	.WORD	177546	::	ADDR OF KW11-L STATUS REGISTER
1847	001310	000100	\$LLVEC:	.WORD	100	::	ADDR OF KW11-L VECTOR
1848	001312	177777	PCLOCK:	.WORD	-1	::	'0' IF KW11-P IS ON SYSTEM
1849	001314	177777	CLKFLG:	.WORD	-1	::	'0' IF A CLOCK IS AVAILABLE
1850	001316	000074	HZ:	.WORD	74	::	74 (8) IF 60 HZ SYSTEM; 62 (8) IF 50 HZ SYSTEM
1851	001320	000000	STATIN:	.WORD	0	::	'TYPE STATISTICS' INDICATOR
1852	001322	000000	PACK:	.WORD	0	::	ENTRY TO THE TABLE D

1853		001222	DRIVE =	\$UNIT		; DRIVE # STORAGE: ERRORS 1-5 & 10
1854	001324	000000	ATTN: .WORD	0		; ATTN REG STORAGE: ERRORS 1-5 & 10
1855	001326	000000	UNIT: .WORD	0		; DRIVE # STORAGE FOR PRINTOUT
1856						; RETRY COUNT IN THE UPPER BYTE
1857	001330	000000	LSTAD: .WORD	0		; STORE LAST MEMORY ADDRESS HERE
1858	001332	000000	CHGADR: .WORD	0		; CHANGE RH11 UNIBUS ADDRESS FLAG
1859	001334	000000	CFLAG: .WORD	0		; 'CONTROL C' FLAG
1860	001336	000000	TSTNM: .WORD	0		; TEST NUMBER FOR PRINT AND SCORE RT.
1861	001340	000000	BADSEC: .WORD	0		; BAD SECTOR/TRACK FLAG
1862	001342	000000	HOUR: .WORD	0		; HOUR COUNT STORED HERE (MAXIMUM - 999.)
1863	001344	000000	MINUTE: .WORD	0		; MINUTE'S COUNT STORED HERE
1864	001346	000000	SECOND: .WORD	0		; SECOND'S COUNT STORED HERE
1865	001350	000000	SIXTEE: .WORD	0		; TIMER ROUTINE COUNTER (FOR ONE SECOND)
1866	001352	000000	CMCNT: .WORD	0		; ZONE COUNT
1867	001354	000000	CMCYL: .WORD	0		; CYLINDER ADDRESS
1868	001356	000000	STARSC: .WORD	0		; STARTING SECTOR (FOR TEST 6,8)
1869	001360	000000	CMSEC: .WORD	0		; DELTA CYLINDER COUNT
1870	001362	000000	CMTRK: .WORD	0		; TRACK ADDRESS
1871	001364	000000	MULINE: .WORD	0	; NEW LINE FLAG AND COLUMN CTR	
1872	001366	000037	SECLMT: .WORD	31.		; SECTOR ADDRESS LIMIT
1873	001370	000004	TRKLMT: .WORD	4.		; TRACK ADDRESS LIMIT
1874	001372	001466	CYLMT: .WORD	822.		; CYLINDER ADDRESS LIMIT FOR RMO3
1875	001374	000000	FAULT: .WORD	0		; =1, IF ALL DRIVES NOT COMPATIBLE

1876
1877
1878 .SBTTL COMMON PARAMETERS
1879

1880
1881 .SBTTL TABLES, CONSTANTS, AND VARIABLE LOCATIONS
1882

1883 :*****
1884 ;TABLE D
1885 ;TABLE LISTED BELOW SPECIFIES THE SECTORS TO BE WRITTEN
1886 ;BY A LOGICAL DRIVE. EACH LOGICAL DRIVE WRITES TWO SECTORS IN ONE
1887 ;CYLINDER, 16 CYLINDERS IN ONE BLOCK, 2 BLOCKS IN ONE WRITE-CURRENT
1888 ;ZONE AND 7 CURRENT ZONES IN A PACK.
1889 ;
1890 ;
1891 ;

1892	001376	000	017	015	LOG0: .BYTE	0,15.,13.,10.,6,1,11.,4,12.,13.,9.,14.,2,5,7,8.	;DRIVE 0
1893	001401	012	006	001			
1894	001404	013	004	014			
1895	001407	015	011	016			
1896	001412	002	005	007			
1897	001415	010					
1898	001416	001	000	016	LOG1: .BYTE	1,0,14.,11.,7,2,12.,5,13.,4,10.,15.,3,6,8.,9.	;DRIVE 1
1899	001421	013	007	002			
1900	001424	014	005	015			
1901	001427	004	012	017			
1902	001432	003	006	010			
1903	001435	011					
1904	001436	002	001	017	LOG2: .BYTE	2,1,15.,12.,8.,3,13.,6,14.,5,11.,0,4,7,9.,10.	;DRIVE 2
1905	001441	014	010	003			
1906	001444	015	006	016			
1907	001447	005	013	000			
1908	001452	004	007	011			

F04

1909	001455	012							
1910	001456	003	002	000	LOG3:	.BYTE	3,2,0,13.,9.,4,14.,7,15.,6,12.,1,5,8.,10.,11.		
1911	001461	015	011	004					
1912	001464	016	007	017					
1913	001467	006	014	001					
1914	001472	005	010	012					
1915	001475	013							
1916	001476	004	003	001	LOG4:	.BYTE	4,3,1,14.,10.,5,15.,8.,0,7,13.,2,6,9.,11.,12.		
1917	001501	016	012	005					
1918	001504	017	010	000					
1919	001507	007	015	002					
1920	001512	006	011	013					
1921	001515	014							
1922	001516	005	004	002	LOG5:	.BYTE	5,4,2,15.,11.,6,0,9.,1,8.,14.,3,7,10.,12.,13.		
1923	001521	017	013	006					
1924	001524	000	011	001					
1925	001527	010	016	003					
1926	001532	007	012	014					
1927	001535	015							
1928	001536	006	005	003	LOG6:	.BYTE	6,5,3,0,12.,7,1,10.,2,9.,15.,4,8.,11.,13.,14.		
1929	001541	000	014	007					
1930	001544	001	012	002					
1931	001547	011	017	004					
1932	001552	010	013	015					
1933	001555	016							
1934	001556	007	006	004	LOG7:	.BYTE	7,6,4,1,13.,8.,2,11.,3,10.,0,5,9.,12.,14.,15.		
1935	001561	001	015	010					
1936	001564	002	013	003					
1937	001567	012	000	005					
1938	001572	011	014	016					
1939	001575	017							
1940	001576	010	007	005	LOG8:	.BYTE	8.,7,5,2,14.,9.,3,12.,4,11.,1,6,10.,13.,15.,0		
1941	001601	002	016	011					
1942	001604	003	014	004					
1943	001607	013	001	006					
1944	001612	012	015	017					
1945	001615	000							
1946	001616	011	010	006	LOG9:	.BYTE	9.,8.,6,3,15.,10.,4,13.,5,12.,2,7,11.,14.,0,1		
1947	001621	003	017	012					
1948	001624	004	015	005					
1949	001627	014	002	007					
1950	001632	013	016	000					
1951	001635	001							
1952	001636	012	011	007	LOG10:	.BYTE	10.,9.,7.,4,0,11.,5,14.,6,13.,3,8.,12.,15.,1,2		
1953	001641	004	000	013					
1954	001644	005	016	006					
1955	001647	015	003	010					
1956	001652	014	017	001					
1957	001655	002							
1958	001656	013	012	010	LOG11:	.BYTE	11.,10.,8.,5,1,12.,6,15.,7,14.,4,9.,13.,0,2,3		
1959	001661	005	001	014					
1960	001664	006	017	007					
1961	001667	016	004	011					
1962	001672	015	000	002					
1963	001675	003							
1964	001676	014	013	011	LOG12:	.BYTE	12.,11.,9.,6,2,13.,7,0,8.,15.,5,10.,14.,1,3,4		

1965	001701	006	002	015	
1966	001704	007	000	010	
1967	001707	017	005	012	
1968	001712	016	001	003	
1969	001715	004			
1970	001716	015	014	012	LOG13: .BYTE 13.,12.,10.,7,3,14.,8.,1,9.,0,6,11.,15.,2,4,5
1971	001721	007	003	016	
1972	001724	010	001	011	
1973	001727	000	006	013	
1974	001732	017	002	004	
1975	001735	005			
1976	001736	016	015	013	LOG14: .BYTE 14.,13.,11.,8.,4,15.,9.,2,10.,1,7,12.,0,3,5,6
1977	001741	010	004	017	
1978	001744	011	002	012	
1979	001747	001	007	014	
1980	001752	000	003	005	
1981	001755	006			
1982	001756	017	016	014	LOG15: .BYTE 15.,14.,12.,9.,5,0,10.,3,11.,2,8.,13.,1,4,6,7
1983	001761	011	005	000	
1984	001764	012	003	013	
1985	001767	002	010	015	
1986	001772	001	004	006	
1987	001775	007			
1988					
1989	001776	000000			ASNLST: .WORD 0 ;A BIT SET IS AN ASSIGNED LOGICAL DRIVE
1990					
1991	002000	000000			ASSGN1: .WORD 0 ;A BIT SET IS AN ASSIGNED LOGICAL DRIVE FOR PASS 1
1992					
1993	002002	000000			ASSGN2: .WORD 0 ;A BIT SET IS AN ASSIGNED LOGICAL DRIVE FOR PASS 2
1994					
1995	002004	000020			SYSADP: .BLKW 16. ;SUB SYSTEM ADDRESS TABLE
1996					
1997	002044	000000			TABLEX: .WORD 0 ;CURRENT SELECTED SCORE BOARD
1998					
1999					;SCORE BOARD TABLES
2000					;
2001					;
2002					TABLE OF OVERWRITE SCORE,NEGATIVE OFFSET SCORE
2003					
2004	002046	000	000	000	OVWNO: .BYTE 0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0
2005	002051	000	000	000	
2006	002054	000	000	000	
2007	002057	000	000	000	
2008	002062	000	000	000	
2009	002065	000			
2010	002066	000	000	000	OVWN1: .BYTE 0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0
2011	002071	000	000	000	
2012	002074	000	000	000	
2013	002077	000	000	000	
2014	002102	000	000	000	
2015	002105	000			
2016	002106	000	000	000	OVWN2: .BYTE 0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0
2017	002111	000	000	000	
2018	002114	000	000	000	
2019	002117	000	000	000	
2020	002122	000	000	000	

2021	002125	000			
2022	002126	000	000	000	OVWN3: .BYTE 0,0,0,0,0,0,0,0,0,0,0,0,0,0,0
2023	002131	000	000	000	
2024	002134	000	000	000	
2025	002137	000	000	000	
2026	002142	000	000	000	
2027	002145	000			
2028	002146	000	000	000	OVWN4: .BYTE 0,0,0,0,0,0,0,0,0,0,0,0,0,0,0
2029	002151	000	000	000	
2030	002154	000	000	000	
2031	002157	000	000	000	
2032	002162	000	000	000	
2033	002165	000			
2034					
2035					;TABLE OF OVERWRITE SCORE, POSITIVE OFFSET SCORE
2036					
2037					
2038	002166	000	000	000	OVWP0: .BYTE 0,0,0,0,0,0,0,0,0,0,0,0,0,0,0
2039	002171	000	000	000	
2040	002174	000	000	000	
2041	002177	000	000	000	
2042	002202	000	000	000	
2043	002205	000			
2044					
2045	002206	000	000	000	OVWP1: .BYTE 0,0,0,0,0,0,0,0,0,0,0,0,0,0,0
2046	002211	000	000	000	
2047	002214	000	000	000	
2048	002217	000	000	000	
2049	002222	000	000	000	
2050	002225	000			
2051					
2052	002226	000	000	000	OVWP2: .BYTE 0,0,0,0,0,0,0,0,0,0,0,0,0,0,0
2053	002231	000	000	000	
2054	002234	000	000	000	
2055	002237	000	000	000	
2056	002242	000	000	000	
2057	002245	000			
2058					
2059	002246	000	000	000	OVWP3: .BYTE 0,0,0,0,0,0,0,0,0,0,0,0,0,0,0
2060	002251	000	000	000	
2061	002254	000	000	000	
2062	002257	000	000	000	
2063	002262	000	000	000	
2064	002265	000			
2065					
2066	002266	000	000	000	OVWP4: .BYTE 0,0,0,0,0,0,0,0,0,0,0,0,0,0,0
2067	002271	000	000	000	
2068	002274	000	000	000	
2069	002277	000	000	000	
2070	002302	000	000	000	
2071	002305	000			
2072					
2073					;TABLE OF READ SCORE, NEGATIVE OFFSET SCORE
2074					
2075	002306	000	000	000	RDNO: .BYTE 0,0,0,0,0,0,0,0,0,0,0,0,0,0,0
2076	002311	000	000	000	

2077	002314	000	000	000	
2078	002317	000	000	000	
2079	002322	000	000	000	
2080	002325	000			
2081	002326	000	000	000	RDN1: .BYTE 0,0,0,0,0,0,0,0,0,0,0,0,0,0,0
2082	002331	000	000	000	
2083	002334	000	000	000	
2084	002337	000	000	000	
2085	002342	000	000	000	
2086	002345	000			
2087	002346	000	000	000	RDN2: .BYTE 0,0,0,0,0,0,0,0,0,0,0,0,0,0,0
2088	002351	000	000	000	
2089	002354	000	000	000	
2090	002357	000	000	000	
2091	002362	000	000	000	
2092	002365	000			
2093	002366	000	000	000	RDN3: .BYTE 0,0,0,0,0,0,0,0,0,0,0,0,0,0,0
2094	002371	000	000	000	
2095	002374	000	000	000	
2096	002377	000	000	000	
2097	002402	000	000	000	
2098	002405	000			
2099	002406	000	000	000	RDN4: .BYTE 0,0,0,0,0,0,0,0,0,0,0,0,0,0,0
2100	002411	000	000	000	
2101	002414	000	000	000	
2102	002417	000	000	000	
2103	002422	000	000	000	
2104	002425	000			
2105					
2106					;TABLE OF READ SCORE, POSITIVE OFFSET SCORE
2107					
2108	002426	000	000	000	RDPO: .BYTE 0,0,0,0,0,0,0,0,0,0,0,0,0,0,0
2109	002431	000	000	000	
2110	002434	000	000	000	
2111	002437	000	000	000	
2112	002442	000	000	000	
2113	002445	000			
2114	002446	000	000	000	RDP1: .BYTE 0,0,0,0,0,0,0,0,0,0,0,0,0,0,0
2115	002451	000	000	000	
2116	002454	000	000	000	
2117	002457	000	000	000	
2118	002462	000	000	000	
2119	002465	000			
2120	002466	000	000	000	RDP2: .BYTE 0,0,0,0,0,0,0,0,0,0,0,0,0,0,0
2121	002471	000	000	000	
2122	002474	000	000	000	
2123	002477	000	000	000	
2124	002502	000	000	000	
2125	002505	000			
2126	002506	000	000	000	RDP3: .BYTE 0,0,0,0,0,0,0,0,0,0,0,0,0,0,0
2127	002511	000	000	000	
2128	002514	000	000	000	
2129	002517	000	000	000	
2130	002522	000	000	000	
2131	002525	000			
2132	002526	000	000	000	RDP4: .BYTE 0,0,0,0,0,0,0,0,0,0,0,0,0,0,0

2133 002531 000 000 000
 2134 002534 000 000 000
 2135 002537 000 000 000
 2136 002542 000 000 000
 2137 002545 000

;TABLE OF SELF TEST SCORE

2140
 2141 002546 000 000
 2142 002550 000 000
 2143 002552 000 000
 2144 002554 000 000
 2145 002556 000 000

SELF0: .BYTE 0,0
 SELF1: .BYTE 0,0
 SELF2: .BYTE 0,0
 SELF3: .BYTE 0,0
 SELF4: .BYTE 0,0

;THE START LOGICAL DRIVE # TO WRITE ON EACH CYLINDER OF A BLOCK
 ;16 CYLINDERS,2 BLOCKS,TOTAL 32 CYLINDERS IN ONE ZONE

2146
 2147
 2148
 2149
 2150 002560 000 001 003
 2151 002563 006 012 017
 2152 002566 005 014 004
 2153 002571 015 007 002
 2154 002574 016 013 011
 2155 002577 010

INDST: .BYTE 0,1,3,6,10.,15.,5,12.,4,13.,7,2,14.,11.,9.,8.

2156
 2157
 2158
 2159
 2160
 2161
 2162

;BUFTBL: ;BUFFER ALLOCATION TABLE ENTRY COUNT
 ; .IRP X,<0,1,2,3,4,5,6,7,10,11,12,13,14,15,16,17>
 ; .WORD #ENDPGM+(<258.*X>) ;BUFFER ADDRESS OF DRIVE X
 ; .ENDM

2163 002600 036506
 2164 002602 036530
 2165 002604 036552
 2166 002606 036574
 2167 002610 036616
 2168 002612 036640
 2169 002614 036662
 2170 002616 036704
 2171 002620 036726
 2172 002622 036750
 2173 002624 036772
 2174 002626 037014
 2175 002630 037036
 2176 002632 037060
 2177 002634 037102
 2178 002636 037124

BLKADR: .WORD DRIV0 ;ADDRESS OF THE PARAMETER BLOCK FOR DRIVE 0
 .WORD DRIV1 ;ADDRESS OF THE PARAMETER BLOCK FOR DRIVE 1
 .WORD DRIV2 ;ADDRESS OF THE PARAMETER BLOCK FOR DRIVE 2
 .WORD DRIV3 ;ADDRESS OF THE PARAMETER BLOCK FOR DRIVE 3
 .WORD DRIV4 ;ADDRESS OF THE PARAMETER BLOCK FOR DRIVE 4
 .WORD DRIV5 ;ADDRESS OF THE PARAMETER BLOCK FOR DRIVE 5
 .WORD DRIV6 ;ADDRESS OF THE PARAMETER BLOCK FOR DRIVE 6
 .WORD DRIV7 ;ADDRESS OF THE PARAMETER BLOCK FOR DRIVE 7
 .WORD DRIV10 ;ADDRESS OF THE PARAMETER BLOCK FOR DRIVE 10
 .WORD DRIV11 ;ADDRESS OF THE PARAMETER BLOCK FOR DRIVE 11
 .WORD DRIV12 ;ADDRESS OF THE PARAMETER BLOCK FOR DRIVE 12
 .WORD DRIV13 ;ADDRESS OF THE PARAMETER BLOCK FOR DRIVE 13
 .WORD DRIV14 ;ADDRESS OF THE PARAMETER BLOCK FOR DRIVE 14
 .WORD DRIV15 ;ADDRESS OF THE PARAMETER BLOCK FOR DRIVE 15
 .WORD DRIV16 ;ADDRESS OF THE PARAMETER BLOCK FOR DRIVE 16
 .WORD DRIV17 ;ADDRESS OF THE PARAMETER BLOCK FOR DRIVE 17

2179
 2180

.EVEN

2181
 2182 002640 000000
 2183
 2184

OFFCOD: .WORD 0 ;OFFSET CODE TABLE
 ;NUMBER FOR NEGATIVE OFFSET (DIR = OUT)
 ;NUMBER FOR POSITIVE OFFSET (DIR = IN)

2185
 2186
 2187

.EVEN

2188 002642 066666

STNDAT: .WORD 066666

K04

2189	002644	155554	.WORD	155554
2190	002646	133331	.WORD	133331
2191	002650	066663	.WORD	066663
2192	002652	155546	.WORD	155546
2193	002654	133315	.WORD	133315
2194	002656	066633	.WORD	066633
2195	002660	155466	.WORD	155466
2196	002662	133155	.WORD	133155
2197	002664	066333	.WORD	066333
2198	002666	154666	.WORD	154666
2199	002670	131555	.WORD	131555
2200	002672	063333	.WORD	063333
2201	002674	146666	.WORD	146666
2202	002676	115555	.WORD	115555
2203	002700	033333	.WORD	033333
2204	002702	040135	PSEUDO: .WORD	040135
2205	002704	177070	.WORD	177070
2206	002706	070414	.WORD	070414
2207	002710	064531	.WORD	064531
2208	002712	174473	.WORD	174473
2209	002714	062422	.WORD	062422
2210	002716	114352	.WORD	114352
2211	002720	036620	.WORD	036620
2212	002722	010031	.WORD	010031
2213	002724	052336	.WORD	052336
2214	002726	017310	.WORD	017310
2215	002730	011347	.WORD	011347
2216	002732	102367	.WORD	102367
2217	002734	152567	.WORD	152567
2218	002736	001246	.WORD	001246
2219	002740	160073	.WORD	160073

;*****

2220
2221
2222
2223

2224
2225
2226
2227
2228
2229
2230
2231
2232
2233
2234
2235
2236
2237
2238
2239
2240
2241
2242
2243
2244
2245
2246
2247
2248
2249
2250
2251
2252
2253
2254
2255
2256
2257
2258
2259
2260
2261
2262
2263
2264
2265
2266
2267
2268
2269
2270
2271
2272
2273
2274
2275
2276
2277
2278
2279

.SBTTL ERROR POINTER TABLE

;*THIS TABLE CONTAINS THE INFORMATION FOR EACH ERROR THAT CAN OCCUR.
 ;*THE INFORMATION IS OBTAINED BY USING THE INDEX NUMBER FOUND IN
 ;*LOCATION \$ITEMB. THIS NUMBER INDICATES WHICH ITEM IN THE TABLE IS PERTINENT.
 ;*NOTE1: IF \$ITEMB IS 0 THE ONLY PERTINENT DATA IS (\$ERRPC).
 ;*NOTE2: EACH ITEM IN THE TABLE CONTAINS 4 POINTERS EXPLAINED AS FOLLOWS:

;* EM ;POINTS TO THE ERROR MESSAGE
 ;* DH ;POINTS TO THE DATA HEADER
 ;* DT ;POINTS TO THE DATA
 ;* DF ;POINTS TO THE DATA FORMAT

\$ERRTB:

;ERROR 1

;RH70 INTERRUPT OCCURRED (RMAS = 0)

;ERROR 2

;UNEXPECTED ATTENTION OCCURRED

;ERROR 3

;MASSBUS PARITY ERROR (MCPE=1)

;ERROR 4

;MASSBUS PARITY ERROR (PAR=1)

;ERROR 5

;ADDRESS PLUG BIT CHANGED

;ERROR 6

;RH11 DIDN'T RESPOND TO ADDRESSING

002742

002742 031616
 002744 034244
 002746 034666
 002750 035012

002752 031665
 002754 034253
 002756 034672
 002760 035013

002762 031723
 002764 034335
 002766 034710
 002770 035021

002772 031761
 002774 034366
 002776 034720
 003000 035024

003002 032016
 003004 034253
 003006 034672
 003010 035013

003012 032052
 003014 034430

EM1
 DH1
 DT1
 DF1

EM2
 DH2
 DT2
 DF2

EM3
 DH3
 DT3
 DF3

EM4
 DH4
 DT4
 DF4

EM5
 DH2
 DT2
 DF2

EM6
 DH6

```

2280 003016 034732 DT6
2281 003020 035012 DF1
2282
2283 ;ERROR 7
2284
2285 003022 000000 0
2286 003024 034441 DH7
2287 003026 034736 DT7
2288 003030 000000 0
2289
2290 ;ERROR 10
2291
2292 003032 000000 0
2293 003034 034512 DH10
2294 003036 034752 DT10
2295 003040 000000 0
2296
2297 ;ERROR 11
2298
2299 003042 000000 0
2300 003044 034563 DH11
2301 003046 034766 DT11
2302 003050 000000 0
2303
2304 ;ERROR 12
2305
2306 003052 000000 0
2307 003054 034634 DH12
2308 003056 035002 DT12
2309 003060 000000 0
2310
2311
2312 .SBTTL SETUP AND INITIALIZATION ROUTINE
2313
2314 ; START ADDRESS = 200
2315 ; ADDRESS TO CHANGE RH11 UNIBUS ADDRESS = 204
2316
2317
2318
2319 003062 012737 000400 001332 START: MOV #400,CHGADR ;200 START ADDRESS FLAG
2320 003070 000406 BR START3
2321 003072 012737 177777 001332 START1: MOV #-1,CHGADR ;204 START ADDRESS FLAG
2322 003100 000402 BR START3
2323 003102 005037 001332 START2: CLR CHGADR ;220 START ADDRESS FLAG
2324 ;COMMON BRANCH POINT
2325 003106 000005 START3: RESET ;CLEAR THE BUS
2326 .SBTTL INITIALIZE THE COMMON TAGS
2327 ;;CLEAR THE COMMON TAGS ($CMTAG) AREA
2328 003110 012706 001114 MOV #SCMTAG,R6 ;;FIRST LOCATION TO BE CLEARED
2329 003114 005026 CLR (R6)+ ;;CLEAR MEMORY LOCATION
2330 003116 022706 001154 CMP #SWR,R6 ;;DONE?
2331 003122 001374 BNE -6 ;;LOOP BACK IF NO
2332 003124 012706 001100 MOV #STACK,SP ;;SETUP THE STACK POINTER
2333 ;;INITIALIZE A FEW VECTORS
2334 003130 012737 022362 000020 MOV #SSCOPE,@#IOTVEC ;;IOT VECTOR FOR SCOPE ROUTINE
2335 003136 012737 000340 000022 MOV #340,@#IOTVEC+2 ;;LEVEL 7

```

```

2336 003144 012737 017366 000030      MOV      #ERRVEC, @EMTVEC      ;; EMT VECTOR FOR ERROR ROUTINE
2337 003152 012737 000340 000032      MOV      #340, @EMTVEC+2      ;; LEVEL 7
2338 003160 012737 022642 000034      MOV      #STRAP, @TRAPVEC      ;; TRAP VECTOR FOR TRAP CALLS
2339 003166 012737 000340 000036      MOV      #340, @TRAPVEC+2      ;; LEVEL 7
2340 003174 012737 020452 000024      MOV      #SPWRON, @PWRVEC      ;; POWER FAILURE VECTOR
2341 003202 012737 000340 000026      MOV      #340, @PWRVEC+2      ;; LEVEL 7
2342 003210 013737 017260 017252      MOV      SENDCT, SEOPCT      ;; SETUP END-OF-PROGRAM COUNTER
2343 003216 005037 001174      CLR      $TIMES                ;; INITIALIZE NUMBER OF ITERATIONS
2344 003222 005037 001176      CLR      $ESCAPE              ;; CLEAR THE ESCAPE ON ERROR ADDRESS
2345 003226 112737 000001 001131      MOV      #1, $ERMAX          ;; ALLOW ONE ERROR PEU TEST
2346                                     ;; INITIALIZE THE "1-BIT" TRAP VECTOR. THEN LOAD LOCATION "SRTN", IN
2347                                     ;; THE "END-OF-PASS" (SEOP) ROUTINE, WITH A "RTI" OR "RTT".
2348 003234 012737 017356 000014      MOV      #SRTN, @TBITVEC      ;; SET "T" BIT VECTOR TO SRTN
2349 003242 012737 000340 000016      MOV      #340, @TBITVEC+2      ;; LEVEL 7
2350 003250 012737 000002 017356      MOV      #RTI, SRTN          ;; SET SRTN TO A RTI
2351 003256 012737 003304 000010      MOV      #65$, @RESVEC      ;; TRY TO DO A RTT
2352 003264 005046      CLR      -(SP)                ;; DUMMY PS
2353 003266 012746 003274      MOV      #64$, -(SP)          ;; AND PC
2354 003272 000006      RTT                          ;; TRY THE RTT
2355 003274 012737 000006 017356 64$: MOV      #RTT, SRTN          ;; RTT IS LEGAL--SET SRTN TO A RTT
2356 003302 000402      BR      66$                  ;;
2357 003304 062706 000010      65$: ADD      #10, SP          ;; RTT ILLEGAL--CLEAN OFF THE STACK
2358 003310 012737 000012 000010 66$: MOV      #RESVEC+2, @RESVEC ;; RESTORE TRAP CATCHER
2359 003316 005037 017364      CLR      $TBIT                ;; CLEAR "T" BIT SWITCH
2360 003322 012737 003322 001122      MOV      #, $LPCADR          ;; INITIALIZE THE LOOP ADDRESS FOR SCOPE
2361 003330 012737 003330 001124      MOV      #, $LPERR          ;; SETUP THE ERROR LOOP ADDRESS
2362                                     ;; SIZE FOR A HARDWARE SWITCH REGISTER IF NOT FOUND OR IT IS
2363                                     ;; EQUAL TO A "-1" SETUP FOR A SOFTWARE SWITCH REGISTER.
2364 003336 013746 000004      MOV      @ERRVEC, -(SP)      ;; SAVE ERROR VECTOR
2365 003342 012737 003376 000004      MOV      #67$, @ERRVEC      ;; SET UP ERROR VECTOR
2366 003350 012737 177570 001154      MOV      #DSWR, SWR          ;; SETUP FOR A HARDWARE SWICH REGISTER
2367 003356 012737 177570 001156      MOV      #DISP, DISPLAY      ;; AND A HARDWARE DISPLAY REGISTER
2368 003364 022777 177777 175562      CMP      #-1, @SWR          ;; TRY TO REFERENCE HARDWARE SWR
2369 003372 001012      BNE      69$                ;; BRANCH IF NO TIMEOUT TRAP OCCURRED
2370                                     ;; AND THE HARDWARE SWR IS NOT = -1
2371      BR      68$                ;; BRANCH IF NO TIMEOUT
2372 003376 012716 003404      67$: MOV      #68$, (SP)      ;; SET UP FOR TRAP RETURN
2373 003402 000002      RTI                          ;;
2374 003404 012737 000176 001154 68$: MOV      #SWREG, SWR        ;; POINT TO SOFTWARE SWR
2375 003412 012737 000174 001156      MOV      #DISPREG, DISPLAY  ;;
2376 003420 012637 000004      69$: MOV      (SP)+, @ERRVEC  ;; RESTORE ERROR VECTOR
2377
2378 003424 005037 001216      CLR      $PASS                ;; CLEAR PASS COUNT
2379 003430 132737 000200 001231      BITB    #APTSIZE, $ENVM      ;; TEST USER SIZE UNDER APT
2380 003436 001403      BEQ     70$                  ;; YES, USE NON-APT SWITCH
2381 003440 012737 001232 001154      MOV     #SSWREG, SWR         ;; NO, USE APT SWITCH REGISTER
2382      70$:
2383 003446 012737 000240 000032      MOV     #240, @EMTVEC+2      ;; CHANGE EMT PRIORITY TO 5
2384 003454 012737 000240 000036      MOV     #240, @TRAPVEC+2     ;; CHANGE TRAP PRIORITY TO 5
2385 003462 005227 177777      INC     #-1                  ;; FIRST START ?
2386 003466 001002      BNE     1$                   ;; BR IF NOT
2387 003470 104401 037262      TYPE   TITLE                 ;; NAME AND MANDEC NUMBER
2388 003474 004737 016462      1$: JSR    PC, $TKINT         ;; TURN ON THE KEYBOARD INTERRUPT
2389      .SBTTL GET VALUE FOR SOFTWARE SWITCH REGISTER
2390 003500 005737 000042      TST    @#42                  ;; ARE WE RUNNING UNDER XXDP/ACT?
2391 003504 001012      BNE     71$                  ;; BRANCH IF YES

```

```

2392 003506 123727 001230 000001      CMPB   $ENV,#1      ;; ARE WE RUNNING UNDER APT?
2393 003514 001406                      BEQ    71$          ;; BRANCH IF YES
2394 003516 023727 001154 000176      CMP    SWR,#SWREG  ;; SOFTWARE SWITCH REG SELECTED?
2395 003524 001005                      BNE    72$          ;; BRANCH IF NO
2396 003526 104406                      GTSWR                      ;; GET SOFT-SWR SETTINGS
2397 003530 000403                      BR     72$
2398 003532 112737 000001 001150 71$:      MOVB   #1,$AUTOB  ;; SET AUTO-MODE INDICATOR
2399 003540 72$:
2400 003540 013737 001274 023076      MOV    $RMADR,RMADR ;; RH11 ADDRESS
2401 003546 013737 001276 023100      MOV    $RMVEC,RMVEC ;; RH11 VECTOR ADDRESS
2402 003554 012705 001776      2$:   MOV    #ASNLST,R5 ;; START OF AREA TO CLEAR
2403 003560 005025                      3$:   CLR    (R5)+
2404 003562 022705 002560      CMP    #INOST,R5   ;; LOOK FOR END OF CLEAR AREA
2405 003566 001374                      BNE    3$          ;; BR IF NOT FINISHED
2406 003570 012706 001100      MOV    #STACK,SP  ;; SETUP THE STACK POINTER
2407 003574 005037 177776      CLR    PS          ;; CLEAR THE PROCESSOR STATUS WORD
2408 003600 013737 001316 001350      MOV    HZ,SIXTEE  ;; 1/60 TH OR 1/50 TH SECOND COUNTER VALUE
2409 003606 005037 001342      CLR    HOUR        ;; CLEAR THE HOUR'S COUNTER
2410 003612 005037 001344      CLR    MINUTE      ;; CLEAR THE MINUTE'S COUNTER
2411 003616 005037 001346      CLR    SECOND      ;; CLEAR THE SECOND'S COUNTER
2412 003622 005037 001334      CLR    CFLAG      ;; CLEAR THE 'CONTROL C' FLAG
2413
2414 ;ROUTINE TO DETERMINE BUFFER AREA SIZE
2415
2416 003626 005227 177777      SIZMEM: INC    #-1   ;; SEE IF TIME TO SIZE MEMORY
2417 003632 001002                      BNE    1$          ;; BR IF NOT
2418 003634 004737 031216      JSR    PC,$SIZE   ;; SEE HOW MUCH MEMORY ON SYSTEM
2419 003640 013737 031312 001330 1$:   MOV    $LSTAD,LSTAD ;; SAVE THE LAST ADDRESS
2420 003646 023727 001330 160000      CMP    LSTAD,#160000 ;; OVER 28K ?
2421 003654 101403                      BLOS   2$          ;; NO THEN DON'T SET THE NEW LIMIT
2422 003656 012737 160000 001330      MOV    #160000,LSTAD ;; SET NEW LIMIT
2423 003664 162737 005670 001330 2$:   SUB    #1500.*2,LSTAD ;; SAVE XXDP LOADER AND ABSOLUTE LOADER
2424
2425 ;
2426 ;   SET UP THE OTHER SYSTEM DEVICES THAT
2427 ;   THE PROGRAM WILL USE
2428
2428 003672 004737 014740      SETVEC: JSR    PC,CKCLK ;; START THE CLOCK
2429 003676 012737 177777 023036      MOV    #-1,$SAVEFG ;; SET THE SAVE REGISTERS FLAG
2430
2431 ;SETUP IF 'XXDP' OR 'ACT11' OPERATION
2432
2433 003704 005001      MONTR: CLR    R1      ;; DRIVE #
2434 003706 005002      CLR    R2      ;; AVAIL TABLE INDEX
2435 003710 005003      CLR    R3      ;; DRIVE# X 2
2436 003712 016300 002600 1$:   MOV    BLKADR(R3),R0 ;; LOAD DPB ADDRESS
2437 003716 004737 015426      JSR    PC,CLRDPB ;; CLEAR DPB BLOCK
2438 003722 022322      2$:   CMP    (R3)+,(R2)+ ;; INCREMENT INDEX
2439 003724 005201      INC    R1      ;; NEXT DRIVE
2440 003726 022701 000007      CMP    #7,R1    ;; ALL DRIVE ASSIGN ?
2441 003732 002367      BGE    1$      ;; NO
2442
2443
2444 ;
2445 ;   ASSIGN LOGICAL DRIVES TO BE TEST IN THE PASS1 AND PASS 2
2446 ;   THREE WORDS ARE USED IN THE BIT MAPS:
2447 ;   ASNLST:  SPECIFIES THE LOGICAL DRIVES ASSIGNED
2448 ;   ASSGN1:  SPECIFIES THE LOGICAL DRIVES WILL BE TESTED IN PASS1.
    
```


2448
2449
2450
2451
2452
2453
2454
2455
2456
2457
2458
2459
2460
2461
2462
2463
2464
2465
2466
2467
2468
2469
2470
2471
2472
2473
2474
2475
2476
2477
2478
2479
2480
2481
2482
2483
2484
2485
2486
2487
2488
2489
2490
2491
2492
2493
2494
2495
2496
2497
2498
2499
2500
2501
2502
2503

```

ASSGN2:  SPECIFIES THE LOGICAL DRIVES WILL BE TESTED IN PASS2.

EACH LOGICAL DRIVE HAS A HISTORY FILE LABELED DIRV'Z (Z=0 TO 17)
THE LOCATIONS LABELED $SYSTEM AND $PHYRD IN THE HISTORY FILE
STORE THE SYSTEM NAME (A TO H) AND PHYSICAL DRIVE NUMBER
(O TO 7).
THE SUB-SYSTEM ADDRESS AND INTERRUPT VECTOR ARE STOREED
IN THE TABLE LABELED "SYSADR:".

THE LOCATIONS SYSADR AND SYSADR+2 FOR SUB-SYSTEM A, SYSADR+4
AND SYSADR+6 FOR SUBSYSTEM B , ETC, THE FIRST WORD
IS THE SUB SYSTEM ADDRESS WHILE THE SECOND WORD IS THE VECTOR

THE LOGICAL DRIVES ARE ASSIGNED FROM CONSOLE KEYBOARD.

MOD00:  MOV      #ASNLST,RO      ;ADDRESS OF 1ST BIT MAPS IN RO
        MOV      #INDST,R1      ;LAST ADDRESS TO CLEAR
1$:     CLR      (RO)+          ;CLEAR CURRENT POINTED ADDRESS
        CMP      R1,RO          ;ALL DONE ?
        BHI     1$             ;NO, THEN BRANCH BACK
        MOV      #'A,$CDW2      ;TEMP STORATE OF SYS NAME

MOD21:  CLR      DRIVE          ;TEM STORAGE OF PHYSICAL DRIVE BIT MAP
        TYPE    , $CRLF
        TYPE    , MSG1          ;SUB-SYSTEM
        TYPE    , $CDW2        ;A TO H (ONE OF THEM)
        TYPE    , LINSF
        TYPE    , MSG2
        TYPE    , COLON
        RDLIN  (SP)+,R1        ;READ IN THE DRIVE NUMBERS
        MOV      (R1)           ;GET THE INPUT LINE ADDRESS
1$:     TSTB    (R1)           ;END OF STRING ?
        BEQ     2$             ;YES
        JSR    R5,CK.OCT       ;CHECK THE DIGIT MUST 0 TO 7, RETURN VALUE IN R2
        BR     MOD21           ;INCORRECT DRIVE NUMBER, ENTER AGAIN
        BISB   ATABIT(R2),DRIVE ;SET THE ASSIGNED PHYSICAL DRIVE BIT
        ;R2 THE DRIVE NUMBER FROM CK.OCT RT.
        INC    R1              ;NEXT BYTE OF INPUT LINE
        TSTB   (R1)           ;END OF STRING ?
        BEQ    2$             ;YES
        CMPB   #'A,(R1)+       ;MUST BE A
        BNE   MOD21           ;ENTER AGAIN, IF NOT
        BR    1$              ;LOCATE NEXT DRIVE
2$:     TST     CHGADR          ;START AT 200 ?
        BGT    MOD22          ;BRANCH IF SO
        MOV    $CDW2,R1        ;SYS NAME ASCII FROM A TO H
        BIC   #177760,R1      ;LEFT ONLY 4 BITS
        DEC   R1               ;ADJUST INDEX VALUE
        ASL   R1               ;2 WORD INDEX VALUE
        ASL   R1
        ADD   #SYSADR,R1      ;SYS ADDRESS TABLE ADDRESS
    
```

```

2504 004106 010137 001270      MOV      R1,SCDW1      ; SYS ADDRESS TABLE'S ENTRY TO CDW1
2505 004112 000400      3$:      BR          MOD23      ;
2506 004114 005737 001222      MOD23:   TST      DRIVE      ;CHECK IF ANY PHYSICAL DRIVE(S) ASSIGNED
2507 004120 001416      BEQ      2$          ;BRANCH IF NONE
2508 004122 013700 001270      1$:      MOV      $CDW1,R0      ;SYS ADDRESS TABLE ENTRY
2509 004126 011037 001274      MOV      (R0), $RMADR   ; SYS ADDRESS
2510 004132 016037 000002 001276      MOV      2(R0), $RMVEC  ; SYS VECTOR
2511 004140 004737 031314      JSR      PC,BUSADR     ;CHECK THE ADDRESS WITH THE OPERATOR
2512 004144 013710 001274      MOV      $RMADR,(R0)   ;NEW RH11/70 ADDRESS INTO TABLE
2513 004150 013760 001276 000002      MOV      $RMVEC,2(R0)  ;NEW VECTOR OF RH11/70 INTO TABLE
2514 004156 000407      2$:      BR          MOD11      ;BRANCH TO NEXT MODULE
2515
2516
2517
2518 004160      MOD22:
2519 004160 013737 001274 002004 3$:      MOV      $RMADR,SYSADR ;LOAD THE SYSTEM ADDRESS TABLE
2520 004166 013737 001276 002006 4$:      MOV      $RMVEC,SYSADR+2 ;LOAD THE VECTOR
2521 004174 000400      BR          MOD11
2522
2523
2524
2525
2526      :
2527      :      $CDW2-- ASCII NAME OF SUB SYSTEM (A TO H)
2528      :      $CDW1--ENTRY TO THE SYS ADDRESS TABLE
2529      :      DRIVE--PHYSICAL DRIVES TO BE ASSIGNED
2530      :      THIS SECTION OF CODING USES THE ABOVE PARAMETERS
2531      :      TO SET UP THE BIT MAP OF ASNLST,ASSGN1,ASSGN2
2532      :
2533
2534
2535
2536 004176 005737 001222      MOD11:   TST      DRIVE      ;ANY DRIVE ASSIGN ?
2537 004202 001002      BNE     MOD30      ;BRANCH IF ANY
2538 004204 000137 004360      JMP     MOD12      ;BRANCH, IF NONE
2539 004210 022737 177777 001776  MOD30:   CMP      #-1,ASNLST   ;ALL 16 LOGICAL DRIVES HAS BEEN ASSIGNED ?
2540 004216 001457      BEQ     5$          ;YES, THEN DON'T ASSIGN NEW DRIVES
2541 004220 013700 001776      MOV     ASNLST,R0    ;FOUND THE AVAILABLE LOGICAL DRIVE LOCATION
2542 004224 012701 000001      MOV     #1,R1       ;START FROM LOGICAL DRIVE 0
2543 004230 005002      CLR     R2          ;INDEX VALUE
2544 004232 000100      1$:     BIT      R1,R0 ;IS THE LOGICAL DRIVE AVAILABLE ?
2545 004234 001406      BEQ     2$          ;YES
2546 004236 000241      CLC
2547 004240 006101      ROL     R1          ;NEXT LOGICAL DRIVE
2548 004242 103445      BCS     5$          ;BRANCH IF NONE IS AVAILABLE
2549 004244 062702 000002      ADD     #2,R2       ;INCREMENT INDEX VALUE
2550 004250 000770      BR      1$         ;LOCATE NEXT LOGICAL DRIVE
2551 004252 016204 002E00 000014 2$:     MOV     BLKADR(R2),R4 ;GET THE LOGICAL DRIVE'S HISTORY FILE
2552 004256 113764 001272      MOV     $CDW2,$SYSNM(R4) ;LOAD THE ASCII SYS NAME
2553 004264 050137 001776      BIS     R1,ASNLST   ;SET LOGICAL DRIVE ASSIGN BIT
2554 004270 050137 002000      BIS     R1,ASSGN1  ;SET PASS 1 BIT
2555 004274 050137 002002      BIS     R1,ASSGN2  ;SET PASS 2 BIT
2556 004300 013700 001222      MOV     DRIVE,R0    ;LOAD THE ASCII PHYSICAL DRIVE #
2557 004304 012701 000001      MOV     #1,R1       ;START FROM DRIVE 0
2558 004310 005002      CLR     R2          ;DRIVE #
2559 004312 030100      3$:     BIT      R1,R0    ;IS THE PHYSICAL DRIVE ASSIGNED
    
```

E05

2560	004314	001005			BNE	4\$; YES, THEN BRANCH
2561	004316	000241			CLC			; LOCATE THE NEXT DRIVE
2562	004320	006101			ROL	R1		; SHIFT ONE BIT LEFT
2563	004322	103415			BCS	5\$; BRANCH IF NO MORE DRIVES
2564	004324	005202			INC	R2		; PHYSICAL DRIVE NUMBER
2565	004326	000771			BR	3\$; LOOPING BACK
2566	004330	110214		4\$:	MOVB	R2, (R4)		; LOAD THE PHYSICAL DRIVE # INTO HISTORY FILE
2567	004332	062702	000060		ADD	#'0, R2		; ASCII CODE OF DRIVE #
2568	004336	110264	000015		MOVB	R2, \$PHYDR(R4)		; PHYSICAL DRIVE NUMBER
2569	004342	112764	000011	000016	MOVB	#HT, \$GAP(R4)		; MAKE UP FOR SCORE TYPE
2570	004350	040137	001222		BIC	R1, DRIVE		; RESET THE ASSIGNED DRIVE BIT
2571	004354	001315			BNE	MOD30		; BRANCH IF NOT ALL DONE
2572	004356	000400		5\$:	BR	MOD12		; CHECK OTHER SUB SYSTEM
2573								
2574								
2575	004360	005737	001332	MOD12:	TST	CHGADR ;200 START ?		
2576	004364	003066			BGT	6\$; YES, THEN EXIT
2577	004366	022737	177777	001776	1\$:	CMP	#-1, ASNLST	; FULL HOUSE
2578	004374	001462			BEQ	6\$; YES, THEN EXIT
2579	004376	104401	035737	2\$:	TYPE	, MSG5		; WILL TEST
2580	004402	104401	035041		TYPE	, MSG2		; DRIVES
2581	004406	005003			CLR	R3		; INDEX TO LOGICAL DRIVE HISTORY FILE
2582	004410	012704	000001		MOV	#1, R4		; BIT MAP OF ASNLST
2583	004414	030437	001776	3\$:	BIT	R4, ASNLST		; ASSIGNED LOGICAL DRIVE ?
2584	004420	001417			BEQ	5\$; NO
2585	004422	016305	002600		MOV	BLKADR(R3), R5		; LOAD THE HISTORY FILE ADDRESS
2586	004426	126537	000014	001272	CMPB	\$SYSNM(R5), \$CDW2		; ON THE SAME SYSTEM ?
2587	004434	001003			BNE	4\$; NO
2588	004436	111546			MOVB	(R5), -(SP)		; TYPE THE PHYSICAL DRIVE #
2589	004440	104403			TYPOS			
2590	004442	002			.BYTE	2		
2591	004443	000			.BYTE	0		
2592	004444	062703	000002	4\$:	ADD	#2, R3		; INCREMENT TO NEXT LOGICAL DRIVE
2593	004450	000241			CLC			
2594	004452	006104			ROL	R4		; BIT MAP OF THE NEXT LOGICAL DRIVE
2595	004454	103401			BCS	5\$; BRANCH IF ALL LOGICAL DRIVE'S CHECKED
2596	004456	000756			BR	3\$; BRANCH BACK
2597	004460	104401	036121	5\$:	TYPE	, LINSF		
2598	004464	104401	035752		TYPE	, MSG6		; ON
2599	004470	104401	035030		TYPE	, MSG1		; SUB SYSTEM
2600	004474	104401	001272		TYPE	, \$CDW2		; A TO H
2601								
2602	004500	005237	001272		INC	\$CDW2		; CHECK NEXT SUB SYSTEM
2603	004504	122737	000110	001272	CMPB	#'H, \$CDW2		; ALL EIGHT SUB SYSTEMS CHECKED?
2604	004512	103413			BLO	6\$; YES
2605	004514	104401	001205		TYPE	, \$CRLF		
2606	004520	104401	035756		TYPE	, MSG7		; ASK FOR OTHER SUB SYSTEM
2607	004524	104411			RDLIN			; READ IN A LINE
2608	004526	012605			MOV	(SP)+, R5		; CHECK THE FIRST CHARACTER
2609	004530	122715	000131		CMPB	#'Y, (R5)		; ENTER Y ?
2610	004534	001002			BNE	6\$; BRANCH IF NOT
2611	004536	000137	003760		JMP	MOD21		; SET UP OTHER SUB SYSTEM
2612	004542	005737	001332	6\$:	TST	CHGADR		; START AT 220
2613	004546	001402			BEQ	7\$; YES, EXECUTE PASS2 ONLY
2614	004550	000137	004564		JMP	XPASS1		; TO PASS1
2615	004554	005037	002000	7\$:	CLR	ASSGN1		; CLEAR THE PASS1 BIT MAP

F05

```

2616 004560 000137 006772          JMP      XPASS2          ;BRANCH TO PASS2
2617
2618
2619
2620
2621
2622          :          PASS ONE , THE VARIAYLES ARE ASSIGNED AS FOLLOWS:
2623          :          $CDW1 : ADDRESS OF THE CURRENT LOGICAL DRIVE HISTORY FILE
2624          :          $CDW2 : SYSTEM NAME A THROUGH H
2625          :          $DEV# : CURRENT LOGICAL DRIVE #
2626          :          ASNLST : ASSIGNED LOGICAL DRIVES
2627          :          ASSGN1 : ASSIGNED LOGICAL DRIVES IN THIS PASS
2628          :          R0 : ADDRESS OF DPB BLOCK FEEDED INTO DRIVER-HANDLER
2629          :          R1 : TEMP STORAGE OF ADDRESS OF THE LOGICAL BLOCK
2630
2631
2632
2633
2634 004564 005737 002000          XPASS1: TST      ASSGN1          ;ANY DRIVE ASSIGNED FOR PASS1
2635 004570 001002                    BNE      IS              ;BRANCH IF THEY ARE
2636 004572 000137 005432          JMP      ENDX1          ;END OF PASS 1
2637 004576 005037 001266          IS:   CLR      $DEV#     ;INDEX OF LOGICAL BLOCK
2638 004602 013737 002600 001270  MOV     BLKADR,$CDW1    ;ADDRESS OF LOGICAL BLOCK 0
2639 004610 112737 000101 001272  MOV     #'A,$CDW2      ;SYS NAME STARTS FROM A
2640 004616 012777 013256 016254  MOV     #IDLEX,$RMVEC  ;RESET ALL INTERRUPT VERTOR
2641 004624 005077 016252          CLR     $RMVEC+2      ;CLEAR THE INTERRUPT LEVEL
2642 004630 013737 002004 023076  MOV     SYSADR,$MADR   ;LOAD SYS-TEM A INTO
2643 004636 013737 002006 023100  MOV     SYSADR+2,$RMVEC ;DIRVER-HANDLER
2644 004644 013701 001270          MOV     $CDW1,R1      ;R1=ADDRESS OF LOGICAL BLOCK 1
2645 004650 012777 013256 016222  MOV     #IDLEX,$RMVEC  ;RESET ALL INTERRUPT VECTOR
2646 004656 005077 016220          CLR     $RMVEC+2      ;CLEAR THE INTERRUPT LEVEL
2647 004662 104401 001205          TYPE   ,SCRLF
2648 004666 104401 035053          TYPE   ,MSG3
2649 004672 104401 001205          TYPE   ,SCRLF
2650 004676 104401 035101          TYPE   ,MSG4
2651 004702 104401 001272          TYPE   , $CDW2
2652 004706 111137 001222          MOV     (R1),DRIVE    ;LOAD THE PHYSICAL DRIVE #
2653 004712 111146          MOV     (R1),-(SP)   ;TYPE THE DRIVE #
2654 004714 104403          TYPOS
2655 004716          .BYTE  2
2656 004717          .BYTE  0
2657 004720 104401 036121          TYPE   ,LINSF
2658 004724 104401 035127          TYPE   ,MSG8
2659 004730 104401 001205          TYPE   ,SCRLF
2660 004734 104401 035142          TYPE   ,MSG9
2661 004740 104401 036121          TYPE   ,LINSF
2662
2663
2664
2665
2666 004744 104411          25:   RDLIN          ;CHECK IF O.P. READY
2667 004746 012602          MOV     (SP)+,R2      ;LOCATE THE INPUT LINE
2668 004750 122722 000122          CMPB   #'R',(R2)+    ;FIRST CHARACTER IS A "R" ?
2669 004754 001373          BNE    25            ;BRANCH IF NOT
2670 004756 1057:2          TSTB   (R2)          ;FOLLOW BY <CR> ?
2671 004760 001371          BNE    25            ;BRANCH IF NOT

```

G05

MAINDEC-11-DZRM1 AO/00, RMO3 DRIVE COMPATIBILITY TEST MACY11 30(1046) 21-JUL-77 16:51 PAGE 58
 DZRM1A.P11 21-JUL-77 15:44 GET VALUE FOR SOFTWARE SWITCH REGISTER

SEQ 0057

2672	004762	004737	023114		JSR	PC, RMINIT	; INITIALIZE THE SUB SYSTEM
2673	004766	012737	177777	023036	MOV	#-1, SAVEFG	; SAVE ALL RH/RM REGISTERS
2674	004774	012737	177777	023040	MOV	#-1, SEEKFG	; DON'T DO IMPLY SEEK
2675	005002	013700	001222		MOV	DRIVE RO	; RO=PHYSICAL DRIVE # OF THE SUB SYSTEM
2676	005006	105760	022750		TSTB	DRVSTA(RO)	; DIRVE EXIST AND ON LINE ?
2677	005012	003452			BLE	5\$; BRANCH IF NOT
2678	005014	105760	022760		TSTB	DRVTYP(RO)	; DRIVE IS AN RMO3 ?
2679	005020	003447			BLE	5\$; BRANCH IF NOT
2680							; SET UP TO RETRIEVE THE BAD SPOT FILE
2681							; FROM THE LAST TRACK
2682	005022	012700	037146		MOV	#FMTDPB, RO	; DPB ADDRESS
2683	005026	113710	001222		MOV	DRIVE, (RO)	; LOAD THE DRIVE NUMBER
2684	005032	012760	037262	000006	MOV	#ENDPGM, \$BUF(RO)	; LOAD BUFFER ADDRESS
2685	005040	012760	037166	000014	MOV	#RM, REG, 14(RO)	; AREA TO SAVE ALL RH/RMO3 REG'S
2686	005046	012760	177400	000004	MOV	#-256, \$WORDM(RO)	; WORD COUNT (NEG)
2687	005054	013760	001372	000012	MOV	CYLINT, \$CYL(RO)	; CYLINDER 822.
2688	005062	113760	001370	000011	MOV	TRKLMT, \$TRK(RO)	; TRACK ADDRESS 4.
2689	005070	105060	000010		CLRB	\$SEC(RO)	; SEC 0
2690	005074	112760	000171	000002	MOV	#RODAT, \$COMND(RO)	; READ DATA COMMAND
2691							
2692	005102	004037	023620		3\$: JSR	RO, RMO3	; CALL THE DRIVER-HANDLER
2693	005106	037146			FMTDPB		; PARAMETER ADDRESS
2694	005110	000774			BR	3\$; LOOPING IF QUEUE IS NOT SUCCESSFUL
2695	005112	005737	037164		4\$: TST	FMTDPB+16	; COMMAND DONE ?
2696	005116	001775			BEQ	4\$; BRANCH IF NOT
2697	005120	100013			BPL	6\$; BRANCH IF DONE, WITHOUT ERROR
2698	005122	062737	000002	037156	ADD	#2, FMTDPB+10	; TRY NEXT SECTOR (0, 2, 4, 6, 8)
2699	005130	122737	000010	037156	CMPB	#8, FMTDPB+10	; ALL FIVE SECTORS CHECKED ?
2700	005136	101361			BHI	3\$; NO, THEN TRY AGAIN
2701							
2702	005140	104401	035201		5\$: TYPE	MESG10	; DRIVE IS NOT READY
2703	005144	000137	005432		JMP	ENDX1	; STOP THE TEST
2704							
2705							
2706							; BAD SPOT FILE IS RETRIVED, IS STORED
2707							; FROM ENDPGM+4 TO ENDPGM+256.
2708							; FIRST WORD CYLINDER # SECOND WORD
2709							; TRK AND SEC NUMBERS, FILE IS TERMINATED
2710							; BY A -1 IN THE CYLINDER NUMBER
2711							
2712							
2713	005150	012704	037272		6\$: MOV	#ENDPGM+10, R4	; R4 ADDRESS OF BAD SPOT FILE
2714	005154	022714	177777		7\$: CMP	#-1, (R4)	; END OF BAD SPOT FILE ?
2715	005160	001411			BEQ	8\$; YES
2716	005162	022704	040262		CMP	#ENDPGM+1000, R4	; END OF BAD SPOT FILE ?
2717	005166	101406			BLOS	8\$; BRANCH IF IT IS
2718	005170	004537	005264		JSR	R5, SPOTX	; CHECK THE CYLINDER POINTED BY (R4)
2719	005174	000415			BR	10\$; BRANCH IF BAD SPOT IN THE TEST ZONES
2720	005176	062704	000004		ADD	#4, R4	; NEXT BAD SPOT ADDRESS
2721	005202	000764			BR	7\$; LOOPING BACK
2722							
2723	005204	032777	000200	173742	8\$: BIT	#BIT7, @SWR	; SWITCH 7 SET ?
2724	005212	001404			BEQ	9\$; BRANCH IF NOT SET
2725	005214	012700	037146		MOV	#FMTDPB, RO	; DPB ADDRESS
2726	005220	004737	014406		JSR	PC, PRTBAD	; PRINT THE BAD SPOT FILE
2727	005224	000137	005450		9\$: JMP	TST1	; PACK IS ACCEPTABLE

H05

```

2728 005230 104401 035245      10$: TYPE      ,MESG11      ;PACK NOT ACCEPTABLE
2729 005234 104401 001205      TYPE      $CRLF
2730 005240 032777 000200 173706  BIT      #BIT7,@SWR      ;SWITCH 7 SET ?
2731 005246 001404      BEQ      11$           ;BRANCH IF NOT SET
2732 005250 012700 037146      MOV      #FMTDPB,R0     ;DPB ADDRESS
2733 005254 004737 014406      JSR      PC,PRTBAD      ;TYPE THE BAD SPOT FILE
2734 005260 000137 004564      11$: JMP      XPASS1      ;RESTART PASS 1
2735
2736
2737      :      SUBROUTINE SPOTX
2738      :      CHECK THE CYLINDER POINTED BY (R4) IS IN THE TESTING ZONES
2739      :      (0-15,128-143,256-271,384-399,512-527,640-655,768-783
2740      :      112-127,240-255,368-383,496-511,624-639,752-767
2741      :      17-32,145-160,273-288,401-416,529-544,657-672,785-800
2742      :      AND 620 )
2743      :      CALLING SEQ:
2744      :      JSR      R5,SPOTX      ;R4=POINT TO CYLINDER NUMBER
2745      :      RET1
2746      :      RET2      ;ERROR RET
2747      :      ;NORMAL RET1
2748
2749 005264 010146      SPOTX: MOV      R1,-(SP)      ;SAVE R1 THROUGH R3
2750 005266 010246      MOV      R2,-(SP)
2751 005270 010346      MOV      R3,-(SP)
2752
2753 005272 005003      CLR      R3           ;ERROR FLAG
2754 005274 005046      CLR      -(SP)        ;DUMMY PAIR
2755 005276 005046      CLR      -(SP)        ;DUMMY PAIR
2756 005300 005046      CLR      -(SP)        ;ZONE STARTING ADDRESS
2757 005302 012746 000007      MOV      #7,-(SP)     ;SEGMENT NUMBER
2758 005306 012746 000021      MOV      #17,-(SP)    ;ZONE STARTING ADDRESS
2759 005312 012746 000007      MOV      #7,-(SP)     ;SEGMENT NUMBER
2760 005316 012701 000160      MOV      #12.,R1      ;R1=ZONE STARTING ADDRESS
2761 005322 012702 000006      MOV      #6,R2        ;R2=SEGMENT NUMBER
2762 005326 021401      1$:  CMP      (R4),R1    ;CYL IN THE ZONE ?
2763 005330 103410      BLO      3$           ;BRANCH IF NOT
2764 005332 062701 000017      ADD      #15.,R1      ;CHECK WITH THE UPPER BOND
2765 005336 021401      CMP      (R4),R1      ;CYL IN THE ZONE ?
2766 005340 101002      BHI      2$           ;BRANCH IF NOT
2767 005342 052703 000002      BIS      #BIT1,R3     ;SET THE ERROR FLAG
2768
2769 005346 162701 000017      2$:  SUB      #15.,R1    ;RESTORE TO THE LOWER BOND
2770 005352 005302      3$:  DEC      R2          ;DECREMENT THE SEGMENT COUNT
2771 005354 001403      BEQ      4$           ;ALL SEGMENT CHECKED ?
2772 005356 062701 000200      ADD      #128.,R1     ;ADJUST ZONE STARTING ADDRESS
2773 005362 000761      BR       1$          ;LOOPING BACK UNTIL ALL SEGMENTS ARE CHECKED
2774
2775 005364 012602      4$:  MOV      (SP)+,R2    ;POP THE NEXT SET OF ZONE PARAMETERS
2776 005366 012601      MOV      (SP)+,R1
2777 005370 005702      TST      R2           ;DUMMY PAIR
2778 005372 001355      BNE      1$           ;BRANCH IF NOT
2779 005374 005701      TST      R1           ;DUMMY PAIR
2780 005376 001353      BNE      1$           ;BRANCH IF NOT
2781
2782 005400 021427 001154      5$:  CMP      (R4),#620.   ;ON CYLDER 620 ?
2783 005404 001002      BNE      6$           ;NO
  
```

2784 005406 052703 000002
2785 005412 005703
2786 005414 001002
2787 005416 062705 000002
2788 005422 012603
2789 005424 012602
2790 005426 012601
2791 005430 000305

65: BIS #BIT1,R3 ;SET ERROR FLAG
TST R3 ;ANY ERROR ?
BNE 75 ;YES
75: ADD #2,R5 ;ADJUST FOR NORMAL RETURN
MOV (SP)+,R3 ;RESTORE R3 THROUGH R1
MOV (SP)+,R2
MOV (SP)+,R1
RTS R5 ;EXIT

2792
2793
2794 005432 104401 001205
2795 005436 104401 036424
2796 005442 000000
2797 005444 000137 000200
2798
2799
2800
2801
2802
2803
2804
2805
2806
2807
2808
2809
2810
2811
2812
2813
2814
2815
2816
2817
2818
2819
2820
2821
2822
2823

ENDX1: TYPE , \$CRLF ;
TYPE , MSG2 ; DRIVE NOT ONLINE OR NOT ASSIGNED
HALT ; TEMP HALT FOR DEBUG
JMP @#200 ; RESTART IF DESIRED

THE FOIIOWING CODING FOR TEST 1 THROUGH TEST 4
PARAMETER IN TST 1
\$CDW1 : ADDRESS OF LOGICAL DRIVE BLOCK
DRIVE : PHYSICAL DRIVE #
\$DEVN : LOGICAL DRIVE # 0-17
ASSGN1 : ASSIGN LOGICAL DRIVE BIT MAP
ASMLST : ASSIGNED LOGICAL DRIVE MAP INDICATOR
\$CDW2: SYS-NAME
\$CDW2,DRIVE ARE ONLY CHANGED IN TST1 DURING PASS 1
\$DEVN,ASSGN1,\$CDW1 ARE CHANGED BY THE TEST 4

;TST 1:DIRECT OPERATOR TO MOUNT AND LOAD PACKS

2824 005450 000004
2825 005452 012737 000001 001174
2826 005460 012737 000001 001336
2827 005466 012706 001100
2828 005472 023737 001270 002600
2829 005500 001524
2830 005502 013701 001270
2831 005506 126137 000014 001272
2832 005514 001426
2833 005516 116137 000014 001272
2834 005524 012777 013256 015346
2835 005532 005077 015344
2836 005536 104401 001205
2837 005542 104401 035053
2838 005546 104401 001205
2839 005552 104401 035752

TST1: SCOPE
MOV #1,\$TIMES ;DO 1 ITERATION
MOV #1,TSTNM ;LOAD THE TEST NUMBER
MOV #STACK,SP ;INITIALIZE THE STACK POINT
CMP \$CDW1,BLKADR ;LOGICAL DRIVE 0
BEQ 35 ;THEN EXIT
MOV \$CDW1,R1 ;R1=LOGICAL DRIVE BLOCK ADDRESS
CMPB \$SYSNM(R1),\$CDW2 ;STILL ON THE SAME SYSTEM ?
IS ;THEN ,EXIT
MOVB \$SYSNM(R1),\$CDW2 ;LOAD THE NEW SUB SYSTEM NAME
MOV #IDLEX,@RMVEC ;RESET THE INTERRUPT VECTOR
CLR @RMVEC+2 ;CLEAR THE INTERRUPT LEVEL
TYPE , \$CRLF
TYPE , MSG3 ;** STARTING PASS 1 **
TYPE , \$CRLF
TYPE , MSG6 ;ON--

J05

MAINDEC-11-DZRM1 AO/00 RMO3 DRIVE COMPATIBILITY TEST MACY11 30(1046) 21-JUL-77 16:51 PAGE 61
 DZRM1A.P11 21-JUL-77 15:44 GET VALUE FOR SOFTWARE SWITCH REGISTER

SEQ 0060

```

2840 005556 104401 035030          TYPE      ,MSG1          ;SUB-SYSTEM
2841 005562 104401 001272          TYPE      ,SCDW2          ;A TO H
2842 005566 104401 036121          TYPE      ,LINSR          ;
2843 005572 111137 001222          1$:      MOV      (R1),DRIVE ;LOAD THE PHYSICAL DRIVE #
2844 005576 104401 001205          TYPE      ,SCRLF          ;
2845 005602 104401 035101          TYPE      ,MSG4          ;MOUNT PACK ON THE DRIVE
2846 005606 104401 001272          TYPE      ,SCDW2          ;SYS-NAME
2847 005612 113746 001222          MOV      DRIVE,-(SP) ;THE PHYSICAL DRIVE #
2848 005616 104403          TYPOS
2849 005620      002          .BYTE      2
2850 005621      000          .BYTE      0
2851 005622 104401 036121          TYPE      ,LINSR          ;
2852 005626 104401 035127          TYPE      ,MSG8          ;AND LOAD
2853 005632 104401 001205          TYPE      ,SCRLF          ;
2854 005636 104401 035142          TYPE      ,MSG9          ;
2855 005642 104411          2$:      RDLIN
2856 005644 012605          MOV      (SP)+,R5 ;LOCATE THE READIN LINE
2857 005646 122725 000122          CMPB    #'R,(R5)+ ;CHECK IF O.P. READY ?
2858 005652 001373          BNE
2859 005654 105715          TSTB    (R5) ;IF NOT
2860 005656 001371          BNE      2$ ;NOT CORRECT INPUT LINE FORMAT
2861 005660 113701 001272          MOV      $CDW2,R1 ;LOCATE THE SYSTEM ADDRESS TABLE
2862 005664 042701 177760          BIC      #'177760,R1 ;LEFT ON 4 BITS
2863 005670 005301          DEC      R1 ;ADJUST THE INDEX VALUE
2864 005672 006301          ASL      R1 ;FOUR WORD INDEX VALUE
2865 005674 006301          ASL      R1
2866 005676 016137 002004 023076          MOV      SYSADR(R1),RMAADR ;LOAD THE SYSTEM ADDRESS
2867 005704 016137 002006 023100          MOV      SYSADR+2(R1),RMVEC ;LOAD THE SYSTEM INTERRUPT VECTOR
2868 005712 004737 023114          JSR      PC,RMINIT ;INITIALIZE THE SYSTEM
2869 005716 012737 177777 023036          MOV      #-1,SAVEFG ;SAVE ALL RH/RM REGISTER
2870 005724 012737 177777 023040          MOV      #-1,SEEKFG ;DON'T DO ANY IMPLY SEEK
2871 005732 013700 001222          MOV      DRIVE,R0 ;R0=PHYSICAL DRIVE #
2872 005736 105760 022750          TSTB    DRVSTA(R0) ;ON-LINE ?
2873 005742 003404          BLE
2874 005744 105760 022760          TSTB    DRVSTYP(R0) ;AN RMO3
2875 005750 003401          BLE      4$ ;BRANCH IF NOT AN RMO3
2876 005752 000403          3$:      BR
2877 005754 104401 035201          4$:      BR      TST2 ;ALL DONE PROCEED TO TEST 2
2878 005760 000633          BR      TST1 ;DRIVE NOT READY
2879
2880
2881          ;TEST 2
2882          ;BASIC READ AND WRITE TEST
2883          ;ALL LOGICAL DRIVE ACCESS CYLINDER 620
2884          ;AND SECTOR ADDRESS IS COORESPONDING TO THE LOGICAL DRIVE #
2885          ;EACH LOGICAL DRIVE PERFORM WRITE AND WRITE CHECK ON ALL FIVE SURFACES(TRK0 - TRK4)
2886
2887
2888
2889          ;*****
2890          †ST2:  SCOPE
2891 005762 000004          MOV      #1,$TIMES ;DO 1 ITERATION
2892 005764 012737 000001 001174          MOV      #2,TSTNM ;LOAD TEST NUMBER
2893 005772 012737 000002 001336          MOV      #STACK,SP ;INITIAL THE STACK POINTER
2894 006000 012706 001100          MOV      #FMTDPB,R0 ;DPB BLOCK ADDRESS
2895 006004 012700 037146          MOV      $CDW1,R1 ;ADDRESS OF THE LOGICAL DRIVE BLOCK
2896 006010 013701 001270

```


K05

```

2896 006014 113710 001222          MOVB   DRIVE,(R0)      ;PHYSICAL DRIVE #
2897 006020 013760 001266 000010    MOV    $DEVH,$SEC(R0) ;LOAD THE SECTOR # FROM THE LOGICAL DRIVE NUMBER.
2898 006026 012760 001154 000012    MOV    #620,$CYL(R0)  ;LOAD CYLINDER NUMBER
2899 006034 012760 177400 000004    MOV    #-256,$WORDM(R0);LOAD NEG WORD COUNT
2900 006042 012760 037262 000006    MOV    #ENDPGH,$BUF(R0);LOAD BUFFER ADDRESS
2901 006050 012760 037166 000014    MOV    #RM.REG,14(R0) ;ADDRESS TO SAVE ALL RM/RM03 REG'S
2902 006056 105060 000011          CLRB   $TRK(R0)       ;START FROM TRACK 0
2903 006062 112760 000161 000002    MOVB   #WRTDAT,$COMND(R0);WRITE DATA COMMAND
2904 006070 004737 014546          JSR    PC,FILBUF      ;FILL THE BUFFER WITH STANDARD PATTERN
2905 006074 004037 023620          JSR    R0,RM03       ;CALL THE DRIVER
2906 006100 037146          FMTDPB
2907 006102 000774          BR     2$            ;BRANCH IF NOT QUEUE SUCCESSFULLY
2908 006104 005737 037164          3$:  TST    FMTDPB+16
2909 006110 001775          BEQ    3$            ;BRANCH IF NOT DONE
2910 006112 012700 037146          MOV    #FMTDPB,R0    ;R0=FMTDPB ADDRESS
2911 006116 004737 013264          JSR    PC,PROCESS    ;CHECK THE TERMINATION
2912 006122 112760 000151 000002    MOVB   #WCKD,$COMND(R0);CHANGE TO THE WRITE CHECK DATA COMMAND
2913 006130 004037 023620          4$:  JSR    R0,RM03       ;CALL THE DRIVER
2914 006134 037146          FMTDPB
2915 006136 000774          BR     4$            ;BRANCH IF NOT QUEUE SUCCESSFULLY
2916 006140 005737 037164          5$:  TST    FMTDPB+16
2917 006144 001775          BEQ    5$            ;BRANCH IF NOT DONE
2918 006146 012700 037146          MOV    #FMTDPB,R0
2919 006152 004737 013264          JSR    PC,PROCESS    ;PROCESS IF ANY ERROR HAPPENS ?
2920 006156 112760 000161 000002    MOVB   #WRTDAT,$COMND(R0);RESET TO WRITE DATA COMMAND
2921 006164 105260 000011          INCB   $TRK(R0)      ;INCREMENT TO THE NEXT TRACK
2922 006170 122760 000005 000011    CMPB   #5,$TRK(R0)   ;ALL TRACKS DONE ?
2923 006176 101336          BHI    2$            ;NO
2924
2925
2926
2927 ;TEST 3
2928 ;WRITE 7 ZONES FOR WRITE TEST IN PASS 2
2929 ;WRITE 6 ZONES FOR READ TEST IN PASS2
2930 ;$DEVH : LOGICAL DRIVE #
2931 ;$CDW1 : ADDRESS OF LOGICAL DRIVE HISTORY BLOCK FILE
2932 ;$CDW2 : SYS NAME
2933 ;DRIVE : PHYSICAL DRIVE # OF THIS LOGICAL DRIVE
2934 ;PACK  : ENTRY OF TABLE-D
2935 ;CMCNT : ZONE COUNT
2936 ;CMSEC : DELTA CYLINDER COUNT
2937 ;R4    : ENTRY POINTER OF TABLE-D,CANNOT BE DESTORIED.
2938 ;R0    : ADDRESS OF FMTDPB
2939
2940
2941
2942 ;*****
2943 ;*****
2944 006200 000004          †TST3: SCOPE
2945 006202 012737 000001 001174    MOV    #1,$TIMES     ;DO 1 ITERATION
2946 006210 012737 000003 001336    MOV    #3,TSTNM      ;LOAD THE TEST NUMBER
2947 006216 012706 001100          MOV    #STACK,SP     ;INITIAL THE STACK POINTER
2948 006222 012704 001376          MOV    #LOGO,R4      ;ADDRESS OF TABLE-D
2949 006226 013700 001266          MOV    $DEVH,R0      ;LOGICAL DRIVE #
2950 006232 001404          BEQ    2$            ;BRANCH IF LOGICAL DRIVE 0
2951 006234 062704 000020          1$:  ADD    #16.,R4     ;EACH LOGICAL DRIVE TAKES 16 BYTES IN THE TABLE
2951 006240 005300          DEC    R0            ;DECREMENT THE DRIVE # COUNT

```

L05

2952	006242	001374				BNE	15		; BRANCH UNTIL THE ENTRY IS LOCATED
2953	006244	010437	001322		25:	MOV	R4,PACK		; SAVE THE TABLE-D ENTRY IN PACK
2954									; SET UP THE FMTDPB BLOCK
2955	006250	012700	037146			MOV	#FMTDPB,R0		; ADDRESS OF FMTDPB
2956	006254	113710	001222			MOV	DRIVE,(R0)		; PHYSICAL DRIVE NUMBER
2957	006260	112760	000161	000002		MOV	#WRTDAT,\$CMD(R0)		; WRITE DATA COMMAND
2958	006266	012760	037262	000006		MOV	#ENDPGM,\$BUF(R0)		; BUFFER ADDRESS
2959	006274	012760	037166	000014		MOV	#RM.REG,14(R0)		; ADDRESS TO SAVE ALL RH/RMO3 REG'S
2960	006302	012760	177400	000004		MOV	#-256,\$WORD(R0)		; NEG WORD COUNT
2961	006310	013701	001266			MOV	\$DEVN,R1		; LOGICAL DRIVE #
2962	006314	006301				ASL	R1		; WORD INDEX
2963	006316	016104	002702			MOV	PSEUDO(R1),R4		; LOAD THE DATA PATTERN
2964	006322	016002	000006			MOV	\$BUF(R0),R2		; BUFFER ADDRESS IN R2
2965	006326	012703	000400			MOV	#256,R3		; POS WORD COUNT
2966	006332	010422			35:	MOV	R4,(R2)+		; FULL THE BUFFER WITH SIGLE WORD PATTERN
2967	006334	005303				DEC	R3		; DECREMENT THE WORD COUNT
2968	006336	001375				BNE	35		; BRANCH,UNTIL IT IS FULL
2969									
2970									
2971	006340	005046				CLR	-(SP)		; DUMY PAIR OF ZONE COUNT
2972	006342	005046				CLR	-(SP)		; DUMY STARTING CYLINDER NUMBER
2973	006344	012746	000006			MOV	#6, -(SP)		; ZONE COUNT
2974	006350	012746	000160			MOV	#112, -(SP)		; STARTING CYLINDER NUMBER
2975	006354	012737	000007	001352		MOV	#7,CMCNT		; ZONE COUNT
2976	006356	005037	001354			CLR	CMCYL		; STARTING CYLINDER NUMBER
2977	006356	012737	000020	001360	45:	MOV	#16,CMSEC		; DELTA CYLINDER NUMBER
2978	006374	012700	037146			MOV	#FMTDPB,R0		; R0 DPB ADDRESS
2979	006400	013704	001322			MOV	PACK,R4		; R4 ENTRY TO TABLE-D
2980	006404	013760	001354	000012	55:	MOV	CMCYL,\$CYL(R0)		; STARTING CYLINDER
2981	006412	105060	000011			CLRB	\$TRK(R0)		; STARTS FROM TRACK 0
2982	006416	111460	000010		65:	MOV	(R4),\$SEC(R0)		; LOAD SECTOR NUMBER FROM TABLE-D
2983	006422	004037	023620		75:	JSR	R0,RMO3		; CALL THE DRIVER
2984	006426	037146							
2985	006430	000774				BR	75		; BRANCH IF QUEU IS NOTSUCCESSFUL
2986	006432	005737	037164		85:	TST	FMTDPB+16		; DONE ?
2987	006436	001775				BEQ	85		; BRANCH IF NOT
2988	006440	012700	037146			MOV	#FMTDPB,R0		
2989	006444	004737	013264			JSR	PC,PROCES		; PROCESS TO CHECK IF ANY ERROR
2990	006450	062760	000020	000010		ADD	#16,\$SEC(R0)		; WRITE TWO SECTORS ON ONE CYLINDER
2991	006456	122760	000037	000010		CMPB	#31,\$SEC(R0)		; ALL DONE-TWO SECTORS
2992	006464	103346				BHIS	75		; BRANCH IF NOT
2993	006466	111460	000010			MOV	(R4),\$SEC(R0)		; RESTORE SECTOR #
2994	006472	105260	000011			INCB	\$TRK(R0)		; INCREMENT TO NEXT TRACK
2995	006476	122760	000004	000011		CMPB	#4,\$TRK(R0)		; LAST TRACK ?
2996	006504	103346				BHIS	75		; NO, THEN BRANCH
2997	006506	105060	000011			CLRB	\$TRK(R0)		; RESTORE TO TRACK-0
2998	006512	000060	000012			INC	\$CYL(R0)		; INCREMENT CYLINDER NUMBER
2999	006516	000064				INC	R4		; INCREMENT TABLE-D ENTRY
3000	006520	005337	001360			DEC	CMSEC		; DECREMENT THE DELTA CYLINDER COUNT
3001	006524	001334				BNE	65		; BRANCH IF NOT END OF THIS BLOCK
3002	006526	062760	000160	000012		ADD	#112,\$CYL(R0)		; INCREMENT THE CYLINDER NUMBER TO NEXT ZONE
3003	006534	016037	000012	001354		MOV	\$CYL(R0),CMCYL		; INITAIL THE STARTING CYLINDER IN THE BLOCK
3004	006542	005337	001352			DEC	CMCNT		; DECREMENT THE ZONE COUNT
3005	006546	001307				BNE	45		; LOOPING IF NOT END OF ZONE
3006	006550	012637	001354			MOV	(SP)+,CMCYL		; LOAD NEW PAIR OF STARTING CYLINDER
3007	006554	012637	001352			MOV	(SP)+,CMCNT		; AND ZONE COUNT

M05

3008 006560 005737 001354
 3009 006564 001300
 3010 006566 005737 001352
 3011 006572 001275

TST CMCYL ; NOT END YET ?
 BNE 4\$; BRANCH IF NOT
 TST CMCNT ; BRANCH IF NOT END
 BNE 4\$; LOOPING BACK

; TEST 4
 ; UPDATE THE PARAMETERS, \$CDW1, \$DEVN, ASSGN1
 ; DIRECT THE OPERATOR TO DISMOUNT PACK AND LOAD TO OTHER DRIVE
 ; \$CDW2, DRIVE ARE CHANGED BY TEST ONE ONLY AFTER THE TEST LOOPING TO TEST1

3022 006574 000004
 3023 006576 012737 000001 001174
 3024 006604 012737 000004 001336
 3025 006612 012706 001100
 3026 006516 012777 013256 014254
 3027 006024 005077 014252
 3028 006030 104401 001205
 3029 006034 104401 035323
 3030 006040 104401 001272
 3031 006044 013746 001222
 3032 006050 104403
 3033 006002
 3034 006003 000
 3035 006054 104401 036121
 3036 006060 104401 035341
 3037 006064 012701 000001
 3038 006070 005002
 3039 006072 020237 001266
 3040 006076 001404
 3041 006700 000241
 3042 006702 005101
 3043 006704 005202
 3044 006706 000771
 3045 006710 040137 002000
 3046 006714 001410
 3047 006716 005202
 3048 006720 006302
 3049 006722 016237 002600 001270
 3050 006730 006202
 3051 006732 010237 001266
 3052 006736 104411
 3053 006740 012205
 3054 006742 122725 000122
 3055 006746 001373
 3056 006750 105715
 3057 006752 001371
 3058 006754 005737 002000
 3059 006760 001002
 3060 006762 000137 006772
 3061 006766 000137 005450

↑ST4: SCOPE ; DO 1 ITERATION
 MOV #1, \$TIMES ; LOAD THE TEST NUMBER
 MOV #4, TSTNM ; LOAD THE STACK POINTER
 MOV #STACK, SP ; RESET THE INTERRUPT VECTOR
 MOV #IDLEX, \$RMVEC ; CLEAR THE INTERRUPT LEVEL
 CLR \$RMVEC+2
 TYPE , \$CRLF
 TYPE , #312
 TYPE , #2
 MOV \$DRIVE, -(SP)
 TYPOS
 .BYTE 2
 .BYTE 0
 TYPE , LINS
 TYPE , MESS13
 MOV #1, R1
 CLR R2
 1\$: CMP R2, \$DEVN ; LOCATE THE COORESPONDING BIT MAP
 BEQ 2\$; BRANCH IF LOCATED
 CLC ; LOCATE NEXT DRIVE
 ROL R1
 INC R2 ; NEXT DRIVE #
 BR 1\$; LOCATE THE BIT MAP
 2\$: BIC R1, ASSGN1 ; DEASSIGN THE LOGICAL DRIVE FOR PASS 1
 BEQ 4\$; NO MORE DRIVES
 3\$: INC R2 ; GET NEXT LOGICAL DRIVE #
 ASL R2 ; WORD INDEX
 MOV BLKADR(R2), \$CDW1 ; LOAD THE NEW DPB ADDRESS
 ASR R2 ; RESTORE R2
 MOV R2, \$DEVN ; LOAD THE NEW LOGICAL DRIVE #
 4\$: RDLIN ; WAIT UNTIL IT IS DONE
 MOV (SP)+, R5 ; LOCATE THE INPUT LINE
 CMPB #R, (R5)+
 BNE 4\$
 TSTB (R5)
 BNE 4\$; TERMINATOR ?
 TST ASSGN1 ; BRANCH IF NOT
 BNE 5\$; OTHER DRIVES ?
 JMP XPASS2 ; BRANCH IF MORE DRIVES IN TEST
 5\$: JMP TST1 ; JUMP TO TEST 1

3062
 3063

N05

```

3064 ;XPASS2 INITILIZE FOR PASS 2 TEST
3065 ;SCDW1 : ADDRESS OF THE CURRENT LOGICAL DRIVE HISTORY FILE
3066 ;SCDW2 : SYSTEM NAME A THROUGH H
3067 ;SDEVN : CURRENT LOGICAL DRIVE # 0 TO 15.
3068 ;ASSGN2 : ASSIGNED LOGICAL DRIVE FOR PASS 2
3069 ;ASNLST : ASSIGNED LOGICAL DRIVE
3070 ;DRIVE : PHYSICAL DRIVE # OF CURRENT RH/RM SYSTEM

```

```

3074 006772 005737 002002 XPASS2: TST ASSGN2 ;ANYTHING IN TEST FOR PASS 2
3075 00776 001002 BNE 1$ ;YES, THEN GO ON
3076 00700 000137 012762 JMP XEND2 ;JUMP TO END OF PASS 2
3077 007004 005037 001266 1$: CLR SDEVN ;START FROM LOGICAL DRIVE 0
3078 007010 013737 002600 001270 MOV BLKADR,SCDW1 ;ADDRESS OF LOGICAL BLOCK DRIVE 0
3079 007016 112737 000101 001272 MOVB #'A,SCDW2 ;LOAD SYSTEM NAME "A"
3080 007024 013737 002004 023076 MOV SYSAOR,RMADR ;LOAD SYSTEM-A ADDRESS TO DRIVER
3081 007032 013737 002006 023100 MOV SYSAOR+2,RMVEC ;LOAD SYSTEM-A VECTOR TO DRIVER
3082 007040 013701 001270 MOV SCDW1,R1 ;R1=ADDRESS OF LOGICAL BLOCK
3083 007044 104401 001205 TYPE ,SCRLF
3084 ; TYPE ,MSG:4 ;STARTING PASS 2
3085 007050 005037 001374 CLR FAULT ;RESET THE NOT COMPATIBLE FLAG
3086 007054 000400 BR TST5 ;BRANCH TO TEST 5

```

```

3088 ;SCDW1 : ADDRESS OF CURRENT LOGICAL DRIVE BLOCK, ONLY CHANGED BY TST9
3089 ;SCDW2 : SYSTEM-NAME , ONLY CHANGED BY TEST 5
3090 ;SDEVN : CURRENT LOGICAL DRIVE #
3091 ;ASSGN2 : ASSIGNED LOGICAL DRIVE'S BIT MAP FOR PASS 2
3092 ;DRIVE : PHYSICAL DRIVE #
3093 ;ASNLST : ASSIGNED LOGICAL DRIVE IN THE TEST
3094 ;IN TEST 5 DIRECT OPERATOR TO CHANGE, LOAD THE PACK
3095
3096
3097
3098
3099

```

```

3100 ;*****
3101 007056 000004 TST5: SCOPE
3102 007060 012737 000001 001174 MOV #1,STIMES ;DO 1 ITERATION
3103 007066 012737 000005 001336 MOV #5,TSTNM ;LOAD THE TEST NUMBER
3104 007074 012706 001100 MOV #STACK,SP ;LOAD THE STACK POINTER
3105 007100 012777 013256 013772 MOV #IDLEX,RMVEC ;RESET THE INTERRUPT VECTOR
3106 007106 005077 013770 CLR RMVEC+2 ;CLEAR THE INTERRUPT LEVEL
3107 007112 013701 001270 MOV SCDW1,R1 ;ADDRESS OF THE HISTORY FILE
3108 007116 126137 000014 001272 CMPB $$SYSNM(R1),SCDW2 ;ON THE SAME SUB-SYSTEM
3109 007124 001420 BEQ 1$ ;THEN DON'T UPDATE SYSTEM ADDRESS
3110 007126 116137 000014 001272 MOVB $$SYSNM(R1),SCDW2
3111 007134 013700 001272 MOV SCDW2,R0 ;LOCATE SYSTEM ADDRESS TABLE
3112 007140 005300 DEC R0 ;ADJUST FOR INDEX FORM 0
3113 007142 042700 177760 BIC #177760,R0 ;LEFT ON FOUR BITS
3114 007146 006300 ASL R0
3115 007150 006300 ASL R0 ;INDEX FOR TWO WORD
3116 007152 016037 002004 023076 MOV SYSAOR(R0),RMADR ;SYSTEM ADDRESS
3117 007160 016037 002006 023100 MOV SYSAOR+2(R0),RMVEC ;SYSTEM INTERRUPT VECTOR
3118 ;1$: MOV #IDLEX,RMVEC ;RESET THE INTERRUPT VECTOR
3119 ; CLR RMVEC+2 ;CLEAR THE INTERRUPT LEVEL

```

```

3120 007166 104401 001205      1$: TYPE , $CRLF
3121 007172 104401 035414      TYPE , MSG14 ; START THE PASS 2
3122 007176 104401 001205      TYPE , $CRLF
3123 007202 104401 035101      TYPE , MSG4 ; MOUNT PACK ON DRIVE
3124 007206 104401 001272      TYPE , $CDW2 ; SYSTEM NAME
3125 007212 111137 001222      MOVB (R1),DRIVE ; LOCATE THE PHYSICAL DRIVE #
3126 007216 111146              MOVB (R1),-(SP)
3127 007220 104403              TYPOS
3128 007222          002        .BYTE 2
3129 007223          000        .BYTE 0
3130 007224 104401 036121      TYPE , LINSF
3131 007230 104401 035127      TYPE , MSG8 ; AND LOAD
3132 007234 104401 001205      TYPE , $CRLF
3133 007240 104401 035142      TYPE , MSG9 ; TYPE R<CR> WHEN DRIVE IS READY
3134 007244 104411              ROLIN
3135 007246 012602              MOV (SP)+,R2 ; LOCATE THE READ IN LINE
3136 007250 122722 000122      CMPB #'R,(R2)+ ; FIRST CHAR IS A "R"
3137 007254 001373              BNE 2$ ; BRANCH IF NOT
3138 007256 105712              TSTB (R2) ; FOLLOWED BY A TERMINATOR
3139 007260 001371              BNE 2$ ; BRANCH IF NOT
3140 007262 004737 023114      JSR PC,RMINIT
3141 007266 012737 177777 023036 MOV #-1,SAVEFG ; SAVE ALL RH/RM REGISTERS
3142 007274 012737 177777 023040 MOV #-1,SEEKFG ; DON'T DO IMPLY SEEK
3143 007302 013700 001222      MOV DRIVE,R0 ; LOAD THE PHYSICAL DRIVE NUMBER
3144 007306 105760 022750      TSTB DRVSTA(R0) ; DRIVE EXISTS AND ON-LINE ?
3145 007312 003405              BLE 3$ ; BRANCH IF NOT
3146 007314 105760 022760      TSTB DRVTyp(R0) ; AN RMO3 ?
3147 007320 003402              BLE 3$ ; NOT AN RMO3
3148 007322 000137 007340      JMP TST6 ; BRANCH IF IT IS, (NEXT TEST)
3149 007326 104401 001205      3$: TYPE , $CRLF
3150 007332 104401 035201      TYPE , MSG10 ; DRIVE IS NOT READY
3151 007336 000647              BR TST5 ; TRY AGAIN
3152
3153
3154
3155 ;DRIVE : PHYSICAL DRIVE NUMBER
3156 ;$CDW1 : DPB BLOCK OF THIS LOGICAL DRIVE
3157 ;$DEVN : LOGICAL DRIVE #
3158 ;$CDW2 : SUB-SYSTEM NAME
3159 ;RMDR : SUB-SYSTEM BASE REGISTER ADDRESS
3160 ;RMVEC : SUB-SYSTEM INTERRUPT VECTOR
3161
3162 ;THE ABOVE PARAMETERS CANNOT BE MODIFIED BY THIS TEST (TST6)
3163 ;THE FOLLOWING REG'S ARE ASSIGNED AS:
3164 ;R0 : ADDRESS OF DPB FEED INTO DRIVER HANDLER=FMTDPB
3165 ;R1 : ADDRESS OF THE HISTORY FILE BLOCK OF THE LOGICAL DRIVE=$CDW1
3166
3167
3168 ;IN TEST 6, EACH LOGICAL DRIVE WRITES 7 CYLINDERS ON EACH SURFACE WITH
3169 ;AN UNIQUE DATA PATTERN. THESE 7 CYLINDERS HAS BEEN
3170 ;WRITTEN BY OTHER DRIVES IN PASS 1.
3171 ;THEN, THIS LOGICAL DRIVE EXECUTES "WRITE CHECK DATA" TO SEE IF
3172 ;THIS LOGICAL DRIVE CAN OVER-WRITE ALL DATA WRITTEN BY OTHER
3173 ;DRIVES.
3174
3175 ;THESE 7 CYLINDERS ARE SPECIFIED AS $DEVN,$DEVN+128,$DEVN+256
    
```

3176
3177
3178
3179
3180
3181
3182
3183
3184
3185
3186
3187
3188
3189
3190
3191
3192
3193
3194
3195
3196
3197
3198
3199
3200
3201
3202
3203
3204
3205
3206
3207
3208
3209
3210
3211
3212
3213
3214
3215
3216
3217
3218
3219
3220
3221
3222
3223
3224
3225
3226
3227
3228
3229
3230
3231

007340 000004
007342 012737 000001 001174
007350 012737 000006 001336
007356 012706 001100
007362 012703 002046
007366 012704 002306
007372 005023
007374 020403
007376 101375
007400 012700 037146
007404 013701 001270
007410 113710 001222
007414 012760 160000 000004
007422 005060 000010
007426 112760 000161 000002
007434 013760 001266 000012
007442 012760 037262 000006
007450 012760 037166 000014
007456 013702 001266
007462 006302
007464 016202 002702
007470 016003 000006
007474 012704 020000
007500 010223
007502 005304
007504 001375
007506 004037 023620
007512 037146
007514 000774
007516 005737 037164
007522 001775
007524 012700 037146
007530 004737 013264
007534 105260 000011
007540 122760 000005 000011
007546 101357
007550 105060 000011
007554 062760 000200 000012
007562 022760 001417 000012
007570 103346

;SDEV+384,SDEV+512,SDEV+640 AND SDEV+768.
;THE OVER-WRITE TEST IS PERFORMED WITH OFFSETS IN BOTH DIRECTIONS.
; :
;*****
TST6: SCOPE
MOV #1,STIMES ;DO 1 ITERATION
MOV #6,TSTNM ;LOAD TEST NUMBER
MOV #STACK,SP ;INITIAL THE STACK POINT
MOV #OVIND,R3 ;1 ST ADDRESS TO CLEAR
MOV #RND,R4 ;LAST ADDRESS+2
1\$: CLR (R3)+ ;RESET ALL SCORE BOARD
CMP R4,R3 ;ALL LOCATIONS ARE CLEARED ?
BHI 1\$;BRANCH IF NOT
MOV #FMTDPB,R0 ;SET UP PARAMETER BLOCK
MOV #CDW1,R1 ;HISTORY FILE BLOCK
MOVB DRIVE,(R0) ;LOAD THE PHYSICAL DRIVE #
MOV #8192,SWRDM(R0) ;LOAD THE WORD COUNT
CLR #SEC(R0) ;START FROM TRKO,SECO
MOVB #WRTDAT,SCOMD(R0) ;WRITE DATA COMMAND
MOV SDEV,SCYL(R0) ;LOAD THE STARTING CYLINDER
MOV #ENDPGH,SBUF(R0) ;LOAD THE BUFFER ADDRESS
MOV #RM.REG,14(R0) ;REG'S SAVE ADDRESS
MOV SDEV,R2 ;LOCATE THE DATA PATTERN
ASL R2 ;WORD INDEX
MOV PSEUDO(R2),R2 ;LOAD R2 THE DATA PATTERN POINTED
;BY ITSELF
MOV SBUF(R0),R3 ;BUFFER ADDRESS
MOV #8192,R4 ;WORD COUNT
2\$: MOV R2,(R3)+ ;FILL THE BUFFER
DEC R4 ;DECREMENT WORD CTR
BNE 2\$;BRANCH IF NOT DONE
;START TO WRITE ONE CYLINDER
;ON EACH SURFACE OF EACH WRITE
;CURRENT ZONE (7 ZONES ON ONE PACK)
3\$: JSR R0,RM03 ;CALL THE DRIVER
;PARAMETER BLOCK
BR 3\$;BRANCH IF QUEUE FAIL
4\$: TST FMTDPB+16 ;WRITE COMMAND DONE ?
BEQ 4\$;NO, THEN WAIT
MOV #FMTDPB,R0 ;PROCESS IF ANY ERROR
JSR PC,PROCES
INCB STRK(R0) ;NEXT TRACK
CMPB #5,STRK(R0) ;LAST TRACK IS DONE ?
BHI 3\$;NO, THEN BRANCH
CLRB STRK(R0) ;RESET TRACK NUMBER
ADD #128,SCYL(R0) ;MOVE TO NEXT ZONE
CMP #783,SCYL(R0) ;LAST ZONE IS DONE ?
BHIS 3\$;BRANCH IF NOT
;RESET THE FMTDPB BLOCK AND
;EXECUTE WRITE-CHECK COMMAND
;TO DETECT ANY COMPATIBLE PROBLEM

```

3232                                     ;THE FOLLOWING SUBROUTINE ARE CALLED
3233                                     ;SCORE,OFFST,MAKEUP.
3234
3235 007572 005037 002640                CLR    OFFCOD                ;SET NEGATIVE OFFSET DIRECTION FLAG
3236 007576 012700 037146                MOV    #FMTDPB,RO           ;RO=FMTDPB ADDRESS
3237 007602 005060 000010                CLR    $SEC(RO)            ;START FROM SECTOR 0,SURFACE 0
3238 007606 013760 001266 000012        MOV    $DEVH,$CYL(RO)      ;STARTING CYLINDER NUMBER
3239                                     ;TOTAL 7 CYLINDERS ON ONE SURFACE
3240 007614 112760 000151 000002        MOV    #WCKD,$COMND(RO)    ;WRITE-CHECK-DATA COMMAND
3241 007622 012760 037262 000006        MOV    #ENDPGM,$BUF(RO)    ;RESET BUFFER ADDRESS
3242 007630 012760 037166 000014        MOV    #RM.REG,14(RO)      ;ADDRESS TO SAVE RM/RMO3 REG'S
3243 007636 004037 023620                JSR    RO,RMO3              ;CALL THE DRIVER
3244 007642 037146                        FMTDPB                       ;PARAMETER BLOCK ADDRESS
3245 007644 000774                        BR                               ;BRANCH IF QUEUE FAILURE
3246 007646 005737 037164                TST    FMTDPB+16           ;TEST IF COMMAND IS DONE ?
3247 007652 001775                        BEQ    2$                  ;BRANCH IF NOT
3248 007654 012700 037146                MOV    #FMTDPB,RO           ;LOAD THE PARAMETER BLOCK ADDRESS
3249 007660 004737 013264                JSR    PC,PROCES            ;REPORT IF ANY ERROR
3250 007664 004737 010732                JSR    PC,LABAU             ;LOCATE STARTING AND ENDING SECTORS
3251 007670 005760 000016                TST    16(RO)              ;ANY ERROR ?
3252 007674 100006                        BPL    3$                  ;BRANCH IF NONE
3253 007676 023737 001360 001356        CMP    CMSEC,STARSC        ;ON THE SAME SECTOR FOR STARTING AND ENDING
3254 007704 101404                        BLOS   4$                  ;DON'T INCREMENT SCORES
3255 007706 005337 001360                DEC    CMSEC                ;DECREMENT THE SECTOR ADDRESS
3256 007712 004737 010512                JSR    PC,SCORE            ;INCREMENT SCORE
3257 007716 005760 000022                TST    $RMWC(RO)           ;WORD COUNT = 0 /
3258 007722 001407                        BEQ    5$                  ;BRANCH IF WORD COUNT IS 0
3259 007724 116060 000026 000010        MOV    $RMDA(RO),$SEC(RO)  ;UPDATE STARTING SECTOR
3260 007732 016060 000022 000004        MOV    $RMWC(RO),$WRDM(RO) ;UPDATE WORD COUNT
3261 007740 000736                        BR    1$                   ;TO READ THE REST SECTORS
3262
3263
3264                                     ;THE FOLLOWING CODING TEST THE
3265                                     ;COMPATIBLE PROBLEM IN OFFSET MODE
3266                                     ;OFFCOD=0,NEGATIVE ;OFFCOD=1 ,POSITIVE
3267
3268 007742 012700 037146                5$:  MOV    #FMTDPB,RO           ;RESET THE DPB BLOCK
3269 007746 012760 160000 000004        MOV    #-8192,$WRDM(RO)    ;FULL TRACK WORD COUNT
3270 007754 105060 000010                CLR    $SEC(RO)            ;RESET TO SECTOR 0,SURFACE NOT CHANGED
3271 007760 012760 037262 000006        MOV    #ENDPGM,$BUF(RO)    ;BUFFER ADDRESS
3272 007766 012760 037166 000014        MOV    #RM.REG,14(RO)      ;ADDRESS TO SAVE ALL RM/RMO3 REG'S
3273 007774 004537 010176                JSR    K5,OFFST            ;CALL OFFSET
3274 010000 000440                        BR    10$                 ;BRANCH TO NEXT CYLINDER,IF OFFSET FAILS
3275 010002 004737 010400                JSR    PC,MAKEUP           ;CALL WRITE CHECK IN OFFSET MODE
3276 010006 005737 037164                7$:  TST    FMTDPB+16           ;OFFSET WRITE CHECK IS DONE ?
3277 010012 001775                        BEQ    7$                  ;BRANCH IF NOT
3278
3279 010014 012700 037146                MOV    #FMTDPB,RO           ;LOAD THE DPB ADDRESS
3280 010020 004737 013264                JSR    PC,PROCES            ;REPORT IF ANY ERROR
3281 010024 004737 010732                JSR    PC,LABAU             ;LOCATE STARTING AND ENDING SECTORS
3282 010030 005760 000016                TST    16(RO)              ;ANY ERROR ?
3283 010034 100006                        BPL    8$                  ;BRANCH IF NONE
3284 010036 023737 001360 001356        CMP    CMSEC,STARSC        ;STARTING AND ENDING ADDRESSES O.K ?
3285 010044 101404                        BLOS   9$                  ;BRANCH IF NOT
3286 010046 005337 001360                DEC    CMSEC                ;EXCLUDING THE BAD SECTOR
3287 010052 004737 010512                8$:  JSR    PC,SCORE            ;UPDATE THE TEST SCORE
    
```


E06

```

3288 010056 005760 000022 95: TST $RMWC(R0) ;WORD CTR = 0 ?
3289 010062 001407 BEQ 10$ ;IF WORD CTR=0 BRANCH TO NEXT OP
3290 010064 116060 000026 000010 MOV $RMDA(R0), $SEC(R0) ;UPDATE THE NEW STARTING ADDRESS
3291 010072 016060 000022 000004 MOV $RMWC(R0), $WRDM(R0) ;UPDATE THE NEW WORD COUNT
3292 010100 000735 BR 6$
3293 010102 062760 000200 000012 10$: ADD #128., $CYL(R0) ;ADJUST CYLINDER ADDRESS TO NEXT ZONE
3294 010110 022760 001417 000012 CMP #783., $CYL(R0) ;ALL 7 ZONES HAVE BEEN TESTED ?
3295 010116 103402 BLO 11$ ;BRANCH, IF ALL DONE
3296 010120 000137 007614 JMP LOOP2 ;TO NEXT WRITE CURRENT ZONE
3297 010124 013760 001266 000012 11$: MOV $DEVN, $CYL(R0) ;RESET CYLINDER ADDRESS
3298 010132 105260 000011 INCB $TRK(R0) ;INCREMENT TO NEXT SURFACE
3299 010136 122760 000005 000011 CMPB #5, $TRK(R0) ;ALL FIVE SURFACES ARE TESTED ?
3300 010144 101402 BLOS 12$ ;BRANCH IF ALL DONE
3301 010146 000137 007614 JMP LOOP2 ;TO NEXT SURFACE
3302 010152 005737 002640 12$: TST OFFCOD ;FINISHING TEST THE POSITIVE OFFSET ?
3303 010156 001005 BNE 13$ ;BRANCH IF ALL DONE
3304 010160 012737 000001 002640 MOV #1, OFFCOD ;SET POSITIVE OFFSET DIRECTION FLAG
3305 010166 000137 007576 JMP LOOP1 ;RESTART LOCATION
3306 010172 000137 011030 13$: JMP TST7 ;BRANCH TO NEXT TEST
    
```

```

3307
3308
3309
3310
3311 ;OFFST ROUTINE
3312 ;OFFSET THE HEAD IN THE DIRECTION TOWARD SPINDLE OR AWAY FROM THE SPINDLE
3313 ;OFFCOD = 1 TOWARD SPINDLE (POSITIVE)
3314 ;OFFCOD = 0 AWAY FROM SPINDLE (NEGATIVE)
3315 ;DRIVE PHYSICAL DRIVE NUMBER
3316 ;R0 DPB ADDRESS
3317 ;RETRY 3 TIMES
3318 ;CALLING SEQUENCE
3319 ; JSR R5, OFFST
3320 ; RET1 OFFSET FAIL RETURN ADDRESS
3321 ; RET2 OFFSET SUCCESSFUL RETURN
3322
    
```

```

3323 010176 010146 OFFST: MOV R1, -(SP) ;SAVE ALL REGISTERS
3324 010200 010246 MOV R2, -(SP)
3325 010202 010346 MOV R3, -(SP)
3326 010204 010446 MOV R4, -(SP)
3327 010206 013704 023076 MOV $RMDA, R4 ;RH70/RM BASE ADDRESS
3328 010212 013701 001222 MOV $DRIVE, R1 ;PHYSICAL DRIVE # R1 FOR INDEXING
3329 010216 012702 000003 MOV #3, R2 ;TRY TO OFFSET 3 TIMES
3330 010222 005003 15: CLR R3 ;DECREMENT COUNT
3331 010224 010164 000010 MOV R1, RMCS2(R4) ;LOAD DRIVE ADDRESS
3332 010230 012764 000011 000000 MOV #11, RMCS1(R4) ;CLEAR DRIVE WITH INTERRUPT DISABLE
3333 010236 016064 000012 000034 MOV $CYL(R0), $RMDA(R4) ;LOAD DESIRED CYLINDER ADDRESS
3334 010244 016064 000010 000006 MOV $SEC(R0), $RMDA(R4) ;LOAD DESIRED ADDRESS
3335 010252 016064 000004 000002 MOV $WRDM(R0), $RMWC(R4) ;LOAD WORD COUNT
3336 010260 016064 000006 000004 MOV $BUF(R0), $RMBR(R4) ;LOAD BUFFER ADDRESS
3337 010266 005737 002640 TST OFFCOD ;WHICH DIRECTION ?
3338 010272 001404 BEQ 2$ ;BRANCH IF NEGATIVE
3339 010274 012764 010200 000032 MOV #BIT12:BIT7, $RMOF(R4) ;LOAD RMOF WITH FMT AND OFT
3340 010302 000403 BR 3$
3341 010304 012764 010000 000032 2$: MOV #BIT12, $RMOF(R4) ;LOAD FMT ONLY
3342 010312 012764 000015 000000 3$: MOV #15, RMCS1(R4) ;ISSUE OFFSET COMMAND
3343 010320 136164 023064 000016 4$: BITB $ATABIT(R1), $RMA5(R4) ;ATA= 1
    
```


F06

```

3344 010326 001005      BNE      5$      ; OFFSET IS DONE
3345 010330 005303      DEC      R3      ; COUNT = 0
3346 010332 001372      BNE      4$      ; BRANCH IF NOT
3347 010334 005302      DEC      R2      ; DECREMENT RETRY COUNT
3348 010336 003413      BLE      6$      ; ERROR EXT
3349 010340 000730      BR       1$      ; RETRY
3350 010342 032764 040000 000012 5$: BIT      #BIT14,RMDS(R4) ; ANY ERROR DURING OFFSET ?
3351 010350 001324      BNE      1$      ; BRANCH IF ERROR
3352 010352 032764 000001 000012 BIT      #BIT0,RMDS(R4) ; OFFSET MODE BIT SET ?
3353 010360 001720      BEQ      1$      ; BRANCH IF NOT
3354 010362 062705 000002      ADD      #2,R5    ; ADJUST RETURN ADDRESS
3355 010366 012604      MOV      (SP)+,R4 ; RESTORE REG
3356 010370 012603      MOV      (SP)+,R3
3357 010372 012602      MOV      (SP)+,R2
3358 010374 012601      MOV      (SP)+,R1
3359 010376 000205      RTS      R5      ;EXIT
3360
3361
3362      ;MAKEUP ROUTINE
3363      ;THIS ROUTINE ISSUES A WRITE CHECK OR READ  COMMAND TO THE SELECTED DRIVE
3364      ;IN OFFSET MODE.
3365      ;AND SET UP THE FOLLOWING PARAMETERS
3366      ;
3367      ; DTUM = PHYSICAL DRIVE NUMBER
3368      ; TRNSWT = FMTDPB
3369      ; DRVACT (DRIVE) = 1
3370      ; TIMER (DRIVE) = 1 SECOND
3371
3372      ;CALLING SEQ
3373
3374      JSR      PC,MAKEUP
3375      RET
3376      ;MAIN PURPOSE OF THIS ROUTINE, TO EXECUTE A COMMAND WHILE ASSURE THAT
3377      ;THIS READ OR WRITE-CHECK COMMAND BEING EXECUTED IN OFFSET MODE.
3378      ;ROUTINES USED TO,SC,STO,( IN DRIVE HANDLER )
3379
3380
3381
3382 010400 010146      MAKEUP: MOV      R1,-(SP)
3383 010402 010246      MOV      R2,-(SP)
3384 010404 010446      MOV      R4,-(SP)
3385 010406 012702 000151  MOV      #WCKD,R2    ; WRITE CHECK DATA IN TEST 6
3386 010412 022737 000010 001336  CMP      #10,TSTNM  ; ON TEST 8 ?
3387 010420 001002      BNE      1$      ; BRANCH IF NOT
3388 010422 012702 000171  MOV      #RDDAT,R2  ; READ DATA COMMAND IN TEST 8
3389 010426 005037 037164 1$: CLR      FMTDPB+16 ; CLEAR THE STATUS WORD
3390 010432 013737 001222 023062  MOV      DRIVE,DTUM ; ACTIVE DRIVE NUMBER
3391 010440 012737 037146 023010  MOV      #FMTDPB,TRNSWT ; TRANSFER UNDERWAY FLAG
3392 010446 013701 001222      MOV      DRIVE,R1  ; DRIVE NUMBER
3393 010452 013704 023076      MOV      RMADR,R4  ; RH/RM BASE ADDRESS
3394 010456 112761 000001 022740  MOV      #1,DRVACT(R1) ; ACTIVE DRIVE FLAG
3395 010464 006301      ASL      R1      ; WORD INDEX
3396 010466 012761 001750 023042  MOV      #1000.,TIMER(R1) ; ONE SECOND TIMER
3397 010474 006201      ASR      R1
3398 010476 010264 000000      MOV      R2,RMCSI(R4) ; ISSURE WRITE CHECK OR READ COMMAND
3399 010502 012604      MOV      (SP)+,R4 ; RESTORE REG 4, 1
    
```

```

3400 010504 012602          MOV      (SP)+,R2
3401 010506 012601          MOV      (SP)+,R1
3402 010510 000207          RTS      PC          ;EXIT
3403
3404
3405          ; SCORE ROUTINE
3406          ; ROUTINE TO UPDATE THE TEST SCORE
3407          ; (TABLEX): ADDRESS OF CURRENT SCORE BOARD
3408          ; $DEVN: LOGICAL DRIVE #
3409          ; DRIVE: PHYSICAL DRIVE NUMBER
3410          ; CMSEC: END SECTOR ADDRESS
3411          ; STARSC: START SECTOR ADDRESS
3412          ; CALL SEQ
3413
3414          ;
3415          JSR      PC, SCORE
3416          RET
3417
3418          SCORE:
3419 010512          MOV      R1, -(SP)      ; PUSH R1 ON STACK
3420 010514          MOV      R2, -(SP)      ; PUSH R2 ON STACK
3421 010516          MOV      R3, -(SP)      ; PUSH R3 ON STACK
3422 010520          MOV      R4, -(SP)      ; PUSH R4 ON STACK
3423 010522          CMP      CMSEC, STARSC  ; CORRECT START AND STOP ADDRESSES
3424 010530          BLE      9$          ; BRANCH IF NOT
3425 010532          CMP      #10, TSTNM    ; ON TEST 8
3426 010540          BNE      2$          ; BRANCH IF NOT (MUST BE TEST 6)
3427 010542          TST      OFFCOD    ; NEGATIVE OFFSET ?
3428 010546          BEQ      1$          ; BRANCH IF NEGATIVE OFFSET
3429 010550          MOV      #RDPO, R3    ; SCORE BOARD ADDRESS
3430 010554          BR      4$
3431 010556          MOV      #RDNO, R3    ; SCORE BOARD ADDRESS
3432 010562          BR      4$
3433 010564          TST      OFFCOD    ; NEGATIVE OFFSET
3434 010570          BEQ      3$          ; BRANCH IF NEGATIVE OFFSET
3435 010572          MOV      #OVWPO, R3  ; SCORE BOARD ADDRESS
3436 010576          BR      4$
3437 010600          MOV      #OVWNO, R3    ; SCORE BOARD ADDRESS
3438 010604          MOV      #FMTDPB+STRK, R2 ; LOAD THE SURFACE NUMBER
3439 010610          TST      R2          ; ON SURFACE 0
3440 010612          BEQ      6$          ; BRANCH IF IT IS
3441 010614          ADD      #16., R3    ; EACH SCORE BOARD TAKES 16 BYTES
3442 010620          DEC      R2          ; LOCATED ?
3443 010622          BNE      5$          ; BRANCH IF NOT
3444 010624          MOV      R3, TABLEX  ; STORE THE TABLE STARTING ADDRESS
3445 010630          MOV      R3, R1          ; RE ASSIGN REGISTERS
3446 010632          MOV      $DEVN, R2    ; LOGICAL DRIVE #
3447 010636          MOV      STARSC, R3    ; START SECTOR
3448 010642          MOV      INDS(T,R2), R4 ; LOCATE THE STARTING PRONT FOR SCORE BOARD
3449 010646          ADD      R3, R4          ; UPDATE POINTER
3450 010650          CMP      #15., R4    ; SHOULD ADJUST POINTER ?
3451 010654          BLE      7$          ; NO
3452 010656          SUB      #16., R4    ; ENTRY POINT AT THE SCORE BOARD
3453 010662          BR      11$
3454 010664          ADD      R4, R1
3455 010666          CMP      CMSEC, R3    ; ENDING SECTOR REACHED ?
    
```

```

3456 010672 002412          BLT      9$          ;BRANCH IF IT IS
3457 010674 105221          INCB     (R1)+       ;INCREMENT SCORE AND POINT TO NEXT
3458                                ;LOGICAL DRIVE
3459 010676 005204          INC      R4          ;INCREMENT LOGICAL DRIVE #
3460 010700 005203          INC      R3          ;INCREMENT SECTOR COUNT
3461 010702 022704 000017  CMP      #15.,R4     ;TIME TO RESET TABLE ?
3462 010706 002367          BGE     B$          ;BRANCH IF NOT
3463 010710 013701 002044  MOV      TABLEX,R1 ;RESET TABLE ADDRESS
3464 010714 005004          CLR     R4          ;LOGICAL DRIVE 0
3465 010716 000763          BR      B$          ;LOOPING BACK
3466 010720          9$:
3467 010720 012604          MOV     (SP)+,R4    ;:POP STACK INTO R4
3468 010722 012603          MOV     (SP)+,R3    ;:POP STACK INTO R3
3469 010724 012602          MOV     (SP)+,R2    ;:POP STACK INTO R2
3470 010726 012601          MOV     (SP)+,R1    ;:POP STACK INTO R1
3471 010730 000207          RTS     PC

```

```

3472
3473
3474          ;LABAD ROUTINE
3475          ;LOCATE THE START SECTOR AND THE TERMINATE SECTOR OF THE PREVIOUS
3476          ;OPERATION
3477
3478          ;STARSC :      STARTING SECTOR
3479          ;CMSEC :      ENDING SECTOR
3480          ;INFORMATION FROM $RMDA(FMTDPB), $RMWC(FMTDPB), $SEC(FMTDPB)
3481          ;          $SEC(FMTDPB), $WRDM(FMTDPB)
3482          ;CALLING SEQ
3483
3484          ;          JSR      PC,LABAD
3485          ;          RET

```

```

3486
3487
3488          LABAD:
3489 010732 010046          MOV     R0,-(SP)    ;:PUSH R0 ON STACK
3490 010734 010246          MOV     R2,-(SP)    ;:PUSH R2 ON STACK
3491 010736 012700 037146  MOV     #FMTDPB,R0  ;:DPB ADDRESS
3492 010742 116002 000026  MOV     $RMDA(R0),R2 ;:HARDWARE TERMINATING SECTOR
3493 010746 116037 000010 001356  MOV     $SEC(R0),STARSC ;:STARTING SECTOR ADDRESS
3494 010754 005702          TST     R2          ;:TERMINATOR AT 0 SECTOR
3495 010756 001404          BEQ     1$          ;:BRANCH IF IT IS
3496 010760 005302          DEC     R2          ;:DECREMENT ONE SECTOR COUNT
3497 010762 010237 001360  MOV     R2,CMSEC    ;:ENDING SECTOR ADDRESS
3498 010766 000415          BR      3$          ;:EXIT
3499 010770 005760 000022  1$:    TST     $RMWC(R0)   ;:WORD COUNT = 0
3500 010774 001407          BEQ     2$          ;:BRANCH IF IT IS
3501 010776 026060 000022 000004  CMP     $RMWC(R0), $WRDM(R0) ;:WORD COUNT CHANGED AT ALL ?
3502 011004 001003          BNE     2$          ;:BRANCH IF CHANGED
3503 011006 116037 000010 001360  MOV     $SEC(R0),CMSEC ;:END SECTOR = START SECTOR
3504 011014 112737 000037 001360  2$:    MOV     #31.,CMSEC ;:END AT SECTOR 31
3505 011022          3$:
3506 011022 012602          MOV     (SP)+,R2    ;:POP STACK INTO R2
3507 011024 012600          MOV     (SP)+,R0    ;:POP STACK INTO R0
3508 011026 000207          RTS     PC

```

```

3509
3510          ;TEST 7
3511          ;SELF TEST:WRITE CYLINDERS $DEV+17,$DEV+17+128,$DEV+17+128X2,ETC.

```

```

3512 ; THEN EXECUTE WRITE CHECK TO DETECT ANY DATA OR HEADER PROBLEM
3513 ; FOR THE SELECTED LOGICAL DRIVE
3514 ; $DEVN: LOGICAL DRIVE #
3515 ; DRIVE: PHYSICAL DRIVE #
3516 ;
3517 ;
3518 ;
3519 ;
3520 ; *****
3521 011030 000004 15: SCOPE
3522 011032 012737 000001 001174 MOV #1, $TIMES ; DO 1 ITERATION
3523 011040 012737 000007 001336 MOV #7, $TSTM ; LOAD TEST NUMBER
3524 011046 012706 001100 MOV #STACK, SP ; INITIAL THE STACK
3525 011052 012702 002546 MOV #SELF0, R2 ; CLEAR THE SELF TEST SCORE BOARDS
3526 011056 005022 CLR (R2)+ ;
3527 011060 022702 002560 15: CMP #SELF0+12, R2 ; ALL DONE ?
3528 011064 101374 BHI 15 ; BRANCH IF NOT
3529 011066 012700 037146 MOV #FMTDPB, R0 ; SET UP DPB
3530 011072 012760 160000 000004 MOV #-8192, $WRDM(R0) ; LOAD FULL TRACK WORD COUNT
3531 011100 112760 000161 000002 MOVB #WRTDAT, $COMND(R0) ; WRITE DATA COMMAND
3532 011106 005060 000010 CLR $SEC(R0) ; SECTOR 0, SURFACE 0
3533 011112 113710 001222 MOVB DRIVE, (R0) ; LOAD PHY. DRIVE
3534 011116 013702 001266 MOV $DEVN, R2 ; LOCATE THE STARTING CYLINDER
3535 011122 062702 000021 ADD #17, R2
3536 011126 010260 000012 MOV R2, $CYL(R0) ; CYLINDER ADDRESS
3537 011132 012760 037262 000006 MOV #ENOPGM, $BUF(R0) ; RESET BUFFER ADDRESS
3538 011140 012760 037166 000014 MOV #RM.REG, 14(R0) ; ADDRESS TO SAVE ALL RH/RMO3 REG'S
3539 011146 004737 014546 JSR PC, FILBUF ; FILL THE BUFFER WITH WORSE CASE PATTERN
3540 011152 004037 023620 25: JSR R0, RMO3 ; CALL DRIVER HANDLER
3541 011156 037146 FMTDPB
3542 011160 000774 BR 25 ; BRANCH IF QUEUE FAILS
3543 011162 005737 037164 35: TST FMTDPB+16 ; ALL DONE ?
3544 011166 001775 BEQ 35 ; BRANCH IF NOT
3545 011170 012700 037146 MOV #FMTDPB, R0 ; REPORT IF ANY ERROR
3546 011174 004737 013264 JSR PC, PROCES
3547 011200 105260 000011 INCB $TRK(R0) ; NEXT SURFACE
3548 011204 122760 000005 000011 CMPB #5, $TRK(R0) ; ALL FIVE SURFACE ARE DONE ?
3549 011212 101357 BHI 25 ; BRANCH IF NOT
3550 011214 005060 000010 CLR $SEC(R0) ; RESET SECTOR AND TRACK
3551 011220 062760 000200 000012 ADD #128, $CYL(R0) ; ADVANCE TO NEXT ZONE
3552 011226 022760 001440 000012 CMP #800, $CYL(R0) ; ALL 7 ZONES ARE DONE ?
3553 011234 103346 BHIS 25 ; BRANCH IF NOT
3554 ; EXECUTE WRITE CHECK
3555 ; TO DETECT ANY DATA OR HEADER
3556 ; PROBLEM
3557 011236 112760 000151 000002 MOVB #WCKD, $COMND(R0) ; CHANGE TO WRITE CHECK COMMAND
3558 011244 012702 002546 MOV #SELF0, R2 ; R2 POINTS TO SCORE BOARD
3559 ; CAN NOT BE DESTORIED
3560 011250 013703 001266 MOV $DEVN, R3 ; LOCATE STARTING ADDRESS
3561 011254 062703 000021 ADD #17, R3
3562 011260 010360 000012 MOV R3, $CYL(R0) ; STARTING CYLINDER
3563 011264 005037 002640 CLR OFFCOD ; SET NEGATIVE OFFSET FLAG
3564 011270 004037 023620 45: JSR R0, RMO3 ; CALL DRIVE HANDLER
3565 011274 037146 FMTDPB
3566 011276 000774 BR 45 ; BRANCH IF QUEUE FAILS
3567 011300 005737 037164 55: TST FMTDPB+16 ; ALL DONE ?

```

```

3568 011304 001775          BEQ      5$          ;BRANCH IF NOT
3569 011306 012700 037146    MOV      #FMDPB,R0
3570 011312 004737 013264    JSR      PC,PROCS
3571 011316 005760 000016    TST      16(R0)      ;ANY ERROR
3572 011322 100401          BMI      6$          ;YES, THEN DON'T INCREMENT SCORE
3573 011324 105212          INCB     (R2)        ;INCREMENT SCORE
3574 011326 004537 010176    6$:     JSR      RS,OFFST ;OFFSET
3575 011332 000415          BR       8$          ;BRANCH IF OFFSET FAILS
3576 011334 004737 010400    JSR      PC,MAKEUP  ;EXECUTE WRITE CHECK IN OFFSET MODE
3577 011340 005737 037164    7$:     TST      FMDPB+16 ;ALL DONE /
3578 011344 001775          BEQ      7$          ;BRANCH IF NOT
3579 011346 012700 037146    MOV      #FMDPB,R0
3580 011352 004737 013264    JSR      PC,PROCS  ;REPORT IF ANY ERROR
3581 011356 005760 000016    TST      16(R0)    ;ERROR BIT SET ?
3582 011362 100401          BMI      8$          ;DON'T INCREMENT SCORE
3583 011364 105212          INCB     (R2)        ;INCREMENT SCORE
3584 011366 005737 002640    8$:     TST      OFFCOD    ;POSITIVE OFFSET IS DONE ?
3585 011372 001006          BNE     9$          ;BRANCH IF DONE
3586 011374 005202          INC      R2         ;INCREMENT SCORE BOARD POINTER
3587 011376 012737 000001 002640  MOV      #1,OFFCOD  ;SET POSITIVE OFFSET FLAG
3588 011404 000137 011270    JMP      4$          ;POSITIVE OFFSET TEST
3589 011410 105260 000011    9$:     INCB     STRK(R0) ;INCREMENT TO NEXT SURFACE
3590 011414 005202          INC      R2         ;ADVANCE SCORE BOARD POINTER
3591 011416 122760 000005 000011  CMPB     #5,STRK(R0) ;ALL FIVE SURFACES ARE DONE ?
3592 011424 101404          BLOS    10$         ;BRANCH IF ALL DONE
3593 011426 005037 002640    CLR      OFFCOD     ;RESET OFFSET DIRECTION
3594 011432 000137 011270    JMP      4$          ;TRY THE NEXT SURFACE
3595 011436 005060 000010    10$:   CLR      $SEC(R0) ;SURFACE 0, SECTOR 0
3596 011442 012702 002546    MOV      #SELF0,R2 ;RESET SCORE BOARD
3597 011446 062760 000200 000012  ADD      #128,$CYL(R0) ;ADVANCE TO NEXT ZONE
3598 011454 022760 001440 000012  CMP      #800,$CYL(R0) ;ALL 7 ZONES ARE DONE ?
3599 011462 103404          BLO     11$         ;BRANCH IF ALL DONE
3600 011464 005037 002640    CLR      OFFCOD     ;RESET OFFSET FLAG
3601 011470 000137 011270    JMP      4$          ;TO NEXT ZONE
3602 011474 000240    11$:   NOP              ;TO NEXT TEST

```

```

;TEST10 TEST 8 READ COMPATIBLE TEST
;CYLINDERS TESTED : $DEVM+112,$DEVM+112+128XN N=1 TO 5
;THIS TEST SELECT ONE CYLINDER FOR EACH LOGICAL DRIVE FROM
;ZONE 1 TO ZONE 6
;$DEVM : LOGICAL DRIVE #
;DRIVE : PHYSICAL DRIVE #

```

```

;*****
†ST10: SCOPE
3614 011476 000004          MOV      #1,$TIMES  ;DO 1 ITERATION
3615 011500 012737 000001 001174  MOV      #10,TSTNM  ;LOAD TEST NUMBER
3616 011506 012737 000010 001336  MOV      #STACK,SP  ;INITIAL THE STACK POINTER
3617 011514 012706 001100          MOV      #RDNO,R2   ;CLEAR THE SCORE BOARD OF READ TEST
3618 011520 012702 002306    1$:     CLR      (R2)+
3619 011524 005022          CMP      #RDP4+16.,R2 ;ALL DONE
3620 011526 022702 002546    BHI     1$          ;BRANCH IF NOT
3621 011532 101374          CLR      OFFCOD     ;SET NEGATIVE OFFSET FLAG
3622 011534 005037 002640    LOOP3: MOV      #FMDPB,R0 ;SET UP DPB BLOCK
3623 011540 012700 037146

```

K06

3624	011544	012760	160000	000004		MOV	#-8192., \$WRDM(RO)	; LOAD THE WORD CTR, FULL TRACK
3625	011552	005060	000010			CLR	\$SEC(RO)	; SURFACE 0 AND SECTOR 0
3626	011556	012760	000171	000002		MOV	\$RDATA, \$COMND(RO)	; LOAD THE READ DATA COMMAND
3627	011564	012760	037262	000006		MOV	\$ENDPGM, \$BUF(RO)	; RESET BUFFER ADDRESS
3628	011572	012760	037166	000014		MOV	\$RM.REG.14(RO)	; ADDRESS TO SAVE ALL RH/RMO3 ADDRESS
3629	011600	113710	001222			MOV	DRIVE,(RO)	; LOAD PHY. DRIVE ADDRESS
3630	011604	013703	001266			MOV	\$DEVN,R3	; LOCATE STARTING CYL
3631	011610	062703	000160			ADD	#112., R3	
3632	011614	010360	000012			MOV	R3, \$CYL(RO)	; STARTING CYL ADDRESS
3633	011620	004037	023620		15:	JSR	RO,RMO3	; CALL THE DRIVE HANDLER
3634	011624	037146				FMTDPB		
3635	011626	000774				BR	15	
3636	011630	005737	037164		25:	TST	FMTDPB+16	; COMMAND DONE ?
3637	011634	001775				BEQ	25	; BRANCH IF NOT
3638	011636	012700	037146			MOV	#FMTDPB,RO	
3639	011642	004737	013264			JSR	PC,PROCÉS	; REPORT IF ANY ERROR
3640	011646	004737	010732			JSR	PC,LABAD	; LOCATE START AND STOP ADDRESS
3641	011652	005760	000016			TST	16(RO)	; ANY ERROR ?
3642	011656	100006				BPL	35	; BRANCH, IF NONE
3643	011660	023737	001360	001356		CMP	CMSEC,STARSC	; ON THE SAME SECTOR ADDRESS
3644	011666	101404				BLOS	45	
3645	011670	005337	001360			DEC	CMSEC	; DECREMENT ONE SECTOR COUNT
3646	011674	004737	010512		35:	JSR	PC,SCORE	; UPDATE THE SCORE
3647	011700	005760	000022		45:	TST	\$RMWC(RO)	; WORD COUNT= 0
3648	011704	001407				BEQ	55	; BRANCH IIF IT IS
3649	011706	116060	000026	000010		MOV	\$RMDA(RO), \$SEC(RO)	; UPDATE THE NEW STARTING SECTOR
3650	011714	016060	000022	000004		MOV	\$RMWC(RO), \$WRDM(RO)	; UPDATE WORD COUNT
3651	011722	000736				BR	15	; CONTINUE
3652	011724	012700	037146		55:	MOV	#FMTDPB,RO	; RESET THE DPB BLOCK
3653	011730	012760	160000	000004		MOV	#-8192., \$WRDM(RO)	; FULL TRACK WORD COUNT
3654	011736	105060	000010			CLRB	\$SEC(RO)	; RESET TO SECTOR 0, TRACK NOT CHANGED
3655	011742	004537	010176		65:	JSR	R5,OFFST	; CALL OFFSET
3656	011746	000440				BR	105	; BRANCH IF OFFSET FAILS
3657	011750	004737	010400			JSR	PC,MAKEUP	; EXECUTE READ DATA IN OFFSET MODE
3658	011754	005737	037164		75:	TST	FMTDPB+16	; OFFSET READ IS DONE ?
3659	011760	001775				BEQ	75	; BRANCH IF NOT
3660	011762	012700	037146			MOV	#FMTDPB,RO	; REPORT IF ANY ERROR
3661	011766	004737	013264			JSR	PC,PROCÉS	
3662	011772	004737	010732			JSR	PC,LABAD	; LOCATE THE START (2,1) STOP ADDRESSES
3663	011776	005760	000016			TST	16(RO)	; ANY ERROR ?
3664	012002	100006				BPL	85	; BRANCH, IF NONE
3665	012004	023737	001360	001356		CMP	CMSEC,STARSC	; START AND STOP SECTOR ADDRESSES IS O.K. ?
3666	012012	101404				BLOS	95	; BRANCH IF NOT
3667	012014	005337	001360			DEC	CMSEC	; END SECTOR IS ERROR SECTOR
3668	012020	004737	010512		85:	JSR	PC,SCORE	; UPDATE THE SCORE
3669	012024	005760	000022		95:	TST	\$RMWC(RO)	; WORD COUNT IS 0
3670	012030	001407				BEQ	105	; BRANCH IF IT IS
3671	012032	116060	000026	000010		MOV	\$RMDA(RO), \$SEC(RO)	; UPDATE SECTOR ADDRESS
3672	012040	016060	000022	000004		MOV	\$RMWC(RO), \$WRDM(RO)	; UPDATE WORD COUNT
3673	012046	000735				BR	65	; LOOPING UNTIL CURRENT TRACK IS DONE
3674	012050	062760	000200	000012	105:	ADD	#128., \$CYL(RO)	; ADJUST CYLINDER TO NEXT ZONE
3675	012056	022760	001377	000012		CMP	#767., \$CYL(RO)	; ALL 6 ZONES ARE DONE ?
3676	012064	103402				BLO	115	; BRANCH IF ALL DONE
3677	012066	000137	011620			JMP	15	
3678	012072	013703	001266		115:	MOV	\$DEVN,R3	; LOCATE STARTING CYLINDER
3679	012076	062703	000160			ADD	#112., R3	

LOG

MAINDEC-11-DZAMI 15:00
DZAMIA.P11 21-JUL-77

RM03 DRIVE COMPATIBILITY TEST MACY11 30(1046) 21-JUL-77 16:51 PAGE 76
GET VALUE FOR SOFTWARE SWITCH REGISTER

SEQ 0075

```

3680 012102 010360 000012      MOV      R3,SCYL(R0)      ;STARTING CYLINDER
3681 012106 105260 000011      INCB    $TRK(R0)         ;TO NEXT SURFACE
3682 012112 122760 000005 000011  CMPB    #5,$TRK(R0)      ;ALL 5 SURFACE ARE DONE
3683 012120 101402          BLOS    12$              ;BRANCH IF ALL DONE
3684 012122 000137 011620      JMP     1$               ;LOOPING UNTIL CURRENT TRACK IS DONE
3685 012126 005737 002640      12$:    TST    OFFCOD      ;OFFSET CODE = POSITIVE ?
3686 012132 001005          BNE     13$              ;IF EQUAL THEN ALL DONE
3687 012134 012737 000001 002640  MOV     #1,OFFCOD        ;SET POSITIVE OFFSET FLAG
3688 012142 000137 011540      JMP     LOOP3
3689 012146 000240      13$:    NOP                ;TO NEXT TEST
3690
3691
3692
3693
3694          ;TEST11 TEST 9
3695          ;REPORT THE TEST SCORES
3696          ;DIRECT THE OPERATOR TO CHANGE PACK AND MOUNT TO OTHER DRIVE
3697
3698          $DEVM : LOGICAL DRIVE #, SHOULD NOT BE UPDATED BEFORE THE REPORT IS COMPLETED.
3699
3700          ;BADSEC: ACCEPTANCE FLAG, BADSEC = 0, ALL DRIVES ARE COMPATIBLE
3701          ;BADSEC = -1, DRIVES ARE NOT COMPATIBLE
3702          ;CMTRK : TRACK (HEAD) NUMBER FOR CONTROLLING THE SCORE TYPING.
3703
3704
3705
3706
3707          ;*****
3708          ;TEST11: SCOPE
3709          MOV     #1,$TIMES      ;DO 1 ITERATION
3710          MOV     #11,$TSTNM     ;LOAD THE TEST NUMBER
3711          MOV     #STACK,$SP     ;LOAD THE STACK POINTER
3712          ;ADJUST THE READ COMPATIBLE TEST SCORE
3713          ;IF THE SELF READ TEST SCORE IS TOO LOW
3714          ;DUMMY SCORE BOARD ADDRESSES
3715          CLR     -(SP)
3716          CLR     -(SP)
3717          MOV     #SELF0+1,-(SP) ;POSITIVE OFFSET READ TEST SCORE ADDRESS
3718          MOV     #RDPO,-(SP)   ;POSITIVE OFFSET TEST SCORE
3719          MOV     #SELF0,R2      ;NEGATIVE OFFSET READ TEST SCORE
3720          MOV     #RDNO,R3      ;NEGATIVE OFFSET READ COMPATIBLE TEST SCORE
3721          1$:    MOV     #5,R1    ;R1= SURFACE (TRACK, NUMBER)
3722          2$:    CMPB    #7,(R2)  ;SELF READ TEST SCORE IS TOO LOW
3723          BLOS    4$              ;BRANCH IF NOT
3724          3$:    MOV     #16.,R5  ;INCREMENT READ COMPATIBLE SCORE FOR ALL 16 DIRVES
3725          ADD    #6,R4           ;ADJUST SCORE BY ADDING 6
3726          MOVB   R4,(R3)+       ;UPDATE SCORE AND POINTS TO NEXT DRIVE
3727          DEC    R5              ;ALL DRIVES ARE UPDATED ?
3728          BNE    3$              ;BRANCH IF NOT
3729          BR     5$
3730          4$:    ADD    #16.,R3  ;ADJUST POINTER OF SCORE BOARD ADDRESS
3731          5$:    ADD    #2,R2    ;UPDATE THE SELF TEST SCORE ADDRESS
3732          DEC    R1              ;ALL FIVE SURFACES ARE DONE ?
3733          BNE    2$              ;BRANCH IF NOT
3734          MOV    (SP)+,R3        ;GET NEXT PAIR
3735          MOV    (SP)+,R2        ;EXIT THE THEY ARE 0

```

3736	012272	001351				BNE	1\$		
3737									
3738									: SET ACCEPTANCE FLAG, INITIALIZE THE
3739									: TABLE POINTERS AND TRACK NUMBER
3740	012274	005037	001340			CLR	BADSEC		: SET ACCEPTANCE FLAG
3741	012300	005037	001362			CLR	CMTRK		: START FROM TRACK 0
3742									
3743	012304	005001				CLR	R1		: START FROM LOG DRV 0
3744	012306	012702	002046			MOV	#OVWNO, R2		: SCORE BOARD BASE ADDRESS
3745	012312	012703	000001			MOV	#BIT0, R3		: BIT POSITION FOR LOG DRV 0
3746	012316	030337	001776		LOOP4:	BIT	R3, ASNLST		: IS THE LOG DRV UNDER TEST ?
3747	012322	001502				BEQ	LOOPS		: BRANCH IF NOT
3748	012324	005037	001364			CLR	NULINE		: NEW LINE INDICATOR
3749	012330	123701	001266			CMPB	\$DEVN, R1		: SELF SCORE ?
3750	012334	001434				BEQ	SPATH		: BRANCH IF IT IS
3751	012336	122712	000016		KPATH:	CMPB	#14., (R2)		: OVERWRITE NEG OFFSET < 14 ?
3752	012342	101403				BLOS	1\$: BRANCH IF NOT
3753	012344	004537	012766			JSR	R5, PRINT		: REPORT EXCEPTIONS
3754	012350	000001					000001		: COLUMN POSITION ON REPORT
3755	012352	122762	000016	000120	1\$:	CMPB	#14., 80. (R2)		: OVERWRITE POS OFFSET < 14 ?
3756	012360	101403				BLOS	2\$: BRANCH IF NOT
3757	012362	004537	012766			JSR	R5, PRINT		: REPORT EXCEPTIONS
3758	012366	000002					000002		: COLUMN POSITION ON REPORT
3759	012370	122762	000014	000240	2\$:	CMPB	#12., 160. (R2)		: READ NEG OFFSET < 6
3760	012376	101403				BLOS	3\$: BRANCH IF NOT
3761	012400	004537	012766			JSR	R5, PRINT		: REPORT EXCEPTIONS
3762	012404	000003					000003		: COLUMN POSITION ON REPORT
3763	012406	122762	000014	000360	3\$:	CMPB	#12., 240 (R2)		: READ POS OFFSET < 12 ?
3764	012414	101445				BLOS	LOOPS		: BRANCH IF NOT
3765	012416	004537	012766			JSR	R5, PRINT		: REPORT EXECPTIONS
3766	012422	000004					000004		: COLUMN POSITION ON REPORT
3767	012424	000441				BR	LOOPS		: EXIT
3768	012426	122712	000016		SPATH:	CMPB	#14., (R2)		: OVERWRITE NEG OFF < 14
3769	012432	101403				BLOS	1\$: BRANCH IF NOT
3770	012434	004537	012766			JSR	R5, PRINT		: REPORT EXCEPTION
3771	012440	000001					000001		: COLUMN POSITION ON REPORT
3772	012442	122762	000016	000120	1\$:	CMPB	#14., 80. (R2)		: OVERWRITE POS OFFSET < 14
3773	012450	101403				BLOS	2\$: BRANCH IF NOT
3774	012452	004537	012766			JSR	R5, PRINT		: REPORT EXCEPTION
3775	012456	000002					000002		: COLUMN POSITION ON REPORT
3776	012460	013704	001362		2\$:	MOV	CMTRK, R4		: LOCATE THE SELF TEST SCORE
3777	012464	006304				ASL	R4		: WORD INDEX
3778	012466	122764	000006	002546		CMPB	#6, SELFO(R4)		: SELF READ NEG OFFSET < 6 ?
3779	012474	101403				BLOS	3\$: BRANCH IF NOT
3780	012476	004537	012766			JSR	R5, PRINT		
3781	012502	000003					000003		: REPORT EXCEPTIONS
3782	012504	013704	001362		3\$:	MOV	CMTRK, R4		: LOCATE THE SELF TEST SCORE
3783	012510	006304				ASL	R4		: WORD INDEX
3784	012512	122764	000006	002547		CMPB	#6, SELFO+1(R4)		: SELF READ POS OFFSET < 6 ?
3785	012520	101403				BLOS	LOOPS		: BRANCH IF NOT
3786	012522	004537	012766			JSR	R5, PRINT		: REPORT EXCEPTIONS
3787	012526	000004					000004		: COLUMN POSITION FOR REPORT PRINTING
3788	012530	005201			LOOPS:	INC	R1		: INCREASE THE LOGICAL DRIVE #
3789	012532	000241				CLC			: ADJUST THE BIT POSITION
3790	012534	006103				ROL	R3		: POINTS TO NEXT DRIVE
3791	012536	005202				INC	R2		: UPDATE SCORE BOARD BASE ADDRESS


```

3792 012540 022701 000017          CMP      #15.,R1      ;ALL DRIVES ARE CHECK ?
3793 012544 103264          BHS     LOOP4      ;BRANCH IF NOT ALL DONE
3794 012546 005237 001362          INC     CMTRK     ;NEXT SURFACE
3795 012552 012702 002046          MOV     #OVWNO,R2 ;RESET SCORE BOARD BASE ADDRESS
3796 012556 005001          CLR     R1        ;LOGICAL DRIVE START FROM 0
3797 012560 013703 001362          MOV     CMTRK,R3 ;LOCATE THE SCORE BOARD BASE ADDRESS
3798 012564 001404          BEQ    2$        ;BRANCH IF ON SURFACE 0
3799 012566 062702 000020          1$:    ADD     #16.,R2 ;FOR EACH SURFACE,16 BYTES
3800 012572 005303          DEC     R3        ;ALL SURFACE DONE ?
3801 012574 001374          BNE    1$        ;BRANCH IF NOT
3802 012576 012703 000001          2$:    MOV     #BIT0,R3 ;BIT MAP POSITION FOR DRIVE 0
3803
3804
3805
3806
3807 012602 122737 000005 001362          CMPB   #5,C:TRK   ;AT THIS POINT:
3808 012610 101242          BHI    LOOP4     ;R1=0, LOGICAL DRIVE # START FROM 0
3809 012612 005737 001340          TST    BADSEC   ;R2 ADDRESS OF SCORE BOARD BASE ADDRESS
3810 012616 100402          BMI    DISMNT   ;R3=1 BIT MAP INDICATE LOGICAL DRIVE 0
3811 012620 104401 001205          TYPE  ,SCRLF    ;ALL SURFACES ARE DONE ?
3812
3813 012624 104401 001205          TYPE  ,MSG15 ;** ALL DRIVES ARE COMPATIBLE **
3814 012630 012777 013256 010242          DISMNT: TYPE ,SCRLF ;CR-LF
3815 012636 005077 010240          MOV    #IDLEX,ARMVEC ;RESET THE INTERRUPT VECTOR
3816 012642 104401 035323          CLR   ARMVEC+2 ;CLEAR THE INTERRUPT VECTOR
3817 012646 104401 001272          TYPE  ,MSG12   ;UNLOAD AND DISMOUNT MESSAGE
3818 012652 013746 001222          TYPE  ,SCDW2   ;SYSTEM NAME
3819 012656 104403          MOV    DRIVE,-(SP) ;PHYSICAL DRIVE NUMBER
3820 012660          .BYTE 2
3821 012661          .BYTE 0
3822 012662 104401 035341          TYPE  ,MSG13   ;MESSAGE TYPE R<CR> WHEN READY
3823 012666 104411          1$:    RDLIN   ;READ IN ONE LINE
3824 012670 012605          MOV    (SP)+,R5 ;LOCATE THE READ IN LINE
3825 012672 122527 000122          CMPB  (R5)+,#'R ;READY ?
3826 012676 001373          BNE   1$        ;TRY AGAIN IF NOT
3827 012700 105715          TSTB  (R5)     ;TERMINATOR ?
3828 012702 001371          BNE   1$        ;BRANCH IF NOT
3829 012704 005002          DEASG: CLR    R2 ;LOGICAL DRIVE NUMBER
3830 012706 012703 000001          MOV    #BIT0,R3 ;BIT MAP OF ASSIGNED DRIVE
3831 012712 020237 001266          1$:    CMP    R2,$DEV ;IS THE LOGICAL DRIVE UNDER TEST ?
3832 012716 001404          BEQ   2$        ;BRANCH IF IT IS
3833 012720 000241          CLC   ;SHIFT THE BIT MAP FOR
3834 012722 006103          ROL   R3       ;NEXT DRIVE
3835 012724 005202          INC   R2       ;INCREMENT THE LOGICAL DRIVE #
3836 012726 000771          BR    1$       ;LOOPING UNTIL THE LOGICAL DRIVE LOCATED
3837 012730 040337 002002          2$:    BIC   R3,ASSGN2 ;CLEAR THE ASSIGNED BIT
3838 012734 001412          BEQ   XEND2    ;BRANCH IF NO MORE DRIVES
3839 012736 005237 001266          INC   $DEV     ;INCREMENT THE LOGICAL DRIVE #
3840 012742 013702 001266          MOV   $DEV,R2 ;UPDATE SYSTEM BLOCK ADDRESS
3841 012746 006302          ASL   R2
3842 012750 016237 002600 001270          MOV   BLKADR(R2),SCDW1 ;SYSTEM BLOCK ADDRESS
3843 012756 000137 007056          JMP   TST5     ;JUMP TO TEST 5 FOR OTHER DRIVE
3844
3845
3846 012762 000137 017224          XEND2: JMP    $EOP ;END OF PASS
3847

```

3848
3849
3850
3851
3852
3853
3854
3855
3856
3857
3858
3859
3860
3861
3862
3863
3864
3865
3866
3867
3868
3869
3870
3871
3872
3873
3874
3875
3876
3877
3878
3879
3880
3881
3882
3883
3884
3885
3886
3887
3888
3889
3890
3891
3892
3893
3894
3895
3896
3897
3898
3899
3900
3901
3902
3903

012766
012766 010146
012770 010246
012772 010346
012774 010446
012776 005737 001340
013002 100432
013004 104401 001205
013010 104401 035503
013014 104401 001272
013020 013746 001222
013024 104403
013026 002
013027 000
013030 104401 001205
013034 104401 035526
013040 104401 001205
013044 104401 035622
013050 104401 001205
013054 012737 177777 001340
013062 012737 000001 001374
013070 005737 001364
013074 001045
013076 104401 001205
013102 104401 001205
013106 013746 001362
013112 104403
013114 002
013115 000
013116 104401 035725
013122 123701 001266
013126 001005

PRINT ROUTINE
NAME PRINT
PRINT EXCEPTIONS FOR TEST SCORE
PARAMETER USED
NULINE = 0 A NEW LINE TO PRINT
= 1 - 4 COLUMN NUMBER TO PRINT THE EXCEPTION MARK
BADSEC = 0 FIRST EXCEPTION DETECTED
BADSEC = -1 NOT FIRST EXCEPTION (DON'T PRINT THE TITLE)
CALLING SEQ:
JSR R5,PRINT
NUMBER COLUMN NUMBER
RET
R1: LOGICAL DRIVE #
SDEVN: LOGICAL DRIVE UNDER TEST
R3: BIT POSITION OF LOGICAL DRIVE IN R1

PRINT:
MOV R1,-(SP) ;PUSH R1 ON STACK
MOV R2,-(SP) ;PUSH R2 ON STACK
MOV R3,-(SP) ;PUSH R3 ON STACK
MOV R4,-(SP) ;PUSH R4 ON STACK
TST BADSEC ;FIRST EXCEPTION
BNI 1\$;BRANCH IF NOT,DON'T HAVE TO PRINT
TITLE
TYPE ,SCRLF ;CRLF
TYPE ,MSG16 ;SCORES FOR DRIVE --
TYPE ,SCDW2 ;SYSTEM NAME
MOV DRIVE,-(SP) ;TYPE THE PHYSICAL DRIVE #
TYPOS
.BYTE 2
.BYTE 0
TYPE ,SCRLF ;CR-LF
TYPE ,MSG17 ;SUB TITLE 1
TYPE ,SCRLF
TYPE ,MSG18 ;SUB TITLE 2
TYPE ,SCRLF
MOV #-1,BADSEC ;RESET THE ACCEPTANCE FLAG
MOV #1,FAULT ;NOT COMPATIBLE FLAG
TST NULINE ;NEW LINE ?
BNE 5\$;BRANCH IF NOT
TYPE ,SCRLF
TYPE ,SCRLF
MOV CMTRK,-(SP) ;TYPE THE SURFACE NUMBER
TYPOS
.BYTE 2
.BYTE 0
TYPE TAB ;TYPE "TABLE" CHARACTER
CMPB \$DEVN,R1 ;SCORE FOR \$DEVN ITSELF ?
BNE 2\$;BRANCH IF NOT

```

3904 013130 104401 035717 TYPE ,SELFX ;MESSAGE: SELF .
3905 013134 104401 035725 TYPE ,TAB
3906 013140 000420 BR 4$ ;NEXT STEP
3907 013142 006301 2$: ASL R1 ;LOCATE THE SYS HISTORY FILE
3908 013144 016137 002600 013174 MOV BLKADR(R: , 2#3$ ;LOCATE THE SYSTEM NAME AND DRIVE #
3909 013152 006201 ASR R1 ;RESTORE DRIVE #
3910 013154 062737 000014 013174 ADD #SSYSNM, 2#3$ ;LOCATE THE SYSTEM NAME AND DRIVE #
3911 013162 104401 036121 TYPE ,LINSF
3912 013166 104401 036121 TYPE ,LINSF
3913 013172 104401 TYPE
3914 013174 000000 3$: .WORD 0 ;TYPE THE SYSTEM AND DRIVE ADDRESS FOR TYPING MESSAGE
3915 013176 104401 035725 TYPE ,TAB
3916 013202 012737 000001 001364 4$: MOV #1, NULINE ;INDICATE PRINTER STOPS AT COLUMN 1
3917 013210 012504 5$: MOV (R5)+, R4 ;RETRIEVE THE DESIRED COLUMN # FROM CALLING ROUTINE
3918
3919 013212 020437 001364 6$: CMP R4, NULINE ;ON THE RIGHT COLUMN ?
3920 013216 103412 BLO 8$ ;IF LOW NOT PRINT
3921 013220 001405 BEQ 7$ ;BRANCH IF LOCATED
3922 013222 104401 035725 TYPE ,TAB ;ADVANCE TO NEXT COLUMN
3923 013226 005237 001364 INC NULINE ;INCREMENT COLUMN CTR
3924 013232 000767 BR 6$ ;CHECK AGAIN
3925 013234 104401 035727 7$: TYPE ,MARKX ;THE EXCEPTION MARK * 0
3926 013240 005237 001364 INC NULINE ;NEXT COLUMN
3927 013244 8$:
3928 013244 012604 MOV (SP)+, R4 ;;POP STACK INTO R4
3929 013246 012603 MOV (SP)+, R3 ;;POP STACK INTO R3
3930 013250 012602 MOV (SP)+, R2 ;;POP STACK INTO R2
3931 013252 012601 MOV (SP)+, R1 ;;POP STACK INTO R1
3932 013254 000205 RTS R5 ;EXIT
3933
3934
3935
3936 013256 000240 IDLEX: NOP ;RESET ALL RH VECTOR FOR MOUNT AND DISMOUNT
3937 013260 000240 NOP
3938 013262 000002 RTI ;EXIT
3939 ;PROCESS THE ORDER TERMINATION
3940
3941 013264 111037 001326 PROCES: MOVB (R0), UNIT ;DRIVE NUMBER FOR ANY ERROR MESSAGES
3942 013270 005760 000016 TST STATUS(R0) ;SEE IF DRIVER SIGNALLED AN ERROR
3943 013274 100421 BMI ERPROC ;BR IF ERROR
3944 013276 032760 100000 000020 BIT #BIT15, SRMCS1(R0) ;SEE IF 'SC' SET
3945 013304 001410 BEQ 1$ ;BR IF NOT SET
3946 013306 032760 040000 000020 BIT #BIT14, SRMCS1(R0) ;SEE IF 'TRE' SET
3947 013314 001011 BNE ERPROC ;BR IF SET
3948 013316 032760 040000 000032 BIT #BIT14, SRMDS(R0) ;SEE IF 'ERR' SET
3949 013324 001005 BNE ERPROC ;BR IF SET
3950 013326 004737 014276 1$: JSR PC, CKERR ;NO ERROR, CHECK ERROR BITS ANYWAY
3951 013332 004737 014344 JSR PC, CKBUS ;NO ERROR, CHECK BUS ADDR & WC
3952 013336 000207 2$: RTS PC ;RETURN
3953
3954 ;ORDER TERMINATED WITH AN ERROR - PROCESS THE ERROR
3955
3956 013340 032760 000200 000016 ERPROC: BIT #BIT07, STATUS(R0) ;DONE BIT SET ?
3957 013346 001402 BEQ ERPRC1 ;BR IF ORDER DIDN'T COMPLETE NORMALLY
3958 013350 000137 013516 JMP DONE ;PROCESS ERROR WITH 'DONE' BIT SET
3959

```

```

3960 ;PROCESS ORDER COMPLETION WITH 'ERROR' & 'DONE NOT' BITS
3961
3962 013354 032760 010000 000016 ERPRC1: BIT #BIT12,STATUS(RO) ;SEE IF DRIVE WAS UNSAFE
3963 013362 001025 BNE PUNSAF ;BR IF YES
3964 013364 032760 004000 000016 BIT #BIT11,STATUS(RO) ;PARITY ERROR OCCURRED
3965 013372 001025 BNE UCPAR ;BR IF IT DID
3966 013374 032760 002000 000016 BIT #BIT10,STATUS(RO) ;FATAL PARITY ERROR?
3967 013402 001025 BNE FALPAR ;BR IF THERE IS ONE
3968 013404 032760 001000 000016 BIT #BIT09,STATUS(RO) ;TIMEOUT?
3969 013412 001025 BNE SWTIM ;BR IF YES
3970 013414 032760 040002 000016 BIT #BIT14:BIT01,STATUS(RO) ;DRIVE WENT OFFLINE ?
3971 013422 001025 BNE OFLIN ;BR IF IT DID
3972 013424 032760 000004 000016 BIT #BIT2,STATUS(RO) ;PORT REQUEST TIME OUT ?
3973 013432 001025 BNE PRTIM ;BR IF IT DID
3974 013434 000207 RTS PC ;ERROR. RETURN
3975
3976 ;DRIVE IS PERSISTENTLY UNSAFE
3977
3978 013436 PUNSAF:
3979 013436 104414 032216 DISPLY EM12
3980 013442 000137 014264 JMP DUMP
3981
3982 ;UNCORRECTABLE MASSBUS PARITY ERROR OCCURRED
3983
3984 013446 UCPAR:
3985 013446 104414 032120 DISPLY EM10
3986 013452 000137 014264 JMP DUMP
3987
3988 ;'FATAL' MASSBUS PARITY ERROR OCCURRED
3989
3990 013456 FALPAR:
3991 013456 104414 032163 DISPLY EM11
3992 013462 000137 014264 JMP DUMP
3993
3994 ;SOFTWARE TIMEOUT OCCURRED
3995
3996 013466 SWTIM:
3997 013466 104414 032247 DISPLY EM13
3998 013472 000137 014264 JMP DUMP
3999
4000 ;DRIVE WENT OFFLINE
4001
4002 013476 OFLIN:
4003 013476 104414 032321 DISPLY EM14
4004 013502 000137 014264 JMP DUMP
4005 ;PORT REQUEST TIMEOUT ERROR
4006
4007 013506 PRTIM:
4008 013506 104414 032344 DISPLY EM15
4009 013512 000137 014264 JMP DUMP
4010
4011 ;PROCESS ORDER COMPLETION WITH 'ERROR' & 'DONE' BITS SET
4012
4013 013516 032760 000030 000016 DONE: BIT #BIT04:BIT03,STATUS(RO) ;UNSAFE OCCURRED
4014 013524 001402 BEQ +6 ;BR IF NOT
4015 013526 000137 014254 JMP UNSAF ;REPORT UNSAFE

```

E07

```

4016 013532 032760 040000 000030 BIT #BIT14,SRMCS2(RO) ;IS 'WCE' SET ?
4017 013540 001402 BEQ .+6 ;BRANCH IF NOT SET
4018 013542 000137 JMP WCKER ;WRITE CHECK ERROR
4019 013546 032760 040000 000032 BIT #BIT14,SRMDS(RO) ;CHECK 'ERR'
4020 013554 001002 BNE 1$ ;BR IF SET
4021 013556 000137 JMP TRFER ;PROCESS 'TRE'
4022 013562 032760 000400 000034 1$: BIT #BIT08,SRMER1(RO) ;'HCRC' SET?
4023 013570 001402 BEQ .+6 ;BR IF NOT
4024 013572 000137 JMP HCRCER ;PROCESS 'HCRC'
4025 013576 032760 000020 000034 BIT #BIT04,SRMER1(RO) ;'FMT' SET?
4026 013604 001402 BEQ .+6 ;BR IF NOT SET
4027 013606 000137 JMP CKFMT ;CHECK FORMAT ERROR
4028 013612 032760 000200 000034 BIT #BIT07,SRMER1(RO) ;'HCE' SET?
4029 013620 001402 BEQ .+6 ;BR IF NOT SET
4030 013622 000137 JMP CKHCE ;CHECK 'HCE' ERROR
4031 013626 032760 020000 000034 BIT #BIT13,SRMER1(RO) ;'OPI' SET?
4032 013634 001402 BEQ .+6 ;BR IF NOT SET
4033 013636 000137 JMP OPIER ;REPORT 'OPI'
4034 013642 032760 000010 000034 BIT #BIT3,SRMER1(RO) ;'PAR' SET?
4035 013650 001402 BEQ .+6 ;BR IF NOT SET
4036 013652 000137 JMP PARER ;REPORT 'PAR'
4037 013656 032760 000040 000034 BIT #BIT5,SRMER1(RO) ;'WCF' SET?
4038 013664 001402 BEQ .+6 ;BR IF NOT SET
4039 013666 000137 JMP WCFER ;REPORT 'WCF'
4040 013672 032760 002000 000034 BIT #BIT10,SRMER1(RO) ;'IAE' SET?
4041 013700 001402 BEQ .+6 ;BR IF NOT SET
4042 013702 000137 JMP IAEER ;REPORT 'IAE'
4043 013706 032760 004000 000034 BIT #BIT11,SRMER1(RO) ;'WLE' SET?
4044 013714 001402 BEQ .+6 ;BR IF NOT SET
4045 013716 000137 JMP WLEER ;REPORT 'WLE'
4046 013722 032760 001000 000034 BIT #BIT9,SRMER1(RO) ;'AOE' SET?
4047 013730 001405 BEQ 2$ ;BR IF NOT SET
4048 013732 032760 002000 000032 BIT #BIT10,SRMDS(RO) ;'LST' SET?
4049 013740 001401 BEQ 2$ ;BR IF NOT SET
4050 013742 000207 RTS PC ;'AOE' & 'LST' SET, EXIT
4051 013744 032760 010000 000034 2$: BIT #BIT12,SRMER1(RO) ;SEE IF 'DTE' SET
4052 013752 001402 BEQ .+6 ;BR IF NOT
4053 013754 000137 JMP DTEER ;REPORT 'DTE' ERROR
4054 013760 005760 000034 TST SRMER1(RO) ;SEE IF 'DCK' SET
4055 013764 100002 BPL .+6 ;BR IF NOT
4056 013766 000137 JMP DCKER ;PROCESS 'DCK'
4057 013772 032760 060000 000062 BIT #BIT14:BIT13,SRMER2(RO) ;'SKI' OR 'OCYL' SET
4058 014000 001006 BNE 3$ ;BR IF IT IS
4059 014002 032760 100000 000062 BIT #BIT15,SRMER2(RO) ;BAD SPOT ?
4060 014010 001004 BNE 4$ ;BRANCH IF SO
4061 014012 000137 JMP DRVER ;REPORT ERROR
4062 014016 000137 JMP SKIER ;REPORT DRIVE ERROR
4063 014022 000207 4$: RTS PC ;
4064
4065 ;PROCESS DATA ('DCK') CHECK ERROR
4066
4067 014024 DCKER:
4068 014024 104414 032421 DISPLY EM21
4069 014030 000137 014264 JMP DUMP
4070
4071 ;WRITE CHECK ERROR PROCESSING
    
```

4072					
4073	014034			000034	WCKER:
4074	014034	032760	100000		BIT #BIT15,SRMER1(RO) ;DCK BIT SET ?
4075	014042	001004			BNE 1\$;BRANCH IF SET
4076	014044	104414	032525		DISPLY ,EM23
4077	014050	000137	014264		JMP DUMP
4078	014054	104414	032452		1\$: DISPLY ,EM22
4079	014060	000137	014264		JMP DUMP
4080					
4081					;REPORT 'HCRC' ERROR
4082					
4083	014064				HRCER:
4084	014064	104414	032400		DISPLY ,EM20
4085	014070	000137	014264		JMP DUMP
4086					
4087					;REPORT DRIVE ERROR
4088					
4089	014074				DRVER:
4090	014074	104414	033015		DISPLY ,EM30
4091	014100	000137	014264		JMP DUMP
4092					
4093					;PROCESS FORMAT ('FER') ERROR
4094					
4095	014104				CKFMT:
4096	014104	104414	032604		DISPLY ,EM24
4097	014110	000137	014264		JMP DUMP
4098					
4099					;PROCESS HEADER COMPARE ('HCE') ERROR
4100					
4101	014114				CKHCE:
4102	014114	104414	032652		DISPLY ,EM25
4103	014120	000137	014264		JMP DUMP
4104					;POSSIBLE POSITIONING ERROR
4105					
4106	014124	104414	034153		POSER: DISPLY ,EM51
4107	014130	000137	014264		JMP DUMP
4108					;REPORT 'OPI' ERROR
4109	014134				OPIER:
4110	014134	104414	033047		DISPLY ,EM31
4111	014140	000137	014264		JMP DUMP
4112					;REPORT 'DTE' ERROR
4113					
4114	014144				DTEER:
4115	014144	104414	033112		DISPLY ,EM32
4116	014150	000137	014264		JMP DUMP
4117					;REPORT 'PAR' ERROR
4118					
4119	014154				PARER:
4120	014154	104414	033145		DISPLY ,EM33
4121	014160	000137	014264		JMP DUMP
4122					;REPORT 'IAE' ERROR
4123					
4124	014164				IAEER:
4125	014164	104414	033264		DISPLY ,EM35
4126	014170	000137	014264		JMP DUMP
4127					

```

4128 ;REPORT WLE ERROR
4129
4130 014174 WLEER:
4131 014174 104414 033322 DISPLY EM36
4132 014200 000137 014264 JMP DUMP
4133 ;REPORT FORMAT ERROR
4134
4135 014204 FMTER:
4136 014204 104414 032733 DISPLY EM26
4137 014210 000137 014264 JMP DUMP
4138 ;REPORT HEADER COMPARE ERROR
4139
4140 014214 HCEER: DISPLY EM27
4141 014220 000137 014264 JMP DUMP
4142
4143 ;PROCESS CONTROL/INTERFACE TRANSFER ERROR
4144
4145 014224 TRFER:
4146 014224 104414 033435 DISPLY EM40
4147 014230 000137 014264 JMP DUMP
4148
4149 ;PROCESS 'SKI' OR 'OCYL'
4150
4151 014234 SKIER:
4152 014234 104414 034115 DISPLY EMS0
4153 014240 000137 014264 JMP DUMP
4154 ;REPORT WRITE CLOCK FAILURE
4155
4156 014244 WCFER:
4157 014244 104414 033222 DISPLY EM34
4158 014250 000137 014264 JMP DUMP
4159
4160 ;REPORT DRIVE UNSAFE ERROR
4161
4162 014254 UNSAF:
4163 014254 104414 034216 DISPLY EM60
4164 014260 000137 014264 JMP DUMP
4165
4166
4167 014264 DUMP:
4168 014264 104007 ERROR 7
4169 014266 104010 ERROR 10
4170 014270 104011 ERROR 11
4171 014272 104012 ERROR 12
4172 014274 000207 RTS PC
4173
4174
4175 ;CHECK ERROR BITS IN THE RH11 AND RMO3 REGSTERS
4176
4177 014276 032760 060000 000020 CKERR: BIT #60000,SRMCS1(RO) ;SEE IF 'TRE' OR 'MCPE'
4178 014304 001012 BNE 1$ ;YES
4179 014306 032760 177400 000030 BIT #177400,SRMCS2(RO) ;ERROR BITS IN CS2 /
4180 014314 001006 BNE 1$ ;YES
4181 014316 005760 000034 TST SRMER1(RO) ;ANY ERROR IN ER1
4182 014322 001003 BNE 1$ ;YES
4183 014324 005760 000062 TST SRMER2(RO) ;ANY ERROR IN ER2
    
```

H07

```

4184 014330 001404          BEQ      2$          ;BRANCH IF NO ERROR
4185 014332 104414 033671  1$:  DISPLY  ,EM44
4186 014336 000137 014264  JMP      DUMP
4187 014342 000207          RTS      PC          ;TYPE ALL REGISTERS
4188
4189          ;CHECK BUS ADDRESS REGISTER AND WORD COUNT REGISTER
4190
4191 014344 005760 000022  CKBUS: TST      $RMWC(RO) ;WORD COUNT = 0
4192 014350 001011          BNE      1$          ;NO
4193 014352 016046 000004  MOV      $WRDM(RO),-(SP) ;WORD LENGTH
4194 014356 005416          NEG      (SP)         ;GET THE POSITIVE NUMBER OF WORD COUNT
4195 014360 006316          ASL      (SP)         ;BYTE COUNT
4196 014362 066016 000006  ADD      $BUF(RO),(SP)
4197 014366 022660 000024  CMP      (SP)+,$RMB A(RO)
4198 014372 001404          BEQ      2$
4199 014374 104414 033477  1$:  DISPLY  ,EM41
4200 014400 000137 014264  JMP      DUMP          ;TYPE ALL REGISTERS
4201 014404 000207          RTS      PC
4202          ;ROUTINE TO DISPLAY THE SECTOR WHICH GAVE THE HARD ERROR
4203
4204 014406 104401 001205  PRTBAD: TYPE    , $CR LF
4205 014412 104401 036351  TYPE    , MSG19
4206 014416 104401 001205  TYPE    , $CR LF
4207 014422 016001 000024  MOV      $RMB A(RO),R1 ;PUT THE END ADDRESS INTO R1
4208 014426 016046 000004  MOV      $WRDM(RO),-(SP) ;FIND THE BEGINNING OF THE SECTOR
4209 014432 005416          NEG      (SP)         ;GET THE POSITIVE NUMBER OF WORD COUNT
4210 014434 066016 000022  ADD      $RMWC(RO),(SP) ;SUBTRACT THE WORDS NOT TRANSFERED
4211 014440 005046          CLR      -(SP)        ;MAKE THE UPPER DIVIDEND 0
4212 014442 012746 000400  MOV      #256,-(SP) ;DIVIDE THE WORDS TRANSFERED BY THE SECTOR SIZE
4213 014446 004737 015472  JSR      PC,LINKDV    ;DIVIDE
4214 014452 005716          TST      (SP)        ;REMAINDER = 0 ?
4215 014454 001403          BEQ      1$          ;BR IF IT IS - COMPLETE SECTOR TRANSFERED
4216 014456 006316          ASL      (SP)         ;CONVERT THE RESIDUAL SECTOR SIZE INTO BYTE COUNT
4217 014460 161601          SUB      (SP),R1     ;SUBTRACT IT FROM THE END ADDRESS
4218 014462 000402          BR      2$          ;FINISH THE SIZING
4219 014464 162701 001000  1$:  SUB      #1000,R1   ;SUBTRACT FULL SECTOR SIZE FROM END ADDR
4220 014470 062706 000004  2$:  ADD      #4,SP     ;RESTORE THE STACK POINTER
4221 014474 012702 000007  3$:  MOV      #7,R2     ;R2 CONTAINS THE WORDS/LINE COUNT
4222 014500 010146          MOV      R1,-(SP)    ;PUT THE ADDRESS ON THE STACK
4223 014502 004737 014666  JSR      PC,LIN OCT  ;TYPE THE ADDRESS
4224 014506 020160 000024  4$:  CMP      R1,$RMB A(RO) ;PRINTED ALL THE SECTOR ?
4225 014512 001412          BEQ      5$          ;BR IF ALL PRINTED
4226 014514 104414 036121  DISPLY  ,LINS P      ;SPACES
4227 014520 012146          MOV      (R1)+,-(SP) ;PUT THE DATA ON THE STACK
4228 014522 004737 014666  JSR      PC,LIN OCT  ;TYPE THE DATA
4229 014526 005302          DEC      R2          ;DECREMENT THE HORIZONTAL COUNT
4230 014530 001366          BNE      4$          ;BR IF NOT AT THE END OF THE LINE
4231 014532 104414 001205  DISPLY  , $CR LF
4232 014536 000756          BR      3$          ;RESTORE THE WORDS/LINE COUNT
4233 014540 104414 001205  5$:  DISPLY  , $CR LF
4234 014544 000207          6$:  RTS      PC
4235
4236
4237
4238 014546 104412          FILBUF: SAVREG
4239 014550 016001 000006  MOV      $BUF(RO),R1 ;SAVE THE REGISTERS
                                ;BUFFER ADDRESS

```



```

4240 014554 016002 000004      MOV      SWDM(R0),R2      ; POSITIVE WORD COUNT
4241 014560 005402              NEG      R2              ;
4242 014562 012705 002642      MOV      #STNDAT,R5     ; PATTERN ADDRESS
4243 014566 012703 000020      MOV      #20,R3        ; PATTERN COUNT
4244 014572 012521      3$:  MOV      (R5)+,(R1)+  ; MOVE THE PATTERN INTO THE BUFFER
4245 014574 005302              DEC      R2              ; DECREMENT THE WORD COUNT
4246 014576 003407              BLE      4$              ; BR IF DONE (WORD COUNT = 0)
4247 014600 005303              DEC      R3              ; DECREMENT THE PATTERN COUNT
4248 014602 001373              BNE      3$              ; BR IF MORE PATTERN
4249 014604 012703 000020      MOV      #20,R3        ; RESTORE PATTERN COUNT
4250 014610 012705 002642      MOV      #STNDAT,R5     ; RESTORE THE ADDRESS
4251 014614 000766              BR       3$              ; CONTINUE DISTRIBUTING THE PATTERN
4252 014616 104413      4$:  RESREG              ; RESTORE THE REGISTERS
4253 014620 000207              RTS      PC              ; RETURN
4254
4255      ;*****
4256      .SBTTL  ERROR MESSAGE GENERATION ROUTINES
4257
4258      ;*****
4259
4260      ;PRINT LINE 1 OF ERROR MESSAGE:
4261      ;'HH:MM:SS'
4262
4263
4264 014622 032777 002000 164324  LINE1:  BIT      #SW10,SWR      ; SWITCH 10 SET ?
4265 014630 001402              BEQ      1$              ; BR IF NOT
4266 014632 104401 001200              TYPE     ,SBELL          ; RING THE BELL
4267 014636 032777 020000 164310  1$:  BIT      #SW13,SWR      ; INHIBIT TYPEOUT ?
4268 014644 001403              BEQ      2$              ; BR IF NOT
4269 014646 104414 001205              DISPLY   ,SCRLF          ; CR-LF
4270 014652 000404              BR       3$              ; EXIT
4271 014654 004737 015136      2$:  JSR      PC,STIME      ; TYPE THE TIME
4272 014660 104414 036332              DISPLY   ,LINSPO         ; SPACES
4273 014664 000207      3$:  RTS      PC              ; RETURN & TYPE DESCRIPTION
4274
4275      ;OCTAL TYPEOUT ROUTINE
4276      ;CALL:
4277      ;
4278      ;
4279      ;
4280
4281 014666 016646 000002      LINOCT:  MOV      2(SP),-(SP)  ; PUT NUMBER IN PROPER LOCATION ON STACK
4282 014672 004737 016432              JSR      PC,$$B20        ; CONVERT THE NUMBER TO OCTAL
4283 014676 012637 014712              MOV      (SP)+,1$        ; GET THE ADDRESS OF THE ASCII STRING
4284 014702 062737 000005 014712  ADD      #5.,1$          ; ADDRESS THE LAST 6 ASCII DIGITS
4285 014710 104414              DISPLY   ; TYPE IT
4286 014712 000000      1$:  .WORD    0              ; ADDRESS
4287 014714 012616              MOV      (SP)+,(SP)      ; CORRECT THE STACK
4288 014716 000207              RTS      PC              ; RETURN
4289
4290      ;ROUTINE TO CONVERT THE INPUT NUMBER TO DECIMAL AND TYPE IT WITH
4291      ;LEADING ZERO SUPPRESSION
4292      ;CALL:
4293      ;
4294      ;
4295      ;

```

```

4296
4297 014720 016646 000002 LINDEC: MOV 2(SP),-(SP) ;SET UP STACK FOR CONVERT
4298 014724 004737 016402 JSR PC,$S820 ;CONVERT IT TO DECIMAL
4299 014730 004737 016006 JSR PC,$SUPRS ;TYPE IT (WITH LEADING ZEROS SUPRESSED)
4300 014734 012616 MOV (SP)+,(SP) ;RESTORE STACK POINTER
4301 014736 000207 RTS PC
4302
4303 ;*****
4304
4305 .SBTTL GENERAL SUPPORT SUBROUTINES
4306
4307 ;*****
4308
4309
4310 ;ROUTINE TO CHECK FOR KW11-L OR KW11-P CLOCKS
4311
4312 014740 012737 177777 001314 CKCLK: MOV #-1,CLKFLG ;CLEAR CLOCK AVAILABILITY FLAG
4313 014746 012737 177777 001312 MOV #-1,PCLOCK ;CLEAR KW11-P CLOCK AVAILABILITY FLAG
4314 014754 012737 015034 000004 MOV #CKCLK1,ERRVEC ;SET UP VECTOR FOR CLOCK CHECK
4315 014762 005037 000006 CLR @#ERRVEC+2 ;NEW PSW
4316 014766 005777 164306 TST @SLKCSR ;CHECK FOR KW11-P
4317 014772 005037 001314 CLR CLKFLG ;SET CLOCK AVAILABILITY FLAG
4318 014776 005037 001312 CLR PCLOCK ;SET KW11-P CLOCK FLAG
4319 015002 013701 001304 MOV $LPVEC,R1 ;KW11-P VECTOR ADDRESS
4320 015006 012721 015234 MOV #CLOCK,(R1)+ ;SET UP KW11-P VECTOR
4321 015012 012711 000300 MOV #300,(R1) ;PSW - PRI 6
4322 015016 012777 174575 164256 MOV #-1667,@SLKCSB ;LOAD COUNTER BUFFER WITH 16.67
4323 015024 012777 000131 164246 MOV #131,@SLKCSR ;SET CLOCK - CNT UP, 10US, CONT INT
4324 015032 000435 BR CKCLK3
4325 015034 062706 000004 CKCLK1: ADD #4,SP ;RESTORE THE STACK POINTER
4326 015040 012737 015102 000004 MOV #CKCLK2,@ERRVEC ;CHANGE ERROR VECTOR TO CHECK FOR KW11-L
4327 015046 005777 164234 TST @SLKS ;LOOK FOR KW11-L
4328 015052 005037 001314 CLR CLKFLG ;SET CLOCK FLAG
4329 015056 013701 001310 MOV $LLVEC,R1 ;KW11-L VECTOR ADDRESS
4330 015062 012721 015234 MOV #CLOCK,(R1)+ ;SET UP KW11-L VECTOR
4331 015066 012711 000300 MOV #300,(R1) ;PSW - PRI 6
4332 015072 012777 000100 164206 MOV #100,@SLKS ;SET KW11-L INTERRUPT
4333 015100 000412 BR CKCLK3
4334 015102 062706 000004 CKCLK2: ADD #4,SP ;RESTORE THE STACK POINTER
4335 015106 104401 036130 TYPE ,NEDCLK ;'F OR L CLOCK MUST BE ON SYSTEM'
4336 015112 005737 000042 TST 42 ;UNDER MONITOR CONTROL ?
4337 015116 001400 BEQ 15 ;BR IF NOT
4338 015120 000000 15: HALT ;HALT
4339 015122 000137 003062 JMP START ;TRY AGAIN
4340 015126 012737 000006 000004 CKCLK3: MOV #6,@ERRVEC ;RESTORE THE ERROR VECTOR
4341 015134 000207 RTS PC
4342
4343
4344 ;ROUTINE TO TYPE THE TIME
4345
4346 015136 005737 001314 $TIME: TST CLKFLG ;CLOCK ON THE SYSTEM ?
4347 015142 001033 BNE 15 ;BR IF NOT
4348 015144 104401 001205 TYPE ,$CRLF ;CR-LF
4349 015150 013746 001342 MOV HOUR,-(SP) ;PUT 'HOURS' ON THE STACK
4350 015154 004737 016402 JSR PC,$S820 ;CONVERT TO DECIMAL
4351 015160 004537 015716 JSR RS,REPLZ ;TYPE IT
    
```

K07

MAINDEC-11-DZRM1 AO/DO
DZRMIA.P11 21-JUL-77

RM03 DRIVE COMPATIBILITY TEST
15:44 GENERAL SUPPORT

MACY11 30(1046)
SUBROUTINES

21-JUL-77 16:51 PAGE 88

SEQ 0087

```

4352 015164 000002          .WORD 2          ;TYPE 2 DIGITS
4353 015166 104401 036201  TYPE      ,COLON  ;' '
4354 015172 013746 001344  MOV      MINUTE, -(SP) ;PUT 'MINUTES' ON THE STACK
4355 015176 004737 016402  JSR      PC, $SB2D    ;CONVERT TO DECIMAL
4356 015202 004537 015716  JSR      R5, REPLZ   ;TYPE IT
4357 015206 000002          .WORD 2          ;TYPE 2 DIGITS
4358 015210 104401 036201  TYPE      ,COLON  ;' '
4359 015214 013746 001346  MOV      SECOND, -(SP) ;PUT SECONDS ON THE STACK
4360 015220 004737 016402  JSR      PC, $SB2D    ;CONVERT TO DECIMAL
4361 015224 004537 015716  JSR      R5, REPLZ   ;TYPE IT
4362 015230 000002          .WORD 2          ;TYPE 2 DIGITS
4363 015232 000207          .WORD 2          ;TYPE 2 DIGITS
4364                                     1S:  RTS      PC
4365                                     ;CLOCK HANDLER ROUTINE
4366
4367 015234 005337 001350  CLOCK:  DEC      SIXTEE ;INCREMENT THE 1/60 SECOND COUNTER
4368 015240 001033          BNE      1S         ;BR IF A SECOND NOT COUNTED
4369 015242 013737 001316 001350  MOV      HZ, SIXTEE  ;RESTORE THE VALUE
4370 015250 005237 001346          INC      SECOND     ;COUNT THE SECOND
4371 015254 022737 000074 001346  CMP      #60., SECOND ;AT MAXIMUM ?
4372 015262 001022          BNE      1S         ;BR IF NOT
4373 015264 005037 001346          CLR      SECOND     ;CLEAR THE SECOND'S COUNTER
4374 015270 005237 001344          INC      MINUTE     ;COUNT THE MINUTE
4375 015274 022737 000074 001344  CMP      #60., MINUTE ;AT MAXIMUM ?
4376 015302 001012          BNE      1S         ;BR IF NOT
4377 015304 005037 001344          CLR      MINUTE     ;CLEAR THE MINUTE'S COUNTER
4378 015310 005237 001342          INC      HOUR       ;COUNT THE HOURS
4379 015314 022737 001747 001342  CMP      #999., HOUR ;AT MAXIMUM
4380 015322 103002          BHS     1S         ;BR IF NOT
4381 015324 005037 001342          CLR      HOUR       ;CLEAR THE HOURS
4382 015330 012746 000021          1S:  MOV      #17., -(SP) ;17 MS ON THE STACK
4383 015334 004737 027266          JSR      PC, RPTMR  ;DRIVER TIMER ROUTINE
4384 015340 000002          2S:  RTI
4385
4386                                     ;COMMAND DECODE ROUTINE
4387                                     ;CALL:
4388                                     MOV      #-1, CFLAG ;'CFLAG' IS NORMALLY SET BY THE TTY SERVICE
4389                                     ;ROUTINE IN INTERRUPT MODE
4390                                     JSR      PC, KSR
4391                                     ;SYSTEM BUSY RETURN
4392                                     ;RETURN AFTER KEYBOARD SERVICED
4393
4394 015342 104412          KSR:  SAVREG ;SAVE THE REGISTERS
4395 015344 012737 000200 177776  MOV      #PR4, PS   ;SET PRIORITY TO 4
4396 015352 005037 001334          CLR      CFLAG     ;CLEAR THE 'CONTROL C' FLAG
4397 015356 004737 015136          JSR      PC, $TIME ;TYPE THE TIME
4398 015362 005777 163574          TST     $TKB       ;CLEAR ANY GARBAGE IN THE TTY BUFFER
4399 015366 005737 001334          TST     CFLAG      ;CHECK THE CONTROL C FLAG
4400 015372 001002          BNE     7S         ;EXIT IF 'CONTROL C' ENTERED
4401 015374 000240          NOP ;DUMP CODING FOR LATER USE 3/8/77
4402 015376 000240          NOP
4403 015400 104413          7S:  RESREG ;RESTORE R0 - R5
4404 015402 062716 000002          ADD     #2, (SP)   ;INCREMENT THE RETURN ADDRESS
4405 015406 005777 163550          TST     $TKB       ;CLEAR THE TTY BUFFER
4406 015412 052777 000100 163540  BIS     #BIT06, $TKS ;SET TTY INTERRUPT ENABLE
4407 015420 005037 177776          CLR     PS        ;SET PRIORITY BACK TO ZERO

```

```

4408 015424 000207          RTS      PC          ;RETURN
4409
4410          ;ROUTINE TO CLEAR THE DPB FOR THE ASSIGNED DRIVE
4411          ;CALL:
4412          ;      MOV      #DPB,R0          ;DPB ADDRESS
4413          ;      JSR      PC,CLRDPB
4414          ;
4415          ;
4416          CLRDPB:
4417 015426 010146          MOV      R1,-(SP)          ;; PUSH R1 ON STACK
4418 015426 010346          MOV      R3,-(SP)          ;; PUSH R3 ON STACK
4419 015432 010446          MOV      R4,-(SP)          ;; PUSH R4 ON STACK
4420 015434 010546          MOV      R5,-(SP)          ;; PUSH R5 ON STACK
4421 015436 010004          MOV      R0,R4          ;; GET THE DPB ADDRESS
4422 015440 062704 000002          ADD      #2,R4          ;; ADDRESS OF FIRST LOCN TO BE CLEARED
4423 015444 012703 000020          MOV      #SEMTAB-2,R3    ;; NUMBER OF LOCATIONS TO CLEAR
4424 015450 005024          1$:      CLR      (R4)+          ;; CLEAR THE STORAGE LOCATION
4425 015452 162703 000002          SUB      #2,R3          ;; DECREMENT THE BYTE COUNT
4426 015456 001374          BNE      1$            ;; LOOPING BACK
4427 015460 012605          MOV      (SP)+,R5        ;; POP STACK INTO R5
4428 015462 012604          MOV      (SP)+,R4        ;; POP STACK INTO R4
4429 015464 012603          MOV      (SP)+,R3        ;; POP STACK INTO R3
4430 015466 012601          MOV      (SP)+,R1        ;; POP STACK INTO R1
4431 015470 000207          RTS      PC          ;RETURN
4432
4433 015472 104412          LINKDV: SAVREG          ;STORE R0 - R5
4434 015474 016605 000026          MOV      26(SP),R5        ;DIVISOR
4435 015500 005004          CLR      R4            ;OTHER DIVISOR WORD
4436 015502 016602 000030          MOV      30(SP),R2        ;UPPER DIVIDEND WORD
4437 015506 016603 000032          MOV      32(SP),R3        ;LOWER DIVIDEND WORD
4438 015512 005000          CLR      R0            ;CLEAR OTHER DIVIDEND REGISTERS
4439 015514 005001          CLR      R1
4440 015516 004737 015540          JSR      PC,M.DPID        ;GO TO THE DIVIDE ROUTINE
4441 015522 010166 000030          MOV      R1,30(SP)        ;REMAINDER ON THE STACK
4442 015526 010366 000032          MOV      R3,32(SP)        ;QUOTIENT ON THE STACK
4443 015532 104413          RESREG          ;RESTORE R0 - R5
4444 015534 012616          MOV      (SP)+,(SP)      ;MOVE RETURN UP THE STACK
4445 015536 000207          RTS      PC
4446
4447          ;
4448          ;
4449          ;
4450          ;
4451          ;
4452          ;
4453          ;
4454 015540 012746 000040          M.DPID: MOV      #40,-(SP)      ;COUNTER FOR DIVISION CYCLES
4455 015544 010446          MOV      R4,-(SP)        ;HIGH ORDER
4456 015546 010546          MOV      R5,-(SP)        ;LOW ORDER DIVISOR TO THE STACK
4457 015550 005466 000002          NEG      2(SP)          ;FORM NEGATIVE
4458 015554 005416          NEG      2SP            ;VERSION OF THE DIVISOR
4459 015556 005666 000002          SBC      2(SP)
4460 015562 061601          ADD      2SP,R1
4461 015564 005500          ADC      R0            ;PERFORM THE INITIAL SUBTRACTION
4462 015566 066600 000002          ADD      2(SP),R0
4463 015572 103445          BCS      M.DP50        ;IF CARRY THEN OVERFLOW HAS OCCURRED
    
```

```

4464 015574 005046          CLR      -(SP)          ;THIS IS A LONGER LASTING CARRY BIT
4465 015576 006103      M.DP40: ROL      R3
4466 015600 006102          ROL      R2
4467 015602 006101          ROL      R1
4468 015604 006100          ROL      R0
4469 015606 005716          TST     @SP             ;TEST "CARRY" INDICATOR
4470 015610 001410          BEQ     M.DP41         ;IF NO "CARRY" THEN ADD ELSE SUBTRACT
4471 015612 005016          CLR     @SP             ;CLEAR UP FOR NEXT TIME
4472 015614 066601 000002      ADD     2(SP),R1
4473 015620 005500          ADC     R0             ;ADD -(DIVISOR)
4474 015622 005516          ADC     @SP             ;SET "CARRY"
4475 015624 066600 000004      ADD     4(SP),R0; <- I
4476 015630 000404          BR      M.DP42
4477 015632 060501      M.DP41: ADD     R5,R1
4478 015634 005500          ADC     R0             ;ADD +(DIVISOR)
4479 015636 005516          ADC     @SP             ;SET "CARRY"
4480 015640 060400          ADD     R4,R0; <- I
4481 015642 005516      M.DP42: ADC     @SP
4482 015644 005716          TST     @SP             ;SET "CARRY"
4483 015646 001401          BEQ     .+4; -> I     ;TEST THE UPDATE INDICATOR
4484 015650 005203          INC     R3; <- I     ;IF ZERO FORGET IT
4485 015652 005366 000006      DEC     6(SP); <- I     ;NO CARRY POSSIBLE HERE
4486 015656 003347          BGT     M.DP40         ;DECREMENT COUNTER
4487 015660 006003          ROR     R3             ;BRANCH IF MORE TO DO
4488 015662 103404          BCS     M.DP44
4489 015664 060501          ADD     R5,R1
4490 015666 005500          ADC     R0
4491 015670 060400          ADD     R4,R0
4492 015672 000241          CLC
4493 015674 006103      M.DP44: ROL      R3
4494 015676 062706 000010      ADD     #10,SP         ;ADJUST STACK BY 4 WORDS
4495 015702 000242          CLV
4496 015704 000207          RTS     PC
4497 015706 062706 000006      M.DP50: ADD     #6,SP
4498 015712 000262          SEV
4499 015714 000207          RTS     PC

4500
4501
4502          ;ROUTINE TO REPLACE LEADING ZEROS IN A NUMERIC STRING WITH SPACES
4503          ;CALL
4504          ;      MOV     #ADR, -(SP)          ;ADDRESS OF NUMBER (IN ASCII)
4505          ;      JSR     R5, REPLZ          ;
4506          ;      .WORD  N                    ;'N' IS NUMBER OF DIGITS TO BE TYPED
4507
4508 015716 010046      REPLZ: MOV     R0, -(SP)          ;SAVE R0
4509 015720 012746 000012      MOV     #10, -(SP)        ;MAXIMUM NUMBER OF DIGITS TO BE TYPED
4510 015724 162516          SUB     (R5)+, (SP)        ;SUBTRACT DIGITS TO FORM INDEX
4511 015726 016600 000006      MOV     6(SP), R0         ;ADDRESS OF NUMBER TO R0
4512 015732 122710 000060      1$:   CMPB   #'0', (R0)        ;BYTE EQUAL TO ASCII '0' ?
4513 015736 001004          BNE     2$                ;BR IF NOT
4514 015740 112710 000040      MOVB   #40, (R0)         ;REPLACE THE ZERO WITH A SPACE
4515 015744 005200          INC     R0                ;INCREMENT THE BYTE ADDRESS
4516 015746 000771          BR      1$                ;GO BACK AND LOOK FOR MORE LEADING ZEROS
4517 015750 105710      2$:   TSTB   (R0)                ;SEE IF ZERO BYTE TERMINATOR
4518 015752 001003          BNE     3$                ;BR IF NOT
4519 015754 005300          DEC     R0                ;BACKUP STRING POINTER
    
```

```

4520 015756 112710 000060      MOV      #'0,(R0)      ;PUT A ZERO BACK IN
4521 015762 016637 000006 015776 3$:  MOV      6(SP),4$     ;PUT ADDRESS IN LOCATION FOR TYPEOUT
4522 015770 062637 015776      ADD      (SP)+,4$     ;BEGINNING OF SIGNIFICANT DIGITS
4523 015774 104401      TYPE     ;TYPE THE NUMBER
4524 015776 000000      .WORD   0            ;ADDRESS OF NUMBER
4525 016000 012600      MOV      (SP)+,R0     ;RESTORE R0
4526 016002 012616      MOV      (SP)+,(SP)   ;MOVE RETURN ADDRESS
4527 016004 000205      RTS      R5          ;RETURN
4528
4529 ;TYPE NUMERICAL ASCIZ STRING SUPPRESS LEADING ZEROS
4530
4531 ;CALL
4532 ;
4533 ;      MOV      #NUMADR, -(SP) ;FIRST ADDRESS OF ASCIZ STRING
4534 ;      JSR      PC,$SUPRS
4535 $SUPRS: MOV      R0, -(SP)   ;SAVE R0
4536 016010 016600 000004      MOV      4(SP),R0    ;PICKUP THE POINTER
4537 016014 105710      TSTB    (R0)         ;TERMINATOR ?
4538 016016 001403      BEQ     2$           ;BR IF YES
4539 016020 122720 000060      CMPB    #'0,(R0)+   ;IS THIS AN ASCII '0' ?
4540 016024 001773      BEQ     1$           ;BR IF YES
4541 016026 005300      DEC     R0           ;BACKUP BY '1'
4542 016030 010037 016036      MOV      R0,3$      ;SAVE FOR TYPING
4543 016034 104414      DISPLY  ;GO PRINT
4544 016036 000000      .WORD   0            ;ASCIZ POINTER GOES HERE
4545 016040 012600      MOV      (SP)+,R0    ;RESTORE R0
4546 016042 012616      MOV      (SP)+,(SP) ;RESTORE THE STACK
4547 016044 000207      RTS      PC          ;RETURN
4548
4549 ;ROUTINE TO TYPE AT PRIORITY 4
4550
4551 016046 013746 177776      TYPRI4: MOV      2#PS, -(SP) ;SAVE THE PRESENT STATUS
4552 016052 012737 000200 177776      MOV      #200,2#PS  ;CHANGE THE PRIORITY TO 4
4553 016060 012537 016070      MOV      (R5)+,1$   ;MESSAGE ADDRESS
4554 016064 004737 017722      JSR      PC,$TYPE   ;TYPE THE MESSAGE
4555 016070 000000      .WORD   0            ;MESSAGE ADDRESS GOES HERE
4556 016072 000205      RTS      R5          ;RETURN
4557
4558 ;ROUTINE TO TYPE ERRORS
4559 ;CALL
4560 ;      DISPLY  ;MUST DEFINED IN 'TRAP' TABLE
4561 ;      MESADR  ;ADDRESS OF MESSAGE
4562 ;      RETURN
4563
4564 016074 032777 020000 163052 $DSPLY: BIT      #BIT13,2$WR ;INHIBIT ERROR TYPEOUT ?
4565 016102 001002      BNE     1$           ;BR IF YES
4566 016104 000137 017722      JMP     $TYPE        ;TYPE THE MESSAGE
4567 016110 062716 000002      1$:    ADD     #2,(SP) ;INCREMENT THE RETURN
4568 016114 000002      RTI     ;RETURN
4569
4570 ;THIS ROUTINE IS USED TO CHECK IF AN
4571 ;ASCII CHARACTER IS A DIGIT BETWEEN 0 AND 7.
4572 ;CALL
4573 ;      MOV      #ADR,R1 ;ADDRESS OF ASCII CHARACTER
4574 ;      JSR      R5,CK.OCT ;CHECK THE CHARACTER
4575 ;      RETURN1 ;CHARACTER IS NOT BETWEEN 0-7

```

```

4576          ;          RETURN2          ; CHARACTER IS IN R2 AS A
4577          ;                                ; OCTAL DIGIT
4578
4579 016116 121127 000060 CK.OCT: CMPB (R1),#0          ; LESS THAN ZERO?
4580 016122 103407          BLO 1$          ; YES -- BRANCH
4581 016124 121127 000067          CMPB (R1),#7          ; GREATER THAN SEVEN?
4582 016130 101004          BHI 1$          ; YES -- BRANCH
4583 016132 111102          MOVB (R1),R2          ; GET THE CHARACTER
4584 016134 042702 177770          BIC #1C7,R2          ; STRIP AWAY THE ASCII
4585 016140 005725          TST (R5)+          ; ADJUST FOR RETURN
4586 016142 000205          1$: RTS R5          ; RETURN
4587
4588          ; THIS ROUTINE IS USED TO CHECK AN ASCII CHARACTER
4589          ; AND DETERMINE IF IT IS A DIGIT BETWEEN 0 AND 9.
4590          ; CALL
4591          ;          MOV #ADR,R1          ; ADDRESS OF ASCII CHARACTER
4592          ;          JSR R5,CK.DEC          ; CHECK THE CHARACTER
4593          ;          RETURN1          ; NOT BETWEEN 0 AND 9
4594          ;          RETURN2          ; BETWEEN 0 AND 9
4595          ;          ; R2 = DIGIT
4596
4597 016144 121127 000060 CK.DEC: CMPB (R1),#0          ; LESS THAN ZERO?
4598 016150 103407          BLO 1$          ; YES -- BRANCH
4599 016152 121127 000071          CMPB (R1),#9          ; GREATER THAN NINE?
4600 016156 101004          BHI 1$          ; YES -- BRANCH
4601 016160 111102          MOVB (R1),R2          ; GET THE CHARACTER
4602 016162 042702 000060          BIC #0,R2          ; STRIP AWAY THE ASCII
4603 016166 005725          TST (R5)+          ; ADJUST FOR RETURN
4604 016170 000205          1$: RTS R5          ; RETURN
4605
4606          ; THIS ROUTINE WILL CHECK AN ASCII CHARACTER TO
4607          ; DETERMINE WHAT IT IS.
4608          ; CALL
4609          ;          MOV #ADR,R1          ; ADDRESS OF ASCII CHARACTER
4610          ;          JSR R5,CK.CHR          ; CHECK CHARACTER
4611          ;          RETURN ADR1          ; UNKNOWN CHARACTER
4612          ;          RETURN ADR2          ; CARRIAGE RETURN * (R1)=ADR+1
4613          ;          RETURN ADR3          ; COMMA * (R1)=ADR+1
4614          ;          RETURN ADR4          ; PERIOD * (R1)=ADR+1
4615          ;          RETURN ADR5          ; DIGIT BETWEEN 0 AND 7.
4616          ;          RETURN ADR6          ; DIGIT BETWEEN 8 AND 9.
4617          ;          ; R2 = DIGIT * (R1)=ADR+1
4618
4619 016172 105711          CK.CHR: TSTB (R1)          ; "CARRIAGE RETURN"?
4620 016174 001417          BEQ 3$          ; YES -- BRANCH
4621 016176 121127 000054          CMPB (R1),#',          ; "COMMA"?
4622 016202 001413          BEQ 2$          ; YES -- BRANCH
4623 016204 121127 000056          CMPB (R1),#'.          ; "PERIOD"?
4624 016210 001407          BEQ 1$          ; YES -- BRANCH
4625 016212 004537 016144          JSR R5,CK.DEC          ; "DIGIT"?
4626 016216 000410          BR 4$          ; NO -- BRANCH
4627 016220 004537 016116          JSR R5,CK.OCT          ; OCTAL ?
4628 016224 005725          TST (R5)+          ; DIGIT BETWEEN 8-9
4629 016226 005725          TST (R5)+          ; DIGIT BETWEEN 0-7
4630 016230 005725          1$: TST (R5)+          ; PERIOD
4631 016232 005725          2$: TST (R5)+          ; COMMA
    
```

```

4632 016234 005725      3$:   TST      (R5)+      ;CARRIAGE RETURN
4633 016236 005201      INC      R1              ;MOVE POINTER TO NEXT CHARACTER
4634 016240 011505      4$:   MOV      (R5),R5     ;UNKNOWN CHARACTER
4635 016242 000205      RTS      R5              ;RETURN
4636
4637
4638
4639
4640
4641
4642
4643
4644
4645
4646
4647
4648
4649
4650 016244 010446      CK.DIG: MOV     R4,-(SP)      ;SAVE R4
4651 016246 010346      MOV     R3,-(SP)      ;SAVE R3
4652 016250 010246      MOV     R2,-(SP)      ;SAVE THE MAX. SIZE ON THE STACK
4653 016252 005002      CLR     R2              ;START WITH 0
4654 016254 005003      CLR     R3
4655 016256 005004      CLR     R4
4656 016260 004537 016172      JSR     R5,CK.CHR     ;CHECK ONE CHARACTER
4657 016264 016360      6$:
4658 016266 016366      9$:
4659 016270 016360      6$:
4660 016272 016362      7$:
4661 016274 016300      1$:
4662 016276 016300      1$:
4663 016300 062705 000004      1$:   ADD     #4,R5          ;STEP RETURN POINTER PAST "CR" & "PERIOD" RETURNS
4664 016304 006303      2$:   ASL     R3              ;INPUT NUMBER *2
4665 016306 010346      MOV     R3,-(SP)      ;SAVE #2
4666 016310 006303      ASL     R3              ;#4
4667 016312 006303      ASL     R3              ;#8
4668 016314 062603      ADD     (SP)+,R3       ;(*2)+(*8) = #10
4669 016316 060203      ADD     R2,R3          ;UPDATE THE INPUT NUMBER
4670 016320 004537 016172      JSR     R5,CK.CHR     ;CHECK ONE CHARACTER
4671 016324 016364      8$:
4672 016326 016350      5$:
4673 016330 016346      4$:
4674 016332 016340      3$:
4675 016334 016304      2$:
4676 016336 016304      2$:
4677 016340 105711      3$:   TSTB   (R1)           ;DOES A "CR" FOLLOW THE "PERIOD"
4678 016342 001010      BNE     B$              ;BR IF NOT
4679 016344 005724      TST     (R4)+          ;INCREMENT THE RETURN
4680 016346 005724      4$:   TST     (R4)+          ;INCREMENT THE RETURN
4681 016350 005724      5$:   TST     (R4)+          ;INCREMENT THE RETURN
4682 016352 020316      CMP     R3,(SP)        ;CHECK THE MAGNITUDE OF THE NUMBER
4683 016354 101004      BHI     9$              ;BR IF ENTERED NUMBER TOO LARGE
4684 016356 000402      BR      B$              ;BYPASS INCREMENT
4685 016360 005725      6$:   TST     (R5)+          ;INCREMENT RETURN PAST INVALID RETURN
4686 016362 005725      7$:   TST     (R5)+          ;INCREMENT RETURN
4687 016364 060405      8$:   ADD     R4,R5          ;SETUP RETURN POINTER

; THIS ROUTINE CHECKS AN ASCII STRING FOR LEGAL
; CHARACTERS AND FORMS A DECIMAL VALUE BINARY NUMBER IN R2.
; CALL
;     MOV     #ADR,R1      ; ADDRESS OF ASCII STRING
;     MOV     #NUM,R2      ; MAX. MAGNITUDE OF INPUT NUMBER
;     JSR     R5,CK.DIG    ; CHECK DIGITS
;     RETURN  ADR1        ; "CR" ONLY ENTERED -- R2=0
;     RETURN  ADR2        ; "PERIOD" ONLY ENTERED -- R2=0
;     RETURN  ADR3        ; ILLEGAL CHARACTER OR INPUT TOO LARGE -- R2=?
;     RETURN  ADR4        ; "CR" -- R2 = NUMBER
;     RETURN  ADR5        ; "COMMA" -- R2 = NUMBER
;     RETURN  ADR6        ; "PERIOD" -- R2 = NUMBER
    
```



```

4688 016366 010302          95:  MOV    R3,R2          ;ENTERED VALUE
4689 016370 005726          TST    (SP)+          ;CLEAN MAX. SIZE OFF OF STACK
4690 016372 012603          MOV    (SP)+,R3      ;RESTORE R3
4691 016374 012604          MOV    (SP)+,R4      ;RESTORE R4
4692 016376 011505          MOV    (R5),R5       ;GET RETURN ADDRESS
4693 016400 000205          RTS     R5           ;RETURN
4694
4695
4696
4697
4698
4699
4700
4701
4702
4703
4704
4705 016402 016637 000002 016426 $SB20: MOV    2(SP),1$      ;SAVE THE BINARY NUMBER
4706 016410 012746 016426      MOV    #1$,-(SP)     ;SET THE POINTER
4707 016414 004737 022046      JSR    PC,$DB20      ;CALL THE DOUBLE LENGTH CONVERT
4708 016420 012666 000002      MOV    (SP)+,2(SP)   ;PICKUP THE POINTER
4709 01642  000207              RTS     PC           ;RETURN
4710 016426 000000 000000      1$:   .WORD 0,0
4711
4712
4713
4714
4715
4716
4717
4718
4719
4720
4721
4722 016432 016637 000002 016456 $SB20: MOV    2(SP),1$      ;SAVE THE BINARY NUMBER
4723 016440 012746 016456      MOV    #1$,-(SP)     ;SET THE POINTER
4724 016444 004737 022242      JSR    PC,$DB20      ;CALL THE DOUBLE LENGTH CONVERT
4725 016450 012666 000002      MOV    (SP)+,2(SP)   ;PICKUP THE POINTER
4726 016454 000207              RTS     PC           ;RETURN
4727 016456 000000 000000      1$:   .WORD 0,0
4728
4729
4730
4731
4732
4733
4734 016462 012737 016512 000060 $TKINT: MOV    #STKSRV,TKVEC ;SETUP VECTOR
4735 016470 012737 000240 000062      MOV    #PR5,TKVEC+2 ;PRIORITY TO 5
4736 016476 005777 162460      TST    #STKB         ;CLEAR THE BUFFER
4737 016502 012777 000100 162450      MOV    #BIT06,#STKS ;SET INTERRUPT ENABLE
4738 016510 000207              RTS     PC           ;RETURN
4739
4740
4741
4742
4743

```

; THIS ROUTINE WILL CONVERT A 16-BIT UNSIGNED BINARY NUMBER TO AN
 ; UNSIGNED DECIMAL ASCIZ NUMBER.

; CALL
 ; MOV NUMBER, -(SP) ; PUT THE NUMBER ON THE STACK
 ; JSR PC, \$SB20 ; CALL
 ; RETURN ; ADDRESS OF THE 1ST ASCIZ CHAR IS ON THE STACK

; NOTE: THE PROGRAM REQUIRES THIS FORM OF '\$SB20', NOT THE VERSION ON
 ; THE SYSMAC LIBRARY, REV C AND LATER

; THIS ROUTINE WILL CONVERT A 16-BIT UNSIGNED BINARY NUMBER TO AN
 ; UNSIGNED OCTAL ASCIZ NUMBER.

; CALL
 ; MOV NUMBER, -(SP) ; PUT THE NUMBER ON THE STACK
 ; JSR PC, \$SB20 ; CALL
 ; RETURN ; ADDRESS OF THE 1ST ASCIZ CHAR IS ON THE STACK

; NOTE: THE PROGRAM REQUIRES THIS FORM OF '\$SB20', NOT THE VERSION ON
 ; THE SYSMAC LIBRARY, REV C AND LATER

; KEYBOARD INTERRUPT INITIALIZATION ROUTINE

; CALL
 ; JSR PC, \$TKINT
 ; RETURN

; KEYBOARD INTERRUPT SERVICE ROUTINE

; CALL
 ; ENTER VIA INTERRUPT

```

4744 016512 104410          $TKSRV: RDCHR          ; READ THE KEYBOARD
4745 016514 112637 016642  MOVB      (SP)+,5$      ; GET THE CHARACTER
4746 016520 023727 016642 000003  CMP      5$,#3      ; 'CONTROL C' ?
4747 016526 001012          BNE      1$         ; BR IF NOT
4748 016530 104401 001205          TYPE     ,SCRLF      ; CR-LF
4749 016534 104401 017146          TYPE     ,SCNTLC     ; '↑C'
4750 016540 012737 177777 001334  MOV      #-1,CFLAG  ; SET THE 'CONTROL C' FLAG
4751 016546 005077 162406          CLR      2$TKS      ; CLEAR THE TTY INTERRUPT
4752 016552 000432          BR       4$         ; EXIT
4753 016554 023727 001154 000176 1$:  CMP      SWR,#SWREG  ; SOFTWARE SWITCH REGISTER IN USE ?
4754 016562 001024          BNE      3$         ; BR IF NOT
4755 016564 023727 016642 000007  CMP      5$,#7      ; 'CONTROL G' ?
4756 016572 001020          BNE      3$         ; BR IF NOT
4757 016574 104401 001205          TYPE     ,SCRLF      ; CR-LF
4758 016600 104401 021723          TYPE     ,SCNTLG     ; '↑G'
4759 016604 013746 177776          MOV      PS,-(SP)   ; PUT THE STATUS WORD ON THE STACK
4760 016610 012746 016624          MOV      #2$,-(SP) ; RETURN ADDRESS
4761 016614 005077 162340          CLR      2$TKS      ; CLEAR THE TTY INTERRUPT ENABLE
4762 016620 000137 021364          JMP      $GTSWR     ; GET THE SWITCH REGISTER ENTRY
4763 016624 012777 000100 162326 2$:  MOV      #100,2$TKS ; ENABLE TTY KEYBOARD INTERRUPT
4764 016632 000402          BR       4$         ; EXIT
4765 016634 104401 016642          3$:  TYPE     ,5$         ; ECHO THE CHARACTER
4766 016640 000002          4$:  RTI              ; RETURN
4767
4768 016642 000000          5$:  .WORD  0          ; ENTERED CHARACTER
4769
4770          ; THIS ROUTINE WILL INPUT A STRING FROM THE TTY
4771          ; CALL:
4772          ;
4773          ;       ROLIN
4774          ;       RETURN HERE
4775          ;
4776          ; INPUT A STRING FROM THE TTY
4777          ; ADDRESS OF FIRST CHARACTER WILL BE ON THE STACK
4778          ; TERMINATOR WILL BE A BYTE OF ALL 0'S
4779
4776 016644 010346          $RDLIN: MOV      R3,-(SP) ; SAVE R3
4777 016646 005046          CLR      -(SP)     ; CLEAR THE RUBOUT KEY
4778 016650 012703 017122          1$:  MOV      #STTYIN,R3 ; GET ADDRESS
4779 016654 022703 017134          2$:  CMP      #STTYIN+10.,R3 ; BUFFER FULL?
4780 016660 101467          BLOS     4$         ; BR IF YES
4781 016662 104410          RDCHR          ; GO READ ONE CHARACTER FROM THE TTY
4782 016664 112613          MOVB     (SP)+,(R3) ; GET CHARACTER
4783 016666 122713 000177          CMPB     #177,(R3)  ; IS IT A RUBOUT
4784 016672 001022          BNE      5$         ; BR IF NO
4785 016674 005716          TST      (SP)       ; IS THIS THE FIRST RUBOUT?
4786 016676 001007          BNE      6$         ; BR IF NO
4787 016700 112737 000134 017120  MOVB     #' \,9$    ; TYPE A BACK SLASH
4788 016706 104401 017120          TYPE     ,9$
4789 016712 012716 177777          MOV      #-1,(SP)  ; SET THE RUBOUT KEY
4790 016716 005303          6$:  DEC      R3         ; BACKUP BY ONE
4791 016720 020327 017122          CMP      R3,#STTYIN ; STACK EMPTY?
4792 016724 103445          BLO      4$         ; BR IF YES
4793 016726 111337 017120          MOVB     (R3),9$    ; SETUP TO TYPEOUT THE DELETED CHAR.
4794 016732 104401 017120          TYPE     ,9$
4795 016736 000746          BR       2$         ; GO READ ANOTHER CHAR.
4796 016740 005716          5$:  TST      (SP)       ; RUBOUT KEY SET?
4797 016742 001406          BEQ      7$         ; BR IF NO
4798 016744 112737 000134 017120  MOVB     #' \,9$    ; TYPE A BACK SLASH
4799 016752 104401 017120          TYPE     ,9$

```

```

4800 016756 005016          CLR      (SP)          ;CLEAR THE RUBOUT KEY
4801 016760 122713 000025 7$:  CMPB    #25,(R3)      ;IS CHARACTER A CTRL U?
4802 016764 001003          BNE     10$           ;BR IF NO
4803 016766 104401 021716          TYPE   ,SCNTLU       ;TYPE A CONTROL "U"
4804 016772 000726          BR      1$           ;GO START OVER
4805 016774 122713 000003 10$:  CMPB    #3,(R3)      ;IS CHARACTER A CTRL C ?
4806 017000 001006          BNE     8$           ;BR IF NOT
4807 017002 012737 177777 001334  MOV     #-1,CFLAG    ;SET CNTRL C FLAG
4808 017010 104401 017146          TYPE   ,SCNTLC      ;ECHO IT
4809 017014 000427          BR      11$          ;EXIT
4810 017016 122713 000012 8$:  CMPB    #12,(R3)     ;IS CHARACTER A "LF"?
4811 017022 001011          BNE     3$           ;BRANCH IF NO
4812 017024 105013          CLRB   (R3)         ;CLEAR THE CHARACTER
4813 017026 104401 001205          TYPE   ,SCRLF      ;TYPE A "CR" & "LF"
4814 017032 104401 017122          TYPE   ,STTYIN     ;TYPE THE INPUT STRING
4815 017036 000706          BR      2$           ;GO PICKUP ANOTHER CHACTER
4816 017040 104401 001204 4$:  TYPE   ,SQUES       ;TYPE A ''
4817 017044 000701          BR      1$           ;CLEAR THE BUFFER AND LOOP
4818 017046 111337 017120 3$:  MOV     (R3),9$      ;ECHO THE CHARACTER
4819 017052 104401 017120          TYPE   ,9$         ;
4820 017056 122723 000015          CMPB   #15,(R3)+    ;CHECK FOR RETURN
4821 017062 001274          BNE     2$           ;LOOP IF NOT RETURN
4822 017064 105063 177777          CLRB   -1(R3)      ;CLEAR RETURN (THE 15)
4823 017070 104401 001206          TYPE   ,SLF        ;TYPE A LINE FEED
4824 017074 005726          TST    (SP)+        ;CLEAN RUBOUT KEY FROM THE STACK
4825 017076 012603          MOV     (SP)+,R3    ;RESTORE R3
4826 017100 011646          MOV     (SP)-,(SP) ;ADJUST THE STACK AND PUT ADDRESS OF THE
4827 017102 016666 000004 000002  MOV     4(SP),2(SP) ;FIRST ASCII CHARACTER ON IT
4828 017110 012766 017122 000004  MOV     #STTYIN,4(SP)
4829 017116 000002          RTI                    ;RETURN
4830 017120 000          9$:  .BYTE   0            ;STORAGE FOR ASCII CHAR. TO TYPE
4831 017121 000          .BYTE   0            ;TERMINATOR
4832 017122 000024          $TTYIN: .BLKB 20     ;RESERVE 20 BYTES FOR TTY INPUT
4833 017146 041536 005015 000 $CNTLC: .ASCIZ /tC<<CR><LF> ;CONTROL "C"
4834
4835          017154          .EVEN
4836
4837
4838
4839 017154 005737 001374  FINISH: TST    FAULT    ;COMPATIBLE ?
4840 017160 001006          BNE     1$           ;BRANCH IF NOT
4841 017162 104401 001205          TYPE   ,SCRLF      ;
4842 017166 104401 001205          TYPE   ,SCRLF      ;
4843 017172 104401 035442          TYPE   ,MSG15      ;MESSAGE: ALL DRIVE COMPATIBLE
4844 017176 104401 001205 1$:  TYPE   ,SCRLF      ;
4845 017202 104401 001205          TYPE   ,SCRLF      ;
4846 017206 104401 036375          TYPE   ,MSG20      ;
4847 017212 104401 001205          TYPE   ,SCRLF      ;
4848 017216 000000          HALT
4849 017220 000137 000200          JMP     #200        ;BRANCH TO 200 START IF DESIRED
4850
4851          .SBTTL  END OF PASS ROUTINE
4852
4853          ;*****
4854          ;*INCREMENT THE PASS NUMBER ($PASS)
4855          ;*IF SW12=1 INHIBIT TRACE TRAP
    
```

```

4856 ;*IF THERES A MONITOR GO TO IT
4857 ;*IF THERE ISN'T JUMP TO FINISH
4858
4859 SEOP:
4860 017224 000240 NOP
4861 017224 005037 001116 CLR $TSTNM ;: ZERO THE TEST NUMBER
4862 017232 005037 001174 CLR $TIMES ;: ZERO THE NUMBER OF ITERATIONS
4863 017236 005237 001216 INC $PASS ;: INCREMENT THE PASS NUMBER
4864 017242 042737 100000 001216 BIC #100000,$PASS ;: DON'T ALLOW A NEG. NUMBER
4865 017250 005327 DEC (PC)+ ;: LOOP?
4866 017252 000001 SEOPCT: .WORD 1
4867 017254 003022 BGT $DOAGN ;: YES
4868 017256 012737 MOV (PC)+,2(PC)+ ;: RESTORE COUNTER
4869 017260 000001 SENDCT: .WORD 1
4870 017262 017252 SEOPCT
4871 017264 013700 000042 $GET42: MOV 2#42,RO ;: GET MONITOR ADDRESS
4872 017270 001414 BEQ $DOAGN ;: BRANCH IF NO MONITOR
4873 017272 005046 CLR -(SP) ;: INSURE THE "T" BIT IS CLEAR
4874 017274 012746 017302 MOV #SCLR.T,-(SP) ;: SETUP FOR AN RTI OR RTT
4875 017300 000426 BR $RTRN ;: GO DO AN RTI OR RTT TO LOAD THE PSW
4876 ;: WITH A CLEARED "T" BIT
4877 017302 SCLR.T:
4878 017302 013700 000042 MOV 2#42,RO ;: INSURE RO CONTAINS THE MONITORS
4879 017306 001405 BEQ $DOAGN ;: RETURN ADDRESS
4880 017310 000005 RESET ;: CLEAR THE WORLD
4881 017312 004710 SENDAD: JSR PC,(RO) ;: GO TO MONITOR
4882 017314 000240 NOP ;: SAVE ROOM
4883 017316 000240 NOP ;: FOR
4884 017320 000240 NOP ;: ACT11
4885 017322 SDOAGN:
4886 017322 104400 TRAP ;: PUSH OLD PSW AND PC ON STACK
4887 017324 042716 000020 BIC #20,(SP) ;: CLEAR THE "T" BIT
4888 017330 032777 010000 161616 BIT #BIT12,2SWR ;: RUN WITH TRACE TRAP?
4889 017336 001005 BNE 1$ ;: BR IF NO
4890 017340 005137 017364 COM $TBIT ;: IS IT TIME FOR TRACE TRAP
4891 017344 100402 BMI 1$ ;: BR IF NO
4892 017346 052716 000020 BIS #20,(SP) ;: SET TRACE TRAP
4893 017352 012746 017360 1$: MOV #SLOOP,-(SP) ;: JUMP TO START OF TEST
4894 017356 000002 SRTRN: RTI ;: RETURN--THIS IS CHANGED TO
4895 ;: AN "RTT" IF "RTT" IS A LEGAL
4896 ;: INSTRUCTION
4897 017360 SLOOP:
4898 017360 000137 JMP 2(PC)+ ;: RETURN
4899 017362 017154 $RTNAD: .WORD FINISH
4900 017364 000000 $TBIT: .WORD 0 ;: "T" BIT STATE INDICATOR
4901
4902 .SBTTL ERROR HANDLER ROUTINE
4903
4904 ;:*****
4905 ;:THIS ROUTINE WILL INCREMENT THE ERROR FLAG AND THE ERROR COUNT,
4906 ;:SAVE THE ERROR ITEM NUMBER AND THE ADDRESS OF THE ERROR CALL
4907 ;:AND GO TO $ERRTYP ON ERROR
4908 ;:THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
4909 ;:*SW15=1 HALT ON ERROR
4910 ;:*SW13=1 INHIBIT ERROR TYPEOUTS
4911 ;:*SW10=1 BELL ON ERROR
    
```

```

4912 ;*SW09=1      LOOP ON ERROR
4913 ;*CALL
4914 ;*      ERROR  N      ;;ERROR=EMT AND N=ERROR ITEM NUMBER
4915
4916 $ERROR:
4917 017366      104407      CKSWR      ;; TEST FOR CHANGE IN SOFT-SWR
4918 017370      105237      001117      7$:      INCB      $ERFLG      ;; SET THE ERROR FLAG
4919 017374      001775      BEQ      7$      ;; DON'T LET THE FLAG GO TO ZERO
4920 017376      013777      001116      161552      MOV      $STNM, $DISPLAY      ;; DISPLAY TEST NUMBER AND ERROR FLAG
4921 017404      032777      002000      161542      BIT      #BIT10, $SWR      ;; BELL ON ERROR?
4922 017412      001402      BEQ      1$      ;; NO - SKIP
4923 017414      104401      001200      TYPE      $BELL      ;; RING BELL
4924 017420      005237      001126      1$:      INC      $ERTTL      ;; COUNT THE NUMBER OF ERRORS
4925 017424      011637      001132      MOV      (SP), $ERRPC      ;; GET ADDRESS OF ERROR INSTRUCTION
4926 017430      162737      000002      001132      SUB      #2, $ERRPC
4927 017436      117737      161470      001130      MOVB    $ERRPC, $ITEMB      ;; STRIP AND SAVE THE ERROR ITEM CODE
4928 017444      032777      020000      161502      BIT      #BIT13, $SWR      ;; SKIP TYPEOUT IF SET
4929 017452      001004      BNE      20$      ;; SKIP TYPEOUTS
4930 017454      004737      017566      JSR      PC, $ERRTYP      ;; GO TO USER ERROR ROUTINE
4931 017460      104401      001205      TYPE      , $CRLF
4932 017464
4933 017464      122737      000001      001230      20$:      CMPB    #APTENV, $ENV      ;; RUNNING IN APT MODE
4934 017472      001007      BNE      2$      ;; NO SKIP APT ERROR REPORT
4935 017474      113737      001130      017506      MOVB    $ITEMB, 21$      ;; SET ITEM NUMBER AS ERROR NUMBER
4936 017502      004737      020222      JSR      PC, $ATY4      ;; REPORT FATAL ERROR TO APT
4937 017506      000
4938 017507      000      21$:      .BYTE  0
4939 017510      000777      .BYTE  0
4940 017512      005777      161436      22$:      BR      22$      ;; APT ERROR LOOP
4941 017516      100002      2$:      TST    $SWR      ;; HALT ON ERROR
4942 017520      000000      BPL      3$      ;; SKIP IF CONTINUE
4943 017522      104407      HALT      ;; HALT ON ERROR!
4944 017524      032777      001000      161422      3$:      BIT      #BIT09, $SWR      ;; TEST FOR CHANGE IN SOFT-SWR
4945 017532      001402      BEQ      4$      ;; LOOP ON ERROR SWITCH SET?
4946 017534      013716      001124      BR      IF NO
4947 017540      005737      001176      4$:      MOV      $LPERR, (SP)      ;; FUDGE RETURN FOR LOOPING
4948 017544      001402      TST    $ESCAPE      ;; CHECK FOR AN ESCAPE ADDRESS
4949 017546      013716      001176      BEQ      5$      ;; BR IF NONE
4950 017552      MOV      $ESCAPE, (SP)      ;; FUDGE RETURN ADDRESS FOR ESCAPE
4951 017552      022737      017312      000042      5$:      CMP      #SENDAD, #42      ;; ACT-11 AUTO-ACCEPT?
4952 017560      001001      BNE      6$      ;; BRANCH IF NO
4953 017562      000000      HALT      ;; YES
4954 017564
4955 017564      000002      6$:      RTI      ;; RETURN
4956
4957 .SBTTL  ERROR MESSAGE TYPEOUT ROUTINE
4958
4959 ;*****
4960 ;*THIS ROUTINE USES THE "ITEM CONTROL BYTE" ($ITEMB) TO DETERMINE WHICH
4961 ;*ERROR IS TO BE REPORTED. IT THEN OBTAINS, FROM THE "ERROR TABLE" ($ERRTB),
4962 ;*AND REPORTS THE APPROPRIATE INFORMATION CONCERNING THE ERROR.
4963
4964 $ERRTYP:
4965 017566      104401      001205      TYPE      $CRLF      ;; "CARRIAGE RETURN" & "LINE FEED"
4966 017572      010046      MOV      RO, -(SP)      ;; SAVE RO
4967 017574      005000      CLR      RO      ;; PICKUP THE ITEM INDEX

```

```

4968 017576 153700 001130      BISB  2(S)ITEMB,RO
4969 017602 001004      BNE   1S
4970
4971 017604 013746 001132      MOV   SERRPC,-(SP)
4972
4973 017610 104402      TYPOC
4974 017612 000426      BR    6S
4975 017614 005300      1S:  DEC  RO
4976 017616 006300      ASL  RO
4977 017620 006300      ASL  RO
4978 017622 006300      ASL  RO
4979 017624 062700 002742      ADD  SERRTB,RO
4980 017630 012037 017640      MOV  (RO)+,2S
4981 017634 001404      BEQ  3S
4982 017636 104401      TYPE
4983 017640 000000      2S:  .WORD 0
4984 0176 2 104401 001205      TYPE  ,SCLF
4985 017646 012037 017656      3S:  MOV  (RO)+,4S
4986 017652 001404      BEQ  5S
4987 017654 104401      TYPE
4988 017656 000000      4S:  .WORD 0
4989 017660 104401 001205      TYPE  ,SCLF
4990 017664 011000      5S:  MOV  (RO),RO
4991 017666 001004      BNE  7S
4992 017670 012600      6S:  MOV  (SP)+,RO
4993 017672 104401 001205      TYPE  ,SCLF
4994 017676 000207      RTS  PC
4995 017700      7S:
4996 017700 013046      MOV  2(RO)+,-(SP)
4997 017702 104402      TYPOC
4998 017704 005710      TST  (RO)
4999 017706 001770      BEQ  8S
5000 017710 104401 017716      TYPE  ,8S
5001 017714 000771      BR   7S
5002 017716 020040 000      8S:  .ASCIZ / /
5003 017722      .EVEN

```

```

;; IF ITEM NUMBER IS ZERO, JUST
;; TYPE THE PC OF THE ERROR
;; SAVE SERRPC FOR TYPEOUT
;; ERROR ADDRESS
;; GO TYPE--OCTAL ASCII(ALL DIGITS)
;; GET OUT
;; ADJUST THE INDEX SO THAT IT WILL
;; WORK FOR THE ERROR TABLE
;;
;; FORM TABLE POINTER
;; PICKUP "ERROR MESSAGE" POINTER
;; SKIP TYPEOUT IF NO POINTER
;; TYPE THE "ERROR MESSAGE"
;; "ERROR MESSAGE" POINTER GOES HERE
;; "CARRIAGE RETURN" & "LINE FEED"
;; PICKUP "DATA HEADER" POINTER
;; SKIP TYPEOUT IF 0
;; TYPE THE "DATA HEADER"
;; "DATA HEADER" POINTER GOES HERE
;; "CARRIAGE RETURN" & "LINE FEED"
;; PICKUP "DATA TABLE" POINTER
;; GO TYPE THE DATA
;; RESTORE RO
;; "CARRIAGE RETURN" & "LINE FEED"
;; RETURN
;;
;; SAVE 2(RO)+ FOR TYPEOUT
;; GO TYPE--OCTAL ASCII(ALL DIGITS)
;; IS THERE ANOTHER NUMBER?
;; BR IF NO
;; TYPE TWO(2) SPACES
;; LOOP
;; TWO(2) SPACES

```

.SBTTL TYPE ROUTINE

```

5007
5008 *****
5009 *ROUTINE TO TYPE ASCIZ MESSAGE. MESSAGE MUST TERMINATE WITH A 0 BYTE.
5010 *THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED.
5011 *NOTE1:      $NULL CONTAINS THE CHARACTER TO BE USED AS THE FILLER CHARACTER.
5012 *NOTE2:      $FILLS CONTAINS THE NUMBER OF FILLER CHARACTERS REQUIRED.
5013 *NOTE3:      $FILLC CONTAINS THE CHARACTER TO FILL AFTER.
5014 *
5015 *CALL:
5016 *#1) USING A TRAP INSTRUCTION
5017 *      TYPE      ,MESADR      ;;MESADR IS FIRST ADDRESS OF AN ASCIZ STRING
5018 *OR
5019 *      TYPE
5020 *      MESADR
5021 *
5022 017722 105737 001173      $TYPE: TSTB  $TPFLG      ;;IS THERE A TERMINAL?
5023 017726 100002      BPL   1S              ;;BR IF YES

```

```

5024 017730 000000          HALT
5025 017732 000430          BR          3$
5026 017734 010046          1$: MOV      RO, -(SP)
5027 017736 017600 000002  MOV      2(2(SP), RO)
5028 017742 122737 000001 001230  CMPB    #APTENV, $ENV
5029 017750 001011          BNE     62$
5030 017752 132737 000100 001231  BITB    #APTSPool, $ENV
5031 017760 001405          BEQ     62$
5032 017762 010037 017772  MOV      RO, 61$
5033 017766 004737 020212  JSR     PC, $ATY3
5034 017772 000000          .WORD  0
5035 017774 132737 000040 001231 61$: BITB    #APTCsup, $ENV
5036 020002 001003          BNE     60$
5037 020004 112046          2$: MOVB   (RO)+, -(SP)
5038 020006 001005          BNE     4$
5039 020010 005726          TST    (SP)+
5040 020012 012600          60$: MOV    (SP)+, RO
5041 020014 062716 000002 3$: ADD    #2, (SP)
5042 020020 000002          RTI
5043 020022 122716 000011 4$: CMPB   #HT, (SP)
5044 020026 001430          BEQ     8$
5045 020030 122716 000200          CMPB   #CRLF, (SP)
5046 020034 001006          BNE     5$
5047 020036 005726          TST    (SP)+
5048 020040 104401          TYPE
5049 020042 001205          $CRLF
5050 020044 105037 020200          CLRB   $CHARCNT
5051 020050 000755          BR      2$
5052 020052 004737 020134 5$: JSR    PC, $TYPEC
5053 020056 123726 001172 6$: CMPB   $FILLC, (SP)+
5054 020062 001350          BNE     2$
5055 020064 013746 001170          MOV    $NULL, -(SP)
5056
5057 020070 105366 000001 7$: DECB   1(SP)
5058 020074 002770          BLT    6$
5059 020076 004737 020134          JSR    PC, $TYPEC
5060 020102 105337 020200          DECB   $CHARCNT
5061 020106 000770          BR      7$
5062
5063          ;HORIZONTAL TAB PROCESSOR
5064
5065 020110 112716 000040 8$: MOVB   #' (SP)
5066 020114 004737 020134 9$: JSR    PC, $TYPEC
5067 020120 132737 000007 020200  BITB    #7, $CHARCNT
5068 020126 001372          BNE     9$
5069 020130 005726          TST    (SP)+
5070 020132 000724          BR      2$
5071 020134 105777 161024  $TYPEC: TSTB   2$TPS
5072 020140 100375          BPL    $TYPEC
5073 020142 116677 000002 161016  MOVB   2(SP), 2$TPB
5074 020150 122766 000015 000002  CMPB   #CR, 2(SP)
5075 020156 001003          BNE     1$
5076 020160 105037 020200          CLRB   $CHARCNT
5077 020164 000406          BR      $TYPEX
5078 020166 122766 000012 000002 1$: CMPB   #LF, 2(SP)
5079 020174 001402          BEQ    $TYPEX

```

```

; HALT HERE IF NO TERMINAL
; LEAVE
; SAVE RO
; GET ADDRESS OF ASCIZ STRING
; RUNNING IN APT MODE
; NO GO CHECK FOR APT CONSOLE
; SPOOL MESSAGE TO APT
; NO GO CHECK FOR CONSOLE
; SETUP MESSAGE ADDRESS FOR APT
; SPOOL MESSAGE TO APT
; MESSAGE ADDRESS
; APT CONSOLE SUPPRESSED
; YES, SKIP TYPE OUT
; PUSH CHARACTER TO BE TYPED ONTO STACK
; BR IF IT ISN'T THE TERMINATOR
; IF TERMINATOR POP IT OFF THE STACK
; RESTORE RO
; ADJUST RETURN PC
; RETURN
; BRANCH IF <HT>
; BRANCH IF NOT <CRLF>
; POP <CR><LF> EQUIV
; TYPE A CR AND LF
; CLEAR CHARACTER COUNT
; GET NEXT CHARACTER
; GO TYPE THIS CHARACTER
; IS IT TIME FOR FILLER CHARS.?
; IF NO GO GET NEXT CHAR.
; GET # OF FILLER CHARS. NEEDED
; AND THE NULL CHAR.
; DOES A NULL NEED TO BE TYPED?
; BR IF NO--GO POP THE NULL OFF OF STACK
; GO TYPE A NULL
; DO NOT COUNT AS A COUNT
; LOOP

```

```

5080 020176 105227          INCB      (PC)+      ;;COUNT THE CHARACTER
5081 020200 000000          $CHARCNT: .WORD 0      ;;CHARACTER COUNT STORAGE
5082 020202 000207          $TYPEX: RTS      PC
5083
5084
5085          .SBTTL  APT COMMUNICATIONS ROUTINE
5086
5087          ;;*****
5088 020204 112737 000001 020450 $ATY1:  MOVB      #1,$FFLG      ;;TO REPORT FATAL ERROR
5089 020212 112737 000001 020446 $ATY3:  MOVB      #1,$MFLG      ;;TO TYPE A MESSAGE
5090 020220 000403          BR          $ATYC
5091 020222 112737 000001 020450 $ATY4:  MOVB      #1,$FFLG      ;;TO ONLY REPORT FATAL ERROR
5092 020230          $ATYC:
5093 020230 010046          MOV      RD,-(SP)      ;;PUSH RD ON STACK
5094 020232 010146          MOV      R1,-(SP)      ;;PUSH R1 ON STACK
5095 020234 105737 020446          TSTB     $MFLG      ;;SHOULD TYPE A MESSAGE?
5096 020240 001450          BEQ      5$          ;;IF NOT: BR
5097 020242 122737 000001 001230          CMPB     #APTEMV,$ENV      ;;OPERATING UNDER APT?
5098 020250 001031          BNE      3$          ;;IF NOT: BR
5099 020252 132737 000100 001231          BITB     #APTPOOL,$ENVM      ;;SHOULD SPOOL MESSAGES?
5100 020260 001425          BEQ      3$          ;;IF NOT: BR
5101 020262 017600 000004          MOV      #4(SP),RO      ;;GET MESSAGE ADDR.
5102 020266 062766 000002 000004          ADD      #2,4(SP)      ;;BUMP RETURN ADDR.
5103 020274 005737 001210          1$: TST      $MSGTYPE      ;;SEE IF DONE W/ LAST XMISSION?
5104 020300 001375          BNE      1$          ;;IF NOT: WAIT
5105 020302 010037 001224          MOV      RO,$MSGAD      ;;PUT ADDR IN MAILBOX
5106 020306 105720          2$: TSTB     (RO)+      ;;FIND END OF MESSAGE
5107 020310 001376          BNE      2$
5108 020312 163700 001224          SUB      $MSGAD,RO      ;;SUB START OF MESSAGE
5109 020316 006200          ASR      RO          ;;GET MESSAGE LNTH IN WORDS
5110 020320 010037 001226          MOV      RO,$MSGGLT      ;;PUT LENGTH IN MAILBOX
5111 020324 012737 000004 001210          MOV      #4,$MSGTYPE      ;;TELL APT TO TAKE MSG.
5112 020332 000413          BR          5$
5113 020334 017637 000004 020360 3$: MOV      #4(SP),4$      ;;PUT MSG ADDR IN JSR LINKAGE
5114 020342 062766 000002 000004          ADD      #2,4(SP)      ;;BUMP RETURN ADDRESS
5115 020350 013746 177776          MOV      177776,-(SP)      ;;PUSH 177776 ON STACK
5116 020354 004737 017722          JSR      PC,$TYPE      ;;CALL TYPE MACRO
5117 020360 000000          4$: .WORD      0
5118 020362          5$:
5119 020362 105737 020450          10$: TSTB     $FFLG      ;;SHOULD REPORT FATAL ERROR?
5120 020366 001416          BEQ      12$          ;;IF NOT: BR
5121 020370 005737 001230          TST      $ENV          ;;RUNNING UNDER APT?
5122 020374 001413          BEQ      12$          ;;IF NOT: BR
5123 020376 005737 001210          11$: TST      $MSGTYPE      ;;FINISHED LAST MESSAGE?
5124 020402 001375          BNE      11$          ;;IF NOT: WAIT
5125 020404 017637 000004 001212          MOV      #4(SP),$FATAL      ;;GET ERROR #
5126 020412 062766 000002 000004          ADD      #2,4(SP)      ;;BUMP RETURN ADDR.
5127 020420 005237 001210          INC      $MSGTYPE      ;;TELL APT TO TAKE ERROR
5128 020424 105037 020450          12$: CLRB     $FFLG      ;;CLEAR FATAL FLAG
5129 020430 105037 020447          CLRB     $LFLG      ;;CLEAR LOG FLAG
5130 020434 105037 020446          CLRB     $MFLG      ;;CLEAR MESSAGE FLAG
5131 020440 012601          MOV      (SP)+,R1      ;;POP STACK INTO R1
5132 020442 012600          MOV      (SP)+,RO      ;;POP STACK INTO RO
5133 020444 000207          RTS      PC          ;;RETURN
5134 020446          000          $MFLG: .BYTE      0      ;;MESSG. FLAG
5135 020447          000          $LFLG: .BYTE      0      ;;LOG FLAG
    
```



```

5136 020450 000 $FFLG: .BYTE 0 ;;FATAL FLAG
5137 020452 .EVEN
5138 000200 APTSIZE=200
5139 000001 APTENV=001
5140 000100 APTSPool=100
5141 000040 APTCSUP=040
5142
5143 .SBTTL POWER DOWN AND UP ROUTINES
5144
5145 ;;*****
5146 :POWER DOWN ROUTINE
5147 020452 012737 020624 000024 $PWRDN: MOV $SILLUP,@PWRVEC ;;SET FOR FAST UP
5148 020460 012737 000340 000026 MOV #340,@PWRVEC+2 ;;PRIO:7
5149 020466 010046 MOV RO,-(SP) ;;PUSH RO ON STACK
5150 020470 010146 MOV R1,-(SP) ;;PUSH R1 ON STACK
5151 020472 010246 MOV R2,-(SP) ;;PUSH R2 ON STACK
5152 020474 010346 MOV R3,-(SP) ;;PUSH R3 ON STACK
5153 020476 010446 MOV R4,-(SP) ;;PUSH R4 ON STACK
5154 020500 010546 MOV R5,-(SP) ;;PUSH R5 ON STACK
5155 020502 017746 160446 MOV @SWR,-(SP) ;;PUSH @SWR ON STACK
5156 020506 010637 020630 MOV SP,$SAVR6 ;;SAVE SP
5157 020512 012737 020524 000024 MOV $PWRUP,@PWRVEC ;;SET UP VECTOR
5158 020520 000000 HALT
5159 020522 000776 BR .-2 ;;HANG UP
5160
5161 ;;*****
5162 :POWER UP ROUTINE
5163 020524 012737 020624 000024 $PWRUP: MOV $SILLUP,@PWRVEC ;;SET FOR FAST DOWN
5164 020532 013706 020630 000026 MOV $SAVR6,SP ;;GET SP
5165 020536 005037 020630 CLR $SAVR6 ;;WAIT LOOP FOR THE TTY
5166 020542 005237 020630 15: INC $SAVR6 ;;WAIT FOR THE INC
5167 020546 001375 BNE 15 ;;OF WORD
5168 020550 012677 160400 MOV (SP)+,@SWR ;;POP STACK INTO @SWR
5169 020554 012605 MOV (SP)+,R5 ;;POP STACK INTO R5
5170 020556 012604 MOV (SP)+,R4 ;;POP STACK INTO R4
5171 020560 012603 MOV (SP)+,R3 ;;POP STACK INTO R3
5172 020562 012602 MOV (SP)+,R2 ;;POP STACK INTO R2
5173 020564 012601 MOV (SP)+,R1 ;;POP STACK INTO R1
5174 020566 012600 MOV (SP)+,RO ;;POP STACK INTO RO
5175 020570 012737 020452 000024 MOV $PWRDN,@PWRVEC ;;SET UP THE POWER DOWN VECTOR
5176 020576 012737 000340 000026 MOV #340,@PWRVEC+2 ;;PRIO:7
5177 020604 104401 TYPE ;;REPORT THE POWER FAILURE
5178 020606 020632 $PWRMG: .WORD $POWER ;;POWER FAIL MESSAGE POINTER
5179 020610 042766 000020 000002 BIC #20,2(SP) ;;CLEAR "T" BIT
5180 020616 005037 017364 CLR $TBIT ;;CLEAR THE "T" BIT FLAG
5181 020622 000002 RTI
5182 020624 000000 $SILLUP: HALT ;;THE POWER UP SEQUENCE WAS STARTED
5183 020626 000776 BR .-2 ;;BEFORE THE POWER DOWN WAS COMPLETE
5184 020630 000000 $SAVR6: 0 ;;PUT THE SP HERE
5185 020632 005015 047520 042527 $POWER: .ASCIZ <15><12>"POWER"
5186 020640 000122
5187 .EVEN
5188
5189 .SBTTL BINARY TO OCTAL (ASCII) AND TYPE
5190
5191 ;;*****

```

M08

```

5192 ;#THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 6-DIGIT
5193 ;#OCTAL (ASCII) NUMBER AND TYPE IT.
5194 ;#STYPOS---ENTER HERE TO SETUP SUPPRESS ZEROS AND NUMBER OF DIGITS TO TYPE
5195 ;#CALL:
5196 ;#      MOV      NUM,-(SP)      ;;NUMBER TO BE TYPED
5197 ;#      TYPOS   ;;CALL FOR TYPEOUT
5198 ;#      .BYTE   N              ;;N=1 TO 6 FOR NUMBER OF DIGITS TO TYPE
5199 ;#      .BYTE   M              ;;M=1 OR 0
5200 ;#                               ;;1=TYPE LEADING ZEROS
5201 ;#                               ;;0=SUPPRESS LEADING ZEROS
5202 ;#
5203 ;#STYPON----ENTER HERE TO TYPE OUT WITH THE SAME PARAMETERS AS THE LAST
5204 ;#STYPOS OR STYPOC
5205 ;#CALL:
5206 ;#      MOV      NUM,-(SP)      ;;NUMBER TO BE TYPED
5207 ;#      TYPON   ;;CALL FOR TYPEOUT
5208 ;#
5209 ;#STYPOC---ENTER HERE FOR TYPEOUT OF A 16 BIT NUMBER
5210 ;#CALL:
5211 ;#      MOV      NUM,-(SP)      ;;NUMBER TO BE TYPED
5212 ;#      TYPOC   ;;CALL FOR TYPEOUT
5213 ;#
5214 020642 017646 000000 21065 $TYPOS: MOV      2(SP),-(SP)      ;; PICKUP THE MODE
5215 020646 116637 000001 21065 MOVB     1(SP),SOFILL ;; LOAD ZERO FILL SWITCH
5216 020654 112637 021067 21065 MOVB     (SP)+,SOMODE+1 ;; NUMBER OF DIGITS TO TYPE
5217 020660 062716 000002 21065 ADD      #2,(SP)      ;; ADJUST RETURN ADDRESS
5218 020664 000406 21065 BR       $TYPON
5219 020666 112737 000001 021065 $TYPOC: MOVB     #1,SOFILL ;; SET THE ZERO FILL SWITCH
5220 020674 112737 000006 021067 MOVB     #6,SOMODE+1 ;; SET FOR SIX(6) DIGITS
5221 020702 112737 000605 021064 $TYPON: MOVB     #5,SOCNT  ;; SET THE ITERATION COUNT
5222 020710 010346 21067 MOV      R3,-(SP)      ;; SAVE R3
5223 020712 010446 21067 MOV      R4,-(SP)      ;; SAVE R4
5224 020714 010546 21067 MOV      R5,-(SP)      ;; SAVE R5
5225 020716 113704 021067 MOVB     SOMODE+1,R4 ;; GET THE NUMBER OF DIGITS TO TYPE
5226 020722 005404 21067 NEG      R4
5227 020724 062704 000006 21066 ADD      #6,R4      ;; SUBTRACT IT FOR MAX. ALLOWED
5228 020730 110437 021066 MOVB     R4,SOMODE   ;; SAVE IT FOR USE
5229 020734 113704 021065 MOVB     SOFILL,R4   ;; GET THE ZERO FILL SWITCH
5230 020740 016605 000012 21065 MOV      12(SP),R5   ;; PICKUP THE INPUT NUMBER
5231 020744 005003 21065 CLR      R3          ;; CLEAR THE OUTPUT WORD
5232 020746 006105 15:    ROL      R5          ;; ROTATE MSB INTO "C"
5233 020750 000404 21065 BR       3$         ;; GO DO MSB
5234 020752 006105 25:    ROL      R5          ;; FORM THIS DIGIT
5235 020754 006105 21065 ROL      R5
5236 020756 006105 21065 ROL      R5
5237 020760 010503 21065 MOV      R5,R3
5238 020762 006103 35:    ROL      R3          ;; GET LSB OF THIS DIGIT
5239 020764 105337 021066 DECB     SOMODE      ;; TYPE THIS DIGIT?
5240 020770 100016 21066 BPL      7$         ;; BR IF NO
5241 020772 042703 177770 21066 BIC      #177770,R3 ;; GET RID OF JUNK
5242 020776 001002 21066 BNE      4$         ;; TEST FOR 0
5243 021000 005704 21066 TST      R4          ;; SUPPRESS THIS 0?
5244 021002 001403 21066 BEQ      5$         ;; BR IF YES
5245 021004 005204 45:    INC      R4          ;; DON'T SUPPRESS ANYMORE 0'S
5246 021006 052703 000060 21066 BIS      #'0,R3     ;; MAKE THIS DIGIT ASCII
5247 021012 052703 000040 21066 BIS      #' ,R3     ;; MAKE ASCII IF NOT ALREADY
    
```

```

5248 021016 110337 021062          MOVB   R3,B$          ;; SAVE FOR TYPING
5249 021022 104401 021062          TYPE   ,B$           ;; GO TYPE THIS DIGIT
5250 021026 105337 021064 7$:     DECB   $OCNT         ;; COUNT BY 1
5251 021032 003347          BGT    2$           ;; BR IF MORE TO DO
5252 021034 002402          BLT    6$           ;; BR IF DONE
5253 021036 005204          INC    R4           ;; INSURE LAST DIGIT ISN'T A BLANK
5254 021040 000744          BR     2$           ;; GO DO THE LAST DIGIT
5255 021042 012605          6$:     MOV    (SP)+,R5  ;; RESTORE R5
5256 021044 012604          MOV    (SP)+,R4  ;; RESTORE R4
5257 021046 012603          MOV    (SP)+,R3  ;; RESTORE R3
5258 021050 016666 000002 000004  MOV    2(SP),4(SP) ;; SET THE STACK FOR RETURNING
5259 021056 012616          MOV    (SP)+,(SP)
5260 021060 000002          RTI                    ;; RETURN
5261 021062 000          8$:     .BYTE   0          ;; STORAGE FOR ASCII DIGIT
5262 021063 000          .BYTE   0          ;; TERMINATOR FOR TYPE ROUTINE
5263 021064 000          $OCNT: .BYTE   0          ;; OCTAL DIGIT COUNTER
5264 021065 000          $OFILL: .BYTE  0          ;; ZERO FILL SWITCH
5265 021066 000000          $OMODE: .WORD   0          ;; NUMBER OF DIGITS TO TYPE
5266
5267          .SBTTL  CONVERT BINARY TO DECIMAL AND TYPE ROUTINE
5268
5269          ;*****
5270          ;*THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 5-DIGIT
5271          ;*SIGNED DECIMAL (ASCII) NUMBER AND TYPE IT. DEPENDING ON WHETHER THE
5272          ;*NUMBER IS POSITIVE OR NEGATIVE A SPACE OR A MINUS SIGN WILL BE TYPED
5273          ;*BEFORE THE FIRST DIGIT OF THE NUMBER. LEADING ZEROS WILL ALWAYS BE
5274          ;*REPLACED WITH SPACES.
5275          ;*CALL:
5276          ;*     MOV    NUM,-(SP)          ;; PUT THE BINARY NUMBER ON THE STACK
5277          ;*     TYPDS          ;; GO TO THE ROUTINE
5278
5279          $TYPDS:
5280 021070 010046          MOV    R0,-(SP)     ;; PUSH R0 ON STACK
5281 021072 010146          MOV    R1,-(SP)     ;; PUSH R1 ON STACK
5282 021074 010246          MOV    R2,-(SP)     ;; PUSH R2 ON STACK
5283 021076 010346          MOV    R3,-(SP)     ;; PUSH R3 ON STACK
5284 021100 010546          MOV    R5,-(SP)     ;; PUSH R5 ON STACK
5285 021102 012746 020200          MOV    #20,0,-(SP) ;; SET BLANK SWITCH AND SIGN
5286 021106 016605 000020          MOV    20(SP),R5    ;; GET THE INPUT NUMBER
5287 021112 100004          BPL    1$           ;; BR IF INPUT IS POS.
5288 021114 005405          NEG    R5           ;; MAKE THE BINARY NUMBER POS.
5289 021116 112766 000055 000001  MOVB   #'-,1(SP)    ;; MAKE THE ASCII NUMBER NEG.
5290 021124 005000          1$:     CLR    R0           ;; ZERO THE CONSTANTS INDEX
5291 021126 012703 021304          MOV    #$DBLK,R3    ;; SETUP THE OUTPUT POINTER
5292 021132 112723 000040          MOVB   #'',(R3)+    ;; SET THE FIRST CHARACTER TO A BLANK
5293 021136 005002          2$:     CLR    R2           ;; CLEAR THE BCD NUMBER
5294 021140 016001 021274          MOV    $DTBL(R0),R1 ;; GET THE CONSTANT
5295 021144 160105          3$:     SUB    R1,R5     ;; FORM THIS BCD DIGIT
5296 021146 002402          BLT    4$           ;; BR IF DONE
5297 021150 005202          INC    R2           ;; INCREASE THE BCD DIGIT BY 1
5298 021152 000774          BR     3$
5299 021154 060105          4$:     ADD    R1,R5     ;; ADD BACK THE CONSTANT
5300 021156 005702          TST   R2           ;; CHECK IF BCD DIGIT=0
5301 021160 001002          BNE   5$           ;; FALL THROUGH IF 0
5302 021162 105716          TSTB  (SP)         ;; STILL DOING LEADING 0'S?
5303 021164 100407          BMI   7$           ;; BR IF YES
    
```

5304	021166	106316			5\$:	ASLB	(SP)	MSD?
5305	021170	103003				BCC	6\$	BR IF NO
5306	021172	116663	000001	177777		MOVB	1(SP),-1(R3)	YES--SET THE SIGN
5307	021200	052702	000060		6\$:	BIS	#'0,R2	MAKE THE BCD DIGIT ASCII
5308	021204	052702	000040		7\$:	BIS	#' R2	MAKE IT A SPACE IF NOT ALREADY A DIGIT
5309	021210	110223				MOVB	R2,(R3)+	PUT THIS CHARACTER IN THE OUTPUT BUFFER
5310	021212	005720				TST	(R0)+	JUST INCREMENTING
5311	021214	020027	000010			CMP	R0,#10	CHECK THE TABLE INDEX
5312	021220	002746				BLT	2\$	GO DO THE NEXT DIGIT
5313	021222	003002				BGT	8\$	GO TO EXIT
5314	021224	010502				MOV	R5,R2	GET THE LSD
5315	021226	000764				BR	6\$	GO CHANGE TO ASCII
5316	021230	105726			8\$:	TSTB	(SP)+	WAS THE LSD THE FIRST NON-ZERO?
5317	021232	100003				BPL	9\$	BR IF NO
5318	021234	116663	177777	177776		MOVB	-1(SP),-2(R3)	YES--SET THE SIGN FOR TYPING
5319	021242	105013			9\$:	CLRB	(R3)	SET THE TERMINATOR
5320	021244	012605				MOV	(SP)+,R5	POP STACK INTO R5
5321	021246	012603				MOV	(SP)+,R3	POP STACK INTO R3
5322	021250	012602				MOV	(SP)+,R2	POP STACK INTO R2
5323	021252	012601				MOV	(SP)+,R1	POP STACK INTO R1
5324	021254	012600				MOV	(SP)+,R0	POP STACK INTO R0
5325	021256	104401	021304			TYPE	\$DBLK	NOW TYPE THE NUMBER
5326	021262	016666	000002	000004		MOV	2(SP),4(SP)	ADJUST THE STACK
5327	021270	012616				MOV	(SP)+,(SP)	
5328	021272	000002				RTI		;; RETURN TO USER
5329	021274	023420			SOTBL:	10000.		
5330	021276	001750				1000.		
5331	021300	000144				100.		
5332	021302	000012				10.		
5333	021304	000004			\$DBLK:	.BLKW 4		
5334								
5335						.SBTTL	TTY INPUT ROUTINE	
5336								
5337						*****		
5338						.ENABL	LSB	
5339								
5340						*****		
5341						.*SOFTWARE SWITCH REGISTER CHANGE ROUTINE.		
5342						.*ROUTINE IS ENTERED FROM THE TRAP HANDLER, AND WILL		
5343						.*SERVICE THE TEST FOR CHANGE IN SOFTWARE SWITCH REGISTER TRAP CALL		
5344						.*WHEN OPERATING IN TTY FLAG MODE.		
5345	021314	022737	000176	001154	\$CKSWR:	CMP	\$SWREG,\$SWR	IS THE SOFT-SWR SELECTED?
5346	021322	001074				BNE	15\$	BRANCH IF NO
5347	021324	105777	157630			TSTB	\$TKS	CHAR THERE?
5348	021330	100071				BPL	15\$	IF NO, DON'T WAIT AROUND
5349	021332	117746	157624			MOVB	\$TKB,-(SP)	SAVE THE CHAR
5350	021336	042716	177600			BIC	#'C177,(SP)	STRIP-OFF THE ASCII
5351	021342	022726	000007			CMP	#7,(SP)+	IS IT A CONTROL G?
5352	021346	001062				BNE	15\$	NO, RETURN TO USER
5353	021350	123727	001150	000001		CMPB	\$AUTOB,#1	ARE WE RUNNING IN AUTO-MODE?
5354	021356	001456				BEQ	15\$	BRANCH IF YES
5355								
5356	021360	104401	021723			TYPE	,\$CNTLG	ECHO THE CONTROL-G (+G)
5357	021364	104401	021730		\$GTSWR:	TYPE	,\$MSWR	TYPE CURRENT CONTENTS
5358	021370	013746	000176			MOV	\$WREG,-(SP)	SAVE SWREG FOR TYPEOUT
5359	021374	104402				TYPOC		GO TYPE--OCTAL ASCII(ALL DIGITS)

```

5360 021376 104401 021741          TYPE      ,SMNEW      ;; PROMPT FOR NEW SWR
5361 021402 005046          19$: CLR      -(SP)      ;; CLEAR COUNTER
5362 021404 005046          CLR      -(SP)      ;; THE NEW SWR
5363 021406 105777 157546      7$: TSTB   2$TKS      ;; CHAR THERE?
5364 021412 100375          BPL      7$         ;; IF NOT TRY AGAIN
5365
5366 021414 117746 157542          MOVB   2$TKB, -(SP)  ;; PICK UP CHAR
5367 021420 042716 177600          BIC    #1C177, (SP) ;; MAKE IT 7-BIT ASCII
5368
5369
5370
5371 021424 021627 000025      9$: CMP    (SP), #25   ;; IS IT A CONTROL-U?
5372 021430 001005          BNE    10$         ;; BRANCH IF NOT
5373 021432 104401 021716          TYPE   , $CNTLU     ;; YES, ECHO CONTROL-U (↑U)
5374 021436 062706 000006      20$: ADD   #6, SP      ;; IGNORE PREVIOUS INFUT
5375 021442 000757          BR     19$        ;; LET'S TRY IT AGAIN
5376
5377
5378 021444 021627 000015      10$: CMP   (SP), #15   ;; IS IT A <CR>?
5379 021450 001022          BNE   16$         ;; BRANCH IF NO
5380 021452 005766 000004          TST   4(SP)      ;; YES, IS IT THE FIRST CHAR?
5381 021456 001403          BEQ   11$        ;; BRANCH IF YES
5382 021460 016677 000002 157466      MOV    2(SP), 2$SWR ;; SAVE NEW SWR
5383 021466 062706 000006      11$: ADD   #6, SP      ;; CLEAR UP STACK
5384 021472 104401 001205      14$: TYPE   , $CR LF  ;; ECHO <CR> AND <LF>
5385 021476 123727 001151 000001      CMPB  $INTAG, #1   ;; RE-ENABLE TTY KBD INTERRUPTS?
5386 021504 001003          BNE   15$        ;; BRANCH IF NOT
5387 021506 012777 000100 157444      MOV    #100, 2$TKS ;; RE-ENABLE TTY KBD INTERRUPTS
5388 021514 000002          RTI                    ;; RETURN
5389 021516 004737 020134      15$: JSR    PC, $TYPEC  ;; ECHO CHAR
5390 021522 021627 000060      16$: CMP   (SP), #60   ;; CHAR < 0?
5391 021526 002420          BLT   18$        ;; BRANCH IF YES
5392 021530 021627 000067          CMP   (SP), #67   ;; CHAR > ??
5393 021534 003015          BGT   18$        ;; BRANCH IF YES
5394 021536 042726 000060          BIC   #60, (SP)+  ;; STRIP-OFF ASCII
5395 021542 005766 000002          TST   2(SP)      ;; IS THIS THE FIRST CHAR
5396 021546 001403          BEQ   17$        ;; BRANCH IF YES
5397 021550 006316          ASL   (SP)      ;; NO, SHIFT PRESENT
5398 021552 006316          ASL   (SP)      ;; CHAR OVER TO MAKE
5399 021554 006316          ASL   (SP)      ;; ROOM FOR NEW ONE.
5400 021556 005266 000002      17$: INC   2(SP)      ;; KEEP COUNT OF CHAR
5401 021562 056616 177776          BIS   -2(SP), (SP) ;; SET IN NEW CHAR
5402 021566 000707          BR    7$         ;; GET THE NEXT ONE
5403 021570 104401 001204      18$: TYPE   , $QUES   ;; TYPE ?<CR><LF>
5404 021574 000720          BR    20$        ;; SIMULATE CONTROL-U
5405          .DSABL  LSB
5406
5407
5408          ;*****
5409          ;THIS ROUTINE WILL INPUT A SINGLE CHARACTER FROM THE TTY
5410          ;CALL:
5411          ; RDCHR          ;; INPUT A SINGLE CHARACTER FROM THE TTY
5412          ; RETURN HERE  ;; CHARACTER IS ON THE STACK
5413          ;              ;; WITH PARITY BIT STRIPPED OFF
5414          ;
5415

```

5416	021576	011646			\$RDCHR: MOV	(SP), -(SP)	:: PUSH DOWN THE PC
5417	021600	016666	000004	000002	MOV	4(SP), 2(SP)	:: SAVE THE PS
5418	021606	105777	157346		1\$: TSTB	2\$TKS	:: WAIT FOR
5419	021612	100375			BPL	1\$:: A CHARACTER
5420	021614	117766	157342	000004	MOVB	2\$TKB, 4(SP)	:: READ THE TTY
5421	021622	042766	177600	000004	BIC	#1C<177>, 4(SP)	:: GET RID OF JUNK IF ANY
5422	021630	026627	000004	000023	CMF	4(SP), #23	:: IS IT A CONTROL-S?
5423	021636	001013			BNE	3\$:: BRANCH IF NO
5424	021640	105777	157314		2\$: TSTB	2\$TKS	:: WAIT FOR A CHARACTER
5425	021644	100375			BPL	2\$:: LOOP UNTIL ITS THERE
5426	021646	117746	157310		MOVB	2\$TKB, -(SP)	:: GET CHARACTER
5427	021652	042716	177600		BIC	#1C177, (SP)	:: MAKE IT 7-BIT ASCII
5428	021656	022627	000021		CMF	(SP)+, #21	:: IS IT A CONTROL-Q?
5429	021662	001366			BNE	2\$:: IF NOT DISCARD IT
5430	021664	000750			BR	1\$:: YES, RESUME
5431	021666	026627	000004	000140	3\$: CMF	4(SP), #140	:: IS IT UPPER CASE?
5432	021674	002407			BLT	4\$:: BRANCH IF YES
5433	021676	026627	000004	000175	CMF	4(SP), #175	:: IS IT A SPECIAL CHAR?
5434	021704	003003			BGT	4\$:: BRANCH IF YES
5435	021706	042766	000040	000004	BIC	#40, 4(SP)	:: MAKE IT UPPER CASE
5436	021714	000002			4\$: RTI		:: GO BACK TO USER
5437	021716	052536	005015	000	\$CNTLU: .ASCIZ	/1U/<15><12>	:: CONTROL "U"
5438	021723	136	006507	000012	\$CNTLG: .ASCIZ	/1G/<15><12>	:: CONTROL "G"
5439	021730	005015	053523	020122	\$MSWR: .ASCIZ	<15><12>/SWR = /	
5440	021736	020075	000				
5441	021741	040	047040	053505	\$MNEW: .ASCIZ	/ NEW = /	
5442	021746	036440	000040				

.SBTTL SAVE AND RESTORE RO-R5 ROUTINES

```

*****
: *SAVE RO-R5
: *CALL:
: * SAVREG
: *UPON RETURN FROM $SAVREG THE STACK WILL LOOK LIKE:
: *
: *TOP---(+16)
: * +2---(+18)
: * +4---R5
: * +6---R4
: * +8---R3
: * +10---R2
: * +12---R1
: * +14---R0

```

\$SAVREG:

5462	021752				MOV	R0, -(SP)	:: PUSH R0 ON STACK
5463	021752	010046			MOV	R1, -(SP)	:: PUSH R1 ON STACK
5464	021754	010146			MOV	R2, -(SP)	:: PUSH R2 ON STACK
5465	021756	010246			MOV	R3, -(SP)	:: PUSH R3 ON STACK
5466	021760	010346			MOV	R4, -(SP)	:: PUSH R4 ON STACK
5467	021762	010446			MOV	R5, -(SP)	:: PUSH R5 ON STACK
5468	021764	010546			MOV	22(SP), -(SP)	:: SAVE PS OF MAIN FLOW
5469	021766	016646	000022		MOV	22(SP), -(SP)	:: SAVE PC OF MAIN FLOW
5470	021772	016646	000022		MOV	22(SP), -(SP)	:: SAVE PS OF CALL
5471	021776	016646	000022				

```

5472 022002 016646 000022      MOV      22(SP),-(SP)      ;;SAVE PC OF CALL
5473 022006 000002              RTI
5474
5475      ;*RESTORE RO-R5
5476      ;*CALL:
5477      ;*      RESREG
5478      $RESREG:
5479 022010 012666 000022      MOV      (SP)+,22(SP)      ;;RESTORE PC OF CALL
5480 022014 012666 000022      MOV      (SP)+,22(SP)      ;;RESTORE PS OF CALL
5481 022020 012666 000022      MOV      (SP)+,22(SP)      ;;RESTORE PC OF MAIN FLOW
5482 022024 012666 000022      MOV      (SP)+,22(SP)      ;;RESTORE PS OF MAIN FLOW
5483 022030 012605              MOV      (SP)+,R5          ;;POP STACK INTO R5
5484 022032 012604              MOV      (SP)+,R4          ;;POP STACK INTO R4
5485 022034 012603              MOV      (SP)+,R3          ;;POP STACK INTO R3
5486 022036 012602              MOV      (SP)+,R2          ;;POP STACK INTO R2
5487 022040 012601              MOV      (SP)+,R1          ;;POP STACK INTO R1
5488 022042 012600              MOV      (SP)+,R0          ;;POP STACK INTO R0
5489 022044 000002              RTI
5490
5491      .SBTTL  DOUBLE LENGTH BINARY TO DECIMAL ASCII CONVERT ROUTINE
5492
5493      ;*****
5494      ;THIS ROUTINE WILL CONVERT A 32-BIT BINARY NUMBER TO AN UNSIGNED
5495      ;DECIMAL (ASCII) NUMBER. THE SIGN OF THE BINARY NUMBER MUST BE
5496      ;POSITIVE.
5497      ;CALL
5498      ;*      MOV      #PNTR, -(SP)      ;; POINTER TO LOW WORD OF BINARY NUMBER
5499      ;*      JSR      PC, @#$DB2D
5500      ;*      RETURN
5501      ;*
5502      ;*
5503      ;*
5504 022046 104412      $DB2D:  SAVREG      ;; SAVE REGISTERS
5505 022050 016602 000002      MOV      2(SP),R2          ;; PICKUP THE DATA POINTER
5506 022054 012700 022226      MOV      #$DECVL,R0        ;; GET ADDRESS OF "SDECVL" STRING
5507 022060 010066 000002      MOV      R0,2(SP)          ;; PUT ADDRESS OF ASCII STRING ON STACK
5508 022064 012201              MOV      (R2)+,R1          ;; PICKUP THE BINARY NUMBER
5509 022066 012202              MOV      (R2)+,R2
5510 022070 012737 000012 022144      MOV      #10,4$           ;; SET UP TO DO 10 CONVERSIONS
5511 022076 012704 022156      MOV      #$TNPOWER,R4      ;; ADDRESS OF TEN POWER
5512 022102 012705 022160      MOV      #$TNPOWER+2,R5
5513 022106 005003      1$:  CLR      R3              ;; CLEAR PARTIAL
5514 022110 161401      2$:  SUB      (R4),R1          ;; SUBTRACT TEN POWER
5515 022112 005602              SBC      R2
5516 022114 161502              SUB      (R5),R2
5517 022116 002402              BLT      3$
5518 022120 005203              INC      R3              ;; ADD 1 TO PARTIAL
5519 022122 000772              BR       2$              ;; LOOP
5520 022124 062401      3$:  ADD      (R4)+,R1          ;; RESTORE SUBTRACTED VALUE
5521 022126 005502              ADC      R2
5522 022130 062402              ADD      (R4)+,R2
5523 022132 022525              CMP      (R5)+,(R5)+      ;; MOVE TO NEXT TEN POWER
5524 022134 052703 000060      BIS      #'0,R3           ;; CHANGE PARTIAL TO ASCII
5525 022140 110320              MOVB     R3,(R0)+         ;; SAVE IT
5526 022142 005327              DEC      (PC)+           ;; DONE?
5527 022144 000000      4$:  .WORD    0
    
```

```

5528 022146 001357           BNE      1$           ;; BR IF NO
5529 022150 105020           CLRB    (R0)+        ;; TERMINATOR
5530 022152 104413           RESREG                    ;; RESTORE REGISTERS
5531 022154 000207           RTS     PC           ;; RETURN
5532 022156 145000           STNPR: 145000        ;; 1.0E09
5533 022160 035632           35632
5534 022162 160400           160400                ;; 1.0E08
5535 022164 002765           2765
5536 022166 113200           113200                ;; 1.0E07
5537 022170 000230           230
5538 022172 041100           041100                ;; 1.0E06
5539 022174 000017           17
5540 022176 103240           103240                ;; 1.0E05
5541 022200 000001           1
5542 022202 023420           23420                ;; 1.0E04
5543 022204 000000           0
5544 022206 001750           1750                 ;; 1.0E03
5545 022210 000000           0
5546 022212 000144           144                  ;; 1.0E02
5547 022214 000000           0
5548 022216 000012           12                   ;; 1.0E01
5549 022220 000000           0
5550 022222 000001           1                    ;; 1.0E00
5551 022224 000000           0
5552 022226 000014           $DECVL: .BLKB 12.   ;; RESERVE STORAGE FOR ASCIZ STRING
5553
5554 .SBTTL DOUBLE LENGTH BINARY TO OCTAL ASCII CONVERT ROUTINE
5555
5556 ;*****
5557 ;*THIS ROUTINE WILL CONVERT A 32-BIT UNSIGNED BINARY NUMBER TO AN
5558 ;*UNSIGNED OCTAL ASCIZ NUMBER.
5559 ;*CALL
5560 ;*   MOV     #PNTR, -(SP)   ;; POINTER TO LOW WORD OF BINARY NUMBER
5561 ;*   JSR    PC, @#$DB20    ;; CALL THE ROUTINE
5562 ;*   RETURN                ;; THE ADDRESS OF THE FIRST ASCIZ CHAR. IS ON THE STACK
5563
5564
5565 022242 104412           $DB20: SAVREG        ;; SAVE ALL REGISTERS
5566 022244 016601 000002     MOV     2(SP), R1    ;; PICKUP THE POINTER TO LOW WORD
5567 022250 012705 022361     MOV     #SOCTVL+13., R5 ;; POINTER TO DATA TABLE
5568 022254 012704 000014     MOV     #12., R4     ;; DO ELEVEN CHARACTERS
5569 022260 012703 177770     MOV     #1C7, R3     ;; MASK
5570 022264 012100     MOV     (R1)+, R0    ;; LOWER WORD
5571 022266 012101     MOV     (R1)+, R1    ;; HIGH WORD
5572 022270 005002     CLR     R2           ;; TERMINATOR
5573 022272 110245 1$:   MOVB   R2, -(R5)    ;; PUT CHARACTER IN DATA TABLE
5574 022274 010002     MOV     R0, R2      ;; GET THIS DIGIT
5575 022276 005304     DEC     R4           ;; COUNT THIS CHARACTER
5576 022300 003007     BGT    3$           ;; BR IF NOT THE LAST DIGIT
5577 022302 001405     BEQ    2$           ;; BR IF IT IS THE LAST DIGIT
5578 022304 005205     INC     R5           ;; ALL DIGITS DONE-ADJUST POINTER FOR FIRST
5579 022306 010566 000002     MOV     R5, 2(SP)   ;; ASCIZ CHAR. & PUT IT ON THE STACK
5580 022312 104413     RESREG                    ;; RESTORE ALL REGISTERS
5581 022314 000207     RTS     PC           ;; RETURN TO USER
5582 022316 006203 2$:   ASR    R3           ;; POSITION THE MASK FOR THE LAST DIGIT
5583 022320 006001 3$:   ROR    R1           ;; POSITION THE BINARY NUMBER FOR
    
```



```

5584 022322 006000 ROR RO ;; THE NEXT OCTAL DIGIT
5585 022324 006001 ROR R1
5586 022326 006000 ROR RO
5587 022330 006001 ROR R1
5588 022332 006000 ROR RO
5589 022334 040302 BIC R3,R2 ;; MASK OUT ALL JUNK
5590 022336 062702 000060 ADD #'0,R2 ;; MAKE THIS CHAR. ASCII
5591 022342 000753 BR 1$ ;; GO PUT IT IN THE DATA TABLE
5592 022344 000016 $OCTVL: .BLKB 14. ;; RESERVE DATA TABLE
5593
5594 .SBTTL SCOPE HANDLER ROUTINE
5595
5596 ;*****
5597 ;*THIS ROUTINE CONTROLS THE LOOPING OF SUBTESTS. IT WILL INCREMENT
5598 ;*AND LOAD THE TEST NUMBER($TSTNM) INTO THE DISPLAY REG.(DISPLAY<7:0>)
5599 ;*AND LOAD THE ERROR FLAG ($ERFLG) INTO DISPLAY<15:08>
5600 ;*THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
5601 ;*SW14=1 LOOP ON TEST
5602 ;*SW11=1 INHIBIT ITERATIONS
5603 ;*SW09=1 LOOP ON ERROR
5604 ;*SW08=1 LOOP ON TEST IN SWR<7:0>
5605 ;*CALL
5606 ;* SCOPE ;;SCOPE=IOT
5607
5608 $SCOPE:
5609 022362 104407 CKSWR ;; TEST FOR CHANGE IN SOFT-SWR
5610 022364 032777 040000 156562 1$: BIT #BIT14,$SWR ;; LOOP ON PRESENT TEST?
5611 022372 001114 BNE $OVER ;; YES IF SW14=1
5612 ;*****START OF CODE FOR THE XOR TESTER*****
5613 022374 000416 $XTSTR: BR 6$ ;; IF RUNNING ON THE "XOR" TESTER CHANGE
5614 ; THIS INSTRUCTION TO A "NOP" (NOP=240)
5615 022376 013746 000004 MOV @#ERRVEC,-(SP) ;; SAVE THE CONTENTS OF THE ERROR VECTOR
5616 022402 012737 022422 000004 MOV #5$,@#ERRVEC ;; SET FOR TIMEOUT
5617 022410 005737 177060 TST @#177060 ;; TIME OUT ON XOR?
5618 022414 012637 000004 MOV (SP)+,@#ERRVEC ;; RESTORE THE ERROR VECTOR
5619 022420 000463 BR $SVLAD ;; GO TO THE NEXT TEST
5620 022422 022626 5$: CMP (SP)+,(SP)+ ;; CLEAR THE STACK AFTER A TIME OUT
5621 022424 012637 000004 MOV (SP)+,@#ERRVEC ;; RESTORE THE ERROR VECTOR
5622 022430 000423 BR 7$ ;; LOOP ON THE PRESENT TEST
5623 022432
5624 022432 032777 000400 156514 6$;*****END OF CODE FOR THE XOR TESTER*****
5625 022440 001404 BIT #BIT08,$SWR ;; LOOP ON SPEC. TEST?
5626 022442 127737 156506 001116 2$: BEQ 2$ ;; BR IF NO
5627 022450 001465 CMPB @SWR,$TSTNM ;; ON THE RIGHT TEST? SWR<7:0>
5628 022452 105737 001117 2$: BEQ $OVER ;; BR IF YES
5629 022456 001421 TSTB $ERFLG ;; HAS AN ERROR OCCURRED?
5630 022460 123737 001131 001117 3$: BEQ 3$ ;; BR IF NO
5631 022466 101015 CMPB $ERMAX,$ERFLG ;; MAX. ERRORS FOR THIS TEST OCCURRED?
5632 022470 032777 001000 156456 4$: BHI 3$ ;; BR IF NO
5633 022476 001404 BIT #BIT09,$SWR ;; LOOP ON ERROR?
5634 022500 013737 001124 001122 7$: BEQ 4$ ;; BR IF NO
5635 022506 000446 MOV $LPERR,$LPADR ;; SET LOOP ADDRESS TO LAST SCOPE
5636 022510 105037 001117 4$: BR $OVER
5637 022514 005037 001174 CLR $ERFLG ;; ZERO THE ERROR FLAG
5638 022520 000415 CLR $TIMES ;; CLEAR THE NUMBER OF ITERATIONS TO MAKE
5639 022522 032777 004000 156424 3$: BR 1$ ;; ESCAPE TO THE NEXT TEST
BIT #BIT11,$SWR ;; INHIBIT ITERATIONS?

```

```

5640 022530 001011      BNE      1$          ;; BR IF YES
5641 022532 005737 001216  TST      $PASS      ;; IF FIRST PASS OF PROGRAM
5642 022536 001406      BEQ      1$          ;; INHIBIT ITERATIONS
5643 022540 005237 001120  INC      $ICNT      ;; INCREMENT ITERATION COUNT
5644 022544 023737 001174 001120  CMP      $TIMES,$ICNT ;; CHECK THE NUMBER OF ITERATIONS MADE
5645 022552 002024      BGE      $OVER      ;; BR IF MORE ITERATION REQUIRED
5646 022554 012737 000001 001120 1$: MOV     #1,$ICNT    ;; REINITIALIZE THE ITERATION COUNTER
5647 022562 013737 022640 001174  MOV     $MXCNT,$TIMES ;; SET NUMBER OF ITERATIONS TO DO
5648 022570 105237 001116      INCB     $STNM      ;; COUNT TEST NUMBERS
5649 022574 113737 001116 001214  MOVB   $STNM,$TESTN ;; SET TEST NUMBER IN APT MAILBOX
5650 022602 011637 001122      MOV     (SP),$LPADR ;; SAVE SCOPE LOOP ADDRESS
5651 022606 011637 001124      MOV     (SP),$LPERR ;; SAVE ERROR LOOP ADDRESS
5652 022612 005037 001176      CLR     $ESCAPE    ;; CLEAR THE ESCAPE FROM ERROR ADDRESS
5653 022616 112737 000001 001131  MOVB   #1,$ERMAX   ;; ONLY ALLOW ONE(1) ERROR ON NEXT TEST
5654 022624 013777 001116 156324 $OVER: MOV     $STNM,$DISPLAY ;; DISPLAY TEST NUMBER
5655 022632 013716 001122      MOV     $LPADR,(SP) ;; FUDGE RETURN ADDRESS
5656 022636 000002      RTI                    ;; FIXES PS
5657 022640 003720      $MXCNT: 2000.        ;; MAX. NUMBER OF ITERATIONS

```

.SBTTL TRAP DECODER

```

*****
; *THIS ROUTINE WILL PICKUP THE LOWER BYTE OF THE "TRAP" INSTRUCTION
; *AND USE IT TO INDEX THROUGH THE TRAP TABLE FOR THE STARTING ADDRESS
; *OF THE DESIRED ROUTINE. THEN USING THE ADDRESS OBTAINED IT WILL
; *GO TO THAT ROUTINE.

```

```

5667 022642 010046      $TRAP: MOV     RO,-(SP) ;; SAVE RO
5668 022644 016600 000002  MOV     2(SP),RO    ;; GET TRAP ADDRESS
5669 022650 005740      TST     -(RO)      ;; BACKUP BY 2
5670 022652 111000      MOVB   (RO),RO    ;; GET RIGHT BYTE OF TRAP
5671 022654 006300      ASL    RO         ;; POSITION FOR INDEXING
5672 022656 016000 022676  MOV     $TRPAD(RO),RO ;; INDEX TO TABLE
5673 022662 000200      RTS     RO         ;; GO TO ROUTINE

```

;; THIS IS USE TO HANDLE THE "GETPRI" MACRO

```

5678 022664 011646      $TRAP2: MOV    (SP),-(SP) ;; MOVE THE PC DOWN
5679 022666 016666 000004 000002  MOV    4(SP),2(SP) ;; MOVE THE PSW DOWN
5680 022674 000002      RTI                    ;; RESTORE THE PSW

```

.SBTTL TRAP TABLE

```

; *THIS TABLE CONTAINS THE STARTING ADDRESSES OF THE ROUTINES CALLED
; *BY THE "TRAP" INSTRUCTION.

```

```

; ROUTINE
; -----
5689 022676 022664      $TRPAD: .WORD  $TRAP2
5690 022700 017722      $TYPE  ;; CALL=TYPE      TRAP+1(104401) TTY ,YPEOUT ROUTINE
5691 022702 020666      $TYPOC ;; CALL=TYPOC      TRAP+2(104402) TYPE OCTAL NUMBER (WITH LEADING ZEROS)
5692 022704 020642      $TYPOS ;; CALL=TYPOS      TRAP+3(104403) TYPE OCTAL NUMBER (NO LEADING ZEROS)
5693 022706 020702      $TYPON ;; CALL=TYPON      TRAP+4(104404) TYPE OCTAL NUMBER (AS PER LAST CALL)
5694 022710 021070      $TYPDS ;; CALL=TYPDS      TRAP+5(104405) TYPE DECIMAL NUMBER (WITH SIGN)
5695

```

```

5696 022712 021364          SGTSWR ;;CALL=GTSWR   TRAP+6(104406)  GET SOFT-SWR SETTING
5697
5698 022714 021314          $CKSWR ;;CALL=CKSWR   TRAP+7(104407)  TEST FOR CHANGE IN SOFT-SWR
5699 022716 021576          $RDCHR ;;CALL=RDCHR   TRAP+10(104410) TTY TYPEIN CHARACTER ROUTINE
5700 022720 016644          $RDLIN ;;CALL=RDLIN    TRAP+11(104411) TTY TYPEIN STRING ROUTINE
5701 022722 021752          $$AVREG ;;CALL=SAVREG  TRAP+12(104412) SAVE RO-RS ROUTINE
5702 022724 022010          $RESREG ;;CALL=RESREG TRAP+13(104413) RESTORE RO-RS ROUTINE
5703 022726 016074          $DSPLY ;;CALL=DISPLY TRAP+14(104414) ROUTINE TO TYPE ERROR MESSAGES
5704          000032          $TERM=-$TRPAD
5705
5706          ;;*****
5707
5708
5709
5710          .SBTTL SINGLE/DUAL PORT RH70/RM03 DRIVER (REV 1.0)
5711
5712          ;COPYRIGHT (C) 1976
5713          ;DIGITAL EQUIPMENT CORP.
5714          ;MAYNARD, MA 01754
5715          ;AUTHOR(S): JIM LACEY/CHUCK HESS/C. CHEN
5716
5717          ;;*****
5718
5719          ;STORAGE FOR RMDS, RMER1, RMER2, AND RMMR2 ON AN ERROR "2"
5720          ;RMERRS = RMDS
5721          ;RMERRS+2 = RMER1
5722          ;RMERRS+4 = RMER2
5723          ;RMERRS+6 = RMMR2
5724
5725 022730 000000 000000 000000 RMERRS: .WORD 0,0,0,0
5726 022736 000000
5727
5728          ;TABLE OF DRIVE ACTIVE INDICATORS (DRVACT=8 BYTES)
5729          ;DRVACT=0 IF DRIVE IS IDLE
5730          ;DRVACT>0 IF DRIVE IS ACTIVE WITH A COMMAND
5731          ;DRVACT<0 IF DRIVE IS ACTIVE WITH AN ERROR RECOVERY OPERATION
5732
5733 022740          000          DRVACT: .BYTE 0          ;DRIVE 0
5734 022741          000          .BYTE 0          ;DRIVE 1
5735 022742          000          .BYTE 0          ;DRIVE 2
5736 022743          000          .BYTE 0          ;DRIVE 3
5737 022744          000          .BYTE 0          ;DRIVE 4
5738 022745          000          .BYTE 0          ;DRIVE 5
5739 022746          000          .BYTE 0          ;DRIVE 6
5740 022747          000          .BYTE 0          ;DRIVE 7
5741
5742          ;TABLE OF DRIVE STATUS INDICATORS (DRVSTA=8 BYTES)
5743          ;DRVSTA=0 IF DRIVE IS OFFLINE OR NONEXSITENT
5744          ;DRVSTA>0 IF DRIVE IS ONLINE
5745          ;DRVSTA<0 IF DRIVE IS UNSAFE
5746
5747 022750          000          DRVSTA: .BYTE 0          ;DRIVE 0
5748 022751          000          .BYTE 0          ;DRIVE 1
5749 022752          000          .BYTE 0          ;DRIVE 2
5750 022753          000          .BYTE 0          ;DRIVE 3
5751 022754          000          .BYTE 0          ;DRIVE 4

```

5752 022755 000
 5753 022756 000
 5754 022757 000

.BYTE 0 ;DRIVE 5
 .BYTE 0 ;DRIVE 6
 .BYTE 0 ;DRIVE 7

5755
 5756
 5757
 5758
 5759

;TABLE OF DRIVE TYPES (DRVTYP=8 BYTES)
 ;DRVTYP=0 IF DRIVE IS NONEXISTENT (DRVSTA=0, ALSO)
 ;DRVTYP=4 IF DRIVE IS RMO3
 ;DRVTYP=-1 IF NOT RMO3

5760
 5761 022760 000
 5762 022761 000
 5763 022762 000
 5764 022763 000
 5765 022764 000
 5766 022765 000
 5767 022766 000
 5768 022767 000

DRVTYP: .BYTE 0 ;DRIVE 0
 .BYTE 0 ;DRIVE 1
 .BYTE 0 ;DRIVE 2
 .BYTE 0 ;DRIVE 3
 .BYTE 0 ;DRIVE 4
 .BYTE 0 ;DRIVE 5
 .BYTE 0 ;DRIVE 6
 .BYTE 0 ;DRIVE 7

5769
 5770
 5771
 5772
 5773

;TABLE OF DUAL PORT INITIALIZATION INDICATORS
 ;DPINT=0 IF INITIALIZATION IS NOT ACTIVE ON THE DRIVE
 ;DPINT<0 IF INITIALIZATION IS IN PROGRESS

5774 022770 000
 5775 022771 000
 5776 022772 000
 5777 022773 000
 5778 022774 000
 5779 022775 000
 5780 022776 000
 5781 022777 000

DPINT: .BYTE 0 ;DRIVE 0
 .BYTE 0 ;DRIVE 1
 .BYTE 0 ;DRIVE 2
 .BYTE 0 ;DRIVE 3
 .BYTE 0 ;DRIVE 4
 .BYTE 0 ;DRIVE 5
 .BYTE 0 ;DRIVE 6
 .BYTE 0 ;DRIVE 7

5782
 5783
 5784
 5785
 5786

;TABLE OF PENDING DUAL PORT REQUESTS
 ;DPRQS=0 IF THAT A DUAL PORT REQUEST IS NOT PENDING FOR THAT DRIVE
 ;DPRQS<0 IF THAT A DUAL PORT REQUEST IS PENDING FOR THAT DRIVE

5787 023000 000
 5788 023001 000
 5789 023002 000
 5790 023003 000
 5791 023004 000
 5792 023005 000
 5793 023006 000
 5794 023007 000

DPRQS: .BYTE 0 ;DRIVE 0
 .BYTE 0 ;DRIVE 1
 .BYTE 0 ;DRIVE 2
 .BYTE 0 ;DRIVE 3
 .BYTE 0 ;DRIVE 4
 .BYTE 0 ;DRIVE 5
 .BYTE 0 ;DRIVE 6
 .BYTE 0 ;DRIVE 7

5795
 5796
 5797
 5798
 5799

;TRANSFER WAIT FLAG (TRNSWT=1 WORD)
 ;THIS IS A ONE WORD QUEUE. IT WILL CONTAIN THE ADDRESS OF
 ;"DPB" OF THE I/O OPERATION.

5800 023010 000000

TRNSWT: .WORD 0

5801
 5802
 5803
 5804
 5805
 5806
 5807

;SEARCH WAIT KEYS (SRCHWT=1 WORD)
 ;THIS IS A ONE WORD QUEUE THAT WILL CONTAIN A KEY FOR EACH OF
 ;THE DRIVES THAT ARE PERFORMING A SEARCH COMMAND FOR THE I/O
 ;REQUEST THAT IS AT THE TOP OF THEIR REQUEST QUEUE.
 ;EACH DRIVE IS ASSIGNED ONE BIT, STARTING AT BIT00 FOR DRIVE 0.

```

5808 023012 000000 SRCHWT: .WORD 0
5809
5810 ;RMO3 DRIVER ACTIVE FLAG (ACTDRV=1 BYTE)
5811 ;ACTDRV=0 IF DRIVER IS INACTIVE
5812 ;ACTDRV>0 IF DRIVER IS ACTIVE
5813
5814 023014 000 ACTDRV: .BYTE 0
5815
5816 ;SOFTWARE TIMER ROUTINE ACTIVE FLAG (ACTSTR=1 BYTE)
5817 ;ACTSTR=0 IF SOFTWARE TIMER ROUTINE IS INACTIVE
5818 ;ACTSTR>0 IF SOFTWARE TIMER ROUTINE IS ACTIVE
5819
5820 023015 000 ACTSTR: .BYTE 0
5821
5822 ;UNLOAD FLAG (ULDFLG=8 BYTES)
5823 ;ULDFLG=0 IF NO UNLOAD COMMAND
5824 ;ULDFLG>0 IF UNLOAD COMMAND IN PROGRESS
5825 ;ULDFLG<0 IF UNLOAD COMMAND IN WAIT QUEUE
5826
5827 023016 000 ULDFLG: .BYTE 0 ;DRIVE 0
5828 023017 000 .BYTE 0 ;DRIVE 1
5829 023020 000 .BYTE 0 ;DRIVE 2
5830 023021 000 .BYTE 0 ;DRIVE 3
5831 023022 000 .BYTE 0 ;DRIVE 4
5832 023023 000 .BYTE 0 ;DRIVE 5
5833 023024 000 .BYTE 0 ;DRIVE 6
5834 023025 000 .BYTE 0 ;DRIVE 7
5835
5836 ;LOOK AHEAD COUNT (LACNT=8 BYTES)
5837 ;LACNT WILL INDICATE THE NUMBER OF LOOK AHEADS PERFORMED
5838
5839 023026 000 LACNT: .BYTE 0 ;DRIVE 0
5840 023027 000 .BYTE 0 ;DRIVE 1
5841 023030 000 .BYTE 0 ;DRIVE 2
5842 023031 000 .BYTE 0 ;DRIVE 3
5843 023032 000 .BYTE 0 ;DRIVE 4
5844 023033 000 .BYTE 0 ;DRIVE 5
5845 023034 000 .BYTE 0 ;DRIVE 6
5846 023035 000 .BYTE 0 ;DRIVE 7
5847
5848 ;SAVE REGISTERS FLAG (SAVEFG =1 WORD)
5849 ;SAVEFG <0 IF SAVE THE RH70/RMO3 REGISTERS WHEN THE
5850 ;OPERATION IS COMPLETED AS PER (DPB+14).
5851 ;SAVEFG=0 IF SAVE THE RH70/RMO3 REGISTERS, AS PER
5852 ;(DPB+14), AFTER AN ERROR.
5853
5854 023036 000000 SAVEFG: .WORD 0
5855
5856 ;SEEK FLAG (SEEKFG=1 WORD)
5857 ;SEEKFG=0 IF WHEN THE DISK ADDRESS ISN'T IN THE WINDOW
5858 ;FOR A DATA TRANSFER START A SEARCH COMMAND
5859 ;SEEKFG<0 IF DATA TRANSFER WILL DO IMPLIED SEEKS,
5860 ;DISREGARD THE WINDOW
5861
5862 023040 177777 SEEKFG: .WORD -1
5863

```

```

5864 ;TIMEOUT TABLE (TIMER=8 WORDS)
5865 ;THIS TABLE CONTAINS THE TIME ALLOWED FOR AN OPERATION
5866
5867 023042 177777 TIMER: .WORD -1 ;DRIVE 0
5868 023044 177777 .WORD -1 ;DRIVE 1
5869 023046 177777 .WORD -1 ;DRIVE 2
5870 023050 177777 .WORD -1 ;DRIVE 3
5871 023052 177777 .WORD -1 ;DRIVE 4
5872 023054 177777 .WORD -1 ;DRIVE 5
5873 023056 177777 .WORD -1 ;DRIVE 6
5874 023060 177777 .WORD -1 ;DRIVE 7
5875
5876 ;DATA TRANSFER UNDERWAY INDICATOR (DTUW=1 WORD)
5877 ;DTUW<0 IF NO DATA TRANSFER UNDERWAY
5878 ;DTUW=+N (WHERE N=0 TO 7) IMPLIES DATA TRANSFER UNDERWAY ON DRIVE N
5879
5880 023062 177777 DTUW: .WORD -1
5881
5882 ;ATTENTION BITS TABLE (ATABIT=8 BYTES)
5883 ;THIS TABLE CONTAINS THE CORRESPONDING BIT TO EACH DRIVES
5884 ;ATTENTION BIT
5885
5886 023064 001 ATABIT: .BYTE 1 ;DRIVE 0
5887 023065 002 .BYTE 2 ;DRIVE 1
5888 023066 004 .BYTE 4 ;DRIVE 2
5889 023067 010 .BYTE 10 ;DRIVE 3
5890 023070 020 .BYTE 20 ;DRIVE 4
5891 023071 040 .BYTE 40 ;DRIVE 5
5892 023072 100 .BYTE 100 ;DRIVE 6
5893 023073 200 .BYTE 200 ;DRIVE 7
5894
5895 ;FSRMO3 TO RH70 "MASSBUS CONTROL BUS PARITY ERRORS" (MCPE) ALLOWED BEFORE
5896 ;CALLING IT FATAL (MCPEMX=1 WORD)
5897
5898 023074 000003 MCPEMX: .WORD 3
5899
5900 ;STORAGE FOR RMAADR (THE FIRST ADDRESS (776700) OF THE RH70/RMO3),
5901 ;RMVEC (THE VECTOR ADDRESS (254)), AND RMVEC+2 (THE BR LEVEL (5)).
5902
5903 023076 176700 RMAADR: .WORD 176700
5904 023100 000254 000240 RMVEC: .WORD 254,5*32.
5905
5906 ;MAXIMUM NUMBER OF LOOK AHEADS ALLOWED IS 4 (MXLACT=1 WORD)
5907
5908 023104 000004 MXLACT: .WORD 4
5909 ;MAXIMUM DELTA DELAY IS 8 SECTORS (MXDLTA=1 WORD)
5910
5911 023106 001000 MXDLTA: .WORD 8.*64.
5912 ;MINIMUM DELTA DELAY IS 2 SECTORS (MNDLTA=1 WORD)
5913
5914 023110 000200 MNDLTA: .WORD 2*64.
5915 ;MAXIMUM SEARCH FOR I/O WINDOW IS 5 SECTORS (MXWINDW=1 WORD)
5916
5917 023112 000005 MXWINDW: .WORD 5
5918
5919 ;DEFINITIONS OF THE RH70/RMO3 ADDRESS INDEXES

```

```

5920
5921      000000      RMCS1=0      ;CONTROL AND STATUS REGISTER #1 (DRIVE REG. 00)
5922      000002      RMWC=2      ;WORD COUNT REGISTER (NOT A DRIVE REG)
5923      000004      RMBA=4      ;UNIBUS ADDRESS REGISTER (NOT A DRIVE REG)
5924      000006      RMDA=6      ;DESIRED SECTOR/TRACK ADDRESS REGISTER (DRIVE REG. 05)
5925      000010      RMCS2=10     ;CONTROL AND STATUS REGISTER #2 (NOT A DRIVE REG)
5926      000012      RMD5=12     ;DRIVE STATUS REGISTER (DRIVE REG 01)
5927      000014      RMER1=14     ;ERROR REGISTER #1 (DRIVE REG. 02)
5928      000016      RMAS=16     ;ATTENTION SUMMARY PSEUDO REGISTER (DRIVE REG. 04)
5929      000020      RMLA=20     ;LOOK AHEAD REGISTER (DRIVE REG. 07)
5930      000022      RMOB=22     ;DATA BUFFER REGISTER (NOT A DRIVE REG.)
5931      000024      RMMR1=24     ;MAINTAINABILITY REGISTER (DRIVE REG. 03)
5932      000026      RMDT=26     ;DRIVE TYPE REGISTER (DRIVE REG. 06)
5933      000030      RMSN=30     ;SERIAL NUMBER REGISTER (DRIVE REG. 10)
5934      000032      RMOF=32     ;OFFSET REGISTER (DRIVE REG. 11)
5935      000034      RMDC=34     ;DESIRED CYLINDER ADDRESS REGISTER (DRIVE REG. 12)
5936      000036      RMRH=36     ;DUMMY ADDRESS REGISTER (DRIVE REG. 13)
5937      000040      RMMR2=40     ;MAINTENANCE REGISTER #2
5938      000042      RMER2=42     ;ERROR REGISTER #2 (DRIVE REG. 15)
5939      000044      RMEC1=44     ;ECC POSITION REGISTER (DRIVE REG. 16)
5940      000046      RMEC2=46     ;ECC PATTERN REGISTER (DRIVE REG. 17)
5941
5942      ;RH70/RM03 DRIVER INITIALIZATION CODE
5943      ;THIS ROUTINE WILL DETERMINE WHICH RM03 DRIVES ARE
5944      ;AVAILABLE FOR TESTING AND SET THE DRVSTA INDICATOR
5945      ;TO THE PROPER STATE FOR EACH DRIVE.
5946      ;NOTE: THIS ROUTINE CALLS DRVINT
5947
5948      ;CALL
5949
5950      JSR      PC,RMINIT
5951      RETURN
5952
5953      ;NOTE: THE 'P' OR 'L' CLOCK MUST BE STARTED
5954
5955      RMINIT: SAVREG      ;SAVE R0 - R5
5956      MOV      @#PS, -(SP) ;SAVE THE PRESENT PROCESSOR STATUS
5957      MOV      @<5*32., @#PS ;CHANGE THE PRIORITY TO 5
5958      JSR      PC, CLRQUE ;CLEAR ALL REQUEST QUEUES
5959      MOV      @RMERRS, R1 ;FIRST ADDRESS TO BE CLEARED
5960      MOV      @SEEKFG, R2 ;LAST ADDRESS TO BE CLEARED
5961      CLR      (R1)+ ;CLEAR
5962      CMP      R1, R2 ;ARE WE DONE?
5963      BLO     $ ;BRANCH IF NO
5964      MOV      @DTUW, R2 ;LAST ADDRESS
5965      MOV      @-1, (R1)+ ;INITIALIZE
5966      CMP      R1, R2 ;DONE?
5967      BLOS    $ ;LOOP IF NO
5968      CLR      DRVSTA ;SET ALL DRIVES TO OFFLINE
5969      CLR      DRVSTA+2
5970      CLR      DRVSTA+4
5971      CLR      DRVSTA+6
5972      MOV      RMVEC, R3 ;SETUP THE RH70/RM03 VECTOR
5973      MOV      @ISR, (R3)+
5974      MOV      RMVEC+2, (R3)
5975      MOV      RMAOR, R4 ;FIRST ADDRESS OF RH70/RM03
    
```

```

5976 023226 012764 000040 000010      MOV      #BIT05,RMCS2(R4)      ; MASSBUS INIT
5977 023234 005001                    CLR      R1                    ; START WITH DRIVE 0
5978 023236 004037 023326      3S:    JSR      R0,DRVINT          ; INIT THE DRIVE
5979 023242 000401                    BR      4S                      ; 'DVA' NOT SET OR PARITY ERROR
5980 023244 000402                    BR      5S                      ; NORMAL RETURN
5981 023246 105061 022750      4S:    CLRB   DRVSTA(R1)         ; SET DRIVE STATUS TO OFFLINE
5982 023252 005001      5S:    INC      R1                    ; GO TO NEXT DRIVE
5983 023254 040001 177770      BIC      #1C7,R1              ; MASK OUT UNUSED BITS
5984 023260 000000      BNE     3S                    ; BR IF MORE DRIVES TO GO
5985 023262 000001 000007      MOV      #7,R1                ; START WITH DRIVE 7
5986 023266 000037 177776      CLR      #PS                  ; CLEAR THE PROCESSOR STATUS
5987 023272 105761 022770      6S:    TSTB   DPINT(R1)          ; WAITING FOR DRIVE TO SWITCH PORTS ?
5988 023276 001405                    BEQ     8S                      ; BR NOT WAITING
5989 023300 004737 030364      JSR      PC,SET.IE            ; SET INTERRUPT
5990 023304 105761 022770      7S:    TSTB   DPINT(R1)          ; DRIVE SWITCHED PORTS ?
5991 023310 001375                    BNE     7S                      ; BR IF NOT
5992 023312 005301      8S:    DEC      R1                    ; GO TO THE NEXT DRIVE
5993 023314 100366                    BPL     6S                      ; CHECK NEXT DRIVE
5994 023316 012637 177776      MOV      (SP)+,#PS            ; RESTORE THE PROCESSOR STATUS
5995 023322 104413      RESREG  PC                    ; RESTORE R0 - R5
5996 023324 000207      RTS      PC                    ; BYE-BYE
5997
5998      ;DRIVE INITIALIZATION ROUTINE
5999      ;THIS ROUTINE DETERMINES IF A DRIVE EXIST AND IF IT IS
6000      ;AN RMO3. IF IT IS, A "READ-IN PRESET" IS ISSUED AND FMT22
6001      ;IS SET TO A "1". THEN MOL, DPR, DRY, AND VV ARE CHECKED TO
6002      ;INSURE THEY ARE ALL ON A "1". AND DEPENDING ON THEIR STATE,
6003      ;DRVSTA IS SET TO THE PROPER CONDITION.
6004
6005      ;CALL
6006      :
6007      :
6008      :
6009      :
6010      :
6011      :
6012 023326 010546      DRVINT: MOV      R5,-(SP)          ; SAVE R5
6013 023330 105061 022750      DULP:  CLRB   DRVSTA(R1)       ; START DRIVE STATUS AS OFFLINE
6014 023334 105061 022760      CLRB   DRVSTYP(R1)           ; CLEAR THE DRIVE TYPE INDICATOR
6015 023340 105061 023016      CLRB   ULDFLG(R1)           ; CLEAR THE UNLOAD FLAG
6016 023344 010164 000010      MOV      R1,RMCS2(R4)       ; SELECT A DRIVE
6017 023350 112764 000111 000000      MOVB   #111,RMCS1(R4)       ; DO A DRIVE CLEAR COMMAND (& SEIZE DRIVE)
6018 023356 032764 010000 000010      BIT    #BIT12,RMCS2(R4)     ; NONEXISTENT DRIVE?
6019 023364 001403                    BEQ     1S                      ; NO---BRANCH
6020 023366 004737 030364      JSR      PC,SET.IE            ; GO SET "IE" WITHOUT A "TRE"
6021 023372 000476                    BR      6S                      ; LEAVE THIS ROUTINE
6022 023374 105061 022750      1S:    CLRB   DRVSTA(R1)         ; SET DRIVE STATUS TO OFFLINE
6023 023400 032764 004000 000000      BIT    #BIT11,RMCS1(R4)     ; SEE IF DRIVE AVAILABLE
6024 023406 001750                    BEQ     DULP                    ; BR IF DRIVE NOT AVAILABLE
6025 023410 004037 027674      JSR      R0,RD.RM            ; READ THE DRIVE TYPE REG.
6026 023414 000026                    RMDT
6027 023416 023614                    BS
6028 023420 012605                    MOV      (SP)+,R5            ; ERROR RETURN ADDRESS
6029 023422 112761 000004 022760      MOVB   #4,DRVSTYP(R1)       ; PUT DRIVE TYPE IN R5
6030 023430 022705 020024      CMPL   #20024,R5            ; SET RMO3 INDICATOR
6031 023434 001407                    BEQ     2S                      ; SINGLE PORT RMO3 ?
                                ; BR IF YES
    
```


B10

```

6032 023436 022705 024024      CMP      #24024,R5      ;DUAL PORT RMO3 ?
6033 023442 001404      BEQ      2$          ;BR IF YES
6034 023444 112761 177777 022760      MOV      #-1,DRVSTYP(R1) ;SET INDICATOR TO 'OTHER'
6035 023452 000446      BR      6$          ;EXIT
6036 023454 012746 000121      2$:      MOV      #121,-(SP)    ;DO A "READ-IN PRESET"
6037 023460 004037 030054      JSR      RO,WRT.RM
6038 023464 000000      RMCS1
6039 023466 023614      BS
6040 023470 012746 010000      MOV      #BIT12,-(SP)  ;SET FMT22=1
6041 023474 004037 030054      JSR      RO,WRT.RM
6042 023500 000032      RMOF
6043 023502 023614      PS
6044 023504 004037 027674      JSR      RO,RD.RM      ;READ RMO3
6045 023510 000012      RMCS1
6046 023512 023614      BS
6047 023514 012605      MOV      (SP)+,R5      ;AND SAVE IT IN R5
6048 023516 100015      BPL      4$          ;BRANCH IF ATA=0
6049 023520 116164 023064 000016      MOV      ATABIT(R1),RMA5(R4) ;CLEAR ATTENTION BIT
6050 023526 004037 027674      JSR      RO,RD.RM      ;FIND OUT WHY ATA=1
6051 023532 000014      RMER1
6052 023534 023614      BS
6053 023536 006126      ROL      (SP)+          ;IS IT UNSAFE?
6054 023540 100004      BPL      4$          ;BR IF NOT
6055 023542 112761 177777 022750      MOV      #-1,DRVSTA(R1) ;SET UNSAFE INDICATOR
6056 023550 000407      BR      6$          ;EXIT
6057 023552 005105      4$:      COM      R5          ;CHECK MOL, DPR, DRY, AND VV
6058 023554 042705 167077      BIC      #1<BIT12:BIT08:BIT07:BIT06>,R5
6059 023560 001003      BNE      6$          ;BRANCH IF MOL, DPR, DRY, OR VV IS CLEAR
6060 023562 112761 000001 022750      MOV      #1,DRVSTA(R1) ;SET DRIVE STATUS TO ONLINE
6061 023570 005720      6$:      TST      (R0)+        ;STEP OVER THE ERROR RETURN
6062 023572 000410      BR      8$          ;EXIT
6063 023574 006301      7$:      ASL      R1          ;CHANGE INDEX TO ADDRESS WORDS
6064 023576 012761 003720 023042      MOV      #2000.,TIMER(R1) ;START 2 SEC TIMER
6065 023604 006201      ASR      R1          ;RESTORE R1
6066 023606 112761 177777 022770      MOV      #-1,DPINT(R1) ;SET PORT INITIALIZE INDICATOR
6067 023614 012605      8$:      MOV      (SP)+,R5      ;RESTORE R5
6068 023616 000200      RTS      R0          ;EXIT
6069
6070      ;REQUEST PRE-PROCESSOR-HANDLES SUBSYSTEM REQUEST
6071
6072      ;CALL
6073
6074      ;
6075      JSR      RO,#RMO3 ;CALL THE RMO3 DRIVER
6076      PNTADR ;ADDRESS OF POINTER OF DRIVES PARAMETER BLOCK
6077      RETURN1 ;RETURN HERE IF QUEUE IS FULL
6078      RETURN2 ;RETURN HERE IF REQUEST IS IN QUEUE OR THERE
6079      ;IS AN ERROR CONDITION
6080 023620 013746 177776      RMO3:  MOV      #PS,-(SP)    ;SAVE THE CALLING STATUS
6081 023624 013737 023102 177776      MOV      RMVEC+2,#PS   ;DON'T ALLOW ANY RMO3 INTERRUPTS
6082 023632 112737 000001 023014      MOV      #1,ACTDRV    ;SET "ACTIVE DRIVER" FLAG
6083 023640 104412      SAVREG ;SAVE R0 - R5
6084 023642 011002      MOV      (R0),R2      ;PICKUP THE DRIVE PARAMETER BLOCK POINTER
6085 023644 005062 000016      CLR      16(R2)       ;CLEAR THE STATUS/ERROR INDICATOR
6086 023650 111201      MOV      (R2),R1      ;PICKUP THE DRIVE NUMBER
6087 023652 013704 023076      MOV      RMA0R,R4     ;UNIBUS ADDRESS OF RMCS1
    
```

```

6088 023656 105761 022750      TSTB  DRVSTA(R1)      ;CHECK DRIVES STATUS
6089 023662 003014      BGT   1$             ;BRANCH IF ONLINE
6090 023664 105761 023016      TSTB  ULDFLG(R1)     ;UNLOAD COMMAND IN QUEUE?
6091 023670 001036      BNE   3$             ;BRANCH IF YES
6092 023672 105761 022770      TSTB  DPINT(R1)     ;TRYING TO INIT THE DRIVE
6093 023676 001042      BNE   5$             ;BR IF YES
6094 023700 004037 023326      JSR   RO,DRVINT     ;GO INIT. THE DRIVE
6095 023704 000434      BR    4$             ;ERROR RETURN
6096 023706 105761 022750      TSTB  DRVSTA(R1)     ;IS DRIVE STATUS ONLINE?
6097 023712 003445      BLE   6$             ;BR IF NOT
6098 023714 105761 023000      1$:  TSTB  DPRQS(R1)   ;OUTSTANDING PORT REQUEST FOR THE DRIVE ?
6099 023720 001031      BNE   5$             ;BR IF YES
6100 023722 010164 000010      MOV   R1,RMCS2(R4)  ;SELECT THE DRIVE
6101 023726 004037 031026      JSR   RO,DRVQUE     ;PUT THIS REQUEST IN QUEUE
6102 023732 000460      BR    9$             ;QUEUE IS FULL
6103 023734 122762 000103 000002      CMPB  #103,2(R2)    ;IS THIS REQ. FOR AN UNLOAD?
6104 023742 001003      BNE   2$             ;BR IF NO
6105 023744 112761 177777 023016      MOVB  #-1,ULDFLG(R1);SET THE "UNLOAD IN QUEUE" FLAG
6106 023752 105761 022740      2$:  TSTB  DRVACT(R1)  ;IS THIS DRIVE ACTIVE?
6107 023756 001043      BNE   8$             ;BR IF YES
6108 023760 004737 024112      JSR   PC,OPT        ;CALL THE OPTIMIZER
6109 023764 000440      BR    8$
6110 023766 012762 120000 000016 3$:  MOV   #BIT15!BIT13,16(R2);SET THE "UNLOAD IN QUEUE" ERROR FLAG
6111 023774 000434      BR    8$             ;EXIT
6112 023776 004737 025172      4$:  JSR   PC,C17       ;GO HANDLE THE PARITY ERROR
6113 024002 000431      BR    8$
6114 024004 004037 031026      5$:  JSR   RO,DRVQUE     ;PUT REQUEST IN QUEUE
6115 024010 000431      BR    9$             ;QUEUE IS FULL
6116 024012 032714 000100      BIT   #BIT06,(R4)   ;IE BIT SET ?
6117 024016 001023      BNE   8$             ;YES
6118 024020 004737 030364      JSR   PC,SET.IE     ;SET THE INTERRUPT
6119 024024 000420      BR    8$             ;RETURN
6120 024026 105761 022750      6$:  TSTB  DRVSTA(R1)   ;SEE IF DRIVE OFFLINE OR UNSAFE
6121 024032 002412      BLT   7$             ;BR IF UNSAFE
6122 024034 012762 140000 000016      MOV   #BIT15!BIT14,16(R2);SET OFFLINE ERROR INDICATOR
6123 024042 105761 022760      TSTB  DRVSTYP(R1)  ;SEE IF OFFLINE OR NONEXISTENT
6124 024046 001007      BNE   8$             ;BR IF OFFLINE
6125 024050 012762 100002 000016      MOV   #BIT15!BIT01,16(R2);REPORT DRIVE NONEXISTENT
6126 024056 000403      BR    8$             ;GO TO EXIT
6127 024060 012762 110000 000016 7$:  MOV   #BIT15!BIT12,16(R2);DRIVE IS UNSAFE
6128 024066 104413      8$:  RESREG ;RESTORE RO - R5
6129 024070 005720      TST   (RO)+         ;SETUP FOR NORMAL RETURN
6130 024072 000401      BR    10$          ;FINISH UP, THEN EXIT
6131 024074 104413      9$:  RESREG ;RESTORE RO - R5
6132 024076 005720      10$: TST   (RO)+        ;CORRECT THE RETURN ADDRESS
6133 024100 105037 023014      CLRB  ACTDRV        ;CLEAR "ACTIVE DRIVER" FLAG
6134 024104 012637 177776      MOV   (SP)+,2#PS    ;RETURN "PS" TO USER LEVEL
6135 024110 000200      RTS   RO            ;RETURN TO CALLER
6136
6137 ;OPTIMIZER-CALLED FOR A PARTICULAR DRIVE
6138
6139 ;CALL
6140
6141     MOV   #DRVNUM,R1 ;DRIVE NUMBER TO R1
6142     JSR   PC,OPT      ;SETUP A COMMAND
6143 024112 104412      OPT: SAVREG         ;SAVE RO - R5
    
```

```

6144 024114 013746 177776      MOV      2#PS -(SP)      ;SAVE PROC. STATUS
6145 024120 146137 023064 023012 BICB    ATABIT(R1),SRCHWT ;CLEAR LA SEACH FLAG
6146 024126 105061 023000      CLRB    DPRQS(R1)      ;RESET THE PORT REQ FLAG ****
6147 024132 004737 031102      JSR     PC,GETREQ      ;GET "DPR" POINTER OF REQUEST
6148 024136 005702      TST     R2              ;IS THERE A REQUEST IN QUEUE?
6149 024140 001472      BEQ     7$              ;NO--BRANCH TO EXIT
6150 024142 010164 000010      MOV     R1,RMCS2(R4)    ;LOAD THE DRIVE ADDRESS *****
6151 024146 012764 000111 000000      MOV     #11,RMCS1(R4)   ;CLEAR THE DRIVE
6152 024154 032764 004000 000000      BIT     #BIT11,RMCS1(R4) ;DVA SET ?
6153 024162 001446      BEQ     5$              ;TO PROT REQUEST, IF NOT
6154 024164 105761 022750      10$:   TSTB   DRVSTA(R1)     ;IS DRIVE ONLINE?
6155 024170 003014      BGT     1$              ;YES--BRANCH
6156 024172 004737 031124      JSR     PC,POPQUE      ;NO--REMOVE REQUEST FROM QUEUE
6157 024176 012762 140000 000016      MOV     #BIT15!BIT14,16(R2) ;SET OFFLINE STATUS/ERROR INDICATOR
6158 024204 105761 022750      TSTB   DRVSTA(R1)     ;IS DRIVE UNSAFE ?
6159 024210 100053      BPL     8$              ;BR TO EXIT IF NOT
6160 024212 012762 110000 000016      MOV     #BIT15!BIT12,16(R2) ;SET UNSAFE STATUS/ERROR INDICATOR
6161 024220 000447      BR      8$              ;BRANCH TO EXIT
6162 024222      1$:
6163      :
6164      :
6165      :
6166      :
6167      :
6168      :
6169 024222 122762 000150 000002      MOV     #11,-(SP)      ;LOAD COMMAND ONTO THE STACK
6170 024230 002403      JSR     RO,WRT.RM      ;LOAD THE REGISTER
6171 024232 004737 024556      RMCS1   ;REGISTER INCREMENT
6172 024236 000440      6$     ;ERROR RETURN ADDRESS
6173 024240 005737 023062      BIT     #BIT11,(R4)    ;DRIVE AVAILABLE ?
6174 024244 002012      BEQ     9$              ;BR IF NOT
6175 024246 005737 023040      CMPB   #150,2(R2)     ;IS THE REQUEST FOR I/O?
6176 024252 100404      BLT     2$              ;YES--BRANCH
6177 024254 004037 025526      JSR     PC,C14         ;CALL THE COMMAND INITIATOR
6178 024260 000427      BR      8$              ;BRANCH TO EXIT
6179 024262 000403      BR      4$              ;DATA TRANSFER UNDERWAY?
6180 024264 004737 024350      2$:   TST     DTUW          ;YES--GO START A SEARCH
6181 024270 000423      BR      4$              ;DO IMPLIED SEEKS?
6182 024272 004737 024456      4$:   TST     SEEKFG      ;YES---BRANCH
6183 024276 000400      BR      8$              ;NO--DO LOOK AHEAD
6184 024300 112761 177777 023000 5$:   JSR     RO,LA          ;RETURN HERE ON A PARITY ERROR
6185 024306 010103      BR      4$              ;GO START A SEARCH
6186 024310 006303      BR      8$              ;START A DATA TRANSFER
6187 024312 012763 023420 023042 5$:   JSR     PC,C13         ;START A SEARCH
6188 024320 000402      BR      8$              ;GO TO THE EXIT
6189 024322 004737 025172      6$:   MOVB   #-1,DPRQS(R1) ;SET PORT REQUEST INDICATOR
6190 024326 032714 000100      7$:   MOV     R1,R3        ;SET UP TO ADDRESS WORDS
6191 024332 001002      ASL     R3              ;CONVERT TO WORD INDEX
6192 024334 004737 030364      MOV     #10000.,TIMER(R3) ;START 10 SEC TIMER
6193 024340 012637 177776      8$:   BR      7$           ;EXIT
6194 024344 104413      JSR     PC,C17         ;PROCESS THE PARITY ERROR
6195 024346 000207      BIT     #BIT06,(R4)    ;SEE IF 'IE' ALREADY SET
6196      :
6197      :
6198      :
6199      :
      BNE   8$              ;BR IF SET
      JSR   PC,SET.IE      ;SET "IE" WITHOUT A "TRE"
      MOV   (SP)+,2#PS     ;RESTORE PROC. STATUS
      RESREG ;RESTORE R0 - R5
      RTS   PC
;COMMAND INITIATOR
;CALL

```

E10

6200					MOV	#DRVNUM,R1	;DRIVE NUMBER
6201					MOV	#DPB,R2	;ADDRESS OF DPB
6202					JSF	PC,C1?	;C1?= C11,C13, OR C14
6203							;WHERE:
6204							;C11=DATA TRANSFER
6205							;C12=SEARCH REQUESTED BY DATA XFER
6206							;C14=NOT DATA TRANSFER
6207							
6208	024350	004737	031124	C11:	JSR	PC,POPQUE	;REMOVE REQUEST FROM "DRIVES WAIT" QUEUE
6209	024354	010237	023010		MOV	R2,TRNSWT	;PUT REQ. IN TRANSFER WAIT QUEUE
6210	024360	010203			MOV	R2,R3	;DPB ADDRESS TO R3
6211	024362	013704	023076		MOV	RMADR,R4	;RMCS1 ADDRESS
6212	024366	010164	000010		MOV	R1,RMCS2(R4)	;SELECT DRIVE
6213	024372	062703	000004		ADD	#4,R3	;DESIRED WORD COUNT
6214	024376	062704	000002		ADD	#2,R4	;RMMC ADDRESS
6215	024402	012324			MOV	(R3)+,(R4)+	;LOAD WORD COUNT
6216	024404	012324			MOV	(R3)+,(R4)+	;LOAD BUFFER ADDRESS
6217	024406	012346			MOV	(R3)+,-(SP)	;LOAD SECTOR AND TRACK
6218	024410	004037	030054		JSR	RO,WRT.RM	;CALL THE LOAD(WRITE) ROUTINE
6219	024414	000006			RMDA		;INDEX OF REGISTER TO LOAD
6220	024416	025172			CI7		;ERROR RETURN ADDRESS
6221	024420	012346			MOV	(R3)+,-(SP)	;LOAD CYLINDER ADDRESS
6222	024422	004037	030054		JSR	RO,WRT.RM	
6223	024426	000034			RMDC		
6224	024430	025172			CI7		
6225	024432	016246	000002		MOV	2(R2),-(SP)	;LOAD "COMMAND+GO", "A17&A16", AND "PSEL"
6226	024436	004037	030054		JSR	RO,WRT.RM	
6227	024442	000000			RMCS1		
6228	024444	025172			CI7		
6229	024446	010137	023062		MOV	R1,DTUM	;SET "DATA TRANSFER UNDERWAY"
6230	024452	000137	025134		JMP	CI5	
6231	024456	013704	023076	C13:	MOV	RMADR,R4	;RMCS1 ADDRESS
6232	024462	010164	000010		MOV	R1,RMCS2(R4)	;SELECT DRIVE
6233	024466	016246	000012		MOV	12(R2),-(SP)	;DESIRED CYLINDER ADDRESS
6234	024472	004037	030054		JSR	RO,WRT.RM	
6235	024476	000034			RMDC		
6236	024500	025172			CI7		
6237	024502	116203	000010		MOV	10(R2),R3	;PICKUP SECTOR ADDRESS
6238					SUB	MXWINDOW,R3	;BACKUP BY MAX. SEARCH FOR I/O WINDOW
6239					BGE	15	
6240					ADD	#32,R3	
6241	024506	010346		15:	MOV	R3,-(SP)	;COMBINE THE ADJUSTED SECTOR WITH
6242	024510	042716	177740		BIC	#177740,(SP)	;CHOP OF ALL EXENTED BITS ,IF ANY
6243	024514	116266	000011	000001	MOV	11(R2),1(SP)	;THE DESIRED TRACK
6244	024522	004037	030054		JSR	RO,WRT.RM	;LOAD DESIRED TRACK & SECTOR
6245	024526	000006			RMDA		
6246	024530	025172			CI7		
6247	024532	012746	000131		MOV	#131,-(SP)	;START A SEARCH
6248	024536	004037	030054		JSR	RO,WRT.RM	
6249	024542	000000			RMCS1		
6250	024544	025172			CI7		
6251	024546	156137	023064	023012	BISB	ATABIT(R1),SRCHWT	;SET "SEARCH WAIT" KEY
6252	024554	000567			BR	CI5	
6253	024556	013704	023076	C14:	MOV	RMADR,R4	;RMCS1 ADDRESS
6254	024562	010164	000010		MOV	R1,RMCS2(R4)	;SELECT DRIVE
6255	024566	116203	000002		MOV	2(R2),R3	;PICKUP THE REQUESTED COMMAND

F10

MAIN C-11-DZRM1 AO/00, RMO3 DRIVE COMPATIBILITY TEST MACY11 30(1046) 21-JUL-77 16:51 PAGE 122
 DZRM1A.P11 21-JUL-77 15:44 SINGLE/DUAL PORT RH70/RMO3 DRIVER (REV 1.0)

SEQ 0121

6256	024572	122703	000131		CMPB	#131,R3	; IS IT A SEARCH COMMAND?
6257	024576	001007			BNE	1\$; BRANCH IF NO
6258	024600	016246	000010		MOV	10(R2),-(SP)	; LOAD DESIRED TRACK & SECTOR
6259	024604	004037	030054		JSR	RO,WRT.RM	
6260	024610	000006			RMOA		
6261	024612	025172			CI7		
6262	024614	000403			BR	2\$; GO LOAD CYLINDER
6263	024616	122703	000105	1\$:	CMPB	#105,R3	; IS IT A SEEK COMMAND
6264	024622	001007			BNE	3\$; BRANCH IF NO
6265	024624	016246	000012	2\$:	MOV	12(R2),-(SP)	; LOAD DESIRED CYLINDER
6266	024630	004037	030054		JSR	RO,WRT.RM	
6267	024634	000034			RMOC		
6268	024636	025172			CI7		
6269	024640	000546			BR	CI6	
6270	024642	122703	000115	3\$:	CMPB	#115,R3	; IS IT AN "OFFSET" COMMAND?
6271	024646	001013			BNE	4\$; BR IF NO
6272	024650	004037	027674		JSR	RO,RO.RM	; MERGE THE OFFSET VALUE INTO RMOF
6273	024654	000032			RMOF		; BUT DON'T CHANGE THE UPPER
6274	024656	025172			CI7		
6275	024660	116216	000001		MOV	1(R2),(SP)	; BYTE WHEN LOADING THE
6276	024664	004037	030054		JSR	RO,WRT.RM	; REGISTER (RMOF)
6277	024670	000032			RMOF		
6278	024672	025172			CI7		
6279	024674	000530			BR	CI6	; GO START THE COMMAND
6280	024676	122703	000107	4\$:	CMPB	#107,R3	; IS IT A "RECALIBRATE" COMMAND?
6281	024702	001525			BEQ	CI6	; BRANCH IF YES
6282	024704	122703	000117		CMPB	#117,R3	; IS IT A RETURN TO CENTER?
6283	024710	001522			BEQ	CI6	; BRANCH IF YES
6284	024712	122703	000103		CMPB	#103,R3	; IS IT AN "UNLOAD" COMMAND?
6285	024716	001016			BNE	5\$; BRANCH IF NO
6286	024720	112761	000001	022740	MOV	#1,DRVACT(R1)	; SET THE DRIVE ACTIVE INDICATOR
6287	024726	105061	022750		CLRB	DRVSTA(R1)	; PUT DRIVE STATUS TO OFFLINE
6288	024732	112761	000001	023016	MOV	#1,ULDFLG(R1)	; SET "UNLOAD IN PROGRESS" FLAG
6289	024740	010346			MOV	R3,-(SP)	; START THE "UNLOAD" COMMAND
6290	024742	004037	030054		JSR	RO,WRT.RM	
6291	024746	000000			RMCS1		
6292	024750	025172			CI7		
6293	024752	000207			RTS	PC	; RETURN TO USER
6294	024754	122703	000143	5\$:	CMPB	#143,R3	; IS IT A "SET FORMAT" COMMAND?
6295	024760	001014			BNE	6\$; BRANCH IF NO
6296	024762	004037	027674		JSR	RO,RO.RM	; READ THE OFFSET REGISTER
6297	024766	000032			RMOF		
6298	024770	025172			CI7		
6299	024772	116266	000001	000001	MOV	1(R2),1(SP)	; COMBINE "FMT22" "ECI" AND "HCI"
6300	025000	004037	030054		JSR	RO,WRT.RM	; LOAD "FMT22", "ECI", AND/OR "HCI".
6301	025004	000032			RMOF		
6302	025006	025172			CI7		
6303	025010	000436			BR	12\$	
6304	025012	122703	000141	6\$:	CMPB	#141,R3	; IS IT A "GET REGISTER" COMMAND?
6305	025016	001023			BNE	10\$; BRANCH IF NO
6306	025020	016203	000006	7\$:	MOV	6(R2),R3	; POINTS TO 1ST ADDRESS OF WHERE
6307							; TO PUT THE REGISTER(S)
6308	025024	116237	000010	025042	MOV	10(R2),9\$; INIT. THE INDEX FOR THE FIRST REG.
6309	025032	116205	000011		MOV	11(R2),R5	; INDEX OF LAST REG. TO MOVE
6310	025036	004037	027674	8\$:	JSR	RO,RO.RM	; READ RH70/RMO3 REGISTER
6311	025042	000000		9\$:	RMCS1		; INDEX OF REG. TO READ

G10

MAINDEC-11-DZRM1 AO/00, RMO3 DRIVE COMPATIBILITY TEST MACY11 30(1046) 21-JUL-77 16:51 PAGE 123
 DZRM1A.P11 21-JUL-77 15:44 SINGLE/DUAL PORT RH70/RMO3 DRIVER (REV 1.0)

SEQ 0122

6312	025044	025172				CI7		
6313	025046	012623				MOV	(SP)+, (R3)+	; GET THE CONTENTS OF RH70//RMO3 REG.
6314	025050	023705	025042			CMP	95, R5	; LAST REG. BEEN READ?
6315	025054	001414				BEQ	125	; GET OUT IF YES
6316	025056	062737	000002	025042		ADD	#2, 95	; INCREASE THE INDEX BY 2
6317	025064	000764				BR	85	; LOOP--MORE TO READ
6318	025066	122703	000145		105:	CMPB	#145, R3	; IS IT A "SELECT DRIVE" COMMAND?
6319	025072	001405				BEQ	125	; BRANCH IF YES
6320	025074	010346			115:	MOV	R3, -(SP)	; LOAD THE COMMAND
6321	025076	004037	030054			JSR	RO, WRT.RM	
6322	025102	000000				RMCS1		
6323	025104	025172				CI7		
6324	025106	004737	031124		125:	JSR	PC, POPQUE	; REMOVE REQ. FROM QUEUE
6325	025112	052762	000200	000015		BIS	#BIT07, 16(R2)	; SET THE "DONE" BIT
6326	025120	005737	023036			TST	SAVEFG	; SAVE THE RH70/RMO3 REGISTERS?
6327	025124	100002				BPL	135	; BRANCH IF NO
6328	025126	004737	030246			JSR	PC, SVRH70	; YES--GO SAVE THE REGISTERS
6329	025132	000207			135:	RTS	PC	; RETURN TO USER
6330	025134	006301			CI5:	ASL	R1	
6331	025136	012761	001750	023042		MOV	#1000., TIMER(R1)	; SET A ONE SECOND TIMER
6332	025144	006201				ASR	R1	
6333	025146	112761	000001	022740		MOVB	#1, DRVACT(R1)	; SET THE DRIVE ACTIVE
6334	025154	000207				RTS	PC	; RETURN TO THE USER
6335	025156	010346			CI6:	MOV	R3, -(SP)	; LOAD THE COMMAND
6336	025160	004037	030054			JSR	RO, WRT.RM	
6337	025164	000000				RMCS1		
6338	025166	025172				CI7		
6339	025170	000761				BR	CI5	
6340	025172	032764	010000	000010	CI7:	BIT	#BIT12, RMCS2(R4)	; DRIVE NON-EXISTENT ?
6341	025200	001034				BNE	CI8	; BR IF YES
6342	025202	005702			15:	TST	R2	; ANYTHING IN QUEUE ?
6343	025204	001405				BEQ	CI7B	; BR IF NOT
6344	025206	012762	104000	000016		MOV	#BIT15:BIT11, 16(R2)	; SET "PARITY" ERROR INDICATOR
6345	025214	004737	030246			JSR	PC, SVRH70	; GO SAVE THE RH70/RMO3 REGISTERS
6346	025220	012746	000111		CI7B:	MOV	#111, -(SP)	; DO A "DRIVE CLEAR"
6347	025224	004037	030054			JSR	RO, WRT.RM	
6348	025230	000000				RMCS1		
6349	025232	025272				CI8		
6350	025234	004737	031006			JSR	PC, EMPTYQ	; EMPTY THE QUEUE
6351	025240	105061	023016			CLRB	ULDFLG(R1)	; CLEAR THE UNLOAD IN QUEUE FLAG
6352	025244	105061	022740			CLRB	DRVACT(R1)	; DRIVE IS IDLE
6353	025250	020137	023062			CMP	R1, DTUW	; IF THIS DRIVE HAD AN I/O REQUEST
6354	025254	001005				BNE	15	; IN PROGRESS CLEAR ALL OF THE FLAGS
6355	025256	005037	023010			CLR	TRNSWT	
6356	025262	012737	177777	023062		MOV	#-1, DTUW	
6357	025270	000207			15:	RTS	PC	
6358	025272	104412			CI8:	SAVREG		; SAVE R0 - R5
6359	025274	032764	010000	000010		BIT	#BIT12, RMCS2(R4)	; IS 'NED' SET ?
6360	025302	001002				BNE	15	; BR IF YES
6361	025304	005001				CLR	R1	
6362	025306	005003				CLR	R3	
6363	025310	105761	022740		15:	TSTB	DRVACT(R1)	; DRIVE ACTIVE?
6364	025314	001443				BEQ	55	; BRANCH IF NO
6365	025316	013702	023010			MOV	TRNSWT, R2	; GET THE "TRANSFER WAIT" QUEUE
6366	025322	020137	023062			CMP	R1, DTUW	; DID THIS DRIVE HAVE AN I/O IN PROGRESS?
6367	025326	001402				BEQ	25	; BRANCH IF YES

H10

```

6368 025330 004737 031102      JSR    PC,GETREQ      ;GET THE DPB POINTER
6369 025334 005702      2$:   IST    R2        ;QUEUE ENTRY FOR DRIVE ?
6370 025336 001415      BEQ    4$             ;BR IF NOT
6371 025340 032764 010000 000010    BIT    #BIT12,RMCS2(R4) ;'NED' SET ?
6372 025346 001404      BEQ    3$             ;BR IF NOT
6373 025350 012762 100002 000016    MOV    #BIT15!BIT01,16(R2) ;SET 'DRIVE NON-EXISTENT' INDICATOR
6374 025356 000405      BR     4$             ;CONTINUE
6375 025360 012762 102000 000016    3$:   MOV    #BIT15!BIT10,16(R2) ;SET "NON-CLEARABLE PARITY" ERROR INDICATOR
6376 025366 004737 030246      JSR    PC,SVRH70     ;SAVE RH70/RM03 REGISTERS
6377 025372 012763 177777 023042    4$:   MOV    #-1,TIMER(R3) ;STOP THE TIMER
6378 025400 105061 022740      CLRB  DRVACT(R1)    ;SET "DRIVE ACTIVE" TO IDLE
6379 025404 020137 023062      CMP    R1,DTUM      ;IS THIS DRIVE SETUP FOR A TRANSFER
6380 025410 001005      BNE   5$             ;BR IF NOT
6381 025412 012737 177777 023062      MOV    #-1,DTUM     ;RESET THE INDICATOR
6382 025420 005037 023010      CLR  TRNSWT         ;CLEAR THE TRANSFER QUEUE
6383 025424 105061 023016    5$:   CLRB  ULDFLG(R1)   ;CLEAR UNLOAD FLAG
6384 025430 032764 010000 000010    BIT    #BIT12,RMCS2(R4) ;'NED' SET ?
6385 025436 001021      BNE   6$             ;BR IF YES
6386 025440 005201      INC    R1            ;MOVE TO THE NEXT DRIVE
6387 025442 062703 000002      ADD    #2,R3
6388 025446 042701 177770      BIC    #1<7,R1
6389 025452 001316      BNE   1$             ;BRANCH IF MORE DRIVES
6390 025454 012737 177777 023062      MOV    #-1,DTUM     ;NO DATA TRANSFERS UNDERWAY
6391 025462 005037 023010      CLR  TRNSWT         ;CLEAR THE 'TRANSFER WAIT' QUEUE
6392 025466 004737 030730      JSR    PC,CLRQUE    ;CLEAR ALL OF THE REQUEST QUEUES
6393 025472 012764 000040 000010    MOV    #BIT05,RMCS2(R4) ;DO A MASSBUS INIT.
6394 025500 000406      BR     7$             ;CONTINUE
6395 025502 004737 031006    6$:   JSR    PC,EMPTYQ   ;CLEAR THE DRIVE'S QUEUE
6396 025506 105061 022750      CLRB  DRVSTA(R1)    ;SET DRIVE TO OFFLINE
6397 025512 105061 022760      CLRB  DRVTYP(R1)   ;CLEAR THE DRIVE TYPE INDICATOR
6398 025516 004737 030364    7$:   JSR    PC,SET.IE   ;SET "IE" WITHOUT "TRE"
6399 025522 104413      RESREG              ;RESTORE R0 - R5
6400 025524 000207      RTS    PC            ;RETURN
6401
6402      ;LOOK AHEAD ROUTINE
6403
6404      ;CALL
6405      MOV    #DRVNUM,R1 ;DRIVE NUMBER
6406      MOV    #DPB,R2    ;POINT TO DPB
6407      JSR    RO,LA      ;GO CHECK THE WINDOW
6408      RETURN1          ;ERROR RETURN
6409      RETURN2          ;START A SEARCH
6410      RETURN3          ;START A DATA TRANSFER
6411
6412 LA:   MOV    RMADR,R4 ;GET RMCS1'S ADDRESS
6413      MOV    R1,RMCS2(R4) ;SELECT DRIVE
6414      JSR    RO,RO.RM  ;READ DRIVE STATUS
6415      RMDS
6416      4$             ;ERROR RETURN ADDRESS
6417      BIC    #1<020200,(SP) ;ON CYLINDER ?
6418      CMP    #200,(SP)+ ;PIP=0,DRY=1?
6419      BNE   3$             ;NO
6420      INCB  LACNT(R1)    ;INCREMENT THE LOOK AHEAD COUNT
6421      CMPB  LACNT(R1),MXLACT ;EXCEED MAX?
6422      BGT    2$             ;BRANCH IF YES
6423      MOVB  10(R2),R3   ;GET DESIRED SECTOR ADDRESS AND

```



```

6480 026034 100002          BPL      1$          ;BRANCH IF NO
6481 026036 004737 030246    JSR      PC,SVRH70  ;YES--SAVE THE REGISTERS
6482 026042          1$:          ;
6483 026042 004737 031102    JSR      PC,GETREQ  ;GET DPB POINTER
6484 026046 005702          TST      R2          ;ENTRY FOR DRIVE ?
6485 026050 001403          BEQ      2$          ;BR IF NOT
6486 026052 004737 024112    JSR      PC,OPT     ;CALL OPTIMIZER
6487 026056 000417          BR       SC          ;CHECK OTHER DRIVES
6488          ;THE RELEASE DRIVE COMMAND IS FORECD TO ENTER FOR DUAL PORT OPERATION
6489 026060 012714 000113    2$:      MOV      #113,(R4) ;RELEASE THE DRIVE
6490 026064 000414          BR       SC          ;CHECK FOR OTHER DRIVES
6491 026066 052762 100100 000016 3$:      BIS      #BIT15!BIT06,16(R2) ;SET DATA ERROR FLAG
6492 026074 004737 031006    JSR      PC,EMPTYQ  ;EMPTY THE "DRIVE'S WAIT" QUEUE
6493 026100 004737 030246    JSR      PC,SVRH70  ;SAVE THE RH70/RMO3 REGISTERS
6494 026104 012714 040111    MOV      #40111,(R4) ;ISSUE A "DRIVE CLEAR"
6495 026110 012714 000113    MOV      #113,(R4)  ;ISSUE A RELEASE TO THE DRIVE
6496 026114 000400          BR       SC          ;CHECK FOR OTHER DRIVES
6497
6498
6499
6500          ;SPECIAL CONDITION ROUTINE
6501
6502 026116 116403 000016    SC:      MOVB     RMAS(R4),R3 ;READ "RMAS"
6503 026122 001014          BNE      2$          ;BRANCH IF ANY 'ATA' BITS SET
6504 026124 004037 027674    JSR      RD,RD.RM   ;READ CONTROL AND STATUS REGISTER
6505 026130 000000          RMCS1
6506 026132 025272          CIB
6507 026134 106126          ROLB     (SP)+      ;IS "IE"=1?
6508 026136 100405          BMI      1$          ;YES, NO DRIVES TO CHECK
6509 026140 004037 031172    JSR      RD,ES.SAV  ;SAVE THE ADDRESS IN 'ESCAPE'
6510 026144 104001          ERROR    1          ;REPORT AN ILLEGAL INTERRUPT
6511 026146 004737 030364    JSR      PC,SET.IE ;SET INTERRUPT ENABLE
6512 026152 000207          1$:      RTS      PC          ;RETURN
6513 026154 005046          2$:      CLR      -(SP)      ;PROCESS ALL DRIVES THAT HAVE
6514 026156 110316          MOVB     R3,(SP)   ;AN "ATA"=1
6515 026160 012703 000001    MOV      #1,R3
6516 026164 005001          CLR      R1
6517 026166 030316          SC3:     BIT      R3,(SP) ;ATA=1?
6518 026170 001005          BNE      SC5        ;YES--BRANCH
6519 026172 005201          SC4:     INC      R1     ;MOVE TO THE NEXT DRIVE
6520 026174 106303          ASLB     R3
6521 026176 001373          BNE      SC3        ;BRANCH IF MORE TO CHECK?
6522 026200 005726          TST      (SP)+     ;CLEAN OFF THE STACK
6523 026202 000207          RTS      PC          ;RETURN TO USER
6524 026204 105761 022770          SC5:     TSTB     DPINT(R1) ;INITIALIZING THE DRIVE ?
6525 026210 001402          BEQ      1$          ;BR IF NOT
6526 026212 000137 027130          JMP      SC13       ;PROCESS THE DRIVE
6527 026216 105761 023000          1$:      TSTB     DPRQS(R1) ;PORT REQUEST OUTSTANDING ?
6528 026222 001402          BEQ      2$          ;BR IF NOT
6529 026224 000137 027130          JMP      SC13       ;START THE OUTSTANDING COMMAND
6530 026230 105761 022750          2$:      TSTB     DRVSTA(R1) ;CHECK THE DRIVE STATUS
6531 026234 003025          BGT      5$          ;BRANCH IF ONLINE
6532 026236 105761 023016          T:      3          ULDFLG(R1) ;UNLOAD IN PROGRESS?
6533 026242 003422          BLE      5$          ;BRANCH IF NOT
6534 026244 004737 031102          JSR      PC,GETREQ  ;GET DPB POINTER
6535 026250 004737 030246          JSR      PC,SVRH70  ;SAVE THE RH70/RMO3 REGISTERS
    
```

K10

6536	026254	004737	027060		JSR	PC,SC12	;SAVE RMD5, RMR1, RMR2, AND RMMR2
6537							;ALSO DO A DRIVE INIT (DRVINT)
6538	026260	105761	022750		TSTB	DRVSTA(R1)	;DID DRIVE COME ONLINE?
6539	026264	003416			BLE	6\$;NO---BRANCH
6540	026266	032737	040000	022730	BIT	#BIT14,RMERRS	;WAS THERE AN ERROR?
6541	026274	001002			BNE	3\$;BR IF ERROR
6542	026276	000137	026750		JMP	SC11	;NO ERROR
6543	026302	013705	022732	3\$:	MOV	RMERRS+2,R5	;YES -- PICKUP RMR1 AND
6544	026306	000502			BR	SC6A	;GO PROCESS THE ERROR
6545	026310	105761	022740	5\$:	TSTB	DRVACT(R1)	;DRIVE ACTIVE WITH COMMAND OR ERROR RECOVERY ?
6546	026314	001033			BNE	SC6	;BR IF EITHER
6547	026316	004737	027060		JSR	PC,SC12	;SAVE RMD5, RMR1, RMR2, AND RMMR2
6548							;ALSO DO A DRVINT
6549	026322	105761	022770	6\$:	TSTB	DPINT(R1)	;TRYING TO INIT THE DRIVE ?
6550	026326	001321			BNE	SC4	;BR IF YES, CHECK ON MORE DRIVES
6551	026330	105761	022750		TSTB	DRVSTA(R1)	;CHECK ON DRIVE'S STATUS
6552	026334	100412			BMI	7\$;BR IF UNSAFE
6553	026336	032737	020000	022734	BIT	#BIT13,RMERRS+4	;ADDRESS PLUG CHANGED ?
6554	026344	001013			BNE	8\$;BR IF YES
6555	026346	012746	000113		MOV	#113,-(SP)	;RELEASE COMMAND
6556	026352	004037	030054		JSR	RO,WRT.RM	;WRITE THE COMMAND INTO RMCS1
6557	026356	000000			RMCS1		;REGISTER INDEX
6558	026360	026720			SC8		;PARITY EXIT ADDRESS
6559	026362	011605		7\$:	MOV	(SP),R5	;PICKUP (RMAS) BEFORE THE ERROR CALL
6560	026364	004037	031172		JSR	RO,ES.SAV	;SAVE THE ADDRESS IN 'SESCAPE'
6561	026370	104002			ERROR	2	;REPORT THE UNEXPECTED ATTENTION
6562	026372	000677			BR	SC4	;GO CHECK FOR i nter ATA'S
6563	026374			8\$:			
6564	026374	004037	031172		JSR	RO,ES.SAV	;SAVE THE ADDRESS IN 'SESCAPE'
6565	026400	104005			ERROR	5	;REPORT THE ADDRESS PLUG CHANGE
6566	026402	000673			BR	SC4	;CHECK FOR MORE DRIVES
6567	026404	006301		SC6:	ASL	R1	;SETUP TO ADDRESS WORDS
6568	026406	012761	177777	023042	MOV	#-1,TIMER(R1)	;STOP THE TIMER
6569	026414	006201			ASR	R1	;RESTORE THE DRIVE ADDRESS
6570	026416	004737	031102		JSR	PC,GETREQ	;GET THE DPB POINTER FROM THE QUEUE
6571	026422	010164	000010		MOV	R1,RMCS2(R4)	;SELECT DRIVE
6572	026426	004037	027674		JSR	RO,RO.RM	;READ THE RMD3'S STATUS REG.
6573	026432	000012			RMD5		
6574	026434	026720			SC8		
6575	026436	011605			MOV	(SP),R5	;AND PUT IT IN R5
6576	026440	006126			ROL	(SP)+	;WAS THERE AN ERROR?
6577	026442	100407			BMI	1\$;BR IF ERROR
6578	026444	105761	022740		TSTB	DRVACT(R1)	;CHECK DRIVE'S STATE
6579	026450	003137			BGT	SC11	;BR IF DRIVE ACTIVE WITH ORDER
6580	026452	052762	100210	000016	BIS	#BIT15!BIT07!BIT03,16(R2)	;INFORM USER OF ERROR RECOVER COMPLETION
6581	026460	000470			BR	SC7	
6582	026462	004037	027674	9\$:	JSR	RO,RO.RM	;READ ERROR REGISTER #1
6583	026466	000014			RMR1		
6584	026470	026720			SC8		
6585	026472	012605			MOV	(SP)+,R5	;AND SAVE IT IN R5
6586	026474	004737	030246		JSR	PC,SVRH70	;SAVE RH70/RMD3 REGISTERS
6587	026500	012746	000111		MOV	#111,-(SP)	;ISSUE A DRIVE CLEAR
6588	026504	004037	030054		JSR	RO,WRT.RM	
6589	026510	000000			RMCS1		
6590	026512	026720			SC8		
6591	026514	006105		SC6A:	ROL	R5	;WAS "UNSAFE" CONDITION =1?

6592	026516	100406			BMI	1\$;BRANCH IF YES
6593	026520	005702			TST	R2	;ANYTHING IN QUEUE ?
6594	026522	001447			BEQ	SC7	;BR IF NOT
6595	026524	052762	100240	000016	BIS	#BIT15!BIT07!BIT05,16(R2)	;INFORM USER OF ERROR
6596	026532	000443			BR	SC7	
6597	026534	004037	027674		1\$: JSR	RO,RO.RM	;READ DRIVE STATUS REG. #1
6598	026540	000012			RMO3		
6599	026542	026720			SC8		
6600	026544	011605			MOV	(SP),R5	;SAVE RMO3 IN R5
6601	026546	006126			ROL	(SF)+	; "ERR"=1?
6602	026550	100011			BPL	2\$;BR IF NO--UNSAFE CLEARED
6603	026552	112761	177777	022750	MOVB	#-1,DRVSTA(R1)	;DRIVE IS UNSAFE
6604	026560	004737	030246		JSR	PC,SVRH70	;SAVE RH70/RMO3 REGISTERS
6605	026564	052762	110000	000016	BIS	#BIT15!BIT12,16(R2)	;INFORM USER OF UNSAFE ERROR
6606	026572	000423			BR	SC7	
6607	026574	032705	010000		2\$: BIT	#BIT12,R5	; "MOL" = 1 ?
6608	026600	001015			BNE	3\$;BR IF YES
6609	026502	112761	177777	022740	MOVB	#-1,DRVACT(R1)	;ACTIVE ERROR RECOVER
6610	026510	112761	000001	022750	MOVB	#1,DRVSTA(R1)	;ONLINE
6611	026516	006301			ASL	R1	
6612	026520	012761	072460	023042	MOV	#30000.,TIMER(R1)	;START 30 SECOND TIMER
6613	026526	006201			ASR	R1	
6614	026530	000137	026172		JMP	SC4	
6615	026534	052762	100220	000016	3\$: BIS	#BIT15!BIT07!BIT04,16(R2)	;INFORM USER OF ERROR
6616	026542	105061	022740		SC7: CLR	DRVACT(R1)	;DRIVE IS IDLE
6617	026546	004737	031006		JSR	PC,EMPTYQ	;DUMP THE QUEUE
6618	026552	105761	023016		TST	ULDFLG(R1)	;UNLOAD IN PROGRESS OR QUEUE?
6619	026556	003002			BGT	1\$;BR IF NOT
6620	026560	105061	023016		CLR	ULDFLG(R1)	;CLEAR UNLOAD FLAG
6621	026664	116164	023064	000016	1\$: MOV	ATABIT(R1),RMA5(R4)	;CLEAR ATTENTION BIT
6622	026672	105761	022750		TST	DRVSTA(R1)	;IS THE DRIVE UNSAFE ?
6623	026676	100406			BMI	2\$;BR IF IT IS
6624	026700	012746	000113		MOV	#113,-(SP)	;RELEASE COMMAND
6625	026704	004037	030054		JSR	RO,WRT.RM	;WRITE THE COMMAND INTO RPCS1
6626	026710	000000			RMCS1		;REGISTER INDEX
6627	026712	026720			SC8		;PARITY EXIT ADDRESS
6628	026714	000137	026172		2\$: JMP	SC4	;CHECK FOR MORE DRIVES
6629	026720	105761	022740		SC8: TST	DRVACT(R1)	;IS DRIVE IDLE?
6630	026724	001405			BEQ	1\$;YES--BRANCH
6631	026726	004737	031102		JSR	PC,GETREQ	;GET DPB POINTER
6632	026732	004737	025172		JSR	PC,CI7	;PROCESS THE PARITY ERROR
6633	026736	000402			BR	2\$;CONTINUE
6634	026740	004737	025220		1\$: JSR	PC,CI7B	;PROCESS THE UNCORRECTABLE PARITY ERROR
6635	026744	000137	026172		2\$: JMP	SC4	;CHECK MORE DRIVES
6636	026750	105761	023016		SC11: TST	ULDFLG(R1)	; "UNLOAD IN PROGRESS" ?
6637	026754	003402			BLE	1\$;BRANCH IF NO
6638	026756	105061	023016		CLR	ULDFLG(R1)	;CLEAR UNLOAD FLAG
6639	026762	105061	022740		1\$: CLR	DRVACT(R1)	;SET DRIVE IDLE
6640	026766	136137	023064	023012	BIT	ATABIT(R1),SRCHWT	;DOING A SEARCH OPERATION FOR ;AN I/O COMMAND?
6641							
6642	026774	001012			BNE	2\$;BRANCH IF YES
6643	026776	004737	031124		JSR	PC,POPQUE	;REMOVE REQUEST FROM QUEUE
6644	027002	052762	000200	000016	BIS	#BIT07,16(R2)	;SET "DONE" BIT
6645	027010	005737	023036		TST	SAVEFG	;SAVE THE REGISTERS?
6646	027014	100002			BPL	2\$;BRANCH IF NO
6647	027016	004737	030246		JSR	PC,SVRH70	;YES--SAVE ALL OF THE RH70/RMO3 REG'S

M10

```

6648 027022 116164 023064 000016 2$: MOVB ATABIT(R1),RMA5(R4) ;CLEAR ATTENTION BIT
6649 027030 146137 023064 023012 BICB ATABIT(R1),SRCHWT ;CLEAR IMPLIED SEEK SET
6650 027036 006301 ASL R1 ;WORD INDEX
6651 027040 012761 177777 023042 MOV #1,TIMER(R1) ;STOP CLOCK
6652 027046 006201 ASR R1 ;RESTORE R1
6653 027050 004737 024112 JSR PC,OPT ;START A REQUEST
6654 027054 000137 026172 JMP SC4 ;CHECK FOR MORE DRIVES
6655 027060 010164 000010 SC12: MOV R1,RMCS2(R4) ;SELECT DRIVE
6656 027064 016437 000012 022730 MOV RMO5(R4),RMERRS ;SAVE THE FOUR REGISTERS THAT
6657 027072 016437 000014 022732 MOV RMER1(R4),RMERRS+2 ;WILL TELL US SOMETHING
6658 027100 016437 000042 022734 MOV RMER2(R4),RMERRS+4
6659 027106 016437 000040 022736 MOV RMER2(R4),RMERRS+6
6660 027114 004037 023326 JSR RO,DRVINT ;INIT. THE STATE OF THE DRIVE
6661 027120 000401 BR 1$ ;TAKE ERROR EXIT
6662 027122 000207 RTS PC ;RETURN
6663 027124 005726 1$: TST (SP)+ ;POP PC OFF OF THE STACK
6664 027126 000674 BR SC8 ;PROCESS THE PARITY ERROR
6665 027130 006301 SC13: ASL R1 ;SETUP TO ADDRESS WORDS
6666 027132 012761 177777 023042 MOV #1,TIMER(R1) ;STOP THE TIMER
6667 027140 006201 ASR R1
6668 027142 010164 000010 MOV R1,RMCS2(R4) ;SELECT THE DRIVE
6669 027146 116164 023064 000016 MOVB ATABIT(R1),RMA5(R4) ;CLEAR THE ATTENTION BIT
6670 027154 105761 022770 1$: TSTB DPINT(R1) ;INITIALIZING THE DRIVE ?
6671 027160 001424 BEQ 2$ ;BR IF NOT
6672 027162 105061 022770 CLRB DPINT(R1) ;CLEAR THE INIT INDICATOR
6673 027166 004037 023326 JSR RO,DRVINT ;GO INIT THE DRIVE
6674 027172 000240 NOP ;DUMMY PARITY ERROR RETURN
6675 027174 105761 022750 TSTB DRVSTA(R1) ;DRIVE ONLINE ?
6676 027200 003014 BGT 2$ ;BR IF YES -- START ORDER
6677 027202 005702 TST R2 ;QUEUE ENTRY FOR THE DRIVE
6678 027204 001426 BEQ 3$ ;BR IF NOT
6679 027206 004737 031102 JSR PC,GETREQ ;GET DPB ADDRESS
6680 027212 052762 140000 000016 BIS #BIT15:BIT14,16(R2) ;INFORM USER THAT DRIVE OFFLINE
6681 027220 004737 030246 JSR PC,SVRH70 ;SAVE THE REGISTERS
6682 027224 004737 031006 JSR PC,EMPTYQ ;EMPTY THE REQUEST QUEUE
6683 027230 000414 BR 3$
6684 027232 032764 004000 000000 2$: BIT #BIT11,RMCS1(R4) ;DVA SET ?
6685 027240 001006 BNE 4$ ;SET THEN CALL OPT
6686 027242 006301 ASL R1
6687 027244 012761 023420 023042 MOV #10000.,TIMER(R1)
6688 027252 006201 ASR R1
6689 027254 000402 BR 3$
6690 027256 004737 024112 4$: JSR PC,OPT ;START THE PENDING REQUEST
6691 027262 000137 026172 3$: JMP SC4 ;PROCESS OTHER DRIVES
6692
6693 ;/RMO3 TIMER ROUTINE
6694 ;CALL
6695 ;
6696 ; MOV #TIME, -(SP) ;ELAPSED TIME IN MILLISECONDS ON THE STACK
6697 ; JSR PC,RPTMR ;CALL RMO3 TIME ROUTINE
6698
6699 RPTMR: TST ACTDRV ;CHECK "ACTDRV & ACTSTR"
6700 027272 001027 BNE 4$ ;IF NON ZERO EXIT
6701 027274 112737 000001 023015 MOVB #1,ACTSTR ;SET "ACTSTR"
6702 027302 104412 SAVREG ;SAVE R0 - R5
6703 027306 005003 CLR R1 ;START WITH DRIVE 0
        CLR R3
    
```

N10

```

6704 027310 005763 023042      1$:   TST   TIMER(R3)      ; IS THE TIMER RUNNING?
6705 027314 002406                BLT   2$              ; BRANCH IF NO
6706 027316 166663 000002 023042      SUB   2(SP),TIMER(R3) ; COUNT THE INTERVAL
6707 027324 003002                BGT   2$              ; BR IF NO SOFTWARE TIMEOUT
6708 027326 004737 027356      JSR   PC,STO          ; CALL SOFTWARE TIMEOUT ROUTINE
6709 027332 005201                2$:   INC   R1           ; MOVE TO NEXT DRIVE
6710 027334 005723                TST   (R3)+
6711 027336 022701 000010      CMP   #8.,R1         ; OUT OF DRIVES?
6712 027342 003362                BGT   1$              ; BRANCH IF NO
6713 027344 104413                3$:   RESREG          ; RESTORE R0 - R5
6714 027346 105037 023015      CLR   ACTSTR         ; ZERO ACTIVE SOFTWARE TIMEOUT ROUTINE FLAG
6715 027352 012616                4$:   MOV   (SP)+,(SP) ; ADJUST THE STACK
6716 027354 000207                RTS   PC              ; RETURN
6717
6718 ; SOFTWARE TIMEOUT ROUTINE
6719
6720 ; NOTE: THIS ROUTINE MUST BE ENTERED AT PRIORITY 6
6721 ; OR GREATER
6722
6723 ; CALL:
6724 ;   STO
6725 ;   MOV   #DRVNUM,R1   ; DRIVE NUMBER
6726 ;   JSR   PC,STO      ; CALL
6727 ;   RETURN
6728
6728 027356 010146      STO:  MOV   R1,-(SP)   ; SAVE R1
6729 027360 010246      MOV   R2,-(SP)   ; SAVE R2
6730 027362 010346      MOV   R3,-(SP)   ; SAVE R3
6731 027364 010446      MOV   R4,-(SP)   ; SAVE R4
6732 027366 013704 023076      MOV   RMADR,R4   ; GET ADDRESS OF "RMCS1"
6733 027372 010164 000010      MOV   R1,RMCS2(R4) ; SELECT THE DRIVE
6734 027376 004037 027674      JSR   R0,RD.RM   ; READ "DRIVE STATUS REG"
6735 027402 000012      RMD3
6736 027404 027556      STOS
6737 027406 105726      TSTB  (SP)+
6738 027410 100434      BMI   ST02
6739 027412 105761 022770      ST01: TSTB  DPINT(R1)   ; IS "DRY"=1?
6740 027416 001031      BNE   ST02         ; BR IF YES
6741 027420 105761 023000      TSTB  DPRQS(R1)   ; TRYING TO INITIALIZE THE DRIVE ?
6742 027424 001026      BNE   ST02         ; BR IF YES
6743 027426 013702 023010      MOV   TRANSW,R2   ; OUTSTANDING PORT REQUEST FOR THE DRIVE ?
6744 027432 020137 023062      CMP   R1,DTUM     ; BR IF YES
6745 027436 001404      BEQ   1$           ; PICKUP TRANSFER WAIT QUEUE
6746 027440 000137 027662      JMP   ST09        ; TRANSFER UNDERWAY ON THIS DRIVE?
6747 027444 004737 031102      JSR   PC,GETREQ   ; BRANCH IF YES
6748 027450 052762 101000 000016 1$:   BIS   #BIT15:BIT09,16(R2) ; IF NOT DON'T BOTHER DRIVES
6749 027456 004737 030246                JSR   PC,SVRM70   ; GET DPB ADDRESS
6750 027462 012764 000040 000010      MOV   #BIT05,RMCS2(R4) ; SET THE ERROR FLAGS
6751 027470 105061 022740                CLR   DRVACT(R1)  ; SAVE RM70/RMD3 REGISTERS
6752 027474 105061 023016                CLR   ULDFLG(R1) ; "INIT" THE MASS BUS
6753 027500 000470                BR    ST09        ; DRIVE IS IDLE
6754 027502 116405 000016      ST02: MOVB  RMAS(R4),R5  ; CLEAR THE UNLOAD FLAG
6755 027506 136105 023064      BITB  ATABIT(R1),R5 ; DON'T BOTHER OTHER DRIVES
6756 027512 001007                BNE   ST03        ; READ ATTENTION REG
6757 027514 105761 022770      TSTB  DPINT(R1)   ; IS ATTENTION FOR THIS DRIVE UP ?
6758 027520 001021                BNE   ST06        ; YES--BRANCH
6759 027522 105761 023000      TSTB  DPRQS(R1)   ; TRYING TO INITIALIZE THE DRIVE ?
                ; BR IF YES - DRIVE NOT ONLINE
                ; OUTSTANDING PORT REQUEST FOR THE DRIVE ?
    
```

```

6760 027526 001035      BNE      ST07      ;BR IF YES - NO RESPONSE TO REQUEST
6761 027530 000454      BR       ST09      ;OTHER WISE EXIT
6762 027532 105761 022770  ST03:  TSTB   DPINT(R1) ;INITIALIZING THE DRIVE ?
6763 027536 001003      BNE      15        ;BR IF INIT PENDING
6764 027540 105761 023000  TSTB   DPRQS(R1)  ;PORT REQUEST PENDING ?
6765 027544 001446      BEQ      ST09      ;BR IF NOT
6766 027546 012763 177777 023042  15:    MOV    #-1,TIMER(R3) ;STOP THE TIMER
6767 027554 000442      BR       ST09      ;EXIT
6768 027556 004737 025272  ST05:  JSR    PC,C18  ;GO HANDLE THE PARITY ERROR
6769 027562 000437      BR       ST09
6770 027564 105061 022770  ST06:  CLRB   DPINT(R1) ;CLEAR THE INITIALIZE INDICATOR
6771 027570 105061 022750      CLRB   DRVSTA(R1) ;SET UNIT OFFLINE
6772 027574 012763 177777 023042  MOV    #-1,TIMER(R3) ;STOP THE TIMER
6773 027602 004737 031102      JSR    PC,GETREQ  ;GET THE DPB ADDRESS
6774 027606 005702      TST    R2         ;REQUEST IN QUEUE ?
6775 027610 001424      BEQ     ST09      ;BR IF NOT
6776 027612 052762 140000 000016  BIS    #BIT15!BIT14,16(R2) ;INFORM THE USER DRIVE NOT AVAILABLE
6777 027620 000414      BR      ST08
6778 027622 012763 177777 023042  ST07:  MOV    #-1,TIMER(R3) ;STOP THE TIMER
6779 027630 105061 023000      CLRB   DPRQS(R1)  ;CLEAR PORT REQUEST INDICATOR
6780 027634 004737 031102      JSR    PC,GETREQ  ;GET DPB ADDRESS
6781 027640 005702      TST    R2         ;QUEUE ENTRY FOR DRIVE ?
6782 027642 001407      BEQ     ST09      ;BR IF NONE
6783 027644 012762 100004 000016  MOV    #BIT15!BIT2,16(R2) ;INFORM USER OF PORT REQUEST ERROR
6784 027652 004737 031006  ST08:  JSR    PC,EMPTYQ ;CLEAR THE QUEUE FOR THE DRIVE
6785 027656 004737 030246      JSR    PC,SVRH70  ;SAVE THE REGISTERS
6786 027662 012604  ST09:  MOV    (SP)+,R4    ;RESTORE R4
6787 027664 012603      MOV    (SP)+,R3    ;RESTORE R3
6788 027666 012602      MOV    (SP)+,R2    ;RESTORE R2
6789 027670 012601      MOV    (SP)+,R1    ;RESTORE R1
6790 027672 000207      RTS     PC         ;RETURN
6791
6792 ;ROUTINE TO READ A RH70/RMO3 REGISTER
6793 ;CALL
6794 ;
6795 ;JSR    RD, RD.RM ;GO READ A REGISTER
6796 ;INDEX ;REG. INDEX FROM BASE
6797 ;ERRADR ;ERROR ADDRESS--PROCESS ERROR STARTING
6798 ; ;AT THIS ADDRESS
6799 ; ;CONTENTS OF REG. IS ON THE STACK
6800 ;
6801 027674 013737 023074 030042 RD.RM:  MOV    MCPEMX,RD.RM2 ;MAX. RETRYs ALLOWED
6802 027702 011646      MOV    (SP)-,(SP)  ;SAVE RD FOR RETURN
6803 027704 013737 023076 027720  MOV    RMADR,RD.ADR ;FORM THE DESIRED ADDRESS
6804 027712 062037 027720      ADD    (RD)+,RD.ADR ;USING THE BASE AND THE INDEX
6805 027716 013727      RD.RM1: MOV    @((PC)+),(PC)+ ;READ THE DESIRED REGISTER OF THE RMO3
6806 027720 000000      RD.ADR: .WORD 0    ;ADDRESS IS FORMED HERE
6807 027722 000000      RD.WRD: .WORD 0    ;REG. CONTENTS PUT HERE
6808 027724 013766 027722 000002  MOV    RD.WRD,2(SP) ;RETURN IT TO THE USER
6809 027732 013746 023076      MOV    RMADR,-(SP) ;PUT THE ADDRESS ON THE STACK
6810 027736 062716 000010      ADD    #RMC52,(SP) ;FORM THE ADDRESS OF RMC52
6811 027742 032736 010000      BIT    #BIT12,@(SP)+ ;CHECK THE 'MED' BIT
6812 027746 001037      BNE    RD.RM3     ;BR IF DRIVE NON-EXISTENT
6813 027750 017746 173122      MOV    @RMADR,-(SP) ;READ RMC51
6814 027754 032716 020000      BIT    #BIT13,(SP) ;DID MCPE SET?
6815 027760 001002      BNE    15        ;BRANCH IF YES
    
```

```

6816 027762 022620          CMP      (SP)+,(RO)+      ;ADJUST FOR RETURN
6817 027764 000432          BR       RD.RM4          ;EXIT
6818 027766                1$:
6819 027766 004037 031172          JSR     RO,ES.SAV        ;SAVE THE ADDR. SS IN 'SESCAPE'
6820 027772 104003          ERROR   3              ;REPORT "MCPE" ERROR
6821 027774 005737 023062          TST     DTUW            ;DATA TRANSFER UNDERWAY?
6822 030000 100405          SMI     2$              ;NO--BRANCH
6823 030002 032716 040000          BIT     #BIT14,(SP)     ;NO--"TRE"=1?
6824 030006 001402          BEQ     2$              ;NO--BRANCH
6825 030010 005726          TST     (SP)+          ;YES--CLEAN OFF THE STACK AND
6826 030012 000415          BR     RD.RM3          ;TAKE THE FATAL ERROR EXIT
6827 030014 052716 040000          2$:   BIS     #BIT14,(SP) ;CLEAR "MCPE" BY SENDING A "1" TO "TRE"
6828 030020 000316          SWAB   (SP)           ;POSITION BEFORE WRITING
6829 030022 013737 023076 030036          MOV     RMADR,3$       ;FORM ADDRESS OF HIGH BYTE
6830 030030 005237 030036          INC     3$
6831 030034 112637          MOVB   (SP)+,2(PC)+    ;WRITE THE HIGH BYTE OF RMCS1
6832 030036 000000          3$:   .WORD 0           ;ADDRESS STORAGE
6833 030040 005327          DEC     (PC)+          ;EXCEEDED MAX. RETRYS
6834 030042 000003          RD.RM2: .WORD 3
6835 030044 002324          BGE    RD.RM1          ;BRANCH IF NO
6836 030046 011000          RD.RM3: MOV     (RO),RO ;FATAL ERROR EXIT
6837 030050 012616          MOV     (SP)+,(SP)
6838 030052 000200          RD.RM4: RTS     RO
6839
6840          ;ROUTINE TO WRITE A REGISTER
6841          ;CALL
6842          ;
6843          ;
6844          ;
6845          ;
6846          ;
6847          ;
6848          ;
6849 030054 013737 023074 030232 WRT.RM: MOV     MCPMX,WRT.R2 ;MAX RETRYS ALLOWED
6850 030062 016637 000002 030142          MOV     2(SP),WRT.WD   ;SAVE THE WORD TO WRITE
6851 030070 012616          MOV     (SP)+,(SP)     ;ADJUST THE STACK
6852 030072 012037 030144          MC     (RO)+,WRT.AD    ;GET INDEX OF REGISTER TO BE WRITTEN
6853 030076 001015          BNE    1$              ;BRANCH IF NOT RMCS1
6854 030100 122737 000150 030142          CMPB   #150,WRT.WD    ;IS THE COMMAND FOR DATA TRANSFERS?
6855 030106 002411          BLT    1$              ;YES--DON'T GET THE OLD A16 & A17, & PSEL
6856 030110 004037 027674          JSR    RO,RD.RM        ;NO---COMBINE A16&A17, & PSEL WITH
6857 030114 000000          RMCS1 ;THE COMMAND BEFORE SENDING IT TO
6858 030116 030236          WRT.R3 ;THE RM70/RMO3
6859 030120 000316          SWAB   (SP)
6860 030122 042716 177770          BIC     #1C7,(SP)
6861 030126 112637 030143          MOVB   (SP)+,WRT.WD+1 ;
6862 030132 063737 023076 030144          1$:   ADD     RMADR,WRT.AD  ;FORM THE ADDRESS OF THE DISK REG.
6863 030140 012737          WRT.R1: MOV     (PC)+,2(PC)+ ;LOAD THE DESIRED REG.
6864 030142 000000          WRT.WD: .WORD 0       ;WORD TO WRITE GOES HERE
6865 030144 000000          WRT.AD: .WORD 0       ;ADDRESS IS FORMED HERE
6866 030146 013746 023076          MOV     RMADR,-(SP)    ;PUT THE ADDRESS ON THE STACK
6867 030152 062716 000010          ADD     #RMCS2,(SP)   ;FORM THE ADDRESS OF RMCS2
6868 030156 032736 010000          BIT     #BIT12,2(SP)+ ;CHECK THE 'MED' BIT
6869 030162 00 025          BNE    WRT.R3         ;BR IF DRIVE NON-EXISTENT
6870 030164 004037 027674          JSR    RO,RD.RM        ;CHECK FOR PARITY ERROR ON WRITE
6871 030170 000014          RMER1
    
```



```

6872 030172 030236          WRT.R3
6873 030174 032726 000010  BIT      #BIT03,(SP)+
6874 030200 001420          BEQ      WRT.R4          ;BRANCH IF "PAR=0"
6875 030202 016037 177776 030214  MOV      -2(R0),1$      ;PICKUP THE INDEX
6876 030210 004037 027674          JSR      R0,RD.RM      ;READ THE REG.
6877 030214 000000          1$:     .WORD 0          ;REG. INDEX
6878 030216 030236          WRT.R3          ;RETURN TO THIS ADDRESS ON ERROR
6879 030220 004037 031172  JSR      R0,ES.SAV     ;SAVE THE ADDRESS IN 'SESCAPE'
6880 030224 104004          ERROR 4          ;REPORT THE PARITY ON WRITE ERROR
6881 030226 005726          TST      (SP)+        ;CLEAR OFF THE STACK
6882 030230 005327          DEC      (PC)+        ;DECREMENT THE ERROR COUNT
6883 030232 000003          WRT.R2: .WORD 3      ;RETRY COUNTER
6884 030234 002341          BGE      WRT.R1      ;TRY AGAIN IF NOT FINISHED
6885 030236 011000          WRT.R3: MOV      (R0),R0 ;TAKE THE "PARITY ON WRITE" ERROR EXIT
6886 030240 000401          BR       WRT.R5      ;EXIT
6887 030242 005720          WRT.R4: TST      (R0)+ ;ADJUST FOR ERROR FREE EXIT
6888 030244 000200          WRT.R5: RTS      R0
6889
6890          ;ROUTINE TO SAVE THE RH70/RP04/5/RM03 REGISTERS AS PER DPB+14
6891          ;CALL
6892          ;
6893          MOV      #DPBNUM,R2          ;DPB POINTER TO R2
6894          JSR      PC,SVRH70          ;SAVE THE DRIVES REG'S
6895
6896          SVRH70: SAVREG          ;SAVE R0 - R5
6897          TST      R2          ;QUEUE ENTRY FOR THE DRIVE ?
6898          BEQ      6$          ;BR IF NONE
6899          MOV      R2,R4          ;
6900          MOV      (R2),RMC52(R4) ;SELECT DRIVE
6901          MOV      14(R2),R3      ;GET THE ERROR TABLE POINTER
6902          BEQ      6$          ;EXIT IF NO ADDRESS
6903          CLR      3$          ;COUNTER & POINTER
6904          CMP      3$,#RMD8      ;REACHED THE BUFFER REGISTER ?
6905          BNE      2$          ;BR IF NOT
6906          BIT      #BIT07,RMC52(R4) ;'OR' SET ?
6907          BNE      2$          ;BR IF SET
6908          CLR      (R3)+          ;STORE RMD8 AS ZEROES
6909          BR       4$          ;CONTINUE
6910          JSR      R0,RD.RM      ;READ THE SELECTED REGISTER
6911          .WORD 0          ;REGISTER INDEX
6912          5$:     MOV      (SP)+,(R3)+ ;ERROR RETURN ADDRESS
6913          MOV      (SP)+,(R3)+ ;STORE THE REGISTER CONTENTS
6914          CMP      3$,#RMEC2      ;REACHED THE END ?
6915          BEQ      6$          ;BR IF YES
6916          ADD      #2,3$          ;INCREMENT THE REGISTER INDEX
6917          BR       1$          ;CONTINUE READING THE REGISTERS
6918          JSR      PC,C17          ;PROCESS THE UNCORRECTABLE PARITY ERROR
6919          RESREG          ;RESTORE R0 - R5
6920          RTS      PC          ;RETURN
6921
6922          ;ROUTINE TO SET THE INTERRUPT WITHOUT GETTING A "TRE"
6923          ;CALL
6924          MOV      #DRVNUM,R1      ;DRIVE NUMBER TO R1
6925          JSR      PC,SET.IE      ;SET "IE"
6926          RETURN
6927
    
```


E11

```

6928 030364 010446          SET.IE: MOV    R4, -(SP)          ;SAVE R4
6929 030366 013704 023076    MOV    RMAOR, R4          ;PICKUP ADDRESS OF RMCS1
6930 030372 010164 000010    MOV    R1, RMCS2(R4)      ;SELECT DRIVE
6931 030376 011446          MOV    (R4), -(SP)        ;READ RMCS1
6932 030400 052716 040000    BIS    #BIT14, (SP)       ;SET THE "TRE" BIT OF THE WORD READ
6933 030404 000316          SWAB   (SP)               ;ADJUST FOR JATO
6934 030406 112714 000100    MOVB  #BIT06, (R4)        ;SET "IE"
6935 030412 032764 010000 000010 BIT    #BIT12, RMCS2(R4)   ;IS "NEP"=1?
6936 030420 001002          BNE    1$                ;YES CLEAR "TRE"
6937 030422 005726          TST   (SP)+              ;CLEAN OFF THE STACK
6938 030424 000402          BR    2$
6939 030426 112664 000001    1$:  MOVB  (SP)+, 1(R4)     ;CLEAR "TRE"
6940 030432 012604          2$:  MOV   (SP)+, R4       ;RESTORE R4
6941 030434 000207          RTS    PC                 ;RETURN TO CALLER

6942
6943          ; QUEUE COUNT
6944 030436          000          QCNT:  .BYTE  0            ;DRIVE 0
6945 030437          000          .BYTE  0            ;DRIVE 1
6946 030440          000          .BYTE  0            ;DRIVE 2
6947 030441          000          .BYTE  0            ;DRIVE 3
6948 030442          000          .BYTE  0            ;DRIVE 4
6949 030443          000          .BYTE  0            ;DRIVE 5
6950 030444          000          .BYTE  0            ;DRIVE 6
6951 030445          000          .BYTE  0            ;DRIVE 7
6952
6953          ; QUEUE INPUT POINTERS
6954
6955 030446 030530          QINPT: .WORD  QDRV0        ;DRIVE 0
6956 030450 030550          .WORD  QDRV1        ;DRIVE 1
6957 030452 030570          .WORD  QDRV2        ;DRIVE 2
6958 030454 030610          .WORD  QDRV3        ;DRIVE 3
6959 030456 030630          .WORD  QDRV4        ;DRIVE 4
6960 030460 030650          .WORD  QDRV5        ;DRIVE 5
6961 030462 030670          .WORD  QDRV6        ;DRIVE 6
6962 030464 030710          .WORD  QDRV7        ;DRIVE 7
6963
6964          ; QUEUE OUTPUT POINTERS
6965
6966 030466 030530          QOUTPT: .WORD  QDRV0        ;DRIVE 0
6967 030470 030550          .WORD  QDRV1        ;DRIVE 1
6968 030472 030570          .WORD  QDRV2        ;DRIVE 2
6969 030474 030610          .WORD  QDRV3        ;DRIVE 3
6970 030476 030630          .WORD  QDRV4        ;DRIVE 4
6971 030500 030650          .WORD  QDRV5        ;DRIVE 5
6972 030502 030670          .WORD  QDRV6        ;DRIVE 6
6973 030504 030710          .WORD  QDRV7        ;DRIVE 7
6974
6975 030506 030530          QSTART: .WORD  QDRV0        ;DRIVE 0 START ADDRESS
6976 030510 030550          QSTOP:  .WORD  QDRV1        ;DRIVE 0 STOP ADDRESS & DRIVE 1 START ADDRESS
6977 030512 030570          .WORD  QDRV2        ;STOP DRIVE 1--START DRIVE 2
6978 030514 030610          .WORD  QDRV3        ;STOP DRIVE 2--START DRIVE 3
6979 030516 030630          .WORD  QDRV4        ;STOP DRIVE 3--START DRIVE 4
6980 030520 030650          .WORD  QDRV5        ;STOP DRIVE 4--START DRIVE 5
6981 030522 030670          .WORD  QDRV6        ;STOP DRIVE 5--START DRIVE 6
6982 030524 030710          .WORD  QDRV7        ;STOP DRIVE 6--START DRIVE 7
6983 030526 030730          .WORD  QTERM        ;STOP DRIVE 7
    
```

```

6984
6985 ;DRIVE REQUEST QUEUES
6986
6987 030530 000010 QDRV0: .BLKW 10
6988 030550 000010 QDRV1: .BLKW 10
6989 030570 000010 QDRV2: .BLKW 10
6990 030610 000010 QDRV3: .BLKW 10
6991 030630 000010 QDRV4: .BLKW 10
6992 030650 000010 QDRV5: .BLKW 10
6993 030670 000010 QDRV6: .BLKW 10
6994 030710 000010 QDRV7: .BLKW 10
6995 030730 QTERM=.
6996
6997 ;ROUTINE TO CLEAR ALL OF THE REQUEST QUEUES
6998
6999 ;CALL
7000 ; JSR PC,CLRQUE
7001
7002 030730 104412 CLRQUE: SAVREG ;SAVE R0 - R5
7003 030732 012702 MOV #QCNT,R2 ;ZERO THE QUEUE COUNTS
7004 030736 005022 CLR (R2)+ ;DRIVES 0 & 1
7005 030740 005022 CLR (R2)+ ;DRIVES 2 & 3
7006 030742 005022 CLR (R2)+ ;DRIVES 4 & 5
7007 030744 005022 CLR (R2)+ ;DRIVES 6 & 7
7008 030746 012703 MOV #8,R3 ;MOVE THE STARTING
7009 030752 012701 MOV #QSTART,R1 ;ADDRESS OF THE QUEUE INTO
7010 030756 012122 1$: MOV (R1)+,(R2)+ ;THE QUEUE INPUT POINTER
7011 030760 005303 DEC R3
7012 030762 001375 BNE 1$
7013 030764 012703 MOV #8,R3 ;MOVE THE STARTING ADDRESS
7014 030770 012701 MOV #QSTART,R1 ;OF THE QUEUE INTO THE
7015 030774 012122 2$: MOV (R1)+,(R2)+ ;QUEUE OUTPUT POINTER
7016 030776 005303 DEC R3
7017 031000 001375 BNE 2$
7018 031002 104413 RESREG ;RESTORE R0 - R5
7019 031004 000207 RTS PC
7020
7021 ;EMPTY THE QUEUE SPECIFIED BY R1
7022
7023 ;CALL
7024 ; MOV DRVNUM,R1 ;DRIVE NUMBER TO R1
7025 ; JSR PC,EMPTYQ
7026
7027 031006 105061 030436 EMPTYQ: CLRB QCNT(R1) ;CLEAR NUMBER OF ITEMS IN QUEUE
7028 031012 006301 ASL R1
7029 031014 016161 030446 030466 MOV QINPT(R1),QOUTPT(R1) ;SET OUTPUT QUEUE POINTER=INPUT POINTER
7030 031022 006201 ASR R1
7031 031024 000207 RTS PC
7032
7033 ;ROUTINE TO PUT A REQUEST IN QUEUE
7034
7035 ;CALL
7036 ; MOV #DRVNUM,R1 ;DRIVE NUMBER
7037 ; MOV #DPB,R2 ;ADDRESS OF PARAMETER BLOCK
7038 ; JSR RO,DRVQUE ;GO PUT REQUEST IN QUEUE
7039 ; RETURNI ;RETURN HERE IF QUEUE IS FULL
    
```

G11

MAINDEC-11-DZRM1 AO/00, RM03 DRIVE COMPATIBILITY TEST MACY11 30(1046) 21-JUL-77 16:51 PAGE 136
 DZRM1A.P11 21-JUL-77 15:44 SINGLE/DUAL PORT RH70/RM03 DRIVER (REV 1.0)

SEQ 0135

```

7040 ; RETURN2 ; RETURN HERE IF REQUEST IS IN QUEUE
7041
7042 031026 122761 000010 030436 DRVQUE: CMPB #10, QCNT(R1) ; IS QUEUE FULL?
7043 031034 001421 BEQ 2$ ; BR IF YES-TAKE RETURN1
7044 031036 105261 030436 INCB QCNT(R1) ; INCREMENT QUEUE COUNT
7045 031042 006301 ASL R1
7046 031044 010271 030446 MOV R2, QINPT(R1) ; PUT THIS REQUEST IN QUEUE
7047 031050 062761 000002 030446 ADD #2, QINPT(R1) ; UPDATE THE QUEUE POINTER
7048 031056 026161 030446 030510 CMP QINPT(R1), QSTOP(R1) ; TIME TO RESET THE POINTER
7049 031064 001003 BNE 1$ ; BRANCH IF NO
7050 031066 016161 030506 030446 MOV QSTART(R1), QINPT(R1) ; YES--RESET POINTER
7051 031074 006201 1$: ASR R1
7052 031076 005720 TST (R0)+ ; TAKE RETURN 2
7053 031100 000200 2$: RTS R0 ; RETURN TO USER
7054
7055 ; ROUTINE TO GET THE "DPB" ADDRESS OF NEXT REQUEST IN QUEUE
7056
7057 ; CALL
7058 ; MOV #DRVNUM, R1 ; DRIVE NUMBER TO R1
7059 ; JSR PC, GETREQ ; GO GET THE REQUEST
7060 ; RETURN ; R2="DPB" ADDRESS OF THE REQUEST
7061 ; ; R2=0 IF NO REQUEST IN QUEUE
7062
7063 031102 005002 GETREQ: CLR R2
7064 031104 105761 030436 TSTB QCNT(R1) ; IS THERE ANY REQUEST IN QUEUE?
7065 031110 001404 BEQ 2$ ; NO---BRANCH
7066 031112 006301 1$: ASL R1
7067 031114 017102 030466 MOV QOUTPT(R1), R2 ; PICKUP "DPB" POINTER FOR THIS DRIVE
7068 031120 006201 ASR R1
7069 031122 000207 2$: RTS PC ; RETURN TO USER
7070
7071 ; ROUTINE TO "POP" THE REQUEST FROM QUEUE
7072
7073 ; CALL
7074 ; MOV #DRVNUM, R1 ; DRIVE NUMBER TO R1
7075 ; JSR PC, POPQUE ; CALL TO REMOVE REQUEST
7076 ; RETURN ; R2=ADDRESS OF DPB REMOVED
7077
7078 031124 105361 030436 POPQUE: DECB QCNT(R1) ; DECREMENT QUEUE COUNT
7079 031130 006301 ASL R1
7080 031132 017102 030466 MOV QOUTPT(R1), R2 ; GET THE "DPB" POINTER
7081 031136 005071 030466 CLR QOUTPT(R1) ; REMOVE DPB ADDRESS FROM THE QUEUE
7082 031142 062761 000002 030466 ADD #2, QOUTPT(R1) ; UPDATE THE QUEUE POINTER
7083 031150 026161 030466 030510 CMP QOUTPT(R1), QSTOP(R1) ; TIME TO RESET THE POINTER?
7084 031156 001003 BNE 1$ ; NO--BRANCH TO EXIT
7085 031160 016161 030506 030466 MOV QSTART(R1), QOUTPT(R1) ; YES--RESET THE POINTER
7086 031166 006201 1$: ASR R1
7087 031170 000207 RTS PC ; RETURN TO USER
7088
7089 ; ROUTINE TO SAVE THE CONTENTS OF 'ESCAPE' WHEN THE DRIVER
7090 ; REPORTS AN ERROR DIRECTLY.
7091
7092 ; CALL
7093 ; JSR ERROR, R0, ES.SAV
7094 ; ERROR N ; THE ERROR CALL
7095 ; RETURN ; THE RETURN IS PAST THE ERROR CALL

```

H11

```

7096
7097 031172 012037 031206 ES.SAV: MOV (R0)+,1$ ;GET THE ERROR CALL
7098 031176 013746 001176 MOV $ESCAPE,-(SP) ;SAVE THE ADDRESS IN 'ESCAPE'
7099 031202 005037 001176 CLR $ESCAPE ;CLEAR THE ESCAPE RETURN
7100 031206 000000 1$: .WORD 0 ;THE ERROR CALL IS MOVED HERE
7101 031210 012637 001176 MOV (SP)+,$ESCAPE ;RESTORE THE ESCAPE ADDRESS
7102 031214 000200 RTS R0 ;RETURN
7103
7104 ;*****
7105 .SBTTL DATA, CONTROL, & STATUS BLOCKS
7106
7107 ;*****
7108
7109 .SBTTL ROUTINE TO SIZE MEMORY
7110
7111 ;*****
7112 ;*CALL:
7113 ;* JSR PC,$SIZE
7114 ;* RETURN
7115 ;*$LSTAD WILL CONTAIN THE LAST AVAILABLE MEMORY LOCATION
7116
7117 $SIZE: MOV R0,-(SP) ;SAVE R0 ON THE STACK
7118 031216 010046 MOV R1,-(SP) ;SAVE R1 ON THE STACK
7119 031220 010146 MOV @#ERRVEC,-(SP) ;SAVE PRESENT ERROR VECTOR PS & PC
7120 031222 013746 000004 MOV @#ERRVEC+2,-(SP)
7121 031226 013746 000006 MOV SP,R0 ;SAVE THE STACK POINTER
7122 031232 010600 ;;SET THE ERRVEC PS TO THE PRESENT PS
7123 TRAP ;;PUSH OLD PSW AND PC ON STACK
7124 031234 104400 MOV (SP)+,@#ERRVEC+2 ;;SAVE THE PSW IN @#ERRVEC+2
7125 031236 012637 000006 000004 MOV #2$,@#ERRVEC ;;SET FOR TIMEOUT
7126 031242 012737 031262 MOV #2000,R1 ;;FIRST ADDRESS
7127 031250 012701 020000 1$: TST (R1) ;;TEST THIS ADDRESS
7128 031254 005711 TST (R1)+ ;;STEP TO NEXT ADDRESS
7129 031256 005721 BR 1$ ;;TRY ANOTHER
7130 031260 000775 2$: SUB #2,R1 ;;DROP BACK
7131 031262 162701 000002 MOV R0,SP ;;RESTORE THE STACK
7132 031266 010006 MOV (SP)+,@#ERRVEC+2 ;;RESTORE ERROR VECTOR
7133 031270 012637 000006 MOV (SP)+,@#ERRVEC
7134 031274 012637 000004 MOV R1,$LSTAD ;;LAST ADDRESS
7135 031300 010137 031312 MOV (SP)+,R1 ;;RESTORE R1
7136 031304 012601 MOV (SP)+,R0 ;;RESTORE R0
7137 031306 012600 RTS PC
7138 031310 000207 $LSTAD: .WORD 0 ;;CONTAINS THE LAST ADDRESS
7139 031312 000000
7140
7141 .SBTTL BUSADR - GET BUS ADDRESS AND VECTOR ADDRESS FOR RH11
7142 ;THIS ROUTINE IS USED TO INSURE THE BUS ADDRESS
7143 ;OF THE RH11 IS SETUP FOR THE PROPER ADDRESS.
7144 ;IT WILL ALSO READ THE ADDRESS FROM THE TTY IF
7145 ;REQUIRED.
7146 ;NOTE: THIS ROUTINE DESTROYS R0-R4
7147 ;CALL
7148
7149 ; JSR PC,BUSADR
7150 ; RETURN
7151 ;
  
```

```

7152 031314 104412          BUSADR: SAVREG          :SAVE ALL REG
7153 031316 012700 001274 1$:  MOV      #SRMADR,R0      ;FIRST ADDRESS
7154 031322 104401 031464   TYPE      MRMCSI        ;"RMCSI="
7155 031326 011046          MOV      (R0),-(SP)     ;PRESENT RMCSI ADDRESS
7156 031330 104402          TYPOC          ;TYPE IT
7157 031332 104401 036121   TYPE      ,LINSF       ;2 SPACES
7158 031336 104411          RDLIN         ;GET THE ENTRY
7159 031340 012601          MOV      (SP)+,R1      ;ADDRESS OF ASCII TEXT
7160 031342 004537 031506   JSR      R5,CK.NUM     ;ENTER AND STORE THE NEW ADDRESS
7161 031346 000763          BR       1$           ;ERROR EXIT
7162 031350 012700 001276 2$:  MOV      #SRMVEC,R0    ;VECTOR ADDRESS
7163 031354 104401 031475   TYPE      MRHVEC       ;"RHVEC="
7164 031360 011046          MOV      (R0),-(SP)   ;PRESENT RH11 VECTOR ADDRESS ON THE STACK
7165 031362 104402          TYPOC          ;TYPE IT
7166 031364 104401 036121   TYPE      ,LINSF       ;2 SPACES
7167 031370 104411          RDLIN         ;READ THE ENTRY
7168 031372 012601          MOV      (SP)+,R1      ;ASCII TEXT ADDRESS
7169 031374 004537 031506   JSR      R5,CK.NUM     ;ENTER AND STORE NEW ADDRESS
7170 031400 000763          BR       2$           ;ERROR EXIT
7171 031402 012700 001274 3$:  MOV      #SRMADR,R0    ;FIRST ADDRESS OF NEW PARAMETERS
7172 031406 012701 023076   MOV      #RMADR,R1     ;FIRST ADDRESS OF WHERE TO PUT THEM
7173 031412 013705 000004   MOV      @#ERRVEC,R5   ;SAVE ERROR VECTOR
7174 031416 012737 031442 000004  MOV      #45,@#ERRVEC  ;LOAD NEW VECTOR ADDRESS
7175 031424 005777 147644   TST     @SRMADR        ;LEGAL I/O ADDRESS ?
7176 031430 010537 000004   MOV      R5,@#ERRVEC   ;YES IF NOT TRAP TO TIMEOUT
7177 031434 012021          MOV      (R0)+,(R1)+  ;LOAD THE BUS ADDRESS
7178 031436 012021          MOV      (R0)+,(R1)+  ;LOAD VECTOR ADDRESS
7179 031440 000407          BR       6$           ;COMMON EXIT
7180 031442 012716 031450 4$:  MOV      #5$, (SP)     ;SET RETURN ADDRESS
7181 031446 000002          RTI              ;RETRUN FROM TIME OUT TRAP
7182 031450 104006          ERROR      6         ;NO RESPONSE FROM RMADR
7183 031452 010537 000004   MOV      R5,@#ERRVEC   ;RESTORE THE TIME OUT TRAP
7184 031456 000717          BR       1$           ;TRY AGAIN
7185 031460 104413          6$:  RESREG          ;RESTORE ALL REG
7186 031462 000207          RTS      PC
7187
7188 031464 046522 051503 020061 MRMCSI: .ASCIZ @RMCSI = @
7189 031472 020075 000          000
7190 031475 122 053110 041505 MRHVEC: .ASCIZ @RHVEC = @
7191 031502 036440 000040
7192
7193          .SBTTL CK.NUM - CHECK NUMBER (OCTAL)
7194          ;THIS ROUTINE CHECKS AN ASCIZ STRING FOR LEGAL CHARACTERS
7195          ;AND FORMS AN OCTAL NUMBER IN R2
7196          ;CALL:
7197          ;      MOV      #ADR,R1          ;ADDRESS OF ASCIZ STRING
7198          ;      JSR      R5,CK.NUM       ;R5 CHANGED
7199          ;      RET              ;ERROR EXIT
7200          ;      RET              ;NORMAL EXIT
7201 CK.NUM:  MOV      R2,-(SP)          ;SAVE R2
7202          MOV      R3,-(SP)          ;SAVE R3
7203          MOV      R4,-(SP)          ;SAVE R4
7204          MOV      #6,R3            ;MAX OCTAL DIGITS IN THE NUMBER
7205          CLR      R2                ;FINAL OCTAL VALUE
7206          1$:  MOVB   (R1)+,R4          ;GET CURRENT POINTED BYTE
7207          BEQ     3$                ;BRANCH, IF TERMINATOR DETECTED

```

```

7208 031526 120427 000060      CMPB   R4,#'0      ;SMALLER THAN ASCII-0 ?
7209 031532 103425              BLO    5$          ;YES, ERROR EXIT
7210 031534 120427 000067      CMPB   R4,#'7      ;LARGER THAN ASCII-7 ?
7211 031540 101022              BHI    5$          ;YES, ERROR EXIT
7212 031542 006302              ASL    R2          ;SHIFT LEFT
7213 031544 103420              BCS    5$          ;
7214 031546 006302              ASL    R2          ;ONE
7215 031550 103416              BCS    5$          ;
7216 031552 006302              ASL    R2          ;OCTAL DIGIT
7217 031554 103414              BCS    5$          ;ERROR IF CARRY BIT SET
7218 031556 042704 177770      BIC    #177770,R4 ;CHOP OFF HIGHER BITS
7219 031562 060402              ADD    R4,R2      ;APPENDING CURRENT DIGIT TO NUMBER
7220 031564 005303              DEC    R3          ;DECREMENT BYTE COUNT
7221 031566 001401              BEQ    2$          ;BRANCH, IF LAST BYTE
7222 031570 000754              BR     1$          ;LOOPING BACK
7223 031572 112104 2$:      MOVB   (R1)+,R4    ;CHECK TERMINATOR
7224 031574 001004              BNE    5$          ;ERROR EXIT
7225 031576 005702 3$:      TST    R2          ;FINAL VALUE = 0
7226 031600 001402              BEQ    5$          ;YES, TAKE ERROR EXIT
7227 031602 010210              MOV    R2,(R0)    ;REPLACE THE ORIGINAL VALUE
7228 031604 005725 4$:      TST    (R5)+      ;ADJUST FOR NORMAL RETURN
7229 031606 012604 5$:      MOV    (SP)+,R4   ;RESTORE R4
7230 031610 012603              MOV    (SP)+,R3   ;RESTORE R3
7231 031612 012602              MOV    (SP)+,R2   ;RESTORE R2
7232 031614 000205              RTS    R5          ;EXIT

```

```

7233
7234 ;*****
7235
7236 .SBTTL  ERROR MESSAGES
7237
7238 ;*****
7239
7240 .NLIST  BEX

```

- 031616 044122 03J067 030450 EM1: .ASCIZ /RH70(11) INTERRUPT OCCURRED (RMAS = 0)/
- 031665 125 042516 050130 EM2: .ASCIZ /UNEXPECTED ATTENTION OCCURRED/
- 031723 115 051501 041123 EM3: .ASCIZ /MASSBUS PARITY ERROR (MCPE=1)/
- 031761 115 051501 041123 EM4: .ASCIZ /MASSBUS PARITY ERROR (PAR=1)/
- 032016 042101 051104 051505 EM5: .ASCIZ /ADDRESS PLUG CHANGE BIT SET/
- 032052 044122 030461 033450 EM6: .ASCIZ /RH11(70) DIDN'T RESPOND TO ADDRESSING/
- 032120 047125 047503 051122 EM10: .ASCIZ /UNCORRECTABLE MASSBUS PARITY ERROR/
- 032163 106 052101 046101 EM11: .ASCIZ /FATAL MASSBUS PARITY ERROR/
- 032216 042520 051522 051511 EM12: .ASCIZ /PERSISTENT DEVICE UNSAFE/
- 032247 117 042520 040522 EM13: .ASCIZ /OPERATION NOT COMPLETED WITHIN TIME LIMIT/
- 032321 104 044522 042526 EM14: .ASCIZ /DRIVE WENT OFFLINE/

032344	047516	051040	051505	EM15:	.ASCIZ	/NO RESPONSE TO PORT REQUEST/
032400	042510	042101	051105	EM20:	.ASCIZ	/HEADER CRC ERROR/
032421	104	052101	020101	EM21:	.ASCIZ	/DATA CHECK ('DCK') ERROR/
032452	051127	052111	020105	EM22:	.ASCIZ	/WRITE CHECK ERROR - DATA CHECK ('DCK') SET/
032525	127	044522	042524	EM23:	.ASCIZ	/WRITE CHECK ERROR - DATA CHECK ('DCK') NOT SET/
032604	042510	042101	051105	EM24:	.ASCIZ	/HEADER READ ERROR - 'FMT' BIT DROPPED/
032652	042510	042101	051105	EM25:	.ASCIZ	/HEADER READ ERROR - HEADER COMPARE ('HCE') ERROR/
032733	106	051117	040515	EM26:	.ASCIZ	/FORMAT ERROR ('FER')/
032760	042510	042101	051105	EM27:	.ASCIZ	/HEADER COMPARE ('HCE') ERROR/
033015	115	051511	042503	EM30:	.ASCIZ	/MISCELLANEOUS DRIVE ERROR/
033047	117	042520	040522	EM31:	.ASCIZ	/OPERATION INCOMPLETE ('OPI') ERROR/
033112	051104	053111	020105	EM32:	.ASCIZ	/DRIVE TIMING ('DTE') ERROR/
033145	120	051101	052111	EM33:	.ASCIZ	/PARITY ('PAR') ERROR AFTER OPERATION STARTED/
033222	051127	052111	020105	EM34:	.ASCIZ	/WRITE CLOCK FAILURE ('WCF') ERROR/
033264	047111	040526	044514	EM35:	.ASCIZ	/INVALID ADDRESS ('IAE') ERROR/
033322	051127	052111	020105	EM36:	.ASCIZ	/WRITE LOCK ('WLE') ERROR/
033353	104	052101	020101	EM37:	.ASCIZ	/DATA CHECK ('DCK') SET DURING WRITE CHECK COMMAND/
033435	122	030510	024061	EM40:	.ASCIZ	/RH11(70) OR UNIBUS TRANSFER ERROR/
033477	102	051525	040440	EM41:	.ASCIZ	/BUS ADDRESS OR WORD COUNT INCORRECT/
033543	104	052101	020101	EM42:	.ASCIZ	/DATA COMPARE ERRORS - NO OTHER ERROR(S) DETECTED/
033624	040503	023516	020124	EM43:	.ASCIZ	/CAN'T MATCH DATA READ WITH A PATTERN/
033671	105	051122	051117	EM44:	.ASCIZ	/ERROR BIT(S) SET, BUT NO ERROR SIGNALLED BY THE RH11/
033755	105	041503	046040	EM45:	.ASCIZ	/ECC LOGIC FAILURE - POSITION REGISTER VALUE NOT VALID/
034043	102	051525	040440	EM46:	.ASCIZ	/BUS ADDRESS AND WORD COUNT NOT CONSISTENT/
034115	123	042505	020113	EM50:	.ASCIZ	/SEEK INCOMPLETE ('SKI') ERROR/
034153	120	047522	051107	EM51:	.ASCIZ	/PROGRAM DETECTED POSITIONING ERROR/
034216	051104	053111	020105	EM60:	.ASCIZ	/DRIVE UNSAFE ERROR/
034241	040	000040		EM61:	.ASCIZ	/ /
				.EVEN		

034244	046522	051501	020040	DH1:	.ASCIZ	/RMAS	/						
034253	104	044522	042526	DH2:	.ASCIZ	/DRIVE	RMDS	RMER1	RMER2	RMMR2	RMAS	/	
034335	104	044522	042526	DH3:	.ASCIZ	/DRIVE	REG ADR	DATA	/				
034366	051104	053111	020105	DH4:	.ASCIZ	/DRIVE	REG ADR	GOOD	BAD	/			
034430	046522	042101	020122	DH6:	.ASCIZ	/RMADR	/						
034441	104	044522	042526	DH7:	.ASCIZ	/DRIVE	RMCS1	RMWC	RMBA	RMDA	/		
034512	046522	051503	020062	DH10:	.ASCIZ	/RMCS2	RMDS	RMER1	RMAS	RMDB	/		
034563	122	046515	030522	DH11:	.ASCIZ	/RMMR1	RMDT	RMOF	RMDC	RMMR2	/		
034634	046522	051105	020062	DH12:	.ASCIZ	/RMER2	RMEC1	RMEC2	/				
	034666					.EVEN							

.LIST BEX

7241													
7242	034666	001324	000000	DT1:	.WORD	ATTN,0							
7243	034672	001222	022730	DT2:	.WORD	DRIVE, RMERRS, RMERRS+2, RMERRS+4, RMERRS+6, ATTN,0							
7244	034700	022734	022736										
7245	034706	000000											
7246	034710	001222	027720	DT3:	.WORD	DRIVE, RD. ADR, RD. WRD, 0							
7247	034716	000000											
7248	034720	001222	030144	DT4:	.WORD	DRIVE, WRT. AD, WRT. WD, RD. WRD, 0							
7249	034726	027722	000000										
7250	034732	023076	000000	DT6:	.WORD	RMADR, 0							
7251	034736	001222	037166	DT7:	.WORD	DRIVE, RM. REG, RM. REG+2, RM. REG+4, RM. REG+6, 0							
7252	034744	037172	037174										
7253	034752	037176	037200	DT10:	.WORD	RM. REG+10, RM. REG+12, RM. REG+14, RM. REG+16, RM. REG+22, 0							
7254	034760	037204	037210										
7255	034766	037212	037214	DT11:	.WORD	RM. REG+24, RM. REG+26, RM. REG+32, RM. REG+36, RM. REG+40, 0							
7256	034774	037224	037226										
7257	035002	037230	037232	DT12:	.WORD	RM. REG+42, RM. REG+44, RM. REG+46, 0							
7258	035010	000000											

:

7261													
7262	035012	000		DF1:	.BYTE	0							
7263	035013	000	000	DF2:	.BYTE	0,0,0,0,0,0							
7264	035016	000	000										
7265	035021	000	000	DF3:	.BYTE	0,0,0							
7266	035024	000	000	DF4:	.BYTE	0,0,0,0							
7267	035027	000											
7268						.EVEN							

.NLIST BEX

035030	052523	051502	051531	MSG1:	.ASCIZ	/SUBSYS	/						
035041	104	044522	042526	MSG2:	.ASCIZ	/DRIVE(S)	/						
035053	052	020052	052123	MSG3:	.ASCIZ	** STARTING PASS 1 **	/						
035101	115	052517	052116	MSG4:	.ASCIZ	/MOUNT PACK ON DRIVE	/						
035127	101	042116	046040	MSG8:	.ASCIZ	/AND LOAD.	/						
035142	054524	042520	051040	MSG9:	.ASCIZ	/TYPE R<CR> WHEN DRIVE READY :	/						
035201	104	044522	042526	MSG10:	.ASCIZ	/DRIVE IS NOT READY, TEST IS ABORTED/							
035245	120	041501	020113	MSG11:	.ASCIZ	/PACK IS NOT ACCEPTABLE, CHANGE PACK , TRY AGAIN/							
035323	125	046116	040517	MSG12:	.ASCIZ	/UNLOAD DRIVE	/						
035341	040	040440	042116	MSG13:	.ASCII	/ AND REMOVE PACK/<CR><LF>							
035364	054524	042520	051040		.ASCIZ	/TYPE R<CR> WHEN DONE :	/						
035414	025052	051440	040524	MSG14:	.ASCIZ	** STARTING PASS 2 **	/						
035442	025040	020052	046101	MSG15:	.ASCIZ	/ ** ALL DRIVES ARE COMPATIBLE **	/						


```

035503 123 047503 042522 MSG16: .ASCIZ /SCORES FOR DRIVE /
035526 051124 041501 020113 MSG17: .ASCIZ /TRACK DRIVE OVRWRT OVRWRT READ READ/
035622 047516 020056 020040 MSG18: .ASCIZ /NO. READ OFST- OFST+ OFST- OFST+ /
035717 040 051440 046105 SELFX: .ASCII / SELF/
035725 011 000 TAB: .BYTE 11,0 ;THE SEQUENCE OF SELFX,TAB MUST BE NOT REVERSED.
035727 040 020052 060 MARKX: .ASCII / * 0/
035733 011 000 .BYTE 11,0
035735 054 000 COMMA: .ASCIZ / /
035737 127 046111 020114 MSG5: .ASCIZ /WILL TEST /
035752 047117 000040 MSG6: .ASCIZ /ON /
035756 051511 052040 042510 MSG7: .ASCIZ /IS THERE ANOTHER SUB-SYSTEM (Y OR N<CR>) ? /
036031 116 052117 040440 NOTRM: .ASCIZ /NOT AN RM03/
036045 040 047516 020124 NOTSAF: .ASCIZ / NOT SAFE /
036057 040 047516 020124 NOTPRS: .ASCIZ / NOT PRESENT /
036074 047440 043106 044514 UNTOFF: .ASCIZ / OFFLINE /
036105 040 047117 044514 UNTON: .ASCIZ / ONLINE /
036115 040 020040 040 LIN4SP: .ASCII / /
036121 040 000 LINSP: .ASCIZ / /
036123 122 030115 000063 RM03A: .ASCIZ /RM03/
036130 005015 023440 023514 NEDCLK: .ASCIZ <CR><LF> / 'L' OR 'P' CLOCK REQUIRED ON SYSTEM/<CR><LF>
036201 072 000 COLON: .ASCIZ / /
036203 105 052116 051105 ENTDRV: .ASCIZ /ENTER I.D. FOR DRIVE # /
036232 020077 047111 040526 BADENT: .ASCIZ /? INVALID ENTRY /
036252 047105 042524 020122 ENADR: .ASCIZ /ENTER BAD TRK/SEC ADDRESSES FOR DRV # /
036316 027440 000040 SLASH: .ASCIZ / /
036322 000077 QUES: .ASCIZ /? /
036324 051104 053111 000105 UNTMSG: .ASCIZ /DRIVE /
036332 000040 LINSPO: .ASCIZ / /
036334 051104 053111 020105 STATUS: .ASCIZ /DRIVE STATUS /
036351 040 020040 041040 MSG19: .ASCIZ / BAD SPOT FILE /
036375 040 025052 020040 MSG20: .ASCIZ / ** END OF TEST ** /
036424 051104 053111 020105 MSG21: .ASCIZ /DRIVE NOT ON-LINE OR NOT ASSIGNED/<CR><LF>
036467 120 047522 051107 .ASCIZ /PROGRAM HALT/<CR><LF>

```

.EVEN

.LIST BEX

;HISTORY FILE FOR 15 LOGICAL DRIVES:(0-17)

```

SFMT = 1 ;COMMAND CODE
$COMND = SFMT+1 ;PRO. SELECT AND A16,A17
$PSEL = SFMT+2 ;WORD COUNT
$WROM = SFMT+3 ;BUFFER ADDRESS
$BUF = SFMT+5 ;SECTOR ADDRESS
$SEC = SFMT+7 ;TRACK ADDRESS
$TRK = SFMT+10 ;CYLINDER ADDRESS
$CYL = SFMT+11 ;SUB SYSTEM A-H
$SYSNM = SFMT+13 ;PHYSICAL DRIVE CODE (ASCII )
$PHYDR = SFMT+14 ;LEFT TWO NULL BYTES
$GAP = SFMT+15 ;END OF HISTORY TABLE
$EMTAB = $GAP+4

```

```

7271
7272
7273
7274 000001
7275 000002
7276 000003
7277 000004
7278 000006
7279 000010
7280 000011
7281 000012
7282 000014
7283 000015
7284 000016
7285 000022
7286
7287 036506 000 000
7288 036510 000020

```

```

DRIVO: .BYTE 7&0,0 ;HISTORY BLOCK OF LOGICAL DRIVE 0
.BLKB $EMTAB-$COMND

```

7289	036530	001	000	DRIV1:	.BYTE	781,0	:HISTORY BLOCK OF LOGICAL DRIVE 1
7290	036532	000020			.BLKB	SEMTAB-SCOMND	
7291	036552	002	000	DRIV2:	.BYTE	782,0	:HISTORY BLOCK OF LOGICAL DRIVE 2
7292	036554	000020			.BLKB	SEMTAB-SCOMND	
7293	036574	003	000	DRIV3:	.BYTE	783,0	:HISTORY BLOCK OF LOGICAL DRIVE 3
7294	036576	000020			.BLKB	SEMTAB-SCOMND	
7295	036516	004	000	DRIV4:	.BYTE	784,0	:HISTORY BLOCK OF LOGICAL DRIVE 4
7296	036520	000020			.BLKB	SEMTAB-SCOMND	
7297	036540	005	000	DRIV5:	.BYTE	785,0	:HISTORY BLOCK OF LOGICAL DRIVE 5
7298	036542	000020			.BLKB	SEMTAB-SCOMND	
7299	036562	006	000	DRIV6:	.BYTE	786,0	:HISTORY BLOCK OF LOGICAL DRIVE 6
7300	036564	000020			.BLKB	SEMTAB-SCOMND	
7301	036704	007	000	DRIV7:	.BYTE	787,0	:HISTORY BLOCK OF LOGICAL DRIVE 7
7302	036706	000020			.BLKB	SEMTAB-SCOMND	
7303	036726	000	000	DRIV10:	.BYTE	7810,0	:HISTORY BLOCK OF LOGICAL DRIVE 10
7304	036730	000020			.BLKB	SEMTAB-SCOMND	
7305	036750	001	000	DRIV11:	.BYTE	7811,0	:HISTORY BLOCK OF LOGICAL DRIVE 11
7306	036752	000020			.BLKB	SEMTAB-SCOMND	
7307	036772	002	000	DRIV12:	.BYTE	7812,0	:HISTORY BLOCK OF LOGICAL DRIVE 12
7308	036774	000020			.BLKB	SEMTAB-SCOMND	
7309	037014	003	000	DRIV13:	.BYTE	7813,0	:HISTORY BLOCK OF LOGICAL DRIVE 13
7310	037016	000020			.BLKB	SEMTAB-SCOMND	
7311	037036	004	000	DRIV14:	.BYTE	7814,0	:HISTORY BLOCK OF LOGICAL DRIVE 14
7312	037040	000020			.BLKB	SEMTAB-SCOMND	
7313	037060	005	000	DRIV15:	.BYTE	7815,0	:HISTORY BLOCK OF LOGICAL DRIVE 15
7314	037062	000020			.BLKB	SEMTAB-SCOMND	
7315	037102	006	000	DRIV16:	.BYTE	7816,0	:HISTORY BLOCK OF LOGICAL DRIVE 16
7316	037104	000020			.BLKB	SEMTAB-SCOMND	
7317	037124	007	000	DRIV17:	.BYTE	7817,0	:HISTORY BLOCK OF LOGICAL DRIVE 17
7318	037126	000020			.BLKB	SEMTAB-SCOMND	
7319							
7320							
7321							
7322	037146	000		FMTOPB:	.BYTE	0	: DRIVER PARAMETER BLOCK, DRIVE #
7323	037147	000			.BYTE	0	: OFFSET FMT16, HCI, ECI
7324	037150	000			.BYTE	0	: COMMAND CODE
7325	037151	000			.BYTE	0	: PSEL, A16 AND A17
7326	037152	000000			.WORD	0	: WORD COUNT (NEG)
7327	037154	037262			.WORD	#ENDPGM	: BUFFER ADDRESS
7328	037156	000			.BYTE	0	: SECTOR ADDRESS
7329	037157	000			.BYTE	0	: TRACK ADDRESS
7330	037160	000000			.WORD	0	: CYLINDER ADDRESS
7331	037162	037166			.WORD	RM.REG	: ADDRESS TO SAVE ALL RH11/RM03 REG'S
7332	037164	000000			.WORD	0	: STATUS WORD
7333							
7334	037166	000000		RM.REG:	.WORD	0	: RMCS1
7335	037170	000000			.WORD	0	: RMWC
7336	037172	000000			.WORD	0	: RMBA
7337	037174	000000			.WORD	0	: RMDA
7338	037176	000000			.WORD	0	: RMCS2
7339	037200	000000			.WORD	0	: RMD5
7340	037202	000000			.WORD	0	: RMER1
7341	037204	000000			.WORD	0	: RMAS
7342	037206	000000			.WORD	0	: RMLA
7343	037210	000000			.WORD	0	: RMDB
7344	037212	000000			.WORD	0	: RMMR1

7345	037214	000000	.WORD	0	;RMDT
7346	037216	000000	.WORD	0	;RMSN
7347	037220	000000	.WORD	0	;RMOF
7348	037222	000000	.WORD	0	;RMCA
7349	037224	000000	.WORD	0	;RMDC
7350	037226	000000	.WORD	0	;RMER2
7351	037230	000000	.WORD	0	;RMR2
7352	037232	000000	.WORD	0	;RMEC1
7353	037234	000000	.WORD	0	;RMEC2

;INDEX OF STATUS AND REGISTER WORDS RELATIVE TO FMTDPB

7358	000016	STATUS	=	16
7359	000020	SRMCS1	=	20
7360	000022	SRMWC	=	SRMCS1+2
7361	000024	SRMBA	=	SRMWC+2
7362	000026	SRMDA	=	SRMBA+2
7363	000030	SRMCS2	=	SRMDA+2
7364	000032	SRMDS	=	SRMCS2+2
7365	000034	SRMER1	=	SRMDS+2
7366	000036	SRMAS	=	SRMER1+2
7367	000040	SRMLA	=	SRMAS+2
7368	000042	SRMDB	=	SRMLA+2
7369	000044	SRMR1	=	SRMDB+2
7370	000046	SRMDT	=	SRMR1+2
7371	000050	SRMSN	=	SRMDT+2
7372	000052	SRMOF	=	SRMSN+2
7373	000054	SRMDC	=	SRMOF+2
7374	000056	SRMR	=	SRMDC+2
7375	000060	SRMR2	=	SRMR+2
7376	000062	SRMER2	=	SRMR2+2
7377	000064	SRMEC1	=	SRMER2+2
7378	000066	SRMEC2	=	SRMEC1+2

7381	037236	000000	000000	177776	GENDPB: .WORD	0,0,-2,CYLDER
7382	037244	037256				
7383	037246	000000	000000	037166	.WORD	0,0,RM.REG,0
7384	037254	000000				
7385	037256	000002			CYLDER: .BLKW	2
7386		037262			ENDPGM	=
7387					.NLIST	BEX ;LAST LOCATION OF PROGRAM+2

037262	005015	040515	047111	TITLE: .ASCII	<CR><LF>/MAINDEC-11-DZRM1-A/<CR><LF>
037310	046522	031460	042040	.ASCIZ	RM03 DRIVE COMPATIBILITY TEST<CR><LF><LF>
037351	015	052012	020117	LOADRV: .ASCII	<CR><LF>/TO TEST DRIVE 0, REPLACE THE 'XXDP' PACK ON DRIVE 0/<CR><LF>
037440	044527	044124	040440	.ASCII	/WITH ANOTHER PACK, CLEAR MEMORY LOCATION 40,/<CR><LF>
037516	047101	020104	042522	.ASCIZ	/AND RESTART THE PROGRAM/<CR><LF>

7388			.LIST	BEX
7389	000001		.END	

SW07 = 000200	1600#	1610												
SW08 = 000400	1599#	1609												
SW09 = 001000	1598#	1608												
SW1 = 000002	1616#													
SW10 = 002000	1597#	4264												
SW11 = 004000	1596#													
SW12 = 010000	1595#													
SW13 = 020000	1594#	4267												
SW14 = 040000	1593#													
SW15 = 100000	1592#													
SW2 = 000004	1615#													
SW3 = 000010	1614#													
SW4 = 000020	1613#													
SW5 = 000040	1612#													
SW6 = 000100	1611#													
SW7 = 000200	1610#													
SW8 = 000400	1609#													
SW9 = 001000	1608#													
SYSADR 002004	1995#	2503	2519*	2520*	2642	2643	2866	2867	3080	3081	3116	3117		
TAB 035725	3901	3905	3915	3922	7270#									
TABLEX 002044	1997#	3444*	3463											
TAB.XY= 001114	1740#	1747												
TEITVE= 000014	1650#	2348*	2349*											
TD 025746	6456	6465#												
TIMER 023042	3396*	5867#	6064*	6187*	6331*	6377*	6468*	6568*	6612*	6651*	6666*	6687*	6704	
	6706*	6766*	6772*	6778*										
TITLE 037262	2387	7387#												
TKVEC = 000060	1657#	4734*	4735*											
TPVEC = 000064	1658#													
TRAPVE= 000034	1656#	2338*	2339*	2384*										
TRFER 014224	4021	4145#												
TRKLM 001370	1873#	2688												
TRNSWT 023010	3391*	5800#	6209*	6355*	6365	6382*	6391*	6470	6471*	6743				
TRTVEC= 000014	1651#													
TSTNM 001336	1860#	2826*	2892*	2945*	3024*	3103*	3185*	3386	3425	3523*	3616*	3710*		
TST1 005450	2727	2824#	2878	3061										
TST10 011476	3614#													
TST11 012150	3708#													
TST2 005762	2876	2890#												
TST3 006200	2943#													
TST4 006571	3022#													
TST5 007056	3086	3101#	3151	3843										
TST6 007340	3148	3183#												
TST7 011030	3306	3521#												
TYPOS = 104405	5694#													
TYPE = 104401	2387	2476	2477	2478	2479	2480	2481	2579	2580	2597	2598	2599	2600	
	2605	2606	2647	2648	2649	2650	2651	2657	2658	2659	2660	2661	2702	
	2728	2729	2794	2795	2836	2837	2838	2839	2840	2841	2842	2844	2845	
	2846	2851	2852	2853	2854	2877	3028	3029	3030	3035	3036	3083	3120	
	3121	3122	3123	3124	3130	3131	3132	3133	3149	3150	3811	3813	3816	
	3817	3822	3879	3880	3881	3886	3887	3888	3889	3890	3895	3896	3901	
	3904	3905	3911	3912	3913	3915	3922	3925	4204	4205	4206	4266	4335	
	4348	4353	4358	4523	4748	4749	4757	4758	4765	4788	4794	4799	4803	
	4808	4813	4814	4816	4819	4823	4841	4842	4843	4844	4845	4846	4847	
	4923	4931	4965	4982	4984	4987	4989	4993	5000	5048	5177	5249	5325	
	5356	5357	5360	5373	5384	5403	5690#	7154	7157	7163	7166			

TYPOC = 104402	4973	4997	5359	5691#	7156	7165									
TYPON = 104404	5693#														
TYPOS = 104403	2589	2654	2848	3032	3127	3819	3883	3898	5692#						
TYPRI4 016046	4551#														
UCPAR 013446	3965	3984#													
ULDFLG 023016	5827#	6015#	6090	6105#	6288#	6351#	6383#	6532	6618	6620#	6636	6638#	6752#		
UNIT 001326	1855#	3941#													
UNSAF 014254	4015	4162#													
UNMSG 036324	7270#														
UNTOFF 036074	7270#														
UNTON 036105	7270#														
WCFER 014244	4039	4156#													
WCKD = 000151	1684#	2912	3240	3385	3557										
WCKER 014034	4018	4073#													
WCKHD = 000153	1685#														
WLEER 014174	4045	4130#													
WRTDAT = 000161	1676#	2903	2920	2957	3197	3531									
WRTHD = 000163	1687#														
WRT.R0 030144	6852#	6862#	6865#	7248											
WRT.R1 030054	6037	6041	6218	6222	6226	6234	6244	6248	6259	6266	6276	6290	6300		
	6321	6336	6347	6556	6588	6625	6849#								
	6863#	6884													
WRT.R2 030232	6849#	6883#													
WRT.R3 030236	6858	6869	6872	6878	6885#										
WRT.R4 030242	6874	6887#													
WRT.R5 030244	6886	6888#													
WRT.W0 030142	6850#	6854	6861#	6864#	7248										
XEND2 012762	3076	3838	3846#												
XPASS1 004564	2614	2634#	2734												
XPASS2 006772	2616	3060	3074#												
\$APTHD 001100	1727	1733#													
\$ASTAT = ***** U	5119	5134													
\$ATYC 020230	5090	5092#													
\$ATY1 020204	5088#														
\$ATY3 020212	5033	5089#													
\$ATY4 020222	4936	5091#													
\$AUTO8 001150	1765#	2398#	5353	5443											
\$RASE 001264	1833#														
\$ADR 001136	1760#														
\$D0AT 001142	1762#														
\$BELL 001200	1780#	4266	4923	4956											
\$BUF = 000006	2684#	2900#	2958#	2964	3199#	3205	3241#	3271#	3336	3537#	3627#	4196	4239		
	7278#														
\$CDW1 001270	1635#	2504#	2509	2638#	2644	2828	2830	2895	3049#	3078#	3082	3107	3193		
	3842#														
\$CDW2 001272	1836#	2472#	2478	2498	2552	2586	2600	2602#	2603	2639#	2651	2831	2833#		
	2841	2846	2861	3030	3079#	3108	3110#	3111	3124	3817	3881				
\$CHARC 020200	5050#	5060#	5067	5076#	5081#										
\$CKSWR 021314	5345#	5698													
\$CLR.T 017302	4874	4877#													
\$CHTAG 001114	1748#	2327	2328	2336	2342	2343	2344								
\$CM3 = 000000	1778#														
\$CNTLC 017146	4749	4808	4833#												
\$CNTLG 021723	4758	5356	5438#												
\$CNTLU 021716	4803	5373	5437#												
\$COMND = 000002	2690#	2903#	2912#	2920#	2957#	3197#	3240#	3531#	3557#	3626#	7275#	7288	7290		

SLKCSB	001302	1844#	4322*							
SLKCSR	001300	1843#	4316	4323*						
SLKS	001306	1846#	4327	4332*						
SLLVEC	001310	1847#	4329							
SLOOP	017360	4893	4897#							
SLPADR	001122	1753#	2360*	5634*	5650*	5655	5657			
SLPERR	001124	1754#	2361*	4946	5634	5651*	5657			
SLPVEC	001304	1845#	4319							
SLSTAD	031312	2419	7135*	7139#						
SMADR1	001242	1820#								
SMADR2	001246	1824#								
SMADR3	001252	1827#								
SMADR4	001256	1830#								
SMAIL	001210	1735	1739	1793#	2378	2392	4933	5028	5649	
SMAMS1	001240	1814#								
SMAMS2	001244	1822#								
SMAMS3	001250	1825#								
SMAMS4	001254	1828#								
SMBADR	001102	1735#								
SMBLG	020746	5089*	5095	5130*	5134#					
SMBEW	021741	5360	5441#							
SMSGAD	001224	1800#	5105*	5108						
SMSGLG	001226	1801#	5110*							
SMSGTY	001210	1794#	5103	5111*	5123	5127*				
SMSWR	021730	5357	5439#							
SMTYP1	001241	1815#								
SMTYP2	001245	1823#								
SMTYP3	001251	1826#								
SMTYP4	001255	1829#								
SMXCNT	022640	5647	5657#							
SMULL	001170	1774#	5055	5084						
SMYST=	000000	2823#	2889#	2942#	3021#	3100#	3182#	3520#	3613#	3707#
SOCNT	021064	5221*	5250*	5263#						
SOCTVL	022344	5567	5592#							
SOMODE	021066	5216*	5220*	5225	5228*	5239*	5265#			
SOVER	022624	5611	5627	5635	5645	5654#				
SPASS	001216	1797#	2378*	4863*	4864*	4900	5641	5658		
SPASTM	001106	1737#								
SPHYDR=	000015	2568*	7283#							
SPOWER	020632	5178	5185#							
SPSEL =	000003	7276#								
SPWRDN	020452	2340	5147#	5175						
SPWRMG	020606	5178#								
SPWRUP	020524	5157	5163#							
SQUES	001204	1781#	4816	4956	5084	5403				
SROCHR	021576	5416#	5699							
SRODEC=	***** U	5701								
SROLIN	016644	4776#	5700							
SROCT=	***** U	5701								
SROSZ =	000001	5437#								
SRESRE	022010	5478#	5702							
SRMADR	001274	1841#	2400	2510*	2513	2519	7153	7171	7175	
SRMAS =	000036	7366#	7367							
SRMBA =	000024	4197	4207	4224	7361#	7362				
SRMCS1=	000020	3944	3946	4177	7359#	7360				
SRMCS2=	000030	4016	4179	7363#	7364					

SRM0A = 000026	3259	3290	3492	3649	3671	7362#	7363										
SRM0B = 000042	7368#	7369															
SRM0C = 000054	7373#	7374															
SRM0S = 000032	3948	4013	4048	7364#	7365												
SRM0T = 000046	7370#	7371															
SRMEC1 = 000064	7377#	7378															
SRMEC2 = 000066	7378#																
SRMER1 = 000034	4022	4025	4028	4031	4034	4037	4040	4043	4046	4051	4054	4074	4181				
	7365#	7366															
SRMER2 = 000062	4057	4059	4183	7376#	7377												
SRMHR = 000056	7374#	7375															
SRMLA = 000040	7367#	7368															
SRMMR1 = 000044	7369#	7370															
SRMMR2 = 000060	7375#	7376															
SRMOF = 000052	7372#	7373															
SRMSN = 000050	7371#	7372															
SRMVEC = 001276	1842#	2401	2511*	2514	2520	7162											
SRMVC = 000022	3257	3260	3288	3291	3499	3501	3647	3650	3669	3672	4191	4210	7360#				
	7361																
SRTNAD 017362	4899#																
SRTRN 017356	2348	2350*	2355*	4875	4894#												
SR2A = ***** U	5703																
SSAVRE 021752	5462#	5701															
SSAVR6 020630	5156*	5164	5165*	5166*	5184#												
SSB20 016402	4298	4350	4355	4360	4705#												
SSB20 016432	4282	4722#															
SSCOPE 022362	2334	5608#															
SSSEC = 000010	2689*	2897*	2982*	2990*	2991	2993*	3196*	3237*	3259*	3270*	3290*	3334	3493				
	3503	3532*	3550*	3595*	3625*	3649*	3654*	3671*	7279#								
SSSETUP = 000137	2311#	2333	2334	2336	2338	2340	2342	2343	2344	2346	2360	2389	4861				
	4917	4943	4951	5180	5340	5443	5609										
SSIZE 031216	2418	7118#															
SSSTUP = 177777	2311#																
SSUPRS 016006	4299	4535#															
SSVLAD 022570	5619	5648#															
SSVPC = 009224	1711#	1716															
SSWR = 177600	1526#	1537	1541	1542	1543	1544	1545	1546	1547	1548	1778	1779	1780				
	2343	2344	2346	2360	2361	2825	2891	2944	3023	3102	3184	3522	3615				
	3709	4855	4862	4873	4886	4900	4908	4909	4910	4911	4912	4921	4928				
	4940	4944	4956	5179	5600	5601	5602	5603	5604	5610	5622	5624	5625				
	5628	5629	5630	5637	5638	5639	5651	5654	5657								
SSWREG 001232	1805#	2381															
SSWRMK = 000000	1548	1549	5604	5605	5626												
SSYSNM = 000014	2552*	2586	2831	2833	3108	3110	3910	7282#									
STATUS = 000016	3942	3956	3962	3964	3966	3968	3970	3972	4013	7358#							
STBIT 017364	2359*	4890*	4900#	5180*													
STERM = 000032	5704#																
STESTN 001214	1796#	5649*															
STIME 015136	4271	4346#	4397														
STIMES 001174	1778#	2343*	2825*	2891*	2944*	3023*	3102*	3184*	3522*	3615*	3709*	4862*	5637*				
	5644	5647*	5657														
STKB 001162	1771#	4398	4405	4736	5338	5349	5366	5420	5426								
STKINT 016462	2388	4734#															
STKS 001160	1770#	4406*	4737*	4751*	4761*	4763*	5338	5347	5363	5387*	5418	5424					
STKSRV 016512	4734	4744#															
STN = 000012	1526#	1537	2823	2825#	2889	2891#	2942	2944#	3021	3023#	3100	3102#	3182				

.S0820	1526#	5491
.S0820	1526#	5554
.SEOP	1526#	4851
.SERRO	1526#	4902
.SERRT	1526#	4957
.SPOME	1526#	5143
.SPREAD	1526#	5335
.SSAVE	1526#	5445
.SSCOP	1526#	5594
.SSIZE	1526#	7110
.STRAP	1526#	5659
.STYPD	1526#	5267
.STYPE	1526#	5005
.STYPO	1526#	5189

. ABS. 037550 000

ERRORS DETECTED: 0

DSKZ:DZRMIA, DSKZ:DZRMIA, SEQ/NL:MD:MC:CND:TOC/LI:ME/DOC/SOL/CRF=DSKM:RMDRV4.P11, DSKM:DZRMIA.P11

RUN-TIME: 29 20 2 SECONDS

RUN-TIME RATIO: 717/52=13.7

CORE USED: 40K (79 PAGES)

DOCUMENT PAGES: 161