

TMA-11

DATA RELIA EXERCISE
MD-11-DZTMH-D

EP-DZTMH-D-DL-A
COPYRIGHT © 1976
FICHE 1 OF 1

NOV 1976
digital
MADE IN USA

0.11

0.11

TABLE OF CONTENTS

PARAGRAPH	SUBJECT	PAGE
1	ABSTRACT	1
2	REQUIREMENTS	1
3	LOADING PROCEDURE	1
4	STARTING PROCEDURE	2
5	DATA PATTERNS	7
6	RANDOMIZATION	8
7	DYNAMIC PARAMETER	9
8	CONSOLE SWITCHES	10
9	ERROR PRINTOUT	14
10	STATISTIC PRINTOUT	20
11	AUTO SEQUENCE	22
12	TESTING PROCEDURES	24
13	LISTING	

110
111
112
113
114
115
116
117
118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162

(PAGE 2)

4. STARTING PROCEDURE

THERE ARE FOUR (4) STARTING ADDRESSES THAT MAY BE USED;
200(8), 204(8), 210(8), AND 240(8):

A. 200(8): THIS ADDRESS MUST BE USED ON INITIAL START FROM
LOAD AS ALL PARAMETERS ARE ENTERED FROM HERE.
REQUESTS ARE PRINTED ON THE TELETYPE FOR ENTRY OF
CONTROLLER REGISTER STARTING ADDRESS, VECTOR ADDRESS,
UNIT NUMBER, DENSITY, PARITY, RECORD COUNT, CHARACTER
COUNT, PATTERN NUMBER, TAPE MARK (EOF) OPTION, AND STALL
FOR READ, WRITE, AND TURNAROUND. ALL REPOSSES SHOULD
BE MADE IN OCTAL AND WITHIN THE LIMITS OF THE PARAMETER.
A QUESTION MARK (?) WILL BE TYPED IF ANY
CHARACTER ENTERED IS NOT BETWEEN 0 THRU 7 (OCTAL).
THE CHARACTER MAY BE RETYPED FOLLOWING THE QUESTION
MARK. IF THE RESPONSE IS NOT WITHIN ITS LIMITS. A
QUESTION MARK (?) IS TYPED AND THE ENTIRE RESPONSE
MAY BE REENTERED. SOME RESPONSES REQUIRE MORE THAN ONE
(1) CHARACTER, BUT NONE REQUIRES MORE THAN SIX (6).
RESPONSES NEED NOT HAVE
LEADING ZEROS AND SHOULD BE TERMINATED BY A CARRIAGE
RETURN IF LESS THAN THE MAXIMUM NUMBER OF CHARACTERS
IS INPUT.

B. 204(8): THIS ADDRESS SHOULD BE USED ANYTIME A RESTART
OF THE PROGRAM IS NECESSARY AND THE PARAMETERS
ENTERED AT THE INITIAL START OF 200(8) NEED NOT
BE CHANGED. ALSO NOTE THAT ANY DATA PATTERN WHICH
HAD BEEN GENERATED BY SETTING THE RANDOM DATA
SWITCH (CONSOLE SWITCH EIGHT) WILL NOT BE OVERWRITTEN
AND THEREFORE IS HELD IN CORE FOR USE UNTIL
CONSOLE SWITCH EIGHT(8) IS AGAIN SET.

C. 210(8): THIS ADDRESS IS THE SAME AS USING 204(8) IN THAT THE
PREVIOUSLY SET PARAMETERS ARE USED; HOWEVER, THE DATA
PATTERN IS RETURNED TO THE FIXED PATTERN ORIGINALLY
CALLED FOR AT THE 200(8) START. ALSO ALL STATISTICS
PREVIOUSLY GATHERED WILL BE CLEARED.

D. 240(8): THIS IS A SPECIAL ADDRESS WHICH WILL CAUSE THE
PROGRAM TO EXECUTE A PREDETERMINED TEST PLAN ON
ALL AVAILABLE UNITS. THE ONLY INPUT REQUIRED
BY THE OPERATOR IS A RESPONSE TO REQUESTS FOR THE
CONTROLLER ADDRESS, VECTOR ADDRESS, AND CONTINUOUS
OPERATION OF THE SEQUENCE.

SEE ITEM 11, (PAGE 22) FOR FULL DETAILS.

163
164
165
166
167
168
169
170
171
172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196
197
198
199
200
201
202
203
204
205
206
207
208
209
210
211
212
213
214
215
216

(PAGE 3)

THE FOLLOWING IS AN EXPLANATION OF THE INITIAL START (200 OCTAL) REQUESTS AND RESPONSES:

REGISTER START: THE RESPONSE REQUIRED FOR THIS REQUEST IS TO ENTER THE ADDRESS OF THE FIRST CONTROLLER REGISTER (MTS) AS A SIX DIGIT UNIBUS ADDRESS.

VECTOR ADDRESS: THE RESPONSE FOR THIS REQUEST IS TO ENTER THE INTERRUPT VECTOR ADDRESS USED BY THE CONTROLLER AS A THREE (3) DIGIT ADDRESS.

UNIT NUMBER: THE UNIT NUMBER IS ENTERED AS ONE (1) OCTAL CHARACTER AND MUST BE WITHIN THE LIMITS OF 0 THROUGH 7. WHEN THE UNIT NUMBER HAS BEEN ENTERED AND IS LEGAL, THE PROGRAM TESTS FOR THE PRESENCE OF A UNIT OF THAT NUMBER. IF THE UNIT IS AVAILABLE A PRINTOUT OF 7 CHANNEL OR 9 CHANNEL WILL BE MADE TO ASSIST THE OPERATOR IN SETTING DENSITY AND PARITY. IF THE UNIT IS NOT AVAILABLE, A MESSAGE STATING SO WILL BE PRINTED AND A NEW UNIT NUMBER REQUEST WILL BE ISSUED. WHEN A GOOD UNIT NUMBER HAS BEEN ENTERED, REQUESTS FOR OPERATING DENSITY AND PARITY ARE MADE FOR THAT UNIT AND SHOULD BE RESPONDED TO ACCORDING TO THAT PARTICULAR UNIT'S NEEDS. AS MANY AS EIGHT (8) UNIT NUMBER REQUESTS MAY BE USED, HOWEVER, AT LEAST ONE MUST BE USED. THE UNIT NUMBER AND THEIR RESPECTIVE DENSITY AND PARITY MAY BE ENTERED IN ANY ORDER. THE INFORMATION FOR EACH UNIT ENTERED IS LOADED INTO A TABLE FOR REFERENCE IN TESTING. IF LESS THAN EIGHT(8) UNITS ARE REQUIRED, THEN RESPONDING TO THE UNIT NUMBER REQUEST WITH A CARRIAGE RETURN WILL TERMINATE THE UNIT ENTRIES AND CONTINUE TO THE NEXT PARAMETER. IT SHOULD BE REMEMBERED THAT AT LEAST ONE UNIT NUMBER REQUEST MUST BE ENTERED. IF THE FIRST REQUEST IS RESPONDED TO BY A CARRIAGE RETURN, THEN THE REQUEST WILL BE REPEATED.

DENSITY: THE DENSITY REQUEST IS RESPONDED TO BY ONE (1) OCTAL CHARACTER AND MUST BE WITHIN THE LIMITS OF 0 THRU 3. AS EACH UNIT NUMBER IS ENTERED, A REQUEST FOR THE OPERATING DENSITY FOR THAT UNIT IS TYPED. THE RESPONSE MEANINGS ARE AS FOLLOWING:

- A. 0 = 200BPI, 7 CHANNEL NRZI
- B. 1 = 556BPI, 7 CHANNEL NRZI
- C. 2 = 800BPI, 7 CHANNEL NRZI
- D. 3 = 800BPI, 9 CHANNEL NRZI

H01

TM A, B-11 TS03 OR TUID, N, W MULTIDRIVE DATA RELIABILITY EXERCISER
CONTINUED. P11

MACY11 27(732) 04-NOV-76 11:29 PAGE 8

273
274

SEE ITEM 5, (PAGE 7) FOR A DESCRIPTION OF THE
DATA PATTERNS.

275
276
277
278
279
280
281
282
283
284
285
286
287
288
289
290
291
292
293
294
295
296
297
298
299
300
301
302
303
304
305
306
307
308
309
310
311
312
313
314
315
316
317
318
319
320
321
322
323
324
325
326
327
328
329
330

(PAGE 5)

TAPE MARK:

THE TAPE MARK REQUEST IS USED TO DETERMINE IF THE OPERATOR WISHES TO HAVE EACH DATA BLOCK SEPARATED BY A TAPE MARK (OFTEN CALLED EOF FOR END OF FILE). IF RESPONDED TO BY A ONE(1) THE TAPE MARK WILL BE WRITTEN AND WHEN READING WILL BE EXPECTED AT THE END OF EACH DATA BLOCK. A ZERO(0) RESPONSE WILL DISALLOW THE TAPE MARK OPTION. PLEASE NOTE THAT THE TAPE MARK RECORD INCREASES THE BLOCK SIZE BY ONE(1) RECORD; IN OTHER WORDS, A BLOCK OF 100 RECORDS WILL HAVE THE TAPE MARK AS RECORD 101.

SINGLE PASS:

IF RESPONDED TO WITH A ONE, THE PROGRAM WILL HALT AND PRINT AN END OF PASS MESSAGE WHEN THE LAST AVAILABLE UNIT REACHES END OF TAPE AND IS REWOUND.

STALLS:

THE STALL REQUESTS ARE RESPONDED TO BY A SIX (6) CHARACTER OCTAL NUMBER WITHIN THE LIMITS OF 1 THRU 177777. LEADING ZEROS ARE NOT REQUIRED AND AN ENTRY OF LESS THAN SIX (6) CHARACTERS SHOULD BE TERMINATED BY A CARRIAGE RETURN. EACH INCREMENT OF THE VALUE ADDS ABOUT 2.6 MICSEC TO THE DELAY.

READ: THE TIME DELAY BETWEEN EACH RECORD READ
WRITE: THE TIME DELAY BETWEEN EACH RECORD WRITTEN
TURN AROUND: TIME DELAY BETWEEN CHANGES OF TAPE DIRECTION (FORWARD, TO REVERSE, ETC.) AND BETWEEN BLOCKS.

FIXED PARAMETERS:

IT SHOULD BE NOTED THAT ALL PARAMETERS EXCEPT FOR THE UNIT DESCRIPTION VALUES (UNIT NUMBER, DENSITY, AND PARITY) HAVE NOMINAL VALUES ALREADY STORED IN THE PROGRAM. AS EACH PARAMETER REQUEST (PATTERN NUMBER, RECORD COUNT, CHARACTER COUNT, AND STALLS) IS TYPED, ITS PRESENT STORED VALUE IS ALSO PRINTED. IF THESE VALUES NEED NOT BE CHANGED, SIMPLY TYPE A CARRIAGE RETURN AS RESPONSE AND NO CHANGE WILL BE MADE. EACH START OF THE PROGRAM AT 200(8) WILL SHOW THE CURRENT VALUES OF THESE PARAMETERS AS PER THE LAST ENTRY. WHEN A FRESH LOAD OF THE PAPER TAPE IS DONE, THE PARAMETERS WILL REFLECT THE FIXED VALUES STORED IN THE PROGRAM.

- A. RECORD COUNT = 100
- B. CHARACTER COUNT = 200
- C. PATTERN NUMBER = 1
- D. READ STALL = 1
- E. WRITE = 1
- F. TURN AROUND = 1

001
002
003
004
005
006
007
008
009
010
011
012
013
014
015
016
017
018
019
020
021
022
023
024
025
026
027
028
029
030
031
032
033
034
035
036
037
038
039
040
041
042
043
044
045
046
047
048
049
050
051
052
053
054
055
056
057
058
059
060
061
062
063
064
065
066
067
068
069
070
071
072
073
074
075

(PAGE 5)

SAMPLE START AT 200(8):

THE FOLLOWING IS A SAMPLE OF THE
PRINTED REQUESTS AND THEIR RESPONSES.
RESPONSES ARE ENCLOSED IN PARENS FOR
CLARITY ONLY AND (CR) MEANS CARRIAGE RETURN

LOAD ADDRESS 200(8), SET CONSOLE SWITCHES, PRESS START SWITCH:

TM, A, B-11: TS03 OR TU10, N, W MULTIDRIVE DATA RELIABILITY EXERCISER
ENTER CONDITIONS IN OCTAL
REGISTER START = 172520 (CR)
VECTOR ADDRESS = 224 (CR)
UNIT NUMBER=(5) 9 TRK
DENSITY=(3)
PARITY=(0)
UNIT NUMBER=(2) 7 TRK
DENSITY=(2)
PARITY=(1)
UNIT NUMBER=(CR)
RECORD COUNT=100 (500)(CR)
CHARACTER COUNT=201 (38)^(7)(CR)
PATTERN NUMBER=1 (22)
?
(6)(CR)
TAPE MARK = 0 (1)(CR)
SINGLE PASS = 0(CR)

ENTER STALLS
READ=1 (CR)
WRITE=1 (CR)
TURN AROUND=1 (3000)(CR)

THE PROGRAM WILL NOW PERFORM THE TEST CYCLE SET IN
THE CONSOLE SWITCHES ON UNIT FIVE (5) THEN TWO (2),
ONE BLOCK ON EACH UNIT PER CYCLE, USING DATA PATTERN
NUMBER SIX (6) WITH A BLOCKING FACTOR OF 37 CHARACTERS
PER RECORD AND 500 RECORDS PER BLOCK. THE DELAYS ARE SET
FOR MINIMUM ON READ AND WRITE, AND APPROXIMATELY .75
SECONDS ON TURN AROUND.

(PAGE 7)

5. DATA PATTERNS

THERE ARE TWENTY DATA PATTERN GENERATORS STORED IN CORE AND ANY ONE OF THESE MAY BE SELECTED. THE ONE UNIQUE CASE IS PATTERN ZERO(0); SELECTION OF PATTERN ZERO(0) REQUIRES THAT A PREVIOUSLY PREPARED PAPER TAPE BE ENTERED AT THE HIGH SPEED READER. THIS TAPE CONTAINS A DATA PATTERN OF NO MORE THAN 377 OCTAL CHARACTERS. THE FIRST CHARACTER READ IN IS THE NUMBER OF ACTUAL DATA CHARACTERS THAT ARE CONTAINED ON THE TAPE. EACH DATA CHARACTER MAY BE ANY COMBINATION OF BITS AND WILL BE LOADED INTO CORE AS THEY APPEAR ON THE TAPE. NO MATTER HOW MANY CHARACTERS ARE ON TAPE, THE ENTIRE WRITE BUFFER (2000 CHARACTERS) WILL BE FILLED WITH THE PATTERN ENTERED SO THAT ANY SIZE RECORD CAN BE USED.

THE FOLLOWING IS A LIST OF THE DATA PATTERNS AVAILABLE:

- DATA0: EXTERNAL INPUT THRU HIGH SPEED READER (SEE DTC; MAINDEC-11-DZTUF-A)
- DATA1: ALL ONE BITS IN ALL CHARACTERS
- DATA2: ALL ZERO BITS IN ALL CHARACTERS
- DATA3: A ONE BIT WALKING FROM RIGHT TO LEFT IN A FIELD OF ZEROS
- DATA4: A ZERO BIT WALKING FROM RIGHT TO LEFT IN A FIELD OF ONES.
- DATA5: ALTERNATING ONE AND ZERO BITS IN EACH CHARACTER
- DATA6: ALTERNATING ZERO AND ONE BITS IN EACH CHARACTER
- DATA7: SAME AS DATA5 BUT WITH EVERY OTHER CHARACTER COMPLEMENTED
- DATA10: SAME AS DATA6 BUT WITH EVERY OTHER CHARACTER COMPLEMENTED
- DATA11: INCREMENTING CHARACTERS (000-377)
- DATA12: DECREMENTING CHARACTERS (377-000)
- DATA13: ALTERNATING CHARACTERS OF ALL ZERO AND ALL ONE BITS
- DATA14: ALTERNATING CHARACTERS OF ALL ONE AND ALL ZERO BITS
- DATA15: SPECIAL PATTERN OF A WALKING ZERO BIT REPEATED 4 TIMES
- DATA16: IBM COMPAT PATTERN 1: RIPPLE
- DATA17: IBM COMPAT PATTERN 2: FIXED (ABCDEF)
- DATA20: IBM COMPAT PATTERN 3: FIXED (J)

376
377
378
379
380
381
382
383
384
385
386
387
388
389
390
391
392
393
394
395
396
397
398
399
400
401
402
403
404
405
406
407
408
409
410
411
412
413
414
415
416
417

(PAGE 8)

6. RANDOMIZATION

THERE ARE THREE (3) VALUES THAT MAY BE GENERATED RANDOMLY;
DATA, CHARACTER COUNT, AND RECORD COUNT. THESE ARE NORMALLY SET TO
SOME FIXED VALUE BUT MAY BE RANDOMIZED BY SETTING THE APPROPRIATE
CONSOLE SWITCHES.

- A. RANDOM DATA: (CONSOLE SWITCH 8)
GENERATES AN ENTIRE BUFFER, CHARACTER BY CHARACTER, OF RANDOM DATA WHEN SWITCH 8 IS SET TO A ONE. ONCE SET, THE RESETTING OF SWITCH 8 CAUSES THE LAST GENERATED PATTERN TO BE RETAINED IN CORE. A RESTART AT LOCATION 200(8) OR 210(8) WILL CAUSE REVERSION OF THE DATA TO THE FIXED PATTERN REQUESTED INITIALLY. A RESTART AT LOCATION 204(8) WILL HOLD THE LAST GENERATED PATTERN IN CORE UNTIL SWITCH 8 IS AGAIN SET. ALTHOUGH THE DATA IS GENERATED AS RANDOM, THE PROGRESSION OF RANDOM CHARACTERS IS ALWAYS THE SAME FROM THE OUTSET OF RANDOMIZATION. THEREFORE IT IS POSSIBLE TO GENERATE ONE TAPE REEL OF RANDOM DATA ON ONE UNIT, RESTART THE PROGRAM TO RE-ESTABLISH THE OUTSET POINT, AND READ THE RANDOM TAPE REEL ON ANOTHER UNIT FOR COMPATABILITY TESTING. IN MULTIDRIVE SYSTEMS THE SAME BLOCK OF DATA, WHETHER RANDOM OR FIXED, IS WRITTEN OR READ ON EACH AVAILABLE UNIT IN THE ORDER THAT THEY WERE ENTERED, BEFORE BEING CHANGED.
- B. RANDOM CHARACTER COUNT: (CONSOLE SWITCH 7)
GENERATES A DIFFERENT NUMBER OF CHARACTERS PER RECORD TO BE WRITTEN ON EACH BLOCK CYCLE. THE SAME NUMBER OF CHARACTERS PER RECORD IS WRITTEN OR READ ON EACH AVAILABLE UNIT BEFORE BEING CHANGED. RESETTING SWITCH 7 HOLDS THE LAST VALUE GENERATED.
- C. RANDOM RECORD COUNT: (CONSOLE SWITCH 6)
GENERATES A DIFFERENT NUMBER OF RECORDS FOR EACH BLOCK OF DATA WRITTEN OR READ ON EACH BLOCK CYCLE. THE SAME NUMBER OF RECORDS IS WRITTEN OR READ ON EACH AVAILABLE UNIT BEFORE BEING CHANGED. RESETTING SWITCH 6 HOLDS LAST VALUE GENERATED.

418
419
420
421
422
423
424
425
426
427
428
429
430
431
432
433
434
435
436
437
438
439
440
441
442
443
444
445
446
447
448
449
450
451
452
453
454
455
456
457
458
459
460
461
462
463
464
465
466
467
468

469
470
471
472
473
474
475
476
477
478
479
480
481
482
483
484
485
486
487
488
489
490
491
492
493
494
495
496
497
498
499
500
501
502
503
504
505
506
507
508
509
510
511
512
513
514
515
516

(PAGE 9)

7. DYNAMIC PARAMETERS:

THE THREE (3) STALL VALUES ARE CONSIDERED TO BE DYNAMIC PARAMETERS AS THEY MAY BE CHANGED WHILE THE PROGRAM IS RUNNING BY TYPING A CONTROL C CHARACTER AT THE TELETYPE. AS SOON AS THE BUS IS RELEASED BY THE MAG TAPE OPERATION IN PROGRESS, THE PROGRAM WILL RESPOND TO THE CONTROL C INPUT BY TYPING A REQUEST FOR NEW STALL PARAMETERS. THE LAST VALUES THAT WERE ENTERED WILL BE PRINTED AS THE STORED VALUES AND MAY BE CHANGED BY ENTERING NEW VALUES OR LEFT UNCHANGED BY TYPING A CARRIAGE RETURN.

8. THIS PROGRAM HAS BEEN MODIFIED TO RUN ON A PROCESSOR WITH OR WITHOUT A HARDWARE SWITCH REGISTER. WHEN FIRST EXECUTED THE PROGRAM TESTS THE EXISTENCE OF A HARDWARE SWITCH REGISTER. IF NOT FOUND A SOFTWARE SWITCH REGISTER LOCATION (SWREG=LOC. 176) IS DEFAULTED TO. IF THIS IS THE CASE, UPON EXECUTION THE CONTENTS OF THE SWREG ARE DUMPED IN OCTAL ON THE CONSOLE TTY AND ANY CHANGES ARE REQUESTED

(IE) SWR=XXXXXX NEW=

POSSIBLE RESPONSES ARE:

- 1. <CR> IF NO CHANGES ARE TO BE MADE
- 2. 6 DIGITS 0-7 TO REPRESENT IN OCTAL THE NEW SWITCH REGISTER VALUE ;LAST DIGIT FOLLOWED BY <CR>.
- 3. ↑U TO ALLOW REENTERING VALUE IF ERROR IS COMMITTED KEYING IN SWREG VALUE.
- 4. <LF> ONLY VALID FOR ACT-11 SYSTEMS-DO NOT USE

BUILT INTO THE PROGRAM IS THE ABILITY TO DYNAMICALLY CHANGE THE CONTENTS OF SWREG DURING PROGRAM EXECUTION. BY STRIKING ↑G (CNTL G) ON CONSOLE TTY THE OPERATOR SETS A REQUEST FLAG TO CHANGE THE CONTENTS OF SWREG, WHICH IS PROCESSED IN KEY AREAS OF THE PROGRAM CODE (IE) ERROR ROUTINES, AFTER HALTS END OF PASS, AND OTHER APPLICABLE AREAS.

802

UNITED STATES GOVERNMENT MULTICRIME DATA RELIABILITY EXERCISER

MAC111 27(732) 04-NOV-76 11:29 PAGE 15

UNITED STATES GOVERNMENT

UNITED STATES GOVERNMENT

SWD: I=DO NOT WRITE
O=WRITE

(PAGE 11)

SWITCH EXPLANATION AND EXAMPLES:

SW0+SW3:

THESE SWITCHES ARE USED TO CONTROL THE SEQUENCE OF MAG TAPE OPERATIONS PERFORMED ON EACH AVAILABLE UNIT. THE BLOCK OF DATA DESCRIBED THROUGH THE RESPONSES TO TELETYPE REQUESTS AT INITIAL START WILL BE EITHER WRITTEN OR READ FROM EACH AVAILABLE UNIT IN THE ORDER THAT THEY WERE ENTERED. THE SEQUENCE OF OPERATIONS IS CALLED A CYCLE, AND WILL BE PERFORMED CONTINUOUSLY UNTIL STOPPED BY THE OPERATOR. WHEN END OF TAPE IS REACHED, THE UNIT WILL BE REWOUND AND FLAGGED AS UNAVAILABLE FOR TEST UNTIL ALL UNITS HAVE REACHED EOT, AT WHICH TIME TESTING IS RESUMED ON ALL AVAILABLE UNITS.

EXAMPLES: SW0+SW3

- A. SW0=0, SW3=1 WRITE ONLY X RECORDS OF Y CHARACTERS
- B. SW0=1, SW3=0 READ ONLY X RECORDS OF Y CHARACTERS
- C. SW0=0, SW3=0 WRITE THEN BACKSPACE AND READ X RECORDS

SW1:

SWITCH ONE (1), WHEN SET TO A ZERO (0), WILL CAUSE ANY DATA RELATED WRITE ERROR TO BE RETRIED. THE RETRY SCHEME CONSISTS OF REWRITING THE RECORD IN THE SAME SPOT ON THE TAPE FOUR (4) TIMES. IF ALL FOUR (4) REPEATS ARE SUCCESSFUL, THE RECORD IS CONSIDERED RECOVERED, AND A TAPE WRITE ERROR IS LOGGED. IF ANY OF THE FOUR (4) REPEATS IS UNSUCCESSFUL, A WRITE WITH EXTENDED INTERRECORD GAP IS DONE, A SUSPECTED BAD TAPE SPOT LOGGED AT THIS BLOCK AND RECORD NUMBER, AND A SECOND RETRY OF FOUR REPEATS IS DONE. IF AFTER FOUR (4) RETRIES, THE RECORD CANNOT BE RECOVERED A NOTIFICATION IS PRINTED, AND TESTING IS RESUMED ON THE NEXT RECORD. IF 20(8) BAD TAPE SPOTS ARE FOUND, THE UNIT WILL BE REWOUND AND REMOVED FROM TESTING WITH AN APPROPRIATE MESSAGE PRINTED.

SWITCH ONE (1), WHEN SET TO A ZERO (0), WILL ALSO CAUSE ANY DATA RELATED READ ERROR TO BE RETRIED. THE RETRY SCHEME CONSISTS OF REREADING THE RECORD A MAXIMUM OF FOUR (4) TIMES. IF THE RECORD IS SUCCESSFULLY RECOVERED ON ANY OF THE REREADS IT IS CONSIDERED FOR STATISTICS PURPOSES TO BE A SOFT READ ERROR AND TESTING CONTINUES IF THE REREADS FAIL TO RECOVER THE RECORD, THE ERROR IS LOGGED AS A HARD READ ERROR.

SW4:

SWITCH FOUR (4) WHEN SET WILL PRINT THE STATISTICS GATHERED FOR EACH UNIT. THE NUMBER WILL BE PRINTED AT THE END OF A BLOCK CYCLE.

SEE ITEM 10, PAGE 20 FOR FULL DETAILS.

01
02
03
04
05
06
07
08
09
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31

002

TR A.B-11 TS03 OR TUID.N.W MULTIDRIVE DATA RELIABILITY EXERCISER
021740.P11

MACY11 27(732) 04-NOV-76 11:29 PAGE 17

632

DZTMAO.P11

63
64
65
66
67
68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86

(PAGE 12)

- SW5: SWITCH FIVE (5) WHEN SET DURING A READ OPERATION WILL CAUSE THE PROGRAM TO CONTINUOUSLY READ THE CURRENT RECORD BY SPACING REVERSE OVER THE RECORD AND REREADING THAT RECORD. THIS TAPE MOVEMENT IS CALLED YOZZLING. THERE IS A SOFTWARE DELAY EXECUTED BETWEEN EACH SPACE/READ OF THE RECORD AND IT MAY BE VARIED BY TYPING CONTROL C ON THE TELETYPE DURING THE EXECUTION OF THE YOZZLE AND RESPONDING TO THE PRINTED REQUEST WITH A SIX (6) DIGIT VALUE. THE YOZZLE STALL IS PRESET TO A VALUE OF 1000 IN THE PROGRAM TO PREVENT EXCESSIVE TAPE WEAR, BUT MAY BE SET TO ANY VALUE THROUGH THE TELETYPE.
- SW6-8: THESE THREE (3) SWITCHES CONTROL THE RANDOMIZATION OF DATA AND BLOCK SIZE AND MAY BE SET AND RESET AT ANY TIME. THE ACTUAL CHANGE WILL TAKE PLACE BETWEEN BLOCK CYCLES.
- SW9: SWITCH NINE (9) WHEN SET WILL CAUSE ALL AVAILABLE TAPE UNITS TO BE REWOUND AT THE END OF THE CURRENT BLOCK CYCLE. TESTING WILL BE RESUMED AT A BLOCK COUNT OF ONE (1) WHEN ALL UNITS HAVE REACHED BOT.
- SW10-13: THESE SWITCHES ARE USED TO CONTROL THE ERROR HANDLING TO BE DONE ON THE TAPE OPERATION DESCRIBED BY SWITCHES 0+3.
 - A. SWITCH TEN (10) WHEN SET TO A ONE WILL DISALLOW ANY ERROR PRINTOUTS MADE ON THE OPERATION IN PROGRESS. CATASTROPHIC FAILURES AND INFORMATION PRINTOUTS WILL STILL OCCUR. IE: UNIT NOT AVAILABLE, ILLEGAL BOT, DROP OR PICK OVERFLOW, AND EOT REWIND.
 - B. SWITCH ELEVEN (11) WHEN SET TO A ONE WILL DISALLOW THE CHECKING FOR STATUS ERRORS ON READ OPERATIONS.
 - C. SWITCH TWELVE (12) WHEN SET TO A ONE WILL DISALLOW THE CHECKING FOR STATUS ERRORS ON WRITE OPERATIONS.
 - D. SWITCH THIRTEEN (13) WHEN SET TO A ONE WILL DISALLOW THE CHECKING OF READ DATA. THIS SWITCH HAS NO EFFECT ON STATUS CHECKING.

687
688
689
690
691
692
693
694
695
696
697
698
699
700
701
702
703
704
705
706
707
708

(PAGE 13)

SW14:

SWITCH FOURTEEN (14) IS USED DURING A READ ONLY OPERATION; WHEN SET, THE BLOCK OF DATA BEING READ WILL CONTINUOUSLY BE READ AND SPACED OVER SO THAT TAPE WILL REMAIN AT THE SAME BLOCK. WHEN RESET, THE TAPE WILL BE ALLOWED TO MOVE FORWARD AND DATA BLOCKS WILL BE READ PROGRESSIVELY. THIS IS A BLOCK YOZZLE.

SW15:

SWITCH FIFTEEN (15) WHEN SET TO A ONE, WILL CAUSE THE PROGRAM TO HALT ON ANY ERROR DETECTED BY THE OPERATION IN PROGRESS. IF BOTH SWITCH TEN (10) AND FIFTEEN (15) ARE SET, THE ACTUAL ERROR DETECTED WILL NOT BE PRINTED BUT WILL CAUSE A HALT. IF SWITCH TEN (10) IS RESET BEFORE PRESSING CONTINUE, THE ERROR WHICH CAUSED THE HALT WILL BE PRINTED BEFORE TESTING IS RESUMED.

9. ERROR PRINTOUTS

THERE ARE THREE TYPES OF ERROR PRINTOUTS MADE BY THE PROGRAM: OPERATION ERRORS, DATA ERRORS, AND CONDITION ERRORS. EACH ERROR MESSAGE PRINTED IS PRECEDED BY A HEADER WHICH CONTAINS THE UNIT NUMBER, BLOCK COUNT NUMBER, BAD RECORD NUMBER PLUS TOTAL NUMBER OF RECORDS, SIZE OF RECORD, AND TYPE OF OPERATION WHICH CAUSED ERROR.

A. OPERATION ERRORS:

THESE ARE ERRORS WHICH CAN OCCUR AS A DIRECT RESULT OF A TAPE OPERATION.

- 1. READ/WRITE STATUS ERRORS: THESE ARE INDICATED BY THE ERROR BIT (BIT 15) OF THE TAPE COMMAND REGISTER BEING SET TO A ONE.
- 2. RECCRD LENGTH ERRORS: THESE ARE INDICATED BY A BYTE COUNT OTHER THAN ZERO (0) OR AN INCORRECT CURRENT MEMORY ADDRESS OR BOTH
- 3. TAPE POSITIONING ERRORS: THESE ARE INDICATED BY A SPACE COUNT OTHER THAN ZERO (0), NO BOT FOUND FROM A REWIND, OR NO TAPE UNIT READY AT THE END OF REWIND.

B. DATA ERRORS:

DATA ERRORS WILL OCCUR WHEN TAPE IS BEING READ AND THE DATA DOES NOT MATCH THE EXPECTED DATA.

BECAUSE DATA RECORDS CAN BE UP TO TWO THOUSAND CHARACTERS LONG, AN ERROR CONDITION WHICH WILL CAUSE THE ENTIRE RECORD TO READ INCORRECTLY COULD CAUSE A VERY LENGTHY PRINTOUT. THEREFORE, A COUNTER OF SUCCESSIVE BAD CHARACTERS IS EMPLOYED. IF TEN (10) CHARACTERS IN SUCCESSION ARE BAD, A NOTIFICATION IS PRINTED (BAD RECORD) AND THE NEXT TWENTY (20) CHARACTERS ARE SKIPPED BEFORE CHECKING IS RESUMED. IF THE BAD RECORD CONDITION OCCURS THREE (3) TIMES IN ONE RECORD, THE REST OF THE RECORD IS SKIPPED, DOWN TO THE LAST TEN (10) CHARACTERS, WHICH WILL BE CHECKED. THE SKIPPING AND RESUMPTION OF CHECKING WILL ONLY BE DONE ON RECORDS WHICH ARE LONG ENOUGH TO ALLOW IT.

709
710
711
712
713
714
715
716
717
718
719
720
721
722
723
724
725
726
727
728
729
730
731
732
733
734
735
736
737
738
739
740
741
742
743
744
745
746
747
748
749
750
751
752
753
754
755
756
757
758
759
760
761

(PAGE 15)

C. CONDITION ERRORS: THESE ERRORS REFLECT THE STATE OF THE TAPE SYSTEM BEFORE AND AFTER AN OPERATION.

1. EOT: WHEN AN EOT (END OF TAPE) IS ENCOUNTERED DURING EITHER A READ OR A WRITE, THAT UNIT IS FLAGGED AS UNAVAILABLE FOR TESTING AND IS REWOUND UNTIL ALL AVAILABLE UNITS HAVE REACHED EOT. AT WHICH TIME TESTING IS RESUMED ON ALL AVAILABLE UNITS.
2. ILLEGAL BOT: WHEN A UNIT ENCOUNTERS BEGINNING OF TAPE (BOT) DURING A READ OPERATION THE ERROR IS PRINTED AND THE UNIT DROPPED FROM TESTING UNTIL ALL ARE RESTARTED ON THE NEXT PASS.
3. DROP DRIVE: UNIT BECOMES UNAVAILABLE DUE TO LOSE OF SELECT REMOTE, BOT DURING REWIND, OR NO TUR WHEN MAKING INITIAL SELECTION UNIT IS DROPPED, STATISTICS PRINTED, TESTING WILL RESUME AT BEGINNING OF NEXT PASS.
4. CONTROLLER NOT READY: BEFORE ANY OPERATION IS ATTEMPTED THE CONTROLLER IS CHECKED FOR READY. IF IT IS NOT READY, AN ERROR WILL BE PRINTED AND THE PROGRAM WILL STOP.
5. NO INTERRUPT RETURNED: EACH TAPE OPERATION SHOULD BE TERMINATED BY SETTING AN INTERRUPT IN THE CPU. IF NO INTERRUPT IS RETURNED WITHIN THE APPROPRIATE TIME, AN ERROR IS PRINTED.
6. NO MORE UNITS TO TEST: IF ALL UNITS HAVE BEEN DROPPED FOR CATASTROPHIC ERRORS, THE PROGRAM WILL STOP.

E. EXAMPLES:

GLOSSARY:

- BN = BLOCK NUMBER
- RN = RECORD NUMBER (X) OF A TOTAL OF (Y)
- RS = RECORD SIZE IN CHARACTERS PER RECORD
- WE = WRITE ERROR
- RE = READ ERROR
- SE = SPACE ERROR
- F = FORWARD
- CR = COMMAND REGISTER
- CS = STATUS REGISTER
- WC = BYTE COUNTER
- CA = CURRENT MEMORY ADDRESS POINTER AND EXPECTED VALUE
- CN = CHARACTER NUMBER
- G = GOOD DATA (SHOWN IN BIT FORMAT AS IN CORE)
- B = BAD DATA (SHOWN IN BIT FORMAT AS IN CORE)
- ERR AMT = NUMBER LEFT TO SPACE
- TM = TAPE MARK (OFTEN CALLED EOF FOR END OF FILE)
- LPC = LONGITUDINAL PARITY CHECK (RECEIVED - EXPECTED)

755
756
757
758
759
760
761
762
763
764
765
766
767
768
769
770
771
772
773
774
775
776
777
778
779
780
781
782
783
784
785
786
787
788
789
790
791
792
793
794
795
796
797
798
799
800
801
802
803
804
805
806
807
808
809
810
811
812
813
814
815
816
817

818

PATRN = DATA PATTERN (R=RANDOM)

019
020
021
022
023
024
025
026
027
028
029
030
031
032
033
034
035
036
037
038
039
040
041
042
043
044
045
046
047
048
049
050
051
052
053
054
055
056
057
058
059
060
061
062
063
064
065
066
067
068
069
070
071
072
073
074

(PAGE 16)

EXAMPLE 1

EXAMPLE 1: IN THIS EXAMPLE A TAPE VERTICAL PARITY ERROR WAS DETECTED DURING A WRITE OPERATION OF THE TWELVTH (12) RECORD OF THE BLOCK. THE WORD COUNT AND CURRENT MEMORY ADDRESS ARE CORRECT. THE RETRY OPTION WAS DISABLED.

UNIT NO. 3 *DEN 1 *PAR 0 *PATRN 1
BN 406*RN 12-200*RS 2000*WE
CMD 1010001111000100
STAT 0001000001000001
WC 0
CA 14436-14436

EXAMPLE 2

EXAMPLE 2: IN THIS EXAMPLE A RECORD LENGTH ERROR WAS DETECTED WHILE READING THE FIRST RECORD OF THE BLOCK. THE RETRY OPTION WAS DISABLED. THE WORD COUNT SHOWS A COUNT OF 20 CHARACTERS LEFT TO BE TRANSFERRED. THE CURRENT MEMORY ADDRESS REFLECTS THAT A SHORTAGE OF 20 CHARACTERS TRANSFERRED HAD OCCURRED. IN THIS EXAMPLE THE STATUS AND COMMAND REGISTERS DO NOT SHOW ANY ERROR, BUT THE LPC IS SHOWN TO BE INCORRECT.

UNIT NO. 7 *DEN 2 *PAR 0 *PATRN 6
BN 10*RN 1-100*RS 50*RE F***
CMD 0100011111000100
STAT 0000000001000001
WC 20
CA 12466-12506
LPC 337 -147

EXAMPLE 3

EXAMPLE 3: IN THIS EXAMPLE THE TAPE UNIT WAS TRYING TO SPACE OVER THE 15 RECORDS IN THE BLOCK IN ORDER TO ESTABLISH PROPER POSITION TO BEGIN READING. THE OPERATION WAS TERMINATED BEFORE THE ENTIRE 15 RECORDS WERE TRAVERSED AND AN ERROR SHOWN BECAUSE THE TAPE IS NOT IN PROPER POSITION TO BEGIN READING.

UNIT NO. 0 *PATRN R
BN 2*RN 15-15*RS 23 *SE
ERR AMT 4

K02

TM A,B-11 TS03 OR TUD.N.W MULTIDRIVE DATA RELIABILITY EXERCISER
DZTMAD.P11

MACY11 27(732) 04-NOV-76 11:29 PAGE 24

875

876
877
878
879
880
881
882
883
884
885
886
887
888
889
890
891
892
893
894
895
896
897
898
899
900
901
902
903
904
905
906
907
908
909
910
911

(PAGE 17)

EXAMPLE 4

EXAMPLE 4: IN THIS EXAMPLE UNIT NUMBER ONE (1) HAD BEEN
REWOUND VIA CONSOLE SWITCH NINE (9) AND AT THE
COMPLETION OF THE OPERATION BOT WAS NOT SET IN
THE STATUS REGISTER.

UNIT NO. 1 *DEN 3 *PAR 0 *PATRN R
SN 3002*RN 65-65*RS 10
NO BOT ON REWIND-HALT

EXAMPLE 5

EXAMPLE 5: IN THIS EXAMPLE TWO BAD CHARACTERS WERE
READ FROM TAPE IN THE FORWARD DIRECTION.
THE FIRST (0) AND THE THIRTEENTH (13) CHARACTERS
OF THE TOTAL NUMBER OF SIXTEEN (16) CHARACTERS
IN THE BLOCK ARE BAD. CHARACTER NUMBER
ZERO (0) HAS DROPPED BIT NUMBER FIVE (5) AND
CHARACTER NUMBER TWELVE (12) HAS PICKED UP
BIT NUMBER SEVEN (7).

UNIT NO. 5 *DEN 3 *PAR 0 *PATRN 5
BN 12*RN 3-10*RS 15*DE-F**
CN 0
G; 10101010
B; 10001010
CN 12
G; 01010101
B; 11010101

912
913
914
915
916
917
918
919
920
921
922
923
924
925
926
927
928
929
930
931
932
933
934
935
936
937
938
939
940
941
942
943
944
945
946
947
948
949
950
951
952
953
954
955
956
957
958
959
960
961
962

(PAGE 18)

EXAMPLE 6

EXAMPLE 6: IN THIS EXAMPLE UNIT NUMBER SIX (6) HAS REACHED END OF TAPE (EOT) FOR THE 1ST TIME AND WILL BE REWCUND. TESTING WILL RESTART ON UNIT NUMBER SIX (6) WHEN ALL UNITS HAVE REACHED EOT.

UNIT NO. 6 *DEN 3 *PAR 0 *PATRN R
BN 677 *RN 25-600*RS 1566
EOT NO. 1
UNIT WILL REWIND AND BE
RESTARTED ON BLOCK ONE
WHEN ALL AVAIL UNITS REACH EOT

EXAMPLE 7

EXAMPLE 7: IN THIS EXAMPLE UNIT NUMBER TWO (2) HAS ENCOUNTERED BEGINNING OF TAPE (BOT). DRIVE WILL BE DROPPED STATISTICS WILL BE PRINTED, TESTING RESUMED AT BEGINNING OF NEXT PASS.

UNIT NO. 2 *DEN 2 *PAR 0 *PATRN 2
BN 56*RN 2-4*RS 1200
ILLEGAL BOT

EXAMPLE 8

EXAMPLE 8: IN THIS EXAMPLE THE SELECTED UNIT (NUMBER 0) HAS BECOME UNAVAILABLE. UNIT WILL BE DROPPED STATISTICS WILL BE PRINTED, TESTING WILL RESUME AT BEGINNING OF NEXT PASS.

UNIT NO. 3 *DEN 1 *PAR 0 *PATRN 4
BN 1*RN 0-200*RS 66 NOT AVAIL
(OR LOST SELECT REMOTE, NO BOT ON REWIND)

EXAMPLE 9

EXAMPLE 9: IN THIS EXAMPLE THE WRITE OPERATION EXECUTED ON UNIT NUMBER SIX (6) WAS NOT COMPLETED AND NO INTERRUPT WAS RETURNED.

UNIT NO. 6 *DEN 2 *PAR 0 *PATRN R
BN 12*RN 3-4*RS 100*WE
NO INTERRUPT RETURNED

(PAGE 19)

EXAMPLE 10

EXAMPLE: 10 THIS EXAMPLE SHOWS A READ ERROR WHICH RECOVERED ON THE SECOND RETRY. THIS ERROR WILL BE LOGGED AS A RDERR BUT WILL BE CATEGORIZED AS A SOFT ERROR. THE REGISTERS SHOW A PARITY ERROR WAS THE CAUSE OF THE ERROR.

UNIT NO. 1 *DEN 3 *PAR 1 *PATTRN R
*BN 10 *RN 2-100 *RS 1117 *RE F***
CMD 1110100110000010
STAT 0011000001000001
WC 0
LPC 337-147
ORIGINAL ERROR

UNIT NO. 1 *DEN 3 *PAR 0 *PATTRN R
*BN 10 *RN 2-100 *RS 1117 *RE F***
CMD 1110100110000010
STAT 0011000001000001
WC 0
LPC 337-147
READ FAILED--RETRY: 1
REREAD SUCCESSFUL--RETRY: 2

EXAMPLE 11

EXAMPLE 11: THIS EXAMPLE SHOWS A WRITE ERROR WHICH WAS NOT RECOVERED BY SUCCESSFULLY REWRITTING THE RECORD FOUR TIMES AT THAT LOCATION. THE RECORD WAS SUCCESSFULLY WRITTEN AFTER 3 INCHES OF TAPE WAS ERASED. THIS ERROR WILL BE LOGGED AS A BAD TAPE SPOT.

UNIT NO. 0 *DEN 3 *PAR 0 *PATTRN R
*BN 2 *RN 370 -461 *RS 2407 *WE
CMD 1110000010000100
STAT 0011000001000001
WC 0
CA 25613 -25613
ORIGINAL ERROR

UNIT NO. 0 *DEN 3 *PAR 0 *PATTRN R
*BN 2 *RN 370 -461 *RS 2407 *WE
CMD 1110000010000100
STAT 0011000001000001
WC 0
CA 25613 -25613
SUSPECT BAD TAPE
RETRY: 0
REPEAT: 0

953
954
955
956
957
958
959
960
961
962
963
964
965
966
967
968
969
970
971
972
973
974
975
976
977
978
979
980
981
982
983
984
985
986
987
988
989
990
991
992
993
994
995
996
997
998
999
1000
1001
1002
1003
1004
1005
1006
1007
1008
1009
1010
1011
1012
1013
1014
1015
1016
1017
1018

B03

TR A. B-11 7503 OF TUC.N.A MULTIDRIVE DATA RELIABILITY EXERCISE
CCTHAC.P11

MACY11 27(732) 04-NOV-76 11:29 PAGE 28

1218
1225

RECOVERED
RETRY: 1

(PAGE 20)

10. STATISTICS PRINTOUT

THE PROGRAM GATHERS A VARIETY OF STATISTICS DURING THE COURSE OF ITS TESTING. THE STATISTICS ARE KEPT ON A UNIT BY UNIT BASIS AND ARE SUMMARIZED IN A STATISTICS PRINTOUT. STATISTIC PRINTOUTS CAN BE PRINTED AT THE END OF EACH BLOCK CYCLE BY SETTING SWITCH FOUR (4) TO 1. A STATISTIC PRINTOUT IS AUTOMATICALLY PRINTED WHEN A UNIT REACHES EOT AND IS REWOUND.

HERE IS AN EXPLANATION OF THE STATISTIC SUMMARY.

DROPS: THE NUMBER OF BITS DROPPED ON A PER TRACK BASIS. DROPS ARE COLLECTED DURING THE DATA CHECK ROUTINE.

PICKS: THE NUMBER OF BITS PICKED ON A PER TRACK BASIS. DROPS ARE COLLECTED DURING THE DATA CHECK ROUTINE.

WTERR: THE NUMBER OF RECORDS IN WHICH A WRITE ERROR OCCURRED. IF WRITE RETRY WAS ENABLED, WTERR WILL CONTAIN ONLY THOSE RECORDS WHICH WERE NOT RECOVERED AFTER ONE RETRY.

RTRY: THE NUMBER OF RETRIES INITIATED UNDER THE WRITE RETRY OPTION. (SEE ITEM 8., SW1:)

RDERR: THE TOTAL NUMBER OF RECORDS IN WHICH A READ ERROR OCCURRED.

SOFT: THE NUMBER OF READ ERRORS WHICH WERE RECOVERED WITHIN A MAXIMUM OF FOUR REREADS OF A RECORD UNDER THE READ RETRY OPTION. (SEE ITEM 8., SW1:)
**NOTE: SOFT READ ERRORS ARE ONLY CATEGORIZED FOR THOSE READ ERRORS OCCURRING WHEN CONSOLE SWITCH 1 IS SET TO ZERO.

HARD: THE NUMBER OF READ ERRORS WHICH REMAINED UNRECOVERED UNDER THE READ RETRY SCHEME. (SEE ITEM 8., SW1:)
**NOTE: HARD READ ERRORS ARE ONLY CATEGORIZED FOR THOSE READ ERRORS OCCURRING WHEN CONSOLE SWITCH 1 IS SET TO ZERO.

DTERR: THE NUMBER OF DATA ERRORS FOUND FOR THIS UNIT.
**NOTE: DATA ERRORS ARE ONLY FOUND FOR THOSE RECORDS WHICH WERE READ WITH SWITCH 11 RESET TO ZERO.

102
1021
1022
1023
1024
1025
1026
1027
1028
1029
1030
1031
1032
1033
1034
1035
1036
1037
1038
1039
1040
1041
1042
1043
1044
1045
1046
1047
1048
1049
1050
1051
1052
1053
1054
1055
1056
1057
1058
1059
1060
1061
1062
1063
1064
1065
1066
1067
1068
1069
1070
1071
1072
1073
1074

(PAGE 21)

BAD TAPE SPOTS: A COUNT OF THE NUMBER OF TAPE SPOTS
WHERE A RECORD COULD NOT BE REWRITTEN SUCCESSFULLY
UNDER THE WRITE RETRY OPTION (SEE ITEM8.. SW1:)
FOLLOWING THE COUNT IS A LIST OF THE BAD TAPE
LOCATIONS IDENTIFIED BY THE BLOCK AND RECORD NUMBER
WHEN THE BAD TAPE SPOT WAS LOGGED.

EXAMPLE

DROPS:	0	0	0	0	7	0	0	0
PICKS:	0	0	0	2	0	0	0	0
WTERR:	3							
RTRY:	4							
RDERR:	6							
SOFT:	1							
HARD:	5							
DTERR:	10							
1	BAD TAPE SPOTS							
0	*BN 16 *RN 41							

1075
1076
1077
1078
1079
1080
1081
1082
1083
1084
1085
1086
1087
1088
1089
1090
1091
1092
1093
1094
1095

11. AUTO SEQUENCE

THE AUTO SEQUENCE (START AT ADDRESS 240) WILL EXECUTE A PREDETERMINED TEST PLAN ON ALL AVAILABLE UNITS. THE ONLY OPERATOR RESPONSE REQUIRED IS TO THE TYPED REQUESTS FOR THE CONTROLLER ADDRESS AND VECTOR AND CONTINUOUS OR SINGLE CYCLE. ALL SWITCHES REMAIN ACTIVE AND MAY BE USED NORMALLY; HOWEVER, THE INTENT IS TO LEAVE ALL SWITCHES DOWN AND ALLOW FULL EXECUTION OF THE TEST PLAN FOR SYSTEM CHECKOUT.

SAMPLE START AT 240(8): AUTO SEQUENCE

LOAD ADDRESS 240(8), SET SWITCHES TO ZERO, PRESS START:

TM A,B-11 AUTO SEQUENCE TEST
ENTER RESPONSES IN OCTAL

REGISTER START = 172520 (CR)
VECTOR = 224 (CR)
AUTO CONT: 0 (1)

THIS EXAMPLE SHOWS AN AUTO SEQUENCE START WITH THE CONTROLLER AT BUS ADDRESS 172520 AND A VECTOR OR 224. ALL AVAILABLE UNITS WILL BE TESTED CONTINUOUSLY.

AS EACH PASS IS COMPLETED A DIVIDER LINE OF ASTERISKS WILL BE PRINTED FOLLOWED BY AN END OF PASS MESSAGE INDICATING HOW MANY PASSES HAVE BEEN COMPLETED SINCE THE AUTO SEQUENCE WAS BEGUN. AT THE START OF EACH PASS THE UNITS BEING TESTED ARE PRINTED.

AUTO SEQUENCE TEST PLAN:

THE AUTO SEQUENCER WILL EXECUTE A PASS CONSISTING OF THE WRITING, READING, AND CHECKING OF SEVERAL DIFFERENT DATA PATTERNS. EACH PASS WILL START AT BOT AND PROCESS AN ENTIRE MAG TAPE BEFORE REWINDING

THE UNITS WILL BE SET UP TO WRITE 800 BPI IN NINE TRACK FORMAT. ODD PARITY WILL BE USED AND NO TAPE MARKS WILL BE WRITTEN.

THE DATA PATTERNS WILL BE AS FOLLOWS:

THREE FIXED DATA PATTERNS:

EACH PATTERN WILL BE USED FOR SIX BLOCKS.
EACH BLOCK CONSISTS OF (100) 4000 CHARACTER RECORDS.

- PATTERN 3: WALKING ONE BIT
- PATTERN 7: ALTERNATING ONE AND ZERO BITS
- PATTERN 11: INCREMENTING CHARACTERS (000-377)

1108
1109
1110
1111
1112
1113
1114
1115
1116
1117
1118
1119
1120
1121
1122
1123
1124
1125
1126
1127
1128
1129
1130
1131
1132
1133
1134
1135
1136
1137
1138
1139
1140
1141
1142
1143
1144
1145
1146
1147
1148
1149
1150
1151

(PAGE 23)

RANDOM DATA:

FOLLOWING THE FIXED DATA PATTERNS, RANDOM DATA WILL BE WRITTEN IN THE SAME BLOCK STRUCTURE UNTIL EOT IS REACHED. IT IS IMPORTANT THAT THE TAPE USED FOR THE TEST BE OF SUFFICIENT LENGTH TO ACCOMODATE ALL OF THE FIXED DATA PATTERNS AND AT LEAST ONE RECORD OF RANDOM DATA; OTHERWISE, THE TAPE WILL BE REWOUND UNTIL ALL OF THE DATA PATTERNS HAVE BEEN TESTED.

1:55
1:56
1:57
1:58
1:59
1:60
1:61
1:62
1:63
1:64

(PAGE 24)

12. TESTING PROCEDURES

AS PREVIOUSLY STATED THIS PROGRAM CONTAINS NO FIXED TESTS. THE ENTIRE TEST CYCLE TO BE EXECUTED IS DESCRIBED BY THE OPERATOR THROUGH RESPONSES TO TELETYPE REQUESTS FOR PARAMETERS AND CONSOLE SWITCH SETTINGS FOR OPERATION. THE OPERATION SELECTED WILL BE EXECUTED WITH THE PARAMETERS ENTERED CONTINUOUSLY ON EACH AVAILABLE UNIT, ONE BLOCK AT A TIME, UNTIL STOPPED BY THE OPERATOR. THE OPERATION MAY BE CHANGED DYNAMICALLY BY CHANGING THE CONSOLE SWITCHES AT ANY TIME. THE PROGRAM WILL ATTEMPT TO PERFORM ANY OPERATION SET AND THEREFORE CAUTION SHOULD BE TAKEN TO ASSURE THAT THE UNIT IS CAPABLE OF PERFORMING AS REQUESTED. FOR INSTANCE, ONE SHOULD NOT ATTEMPT TO PERFORM READ OPERATIONS ON A TAPE WHICH HAS NOT BEEN WRITTEN AS THE DATA, IF ANY, IS UNPREDICTABLE. HOWEVER, IF A TAPE HAS BEEN WRITTEN WITH THIS PROGRAM, IT CAN BE READ AS OFTEN AS DESIRED WITHOUT BEING REWRITTEN. THIS IS A GOOD PROCEDURE TO USE FOR TESTING TAPE COMPATABILITY. SCOPING OF TAPE UNITS BECOMES SIMPLE; BY SETTING THE DESIRED OPERATION AND ITS PARAMETER, A UNIT MAY BE CONTINUOUSLY EXERCISED IN ANY MANNER DESIRED. BY USING THE VARIOUS ERROR CONTROL SWITCHES AND ENTERING THE NEEDED STALL, ANY FUNCTION CAN BE SCOPED RATHER EASILY. RELIABILITY TESTING CAN BE PERFORMED BY USE OF THE RANDOMIZATION CAPABILITY. PERHAPS A CYCLE OF RANDOM TESTING MIGHT BE SET UP AND ALLOWED TO RUN FOR SOME PERIOD OF TIME, THE STATISTICAL COLLECTION OF DROPS AND PICKS IS THEN SIGNIFICANT. INTERMITTANT PROBLEMS CAN BE FOUND BY SETTING THE DESIRED OPERATION IN MOTION AND DISALLOWING ERROR PRINTOUTS WHILE ALLOWING A HALT ON ERROR. THE ERROR THAT CAUSED THE HALT CAN BE PRINTED BY RESETTING CONSOLE SWITCH TEN AND PRESSING CONTINUE. IF SOME PARTICULAR DATA PATTERN SHOULD BE CAUSING DATA ERROR, USE OF THE YOZZLE SWITCH AND ITS ASSOCIATED STALL CAN BE USED TO ALLOW SCOPING OF THIS PARTICULAR RECORD.

AS YOU SEE, THERE ARE MYRIAD TESTING PROCEDURES WHICH COULD BE PERFORMED. THE PARAMETERS, TAPE OPERATIONS, ERROR EXAMINATION AND REPORTING ARE ALL AT YOUR DISCRETION.

TRY IT, YOU'LL LIKE IT.

13. LISTING

```

%
.TITLE TM A,B-11 TS03 OR TU10,N,W MULTIDRIVE DATA RELIABILITY EXERCISER
;MAINDEC-11-DZTMH-D-D
;AUG 1976
;R. B. BARNES/RON PLATUKIS/R. SOLER
.ENABLE ABS,AMA
.MCALL .SACT11

```

1165
1166
1167
1168
1169
1170
1171
1172
1173
1174
1175
1176
1177
1178
1179
1180
1181
1182
1183
1184
1185
1186
1187
1188
1189
1190
1191
1192
1193
1194
1195
1196
1197
1198
1199
1200
1201
1202
1203
1204
1205
1206
1207
1208
1209
1210
1211
1212
1213
1214
1215
1216
1217
1218
1219
1220

1261
1262
1263
1264
1265
1266
1267
1268
1269
1270
1271
1272
1273
1274
1275
1276
1277
1278
1279
1280
1281
1282
1283
1284
1285
1286
1287
1288
1289
1290
1291
1292
1293
1294
1295
1296
1297
1298
1299
1300

```
:CONSOLE SWITCHES*****  
;SW15: 1=STOP ON ERROR  
;      0=CONTINUE ON ERROR  
  
;SW14: 1=YOZZLE ON CURRENT BLOCK  
;      0=DO NOT YOZZLE ON BLOCK  
  
;SW13: 1=DO NOT CHECK DATA  
;      0=CHECK DATA  
  
;SW12: 1=DO NOT CHECK WRITE ERRORS  
;      0=CHECK WRITE ERRORS  
  
;SW11: 1=DO NOT CHECK READ ERRORS  
;      0=CHECK READ ERRORS  
  
;SW10: 1=DO NOT PRINT ERRORS  
;      0=PRINT ERRORS  
  
;SW9:  1=REWIND TAPE  
;      0=DO NOT REWIND  
  
;SW8:  1=USE RANDOM DATA  
;      0=USE FIXED DATA PATTERN  
  
;SW7:  1=USE RANDOM CHARACTER COUNT  
;      0=USE FIXED CHAR COUNT  
  
;SW6:  1=USE RANDOM RECORD COUNT  
;      0=USE FIXED RECORD COUNT  
  
;SW5:  1=YOZZLE ON CURRENT RECORD  
;      0=DO NOT YOZZLE ON RECORD  
  
;SW4:  1=PRINT DROPS AND PICKS  
;      0=DO NOT PRINT DROPS AND PICKS  
  
;SW3:  1=DO NOT READ FORWARD  
;      0=READ FORWARD  
  
;SW2:  NOT USED  
  
;SW1:  1=INHIBIT WRITE AND READ RETRY  
;      0=ENABLE WRITE AND READ RETRY  
  
;SW0:  1=DO NOT WRITE  
;      0=WRITE
```

```

1271
1272
1273
1274
1275
1276
1277
1278
1279
1280
1281
1282
1283
1284
1285
1286
1287
1288
1289
1290
1291
1292
1293
1294
1295
1296
1297
1298
1299
1300
1301
1302
1303
1304
1305
1306
1307
1308
1309
1310
1311
1312
1313
1314
1315
1316
1317
1318
1319
1320
1321
1322
1323

```

```

;REGISTER EQUIVS*****
RO=%0
R1=%1
R2=%2
R3=%3
R4=%4
R5=%5
SP=%6
PC=%7
NOP=240

;TRAP CATCHERS*****
.=0
.=42
.SBTTL ACT11 HOOKS

;*****
;HOOKS REQUIRED BY ACT11
$SVPC=. ;SAVE PC
.=46
$ENDAD ;;1)SET LOC.46 TO ADDRESS OF $ENDAD IN .SEOP
.=52
.WORD 0 ;;2)SET LOC.52 TO ZERO
.= $SVPC ;; RESTORE PC

;TTY INTERRUPT VECTOR*****
.=60
TTINT ;TTY INTERRUPT HANDLER ADDRESS
0

;SOFTWARE SWITCH REGISTER LOCATIONS*****
.=174
DISPREG:0
SWREG: 0

;START ADDRESS*****
.=200
JMP START ;ENTER PARAMETERS VIA TTY

.=204
JMP STARTA ;USE FIXED PARAMETERS; HOLD DATA

.=210
CHAIN: CLR RDFL
JMP STARTE ;USE FIXED PARAMETERS; NEW DATA

```

1324
1325
1326
1327
1328
1329
1330
1331
1332
1333
1334

000224 017466
000226 000340

000240 005237 021624
000244 000137 003106

;MAG TAPE INTERRUPT VECTOR*****

.=224
MTINT
340

;MAG TAPE INTERRUPT HANDLER ADDRESS

;AUTO SEQUENCE START*****

.=240
INC
JMP

ASEQF
STAUT

;SET AUTO SEQUENCE FLAG
;GO TO START OF AUTO SEQ

1335 000600

.=600
;CONSTANTS*****

1336
1337
1338 000600 172520
1339 000602 172522
1340 000604 172524
1341 000606 172526
1342 000610 172530
1343 000612 172532
1344 000614 000224
1345 000616 000000
1346 000620 000100
1347 000622 177600
1348 000624 000001
1349 000626 000002
1350 000630 000001
1351 000632 000001
1352 000634 000001
1353 000636 000001
1354 000640 001000
1355 000642 000100
1356 000644 177600
1357 000646 000000
1358 000650 177776
1359 000652 177570
1360 000654 177570
1361 000656 177560
1362 000660 177562
1363 000662 177564
1364 000664 177566
1365 000666 177550
1366 000670 177552
1367 000672 153624
1368 000674 172520
1369 000676 032561
1370

MTS: 172520
MTC: 172522
MWC: 172524
MDA: 172526
MTD: 172530
MTRD: 172532
VECT: 224
UCES: 0
RCNT: 100
CARCNT: 177600
PATRN: 1
RDCMD: 2
SPFLG: 1
RSTAL: 1
WSTAL: 1
TSTAL: 1
YSTAL: 1000
RCSAV: 100
CCSAV: -200
TMEX: 0
PSW: 177776
SWR: 177570
DISPLAY: 177570
TKS: 177560
TKB: 177562
TPS: 177564
TPB: 177566
PRS: 177550
PRB: 177552
RANBAS: 153624
REGST: 172520
RANSAY: 032561

;TAPE STATUS REGISTER
;TAPE COMMAND REGISTER
;TAPE CHARACTER COUNT REGISTER
;TAPE DATA ADDRESS REGISTER
;TAPE DATA BUFFER
;TAPE READ LINES
; INTERRUPT VECTOR ADDRESS
;UNIT DESCRIPTION (PARITY,DENSITY,UNIT,TRACK)
;RECORD COUNTER
;NUMBER OF CHAR (2 - 4000) OCTAL IN TWOS COMPLEMENT
;DATA PATTERN SELECTOR (0 - 20) OCTAL
;READ COMMAND
;SINGLE PASS FLAG
;READ STALL
;WRITE STALL
;TURN AROUND STAL
;YOZZLE STAL
;RECORD COUNT SAVE
;CHARACTER COUNT SAVE
;TAPE MARK FLAG: 1=TM 0=NO TM
;PROCESSOR STATUS
;CONSOLE SWITCHES

;TTY READ STATUS REGISTER
;TTY READ BUFFER
;TTY PUNCH STATUS REGISTER
;TTY PUNCH OUTPUT REGISTER
;H/S READER STATUS REGISTER
;H/S READER BUFFER
;RANDOM NUMBER GENERATOR BASE
;STARTING REGISTER ADDRESS
;RANDOM NUMBER BUFFER

1371
1372
1373
1374
1375
1376
1377
1378
1379
1380
1381
1382
1383
1384
1385
1386
1387
1388
1389
1390
1391
1392
1393
1394
1395
1396
1397
1398
1399
1400
1401
1402
1403
1404
1405
1406
1407
1408
1409
1410
1411

000700 000000
000702 000000
000704 000000
000706 000000
000710 000000
000712 000000
000714 000000
000716 000000
000720 000000
000722 000000
000724 000000
000726 000000
000730 000000
000732 000000
000734 000000
000736 000000
000740 000000
000742 000000
000744 000000
000746 000000
000750 000000
000752 000000
000754 000000
000756 000000
000760 000000
000762 000000
000764 000000
000766 000000
000770 000000
000772 000000
000774 000000
000776 000000
001000 000000
001002 000000
001004 000000
001006 000000
001010 000000

TINF: 0
TOB: 0
TIB: 0
TEMP1: 0
TEMP2: 0
TEMP3: 0
TEMP4: 0
EMADDR: 0
BLCNTR: 0
BBC: 0
RTRN: 0
HDRFL: 0
STAL: 0
PFLG: 0
UNP: 0
BCNT: 0
ERSAV: 0
SERFL: 0
DERFL: 0
BTFLG: 0
RPCNT: 0
RTCNT: 0
RTYFL: 0
TMFLG: 0
EOTREC: 0
BTPT: 0
ERTFL: 0
BDPP: 0
BPKP: 0
BTSTF: 0
RRTYFL: 0
SEQCT: 0
COUNT: 0
TEMPST: 0
RDSW: 0
DUCTR: 0
STCDFL: 0

; FLAGS AND COUNTERS*****

; TTY ENTERY FLAG
; TTY OUTPUT BUFFER
; TTY INPUT BUFFER
; TEMP STORAGE
; TEMP STORAGE
; TEMP STORAGE
; TEMP STORAGE
; ERROR MSG ADDRESS STORAGE
; BLOCK COUNTER
; BAD RECORD COUNTER
; INTERRUPT RETURN STORAGE
; HEADER FLAG
; DELAY STORAGE
; PRINT FLAG
; UNIT TABLE POINTER
; BIT COUNTER
; STATUS STORAGE
; STATUS ERROR FLAG
; DATA ERROR FLAG
; BAD TAPE FLAG
; REPEAT COUNTER
; RETRY COUNTER
; RETRY FLAG
; TM FLAG
; END OF TAPE RECORD
; BAD TAPE POINTER
; ERASE TAPE FLAG
; DROP POINTER
; PICK POINTER
; BAD TAPE STATISTICS FLAG
; READ RETRY FLAG
; AUTO SEQ PASS COUNT

; DROPPED UNIT COUNTER
; 7 TRK CORE DUMP FLAG

1412
1413
1414
1415
1416
1417
1418
1419
1420
1421
1422
1423
1424
1425
1426
1427
1428
1429
1430
1431
1432
1433
1434
1435
1436
1437
1438
1439
1440
1441
1442
1443
1444
1445
1446
1447
1448
1449
1450
1451
1452
1453
1454
1455
1456
1457
1458
1459
1460
1461
1462
1463
1464
1465

001012 060000
001014 177777
001016 177777
001020 177777
001022 177777
001024 177777
001026 177777
001030 177777
001032 177777

001034 001254
001036 001274
001040 001314
001042 001334
001044 001354
001046 001374
001050 001414
001052 001434
001054 001454
001056 001474
001060 001514
001062 001534
001064 001554
001066 001574
001070 001614
001072 001634

001074 000000
001076 000000
001100 000000
001102 000000
001104 000000
001106 000000
001110 000000
001112 000000

001114 000000
001116 000000
001120 000000
001122 000000
001124 000000
001126 000000
001130 000000
001132 000000

UN1: 60000
UN2: -1
UN3: -1
UN4: -1
UN5: -1
UN6: -1
UN7: -1
UN8: -1
UNX: -1

PIK1: BP00
PIK2: BP10
PIK3: BP20
PIK4: BP30
PIK5: BP40
PIK6: BP50
PIK7: BP60
PIK8: BP70
DRP1: BD00
DRP2: BD10
DRP3: BD20
DRP4: BD30
DRP5: BD40
DRP6: BD50
DRP7: BD60
DRP8: BD70

WTER1: 0
WTER2: 0
WTER3: 0
WTER4: 0
WTER5: 0
WTER6: 0
WTER7: 0
WTER8: 0

RDER1: 0
RDER2: 0
RDER3: 0
RDER4: 0
RDER5: 0
RDER6: 0
RDER7: 0
RDER8: 0

;UNIT ORDER AND DESCRIPTION TABLE *****

: THIS TABLE IS LOADED
: WITH UNIT NUMBERS AND
: THEIR DESCRIPTIONS IN
: THE ORDER THAT THEY
: WILL BE TESTED

;UNIT DROPS AND PICKS COUNTERS*****

;UNIT WRITE ERRORS*****

;UNIT READ ERRORS*****

1466 ;UNIT DATA ERRORS*****

1467			
1468	001134	000000	DATER1: 0
1469	001136	000000	DATER2: 0
1470	001140	000000	DATER3: 0
1471	001142	000000	DATER4: 0
1472	001144	000000	DATER5: 0
1473	001146	000000	DATER6: 0
1474	001150	000000	DATER7: 0
1475	001152	000000	DATER8: 0

1477 ;UNIT RETRY COUNTERS*****

1478			
1479	001154	000000	RTY1: 0
1480	001156	000000	RTY2: 0
1481	001160	000000	RTY3: 0
1482	001162	000000	RTY4: 0
1483	001164	000000	RTY5: 0
1484	001166	000000	RTY6: 0
1485	001170	000000	RTY7: 0
1486	001172	000000	RTY8: 0

1488 ;UNIT SOFT READ ERRORS*****

1489			
1490	001174	000000	GDRTY1: 0
1491	001176	000000	GDRTY2: 0
1492	001200	000000	GDRTY3: 0
1493	001202	000000	GDRTY4: 0
1494	001204	000000	GDRTY5: 0
1495	001206	000000	GDRTY6: 0
1496	001210	000000	GDRTY7: 0
1497	001212	000000	GDRTY8: 0

1499 ;UNIT HARD READ ERRORS*****

1500			
1501	001214	000000	BDRTY1: 0
1502	001216	000000	BDRTY2: 0
1503	001220	000000	BDRTY3: 0
1504	001222	000000	BDRTY4: 0
1505	001224	000000	BDRTY5: 0
1506	001226	000000	BDRTY6: 0
1507	001230	000000	BDRTY7: 0
1508	001232	000000	BDRTY8: 0

1510 ;UNIT EOT COUNTERS*****

1511			
1512	001234	000000	EOTCT1: 0
1513	001236	000000	EOTCT2: 0
1514	001240	000000	EOTCT3: 0
1515	001242	000000	EOTCT4: 0
1516	001244	000000	EOTCT5: 0
1517	001246	000000	EOTCT6: 0
1518	001250	000000	EOTCT7: 0
1519	001252	000000	EOTCT8: 0

1520

1574
1573
1572
1571
1570
1569
1568
1567
1566
1565
1564
1563
1562
1561
1560
1559
1558
1557
1556
1555
1554
1553
1552
1551
1550
1549
1548
1547
1546
1545
1544
1543
1542
1541
1540
1539
1538
1537
1536
1535
1534
1533
1532
1531
1530
1529
1528
1527
1526
1525
1524
1523
1522
1521
1520
1519
1518
1517
1516
1515
1514
1513
1512
1511
1510
1509
1508
1507
1506
1505
1504
1503
1502
1501
1500
1499
1498
1497
1496
1495
1494
1493
1492
1491
1490
1489
1488
1487
1486
1485
1484
1483
1482
1481
1480
1479
1478
1477
1476
1475
1474
1473
1472
1471
1470
1469
1468
1467
1466
1465
1464
1463
1462
1461
1460
1459
1458
1457
1456
1455
1454
1453
1452
1451
1450
1449
1448
1447
1446
1445
1444
1443
1442
1441
1440
1439
1438
1437
1436
1435
1434
1433
1432
1431
1430
1429
1428
1427
1426
1425
1424
1423
1422
1421
1420
1419
1418
1417
1416
1415
1414
1413
1412
1411
1410
1409
1408
1407
1406
1405
1404
1403
1402
1401
1400
1399
1398
1397
1396
1395
1394
1393
1392
1391
1390
1389
1388
1387
1386
1385
1384
1383
1382
1381
1380
1379
1378
1377
1376
1375
1374
1373
1372
1371
1370
1369
1368
1367
1366
1365
1364
1363
1362
1361
1360
1359
1358
1357
1356
1355
1354
1353
1352
1351
1350
1349
1348
1347
1346
1345
1344
1343
1342
1341
1340
1339
1338
1337
1336
1335
1334
1333
1332
1331
1330
1329
1328
1327
1326
1325
1324
1323
1322
1321
1320
1319
1318
1317
1316
1315
1314
1313
1312
1311
1310
1309
1308
1307
1306
1305
1304
1303
1302
1301
1300
1299
1298
1297
1296
1295
1294
1293
1292
1291
1290
1289
1288
1287
1286
1285
1284
1283
1282
1281
1280
1279
1278
1277
1276
1275
1274
1273
1272
1271
1270
1269
1268
1267
1266
1265
1264
1263
1262
1261
1260
1259
1258
1257
1256
1255
1254
1253
1252
1251
1250
1249
1248
1247
1246
1245
1244
1243
1242
1241
1240
1239
1238
1237
1236
1235
1234
1233
1232
1231
1230
1229
1228
1227
1226
1225
1224
1223
1222
1221
1220
1219
1218
1217
1216
1215
1214
1213
1212
1211
1210
1209
1208
1207
1206
1205
1204
1203
1202
1201
1200
1199
1198
1197
1196
1195
1194
1193
1192
1191
1190
1189
1188
1187
1186
1185
1184
1183
1182
1181
1180
1179
1178
1177
1176
1175
1174
1173
1172
1171
1170
1169
1168
1167
1166
1165
1164
1163
1162
1161
1160
1159
1158
1157
1156
1155
1154
1153
1152
1151
1150
1149
1148
1147
1146
1145
1144
1143
1142
1141
1140
1139
1138
1137
1136
1135
1134
1133
1132
1131
1130
1129
1128
1127
1126
1125
1124
1123
1122
1121
1120
1119
1118
1117
1116
1115
1114
1113
1112
1111
1110
1109
1108
1107
1106
1105
1104
1103
1102
1101
1100
1099
1098
1097
1096
1095
1094
1093
1092
1091
1090
1089
1088
1087
1086
1085
1084
1083
1082
1081
1080
1079
1078
1077
1076
1075
1074
1073
1072
1071
1070
1069
1068
1067
1066
1065
1064
1063
1062
1061
1060
1059
1058
1057
1056
1055
1054
1053
1052
1051
1050
1049
1048
1047
1046
1045
1044
1043
1042
1041
1040
1039
1038
1037
1036
1035
1034
1033
1032
1031
1030
1029
1028
1027
1026
1025
1024
1023
1022
1021
1020
1019
1018
1017
1016
1015
1014
1013
1012
1011
1010
1009
1008
1007
1006
1005
1004
1003
1002
1001
1000
999
998
997
996
995
994
993
992
991
990
989
988
987
986
985
984
983
982
981
980
979
978
977
976
975
974
973
972
971
970
969
968
967
966
965
964
963
962
961
960
959
958
957
956
955
954
953
952
951
950
949
948
947
946
945
944
943
942
941
940
939
938
937
936
935
934
933
932
931
930
929
928
927
926
925
924
923
922
921
920
919
918
917
916
915
914
913
912
911
910
909
908
907
906
905
904
903
902
901
900
899
898
897
896
895
894
893
892
891
890
889
888
887
886
885
884
883
882
881
880
879
878
877
876
875
874
873
872
871
870
869
868
867
866
865
864
863
862
861
860
859
858
857
856
855
854
853
852
851
850
849
848
847
846
845
844
843
842
841
840
839
838
837
836
835
834
833
832
831
830
829
828
827
826
825
824
823
822
821
820
819
818
817
816
815
814
813
812
811
810
809
808
807
806
805
804
803
802
801
800
799
798
797
796
795
794
793
792
791
790
789
788
787
786
785
784
783
782
781
780
779
778
777
776
775
774
773
772
771
770
769
768
767
766
765
764
763
762
761
760
759
758
757
756
755
754
753
752
751
750
749
748
747
746
745
744
743
742
741
740
739
738
737
736
735
734
733
732
731
730
729
728
727
726
725
724
723
722
721
720
719
718
717
716
715
714
713
712
711
710
709
708
707
706
705
704
703
702
701
700
699
698
697
696
695
694
693
692
691
690
689
688
687
686
685
684
683
682
681
680
679
678
677
676
675
674
673
672
671
670
669
668
667
666
665
664
663
662
661
660
659
658
657
656
655
654
653
652
651
650
649
648
647
646
645
644
643
642
641
640
639
638
637
636
635
634
633
632
631
630
629
628
627
626
625
624
623
622
621
620
619
618
617
616
615
614
613
612
611
610
609
608
607
606
605
604
603
602
601
600
599
598
597
596
595
594
593
592
591
590
589
588
587
586
585
584
583
582
581
580
579
578
577
576
575
574
573
572
571
570
569
568
567
566
565
564
563
562
561
560
559
558
557
556
555
554
553
552
551
550
549
548
547
546
545
544
543
542
541
540
539
538
537
536
535
534
533
532
531
530
529
528
527
526
525
524
523
522
521
520
519
518
517
516
515
514
513
512
511
510
509
508
507
506
505
504
503
502
501
500
499
498
497
496
495
494
493
492
491
490
489
488
487
486
485
484
483
482
481
480
479
478
477
476
475
474
473
472
471
470
469
468
467
466
465
464
463
462
461
460
459
458
457
456
455
454
453
452
451
450
449
448
447
446
445
444
443
442
441
440
439
438
437
436
435
434
433
432
431
430
429
428
427
426
425
424
423
422
421
420
419
418
417
416
415
414
413
412
411
410
409
408
407
406
405
404
403
402
401
400
399
398
397
396
395
394
393
392
391
390
389
388
387
386
385
384
383
382
381
380
379
378
377
376
375
374
373
372
371
370
369
368
367
366
365
364
363
362
361
360
359
358
357
356
355
354
353
352
351
350
349
348
347
346
345
344
343
342
341
340
339
338
337
336
335
334
333
332
331
330
329
328
327
326
325
324
323
322
321
320
319
318
317
316
315
314
313
312
311
310
309
308
307
306
305
304
303
302
301
300
299
298
297
296
295
294
293
292
291
290
289
288
287
286
285
284
283
282
281
280
279
278
277
276
275
274
273
272
271
270
269
268
267
266
265
264
263
262
261
260
259
258
257
256
255
254
253
252
251
250
249
248
247
246
245
244
243
242
241
240
239
238
237
236
235
234
233
232
231
230
229
228
227
226
225
224
223
222
221
220
219
218
217
216
215
214
213
212
211
210
209
208
207
206
205
204
203
202
201
200
199
198
197
196
195
194
193
192
191
190
189
188
187
186
185
184
183
182
181
180
179
178
177
176
175
174
173
172
171
170
169
168
167
166
165
164
163
162
161
160
159
158
157
156
155
154
153
152
151
150
149
148
147
146
145
144
143
142
141
140
139
138
137
136
135
134
133
132
131
130
129
128
127
126
125
124
123
122
121
120
119
118
117
116
115
114
113
112
111
110
109
108
107
106
105
104
103
102
101
100
99
98
97
96
95
94
93
92
91
90
89
88
87
86
85
84
83
82
81
80
79
78
77
76
75
74
73
72
71
70
69
68
67
66
65
64
63
62
61
60
59
58
57
56
55
54
53
52
51
50
49
48
47
46
45
44
43
42
41
40
39
38
37
36
35
34
33
32
31
30
29
28
27
26
25
24
23
22
21
20
19
18
17
16
15
14
13
12
11
10
9
8
7
6
5
4
3
2
1
0

001254 000000
001274 000000
001314 000000
001334 000000
001354 000000
001374 000000
001414 000000
001434 000000
001454 000000
001474 000000
001514 000000
001534 000000
001554 000000
001574 000000
001614 000000
001634 000000
001654 000000
001760 000000
002064 000000
002170 000000
002274 000000
002400 000000
002504 000000
002610 000000

BP00: 0
BP10: 0
BP20: 0
BP30: 0
BP40: 0
BP50: 0
BP60: 0
BP70: 0
B000: 0
B010: 0
B020: 0
B030: 0
B040: 0
B050: 0
B060: 0
B070: 0
BT00: 0
BT01: 0
BT02: 0
BT03: 0
BT04: 0
BT05: 0
BT06: 0
BT07: 0

:DROPS + PICKS PER CHANNEL PER UNIT.*****

0
=.+16
=.+16
=.+16
=.+16
=.+16
=.+16
=.+16
=.+16
=.+16
=.+16
=.+16
=.+16
=.+16
=.+16
=.+16
=.+16
=.+16
0
=.+102
=.+102
=.+102
=.+102
=.+102
=.+102
=.+102
=.+102
=.+102
=.+102

;UNIT BAD TAPE COUNTER: 16 PER DRIVE

1575
1576
1577
1578
1579
1580
1581
1582
1583
1584
1585
1586
1587
1588
1589
1590
1591
1592
1593
1594
1595
1596
1597
1598
1599
1600
1601
1602
1603
1604
1605

002714 001654
002716 001760
002720 002064
002722 002170
002724 002274
002726 002400
002730 002504
002732 002610

002734 002734
002736 012552
002740 012754
002742 012776
002744 013004
002746 013032
002750 013044
002752 013054
002754 013064
002756 013074
002760 013104
002762 013126
002764 013152
002766 013162
002770 013172

:UNIT BAD TAPE POINTERS*****

BTADDR: BT00
BT01
BT02
BT03
BT04
BT05
BT06
BT07

:DATA PATTERN GENERATORS*****

DATBL: . :ENTRY TABLE
DATA0: DAT0 :EXTERNAL INPUT FROM H/S READER
DATA1: DAT1 :ALL ONES
DATA2: DAT2 :ALL ZEROS
DATA3: DAT3 :WALKING ONE
DATA4: DAT4 :WALKING ZERO
DATA5: DAT5 :ALTERNATING ONE/ZERO
DATA6: DAT6 :ALTERNATING ZERO/ONE
DATA7: DAT7 :ALTERNATING ONE/ZERO IN ALTERNATING CHARACTERS
DATA10: DAT10 :ALTERNATING ZERO/ONE IN ALTERNATING CHARACTERS
DATA11: DAT11 :ALL BITS 0-377
DATA12: DAT12 :ALL BITS 377-0
DATA13: DAT13 :ALTERNATING CHARACTERS 0 AND 377
DATA14: DAT14 :ALTERNATING CHARACTERS 377 AND 0
DATA15: DAT15 :WALKING ZERO REPEATED FOUR TIMES

1606
1607
1608
1609
1610
1611
1612
1613
1614
1615
1616
1617
1618
1619
1620
1621
1622
1623
1624
1625
1626
1627
1628
1629
1630
1631
1632
1633
1634
1635
1636
1637
1638
1639
1640
1641
1642
1643
1644
1645
1646
1647
1648
1649
1650
1651
1652
1653
1654
1655
1656
1657
1658
1659
1660
1661

002772 005037 021624
002776 012737 177570 000652
003004 005737 000042
003010 001436
003012 012706 000500
003016 012704 023144
003022 004737 020530
003026 122737 000004 000041
003034 001006
003036 012704 026120
003042 004737 020530
003046 000137 004622
003052 012737 000176 000652
003060 012700 001014
003064 022720 177777
003070 001404
003072 062737 000401 004716
003100 000771
003102 000137 000210
003106 012737 000001 000700
003114 005037 013304
003120 000137 003146
003124 005037 000700
003130 012706 000500
003134 004737 022040
003140 000451
003142 005037 000700
003146 012700 000702
003152 012701 000044
003156 005020
003160 005301
003162 001375
003164 012700 000510
003170 012701 001074
003174 005021
003176 005300

.EVEN
:*****
:PROGRAM START AND SEQUENCE FORMATTER:
:THIS ROUTINE IS USED TO PERFORM ALL HOUSEKEEPING,
:DECIDE WHICH TRANSPORT TO TEST AND ITS AVAILABILITY,
:LOAD THE WRITE BUFFER WITH THE SELECTED DATA PATTERN,
:GENERATE ANY RANDOM NUMBER AND THEN EXECUTE
:THE TEST CYCLE REQUESTED BY THE SWITCH SETTING.
:AT THE END OF THE TEST CYCLE THE NEXT UNIT IS SELECTED
:AND CHECKED FOR AVAILABILITY AND THE TEST CYCLE IS
:EXECUTED ON IT.
:THE NUMBER OF BITS DROPPED OR PICKED MAY BE PRINTED
:AT THE END OF EACH TEST CYCLE VIA CONSOLE SWITCH FOUR (4).
:*****
START: CLR ASEG ;CLEAR AUTO SEQ FLAG
MOV #177570,SWR ;PRESET FOR CONSOLE SWITCHES
TST #42 ;SEE IF CHAIN MODE
BEQ STAUT ;IF NOT: BR
MOV #500,SP ;SET UP STACK POINTER
MOV #MSG31,R4
JSR PC,TTOUT ;PRINT TITLE
CMPB #4,#41 ;SEE IF LOAD MEDIUM
BNE 1\$;IF NOT: BR
MOV #MSG97,R4
JSR PC,TTOUT ;PRINT NO TEST LOAD MEDIUM
JMP REOTB ;END TEST
1\$: MOV #176,SWR ;SET FOR SOFTWARE SWITCHES
MOV #UN2,RO ;SET UNIT POINTER
2\$: CMP #-1,(RO)+ ;SEE IF END OF UNITS
BEQ 3\$;IF SO: BR
ADD #401,REOTC ;ELSE BUMP UNIT EOT COUNTER
BR 2\$
3\$: JMP CHAIN ;GO DO CHAIN START
STAUT: MOV #1,TINF ;SET TTY ENTRY FLAG
CLR RDFL ;CLEAR RANDOM DATA FLAG
JMP STARTB
STARTA: CLR TINF ;CLEAR TTY ENTRY FLAG
MOV #500,SP ;SET STACK POINTER
JSR PC,SUSWR ;CHECK FOR SOFTSWR
BR STAUTO
STARTE: CLR TINF ;CLEAR INPUT FLAG
STARTB: MOV #TOB,RO
MOV #44,R1
STARTO: CLR (RO)+ ;CLEAR FLAGS AND COUNTERS
DEC R1
BNE STARTC
MOV #510,RO ;SET SIZE OF TABLE
MOV #WTER1,R1 ;SET START OF TABLE
STARTC: CLR (R1)+ ;CLEAR STATISTICS TABLES
DEC RO

1662	003200	001375			BNE	STARTC		;CLEAR ALL
1663	003202	012737	177777	012750	MOV	#-1,PATS		;RESET PATTERN
1664	003210	012737	177777	012752	MOV	#-1,PARS		;RESET PARITY
1665	003216	012737	000001	000720	MOV	#1,BLCNTR		;PRESET BLOCK COUNTER
1666	003224	005077	175352		CLR	AMTC		
1667	003230	052777	010000	175344	BIS	#10000,AMTC		;POWER CLEAR CONTROLLER
1668	003236	012706	000500		STARTD: MOV	#500,SP		
1669	003242	004737	022040		JSR	PC,SUSWR		;CHECK FOR SORTSWR
1670	003246	012777	000340	175374	13: MOV	#340,SPSW		
1671	003254	004737	010722		JSR	PC,TINP		;GO GET PARAMETERS FROM TTY
1672	003260	004737	004110		JSR	PC,RANSET		;GO RESET BASE
1673	003264	005000			STAUTO: CLR	RO		;POINT TO FIRST ENTRY
1674	003266	022737	000176	000652	CMP	#SWREG,SWR		;TEST FOR SOFTSWR
1675	003274	001005			BNE	STARDA		
1676	003276	005737	000042		TST	#42		;SEE IF CHAIN MODE
1677	003302	001002			BNE	STARDA		;IF SO: BR
1678	003304	004737	022164		JSR	PC,CNTLU		;ASK FOR CONTROL SETTINGS
1679	003310	005160	001012		STARDA: COM	UNI(RO)		;SEE IF LAST ENTRY
1680	003314	001411			BEQ	STAROB		;IF SO: BR
1681	003316	005160	001012		COM	UNI(RO)		
1682	003322	042760	100200	001012	BIC	#100200,UNI(RO)		;CLEAR EOT/DROPPED FLAG
1683	003330	062700	000002		ADD	#2,RO		;POINT TO NEXT UNIT ENTRY
1684	003334	000137	003310		JMP	STARDA		;CONTINUE CLEARING
1685	003340	005160	001012		STAROB: COM	UNI(RO)		
1686	003344	013703	004716		MOV	REOTC,R3		
1687	003350	000303			SWAB	R3		
1688	003352	110337	004716		MOV	R3,REOTC		;RESTORE EOT CNTR
1689	003356	012777	000100	175272	START1: MOV	#100,ATKS		;SET TTY INTERRUPT ENABLE
1690	003364	013700	000734		MOV	UNP,RO		;RO = UNIT TABLE POINTER
1691	003370	005160	001012		COM	UNI(RO)		
1692	003374	001407			BEQ	STAR1B		;IF LAST UNIT IN STRING: BR
1693	003376	005160	001012		COM	UNI(RO)		
1694	003402	016037	001012	000616	STAR1A: MOV	UNI(RO),UDES		;LOAD NEXT UNIT DESCRIPTION
1695	003410	000137	003542		JMP	STAR14		
1696	003414	005237	000720		STAR1B: INC	BLCNTR		;BUMP BLOCK COUNTER
1697	003420	005737	021624		TST	ASEQF		;SEE IF AUTO SEQ
1698	003424	001414			BEQ	STAR1C		;IF NOT: BR
1699	003426	023737	000720	021622	CMP	BLCNTR,ABLCNT		;SEE IF DONE SEQ
1700	003434	001010			BNE	STAR1C		;IF NOT: BR
1701	003436	005160	001012		COM	UNI(RO)		;RESET UNIT TABLE TERMINATOR
1702	003442	012737	000001	000720	MOV	#1,BLCNTR		;RESET BLOCK COUNTER
1703	003450	005037	000734		CLR	UNP		;RESET UNIT POINTER
1704	003454	000207			RTS	PC		;RETURN TO AUTO SEQ
1705	003456	005037	000734		STAR1C: CLR	UNP		
1706	003462	005160	001012		COM	UNI(RO)		
1707	003466	005000			CLR	RO		
1708	003470	016037	001012	000616	MOV	UNI(RO),UDES		;LOAD FIRST UNIT DESCRIPTION
1709	003476	032777	000200	175146	BIT	#200,JSWR		;SEE IF RANDOM RECORD SIZE
1710	003504	001402			BEQ	STAR12		;IF NOT: BR
1711	003506	004737	010644		JSR	PC,CCNTR		;GO GENERATE RANDOM CHAR COUNT
1712	003512	032777	000400	175132	START2: BIT	#400,JSWR		;SEE IF RANDOM DATA
1713	003520	001402			BEQ	STAR13		;IF NOT: BR
1714	003522	004737	013236		JSR	PC,DATR		;GO GENERATE RANDOM DATA
1715	003526	032777	000100	175116	START3: BIT	#100,JSWR		;SEE IF RANDOM RECORD COUNT
1716	003534	001402			BEQ	STAR14		;IF NOT: BR
1717	003536	004737	010676		JSR	PC,RCNTR		;GO GENERATE RANDOM RECORD COUNT

1718	003542	032760	100000	001012	START4:	BIT	#100000,UNI(RO)	:SEE IF UNIT REACHED EOT OR DROPPED
1719	003550	001404				BEQ	START4	:IF NOT: BR
1720	003552	062737	000002	000734		ADD	#2,UNP	:POINT TO NEXT UNIT
1721	003560	000676				BR	START1	
1722	003562	013777	000616	175012	STAR40:	MOV	UDES,2MTC	:SET UNIT NUMBER
1723	003570	004737	021226			JSR	PC,STOLY	:GO AWAIT ASSURED STATUS
1724	003574	032777	000001	174776		BIT	#1,2MTS	:SEE IF TUR
1725	003602	001030				BNE	STAR46	:IF SO: BR
1726	003604	032777	000002	174766		BIT	#2,2MTS	:SEE IF REWINDING
1727	003612	001414				BEQ	STAR45	:IF NOT: BR
1728	003614	004737	017506			JSR	PC,PAPRT	:PRINT HEADER
1729	003620	012704	025477			MOV	#MSG89,R4	
1730	003624	004737	020530			JSR	PC,TTOUT	:PRINT REWIND MSG
1731	003630	032777	000001	174742	STAR44:	BIT	#1,2MTS	
1732	003636	001774				BEQ	STAR44	:AWAIT REWIND DONE
1733	003640	000137	003664			JMP	STAR46	
1734	003644	004737	017506		STAR45:	JSR	PC,PAPRT	:PRINT HEADER
1735	003650	012704	023703			MOV	#MSG49,R4	
1736	003654	004737	020530			JSR	PC,TTOUT	:PRINT NOT AVAIL
1737	003660	000137	020050			JMP	DRPDRV	:GO DROP DRIVE
1738	003664	005037	001010		STAR46:	CLR	STCDFL	:CLEAR 7 TRK CORE DUMP FLAG
1739	003670	032777	000020	174702		BIT	#20,2MTS	:SEE IF 7 TRK
1740	003676	001411				BEQ	1\$:IF NOT: BR
1741	003700	013704	000616			MOV	UDES,R4	:GET UNIT DESCRIPTION
1742	003704	042704	117777			BIC	#117777,R4	:MASK DENSITY
1743	003710	022704	060000			CMP	#60000,R4	:SEE IF CORE DUMP
1744	003714	001002				BNE	1\$:IF NOT: BR
1745	003716	005237	001010			INC	STCDFL	:ELSE SET FLAG
1746	003722	004737	012370		1\$:	JSR	PC,DSUP	:GO SET UP WRITE DATA
1747	003726	004737	004720			JSR	PC,RWIND	:REWIND
1748	003732	004737	005254			JSR	PC,WRITE	:WRITE
1749	003736	013737	000636	000730		MOV	T\$AL,STAL	:SET TURN AROUND DELAY
1750	003744	004737	010634			JSR	PC,STALL	:DELAY
1751	003750	004737	006626			JSR	PC,RSEQ	:GO TO READ SEQUENCER
1752	003754	013737	000636	000730		MOV	T\$AL,STAL	:SET TURN AROUND DELAY
1753	003762	004737	010634			JSR	PC,STALL	:DELAY
1754	003766	032777	000020	174656		BIT	#20,2SWR	:SEE IF SHOULD PRINT DROPS AND PICK
1755	003774	001410				BEQ	START5	:IF NOT: BR
1756	003776	012700	000001			MOV	#1,RO	:SET RECORD COUNTER TO 1
1757	004002	005237	000772			INC	BT\$F	:SET FOR STAT PRINT ONLY
1758	004006	004737	015370			JSR	PC,PRSTAT	:PRINT STATISTICS
1759	004012	005037	000772			CLR	BT\$F	:CLEAR FLAG
1760	004016	017700	174630		START5:	MOV	2\$WR,RO	:LOAD SWR
1761	004022	042700	177762			BIC	#177762,RO	:MASK READ/WRITE SWITCHES
1762	004026	022700	000015			CMP	#15,RO	:SEE IF HAVE READ OR WRITE
1763	004032	001424				BEQ	START8	:IF NOT: BR
1764	004034	032777	000001	174536	START6:	BIT	#1,2MTS	:SEE IF HAVE UNIT READY
1765	004042	001013				BNE	START7	:IF SO: BR
1766	004044	005337	000730			DEC	STAL	
1767	004050	001371				BNE	START6	:DELAY FOR TUR
1768	004052	004737	017506			JSR	PC,PAPRT	:PRINT HEADER
1769	004056	012704	023703			MOV	#MSG49,R4	
1770	004062	004737	020530			JSR	PC,TTOUT	:PRINT NOT AVAIL
1771	004066	000137	020050			JMP	DRPDRV	:GO DROP DRIVE
1772	004072	062737	000002	000734	START7:	ADD	#2,UNP	:POINT TO NEXT UNIT
1773	004100	005077	174476			CLR	2MTC	

G04

```

1774 004104 000137 003356      START8: JMP      START1      ;CONTINUE
1775                                     ;RANDOM BASE RESET*****
1776
1777
1778 004110 012737 153624 000672 RANSET: MOV      #153624, RANBAS ;RESET BASE
1779 004116 012737 032561 000676      MOV      #32561, RANSABV ;RESET BUFFER
1780 004124 013737 000642 000620      MOV      RCSAV, RCNT ;RESET RECORD COUNT
1781 004132 013737 000644 000622      MOV      CCSAV, CARCNT ;RESET CHAR COUNT
1782 004140 000207
RTS      PC

```

```

1783
1784
1785
1786
1787
1788
1789
1789
1790
1791
1792
1793
1794
1795 004142 013777 000616 174432 REOT:
1796 004150 032777 000010 174422 REOT1:
1797 004156 001374
1798 004160 052777 000017 174414
1799 004166 004737 017506
1800 004172 032737 000004 000746
1801 004200 001405
1802 004202 012704 025470
1803 004206 004737 020530
1804 004212 000404
1805 004214 032737 000002 000746 1$:
1806 004222 001405
1807 004224 012704 024306 2$:
1808 004230 005037 000746
1809 004234 000437
1810 004236 005737 000746 REOT1C:
1811 004242 001405
1812 004244 012704 024116
1813 004250 005037 000746
1814 004254 000427
1815 004256 005737 021624 REOT1D:
1816 004262 001406
1817 004264 005737 000624
1818 004270 100403
1819 004272 012704 025334
1820 004276 000416
1821 004300 012704 022572 REOT1A:
1822 004304 004737 020530
1823 004310 013704 000734
1824 004314 005264 001234
1825 004320 016403 001234
1826 004324 004737 020716
1827 004330 012704 022606
1828 004334 004737 020530 REOT1B:
1829 004340 004737 015400
1830 004344 032777 000200 174230 REOT2:
1831 004352 001774
1832 004354 105337 004716
1833 004360 001410
1834 004362 013700 000734
1835 004366 052760 100000 001012
1836 004374 005726
1837 004376 000137 004072
1838 004402 000337 004716 REOT3:

```

```

*****
;REWIND FROM EOT:
;
;WHEN ANY TRANSPORT BEING TESTED REACHES END OF TAPE
;DURING A READ OR WRITE OPERATION, IT WILL BE REWOUND
;AND FLAGGED AS UNAVAILABLE UNTIL ALL AVAILABLE UNITS
;HAVE REACHED EOT AT WHICH TIME ALL TESTING WILL BE RESUMED
;AT A BLOCK COUNT OF ONE (1). A MESSAGE WILL BE
;PRINTED ON THE SUPERVISORS CONSOLE AS EACH UNIT REACHES
;EOT AND IS REWOUND.
*****
;LOAD COMMAND REGISTER
;AWAIT SETTLE DOWN RESET
;START REWIND
;PRINT HEADER
;ERROR DURING RETRY?
;IF NOT: BR
;PRINT RETRY
;BACKSPACE ERROR
;IF NOT: BR
;POINT TO BACKSPACE ERROR MESSG.
;CLEAR BAD TAPE FLAG
;TEST BAD TAPE FLAG
;IF NOT: BR
;SET UP BAD TAPE MESSAGE
;CLEAR BAD TAPE FLAG
;IS IT AUTO SEQ?
;IF NOT: BR
;IS IT RANDOM DATA?
;IF SO: BR
;PRINT EARLY ASEQ EOT MESSG.
;PRINT EOT MESSAGE
;BUMP EOT COUNTER
;PRINT EOT COUNT
;PRINT REWIND MSG
;PRINT STATS WITHOUT HEADER
;AWAIT CUR
;SEE IF LAST UNIT TO REACH EOT
;IF SO: BR
;SET EOT FLAG
;GO TO NEXT UNIT

```

1839	004406	013700	004716			MOV	REOTC,RO	
1840	004412	000337	004716			SWAB	REOTC	
1841	004416	110037	004716			MOV	RD,REOTC	;RESTORE EOT UNIT COUNTER
1842	004422	005037	000734			CLR	UNP	
1843	004426	013700	000734			MOV	UNP,RO	;POINT TO FIRST UNIT
1844	004432	016037	001012	000616	REOT4:	MOV	UNI(RO),UDES	;LOAD UNIT DESCRIPTION
1845	004440	032737	000200	000616		BIT	#200,UDES	;SEE IF UNIT IS DRCPED
1846	004446	001034				BNE	REOT6A	;IF SO: BR
1847	004450	013777	000616	174124		MOV	UDES,DMTC	;LOAD COMMAND REGISTER
1848	004456	032777	000002	174114	REOT5:	BIT	#2,DMTS	
1849	004464	001374				BNE	REOT5	;AWAIT RWS RESET
1850	004466	032777	000040	174104		BIT	#40,DMTS	;SEE IF HAVE BOT
1851	004474	001012				BNE	REOT6	;IF SO: BR
1852	004476	012700	000001			MOV	#1,RO	
1853	004502	004737	017506			JSR	PC,PAPRT	;PRINT HEADER
1854	004506	012704	023655			MOV	#MSG48,R4	
1855	004512	004737	020530			JSR	PC,TTOUT	;PRINT BOT ERROR
1856	004516	000137	020050			JMP	DRPDRV	;GO DROP DRIVE
1857	004522	032777	000010	174050	REOT6:	BIT	#10,DMTS	;SEE IF SWDN IS RESET
1858	004530	001374				BNE	REOT6	;IF NOT: AWAIT SWDN RESET
1859	004532	042760	100200	001012		BIC	#100200,UNI(RO)	;CLEAR EOT/DROPPED FLAG
1860	004540	062737	000002	000734	REOT6A:	ADD	#2,UNP	
1861	004546	013700	000734			MOV	UNP,RO	;POINT TO NEXT UNIT
1862	004552	005160	001012			COM	UNI(RO)	;SEE IF LAST UNIT
1863	004556	001404				BEQ	REOT7	;IF SO: BR
1864	004560	005160	001012			COM	UNI(RO)	
1865	004564	000137	004432			JMP	REOT4	;DO NEXT UNIT
1866	004570	005160	001012		REOT7:	COM	UNI(RO)	
1867	004574	012737	000001	000720		MOV	#1,BLCNTR	;SET TO BLOCK COUNT 1
1868	004602	005037	000734			CLR	UNP	
1869	004606	005000				CLR	RO	;SET TO RESTART WITH FIRST UNIT
1870	004610	005726				TST	(SP)+	;RESET STACK
1871	004612	005737	021624			TST	ASEQF	;SEE IF AUTO SEQ
1872	004616	001401				BEQ	REOT8	;IF NOT: BR
1873	004620	000207				RTS	PC	;RETURN
1874	004622	012704	023473		REOT8:	MOV	#MSG39,R4	
1875	004626	004737	020530			JSR	PC,TTOUT	;PRINT END OF PASS
1876	004632	005737	000630			TST	SPFLG	;SEE IF SINGLE PASS
1877	004636	001412				BEQ	REOTX	;IF NOT: BR
1878	004640	013704	000042		REOT9:	MOV	#42,R4	
1879	004644	001405				BEQ	HERE	;IF NOT CHAIN MODE: BR
1880	004646	000005				RESET		
1881	004650	004714			SENDAD:	JSR	PC,(R4)	
1882	004652	000240				NOP		
1883	004654	000240				NOP		
1884	004656	000240				NOP		
1885	004660	000240			HERE:	NOP		
1886	004662	000000			REOT10:	HALT		
1887	004664	012706	000500		REOTX:	MOV	#500,SP	;RESET STACK
1888	004670	004737	004110			JSR	PC,RANSET	;GO RESET RANDOM BASE
1889	004674	012737	177777	012750		MOV	#-1,PATS	;PRESET PATTERN
1890	004702	005037	013304			CLR	RDFL	;CLEAR RANDOM DATA FLAG
1891	004706	005037	001006			CLR	DUCTR	;CLEAR DROPPED UNITER COUNTER
1892	004712	000137	003264			JMP	STAUTO	;RESTART AT BLOCK NUMBER ONE
1893	004716	000401			REOTC:	401		;ECT UNIT COUNTER(DEFAULT TO ONE UNIT)


```

1894
1895
1896
1897
1898
1899
1900
1901
1902
1903 004720 032777 001000 173724 RWND: BIT #1000,JSWR ;SEE IF SHOULD REWIND
1904 004726 001001 BNE RWNDA ;IF SO: BR
1905 004730 000207 RTS PC ;ELSE EXIT
1906 004732 005037 000734 RWNDA: CLR UNP ;CLEAR POINTER
1907 004736 000337 004716 SWAB REOTC
1908 004742 013700 004716 MOV REOTC,RO
1909 004746 000337 004716 SWAB REOTC
1910 004752 110037 004716 MOVB RO,REOTC ;RESTORE EOT UNIT COUNTER
1911 004756 013700 000734 RWND0: MOV UNP,RO ;POINT TO UNIT ENTRY
1912 004762 005160 001012 COM UN1(RO) ;SEE IF LAST ENTRY
1913 004766 001424 BEQ RWND2 ;IF SO: BR
1914 004770 005160 001012 COM UN1(RO)
1915 004774 016037 001012 000616 MOV UN1(RO),UDES ;SET UNIT DESCRIPTION
1916 005002 013777 000616 173572 MOV UDES,AMTC ;LOAD COMMAND REGISTER
1917 005010 052777 000017 173564 BIS #17,AMTC ;START REWIND
1918 005016 032777 000200 173556 RWND1: BIT #200,AMTC
1919 005024 001774 BEQ RWND1 ;AWAIT CUR
1920 005026 062737 000002 000734 ADD #2,UNP ;BUMP POINTER
1921 005034 000137 004756 JMP RWND0 ;DO NEXT UNIT
1922 005040 005160 001012 RWND2: COM UN1(RO)
1923 005044 005037 000734 RWND3: CLR UNP ;CLEAR POINTER
1924 005050 013700 000734 MOV UNP,RO ;POINT TO UNIT ENTRY
1925 005054 005160 001012 COM UN1(RO) ;SEE IF LAST ENTRY:
1926 005060 001452 BEQ RWNDX ;IF SO: BR
1927 005062 005160 001012 COM UN1(RO)
1928 005066 016037 001012 000616 MOV UN1(RO),UDES ;SET UNIT DESCRIPTION
1929 005074 032737 000200 000616 BIT #200,UDES ;SEE IF UNIT IS DROPPED
1930 005102 001403 BEQ IS ;IF NOT: BR
1931 005104 005337 004716 DEC REOTC ;ELSE DECREMENT EOT UNIT CNTR
1932 005110 000417 BR RWND5
1933 005112 013777 000616 173462 IS: MOV UDES,AMTC ;LOAD COMMAND REGISTER
1934 005120 032777 000002 173452 RWND4: BIT #2,AMTS
1935 005126 001374 BNE RWND4 ;AWAIT RWS RESET
1936 005130 032777 000040 173442 BIT #40,AMTS ;SEE IF HAVE BOT
1937 005136 001411 BEQ RWND6 ;IF NOT: BR
1938 005140 032777 000010 173432 IS: BIT #10,AMTS ;SEE IF SDWN SET
1939 005146 001374 BNE IS ;IF SO AWAIT RESET
1940 005150 062737 000002 000734 RWND5: ADD #2,UNP ;BUMP POINTER
1941 005156 000137 005050 JMP RWND3 ;DO NEXT UNIT
1942 005162 013700 000001 RWND6: MOV #1,RO
1943 005166 004737 017506 JSR PC,PAPRT ;PRINT HEADER
1944 005172 012704 023655 MOV #MSG48,R4
1945 005176 004737 020530 JSR PC,TTOUT ;PRINT NO BOT
1946 005202 000137 020050 JMP DRPDRV ;GO DROP DRIVE
1947 005206 005160 001012 RWNDX: COM UN1(RO)
1948 005212 005000 CLR RO
1949 005214 010037 000734 IS: MOV RO,UNP

```

K04

1950	005220	016037	001012	000616	MOV	UN1'RO), UDES	
1951	005226	032737	100200	000616	BIT	#100200, UDES	; SEE IF UNIT DROPPED
1952	005234	001403			BEO	2\$; IF NOT: BR
1953	005236	062700	C00002		ADD	#2, RO	
1954	005242	C00764			BR	1\$	
1955	005244	012737	C00001	000720	MOV	#1, BLCNTR	
1956	005252	000207			RTS	PC	

1957
1958
1959
1960
1961
1962
1963
1964
1965
1966
1967
1968
1969
1970
1971
1972
1973
1974
1975
1976
1977
1978
1979
1980
1981
1982
1983
1984
1985
1986
1987
1988
1989
1990
1991
1992
1993
1994
1995
1996
1997
1998
1999
2000
2001
2002
2003
2004
2005
2006
2007
2008
2009
2010
2011
2012

005254 032777 000001 173370 WRITE:
005262 001076
005264 012737 022452 000716
005272 005077 173304
005276 005077 173276
005302 005037 000760
005306 013700 000620
005312 013777 000622 173264 W0:
005320 012777 026200 173260
005326 005737 000764
005332 001406
005334 112777 000014 173240
005342 005037 000764
005346 000403
005350 112777 000004 173224 W0A:
005356 012737 005370 000724 W0B:
005364 000137 017006
005370 005737 017402 W1A:
005374 001413
005376 005037 017402
005402 013701 000620
005406 160001
005410 005201
005412 010137 000760
005416 052737 100000 000760
005424 032777 010000 173220 W1:
005432 001002
005434 004737 016036
005440 013737 000634 000730 W3:
005446 004737 010634
005452 005737 000754
005456 001401
005460 000207 W3A0:
005462 005737 000742 W3A:

```
*****  
:WRITE ROUTINE:  
:  
:THIS ROUTINE IS USED TO WRITE ONTO TAPE THE BLOCK  
:OF DATA DESCRIBED BY THE OPERATOR AND SET UP  
:IN THE SEQUENCE FORMATTER. THE TAPE UNIT TO BE USED  
:HAS BEEN ASSIGNED BY THE SEQUENCE FORMATTER AND  
:ITS PARAMETERS SET IN A UNIT DESCRIPTION WORD.  
:AS EACH RECORD OF THE BLOCK IS WRITTEN, IT IS CHECKED  
:FOR STATUS ERRORS, WORD COUNT ZERO, AND CORRECT CURRENT  
:MEMORY ADDRESS. IF THE WRITE OPERATION CAUSES THE SELECTED  
:UNIT TO REACH END OF TAPE (EOT), THE UNIT IS REWOUND  
:AND FLAGGED AS UNAVAILABLE FOR TESTING UNTIL ALL AVAILABLE  
:UNITS HAVE REACHED EOT AT WHICH TIME ALL UNITS WILL  
:BE RESTARTED AT A BLOCK COUNT OF ONE (1).  
:ERROR CHECKING MAY BE DISALLOWED VIA CONSOLE SWITCH  
:TWELVE (12).  
:WRITING TO TAPE MAY BE DISALLOWED VIA CONSOLE SWITCH  
:ZERO (0).  
*****  
:SEE IF SHOULD WRITE  
:IF NOT: BR  
:SET ERROR MSG ADDRESS  
:CLEAR EOT FLAG  
:RO=RECORD COUNT  
:LOAD CHAR COUNT  
:SET DATA ADDR  
:SEE IF SHOULD ERASE  
:IF NOT: BR  
:SET OP-CODE: WRITE W/EXTENDED IRG  
:CLEAR ERASE FLAG  
:SET WRITE OP COMMAND  
:SET RETURN ADDRESS  
:GO EXECUTE COMMAND  
:SEE IF EOT FOUND  
:IF NOT: BR  
:CLEAR WRITE EOT FLAG  
:BUILD SHORTENED RECORD COUNT  
:SET EOT FLAG  
:SEE IF SHOULD CHECK ERRORS  
:IF NOT: BR  
:GO CHECK EPRORS  
:SET DELAY  
:DELAY  
:SEE IF RETRY  
:IF NOT: BR  
:ELSE RETURN TO RETRY ROUTINE  
:SEE IF WRITE ERROR
```

2013	005466	001453		BEQ	W3D		; IF NOT: BR
2014	005470	013704	000734	MOV	UNP,R4		; BUMP WRITE ERROR
2015	005474	005264	001074	INC	WTER1(R4)		
2016	005500	005037	000742	CLR	SERFL		; CLEAR STATUS ERROR FLAG
2017	005504	032777	000002	BIT	#2, QSWR	173140	; SEE IF RETRY -- SW1
2018	005512	001041		BNE	W3D		; IF NOT: BR
2019	005514	042737	072521	BIC	#072521,ERSAV	000740	; MASK UNRECOVERABLE ERROR
2020	005522	005737	000740	TST	ERSAV		; SEE IF RETRYABLE ERROR
2021	005526	001411		BEQ	W3B		; IF SO: BR
2022	005530	012704	023735	MOV	#MSG52,R4		
2023	005534	004737	020530	JSR	PC,TTOUT		; PRINT NON-RETRYABLE ERROR FLAG
2024	005540	012704	022452	MOV	#MSG5,R4		
2025	005544	004737	020530	JSR	PC,TTOUT		; PRINT WRITE ERROR TAG
2026	005550	000422		BR	W3D		
2027	005552	013704	000734	MOV	UNP,R4	W3B:	
2028	005556	005264	001154	INC	RTY!(R4)		; BUMP RETRY CNTR
2029	005562	032777	002000	BIT	#2000, QSWR	173062	; SEE IF PRINT ERRORS
2030	005570	001004		BNE	W3C		; IF NOT: BR
2031	005572	012704	023755	MOV	#MSG53,R4		
2032	005576	004737	020530	JSR	PC,TTOUT		; PRINT ORIGINAL ERROR TAG
2033	005602	005037	000752	CLR	RTCNT	W3C:	; CLEAR RETRY NUMBER
2034	005606	005037	000750	CLR	RPCNT		; CLEAR REPEAT COUNTER
2035	005612	004737	006142	JSR	PC,WRTY		; GO RETRY WRITE ERROR
2036	005616	005037	000754	CLR	RTYFL	W3D:	; CLEAR RETRY FLAG
2037	005622	005737	000760	TST	EOTREC		; WAS EOT REACHED?
2038	005626	100403		BMI	WEX		; IF SO: BR
2039	005630	005300		DEC	RD		; SEE IF DONE ALL
2040	005632	001227		BNE	W0		; IF NOT: BR
2041	005634	005200		INC	RD		; ADJUST FOR REC NO. IN HEADER
2042	005636	005737	000646	TST	TMEX	WEX:	; SEE IF TM
2043	005642	001402		BEQ	WEX1		; IF NOT: BR
2044	005644	004737	005712	JSR	PC,WTM		; WRITE TM
2045	005650	005037	000754	CLR	RTYFL	WEX1:	; CLEAR RETRY FLAG
2046	005654	005037	000756	CLR	TMFLG		; CLEAR TM FLAG
2047	005660	005737	000760	TST	EOTREC		; TEST FOR EOT
2048	005664	100401		BMI	W4		; IF SO: BR
2049	005666	000207		RTS	PC	WEX2:	; EXIT
2050	005670	017704	172756	MOV	QSWR,R4	W4:	
2051	005674	042704	177767	BIC	#177767,R4		; CHECK IF WRITE ONLY
2052	005700	022704	000010	CMP	#10,R4		
2053	005704	001370		BNE	WEX2		; IF NOT: BR
2054	005706	000137	004142	JMP	REOT		; GO REWIND ALL AVAIL TAPES
2055							

```

2056 ;*****
2057 ;WRITE TAPE MARK
2058 ;
2059 ;THIS ROUTINE, ENABLED THRU TELETYPE RESPONSE
2060 ;AT PROGRAM START-UP, WILL WRITE A TAPE MARK
2061 ;FOLLOWING THE WRITING OF EACH BLOCK OF DATA.
2062 ;THIS OPTION INCREASES THE BLOCK SIZE BY ONE RECORD;
2063 ;A BLOCK OF 100 RECORDS WILL HAVE A TAPE MARK
2064 ;WRITTEN AS RECORD 101.
2065 ;*****
2066
2067 005712 012737 024457 000716 WTM: MOV #MSG62,EMADDR ;POINT TO TM ERROR MSG
2068 005720 005300 DEC RO
2069 005722 005237 000756 INC TMFLG ;SET TM FLAG
2070 005726 005077 172652 CLR @MWC ;CLEAR BYTE COUNTER
2071 005732 012777 026200 172646 MOV #WDATA,@MDA
2072 005740 012777 000006 172634 MOV #6,@MTC ;SET TM OP CODE
2073 005746 012737 005760 000724 MOV #WTMO,RTRN ;SAVE RETURN ADDRESS
2074 005754 000137 017006 JMP TAPG ;EXECUTE TM COMMAND
2075 005760 032777 010000 172664 WTM0: BIT #10000,@SWR ;SEE IF SHOULD CHECK ERRORS
2076 005766 001062 BNE WTM4 ;IF NOT: BR
2077 005770 004737 016036 JSR PC,ERCHK ;CHECK FOR ERRORS
2078 005774 005737 000742 TST SERFL ;SEE IF STATUS ERROR
2079 006000 001455 BEQ WTM4 ;IF NOT: BR
2080 006002 005737 000754 TST RTYFL ;SEE IF RETRY
2081 006006 001401 BEQ WTM1 ;IF NOT: BR
2082 006010 000207 RTS PC ;ELSE RETURN TO RETRY ROUTINE
2083 006012 013704 000734 WTM1: MOV UNP,R4
2084 006016 005264 001074 INC WTER1(R4) ;BUMP WRITE ERROR
2085 006022 032777 000002 172622 BIT #2,@SWR ;SEE IF SHOULD RETRY
2086 006030 001041 BNE WTM4 ;IF NOT: BR
2087 006032 042737 147377 000740 BIC #147377,ERSAV ;MASK UNRECOVERABLE ERROR
2088 006040 005737 000740 TST ERSAV ;SEE IF RECOVERABLE
2089 006044 001411 BEQ WTM2 ;IF SO: BR
2090 006046 012704 023735 MOV #MSG52,R4
2091 006052 004737 020530 JSR PC,TTOUT ;PRINT UNRETRYABLE TAG
2092 006056 012704 024457 MOV #MSG62,R4
2093 006062 004737 020530 JSR PC,TTOUT ;PRINT TM ERROR TAG
2094 006066 000207 RTS PC
2095 006070 005037 000750 WTM2: CLR RPCNT ;CLEAR REPEAT CNTR
2096 006074 013704 000734 MOV UNP,R4
2097 006100 005264 001154 INC RTY1(R4) ;BUMP RETRY CNTR
2098 006104 005037 000752 CLR RTCNT ;CLEAR RETRY LOOP CNTR
2099 006110 032777 002000 172534 BIT #2000,@SWR ;SEE IF PRINT ERRORS
2100 006116 001004 BNE WTM3 ;IF NOT: BR
2101 006120 012704 023755 MOV #MSG53,R4
2102 006124 004737 020530 JSR PC,TTOUT ;PRINT ORIGINAL ERROR TAG
2103 006130 004737 006142 WTM3: JSR PC,WRTY ;GO DO RETRY
2104 006134 005037 000756 WTM4: CLR TMFLG ;CLEAR TM FLAG
2105 006140 000207 RTS PC ;EXIT
2106

```



```

1153 006440 000137 006570          TMP      BTOV          ;ELSE GO TO BAD TAPE OVERFLOW
1154 006444 005237 000752          WRTY4:  INC      RTCNT      ;BUMP RETRY COUNTER
1155 006450 022737 000004 000752          CMP      #4,RTCNT      ;SEE IF DONE 4 RETRIES
1156 006456 001410          BEQ      WRTY5          ;IF SO: BR
1157 006460 013704 000734          MOV      UNP,R4
1158 006464 005264 001154          INC      RTY1(R4)      ;BUMP RETRY COUNTER
1159 006470 005237 000764          INC      ERTFL         ;SET ERASE FLAG
1160 006474 000137 006150          JMP      WRTY0         ;DO NEXT RETRY
1161 006500 000137 006614          WRTY5:  JMP      BTUR        ;ELSE GO TO BAD TAPE UNRECOVERABLE

          ;WRITE RETRY BACKSPACE-ERASE SUBROUTINE

1162 006504 005037 000742          WRTSB:  CLR      SERFL         ;CLEAR FLAG
1163 006510 012777 177777 172066          MOV      #-1,IMMC      ;SET FOR 1 RECORD
1164 006516 012737 024553 000716          MOV      #MSG69,EMADDR
1165 006524 004737 010466          JSR      PC,SPBK       ;DO SPACE BACK
1166 006530 012737 022452 000716          MOV      #MSG5,EMADDR
1167 006536 032737 000002 000746          BIT      #2,BTFLG      ;SEE IF ERROR ON BACKSPACE
1168 006544 001410          BEQ      WRTSBO        ;IF NOT: BR
1169 006546 005037 000754          CLR      RTYFL
1170 006552 022626          CMP      (SP)+,(SP)+   ;RESET STACK
1171 006554 052737 000004 000746          BIS      #4,BTFLG      ;MARK RETRY ERROR
1172 006562 000137 004142          JMP      REOT          ;REWIND AND REMOVE FROM TESTING
1173 006566 000207          WRTSBO: RTS      PC      ;RETURN

          ;BAD TAPE OVERFLOW SUBROUTINE*****

1174 006570 013704 000734          BTOV:  MOV      UNP,R4
1175 006574 005264 001154          INC      RTY1(R4)      ;BUMP RETRY COUNTER
1176 006600 012737 000001 000746          MOV      #1,BTFLG      ;SET BAD TAPE OVERFLOW FLAG
1177 006606 005726          TST      (SP)+         ;RESET STACK
1178 006610 000137 004142          JMP      REOT          ;GO REWIND AND REMOVE FROM TESTING

          ;BAD TAPE UNRECOVERABLE SUBROUTINE*****

1179 006614 012704 024063          BTUR:  MOV      #MSG58,R4
1180 006620 004737 020530          JSR      PC,TTOUT      ;PRINT UNRECOVERABLE BAD SPOT MSG
1181 006624 000207          RTS      PC            ;RESUME TESTING
  
```

2201
2202
2203
2204
2205
2206
2207
2208
2209
2210
2211
2212
2213
2214
2215
2216
2217
2218
2219
2220
2221
2222
2223
2224
2225
2226
2227
2228
2229
2230
2231

006626 032777 000010 172016
006634 001031
006636 032777 000001 172006
006644 001404
006646 032777 040000 171776
006654 001410
006656 004737 010132
006662 032737 000002 000746
006670 001402
006672 000137 004142
006676 012737 000002 000526
006704 004737 006722
006710 032777 040000 171734
006716 001357
006720 000207

RSEQ: BIT #10, QSWR
BNE RSEX
BIT #1, QSWR
BEQ RSFROA
BIT #40000, QSWR
BEQ RSFRO
RSFRCA: JSR PC, BKSP
BIT #2, BTFLG
BEQ RSFRO
JMP REOT
RSFRO: MOV #2, RDCMD
JSR PC, READ
BIT #40000, QSWR
BNE RSFROA
RSEX: RTS PC

:SEE IF SHOULD READ FORWARD
:IF NOT: BR
:SEE IF WRITE
:IF SO: BR
:SEE IF SHOULD REMAIN IN PLACE
:IF NOT: BR
:GO BACKSPACE TO START
:ERROR ON BACKSPACE?
:IF NOT: BR
:REWIND AND REMOVE FROM TESTING
:LOAD READ FORWARD COMMAND
:GO READ FORWARD
:SEE IF SHOULD READ SAME BLOCK
:IF SO: BR
:EXIT

:READ SEQUENCER:
:THIS ROUTINE IS USED TO DETERMINE THE SEQUENCE
:IN WHICH READ TAPE OPERATIONS ARE TO BE PERFORMED.
:SWITCH THREE (3) DISALLOWS READING.
:IF THE PROGRAM IS BEING RUN IN THE READ ONLY MODE,
:CONSOLE SWITCH ZERO (0) SET TO A ONE (1), THEN SETTING
:CONSOLE SWITCH FOURTEEN (14) WILL CAUSE READING OF
:THE SAME BLOCK OF DATA CONTINUOUSLY
:WHEN SET TO A ONE (1), AND ALLOW TAPE
:TO READ BLOCKS PROGRESSIVELY WHEN SET TO A ZERO (0).

2232
2233
2234
2235
2236
2237
2238
2239
2240
2241
2242
2243
2244
2245
2246
2247
2248
2249
2250
2251
2252
2253
2254
2255
2256
2257
2258
2259
2260
2261
2262
2263
2264
2265
2266
2267
2268
2269
2270
2271
2272
2273
2274
2275
2276
2277
2278
2279
2280
2281
2282
2283
2284
2285
2286
2287

006722 013700 000620
006726 012737 022457 000716
006734 005037 000756
006740 052777 040000 171644
006746 005077 171630
006752 005077 171622
006756 013777 000622 171620
006764 012777 032212 171614
006772 053777 000626 171602
007000 012737 007012 000724
007006 000137 017006
007012 032777 002000 171560
007020 001405
007022 052737 100000 000760
007030 000137 007350
007034 032777 000040 171536
007042 001411
007044 004737 017506
007050 012704 022725
007054 004737 020530
007060 000240
007062 000137 020050
007066 032777 004000 171556
007074 001037
007076 004737 016036
007102 005737 000742
007106 001432
007110 013704 000734
007114 005264 001114
007120 032777 000002 171524
007126 001022
007130 017737 171444 000740
007136 042737 073525 000740
007144 001411
007146 012704 023735
007152 004737 020530

READ:
RDO:
RD1:
RD1A:
RD2:
RD3:
RD4:

```
*****  
;READ ROUTINE:  
;THIS ROUTINE PERFORMS THE READ OPERATION DETERMINED  
;BY THE READ SEQUENCE ROUTINE ONE RECORD AT A TIME.  
;AT THE END OF EACH READ OPERATION THE STATUS REGISTER  
;IS SCANNED FOR EITHER END OF TAPE OR BEGINNING OF TAPE.  
;IF EOT WAS REACHED, CONTROL WILL BE PASSED TO  
;THE EOT SUBROUTINE TO REWIND THE UNIT AND FLAG IT  
;UNAVAILABLE UNTIL ALL UNITS HAVE REACHED EOT.  
;IF BOT WAS REACHED AND ERROR IS PRINTED AND THE  
;PROGRAM WILL HALT. TESTING MAY BE RESUMED BY PRESSING  
;THE CONTINUE SWITCH TWICE.  
;CONSOLE SWITCHES ELEVEN (11) AND THIRTEEN (13) DETERMINE WHETHER  
;OR NOT TO CHECK FOR STATUS ERRORS (11) OR DATA ERRORS (13),  
;CONSOLE SWITCH FIVE (5) IS USED TO CAUSE A CONTINUOUS  
;READ AND SPACE (FORWARD OR REVERSE) OF THE CURRENT  
;RECORD ON TAPE (YOZZLE).  
*****  
MOV RCNT,RO ;LOAD REC CNTR  
MOV #MSG6,EMADDR ;SET ERROR MSG ADDRESS  
CLR TMFLG ;CLEAR TM FLAG  
BIS #40000,AMTRD ;SET TO READ LPC ON READ  
CLR AMTC  
CLR AMTS  
RD1: MOV CARCNT,AMWC ;LOAD CHAR CNTR  
RD1A: MOV #RDATA,AMDA ;LOAD DATA ADDR  
BIS RDCMD,AMTC ;LOAD READ OP COMMAND  
MOV #RD2,ATRN ;SET INTERRUPT RETURN ADDRESS  
JMP TAPG ;GO EXECUTE TAPE COMMAND  
RD2: BIT #2000,AMTS ;SEE IF AT EOT  
BEQ RD3 ;IF NOT: BR  
BIS #100000,EOTREC ;MARK EOT FOUND  
JMP RDEX ;GO REWIND  
RD3: BIT #40,AMTS ;SEE IF AT LOAD POINT  
BEQ RD4 ;IF NOT: BR  
JSR PC,PAFRT ;PRINT CYCLE NUMBER  
MOV #MSG22,R4  
JSR PC,TTOUT ;PRINT BOT ERROR  
JMP DRPDRV ;DROP DRIVE  
RD4: BIT #4000,ASWR ;SEE IF SHOULD CHECK ERRORS  
BNE RD5 ;IF NOT: BR  
JSR PC,ERCHK ;GO CHECK ERRORS  
TST SERFL ;SEE IF STATUS ERROR  
BEQ RD5 ;IF NOT: BR  
MOV UNP,R4  
INC RDER1(R4) ;BUMP READ ERROR  
BIT #2,ASWR ;SEE IF SHOULD DO READ RETRY  
BNE RD5 ;IF NOT: BR  
MOV AMTS,ERSAV  
BIC #073525,ERSAV ;MASK NON-RETRYABLE ERRORS  
BEQ RD4A ;IF RETRYABLE: BR  
MOV #MSG52,R4  
JSR PC,TTOUT ;PRINT NON-RETRYABLE MESSG.
```

```

2298 007156 012704 022457      MOV      #MSG6,R4
2299 007162 004737 020530      JSR      PC,TTOUT      ;PRINT READ EPROR TAG
2300 007166 000402      BR       R05
2301 007170 004737 007376      JSR      PC,RTY      ;DO RETRY
2302 007174 032777 020000 171450  RD4A:  BIT      #20000,ASWR    ;SEE IF SHOULD DO DATA CHECK
2303 007202 001007      BNE     R06            ;IF NOT: BR
2304 007204 005737 000756      TST     TMFLG         ;IS IT TM?
2305 007210 001004      BNE     R06            ;IF SO: BR
2306 007212 004737 013712      JSR      PC,DCHK      ;GO CHECK DATA
2307 007216 005037 000742      CLR     SERFL         ;CLEAR STATUS ERROR FLAG
2308 007222 004737 012516  RD6:  JSR      PC,DS3      ;CLEAR BUFFER
2309 007226 032777 000040 171416  BIT      #40,ASWR     ;SEE IF SHOULD YOZZLE
2310 007234 001402      SEQ     R07            ;IF NOT: BR
2311 007236 004737 007600      JSR      PC,YOZ       ;ELSE GO YOZZLE
2312 007242 013737 000632 000730  RD7:  MOV     RSTAL,STAL   ;SET DELAY
2313 007250 004737 010634      JSP     PC,STALL     ;STALL
2314 007254 005737 000756      TST     TMFLG         ;JUST DONE TM?
2315 007260 001033      BNE     RDEX          ;IF SO: BR
2316 007262 005737 000760      TST     EOTREC        ;WAS EOT REACHED
2317 007266 100430      BMI     RDEX          ;IF SO: BR
2318 007270 005300      DEC     R0            ;
2319 007272 001225      BNE     R00           ;IF NOT DONE ALL: BR
2320 007274 005200      INC     R0            ;ADJUST FOR REC NO IN HEADER
2321 007276 005737 000646  RD10: TST     TMEX          ;EXPECT A TAPE MARK?
2322 007302 001422      BEQ     RDEX          ;IF NOT: BR
2323 007304 005300      DEC     R0            ;ELSE READ TM
2324 007306 012777 177776 171270  MOV     #-2,AMWC     ;SET BYTE COUNT
2325 007314 005737 001010      TST     STCDFL        ;SEE IF 7 TRK CORE DUMP
2326 007320 001402      BEQ     IS           ;IF NOT: BR
2327 007322 005277 171256      INC     AMWC          ;SET TO ONE CHAR
2328 007326 005237 000756  IS:   INC     TMFLG         ;SET TM FLAG
2329 007332 012737 024563 000716  MOV     #MSG70,EMADDR ;SET TO READ LPC ON READ TM
2330 007340 042777 040000 171244  BIC     #40000,AMTRD  ;GO READ
2331 007346 000606      BR      R01A
2332 007350 005037 000756  RDEX: CLR     TMFLG
2333 007354 005737 000760      TST     EOTREC        ;WAS EOT REACHED
2334 007360 100005      BPL     RDEXX         ;IF NOT: BR
2335 007362 005726      TST     (SP)+         ;RESET STACK
2336 007364 005037 000760      CLR     EOTREC        ;CLEAR EOT IND.
2337 007370 000137 004142      JMP     REOT          ;GO REWIND
2338 007374 000207  RDEXX: RTS     PC      ;EXIT
2339
2340
2341
2342
2343
2344
2345
2346
2347
2348
2349
2350
2351
2352
2353
2354
2355
2356
2357
2358
2359
2360
2361
2362
2363
2364
2365
2366
2367
2368
2369
2370
2371
2372
2373
2374
2375
2376
2377
2378
2379
2380
2381
2382
2383
2384
2385
2386
2387
2388
2389
2390
2391
2392
2393
2394
2395
2396
2397
2398
2399
2400
2401
2402
2403
2404
2405
2406
2407
2408
2409
2410
2411
2412
2413
2414
2415
2416
2417
2418
2419
2420
2421
2422
2423
2424
2425
2426
2427
2428
2429
2430
2431
2432
2433
2434
2435
2436
2437
2438
2439
2440
2441
2442
2443
2444
2445
2446
2447
2448
2449
2450
2451
2452
2453
2454
2455
2456
2457
2458
2459
2460
2461
2462
2463
2464
2465
2466
2467
2468
2469
2470
2471
2472
2473
2474
2475
2476
2477
2478
2479
2480
2481
2482
2483
2484
2485
2486
2487
2488
2489
2490
2491
2492
2493
2494
2495
2496
2497
2498
2499
2500

```

2344	007432	005237	000752		INC	RTCNT		;BUMP RETRY COUNT
2345	007436	005737	000742		TST	SERFL		;SEE IF ERROR?
2346	007442	001431			BEQ	RRTY4		;IF NOT: BR
2347	007444	032777	002000	171200	BIT	#2000,JSWR		;SEE IF PRINT?
2348	007452	001010			BNE	RRTY2		;IF NOT: BR
2349	007454	012704	024572		MOV	#MSG71,R4		
2350	007460	004737	020530		JSR	PC,TTOUT		;PRINT FAILED RETRY MESSG.
2351	007464	013703	000752		MOV	RTCNT,R3		
2352	007470	004737	020716		JSR	PC,OCIP		;PRINT RETRY NUMBER
2353	007474	022737	000004	000752	RRTY2: CMP	#4,RTCNT		;DONE 4 RETRYS?
2354	007502	001351			BNE	RRTY1		;IF NOT: BR
2355	007504	012704	024620		MOV	#MSG72,R4		
2356	007510	004737	020530		JSR	PC,TTOUT		;PRINT SUSPECT HARD ERROR MESSG.
2357	007514	013704	000734		RRTY3: MOV	UNP,R4		
2358	007520	005264	001214		INC	BDRY1(R4)		;BUMP HARD ERROR COUNT
2359	007524	000420			BR	RRTYX		
2360	007526	032777	002000	171116	RRTY4: BIT	#2000,JSWR		;SEE IF SHOULD PRINT?
2361	007534	001010			BNE	RRTY5		;IF NOT: BR
2362	007536	012704	024644		MOV	#MSG73,R4		
2363	007542	004737	020530		JSR	PC,TTOUT		;TYPE SUCCESSFUL RETRY MESSAGE
2364	007546	013703	000752		MOV	RTCNT,R3		
2365	007552	004737	020716		JSR	PC,OCIP		;PRINT RETRY COUNT
2366	007556	013704	000734		RRTY5: MOV	UNP,R4		
2367	007562	005264	001174		INC	GDRY1(R4)		;INCREASE SOFT ERROR COUNT
2368	007566	005037	000774		RRTYX: CLP	RRTYFL		;CLEAR RETRY FLAG
2369	007572	004737	022120		JSR	PC,CKSWR		;GO CHECK FOR 1G
2370	007576	000207			RTS	PC		;RETURN

```

2372
2373
2374
2375
2376
2377
2378
2379
2380
2381
2382
2383
2384
2385
2386 007600 012777 000001 171050 YOZ:
2387 007606 013737 000640 000730
2388 007614 004737 010634
2389 007620 012777 177777 170756 YOZO:
2390 007626 112777 000012 170746 YOZA:
2391 007634 012737 007654 000724 YOZB:
2392 007642 012737 177775 000730
2393 007650 000137 017006
2394 007654 013737 000640 000730 YOZC:
2395 007662 004737 010634
2396 007666 113777 000626 170706
2397 007674 012777 032212 170704
2398 007702 013777 000622 170674
2399 007710 005737 000756
2400 007714 001410
2401 007716 012777 177776 170660
2402 007724 005737 001010
2403 007730 001402
2404 007732 005277 170646
2405 007736 012737 007750 000724 YOZC1:
2406 007744 000137 017006
2407 007750 032777 004000 170674 YOZD:
2408 007756 001002
2409 007760 004737 016036
2410 007764 005737 000774 YOZE:
2411 007770 001401
2412 007772 000207
2413 007774 032777 020000 170650 YOZE1:
2414 010002 001002
2415 010004 004737 013712
2416 010010 004737 012516 YOZF:
2417 010014 105777 170636
2418 010020 100034
2419 010022 122777 000203 170630
2420 010030 001030
2421 010032 012704 023602
2422 010036 004737 020530
2423 010042 013703 000640
2424 010046 004737 020716
2425 010052 010037 000712
2426 010056 012705 000640
2427 010062 012701 000006

```

```

*****
;YOZZLE SUBROUTINE:
;
;THIS SUBROUTINE, ENTERED VIA SWITCH FIVE (5), IS USED TO PERFORM
;A CONTINUOUS READ AND SPACE OVER OF THE CURRENT RECD ON TAPE.
;FULL STATUS AND DATA CHECKING MAY BE PERFORMED
;OR NOT VIA CONSOLE SWITCHES ELEVEN (11) AND THIRTEEN (13).
;A SOFTWARE DELAY IS PERFORMED BETWEEN EACH READ
;AND SPACE OPERATION AND MAY BE VARIED BY TYPING
;CNTRL C ON THE TTY AND ENTERING A VALUE IN RESPONSE
;TO THE PRINTED REQUEST.
*****

```

```

MOV #1, @TKS ;SET TTY ENABLE
MOV YSTAL, STAL
JSR PC, STALL ;DO YOZZLE STALL
MOV #-1, @MWC ;SET TO 1 RECORD SPACING
MOVB #12, @MTC ;SET TO SPACE REVERSE
MOV #YOZC, RTRN ;SET RETURN ADDRESS
MOV #177775, STAL ;SET TIME MULTIPLIER
JMP TAPG ;GO YOZZLE
MOV YSTAL, STAL
JSR PC, STALL ;DO YOZZLE STALL
MOVB RDCMD, @MTC ;SET READ COMMAND F OR R
MOV #RDATA, @MDA ;SET READ ADDRESS
MOV CARCNT, @MWC ;SET CHARACTER COUNT
TST TMFLG ;IS IT A TM?
BEQ YOZC1 ;IF NOT: BR
MOV #-2, @MWC ;SET FOR TM
TST STCDFL ;SEE IF 7 TRK CORE DUMP
BEQ YOZC1 ;IF NOT: BR
INC @MWC ;SET TO ONE CHARACTER
MOV #YOZD, RTRN ;SET RETURN ADDRESS
JMP TAPG ;GO YOZZLE
BIT #4000, @SWR ;SEE IF ERROR CHECK
BNE YOZE ;IF NOT: BR
JSR PC, ERCHK ;ELSE GO CHECK ERRORS
TST RRTYFL ;IS IT A READ RETRY?
BEQ YOZE1 ;IF NOT: BR
RTS PC
BIT #20000, @SWR ;SEE IF SHOULD CHECK DATA
BNE YOZF ;IF NOT: BR
JSR PC, DCHK ;ELSE GO CHECK DATA
JSR PC, D53 ;GO CLEAR DATA AREA
TSTB @TKS ;SEE IF HAVE NEW STALL VALUE
BPL YOZG ;IF NOT: BR
CMPB #203, @TKB ;SEE IF CONT C
BNE YOZG ;IF NOT: BR
MOV #MSG44, R4
JSR PC, TOUT ;PRINT YSTALL REQUEST
MOV YSTAL, R3
JSR PC, OCTP ;PRINT PRESENT STALL
MOV RO, TEMP3 ;SAVE RO(REC CNT)
MOV #YSTAL, R5 ;SET ADDRESS OF YSTL
MOV #6, R1 ;SET NUMBER OF CHAR TO INPUT

```

2428	010066	012702	177777		MOV	#-1,R2	;SET MAXIMUM LIMIT
2429	010072	012703	001000		MOV	#1000,R3	;SET MINIMUM LIMIT
2430	010076	004737	020272		JSR	PC,TIR	;GO GET VALUE
2431	010102	013700	000712		MOV	TEMP3,R0	;RESTORE R0(REC CNTR)
2432	010106	000137	007600		JMP	Y0Z	;RESTART YOZZLE
2433	010112	032777	000040	170532	BIT	#40,@SWR	;SEE IF SHOULD CONTINUE YOZZLE
2434	010120	001227			SNE	Y0Z	;IF SO: BR
2435	010122	012777	000100	170526	MOV	#100,@TKS	;SET TTY INTERRUPT ENABLE
2436	010130	000207			RTS	PC	;EXIT

2453
2454
2455
2456
2457
2458
2459
2460
2461
2462
2463
2464
2465
2466
2467
2468
2469
2470
2471
2472
2473
2474
2475
2476
2477
2478
2479
2480
2481
2482
2483
2484
2485
2486
2487
2488
2489
2490
2491
2492
2493

010132 005037 000726
010136 013700 000620
010142 005100
010144 005200
010146 005737 000760
010152 001407
010154 013700 000760
010160 042700 100000
010164 005400
010166 005037 000760
010172 010037 000714
010176 005737 000646
010202 001520
010204 012737 024466 000716
010212 012777 177777 170364
010220 013700 000620
010224 063700 000714
010230 004737 010466
010234 032737 000002 000746
010242 001401
010244 000207
010246 017737 170326 000740
010254 032737 040000 000740
010262 001053
010264 005737 000726
010270 001014
010272 032777 002000 170352
010300 001040
010302 004737 017506
010306 013704 000716
010312 004737 020530
010316 012704 022750
010322 004737 020530
010326 017703 170250
010332 005037 000712
010336 000303
010340 004737 021144
010344 000303
010346 004737 021144
010352 005737 000712
010356 001011

```
*****  
:BACKSPACE SUBROUTINE:  
:  
:THIS SUBROUTINE IS USED TO PERFORM THE  
:BACKSPACE OPERATION REQUIRED BY THE READ  
:ROUTINE EITHER FOR READ FORWARD AFTER WRITING,  
:OR FOR CONTINUOUS READING OF A DATA BLOCK  
:WHEN IN READ ONLY MODE WITH SWITCH FOURTEEN (14)  
:SET TO A ONE.  
:A CHECK FOR RECORD COUNT ZERO IS MADE AT THE  
:END OF THE SPACE OPERATION TO ASSURE THAT PROPER  
:TAPE POSITIONING WAS DONE.  
*****  
BKSP: CLR HDRFL :CLEAR HEADER FLAG  
BO: MOV RCNT,RO  
COM RO ;BUILD SPACE AMOUNT  
INC RO  
TST EOTREC ;SEE IF EOT WAS REACHED  
BEQ BKO ;IF NOT: BR  
MOV EOTREC,RO ;GET SHORTENED BLOCK COUNT  
BIC #100000,RO  
NEG RO  
CLR EOTREC ;CLEAR EOT FLAG  
BKO: MOV RO,TEMP4 ;SAVE BACKSPACE COUNT  
TST TMEX ;IS THERE A TM?  
BEQ BOA ;IF NOT: BR  
MOV #MSG63,EMADDR ;POINT TO TM SP ERROR MESSG  
MOV #-1,AMWC ;SET FOR 1 RECORD  
MOV RCNT,RO ;RO=RECORD COUNT  
ADD TEMP4,RO ;RO=RCNT-BACKSPACE CNT FOR HEADER  
JSR PC,SPBK ;BACKSPACE OVER TM  
BIT #2,BTFLG ;WAS THERE AN ERROR  
BEQ BK1 ;IF NOT: BR  
RTS PC ;ELSE RETURN WITH ERROR FLAG SET  
BK1: MOV AMTS,ERSAV ;GET STATUS  
BIT #40000,ERSAV ;IS TM SET  
BNE BK3 ;IF SET: BR  
BK1C: TST HDRFL ;ALREADY PRINTED HEADER?  
BNE BK2 ;IF SO: BR  
BIT #2000,ASWR ;SHOULD PRINT?  
BNE BK1B ;IF NOT: BR  
JSR PC,PAPRT ;PRINT HEADER  
MOV EMADDR,R4 ;POINT TO TM SP ERROR  
JSR PC,TTOUT ;PRINT ERROR  
BK2: JSR PC,TTOUT ;PRINT COMMAND HEADER  
MOV AMTC,R3  
CLR TEMP3  
BK1A: SWAB R3 ;POSITION MOST SIGNIFICANT  
JSR PC,DOUT ;PRINT  
SWAB R3 ;POSITION LEAST SIGNIFICANT  
JSR PC,DOUT ;PRINT  
TST TEMP3 ;SEE IF PRINTED STATUS  
BNE BK1B ;IF SO: BR
```

K05

2494	010360	005237	000712			INC	TEMP3	;SET FLAG
2495	010364	012704	023135			MOV	#MSG30,R4	;PRINT STATUS HEADER
2496	010370	004737	020530			JSR	PC,TTOUT	
2497	010374	017703	170200			MOV	AMTS,R3	;LOAD STATUS
2498	010400	000756				BR	BK1A	;GO PRINT STATUS
2499	010402	052737	000002	000746	BK1B:	BIS	#2,BTFLG	;SET BT FLAG (POSITION ERROR)
2500	010410	000207				RTS	PC	;RETURN
2501	010412	042737	142121	000740	BK3:	BIC	#142121,ERSAV	;LOOK FOR NON-TM ERRORS
2502	010420	001407				BEQ	BOB	;IF NOT: BR
2503	010422	005737	000760			TST	EOTREC	;WAS EOT REACHED
2504	010426	001716				BEQ	BK1C	;IF NOT: BR
2505	010430	042737	002000	000740		BIC	#2000,ERSAV	;CHECK FOR NON-EOT ERRORS
2506	010436	001312				SNE	BK1C	;IF ANY: BR
2507								
2508	010440	163700	000620		BOB:	SUB	RCNT,RO	;AGAIN RO=BACKSPACE COUNT
2509	010444	012737	022471	000716	BOA:	MOV	#MSG10,EMADDR	;POINT TO SE MESSG
2510	010452	005200				INC	RO	;RO=BACKSPACE COUNT+1
2511	010454	063700	000620			ADD	RCNT,RO	;RO=RCNT-BACKSPACE CNT + 1 FOR HEADER
2512	010460	013777	000714	170116		MOV	TEMP4,AMWC	
2513	010466	013737	000636	000730	SPBK:	MOV	TSTAL,STAL	
2514	010474	004737	010634			JSR	PC,STALL	;DO STALL
2515	010500	005077	170074			CLR	AMTS	
2516	010504	105077	170072			CLRB	AMTC	
2517	010510	052777	000012	170064		BIS	#12,AMTC	;SET BACKSPACE OP
2518	010516	012737	010536	000724		MOV	#B1,RTRN	;SET RETURN ADDRESS
2519	010524	012737	177377	000730		MOV	#177377,STAL	;SET INTERRUPT TIME MULTIPLIER
2520	010532	000137	017006			JMP	TAPG	;GO DO SPACE
2521	010536	017701	170042		B1:	MOV	AMWC,R1	;LOAD SPACE COUNTER
2522	010542	001426				BEQ	B2	;IF COUNT IS ZERO: BR
2523	010544	032777	002000	170100		BIT	#2000,ASWR	;SEE IF PRINT
2524	010552	001017				BNE	B1A	;IF NOT: BR
2525	010554	004737	017506			JSR	PC,PAPRT	;ELSE PRINT SPACE ERROR
2526	010560	013704	000716			MOV	EMADDR,R4	
2527	010564	004737	020530			JSR	PC,TTOUT	
2528	010570	012704	023631			MOV	#MSG45,R4	
2529	010574	004737	020530			JSR	PC,TTOUT	;PRINT SPACE COUNT HEADER
2530	010600	005301				DEC	R1	
2531	010602	005101				COM	R1	
2532	010604	010103				MOV	R1,R3	
2533	010606	004737	020716			JSR	PC,OCTP	;PRINT NUMBER OF RECORDS LEFT TO SPACE
2534	010612	012737	000002	000746	B1A:	MOV	#2,BTFLG	;SET BAD TAPE FLAG
2535	010620	013737	000636	000730	B2:	MOV	TSTAL,STAL	;DO STALL
2536	010626	004737	010634			JSR	PC,STALL	;STALL
2537	010632	000207				RTS	PC	;EXIT
2538								

2539
2540
2541
2542
2543
2544
2545
2546
2547
2548
2549
2550
2551
2552
2553
2554
2555
2556
2557
2558
2559
2560
2561
2562
2563
2564
2565
2566
2567
2568
2569
2570
2571
2572
2573
2574
2575
2576
2577
2578
2579
2580
2581
2582

```
*****  
:STALL ROUTINE:  
:THIS ROUTINE IS USED TO PROVIDE SOFTWARE DELAYS  
:DURING READ, WRITE, TURN AROUND, AND YOZZLE.  
:THE DELAY TIMES MAY BE SET BY THE OPERATOR AT  
:INITIAL START FROM 200(8) OR MAY BE MODIFIED  
:AT ANY TIME BY ENTERING CNTRL C ON THE TTY AND  
:INSERTING NEW VALUES IN RESPONSE TO THE REQUEST  
:PRINTED.  
:THE READ STALL AND THE WRITE STALL ARE DELAYS  
:EXECUTED BETWEEN EACH RECORD OF THE DATA BLOCK.  
:THE TURN AROUND STALL IS EXECUTED EACH TIME  
:THE DIRECTION OF TAPE MOVEMENT IS CHANGED AND  
:ALSO EACH TIME THE TAPE OPERATION CHANGES FROM  
:WRITE TO READ OR READ TO WRITE.  
:THE YOZZLE STALL IS EXECUTED ONLY DURING THE  
:YOZZLE ROUTINE.  
*****
```

010634 005337 000730
010640 001375
010642 000207

```
STALL: DEC STAL  
BNE STALL ;DELAY  
RTS PC ;EXIT
```

```
*****  
:RANDOM CHARACTER COUNT GENERATOR:  
:THIS ROUTINE ENTERED VIA CONSOLE SWITCH  
:SEVEN (7) IS USED TO GENERATE A RANDOM  
:CHARACTER COUNT FOR EACH DATA BLOCK.  
:ALL RECORDS WITHIN A GIVEN BLOCK WILL BE  
:THE SAME, BUT EACH BLOCK WILL VARY.  
:THE LIMITS ARE TWO (2) TO TWO THOUSAND  
:(2000) OCTAL CHARACTERS PER RECORD.  
*****
```

010644 012701 177776
010650 012702 174000
010654 004737 020240
010660 013737 000676 000622
010666 012737 177777 012750
010674 000207

```
CCNTR: MOV #-2,R1 ;SET HIGH LIMIT  
MOV #-4000,R2 ;SET LOW LIMIT  
JSR PC,RANG ;GO GENERATE NUMBER  
MOV RANSAV,CARCNT ;SET CHAR COUNT  
MOV #-1,PATS ;PRESET DATA PATTERN  
RTS PC ;EXIT
```


2639	010766	012704	024733		MOV	#MSG77, R4	
2640	010772	004737	020530		JSR	PC, TTOUT	;PRINT AUTO SEQ PROGRAM NAME
2641	010776	000410			BR	TINPO	
2642	011000	012704	023144	TINPB1:	MOV	#MSG31, R4	
2643	011004	004737	020530		JSR	PC, TTOUT	;PRINT PROGRAM NAME
2644	011010	012704	023261		MOV	#MSG31A, R4	
2645	011014	004737	020530		JSR	PC, TTOUT	;PRINT REST OF TITLE
2646	011020	122737	000004	000041	TINPO:	CMPB	#4, @#41
2647	011026	001006			BNE	1\$;IF NOT: BR
2648	011030	012704	026120		MOV	#MSG97, R4	
2649	011034	004737	020530		JSR	PC, TTOUT	;ELSE PRINT NO TEST
2650	011040	000137	004662		JMP	REOT10	;END TEST
2651	011044	012704	025255	1\$:	MOV	#MSG84, R4	
2652	011050	004737	020530		JSR	PC, TTOUT	;REQUEST STARTING REGISTER ADDRESS
2653	011054	013703	000600		MOV	MTS, R3	
2654	011060	004737	020716		JSR	PC, OCTP	;PRINT CURRINT REGISTER START
2655	011064	013705	000674		MOV	REGST, R5	;SAVE ADDRESS LOCATION
2656	011070	012701	000C06		MOV	#6, R1	;SET SIZE OF ENTRY
2657	011074	012702	177770		MOV	#177770, R2	;SET UPPER LIMIT
2658	011100	012703	170000		MOV	#170000, R3	;SET LOWER LIMIT
2659	011104	004737	020272		JSR	PC, TTR	;GO GET RESPONSE
2660	011110	012705	000602		MOV	#MTC, R5	;SET TABLE BASE
2661	011114	013704	000600		MOV	MTS, R4	;GET INITIAL ADDRESS
2662	011120	062704	000002	2\$:	ADD	#2, R4	;BUMP ADDRESS
2663	011124	010425			MOV	R4, (R5)+	;FILL TABLE
2664	011126	020527	000614		CMP	R5, #MTRD+2	;DONE?
2665	011132	001372			BNE	2\$;IF NOT: BR
2666	011134	012704	025300		MOV	#MSG85, R4	
2667	011140	004737	020530		JSR	PC, TTOUT	;REQUEST VECTOR ADDR.
2668	011144	013703	000614		MOV	VECT, R3	
2669	011150	004737	020716		JSR	PC, OCTP	;PRINT CURRENT VECTOR
2670	011154	012705	000614		MOV	#VECT, R5	;SET SAVE LOCATION
2671	011160	012701	000003		MOV	#3, R1	;SET SIZE OF RESPONSE
2672	011164	012702	000476		MOV	#476, R2	;SET UPPER LIMIT
2673	011170	012703	000060		MOV	#60, R3	;SET LOWER LIMIT
2674	011174	004737	020272		JSR	PC, TTR	;GO GET RESPONSE
2675	011200	013700	000614		MOV	VECT, R0	;GET VECTOR ADDRESS
2676	011204	012720	017466		MOV	#MTINT, (R0)+	;LOAD VECTOR WITH HANDLER ADDR.
2677	011210	012710	000340		MOV	#340, (R0)	;LOAD PRIORITY LEVEL
2678	011214	005737	021624		TST	ASEQF	;SEE IF AUTO SEQ
2679	011220	001403			BEQ	TINPOD	;IF NOT: BR
2680	011222	005726			TST	(SP)+	;RESET STACK
2681	011224	000137	021252		JMP	ASEQ	;GO TO AUTO SEQ
2682	011230	012704	023314	TINPOD:	MOV	#MSG32, R4	
2683	011234	004737	020530		JSR	PC, TTOUT	;PRINT UNIT NUMBER REQUEST
2684	011240	005037	000710		CLR	TEMP2	;CLEAR BUFFER
2685	011244	012705	000710		MOV	#TEMP2, R5	;SET UNIT DESCRIPTION BUFFER ADDRESS
2686	011250	012701	000001		MOV	#1, R1	;SET NUMBER OF CHARACTERS TO INPUT
2687	011254	012702	000007		MOV	#7, R2	;SET MAXIMUM LIMIT
2688	011260	012703	000000		MOV	#0, R3	;SET MINIMUM LIMIT
2689	011264	004737	020272		JSR	PC, TTR	;GO GET UNIT NUMBER
2690	011270	005737	000706		TST	TEMP1	;SEE IF HAVE NEW PARAMETER
2691	011274	001014			BNE	TINPOB	;IF SO: BR
2692	011276	005737	000734		TST	UNP	;SEE IF FIRST ENTRY
2693	011302	001002			BNE	TINPOA	;IF NOT: BR
2694	011304	000137	011230		JMP	TINPOD	;ELSE RETRY

2751	011660	004737	020530	JSR	PC, TTOUT	;PRINT RECORD COUNT REQUEST
2752	011664	013703	000620	MOV	RCNT, R3	
2753	011670	004737	020716	JSR	PC, OCTP	;PRINT RECORD COUNT
2754	011674	012705	000620	MOV	#RCNT, R5	;SET RECORD COUNT ADDRESS
2755	011700	012701	000006	MOV	#6, R1	;SET NUMBER OF CHARACTERS TO INPUT
2756	011704	012702	177777	MOV	#-1, R2	;SET MAXIMUM LIMIT
2757	011710	012703	000001	MOV	#1, R3	;SET MINIMUM LIMIT
2758	011714	004737	020272	JSR	PC, TTR	;GO GET RECORD COUNT
2759	011720	013737	000620	MOV	RCNT, RCSAV	;SAVE RECORD COUNT
2760	011726	012704	023404	MOV	#MSG36, R4	
2761	011732	004737	020530	JSR	PC, TTOUT	;PRINT CHARACTER COUNT REQUEST
2762	011736	005437	000622	NEG	CARCNT	
2763	011742	013703	000622	MOV	CARCNT, R3	
2764	011746	004737	020716	JSR	PC, OCTP	;PRINT CHAR COUNT
2765	011752	012705	000622	MOV	#CARCNT, R5	;SET CHARACTER COUNT ADDRESS
2766	011756	012701	000006	MOV	#6, R1	;SET NUMBER OF CHARACTERS TO INPUT
2767	011762	012702	004000	MOV	#4000, R2	;SET MAXIMUM LIMIT
2768	011756	012703	000004	MOV	#4, R3	;SET MINIMUM LIMIT
2769	011772	004737	020272	JSR	PC, TTR	;GO GET CHARACTER COUNT
2770	011776	005437	000622	NEG	CARCNT	;SET TO TWO'S COMPLEMENT
2771	012002	013737	000622	MOV	CARCNT, CCSAV	;SAVE CHAR COUNT
2772	012010	012704	023430	MOV	#MSG37, R4	;PRINT PATTERN NUMBER REQUEST
2773	012014	004737	020530	JSR	PC, TTOUT	
2774	012020	013703	000624	MOV	PATRN, R3	
2775	012024	004737	020716	JSR	PC, OCTP	;PRINT PATTERN
2776	012030	005037	012746	CLR	DOFL	;CLEAR EXTERNAL DATA FLAG
2777	012034	012705	000624	MOV	#PATRN, R5	;SET PATTERN NUMBER ADDRESS
2778	012040	012701	000002	MOV	#2, R1	;SET NUMBER OF CHARACTERS TO INPUT
2779	012044	012702	000015	MOV	#15, R2	;SET MAXIMUM LIMIT
2780	012050	012703	000000	MOV	#0, R3	;SET MINIMUM LIMIT
2781	012054	004737	020272	JSR	PC, TTR	;GO GET PATTERN NUMBER
2782	012060	012704	024270	MOV	#MSG60, R4	;PRINT TM REQUEST
2783	012064	004737	020530	JSR	PC, TTOUT	
2784	012070	013703	000646	MOV	TMEX, R3	
2785	012074	004737	020716	JSR	PC, OCTP	;PRINT TMEX VALUE
2786	012100	012705	000646	MOV	#TMEX, R5	;SE TMEX ADDRESS
2787	012104	012701	000001	MOV	#1, R1	;SET NUMBER OF CHARACTERS TO INPUT
2788	012110	010102		MOV	R1, R2	;SET MAXIMUM LIMIT
2789	012112	005003		CLR	R3	;SET MINIMUM LIMIT
2790	012114	004737	020272	JSR	PC, TTR	;GO GET RESPONSE
2791	012120	012704	023453	MOV	#MSG39, R4	
2792	012124	004737	020530	JSR	PC, TTOUT	;PRINT SINGLE PASS REQUEST
2793	012130	013703	000630	MOV	SPFLG, R3	
2794	012134	004737	020716	JSR	PC, OCTP	;PRINT CURRENT FLAG SETTING
2795	012140	012705	000630	MOV	#SPFLG, R5	;GET ADDRESS OF FLAG
2796	012144	012701	000001	MOV	#1, R1	;SET SIZE OF RESPONSE
2797	012150	012702	000001	MOV	#1, R2	;SET UPPER LIMIT
2798	012154	012703	000000	MOV	#0, R3	;SET LOWER LIMIT
2799	012160	004737	020272	JSR	PC, TTR	;GO GET RESPONSE
2800	012164	012704	023515	MOV	#MSG40, R4	
2801	012170	004737	020530	JSR	PC, TTOUT	;PRINT READ STALL REQUEST
2802	012174	013703	000632	MOV	RSTAL, R3	
2803	012200	004737	020716	JSR	PC, OCTP	;PRINT READ STALL
2804	012204	012705	000632	MOV	#RSTAL, R5	;SET READ STALL ADDRESS
2805	012210	012701	000006	MOV	#6, R1	;SET NUMBER OF CHARACTERS TO INPUT
2806	012214	012702	177777	MOV	#-1, R2	;SET MAXIMUM LIMIT

000642

000644

TINP4:

```

2807 012220 012703 000001      MOV      #1,R3      ;SET MINIMUM LIMIT
2808 012224 004737 020272      JSR      PC,TTR     ;GO GET READ STALL
2809 012230 012704 023544      MOV      #MSG41,R4
2810 012234 004737 020530      JSR      PC,TTOUT   ;PRINT WRITE STALL REQUEST
2811 012240 013703 000634      MOV      #WSTAL,R3
2812 012244 004737 020716      JSR      PC,OCIP    ;PRINT READ STALL
2813 012250 012705 000634      MOV      #WSTAL,R5 ;SET WRITE STALL ADDRESS
2814 012254 012701 000006      MOV      #6,R1      ;SET NUMBER OF CHARACTERS TO INPUT
2815 012260 012702 177777      MOV      #-1,R2     ;SET MAXIMUM LIMIT
2816 012264 012703 000001      MOV      #1,R3      ;SET MINIMUM LIMIT
2817 012270 004737 020272      JSR      PC,TTR     ;GO GET WRITE STALL
2818 012274 012704 023556      MOV      #MSG42,R4
2819 012300 004737 020530      JSR      PC,TTOUT   ;PRINT TURN AROUND STALL REQUEST
2820 012304 013703 000636      MOV      #TSTAL,R3
2821 012310 004737 020716      JSR      PC,OCIP    ;PRINT TA STALL
2822 012314 012705 000636      MOV      #TSTAL,R5 ;SET TURN AROUND STALL ADDRESS
2823 012320 012701 000006      MOV      #6,R1      ;SET NUMBER OF CHARACTERS TO INPUT
2824 012324 012702 177777      MOV      #-1,R2     ;SET MAXIMUM LIMIT
2825 012330 012703 000001      MOV      #1,R3      ;SET MINIMUM LIMIT
2826 012334 004737 020272      JSR      PC,TTR     ;GO GET TURN AROUND STALL
2827 012340 000207
2828
2829
2830
2831 012342 000241
2832 012344 006137 000710      TPOS:   CLC
2833 012350 005303
2834 012352 001373
2835 012354 013700 000734      MOV      UNP,RO     ;LOAD UNIT POINTER
2836 012360 053750 000710 001012      BIS      TEMP2,UNI(RO) ;LOAD CHARACTER INTO UNI(RO)
2837 012366 000207      RTS      PC
2838

```

;UNIT DESCRIPTION POSITIONING SUBROUTINE*****

```

CLC
ROL    TEMP2      ;POSITION CHARACTER
DEC    R3         ;SEE IF DONE
BNE    TPOS      ;IF NOT: BR
MOV    UNP,RO    ;LOAD UNIT POINTER
BIS    TEMP2,UNI(RO) ;LOAD CHARACTER INTO UNI(RO)
RTS    PC        ;EXIT

```

2839
2840
2841
2842
2843
2844
2845
2846
2847
2848
2849
2850
2851
2852
2853
2854
2855
2856
2857
2858
2859
2860
2861
2862
2863
2864
2865
2866
2867
2868
2869
2870
2871
2872
2873
2874
2875
2876
2877
2878
2879
2880
2881
2882
2883
2884
2885
2886
2887
2888
2889
2890
2891
2892
2893

012370 005737 013304
012374 001045
012376 005737 021624
012402 001406
012404 005737 000624
012410 100003
012412 004737 013236
012416 000207
012420 023737 000624 012750
012426 001014
012430 013700 000616
012434 042703 173777
012440 023703 012752
012444 001404
012446 010337 012752
012452 004737 013306
012456 000207
012460
012460 012703 026200
012464 013701 000624
012470 010137 012750
012474 062701 000001
012500 000241
012502 006101
012504 000171 002734
012510 000240
012512 004737 013306
012516 012702 002002
012522 012701 032212
012526 005021
012530 005302
012532 001375
012534 013737 000616 012752
012542 042737 173777 012752
012550 000207

DSUP:
DSC:
DSOA:
DSOB:
DSOC:
DS1:
DS3:
DS4:

TST RDFL
BNE DS1
TST ASEQF
BEQ DSOA
TST PATRN
BPL DSOA
JSR PC, DATR
RTS PC
CMP PATRN, PATS
BNE DSOC
MOV UDES, R3
BIC #173777, R3
CMP PARS, R3
BEQ DSOB
MOV R3, PARS
JSR PC, CRCLRC
RTS PC
MOV #WDATA, R3
MOV PATRN, R1
MOV R1, PATS
ADD #1, R1
CLC
ROL R1
JMP @DATBL(R1)
NOP
JSR PC, CRCLRC
MOV #2002, R2
MOV #RDATA, R1
CLR (R1)+
DEC R2
BNE DS4
MOV UDES, PARS
BIC #173777, PARS
RTS PC

: DATA SETUP ROUTINE:
: THIS ROUTINE IS USED TO GENERATE INTO THE ENTIRE
: WRITE BUFFER (4000 OCTAL CHARACTERS) THE DATA PATTERN
: SELECTED BY THE OPERATOR. THESE ARE 20 (8) FIXED
: DATA PATTERNS AVAILABLE AND ONE SELECTION (DATA PATTERN 0)
: WHICH WILL READ ANY PATTERN PRESENTED AT THE
: HIGH SPEED PAPER TAPE READER. THIS TAPE MUST BE PREPARED
: BY USING THE PROGRAM CALLED DTC.
: RANDOM DATA MAY ALSO BE USED VIA CONSOLE
: SWITCH EIGHT (8).
: THIS ROUTINE IS ALSO USED TO CLEAR OUT THE
: READ BUFFER (4000 OCTAL CHARACTERS) BEFORE EACH
: RECORD IS READ.
: *****
; SEE IF DID RANDOM DATA
; IF SO: BR
; SEE IF AUTO SEQ
; IF NOT: BR
; SEE IF AUTO RANDOM
; IF NOT: BR
; ELSE GO GENERATE RANDOM DATA
; RETURN
; NEW PATTERN?
; IF SO: BR
; GET UNIT DESCRIPTION
; MASK PARITY
; SEE IF SAME AS LAST TIME
; IF SO, BR
; SAVE PARITY
; GO GENERATE EXPECTED CRC/LRC
; R3 = ADDR OF WRITE BUFFER
; R1 = PATTERN SELECTOR
; BUMP POINTER
; MAKE PATTERN SELECTOR EVEN
; GO GENERATE PATTERN
; R2=BUFFER SIZE +2
; R1=READ DATA START
; CLEAR BUFFER
; SEE IF DONE ALL
; IF NOT: BR
; SET PARITY
; EXIT

```

2894
2895
2896
2897 012552 005737 012746
2898 012556 001354
2899 012560 012737 000001 012746
2900 012566 005077 166076
2901 012572 005077 166070
2902 012576 005037 000706
2903 012602 052777 000001 166056 DATOA:
2904 012610 005037 000714
2905 012614 012704 000004
2906 012620 032777 000200 166040 DATOB:
2907 012626 001006
2908 012630 005337 000714
2909 012634 001371
2910 012636 005304
2911 012640 001367
2912 012642 000722
2913 012644 005001
2914 012646 117701 166016
2915 012652 005737 000706
2916 012656 001012
2917 012660 105701
2918 012662 001747
2919 012664 012737 000001 000706
2920 012672 010137 000710
2921 012676 010102
2922 012700 000137 012602
2923 012704 110123 DATOC:
2924 012706 005302
2925 012710 001334
2926 012712 012701 026200 DATOD:
2927 012716 013702 000710
2928 012722 112123 DATOE:
2929 012724 022703 032212
2930 012730 003002
2931 012732 000137 012510
2932 012736 005302 DATOF:
2933 012740 001370
2934 012742 000137 012712
2935 012746 000000 DOFL:
2936 012750 177777 PATS:
2937 012752 177777 PARS:
2938
    
```

:EXTERNAL DATA INPUT FROM H/S READER (256 CHARACTER MAXIMUM)

```

;SEE IF SHOULD DO EXTERNAL INPUT
;IF NOT: BR
;SET EXTERNAL FLAG
;CLEAR READER BUFFER
;CLEAR READER STATUS
;CLEAR FOR USE AS CHARACTER FLAG
;START READER
;SET UP READER DONE DELAY
;SEE IF DONE
;IF SO :BR
;DELAY FOR READER DONE
;CONTINUE DELAY
;IF READER NEVER DONE: BR
;CLEAR SAVE LOCATION
;SAVE CHARACTER
;SEE IF HAVE FOUND START CHARACTER
;IF SO : BR
;SEE IF CHARACTER IS 0
;IF SO : BR
;ELSE SET CHARACTER FOUND FLAG
;SAVE DATA SIZE
;SAVE DATA SIZE
;GO GET FIRST DATA CHAR
;LOAD BUFFER
;SEE IF READ ALL
;IF NOT : BR
;R1 = START OF WRITE BUFFER
;R2 = SIZE OF DATA FIELD
;REPEAT LOAD OF DATA FIELD
;SEE IF DONE
;IF NOT: BR
;EXIT
;SEE IF AT END OF DATA FIELD
;IF NOT : BR
;ELSE RESTART FILL
;EXTERNAL DATA FLAG=1 IF ALREADY DONE
    
```

```

2939                                     ;ALL ONES*****
2940
2941 012754 012701 177777 DAT1:  MOV  #-1,R1      ;R1=DATA
2942 012760 012702 002002 DAT1A: MOV  #2002,R2   ;R2=WORD COUNT +2
2943 012764 010123          DAT1B: MOV  R1,(R3)+   ;LOAD BUFFER
2944 012766 005302          DEC  R2           ;SEE IF DONE
2945 012770 001375          BNE  DAT1B        ;IF NOT: BR
2946 012772 000137 012510  JMP  DS1         ;RETURN
2947
2948                                     ;ALL ZEROS*****
2949
2950
2951 012776 005001          DAT2:  CLR  R1           ;R1=DATA
2952 013000 000137 012760  JMP  DAT1A       ;LOAD BUFFER
2953
2954                                     ;WALKING ONE*****
2955
2956 013004 012701 000001  DAT3:  MOV  #1,R1      ;R1=DATA
2957 013010 000241          CLC
2958 013012 012702 004004  DAT3A: MOV  #4004,R2   ;R2=CHARACTER COUNT+4
2959 013016 110123          DAT3B: MOVB R1,(R3)+   ;LOAD BUFFER
2960 013020 106101          ROLB R1           ;SET NEXT CHARACTER
2961 013022 005302          DEC  R2           ;SEE IF DONE
2962 013024 001374          BNE  DAT3B        ;IF NOT: BR
2963 013026 000137 012510  JMP  DS1         ;RETURN
2964
2965                                     ;WALKING ZERO*****
2966
2967 013032 012701 000376  DAT4:  MOV  #376,R1   ;R1=START OF DATA
2968 013036 000261          SEC
2969 013040 000137 013012  JMP  DAT3A       ;LOAD BUFFER
2970
2971                                     ;ALTERNATING ONE/ZERO*****
2972
2973
2974 013044 012701 052525  DAT5:  MOV  #52525,R1 ;R1=DATA
2975 013050 000137 012760  JMP  DAT1A       ;LOAD BUFFER
2976
2977                                     ;ALTERNATING ZERO/ONE*****
2978
2979 013054 012701 125252  DAT6:  MOV  #125252,R1 ;R1=DATA
2980 013060 000137 012760  JMP  DAT1A       ;LOAD BUFFER
2981
2982                                     ;ONE/ZERO IN ALTERNATING CHARACTERS*****
2983
2984 013064 012701 125125  DAT7:  MOV  #125125,R1 ;R1=DATA
2985 013070 000137 012760  JMP  DAT1A       ;LOAD BUFFER
2986
2987                                     ;ZERO/ONE IN ALTERNATING CHARACTERS*****
2988
2989 013074 012701 052652  DAT10: MOV #52652,R1  ;R1=DATA
2990 013100 000137 012760  JMP  DAT1A       ;LOAD BUFFER
2991

```



```

2992
2993
2994
2995 013104 005001
2996 013106 012702 004004
2997 013112 110123
2998 013114 105201
2999 013116 005302
3000 013120 001374
3001 013122 000137 012510
3002
3003
3004
3005 013126 012701 000377
3006 013132 012702 004004
3007 013136 110123
3008 013140 105301
3009 013142 005302
3010 013144 001374
3011 013146 000137 012510
3012
3013
3014
3015 013152 012701 000377
3016 013156 000137 012760
3017
3018
3019
3020 013162 012701 177400
3021 013166 000137 012760
3022
3023
3024
3025 013172 012702 002002
3026 013176 012701 177376
3027 013202 012704 000002
3028 013206 010123
3029 013210 005302
3030 013212 001002
3031 013214 000137 012510
3032 013220 005304
3033 013222 001371
3034 013224 000261
3035 013226 006101
3036 013230 103764
3037 013232 000137 013176
3038

;ALL BITS 0-377*****
DAT11: CLR R1 ;R1=STARTING DATA
MOV #4004,R2 ;R2=CHARACTER COUNT+4
DAT11A: MOV R1,(R3)+ ;LOAD BUFFER
INCB R1 ;BUMP DATA
DEC R2 ;SEE IF DONE
BNE DAT11A ;IF NOT: BR
JMP DS1 ;RETURN

;ALL BITS 377-0*****
DAT12: MOV #377,R1 ;R1=STARTING DATA
MOV #4004,R2 ;R2=CHARACTER COUNT+4
DAT12A: MOV R1,(R3)+ ;LOAD BUFFER
DECB R1 ;BUMP DATA
DEC R2 ;SEE IF DONE
BNE DAT12A ;IF NOT: BR
JMP DS1 ;RETURN

;ALTERNATING CHARACTERS 0 AND 377*****
DAT13: MOV #377,R1 ;R1 = DATA
JMP DAT1A ;LOAD BUFFER

;ALTERNATING CHARACTERS 377 AND 0*****
DAT14: MOV #177400,R1 ;R1 = DATA
JMP DAT1A ;LOAD BUFFER

;WALKING ZERO REPEATED FOUR TIMES*****
DAT15: MOV #2002,R2 ;SET NUMBER OF WORDS
DAT15R: MOV #177376,R1 ;SET START OF DATA
DAT15A: MOV #2,R4 ;SET NUMBER OF REPEATS
DAT15B: MOV R1,(R3)+ ;LOAD DATA
DEC R2 ;SEE IF DONE
BNE DAT15C ;IF NOT: BR
JMP DS1 ;RETURN
DAT15C: DEC R4 ;SEE IF DONE REPEATS
BNE DAT15B ;IF NOT: BR
SEC
ROL R1 ;SET NEXT PATTERN
BCS DAT15A ;SEE IF SHOULD RESTART
JMP DAT15R ;IF SO: BR
  
```

```

3039
3040
3041
3042 013236 013704 000622      DATR:  MOV  CARCNT,R4      ;SET SIZE OF RECORD
3043 013242 012703 026200      MOV  #WDATA,R3      ;SET ADDRESS OF START OF BUFFER
3044 013246 012701 177777      MOV  #-1,R1        ;SET HIGH LIMIT
3045 013252 005002                CLR  R2            ;SET LOW LIMIT
3046 013254 004737 020240      DATRO: JSR  PC,RAND ;GO GENERATE NUMBER
3047 013260 013723 000676      MOV  RANSAB,(R3)+  ;LOAD BUFFER
3048 013264 005204                INC  R4            ;SEE IF DONE ALL
3049 013266 001372                BNE  DATRO        ;IF NOT: BR
3050 013270 004737 012510      JSR  PC,DS1       ;GO CHECK FOR 7 CH
3051 013274 012737 000001 013304  MOV  #1,RDFL      ;SET RANDOM DATA FLAG
3052 013302 000207                RTS  PC           ;EXIT
3053 013304 000000                RDFL: 0          ;RANDOM DATA SELECT FLAG
    
```

```

3054
3055
3056
3057
3058
3059
3060
3061
3062
3063 013306 000240
3064 013310 013700 000622
3065 013314 005400
3066 013316 012701 026200
3067 013322 005037 013674
3068 013326 111104
3069 013330 004737 013522
3070 013334 004737 013650
3071 013340 000241
3072 013342 006004
3073 013344 103014
3074 013346 052704 000400
3075 013352 000241
3076 013354 010405
3077 013356 042705 177703
3078 013362 005105
3079 013364 042705 177703
3080 013370 042704 000074
3081 013374 050504
3082 013376 010437 013674
3083 013402 005300
3084 013404 001402
3085 013406 000137 013326
3086 013412 013704 013674
3087 013416 005137 013674
3088 013422 042737 177050 013674
3089 013430 042704 177727
3090 013434 050437 013674
3091 013440 013737 013674 013676
3092 013446 013700 000622
3093 013452 005400
3094 013454 012701 026200
3095 013460 005037 013674
3096 013464 111104
3097 013466 004737 013522
3098 013472 004737 013650
3099 013476 005300
3100 013500 001371
3101 013502 013704 013676
3102 013506 004737 013650
3103 013512 013737 013674 013700
3104 013520 000207
3105 013522 005704
3106 013524 001010
3107 013526 032737 004000 000616
3108 013534 001404
3109 013536 012704 000420

```

```

*****
;CRC/LRC CHARACTER BUILD;
;
;THIS ROUTINE WILL CONSTRUCT AND SAVE THE EXPECTED
;CRC AND LRC CHARACTERS ACCORDING TO DATA AND
;RECORD SIZE IF OPERATING IN NRZ MODE
*****
CRCLRC: NOP
CRLR:  MOV    CARCNT,RO      ;SET RECORD SIZE
        NEG    RO
        MOV    #WDATA,R1    ;SET START OF BUFFER
        CLR    XORS
CL0:   MOVB   (R1),R4        ;GET CHARACTER
        JSR    PC,CLP        ;GO GET PARITY OF CHARACTER
        JSR    PC,XOR        ;XOR CHARACTER
        CLC
        ROR    R4            ;ROTATE 1 RIGHT
        BCC    CL2          ;IF NO CARRY: BR
        BIS    #400,R4      ;SET BIT NINE
        CLC
CL1:   MOV    R4,R5          ;SAVE CHARACTER
        BIC    #177703,R5
        COM    R5
        BIC    #177703,R5
        BIS    R5,R4        ;COMPLEMENT BITS 2,3,4,5
CL2:   MOV    R4,XORS
        DEC    RO
        BEQ    CLLAST      ;IF LAST CHARACTER: BR
        JMP    CLO         ;GET NEXT
CLLAST: MOV    XORS,R4
        COM    XORS
        BIC    #177050,XORS ;COMPLEMENT ALL BUT BITS 3&5
        BIC    #177727,R4
        BIS    R4,XORS
        MOV    XORS,EXCRC   ;SAVE EXPECTED CRC
        MOV    CARCNT,RO
        NEG    RO
        MOV    #WDATA,R1    ;DO EXPT LRC
        CLR    XORS
CL3:   MOVB   (R1),R4
        JSR    PC,CLP        ;GET PARITY
        JSR    PC,XOR        ;XOR CHARACTER
        DEC    RO
        BNE    CL3         ;DO ALL FOR LRC
        MOV    EXCRC,R4
        JSR    PC,XOR        ;XOR CRC TO DATA
        MOV    XORS,EXLRC   ;SAVE EXPT LRC
        RTS    PC           ;RETURN
CLP:   TST    R4            ;SEE IF 0 CHAR
        BNE    CLPE        ;IF NOT: BR
        BIT    #4000,UDES    ;SEE IF EVEN PARITY
        BEQ    CLPE        ;IF NOT: BR
        MOV    #420,R4      ;SET 0 CHAR EVEN PARITY

```


3148
3149
3150
3151
3152
3153
3154
3155
3156
3157
3158
3159
3160
3161
3162
3163
3164
3165
3166
3167
3168
3169
3170
3171
3172
3173
3174
3175
3176
3177
3178
3179
3180
3181
3182
3183
3184
3185
3186
3187
3188
3189
3190
3191
3192
3193
3194
3195
3196
3197
3198
3199
3200
3201
3202
3203

013712 005037 000722
013716 005037 000744
013722 005037 000726
013726 013705 000622
013732 012701 026200
013736 012702 032212
012742 032737 004000 000616
013750 001435
013752 005737 001010
013756 001032
013760 012703 000377
013764 042703 177400
013770 032777 000020 164502
013776 001402
014000 042703 000300
014004 130311
014006 001404
014010 005201
014012 005205
014014 001373
014016 000406
014020 112721 000020
014024 012737 177777 012750
014032 000767
014034 013705 000622
014040 012701 026200
014044 032777 000020 164526
014052 001403
014054 005737 001010
014060 001417
014062 122122
014064 001003
014066 105037 000722
014072 000407
014074 004737 014656
014100 004737 014242
014104 012737 000001 000744
014112 005205
014114 001362
014116 000432
014120 000240
014122 010137 014240

```

DCHK: CLR BBC ;CLEAR BAD RECORD CNTR
        CLR DERFL ;CLEAR DATA ERROR FLAG
        CLR HDRFL ;CLEAR HEADER FLAG
        MOV CARCNT,R5 ;LOAD CHAR COUNT
        MOV #WDATA,R1 ;SET WRITE DATA ADDR
        MOV #RDATA,R2 ;SET READ DATA ADDR
        BIT #4000,UDES ;SEE IF EVEN PARITY
        BEQ DFC ;IF NOT: BR
        TST STCDFL ;SEE IF 7 TRK CORE DUMP
        BNE DFC ;IF SO: BR
        MOV #377,R3
        BIC #177400,R3 ;BACKGROUND DATA MASK
        BIT #20,AMTS ;SEE IF 7 TRK DRIVE(NORMAL)
        BEQ DFA ;IF NOT: BR
        BIC #300,R3 ;MASK FOR 7 TRK NORMAL DATA
        BITB R3,(R1) ;SEE IF ZERO CHARACTER
        BEQ DFC
        INC R1 ;BUMP POINTER
        INC R5 ;SEE IF DONE
        BNE DFA ;IF NOT: BR
        BR DFC
        MOVB #20,(R1)+ ;REPLACE 0 WITH 20
        MOV #-1,PATS ;SET TO GENERATE NEW PATTERN
        BR DFB
        MOV CARCNT,R5 ;RESET COUNT
        MOV #WDATA,R1 ;RESET ADDRESS
        BIT #20,AMTS ;SEE IF 7 TRACK
        BEQ DF9 ;IF NOT: BR
        TST STCDFL ;SEE IF 7 TRK CORE DUMP
        BEQ DF7 ;IF NOT: BR
        CMPB (R1)+,(R2)+ ;SEE IF DATA IS GOOD
        BNE DF91 ;IF NOT: BR
        CLRB BBC ;ELSE CLEAR BAD RECORD COUNTER
        BR DF92
        JSR PC,DRPKF ;GO DO DROPS AND PICKS
        JSR PC,DERR ;GO PRINT ERROR
        MOV #1,DERFL ;SET DATA ERROR FLAG
        INC R5 ;SEE IF DONE ALL CHARACTERS
        BNE DF9 ;IF NOT: DO ALL
        BR DF3
        NOP
        MOV R1,STAS ;SAVE CHARACTER ADDRESS

```

```

*****
;DATA CHECK SUBROUTINE:
;THIS SUBROUTINE IS USED TO COMPARE EACH CHARACTER
;OF DATA READ FROM TAPE WITH THE EXPECTED CHARACTER.
;ANY ERROR DETECTED WILL CAUSE CONTROL TO BE
;PASSED TO AN ERROR PRINT SUBROUTINE AND A
;SUBROUTINE TO ACCUMULATE THE NUMBER OF BITS
;DROPPED AND PICKED UP FROM EACH CHARACTER.
;DATA CHECKING MAY BE TERMINATED BY USE OF
;CONSOLE SWITCH THIRTEEN (13).
*****

```

3204	014126	117737	000106	014236		MOV B	@STAS,STCS	;SAVE CHARACTER
3205	014134	142711	000300			BIC B	#300,(R1)	;MASK FOR 7 TRACK DRIVE
3206	014140	122122				CMP B	:(R1)+,(R2)+	;SEE IF DATA IS GOOD
3207	014142	001003				BNE	DF71	;IF NOT: BR
3208	014144	105037	000722			CLRB	BBC	;CLEAR BAD RECORD COUNTER
3209	014150	000407				BR	DF72	
3210	014152	004737	014656		DF71:	JSR	PC,DRPKF	;GO DO DROPS AND PICKS
3211	014156	004737	014242			JSR	PC,DERR	;GO PRINT ERROR
3212	014162	012737	000001	000744		MOV	#1,DERFL	;SET DATA ERROR FLAG
3213	014170	000240			DF72:	NOP		
3214	014172	153777	014236	000040		BIS B	STCS,@STAS	;RESET DATA
3215	014200	005205				INC	R5	;SEE IF DONE ALL
3216	014202	001346				BNE	DF7	;IF NOT: DO ALL
3217	014204	005737	000744		DF3:	TST	DERFL	;SEE IF HAD DATA ERROR
3218	014210	001411				BEQ	DFX	;IF NOT: BR
3219	014212	005737	000742			TST	SERFL	
3220	014216	001006				BNE	DFX	;IF NOT DATA ERROR ONLY: BR
3221	014220	013704	000734			MOV	UNP,R4	
3222	014224	005264	001134			INC	DATER1(R4)	;BUMP DATA ERROR COUNTER
3223	014230	004737	022120			JSR	PC,CKSWR	;CHECK FOR ↑G
3224	014234	000207			DFX:	RTS	PC	;EXIT
3225	014236	000000			STCS:	0		;7 TRACK DATA SAVE
3226	014240	000000			STAS:	0		;7 TRACK ADDRESS SAVE

3227
3228
3229
3230
3231
3232
3233
3234
3235
3236
3237
3238
3239
3240
3241
3242
3243
3244
3245
3246
3247
3248
3249
3250
3251
3252
3253
3254
3255
3256
3257
3258
3259
3260
3261
3262
3263
3264
3265
3266
3267
3268
3269
3270
3271
3272
3273
3274
3275
3276
3277
3278
3279
3280
3281
3282

014242 032777 002000 164402
014250 001402
014252 000137 014400
014256 005237 000732
014262 005737 000726
014266 001013
014270 005737 000742
014274 001010
014276 004737 017506
014302 012704 022426
014306 004737 020530
014312 004737 016742
014316 012704 022445
014322 004737 020530
014326 010203
014330 162703 032212
014334 005303
014336 004737 020716
014342 012704 022433
014346 004737 020530
014352 114103
014354 004737 021144
014360 012704 022440
014364 004737 020530
014370 114203
014372 004737 021144
014376 122122
014400 105237 000722

DERR:
DERRO:
DERR0A:
DERR0B:
DERR1:
DERR2:
DERR3:
DERR4:

```
*****  
;DATA ERROR SUBROUTINE:  
;THIS SUBROUTINE IS USED TO PRINT OUT ANY  
;ERRORS FOUND DURING THE DATA CHECK.  
;EACH CHARACTER FOUND BAD WILL BE PRINTED  
;IN BIT FORMAT ALONG WITH ITS EXPECTED CHARACTER.  
;AN ERROR HEADER CONSISTING OF THE UNIT NUMBER,  
;BLOCK NUMBER, RECORD NUMBER, SIZE OF RECORD, AND  
;ERROR TYPE (READ FORWARD, WRITE, ETC)  
;IS PRINTED ONLY ONCE FOR EACH RECORD FOUND BAD.  
;A COUNT IS MADE OF THE NUMBER OF SUCCESSIVE BAD  
;CHARACTERS, AND IF TEN (10) SUCCESSIVE BAD CHARACTERS  
;ARE FOUND IN A SINGLE RECORD, A MESSAGE INDICATING  
;A BAD RECORD CONDITION IS PRINTED AND THE NEXT  
;TWENTY (20) CHARACTERS ARE SKIPPED BEFORE CHECKING  
;IS RESUMED. IF THE BAD RECORD CONDITION IS FOUND  
;THREE TIMES IN A RECORD, ALL REMAINING DATA IS  
;SKIPPED EXCEPT THE FINAL TEN (10) CHARACTERS.  
;THIS SKIPPING IS OF COURSE ONLY POSSIBLE IN  
;RECORDS WHICH CONTAIN A SUFFICIENT NUMBER OF CHARACTERS.  
;PRINTING OF ERRORS MAY BE DISALLOWED AT ANY TIME  
;BY SETTING CONSOLE SWITCH TEN (10) TO A ONE.  
;THE OPERATOR MAY CAUSE THE PROGRAM TO HALT ON ANY ERROR  
;BY SETTING CONSOLE SWITCH FIFTEEN (15) TO A ONE.  
*****  
BIT #2000, @SWR ;SEE IF SHOULD PRINT ERRORS  
BEQ DERR0 ;IF SO: BR  
JMP DERR4 ;ELSE SKIP PRINT  
DERRO: INC PFLG ;SET PRINT FLAG  
TST HDRFL ;SEE IF HAVE PRINTED HEADER  
BNE DERR0A ;IF SO: BR  
TST SERFL ;ALREADY PRINTED HEADER?  
BNE DERR0A ;IF SO: BR  
JSR PC, PAPRT ;PRINT CYCLE NUMBER  
MOV #MSG1, R4 ;LOAD ERROR MSG ADDR  
JSR PC, TTOUT ;PRINT ERROR  
JSR PC, FRPRT ;PRINT F OR R  
DERR0A: MOV #MSG4, R4 ;PRINT CHAR NO. HEADER  
JSR PC, TTOUT ;POINT TO CHAR  
MOV R2, R3 ;POINT TO CHAR  
DEC R3 ;PRINT CHAR NUMBER  
DERR0B: JSR PC, OCTP ;PRINT CHAR NUMBER  
MOV #MSG2, R4 ;PRINT EXPECTED DATA  
JSR PC, TTOUT ;LOAD EXPECTED DATA  
MOVB -(R1), R3 ;GO PRINT CHAR  
JSR PC, DOUT ;PRINT RECEIVED DATA  
MOV #MSG3, R4 ;PRINT RECEIVED DATA  
JSR PC, TTOUT ;PRINT RECEIVED DATA  
DERR1: MOVB -(R2), R3 ;PRINT BAD CHAR  
DERR2: JSR PC, DOUT ;RESET POINTERS  
DERR3: CMPB (R1)+, (R2)+ ;BUMP BAD RECORD CNTR  
DERR4: INCB BBC
```

00000	014404	122737	000010	000722		CMPB	#10,BBC	:SEE IF BLD 5TH
00001	014406	001037				BNE	DEREX	:IF NOT: BR
00002	014408	002777	002000	164230		BIT	#2000,2SWR	:SEE IF PRINT INHIBIT
00003	014410	001004				BNE	IS	:IF SO: BR
00004	014412	012704	022526			MOV	#MSG15,R4	
00005	014414	004737	020530			JSR	PC,TTCUT	:PRINT BLD 8TH
00006	014416	125037	000722		:S:	CLRB	BBC	:RESET BAD RECORD CNTR
00007	014418	000337	000722			SWAB	BBC	:POSITION BLD 8TH AMOUNT
00008	014420	105237	000722			INCB	BBC	:BUMP AMOUNT
00009	014422	122737	000033	000722		CMPB	#3,BBC	:SEE IF HAD 3 BLD 8THS
00010	014424	101037				BHI	DERR4B	:IF NOT: BR
00011	014426	000337	000722			SWAB	BBC	:REPOSITION BBC
00012	014428	022705	177757			CMP	#177767,R5	:SEE IF ON LAST EIGHT CHARS
00013	014430	101445				BLOS	DERR6	:IF SO: BR
00014	014432	012705	177767			MOV	#177767,R5	:SET CHAR CNTR TO 8
00015	014434	013737	000622	000706		MOV	CHARCNT,TEMP1	:LOAD CHAR COUNT
00016	014436	005137	000706			COM	TEMP1	
00017	014438	005237	000706			INC	TEMP1	
00018	014440	162737	000010	000706		SUB	#10,TEMP1	:POINT TO BUFFER -8
00019	014442	013701	000706			MOV	TEMP1,R1	:POINT TO NEXT CHAR
00020	014444	062701	026200			ADD	#WDATA,R1	:POINT TO NEXT WRITE CHAR
00021	014446	013702	000706			MOV	TEMP1,R2	:POINT TO END OF READ DATA -8 FORWARD
00022	014448	062702	032212			ADD	#RDATA,R2	:POINT TO NEXT CHAR
00023	014450	000422				BR	DEREX	:EXIT
00024	014452	012702	000010		DERR4A:	MOV	#10,R2	:POINT TO THE END OF READ DATA -8 REVERSE
00025	014454	062702	032212			ADD	#RDATA,R2	:POINT TO THE NEXT CHAR
00026	014456	000415				BR	DEREX	:EXIT
00027	014458	000337	000722		DERR4B:	SWAB	BBC	:REPOSITION BBC
00028	014460	000241				CLC		
00029	014462	062705	000024			ADD	#24,R5	:SKIP 20 CHARS
00030	014464	103405				BCS	DERR6	:IF EXCEED RECORD SIZE: BR
00031	014466	062701	000024			ADD	#24,R1	:SKIP 20 CHARS
00032	014468	062702	000024		DERR5:	ADD	#24,R2	:SKIP FORWARD 20 CHARS
00033	014470	000402				BR	DEREX	
00034	014472	012705	177777		DERR6:	MOV	#-1,R5	:SET TO EOR
00035	014474	032777	100000	164034	DEREX:	BIT	#100000,2SWR	:SEE IF SHOULD HALT ON ERROR
00036	014476	001412				BEQ	DEREX1	:IF NOT: BR
00037	014478	000000				HALT		
00038	014480	005737	000732			TST	PFLG	:SEE IF PRINTED
00039	014482	001006				BNE	DEREX1	:IF SO: BR
00040	014484	032777	002000	164014		BIT	#2000,2SWR	:SEE IF SHOULD PRINT
00041	014486	001002				BNE	DEREX1	:IF NOT: BR
00042	014488	000137	014256			JMP	DERRO	:ELSE PRINT
00043	014490	004737	022120		DEREX1:	JSR	PC,CKSWR	:TEST FOR 1G
00044	014492	005037	000732			CLR	PFLG	:CLEAR FLAG
00045	014494	000207				RTS	PC	:RETURN

3330
3331
3332
3333
3334
3335
3336
3337
3338
3339
3340
3341
3342
3343
3344
3345
3346
3347
3348
3349
3350
3351
3352
3353
3354
3355
3356
3357
3358
3359
3360
3361
3362
3363
3364
3365
3366
3367
3368
3369
3370
3371
3372
3373
3374
3375
3376
3377
3378
3379
3380
3381
3382
3383
3384
3385

014656 005037 000706
014662 005037 000710
014666 005037 000712
014672 013704 000734
014676 016437 001034 000770
014704 016437 001054 000766
014712 124142
014714 112137 000706
014720 112237 000710
014724 004737 014736
014730 004737 015156
014734 000207
014736 113703 000706
014742 113704 000710
014746 140403
014750 001001
014752 000207
014754 012737 000010 000736
014762 132703 000001
014766 001455
014770 105737 000712
014774 001016
014776 005277 163764
015002 005777 163760
015006 100045
015010 032777 002000 163634
015016 001402
015020 004737 017506
015024 004737 015222
015030 000415
015032 005277 163732
015036 005777 163726
015042 100027
015044 032777 002000 163600
015052 001402
015054 004737 017506
015060 004737 015222
015064 013704 000734

DRPKF: CLR TEMP1
CLR TEMP2
CLR TEMP3
MOV UNP,R4
MOV PIK1(R4),BPKP
MOV DRP1(R4),BDPP
CMPB -(R1),-(R2)
MOVB (R1)+,TEMP1
MOVB (R2)+,TEMP2
DRPK: JSR PC,DRDP
JSR PC,PICK
RTS PC
DROP: MOVB TEMP1,R3
MOVB TEMP2,R4
DPC: BICB R4,R3
BNE DPCG
RTS PC
DPCG: MOV #10,BCNT
DPC0: BITB #1,R3
BEQ DPC2
TSTB TEMP3
BNE DPC1
INC #BDPP
TST #BDPP
BPL DPC2
BIT #2000,#SWR
BEQ DPC0A
JSR PC,PAPRT
DPC0A: JSR PC,DPPRT
SR DPC2A
DPC1: INC #BPKP
TST #BPKP
BPL DPC2
BIT #2000,#SWR
BEQ DPC1A
JSR PC,PAPRT
DPC1A: JSR PC,DPPRT
DPC2A: MOV UNP,R4

:DROPS AND PICKS SUBROUTINE:
:THIS SUBROUTINE IS USED TO ACCUMULATE FROM
:EACH BAD DATA CHARACTER FOUND THE NUMBER
:OF BITS WHICH WERE EITHER DROPPED OR PICKED UP.
:TWO COUNTERS ARE USED TO ACCUMULATE THIS
:INFORMATION AND CAN STORE UP TO 32K DROPS
:OR PICKS BEFORE OVERFLOWING. IF OVERFLOW IS
:ABOUT TO OCCUR, THESE ACCUMULATORS ARE
:PRINTED IN OCTAL AND RESET TO ZERO.
:THE CONTENTS OF THE ACCUMULATORS MAY BE
:DISPLAYED AT ANY TIME BY SETTING CONSOLE
:SWITCH FOURTEEN TO A ONE (1). THE PRINTOUT WILL OCCUR
:AT THE END OF THE CURRENT BLOCK CYCLE.

:POINT TO CHAR
:LOAD GOOD CHAR
:LOAD BAD CHAR
:GET DROPS
:GET PICKS
:EXIT
:R3 = GOOD CHAR
:R4 = BAD CHAR
:GET DROPS/PICKS
:IF SOME: BR
:RETURN
:SET NUMBER TO CHECK
:SEE IF DROPPED OR PICKED THIS BIT
:IF NOT: BR
:SEE IF ON PICKS
:IF SO: BR
:BUMP DROP CNTR
:IF NO OVERFLOW: BR
:SEE IF HAVE PRINTED DATA
:IF SO: BR
:PRINT CYCLE NUMBER
:PRINT DROPS AND PICKS
:BUMP PICK CNTR
:SEE IF OVERFLOW
:IF NOT: BR
:SEE IF HAVE PRINTED DATA
:IF SO: BR
:PRINT CYCLE NUMBER
:PRINT DROPS AND PICKS

```

3386 015070 016403 001054      MOV      DRP1(R4),R3      ;SET DROP POINTER
3387 015074 016404 001034      MOV      PIK1(R4),R4     ;SET PICK POINTER
3388 015100 012737 000010 000736      MOV      #10,BCNT       ;SET NUMBER OF BITS
3389 015106 005023      DPC2B: CLR      (R3)+         ;CLEAR DROPS
3390 015110 005024      CLR      (R4)+         ;CLEAR PICK
3391 015112 005337 000736      DEC      BCNT           ;SEE IF DONE
3392 015116 001373      SNE     DPC2B          ;IF NOT: BR
3393 015120 000207      RTS     PC              ;EXIT
3394 015122 000241      DPC2:  CLC              ;
3395 015124 106003      RORB   R3              ;GET NEXT BIT
3396 015126 005337 000736      DEC     BCNT           ;SEE IF DONE
3397 015132 001410      BEQ    DPC3            ;
3398 015134 062737 000002 000770      ADD     #2,BPKP        ;
3399 015142 062737 000002 000766      ADD     #2,BDPP        ;
3400 015150 000137 014762      JMP    DPC0            ;CONTINUE
3401 015154 000207      DPC3:  RTS     PC       ;RETURN
3402 015156 013704 000734      PICK:  MOV     UNP,R4    ;SET UNIT POINTER
3403 015162 016437 001034 000770      MOV     PIK1(R4),BPKP  ;SET PICK POINTER
3404 015170 016437 001054 000766      MOV     DRP1(R4),BDPP  ;SET DROP POINTER
3405 015176 113704 000706      MOVB   TEMP1,R4       ;R4 = GOOD CHAR
3406 015202 113703 000710      MOVB   TEMP2,R3       ;R3 = BAD CHAR
3407 015206 112737 000001 000712      MOVB   #1,TEMP3       ;SET PICK FLAG
3408 015214 004737 014746      JSR    PC,DPC         ;GO CHECK PICKS
3409 015220 000207      RTS     PC              ;EXIT
3410 015222 012704 023113      DPPRT: MOV     #MSG26,R4  ;
3411 015226 004737 020530      JSR    PC,TTOUT       ;PRINT DROP HEADER
3412 015232 013704 000734      MOV     UNP,R4        ;
3413 015236 016437 001054 000766      MOV     DRP1(R4),BDPP  ;SET DROP POINTER
3414 015244 016437 001034 000770      MOV     PIK1(R4),BPKP  ;SET PICK POINTER
3415 015252 062737 000016 000766      ADD     #16,BDPP       ;
3416 015260 062737 000016 000770      ADD     #16,BPKP       ;
3417 015266 012737 000010 000736      MOV     #10,BCNT      ;SET NUMBER TO PRINT
3418 015274 017703 163466      DPPRT0: MOV    #BDPP,R3 ;
3419 015300 004737 020716      JSR    PC,OC1P        ;PRINT DROPS
3420 015304 005337 000736      DEC     BCNT          ;SEE IF DONE
3421 015310 001404      BEQ    DPPRT1        ;IF NOT: BR
3422 015312 162737 000002 000766      SUB     #2,BDPP       ;BUMP POINTER
3423 015320 000765      BR     DPPRT0        ;CONTINUE FOR ALL 8 BITS
3424 015322 012737 000010 000736      DPPRT1: MOV    #10,BCNT ;SET NUMBER TO PRINT
3425 015330 012704 023124      MOV     #MSG27,R4     ;
3426 015334 004737 020530      DPPRT2: JSR    PC,TTOUT   ;PRINT PICK HEADER
3427 015340 017703 163424      MOV     #BPKP,R3      ;
3428 015344 004737 020716      JSR    PC,OC1P        ;PRINT PICKS
3429 015350 005337 000736      DEC     BCNT          ;SEE IF DONE
3430 015354 001404      BEQ    DPPRTX        ;IF SO: BR
3431 015356 162737 000002 000770      SUB     #2,BPKP       ;BUMP POINTER
3432 015364 000765      BR     DPPRT2        ;CONTINUE FOR ALL 8 BITS
3433 015366 000207      DPPRTX: RTS     PC     ;RETURN

```

3474
3475
3476
3477
3478
3479
3480
3481
3482
3483
3484
3485
3486
3487
3488
3489
3490
3491
3492
3493
3494
3495
3496
3497
3498
3499
3500

015370 012700 000001
015374 004737 017506
015400 004737 015222
015404 012704 024475
015410 004737 020530
015414 013704 000734
015420 016403 001074
015424 004737 020716
015430 012704 024722
015434 004737 020530
015440 013704 000734
015444 016403 001154
015450 004737 020716
015454 012704 024506
015460 004737 020530
015464 013704 000734
015470 016403 001114
015474 004737 020716
015500 012704 024700
015504 004737 020530
015510 013704 000734
015514 016403 001174
015520 004737 020716
015524 012704 024711
015530 004737 020530
015534 013704 000734
015540 016403 001214
015544 004737 020716
015550 012704 024517
015554 004737 020530
015560 013704 000734
015564 016403 001134
015570 004737 020716
015574 004737 015606
015600 004737 022120
015604 000207

:STATISTICS PRINT
:THIS SUBROUTINE PRINTS THE ACCUMULATED
:ERROR STATISTICS FOR EACH DRIVE.
:THE ROUTINE CAN BE CALLED TO PRINT
:AT THE END OF EACH BLOCK BY SELECTING
:SW14=1. THE SUMMARY IS AUTOMATICALLY
:PRINTED FOR A DRIVE WHENEVER A TAPE
:IS REWOUND FROM EOT OR DROPPED.

PRSTAT: MOV #1,R0 ;SET RECORD COUNTER TO 1
JSR PC,PAPRT ;PRINT CYCLE NUMBER
PRSTA2: JSR PC,DPPRT ;PRINT DROPS AND PICKS
MOV #MSG64,R4
JSR PC,TTOUT ;PRINT WRITE ERROR TAG
MOV UNP,R4
MOV WTER1(R4),R3
JSR PC,OCTP ;PRINT WRITE ERRORS
MOV #MSG76,R4
JSR PC,TTOUT ;PRINT RETRY TOTAL
MOV UNP,R4
MOV RTY1(R4),R3
JSR PC,OCTP ;PRINT RETRIES
MOV #MSG65,R4
JSR PC,TTOUT ;PRINT READ ERROR TAG
MOV UNP,R4
MOV RDER1(R4),R3
JSR PC,OCTP ;PRINT READ ERRORS
MOV #MSG74,R4
JSR PC,TTOUT ;PRINT SOFT ERROR MESSAGE
MOV UNP,R4
MOV GDRY1(R4),R3
JSR PC,OCTP ;PRINT SOFT ERROR NUMBER
MOV #MSG75,R4
JSR PC,TTOUT ;PRINT HARD RD ERROR MESSG
MOV UNP,R4
MOV BDRY1(R4),R3
JSR PC,OCTP ;PRINT HARD RD ERROR COUNT
MOV #MSG66,R4
JSR PC,TTOUT ;PRINT DATA ERROR TAG
MOV UNP,R4
MOV DATR1(R4),R3
JSR PC,OCTP ;PRINT DATA ERROR NUMBER
JSR PC,BTPRT ;PRINT BAD TAPE STATS
JSR PC,CKSWR ;CHECK FOR 1G
RTS PC ;RETURN

3483
3484
3485
3486
3487
3488
3489
3490
3491
3492
3493
3494
3495
3496
3497
3498
3499
3500
3501
3502
3503
3504
3505
3506
3507
3508
3509
3510
3511
3512
3513
3514
3515
3516
3517
3518
3519
3520
3521
3522
3523
3524
3525
3526
3527
3528
3529
3530
3531
3532
3533
3534
3535
3536

015606 005037 000754
 015612 012704 024530
 015616 004737 020530
 015622 013704 000734
 015626 016437 002714
 015634 017703 163122
 015640 000241
 015642 006003
 015644 004737 020716
 015650 012704 024532
 015654 004737 020530
 015660 005777 163076
 015664 001001
 015666 000207
 015670 013701 000762
 015674 005721
 015676 005000
 015700 010003
 015702 000241
 015704 006003
 015706 004737 020716
 015712 012704 022513
 015716 105724
 015720 004737 020530
 015724 011103
 015726 004737 020716
 015732 012704 022521
 015736 004737 020530
 015742 062701 000040
 015746 012103
 015750 004737 020716
 015754 162701 000040
 015760 005720
 015762 020077 162774
 015766 001405
 015770 012704 024530
 015774 004737 020530
 016000 000737
 016002 005737 000772
 016006 001002
 016010 004737 016016
 016014 000207
 016016 012703 000041
 016022 013704 000762
 016026 005024
 016030 005303
 016032 001375
 016034 000207

000762

```

;BAD TAPE STATISTICS PRINT*****
BTPRT: CLR RTYFL
        MOV #MSG67,R4
        JSR PC,TTOUT ;DO CR/LF
        MOV UNP,R4
        MOV BTADDR(R4),BTPT ;SET TABLE POINTER
        MOV @BTPT,R3
        CLC
        ROR R3 ;CORRECT NUMBER
        JSR PC,OCTP ;PRINT NUMBER OF BAD SPOTS
        MOV #MSG68,R4
        JSR PC,TTOUT ;PRINT BAD TAPE TAG
        TST @BTPT ;SEE IF ANY BAD SPOTS
        BNE BTOVD ;IF SO: BR
        RTS PC
BTOVD: MOV BTPT,R1 ;SET TABLE POINTER
        TST (R1)+
        CLR RO
BTCV1: MOV RO,R3
        CLC
        ROR R3 ;R3=R3/2 FOR CORRECT NUMBER
        JSR PC,OCTP ;PRINT ENTRY NUMBER
        MOV #MSG13,R4
        TSTB (R4)+ ;SKIP CR/LF
        JSR PC,TTOUT ;PRINT BLOCK NUMBER TAG
        MOV (R1),R3
        JSR PC,OCTP ;PRINT BLOCK NUMBER
        MOV #MSG14,R4
        JSR PC,TTOUT ;PRINT RECORD NUMBER TAG
        ADD #40,R1
        MOV (R1)+,R3
        JSR PC,OCTP ;PRINT RECORD NUMBER
        SUB #40,R1 ;RESET POINTER FOR BLOCK NUMBER
        TST (R0)+
        CMP RO,@BTPT ;SEE IF DONE
        BEQ BTOVD2
        MOV #MSG67,R4
        JSR PC,TTOUT ;DO CR/LF
        BR BTOV1 ;CONTINUE
        TST BTSTF ;SEE IF STAT ONLY PRINT
        BNE BTOVX ;IF SO: BR
        JSR PC,BTCLR ;CLEAR TABLE
        RTS PC ;RETURN

;CLEAR BAD TAPE TABLE
BTCLR: MOV #41,R3 ;SET SIZE OF TABLE
        MOV BTPT,R4 ;SET POINTER
        CLR (R4)+ ;CLEAR ENTRY
        DEC R3 ;DONE?
        BNE BTCLR1 ;IF NOT: BR
        RTS PC ;RETURN
BTCLR1: CLR (R4)+
        DEC R3
        BNE BTCLR1
        RTS PC
    
```

3551
3552
3553
3554
3555
3556
3557
3558
3559
3560
3561
3562
3563
3564
3565
3566
3567
3568
3569
3570
3571
3572
3573
3574
3575
3576
3577
3578
3579
3580
3581
3582
3583
3584
3585
3586
3587
3588
3589
3590
3591
3592

015036 013703 000622
016042 004737 022120
016046 005037 000742
016052 005403
016054 005737 000756
016060 001413
016062 012703 000002
016066 005737 001010
016072 001401
016074 005303
016076 032777 000004 162476 15:
016104 001401
016106 005003
016110 032777 000004 162464 ERCA:
016116 001404
016120 062703 026200
016124 000137 016134
016130 062703 032212
016134 010337 016740
016140 020377 162442
016144 001105
016146 017703 162432
016152 001102
016154 005037 013706
016160 032777 000004 162414
016166 001045
016170 032777 000020 162402
016176 001041
016200 012737 013700 013704
016206 005737 000756
016212 001404
016214 000432

```
*****  
:READ/WRITE STATUS CHECK SUBROUTINE:  
:THIS SUBROUTINE IS USED TO PERFORM A CHECK  
:OF THE TAPE STATUS REGISTER FOR ERRORS AND  
:TO ASSURE A CORRECT CURRENT MEMORY ADDRESS  
:AND CHARACTER COUNT AT THE END OF EACH TAPE  
:OPERATION (READ OR WRITE).  
:IF A STATUS ERROR IS INDICATED BY BIT FIFTEEN (15)  
:OF THE COMMAND REGISTER BEING SET, THEN AN ERROR  
:HEADER CONSISTING OF UNIT NUMBER, BLOCK NUMBER,  
:RECORD NUMBER, RECORD SIZE, AND TYPE OF ERROR  
:WILL BE PRINTED FOLLOWED BY THE CONTENTS OF  
:THE COMMAND REGISTER AND STATUS REGISTER PLUS  
:THE CURRENT MEMORY ADDRESS AND CHARACTER COUNT.  
:IF NO STATUS ERROR IS INDICATED, THE CHARACTER COUNT  
:AND CURRENT MEMORY ADDRESS ARE BOTH CHECKED AND  
:THE ENTIRE PRINT OUT IS DONE IF EITHER IS IN ERROR.  
:ERROR PRINT OUTS MAY BE DISALLOWED BY SETTING CONSOLE  
:SWITCH TEN (10) TO A ONE (1).  
:THE PROGRAM MAY BE HALTED ON ANY ERROR BY SETTING  
:CONSOLE SWITCH FIFTEEN TO A ONE (1).  
*****  
ERCHK: MOV CARCNT,R3 ;GET CHARACTER COUNT  
JSR PC,CKSWR ;CHECK FOR 1G  
CLR SERFL ;CLEAR STATUS ERROR FLAG  
NEG R3  
TST TMFLG ;A TM OPERATION?  
BEQ EROA ;IF NOT: BR  
MOV #2,R3  
TST STCDFL ;SEE IF 7 TRK CORE DUMP  
BEQ 15 ;IF NOT: BR  
DEC R3 ;SET TO ONE CHARACTER  
BIT #4,QMTC ;SEE IF A WRITE TM?  
BEQ EROA ;IF NOT: BR  
CLR R3 ;ELSE CLEAR R3  
ERCA: BIT #4,QMTC ;SEE IF WRITE OP  
BEQ ERO  
ADD #WDATA,R3  
JMP ERI  
ERO: ADD #RDATA,R3 ;ADD START OF BUFFER  
ER!: MOV R3,CADER ;SAVE EXPT ADDRESS  
CMP R3,QMDA ;SEE IF ADDRESS OK  
BNE ER2 ;IF NOT: BR  
MOV QMWC,R3 ;GET CHARACTER COUNT  
BNE ER2 ;IF NOT ZERO: BR  
CLR LRCPT ;CLEAR LPC PRINT FLAG  
BIT #4,QMTC ;A WRITE OP?  
BNE ER1B ;IF SO: BR  
BIT #20,QMTC ;SEE IF SEVEN TRACK DRIVE  
BNE ER1B ;IF SO: BR  
MOV EXLRC,LRCV ;SET FOR EXPECTED LPC  
TST TMFLG ;IS IT A TM?  
BEQ 15 ;IF NOT: BR  
BR ER1B
```

3593	016216	012737	000023	013704		MOV	#23,LPCSV	;USE TM LPC
3594	016224	013704	000616		1\$:	MOV	UDES,R4	;GET UNIT DESCRIPTION
3595	016230	042704	117777			BIC	#117777,R4	;MASK DENSITY
3596	016234	022704	060000			CMP	#60000,R4	;SEE IF 9 TRK DENSITY AT 800 BPI
3597	016240	001020				BNE	ER1B	;IF NOT: BR
3598	016242	017737	162342	013702		MOV	#MTD,ACTLRC	;GET ACTUAL LPC
3599	016250	032777	020000	162374		BIT	#20000,ASWR	;SEE IF NO DATA CHECK
3600	016256	001011				BNE	ER1B	;IF NOT: BR (ALLOW READ OF UNKNOWN TAPES)
3601	016260	005237	013706			INC	LRCPT	;SET LPC PRINT FLAG
3602	016264	042737	177000	013702		BIC	#..77000,ACTLRC	;JUST 9 BITS
3603	016272	023737	013702	013704		CMP	ACTLRC,LRCSV	;DOES ACTUAL AGREE WITH EXPECTED?
3604	016300	001027				BNE	ER2	;IF NOT: BR
3605	016302	032777	100000	162272	ER1B:	BIT	#100000,AMTC	;SEE IF HAVE ERROR
3606	016310	001002				BNE	1\$;IF SO: BR
3607	016312	000137	016720			JMP	EREX	
3608	016316	017737	162256	000740	1\$:	MOV	AMTS,ERSAV	;GET STATUS
3609	016324	005737	000756			TST	TMFLG	;A TM OPERATION?
3610	016330	001404				BEQ	ER1A	;IF NOT: BR
3611	016332	042737	042125	000740		BIC	#42125,ERSAV	;IGNORE TM INDICATOR AND WRL
3612	016340	001567				BEQ	EREX	;IF NO OTHER ERRORS: BR
3613	016342	005737	000760		ER1A:	TST	EOTREC	;IS IT EOT
3614	016346	100004				BPL	ER2	;IF NOT: BR
3615	016350	042737	032125	000740		BIC	#32125,ERSAV	;IGNORE EOT INDICATOR
3616	016356	001560				BEQ	EREX	;IF NO OTHER ERRORS: BR
3617	016360	005237	000742		ER2:	INC	SERFL	;SET STATUS ERROR FLAG
3618	016364	032777	002000	162260		BIT	#2000,ASWR	;SEE IF SHOULD PRINT ERRORS
3619	016372	001411				BEQ	ER3	;IF SO: BR
3620	016374	005737	000774			TST	RRTYFL	;SEE IF READ RETRY
3621	016400	001404				BEQ	ER2A	;IF NOT: BR
3622	016402	022737	000003	000752		CMP	#3,RTCNT	;SEE IF LAST RETRY
3623	016410	001402				BEQ	ER3	;IF SO: BR
3624	016412	000137	016664		ER2A:	JMP	EREXO	;ELSE EXIT
3625	016416	005237	000732		ER3:	INC	PFLG	;SET PRINT FLAG
3626	016422	004737	017506			JSR	PC,PAPRT	;PRINT HEADER
3627	016426	013704	000716		ER3A:	MOV	EMADDR,R4	
3628	016432	004737	020530		ER3B:	JSR	PC,TTOUT	;PRINT ERROR HEADER
3629	016436	004737	016742			JSR	PC,FRPRT	;PRINT F OR R
3630	016442	005037	000712			CLR	TEMP3	
3631	016446	012704	022750			MOV	#MSG23,R4	
3632	016452	004737	020530			JSR	PC,TTOUT	;PRINT COMMAND HEADER
3633	016456	017703	162120			MOV	AMTC,R3	
3634	016462	000303			ER7:	SWAB	R3	;POSITION MOST SIGNIFICANT
3635	016464	004737	021144			JSR	PC,DOUT	;PRINT REGISTER
3636	016470	000303				SWAB	R3	;POSITION LEAST SIGNIFICANT
3637	016472	004737	021144			JSR	PC,DOUT	;PRINT REGISTER
3638	016476	005737	000712			TST	TEMP3	;SEE IF PRINTED STATUS REGISTER
3639	016502	001012				BNE	ER10	;IF SO: BR
3640	016504	005237	000712			INC	TEMP3	;SET FLAG
3641	016510	012704	023135			MOV	#MSG30,R4	
3642	016514	004737	020530			JSR	PC,TTOUT	;PRINT STATUS HEADER
3643	016520	017703	162054			MOV	AMTS,R3	;LOAD STATUS REGISTER
3644	016524	000137	016462			JMP	ER7	;GO PRINT STATUS
3645	016530	012704	023643		ER10:	MOV	#MSG46,R4	
3646	016534	004737	020530			JSR	PC,TTOUT	;PRINT CHARACTER COUNT HEADER
3647	016540	017703	162040			MOV	AMWC,R3	
3648	016544	005403				NEG	R3	;SET TO TRUE VALUE

```

3649 016546 004737 020716 JSR PC, OCTP ;PRINT CHARACTER COUNT
3650 016552 012704 023650 MOV #MSG47, R4
3651 016556 004737 020530 JSR PC, TTOUT ;PRINT ADDRESS HEADER
3652 016562 017703 162020 MOV #MDA, R3
3653 016566 004737 020716 JSR PC, OCTP ;PRINT ADDRESS
3654 016572 012737 000255 000702 MOV #255, TOB
3655 016600 004737 020670 JSR PC, TOG ;PRINT /
3656 016604 013703 016740 MOV CADER, R3
3657 016610 004737 020716 JSR PC, OCTP ;PRINT EXPT ADDRESS
3658 016614 005737 013706 TST LACPT ;WAS LPC CHECKED?
3659 016620 001421 BEQ EREXO ;IF NOT: BR
3660 016622 012704 025247 MOV #MSG83, R4
3661 016626 004737 020530 JSR PC, TTOUT ;PRINT LPC TAG
3662 016632 013703 013702 MOV ACTLRC, R3
3663 016636 004737 020716 JSR PC, OCTP ;PRINT ACTUAL LPC
3664 016642 012737 000255 000702 MOV #255, TOB
3665 016650 004737 020670 JSR PC, TOG ;PRINT -
3666 016654 013703 013704 MOV LACSV, R3
3667 016660 004737 020716 JSR PC, OCTP ;PRINT EXPECTED LPC
3668 016664 032777 100000 161760 EREXO: BIT #100000, ASWR ;SEE IF STOP ON ERRCR
3669 016672 001412 BEQ EREX ;IF NOT: BR
3670 016674 000000 HALT
3671 016676 005737 000732 TST PFLG ;SEE IF PRINT
3672 016702 001006 BNE EREX ;IF SO: BR
3673 016704 032777 002000 161740 BIT #2000, ASWR ;SEE IF SHOULD PRINT
3674 016712 001002 BNE EREX ;IF NOT: BR
3675 016714 000137 016416 JMP ER3 ;PRINT ERROR
3676 016720 004737 022120 EREX: JSR PC, CKSWR ;GO TEST FOR 1G
3677 016724 005037 000732 CLR PFLG ;CLEAR FLAG
3678 016730 017737 161644 000740 MOV #MTC, ERSV ;SAVE STATUS REGISTER
3679 016736 000207 RTS PC ;RETURN
3680 016740 000000 CADER: 0 ;EXPT ADDRESS SAVE LOCATION
3681
3682 ;*****
3683 ;F FOR FORWARD/R FOR REVERSE PRINT SUBROUTINE:
3684 ;
3685 ;THIS SUBROUTINE IS USED TO PRINT OUT THE
3686 ;TAPE DIRECTION USED WHEN ANY ERROR IS
3687 ;DETECTED IN STATUS OF READ OR WRITE, DATA, OR
3688 ;SPACING OPERATIONS.
3689 ;*****
3690
3691 016742 032777 000004 161632 FRPRT: BIT #4, MTC ;SEE IF WRITE COMMAND
3692 016750 001015 BNE FREX ;IF SO: BR
3693 016752 032737 010000 000626 BIT #10000, RDCMD ;SEE IF READ REVERSE
3694 016760 001405 BEQ FRO ;IF NOT: BR
3695 016762 012704 022564 MOV #MSG17, R4
3696 016766 004737 020530 JSR PC, TTOUT ;PRINT R
3697 016772 000404 BR FREX
3698 016774 012704 022556 FRO: MOV #MSG16, R4
3699 017000 004737 020530 JSR PC, TTOUT ;PRINT F
3700 017004 000207 RTS PC ;EXIT

```

3701
3702
3703
3704
3705
3706
3707
3708
3709
3710
3711
3712
3713
3714
3715
3716
3717
3718
3719
3720
3721
3722
3723
3724
3725
3726
3727
3728
3729
3730
3731
3732
3733
3734
3735
3736
3737
3738
3739
3740
3741
3742
3743
3744
3745
3746
3747
3748
3749
3750
3751
3752
3753
3754
3755
3756

017006 005037 000706
017012 013704 000602
017016 005204
017020 113714 000617
017024 032777 000200 161550
017032 001035
017034 005237 000706
017040 001371
017042 004737 017506
017046 032777 000004 161526
017054 001405
017056 012704 022452
017062 004737 020530
017066 000406
017070 012704 022457
017074 004737 020530
017100 004737 016742
017104 012704 023007
017110 004737 020530
017114 000000
017116 005037 000734
017122 000137 003264
017126 000240
017130 000240
017132 005037 000706
017136 032777 000100 161434
017144 001013

TAPG:
TAPG0:
TAPG1:
TAPG2:
TAPG2A:
TAPG3:
1S:

CLR TEMP1
MOV MTC,R4
INC R4
MOVB UDES+1,(R4)
BIT #200,AMTC
BNE TAPG3
INC TEMP1
BNE TAPG0
JSR PC,PAPRT
BIT #4,AMTC
BEQ TAPG1
MOV #MSG5,R4
JSR PC,TTOUT
BR TAPG2
TAPG1: MOV #MSG6,R4
JSR PC,TTOUT
JSR PC,FRPRT
TAPG2: MOV #MSG25,R4
JSR PC,TTOUT
TAPG2A: HALT
CLR UNP
JMP STAUTO
TAPG3: NOP
NOP
CLR TEMP1
BIT #100,AMTS
BNE 2\$

;GET COMD REGISTER ADDRESS
;BUMP TO HIGH BYTE
;LOAD UNIT DESCRIPTION
;SEE IF HAVE READY
;IF SO: BR
;SEE IF TIMED OUT
;WAIT FOR READY
;PRINT CYCLE NUMBER
;SEE IF WRITE OP
;IF NOT: BR
;PRINT WRITE ERR
;PRINT READ ERR
;PRINT F OR R
;PRINT NO READY ERR
;RESET UNIT POINTER
;RESTART
;SET DELAY
;SEE IF SELR
;IF SO: BR

:TAPE COMMAND EXECUTE SUBROUTINE:
:THIS SUBROUTINE IS USED TO EXECUTE THE
:MAG TAPE COMMAND DESCRIBED BY THE READ
:OR WRITE ROUTINE. THE FINAL COMMAND IS
:SENT TO THE DEVICE REGISTER ALONG WITH THE
:INTERRUPT ENABLE AND GO BITS.
:ONCE THE COMMAND IS ISSUED, AN INTERRUPT
:TIMER IS STARTED AND IF NO INTERRUPT IS RETURNED
:BEFORE TIME OUT OCCURS, AN ERROR WILL BE
:PRINTED AND THE PROGRAM STOPPED. TESTING MAY
:BE RESUMED BY PRESSING THE CONTINUE BUTTC'
:TWO INTERRUPT HANDLERS ARE USED, ONE FOR MAG TAPE
:AND ANOTHER FOR TELETYPE (TTY).
:UPON RECEIPT OF A MAG TAPE INTERRUPT, HOUSEKEEPING
:IS PERFORMED AND CONTROL RETURNED TO THE CALLING
:ROUTINE (READ,WRITE,ETC).
:RECEIPT OF A TTY INTERRUPT WILL CAUSE THE
:PROGRAM TO CHECK FOR ENTRY OF A CNTRL C CHARACTER.
:IF NOT CNTRL C, THEN CONTINUATION OF WAIT FOR MAG
:TAPE INTERRUPT IS RETURNED. IF, HOWEVER, THE TTY
:INTERRUPT WAS CAUSED BY ENTRY OF A CNTRL C,
:THEN AT THIS TIME REQUESTS FOR NEW STALL VALUES
:ARE PRINTED AND THE RESPONSES ENTERED. RESUMPTION
:OF TAPE INTERRUPT WAIT IS THEN RESUMED.

```

3757 017146 005237 000706      INC      TEMP1
3758 017152 001371      BNE      1$
3759 017154 004737 017506      JSR      PC,PAPRT      ;DELAY
3760 017160 012704 026020      MOV      #MSG95,R4    ;PRINT HEADER
3761 017164 004737 020530      JSR      PC,TTCUT
3762 017170 000137 020050      JMP      DRPDRV      ;PRINT SELR LOST
3763 017174 005077 161450      2$:      CLR      @PSW        ;GO DROP DRIVE
3764 017200 000240      NOP
3765 017202 000240      NOP      ;SET TO PRIORITY 0
3766 017204 052777 000101 161370      BIS      #101,@MTC    ;SET INTERRUPT ENABLE AND GO
3767 017212 012704 020000      MOV      #20000,R4
3768 017216 005003      CLR      R3
3769 017220 032777 000004 161354      BIT      #4,@MTC      ;SEE IF WRITE OP
3770 017226 001042      BNE      TAPG8        ;IF SO GO TO WRITE EOT WATCH
3771 017230 005303      TAPG4:  DEC     R3
3772 017232 001376      BNE      TAPG4
3773 017234 005304      DEC     R4            ;SEE IF TIMED OUT
3774 017236 001374      BNE      TAPG4
3775 017240 012777 000340 161402      TAPG5:  MOV     #340,@PSW  ;RESET PRIORITY
3776 017246 042777 000100 161326      BIC     #100,@MTC    ;CLEAR INTERRUPT ENABLE
3777 017254 032777 002000 161370      BIT     #2000,@SWR   ;SEE IF SHOULD PRINT ERRORS
3778 017262 001014      BNE      TAPG6        ;IF NOT: BR
3779 017264 004737 017506      JSR     PC,PAPRT     ;PRINT CYCLE NUMBER
3780 017270 013704 000716      MOV     EMADDR,R4
3781 017274 004737 020530      JSR     PC,TTCUT
3782 017300 004737 016742      JSR     PC,FRPRT
3783 017304 012704 022757      MOV     #MSG24,R4
3784 017310 004737 020530      JSR     PC,TTCUT     ;PRINT NO INTERRUPT
3785 017314 032777 100000 161330      TAPG6:  BIT     #100000,@SWR ;SEE IF SHOULD HALT ON ERROR
3786 017322 001401      BEQ     TAPG7        ;IF NOT: BR
3787 017324 000000      HALT
3788 017326 000240      TAPG7:  NOP
3789 017330 000177 161370      JMP     @RTN         ;RETURN TO CALLING ROUTINE
3790 017334 032777 000010 161236      TAPG8:  BIT     #10,@MTC    ;SEE IF SDWN SET
3791 017342 001012      BNE     2$           ;IF SO: BR
3792 017344 032777 002000 161226      BIT     #2000,@MTC   ;SEE IF EOT REACHED
3793 017352 001404      BEQ     1$           ;IF NOT: BR
3794 017354 052737 000001 017402      BIS     #1,WEOTF     ;SET EOT FLAG
3795 017362 000402      BR      2$
3796 017364 005037 017402      1$:      CLR     WEOTF        ;CLEAR FLAG
3797 017370 005303      2$:      DEC     R3
3798 017372 001360      BNE     TAPG8        ;DELAY
3799 017374 005304      DEC     R4
3800 017376 001356      BNE     TAPG8        ;DELAY
3801 017400 000717      BR      TAPG5
3802 017402 000000      WEOTF:  0
3803

```

```

3804
3805
3806
3807 017404 012777 000340 161236 TTINT: MOV #340, @PSW ;RESET PSW
3808 017412 005077 161240 CLR @TKS ;CLEAR TTY STATUS
3809 017416 122777 000203 161234 CMPB #203, @TKB ;SEE IF CONT C
3810 017424 001404 SEQ TTINTO ;IF SO: BR
3811 017426 004737 022120 JSR PC, CKSWR ;GO CHECK FOR ↑G
3812 017432 000240 NOP
3813 017434 000002 RTI ;ELSE RETURN
3814 017436 010037 000712 TTINTO: MOV R0, TEMP3 ;SAVE R0(REC CNTR)
3815 017442 004737 012164 JSR PC, TINP4 ;GO GET STALL VALUES
3816 017446 013700 000712 MOV TEMP3, R0 ;RESTORE R0(REC CNTR)
3817 017452 005077 161202 CLR @TKB ;CLEAR TTY BUFFER
3818 017456 012777 000100 161172 MOV #100, @TKS ;RESET INTERRUPT ENABLE
3819 017464 000002 RTI ;RETURN
3820
3821 ;MAG TAPE INTERRUPT HANDLER*****
3822
3823 017466 022626 000100 161104 MTINT: CMP (SP)+, (SP)+ ;RESET STACK POINTER
3824 017470 042777 000100 BIC #100, @MTC ;RESET INTERRUPT ENABLE
3825 017476 000240 NOP
3826 017500 000240 NOP
3827 017502 000177 161216 JMP @RTRN ;RETURN
3828
3829 ;*****
3830 ;ERROR HEADER PRINT SUBROUTINE:
3831 ;
3832 ;THIS ROUTINE IS USED TO PRINT OUT A HEADER
3833 ;WITH EACH ERROR MESSAGE. THE PRINT IS IN TWO
3834 ;LINES AND CONTAINS THE FOLLOWING INFORMATION.
3835 ;LINE 1: UNIT NUMBER, DATA PATTERN NUMBER
3836 ;LINE 2: CURRENT BLOCK NUMBER, RECORD NUMBER IN
3837 ;WHICH THE ERROR OCCURED PLUS THE TOTAL NUMBER
3838 ;OF RECORDS IN THIS BLOCK, THE RECORD SIZE (NUMBER
3839 ;OF CHARACTERS), AND THE ERROR TYPE (READ, WRITE, SPACE, ETC)
3840 ;PLUS THE TAPE DIRECTION (FORWARD OR REVERSE).
3841 ;ALL NUMBERS ARE IN OCTAL.
3842 ;*****
3843
3844 017506 012704 022476 PAPRT: MOV #MSG11, R4
3845 017512 004737 020530 JSR PC, TOUT ;PRINT UNIT HEADER
3846 017516 013703 000616 MOV UDES, R3
3847 017522 000303 SWAB R3
3848 017524 042703 177770 BIC #177770, R3
3849 017530 004737 020716 JSR PC, OCTP ;PRINT UNIT NUMBER
3850 017534 012704 025560 MOV #MSG90, R4
3851 017540 004737 020530 JSR PC, TOUT ;PRINT DENSITY TAG
3852 017544 005003 CLR R3
3853 017546 032737 020000 000616 BIT #20000, UDES ;SEE IF BIT 1 OF DENSITY=1
3854 017554 001401 BEQ 1$ ;IF NOT: BR
3855 017556 005203 INC R3 ;ELSE SET BIT 1
3856 017560 032737 040000 000616 1$: BIT #40000, UDES ;SEE IF BIT 2 OF DENSITY=1
3857 017566 001402 BEQ 2$ ;IF NOT: BR
3858 017570 052703 000002 BIS #2, R3 ;ELSE SET BIT 2
3859 017574 004737 020716 JSR PC, OCTP ;PRINT DENSITY SETTING

```

3860	017600	012704	025566		MOV	#MSG91, R4	
3861	017604	004737	020530		JSR	PC, TTOUT	;PRINT PARITY TAG
3862	017610	005003			CLR	R3	
3863	017612	032737	004000	000616	BIT	#4000, UDES	;SEE IF EVEN PARITY
3864	017620	001401			BEQ	35	;IF NOT: BR
3865	017622	005203			INC	R3	;ELSE SET TO A ONE
3866	017624	004737	020716		JSR	PC, OCTP	;PRINT PARITY
3867	017630	012704	025323		MOV	#MSG86, R4	
3868	017634	004737	020530		JSR	PC, TTOUT	;PRINT PATTRN TAG
3869	017640	032777	000400	161004	BIT	#400, JSWR	;SEE IF RANDOM DATA
3870	017646	001406			BEQ	PAPRTB	;IF NOT: BR
3871	017650	012737	000122	000702	PAPRTA: MOV	1.122, TOB	
3872	017656	004737	020670		JSR	PC, TOG	;PRINT R
3873	017662	000412			BR	PAPRTD	
3874	017664	005737	021624		PAPRTB: TST	ASEQF	;SEE IF AUTO SEQ
3875	017670	001403			BEQ	PAPRTC	;IF NOT: BR
3876	017672	005737	000624		TST	PATRN	;SEE IF AUTO RANDOM
3877	017676	100764			BMI	PAPRTA	;IF SO: BR
3878	017700	013703	000624		PAPRTC: MOV	PATRN, R3	
3879	017704	004737	020716		JSR	PC, OCTP	;PRINT PATTRN NUMBER
3880	017710	012704	022513		PAPRTD: MOV	#MSG13, R4	
3881	017714	004737	020530		JSR	PC, TTOUT	;PRINT BLOCK NO. HEADER
3882	017720	013703	000720		MOV	BLCNTR, R3	
3883	017724	004737	020716		JSR	PC, OCTP	;PRINT NUMBER
3884	017730	012704	022521		MOV	#MSG14, R4	
3885	017734	004737	020530		JSR	PC, TTOUT	;PRINT REC NO. HEADER
3886	017740	010003			MOV	RD, R3	
3887	017742	032777	000004	160632	BIT	#4, JMTC	;SEE IF WRITE OPERATION
3888	017750	001000			BNE	PAPRT1	;IF SO: BR
3889	017752	013703	000620		PAPRT1: MOV	RCNT, R3	
3890	017756	160003			SUB	RD, R3	;GET RECORD NUMBER
3891	017760	005203			INC	R3	
3892	017762	004737	020716		PAPRT2: JSR	PC, OCTP	;PRINT RECORD NUMBER
3893	017766	012737	000055	000702	MOV	#55, TOB	;LOAD DASH (-)
3894	017774	004737	020670		JSR	PC, TOG	;PRINT DASH (-)
3895	020000	013703	000620		MOV	RCNT, R3	
3896	020004	004737	020716		JSR	PC, OCTP	;PRINT RECORD COUNT
3897	020010	012704	022464		MOV	#MSG7, R4	
3898	020014	004737	020530		JSR	PC, TTOUT	;PRINT RECORD SIZE HEADER
3899	020020	013703	000622		MOV	CARCNT, R3	;GET CHARACTER COUNT
3900	020024	005303			DEC	R3	
3901	020026	005103			COM	R3	;REMOVE TWOS COMPLEMENT
3902	020030	004737	020716		JSR	PC, OCTP	;PRINT RECORD SIZE
3903	020034	012737	000001	000726	MOV	#1, HDRFL	;SET HEADER FLAG
3904	020042	004737	022120		JSR	PC, CKSWR	;TEST FOR 1G
3905	020046	000207			RTS	PC	;RETURN

```

3907
3908
3909
3910 020050 000240 DRPDRV: NOP
3911 020052 012777 010000 160522 MOV #10000,R2MTC ;POWER CLEAR CONTROLLER
3912 020060 012704 025574 MOV #MSG92,R4
3913 020064 004737 020530 JSR PC,TTOUT ;PRINT UNIT DROPPED
3914 020070 013703 000616 MOV UDES,R3 ;GET UNIT DESCRIPTION
3915 020074 000303 SWAB R3
3916 020076 042702 177770 BIC #177770,R3 ;MASK UNIT NUMBER
3917 020102 004737 020716 JSR PC,OCTP ;PRINT DROPPED UNIT NUMBER
3918 020106 012704 025620 MOV #MSG93,R4
3919 020112 004737 020530 JSR PC,TTOUT ;PRINT REST OF MSG
3920 020116 013700 000734 MOV UNP,R0 ;SET UNIT POINTER
3921 020122 052760 100200 001012 BIS #100200,UN1(R0) ;SET DROPPED FLAG
3922 020130 005337 004716 DEC REOTC ;DECREMENT EOT UNIT COUNTER
3923 020134 004737 015370 JSR PC,PRSTAT ;PRINT CURRENT STATS
3924 020140 005237 001006 INC DUCTR ;BUMP DROPPED UNIT COUNTER
3925 020144 123737 001006 004717 CMPB DUCTR,REOTC+1 ;SEE IF DROPPED ALL UNITS
3926 020152 103405 BLO 1$ ;IF NOT: BR
3927 020154 012704 026047 MOV #MSG95,R4
3928 020160 004737 020530 JSR PC,TTOUT ;PRINT ALL DROPPED: STOP
3929 020164 000137 004640 JMP REOT9 ;GO TO END ROUTINE
3930 020170 000240 1$: NOP
3931 020172 005000 CLR R0
3932 020174 032760 100200 001012 2$: BIT #100200,UN1(R0) ;SEE IF ANY DRIVES LEFT IN THIS PASS
3933 020202 001414 BEQ 3$ ;IF SO: BR
3934 020204 062700 000002 ADD #2,R0 ;BUMP POINTER
3935 020210 022760 177777 001012 CMP #-1,UN1(R0) ;SEE IF LAST ENTRY
3936 020216 001366 BNE 2$ ;IF NOT: BR
3937 020220 012704 025712 MOV #MSG94,R4
3938 020224 004737 020530 JSR PC,TTOUT ;PRINT NO MORE UNITS
3939 020230 000137 004622 JMP REOT8 ;GO TO END OF PASS ROUTINE
3940 020234 000137 004072 3$: JMP START7 ;GO TO NEXT UNIT

```

```

3941
3942 ;*****
3943 ;RANDOM NUMBER GENERATOR SUBROUTINE:
3944 ;
3945 ;THIS SUBROUTINE IS USED TO GENERATE THE RANDOM
3946 ;NUMBERS REQUIRED FOR USE AS RANDOM DATA,
3947 ;RECORD COUNT, AND CHARACTER COUNT.
3948 ;*****
3949

```

```

3950 020240 063737 000676 000672 RANG: ADD RANSV,RANBAS
3951 020246 063737 000672 000676 ADD RANBAS,RANSV ;GET NEW NUMBER
3952 020254 023701 000676 CMP RANSV,R1 ;SEE IF NUMBER TOO BIG
3953 020260 101367 BHI RANG ;IF SO: BR
3954 020262 020237 000676 CMP R2,RANSV ;SEE IF NUMBER TOO SMALL
3955 020266 101364 BHI RANG ;IF SO: BR
3956 020270 000207 RTS PC ;EXIT

```


4010
4011
4012
4013 020443 012704 023576
4014 020444 004737 020530
4015 020450 162716 000020
4016 020454 000207
4017
4018
4019
4020 020456 005077 160174
4021 020462 005077 160172
4022 020466 005037 000704
4023 020472 005277 160160
4024 020476 105777 160154
4025 020502 100375
4026 020504 017737 160150 000704
4027 020512 105777 160144
4028 020516 100375
4029 020520 113777 000704 160136
4030 020526 000207
4031
4032
4033
4034 020530 112437 000702
4035 020534 122737 000043 000702
4036 020542 001460
4037 020544 122737 000045 000702
4038 020552 001407
4039 020554 122737 000041 000702
4040 020562 001434
4041 020564 004737 020670
4042 020570 000757
4043 020572 112737 000015 000702 TCRLF:
4044 020600 004737 020670
4045 020604 012703 000004
4046 020610 005037 000702 TCRLFA:
4047 020614 004737 020670
4048 020620 005303
4049 020622 001372
4050 020624 112737 000012 000702
4051 020632 004737 020670
4052 020636 105737 001004
4053 020642 100401
4054 020644 000731
4055 020646 005037 001004 IS:
4056 020652 000414
4057 020654 112737 000007 000702 TBELL:
4058 020662 004737 020670
4059 020666 000720
4060 020670 105777 157765 TOG:
4061 020674 100375
4062 020676 113777 000702 157760
4063 020704 000207
4064
4065

:TTY ENTRY ERROR SUBROUTINE*****

TINER: MOV #MSG43,R4
JSR PC,TTOUT ;PRINT?
SUB #20,(SP) ;RESET SP TO START OF VALUE ROUTINE
RTS PC ;REDO VALUE ENTRY

:TTY READ SUBROUTINE*****

TTIN: CLR @TKS
CLR @TKB
CLR TIB
INC @TKS
TTIN1: TSTB @TKS
BPL TTIN1
MOV @TK3,TIB
TTIN2: TSTB @TFS
BPL TTIN2
MOVB TIB,@TPE
RTS PC

:TTY OUTPUT SUBROUTINE*****

TTOUT: MOVB (R4)+,TOB
CMPB #43,TCB
BEQ TEX
CMPB #45,TO3
BEQ TCRLF
CMPB #41,TCB
BEQ TBELL
JSR PC,TOG
BR TTOUT
TCRLF: MOVB #15,TOE
JSR PC,TOG
MOV #4,R3
TCRLFA: CLR TOB
JSR PC,TOG
DEC R3
BNE TCRLFA ;DO FILLERS
MOVB #12,TOB
JSR PC,TOG
TSTB RDSW
BMI IS
BR TTOUT
IS: CLR RDSW
BR TEX
TBELL: MOVB #7,TOE
JSR PC,TOG
BR TTOUT
TOG: TSTB @TFS
BPL TOG
MOVB TOB,@TPE
TEX: RTS PC

```

;OCTAL OUTPUT SUBROUTINE*****
4066
4067
4068 020706 012737 000001 021142 OCTPE: MOV #1,OFL
4069 020714 000402 BR OCTPE1
4070 020716 005037 021142 OCTP: CLR OFL ;CLEAR FLAG FOR LEADING ZERO
4071 020722 010304 OCTPE1: MOV R3,R4
4072 020724 001007 SNE OCTPO ;IF NOT ZERO: BR
4073 020726 005737 021142 TST OFL
4074 020732 001004 BNE OCTPO
4075 020734 004737 021122 JSR PC,OCTPG1 ;ELSE PRINT ZERO
4076 020740 000137 021064 JMP OCTP3 ;SPACE AND EXIT
4077 020744 032704 105000 OCTPO: BIT #10000,R4 ;SEE IF MSD = 1
4078 020750 001406 BEQ OCTP1 ;IF NOT: BR
4079 020752 012704 000001 MOV #1,R4
4080 020756 004737 021100 JSR PC,OCTPG ;PRINT 1
4081 020762 000137 020774 JMP OCTP2
4082 020766 005004 OCTP1: CLR R4
4083 020770 004737 021100 JSR PC,OCTPG ;PRINT 0
4084 020774 010304 OCTP2: MOV R3,R4
4085 020776 006004 ROR R4
4086 021000 006004 ROR R4
4087 021002 006004 ROR R4 ;POSITION DIGIT
4088 021004 006004 ROR R4
4089 021006 000304 SWAB R4
4090 021010 004737 021100 JSR PC,OCTPG ;PRINT DIGIT 2
4091 021014 010304 MOV R3,R4
4092 021016 006004 ROR R4
4093 021020 000304 SWAB R4
4094 021022 004737 021100 JSR PC,OCTPG ;PRINT DIGIT 3
4095 021026 010304 MOV R3,R4
4096 021030 006104 ROL R4
4097 021032 006104 ROL R4
4098 021034 000304 SWAB R4
4099 021036 004737 021100 JSR PC,OCTPG ;PRINT DIGIT 4
4100 021042 010304 MOV R3,R4
4101 021044 006004 ROR R4
4102 021046 006004 ROR R4
4103 021050 006004 ROR R4
4104 021052 004737 021100 JSR PC,OCTPG
4105 021056 010304 MOV R3,R4
4106 021060 004737 021100 JSR PC,OCTPG ;PRINT DIGIT 5
4107 021064 012737 000240 000702 OCTP3: MOV #240,TCB
4108 021072 004737 020670 JSR PC,TOG ;PRINT SPACE
4109 021076 000207 RTS PC ;EXIT
4110 021100 042704 177770 OCTPG: BIC #177770,R4
4111 021104 001004 BNE OCTPG0
4112 021106 005737 021142 TST OFL
4113 021112 001001 BNE OCTPG0
4114 021114 000207 RTS PC
4115 021116 005237 021142 OCTPG0: INC OFL
4116 021122 052704 000260 OCTPG1: BIS #260,R4
4117 021126 010437 000702 MOV R4,TOB
4118 021132 004737 020670 JSR PC,TOG
4119 021136 010304 MOV R3,R4
4120 021140 000207 RTS PC
4121 021142 000000 OFL: 0 ;FIRST CHAR FLAG

```

4132
4133
4134
4135
4136
4137
4138
4139
4140
4141
4142
4143
4144
4145
4146
4147
4148
4149

021144 005037 000702
021150 012704 000010
021154 110337 000702
021160 105777 157476
021164 100375
021166 132737 000200 000702
021174 001404
021176 012777 000061 157460
021204 000403
021206 012777 000060 157450
021214 006137 000702
021220 005304
021222 001355
021224 000207

021226 005777 157360
021232 100775
021234 005777 157352
021240 100375
021242 005777 157344
021246 100775
021250 000207

;DATA CHARACTER OUTPUT SUBROUTINE*****

DOUT: CLR TOB
MOV #10,R4 ;SET NUMBER TO PRINT
MOV R3,TOB
DOUT1: TST @TPS
BPL DOUT1
BITB #200,TOB
BEQ DOUT2
MOV #061,@TPB
SR DOUT3
DOUT2: MOV #060,@TPB
DOUT3: ROL TOB
DEC R4
BNE DOUT1
RTS PC

;ASSURE VALID STATUS DELAY SUBROUTINE*****

STDLY: TST @MTRD
BMI STDLY ;AWAIT TIMER = 0
1S: TST @MTRD ;AWAIT TIMER =1
2S: TST @MTRD ;AWAIT TIMER = 0
BMI 2S ;EXIT
RTS PC


```

;AUTO SEQUENCE TEST ROUTINE*****
4150
4151
4152 021252 012704 025036 ASEQ: MOV #MSG78,R4
4153 021256 004737 020530 JSR PC,TTOUT ;PRINT CONT. REQUEST
4154 021262 013703 021626 MOV ASEQCF,R3
4155 021266 004737 020716 JSR PC,OCTP ;PRINT CURRENT VALUE
4156 021272 012705 021626 MOV #ASEQCF,R5 ;SET ENTRY ADDRESS
4157 021276 012701 000301 MOV #1,R1 ;SET SIZE OF ENTRY
4158 021302 012702 000001 MOV #1,R2 ;SET UPPER LIMIT
4159 021306 005003 CLR R3 ;SET LOWER LIMIT
4160 021310 004737 020272 JSR PC,TTR ;GET INPUT
4161
4162 021314 004737 021630 ASEQ0: JSR PC,HRDS ;SELECT HARDWARE CONFIGURATION
4163 021320 012704 025053 MOV #MSG79,R4
4164 021324 004737 020530 JSR PC,TTOUT ;PRINT DIVIDER
4165 021330 012704 025121 MOV #MSG80,R4
4166 021334 004737 020530 JSR PC,TTOUT ;PRINT UNITS NUMBER MESSG.
4167 021340 012700 001012 MOV #UNI,R0 ;POINT TOP OF DRIVE TABLE
4168 021344 005710 ASEQ2: TST (R0) ;SEE IF END
4169 021346 100424 BMI AMOD1 ;IF SO: BR
4170 021350 011037 000706 MOV (R0),TEMP1 ;GET UNIT DESCRIPTION
4171 021354 113703 000707 MOVVB TEMP1+1,R3 ;POSITION AND
4172 021360 042703 177770 BIC #177770,R3 ; MASK UNIT NUMBER
4173 021364 004737 020716 JSR PC,OCTP ;PRINT DRIVE TABLE
4174 021370 012704 023726 MOV #MSG51,R4 ;PRESET FOR 9 TRK MSG
4175 021374 032710 020000 BIT #20000,(R0) ;SEE IF 7 TRK
4176 021400 001002 BNE 15 ;IF NOT: BR
4177 021402 012704 023717 MOV #MSG50,R4 ;SET TO 7 TRK MSG
4178 021406 004737 020530 15: JSR PC,TTOUT ;PRINT TRK MSG
4179 021412 062700 000002 ADD #2,R0 ;BUMP POINTER
4180 021416 000752 BR ASEQ2 ;DO ALL
4181 021420 005037 000720 AMOD1: CLR BLCNTR
4182
4183 021424 004737 004732 AMOD1B: JSR PC,RWINDA ;GO REWIND ALL DRIVES
4184 021430 012737 000006 021622 MOV #6,ABLCNT ;SET NUMBER OF BLOCKS
4185 021436 012737 174000 000622 MOV #-4000,CARCNT ;SET RECORD SIZE
4186 021444 012737 000100 000620 MOV #100,RCNT ;SET RECORD COUNT
4187 021452 012737 000003 000624 MOV #3,PATRN ;SELECT PATTERN 3
4188 021460 005037 000646 CLR TMEX ;ASSURE NO TM
4189 021464 004737 003264 JSR PC,STAUTO ;GO DO THIS PATTERN
4190 021470 012737 000007 000624 MOV #7,PATRN ;SELECT PATTERN 7
4191 021476 004737 003264 JSR PC,STAUTO ;GO DO THIS PATTERN
4192 021502 012737 000011 000624 MOV #11,PATRN ;SELECT PATTERN 11
4193 021510 004737 003264 JSR PC,STAUTO ;GO DO THIS PATTERN
4194 021514 012737 177777 021622 MOV #-1,ABLCNT ;FORCE TO END OF TAPE
4195 021522 012737 177777 000624 MOV #-1,PATRN ;SELECT AUTO RANDOM DATA
4196 021530 012737 152634 000672 MOV #152634,PANBAS
4197 021536 012737 032561 000676 MOV #32561,RANSAV ;RESET RANDOM DATA BASE
4198 021544 004737 003264 JSR PC,STAUTO ;GO DO RANDOM
4199 021550 012704 025053 MOV #MSG79,R4
4200 021554 004737 020530 JSR PC,TTOUT ;PRINT DIVIDER
4201 021560 012704 025145 ASEQX: MOV #MSG81,R4
4202 021564 004737 020530 JSR PC,TTOUT
4203 021570 005737 021626 TST ASEQCF ;SEE IF CONTINUOUS AUTO SEQ
4204 021574 001001 BNE ASEQXX ;IF SO: BR
4205 021576 000000 HALT
  
```

```

4206 021600 004737 022120 ASEQXX: JSR PC,CKSWR ;TEST FOR 1G
4207 021604 005237 000776 INC SEQCT ;BUMP PASS COUNT
4208 021610 013703 000776 MOV SEQCT,R3
4209 021614 004737 020716 JSR PC,OC1P ;PRINT PASS COUNT
4210 021620 000635 BR ASEQO
4211 021622 000000 ABLCNT: 0
4212 021624 000000 ASEQF: 0
4213 021626 000000 ASEQCF: 0
4214
4215 ;SUBROUTINE TO SELECT AUTO SEQ HARDWARE*****
4216
4217 021630 005003 HRDS: CLR R3 ;CLEAR TABLE POINTER
4218 021632 005037 000706 CLR TEMP1 ;CLEAR UNIT DESCRIPTION HOLDER
4219 021636 005037 000712 CLR TEMP3 ;UNIT COUNT
4220 021642 005037 004716 CLR REOTC ;CLEAR EOT COUNTER
4221 021646 005037 000710 CLR TEMP2 ;CLEAR UNIT INCREMENT
4222 021652 012777 010000 156722 MOV #10000,AMTC ;POWER CLEAR CONTROLLER
4223 021660 113737 000710 000707 HRDS1: MOVB TEMP2,TEMP1+1 ;POSITION UNIT NUMBER
4224 021666 013777 000706 156706 MOV TEMP1,AMTC ;SELECT DRIVE
4225 021674 004737 021226 JSR PC,STOLY ;GO ASSURE VALID STATUS
4226 021700 032777 000001 156672 BIT #1,AMTS ;SEE IF AVAIL
4227 021706 001421 BEQ HRDS2 ;IF NOT: BR
4228 021710 052737 060000 000706 BIS #60000,TEMP1 ;SET DENSITY AND PARITY
4229 021716 032777 000020 156654 BIT #20,AMTS ;SEE IF 7 TRK
4230 021724 001403 BEQ 1$ ;IF NOT: BR
4231 021726 042737 020000 000706 BIC #20000,TEMP1 ;ELSE SET TO 7 TRK NORMAL DENSITY
4232 021734 013763 000706 001012 1$: MOV TEMP1,UN1(R3) ;PUT IN TABLE
4233 021742 052703 000002 ADD #2,R3
4234 021746 005237 000712 INC TEMP3 ;INCREMENT COUNT
4235
4236 021752 005237 000710 HRDS2: INC TEMP2 ;SET FOR NEXT UNIT
4237 021756 022737 000010 000710 CMP #10,TEMP2 ;DONE?
4238 021764 001335 BNE HRDS1 ;IF NOT: BR
4239 021766 005703 TST R3 ;FOUND A UNIT?
4240 021770 001007 BNE HRDSX ;IF SO: BR
4241 021772 012704 025173 MOV #MSG82,R4
4242 021776 004737 020530 JSR PC,TTOUT ;TYPE NO UNIT AVAILABLE
4243 022002 000000 HALT ;HALT
4244 022004 000137 003106 JMP STAUT ;START AUTO SEQ AGAIN
4245 022010 012763 177777 001012 HRDSX: MOV #-1,UN1(R3) ;MARK END OF TABLE
4246 022016 013737 000712 004716 MOV TEMP3,REOTC ;SET NUMBER OF UNITS
4247 022024 000337 000712 SWAB TEMP3
4248 022030 053737 000712 004716 BIS TEMP3,REOTC ;SET EOT CNTR
4249 022036 000207 RTS PC ;RETURN
4250
4251
4252 022040 013746 000006 SUSWR: MOV @#6,-(SP) ;SAVE VECTORS
4253 022044 013746 000004 MOV @#4,-(SP)
4254 022050 012737 022070 000004 MOV #1$,@#4 ;SET UP FOR TIMEOUT
4255 022056 022777 177777 156566 CMP #-1,@SWR ;REFERENCE HARDWARE SWITCH REGISTER
4256 022064 001402 BEQ 2$
4257 022066 000407 BR 3$
4258 022070 022626 1$: CMP (SP)+,(SP)+ ;ADJUST STACK
4259 022072 012737 000176 000652 2$: MOV #SWREG,SWR ;POINT TO SOFTWARE SWITCH REG
4260 022100 012737 000174 000654 MOV #DISPREG,DISPLAY ;POINT TO SOFT DISPLAY REG
4261 022106 012637 000004 3$: MOV (SP)+,@#4 ;RESTORE VECTORS

```

```

4252 022112 012637 000006      MOV      (SP)+, @#6
4263 022116 000207      RTS      PC                ;RETURN
4264
4265 022120 022737 000176 000652 CKSWR:  CMP      #SWREG, SWR      ;SOFTWARE SWITCH REG PRESENT
4266 022126 001036      BNE      OUT              ;NO GET OUT
4267 022130 017737 156524 000704      MOV      @TKB, TIB       ;AND STRIP OFF
4268 022136 042737 177600 000704      BIC      #177600, TIB    ;THE GARBAGE
4269 022144 022737 000007 000704      CMP      #7, TIB        ;IS IT A <↑G>
4270 022152 001024      BNE      OUT
4271 022154 012704 026154      MOV      #SCNTG, R4
4272 022160 004737 020530      JSR      PC, TTOUT
4273 022164 012704 026160      MOV      #MSWR, R4      CNTLU:
4274 022170 004737 020530      JSR      PC, TTOUT
4275 022174 017703 156452      MOV      @SWR, R3
4276 022200 004737 020706      JSR      PC, OCTPE
4277 022204 012704 026170      MOV      #MNEW, R4
4278 022210 004737 020530      JSR      PC, TTOUT
4279 022214 005037 001002      CLR      @TEMPST
4280 022220 004737 022226      JSR      PC, $READ
4281 022224 000207      OUT:      RTS              ;GO READ A LINE
4282                                     ;RETURN TO MAIN BODY OF PROGRAM
4283 022226 005037 001002      $READ:   CLR      TEMPST
4284 022232 012737 000007 001000      MOV      #7, COUNT
4285 022240 004737 020456      1$:      JSR      PC, TTIN
4286 022244 042737 177600 000704      BIC      #177600, TIB    ;GO READ A CHARACTER
4287 022252 122737 000025 000704      CMPB     #25, TIB       ;STRIP OFF GARBAGE
4288 022260 001002      BNE      2$              ;IS IT A ↑U?
4289 022262 005726      3$:      TST      (SP)+          ;BRANCH IF NOT
4290 022264 000737      BR       CNTLU           ;POP THE STACK
4291 022266 122737 000015 000704      2$:      CMPB     #15, TIB       ;START OVER
4292 022274 001013      BNE      4$              ;IS IT A <CR>?
4293 022276 012737 000200 001004      MOV      #200, RDSW     ;BRANCH IF NOT
4294 022304 004737 020572      JSR      PC, TCR LF
4295 022310 022737 000007 001000      CMP      #7, COUNT     ;ECHO IT WITH <LF>
4296 022316 001037      BNE      7$              ;WAS IT FIRST CHARACTER
4297 022320 005726      8$:      TST      (SP)+          ;CHANGE SWR IF NOT FIRST ONE
4298 022322 000740      BR       OUT            ;POP THE STACK
4299 022324 122737 000060 000704      4$:      CMPB     #60, TIB       ;GET OUT
4300 022332 003004      BGT      5$
4301 022334 122737 000067 000704      CMPB     #67, TIB
4302 022342 002005      BGE      6$
4303 022344 012704 023576      5$:      MOV      #MSG43, R4
4304 022350 004737 020530      JSR      PC, TTOUT
4305 022354 000742      BR       3$              ;START OVER IF NOT LEGAL CHARACTER
4306 022356 006337 001002      6$:      ASL      TEMPST
4307 022362 006337 001002      ASL      TEMPST
4308 022366 006337 001002      ASL      TEMPST
4309 022372 142737 000060 000704      BICB     #60, TIB       ;GET NITTY-GRITTY
4310 022400 153737 000704 001002      BISB     TIB, TEMPST
4311 022406 005337 001000      DEC      COUNT          ;ONLY WANT 6 DIGITS
4312 022412 001754      BEQ      5$
4313 022414 000711      BR       1$
4314 022416 013777 001002 156226      7$:      MOV      TEMPST, @SWR   ;CHANGE SWITCH REGISTER CONTENTS
4315 022424 000735      BR       8$
4316
4317

```

```

4318
4319 ;ERROR MESSAGES*****
4320
4321 022426 042052 020105 043 MSG1: .ASCII /*DE */
4322
4323 022433 045 035507 021440 MSG2: .ASCII /*G; */
4324
4325 022440 041045 020073 043 MSG3: .ASCII /*B; */
4326
4327 022445 045 047103 021440 MSG4: .ASCII /*CN */
4328
4329 022452 053452 020105 043 MSG5: .ASCII /*WE */
4330
4331 022457 052 042522 021440 MSG6: .ASCII /*RE */
4332
4333 022464 051052 020123 043 MSG7: .ASCII /*RS */
4334
4335 022471 052 042523 021440 MSG10: .ASCII /*SE */
4336
4337 022476 022445 052445 044516 MSG11: .ASCII /*%%UNIT NO. */
4338 022504 020124 047516 020056
4339 022512 043
4340
4341 022513 045 041052 020116 MSG13: .ASCII /**BN */
4342 022520 043
4343
4344 022521 052 047122 021440 MSG14: .ASCII /**RN */
4345
4346 022526 020045 020040 020040 MSG15: .ASCII /* BAD RECORD%%*/
4347 022534 020040 020040 041040
4348 022542 042101 051040 041505
4349 022550 051117 022504 021445
4350
4351 022556 043040 025052 021452 MSG16: .ASCII / F****/
4352
4353 022564 051040 025052 021452 MSG17: .ASCII / R****/
4354
4355 022572 042445 052117 020040 MSG20: .ASCII /*EOT NO. */
4356 022600 047040 027117 021440
4357 022606 052445 044516 020124 MSG20A: .ASCII /*UNIT WILL REWIND AND BE*/
4358 022614 044527 046114 051040
4359 022622 053505 047111 020104
4360 022630 047101 020104 042502
4361 022636 045
4362 022637 122 051505 040524 .ASCII /RESTARTED ON BLOCK ONE*/
4363 022644 052122 042105 047440
4364 022652 020116 046102 041517
4365 022660 020113 047117 022505
4366 022666 044127 047105 040440 .ASCII /WHEN ALL AVAIL UNITS REACH EOT*/
4367 022674 046114 040440 040526
4368 022702 046111 052440 044516
4369 022710 051524 051040 040505
4370 022716 044103 042440 052117
4371 022724 043
4372
4373

```

4374	022725	045	020441	044441	MSG22: .ASCII	/%!!!ILLEGAL BOT%%#/ /
4375	022732	046114	043505	046101		
4376	022740	041040	052117	022445		
4377	022746	021445				
4378						
4379	022750	041445	046517	020104	MSG23: .ASCII	/%CMD #/ /
4380	022756	043				
4381						
4382	022757	045	047516	044440	MSG24: .ASCII	/%NO INTERRUPT RETURNED%%#/ /
4383	022764	052116	051105	052522		
4384	022772	052120	051040	052105		
4385	023000	051125	042516	022504		
4386	023006	043				
4387						
4388	023007	045	020441	047041	MSG25: .ASCII	/%!!!NO CONTROLLER READY !!! STOP:%%/ /
4389	023014	020117	047503	052116		
4390	023022	047522	046114	051105		
4391	023030	051040	040505	054504		
4392	023036	020440	020441	051440		
4393	023044	047524	035120	045		
4394	023051	120	042522	051523	.ASCII	/%PRESS CONTINUE TO RESUME TESTING%%#/ /
4395	023056	041440	047117	044524		
4396	023064	052516	020105	047524		
4397	023072	051040	051505	046525		
4398	023100	020105	042524	052123		
4399	023106	047111	022507	043		
4400						
4401	023113	045	051104	050117	MSG26: .ASCII	/%DROPS: #/ /
4402	023120	035123	021440			
4403						
4404	023124	050045	041511	051513	MSG27: .ASCII	/%PICKS: #/ /
4405	023132	020072	043			
4406						
4407	023135	045	052123	052101	MSG28: .ASCII	/%STAT #/ /
4408	023142	021440				
4409						
4410	023144	022445	046524	040454	MSG31: .ASCII	/%TM,A,B-11:T503 OR TU10,N,W MULTIDRIVE DATA RELIABILITY EXERCISER (DZTM /
4411	023152	041054	030455	035061		
4412	023160	051524	031460	047440		
4413	023166	020122	052524	030061		
4414	023174	047054	053454	046440		
4415	023202	046125	044524	051104		
4416	023210	053111	020105	040504		
4417	023216	040524	051040	046105		
4418	023224	040511	044502	052114		
4419	023232	020131	054105	051105		
4420	023240	044503	042523	020122		
4421	023246	042050	052132	044115		
4422	023254	042055	022451	043		
4423	023261	105	052116	051105	MSG31A: .ASCII	/%ENTER CONDITIONS IN OCTAL%%#/ /
4424	023266	041440	047117	044504		
4425	023274	044524	047117	020123		
4426	023302	047111	047440	052103		
4427	023310	046101	021445			
4428						
4429	023314	052445	044516	020124	MSG32: .ASCII	/%UNIT NUMBER = #/ /

4430	023322	052516	041115	051105			
4431	023330	036440	021440				
4432							
4433	023334	042045	047105	044523	MSG33:	.ASCII	/%DENSITY = #/
4434	023342	054524	036440	021440			
4435							
4436	023350	050045	051101	052111	MSG34:	.ASCII	/%PARITY = #/
4437	023356	020131	020075	043			
4438							
4439	023362	045	042522	047503	MSG35:	.ASCII	/%RECORD COUNT = #/
4440	023370	042122	041440	052517			
4441	023376	052116	036440	021440			
4442							
4443	023404	041445	040510	040522	MSG36:	.ASCII	/%CHARACTER COUNT = #/
4444	023412	052103	051105	041440			
4445	023420	052517	052116	036440			
4446	023426	021440					
4447							
4448	023430	050045	052101	042524	MSG37:	.ASCII	/%PATTERN NUMBER = #/
4449	023436	047122	047040	046525			
4450	023444	042502	020122	020075			
4451	023452	043					
4452							
4453	023453	045	044523	043516	MSG38:	.ASCII	/%SINGLE PASS = #/
4454	023460	042514	050040	051501			
4455	023466	020123	020075	043			
4456	023473	041	042445	042116	MSG39:	.ASCII	/%END OF PASS !!#/
4457	023500	047440	020106	040520			
4458	023506	051523	020040	020441			
4459	023514	043					
4460	023515	045	042445	052116	MSG40:	.ASCII	/%ENTER STALLS%READ = #/
4461	023522	051105	051440	040524			
4462	023530	046114	022523	042522			
4463	023536	042101	036440	021440			
4464							
4465	023544	053445	044522	042524	MSG41:	.ASCII	/%WRITE = #/
4466	023552	036440	021440				
4467							
4468	023556	052045	051125	020116	MSG42:	.ASCII	/%TURN AROUND = #/
4469	023564	051101	052517	042116			
4470	023572	036440	021440				
4471							
4472	023576	037445	021445		MSG43:	.ASCII	/%?%#/
4473							
4474	023602	042445	052116	051105	MSG44:	.ASCII	/%ENTER YOZZLE STALL = #/
4475	023610	054440	055117	046132			
4476	023616	020105	052123	046101			
4477	023624	020114	020075	043			
4478							
4479	023631	045	051105	020122	MSG45:	.ASCII	/%ERR AMT #/
4480	023636	046501	020124	043			
4481							
4482	023643	045	041527	021440	MSG46:	.ASCII	/%WC #/
4483							
4484	023650	041445	020101	043	MSG47:	.ASCII	/%CA #/
4485							

4486	020555	045	020441	047041	MSG48: .ASCII	/%!!!NO BOT ON REWIND:*/
4487	023662	020117	047502	020124		
4488	023670	047117	051040	053505		
4489	023676	047111	035104	043		
4490						
4491	023703	040	047516	020124	MSG49: .ASCII	/ NOT AVAIL */
4492	023710	053101	044501	020114		
4493	023716	043				
4494	023717	055	052067	045522	MSG50: .ASCII	/-7TRK */
4495	023724	021440				
4496	023726	034455	051124	020113	MSG51: .ASCII	/-9TRK */
4497	023734	043				
4498	023735	045	047516	035116	MSG52: .ASCII	/%NON:RETRYABLE */
4499	023742	042522	051124	040531		
4500	023750	046102	020105	043		
4501	023755	045	025052	047452	MSG53: .ASCII	/%***ORIGINAL ERROR****/
4502	023762	044522	044507	040516		
4503	023770	020114	051105	047522		
4504	023776	025122	025052	043		
4505	024003	045	042522	047503	MSG54: .ASCII	/%RECOVERED*/
4506	024010	042526	042522	021504		
4507	024016	051045	052105	054522	MSG55: .ASCII	/%RETRY: */
4508	024024	020072	043			
4509	024027	045	052523	050123	MSG56: .ASCII	/%SUSPECT BAD TAPE*/
4510	024034	041505	020124	040502		
4511	024042	020104	040524	042520		
4512	024050	043				
4513	024051	045	042522	042520	MSG57: .ASCII	/%REPEAT: */
4514	024056	052101	020072	043		
4515	024063	045	020441	052441	MSG58: .ASCII	/%!!!UNRECOVERABLE BAD SPOT*/
4516	024070	051116	041505	053117		
4517	024076	051105	041101	042514		
4518	024104	041040	042101	051440		
4519	024112	047520	021524			
4520						
4521	024116	020445	020441	040502	MSG59: .ASCII	/%!!!BAD TAPE OVERFLOW/
4522	024124	020104	040524	042520		
4523	024132	047440	042526	043122		
4524	024140	047514	127			
4525	024143	045	040524	042520	.ASCII	/%TAPE WILL BE REWOUND AND REMOVED FROM/
4526	024150	053440	046111	020114		
4527	024156	042502	051040	053505		
4528	024164	052517	042116	040440		
4529	024172	042116	051040	046505		
4530	024200	053117	042105	043040		
4531	024206	047522	115			
4532	024211	045	042524	052123	.ASCII	/%TESTING UNTIL ALL ARE RESTARTED AT BLOCK ONE.*/
4533	024216	047111	020107	047125		
4534	024224	044524	020114	046101		
4535	024232	020114	051101	020105		
4536	024240	042522	052123	051101		
4537	024246	042524	020104	052101		
4538	024254	041040	047514	045503		
4539	024262	047440	042516	021456		
4540	024270	052045	050101	020105	MSG60: .ASCII	/%TAPE MARK = */
4541	024276	040515	045522	036440		

4542	024304	021440					
4543							
4544	024306	020445	020441	040502	MSG61:	.ASCII	/%!!!BACKSPACE ERROR/
4545	024314	045503	050123	041501			
4546	024322	020105	051105	047522			
4547	024330	122					
4548	024331	045	040524	042520		.ASCII	/%TAPE WILL BE REWOUND AND REMOVED FROM /
4549	024336	053440	046111	020114			
4550	024344	042502	051040	053505			
4551	024352	052517	042116	040440			
4552	024360	042116	051040	046505			
4553	024366	053117	042105	043040			
4554	024374	047522	020115				
4555	024400	052045	051505	044524		.ASCII	/%TESTING UNTIL ALL ARE RESTARTED AT BLOCK ONE.*/
4556	024406	043516	052440	052116			
4557	024414	046111	040440	046114			
4558	024422	040440	042522	051040			
4559	024430	051505	040524	052122			
4560	024436	042105	040440	020124			
4561	024444	046102	041517	020113			
4562	024452	047117	027105	043			
4563	024457	052	042527	052040	MSG62:	.ASCII	/*WE TM*/
4564	024464	021515					
4565	024466	051452	020105	046524	MSG63:	.ASCII	/*SE TM*/
4566	024474	043					
4567	024475	045	052127	051105	MSG64:	.ASCII	/%WTERR: */
4568	024502	035122	021440				
4569	024506	051045	042504	051122	MSG65:	.ASCII	/%KDERR: */
4570	024514	020072	043				
4571	024517	045	052104	051105	MSG66:	.ASCII	/%DTERR: */
4572	024524	035122	021440				
4573	024530	021445			MSG67:	.ASCII	/%*/
4574	024532	041040	042101	052040	MSG68:	.ASCII	/ BAD TAPE SPOTS%*/
4575	024540	050101	020105	050123			
4576	024546	052117	022523	043			
4577	024553	052	042523	051040	MSG69:	.ASCII	/*SE RTY*/
4578	0245FJ	054524	043				
4579	024563	052	042522	052040	MSG70:	.ASCII	/*RE TM*/
4580	024570	021515					
4581	024572	051045	040505	020104	MSG71:	.ASCII	/%READ FAILED--RETRY: */
4582	024600	040506	046111	042105			
4583	024606	026455	042522	051124			
4584	024614	035131	021440				
4585	024620	020445	020441	040510	MSG72:	.ASCII	/%!!!HARD READ ERROR*/
4586	024626	042122	051040	040505			
4587	024634	020104	051105	047522			
4588	024642	021522					
4589	024644	051045	051105	040505	MSG73:	.ASCII	/%REREAD SUCCESSFUL--RETRY: */
4590	024652	020104	052523	041503			
4591	024660	051505	043123	046125			
4592	024666	026455	042522	051124			
4593	024674	035131	021440				
4594	024700	020045	047523	052106	MSG74:	.ASCII	/% SOFT: */
4595	024706	020072	043				
4596	024711	045	044040	051101	MSG75:	.ASCII	/% HARD: */
4597	024716	035104	021440				

4598	024722	020045	052122	054522	MSG76:	.ASCII	/% RTRY: #/
4599	024730	020072	043				
4600	024733	045	052045	026115	MSG77:	.ASCII	/%TM,A,B-11 AUTO SEQUENCE TEST (DZTMH-D)%/
4601	024740	026101	026502	030461			
4602	024746	040440	052125	020117			
4603	024754	042523	052521	047105			
4604	024762	042503	052040	051505			
4605	024770	020124	042050	052132			
4606	024776	044115	042055	022451			
4607	025004	047105	042524	020122		.ASCII	/ENTER RESPONSES IN CCTAL%#/
4608	025012	042522	050123	047117			
4609	025020	042523	020123	047111			
4610	025026	047440	052103	046101			
4611	025034	021445					
4612	025036	040445	052125	020117	MSG78:	.ASCII	/%AUTO CONT: #/
4613	025044	047503	052116	020072			
4614	025052	043					
4615	025053	045	025045	025052	MSG79:	.ASCII	/%*****%/
4616	025060	025052	025052	025052			
4617	025066	025052	025052	025052			
4618	025074	025052					
4619	025076	025052	025052	025052		.ASCII	/%*****%/
4620	025104	025052	025052	025052			
4621	025112	025052	025052	022452			
4622	025120	043					
4623	025121	125	044516	051524	MSG80:	.ASCII	/UNITS TO BE TESTED%#/
4624	025126	052040	020117	042502			
4625	025134	052040	051505	042524			
4626	025142	022504	043				
4627	025145	105	042116	047440	MSG81:	.ASCII	/END OF SEQUENCE NO. #/
4628	025152	020106	042523	052521			
4629	025160	047105	042503	020040			
4630	025166	047516	020056	043			
4631	025173	045	020441	047041	MSG82:	.ASCII	/%!!!NO DRIVES AVAILABLE FOR AUTO SEQ--HALT%#/
4632	025200	020117	051104	053111			
4633	025206	051505	040440	040526			
4634	025214	046111	041101	042514			
4635	025222	043040	051117	040440			
4636	025230	052125	020117	042523			
4637	025236	026521	044055	046101			
4638	025244	022524	043				
4639	025247	045	050114	020103	MSG83:	.ASCII	/%LPC #/
4640	025254	043					
4641	025255	045	042522	044507	MSG84:	.ASCII	/%REGISTER START = #/
4642	025262	052123	051105	051440			
4643	025270	040524	052122	036440			
4644	025276	021440					
4645	025300	053045	041505	047524	MSG85:	.ASCII	/%VECTOR ADDRESS = #/
4646	025306	020122	042101	051104			
4647	025314	051505	020123	020075			
4648	025322	043					
4649	025323	052	040520	052124	MSG86:	.ASCII	/%PATRN #/
4650	025330	047122	021440				
4651	025334	050045	042522	040515	MSG87:	.ASCII	/%PREMATURE EOT IN AUTO SEQ/
4652	025342	052524	042522	042440			
4653	025350	052117	044440	020116			

4710	026020	020441	022441	047514	MSG95: .ASCII /!!!%LOST SELECT REMOTE#/ 043
4711	026026	052123	051440	046105	
4712	026034	041505	020124	042522	
4713	026042	047515	042524	043	
4714	026047	041	020441	040445	MSG96: .ASCII !!!%ALL ARE DROPPED: END OF PASS STOP!!!#'
4715	026054	046114	040440	042522	
4716	026062	042040	047522	050120	
4717	026070	042105	020072	047105	
4718	026076	020104	043117	050040	
4719	026104	051501	020123	052123	
4720	026112	050117	020441	021441	MSG97: .ASCII /!!!%CANNOT TEST LOAD MEDIUM%#/ 043
4721	026120	020441	041445	047101	
4722	026126	047516	020124	042524	
4723	026134	052123	046040	040517	
4724	026142	020104	042515	044504	
4725	026150	046525	021445		
4726	026154	057045	021507		\$CNTG: .ASCII /%TG#/ \$MSWR: .ASCII /%%SWR= #/
4727	026160	022445	053523	036522	
4728	026166	021440			
4729	026170	020040	042516	036527	\$MNEW: .ASCII / NEW= #/
4730	026176	021440			
4731					.EVEN
4732	026200	000000			WDATA: 0 ;WRITE BUFFER
4733					
4734		032212			.+.4010
4735	032212	000000			RDATA: 0 ;READ BUFFER
4736					
4737		000001			.END

DATER1	001134	1468#	3222*	3477					
DATER2	001136	1469#							
DATER3	001140	1470#							
DATER4	001142	1471#							
DATER5	001144	1472#							
DATER6	001146	1473#							
DATER7	001150	1474#							
DATER8	001152	1475#							
DATR	013236	1714	2863	3042#					
DATRO	013254	3046#	3049						
DATO	012552	1590	2897#						
DATO9A	012602	2903#	2918	2922	2925				
DATO8	012620	2906#	2909	2911					
DATOC	012704	2916	2923#						
DATOO	012712	2926#	2934						
DATOE	012722	2928#	2933						
DATOF	012736	2930	2932#						
DAT1	012754	1591	2942#						
DAT1A	012760	2943#	2952	2975	2980	2985	2990	3016	3021
DAT1B	012764	2944#	2946						
DAT10	013074	1598	2989#						
DAT11	013104	1599	2995#						
DAT11A	013112	2997#	3000						
DAT12	013126	1600	3005#						
DAT12A	013136	3007#	3010						
DAT13	013152	1601	3015#						
DAT14	013162	1602	3020#						
DAT15	013172	1603	3025#						
DAT15A	013202	3027#	3036						
DAT15B	013206	3028#	3033						
DAT15C	013220	3030	3032#						
DAT15R	013176	3026#	3037						
DAT2	012776	1592	2951#						
DAT3	013004	1593	2956#						
DAT3A	013012	2958#	2969						
DAT3B	013016	2959#	2962						
DAT4	013032	1594	2967#						
DAT5	013044	1595	2974#						
DAT6	013054	1596	2979#						
DAT7	013064	1597	2984#						
DCHK	013712	2296	2415	3162#					
DEREX	014612	3284	3306	3309	3316	3318#			
DEREX1	014644	3319	3322	3324	3326#				
DERFL	000744	1392#	3163*	3198*	3212*	3217			
DERR	014242	3197	3211	3255#					
DERR0	014256	3256	3258#	3325					
DERR0A	014316	3260	3262	3267#					
DERR0B	014336	3272#							
DERR1	014370	3279#							
DERR2	014372	3280#							
DERR3	014376	3281#							
DERR4	014400	3257	3282#						
DERR4A	014544	3307#							
DERR4B	014556	3293	3310#						
DERR5	014576	3315#							
DERR6	014604	3296	3313	3317#					

MSG15	022526	3287	4346#			
MSG16	022556	3698	4351#			
MSG17	022564	3695	4353#			
MSG2	022433	3273	4323#			
MSG20	022572	1821	4355#			
MSG20A	022606	1827	4357#			
MSG22	022725	2270	4374#			
MSG23	022750	2484	3631	4379#		
MSG24	022757	3783	4382#			
MSG25	023007	3747	4388#			
MSG26	023113	3410	4401#			
MSG27	023124	3425	4404#			
MSG3	022440	3277	4325#			
MSG30	023135	2495	3641	4407#		
MSG31	023144	1631	2642	4410#		
MSG31A	023261	2644	4423#			
MSG32	023314	2682	4429#			
MSG33	023334	2717	4433#			
MSG34	023350	2729	4436#			
MSG35	023363	2750	4439#			
MSG36	023404	2760	4443#			
MSG37	023430	2772	4448#			
MSG38	023453	2791	4453#			
MSG39	023473	1874	4456#			
MSG4	022445	3267	4327#			
MSG40	023515	2800	4460#			
MSG41	023544	2809	4465#			
MSG42	023556	2818	4468#			
MSG43	023576	4013	4303	4472#		
MSG44	023602	2421	4474#			
MSG45	023631	2528	4479#			
MSG46	023643	3645	4482#			
MSG47	023650	3650	4484#			
MSG48	023655	1854	1944	4486#		
MSG49	023703	1735	1759	2708	4491#	
MSG5	022452	1981	2024	2179	3741	4329#
MSG50	023717	2713	4177	4494#		
MSG51	023726	2715	4174	4496#		
MSG52	023735	2022	2090	2286	4498#	
MSG53	023755	2031	2101	2340	4501#	
MSG54	024003	2126	4505#			
MSG55	024016	2128	2137	4507#		
MSG56	024027	2135	4509#			
MSG57	024051	2141	4513#			
MSG58	024063	2198	4515#			
MSG59	024116	1812	4521#			
MSG6	022457	2253	2288	3744	4331#	
MSG60	024270	2782	4540#			
MSG61	024306	1807	4544#			
MSG62	024457	2067	2092	4563#		
MSG63	024466	2466	4565#			
MSG64	024475	3449	4567#			
MSG65	024506	3459	4569#			
MSG66	024517	3474	4571#			
MSG67	024530	3487	3521	4573#		
MSG68	024532	3495	4574#			

COMMEN	10		
ENDCOM	10		
ESCAPE	10		
GETPRI	10		
GETSWR	10		
MULT	10		
NEWST	10		
POP	10		
PUSH	10		
REPORT	10		
SETPRI	10		
SETUP	10		
SKIP	10		
SLASH	10		
STARS	10	1290	
SWRSU	10		
TYPBIN	10		
TYPDEC	10		
TYPNAM	10		
TYPNUM	10		
TYPQCS	10		
TYPQCT	10		
TYPTXT	10		
SSESCA	10		
SSNEWT	10		
SSSKIP	10		
.EQUAT	10		
.HEADE	10		
.KT11	10		
.SETUP	10		
.SWRHI	10		
.SACTI	10	1220*	1289
.SAPT8	10		
.SAPTH	10		
.SAPTY	10		
.SASTA	10		
.SCATC	10		
.SCHTA	10		
.SOB2D	10		
.SOB2O	10		
.SDIV	10		
.SEOP	10		
.SERRO	10		
.SERRT	10		
.SMULT	10		
.SPOWE	10		
.SRAND	10		
.SRDDE	10		
.SROOC	10		
.SREAD	10		
.SR2AZ	10		
.SSAVE	10		
.SSB2D	10		
.SSB2O	10		
.SSCOP	10		
.SSIZE	10		

H10

ADD	1642 2303 3951 4306 3073	1683 3305 4179 4307	1720 3309 4233 4308	1772 3312	1860 3314	1920 3315	1940 3398	1953 3399	2155 3415	2157 3416	2469 3514	2511 3576	2662 3578	2744 3934	2878 3950
B5L															
BCCS															
BFC2	1629 1806 1989 2268 2522 3175 3569 3793 4230 4302	1641 1811 1997 2278 2638 3178 3572 3810 4256	1680 1816 2010 2285 2679 3189 3575 3854 4312	1692 1831 2013 2300 2712 3191 3591 3857	1698 1833 2021 2312 2725 3218 3610 3864	1710 1863 2043 2316 2737 3256 3612 3870	1713 1872 2079 2346 2743 3319 3616 3875	1716 1877 2081 2400 2860 3367 3619 3933	1719 1879 2089 2403 2870 3374 3621 3982	1727 1913 2166 2411 2918 3382 3623 4036	1732 1919 2181 2458 3084 3397 3659 4038	1740 1926 2219 2465 3108 3421 3669 4040	1755 1930 2221 2472 3115 3430 3694 4078	1763 1937 2224 2502 3126 3520 3740 4132	1801 1952 2264 2504 3169 3566 3786 4227
BGE															
BGT	2930	4300													
BH1	3293	3953	3955	3988											
BIC	1692 2868 3615 3205	1742 2890 3776 3362	1761 3077 3824 4309	1859 3079 3948	2019 3080 3916	2051 3088 3997	2087 3089 4110	2284 3122 4172	2320 3134 4231	2460 3135 4268	2501 3173 4286	2505 3176	2699 3595	2726 3602	2738 3611
BICB															
BIS	1667 3090 3214	1798 3131 4310	1835 3136	1917 3766	2003 3794	2184 3858	2255 3921	2260 3998	2265 4116	2499 4228	2517 4248	2836	2903	3074	3081
BISB															
BIT	1709 1948 2085 2299 3114 3585 3790 3177	1712 1850 2099 2338 3123 3587 3792 3356	1715 1857 2124 2347 3125 3599 3853 4131	1718 1903 2133 2360 3128 3605 3856	1724 1918 2180 2407 3168 3618 3863	1726 1929 2216 2413 3174 3668 3869	1731 1934 2218 2433 3188 3673 3887	1739 1936 2220 2471 3255 3691 3932	1754 1938 2223 2475 3285 3693 4077	1764 1951 2228 2479 3318 3734 4175	1796 1979 2263 2523 3323 3739 4226	1800 2004 2267 2704 3373 3755 4229	1805 2017 2274 2711 3381 3769	1830 2029 2281 2906 3571 3777	1845 2075 2292 3107 3574 3785
BITB															
BLO															
BLOCS	3296	3985	4002	4005											
BNT	1818	2038	2048	2307	3877	4053	4144	4148	4169						
BNE	1634 1904 2125 2361 2665 2933 3193 3525 3737 4072	1657 1935 2134 2408 2691 2946 3200 3535 3756 4074	1662 1939 2146 2414 2693 2962 3207 3581 3758 4111	1675 1980 2162 2420 2705 3000 3216 3583 3770 4113	1677 2005 2217 2434 2707 3010 3220 3586 3772 4138	1700 2018 2229 2476 2834 3030 3260 3588 3774 4176	1725 2030 2275 2478 2858 3033 3262 3597 3778 4204	1744 2040 2282 2480 2866 3049 3284 3600 3791 4238	1765 2053 2293 2493 2888 3100 3286 3604 3798 4240	1767 2076 2295 2506 2898 3106 3322 3606 3800 4266	1797 2086 2305 2524 2907 3120 3324 3639 3888 4270	1846 2100 2309 2561 2909 3124 3363 3672 3936 4288	1849 2115 2339 2628 2911 3129 3369 3674 3980 4292	1851 2120 2348 2636 2916 3171 3392 3692 4000 4296	1858 2123 2354 2647 2925 3181 3498 3735 4049
BP															
BR	2324 1643 2498 3592 4290	2418 1651 2641 3697 4298	2862 1721 2912 3743 4305	3372 1804 3182 3795 4313	3380 1809 3185 3801 4315	3614 1814 3195 3873	4025 1820 3201 4042	4028 1932 3209 4054	4061 1954 3306 4056	4130 1992 3309 4059	4146 2026 3316 4069	2117 2290 3377 4134	2290 3423 3480	2321 3432 4210	2359 3523 4257
CLC															
CLR	2831 1321 1808 2016 2297	2879 1626 1813 2033 2322	2957 1646 1842 2034 2326	3071 1648 1868 2036 2342	3075 1652 1869 2045 2368	3117 1655 1890 2046 2453	3311 1660 1891 2070 2462	3394 1666 1906 2095 2487	3492 1673 1923 2098 2515	3504 1703 1948 2104 2630	3991 1705 1982 2175 2631	3993 1707 1983 2182 2634	3995 1738 1984 2254 2684	1759 1991 1998 2256 2719	1773 1998 2257 2731

	2746	2776	2789	2886	2900	2901	2902	2904	2913	2951	2995	3045	3067	3095	3112
	3162	3163	3164	3327	3348	3349	3350	3399	3390	3486	3502	3533	3553	3573	3584
	3630	3677	3730	3750	3754	3763	3768	3796	3808	3817	3852	3862	3931	3976	3977
	4020	4021	4022	4046	4055	4070	4082	4126	4159	4181	4188	4217	4218	4219	4220
	4221	4279	4283												
CLRB	2516	3194	3208	3289											
CMP	1640	1674	1699	1743	1762	2052	2122	2161	2165	2183	2353	2664	2742	2665	2869
	2929	3295	3519	3580	3596	3603	3622	3823	3935	3952	3954	4001	4004	4237	4255
	4258	4265	4269	4295											
CMPB	1633	2419	2646	3192	3206	3281	3283	3292	3354	3809	3925	3979	3984	3987	4035
	4037	4039	4287	4291	4299	4301									
COM	1679	1681	1685	1691	1693	1701	1706	1862	1864	1866	1912	1914	1922	1925	1927
	1947	2455	2531	3078	3087	3299	3901								
DEC	1656	1661	1766	1931	2039	2068	2148	2308	2313	2530	2560	2635	2705	2833	2897
	2908	2910	2924	2932	2945	2961	2999	3009	3029	3032	3083	3099	3119	3271	3391
	3396	3420	3429	3534	3570	3771	3773	3797	3799	3900	3922	3999	4048	4137	4311
DECB	1832	3008													
HALT	1287	1886	3320	3670	3749	3787	4205	4243							
INC	1333	1696	1745	1757	1824	2001	2015	2028	2041	2069	2084	2097	2121	2160	2164
	2168	2169	2191	2280	2310	2317	2318	2337	2344	2358	2367	2404	2456	2494	2510
	2741	3048	3110	3116	3179	3180	3199	3215	3222	3258	3300	3370	3378	3601	3517
	3625	3640	3732	3736	3757	3855	3865	3891	3924	3990	4023	4115	4207	4234	4236
INCB	2998	3282	3291												
IMP	1315	1318	1322	1334	1637	1644	1647	1684	1695	1733	1737	1771	1774	1837	1656
	1865	1892	1921	1941	1946	1995	2054	2074	2163	2170	2171	2185	2194	2225	2262
	2266	2273	2327	2393	2406	2432	2520	2650	2681	2694	2697	2710	2714	2745	2881
	2922	2931	2934	2947	2952	2963	2969	2975	2980	2985	2990	3001	3011	3016	3021
	3031	3037	3085	3257	3325	3400	3577	3607	3624	3644	3675	3751	3762	3789	3827
	3929	3939	3940	3983	3986	3989	4003	4006	4076	4081	4244				
JSP	1632	1636	1650	1669	1671	1672	1678	1711	1714	1717	1723	1728	1730	1734	1736
	1746	1747	1748	1750	1751	1753	1758	1768	1770	1799	1803	1822	1826	1828	1829
	1853	1855	1875	1881	1888	1943	1945	2006	2008	2023	2025	2032	2035	2044	2077
	2091	2093	2102	2103	2113	2116	2118	2127	2129	2131	2136	2138	2140	2142	2144
	2178	2199	2222	2227	2269	2271	2276	2287	2289	2291	2296	2298	2301	2303	2341
	2343	2350	2352	2356	2363	2365	2369	2388	2395	2409	2415	2416	2422	2424	2430
	2470	2481	2483	2485	2489	2491	2496	2514	2525	2527	2529	2533	2536	2578	2596
	2640	2643	2645	2649	2652	2654	2659	2667	2669	2674	2682	2689	2701	2709	2716
	2718	2723	2728	2730	2735	2740	2751	2753	2758	2761	2764	2769	2773	2775	2781
	2783	2785	2790	2792	2794	2799	2801	2803	2808	2810	2812	2817	2819	2821	2826
	2863	2872	2883	3046	3050	3069	3070	3097	3098	3102	3196	3197	3210	3211	3223
	3263	3265	3266	3268	3272	3274	3276	3278	3280	3288	3326	3357	3358	3375	3376
	3383	3384	3408	3411	3419	3426	3428	3447	3448	3450	3453	3455	3458	3460	3463
	3465	3468	3470	3473	3475	3478	3479	3480	3488	3494	3496	3506	3509	3511	3513
	3516	3522	3526	3562	3626	3628	3629	3632	3635	3637	3642	3646	3649	3651	3653
	3655	3657	3661	3663	3665	3667	3676	3696	3699	3738	3742	3745	3746	3748	3759
	3761	3779	3781	3782	3784	3811	3815	3845	3849	3851	3859	3861	3866	3868	3872
	3879	3881	3883	3885	3892	3894	3896	3898	3902	3904	3913	3917	3919	3923	3928
	3938	3978	4014	4041	4044	4047	4051	4058	4075	4080	4083	4090	4094	4099	4104
	4106	4108	4118	4153	4155	4160	4162	4164	4166	4173	4178	4183	4189	4191	4193
MOV	4198	4200	4202	4206	4209	4225	4242	4272	4274	4276	4278	4280	4285	4294	4304
	1627	1630	1631	1635	1638	1639	1645	1649	1653	1654	1658	1659	1663	1664	1665
	1668	1670	1686	1689	1690	1694	1702	1708	1722	1729	1735	1741	1749	1752	1756
	1760	1769	1778	1779	1780	1781	1795	1802	1807	1812	1819	1821	1823	1825	1827
	1834	1839	1843	1844	1847	1852	1854	1861	1867	1874	1878	1887	1889	1908	1911
	1915	1916	1924	1928	1933	1942	1944	1949	1950	1955	1981	1985	1986	1987	1994
	1999	2002	2007	2014	2022	2024	2027	2031	2050	2067	2071	2072	2073	2083	2090

	2092	2096	2101	2112	2126	2128	2130	2135	2137	2139	2141	2143	2147	2149	2150
	2151	2153	2154	2156	2158	2167	2176	2177	2173	2190	2192	2198	2226	2252	2253
	2258	2259	2261	2270	2279	2283	2286	2288	2302	2314	2319	2340	2349	2351	2355
	2357	2366	2364	2366	2386	2387	2389	2391	2392	2394	2397	2338	2401	2405	2421
	2423	2425	2426	2427	2428	2429	2431	2435	2454	2459	2463	2466	2467	2468	2474
	2482	2484	2486	2495	2497	2509	2512	2513	2518	2519	2521	2526	2528	2532	2534
	2572	2576	2577	2579	2580	2594	2595	2597	2632	2633	2639	2642	2644	2648	2651
	2652	2655	2656	2657	2658	2660	2661	2663	2666	2668	2670	2671	2672	2673	2675
	2676	2677	2682	2685	2686	2687	2688	2695	2696	2698	2700	2702	2703	2708	2713
	2715	2717	2720	2721	2722	2727	2729	2732	2733	2734	2739	2747	2750	2752	2754
	2755	2756	2757	2759	2760	2763	2765	2766	2767	2769	2771	2772	2774	2777	2779
	2779	2780	2782	2784	2786	2787	2788	2791	2793	2795	2796	2797	2798	2800	2802
	2804	2805	2806	2807	2809	2811	2813	2814	2815	2816	2818	2820	2822	2823	2824
	2825	2825	2867	2871	2875	2876	2877	2884	2885	2899	2899	2905	2919	2920	2921
	2826	2927	2942	2943	2944	2956	2958	2967	2974	2979	2984	2989	2996	3005	3006
	3015	3020	3025	3026	3027	3029	3042	3043	3044	3047	3051	3064	3066	3076	3082
	3086	3091	3092	3094	3101	3103	3109	3113	3133	3137	3165	3166	3167	3172	3184
	3186	3187	3198	3203	3212	3221	3264	3267	3269	3273	3277	3287	3297	3298	3302
	3304	3307	3317	3351	3352	3353	3365	3385	3386	3387	3388	3402	3403	3404	3410
	3412	3413	3414	3417	3418	3424	3425	3427	3446	3449	3451	3452	3454	3456	3457
	3459	3461	3462	3464	3466	3467	3469	3471	3472	3474	3476	3477	3487	3489	3490
	3491	3495	3500	3503	3507	3510	3512	3515	3521	3531	3532	3561	3567	3579	3582
	3589	3593	3594	3598	3608	3627	3631	3633	3641	3643	3645	3647	3650	3652	3654
	3656	3660	3662	3664	3666	3678	3695	3698	3731	3741	3744	3747	3760	3767	3775
	3780	3783	3807	3814	3816	3818	3844	3846	3850	3860	3867	3871	3878	3880	3882
	3884	3886	3889	3893	3895	3897	3899	3903	3911	3912	3914	3918	3920	3927	3937
	4007	4013	4026	4045	4068	4071	4079	4084	4091	4095	4100	4105	4107	4117	4119
	4127	4133	4135	4152	4154	4156	4157	4158	4163	4165	4167	4170	4174	4177	4184
	4185	4186	4187	4190	4192	4194	4195	4196	4197	4199	4201	4208	4222	4224	4232
	4241	4245	4246	4252	4253	4254	4259	4260	4261	4262	4267	4271	4273	4275	4277
	4284	4293	4303	4314											
MOVE	1688	1841	1910	1990	1993	2390	2396	2749	2914	2923	2928	2959	2997	3007	3068
	3096	3121	3183	3204	3275	3279	3355	3356	3360	3361	3405	3406	3407	3733	4029
NEG	4034	4043	4050	4057	4062	4128	4171	4223							
NCP	2461	2762	2770	3065	3093	3564	3648								
	1882	1883	1884	1885	2272	2882	3063	3202	3213	3752	3753	3764	3765	3789	3812
	3825	3826	3910	3930											
RESET	1880														
ROL	2832	2880	3035	3992	3994	3996	4096	4097	4136						
ROLB	2936														
ROR	3072	3118	3493	3505	4085	4086	4087	4088	4092	4101	4102	4103			
RORB	3395														
RTY	3813	3819													
RTS	1704	1782	1873	1905	1956	2011	2049	2082	2094	2105	2132	2186	2200	2230	2328
	2370	2412	2436	2473	2500	2537	2562	2581	2598	2629	2827	2837	2864	2873	2891
	3052	3104	3111	3127	3130	3132	3138	3224	3328	3359	3364	3393	3401	3409	3433
	3481	3499	3527	3536	3679	3700	3905	3956	4008	4016	4030	4063	4109	4114	4120
	4139	4149	4249	4263	4281										
SEC	2968	3034													
SUB	2000	2159	2508	3270	3301	3422	3431	3517	3890	4015					
SWAB	1687	1838	1840	1907	1909	2488	2490	2748	3290	3294	3310	3634	3636	3847	3915
	4089	4093	4098	4247											
TST	1628	1676	1697	1810	1815	1817	1836	1870	1871	1876	1988	1996	2009	2012	2020
	2037	2042	2047	2078	2080	2088	2114	2119	2145	2152	2193	2277	2294	2304	2306
	2311	2315	2323	2325	2345	2399	2402	2410	2457	2464	2477	2492	2503	2627	2637
	2678	2680	2690	2692	2724	2736	2857	2859	2861	2897	2915	3105	3170	3190	3217

K10

TM A.B-11 T503 OR TUIO N.W. MULTIDRIVE DATA RELIABILITY EXERCISER
 DZTMHD.P11 CROSS REFERENCE TABLE -- PERMANENT SYMBOLS

MACY11 27(732) 04-NOV-76 11:29 PAGE 131

	3219	3259	3261	3321	3371	3379	3497	3501	3518	3524	3565	3568	3590	3609	3613
	3620	3638	3658	3671	3874	3876	3981	4073	4112	4143	4145	4147	4168	4203	4239
	4289	4297													
TSTB	2417	2917	3368	3508	4024	4027	4052	4060	4129						
.ASCII	4321	4323	4325	4327	4329	4331	4333	4335	4337	4341	4344	4346	4351	4353	4355
	4357	4362	4366	4374	4379	4382	4388	4394	4401	4404	4407	4410	4423	4429	4433
	4436	4439	4443	4448	4453	4456	4460	4465	4468	4472	4474	4479	4482	4484	4486
	4491	4494	4496	4498	4501	4505	4507	4509	4513	4515	4521	4525	4532	4540	4544
	4548	4555	4563	4565	4567	4569	4571	4573	4574	4577	4579	4581	4585	4589	4594
	4596	4598	4600	4607	4612	4615	4619	4623	4627	4631	4639	4641	4645	4649	4651
	4656	4663	4668	4671	4680	4681	4682	4686	4692	4697	4704	4710	4714	4721	4725
	4727	4729													
.ENABL	1	1219													
.END	4737														
.ENDC	1291	1295	1297												
.EVEN	1609	4731													
.IF	1290	1293	1295												
.IFF	1291	1295	1297												
.LIST	1	1287													
.MACRO	1														
.MCALL	1220														
.NLIST	1	1287													
.REM	1														
.REPT	1287														
.SBTTL	1288														
.TITLE	1215														
.WORD	1296														

ERRORS DETECTED: 0
 DEFAULT GLOBALS GENERATED: 0

*, DZTMHD.SEQ/SOL/CRF/PAGNUM/NL:TOC=DZTMHD.SML, DZTMHD.P11
 RUN-TIME: 32 47 7 SECONDS
 RUN-TIME RATIO: 341/87=3.8
 CORE USED: 33K (65 PAGES)

