

# DH11/VT20

HOST COMPUTER PROGRAM  
MD-11-DZVTG-A

EP-DZVTG-A-DL  
COPYRIGHT © 1975  
FICHE 1 OF 1

JUN 1978  
**digital**  
MADE IN USA



IDENTIFICATION  
\*\*\*\*\*

SEC 0001

PRODUCT CODE: MAINDEC-11-0ZVTG-A-D  
PRODUCT NAME: DM11/VT20 HOST COMPUTER PROGRAM  
DATE: OCTOBER, 1975  
MAINTAINER: DIAGNOSTIC GROUP  
AUTHOR: E. BOUSE/P. NELSON

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS MANUAL.

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED TO THE PURCHASER UNDER A LICENSE FOR USE ON A SINGLE COMPUTER SYSTEM AND CAN BE COPIED (WITH INCLUSION OF DIGITAL'S COPYRIGHT NOTICE) ONLY FOR USE IN SUCH SYSTEM, EXCEPT AS MAY OTHERWISE BE PROVIDED IN WRITING BY DIGITAL.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

COPYRIGHT (C) ,1975 BY DIGITAL EQUIPMENT CORPORATION.

## TABLE OF CONTENTS

1. ABSTRACT
2. REQUIREMENTS (EQUIPMENT & MEMORY)
3. LOADING PROCEDURE
4. STARTING PROCEDURE
5. PROGRAM ACTION
6. MONITOR COMMANDS
7. ERROR REPORTING
8. DATA FORMAT
9. DISPLAY REGISTER OPTION
10. LISTING

## 1. ABSTRACT

\*\*\*\*\*

THIS PROGRAM IS A COMBINATION DM11 DIAGNOSTIC AND DATA HANDLING ROUTINE. IT IS USED IN CONJUNCTION WITH MAINDEC-11-DBVTA (VT20 SYSTEM DIAGNOSTIC), TEST 21. THE PROGRAM IS COMPLETELY OPERATOR INTERACTIVE BY MEANS OF A CONSOLE DEVICE AND WILL RESPOND TO ANY OPERATOR INPUTS. BY MEANS OF THE CONSOLE DEVICE, TRANSMITTER & RECEIVER LINES CAN BE VERIFIED, SPECIFIED LINES CAN BE HELD FROM TRANSMITTING, RECEIVER BUFFERS CAN BE EXAMINED, DATA CAN BE ORIGINATED AND TRANSMITTED, AND SYSTEM STATUS MONITORED. THE PROGRAM ALSO HAS A PROVISION TO BOOT (TRANSFER) PROGRAMS I.E. VT20 DIAGNOSTIC, FROM THE HOST READER TO ANY SPECIFIED VT20 SYSTEM.

THE PROGRAM HAS BEEN WRITTEN TO EXERCISE ALL 16 DM11 LINES SIMULTANEOUSLY. THE BAUD RATE OF EACH LINE IS USER SELECTABLE AND IS SETUP ON PROGRAM INITIALIZATION.

ALL LINE NUMBERS ARE TO BE ENTERED AS DECIMAL VALUES. THE PROGRAM WILL RESPOND TO ALL ILLEGAL INPUTS BY TYPING '?'. THIS INDICATES THAT THE PREVIOUSLY INPUTTED CHARACTER WAS IGNORED. USE (CR) TO TERMINATE ALL INPUTS. RUBOUT MAY BE USED TO DELETE PREVIOUSLY INPUTTED CHARACTERS WHEN ENTERING ADDRESSES AND LINE NUMBERS. THE RUBOUT WILL HAVE NO EFFECT IN THE SEND MODE (REFER TO 6.J).

## 2. REQUIREMENTS (EQUIPMENT &amp; MEMORY)

\*\*\*\*\*

- A. ANY PDP-11 FAMILY COMPUTER WITH A KW11 LINE CLOCK, A CONSOLE DEVICE AND AT LEAST 4K OF MEMORY. THIS IS THE MINIMUM CONFIGURATION TO SUPPORT TESTING OF TWO VT20 SYSTEMS. THEREAFTER, AT LEAST 1K OF ADDITIONAL MEMORY IS REQUIRED FOR EACH VT20 SYSTEM TO BE TESTED.

## 3. LOADING PROCEDURE

\*\*\*\*\*

- A. USE STANDARD PROCEDURE FOR LOADING BINARY TAPES.

#### 4. STARTING PROCEDURE \*\*\*\*\*

LOAD AND START PROGRAM AT LOCATION 200. THE PROGRAM WILL RESPOND BY TYPING THE PROGRAM HEADER AND THEN ASK FOR THE DM11 'SCR' ADDRESS.

1. RESPOND WITH (CR) IF A DEFAULT ADDRESS OF 160020 IS TO BE USED.
2. OTHERWISE, RESPOND WITH THE ADDRESS OF THE DM11 'SCR' ADDRESS TO BE USED.

#### 5. PROGRAM ACTION \*\*\*\*\*

AFTER RECEIVING THE DM11 'SCR' ADDRESS, THE PROGRAM VALIDATES THAT THE 'SCR' ADDRESS IS PRESENT AND THEN MAPS THE DM11 VECTOR ADDRESSES AND SETS UP THE SERVICE ROUTINES. ANY ERRORS ENCOUNTERED WHILE MAPPING THE DM11 WILL RESULT IN AN ERROR PRINTOUT. THESE ARE CONSIDERED 'FATAL ERRORS' AND MUST BE CORRECTED BEFORE THE PROGRAM WILL CONTINUE.

THE PROGRAM ALSO CHECKS THAT THE KM11 LINE CLOCK IS AVAILABLE I.E. RETURNS A SLAVE SYNC WHEN ADDRESSED. IF THE LINE CLOCK DOESN'T RESPOND, THE FOLLOWING MESSAGE WILL BE PRINTED: "NO SLAVE SYNC RETURNED ADDRESSING THE KM11 LINE CLOCK. THIS PROGRAM WILL RUN WITHOUT IT BUT ALL SYSTEM ERRORS MAY NOT BE REPORTED".

THE PROGRAM THEN REQUESTS AND SETS UP THE BAUD RATE FOR EACH LINE. IF AN ILLEGAL BAUD RATE IS ENTERED, IT WILL BE IGNORED AND THE LINE NUMBER WILL BE PRINTED AGAIN. ALL UNUSED LINES SHOULD BE ENTERED AS '0' BAUD TO AVOID ERRONEOUS ERRORS.

AFTER ACCEPTING THE LINE BAUD RATES, EACH ACTIVE LINE, DEFINED BY THE USER, IS THEN TESTED. THIS TESTING INVOLVES SETTING THE MAINTAINANCE BIT (9) AND THEN TRANSMITTING A '125'. A CHECK IS THEN MADE THAT A TRANSMITTER AND RECEIVER INTERRUPT OCCURRED AND THAT THE '125' WAS RECEIVED CORRECTLY. THE PROGRAM THEN PRINTS A 'DOT' THIS INDICATES THAT THE PROGRAM HAS ENTERED THE MONITOR MODE.

IN THE MONITOR MODE, THE PROGRAM IS READY TO AUTOMATICALLY RECEIVE AND TRANSMIT DATA RECEIVED FROM ANY INITIALIZED VT20 SYSTEM. ALSO IN THE MONITOR MODE, THE PROGRAM RUNS BACKGROUND JOBS OF PRINTING ERRORS, KEEPING ACCOUNT OF SYSTEM STATUS AND EXECUTING OPERATOR REQUESTS.

## 6. MONITOR COMMANDS

\*\*\*\*\*

THERE ARE SEVERAL MONITOR COMMANDS WHICH ENABLE THE OPERATOR TO CONTROL AND COMMAND THE PROGRAM. THERE ARE TWO TYPES OF COMMANDS: MONITOR RESPONSE COMMANDS I.E. "A,"C,"D,"E,"O&T AND & LINE DEPENDANT COMMANDS. I.E. "B,"H,"L,"R,"S & "X. ON RECEIPT OF A MONITOR RESPONSE COMMAND, THE PROGRAM WILL IMMEDIATELY EXECUTE THE COMMAND. ON RECEIPT OF A LINE DEPENDENT COMMAND THE PROGRAM WILL WAIT FOR A LINE NUMBER AND A CARRIAGE RETURN (CR) BEFORE EXECUTING THE COMMAND. THE FORM OF THIS TYPE OF COMMAND IS "COMMAND & LINE NO. (CR)". IN SOME CASES, THE COMMAND WILL ALLOW FOR MULTIPLE LINE NUMBERS TO BE ACCEPTED. IN THESE CASES THE LINE NUMBERS ARE TO BE SEPERATED BY COMMAS AND TERMINATED BY (CR). AN EXAMPLE WOULD BE: "V0,4,6,7(CR)". ON RECEIPT OF THIS COMMAND, LINES 0,4,6 & 7 WOULD BE VERIFIED (REFER TO THE "V COMMAND SECTION 6.V).

THE OMISSION OF A LINE NUMBER I.E. (CR) ONLY, WILL RESULT IN LINE '0' BEING SERVICED. IN ALL CASES, THE LINE NUMBERS MAY BE INPUTTED IN ANY ORDER. ALL CONTROL CHARACTERS I.E. "A,"B ETC. ARE OBTAINED BY TYPING THE 'CNTRL & CHARACTER SPECIFIED' KEYS SIMULTANEOUSLY.

## A. "A (ABSOLUTE SYSTEM RESTART)\*

ONE RECEIPT OF THIS COMMAND, THE PROGRAM WILL BE RESTARTED. THIS WILL ENABLE FOR A NEW DM11 'SCR' DEVICE ADDRESS AND NEW BAUD RATES TO BE ENTERED.

## B. "B (BOOT SELECTED LINES)\*

THE PURPOSE OF THIS COMMAND IS TO BOOT A ROUTINE FROM THE READER OF THE HOST COMPUTER TO SELECTED VT20 SYSTEMS. UPON RECEIPT OF THE ("B), THE PROGRAM WILL WAIT FOR THE LINE OR LINES NUMBERS OVER WHICH THE PROGRAM IS TO BE TRANSFERED. AFTER RECEIVING THE LINE NUMBER(S), THE PROGRAM WILL REQUEST THE READER DEVICE & VECTOR ADDRESSES. THIS QUESTION WILL ONLY BE ASKED ON THE INITIAL USE OF THE BOOT ROUTINE, HOWEVER THESE ADDRESSES CAN BE CHANGED BY TYPING A ("E). THEN ON THE NEXT OCCURANCE OF THE ("B) COMMAND, A NEW READER DEVICE ADDRESS WILL BE REQUESTED.

IN ORDER FOR PROGRAMS TO BE BOOTED TO A SELECTED VT20 SYSTEM, THE BOOTSTRAP LOADER (SEE NOTE 2) IN THE PDP-11/05 OF THE VT20 MUST BE MODIFIED. THIS WILL ENABLE THE PDP-11 TO ACCEPT THE BOOTED PROGRAM. TO DO THIS, SIMPLY REPLACE THE PC11 OR TTY 'CSR' ADDRESS IN LOCATION '37776' WITH A DL11 'CSR' ADDRESS OF EITHER '175610 OR 175620'. THE ABSOLUTE LOADER WILL BE THE FIRST PROGRAM BOOTED (UNLESS A B792YL IS PRESENT) AND AFTER THE SUCCESSFUL COMPLETION OF THE ABSOLUTE BOOT (37500 FOR AN 8K COMPUTER, ETC). THE BOOT ROUTINE IS CAPABLE OF BOOTING ALL '16' DM LINES SIMULTANEOUSLY. IF A BM792YK BOOT IS UTILIZED ONLY THE EVEN# LINES (175610 ADDRESS) CAN BE UTILIZED FOR THE BOOT OPERATION, HOWEVER NO PROGRAM MODIFICATION IS REQUIRED.

NOTE1: BEFORE BOOTING ANY PROGRAMS, INCLUDING THE ABSOLUTE LOADED, NOTE2: SUCCESSFUL BOOT OPERATION WILL BE INDICATED BY A HALT THE VT20 BOOTED. THE LINE (S) TO BE BOOTED SHOULD FIRST BE VERIFIED (REFER TO "V COMMAND).

C. "C (CLEAR SOFTWARE SWITCHES EXIT PRESENT MODE)\*

THIS COMMAND CAN BE EXECUTED AT ANYTIME TO TERMINATE OPERATOR REQUESTS I.E. SEND, HOLD, BOOT MODES ETC., AND RESET THE SYSTEM STATUS TO A KNOWN STATE. THE ("C) WILL NOT EFFECT THE STATE OF ACTIVE RECEIVERS AND TRANSMITTERS. HOWEVER, ALL LINES THAT WERE BEING HELD, REMAIN HELD UNTIL RELEASED BY THE ("R) COMMAND.

D. "D (PRINT RECEIVED DATA)

THIS COMMAND ENABLES ALL DATA BEING RECEIVED BY THE HOST PROGRAM, REGARDLESS OF LINE NUMBER, TO BE PRINTED. THIS IS A DOUBLE FUNCTION COMMAND WHICH ON THE FIRST RECEIPT OF ("D) WILL ENABLE THE DIAGNOSTIC MODE. THIS WILL RESULT IN THE MESSAGE "DIAGNOSTIC MODE ENABLE" TO BE TYPED. ON THE SECOND RECEIPT OF A "D", THE DIAGNOSTIC MODE WILL BE DISABLED.

THE USE OF THIS COMMAND SHOULD BE RESTRICTED TO RUNNING ONE LINE AND THEN ONLY IF THERE ARE NO ERRORS BEING REPORTED BY THAT LINE. IT IS RECOMMENDED THAT THE ("P) FEATURE BE USED IN LIEU OF THE DIAGNOSTIC MODE IF MULTIPLE LINES ARE BEING EXERCISED.

E. "E (ESCAPE RESTART/REINITIALIZE HARDWARE AND SOFTWARE)\*

THIS COMMAND IS TO BE USED IF MULTIPLE RECEIVER AND/OR TRANSMITTER ERRORS ARE BEING REPORTED AND THE USE OF ("C) HAS NO APARENT EFFECT. ON RECEIPT OF A ("E), ALL SYSTEM SOFTWARE AND HARDWARE FLAGS ARE RESET. THIS WILL RESULT IN TERMINATING THE OPERATION OF ANY LINES WHICH WERE ACTIVE UPON THE RECEIPT OF THE ("E). HENCEFORTH, ALL VT20 SYSTEMS WILL HAVE TO BE REINITIALIZED. THIS COMMAND WILL ALSO RE-INITIALIZE THE DM11 AND RESET THE MONITOR TRANSFER AND ERRORS COUNTERS. THESE ARE THE COUNTS DISPLAYED WHEN LISTING MONITOR STATUS (REFER TO "L).

## F. "H (HOLD SELECTED LINES)"

THIS COMMAND WILL ENABLE FOR A SELECTED LINES' BUFFER TO BE HELD FROM BEING TRANSMITTED. THE COMMAND MAY BE USED SOLELY TO HOLD LINE TRANSMISSION OR USED IN CONJUNCTION WITH THE ("S) FEATURE. THIS WILL ENABLE A USER TO CREATE A BUFFER WHICH CAN BE RELEASED, ON COMMAND, IN A BURST AT TRANSMITTER BAUD RATE. REFER TO THE MONITOR COMMAND ("S) FOR INSTRUCTIONS ON CREATING THIS BUFFER. THIS COMMAND WILL FACILITATE HOLDING UP TO '16' DM LINES SIMULTANEOUSLY IN ANY ORDER. THE LINES CAN THEN BE RELEASED (REFER TO "R) INDIVIDUALLY OR SIMULTANEOUSLY.

## G. "L (LIST SELECTED LINE STATUS)

THIS COMMAND WILL ENABLE FOR THE CURRENT SYSTEM STATUS TO BE MONITORED. THE ("L) OPTION CAN BE USED IN ONE OF TWO WAYS: (1) TYPE "L(CR)" TO PRINT THE STATUS OF ALL DM11 LINES. (2) TYPE "L & LINE NO., LINE NO.,(CR)" TO PRINT THE STATUS OF SPECIFIED LINE(S). THE FOLLOWING IS AN EXAMPLE AND EXPLANATION OF THE MONITOR PRINTOUT. REFER TO SECTION 7.(ERRORS) FOR A FURTHER EXPLANATION OF THE ERROR DATA.

## EXAMPLE:

LINE	IN	OUT	OR	PAR.	FRAM	TRAN	ST.	HELD	PEND	BAUD
A	B	C	D	E	F	G	H	I	J	K

A# NO. OF LINE BEING MONITORED  
 B# NO. OF BLOCKS OF DATA RECEIVED  
 C# NO. OF BLOCKS OF DATA TRANSMITTED  
 D# NO. OF OVERRUN ERRORS INCURRED  
 E# NO. OF PARITY ERRORS INCURRED  
 F# NO. OF FRAMING ERRORS INCURRED  
 G# NO. OF ILLEGAL TRANSMITTER INTERRUPTS INCURRED.  
 H# NO. OF ILLEGAL START CODES INCURRED.  
 I# TO '1' IF LINE IS CURRENTLY BEING HELD.  
 J# TO '1' IF A HELD LINE HAS DATA PENDING  
 K# TO THE LINE BUAD RATE SELECTED BY THE USER

## H. "P (PRINT SELECTED LINE BUFFER)

THIS COMMAND IS USED TO PRINT THE CONTENTS OF A SELECTED LINES' BUFFER. IT SHOULD BE NOTED THAT THE START CODE (377) IS DETECTED AND PRINTED AS AN UP-ARROW (^). THE EOP CODE (14) IS ALSO DETECTED AND IS PRINTED AS "(EOP)". UPON COMPLETION OF PRINTING A BUFFER OR IF THE BUFFER IS EMPTY, A DOT WILL BE PRINTED INDICATING A RETURN TO THE MONITOR. THIS COMMAND SUPERCEDES "D AND AUTOMATICALLY EXITS THE 'PRINT RECEIVED DATA MODE.'



## I. "R (RELEASE SELECTED LINES)\*

THIS COMMAND IS USED TO RELEASE LINES THAT WERE HELD USING THE ("H) FEATURE. LINES MAY BE RELEASED IN ANY ORDER AND EITHER INDIVIDUALLY OR COLLECTIVELY. THE ("L) COMMAND CAN BE USED TO DETERMINE IF A SELECTED LINE IS BEING HELD. THE ("R) COMMAND WILL FACILITATE RELEASING UP TO 16 LINES SIMULTANEOUSLY.

## J. "S (SEND FOLLOWING DATA TO SELECTED LINES VT20 SW00=1)\*

THIS COMMAND IS USED TO SEND DATA, ORIGINATED ON THE HOST CONSOLE DEVICE, TO SELECTED TRANSMITTER LINE(S). IN THIS MODE, AS EACH CHARACTER IS RECEIVED IT IS STORED IN THE RESPECTIVE LINE(S) DATA BUFFER. UP TO 384 CHARACTERS MAY BE INPUTTED. AFTER THE DESIRED BUFFER HAS BEEN CREATED, TYPE (ALT). THIS WILL RESULT IN THE SEND MODE BEING TERMINATED AND THE RESPECTIVE LINE(S) TRANSMITTERS BEING ACTIVATED. AN ALTERNATE TO THIS IS TO HOLD SELECTED LINES AND THEN RELEASE THEM ON COMMAND. THIS IS DONE USING THE ("H) FEATURE TO HOLD SELECTED LINE(S) AND THEN ENTERING THE ("S) MODE. WHEN THE DESIRED BUFFER HAS BEEN CREATED, EXIT THE ("S) MODE BY TYPING (ALT). THE PROGRAM WILL RESPOND BY A DOT, INDICATING A RETURN TO THE MONITOR. THE DATA BUFFER(S) CAN THEN BE PRINTED (REFER TO "P) AND/OR RELEASED (REFER TO "R).

WHEN USING THE ("S) FEATURE, SW00 MUST BE SET TO A "1" (UP) ON THE VT20 SYSTEM RECEIVING THE DATA. OTHERWISE, THE DATA WILL LOOK AND BE HANDLED AS DATA, OR RECEIVER ERRORS. THIS SWITCH SHOULD BE RESET (DOWN) WHEN NOT USING THE SEND MODE.

K. **"V**(VERIFY SELECTED LINES IF VT20 IS CYCLING TST21, SW00,01=1)\*

THIS COMMAND IS DEFINITELY THE MOST USEFUL AND BENEFICIAL COMMAND THAT THE OPERATOR CAN USE TO BRING UP A VT20 SYSTEM. IT IS USED TO VERIFY THAT A SELECTED DL11 LINE OR LINES ARE FUNCTIONING (I.E. TRANSMITTING & RECEIVING). TO USE THIS ROUTINE, TYPE **"V** LINE NO., LINE NO.,... (CR). THE SELECTED LINE (S) WILL THEN HAVE A CODE OF '125' TRANSMITTED OVER THEM (REFER TO NOTE). A CHECK IS THEN MADE THAT ALL LINE RECEIVERS RESPONDED WITH THE CORRECT DATA. THIS CODE IS TRANSMITTED '5' TIMES PER LINE AND THEN THE MESSAGE: "LINE XXX VERIFIED OK" IS PRINTED. IF A LINE FAILS TO RESPOND, THE MESSAGE: "LINE XXX NO VERIFY DATA RETURNED" IS PRINTED. IF A LINE RESPONDS BUT THE DATA IS INVALID, THE MESSAGE: "LINE XXX VERIFY DATA ERROR, SENT-125 RECV'D -XXX" IS PRINTED. THE DATA IS THEN RE-TRANSMITTED AND AGAIN VERIFIED. THIS WILL CONTINUE UNTIL A **"C"** IS TYPED BY THE OPERATOR TO TERMINATE THE TEST, OR '5' SUCCESSFUL DATA CODES ARE RECEIVED.

NOTE: IN ORDER FOR THIS TEST TO FUNCTION, EITHER **"TST21"** OF THE VT20 DIAGNOSTIC (MAINDEC-11-DBVTA) MUST BE LOADED AND RUNNING WITH **"SW00 & SW01"** SET OR THE FOLLOWING DL11 ECHO PATCH ROUTINE MUST BE TOGGLED INTO THE VT20 SYSTEM UNDER TEST.

1000/	105737 1756X0	TSTB @DLRCR	;WAIT FOR DATA
1004/	100375	BPL .-4	
1006/	113737 1756Y2 1756N6	MOVB @DLRBUF,@DLXBUF	;ECHO CHAR.
1014/	771	BR .-14	;WAIT NEXT CHAR.

WHERE: X= ADDRESS OF SELECTED DL11 RECEIVER CONTROL STATUS REGISTER  
 Y= ADDRESS OF SELECTED DL11 RECEIVER DATA BUFFER REGISTER  
 N= ADDRESS OF SELECTED DL11 TRANSMITTER DATA BUFFER REGISTER

NOTE: IF TEST 21 IS USED, ALL TUBES TO BE VERIFIED MUST BE CLEARED OF ANY PRIOR ACTIVITY (CONTROL C OR CONTROL E).

L. **"X** (TRANSMIT ON SELECTED LINES)

THIS COMMAND FORCES A CONTINUOUS TRANSMISSION OF THE CODE 125 OCTAL ON THE LINES SPECIFIED. ALL DATA ERRORS INTO THE MOST ARE IGNORED ALTHOUGH, IF TEST 21 OF DBVTA IS RUNNING WITH SW0 & 1 SET, IN THE VT200<sup>0</sup> CONNECTED TO THE LINES SELECTED, ALL TRANSMISSION ERRORS WILL BE COUNTED AND RECEIVE DATA DISPLAYED. THIS COMMAND IS DESIGNED TO BE A TOOL TO AID IN THE INSTALLATION AND INITIAL LINE CHECK-OUT AND TROUBLE-SHOOTING. THIS COMMAND MUST BE EXITED VIA **"E** ONLY!

M. AUXILIARY COMMANDS

**"O** (INHIBIT A PRINTOUT) - INHIBITS THE PRINTING OF ONE MESSAGE ONLY. THIS WOULD EITHER BE THE MESSAGE CURRENTLY PRINTING OR THE NEXT MESSAGE WHICH WAS TO BE PRINTED.

**"T** (INHIBIT ALL ERROR PRINTOUTS) - ALLOWS CONTROL OF THE

PRINTING OF ERRORS. FIRST CONTROL T DISABLES ERROR PRINTOUT AND SECOND CONTROL T RE-ENABLED ERROR PRINTOUTS. CONTROL A AND CONTROL C WILL BOTH CAUSE RE-ENTRY INTO THE ERROR PRINTING MODE.

- \* THESE COMMANDS SHOULD BE PRECEDED BY A CONTROL C OR E AT THE VT20'S TO BE TESTED TO AVOID MISLEADING ERROR PRINTOUTS.

## 7. ERROR REPORTER

\*\*\*\*\*

THE PROGRAM HANDLES ERRORS IN TWO PHASES (1) FATAL ERRORS (INCURRED WHILE MAPPING THE DH11 ADDRESS AND VECTORS) AND (2) NON-FATAL SYSTEM ERRORS (INCURRED WHILE RECEIVING AND TRANSFERRING DATA). FATAL ERRORS MUST BE CORRECTED BEFORE THE PROGRAM WILL CONTINUE.

### A. FATAL ERRORS

THESE ERRORS CAN RESULT FROM THE USER ENTERING ILLEGAL DEVICE ADDRESS OR SIMPLY BY HAVING A BAD DH11 PRESENT. FATAL ERRORS OF THIS NATURE WILL RESULT IN ONE OF TWO TYPEOUTS:

#### 1. "THAT DH11 ADDRESS IS NOT PRESENT"

THIS PRINTOUT WILL RESULT IF THE ADDRESS ENTERED BY THE USER DIDN'T RETURN A 'SLAVE SYNC' WHEN ADDRESSED.

#### 2. "NO INTERRUPT RESPONSE FROM DEVICE NNNNNN"

THIS PRINTOUT WILL RESULT AFTER MAPPING IF THE DH11 RECEIVER FAILS TO INTERRUPT WHEN ENABLED.

### B. SYSTEM ERRORS

SYSTEM ERRORS ARE HANDLED AS BACKGROUND JOBS. WHEN AN ERROR IS INCURRED IT IS CATEGORIZED BY GIVING IT A UNIQUE NUMBER AND PUSHED INTO AN ERROR BUFFER.

THESE ERRORS ARE THEN PRINTED (IN THE ORDER OF INCURRENCE) BY THE MONITOR. A MAXIMUM OF SIX(6) ERRORS PER/LINE, REGARDLESS OF TYPE, ARE SAVED IN THE ERROR BUFFER AND PRINTED. THE SYSTEM DOES, HOWEVER, KEEP A RUNNING COUNT OF ALL ERRORS. THIS INFORMATION CAN BE ACCESSED BY USE OF THE (L) COMMAND. THESE ERROR COUNTERS ARE RESET ONLY ON SYSTEM START UP AND BY THE (E) & (A) COMMANDS. EACH ERROR PRINTOUT WILL CONSIST OF THE LINE NUMBER AND A MESSAGE DESCRIBING THE ERROR TYPE.

FOLLOWING IS A LIST AND DESCRIPTION OF THE POSSIBLE ERROR MESSAGES THAT MAY OCCUR:

1. ILLEGAL NON-EX MEMORY INTERRUPT

THIS ERROR WILL RESULT IF THE NPR HARDWARE PLACES THE ADDRESS OF A MEMORY LOCATION ON THE UNIBUS AND NO SLAVE SYN IS RECEIVED IN 20USEC.

2. "ILLEGAL TRANS. INTERRUPT"

THIS ERROR WILL RESULT IS THE LINE RECEIVER IS ACTIVE AND A TRANSMITTER INTERRUPT IS SERVICED.

3. "OVERRUN ERROR"

4. "FRAMING ERROR"

5. "PARITY ERROR"

6. "ILLEGAL START CODE"

THIS ERROR IS A RESULT OF THE FIRST CHARACTER RECEIVED, OTHER THAN A NULL CODE, NOT BEING '377'. (REFER TO DATA FORMAT, SECTION 8., FOR A FURTHER EXPLANATION.)

7. "ILLEGAL READER INTERRUPT"

8. "ATTEMPT TO RECEIVE WHILE IN SEND MODE"

THIS MESSAGE IS PRINTED IF DATA IS RECEIVED FROM THE VT20 ON THE SAME LINE AS THE USER HAS SPECIFIED TO BE USED AS A "SEND" DATA LINE.

9. "VERIFY CHECK OK"

THIS MESSAGE IS PRINTED AFTER 'S' SUCCESSFUL TRANSMIT/RECEIVE OPERATIONS HAVE BEEN COMPLETED WHEN VERIFYING A LINE.

10. "DATA VERIFY ERROR, SENT-125 RECV'D-XXX"

IF THIS ERROR OCCURS, THE VERIFY CODE (125) WILL BE RE-TRANSMITTED. THIS WILL CONTINUE UNTIL EITHER 'S' SUCCESSFUL TRANSMIT/RECEIVE OPERATIONS HAVE BEEN COMPLETED OR A (^C) IS TYPED TO TERMINATE THE VERIFY TEST.

**11. "NO VERIFY DATA RETURNED"**

IF THIS ERROR OCCURS, NO FURTHER ATTEMPT IS MADE TO RE-TRANSMIT THE DATA, AND THE VERIFY TEST THAT PARTICULAR LINE IS ABORTED.

**12. "NO TRANSMITTER INTERRUPTS OCCURRING"**

THIS MESSAGE IS PRINTED IF NO TRANSMITTER INTERRUPT IS OCCURRED WHEN THE PROGRAM ATTEMPTS TO CHECK THE RECEIVER TRANSMITTER LOGIC. THIS CHECK IS MADE BY SETTING THE MAINTENANCE BIT (9) AND TRANSMITTING A CHARACTER (129).

IT SHOULD BE NOTED AGAIN, THAT IS CHECK IS AUTOMATICALLY PERFORMED BY THE PROGRAM AFTER THE BAUD RATES HAVE BEEN SET UP, AND ARE NOT OPERATOR DEPENDANT. THIS CHECKING TAKES PLACE EVERYTIME A ("E OR "A) IS TYPED.

**13. "NO RECEIVER INTERRUPTS OCCURRING"**

THIS ERROR IS ASSOCIATED WITH THE AUTOMATIC CHECKING OF THE RECEIVER AND TRANSMITTER AS DESCRIBED ABOVE. IN THIS CASE THOUGH, NO RECEIVER INTERRUPT OCCURRED FROM THE DESCRIBED CHECK.

IF THIS ERROR IS DETECTED, THE USER SHOULD TYPE A ("E). THIS WILL CAUSE THE SEQUENCE WHICH CAUSED THE ERROR TO BE REPEATED. IF THE ERROR RE-OCCURS, THEN THE DM11 DIAGNOSTICS SHOULD BE LOADED. IF THE USER ATTEMPTS TO CONTINUE RUNNING THE PROGRAM AFTER ENCOUNTERING THIS ERROR, THE PROGRAM MAY HANG.

**14. "DATA CHECK ERROR, SENT -125 RECV'D -XXX"**

THIS ERROR IS ALSO ASSOCIATED WITH THE AUTOMATIC CHECKING SEQUENCE. ONLY IN THIS CASE, THE DATA RECEIVED ON THE CHECK WAS NOT THE CODE TRANSMITTED (377).

**8. DATA FORMAT**

\*\*\*\*\*

ALL DATA RECEIVED FROM THE VT20 SYSTEMS IS SPECIALLY FORMATTED. THIS FORMAT IS CHECKED AND TRANSMITTED EXACTLY AS IT WAS RECEIVED. THE FORMAT OF THIS DATA IS: 4 NULL CHARACTERS (000), A START CODE(377), DATA (UP TO 384 CHARACTERS ORIGINATED BY USER), AND A EOP (END OF PARAGRAPH CODE=14).

NOTE - THE DATA ORIGINATED FROM A VT20 MAY BE IN ONE OF THREE FORMATS:

- A. RANDOM, GENERATED FROM THE KEYBOARD
- B. INCREMENTAL, GENERATED BY "A"
- C. WORST CASE, GENERATED BY "W"

REFER TO MAINDEC-11-DBVTA WRITEUP FOR DETAILS.

WHEN DATA IS RECEIVED, THE PROGRAM VERIFIES THAT THE FIRST CHARACTER, OTHER THAN NULLS), IS A START CODE. ON RECEIPT OF THE START CODE, THE RECEIVER SERVICE ROUTINE IS INITIALIZED. ALL DATA FROM THIS POINT, UNTIL THE RECEIPT OF AN EOP CODE, IS STORED IN THE APPROPRIATE LINES' BUFFER. ON RECEIPT OF THE EOP, THE RECEIVER SERVICE ROUTINE IS TERMINATED. THE TRANSMITTER SERVICE ROUTINE IS THEN INITIALIZED. THUS, NO DL11 TRANSMITTER AND RECEIVER ARE ACTIVE SIMULTANEOUSLY. THE RECEIVED DATA IS THEN TRANSMITTED, EXACTLY AS IT WAS RECEIVED.

IT SHOULD BE NOTED THAT WHEN A LINES' BUFFER IS PRINTED, THE START CODE CHARACTER IS DETECTED AND PRINTED AS AN UP-ARROW ("^"). THIS ALSO HOLDS TRUE ON THE VT20 END, WHERE THE START CODE IS DISPLAYED AS AN ("^") ON THE SCREEN.

#### 9. DISPLAY REGISTER OPTION

\*\*\*\*\*

IF THIS PROGRAM IS BEING RUN ON A PDP-11/45 THE ACTIVITY OF THE DM11 LINES MAY BE VISUALLY MONITORED. THIS IS DONE BY SETTING THE DATA DISPLAY SELECT SWITCH, ON THE /45 CONSOLE, TO THE "DISPLAY REGISTER" POSITION. THEN EVERY TIME A DM11 TRANSMITTER BECOMES ACTIVE, IT'S CORRESPONDING LINE NUMBER WILL BE REFLECTED BY LIGHTING A LIGHT IN THE DATA LIGHT REGISTER. IT CAN BE NOTED, THAT IF A SELECTED LINE IS HELD, THE LIGHT REFLECTING THAT LINE WILL BE LIT IF THAT LINE IS READY TO BE RELEASED.

#### 10. LISTING

\*\*\*\*\*

```
1 .TITLE DH11/VT20 MOST DIAGNOSTIC PROGRAM
2 .ABS
3 .ENABLE AMA
4 JMAINDEC=11-DZVTG-A-D
5 JCOPYRIGHT APRIL 30, 1975
6 JREVISED OCTOBER, 1975
7 JDIGITAL EQUIPMENT CORP. MAYNARD, MASS. 01754
8 JPROGRAMMER: EARL L. BOUSE
9
10 JREGISTER DEFINITIONS
11
12 000000 R0=X0
13 000001 R1=X1
14 000002 R2=X2
15 000003 R3=X3
16 000004 R4=X4
17 000005 R5=X5
18 000006 SP=X6
19 000007 PC=X7
20
21 JINSTRUCTION DEFINITION
22
23 005726 POP1SP=05726
24 022626 POP2SP=22626
25 024646 PUSH2SP=24646
26 000240 NOP=240
27 001100 STACK=1100
28 000014 EOP=14
29
30 JLOAD TRAP CATCHER INTO LOC 0-1000
31
32 000000
33 .REPT .=0
34 .+2
35 4
36 .ENDR JLOAD TRAP WITH 'IOT' TRAP VECTOR
37
38 .=20
39 000020 010664 MAPVEC JMAPPER TRAP ROUTINE
40 000022 000340 340
41 000024 010460 PWRPAL JPOWER FAIL HANDLER
42 000026 000340 340
43 000030 010564 EMTSRV JEMT SERVICE ROUTINE
44 000032 000340 340
45 000060 000060 .=60
46 000060 003150 KEYSRV JTTY KEYBOARD SERVICE ROUTINE
47 000062 000200 200
48 000200 000200 .=200
49 000200 000137 001342 JMP START JPROGRAM STARTING ADDRESS
50
51 JREGISTER ADDRESSES
52 001200 .=1200
53 001200 177776 PSW1 JADDRESS OF PROCESSOR STATUS REG.
54 001202 177560 TKS1 JADDRESS OF KEYBOARD STATUS REG.
```

55 001204 177562  
56 001206 177564  
57 001210 177566  
58 001212 177570  
59  
60  
61  
62 104000  
63 104001  
64 104002  
65 104003  
66  
67  
68  
69  
70  
71 001214 177546  
72 001216 000100  
73 001220 000102  
74  
75  
76  
77  
78  
79  
80  
81 001222 160020  
82 001224 160022  
83 001226 160024  
84 001230 160026  
85 001232 160030  
86 001234 160032  
87 001236 160034  
88 001240 160036  
89 001242 000540  
90 001244 000542  
91 001246 000544  
92 001250 000546  
93  
94  
95  
96  
97  
98 001252 000000  
99 001254 000100  
100 001256 000200  
101 001260 000300  
102 001262 000400  
103 001264 000500  
104 001266 000600  
105 001270 000700  
106 001272 001000  
107 001274 001100  
108 001276 001200

TKB: 177562  
TPS: 177564  
TPB: 177566  
SWR: 177570

! " " " BUFFER "  
! " " PRINTER STATUS REG.  
! " " PRINTER BUFFER REG.  
! " " SWITCH REG.

!TRAP EQUIVALENCE TABLE:

PRINT=EMT  
PRTOCT=PRINT+1  
BINDEC=PRTOCT+1  
OCTPR3=BINDEC+1

!SUBROUTINE TO PRINT ASCII MESSAGES.  
!SUBROUTINE TO PRINT A 6 DIGIT OCTAL NO  
!SUBROUTINE TO CONVERT OCTAL TO BINARY & PRINT IT  
!SUBROUTINE TO PRINT A 3 DIGIT OCTAL NO.

!\*\*\*\*\*  
!LINE CLOCK REGISTER AND VECTOR ADDRESSES  
!\*\*\*\*\*

KW11: 177546  
KNVTR: 102  
KNBR: 102

!\*\*\*\*\*  
!DM11 ADDRESS TABLE  
!THIS TABLE IS OVERLAYED WITH DM11 ADDRESSES SPECIFIED BY THE USER  
!ON PROGRAM INITIALIZATION.  
!\*\*\*\*\*

DHSCR: 160020  
DHNRC: 160022  
DHLPR: 160024  
DHCAR: 160026  
DHBCR: 160030  
DHBAR: 160032  
DHBKR: 160034  
DHSSR: 160036  
DHRVTR: 540  
DHRBR: 542  
DHTVTR: 544  
DHTBR: 546

!SYSTEM CONTROL REGISTER  
!NEXT RECEIVED CHARACTER REGISTER  
!LINE PARAMETER REGISTER  
!CURRENT ADDRESS REGISTER  
!BYTE COUNT REGISTER  
!BUFFER ACTIVE REGISTER  
!BREAK CONTROL REGISTER  
!SILO STATUS REGISTER  
!RECEIVER VECTOR ADDRESS  
!RECEIVER 'BR' LEVEL ADDRESS  
!TRANSMITTER VECTOR ADDRESS  
!TRANSMITTER 'BR' LEVEL ADDRESS

!\*\*\*\*\*  
!RECEIVER BAUD SPEED EQUIVALENCE TABLE  
!\*\*\*\*\*

RCBAUD: 0                   !ZERO  
          100               !50  
          200               !75  
          300               !110  
          400               !134.5  
          500               !150  
          600               !200  
          700               !300  
          1000              !600  
          1100              !1200  
          1200              !1800



109 001300 001300  
110 001302 001400  
111 001304 001500  
112  
113  
114  
115  
116  
117 001306 000000  
118 001310 002000  
119 001312 004000  
120 001314 006000  
121 001316 010000  
122 001320 012000  
123 001322 014000  
124 001324 016000  
125 001326 020000  
126 001330 022000  
127 001332 024000  
128 001334 026000  
129 001336 030000  
130 001340 032000  
131  
132  
133  
134  
135  
136 001342 012777 000340 177630  
137 001350 012706 001100  
138 001354 005077 177622  
139 001360 005037 005546  
140 001364 005037 007646  
141 001370 004737 010626  
142 001374 012737 001412 000004  
143 001402 012701 020000  
144 001406 005721  
145 001410 000776  
146 001412 162701 001000  
147 001416 010137 014274  
148 001422 012737 000006 000004  
149 001430 012737 000004 000006  
150 001436 012700 014376  
151 001442 005020  
152 001444 023700 014274  
153 001450 001374  
154 001452 005737 014270  
155 001456 001004  
156 001460 005237 014270  
157 001464 104000 011031  
158 001470 104000 012346  
159 001474 004737 004722  
160 001500 005737 015044  
161 001504 001003  
162 001506 012737 160020 015044

1300 12400  
1400 14800  
1500 19600

\*\*\*\*\*  
TRANSMITTER BAUD SPEED EQUIVALENC TABLE  
\*\*\*\*\*

TRBAUDI 0	1ZERO
2000	150
4000	175
6000	1110
10000	1134.5
12000	1150
14000	1200
16000	1300
20000	1600
22000	11200
24000	11800
26000	12400
30000	14000
32000	19600

\*\*\*\*\*  
REQUEST AND SET UP A DH11 DEVICE ADDRESS TABLE.  
\*\*\*\*\*

```

START:  MOV    0340,0PSW      ;SET PROCESSOR PRIORITY '07'
        MOV    0STACK,SP     ;INITIALIZE STACK POINTER
        CLR    0TKS          ;CLR KEYBOARD INTERRUPT ENABLE
        CLR    VERPT        ;RESET VERIFY REPEAT REQUEST
        CLR    PRERR        ;RESET INHIBIT ERROR PRINTOUT
        JSR   PC,OVRLAY     ;OVERLAY TRAP AREA.
        MOV    0CORSIZ,004   ;RESET TIMEOUT
        MOV    020000,R1    ;TEST CORE SIZE
        TST   (R1)+
        BR    0-2
CORSIZ: SUB    01000,R1      ;SAVE THIS ADDRESS AS ERROR BUFFER LIMIT
        MOV    R1,MEMSIZ
        MOV    06,004
        MOV    04,006      ;RESET '6' TO TRAP
        MOV    00UPPTR,R0   ;SETUP TO CLR BUFFER & STORAGE AREA
        CLR   (R0)+
        CMP   MEMSIZ,R0    ;DONE?
        BNE  0-6
        TST  MONFLG       ;HAS THE HEADER BEEN TYPED?
        BNE  START1      ;YES, SKIP RE-TYPING IT
        INC  MONFLG       ;NO, SET FLAG
        PRINT, TITLE     ;TEXT 'DH11 DATA HANDLING ROUTINE'
START1: PRINT  ,MPIAD    ;ASK FOR THE DH11 'SCR' ADDRESS
        JSR  PC,GETLN1   ;SET & DECODE THE LINE ADDRESS
        TST  DEVA DR     ;HAS AN ADDRESS INPUTTED?
        BNE  START2     ;YES, SET IT UP.
        MOV  0160020,DEVA DR ;NO, USE DEFAULT 160020 AS 'SCR' ADDRESS
    
```

```

163 001514 013701 015044          START2: MOV      DEVAOR,R1      /GET READY TO ASSEMBLE DM11 ADDRESSES
164 001520 012704 001222          MOV      @DMSCR,R4        /SET UP POINTER TO SAVE ACTIVE DL'S
165 001524 012737 001636 000004   MOV      @START5,@04      /SET UP TIME-OUT ADDRESS
166 001532 012737 000340 000006   MOV      @340,@06
167 001540 052711 040000          BIS      @40000,(R1)      /TEST IF ADDRESS IS PRESENT BY SETTING
168 001544 000240          NOP                          /THE INITIALIZE BIT
169 001546 000240          NOP
170 001550 010105          START3: MOV      R1,R5
171 001552 062705 000020          ADD      @20,R5          /SET UP END ADDRESS COMPARE
172 001556 010124          18:  MOV      R1,(R4)+     /SAVE ADDRESS IN TABLE
173 001560 062701 000002          ADD      @2,R1          /SET UP NEXT DM ADDRESS
174 001564 020105          CMP      R1,R5          /AT END OF ADDRESSES?
175 001566 001373          BNE      18              /NO
176 001570 012737 001606 000004   MOV      @START6,@04      /SET UP TIME-OUT ADDRESS
177 001576 005777 177412          TST      @KW11
178 001602 000240          NOP
179 001604 000403          BR       START6
180 001606 104000 013010          START4: PRINT,   MESS14     /TEXT "CLOCK NOT AVAILABLE"
181 001612 000402          BR       START7
182 001614 005237 014272          START6: INC      LINCLK    /YES, SET THE SOFTWARE FLAG
183 001620 012737 000006 000004   START7: MOV      @6,@04    /NO, RESET TRAP WITH A 'IOT' TRAP
184 001626 012737 000004 000006   MOV      @4,@06
185 001634 000403          BR       FINVEC          /NOW SETUP VECTOR ADDRESS
186 001636 104000 012133          START5: PRINT,   MESS1      /TEXT 'THAT DM11 ADDRESS IS NOT PRESENT'.
187 001642 000712          BR       START1          /REQUEST A NEW ADDRESS
188
189
190 /*****
191 /NOW THAT AN 'ACTIVE' DEVICE TABLE HAS BEEN SETUP, AN INTERRUPT IS FORCED
192 /AND THE DM11 VECTOR ADDRESSES ARE MAPPED.
193 /*****
194 001644 013700 001222          FINVEC: MOV      DMSCR,R0   /SET UP 'SCR' ADDRESS POINTER
195 001650 012701 001242          MOV      @DMRYTR,R1      /SET UP RECEIVER VECTOR ADDRESS POINTER
196 001654 005077 177320          CLR      @PSW            /SET PROC. PRIORITY @0
197 001660 052737 000001 015144   BIS      @1,FMAP         /SET MAPPING FLAG
198 001666 012710 001100          MOV      @1100,(R0)      /SELECT: MAINTENANCE MODE, REC. INTR. ENABLE
199 001672 052710 000200          BIS      @200,(R0)      /CAUSE RECEIVER INTERRUPT
200 001676 000240          NOP
201 001700 000240          NOP
202 001702 012777 000340 177270   MOV      @340,@PSW
203 001710 005010          CLR      (R0)            /CLEAR 'SCR'
204 001712 005737 015144          TST      FMAP           /DID INTERRUPT OCCUR?
205 001716 001412          BEQ      LDVECT         /YES, NOW LOAD THE VECTOR ADDRESS
206 001720 005037 015144          CLR      FMAP           /CLEAR THE SOFTWARE FLAG
207 001724 104000 012177          PRINT,   MESS2          /TEXT 'NO INTERRUPT RESPONSE FROM DEVICE'
208 001730 010037 015122          MOV      R0,KSTOR1      /PRINT 'SRC' ADDRESS
209 001734 104001 015122          PRTCT,   KSTOR1
210 001740 000137 001470          JMP      START1
211
212 /*****
213 /AT THIS POINT THE RECEIVER AND TRANSMITTER VECTOR ADDRESSES HAVE BEEN
214 /MAPPED. THE FOLLOWING SUBROUTINE LOADS THE VECTOR ADDRESSES WITH THEIR
215 /RESPECTIVE SERVICE ROUTINE ADDRESSES AND BR LEVELS.
216 /*****

```

D2

```

217
218 001744 013701 001242
219 001750 012721 006256
220 001754 012721 000340
221 001760 012721 007144
222 001764 012721 000340
223
224
225
226
227
228
229
230
231 001770 012701 014450
232 001774 005011
233 001776 005037 015032
234 002002 012702 014512
235 002006 104000 012556
236 002012 104002 015032
237 002016 004737 010334
238 002022 000773
239 002024 013703 015034
240 002030 016311 001292
241 002034 056311 001306
242 002040 052721 000023
243 002044 012703 016526
244 002050 012322
245 002052 012322
246 002054 005237 015032
247 002060 022737 000020 015032
248 002066 001351
249
250
251
252
253
254
255
256
257 002070 012777 000340 177102
258 002076 012706 001100
259 002102 005037 005546
260 002106 005037 005544
261 002112 005037 007646
262 002116 012701 014614
263 002122 005021
264 002124 023701 014274
265 002130 001374
266 002132 012702 014450
267 002136 012701 030100
268 002142 012777 004000 177052
269 002150 010177 177046
270 002154 012277 177046

LDVECT: MOV DHRVTR,R1 ;SET UP TO LOAD THE SERVICE ADDRESSES
MOV @RCVTR,(R1)+ ;LOAD THE RECEIVER SERVICE ADDRESS
MOV @340,(R1)+ ;SET RECEIVER TO BR LEVEL 7
MOV @TRNMIT,(R1)+ ;LOAD THE TRANSMITTER SERVICE ADDRESS
MOV @340,(R1)+ ;SET TRANSMITTER TO BR LEVEL 7

;*****
;ENTERED HERE TO REQUEST THE BAUD RATE FOR EACH OF THE 16 DM LINES.
;THIS ROUTINE CHECKS FOR LEGAL BAUD RATES, ASSEMBLES THEM INTO USABLE
;RECEIVER & TRANSMITTER BAUD EQUIVALENCE VALUES AND SAVES THEM IN A TABLE.
;THIS TABLE IS THEN LATTER LOADED INTO THE LINE PARAMETER REGISTER.
;*****

GTBAUD: MOV @LPWORD,R1 ;SET UP LINE PARAMETER TABLE POINT
CLR (R1) ;CLEAR 1ST WORD IN TABLE
CLR LINNO
MOV @BAUDMS,R2 ;SET UP POINTER TO SAVE 'ASCII' BAUD VALUES
PRINT, MESS2 ;REQUEST THE LINE BAUD RATES
181 BINDEC, LINNO ;PRINT THE LINE NUMBER
JBR PC,DECODE ;GET & DECODE BAUD VALUE
BR 18 ;RETURN HERE FROM DECODE ON ILLEGAL ENTRY
MOV OFFSET,R3 ;SET UP OFFSET
MOV RCBAUD(R3),(R1) ;SAVE RECEIVER BAUD RATE
BIS TRBAUD(R3),(R1) ;SAVE TRANSMITTER BAUD RATE
BIS @23,(R1)+ ;SELECT: FULL DUPLEX, ODD PARITY, PAR. ENABLED, 8-BIT
MOV @TTYBUF,R3 ;SET UP TO SAVE 'ASCII' VALUE OF BAUD SETTING
MOV (R3)+,(R2)+ ;SAVE FOR PRINTING BAUD RATE IN MONITOR ('M) ROUTINE
MOV (R3)+,(R2)+
INC LINNO ;UPDATE THE LINE NUMBER
CMP @20,LINNO ;DONE ALL '16' LINES?
BNE 18 ;NO

;*****
;PROGRAM ENTERED HERE TO INITIALIZE ALL SOFTWARE SWITCHES (BOTH FOR
;USER OPTIONS I.E. 'S', 'P', ETC. AND PROGRAM SWITCHES. THIS IS ENTER-
;ED EITHER FROM THE MONITOR ON PROGRAM LOADS OR BY TYPING A 'E'.
;*****

SERVICE: MOV @340,@PSW ;SET PROC. PRIORITY 07
MOV @STACK,SP ;RESET STACK POINTER
CLR VERPT ;CLEAR CONTROL X FLAG
CLR LINSTR ;RESET CONTROL X LINE STORAGE
CLR PRTRR ;RESET ERROR PRINT FLAG
MOV @HOLDSW,R1 ;SET UP TO CLEAR ALL SOFTWARE SW'S.
181 CLR (R1)+
CMP MEMSIZ,R1 ;DONE?
BNE 18 ;NO
MOV @LPWORD,R2 ;SET UP LINE PARAMETER TABLE POINTER
MOV @30100,R1
MOV @4000,@DMSCR ;ISSUE MASTER CLEAR TO INITIALIZE THE 'DM'
281 MOV R1,@DMSCR ;SELECT: REC, TRANS & NON-EX MEM INTERRUPTS
MOV (R2)+,@DHLPR ;LOAD THE LINE PARAMETER REG. FROM TABLE

```

271	002160	012777	005542	177042	MOV	OVERDAT, @DHCAR	);SET UP CURRENT ADDRESS REGISTER
272	002166	012777	177777	177036	MOV	0-1, @DHBCR	);SET BYTE COUNT REGISTER
273	002174	005201			INC	R1	);UPDATE THE LINE NUMBER
274	002176	032701	000020		BIT	020, R1	);LOADED ALL '16' LINES?
275	002202	001762			BEQ	20	);NO
276	002204	005077	177030		CLR	@DHSSR	);SET SILO ALARM TO '0' IF NO CLOCK
277	002210	005737	014272		TST	LINCLK	);IS A LINE CLOCK AVAILABLE?
278	002214	001521			BEQ	RESTRY	);NO
279	002216	012777	000040	177014	MOV	032, @DHSSR	);SET SILO ALARM FOR '32' CHARACTERS
280	002224	012777	006250	176764	MOV	@CLKSRV, @KHWTR	);YES, SERVICE RECEIVER SILO ON INTERRUPT
281	002232	012777	000300	176760	MOV	0300, @KWBK	);SET CLOCK TO BR LEVEL 6
282	002240	052777	000100	176746	BIS	0100, @KWI1	);SET THE INTERRUPT ENABLE

283  
284  
285  
286  
287  
288  
289  
290  
291  
292  
293  
294

```

)*****
)EACH ACTIVE TRANSMITTER (DEFINED BY THE USER) IS NOW TESTED TO BE OPERATIONAL.
)THIS IS DONE BY TRANSMITTING A '125' CHARACTER ON EACH ACTIVE TRANSMITTER
)WITH THE MAINTENANCE BIT (9) SET. A CHECK IS THEN MADE THAT THE
)TRANSMITTER INTERRUPTED AND THAT THE RECEIVER INTERRUPTED AND
)RECEIVED THE '125' TEST CHARACTER.
)THE ERROR CODES FOR THIS CHECKING ARE:
)14=NO TRANSMITTER INTERRUPT OCCURRED
)16=NO RECEIVER INTERRUPT OCCURRED
)*****
    
```

295	002246	012700	015704		TRNCHK1	MOV	@ERRBUF, R0	);SETUP THE ERROR BUFFER
296	002252	010005				MOV	R0, R5	
297	002254	052777	000100	176720		BIS	0100, @TKS	);ENABLE KEYBOARD INTERRUPTS
298	002262	104000	014262			PRINT,	DOT	);TO INDICATE READY
299	002266	005077	176706			CLR	@PSW	);SET PROC. PRIORITY 00
300	002272	012701	014450			MOV	@LPWORD, R1	);SET UP POINTER TO CHECK ACTIVE TRANSMITTER
301	002276	012702	000001			MOV	01, R2	
302	002302	005003				CLR	R3	
303	002304	022721	000077		181	CMP	@77, (R1)+	);IS THIS LINE ACTIVE?
304	002310	002043				BGE	30	);NO
305	002312	052777	001000	176702		BIS	01000, @DHSCR	);SET THE MAINTENANCE BIT
306	002320	056337	014276	015020		BIS	LINENO(R3), RECVCK	);SET THE RECEIVER CHECK SW.
307	002326	056337	014276	015022		BIS	LINENO(R3), ACTIVE	);YES, SET LINE ACTIVE BIT
308	002334	056337	014276	315152		BIS	LINENO(R3), TRNSHM	
309	002342	050277	176666			BIS	R2, @DHBAR	);START TRANSMITTER
310	002346	005037	015006			CLR	CLKCTR	
311	002352	022737	000003	015006		CMP	03, CLKCTR	);WAIT FOR CLOCK INTERRUPT TO GIVE
312	002360	001374				BNE	.-6	);TRANSMITTER AMPLE TIME
313	002362	005737	015022			TST	ACTIVE	);WAS A TRANSMITTER INTERRUPT SERVICED?
314	002366	001405				BEQ	20	);YES
315	002370	112720	000014			MOVB	014, (R0)+	);NO, POST AS NO TRANSMITTER INTERRUPT
316	002374	110310				MOVB	R3, (R0)	);SET UP TO SAVE FAILING LINE NUMER
317	002376	106220				ASRB	(R0)+	
318	002400	000407				BR	30	
319	002402	005737	015020		281	TST	RECVCK	);DID THE RECEIVER INTERRUPT?
320	002406	001404				BEQ	30	);YES
321	002410	112720	000016			MOVB	016, (R0)+	);NO, POST AN RECEIVER ERROR
322	002414	110310				MOVB	R3, (R0)	);SAVE FAILING LINE NUMBER
323	002416	106220				ASRB	(R0)+	
324	002420	042777	001000	176574	381	BIC	01000, @DHSCR	);CLEAR THE MAINTENANCE BIT

325	002426	005037	015022		CLR	ACTIVE		
326	002432	005037	015152		CLR	TRNSWH		
327	002436	005037	015020		CLR	RECVCK		
328	002442	006302			ASL	R2	IUPDATE POINTER	
329	002444	062703	000002		ADD	02,R3	IUPDATE OFFSET	
330	002450	022703	000040		CHP	032.,R3	ITESTED ALL LINES?	
331	002454	001313			BNE	18	I NO	
332	002456	000424			BR	MONITR	IYES, ENTER THE MONITOR	
333								
334								
335								
336								
337								
338								
339								
340	002460	012706	001100		RESTRY:	MOV	0STACK,SP	I RESET STACK POINTER
341	002464	012701	014616			MOV	0SENDW,R1	
342	002470	005021			48:	CLR	(R1)+	I CLEAR THE 'C' SOFTWARE SWITCHES.
343	002472	022701	015146			CHP	0RECSWH,R1	I DONE?
344	002476	001374				BNE	48	
345	002500	005037	007646			CLR	PRYERR	I PRINT ALL ERRORS
346	002504	012700	015704			MOV	0ERRBUF,R0	I SETUP ERROR BUFFER
347	002510	010005				MOV	R0,R5	
348	002512	052777	000100	176462		BIS	0100,0TKS	I ENABLE KEYBOARD INTERRUPTS
349	002520	104000	014262			PRINT,	DOT	I TO INDICATE READY
350	002524	005077	176450			CLR	0PSW	I SET PROC. PRIORITY 00
351								
352								
353								
354								
355								
356								
357								
358	002530	013777	015022	176454	MONITR:	MOV	ACTIVE,0SWR	I DISPLAY SYSTEM STATUS
359	002536	022700	016512			CHP	0ERRBUF+390.,R0	I TEST THAT THE ERROR BUFFER ISN'T EXCEEDED
360	002542	003003				BGT	MONTR1	I BUFFER OK
361	002544	012700	015704			MOV	0ERRBUF,R0	I NO, RE-SET THE BUFFER POINTER
362	002550	010005				MOV	R0,R5	
363	002552	004737	002634		MONTR1:	JSR	PC,SRVERR	I CHECK ERROR BUFFER
364	002556	004737	003004			JSR	PC,SYSCK1	I CHECK IF LINES ARE BEING VALIDATED
365	002562	004737	002570			JSR	PC,TSTBOT	I CHECK IF ANY LINES ARE BEING BOOTED
366	002566	000760				BR	MONITR	
367								
368								
369								
370								
371								
372	002570	005737	014620		TSTBOT:	TST	BOOTFG	I CURRENTLY BOOTING PROGRAM?
373	002574	001416				BEO	TSTEXT	I NO, EXIT
374	002576	023737	015036	015130		CHP	REDONE,KSTOR4	I YES, HAVE ALL TRANSMITTERS FINISHED?
375	002604	001012				BNE	TSTEXT	I NO, EXIT
376	002606	005037	015036			CLR	REDONE	I YES, CLEAR COUNTER
377	002612	012737	016570	015052		MOV	0READSP,BOOTP2	I RESET READER BUFFER POINTER
378	002620	005037	015056			CLR	READCT	I CLEAR THE CHARACTER COUNTER

```
379 002624 012777 000101 012322      MOV      #101,PRCSR      ;SET READER GO TO RESTART BOOT
380 002632 000207                      TSTEXT: RTS            PC      ;RETURN
381
382
383                                     ;*****
384                                     ;ENTERED HERE TO REPORT THE SYSTEM ERRORS, ALL ERRORS ARE BUFFERED
385                                     ;IN THE SERVICE ROUTINES I.E. RECEIVER, READER AND TRANSMITTER.
386                                     ;THESE ERRORS ARE THEN REPORTED AS BACKGROUND JOBS.
387                                     ;*****
388 002634 020005      SRVERRI: CMP      R0,R5      ;ARE THERE ANY ERRORS PENDING?
389 002636 001441      BEQ      SRVEXT      ;NO, EXIT
390 002640 005737 015132      TST      RMODE      ;YES, DATA REPORT MODE REQUESTED?
391 002644 001106      BNE      DATA      ;YES, GO TO DATA REPORT ROUTINE
392 002646 112537 015124      MOVB    (R5)+,KSTOR2 ;GET THE ERROR CODE
393 002652 112537 015122      MOVB    (R5)+,KSTOR1 ;GET FAILING UNIT NO.
394 002656 104000 012255      281     PRINT,  MESS      ;TEXT 'LINE'
395 002662 104002 015122      BINDEC, KSTOR1      ;PRINT FAILING UNIT NO.
396 002666 013704 015124      MOV     KSTOR2,R4    ;PICK UP OFFSET TO PRINT ERROR TYPE
397 002672 042704 177760      BIC     #177760,R4
398 002676 006304      ASL     R4
399 002700 016437 002744 002710      MOV     ERRTABL(R4),ERRMES+2
400 002706 104000 000000      ERRMES: PRINT,  HALT    ;MODIFIED TO PRINT ERROR MESSAGE
401 002712 022704 000024      CMP     #24,R4      ;IS THIS A VERIFY DATA ERROR?
402 002716 001403      BEQ     38          ;YES,
403 002720 022704 000036      CMP     #36,R4      ;NO, IS THIS A CHECK DATA ERROR
404 002724 001006      BNE     SRVEXT      ;NO, EXIT
405 002726 112537 015122      381     MOVB    (R5)+,KSTOR1 ;YES, PICK UP THE BAD DATA
406 002732 104003 015122      OCTPR3, KSTOR1      ;PRINT IT
407 002736 104000 014262      PRINT,  DOT
408 002742 000207      SRVEXT: RTS            PC      ;RETURN
409
410 002744 013224      ERRTABL: CODE00      ;# ILLEGAL RECEIVER INTERRUPT
411 002746 013260      CODE01      ;# OVERRUN ERROR
412 002750 013301      CODE02      ;# FRAMING ERROR
413 002752 013322      CODE03      ;# PARITY ERROR
414 002754 013342      CODE04      ;# ILLEGAL START CODE RECEIVED
415 002756 013501      CODE05      ;# ILLEGAL READER INTERRUPT
416 002760 013535      CODE06      ;# ILLEGAL TRANSMITTER INTERRUPT
417 002762 013571      CODE07      ;# ATTEMPT TO RECEIVE WHILE IN SEND MODE
418 002764 013642      CODE10      ;# TRANSMITTER NON-EX MEMORY INTERRUPT
419 002766 013711      CODE11      ;# VERIFY CHECK OK
420 002770 013730      CODE12      ;# DATA VERIFY ERROR, SENT=377 RECV'D=XXX
421 002772 013775      CODE13      ;# NO VERIFY DATA RETURNED
422 002774 014030      CODE14      ;# NO TRANSMITTER INTERRUPTS OCCURRING
423 002776 014077      CODE15      ;# IS ACTIVE, CAN'T VERIFY - TYPE 'E'
424 003000 014146      CODE16      ;# NO RECEIVER INTERRUPTS OCCURRING
425 003002 014212      CODE17      ;# DATA CHECK ERROR, SENT=377 RECV'D=XXX
426
427
428                                     ;*****
429                                     ;ENTERED HERE TO REPORT LINES THAT DIDN'T RESPOND WHEN VERIFIED
430                                     ;*****
431 003004 005737 015004      SYSCK1: TST      SYSSW1 ;ARE THERE ANY VALIDATING LINES HUNG?
432 003010 001423      BEQ     SYSEXT      ;NO, EXIT
```

```

433 003012 013701 015004      MOV      SYSSW1,R1      ;YES, REPORT THEM
434 003016 012702 000001      MOV      R1,R2        ;SET UP AS POLLING BIT
435 003022 005003              CLR      R3           ;SET UP AS LINE NO.
436 003024 030201              BIT      R2,R1        ;LINE HUNG?
437 003026 001404              BEQ     28            ;NO
438 003030 112720 000013      MOV     R13,(R0)+     ;YES, POST AS NO DATA RETURNED ON VERIFY
439 003034 110310              MOV     R3,(R0)      ;SET UP LINE NO.
440 003036 106220              ASRB   (R0)+
441 003040 006302 281          ASL     R2
442 003042 062703 000002      ADD     R2,R3
443 003046 022703 000040      CMP     R32.,R3      ;TESTED ALL LINES?
444 003052 001364              BNE    18
445 003054 005037 015004      CLR     SYSSW1       ;CLEAR THE SOFTWARE SWITCH
446 003060 000207      SYSEXT: RTS          PC          ;RETURN

```

```

;*****
;ENTERED HERE WHEN IN DIAGNOSTIC MODE TO TYPE DATA RECEIVED FROM THE VT20
;*****

```

```

451
452 003062 105777 176120      DATA: TSTB   0TPB
453 003066 100375              BPL     =4
454 003070 122715 000377      CMPB   R377,(R5)     ;CHAR. = TO START CODE?
455 003074 001010              BNE    PRTAS1       ;NO, CHECK FOR 'LF' CODE
456 003076 112777 000336 176104      MOV     R336,0TPB   ;YES, CHANGE CODE TO ' '.
457 003104 005037 015134      PRTAS0: CLR    PRTCNT ;CLR PRINT COUNT.
458 003110 104000 014260      PRINT, CRLF
459 003114 000413              BR     EXIT

```

```

460
461 003116 122715 000012      PRTAS1: CMPB   R12,(R5) ;CHAR. = TO 'LF'
462 003122 001770              BEQ    PRTAS0       ;YES, PRINT 'CR-LF'
463 003124 111577 176060      MOV     (R5),0TPB   ;NO, PRINT CHAR. AS IS.
464 003130 005237 015134      INC    PRTCNT       ;INC. PRINT COUNT
465 003134 022737 000100 015134      CMP     R64.,PRTCNT ;LINE FULL?
466 003142 001760              BEQ    PRTAS0       ;YES, PRINT CRLF.
467 003144 105725      EXIT:  TSTB   (R5)+  ;INC. BUFFER POINTER.
468 003146 000207      RTS     PC          ;RETURN

```

```

;*****
;ENTERED HERE TO SERVICE KEYBOARD INTERRUPTS
;THE CHARACTERS SERVICED BY THE 'KEYSRV' ROUTINE ARE CATEGORIZED INTO
;ONE OF THREE (3) CATEGORIES: (1)CONTROL CHARACTERS, (2)CHARACTERS ENTERED WHILE
;IN THE SEND MODE, (3)LINE NO'S & ADDRESSES. ALL CONTROL CHARACTERS ARE
;TESTED AND VALIDATED BY THE 'KEYSRV' ROUTINE. IF IT ISN'T A CONTROL CHARACTER
;A TEST IS MADE TO SEE IF THE SEND MODE IS ACTIVE (CONSPFL=1). THESE
;CHARACTERS ARE HANDLED BY THE 'SENDLN' ROUTINE. IF NEITHER OF THE ABOVE ARE
;TRUE, THE CHARACTER IS HANDLED BY THE 'GETLN2' ROUTINE. THIS ROUTINE
;ASSEMBLES LINE NUMBERS, REGISTER ADDRESSES AND BAUD RATES.
;*****

```

```

481
482 003150 010146      KEYSRV: MOV     R1,-(SP) ;SAVE WORKING REG.'S
483 003152 010246      MOV     R2,-(SP)
484 003154 010346      MOV     R3,-(SP)
485 003156 010446      MOV     R4,-(SP)
486 003160 117701 176020      MOV     R0KB,R1     ;GET CHAR.

```

487	003164	042701	177600		BIC	0177600,R1	!STRIPE OFF PARITY BIT
488	003170	010137	015030		MOV	R1,8CHAR	!SAVE THE CHAR.
489	003174	022701	000019		CMP	019,R1	!CHAR. = TO 'CR'?
490	003200	001003			BNE	48	!NO
491	003202	004737	006226		JSR	PC,TYPEIT	!YES, ECHO IT
492	003206	000554			BR	EXITK8	!EXIT
493	003210	022701	000012	481	CMP	012,R1	!CHAR. = TO 'LF'?
494	003214	001536			BEG	GETLN	!YES
495	003216	020127	000033		CMP	R1,033	!CHAR. PRINTABLE?
496	003222	002133			BGE	GETLN	!YES
497	003224	012701	000136		MOV	0130,R1	!NO, PRINT AS A CONTROL CHAR.
498	003230	004737	006226		JSR	PC,TYPEIT	
499	003234	013701	015030		MOV	8CHAR,R1	
500	003240	052701	000100		BIS	0100,R1	!MAKE CHAR. PRINTABLE
501	003244	004737	006226		JSR	PC,TYPEIT	
502	003250	122701	000101		CMPB	0101,R1	!CHAR. = TO '^A'?
503	003254	001002			BNE	.06	!NO
504	003256	000137	001342		JMP	START	!YES, RESTART PROGRAM
505	003262	122701	000103		CMPB	0103,R1	!CHAR. = TO '^C'?
506	003266	001557			BEG	CONC	
507	003270	122701	000105		CMPB	0105,R1	!^E FOR ESCAPE AND RESTART
508	003274	001002			BNE	.06	
509	003276	000137	002070		JMP	SERVICE	!YES, DO A COMPLETE RESTART
510	003302	005737	015010		TST	SYSSWH	!SYSTEM ACTIVE?
511	003306	001074			BNE	QMARK	!YES, IGNORE REQUEST
512	003310	005237	015010		INC	SYSSWH	!NO, SET REQUEST SW.
513	003314	122701	000102		CMPB	0102,R1	!CHAR. = TO '^B'?
514	003320	001002			BNE	100	!NO
515	003322	000137	005550		JMP	BOOT	!YES, BOOT TAPE TO VT20.
516	003326	122701	000130	106i	CMPB	0130,R1	!CHAR. = '^X'?
517	003332	001005			BNE	118	!NO
518	003334	012737	000001	005546	MOV	01,VERPT	!YES=LOAD VERIFY REPEAT FLAG
519	003342	000137	005310		JMP	VERIFY	!AND GO VERIFY
520	003346	122701	000124	118i	CMPB	0124,R1	!CHAR. = '^Y'?
521	003352	001003			BNE	128	!NO
522	003354	005137	007646		COM	PRYERR	!COMPLEMENT PRINT INHIBIT FLAG
523	003360	000463			BR	PRYDOT	!AND EXIT
524	003362	122701	000104	128i	CMPB	0104,R1	!CHAR. = '^D'?
525	003366	001505			BEG	COND	!YES, DIAGNOSTIC MODE
526	003370	122701	000110		CMPB	0110,R1	!^M (HOLD)?
527	003374	001466			BEG	CONH	
528	003376	122701	000122		CMPB	0122,R1	!^R (RELEASE)?
529	003402	001521			BEG	CONR	
530	003404	122701	000123		CMPB	0123,R1	!^S (SEND)?
531	003410	001002			BNE	.06	!NO
532	003412	000137	004066		JMP	CONS	
533	003416	122701	000114	18i	CMPB	0114,R1	!^L (LIST SYSTEM STATUS)
534	003422	001002			BNE	28	!NO
535	003424	000137	005006		JMP	CONL	!YES
536	003430	122701	000120	28i	CMPB	0120,R1	!^P (PRINT)?
537	003434	001571			BEG	CONP	
538	003436	122701	000117		CMPB	0117,R1	!^O (SUPPRESS PRINTING)
539	003442	001007			BNE	38	!NO
540	003444	005237	015026		INC	OSWITCH	!YES, SET THE SOFTWARE FLAG



```

541 003450 005337 015010          DEC      SYSSWM
542 003454 112701 000040          MOV     @40,R1          ;PRINT SPACE
543 003460 000427                    BR      EXITKS         ;EXIT
544 003462 122701 000126          381    CMPB    @126,R1  ;"V (VERIFY LINE)
545 003466 001002                    BNE     58              ;NO
546 003470 000137 005310          JMP     VERIFY         ;YES, VERIFY LINE(S)
547 003474 005337 015010          581    DEC      SYSSWM  ;CLR SYSTEM SWITCH ON ILLEGAL ENTRY
548 003500 112701 000077          QMARK: MOV     @77,R1  ;ILLEGAL CHAR.
549 003504 004737 006226          KEY1:  JSR     PC,TYPEIT ;TYPE '9'.
550 003510 000413                    BR      EXITKS         ;IGNORE IT
551 003512 005737 015040          GETLN: TST     CON$PL   ;ARE WE IN SEND MODE?
552 003516 001402                    BEQ     ,+6            ;NO
553 003520 000137 004136          JMP     SENDLN        ;YES, GO TO THE SEND ROUTINE
554 003524 000137 004416          JMP     GETLN2        ;GO TO LINE NO. INPUT ROUTINE
555
556 003530 005037 015010          PRD0T: CLR     SYSSWM
557 003534 104000 014262          PRINT, DOT
558 003540 012604                    EXITKS: MOV    (SP)+,R4 ;RESTORE THE WORKING REG.'S
559 003542 012603                    MOV     (SP)+,R3
560 003544 012602                    MOV     (SP)+,R2
561 003546 012601                    MOV     (SP)+,R1
562 003550 000002                    RTI
563
564
565
566
567
568
569
570 003552 004737 004626          CONH:  JSR     PC,FORMIT ;FORM OFFSETS
571 003556 056337 014276 014614          DIS     LINENO(R3),HOLD$W ;SET HOLD SW. FOR THIS LINE.
572 003564 005337 014732          DEC     $C0CTR        ;ANY MORE LINES TO BE HELD?
573 003570 001403                    BEQ     CONH1          ;NO
574 003572 004737 004632          JSR     PC,FORMON     ;YES, FORM OFFSET FOR LINE
575 003576 000767                    BR      CONH+4         ;HOLD NEXT LINE
576 003600 000753          CONH1: BR      PRD0T    ;EXIT
577
578
579
580
581
582 003602 005137 015132          COND:  COM     RMODE    ;SET/CLEAR DIAGNOSTIC SW.
583 003606 001403                    BEQ     18              ;RESET POINTERS IF CLEARED
584 003610 104000 012500          PRINT, MESS9         ;TEXT 'DIAG. MODE ENABLED'
585 003614 000403                    BR      28              ;EXIT
586 003616 012700 015704          181    MOV     @ERRBUF,R0 ;RESET BUFFER POINTERS
587 003622 010009                    MOV     R0,R5
588 003624 000741          281    BR      PRD0T    ;EXIT
589
590
591
592
593
594 003626 005002          CONC:  CLR     R2

```

;\*\*\*\*\*  
;ENTERED HERE ON RECEIPT A 'H' TO HOLD A SPECIFIED TRANSMISSION LINE.  
;THIS ROUTINE SIMPLY SETS A SOFTWARE SWITCH (HOLD\$W) TO INDICATE THAT A  
;SPECIFIED LINE OR LINES ARE TO BE HELD FROM TRANSMITTING DATA BACK TO THE VT20  
;COMMAND FORMAT: "H (LINE NO.), (LINE NO.),...ETC FUP TO 16 LINE NO.'S  
;\*\*\*\*\*

;\*\*\*\*\*  
;SUBROUTINE ENTERED ON RECEIPT OF A 'D' TO ENTER DIAGNOSTIC MODE  
;\*\*\*\*\*

;\*\*\*\*\*  
;ENTERED ON RECEIPT OF A 'C' TO CLEAR ALL USER SOFTWARE SWITCHES.  
;\*\*\*\*\*

```

595 003630 005003          CLR      R3
596 003632 012604          MOV      (SP)+,R4          ;RESTORE THE WORKING REG.'S
597 003634 012603          MOV      (SP)+,R3
598 003636 012602          MOV      (SP)+,R2
599 003640 012601          MOV      (SP)+,R1
600 003642 000137 002460    JMP      RESTRY
601
602
603
604
605
606
607
608
609
610
611 003646 004737 004626    CONR1: JSR      PC,FORMIT          ;FORM THE OFFSETS
612 003652 004737 003660    JSR      PC,RELEASE          ;RELEASE HELD LINES
613 003656 000724          BR       PRYDOT             ;EXIT
614
615 003660 036337 014276 014614  RELESE: BIT      LINENO(R3),HOLDSW          ;IS LINE BEING HELD?
616 003666 001445          BEQ      CONR2              ;NO, EXIT
617 003670 046337 014276 014614  CONR1: BIC      LINENO(R3),HOLDSW          ;CLR HOLD SW. FOR THIS LINE.
618 003676 046337 014276 014616    BIC      LINENO(R3),SENDSW          ;CLEAR THE SEND SW.
619 003704 036337 014276 015150    BIT      LINENO(R3),PENDIN          ;IS DATA PENDING ON THIS LINE?
620 003712 001433          BEQ      CONR2              ;NO SIMPLY RELEASE THE LINE
621 003714 056337 014276 015152    BIS      LINENO(R3),TRNSW          ;YES, SET TRANSMITTER SW.
622 003722 012777 000340 175250    MOV      @340,@PSW          ;TEMPORARILY INHIBIT ANY INTERRUPTS
623 003730 046337 014276 015150    BIC      LINENO(R3),PENDIN          ;CLEAR THE PEND SW.
624 003736 056337 014276 015022    BIS      LINENO(R3),ACTIVE          ;SET WHEN TRANSMITTING
625 003744 052702 030500          BIS      @30500,R2
626 003750 010277 175246          MOV      R2,@DHSCR
627 003754 016377 015160 175250    MOV      BYTECT(R3),@DHSCR          ;SET UP BYTE COUNT
628 003762 016377 014336 175240    MOV      BUPADR(R3),@DHCR          ;SET UP CURRENT ADDRESS
629 003770 056377 014276 175236    BIS      LINENO(R3),@DHBR          ;START UP TRANSMITTER
630 003776 005077 175176          CLR      @PSW              ;RE-ENABLE INTERRUPTS
631 004002 005337 014732    CONR2: DEC      BCDCTR          ;ANY MORE LINES TO BE RELEASED?
632 004006 003403          BLE      CONR3              ;NO
633 004010 004737 004632          JSR      PC,FORMON          ;YES, FORM OFFSET FOR NEXT LINE
634 004014 000721          BR       RELEASE           ;RELEASE NEXT LINE
635 004016 000207    CONR3: RTS      PC              ;RETURN
636
637
638
639
640
641
642
643 004020 005077 175154    CONP1: CLR      @PSW              ;ENABLE FURTHER INTERRUPTS
644 004024 005037 015132          CLR      RMODE             ;CLR DIAGNOSTIC MODE
645 004030 004737 004626          JSR      PC,FORMIT          ;FORM THE OFFSETS
646 004034 010437 004042    CONP1: MOV      R4,CONP2+2          ;SET UP BUFFER TO BE PRINTED
647 004040 104000 000000    CONP2: PRINT,  HALT
648 004044 005337 014732          DEC      BCDCTR             ;DONE PRINTING ALL REQUESTS

```

\*\*\*\*\*  
 ENTERED HERE ON RECEIPT OF A "R" TO RELEASE A SPECIFIED TRANSMISSION  
 LINE. THIS COMMAND RELEASES HELD LINES IN ONE OF THREE WAYS (1)LINES THAT  
 ARE INDICATED TO BE RELEASED AND WEREN'T BEING HELD ARE IGNORED, (2)LINES THAT  
 ARE BEING HELD BUT HAVE NO DATA PENDING, SIMPLY CLEAR THE HOLD SWITCH (HOLDSW), (3)LINES  
 THAT ARE BEING HELD AND HAVE DATA PENDING ARE RELEASED AND THE TRANSMITTERS FOR  
 THOSE LINES ARE INITIALIZED AND ACTIVATED.  
 \*\*\*\*\*

\*\*\*\*\*  
 ENTERED HERE ON RECEIPT OF A "P" TO PRINT THE DATA IN A SPECIFIED  
 LINES BUFFER. THIS CAN EITHER BE DATA RECEIVED FROM A SLAVE VT20  
 OR DATA ENTERED WHILE IN THE SEND MODE.  
 \*\*\*\*\*

```

649 004050 003405          BLE  CONP3      IYES
650 004052 004737 004632  JBR  PC,FORMON  INO, FORM NEXT OFFSET
651 004056 104000 014260  PRINT,  CRLF
652 004062 000764          BR   CONP1
653 004064 000621  CONP3: BR   PRTOOT      IEXIT
654
655 /*****
656 /SUBROUTINE ENTERED TO SETUP TO SEND DATA FROM KB TO SPECIFIED LINE
657 /CALLING SEQUENCE: "S(LINE NO.),(LINE NO.),...ETC.  IUP TO 16 LINE NO.'S
658 /          DATA          IUP TO 304 CHAR,'S
659 /          'ALT'MODE      ITO TERMINATE SEND MODE
660 /*****
661
662 004066 004737 004626  CONS1: JBR  PC,FORMIT  IFORM THE OFFSETS
663 004072 005237 015040  INC  CONSPL      ISET SOFTWARE SW.
664 004076 010463 014376  CONS1: MOV  R4,BUFPTR(R3) ISET UP THE BUFFER POINTER
665 004102 012763 000005 015160  MOV  05,BYTECT(R3) IINITIALIZE THE BYTE COUNTER
666 004110 056337 014276 014616  BIS  LINENO(R3),SEND SW ISET THE SEND SW.
667 004116 005337 014732  DEC  BCDCTR      IANY MORE LINES TO BE SETUP?
668 004122 003403          BLE  CONS2      INO
669 004124 004737 004632  JBR  PC,FORMON  IYES, SET THEM UP
670 004130 000762          BR   CONS1
671 004132 000137 003540  CONS2: JMP  EXITKS      IEXIT
672
673 /*****
674 /ENTERED HERE FROM THE 'KEYSRV' ROUTINE WHEN THE SEND SWITCH (CONSPL) IS SET
675 /*****
676
677 004136 004737 006226  SENDLN: JBR  PC,TYPEIT  IECHO CHAR.
678 004142 005001          CLR  R1
679 004144 005002          CLR  R2
680 004146 005003          CLR  R3
681 004150 036337 014276 014616  CONS1: BIS  LINENO(R3),SEND SW ISEND TO THIS LINE?
682 004156 001422          BEQ  TAGC        INO, CHECK NEXT LINE
683 004160 016304 014376  MOV  BUFPTR(R3),R4 ISET UP BUFFER POINTER
684 004164 122737 000033 015030  CMPB 033,SCHAR I=TO 'ALT' TO TERMINATE SEND MODE?
685 004172 001424          BEQ  TAGA        IYES
686 004174 122737 000175 015030  CMPB 0175,SCHAR I= ALT ON ASR33
687 004202 001420          BEQ  TAGA        IYES,
688
689 004204 113724 015030  SENDBF: MOVB  SCHAR,(R4)+ ISAVE CHARACTER IN BUFFER
690 004210 112714 000014  MOVB  @EOP,(R4) ITERMINATE THE BUFFER
691 004214 010463 014376  MOV  R4,BUFPTR(R3) ISAVE BUFFER POINTER
692 004220 005263 015160  INC  BYTECT(R3) ICOUNT NO. OF BYTES SAVED
693 004224 005202  TAGC: INC  R2 IUPDATE THE LINE NO.
694 004226 062703 000002  ADD  02,R3
695 004232 022703 000040  CMP  032.,R3 IDONE ALL LINES?
696 004236 001344          BNE  CONS2      INO
697 004240 000137 003540  JMP  EXITKS      IYES, EXIT
698 004244 005037 015040  TAGA: CLR  CONSPL
699 004250 112714 000014  MOVB  @EOP,(R4) ITERMINATE BUFFER
700 004254 036337 014276 014616  TAGB: BIS  LINENO(R3),SEND SW ISENDING ON THIS LINE?
701 004262 001445          BEQ  TAGC        INO, CHECK NEXT LINE
702 004264 046337 014276 014616  BIC  LINENO(R3),SEND SW ICLEAR THE SEND SW.

```

```

703 004272 005463 015160          NEG      BYTECT(R3)          ;COMPLIMENT BYTE COUNT
704 004276 036337 014276 014614    BIT      LINENO(R3),HOLD SW ;IS THIS LINE BEING HELD?
705 004304 001404                    BEQ      TAGD                    ;NO
706 004306 056337 014276 015150    BIS      LINENO(R3),PENDIN    ;YES, SET THE PENDING SW.
707 004314 000430                    BR       TAGD                    ;
708 004316 012777 000340 174654    TAGD1   MOV      @340,@PSW      ;TEMPORARILY INHIBIT FURTHER INTERRUPTS
709 004324 052702 030100                    BIS      @30100,R2            ;SET UP TO INITIALIZE TRANSMITTER
710 004330 010277 174666                    MOV      R2,@DHSCR            ;
711 004334 016377 015160 174670    MOV      BYTECT(R3),@DHBCR    ;
712 004342 016377 014336 174660    MOV      @UPADR(R3),@DHCAR    ;
713 004350 056337 014276 015152    BIS      LINENO(R3),TRNSWH    ;SET TRANSMITTER SW.
714 004356 056337 014276 015022    BIS      LINENO(R3),ACTIVE    ;
715 004364 056377 014276 174642    BIS      LINENO(R3),@DHBAR    ;START TRANSMITTER
716 004372 005077 174602                    CLR      @PSW                  ;RE-ENABLE INTERRUPTS
717 004376 005202                    TAGE1   INC      R2              ;UPDATE THE LINE NO.
718 004400 062703 000002                    ADD      @2,R3                 ;
719 004404 022703 000040                    CMP      @32.,R3              ;
720 004410 001321                    BNE      TAGB                  ;
721 004412 000137 003530                    JMP      PRYDOT                ;EXIT

```

```

;*****
;SUBROUTINE ENTERED TO FORM ADDRESSES, BAUD RATES OR LINE NUMBER
;*****

```

```

727 004416 022701 000177          GETLN21 CMP      @177,R1              ;CHAR. = RUBOUT?
728 004422 001446                    BEQ      RUBOUT                ;YES
729 004424 005737 015024                    TST      RUBSWH                ;IS RUBOUT SW. SET?
730 004430 001402                    BEQ      18                      ;NO
731 004432 104000 014265                    PRINT,  SLASH                  ;YES, PRINT '/'
732 004436 005037 015024          18:    CLR      RUBSWH                ;CLR SW.
733 004442 004737 006226                    JSR      PC,TYPEIT             ;ECHO CHAR.
734 004446 120127 000054                    CMPB    R1,@54                 ;CHAR. = TO ', '?
735 004452 001410                    BEQ      38                      ;YES, SAVE IT
736 004454 120127 000060                    CMPB    R1,@60                 ;LEGAL NO.?
737 004460 002403                    BLT      28                      ;NO
738 004462 120127 000071                    CMPB    R1,@71                 ;
739 004466 003402                    BLE      38                      ;YES
740 004470 000137 003500          28:    JMP      @MARK                ;NO, TYPE '?'
741 004474 110177 010312          38:    MOVB    R1,@TTYPTR           ;SAVE CHAR. IN TTY BUFFER
742 004500 005237 015012                    INC      TTYPTR                ;UPDATE POINTER
743 004504 105077 010302                    CLRB    @TTYPTR                ;TERMINATE BUFFER WITH NULL
744 004510 042701 177770                    BIC      @177770,R1            ;STRIP
745 004514 006337 015044                    ASL     DEVADR                 ;LEFT JUSTIFY '3' PLACES
746 004520 006337 015044                    ASL     DEVADR                 ;
747 004524 006337 015044                    ASL     DEVADR                 ;
748 004530 060137 015044                    ADD     R1,DEVADR              ;THEN ADD NEW DIGIT
749 004534 000137 003540                    JMP     EXITK                    ;EXIT
750
751 004540 005737 015024          RUBOUT: TST      RUBSWH                ;IS THE RUBOUT SW. SET?
752 004544 001002                    BNE     18                      ;YES
753 004546 104000 014265                    PRINT,  SLASH                  ;
754 004552 005237 015024          18:    INC      RUBSWH                ;SET SW.
755 004556 005337 015012                    DEC     TTYPTR                ;BACK UP BUFFER POINTER
756 004562 117701 010224                    MOVB    @TTYPTR,R1            ;PICK UP PREVIOUS CHAR.

```

757 004566 105077 010220  
758 004572 004737 006226  
759 004576 013701 015044  
760 004602 042701 177770  
761 004606 006237 015044  
762 004612 006237 015044  
763 004616 006237 015044  
764 004622 000137 003540

CLRB 0TTYPTR ITERMNATE BUFFER  
JSR PC,TYPEIT IECHO CHAR,  
MOV DEVADR,R1  
BIC 0177770,R1  
ASR DEVADR  
ASR DEVADR  
ASR DEVADR  
JMP EXITKS IEXIT

\*\*\*\*\*  
SUBROUTINE ENTERED TO FORM THE ADDRESS AND REGISTER OFFSETS  
\*\*\*\*\*

770 004626 004737 004722  
771 004632 005001  
772 004634 005002  
773 004636 005003  
774 004640 017704 010070  
775 004644 062737 000002 014734  
776 004652 005704  
777 004654 001415  
778 004656 022704 000017  
779 004662 002005  
780 004664 012701 000077  
781 004670 004737 006226  
782 004674 000754  
783 004676 005202  
784 004700 062703 000002  
785 004704 005304  
786 004706 001373  
787 004710 016304 014336  
788 004714 005024  
789 004716 005024  
790 004720 000207

FORMIT: JSR PC,GETLN1 IFORM LINE NO.  
FORMON: CLR R1  
CLR R2  
CLR R3  
MOV 0BCOPTR,R4 IPICK UP LINE NUMBER  
ADD 02,BCOPTR IUPDATE POINTER FOR NEXT ENTRY  
TST R4 IIS THE LINE NO. '0'?  
BEQ 18 IYES, NO WORK NEEDED  
CMP 015.,R4 ILEGAL LINE NO?  
BGE 28 IYES  
MOV 077,R1  
JSR PC,TYPEIT  
BR FORMIT  
281 INC R2 IUPDATE LINE NO.  
ADD 02.,R3 IFORM THE ADDRESS OFFSET  
DEC R4 IDONE?  
BNE 28 INO  
181 MOV 0UFADR(R3),R4 ISET UP THE BUFFER ADDRESS POINTER  
CLR (R4)+  
CLR (R4)+  
TST PC IRETURN

\*\*\*\*\*  
SUBROUTINE TO ENABLE FORMING OF A LINE NUMBER  
\*\*\*\*\*

795 004722 005037 015044  
796 004726 005037 015030  
797 004732 005037 016926  
798 004736 012737 016926 015012  
799 004744 052777 000100 174230  
800 004752 005077 174222  
801 004756 013777 015022 174226 181  
802 004764 023727 015030 000015  
803 004772 001371  
804 004774 004737 010050  
805 005000 104000 014260  
806 005004 000207

GETLN1: CLR DEVADR ISET UP TO GET LINE NUMBER  
CLR SCHAR  
CLR TTYBUF  
MOV 0TTYBUF,TTYPTR ISET UP BUFFER POINTER  
BIS 0100,0TKS IENABLE TTY INTERRUPTS  
CLR 0PSW IGET LINE NO.  
181 MOV ACTIVE,0SHR IDISPLAY SYSTEM STATUS  
CMP SCHAR,015 IEXIT ON CARRIAGE RETURN  
BNE 18  
JSR PC,0COBIN ICONVERT LINE NO. TO OCTAL  
PRINT ,CRLF  
RTS PC

\*\*\*\*\*  
ENTERED HERE ON RECEIPT OF A 'L' TO LIST SYSTEM STATUS. THE 'L'  
OPTION CAN BE USED IN ONE OF TWO WAYS: (1) TYPE 'L (CR)' TO PRINT THE

810

```

811
812
813
814
815 005006 005077 174166
816 005012 004737 004626
817 005016 012701 000020
818 005022 104000 012415
819 005026 010337 015032
820 005032 006237 015032
821 005036 104000 014260
822 005042 104002 015032
823 005046 016337 015222 015120
824 005054 104002 015120
825 005060 016337 015370 015120
826 005066 104002 015120
827 005072 016337 015474 015120
828 005100 104002 015120
829 005104 016337 015432 015120
830 005112 104002 015120
831 005116 016337 015600 015120
832 005124 104002 015120
833 005130 016337 015536 015120
834 005136 104002 015120
835 005142 005037 015120
836 005146 036337 014276 014614
837 005154 001402
838 005156 005237 015120
839 005162 104002 015120
840 005166 005037 015120
841 005172 036337 014276 015150
842 005200 001402
843 005202 005237 015120
844 005206 104002 015120
845 005212 010302
846 005214 006302
847 005216 016237 014512 014440
848 005224 062702 000002
849 005230 016237 014512 014442
850 005236 005037 014444
851 005242 104000 014440
852 005246 005237 015032
853 005252 062703 000002
854 005256 105737 016526
855 005262 001002
856 005264 005301
857 005266 001263
858 005270 005337 014732
859 005274 003403
860 005276 004737 004632
861 005302 000651
862 005304 000137 003530
863
864

```

STATUS OF ALL DH11 LINES. (2) TYPE 'L & LINE NO.' TO PRINT THE STATUS  
OF SPECIFIED LINE(S).  
\*\*\*\*\*

```

CONL: CLR      PPSW      ;ENABLE FURTHER INTERRUPTS
      JSR      PC,FORMIT ;FORM THE LINE NUMBER
      MOV      @16.,R1   ;SET UP THE NO. OF DH LINES
      PRINT,   MESS      ;PRINT HEADER
181   MOV      R3,LINNO
      ASR      LINNO     ;SET UP THE LINE NO.
281   PRINT,   CRLF
      BINDEC,  LINNO     ;PRINT THE LINE NO.
      MOV      RECNTR(R3),TEMP ;PRINT NO. OF BLOCKS RECEIVED
      BINDEC,  TEMP
      MOV      OR(R3),TEMP ;PRINT NO. OF OVERRUN ERRORS
      BINDEC,  TEMP
      MOV      PAR(R3),TEMP ;PRINT NO. OF PARITY ERRORS
      BINDEC,  TEMP
      MOV      PRM(R3),TEMP ;PRINT NO. OF FRAMING ERRORS
      BINDEC,  TEMP
      MOV      TRN(R3),TEMP ;PRINT NO. OF TRANSMITTER ERRORS
      BINDEC,  TEMP
      MOV      ST(R3),TEMP  ;PRINT NO. OF START CODE ERRORS
      CLR      TEMP
      BIT      LINENO(R3),HOLDSW ;IS THIS LINE BEING HELD?
      BEQ     .+6         ;NO
      INC     TEMP
      BINDEC,  TEMP      ;PRINT STATUS IF HELD
      CLR     TEMP
      BIT     LINENO(R3),PENDIN ;IS THIS LINE PENDING?
      BEQ     .+6         ;NO
      INC     TEMP
      BINDEC,  TEMP      ;PRINT STATUS OF PENDING
      MOV     R3,R2
      ASL     R2
      MOV     BAUDMS(R2),MSGBUF
      ADD     @2,R2
      MOV     BAUDMS(R2),MSGBUF+2
      CLR     MSGBUF+4
      PRINT,  MSGBUF     ;PRINT THE LINE BAUD RATE
      INC     LINNO     ;UPDATE THE LINE NO.
      ADD     @2,R3     ;UPDATE THE OFFSET NO.
      TSTB   TTYBUF    ;WAS A SPECIFIED LINE REQUESTED?
      BNE    38        ;YES, EXIT
      DEC    R1         ;NO, DONE ALL LINES?
      BNE    28        ;NO
381   DEC     BCOCTR    ;DONE ALL LINES?
      BLE    48        ;YES, EXIT
      JSR    PC,FORMON  ;NO SET UP NEXT LINE
      BR     18
481   JMP     PRYDOT

```

\*\*\*\*\*

```

865 JVERIFY LINE ROUTINE
866 JENTERED HERE ON RECEIPT OF A "V". THIS ROUTINE IS USED TO VERIFY THAT A
867 JSELECTED DH11 LINE OR LINES ARE FUNCTIONING I.E. TRANSMITTING & RECEIVING.
868 JTO CALL THIS ROUTINE, TYPE: "V LINE NO, LINE NO,..."(CR). THE SELECTED
869 JLINE(S) WILL THEN HAVE A CODE OF '125' TRANSMITTED OVER THEM (REFER TO NOTE).
870 JA CHECK IS THEN MADE THAT ALL LINES RESPONDED WITHIN 16 MSEC. WITH THE
871 JCORRECT DATA. THIS CODE IS TRANSMITTED '5' TIMES PER LINE AND THEN THE
872 JMESSAGE: "LINE XXX VERIFIED OK" IS TYPED. IF A LINE FAILS TO RESPOND,
873 JTHE MESSAGE: "LINE XXX NO VERIFY DATA RETURNED" IS TYPED. IF A
874 JLINE RESPONDS BUT THE DATA IS INVALID, THE MESSAGE: "LINE XXX VERIFY DATA
875 JERROR, SENT -125 RECV'D-XXX" IS TYPED.
876 J
877 JNOTE: IN ORDER FOR THIS TEST TO FUNCTION, EITHER 'TST21' OF THE VT20
878 JDIAGNOSTIC MUST BE LOADED AND RUNNING WITH 'SW00 & SW01' SET OR THE
879 JFOLLOWING DL11 ECHO PATCH ROUTINE MUST BE TOGGLED INTO THE VT20
880 JSYSTEM UNDER TEST.
881 J
882 J1000/ 105737 1756X0 TSTB @DLRCSR JWAIT FOR DATA
883 J1004/ 100375 BPL :=4
884 J1006/ 113737 1756Y2 1756N6 MOVB @DLRBUF,@DLXBUF
885 J1014/ 771 BR :=14 JWAIT FOR NEXT CHAR
886 J
887 JWHERE: = ADDRESS OF SELECTED DL11 RECEIVER CONTROL STATUS REGISTER
888 J = ADDRESS OF SELECTED DL11 RECEIVER DATA BUFFER REGISTER
889 J NNNNNN= ADDRESS OF SELECTED DL11 TRANSMITTER DATA BUFFER REGISTER
890 J*****
891
892 005310 004737 004626 JVERIFY: JSR PC,FORMIT JFORM THE SELECTED LINE NUMBER
893 005314 013737 014732 005544 MOV BCDCTR,LINSTR JSTORE LINE COUNT IN CASE LOOP SET
894 005322 056337 014276 015004 VPRPT: BIS LINENO(R3),SYSSW1
895 005330 012763 000001 014626 MOV @1,VRFPSWH(R3) JSET THE VERIFY SWITCH
896 005336 004737 005406 JSR PC,VRFPSND JTRANSMIT THE VERIFY CHARACTER
897 005342 005337 014732 VERNXT: DEC BCDCTR JDONE ALL LINES?
898 005346 001403 BEQ VRFEXT JYES,CHECK REPEAT FLAG
899
900 005350 004737 004632 VERLNI: JSR PC,FORMON JNO, FORM THE NEXT LINE NUMBER
901 005354 000762 BR VPRPT
902 005356 005737 005546 VRFEXT: TST VRFEXT JREPEAT?
903 005362 001407 BEQ 38 JNO-EXIT
904 005364 013737 005544 014732 MOV LINSTR,BCDCTR JRESET LINE COUNTER
905 005372 012737 014736 014734 MOV @BCDUP,BCDPTR JRESET THE LINE POINTER
906 005400 000763 BR VERLNI JAND REPEAT TESTS
907 005402 000137 003530 381 JMP PRYDOT
908
909 005406 036337 014276 015146 VRFPSND: BIS LINENO(R3),RECSWH JIS LINE CURRENTLY RECEIVING?
910 005414 001004 BNE 18 JYES, REPORT LINE AS ACTIVE
911 005416 036337 014276 015152 BIS LINENO(R3),TRNSWH JIS LINE TRANSMITTING?
912 005424 001413 BEQ 28 JNO, LINE IS IDLE
913 005426 046337 014276 015004 181 BIC LINENO(R3),SYSSW1 JCLEAR THE VERIFY REQUEST SW.
914 005434 005737 005546 TST VRFEXT JCONTROL XT
915 005440 001004 BNE 100 JYES-BYPASS ERROR LOGGING
916 005442 112720 000015 MOVB @15,(R0)+ JLINE IS ACTIVE, CAN'T VERIFY
917 005446 110310 MOVB R3,(R0) JSET UP LINE NUMBER
918 005450 106220 ASRB (R0)+

```

919	005452	000207		108:	RTS	PC				
920	005454	010302		281	MOV	R3,R2				);EXIT IF NO OTHER LINES TO BE CHECKED
921	005456	006202			ASR	R2				);SET UP THE LINE NUMBER
922	005460	052702	030100		BIS	330100,R2				
923	005464	012777	000340	173506	MOV	0340,0PSW				);TEMPORARILY INHIBIT INTERRUPTS
924	005472	010277	173524		MOV	R2,0DMSCR				
925	005476	012777	177777	173526	MOV	0-1,0DMBCR				);SET UP BYTE COUNT
926	005504	012777	005542	173516	MOV	0VERDAT,0DMCAR				);SET UP THE CURRENT ADDRESS
927	005512	056337	014276	015152	BIS	LINENO(R3),TRNSHW				);SET TRANSMITTER SW.
928	005520	056337	014276	015022	BIS	LINENO(R3),ACTIVE				
929	005526	056377	014276	173500	BIS	LINENO(R3),0DMBAR				);START THE TRANSMITTER
930	005534	005077	173440		CLR	0PSW				
931	005540	000207			VEREXT:	RTS	PC			
932										
933	005542	052525			VERDAT:	52525				
934	005544	000000			LINSTR:	0				);TEMP STORAGE FOR LINE COUNT
935	005546	000000			VERPT:	0				);VERIFY REPEAT FLAG
936										
937										
938										
939										
940										
941										
942										
943										
944										
945										
946										
947										
948										
949	005550	004737	004626		BOOT:	JSR	PC,FORMIT			);WAIT FOR LINE NUMBERS
950	005554	013737	014732	015130		MOV	BCDCTR,KSTOR4			);SAVE NO. OF LINE SET UP
951	005562	005037	014624			CLR	BOOTLN			);SET UP TO SAVE LINES TO BE BOOTED
952	005566	056337	014276	014624	BOOT1:	BIS	LINENO(R3),BOOTLN			
953	005574	005337	014732			DEC	BCDCTR			);SET UP ALL LINES?
954	005600	001403				BEQ	BOOT2			);YES,
955	005602	004737	004632			JSR	PC,FORMON			);NO, FORM OFFSETS FOR NEXT LINE
956	005606	000767				BR	BOOT1			
957	005610	005237	014620		BOOT2:	INC	BOOTFG			);SET TO INDICATE THAT READER IS ACTIVE
958	005614	005737	015154			TST	RCSR			);HAS READER ADDRESS BEEN SETUP?
959	005620	001030				BNE	BOOT4			);YES
960	005622	104000	012525		BOOT3:	PRINT,	ME811			);REQUEST READER DEVICE ADDRESS
961	005626	004737	004722			JSR	PC,GETLN1			);GET IT
962	005632	013701	015044			MOV	DEVAOR,R1			
963	005636	005701				TST	R1			);HAS ONE ENTERED?
964	005640	001770				BEQ	BOOT3			);NO, MAKE HIM DO IT
965	005642	010137	015154			MOV	R1,RCSR			);YES, SET IT UP
966	005646	062701	000002			ADD	02,R1			
967	005652	010137	015156			MOV	R1,RDBR			
968	005656	104000	012767			PRINT,	ME813			);ASK FOR VECTOR ADDRESS
969	005662	004737	004722			JSR	PC,GETLN1			);GET IT
970	005666	013701	015044			MOV	DEVAOR,R1			
971	005672	012721	005736			MOV	0READER,(R1)+			);SET UP READER SERVICE ROUTINE
972	005676	012711	000200			MOV	0200,(R1)			);SET BR LEVEL 04



```

973 005702 012737 016570 015052 BOOT4: MOV @READBF,BOOTP2
974 005710 005037 015036 CLR REDONE ;CLEAR READ TRANSMIT DONE COUNTER
975 005714 005037 015056 CLR READCT
976 005720 012777 000101 007226 MOV @101,@RCSR ;SET GO & INTERRUPT ENABLE FOR READER
977 005726 005037 015010 CLR SYSSWH
978 005732 000137 003540 JMP EXITK ;EXIT
979
980 ;*****
981 ;READER INTERRUPT SERVICE ROUTINE
982 ;THIS ROUTINE READS UP TO '64' CHARACTERS FROM THE PAPERTAPE READER AND THEN
983 ;TRANSMITS THEM TO SPECIFIED LINE OR LINES ENTERED BY ('B).
984 ;READER ERROR CODES ARE AS FOLLOWS:
985 ;05 = ILLEGAL READER INTERRUPT
986 ;*****
987
988 005736 010146 READER: MOV R1,-(SP) ;SAVE WORKING REGISTERS
989 005740 010246 MOV R2,-(SP)
990 005742 010346 MOV R3,-(SP)
991 005744 017737 007204 015002 MOV @RCSR,@RSTAT ;SAVE READER STATUS
992 005752 017737 007200 015000 MOV @RDBR,RCHAR ;READ & SAVE CHAR.
993 005760 013702 015052 MOV BOOTP2,R2 ;SET UP THE READER BUFFER POINTER
994 005764 005737 014620 TST BOOTPG ;IS READER ACTIVE?
995 005770 001006 BNE READ1 ;YES, LEGAL INTERRUPT
996 005772 112720 000005 MOV# 005,(R0)+ ;CODE FOR ILLEGAL READER INTERRUPT
997 005776 105020 CLRB (R0)+ ;LINE NO, IS NOT APPLICABLE
998 006000 005077 007150 CLR @RCSR ;DISABLE FURTHER READER INTERRUPTS
999 006004 000504 BR READ4 ;EXIT
1000 006006 005737 015002 READ1: TST RSTAT ;END OF TAPE FLAG SET?
1001 006012 100416 BMI READ2 ;YES, EXIT
1002 006014 113722 015000 MOV# RCHAR,(R2)+ ;SAVE CHAR IN READER BUFFER
1003 006020 010237 015052 MOV R2,BOOTP2 ;SAVE BUFFER POINTER
1004 006024 005237 015056 INC READCT ;KEEP TRACK OF NO. OF CHAR'S READ.
1005 006030 022737 000100 015056 CMP @64,,READCT ;READ '64' CHAR'S?
1006 006036 001413 BEQ READ3 ;YES
1007 006040 012777 000101 007106 MOV @101,@RCSR ;START NEXT READ
1008 006046 000463 BR READ4 ;EXIT
1009 006050 005077 007100 READ2: CLR @RCSR ;DISABLE READER INTERRUPT
1010 006054 005037 014620 CLR BOOTPG ;CLEAR THE SOFTWARE SW.
1011 006060 005737 015056 TST READCT ;ANY DATA TO TRANSMIT?
1012 006064 001452 BEQ READ3 ;NO, EXIT
1013
1014 ;AT THIS POINT EITHER THE READER BUFFER IS FULL (64 CHARACTERS) OR THE END OF
1015 ;TAPE POINT HAS BEEN REACHED. THE TRANSMITTERS ARE NOW SET UP TO
1016 ;TRANSMIT THE READER BUFFER.
1017
1018 006066 005003 READ3: CLR R3
1019 006070 005437 015056 NEG READCT
1020 006074 036337 014276 014624 ;BI BIT LINENO(R3),BOOTLN ;BOOTING THIS LINE?
1021 006102 001433 BEQ 20 ;NO
1022 006104 010302 MOV R3,R2
1023 006106 006202 ASR R2 ;'R2' NOW = TO A LINE NO.
1024 006110 052702 030100 BIS @30100,R2 ;ASSEMBLE 'SCR' WORD
1025 006114 012777 000340 173056 MOV @340,@PSW ;TEMPORARILY INHIBIT INTERRUPTS
1026 006122 010277 173074 MOV R2,@DMSCR

```

```

1027 006126 013777 015056 173076      MOV      READCT,0DHBCR      ;SET UP BYTE COUNT
1028 006134 012777 016570 173066      MOV      @READBP,0DMCAR    ;SET UP CURRENT ADDRESS
1029 006142 056337 014276 014622      BIS      LINENO(R3),BOOTSW ;SET THE BOOT SW.
1030 006150 056337 014276 015022      BIS      LINENO(R3),ACTIVE ;SET ACTIVE WHEN TRANSMITTING
1031 006156 056377 014276 173050      BIS      LINENO(R3),0DHBAR ;START THE TRANSMITTER
1032 006164 012777 000200 173006      MOV      @200,0PSW        ;RE-SET BR 04
1033 006172 062703 000002 281      ADD      @2,R3             ;SET UP TO GET THE NEXT LINE NO.
1034 006176 022703 000040      CMP      @32,,R3          ;SERVICED ALL LINES?
1035 006202 001334      BNE      18               ;NO
1036 006204 005737 015002      TST      RSTAT           ;WAS END OF TAPE REACHED?
1037 006210 100002      BPL      READ4           ;NO
1038 006212 104000 014262  READ3A1 PRINT, DOT        ;YES,
1039 006216 012603  READ41 MOV      (SP)+,R3
1040 006220 012602      MOV      (SP)+,R2
1041 006222 012601      MOV      (SP)+,R1
1042 006224 000002      RTI                      ;EXIT
1043
1044      ;*****
1045      ;SUBROUTINE TO TYPE THE CHARACTER IN 'R1'
1046      ;*****
1047
1048 006226 013777 015022 172756  TYPEIT: MOV      ACTIVE,0SHR    ;DISPLAY SYSTEM STATUS
1049 006234 105777 172746      TSTB     @TPS            ;WAIT FOR PRINTER
1050 006240 100372      BPL      TYPEIT
1051 006242 110177 172742      MOVB    R1,@TPB         ;OUTPUT CHAR.
1052 006246 000207      RTS      PC
1053
1054      ;*****
1055      ;KWL1 LINE CLOCK SERVICE ROUTINE
1056      ;ENTERED HERE ON RECEIPT OF CLOCK INTERRUPTS. THIS ROUTINE SIMPLY INCREMENTS
1057      ;A CLOCK COUNTER (USED TO CHECK SYSTEM STATUS) AND THEN SERVICES THE RECEIVER
1058      ;SILO.
1059      ;*****
1060
1061 006250 005237 015006  CLKSRV: INC      CLKCTR    ;UPDATE THE COUNTER
1062 006254 000400      BR      RECVER          ;SERVICE RECEIVER SILO
1063
1064      ;*****
1065      ;SUBROUTINE ENTERED TO SERVICE ALL DH11 RECEIVER INTERRUPTS.
1066      ;R0=ERROR ADDRESS POINTER
1067      ;R1=DATA BUFFER ADDRESS OFFSET (BUFFERS ARE 512 BYTES APART)
1068      ;R2=DEVICE REGISTER ADDRESS OFFSET
1069      ;R3=UNIT ADDRESS OFFSET
1070      ;R4=DATA BUFFER ADDRESS POINTER
1071      ;RECEIVER ERROR CODES ARE AS FOLLOWS:
1072      ;00 = ILLEGAL RECEIVER INTERRUPT
1073      ;01 = OVERRUN ERROR
1074      ;02 = FRAMING ERROR
1075      ;03 = PARITY ERROR
1076      ;04 = ILLEGAL START CODE
1077      ;07 = ATTEMPT TO RECEIVE DATA WHILE IN SEND MODE
1078      ;11 = VERIFIED 'OK'
1079      ;12 = VERIFY DATA ERROR
1080      ;17 = DATA CHECK ERROR, SENT=000 RECV'D=XXX

```

```

1001
1002
1003 006256 010146
1004 006260 010246
1005 006262 010346
1006 006264 010446
1007 006266 017702 172732
1008 006272 010203
1009 006274 000303
1090 006276 042703 177760
1091 006302 006303
1092 006304 005702
1093 006306 100402
1094 006310 000137 007132
1095 006314 036337 014276 014616 181
1096 006322 001412
1097 006324 005263 015642
1098 006330 022763 000005 014670
1099 006336 002753
1100 006340 112720 000007
1101 006344 000137 007116
1102
1103 006350 032702 070000
1104 006354 001444
1105 006356 032702 040000
1106 006362 001412
1107 006364 005263 015370
1108 006370 022763 000005 014670
1109 006376 002733
1110 006400 112720 000001
1111 006404 000137 007116
1112
1113 006410 032702 020000
1114 006414 001412
1115 006416 005263 015432
1116 006422 022763 000005 014670
1117 006430 002716
1118 006432 112720 000002
1119 006436 000137 007116
1120
1121 006442 005263 015474
1122 006446 022763 000005 014670
1123 006454 002704
1124 006456 112720 000003
1125 006462 000137 007116
1126
1127 006466 016304 014376
1128 006472 036337 014276 015146
1129 006500 001116
1130 006502 036337 014276 015020
1131 006510 001414
1132 006512 046337 014276 015020
1133 006520 122702 000125
1134 006524 001660

```

```

.....
RECVR1: MOV R1, -(SP) ;SAVE WORKING REGISTERS
MOV R2, -(SP)
MOV R3, -(SP)
MOV R4, -(SP)
RECNEXT: MOV @DHNRC, R2 ;READ NEXT WORD FROM THE SILO
MOV R2, R3
SWAB R3 ;SET UP TO USE LINE NO. AS OFFSET
BIC @177760, R3
ABL R3
TST R2 ;IS CHARACTER VALID?
BHI 18 ;YES
JMP RECVT ;NO, SILO IS EMPTY, EXIT
BIT LINENO(R3), SENDSW ;IS THIS LINE IN SEND MODE?
BEQ RECVR1 ;NO
INC @ND(R3) ;KEEP TRACK OF NO. OF SEND ERRORS
CMP @5, ERRCTR(R3) ;HAS UNIT EXCEEDED ERROR LIMIT?
BLT RECNEXT ;YES, SERVICE THE NEXT CHAR.
MOVB @07, (R0)+ ;NO, POST AS SEND ERROR
JMP RECERR

RECVR1: BIT @70000, R2 ;ANY RECEIVER ERROR FLAGS SET?
BEQ RECVR2 ;NO, VALID CHAR.
BIT @40000, R2 ;YES, IS IT AN OVERRUN ERROR?
BEQ FRAMER ;NO
INC @R(R3) ;KEEP TRACK OF OVERRUN ERRORS
CMP @5, ERRCTR(R3) ;HAS UNIT EXCEEDED ERROR LIMIT?
BLT RECNEXT ;YES, SERVICE NEXT CHAR.
MOVB @01, (R0)+ ;YES, POST AS OVERRUN ERROR
JMP RECERR

FRAMER: BIT @20000, R2 ;IS IT A FRAMING ERROR?
BEQ PARITY ;NO
INC @RM(R3) ;KEEP TRACK OF FRAMING ERRORS
CMP @5, ERRCTR(R3) ;HAS UNIT EXCEEDED ERROR LIMIT?
BLT RECNEXT ;YES, SERVICE NEXT CHAR.
MOVB @02, (R0)+ ;YES, POST AS FRAMING ERROR
JMP RECERR

PARITY: INC @PAR(R3) ;KEEP TRACK OF PARITY ERRORS
CMP @5, ERRCTR(R3) ;HAS UNIT EXCEEDED ERROR LIMIT?
BLT RECNEXT ;YES, SERVICE NEXT CHAR.
MOVB @03, (R0)+ ;POST AS PARITY ERROR
JMP RECERR

RECVR2: MOV @UPPTR(R3), R4 ;SET UP DATA BUFFER POINTER
BIT LINENO(R3), RECSW ;IS THIS LINE CURRENTLY RECEIVING?
BNE RECVR4 ;YES, SAVE CHAR.
BIT LINENO(R3), RECVCK ;MAINT. CHECKING THIS RECEIVER?
BEQ 38 ;NO
BIC LINENO(R3), RECVCK ;YES, CLEAR THE CHECK SW.
CMPB @125, R2 ;IS THE CHECK CHAR. = 125
BEQ RECNEXT ;YES, IT IS OK

```

1135	006526	112720	000017		MOVB	017,(R0)+	INO, POST AS A DATA CHECK ERROR	
1136	006532	110310			MOVB	R3,(R0)	ISAVE LINE NO.	
1137	006534	106220			ASRB	(R0)+		
1138	006536	110220			MOVB	R2,(R0)+	ISAVE RECV'D CHAR.	
1139	006540	000652			BR	RECXYT	ISERVICE THE NEXT CHAR.	
1140								
1141	006542	009763	014626	381	TST	VRFSWH(R3)	IVERIFYING THIS LINE?	
1142	006546	001439			BEQ	R4A	INO	
1143	006550	046337	014276	015004	BIC	LINENO(R3),SYSSW1	YES, CLEAR SOFTWARE SW.	
1144	006556	009737	005546		TST	VERPT	CONTROL X?	
1145	006562	001163			BNE	RECEXT	YES BY-PASS ERROR CHECKING	
1146	006564	122702	000125		CMPB	0129,R2	YES, IS DATA CORRECT?	
1147	006570	001411			BEQ	R1A	YES	
1148	006572	112720	000012		MOVB	012,(R0)+	INO POST AS VERIFY DATA ERROR	
1149	006576	110310			MOVB	R3,(R0)	SET UP TO SAVE LINE NO.	
1150	006600	106220			ASRB	(R0)+		
1151	006602	110220			MOVB	R2,(R0)+	ISAVE THE BAD DATA	
1152	006604	004737	005406	R2A1	JSR	PC,VRFSND	SEND ANOTHER CHARACTER	
1153	006610	000137	006266		JMP	RECXYT	SERVICE THE NEXT CHARACTER	
1154								
1155	006614	005263	014626	R1A1	INC	VRFSWH(R3)		
1156	006620	022763	000006	014626	CMP	06,VRFSWH(R3)	HAVE WE HAD FIVE (5) GOOD TRANSFERS?	
1157	006626	001366			BNE	R2A	INO, START NEXT TRANSFER	
1158	006630	112720	000011		MOVB	011,(R0)+	YES, POST AS LINE VERIFIED	
1159	006634	005063	014626		CLR	VRFSWH(R3)	CHAR THE SW.	
1160	006640	000530			BR	RECER1	EXIT	
1161								
1162	006642	105702		R4A1	TSTB	R2	NULL CHAR.?	
1163	006644	001610			BEQ	RECXYT	YES, IGNORE IT	
1164	006646	122702	000377		CMPB	0377,R2	TO START CODE CHAR.?	
1165	006652	001413			BEQ	RECVR3	YES, SET UP TO RECEIVE DATA	
1166	006654	005263	015536		INC	ST(R3)		
1167	006660	022763	000005	014670	CMP	05,ERRCTR(R3)	HAS UNIT EXCEEDED ERROR LIMIT?	
1168	006666	003002			BGT	58		
1169	006670	000137	006266		JMP	RECXYT	YES, SERVICE NEXT CHAR.	
1170	006674	112720	000004	581	MOVB	004,(R0)+	INO, POST AS ILLEGAL START CODE	
1171	006700	000506			BR	RECERR		
1172								
1173							ENTERED HERE ON RECEIPT OF A START CODE (377)	
1174								
1175	006702	056337	014276	015146	RECVR31	BIS	LINENO(R3),RECSWH	SET RECEIVER SW.
1176	006710	046337	014276	015022		BIC	LINENO(R3),ACTIVE	KEEP TRACK OF SYSTEM STATUS
1177	006716	016304	014336		MOV	BUPADR(R3),R4	SET UP BUFFER ADDRESS POINTER	
1178	006722	005024			CLR	(R4)+		
1179	006724	005024			CLR	(R4)+		
1180	006726	012763	000004	015160	MOV	04,BYTECT(R3)	INITIALIZE BYTE COUNT	
1181	006734	000403			BR	REC4A		
1182								
1183							ENTERED HERE TO PROCESS THE CHAR. WHEN THE 'RECSWH' IS SET	
1184								
1185								
1186	006736	122702	000377		RECVR41	CMPB	0377,R2	CHAR. = TO START CODE?
1187	006742	001757				BEQ	RECVR3	YES, RE-SET RECEIVER
1188	006744	110224			REC4A1	MOVB	R2,(R4)+	SAVE CHARACTER IN BUFFER

1189	006746	005263	015160		INC	BYTECT(R3)	IUPDATE BYTE COUNT	
1190	006752	005737	015132		TST	RMODE	I RUNNING DATA REPORT MODE?	
1191	006756	001401			BEQ	RECVRS	INO	
1192	006760	110220			MOVB	R2,(R0)+	IYES, SAVE CHAR. IN ERROR BUFFER	
1193	006762	010463	014376	RECVR5:	MOV	R4,BUFPTR(R3)	ISAVE DATA BUFFER POINTER	
1194	006766	122702	000014		CMPS	0EOP,R2	ICHR, = END OF PARAGRAPH?	
1195	006772	001402			BEQ	,+6		
1196	006774	000137	006266		JMP	RECNTX	INO, SERVICE THE NEXT CHAR.	
1197	007000	046337	014276	015146	BIC	LINENO(R3),RECSWH	IYES, CLEAR THE RECEIVER SW.	
1198	007006	036337	014276	014614	BIT	LINENO(R3),HOLD5W	IS THIS LINE BEING HELD?	
1199	007014	001405			BEQ	RECVR6	INO, SET UP TO TRANSMIT	
1200	007016	056337	014276	015150	BIS	LINENO(R3),PENDIN	IYES, SET THE PENDING DATA SW.	
1201	007024	000137	006266		JMP	RECNTX	ISERVICE THE NEXT CHARACTER	
1202	007030	010301		RECVR6:	MOV	R3,R1		
1203	007032	006201			ASR	R1	I= TO CURRENT LINE NUMBER	
1204	007034	052701	030500		BIS	030500,R1	IASSEMBLE THE 'SCR' WORD	
1205	007040	010177	172156		MOV	R1,0DHSCR		
1206	007044	005463	015160		NEG	BYTECT(R3)	ICOMPLIMENT BYTE COUNT	
1207	007050	016377	015160	172154	MOV	BYTECT(R3),0DHBCR	ILOAD THE BYTE COUNT REG.	
1208	007056	016377	014336	172144	MOV	BUFADR(R3),0DHCAR	ILOAD THE CURRENT ADDRESS REGISTER	
1209	007064	056377	014276	172142	BIS	LINENO(R3),0DHBAR	ISTART THE TRANSMITTER.	
1210	007072	005263	015222		INC	RECNTX(R3)	ICOUNT NO. OF BLOCKS RECEIVED	
1211	007076	056337	014276	015152	BIS	LINENO(R3),TRNSWH	ISET TRNSMITTER SW.	
1212	007104	056337	014276	015022	BIS	LINENO(R3),ACTIVE	IKEEP TRACK OF SYSTEM STATUS	
1213	007112	000137	006266		JMP	RECNTX	ISERVICE THE NEXT CHAR.	
1214	007116	005263	014670	RECERR:	INC	ERRCTR(R3)	IKEEP TRACK OF NO. OF ERRORS	
1215	007122	110310		RECER1:	MOVB	R3,(R0)	IGET FAILING LINE NO.	
1216	007124	106220			ASRB	(R0)+	ISET IT UP TO BE PRINTED	
1217	007126	000137	006266		JMP	RECNTX	ISERVICE THE NEXT CHAR.	
1218	007132	012604		RECEXT:	MOV	(SP)+,R4	IRESTORE THE WORKING REGISTERS	
1219	007134	012603			MOV	(SP)+,R3		
1220	007136	012602			MOV	(SP)+,R2		
1221	007140	012601			MOV	(SP)+,R1		
1222	007142	000002			RTI			
1223								
1224								
1225								
1226								
1227								
1228								
1229								
1230								
1231	007144	042777	100000	172050	TRNMIT:	BIC	0100000,0DHSCR	ICLEAR THE INTERRUPT REQUEST
1232	007152	010146			MOV	R1,-(SP)	ISAVE THE WORKING REGISTERS	
1233	007154	010246			MOV	R2,-(SP)		
1234	007156	010346			MOV	R3,-(SP)		
1235	007160	013701	015022		MOV	ACTIVE,R1	IGET THE CURRENTLY ACTIVE TRANSMITTERS	
1236	007164	017702	172044		MOV	0DHBAR,R2	IREAD THE STATUS OF THE ACTIVE TRANSMITTERS	
1237	007170	040201			BIC	R2,R1	IR1 = TO TERMINATED TRANSMITTERS	
1238	007172	012702	000001		MOV	01,R2	IUSE 'R2' AS A POLLING BIT	
1239	007176	005003			CLR	R3	IUSE 'R3' AS ADDRESS OFFSET POINTER	
1240	007200	030201		TRAN1:	BIT	R2,R1	ITRANSMITTER DONE?	
1241	007202	001007			BNE	TRAN2	IYES, SERVICE IT	
1242	007204	006302		TRAN1A:	ASL	R2	INO, POLL NEXT RECEIVER	

\*\*\*\*\*  
 ISUBROUTINE ENTERED TO SERVICE ALL DM11 TRANSMITTER & NON-EX MEM. INTERRUPTS  
 ITRANSMITTER ERROR CODES ARE AS FOLLOWS:  
 I06 = ILLEGAL TRANSMITTER INTERRUPT  
 I10 = TRANSMITTER NON-EX MEMORY INTERRUPT  
 \*\*\*\*\*

1243	007206	062703	000002		ADD	02,R3	IUPDATE POINTER	
1244	007212	022703	000040		CMP	040,R3	I CHECKED ALL LINES?	
1245	007216	001370			BNE	TRAN1	I NO	
1246	007220	000444			BR	TRNEXT	I YES, EXIT	
1247	007222	036337	014276	014622	TRAN2:	BIT	LINENO(R3),BOOTSW	I BOOTING THIS LINE?
1248	007230	001411			BEG	TRAN3	I NO	
1249	007232	005237	015036		INC	REDONE	I YES, COUNT NO. OF LINE'S THAT HAVE FINISHED	
1250	007236	046337	014276	014622	BIC	LINENO(R3),BOOTSW	I CLEAR THE BOOT SW.	
1251	007244	046337	014276	015022	BIC	LINENO(R3),ACTIVE	I CLEAR LINE ACTIVE FLAG	
1252	007252	000754			BR	TRAN1A	I SERVICE THE NEXT LINE	
1253	007254	036337	014276	015152	TRAN3:	BIT	LINENO(R3),TRNSWH	I IS THIS TRANSMITTER ENABLED?
1254	007262	001012			BNE	TRAN4	I YES	
1255	007264	112720	000006		MOVB	006,(R0)+	I NO, SAVE AS ILLEGAL TRANSMITTER INTERRUPT	
1256	007270	004737	007276		JBR	PC,TRNERR	I SET UP TO REPORT ERROR	
1257	007274	000743			BR	TRAN1A	I SERVICE THE NEXT LINE	
1258								
1259	007276	005263	014670		TRNERR:	INC	ERRCTR(R3)	I KEEP TRACK OF NO. OF ERRORS
1260	007302	110310			MOVB	R3,(R0)		
1261	007304	106220			ASRB	(R0)+	I SAVE THE FAILING LINE NO.	
1262	007306	000207			RTS	PC	I RETURN	
1263								
1264	007310	046337	014276	015152	TRAN4:	BIC	LINENO(R3),TRNSWH	I CLEAR THE TRANSMITTER SW.
1265	007316	005263	015264		INC	XPERCT(R3)	I COUNT NO. OF BLOCKS TRANSFERRED	
1266	007322	046337	014276	015022	BIC	LINENO(R3),ACTIVE	I CLEAR LINE ACTIVE FLAG	
1267	007330	000725			BR	TRAN1A	I SERVICE THE NEXT LINE	
1268	007332	032777	002000	171662	TRNEXT:	BIT	02000,0DMSCR	I NON-EX MEMORY INTERRUPT?
1269	007340	001407			BEG	10	I NO	
1270	007342	052777	000400	171652	BIS	0400,0DMSCR	I CLR NON-EX MEM. INTERRUPT	
1271	007350	112720	000010		MOVB	010,(R0)+	I YES, SET UP ERROR CODE	
1272	007354	004737	007276		JBR	PC,TRNERR	I REPORT IT	
1273	007360	012603			181	MOV	(SP)+,R3	I RESTORE THE WORKING REGISTERS
1274	007362	012602			MOV	(SP)+,R2		
1275	007364	012601			MOV	(SP)+,R1		
1276	007366	000002			RTI			

\*\*\*\*\*  
 I MESSAGE PRINT ROUTINE, ENTERED VIA EMT DISPATCH HANDLER.  
 I ROUTINE PICKS UP CONTENTS OF THE 'PC' AND USES THIS AS  
 I THE ADDRESS OF MESSAGE TO BE TYPED.  
 \*\*\*\*\*

1284	007370	003077	171604		TYPMES:	CLR	0PSH	
1285	007374	010237	015016		MOV	R2,TYPSV2		I SAVE R2
1286	007400	017602	000000		MOV	0(SP),R2		I SET THE MESSAGE ADDRESS FROM START
1287	007404	062716	000002		ADD	02,(SP)		I SET UP STACK TO EXIT
1288	007410	010146			MOV	R1,-(SP)		I SAVE R1
1289	007412	005037	015134		CLR	PRTCNT		
1290	007416	005737	015026		TYPERA:	TST	0SWITCH	I IS THE 'O' SWITCH SET?
1291	007422	001103			BNE	TYPEXT		I YES, SUPPRESS PRINTING & EXIT
1292	007424	005737	007646		TST	PRTERR		I INHIBIT PRINT SWITCH SET?
1293	007430	001100			BNE	TYPEXT		I YES-EXIT
1294	007432	112201			MOVB	(R2)+,R1		I NO, PICK UP CHAR.
1295	007434	105701			TSTB	R1		I TEST FOR NULL CHARACTER
1296	007436	001475			BEG	TYPEXT		I IF SO, EXIT

```

1297 007440 122701 000012          CMPB   012,R1          JTEST FOR LINE FEED
1298 007444 001003          BNE    18             JNO
1299 007446 004737 007560          JSR    PC,TYPECL     JYES, TYPE 'CR/LF'
1300 007452 000761          BR     TYPEPA
1301 007454 122701 000377          18:    CMPB   0377,R1          JTEST FOR START CODE
1302 007460 001455          BEQ    TYPEPB
1303 007462 122701 000014          CMPB   0EOP,R1       JTEST FOR 'END OF PARAGRAPH'
1304 007466 001447          BEQ    TYPEOP        JTYPE '(EOP)'
1305 007470 122701 000045          CMPB   045,R1        JTEST FOR 'X'
1306 007474 001003          BNE    28             JNO
1307 007476 004737 007560          JSR    PC,TYPECL     JYES, TYPE 'CR/LF'
1308 007502 000745          BR     TYPEPA
1309 007504 122701 000040          28:    CMPB   040,R1          JIS THIS CHAR. PRINTABLE?
1310 007510 003410          BLE    38             JYES, PRINT IT
1311 007512 010146          MOV    R1,-(SP)      JNO, SAVE IT
1312 007514 012701 000336          MOV    0336,R1      JPRINT IT AS A CONTROL CHAR.
1313 007520 004737 007540          JSR    PC,OUTPUT
1314 007524 012601          MOV    (SP)+,R1
1315 007526 052701 000100          BIS    0100,R1      JRETRIEVE CHAR.
1316 007532 004737 007540          38:    JSR    PC,OUTPUT      JMAKE IT PRINTABLE
1317 007536 000727          BR     TYPEPA
1318
1319 007540 004737 006226          OUTPUT: JSR    PC,TYPEIT
1320 007544 005237 015134          INC    PRTCNT
1321 007550 022737 000100 015134          CMP    064,,PRTCNT  JLINE FULL?
1322 007556 003012          BGT    TYPEPRET      JNO, CHECK NEXT CHAR.
1323 007560 005037 015134          TYPECL: CLR    PRTCNT
1324 007564 012701 000015          MOV    015,R1
1325 007570 004737 006226          JSR    PC,TYPEIT    JTYPE 'CR'
1326 007574 012701 000012          MOV    012,R1
1327 007600 004737 006226          JSR    PC,TYPEIT    JTYPE 'LF'
1328 007604 000207          TYPEPRET: RTS    PC      JRETURN
1329
1330 007606 012702 013215          TYPEOP: MOV    0EOPMSG,R2
1331 007612 000701          BR     TYPEPA
1332
1333 007614 012701 000336          TYPEPB: MOV    0336,R1
1334 007620 004737 006226          JSR    PC,TYPEIT    JPRINT '#'
1335 007624 004737 007560          JSR    PC,TYPECL     JTYPE 'CR/LF'
1336 007630 000672          BR     TYPEPA
1337
1338 007632 005037 015026          TYPEXT: CLR    0SWITCH    JCLEAR THE 'O' SOFTWARE SWITCH
1339 007636 013702 015016          MOV    TYPV2,R2      JRESTORE R2
1340 007642 012601          MOV    (SP)+,R1      JRESTORE R1
1341 007644 000002          RTI
1342 007646 000000          PRTER: 0             JPRINT INHIBIT SWITCH
1343
1344
1345
1346          J*****
1347          JSUBROUTINE TO TYPEOUT A '3 OR 6' DIGIT OCTAL NO. THE 'PC' CONTAINS
1348          JTHE ADDRESS OF 'NUMBER' TO BE TYPED
1349          J*****
1350 007650 005077 171324          OCTPRT: CLR    0PSW

```

```

1351 007654 005737 007646      TST      PRERR      ;INHIBIT ERROR PRINT?
1352 007660 001057      BNE      OCTEXT    ;YES=EXIT
1353 007662 010137 010022      MOV      R1,OCTSV1 ;SAVE R1
1354 007666 010237 010024      MOV      R2,OCTSV2 ;SAVE R2
1355 007672 017601 000000      MOV      0(SP),R1  ;THE ADDRESS OF WORD TO BE TYPED
1356 007676 062716 000002      ADD      02,(SP)   ;SET UP STACK TO EXIT
1357 007702 005737 010026      TST      OCTSV3    ;PRINT '6' DIGITS?
1358 007706 001402      BEQ      .+6       ;YES
1359 007710 042711 177400      BIC      0177400,(R1) ;NO,STRIPE TO '3' DIGITS
1360 007714 012737 000006 015126      MOV      06,KSTOR3
1361 007722 012737 000376 010030      MOV      0376,MASK ;MASK FOR FIRST BIT
1362 007730 000401      BR       .+4
1363 007732 006111      MOVEIT: ROL      (R1)
1364 007734 006111      ROL      (R1)
1365 007736 006111      ROL      (R1)
1366 007740 005337 010026      DEC      OCTSV3
1367 007744 002013      BGE      MOVEON
1368 007746 111102      MOV      (R1),R2
1369 007750 143702 010030      BIC      MASK,R2
1370 007754 052702 000260      BIS      0260,R2
1371 007760 132777 000200 171220      BIT      0200,0TP8
1372 007766 100374      SPL      .-6
1373 007770 110277 171214      MOV      R2,0TP8  ;PRINT CHAR.
1374 007774 012737 000370 010030      MOVEON: MOV      0370,MASK ;MASK FOR NEXT '5' DIGITS
1375 010002 005337 015126      DEC      KSTOR3
1376 010006 001351      BNE      MOVEIT
1377 010010 013701 010022      MOV      OCTSV1,R1 ;RESTORE R1
1378 010014 013702 010024      MOV      OCTSV2,R2
1379 010020 000002      OCTEXT: RTI
1380
1381 010022 000000      OCTSV1: 0
1382 010024 000000      OCTSV2: 0
1383 010026 000000      OCTSV3: 0
1384 010030 000376      MASK:   376
1385 010032 005037 010026      XOCTP6: CLR      OCTSV3
1386 010036 000704      BR       OCTPRT
1387
1388 010040 012737 000003 010026      XOCTP3: MOV      03,OCTSV3
1389 010046 000700      BR       OCTPRT
1390
1391 ;*****
1392 ;SUBROUTINE TO CONVERT 'N' 'BCD' WORDS SEPERATED VIA COMMA'S TO OCTAL
1393 ;*****
1394
1395 010050 010146      BCDBINI: MOV      R1,=(SP) ;SAVE WORKING REGISTERS
1396 010052 010246      MOV      R2,=(SP)
1397 010054 010346      MOV      R3,=(SP)
1398 010056 010446      MOV      R4,=(SP)
1399 010060 012704 016526      MOV      0TTYBUF,R4 ;PICK UP BUFFER POINTER
1400 010064 012737 014736 014734      MOV      0BCDBUF,BCDPTR ;SET UP BUFFER POINTER
1401 010072 005037 014732      CLR      BCDCTR ;COUNT NO. OF ENTRIES IN BUFFER
1402 010076 005001      BCDBN0: CLR      R1
1403 010100 105714      BCDBN1: TST      (R4) ;END OF DATA?
1404 010102 001431      BEQ      BCDEND   ;YES, EXIT

```



```

1405 010104 112403          MOV8   (R4)+,R3      JSAVE IT
1406 010106 022703 000054  CMP    #54,R3      ICHAR. = TO ',?'
1407 010112 001003          BNE   BCD8N2      INO
1408 010114 004737 010146  JSR   PC,BCDBN3   IYES, SAVE CURRENT WORD
1409 010120 000766          BR    BCD8N8      ICONVERT NEXT WORD
1410 010122 042703 000360  BCD8N2I BIC    #360,R3   ISTEPE NO. TO BCD
1411 010126 010102          MOV   R1,R2      JSAVE CURRENT TOTAL
1412 010130 006301          ASL  R1          INX2
1413 010132 006301          ASL  R1          INX4
1414 010134 006301          ASL  R1          INX8
1415 010136 060201          ADD  R2,R1      INX9
1416 010140 060201          ADD  R2,R1      INX10
1417 010142 060301          ADD  R3,R1      IN+NEW NO.
1418 010144 000755          BR   BCD8N1
1419
1420 010146 010177 004562  BCD8N3I MOV   R1,#BCDPTR JSAVE WORD
1421 010152 062737 000002 014734  ADD   #2,BCDPTR  IUPDATE POINTER
1422 010160 005237 014732  INC  BCDCTR      ICOUNT NO. OF ENTRIES IN BUFFER
1423 010164 000207          RTS  PC          IRETURN
1424
1425 010166 004737 010146  BCD8N1I JSR   PC,BCDBN3   JSAVE WORD
1426 010172 012737 014736 014734  MOV   #BCDBUF,BCDPTR
1427 010200 012604          MOV  (SP)+,R4    IRESTORE THE WORKING REGISTERS
1428 010202 012603          MOV  (SP)+,R3
1429 010204 012602          MOV  (SP)+,R2
1430 010206 012601          MOV  (SP)+,R1
1431 010210 000207          RTS  PC          IEXIT
1432
1433  I*****
1434  ISUBROUTINE TO PRINT DECIMAL VALUE
1435  I*****
1436 010212 005077 170762  XBINDEC:CLR  #PSW
1437 010216 010237 010024  MOV   R2,OCTSV2  JSAVE R2
1438 010222 017602 000000  MOV   #0,(SP),R2 IPICK UP ADDRESS OF VALUE
1439 010226 011202          MOV  (R2),R2     IMOVE VALUE TO R2
1440 010230 042702 160000  BIC   #160000,R2 ICAN ONLY PRINT A '4' DIGIT NO.
1441 010234 062716 000002  ADD  #2,(SP)     ISET UP STACK TO EXIT
1442 010240 010146          MOV  R1,-(SP)
1443 010242 010446          MOV  R4,-(SP)
1444 010244 012704 010322  MOV  #DECPTR,R4
1445 010250 012701 177777  TYPT1: MOV  #0,R1
1446 010254 005201  TYPT2: INC  R1
1447 010256 161402          SUB  (R4),R2
1448 010260 100375          SPL  TYPT2
1449 010262 062402          ADD  (R4)+,R2
1450 010264 052701 000260  DEC1: BIS  #260,R1
1451 010270 004737 006226  JSR  PC,TYPEIT
1452 010274 005714          TST  (R4)        IDONE?
1453 010276 001364          BNE  TYPT1       INO
1454 010300 012701 000240  MOV  #240,R1     IYES, TYPE SPACE
1455 010304 004737 006226  JSR  PC,TYPEIT
1456 010310 013702 010024  MOV  OCTSV2,R2   IRESTORE R2
1457 010314 012604          MOV  (SP)+,R4
1458 010316 012601          MOV  (SP)+,R1

```

1459 010320 000002  
1460  
1461 010322 001750  
1462 010324 000144  
1463 010326 000012  
1464 010330 000001  
1465 010332 000000  
1466  
1467  
1468  
1469  
1470  
1471  
1472  
1473  
1474  
1475 010334 013703 016526  
1476 010340 004737 004722  
1477 010344 005737 016526  
1478 010350 001006  
1479 010352 010337 016526  
1480 010356 005737 014450  
1481 010362 001033  
1482 010364 000434  
1483  
1484 010366 012703 013370  
1485 010372 005037 015034  
1486 010376 012704 016526  
1487 010402 122713 000040  
1488 010406 001001  
1489 010410 105723  
1490 010412 122324  
1491 010414 001006  
1492 010416 122713 000054  
1493 010422 001373  
1494 010424 006337 015034  
1495 010430 000410  
1496 010432 005237 015034  
1497 010436 105713  
1498 010440 001406  
1499 010442 122723 000054  
1500 010446 001753  
1501 010450 000772  
1502 010452 062716 000002  
1503 010456 000207  
1504  
1505  
1506  
1507  
1508 010460 010046  
1509 010462 010146  
1510 010464 010246  
1511 010466 010346  
1512 010470 010446

```

RTI
DECPTR: 1000.
        100.
        10.
        1.
        0

;*****
;SUBROUTINE ENTERED TO ACCEPT & DECODE BAUD RATES INPUT BY THE USER.
;DECODE CALLING SEQUENCE:
;      JSR      PC,DECODE          ;CALL DECODE
;      RETURN  CALL+2          ;ILLEGAL ENTRY RETURN
;      RETURN  CALL+4          ;LEGAL ENTRY RETURN
;*****

DECODE: MOV      TTYBUF,R3          ;SAVE CONTENTS OF TTY BUFFER
        JSR      PC,GETLN1        ;PICK UP INPUTTED BAUD RATE
        TST      TTYBUF          ;WAS A BAUD RATE INPUTTED?
        BNE     DECOD1          ;YES, DECODE IT
        MOV      R3,TTYBUF        ;RESTORE CONTENTS OF TTY BUFFER
        TST      LPWORD          ;NO, HAS AN ENTRY BEEN MADE IN THE TABLE?
        BNE     OUT2            ;YES, USE CURRENT BAUD SETTING
        BR      OUT1            ;NO, ILLEGAL ENTRY - RETURN TO CALL+2

DECOD1: MOV      @BAUDTB,R3        ;SET UP MESSAGE MATCH TABLE POINTER
        CLR      OFFSET          ;
RECYCL: MOV      @TTYBUF,R4        ;SET UP TELETYPE BUFFER POINTER
        CMPB    @40,(R3)         ;CHAR = TO SPACE?
        BNE     ,+4             ;NO
        TSTB    (R3)+           ;YES, SKIP IT
MATCH:  CMPB    (R3)+,(R4)+      ;COMPARE BUFFERS
        BNE     FLUSH           ;NOT EQUAL, SET UP NEXT WORD
        CMPB    @54,(R3)        ;CHAR = COMMA?
        BNE     MATCH          ;NO, COMPARE NEXT CHAR.
        ASL     OFFSET          ;YES, SET UP THE OFFSET
        BR      OUT2            ;
FLUSH:  INC     OFFSET          ;INCREMENT THE OFFSET CNTR.
        TSTB    (R3)           ;END OF MESSAGE?
        BEQ     OUT1            ;YES, ILLEGAL ENTRY - RETURN TO CALL+2
        CMPB    @54,(R3)+      ;CHAR = COMMA
        BEQ     RECYCL          ;YES, COMPARE NEXT WORD
        BR      FLUSH+4        ;NO, KEEP GOING
OUT2:   ADD     @2,(SP)         ;SET UP TO RETURN TO CALL +4
OUT1:   RTS      PC            ;RETURN

;*****
;POWER FAIL HANDLER
;*****

PWRFAIL: MOV     R0,-(SP)
        MOV     R1,-(SP)
        MOV     R2,-(SP)
        MOV     R3,-(SP)
        MOV     R4,-(SP)
    
```

```

1513 010472 010546          MOV      R5, -(SP)
1514 010474 013746 000024    MOV      24, -(SP)
1515 010500 010637 015120    MOV      SP, TEMP
1516 010504 012737 010514 000024    MOV      @PWRUP, @024
1517 010512 000000          HALT
1518 010514 012777 000340 170456 PWRUP:  MOV      @340, @PSW          ;POWER UP DELAY
1519 010522 005001          CLR      R1
1520 010524 005201          INC      R1
1521 010526 001376          BNE     @-2
1522 010530 013706 015120    MOV      TEMP, SP
1523 010534 012637 000024    MOV      (SP)+, @024
1524 010540 012605          MOV      (SP)+, R5
1525 010542 012604          MOV      (SP)+, R4
1526 010544 012603          MOV      (SP)+, R3
1527 010546 012602          MOV      (SP)+, R2
1528 010550 012601          MOV      (SP)+, R1
1529 010552 012600          MOV      (SP)+, R0
1530 010554 104000          PRINT
1531 010556 012263          MESA
1532 010560 000137 002070    JMP      SERVICE
1533
1534          ;*****
1535          ;EMT DISPATCH SERVICE ROUTINE
1536          ;ARGUMENT OF EMT IS EXTRACTED AND USED AS OFFSET TO OBTAIN POINTER
1537          ;TO THE SELECTED SUBROUTINE.
1538          ;*****
1539
1540 010564 011646          EMTSRV: MOV      (SP), -(SP)          ;GET PC FOR TO RETURN
1541 010566 162716 000002    SUB      @2, (SP)          ;PC OF EMT
1542 010572 017616 000000    MOV      @0(SP), (SP)      ;GET EMT
1543 010576 006316          EMTOK:  ABL      (SP)          ;MULTIPLY EMT ARG BY '2'
1544 010600 042716 177001    BIC      @177001, (SP)      ;CLEAR UNWANTED BITS
1545 010604 062716 010616    ADD      @EMTTAB, (SP)      ;POINTER TO SUBROUTINE ADDRESS
1546 010610 017616 000000    MOV      @0(SP), (SP)      ;SUBROUTINE ADDRESS
1547 010614 000136          JMP      @0(SP)+          ;GO TO SUBROUTINE
1548
1549          ;EMT DISPATCH TABLE
1550
1551 010616 007370          EMTTAB: TYPHES          ;SUBROUTINE TO PRINT ASCII MESSAGES.
1552 010620 010032          KOCTP6          ;SUBROUTINE TO PRINT A '6' DIGIT OCTAL NO.
1553 010622 010212          XBINDEC          ;SUBROUTINE TO CONVERT OCTAL TO BINARY & PRNT IT
1554 010624 010040          KOCTP3          ;SUBROUTINE TO PRINT A '3' DIGIT OCTAL NO.
1555          ;*****
1556          ;OVERLAY VECTOR AREA WITH '+2' IN THE VECTOR FOLLOWED W/ IOT TRAP
1557          ;*****
1558
1559 010626 012701 000210    OVLAY:  MOV      @210, X1          ;GET DL11-E VECTOR BASE ADDRESS
1560 010632 012702 000212    MOV      @212, X2
1561 010636 012703 000004    MOV      @4, X3
1562 010642 010221          OVLAY:  MOV      X2, (1)+          ;LOAD VECTOR WITH IOT ERROR TRAP
1563 010644 010321          MOV      X3, (1)+
1564 010646 062702 000004    ADD      @4, X2
1565 010652 020127 001000    CMP      X1, @1000          ;ALL VECTORS BEEN LOADED
1566 010656 001401          BEQ     OVLAY

```

1567 010660 000770  
1568 010662 000207  
1569  
1570  
1571  
1572  
1573  
1574 010664 011637 015140  
1575 010670 022626  
1576 010672 011637 015142  
1577 010676 005737 015144  
1578 010702 001427  
1579 010704 162737 000004 015140  
1580 010712 013721 015140  
1581 010716 062737 000002 015140  
1582 010724 013721 015140  
1583 010730 062737 000002 015140  
1584 010736 013721 015140  
1585 010742 062737 000002 015140  
1586 010750 013721 015140  
1587 010754 005037 015144  
1588 010760 000002  
1589  
1590  
1591  
1592 010762 052777 004000 170232  
1593 010770 104000  
1594 010772 012324  
1595 010774 162737 000004 015140  
1596 011002 104001  
1597 011004 015140  
1598 011006 104000  
1599 011010 012406  
1600 011012 162737 000002 015142  
1601 011020 104001  
1602 011022 015142  
1603 011024 000137 001342  
1604  
1605 011030 000  
1606  
1607  
1608 011031 045 042045 030510  
011036 027461 052126 030062  
011044 044040 051517 020124  
011052 044504 043501 047516  
011060 052123 041511 050040  
011066 047522 051107 046501  
011074 045  
1609 011075 115 044501 042116  
011102 041505 030455 026461  
011110 055104 052126 026507  
011116 026501 041120  
1610 011122 020040 032040 031457  
011130 027460 032467 022456

BR OVRLYA  
OVRLYBI RTS 7 JEXIT  
\*\*\*\*\*  
JMAPVEC = MAP VECTOR OR REPORT ERROR DEPENDING ON STATE OF 'FMAP' FLAG  
\*\*\*\*\*  
MAPVEC: MOV (SP),TOPC  
POP2SP  
MOV (SP),FROMPC  
TST FMAP JMAPPING?  
BEQ ERTRAP JNO, REPORT ERROR  
SUB #4,TOPC JSETUP TO LOAD RECEIVER VECTOR  
MOV TOPC,(R1)+ JSTORE RECEIVER VECTOR  
ADD #2,TOPC  
MOV TOPC,(R1)+ JSTORE BR ADDRESS  
ADD #2,TOPC JSET UP TO LOAD TRANSMITTER VECTOR  
MOV TOPC,(R1)+ JSTORE RECEIVER  
ADD #2,TOPC  
MOV TOPC,(R1)+  
CLR FMAP  
RTI  
JERROR TRAP HANDLER, ENTERED ON ILLEGAL TRAPS  
ERTRAP: BIS #4000,#DMSCR JISSUE MASTER CLEAR TO 'DM'  
PRINT  
MESS JTEXT 'ILLEGAL TRAP TO'  
SUB #4,TOPC  
PRTOCT  
TOPC JTYPE 'PC' TRAPPED TOO  
PRINT  
MESS JTEXT 'FROM'  
SUB #2,FROMPC  
PRTOCT  
FROMPC JTYPE WHERE IT TRAPPED FROM  
JMP START JRE-START TEST  
JBYTE  
JMESSAGES  
TITLE: .ASCII J%%DH11/VT20 HOST DIAGNOSTIC PROGRAM%  
JMAINDEC-11-DZVTG-A-PB%  
J 4/30/75.X%

1611	011136	054523	052123	046505	.ASCII	/SYSTEM COMMAND LISTX/
	011144	041440	046517	040515		
	011152	042116	046040	051511		
	011160	022524				
1612	011162	040536	020040	041101	.ASCII	/A ABSOLUTE SYSTEM RESTARTX/
	011170	047523	052514	042524		
	011176	051440	051531	042524		
	011204	020115	042522	052123		
	011212	051101	022524			
1613	011216	041136	020040	047502	.ASCII	/B BOOT SELECTED LINESX/
	011224	052117	051440	046105		
	011232	041505	042524	020104		
	011240	044514	042516	022523		
1614	011246	041536	020040	046103	.ASCII	/C CLEAR SOFTWARE SWITCHES/EXIT PRESENT MODEX/
	011254	040505	020122	047523		
	011262	052106	040527	042522		
	011270	051440	044527	041524		
	011276	042510	027523	054105		
	011304	052111	050040	042522		
	011312	042523	052116	046440		
	011320	042117	022505			
1615	011324	042136	020040	051120	.ASCII	/D PRINT RECEIVED DATA/DIAGNOSTIC MODEX/
	011332	047111	020124	042522		
	011340	042503	053111	042105		
	011346	042040	052101	027501		
	011354	044504	043501	047516		
	011362	052123	041511	046440		
	011370	042117	022505			
1616	011374	042536	020040	046505	.ASCII	/E EMERGENCY RESTART/REINITIALIZE ALL SWITCHESX/
	011402	051105	042507	041516		
	011410	020131	042522	052123		
	011416	051101	027524	042522		
	011424	047111	052111	040511		
	011432	044514	042532	040440		
	011440	046114	051440	044527		
	011446	041524	042510	022523		
1617	011454	044136	020040	047510	.ASCII	/H HOLD SELECTED LINES/INHIBIT TRANSMISSIONX/
	011462	042114	051440	046105		
	011470	041505	042524	020104		
	011476	044514	042516	027523		
	011504	047111	044510	044502		
	011512	020124	051124	047101		
	011520	046523	051511	044523		
	011526	047117	045			
1618	011531	136	020114	046040	.ASCII	/L LIST SELECTED LINE STATUSX/
	011536	051511	020124	042523		
	011544	042514	052103	042105		
	011552	046040	047111	020105		
	011560	052123	052101	051525		
	011566	045				
1619	011567	136	020120	050040	.ASCII	/P PRINT SELECTED LINE BUFFERX/
	011574	044522	052116	051440		
	011602	046105	041505	042524		
	011610	020104	044514	042516		

	011616	041040	043125	042506		
	011624	022522				
1620	011626	051136	020040	042522	.ASCII	/'R RELEASE SELECTED LINESX)
	011634	042514	051501	020105		
	011642	042523	042514	052103		
	011650	042105	046040	047111		
	011656	051505	045			
1621	011661	136	020123	051440	.ASCII	/'S SEND FOLLOWING DATA TO SELECTED LINESX)
	011666	047105	020104	047506		
	011674	046114	053517	047111		
	011702	020107	040504	040524		
	011710	052040	020117	042523		
	011716	042514	052103	042105		
	011724	046040	047111	051505		
	011732	045				
1622	011733	136	020117	044440	.ASCII	/'O INHIBIT/KILL CURRENT PRINTOUTX)
	011740	044116	041111	052111		
	011746	045457	046111	020114		
	011754	052503	051122	047105		
	011762	020124	051120	047111		
	011770	047524	052125	045		
1623	011775	136	020124	044440	.ASCII	/'T INHIBIT/RESTART ERROR PRINTOUTX)
	012002	044116	041111	052111		
	012010	051057	051505	040524		
	012016	052122	042440	051122		
	012024	051117	050040	044522		
	012032	052116	052517	051524		
	012040	045				
1624	012041	136	020126	053040	.ASCII	/'V VERIFY SELECTED LINESX)
	012046	051105	043111	020131		
	012054	042523	042514	052103		
	012062	042105	046040	047111		
	012070	051505	045			
1625	012073	136	020130	052040	.ASCIZ	/'X TRANSMIT ON SELECTED LINESX)
	012100	040522	051516	044515		
	012106	020124	047117	051440		
	012114	046105	041505	042524		
	012122	020104	044514	042516		
	012130	022523	000			
1626						
1627	012133	045	044124	052101	MES11 .ASCIZ	/'XTHAT DH11 ADDRESS IS NOT PRESENT??)
	012140	042040	030510	020061		
	012146	042101	051104	051505		
	012154	020123	051511	047040		
	012162	052117	050040	042522		
	012170	042523	052116	037477		
	012176	000				
1628						
1629	012177	045	047516	051040	MES21 .ASCIZ	/'XNO RECEIVER INTERRUPT RESPONSE FROM DEVICE )
	012204	041505	044505	042526		
	012212	020122	047111	042524		
	012220	051122	050125	020124		
	012226	042522	050123	047117		
	012234	042523	043040	047522		

	012242	020115	042504	044526			
	012250	042503	020040	000			
1630							
1631	012255	114	047111	020105	ME831	.ASCIZ	]LINE ]
	012262	000					
1632	012263	045	051045	041505	ME841	.ASCIZ	]XRECOVERED FROM POWER FAILURE,X]
	012270	053117	051105	042105			
	012276	043040	047522	020115			
	012304	047520	042527	020122			
	012312	040506	046111	051125			
	012320	027105	000045				
1633							
1634	012324	044445	046114	043505	ME851	.ASCIZ	]XILLEGAL TRAP TO ]
	012332	046101	052040	040522			
	012340	020120	047524	000040			
1635							
1636							
1637	012346	042445	052116	051105	MPIAD1	.ASCIZ	]XENTER THE DM11 'SCR' ADDRESS? ]
	012354	052040	042510	042040			
	012362	030510	020061	051447			
	012370	051103	020047	042101			
	012376	051104	051505	037523			
	012404	000040					
1638							
1639	012406	043040	047522	020115	ME861	.ASCIZ	] FROM ]
	012414	000					
1640							
1641							
1642	012415	045	046514	042516	ME881	.ASCIZ	]XLINE IN OR. PAR. FRAM TRAN ST. HELD PEND BAUD]
	012422	044440	020116	020040			
	012430	051117	020056	050040			
	012436	051101	020056	051106			
	012444	046501	052040	040522			
	012452	020116	052123	020056			
	012460	044040	046105	020104			
	012466	042520	042116	041040			
	012474	052501	000104				
1643							
1644							
1645	012500	042040	040511	027107	ME891	.ASCIZ	] DIAG. MODE ENABLED.]
	012506	046440	042117	020105			
	012514	047105	041101	042514			
	012522	027104	000				
1646	012525	045	042522	042101	ME8111	.ASCIZ	]XREADER DEVICE ADDRESS? ]
	012532	051105	042040	053105			
	012540	041511	020105	042101			
	012546	051104	051505	037523			
	012554	000040					
1647	012556	047105	042524	020122	ME8121	.ASCII	]ENTER BAUD RATE OF EACH LINE. CONSECUTIVE LINE BAUD RATES MAY BE]
	012564	040502	042125	051040			
	012572	052101	020105	043117			
	012600	042440	041501	020110			
	012606	044514	042516	020056			
	012614	047503	051516	041505			

	012622	052125	053111	020105	
	012630	044514	042516	041040	
	012636	052501	020104	040522	
	012644	042524	020123	040515	
	012652	020131	042502		
1648	012656	047105	042524	020122	.ASCII IENTER BY TYPING 'CR',(NOTE: ENTER UNUSED LINES AS '0' BAUD.)XXI
	012664	054502	052040	050131	
	012672	047111	020107	041447	
	012700	023522	024054	047516	
	012706	042524	020072	047105	
	012714	042524	020122	047125	
	012722	051525	042105	046040	
	012730	047111	051505	040440	
	012736	020123	030047	020047	
	012744	040502	042125	024456	
	012752	022445			
1649	012754	044514	042516	041040	.ASCIZ ILINE BAUDXI
	012762	052501	022504	000	
1650	012767	126	041505	047524	ME813I .ASCIZ IVECTOR ADDRESS? I
	012774	020122	042101	051104	
	013002	051505	037523	000040	
1651	013010	047045	020117	046123	ME814I .ASCII IENO SLAVE SYNC RETURNED ADDRESSING THE KW11 LINE CLOCK
	013016	053101	020105	054523	
	013024	041516	051040	052105	
	013032	051125	042516	020104	
	013040	042101	051104	051505	
	013046	044523	043516	052040	
	013054	042510	045440	030527	
	013062	020061	044514	042516	
	013070	041440	047514	045503	
1652	013076	052045	044510	020123	.ASCII IXTTHIS PROGRAM WILL RUN WITHOUT IT BUT ALL9
	013104	051120	043517	040522	
	013112	020115	044527	046114	
	013120	051040	047125	053440	
	013126	052111	047510	052125	
	013134	044440	020124	052502	
	013142	020124	046101	114	
1653	013147	045	054523	052123	.ASCIZ ISYSTEM ERRORS 'MAY NOT' BE REPORTED.I
	013154	046505	042440	051122	
	013162	051117	020123	046447	
	013170	054501	047040	052117	
	013176	020047	042502	051040	
	013204	050105	051117	042524	
	013212	027104	000		
1654	013215	040	042450	050117	EOPMSGI .ASCIZ I (EOP)I
	013222	000051			
1655	013224	044440	046114	043505	CODE00I .ASCIZ I ILLEGAL RECVR. INTERRUPTXI.I
	013232	046101	051040	041505	
	013240	051126	020056	047111	
	013246	042524	051122	050125	
	013254	022524	000056		
1656					
1657	013260	047440	042526	051122	CODE01I .ASCIZ I OVERRUN ERRORXI.I
	013266	047125	042440	051122	



	013274	051117	027045	000	
1658					
1659	013301	040	051106	046501	CODE021 .ASCIZ ; FRAMING ERRORX.;
	013306	047111	020107	051105	
	013314	047522	022522	000056	
1660					
1661	013322	050040	051101	052111	CODE031 .ASCIZ ; PARITY ERRORX.;
	013330	020131	051105	047522	
	013336	022522	000056		
1662					
1663	013342	044440	046114	043505	CODE041 .ASCIZ ; ILLEGAL START CODEX.;
	013350	046101	051440	040524	
	013356	052122	041440	042117	
	013364	022505	000056		
1664					
1665	013370	026060	032440	026060	BAUDTB1 .ASCII 10, 50, 75, 110, 134.5, 150, 200, ;
	013376	033440	026065	030440	
	013404	030061	020054	031461	
	013412	027064	026065	030440	
	013420	030065	020054	030062	
	013426	026060	040		
1666	013431	063	030060	020054	.ASCIZ 1300, 600, 1200, 1800, 2400, 4800, 9600, ;
	013436	030066	026060	030440	
	013444	030062	026060	030440	
	013452	030070	026060	031040	
	013460	030064	026060	032040	
	013466	030070	026060	034440	
	013474	030066	026060	000	
1667					
1668	013501	040	046111	042514	CODE051 .ASCIZ ; ILLEGAL READER INTERRUPTX.;
	013506	040507	020114	042522	
	013514	042101	051105	044440	
	013522	052116	051105	052522	
	013530	052120	027045	000	
1669					
1670	013535	040	046111	042514	CODE061 .ASCIZ ; ILLEGAL TRANS. INTERRUPTX.;
	013542	040507	020114	051124	
	013550	047101	027123	044440	
	013556	052116	051105	052522	
	013564	052120	027045	000	
1671					
1672	013571	040	052101	042524	CODE071 .ASCIZ ; ATTEMPT TO RECEIVE WHILE IN SEND MODEX.;
	013576	050115	020124	047524	
	013604	051040	041505	044505	
	013612	042526	053440	044510	
	013620	042514	044440	020116	
	013626	042523	042116	046440	
	013634	042117	022505	000056	
1673					
1674	013642	052040	040522	051516	CODE101 .ASCIZ ; TRANSMITTER NON-EX MEMORY INTERRUPTX.;
	013650	044515	052124	051105	
	013656	047040	047117	042455	
	013664	020130	042515	047515	
	013672	054522	044440	052116	

```

013700 051105 052522 052120
013706 027045 000
1675
1676 013711 040 042526 044522 CODE111 .ASCIZ ; VERIFIES OKX.;
013716 044506 051505 047440
013724 022513 000056
1677
1678 013730 042040 052101 020101 CODE121 .ASCIZ ; DATA VERIFY ERROR, SENT=377 RECV'D=;
013736 042526 044522 054506
013744 042440 051122 051117
013752 020054 042523 052116
013760 031455 033467 051040
013766 041505 023526 026504
013774 000
1679
1680 013775 040 047516 053040 CODE131 .ASCIZ ; NO VERIFY DATA RETURNEDX.;
014002 051105 043111 020131
014010 040504 040524 051040
014016 052105 051125 042516
014024 022504 000056
1681
1682 014030 047040 020117 051124 CODE141 .ASCIZ ; NO TRANSMITTER INTERRUPTS OCCURRINGX.;
014036 047101 046523 052111
014044 042524 020122 047111
014052 042524 051122 050125
014060 051524 047440 041503
014066 051125 044522 043516
014074 027045 000
1683
1684 014077 040 051511 040440 CODE151 .ASCIZ ; IS ACTIVE, CAN'T VERIFY - TYPE "E"X.;
014104 052103 053111 026105
014112 041440 047101 052047
014120 053040 051105 043111
014126 020131 020055 054524
014134 042520 023440 042536
014142 022447 000056
1685
1686 014146 047040 020117 042522 CODE161 .ASCIZ ; NO RECEIVER INTERRUPTS OCCURRINGX.;
014154 042503 053111 051105
014162 044440 052116 051105
014170 052522 052120 020123
014176 041517 052503 051122
014204 047111 022507 000056
1687
1688 014212 042040 052101 020101 CODE171 .ASCIZ ; DATA CHECK ERROR, SENT=377 RECV'D=;
014220 044103 041505 020113
014226 051105 047522 026122
014234 051440 047105 026524
014242 033463 020067 042522
014250 053103 042047 000055
1689
1690 014256 000040 SPACE: .ASCIZ ; ;
1691 014260 000045 CRLF: .ASCIZ ;X;
1692 014262 027045 000 DOT: .ASCIZ ;X.;

```

```

1693 014265 134 000
1694 014270
1695
1696
1697 014270 000000
1698 014272 000000
1699 014274 000000
1700 014276 000001
1701 014300 000002
1702 014302 000004
1703 014304 000010
1704 014306 000020
1705 014310 000040
1706 014312 000100
1707 014314 000200
1708 014316 000400
1709 014320 001000
1710 014322 002000
1711 014324 004000
1712 014326 010000
1713 014330 020000
1714 014332 040000
1715 014334 100000
1716
1717
1718
1719
1720 014336 016672
1721 014340 017656
1722 014342 020642
1723 014344 021626
1724 014346 022612
1725 014350 023576
1726 014352 024562
1727 014354 025546
1728 014356 026532
1729 014360 027516
1730 014362 030502
1731 014364 031466
1732 014366 032452
1733 014370 033436
1734 014372 034422
1735 014374 035406
1736
1737 014376 000000
1738 014440
1739
1740
1741 014440 000000
1742 014450
1743 014450 000000
1744 014512
1745 014512 000000
1746 014614

```

```

SLASH: .ASCIZ / \ /
        .EVEN

```

```

MONFLG: 0
LINCLK: 0
MEMSIZ: 0
LINENO: 1
        2
        4
        10
        20
        40
        100
        200
        400
        1000
        2000
        4000
        10000
        20000
        40000
        100000

```

ADDRESSES AND CONSTANTS

```

BUFADR: BUFFER
        BUFFER+500.
        BUFFER+1000.
        BUFFER+1500.
        BUFFER+2000.
        BUFFER+2500.
        BUFFER+3000.
        BUFFER+3500.
        BUFFER+4000.
        BUFFER+4500.
        BUFFER+5000.
        BUFFER+5500.
        BUFFER+6000.
        BUFFER+6500.
        BUFFER+7000.
        BUFFER+7500.

```

```

BUFPTR: 0
        .B.+40

```

```

MSGBUF: 0
        .B.+6
LPWORD: 0
        .B.+40
BAUDMS: 0
        .B.+100

```

THIS BUFFER AREA CONTAINS A POINTER  
ADDRESS WHICH POINTS TO THE NEXT  
RECEIVER CHARACTER STORAGE BYTE

LINE PARAMETER WORD BUFFER

MESSAGE BUFFER FOR THE BAUD RATES

1747 014614 000000  
 1748 014616 000000  
 1749 014620 000000  
 1750 014622 000000  
 1751 014624 000000  
 1752 014626 000000  
 1753 014670 014670  
 1754 014670 000000  
 1755 014732 014732  
 1756 014732 000000  
 1757 014734 000000  
 1758 014736 000000  
 1759 015000 015000  
 1760 015000 000000  
 1761 015002 000000  
 1762 015004 000000  
 1763 015006 000000  
 1764 015010 000000  
 1765 015012 000000  
 1766 015014 000000  
 1767 015016 000000  
 1768 015020 000000  
 1769 015022 000000  
 1770 015024 000000  
 1771 015026 000000  
 1772 015030 000000  
 1773 015032 000000  
 1774 015034 000000  
 1775 015036 000000  
 1776 015040 000000  
 1777 015042 000000  
 1778 015044 000000  
 1779 015046 000000  
 1780 015050 000000  
 1781 015052 000000  
 1782 015054 000000  
 1783 015056 000000  
 1784 015120 015120  
 1785 015120 000000  
 1786 015122 000000  
 1787 015124 000000  
 1788 015126 000000  
 1789 015130 000000  
 1790 015132 000000  
 1791 015134 000000  
 1792 015136 000000  
 1793 015140 000000  
 1794 015142 000000  
 1795 015144 000000  
 1796 015146 000000  
 1797 015150 000000  
 1798 015152 000000  
 1799  
 1800

HOLDSWI 0  
 SENDSWI 0  
 BOOTFGI 0  
 BOOTSWI 0  
 BOOTLNI 0  
 VRFSWHI 0  
 ERRCTRI 0  
 BCDCTRI 0  
 BCDPTRI 0  
 BCDBUPI 0  
 RCHARI 0  
 RSTATI 0  
 SYSSWI1 0  
 CLKCTRI 0  
 SYSSWHI 0  
 TTYPTRI 0  
 CNTRI 0  
 TYPV2I 0  
 RECVCKI 0  
 ACTIVEI 0  
 RUBSWHI 0  
 OSWITCI 0  
 SCHARI 0  
 LINNOI 0  
 OFFSETI 0  
 REDONEI 0  
 CONSPLI 0  
 SAVCHRI 0  
 DEVADRI 0  
 PRTPLBI 0  
 BOOTP1I 0  
 BOOTP2I 0  
 BOOTADI 0  
 READCTI 0  
 TEMPI 0  
 KSTOR1I 0  
 KSTOR2I 0  
 KSTOR3I 0  
 KSTOR4I 0  
 RMODEI 0  
 PRTCNTI 0  
 PRTSWHI 0  
 TOPCI 0  
 FROMPCI 0  
 FHAPI 0  
 RECWHI 0  
 PENDINGI 0  
 TRNSWHI 0  
 IREADER DEVICE ADDRESSES

IHOLD SW., SET = HOLDING A LINE  
 ISEND SW., SET = LINE IN SEND MODE  
 ISET TO INDICATE READER IS ACTIVE  
 IBOOT SW., SET = BOOTING  
 ICONTAINS THE BOOT ADDR, LINE NO.  
 .B.+40  
 .B.+40  
 .B.+40  
 ICONTAINS NO. OF CHAR'S READ FROM READER  
 ITEMPORARY STORAGE  
 IPERMANENT STORAGE  
 IPERMANENT STORAGE  
 ISOFTWARE SW.  
 ISOFTWARE SW., SET IF MAPPING  
 IRECEIVER SOFTWARE SW, SET=RECEIVING  
 ISET WHEN A HELD LINE IS READY TO BE TRANS.  
 ITRANSMITTER SOFTWARE SW, SET=TRANSMITTING

1001 015154 000000  
1002 015156 000000  
1003 015160 000000  
1004 015222 015222  
1005 015222 000000  
1006 015264 015264  
1007 015264 000000  
1008 015326 015326  
1009 015326 000000  
1010 015370 015370  
1011 015370 000000  
1012 015432 015432  
1013 015432 000000  
1014 015474 015474  
1015 015474 000000  
1016 015536 015536  
1017 015536 000000  
1018 015600 015600  
1019 015600 000000  
1020 015642 015642  
1021 015642 000000  
1022 015704 015704  
1023 015704 000000  
1024 016526 016526  
1025 016526 000000  
1026 016570 016570  
1027 016570 000000  
1028 016672 016672  
1029 016672 000000  
1030 000001

RCSR: 0  
RDBR: 0  
BYTECT: 0  
RECNT: 0  
XPERCT: 0  
REC: 0  
ORI: 0  
FRM: 0  
PAR: 0  
ST: 0  
TRN: 0  
SND: 0  
ERRBUF: 0  
TTYBUF: 0  
READBF: 0  
BUFFER: 0  
END

IBUFFER AREA TO SAVE N OF RECEIVED BYTES  
IALLOCATE '1' LOCATION FOR EACH UNIT,

IERROR BUFFER STORAGE AREA,

IHEADER DATA BUFFER

IDATA BUFFER STORAGE AREA,

ACTIVE	015022	307*	313	325*	358	624*	714*	801	928*	1030*	1040	1176*	1212*	1235
		1251*	1266*	1769*										
BAUDMS	014512	234	847	849	1745*									
BAUD*8	013370	1484	1665*											
BCDBIN	010050	804	1395*											
BCDBN0	010076	1402*	1409											
BCDBN1	010100	1403*	1418											
BCDBN2	010122	1407	1410*											
BCDBN3	010146	1408	1420*	1425										
BCDBUF	014736	905	1400	1426	1750*									
BCDCTR	014732	572*	631*	648*	667*	858*	893	897*	924*	950	953*	1401*	1422*	1756*
BCDEND	010166	1404	1425*											
BCDPTR	014734	774	775*	905*	1400*	1420*	1421*	1426*	1757*					
BINDEC*	104002	64*	65	236	395	822	824	826	828	830	832	834	839	844
BOOT	005550	515	949*											
BOOTAD	015054	1782*												
BOOTFG	014620	372	957*	994	1010*	1749*								
BOOTLN	014624	951*	952*	1020	1751*									
BOOTP1	015050	1780*												
BOOTP2	015052	377*	973*	993	1003*	1781*								
BOOTSW	014622	1029*	1247	1250*	1750*									
BOOT1	005566	952*	956											
BOOT2	005610	954	957*											
BOOT3	005622	960*	964											
BOOT4	005702	959	973*											
BUFADR	014336	628	712	787	1177	1208	1720*							
BUFFER	016672	1720	1721	1722	1723	1724	1725	1726	1727	1728	1729	1730	1731	1732
		1733	1734	1735	1829*									
BUFPTR	014376	150	664*	683	691*	1127	1193*	1737*						
BYTECT	015160	627	665*	692*	703*	711	1180*	1189*	1206*	1207	1893*			
CLKCTR	015006	310*	311	1261*	1763*									
CLKSRV	006250	280	1061*											
CNTR	015014	1766*												
CODE00	013224	410	1655*											
CODE01	013260	411	1657*											
CODE02	013301	412	1659*											
CODE03	013322	413	1661*											
CODE04	013342	414	1663*											
CODE05	013501	415	1668*											
CODE06	013535	416	1670*											
CODE07	013571	417	1672*											
CODE10	013642	418	1674*											
CODE11	013711	419	1676*											
CODE12	013730	420	1678*											
CODE13	013775	421	1680*											
CODE14	014030	422	1682*											
CODE15	014077	423	1684*											
CODE16	014146	424	1686*											
CODE17	014212	425	1688*											
CONC	003626	506	594*											
COND	003602	525	582*											
CONH	003552	527	570*	575										
CONH1	003600	573	576*											
CONL	005006	535	815*											

CONP	004020	537	6430											
CONP1	004034	6460	652											
CONP2	004040	6460	6470											
CONP3	004064	649	6530											
CONR	003646	529	6110											
CONR1	003670	6170												
CONR2	004002	616	620	6310										
CONR3	004016	632	6350											
CONS	004066	532	6620											
CONSFL	015040	551	6630	6900	17760									
CONSO	004150	6810	696											
CONS1	004076	6640	678											
CONSR	004132	668	6710											
CORBIZ	001412	142	1460											
CRLF	014260	458	651	805	821	16910								
DATA	003062	391	4520											
DECODE	010334	237	14750											
DECOD1	010366	1070	10800											
DECPTR	010322	1444	14610											
DEC1	010264	14500												
DEVADR	015044	160	1620	163	7450	7460	7470	7480	759	7610	7620	7630	7950	962
		970	17780											
DHBR	001234	860	3090	6200	7150	9200	10310	12090	1236					
DHBCR	001232	850	2720	6270	7110	9250	10270	12070						
DHBKR	001236	870												
DHCR	001230	840	2710	6280	7120	9260	10280	12080						
DHLPR	001226	830	2700											
DHNRC	001224	820	1087											
DHRBR	001244	900												
DHRVTR	001242	890	195	210										
DHSCR	001222	810	164	194	2680	2690	3050	3240	6260	7100	9240	10260	12050	12310
		1260	12700	15920										
DHSSR	001240	800	2760	2790										
DHTBR	001250	920												
DHTVTR	001246	910												
DOT	014262	290	349	407	557	1030	16920							
EMTOK	010576	15430												
EMTSRV	010564	43	15400											
EMTYAB	010616	1545	15510											
EOP	000014	200	690	699	1194	1303								
EOPMSG	013215	1330	16540											
ERRBUF	015704	295	346	359	361	506	10230							
ERRCTR	014670	1090	1100	1116	1122	1167	12140	12590	17540					
ERRMES	002706	3990	4000											
ERRYBL	002744	399	4100											
ERTRAP	010762	1570	15920											
EXIT	003144	459	4670											
EXITKS	003540	492	543	550	5500	671	697	749	764	978				
PINVEC	001644	185	1940											
FLUSH	010432	1491	14960	1501										
FMAP	015144	1970	204	2060	1577	15070	17950							
FORMIT	004626	570	611	645	662	7700	782	816	892	949				
FORMON	004632	574	633	650	669	7710	860	900	955					
FRAMER	006410	1106	11130											

FRM	015432	829	1115*	18130												
FROMPC	015142	1576*	1600*	1602	17940											
GETLN	003512	494	496	5510												
GETLN1	004722	159	770	7950	961	969	1476									
GETLN2	004416	554	7270													
GTBAUD	001770	2310														
HOLDSW	014614	262	571*	615	617*	704	836	1198	17470							
KEYSRV	003150	46	4820													
KEY1	003504	5490														
KSTOR1	015122	208*	209	393*	395	405*	406	17860								
KSTOR2	015124	392*	396	17870												
KSTOR3	015126	1360*	1375*	17880												
KSTOR4	015130	374	950*	17890												
KWDR	001220	730	201*													
KWVTR	001216	720	200*													
KW11	001214	710	177	282*												
LDVECT	001744	205	2100													
LINCLK	014272	182*	277	16980												
LINENO	014276	306	307	308	571	615	617	618	619	621	623	624	629	666		
		681	700	702	704	706	713	714	715	836	841	894	909	911		
		913	927	928	929	952	1020	1029	1030	1031	1095	1128	1130	1132		
		1143	1175	1176	1197	1198	1200	1209	1211	1212	1247	1250	1251	1253		
		1264	1266	17000												
LINNO	015032	233*	236	246*	247	819*	820*	822	852*	17730						
LINSTR	005544	260*	893*	984	9340											
LPWORD	014450	231	266	300	1480	17430										
MAPVEC	010664	39	15740													
MASK	010030	1361*	1369	1374*	13840											
MATCH	010412	14900	1493													
MEMSIZ	014274	147*	152	264	16990											
MES1	012133	186	16270													
MES11	012525	960	16460													
MES12	012556	235	16470													
MES13	012767	968	16500													
MES14	013010	100	16510													
MES2	012177	207	16290													
MES3	012255	394	16310													
MES4	012263	1531	16320													
MES5	012324	1594	16340													
MES6	012406	1599	16390													
MES8	012415	818	16420													
MES9	012500	584	16450													
MPIAD	012346	150	16370													
MONPLG	014270	154	156*	16970												
MONTR	002530	332	3500	366												
MONTR1	002552	360	3630													
MOVEIT	007732	13630	1376													
MOVEON	007774	1367	13740													
MSOBUF	014440	847*	849*	850*	851	17410										
NOP	000240	260														
OCTEXT	010020	1352	13790													
OCTPRT	007650	13500	1386	1389												
OCTPR3	104003	650	406													
OCTSV1	010022	1353*	1377	13810												



OCTSV2	010024	1354*	1378	1382*	1437*	1456								
OCTSV3	010026	1357	1366*	1383*	1385*	1388*								
OFFSET	015034	239	1485*	1494*	1496*	1774*								
OR	015370	825	1107*	1811*										
OSWITC	015026	540*	1290	1330*	1771*									
OUTPUT	007540	1313	1316	1319*										
OUT1	010456	1482	1498	1503*										
OUT2	010452	1481	1495	1502*										
OVRLAY	010626	141	1559*											
OVRLYA	010642	1562*	1567											
OVRLYB	010662	1566	1568*											
PAR	015474	827	1121*	1815*										
PARITY	006442	1114	1121*											
PC	0000007	190	141*	159*	237*	363*	364*	365*	380*	408*	446*	468*	491*	498*
		501*	549*	570*	574*	611*	612*	633*	635*	645*	658*	662*	669*	677*
		733*	750*	770*	781*	790*	804*	806*	816*	860*	892*	896*	908*	919*
		931*	949*	955*	961*	969*	1052*	1152*	1256*	1262*	1272*	1299*	1307*	1313*
		1316*	1319*	1325*	1327*	1328*	1334*	1335*	1408*	1423*	1425*	1431*	1451*	1455*
		1476*	1503*											
PENDIN	015150	619	623*	706*	841	1280*	1797*							
POP1SP	005726	230												
POP2SP	022626	240	1575											
PRINT	0104000	620	63	157	158	188	186	207	235	298	349	394	408	407
		458	557	584	647	651	731	753	805	818	821	851	968	968
		1038	1538	1593	1598									
PRTAS0	003104	457*	462	466										
PRTAS1	003116	455	461*											
PRTCNT	015134	857*	464*	465	1289*	1320*	1321	1323*	1791*					
PRTDOT	003530	523	556*	576	588	613	653	721	862	987				
PRTERR	007646	140*	261*	345*	522*	1292	1342*	1351						
PRTFLG	015046	1779*												
PRTOCT	104001	630	64	209	1596	1601								
PRTSHH	015136	1792*												
PSW	001200	530	136*	196*	202*	257*	299*	350*	622*	630*	643*	708*	716*	800*
		819*	923*	930*	1025*	1032*	1284*	1350*	1436*	1518*				
PUSH29	024646	250												
PWRFAL	010460	41	1508*											
PWRUP	010514	1516	1518*											
QMARK	003580	511	548*	748										
RCBAUD	001252	980	240											
RCHAR	015080	992*	1002	1760*										
RCSR	015154	379*	958	965*	976*	991	998*	1007*	1009*	1001*				
RDBR	015156	967*	992	1002*										
READBF	016570	377	973	1028	1027*									
READCT	015056	378*	975*	1004*	1005	1011	1019*	1027	1783*					
READER	005736	971	988*											
READ1	006006	995	1000*											
READ2	006050	1001	1009*											
READ3	006066	1006	1010*											
READ3A	006212	1012	1030*											
READ4	006216	999	1008	1037	1039*									
REC	015326	1009*												
RECERR	007116	1101	1111	1119	1125	1171	1214*							
RECER1	007122	1160	1215*											

RECEXT	007132	1094	1145	12100										
RECNR	015222	823	1210*	18050										
RECNYT	006266	10870	1099	1109	1117	1123	1134	1139	1153	1163	1169	1196	1201	1213
		1217												
RECR4A	006744	1101	11800											
RECSWH	015146	343	909	1120	1175*	1197*	17960							
RECVCK	015020	306*	319	327*	1130	1132*	17600							
RECYER	006256	219	1062	10030										
RECVR1	006350	1096	11030											
RECVR2	006466	1104	11270											
RECVR3	006702	1165	11750	1107										
RECVR4	006736	1129	11860											
RECVR5	006762	1191	11930											
RECVR6	007030	1199	12020											
RECYCL	010376	14060	1500											
REDONE	015036	374	376*	974*	1249*	17750								
RELEASE	003660	612	6150	634										
RESTRY	002460	270	3400	600										
RMODE	015132	390	902*	644*	1190	17900								
RSTAT	015002	991*	1000	1036	17610									
RUBOUT	004540	720	7510											
RUBSWH	015024	729	732*	751	754*	17700								
R0	=X000000	120	150*	151*	152	194*	190*	199*	203*	208	295*	296	315*	316*
		317*	321*	322*	323*	346*	347	359	361*	362	388	438*	439*	440*
		506*	507	916*	917*	918*	996*	997*	1100*	1110*	1110*	1124*	1135*	1136*
		1137*	1138*	1140*	1149*	1150*	1151*	1150*	1170*	1192*	1215*	1216*	1255*	1260*
		1261*	1271*	1500	1929*									
R1	=X000001	130	143*	144	146*	147	163*	167*	170	172	173*	174	195*	210*
		219*	220*	221*	222*	231*	232*	240*	241*	242*	262*	263*	264	267*
		269	273*	274	300*	303	341*	342*	343	433*	436	482	486*	487*
		488	489	493	495	497*	499*	500*	502	505	507	513	516	520
		524	526	528	530	533	536	538	542*	544	548*	561*	599*	678*
		727	734	736	738	741	744*	748	756*	759*	760*	771*	780*	817*
		856*	962*	963	965	966*	967	970*	971*	972*	988	1041*	1051	1083
		1202*	1203*	1204*	1205	1221*	1232	1235*	1237*	1240	1275*	1288	1294*	1295
		1297	1301	1303	1305	1309	1311	1312*	1314*	1315*	1324*	1326*	1333*	1340*
		1353	1355*	1359*	1363*	1364*	1365*	1368	1377*	1395	1402*	1411	1412*	1413*
		1414*	1415*	1416*	1417*	1420	1430*	1442	1445*	1446*	1450*	1454*	1458*	1509
		1519*	1520*	1520*	1500*	1502*	1504*	1506*						
R1A	006614	1147	11550											
R2	=X000002	140	234*	244*	245*	266*	270	301*	309	320*	434*	436	441*	483
		560*	594*	598*	625*	626	679*	693*	709*	710	717*	772*	783*	845*
		846*	847	848*	849	920*	921*	922*	924	989	993*	1002*	1003	1022*
		1023*	1024*	1026	1040*	1004	1007*	1000	1092	1103	1105	1113	1133	1138
		1140	1151	1162	1164	1106	1108	1192	1194	1220*	1233	1236*	1237	1238*
		1240	1242*	1274*	1285	1286*	1294	1330*	1339*	1354	1368*	1369*	1370*	1373
		1378*	1396	1411*	1415	1416	1429*	1437	1438*	1439*	1440*	1447*	1449*	1456*
		1510	1527*											
R2A	006604	11520	1157											
R3	=X000003	150	239*	240	241	243*	244	245	302*	306	307	308	316	322
		329*	330	435*	439	442*	443	484	559*	571	595*	597*	615	617
		618	619	621	623	624	627	628	629	664*	665*	666	680*	681
		683	691*	692*	694*	695	700	702	703*	704	706	711	712	713
		714	715	718*	719	773*	784*	787	819	823	825	827	829	831

ES

		833	836	841	845	853	894	895	909	911	913	917	920	927
		920	929	952	990	1018	1020	1022	1029	1030	1031	1033	1034	1039
		1085	1088	1089	1090	1091	1095	1097	1098	1107	1108	1115	1116	1121
		1122	1127	1128	1130	1132	1136	1141	1143	1149	1155	1156	1159	1166
		1167	1175	1176	1177	1180	1189	1193	1197	1198	1200	1202	1206	1207
		1208	1209	1210	1211	1212	1214	1215	1219	1234	1239	1243	1244	1247
		1250	1251	1253	1259	1260	1264	1265	1266	1273	1397	1405	1406	1410
		1417	1428	1475	1479	1484	1487	1489	1490	1492	1497	1499	1511	1526
R4	=X000004	160	164	172	396	397	398	399	401	403	405	558	596	646
		660	683	689	690	691	699	774	776	778	785	787	788	789
		1086	1127	1177	1178	1179	1188	1193	1218	1398	1399	1403	1405	1427
		1443	1444	1447	1449	1452	1457	1486	1490	1512	1525			
R4A	006642	1142	11620											
R5	=X000005	170	170	171	174	296	347	362	388	392	393	405	454	461
		463	467	587	1513	1524								
SAVCHR	015042	17770												
SCHAR	015030	488	499	684	686	689	796	802	17720					
SEND0P	004204	6890												
SENDLN	004136	553	6770											
SEND0W	014616	341	618	666	681	700	702	1095	17480					
SERVCE	002070	2570	509	1532										
SLASH	014265	731	753	16930										
SND	015642	1097	10210											
SP	=X000006	180	137	258	340	482	483	484	485	558	559	560	561	596
		597	598	599	988	989	990	1039	1040	1041	1083	1084	1085	1086
		1210	1219	1220	1221	1232	1233	1234	1273	1274	1275	1286	1287	1288
		1311	1314	1340	1355	1356	1395	1396	1397	1398	1427	1428	1429	1430
		1438	1441	1442	1443	1457	1458	1502	1508	1509	1510	1511	1512	1513
		1514	1515	1522	1523	1524	1525	1526	1527	1528	1529	1540	1541	1542
		1543	1544	1545	1546	1547	1574	1576						
		16900												
SPACE	014256	363	3880											
SRVERR	002634	389	404	4080										
SRVEXT	002742	833	1166	18170										
ST	015536	270	137	258	340									
STACK	001100	49	1360	504	1603									
START	001342	155	1580	187	210									
START1	001470	161	1630											
START2	001514	1700												
START3	001550	176	1800											
START4	001606	165	1860											
START5	001636	179	1820											
START6	001614	181	1830											
START7	001620	580	358	801	1048									
SWR	001212	364	4310											
SYSCK1	003004	432	4460											
SYSEXT	003060	510	512	541	547	556	977	17640						
SYSSWM	015010	431	433	445	894	913	1143	17620						
SYSSW1	015004	685	687	6980										
YAGA	004244	7000	720											
YAGB	004254	682	6930											
YAGC	004224	705	7080											
YAGD	004316	701	707	7170										
YAGE	004376	823	824	825	826	827	828	829	830	831	832	833	834	835
TEMP	015120													

TITLE	011031	030*	039	040*	043*	044	1515*	1522	1705*						
TKB	001204	157	1600*												
TKS	001202	55*	406												
TOPC	015140	54*	138*	297*	348*	799*									
TPB	001210	1574*	1579*	1500	1501*	1502	1503*	1504	1505*	1506	1505*	1597	1793*		
TPS	001206	57*	456*	463*	1051*	1373*									
TRAN1	007200	56*	452	1049	1371										
TRAN1A	007204	1240*	1245												
TRAN2	007222	1242*	1252	1257	1267										
TRAN3	007254	1241	1247*												
TRAN4	007310	1248	1253*												
TRBAUD	001306	1254	1264*												
TRN	015600	117*	241												
TRNCHK	002246	831	1019*												
TRNERR	007276	295*													
TRNEXT	007332	1256	1259*	1272											
TRNHIT	007144	1246	1260*												
TRNSWH	015152	221	1231*												
TSTBOT	002570	300*	326*	621*	713*	911	927*	1211*	1253	1264*	1798*				
TSTEXT	002632	365	372*												
TTYBUF	016526	373	375	380*											
TTYPTR	015012	243	797*	798	854	1399	1475	1477	1479*	1486	1025*				
TYPECL	007560	741*	742*	743*	755*	756	757*	798*	1765*						
TYPEIT	006226	1299	1307	1323*	1335										
		491	498	501	549	677	733	758	781	1048*	1050	1319	1325	1327	
		1334	1451	1455											
TYPEOP	007606	1304	1330*												
TYPERA	007416	1290*	1300	1308	1317	1331	1336								
TYPERB	007614	1302	1333*												
TYPEXT	007632	1291	1293	1296	1338*										
TYPHES	007370	1204*	1551												
TYPRET	007604	1322	1320*												
TYPSV2	015016	1205*	1339	1767*											
TYPT1	010250	1445*	1453												
TYPT2	010254	1446*	1448												
VERDAT	005542	271	926	933*											
VEREXT	005540	931*													
VERIFY	005310	519	546	892*											
VERLN	005350	900*	906												
VERNXT	005342	897*													
VERPT	005546	139*	259*	518*	902	914	935*	1144							
VFRPT	005322	894*	901												
VRPEXT	005356	898	902*												
VRPSND	005406	896	909*	1152											
VRPSWH	014626	895*	1141	1155*	1156	1159*	1752*								
XBINDE	010212	1436*	1553												
XFERCT	015264	1265*	1007*												
XOCTP3	010040	1308*	1554												
XOCTP6	010032	1305*	1552												
.	016674	320	36	38*	45*	48*	52*	145	153	312	453	503	508	531	
		552	837	842	1195	1350	1362	1372	1488	1521	1694*	1730*	1742*	1744*	
		1746*	1753*	1755*	1759*	1704*	1804*	1806*	1808*	1810*	1812*	1814*	1816*	1818*	
		1020*	1022*	1024*	1026*	1020*									



JMP	49	210	504	509	515	519	532	535	546	553	554	600	671	697	721
	740	749	764	862	907	970	1094	1101	1111	1119	1125	1153	1169	1196	1201
	1213	1217	1532	1547	1603										
JSR	141	159	237	363	364	365	491	498	501	549	570	574	611	612	633
	645	650	662	669	677	733	758	770	781	804	816	860	892	896	900
	949	955	961	969	1152	1256	1272	1299	1307	1313	1316	1319	1325	1327	1334
	1335	1400	1425	1451	1455	1476									
MOV	136	137	142	143	147	148	149	150	162	163	164	165	166	170	172
	176	183	184	194	195	198	202	208	218	219	220	221	222	231	234
	239	240	243	244	245	257	258	262	266	267	268	269	270	271	272
	279	280	281	295	296	300	301	340	341	346	347	358	361	362	377
	379	396	399	433	434	482	483	484	485	488	497	499	518	558	559
	560	561	586	587	596	597	598	599	622	626	627	628	646	664	665
	683	691	700	710	711	712	759	774	780	787	798	801	817	819	823
	825	827	829	831	833	845	847	849	893	895	984	985	920	923	924
	925	926	950	962	965	967	970	971	972	973	976	988	989	990	991
	992	993	1003	1007	1022	1025	1026	1027	1028	1032	1039	1040	1041	1048	1083
	1084	1085	1086	1087	1088	1127	1177	1180	1193	1202	1205	1207	1208	1210	1219
	1220	1221	1232	1233	1234	1235	1236	1238	1273	1274	1275	1285	1286	1288	1311
	1312	1314	1324	1326	1330	1333	1339	1340	1353	1354	1355	1360	1361	1374	1377
	1378	1388	1395	1396	1397	1398	1399	1400	1411	1420	1426	1427	1428	1429	1430
	1437	1438	1439	1442	1443	1444	1445	1454	1456	1457	1458	1475	1479	1484	1486
	1508	1509	1510	1511	1512	1513	1514	1515	1516	1518	1522	1523	1524	1525	1526
	1527	1528	1529	1540	1542	1546	1559	1560	1561	1562	1563	1574	1576	1580	1582
	1584	1586													
MOVB	315	316	321	322	392	393	405	438	439	456	463	486	542	548	609
	690	699	741	756	916	917	996	1002	1051	1100	1110	1118	1124	1135	1136
	1138	1148	1149	1151	1158	1170	1188	1192	1215	1255	1260	1271	1294	1368	1373
	1405														
NEG	703	1019	1206												
NOP	168	169	178	200	201										
ROL	1363	1364	1365												
RTI	562	1042	1222	1276	1341	1379	1459	1588							
RTS	388	408	446	468	635	790	806	919	931	1052	1262	1320	1423	1431	1503
	1568														
SUB	146	1447	1541	1579	1595	1600									
SWAB	1089														
TST	144	154	160	177	204	277	313	319	372	390	431	510	551	729	751
	776	902	914	950	963	994	1000	1011	1036	1092	1141	1144	1190	1290	1292
	1351	1357	1452	1477	1480	1577									
TSTB	452	467	854	1049	1162	1295	1403	1489	1497						
.ABS	2														
.ASCII	1608	1609	1610	1611	1612	1613	1614	1615	1616	1617	1618	1619	1620	1621	1622
	1623	1624	1647	1648	1651	1652	1665								
.ASCIIZ	1625	1627	1629	1631	1632	1634	1637	1639	1642	1645	1646	1649	1650	1653	1654
	1655	1657	1659	1661	1663	1666	1668	1670	1672	1674	1676	1678	1680	1682	1684
	1686	1688	1690	1691	1692	1693									
.BYTE	1685														
.ENABL	3														
.END	1030														
.EVEN	1694														
.REPT	33														
.TITLE	1														

15

ERRORS DETECTED: 0

\*DZVTGA,DZVTGA/CRF\_DZVTGA.SRC  
RUN-TIME: 7 15 3 SECONDS  
CORE USED: 9K