

1. INTRODUCTION	1.1 PURPOSE	1.2 SCOPE	1.3 REFERENCES
2. SYSTEM DESCRIPTION	2.1 SYSTEM ARCHITECTURE	2.2 HARDWARE CONFIGURATION	2.3 SOFTWARE CONFIGURATION
3. OPERATIONAL PROCEDURES	3.1 STARTUP	3.2 NORMAL OPERATION	3.3 SHUTDOWN
4. MAINTENANCE PROCEDURES	4.1 PREVENTIVE MAINTENANCE	4.2 TROUBLESHOOTING	4.3 REPAIR PROCEDURES
5. SAFETY PROCEDURES	5.1 ELECTRICAL SAFETY	5.2 MECHANICAL SAFETY	5.3 ENVIRONMENTAL SAFETY
6. APPENDICES	6.1 GLOSSARY	6.2 INDEX	6.3 INDEX

B01

EOF1DMQUBSEQ

00010000

770325

PDP10 411

HDR1DMQXABSEQ

00010000

770325

DO1

44
45
46
47
48
49
50
51
52
53
54
55
56
57
58

THE TRDP USER MANUAL CONSISTS OF THE FOLLMWING SECTIOLS:
SECTION 1. TRDP INTRODUCTION
SECTION 2. TRDP GENERAL USE DOCUMENTATION
SECTION 3. TRDP UPDATE PROGRAM (UPD2TR)

59
60
61
62
63
64
65
66
67
68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93SECTION 1. TRDP INTRODUCTION
-----TABLE OF CONTENTS

1. WHAT IS TRDP
2. TRDP REQUIREMENTS
3. DISCLAIMERS
4. CONTENTS OF A TRDP PACKAGE
5. THE TRDP PACKAGE
1. WHAT IS TRDP

TRDP IS A NAME FOR A PDP-11 DIAGNOSTIC PACKAGE AVAILABLE ON MULTIMEDIA, INCLUDES TR79F DIAGNOSTIC PACKAGE (9 TRACK MAGTAPE).

THE TRDP PACKAGES CONTAIN PDP-11 FAMILY DIAGNOSTIC PROGRAMS ON MEDIA OTHER THAN PAPER TAPE. TRDP PACKAGES HAVE THE FOLLOWING ADVANTAGES:

- A. MORE COMPACT STORAGE MEDIA.
- B. EASY AND CONVENIENT MEANS OF LOADING PROGRAMS UNDER KEYBOARD CONTROL.
- C. MEANS ARE PROVIDED FOR UPDATING AND MODIFYING PROGRAMS.
- D. POSSIBLE TO SEQUENTIALLY RUN A SERIES OF PROGRAMS THROUGH USE OF THE "CHAIN MODE" FEATURE. (PROGRAMS MUST BE CHAINABLE).

94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117
118
1192. TRDP REQUIREMENTS

2.1 ALL TRDP PACKAGES REQUIRE:

- A. PDP-11 PROCESSOR WITH AT LEAST 16K STORAGE.
- B. CONSOLE DEVICE
- C. TR79F DIAGNOSTIC PACKAGE MEDIA:

2.2 THE ABOVE REQUIREMENTS ARE FOR LOADING AND RUNNING DIAGNOSTIC PROGRAMS ALREADY STORED IN THE DIAGNOSTIC PACKAGE MEDIA. THEY ARE ALSO SUFFICIENT FOR IMPLEMENTING PERMANENT PATCHES ON PROGRAMS WHEN REQUIRED. TO UPDATE A DIAGNOSTIC PACKAGE, THAT IS ADD NEW PROGRAMS OR NEW VERSIONS OF PROGRAMS TO THE PACKAGE, THE FOLLOWING HARDWARE IS REQUIRED:

- A. PC11 HIGH SPEED READER, OR
- B. ASR 33 OR ASR 35 TELETYPE.

2.3 OPTIONAL HARDWARE:

- A. BOOTSTRAP ROM FOR THE TR79F
IT MAKES LOADING THE TRDP MONITOR MORE CONVENIENT.

120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
1413. DISCLAIMERS

3.1 THE TRDP PACKAGES HAVE BEEN DESIGNED FOR DIAGNOSTIC PURPOSES ONLY. THE TRDP SOFTWARE IS NOT INTENDED TO BE COMPATIBLE WITH ANY OTHER PDP-11 FAMILY SOFTWARE. ANY NON-DIAGNOSTIC USES OF THE SOFTWARE, OR USES OF THE SOFTWARE IN OTHER THAN THE MANNER DESCRIBED IN THIS DOCUMENT ARE NOT SUPPORTED.

3.2 THE TRDP PACKAGES ARE BINARY PACKAGES ONLY. THEY PROVIDE THE PDP-11 FAMILY DIAGNOSTIC PROGRAMS IN THE MEDIA DESCRIBED. DOCUMENTATION FOR EACH OF THE PROGRAMS STORED IN A TRDP PACKAGE MUST BE OBTAINED SEPARATELY, FROM SOFTWARE DISTRIBUTION CENTER (SDC). HOWEVER, THIS DOCUMENTATION MUST BE OBTAINED AT THE SAME TIME AS THE PACKAGE, IN ORDER TO INSURE THAT THE DOCUMENTS AND THE PROGRAMS ARE AT THE SAME REVISION LEVEL.

142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167
168
169
1704. CONTENTS OF A TRDP PACKAGE

THE BASIC PARTS OF A TRDP PACKAGE ARE:

- A. A CONTROL PROGRAM REFERRED TO AS THE "MONITOR". THE MONITOR PROVIDES THE MEANS TO LOAD PROGRAMS UNDER KEYBOARD CONTROL, TO OBTAIN A DIRECTORY OF CONTENTS OF THE TRDP MEDIUM (DISK, MAGTAPE, ETC).
- B. TRDP UPDATE PROGRAM #2 (UPD2TR). A 6.5K PROGRAM THAT PROVIDES A MORE COMPREHE SET OF COMMANDS THAT PROVIDE MORE CONVENIENCE AND EASE OF UPDATING THE TRDP PACKAGE.

5. THE TRDP PACKAGE

THE TRDP PACKAGE PROVIDES THE PDP-11 FAMILY DIAGNOSTICS ON 9 TRACK MAGTAPE (TR79F). THE PACKAGE CONSISTS OF THE FOLLOWING ITEMS THAT MUST BE ORDERED INDIVIDUALLY:

- MAINDEC-11-DMQXA TRDP USER MANUAL (THIS DOCUMENT).
- MAINDEC-11-DMZZH-A-MB9 TRDP-TRDP TR79F DIAGNOSTIC PACKAGE (9 TRACK).

171
172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196
197
198
199
200
201
202
203
204
205
206
207
208
209
210

SECTION 2. TRDP GENERAL USE DOCUMENTATION

TABLE OF CONTENTS

- 1. LOADING PROCEDURES
- 1.1 LOADING TRDP MONITOR
- 2. USE PROCEDURES
- 2.1 SETTING THE CONSOLE FILL COUNT
- 2.2 OBTAINING A DIRECTORY
- 2.3 LOADING AND RUNNING PROGRAMS
- 2.4 CHAIN MODE OPERATION
- 2.4.1 CHAIN PROGRAM COMMANDS
- 2.4.2 MAKING A CHAIN
- 2.4.3 RUNNING A CHAIN
- 3. ERRORS
- 3.1 TRDP RESIDENT MONITOR ERRORS

APPENDIX A. TRDP RESIDENT MONITOR COMMANDS

211
212
213
214
215
216
217
218
219
220
221
222
223
224
225
226
227

1.1 LOADING TRDP MONITOR

THE TRDP MONITOR CAN BE LOADED BY BMB873-S1,
OR VIA A "TOGGLE-IN" PROCEDURE.
THE TOGGLE-IN PROCEDURE IS ONLY VALID FOR THE TR79F.

1.1.1 VIA BOOTSTRAP LOADER

- A. MOUNT THE TRDP TAPE ON DRIVE 0 AND MAKE READY.
- B. REWIND DRIVE 0 TO "BOT" AND SET "ON-LINE"
- C. LOAD BMB873-S1 STARTING ADDRESS 173536
- D. PRESS START
- E. GO TO 1.4.3 STEP A.

228
229
230
231
232
233
234
235
236
237
238
239
240
241
242
243
244
245
246
247
248
249
250
251
252
253
254
255
256
257
258
259
260
261
262
263
264
265
266
267
268
269
270
271
272
273
274
275
276
277
278
279
280
281
282
283

1.1.2 VIA "TOGGLE-IN" PROCEDURE

- A. MOUNT TROP TAPE ON DRIVE 0 AND MAKE READY.
- B. REWIND DRIVE 0 TO "BOT" AND SET "ON-LINE".
DRIVE SHOULD BE A LOAD POINT
- C. TOGGLE IN PROGRAM
- D. STARTING ADDRESS AT LOCATION 10000
- E. WAIT UNTILL DRIVE & CPU HALT
- F. LOAD START ADDRESS AT LOCATION ZERO (0) PRESS START KEY

010000	012700	164000	START:	MOV	#164000,R0	
010004	012701	164002		MOV	#164002,R1	
010010	012702	164004		MOV	#164004,R2	
010014	012703	164006		MOV	#164006,R3	
010020	012706	077776		MOV	#77776,SP	;MTBAR
010024	000005			RESET		
010026	004767	000070		JSR	PC,READY	
010032	005011		BURST:	CLR	R1	
010034	010012			MOV	R0,R2	
010036	012710	000005		MOV	#5,R0	
010042	004767	000054		JSR	PC,READY	
010046	032711	000020		BIT	#20,R1	
010052	005011			CLR	R1	
010054	012710	000005		MOV	#5,R0	
010060	004767	000036		JSR	PC,READY	
010064	005004		1\$:	CLR	R4	
010066	010413		REED:	MOV	R4,R3	
010070	012712	174000		MOV	#-2048.,R2	
010074	005011			CLR	R1	
010076	012710	000005		MOV	#5,R0	
010102	004767	000014		JSR	PC,READY	
010106	010405		3\$:	MOV	R4,R5	
010110	112524		PACK:	MOVB	(R5)+,(R4)+	
010112	005205			INC	R5	
010114	020513			CMP	R5,R3	
010116	001374			BNE	PACK	
010120	000000			HALT		
010122	032710	000200	READY:	BIT	#200,R0	
010126	001775			BEQ	READY	
010130	032710	100000		BIT	#100000,R0	
010134	001404			BEQ	RTN	
010136	032711	011000		BIT	#11000,R1	
010142	001001			BNE	RTN	
010144	000000		TAPERR:	HALT		
010146	000207		RTN:	RTS	PC	

284
285
286
287
288
289
290
291
292
293
294
295
296
297
298
299
300
301
302
303
304
3051.1.3 COMMON PROCEDURE

- A. THE MONITOR IS LOADED FROM MEDIUM.
B. THE MONITOR TYPES THE FOLLOWING MESSAGE AND IS THEN READY TO ACCEPT KEYBOARD COMMANDS.
XXXXX-X TRDP - TR79F MONITOR NNK RESTART: XXXXXX
(HELP MESSAGE)

WHERE: NNK IS THE SYSTEM'S STORAGE UP TO 28K.
XXXXXX IS THE MONITOR'S RESTART ADDRESS.
THE DOT (.) INDICATES THE MONITOR IS READY TO ACCEPT COMMANDS.

- C. THE HELP MESSAGE MAY BE ELIMINATED BY TYPING CTL C.
D. GO TO SECTION 2. USE PROCEDURES.

NOTE: <CR> MEANS PRESSING THE "RETURN" KEY ON KEYBOARD.

306
307
308
309
310
311
312
313
314
315
316
317
318
319
320
321
322
323
324
325
326
327
328
329
330
331
332
333
334
335
336
337
338
339
340
341
342
343
344
345
346
347
348
349
350
351
352
353
354
355
356
357
358
359
360
361

2. USE PROCEDURES

THE USE PROCEDURES THAT FOLLOW APPLY TO TRDP

2.1 SET THE FILL COUNT

THE TTY OUTPUT ROUTINE OF THE UPDATE PROGRAM NORMALLY OUTPUTS 14(8) FILLER CHARACTERS AFTER A CARRIAGE RETURN, IN ORDER TO INSURE THAT THE LA30S TERMINAL PRINTS CORRECTLY, HOWEVER, ON TERMINALS OTHER THAN THE LA30S THE FILLER CHARACTERS ARE NOT REQUIRED AND ARE TIME CONSUMING AND ANNOYING. THE NUMBER OF FILLER CHARACTERS OUTPUT CAN BE CHANGED BY MEANS OF THE "F" COMMAND. THE F COMMAND SHOULD BE THE FIRST COMMAND ISSUED IN ORDER TO PROPERLY SET UP THE CONSOL. TYPE:

F<CR>

000014 1

;THE 000014 IS TYPED BY THE PROGRAM AND
;INDICATES THE CURRENT FILLER COUNT. THE 1
;INDICATES THE USER TYPED A FILLER COUNT OF 1.

2.2 OBTAINING A DIRECTORY

TO OBTAIN A DIRECTORY TYPE ONE OF THE FOLLOWING:

D<CR> TO OBTAIN DIRECTORY ON CONSOLE TERMINAL, OR

D/F<CR> TO OBTAIN SHORT DIRECTORY ON CONSOLE TERMINAL,

D/L<CR> TO OBTAIN DIRECTORY ON LINE PRINTER. LINE PRINTER MUST BE PRESENT ON SYSTEM. NO CHECK IS MADE FOR IT.

THE DIRECTORY CONTAINS THE FOLLOWING INFORMATION:

FILNAM.EXT PROGRAM NAME AND EXTENSION ASSIGNED. .BIN, .BIC, AND .SAV, ARE THE ONLY VALID EXTENSIONS FOR TRDP MONITOR USE.

NOTE: .BIN IS A BINARY FILE
.BIC IS A CHAINABLE BINARY FILE
.SAV IS A CORE IMAGE FILE.

LENGTH NUMBER OF BLOCKS USED. DECIMAL NUMBER. (DISK).

START STARTING BLOCK NUMBER. OCTAL NUMBER. (DISK AND DECTAPE).

DATE DATE WHEN PROGRAM WAS PUT ON MEDIUM.

362
363
364
365
366
367
368
369
370
371
372
373
374
375
376
377
378
379
380
381
382
383
384
385
386
387
388
389
390
391
392
393
394
395
396
397
3982.3 LOADING AND RUNNING PROGRAMS

A. TYPE "R" AND THE PROGRAM NAME (UP TO 6 CHARACTERS). DO NOT TYPE THE EXTENSION (.BIN, .BIC,). THIS WILL LOAD AND RUN THE PROGRAM. TO JUST LOAD THE PROGRAM TYPE "L" AND THE PROGRAM NAME. ONCE LOADED TYPING A "S" WILL START THE PROGRAM.

B. DEPRESS THE CTL AND C KEYS.

IF A TYPING ERROR IS MADE, DEPRESS THE CTRL AND C KEYS AT SAME TIME. A DOT (.) WILL BE TYPED. RETYPE "R" AND THE PROGRAM NAME.

C. THE DESIRED PROGRAM IS LOADED, A DOT TYPED, AND,

1. THE PROGRAM SELF STARTS IF IT IS SELF STARTING, OR
2. THE PROGRAM IS STARTED AT LOC 000200 IF THE PROGRAM NAME WAS ENDED WITH AN ALTMODE CHARACTER, OR
3. THE MONITOR WAITS FOR ANOTHER COMMAND. THE PROGRAM JUST LOADED MUST BE STARTED MANUALLY BY TYPING S PROGRAM NAME <CR>.

D. TO LOAD ANOTHER PROGRAM AFTER RUNNING THE PREVIOUSLY LOADED PROGRAM, RESTART THE MONITOR AT THE RESTART ADDRESS, OR RELOAD THE MONITOR AS DESCRIBED IN SECTION 1.

E. POSSIBLE ERRORS ARE DESCRIBED IN SECTION 3.

CAUTION: WHEN LOADING DIAGNOSTICS THAT TEST THE TRDP MEDIUM CARE MUST BE TAKEN TO INSURE THAT THE MEDIUM IS NOT ACCIDENTALLY DESTROYED. THAT IS THE REASON THAT THE MEDIUM MUST BE WRITE-LOCKED. REMOVE IT IF IT IS DESIRED TO TEST THAT DRIVE.

399
400
401
402
403
404
405
406
407
408
409
410
411
412
413
414
415
416
417
418
419
420
421
422
423
424
425
426
427
428
429
430
431
432
4332.4 CHAIN MODE OPERATION

CHAIN MODE OPERATION CONSISTS OF THE SEQUENTIAL EXECUTION OF PROGRAMS WITHOUT OPERATOR INTERVENTION. ONLY PROGRAMS THAT HAVE BEEN MODIFIED TO RUN IN CHAIN MODE CAN BE CHAINED. CHAINABLE PROGRAMS ARE IDENTIFIED IN THE DIRECTORY BY THE EXTENSION .BIC.
NOTE: .BIC IS A CHAINABLE BINARY FILE.

TO RUN CHAIN MODE, THE TRDP MONITOR REQUIRES A FILE INDICATING THE PROGRAMS TO RUN, AND THE NUMBER OF TIMES EACH PROGRAM MUST EXECUTE BEFORE GOING ON TO THE NEXT PROGRAM IN THE TABLE.

A CHAIN FILE MAY BE GENERATED BY USING THE XTECO TEXT EDITOR, AND THE USER MUST PUT A .CCC EXTENSION ON THE CHAIN FILE.
TO SUMMARIZE:

1. CHAIN MODE RUNS CHAINABLE PROGRAMS ONLY. (.BIC EXTENSIONS).
2. A CHAIN FILE INDICATES THE PROGRAMS TO RUN AND THEIR PASS COUNTS.
3. ONLY PROGRAMS RESIDENT ON THE SAME MEDIUM DRIVE CAN BE CHAINED.
4. THE CHAIN FILE MUST BE ON THE SAME MEDIUM WITH A .CCC EXTENSION.

NOTE: THE .CCC EXTENSION INDICATES A CHAIN FILE

CHAIN MODE IS ENTERED BY TYPING:

C FILENAME<CR> (WHILE IN MONITOR MODE).

WHERE:

C IS THE "CHAIN" COMMAND
FILENAME IS THE VALUE OF THE ASCII FILE THAT CONTAINS THE MONITOR COMMANDS TO BE EXECUTED. THE FILE MUST HAVE A ".CCC" EXTENSION.

434
435
436
437
438
439
440
441
442
443
444
445
446
447
448
449
450
451
452
453
454
455
456
457
458
459
460
461
462
4632.4.1 MAKING A CHAIN ASCII FILE

THE CHAIN ASCII FILE MAY BE CREATED BY RUNNING THE XTECO PROGRAM AND USING THE TEXT EDITOR TO CREATE THE ASCII CHAIN FILE. THE CHAIN FILE MAY CONTAIN ANY OF THE COMMANDS SUPPORTED UNDER THE TRDP MONITOR. THE COMMANDS IN THE ASCII FILE ARE EXECUTED IN THE ORDER IN WHICH THEY ARE ENTERED AND RUN AS A BATCH MODE.
EXAMPLE OF A CHAIN FILE;

```

;CPU.CCC
;THIS CHAIN FILE EXERCISES THE XYZ PROCESSOR WITH T1-T13..
.
R DOAA/1000           ;RUN T1 1000 TIMES<CR>
R DOBA/1000           ;RUN T2 1000 TIMES<CR>
R DOCA/1000           ;RUN T3 1000 TIMES<CR>
R DODA/1000           ;RUN T4 1000 TIMES<CR>
R DOEA/1000           ;RUN T5 1000 TIMES<CR>
R DOFA/1000           ;RUN T6 1000 TIMES<CR>
R DOGA/1000           ;RUN T7 1000 TIMES<CR>
R DOHA/1000           ;RUN T8 1000 TIMES<CR>
R DOJ A/1000          ;RUN T9 1000 TIMES<CR>
R DOKA/1000           ;RUN T10 1000 TIMES<CR>
R DOLA/1000           ;RUN T11 1000 TIMES<CR>
R DOMA/1000           ;RUN T12 1000 TIMES<CR>
L DONA                ;LOAD T13<CR>
S/1000<CR>            ;START IT, RUN 1000 TIMES<CR>
C CPU                 ;RESUBMIT CHAIN FILE AGAIN.

```


464
465
466
467
468
469
470
471
472
473
474
475
476
477
478
479
480
481
482
483
484
485
486
487
488
489
490
491
492
493
494
495
496
497
498
499
500
501
5022.4.2 RUNNING A CHAIN

TO EXECUTE A CHAIN FILE THE USER TYPES;

C FILNAM<CR> OR
C FILNAM/QV<CR>

IN THE FIRST CASE THE PASS COUNT SPECIFIED IN THE CHAIN FILE IS USED BY THE TRDP MONITOR TO DETERMINE THE NUMBER OF PASSES TO EXECUTE EACH PROGRAM. IN THE SECOND CASE THE PASS COUNT IS NOT USED AND EACH PROGRAM IS EXECUTED ONLY ONCE. THE /QV SWITCH PROVIDES A SINGLE EXECUTION MODE OF OPERATION OR "QUICK VERIFY". THE CHAIN FILE TO BE EXECUTED MUST HAVE AN EXTENSION OF .CCC.

THE CHAIN FILE AND THE OBJECTIVE PROGRAMS TO BE RUN MUST RESIDE IN THE SAME TRDP MEDIUM AND MUST BE MOUNTED ON DRIVE 0 OF TRDP DEVICE

WHEN IN CHAIN MODE SWITCH REGISTER OR SOFTWARE SWITCH REGISTER SHOULD BE SET TO 000000.

THE TRDP MONITOR WILL TYPE EACH COMMAND THAT IT EVALUATES AND THEN PROCEED TO EXECUTE IT.

IF THE MONITOR ENCOUNTERS A PROGRAM THAT DOES NOT HAVE A .BIC EXTENSION IT TYPES "NEXFIL". THEN IF THE ERROR RESULTED FROM A R (RUN COMMAND) ONLY, IT WILL CONTINUE WITH THE CHAIN FILE COMMAND, OTHERWISE IT TERMINATES THE CHAIN OPERATION.

WHEN THE LAST COMMAND OTHER THAN ANOTHER "C" COMMAND HAS BEEN EXECUTED THE TRDP MONITOR TERMINATES CHAIN MODE AND TYPES A DOT(.), READY TO ACCEPT ANOTHER COMMAND FROM THE CONSOLE.

IF THE USER WISHES TO TERMINATE CHAIN MODE BEFORE ITS NORMAL TERMINATION HE MAY DO SO BY REPEATEDLY TYPING CTL C (^C) AT THE CONSOLE UNTIL THE MONITOR ACCEPTS IT AT THE END OF A PROGRAM PASS.

503			
504	3.	ERRORS	
505		-----	
506	3.1	TRDP RESIDENT MONITOR ERRORS	
507		-----	
508			
509			
510		INVCMD/SW	INVALID COMMAND AND/OR SWITCH. CHECK COMMAND
511			JUST GIVEN.
512			
513		DEVERR	DEVICE ERROR ON EITHER INPUT OR OUTPUT DEVICE.
514			CHECK THAT OUTPUT DEVICE IS WRITE-ENABLED.
515			
516		EOM	END OF MEDIUM. OCCURS DURING INPUT OPERATIONS
517			WHEN THE PROGRAM ATTEMPTS TO INPUT AND THE FILE
518			IS AT AN END. SERIOUS PROBLEM. FILE IN STOR-
519			AGE IS PROBABLY WIPED OUT.
520			
521		INVADR	INVALID ADDRESS. MUST BE EVEN WITHIN EXISTING
522			LOCORE AND HICORE LIMITS, AND MUST NOT BE WITHIN
523			UPDATE PROGRAM.
524			
525		CKSMER	CHECKSUM ERROR DURING "LOAD" COMMAND.
526			
527		POFLO	PROGRAM TOO LARGE TO LOAD WITHIN EXISTING CORE
528			SPACE.
529			
530		INVNAM	INVALID CHARACTER TYPED FOR FILE NAME.
531			
532		NEXFIL	NON-EXISTENT FILE. IF IN CHAIN MODE
533			THE PROGRAM TO BE RUN DOES NOT HAVE
534			.BIC EXTENSION.
535			
536			
537			

538
539
540
541
542
543
544
545
546
547
548
549
550
551
552
553
554
555
556
557
558
559
560
561
562
563
564
565
566
567
568
569
570
571
572
573
574
575

APPENDIX A. TRDP RESIDENT MONITOR COMMANDS

F<CR>	SET CONSOLE FILL COUNT.
D<CR>	DIRECTORY ON THE TTY CONSOLE.
D/F<CR>	SHORT DIRECTORY ON THE TTY CONSOLE.
D/L	DIRECTORY ON THE LINE PRINTER.
D/L/F	SHORT DIRECTORY ON LINE PRINTER.
R COPY	STARTS THE COPY PROGRAM.
R FILENAME	STARTS INDICATED PROGRAM.
L FILENAME	LOADS DESIRED PROGRAM.
S FILENAME	STARTS DESIRED PROGRAM WHICH WAS LOADED UNDER "L" COMMAND.
S ADDR	STARTS PROGRAM AT SPECIFIED ADDRESS.
C FILENAME	RUNS DESIRED CHAIN TABLE.
C FILENAME/QV	RUNS DESIRED CHAIN IN QUICK VERIFY.
E 0<CR>	ENABLE DRIVE 0(TADP)
E 1<CR>	ENABLE DRIVE 1(TADP)

576
577
578
579
580
581
582
583
584
585
586
587
588
589
590
591
592
593
594
595
596
597
598
599
600
601
602
603
604
605
606
607
608
609
610
611
612
613
614
615
616
617
618
619
620SECTION 3. TRDP UPDATE PROGRAMS #2 (UPD2TR)
-----TABLE OF CONTENTS

1. ABSTRACT
2. REQUIREMENTS
3. LOADING AND STARTING PROCEDURE.
4. COMMAND DESCRIPTIONS
5. ERRORS
6. UPDATING TRDP MEDIA
7. HELP ASCII REFERENCE FILE

APPENDIX A. UPD2TR COMMANDS

APPENDIX B. PERIPHERALS SUPPORTED BY UPDATE PROGRAMS

APPENDIX C. PROGRAM NAMING CONVENTIONS

1. ABSTRACT

EACH TRDP PACKAGE CONTAINS PROGRAM CALLED UPD2TR.BIN.
THIS PROGRAMS IS USED TO ADD, DELETE, RENAME, OR PATCH PROGRAMS ON TRDP
PACKAGES, AND IN GENERAL, PROVIDE FILE MAINTENANCE SERVICES.

UPD2TR IS A BK PROGRAM WHICH RELOCATES ITSELF TO THE TOP BK OF
MEMORY, LEAVING LOWER STORAGE FREE FOR OTHER PROGRAMS. IT IS
CAPABLE OF PERFORMING OPERATIONS ON ALL TRDP MASS STORAGE DEVICES.

621
622
623
624
625
626
627
628
629
630
631
632
633
634
635
636
637
638
639
640
641
642
643
644
645
646
647
648
649
650
651
652
653
654
655
656
657
658
659
660
661
662
663
664
665
666
667
668
669
670
671
672
673
674
675
6763. LOADING AND STARTING PROCEDURE

UPD2TR IS LOADED VIA THE TRDP MONITOR BY TYPING R UPD2TR<CR>. ONCE LOADED, IT OUTPUTS THE FOLLOWING MESSAGE:

XXXXX-X - TRDP UPDATE PROGRAM #2 21-FEB-76
DATE:

TYPE THE DATE ACCORDING TO FOLLOWING FORMAT:

DATE:DD-MMM-YY<CR>

DD IS THE DAY OF THE MONTH, MMM IS JAN, FEB, MAR, APR, MAY, JUN, JUL, AUG, SEP, OCT, NOV, DEC, AND YY IS BETWEEN 70 AND 99.

TEST IS MADE TO MAKE SURE NO MONTH HAS MORE THAN 31 DAYS. BUT DATES LIKE FEB 30, APR 31, ETC., WILL NOT BE DETECTED AS ERRORS BUT WILL BE STORED AWAY AS FEB 30, APR 1, ETC.

THE PROGRAM WILL TYPE BACK THE DATE FOLLOWED BY:

PROGRAM RELOCATED TO:YYYYYY ;INITIAL ADDR WHERE PROGRAM RELOCATED TO.
RESTART: XXXXXX ;UPD1 RESTART ADDRESS.
* ;* INDICATES READY FOR KEYBOARD COMMANDS.

4. COMMAND DESCRIPTIONS

4.1 IN THE COMMAND DESCRIPTIONS THAT FOLLOW, AN INDICATION IS PROVIDED AS TO THE AVAILABILITY OF THE COMMAND UNDER UPD2TR.

4.2 THE FILL COMMAND (UPD2TR)

THE CONSOLE TERMINAL OUTPUT ROUTINE OF THE UPDATE PROGRAM NORMALLY OUTPUTS 14(8) FILLER CHARACTERS AFTER A CARRIAGE RETURN, IN ORDER TO INSURE THAT THE LA30 TERMINAL PRINTS CORRECTLY. HOWEVER, ON TERMINALS OTHER THAN THE LA30 THE FILLER CHARACTERS ARE NOT REQUIRED AND ARE TIME CONSUMING AND ANNOYING. THE NUMBER OF FILLER CHARACTERS OUTPUT CAN BE CHANGED BY MEANS OF THE "FILL" COMMAND. THE FILL COMMAND SHOULD BE THE FIRST COMMAND ISSUED IN ORDER TO PROPERLY SET UP THE CONSOLE. TYPE:

FILL<CR>

000014 1

;THE 000014 IS TYPED BY THE PROGRAM AND
;INDICATES THE CURRENT FILLER COUNT. THE 1
;INDICATES THE USER TYPED A FILLER COUNT OF 1.

677
678
679
680
681
682
683
684
685
686
687
688
689
690
691
692
693
694
695
696
697
698
699
700
701
702
703
704
705
706
707
708
709
710
711
712
713
714
715
716
717
718
719
720
721
722
723
724
725
726
727
728
729
730
731
732

THE FILLER COUNT SHOULD BE SET TO A 1 FOR ASR33 AND ASR35 TERMINALS. FOR OTHER TERMINALS, SET THE NUMBER TO WHATEVER PRODUCES CORRECT PRINTING AFTER A CARRIAGE RETURN, WITHOUT UNDUE DELAY.

4.3 THE "CLR" COMMAND (UPD2TR)

THE "CLR" COMMAND IS USED TO CLEAR TO ZEROES ALL CORE STORAGE BELOW THE UPDATE PROGRAM. IT IS PROVIDED IN CASE THE USER WISHES CORE STORAGE TO BE "ZEROED" PRIOR TO LOADING A PROGRAM. TYPE:

CLR<CR>

THE PROGRAM RESPONDS WITH *

4.4 LOAD COMMAND (UPD2TR)

THE LOAD COMMAND IS USED TO LOAD FILES STORED IN ABS FORMAT. (FILES WITH EXTENSIONS OF .BIN, .BIC, OR OTHER EXTENSIONS KNOWN TO INDICATE ABS FORMAT).

LOAD DEV: FILNAM.EXT ;COMMAND FORMAT

IF THE DEVICE HAS NO DIRECTORY, THEN THE FILE NAME AND EXTENSION SHOULD BE OMITTED.

LOAD PR: ;USER COMMAND TO LOAD FROM PAPER TAPE.
XFRADR: 000050 CORE: 000000,017670
*

XFRADR: INDICATES THE STARTING ADDRESS OF THE PROGRAM LOADED. IF IT IS 000001 OR ODD, THE PROGRAM IS NOT SELF-STARTING.

CORE: LEFT NUMBER INDICATES THE LOWEST LOCATION LOADED INTO DURING THE LOAD. THE RIGHT NUMBER INDICATES THE HIGHEST LOCATION LOADED INTO DURING THE LOAD. THE LEFT AND RIGHT NUMBERS IN EFFECT INDICATE THE CORE LIMITS OF THE PROGRAM.

4.5 DUMP COMMAND (UPD2TR)

THE MEMORY CONTENTS CAN BE WRITTEN TO A TRDP MEDIUM IN ABS FORMAT BY THE DUMP COMMAND.

DUMP DEV: FILNAM.EXT ;COMMAND FORMAT

PROCESSING STARTS FROM PROGRAM'S LOW CORE LIMIT AND PROCEEDS TO AND INCLUDES THE PROGRAM'S HIGH CORE LIMIT.

*DUMP DKO:XXX.BIN ;DUMP PROGRAM ONTO DKO:. CALL IT XXX.BIN
*DIR DKO:

12-JAN-76					
ENTRY#	FILNAM	.EXT	DATE	LENGTH	START
000001	XXX	.BIN	26-AUG-72	17	000105

733
734
735
736
737
738
739
740
741
742
743
744
745
746
747
748
749
750
751
752
753
754
755
756
757
758
759
760
761
762
763
764
765
766
767
768
769
770
771
772
773
774
775
776
777
778
779
780
781
782
783
784
785
786
787
788

000002 2
 000003 3 2-AUG-72 12C 000172
 FREE FILES: 445 2-AUG-72 12C 000206

*

4.6 THE "XFR" COMMAND (UPD2TR)

ONCE A PROGRAM HAS BEEN LOADED INTO CORE VIA THE "LOAD" COMMAND, IT CAN BE MADE SELF-STARTING OR NOT SELF-STARTING AT THE USER'S DISCRETION. AS DESCRIBED UNDER "LOAD COMMAND", THE LOAD ROUTINE TYPES: XFRADR:XXXXXX INDICATING WHETHER A PROGRAM IS OR IS NOT SELF-STARTING. THE USE OF "XFR" IS:

XFR<CR> :REQUEST CURRENT TRANSFER ADDRESS.
 000001 000050 :000001 IS THE CURRENT XFR ADDRESS. 000050 IS THE
 :NEW XFR ADDRESS ENTERED BY THE USER.

NOTE: DIAGNOSTIC PROGRAMS ARE PURPOSELY MADE NOT SELF-STARTING.

4.7 THE "START" COMMAND (UPD2TR)

THE "START" COMMAND IS USED TO BEGIN EXECUTION OF A PROGRAM IN CORE.

START<CR> ;USED TO START A SELF-STARTING PROGRAM.

START ADR<CR> ;USED TO A START A PROGRAM AT A SPECIFIC LOCATION.

NOTE: IF THE COMMAND START<CR> IS GIVEN FOR A NON-SELF-START PROGRAM, THE PROCESSOR WILL TRAP OUT WITHOUT AN ERROR MESSAGE.

4.8 THE SAVE COMMAND (UPD2TR)

THE CONTENTS OF CORE ARE WRITTEN ONTO THE OUTPUT DEVICE AS A SINGLE BLOCK OF DATA, STARTING AT LOC 000000 AND PROCEEDING TO THE HIGH LIMIT OF THE PROGRAM IN CORE. THE SAVE COMMAND IN EFFECT, SAVES A "CORE IMAGE" OF THE CONTENTS OF CORE. FOR TRDP PURPOSES THE ONLY VALID EXTENSION FOR SAVED PROGRAMS IS .SAV.

THE ONLY CURRENT USE OF THE SAVE COMMAND IS TO PLACE A CORE IMAGE OF THE TRDP MONITOR ON CASSETTE AND MAGTAPE. TRDP PACKAGES DO NOT CONTAIN ANY OTHER CORE IMAGE FILES

NOTE: .SAV IS A CORE IMAGE FILE.

SAVE DEV: FILNAM.EXT ;COMMAND FORMAT.

*SAVE DKO: UPDATE.SAV
 *DIR DKO:

12-JAN-76					
ENTRY#	FILNAM	.EXT	DATE	LENGTH	START
000001	UPDATE	.BIN	26-AUG-72	17	000105

789
790
791
792
793
794
795
796
797
798
799
800
801
802
803
804
805
806
807
808
809
810
811
812
813
814
815
816
817
818
819
820
821
822
823
824
825
826
827
828
829
830
831
832
833
834
835
836
837
838
839
840
841
842
843
844

```

000002      2      2-AUG-72      12C      000172
000003      UPDATE .SAV      26-AUG-72      12C      000247
FREE FILES: 445
*
```

4.9 THE GET COMMAND (UPD2TR)

THE GET COMMAND PLACES THE "SAVED" PROGRAM INTO CORE STARTING AT LOC 000000.

GET DEV:FILNAM.EXT

```

↑C
*GET DKD:UPDATE.SAV
*
```

NOTE: SAVE CORE IMAGE FILES (.SAV FILES) ARE NO LONGER IN USE. THE "GET" COMMAND IS NO LONGER VERY USEFUL. IT HAS BEEN LEFT AS THE COMPLEMENTARY COMMAND FOR THE SAVE COMMAND.

4.10 THE MOD COMMAND (UPD2TR)

ONCE A PROGRAM IS LOADED IT CAN BE PATCHED BY THE MOD COMMAND.

MOD ADR CAUSES UPDATE TO PRINT THE FOLLOWING:

ADR CONTENTS OF ADR,
AND WAITS FOR USER RESPONSE.

THE USER MAY TYPE IN AN OCTAL NUMBER AND A TERMINATOR, OR JUST A TERMINATOR.

IF A NUMBER IS TYPED, IT IS USED AS THE NEW CONTENT OF ADR.

THE TERMINATOR CAN BE EITHER A CARRIAGE RETURN OR A LINE FEED. CARRIAGE RETURN TAKES THE PROGRAM BACK TO COMMAND MODE, WHEREAS THE LINE FEED CAUSES THE NEXT WORD (ADR+2) TO BE OPENED FOR MODIFICATION

```

#MOD 50
000050 000005 3 <LF>
000052 012737 4 <LF>
000054 000340 5 <CR>
#MOD 50
000050 000003 <LF>
000052 000004 <CR>
*
```

THE MOD COMMAND WILL NOT ALLOW THE USER TO GO BEYOND THE PROGRAM'S PROTECTION LIMIT, AN "INVCOR" ERROR WILL OCCUR.
(SEE SECTION 4.13)

845
846
847
848
849
850
851
852
853
854
855
856
857
858
859
860
861
862
863
864
865
866
867
868
869
870
871
872
873
874
875
876
877
878
879
880
881
882
883
884
885
886
887
888
889
890
891
892
893
894
895
896
897
898
899
900

4.11 THE CORE COMMAND (UPD2TR)

THE CORE COMMAND CAUSES THE LOWER AND UPPER LIMITS OF THE PROGRAM IN CORE TO BE TYPED:

```
*CORE<CR>
000000,014776          ;LEFT NUMBER IS THE LOWER CORE LIMIT.
                        ;RIGHT NUMBER IS THE UPPER CORE LIMIT.
```

4.12 THE "LOCORE" COMMAND (UPD2TR)

THE "LOCORE" COMMAND IS USED TO CHANGE THE LOWER LIMIT OF THE PROGRAM IN CORE:

```
*LOCORE ADR<CR>      ;WHERE ADR IS THE NEW LOW CORE LIMIT. IT IS RECOMMENDED
                        ;THAT ADDRESS BE EVEN.
```

4.13 THE "HICORE" COMMAND (UPD2TR)

THE "HICORE" COMMAND IS USED TO CHANGE THE UPPER LIMIT OF THE PROGRAM IN CORE:

```
*HICORE ADR<CR>      ;WHERE ADR IS THE NEW HIGH CORE LIMIT. RECOMMEND THAT
                        ;ADDRESS BE EVEN, BUT MUST BE HIGHER THAN THE LOWER
                        ;LIMIT, AND MUST BE LOWER THAN START OF UPDATE PROGRAM.
```

TYPICALLY, THE HICORE COMMAND IS USED TO RESERVE AN AREA FOR PATCHING A PROGRAM. THE UPDATE PROGRAM WILL NOT ALLOW MODIFICATION OF CORE OUTSIDE THE UPPER AND LOWER CORE LIMITS. THEREFORE, THE NEW LIMITS MUST BE SET FIRST. THIS PROTECTS THE CORE OUTSIDE THE PROGRAM FOR THE USER.

4.14 THE DIRLP AND DIR COMMANDS

```
DIR      (UPD2TR)
DIRLP    (UPD2TR)
#DIRLP DEV:      ;COMMAND FORMAT
COMMAND EXAMPLES;
UPD2TR ONLY
-----
```

```
*DIR DEV:*.BIN          ;GIVES A DIRECTORY OF ALL FILES
                        ;WITH A ".BIN" EXTENSION.
*DIR DEV:*.BI?         ;GIVES A DIRECTORY OF ALL FILES
                        ;WITH AN EXTENSION BEGINING WITH
                        ;"BI" AND ANY OTHER CHARACTER
                        ;SUCH AS BIN OR BIC.
DIR DEV:ZTC???.BI?    ;GIVES A DIRECTORY OF ALL FILES
                        ;WITH THE FIRST THREE CHARACTERS
                        ;OF THE FILENAME BEING "ZTC"
                        ;AND HAVING AN EXTENSION BEGINING
                        ;WITH "BI". EXAMPLES; ZTCA.BIN,
                        ;ZTCB.BIN, ZTCC.BIC.
```

NOTE: AT THE END OF THE DIRECTORY THE FREE FILES AND FREE BLOCKS WILL BE

901
902
903
904
905
906
907
908
909
910
911
912
913
914
915
916
917
918
919
920
921
922
923
924
925
926
927
928
929
930
931
932
933
934
935
936
937
938
939
940
941
942
943
944
945
946
947
948
949
950
951
952
953
954
955
956

INDICATED ONLY ON RANDOM ACCESS DEVICES.

NOTE: DIR IN UPDATE #1 GIVES ONLY THE SHORT DIRECTORY (NO LENGTH, NO START).

DIRLP CAUSES THE DIRECTORY OF DEV: TO PRINTED ON LINE PRINTER. IF DIR IS USED, THE DIRECTORY IS TYPED ON CONSOLE DEVICE. DO NOT USE DIRLP UNLESS A LINE PRINTER EXISTS, AS NO CHECK IS MADE FOR ITS EXISTENCE. THE PROGRAM WILL PROBABLY TRAP.

```
#DIR DKO:
12-JAN-76
ENTRY#      FILNAM .EXT      DATE           LENGTH        START
000001      1                2-AUG-72       14            000105
000002      2                2-AUG-72       12C           000172
000003      3                2-AUG-72       12C           000206
000004      5                2-AUG-72       12C           000222
FREE FILES: 444
*
```

LENGTH IS THE NUMBER OF BLOCKS (10) THE FILE OCCUPIES. A "C" AFTER THE FILE LENGTH INDICATES THE FILE IS CONTIGUOUS.

START IS THE ADDR OF FIRST BLOCK OF FILE. OCTAL NUMBER.
DATE IS THE FILE CREATION DATE.

4.15 THE DELETE COMMAND (UPD2TR)

DEL DEV:FILNAM.EXT

CAUSES THE FILE NAMED TO BE DELETED FROM THE DIRECTORY.

```
#DEL DKO:1
#DIR DKO:
```

```
12-JAN-76
ENTRY#      FILNAM .EXT      DATE           LENGTH        START
000002      2                2-AUG-72       12C           000172
000003      3                2-AUG-72       12C           000206
000004      5                2-AUG-72       12C           000222
FREE FILES: 444
*
```

4.16 THE ZERO COMMAND (UPD2TR)

ZERO DEV:

DESTROYS THE DIRECTORY. AS FAR AS UPDATE IS CONCERNED, THERE IS NOTHING ON THE DEVICE. THIS SHOULD BE DONE ON A BRAND NEW TAPE OR CARTRIDGE SINCE UPDATE USES THE ZERO COMMAND TO RESERVE SOME ROOM FOR USE BY THE TRDP MONITOR. VALID FOR ALL MASS STORAGE DEVICES.

```
*ZERO DKO:
```

957
 958
 959
 960
 961
 962
 963
 964
 965
 966
 967
 968
 969
 970
 971
 972
 973
 974
 975
 976
 977
 978
 979
 980
 981
 982
 983
 984
 985
 986
 987
 988
 989
 990
 991
 992
 993
 994
 995
 996
 997
 998
 999
 1000
 1001
 1002
 1003
 1004
 1005
 1006
 1007
 1008
 1009
 1010
 1011
 1012

*DIR DKO:
 26-AUG-72

FILNAM.EXT LENGTH START DATE

FREE FILES: 448
 *

4.17 THE BOOT (UPD2TR)

4.17.1 BOOT DEV:

CAUSES BLOCK 0 OF DEV TO BE LOADED INTO MEMORY, STARTING AT LOC 000000.
 BLOCK 0 IS ASSUMED TO HAVE A BOOT LOADER. THE PROGRAM THEN JUMPS TO
 LOC 000000 TO START THE BOOT LOADER.

EXAMPLE:

BOOT DKO:<CR> ;BOOTS IN THE RKDP MONITOR.

BOOT MTD:<CR> ;BOOTS IN THE TRDP MONITOR.

4.17.2 SAVM DEV: (UPD2TR)

CAUSES THE FIRST 4K TO BE WRITTEN IN .SAV FORMAT (CORE IMAGE)
 STARTING AT THE MONITOR CORE IMAGE BLOCK OF THE DEVICE.
 THIS COMMAND IS USED TO WRITE THE TRDP MONITOR ON THE
 DEVICE AS A CORE IMAGE THAT IS BOOTABLE.

*LOAD DK1:RKDP.BIN ;LOAD RKDP MONITOR.
 *SAVM DKO: ;SAVE IT AS CORE IMAGE ON DKO:

THE SAVM COMMAND IS VALID ONLY ON RANDOM ACCESS DEVICES.

NOTE: SAVM IS NOT A DIRECTORY ENTRY IT WILL NOT SHOW
 ON DIRECTORY.

4.18 THE RENAME COMMAND (UPD2TR)

*REN DEV:NEWMAM.EXT+DEV:OLDNAM.EXT

RENAMES THE OLD FILE. THE DEVICES MUST BE THE SAME. NOT ALLOWED
 ON MAGTAPE OR CASSETTE.

*DIR DKO:

12-JAN-76
 ENTRIES

FILNAM .EXT DATE LENGTH START

1013
 1014
 1015
 1016
 1017
 1018
 1019
 1020
 1021
 1022
 1023
 1024
 1025
 1026
 1027
 1028
 1029
 1030
 1031
 1032
 1033
 1034
 1035
 1036
 1037
 1038
 1039
 1040
 1041
 1042
 1043
 1044
 1045
 1046
 1047
 1048
 1049
 1050
 1051
 1052
 1053
 1054
 1055
 1056
 1057
 1058
 1059
 1060
 1061
 1062
 1063
 1064
 1065
 1066
 1067
 1068

```

000001 ASD .123 26-AUG-76 16C 000105
FREE FILES: 447

*REN DKO:123.ASD+DKO:ASD.123
*DIR DKO:
12-JAN-76
ENTRY# FILNAM .EXT DATE LENGTH START
000001 123 .ASD 26-AUG 16C 000105
FREE FILES: 447
*
  
```

4.19 PIP COMMAND (UPD2TR)

 PIP IS USED TO COPY A LINKED FILE FROM ANY DEVICE THAT CAN INPUT TO ANY DEVICE THAT CAN PERFORM OUTPUT OPERATIONS. FILE DATA IS NOT CHECKED FOR FORMAT OR CHECKSUMS.

PIP DEV1:FILNAM.EXT+DEV2:FILNAM.EXT

PIP PP:+PR: (COPIES PAPER TAPE)
 *PIP DKO:123.456<PR: ;PAPER TAPE TO DISK
 *PIP PP:<DKO:123.456 ;DISK TO PAPER TAPE PUNCH.
 *DIR DKO:

```

12-JAN-76
ENTRY# FILNAM .EXT DATE LENGTH START
000001 123 .ASD 26-AUG-72 16C 000105
000002 123 .456 26-AUG-72 3 000125
FREE FILES: 446
*
  
```

THE USER SHOULD MAKE SURE THAT THE OUTPUT FILE NAME DOESN'T EXIST ALREADY ON THE OUTPUT DEVICE DIRECTORY.

PIP DKO:A+DKO:A ;IS A NO NO.
 DELOLD ;CAUSES THIS ERROR. DELETE OLD FILE 1ST.

PIP HAS OTHER USEFUL FEATURES:

PIP PP:+PR: COPIES A PAPER TAPE.

IMPORTANT!!!

A PROGRAM THAT HAS BEEN "PIPPED" TO A TRDP DEVICE MUST BE LOADED IMMEDIATELY VIA THE "LOAD" COMMAND TO INSURE THAT NO ERRORS HAVE OCCURRED DURING THE "PIP" COMMAND AS THE PIP COMMAND DOES NOT CHECKSUM INPUT DATA!

4.20 THE "FILE" COMMANDS (UPD2TR)

1069
1070
1071
1072
1073
1074
1075
1076
1077
1078
1079
1080
1081
1082
1083
1084
1085
1086
1087
1088
1089
1090
1091
1092
1093
1094
1095
1096
1097
1098
1099
1100
1101
1102
1103
1104
1105
1106
1107
1108
1109
1110
1111
1112
1113
1114
1115
1116
1117
1118
1119
1120
1121
1122
1123
1124

UPD2TR INCLUDES A GROUP OF COMMANDS WHICH CAN EXECUTE ON MULTIPLE FILES WITHOUT REQUIRING THE NAME OF EACH FILE TO BE INDIVIDUALLY LISTED IN THE COMMAND STRINGS. THESE ARE THE "FILE" COMMANDS, INCLUDING FILE, FILEF, FILEL, FILEG, FILED, AND FILET. FOLLOWING THIS GENERAL DESCRIPTION, THEIR DIFFERENCES WILL BE INDIVIDUALLY EXPLAINED. NOTE THAT THE "FILE" COMMANDS IN GENERAL, CAN NOT BE USED WITH NON-DIRECTORY DEVICES (SUCH AS PR,PP, LP).

THE "FILE" COMMANDS RECOGNIZE TWO SPECIAL CHARACTERS IN THE FILE NAME AND EXTENSION. THESE CHARACTERS, THE ASTERISK (*) AND THE QUESTION-MARK (?) ALLOW A SINGLE NAME TO REFERENCE SEVERAL FILES.

NOTE THAT FILE NAMES ARE ALWAYS RECORDED AS HAVING 6 CHARACTERS, AND EXTENSIONS ALWAYS HAVE 3 CHARACTERS. THEY ARE LEFT-JUSTIFIED WITH TRAILING BLANKS ADDED, AND THE BLANKS ARE PART OF THE NAME.

BECAUSE THE "FILE" COMMANDS CAN HANDLE SEVERAL FILES PER COMMAND ISSUED, THEIR TREATMENT OF ERROR CONDITIONS SHOULD BE NOTED. IF A DEVICE ERROR OCCURS IN THE PROCESS OF FINDING A FILE (I.E. WHEN THE DIRECTORY IS REFERENCED IN THE CASE OF DISK OR DECTAPE, OR THE BLOCKS ARE SCANNED IN THE CASE OF CASSETTE OR MAGTAPE), THE "FILE" COMMAND IS ABORTED AND THE ERROR IS PRINTED. IF A DEVICE ERROR, CHECKSUM ERROR, OR END OF MEDIUM ERROR OCCURS WHILE READING A FILE (FILEL, FILEG, AND FILET) THE ERROR IS REPORTED AND THEN PROCESSING OF THE COMMAND IS CONTINUED.

THE "FILE" COMMANDS LIST THE DESCRIPTIVE INFORMATION ABOUT EACH FILE AS IT IS PROCESSED, INCLUDING FILE NAME, TRANSFER ADDRESS, AND LOCORE AND HICORE VALUES. THE /N AND /LP SWITCHES ARE INCLUDED TO ALTER THIS IF DESIRED.

4.21 THE "ASTERISK" CONSTRUCTION

THE "ASTERISK" CONSTRUCTION PERMITS REFERENCE TO ALL FILES HAVING A DESIRED EXTENSION (ANY FILENAME), TO ALL FILES HAVING A DESIRED FILENAME (ANY EXTENSION), OR TO ALL FILES ON A DEVICE. ITS USE IN THE FILENAME POSITION MEANS "ANY FILENAME" AND IN THE FILE EXTENSION POSITION MEANS "ANY EXTENSION".

TO REFER TO ALL FILES HAVING A DESIRED EXTENSION (ANY FILENAME), AN ASTERISK IS TYPED FOR THE FILENAME:

DKO:*.OBJ MEANS ALL FILES ON DISK D WITH
A .OBJ EXTENSION

TO REFER TO ALL FILES WITH A DESIRED FILENAME (ANY EXTENSION), AN ASTERISK IS TYPED FOR THE EXTENSION:

DKO:UPD2TR.* MEANS ALL FILES ON DISK D WITH THE
FILENAME UPD2TR, SUCH AS UPD2TR.P11,
UPD2TR.LST, AND UPD2TR.DOC

1125
1126
1127
1128
1129
1130
1131
1132
1133
1134
1135
1136
1137
1138
1139
1140
1141
1142
1143
1144
1145
1146
1147
1148
1149
1150
1151
1152
1153
1154
1155
1156
1157
1158
1159
1160
1161
1162
1163
1164
1165
1166
1167
1168
1169
1170
1171
1172
1173
1174
1175
1176
1177
1178
1179
1180

TO REFER TO ALL FILES ON A DEVICE (ANY FILENAME, ANY EXTENSION),
ASTERISKS ARE TYPED FOR BOTH THE FILENAME AND THE EXTENSION:

MT3:*. * MEANS ALL FILES ON MAGTAPE 3

4.22 THE "WILD CHARACTER" CONSTRUCTION

THE "WILD CHARACTER" CONSTRUCTION PERMITS REFERENCE TO ALL FILES
WHOSE FILE NAMES DIFFER IN SPECIFIC CHARACTER POSITIONS. WHEN
SEARCHING FOR FILES CORRESPONDING TO THE NAME IN THE COMMAND STRING,
ANY CHARACTER IS ACCEPTED AS MATCHING A QUESTION MARK. FOR EXAMPLE:

DKO:UPD?.DOC MEANS ANY FILE WHOSE NAME BEGINS WITH "UPD",
HAS ANY CHARACTER NEXT (INCLUDING A BLANK)
AND THEN TWO BLANKS, WITH A .DOC EXTENSION.
UPD1.DOC AND UPD2TR.DOC WOULD BOTH QUALIFY.

4.23 THE FILE COMMAND (UPD2TR)

THE FILE COMMAND IS USED TO DO BULK TRANSFERS FROM ONE DEVICE TO
ANOTHER. IT IS SIMILAR TO A PIP COMMAND EXCEPT THAT IT CAN UTILIZE
THE "ASTERISK" AND "WILD CHARACTER" CONSTRUCTIONS. IF A FILE OF THE
SAME NAME ALREADY EXISTS ON THE OUTPUT DEVICE, THE FILE COMMAND
(UNLIKE THE PIP COMMAND) WILL DELETE THE OLD FILE. NOTE ALSO THAT
THE FILE COMMAND CAN TRANSFER BOTH LINKED AND CONTIGUOUS (CORE-
IMAGE) FILES.

FILE DEV:<DEV:FILNAM.EXT ;COMMAND FORMAT

WHERE THE DEVICE NAME ON THE LEFT IS THE OUTPUT DEVICE AND
THAT ON THE RIGHT IS THE INPUT DEVICE.

4.24 THE FILEF COMMAND (UPD2TR)

THE FILEF COMMAND IS USED TO DO FAST TRANSFERS ONTO ALL DIRECTORY DEVICES.
FOR MAG TAPE LOGICAL END OF TAPE IS FOUND AND ALL THE REQUESTED
FILES ARE TRANSFERRED SEQUENTIALLY ONTO THE TAPE STARTING AT THAT
POINT. THIS FAST TRANSFER COMMAND ELIMINATES THE CHECK OF THE TAPE
DIRECTORY WHICH IS MADE BEFORE EACH FILE TRANSFER IF THE FILE COMMAND
IS USED.

FOR RANDOM ACCESS DEVICES THE FILE IS TRANSFERRED TO THE FIRST
AVAILABLE SPACE ON THE DEVICE.

FILEF DEV:<DEV:FILNAM.EXT ;COMMAND FORMAT

1181 4.25 THE FILED COMMAND (UPD2TR)
 1182 -----
 1183 THE FILED COMMAND DELETES THE FILES NAMED FROM THE DEVICE'S DIRECTORY.
 1184 FILED DEV:FILNAM.EXT ;COMMAND FORMAT
 1185
 1186 UPD2TR NOW PERMITS THE USE OF THE DEL(ETE) COMMAND WITH * AND WILD CHARACTER
 1187 FILENAME CONSTRUCTION. EXAMPLE:
 1188
 1189 DEL DKO:*.BIN ;DELETES ALL FILES IN DKO: WITH .BIN
 1190 ;EXTENSION.
 1191
 1192 CAUTION!!! THE UPD2TR PROGRAM DOES NOT REQUIRE VERIFICATION OF A MASS
 1193 DELETION COMMAND. THE USER MUST BE CAREFUL NOT TO
 1194 SPECIFY A DELETE THAT HE DOES NOT REALLY MEAN TO OCCUR.
 1195 IF IT SHOULD, TYPING CONTROL C WILL ABORT THE COMMAND
 1196 AT THE EARLIEST OPPORTUNITY.
 1197
 1198
 1199
 1200 4.26 THE FILEL COMMAND (UPD2TR)
 1201 -----
 1202 THE FILEL COMMAND SEQUENTIALLY LOADS INTO CORE EACH FILE REFERENCED.
 1203 IT ASSUMES THAT ALL REFERENCED FILES ARE ABS FORMAT (IF NOT A CKSMER
 1204 OR EOM ERROR WILL OCCUR). ITS PURPOSE IS TO SHOW THAT ALL ABS
 1205 FORMATTED FILES CAN BE CORRECTLY LOADED (CHECKS FOR DEVICE AND
 1206 CHECKSUM ERRORS). IF AN ERROR OCCURS, IT WILL IDENTIFY THE TYPE OF
 1207 ERROR AND THE DEVICE.
 1208
 1209 FILEL DEV:FILNAM.EXT ;COMMAND FORMAT
 1210 THE LOAD COMMAND MAY ALSO BE USED IN UPD2TR TO PERFORM THE SAME FUNCTIONS
 1211 AS THE FILEL COMMAND.
 1212
 1213
 1214 4.27 THE FILEG COMMAND (UPD2TR)
 1215 -----
 1216 THE FILEG (FILE GET) COMMAND IS SIMILAR TO THE FILEL COMMAND EXCEPT
 1217 THAT IT LOADS AND CHECKS CONTIGUOUS (CORE-IMAGE) FILES INSTEAD OF
 1218 ABS FORMAT FILES. DEVICE ERRORS AND SIZE ERRORS WILL BE REPORTED.
 1219
 1220 FILEG DEV:FILNAM.EXT ;COMMAND FORMAT
 1221
 1222 THE GET COMMAND MAY ALSO BE USED IN UPD2TR TO PERFORM THE SAME FUNCTIONS
 1223 AS THE FILEG COMMAND.
 1224
 1225
 1226 4.28 THE FILET COMMAND (UPD2TR)
 1227 -----
 1228 THE FILET COMMAND TESTS ALL FILES NAMED BY READING THEM INTO A BUFFER
 1229 TO MAKE CERTAIN THAT NO DEVICE ERRORS OCCUR. ANY DEVICE ERRORS ARE
 1230 LISTED AS THEY OCCUR.
 1231
 1232 FILET DEV:FILNAM.EXT ;COMMAND FORMAT
 1233
 1234
 1235
 1236

1237
1238
1239
1240
1241
1242
1243
1244
1245
1246
1247
1248
1249
1250
1251
1252
1253
1254
1255
1256
1257
1258
1259
1260
1261
1262
1263
1264
1265
1266
1267
1268
1269
1270
1271
1272
1273
1274
1275
1276
1277
1278
1279
1280
1281
1282
1283
1284
1285
1286
1287
1288
1289
1290
1291
12924.29 THE /LP AND /N SWITCHES (UPD2TR)

THE "FILE" COMMANDS NORMALLY CAUSE PRINTING OF THE NAMES OF THE FILES CHECKED, THEIR TRANSFER ADDRESSES, AND LOCORE AND HICORE VALUES, ON THE CONSOLE TERMINAL. THE /LP SWITCH CAUSES THIS INFORMATION TO BE OUTPUT ON THE LINE PRINTER INSTEAD. THE /N SWITCH INHIBITS PRINTING OF THIS INFORMATION, SO THAT ONLY ERROR PRINTOUTS ARE OUTPUT. SWITCHES MUST NOW BE SPECIFIED AT END OF THE COMMAND STRING.

```
FILET DKO:*.*/LP           ;TEST ALL FILES ON DKO AND PRINT
                           ;THE FILE INFORMATION AND ERROR
                           ;INFORMATION ON THE LINE PRINTER
```

```
FILEL /N MT2:*.BIN/LP      ;LOAD ALL .BIN FILES FROM MAGTAPE 2,
                           ;REPORTING ONLY ERROR INFORMATION
                           ;ON THE LINE PRINTER
```

```
DEL DKO:*.TXT/LP          ;DELETE ALL .TXT FILES FROM DKO: AND
                           ;PRINT DELETED FILES ON LINE PRINTER.
```

4.30 THE "EOT" COMMAND (UPD2TR)

THE "EOT" COMMAND IS PROVIDED AS A MEANS OF PLACING AN "END-OF-TAPE" MARK OR SENTINEL FILE AT A SELECTED SPOT ON MAGTAPE OR CASSETTE. APPLICATIONS OF THIS COMMAND INCLUDE REPLACING AN "EOT" MARK WHEN IT HAS BEEN ACCIDENTALLY DESTROYED, OR WHEN THE USER WISHES TO DELETE FILES AT THE END OF THE MEDIUM, AND STILL BE ABLE TO USE THE SPACE TAKEN UP BY THOSE DELETED FILES.

THE PROCEDURE TO BE USED IS AS FOLLOWS:

- A. POSITION THE MAGTAPE BY PERFORMING A FILET COMMAND ON THE FILE PRECEDING THE SPOT WHERE THE "EOT" IS TO BE PLACED. IN PRACTICE, IF AN "EOT" HAS BEEN LOST, THE USER SHOULD FILET THE NEXT TO THE LAST FILE, SINCE THE LAST FILE MAY BE UNRECOVERABLE.
- B. PERFORM AN "EOT" COMMAND.

EXAMPLE:

```
*FILET MTO:ZGRADO.BIN<CR> ;READS FILE ZGRADO.BIN AND STOPS.
*EOT<CR>                  ;WRITES EOT.
```

4.31 THE TEXT COMMAND (UPD2TR)

UPD2TR INCLUDES THE FACILITY TO EXECUTE A SEQUENCE OF COMMANDS CONTAINED IN AN ASCII TEXT FILE. THIS ASCII TEXT FILE IS CREATED VIA THE TEXT COMMAND. ALSO SEE SECTION 4. XTECO TEXT EDITOR.

```
TEXT DEV:FILNAM.EXT           ;COMMAND FORMAT
```

WHEN THE TEXT COMMAND IS ISSUED UPD2TR OPENS THE NAMED FILE FOR

1293
1294
1295
1296
1297
1298
1299
1300
1301
1302
1303
1304
1305
1306
1307
1308
1309
1310
1311
1312
1313
1314
1315
1316
1317
1318
1319
1320
1321
1322
1323
1324
1325
1326
1327
1328
1329
1330
1331
1332
1333
1334
1335
1336
1337
1338
1339
1340
1341
1342
1343
1344
1345
1346
1347
1348

OUTPUT AND RESPONDS WITH A QUOTATION MARK (") TO INDICATE ITS READINESS TO ACCEPT TEXT. ANY ASCII CHARACTER (EXCEPT CONTROL C AND RUBOUT) WILL BE ACCEPTED AS INPUT TO THE TEXT FILE. CONTROL C (↑C) WILL ABORT TEXT MODE, RETURNING TO COMMAND MODE AND CLOSING THE OUTPUT FILE. CONTROL Z (↑Z) IS THE STANDARD TERMINATOR FOR INPUT TO THE TEXT FILE. RUBOUT CAN BE USED TO DELETE CHARACTERS ON THE CURRENT LINE (BUT NOT ON PRECEDING LINES).

THREE CHARACTERS, THE POUND SIGN (#), THE SEMICOLON (;), AND THE DOLLAR SIGN (\$) HAVE SPECIAL SIGNIFICANCE IN THE TEXT FILE. THE # SIGN AND ; ARE USED TO START A COMMENT WHICH IS TO BE PRINTED DURING COMMAND FILE EXECUTION. THE \$ SIGN IS USED TO START A COMMENT WHICH IS TO BE PRINTED AND FOLLOWED BY A HALT DURING COMMAND FILE EXECUTION (SUCH AS "\$PRESS CONT WHEN READY").

4.32 THE PRINT COMMAND (UPD2TR)

THE PRINT COMMAND OUTPUTS A FILE ON THE LINE PRINTER. IT IS USED TO PRINT TEXT FILES, AND WILL OUTPUT TO THE LINE PRINTER. AFTER THE TEXT FILE IS PRINTED THE PROGRAM OUTPUTS 10 CARRIAGE RETURNS AND LINE FEEDS TO SIMULATE A FORM FEED. NOTE THAT BOTH PRINT AND TYPE COMMANDS ACCEPT * AND WILD CHARACTER CONSTRUCTION IN FILENAMES, SO THAT MULTIPLE TEXT FILES MAY BE PRINTED WITH ONE COMMAND.

PRINT DEV:FILNAM.EXT ;COMMAND FORMAT

PRINT DEV:*.TXT

WHERE DEV IS THE SOURCE DEVICE ON WHICH THE FILE RESIDES.

NOTE THAT NO CHECK IS MADE OF FILE PRINTABILITY.

4.33 THE TYPE COMMAND (UPD2TR)

SAME AS THE PRINT COMMAND EXCEPT THAT IT OUTPUTS TO THE CONSOLE TERMINAL INSTEAD OF TO THE LINE PRINTER.

TYPE DEV:FILNAM.EXT ;COMMAND FORMAT

4.34 THE DO COMMAND (UPD2TR)

THE DO COMMAND IS USED TO CAUSE THE EXECUTION OF A COMMAND FILE. THE FILE MUST BE ON ONE OF THE TRDP STORAGE MEDIA (DECTAPE, MAGTAPE, CASSETTE, OR DISK). THE FILE IS EXECUTED LINE BY LINE, AND MUST BE TERMINATED BY A ↑Z (CONTROL Z). EXECUTABLE FILES ARE CREATED VIA THE TEXT COMMAND, OR VIA THE XTECO TEXT EDITOR PROGRAM (SEE SECTION 4.) FOR NOTES ON THE FILE'S FORMAT AND THE USE OF SPECIAL CHARACTERS, SEE THE PRECEDING TEXT COMMAND DESCRIPTION.

DO DEV:FILNAM.EXT ;COMMAND FORMAT

1349
1350
1351
1352
1353
1354
1355
1356
1357
1358
1359
1360
1361
1362
1363
1364
1365
1366
1367
1368
1369
1370
1371
1372
1373
1374
1375
1376
1377
1378
1379
1380
1381
1382
1383
1384
1385
1386
1387
1388
1389
1390
1391
1392
1393
1394
1395
1396
1397
1398
1399
1400
1401
1402
1403
14044.35 THE ASG (ASSIGN) COMMAND (UPD2TR)

THE ASG (ASSIGN) COMMAND ALLOWS THE USE OF LOGICAL DEVICE NAMES IN COMMAND FILES. ALLOWED LOGICAL DEVICE NAMES ARE 1, 2, 3, 4, AND SYS. A COMMAND FILE MAY USE A LOGICAL NAME SUCH AS "1" INSTEAD OF SPECIFYING, FOR EXAMPLE, DK0 OR DK1. THEN, BEFORE EXECUTING THE COMMAND FILE, THE USER CAN ASSIGN THE DESIRED PHYSICAL DEVICE TO THE LOGICAL NAME, PERMITTING USE OF ANY AVAILABLE UNIT.

ASG PHYSICAL DEV = LOGICAL DEV ;COMMAND FORMAT

REVERSAL OF PHYSICAL AND LOGICAL DEVICE NAMES IN THE COMMAND STRING RESULTS IN "INVDEV" ERROR MESSAGE. THE COMMAND IS NOT PERFORMED.

ASG DK1: = 2: ;ASSIGNS DISK 1 TO LOGICAL DEVICE "2"

4.37 THE PATCH COMMAND (UPD2TR)

THE PATCH COMMAND ENABLES THE USER TO PATCH A PROGRAM ON ANY DIRECTORY-ORIENTED (RANDOM ACCESS) TRDP SUPPORTED DEVICE. NO OUTPUT DEV: FILE SPECIFICATION IS REQUIRED OR PERMITTED, THE INPUT DEVICE IS ASSUMED TO BE THE DESIRED OUTPUT DEVICE.

THE FILE(S) TO BE PATCHED MUST BE IN ABS FORMAT BINARY FILE. THE PATCH ROUTINE DOES NOT CHECK IN ADVANCE FOR CORRECT FILE FORMAT. THE FOLLOWING EXTENSION ARE FOR TRDP ABS FORMAT FILES; .BIN, .BIC, .MPG.

CARRIAGE-RETURN OR LINE-FEED ARE THE ONLY CHARACTERS WHICH MAY BE USED FOR TERMINATING A TYPED ENTRY. THE LINE-FEED MAY BE THOUGHT OF AS AN "ADVANCE" KEY, WHICH WILL GO TO THE NEXT ADDRESS. THE RUBOUT KEY MAY BE USED TO CORRECT TYPING MISTAKES MADE ON INPUT. ALL ADDRESSES ENTERED MUST BE EVEN. IF AN ADDRESS IS TYPED (IN RESPONSE TO A PROMPT) WHICH IS ODD, THE PROMPT WILL BE RE-ASKED.

IF AN ADDRESS IS TYPED WHICH IS NOT WITHIN THE CORE LOAD LIMITS OF THE FILE BEING OPERATED UPON, THE UNKNOWN CONTENTS OF THE SPECIFIED ADDRESS WILL BE INDICATED BY "XXXXXX". THE PROGRAM WILL THEN GIVE THE USUAL "?" PROMPT, ASKING IF MODIFICATION IS DESIRED.

IN RESPONSE TO THE "ADDR?" PROMPT, IF A CARRIAGE-RETURN OR A LINE-FEED IS TYPED AS THE ONLY THING ON THE INPUT LINE, THE EXIT SEQUENCE WILL BE ENTERED, AT SUCH TIME, THE USER IS ASKED TO WRITE-ENABLE THE OUTPUT DEVICE AND CONFIRM THE FACT THAT THE PATCHES SHOULD BE ENTERED INTO THE SPECIFIED FILE.

IF A FILE IS MODIFIED BY THE USE OF THE "PATCH" COMMAND, THE DATE AND LENGTH OF THE FILE OPERATED UPON ARE UPDATED IN THE DEVICE DIRECTORY AS

1405
1406
1407
1408
1409
1410
1411
1412
1413
1414
1415
1416
1417
1418
1419
1420
1421
1422
1423
1424
1425
1426
1427
1428
1429
1430
1431
1432
1433

REQUIRED.

IF THE FILE BEING PATCHED CONTAINS REPRESENTATIONS OF ISOLATED SINGLE-BYTE DATA, FOR EXAMPLE THOSE GENERATED BY THE FOLLOWING ASSEMBLY CODE SEQUENCES;

A. .=24
 .BYTE 120
 .EVEN ;GENERATES ONLY 1 BYTE OF DATA

B. .=413
 .BYTE-1 CORE LIMITS. OCCURS DURING DUMP COMMAND.

DIRERR INVALID NAME IN DEVICE DIRECTORY.

DELERR BIT MAP ERROR DURING DELETE OPERATION ON DECTAPE OR DISK.
 NOT USUAL UNLESS MEDIUM HAS BEEN WIPED OUT. TRANSFER
 FILES TO OTHER MEDIUM. (SEE SECTION 4.).

POFLOW PROGRAM TOO LARGE TO LOAD WITHIN EXISTING CORE SPACE.

INVSW INVALID SWITCH SPECIFIED IN COMMAND STRING.

DUMP ERROR ACT MODE ONLY (SEE SECTION 7). OCCURS DURING DUMP
 COMMAND WHEN DATA DUMPED ON OUTPUT DEVICE DOES NOT MATCH
 DATA IN CORE.

1434			
1435	5.	ERRORS	
1436		-----	
1437			
1438		INVCMD	INVALID COMMAND. CHECK COMMAND JUST GIVEN.
1439			
1440		INVDEV	INVALID DEVICE SPECIFIED FOR COMMAND GIVEN.
1441			
1442		INVADR	INVALID ADDRESS. MUST BE EVEN, WITHIN EXISTING LOCORE AND HICORE LIMITS, AND MUST NOT BE WITHIN UPDATE PROGRAM.
1443			
1444			
1445		INVNAM	INVALID FILE NAME. NO SPECIAL CHARACTERS ALLOWED. A THROUGH Z, AND 0 THROUGH 9 ARE ONLY VALID CHARACTERS. ALSO OCCURS IF * OR WILD CHARACTER CONSTRUCTION FILENAMES ARE SPECIFIED TO A COMMAND THAT DOES NOT ALLOW IT.
1446			
1447			
1448			
1449			
1450		NEXFIL	NON-EXISTENT FILE. FILE DOES NOT EXIST IN DEVICE DIRECTORY.
1451			
1452		DELOLD	DELETE OLD FILE BEFORE GIVING COMMAND THAT WOULD CREATE
1453			

1454
1455
1456
1457
1458
1459
1460
1461
1462
1463
1464
1465
1466
1467
1468
1469
1470
1471
1472
1473
1474
1475
1476
1477
1478
1479
1480
1481

5.1 ERRORS UNIQUE TO THE FILCMP COMMAND

UNEQUAL FILE TYPES	INDICATES THE TWO FILES BEING COMPARED ARE NOT OF SIMILAR STRUCTURE.
UNEQUAL FILE SIZES	INDICATES THE TWO FILES BEING COMPARED ARE NOT THE SAME SIZE.
SCRATCH FILE SHORTER THAN MASTER FILE	THE SCRATCH FILE IS THE FILE ON THE DEVICE WHICH IS ON THE LEFT OF THE BACK ARROW IN THE COMMAND STRING.
SCRATCH FILE LONGER THAN MASTER FILE	THE SCRATCH FILE WHICH IS ON THE LEFT OF THE BACK ARROW IS LONGER THAN THE FILE ON THE RIGHT.
BLOCK COMPARE ERROR XTH BLOCK, YTH BYTE	THIS INDICATES THERE WAS AN ERROR IN THE COMPARE. X AND Y INDICATE THE BLOCK NUMBER AND BYTE NUMBER WHERE THE ERROR OCCURRED.

1482
1483
1484
1485
1486
1487
1488
1489
1490
1491
1492
1493
1494
1495
1496
1497
1498
1499
1500
1501
1502
1503
1504
1505
1506
1507
1508
1509
1510
1511
1512
1513
1514
1515
1516
1517
1518
1519
1520
1521
1522
1523
1524
1525
1526
1527
1528
1529
1530
1531
1532
1533
1534
1535
1536
1537

6. UPDATING TRDP MEDIA

UPDATING TRDP MEDIA CONSISTS OF:

- A. PATCHING EXISTING PROGRAMS (DEPO), OR
- B. REPLACING PROGRAMS WITH NEWER VERSIONS, OR
- C. ADDING NEW PROGRAMS.

WHEN FIRST BECOMING ACQUAINTED WITH THE USE OF THE UPDATE PROGRAMS THE USER SHOULD MAKE EXTRA SURE THAT A BACKUP FOR THE MEDIUM TO BE MODIFIED EXISTS, IN ORDER TO BE ABLE TO RECOVER FROM FATAL ERRORS. (ZEROING THE MEDIUM, DELETING THE WRONG FILE, ETC.).

6.1 PATCHING EXISTING PROGRAMS

PATCHING A PROGRAM IN A TRDP MEDIUM CONSISTS OF:

- A. LOADING EXISTING PROGRAM INTO MEMORY (LOAD COMMAND)
- B. MAKING MODIFICATIONS (PATCHING - MOD COMMAND)
- C. DELETING OLD PROGRAM (DEL COMMAND)
- D. STORING MODIFIED PROGRAM (DUMP COMMAND).

AN ALTERNATE, SAFER, PROCEDURE WOULD STORE THE PATCHED PROGRAM FIRST, AND THEN AFTER TRYING THE MODIFIED PROGRAM, THE OLD PROGRAM WOULD BE DELETED.

EXAMPLE:

```

↑C
#LOAD MTO:DOSAO.BIN          (LOAD PROGRAM)
#MOD 3450                    (MODIFY PROGRAM)
003450 012737 000000
#MOD 3766
003766 012737 000000
003770 000005 000000
#DEL MTO:DOSAO.BIN          (DELETE OLD PROGRAM)
#DUMP MTO:DOSA1.BIN         (STORE MODIFIED PROGRAM)
#LOAD MTO:DOSA1.BIN         (LOAD NEW PROGRAM)
#START 200                  (TRY OUT NEW PROGRAM)

```

IT IS IMPORTANT WHEN IMPLEMENTING DEPO'S THAT THE NAME OF THE PROGRAM REFLECT THE DEPO LEVEL OF THE PROGRAM. SEE APPENDIX D. PROGRAM NAMING CONVENTIONS.

6.2 REPLACING PROGRAMS WITH NEWER VERSIONS, OR ADDING NEW PROGRAMS

TO REPLACE A PROGRAM, OR TO ADD A NEW ONE:

- A. DELETE OLD PROGRAM IF REPLACING IT,

1538
1539
1540
1541
1542
1543
1544
1545
1546
1547
1548
1549
1550
1551
1552
1553
1554
1555
1556
1557
1558
1559
1560
1561
1562
1563
1564
1565
1566
1567
1568
1569
1570
1571
1572
1573
1574
1575
1576
1577
1578
1579
1580
1581
1582
1583
1584
1585
1586
1587
1588
1589
1590
1591
1592
1593

B. LOAD NEW PROGRAM INTO MEMORY,
C. DUMP PROGRAM ONTO DEVICE.

EXAMPLE 1:

```
*DEL MTO:DOSA1.BIN          (DELETE OLD PROGRAM)
*LOAD PR:                   (LOAD NEW PROGRAM )
*DUMP MTO:DOSBO.BIN        (STORE NEW PROGRAM)
*LOAD MTO:DOSBO.BIN        (LOAD NEW PROGRAM)
*START 200                  (TRY NEW PROGRAM)
```

EXAMPLE 2:

```
DEL MTO:DOSA1.BIN          ;DELETES OLD PROGRAM.
LOAD PR:                   ;LOADS NEW PROGRAM FROM PAPER TAPE.
DUMP MTO:DOSBO.BIN        ;ADDS NEW PROGRAM.
LOAD MTO:DOSBO.BIN        ;CHECKS THAT PROGRAM LOADS CORRECTLY.
```

NOTE: DELETING A PROGRAM FROM CASSETTE OR MAGTAPE DOES NOT PHYSICALLY REMOVE THE PROGRAM FROM THE MEDIUM, IT STILL TAKES UP SPACE. TO CLEAN UP THE CASSETTE OR MAGTAPE, IT MUST BE COPIED VIA ITS TRDP MONITOR'S COPY ROUTINE, WHICH COPIES ONLY "GOOD" FILES.

```
*PIP MTO:OVLY.BIN+PR:      (PIP TO MTO: FROM PR:)
*LOAD MTO:OVLY.BIN        (LOAD OVERLAY)
```

RELOADING OF A PROGRAM THAT HAS BEEN "PIPPED" DIRECTLY TO A DEVICE IS IMPORTANT, TO INSURE THAT NO READING ERRORS HAVE OCCURRED. THE PIP COMMAND DOES NOT CHECKSUM INPUT DATA.

6.3 GENERATING A TRDP MEDIUM

IT MAY BE DESIRABLE TO CREATE A CUSTOM MADE MEDIUM CONTAINING ONLY THOSE PROGRAMS REQUIRED TO TEST A PARTICULAR SYSTEM. AS AN EXAMPLE, SUCH A MEDIUM COULD CONTAIN:

- A. PROCESSOR TESTS
- B. MEMORY TESTS
- C. I/O PROGRAMS FOR THAT SYSTEM

WITH SUCH A MEDIUM, THE ENTIRE SYSTEM COULD BE TESTED USING THE CHAIN MODE OF OPERATION, WITHOUT HAVING TO SWITCH DECTAPES, OR CASSETTES.

THE PROCEDURES FOR GENERATING A NEW MEDIUM FOLLOW.

6.3.1 CREATING A NEW TRDP MAGTAPE

- A. MOUNT "NEW" MAGTAPE ON DRIVE 0
- B. PERFORM THE FOLLOWING COMMANDS:

FOR A TR79F

1594
 1595
 1596
 1597
 1598
 1599
 1600
 1601
 1602
 1603
 1604
 1605
 1606
 1607
 1608
 1609
 1610
 1611
 1612
 1613
 1614
 1615
 1616
 1617
 1618
 1619
 1620
 1621
 1622
 1623
 1624
 1625
 1626
 1627
 1628
 1629
 1630
 1631
 1632
 1633
 1634
 1635
 1636
 1637
 1638
 1639
 1640
 1641

ZERO: MTO:
 LOAD DKO:TRDP.BIN
 SAVE MTO:TRDP.SAV
 DUMP MTO:TRDP.BIN
 LOAD DKO:UPDTR.BIN
 DUMP MTO:UPDTR.BIN

6.3.9 CREATING A TRDP MEDIUM - COMMON PROCEDURE

ONCE THE MONITOR HAS BEEN SAVED ON THE MEDIUM,UPD2TR.BIN
 SHOULD BE SAVED:

FILEF DEV1:<DEVO:UPD?.BIN ;TRANSFERS UPD1.BIN AND UPD2TR.BIN

CONTIGUOUS (CORE-IMAGE) FILES SHOULD BE TRANSFERRED NEXT (TO GUARANTEE
 ROOM ON THE MEDIUM). THIS CAN BE DONE VIA THE FILEF COMMAND:

FILEF DEV1:<DEVO:A.SAV ;TRANSFER A.SAV

FROM THIS POINT ON, THE DESIRED PROGRAMS ARE TRANSFERRED FROM THE
 INPUT MEDIA TO THE OUTPUT MEDIUM VIA THE FILEF COMMAND. USE OF THE
 SPECIAL FEATURES CAN CONSIDERABLY DECREASE THE NUMBER OF COMMANDS
 REQUIRED. FOR EXAMPLE, TO TRANSFER ALL DECTAPE DIAGNOSTICS TO THE
 NEW MEDIUM A SINGLE FILEF COMMAND WILL SUFFICE:

FILEF DEV1:<DEVO:XTC???.* ;TRANSFERS ALL PROGRAMS WHOSE
 ;NAMES START WITH "XTC"

AFTER ALL THE DESIRED FILES HAVE BEEN STORED ON THE NEW MEDIUM,
 IT SHOULD BE TESTED VIA THE FILET, FILEL, AND FILEG COMMANDS:

FILET DEV1:.* /LP ;READ EVERY FILE ON THE NEW MEDIUM,
 ;LISTING ALL INFORMATION ON THE
 ;LINE PRINTER
 FILEL DEV1:*.BI?/N ;LOAD ALL ABS FORMAT FILES
 ;TO VERIFY THAT NO ERRORS
 ;OCCUR. LIST ERRORS ONLY.
 FILEG DEV1:*.SA?/N ;LOAD ALL CONTIGUOUS FILES TO
 ;VERIFY THAT NO ERRORS OCCUR.
 ;LIST ERRORS ONLY.

IT IS ALSO A GOOD IDEA TO DUPLICATE THE NEW MEDIUM TO PROVIDE A
 BACKUP.

1642
1643
1644
1645
1646
1647
1648
1649
1650
1651
1652
1653
1654
1655
1656
1657
1658
1659
1660
1661
1662
1663
1664
1665
1666
1667
1668
1669
1670
1671
1672
1673
1674
1675
1676
1677
1678
1679
1680
1681
1682
1683
1684
1685
1686
1687
1688
1689
1690
1691
1692
1693
1694
1695
1696
1697

APPENDIX B. UPD2TR PROGRAM COMMANDS

FILL<CR>	SETS UP TERMINAL FOR CORRECT PRINT AFTER CRLF.
CLR<CR>	CLEARs CORE BELOW UPDATE PROGRAM
XFR<CR>	PERMITS MAKING PROGRAM SELF-STARTING, OR NON SELF-STARTING.
DUMP DEV:FILNAM.EXT	WRITES MEMORY CONTENTS IN ABS FORMAT
LOAD DEV:DILNAM.EXT	LOADS ABS FORMAT PROGRAM (.BIN, .BIC)
PIP DEV1:FILNAM.EXT+DEV2:FILNAM.EXT	COPIES FILE FROM ONE DEVICE TO ANOTHER.
SAVE DEV:FILNAM.EXT	WRITES MEMORY CONTENTS ONTO CONTIGUOUS BLOCKS
GET DEV:FILNAM.EXT	LOADS CORE IMAGE PROGRAM
MOD ADR	MODIFIES CORE CONTENTS
CORE	TYPES PROTECTION LIMITS
LOCORE ADR	ENTERS LOW PROTECTION LIMIT
HICORE ADR	ENTERS HIGH PROTECTION LIMIT
DIR DEV:	TYPES DEV DIRECTORY ON TTY
DIRLP DEV:	TYPES DEV DIRECTORY ON LINE PRINTER.
DEL DEV:FILNAM.EXT	DELETES FILE FROM DEV DIRECTORY
ZERO DEV:	ZEROES DEVICE DIRECTORY
BOOT DEV:	LOADS BLOCK 0 OF DEV STARTING AT LOC 000000
SAVM DEV:	WRITES 4K ONTO DEV STARTING AT BLOCK 30
START	STARTS PROGRAM AT LOC 000000
START ADR	STARTS PROGRAM AT ADR
ACT	PUTS UPD2TR PROGRAM IN "ACT MODE"
NOTACT	TAKES UPD2TR PROGRAM OUT OF "ACT MODE"
FILE DEV:<DEV:FILENAM.EXT	COPIES FILE(S) FROM ONE DEVICE TO ANOTHER, DELETING FILE OF SAME NAME BEFORE DOING THE TRANSFER
FILEF DEV:<DEV:FILNAM.EXT	SAME AS FILE EXCEPT THAT WITH CASSETTE OR MAGTAPE FAST TRANSFERS ARE PERFORMED (NO DIR CHE

1698		
1699	FILET DEV:FILNAM.EXT	READS FILE AND CHECKS FOR DEVICE ERRORS (FILE "TEST")
1700		
1701		
1702	FILEL DEV:FILNAM.EXT	LOADS FILES (ASSUMES ABS FORMAT) CHECKING FOR DEVICE AND CHECKSUM ERRORS
1703		
1704		
1705	FILEG DEV:FILNAM.EXT	LOADS FILES (ASSUMES CONTIGUOUS FORMAT) CHECKING FOR DEVICE AND FILE SIZE ERRORS
1706		
1707		
1708	FILED DEV:FILNAM.EXT	DELETES NAMED FILES
1709		
1710	FILCMP DEV:<DEV:FILNAM.EXT	COMPARES TWO FILES AGAINST EACH OTHER ON TWO TRDP MEDIUMS.
1711		
1712		
1713	PATCH	ENABLE THE USER TO PATCH A PROGRAM.
1714		
1715	TEXT DEV:FILNAM.EXT	CREATES TEXT FILE FOR PRINTING OR FOR COMMAND EXECUTION
1716		
1717		
1718	PRINT DEV:FILNAM.EXT	OUTPUTS A FILE TO THE LINE PRINTER (ASSUMES IT ENDS WITH A ↑Z)
1719		
1720		
1721	TYPE DEV:FILNAM.EXT	OUTPUTS A FILE TO THE CONSOLE TERMINAL
1722		
1723	DO DEV:FILNAM.EXT	EXECUTES A COMMAND FILE.
1724		
1725	ASG PHYSICAL = LOGICAL	ASSIGNS A PHYSICAL DEVICE TO A LOGICAL DEVICE NAME
1726		
1727		
1728	EOT	WRITES END OF TAPE MARK (FILE) ON MAGTAPE OR CASSETTE AFTER TAPE HAS BEEN POSITIONED.
1729		
1730		
1731	PATCH DEV:FILNAM.EXT	ENABLES PATCHING CAPABILITIES TO A FILE ON THE TRDP MEDIA.
1732		
1733		
1734	FILCMP DEV:=DEV:FILNAM.EXT	COMPARES TWO FILES WITH EACH OTHER.
1735		
1736		
1737		
1738	↑C (CONTROL C)	RETURNS TO COMMAND MODE (OPEN OUTPUT FILE IS CLOSED).
1739		
1740	↑Z (CONTROL Z)	ENDS INPUT TO A TEXT FILE
1741		
1742		
1743	*	USED FOR FILE NAMING TO MEAN "ANY" (ANY FILE NAME OR ANY FILE EXTENSION)
1744		
1745		
1746	?	USED FOR FILE NAMING TO INDICATE A WILD CHARACTER (ANY CHARACTER WILL MATCH IT)
1747		
1748		
1749	# OR ;	USED IN A FILE OF EXECUTABLE COMMANDS TO START A COMMENT LINE WHICH IS TO BE TYPED DURING EXECUTION
1750		
1751		
1752		
1753	\$	SAME AS # BUT CAUSES A HALT AFTER

004

.MAIN. MACY11 27(732) 01-MAR-77 10:39 PAGE 41
DMQXAB.M11

1754
1755
1756

THE COMMENT IS PRINTED

1757
1758
1759
1760
1761
1762
1763
1764
1765
1766
1767
1768
1769
1770
1771
1772
1773
1774
1775
1776
1777APPENDIX C. PERIPHERALS SUPPORTED BY UPDATE PROGRAMS

TRDP SUPPORTS OR WILL SUPPORT THE FOLLOWING DEVICES:

PR:	PC11 HIGH SPEED PAPER TAPE READER	(UPD2TR)
PP:	PC11 HIGH SPEED PAPER TAPE PUNCH	(UPD2TR)
KB:	TTY KEYBOARD, OR LOW SPEED READER	(UPD2TR)
PT:	TTY PRINTER AND PUNCH	(UPD2TR)
DKN:	RK11/RK05 DISK	(UPD2TR, N=0-3)
MTN:	TR79F MAGTAPE 9 TRACK	(UPD2TR, N=0)
CTN:	TA11 CASSETTE	(UPD2TR, N=0 OR 1).

1778
 1779
 1780
 1781
 1782
 1783
 1784
 1785
 1786
 1787
 1788
 1789
 1790
 1791
 1792
 1793
 1794
 1795
 1796
 1797
 1798
 1799
 1800
 1801
 1802
 1803
 1804
 1805
 1806
 1807
 1808
 1809
 1810
 1811

APPENDIX D. PROGRAM NAMING CONVENTIONS

THE FOLLOWING PROGRAM NAMING CONVENTION HAS BEEN USED FOR TRDP. ITS USE WILL PERMIT USERS TO DETERMINE BOTH THE VERSION, AND THE MCN LEVEL OF THE STORED PROGRAMS. CONTINUED USE OF THIS SCHEME WHEN PROGRAMS ARE UPDATED IN THE FIELD IS HIGHLY RECOMMENDED.

```

D      ZFPKA#
↑      ↑↑↑↑↑↑
I      II III
I      II III-----# = INDICATES MCN LEVEL
I      II II-----0 = INDICATES NO MCN ISSUED
I      II II-----A THRU 2 = REVISION DESIGNATION
I      II I-----A THRU 2 = PROGRAM DESIGNATION
I      II 0 THRU 9 = OVERLAY DESIGNATION
I      II-----2 DIGITS = OPTION DESIGNATION
I      I-----A = 11/05, 15, 20 PROCESSORS
I      B = 11/25 PROCESSOR
I      C = 11/45 PROCESSOR
I      Z = ALL PROCESSORS
I-----D INDICATES A DIAGNOSTIC PROGRAM, AND IS NOT USED
I      IN NAMING A PROGRAM.
  
```

.BIN EXTENSION USED TO STORE PROGRAM IN ABS FORMAT.
 .SAV EXTENSION USED TO STORE PROGRAM IN CORE IMAGE FORMAT.
 .BIC EXTENSION INDICATES ABS FORMAT CHAINABLE PROGRAM.

1812
1813
1814
1815
1816
1817
1818
1819
1820
1821
1822
1823
1824
1825
1826
1827
1828
1829
1830
1831
1832
1833
1834
1835
1836
1837
1838
1839
1840
1841
1842
1843
1844
1845
1846
1847
1848
1849
1850
1851
1852
1853
1854
1855
1856
1857
1858
1859
1860
1861
1862
1863
1864
1865
1866
1867

7. HELP ASCII REDRENCE FILE

THIS FILE RESIDENT TO THE DIAGNOSTIC DISTRIBUTION MEDIA IS FOR QUICK COMMAND STRING REFERENCE. THE FILE CAN BE TYPED/PRINTED OUT BY USING STANDARD UPDATE COMMANDS.

DETAILED CMM'D DISCRPTION REFRENCE TRDP USER MANUAL M-11-DMQXA

TRDP RESIDENT MONITOR COMMANDS

F<CR> SET CONSOLE FILL COUNT
D<CR> DIRECTORY ON THE TTY CONSOLE
D/F<CR> SHORT DIRECTORY ON THE TTY CONSOLE
D/L<CR> DIRECTORY ON THE LINE PRINTER
D/L/F<CR> SHORT DIRECTORY ON THE LINE PRINTER
R FILENAME<CR> STARTS THE INDICATED PROGRAM
L FILENAME<CR> LOADS THE INDICATED PROGRAM
S FILENAME<CR> STARTS THE DESIRED PROGRAM THAT WAS LOADED UNDER "L" COMMAND.
S ADDR<CR> STARTS PROGRAM AT SPECIFIED ADDRESS
C FILENAME<CR> RUNS DESIRED CHAIN TABLE
C FILENAME/QV<CR> RUNS DESIRED CHAIN IN QUICK VERIFY

XXDP RESIDENT MONITOR ERRORS

INVCMD/SW INVALID COMMAND AND/OR SWITCH, CHECK COMMAND JUST GIVEN.
DEVERR DEVICE ERROR ON INPUT DEVICE.
EOM END OF MEDIUM, OCCURS DURING INPUT OPERATIONS WHEN THE PROGRAM ATTEMPTS TO INPUT AND THE FILE IS AT AN END. SERIOUS PROBLEM. FILE IN STORAGE IS PROBABLY WIPED OUT.
INVADR INVALID ADDRESS. MUST BE EVEN.
CKSMER CHECKSUM ERROR DURING "LOAD" COMMAND.
POFLO PROGRAM TOO LARGE TO LOAD WITHIN AVAILABLE CORE SPACE.
INVNAM INVALID CHARACTER USED FOR FILE NAME
NEXFIL NON-EXISTENT FILE, FILE DOES NOT EXIST ON MEDIUM

UPD2 PROGRAM COMMANDS

FILL<CR> SETS UP TERMINAL FOR CORRECT PRINT AFTER CRLF.
CLR<CR> CLEARS CORE BELOW UPDATE PROGRAM
XFR<CR> PERMITS MAKING PROGRAM SELF-STARTING, OR NON SELF-STARTING.
DUMP DEV:FILNAM.EXT ADR WRITES MEMORY CONTENTS IN ABS FORMAT
LOAD DEV:FILNAM.EXT LOADS ABS FORMAT PROGRAM (.BIN, .BIC)
PIP DEV1:FILNAM.EXT+DEV2:FILNAM.EXT COPY FILE FROM DEVICE TO DEVICE
SAVE DEV:FILNAM.EXT ADR WRITES MEMORY CONTENTS ONTO CONTIGUOUS BLOCKS
GET DEV:FILNAM.EXT READ CONTIGUOUS BLOCKS INTO MEMORY
MOD ADR MODIFIES CORE CONTENTS

1868	CORE	TYPES PROTECTION LIMITS
1869	LOCORE ADR	ENTERS LOW PROTECTION LIMIT
1870	HICORE ADR	ENTERS HIGH PROTECTION LIMIT
1871	DIR DEV:	TYPES DEV DIRECTORY ON TTY
1872	DIRLP DEV:	TYPES DEV DIRECTORY ON LINE PRINTER.
1873	DEL DEV: FILNAM.EXT	DELETES FILE FROM DEV DIRECTORY
1874	ZERO DEV:	ZERO DEVICE DIRECTORY
1875	BOOT DEV:	LOADS BLOCK 0 OF DEV STARTING AT LOC 000000
1876	SAVM DEV:	WRITES 4K ONTO DEV STARTING AT BLOCK 30
1877	START	STARTS PROGRAM AT ITS TRANSFER ADDRESS
1878	START ADR	STARTS PROGRAM AT ADR
1879	ACT	UPD2 "ACT MODE"
1880	NOTACT	UPD2 OUT OF "ACT MODE"
1881	FILE DEV: <DEV: FILNAM.EXT	COPIES FILE(S) FROM ONE DEVICE TO
1882		ANOTHER, DELETING FILE OF SAME NAME
1883		BEFORE DOING THE TRANSFER
1884	FILEF DEV: <DEV: FILNAM.EXT	SAME AS FILE EXCEPT THAT WITH CASSETTE OR
1885		MAGTAPE FAST TRANSFERS ARE PERFORMED (NO DIR CHECKING)
1886	FILET DEV: FILNAM.EXT	READS FILE AND CHECKS FOR DEVICE
1887		ERRORS (FILE "TEST")
1888	FILEL DEV: FILNAM.EXT	LOADS FILES (ASSUMES ABS FORMAT)
1889		CHECKING FOR DEVICE AND CHECKSUM ERRORS
1890	FILEG DEV: FILNAM.EXT	LOADS FILES (ASSUMES CONTIGUOUS FORMAT)
1891		CHECKING FOR DEVICE AND FILE SIZE ERRORS
1892	FILED DEV: FILNAM.EXT	DELETES NAMED FILES
1893	TEXT DEV: FILNAM.EXT	CREATES TEXT FILE FOR PRINTING
1894		OR FOR COMMAND EXECUTION
1895	PATCH DEV: FILNAM.EXT <CR>	ENABLES THE USER TO PATCH AN ABS FORMAT PROGRAM
1896		ON ANY XDOP RANDOM ACCESS DEVICE.
1897	PRINT DEV: FILNAM.EXT	OUTPUTS A FILE TO THE LINE PRINTER
1898	TYPE DEV: FILNAM.EXT	OUTPUTS A FILE TO THE CONSOLE TERMINAL
1899	DO DEV: FILNAM.EXT	EXECUTES A COMMAND FILE.
1900	ASG PHYSICAL = LOGICAL	ASSIGNS A PHYSICAL DEVICE TO A
1901		LOGICAL DEVICE NAME
1902	EOT	WRITES END OF TAPE MARK (FILE) ON MAGTAPE
1903		OR CASSETTE AFTER TAPE HAS BEEN POSITIONED.
1904	↑C (CONTROL C)	RETURN TO COMMAND MODE (OPEN OUTPUT FILE IS CLOSED).
1905	↑Z (CONTROL Z)	ENDS INPUT TO A TEXT FILE
1906	*	USED FOR FILE NAMING TO MEAN "ANY"
1907		(ANY FILE NAME OR ANY FILE EXTENSION)
1908	?	USED FOR FILE NAMING TO INDICATE A WILD
1909		CHARACTER (ANY CHARACTER WILL MATCH IT)
1910	# OR ;	USED IN A FILE OF EXECUTABLE COMMANDS
1911		TO START A COMMENT LINE WHICH IS TO
1912		BE TYPED DURING EXECUTION
1913	\$	SAME AS # BUT CAUSES A HALT AFTER
1914		THE COMMENT IS PRINTED
1915	/LP	LINE PRINTER OUTPUT
1916	/N	ABORTS TYPE OUTS
1917		
1918	ERRORS	
1919	-----	
1920	INVCMD	INVALID COMMAND
1921	INVDEV	INVALID DEVICE
1922	INVADR	INVALID ADDRESS
1923	INVNAM	INVALID FILE NAME

1924
 1925
 1926
 1927
 1928
 1929
 1930
 1931
 1932
 1933
 1934
 1935
 1936
 1937
 1938
 1939
 1940
 1941
 1942
 1943
 1944
 1945
 1946
 1947
 1948
 1949
 1950
 1951
 1952
 1953
 1954
 1955
 1956
 1957
 1958
 1959
 1960
 1961
 1962
 1963
 1964
 1965
 1966
 1967
 1968
 1969
 1970
 1971
 1972

NEXFIL NON-EXISTENT FILE
 DELOLD DELETE OLD FILE BEFORE GIVING COMMAND
 DEVERR DEVICE ERROR ON EITHER INPUT OR OUTPUT DEVICE
 NOTRDY PAPER TAPE DEVICE IS NOT READY
 CKSMER CHECKSUM ERROR
 EOM END OF MEDIUM
 DEVFUL DEVICE FULL
 INVCOR HIGH CORE LIMIT LOWER THAN LOWER CORE LIMIT
 DIRERR INVALID NAME IN DEVICE DIRECTORY
 DELERR BIT MAP ERROR DURING DELETE OPERATION ON DECTAPE OR DISK
 POFLOW PROGRAM TOO LARGE TO LOAD WITHIN EXISTING CORE SPACE
 INVSX INVALID SWITCH SPECIFIED IN COMMAND STRING
 DUMP ERROR ACT MODE ONLY DATA DUMPED ON OUTPUT DEVICE DOES NOT MATCH

PERIPHERALS SUPPORTED BY UPDATE PROGRAMS

 PR: PC11 HIGH SPEED PAPER TAPE READER (UPD2)
 PP: PC11 HIGH SPEED PAPER TAPE PUNCH (UPD2)
 KB: TTY KEYBOARD, OR LOW SPEED READER (UPD2)
 PT: TTY PRINTER AND PUNCH (UPD2)
 DKN: RK11/RK05 DISK (UPD2, N=0-3)
 MTN: TR79F (UPD2, N=0)

CREATING A NEW XXDP DECPACK

 ZERO DK1:
 LOAD DKO:RKDP.BIN
 SAVM DK1:
 DUMP DK1:RKDP.BIN
 LOAD DKO:UPD1.BIN
 DUMP DK1:UPD1.BIN
 LOAD DKO:UPD2.BIN
 DUMP DK1:UPD2.BIN

CREATING A NEW XXDP MAGTAPE (TR79F)

 ZERO: MTO:
 LOAD DKO:TRDP.BIN
 SAVE MTO:TRDP.SAV
 DUMP MTO:TRDP.BIN
 LOAD DKO:UPDTR.BIN
 DUMP MTO:UPDTR.BIN

↑Z
 %
 .ENABLE ABS
 .END

000001

J04

.MAIN. MACY11 27(732) 01-MAR-77 10:39 PAGE 48
DMQXAB.M11 SYMBOL TABLE

PC =%000007 R1 =%000001 R3 =%000003 R5 =%000005 . = 000000

ERRORS DETECTED: 0
DEFAULT GLOBALS GENERATED: 0

*.DMQXAB.SEQ/SOL=DMQXAB.M11
RUN-TIME: 1 3 0 SECONDS
RUN-TIME RATIO: 108/4=23.6
CORE USED: 5K (9 PAGES)

EOF1DMQXABSEQ 00010000 770325 PDP10 411 7