


ELECTRONIC NAVIGATION INDUSTRIES, INC.

INSTRUCTION MANUAL

MODEL 600L

BROADBAND POWER AMPLIFIER



3000 WINTON ROAD SOUTH, ROCHESTER, NEW YORK 14623
TELEPHONE: AREA CODE 716/473-6900
TELEX #97-8283 ENI ROC

CONTENTS

CHAPTER 1 GENERAL INFORMATION

- 1.1 Introduction 1
- 1.2 Data Summary 1

CHAPTER 2 OPERATION

- 2.1 Introduction 3
- 2.2 Mains Voltage Setting 3
 - 2.2.1 Mains Fuse Rating 3
 - 2.2.2 Mains Lead Connection 3
 - 2.2.3 Operation 4

CHAPTER 3 TECHNICAL DESCRIPTION

- 3.1 General Description 5

CHAPTER 4 MAINTENANCE

- 4.1 Introduction 6
- 4.2 Access and Layout 6
- 4.3 Performance Checks 6
 - 4.3.1 Initial Check 7
- 4.4 Re-alignment Procedure 7
 - 4.4.1 Measurement of Gain 8
 - 4.4.2 Measurement of Harmonics 9
- 4.5 Packaging for Reshipment 10

CHAPTER 5 SCHEMATIC AND PARTS LIST

- 5.1 Schematic Diagram 11
- 5.2 Parts List 11
- 5.3 List of Manufacturers 11
- 5.4 Ordering Replacement Parts 11

CHAPTER 1. GENERAL INFORMATION

1.1 INTRODUCTION

The Model 600L is a general purpose broadband amplifier capable of more than 150 milliwatts of linear power output when driven by any laboratory signal or sweep generator from .8 to 1020 MHz.

An ultra linear Class A design, the 600L will "boost" the output of any signal source by a flat 24 dB (± 1.5 dB) and provide its full forward output power into any load impedance (from an open to a short circuit). Its output is a faithful reproduction of the input waveform for AM, FM, SSB, CATV, pulse and other complex modulations. Although specified only over the .8 to 1020 MHz frequency range, full power output is typically available from .7 to 1050 MHz.

The use of microwave transistors on thin film substrates, microstrip circuitry, and plug-in modules make the 600L both reliable and easy to service. An integral power supply permits operation over a wide range of temperature and AC line conditions.

1.2 DATA SUMMARY

| | |
|--|---|
| Frequency Coverage: | .8 to 1020 MHz |
| Gain: | 24 dB Nominal |
| Gain Variation: | ± 1.5 dB |
| Maximum Linear Power Output: | More than 150 milliwatts |
| Harmonic Distortion: | All harmonics greater than 20 dB below the fundamental at 150 milliwatts output. Lower Distortion at reduced power. |
| Input/Output Impedance: | 50 ohms |
| Input/Output VSWR: | 1.8 Maximum |
| Stability: | Unconditionally stable |
| Typical 3rd Order Intermodulation Intercept Point: | +35 dBm |
| Noise Figure: | 9 dB |
| Power Requirements: | 115/230V a.c. $\pm 12\%$ 50-400 Hz at 12 watts |

| | |
|------------------------|--|
| Size and Weight: | 3.87 x 6.5 x 4.56 inches, 2.5 lbs. 9.8 x 16.5 x 11.8 cm, 1.1 kg. |
| Operating Temperature: | 0° to 45° C |
| Protection: | Unit will withstand a +20 dB overdrive (1 volt RMS) for all output load conditions, including short and open circuits. |
| Output Connectors: | BNC standard, SMA and type N optional |

CHAPTER 2. OPERATION

2.1 INTRODUCTION

The ENI 600L RF amplifier is used to increase the r.f. output level of signal sources in the .8 to 1020 MHz range. No tuning or any other form of adjustment is required other than the selection of the correct power supply input voltage.

The 600L produces rated power output at its output connector, regardless of load impedance. Any power reflected due to output load mismatch is absorbed in the amplifier. Therefore, although the output impedance is 50 ohms (typical VSWR: 1.5:1), the amplifier will work into any load impedance.

2.2 Mains Voltage Setting

The supply voltage selection switch is located at the rear of the instrument and is normally set for 115 V a.c. operation.

CAUTION

Before connecting the unit to the mains supply, check that the supply voltage selection switch is correctly set. Extensive damage will result if the Amplifier is connected to the wrong supply voltage. Under no circumstances should this switch be operated while the supply is connected.

2.2.1 Mains Fuse Rating

The mains fuse F1 is located on the rear panel. The replacement part number details are:

.5 amp Slow Blow ENI Part No. 313.500

The .5 amp rating is correct for both 115 and 230 volts a.c.

2.2.2 Mains Lead Connection

For 230 V a.c. operation, a suitable mains supply plug must be fitted to the mains lead attached to the instrument. The three conductors are color coded as follows:

BLACK - Live
WHITE - Neutral
GREEN - Earth

2.2.3 OPERATION

Determine and adjust the voltage setting and fuse rating as described in the previous sections 2.2 and 2.2.1 then proceed as follows:

- (i) Ensure input voltage is not excessive.

The 1 V rms indicated maximum input voltage is 5 times the level of the input signal required to achieve maximum output. Input voltages in excess of 2 volts peak may permanently damage the instrument.

- (ii) Connect the input signal via a 50 ohm coaxial lead and BNC plug to the input connector.
- (iii) Connect the output via a 50 ohm coaxial lead and BNC plug to the load.

CHAPTER 3. TECHNICAL DESCRIPTION

3.1 GENERAL DESCRIPTION

The ENI 600L is designed to amplify signals by 24 dB in the frequency band of .8 to 1020 MHz. The signal from the front panel BNC connector is fed via a length of 50 ohm coaxial cable to the input of the amplifier module (600L - 2822). The signal from the input of the amplifier module is fed via a length of microstrip transmission line to a π network attenuator R1, R2, and R3 (see figure 5.1). The output from the attenuator is fed to the input of low noise transistor amplifier stage Q1. The output of Q1 is amplified and gain leveled by stage Q2. The output of Q2 is then impedance matched by L6 and C11 and fed to the base of output transistor Q3. The low distortion output of Q3 is also impedance matched and fed via 50 ohm coaxial cable to provide the specified 50 ohms to the output BNC connector.

The amplifier power requirements are 115 V or 230 V a.c. at 12 watts. The power unit provides a regulated 15 V d.c. 300 mA source. The 15 V d.c. source is regulated by series pass transistor Q1 and integrated circuit regulator IC1. R2 adjusts the supply to 15 volts. The light located in the front panel is of the L.E.D. type and will indicate when the power supply is operating correctly.

CHAPTER 4. MAINTENANCE

4.1 INTRODUCTION

The ENI 600L RF amplifier requires no periodic maintenance. The instrument is unconditionally stable and is failsafe under all load conditions. Damage can only be externally caused by the incorrect selection of the supply voltage or by an input signal in excess of the specified 1 volt rms maximum.

This chapter therefore, deals only with certain fundamental procedures for fault location and with the subsequent re-alignment procedures.

Performance limits quoted are for guidance only and should not be taken for guaranteed performance specifications unless they are also quoted in the Data Summary Section 1.2.

4.2 ACCESS AND LAYOUT

The ENI 600L is housed in an aluminum chassis. The cover can be removed by releasing the four #4-40 screws on the side of the unit and lifting the cover.

The lamp indicator on the front panel is of the L.E.D. type. This lamp may be replaced by applying pressure with the thumb to its lens until it is released from its plastic bezel.

The rear panel supports the mains fuseholder and the mains input selector switch (S2).

The amplifier module is mounted to the base and rear of the one piece chassis. Before removal of this module it is necessary to first remove its top cover, the coaxial cables connected to it and the appropriate lead from the terminal located on the power supply regulator module (600L - 4822).

4.3 PERFORMANCE CHECKS

To determine the amplifier's performance carry out the following procedure.

4.3.1 Initial Check

The following check can be made after repair and adjustments or whenever the condition of the unit is in question.

- (i) Connect power supply. Switch on power and observe that the supply lamp (DS1) illuminates.

- (ii) Connect a sweep generator (Hewlett Packard 8620C or similar) capable of sweeping the frequency range 10 to 1020 MHz to the input connector.
- (iii) Adjust the output level of the sweep generator so that a 50 ohm video detector connected at the output of the unit will not be damaged by excessive power output.
- (iv) Observe the gain versus frequency ripple on an oscilloscope calibrated in decibels. The gain variation must be not more than ± 1.5 dB over the frequency range.
- (v) Connect a calorimetric power meter (HP434 or equivalent) through a short length of 50 ohm cable to the output connector. Adjust the input CW signal to any frequency between .8 and 1020 MHz for 150 milliwatts output.
- (vi) Observe the harmonic distortion of the output on a spectrum analyzer. The harmonic components contributed by the amplifier should be at least 20 dB down from the fundamental.

If the requirements of this check are not met, verify that:

- (a) The mains supply switch and fuse are correctly selected and that DS1 is illuminated.
- (b) The power amplifier supply voltage is set at 15 volts by R2.

If the above checks are found to be correct, then normal fault location procedures, with reference to the circuit diagram Figure 5.1 should be followed to determine the correct operation of the amplifier module.

4.4 RE-ALIGNMENT PROCEDURE

Before any adjustment is made to the unit, first

- (i) Ensure that the mains switch and fuse are correctly selected and that DS1 is illuminated.
- (ii) Measure the power supply voltage and adjust per section 4.3.1(b).

4.4.1 Measurement of Gain

Equipment required:

- (a) HP8620C - Sweep Oscillator
- (b) HP86222A - RF Plug-in
- (c) Oscilloscope - Telequipment Model S54A
- (d) 50 ohm Detector - Wavetek D151
- (e) Attenuator, 10 dB, 20 watts - Narda 766-10
- (f) HP8601A Sweep Signal Generator




Fig. 4.1 Gain Measurement

Connect the equipment as shown in Figure 4.1, then proceed as follows:

- (a) Set the oscilloscope to DC, time/CM to Ext. X, and vertical gain to 10MV/CM.
- (b) Set the sweep/generator to the sweep mode with the start frequency at 10 MHz and the sweep width to 1020 MHz.
- (c) Disconnect the ENI 600L from the set-up and connect the sweep/generator RF output directly to the 10 dB attenuator.
- (d) Adjust the output level of the sweep/generator for full vertical deflection on the oscilloscope face.

- (e) Calibrate the scope face to show 3 dB in 1 dB steps by attenuating the sweep/generator in 1 dB steps and marking the traces with a grease pencil.
- (f) Return sweep/generator output level to full deflection. Rotate the step attenuator on the sweep/generator (CCW) so that the output is reduced by 24 dB.
- (g) Reconnect the 600L into the test set-up of Figure 4.1.
- (h) Flip the 600L power switch to the "on" position.
- (i) Observe the gain versus frequency sweep on the oscilloscope.
 - 1. The average gain should be 24 dB (within 1 dB).
 - 2. The gain variation should be within the 3 dB markings as shown on the oscilloscope.
- (j) Repeat steps (a) through (i) using the HP8601A Sweep Generator with start frequency at 800 KHz and the stop at 10 MHz.

4.4.2 Measurement of Harmonics

Equipment required:

- (a) HP8620C - Sweep Oscillator
- (b) HP86222A - RF Plug-in
- (c) Calorimetric Power Meter - HP434A
- (d) Spectrum Analyzer - HP140T Display Unit
 - HP8555A Spectrum Analyzer
 - RF Section
 - HP8552A Spectrum Analyzer
 - IF Section

TABLE 5.1. REPLACEMENT PARTS LIST.

| REF. DESIGN. | DESCRIPTION | MFR. CODE | PART NO. |
|--------------|-----------------------------------|-----------|-------------------|
| | Power Distribution Assembly | | |
| DS1 | LED, Lamp | 10226 | 5082-4430 |
| T1 | Transformer, Power | 12715 | AM6400A |
| Q1 | Transistor | 79089 | 40312 |
| CR1 | Bridge Rectifier | 83003 | VS148 |
| C1 | Cap., Elect., 500 UF 50 VDCW | 09023 | WBR500-50 |
| S1 | Switch, Toggle | | ST1-1 |
| S2 | Switch, Slide DPDT | 22753 | 622-HK-115/230 |
| F1 | Fuse Type 3AG, .5ASB | 75915 | 313.500 |
| FX | Fuseholder | 75915 | 342001 |
| A111 | Power Supply Regulator Board | 10226 | 600L-4822 |
| A111C1 | I.C. Regulator | 49956 | RC723CT |
| A111C2 | Cap., Mica, 560 PF 5% | 09023 | CM05ED561J03 |
| A111R1 | Resistor, Film, 2.7K ohm 5% 1/2W | 16299 | HC-5-2.7K |
| A111R2 | Pot, 1K ohm, 5% | 32997 | 3389T-1-102 |
| A111R3 | Resistor, Film, 2.7K ohm 5% 1/2W | 16299 | HC-5-2.7K |
| A111R4 | Resistor, Comp., 1.2K ohm 5% 1/2W | 01121 | RC20GF122J |
| | RF Assembly | | 600L-2822 |
| Q1-3 | Transistor | 10226 | ENI-6 |
| C1 | Cap., Cer., 1PF, Chip | 31433 | C080C109D5GAH |
| C5 | Cap., Feed Through, 1000 PF | 72982 | 357-000X-540-102M |
| C6 | Cap., Elect., 20 UF, 50VDCW | 56289 | TE1305 |
| C15 | Cap., Mica, 3 PF, 5% | 09023 | DM5CC030A |
| A-110 | Power Amplifier Board | 10226 | 600L-4821 |
| A-110R1 | Resistor, Comp., 27 ohm 5% 1/8W | 01121 | RC05GF270J |
| A-110R2,3 | Resistor, Comp. 240 ohm 5% 1/8W | 01121 | RC05GF241J |
| A-110R4 | Resistor, Comp. 300 ohm 5% 1/8W | 01121 | RC05GF301J |
| A-110R5 | Resistor, Comp., 240 ohm 5% 1/4W | 01121 | RC07GF241J |
| A-110R6 | Variable | 01121 | |
| A-110R7,8 | Resistor, Comp., 18 ohm 5% 1/8W | 01121 | RC05GF180J |
| A-110R9 | Resistor, Comp., 300 ohm 5% 1/8W | 01121 | RC05GF301J |
| A-110R10 | Resistor, Comp., 200 ohm 5% 1/4W | 01121 | RC07GF201J |
| A-110R11 | Resistor, Comp., 12 ohm 5% 1/4W | 01121 | RC07GF120J |
| A-110R12 | Variable | 01121 | |
| A-110R13,14 | Resistor, Comp., 18 ohm 5% 1/8W | 01121 | RC05GF180J |
| A-110R15 | Resistor, Comp., 300 ohm 5% 1/8W | 01121 | RC05GF301J |
| A-110R16 | Resistor, Comp., 270 ohm 5% 1/4W | 01121 | RC07GF271J |
| A-110R17 | Variable | 01121 | |
| A-110R18,19 | Resistor, Comp., 27 ohm 5% 1/8W | 01121 | RC05GF270J |