THE CONTROL OF THE PROPERTY OF

"TRADER" SERVICE SHEET

жилилия с на авторита на базанительной при может на авторительного при выправания при при выправания при выправания при выправания выпра

ISSUE REVISED OF

SERVICE SHEET No. 392

FEATURE of the Ekco AW119 is the inclusion of 7-metre channel for the reception of the television sound programme. The remaining three bands include a short-wave range of 16-51m, and provision is made for use with a dipole aerial.

ALTERNATION OF THE MANAGEMENT OF THE PROPERTY OF THE PROPERTY

The receiver is a 4-valve (plus rectifier) superhet, designed to operate from A.C. mains of 200-250V, 40-80 c/s. There is provision for the connection of a gramophone pick-up and an external speaker. A negative feed-back circuit reduces harmonic output, and a special filter circuit rejects heterodyne whistles.

Release date and original price: June, 1938. £11 11s.

CIRCUIT DESCRIPTION

Aerial input on M.W. via coupling capacitor C2, and on L.W. via coupling coil L2, to mixed coupled band-pass filter.

EKCO AW119

A.C. SUPERHET

Primary Coils L3, L4 are tuned by C37; secondary coils L9, L10 by C43. On L.W. aerial circuit is shunted by I.F. filter L1, C3. Image suppression by C42.

On television sound, referred to as "T.S.," and S.W. bands, input is via coupling coil L5 (T.S.) or L6 (S.W.) to single-tuned circuits L7, C43 (T.S.) or L8, C43 (S.W.). The two dipole connections are aerial socket "A" and the unmarked socket immediately beneath it. Socket "E" should be connected to earth.


First valve (V1, Mullard metallised TH4A or TH4B), is a triode hexode operating as frequency changer with internal coupling. Triode oscillator grid coils L11 (T.S. and S.W.), L12 (M.W.) and L13 (L.W.) are tuned by C45; parallel trimming by C46 (S.W.), C47 (M.W.) and C10 C48 (M.W.) species tracking by C46 C10, C48 (L.W.); series tracking by C8 (M.W.), C9 (L.W.), and adjustable irondust cores in both cases. A harmonic of the S.W. oscillator is used for T.S.

Reaction coupling by coils L14 (T.S. and S.W.), L15 (M.W.) and L16 (L.W.), which are connected in series, switches \$17 (S.W.) and \$18 (M.W.) short-circuiting those coils which are not required.


Second valve (V2, Ekco metallised VP41 or Mullard VP4B) is a variable-mu R.F. pentode operating as intermediate frequency amplifier with tuned-primary, tuned-secondary transformer couplings C49, L17, L18, C50 and C51, L19, L20,

Intermediate frequency 126.5 kc/s.


Diode second detector is part of double diode triode valve (V3, Ekco metallised DT41 or Mullard TDD4). Audio frequency component in rectified output is developed across load resistors R10, R11, and that across R11 is passed via A.F. coupling capacitor C16 and manual volume control R13 to C.G. of triode section, which operates as A.F. amplifier. A fixed resistor R12, connected between C16 and the top of R13, limits the range of the volume control to a predetermined maximum. High-note compensation by C17 between top of R12 and triode C.G. Variable tone control by C18 and R15 between triode C.G. and chassis. Provision for connection of gramophone pick-up be-tween junction of R10, R11 and chassis. I.F. filtering by C20 and C21.



Under-chassis view. The output transformer TI is almost hidden by components mounted upon it. The waveband switch units (marked I and 2 in circles) are indicated here and shown in detail in the diagrams in col. 4 overleaf. The components on each side of the small panel near the centre are listed in order from top to bottom, as seen here where the chassis is inverted.



Second diode of V3, fed from V2 anode via C15, provides D.C. potentials which are developed across load resistors R19, R20 and fed back through decoupling cir-



cuits as G.B. to F.C. and I.F. valves, giving automatic volume control. R19, R20 are connected in series between the diode anode and cathode, so that while no delay voltage is applied to the diode the voltage existing on **V3** cathode is applied as a fixed positive bias to the controlled valves, in the opposite sense to their own fixed G.B. voltages, and so opposes both the normal G.B. and A.V.C. voltages.

Resistance-capacitance coupling by R18 in anode circuit and, in series from V3 anode to chassis, C24, R21, R22 and R23, between V3 triode and pentode output valve (V4, Ekco OP42 or Mullard PenA4). On television sound channel, R23 is short-circuited by \$20

is short-circuited by \$20.

The output transformer T1 is provided with two secondary windings, one for the speech coil, and the other to provide negative feed-back voltages. The speech coil secondary is tapped for a low impedance external speaker, while switch self permits the internal speaker to be muted. A whistle filter of special design, comprising coils L21, L22, L23 and capacitors C27, C28, is included in the leads to the speech coil.

R25 and R26 are connected in series to form a potential divider across the feedback secondary winding. Across R26 are connected a switch \$19 and a filter circuit R14, C19, and the voltage developed across R26 is fed back via R13, which is returned to the junction of R25 and R26, to V3 triode control grid. S19 closes on the

V3 triode control grid. S19 closes on the S.W. band, muting the feed-back. H.T. current is supplied by I.H.C. full-wave rectifying valve (V5, Cossor 431U or Mullard 1W4/350). Smoothing by iron-cored choke L27 and speaker field L26 in association with dry electrolytic capacitors C29, C30, C31 and C32. C29 is connected in parallel with 102 to form connected in parallel with L26 to form

a tuned filter circuit.

782 EKCO

Supplement to The Wireless & Electrical Trader, August 10, 1946

COMPONENTS AND VALUES

	CAPACITORS	Values (µF)
C1	L.W. Aerial shunt	0.00015
ĈŹ	Aerial M.W. coupling	0.001
č š	I.F. filter tuning	0.00015
Č	I.F. filter tuning V1 hex. C.G. decoupling	0.04
èš –	V1 S.G. decoupling	0.1
ČĞ	V1 cathode by-pass	0.1
Č7	V1 ose C C capacitor	0.00005
čs –	V1 osc. C.G. capacitor Osc. eirc. M.W. tracker Osc. eirc. L.W. tracker	0.002
	Ose eire I W tracker	0.0008
(19	Osc. L.W. fixed trimmer	0.00002
C10		0.00002
CH	VI osc. anode decoupling {	2.0
C12*		0.04
C13	V2 C.G. decoupling	0.1
C14	V2 cathode by-pass	
C1a	V3 A.V.C. diode coupling	0.000015
C16	Coupling to V3 triode	0.01
C17	High-note compensator	0.00006
C18	Part variable tone control	0.004
C19	Part feed-back coupling	0.05
C20	The by man agracitors	0.0002
C21	I.F. by-pass capacitors	0.0002
('22*	V3 anode decoupling	2.0
C23*	V3 cathode by-pass	50.0
C24	A.F. coupling to V4	0.01
C25	Fixed tone corrector	0.0025
C26*	V4 cathode by-pass	50.0
C27	` '	0.5
C28	Parts of whistle filter {	0.5
C29*	7	2.0
C30*	H.T. smoothing capaci-	8.0
C31*	tors	12.0
C32*		2.0
C33	H.T. circuit R.F. by-pass	$\bar{0}\cdot\check{1}$
C34	Maine R W hy-nass	Ŏ:Ô1
	Mains R.F. by-pass V1 A.V.C. line decoupling	0.003
C35	R D pri I W trimmer	0 000
C36‡	BP. pri. L.W. trimmer Band-pass pri. tuning	
C37†	D D vsi M W trimmer	
C38‡	BP. pri, M.W. trimmer	
C39‡	Aerial S.W. trimmer	
C40‡	BP. sec. M.W. trimmer	
C41‡	BP. sec. L.W. trimmer	
C42‡	Image suppressor	
C43†	Band-pass sec. tuning	
C44‡	Aerial T.S. trimmer	_
C45†	Oscillator circuit tuning	
C461	Osc. circ. S.W. trimmer Osc. circ. M.W. trimmer	l —
	Osc. circ. M.W. trimmer	
C471	Osc. circ. L.W. trimmer	—
C47‡ C481		
C48‡	1st I.F. trans. pri. tuning	
C481 C491	1st 1.F. trans. pri. tuning	
C481 C491 C501	1st I.F. trans. pri. tuning 1st I.F. trans. sec. tuning	
C48‡ C49‡	1st 1.F. trans. pri. tuning	

† Variable.


· Electrolytic.

‡ Pre-set.

-	RESISTORS	Values (ohms)
R1	V1 hex, C.G. decoupling	250,000
R2	V1 S.G. potential divider	*12,500
R3	()	25,00 0
R4	V1 fixed G.B. resistor	250
R_5	V1 osc. C.G. resistor	25,000
R6	V1 osc. anode stabiliser	200
R7	V1 osc. anode H.T. feed	†20,000
R8	V2 C.G. decoupling	1,000,000
R9	V2 fixed G.B. resistor	300
R10	\ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \	500,000
R11	\ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \	100,000
R12	A.F. output limiter	500,000
R13 R14	Manual volume control Part feed-back coupling	1,000,000
R15	Manda M. L. Annua annual and	1,000 1,500,000
R16	To tall to O.D. 11	2,000
R17	V3 triode G.B. resistor V3 ano de decoupling	15,000
R18	V3 triode anode load	50,000
R19	1)	500,000
R20	A.V.C. diode load resistors {	500,000
R21	11 3	75,000
R22	V4 C.G. feed potential di-	250,000
R23	vider resistors	250,000
R24	V4 G.B. resistor	120
R25) (20,000
R26	Part feed-back coupling	1,000

* Two 25,000 Ω in parallel in our chassis. † Two 40,000 Ω in parallel in our chassis.

OTHER COMPONENTS	Approx. Values (ohms)
L1	40·0 40·0 2·5 30·0 Very low 0·05 2·5 27·0 0·05 3·0 9·0 0·4 0·6 2·0 80·0 80·0 80·0



Plan view of the chassis. Most of the trimmers are grouped on the left.

R13 and R15 are operated by concentric spindles from the drum and lever on the right. Tuning and waveband switching are controlled by the drum and lever on the left.

	OTHER COMPONENTS (Continued)	Approx Values (ohms)
L21 L22	Parts of whistle filter	2·5 5·0
L23	[Tares of winsole inter]	2.5
L24	Speaker speech coil	24.0
L25	Hum neutralising coil	0.7
L26	Speaker field coil	1.250.0
L27	H.T. smoothing choke	350.0
	(Pri,	350.0
T1	Output trans. Speech sec.	4.0
i	FB. sec.	40.0
	Pri., total	35.0
T2	Mains Heater sec	0.05
	trans. Rect. heat, sec.	0.1
01.000	H.T. sec., total	550.0
81-820	Waveband switches	
S21	Int. speaker switch	-
S22 :	Mains switch, ganged R13	. —

VALVE ANALYSIS

Valve voltages and currents given in the table below are those measured in our receiver when it was operating on mains of 225 V, using the 220-230 V tapping on the mains transformer. The receiver was tuned to the lowest wavelength on the medium band and the volume control was at maximum, but there was no signal input.

Voltages were measured on the 400 V scale of a model 7 Universal Avometer, chassis being negative.

If, as in our case, V2 should become unstable when measurements are being made of its anode current, it can be stabilised by connecting a non-inductive capacitor of about $0.1~\mu F$ from grid (top cap) to chassis.

Valve	Anode Voltage (V)	Anode Current (mA)		Screen Current (mA)
V1 <u>5</u> TH4A	$\left\{\begin{array}{c}240\\\text{Oscil}\\82\end{array}\right.$	$\left\{egin{array}{c} 3\cdot 4 \ \mathrm{lator} \ 7\cdot 0 \end{array} ight\}$	84	7.5
V2 VP41	240	11.5	240	5.0
V3 DT41 V4 OP42	110 225	1·7 40·0	240	5.0
V5 43IU	377†			

† Each anode A.C.

DISMANTLING THE SET

Removing Chassis.—Remove one roundhead wood screw from each side of the front of the chassis, and the two 4BA screws holding the scale assembly brackets to the top of the cabinet;

from beneath the rear of the chassis remove the two 4BA screws which hold it to the cross-bar, and remove the bar;

then, supporting the chassis with one hand, remove one round-head wood screw from each end of the rear member of the chassis with the other, when the chassis may be withdrawn to the extent of the speaker leads.

To free the chassis entirely, unsolder the four speaker leads.


When replacing, connect the speaker leads as follows, numbering the tags from left to right: 1, red; 2, yellow; 3, brown; 4, red.

Removing Speaker.—Slacken the four clamps holding the speaker to the subbaffle.

When replacing, see that the connecting strip is at the top and connect the leads as described previously.

Switch Diagrams and Table

Diagrams of the wave-band switch units, as seen when viewed from the rear of an inverted chassis. "B" indicates a blank tag. Below is the associated switch table.



Switch	L.W.	M.W.	s.w.	T.S.
SI			_	С
82			C	
83		С	-	
84	C			
85				С
86			C	C
87		C .	С	
88		C	C C —	
89	С			<u> </u>
810	· <u> </u>	_ i		C
sii			C	_
812		c	_	
813	C			
\$14	_		С	С
\$15		c		
S16	C	:		
_ S17	_		c	C
S18	0 0	C		
S19			C	
\$20		! <u> </u>		C

GENERAL NOTES

switches.—\$1-\$20 are the waveband switches, in two rotary units beneath the chassis. They are indicated in our underchassis view, and shown in detail in the diagrams above. The table (above) shows the switch positions for the four control settings, starting from the fully anti-clockwise position of the switch spindle. A dash indicates open, and C, closed.

821 is the internal speaker switch, which is mounted at the rear of the chassis near the external speaker sockets, and controlled by a small milled knob. When this is unscrewed, the internal speaker is muted.

**s22 is the Q.M.B. mains switch, ganged with the volume control R13.

Coils.—L1 is mounted beneath the chassis, and has an adjustable iron-dust core, reached through a hole in the chassis deck. L2, L3, L4, L9, L10 and L11-L16 are in two screened units on the chassis deck. The first of these units contains four trimmers reached through holes in the top of the can. The second contains two trimmers (reached again through holes in the top of the can) and the three fixed capacitors C8-C10, while the cores of L12 and L13 are adjustable through holes in one side of the can. L5, L7 and L6, L8 are on small tubular formers, sup-

ported directly on their switch units beneath the chassis.

L17, L18 and L19, L20 are the I.F. transformers in two further screened units on the chassis deck. They contain their associated trimmers, while the second also includes R10, C15 and C20.

The filter coils **L21-L23** are on a single former beneath the chassis, and are unscreened.

Scale Lamps.—These are three Rival M.E.S. types, rated at 6.2 V, 0.3 A.

External Speaker.—Two sockets are provided at the rear of the chassis for a low impedance (4Ω) external speaker. The internal speaker can be muted by unscrewing **\$21**.

Capacitors C12, C22, C30, C31.—These are four dry electrolytics in a single large carton beneath the chassis, with a common negative (black) lead. The green lead is the positive of C12 $(2\mu F)$, the yellow lead is the positive of C22 $(2\mu F)$, the blue lead is the positive of C30 $(8\mu F)$, and the red lead is the positive of C31 $(12\mu F)$.

Capacitors C29, C32.—These are two further 2μ F dry electrolytics in a separate smaller carton bound up with the larger one. The black lead is the negative of C32, the green is the positive of C32 and the negative of C29, while the red is the positive of C29. Note that as far as polarity is concerned, C29 and C32 are connected in series.

Capacitors C5, C6.—These are two $0.1\mu F$ paper capacitors in a metal-cased unit at the inside of the rear of the chassis. The tag nearest the chassis deck is common to both sections. The other connection of each goes to one of the two tags shown numbered in the under-chassis view.

Capacitors C10, C36.—These are small capacitors formed of wires spiralled over insulated wires. C10 is inside the oscillator coil unit, while C36 is beneath the chassis near the switch units. The latter is adjustable by sliding the spiralled winding over the straight wire, or by attering the length of the spiralled winding.

Chassis Divergencies.—R2 in our chassis was composed of two $25,000\Omega$ resistors connected in parallel. In other chassis it may be one $12,500\Omega$ resistor. The same applies to R7, which may be one $20,000\Omega$ resistor instead of two $40,000\Omega$ types in parallel.

C34, the mains R.F. by-pass, and C35, V1 A.V.C. line decoupling, are not shown in the makers' diagram.

CIRCUIT ALIGNMENT


1.F. Stages—Connect signal generator to E socket, and via a 0.02μ F capacitor to control grid (top cap) of V1, leaving existing clip in position. Switch set to L.W., turn gang to maximum, feed in a 126.5 kc/s (2,372 m) signal, and adjust C49, C50, C51 and C52 for maximum output.

R.F. and Oscillator Stages.—See that cursor line covers the 550 m mark when gang is at maximum. Volume control should be at maximum during alignment. Transfer signal generator to A and E sockets.

S.W.—Switch set to S.W., tune to 18 Mc/s on scale, and feed in an 18 Mc/s (16.67 m) signal. Fully unscrew **C46**, then screw it in slowly. Two peaks will be obtained, of which the first reached is correct. Adjust to this accurately.

correct. Adjust to this accurately.

Feed in a 20.75 Mc/s (14.45 m) signal (its second harmonic being 41.5 Mc/s), at full generator output. Then switch to T.S. (television sound) and adjust C44 for maximum output. Switch to S.W., feed in a 15 Mc/s (20 m) signal, tune to 15 Mc/s on scale and adjust C39 for maximum output.



The Ekco AW119 superhet.

M.W.—Switch set to M.W., tune to 200 m on scale, and feed in a 200 m (1,500 kc/s) signal. Fully unscrew C47 and then screw it in slowly, adjusting accurately to the first peak reached. Tune to 250 m on scale, feed in a 250 m (1,200 kc/s) signal and adjust C40 and C38 for maximum output. Tune to 500 m on scale, feed in a 500 m (600 kc/s) signal, and adjust iron core of L12 for maximum output, while rocking the gang for optimum results. Repeat the adjustments at 200, 250 and 500 m.

L.W.—Switch set to L.W., tune to 1,100 m on scale, feed in a 1,100 m (272.5 kc/s) signal and adjust C48, C41 and C36 for maximum output. C36 is adjusted by sliding the spiralled wire on the insulating sleeve over the straight wire.

Tune to 1,700 m on scale, feed in a

1,700 m on scale, feed in a 1,700 m (176.5 kc/s) signal, and adjust core of **L13** for maximum output, while rocking the gang for optimum results.

I.F. Filter.—Leaving set switched to L.W. and tuned to 1,700 m, feed in a 126.5 kc/s signal at full generator output, and adjust core of L1 for minimum output. Reduce generator output, and adjust to 1,100 m (272.5 kc/s). Tune to 1,100 m on scale, and repeat L.W. alignment as above.

Image Suppressor.—Switch set to M.W., feed in a 300 m (1,000 kc/s) signal at full generator output. Tune receiver to image of generator frequency (about 400 m) and adjust C42 for minimum output.

Tune to 250 m, feed in a 250 m (1,200 kc/s) signal, and re-adjust **C40** for maximum output.