

ELECRAFT KAT1 AUTOMATIC ANTENNA TUNER

Assembly and Operating Instructions

E740024 Revision D, March 22, 2017. Copyright © 2017, Elecraft; All Rights Reserved

Introduction

The KAT1 internal automatic antenna tuner (ATU) allows nearly any random-length wire antenna to be connected directly to the Elecraft K1 transceiver and used on one or more bands. The L-network configuration can be used with coax-fed or end-fed wire antennas, or with balanced feedlines via a balun. Unlike some internal auto-tuners, the KAT1 functions on receive as well as transmit. This provides an increase in receive sensitivity and improves rejection of out-of-band signals.

The KAT1 uses latching relays to reduce current drain to nearly zero except when actually tuning. These relays select appropriate combinations of inductance and capacitance, as well as either a capacitor-in or capacitor-out L-network configuration. Tune-up is controlled by the KAT1's microprocessor, which also supplies SWR or power information to be displayed on the K1's LCD. Once a match has been found, matching parameters are saved so that the settings can be recalled immediately on any band change.

ATU parameters (L, C, SWR, etc.) can be viewed using the K1's menu. Additional menu entries are provided to do component-level troubleshooting all relays, inductors, and capacitors.

In addition to being one of the world's smallest automatic antenna tuners, the KAT1 is very easy to build and install. The KAT1 module plugs directly into the K1's Filter board with no additional wiring. Gold plated connectors and redundant connector pins are used to provide excellent reliability for field operation.

Specifications

L - C Ranges	L: approx. 0-5 μ H in 16 steps; C: approx. 0-300 pF in 32 steps
Network Type	L-network (series L, shunt C); C switchable to transceiver or antenna side
Tuning time	1 to 8 seconds typical for initial tune-up; < 1/2 sec. to recall per-band settings
SWR Display	1.0:1 to 9.9:1
Current Drain	Approx. 10-30 mA during TUNE; < 5 mA at all other times
Size	5.0" (L) x 1.8" (D) x 0.5" (H) (12.7 x 4.6 x 1.3 cm)



Caution: Some components in this kit can be damaged by static discharge. Before handling any transistors or integrated circuits, always put on an anti-static wrist strap or touch any grounded, unpainted metal surface.

Parts Inventory

The table below lists all parts in the kit. The K1 Owner's manual has photographs of similar parts.

Ref.	Description	Part No.	Qty
C1	Capacitor, 10 pF, 500 V NPO disc	E530026	1
C2	Capacitor, 22 pF, 500 V NPO disc	E530027	1
C3	Capacitor, 39 pF, 500 V NPO disc	E530028	1
C4	Capacitor, 82 pF, 500 V NPO disc	E530029	1
C5	Capacitor, 150 pF, 500 V NPO disc ("151")	E530030	1
C11, C12, C17	Capacitor, .001 μ F, 25 V ("102")	E530001	3
C13, C14, C16, RF-C76	Capacitor, .01 μ F, 25 V ("103")	E530009	4
C15	Capacitor, .047 μ F, 25 V ("473")	E530025	1
C10	Capacitor, 100 pF, 200 V, NPO disc ("101")	E530034	1
C9	Ceramic trimmer, 5-30 pF	E540001	1
D1, D2	Diode, 1N5711	E560004	2
D3	Diode, 1N34A	E560000	1
FIL-J1	Conn., 3-pin female, 0.1" spcg., Samtec SSW-103-01-G-S	E620009	2
FIL-J2	Conn., 5x2 female, 0.1" spcg., Samtec SSW-105-01-G-D	E620045	2
K1-K10	DPDT latching relay	E640001	10
L1-L4	Toroidal inductor, T37-2 core (RED); see text	E680006	4
P1	Conn., 3-pin male, .1" spcg., Samtec MTSW-103-22-G-S-420	E620046	1
P2	Conn., 5x2 male, .1" spcg., Samtec MTSW-105-22-G-D-420	E620047	1
R1, R2	Trimmer potentiometer, 100K	E520001	2
R5	Resistor, 100 ohms, 5%, 1/4-watt (brown-black-brown)	E500010	1
R3	Resistor, 200 ohms, 5%, 1/4-watt (red-black-brown)	E500020	1
R6	Resistor, 1 k, 5%, 1/4-watt (brown-black-red)	E500013	1
RF-R39	Resistor, 1.8 k, 5%, 1/4-watt (brown-gray-red)	E500004	1
R4	Resistor, 3.3 k, 5%, 1/4-watt (orange-orange-red)	E500017	1
RF-R4	Resistor, 5.6 k, 5%, 1/4-watt (green-blue-red)	E500007	1
RFC1	RF choke, 82 μ H, miniature (gray-red-black)	E690003	1
T1	Toroidal transformer, FT37-43 core (gray); see text	E680003	1
U1	IC, Microcontroller, 16C72A, 16F872A or 16C72A	E610007	1
U2	IC, Op-amp, LM358	E600010	1
Z1	Ceramic resonator w/internal capacitors, 4.0 MHz	E660001	1
HDWR	Socket for U1, 28 pins	E620011	1
HDWR	#4 split lock washer (2 spares)	E700004	4
HDWR	4-40 x 1" ZN ST Phillips machine screw (2 spares)	E700047	4
HDWR	Standoff, 3/16" dia. x 5/8", #4 hex, RAF #1323-4-A	E700048	2
MISC	Enamel wire, #26 Thermaleze, GREEN	E760004	2 ft.
MISC	Enamel wire, #26 Thermaleze, RED	E760002	5 ft.
MISC	Hookup wire, #24 insulated	E760005	3"
MISC	KAT1 PC board	E100112	1

K1 Firmware Requirements

To use the KAT1 antenna tuner, you'll need K1 main processor firmware revision **109** or later. (The main processor is U1 on the Front Panel board.) To check the firmware revision, hold any switch when powering up the K1. When you release the switch, the firmware revision will be shown on the LCD.

KAT1 PC Board Assembly



A fine-point, temperature-controlled soldering iron (700-800 degrees F) is required to assemble this kit. A high-wattage iron or one with a wide tip may damage components, pads, or traces. Use a minimum amount of solder to avoid ground shorts.



Install components only in the order described below. Double-check all values before soldering, since removing parts from double-sided PC boards can be difficult.

Place relays at locations K1-K5, with the white-striped end of each relay oriented as shown by its component outline, but do not solder. **Do not bend the relay leads.** Note: The reference designators for the relays may be difficult to read on the rev. C board. They are sequential, starting from the left with K1.

Place relays at locations K6-K10. **This second row of relays faces in the opposite direction from the first row.** Do not solder yet.

Using a book or other flat object to hold the relays in place on the top side of the board, flip the board over. Solder two diagonal corner pins on each relay.

Inspect all 10 relays closely to make sure that they're seated flat against the PC board. If not, re-heat the corner pins one at a time while pressing down on the relay. Once all relays are properly seated, solder the remaining pins.

Install the 28-pin IC socket at U1. The notched end of the socket must be aligned with the notched end of the component outline.

Install the following resistors, starting with R6 in the upper left-hand corner of the board:

__ R6, 1k (brown-black-red)

__ R5, 100 ohms (brown-black-brown)

__ R4, 3.3k (orange-orange-red)

__ R3, 200 ohms (red-black-brown)

Install the three diodes, with the banded end of each diode oriented as shown on the board. D1 and D2 are type 1N5711. D3 is a type 1N34A, with a larger glass body. The reference designator D3 may not be silk-screened on the board. D3 goes into the two solder pads between relay K3 and the edge of the board, with the banded end closest to the pads for connector J2 at the corner of the board. Note: On the revision C PC board, D3 may be a tight fit. Pre-form the leads if necessary.

Install potentiometers R1 and R2 as indicated by their outlines. Make sure they are fully seated on the PC board and are not tilted. **Trim the leads after soldering.** This is necessary to prevent shorts when the KAT1 is installed above the Filter board.

Install RF choke RFC1, which is located near U1.

Ceramic resonator Z1 looks like a capacitor with three leads. Install Z1 (to the left of U1). Be careful not to overheat the resonator when soldering, as this can alter the resonant frequency. Keep soldering time to 1-2 seconds per lead. Trim the leads after soldering.

Install the LM358 IC at U2, with the notched or dimpled end oriented as shown by the component outline. Bend two corner pins to hold the IC in place, then solder.

Install the trimmer capacitor, C9. The flat side of C9 should be oriented to the left as indicated by its outline.

Install the following capacitors. Note: On the rev. C PC board, the pads for C5 (150 pF) and C17 (.001 μ F) may not be spaced perfectly for the supplied capacitors. You may need to pre-form the leads before installation.

__ C1, 10 pF __ C2, 22 pF __ C3, 39 pF __ C4, 82 pF __ C5, 150 pF (151)


__ C11, __ C12, and __ C17, .001 μ F (102) __ C13, and __ C14, .01 μ F (103)

__ C15, .047 μ F (473) __ C16, .01 μ F (103) __ C10, 100 pF (101)



In the following steps, inductors L1 through L4 will be wound and installed. *There is no need to adjust the windings to precisely match the inductances shown on the schematic.*

Inductor L1 is wound on a T37-2 core (red) using 6" (15 cm) of #26 red enamel wire. To wind the inductor, pass the long end of the wire through the core exactly 8 times. *Each pass through the core counts as one turn.* The finished winding should look like the illustration below. Exact turns spacing is not critical.



- Spread out the turns of L1 so they occupy about 80-90% of the core's circumference.
- Cut L1's leads to about 1/2" (12 mm) long. Completely remove the enamel insulation from the leads to within 1/8" (3 mm) of the core. The enamel wire provided can be heat-stripped using a small amount of solder on the tip of your iron. Stripping using this method takes 4-6 seconds.
- Install L1 vertically on the PC board as shown by its component outline, then pull the leads taut on the bottom of the board.
- Trim and solder the leads of L1. When soldering, make sure that the solder binds well to the leads. If the lead appears to be an "island" in a small pool of solder, chances are it is not making good contact. Measure from pad to pad using an ohmmeter to verify the connection.
- Wind and install L2 through L4 using the same procedure you used for L1. The number of turns and wire length for each inductor is shown below.

__ L2, 12 turns (8" [20 cm])


__ L3, 17 turns (11" [28 cm])

__ L4, 25 turns (15" [38 cm])

T1 is wound on a ferrite toroidal core (gray, FT37-43; may have an orange dot). Cut two 10" (25 cm) lengths of #26 enamel wire, one red and one green. Twist the two wires together, crossing over each other about 3 to 4 times per inch (1-2 times per cm). Then wind the twisted wires onto the core as shown below, using 10 turns. Each pass through the core counts as one turn, and turns spacing should closely resemble the illustration.



The wires labeled (1) and (3) should originate from below the core, and wires (2) and (4) from above it, as shown below. This will ensure that the transformer has the correct phasing.



Trim the leads of T1 to about 1/2" (12 mm) long. Completely remove the insulation from T1's leads up to the edge of the core, using a solder pot or hot soldering iron tip. Do not attempt to burn off the insulation using a match or lighter, as the flame may fuse the pairs of wire together, causing them to become shorted. Another way to remove the insulation is to use fine sand paper.

Tin T1's leads with solder. If the leads do not tin easily, the insulation may not be fully removed.

Using an ohmmeter, measure between the red and green wires to make sure that they're not shorted.

Install T1 as indicated by its PC board outline near the right end of the board. Insert the leads into the numbered holes as shown by the drawing of T1. Pull the leads taut on the bottom of the board. Before soldering, make sure that the entire portion of exposed lead is properly tinned.

Cut a 1-1/8" (2.9 cm) length of insulated, solid-conductor hookup wire. Remove 1/4" (6 mm) of insulation from each end. This jumper will form the 1-turn link winding of T1.

Insert this wire through the center of T1 and into the pad labeled 5. Bend the wire down to the left and insert the other end into pad 6. Pull the leads of the wire taut on the bottom of the board, then solder.

- Install the 3-pin male connector, P1, on the *bottom* of the ATU board as shown below. Before soldering, make sure the connector is seated flat against the board and is not tilted. If the connector is not mounted correctly, it may be difficult to plug the ATU board into the Filter board.



- Install the 10-pin, dual-row male connector, P2, on the *bottom* of the ATU board. As with P1, make sure the connector is seated completely flat against the PC board.
- Straighten the pins on U1 (16C72A). Refer to Figure 4-6 in the K1 owner's manual if necessary.
- Install U1 in its socket, noting the orientation of pin 1, which is label on the board.
- Form a discarded component lead into a small U-shape, and install it between the two pads labeled with a ground symbol (lower left-hand corner of the PC board). Solder the jumper on the bottom of the board.

K1 Filter Board Preparation

- Remove the K1's top cover (four screws).
- Remove the three screws holding the Filter board in place, and unplug the board.
- Install a 3-pin female connector (FIL-J1) on the *top* side of the Filter board. Before soldering, make sure that the connector is flat against the board and is not tilted.
- Remove the jumper between pins 2 and 10 of J2 on the Filter board. Wick out any residual solder.
- Install a 10-pin, dual-row female connector (FIL-J2) on the *top* side of the Filter board. Before soldering, make sure that the connector is flat against the board and is not tilted.
- If you have any additional Filter boards, repeat the previous three steps for each one.
- If any of your Filter boards are not aligned, you should align them now as described in the K1 owner's manual. Filter board alignment cannot be done with the KAT1 installed, since the KAT1 module prevents access to the slug-tuned inductors. See page 40, **Band-Pass Filter Alignment**, and page 46, **Preparation for Transmit Alignment**.

K1 RF Board Preparation



- Remove the K1's bottom cover (six screws, plus the connector hardware).
- If your K1's RF board is revision E or later, move the RF DET jumper on 3-pin header P3 to the KAT1 position. If your K1's RF board is revision D or earlier, locate R36 on the RF board, near the antenna jack. Unsolder the lead of R36 that is closest to the jack. Bend the resistor up and away from the board, but do not remove it completely. **Note:** If you need to remove the KAT1 later to align a new filter board, you will need to reconnect R36 or move the header on P3 to its original position.



The following five steps are only necessary if you have revision D or earlier of the K1 RF board. On later revisions, these parts will already have been installed during RF board assembly.

- Install resistor RF-R39 (1.8 k, brown-gray-red) on the bottom of the RF board between Q14 base and ground, if you haven't already. To install this resistor:
 1. Locate RP4, in the back-left corner of the RF board near the key jack.
 2. On the bottom of the board, solder one end of R39 to pin 1 of RP4 (the round pad). Keep the lead length very short.
 3. Solder the other lead of R39 to the nearby ground pad for crystal X6. This pad can be easily identified on the top side of the board; the "X6" label is directly above it.
- Solder capacitor RF-C76 (.01 μ F, "103") across RF-R39, the resistor in the previous step. Use short leads, and fold the capacitor down so it won't hit the bottom cover.

- On the bottom of the RF board, locate the label **DRV**. Just to the right of the letter **V** in **DRV** is a trace segment about 1" (2.5 cm) long, with four 45-degree bends (see below). Carefully cut this trace in approximately the location shown, using a sharp knife or hand milling tool. Use an ohmmeter to verify that the trace is cut.



- Solder resistor RF-R4 (5.6 k) on the bottom of the board between the two pads located at either end of the cut trace segment. Use the minimum lead length necessary. Position the resistor so that its leads do not touch any adjacent pads or traces. Solder the resistor on the bottom of the board.
- If you plan to use the KAT1 on 80 meters, install a 100- μ H RF choke on the bottom of the RF board as described in the K1B80 errata sheet. The RF choke is supplied with the 80-meter band kit.

Filter Board and KAT1 Module Installation

- Plug in the Filter board you plan to use, being very careful to line up all 8 pins of each of the three connectors. To hold the Filter board in place, use only the *middle* of the three screws. The two screws at the ends of the Filter board will not be needed, because the KAT1 module's screws will be inserted here.
- Set one 5/8" long unthreaded standoff on top of each of the two holes at the ends of the Filter board. These standoffs must not be left out, since they establish the spacing between the two boards.
- Plug the KAT1 module into the Filter board, being careful to line up all pins of the 3-pin and 10-pin connectors.
- The two 5/8" long standoffs should now be visible through the holes at each end of the KAT1 module. Use two 1" long 4-40 screws and two #4 split lock washers to hold the KAT1 to the Filter board.

Initial Test

- Connect a power supply or battery to the K1 and turn on power. If you see or smell smoke, turn power OFF immediately. Check all connections and refer to the Troubleshooting section if necessary.
- Tap **MENU** and scroll through the entries until you find **ATU**. To select the mode for the ATU, hold **EDIT**. If you see three dashes (---) instead of the **ATU** parameter, refer to Troubleshooting.
- Step through the **ATU** menu parameters using **WPM+** and **WPM-**. Each menu entry will be explained in the Using the ATU section.
- Set the **ATU** parameter to **L0**. You should hear a relay switch when you move from **L0** to **L1**, then to **L2**, etc., up through **L4**. The same should be true for **C0** through **C5**, as well as **N1** and **N2**. If you don't hear any relays switching, see Troubleshooting.
- Connect a 50-ohm dummy load to the K1's antenna jack (5W or higher rating). Use the **OUT** menu entry to set power to 5 watts.
- Set the **ATU** parameter to **Fx.x** (KAT1 firmware revision). You should see **F1.1** (or higher). Exit the menu, then hold **WPM+** and **WPM-** together to go into TUNE mode: you should see **r8.5**. Immediately tap any key to exit TUNE.

Note: **r8.5** is an SWR test value only, showing whether digital data is being transmitted successfully from the KAT1 to the K1 in TUNE mode.

SWR Bridge Adjustment (C9)

- Make sure a 50-ohm dummy load is connected to the antenna jack.
- Select band 1 (the lower of the two bands).
- Set the **ATU** parameter to **CLS** (Calibrate SWR) using the menu.
- Set power output for 5.0 watts using the **OUT** menu entry. Exit the menu.
- Pre-set potentiometers R1 and R2 on the ATU board to about 60% of full clockwise rotation.
- Connect the positive lead of a DMM or analog voltmeter to the point labeled **TP1**. Connect the negative lead to the nearby ground jumper.
- Locate a non-metallic tuning tool for adjusting ceramic trimmer C9. An alternative is to use a very small flat-blade screwdriver or jeweler's driver, with tape wrapped around the metal shaft to prevent you from contacting it.
- Enter TUNE mode by holding **WPM+** and **WPM-** together. Adjust C9 for the lowest possible voltmeter reading. (The null may be sharp.) Cancel TUNE mode by tapping any switch other than **WPM+** or **WPM-**.

Power Calibration (R1 and R2)



The KAT1 will provide accurate power readings only if properly calibrated. This requires an external wattmeter *or* an RF probe and digital multimeter (DMM). Appendix E of the K1 Owner's Manual shows how to construct a suitable RF probe.

- If you have an external wattmeter:* connect its input jack to the K1's antenna jack. Connect a 50-ohm dummy load to the wattmeter's output jack. Use short lengths of good-quality coax.
- If you're using an RF probe:* connect a 50-ohm dummy load directly to the K1's antenna jack using the shortest possible leads. Connect the tip of the RF probe to the "hot" lead of the dummy load, and the probe's ground clip to the dummy load's chassis or RF ground. Connect the DC outputs of the RF probe to your DMM, and set the DMM for DC volts (20 or 30 volt scale).
- Select band 1 (the lowest-frequency band).
- Use the **OUT** menu entry to set the K1's output to **5.0** watts.
- Use the **ATU** menu entry to set the ATU's mode to **CLP** (Calibrate Power), then exit the menu.
- If you have an external wattmeter:* Enter TUNE mode. Once the power has stabilized (about two seconds), tap **WPM+** or **WPM-** until the wattmeter shows close to 5.0 watts. Then adjust R1 on the KAT1 so that the K1's LCD shows the same power.
- If you're using an RF probe:* Enter TUNE mode. Once power has stabilized (about two seconds), tap **WPM+** or **WPM-** until the DMM shows about 14 VDC. Then adjust R1 on the KAT1 so that the K1's LCD shows about 5.0 watts.

Note: The power indicated when using an RF probe will vary somewhat from band to band due to the stray reactance of both the tuner and the probe. Also, the probe's diode may not perform as efficiently on the higher bands. This is why we recommend doing the **CLP** adjustment on the lower of the K1's two bands.

- Adjust R2's rotation to match that of R1 (visually).

Final Assembly

- Turn off the K1 and disconnect the power source.
- Re-install the bottom cover and the connector hardware.
- Due to the height of the ATU board when installed, the rear-most lug on the speaker may touch the case of one of the ATU's relays. To avoid this, fold the speaker lugs as flat as possible; make sure they're not shorted to the speaker frame.
- Plug in the speaker. **Route the speaker cable along the K1's right side panel, away from the ATU board and the front panel.** This will minimize stray RF pickup.
- Re-install the top cover.

Using the ATU

Caution: Never touch an exposed antenna wire when transmitting. If you ever feel an RF burn or shock when touching the K1 chassis or key, see **Antenna Considerations**.

Basic ATU Operation (TUN)

To tune up an antenna using the KAT1:

- Use the K1 menu to set the ATU's operating mode to **TUN** (auto-tune), then exit the menu.
- Connect an antenna and ground to the K1. (You can use most coax-fed antennas, as well as end-fed wires connected directly to the K1 with no coax. Use a balun with balanced feedlines.)
- Enter TUNE mode. Power will be reduced to about 1.5 watts and displayed briefly, then SWR will be displayed while the ATU matches the transmitter to the load (usually 1-5 seconds). If the match is already very good (< 1.2:1), the tuner's L and C settings will not be changed.
- When you no longer hear any relays switching, tune-up has completed, and the final SWR is displayed. At this point you can optionally tap **WPM+** or **WPM-** to change the selected power level. Pressing any other switch or tapping the key will cancel TUNE and restore your specified power.
- ATU settings are stored in EEPROM, and will be recalled instantly whenever you change bands.

Displaying Power Output (OUT)

To display forward power without changing the present L and C settings:

- Change the **ATU** mode from **TUN** to **OUT** and exit the menu.
- Enter TUNE mode; forward power will be displayed until you tap any switch.
- If the actual power output is lower than you selected in the menu, you may have it set higher than the K1 is capable of on the present band. **Always set power to a level at or below the maximum that the K1 can achieve. Use lower power when running from a battery.**

Displaying SWR (rx.x)

To display SWR without changing the present L and C settings:

- Use the menu to change the **ATU** mode from **TUN** to **rx.x** (the most recent **SWR** reading). Example: **r1.2** means that the last SWR reading was 1.2:1.
- Enter TUNE mode; the present SWR will be displayed until you cancel by pressing any switch. Power will be reduced to about 1.5 watts whenever SWR is displayed.

Using an External Antenna Tuner (CLS and CLP)

If you're using an external antenna tuner you can still use the KAT1 to display SWR or power:

- Set the ATU mode to **CLS** (for SWR display) or **CLP** (for forward power display). In both cases, the L and C in the matching network will be set to zero.
- Enter TUNE mode. In the case of **CLS**, power will be reduced to about 1.5 watts, then SWR will be displayed. In **CLP** mode, power will be displayed, and will not be reduced.
- Adjust the external antenna tuner. Once tune-up is completed, exit TUNE mode as usual.

Important ATU Operating Tips

- A 1.0:1 SWR is *not* necessary for good performance. See **Antenna Considerations**. If the final SWR is above 3:1, you may want to use lower power or re-configure your antenna. (The impedance matching range is reduced on 80 meters.)
- If you switch between the various ATU modes frequently, you can assign the **ATU** menu entry to the programmable function switch, **PFn** (see the K1 Owner's Manual for details).
- If you use **DISPLAY** to put the K1 into supply voltage display mode, then enter TUNE, you'll see the transmit-mode battery voltage, not SWR or power output. The ATU settings will not change.
- The ATU menu entry can be used to display the current values of L, C, network type, and other data. See **ATU Modes** for a full listing of all status displays.

ATU Modes

Table 1 lists all of the KAT1's operating modes, and what is displayed when TUNE is activated in each mode. The ATU's **TUN** mode is used for normal operation. In this and all other modes where SWR is displayed, power is dropped to approximately 1.5 watts during TUNE. You can override this level by setting power *lower* using the **OUT** menu entry. However, if you see **PLO** on the LCD during TUNE, you may have power set too low to obtain a stable SWR reading.

The other modes are primarily used for calibration and troubleshooting:

- In **CLS** mode (as well as **CLP**), the L and C relays are all reset (L and C = zero).
- The **L0-L4**, **C0-C5**, **N1**, and **N2** modes select individual L/C/net relays for test purposes. Note: In modes **L0-L4**, capacitance is set to 0. In modes **C0-C5**, the inductance is set to about 1 μ H. See Troubleshooting for details on how to make use of these modes.
- The **Fx.x** menu entry shows the firmware revision. If you enter TUNE in this mode you should see **r8.5**, which is a test pattern for the digital SWR data sent over the RFDET/DATA line.

Table 1. ATU Modes

Mode	Description	TUNE	Mode	Description	TUNE
CLP	Used for calibration of R1; L/C = 0	Power	NTx	1=Cin, 2=Cout (present band)	SWR
CLS	SWR bridge only; L/C = 0	SWR	Exx	1-49 = error (see Troubleshooting)	SWR
TUN	Auto-tune mode	SWR	Fx.x	KAT1 firmware revision, e.g. F1.0	r8.5
OUT	Forward power display	Power	L0-L4	Individual inductor test (C = 0)	SWR
rx.x	SWR from most recent TUNE	SWR	C0-C5	Individual capacitor test (L = 1 μ H)	SWR
Lx.x	Inductance, μ H (present band)	SWR	N1	Network relay test, Cin (L/C = 0)	SWR
Cxx	Capacitance, pF x10 (present band)	SWR	N2	Network relay test, Cout (L/C = 0)	SWR

Antenna Considerations

An antenna tuner will not *improve* your antenna—it can only tune out the antenna's reactance. In general, use the longest, highest antenna you can put up, and keep the antenna away from power lines and buildings. The KAT1 will work with a wide variety of antennas, some of which are covered below.

Ground System

A good ground system will provide efficient radiation, better antenna loading characteristics, less RF on the chassis, and safer operation. Use a minimum of two radials, cut to 1/4 wavelength on the lowest band used.

Do I Need a 1:1 SWR?

No—this is a common misconception. For example, if the SWR is 2:1, the loss in transmitted signal strength will be only about 0.5 dB. Of course the KAT1 always tries to hit 1:1, and with most antennas it will find an SWR below 1.5:1 on most bands. If the SWR is higher than 3:1, try using a balun (see below).

Resonant and Multi-Band Antennas

With resonant antennas such as dipoles, beams, or verticals, the KAT1 will typically improve the match on each band used. It may also allow operation on additional bands, although with beams, the radiation pattern may change completely. With short, loaded whips the tuner may provide multi-band coverage, but such antennas are generally ineffective due to the low radiation resistance. We recommend random-wire antennas for portable use (see below).

One useful trick with coax-fed antennas is to short the center conductor and braid together and treat the system as if it were a random wire. This may allow you to operate well below the antenna's intended bands.

Random-Length Antennas

The KAT1 is optimized for use with long, random-length wire antennas, since these are the easiest antennas to set up in the field (you just toss the wire in a nearby tree). In most cases you can connect such an antenna (and a few ground radials) directly to the K1, with no feedline. However, watch for RF problems, especially if the wire is exactly a half-wavelength long or any multiple thereof on a given band. The KAT1 also works with loops. An untuned loop of wire 30 feet long (or longer), formed into any shape, can be matched on most bands. A loop may work well even if you can't lay out a lot of ground radials.

Using Baluns and RF Isolation Chokes

A balun converts a balanced antenna or feedline to unbalanced (one side grounded) to work with your tuner. A balun can also perform an impedance transformation and/or help isolate the antenna from the rig to reduce RF pickup. You may need a balun if: (1) you're using balanced feedline; (2) you're having trouble matching an antenna on one or more bands; (3) you notice RF feedback or get an RF burn. A low-loss, broad-band, 4:1 balun is a good choice, and may solve all three problems. A 9:1 or 4:1 balun is often used with open-wire line. A 1:1 balun or coaxial isolate choke (current balun) will also work in many cases.

Balun design is covered in many publications, including the *ARRL Handbook*. Also check the Elecraft web site (www.elecraft.com) for antenna-related application notes.

Troubleshooting

If the ATU menu parameter shows "---" at all times, make sure you have revision 109 or later of the K1 main processor firmware. Other possibilities include a connector shifted by one position, an unsoldered pin, etc. Check the ATU PC board for shorts to ground, solder bridges, and unsoldered connections. Verify that the microcontroller is fully seated in its socket and is not plugged in backwards.

If you don't see r8.5 when doing TUNE with the ATU in Fx.x mode, digital SWR data is not being sent correctly across the RFDET/DATA line. Check U2 and D3 for proper orientation. Also look for a short anywhere around U2 or related components.

If the ATU menu parameter becomes "---" after doing a tune-up, it may be due to very high RF feedback into the transceiver. Turn power off and back on, then re-test the ATU using a dummy load or a different antenna. If it functions correctly on a dummy load but not on your antenna, try using a balun.

If the SWR isn't < r1.2 with a 50-ohm load, C9's setting may be incorrect. On the highest bands the SWR may be slightly higher than 1.0:1 due to stray reactances in the tuner, even when the ATU is in **CLS** mode.

If the power indicated is always about 0 watts, the windings of T1 may be reversed, or one or more leads of T1 or L1-L4 may not be properly stripped.

If you see PLO on the display during any mode that should display SWR, you probably have power set too low to obtain a stable SWR reading. Power is automatically reduced to 1.5 watts in all SWR-reading modes, so there's usually no need to set power below this level manually, unless you're operating "QRPp" (very low power). In this case, set the power to about 1 to 2 watts for tune-up purposes, then decrease it for operation.

If the ATU shows an error message (Exx in the menu where xx is between 1 and 49), you may have a defective microcontroller. **Exx** numbers 50-99 are used for tune-up algorithm tracking, and do not indicate a problem.

If SWR is not displayed during TUNE with the ATU in CLS, TUN, or a status mode, you may have high RF feedback into the transceiver. Reduce power to 0.5 watts using the **OUT** menu entry. If this cures the problem, you may need to improve your ground system, move the antenna farther away, or use a balun.


If the tuner is unable to achieve a low SWR on some bands, even with several different antennas, you could have a single defective relay or component on the L-C board. Start by slowly scrolling through ATU menu parameters **L0** through **L4**, **C0** through **C5**, **N1**, and **N2**. At each setting you should hear relays switching. If you find one that doesn't, this may pinpoint a bad relay. If the relays are all working but you suspect an inductor or capacitor, you can test each L and C by noting their effect on SWR, one at a time. Start on the highest band. Connect a 50-ohm dummy load to one of the antenna jacks, select **L0**, do TUNE, and note the SWR reading. Then select **L1** and do TUNE again; the SWR should change by a small amount. **L2** should have a larger effect, etc. When the inductance selections cause the SWR to go off the scale (**9.9**), switch to a lower band, go back to **L0**, then test the remaining inductors. Similarly, you can test all five capacitors, starting on the highest band with **C0**, **C1**, etc. You'll know you have found the bad component if it has too large or small an effect (or no effect) on SWR, in relation to the others tested.

Circuit Details

The ATU uses four inductors and five capacitors in an L-network. The capacitance can be placed at the transmitter or antenna end of the network via K5. Each inductor and capacitor has its own DPDT relay, with the individual sections of each relay placed in parallel for reliability. The relays are selected under control of the ATU's microcontroller, U1. Latching relays are used so that they will not consume any power except when the operator is actually tuning.

T1, D1, D2 (etc.) form a directional coupler for SWR and power measurements. The bridge output is buffered by op-amp U2 and routed to the K1 control board. The bridge outputs are also connected to A-to-D inputs on the microcontroller, U1. U1 measures these voltages and converts them to SWR or power readings, using averaging and linearization techniques to improve accuracy. During normal operation, the RFDET/DATA line provides an analog power indication to the K1's main microcontroller. When SWR is to be displayed, this line is used to transmit digital SWR data (10 ms/bit data rate). U1 "sleeps" except during antenna tune-up, so it generates no receiver noise.

KAT1 Schematic



NOTES:

1. R36 on the K1 RF board must be removed when the ATU is installed (see text).
2. K1-K10 are single-coil latching relays, shown in the RESET position.
Pins 5 and 6 of each relay are used as tie points but are not internally connected.

☐ = On bottom of PC board.

Elecraft		KAT1 Antenna Tuner		
By W. Burdick	Rev.	Date	Sh.	
E. Swartz	A	11-27-00	1 of 1	