

# Manual Supplement

Manual Title:	8808A Getting Started	Supplement Issue:	7
Part Number:	2716412	Issue Date:	11/13
Print Date:	July 2007	Page Count:	2
Revision/Date:			

---

---

This supplement contains information necessary to ensure the accuracy of the above manual.

## Change #1, 44931, 46479, 47892

On page 1, in the **Specifications** section, under **Relative Humidity (non-condensing)**, replace Operating with the following:

Operating..... <90 % (0 °C to 28 °C)  
 <75 % (28 °C to 40 °C)  
 <45 % (40 °C to 50 °C)

On page 5, under **DC Current, Shunt Resistance**, replace the Burden Voltage with the following:

Burden voltage <5 mV for 200 µA and 2 mA range.

In the **Input Characteristics** table, change the **Burden Voltage** for both 200 µA and 2 mA ranges,

From: <1 mV

To: <5 mV

## Change #2

On page 6, under the Warning, replace steps 4 and 5, with the following:

4. Insert the other end of the test lead into the **mA** terminal. If the fuse is good, the Meter displays a reading of <10 Ω. If the fuse is blown, the Meter displays **OL** to indicate an overload.
5. Remove the test lead from the **mA** terminal and insert it into the **10 A** terminal. If the fuse is good, the Meter displays a reading of <2 Ω. If the fuse is blown, the Meter displays **OL** to indicate an overload.

## Change #3, 53744

Under the **LIMITED WARRANTY AND LIMITATION OF LIABILITY** replace the second sentence with the following:

The warranty period is three years limited and begins on the date of shipment.

On page 11, replace Table 6 with the following:

**Table 6. Accessories**

Item	Model / Part Number
Premium Test Lead Set	TL71
Fuse, .25*1.25, 0.063 A, 250 V, Slow	163030
Fuse, .25*1.25, 0.125 A, 250 V, Slow	166488
F1 - Fuse, 11 A, 1000 V, Fast, 406INX1.5IN, BULK	803293
F2 - Fuse, 440 mA, 1000 V, Fast, 406INX1.375IN, BULK	943121
Rack Mount Kit 8845A & 8846A Single	Y8846S
Rack Mount Kit 8845A & 8846A Dual	Y8846D
USB to RS-232 Cable Adapter (included)	884x-USB
Precision Electronic Probe Set	TL910
2X4 Wire Ohms 1000 V Test Lead	TL2X4W-PTII
FlukeView Forms Basic Software (included)	FVF-SC5
FlukeView Forms Software Upgrade to enhanced version	FVF-UG

In the **Specifications** section on page 2, change the **Warranty**,

From: One year

To: Three years limited


## Change #4

On page 6, under the **Current-Input Fuses** section add the following Table:

**Current Input Fuse Table**

F1	F1 - Fuse, 11 A, 1000 V, Fast blow or equivalent	803293
F2	F2 - Fuse, 440 mA, 1000 V, Fast blow or equivalent	943121

On page 6, under the **Warning** replace step 3 with:

Press  to set the range to 200 Ω.



On page 7, under the **Warning** replace step 5 with:

- Remove the defective fuse and replace it with a fuse of an appropriate rating. See the Current Input Fuse Table.

## Change #5, 64136 64137, 64189, 65595

On page 2, under **General Safety Summary** remove the first paragraph.

On page 4, add the following to the **Symbols** table:

	Conforms to relevant South Korean EMC Standards.
	Conforms to CAN/CSA-C22.2 No. 61010-1, second edition, including Amendment 1.

On page 2, in the **Specification** section, replace **Safety** and **EMC** with:

**Safety** ..... IEC 61010-1: Overvoltage CAT II, Pollution Degree 2  
IEC 61010-2-030: Measurement 600 V CAT II

**Electromagnetic Environment**..... IEC 61326-1: Basic

**Electromagnetic Compatibility**.....Applies to use in Korea only. Class A Equipment (Industrial Broadcasting & Communication Equipment)<sup>[1]</sup>

[1] This product meets requirements for industrial (Class A) electromagnetic wave equipment and the seller or user should take notice of it. This equipment is intended for use in business environments and is not to be used in homes.