



MAU3147FC, MAU3073FC, MAU3036FC DISK DRIVES INSTALLATION GUIDE

CARE OF YOUR FUJITSU DRIVE

Careful handling and installation of your disk drive is paramount to the longevity of the unit. Serious damage can occur to the internal mechanisms if forces outside the environmental specifications are exerted to the casing. In transportation, always use the original packing in which the drive was supplied and avoid sharp changes in temperature to minimise the risk of condensation.

Handling

1. **Never** drop. Handle with care.
2. **Never** move the disk drive while the disks are spinning. This is when the drive is powered on and also immediately after power off. Refer to the Start/Stop specification for your drive.
3. **Always** turn off the power before connecting or disconnecting the interface cable.
4. **Never** place the drive in the vicinity of strong magnetic fields such as monitors, televisions, or loudspeakers.
5. **Never** use any cleaning agents or liquids on the drive.
6. **Always** use an antistatic mat and wrist strap when handling the drive. Hold the drive by the Base casting and never touch the components on printed circuit board.
7. **Never** remove any labels from the drive and do not deface them in any way; these labels are part of the disk drive design.
8. **Never** open the disk enclosure for any reason. Doing so voids any warranty.
9. **Always** pay close attention to the mounting specifications such as sway space and cooling. If the temperature difference between storage location and installation locations is more than 10°C, leave the drive in the new location for at least two hours for Temperature acclimation. This minimises any risk of condensation forming on the drive.

The Drive needs NO preventative or periodic maintenance during its life time if properly used in the correct environment.

INSTALLATION

1. **ORIENTATION**—The drive can be installed in each six surface down orientations. Inclination from vertical or horizontal should not exceed 5°.
2. **MOUNTING SCREW INSTALLATION**—When the mounting screw holes on the side of the drive are used, be sure to use the two pairs of outer holes. Do not use the center hole in conjunction with only one of the outer holes. The screws must not penetrate the drive by more than 5.0 millimeters. Impact caused by the electric driver must be within the device specifications.
3. **COOLING**—Allow space above and below the drive to provide an adequate air flow. Fan cooling is recommended. The disk enclosure temperature measured at center of base cover (label side) should never exceed 60°C. See Table 1.

Table 1. Reference value of airflow

Environmental temperature	Required velocity of airflow
35°C	> 0.8 m/s
40°C	> 1.1 m/s
45°C	> 1.7 m/s

4. **ATTACHING THE CABLES**—To avoid possible damage to the drive, make sure the direction of the connector matches.

CAUTION: Warranty may be avoided if damage to the connector is caused by wrong insertion.