

# DDR/LPDDR Post Process Compliance Tool

User Guide

# Notices

© Keysight Technologies 2008-2014, 2015

No part of this manual may be reproduced in any form or by any means (including electronic storage and retrieval or translation into a foreign language) without prior agreement and written consent from Keysight Technologies as governed by United States and international copyright laws.

## Trademarks

UNIX is a registered trademark of UNIX System Laboratories in the U.S.A. and other countries. Target is copyrighted by Thru-Put Systems, Inc.

## Software Release

06.20.0000

## Edition

November 2015

Available in electronic format only

Keysight Technologies  
1900 Garden of the Gods Road  
Colorado Springs, CO 80907 USA

## Warranty

THE MATERIAL CONTAINED IN THIS DOCUMENT IS PROVIDED "AS IS," AND IS SUBJECT TO BEING CHANGED, WITHOUT NOTICE, IN FUTURE EDITIONS. FURTHER, TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, KEYSIGHT DISCLAIMS ALL WARRANTIES, EITHER EXPRESS OR IMPLIED WITH REGARD TO THIS MANUAL AND ANY INFORMATION CONTAINED HEREIN, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. KEYSIGHT SHALL NOT BE LIABLE FOR ERRORS OR FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES IN CONNECTION WITH THE FURNISHING, USE, OR PERFORMANCE OF THIS DOCUMENT OR ANY INFORMATION CONTAINED HEREIN. SHOULD KEYSIGHT AND THE USER HAVE A SEPARATE WRITTEN AGREEMENT WITH WARRANTY TERMS COVERING THE MATERIAL IN THIS DOCUMENT THAT CONFLICT WITH THESE

TERMS, THE WARRANTY TERMS IN THE SEPARATE AGREEMENT WILL CONTROL.

## Technology Licenses

The hardware and/or software described in this document are furnished under a license and may be used or copied only in accordance with the terms of such license.

## U.S. Government Rights

The Software is "commercial computer software," as defined by Federal Acquisition Regulation ("FAR") 2.101. Pursuant to FAR 12.212 and 27.405-3 and Department of Defense FAR Supplement ("DFARS") 227.7202, the U.S. government acquires commercial computer software under the same terms by which the software is customarily provided to the public. Accordingly, Keysight provides the Software to U.S. government customers under its standard commercial license, which is embodied in its End User License Agreement (EULA), a copy of which can be found at <http://www.keysight.com/find/sweula>. The license set forth in the EULA represents the exclusive authority by which the U.S. government may use, modify, distribute, or disclose the Software. The EULA and the license set forth therein, does not require or permit, among other things, that Keysight: (1) Furnish technical information related to commercial computer software or commercial computer software documentation that is not customarily provided to the public; or (2) Relinquish to, or otherwise provide, the government rights in excess of these rights customarily provided to the public to use, modify, reproduce, release, perform, display, or disclose commercial computer software or commercial computer software documentation. No additional government requirements beyond those set forth in the EULA shall apply, except to the extent that those terms, rights, or licenses are explicitly required from all providers of commercial computer software pursuant to the FAR and the DFARS and are set forth specifically in writing elsewhere in the EULA. Keysight shall be under no obligation to update, revise or otherwise modify the Software. With respect to any technical data as defined by FAR 2.101, pursuant to FAR 12.211 and 27.404.2 and DFARS 227.7102, the U.S. government acquires no greater than Limited Rights as defined in

FAR 27.401 or DFAR 227.7103-5 (c), as applicable in any technical data. 52.227-14 (June 1987) or DFAR 252.227-7015 (b)(2) (November 1995), as applicable in any technical data.

## Safety Notices

### CAUTION

A CAUTION notice denotes a hazard. It calls attention to an operating procedure, practice, or the like that, if not correctly performed or adhered to, could result in damage to the product or loss of important data. Do not proceed beyond a CAUTION notice until the indicated conditions are fully understood and met.

### WARNING

A WARNING notice denotes a hazard. It calls attention to an operating procedure, practice, or the like that, if not correctly performed or adhered to, could result in personal injury or death. Do not proceed beyond a WARNING notice until the indicated conditions are fully understood and met.

## Safety Summary

The following general safety precautions must be observed during all phases of operation of this instrument. Failure to comply with these precautions or with specific warnings or operating instructions in the product manuals violates safety standards of design, manufacture, and intended use of the instrument. Keysight Technologies assumes no liability for the customer's failure to comply with these requirements. Product manuals are provided with your instrument on CD-ROM and/or in printed form. Printed manuals are an option for many products. Manuals may also be available on the Web. Go to [www.keysight.com](http://www.keysight.com) and type in your product number in the Search field at the top of the page.

General	Do not use this product in any manner not specified by the manufacturer. The protective features of this product may be impaired if it is used in a manner not specified in the operation instructions.
Before Applying Power	Verify that all safety precautions are taken. Make all connections to the unit before applying power. Note the instrument's external markings described in "Safety Symbols".
Ground the Instrument	If your product is provided with a grounding type power plug, the instrument chassis and cover must be connected to an electrical ground to minimize shock hazard. The ground pin must be firmly connected to an electrical ground (safety ground) terminal at the power outlet. Any interruption of the protective (grounding) conductor or disconnection of the protective earth terminal will cause a potential shock hazard that could result in personal injury.
Fuses	See the user's guide or operator's manual for information about line-fuse replacement. Some instruments contain an internal fuse, which is not user accessible.
Do Not Operate in an Explosive Atmosphere	Do not operate the instrument in the presence of flammable gases or fumes.
Do Not Remove the Instrument Cover	Only qualified, service-trained personnel who are aware of the hazards involved should remove instrument covers. Always disconnect the power cable and any external circuits before removing the instrument cover.
Cleaning	Clean the outside of the instrument with a soft, lint-free, slightly dampened cloth. Do not use detergent or chemical solvents.
Do Not Modify the Instrument	Do not install substitute parts or perform any unauthorized modification to the product. Return the product to an Keysight Sales and Service Office for service and repair to ensure that safety features are maintained.
In Case of Damage	Instruments that appear damaged or defective should be made inoperative and secured against unintended operation until they can be repaired by qualified service personnel.

### CAUTION

A CAUTION notice denotes a hazard. It calls attention to an operating procedure, practice, or the like that, if not correctly performed or adhered to, could result in damage to the product or loss of important data. Do not proceed beyond a CAUTION notice until the indicated conditions are fully understood and met.

### WARNING

A WARNING notice denotes a hazard. It calls attention to an operating procedure, practice, or the like that, if not correctly performed or adhered to, could result in personal injury or death. Do not proceed beyond a WARNING notice until the indicated conditions are fully understood and met.

## Safety Symbols

Table 1 Safety Symbol

Symbol	Description
	Direct current
	Alternating current
	Both direct and alternating current
	Three phase alternating current
	Three phase alternating current
	Earth ground terminal
	Protective earth ground terminal
	Frame or chassis ground terminal
	Terminal is at earth potential
	Equipotentiality
N	Neutral conductor on permanently installed equipment
L	Line conductor on permanently installed equipment
	On (mains supply)
	Off (mains supply)
	Stand by (mains supply). The instrument is not completely disconnected from the mains supply when the power switch is in the stand by position
	In position of a bi-stable push switch

Symbol	Description
	Out position of a bi-stable push switch
	Equipment protected throughout by DOUBLE INSULATION or REINFORCED INSULATION
	Caution, refer to accompanying documentation
	Caution, risk of electric shock
	Do not apply around or remove from HAZARDOUS LIVE conductors
	Application around and removal from HAZARDOUS LIVE conductors is permitted
	Caution, hot surface
	Ionizing radiation
CAT I	IEC Measurement Category I
CAT II	Measurement Category II
CAT III	Measurement Category III
CAT IV	Measurement Category IV

## Compliance and Environmental Information

**Table 2** Compliance and Environmental Information

Safety Symbol	Description
	CSA is the Canadian certification mark to demonstrate compliance with the Safety requirements.
	The C-tick mark is a registered trademark of the Spectrum Management Agency of Australia. This signifies compliance with the Australia EMC Framework regulations under the terms of the Radio Communication Act of 1992.
	CE compliance marking to the EU Safety and EMC Directives. ISM GRP-1A classification according to the international EMC standard. ICES/NMB-001 compliance marking to the Canadian EMC standard.

## DDR/LPDDR Post Process Compliance—At a Glance

The DDR/LPDDR Post Process Compliance Tool evaluates the captured DDR/LPDDR data against a set of user-defined limits to help you validate that a memory system is operating properly. The bus types supported by this tool are:

- DDR1/2/3/4
- LPDDR1/2/3/4

The automated test application guides you through the process of selecting and configuring tests, running tests, and evaluating the test results.

The application assumes that the Keysight logic analysis system has already been set up to properly capture DDR data.

To use the automated test application, see:

- Chapter 2, "[Starting the DDR/LPDDR Post Process Compliance Tool](#)" on page 15
- Chapter 3, "[Configuring Tests](#)" on page 19
- Chapter 4, "[Setting Up the Test Environment](#)" on page 27
- Chapter 5, "[Selecting Tests](#)" on page 29
- Chapter 6, "[Running Tests](#)" on page 33
- Chapter 7, "[Automating the Tests](#)" on page 37
- Chapter 8, "[Viewing Results](#)" on page 41
- Chapter 9 "[Viewing/Exporting/Printing the Report](#)" on page 45
- Chapter 10 "[Saving Test Projects](#)" on page 51
- Chapter 11, "[Creating or Opening a Test Project](#)" on page 53



# Contents

Safety Summary	3
Compliance and Environmental Information	6
DDR/LPDDR Post Process Compliance—At a Glance	7
<b>1 About the Tool</b>	
<b>2 Starting the DDR/LPDDR Post Process Compliance Tool</b>	
<b>To Toggle between the Toolbar</b>	17
<b>3 Configuring Tests</b>	
<b>To set the test limits</b>	20
<b>To create/edit limit sets</b>	24
<b>To activate/refresh limit sets</b>	25
<b>4 Setting Up the Test Environment</b>	
<b>5 Selecting Tests</b>	
<b>6 Running Tests</b>	
<b>To set the display preferences</b>	36
<b>7 Automating the Tests</b>	
Prerequisites	37
Automation by Scripts	38
Automation by Files	39
<b>8 Viewing Results</b>	
<b>To change margin thresholds</b>	43
<b>9 Viewing/Exporting/Printing the Report</b>	
<b>To export the report</b>	47
<b>To print the report</b>	49

10 Saving Test Projects

**To set AutoRecovery preferences** 52

11 Creating or Opening a Test Project

**To set load preferences** 54

Index

# 1 About the Tool

## Overview of the tests

There are two types of tests:

- Tests which check for timing violations
- Tests which check for illegal DDR state transitions

The test limits can be (and must be) configured by the user.

The provided timing violation tests include:

Parameter	Description	Test
tRAS <sub>max</sub>	Row Active time ACTIVATE to PRECHARGE/Auto-PRECHARGE	must be < tRASmax
tRAS <sub>min</sub>	Row Active time ACTIVATE to PRECHARGE/Auto-PRECHARGE	must be > tRASmin
tRP	PRECHARGE to any other command (same bank)	must be > tRP
tCCD	Time between any read or write command	must be > tCCD
tRRD	ACTIVATE to ACTIVATE (any bank)	must be >= tRRD
tFAW	Time for four ACTIVATES (any bank)	must be >= tFAW
tRFC	REFRESH to REFRESH or ACTIVATE	must be > tRFC
tDARW	ACTIVATE to external READ/WRITE	must be > tDARW
tDRP	Read to Precharge/AutoPrecharge	must be > tDRP
tDRW	Read to Write	must be > tDRW
tDWP	Write to Precharge/AutoPrecharge	must be > tDWP
tDWR	Write to Read	must be > tDWR

Description
READ or WRITE to an inactive row
REFRESH to an active bank
ACTIVATE to an active bank

## Compatibility


The DDR/LPDDR Post Process Compliance Tool works for most DDR, DDR2, DDR3, DDR4, LPDDR, LPDDR2, LPDDR3 and LPDDR4 systems.

The tool is not able to fully model systems which use the following optional DDR features:


- Partial Array Self-Refresh (PASR)
- Auto Self-Refresh (ASR)
- On-the-fly Burst Length switching

About the software The Post Process Compliance Tool is part of the Keysight B4661A DDR/LPDDR Toolset package. This tool requires that you install the Logic and Protocol Analyzer software version 6.2 or higher. Versions prior to 6.2 do not support this tool.

Software License The DDR/LPDDR Post Process Compliance Tool requires B4661A\_3 license to operate. If this license is not installed in your system, the following license error dialog box is displayed while launching the DDR/LPDDR Post Process Compliance Tool application.




When you are launching the DDR/LPDDR Post Process Compliance Tool for the first time, the Keysight Technologies Software End User License Agreement dialog box appears. You can read the agreement and choose to agree or disagree before proceeding further to use the DDR/LPDDR Post Process Compliance Tool.






## 2 Starting the DDR/LPDDR Post Process Compliance Tool

- 1 From the logic analysis system's main menu, choose **Tools > External Applications > DDR/LPDDR Post Process Compliance Tool**.



The DDR/LPDDR Post Process Compliance Tool window appears.


## 2 Starting the DDR/LPDDR Post Process Compliance Tool



- See Also
- ["To Toggle between the Toolbar"](#) on page 17
- Next
- ["Creating or Opening a Test Project"](#) on page 53

## To Toggle between the Toolbar

To toggle between the toolbars, you can click and drag the toolbars accordingly. To keep the default display for the toolbars, select **View>Preferences>Tab Layout** from the menu.






## 3 Configuring Tests

You must configure a set of limits in **Configure** tab before you can run any tests.

These limits describe the memory part you are using and certain characteristics of the memory bus.



You can load, edit, and apply limits in **Limits** menu.

- See Also
- ["To set the test limits"](#) on page 20 (for information on how to calculate the limits)
  - ["To create/edit limit sets"](#) on page 24 (for information on how to enter and save the limits)
  - ["To activate/refresh limit sets"](#) on page 25 (for information on how to load a limit set which you have saved)

## To set the test limits

All timing violation tests are based on compliance limits that are specified by the user. Specify these limits based on the specific DDR memory parts you are using. Limits will vary depending on:

- Memory technology (DDR2, DDR3)
- Speed grade
- Clock speed
- Part density
- User selected options such as Additive Latency and burst length

**Units** Some times must be entered in seconds (s). If the data sheet expresses these limits in terms of clock cycles, you will need to convert those limits to seconds.

Each logic analyzer sample has a timestamp. Results will be calculated by subtracting the time stamp of the first event from the timestamp of the second event. Note that the time stamps are only as good as the time stamp resolution of the logic analyzer card being used (this resolution may be as coarse as 2ns; see the Specifications and Characteristics in the logic analyzer's Online help for details). The elapsed time includes time during which the DDR clock is inactive.

Other times must be entered as a number of clock cycles (CK). Results will be calculated by counting the number of logic analyzer samples between the two events.

Additive latency (AL) is normally expressed as a number of clocks (CK). For some calculations, you will need to convert AL to seconds (s) by dividing by the clock rate.

Burst length (BL) is simply an integer (4 or 8).

**Definitions of the limits** You will need to look up some of the limits from the part data sheet. You will then calculate values for the derived limits.

Keysight suggests using the formulas here to compute the derived limits. However, it is entirely the responsibility of the user to choose limits that are appropriate for the intended application.

Here are the limits you need to specify:

Parameter	Description	Unit	Suggested Definition	Reference
tRAS <sub>max</sub>	Row Active time ACTIVE to PRECHARGE	s	Part dependent (9 * tREFI)	Data Sheet (tREFI). See DDR3 (see <a href="#">page 24</a> ) page 147.
tRAS <sub>min</sub>	Row Active time ACTIVE to PRECHARGE	s	Part dependent	Data Sheet
tDARW	Min ACT to external READ/WRITE	s	tRCD-AL	DDR2 (see <a href="#">page 23</a> ) 3.5 / DDR3 (see <a href="#">page 24</a> ) 12.3
tRP	Row Precharge time min PRECHARGE to any other command (same bank)	s	Part dependent	Data Sheet
tDRP	Min Read to Precharge	CK	DDR2: AL + BL/2 + max (tRTP, 2CK) -2CK DDR3: AL + tRTP	DDR2 (see <a href="#">page 23</a> ) 3.7.1 / DDR3 (see <a href="#">page 24</a> ) 4.13.3
tDRW	Min Read to Write	CK	DDR2: BL/2 + 2CK DDR3: BL4: RL + CCD/2 + 2CK - WL DDR3: BL8: RL + CCD + 2CK - WL	DDR2 (see <a href="#">page 23</a> ) figure 35 / DDR3 (see <a href="#">page 24</a> ) figure 35, 36
tRFC	REFRESH command time. min time REFRESH to REFRESH or ACTIVATE	s	Part dependent	Data Sheet

Parameter	Description	Unit	Suggested Definition	Reference
tDWP	Min Write to Precharge	CK	WL + BL/2 + tWR	DDR2 (see page 23) 3.7.2 / DDR3 (see page 24) Figure 49, 50
tDWR	Min Write to Read	CK	DDR2: CL -1 + BL/2 + tWTR DDR3: WL + BL/2 + tWTR	DDR2 (see page 23) Figure 41 / DDR3 (see page 24) Figure 53, 56
tCCD	CAS to CAS delay min time between any read or write command	CK	Part dependent	Data Sheet
tRRD	Min time between two ACTIVATE commands (different banks)	s	Part dependent	Data Sheet
tFAW	Min time for four ACTIVATE commands (different banks)	s	Part dependent	Data Sheet

Values used to calculate the limits To calculate the limits, you will need to look up or calculate the following values:

Parameter	Description	Unit	Suggested Definition	Reference
AL	Additive Latency	CK, s	User selection	System Design
BL	Burst Length		User selection	System Design
CL	CAS (Read) Latency	CK	Part dependent	Data Sheet
CWL	CAS Write Latency	CK	Part dependent	Data Sheet
RL	Read Latency	CK	AL + CL	DDR3 (see page 24) 3.4.3.4
WL	Write latency	CK	AL + CWL	DDR3 (see page 24) 3.4.3.4
tRCD	RAS to CAS Delay (ACT to internal R/W)	s	Part dependent	Data Sheet
tREFI	Refresh Interval; average time between Refresh commands	s	Part dependent	Data Sheet
tRTP	Internal Read to Precharge	s	Part dependent (max 4CK or 7.5ns)	Data Sheet
tWR	Internal Write Recovery	s	Part dependent	Data Sheet
tWTR	Internal Write to internal Read	s	Part dependent (max 4CK or 7.5ns)	Data Sheet

External Read/Write + AL = Internal Read/Write

#### Naming conventions

Limits which are normally expressed as maximum or minimum times have names beginning with 't'. The names of derived timing limits begin with 'tD'. Derived limits are not usually specified directly in the part data sheet. In general, you will compute these from the standard timing parameters.


Limits which are normally expressed as a number of clock cycles have no prefix. In some cases, you may need to convert these to seconds for use by the tool.

#### Customizing the limits

The definitions are suggestions based on the DDR2/3 standards. There is no requirement that the user must set the limits to those specified in the data sheet or in the JEDEC standard. You can set the limits however you like, depending on the goals of your testing.

To load and view the limits, you can either use the default limit set or use customized limit sets.

If you are using customized limit sets, you can select the customized compressed archived files (.lim) from your local system and click **Apply Custom Limit Set...** in **Limits** section.



**Example limits** An example limit set is supplied with the validation tool. The example is based on a DDR800 part with 6-6-6 timing.

Example part:

- Data sheet: MICRON DDR3 MT41J256-32 Me x 4 x 8 Banks PDF: 09005aef82f1e6e2 Rev. M 9/08 EN
- Speed Grade 25 (6-6-6)
- Clock 400 MHz (2.5ns)
- Data Rate 800 MT/s
- Temperature 0-85C

Parameter	Value	Reference
tREFI	7.8 us (low temp)	Data Sheet, page 71
tRAS <sub>max</sub>	70.2us	Data Sheet (tREFI), page 63
tRAS <sub>min</sub>	37.5ns	Data Sheet, page 30
tRP	15ns	Data Sheet, page 30
tCCD	4CK (10ns)	Data Sheet, page 70
tRRD	10ns	Data Sheet, page 30
tFAW	50ns	Data Sheet, page 30
tRFC	110ns	Data Sheet, page 30
tRCD	15ns	Data Sheet, page 30
tRTP	10ns	Data Sheet, page 70
tWR	15ns	Data Sheet, page 70

Parameter	Value	Reference
tWTR	10ns	Data Sheet, page 70
AL	0ns (0CK)	User selected (MR1, 0 means no additive latency)
BL	10ns (8 bursts)	User selected (MR0)
CL	6CK (15ns)	Data Sheet, page 30 (MR0)
CWL	5CK (12.5ns)	Data Sheet, page 116 (MR2)


Parameter	Value
RL	6CK (15ns)
WL	5CK (12.5ns)
tDARW	15ns
tDRP	10ns
tDRW	17.5ns
tDWP	32.5ns
tDWR	27.5ns

- References
- DDR2 JEDEC Standard 79-2E, April 2008
  - DDR3 JEDEC Standard 79-3C, November 2008

## To create/edit limit sets

You can create new limit sets by modifying existing limit sets and saving them to new files.

- 1 From the DDR/LPDDR Post Process Compliance Tool's main page, choose **Edit Limit Values...** in **Limits** section.
- 2 In the Create/Edit User-Defined Limit Set dialog, double-click on the required test for which you want to edit the limits.



- 3 Modify the limit as desired.
- 4 Repeat the last two steps until all limits requiring change are modified.
- 5 Click **OK** to save your custom limit set to a file. Enter the file name in the Save File As dialog.
  - Now, you can activate your newly-created limit set for use in the next run. See ["To activate/refresh limit sets"](#) on page 25.

### When Loading Projects

When you load a project, the application will attempt to restore the limit set that was in use at the time the project was saved.


### See Also

- ["To set the test limits"](#) on page 20 (for information on how to calculate the limits)

## To activate/refresh limit sets

To load a previously defined limit set:

- 1 From the DDR/LPDDR Post Process Compliance Tool's menu, click **Activate/Refresh limit set...**
- 2 In the Activate/Refresh Compliance Limit Set dialog, select one of the official limit sets or a user-defined limit set.



- 3 Click **OK**.


### NOTE

If you have existing test results when you activate a different limit set, the application examines your results to see if any of them would experience a limit change when the different limit set is loaded. If any results would be affected in this way, the application tells you which ones they are and warns that they must be deleted.




## 4 Setting Up the Test Environment

- 1 Click the **Set Up** tab.
- 2 If more than one DDR bus decoder exists in the logic analysis system setup, select which one to use for the compliance tests from the **Select a DDR module to analyze** listbox.  
If only one decoder exists, it will be selected automatically.  
If needed, click **Refresh** to update the list. You may need to refresh the list and select a new decoder if you load a new logic analyzer configuration file, or whenever you add or remove a decoder.
- 3 Select the DDR memory type. The DDR/LPDDR Post Process Compliance Tool can work with any of the following memory bus standards.
  - DDR1/2/3 /4
  - LPDDR1/2/3/4
- 4 From the **Set Up** section, select whether or not you want the tool to automatically acquire new data when compliance tests are run. Whether you plan to run tests once or multiple times, the selection of this checkbox instructs the tool to first run the logic analyzer for data acquisition. When the data acquisition run is complete, the tool starts post processing the newly acquired data by running the selected tests. If you plan to run the tests multiple times or forever, then you must select this checkbox to ensure that the tool runs the logic analyzer repetitively for data acquisition and then acquires the new data automatically for post processing.  
Deselecting this checkbox instructs the tool to use the already acquired data for post processing. The tool does not run the logic analyzer for data acquisition in this case. Therefore, when you deselect this checkbox, you can run the tests only once on existing data.
- 5 (optional) Describe the test for future reference. The specified **User Comments** will appear on the HTML report which is generated for the test.



Next · "Selecting Tests" on page 29

## 5 Selecting Tests



- 1 Click the **Select Tests** tab and then select the tests you want to run.  
The tests displayed in this tab vary depending on the memory bus type that you selected in the **Set Up** tab.  
The following table lists the tests available for the memory bus types.

Tests Available With B4661A License (DDR Memory Type)

DDR1, 2 tests	DDR3 tests	DDR4 tests
<ul style="list-style-type: none"> <li><input type="checkbox"/> DDR/LPDDR Tests</li> <li><input type="checkbox"/> ACTIVATE to PRECHARGE/Auto-PRECHARGE must be <math>\leq</math> tRASmax</li> <li><input type="checkbox"/> ACTIVATE to PRECHARGE must be <math>\geq</math> tRASmin</li> <li><input type="checkbox"/> ACTIVATE to READ/WRITE must be <math>\geq</math> tRCD</li> <li><input type="checkbox"/> PRECHARGE to ACTIVATE must be <math>\geq</math> tRP</li> <li><input type="checkbox"/> READ to PRECHARGE must be <math>\geq</math> tRTP</li> <li><input type="checkbox"/> READ to WRITE must be <math>\geq</math> tDRW</li> <li><input type="checkbox"/> WRITE to PRECHARGE must be <math>\geq</math> tDWP</li> <li><input type="checkbox"/> WRITE to READ must be <math>\geq</math> tDWR</li> <li><input type="checkbox"/> WRITE to WRITE, READ to READ must be <math>\geq</math> tCCD</li> <li><input type="checkbox"/> REFRESH to non-NOP/DES must be <math>\geq</math> tRFC</li> <li><input type="checkbox"/> ACTIVATE to ACTIVATE (different banks) must be <math>\geq</math> tTRD</li> <li><input type="checkbox"/> READ or WRITE to an inactive row</li> <li><input type="checkbox"/> REFRESH to an active bank</li> <li><input type="checkbox"/> ACTIVATE to an active bank</li> <li><input type="checkbox"/> ACTIVATE to ACTIVATE (same bank) must be <math>\geq</math> tRC</li> <li><input type="checkbox"/> Mode Register Set command to Mode Register Set command <math>\geq</math> tMRD</li> <li><input type="checkbox"/> Refresh tests</li> <li><input type="checkbox"/> REFRESH cmd to REFRESH cmd must be <math>\leq</math> tREFI * 9</li> </ul>	<ul style="list-style-type: none"> <li><input type="checkbox"/> DDR/LPDDR Tests</li> <li><input type="checkbox"/> ACTIVATE to PRECHARGE/Auto-PRECHARGE must be <math>\leq</math> tRASmax</li> <li><input type="checkbox"/> ACTIVATE to PRECHARGE must be <math>\geq</math> tRASmin</li> <li><input type="checkbox"/> ACTIVATE to READ/WRITE must be <math>\geq</math> tRCD</li> <li><input type="checkbox"/> PRECHARGE to ACTIVATE must be <math>\geq</math> tRP</li> <li><input type="checkbox"/> READ to PRECHARGE must be <math>\geq</math> tRTP</li> <li><input type="checkbox"/> READ to WRITE must be <math>\geq</math> tDRW</li> <li><input type="checkbox"/> WRITE to PRECHARGE must be <math>\geq</math> tDWP</li> <li><input type="checkbox"/> WRITE to READ must be <math>\geq</math> tDWR</li> <li><input type="checkbox"/> WRITE to WRITE, READ to READ must be <math>\geq</math> tCCD</li> <li><input type="checkbox"/> REFRESH to non-NOP/DES must be <math>\geq</math> tRFC</li> <li><input type="checkbox"/> ACTIVATE to ACTIVATE (different banks) must be <math>\geq</math> tTRD</li> <li><input type="checkbox"/> Four ACTIVATE window (different banks) must be <math>\geq</math> tFAW</li> <li><input type="checkbox"/> READ or WRITE to an inactive row</li> <li><input type="checkbox"/> REFRESH to an active bank</li> <li><input type="checkbox"/> ACTIVATE to an active bank</li> <li><input type="checkbox"/> ACTIVATE to ACTIVATE (same bank) must be <math>\geq</math> tRC</li> <li><input type="checkbox"/> Mode Register Set command to Mode Register Set command <math>\geq</math> tMRD</li> <li><input type="checkbox"/> Mode Register Set command to valid command <math>\geq</math> tMOD</li> <li><input type="checkbox"/> Refresh tests</li> <li><input type="checkbox"/> REFRESH cmd to REFRESH cmd must be <math>\leq</math> tREFI * 9</li> <li><input type="checkbox"/> Long cal (normal operation) to valid command must be <math>\geq</math> tZQoper</li> <li><input type="checkbox"/> Powerdown and Self Refresh tests</li> <li><input type="checkbox"/> REF command to power down entry <math>\geq</math> tREFPDEN</li> <li><input type="checkbox"/> Read command to power down entry <math>\geq</math> tRDPDEN</li> <li><input type="checkbox"/> Write command to power down entry <math>\geq</math> tWRPDEN</li> <li><input type="checkbox"/> Exit reset from CKE high to valid command <math>\geq</math> tXPR</li> <li><input type="checkbox"/> SelfRefreshExit to Valid command with DLL <math>&lt;</math> tXSDLL</li> <li><input type="checkbox"/> Exit Precharge Power Down with DLL to any valid command <math>&lt;</math> tXPDDL</li> <li><input type="checkbox"/> Calibration Tests</li> <li><input type="checkbox"/> Short cal (normal operation) to valid command must be <math>\geq</math> tZQCS</li> </ul>	<ul style="list-style-type: none"> <li><input type="checkbox"/> ACTIVATE to PRECHARGE/Auto-PRECHARGE must be <math>\leq</math> tRASmax</li> <li><input type="checkbox"/> ACTIVATE to PRECHARGE must be <math>\geq</math> tRASmin</li> <li><input type="checkbox"/> ACTIVATE to READ/WRITE must be <math>\geq</math> tRCD</li> <li><input type="checkbox"/> PRECHARGE to ACTIVATE must be <math>\geq</math> tRP</li> <li><input type="checkbox"/> READ to PRECHARGE must be <math>\geq</math> tRTP</li> <li><input type="checkbox"/> READ to WRITE must be <math>\geq</math> tDRW</li> <li><input type="checkbox"/> WRITE to PRECHARGE must be <math>\geq</math> tDWP</li> <li><input type="checkbox"/> WRITE to READ (different bank group) must be <math>\geq</math> tDWRS</li> <li><input type="checkbox"/> WRITE to READ (same bank group) must be <math>\geq</math> tDWRL</li> <li><input type="checkbox"/> WRITE to WRITE (different bank group), READ to READ (different bank group) must be <math>\geq</math> tCCD</li> <li><input type="checkbox"/> WRITE to WRITE (same bank group), READ to READ (same bank group) must be <math>\geq</math> tCCD</li> <li><input type="checkbox"/> REFRESH to non-NOP/DES must be <math>\geq</math> tRFC</li> <li><input type="checkbox"/> ACTIVATE to ACTIVATE (different bank group) must be <math>\geq</math> tTRDS</li> <li><input type="checkbox"/> ACTIVATE to ACTIVATE (same bank group, different bank addr) must be <math>\geq</math> tTRD</li> <li><input type="checkbox"/> Four ACTIVATE window (different banks) must be <math>\geq</math> tFAW</li> <li><input type="checkbox"/> READ or WRITE to an inactive row</li> <li><input type="checkbox"/> REFRESH to an active bank</li> <li><input type="checkbox"/> ACTIVATE to an active bank</li> <li><input type="checkbox"/> ACTIVATE to ACTIVATE (same bank) must be <math>\geq</math> tRC</li> <li><input type="checkbox"/> Mode Register Set command to Mode Register Set command <math>\geq</math> tMRD</li> <li><input type="checkbox"/> Mode Register Set command to valid command <math>\geq</math> tMOD</li> <li><input type="checkbox"/> Refresh tests</li> <li><input type="checkbox"/> REFRESH cmd to REFRESH cmd must be <math>\leq</math> tREFI * 9</li> <li><input type="checkbox"/> Long cal (normal operation) to valid command must be <math>\geq</math> tZQoper</li> <li><input type="checkbox"/> Powerdown and Self Refresh tests</li> <li><input type="checkbox"/> REF command to power down entry <math>\geq</math> tREFPDEN</li> <li><input type="checkbox"/> Read command to power down entry <math>\geq</math> tRDPDEN</li> <li><input type="checkbox"/> Write command to power down entry <math>\geq</math> tWRPDEN</li> <li><input type="checkbox"/> Exit reset from CKE high to valid command <math>\geq</math> tXPR</li> <li><input type="checkbox"/> SelfRefreshExit to Valid command with DLL <math>&lt;</math> tXSDLL</li> <li><input type="checkbox"/> Exit Precharge Power Down with DLL to any valid command <math>&lt;</math> tXPDDL</li> <li><input type="checkbox"/> Calibration Tests</li> <li><input type="checkbox"/> Short cal (normal operation) to valid command must be <math>\geq</math> tZQCS</li> </ul>

Tests Available With B4661A License (LPDDR Memory Type)

LPDDR1 tests	LPDDR2 tests	LPDDR3 tests
<p><input type="checkbox"/> DDR/LPDDR Tests</p> <ul style="list-style-type: none"> <li><input type="checkbox"/> ACTIVATE to PRECHARGE/Auto-PRECHARGE must be &lt;= tRASmax</li> <li><input type="checkbox"/> ACTIVATE to PRECHARGE must be &gt;= tRASmin</li> <li><input type="checkbox"/> ACTIVATE to READ/WRITE must be &gt;= tRCD</li> <li><input type="checkbox"/> PRECHARGE to ACTIVATE must be &gt;= tRP</li> <li><input type="checkbox"/> READ to PRECHARGE must be &gt;= tRTP</li> <li><input type="checkbox"/> READ to WRITE must be &gt;= tDRW</li> <li><input type="checkbox"/> WRITE to PRECHARGE must be &gt;= tDWP</li> <li><input type="checkbox"/> WRITE to READ must be &gt;= tDWR</li> <li><input type="checkbox"/> WRITE to WRITE, READ to READ must be &gt;= tCCD</li> <li><input type="checkbox"/> REFRESH to non-NOP/DES must be &gt;= tRFC</li> <li><input type="checkbox"/> ACTIVATE to ACTIVATE (different banks) must be &gt;= tRRD</li> <li><input type="checkbox"/> READ or WRITE to an inactive row</li> <li><input type="checkbox"/> REFRESH to an active bank</li> <li><input type="checkbox"/> ACTIVATE to an active bank</li> <li><input type="checkbox"/> ACTIVATE to ACTIVATE (same bank) must be &gt;= tRC</li> <li><input type="checkbox"/> Mode Register Set command to Mode Register Set command &gt;= tMRD</li> <li><input type="checkbox"/> Refresh tests                             <ul style="list-style-type: none"> <li><input type="checkbox"/> REFRESH cmd to REFRESH cmd must be &lt;= tREFI * 9</li> </ul> </li> </ul>	<p><input type="checkbox"/> DDR/LPDDR Tests</p> <ul style="list-style-type: none"> <li><input type="checkbox"/> ACTIVATE to PRECHARGE/Auto-PRECHARGE must be &lt;= tRASmax</li> <li><input type="checkbox"/> ACTIVATE to PRECHARGE must be &gt;= tRASmin</li> <li><input type="checkbox"/> ACTIVATE to READ/WRITE must be &gt;= tRCD</li> <li><input type="checkbox"/> READ to PRECHARGE must be &gt;= tRTP</li> <li><input type="checkbox"/> READ to WRITE must be &gt;= tDRW</li> <li><input type="checkbox"/> WRITE to PRECHARGE must be &gt;= tDWP</li> <li><input type="checkbox"/> WRITE to READ must be &gt;= tDWR</li> <li><input type="checkbox"/> WRITE to WRITE, READ to READ must be &gt;= tCCD</li> <li><input type="checkbox"/> ACTIVATE to ACTIVATE (different banks) must be &gt;= tRRD</li> <li><input type="checkbox"/> Four ACTIVATE window (different banks) must be &gt;= tFAW</li> <li><input type="checkbox"/> READ or WRITE to an inactive row</li> <li><input type="checkbox"/> REFRESH to an active bank</li> <li><input type="checkbox"/> ACTIVATE to an active bank</li> <li><input type="checkbox"/> MRW Long Calibration command to any valid command (or CKE low) must be &gt;= tMRW</li> <li><input type="checkbox"/> MRW Short Calibration command to any valid command (or CKE low) must be &gt;= tMRW</li> <li><input type="checkbox"/> MRW Init Calibration command to any valid command (or CKE low) must be &gt;= tMRW</li> <li><input type="checkbox"/> MRW Reset Calibration command to any valid command (or CKE low) must be &gt;= tMRW</li> <li><input type="checkbox"/> MRW command to any valid command (or CKE low) must be &gt;= tMRW</li> <li><input type="checkbox"/> MRR command to any valid command (or CKE low) must be &gt;= tMRD</li> <li><input type="checkbox"/> PRECHARGE (all banks) to ACTIVATE/REFRESH must be &gt;= tRPab</li> <li><input type="checkbox"/> PRECHARGE (per bank) to ACTIVATE/REFRESH must be &gt;= tRPpb</li> <li><input type="checkbox"/> Duration of CKE high/low &gt;= tCKE</li> <li><input type="checkbox"/> Duration of self-refresh &gt;= tCKESR</li> <li><input type="checkbox"/> Duration of deep power down &gt;= tDPPD</li> <li><input type="checkbox"/> Refresh tests                             <ul style="list-style-type: none"> <li><input type="checkbox"/> Greater than 8 REFRESH all bank commands in tREFBW</li> <li><input type="checkbox"/> Required number of refresh commands occur in time period &lt;= tREFW</li> <li><input type="checkbox"/> Refresh (all banks) to Activate or Refresh must be &gt;= tRFCab</li> <li><input type="checkbox"/> Refresh (per bank) to Activate (same bank) or Refresh must be &gt;= tRFCpb</li> </ul> </li> <li><input type="checkbox"/> Powerdown and Self Refresh tests                             <ul style="list-style-type: none"> <li><input type="checkbox"/> Exit self-refresh to valid command &gt;= tXSR</li> <li><input type="checkbox"/> Exit power down to valid command &gt;= tXPD</li> </ul> </li> </ul>	<p><input type="checkbox"/> DDR/LPDDR Tests</p> <ul style="list-style-type: none"> <li><input type="checkbox"/> ACTIVATE to PRECHARGE/Auto-PRECHARGE must be &lt;= tRASmax</li> <li><input type="checkbox"/> ACTIVATE to PRECHARGE must be &gt;= tRASmin</li> <li><input type="checkbox"/> ACTIVATE to READ/WRITE must be &gt;= tRCD</li> <li><input type="checkbox"/> READ to PRECHARGE must be &gt;= tRTP</li> <li><input type="checkbox"/> READ to WRITE must be &gt;= tDRW</li> <li><input type="checkbox"/> WRITE to PRECHARGE must be &gt;= tDWP</li> <li><input type="checkbox"/> WRITE to READ must be &gt;= tDWR</li> <li><input type="checkbox"/> WRITE to WRITE, READ to READ must be &gt;= tCCD</li> <li><input type="checkbox"/> ACTIVATE to ACTIVATE (different banks) must be &gt;= tRRD</li> <li><input type="checkbox"/> Four ACTIVATE window (different banks) must be &gt;= tFAW</li> <li><input type="checkbox"/> READ or WRITE to an inactive row</li> <li><input type="checkbox"/> REFRESH to an active bank</li> <li><input type="checkbox"/> ACTIVATE to an active bank</li> <li><input type="checkbox"/> MRW Long Calibration command to any valid command (or CKE low) must be &gt;= tMRW</li> <li><input type="checkbox"/> MRW Short Calibration command to any valid command (or CKE low) must be &gt;= tMRW</li> <li><input type="checkbox"/> MRW Init Calibration command to any valid command (or CKE low) must be &gt;= tMRW</li> <li><input type="checkbox"/> MRW Reset Calibration command to any valid command (or CKE low) must be &gt;= tMRW</li> <li><input type="checkbox"/> MRW command to any valid command (or CKE low) must be &gt;= tMRW</li> <li><input type="checkbox"/> MRR command to any valid command (or CKE low) must be &gt;= tMRD</li> <li><input type="checkbox"/> PRECHARGE (all banks) to ACTIVATE/REFRESH must be &gt;= tRPab</li> <li><input type="checkbox"/> PRECHARGE (per bank) to ACTIVATE/REFRESH must be &gt;= tRPpb</li> <li><input type="checkbox"/> Duration of CKE high/low &gt;= tCKE</li> <li><input type="checkbox"/> Duration of self-refresh &gt;= tCKESR</li> <li><input type="checkbox"/> Duration of deep power down &gt;= tDPPD</li> <li><input type="checkbox"/> Refresh tests                             <ul style="list-style-type: none"> <li><input type="checkbox"/> Greater than 8 REFRESH all bank commands in tREFBW</li> <li><input type="checkbox"/> Required number of refresh commands occur in time period &lt;= tREFW</li> <li><input type="checkbox"/> Refresh (all banks) to Activate or Refresh must be &gt;= tRFCab</li> <li><input type="checkbox"/> Refresh (per bank) to Activate (same bank) or Refresh must be &gt;= tRFCpb</li> </ul> </li> <li><input type="checkbox"/> Powerdown and Self Refresh tests                             <ul style="list-style-type: none"> <li><input type="checkbox"/> Exit self-refresh to valid command &gt;= tXSR</li> <li><input type="checkbox"/> Exit power down to valid command &gt;= tXPD</li> </ul> </li> </ul>

Some things to consider while selecting tests:

- Some tests might not make sense for your system. Do not select those tests.
- Checking a parent node/group will check all available sub-groups/tests.
- Unchecking a parent node/group will uncheck all sub-groups/tests.
- A parent node is checked if all subgroups are checked.
- A parent node is unchecked if ANY subgroup is unchecked.

When Tests Have Already Been Run

Set Up	Select Tests	Configure	Run	Automate	Results	HTML Report
	<input type="checkbox"/> Four ACTIVATE window (different banks) must be >= tFAW <input checked="" type="checkbox"/> READ or WRITE to an inactive row <input checked="" type="checkbox"/> REFRESH to an active bank <input type="checkbox"/> ACTIVATE to an active bank					

The marks have the following meanings:


Marks	Meanings
✓	The test passed.
✗	The test failed.
○	The test has not been run, or no tests in the group have been run.
⏸	The test is currently running.
⦿	Some tests in the group have run and passed.
⦿	Some tests in the group have run and failed.
⦿	Some tests in the group have passed and some have failed; not all of the tests have run.
●	All tests in the group have run and passed.
●	All tests in the group have run and failed.

- See Also
- ["To set the test limits"](#) on page 20 (for information on how to calculate the limits)
  - ["About the Tool"](#) on page 11 (for an overview of the tests performed)
- Next
- ["Configuring Tests"](#) on page 19

## 6 Running Tests

You can use the **Run** tab to specify how the tests should be run and then run the tests as per these settings.

You can run the tests once or repetitively.



To run the selected tests:

- 1 Click the **Run** tab.
- 2 Configure the settings for running the tests.
  - a From the **Store Mode** section, select which trial results from the test run(s) you want to store. You can store results for a maximum of 25 trials.
  - b From the **Run Until** section, select the number of times you want to run the tests. Following options are available:
    - Once - The tests are run once.

- N Times- The tests are run repetitively for the number of times specified in the Number of Runs field.
- Forever- The tests are run repetitively until you press the Stop button.


If you select **N Times** or **Forever**, make sure you select the **Automatically acquire new logic analyzer data when running tests** checkbox in the **Set Up** tab.

- On selecting the **N Times** option, the **Pause in between** checkbox is displayed. Select this checkbox to instruct the tool to pause the test run after the completion of each run in the repetitive run.
- Select the **Send email when run is paused or stopped** checkbox in the **Email** section to instruct the tool to send a notification email with the information about the test run when the test run completes or pauses. You can specify the SMTP Server and the email address to which email should be sent in the designated place when this checkbox is selected. You can also specify the sender's email address.
- In the **Event** section, select the **Detect Event** checkbox to instruct the tool to perform a specified action when the specified event is detected in the test run. On selecting this checkbox, a listbox is displayed with this checkbox. From this listbox, you can select either Pause or Stop to pause or stop the test run when the selected event is detected during a test run.
- When you select Event in the **Store Mode** section or select the **Detect Event** checkbox, the **When detect:** listbox is displayed to allow you to select the event. When the selected event occurs in the test run, the specified action is performed if the **Detect Event** checkbox is selected or the details for the event are stored if the **Store Mode** is set to **Event**. You can select from the following events:
  - Pass - Perform the event action or store the event details when a test passes.
  - Fail - Perform the event action or store the event details when a test fails.
  - Margin < N - Perform the event action or store the event details when a test result margin is less than the specified minimum required margin percentage.


At times, you may receive warning messages when the selected event does not logically matches with the selected Store Mode. For instance, if the **Store Mode** is **Best**, then you can only use **Pass** as the event. Similarly, if the store mode is **Worst**, you cannot use **Pass** as the event. The tool automatically corrects the event selection in such cases.

While you select the test configurations, the tool automatically keeps documenting the test configurations for your reference in the open listbox in this tab. The **Message** tab displays the list of actions and any warnings if generated.

- Run the tests. There are several ways to run the selected tests:
  - Click  in the toolbar. to run all the selected tests.
  - Select a branch in the Select Tests tab and then click  in the toolbar to repeatedly run only the tests of the selected branch.
  - Click the big **Run** button in the Run tab.
- If there are existing test results, you are asked if you would like to keep them or re-test (delete) them.  
If you would like to keep the existing test results to compare against new results, click **Append**. Click **Replace** if you would like to delete the existing test results.



5 While the tests are running, status dialogs appear to inform you about the test progress.



When the tests are complete, Results tab is automatically displayed.


See Also · ["To set the display preferences"](#) on page 36

Next · ["Viewing Results"](#) on page 41

## To set the display preferences

Information, warning, and error conditions can occur while running tests. The display preferences let you choose whether message dialogs are shown. And, there are other display preferences that affect what happens as tests are run.

- 1 From the DDR/LPDDR Post Process Compliance Tool's menu, choose **View > Preferences....**
- 2 In the Preferences dialog, select the **Display** tab.



- 3 In the Display tab, you can choose to show the following types of message prompts:
  - Information prompts.
  - Warning prompts.
  - Error prompts.

### NOTE

Messages that require you to make a choice, such as "OK/Cancel" and "Yes/No" are always enabled.

- 4 Also, you can choose to:
  - **Change the Color Scheme**— Choose a background color from Midnight and Platinum options.
  - **Keep application on top** — Always keep the application's main dialog on the top of the logic analyzer application. Note that the mid-run dialogs are always displayed on the top.
  - **Show tooltips** — By enabling this option, the tooltips appear as you move the pointer over various controls in the application.
- 5 Click **Apply** to save the changes and click **OK** to close the Preferences dialog.


## 7 Automating the Tests

In the **Automate** tab, you can automate the required tests by selecting either of the following options from the **Execute commands from** section:

- Scripts
- Files

### Prerequisites

- 1 Click **Settings**. The Automation Settings window appears.




- 2 Check and change (if required) the appropriate settings and click **Close**.

## Automation by Scripts

Perform the following steps to automate the tests by scripts:

- 1 Write the automation programs/commands in the top pane.




- 2 Click **Save As...** to save the automation script on your local system.
- 3 Click **Start**.

## Automation by Files

Perform the following steps to automate the tests by files:

- 1 Click **Add...** to load the required file. The loaded file is displayed in the upper pane.



- 2 Click **Start**.



# 8 Viewing Results

- 1 Click the **Results** tab.

DDR/LPDDR Post Process Compliance Tool -- DDR Device 1

File View Help

Set Up | Select Tests | Configure | Run | Automate | **Results** | HTML Report

Test Name	Actual Value	Margin	Pass Limits	# Trials
ACTIVATE to PRECHARGE/Auto-PRECHARGE must be $\leq$ tRASmax	Pass	103E+01	VALUE $\leq$ 70.200 $\mu$ s	1
ACTIVATE to PRECHARGE must be $\geq$ tRASmin	Pass	4.8	VALUE $\geq$ 34.96 ns	1
ACTIVATE to READ/WRITE must be $\geq$ tRCD	Fail	-75.4	VALUE $\geq$ 13.68 ns	1
PRECHARGE to ACTIVATE must be $\geq$ tRP	Fail	-76.0	VALUE $\geq$ 13.68 ns	1
READ to PRECHARGE must be $\geq$ tRTP	Fail	-55.9	max(7.5ns, 4CK)	1
READ to WRITE must be $\geq$ tDRW	Pass	155.6	RL + BL/2 + 2tCK - WL	1
WRITE to PRECHARGE must be $\geq$ tDWP	Fail	-23.8	WL + BL/2 + tWR	1

**RESULTS**

Parameter	Value
tRCD	Fail
---Additional Info---	
Acquisition Time	Triggered on 11/16/2015 at 10:42:43 AM
Number of tests	7673
Number of failures	39
Number of failures listed	20
<a href="#">Mark all failures listed</a>	
<a href="#">Mark and jump to worst case failure listed</a>	
<a href="#">Edit limit value</a>	
State Pair	
Margin/Time/Clocks/Clock_Frequency	
-----	
302_316	-14.6%, 11.7 ns, 7 CK, 595.2 MHz
302_318	-2.3%, 13.4 ns, 8 CK, 595.2 MHz
3442_3458	-2.3%, 13.4 ns, 8 CK, 595.2 MHz
8442_8458	-2.3%, 13.4 ns, 8 CK, 595.2 MHz

**Messages**

2015-11-17 10:12:17:711 AM Run ended  
 2015-11-17 10:24:54:086 AM Info  
 2015-11-17 10:25:47:292 AM Error  
 2015-11-17 10:28:11:150 AM Discard Unsaved Changes?

Unsaved changes exist. Click OK to discard them and close; click Cancel to k open  
 [Response: OK (OKCancel)]

(BETA VERSION 0.00.5793) Unsaved Changes 7 Tests **FAIL**

The Results tab contains three re-sizable panes for test results information. If you select one of the tests in the top pane, details and reference images (if any) are shown in the lower panes.

**TIP**

A quick way to reset all configuration options and delete all test results is to create a new project (see page 53). The new project will have default configuration options.

For each individual test that you selected to run, the tool reports the total number of failures that occurred for that specific test. It can show up to a maximum of *250 failures* in the Details screen for an individual test.

Each limit is measured as the time between two states. Each logic analyzer state has a number and a timestamp. In case of a failure, the numbers of the two states will be reported. Note that the time stamps are only as good as the time stamp resolution of the logic analyzer card being used (this resolution may be as coarse as 2ns; see the Specifications and Characteristics in the logic analyzer's Online help for details).

If a test case is not encountered in the logic analyzer trace:

- In the details for the test, the number of tests will be 0.
- For limit tests, the "Actual Value" column will display "N/A."
- For pass/fail tests, the "Actual Value" column will display "Pass."

See Also • ["To change margin thresholds"](#) on page 43

Next • ["Viewing/Exporting/Printing the Report"](#) on page 45

To change margin thresholds

- 1 From the DDR/LPDDR Post Process Compliance Tool's menu, choose **View>Preferences...**
- 2 In the Preferences dialog, select the **Results** tab.



- 3 In the **Margin Reporting** area, you can:
  - Enable or disable margin highlighting.
  - You can change the percent of margin at which to give warnings or critical failures.
- 4 Click **OK** to close the Preferences dialog.

## NOTE

The DDR/LPDDR Post Process Compliance Tool runs the tests one time, so the Trial display options do not apply.

You can set the display order of test result in **Test Display** section.



# 9 Viewing/Exporting/Printing the Report

- To view the HTML test report, click the **HTML Report** tab.

DDR/LPDDR Post Process Compliance Tool -- DDR Device 1

File View Help

Set Up Select Tests Configure Run Automate Results **HTML Report**

**KEYSIGHT TECHNOLOGIES**

## DDR/LPDDR Test Report

Overall Result: **FAIL**

Test Configuration Details	
Test Session Details	
Application SW Version	0.00.5793
Debug Mode Used	No
Compliance Limits (official)	DDR3 1333 Limits Set
Last Test Date	2015-11-17 10:12:17 UTC +05:30

### Summary of Results

Test Statistics	
Failed	4
Passed	3
Total	7

Margin Thresholds	
Warning	< 2 %
Critical	< 0 %

Pass	# Failed	# Trials	Test Name	Actual Value	Margin	Pass Limits
✓	0	1	ACTIVATE to PRECHARGE/Auto-PRECHARGE must be <= tRASmax	Pass	103E+01 %	VALUE <= 70.200 μs
✓	0	1	ACTIVATE to PRECHARGE must be >= tRASmin	Pass	4.8 %	VALUE >= 34.96 ns
✗	1	1	ACTIVATE to READ/WRITE must be >= tRCD	Fail	-75.4 %	VALUE >= 13.68 ns
✗	1	1	PRECHARGE to ACTIVATE must be >= tRP	Fail	-76.0 %	VALUE >= 13.68 ns
✗	1	1	READ to PRECHARGE must be >= tRTP	Fail	-55.9 %	max(7.5ns, 4CK)

Messages

2015-11-17 10:24:54:086 AM Info  
 2015-11-17 10:25:47:292 AM Error  
 2015-11-17 10:28:11:150 AM Discard Unsaved Changes?  
 2015-11-17 10:29:51:404 AM Discard Unsaved Changes?

Unsaved changes exist. Click OK to discard them and close; click Cancel to k  
 open  
 [Response: OK (OKCancel)]

(BETA VERSION 0.00.5793) Unsaved Changes 7 Tests **FAIL**

Clicking on any tests under Test Name section displays the details of the particular test result.

DDR/LPDDR Post Process Compliance Tool -- DDR Device 1

File View Help

Set Up Select Tests Configure Run Automate Results **HTML Report**

Next

✓ **ACTIVATE to PRECHARGE must be  $\geq$  tRASmin** Reference: JESD79-3F (JE

Test Summary: **Pass** Test Description: Test time between activate to precharge must be greater than or equal to tRASmin

Pass Limits: Pass/Fail **tRASmin Pass**

**Result Details**

Acquisition Time Triggered on 11/16/2015 at 10:42:43 AM Number of tests 4303 Number of failures 0 Closest Margin State Pair Margin/Time/Clocks/Clock\_Frequency

38864 38908 4.8%, 36.6 ns, 22 CK, 595.2 MHz

Top Previous

Next

✗ **ACTIVATE to READWRITE must be  $\geq$  tRCD** Reference: JESD79-3F (JE

Test Summary: **FAIL** Test Description: Test time between activate to read or write must be greater than or equal to tRCD

Pass Limits: Pass/Fail **tRCD Fail**

**Result Details**

Acquisition Time Triggered on 11/16/2015 at 10:42:43 AM Number of tests 7673 Number of failures 39 Number of failures listed 20 State Pair Margin/Time/Clocks/Clock\_Fre

302 316	-14.6%, 11.7 ns, 7 CK, 595.2 MHz	302 318	-2.3%, 13.4 ns, 8 CK, 595.2 MHz	3442 3458	-2.3%, 13.4 ns, 8 CK, 595.2 MHz	8442 8458	-2.3%, 13.4 ns
9300 9312	-26.9%, 10.0 ns, 6 CK, 595.2 MHz	10322 10338	-2.3%, 13.4 ns, 8 CK, 595.2 MHz	12310 12326	-2.3%, 13.4 ns, 8 CK, 595.2 MHz	12550 12566	-2.3%, 13.4 ns, 8 CK, 595.2 MHz
18750 18764	-14.6%, 11.7 ns, 7 CK, 595.2 MHz	18750 18766	-2.3%, 13.4 ns, 8 CK, 595.2 MHz	20946 20962	-2.3%, 13.4 ns, 8 CK, 595.2 MHz	22360 22364	-75.4%, 3.4 ns, 2 CK, 595.2 MHz
22360 22368	-50.9%, 6.7 ns, 4 CK, 595.2 MHz	22360 22376	-2.3%, 13.4 ns, 8 CK, 595.2 MHz	27146 27160	-15.2%, 11.6 ns, 7 CK, 595.2 MHz	27146 27162	-2.9%, 13.3 ns, 8 CK, 595.2 MHz
30008 30024	-2.3%, 13.4 ns, 8 CK, 595.2 MHz	31654 31666	-26.9%, 10.0 ns, 6 CK, 595.2 MHz	31654 31668	-14.6%, 11.7 ns, 7 CK, 595.2 MHz	33026 33038	-27.5%, 9.9 ns, 6 CK, 595.2 MHz

Top Previous

Next

✗ **PRECHARGE to ACTIVATE must be  $\geq$  tRP** Reference: JESD79-3F (JE

Test Summary: **FAIL** Test Description: Test time between precharge to activate must be greater than or equal to tRP

Pass Limits: Pass/Fail **tRP Fail**

**Result Details**

Acquisition Time Triggered on 11/16/2015 at 10:42:43 AM Number of tests 2520 Number of failures 198 Number of failures listed 20 State Pair Margin/Time/Clocks/Clock\_Fr

588 600	-26.9%, 10.0 ns, 6 CK, 595.2 MHz	658 674	-2.3%, 13.4 ns, 8 CK, 595.2 MHz	722 738	-2.9%, 13.3 ns, 8 CK, 595.2 MHz	838 854	-2.3%, 13.4 ns, 8 CK
---------	----------------------------------	---------	---------------------------------	---------	---------------------------------	---------	----------------------

Messages

2015-11-17 09:36:15:341 AM Ready ^ Unsaved changes exist. Click OK to discard them and close; click Cancel to keep the dialog [Response: OK (OKCancel)]

2015-11-17 09:36:36:637 AM Run started v

(BETA VERSION 0.00.5793) Unsaved Changes 7 Tests **FAIL**


- See Also
- "To export the report" on page 47
  - "To print the report" on page 49
- Next
- "Saving Test Projects" on page 51

To export the report

- 1 From the DDR/LPDDR Post Process Compliance Tool's menu, choose **File > Export Results**.  
There are two options for exporting the HTML test report: CSV or HTML.

To export results in  
CSV  
(comma-separated  
values) format


Select the CSV option to export the results as a comma-separated list of values.



The data format is shown in the first line of the exported \*.csv file.


```
Test ID, Test Name, Measured Item, Trial 1 Value
100,"ACTIVATE to PRECHARGE/Auto-PRECHARGE must be < tRASmax",Number of tests ,"9"
100,"ACTIVATE to PRECHARGE/Auto-PRECHARGE must be < tRASmax",Number of failures ,"0"
100,"ACTIVATE to PRECHARGE/Auto-PRECHARGE must be < tRASmax",Actual Value ,"4.92E-05"
100,"ACTIVATE to PRECHARGE/Auto-PRECHARGE must be < tRASmax",Margin,"29.9"
```

To export the  
report in HTML  
format



There are two options for exporting HTML format test reports:

- **Single-File** – To save a single-file report, use the “save as” type “Web Archive, single file (.mt)”.



**NOTE**

Single-file reports will not contain hyper-links in the summary table (due to a .mht format limitation). If you want these hyper-links, use the multi-file format.

- **Multi-File** – If your report is large and you would like to use links within the report, select the **HTML>Multi-File** option. Selecting the multi-file option exports the results as a set of separate image and HTML files. It creates a folder with the specified name that may be copied to any computer.  
To view the exported report, open the HTML file stored in the folder.

## To print the report

- To preview the HTML test report printout, choose **File>Print Preview...** from the menu.
- To print the HTML test report, choose **File>Print...** from the menu.



# 10 Saving Test Projects

To save test settings and results to the current project directory:

- 1 Choose **File>Save Project** from the menu.


To save test settings and results to a new project directory:

- 1 Choose **File>Save Project As...** from the menu.
- 2 In the Save Project As... dialog, enter the device name and location.  
Project files will be saved in a directory whose name is the device name.
- 3 Click **OK**.

See Also · ["To set AutoRecovery preferences"](#) on page 52

To set AutoRecovery preferences

- 1 From the DDR/LPDDR Post Process Compliance Tool's menu, choose **View>Preferences...**
- 2 In the Preferences dialog, select the **Save/Load** tab.



- 3 In the **AutoRecovery/HTML Report Update** section, you can choose:
  - To auto-save results after each trial or permutation even if the entire multi-trial is not completed. This option enables full recovery.
  - To auto-save results only upon the completion of the entire multi-trial.
- 4 Click **Apply** to save the changes and click **OK** to close the Preferences dialog.

# 11 Creating or Opening a Test Project

To create a new test project:

- 1 Choose **File>New Project...** from the menu.  
A new, empty project, with all the default settings is created.

To open an existing test project:


- 1 Choose **File>Open Project...** from the menu.
- 2 In the Open dialog, browse to a test project directory and select the desired ".proj" file.
- 3 Click **Open**.

See Also · ["To set load preferences"](#) on page 54

Next · ["Setting Up the Test Environment"](#) on page 27

To set load preferences

- 1 From the DDR/LPDDR Post Process Compliance Tool's menu, choose **View>Preferences...**
- 2 In the Preferences dialog, select the **Save/Load** tab.



- 3 In the **Save/Load** tab, you can choose to restore saved test selections when loading a project.
- 4 Click **Apply** to save the changes and click **OK** to close the Preferences dialog.

# Index

## A

about, 11  
activate limit set, 25  
ASR, 11  
Automate, 37  
AutoRecovery preferences, 52

## C

clock speed, 27  
comma-separated value (CSV) format,  
  export results, 47  
configuring tests, 19  
create limit set, 24  
creating test project, 53  
critical at percent of margin, 43  
CSV (comma-separated value) format,  
  export results, 47  
CTC commands, 27

## D

display preferences, 36

## E

edit limit set, 24  
enable margin reporting, 43  
error dialogs, 36  
exporting the report, 47

## H

HTML format, export results, 47  
HTML test report,  
  viewing/exporting/printing, 45

## I

information dialogs, 36  
invert scope display, 36

## K

keep application on top, 36

## L

limit set, activate/refresh, 25  
limit set, create/edit, 24

limit set, restore, 24  
limitations, 11  
load preferences, 54

## M

margin thresholds, changing, 43  
multi-file HTML, export results, 48

## O

on-the-fly burst length, 11  
opening test project, 53

## P

PASR, 11  
preferences, display, 36  
preferences, report, 43  
preferences, save/load, 52, 54  
preview print, 49  
printing HTML test report, 49  
project, creating or opening, 53  
project, saving, 51

## R

refresh limit set, 25  
report (HTML),  
  viewing/exporting/printing, 45  
report preferences, 43  
report, exporting, 47  
report, printing, 49  
results, viewing test, 41  
running tests, 33

## S

save/load preferences, 52, 54  
saving test project, 51  
selecting tests, 29  
self refresh, 11  
set up, 27  
show tooltips, 36  
single-file HTML, export results, 47  
starting DDR post process compliance  
  tool, 15

## T

test project, creating or opening, 53

test project, saving, 51  
test report (HTML),  
  viewing/exporting/printing, 45  
tests, configuring, 19  
tests, running, 33  
tests, selecting, 29  
tests, viewing results, 41  
toolbar, viewing/hiding, 17  
tooltips, show, 36

## U

unavailable tests, 29

## V

viewing HTML test report, 45  
viewing test results, 41

## W

warn at percent of margin, 43  
warning dialogs, 36





