# **E5080A Security Feature** Rev. 1.0

June 2015 Copyright 2015 Keysight Technologies

## **Contacting Keysight Sales and Service Offices**

Assistance with test and measurements needs and information on finding local Keysight offices are available on the internet at, <a href="http://www.keysight.com/find/assist">http://www.keysight.com/find/assist</a>. If you do not have access to the internet, please contact your field engineer.

Note: In any correspondence or telephone conversations, refer to the signal generator by its model number and full serial number. With this information, the Keysight representative can determine whether your unit is still within its warranty period.

## **Product Declassification and Security**

Model Number(s): E5080A Product Name: Network Analyzer

Product Family Name: Network Analyzer

This document describes instrument security features and the steps to declassify an instrument through memory sanitization or removal.

#### **Table of Contents**

Terms and Definitions.	4
Instrument Memory	5
Memory Clearing, Sanitization and/or Removal	6
User and Remote Interface Security	10

#### **Terms and Definitions**

#### **Definitions:**

Clearing – Clearing is the process of eradicating the data on media before reusing the media so that the data can no longer be retrieved using the standard interfaces on the instrument. Clearing is typically used when the instrument is to remain in an environment with an acceptable level of protection.

Sanitization — Sanitization is the process of removing or eradicating stored data so that the data cannot be recovered using any known technology. Instrument sanitization is typically required when an instrument is moved from a secure to a non-secure environment such as when it is returned to the factory for calibration. Keysight memory sanitization procedures are designed for customers who need to meet the requirements specified by the US Defense Security Service (DSS). These requirements are outlined in the "Clearing and Sanitization Matrix" issued by the Cognizant Security Agency (CSA) and referenced in National Industrial Security Program Operating Manual (NISPOM) DoD 5220.22M ISL 01L-1 section 8-301.

Security erase – Security erase is a term that is used to refer to either the clearing or sanitization features of Keysight instruments.

Instrument declassification — A term that refers to procedures that must be undertaken before an instrument can be removed from a secure environment such as is the case when the instrument is returned for calibration. Declassification procedures will include memory sanitization and/or memory removal. Keysight declassification procedures are designed to meet the requirements specified by the DSS NISPOM security document (DoD 5220.22M chapter 8)

## **Instrument Memory**

This section contains information on the types of memory available in your instrument. It explains the size of memory, how it is used, its location, volatility, and the sanitization procedure.

Summary of instrument memory - base instrument

			nemory - base instru	31110111		
Memory Type and Size	Writable During Normal Operation?	Data Retained When Powered Off?	Purpose/Contents	Data Input Method	Location in Instrument and Remarks	Sanitization Procedure
Main Memory	Yes	No	Windows Operating system memory,	Operating system (not user defined)	CPU Module	Cycle power
Memory for product information	No	Yes	Product number, serial number, options	Product number, serial number is stored at factory. Option is installed by Keysight License Manager	CPU Module	N/A (The data is not stored by user under normal operation.)
Media Storage	Yes	Yes	Windows Operating system boot device, factory correction data, and users file including saved traces data, settings, or images.	User-Saved Data Operating system (not user defined)	SSD assembly	Remove
Memory for DSP module (RAM)	Yes	Yes	Data Processing for measurement	Measurement (not user defined)	A51 DSP Module	Cycle power
Non-volatile Memory (Flash)	No	Yes	System calibration data (not user defined calibration data)	Adjustment Program performed by Keysight factory personnel or by calibration labs	A51 DSP Module	N/A (The data is not stored by user under normal operation.)
Non-volatile Memory	No	Yes	Module serial number, Revision number	Calibration at factory	Receiver and Synthesizer modules	N/A (The data is not stored by user under normal operation.)

## Memory Clearing, Sanitization and/or Removal Procedures

This section explains how to clear, sanitize, and remove memory from your instrument for all memory types.

#### <Memory type>

Description and	Main Memory for Windows Operating system memory
purpose	
Size	8 GB
Memory clearing	Power rebooting. This is a volatile memory.
Memory sanitization	Power rebooting. This is a volatile memory.
Memory removal	This memory cannot be removed without damaging the instrument
Write protecting	N/A
Memory validation	N/A
Remarks	

Description and	Memory for Product Information.
purpose	
Size	512 kbit
Memory clearing	Software option can be removed by Keysight License Manager. Other
	information cannot be removed by user.
Memory sanitization	N/A
Memory removal	This memory cannot be removed without damaging the instrument
Write protecting	N/A
Memory validation	N/A
Remarks	

Description and	Media Storage (Solid State Drive)
purpose	
Size	80 GB
Memory clearing	N/A
Memory sanitization	N/A
Memory removal	The storage drive needs to be removed and replaced with a new or unused hard
	disk drive part as per the service manual.
Write protecting	N/A
Memory validation	N/A
Remarks	

Description and	Memory for DSP (RAM) for A51 DSP Module
purpose	
Size	1.8M bit
Memory clearing	Power rebooting. This is a volatile memory.
Memory sanitization	Power rebooting. This is a volatile memory.
Memory removal	This memory cannot be removed without damaging the instrument.
Write protecting	N/A
Memory validation	N/A
Remarks	

Description and	Non-volatile memory (Flash) for A51 DSP Module. This memory is for product
purpose	serial number.
Size	64 MB
Memory clearing	N/A

Memory sanitization	N/A
Memory removal	The A51 DSP module needs to be removed and replaced with a new or unused
	module.
Write protecting	N/A
Memory validation	N/A
Remarks	

Description and purpose	Non-volatile memory (EEPROM) for These memories are for board serial number, board revision number. (Any user data is not stored in these memories)
Size	256 kBit
Memory clearing	N/A
Memory sanitization	N/A
Memory removal	
Write protecting	N/A
Memory validation	N/A
Remarks	

### User and Remote Interface Security Measures

#### Screen and Annotation Blanking

The frequency-blanking feature is available. This function provides three security levels:

The operator can perform the following keystrokes to control this frequency-blanking feature, [System] > Main tab > Security > None | Low | High | Extra

or set the levels by the following SCPI command:

:SYSTem:SECurity:LEVel {NONE|LOW|HIGH|EXTRa}

<sup>&</sup>quot;OFF" during normal operation;

<sup>&</sup>quot;Low" deletes frequency information from the display, but can be turned "OFF" by front panel operation;

<sup>&</sup>quot;High" deletes frequency information from the display, and cannot be turned "OFF" except rebooting.

<sup>&</sup>quot;Extra" deletes frequency information from the display and will not be saved to ASCII file types. Only Preset or recall of instrument state can re-enable display of frequencies.