



# **Agilent U2300A Series Multifunction USB Data Acquisition**

## **Programming Guide**



**Agilent Technologies**

# Notices

© Agilent Technologies, Inc., 2006, 2008

No part of this manual may be reproduced in any form or by any means (including electronic storage and retrieval or translation into a foreign language) without prior agreement and written consent from Agilent Technologies, Inc. as governed by United States and international copyright laws.

## Manual Part Number

U2351-90202

## Edition

Third Edition, March 15, 2008

Printed in Malaysia

Agilent Technologies, Inc.  
Bayan Lepas Free Industrial Zone,  
11900 Penang, Malaysia

## Warranty

**The material contained in this document is provided “as is,” and is subject to being changed, without notice, in future editions. Further, to the maximum extent permitted by applicable law, Agilent disclaims all warranties, either express or implied, with regard to this manual and any information contained herein, including but not limited to the implied warranties of merchantability and fitness for a particular purpose. Agilent shall not be liable for errors or for incidental or consequential damages in connection with the furnishing, use, or performance of this document or of any information contained herein. Should Agilent and the user have a separate written agreement with warranty terms covering the material in this document that conflict with these terms, the warranty terms in the separate agreement shall control.**

## Technology Licenses

The hardware and/or software described in this document are furnished under a license and may be used or copied only in accordance with the terms of such license.

## Restricted Rights Legend

U.S. Government Restricted Rights. Software and technical data rights granted to the federal government include only those rights customarily provided to end user customers. Agilent provides this customary commercial license in Software and technical data pursuant to FAR 12.211 (Technical Data) and 12.212 (Computer Software) and, for the Department of Defense, DFARS 252.227-7015 (Technical Data - Commercial Items) and DFARS 227.7202-3 (Rights in Commercial Computer Software or Computer Software Documentation).

## Safety Notices

### CAUTION

A **CAUTION** notice denotes a hazard. It calls attention to an operating procedure, practice, or the like that, if not correctly performed or adhered to, could result in damage to the product or loss of important data. Do not proceed beyond a **CAUTION** notice until the indicated conditions are fully understood and met.

---

### WARNING

A **WARNING** notice denotes a hazard. It calls attention to an operating procedure, practice, or the like that, if not correctly performed or adhered to, could result in personal injury or death. Do not proceed beyond a **WARNING** notice until the indicated conditions are fully understood and met.

---

# Content

<b>1</b>	<b>Introduction to Programming</b>	<b>1</b>
	Syntax Conventions	3
	Command Separators	4
	Using the MIN and MAX Parameters	4
	Querying Parameter Settings	5
	SCPI Command Terminators	5
	IEEE-488.2 Common Commands	5
	SCPI Parameter Types	6
	Numeric Parameters	6
	Discrete Parameters	6
	Boolean Parameters	7
	ASCII String Parameters	7
	Channel List Parameters	7
	Using Device Clear	9
<b>2</b>	<b>ACQUIRE Subsystem</b>	<b>11</b>
	ACQUIRE:SRATE	12
	ACQUIRE:POINtS	13
	ACQUIRE:BURSt	14
<b>3</b>	<b>APPLY Subsystem</b>	<b>15</b>
	APPLY?	16
	APPLY:SINusoid	17
	APPLY:SQUare	18
	APPLY:SAWTooth	19
	APPLY:TRIangle	20
	APPLY:NOISe	21
	APPLY:USER	22

<b>4</b>	<b>CALibration Subsystem</b>	<b>23</b>
	CALibration:BEgin	24
<b>5</b>	<b>CONFigure Subsystem</b>	<b>25</b>
	CONFigure Subsystem Introduction	26
	CONFigure:DIgital:DIRection	27
	CONFigure:TIMEbase:SOURce	28
	CONFigure:TIMEbase:ECLock	29
	CONFigure:SSI	30
<b>6</b>	<b>IEEE-488 Common Command</b>	<b>33</b>
	*CLS	34
	*ESE	35
	*ESR?	38
	*IDN?	39
	*OPC?	40
	*RCL	41
	*RST	42
	*SAV	43
	*SRE	46
	*STB?	48
	*TST?	50
	*WAI	51
<b>7</b>	<b>MEASure Subsystem</b>	<b>53</b>
	MEASure[:VOLTage][:DC]?	54
	MEASure:COUNter:DATA?	55
	MEASure:COUNter:FREQuency?	56
	MEASure:COUNter:PERiod?	57
	MEASure:COUNter:PWIDth?	58
	MEASure:COUNter:TOTALize?	59
	MEASure:DIgital?	60
	MEASure:DIgital:BIT?	61

<b>8</b>	<b>OUTPut Subsystem</b>	<b>63</b>
	OUTPut	64
	OUTPut:WAVeform:ITERate	65
	OUTPut:WAVeform:SRATe	66
	OUTPut:WAVeform:FREQuency	67
	OUTPut:TRIGger:SOURce	68
	OUTPut:TRIGger:TYPe	69
	OUTPut:TRIGger:DCouNT	70
	OUTPut:TRIGger:ATRIgger:SOURce	71
	OUTPut:TRIGger:ATRIgger:HTHReshold	72
	OUTPut:TRIGger:ATRIgger:LTHReshold	73
	OUTPut:TRIGger:ATRIgger:CONDition	74
	OUTPut:DTRIGger:POLarity	75
<b>9</b>	<b>Root Commands</b>	<b>77</b>
	DIGitize	78
	RUN	79
	STOP	80
	MODEl?	81
	SERial?	82
	DATA[:USER]	83
<b>10</b>	<b>ROUTe Subsystem</b>	<b>85</b>
	ROUTe:SCAN	86
	ROUTe:CHANnel:RANGe	88
	ROUTe:CHANnel:POLarity	90
	ROUTe:CHANnel:STYPe	92
	ROUTe:CHANnel:RSouRCe	94
	ROUTe:CHANnel:RVOLtage	95
	ROUTe:ENABLE	97
<b>11</b>	<b>SENSe Subsystem</b>	<b>99</b>
	[SENSe:]VOLTage:RANGe	100
	[SENSe:]VOLTage:POLarity	102

	[SENSe:]VOLTage:STYPe	104
	[SENSe:]COUNter:FUNcTion	106
	[SENSe:]COUNter:ABORt	108
	[SENSe:]COUNter:GATE:POLarity	109
	[SENSe:]COUNter:GATE:SOURce	111
	[SENSe:]COUNter:GATE:CONTRol	112
	[SENSe:]COUNter:CLock:INTernal?	113
	[SENSe:]COUNter:CLock:EXTernal?	114
	[SENSe:]COUNter:CLock:POLarity	115
	[SENSe:]COUNter:CLock:SOURce	116
	[SENSe:]COUNter:TOTalize:IVALue	117
	[SENSe:]COUNter:TOTalize:INITiate	118
	[SENSe:]COUNter:TOTalize:CLEar	119
	[SENSe:]COUNter:TOTalize:UDOWn:SOURce	120
	[SENSe:]COUNter:TOTalize:UDOWn:DIRection	121
<b>12</b>	<b>SOURce Subsystem</b>	<b>123</b>
	SOURce:VOLTage[:LEVel]	124
	SOURce:VOLTage:POLarity	125
	SOURce:VOLTage:RSouRce	126
	SOURce:VOLTage:RVOLTage	127
	SOURce:DIGital:DATA	128
	SOURce:DIGital:DATA:BIT	130
	SOURce:COUNter:OUTPut:POLarity	132
<b>13</b>	<b>SYSTem Subsystem</b>	<b>133</b>
	SYSTem:CDEscription?	134
	SYSTem:ERRor?	135
<b>14</b>	<b>TRIGger Subsystem</b>	<b>137</b>
	TRIGger:SOURce	138
	TRIGger:TYPe	139
	TRIGger:DCouNT	140
	TRIGger:ATRIGger:SOURce	141

	TRIGger:ATRIgger:HTHReshold	143
	TRIGger:ATRIgger:LTHReshold	144
	TRIGger:ATRIgger:CONDition	145
	TRIGger:DTRIgger:POLarity	146
<b>15</b>	<b>WAVeform Subsystem</b>	<b>147</b>
	WAVeform:DATA?	148
	WAVeform:POINts	150
	WAVeform:STATus?	152
	WAVeform:COMPLete?	153
<b>16</b>	<b>Error Messages</b>	<b>155</b>

## **Contents**





# 1 Introduction to Programming

Introduction to the SCPI Language	2
Syntax Conventions	3
Command Separators	4
Using the MIN and MAX Parameters	4
Querying Parameter Settings	5
SCPI Command Terminators	5
IEEE-488.2 Common Commands	5
SCPI Parameter Types	6
Numeric Parameters	6
Discrete Parameters	6
Boolean Parameters	7
ASCII String Parameters	7
Channel List Parameters	7
Using Device Clear	9

This chapter provides introduction to remote programming of a USB DAQ device with the SCPI programming language.



## Introduction to the SCPI Language

SCPI (Standard Commands for Programmable Instruments) is an ASCII-based instrument command language designed for test and measurement instruments. SCPI commands are based on a hierarchical structure, also known as a tree system. In this system, associated commands are grouped together under a common node or root, thus forming subsystems. A portion of the SENSE subsystem is shown below to illustrate the tree system.

SENSE:

VOLTage:

```
DC:RANGe {<range>|MIN|MAX} [, (@<ch_list>)]
```

```
DC:RANGe? [ (@<ch_list>) |MIN|MAX]
```

RESistance:

```
OCOMPensated {OFF|0|ON|1} [, (@<ch_list>)]
```

```
OCOMPensated? [ (@<ch_list>)]
```

TEMPerature:

```
RJUNction? [ (@<ch_list>)]
```

SENSE is the root keyword of the command, VOLTage, RESistance, and TEMPerature are second-level keywords, and DC, OCOMPensated, and RJUNction are third-level keywords. A colon (:) separates a command keyword from a lower-level keyword.

## Syntax Conventions

The format used to show commands is illustrated below:

```
VOLTage:DC:RANGe {<range>|MIN|MAX}[, (@<ch_list>)]
```

The command syntax shows most commands (and some parameters) as a mixture of upper- and lower-case letters. The upper-case letters indicate the abbreviated spelling for the command. For shorter program lines, you can send the abbreviated form. For better program readability, you can send the long form.

For example, in the above syntax statement, `VOLTage` and `VOLT` are both acceptable forms. You can use upper- or lower-case letters. Therefore, `VOLTAGE`, `volt`, and `Volt` are all acceptable. Other forms, such as `VOL` and `VOLTAG`, are not valid and will generate an error.

Braces ( `{ }` ) enclose the parameter choices for a given command string. The braces are not sent with the command string.

A vertical bar ( `|` ) separates multiple parameter choices for a given command string.

Triangle brackets ( `< >` ) indicate that you must specify a value for the enclosed parameter. For example, the above syntax statement shows the `<range>` parameter enclosed in triangle brackets. The brackets are not sent with the command string. You must specify a value for the parameter (e.g., `"VOLTage:DC:RANGe 10"`).

Some parameters are enclosed in square brackets ( `[ ]` ). This indicates that the parameter is optional and can be omitted. The brackets are not sent with the command string. If you do not specify a value for an optional parameter, the instrument chooses a default value.

## Command Separators

A colon ( : ) is used to separate a command keyword from a lower-level keyword. You must insert a blank space to separate a parameter from a command keyword. If a command requires more than one parameter, you must separate adjacent parameters using a comma as shown below:

```
CONFigure:VOLTage:DC 10, 0.003
```

A semicolon ( ; ) is used to separate commands within the same subsystem, and can also minimize typing. For example, sending the following command string:

```
TRIGger:SOURce EXTernal; COUNT 10
```

is the same as sending the following two commands:

```
TRIGger:SOURce EXTernal  
TRIGger:COUNT 10
```

Use a colon and a semicolon to link commands from different subsystems. For example, in the following command string, an error is generated if you do not use both the colon and semicolon:

```
ROUTE:CHANnel:DELAY 1; :TRIGger:SOURce EXTernal
```

## Using the MIN and MAX Parameters

For many commands, you can substitute "MIN" or "MAX" in place of a parameter. For example, consider the following command:

```
VOLTage:DC:RANGE {<range>|MIN|MAX}[, (@<ch_list>)]
```

Instead of selecting a specific value for the <range> parameter, you can substitute MIN to set the range to its minimum value or MAX to set the range to its maximum value.

## Querying Parameter Settings

You can query the current value of most parameters by adding a question mark ( ? ) to the command. For example, the following command sets the scan count to 10 sweeps:

```
TRIGger:COUNT 10
```

You can then query the scan count value by sending:

```
TRIGger:COUNT?
```

You can also query the minimum or maximum scan count allowed as follows:

```
TRIGger:COUNT? MIN
TRIGger:COUNT? MAX
```

## SCPI Command Terminators

A command string sent to the instrument must terminate with a <new line> (<NL>) character. The IEEE-488 EOI (End-Or-Identify) message is interpreted as a <NL> character and can be used to terminate a command string in place of a <NL> character. A <carriage return> followed by a <NL> is also accepted. Command string termination will always reset the current SCPI command path to the root level.

## IEEE-488.2 Common Commands

The IEEE-488.2 standard defines a set of common commands that perform functions such as reset, self-test, and status operations. Common commands always begin with an asterisk ( \* ), are three characters in length, and may include one or more parameters. The command keyword is separated from the first parameter by a blank space. Use a semicolon ( ; ) to separate multiple commands as shown below:

```
*RST; *CLS; *ESE 32; *OPC?
```

## SCPI Parameter Types

The SCPI language defines several data formats to be used in program messages and response messages.

### Numeric Parameters

Commands that require numeric parameters will accept all commonly used decimal representations of numbers including optional signs, decimal points, and scientific notation. Special values for numeric parameters such as MIN, MAX, and DEF are also accepted. You can also send engineering unit suffixes with numeric parameters (e.g., M, K, or u). If only specific numeric values are accepted, the instrument will automatically round the input numeric parameters. The following command requires a numeric parameter for the range value:

```
VOLTage:DC:RANGe {<range>|MIN|MAX}[, (@<ch_list>)]
```

### Discrete Parameters

Discrete parameters are used to program settings that have a limited number of values (like BUS, IMMEDIATE, EXTERNAL). They have a short form and a long form just like command keywords. You can mix upper- and lower-case letters. Query responses will always return the short form in all upper-case letters. The following command requires discrete parameters for the temperature units:

```
UNIT:TEMPerature {C|F|K}[, (@<ch_list>)]
```

## Boolean Parameters

Boolean parameters represent a single binary condition that is either true or false. For a false condition, the instrument will accept "OFF" or "0". For a true condition, the instrument will accept "ON" or "1". When you query a Boolean setting, the instrument will always return "0" or "1". The following command requires a Boolean parameter:

```
INPut:IMPedance:AUTO {OFF|0|ON|1}[, (@<ch_list>)]
```

## ASCII String Parameters

String parameters can contain virtually any set of ASCII characters. A string must begin and end with matching quotes; either with a single quote or a double quote. You can include the quote delimiter as part of the string by typing it twice without any characters in between. The following command uses a string parameter:

```
DISPlay:TEXT <quoted string>
```

For example, the following command displays the message "SCANNING..." on the instrument's front panel (the quotes are not displayed).

```
DISPlay:TEXT "SCANNING..."
```

You can also display the same message using the following command with single quotes.

```
DISPlay:TEXT 'SCANNING...'
```

## Channel List Parameters

Channel list parameters have the form (@sccc), where *s* is the mainframe slot number (1 through 8) and *ccc* is the channel number. You can specify a single channel, multiple channels, or a range of channels. The channel list must be preceded with the "@" symbol and must be enclosed in parentheses. The following commands use a channel list (<ch\_list>) parameter:

## 1 Introduction to Programming

```
ROUTE:CLOSE (@<ch_list>)
```

```
INPut:IMPedance:AUTO <mode> [, (@<ch_list>)]
```

As shown above, the <ch\_list> parameter is optional for some commands (as indicated by square brackets). If you omit the <ch\_list> parameter, the command will be applied to the internal DMM.

The following command closes channel 10 on the module in slot 3.

```
ROUTE:CLOSE (@3010)
```

The following command closes channels 10, 12, and 15 on the module in slot 2.

```
ROUTE:CLOSE (@2010,2012,2015)
```

The following command closes channels 5 through 10 (slot 1) and channel 15 (slot 2). When you specify a range of channels, any channels that are invalid will be ignored (no error will be generated) but the first and last channel in the range must be valid.

```
ROUTE:CLOSE (@1005:1010,2015)
```

The Analog Bus relays (numbered s911, s912, s913, etc.) on the multiplexer and matrix modules are ignored if they are included in a range of channels. An error will be generated if an Analog Bus relay is specified as the first or last channel in a range of channels. For example, the following command closes all valid channels between channel 30 (slot 1) and channel 5 (slot 2). In addition, this command closes Analog Bus relay 911 on the module in slot 1 (Bank 1). Note that although the specified range of channels includes the other Analog Bus relays, they are ignored and are not closed by this command.

```
ROUTE:CLOSE (@1030:2005,1911)
```

The following command will generate an error since the Analog Bus relays cannot be specified as the first or last channel in a range of channels (none of the channels will be closed).

```
ROUTE:CLOSE (@1005:1911) !Generates an error
```



## Using Device Clear

Device Clear is an IEEE-488 low-level bus message that you can use to return the instrument to a responsive state (e.g., during a lengthy query). Different programming languages and IEEE-488 interface cards provide access to this capability through their own unique commands. The status registers, the error queue, and all configuration states are left unchanged when a Device Clear message is received.

Device Clear performs the following actions:

- 1 If a scan is running, it is aborted.
- 2 The instrument returns to the trigger "idle" state.
- 3 The instrument's input and output buffers are cleared.
- 4 The instrument is prepared to accept a new command string.

An overlapped command, if any, will be terminated with no "Operation Complete" indication.

### NOTE

- The `ABORT` command is the recommended method to terminate a measurement.
  - It is recommended that you allow for a two-second wait following a Device Clear to enable the instrument to process the clear operation.
-

## **1 Introduction to Programming**



## 2 ACQuire Subsystem

ACQuire:SRATe 12

ACQuire:POINts 13

ACQuire:BURSt 14

This chapter elaborates the set of commands in ACQuire command subsystem.



### ACQuire:SRATe

#### Syntax

ACQuire:SRATe <value>

This command is used to set the sampling rate of the analog input.

ACQuire:SRATe?

The query command returns a numeric value representing the sampling rate set for the instrument.

#### Supported Model

U2351A, U2352A, U2353A, U2354A, U2355A, U2356A, U2331A

#### Parameters

Item	Type	Range of Values	Default Value
<value>	Numeric	U2351A/U2352A/U2355A: 3 Hz - 250 kHz U2353A/U2354A/U2356A: 3 Hz - 500 kHz U2331A: 3 Hz - 3 MHz	1000 Hz

#### Remarks

- <value> \* <number of entries> is the maximum ADC sampling rate.
- For U2331A, the maximum sampling rate is 3 MHz if only one channel is enabled and 1 MHz or the <number of entries> for multiple channels.

#### Query Returned Format

<value> [Hz]

#### See Also

[DIGitize](#)

[RUN](#)

## ACQuire:POINTs

### Syntax

ACQuire:POINTs <value>

This command is used to set the count of a single-shot analog input.

ACQuire:POINTs?

The query command returns a numeric value, representing the acquisition count for single-shot analog input. Note that the single-shot acquisition is initiated by the DIGitize command.

### Supported Model

U2351A, U2352A, U2353A, U2354A, U2355A, U2356A, U2331A

### Parameters

Item	Type	Range of Values	Default Value
<value>	Numeric	Maximum of 8 Msa	500

### Remarks

<value> \* <number of entries> is equivalent to eight mega points.

### Query Returned Format

<value>

### See Also

[DIGitize](#)

### ACQUIRE:BURSt

#### Syntax

ACQUIRE:BURSt <mode>

This command is used to set the burst mode of multiplexer DAQ device. In the burst mode, the device will use the full rate to perform data acquisition operation.

ACQUIRE:BURSt?

The query command returns a string value representing the state of the burst mode of multiplexer DAQ device for the input channels. "0" indicates OFF while "1" indicates ON.

#### Supported Model

U2351A, U2352A, U2353A, U2354A, U2355A, U2356A, U2331A

#### Parameters


Item	Type	Range of Values	Default Value
<mode>	String	{0 1}	0

#### Remarks

For multiplexing cards only (U2351A, U2352A, U2353A, U2354A, U2355A, U2356A, U2331A).

#### Query Returned Format

<mode> ::= {0|1}



## 3 APPLY Subsystem

APPLY?	16
APPLY:SINusoid	17
APPLY:SQUare	18
APPLY:SAWTooth	19
APPLY:TRlangle	20
APPLY:NOISe	21
APPLY:USER	22

This chapter explains how the APPLY command subsystem is configured to generate different waveforms.



## APPLy?

### Syntax

APPLy? (@<ch\_list>)

The query returns a string value that indicates the application mode of analog outputs.

### Supported Model

U2351A, U2353A, U2355A, U2356A, U2331A

### Parameters

Name	Type	Range of Values	Default Value
<ch_list>	Numeric	201 through 202	N/A

### Query Returned Format

<mode>, <amplitude>, <offset>

<mode> ::= {SIN|SQU|SAWT|TRI|NOIS|USER}

SIN: Sine wave function selected

SQU: Square wave function selected

SAWT: Sawtooth wave function selected

TRI: Triangle wave function selected

NOIS: Noise function selected

USER: User defined wave pattern selected

<amplitude> ::= Peak voltage of output function

<offset> ::= DC offset of output function



## APPLY:SINusoid

### Syntax

```
APPLY:SINusoid [<amplitude>, <offset>] (@<ch_list>)
```

This command is used to configure a sine waveform pattern onto the FIFO buffer. It outputs a sine wave with the specified amplitude and DC offset. The waveform is generated after executing the OUTPUT ON command.

### Supported Model

U2351A, U2353A, U2355A, U2356A, U2331A

### Parameters

Name	Type	Range of Values	Default Value
<amplitude>	Float	<amplitude>: amplitude units [V]	10
<offset>	Float	<offset>: offset voltage [V]	0.0
<ch_list>	Numeric	U2331A: 201 through 202	N/A

### Remarks

- Amplitude must be larger than zero.
- $\text{Amplitude} + \text{Offset} \leq 10$ ;  $\text{Amplitude} * (-1) + \text{Offset} \geq -10$ .

### Query Returned Format

```
<mode>, <amplitude>, <offset>
```

## APPLy:SQUare

### Syntax

```
APPLy:SQUare [<amplitude>, <offset>] (@<ch_list>)
```

This command is used to configure a square waveform pattern onto the FIFO buffer. It outputs a square wave with the defined amplitude and DC offset. The waveform is generated after executing the `OUTPut ON` command.

### Supported Model

U2351A, U2353A, U2355A, U2356A, U2331A

### Parameters

Name	Type	Range of Values	Default Value
<amplitude>	Float	<amplitude>: amplitude units [V]	10
<offset>	Float	<offset>: offset voltage [V]	0.0
<ch_list>	Numeric	201 through 202	N/A

### Remarks

- Amplitude must be larger than zero.
- $\text{Amplitude} + \text{Offset} \leq 10$ ;  $\text{Amplitude} * (-1) + \text{Offset} \geq -10$ .

### Query Returned Format

```
<mode>, <amplitude>, <offset>
```

## APPLY:SAWTooth

### Syntax

```
APPLY:SAWTooth [<amplitude>, <offset>] (@<ch_list>)
```

This command is used to configure a sawtooth waveform pattern onto the FIFO buffer. It outputs a sawtooth wave with the specified amplitude and DC offset. The waveform is generated after executing the `OUTPut ON` command.

### Supported Model

U2351A, U2353A, U2355A, U2356A, U2331A

### Parameters

Name	Type	Range of Values	Default Value
<amplitude>	Float	<amplitude>: amplitude units [V]	10
<offset>	Float	<offset>: offset voltage [V]	0.0
<ch_list>	Numeric	U2331A: 201 through 202	N/A

### Remarks

- Amplitude must be larger than zero.
- $\text{Amplitude} + \text{Offset} \leq 10$ ;  $\text{Amplitude} * (-1) + \text{Offset} \geq -10$ .

### Query Returned Format

```
<mode>, <amplitude>, <offset>
```

## APPLy:TRiangle

### Syntax

```
APPLy:TRiangle [<amplitude>, <offset>] (@<ch_list>)
```

This command is used to configure a triangle waveform pattern onto the FIFO buffer. It outputs a triangle wave with the defined amplitude and DC offset. The waveform is generated after executing the OUTPut ON command.

### Supported Model

U2351A, U2353A, U2355A, U2356A, U2331A

### Parameters

Name	Type	Range of Values	Default Value
<amplitude>	Float	<amplitude>: amplitude units [V]	10
<offset>	Float	<offset>: offset voltage [V]	0.0
<ch_list>	Numeric	U2331A: 201 through 202	N/A

### Remarks

- Amplitude must be larger than zero.
- $\text{Amplitude} + \text{Offset} \leq 10$ ;  $\text{Amplitude} * (-1) + \text{Offset} \geq -10$ .

### Query Returned Format

```
<mode>, <amplitude>, <offset>
```

## APPLY:NOISe

### Syntax

```
APPLY:NOISe [<amplitude>, <offset>] (@<ch_list>)
```

This command is used to configure a user defined pattern onto the FIFO buffer. It outputs a noise waveform with the specified amplitude and DC offset. The waveform is generated after executing the OUTPut ON command.

### Supported Model

U2351A, U2353A, U2355A, U2356A, U2331A

### Parameters

Name	Type	Range of Values	Default Value
<amplitude>	Float	<amplitude>: amplitude units [V]	10
<offset>	Float	<offset>: offset voltage [V]	0.0
<ch_list>	Numeric	201 through 202	N/A

### Remarks

- Amplitude must be larger than zero.
- $\text{Amplitude} + \text{Offset} \leq 10$ ;  $\text{Amplitude} * (-1) + \text{Offset} \geq -10$ .

### Query Returned Format

```
<mode>, <amplitude>, <offset>
```

## APPLy:USER

### Syntax

APPLy:USER (@<ch\_list>)

This command is used to configure a user waveform pattern onto the FIFO buffer. It outputs a user defined wave. The waveform is generated as soon as the command is executed. The waveform is generated after executing the OUTPut ON command.

### Supported Model

U2351A, U2353A, U2355A, U2356A, U2331A

### Parameters


Name	Type	Range of Values	Default Value
<ch_list>	Numeric	201 through 202	N/A

### Remarks

- The [OUTPut](#) command will return error if channel 201 and 202 is configured to user defined and pre-defined waveform patterns at the same time.

### See Also

[DATA\[:USER\]](#)



## 4 CALibration Subsystem

CALibration:BEGIN 24

This chapter explains the CALibration command subsystem that is used to carry out the calibration function on the U2300A Series multifunction USB DAQ devices.



### CALibration:BEIn

#### Syntax

```
CALibration:BEIn
```

This command is used to calibrate your device. When the function is executed, the device goes into a self-calibration mode. This command initiates a voltage calibration (adjustment) sequence for the specified DAC channel on the USB DAQ device. This sequence sets both zero and gain adjustment constants for each of the DAC output.

#### Supported Model

U2351A, U2352A, U2353A, U2354A, U2355A, U2356A, U2331A

#### Remarks

Use the `*OPC?` command to check if the calibration is completed. The calibration is complete if the returned value is "1". If the returned value is "0", the calibration is still in progress.





## 5 CONFigure Subsystem

CONFigure Subsystem Introduction	26
CONFigure:DIgital:DIRection	27
CONFigure:TIMEbase:SOURce	28
CONFigure:TIMEbase:ECLOCK	29
CONFigure:SSI	30

This chapter explains the CONFigure command subsystem.



## CONFigure Subsystem Introduction

The CONFigure command provides the most flexible way to program the instrument for measurements. When you execute this command, the instrument uses default values for the requested measurement configuration, for example the MEASure? command. However, the measurement is not automatically started and you can change some measurement attributes before actually initiating the measurement. This enables you to incrementally change the instrument's configuration from the default conditions.

The CONFigure subsystem commands are as below:

- CONFigure:DIGital:DIRection
- CONFigure:TIMEbase:SOURce
- CONFigure:TIMEbase:ExternalCLOCK
- CONFigure:SSI

## CONFigure:DIgital:DIRection

### Syntax

```
CONFigure:DIgital:DIRection <direction>, (@<ch_list>)
```

This command is used to configure the selected digital port and the direction setting for input and output operations of the selected port.

```
CONFigure:DIgital:DIRection? (@<ch_list>)
```

The query command returns "INPut" or "OUTPut" for the specified channels. Multiple responses are separated by comma.

### Supported Model

U2351A, U2352A, U2353A, U2354A, U2355A, U2356A, U2331A

### Parameters

Item	Type	Range of Values	Default Value
<direction>	String	{INPut OUTPut}	INPut
<ch_list>	Numeric	Channel 501 through 504	N/A

### Query Returned Format

```
<direction> ::= {INPut|OUTPut}
```

### Example

```
CONFigure:DIgital:DIRection INPut, (@501)
```

```
CONFigure:DIgital:DIRection? (@501)
```

```
//Expected returned string is INPut
```

### See Also

[MEASure:DIgital?](#)

[MEASure:DIgital:BIT?](#)

**CONFigure:TIMEbase:SOURce****Syntax**

```
CONFigure:TIMEbase:SOURce <mode>
```

This command is used to set the timebase/clock source for both analog inputs and outputs.

```
CONFigure:TIMEbase:SOURce?
```

The query command returns a string value, which represents the timebase/clock source for both analog input and output channels.

**Supported Model**

U2351A, U2352A, U2353A, U2354A, U2355A, U2356A, U2331A

**Parameters**

Item	Type	Range of Values	Default Value
<mode>	String	INTernal: Internal clock as the base time EXTernal: External clock as the base time CCG: Clock based on U2781A modular instrument chassis	INTernal

**Query Returned Format**

```
<mode> ::= {INTernal|EXTernal|CCG}
```

**Example**

```
CONFigure:TIMEbase:SOURce EXTernal
```

```
CONFigure:TIMEbase:SOURce? //Expected returned string is EXTernal
```

## CONFigure:TIMEbase:ECLock

### Syntax

CONFigure:TIMEbase:ECLock <clock>

This command is used to set if the time base/clock source is set to external.

CONFigure:TIMEbase:ECLock?

The query command returns a numeric value that is set by the user of the external clock in kHz.

### Supported Model

U2351A, U2352A, U2353A, U2354A, U2355A, U2356A, U2331A

### Parameters

Item	Type	Range of Values	Default Value
<clock>	Float	10 MHz to 48 MHz	10000 kHz

### Query Returned Format

<clock> [kHz]

### Example

CONFigure:TIMEbase:ECLock 20000 //Set to external clock of 20 MHz

### See Also

[CONFigure:TIMEbase:SOURce](#)

## CONFigure:SSI

### Syntax

```
CONFigure:SSI <mode>
```

This command sets the synchronization status (master/slave) when used in the U2781A modular instrument chassis.

```
CONFigure:SSI?
```

The query command returns a string value, which represents the synchronization status (master/slave).

### Supported Model

U2351A, U2352A, U2353A, U2354A, U2355A, U2356A, U2331A

### Parameters

Item	Type	Range of Values	Default Value
<mode>	String	NONE: None MAST: To function as SSI master triggering source SLAV: To receive triggering source from master	NONE

### NOTE

- This command is only operational when used in U2781A modular instrument chassis.
- There should only be one master assigned.

### Remarks

- This command will force all reference clock sources to synchronous serial interface (SSI).
- Once a module is configured as a slave (via `CONFigure:SSI:SLAV`), it becomes a listener and listens for triggering signals on the backplane of the U2781A chassis. To undo this listener behavior, a `CONFigure:SSI:NONE` command must be applied to the slave module.

**Query Returned Format**

<mode> ::= {NONE|MAST|SLAV}

**See also:**


[CONFigure:TIMEbase:SOURce](#)

[TRIGger:SOURce](#)

[OUTPut:TRIGger:SOURce](#)







## 6 IEEE-488 Common Command

*CLS	34
*ESE	35
*ESR?	38
*IDN?	39
*OPC?	40
*RCL	41
*RST	42
*SAV	43
*SRE	46
*STB?	48
*TST?	50
*WAI	51

This chapter gives an introduction to the IEEE-488.2 common commands. It defines a set of common commands that perform functions such as reset, self-test and status operations.



## \*CLS

### Syntax

```
*CLS
```

This command is used to clear the event registers in all register groups. This command also clears the error queue.

### Supported Model

U2351A, U2352A, U2353A, U2354A, U2355A, U2356A, U2331A

### Example

The following command clears the event register bits:

```
*CLS
```

**\*ESE****Syntax**

```
*ESE <enable_value>
```

This command enables bits in the enable register for the Standard Event Register group. The selected bits are then reported to bit 5 of the Status Byte Register.

**Supported Model**

U2351A, U2352A, U2353A, U2354A, U2355A, U2356A, U2331A

**Parameters**

Item	Type	Range of Values	Default Value
<enable_value>	Numeric	A decimal value which corresponds to the binary-weighted sum of the bits in the register. Refer to table below.	This is a required parameter.

**Returned Format**

The query command reads the enable register and returns a decimal value which corresponds to the binary-weighted sum of all bits set in the register. For example, if bit 3 (decimal value = 8) and bit 7 (decimal value = 128) are enabled, the query command will return "+136".

### Remarks

- The following table lists the bit definitions for the Standard Event Register.

Bit Number	Decimal Value	Definition
0 Not used	Not used	"0" is returned
1 Not used	Not used	"0" is returned
2 Query Error	4	The instrument tried to read the output buffer but it was empty. Or, a new command line was received before a previous query has been read. Or, both the input and output buffers are full
3 Device Error	Not used	"0" is returned
4 Execution Error	16	An execution error occurred
5 Command Error	32	A command syntax error occurred
6 Not used	Not used	"0" is returned
7 Power On	128	Power has been turned off and on since the last time the event register was read or cleared

- Use the <enable\_value> parameter to specify which bits will be enabled. The decimal value specified corresponds to the binary-weighted sum of the bits you wish to enable in the register. For example, to enable bit 2 (decimal value = 4), bit 3 (decimal value = 8), and bit 7 (decimal value = 128), the corresponding decimal value would be 140 (4 + 8 + 128).
- The \*CLS (clear status) command will not clear the enable register but it clears all bits in the event register.
- An Instrument Preset (SYSTEM:PRESet command) does not clear the bits in the Status Byte enable register.
- Refer to [Figure 6-1](#) on page 37 for the status system diagram.

### Example

The following command enables bit 4 (decimal value = 16) in the enable register. If an Execution Error occurs, this condition will be reported to the Status Byte Register (bit 5 will be set to high).

\*ESE 16


The following query returns which bits are enabled in the register.

\*ESE?

Typical Response: +16

**See Also**

\*ESR?



**Figure 6-1** Status system diagram

## \*ESR?

### Syntax

\*ESR?

The command reads the event register and returns a decimal value which corresponds to the binary-weighted sum of all bits set in the register (see table above). For example, if bit 1 (decimal value = 2) and bit 4 (decimal value = 16) are set (and the corresponding bits are enabled), this command will return "+18".

### Supported Model

U2351A, U2352A, U2353A, U2354A, U2355A, U2356A, U2331A

### Example

The following command reads the event register (bits 3 and 4 are set).

\*ESR?

Typical Response: +24

### Remarks

Refer to [Figure 6-1](#), status system diagram for more information.

### See Also

[\\*ESE](#)

## \*IDN?

### Syntax

\*IDN?

This command reads the instrument's identification string which contains four comma-separated fields. The first field is the manufacturer's name, followed by the instrument model number, serial number and firmware revision code.

### Supported Model

U2351A, U2352A, U2353A, U2354A, U2355A, U2356A, U2331A

### Query

The command returns a string with the following format:

Agilent Technologies, U2331A, <Serial Number>, A.YYYY.MM.DD

YYYY = Year

MM = Month

DD = Date

### Example

The following query returns the instrument's identification string.

\*IDN?

Typical Response:

Agilent Technologies, U2331A, TW12345678, A.2006.10.10

### See Also

[SYSTem:CDEscription?](#)

## \*OPC?

### Syntax

\*OPC?

This query returns "1" to the output buffer at the completion of the current operation.

### Supported Model

U2351A, U2352A, U2353A, U2354A, U2355A, U2356A, U2331A

### Remarks

This command is performed to synchronize your application with the instrument.

### Return Format

The command returns "1" to the output buffer.

### Example

The following command waits until the internal calibration routine is completed and then sets the returned value of \*OPC? to 1. When the calibration routine is not completed just yet, the \*OPC? query will return a 0. In other words, a return value of 1 indicates that this calibration routine has been completed.

### See Also

[CALibration:BEgin](#)

[SYSTem:ERRor?](#)



## \*RCL

### Syntax

```
*RCL {1|2}
```

This command recalls the instrument state stored in the defined storage location. It is not possible to recall the instrument state from a storage location that is empty or was deleted. When shipped from the factory, storage locations 1 through 2 are empty.

Use the \*SAV command to store the current instrument state.

### Supported Model

U2351A, U2352A, U2353A, U2354A, U2355A, U2356A, U2331A

### Remarks

- The instrument has two storage locations in the non-volatile memory to store instrument states. You can only recall a state from a location that contains a previously stored state.
- Before recalling a stored state, the instrument will perform the equivalent of a Factory Reset (\*RST command).
- A Factory Reset (\*RST command) has no effect on the configurations stored in the memory. Once a state is stored, it remains until it is overwritten or specifically deleted.

### Example

The following command recalls the instrument state previously stored in location 1.

```
*RCL 1
```

### See Also

\*SAV

## \*RST

### Syntax

```
*RST
```

This command resets the instrument to the default configuration. See Factory Reset State for a complete listing of the instrument's default configuration.

### Remarks

- This command does not affect any previously-stored instrument states (see [\\*SAV](#) command).

### Example

The following command resets the instrument.

```
*RST
```

### See Also

[SYSTem:ERRor?](#)

## \*SAV

### Syntax

```
*SAV {1|2}
```

This command stores (saves) the current instrument state in the designated storage location. Any state previously stored in the same location is overwritten (with no error is generated).

Use the \*RCL command to recall a stored instrument state.

### Remarks

- The instrument has two storage locations in non-volatile memory to store instrument states. You can store the instrument state in any of the five locations, but you can only recall a state from a location that contains a previously stored state.
- A Factory Reset (\*RST command) does not affect the configurations stored in the memory. Once a state is stored, it remains until it is overwritten or specifically deleted.
- The following parameters are saved in \*SAV:
  - [SENSe:]VOLTage:RANGE
  - [SENSe:]VOLTage:POLarity
  - [SENSe:]VOLTage:STYPe
  - [SENSe:]COUNter:FUNCTion
  - [SENSe:]COUNter:GATE:POLarity
  - [SENSe:]COUNter:GATE:SOURce
  - [SENSe:]COUNter:GATE:CONTRol
  - [SENSe:]COUNter:CLock:EXTernal
  - [SENSe:]COUNter:CLock:SOURce
  - [SENSe:]COUNter:TOTALize:IVALue
  - [SENSe:]COUNter:TOTALize:UDOWn:SOURce
  - [SENSe:]COUNter:TOTALize:UDOWn:DIRection
  - SOURce:VOLTage:POLarity
  - SOURce:VOLTage:RSouRce

- SOURce:VOLTage:RVOLTage
- CONFigure:DIgital:DIRection
- CONFigure:TIMEbase:SOURce
- CONFigure:TIMEbase:ECLOCK
- CONFigure:SSI
- APPLy
- APPLy:SINusoid
- APPLy:SQUare
- APPLy:SAWTooth
- APPLy:NOISe
- APPLy:USER
- OUTPut:WAVeform:ITERate
- OUTPut:WAVeform:SRATE
- OUTPut:WAVeform:FREQuency
- OUTPut:TRIGger:SOURce
- OUTPut:TRIGger:TYPE
- OUTPut:TRIGger:DCouNT
- OUTPut:TRIGger:ATRiGger:SOURce
- OUTPut:TRIGger:ATRiGger:HTHReshold
- OUTPut:TRIGger:ATRiGger:LTHReshold
- OUTPut:TRIGger:ATRiGger:CONDition
- OUTPut:TRiGger:DTRiGger:POLarity
- ROUTe:CHANnel:RSouRce
- ROUTe:CHANnel:RVOLTage
- ROUTe:SCAN
- ROUTe:CHANnel:RANGE
- ROUTe:CHANnel:POLarity
- ROUTe:CHANnel:STYPE
- ACQuire:SRATE
- ACQuire:POINTs
- ACQuire:BURSt

- WAVEform:POINTs
- TRIGger:SOURce
- TRIGger:TYPe
- TRIGger:DCouNT
- TRIGger:ATRIgger:SOURce
- TRIGger:ATRIgger:CONDition
- TRIGger:DTRIgger:POLarity
- TRIGger:ATRIgger:HTHReshold
- TRIGger:ATRIgger:LTHReshold

**Example**

The following command stores the current instrument state in location 1.

```
*SAV 1
```

**See Also**

[\\*RCL](#)

**\*SRE****Syntax**

\*SRE <enable\_value>

This command enables bits in the enable register for the Status Byte Register group. Once enabled, the corresponding bits may generate a Request for Service (RQS) in the Status Byte. This RQS event may generate a "call back" to your application as a type of asynchronous interrupt.

\*SRE?

The query command reads the enable register and returns a decimal value which corresponds to the binary-weighted sum of all bits set in the register. For example, if bit 3 (decimal value = 8) and bit 7 (decimal value = 128) are enabled, the query command will return "+136".

**Parameters**

Name	Type	Range of Values	Default Value
<enable_value>	Numeric	A decimal value which corresponds to the binary-weighted sum of the bits in the register. Refer to the table below.	This is a required parameter.

**Remarks**

- The following table lists the bit definitions for the Status Byte Register.

Bit Number	Decimal Value	Definition
0 Not used	Not used	Always zero
1 Not used	Not used	Always zero
2 Error Queue	4	One or more errors have been stored in the Error Queue Use the <a href="#">SYSTem:ERRor?</a> command to read and delete errors
3 Not used	Not used	Always zero
4 Message Available	16	Data is available in the instrument's output buffer for single SCPI query but not for continuous acquisition output buffer

5 Standard Event Summary	32	One or more bits are set in the Standard Event Register (bits must be enabled, see *ESE command)
6 Master Summary	64	One or more bits are set in the Status Byte Register and may generate a Request for Service (RQS) Bits must be enabled using the *SRE command
7 Not used	Not used	Always zero

- Use the <enable\_value> parameter to specify which bits will be enabled. The decimal value specified corresponds to the binary-weighted sum of the bits you wish to enable in the register. For example, to enable bit 1 (decimal value = 2), bit 3 (decimal value = 8), and bit 6 (decimal value = 64), the corresponding decimal value would be 74 (2 + 8 + 64).
- The Status Byte enable register is cleared when you execute the \*SRE 0 command.
- Refer to [Figure 6-1](#), status system diagram for more information.

### Return Format

The query command reads the enable register and returns a decimal value which corresponds to the binary-weighted sum of all bits set in the register. For example, if bit 3 (decimal value = 8) and bit 7 (decimal value = 128) are enabled, the query command will return "+136".

### Example

The following command enables bit 4 (decimal value = 16) in the enable register.

```
*SRE 16
```

The following query returns which bits are enabled in the register.

```
*SRE?
```

Typical Response: +16

### See Also

[\\*STB?](#)

**\*STB?****Syntax**

\*STB?

This command queries the condition register for the Status Byte Register group. This command is similar to a Serial Poll but it is processed like any other instrument command. This is a read-only register and the bits are not cleared when you read the register.

**Remarks**

- The following table lists the bit definitions for the Status Byte Register.

Bit Number	Decimal Value	Definition
0 Not used	Not used	Always zero
1 Not used	Not used	Always zero
2 Error Queue	4	One or more errors have been stored in the Error Queue Use the <a href="#">SYSTem:ERRor?</a> command to read and delete errors
3 Not used	Not used	Always zero
4 Message Available	16	Data is available in the instrument's output buffer for single SCPI query but not for continuous acquisition output buffer
5 Standard Event Summary	32	One or more bits are set in the Standard Event Register (bits must be enabled, see <a href="#">*ESE</a> command)
6 Master Summary	64	One or more bits are set in the Status Byte Register and may generate a Request for Service (RQS) Bits must be enabled using the <a href="#">*SRE</a> command
7 Not used	Not used	Always zero

- Use the <enable\_value> parameter to specify which bits will be enabled. The decimal value specified corresponds to the binary-weighted sum of the bits you wish to enable in the register. For example, to enable bit 1 (decimal value = 2), bit 3 (decimal value = 8), and bit 6 (decimal value = 64), the corresponding decimal value would be 74 (2 + 8 + 64).



- The Status Byte enable register is cleared when you execute the \*SRE 0 command.
- Refer to [Figure 6-1](#) for the status system diagram.

**Example**

The following command reads the condition register (bits 3 and 4 are set).

```
*STB?
```

Typical Response: +24

**See Also**

[\\*CLS](#)

[\\*SRE](#)

## \*TST?

### Syntax

\*TST?

This command performs a self-test of the instrument and returns a pass/fail indication.

### Return Query Format

The command returns "+0" (all tests passed) or "+1" (one or more tests failed).

### Example

The following command performs a self-test and returns a pass/fail indication.

\*TST?

Typical Response: +0

## \*WAI

### Syntax


\*WAI

This command configures the instrument to wait for all pending operations to complete before executing any additional commands over the interface.

### See Also

[\\*OPC?](#)





## 7 MEASure Subsystem

MEASure[:VOLTage][:DC]? 54
MEASure:COUNter:DATA? 55
MEASure:COUNter:FREQuency? 56
MEASure:COUNter:PERiod? 57
MEASure:COUNter:PWIDth? 58
MEASure:COUNter:TOTalize? 59
MEASure:DIGital? 60
MEASure:DIGital:BIT? 61

This chapter explains how the MEASure command subsystem is configured when acquiring data from the U2300A Series multifunction USB DAQ devices.



## MEASure[:VOLTage][:DC]?

### Syntax

```
MEASure[:VOLTage][:DC]? (@<ch_list>)
```

The query command returns a numeric value representing the scaled voltage value in volts for analog inputs. Multiple responses are separated by commas.

### Supported Model

U2351A, U2352A, U2353A, U2354A, U2355A, U2356A, U2331A

### Parameters

Item	Type	Range of Values	Default Value
<ch_list>	Numeric	Single-ended mode: U2351A/U2352A/U2353A/U2354A: 101-116 U2355A/U2356A/U2331A: 101-164 Differential mode: U2351A/U2352A/U2353A/U2354A: 101-108 U2355A/U2356A/U2331A: 101-132	N/A

### Remarks

If the returned value is 999.9, it is out of range.

### Query Returned Format

```
<value> [V]
```

### See Also

[\[SENSe:\]VOLTage:STYPe](#)

## MEASure:COUNter:DATA?

### Syntax

```
MEASure:COUNter:DATA? (@<ch_list>)
```

The query command returns a float value based on the `SENSe:COUNter` command. This value is the counter value for specific counting mode on specified counter channel. Multiple responses are separated by commas.

### Supported Model

U2351A, U2352A, U2353A, U2354A, U2355A, U2356A, U2331A

### Parameters

Item	Type	Range of Values	Default Value
<ch_list>	Numeric	301 through 302	N/A

### Remarks

This query requires a channel number to be stated.

### Query Returned Format

```
<value>
```

### Example

```
SENSe:COUNter:FUNctIon TOTAlize, (@301)
```

```
SENSe:COUNter:FUNctIon FREQuency, (@301)
```

```
MEASure:COUNter:DATA? (@301)
```

### See Also

[\[SENSe:\]COUNter:FUNctIon](#)

## MEASure:COUNter:FREQuency?

### Syntax

```
MEASure:COUNter:FREQuency? (@<ch_list>)
```

The query command returns a numeric value that indicates the frequency value in kHz of the designated counter channel. Multiple responses are separated by commas.

### Supported Model

U2351A, U2352A, U2353A, U2354A, U2355A, U2356A, U2331A

### Parameters

Item	Type	Range of Values	Default Value
<ch_list>	Numeric	301 through 302	N/A

### Remarks

This query requires a channel number to be stated.

### Query Returned Format

```
<value> [kHz]
```

### Example

```
SENSe:COUNter:FUNction FREQuency, (@301)
```

```
MEASure:COUNter:FREQuency? (@301)
```

### See Also

[\[SENSe:\]COUNter:FUNction](#)

[MEASure:COUNter:DATA?](#)



## MEASure:COUNter:PERiod?

### Syntax

```
MEASure:COUNter:PERiod? (@<ch_list>)
```

The query command returns a numeric value representing the period value in ms of the specified counter channel. Multiple responses are separated by commas.

### Supported Model

U2351A, U2352A, U2353A, U2354A, U2355A, U2356A, U2331A

### Parameters

Item	Type	Range of Values	Default Value
<ch_list>	Numeric	301 through 302	N/A

### Remarks

This query requires a channel number to be stated.

### Query Returned Format

```
<value> [ms]
```

### Example

```
[SENSe:]COUNter:FUNctIon PERiod, (@301)
MEASure:COUNter:PERiod? (@301)
```

### See Also

[\[SENSe:\]COUNter:FUNctIon](#)

[MEASure:COUNter:DATA?](#)

## MEASure:COUNter:PWIDth?

### Syntax

```
MEASure:COUNter:PWIDth? (@<ch_list>)
```

This query command returns a numeric value. The returned value is the pulse width (duty cycle) of the specified counter channel measured in milliseconds (ms). Multiple responses are separated by commas.

### Supported Model

U2351A, U2352A, U2353A, U2354A, U2355A, U2356A, U2331A

### Parameters

Item	Type	Range of Values	Default Value
<ch_list>	Numeric	301 through 302	N/A

### Remarks

This query requires a channel number to be stated.

### Query Returned Format

```
<value> [ms]
```

### Example

```
[SENSe:]COUNter:FUNCTion PWIDth, (@301)
MEASure:COUNter:PWIDth? (@301)
```

### See Also

[\[SENSe:\]COUNter:FUNCTion](#)

[MEASure:COUNter:DATA?](#)

## MEASure:COUNter:TOTalize?

### Syntax

```
MEASure:COUNter:TOTalize? (@<ch_list>)
```

This query command returns a numeric value that represents the totalized value of the specified counter channel . Multiple responses are separated by commas.

### Supported Model

U2351A, U2352A, U2353A, U2354A, U2355A, U2356A, U2331A

### Parameters

Item	Type	Range of Values	Default Value
<ch_list>	Numeric	301 through 302	N/A

### Remarks

This query requires a channel number to be stated.

### Query Returned Format

```
<value>
```

## MEASure:DIGital?

### Syntax

```
MEASure:DIGital? (@<ch_list>)
```

The query command returns a numeric value representing the digital data from the specified digital input port. Multiple responses are separated by commas.

### Supported Model

U2351A, U2352A, U2353A, U2354A, U2355A, U2356A, U2331A

### Parameters

Item	Type	Range of Values	Default Value
<ch_list>	Numeric	Channel 501 through 504	N/A

### Remarks

This query requires a channel number to be stated.

### Query Returned Format

Channel 501, 502: 0 to 255 (8-bits)

Channel 503, 504: 0 to 15 (4-bits)

### Example

```
CONFigure:DIGital:DIRection INPut, (@501)
```

```
MEASure:DIGital? (@501)
```

### See Also

[CONFigure:DIGital:DIRection](#)

## MEASure:DIGital:BIT?

### Syntax

```
MEASure:DIGital:BIT? <bit>, (@<ch_list>)
```

This query returns the digital logic state of the specified bit of the designated channel.

### Supported Model

U2351A, U2352A, U2353A, U2354A, U2355A, U2356A, U2331A

### Parameters

Item	Type	Range of Values	Default Value
<bit>	Numeric	Channel 501 and 502: Bit 0 to 7 Channel 503 and 504: Bit 0 to 3	0
<ch_list>	Numeric	Channel 501 through 504	N/A

### Remarks

- Channel 501 and 502 are 8-bit, while Channel 503 and 504 are 4-bit.
- This query requires a channel number to be stated.

### Query Returned Format

0 or 1

### Example

```
CONFigure:DIGital:DIRection INPut, (@501)
```


```
CONFigure:DIGital:BIT? 2, (@501) //Reads bit 2 of channel 501
```

```
MEASure:DIGital:BIT? 0, (@502) //Reads bit 0 of channel 502
```

### See Also

[CONFigure:DIGital:DIRection](#)





## 8 OUTPut Subsystem

OUTPut	64
OUTPut:WAVEform:ITERate	65
OUTPut:WAVEform:SRATe	66
OUTPut:WAVEform:FREQuency	67
OUTPut:TRIGger:SOURce	68
OUTPut:TRIGger:TYPE	69
OUTPut:TRIGger:DCouNT	70
OUTPut:TRIGger:ATRIgger:SOURce	71
OUTPut:TRIGger:ATRIgger:HTHReshold	72
OUTPut:TRIGger:ATRIgger:LTHReshold	73
OUTPut:TRIGger:ATRIgger:CONDition	74
OUTPut:DTRIGger:POLarity	75

This chapter explains the OUTPut command subsystem.



# OUTPut

## Syntax

OUTPut <mode>

This command sets the status (ON/OFF) of the analog output.

OUTPut?

The query command returns a string value representing the status of the analog output.

## Supported Model

U2351A, U2353A, U2355A, U2356A, U2331A

## Parameters

Name	Type	Range of Values	Default Value
<mode >	String	OFF or 0: Output predefined waveform ON or 1: Terminate waveform output	0

## Remarks

- The OUTPut ON and OUTPut OFF commands cannot be executed repeatedly.
- Resets the voltage level by using the SOURce:VOLTage 0 command.
- Cannot generate user-defined and pre-defined waveforms at the same time.

## Query Returned Format

<mode> ::= {0|1}



## OUTPut:WAVeform:ITERate

### Syntax

```
OUTPut:WAVeform:ITERate <value>
```

This command is used to set the number of iteration of the data in the buffer output.

```
OUTPut:WAVeform:ITERate?
```

The query command returns the integer value representing the iteration number of data in the buffer to output to the desired port.

### Supported Model

U2351A, U2353A, U2355A, U2356A, U2331A

### Parameters

Name	Type	Range of Values	Default Value
<value>	Integer	0 to 16777215 (24 bits)	0

### Remarks

- 0 for infinite iteration.
- Positive number for iteration count.
- The iteration value must be larger or equal to zero and less than 0xfffff.

### Query Returned Format

```
<value>
```

## OUTPut:WAVEform:SRATe

### Syntax

OUTPut:WAVEform:SRATe <value>

This command is used to set the updated rate of analog outputs.

OUTPut:WAVEform:SRATe?

The query command returns an integer value representing the updated rate of analog outputs measured in Hz.

### Supported Model

U2351A, U2353A, U2355A, U2356A, U2331A

### Parameters

Name	Type	Range of Values	Default Value
<value>	Float	(48/16777215) MHz to 1 MHz	0

### Remarks

- The range bound by  $0 \leq \text{<value>} \leq 10^6$ . Must be  $\geq 48 \times 10^6 / 0\text{xfffff}$ .
- Default value zero implies automatic sampling configuration for SIN, SQU, SAWT, TRI, and NOIS waveform generation.
- Maximum of 4096 points for one waveform.

### Query Returned Format

<value> [Hz]

## OUTPut:WAVEform:FREQuency

### Syntax

OUTPut:WAVEform:FREQuency <value>

This command sets the frequency of analog outputs.

OUTPut:WAVEform:FREQuency?

The query command returns a float value representing the frequency in Hz for analog outputs.

### Supported Model

U2351A, U2353A, U2355A, U2356A, U2331A

### Parameters

Name	Type	Range of Values	Default Value
<value>	Float	10 Hz to 10000 Hz	4000

### Remarks

The range of the returned value is from 10 Hz to 10000 Hz.

### Query Returned Format

<value> Hz

## OUTPut:TRIGger:SOURce

### Syntax

```
OUTPut:TRIGger:SOURce <mode>
```

This command is used to set the setting of the D/A trigger control.

```
OUTPut:TRIGger:SOURce?
```

The query command returns a string value representing the setting of the D/A trigger control.

### Supported Model

U2351A, U2353A, U2355A, U2356A, U2331A

### Parameters

Name	Type	Range of Values	Default Value
<mode>	String	NONE: Immediate trigger EXTD: From external digital trigger pin EXTA: From external analog trigger pin STRG: Clock Source by star trigger	NONE

### Query Returned Format

```
<mode> ::= {NONE|EXTD|EXTA|STRG}
```

## OUTPut:TRIGger:TYPe

### Syntax

OUTPut:TRIGger:TYPe <mode>

This command sets the trigger mode selection of the analog output.

OUTPut:TRIGger:TYPe?

The query command returns a string value that indicates the trigger mode selection of the analog output.

### Supported Model

U2351A, U2353A, U2355A, U2356A, U2331A

### Parameters

Name	Type	Range of Values	Default Value
<mode>	String	POST: post-trigger DEL: delay-trigger	POST

### Query Returned Format

<mode> ::= {POST|DEL}

## OUTPut:TRIGger:DCouNT

### Syntax

OUTPut:TRIGger:DCouNT <value>

This command is used to set the delay counter value, which is the duration of output after trigger signal is received.

OUTPut:TRIGger:DCouNT?

The query command returns an integer value representing the delay time or count.

### Supported Model

U2351A, U2353A, U2355A, U2356A, U2331A

### Parameters

Name	Type	Range of Values	Default Value
<value>	Integer	0 to 2147483647 (31 bits)	0

### Remarks

$0 \leq \text{<value>} \leq 0x7fffffff$  (for counter).

### Query Returned Format

<value> [second]

## OUTPut:TRIGger:ATRIgger:SOURce

### Syntax

OUTPut:TRIGger:ATRIgger:SOURce <mode>

This command sets the trigger source of the analog output.

OUTPut:TRIGger:ATRIgger:SOURce?

The query command returns a string value that indicates the trigger source of the analog output.

### Supported Model

U2351A, U2353A, U2355A, U2356A, U2331A

### Parameters

Name	Type	Range of Values	Default Value
<mode>	String	EXTAP: From external analog trigger pin SONE: Source from first scanned channel for multiplexing USB DAQ device	EXTAP

### Query Returned Format

<mode> ::= {EXTAP|SONE}

## **OUTPut:TRIGger:ATRIgger:HTHReshold**

### **Syntax**

```
OUTPut:TRIGger:ATRIgger:HTHReshold <value>
```

This command sets the high threshold voltage of the analog trigger output.

```
OUTPut:TRIGger:ATRIgger:HTHReshold?
```

The query command returns a float value that represents the high threshold voltage for the analog trigger output.

### **Supported Model**

U2351A, U2353A, U2355A, U2356A, U2331A

### **Parameters**

<b>Name</b>	<b>Type</b>	<b>Range of Values</b>	<b>Default Value</b>
<value>	Float	-10 V to 10 V	10.0

### **Query Returned Format**

```
<value>
```



## OUTPut:TRIGger:ATRIgger:LTHReshold

### Syntax

OUTPut:TRIGger:ATRIgger:LTHReshold <value>

This command is used to set the low threshold voltage of the analog trigger output.

OUTPut:TRIGger:ATRIgger:LTHReshold?

The query command returns a float value. This returned value is the low threshold voltage of the analog trigger output.

### Supported Model

U2351A, U2353A, U2355A, U2356A, U2331A

### Parameters

Name	Type	Range of Values	Default Value
<value>	Float	-10 V to 10 V	10.0

### Query Returned Format

<value>

## OUTPut:TRIGger:ATRIgGger:CONDition

### Syntax

```
OUTPut:TRIGger:ATRIgGger:CONDition <mode>
```

This command sets the trigger condition for the analog trigger control of the analog output.

```
OUTPut:TRIGger:ATRIgGger:CONDition?
```

The query command returns a string value representing the trigger condition for the analog trigger control for the analog output.

### Supported Model

U2351A, U2353A, U2355A, U2356A, U2331A

### Parameters

Name	Type	Range of Values	Default Value
<mode>	String	AHIG: Above-High-Level triggering BLOW: Below-Low-Level triggering WIND: Inside Region triggering	BLOW

### Query Returned Format

```
<mode> ::= {AHIG|BLOW|WIND}
```

## OUTPut:DTRiGger:POLarity

### Syntax

OUTPut:DTRiGger:POLarity <mode>

This command is to set the polarity of the external digital trigger of the analog output.

OUTPut:DTRiGger:POLarity?

The query command returns a string value representing the analog trigger condition of the analog output.

### Supported Model

U2351A, U2353A, U2355A, U2356A, U2331A


### Parameters

Name	Type	Range of Values	Default Value
<mode>	String	POS: Trigger positive edge active NEG: Trigger negative edge active	POS

### Query Returned Format

<mode> ::= { POS | NEG }





## 9 Root Commands

DIGitize	78
RUN	79
STOP	80
MODEl?	81
SERial?	82
DATA[:USER]	83

This chapter explains how the SYSTem root commands are utilized for the U2300A Series multifunction USB DAQ devices.



## DIGitize

### Syntax

```
DIGitize
```

This command is used to start the single-shot data acquisition.

### Supported Model

U2351A, U2352A, U2353A, U2354A, U2355A, U2356A, U2331A

### Remarks

- Use the [STOP](#) command to stop the single-shot acquisition before the number of point stated in `ACQUIRE:POINTS` is reached.
- In general condition, there are four trigger conditions; post trigger, pre-trigger, middle trigger and NONE. However, user can only select post and delay trigger modes when used in NONE trigger mode.

### See Also:

[ACQUIRE:POINTS](#)

[ACQUIRE:SRATE](#)

[STOP](#)

[WAVEFORM:COMPLETE?](#)

[WAVEFORM:DATA?](#)

# RUN

## Syntax

RUN

This command is used to start the continuous data acquisition.

## Supported Model

U2351A, U2352A, U2353A, U2354A, U2355A, U2356A, U2331A

## Remarks

- Use the [STOP](#) command to stop a complete work flow.
- Post and delay trigger conditions are only supported in continuous analog input mode.

## See Also:

[ACQUIRE:SRATE](#)

[STOP](#)

[WAVEform:DATA?](#)

[WAVEform:POINts](#)

[WAVEform:STATus?](#)

# STOP

## Syntax

STOP

This command is used to stop the asynchronous analog input operation.

## Supported Model

U2351A, U2352A, U2353A, U2354A, U2355A, U2356A, U2331A



## MODe1?

### Syntax

```
MODe1?
```

This query returns the model of the USB DAQ device. The returned string can be any of the models in the U2300A Series DAQ devices.

## SERial?

### Syntax

```
SERial?
```

This query returns a string value indicating the serial number of the USB DAQ device.

## DATA[:USER]

### Syntax

```
DATA[:USER]
```

```
DATA <header><binary block>
```

This command is used to set the user-defined pattern onto the FIFO buffer.

### Supported Model

U2352A, U2354A, U2355A, U2356A, U2331A

### Remarks

- Binary block must use the IEEE-488.2 binary block format.
- Syntax cannot be executed while analog output is running after executing command `OUTPut ON`.
- This is an adjunct command for [APPLy:USER](#).

### Example


```
DATA #800000200<byte1><byte2>...<byte200>
```

### See Also:

[OUTPut:WAVeform:ITERate](#)

[OUTPut:WAVeform:SRATe](#)





## 10 ROUTe Subsystem

ROUTe:SCAN	86
ROUTe:CHANnel:RANGe	88
ROUTe:CHANnel:POLarity	90
ROUTe:CHANnel:STYPe	92
ROUTe:CHANnel:RSouRCe	94
ROUTe:CHANnel:RVOLtage	95
ROUTe:ENABLe	97

This chapter contains information on the ROUTe command subsystem.



## ROUTe:SCAN

### Syntax

```
ROUTe:SCAN (@<ch_list>)
```

This command is used to set the acquisition sequence which is specified in the channel list (<ch\_list>). This acquisition sequence is also known as a scan list.

```
ROUTe:SCAN?
```

The query command returns an integer value that indicates the specified input channel. Multiple responses are separated by commas.

### Supported Model

U2351A, U2352A, U2353A, U2354A, U2355A, U2356A, U2331A

### Parameters

Item	Type	Range of Values	Default Value
<ch_list>	Numeric	Single-ended mode: U2351A/U2352A/U2353A/U2354A: 101-116 U2355A/U2356A/U2331A: 101-164  Differential mode: U2351A/U2352A/U2353A/U2354A: 101-108 U2355A/U2356A/U2331A: 101-132	N/A

**Remarks**

- For U2300A Series DAQ device that supports multiplexing only.
- The maximum channel list is 100 items.
- Repeated channel assignment is allowed, for instance 101, 102, 103, 101...
- This command is capable of changing the scan order without changing the properties on RANGE, POLARITY and SIGNAL TYPE.
- Consecutive channels can be specified using colon or comma. For example 101, 102, 103 or 101:103.

**Query Returned Format**

(@<ch\_list>)

## ROUTe:CHANnel:RANGe

### Syntax

ROUTe:CHANnel:RANGe <value>, (@<ch\_list>)

This command is used to set the voltage range of the specified analog input channels.

ROUTe:CHANnel:RANGe? (@<ch\_list>)

The query command returns a float value that represents the range in volts of the specified analog inputs channels. Multiple responses are separated by commas.

### Supported Model

U2351A, U2352A, U2353A, U2354A, U2355A, U2356A, U2331A

### Parameters

Item	Type	Range of Values	Default Value
<value>	Float	U2331A: Unipolar mode: {10 5 4 2.5 2.0 1.0 0.5 0.4 0.1} Bipolar mode: {10 5 2.5 2.0 1.25 1.0 0.5 0.25 0.2 0.05} U2351A/U2352A/U2353A/U2354A/U2355A/ U2356A: Unipolar/Bipolar mode: {10,5,2.5,1.25}	10
<ch_list>	Numeric	Single-ended mode: U2351A/U2352A/U2353A/U2354A: 101-116 U2355A/U2356A/U2331A: 101-164 Differential mode: U2351A/U2352A/U2353A/U2354A: 101-108 U2355A/U2356A/U2331A: 101-132	N/A



**Remarks**

- If the polarity is UNIPolar, the value 10 means 0 V to 10 V. Whereas, if the polarity is BIPolar, the value is in the range of -10 V to +10 V.
- If the reference value is out of all enumeration, it will raise error code -224, "Illegal parameter value".

**Query Returned Format**

<value> [V]

**See Also**

[ROUTE:CHANnel:POLarity](#)

[ROUTE:CHANnel:STYPe](#)

## ROUTe:CHANnel:POLarity

### Syntax

```
ROUTe:CHANnel:POLarity <mode>, (@<ch_list>)
```

This command is used to set the polarity (unipolar/bipolar) of both analog input and output.

```
ROUTe:CHANnel:POLarity? (@<ch_list>)
```

The query command returns a string value. This string value is the polarity (unipolar/bipolar) of both specified analog inputs and outputs. Multiple responses are separated by commas.

### Supported Model

U2351A, U2352A, U2353A, U2354A, U2355A, U2356A, U2331A

### Parameters

Item	Type	Range of Values	Default Value
<mode>	String	UNIPolar: Unipolar polarity BIPolar: Bipolar polarity	BIPolar
<ch_list>	Numeric	Single-ended mode: U2351A/U2352A/U2353A/U2354A: 101-116 U2355A/U2356A/U2331A: 101-164 Differential mode: U2351A/U2352A/U2353A/U2354A: 101-108 U2355A/U2356A/U2331A: 101-132	N/A

### Remarks

Will return error code if OUTPUT ON.

### Query Returned Format

```
<mode> ::= {UNIPolar|BIPolar}
```

**See Also**

[ROUTE:CHANnel:POLarity](#)

[ROUTE:CHANnel:STYPe](#)

## ROUTe:CHANnel:STYPe

### Syntax

```
ROUTe:CHANnel:STYPe <mode>, (@<ch_list>)
```

This command is used to set the reference ground selection of the specified analog input channel.

```
ROUTe:CHANnel:STYPe? (@<ch_list>)
```

The query command returns a string value representing the signal type of both specified analog inputs and outputs. Multiple responses are separated by commas.

### Supported Model

U2351A, U2352A, U2353A, U2354A, U2355A, U2356A, U2331A

### Parameters

Item	Type	Range of Values	Default Value
<mode>	String	DIFF: Differential mode SING: Referenced single-ended mode (16/64 ch common to ground system on board) NRS: Non-referenced single-ended mode (16/64 ch common to AISENSE pin)	SING
<ch_list>	Numeric	Single-ended mode: U2351A/U2352A/U2353A/U2354A: 101-116 U2355A/U2356A/U2331A: 101-164 Differential mode: U2351A/U2352A/U2353A/U2354A: 101-108 U2355A/U2356A/U2331A: 101-132	N/A

**Remarks**

Some channels only support SING and NRS mode. For example, channels 108 to 116 for U2351A, U2352A, U2353A and U2354A; channels 132 to 164 for U2355A, U2356A and U2331A.

**Query Returned Format**

<mode> ::= {DIFF|SING|NRS}

## ROUTe:CHANnel:RSouRCe

### Syntax

```
ROUTe:CHANnel:RSouRCe <mode>, (@<ch_list>)
```

This command is used to set the reference voltage source of the analog output.

```
ROUTe:CHANnel:RSouRCe? (@<ch_list>)
```

The query command returns a string value, which represents the voltage source for the specified analog output. Multiple responses are separated by commas.

### Supported Model

U2351A, U2353A, U2355A, U2356A, U2331A

### Parameters

Item	Type	Range of Values	Default Value
<mode>	String	INTernal: Internal reference EXTernal: External reference	INTernal
<ch_list>	Numeric	U2351A: 202 through 202 U2353A/U2355A/U2356A/U2331A: 201 through 202	N/A

### Query Returned Format

```
<mode> ::= {INTernal|EXTernal}
```

## ROUTE:CHANnel:RVOLtage

### Syntax

```
ROUTE:CHANnel:RVOLtage <value>, (@<ch_list>)
```

This command is used to set the voltage value of the external reference ENABLEvoltage source of the analog outputs.

```
ROUTE:CHANnel:RVOLtage? (@<ch_list>)
```

The query command returns a numeric value that represents the external reference voltage value in volts for analog outputs.

### Supported Model

U2351A, U2353A, U2355A, U2356A, U2331A

### Parameters

Item	Type	Range of Values	Default Value
<value>	Numeric	From 0 to 10, if the D/A reference voltage source is the external reference.	10
<ch_list>	Numeric	Single-ended mode: U2351A/U2352A/U2353A/U2354A: 101-116 U2355A/U2356A/U2331A: 101-164 Differential mode: U2351A/U2352A/U2353A/U2354A: 101-108 U2355A/U2356A/U2331A: 101-132	N/A

### Remarks

- It will return an error code if OUTPUT ON.
- The reference voltage value cannot be set to zero.

### Query Returned Format

```
<value> [V]
```

**See Also**

[ROUTE:CHANnel:RSouRCe](#)



## ROUTE:ENABLE

### Syntax

```
ROUTE:ENABLE <mode>, <@ch_list>
```

This command is used to enable or disable the signal route for output operations. By enabling a channel, electrical signal is allowed to pass through that enabled channel. Likewise, by disabling a particular channel, electrical signal is not allowed to pass through the said channel.

```
ROUTE:ENABLE? <@ch_list>
```

The query returns a 1 indicating that the specified channel is enabled; and 0 if the specified channel is disabled. Multiple responses are separated by commas.

### Supported Model

U2351A, U2353A, U2355A, U2356A, U2331A

### Parameters

Item	Type	Range of Values	Default Value
<ch_list>	Numeric	201 to 202	N/A
<mode>	String	OFF 0 ON 1	0

### Return Format

1 or 0

### Example

```
ROUTE:ENABLE ON, (@201:202)
```

```
//Enable channels 201 and 202 for analog output
```

```
ROUTE:ENABLE?
```

### See Also

[APPLY?](#)

[APPLY:SINusoid](#)

[APPLY:SQUare](#)

[APPLY:SAWTooth](#)

[APPLY:TRIangle](#)

[APPLY:NOISe](#)

[APPLY:USER](#)

[OUTPut](#)

[OUTPut:WAVeform:ITERate](#)

[OUTPut:WAVeform:SRATE](#)

[OUTPut:WAVeform:FREQuency](#)



## 11 SENSe Subsystem

[SENSe:]VOLTage:RANGe	100
[SENSe:]VOLTage:POLarity	102
[SENSe:]VOLTage:STYPe	104
[SENSe:]COUNter:FUNCTion	106
[SENSe:]COUNter:ABORt	108
[SENSe:]COUNter:GATE:POLarity	109
[SENSe:]COUNter:GATE:SOURce	111
[SENSe:]COUNter:GATE:CONTRol	112
[SENSe:]COUNter:CLock:INTernal?	113
[SENSe:]COUNter:CLock:EXTernal?	114
[SENSe:]COUNter:CLock:POLarity	115
[SENSe:]COUNter:CLock:SOURce	116
[SENSe:]COUNter:TOTalize:IVALue	117
[SENSe:]COUNter:TOTalize:INITiate	118
[SENSe:]COUNter:TOTalize:CLEar	119
[SENSe:]COUNter:TOTalize:UDOWn:SOURce	120
[SENSe:]COUNter:TOTalize:UDOWn:DIRection	121

This chapter explains how the SENSe command subsystem is used to acquire the properties of analog input such as range, polarity, function, signal type, and others.



**[SENSe:]VOLTage:RANGe****Syntax**

```
[SENSe:]VOLTage:RANGe <range>, (@<ch_list>)
```

This command is used to set or inquire the analog input (AI) range of the specified channel. It selects the voltage measurement range of the designated channels.

```
[SENSe:]VOLTage:RANGe? (@<ch_list>)
```

The query returns a discrete value representing the voltage value for current input voltage on each specified analog input channel. Multiple responses are separated by commas.

**Supported Model**

U2351A, U2352A, U2353A, U2354A, U2355A, U2356A, U2331A

**Parameters**

Item	Type	Range of Values	Default Value
<range>	Discrete	U2331A: Unipolar mode: {AUTO 10 5 4 2.5 2.0 1.0 0.5 0.4 0.1} Bipolar mode: {AUTO 10 5 2.5 2.0 1.25 1.0 0.5 0.25 0.2 0.05} U2351A/U2352A/U2353A/U2354A/U2355A/ U2356A: Unipolar Bipolar mode: {AUTO 10 5 2.5 1.25}	AUTO
<ch_list>	Numeric	Single-ended mode: U2351A/U2352A/U2353A/U2354A: 101-116 U2355A/U2356A/U2331A: 101-164 Differential mode: U2351A/U2352A/U2353A/U2354A: 101-108 U2355A/U2356A/U2331A: 101-132	N/A

**Query Returned Format**

```
<range> [V]
```

**Example**

```
*RST;*CLS
ROUTE:SCAN (@101)
VOLTage:RANGE 10, (@101)
//Bipolar with range input of -10 V to +10 V
MEASure:VOLTage? (@101)
```

**See Also**

[SOURCE:VOLTage:POLarity](#)

[\[SENSe:\]VOLTage:STYPe](#)

## [SENSE:]VOLTage:POLarity

### Syntax

```
[SENSE:]VOLTage:POLarity <polarity>, (@<ch_list>)
```

This command is used to set the polarity of the analog input channel.

```
[SENSE:]VOLTage:POLarity? (@<ch_list>)
```

The query command returns a string value that represents the mode of polarity on each specified analog input channel. Multiple responses are separated by comma.

### Supported Model

U2351A, U2352A, U2353A, U2354A, U2355A, U2356A, U2331A

### Parameters

Item	Type	Range of Values	Default Value
<polarity>	String	UNIPolar: Unipolar polarity BIPolar: Bipolar polarity	BIPolar
<ch_list>	Numeric	Single-ended mode: U2351A/U2352A/U2353A/U2354A: 101-116 U2355A/U2356A/U2331A: 101-164 Differential mode: U2351A/U2352A/U2353A/U2354A: 101-108 U2355A/U2356A/U2331A: 101-132	N/A

### Remarks

- Mutually independent with [ROUTE:CHANnel:POLarity](#).

### Query Returned Format

```
<polarity> ::= {UNIPolar|BIPolar}
```

**Example**

```
[:SENSe:]VOLTage:POLarity UNIPolar, (@101)
[:SENSe:]VOLTage:STYPe SING, ( @101)
[:SENSe:]VOLTage:RANGe 10, (@101)
MEASure:VOLTage:DC? (@101)
```

**See Also**

[\[SENSe:\]VOLTage:STYPe](#)

## [SENSe:]VOLTage:STYPe

### Syntax

```
[SENSe:]VOLTage:STYPe <mode>, (@<ch_list>)
```

This command is used to set the reference ground of the specified analog input channel.

```
[SENSe:]VOLTage:STYPe? (@<ch_list>)
```

The query command returns a string value representing the reference ground of the specified analog input channel. Multiple responses are separated by comma.

### Supported Model

U2351A, U2352A, U2353A, U2354A, U2355A, U2356A, U2331A

### Parameters

Item	Type	Range of Values	Default Value
<mode>	String	DIFF: Differential mode SING: Referenced single-ended mode (16/64 ch common to ground system on board) NRS: Non-referenced single-ended mode (16/64 ch common to AISENSE pin)	SING
<ch_list>	Numeric	Single-ended mode: U2351A/U2352A/U2353A/U2354A: 101-116 U2355A/U2356A/U2331A: 101-164 Differential mode: U2351A/U2352A/U2353A/U2354A: 101-108 U2355A/U2356A/U2331A: 101-132	N/A



**Remarks**

- For U2355A/U2356A/U2331A; if Channel 101 is configured to "DIFF" mode, channel 133 will be N/A, 134 will be 102, and so on. Likewise, if channel 102 is set to "DIFF" mode, channel 134 will be N/A until channel 102 is set to back to "SING" mode again.
- For U2351A/U2352A/U2353A/U2354A; if Channel 101 is configured to "DIFF" mode, channel 109 will be N/A. Likewise, channel 102 and 110 are paired in "DIFF" mode.

**Query Returned Format**

```
<mode> ::= {DIFF|SING|NRS}
```

**Example**

```
[:SENSe:]VOLTage:POLarity UNIPolar, (@101)
[:SENSe:]VOLTage:STYPe SING, (@101)
[:SENSe:]VOLTage:RANGe 10, (@101)
MEASure:VOLTage:DC? (@101)
```

## [SENSE:]COUNTER:FUNCTION

### Syntax

```
[SENSE:]COUNTER:FUNCTION <mode>, (@<ch_list>)
```

This command selects the present measurement function on the specified counter channels on the USB DAQ. Valid options are frequency, period, pulse width, or totalize.

```
[SENSE:]COUNTER:FUNCTION? (@<ch_list>)
```

The query command returns a string value representing the present measurement function on each counter channel specified. Multiple responses are separated by comma.

### Supported Model

U2351A, U2352A, U2353A, U2354A, U2355A, U2356A, U2331A

### Parameters

Item	Type	Range of Values	Default Value
<mode>	String	FREQUENCY: returns the measured frequency PERIOD: returns the measured period PWIDTH: returns the measured pulse width TOTALIZE: returns the count on the specified totalizer channels	TOTALIZE
<ch_list>	Numeric	301 through 302	N/A

### Query Returned Format

```
<mode> ::= {FREQUENCY|PERIOD|PWIDTH|TOTALIZE}
```

### See Also

[MEASURE:COUNTER:DATA?](#)

**Example**

```
[:SENSe:]COUNter:FUNCTion TOTAlize (@301)
[:SENSe:]COUNter:TOTAlize:INITiate
MEASure:COUNter:DATA? (@301)
MEASure:COUNter:TOTAlize? (@301)
[:SENSe:]COUNter:ABORT (@301)
```

## [SENSe:]COUNter:ABORt

### Syntax

```
[SENSe:]COUNter:ABORt (@<ch_list>)
```

This command aborts an initiated counter measurement in progress on the specified counter channels. This command may be effective to abort a long internally-gated or externally-gated measurement.

### Supported Device

U2351A, U2352A, U2353A, U2354A, U2355A, U2356A, U2331A

### Parameters

Item	Type	Range of Values	Default Value
<ch_list>	Numeric	301 through 302	N/A

### Remarks

This command does not clear or invalidate any measurement in memory.

### Example

```
[[:SENSe:]COUNter:FUNCTION TOTALize (@301)
[:SENSe:]COUNter:TOTALize:INITiate (@301)
[:SENSe:]COUNter:ABORt (@301)
```

### See Also

[\[SENSe:\]COUNter:TOTALize:CLEar](#)

## [SENSe:]COUNter:GATE:POLarity

### Syntax

```
[SENSe:]COUNter:GATE:POLarity <mode>, (@<ch_list>)
```

This command sets the logic polarity of the Gate input line for counter operations. You can specify the gate polarity as "active high" or "active low". Changing the gate polarity while an initiated measurement is in progress is not allowed.

```
[SENSe:]COUNter:GATE:POLarity? (@<ch_list>)
```

The query command returns a string value that indicates the polarity type of gate configuration on each specified counter channel. Multiple responses are separated by comma.

### Supported Model

U2351A, U2352A, U2353A, U2354A, U2355A, U2356A, U2331A

### Parameters

Item	Type	Range of Values	Default Value
<mode>	String	AHI: Active High ALO: Active Low	AHI
<ch_list>	Numeric	301 through 302	N/A

### Query Returned Format

```
<mode> ::= {AHI|ALO}
```

### Example

```
[ :SENSe:]COUNter:FUNCTion TOTAlize, (@301)
[ :SENSe:]COUNter:TOTAlize:INITiate (@301)
[ :SENSe:]COUNter:GATE:POLarity AHI, (@301)
[ :SENSe:]COUNter:GATE:SOURce INT, (@301)
[ :SENSe:]COUNter:GATE:CONTrol DIS, (@301)
COUNter:GATE:CONTrol
MEASure:COUNter:TOTAlize?
[ :SENSe:]COUNter:ABORT
```

## [SENSe:]COUNter:GATE:SOURce

### Syntax

```
[SENSe:]COUNter:GATE:SOURce <mode>, (@<ch_list>)
```

This command selects the gate source for counter measurements. You can select either the internal (default) source or an external gate signal. You are recommended not to change the gate source when the data acquisition is in progress.

```
[SENSe:]COUNter:GATE:SOURce? (@<ch_list>)
```

The query command returns a string value representing the gate source setting for general purpose digital counter on each specified counter channel. Multiple responses are separated by comma.

### Supported Model

U2351A, U2352A, U2353A, U2354A, U2355A, U2356A, U2331A

### Parameters

Item	Type	Range of Values	Default Value
<mode>	String	INTernal: Gate is controlled by software EXTernal: Gate is controlled by COUNT301_GATE/ COUNT302_GATE pins	INTernal
<ch_list>	Numeric	301 through 302	N/A

### Query Returned Format

```
<mode> ::= {INTernal|EXTernal}
```

## [SENSE:]COUNTER:GATE:CONTROL

### Syntax

```
[SENSE:]COUNTER:GATE:CONTROL <mode>, (@<ch_list>)
```

This command is used set the gate status (enable/disable) of the general purpose digital counter.

```
[SENSE:]COUNTER:GATE:CONTROL? (@<ch_list>)
```

The query command returns a string value representing the gate status on each specified counter channel. Multiple responses are separated by comma.

### Supported Model

U2351A, U2352A, U2353A, U2354A, U2355A, U2356A, U2331A

### Parameters

Item	Type	Range of Values	Default Value
<mode>	String	DIS: Stop counter operation ENAB: Start counter operation	DIS
<ch_list>	Numeric	301 through 302	N/A

### Query Returned Format

```
<mode> ::= {DIS|ENAB}
```

### See Also

[\[SENSE:\]COUNTER:TOTALize:CLEar](#)



## [SENSe:]COUNter:CLocK:INTernal?

### Syntax

```
[SENSe:]COUNter:CLocK:INTernal?
```

The query returns a discrete value representing the internal time base frequency in kHz on each specified counter channel of the general purpose digital counter.

### Supported Model

U2351A, U2352A, U2353A, U2354A, U2355A, U2356A, U2331A

### Parameters

Item	Type	Range of Values	Default Value
<value>	Discrete	N/A	12000 kHz

### Remarks

- This query has only one default value.
- Refer to the *Agilent U2300A Series USB Multifunction DAQ User's Guide* for more information on general purpose digital counter operations.

### Query Returned Format

```
<value> [kHz]
```

## [SENSe:]COUNter:CLocK:EXTernal?

### Syntax

```
[SENSe:]COUNter:CLocK:EXTernal? (@<ch_list>)
```

The query returns a float value representing the external time base frequency in kHz on each specified counter channel of the general purpose digital counter.

### Supported Model

U2351A, U2352A, U2353A, U2354A, U2355A, U2356A, U2331A

### Parameters

Item	Type	Range of Values	Default Value
<value>	Float	1 MHz to 10 MHz	0
<ch_list>	Numeric	301 through 302	N/A

### Remarks

Refer to the *Agilent U2300A Series USB Multifunction DAQ User's Guide* for more information on general purpose digital counter operations.

### Query Returned Format

```
<value> [kHz]
```

## [SENSe:]COUNter:CLocK:POLarity

### Syntax

```
[SENSe:]COUNter:CLocK:POLarity <mode>, (@<ch_list>)
```

This command is used to set the clock polarity settings of the general purpose counter.

```
[SENSe:]COUNter:CLocK:POLarity? (@<ch_list>)
```

The query command returns a string value that represents the clock polarity settings of specified counter channel of the general purpose digital counter. Multiple responses are separated by comma.

### Supported Model

U2351A, U2352A, U2353A, U2354A, U2355A, U2356A, U2331A

### Parameters

Item	Type	Range of Values	Default Value
<mode>	String	AHI: Active High ALO: Active Low	AHI
<ch_list>	Numeric	301 through 302	N/A

### Query Returned Format

```
<mode> ::= {AHI|ALO}
```

## [SENSE:]COUNTER:CLock:SOURce

### Syntax

```
[SENSE:]COUNTER:CLock:SOURce <mode>, (@<ch_list>)
```

This command is used to set the clock source of the general purpose digital counter.

```
[SENSE:]COUNTER:CLock:SOURce? (@<ch_list>)
```

The query command returns a string value representing the clock source settings of the general purpose digital counter. Multiple responses are separated by comma.

### Supported Model

U2351A, U2352A, U2353A, U2354A, U2355A, U2356A, U2331A

### Parameters

Item	Type	Range of Values	Default Value
<mode>	String	INTernal: Gate is controlled by software EXTernal: Gate is controlled by COUNT301_CLK/COUNT302_CLK pin	INTernal
<ch_list>	Numeric	301 through 302	N/A

### Query Returned Format

```
<mode> ::= {INTernal|EXTernal}
```

## [SENSe:]COUNter:TOTalize:IVALue

### Syntax

```
[SENSe:]COUNter:TOTalize:IVALue <value>, (@<ch_list>)
```

This command sets the initial counter value of the general purpose digital counter.

```
[SENSe:]COUNter:TOTalize:IVALue? (@<ch_list>)
```

The query command returns a numeric value representing the initial counter value of the general purpose digital counter. Multiple responses are separated by comma.

### Supported Model

U2351A, U2352A, U2353A, U2354A, U2355A, U2356A, U2331A

### Parameters

Item	Type	Range of Values	Default Value
<value>	Numeric	From 0 to 2147483647 ( $2^{31} - 1$ )	0
<ch_list>	Numeric	301 through 302	N/A

### Query Returned Format

```
<value>
```

## [SENSE:]COUNTER:TOTALize:INITiate

### Syntax

```
[SENSE:]COUNTER:TOTALize:INITiate (@<ch_list>)
```

This command initiates a counter measurement on the USB DAQ device. Gating begins once the counter measurement is initiated.

### Supported Model

U2351A, U2352A, U2353A, U2354A, U2355A, U2356A, U2331A

### Parameters

Item	Type	Range of Values	Default Value
<ch_list>	Numeric	301 through 302	N/A

### Example

```
[::SENSE:]COUNTER:FUNCTION TOTALize, (@301)
[::SENSE:]COUNTER:TOTALize:INITiate (@301)
MEASURE:COUNTER:TOTALize? (@301)
[::SENSE:]COUNTER:ABORT
```

## [SENSe:]COUNter:TOTalize:CLEar

### Syntax

```
[SENSe:]COUNter:TOTalize:CLEar (@<ch_list>)
```

This command clears all the operation of the general purpose digital counter.

### Supported Device

U2351A, U2352A, U2353A, U2354A, U2355A, U2356A, U2331A

### Parameters

Item	Type	Range of Values	Default Value
<ch_list>	Numeric	301 through 302	N/A

### Remarks

This command clears to zero. However, this is not the initialization value.

## [SENSE:]COUNTER:TOTALize:UDOWN:SOURce

### Syntax

```
[SENSE:]COUNTER:TOTALize:UDOWN:SOURce <mode>, (@<ch_list>)
```

This command is used to set the clock source of the general purpose digital counter on the up/down counting process.

```
[SENSE:]COUNTER:TOTALize:UDOWN:SOURce? (@<ch_list>)
```

The query command returns a string value that indicates the clock source of the general purpose digital counter.

### Supported Model

U2351A, U2352A, U2353A, U2354A, U2355A, U2356A, U2331A

### Parameters

Item	Type	Range of Values	Default Value
<mode>	String	INTERNAL: Gate is controlled by software EXTERNAL: Gate is controlled by COUNT301_UPDOWN/ COUNT302_UPDOWN pin	INTERNAL
<ch_list>	Numeric	301 through 302	N/A

### Query Returned Format

```
<mode> ::= {INTERNAL|EXTERNAL}
```



## [SENSe:]COUNter:TOTalize:UDOWn:DIRection

### Syntax

```
[SENSe:]COUNter:TOTalize:UDOWn:DIRection <mode>,
(@<ch_list>)
```

This command is used to set the up or down counting process.

```
[SENSe:]COUNter:TOTalize:UDOWn:DIRection? (@<ch_list>)
```

The query command returns a string value that indicates the up or down direction count direction of each specified counter channel. Multiple responses are separated by comma.

### Supported Model

U2351A, U2352A, U2353A, U2354A, U2355A, U2356A, U2331A

### Parameters

Item	Type	Range of Values	Default Value
<mode>	String	UP: Up counting DOWN: Down counting	UP
<ch_list>	Numeric	301 through 302	N/A

### Query Returned Format

```
<mode> ::= {UP|DOWN}
```





## 12 SOURce Subsystem

SOURce:VOLTage[:LEVel]	124
SOURce:VOLTage:POLarity	125
SOURce:VOLTage:RSouRce	126
SOURce:VOLTage:RVOLTage	127
SOURce:DIGital:DATA	128
SOURce:DIGital:DATA:BIT	130
SOURce:COUNter:OUTPut:POLarity	132

This chapter contains information on the SOURce command subsystem. It also includes the commands on the general purpose digital counter.



## SOURCE:VOLTage[:LEVel]

### Syntax

SOURCE:VOLTage[:LEVel] <value>, (@<ch\_list>)

This command receives a voltage value, scales it to the proper binary value and writes a binary value to the designated analog output channel. This command sets the output voltage level for the specified DAC channels. After setting the desired level, the command closes the corresponding output relay and enable outputs from the specified channels.

SOURCE:VOLTage[:LEVel]? (@<ch\_list>)

The query command returns a numeric value representing the output voltage level in volts for the specified DAC channels on each analog channel specified. Multiple responses are separated by commas.

### Supported Model

U2351A, U2353A, U2355A, U2356A, U2331A

### Parameters

Item	Type	Range of Values	Default Value
<value>	Numeric	-10 V ~ +10 V (12 bits resolution)	0
<ch_list>	Numeric	201 through 202	N/A

### Remarks

- This command is not allowed when "OUTPut ON" is set.
- Not supported for U2352A and U2354A.

### Query Returned Format

<value> [V]

## SOURCE:VOLTage:POLarity

### Syntax

SOURCE:VOLTage:POLarity <mode>, (@<ch\_list>)

This command sets the polarity (unipolar/bipolar) of the output channel.

SOURCE:VOLTage[:POLarity]? (@<ch\_list>)

The query command returns a string value representing the polarity of the specified output channel. Multiple responses are separated by commas.

### Supported Model

U2351A, U2353A, U2355A, U2356A, U2331A

### Parameters

Item	Type	Range of Values	Default Value
<mode>	String	UNIPolar: Unipolar BIPolar: Bipolar	BIPolar
<ch_list>	Numeric	201 through 202	N/A

### Remarks

- Will force reset voltage level to zero, if the voltage output at negative voltage.
- Not supported for U2352A and U2354A.

### Query Returned Format

<mode> ::= {UNIPolar|BIPolar}

**SOURce:VOLTage:RSouRCe****Syntax**

```
SOURce:VOLTage:RSouRCe <mode>, (@<ch_list>)
```

This command used to set the reference voltage source (internal/external) for the output channel.

```
SOURce:VOLTage:RSouRCe? (@<ch_list>)
```

The query command returns a string value that represents the reference voltage source of the output channel specified. Multiple responses are separated by commas.

**Supported Model**

U2351A, U2353A, U2355A, U2356A, U2331A

**Parameters**

Item	Type	Range of Values	Default Value
<mode>	String	INTernal: Internal reference EXTernal: External reference	INTernal
<ch_list>	Numeric	201 through 202	N/A

**Remarks**

- Will force reset voltage level to zero once the reference source is changed.
- Not applicable for U2352A and U2354A.

**Query Returned Format**

```
<mode> ::= {INTernal|EXTernal}
```

## SOURce:VOLTage:RVOLTage

### Syntax

SOURce:VOLTage:RVOLTage <value>

This command used to set the voltage value of the reference voltage once SOURce:VOLTage:RSouRCe command is set to external.

SOURce:VOLTage:RVOLTage?

The query command returns a numeric value representing voltage value of the reference voltage in units of volts of the output channels.

### Supported Model

U2351A, U2352A, U2353A, U2354A, U2355A, U2356A, U2331A

### Parameters

Item	Type	Range of Values	Default Value
<value>	Numeric	Reference voltage value (0 to 10)	10

### Remarks

- Cannot reset to zero.
- Not applicable for U2352A and U2354A.

### Query Returned Format

<value> [V]

## SOURCE:DIGITAL:DATA

### Syntax

```
SOURCE:DIGITAL:DATA <value>, (@<ch_list>)
```

This command outputs a 4 or 8-bit digital pattern to the specified digital output channels. The specified channels have to be configured as OUTPUT, prior to sourcing any digital data.

```
SOURCE:DIGITAL:DATA? (@<ch_list>)
```

The query returns a value representing the digital data of the specific channel. Multiple responses are separated by commas.

### Supported Model

U2351A, U2352A, U2353A, U2354A, U2355A, U2356A, U2331A

### Parameters

Item	Type	Range of Values	Default Value
<value>	Numeric	Counter Channel 501 and 502: 0 through 255 Counter Channel 503 and 504: 0 through 15	0
<ch_list>	Numeric	U2351A/U2353A/U2355A/U2356A/U2331A: 501 through 504 Port A: Channel 501 (8 bits) Port B: Channel 502 (8 bits) Port C: Channel 503 (4 bits) Port D: Channel 504 (4 bits)	N/A



**Remarks**

- Prior to using this command, the DIO channel/port has to be configured as OUTPUT; else a system error will be generated.
- Using this command or query right after \*RST will also generate a system error. This is because after a system reset, the DIO channel/port is set to INPUT.

**Query Returned Format**

<value>

**See Also:**

[CONFigure:DIGital:DIRection](#)

## SOURCE:DIGital:DATA:BIT

### Syntax

SOURCE:DIGital:DATA:BIT <value>, <bit>, (@<ch\_list>)

This command sets or clears individual bits on the specified digital output channels. The specified channels have to be configured as OUTPUT, prior to sourcing any digital data. Please note that once a channel is configured as OUTPUT, all bits within that channel are set as output.

SOURCE:DIGital:DATA:BIT? <bit>, (@<ch\_list>)

The query returns a value of 1 (logic High) or 0 (logic Low) for the specified bit within the specified channel.

### Supported Model

U2351A, U2352A, U2353A, U2354A, U2355A, U2356A, U2331A

### Parameters

Item	Type	Range of Values	Default Value
<value>	Integer	0 or 1	0
<bit>	Integer	Counter Channel 501 and 502: 0 through 7 Counter Channel 503 and 504: 0 through 3	0
<ch_list>	Numeric	U2351A/U2353A/U2355A/U2356A/U2331A: 501 through 504 Port A: Channel 501 Port B: Channel 502 Port C: Channel 503 Port D: Channel 504	N/A

### Remarks

- Prior to using this command, the DIO channel/port has to be configured as OUTPUT; else a system error will be generated.
- Using this command or query right after \*RST will also generate a system error. This is because after a system reset, the DIO channel/port is set to INPUT.

**Query Returned Format**

<value>, <bit>

**See Also:**

[CONFigure:DIGital:DIRection](#)

## SOURCE:COUNTER:OUTPUT:POLarity

### Syntax

```
SOURCE:COUNTER:OUTPUT:POLarity <mode>, (@<ch_list>)
```

This command sets the output polarity of the general purpose digital counter.

```
SOURCE:COUNTER:OUTPUT:POLarity? (@<ch_list>)
```

The query command returns a string value representing the output polarity for general purpose digital counter. Multiple responses are separated by commas.

### Supported Device

U2351A, U2352A, U2353A, U2354A, U2355A, U2356A, U2331A

### Parameters


Item	Type	Range of Values	Default Value
<mode>	String	AHI: Active High ALO: Active Low	AHI
<ch_list>	Numeric	301 through 302	N/A

### Remarks

Pulse generation for active high or active low for every event count.

### Query Returned Format

```
<mode> ::= {AHI|ALO}
```



## 13 SYSTem Subsystem

SYSTem:CDEscription? [134](#)

SYSTem:ERRor? [135](#)

This chapter explains the SYSTem subsystem command for identification purpose.



## SYSTem:CDEscription?

### Syntax

```
SYSTem:CDEscription?
```

This query is used when the USB DAQ device is slotted into the U2781A modular instrument chassis. It identifies which slot is the module plugged into.

### Supported Model

U2351A, U2352A, U2353A, U2354A, U2355A, U2356A, U2331A

### Remarks

- It is only applicable when the DAQ module is used in the modular instrument chassis.
- It works in conjunction with the SYSTem:IDentity command (with the modular instrument chassis).
- For more details, refer to the *U2781A USB Modular Instrument Chassis User's Guide*.

## SYSTEM:ERRor?

### Syntax

SYSTEM:ERRor?

This query reads and clears one error from the instrument's error queue.

### Remarks

- Errors are retrieved in first-in-first-out (FIFO) order. The first error returned is the first error that was stored. Once you have read all of the interface-specific errors, the errors in the global error queue are retrieved.
- Errors are cleared as you read them.
- If more errors occur than the error queue is capable of storing, the last error stored in the queue (the most recent error) will be replaced with -350, "Error queue overflow". No additional errors are stored until you remove errors from the queue. If no errors have occurred when you read the error queue, the instrument responds with +0, "No error".
- SYSTEM:ERRor? will read and clear one error from the queue.
- Error conditions are also summarized in the Status Byte Register.
- The interface-specific and global error queues are cleared by the clear status (\*CLS) command and when power is cycled. The errors are also cleared when you read the error queue. The error queue will not be cleared by a factory reset (\*RST) command or an instrument preset (SYSTEM:PRESet) command.
- Refer to [Chapter 16, "Error Messages,"](#) on page 155 for more information.

### Return Format

The command reads and clears one error string from the error queue. The error string consists of an error number and an error string enclosed in double quotes.

For example:

-113, "Undefined header"

### Example

The following query reads and clears one error.

```
SYSTEM:ERRor?
```

Typical Response:

```
-101, "Invalid character"
```

### See Also

[\\*SRE](#)





## 14 TRIGger Subsystem

TRIGger:SOURce	138
TRIGger:TYPe	139
TRIGger:DCouNT	140
TRIGger:ATRIgger:SOURce	141
TRIGger:ATRIgger:HTHReshold	143
TRIGger:ATRIgger:LTHReshold	144
TRIGger:ATRIgger:CONDition	145
TRIGger:DTRIGGER:POLarity	146

This chapter contains all the TRIGger subsystem commands that are used to program the U2300A Series multifunction USB DAQ devices.



## TRIGger:SOURce

### Syntax

TRIGger:SOURce <mode>

This command is used to set the source of the A/D trigger control.

TRIGger:SOURce?

The query command returns a string value representing the source for A/D trigger control.

### Supported Model

U2351A, U2352A, U2353A, U2354A, U2355A, U2356A, U2331A

### Parameters

Item	Type	Range of Values	Default Value
<mode>	String	NONE : Immediate EXTD: From external digital trigger source EXTA: From analog trigger pin STRG: Clock source by star trigger	NONE

### Remarks

Only POST trigger is allowed when trigger source is in NONE mode.

### Query Returned Format

<mode> ::= { NONE | EXTD | EXTA | STRG }

## TRIGger:TYPe

### Syntax

TRIGger:TYPe <mode>

This command is used to set the type of the A/D source.

TRIGger:TYPe?

The query command returns a string value that indicates the setting for A/D mode selection.

### Supported Model

U2351A, U2352A, U2353A, U2354A, U2355A, U2356A, U2331A

### Parameters

Item	Type	Range of Values	Default Value
<mode>	String	POST: Post Trigger Mode PRE: Pre-Trigger Mode MID: Middle-Trigger Mode DEL: Delay Trigger Mode	POST

### Remarks

- All trigger types are supported in one-shot acquisition. It is invoked by [DIGitize](#) command.
- For continuous analog input and output mode, only POST and DELAY types are supported.

### Query Returned Format

<mode> ::= {POST|PRE|MID|DEL}

### See Also

[TRIGger:SOURce](#)

## TRIGger:DCouNT

### Syntax

TRIGger:DCouNT <value>

This command is used to set the counter value of delay trigger mode.

TRIGger:DCouNT?

The query command returns an integer value of delay trigger mode.

### Supported Model

U2351A, U2352A, U2353A, U2354A, U2355A, U2356A, U2331A

### Parameters

Item	Type	Range of Values	Default Value
<value>	Integer	From 0 to 2147483647 ( $2^{31} - 1$ )	0

### Query Returned Format

<value>

## TRIGger:ATRIgger:SOURce

### Syntax

```
TRIGger:ATRIgger:SOURce <src>
```

This function sets the physical pin for the analog trigger.

```
TRIGger:ATRIgger:SOURce?
```

The query command returns a string value representing the trigger source selection of analog trigger control.

### Supported Device

U2351A, U2352A, U2353A, U2354A, U2355A, U2356A, U2331A

### Parameters

Item	Type	Range of Values	Default Value
<src>	String	EXTAP: From external analog trigger pin SONE: Source from first scanned channel for multiplexing DAQ device	EXTAP

### Remarks

- Only post and pre-trigger modes can be used if trigger source is set to SONE.
- Input range should be configured well. The HTHReshold must be less than the maximum input range while the LTHReshold must be larger than minimum input range.
- To activate SONE trigger, users are required to run the DIGitize command before or after analog output ("OUTPut ON").
- The SONE trigger detection only comes into effect during the DIGitize command execution.
- The SONE parameter refers to the first entry in ROUTe:SCAN command.

### Query Returned Format

```
<src> ::= {EXTAP|SONE}
```

## 14 TRIGger Subsystem

### See Also

TRIGger:SOURce

TRIGger:TYPe

TRIGger:ATRIgger:HTHReshold

TRIGger:ATRIgger:LTHReshold

TRIGger:ATRIgger:CONDition

ROUTE:SCAN

## TRIGger:ATRIgger:HTHReshold

### Syntax

TRIGger:ATRIgger:HTHReshold <value>

This command is used to set the high threshold for analog trigger control.

TRIGger:ATRIgger:HTHReshold?

The query command returns a float value that represents the high threshold in volts for analog trigger cLTHResholdcontrol.

### Supported Model

U2351A, U2352A, U2353A, U2354A, U2355A, U2356A, U2331A

### Parameters

Item	Type	Range of Values	Default Value
<value>	Float	-10 V to +10 V	0

### Remarks

If SONE mode is selected by [TRIGger:ATRIgger:SOURce](#) command, the threshold will be limited by the RANGE configuration of the first channel in the scan list.

### Query Returned Format

<value> [V]

### See Also

[TRIGger:ATRIgger:LTHReshold](#)

## TRIGger:ATRIgger:LTHReshold

### Syntax

```
TRIGger:ATRIgger:LTHReshold <value>
```

This command is used to set the low threshold voltage for analog trigger control.

```
TRIGger:ATRIgger:LTHReshold?
```

The query command returns a float value representing the low threshold voltage for analog trigger control.

### Supported Model

U2351A, U2352A, U2353A, U2354A, U2355A, U2356A, U2331A

### Parameters

Item	Type	Range of Values	Default Value
<value>	Float	-10 V to +10 V	0

### Remarks

- Only post and delay trigger modes can be used if the trigger source is SONE.
- If SONE mode is selected by command [TRIGger:ATRIgger:SOURce](#), the threshold voltage will be limited by the range configuration of the first channel of the scan list.

### Query Returned Format

```
<value> [V]
```

### See Also

[TRIGger:ATRIgger:LTHReshold](#)



## TRIGger:ATRIgger:CONDition

### Syntax

```
TRIGger:ATRIgger:CONDition <mode>
```

This command is used to set the trigger condition of analog trigger control.

```
TRIGger:ATRIgger:CONDition?
```

The query command returns a string value representing the trigger condition of analog trigger control.

### Supported Model

U2351A, U2352A, U2353A, U2354A, U2355A, U2356A, U2331A

### Parameters

Item	Type	Range of Values	Default Value
<mode>	String	AHIG: Above-High-Level Triggering BLOW: Below-Low-Level Triggering WIND: Inside Region Triggering	BLOW

### Remarks

The value of HTHReshold must larger than value of LTHReshold.

### Query Returned Format

```
<mode> ::= {AHIG|BLOW|WIND}
```

### See Also

[TRIGger:ATRIgger:SOURce](#)

[TRIGger:ATRIgger:HTHReshold](#)

[TRIGger:ATRIgger:LTHReshold](#)

## TRIGger:DTRiGger:POLarity

### Syntax

TRIGger:DTRiGger:POLarity <mode>

This command is used to set the polarity of the external digital trigger.

TRIGger:DTRiGger:POLarity?

The query command returns a string value representing the polarity of external digital trigger.

### Supported Model

U2351A, U2352A, U2353A, U2354A, U2355A, U2356A, U2331A

### Parameters


Item	Type	Range of Values	Default Value
<mode>	String	POS: Trigger positive edge active NEG: Trigger negative edge active	POS

### Query Returned Format

<mode> ::= { POS | NEG }

### See Also

[TRIGger:SOURce](#)



## 15 WAVeform Subsystem

WAVeform:DATA?	148
WAVeform:POINts	150
WAVeform:STATus?	152
WAVeform:COMPLete?	153

This chapter explains the WAVeform command subsystem that is used to configure the U2300A Series multifunction USB DAQ devices.



## WAVEform:DATA?

### Syntax

```
WAVEform:DATA?
```

This command is used to returns the raw data of input channels that are enabled by ROUTe:SCAN command. For example, #800000200<byte 1><byte 2>...<byte 200>, indicates that there is a total of 200 bytes of returned data. Each acquisition is made up of two bytes. The first byte is the LSB and the second one is the MSB. The sample shows that there is a total of 100 acquisition points.

### Supported Model

U2351A, U2352A, U2353A, U2354A, U2355A, U2356A, U2331A

### Remarks

- Maximum 8 Msa in DIGitize or 4 Msa in RUN.
- The length of header is fixed at eight characters.

### Example

```
*RST; *CLS

ROUTE:SCAN (@101) //Monitors only channel 101
ACQUIRE:SRATE 30000 //Set sampling rate of 30 KHz
WAVEform:POINTS 3000 //Set to read/fetch 3000 points at one time

RUN

WAVEform:STATUS? //Expect a string returned data
WAVEform:DATA? //Loop until the next STOP command is issued

STOP //Acquisition stops
```

**See Also**

ROUTE:SCAN

ACQUIRE:SRATE

WAVEform:POINTS

RUN

STOP

## WAVEform:POINTs

### Syntax

WAVEform:POINTs <value>

This command queries the number of acquisition points. Each acquisition point is made up of two bytes. Hence, setting the acquisition points to 100 implies that a block of 200 bytes of raw data is transferred to the PC when the WAVEform:DATA? command is issued.

This command-cum-query performs the same functions as “ACQUIRE:POINTs” on page 13. The only difference is that the WAVEform:POINTs command is meant for continuous acquisition. The ACQUIRE:POINTs command is meant for single-shot acquisitions.

### Supported Model

U2351A, U2352A, U2353A, U2354A, U2355A, U2356A, U2331A

### Parameters

Item	Type	Range of Values	Default Value
<value>	Numeric	< 4 Msa	500

### Remarks

- Size of block to read.
- Maximum 4 Msa.
- For continuous analog input function only.

### Example

```
ROUTE:SCAN (@101) //Monitors only channel 101
WAVEform:POINTs 100 //Sets acquisition points for channel
ROUTE:SCAN (@102,103)
WAVEform:POINTs 200 //Both channels get 100 acquisition points each
```

**See Also**

ROUTE:SCAN

ACQUIRE:SRATE

WAVEFORM:DATA?

RUN

STOP

## WAVEform:STATUS?

### Syntax

WAVEform:STATUS?

This commands queries the acquisition status of the instrument.

### Supported Model

U2351A, U2352A, U2353A, U2354A, U2355A, U2356A, U2331A

### Parameters

Item	Type	Range of Values	Default Value
<mode>	String	EPTY: Empty, no data captured FRAG: Fragment, DAQ start to measure but memory buffer block is not complete yet DATA: At least one block is complete and ready to be read back OVER: Buffer is full and the acquisition stops	EPTY

### Remarks

- For [RUN](#) command (continuous analog input mode) only.
- Buffer block.

### Query Returned Format

<mode> ::= {EPTY|FRAG|DATA|OVER}



## WAVeform:COMPLete?

### Syntax

WAVeform:COMPLete?

This command is used to query the current acquisition status of the DIGitize command.

### Supported Model

U2351A, U2352A, U2353A, U2354A, U2355A, U2356A, U2331A

### Parameters

Item	Type	Range of Values	Default Value
<mode>	String	NO: Capturing Data YES: One-Shot Function Completed	NO

### Remarks

Only for DIGitize acquisition mode. The acquisition stops only if the number of points specified by the [WAVeform:POINts](#) command is met or when a STOP command is sent.

### Query Returned Format

<mode> ::= {NO|YES}

### See Also

[DIGitize](#)

[ACQuire:SRATe](#)

[WAVeform:POINts](#)





## 16 Error Messages

This chapter lists the SCPI command error messages.



### Remarks

- Errors are retrieved in first-in-first-out (FIFO) order.
- Errors are cleared as you read them.
- If too many errors occur, the last error stored in the queue (the most recent error) is replaced with -350, "Error queue overflow". No additional errors are stored until you remove errors from the queue. If no errors have occurred when you read the error queue, the instrument responds with +0, "No error".
- SYSTem:ERRor? will read and clear one error from the queue.
- Below are the SCPI error messages:
  - 0000, "No error",
  - -100, "Command error",
  - -101, "Invalid character",
  - -102, "Syntax error",
  - -103, "Invalid separator",
  - -104, "Data type error",
  - -108, "Parameter not allowed",
  - -109, "Missing parameter",
  - -110, "Command header error",
  - -111, "Header separator error",
  - -112, "Program mnemonic too long",
  - -113, "Undefined header",
  - -114, "Header suffix out of range",
  - -120, "Numeric data error",
  - -121, "Invalid character in number",
  - -123, "Exponent too large",
  - -124, "Too many digits",
  - -128, "Numeric data not allowed",
  - -130, "Suffix error",
  - -131, "Invalid suffix",
  - -134, "Suffix too long",
  - -138, "Suffix not allowed",

- -140, "Character data error",
- -141, "Invalid character data",
- -144, "Character data too long",
- -148, "Character data not allowed",
- -150, "String data error",
- -151, "Invalid string data",
- -158, "String data not allowed",
- -160, "Block data error",
- -161, "Invalid block data",
- -168, "Block data not allowed",
- -200, "Execution error",
- -220, "Parameter error",
- -221, "Settings conflict",
- -221, "Settings conflict; amplitude and offset out of reference voltage range",
- -221, "Settings conflict; high threshold is lower than low threshold",
- -221, "Settings conflict; analog trigger level beyond range because of analog trigger source",
- -221, "Settings conflict; sampling rate beyond range because of number of channel",
- -221, "Settings conflict; acquisition points beyond range because of number of channel",
- -221, "Settings conflict; waveform points beyond range because of number of channel",
- -221, "Settings conflict; unsupported trigger mode",
- -221, "Settings conflict; unsupported trigger mode because of analog trigger source",
- -222: Data out of range; external clock is set above instrument's capability
- -223, "Too much data",
- -224, "Illegal parameter value",
- -300, "Device specific error",
- -310, "System error",

- -311, "Memory error",
- -313, "Calibration memory lost",
- -314, "Save/recall memory lost",
- -315, "Configuration memory lost",
- -321, "Out of memory",
- -330, "Self-test failed",
- -350, "Queue overflow",
- -400, "Query error",
- -410, "Query INTERRUPTED",
- -420, "Query UNTERMINATED",
- -430, "Query DEADLOCKED",
- -440, "Query UNTERMINATED after indefinite response",
- 112, "Channel list: channel number out of range.",
- 113, "Channel list: empty scan list",
- 222, "Settings conflict: module type does not match state",
- 223, "Settings conflict: trig source changed to IMM",
- 261, "Not able to execute while scan initiated",
- 262, "Not able to abort scan",
- 263, "Not able to execute while instrument is measuring",
- 264, "Not a scannable channel",
- 281, "Not able to perform on more than one channel",
- 301, "Module currently committed to scan",
- 303, "Module is not able to perform requested operation",
- 304, "Does not exist",
- 305, "Not able to perform requested operation",
- 305, "Not able to perform requested operation; cannot generate user-defined and pre-defined waveforms at once",
- 305, "Not able to perform requested operation; output is running",
- 305, "Not able to perform requested operation; output has stopped",
- 305, "Not able to perform requested operation; function must be enabled first",

- 305, "Not able to perform requested operation; user-defined waveform not set",
- 305, "Not able to perform requested operation; sampling rate cannot be 0 with user-defined output",
- 307, "Incorrectly configured ref channel",
- 308, "Channel not able to perform requested operation",
- 308, "Channel not able to perform requested operation: currently in differential mode",
- 309, "Incorrectly formatted channel list",
- 311, "Not able to specify resolution with Auto range",
- 521, "Input buffer overflow",
- 522, "Output buffer overflow",
- 531, "Insufficient memory",
- 532, "Not able to achieve requested resolution",
- 602, "Self-test failed; RAM read/write",
- 626, "I/O processor failed self-test",
- 705, "Cal: aborted",
- 706, "Cal: value out of range",
- 747, "Calibration failed",
- 748, "Cal checksum failed, internal data",
- 748, "Cal: invalid while cal in progress",
- 748, "Firmware and FPGA revision mismatch"





**www.agilent.com**

**Contact us**

To obtain service, warranty or technical support assistance, contact us at the following phone numbers:

United States:

(tel) 800 829 4444 (fax) 800 829 4433

Canada:

(tel) 877 894 4414 (fax) 800 746 4866

China:

(tel) 800 810 0189 (fax) 800 820 2816

Europe:

(tel) 31 20 547 2111

Japan:

(tel) (81) 426 56 7832 (fax) (81) 426 56

7840

Korea:

(tel) (080) 769 0800 (fax) (080) 769 0900

Latin America:

(tel) (305) 269 7500

Taiwan:

(tel) 0800 047 866 (fax) 0800 286 331

Other Asia Pacific Countries:

(tel) (65) 6375 8100 (fax) (65) 6755 0042

Or visit Agilent worldwide web at:

[www.agilent.com/find/assist](http://www.agilent.com/find/assist)

Product specifications and descriptions in this document subject to change without notice.

© Agilent Technologies, Inc., 2006, 2008

Printed in Malaysia

Third Edition, March 15, 2008

U2351-90202



**Agilent Technologies**