

---

# User's Guide

Publication number E2480-97003  
June 2000

For Safety information, Warranties, and Regulatory information, see the pages behind the index.

© Copyright Agilent Technologies 1994-2000  
All Rights Reserved

---


## Solutions for the Motorola CPU32

This manual describes several ways to connect an Agilent Technologies logic analysis system to your target system. These connections use an analysis probe, plus an emulation module (for an emulation solution).

### **Analysis Probe**


The analysis probe connects your logic analyzer to your target system for state and timing analysis. The analysis probe can be used with an Agilent Technologies 16600A/700A-series logic analysis system or with other Agilent Technologies logic analyzers.

The analysis probe can be purchased alone, or as part of an emulation solution.




### **Emulation Module and Target Interface Module**

The emulation module plugs into your Agilent Technologies 16600A/700A-series logic analysis system frame. The emulation module lets you use the target processor's built-in background debugging features, including run control and access to registers and memory. A high-level source debugger can use the emulation module to debug code running on the target system. You can connect the emulation module to the analysis probe or you can connect it to a debug port on the target system through the provided target interface module (TIM).



## Emulation Solution

The emulation solution includes an analysis probe, an emulation module, cables and adapters, and the Agilent Technologies B4620B Source Correlation Tool Set (for analyzing high-level source code). This solution is designed to be used with an Agilent Technologies 16600A/700A-series logic analysis system.



---

## In This Book

This book documents the following products:

<b>Analysis Probe</b>		
<b>Processor supported</b>	<b>Agilent Technologies Product Ordered</b>	<b>Includes</b>
68331, 68332, 68334, 68335 132-pin PQFP	E9589A Option #002	Agilent Technologies E2480A analysis probe and inverse assembler
68331, 68332 144-pin TQFP	E9589A Option #003	Agilent Technologies E2480A analysis probe and inverse assembler
68336, 68376 160-pin QFP	E9596A Option #002	Agilent Technologies E2480A analysis probe and inverse assembler
<b>Emulation Solution</b>		
<b>Processor supported</b>	<b>Agilent Technologies Product Ordered</b>	<b>Includes</b>
68331, 68332, 68334, 68335 132-pin PQFP	E9489A Option #002	Agilent Technologies E2480A analysis probe, inverse assembler, Agilent Technologies 16610A emulation module, target interface module (TIM), Agilent Technologies B4620B Source Correlation Tool Set
68331, 68332 144-pin TQFP	E9489A Option #003	Agilent Technologies E2480A analysis probe, inverse assembler, Agilent Technologies 16610A emulation module, target interface module (TIM), Agilent Technologies B4620B Source Correlation Tool Set
68336, 68376 160-pin QFP	E9496A Option #002	Agilent Technologies E2480A analysis probe, inverse assembler, Agilent Technologies 16610A emulation module, target interface module (TIM), Agilent Technologies B4620B Source Correlation Tool Set

---

## **1 Overview**

Overview	16
Setup Checklist	17
Setup Assistant	19
Analysis Probe	20
Equipment supplied	20
Minimum equipment required	22
Additional equipment supported	22
Logic analyzers supported	23
Logic analyzer software version requirements	24
Emulation Module	25
Equipment supplied	25
Minimum equipment required	26
Emulation Solution	27
Additional Information Sources	28

## **2 Installing Software**

Installing Software	30
Installing and loading	30
What needs to be installed	31
To install the software from CD-ROM (16600A/700A)	32
To list software packages which are installed (16600A/700A)	33
To install software on other logic analyzers	33

## **3 Connecting and Configuring the Analysis Probe**

Connecting and Configuring the Analysis Probe	36
Target System Requirements	37
Analysis probe—circuit board dimensions	38

Power-on/Power-off Sequence	39
To power on 16600A and 16700A-series logic analysis systems	39
To power on all other logic analyzers	39
To power off	40
Connecting the Analysis Probe to the Target System	42
To connect the transition board	43
To connect the analysis probe to the probe adapter	44
Connecting the probe adapter to the target system	45
Connecting the Analysis Probe to the Logic Analyzer	49
To connect the high-density termination cables to the analysis probe	50
Connecting the high-density cables to the logic analyzer	51
To connect to the 16600A logic analyzer	52
To connect to the 16601A logic analyzer	55
To connect to the 16602A logic analyzer	58
To connect to the 16603A logic analyzer	61
To connect to the 16550A analyzer	64
To connect to the 16554/55A/56/57D analyzers	68
To connect to the 1660A/AS/C/CS/CP logic analyzers	70
To connect to the 1661A/AS/C/CS/CP logic analyzers	72
To connect to the 1662A/AS/C/CS/CP logic analyzers	74
To connect to the 1670A/D logic analyzer	76
To connect to the 1671A/D logic analyzer	79
To connect to the 1672A/D logic analyzer	82
Configuring the Analysis Probe	85
To set the ID switches	86
To interpret the LEDs	87
Configuring the analysis probe for address reconstruction	89
To configure with a debugger	89
To configure with a logic analysis system	90
Configuring the Logic Analysis System	91
To load configuration and inverse assembler files—16600/700 logic analysis systems	92
To load configuration files—other logic analyzers	93

## 4 Analyzing the CPU32 with a Logic Analyzer

Analyzing the CPU32 with a Logic Analyzer 98

Modes of Operation 99

State mode 99

Timing mode 99

Logic Analyzer Configuration 100

Trigger specification 100

Format menu 100

To qualify stored data 106

Using the Inverse Assembler 107

To display captured state data 107

To align the inverse assembler 109

Inverse assembler output format 110

To use the Invasm menu 112

Inverse assembler error messages 114

## **5 Symbols and Source Code in the Analyzer**

Symbols and Source Code in the Analyzer 116

User-Defined Symbols 117

Predefined CPU32 Symbols 117

Object File Symbols 118

Requirements 118

To use object file symbols in the Agilent Technologies 16600A/700A 119

Compilers 120

Source Code 125

Inverse Assembler Generated PC (Software Address) Label 127

Access to Source Code Files 128

Triggering on Symbols and Source Code 129

To avoid triggering on prefetched instructions 129

To correlate relocatable code using the address offset 130

## **6 Connecting and Configuring the Emulation Module**

Connecting and Configuring the Emulation Module	132
Using the Emulation Control Interface	133
To start the Emulation Control Interface from the main System window	135
To start the Emulation Control Interface from the Workspace window	135
To start the Emulation Control Interface from the Workspace window for an emulation probe	137
Designing a Target System for the Emulation Module	138
Debug port connections	138
8-pin BDM port	140
10-pin BDM port	140
Target $V_{DD}$	140
Enabling BDM	141
Installing the Emulation Module	142
To install the emulation module in a 16700A-series logic analysis system or a 16701A expansion frame	143
To install the emulation module in a 16600A-series logic analysis system	145
To test the emulation module	146
Connecting the Emulation Module to the Target System	147
To connect to a target system using a 10-pin debug port	148
To connect to a target system via an 8-pin debug port	149
To connect to a target system using an analysis probe	151
To update firmware	152
To display current firmware version information	153
To verify communication between the emulator and target system	153
Configuring the Emulation Module	154
What can be configured	154
To configure using the Emulation Control Interface	155
To configure using the built-in commands	156
To configure using a debugger	157
To configure the processor type	158
To configure the processor clock speed (BDM communication speed)	159
To set the default clock rate if the processor clock rate is less than 8 MHz	160
Detailed information about processor clock rates	162
To configure restriction to real-time runs	164



Testing the emulator and target system 165  
To test memory accesses 165  
To test with a running program 165

## **7 Using Internal Registers (SIM and EMSIM Registers)**

Internal Registers (SIM and EMSIM Registers) 168  
The purpose of SIM Registers 168  
The purpose of EMSIM registers 168

Configuring the SIM Registers 169  
Summary 169  
How SIM Register Values are Set 169  
The effect of processor type on the EMSIM registers 170  
Using the Emulation Control Interface or built-in commands 170

Configuring EMSIM Register Values 171  
To copy target SIM registers to EMSIM registers 171  
To manually define EMSIM values 171

Configuring SIM Register Values 173  
To copy EMSIM registers to target SIM registers 173  
To manually define SIM values 174

Saving and Loading EMSIM Values 175  
To save EMSIM values in a configuration file 175  
To load EMSIM values from a configuration file 175

Configuring SIM and EMSIM Values Using Built-In Commands 177  
To compare SIM and EMSIM registers 177  
Summary of EMSIM-related built-in commands 178

Internal Representation of SIM and EMSIM Registers 179

## **8 Using the Emulator with a Debugger**

Using the Emulator with a Debugger 182  
Setting up Debugger Software 185

- To connect the logic analysis system to the LAN 186
- To change the port number of an emulator 188
- To verify communication with the emulator 189
- To export the logic analysis system's display to a workstation 190
- To export the logic analysis system's display to a PC 191

Using the Green Hills debugger 192

- Compatibility 192

- Overview 192

- Getting started 192

- To configure the emulation module, analysis probe, and target using an initialization script 196

- To perform common debugger tasks 198

- To send commands to the emulation module 198

- To view commands sent by MULTI to the emulation module 198

- To reinitialize the system 199

- To disconnect from the emulation module 199

- Error conditions 199

Using the Software Development Systems debugger 201

- Compatibility 201

- Overview 201

- Startup behavior 201

- Getting started 202

- To send commands to the emulation module 208

- Download performance 209

- Error conditions 210

## **9 Using the Analysis Probe and Emulation Module Together**

Using the Analysis Probe and Emulation Module Together 212

- What are some of the tools I can use? 212

- Which assembly-level listing should I use? 212

- Which source-level listing should I use? 213

- Where can I find practical examples of measurements? 213

Triggering the Emulation Module from the Analyzer 214

- To stop the processor when the logic analyzer triggers on a line of source code (Source Viewer window) 214

- To stop the processor when the logic analyzer triggers (Intermodule window) 215

- To minimize the “skid” effect 216
- To stop the analyzer and view a measurement 216
  
- Tracing until the processor halts 218
- To capture a trace before the processor halts 218
  
- Triggering the Logic Analyzer from the Emulation Module 219
- The emulation module trigger signal 219
- Group Run 220
- To trigger the analyzer when the processor halts 222
- To trigger the analyzer when the processor reaches a breakpoint 223

## **10 Hardware Reference**

- Hardware Reference 226
  
- Analysis probe—operating characteristics 227
- Theory of operation and clocking 228
- Address reconstruction overview 228
  
- Analysis probe signal-to-connector mapping (Timing) 231
  
- State connector signal definition 239
  
- Emulation module—operating characteristics 243
  
- Emulation module—electrical characteristics 244

## **11 General-Purpose ASCII (GPA) Symbol File Format**

- General-Purpose ASCII (GPA) Symbol File Format 246
- GPA Record Format Summary 248
- SECTIONS 250
- FUNCTIONS 251
- VARIABLES 252
- SOURCE LINES 253
- START ADDRESS 254
- Comments 254

## 12 Troubleshooting the Analysis Probe

- Troubleshooting the Analysis Probe 256
  - Logic Analyzer Problems 257
    - Intermittent data errors 257
    - Unwanted triggers 258
    - No activity on activity indicators 258
    - No trace list display 258
    - Analyzer won't power up 259
  - Analysis Probe Problems 260
    - Target system will not boot up 260
    - Erratic trace measurements 261
    - Capacitive loading 261
  - Inverse Assembler Problems 262
    - No inverse assembly or incorrect inverse assembly 262
    - Inverse assembler will not load or run 263
  - Intermodule Measurement Problems 264
    - An event wasn't captured by one of the modules 264
  - Analysis Probe Messages 265
    - “. . . Inverse Assembler Not Found" 265
    - "Measurement Initialization Error" 266
    - "No Configuration File Loaded" 267
    - "Selected File is Incompatible" 268
    - "Slow or Missing Clock" 268
    - "Time from Arm Greater Than 41.93 ms" 268
    - "Waiting for Trigger" 269
  - Returning Parts to Agilent Technologies for Service 270
    - To return a part to Agilent Technologies 270
    - To obtain replacement parts 271
  - Cleaning the Instrument 272

## 13 Troubleshooting the Emulation Module

Solving Problems	274
Troubleshooting Guide	275
Emulation Module Status Lights	276
Emulation Module Built-in Commands	277
To telnet to the emulation module	277
To use the built-in commands	278
Problems with the BDM Connection	280
If a user interface behaves erratically	280
Problems with Configuration	281
If you have problems displaying some registers	281
If you have problems initializing some registers	281
Problems with the Target System	282
If boot area accesses fail	282
Problems with the LAN Interface	283
If LAN communication does not work	283
If it takes a long time to connect to the network	283
Problems with the Emulation Module	284
To run the built-in performance verification test using the logic analysis system	284
To run complete performance verification tests using a telnet connection	285
If a performance verification test fails	287
Returning Parts to Agilent Technologies for Service	288
To return a part to Agilent Technologies	288
To obtain replacement parts and cables	289
To clean the instrument	289

## **Glossary**



---

**Overview**

---

# Overview

This chapter describes:

- Setup Checklist
- Setup Assistant
- Equipment used with the analysis probe (including a list of logic analyzers supported)
- Equipment used with the emulation module
- System configurations
- Additional information sources




## Setup Checklist

Follow these steps to connect your equipment:

- Check that you received all of the necessary equipment. See page 20 (analysis probe) or page 25 (emulation module).
- If you need to install an emulation module in an Agilent Technologies 16600A/700A series logic analysis system, see page 142.
- Install the software. See page 29.
- If you have an Agilent Technologies 16600A/700A-series logic analysis system, use the Setup Assistant to help you connect and configure the analysis probe and emulation module. See page 19.
- If you do not have an Agilent Technologies 16600A/700A-series logic analysis system, install the analysis probe (see page 42).

# Chapter 1: Overview

## Setup Checklist




E2476F02.VSD

## Setup Assistant

The Setup Assistant is an online tool for connecting and configuring your logic analysis system for microcontroller and bus analysis. The Setup Assistant is available on the Agilent Technologies 16600A and 16700A-series logic analysis systems. You can use the Setup Assistant in place of the connection and configuration procedures provided in this manual.

This menu-driven tool will guide you through the connection procedures for connecting the logic analyzer to an analysis probe, an emulation module, or other supported equipment. It will also guide you through connecting an analysis probe to the target system.

Start the Setup Assistant by clicking its icon in the system window.



If you ordered this product with your Agilent Technologies 16600A/700A-series logic analysis system, the logic analysis system has the latest software installed, including support for this product. If you received this product after you received your logic analysis system, see the “Installing Software” chapter (page 29).

---

## Analysis Probe

This section lists equipment supplied with the analysis probe and equipment requirements for using the analysis probe.


---

### Equipment supplied

The equipment supplied with the analysis probe is shown in the illustration on the next page. It is listed below:

- The Agilent Technologies E2480A analysis probe circuit board.
- Four Agilent Technologies E5346A high-density termination cables.
- Logic analyzer configuration files and inverse assembler software on a CD-ROM (for Agilent Technologies 16600A/700A series logic analysis systems).
- Logic analyzer configuration files and inverse assembler software on five 3.5-inch disks (for other Agilent Technologies logic analyzers).
- This User's Guide.
- A package-specific probing kit (see below).

<b>Processor Package</b>	132-pin PQFP	144-pin TQFP	160-pin QFP
<b>Equipment Supplied</b>	132-pin Transition Board	144-pin Transition Board	160-pin Transition Board
	E3417A Probe Adapter	E5336A Probe Adapter	E5373A Probe Adapter
	User's Guide	E5338A Flexible Cable	E5350A Flexible Cable
		User's Guide	User's Guide



E2480E42

**Equipment Supplied with the Agilent Technologies E2480A Analysis Probe**

## Minimum equipment required

For state and timing analysis of a Motorola CPU32 target system, you need all of the following items.

- The Agilent Technologies E2480A Analysis Probe.
- Four Agilent Technologies E5346A high-density cables.
- A microcontroller-specific transition board.
- A QFP probe adapter kit for your specific microcontroller package.
- The probe adapter User's Guide, for connecting the probe adapter to the target system.
- One of the logic analyzers listed on page page 23. The logic analyzer software version requirements are listed on page 24.

The above is the minimum equipment required to make a measurement. If you want to configure the analysis probe to reconstruct addresses, you must also have an emulation module.

---

## Additional equipment supported

**Emulation module.** The Agilent Technologies E2480A has a built-in connector for an emulation module.

**Agilent Technologies B4620B Source Correlation Tool Set.** The analysis probe and inverse assembler may be used with the Agilent Technologies B4620B Source Correlation Tool Set.

## Logic analyzers supported

The table below lists the logic analyzers supported by the Agilent Technologies E2480A analysis probe. Logic analyzer software version requirements are shown on the following page.

The Agilent Technologies E2480A requires four logic analyzer pods (68 channels) for inverse assembly. The analysis probe contains six high-density connectors (12 logic analyzer pods). Two of the connectors are for State analysis, and the other four are for Timing analysis.

### Logic Analyzers Supported

Logic Analyzer	Channel Count	State Speed	Timing Speed	Memory Depth
16600A	204	100 MHz	125 MHz	64 k states
16601A	136	100 MHz	125 MHz	64 k states
16602A	102	100 MHz	125 MHz	64 k states
16603A	68	100 MHz	125 MHz	64 k states
16550A (one or two cards)	102/card	100 MHz	250 MHz	4 k states
16554A (one or two cards)	68/card	70 MHz	125 MHz	512 k states
16555A (one or two cards)	68/card	110 MHz	250 MHz	1 M states
16555D (one or two cards)	68/card	110 MHz	250 MHz	2 M states
16556A (one or two cards)	68/card	100 MHz	200 MHz	1 M states
16556D (one or two cards)	68/card	100 MHz	200 MHz	2 M states
16557D (one or two cards)	68/card	135 MHz*	250 MHz	2 M states
1660A/AS/C/CS/CP	136	100 MHz	250 MHz	4 k states
1661A/AS/C/CS/CP	102	100 MHz	250 MHz	4 k states
1662A/AS/C/CS/CP	68	100 MHz	250 MHz	4 k states
1670A	136	70 MHz	125 MHz	64 k or .5 M states
1670D	136	100 MHz	125 MHz	64 k or 1 M states
1671A	102	70 MHz	125 MHz	64 k or .5 M
1671D	102	100 MHz	125 MHz	64 k or 1 M
1672A	68	70 MHz	125 MHz	64 k or .5 M
1672D	68	100 MHz	125 MHz	64 k or 1 M

\*For the 16557D, the state and timing speeds decrease for four- or five-card configurations.

## Logic analyzer software version requirements

The logic analyzers must have software with a version number greater than or equal to those listed below to make a measurement with the Agilent Technologies E2480A. You can obtain the latest software at the following web site:

**<http://www.agilent.com/find/logicanalyzer>**

If your software version is older than those listed, load new system software with the higher version numbers before loading the Agilent Technologies E2480A software.

### Logic Analyzer Software Version Requirements

<b>Agilent Technologies Logic Analyzer</b>	<b>Minimum Logic Analyzer Software Version for use with Agilent Technologies E2480A</b>
16600A-series	The latest Agilent Technologies 16600A logic analyzer software version is on the CD-ROM shipped with this product.
1660A/AS Series	3.01
1660C/CS/CP Series	A.02.01
1670A/D Series	A.02.02
<b>Agilent Technologies Mainframe*</b>	
16700A-series	The latest Agilent Technologies 16700A logic analyzer software version is on the CD-ROM shipped with this product.
16500C Mainframe	1.07
16500B Mainframe	3.14

\* The mainframes are used with the Agilent Technologies 16550 and 16554/55/56 logic analyzers.



---

## Emulation Module

This section lists equipment supplied with the emulation module and lists the minimum equipment required to use the emulation module.

---


### Equipment supplied

The equipment supplied with your emulation module includes:

- An Agilent Technologies 16610A emulation module. If you ordered an emulation module as part of your Agilent Technologies 16600A or 16700A logic analysis system, it is already installed in the frame.
- A target interface module (TIM) circuit board.
- A emulation module loopback test board (Agilent part number E3496-66502).
- Firmware for the emulation module and/or updated software for the Emulation Control Interface on a CD-ROM.
- A 50-pin ribbon cable for connecting the emulation module to the target interface module or the Agilent Technologies E2480A analysis probe.
- A 10-pin ribbon cable for connecting the target interface module to the target system.
- Torx T-8, T-10 and T-15 screwdrivers.
- This User's Guide.

## Chapter 1: Overview

### Emulation Module



### Equipment Supplied with the Emulation Module

---

## Minimum equipment required

The following equipment is required to use the emulation module:

A method for connecting to the target system. The Agilent Technologies E2480A analysis probe provides a debug port connector. You can also design a debug port connector on the target system (see “Designing a Target System for the Emulation Module” on page 138).

- An Agilent Technologies 16600A or 16700A logic analysis system.
- A user interface, such as a high-level source debugger or the logic analysis system’s Emulation Control Interface.

## Emulation Solution

An emulation solution uses the equipment and software already described in this chapter.

The combination of an analysis probe, an emulation module, and an Agilent Technologies 16600A or 16700A logic analysis system lets you both trace and control microcontroller activity on the target system.

The analysis probe supplies signals from the target microcontroller to the logic analyzer. A configuration file sets up the logic analyzer to properly interpret these signals.

You can use a debugger or the logic analysis system's Emulation Control Interface to configure and control the target processor and to download program code. You can use the Agilent Technologies B4620B Source Correlation Tool Set to analyze high-level source code using the logic analysis system.

## Additional Information Sources

Additional or updated information can be found in the following places:

Newer editions of this manual may be available. Contact your local Agilent Technologies representative.

If you have a probing adapter, the instructions for connecting the probe to your target microcontroller are in the **Probing Adapter** documentation.

Application notes may be available from your local Agilent Technologies representative or on the World Wide Web at:

**<http://www.agilent.com/find/logicanalyzer>**

If you have an Agilent Technologies 16600A or 16700A logic analysis system, the **online help** for the Emulation Control Interface has additional information on using the emulation module.

The **measurement examples** include valuable tips for making emulation and analysis measurements. You can find the measurement examples under the system help in your Agilent Technologies 16600A/700A logic analysis system.

---

Installing Software


---

# Installing Software

This chapter explains how to install the software you will need for your analysis probe or emulation solution.

## Installing and loading

**Installing** the software will copy the files to the hard disk of your logic analysis system. Later, you will need to **load** some of the files into the appropriate hardware module.



## **What needs to be installed**

### **Agilent Technologies 16600A/700A-series logic analysis systems**

If you ordered an emulation solution with your logic analysis system, the software was installed at the factory.

The following files are installed when you install a processor support package from the CD-ROM:

- Logic analysis system configuration files
- Inverse assembler (automatically loaded with the configuration files)
- Personality files for the Setup Assistant
- Emulation module firmware (for emulation solutions)
- Emulation Control Interface (for emulation solutions)

The Agilent Technologies B4620B Source Correlation Tool Set is installed with the logic analysis system's operating system.

### **Other Agilent Technologies logic analyzers**

The following files can be installed from a floppy disk:

- Logic analyzer configuration files, which automatically load the inverse assembler

## To install the software from CD-ROM (16600A/700A)

Installing a processor support package from a CD-ROM will take just a few minutes. If the processor support package requires an update to the Agilent Technologies 16600A/700A operating system, installation may take approximately 15 minutes.

If the CD-ROM drive is not connected, see the instructions printed on the CD-ROM package.

- 1 Turn on the CD-ROM drive first and then turn on the logic analysis system.
- 2 Insert the CD-ROM in the drive.
- 3 Click the **System Admin** icon.
- 4 Click **Install... .**

Change the media type to “CD-ROM” if necessary.

- 5 Click **Apply**.
- 6 From the list of types of packages, select “PROC-SUPPORT.”  
A list of the available processor support packages will be displayed.
- 7 Click on the “M683XX” package.

If you are unsure if this is the correct package, click Details for information on what the package contains.

- 8 Click **Install... .**

The dialog box will display “Progress: completed successfully” when the installation is complete.

- 9 Click **Close**.

The configuration files are stored in `/logic/configs/hp/processor`. The inverse assemblers are stored in `/logic/ia`.



**See Also**

The instructions printed on the CD-ROM package for a summary of the installation instructions.

The online help for more information on installing, licensing, and removing software.

---

**To list software packages which are installed  
(16600A/700A)**

In the System Administration Tools window, click **List...** .

---

**To install software on other logic analyzers**

Consult the documentation for your logic analyzer for details.



---

Connecting and Configuring the  
Analysis Probe

---

## Connecting and Configuring the Analysis Probe

This chapter shows you how to connect the logic analyzer to the target system through the analysis probe.

If you are connecting to an Agilent Technologies 16600A-series or 16700A-series logic analyzer, use the Setup Assistant to connect and configure your system (see page 19). Use this manual for additional information, if desired.

If you are not using the Setup Assistant, follow the instructions given in this chapter. This chapter covers the following tasks; the order shown here is the recommended order for performing these tasks:

- Check that the target system meets the necessary requirements
- Read the power on/power off sequence
- Connect the analysis probe to the target system
- Connect the analysis probe to the logic analyzer
- Configure the logic analyzer

## Target System Requirements

The Agilent Technologies E2480A connects to a number of microcontrollers and packages. The keep-out area and clearance requirements are described below.

### **Keep-out area on the target board**

The keep-out area varies according to which probe adapter you are using. Refer to the documentation included with your probe adapter for keep-out area and dimensions.

### **Clearance above the target board**


See the diagram on the next page for the dimensions of the analysis probe. You must also allow space for the cables which plug into the top of the analysis probe.

#### **See Also**

The data sheet for your analysis probe, available from your Agilent Technologies representative, has more detailed information and diagrams regarding the keep-out area and analysis probe dimensions.

## Analysis probe—circuit board dimensions

The following figure gives the dimensions for the analysis probe circuit board. The dimensions are listed in inches and millimeters.



**Analysis Probe Circuit Board Dimension Diagram**

## Power-on/Power-off Sequence

Listed below are the sequences for powering on and off a fully connected system. Simply stated, your target system is always the last to be powered on, and the first to be powered off.

---

### To power on 16600A and 16700A-series logic analysis systems

Ensure the target system is powered off.

- 1** Turn on the logic analyzer. The Setup Assistant will guide you through the process of connecting and configuring the analysis probe.
  - 2** When the analysis probe is connected to the target system and logic analyzer, and everything is configured, turn on your target system.
- 

### To power on all other logic analyzers

With all components connected, power on your system in the following order:


- Logic analysis system.
- Your target system.



e2480b07


## To power off

- Turn off your target system.
- Turn off your logic analysis system.





**Read the power on/power off sequence.**



### Connection Sequence

## Connecting the Analysis Probe to the Target System

This section explains how to connect the Agilent Technologies E2480A analysis probe to the target system. Connecting the analysis probe to the target system consists of the following steps.

Note that there are separate instructions for the different QFP packages. The instructions in this manual are only an overview. Use the documentation included with your probe adapter for detailed connecting procedures.

- Turn off the target system.
- Turn off the logic analyzer (unless you are using an Agilent Technologies 16600/16700A logic analysis system).
- Connect the transition board to the analysis probe.
- Connect analysis probe/transition board to the probe adapter.
- Connect the probe adapter to the target system.

The remainder of this section describes these general steps in more detail.

### **Protect Your Equipment**

The analysis probe socket assembly pins are covered for shipment with a conductive foam wafer or conductive plastic pin protector. This is done to protect the delicate gold-plated pins from damage due to impact. When you're not using the analysis probe, protect the socket assembly pins from damage by covering them with the pin protector.

---

## To connect the transition board

The microcontroller-specific transition board properly routes the signals from the probe adapter to the analysis probe. To connect the transition board to the analysis probe:


- Verify that there are no bent pins on the PGA socket of the analysis probe.
- Align the beveled corner of the transition board with the pin A1 corner of the PGA connector on the underside of the analysis probe. The illustration below shows the beveled corner and the pin A1 corner, as seen from the top of the analysis probe.

---

### **CAUTION:**

Serious damage to the target system or analysis probe can result from incorrect connection. Note the position of pin 1 (or pin A1) on the target system, transition board, and the analysis probe prior to making any connection. Also, take care to align the analysis probe connector with the pins on the probe adapter assembly so that all pins are making contact.

Once all pins are aligned correctly, firmly press the transition board onto the analysis probe PGA socket. You might need a solid surface to press against.



### **Pin A1 Corner and Transition Board Alignment**

## To connect the analysis probe to the probe adapter

The orientation of the analysis probe with respect to the probe adapter depends on the orientation of the probe adapter with respect to pin 1 of the target system. Use the appropriate illustration from the following pages to ensure you have the proper orientation. To connect the analysis probe to the probe adapter:

Verify that there are no bent pins on the PGA socket of the transition board.

Note the color (or number of black squares) on the side of the probe adapter or flexible cable that is connected to the pin 1 side of the target system microcontroller. Orient the analysis probe so that the solid white side of the transition board aligns with the same color (or number of black squares) on the PGA end of the probe adapter or flexible cable.

---

**CAUTION:**

Serious damage to the target system or analysis probe can result from incorrect connection. Note the position of pin 1 (or pin A1) on the target system, transition board, and the analysis probe prior to making any connection. Also, take care to align the analysis probe connector with the pins on the probe adapter assembly so that all pins are making contact.

Once all pins are aligned correctly, firmly press the analysis probe/transition board onto the PGA socket of the probe adapter or flexible cable.

## Connecting the probe adapter to the target system

The microcontrollers supported by the Agilent Technologies E2480A analysis probe come in a variety of QFP packages. The QFP probe adapter assemblies allow the analysis probe to be connected to the target system without removing the microcontroller from the target system. Refer to the documentation for your probe adapter for information on attaching the QFP Probe Adapter to your target system.

The illustrations on the following pages show the allowable rotations for the different QFP probe adapters when used with the Agilent Technologies E2480A. Note that the orientation (rotation) of the analysis probe with respect to the probe adapter depends on the orientation (rotation) of the probe adapter with respect to the target system. To ensure that you do not have mechanical interference between the analysis probe and the target system, use the rotation diagrams on the following pages, and the instructions in "To connect the analysis probe to the probe adapter," to determine the desired orientation before you connect the probe adapter to the target system.

---

**CAUTION:**

Serious damage to the target system or analysis probe can result from incorrect connection. Note the position of pin 1 (or pin A1) on the target system, transition board, and the analysis probe prior to making any connection. Also, take care to align the analysis probe connector with the pins on the probe adapter assembly so that all pins are making contact.

---


---

**CAUTION:**

To prevent equipment damage, remove power from all system components before making attachments.


---

### 132-pin PQFP Probe Adapter Rotations




**132-Pin PQFP Probe Adapter Rotation Diagram**

### 144-pin TQFP Probe Adapter Rotations



144-Pin TQFP Probing System Rotation Diagram

### 160-pin QFP Probe Adapter Rotations



e2480e27

**160-Pin QFP Probing System Rotation Diagram**



## Connecting the Analysis Probe to the Logic Analyzer

This section shows the connections between the logic analyzer pod cables and the high-density cables on the analysis probe. Use the appropriate page for your logic analyzer. The configuration file names for each logic analyzer are included with the connection diagrams.


**Number of Pods Used/Required.** The type of measurement to be made determines the number of logic analyzer pods to be used. State measurements require four pods. Full timing measurements require eight pods. If fewer than eight pods are available for timing, the logic analyzer will truncate the pods allocated. In this case, viewing the logic analyzer FORMAT menu shows the pod allocations. If the allocations will not acquire the desired signals, the allocations can be altered manually.

This section shows diagrams for connecting the analysis probe to the Agilent Technologies logic analyzers listed below:

- 16600A logic analyzers (page 52)
- 16601A logic analyzers (page 55)
- 16602A logic analyzers (page 58)
- 16603A logic analyzers (page 61)
- 16550A logic analyzers (one or two cards) (page 64)
- 16554/55/56/57 logic analyzers (one or two cards) (page 68)
- 1660A/AS/C/CS/CP (page 70)
- 1661A/AS/C/CS/CP logic analyzers (page 72)
- 1662A/AS/C/CS/CP logic analyzers (page 74)
- 1670A/D logic analyzers (page 76)
- 1671A/D logic analyzers (page 79)
- 1672A/D logic analyzers (page 82)

## To connect the high-density termination cables to the analysis probe

Four Agilent Technologies E5346A high-density termination cables, and labels to identify them, are included with the Agilent Technologies E2480A. Connect the cables to the connectors on the analysis probe as shown in the illustration below. Attach the labels to the cables after connecting the cables to the logic analyzer. Note that J1 and J6 are State connectors, and J2 through J5 are Timing connectors.




e2480e06

### Connecting High-Density Cables to the Analysis Probe

---

## Connecting the high-density cables to the logic analyzer

The following pages show the connections between the logic analyzer pod cables and the high-density cables of the analysis probe. Note that for each logic analyzer, there are separate connections for State and Timing. Refer to the appropriate pages for your logic analyzer. The configuration file names for each logic analyzer and each CPU32 target system are included with the connection diagrams.




### Analysis Probe Pod Locations

## To connect to the 16600A logic analyzer

Use the following figures to connect the analysis probe to the Agilent Technologies 16600A logic analyzer. Find the labels that were shipped with the high-density cables and use them to help identify the connections.

**Agilent Technologies 16600A State Connections.**




**Configuration File (State Analysis)**

Use configuration files C\_33X\_1S or C\_37X\_1S for state analysis with the 16600A logic analyzer.

Chapter 3: Connecting and Configuring the Analysis Probe  
**Connecting the Analysis Probe to the Logic Analyzer**

**Agilent Technologies 16600A Timing Connections.**



**Configuration File (Timing)**


Use configuration file C\_33X\_1T or C\_37X\_1T for Timing analysis with the 16600A logic analyzer.

## To connect to the 16601A logic analyzer

Use the following figures to connect the analysis probe to the Agilent Technologies 16601A logic analyzer. Find the labels that were shipped with the high-density cables and use them to help identify the connections.


Chapter 3: Connecting and Configuring the Analysis Probe  
**Connecting the Analysis Probe to the Logic Analyzer**

**Agilent Technologies 16601A State Connections.**



**Agilent Technologies 16601A Timing Connections**





**Configuration File (Timing Analysis)**  
Use configuration files C\_33X\_1T or C\_37X\_1T for timing analysis with the 16601A logic analyzer.


## To connect to the 16602A logic analyzer

Use the following figures to connect the analysis probe to the Agilent Technologies 16602A logic analyzer. Find the labels that were shipped with the high-density cables and use them to help identify the connections.

### **Agilent Technologies 16602A State Connections.**

## Chapter 3: Connecting and Configuring the Analysis Probe

### Connecting the Analysis Probe to the Logic Analyzer




#### Configuration File (State Analysis)

Use configuration files C\_33X\_1S or C\_37X\_1S for state analysis with the 16602A logic analyzer.

Chapter 3: Connecting and Configuring the Analysis Probe  
**Connecting the Analysis Probe to the Logic Analyzer**

**Agilent Technologies 16602A Timing Connections.**




## To connect to the 16603A logic analyzer

Use the following figures to connect the analysis probe to the Agilent Technologies 16603A logic analyzer. Find the labels that were shipped with the high-density cables and use them to help identify the connections

### **Agilent Technologies 16603A State Connections. .**


## Chapter 3: Connecting and Configuring the Analysis Probe

### Connecting the Analysis Probe to the Logic Analyzer



**Configuration File (State Analysis)**  
Use configuration files C\_33X\_1S or C\_37X\_1S for state analysis with the 16603A logic analyzer.

**Agilent Technologies 16603A Timing Connections.**




## To connect to the 16550A analyzer

Use the following figures to connect the analysis probe to the Agilent Technologies 16550A logic analyzer. Find the labels that were shipped with the high-density cables and use them to help identify the connections.

### **Agilent Technologies 16550A State Connections.**



Chapter 3: Connecting and Configuring the Analysis Probe  
**Connecting the Analysis Probe to the Logic Analyzer**




## Chapter 3: Connecting and Configuring the Analysis Probe

### Connecting the Analysis Probe to the Logic Analyzer

If fewer than eight pods are available for timing, the logic analyzer will truncate the pods allocated. In this case, viewing the logic analyzer FORMAT menu shows the pod allocations. If the allocations will not acquire the desired signals, the allocations can be altered manually.


#### One-card Agilent Technologies 16550A Timing Connections.



#### Configuration File (Timing Analysis)

Use configuration files C\_33X\_1T or C\_37X\_1T for timing analysis with the 16550A logic analyzer.

**Two-card Agilent Technologies 16550A Timing Connections.**




**Configuration File (Timing Analysis)**

Use configuration files C\_33X\_1T or C\_37X\_1T for timing analysis with the 16550A logic analyzer.

## To connect to the 16554/55A/56/57D analyzers


Use the following figures to connect the analysis probe to the Agilent Technologies 16554A/55A/56A and 16555D/56D/57D logic analyzers. Find the labels that were shipped with the high-density cables and use them to help identify the connections.

### **Agilent Technologies 16554/55/56/57 State Connections.**



If fewer than eight pods are available for timing, the logic analyzer will truncate the pods allocated. In this case, viewing the logic analyzer FORMAT menu shows the pod allocations. If the allocations will not acquire the desired signals, the allocations can be altered manually.

**One- or two-card Agilent Technologies 16554/55/56/57 Timing Connections.**




**Configuration File (Timing Analysis)**

Use configuration files C\_33X\_2T or C\_37X\_2T for timing analysis with the 16554/55/56/57 logic analyzers.

## To connect to the 1660A/AS/C/CS/CP logic analyzers

Use the following figures to connect the analysis probe to the Agilent Technologies 1660A/C logic analyzers. Find the labels that were shipped with the high-density cables and use them to help identify the connections.


### **Agilent Technologies 1660-series State Connections. .**



### **Configuration File (State Analysis)**

Use configuration files C\_33X\_1S or C\_37X\_1S for state analysis with the 1660-series logic analyzer.

**Agilent Technologies 1660-series Timing Connections.**




**Configuration File (Timing Analysis)**

Use configuration files C\_33X\_1T or C\_37X\_1T for timing analysis with the 1660-series logic analyzer.

## To connect to the 1661A/AS/C/CS/CP logic analyzers

Use the following figures to connect the analysis probe to the Agilent Technologies 1661A/C logic analyzers. Find the labels that were shipped with the high-density cables and use them to help identify the connections.

### Agilent Technologies 1661-Series State Connections. .




### Configuration File (State Analysis)

Use configuration files C\_33X\_1S or C\_37X\_1S for state analysis with the 1661-series logic analyzer.



If fewer than eight pods are available for timing, the logic analyzer will truncate the pods allocated. In this case, viewing the logic analyzer FORMAT menu shows the pod allocations. If the allocations will not acquire the desired signals, the allocations can be altered manually.

**Agilent Technologies 1661-Series Timing Connections.**




**Configuration File (Timing Analysis)**

Use configuration files C\_33X\_1T or C\_37X\_1T for timing analysis with the 1661-series logic analyzer.

## To connect to the 1662A/AS/C/CS/CP logic analyzers


Use the following figures to connect the analysis probe to the Agilent Technologies 1662A/C logic analyzers. Find the labels that were shipped with the high-density cables and use them to help identify the connections.

### **Agilent Technologies 1662-Series State Connections. .**



If fewer than eight pods are available for timing, the logic analyzer will truncate the pods allocated. In this case, viewing the logic analyzer FORMAT menu shows the pod allocations. If the allocations will not acquire the desired signals, the allocations can be altered manually.


**Agilent Technologies 1662-Series Timing Connections.**



## To connect to the 1670A/D logic analyzer

Use the following figures to connect the analysis probe to the Agilent Technologies 1670A/D logic analyzer. Find the labels that were shipped with the high-density cables and use them to help identify the connections.

### **Agilent Technologies 1670-series State Connections. .**




**Configuration File (State Analysis)**

Use configuration files C\_33X\_2S or C\_37X\_2S for state analysis with the 1670-series logic analyzers.

Chapter 3: Connecting and Configuring the Analysis Probe  
**Connecting the Analysis Probe to the Logic Analyzer**

**Agilent Technologies 1670-series Timing Connections.**



**Configuration File (Timing Analysis)**


Use configuration files C\_33X\_2T or C\_37X\_2T for timing analysis with the 1670-series logic analyzer.

## To connect to the 1671A/D logic analyzer

Use the following figures to connect the analysis probe to the Agilent Technologies 1671A/D logic analyzer. Find the labels that were shipped with the high-density cables and use them to help identify the connections.

**Agilent Technologies 1671-Series State Connections. .**

Chapter 3: Connecting and Configuring the Analysis Probe  
**Connecting the Analysis Probe to the Logic Analyzer**




**Configuration File (State Analysis)**

Use configuration files C\_33X\_2S or C\_37X\_2S for state analysis with the 1671-series logic analyzers.



If fewer than eight pods are available for timing, the logic analyzer will truncate the pods allocated. In this case, viewing the logic analyzer FORMAT menu shows the pod allocations. If the allocations will not acquire the desired signals, the allocations can be altered manually.

**Agilent Technologies 1671-Series Timing Connections.**




**Configuration File (Timing Analysis)**

Use configuration files C\_33X\_2T or C\_37X\_2T for timing analysis with the 1671-series logic analyzer.

## To connect to the 1672A/D logic analyzer

Use the following figures to connect the analysis probe to the Agilent Technologies 1672A/D logic analyzer. Find the labels that were shipped with the high-density cables and use them to help identify the connections.

### **Agilent Technologies 1672-Series State Connections. .**




## Chapter 3: Connecting and Configuring the Analysis Probe

### Connecting the Analysis Probe to the Logic Analyzer

If fewer than eight pods are available for timing, the logic analyzer will truncate the pods allocated. In this case, viewing the logic analyzer FORMAT menu shows the pod allocations. If the allocations will not acquire the desired signals, the allocations can be altered manually.

#### Agilent Technologies 1672-Series Timing Connections.



## Configuring the Analysis Probe

Configuring the analysis probe consists of the following:

- Setting the ID switches
- Interpreting the LEDs
- Configuring the analysis probe for address reconstruction

The functionality of the analysis probe and logic analyzer, and the accuracy of displays provided by the inverse assembler, depend on the address-reconstruction feature of the analysis probe.

### **See Also**


“Address reconstruction overview” on page 228 for a description of address reconstruction and its relationship to logic analyzer functionality.

---

## To set the ID switches

The Agilent Technologies E2480A provides an identification (ID) which may be used by other system components. The ID consists of primary and secondary values. The primary value is fixed (identifies CPU32 family) by hardware. The secondary ID is set by the 8-bit switch on the analysis probe, which must be configured to match the microcontroller being used. Positions 1 - 7 of the switch generate a binary value which must correspond to the last two digits of the microcontroller (binary 32 for MC68332). Position 8 is reserved and should be set to the "1" position.

The figure below shows the switch settings for the MC68332.



**Switch Settings for MC68332 Target System**

## To interpret the LEDs

The LEDs on the analysis probe hardware have meanings described below, after the following has been done:

1. The ID switches have been set (described in previous section).
2. The analysis probe configuration has been downloaded.

### **LED Interpretations**

- LED DS1 - Default

This LED identifies the type of configuration loaded into the reconstruction hardware. If the LED is lit, the default configuration is loaded. If this LED is not lit, a custom configuration is loaded. This LED only has meaning if LED DS2 is not lit.

- LED DS2 - NO CONFIG


This LED indicates whether or not a configuration has been loaded into the analysis probe. If it is lit, no configuration has been loaded. If it is not lit, a configuration has been loaded.

- LED DS3 - Reserved for future support of hardware breakpoints.

The illustration on the following page shows the Agilent Technologies E2480A LEDs.

If DS2 remains lit after power has been applied to the analysis probe, the analysis probe contains an unknown reconstruction configuration. To resolve this unknown state, cycle power to the analysis probe or execute a "pp load" command (see next section).

Chapter 3: Connecting and Configuring the Analysis Probe  
**Configuring the Analysis Probe**



**Agilent Technologies E2480A LED Locations**



## Configuring the analysis probe for address reconstruction

The Agilent Technologies E2480A is shipped with all reconstruction disabled. This analysis probe configuration provides accurate analysis when A[19:23], FC[0:2], SIZ0, SIZ1, DSACK0, and DSACK1 are valid. If your target system is configured differently, you must configure the analysis probe to match your target system configuration.

To perform address reconstruction, the analysis probe stores copies of the processor's internal registers in non-volatile memory. To configure the analysis probe, the Agilent Technologies E2480A must be connected to an emulation module.

The general steps are:

- 1 Set the emulation module's EMSIM registers.
- 2 Load the EMSIM register values into the analysis probe.

These steps may be performed using a debugger or an Agilent Technologies 16600A/700A-series logic analysis system.

---

## To configure with a debugger

- 1 Configure the the target processor's SIM/SCIM registers using one of the methods in Chapter 7, "Using Internal Registers (SIM and EMSIM Registers)," beginning on page 167.

You need to set the emulator copies (EMSIM registers) of the MCR, PEPAR, CSPAR0, CSPAR1, and the CSBARx and CSORx of all chip selects being used.

Using a debugger, there are two methods of configuration:

- Manually write the values into SIM/SCIM registers MCR, PEPAR, CSPAR0, CSPAR1, and the CSBARx and CSORx of all chip selects being used.

Chapter 3: Connecting and Configuring the Analysis Probe  
**Configuring the analysis probe for address reconstruction**

- Load code into the target, perform a "reset" and "run", then perform a "break" after the SIM/SCIM registers have been configured.
- 2** Start a **telnet** session or open your debugger's command window.
  - 3** Enter the the **sync sim** built-in command.  

This will copy the SIM registers into the emulator's EMSIM registers.
  - 4** Enter the **pp load** built-in command.  

This will copy the EMSIM registers into the analysis probe's non-volatile memory. The analysis probe will then be configured to properly perform address reconstruction.

---

## To configure with a logic analysis system

- 1** In the Emulation Control Interface, open the Configuration window.
- 2** Configure the values of the EMSIM registers using one of the methods in Chapter , "Using Internal Registers (SIM and EMSIM Registers)," beginning on page 167.  

You need to set the emulator copies of the MCR, PEPAR, CSPAR0, CSPAR1, and the CSBARx and CSORx of all chip selects being used.
- 3** Click the **Load analysis probe** button.  

This sends a **pp load** command to the emulator to copy the EMSIM registers into the analysis probe's non-volatile memory.

### See Also

"Using the Emulation Control Interface" on page 133.

Chapter 7, "Using Internal Registers (SIM and EMSIM Registers)," beginning on page 167.

## Configuring the Logic Analysis System

You configure the logic analyzer by loading a configuration file. The information in the configuration file includes:

- Label names and channel assignments for the logic analyzer
- Inverse assembler file name

The configuration file you use is determined by the logic analyzer you are using. The configuration file names are listed with the logic analyzer connection tables, and in a table at the end of this section.

The procedures for loading a configuration file depend on the type of logic analyzer you are using. There is one procedure for the Agilent Technologies 16600/700 series logic analysis systems, and another procedure for the Agilent Technologies 1660-series, 1670-series, and logic analyzer modules in an Agilent Technologies 16500B/C mainframe. Use the appropriate procedures for your analyzer.

## To load configuration and inverse assembler files—16600/700 logic analysis systems

If you did not use Setup Assistant, you can load the configuration and inverse assembler files from the logic analysis system hard disk.

- 1 Click on the File Manager icon. Use File Manager to ensure that the subdirectory `/logic/configs/hp/m683xx/E2480A/` exists.

If the above directory does not exist, you need to install the CPU32 Processor Support Package. Close File Manager, then use the procedure on the CD-ROM jacket to install the CPU32 Processor Support Package before you continue.

- 2 Using File Manager, select the configuration file you want to load in the `/logic/configs/hp/m683xx/E2480A/` directory, then click Load. If you have more than one logic analyzer installed in your logic analysis system, use the Target field to select the machine you want to load.

The logic analyzer is configured for CPU32 analysis by loading the appropriate configuration file. Loading the indicated file also automatically loads the inverse assembler. The configuration file you use is determined by the logic analyzer you are using, and whether you are performing state analysis or timing analysis. The configuration file names are located at the bottom of the table showing the connections for your particular logic analyzer. They are also shown in the table on page 95.

- 3 Close File Manager.

## To load configuration files—other logic analyzers

If you have an Agilent Technologies 1660-series, 1670-series, or logic analyzer modules in an Agilent Technologies 16500B/C mainframe use these procedures to load the configuration file and inverse assembler.

The first time you set up the logic analyzer, make a duplicate copy of the flexible disk. For information on duplicating disks, refer to the reference manual for your logic analyzer.

For logic analyzers that have a hard disk, you might want to create a directory such as CPU32 on the hard drive and copy the contents of the floppy onto the hard drive. You can then use the hard drive for loading files.

Configuring the logic analyzer consists of loading the software by inserting the floppy disk into the logic analyzer disk drive and loading the proper configuration file.

- 1** Insert the floppy disk in the front disk drive of the logic analyzer.
- 2** Go to the Flexible Disk menu.
- 3** Configure the menu to load.
- 4** Use the knob to select the appropriate configuration file.

The configuration file you use is determined by the logic analyzer you are using, and whether you are performing state analysis or timing analysis. The configuration files are shown with the logic analyzer connection tables, and are also in the table on the next page.

- 5** Select the appropriate analyzer on the menu. The Agilent Technologies 165xx logic analyzer modules are shown in the table on the next page.
- 6** Execute the load operation on the menu to load the file into the logic analyzer.

## Chapter 3: Connecting and Configuring the Analysis Probe

### Configuring the Logic Analysis System

The logic analyzer is configured for CPU32 analysis by loading the appropriate configuration file. Loading a state configuration file also automatically loads the inverse assembler.

- 7 If you are using the Agilent Technologies 16505A Prototype Analyzer, insert the "16505 Prototype Analyzer" flexible disk into disk drive of the prototype analyzer and update the Agilent Technologies 16505A from the Session Manager. You must close your workspace to run the update.

The Agilent Technologies 16505A Prototype Analyzer requires software version A.01.30 or higher to work with the Agilent Technologies E2480A.

**Logic Analyzer Configuration Files**

<b>Analyzer Model</b>	<b>Analyzer Description (Modules Only)</b>	<b>Configuration File for Inverse Assembly</b>	<b>Configuration File for Timing</b>
16600A	na	C_33X_1S C_37X_1S	C_33X_1T C_37X_1T
16601A	na	C_33X_1S C_37X_1S	C_33X_1T C_37X_1T
16602A	na	C_33X_1S C_37X_1S	C_33X_1T C_37X_1T
16550A (one card)	100 MHz STATE 500 MHz TIMING	C_33X_1S C_37X_1S	C_33X_1T C_37X_1T
16550A (two cards)	100 MHz STATE 500 MHz TIMING	C_33X_1S C_37X_1S	C_33X_1T C_37X_1T
16554A (one card)	0.5M SAMPLE 70/250 MHz LA	C_33X_2S C_37X_2S	C_33X_2T C_37X_2T
16555A/D (one card)	1.0M SAMPLE 110/250 MHz LA	C_33X_2S C_37X_2S	C_33X_2T C_37X_2T
16556A/D (one card)	1.0M SAMPLE 100/400 MHz LA	C_33X_2S C_37X_2S	C_33X_2T C_37X_2T
16557D (one card)	1.0M SAMPLE 100/400 MHz LA	C_33X_2S C_37X_2S	C_33X_2T C_37X_2T
16554A (two card)	0.5M SAMPLE 70/250 MHz LA	C_33X_2S C_37X_2S	C_33X_2T C_37X_2T
16555A/D (two card)	1.0M SAMPLE 110/250 MHz LA	C_33X_2S C_37X_2S	C_33X_2T C_37X_2T
16556A/D (two card)	1.0M SAMPLE 100/400 MHz LA	C_33X_2S C_37X_2S	C_33X_2T C_37X_2T
16557D (two card)	1.0M SAMPLE 100/400 MHz LA	C_33X_2S C_37X_2S	C_33X_2T C_37X_2T
1660A/AS/C/CS/CP	na	C_33X_1S C_37X_1S	C_33X_1T C_37X_1T
1661A/AS/C/CS/CP	na	C_33X_1S C_37X_1S	C_33X_1T C_37X_1T
1662A/AS/C/CS/CP	na	C_33X_1S C_37X_1S	C_33X_1T C_37X_1T
1670A/D	na	C_33X_2S C_37X_2S	C_33X_2T C_37X_2T
1671A/D	na	C_33X_2S C_37X_2S	C_33X_2T C_37X_2T
1672A/D	na	C_33X_2S C_37X_2S	C_33X_2T C_37X_2T

Chapter 3: Connecting and Configuring the Analysis Probe  
**Configuring the Logic Analysis System**



---

Analyzing the CPU32 with a Logic Analyzer

---

## Analyzing the CPU32 with a Logic Analyzer

This chapter describes modes of operation for the Agilent Technologies E2480A analysis probe. It also describes data, symbol encodings, and information about the inverse assembler.

The information in this chapter is presented in the following sections:

- Modes of operation
- Logic analyzer configuration
- Using the inverse assembler

---

## Modes of Operation

The Agilent Technologies E2480A analysis probe can be used in State mode or Timing mode. The following sections describe these operating modes.

---

### State mode

In State mode, the logic analyzer uses clock store qualification to capture address, data, and status information once during an instruction or data cycle. This mode is set up by the State configuration files. The State configuration files also automatically load the inverse assembler.

---

### Timing mode

In Timing mode, the logic analyzer samples the microcontroller pins asynchronously, at a user-selected sampling rate. The Timing mode is set up by the Timing configuration files.

State and Timing modes use different connectors on the analysis probe. The Timing pins are direct connections to the microcontroller signals. The State pins have active circuitry on the analysis probe. State information is acquired three target system clock cycles after the same information is captured in Timing mode.

## Logic Analyzer Configuration

The following sections describe the logic analyzer configuration as set up by the configuration files.

---

### Trigger specification

The trigger specification is set up by the software to store all states. If you modify the trigger specification to store only selected bus cycles, incorrect or incomplete disassembly may be displayed.

---


### Format menu

This section describes the organization of CPU32 signals in the logic analyzer's Format menu.

The configuration software sets up the analyzer format menu on the analyzer. The figure on the following page shows the Format menu for the CPU32.

The configuration files contain predefined format specifications. These format specifications include all labels for monitoring the microcontroller. The tables on the following pages show the signals used in the STAT label and the predefined symbols set up by the configuration files.

Do not modify the ADDR, DATA, or STAT labels in the format specification if you want inverse assembly. Changes to these labels may cause incorrect or incomplete inverse assembly.




### Format Menu (State)

If fewer than eight pods are available for timing, the logic analyzer will truncate the pods allocated. In this case, the logic analyzer Format menu shows the pod allocations. If the allocations will not acquire the

## Chapter 4: Analyzing the CPU32 with a Logic Analyzer Logic Analyzer Configuration

desired signals, the allocations can be altered manually.



### Format Menu (Timing)

## Status Encoding

This section describes symbol information that has been set up by the analysis probe configuration software. The signal-to-connector tables in the “Hardware Reference” chapter list all the CPU32 signals probed and their corresponding analyzer channels.

The table below describes each of the bits of the STAT label. This table is specifically for a state configuration. The timing configurations have many of the same signals, and those signals are represented by the same symbols used for state configurations.

### Agilent Technologies E2480A STAT Bit Description

Bit	STAT Label	Description
0	~ShoCy	When this bit is asserted it indicates the execution of an internal (show) cycle.
1	Rd/~Wr	Indicates the direction of the transfer.
2	~IFtch	Indicates the bus cycle is an instruction fetch.
3	~PFfsh	Indicates the instruction pipe has been flushed.
4:5	Sizx	Indicates the number of bytes being written or capable of being read.
6:7	DSAckx	Indicates the port size (in bytes) of the peripheral being read from/ written to.
8	~BErr	Indicates that the bus cycle terminated with an error.
9	~Freeze	When asserted, indicates the microcontroller is in background mode.
10	~Bkpt	Indicates a hardware breakpoint has been encountered.
11	~BGAck	When asserted, indicates the microcontroller does not own the bus.
12:14	FCx	These bits indicate the area of memory with which a transfer is taking place.

## Predefined Logic Analyzer Symbols

The configuration software sets up symbol tables on the logic analyzer. The tables define a number of symbols which make several of the STAT fields easier to interpret. The following table lists the symbol descriptions.

### CPU32 Symbolic Representation of Status Bits

Label	Signal	Symbol	Value
~ShoCy	~Show_Cycle	Int	0
		Ext	1
Rd/~Wr	Rd/~Wr	Wr	0
		Rd	1
~IFtch	~Inst_Fetch	Fetch	0
		(blank)	1
~PFlsh	~Pipe_Flush	Flush	0
		(blank)	1
Sizx	Siz[0:1]	long	00
		byte	01
		word	10
		3byt	11
DSAckx	DSAck[0:1]	(blank)	00
		word	01
		byte	10
		wait	11
~BErr	~BErr	Error	0
		(blank)	1
~Freez	~Freeze	Bkgrnd	0
		Runnin	1




<b>Label</b>	<b>Signal</b>	<b>Symbol</b>	<b>Value</b>
~Bkpt	~Bkpt	Break (blank)	0 1
~BGAck	~BGAck	NoBus (blank)	0 1
FCx	FC[0:2]	show user data user prgm (blank) (blank) supr data supr prgm CPU	000 001 010 011 100 101 110 111

---

## To qualify stored data

If you do want to acquire Background cycles, add “L=1” as a clock qualifier. If you do not want to acquire coprocessor cycles, add “M=1” as a clock qualifier.



### **L=1 Clock Qualifier**


To open this window in an Agilent Technologies 16600A/700A-series logic analysis system, select the **Format** tab and click **Master Clock...**

## Using the Inverse Assembler

This section discusses the general output format of the inverse assembler and processor-specific information.

### To display captured state data


The logic analyzer displays captured state data in the Listing menu. The inverse assembler display is obtained by setting the base for the DATA label to Invasm. The following figure shows a typical Listing menu.



**Listing Menu**

## Displaying Data with the Agilent Technologies B4620B Source Correlation Tool Set

Source correlation correlates the addresses from the trace listing with the high-level code execution. The figure below shows execution of data that is correlated to the data shown on the previous page.



### Source Correlation Tool Set Data

## To align the inverse assembler

The CPU32 microcontroller does not indicate externally which word fetched is the beginning of a new instruction. You may have to "point" to the first state of an instruction fetch to align the inverse assembler. Once aligned, the inverse assembler will disassemble from this state through the end of the screen.

Use the following procedure to align the inverse assembler:

- 1** Select a line on the display that you know contains the first word of an instruction fetch.
- 2** Roll this line to the top of the display.

Do not roll the instruction to the line number field at the left center screen. In the Listing Menu figure on page 107, line 1 is the top of the display.
---

- 3** Select the appropriate field for your analyzer.
  - a** For the Agilent Technologies 16600/700 series analyzers, select "Invasm," then select "Align."
  - b** For the other logic analyzers, select "Invasm Options" and use the "Code Synchronization" submenu.
- 4** Select "Align."

The listing inverse assembles from the top line down. Any data before the top of the display is left unchanged.

The listing will inverse assemble from the top line down. Any data before this screen is left unchanged. Rolling the screen up will inverse assemble the lines as they appear on the bottom of the screen. If you jump to another area of the listing by entering a new line number or by rolling the screen down, you may have to re-synchronize the inverse assembler by repeating the described steps.

Each time you inverse assemble a block of memory, the analyzer will

keep that block in the inverse assembled condition. You can inverse assemble several different blocks in the analyzer memory, but the activity between those blocks will not be inverse assembled.

---

## Inverse assembler output format

The following paragraphs explain the operation of the inverse assembler and the results you can expect under certain conditions.

### **Numeric Format**

Unless a value is followed by a suffix character, numeric output from the inverse assembler is in hexadecimal format. For example, decimal values have a period (.) as the suffix character; binary values have a percent sign (%).

### **Missing Opcodes/Operands**

Asterisks (\*) in the inverse assembler output indicate missing operands. Missing operands occur frequently and are primarily due to microcontroller activity. Storage qualification or the use of storage windows can also lead to such occurrences.

### **Don't Care Bytes**

The CPU32 microcontroller can perform byte transfers. During operand reads and writes, entire 16-bit (word) values appear on the microcontroller data bus lines. The inverse assembler will attempt to display "xx" for any bytes in a transfer that are invalid. You can then determine exactly which byte of data was used as an operand. If the microcontroller is configured such that the number of bytes being transferred cannot be determined, an entire word will be displayed. You must then determine which bytes are valid.

## Unexecuted Prefetched Instructions

Prefetched instructions which are not executed by the microcontroller are marked by a hyphen "-" in the first column of the mnemonic/hex field.

The logic analyzer captures prefetches even if they are not executed. Care must be taken when specifying a trigger condition or a storage qualification that follows an instruction that may cause branching. An unused prefetch may generate an unwanted trigger.

Since the microcontroller only prefetches at most two words, one technique to avoid unwanted triggering from unused prefetches is to add "4" to the trigger address. This trigger condition will only be satisfied if the branch is not taken.

## Processor-Specific Output Format

The logic analyzer captures all bus cycles. This includes background and coprocessor cycles as well as code cycles.

A "c" marks coprocessor activity, and background activity is marked with a "b". The "c" and "b" are displayed in the first column of the mnemonic/hex field. Acquisitions of coprocessor and background cycles may be individually enabled/disabled via clock qualifiers (with an Agilent Technologies 16600A/700A-series logic analysis system, select the **Format** tab and click **Master Clock...**).

## General Missing Terms

Depending on the configuration of the microcontroller, the inverse assembler may be unable to supply all the of the information it can supply. For example, if  $\sim$ DS (data strobe) is not valid, internal cycles cannot be captured.

## To use the Invasm menu

The Invasm menu provides three choices: Load, Filter, and Options. These dialogs assist in analyzing and displaying data. Access the Invasm menu in the Listing window.


The following sections describe these dialogs.

### Load

The Load dialog lets you load a different inverse assembler and apply it to the data in the Listing menu. In some cases you may have acquired raw data; you can use the Load dialog to apply an inverse assembler to that data.

### Display Filtering

The inverse assembler lets you Show or Suppress several types of cycles. This allows you to focus on and display more cycles of interest. The figure below shows the Filter menu.





The show/suppress settings do not affect the data that is stored by the logic analyzer; they only affect whether that data is displayed or not. You can examine the same data with different settings, for different analysis requirements.

This dialog allows faster analysis in two ways. First, you can filter unneeded information out of the display. For example, suppressing unexecuted prefetches will show only states in which prefetches were completed.

Second, you can isolate particular operations by suppressing all other operations. For example, you can show Calls and Returns, with all other states suppressed, allowing quick analysis of Calls and Returns.

The following cycles can be shown or suppressed: extension words, unexecuted prefetches, branches, calls and returns, other instructions, data reads, and data writes.

Extension words and unexecuted fetches are suppressed without regard to user mode or supervisor mode because they do not affect the display of executed mnemonics.

All other categories may suppress based on the user mode, supervisor mode, or both. These categories suppress actual executed mnemonics for the display.

## **Options**

The Options menu lets you change the width of the display.

## Inverse assembler error messages

Any of the following list of error messages may appear during analysis of your target software. Included with each message is a brief explanation.

**Fatal Data**

**Error**                   Displayed if the trace memory could not be read properly on entry into the inverse assembler.

**Illegal Opcode**

**<code>**                   Displayed if the inverse assembler encounters an illegal instruction.

**Reserved**

**Opcode**                   Displayed if the inverse assembler encounters a reserved coprocessor instruction.

**Incomplete**

**Opcode**                   Displayed if the inverse assembly cannot acquire all words of a multi-word instruction.

**\* (asterisk)**           Displayed if the inverse assembler cannot find a complete operand field for an instruction. Prefetch activity or storage qualification is often the cause.

---

Symbols and Source Code in the  
Analyzer

---

## Symbols and Source Code in the Analyzer

Symbols are more easily recognized than hexadecimal address values in logic analyzer trace displays, and they are easier to remember when setting up triggers.

Agilent Technologies logic analyzers let you assign user-defined symbol names to particular label values.

Also, you can download symbols from certain object file formats into Agilent Technologies logic analyzers.

When source file line number symbols are downloaded to the logic analyzer, you can set up triggers on source lines. The Agilent Technologies B4620B Source Correlation Tool Set also lets you display the high-level source code associated with captured data.


After describing user-defined symbols, the rest of this chapter describes the requirements and considerations for displaying object file symbols and source code for address values captured by a logic analyzer.

---

## User-Defined Symbols

User-defined symbols are symbols you create from within the logic analyzer user interface by assigning symbol names to label values. Typically, you assign symbol names to address label values, but you can define symbols for data, status, or other label values as well.

User-defined symbols are saved with the logic analyzer configuration.



---

## Predefined CPU32 Symbols

If you're using an analysis probe for a CPU32 microcontroller, the logic analyzer configuration files include predefined symbols.

These symbols appear along with the other user-defined symbols in the logic analyzer.

The predefined symbols are listed on page 104.

## Object File Symbols

The most common way to load program symbols into the logic analyzer is from an object file that is created when the program is compiled.

### Requirements

In order for object file symbols and source code to be accurately assigned to address values captured by the logic analyzer, you need:

#### **An accurate bus trace**

An Agilent Technologies analysis probe is used to capture the microcontroller data.

#### **An inverse assembler**

The inverse assembler software is included with Agilent Technologies analysis probes. The CPU32 inverse assembler decodes captured data into program counter (PC) addresses (also known as software addresses) and assembly language mnemonics.

#### **A symbol file**

You need an object file containing symbolic debug information in a format the logic analyzer understands.

Alternatively, you can use a General Purpose ASCII (GPA) symbol file (see Chapter 11, “General-Purpose ASCII (GPA) Symbol File Format,” beginning on page 245).


#### **Visible internal cycles**

To store internal cycles in the trace, enable Show Cycles (SHEN) in the Module Configuration Register (MCR).

---

## To use object file symbols in the Agilent Technologies 16600A/700A

To load symbols in the Agilent Technologies 16600A/16700A-series logic analysis system, open the logic analyzer module's Setup window and select the Symbol tab; then, select the Object File tab. Make sure the label is ADDR. From this dialog you can select object files and load their symbol information.




When you load object file symbols into a logic analyzer, a database of symbol/line number to address assignments is generated from the object file. The Symbol Selector dialog allows you to use a symbol in place of a hexadecimal value when when defining trigger patterns,

## Chapter 5: Symbols and Source Code in the Analyzer

### Object File Symbols

trigger ranges, and so on.



If your language tool is not one of those listed on page 120, you can create a symbol file in the General-Purpose ASCII (GPA) file format (refer to the “General-Purpose ASCII (GPA) File Format” chapter).

#### See Also

If you have an Agilent Technologies 16600A/700A-series logic analysis system, see the online help for more information on how to load symbols.

If you have another logic analyzer refer to your logic analyzer documentation for information on how to load symbol files.

---

## Compilers

The following CPU32 compilers and their ELF/DWARF or IEEE-695 format object files can be used with Agilent Technologies logic analyzers and the Agilent Technologies B4620B Source Correlation Tool Set:



### **Object File Formats**

<b>Language System &amp; Version</b>	<b>Format</b>
Diab Data version 4.1a	ELF/DWARF
Green Hills version 1.8.8	IEEE-695
Microtec Research, Inc. mcc68k ver. 4.6G, asm68k ver. 7.1	IEEE-695

In order to use symbols in the logic analyzer, file name and line number information must be present in the object file. Your compiler may have options that include or exclude this information.

Limitations: For C++ files, symbols are not demangled. Mangled names are available for use and the trace listing will still correctly correlate to the appropriate source file lines.

When compiling code, if possible, specify that code and data be put in different memory 'blocks'. A 'block' is 32 Kbytes. 32 Kbytes is the smallest area of memory that can be distinguished by each memory block.

It is also useful to put the stack in the data block.

By separating the code and data in this way, the inverse assembler can be configured to properly decode both code and data.

#### **See Also**

Contact your Agilent Technologies sales engineer to find out if there are other compilers for CPU32 microcontrollers that can be used with Agilent Technologies logic analyzers.

## Object File Symbols

### Diab Data Compiler Options

The following options should be used:

-g	Specifies to generate symbolic debugger information (same as -g2).
-WDDOBJECT=F	Specifies the ELF/DWARF file format.
-WDDENVIRON=cross	Specifies the cross development environment.
-WDDTARGET=MC683*	Specifies CPU32 processor.
-Xdebug-mode=0xff	Turns off Diab Data extensions to the file format.

Diab Data provides a utility that you can use to generate the compiler options you need. Enter **dctrl -t** and follow the instructions. When it is finished, it will present you with a string that you can use for the compiler options.

Please refer to the language tool supplier's documentation for more information about the options available.

More information is available on the World Wide Web at: <http://www.diabdata.com>

## **Green Hills Compiler Options**

The following options should be used:

- |                         |  |
|-------------------------|--|
| <code>-nodbg</code>     | Specifies not to use Green Hills proprietary debug information; instead use DWARF style debugging information. |
| <code>-G</code>         | Generates extended debugging information.  |
| <code>-cpu=6833x</code> | Specifies code generation for the 6833x processor.   |

A COFF file is generated. You must then use the `coff695` converter to get an IEEE-695 file.

If you are using the Green Hills MULTI builder interface, use the following selections:

- |  |   |
|--|---|
| Options→File Options, select “Debugging Level MULTI” | Generates extended debugging information.   |
| Options→CPU, select processor                        | Specifies code generation for the CPU32 processor.  |
| Options→Advanced→IEEE695                             | Generate IEEE-695 file format. You must create a COFF file before generating the IEEE-695 file. |

Refer to the debugger information beginning on page 192 for more information on the compiler options required to use the debugger with the emulation module. Those options may be different than the options required for the Agilent Technologies B4620B Source Correlation Tool Set. For example, do not use the “-nodbg” compiler option for an object file intended for use with the MULTI debugger. If you are using source correlation and the debugger, generate two object files.

Please refer to the language tool supplier’s documentation for more information about the options available. More information is available on the World Wide Web at: <http://www.ghs.com>

**Object File Symbols**

**Microtec Research Inc. Compiler Options**

The following options should be used:

-g                      Specifies to generate debugging information.

Please refer to the language tool supplier's documentation for more information about the options available.

More information is available on the World Wide Web at:  
<http://www.mentorg.com/microtec>

---


## Source Code

The Agilent Technologies B4620B Source Correlation Tool Set lets you:

- View the high-level source code associated with captured data.
- Set up triggers based on source code.

The source correlation tool set correlates the logic analyzer's address label with a line of high-level source code whose address, symbol name, file name, and line numbers are described in a symbol file downloaded to the logic analyzer.

If you purchased a solution, the Agilent Technologies B4620B Source Correlation Tool Set was included. Otherwise, the source correlation tool set is available as an add-on product for the Agilent Technologies 16600A/16700A-series logic analysis system and must be licensed before you can use it (see the System Admin dialogs for information on licensing).



### See Also

More information on configuring and using the source correlation tool set can be found in the online help for your logic analysis system.

## **Requirements for source correlation**

The source correlation tool set works with many microcontrollers and their embedded software development environments.

However, the overall effectiveness of the source correlation tool set will vary to some degree depending on the specific development environment it is being used in. The following areas affect the performance of the source correlation tool set for different development environments:

- Analysis probe and inverse assembler.

All the information needed to reconstruct the complete address bus of the target system must be acquired by the logic analyzer. The Agilent Technologies E2480A analysis probe meets this requirement.

The logic analyzer's inverse assembler may need to reconstruct any incomplete address bus information and/or filter out any unexecuted instructions.

When displaying the next or previous instances of a source line, the Source Viewer display uses the PC or SW\_ADDR (Software Address) label generated by the inverse assembler.

- Object file symbols.

The source correlation tool set requires that symbols be loaded into the logic analyzer (refer to the "Object File Symbols" section earlier in this chapter).

The compiler needs to produce an object file format that is readable by the logic analyzer; otherwise, a general-purpose ASCII (GPA) format file needs to be generated.

- Access to source code files.

The source correlation tool set requires that you give the logic analysis system access to your program's high-level source files (either by NFS mounting the file system that contains the source files or by copying source files to the logic analysis system disk).

---

## Inverse Assembler Generated PC (Software Address) Label

In the Agilent Technologies 16600A/16700A-series logic analysis system, the CPU32 inverse assembler generates a “PC” label. The PC label is displayed as another column in the Listing tool. This label is also known as the Software Address generated by the inverse assembler.

The “Goto this line in listing” commands in the Agilent Technologies 16600A/16700A-series logic analysis system perform a pattern search on the PC label in the Listing display (when an inverse assembler is loaded). Because the inverse assembler is called for each line that is searched, the search can be slow, especially with a deep memory logic analyzer.

Also, a single source code line will generate many assembly instructions. The “Goto this line in listing” commands will not find a given source code line unless the first assembly instruction generated from the source line has been acquired by the logic analyzer.

For example, if the compiler unrolls a loop in the source code, the trace could begin after the first assembly instruction of the loop has been executed. A “Goto this line in listing” command would not find the source line.

## Access to Source Code Files

The source correlation tool set must be able to access the high-level source code files referenced by the symbol information so that these source files can be displayed next to and correlated with the logic analyzer's execution trace acquisition. This requires you to be aware of a number of issues.

### Source File Search Path

Verify that the correct file search paths for the source code have been entered into the source correlation tool set. The Agilent Technologies B4620B Source Correlation Tool Set can often read and access the correct source code file from information contained in the symbol file, if the source code files have not been moved since they were compiled.

### Network Access to Source Files

If source code files are being accessed across a network, the logic analyzer networking must be compatible with the network environment. Agilent Technologies logic analyzers currently support Ethernet networks running a TCP/IP protocol and support ftp, telnet, NFS client/server and X-Window client/server applications. Some PC networks may require extensions to the normal LAN protocols to support the TCP/IP protocol and/or these networking applications. Contact your LAN administrator to help set up the logic analyzer on the network.

### Source File Version Control

If the source code files are under a source code or version control utility, check the file names and paths carefully. These utilities can change source code file paths and file names. If these names are changed from the names in the symbol file, the source correlation tool set will not be able to find the proper source code file. Version control utilities usually provide an "export" command that creates a set of source code files with unmodified names. The source correlation tool set can then be given the correct path to these files.



## Triggering on Symbols and Source Code

When setting up trigger specifications to capture processor execution:

- Use the logic analyzer trigger alignment to avoid missed triggers.
- Use the logic analyzer address offset to compensate for relocated code.
- Use the logic analyzer storage qualification to capture the software execution you're interested in and filter out library code execution (whose source file lookups can take a long time if the library source code is not available).

---

## To avoid triggering on prefetched instructions

A CPU32 microcontroller may prefetch one instruction following a taken branch (BRx, JMP, JSR). The preprocessor does not filter these prefetches. This means that the prefetched states will be collected by the analyzer, and that a trigger set to the address of the prefetched instruction will cause a false trigger on the prefetch.

The recommended way to avoid false triggering for a CPU32 device (16 bit data bus) in this case is to offset the address of the trigger by 4. An offset field is provided in the symbolic trigger menu to allow offsetting the symbol address.

Note that this is not a foolproof scheme, since this may result in an inappropriate trigger if the offset address is a point where control transfers (branch destination). Be aware of prefetches and adjust your triggering to compensate for it as you gain experience with the

processor and your code.

**Example**

A common example of this is setting a trigger on the source line following a loop, for instance:

Line #	Addr	C source	Assembly Source
100	1000	for (i=0;i<10;i++)	
	1000		MOVEQ #0,D3
101	1002	{	
	1002		forLoop1:
102	1002	foo = foo + 100;	
	1002		ADD.L #100,D2
103	1008	}	
	1008		ADDQ.L #1,D3
	100A		CMP.L #10,D3
	1010		BLT forLoop1
104	1012	printf("%d\n", foo);	
	1012		-MOVEA.L D2,A0

The instruction at 1012 will be prefetched following the BLT at address 1010. So, setting a trigger on line #104 (address 1012) will result in a premature trigger.

---

## To correlate relocatable code using the address offset

You need to adjust the source correlation tool set to compensate for relocatable code segments or memory management units that produce fixed code offsets.

The offset field in the trigger menu allows you to offset the symbol address. Entering the appropriate address offset will cause the source correlation tool set to reference the correct symbol information for the relocatable or offset code.

To adjust for prefetches, use a trigger offset of 4 (prefetch queue depth) to avoid triggering on prefetched instructions. This is not a foolproof scheme, since this may result in a missed trigger if a branch takes place between the base address and the offset address. For the CPU32, an offset of 4 is large enough to overcome the prefetch queue.

---

Connecting and Configuring the Emulation Module

## Connecting and Configuring the Emulation Module

This chapter shows you how to connect the emulation module to the target system and how to configure the emulation module and target.

Here is a summary of the steps for connecting and configuring the emulation module:

- 1** Make sure the target system is designed to work properly with the emulation module. (page 138)
- 2** Install the emulation module in your logic analysis system, if necessary. (page 142)

If you are connecting to an Agilent Technologies 16600A/700A-series logic analysis system, use the Setup Assistant to guide you through steps 3-6 (see page 19). Use this manual for additional information, if desired.

- 3** Connect the emulation module to your target system using the 50-pin cable and the TIM or an analysis probe. (page 147)
- 4** Update the firmware of the emulation module, if necessary. (page 152)
- 5** Verify communication between the emulation module and the target. (page 153)
- 6** Configure the emulation module. (page 154)
- 7** Test the connection between the emulation module and the target. (page 165)
- 8** Connect a debugger to the emulation module, if applicable. (page 181.)

### See Also

Chapter 8, “Using the Emulator with a Debugger,” beginning on page 181 for information on configuration with a debugger, and on configuring LAN port numbers.

## Using the Emulation Control Interface

The Emulation Control Interface in your Agilent Technologies 16600A/700A-series logic analysis system allows you to control an emulator (an emulation module or an emulation probe).

As you set up the emulation module, you will use the Emulation Control Interface to:

- Update firmware (which reloads or changes the processor-specific personality of the emulator).
- Change the LAN port assignment (rarely necessary).
- Run performance verification tests on the emulator.

The Emulation Control Interface allows you to:

- Run, break, reset, and step the target processor.
- Set and clear breakpoints.
- Read and write registers.
- Read and write memory.
- Read and write I/O memory.
- View memory in mnemonic form.
- Read and write the emulator configuration.
- Download programs (in Motorola S-Record or Intel Hex format) to the target system RAM or ROM.
- View emulator status and errors.
- Write and play back emulator command script files.

If you have an emulation probe, this interface also allows you to configure the LAN address of the emulation probe.

Using the logic analysis system's intermodule bus does not require the Emulation Control Interface to be running. If the emulation module icon is in the Intermodule window, then it will be able to send and receive signals. Therefore if you are using a debugger, you can use an

## Chapter 6: Connecting and Configuring the Emulation Module

### Using the Emulation Control Interface

analyzer to cause a break.

Using a debugger with the Emulation Control Interface is not recommended because:


- The interfaces can get out of synchronization when commands are issued from both interfaces. This causes windows to be out-of-date and can cause confusion.
- Most debuggers cannot tolerate another interface issuing commands and may not start properly if another interface is running.

#### See Also

All of the Emulation Control Interface windows provide online help with a **Help** button or a **Help→On this window** menu selection. Refer to the online help for complete details about how to use a particular window.

## To start the Emulation Control Interface from the main System window

- 1 In the System window, click the emulation module icon.
- 2 Select **Start Session...**




---

## To start the Emulation Control Interface from the Workspace window

- 1 Open the Workspace window.
- 2 Drag the Emulator icon onto the workspace.

Chapter 6: Connecting and Configuring the Emulation Module  
**Using the Emulation Control Interface**

**3** Right-click on the Emulator icon, then select **Start Session...**






## To start the Emulation Control Interface from the Workspace window for an emulation probe

If you have a stand-alone emulation probe connected to the logic analysis system via LAN, use the Emulation Probe icon instead of the Emulator icon.

- 1 Open the Workspace window.
- 2 Drag the Emulation Probe icon onto the workspace.
- 3 Right-click on the Emulation Probe icon, then select **Start Session...**



- 4 In the Session window, enter the IP address or LAN name of the emulation probe, then click **Start Session**.

## Designing a Target System for the Emulation Module

---

### Debug port connections

If you plan to connect the emulation module directly to the target system, the target system should have a debug port (BDM) connector.

The connector should be a dual row header strip ("Berg connector"), 10 pins per inch, with 25 mil pins.

Some of the signals at the BDM port share the same lines, as shown in the diagrams on the following pages.

When deciding whether to use an 8-pin or a 10-pin BDM port, consider how often you are likely to encounter "hung" bus cycles. If you are using an 8-pin BDM port, and a target bus cycle fails to terminate, you will need to reset the target system. If you use a 10-pin BDM port, the emulator will detect and terminate the "hung" cycle.

Therefore if your target system does not have a good bus monitor, or if you are not using the built-in bus monitor, you should use a 10-pin BDM port to take advantage of the  $\overline{DS}$  and  $\overline{BERR}$  signals.

The emulation module adds about 40 pF to all target system signals routed to the debug connector. This added capacitance may reduce the rise time of some signals beyond the processor specifications. If so, the target may need to increase the pull-up current on these signal lines.

The following signals should be available at the BDM port:

### **BDM signal definitions**

<b>Mnemonic</b>	<b>Name</b>	<b>Direction</b>	<b>Signal Description</b>
GND	Ground		
$\overline{\text{BKPT}}$	Breakpoint	Input (to target)	Signals a hardware breakpoint. Also used to place the CPU32 in background debug mode. Active low
DSCLK	Development system clock	Input	Serial input clock
FREEZE	Freeze	Output	Indicates BDM mode
QUOT	Quotient out	Output	Quotient bit of the polynomial divider. Not used in BDM mode.
$\overline{\text{RESET}}$	Reset	Output	Indicates system reset
$\overline{\text{IFETCH}}$	Instruction fetch	Output	Indicates when the CPU is performing an instruction word prefetch and when the instruction pipeline has been flushed (active low)
DSI	Development serial in	Input	BDM data input
$V_{\text{DD}}$		Output	Target power (+5 V or +3.3 V)
$\overline{\text{IPIPE}}$	Instruction pipe	Output	Used to track the movement of words through the instruction pipeline (active low)
DSO	Development serial out	Output	BDM data output
$\overline{\text{DS}}$	Data strobe	Output	During read, indicates ready to receive valid data; during write
$\overline{\text{BERR}}$	Bus error	Input	Used to terminate target memory cycles (optional)

## 8-pin BDM port

An 8-pin BDM port should be a dual row header strip ("Berg connector"), 4 pins per row, 10 pins per inch, with 25 mil pins. If you plan to use the 10-pin cable, use a header with 2 rows of 5 pins.

If you plan to make an 8-pin cable, you should use the following pin assignments for the BDM port:

GND	1	<input type="checkbox"/>	<input type="checkbox"/>	2	$\overline{\text{BKPT}}/\text{DSCLK}$
GND	3	<input type="checkbox"/>	<input type="checkbox"/>	4	FREEZE/QUOT
$\overline{\text{RESET}}$	5	<input type="checkbox"/>	<input type="checkbox"/>	6	$\overline{\text{IFETCH}}/\text{DSI}$
$V_{\text{DD}}$	7	<input type="checkbox"/>	<input type="checkbox"/>	8	$\overline{\text{IPIPE}}/\text{DSO}$

E3490B06

## 10-pin BDM port

If you plan to use the provided 10-pin cable, you should use the following pin assignments for the BDM port:

$\overline{\text{DS}}$	1	<input type="checkbox"/>	<input type="checkbox"/>	2	$\overline{\text{BERR}}$
GND	3	<input type="checkbox"/>	<input type="checkbox"/>	4	$\overline{\text{BKPT}}/\text{DSCLK}$
GND	5	<input type="checkbox"/>	<input type="checkbox"/>	6	FREEZE/QUOT
$\overline{\text{RESET}}$	7	<input type="checkbox"/>	<input type="checkbox"/>	8	$\overline{\text{IFETCH}}/\text{DSI}$
$V_{\text{DD}}$	9	<input type="checkbox"/>	<input type="checkbox"/>	10	$\overline{\text{IPIPE}}/\text{DSO}$

E3490B07

## Target $V_{\text{DD}}$

The emulator may draw up to 10 mA from target  $V_{\text{DD}}$ .

See page 244 for more information on current and voltage requirements.

## Enabling BDM

Your target system does not need to enable background debug mode.

If the emulator is connected before you turn on the target system, the emulator will enable BDM.

If you connect the emulator after you turn on the target system, the emulator will enable BDM when the target is reset.

## Installing the Emulation Module

Your emulation module may already be installed in your logic analysis system. If you need to install an emulation module yourself, follow the instructions on the pages which follow.

---

**CAUTION:**

These instructions are for trained service personnel. To avoid dangerous electric shock, do not perform any service unless qualified to do so. Do not attempt internal service or adjustment unless another person, capable of rendering first aid and resuscitation, is present.

Electrostatic discharge can damage electronic components. Use grounded wrist straps and mats when you handle modules.

---


## To install the emulation module in a 16700A-series logic analysis system or a 16701A expansion frame

You will need T-10 and T-15 Torx screw drivers (supplied with the module).

- 1** Turn off the logic analysis system and REMOVE THE POWER CORD.


Remove any other cables (including mouse or video monitor cables).

- 2** Turn the logic analysis system frame upside-down.
- 3** Remove the bottom cover.




- 4** Remove the slot cover.

You may use either slot.




Chapter 6: Connecting and Configuring the Emulation Module  
**Installing the Emulation Module**

- 5** Install the emulation module.



- 6** Connect the cable and re-install the screws.

You may connect the cable to either of the two connectors. If you have two emulation modules, note that many debuggers will work only with the “first” module: the one toward the top of the frame (“Slot 1”), plugged into the connector nearest the back of the frame.



- 7** Reinstall the bottom cover, then turn the frame right-side-up.  
**8** Plug in the power cord, reconnect the other cables, and turn on the logic analysis system.

The new emulation module will be shown in the system window.

**See Also**

See page 152 for information on giving the emulation module a “personality” for your target processor.



---


## To install the emulation module in a 16600A-series logic analysis system

You will need T-8, T-10, and T-15 Torx screw drivers (supplied with the emulation module).


- 1** Turn off the logic analysis system and REMOVE THE POWER CORD.

Remove any other cables (such as probes, mouse, or video monitor).

- 2** Slide the cover back.




- 3** Remove the slot cover.



## Chapter 6: Connecting and Configuring the Emulation Module

### Installing the Emulation Module

- 4 Install the emulation module.
- 5 Connect the cable and re-install the screws.



- 6 Reinstall the cover.

Tighten the screws snugly ( 2 N·m or 18 inch-pounds).

- 7 Plug in the power cord, reconnect the other cables, and turn on the logic analysis system.

The new emulation module will be shown in the system window.

#### See Also

See page 152 for information on giving the emulation module a “personality” for your target processor.

---


## To test the emulation module

If this is the first time that you have used the emulation module, you should run the built-in performance verification test before you connect to a target system. Refer to page 284 for information on performance verification.


## Connecting the Emulation Module to the Target System

Choose one of the following methods for connecting the emulation module to a target system.

- Directly through a debug port connector on the target board.



- Through an Agilent Technologies E2480A analysis probe, which provides a direct connection to the debug port pins.



After you have connected the emulation module to your target system, you may need to update the firmware in the emulation module.

**See Also**

For information on designing a debug port on your target board, see page 138.

For a list of the parts supplied with the emulation module, see page 25.

---


## To connect to a target system using a 10-pin debug port

The emulator can be connected to a target system through a 10-pin debug port (BDM connector).

The emulator should be connected to the target system using the 10-conductor cable assembly provided.

In order to connect the emulator to the microcontroller, a 10-pin male 2x5 header connector must be available on the target system.

- 1 Remove power from the target system and the emulator.
- 2 Plug one end of the 50-pin cable into the emulator.



- 3 Plug the other end of the 50-pin cable into the target interface module.
- 4 Plug one end of the 10-pin cable into the target interface module.
- 5 Plug the other end of the 10-pin cable into the target system.


Orient the red wire toward pin 1 of the connector.

---

**CAUTION:**

---

Be careful to orient the connector as shown below. If the connector is rotated, your target system or the emulation module may be damaged.



- 6 Turn on the power to the logic analysis system, then turn on the power to the target system.


**See Also**

“Designing a Target System for the Emulation Module” on page 138.

---

### To connect to a target system via an 8-pin debug port

- 1 Remove power from the target system and the emulator.
- 2 Plug one end of the 50-pin cable into the emulator.



- 3 Plug the other end of the 50-pin cable into the target interface module.

Chapter 6: Connecting and Configuring the Emulation Module  
**Connecting the Emulation Module to the Target System**

- 4 Plug one end of the 10-pin cable into the target interface module.
- 5 Plug the other end of the 10-pin cable into the target system.


Orient the red wire toward pin 1 of the connector. Pins 1 and 2 of the cable should be the ones which are not connected. Connect pin 3 of the cable to pin 1 of the target connector.

---

**CAUTION:**

---

Be careful to orient the connector as shown below. If the connector is rotated, your target system or the emulator may be damaged.



- 6 Turn on the power to the logic analysis system, then turn on the power to the target system.


**See Also**

“Designing a Target System for the Emulation Module” on page 138.


---

## To connect to a target system using an analysis probe

- 1 Remove power from the target system.
- 2 Plug one end of the 50-pin cable into the emulation module. The connectors are keyed.



- 3 Plug the other end of the 50-pin cable into the connector on the analysis probe.




## To update firmware

After you have connected the emulation module to your target system, you may need to update the firmware to give it the right “personality” for your processor. You must update the firmware if:

- The emulation module is being connected to a new analysis probe or TIM, or
- The emulation module was not shipped already installed in the logic analysis system, or
- You have an updated version of the firmware from Agilent Technologies.

To update the firmware:

- 1** End any run control sessions which may be running.
- 2** In the Workspace window, remove any Emulator icons from the workspace.
- 3** Install the firmware onto the logic analysis system’s hard disk, if necessary.
- 4** In the system window, click the emulation module and select **Update Firmware**.



- 5** In the Update Firmware window, select the firmware version to load into the emulation module.
- 6** Click **Update Firmware**.

In about 20 seconds, the firmware will be installed and the screen will update to show the current firmware version.

### See Also

Chapter 2, “Installing Software,” beginning on page 29, for instructions on how to install the firmware files on the hard disk.



---

## To display current firmware version information

- In the Update Firmware window, click **Display Current Version**.


There are usually two firmware version numbers: one for “Generics” and one for the personality of your processor.

---

## To verify communication between the emulator and target system

- 1 Turn on the target system.
- 2 Start the Emulation Control Interface.

If the the electrical connections are correct, and if the emulator firmware and analysis probe or TIM match your target processor, the Run Control window should be displayed:



## Configuring the Emulation Module

The emulation module has several user-configurable options. These options may be customized for specific target systems and saved in configuration files for future use.

The easiest way to configure the emulation module is through the Emulation Control Interface in an Agilent Technologies 16600A or 16700A logic analysis system.

If you use the Emulation Control Interface, please refer to the online help in the Configuration window for information on each of the configuration options.

Other ways to configure the emulation module are by using:

- the emulation module's built-in terminal interface
- your debugger, if it provides an "emulator configuration" window which can be used with this Agilent Technologies emulation module

### **What can be configured**

The following options can be configured using the Emulation Control Interface or using built-in commands:

- Processor type.
- Processor clock speed.
- Initial values for internal registers (see Chapter 7, "Using Internal Registers (SIM and EMSIM Registers)," beginning on page 167).

The following option can be configured using built-in commands:

- Restriction to real-time runs.

The built-in "help cf" command also lists the following options, which are provided only for compatibility with standalone emulation probes:

- BNC break in behavior.
- BNC trigger out behavior.

## To configure using the Emulation Control Interface


The easiest way to configure the emulation module is to use the Emulation Control Interface.

### 1 Start an Emulation Control Interface session.

In the system window, click the Emulation Control Interface icon, and then select **Start Session...**

### 2 Open a Configuration window.

Select **Configuration...** from the Emulation Control Interface icon or from the Navigate menu in any Emulation Control Interface window.



### 3 Set the configuration options, as needed.

Configuration changes will take effect when you close the configuration window or when you move the mouse pointer outside the window.

### 4 Save the configuration settings.

To save the configuration settings, open the File Manager window and click **Save...**

**See Also**

**Help→Help** on this window in the Configuration window for information on each of the configuration options.

**Help** in the Emulation Control Interface menu for help on starting an Emulation Control session.

---

## To configure using the built-in commands

If you are unable to configure the emulation module with the Emulation Control Interface or a debugger interface, you can configure the emulation module using the built-in “terminal interface” commands.

- 1** Connect a telnet session to the emulation module over the LAN.

For example, on a UNIX system, for an emulation module in Slot 1 enter:

```
telnet LAN_address 6472
```

- 2** Enter **cf** to see the current configuration settings.
- 3** Use the **cf** command to change the configuration settings.

**See Also**

Enter **help cf** for help on the configuration commands.

For information on connecting using telnet, and for information on other built-in commands, see page 277.

### Example

To see a complete list of configuration items, type **help cf**. This command displays:

```
M>help cf

cf - display or set emulation configuration

cf                - display current settings for all config items
cf <item>         - display current setting for specified <item>
cf <item>=<value> - set new <value> for specified <item>
cf <item> <item>=<value> <item> - set and display can be combined

help cf <item>   - display long help for specified <item>

--- VALID CONFIGURATION <item> NAMES ---
proc             - Set type of CPU16/32 Processor
procck          - Set Clock Speed of Processor
dprocck         - Display Default Clock Speed of Processor
rxt             - Enable or Disable Restriction to Real-Time Runs
breakin         - Select BNC break input option
trigout         - Select BNC trigger output option
M>
```

---

## To configure using a debugger

Because the Agilent Technologies emulation module can be used with several third-party debuggers, specific details for sending the configuration commands from the debugger to the emulation module cannot be given here. However, all debuggers should provide a way of directly entering terminal mode commands to the emulation module. Ideally, you would create a file that contains the modified configuration entries to be sent to the emulation module at the beginning of each debugger session.

### See Also

Information about specific debuggers in Chapter 8, “Using the Emulator with a Debugger,” beginning on page 181.

Your debugger manual.

## To configure the processor type

### Processor type configuration

Value	Built-in command	Notes
<b>CPU32 Processor Types</b>		
68330	cf proc=68330	
68331	cf proc=68331	
68332	cf proc=68332	
68333	cf proc=68333	
68334	cf proc=68334	
68335	cf proc=68335	
68336	cf proc=68336	
68338	cf proc=68338	
68340	cf proc=68340	
68341	cf proc=68341	
68349	cf proc=68349	
68360	cf proc=68360	
68376	cf proc=68376	
683xx	cf proc=683xx	Use for other CPU32 processors
<b>CPU16 Processor Types</b>		
68hc16z1	cf proc=68hc16z1	
68hc16z2	cf proc=68hc16z2	
68hc16y1	cf proc=68hc16y1	

The **cfsave -s** command will store this configuration in the emulation module's flash memory. The **cfsave -r** command will restore this configuration.

If you are using a processor in your target that is not listed as a choice, the emulator can provide direct access to all the registers defined in the CPU32 architecture programming model but will not have direct access to memory mapped registers in the processor's internal modules.

If you are using a processor that is listed as a choice, the emulator will have knowledge of on-chip peripheral registers and SIM registers and

will allow display and modification from the user interface. For example, when 68332 is selected as the processor type, the interface will support direct access to the SIM, the QSM, the TPU, and the TPURAM registers.

The emulator does not have explicit support for all CPU32 processors. When using a member of the CPU32 family that is not explicitly supported it may be possible to select a processor that is a formal subset of the unsupported processor. This will provide direct access to all of the internal memory mapped registers that are common. Since the registers in the internal modules are memory mapped, registers in unsupported CPU32 processors are also accessible through the memory commands. For example, on a 68332, SIM registers can be accessed at memory locations 7FFA00 to 7FFA7F or FFFA00 to FFFA7F.

---

## To configure the processor clock speed (BDM communication speed)

The maximum communication rate with the target processor through the BDM port is based upon the target processor type and the target processor clock speed.

For best performance, set the processor clock speed to the highest speed that is equal to or less than the clock speed of the target processor. You may set the processor clock speed to a speed lower than the actual clock speed of your target system. Use the 25 MHz option for microcontrollers running faster than 25 MHz.

If using the internal clock synthesizer, set the EMSYNCR (EMulator copy of the SYNthesizer Control Register, SYNCR) to the same value as set by the initialization code. See Chapter 7, “Using Internal Registers (SIM and EMSIM Registers),” beginning on page 167.

**Processor clock speed configuration**

<b>Value</b>	<b>Processor clock is at least</b>	<b>Built-in command</b>
33	33 MHz	<code>cf procck=33</code>
25	25 MHz	<code>cf procck=25</code>
20	20 MHz	<code>cf procck=20</code>
16	16 MHz	<code>cf procck=16</code>
8	8 MHz (default)	<code>cf procck=8</code>
4	4 MHz	<code>cf procck=4</code>
2	2 MHz	<code>cf procck=2</code>
1	1 MHz	<code>cf procck=1</code>
512	512 kHz	<code>cf procck=512</code>
32	32 kHz	<code>cf procck=32</code>

Use the `cf dprocck` command to display the default clock speed.

---

## To set the default clock rate if the processor clock rate is less than 8 MHz

For an emulation module, the default clock rate must be set using the Emulation Control Interface.

- 1 End any Emulation Control Interface session for the emulation module.
- 2 Right-click the Emulation Control Interface icon and select **Update Firmware...**
- 3 Click **Modify Lan Port...**



- 4 Select the clock rate.
- 5 Click **Apply**, then click **Close**.

If a target system's processor clock rate is less than 8 MHz following powerup, the default clock rate must be set to 131 kHz.

This can occur when the target system has the processor running off of an external clock source that is less than 8 MHz or is using the clock synthesizer with a crystal that is lower in frequency than the standard crystal.

The actual processor clock rate should then be communicated to the emulator through the configuration processor clock rate entry. The emulator will then start communications with the target processor at the 131 kHz processor clock rate. When the configuration process is complete, the emulator will change the communication rate to a rate based on the clock speed (procck).

The emulator will not communicate correctly with target systems that have a processor clock rate slower than 131 kHz.

**Note**

The emulator does not automatically match the communication speed to the actual target speed (SYNCR register). Maintaining consistency is the responsibility of the user.

To maintain consistency, specify a correct SYNCR register value in the configuration process and make sure that the target code does not change the SYNCR register to a value that is slower than what is specified in the configuration.

*The emulator will not run correctly if the actual target processor clock rate is slower than the rate specified in the configuration.*

## Detailed information about processor clock rates

Most target systems will communicate with the emulator properly and with excellent performance following the basic guidelines given in the preceding sections. In some target systems, the setting of this parameter requires greater knowledge of the actual clock generation model.

The CPU32 family has two major use models for the processor clock rate which can be used to support the majority of target systems. When using the internal clock synthesizer, the processor will run from reset at a Motorola defined default clock rate which, when using the Motorola recommended crystal is usually 8.38 MHz or 1/2 of the maximum clock rate of the processor. The programmer's initialization code then programs the clock synthesizer to run at the desired clock rate which is usually higher than the default. The second model uses an external clock source to directly control the processor clock rate. The emulator directly supports both processor clock rate models. Users that use a different clock rate model can examine the support of these models to determine the correct settings for supporting their processor clock rate.

The emulator supports the use model of the target processor clock rate being increased through the configuration. When applying the configuration at the start of a user interface or through the configuration process, the emulator communicates with the target processor at a rate based on the default processor clock rate (either 8 MHz or 131 kHz). At this default rate, it copies the EMSYNCR (EMulator copy of the SYNthesizer Control Register) to the SYNCR (SYNthesizer Control Register). The emulator then changes its communications rate to the maximum rate that the processor clock rate specified in the configuration can support.

Resetting the target processor also resets the SYNCR to its default value. If the target processor is reset while running user code (as opposed to putting the processor in a reset state from the interface), no communications rate change takes place within the emulator. The

initialization code that runs on the target system from reset is required to set the SYNCR to the correct value.

When the target processor clock rate is fixed through the use of an external clock source, the Processor Clock Rate parameter can be set to the highest rate that is equal to or less than the target clock rate. There are no dependencies upon any other configuration parameters.

For the 6833x interface, when the target system is using the internal clock synthesizer to increase the final clock rate but the user leaves the emulator at the default processor type (683xx) the EMSYNCR is not available to the configuration process. The powerup default clock rate for the target system can be entered into the "Processor Clock Rate". This is a failsafe setting but can limit the emulator performance if the target processor is programmed to run at a significantly faster rate than the powerup default.

If the user desires the higher performance available by setting the "Processor Clock Rate" configuration parameter to his final value but does not set his processor type (which means that the configuration process cannot set the SYNCR) the debugger interface will have a number of failures when invoked because it cannot communicate accurately with the target processor. These will show up as either dashes or bad values in the source, backtrace, and memory windows. These errors can be cleared up if the target system can support a "run from reset" with code in the target system that initializes the target SYNCR register. Following the target initializing this register, a break can be requested and the emulator will communicate correctly with the target. Until the emulator and the target system are running at compatible rates, operations such as "run," "load," "modify memory/registers," or "display memory/registers" will either fail or give incorrect information.

If the user loses communication between the emulator and the target system because of incompatible clock rates, control of the target processor through the emulator can be recovered by applying the configuration to the emulator with the target processor clock rate set to a known good value.

## To configure restriction to real-time runs

### Real-time runs configuration

Value	Emulation module configuration	Built-in command
no	Allows commands which break to the monitor. Examples include commands which display memory or registers. (Default)	<code>cf rrt=no</code>
yes	No commands are allowed which break to the monitor, except "break," "reset," "run," or "step."	<code>cf rrt=yes</code>

## Testing the emulator and target system

After you have connected and configured the emulator, you should perform some simple tests to verify that everything is working.

### **See Also**

Chapter 13, “Troubleshooting the Emulation Module,” beginning on page 273, for information on testing the emulator hardware.

---

## To test memory accesses

- 1** Start the Emulation Control Interface and configure the emulator, if necessary.
- 2** Open the Memory window.
- 3** Write individual locations or fill blocks of memory with patterns of your choosing.

The access size is the size of memory access that will be used to write or read the memory values.

- 4** Use the Memory I/O window to stimulate I/O locations by reading and writing individual memory locations.
- 

## To test with a running program

To more fully test your target, you can load simple programs and execute them.

- 1** Compile or assemble a small program and store it in a Motorola S-Record or Intel Hex file.
  - 2** Use the Load Executable window to download the program into
-

RAM or flash memory.

- 3** Use the Breakpoints window to set breakpoints. Use the Registers window to initialize register values.

The new register or breakpoint values are sent to the processor when you press the Enter key or when you move the cursor out of the selected register field.

- 4** In the Run Control window, click Run.
- 5** Use the Memory Mnemonic window to view the program and use the Memory window to view any output which has been written to memory.

---

## Using Internal Registers (SIM and EMSIM Registers)

## Internal Registers (SIM and EMSIM Registers)

### **The purpose of SIM Registers**

The CPU32 family of processors provides a variety of internal peripheral and memory modules that are directly connected to the CPU32 core through an internal bus. These modules are configured through memory mapped register banks. The base address of the register banks as well as the base address of internal memory modules are established through Module Configuration Registers (e.g. MCR) and Base Address Registers (e.g. CSBARx). A common module throughout the family is a System Integration Module (SIM) which controls such things as clock speed and external chip selects.

### **The purpose of EMSIM registers**

The emulator maintains a set of pseudo registers known as EMSIM registers. There is a one to one correspondence between the the EMSIM registers and the target SIM registers. The purpose of the EMSIM registers is to provide a stable, known set of registers that can be copied into the SIM to establish an initial SIM state or re-establish a previous known state. This is useful because it allows emulator to communicate with a target without first running initialization code to set up the chip select registers.

The names and values of the EMSIM registers are displayed in the Configuration window of the Emulation Control Interface. The SIM registers can be viewed in the Registers window.

#### **Note**

The emulator supports configuration of the internal registers in the System Integration Module (SIM) and other important Module Configuration Registers and Base Address Registers. To simplify the interface, all configurable registers will be referred to as SIM registers even if they are technically part of another module.



---

## Configuring the SIM Registers

### Summary

If you have a boot ROM that initializes the SIM registers, you don't have to configure the EMSIM registers in order to load code and run your target. It is a good idea to configure the EMSIM registers anyway, since the EMSIM registers are used to configure an analysis probe. Page 171 discusses how to copy the SIM registers into the EMSIM registers.

If you do not have a boot ROM, then you will need to initialize the EMSIM registers first so that you can communicate with the memory of the processor. Once the EMSIM registers are defined, then every reset followed by a break will write the EMSIM registers to the processor's SIM registers.

Once you have configured the EMSIM registers, it is a good idea to save a configuration. Loading the configuration will restore the values of all configuration options, including the EMSIM registers.

### How SIM Register Values are Set

These registers are typically initialized by the CPU32 executing the reset initialization code. During development this code may not be available or may not exist on the target system. To aid in development, the most important of these registers can be set directly by the emulator. This enables such functions as clock speed, chip selects, and location of internal memory to be established prior to executing any user code. Once these registers are set, resources in the target system can be accessed in the same manner as the processor would access them after executing the reset initialization code. Activities such as downloading code into the target system can now be performed through the emulator.

The emulator copy is identified by the prefix "EM" on the register name (e.g. EMSYNCR is the emulator copy of the SYNCR register) and are referred to as the EMSIM. The EMSIM registers are transferred to the processor registers when the target processor is reset while it is running in the BDM monitor.

### **Configuring the SIM Registers**

Based on the previous discussion, it should be clear that the EMSIM values specified during configuration need to match the intended programming and of use of your CPU32 target system. You need to carefully decide how the processor will be configured and the corresponding SIM values.

### **The effect of processor type on the EMSIM registers**

EMSIM registers are valid only if the emulator has been configured with a target processor name other than 683xx. If the processor is 683xx, the emulator does not know what type of SIM exists in the target and will not display correct values for the SIM registers.

### **Using the Emulation Control Interface or built-in commands**

If you are using the logic analysis system's Emulation Control Interface, you should use the Emulation Control Interface to work with SIM and EMSIM registers.

If you are using a debugger, use a telnet window or your debugger's "emulator command" window to enter the emulator's built-in commands.

#### **See Also**

See "Emulation Module Built-in Commands" on page 277 for more information on how to use built-in commands.

## Configuring EMSIM Register Values

There are two methods you can use to configure EMSIM register values:

- Copy values from the SIMs into the EMSIM registers, or
- Manually define each of the EMSIM values.

This will not change the value of the SIM registers.

---

### To copy target SIM registers to EMSIM registers

If you have initialization code that properly defines the SIMs, you can copy your values of the SIMs into the EMSIM registers. Then you can save the EMSIM values in a configuration file.

#### **Using the Emulation Control Interface:**

- In the Configuration window, click the **Read Configuration** button.

#### **Using the emulator's built-in commands:**

- Enter the **sync sim** command.
- 

### To manually define EMSIM values

#### **Using the Emulation Control Interface:**

- 1 Open the Configuration window.
  - 2 Enter the values for the registers.
-

**Configuring EMSIM Register Values**

- 3** Open the Workspace window and select **File→Save Configuration...**

The EMSIM values will be saved as part of the configuration. This allows you to restore the EMSIM values by loading the configuration.

---

## Configuring SIM Register Values

There are three ways to configure the values of the SIM registers:

- Using code in your target's boot ROM, or
- Copying values from the EMSIM registers into the SIM registers, or
- Manually entering the value of each SIM register using the Emulation Control Interface

**Some registers can only be written once after processor reset.**

If you set the EMSIM values, then reset and break, the EMSIM values will be written to the SIM registers. If your initialization code then attempts to write to one of the "write once after reset" registers, the writes will fail. In this case, you must run from reset to correctly execute the initialization code.

---

## To copy EMSIM registers to target SIM registers

You can copy values from the EMSIM registers into the SIM registers in three ways:

### Using the Emulation Control Interface:

- In the Configuration window, click the **Load Configuration** button.

### Using the emulator's built-in commands:

- Enter the **sync emsim** command.

### By resetting the target:

- 1 Reset the target processor.

- 2 Break the target processor.

**Some registers can only be written once after processor reset.**

If you set the EMSIM values, then reset and break, the EMSIM values will be written to the SIM registers. If your initialization code then attempts to write to one of the "write once after reset" registers, the writes will fail. In this case, you must run from reset to correctly execute the initialization code.

---

## To manually define SIM values

### **Using the Emulation Control Interface:**

- 1 Open the Registers window.
- 2 Enter the values for the registers.

Once you have entered the values, it is a good idea to copy the SIM values to the EMSIM registers and save a configuration. Then you will be able to reload the SIM registers without typing all the values again:

- 3 In the Configuration window, click the **Read Configuration** button.
- 4 Open the Workspace window and select **File→Save Configuration...**

## Saving and Loading EMSIM Values

You can use the Emulation Control Interface to save the EMSIM values to a configuration file then to restore the EMSIM values.

**The configuration file contains more than just the EMSIM values.**

When you load the configuration, the whole emulator configuration will be restored, including all configuration settings, and the locations of windows. Intermodule measurement configurations will be lost (unless you save and restore with the Source set to **All**).

---

### To save EMSIM values in a configuration file

- 1 Open the Workspace window and select **File→Save Configuration...**
- 2 Set the **Source** field to the emulator (for example, **Motorola CPU16/32 BDM Emulator (Slot 1)**).
- 3 Select a file name and click **Save**.

---

### To load EMSIM values from a configuration file

Once you have saved the configuration, you can specify the saved configuration file and have your EMSIMs set up to the proper values.

- 1 Open the Workspace window and select **File→Load Configuration...**
- 2 Set the **Source** field to the emulator (for example, **Motorola CPU16/32 BDM Emulator (Slot 1)**).

**Saving and Loading EMSIM Values**

**3** Select a file name and click **Load**.

This will not change the SIM registers. To apply the new values to the corresponding SIM registers, see “To copy EMSIM registers to target SIM registers” on page 173.



## Configuring SIM and EMSIM Values Using Built-In Commands

---

### To compare SIM and EMSIM registers

Target SIM registers may be compared to the EMSIM to determine if they have changed. The only way to do this is with a built-in command:

- Enter the **sync diff** command.

This will display the differences between the SIM and EMSIM register sets.

**The emulator, when comparing SIM and EMSIM registers, will not compare EMSIM registers that have not been set.**

When you first turn on the emulator and the target system, **sync diff** will not find any differences. If one register is modified, just that one register may show differences. A complete check of the register differences will occur only if a complete configuration is loaded or the SIM registers are copied to the EMSIM registers.

## Summary of EMSIM-related built-in commands

<b>Command</b>	<b>Meaning</b>
<code>sync sim</code>	Copy values from SIM registers to EMSIM registers
<code>sync emsim</code>	Copy values from EMSIM registers to SIM registers
<code>sync diff</code>	Display differences between SIM and EMSIM registers
<code>reset</code> <code>break</code>	Reset, break, and copy values from EMSIM registers to SIM registers

### **See Also**

Use the **help sync** command to display help for these commands.

See “Emulation Module Built-in Commands” on page 277 for more information on how to use built-in commands.

## Internal Representation of SIM and EMSIM Registers

Internal to the emulator the EMSIM and SIM memory spaces are accessed using memory suffixes of the form `offset@emsim` and `offset@reg`. All memory mapped registers in the 683xx family are contained within a contiguous 4k block of memory (8k for the 68360). The base address is determined by the SIM MCR MM bit in the 6833x or the MBAR in the 68340 and 68360 processors. The internal representation within the emulator of these registers is maintained as an offset to the memory mapped register base. Referencing memory as `offset@emsim` will access a SIM copy value in the EMSIM. Referencing `offset@reg` will access a register within the processor. For example, on a 68332 the memory address `00a00@emsim` will access the EMSIM MCR and `0a00@reg` will access the SIM MCR. The memory address `0@reg` within a 68340 will access its SIM MCR.

The command used to compare the values with the EMSIM and SIM will result in memory references using this notation. For example suppose the command is given to compare the SIM and EMSIM within the 68332. Further suppose that the the values in the Clock Synthesizer Control differ. This is the SIM register SYNCR. The resulting display may look as follows:

```
0a04@emsim=000, 0a04@reg=03f
0a05@emsim=000, 0a05@reg=008
```

Refer to the processor data book to understand which SIM register is differing.

**Internal Representation of SIM and EMSIM Registers**

---

Using the Emulator with a Debugger

---

## Using the Emulator with a Debugger

Several prominent companies design and sell state-of-the-art source debuggers which work with the Agilent Technologies emulation module and emulation probe.

### **Benefits of using a debugger**

The debugger will enable you to control the execution of your processor from the familiar environment of your debugger. Using a debugger lets you step through your code at the source-code level.

With a debugger connection, you can set breakpoints, single-step through source code, examine variables, and modify source code variables from the debugger interface. The debugger can also be used to download executable code to your target system.



Using a debugger to connect to the emulator allows the entire design team to have a consistent interface from software development to hardware/software integration.

Debugger interfaces must be ordered directly from the debugger vendor.

### **Compatibility with other logic analysis system tools**

You can use your logic analysis system to collect and analyze trace data while you use your debugger. If you are using an X windows workstation or a PC with an X terminal emulator, you can display the logic analyzer windows right next to your debugger.

Here is an example of what the display on your PC or workstation might look like:



## Using the Emulator with a Debugger

### Minimum requirements

To use a debugger with the emulator, you will need:

- A debugger which is compatible with the emulator
- A LAN connection to the PC or workstation that is running the debugger
- X windows or an X terminal emulator, such as Reflection X on a PC. This is required only if you wish to have the logic analysis system user interface displayed on your PC or workstation screen, along with the debugger.

### Is your debugger compatible with the emulator?

Ask your debugger vendor whether the debugger can be used with an Agilent Technologies emulation module or emulation probe (also known as a "processor probe" or "software probe").

### LAN connection

You will use a LAN connection to allow the debugger to communicate with the emulator.

### Compatibility with the Emulation Control Interface

Do not use the logic analysis system's Emulation Control Interface and your debugger at the same time.



## Setting up Debugger Software

The instructions in this manual assume that your PC or workstation is already connected to the LAN, and that you have already installed the debugger software according to the debugger vendor's documentation.

To use your debugger with the emulator, follow these general steps:

- Connect the emulator to your target system (see page 147).
- Connect the emulator or logic analysis system to the LAN (page 186).
- Export the logic analysis system's display to your PC or workstation (page 190).
- Configure the emulator (page 154).
- Begin using your debugger.

If you use the Emulation Control Interface to configure the emulator, remember to end the Emulation Control Interface session before you start the debugger.

---

**CAUTION:**

Do not use the Emulation Control Interface at the same time as a debugger. The Emulation Control Interface and debuggers do not keep track of commands issued by other tools. If you use both at the same time, the tools may display incorrect information about the state of the processor, possibly resulting in lost data.

---

**See Also**

Refer to the documentation for your debugger for more information on connecting the debugger to the emulator.

## To connect the logic analysis system to the LAN

Information on setting up a LAN connection is provided in the online help or installation manual for your logic analysis system.

Your debugger will require some information about the LAN connection before it can connect to the emulator. This information may include:

- IP address (Internet address) or LAN name of the logic analysis system.
- Gateway address of the logic analysis system.
- Port number of the emulator.

### Port numbers for emulators

Port number	Use for
<b>Debugger connections</b>	
6470	Slot 1 (First emulator in an Agilent Technologies 1660A/700A-series logic analysis system)
6474	Slot 2 (Second emulator in an Agilent Technologies 16700A-series system)
6478	Slot 3 (Third emulator in an expansion frame)
6482	Slot 4 (Fourth emulator in an expansion frame)
<b>Telnet connections</b>	
6472	Slot 1 (First emulator)
6476	Slot 2 (Second emulator)
6480	Slot 3 (Third emulator)
6484	Slot 4 (Fourth emulator)

Write the information here for future reference:

IP Address of Logic Analysis System \_\_\_\_\_

LAN Name of Logic Analysis System \_\_\_\_\_

Gateway Address \_\_\_\_\_

Port Number of Emulator \_\_\_\_\_

## To change the port number of an emulator

Some debuggers do not provide a means to specify a port number. In that case, the debugger will always connect to port 6470 (the first emulator). If you need to connect to another module, or if the port number of the first module has been changed, you must change the port number to be 6470.

To view or change the port number:

- 1** Click on the emulation module icon in the system window of the logic analysis system, then select Update Firmware.
- 2** Select Modify Lan Port...
- 3** If necessary, enter the new port number in the Lan Port Address field.

The new port number must be greater than 1024 and must not already be assigned to another emulator.

## To verify communication with the emulator

- 1** Telnet to the IP address.

For example, on a UNIX system, enter “telnet <IP\_address> 6472”. This connection will give you access to the emulator’s built-in terminal interface. You should see a prompt, such as “M>”.

- 2** At the prompt, type:

```
ver
```

You should then see information about the emulator and firmware version.

- 3** To exit from this telnet session, type <CTRL>D at the prompt.

### **See Also**

The online help or manual for your logic analysis system, for information on physically connecting the system to the LAN and configuring LAN parameters.

If you have problems verifying LAN communication, see page 283.

## To export the logic analysis system's display to a workstation

By exporting the logic analyzer's display, you can see and use the logic analysis system's windows on the screen of your workstation. To do this, you must have telnet software and X window installed on your computer.

- 1 On the workstation, add the host name of the logic analysis system to the list of systems allowed to make connections:

```
xhost +<IP_address>
```

- 2 Use telnet to connect to the logic analysis system.

```
telnet <IP_address>
```

- 3 Log in as "logic".

The logic analysis system will open a Session Manager window on your display.

- 4 In the Session Manager, click Start Session on This Display.

### Example

On a UNIX workstation, you could use the following commands to export the display of a logic analysis system named "mylogic":

```
$ xhost +mylogic
$ telnet mylogic
Trying...
Connected to mylogic.mycompany.com.
Escape character is '^]'.
Local flow control on
Telnet TERMINAL-SPEED option ON

Agilent Technologies Logic Analysis System

Please Log in as: logic [displayname:0]

login: logic
Connection closed by foreign host.
```

## To export the logic analysis system's display to a PC

By exporting the logic analyzer's display, you can see and use the logic analysis system's windows on the screen of your PC. To do this, you must have telnet software and an X terminal emulator installed on your computer. The following instructions use the Reflection X emulator from WRQ, running on Windows 95, as an example.

- 1** On the PC, start the X terminal emulator software.

To start Reflection X, click the Reflection X Client Startup icon.

- 2** Start a telnet connection to the logic analysis system.

Log in as "logic".

For Reflection X, enter the following values in the Reflection X Client Startup dialog:

- a** In the Host field, enter the LAN name or IP address of the logic analysis system.
- b** In the User Name field, enter "logic".
- c** Leave the Password field blank.
- d** Leave the Command field blank.
- e** Click Run to start the connection.

The logic analysis system will open a Session Manager window on your display.

- 3** In the Session Manager window, click Start Session on This Display.

## Using the Green Hills debugger


### Compatibility

Version 1.8.8.A of the MULTI Development Environment from Green Hills Software, Inc. is one of several debuggers which connect to the Agilent Technologies emulation module.

This section provides information that is specific to using MULTI with the Agilent Technologies emulation module. It is intended to be used in conjunction with the MULTI documentation provided by Green Hills Software.

### Overview

MULTI connects to an emulation module through the Green Hills host-resident program (hpserv).



### Getting started

- 1 Check that your Emulation Module is programmed with firmware for a CPU32 processor.

Go to the system window of the logic analyzer interface and verify that the Emulation Module icon is described as a "Motorola CPU16/32 BDM Emulator". If it is not, follow the instructions on page 152 to update the firmware.

- 2 Build the executable.



If you have the demo software shipped with the Green Hills debugger, follow these steps:

**a** Prepare the executable.

Go to the 68000PC subdirectory where you installed MULTI. Copy the default.lnk file to user.lnk.

**b** Start MULTI.

On Unix, enter "multi".

On Windows, double-click the Green Hills icon.

**c** Set up the MULTI software environment:

- Replace the project default.bld (in the Builder dialog box next to the project button) with hpdemo/ecs.bld and press ENTER.
- Make sure the target button on the MULTI window says "cross 68".
- In the Builder window, double-click ecs.bld.

The box next to the Debug button should display "ecs". The window should list the names of the source code files.

**d** In the Builder menu bar, select **Options→CPU**, then set the processor type.

**e** In the Builder menu bar, select **Options→Advanced**, and select the default output mode.

**f** Build the demo program:

- In the Builder window, click the Build icon. (Or, in the menu bar, select **Build→Build All**.)
- Close the Progress window when the "Build completed" message is displayed.

**g** Select **Options→Advanced**, and select the IEEE-695 output mode to generate an IEEE-695 format file.

**3** Connect MULTI to the emulation module.

There are two ways to connect to the emulation module:

- In the Remote box in the MULTI Builder window, enter:

```
hpserv IP_address
```

## Chapter 8: Using the Emulator with a Debugger

### Using the Green Hills debugger

OR

- In the Builder window, click Debug to open the Debugger window, then in the Debugger window's command pane, enter:

```
remote hpserv IP_address
```

Starting hpserv opens two windows: the Target window and the I/O window. Commands entered in the Target window are sent directly to the emulation module.

The I/O window sends input (stdin) to and receives output (stdout) from the target program while it is running.

Note that hpserv connects to the first emulation module (port 6470) in a logic analysis system frame. You may specify another port by using the -p option with hpserv. See page 186 for more information on port numbers.

#### 4 Start the debugger.

If you have not opened the Debugger window yet, click **Debug** in the Builder window.

#### 5 Configure the emulation module and target system.

Before running the target processor, you must configure the Agilent Technologies emulation module for your target system. For example, you may have to set the BDM clock speed, the reset operation, cache disabling, or other configuration parameters.

If you are unsure of the configuration needed for your emulation module, you can use the Configuration window in the logic analysis system's Emulation Control Interface to explore the configuration options.

Once you know the configuration settings needed for your target system, you may use one of the following methods to configure the emulation module and target system:

- Use the Configuration window in the logic analysis system's Emulation Control Interface.
- Enter "cf" commands in the Target window.
- Use an initialization script.

See “To configure the emulation module, analysis probe, and target using an initialization script” on page 196 for information on saving the configuration commands in a script.

## 6 Specify an initialization address for the stack pointer.

This is required if the stack pointer is neither initialized when the processor is reset nor set in the start-up code generated by the compiler. If the stack pointer address needs to be initialized:

- In the debugger’s command pane, enter:

```
_INIT_SP = <address>
```

OR

- In the Target window, enter:

```
reg a7=<address>
```

OR

- \* Include the following line in an initialization script:

```
target reg a7=<address>
```

## 7 Download the code:

In the Debugger window, select **Remote→LoadProgram**.

The Debugger command pane indicates that the code has been downloaded to the target.

## **To configure the emulation module, analysis probe, and target using an initialization script**

You can use an initialization script to configure the emulation module and set up your target system. If you will always be using the same configuration, this way will save time and reduce errors.

- 1** Save the configuration commands in a text file, one command per line.

Green Hills provides an example initialization sequence in the file `hpserv.rc` in the "hpdemo" directory.

- 2** To run the script, enter the following command in the Debugger command pane:

```
<filename
```

### **Example: simple configuration script**

Create a file with the following lines:

```
remote hpserv logic1
target cf proc=68360
_INIT_SP=0x10000
```

Save the file in the MULTI startup directory and name it `hpserv.rc`. To run the script, enter the following command in the Debugger command pane:

```
<hpserv.rc
```

When run, this script will:

- Connect to the target through the emulation module in a logic analysis system frame called "logic1".
- Set the processor type.
- Initialize the stack pointer.

**Example: script to configure EMSIM and SIM registers**

The following script was written for a target which does not have boot ROM and which is connected to an analysis probe. The script sets the EMSIM registers, then copies the EMSIM values to the target processor (**sync emsim**) and to the analysis probe (**pp load**) to enable address reconstruction.

```
target m -d4 0000@emmbar=01000133
target m -d4 1000@emsim=00001438F
target m -d4 1040@emsim=017CD23A0
target m -d4 1034@emsim=000000000
target m -d4 1030@emsim=000000000
target m -d2 1014@emsim=000000000
target m -d2 1016@emsim=0000000A0
target m -d2 1026@emsim=00000070F
target m -d2 102A@emsim=000000000
target m -d2 1010@emsim=000008000
target m -d1 1008@emsim=000000084
target m -d1 100C@emsim=00000008C
target m -d1 1023@emsim=000000000
target m -d1 1022@emsim=00000000E
target m -d4 1050@emsim=000000000
target m -d4 1060@emsim=0A0000001
target m -d4 1070@emsim=000000000
target m -d4 1080@emsim=000000001
target m -d4 1054@emsim=000000000
target m -d4 1064@emsim=02FE00000
target m -d4 1074@emsim=000000000
target m -d4 1084@emsim=04FE00009
target m -d4 1090@emsim=000000000
target m -d4 10A0@emsim=000000000
target m -d4 10B0@emsim=000000000
target m -d4 10C0@emsim=000000000
target m -d4 1094@emsim=0F0000004
target m -d4 10A4@emsim=0F0000004
target m -d4 10B4@emsim=0F0000004
target m -d4 10C4@emsim=0F0000004
target cf proc=68360
target sync emsim
target pp load
```

## To perform common debugger tasks

- To display registers, click the **regs** button in the Display window.
- To set a breakpoint, click on the source code line where the breakpoint is to be located.
- To clear a breakpoint, click again on the source line.
- To step through code, click **next**.
- To run from the current PC, click **go**.
- To toggle the display between source code and source code interlaced with assembly code, click **assem**.
- To load program symbols, reset the PC, reset the stack pointer, and run from the start, click **restart**.

## To send commands to the emulation module

MULTI communicates to the emulation module using the emulation module's "terminal interface" commands. MULTI automatically generates and sends the commands required for normal operation. If you want to communicate directly with the emulation module during a debug session, you may do so using "terminal interface" commands through the Target window (which comes up when hpserv is brought up). You can also enter these commands from the Debugger window's command pane by preceding the command with the "target" command.

## To view commands sent by MULTI to the emulation module

The communication between MULTI and the emulation module can be viewed by running hpserv in a logging mode:

```
remote hpserv -dc -a -o <filename> <emulation module>
```

The options **-dc** and **-da** log both asynchronous and console messages and the **-o <filename>** directs these messages to a log file called *<filename>*. When using this option, disconnect from hpserv (to flush out the file) and then you may view *<filename>* to see what commands MULTI sent to the emulation module.

NOTE: logging commands in this way may result in a VERY large file. Beware of the disk space it may require.

## To reinitialize the system

If you suspect that the emulation module is out of sync with the MULTI debugger, you may want to reinitialize it. Perform the steps below to accomplish reinitialization:

- 3 In the Target window, type:

```
init -c
```

- 4 Repeat steps 5 through 8 in the "Getting started" section to configure the emulation module.

## To disconnect from the emulation module

- In the Debugger window, select **Remote→Disconnect**.

The Debugger command pane indicates that the debugger has disconnected from the emulation module.

## Error conditions

### **"!ERROR 800! Invalid command: bcast"**

usually means that there is not a target interface module (TIM) connected to the emulation module or the emulation module does not have firmware for the CPU32 family. Verify that the emulation module is connected to the target. Next, go to the system window of the logic analyzer interface and verify that the Emulation Module icon (stop-light) is described as a Motorola CPU16/32 BDM Emulator. If it is not, follow the steps on page 152 to update the firmware in the emulation module.

### **"command socket connection failed: WSAECONNREFUSED: connection refused"**

usually means the emulation module is not at port #6470 on the Logic Analysis System.

### See Also

*Green Hills MULTI Software Development Environment User's*

Chapter 8: Using the Emulator with a Debugger  
**Using the Green Hills debugger**

*Guide.*

*Using MULTI with the Agilent Technologies Processor Probe* from Green Hills Software, Inc.

The Green Hills web site: <http://www.ghs.com>

“Configuring the Emulation Module” on page 154 for more information on configuration options and the "cf" command.




## Using the Software Development Systems debugger

### Compatibility

Version 7.2 of the SingleStep debugger from Software Development Systems, Inc. is one of several debuggers which connect to the Agilent Technologies emulation module.

This section provides information that is specific to using SingleStep with the Agilent Technologies emulation module. It is intended to be used in conjunction with the SingleStep documentation provided by SDS.

### Overview



### Startup behavior

The following actions are performed at the start of a session and when you select **File→Debug**:

- If the target reset option is selected, the target is reset and programmed with the register values in the configuration file (*<filename>.cfg*).
- Hardware breakpoints are disabled.
- Software breakpoints are enabled.
- All breakpoints are cleared.
- `main()` `_exit` breakpoints are set, if that option is selected.

## Getting started

- 1 Check that your emulation module is programmed with firmware for a CPU32 processor:

Go to the system window of the logic analyzer interface and verify that the Emulation Module icon is described as a "Motorola CPU16/32 BDM Emulator". If it is not, follow the instructions on page 152 to update the firmware.

- 2 Connect to the emulation module:
  - a Start SingleStep running on your PC or workstation.
  - b When the small Debug dialog box appears in the middle of the screen, click the Connection tab and then enter the IP address of the Agilent Technologies logic analysis system which contains the emulation module.

If the Debug dialog box is not visible, select **File→Debug**.

Note: SingleStep is hard-coded to connect to the emulation module at port 6470 of the logic analysis system frame. See page page 188 for more information on port numbers.

- 3 Configure the emulation module with the processor clock speed.

In the Debug dialog box, click the Connection tab and then enter a Processor Clock speed which is less than or equal to the speed at which the processor will run out of reset.

The emulation module must know the target clock speed before it can communicate with the target. This value depends on the oscillator or crystal used on your target system and the multipliers applicable at reset. The communications speed can be changed (see "Download performance" on page 209) but will be reset to this value each time SingleStep resets the processor.

- 4 Initialize the target system.

The target system must have various registers and memory locations initialized before it can access RAM and before SingleStep can download an application. Normally, code in the target's boot ROM

performs this initialization. However, when SingleStep resets the target, it immediately places the processor in debug mode. Any initialization code which may exist on the target board has not been run.

SingleStep provides a way for target initialization to occur without running application code through the use of the "\_config" alias. \_config is used to define a list of commands that will be used to initialize the target after a reset. The \_config alias should be defined in the sstep.ini file (in the "cmd" directory) and will point to a file of type .cfg which contains the actual initialization commands.

SingleStep provides some workspace files for some standard targets. These files will setup various registers in order to initialize these targets. The files can be found in the *init* directory and are as follows:

- EST SBC 360 - est360.wsp
- Motorola 332 EVS revision a – 332evs\_a.wsp
- Motorola 332 EVS revision b – 332evs\_b.wsp
- Motorola 340 EVS – 340evs.wsp
- Nohau Trg-332 – trg332.wsp
- Vesta SBC332 – vesta332.wsp

Loading one of these workspace files followed by opening the Debug Dialog from the File Menu and setting the File and Connection options then clicking OK will create a corresponding .cfg file in the *cmd* directory. This file will store the values of the items shown in the Target Configuration tab. You may wish to edit these values before clicking OK and saving them to a .cfg file.

### Example

If you load the `est360.wsp` and set up the Debug Dialog options for the target you are connecting to, when you click OK, the file `68360.cfg` will be created and placed in the `cmd` directory. Comments have been added to this file, in order to explain the items (comments begin with a #).

```
Contents of 68360.cfg:
set vectbase = 0x400000
set vectaddr = 0x400000
write -l CPU:0x3FF00 = 0x08000133      # MBAR
write -l SD:0x08001000 = 0x00014F71   # MCR
write -b SD:0x08001022 = 0x0E        # SYPCR
write -l SD:0x08001040 = 0x17CD23A0   # GIMR
write -l SD:0x08001050 = 0x00000001   # BRO
write -l SD:0x08001054 = 0x3FFC0002   # OR0
write -l SD:0x08001060 = 0x00100001   # BR1
write -l SD:0x08001064 = 0x2FF80000   # OR1
write -l SD:0x08001080 = 0x00400001   # BR3
write -l SD:0x08001084 = 0x2FE00003   # OR3
write -b SD:0x0800100C = 0x8F        # CLKOCR
write -w SD:0x08001010 = 0x4000      # PLLCR
write -w SD:0x08001014 = 0x8000      # CDVCR
write -w SD:0x08001016 = 0x0000     # PEPAR
```

The `.cfg` file sets up the target's chip select registers (SIM registers) needed in order to map memory correctly. If your target is connected to an analysis probe, you will need to execute some additional commands in order to configure the analysis probe. The analysis probe stores its own copy of the chip select registers. In general, just executing the above write commands will configure the target's registers. The emulation module also stores a copy of these registers. The emulation module command "sync sim" listed below will copy the values of the target's SIM registers into the EMSIM registers. Next, the EMSIM registers must be copied over to the analysis probe. This is accomplished by issuing the built-in command "pp load". Enter the following two commands into the Command window:

```
control -c "sync sim"
control -c "pp load"
```

You should have the appropriate values for your target first written into

the SIM registers before issuing these two commands. “control -c” is used by SingleStep to forward a command to the emulation module. For help on either the “sync sim” or “pp load” command, issue the commands, control -c “help sync” or control -c “help pp load” into the Command window. Also, note that the help pp load command will refer to the analysis probe as a preprocessor. They are one in the same.

If your target is not one that SDS ships a workspace for, add a line to the bottom of the file “sstep.ini” (which is supplied with the debugger) that sets up the \_config alias to point to a .cfg file to use. This line will look like:

```
alias _config 'source ${cmdpath}68336.cfg'
```

In this case, the name of the config file to use is 68336.cfg. Edit this file specific for your targets need. Keep in mind, that commands beginning with “control -c” followed by a string of quoted text are commands that will be forwarded to the emulation module. Commands that do not begin with “control -c” are SingleStep commands.

### Example

Here is a configuration file which contains both emulation module built-in commands and SingleStep commands:

```
# Config file for 68336 Motorola Modular Board
# First set clock speed to 8 MHz
control -c "cf procck=8"

# Set the processor id to 68336
control -c "cf proc=68336"

set vectbase = 0x000000
set vectaddr = 0x000000
# write -l CPU:0x3FF00 = 0x01000133      # MBAR
# write -l SD:0x01001000 = 0x0001438F   # MCR
# write -b SD:0x01001022 = 0x0E        # SYPCR
# write -l SD:0x01001040 = 0x17CD23A0  # GIMR
# write -l SD:0x01001050 = 0x00000000  # BR0
# write -l SD:0x01001054 = 0x00000000  # OR0
# write -l SD:0x01001060 = 0xA0000001  # BR1
# write -l SD:0x01001064 = 0x2FE00000  # OR1
# write -l SD:0x01001080 = 0x00000001  # BR3
# write -l SD:0x01001084 = 0x4FE00009  # OR3
```

Chapter 8: Using the Emulator with a Debugger  
**Using the Software Development Systems debugger**

```
# write -b SD:0x0100100C = 0x8C           # CLKOCR
# write -w SD:0x01001010 = 0x8000        # PLLCR
# write -w SD:0x01001014 = 0x0000        # CDVCR
# write -w SD:0x01001016 = 0x00A0        # PEPAR
# write -w SD:0x01001026 = 0x070F        # PICR
# write -b SD:0x01001008 = 0x84           # AVR

# Reset, run, break in order to set up chip selects
# We can issue these commands since the target has boot
# code in ROM that sets up the chip select registers
control -c "rst"
control -c "r"
control -c "b"

# Issue the next two commands since there is an
# analysis probe connected to the target

# Copy the sim values to the emsim set
control -c "sync sim"
# Copy the emsim values to the analysis probe
control -c "pp load"
```

The config file shown in this example did not need to set up chip select registers because the target has boot code in ROM that will accomplish this. Therefore, just issuing a “reset, run, break” will execute the boot code in ROM. If your ROM does not contain boot code to set up these registers, add write commands to the .cfg file (similar to what is shown here for the 68360) to set up these values. Reset, run, break would not be used to set up a target that does not contain boot code.

Given that you added a line to the sstep.ini file that points to this configuration file, all you need to do now is to bring up the Debug Dialog and enter the file to download (if desired), and the connection port to use. Click OK when finished. This config file (the one pointed to by the added line in sstep.ini) will get executed if and only if you have not unchecked the “Reset Target” option on the Debug Dialog’s “Options” tab. This is selected by default. Deselecting this option will prevent the config file you specified in the sstep.ini file from being executed. Also, keep in mind that this file will be executed every time the Debug Dialog is terminated via the OK button when “Reset Target” is selected.

In summary, there are two ways for you to configure the emulation module and your target. The first method consisted of loading an existing workspace, using the Debug Dialog to modify any items needed followed by clicking the OK button and having it create a corresponding .cfg file. If you have an analysis probe connected to this target, you need to enter the two additional commands into the Command window (control -c "sync sim", control -c "pp load"). The second method consisted of creating a .cfg file and specifying that file in the *\_config* alias in the sstep.ini file. This file will automatically be loaded upon clicking OK in the Debug Dialog.

To save time, you may want to do the first method just to generate .cfg file that you can edit and use in method two. If you had an analysis probe connected you would add the two commands mentioned previously to the .cfg file thereby not having to enter them through the Command window.

The "Debug" dialog method and the sstep.ini method are mutually exclusive. Use one or the other, but not both.

Initialization of the target (that is, execution of the *\_config* alias) will not actually occur until the "Debug" dialog is successfully exited.

- 5 Set up the download and execution options in the Options tab of the Debug dialog.
- 6 Download the application and run:

Select the File tab and enter the application file name. Exit the "Debug" dialog box by clicking OK.

Emulation module initialization and target initialization occur every time the "Debug" dialog is terminated via the OK button. A summary of the actions taken by SingleStep is given here:

- Initialize the emulation module with the communication speed specified in the "Debug" dialog.
- If "reset target" was selected then execute the commands specified by the *\_reset* alias. The *\_reset* alias should be used to specify commands that are

## Chapter 8: Using the Emulator with a Debugger

### Using the Software Development Systems debugger

specific to initializing the processor. It is executed each time the processor is reset. The value of the `_reset` alias can be viewed by issuing a `"alias _reset"` from the command window.

- Execute the commands specified by the `_config` alias. The `_config` alias should be used to specify commands that are specific to initializing (configuring) the target system. It is executed each time the processor is reset and each time the debug dialog is exited. The value of the `_config` alias can be viewed by issuing an `"alias _config"` from the command window.
- If "load image" was selected then download the application and set the PC based on object module file contents.
- If "execute until main" was selected then set a breakpoint at `main()` and run.

## To send commands to the emulation module

### To view commands sent by SingleStep

SingleStep communicates to the emulation module using the emulation module's "terminal interface" commands. SingleStep automatically generates and sends the commands required for normal operation. This communication between SingleStep and the emulation module can be observed by entering the following command in the SingleStep command window:

```
control -ms
```

### To send commands

"Terminal interface" commands may be sent directly to the emulation module from the SingleStep command window or included in SingleStep's `.cfg` or `.dbg` command files.

Commands should be enclosed in double quotes and given the prefix:



control-c.

### Examples

To see the speed that the emulation module is using to communicate with the target system you would issue the following command in the SingleStep command window:

```
control -c "cf procck"
```

To change the speed to match a 25MHz processor clock you would issue the following command in the command window:

```
control -c "cf procck=25"
```

For more information about "terminal interface" commands see page 156.

## Download performance

Downloads are fastest when the emulation module speed is set to match that of the target processor. The initial speed that the emulation module uses to communicate with the target processor is set by the Processor clock item in the connection tab of the "Debug" dialog. The user is responsible for specifying this speed to be less than or equal to the initial, reset, speed of the processor. Usually a command in the `_config` alias will raise the speed of the processor above its initial, reset value. For maximum download performance the command to increase the target processor speed should be followed by a command to increase the speed of the emulation module communication:

### Example

After setting the clock rate of the target processor, the following command should be entered to increase the emulation module communication speed:

```
control -c "cf procck=25"
```

## Error conditions

"!ERROR 800! Invalid command: bcast" usually means that there is not a target interface module (TIM) connected to the emulation module or the emulation module does not have firmware for the CPU32 family. Verify that the emulation module is connected to the target. Next, go to the system window of the logic analyzer interface and verify that the Emulation Module icon (stop-light) is described as a Motorola CPU16/32 BDM Emulator. If it is not, follow the steps on page 152 to update the firmware in the emulation module.

### **"command socket connection failed: WSAECONNREFUSED:**

connection refused" usually means the emulation module is not at port #6470 on the Logic Analysis System. See step 2 of the getting started section above.

### **"unrecognized hostname"**

usually means that the debugger is unable to establish communication with the emulator. Verify communication to the emulation module by doing a ping to the logic analyzer. If you are unable to ping the logic analyzer refer to page 283 for more information.

### **See Also**

The SDS web site: <http://www.sdsi.com>

The *SDS SingleStep Users Guide*.

The configuration section beginning on page 154 for more information on configuration options and the "cf" command.

---

Using the Analysis Probe and  
Emulation Module Together

## Using the Analysis Probe and Emulation Module Together

This chapter describes how to use an analysis probe, an emulation module, and other features of your Agilent Technologies 16600A or 16700A logic analysis system to gain insight into your target system.

### **What are some of the tools I can use?**

You can use a combination of all of the following tools to control and measure the behavior of your target system:

- Your analysis probe, to acquire data from the processor bus while it is running full-speed.
- Your emulation module, to control the execution of your target processor and to examine the state of the processor and of the target system.
- The Emulation Control Interface, to control and configure the emulation module, and to display or change target registers and memory.
- Display tools including the Listing tool, Chart tool, and System Performance Analyzer tool to make sense of the data collected using the analysis probe.
- Your debugger, to control your target system using the emulation module. Do not use the debugger at the same time as the Emulation Control Interface.
- The B4620B Source Correlation Tool Set, to relate the analysis trace to your high-level source code.

### **Which assembly-level listing should I use?**

Several windows display assembly language instructions. Be careful to use to the correct window for your purposes:

- The Listing tool shows processor states that were captured during a “Run” of the logic analyzer. Those states are disassembled and displayed in the Listing window.
- The Emulation Control Interface shows the disassembled contents of a

section of memory in the Memory Disassembly window.

- Your debugger shows your program as it was actually assembled, and (if it supports the emulation module) shows which line of assembly code corresponds to the value of the program counter on your target system.

## **Which source-level listing should I use?**

Different tools display source code for different uses:

- The Source Viewer window allows you to follow how the processor executed code as the analyzer captured a trace. Use the Source Viewer to set analyzer triggers. The Source Viewer window is available only if you have licensed the B4620B Source Correlation Tool Set.
- Your debugger shows which line of code corresponds to the current value of the program counter on your target system. Use your debugger to set breakpoints.

## **Where can I find practical examples of measurements?**

The Measurement Examples section in the online help contains examples of measurements which will save you time throughout the phases of system development: hardware turn-on, firmware development, software development, and system integration.

A few of the many things you can learn from the measurement examples are:

- How to find glitches.
- How to find NULL pointer de-references.
- How to profile system performance.

To find the measurement examples, click on the Help icon in the logic analysis system window, then click on “Measurement Examples.”

## Triggering the Emulation Module from the Analyzer

You can trigger the emulation module from the logic analyzer using either the Source Viewer window or the Intermodule window. If you are using the Agilent Technologies B4620B Source Correlation Tool Set, using the Source Viewer window is the easiest method.


---

### To stop the processor when the logic analyzer triggers on a line of source code (Source Viewer window)

If you have the Agilent Technologies B4620B Source Correlation Tool Set, you can easily stop the processor when a particular line of code is reached.

- 1 In the Source window, click on the line of source code where you want to set the trigger, then select **Trace about this line**.

The logic analyzer trigger is now set.



- 2 Select **Trace→Enable - Break Emulator On Trigger**.

The emulation module is now set to halt the processor after receiving a trigger from the logic analyzer.

To disable the processor stop on trigger, select **Trace→Disable - Break Emulator On Trigger**.

- 3 Click **Group Run** in the Source window (or other logic analyzer window).
- 4 If your target system is not already running, click **Run** in the emulation Run Control window to start your target.

---

## To stop the processor when the logic analyzer triggers (Intermodule window)

Use the Intermodule window if you do not have the Agilent Technologies B4620B Source Correlation Tool Set or if you need to use a more sophisticated trigger than is possible in the Source Viewer window.

- 1 Create a logic analyzer trigger.
- 2 In the Intermodule window, click the emulation module icon, then select the analyzer which is intended to trigger it.



The emulation module is now set to stop the processor when the logic analyzer triggers.

- 3** Click **Group Run** in the Source window (or other logic analyzer window).
- 4** If your target system is not already running, click **Run** in the emulation Run Control window to start your target.

**See Also**

See the online help for your logic analysis system for more information on setting triggers.

---

## To minimize the “skid” effect

There is a finite amount of time between when the logic analyzer triggers, and when the processor actually stops. During this time, the processor will continue to execute instructions. This latency is referred to as the skid effect.

To minimize the skid effect:

- 1** In the Emulation Control Interface, open the Configuration window.
- 2** Set processor clock speed to the maximum value which your target can support.

The amount of skid will depend on the processor’s execution speed and whether code is executing from the cache. See page 159 for information on how to configure the clock speed.

---

## To stop the analyzer and view a measurement

- To view an analysis measurement you may have to click Stop



after the trigger occurs.

When the target processor stops it may cause the analyzer qualified clock to stop. Therefore most intermodule measurements will have to be stopped to see the measurement.

**Example**

An intermodule measurement has been set up where the analyzer is triggering the emulation module. The following sequence could occur:

1. The analyzer triggers.
2. The trigger (“Break In”) is sent to the emulation module.
3. The emulation module stops the user program which is running on the target processor. The processor enters a background debug monitor.
4. Because the processor has stopped, the analyzer stops receiving a qualified clock signal.
5. If the trigger position is “End”, the measurement will be completed.

If the trigger position is not “End”, the analyzer may continue waiting for more states.

6. The user clicks Stop in a logic analyzer window, which tells the logic analyzer to stop waiting, and to display the trace.

## Tracing until the processor halts

If you are using a state analyzer, you can begin a trace, run the processor, then manually end the trace when the processor has halted.

To halt the processor, you can set a breakpoint using the Emulation Control Interface or a debugger.

Some possible uses for this measurement are:

- To store and display processor bus activity leading up to a system crash.
- To capture processor activity before a breakpoint.
- To determine why a function is being called. To do this, you could set a breakpoint at the start of the function then use this measurement to see how the function is getting called.

This kind of measurement is easier than setting up an intermodule measurement trigger.

---

## To capture a trace before the processor halts

- 1** Set the logic analyzer to trigger on **nostate**.
- 2** Set the trigger point (position) to **End**.
- 3** In a logic analyzer window, click **Run**.
- 4** In the Emulation Control Interface or debugger click **Run**.
- 5** When the emulation module halts click **Stop** in the logic analyzer window to complete the measurement.

This is the recommended method to do state analysis of the processor bus when the processor halts.

If you need to capture the interaction of another bus when the processor halts or you need to make a timing or oscilloscope measurement you will need to trigger the logic analyzer from the emulation module (described in the next section).

## Triggering the Logic Analyzer from the Emulation Module

You can create an intermodule measurement which will allow the emulation module to trigger another module such as a timing analyzer or oscilloscope.

If you are only using a state analyzer to capture the processor bus then it will be much simpler to use “Tracing until processor halts” as described on page 218.

Before you trigger a logic analyzer (or another module) from the emulation module, you should understand a few things about the emulation module trigger:

### **The emulation module trigger signal**

The trigger signal coming from the emulation module is an “In Background Debug Monitor” (“In Monitor”) signal. This may cause confusion because a variety of conditions could cause this signal and falsely trigger your analyzer.

The “In Monitor” trigger signal can be caused by:

- The most common method to generate the signal is to click **Run** and then click **Break** in the Emulation Control Interface. Going from “Run” (Running User Program) to “Break” (“In Monitor”) generates the trigger signal.
- Another method to generate the “In Monitor” signal is to click **Reset** and then click **Break**. Going from the reset state of the processor to the “In Monitor” state will generate the signal.
- In addition, an “In Monitor” signal is generated any time a debugger or other user interface reads a register, reads memory, sets breakpoints or steps. Care must be taken to not falsely trigger the logic analyzers listening to the “In Monitor” signal.

## **Group Run**

*The intermodule bus signals can still be active even without a Group Run.*

The following setups can operate independently of Group Run:

- Port In connected to an emulation module
- Emulation modules connected in series
- Emulation module connected to Port Out

Here are some examples:

- If “Group Run” is armed from “Port In” and an emulation module is connected to Group Run, then any “Port In” signal will cause the emulation module to go into monitor. The Group Run button does not have to be pressed for this to operate.
- If two emulation modules are connected together so that one triggers another, then the first one going into monitor will cause the second one to go into monitor.
- If an emulation module is connected to Port Out, then the state of the emulation module will be sent out the Port Out without regard to “Group Run”.

The current emulation module state (Running or In Monitor) should be monitored closely when they are part of a Group Run measurement so that valid measurements are obtained.

### **Group Run into an emulation module does not mean that the Group Run will Run the emulation module.**

The emulation module Run, Break, Step, and Reset are independent of the Group Run of the Analyzers.

For example, suppose you have the following IMB measurement set up:



Clicking the **Group Run** button (at the very top of the Intermodule window or a logic analyzer window) will start the analyzer running. The analyzer will then wait for an arm signal. Now when the emulation module transitions into “Monitor” from “Running” (or from “Reset”), it will send the arm signal to the analyzer. If the emulation module is “In Monitor” when you click **Group Run**, you will then have to go to the emulation module or your debugger interface and manually start it running.

### **Debuggers can cause triggers**

Emulation module user interfaces may introduce additional states into your analysis measurement and in some cases falsely trigger your analysis measurement.

When a debugger causes your target to break into monitor it will typically read memory around the program stack and around the current program counter. This will generate additional states which appear in the listing.

You can often distinguish these additional states because the time tags will be in the ms and ms range. You can use the time tag information to determine when the processor went into monitor. Typically the time between states will be in the nanoseconds while the processor is running and will be in the ms and ms range when the debugger has halted the processor and is reading memory.

Not also that some debugger commands may cause the processor to break temporarily to read registers and memory. These states that the debugger introduces will also show up in you trace listing.

If you define a trigger on some state and the debugger happens to read the same state, then you may falsely trigger your analyzer measurement. In summary, when you are making an analysis measurement be aware that the debugger could be impacting your measurement.

---

## To trigger the analyzer when the processor halts

Remember: if you are only using a state analyzer to capture the processor bus then it will be much simpler to use “Tracing until processor halts” as described on page 218.

- 1** Set the logic analyzer to trigger on **anystate**.
- 2** Set the trigger point to **center** or **end**.
- 3** In the Intermodule window, click on the logic analyzer you want to trigger and select the emulation module.

The logic analyzer is now set to trigger on a processor halt.

- 4** Click **Group Run** to start the analyzer(s).
- 5** Click Run in the Emulation Control Interface or use your debugger to start the target processor running.

Clicking **Group Run** will *not* start the emulation module. The emulation module run, break, step, and reset are independent of the Group Run of the analyzers.

- 6** Wait for the Run Control window in the Emulation Control Interface or the status display in your debugger to show that the processor has stopped.

The logic analyzer will store states up until the processor stops, but may continue running.

You may or may not see a “slow clock” error message. In fact, if you are

using a state analyzer on the processor bus the status may never change upon receiving the emulation module trigger (analysis arm). This occurs because the qualified processor clock needed to switch the state analyzer to the next state is stopped. For example, the state analyzer before the arm event may have a status of “Occurrences Remaining in Level 1: 1” and after the arm event it may have the same status of “Occurrences Remaining in Level 1: 1”.

- 7 If necessary, in the logic analyzer window, click **Stop** to complete the measurement.

If you are using a timing analyzer or oscilloscope the measurement should complete automatically when the processor halts. If you are using a state logic analyzer, click **Stop** if needed to complete the measurement.

---

## To trigger the analyzer when the processor reaches a breakpoint

This measurement is exactly like the previous one, but with the one additional complexity of setting breakpoints. Be aware that setting breakpoints may cause a false trigger and that the breakpoints set may not be valid after a reset.

Remember: if you are only using a state analyzer to capture the processor bus then it will be much simpler to use “Tracing until processor halts” as described on page 218.

- 1 Set the logic analyzer to trigger on **anystate**.
- 2 Set the trigger point to **center** or **end**.
- 3 In the Intermodule window, click on the logic analyzer you want to trigger and select the emulation module.

The logic analyzer is now set to trigger on a processor halt.

- 4 Set the breakpoint.

If you are going to run the emulation module from Reset you must do a **Reset** followed by **Break** to properly set the breakpoints. The Reset will clear all on-chip hardware breakpoint registers. The Break command will then reinitialize the breakpoint registers. If you are using software breakpoints which insert an illegal instruction into your program at the breakpoint location you will not need to do the Reset, Break sequence. Instead you must take care to properly insert your software breakpoint in your RAM program location.

- 5 Click **Group Run** to start the analyzer(s).
- 6 Click **Run** in the Emulation Control Interface or use your debugger to start the target processor running.

Clicking **Group Run** will *not* start the emulation module. The emulation module run, break, step, reset are independent of the Group Run of the analyzers.

- 7 Wait for the Run Control window in the Emulation Control Interface or the status display in your debugger to show that the processor has stopped.

The logic analyzer will store states up until the processor stops, but may continue running.

You may or may not see a “slow clock” error message. In fact, if you are using a state analyzer on the processor bus the status may never change upon receiving the emulation module trigger (analysis arm). This occurs because the qualified processor clock needed to switch the state analyzer to the next state is stopped. For example, the state analyzer before the arm event may have a status of “Occurrences Remaining in Level 1: 1” and after the arm event it may have the same status of “Occurrences Remaining in Level 1: 1”

- 8 If necessary, in the logic analyzer window, click **Stop** to complete the measurement.

If you are using a timing analyzer or oscilloscope the measurement should complete automatically when the processor halts. If you are using a state logic analyzer, click **Stop** if needed to complete the measurement.



---

Hardware Reference

## Hardware Reference

This chapter contains additional reference information including the specifications and characteristics for the analysis probe and the emulation probe, as well as signal mapping for the Agilent Technologies E2480A analysis probe. It consists of the following information:

- Analysis probe reference
- Emulation module reference

---

## Analysis probe—operating characteristics

The following operating characteristics are not specifications, but are typical operating characteristics for the Agilent Technologies E2480A CPU32 analysis probe.

### Operating Characteristics

<b>Microcontroller Supported</b>	Motorola 68331, 68332, 68334, 68335, 68336, or 68376
<b>Package Supported</b>	132-pin PQFP, 144-pin TQFP, 160-pin PQFP
<b>Probes Required</b>	Mandatory 4 for state. Up to 8 for timing.
<b>Logic Analyzers Supported</b>	Agilent Technologies 16600A, 16601A, 16602A, 16603A, 16550A (one or two cards), 16554A/55A/56A (one or two cards), 16555D/56D/57D (one or two cards), 1660A/AS/C/CS/CP, 1661A/AS/C/CS/CP, 1662A/AS/C/CS/CP, 1670A/D, 1671A/D, 1672A/D
<b>Accessories Required</b>	See chapter 1 for available accessories. A probe adapter and a transition board are required. For address reconstruction, the emulation module is required.
<b>Optional Accessories</b>	An emulation module can be connected to the analysis probe.

### Electrical Characteristics

<b>Power Requirements</b>	650 mA typical @ 5V, supplied by the logic analyzer. CAT I Pollution degree 2.
<b>Signal Line Loading</b>	10 pF maximum on all signals.

### Environmental Characteristics (Operating)

<b>Temperature</b>	0 to + 50 degrees C
<b>Altitude</b>	4,600 m
<b>Humidity</b>	Up to 75% noncondensing. Avoid sudden, extreme temperature changes which could cause condensation on the circuit board. For indoor use only.

## Theory of operation and clocking

### **Timing**

For timing measurements, raw digital signals from the microcontroller are presented to the logic analyzer through the timing connectors. The acquisition clock is provided by the logic analyzer.

### **State**

For state measurements, all signals are processed by active logic for time alignment before they are routed to the state connectors. This allows the logic analyzer to capture all information about a given cycle in one acquisition state.

Some of the signals which assist the analysis probe in triggering and aligning the source code are reconstructed from their reconfigured functions as chip selects or general I/O. The analysis probe must be configured to match the target system for this reconstruction function to work (page 89).

A qualified target system clock is used by the logic analyzer to acquire state cycles.

---

## Address reconstruction overview

When CPU32 microcontrollers are reconfigured, they can present special problems for debugging. This is especially true when address bits A[19:23] are reconfigured as chip selects. The Agilent Technologies E2480A analysis probe overcomes these problems by using information in the base address register associated with such chip selects to replace the missing address bits. The value injected into the signal path depends on which chip select is active.

This reconstruction provides many benefits when analyzing a target system:

- Triggering on address A0 through A23 is possible, even when the upper address bits are not available from the target microcontroller.
- The software analyzer, with its increased analysis capabilities, can be used.
- Code captured in a trace can be correlated with mnemonics in the source database.
- Alignment of activity shown in a trace list.

The Agilent Technologies E2480A also reconstructs function control bits FC[0:2] when they are configured as chip selects, and SIZ[0:1] and DSack[0:1] when they are configured as general I/O.

The programming is non-volatile. Once programmed, the Agilent Technologies E2480A does not need to remain connected to the emulation module to maintain address reconstruction.


The figure on the following page shows the process by which the Agilent Technologies E2480A reconstructs addresses.

State and Timing modes use different connectors on the analysis probe. The Timing pins are direct connections to the microcontroller signals. The State pins have active circuitry on the analysis probe. State information is acquired three target system clock cycles after the same information is captured in Timing mode.

**See Also**

“Configuring the analysis probe for address reconstruction” on page 89.

Chapter 10: Hardware Reference  
**Analysis probe—operating characteristics**



E2480B05

**Address Reconstruction Overview**

## Analysis probe signal-to-connector mapping (Timing)

The following table shows the flow of signals from the microcontroller through the E2480A timing connectors to the logic analyzer. In addition to being grouped along microcontroller-like functions, the signals are also grouped and ordered along their microcontroller port definitions.

<b>CPU32 SIGNAL NAME</b>	<b>E2480A TIMING CONNECTOR PIN</b>	<b>ANALYZER BIT</b>	<b>TIMING LABEL</b>	<b>TIMING SUBLABEL</b>
<b>Timing Connector J5, Timing Pod 1</b>				
DATA0	38	0	DATA	PORT H
DATA1	36	1	DATA	PORT H
DATA2	34	2	DATA	PORT H
DATA3	32	3	DATA	PORT H
DATA4	30	4	DATA	PORT H
DATA5	28	5	DATA	PORT H
DATA6	26	6	DATA	PORT H
DATA7	24	7	DATA	PORT H
DATA8	22	8	DATA	PORT G
DATA9	20	9	DATA	PORT G
DATA10	18	10	DATA	PORT G
DATA11	16	1	DATA	PORT G
DATA12	14	12	DATA	PORT G
DATA13	12	13	DATA	PORT G
DATA14	10	14	DATA	PORT G
DATA15	8	15	DATA	PORT G
ClkOut	6	CLK		

**Analysis probe signal-to-connector mapping (Timing)**

<b>CPU32 SIGNAL NAME</b>	<b>E2480A TIMING CONNECTOR PIN</b>	<b>ANALYZER BIT</b>	<b>TIMING LABEL</b>	<b>TIMING SUBLABEL</b>
<b>Timing Connector J5, Timing Pod 2</b>				
~BR/CS0	37	0	STAT	CSx
~BG/CS1	35	1	STAT	CSx
~BGAck/CS2	33	2	STAT	CSx
DSAck0	31	3	STAT	PORT E
DSAck1	29	4	STAT	PORT E
~AVec	27	5	STAT	PORT E
~RMC	25	6	STAT	PORT E
~DS	23	7	STAT	PORT E
~AS	21	8	STAT	PORT E
SIZ0	19	9	STAT	PORT E
SIZ1	17	10	STAT	PORT E
R/~W	15	11	STAT	
~BERR	13	12	STAT	
~HALT	11	13	STAT	
~Targ_Reset	9	14	STAT	
~Freeze/Quote	7	15		
~CSBoot	5	CLK		



<b>CPU32 SIGNAL NAME</b>	<b>E2480A TIMING CONNECTOR PIN</b>	<b>ANALYZER BIT</b>	<b>TIMING LABEL</b>	<b>TIMING SUBLABEL</b>
<b>Timing Connector J4, Timing Pod 3</b>				
ADDR0	38	0	ADDR	
ADDR1	36	1	ADDR	
ADDR2	34	2	ADDR	
ADDR3	32	3	ADDR	PORT B
ADDR4	30	4	ADDR	PORT B
ADDR5	28	5	ADDR	PORT B
ADDR6	26	6	ADDR	PORT B
ADDR7	24	7	ADDR	PORT B
ADDR8	22	8	ADDR	PORT B
ADDR9	20	9	ADDR	PORT B
ADDR10	18	10	ADDR	PORT B
ADDR11	16	11	ADDR	PORT A
ADDR12	14	12	ADDR	PORT A
ADDR13	12	13	ADDR	PORT A
ADDR14	10	14	ADDR	PORT A
ADDR15	8	15	ADDR	PORT A

**Analysis probe signal-to-connector mapping (Timing)**

<b>CPU32 SIGNAL NAME</b>	<b>E2480A TIMING CONNECTOR PIN</b>	<b>ANALYZER BIT</b>	<b>TIMING LABEL</b>	<b>TIMING SUBLABEL</b>
<b>Timing Connector J4, Timing Pod 4</b>				
ADDR16	37	0	ADDR	PORT A
ADDR17	35	1	ADDR	PORT A
ADDR18	33	2	ADDR	PORT A
FC0/CS3	31	3		PORT C, CSx
FC1/CS4	29	4		PORT C, CSx
FC2/CS5	27	5		PORT C, CSx
ADDR19/~CS6	25	6	ADDR	PORT C, CSx
ADDR20/~CS7	23	7	ADDR	PORT C, CSx
ADDR21/~CS8	21	8	ADDR	PORT C, CSx
ADDR22/~CS9	19	9	ADDR	PORT C, CSx
ADDR23/~CS10	17	10	ADDR	PORT C, CSx
na	15	11		
na	13	12		
na	11	13		
~IFetch/DS1	9	14		
~IPipe/DS0	7	15		
~Bkpt/DScIk	5	CLK		

NOTE: Signals A19—A23 and CS6—CS10 are multiplexed onto the same pins, and the default configuration of the logic analyzer assumes that signals A19—A23 are valid. If any of the chip selects, CS6—CS10, are being used then the bits associated with A19—A23 should be removed from the ADDR label via the format menu in the logic analyzer. This corresponds to bits 3—7 of pod A4. This results in the display of correct address information in the ADDR field of the listing menu and presents only valid address bus bits to the ADDR field in the trigger menu.

<b>CPU32 SIGNAL NAME</b>	<b>E2480A TIMING CONNECTOR PIN</b>	<b>ANALYZER BIT</b>	<b>TIMING LABEL</b>
------------------------------	--	-------------------------	-------------------------

**Timing Connector J2, Timing Pod 5**

**336, 376**

MISO	38	0	PORT Q
MOSI	36	1	PORT Q
SCK	34	2	PORT Q
PCS0/SS	32	3	PORT Q
PCS1	30	4	PORT Q
PCS2	28	5	PORT Q
PCS3	26	6	PORT Q
TxD	24	7	PORT Q
RxD	22	8	
CTM2C	20	9	
CTD3	18	10	
CTD4	16	1	
CPWM5	14	12	
CPWM6	12	13	
CPWM7	10	14	
CPWM8	8	15	
SCK	6	CLK	

**Analysis probe signal-to-connector mapping (Timing)**

<b>CPU32 SIGNAL NAME</b>	<b>E2480A TIMING CONNECTOR PIN</b>	<b>ANALYZER BIT</b>	<b>TIMING LABEL</b>
<b>Timing Connector J2, Timing Pod 6</b>			
<b>376, 336, 335, 334, 332</b>	<b>331</b>		
TP0	nc	37	0
TP1	IC1	35	1
TP2	IC2	33	2
TP3	IC3	31	3
TP4	OC1	29	4
TP5	OC1/OC2	27	5
TP6	OC1/OC3	25	6
TP7	nc	23	7
TP8	OC1/OC4	21	8
TP9	OC1/OC5/IC4	19	9
TP10	PAI	17	10
TP11	nc	15	11
TP12	nc	13	12
TP13	nc	11	13
TP14	PWMA	9	14
TP15	PWMB	7	15
T2clk	PClk	5	CLK

<b>CPU32 SIGNAL NAME</b>	<b>E2480A TIMING CONNECTOR PIN</b>	<b>ANALYZER BIT</b>	<b>TIMING LABEL</b>
--------------------------	--	-------------------------	-------------------------

**Timing Connector J3, Timing Pod 7**

<b>336, 376</b>	<b>335, 334, 332, 331</b>		
ModClk	ModClk	38	0
IRQ1	IRQ1	36	1
IRQ2	IRQ2	34	2
IRQ3	IRQ3	32	3
IRQ4	IRQ4	30	4
IRQ5	IRQ5	28	5
IRQ6	IRQ6	26	6
IRQ7	IRQ7	24	7
CDT10	nc	22	8
CTD9/CTM2L	nc	20	9
nc	nc	18	10
nc	nc	16	11
nc	nc	14	12
nc	nc	12	13
nc	nc	10	14
nc	nc	8	15

**Analysis probe signal-to-connector mapping (Timing)**

CPU32 SIGNAL NAME			E2480A TIMING CONNECTOR PIN	ANALYZER BIT	TIMING LABEL
<b>Timing Connector J3, Timing Pod 8</b>					
<b>336, 376</b>	<b>334</b>	<b>335, 332, 331</b>			
A2D_A0	nc	nc	37	0	
A2D_A1	nc	nc	35	1	
A2D_A2	nc	nc	33	2	
A2D_A3	nc	nc	31	3	
A2D_A4	nc	nc	29	4	
A2D_A5	nc	nc	27	5	
A2D_A6	nc	nc	25	6	
A2D_A7	VDDA	MISO	23	7	PORT Q*
A2D_B0	VSSA	MOSI	21	8	PORT Q*
A2D_B1	A2D_A0	SCK	19	9	PORT Q*
A2D_B2	A2D_A1	PCS0/SS	17	10	PORT Q*
A2D_B3	A2D_A2	PCS1	15	11	PORT Q*
A2D_B4	A2D_A3	PCS2	13	12	PORT Q*
A2D_B5	A2D_A4	PCS3	11	13	PORT Q*
A2D_B6	A2D_A5	TxD	9	14	PORT Q*
A2D_B7	A2D_A6	RxD	7	15	
nc	nc	nc	5	CLK	

\*The PORT Q labels are valid only for the 331, 332, and 335 microprocessors.

## State connector signal definition

The following table defines the state connectors, the logic analyzer bit assignments, and the label/sublabel(s) to which a signal belongs. This table aids in reconfiguring the logic analyzer to match a particular microcontroller configuration.

### E2480A State Connector Signal List

<b>CPU32 SIGNAL NAME</b>	<b>E2480A STATE CONNECTOR PIN</b>	<b>ANALYZER BIT</b>	<b>STATE LABEL</b>	<b>STATE SUBLABEL</b>
<b>State Connector J1, State Pod 1</b>				
DATA0	38	0	DATA	
DATA1	36	1	DATA	
DATA2	34	2	DATA	
DATA3	32	3	DATA	
DATA4	30	4	DATA	
DATA5	28	5	DATA	
DATA6	26	6	DATA	
DATA7	24	7	DATA	
DATA8	22	8	DATA	
DATA9	20	9	DATA	
DATA10	18	10	DATA	
DATA11	16	1	DATA	
DATA12	14	12	DATA	
DATA13	12	13	DATA	
DATA14	10	14	DATA	
DATA15	8	15	DATA	
ClkOut	6	CLK		

Chapter 10: Hardware Reference  
**State connector signal definition**

<b>CPU32 SIGNAL NAME</b>	<b>E2480A STATE CONNECTOR PIN</b>	<b>ANALYZER BIT</b>	<b>STATE LABEL</b>	<b>STATE SUBLABEL</b>
<b>State Connector J1, State Pod 2</b>				
~SHOW_CYCLE	37	0	STAT	~ShoCy
R/~W	35	1	STAT	R/~W
~INST_FETCH	33	2	STAT	~IFtch
~PIPE_FLUSH	31	3	STAT	~PFfsh
SIZ0	29	4	STAT	SIZx
SIZ1	27	5	STAT	SIZx
DSAck0	25	6	STAT	DSACKx
DSAck1	23	7	STAT	DSACKx
~BERR	21	8	STAT	~BErr
~Freeze	19	9	STAT	~Freez
~Bkpt	17	10	STAT	~Bkpt
~BGAck	15	11	STAT	~BGAck
FC0	13	12	STAT	FCx
FC1	11	13	STAT	FCx
FC2	9	14	STAT	FCx
na	7	15		
~Analyzer_clk_en	5	CLK		



<b>CPU32 SIGNAL NAME</b>	<b>E2480A STATE CONNECTOR PIN</b>	<b>ANALYZER BIT</b>	<b>STATE LABEL</b>	<b>STATE SUBLABEL</b>
<b>State Connector J6, State Pod 3</b>				
ADDR0	38	0	ADDR	
ADDR1	36	1	ADDR	
ADDR2	34	2	ADDR	
ADDR3	32	3	ADDR	
ADDR4	30	4	ADDR	
ADDR5	28	5	ADDR	
ADDR6	26	6	ADDR	
ADDR7	24	7	ADDR	
ADDR8	22	8	ADDR	
ADDR9	20	9	ADDR	
ADDR10	18	10	ADDR	
ADDR11	16	11	ADDR	
ADDR12	14	12	ADDR	
ADDR13	12	13	ADDR	
ADDR14	10	14	ADDR	
ADDR15	8	15	ADDR	
~Freeze	6	CLK		

**State connector signal definition**

<b>CPU32 SIGNAL NAME</b>	<b>E2480A STATE CONNECTOR PIN</b>	<b>ANALYZER BIT</b>	<b>STATE LABEL</b>	<b>STATE SUBLABEL</b>
<b>State Connector J6, State Pod 4</b>				
ADDR16	37	0	ADDR	
ADDR17	35	1	ADDR	
ADDR18	33	2	ADDR	
ADDR19	31	3	ADDR	
ADDR20	29	4	ADDR	
ADDR21	27	5	ADDR	
ADDR22	25	6	ADDR	
ADDR23	23	7	ADDR	
~BGAck	5	CLK		

## Emulation module—operating characteristics

The following operating characteristics are not specifications, but are typical operating characteristics for the Agilent Technologies 16610A emulation module and CPU32 target interface module.

### Operating Characteristics

**Microprocessor  
Compatibility**

Motorola 68330, 68331, 68332, 68F333, 68334, 68335, 68336, 68338, 68340, 68341, 68349, 68360, or 68376 microprocessors operating at clock speeds up to 25 MHz.

The emulator supports both 5V and 3.3V operation.

**Environmental  
Characteristics  
(Temperature, Altitude,  
Humidity)**

The Agilent Technologies 16610A emulation module meets the environmental characteristics of the logic analysis system in which it is installed. For indoor use only.

## Emulation module—electrical characteristics

Characteristic	Symbol	Value	Unit
Supply Voltage from Target	$V_{DD}$	-0.3 to +5.5	V

Characteristic	Symbol	$V_{DD} = 5 \text{ Volts}$		$V_{DD} = 3.3 \text{ Volts}$		Unit
		Min	Max	Min	Max	
Input Current ( $V_{DD}$ )	$I_{il}$		10		6	mA
Input Voltage	$V_{in}$	$V_{SS}-0.5$	$V_{DD}+0.5$	$V_{SS}-0.5$	$V_{DD}+0.5$	V
Input High Voltage	$V_{ih}$	2	$V_{DD}+0.5$	2	$V_{DD}+0.5$	V
Input Low Voltage	$V_{il}$	$V_{SS}-0.5$	0.8	$V_{SS}-0.5$	0.8	V
Input High Current	$I_{ih}$		-20		-15	$\mu\text{A}$
Input Low Current	$I_{il}$		0.6		0.35	mA
Input Capacitance	$C_{in}$		40		40	pF
Output High Voltage ( $\overline{\text{BKPT}}$ , $\overline{\text{IFETCH}}$ /DSI)*	$V_{oh}$	3.86		3		V
Output High Current ( $\overline{\text{BKPT}}$ , $\overline{\text{IFETCH}}$ /DSI)	$I_{oh}$	-4		-2		mA
Output Low Voltage ( $\overline{\text{BKPT}}$ , $\overline{\text{IFETCH}}$ /DSI)	$V_{ol}$	0.4		0.4		V
Output Low Current ( $\overline{\text{BKPT}}$ , $\overline{\text{IFETCH}}$ /DSI)	$I_{ol}$	3.4		3.4		mA
Output Low Voltage ( $\overline{\text{BERR}}$ , $\overline{\text{RESET}}$ ), $I_{ol} = 12 \text{ mA}^*$	$V_{ol}$	0.4		0.4		V
Output Low Voltage ( $\overline{\text{BERR}}$ , $\overline{\text{RESET}}$ ), $I_{ol} = 24 \text{ mA}^*$	$V_{ol}$	0.5		0.5		V

\*The  $V_{oh}$  specification for  $\overline{\text{BERR}}$  and  $\overline{\text{RESET}}$  is not applicable because they are OPEN-collector outputs.

Input-only pins:  $V_{DD}$ ,  $\overline{\text{DS}}$ , FREEZE,  $\overline{\text{I\_PIPE}}$ /DSO

Output-only pins:  $\overline{\text{BKPT}}$

Input/output pins:  $\overline{\text{IFETCH}}$ /DSI,  $\overline{\text{BERR}}$ ,  $\overline{\text{RESET}}$

---

General-Purpose ASCII (GPA) Symbol  
File Format

## General-Purpose ASCII (GPA) Symbol File Format

General-purpose ASCII (GPA) format files are loaded into a logic analyzer just like other object files, but they are usually created differently.

If your compiler is not one of those listed on page 120, if your compiler does not include symbol information in the output, or if you want to define a symbol not in the object file, you can create an ASCII format symbol file.

Typically, ASCII format symbol files are created using text processing tools to convert compiler or linker map file output that has symbolic information into the proper format.

You can typically get symbol table information from a linker map file to create a General-Purpose ASCII (GPA) symbol file.

Various kinds of symbols are defined in different records in the GPA file. Record headers are enclosed in square brackets; for example, [VARIABLES]. For a summary of GPA file records and associated symbol definition syntax, refer to the “GPA Record Format Summary” that follows.

Each entry in the symbol file must consist of a symbol name followed by an address or address range.

While symbol names can be very long, the logic analyzer only uses the first 16 characters.

The address or address range corresponding to a given symbol appears as a hexadecimal number. The address or address range must immediately follow the symbol name, appear on the same line, and be separated from the symbol name by one or more blank spaces or tabs. Ensure that address ranges are in the following format:

```
beginning address..ending address
```

**Example**

```
main      00001000..00001009
test      00001010..0000101F
var1      00001E22           #this is a variable
```

This example defines two symbols that correspond to address ranges and one point symbol that corresponds to a single address.

For more detailed descriptions of GPA file records and associated symbol definition syntax, refer to these topics that follow:

- SECTIONS
- FUNCTIONS
- VARIABLES
- SOURCE LINES
- START ADDRESS
- Comments

## GPA Record Format Summary

```
[SECTIONS]
section_name start..end attribute
```

```
[FUNCTIONS]
func_name start..end
```

```
[VARIABLES]
var_name start [size]
var_name start..end
```

```
[SOURCE LINES]
File: file_name
line# address
```

```
[START ADDRESS]
address
```

#Comments

If no record header is specified, [VARIABLES] is assumed. Lines without a preceding header are assumed to be symbol definitions in one of the VARIABLES formats.

### **Example**

This is an example GPA file that contains several different kinds of records:

```
[SECTIONS]
prog      00001000..0000101F
data      40002000..40009FFF
common    FFFF0000..FFFF1000

[FUNCTIONS]
main      00001000..00001009
test      00001010..0000101F

[VARIABLES]
total     40002000  4
value     40008000  4
```



```
[SOURCE LINES]
File: main.c
10      00001000
11      00001002
14      0000100A
22      0000101E

File: test.c
 5      00001010
 7      00001012
11      0000101A
```

## SECTIONS

```
[SECTIONS]
section_name start..end attribute
```

Use SECTIONS to define symbols for regions of memory, such as sections, segments, or classes.

`section_name` A symbol representing the name of the section.

`start` The first address of the section, in hexadecimal.

`end` The last address of the section, in hexadecimal.

`attribute` This is optional, and may be one of the following:

- **NORMAL** (default)—The section is a normal, relocatable section, such as code or data.
- **NONRELOC**—The section contains variables or code that cannot be relocated; this is an absolute segment.

### **Define sections first**

To enable section relocation, section definitions must appear before any other definitions in the file.

### **Example**

```
[SECTIONS]
prog          00001000..00001FFF
data         00002000..00003FFF
display_io   00008000..0000801F  NONRELOC
```

If you use section definitions in a GPA symbol file, any subsequent function or variable definitions must be within the address ranges of one of the defined sections. Functions and variables that are not within the range are ignored.

## FUNCTIONS

```
[FUNCTIONS]
func_name start..end
```

Use FUNCTIONS to define symbols for program functions, procedures, or subroutines.

`func_name` A symbol representing the function name.

`start` The first address of the function, in hexadecimal.

`end` The last address of the function, in hexadecimal.

### **Example**

```
[FUNCTIONS]
main      00001000..00001009
test      00001010..0000101F
```

## VARIABLES

```
[VARIABLES]
var_name  start [size]
var_name  start..end
```

You can specify symbols for variables either by using the address of the variable, the address and the size of the variable, or a range of addresses occupied by the variable. If you specify only the address of a variable, the size is assumed to be one byte.

`var_name` A symbol representing the variable name.

`start` The first address of the variable, in hexadecimal.

`end` The last address of the variable, in hexadecimal.

`size` This is optional, and indicates the size of the variable, in bytes, in decimal.

### **Example**

```
[VARIABLES]
subtotal  40002000  4
total     40002004  4
data_array 40003000..4000302F
status_char 40002345
```

## SOURCE LINES

```
[SOURCE LINES]
File: file_name
line# address
```

Use SOURCE LINES to associate addresses with lines in your source files.

`file_name` The name of a file.

`line#` The number of a line in the file, in decimal.

`address` The address of the source line, in hexadecimal.

### **Example**

```
[SOURCE LINES]
File: main.c
10      00001000
11      00001002
14      0000100A
22      0000101E
```

## START ADDRESS

```
[START ADDRESS]  
address
```

address The address of the program entry point, in hexadecimal.

### **Example**

```
[START ADDRESS]  
00001000
```

---

## Comments

```
#comment text
```

Use the # character to include comments in a file. Any text following the # character is ignored. You can put comments on a line alone or on the same line following a symbol entry.

### **Example**

```
#This is a comment.
```

---

Troubleshooting the Analysis Probe

## Troubleshooting the Analysis Probe

If you encounter difficulties while making measurements, use this chapter to guide you through some possible solutions. Each heading lists a problem you may encounter, along with some possible solutions.

If you still have difficulty using the analyzer after trying the suggestions in this chapter, please contact your local Agilent Technologies service center.

---

**CAUTION:**

When you are working with the analyzer, be sure to power down both the analyzer and the target system before disconnecting or connecting cables, probes, and analysis probes. Otherwise, you may damage circuitry in the analyzer, analysis probe, or target system.

---



## Logic Analyzer Problems

This section lists general problems that you might encounter while using the logic analyzer.

---

### Intermittent data errors

This problem is usually caused by poor connections, incorrect signal levels, or marginal timing.

- ❑ Remove and reseal all cables and probes, ensuring that there are no bent pins on the analysis probe or poor probe connections.
- ❑ Adjust the threshold level of the data pod to match the logic levels in the system under test.
- ❑ Use an oscilloscope to check the signal integrity of the data lines.

Clock signals for the state analyzer must meet particular pulse shape and timing requirements. Data inputs for the analyzer must meet pulse shape and setup and hold time requirements.

#### **See Also**

See *Capacitive Loading* in this chapter for information on other sources of intermittent data errors.

## Unwanted triggers

Unwanted triggers can be caused by instructions that were fetched but not executed.

- ❑ Add the prefetch queue or pipeline depth to the trigger address to avoid this problem.

The logic analyzer captures prefetches, even if they are not executed. When you are specifying a trigger condition or a storage qualification that follows an instruction that may cause branching, an unused prefetch may generate an unwanted trigger.

---

## No activity on activity indicators

- ❑ Check for loose cables, board connections, and analysis probe connections.
- ❑ Check for bent or damaged pins on the analysis probe.

---

## No trace list display

If there is no trace list display, it may be that your trigger specification is not correct for the data you want to capture, or that the trace memory is only partially filled.

- ❑ Check your trigger sequencer specification to ensure that it will capture the events of interest.
- ❑ Try stopping the analyzer; if the trace list is partially filled, this should display the contents of trace memory.

## Analyzer won't power up

If logic analyzer power is cycled when the logic analyzer is connected to a target system or emulation probe that remains powered up, the logic analyzer may not be able to power up. Some logic analyzers are inhibited from powering up when they are connected to a target system or emulation probe that is already powered up.

- ❑ Remove power from the target system, then disconnect all logic analyzer cabling from the analysis probe. This will allow the logic analyzer to power up. Reconnect logic analyzer cabling after power up.

## Analysis Probe Problems

This section lists problems that you might encounter when using an analysis probe. If the solutions suggested here do not correct the problem, you may have a damaged analysis probe. Contact your local Agilent Technologies Sales Office if you need further assistance.

---

### Target system will not boot up

If the target system will not boot up after connecting the analysis probe, the microcontroller (if socketed) or the analysis probe may not be installed properly, or they may not be making electrical contact.

- Ensure that you are following the correct power-on sequence for the analysis probe and target system.

**1** Power up the analyzer and analysis probe.

**2** Power up the target system.

If you power up the target system before you power up the analysis probe, interface circuitry in the analysis probe may latch up and prevent proper target system operation.

- Verify that the microcontroller and the analysis probe are properly rotated and aligned, so that the index pin on the microcontroller (pin A1) matches the index pin on the analysis probe.
- Verify that the microcontroller and the analysis probe are securely inserted into their respective sockets.
- Verify that the logic analyzer cables are in the proper sockets of the analysis probe and are firmly inserted.

## Erratic trace measurements

- ❑ Do a full reset of the target system before beginning the measurement.

Some analysis probe designs require a full reset to ensure correct configuration.

- ❑ Ensure that your target system meets the timing requirements of the processor with the analysis probe installed.

See *Capacitive loading* in this chapter. While analysis probe loading is slight, pin protectors, extenders, and adapters may increase it to unacceptable levels. If the target system design has close timing margins, such loading may cause incorrect processor functioning and give erratic trace results.

- ❑ Ensure that you have sufficient cooling for the microcontroller.

Ensure that you have ambient temperature conditions and airflow that meet or exceed the requirements of the microcontroller manufacturer.

---

## Capacitive loading

Excessive capacitive loading can degrade signals, resulting in incorrect capture by the analysis probe, or system lockup in the microcontroller. All analysis probe add additional capacitive loading, as can custom probe fixtures you design for your application.

Careful layout of your target system can minimize loading problems and result in better margins for your design. This is especially important for systems that are running at frequencies greater than 50 MHz.

- ❑ Remove as many pin protectors, extenders, and adapters as possible.
- ❑ If multiple analysis probe solutions are available, use one with lower capacitive loading.

## Inverse Assembler Problems

This section lists problems that you might encounter while using the inverse assembler.

When you obtain incorrect inverse assembly results, it may be unclear whether the problem is in the analysis probe or in your target system. If you follow the suggestions in this section to ensure that you are using the analysis probe and inverse assembler correctly, you can proceed with confidence in debugging your target system.

---

### No inverse assembly or incorrect inverse assembly

This problem may be due to incorrect synchronization, modified configuration, incorrect connections, or a hardware problem in the target system. A locked status line can cause incorrect or incomplete inverse assembly.

- ❑ Ensure that each logic analyzer pod is connected to the correct analysis probe connector.

There is not always a one-to-one correspondence between analyzer pod numbers and analysis probe cable numbers. Analysis Probes must supply address (ADDR), data (DATA), and status (STAT) information to the analyzer in a predefined order. The cable connections for each analysis probe are often altered to support that need. Thus, one analysis probe might require that you connect cable 2 to analyzer pod 2, while another will require you to connect cable 5 to analyzer pod 2. See Chapter 3 for connection information.

- ❑ Check the activity indicators for status lines locked in a high or low state.
- ❑ Verify that the STAT, DATA, and ADDR format labels have not been modified from their default values.

These labels must remain as they are configured by the configuration

file. Do not change the names of these labels or the bit assignments within the labels. Some analysis probes also require other data labels. See Chapter 10, “Hardware Reference,” beginning on page 225 for more information.

---

## Inverse assembler will not load or run

You need to ensure that you have the correct system software loaded on your analyzer.

- ❑ Ensure that the inverse assembler is on the same disk as the configuration files you are loading.

Configuration files for the state analyzer contain a pointer to the name of the corresponding inverse assembler. If you delete the inverse assembler or rename it, the configuration process will fail to load the disassembler.

See Chapter 4, “Analyzing the CPU32 with a Logic Analyzer,” beginning on page 97 for details.

## Intermodule Measurement Problems

Some problems occur only when you are trying to make a measurement involving multiple modules.

---

### An event wasn't captured by one of the modules

If you are trying to capture an event that occurs very shortly after the event that arms one of the measurement modules, it may be missed due to internal analyzer delays. For example, suppose you set an oscilloscope module to trigger upon receiving a trigger signal from the logic analyzer because you are trying to capture a pulse that occurs right after the analyzer's trigger state. If the pulse occurs too soon after the analyzer's trigger state, the oscilloscope will miss the pulse.

- ❑ Adjust the skew in the Intermodule menu.

You may be able to specify a skew value that enables the event to be captured.

- ❑ Change the trigger specification for modules upstream of the one with the problem.

If you are using a logic analyzer to trigger an oscilloscope module, try specifying a trigger state one state before the one you are using. This may be more difficult than working with the skew because the prior state may occur more often and not always be related to the event you are trying to capture with the oscilloscope.



---

## Analysis Probe Messages

This section lists some of the messages that the analyzer displays when it encounters a problem.

---

### “... Inverse Assembler Not Found”


This error occurs if you rename or delete the inverse assembler file that is attached to the configuration file.

Ensure that the inverse assembler file is not renamed or deleted, and that it is located in the the correct directory:


- For Agilent Technologies 16600A/700A-series logic analysis systems it should be in `/logic/ia`.
- For other logic analyzers it should be in the same directory as the configuration file.

## “Measurement Initialization Error”

This error occurs when you have installed the cables incorrectly for one or two Agilent Technologies 16550A logic analysis cards. The following diagrams show the correct cable connections for one-card and two-card installations. Ensure that your cable connections match the silk screening on the card, and that they are fully seated in the connectors. Then, repeat the measurement.



### **Cable Connections for One-Card Agilent Technologies 16550A Installations**



### **Cable Connections for Two-Card Agilent Technologies 16550A Installations**

**See Also**

*The Agilent Technologies 16550A 100-MHz State/500-MHz Timing Logic Analyzer Service Guide.*

---

## **“No Configuration File Loaded”**

This is usually caused by trying to load a configuration file for one type of module/system into a different type of module/system.

- ❑ Verify that the appropriate module has been selected from the Load {module} from File {filename} in the disk operation menu. Selecting Load {All} will cause incorrect operation when loading most analysis probe configuration files.

**See Also**

Chapter 3 describes how to load configuration files.

### “Selected File is Incompatible”

This occurs when you try to load a configuration file for the wrong module. Ensure that you are loading the appropriate configuration file for your logic analyzer.

---

### “Slow or Missing Clock”

- ❑ This error message might occur if the logic analyzer cards are not firmly seated in the logic analysis system frame. Ensure that the cards are firmly seated.
  - ❑ This error might occur if the target system is not running properly. Ensure that the target system is on and operating properly.
  - ❑ If the error message persists, check that the logic analyzer pods are connected to the proper connectors on the analysis probe. See Chapter 3 to determine the proper connections.
- 

### “Time from Arm Greater Than 41.93 ms”

The Agilent Technologies 16550A state/timing analyzers have a counter to keep track of the time from when an analyzer is armed to when it triggers. The width and clock rate of this counter allow it to count for up to 41.93 ms before it overflows. Once the counter has overflowed, the system does not have the data it needs to calculate the time between module triggers. The system must know this time to be able to display data from multiple modules on a single screen.

## “Waiting for Trigger”

If a trigger pattern is specified, this message indicates that the specified trigger pattern has not occurred. Verify that the triggering pattern is correctly set.

- ❑ When analyzing microcontrollers that fetch only from word-aligned addresses, ensure that the trigger condition is set to look for an opcode fetch at an address corresponding to a word boundary.

## Returning Parts to Agilent Technologies for Service

The repair strategy for this emulation solution is board replacement.

Exchange assemblies are available when a repairable assembly is returned to Agilent Technologies. These assemblies have been set up on the “Exchange Assembly” program. This lets you exchange a faulty assembly with one that has been repaired, calibrated, and performance verified by the factory. The cost is significantly less than that of a new assembly.

---

### To return a part to Agilent Technologies

- 1** Follow the procedures in this chapter to make sure that the problem is caused by a hardware failure, not by configuration or cabling problems.
- 2** In the U.S., call 1-800-403-0801. Outside the U.S., call your nearest Agilent Technologies sales office. Ask them for the address of the nearest Agilent Technologies service center.
- 3** Package the part and send it to the Agilent Technologies service center.

Keep any parts which you know are working. For example, if only the target interface module is broken, keep the emulation module and cables.

- 4** When the part has been replaced, it will be sent back to you.

The unit returned to you will have the same serial number as the unit you sent to Agilent Technologies.

The Agilent Technologies service center can also troubleshoot the hardware and replace the failed part. To do this, send your entire

measurement system to the service center, including the logic analysis system, analysis probe, and cables.

In some parts of the world, on-site repair service is available. Ask the Agilent Technologies sales or service representative for details.

---

## To obtain replacement parts

The following table lists some parts that may be replaced if they are damaged or lost. Contact your nearest Agilent Technologies Sales Office for further information.

### Analysis Probe Replaceable Parts

<b>Agilent Part Number</b>	<b>Description</b>
<b>E2480A</b>	
E2480-69502	Circuit board assembly
E2480-68701	Inverse assembler disk pouch
5041-9491	Extraction Tool
E5346A	Flexible Adapter Cable
<b>132-Pin QFP</b>	
E3417A	Generic 132-Pin QFP Probe
E8119A	132-pin QFP-FC 6833X Transition Board
<b>144-pin TQFP</b>	
E5336A	144-Pin Elastomeric Probe
E5338A	144-pin TQFP 68332 Adapter
E8120A	144-pin QFP-FV 6833X Transition Board
<b>160-pin TQFP</b>	
E5350A	176-pin TQFP Generic Flex
E5373A	160-pin QFP Elastomeric Probe Adapt
E8122A	160-pin QFP-FT 68336 Transition Board

## Cleaning the Instrument

If the instrument requires cleaning:

- 1** Remove power from the instrument.
- 2** Clean the instrument with a mild detergent and water.
- 3** Make sure that the instrument is completely dry before reconnecting it to a power source.



---

Troubleshooting the Emulation  
Module

## Solving Problems

If you have problems with the emulation module, your first task is to determine the source of the problem. Problems may originate in any of the following places:

- The connection between the emulation module and your debugger
- The emulation module itself
- The connection between the emulation module and the target interface module
- The connection between the target interface module and the target system
- The target system

You can use several means to determine the source of the problem:

- The troubleshooting guide on the next page
- The status lights on the emulation module
- The emulation module "performance verification" tests
- The emulation module's built-in commands

## Troubleshooting Guide

### Common problems and what to do about them

Symptom	What to do	See also
Commands from the Emulation Control Interface have no effect	Check that you are using the correct firmware.	
Commands from debugger have no effect	Use the Emulation Control Interface to try a few built-in commands. If this works, your debugger may not be configured properly. If this does not work, continue with the steps for the next symptom....	page 277
Emulator built-in commands do not work	<ol style="list-style-type: none"> <li>1 Check that the emulator has been properly configured for your target system.</li> <li>2 Run the emulator performance verification tests.</li> <li>3 If the performance verification tests pass, then there is an electrical problem with the connection to the target processor OR the target system may not have been designed according to "Designing a Target System."</li> </ol>	<p>page 154</p> <p>page 284</p> <p>page 138</p> <p>page 282</p>
"Slow or missing clock" message after a logic analyzer run	Check that the target system is running user code or is in reset. (This message can appear if the processor is in background mode.)	
"Slow clock" message in the Emulation Control Interface or "c>" prompt in the built-in "terminal interface"	Check that the clock rate is properly configured.	page 159
Some commands fail	Check the "restrict to real-time runs" configuration	page 164

## Emulation Module Status Lights

The emulation module uses status lights to communicate various modes and error conditions.

The following table gives more information about the meaning of the power and target status lights.

- = LED is off
- = LED is on
- \* = Not applicable (LED is off or on)

### Power/Target Status Lights

Pwr/Target LEDs	Meaning
○ Reset ○ Break ○ Run	No target system power, or emulation module is not connected to the target system
● Reset ○ Break ○ Run	Target system is in a reset state
○ Reset ● Break ○ Run	The target processor is executing in Debug Mode
○ Reset ○ Break ● Run	The target processor is executing user code
○ Reset ● Break ● Run	Only boot firmware is good (other firmware has been corrupted)

---

## Emulation Module Built-in Commands

The emulation module has some built-in commands (sometimes called the “terminal interface”) which you can use for troubleshooting.

You can enter the built-in commands using:

- A telnet (LAN) connection
- The Command Line window in the Emulation Control Interface
- A “debugger command” window in your debugger

---

## To telnet to the emulation module

You can establish a telnet connection to the emulation module if:

- A host computer and the logic analysis system are both connected to a local-area network (LAN), and
- The host computer has the telnet program (often part of the operating system or an internet software package).

To establish a telnet connection:

### **1** Find out the port number of the emulation module.

The default port number of the first emulation module in an Agilent Technologies 16600A/700A series logic analysis system is 6472. The default port of a second module in an Agilent Technologies 16600A-series system is 6476. The default port numbers of a third and fourth module in an expansion frame are 6480 and 6484. These port numbers can be changed, but that is rarely necessary.

### **2** Find out the LAN address or LAN name of the logic analysis system.

### **3** Start the telnet program.

If the LAN name of the logic analysis system is “test2” and you have

**Emulation Module Built-in Commands**

only one emulation module installed, the command might look like this:

```
telnet test2 6472
```

- 4 If you do not see a prompt, press the <Return> key a few times.

To exit from this telnet session, type <CTRL>D at the prompt.

## To use the built-in commands

Here are a few commonly used built-in commands:

### Useful built-in commands

b	Break—go into the background monitor state
cf	Configuration—read or write configuration options
help	Help—display online help for built-in commands
init	Initialize—init -c re-initializes everything in the emulation module except for the LAN software; init -p is the equivalent of cycling power (it will break LAN connections)
lan	configure LAN address (emulation probes only)
m	Memory—read or write memory
pp load	Load EMSIM values into preprocessor
reg	Register—read or write a register
r	Run—start running user code
rep	Repeat—repeat a command or group of commands
rst	Reset—reset the target processor (the emulation module will wait for you to press the target's RESET button)
s	Step—do a low-level single step
sync diff	Compare EMSIM with SIM registers
sync emsim	Copy EMSIM to SIM registers
sync sim	Copy SIM to EMSIM registers
ver	Version—display the product number and firmware version of the emulation module

The prompt indicates the status of the emulation module:

**Emulation module prompts**

U	Running user program
M	Running in background monitor
p	No target power
R	Emulation reset
r	Target reset
?	Unknown state

**Examples**

To set register R0, then view R0 to verify that it was set, enter:

```
R>rst -m
M>reg r0=ffff
M>reg r0
   reg R0=0000ffff
```

To break execution then step a single instruction, enter:

```
M>b
M>s
   PC=xxxxxxxx
M>
```

To determine what firmware version is installed in the emulation module, enter:

```
M>ver
```

**See Also**

Use the help command for more information on these and other commands. Note that some of commands listed in the help screens are generic commands for Agilent Technologies emulators and may not be available for your product.

If you are writing your own debugger, contact Agilent Technologies for more information.

## Problems with the BDM Connection

---

### If a user interface behaves erratically

- ❑ Check the orientation of the cable connecting the target interface module to your target system. If the cable is offset or rotated, the emulator will try to interpret the “random” signals with unpredictable results. If the cable is rotated, the emulator or target system may also be damaged.
- ❑ Check that the processor clock speed has been properly configured. See “To configure the processor clock speed (BDM communication speed)” on page 159.



---

## Problems with Configuration

---

### If you have problems displaying some registers

- ❑ If your user interface can read or write “generic” registers, but cannot access registers that are unique to your target microcontroller, check that the target microcontroller matches the processor type you have configured in the emulator. You can use the Configuration window in the Emulation Control Interface to configure the target processor type.
- ❑ If the value of the SP and PC are displayed as ???, see “If boot area accesses fail” on page 282.

---

### If you have problems initializing some registers

Some registers can only be written once after processor reset.

If you set the EMSIM values, then reset and break, the EMSIM values will be written to the SIM registers. If your initialization code then attempts to write to one of the “write once after reset” registers, the writes will fail.

## Problems with the Target System

---

### If boot area accesses fail

When you start a debugger interface or attempt to run from reset, the emulator makes four accesses to the target system boot area to find reset values for the SP and PC. It then attempts to read the values on the stack and the code at the PC.

This problem can result in unknown values for the SP and PC (displayed as ???) and can make the debugger interface respond very slowly.

To avoid this problem, you can do several things:

- ❑ Use the 10-pin connector. The extra two pins on this connector allow the emulator to complete unterminated memory cycles.
- ❑ In your boot-up code, set the initial PC and stack pointer to memory which will be accessible at reset. Be sure to set the chip selects appropriately.

---

## Problems with the LAN Interface

---

### If LAN communication does not work

If you cannot verify the connection, or if the commands are not accepted by the emulation module:

- ❑ Make sure that you wait for the power-on self test to complete before connecting.
- ❑ Make sure that the LAN cable is connected. Watch the LAN LED's on the back of the logic analysis system to see whether the system is seeing LAN activity. Refer to your LAN documentation for testing connectivity.
- ❑ Check that the host computer or debugger was configured with the correct LAN address. If the logic analysis system is on a different subnet than the host computer, check that the gateway address is correct.
- ❑ Make sure that the logic analysis system's IP address is set up correctly.

---

### If it takes a long time to connect to the network

- ❑ Check the subnet masks on the other LAN devices connected to your network. All of the devices should be configured to use the same subnet mask.

Subnet mask error messages do not indicate a major problem. You can continue using the emulation module.

The subnet mask is set in the logic analysis system's System Admin window. If it then detects other subnet masks, it will generate error messages.

If there are many subnet masks in use on the local subnet, the logic analysis system may take a very long time to connect to the network

## Problems with the Emulation Module

Occasionally you may suspect a hardware problem with the emulation module or target interface module. The procedures in this section describe how to test the hardware, and if a problem is found, how to repair or replace the broken component.

---

### To run the built-in performance verification test using the logic analysis system

- 1** End any Emulation Control Interface or debugger sessions.
- 2** Disconnect the 50-pin cable from the emulation module, and plug the loopback test board (Agilent part number E3496-66502) into the emulation module.
- 3** In the system window, click the emulation module and select **Performance Verification**.
- 4** Click **Start PV**.


The results will appear onscreen.

## To run complete performance verification tests using a telnet connection

- 1 Disconnect the 50-pin cable from the emulation module, and plug the loopback test board (Agilent part number E3496-66502) directly into the emulation module. Do not plug anything into the other end of the loopback test board.

On a good system, the RESET LED will light and the BKG and USER LEDs will be out.

- 2 telnet to the emulation module.



- 3 Enter the `pv 1` command.

### See Also

Options available for the “pv” command are explained in the help screen displayed by typing “help pv” or “? pv” at the prompt. Note, however, that some of the options listed may not apply to your

**Problems with the Emulation Module**

emulation module.

**Examples**

If you are using a UNIX system, to telnet to a logic analysis system named “mylogic”, enter:

```
telnet mylogic 6472
```

Here are some examples of ways to use the pv command.

To execute both tests one time:

```
pv 1
```

To execute test 2 with maximum debug output repeatedly until a ^C is entered:

```
pv -t2 -v9 0
```

To execute tests 3, 4, and 5 only for 2 cycles:

```
pv -t3-5 2
```

The results on a good system with the loopback test board connected, are as follows:

```
M>pv 1

Testing: E3499C Series Emulation System
Test  1: Powerup PV Results                Passed!
Test  2: Target Probe Feedback Test       Passed!
Test  3: Boundary Scan Master Test        Passed!
Test  4: I2C Test                          Passed!
Test  5: Data Lines Test                   Passed!
Number of tests: 1      Number of failures: 0

                Copyright (c) Agilent Technologies 1987-2000

All Rights Reserved.  Reproduction, adaptation, or translation without
prior
written permission is prohibited, except as allowed under copyright laws.

E3499C Series Emulation System
Version:  A.07.53 26Feb98
Location:  Generics

E3490A Motorola CPU16/32 BDM Emulator
Version:  A.02.05 26Feb98

M>
```

## If a performance verification test fails

- ❑ Details of the failure can be obtained through using a -v option (“verbose” level) of 2 or more.
- ❑ Check that the loopback test board is connected.
- ❑ If the problem persists, contact Agilent for assistance.

## Returning Parts to Agilent Technologies for Service

The repair strategy for this emulation solution is board replacement.

Exchange assemblies are available when a repairable assembly is returned to Agilent Technologies. These assemblies have been set up on the “Exchange Assembly” program. This lets you exchange a faulty assembly with one that has been repaired, calibrated, and performance verified by the factory. The cost is significantly less than that of a new assembly.

---

### To return a part to Agilent Technologies

- 1** Follow the procedures in this chapter to make sure that the problem is caused by a hardware failure, not by configuration or cabling problems.
- 2** In the U.S., call 1-800-403-0801. Outside the U.S., call your nearest Agilent Technologies sales office. Ask them for the address of the nearest Agilent Technologies service center.
- 3** Package the part and send it to the Agilent Technologies service center.

Keep any parts which you know are working. For example, if only the target interface module is broken, keep the emulation module and cables.

- 4** When the part has been replaced, it will be sent back to you.

The unit returned to you will have the same serial number as the unit you sent to Agilent Technologies.

The Agilent Technologies service center can also troubleshoot the hardware and replace the failed part. To do this, send your entire measurement system to the service center, including the logic analysis system, target interface module, and cables.



In some parts of the world, on-site repair service is available. Ask an Agilent Technologies sales or service representative for details.

---

## To obtain replacement parts and cables

The following table lists some parts that may be replaced if they are damaged or lost. Contact your nearest Agilent Technologies Sales Office for further information.

### **Exchange assemblies**

<b>Part number</b>	<b>Description</b>
16600-69515	Emulation module

### **Replacement assemblies**

<b>Part number</b>	<b>Description</b>
E3496-61601	50-pin control cable
E3496-61603	10-pin BDM cable
E3496-66502	Loopback test board
E3458-66501	CPU32 target interface module
16700-61608	Expansion cable

---

## To clean the instrument

If the instrument requires cleaning:

- 1** Remove power from the instrument.
- 2** Clean with a mild detergent and water.

- 3** Make sure that the instrument is completely dry before reconnecting it to a power source.

**Analysis Probe** A probing solution connected to the target microcontroller. It provides an interface between the signals of the target microcontroller and the inputs of the logic analyzer. Formerly called a “preprocessor.”

**Elastomeric Probe Adapter** A connector that is fastened on top of a target microcontroller using a retainer and knurled nut. The conductive elastomer on the bottom of the probe adapter makes contact with pins of the target microcontroller and delivers their signals to connection points on top of the probe adapter.

**Emulation Module** An emulation module is installed within the mainframe of a logic analyzer. It provides run control within an emulation and analysis test setup. See Emulation Probe.

**Emulation Probe** An emulation probe is a standalone instrument connected via LAN to the mainframe of a logic analyzer or to a host computer. It provides run control within an emulation and analysis test setup. Formerly called a “processor probe” or “software probe.” See Emulation Module.

**Emulator** An emulation module or

an emulation probe.

**Extender** A part whose only function is to provide connections from one location to another. One or more extenders might be stacked to raise a probe above a target microprocessor to avoid mechanical contact with other components installed close to the target microcontroller. Sometimes called a “connector board.”

**Flexible Adapter** Two connection devices coupled with a flexible cable. Used for connecting probing hardware on the target microcontroller to the analysis probe.

**General-Purpose Flexible Adapter** A cable assembly that connects the signals from an elastomeric probe adapter to an analysis probe. Normally, a male-to-male header or transition board makes the connections from the general-purpose flexible adapter to the analysis probe.

**High-Density Adapter Cable** A cable assembly that delivers signals from an analysis probe hardware interface to the logic analyzer pod cables. A high-density adapter cable has a single Mictor connector that is installed into the analysis probe, and two cables that are connected to

---

## Glossary

corresponding odd and even logic analyzer pod cables.

### **High-Density Termination**

**Adapter Cable** Same as a High-Density Adapter Cable, except it has a termination in the Mictor connector.

**Jumper** Moveable direct electrical connection between two points.

**Mainframe Logic Analyzer** A logic analyzer that resides on one or more board assemblies installed in an Agilent Technologies 16500, 1660-series, or 16600A/700A-series mainframe.

**Male-to-male Header** A board assembly that makes point-to-point connections between the female pins of a flexible adapter or transition board and the female pins of an analysis probe.

**Preprocessor** See Analysis Probe.

**Preprocessor Interface** See Analysis Probe.

**Probe adapter** See Elastomeric Probe Adapter.

**Processor Probe** See Emulation Probe.

**Prototype Analyzer** The Agilent Technologies 16505A prototype analyzer acts as an analysis and display processor for the Agilent Technologies 16500B/C logic analysis system. It provides a windowed interface and powerful analysis capabilities. Replaced by Agilent Technologies 16600A/700A-series logic analysis systems.

**Run Control Probe** See Emulation Probe and Emulation Module.

**Setup Assistant** A software program that guides a user through the process of connecting and configuring a logic analyzer to make measurements on a specific microcontroller.

**Shunt Connector.** See Jumper.

**Software Probe** See Emulation Probe.

**Solution** Agilent Technologies' term for a set of tools for debugging your target system. A solution includes probing, inverse assembly, the Agilent Technologies B4620B Source Correlation Tool Set, and an emulation module.

**Stand-alone Logic Analyzer** A standalone logic analyzer has a predefined set of hardware

---

## Glossary

components which provide a specific set of capabilities. It is designed to perform logic analysis. A standalone logic analyzer differs from a mainframe logic analyzer in that it does not offer card slots for installation of additional capabilities, and its specifications are not modified based upon selection from a set of optional hardware boards that might be installed within its frame.

**Target Control Port** An 8-bit, TTL port on a logic analysis system that you can use to send signals to your target system. It does not function like a pattern generator or emulation module, but more like a remote control for the target's switches.

**Target Interface Module** A small circuit board which connects the 50-pin cable from an emulation module or emulation probe to signals from the debug port on a target system.

**TIM** See Target Interface Module.

**Trigger Specification** A set of conditions that must be true before the instrument triggers. See the printed or online documentation for your logic analyzer for details.

**Transition Board** A board assembly that obtains signals connected to one side and rearranges them in a

different order for delivery at the other side of the board.

**1/4-Flexible Adapter** An adapter that obtains one-quarter of the signals from an elastomeric probe adapter (one side of a target microcontroller) and makes them available for probing.



- 
- (prefetched instruction symbol), 111
  - A**
  - ADDR label, modifying, 100
  - addresses
    - mask, 112
    - offset, 130
    - PC label, 127
    - reconstruction, 89, 228
    - type, 103
  - analysis probe
    - additional equipment supported, 22
    - clocking, 228
    - connecting to, 151
    - connection overview, 41
    - definition, 291
    - dimensions, 38
    - equipment required, 22
    - equipment supplied, 20
    - inverse assembly, 107
    - microprocessors supported, 227
    - modes of operation, 99
    - operating characteristics, 227
    - overview, 2
    - power on/power off sequence, 39
    - processors supported, 4
    - product numbers, 4
    - storage qualification, 106
    - target system requirements, 37
    - theory of operation, 228
  - analysis probe problems, 260
    - erratic trace measurements, 261
    - target system will not boot, 260
  - analyzer problems, 257
    - capacitive loading, 261
    - intermittent data errors, 257
    - unwanted triggers, 258
  - analyzing the processor, 97
  - ASCII format (GPA), 246
  - assistant
    - See setup assistant
  - B**
  - BDM port
    - See debug port
  - bits
    - labels, 100
    - LSB and MSB, 100
    - STAT, 103
  - BKG light, 276
  - branches, displaying, 112
  - breakpoints
    - tracing until, 223
  - built-in commands
    - configuration, 156
    - list of commands, 277
  - bus cycle termination, 138
  - C**
  - cables
    - BDM, 149
    - emulator, 148
    - high-density, 50
    - replacing, 271
  - CD-ROM, installing software from, 32
  - cf commands, 156
  - characteristics
    - analysis probe, 227
    - emulation module, 244
  - checklist
    - setup, 17
  - circuit board, dimensions, 38
  - cleaning, 272, 289
  - clearance, analysis probe, 37
  - clock speed
    - configuring, 159
  - clocks
    - logic analyzer, 99
    - qualification, 106
    - qualified, and emulator, 216
    - slow, 222, 224, 268
  - comments, in GPA files, 254
  - compilers, 120
  - configuration
    - checklist, 17
    - emulation module
      - overview, 154
      - using debugger, 157
    - logic analyzers, 91, 100
  - configuration files
    - installing, 29
    - loading, 91, 93
    - names of, 95
  - connection
    - analysis probe, 35
    - emulation module, 131, 132
    - problems, LAN, 283
    - setup checklist, 17
  - connector
    - BDM, 149
    - debug port, 138
  - connector board, 291
  - creating GPA symbol files, 246
  - D**
  - DATA label, modifying, 100
  - debug port
    - connecting to, 148
    - connections, 138
  - debuggers
    - configuration, 157
    - Green Hills, 192
    - SDS, 201
    - writing, 279
  - development port
    - See debug port
  - Diab Data
    - compiler, 122
  - dimensions of analysis probe, 38
  - directories
    - configuration files, 92
    - source code, 128
  - display filtering, 112
-

- E**
- elastomeric probe adapter
    - definition, 291
  - EMSIM registers, 167
    - configuring analysis probe, 89
    - displaying, 168
    - example with debugger, 197
    - purpose of, 168
  - Emulation Control Interface
    - configuration, 155
    - introduction, 133
    - when to use, 212
  - emulation module
    - Agilent Technologies 16600
      - installation, 145
    - Agilent Technologies 16700A
      - installation, 143
      - configuration, 157
      - connecting, 132, 147
      - definition, 291
      - description of, 2
      - product numbers, 4
      - target system design, 138
  - emulation probe
    - definition, 291
  - emulation solution
    - See solution
  - emulator
    - definition, 291
  - enhanced inverse assembler
    - logic analyzer requirements, 24
  - environmental characteristics
    - emulation module, 243
  - equipment required
    - analysis probe, 22
    - emulation module, 26
  - equipment supplied, 20
    - analysis probe, 20
    - emulation module, 25
    - ordering information, 4
    - overview, 4
  - erratic behavior, 280
  - error messages
    - inverse assembler, 265
    - examples, measurement, 213
    - extender, 291
- F**
- files
    - loading vs. installing, 30
  - filtering, display, 112
  - firmware
    - emulation module, 153
    - updating, 152, 153
    - version, 153
  - flash ROM
    - updating emulator, 152
  - flexible adapter
    - definition, 291
  - floppy disks
    - duplicating, 93
  - flowchart
    - setup, 17
  - format menu, 100
  - full solution, 3
  - FUNCTIONS in GPA format, 251
- G**
- General-Purpose ASCII format, 246
    - address format, 246
    - comments, 254
    - FUNCTIONS, 251
    - record format summary, 248
    - record headers, 246
    - SECTIONS, 250
    - simple form, 246
    - SOURCE LINES, 253
    - START ADDRESS, 254
    - VARIABLES, 252
  - general-purpose flexible adapter
    - definition, 291
  - Green Hills
    - compiler, 123
    - debugger, 192
- H**
- high-density adapter cable
    - definition, 291
  - high-density termination adapter
    - definition, 292
  - HRESET signal, 138
- I**
- information sources, 28
  - installation, software, 29
  - intermodule measurement
    - creating, 215
  - intermodule measurement problems, 264
    - an event wasn't captured, 264
    - analyzer doesn't stop, 216
  - internal cycles, 118
  - internal registers, 167
  - inverse assembler
    - configuration file names, 95
    - loading files, 92, 93
    - output format, 110
    - requirements for, 107
    - requirements for enhanced, 24
  - inverse assembler problems, 262
    - failure to load or run, 263
    - incorrect inverse assembly, 262
    - no inverse assembly, 262
  - inverse assembly, 107
    - displays, 212
    - Pods required, 23
- J**
- jumper, definition, 292
- K**
- keep-out area, 37
- L**
- LAN
    - problems, 283



- lights
    - See status lights
  - listing
    - incorrect, 262
  - Listing menu, 107
  - listing windows, 212
  - Load menu, 112
  - loading configurations
    - logic analyzer, 91
    - vs. installing, 29
  - logic analyzers
    - Agilent Technologies 16550A
      - connections, 64
    - Agilent Technologies 16554/55/56
      - connections, 68
    - Agilent Technologies 1660 series
      - connections, 70
    - Agilent Technologies 16600A and 16700A-series, 19
    - Agilent Technologies 16600A
      - connections, 52
    - Agilent Technologies 16601A
      - connections, 55
    - Agilent Technologies 16602A
      - connections, 58
    - Agilent Technologies 16603A
      - connections, 61
    - Agilent Technologies 1661 series
      - connections, 72
    - Agilent Technologies 1662-series
      - connections, 74
    - Agilent Technologies 1670 series
      - connections, 76
    - Agilent Technologies 1671 series
      - connections, 79
    - Agilent Technologies 1672-series
      - connections, 82
  - clocking, 106
  - configuration, 100
  - configuring, 92, 93
  - loading configuration files, 91
  - software version requirements, 24
  - storage qualification, 106
  - supported, 23
- LSB, 100
- M**
- mainframe logic analyzer
    - definition, 292
  - male-to-male header
    - definition, 292
  - mask, subnet, 283
  - MCR
    - SHEN configuration, 118
  - measurement examples, 213
  - memory banks, 112
  - microprocessors supported, 4
  - Microtec Research Inc.
    - compiler, 124
  - modes
    - operating, 99
  - modifying, 100
  - MSB, 100
  - MULTI debugger, 192
- O**
- object module file symbols, 118
  - offset, address, 130
  - offset, trigger, 111
  - online configuration help, 19
  - operating characteristics
    - analysis probe, 227
    - emulation module, 243
  - Options menu, 112, 113
  - orientation, socket, 42
- P**
- parts supplied, 20
  - path, source file, 128
  - PC label, 127
  - Pods, labels on, 50
  - port number, emulation module, 277
  - power on/power off sequence, 39
- prefetches, 111
  - preprocessor
    - See analysis probe
  - problems
    - analysis probe, 255
  - processor support package, 32
  - processor type
    - configuring, 158
    - effect on EMSIM registers, 170
  - processors supported, 4
  - program symbols, 118
  - prompts, 279
    - list of, 279
  - prototype analyzer
    - definition, 292
  - PV
    - See performance verification
- Q**
- QFP socket, 42
- R**
- real-time runs, configuring, 164
  - record format, General-Purpose
    - ASCII, 248
  - record headers, 246
  - references, 28
  - registers
    - initializing, 281
    - internal, 167
    - problems displaying, 281, 282
    - unknown values, 282
  - repair
    - analysis probe, 270
    - emulation module, 288
  - requirements
    - target system, 37, 138
  - RESET
    - light, 276
  - reset
    - effects of, SDS debugger, 202
    - effects on SIM registers, 173
-

run control tool  
See emulation control interface

## S

SDS debugger, 201  
Section Format, 246  
SECTIONS in GPA format, 250  
service, how to obtain, 270, 288  
setup  
See configuration  
setup assistant, 19  
definition, 292  
setup checklist, 17  
SHEN (in MCR), 118  
signals  
debug port, 138  
logic analyzer, 231  
SIM registers  
configuring, 173  
configuring analysis probe, 89  
displaying, 168  
introduction, 168  
SingleStep debugger, 201  
skid, reducing, 216  
slow clock message, 222, 224, 275  
socket, QFP, 42  
software  
installing, 29  
list of installed, 33  
requirements, 24  
software addresses, 127  
software analyzer  
its dependence on address  
reconstruction, 228  
software probe  
See emulation probe  
software requirements, 24  
software,emulation module  
firmware, 153  
solution  
at a glance, 2  
definition, 292

solutions  
description of, 2  
equipment required, 27  
product numbers, 4  
source code, 115  
displays, 212  
source correlation, 22  
data display, 108  
in analyzer, 115  
using, 125  
source file search path, 128  
SOURCE LINES in GPA format,  
253  
specifications  
See characteristics  
SRESET signal, 138  
START ADDRESS in GPA format,  
254  
STAT, 100  
encoding, 103  
label, 103  
state, 228  
mode of operation, 99  
status bits, 103  
status encoding, 103  
status lights, 276  
subnet mask, 283  
symbol files  
creating, 246  
symbols  
in analyzer, 115  
its dependency on address  
reconstruction, 228  
object file, 118  
object module file, 118  
predefined, 104, 117  
program, 118  
user-defined, 117  
synchronous mode, 99

## T

target control port

definition, 293  
target interface module (TIM)  
connecting, 148  
definition, 293  
target system  
boot failure, 260  
connecting to, 132  
keep-out area, 37  
power sequence, 39  
requirements for analysis probe,  
37  
requirements for emulation, 138  
telnet, 277  
terminal interface  
See also built-in commands  
tests, emulation module, 284  
The, 19  
timing, 228  
mode of operation, 99  
trace, 218  
erratic, 261  
missing display, 258  
trace list alignment  
its dependency on address  
reconstruction, 228  
transition board  
definition, 293  
trigger  
address reconstruction, 228  
emulation module, 214  
on break, 219  
source code, 129  
specification, 100  
unwanted, 258  
troubleshooting, 275  
analysis probe, 255, 256

## U

unexecuted prefetches, 111  
until processor halts, 218  
USER light, 276

---

## V

VARIABLES in GPA format, 252

versions

    emulation module firmware, 153

    logic analyzer software, 24

voltage

    emulation module, 244

## W

web sites

    Agilent Technologies logic  
    analyzers, 28

    See Also under debugger names

wizard

    See setup assistant

---

# Index

---

# DECLARATION OF CONFORMITY

according to ISO/IEC Guide 22 and EN 45014

**Manufacturer's Name:** Agilent Technologies

**Manufacturer's Address:** Digital Design Product Generation Unit  
1900 Garden of the Gods Road  
Colorado Springs, CO 80907 USA

declares, that the product

**Product Name:** Logic Analyzer

**Model Number(s):** Agilent Technologies 16600A, 16601A, 16602A, 16603A

**Product Option(s):** All

conforms to the following Product Specifications:

**Safety:** IEC 1010-1:1990+A1 / EN 61010-1:1993  
UL3111  
CSA-C22.2 No. 1010.1:1993


**EMC:** CISPR 11:1990 / EN 55011:1991                      Group 1 Class A  
IEC 555-2:1982 + A1:1985 / EN 60555-2:1987  
IEC 555-3:1982 + A1:1990 / EN 60555-3:1987 + A1:1991  
IEC 801-2:1991 / EN 50082-1:1992                      4 kV CD, 8 kV AD  
IEC 801-3:1984 / EN 50082-1:1992                      3 V/m, {1kHz 80% AM, 27-1000 MHz}  
IEC 801-4:1998 / EN 50082-1:1992                      0.5 kV Sig. Lines, 1 kV Power Lines

## Supplementary Information:

The product herewith complies with the requirements of the Low Voltage Directive 73/23/EEC and the EMC Directive 89/336/EEC and carries the CE marking accordingly.

This product was tested in a typical configuration with Agilent Technologies test systems.

Colorado Springs, 08/18/97

  
John Strathman, Quality Manager

European Contact: Your local Agilent Technologies Sales and Service Office or Agilent Technologies GmbH, Department ZQ / Standards Europe, Herrenberger Strasse 130, D-71034 Böblingen Germany (FAX: +49-7031-14-3143)

## Product Regulations


**Safety** IEC 1010-1:1990+A1 / EN 61010-1:1993  
UL3111  
CSA-C22.2 No. 1010.1:1993

## EMC

This Product meets the requirement of the European Communities (EC) EMC Directive 89/336/EEC.



**Emissions** EN55011/CISPR 11 (ISM, Group 1, Class A equipment),  
IEC 555-1 and IEC 555-2



<b>Immunity</b>	EN50082-1	Code <sup>1</sup>	Notes <sup>2</sup>
	IEC 801-2 (ESD) 4kV CD, 8kV AD	3	
	IEC 801-3 (Rad.) 3 V/m	1	
	IEC 801-4 (EFT) 0.5 kV, 1kV	3	

<sup>1</sup>Performance Codes:

1 PASS - Normal operation, no effect.

2 PASS - Temporary degradation, self recoverable.

3 PASS - Temporary degradation, operator intervention required.

4 FAIL - Not recoverable, component damage.

<sup>2</sup>Notes: (none)

**Sound Pressure Level** Less than 60 dBA

# DECLARATION OF CONFORMITY

according to ISO/IEC Guide 22 and EN 45014

**Manufacturer's Name:** Agilent Technologies  
**Manufacturer's Address:** Digital Design Product Generation Unit  
1900 Garden of the Gods Road  
Colorado Springs, CO 80907 USA

declares, that the product

**Product Name:** Logic Analyzer Mainframe  
**Model Number(s):** Agilent Technologies 16700A  
**Product Option(s):** All

conforms to the following Product Specifications:

**Safety:** IEC 1010-1:1990+A1 / EN 61010-1:1993  
UL3111  
CSA-C22.2 No. 1010.1:1993


**EMC:** CISPR 11:1990 / EN 55011:1991                      Group 1 Class A  
IEC 555-2:1982 + A1:1985 / EN 60555-2:1987  
IEC 555-3:1982 + A1:1990 / EN 60555-3:1987 + A1:1991  
IEC 801-2:1991 / EN 50082-1:1992                      4 kV CD, 8 kV AD  
IEC 801-3:1984 / EN 50082-1:1992                      3 V/m, {1kHz 80% AM, 27-1000 MHz}  
IEC 801-4:1998 / EN 50082-1:1992                      0.5 kV Sig. Lines, 1 kV Power Lines

## Supplementary Information:

The product herewith complies with the requirements of the Low Voltage Directive 73/23/EEC and the EMC Directive 89/336/EEC and carries the CE marking accordingly.

This product was tested in a typical configuration with Agilent Technologies test systems.

Colorado Springs, 09/22/97

  
John Strathman, Quality Manager

European Contact: Your local Agilent Technologies Sales and Service Office or Agilent Technologies GmbH, Department ZQ / Standards Europe, Herrenberger Strasse 130, D-71034 Böblingen Germany (FAX: +49-7031-14-3143)


## Product Regulations

**Safety** IEC 1010-1:1990+A1 / EN 61010-1:1993  
UL3111  
CSA-C22.2 No. 1010.1:1993

**EMC** This Product meets the requirement of the European Communities (EC) EMC Directive 89/336/EEC.



**Emissions** EN55011/CISPR 11 (ISM, Group 1, Class A equipment),  
IEC 555-2 and IEC 555-3



<b>Immunity</b>		Code <sup>1</sup>	Notes <sup>2</sup>
EN50082-1			
IEC 801-2 (ESD) 4kV CD, 8kV AD		3	
IEC 801-3 (Rad.) 3 V/m		1	
IEC 801-4 (EFT) 0.5 kV, 1kV		3	

<sup>1</sup>Performance Codes:

1 PASS - Normal operation, no effect.

2 PASS - Temporary degradation, self recoverable.

3 PASS - Temporary degradation, operator intervention required.

4 FAIL - Not recoverable, component damage.

<sup>2</sup>Notes: (none)

**Sound Pressure Level** Less than 60 dBA



© Copyright Agilent Technologies  
1994-2000  
All Rights Reserved.

Reproduction, adaptation, or translation without prior written permission is prohibited, except as allowed under the copyright laws.

### Restricted Rights Legend

Use, duplication, or disclosure by the U.S. Government is subject to restrictions set forth in subparagraph (C) (1) (ii) of the Rights in Technical Data and Computer Software Clause in DFARS 252.227-7013. Agilent Technologies, 3000 Hanover Street, Palo Alto, CA 94304 U.S.A. Rights for non-DOD U.S. Government Departments and Agencies are set forth in FAR 52.227-19 (c) (1,2).

### Document Warranty

The information contained in this document is subject to change without notice.

**Agilent Technologies makes no warranty of any kind with regard to this material, including, but not limited to, the implied warranties of merchantability or fitness for a particular purpose.**

Agilent Technologies shall not be liable for errors contained herein or for damages in connection with the furnishing, performance, or use of this material.

### Safety

This apparatus has been designed and tested in accordance with IEC Publication 1010, Safety Requirements for Measuring Apparatus, and has been supplied in a safe condition. This is a Safety Class I instrument (provided with terminal for protective earthing). Before applying power, verify that the correct safety precautions are taken (see the following warnings). In addition, note the external markings on the instrument that are described under "Safety Symbols."

### Warning

- Before turning on the instrument, you must connect the protective earth terminal of the instrument to the protective conductor of the (mains) power cord. The mains plug shall only be inserted in a socket outlet provided with a protective earth contact. You must not negate the protective action by using an extension cord (power cable) without a protective conductor (grounding). Grounding one conductor of a two-conductor outlet is not sufficient protection.
- Only fuses with the required rated current, voltage, and specified type (normal blow, time delay, etc.) should be used. Do not use repaired fuses or short-circuited fuseholders. To do so could cause a shock or fire hazard.

- Service instructions are for trained service personnel. To avoid dangerous electric shock, do not perform any service unless qualified to do so. Do not attempt internal service or adjustment unless another person, capable of rendering first aid and resuscitation, is present.

- If you energize this instrument by an auto transformer (for voltage reduction), make sure the common terminal is connected to the earth terminal of the power source.

- Whenever it is likely that the ground protection is impaired, you must make the instrument inoperative and secure it against any unintended operation.

- Do not operate the instrument in the presence of flammable gasses or fumes. Operation of any electrical instrument in such an environment constitutes a definite safety hazard.

- Do not install substitute parts or perform any unauthorized modification to the instrument.

- Capacitors inside the instrument may retain a charge even if the instrument is disconnected from its source of supply.

### Safety Symbols



Instruction manual symbol: the product is marked with this symbol when it is necessary for you to refer to the instruction manual in order to protect against damage to the product.



Hazardous voltage symbol.



Earth terminal symbol: Used to indicate a circuit common connected to grounded chassis.

### WARNING

The Warning sign denotes a hazard. It calls attention to a procedure, practice, or the like, which, if not correctly performed or adhered to, could result in personal injury. Do not proceed beyond a Warning sign until the indicated conditions are fully understood and met.

### CAUTION

The Caution sign denotes a hazard. It calls attention to an operating procedure, practice, or the like, which, if not correctly performed or adhered to, could result in damage to or destruction of part or all of the product. Do not proceed beyond a Caution symbol until the indicated conditions are fully understood or met.

---

## Product Warranty

This Agilent Technologies product has a warranty against defects in material and workmanship for a period of one year from date of shipment. During the warranty period, Agilent Technologies will, at its option, either repair or replace products that prove to be defective.

For warranty service or repair, this product must be returned to a service facility designated by Agilent Technologies.

For products returned to Agilent Technologies for warranty service, the Buyer shall prepay shipping charges to Agilent Technologies and Agilent Technologies shall pay shipping charges to return the product to the Buyer. However, the Buyer shall pay all shipping charges, duties, and taxes for products returned to Agilent Technologies from another country.

Agilent Technologies warrants that its software and firmware designated by Agilent Technologies for use with an instrument will execute its programming instructions when properly installed on that instrument. Agilent Technologies does not warrant that the operation of the instrument software, or firmware will be uninterrupted or error free.

## Limitation of Warranty

The foregoing warranty shall not apply to defects resulting from improper or inadequate maintenance by the Buyer, Buyer-supplied software or interfacing, unauthorized modification or misuse, operation outside of the environmental specifications for the product, or improper site preparation or maintenance.

**No other warranty is expressed or implied. Agilent Technologies specifically disclaims the implied warranties of merchantability or fitness for a particular purpose.**

## Exclusive Remedies

The remedies provided herein are the buyer's sole and exclusive remedies. Agilent Technologies shall not be liable for any direct, indirect, special, incidental, or consequential damages, whether based on contract, tort, or any other legal theory.

## Assistance

Product maintenance agreements and other customer assistance agreements are available for Agilent Technologies products. For any assistance, contact your nearest Agilent Technologies Sales Office.

## Certification

Agilent Technologies certifies that this product met its published specifications at the time of shipment from the factory. Agilent Technologies further certifies that its calibration measurements are traceable to the United States National Institute of Standards and Technology, to the extent allowed by the Institute's calibration facility, and to the calibration facilities of other International Standards Organization members.

## About this edition

This is the *Solutions for Motorola CPU32 User's Guide*.

Publication number  
E2480-97003, June 2000  
Printed in USA.

The information in this manual previously appeared in:

E3458-97000, Feb 1997  
E2480-97001, May 1997  
E2480-97002, July 1998

Many product updates do not require manual changes, and manual corrections may be done without accompanying product changes. Therefore, do not expect a one-to-one correspondence between product updates and manual updates.

Reflection 1 is a U.S. trademark of Wlker, Richer & Quinn, Inc.

UNIX is a registered trademark of The Open Group.

Windows, MS Windows, Windows NT, and MS-DOS are U.S. registered trademarks of Microsoft Corporation.

X/Open is a registered trademark, and the X device is a trademark of X/Open Company Ltd. in the UK and other countries.