

INFORMATION ONLY – DOES NOT COMMUNICATE
A MODIFICATION OR SAFETY CONDITION

E8267D-12

S E R V I C E N O T E

Supersedes:
None

E8267D Vector Signal Generator

Serial Numbers: [0000A00000 / 9999Z99999]

Error code 617 configuration error can indicate the CPU is not able to detect an assembly. This service note documents the name and status for each assembly and what information should be displayed on the Installed Board Info screen. The Install Board Info is located under the Utility key.

Parts Required:

P/N	Description	Qty.
NA		

ADMINISTRATIVE INFORMATION

SERVICE NOTE CLASSIFICATION:

INFORMATION ONLY

AUTHOR: DMc PRODUCT LINE: PL15

ADDITIONAL INFORMATION:

© AGILENT TECHNOLOGIES, INC. 2006
PRINTED IN U.S.A.



October 2, 2006

Situation:

Error code 617 indicates the CPU is having problems recognizing some of the installed hardware. The primary reasons the error may occur is because the hardware is missing, or the board header information is missing, or the mother board is defective. Reviewing the Installed Board Info can help pinpoint which assembly(s) the CPU can not locate and can be helpful in troubleshooting the problem.

Solution/Action:

1. Go to the Installed Board Info screen (press Utility, Instrument Info/Help Mode, and Installed Board Info) and compare the displayed Description list with the following list. If any assembly is missing and is not an installed option there is a problem. So note the board name and go to step 3.

Note - Some assemblies are options and will only be displayed when the option is installed.

2. Review each assembly status.

a. If the status in the list is detected it indicates the CPU should be able to read the header information. If the CPU can not read the header information it will report something other than detected. Proceed to step 3.

b. If the status is fixed it means the assembly is not detectable but should be installed based on option configuration. For fixed status assemblies if the option hardware is installed but the status does not show as fixed go to step 6.

Description	Status	Bus
ALC	DETECTED	Parallel
ANALOG MOD GEN	DETECTED	Parallel
CPU	DETECTED	
DIG BUS BBGEN (only w/option 601/2 installed)	DETECTED	Parallel
FRACN	DETECTED	Serial
HARD DRIVE (only w/option 005 installed)	DETECTED	
IQ MUX	DETECTED	Parallel
LOW BAND FILTER (only with option 1EH)	DETECTED	Parallel
LOW BAND OUTPUT	DETECTED	Parallel
MECH ATTEN	FIXED	
MICRO INTERFACE	DETECTED	Parallel
MOTHERBOARD	DETECTED*	
PULSE MODULATOR (only w/option UNW)	FIXED	
REFERENCE	DETECTED	
SAMPLER	DETECTED	
YIG DRIVER	DETECTED	

* Header information is not loaded in replacement mother boards. After replacing the mother board, contact the support engineer and request for header information to be loaded.

4. If all the assemblies for the parallel or serial bus are missing work through the following steps until the problem is resolved:

a. remove and reinstall the CPU

b. remove all the boards for that bus and install one at a time. If the assemblies are detected until one board is installed, that assembly is loading the bus and needs to be replaced.

c. replace the CPU

d. replace the mother board.

5. If an assembly show detected for the old assembly but not for the new assembly, the new assembly header information is missing. The board is defective from stock (except for the mother board as noted) and should be returned and reordered. Missing the header information indicates the assembly did not go through all the processes.

6. Verify that the option license key is installed and that a check mark appears after the license key. If there is no check mark, the license key is incorrect and needs to be reinstalled. Contact the support engineer for assistance in getting the license key information.