

cdmaOne Programming Commands

Agilent Technologies E4406A VSA Series Transmitter Tester



Manufacturing Part Number: E4406-90102

Printed in USA

April 2000

© Copyright 1999-2000 Agilent Technologies Company

The information contained in this document is subject to change without notice.

Agilent Technologies makes no warranty of any kind with regard to this material, including but not limited to, the implied warranties of merchantability and fitness for a particular purpose. Agilent Technologies shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance, or use of this material.

Contents

1. cdmaOne Programming Commands

SCPI Command Subsystems	6
CALCulate Subsystem	7
Adjacent Channel Power Limit Test	7
Query the Current Measurement Status	7
Data Query	7
Calculate/Compress Trace Data Query	7
Calculate Peaks of Trace Data	9
CALCulate:MARKers Subsection	11
CONFigure Subsystem	19
DISPlay Subsystem	20
Spectrum Measurement Y-Axis Reference Level	20
Turn a Trace Display On/Off	21
Waveform Measurement Y-Axis Reference Level	23
FETCh Subsystem	24
MEASure Group of Commands	25
Measure Commands	25
Configure Commands	26
Fetch Commands	26
Read Commands	27
Adjacent Channel Power Ratio (ACP) Measurement	28
Code Domain Power Measurement	33
Channel Power Measurement	36
Close Spurs Measurement	37
Rho (Waveform Quality) Measurement	38
Spectrum (Frequency Domain) Measurement	43
Waveform (Time Domain) Measurement	45
READ Subsystem	47
SENSe Subsystem	48
Adjacent Channel Power Measurement	48
Code Domain Power Measurement	64
Channel Power Measurement	67
Correction for Base Station RF Port External Attenuation	71
Close Spurs Measurement	72
Select the Input Port	74
Center Frequency	74
Center Frequency Step Size Automatic	74
Center Frequency Step Size	75
RF Port Input Attenuation	75
RF Port Power Range Auto	75
RF Port Power Range Maximum Total Power	76
Radio Carrier Multiple	76
Radio Standard Band	77
Rho (Waveform Quality) Measurement	78
Reference Oscillator External Frequency	81
Reference Oscillator Rear Panel Output	81
Reference Oscillator Source	81
Spectrum (Frequency-Domain) Measurement	83
Sync Type	94

Waveform (Time-Domain) Measurement95

SCPI Command Subsystems

CALCulate on [page 7](#)

CONFigure on [page 19](#)

DISPlay on [page 20](#)

FETCh on [page 24](#)

MEASure on [page 25](#)

READ on [page 47](#)

SENSe on [page 48](#)

CALCulate Subsystem

This subsystem is used to perform post-acquisition data processing. In effect, the collection of new data triggers the CALCulate subsystem. In this instrument, the primary functions in this subsystem are markers and limits.

Adjacent Channel Power Limit Test

`:CALCulate:ACP:LIMit:STATe OFF|ON|0|1`

`:CALCulate:ACP:LIMit:STATe?`

Turn limit test on or off.

Factory Preset
and *RST: On

Remarks: You must be in Basic, cdmaOne, iDEN mode to use this command. Use INSTRument:SElect to set the mode.

Query the Current Measurement Status

`:CALCulate:CLIMits:FAIL?`

Checks if the current measurement is outside its limits. It returns a 0 (zero) if it is passing or a 1 (one) if it is failing.

Front Panel
Access: None

Data Query

`:CALCulate:DATA[n]?`

Returns the designated measurement data for the currently selected measurement and sub-opcode.

n = any valid sub-opcode for the current measurement. See the [“MEASure Group of Commands” on page 25](#) for information on the data that can be returned for each measurement.

Calculate/Compress Trace Data Query

`:CALCulate:DATA[n]:COMPRESS?`

`MAXimum|MEAN|MINimum|RMS|SAMPLE|SDEVIation|CFIT`

{,<soffset>}{,<length>}{,<roffset>}

Returns the designated trace data for the currently selected measurement. The command can be used with sub-opcodes (*n*) for measurement results that are trace data. See the following table.

This command is used to compress/decimate a long trace to extract the desired data and only return to the computer the necessary data. A typical example would be to acquire N bursts of GSM data and return the mean power of each burst.

The command can also be used to identify the best curve fit for the data.

Curve Fit - applies curve fitting routines to the data. Where <soffset> and <length> are required, and <roffset> is an optional parameter for the desired order of the curve equation. The query will return the following values: the x-offset (in points) and the curve coefficients ((order + 1) values).

<Start offset> - is an optional integer. It specifies the amount of data, at the beginning of the trace, that will be ignored before the decimation process starts. It is an integer index (that starts counting at zero) for all the elements in the trace. The default value is zero.

<Length> - is an optional integer that defines how many trace elements will be compressed into one value. This parameter has a default value equal to the current trace length.

<Repeat offset> - is an optional real number. It defines the beginning of the next field of trace elements to be compressed. This is relative to the beginning of the previous field. This parameter has a default value equal to the <length> variable. Select a number such that repeated additions will round to the correct starting index.

Example: To query the mean power of a set of GSM bursts:

1. Set the waveform measurement sweep time to acquire the required number of bursts.
2. Set the triggers such that acquisition happens at a known position relative to a burst.
3. Then query the mean burst levels using,
`CALC:DATA2:COMP? MEAN,62,1315,1442.3` (These parameter values correspond to GSM signals.)

Remarks: The optional parameters must be entered in the specified order. If you want to specify <length>, you must also specify <soffset> or it's default. (e.g.
`CALC:DATA2:COMP? MEAN,62,1315`)

This command uses the data setting specified by the FORMat:DATA command and can return binary or ascii data.

History: Added in revision A.03.00 and later

Measurement	Available Traces	Markers Available?
ACP - adjacent channel power (Basic, cdmaOne, cdma2000, W-CDMA, iDEN, NADC, PDC modes)	no traces	no markers
CDPower - code domain power (cdmaOne mode)	POWer ($n=2$) ^a TIMing ($n=3$) ^a PHASe ($n=4$) ^a	yes
CHPower - channel power (Basic, cdmaOne, cdma2000, W-CDMA mode)	SPECtrum ($n=2$) ^a	no markers
CSPur - spurs close (cdmaOne mode)	SPECtrum ($n=2$) ^a ULIMit ($n=3$) ^a	yes
RHO - modulation quality (cdmaOne, cdma2000, W-CDMA mode)	EVM ($n=2$) ^a MERRor ($n=3$) ^a PERRor ($n=4$) ^a	yes
SPECtrum - (frequency domain) (all modes)	RFENvelope ($n=2$) ^a for Service mode IQ ($n=3$) ^a SPECtrum ($n=4$) ^a ASPECTrum ($n=7$) ^a	yes
WAVEform - (time domain) (all modes)	RFENvelope ($n=2$) ^a IQ ($n=8$) ^a	yes

a. The n number indicates the sub-opcode that corresponds to this trace. Detailed descriptions of the trace data can be found in the MEASure subsystem documentation by looking up the sub-opcode for the appropriate measurement.

Calculate Peaks of Trace Data

```
:CALCulate:DATA[n]:PEAKs?  
<threshold>,<excursion>[,AMPLitude|FREQuency|TIME]
```

Returns a list of peaks for the designated trace data *n* for the currently selected measurement. The peaks must meet the requirements of the peak threshold and excursion values.

The command can be used with sub-opcodes (*n*) for any measurement results that are trace data. See the table above. Subopcode *n*=0, raw trace data cannot be searched for peaks. Both real and complex traces can be searched, but complex traces are converted to magnitude in dBm.

Threshold - is the level below which trace data peaks are ignored

Excursion - To be defined as a peak, the signal must rise above the threshold by a minimum amplitude change. Excursion is measured from the lowest point above the threshold (of the rising edge of the peak), to the highest signal point that begins the falling edge.

Amplitude - lists the peaks in order of descending amplitude, so the highest peak is listed first. This is the default peak order listing if the optional parameter is not specified.

Frequency - lists the peaks in order of occurrence, left to right across the x-axis

Time - lists the peaks in order of occurrence, left to right across the x-axis

Example: Select the spectrum measurement.

Use `CALC:DATA4:PEAK? -40,10,FREQ` to identify the peaks above -40 dBm, with excursions of at least 10 dB, in order of increasing frequency.

Query Results: Returns a list of floating-point numbers. The first value in the list is the number of peak points that follow. A peak point consists of two values: a peak amplitude followed by the its corresponding frequency (or time).

If no peaks are found the peak list will consist of only the number of peaks, (0).

The peak list is limited to 100 peaks. Peaks in excess of 100 are ignored.

Remarks: This command uses the data setting specified by the `FORMat:DATA` command and can return real 32-bit, real 64-bit, or ASCII data. The default data format is ASCII.

History: Added in revision A.03.00 and later

CALCulate:MARKers Subsection

When using the marker commands you must specify the measurement in the SCPI command. We recommend that you use the marker commands only on the current measurement. Many marker commands will return invalid results, when used on a measurement that is not current. (This is true for commands that do more than simply setting or querying an instrument parameter.) No error is reported for these invalid results.

You must make sure that the measurement is completed before trying to query the marker value. Using the MEASure or READ command, before the marker command, forces the measurement to complete before allowing the next command to be executed.

Each measurement has its own instrument state for marker parameters. Therefore, if you exit the measurement, the marker settings in each measurement are saved and are then recalled when you change back to that measurement.

cdmaOne Mode - <measurement> key words

- ACPr - no markers
- CHPower - no markers
- CDPower - markers available
- CSPur - markers available
- RHO - markers available
- SPECTrum - markers available
- WAVeform - markers available

Example:

Suppose you are using the Spectrum measurement. To position marker 2 at the maximum peak value, of the trace that marker 2 is currently on, the command is:

```
:CALCulate:SPECTrum:MARKer2:MAXimum
```

You must make sure that the measurement is completed before trying to query the marker value. Using the MEASure or READ command, before the marker command, forces the measurement to complete before allowing the next command to be executed.

Markers All Off on All Traces

:CALCulate:<measurement>:MARKer:AOff

Turns off all markers on all the traces.

Example: **CALC:SPEC:MARK:AOff**

Remarks: The keyword for the current measurement must be specified in the command. (Some examples include: SPECTrum, WAVeform)

Front Panel

Access: **Marker, More, Marker All Off**

Marker Function

**:CALCulate:<measurement>:MARKer[1] | 2 | 3 | 4:FUNCTION
BPOWer | NOISe | OFF**

:CALCulate:<measurement>:MARKer[1] | 2 | 3 | 4:FUNCTION?

Selects the type of marker for the specified marker. A particular measurement may not have all the types of markers that are commonly available.

The marker must have already been assigned to a trace. Use

:CALCulate:<measurement>:MARKer[1] | 2 | 3 | 4:TRACe to assign a marker to a particular trace.

Band Power – is the integrated power between the two markers for traces in the frequency domain and is the mean power between the two markers for traces in the time domain.

Noise – is the noise power spectral density in a 1 Hz bandwidth. It is averaged over 32 horizontal trace points.

Off – turns off the marker functions

Example: **CALC:SPEC:MARK3:FUNC Noise**

Remarks: The keyword for the current measurement must be specified in the command. (Some examples include: SPECTrum, WAVeform)

Front Panel

Access: **Marker, Marker Function**

Marker Function Result

`:CALCulate:<measurement>:MARKer[1]|2|3|4:FUNCTION:RESult?`

Requires the result of the currently active marker function. The measurement must be completed before querying the marker. A particular measurement may not have all the types of markers available.

The marker must have already been assigned to a trace. Use `:CALCulate:<measurement>:MARKer[1]|2|3|4:TRACe` to assign a marker to a particular trace.

Example: `CALC:SPEC:MARK:FUNC:RES?`

Remarks: The keyword for the current measurement must be specified in the command. (Some examples include: SPECTrum, WAVeform)

Front Panel

Access: **Marker, Marker Function**

Marker Peak (Maximum) Search

`:CALCulate:<measurement>:MARKer[1]|2|3|4:MAXimum`

Places the selected marker on the highest point on the trace that is assigned to that particular marker number.

The marker must have already been assigned to a trace. Use `:CALCulate:<measurement>:MARKer[1]|2|3|4:TRACe` to assign a marker to a particular trace.

Example: `CALC:SPEC:MARK1:MAX`

Remarks: The keyword for the current measurement must be specified in the command. (Some examples include: SPECTrum, WAVeform)

Front Panel

Access: **Search**

Marker Peak (Minimum) Search

:CALCulate:<measurement>:MARKer[1] | 2 | 3 | 4:MINimum

Places the selected marker on the lowest point on the trace that is assigned to that particular marker number.

The marker must have already been assigned to a trace. Use **:CALCulate:<measurement>:MARKer[1] | 2 | 3 | 4:TRACe** to assign a marker to a particular trace.

Example: **CALC:SPEC:MARK2:MIN**

Remarks: The keyword for the current measurement must be specified in the command. (Some examples include: SPECTrum, WAVeform)

Front Panel
Access: None

Marker Mode

**:CALCulate:<measurement>:MARKer[1] | 2 | 3 | 4:MODE
POSITION|DELTA**

:CALCulate:<measurement>:MARKer[1] | 2 | 3 | 4:MODE?

Selects the type of marker to be a normal position-type marker or a delta marker. A specific measurement may not have both types of markers. For example, several measurements only have position markers.

The marker must have already been assigned to a trace. Use **:CALCulate:<measurement>:MARKer[1] | 2 | 3 | 4:TRACe** to assign a marker to a particular trace.

Example: **CALC:SPEC:MARK:MODE DELTA**

Remarks: For the delta mode only markers 1 and 2 are valid.

The keyword for the current measurement must be specified in the command. (Some examples include: SPECTrum, WAVeform)

Front Panel
Access: **Marker, Marker [Delta]**

Marker On/Off

`:CALCulate:<measurement>:MARKer[1]|2|3|4[:STATe] OFF|ON|0|1`

`:CALCulate:<measurement>:MARKer[1]|2|3|4[:STATe]?`

Turns the selected marker on or off.

The marker must have already been assigned to a trace. Use

`:CALCulate:<measurement>:MARKer[1]|2|3|4:TRACe` to assign a marker to a particular trace.

Example: `CALC:SPEC:MARK2: on`

Remarks: The keyword for the current measurement must be specified in the command. (Some examples include: SPECTrum, AREFERENCE, WAVeform)

The WAVeform measurement only has two markers available.

Front Panel

Access: **Marker, Select then Marker Normal or Marker On Off**

Marker to Trace

`:CALCulate:<measurement>:MARKer[1]|2|3|4:TRACe <trace_name>`

`:CALCulate:<measurement>:MARKer[1]|2|3|4:TRACe?`

Assigns the specified marker to the designated trace. Not all types of measurement data can have markers assigned to them.

Example: With the WAVeform measurement selected, a valid command is `CALC:SPEC:MARK2:TRACE rfenvelope`.

Range: The names of valid traces are dependent upon the selected measurement. See the following table for the available trace names. The trace name assignment is independent of the marker number.

Remarks: The keyword for the current measurement must be specified in the command. (Some examples include: SPECTrum, WAVeform)

Front Panel

Access: **Marker, Marker Trace**

Measurement	Available Traces	Markers Available?
ACP - adjacent channel power (Basic, cdmaOne, cdma2000, W-CDMA, iDEN, NADC, PDC modes)	no traces	no markers
CDPower - code domain power (cdmaOne mode)	POWer ($n=2$) ^a TIMing ($n=3$) ^a PHASe ($n=4$) ^a	yes
CHPower - channel power (Basic, cdmaOne, cdma2000, W-CDMA mode)	SPECtrum ($n=2$) ^a	no markers
CSPur - spurs close (cdmaOne mode)	SPECtrum ($n=2$) ^a ULIMit ($n=3$) ^a	yes
RHO - modulation quality (cdmaOne, cdma2000, W-CDMA mode)	EVM ($n=2$) ^a MERRor ($n=3$) ^a PERRor ($n=4$) ^a	yes
SPECtrum - (frequency domain) (all modes)	RFENvelope ($n=2$) ^a for Service mode IQ ($n=3$) ^a SPECtrum ($n=4$) ^a ASPectrum ($n=7$) ^a	yes
WAVEform - (time domain) (all modes)	RFENvelope ($n=2$) ^a IQ ($n=8$) ^a	yes

a. The n number indicates the sub-opcode that corresponds to this trace. Detailed descriptions of the trace data can be found in the MEASure subsystem documentation by looking up the sub-opcode for the appropriate measurement.

Marker X Value

`:CALCulate:<measurement>:MARKer[1]|2|3|4:X <param>`

`:CALCulate:<measurement>:MARKer[1]|2|3|4:X?`

Position the designated marker on its assigned trace at the specified X value. The parameter value is in X-axis units (which is often frequency or time).

The marker must have already been assigned to a trace. Use

`:CALCulate:<measurement>:MARKer[1]|2|3|4:TRACe` to assign a marker to a particular trace.

The query returns the current X value of the designated marker. The measurement must be completed before querying the marker.

Example: `CALC:SPEC:MARK2:X 1.2e6 Hz`

Default Unit: Matches the units of the trace on which the marker is positioned

Remarks: The keyword for the current measurement must be specified in the command. (Some examples include: SPECTrum, WAVeform)

Front Panel

Access: **Marker, <active marker>, RPG**

Marker X Position

**:CALCulate:<measurement>:MARKer[1]|2|3|4:X:POSITION
<integer>**

:CALCulate:<measurement>:MARKer[1]|2|3|4:X:POSITION?

Position the designated marker on its assigned trace at the specified X position. A trace is composed of a variable number of measurement points. This number changes depending on the current measurement conditions. The current number of points must be identified before using this command to place the marker at a specific location.

The marker must have already been assigned to a trace. Use **:CALCulate:<measurement>:MARKer[1]|2|3|4:TRACe** to assign a marker to a particular trace.

The query returns the current X position for the designated marker. The measurement must be completed before querying the marker.

Example: **CALC:SPEC:MARK:X:POS 500**

Range: 0 to a maximum of (3 to 920,000)

Remarks: The keyword for the current measurement must be specified in the command. (Some examples include: SPECTrum, WAVeform)

Front Panel

Access: **Marker, <active marker>, RPG**

Marker Readout Y Value

:CALCulate:<measurement>:MARKer[1]|2|3|4:Y?

Readout the current Y value for the designated marker on its assigned trace. The value is in the Y-axis units for the trace (which is often dBm).

The marker must have already been assigned to a trace. Use **:CALCulate:<measurement>:MARKer[1]|2|3|4:TRACe** to assign a marker to a particular trace.

The measurement must be completed before querying the marker.

Example: **CALC:SPEC:MARK1:Y -20 dB**

Default Unit: Matches the units of the trace on which the marker is positioned

Remarks: The keyword for the current measurement must be specified in the command. (Some examples include: SPECTrum, WAVeform)

CONFigure Subsystem

`:CONFigure:<measurement>`

The CONFigure commands are used with several other commands and are documented in the section on the [“MEASure Group of Commands”](#) on page 25.

DISPlay Subsystem

The DISPlay controls the selection and presentation of textual, graphical, and TRACe information. Within a DISPlay, information may be separated into individual WINDows.

Spectrum Measurement Y-Axis Reference Level

```
:DISPlay:SPECTrum[n]:WINDow[m]:TRACe:Y[:SCALE]:RLEVEL
<power>
```

```
:DISPlay:SPECTrum[n]:WINDow[m]:TRACe:Y[:SCALE]:RLEVEL?
```

Sets the amplitude reference level for the y-axis.

n – selects the view, the default is Spectrum.

— n=1, Spectrum

— n=2, I/Q Waveform

— n=3, numeric data (service mode)

— n=4, RF Envelope (service mode)

m – selects the window within the view. The default is 1.

Factory Preset

and *RST: 0 dBm, for Spectrum

Range: –250 to 250 dBm, for Spectrum

Default Unit: dBm, for Spectrum

Remarks: May affect input attenuator setting.

To use this command, the appropriate mode should be selected with INSTRUMENT:SElect.

Front Panel

Access: When in Spectrum measurement: **Amplitude Y Scale, Ref Level**

Turn a Trace Display On/Off

`:DISPlay:TRACe[n][:STATe] OFF|ON|0|1`

`:DISPlay:TRACe[n][:STATe]?`

Controls whether the specified trace is visible or not.

n is a sub-opcode that is valid for the current measurement. See the [“MEASure Group of Commands” on page 25](#) for more information about sub-opcodes.

Factory Preset
and *RST: On

Range: The valid traces and their sub-opcodes are dependent upon the selected measurement. See the following table.

The trace name assignment is independent of the window number.

Remarks: To use this command, the appropriate mode should be selected with INSTRument:SElect.

Front Panel
Access: Display, Display Traces

Measurement	Available Traces	Markers Available?
ACP - adjacent channel power (Basic, cdmaOne, cdma2000, W-CDMA, iDEN, NADC, PDC modes)	no traces	no markers
CDPower - code domain power (cdmaOne mode)	POWer ($n=2$) ^a TIMing ($n=3$) ^a PHASe ($n=4$) ^a	yes
CHPower - channel power (Basic, cdmaOne, cdma2000, W-CDMA mode)	SPECtrum ($n=2$) ^a	no markers
CSPur - spurs close (cdmaOne mode)	SPECtrum ($n=2$) ^a ULIMit ($n=3$) ^a	yes
RHO - modulation quality (cdmaOne, cdma2000, W-CDMA mode)	EVM ($n=2$) ^a MERRor ($n=3$) ^a PERRor ($n=4$) ^a	yes
SPECtrum - (frequency domain) (all modes)	RFENvelope ($n=2$) ^a for Service mode IQ ($n=3$) ^a SPECtrum ($n=4$) ^a ASPectrum ($n=7$) ^a	yes
WAVEform - (time domain) (all modes)	RFENvelope ($n=2$) ^a IQ ($n=8$) ^a	yes

a. The n number indicates the sub-opcode that corresponds to this trace. Detailed descriptions of the trace data can be found in the MEASure subsystem documentation by looking up the sub-opcode for the appropriate measurement.

Waveform Measurement Y-Axis Reference Level

`:DISPlay:WAVEform[n]:WINDow[m]:TRACe:Y[:SCALE]:RLEVel
<power>`

`:DISPlay:WAVEform[n]:WINDow[m]:TRACe:Y[:SCALE]:RLEVel?`

Sets the amplitude reference level for the y-axis.

n, selects the view, the default is RF envelope.

n=1, RF envelope

n=2, I/Q waveform

m, selects the window within the view. The default is 1.

Factory Preset

and *RST: 0 dBm, for RF envelope

Range: -250 to 250 dBm, for RF envelope

Default Unit: dBm, for RF envelope

Remarks: May affect input attenuator setting.

To use this command, the appropriate mode should be selected with INSTRument:SElect.

Front Panel

Access: When in Waveform measurement: **Amplitude Y Scale,
Ref Level**

FETCh Subsystem

:FETCh: <measurement>[n]?

The FETCh? commands are used with several other commands and are documented in the section on the [“MEASure Group of Commands”](#) on [page 25](#).

MEASure Group of Commands

This group includes commands used to make measurements and return results. The different commands can be used to provide fine control of the overall measurement process. Most measurements should be done in single measurement mode, rather than doing the measurement continuously.

Each measurement sets the instrument state that is appropriate for that measurement. Other commands are available for each **Mode** to allow changing settings, view, limits, etc. Refer to:

SENSE:<measurement>, SENSE:CHANnel, SENSE:CORRection,
SENSE:FREQuency, SENSE:POWEr, SENSE:RADio, SENSE:SNYC
CALCulate:<measurement>, CALCulate:CLIMits/DATA
DISPlay:<measurement>
TRIGger

Measure Commands

:MEASure : <measurement> [n] ?

This is a fast single-command way to make a measurement using the factory default instrument settings. These are the settings and units that conform to the Standard.

- Stops the current measurement and sets up the instrument for the specified measurement using the factory defaults
- Initiates the data acquisition for the measurement
- Blocks other SCPI communication, waiting until the measurement is complete before returning results.
- After the data is valid it returns the scalar results, or the trace data, for the specified measurement.

If the optional [n] value is not included, or is set to 1, the scalar measurement results will be returned. If the [n] value is set to a value other than 1, the selected trace data results will be returned. See each command for details of what types of scalar results or trace data results are available. The binary data formats should be used for handling large blocks of data since they are smaller and faster than the ASCII format.


If you need to change some of the measurement parameters from the factory default settings you can set up the measurement with the CONFigure command. Use the commands in the SENSE:<measurement> and CALCulate:<measurement> subsystems to change the settings. Then you can use the READ? command, or the INITiate and FETCh? commands, to initiate the measurement and

query the results. See [Figure 1-1](#).

If you need to repeatedly make a given measurement with settings other than the factory defaults, you can use the commands in the SENSE:<measurement> and CALCulate:<measurement> subsystems to set up the measurement. Then use the READ? command or INITiate and FETCh? commands, to initiate the measurement and query results.

Measurement settings persist if you initiate a different measurement and then return to a previous one. Use READ:<measurement>? if you want to use those persistent settings. If you want to go back to the default settings, use MEASure:<measurement>?.

Figure 1-1 Measurement Group of Commands



Configure Commands

:CONFigure:<measurement>

This command sets up the instrument for the specified measurement using the factory default instrument settings and stops the current measurement. It does not initiate the taking of measurement data.

The CONFigure? query returns the current measurement name.

Fetch Commands

:FETCh:<measurement>[n]?

This command puts valid data into the output buffer, but does not initiate data acquisition. Use the INITiate[:IMMEDIATE] command to acquire data before you use the FETCh command. You can only fetch results from the measurement that is currently selected.

If the optional [n] value is not included, or is set to 1, the scalar measurement results will be returned. If the [n] value is set to a value

other than 1, the selected trace data results will be returned. See each command for details of what types of scalar results or trace data results are available. The binary data formats should be used for handling large blocks of data since they are smaller and faster than the ASCII format.

Read Commands

:READ:<measurement>[n]?

- Does not preset the measurement to the factory defaults. (The MEASure? command does preset.) It uses the settings from the last measurement.
- Initiates the measurement and puts valid data into the output buffer. If a measurement other than the current one is specified, the instrument will switch to that measurement before it initiates the measurement and returns results.
- Blocks other SCPI communication, waiting until the measurement is complete before returning the results

If the optional [n] value is not included, or is set to 1, the scalar measurement results will be returned. If the [n] value is set to a value other than 1, the selected trace data results will be returned. See each command for details of what types of scalar results or trace data results are available. The binary data formats should be used when handling large blocks of data since they are smaller and faster than the ASCII format.

Measurement settings persist if you initiate a different measurement and then return to a previous one. Use READ:<measurement>? if you want to use those persistent settings. If you want to go back to the default settings, use MEASure:<measurement>?.

Adjacent Channel Power Ratio (ACP) Measurement

This measures the total rms power in the specified channel and in 5 offset channels. You must be in Basic, cdmaOne, cdma2000, W-CDMA, iDEN, NADC or PDC mode to use these commands. Use INSTRument:SElect to set the mode.

The general functionality of CONFigure, FETCh, MEASure, and READ are described at the beginning of this section. See the SENSE:ACP commands for more measurement related commands.

:CONFigure:ACP

:FETCh:ACP[n]?

:READ:ACP[n]?

:MEASure:ACP[n]?

For Basic mode, a channel frequency and power level can be defined in the command statement to override the default standard setting. A comma must precede the power value as a place holder for the frequency, when no frequency is sent.

History: Added to Basic mode, version A.03.00 or later

Front Panel

Access: **Measure, ACPR**

After the measurement is selected, press **Restore Meas Defaults** to restore factory defaults.

Measurement Results Available

Measurement Type	n	Results Returned
	0	Returns unprocessed I/Q trace data, as a series of comma-separated trace points, in volts. The I values are listed first in each pair, using the 0 through even-indexed values. The Q values are the odd-indexed values.

Measurement Type	n	Results Returned
Total power reference	not specified or n=1 cdmaOne, cdma2000, or W-CDMA mode	Returns 24 comma-separated scalar results, in the following order: Center freq - relative power (dB) Center freq - absolute power (dBm) Center freq - relative power (dB) Center freq - absolute power (dBm) Negative offset freq(1) - relative power (dB), Negative offset freq(1) - absolute power (dBm) Positive offset freq(1) - relative power (dB) Positive offset freq(1) - absolute power (dBm) . . . Positive offset freq(5) - relative power (dB) Positive offset freq(5) - absolute power (dBm)
Power spectral density reference	not specified or n=1 cdmaOne, cdma2000, or W-CDMA mode	Returns 24 comma-separated scalar results, in the following order: Center freq - relative power (dB) Center freq - absolute power (dBm/Hz) Center freq - relative power (dB) Center freq - absolute power (dBm/Hz) Negative offset freq(1) - relative power (dB) Negative offset freq(1) - absolute power (dBm/Hz) Positive offset freq(1) - relative power (dB) Positive offset freq(1) - absolute power (dBm/Hz) . . . Positive offset freq(5) - relative power (dB) Positive offset freq(5) - absolute power (dBm/Hz)
Total power reference	2 cdmaOne, cdma2000, or W-CDMA mode	Returns 11 comma-separated scalar values (in dBm) corresponding to the total power histogram display. The values are returned in ascending frequency order: Negative offset frequency(5) Negative offset frequency(4) . . . Center frequency Positive Offset frequency(1) . . . Positive Offset frequency(5)

Measurement Type	n	Results Returned
Power spectral density reference	3 cdmaOne, cdma2000, or W-CDMA mode	Returns 11 comma-separated scalar values (in dBm/Hz) corresponding to the power spectral density histogram display. The values are returned in ascending frequency order: Negative offset frequency(5) Negative offset frequency(4) . . . Center frequency Positive Offset frequency(1) . . . Positive Offset frequency(5)
(For cdma2000 and W-CDMA the data is only available with spectrum display selected)	4 cdmaOne, cdma2000, or W-CDMA mode	Returns the frequency-domain spectrum trace data for the entire frequency range being measured. With spectrum display selected (DISPlay:ACP:VIEW SPEC): <ul style="list-style-type: none"> In FFT mode (SENSE:ACPR:SWEep:TYPE FFT) the number of trace points returned are 343 (cdma2000 SR1), 1029 (cdma2000 SR3) or 1715 (W-CDMA). This is with the default span of 5 MHz (cdma2000 SR1), 15 MHz (cdma2000 SR3), or 25 MHz (W-CDMA). The number of points also varies if another offset frequency is set. In sweep mode (SENSE:ACPR:SWEep:TYPE SWEep), the number of trace points returned is 601 (for cdma2000 or W-CDMA) for any span. With bar graph display selected, one point of -999.0 will be returned.
Total power reference	5 cdmaOne, cdma2000, or W-CDMA mode	Returns 12 comma-separated scalar values (in dBm) of the absolute power of the center and the offset frequencies: Center frequency Center frequency Negative offset frequency(1) Positive offset frequency(1) . . . Negative Offset frequency(5) Positive Offset frequency(5)
Power spectral density reference	5 cdmaOne, cdma2000, or W-CDMA mode	Returns 12 comma-separated scalar values (in dBm/Hz) of the absolute power of the center and the offset frequencies: Center frequency Center frequency Negative offset frequency(1) Positive offset frequency(1) . . . Negative offset frequency(5) Positive offset frequency(5)

Measurement Type	n	Results Returned
Total power reference	6 cdmaOne, cdma2000, or W-CDMA mode	Returns 12 comma-separated scalar values (total power in dB) of the power relative to the carrier at the center and the offset frequencies: Center frequency Center frequency Negative offset frequency(1) Positive offset frequency(1) . . . Negative offset frequency(5) Positive offset frequency(5)
Power spectral density reference	6 cdmaOne, cdma2000, or W-CDMA mode	Returns 12 comma-separated scalar values (power spectral density in dB) of the power relative to the carrier at the center and offset frequencies: Center frequency Center frequency Negative offset frequency(1) Positive offset frequency(1) . . . Negative offset frequency(5) Positive offset frequency(5)
Total power reference	7 cdmaOne, cdma2000, or W-CDMA mode	Returns 12 comma-separated scalar values of the pass/fail (1=passed, or 0=failed) results determined by testing the absolute power limit of the center and offset frequencies (measured as total power in dB): Center frequency Center frequency Negative offset frequency(1) Positive offset frequency(1) . . . Negative offset frequency(5) Positive offset frequency(5)
Power spectral density reference	7 cdmaOne, cdma2000, or W-CDMA mode	Returns 12 comma-separated scalar values of the pass/fail (1=passed, or 0=failed) results determined by testing the absolute power limit of the center and offset frequencies (measured as power spectral density in dB): Center frequency Center frequency Negative offset frequency(1) Positive offset frequency(1) . . . Negative offset frequency(5) Positive Offset frequency(5)

Measurement Type	n	Results Returned
Total power reference	8 cdmaOne, cdma2000, or W-CDMA mode	Returns 12 comma-separated scalar values of the pass/fail (1=passed, or 0=failed) results determined by testing the power limit relative to the center frequency (measured as total power spectral in dB): Center frequency Center frequency Negative offset frequency(1) Positive offset frequency(1) . . . Negative offset frequency(5) Positive Offset frequency(5)
Power spectral density reference	8 cdmaOne, cdma2000, or W-CDMA mode	Returns 12 comma-separated scalar values of the pass/fail (1=passed, or 0=failed) results determined by testing the power limit relative to the center frequency (measured as power spectral density in dB): Center frequency Center frequency Negative offset frequency(1) Positive offset frequency(1) . . . Negative offset frequency(5) Positive Offset frequency(5)

Code Domain Power Measurement

This measures the power for each of the 64 Walsh codes/channels, relative to the total power in the pilot channel. You must be in the cdmaOne or W-CDMA mode to use these commands. Use INSTRument:SElect to set the mode.

The general functionality of CONFigure, FETCh, MEASure, and READ are described at the beginning of this section. See the SENSE:CDPower commands for more measurement related commands.

:CONFigure:CDPower

:FETCh:CDPower[n]?

:READ:CDPower[n]?

:MEASure:CDPower[n]?

Front Panel

Access: **Measure, Code Domain Power**

After the measurement is selected, press **Restore Meas Defaults** to restore factory defaults.

Measurement Results Available

n	Results Returned
0	Returns unprocessed I/Q trace data, as a series of comma-separated trace points, in volts. The I values are listed first in each pair, using the 0 through even-indexed values. The Q values are the odd-indexed values.

n	Results Returned
not specified or n=1 cdmaOne mode	<p>Returns the following 25 comma-separated scalar results:</p> <ol style="list-style-type: none"> 1. Time offset is a floating point number with units of seconds. This is the time delay of the even second clock with respect to the start of the short code PN sequences, at offsets from the 15 zeros in the characteristic phase of the sequences. 2. Frequency error is a floating point number (in Hz) of the frequency error in the measured signal. This error is based on the linear best fit of the uncorrected measured phase. 3. Carrier feedthrough is a floating point number (in dB) of the dc offset, of I and Q, from the origin. 4. Pilot power is a floating point number with units of dB. It is the relative power of the pilot channel (Walsh code 0) with respect to the carrier power. 5. Paging power is a floating point number with units of dB. It is the relative power of the paging channel (Walsh code 1) with respect to the carrier power. 6. Sync power is a floating point number with units of dB. It is the relative power of the sync channel (Walsh code 32) with respect to the carrier power. 7. Average traffic power is a floating point number with units of dB. It is the average relative power of the active traffic channels with respect to the carrier power. Traffic channels are defined as all of the Walsh codes except Walsh 0,1,32. A traffic channel is active if its coding power is greater than the active threshold parameter which you have selected. 8. Maximum inactive traffic power is a floating point number with units of dB. It is the maximum relative power of an inactive traffic channel with respect to the carrier power. Traffic channels are defined as all of the Walsh codes except Walsh 0,1,32. A traffic channel is inactive if its coding power is less than the active threshold parameter which you have selected. 9. Average inactive traffic power is a floating point number with units of dB. It is the average relative power of the inactive traffic channels with respect to the carrier power. Traffic channels are defined as all of the Walsh codes except Walsh 0,1,32. A traffic channel is inactive if its coding power is less than the active threshold parameter which you have selected. 10. Marker Values The last 16 measurement results are the current values for all four available markers. The values are zero for any marker that is not active. <ol style="list-style-type: none"> 10. Marker 1 position (code number) 11. Marker 1 power level 12. Marker 1 time value 13. Marker 1 phase value . . . 25. Marker 4 phase value

n	Results Returned
2 cdmaOne mode	Returns comma-separated floating point numbers that are the trace data of the code domain <i>power</i> trace for all 64 Walsh codes. This series of 64 numbers represent the relative power levels (in dB) of all 64 walsh codes, with respect to the carrier power.
3 cdmaOne mode	Returns comma-separated floating point numbers that are the trace data of the code domain <i>timing</i> trace for all 64 Walsh codes. This series of 64 numbers represent the relative timing estimations (in seconds) of the codes, relative to the pilot channel. Typical values are on the order of 1 ns.
4 cdmaOne mode	Returns comma-separated floating point numbers that are the trace data of the code domain <i>phase</i> trace for all 64 Walsh codes. This series of 64 numbers represent the relative phase estimations (in radians) of the codes, relative to the pilot channel. Typical values are on the order of 1 mrad.

Channel Power Measurement

This measures the total rms power in a specified integration bandwidth. You must be in the Basic, cdmaOne mode to use these commands. Use INSTRument:SElect to set the mode.

The general functionality of CONFigure, FETCh, MEASure, and READ are described at the beginning of this section. See the SENSE:CHPower commands for more measurement related commands.

:CONFigure:CHPower

:FETCh:CHPower[n]?

:READ:CHPower[n]?

:MEASure:CHPower[n]?

History: Added to Basic mode, version A.03.00 or later

Front Panel

Access: **Measure, Channel Power**

After the measurement is selected, press **Restore Meas Defaults** to restore factory defaults.

Measurement Results Available

n	Results Returned
0	Returns unprocessed I/Q trace data, as a series of comma-separated trace points, in volts. The I values are listed first in each pair, using the 0 through even-indexed values. The Q values are the odd-indexed values.
not specified or n=1	Returns 2 comma-separated scalar results: 1. Channel power is a floating point number representing the total channel power in the specified integration bandwidth. 2. PSD (Power Spectral Density) is the power (in dBm/Hz) in the specified integration bandwidth.
2	Returns comma-separated floating point numbers that are the captured trace data of the power (in dBm/resolution BW) of the signal. The frequency span of the captured trace data is specified by the Span key.

Close Spurs Measurement

This measures the spurious emissions in the transmit band relative to the channel power in the selected channel. You must be in the cdmaOne mode to use these commands. Use INSTRument:SElect to set the mode.

The general functionality of CONFigure, FETCh, MEASure, and READ are described at the beginning of this section. See the SENSE:CSPur commands for more measurement related commands.

:CONFigure:CSPur

:FETCh:CSPur[n]?

:READ:CSPur[n]?

:MEASure:CSPur[n]?

Front Panel

Access: **Measure, Spur Close**

After the measurement is selected, press **Restore Meas Defaults** to restore factory defaults.

Measurement Results Available

n	Results Returned
0	Returns unprocessed I/Q trace data, as a series of comma-separated trace points, in volts. The I values are listed first in each pair, using the 0 through even-indexed values. The Q values are the odd-indexed values.
not specified or n=1	Returns 3 comma-separated scalar results: <ol style="list-style-type: none">1. The worst spur's frequency difference from channel center frequency (in MHz)2. The worst spur's amplitude difference from the limit (in dB)3. The worst spur's amplitude difference from channel power (in dB)
2	Returns trace of the segment containing the worst spur.

Rho (Waveform Quality) Measurement

This measures the modulation accuracy of the transmitter by checking the magnitude and phase error and the EVM (error vector magnitude). You must be in the cdmaOne, cdma2000, or W-CDMA mode to use these commands. Use INSTRument:SElect to set the mode.

The general functionality of CONFigure, FETCh, MEASure, and READ are described at the beginning of this section. See the SENSE:RHO commands for more measurement related commands.

:CONFigure:RHO

:FETCh:RHO[n]?

:READ:RHO[n]?

:MEASure:RHO[n]?

Front Panel

Access: **Measure, Mod Accuracy (Rho)**

After the measurement is selected, press **Restore Meas Defaults** to restore factory defaults.

Measurement Results Available

n	Results Returned
0	<p>Returns unprocessed I/Q trace data, as a series of comma-separated trace points. The I values are listed first in each pair, using the 0 through even-indexed values. The Q values are the odd-indexed values.</p> <p>The standard sample rate is 7.5 MHz and the trace length is determined by the current measurement interval.</p>

n	Results Returned
not specified or n=1 cdmaOne mode	<p>Returns 7 comma-separated floating point numbers, in the following order:</p> <ol style="list-style-type: none"> 1. Rho (no units) represents the correlation of the measured power compared to the ideal pilot channel. The calculation is performed after the complimentary filter, so it is IS95 compliant. It is performed at the decision points in the pilot waveform. If averaging is on, this is the average of the individual rms measurements. 2. Time offset (with units of seconds) is the time delay of the even second clock with respect to the start of the short code PN sequences, at offsets from the 15 zeros in the characteristic phase of the sequence. 3. Frequency error of the measured signal, with units of Hz. This is based on the linear best fit of the uncorrected measured phase. 4. Carrier feedthrough has units of dB and is the dc error offset of I and Q, from the origin. 5. EVM has units of percent. The calculation is based on the composite of the phase error and magnitude error, between the measured signal and the ideal pilot channel. It is performed after the complimentary filter which removes the inter-symbol interference in the modulated data. If averaging is on, this is the average of the individual rms measurements. 6. Magnitude error (with units of percent) is the rms error between the measured (compensated) magnitude and the ideal magnitude. This is performed after the complimentary filter which removes the inter-symbol interference in the modulated data. If averaging is on, this is the average of the individual rms measurements. 7. Phase error (with units in percent) is the rms phase error between the measured phase and the ideal phase. The calculation is performed after the complimentary filter which removes the inter-symbol interference in the modulated data. If averaging is on, this is the average of the individual rms measurements.
2	<p>EVM Trace – returns error vector magnitude (EVM) data, as comma-separated trace points in percent. The first value is the chip 0 decision point. The trace is interpolated for the currently selected points/chips displayed on the front panel. The number of trace points depends on the current measurement interval setting.</p>
3	<p>Magnitude Error Trace – returns magnitude error data, as comma-separated trace points, in percent. The first value is the chip 0 decision point. The trace is interpolated for the currently selected points/chips displayed on the front panel. The number of trace points depends on the current measurement interval setting.</p>
4 cdmaOne mode	<p>Phase Error Trace – returns phase error data, as comma-separated trace points, in degrees. The first value is the symbol 0 decision point. The trace is interpolated for the currently selected chips/symbol displayed on the front panel. The number of trace points depends on the current measurement interval setting.</p>

n	Results Returned
<p>5 cdmaOne mode</p>	<p>Corrected Measured Data – returns a series of floating point numbers that alternately represent I and Q pairs of the corrected measured trace data. The magnitude of each I and Q pair are normalized to 1.0.</p> <p>The number of trace points depends on the current measurement interval setting.</p> <p>The numbers are sent in the following order:</p> <p style="padding-left: 40px;">In-phase (I) sample, of symbol 0 decision point Quadrature-phase (Q) sample, of symbol 0 decision point ... In-phase (I) sample, of symbol 1 decision point Quadrature-phase (Q) sample, of symbol 1 decision point ...</p> <p>The trace can be interpolated to 2,4,8 points/chip selected with the display Points/Chip softkey. This will change the number of points between decision points in the trace, changing the number of I/Q pairs sent for each decision point.</p>
<p>6</p>	<p>Reference IQ Data – returns a series of floating point numbers that alternately represent I and Q pairs of the reference trace data.</p> <p>The number of trace points depends on the current measurement interval setting.</p> <p>The numbers are sent in the following order:</p> <p style="padding-left: 40px;">In-phase (I) sample, of symbol 0 decision point Quadrature-phase (Q) sample, of symbol 0 decision point ... In-phase (I) sample, of symbol 1 decision point Quadrature-phase (Q) sample, of symbol 1 decision point ...</p> <p>The trace can be interpolated to 2,4,8 points/chip selected with the display Points/Chip softkey.</p>

n	Results Returned
<p>7 cdmaOne mode</p>	<p>Complimentary Filtered Measured Data – returns a series of floating point numbers that alternately represent I and Q pairs of the complimentary filtered measured data. This is inverse filtered data of the inter-symbol interference in CDMA signals due to the digital transmission filters defined in the standard as well as the base station phase equalization filter.</p> <p>The number of trace points depends on the current measurement interval setting.</p> <p>The numbers are sent in the following order:</p> <p style="padding-left: 40px;">In-phase (I) sample, of symbol 0 decision point Quadrature-phase (Q) sample, of symbol 0 decision point ... In-phase (I) sample, of symbol 1 decision point Quadrature-phase (Q) sample, of symbol 1 decision point ...</p> <p>The trace can be interpolated to 2,4,8 points/chip selected with the display Points/Chip softkey. This will change the number of points between decision points in the trace, changing the number of I/Q pairs sent for each decision point.</p>
<p>8 cdmaOne mode</p>	<p>Complimentary Filtered Reference Data – returns a series of floating point numbers that alternately represent I and Q pairs of the complimentary filtered reference data. This is inverse filtered data of the inter-symbol interference in CDMA signals due to the digital transmission filters defined in the standard as well as the base station phase equalization filter.</p> <p>The number of trace points depends on the current measurement interval setting.</p> <p>The numbers are sent in the following order:</p> <p style="padding-left: 40px;">In-phase (I) sample, of symbol 0 decision point Quadrature-phase (Q) sample, of symbol 0 decision point ... In-phase (I) sample, of symbol 1 decision point Quadrature-phase (Q) sample, of symbol 1 decision point ...</p> <p>The trace can be interpolated to 2,4,8 points/chip selected with the display Points/Chip softkey. This will change the number of points between decision points in the trace, changing the number of I/Q pairs sent for each decision point.</p>

n	Results Returned
<p>11 cdmaOne mode</p>	<p>Corrected Measured Data – returns a series of floating point numbers that alternately represent I and Q pairs of the corrected measured trace data. The magnitude of each I and Q pair are normalized to 1.0.</p> <p>The number of trace points depends on the current setting for the number of displayed I/Q points in the I/Q display.</p> <p>The numbers are sent in the following order:</p> <p style="padding-left: 40px;">In-phase (I) sample, of symbol 0 decision point Quadrature-phase (Q) sample, of symbol 0 decision point ... In-phase (I) sample, of symbol 1 decision point Quadrature-phase (Q) sample, of symbol 1 decision point ...</p> <p>The trace can be interpolated to 2,4,8 points/chip selected with the display Points/Chip softkey. This will change the number of points between decision points in the trace, changing the number of I/Q pairs sent for each decision point.</p>
<p>13 cdmaOne mode</p>	<p>Complimentary Filtered Measured Data – returns a series of floating point numbers that alternately represent I and Q pairs of the complimentary filtered measured data. This is inverse filtered data of the inter-symbol interference in CDMA signals due to the digital transmission filters defined in the standard as well as the base station phase equalization filter.</p> <p>The number of trace points depends on the current setting for the number of displayed I/Q points in the I/Q display.</p> <p>The numbers are sent in the following order:</p> <p style="padding-left: 40px;">In-phase (I) sample, of symbol 0 decision point Quadrature-phase (Q) sample, of symbol 0 decision point ... In-phase (I) sample, of symbol 1 decision point Quadrature-phase (Q) sample, of symbol 1 decision point ...</p> <p>The trace can be interpolated to 2,4,8 points/chip selected with the display Points/Chip softkey. This will change the number of points between decision points in the trace, changing the number of I/Q pairs sent for each decision point.</p>

Spectrum (Frequency Domain) Measurement

This measures the amplitude of your input signal with respect to the frequency. It provides spectrum analysis capability using FFT (fast Fourier transform) measurement techniques. You must select the appropriate mode using INSTRument:SElect, to use these commands.

The general functionality of CONFigure, FETCh, MEASure, and READ are described at the beginning of this section. See the SENSE:SPECTrum commands for more measurement related commands.

:CONFigure:SPECTrum

:FETCh:SPECTrum[n]?

:READ:SPECTrum[n]?

:MEASure:SPECTrum[n]?

Front Panel

Access: **Measure, Spectrum (Freq Domain)**

After the measurement is selected, press **Restore Meas Defaults** to restore factory defaults.

Measurement Results Available

n	Results Returned
0	Returns unprocessed I/Q trace data, as a series of comma-separated trace points, in volts. The I values are listed first in each pair, using the 0 through even-indexed values. The Q values are the odd-indexed values.

n	Results Returned
not specified or n=1	<p>Returns the following comma-separated scalar results:</p> <ol style="list-style-type: none"> 1. FFT peak is the FFT peak amplitude. 2. FFT frequency is the FFT frequency of the peak amplitude. 3. FFT points is the Number of points in the FFT spectrum. 4. First FFT frequency is the frequency of the first FFT point of the spectrum. 5. FFT spacing is the frequency spacing between the FFT points of the spectrum. 6. Time domain points is the number of points in the time domain trace used for the FFT. 7. First time point is the time of the first time domain point, where time zero is the trigger event. 8. Time spacing is the time spacing between the time domain points. 9. Time domain returns a 1, if time domain is complex (I/Q), or 0 if it is real. (raw ADC samples) 10. Scan time is the total scan time of the time domain trace used for the FFT The total scantime = (time spacing) x (time domain points – 1) 11. Current average count is the current number of data measurements that have already been combined, in the averaging calculation.
2, Service mode only	Returns the trace data of the log-magnitude versus time. (That is, the RF envelope.)
3	Returns the I and Q trace data. It is represented by I and Q pairs (in volts) versus time.
4	Returns spectrum trace data. That is, the trace of log-magnitude versus frequency. (The trace is computed using a FFT.)
5, Service mode only	Returns the averaged trace data of log-magnitude versus time. (That is, the RF envelope.)
6	Not used.
7	Returns the averaged spectrum trace data. That is, the trace of the averaged log-magnitude versus frequency.
8	Not used.
9, Service mode only	Returns a trace containing the shape of the FFT window.
10, Service mode only	Returns trace data of the phase of the FFT versus frequency.

Waveform (Time Domain) Measurement

This measures the power in your input signal with respect to time and is equivalent to zero-span operation in a traditional spectrum analyzer. You must select the appropriate mode using INSTRUMENT:SElect, to use these commands.

The general functionality of CONFigure, FETCh, MEASure, and READ are described at the beginning of this section. See the SENSE:WAVEform commands for more measurement related commands.

:CONFigure:WAVEform

:FETCh:WAVEform[n]?

:READ:WAVEform[n]?

:MEASure:WAVEform[n]?

Front Panel

Access: **Measure, Waveform (Time Domain)**

After the measurement is selected, press **Restore Meas Defaults** to restore factory defaults.

Measurement Results Available

n	Results Returned
0	Returns unprocessed I/Q trace data, as a series of comma-separated trace points, in volts. The I values are listed first in each pair, using the 0 through even-indexed values. The Q values are the odd-indexed values.

n	Results Returned
not specified or n=1	<p>Returns the following comma-separated scalar results:</p> <ol style="list-style-type: none"> 1. Sample time is a floating point number representing the time between samples when using the trace queries (n=0,2,etc). 2. Mean power is the mean power (in dBm). This is either the power across the entire trace, or the power between markers if the markers are enabled. If averaging is on, the power is for the latest acquisition. 3. Mean power averaged is the power (in dBm) for N averages, if averaging is on. This is either the power across the entire trace, or the power between markers if the markers are enabled. If averaging is on, the power is for the latest acquisition. If averaging is off, the value of the mean power averaged is the same as the value of the mean power. 4. Number of samples is the number of data points in the captured signal. This number is useful when performing a query on the signal (i.e. when n=0,2,etc.). 5. Peak-to-mean ratio has units of dB. This is the ratio of the maximum signal level to the mean power. Valid values are only obtained with averaging turned off. If averaging is on, the peak-to-mean ratio is calculated using the highest peak value, rather than the displayed average peak value. 6. Maximum value is the maximum of the most recently acquired data (in dBm). 7. Minimum value is the minimum of the most recently acquired data (in dBm).
2	<p>Returns comma-separated trace points of the entire captured trace data. These data points are floating point numbers representing the power of the signal (in dBm). There are N data points, where N is the number of samples. The period between the samples is defined by the sample time.</p>

READ Subsystem

`:READ:<measurement>[n]?`

The READ? commands are used with several other commands and are documented in the section on the “MEASure Group of Commands” on [page 25](#).

SENSe Subsystem

Sets the instrument state parameters so that you can measure the input signal.

Adjacent Channel Power Measurement

Commands for querying the adjacent channel power measurement results and for setting to the default values are found in the [“MEASure Group of Commands” on page 25](#). The equivalent front panel keys for the parameters described in the following commands, are found under the **Meas Setup** key, after the **ACP** measurement has been selected from the **MEASURE** key menu.

Adjacent Channel Power Measurement Average Count

```
[ :SENSe ] :ACP :AVERAge :COUNT <integer>
```

```
[ :SENSe ] :ACP :AVERAge :COUNT ?
```

Set the number of data acquisitions that will be averaged. After the specified number of average counts, the average mode (termination control) setting determines the average action.

Factory Preset

and *RST: 10, for cdma2000, W-CDMA mode

20, for Basic, cdmaOne, iDEN mode

Range: 1 to 10,000

Remarks: Use INSTRument:SElect to set the mode.

Adjacent Channel Power Measurement Averaging State

```
[ :SENSe ] :ACP :AVERAge [ :STATe ] OFF | ON | 0 | 1
```

```
[ :SENSe ] :ACP :AVERAge [ :STATe ] ?
```

Turn average on or off.

Factory Preset

and *RST: On

Off, for iDEN mode

Remarks: Use INSTRument:SElect to set the mode.

Adjacent Channel Power Measurement Averaging Termination Control

```
[ :SENSe ]:ACP:AVERAge:TCONTRol EXPOnential|REPeat
```

```
[ :SENSe ]:ACP:AVERAge:TCONTRol?
```

Select the type of termination control used for averaging. This determines the averaging action after the specified number of data acquisitions (average count) is reached.

Exponential – Each successive data acquisition after the average count is reached, is exponentially weighted and combined with the existing average.

Repeat – After reaching the average count, the averaging is reset and a new average is started.

Factory Preset

and *RST: Repeat, for basic, cdmaOne, cdma2000, W-CDMA mode
Exponential, for NADC, PDC, iDEN mode

Remarks: Use INSTRument:SElect to set the mode.

Adjacent Channel Power Measurement Channel Integration BW

Basic, iDEN mode

```
[ :SENSe ]:ACP:BANDwidth|BWIDth:INTEgration <freq>
```

```
[ :SENSe ]:ACP:BANDwidth|BWIDth:INTEgration?
```

cdmaOne, cdma2000, W-CMDA mode

```
[ :SENSe ]:ACP:BANDwidth|BWIDth[n]:INTEgration[n] <freq>
```

```
[ :SENSe ]:ACP:BANDwidth|BWIDth[n]:INTEgration[n]?
```

Set the Integration bandwidth that will be used for the main (carrier) channel.

cdmaOne mode

Bandwidth [n] - Where 1 is base station and 2 is mobiles. The default is base station (1).

Integration [n] - Where 1 is cellular bands and 2 is pcs bands. The default is cellular (1).

cdma2000 mode

Bandwidth [n] - Where 1 is base station and 2 is mobiles. The default is base station (1).

Integration [n] - Where 1 is SR1, 2 is SR3 DS, and 3 is SR3 MC. The default is SR1 (1).

W-CDMA mode

Bandwidth [n] - Where 1 is base station and 2 is mobiles. The default is base station (1).

Integration [n] - Where 1 is ARIB, 2 is 3GPP, and 3 is Trial. The default is ARIB (1).

Factory Preset
and *RST:

Mode	Format (Modulation Standard)		
	Basic	1.23 MHz	
cdmaOne	1.23 MHz		
iDEN	18 kHz		
cdma2000	SR1 (n=1)	SR3 DC (n=2)	SR3 MC (n=3)
	1.23 MHz	3.69 MHz	3.69 MHz
W-CDMA	ARIB (n=1)	3GPP (n=2)	Trial (n=3)
	4.069 MHz	3.84 MHz	4.096 MHz

Range: 300 Hz to 20 MHz for Basic, cdmaOne, cdma2000, W-CDMA mode

1 kHz to 5 MHz for iDEN

Default Unit: Hz

Remarks: With measurement type set at (TPR) total power reference, 1.40 MHz is sometimes used. Using 1.23 MHz will give a power that is very nearly identical to the 1.40 MHz value, and using 1.23 MHz will also yield the correct power spectral density with measurement type set at (PSD) reference. However, a setting of 1.40 MHz will not give the correct results with measurement type set at PSD reference.

You must be in Basic, cdmaOne, cdma2000, W-CDMA, iDEN mode to use this command. Use INSTRUMENT:SElect to set the mode.

Adjacent Channel Power Measurement Absolute Amplitude Limits

iDEN mode

```
[ :SENSe ]:ACP:OFFSet:ABSolute <power>
```

```
[ :SENSe ]:ACP:OFFSet:ABSolute?
```

Basic mode

```
[ :SENSe ]:ACP:OFFSet:LIST:ABSolute <power>{ ,<power> }
```

```
[ :SENSe ]:ACP:OFFSet:LIST:ABSolute?
```

cdmaOne, cdma2000, W-CDMA mode

```
[ :SENSe ]:ACP:OFFSet[n]:LIST[n]:ABSolute <power>{ ,<power> }
```

```
[ :SENSe ]:ACP:OFFSet[n]:LIST[n]:ABSolute?
```

Sets the absolute amplitude levels to test against for each of the custom offsets. The list contains five (5) entries. If there is more than one offset, the offset closest to the carrier channel is the first one in the list.

ACP:OFFS[n]:LIST[n]:TEST selects the type of testing to be done at each offset.

The query returns five (5) real numbers that are the current absolute amplitude test limits.

cdmaOne mode

Offset [n] - Where 1 is base station and 2 is mobiles. The default is base station (1).

List [n] - Where 1 is cellular bands and 2 is pcs bands. The default is cellular.

cdma2000 mode

Offset [n] - Where 1 is base station and 2 is mobiles. The default is base station (1).

List [n] - Where 1 is SR1, 2 is SR3 DS, and 3 is SR3 MC. The default is SR1 (1).

W-CDMA mode

Offset [n] - Where 1 is base station and 2 is mobiles. The default is base station (1).

List [n] - Where 1 is ARIB, 2 is 3GPP, and 3 is Trial. The default is ARIB (1).

Factory Preset and *RST:

	Offset A	Offset B	Offset C	Offset D	Offset E
Basic					
	0 dBm	0 dBm	0 dBm	0 dBm	0 dBm
cdmaOne					
BS cellular	0 dBm	0 dBm	0 dBm	0 dBm	0 dBm
BS pcs	0 dBm	-13 dBm	-13 dBm	0 dBm	0 dBm
MS cellular	0 dBm	0 dBm	0 dBm	0 dBm	0 dBm
MS pcs	0 dBm	-13 dBm	-13 dBm	0 dBm	0 dBm
cdma2000					
	50 dBm	50 dBm	50 dBm	50 dBm	50 dBm
W-CDMA					
	50 dBm	50 dBm	50 dBm	50 dBm	50 dBm
iDEN					
	0 dBm	n/a	n/a	n/a	n/a

Range: -200 dBm to 50 dBm

Default Unit: dBm

Remarks: You must be in Basic, cdmaOne, cdma2000, W-CDMA, iDEN mode to use this command. Use INSTRUMENT:SELEct to set the mode.

Adjacent Channel Power Measurement Define Resolution Bandwidth List

iDEN mode

```
[ :SENSe ] :ACP :OFFSet :BANDwidth | BWIDth <res_bw>
```

```
[ :SENSe ] :ACP :OFFSet :BANDwidth | BWIDth ?
```

Basic mode

```
[ :SENSe ] :ACP :OFFSet :LIST :BANDwidth | BWIDth  
<res_bw> { , <res_bw> }
```

```
[ :SENSe ] :ACP :OFFSet :LIST :BANDwidth | BWIDth ?
```

cdmaOne, cdma2000, W-CDMA mode

```
[ :SENSe ] :ACP :OFFSet [n] :LIST [n] :BANDwidth | BWIDth  
<res_bw> { , <res_bw> }
```

```
[ :SENSe ] :ACP :OFFSet [n] :LIST [n] :BANDwidth | BWIDth ?
```

Define the custom resolution bandwidth(s) for the adjacent channel power testing. If there is more than one bandwidth, the list contains five (5) entries. Each resolution bandwidth in the list corresponds to an offset frequency in the list defined by ACP:OFFSet[n]:LIST[n][:FREQ.

cdmaOne mode

Offset [n] - Where 1 is base station and 2 is mobiles. The default is base station (1).

List [n] - Where 1 is cellular bands and 2 is pcs bands. The default is cellular.

cdma2000 mode

Offset [n] - Where 1 is base station and 2 is mobiles. The default is base station (1).

List [n] - Where 1 is SR1, 2 is SR3 DS, and 3 is SR3 MC. The default is SR1 (1).

W-CDMA mode

Offset [n] - Where 1 is base station and 2 is mobiles. The default is base station (1).

List [n] - Where 1 is ARIB, 2 is 3GPP, and 3 is Trial. The default is ARIB (1).

Factory Preset

and *RST:

	Offset A	Offset B	Offset C	Offset D	Offset E
iDEN					
	10 kHz	n/a	n/a	n/a	n/a
Basic					
	30 kHz	30 kHz	30 kHz	30 kHz	30 kHz
cdmaOne					
BS cellular	30 kHz	30 kHz	30 kHz	30 kHz	30 kHz
BS pcs	30 kHz	12.5 kHz	1 MHz	30 kHz	30 kHz
MS cellular	30 kHz	30 kHz	30 kHz	30 kHz	30 kHz
MS pcs	30 kHz	12.5 kHz	1 MHz	30 kHz	30 kHz
cdma2000					
	30 kHz	30 kHz	30 kHz	30 kHz	30 kHz
W-CDMA					
Trial and ARIB	4.096 MHz	4.096 MHz	4.096 MHz	4.096 MHz	4.096 MHz
3GPP	3.84 MHz	3.84 MHz	3.84 MHz	3.84 MHz	3.84 MHz

Range: 300 Hz to 20 MHz for cdmaOne, Basic, cdma2000, W-CDMA mode

1 kHz to 5 MHz for iDEN mode

Default Unit: Hz

Remarks: You must be in Basic, cdmaOne, cdma2000, W-CDMA, iDEN mode to use this command. Use INSTRUMENT:SElect to set the mode.

Adjacent Channel Power Measurement Define Offset Frequency List

iDEN mode

```
[ :SENSe ] :ACP :OFFSet [ :FREQuency ] <offset_freq>
```

```
[ :SENSe ] :ACP :OFFSet [ :FREQuency ] ?
```

Basic mode

```
[ :SENSe ] :ACP :OFFSet :LIST [ :FREQuency ]
```

```
<offset_freq> { , <offset_freq> }
```

```
[ :SENSe ] :ACP :OFFSet :LIST [ :FREQuency ] ?
```

cdmaOne, cdma2000, W-CDMA mode

```
[ :SENSe ] :ACP :OFFSet [ n ] :LIST [ n ] [ :FREQuency ]
```

```
<offset_freq> { , <offset_freq> }
```

```
[ :SENSe ] :ACP :OFFSet [ n ] :LIST [ n ] [ :FREQuency ] ?
```

Define the custom set of offset frequencies at which the switching transient spectrum part of the ACP measurement will be made. The list contains five (5) entries for offset frequencies. Each offset frequency in the list corresponds to a resolution bandwidth in the bandwidth list. An offset frequency of zero turns “off” the measurement for that offset.

cdmaOne mode

Offset [n] - Where 1 is base station and 2 is mobiles. The default is base station (1).

List [n] - Where 1 is cellular frequency bands and 2 is pcs frequency bands. The default is cellular bands (1).

cdma2000 mode

Offset [n] - Where 1 is base station and 2 is mobiles. The default is base station (1).

List [n] - Where 1 is SR1, 2 is SR3 DS, and 3 is SR3 MC. The default is SR1 (1).

W-CDMA mode

Offset [n] - Where 1 is base station and 2 is mobiles. The default is base station (1).

List [n] - Where 1 is ARIB, 2 is 3GPP, and 3 is Trial. The default is ARIB (1).

Factory Preset

and *RST:

	Offset A	Offset B	Offset C	Offset D	Offset E
iDEN					
	25 kHz	n/a	n/a	n/a	n/a
Basic					
	750 kHz	1.98 MHz	0 Hz	0 Hz	0 Hz
cdmaOne					
BS cellular	750 kHz	1.98 MHz	0 Hz	0 Hz	0 Hz
BS pcs	885 kHz	1.25625 MHz	2.75 MHz	0 Hz	0 Hz
MS cellular	885 kHz	1.98 MHz	0 Hz	0 Hz	0 Hz
MS pcs	885 kHz	1.25625 MHz	2.75 MHz	0 Hz	0 Hz
cdma2000					
BTS SR1	750 kHz	1.98 MHz	0 Hz	0 Hz	0 Hz
BTS SR3 DS	2.655 MHz	3.75 MHz	0 Hz	0 Hz	0 Hz
BTS SR3 MC	2.135 kHz	2.5 MHz	0 Hz	0 Hz	0 Hz
MS SR1	885 kHz	1.98 MHz	0 Hz	0 Hz	0 Hz
MS SR3 DS	2.655 MHz	3.75 MHz	0 Hz	0 Hz	0 Hz
MS SR3 MC	2.655 kHz	3.75 MHz	0 Hz	0 Hz	0 Hz
W-CDMA					
	5 MHz	10 MHz	15 MHz	20 MHz	25 MHz

Range: 0 Hz to 20 MHz for iDEN, Basic mode
 0 Hz to 45 MHz for cdmaOne mode
 0 Hz to 100 MHz for cdma2000, W-CDMA mode

Default Unit: Hz

Remarks: You must be in Basic, cdmaOne, cdma2000, W-CDMA, iDEN mode to use this command. Use INSTRUMENT:SElect to set the mode.

Adjacent Channel Power Measurement Amplitude Limits Relative to the Carrier

iDEN mode

```
[ :SENSe ]:ACP:OFFSet:RCARrier <rel_power>
```

```
[ :SENSe ]:ACP:OFFSet:RCARrier?
```

Basic mode

```
[ :SENSe ]:ACP:OFFSet:LIST:RCARrier <rel_power>{,<rel_power>}
```

```
[ :SENSe ]:ACP:OFFSet:LIST:RCARrier?
```

cdmaOne, cdma2000, W-CDMA mode

```
[ :SENSe ]:ACP:OFFSet[n]:LIST[n]:RCARrier  
<rel_power>{,<rel_power>}
```

```
[ :SENSe ]:ACP:OFFSet[n]:LIST[n]:RCARrier?
```

Sets the amplitude levels to test against for any custom offsets. This amplitude level is relative to the carrier amplitude. If multiple offsets are available, the list contains five (5) entries. The offset closest to the carrier channel is the first one in the list. ACP:OFFS[n]:LIST[n]:TEST selects the type of testing to be done at each offset.

The query returns five (5) real numbers that are the current amplitude test limits, relative to the carrier, for each offset.

cdmaOne, Basic mode

Offset [n] - Where 1 is base station and 2 is mobiles. The default is base station (1).

List [n] - Where 1 is cellular frequency bands and 2 is pcs frequency bands. The default is cellular bands (1).

cdma2000 mode

Offset [n] - Where 1 is base station and 2 is mobiles. The default is base station (1).

List [n] - Where 1 is SR1, 2 is SR3 DS, and 3 is SR3 MC. The default is SR1 (1).

W-CDMA mode

Offset [n] - Where 1 is base station and 2 is mobiles. The default is base station (1).

List [n] - Where 1 is ARIB, 2 is 3GPP, and 3 is Trial. The default is ARIB (1).

Factory Preset

and *RST:

	Offset A	Offset B	Offset C	Offset D	Offset E
iDEN					
	0 dBc	n/a	n/a	n/a	n/a
Basic					
	-45 dBc	-60 dBc	0 dBc	0 dBc	0 dBc
cdmaOne					
BS cellular	-45 dBc	-60 dBc	0 dBc	0 dBc	0 dBc
BS pcs	-45 dBc	0 dBc	0 dBc	0 dBc	0 dBc
MS cellular	-42 dBc	-54 dBc	0 dBc	0 dBc	0 dBc
MS pcs	-42 dBc	0 dBc	0 dBc	0 dBc	0 dBc
cdma2000					
	0 dBc	0 dBc	0 dBc	0 dBc	0 dBc
W-CDMA					
	0 dBc	0 dBc	0 dBc	0 dBc	0 dBc

Range: -150 dB to 50 dB for cdmaOne, Basic mode
 -200 dB to 50 dB for cdma2000, W-CDMA, iDEN mode

Default Unit: dB

Remarks: You must be in Basic, cdmaOne, cdma2000, W-CDMA, iDEN mode to use this command. Use INSTRUMENT:SELEct to set the mode.

Adjacent Channel Power Measurement Amplitude Limits Relative to the Power Spectral Density

iDEN mode

```
[ :SENSe ]:ACP:OFFSet:RPSDensity <rel_power>
```

```
[ :SENSe ]:ACP:OFFSet:RPSDensity?
```

Basic mode

```
[ :SENSe ]:ACP:OFFSet:LIST:RPSDensity  
<rel_power>{ ,<rel_power> }
```

```
[ :SENSe ]:ACP:OFFSet:LIST:RPSDensity?
```

cdmaOne, cdma2000, W-CDMA mode

```
[ :SENSe ]:ACP:OFFSet[n]:LIST[n]:RPSDensity  
<rel_power>{ ,<rel_power> }
```

```
[ :SENSe ]:ACP:OFFSet[n]:LIST[n]:RPSDensity?
```

Sets the amplitude levels to test against for any custom offsets. This amplitude level is relative to the power spectral density. If multiple offsets are available, the list contains five (5) entries. The offset closest to the carrier channel is the first one in the list.

ACP:OFFS[n]:LIST[n]:TEST selects the type of testing to be done at each offset.

The query returns five (5) real numbers that are the current amplitude test limits, relative to the power spectral density, for each offset.

cdmaOne, Basic mode

Offset [n] - Where 1 is base station and 2 is mobiles. The default is base station (1).

List [n] - Where 1 is cellular frequency bands and 2 is pcs frequency bands. The default is cellular bands (1).

cdma2000 mode

Offset [n] - Where 1 is base station and 2 is mobiles. The default is base station (1).

List [n] - Where 1 is SR1, 2 is SR3 DS, and 3 is SR3 MC. The default is SR1 (1).

W-CDMA mode

Offset [n] - Where 1 is base station and 2 is mobiles. The default is base station (1).

List [n] - Where 1 is ARIB, 2 is 3GPP, and 3 is Trial. The default is ARIB (1).

Factory Preset

and *RST:

	Offset A	Offset B	Offset C	Offset D	Offset E
iDEN					
	0 dB	n/a	n/a	n/a	n/a
Basic					
	-28.87 dB	-43.87 dB	0 dB	0 dB	0 dB
cdmaOne					
BS cellular	-28.87 dB	-43.87 dB	0 dB	0 dB	0 dB
BS pcs	-28.87 dB	0 dB	0 dB	0 dB	0 dB
MS cellular	-25.87 dB	-37.87 dB	0 dB	0 dB	0 dB
MS pcs	-25.87 dB	0 dB	0 dB	0 dB	0 dB
cdma2000					
	0 dB	0 dB	0 dB	0 dB	0 dB
W-CDMA					
	0 dB	0 dB	0 dB	0 dB	0 dB

Range: -150 dB to 50 dB for cdmaOne, Basic, cdma2000, W-CDMA mode

-200 dB to 50 dB for iDEN mode

Default Unit: dB

Remarks: You must be in Basic, cdmaOne, cdma2000, W-CDMA, iDEN mode to use this command. Use INSTRUMENT:SELEct to set the mode.

Adjacent Channel Power Measurement Control Offset Frequency List

iDEN, NADC, PDC mode

```
[ :SENSe ] :ACP :OFFSet :STATe OFF | ON | 0 | 1
```

```
[ :SENSe ] :ACP :OFFSet :STATe ?
```

Basic mode

```
[ :SENSe ] :ACP :OFFSet :LIST :STATe OFF | ON | 0 | 1 { , OFF | ON | 0 | 1 }
```

```
[ :SENSe ] :ACP :OFFSet :LIST :STATe ?
```

cdmaOne, cdma2000, W-CDMA mode

```
[ :SENSe ] :ACP :OFFSet [ n ] :LIST [ n ] :STATe OFF | ON | 0 | 1  
{ , OFF | ON | 0 | 1 }
```

```
[ :SENSe ] :ACP :OFFSet [ n ] :LIST [ n ] :STATe ?
```

Selects whether testing is to be done at the custom offset frequencies. The measured powers are tested against the absolute values defined with ACP:OFFS[n]:LIST[n]:ABS, or the relative values defined with ACP:OFFS[n]:LIST[n]:RPSD and ACP:OFFS[n]:LIST[n]:RCAR.

cdmaOne mode

Offset [n] - Where 1 is base station and 2 is mobiles. The default is base station (1).

List [n] - Where 1 is cellular frequency bands and 2 is pcs frequency bands. The default is cellular bands (1).

cdma2000 mode

Offset [n] - Where 1 is base station and 2 is mobiles. The default is base station (1).

List [n] - Where 1 is SR1, 2 is SR3 DS, and 3 is SR3 MC. The default is SR1 (1).

W-CDMA mode

Offset [n] - Where 1 is base station and 2 is mobiles. The default is base station (1).

List [n] - Where 1 is ARIB, 2 is 3GPP, and 3 is Trial. The default is ARIB (1).

Factory Preset

and *RST:

	Offset A	Offset B	Offset C	Offset D	Offset E
iDEN					
	On	n/a	n/a	n/a	n/a
Basic					
	On	On	On	On	On
cdmaOne					
BS cellular	On	On	On	On	On
BS pcs	On	On	On	On	On
MS cellular	On	On	On	On	On
MS pcs	On	On	On	On	On
cdma2000					
	On	On	Off	Off	Off
W-CDMA					
	On	On	Off	Off	Off

Remarks: You must be in Basic, cdmaOne, cdma2000, W-CDMA, iDEN mode to use this command. Use INSTRUMENT:SElect to set the mode.

Adjacent Channel Power Measurement Define Type of Offset Frequency List

iDEN mode

[:SENSe] :ACP :OFFSet :TEST ABSolute | AND | RELative | OR

[:SENSe] :ACP :OFFSet :TEST?

Basic mode

[:SENSe] :ACP :OFFSet :LIST :TEST ABSolute | AND | RELative | OR
{ , ABSolute | AND | RELative | OR }

[:SENSe] :ACP :OFFSet :LIST :TEST?

cdmaOne, cdma2000, W-CDMA mode

[:SENSe] :ACP :OFFSet [n] :LIST [n] :TEST
ABSolute | AND | RELative | OR { , ABSolute | AND | RELative | OR }

[:SENSe] :ACP :OFFSet [n] :LIST [n] :TEST?

Defines the type of testing to be done at any custom offset frequencies. The measured powers are tested against the absolute values defined with ACP:OFFS[n]:LIST[n]:ABS, or the relative values defined with ACP:OFFS[n]:LIST[n]:RPSD and ACP:OFFS[n]:LIST[n]:RCAR.

cdmaOne, Basic mode

Offset [n] - Where 1 is base station and 2 is mobiles. The default is base station (1).

List [n] - Where 1 is cellular frequency bands and 2 is pcs frequency bands. The default is cellular bands (1).

cdma2000 mode

Offset [n] - Where 1 is base station and 2 is mobiles. The default is base station (1).

List [n] - Where 1 is SR1, 2 is SR3 DS, and 3 is SR3 MC. The default is SR1 (1).

W-CDMA mode

Offset [n] - Where 1 is base station and 2 is mobiles. The default is base station (1).

List [n] - Where 1 is ARIB, 2 is 3GPP, and 3 is Trial. The default is ARIB (1).

The types of testing that can be done for each offset include:

- And - Test both the absolute power measurement and the power relative to the carrier. If they both fail, then return a failure for the measurement at this offset.

- Absolute - Test the absolute power measurement. If it fails, then return a failure for the measurement at this offset.
- Or - Test both the absolute power measurement and the power relative to the carrier. If either one fails, then return a failure for the measurement at this offset.
- Relative - Test the power relative to the carrier. If it fails, then return a failure for the measurement at this offset.

Factory Preset
and *RST:

	Offset A	Offset B	Offset C	Offset D	Offset E
iDEN					
	REL	n/a	n/a	n/a	n/a
Basic					
	REL	REL	REL	REL	REL
cdmaOne					
BS cellular	REL	REL	REL	REL	REL
BS pcs	REL	ABS	ABS	REL	REL
MS cellular	REL	REL	REL	REL	REL
MS pcs	REL	ABS	ABS	REL	REL
cdma2000					
	REL	REL	REL	REL	REL
W-CDMA					
	REL	REL	REL	REL	REL

Remarks: You must be in Basic, cdmaOne, cdma2000, W-CDMA, iDEN mode to use this command. Use INSTRUMENT:SElect to set the mode.

Adjacent Channel Power Measurement Power Reference

[:SENSe] :ACP:TYPE TPreRef | PSDRef

[:SENSe] :ACP:TYPE?

Selects the measurement type. This allows you to make absolute and relative power measurements of either total power, or the power normalized to the measurement bandwidth.

Total Power Reference - the total power is used as the power reference

Power Spectral Density Reference - the power spectral density is used as the power reference

Factory Preset

and *RST: Total power reference

Remarks: You must be in the cdmaOne, cdma2000, W-CDMA, NADC, PDC mode to use this command. Use INSTRument:SElect to set the mode.

Code Domain Power Measurement

Commands for querying the code domain power measurement results and for setting to the default values are found in the “[MEASure Group of Commands](#)” on page 25. The equivalent front panel keys for the parameters described in the following commands, are found under the **Meas Setup** key, after the **Code Domain Power** measurement has been selected from the **MEASURE** key menu.

Code Domain Power Measurement Average Count

```
[ :SENSE ] :CDPower :AVERage :COUNT <integer>
```

```
[ :SENSE ] :CDPower :AVERage :COUNT?
```

Set the number of frames that will be averaged. After the specified number of frames (average counts) have been averaged, the averaging mode (termination control) setting determines the averaging action.

Factory Preset
and *RST: 10

Range: 1 to 10,000

Remarks: You must be in the cdmaOne mode to use this command. Use INSTRument:SElect to set the mode.

Code Domain Power Measurement Averaging State

```
[ :SENSE ] :CDPower :AVERage [ :STATe ] OFF | ON | 0 | 1
```

```
[ :SENSE ] :CDPower :AVERage [ :STATe ]?
```

Turn code domain power averaging on or off.

Factory Preset
and *RST: On

Remarks: You must be in the cdmaOne mode to use this command. Use INSTRument:SElect to set the mode.

Code Domain Power Measurement Averaging Termination Control

```
[ :SENSe ] :CDPower :AVERage :TCONtrol EXPonential | REPeat
```

```
[ :SENSe ] :CDPower :AVERage :TCONtrol ?
```

Select the type of termination control used for averaging. This determines the averaging action after the specified number of frames (average count) is reached.

Exponential - Each successive data acquisition after the average count is reached, is exponentially weighted and combined with the existing average.

Repeat - After reaching the average count, the averaging is reset and a new average is started.

Factory Preset
and *RST: Repeat

Remarks: You must be in the cdmaOne mode to use this command. Use INSTRument:SElect to set the mode.

Code Domain Power Measurement Active Set Threshold

```
[ :SENSe ] :CDPower :ASET :THReshold <rel_power>
```

```
[ :SENSe ] :CDPower :ASET :THReshold ?
```

Set the active set threshold value. Walsh channels with power less than this value, will be treated as non-active (noise) channels.

Factory Preset
and *RST: -20 dB

Range: -30 dB to 0 dB

Default Unit: dB

Remarks: You must be in the cdmaOne mode to use this command. Use INSTRument:SElect to set the mode.

Code Domain Power Measurement Method

[:SENSE] :CDPower :METHOD POWER | TPhase

[:SENSE] :CDPower :METHOD?

Select the measurement method.

Power - Measures the code domain power of all 64 Walsh Channels.

Timing & Phase - Measures the code domain power, code domain timing, and code domain phase of all 64 Walsh channels

Factory Preset

and *RST: Fast power

Remarks You must be in the cdmaOne mode to use this command. Use INSTRUMENT:SELEct to set the mode.

Code Domain Power Measurement Spectrum Normal/Invert

```
[ :SENSe ] :CDPower :SPECTrum NORMal | INVert
```

```
[ :SENSe ] :CDPower :SPECTrum?
```

Select normal or inverted spectrum for demodulation.

Normal - normal spectrum is used

Invert - inverted spectrum is used

Factory Preset
and *RST: Normal

Remarks You must be in the cdmaOne mode to use this command. Use INSTRument:SElect to set the mode.

Code Domain Power (Measurement Interval)

```
[ :SENSe ] :CDPower :SWEep :TIME <time>
```

```
[ :SENSe ] :CDPower :SWEep :TIME?
```

Set the length of the measurement interval that will be used.

Factory Preset
and *RST: 1.250 ms

Range: 0.5 ms to 30 ms

Default Unit: seconds

Remarks: You must be in the cdmaOne mode to use this command. Use INSTRument:SElect to set the mode.

Channel Power Measurement

Commands for querying the channel power measurement results and for setting to the default values are found in the “[MEASure Group of Commands](#)” on page 25. The equivalent front panel keys for the parameters described in the following commands, are found under the **Meas Setup** key, after the **Channel Power** measurement has been selected from the **MEASURE** key menu. **CHPower** used instead of the more std-compliant **CPOWer**, as that syntax was already used for Carrier Power measurement (but has since been renamed).

Channel Power Measurement Average Count

```
[ :SENSe ] :CHPower :AVERAge :COUNT <integer>
```

```
[ :SENSe ] :CHPower :AVERAge :COUNT?
```

Set the number of data acquisitions that will be averaged. After the specified number of average counts, the averaging mode (terminal control) setting determines the averaging action.

Factory Preset
and *RST: 20

Range: 1 to 10,000

Remarks: You must be in the cdmaOne, cdma2000, W-CDMA, or Basic mode to use this command. Use INSTRument:SElect to set the mode.

Channel Power Measurement Averaging State

```
[ :SENSe ] :CHPower :AVERAge [ :STATe ] OFF | ON | 0 | 1
```

```
[ :SENSe ] :CHPower :AVERAge [ :STATe ]?
```

Turn averaging on or off.

Factory Preset
and *RST: On

Remarks: You must be in the cdmaOne, cdma2000, W-CDMA, or Basic mode to use this command. Use INSTRument:SElect to set the mode.

Channel Power Measurement Averaging Termination Control

```
[ :SENSe ] :CHPower :AVERage :TCONtrol EXPonential | REPeat
```

```
[ :SENSe ] :CHPower :AVERage :TCONtrol ?
```

Select the type of terminal control used for averaging. This determines the averaging action after the specified number of data acquisitions (average count) is reached.

Exponential - Each successive data acquisition after the average count is reached, is exponentially weighted and combined with the existing average.

Repeat - After reaching the average count, the averaging is reset and a new average is started.

Factory Preset
and *RST: Repeat

Remarks: You must be in the cdmaOne, cdma2000, W-CDMA, or Basic mode to use this command. Use INSTRument:SElect to set the mode.

Channel Power Measurement Integration BW

```
[ :SENSe ] :CHPower :BANDwidth | BWIDth :INTEgration <freq>
```

```
[ :SENSe ] :CHPower :BANDwidth | BWIDth :INTEgration ?
```

Set the Integration BW (IBW) that will be used.

Factory Preset
and *RST: 1.23 MHz for Basic, cdmaOne, SR1 of cdma2000
3.69 MHz for SR3 of cdma2000
5 MHz for W-CDMA

Range: 1 kHz to 10 MHz

Default Unit: Hz

Remarks: You must be in the cdmaOne, cdma2000, W-CDMA, or Basic mode to use this command. Use INSTRument:SElect to set the mode.

Channel Power Measurement Span

```
[ :SENSe ] :CHPower :FREQuency :SPAN <freq>
```

```
[ :SENSe ] :CHPower :FREQuency :SPAN ?
```

Set the frequency span that will be used.

Factory Preset
and *RST: 2 MHz for Basic, cdma2000, SR1 of cdma2000
5 MHz for SR3 of cdma2000
6 MHz for W-CDMA

Range: 1 kHz to 10 MHz

Default Unit: Hz

Remarks: You must be in the cdmaOne, cdma2000, W-CDMA, or Basic mode to use this command. Use INSTRUMENT:SElect to set the mode.

Channel Power Measurement Data Points

[:SENSE] :CHPower:POINTs <integer>

[:SENSE] :CHPower:POINTs?

Set the number of data points that will be used. Changing this will change the time record length and resolution BW that are used.

Factory Preset
and *RST: 512

Range: 64 to 32768, in a 2ⁿ sequence

Remarks: You must be in the cdmaOne, cdma2000, W-CDMA, or Basic mode to use this command. Use INSTRUMENT:SElect to set the mode.

Channel Power Measurement Data Points Auto

[:SENSE] :CHPower:POINTs:AUTO OFF | ON | 0 | 1

[:SENSE] :CHPower:POINTs:AUTO?

Select auto or manual control of the data points. This is an advanced control that normally does not need to be changed. Setting this to a value other than the factory default, may cause invalid measurement results.

Auto - couples the Data Points to the Integration BW.

Manual - the Data Points is uncoupled from the Integration BW.

Factory Preset
and *RST: Auto

Remarks: You must be in the cdmaOne, cdma2000, W-CDMA, or Basic mode to use this command. Use INSTRUMENT:SElect to set the mode.

Channel Power Measurement Sweep Time

[:SENSe] :CHPower :SWEep :TIME <time>

[:SENSe] :CHPower :SWEep :TIME?

Sets the sweep time when using the sweep mode.

Factory Preset

and *RST: 625 μ s (1 slot)

Range: 500 μ s to 10 ms

Default Unit: seconds

Remarks: You must be in Basic, cdmaOne mode to use this command. Use INSTRument:SElect to set the mode.

Channel Power Measurement Sweep Time

[:SENSe] :CHPower :SWEep :TIME :AUTO OFF | ON | 0 | 1

[:SENSe] :CHPower :SWEep :TIME :AUTO?

Selects the automatic sweep time, optimizing the measurement.

Factory Preset

and *RST: On

Remarks: You must be in Basic, cdmaOne mode to use this command. Use INSTRument:SElect to set the mode.

Channel Power Measurement Trigger Source

```
[ :SENSe]:CHPower:TRIGger:SOURce EXTernal[1]|EXTernal  
2|IMMEDIATE
```

```
[ :SENSe]:CHPower:TRIGger:SOURce?
```

Select the trigger source used to control the data acquisitions. This is an Advanced control that normally does not need to be changed.

External 1 - front panel external trigger input

External 2 - rear panel external trigger input

Immediate - the next data acquisition is immediately taken (also called Free Run).

Factory Preset

and *RST: Immediate (Free Run)

Remarks: You must be in the cdmaOne, cdma2000, W-CDMA, or Basic mode to use this command. Use INSTRument:SElect to set the mode.

Correction for Base Station RF Port External Attenuation

```
[ :SENSe ]:CORRection:BS[:RF]:LOSS <rel_power>
```

```
[ :SENSe ]:CORRection:BS[:RF]:LOSS?
```

Set the correction equal to the external attenuation used when measuring base stations.

Factory Preset

and *RST: 0 dB

Range: 0 to 100 dB for cdmaOne

–50 to 50 dB for Basic, iDEN, NADC or PDC

Default Unit: dB

Remarks: You must be in the Basic, iDEN, cdmaOne, NADC or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Value is global to the current mode.

Close Spurs Measurement

Commands for querying the close spurs measurement results and for setting to the default values are found in the “[MEASure Group of Commands](#)” on page 25. The equivalent front panel keys for the parameters described in the following commands, are found under the **Meas Setup** key, after the **Spur Close** measurement has been selected from the **MEASURE** key menu.

Close Spurs Measurement Average Count

[:SENSE] :CSPur :AVERAge :COUNT <integer>

[:SENSE] :CSPur :AVERAge :COUNT?

Set the number of data acquisitions that will be averaged. After the specified number of average counts, the averaging mode (terminal control) setting determines the averaging action.

Factory Preset
and *RST: 15

Range: 1 to 10,000

Remarks: You must be in the cdmaOne mode to use this command. Use INSTRument:SElect to set the mode.

Close Spurs Measurement Averaging State

[:SENSE] :CSPur :AVERAge [:STATe] OFF | ON | 0 | 1

[:SENSE] :CSPur :AVERAge [:STATe]?

Turn averaging on or off.

Factory Preset
and *RST: On

Remarks: You must be in the cdmaOne mode to use this command. Use INSTRument:SElect to set the mode.

Close Spurs Measurement Averaging Termination Control

```
[ :SENSe ] :CSPur :AVERage :TCONtrol EXPonential | REPEAT
```

```
[ :SENSe ] :CSPur :AVERage :TCONtrol?
```

Select the type of terminal control used for averaging. This determines the averaging action after the specified number of data acquisitions (average count) is reached.

Exponential - Each successive data acquisition after the average count is reached, is exponentially weighted and combined with the existing average.

Repeat - After reaching the average count, the averaging is reset and a new average is started.

Factory Preset
and *RST: Repeat

Remarks: You must be in the cdmaOne mode to use this command. Use INSTRument:SElect to set the mode.

Close Spurs Measurement Averaging Type

```
[ :SENSe ] :CSPur :AVERage :TYPE LOG | MAXimum | RMS | SCALar
```

```
[ :SENSe ] :CSPur :AVERage :TYPE?
```

Select the type of averaging.

Log - The log of the power is averaged. (This is also known as video averaging.)

Maximum - The maximum values are retained.

RMS - The power is averaged, providing the rms of the voltage.

Scalar - The voltage is averaged.

Factory Preset
and *RST: RMS

Remarks: You must be in the cdmaOne mode to use this command. Use INSTRument:SElect to set the mode.

Close Spurs Measurement Type

[:SENSE] :CSPur :TYPE EXAMine | FULL

[:SENSE] :CSPur :TYPE?

Select the measurement type.

Examine - measures spurs in the upper, lower, and center segments and then displays the worst spur

Full - continuously measures the spurs in the upper, lower, and center segments

Factory Preset

and *RST: Full

Remarks: You must be in the cdmaOne mode to use this command. Use INSTRUMENT:SELEct to set the mode.

Select the Input Port

```
[ :SENSe ] :FEED IQ | RF | IFALign | AREference
```

Select the input port.

IQ is the IQ Input port

RF in the RF INPUT port

IF Align is the IF alignment signal source (internal, 321.4 MHz)

Amplitude Reference is the internal amplitude reference source
(50 MHz)

Factory Preset
and *RST: RF

Remarks: info

Center Frequency

```
[ :SENSe ] :FREQuency:CENTer <freq>
```

```
[ :SENSe ] :FREQuency:CENTer?
```

Set the center frequency.

Factory Preset
and *RST: 1.00 GHz
942.6 MHz for GSM
806 MHz for iDEN

Range: 1 kHz to 4.321 GHz

Default Unit: Hz

Front Panel
Access: FREQUENCY/Channel, Center Freq

Center Frequency Step Size Automatic

[:SENSE] :FREQUENCY :CENTER :STEP :AUTO OFF | ON | 0 | 1

[:SENSE] :FREQUENCY :CENTER :STEP :AUTO ?

Specifies whether the step size is set automatically based on the span.

Factory Preset

and *RST: On

History: Version A.03.00 or later

Front Panel

Access: FREQUENCY/Channel, Center Freq

Center Frequency Step Size

[:SENSE] :FREQUENCY :CENTER :STEP [:INCREMENT] <freq>

[:SENSE] :FREQUENCY :CENTER :STEP [:INCREMENT] ?

Specifies the center frequency step size.

Factory Preset

and *RST: 5 MHz

1.25 MHz for SR1 of cdma2000

Range: 1 kHz to 1 GHz, in 10 kHz steps

Default Unit: Hz

History: Version A.03.00 or later

Front Panel

Access: FREQUENCY/Channel, Center Freq

RF Port Input Attenuation

```
[ :SENSe ] :POWER [ :RF ] :ATTenuation <rel_power>
```

```
[ :SENSe ] :POWER [ :RF ] :ATTenuation?
```

Set the RF input attenuator. This value is set at its auto value if input attenuation is set to auto.

Factory Preset

and *RST: 0 dB

12.0 dB for iDEN

Range: 0 to 40 dB

Default Unit: dB

Front Panel

Access: Input, Input Atten

RF Port Power Range Auto

```
[ :SENSe ] :POWER [ :RF ] :RANGe :AUTO OFF | ON | 0 | 1
```

```
[ :SENSe ] :POWER [ :RF ] :RANGe :AUTO?
```

Select the RF port power range to be set either automatically or manually.

On - power range is automatically set as determined by the actual measured power level at the start of a measurement.

Off - power range is manually set

Factory Preset

and *RST: On

Remarks: You must be in the cdmaOne, GSM, NADC, PDC, cdma2000, W-CDMA mode to use this command. Use INSTRUMENT:SElect to set the mode.

Front Panel

Access: Input, Max Total Pwr (at UUT)

RF Port Power Range Maximum Total Power

```
[ :SENSe ] :POWER [ :RF ] :RANGe [ :UPPer ] <power>
```

```
[ :SENSe ] :POWER [ :RF ] :RANGe [ :UPPer ]?
```

Set the maximum expected total power level at the radio unit under test. This value is ignored if RF port power range is set to auto.

Factory Preset
and *RST: -15.0 dBm

Range: -100 to 80 dBm for GSM
-100 to 27.7 dBm for cdmaOne, iDEN
-200 to 50 dBm for NADC, PDC
-200 to 100 dBm for cdma2000, W-CDMA

Default Unit: dBm

Remarks: Global to the current mode. This is coupled to the RF input attenuation

You must be in the Service, cdmaOne, GSM, NADC, PDC, cdma2000, W-CDMA mode to use this command. Use INSTRUMENT:SElect to set the mode.

Front Panel
Access: Input, Max Total Pwr (at UUT)

Radio Carrier Multiple

```
[ :SENSE]:RADIO:CARRIER:NUMBER SINGLE|MULTIPLE
```

```
[ :SENSE]:RADIO:CARRIER:NUMBER?
```

Select if single or multiple carriers are present on the output of the base station under test. This enables/disables a software filter for the rho and code domain power measurements.

Factory Preset
and *RST: Single

Remarks: You must be in the , iDEN mode to use this command. Use INSTRUMENT:SElect to set the mode.

Front Panel
Access: Mode Setup, Demod, RF Carrier

Radio Standard Band

```
[ :SENSe ] :RADio :STANdard :BAND  
ARIB53 | C95B | CKOR | IS95A | JSTD8 | P95B | PKOR | CUSTOm
```

```
[ :SENSe ] :RADio :STANdard :BAND?
```

Select the standard variant that applies to the radio to be tested.

ARIB53 - ARIB T-53

C95B - EIA/TIA-95B Cellular

CKOR - Cellular in Korea

IS95A - IS-95A Cellular

JSTD8 - J-STD-008 PCS

P95B - EIA/TIA-95B (PCS)

PKOR - PCS in Korea

Factory Preset

and *RST: IS-95A Cellular

Remarks: Global to the current mode.

You must be in the cdmaOne mode to use this command. Use INSTRument:SElect to set the mode.

Front Panel

Access: **Mode Setup, Radio, Band**

Rho (Waveform Quality) Measurement

Commands for querying the rho measurement results and for setting to the default values are found in the “MEASure Group of Commands” on page 25. The equivalent front panel keys for the parameters described in the following commands, are found under the **Meas Setup** key, after the **Mod Accuracy (Rho)** measurement has been selected from the **MEASURE** key menu.

Rho Measurement Average Count

`[:SENSE] :RHO:AVERAGE:COUNT <integer>`

`[:SENSE] :RHO:AVERAGE:COUNT?`

Set the number of frames that will be averaged. After the specified number of frames (average counts), the averaging mode (termination control) setting determines the averaging action.

Factory Preset
and *RST: 10

Range: 1 to 10,000

Remarks: You must be in the cdmaOne, cdma2000, W-CDMA mode to use this command. Use INSTRUMENT:SElect to set the mode.

Rho Measurement Averaging State

`[:SENSE] :RHO:AVERAGE[:STATE] OFF | ON | 0 | 1`

`[:SENSE] :RHO:AVERAGE[:STATE]?`

Turn averaging on or off.

Factory Preset
and *RST: Off

Remarks: You must be in the cdmaOne, cdma2000, W-CDMA mode to use this command. Use INSTRUMENT:SElect to set the mode.

Rho Measurement Averaging Termination Control

`[:SENSE] :RHO:AVERAGE:TCONTROL EXPONENTIAL | REPEAT`

`[:SENSE] :RHO:AVERAGE:TCONTROL?`

Select the type of terminal control used for averaging. This determines the averaging action after the specified number of frames (average count) is reached.

Exponential - Each successive data acquisition after the average count is reached, is exponentially weighted and combined with the existing average.

Repeat - After reaching the average count, the averaging is reset and a new average is started.

Factory Preset
and *RST: Exponential

Repeat for cdma2000 and W-CDMA mode

Remarks: You must be in the cdmaOne, cdma2000, W-CDMA mode to use this command. Use INSTRument:SElect to set the mode.

Rho Measurement Spectrum Normal/Invert

```
[ :SENSe ]:RHO:SPECTrum NORMAl | INVert
```

```
[ :SENSe ]:RHO:SPECTrum?
```

Select normal or inverted spectrum for demodulation.

Normal - normal spectrum is used

Invert - inverted spectrum is used

Factory Preset
and *RST: Normal

Remarks You must be in the cdmaOne, cdma2000, W-CDMA mode to use this command. Use INSTRument:SElect to set the mode.

Rho Measurement Sweep Time (Measurement Interval)

```
[ :SENSe ]:RHO:SWEep:TIME <time>
```

```
[ :SENSe ]:RHO:SWEep:TIME?
```

Set the length of the measurement interval that will be used.

Factory Preset
and *RST: 1.250 ms

Range: 0.5 ms to 30 ms

Default Unit: seconds

Remarks: You must be in the cdmaOne mode to use this command. Use INSTRument:SElect to set the mode.

Rho Measurement Trigger Source

```
[ :SENSe ] :RHO:TRIGger:SOURce  
EXTernal[1] | External2 | FRAMe | IF | IMMEDIATE | IF | RFBURSt  
[ :SENSe ] :RHO:TRIGger:SOURce?
```

Select the trigger source used to control the data acquisitions.

External 1 – front panel external trigger input

External 2 – rear panel external trigger input

Frame – internal frame trigger from front panel input

IF – internal IF envelope trigger

Immediate – the next data acquisition is immediately taken, capturing the signal asynchronously (also called free run).

RF Burst – internal wideband RF burst envelope trigger that has automatic level control for periodic burst signals.

Factory Preset
and *RST: Immediate

Remarks: You must be in the cdma2000 or W-CDMA mode to use this command. Use INSTRUMENT:SElect to set the mode.

Front Panel
Access: Meas Setup, Trig Source

Reference Oscillator External Frequency

```
[ :SENSe ]:ROSCillator:EXTErnal:FREQuency <frequency>
```

```
[ :SENSe ]:ROSCillator:EXTErnal:FREQuency?
```

Set to the frequency of the external reference oscillator being supplied to the instrument. Switch to the external reference with ROSC:SOUR.

Option oscillator commands, if applicable, are found as
SENSe:OPTion:ROSCillator. (ESA?)

Preset

and *RST: Persistent state with factory default of 10 MHz

Range: 1 MHz to 40 MHz, in steps of >100 Hz. There is a
'special case' frequency of 19.6608 MHz

Default Unit: Hz

Remarks: Global to system.

Front Panel

Access: System, Reference, Ref Oscillator

Reference Oscillator Rear Panel Output

```
[ :SENSe ]:ROSCillator:OUTPut[ :STATe ] OFF|ON|0|1
```

```
[ :SENSe ]:ROSCillator:OUTPut?
```

Turn on and off the 10 MHz frequency reference signal going to the rear panel.

Preset

and *RST: Persistent State with factory default of On

Remarks: Global to system.

Front Panel

Access: System, Reference, 10 MHz Out

Reference Oscillator Source

[:SENSE] :ROSCillator :SOURCE INTERNAL | EXTERNAL

[:SENSE] :ROSCillator :SOURCE?

Select the reference oscillator (time base) source. Use `ROSC:EXT:FREQ` to tell the instrument the frequency of the external reference.

Option oscillator commands, if applicable, are found as `SENSE:OPTion:ROSCillator`. (ESA?)

Internal - uses internal 50 MHz reference signal

External - uses the signal at the rear panel external reference input port.

Preset
and *RST: Persistent State with factory default of Internal

Remarks: Global to system.

Front Panel

Access: System, Reference, Ref Oscillator

Spectrum (Frequency-Domain) Measurement

Commands for querying the spectrum measurement results and for setting to the default values are found in the “MEASure Group of Commands” on page 25. The equivalent front panel keys for the parameters described in the following commands, are found under the Meas Setup key, after the Spectrum (Freq Domain) measurement has been selected from the MEASURE key menu.

Spectrum Measurement Data Acquisition Packing

```
[ :SENSe ] :SPECTrum:ACQuisition:PACKing  
AUTO | LONG | MEDium | SHORT
```

```
[ :SENSe ] :SPECTrum:ACQuisition:PACKing?
```

Select the amount of data acquisition packing. This is an advanced control that normally does not need to be changed.

Factory Preset
and *RST: Auto

Remarks: To use this command, the appropriate mode should be selected with INSTRument:SElect.

Spectrum Measurement ADC Dither

```
[ :SENSe ] :SPECTrum:ADC:DITHer [ :STATe ] AUTO | ON | OFF | 2 | 1 | 0
```

```
[ :SENSe ] :SPECTrum:ADC:DITHer [ :STATe ] ?
```

Turn the ADC dither on or off. This is an advanced control that normally does not need to be changed.

Factory Preset
and *RST: Auto

Remarks: To use this command, the appropriate mode should be selected with INSTRument:SElect.

Spectrum Measurement ADC Range

```
[ :SENSe ] :SPECTrum:ADC:RANGe
AUTO | APEak | APLOCK | M6 | P0 | P6 | P12 | P18 | P24 |
```

```
[ :SENSe ] :SPECTrum:ADC:RANGe?
```

Select the range for the gain-ranging that is done in front of the ADC. This is an advanced control that normally does not need to be changed. Auto peak ranging is the default for this measurement. If you are measuring a CW signal please see the description below.

- Auto - automatic range

For FFT spectrums - auto ranging should not be used. An exception to this would be if you know that your signal is “bursty”. Then you might use auto to maximize the time domain dynamic range as long as you are not very interested in the FFT data.

- Auto Peak - automatically peak the range

For CW signals, the default of auto-peak ranging can be used, but a better FFT measurement of the signal can be made by selecting one of the manual ranges that are available: M6, P0 - P24.

Auto peaking can cause the ADC range gain to move monotonically down during the data capture. This movement should have negligible effect on the FFT spectrum, but selecting a manual range removes this possibility. Note that if the CW signal being measured is close to the auto-ranging threshold, the noise floor may shift as much as 6 dB from sweep to sweep.

- Auto Peak Lock - automatically peak lock the range

For CW signals, auto-peak lock ranging may be used. It will find the best ADC measurement range for this particular signal and will not move the range as auto-peak can. Note that if the CW signal being measured is close to the auto-ranging threshold, the noise floor may shift as much as 6 dB from sweep to sweep.

For “bursty” signals, auto-peak lock ranging should not be used. The measurement will fail to operate, since the wrong (locked) ADC range will be chosen often and overloads will occur in the ADC.

- M6 - manually selects an ADC range that subtracts 6 dB of fixed gain across the range. Manual ranging is best for CW signals.
- P0 to 24 - manually selects ADC ranges that add 0 to 24 dB of fixed gain across the range. Manual ranging is best for CW signals.

Factory Preset
and *RST: Auto peak

Remarks: To use this command, the appropriate mode should be selected with INSTRument:SElect.

Spectrum Measurement Average Clear

`[:SENSe] :SPECTrum:AVERAge:CLEAr`

The average data is cleared and the average counter is reset.

Remarks: To use this command, the appropriate mode should be selected with INSTRument:SElect.

Spectrum Measurement Number of Averages

`[:SENSe] :SPECTrum:AVERAge:COUNT <integer>`

`[:SENSe] :SPECTrum:AVERAge:COUNT?`

Set the number of 'sweeps' that will be averaged. After the specified number of 'sweeps' (average counts), the averaging mode (terminal control) setting determines the averaging action.

Factory Preset
and *RST: 25

Range: 1 to 10,000

Remarks: To use this command, the appropriate mode should be selected with INSTRument:SElect.

Spectrum Measurement Averaging State

`[:SENSe] :SPECTrum:AVERAge[:STATe] OFF|ON|0|1`

`[:SENSe] :SPECTrum:AVERAge[:STATe]?`

Turn averaging on or off.

Factory Preset
and *RST: On

Remarks: To use this command, the appropriate mode should be selected with INSTRument:SElect.

Spectrum Measurement Averaging Mode

```
[ :SENSe ] :SPECTrum:AVERAge:TCONtrol EXPONential | REPeat
[ :SENSe ] :SPECTrum:AVERAge:TCONtrol?
```

Select the type of terminal control used for averaging. This determines the averaging action after the specified number of 'sweeps' (average count) is reached.

Exponential - Each successive data acquisition after the average count is reached, is exponentially weighted and combined with the existing average.

Repeat - After reaching the average count, the averaging is reset and a new average is started.

Factory Preset
and *RST: Exponential

Remarks: To use this command, the appropriate mode should be selected with INSTRument:SElect.

Spectrum Measurement Averaging Type

```
[ :SENSe ] :SPECTrum:AVERAge:TYPE
LOG | MAXimum | MINimum | RMS | SCALar
[ :SENSe ] :SPECTrum:AVERAge:TYPE?
```

Select the type of averaging.

Log – The log of the power is averaged. (This is also known as video averaging.)

Maximum – The maximum values are retained.

Minimum – The minimum values are retained.

RMS – The power is averaged, providing the rms of the voltage.

Scalar – The voltage is averaged.

Factory Preset
and *RST: Log

Remarks: To use this command, the appropriate mode should be selected with INSTRument:SElect.

Spectrum Measurement pre-ADC Bandpass Filter

```
[ :SENSe ] :SPECTrum:BANDwidth | BWIDth:PADC OFF | ON | 0 | 1
[ :SENSe ] :SPECTrum:BANDwidth | BWIDth:PADC?
```

Turn the pre-ADC bandpass filter on or off. This is an advanced control that normally does not need to be changed.

Remarks: To use this command, the appropriate mode should be

selected with INSTRUMENT:SElect.

Spectrum Measurement pre-FFT BW Auto

```
[ :SENSe ] :SPECTrum: BANDwidth | BWIDth: PFFT: AUTO OFF | ON | 0 | 1
```

```
[ :SENSe ] :SPECTrum: BANDwidth | BWIDth: PFFT: AUTO?
```

Select auto or manual control of the pre-FFT BW. This is an advanced control that normally does not need to be changed.

Auto - couples the pre-FFT BW to the frequency span.

Manual - the pre-FFT BW is uncoupled from the frequency span.

Remarks: To use this command, the appropriate mode should be selected with INSTRUMENT:SElect.

Spectrum Measurement pre-FFT BW

```
[ :SENSe ] :SPECTrum: BANDwidth | BWIDth: PFFT [ :SIZE ] <freq>
```

```
[ :SENSe ] :SPECTrum: BANDwidth | BWIDth: PFFT [ :SIZE ]?
```

Set the pre-FFT bandwidth. This is an advanced control that normally does not need to be changed.

Frequency span, resolution bandwidth, and the pre-FFT bandwidth settings are normally coupled. If you are not auto-coupled, there can be combinations of these settings that are not valid.

Factory Preset

and *RST: 1.55 MHz
1.25 MHz for cdmaOne
155 kHz, for iDEN mode

Range: 1 Hz to 10 MHz

Remarks: To use this command, the appropriate mode should be selected with INSTRUMENT:SElect.

Spectrum Measurement Pre-FFT BW Filter Type

```
[ :SENSe]:SPECTrum:BAWdwidth|BWiDth:PFfT:TYpe FLAT|GAUSSian
[:SENSe]:SPECTrum:BAWdwidth|BWiDth:PFfT:TYpe?
```

Select the type of pre-FFT filter that is used. This is an advanced control that normally does not need to be changed.

Flat top- a filter with a flat amplitude response, which provides the best amplitude accuracy.

Gaussian - a filter with Gaussian characteristics, which provides the best pulse response.

Factory Preset
and *RST: Flat top

Remarks: To use this command, the appropriate mode should be selected with INSTRUMENT:SElect.

Spectrum Measurement Resolution BW

```
[ :SENSe]:SPECTrum:BAWdwidth|BWiDth[:RESolution] <freq>
[:SENSe]:SPECTrum:BAWdwidth|BWiDth[:RESolution]?
```

Set the resolution bandwidth for the FFT. This is the bandwidth used for resolving the FFT measurement. It is not the pre-FFT bandwidth. This value is ignored if the function is auto-coupled.

Frequency span, resolution bandwidth, and the pre-FFT bandwidth settings are normally coupled. If you are not auto-coupled, there can be combinations of these settings that are not valid.

Factory Preset
and *RST: 20 kHz
250 Hz, for iDEN mode

Range: 0.10 Hz to 3 MHz

Remarks: To use this command, the appropriate mode should be selected with INSTRUMENT:SElect.

Spectrum Measurement Resolution BW Auto

```
[ :SENSe]:SPECTrum:BAWdwidth|BWiDth[:RESolution]:AUTO
OFF|ON|0|1
[:SENSe]:SPECTrum:BAWdwidth|BWiDth[:RESolution]:AUTO?
```

Select auto or manual control of the resolution BW. The automatic mode couples the resolution bandwidth setting to the frequency span.

Factory Preset
and *RST: On

Off, for iDEN mode

Remarks: To use this command, the appropriate mode should be selected with INSTRUMENT:SElect.

Decimation of Spectrum Display

```
[ :SENSe ] :SPECTrum:DECimate[ :FACTor ] <integer>
```

```
[ :SENSe ] :SPECTrum:DECimate[ :FACTor ]?
```

Set the amount of data decimation done by the hardware and/or the software. Decimation by 3 keeps every third sample, throwing away the two in between. Similarly, decimation by 5 keeps every fifth sample, throwing away the four in between.

Using zero (0) decimation selects the automatic mode. The measurement will then automatically choose decimation by “1” or “2” as is appropriate for the bandwidth being used. This is an advanced control that normally does not need to be changed.

Factory Preset
and *RST: 0

Range: 0 to 1000, where 0 sets the function to automatic

Remarks: To use this command, the appropriate mode should be selected with INSTRUMENT:SElect.

History: Version A.02.00 or later

Spectrum Measurement FFT Length

[:SENSE] :SPECTrum:FFT:LENGth <integer>

[:SENSe] :SPECTrum:FFT:LENGth?

Set the FFT length. This value is only used if length control is set to manual. The value must be greater than or equal to the window length value. Any amount greater than the window length is implemented by zero-padding. This is an advanced control that normally does not need to be changed.

Factory Preset

and *RST: 4096

32768, for iDEN mode

Range: 8 to 1,048,576

Remarks: To use this command, the appropriate mode should be selected with INSTRument:SElect.

History: Short form changed from LENGth to LENGth, A.03.00

Spectrum Measurement FFT Length Auto

[:SENSE] :SPECTrum:FFT:LENGth:AUTO OFF | ON | 0 | 1

[:SENSe] :SPECTrum:FFT:LENGth:AUTO?

Select auto or manual control of the FFT and window lengths.

This is an advanced control that normally does not need to be changed.

Auto - the window lengths are coupled to resolution bandwidth, window type (FFT), pre-FFT bandwidth (sample rate) and SENSE:SPECTrum:FFT:RBWPoints.

Manual - lets you set SENSE:SPECTrum:FFT:LENGth and SENSE:SPECTrum:FFT:WINDow:LENGth.

Factory Preset

and *RST: Auto

Remarks: To use this command, the appropriate mode should be selected with INSTRument:SElect.

History: Short form changed from LENGth to LENGth, A.03.00

Spectrum Measurement FFT Minimum Points in Resolution BW

```
[ :SENSe ] :SPECTrum:FFT:RBWPoints <real>
```

```
[ :SENSe ] :SPECTrum:FFT:RBWPoints?
```

Set the minimum number of data points that will be used inside the resolution bandwidth. The value is ignored if length control is set to manual. This is an advanced control that normally does not need to be changed.

Factory Preset

and *RST: 1.30

Range: 0.1 to 100

Remarks: To use this command, the appropriate mode should be selected with INSTRument:SElect.

Spectrum Measurement Window Delay

```
[ :SENSe ] :SPECTrum:FFT:WINDow:DELay <real>
```

```
[ :SENSe ] :SPECTrum:FFT:WINDow:DELay?
```

Set the FFT window delay to move the FFT window from its nominal position of being centered within the time capture. This function is not available from the front panel. It is an advanced control that normally does not need to be changed.

Factory Preset

and *RST: 0

Range: -10.0 to +10.0s

Default Unit: seconds

Remarks: To use this command, the Service mode must be selected with INSTRument:SElect. In Service mode, it is possible to get an acquisition time that is longer than the window time so that this function can be used.

Spectrum Measurement Window Length

```
[ :SENSe ] :SPECTrum:FFT:WINDow:LENGth <integer>
```

```
[ :SENSe ] :SPECTrum:FFT:WINDow:LENGth?
```

Set the FFT window length. This value is only used if length control is set to manual. This is an advanced control that normally does not need to be changed.

Factory Preset

and *RST: 706

5648, for iDEN mode

Range: 8 to 1,048,576

Remarks: To use this command, the appropriate mode should be selected with INSTRUMENT:SElect.

History: Short form changed from LENGth to LENGth, A.03.00

Spectrum Measurement FFT Window

```
[ :SENSE ] :SPECTrum:FFT:WINDow[ :TYPE ]  
BH4Tap | BLACKman | FLATtop | GAUSSian | HAMMING | HANNING | KB70 | KB90  
| KB110 | UNIFORM
```

```
[ :SENSE ] :SPECTrum:FFT:WINDow[ :TYPE ]?
```

Select the FFT window type.

BH4Tap - Blackman Harris with 4 taps

Blackman - Blackman

Flat Top - flat top, the default (for high amplitude accuracy)

Gaussian - Gaussian with alpha of 3.5

Hamming - Hamming

Hanning - Hanning

KB70, 90, and 110 - Kaiser Bessel with sidelobes at -70, -90, or -110 dBc

Uniform - no window is used. (This is the unity response.)

Factory Preset

and *RST: Flat top

Remarks: This selection affects the acquisition point quantity and the FFT size, based on the resolution bandwidth selected.

To use this command, the appropriate mode should be selected with INSTRUMENT:SElect.

Spectrum Measurement Frequency Span

[:SENSe] :SPECTrum:FREQuency:SPAN <freq>

[:SENSe] :SPECTrum:FREQuency:SPAN?

Set the frequency span to be measured.

Factory Preset

and *RST: 1 MHz

100 kHz for iDEN mode

Range: 10 Hz to 10 MHz (15 MHz when Service mode is selected)

Default Unit: Hz

Remarks: The actual measured span will generally be slightly wider due to the finite resolution of the FFT.

To use this command, the appropriate mode should be selected with INSTRument:SElect.

Spectrum Measurement Sweep (Acquisition) Time

[:SENSe] :SPECTrum:SWEep:TIME <time>

[:SENSe] :SPECTrum:SWEep:TIME?

Set the sweep (measurement acquisition) time. It is used to specify the length of the time capture record. If the specified value is less than the capture time required for the specified span and resolution bandwidth, the value is ignored. The value is set at its auto value when auto is selected. This is an advanced control that normally does not need to be changed.

Factory Preset

and *RST: 188.0 μ s

15.059 ms, for iDEN mode

Range: 100 ns to 10 s

Default Unit: seconds

Remarks: NOTE: You must be in the Service mode to use this command. Use INSTRument:SElect to set the mode.

This command only effects the RF envelope trace.

Spectrum Measurement Sweep (Acquisition) Time Auto

```
[ :SENSe ] :SPECTrum:SWEEp:TIME:AUTO OFF | ON | 0 | 1
```

```
[ :SENSe ] :SPECTrum:SWEEp:TIME:AUTO
```

Select auto or manual control of the sweep (acquisition) time. This is an advanced control that normally does not need to be changed.

Auto - couples the Sweep Time to the Frequency Span and Resolution BW

Manual - the Sweep Time is uncoupled from the Frequency Span and Resolution BW.

Factory Preset
and *RST: Auto

Remarks: To use this command, the appropriate mode should be selected with INSTRUMENT:SElect.

Spectrum Measurement Trigger Source

```
[ :SENSe ] :SPECTrum:TRIGger:SOURce EXTErnal[1] | EXTErnal  
2 | FRAME | IF | LINE | IMMEDIATE | RFBURst
```

```
[ :SENSe ] :SPECTrum:TRIGger:SOURce?
```

Select the trigger source used to control the data acquisitions.

External 1 - front panel external trigger input

External 2 - rear panel external trigger input

Frame - internal frame timer from front panel input

IF - internal IF envelope (video) trigger

Line - internal line trigger

Immediate - the next data acquisition is immediately taken (also called free run)

RF Burst - internal wideband RF burst envelope trigger that has automatic level control for periodic burst signals

Factory Preset
and *RST: Immediate (free run)

RF burst, for GSM, iDEN mode

Remarks: To use this command, the appropriate mode should be selected with INSTRUMENT:SElect.

Sync Type

[:SENSe] :SYNC ESECond | EXTErnal[1] | EXTErnal2 | NONE | PSEquence

[:SENSe] :SYNC?

Select the demodulation sync type for the waveform accuracy (Rho) and code domain power measurements.

Even Second - Even second clock

External 1 - front panel external trigger input

External 2 - rear panel external trigger input

None - no demod sync (uses free run trigger)

Pilot Sequence - pilot sequence sync (uses frame trigger)

Factory Preset

and *RST: Even second

Remarks: Global to the current mode.

You must be in the cdmaOne mode to use this command. Use INSTRument:SElect to set the mode.

Front Panel

Access: **Mode Setup, Trigger, Sync Type**

History: Front/Rear panel swapped EXT2/EXT1, A.03.00

Waveform (Time-Domain) Measurement

Commands for querying the waveform measurement results and for setting to the default values are found in the “[MEASure Group of Commands](#)” on page 25. The equivalent front panel keys for the parameters described in the following commands, are found under the **Meas Setup** key, after the **Waveform (Time Domain)** measurement has been selected from the **MEASURE** key menu.

Waveform Measurement Data Acquisition Packing

```
[ :SENSE]:WAVEform:ACQuistion:PACKing AUTO|LONG|MEDIUM|SHORT
```

```
[ :SENSE]:WAVEform:ACQuistion:PACKing?
```

This is an advanced control that normally does not need to be changed.

Factory Preset
and *RST: Auto

Remarks: You must be in the Service mode to use this command.
Use INSTRument:SElect to set the mode.

Waveform Measurement ADC Dither State

```
[ :SENSE]:WAVEform:ADC:DITHer[:STATE] |OFF|ON|0|1
```

```
[ :SENSE]:WAVEform:ADC:DITHer[:STATE]?
```

This is an Advanced control that normally does not need to be changed.

Factory Preset
and *RST: Off

Remarks: You must be in the Service mode to use this command.
Use INSTRument:SElect to set the mode.

Waveform Measurement pre-ADC Bandpass Filter

```
[ :SENSE]:WAVEform:ADC:FILTer[:STATE] OFF|ON|0|1
```

```
[ :SENSE]:WAVEform:ADC:FILTer[:STATE]?
```

Turn the pre-ADC bandpass filter on or off. This is an Advanced control that normally does not need to be changed.

Preset: Off

Remarks: To use this command, the appropriate mode should be selected with INSTRument:SElect.

Waveform Measurement ADC Range

```
[ :SENSe ] :WAVeform:ADC:RANGe  
AUTO | APEak | APLock | GROund | M6 | P0 | P6 | P12 | P18 | P24 |  
[ :SENSe ] :WAVeform:ADC:RANGe?
```

Select the range for the gain-ranging that is done in front of the ADC. This is an Advanced control that normally does not need to be changed.

Auto - automatic range

Auto Peak - automatically peak the range

Auto Peak Lock - automatically peak lock the range

Ground - ground

M6 - subtracts 6 dB of fixed gain across the range

P0 to 24 - adds 0 to 24 dB of fixed gain across the range

Factory Preset
and *RST: Auto

Remarks: To use this command, the appropriate mode should be selected with INSTRument:SElect.

Waveform Measurement Number of Averages

```
[ :SENSe ] :WAVeform:AVERage:COUNT <integer>  
[ :SENSe ] :WAVeform:AVERage:COUNT?
```

Set the number of sweeps that will be averaged. After the specified number of sweeps (average counts), the averaging mode (terminal control) setting determines the averaging action.

Factory Preset
and *RST: 10

Range: 1 to 10,000

Remarks: To use this command, the appropriate mode should be selected with INSTRument:SElect.

Waveform Measurement Averaging State

```
[ :SENSe ] :WAVeform:AVERage[ :STATe] OFF | ON | 0 | 1  
[ :SENSe ] :WAVeform:AVERage[ :STATe]?
```

Turn averaging on or off.

Factory Preset
and *RST: Off

Remarks: To use this command, the appropriate mode should be selected with INSTRument:SElect.

Waveform Measurement Averaging Mode

```
[ :SENSE ] :WAVEform:AVERage:TCONtrol EXPonential | REPEAT
```

```
[ :SENSe ] :WAVEform:AVERage:TCONtrol?
```

Select the type of terminal control used for averaging. This determines the averaging action after the specified number of 'sweeps' (average count) is reached.

Exponential - Each successive data acquisition after the average count is reached, is exponentially weighted and combined with the existing average.

RepPeat - After reaching the average count, the averaging is reset and a new average is started.

Factory Preset

and *RST: Exponential

Remarks: To use this command, the appropriate mode should be selected with INSTRument:SElect.

Waveform Measurement Averaging Type

```
[ :SENSe ] :WAVEform:AVERage:TYPE
```

```
LOG | MAXimum | MINimum | RMS | SCALar
```

```
[ :SENSe ] :WAVEform:AVERage:TYPE?
```

Select the type of averaging.

Log - The log of the power is averaged. (This is also known as video averaging.)

Maximum - The maximum values are retained.

Minimum - The minimum values are retained.

RMS - The power is averaged, providing the rms of the voltage.

Factory Preset

and *RST: RMS

Remarks: To use this command, the appropriate mode should be selected with INSTRument:SElect.

Waveform Measurement Resolution BW

```
[ :SENSe ] :WAVeform: BANDwidth| BWIDth [ :RESolution ] <freq>
```

```
[ :SENSe ] :WAVeform: BANDwidth| BWIDth [ :RESolution ] ?
```

Set the resolution bandwidth. This value is ignored if the function is auto-coupled.

Factory Preset
and *RST: 100 kHz, for NADC, PDC, cdma2000, W-CDMA,
 basic, service mode
 500 kHz, for GSM mode
 2 MHz. for cdmaOne

Range: 1 kHz to 5 MHz

Remarks: To use this command, the appropriate mode should be
 selected with INSTRument:SElect.

Waveform Measurement Resolution BW Filter Type

```
[ :SENSe ] :WAVeform: BANDwidth| BWIDth [ :RESolution ] :TYPE  
FLATtop| GAUSSian
```

```
[ :SENSe ] :WAVeform: BANDwidth| BWIDth [ :RESolution ] :TYPE ?
```

Select the type of Resolution BW filter that is used. This is an Advanced control that normally does not need to be changed.

Flat top - a filter with a flat amplitude response, which provides the best amplitude accuracy.

Gaussian - a filter with Gaussian characteristics, which provides the best pulse response.

Factory Preset
and *RST: Gaussian

Remarks: To use this command, the appropriate mode should be
 selected with INSTRument:SElect.

Decimation of Waveform Display

```
[ :SENSe ] :WAVeform: DECimate [ :FACTor ] <integer>
```

```
[ :SENSe ] :WAVeform: DECimate [ :FACTor ] ?
```

Set the amount of data decimation done by the hardware and/or the firmware. For example, if 4 is selected, three out of every four data points will be thrown away. So every 4th data point will be kept.

Factory Preset
and *RST: 1

Range: 1 to 4

Remarks: To use this command, the appropriate mode should be

selected with INSTRUMENT:SELECT.

Control Decimation of Waveform Display

[:SENSE] :WAVEform:DECimate:STATE OFF | ON | 0 | 1

[:SENSE] :WAVEform:DECimate:STATE?

Set the amount of data decimation done by the hardware in order to decrease the number of acquired points in a long capture time. This is the amount of data that the measurement ignores.

Factory Preset

and *RST: Off

Remarks: To use this command, the appropriate mode should be selected with INSTRUMENT:SELECT.

Waveform Measurement Sweep (Acquisition) Time

[:SENSE] :WAVEform:SWEep:TIME <time>

[:SENSE] :WAVEform:SWEep:TIME?

Set the measurement acquisition time. It is used to specify the length of the time capture record.

Factory Preset

and *RST: 2.0 ms

10.0 ms, for NADC, PDC

15.0 ms, for iDEN mode

Range: 1 μ s to 100 s

Default Unit: seconds

Remarks: To use this command, the appropriate mode should be selected with INSTRUMENT:SELECT.

Waveform Measurement Trigger Source

```
[ :SENSe ] :WAVeform:TRIGger:SOURce EXTeRnal[1] | EXTeRnal  
2 | FRAMe | IF | IMMEdiate | LINE | RFBurst
```

```
[ :SENSe ] :WAVeform:TRIGger:SOURce?
```

Select the trigger source used to control the data acquisitions.

External 1 - front panel external trigger input

External 2 - rear panel external trigger input

Frame - internal frame timer from front panel input

IF - internal IF envelope (video) trigger

Immediate - the next data acquisition is immediately taken (also called free run)

Line - internal line trigger

RF Burst - internal wideband RF burst envelope trigger that has automatic level control for periodic burst signals

Factory Preset

and *RST: Immediate (free run), for Basic, cdmaOne, NADC, PDC mode

RF burst, for GSM, iDEN mode

Remarks: To use this command, the appropriate mode should be selected with INSTRument:SElect.