

Reference Guide

Agilent Technologies ESA Series

Spectrum Analyzers

This guide documents firmware revision A.08.xx

This manual provides documentation for the following instruments:

Agilent Technologies ESA-E Series

E4401B (9 kHz–1.5 GHz)
E4402B (9 kHz–3.0 GHz)
E4404B (9 kHz–6.7 GHz)
E4405B (9 kHz–13.2 GHz)
E4407B (9 kHz–26.5 GHz)

and

Agilent Technologies ESA-L Series

E4411B (9 kHz–1.5 GHz)
E4403B (9 kHz–3.0 GHz)
E4408B (9 kHz–26.5 GHz)



Manufacturing Part Number: E4401-90404
Supersedes E4401-90237

Printed in USA

December 2001

© Copyright 2001 Agilent Technologies

The information contained in this document is subject to change without notice.

Agilent Technologies makes no warranty of any kind with regard to this material, including but not limited to, the implied warranties of merchantability and fitness for a particular purpose. Agilent Technologies shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance, or use of this material.

The following safety symbols are used throughout this manual. Familiarize yourself with the symbols and their meaning before operating this instrument.

WARNING

***Warning* denotes a hazard. It calls attention to a procedure which, if not correctly performed or adhered to, could result in injury or loss of life. Do not proceed beyond a warning note until the indicated conditions are fully understood and met.**

CAUTION

Caution denotes a hazard. It calls attention to a procedure that, if not correctly performed or adhered to, could result in damage to or destruction of the instrument. Do not proceed beyond a caution sign until the indicated conditions are fully understood and met.

NOTE

Note calls out special information for the user's attention. It provides operational information or additional instructions of which the user should be aware.



The instruction documentation symbol. The product is marked with this symbol when it is necessary for the user to refer to the instructions in the documentation.



This symbol is used to mark the on position of the power line switch.



This symbol is used to mark the standby position of the power line switch.



This symbol indicates that the input power required is AC.

WARNING

This is a Safety Class 1 Product (provided with a protective earthing ground incorporated in the power cord). The mains plug shall only be inserted in a socket outlet provided with a protected earth contact. Any interruption of the protective conductor inside or outside of the product is likely to make the product dangerous. Intentional interruption is prohibited.

WARNING

If this product is not used as specified, the protection provided by the equipment could be impaired. This product must be used in a normal condition (in which all means for protection are intact) only.

Warranty

This Agilent Technologies instrument product is warranted against defects in material and workmanship for a period of three years from date of shipment. During the warranty period, Agilent Technologies will, at its option, either repair or replace products which prove to be defective.

For warranty service or repair, this product must be returned to a service facility designated by Agilent Technologies. Buyer shall prepay shipping charges to Agilent Technologies and Agilent Technologies shall pay shipping charges to return the product to Buyer. However, Buyer shall pay all shipping charges, duties, and taxes for products returned to Agilent Technologies from another country.

Agilent Technologies warrants that its software and firmware designated by Agilent Technologies for use with an instrument will execute its programming instructions when properly installed on that instrument. Agilent Technologies does not warrant that the operation of the instrument, or software, or firmware will be uninterrupted or error-free.

LIMITATION OF WARRANTY

The foregoing warranty shall not apply to defects resulting from improper or inadequate maintenance by Buyer, Buyer-supplied software or interfacing, unauthorized modification or misuse, operation outside of the environmental specifications for the product, or improper site preparation or maintenance.

NO OTHER WARRANTY IS EXPRESSED OR IMPLIED. AGILENT TECHNOLOGIES SPECIFICALLY DISCLAIMS THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

Should Agilent have a negotiated contract with the User and should any of the contract terms conflict with these terms, the contract terms shall control

EXCLUSIVE REMEDIES

THE REMEDIES PROVIDED HEREIN ARE BUYER'S SOLE AND EXCLUSIVE REMEDIES. AGILENT TECHNOLOGIES SHALL NOT BE LIABLE FOR ANY DIRECT, INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, WHETHER BASED ON CONTRACT, TORT, OR ANY OTHER LEGAL THEORY.

Where to Find the Latest Information

Documentation is updated periodically. For the latest information about Agilent Technologies ESA Spectrum Analyzers, including firmware upgrades and application information, please visit the following Internet URL:

<http://www.agilent.com/find/esa>

Microsoft® is a U.S. registered trademark of Microsoft Corporation.

Pentium® is a U.S. registered trademark of Intel Corporation.

Bluetooth™ is a trademark owned by its proprietor and used under license.

1. Getting Started	
What You Will Find in This Chapter	10
Front-Panel Connectors and Keys	11
Rear-Panel Features	16
Display Annotation	22
Key Overview	26
Making a Basic Measurement	28
Using the Front Panel	29
Presetting the Spectrum Analyzer	30
Viewing a Signal	31
Analyzer Accuracy and the Internal Alignment Process	37
Warm-up Time	37
File Menu Functions	38
Locating and viewing files in the catalog	39
Creating a directory	41
Formatting a Floppy Disk	42
Saving a File	44
Step 1. Set up the analyzer trace	44
Step 2. Save the file	46
Loading a file	48
Renaming a File	50
Copying a File	51
Deleting a File	52
Using the Alpha Editor	53
Printer Setup and Operation	54
Analyzer Battery Information	57
2. Menu Maps	
What You Will Find in This Chapter	60
Menus	61
Alpha Editor Menu	61
AMPLITUDE Y Scale Menu	62
Amplitude Y Scale: Corrections Menu	63
Auto Couple Menu	64
BW/Avg Menu	65
Det/Demod Menu	66
Display Menu	67
File Menus (1 of 3)	68
File Menus (2 of 3)	69
File Menus (3 of 3)	70
Freq Count (Marker) Menu	71
FREQUENCY Channel Menu	72
Input/Output Menu	73
Marker Menu	74
Marker → Menu	75
Meas Control Menu	76
Meas Setup Menu for Channel Power, Occupied BW, and ACP	77
Meas Setup Menu for Multi-Carrier Power, Power Stat CCDF, Harmonic Distortion, and Burst Power	78

Contents

Meas Setup Menu for Intermod (TOI), Spurious Emissions and Spectrum	
Emission Mask	79
MEASURE Menu	80
Mode Setup Menu	81
Peak Search Menu	82
Preset Menu	83
Print Setup Menu	84
Source Menu	85
SPAN (X Scale) Menu	86
Sweep Menu	87
System Menu	88
Trace/View Menu	89
Trace/View Menu (Channel Power)	90
Trace/View Menu (ACP)	91
Trace/View Menu (Multi-Carrier Power)	92
Trace/View Menu (Harmonic Distortion)	93
Trace/View Menu (Burst Power)	94
Trace/View Menu (Power Stat CCDF and Spectrum Emission Mask)	95
Trig Menu	96

3. Front-Panel Key Reference

AMPLITUDE Y Scale	106
Auto Couple	121
Bk Sp (Backspace)	128
BW/Avg.	129
Det/Demod	134
Display	139
Enter	146
ESC	147
File	148
Freq Count	162
FREQUENCY Channel	163
Help	166
Input/Output	167
Marker	172
Marker →	177
Meas Control	179
Meas Setup	180
Channel Power Meas Setup Menu Keys	180
Occupied BW Meas Setup Menu Keys	181
ACP Meas Setup Menu Keys	184
Multi-Carrier Power Meas Setup Menu Keys	187
Power Stat CCDF Meas Setup Menu Keys	189
Harmonic Distortion Meas Setup Menu Keys	190
Burst Power Meas Setup Menu Keys	191
Intermod (TOI) Meas Setup Menu Keys	194
Spurious Emissions Meas Setup Menu Keys	195
Spectrum Emission Mask Meas Setup Menu Keys	200
MEASURE	204

Contents

MODE	212
Mode Setup	213
Next Window	216
Peak Search	217
Preset	222
Print	227
Print Setup	228
Restart	230
Return	231
Save	232
Single	233
Source	234
SPAN X Scale	238
SPAN X Scale (CCDF)	243
SPAN X Scale (Spectrum Emission Mask)	244
Standby	245
Sweep	246
System (Local)	256
Tab Keys	267
Trace/View	268
Trace/View (ACP)	272
Trace/View (Burst Power)	273
Trace/View (Channel Power)	274
Trace/View (Harmonic Distortion)	275
Trace/View (Power Stat CCDF)	276
Trace/View (Spectrum Emission Mask)	277
Trig	278
↑ (UP) and ↓ (DOWN) Arrow Keys	283
Viewing Angle	284
Zoom	285
4. Instrument Messages	
Instrument Messages Introduction	288
Error Message Format	289
Error Message Types	290
Instrument Messages	292
Error Messages	292
Instrument Messages without Numbers	329
5. AM, FM, and Pulsed RF Reference Charts	
AM, FM, and Pulsed RF Reference Charts	344

1 **Getting Started**

What You Will Find in This Chapter


This chapter introduces the basic functions of the analyzer. In this chapter you will:

- Get acquainted with the front-panel and rear-panel features.
- Get acquainted with the function keys.
- Learn about display annotation.
- Make a basic measurement (using the internal alignment signal).
- Learn about analyzer accuracy and the internal alignment process.
- Learn about file menus.
- Set up your printer.
- Learn about the analyzer battery for retaining internal memory.

NOTE

Before using your analyzer, please read Chapter 1 , “Installation and Setup” of the Getting Started guide which describes how to set up your analyzer and how to verify that it is operational. It also describes many safety considerations that should not be overlooked.

Front-Panel Connectors and Keys



pb938a

- 1 **Viewing Angle** keys allow you to adjust the display so that it can be optimally viewed from different angles.
- 2 **Esc.** The **Esc** (escape) key cancels any entry in progress. **Esc** will abort a print (if one is in progress) and clear error messages from the status line at the bottom of the display. It also clears input and tracking generator overload conditions.
- 3 **Menu keys** are the unlabeled keys next to the screen. The menu key labels are the annotation on the screen next to the unlabeled keys. Most of the labeled keys on the analyzer front panel (also called front-panel keys) access menus of keys having related functions.
- 4 **FREQUENCY Channel, SPAN X Scale, and AMPLITUDE Y Scale** are the three large keys that activate the primary analyzer functions and access menus of related functions. The secondary labels on these keys (Channel, X Scale, and Y Scale) are used in some measurements.

- 5 **CONTROL** functions access menus that allow you to adjust the resolution bandwidth, adjust the sweep time, and control the analyzer display. They also set other analyzer parameters needed for making measurements.
- 6 **MEASURE** accesses a menu of keys that automate some common analyzer measurements. Once a measurement is running, **Meas Setup** accesses additional menu keys for defining your measurement. **Meas Control** and **Restart** access additional measurement control functions.
- 7 **SYSTEM** functions affect the state of the entire analyzer.

 Various setup and alignment routines are accessed with the **System** key.

 The green **Preset** key resets the analyzer to a known state.

 The **File** key menu allows you to save and load setups, traces, states, limit-line tables, screens, measurement results, and amplitude correction factors to or from analyzer memory or the floppy disk drive. The **Save** key immediately executes the **Save Now** function defined under **File** in your User's guide.

 The **Print Setup** menu keys allow you to configure hardcopy outputs. The **Print** key immediately sends hardcopy data to the printer. See your User's guide for more details.
- 8 **MARKER** functions control the markers, read out frequencies and amplitudes along the analyzer trace, automatically locate the signals of highest amplitude, and access functions like **Marker Noise** and **Band Power**.
- 9 The **Media Door** on the right side of the front panel accesses the 3.5 inch disk drive and the **Earphone** connector. The earphone connector provides a connection for an earphone jack which bypasses the internal speaker.
- 10 The **Data Control Keys**, which include the step keys, knob, and numeric keypad, allow you to change the numeric value of an active function such as center frequency, start frequency, resolution bandwidth, and marker position.

The data controls will change the active function in a manner prescribed by that function. For example, you can change center frequency in fine steps with the knob, in discrete steps with the step keys, or to an exact (1 Hz resolution) value with the numeric keypad.

The **Knob** provides fine incremental changes of functions such as center frequency, reference level, and marker position. Clockwise rotation of the knob increases values. The extent of alteration is determined by the size of the measurement range. The speed at which the knob is turned affects the rate at which the values are changed.

For slow sweeps, the analyzer uses a smooth panning feature which is designed to move the trace display to the latest function value as the knob is turned. When center, stop or, start frequency or reference level is adjusted, the signal will shift right or left or up or down with the rotation of the knob before a new sweep is actually taken. An asterisk is placed in the message block (the upper right-hand corner of the analyzer display) to indicate that the data on the screen does not reflect data at the current setting.

The **Numeric Keypad** allows entry of exact values for many of the analyzer functions. You may include a decimal point in the number portion. If not, the decimal point is placed at the end of the number.

Numeric entries must be terminated with a units key. When a numeric entry is begun, the menu keys show the units key labels. The units keys change depending on what the active function is. For example, the units keys for frequency span are **GHz**, **MHz**, **kHz**, and **Hz**, whereas the units for reference level are **+dBm**, **-dBm**, **mV**, **μV**, and **μA**.

NOTE

If an entry from the numeric keypad does not coincide with an allowed function value (for example, that of a 12 MHz bandwidth), the analyzer defaults to the nearest allowable value.

The **Step Keys** (↓ ↑) increase or decrease the active function value. The step size depends upon the current analyzer measurement. Each press results in a single step change. For those parameters with fixed values (resolution bandwidth), the next value in a sequence is selected each time a step key is pressed. Step size is predictable (e.g., 10% of span for center frequency) and can be set for some functions (i.e., center frequency). Out-of-range values or out-of-sequence values will not occur using these keys.

- 11 **VOLUME.** The **VOLUME** knob adjusts the volume of the internal speaker. The speaker is turned on and off with the **Speaker On Off** key in the **Det/Demod** menu.
- 12 **EXT KEYBOARD.** The **EXT KEYBOARD** connector is a 6-pin mini-DIN connector. The keyboard can be used to enter screen titles and filenames.

NOTE

To avoid damage to the analyzer, always turn off power before plugging a keyboard into the analyzer.

- 13 **PROBE POWER** provides power for high-impedance ac probes or other accessories. (+15 V, -12.6 V, 150 mA maximum)
- 14 **LO OUTPUT** provides the proper local oscillator signal for use with external mixers (Option AYZ).
- 15 **IF INPUT** connects to the IF OUTPUT of the external mixer (Option AYZ).
- 16 **Return.** The **Return** key accesses the previously selected menu. Continuing to press **Return** accesses earlier menus. Return also terminates entry of alpha numeric functions (e.g., Title).
- 17 **AMPTD REF OUT** provides an amplitude reference signal of 50 MHz at -20 dBm. *Agilent ESA models E4402B, E4403B, E4404B, E4405B, E4407B, and E4408B only.*
- 18 **Tab Keys** are used to move around in the Limit editor, the Correction editor and similar table-driven forms.

19 **INPUT 50 Ω (INPUT 75 Ω for **Option 1DP)** is the signal input for the analyzer.**

CAUTION

When operating in dc coupled mode on analyzers with Option UKB, ensure protection of the input mixer by limiting the input level to 0 Vdc, +30 dBm.

When operating in ac coupled mode, ensure protection of the input mixer by limiting the input level to 50 Vdc, +30 dBm.

20 The **Next Window** key can be used to select the active window in functions which support split-screen display modes, such as Zone markers. (Refer to “Zone” in the User’s guide for more information.) In such modes, pressing **Zoom** allows you to switch between the split-screen and full-sized display of the active window.

21 **Help.** Press the **Help** key and then any front panel or menu key to get a short description of the key function and the associated SCPI command. The next key you press will remove the help window from the display.

22 **RF OUT 50 Ω** for Option 1DN or **RF OUT 75 Ω (for **Option 1DQ)** is the source output for the built-in tracking generator. Option 1DN or 1DQ only.**

CAUTION


If the tracking generator output power is too high, it may damage the device under test. Do not exceed the maximum power that the device under test can tolerate.

23 The | (On) key turns the analyzer on, while the Standby key turns most of the analyzer off. An analyzer alignment is performed (if **Auto Align** is on) every time the analyzer is turned on. After turning on the analyzer, allow 5 minutes of warm-up time to ensure the analyzer will meet all specifications.

NOTE

The analyzer continues to draw power even if the line power switch is in standby. The detachable power cord is the analyzer disconnecting device. It disconnects the mains circuits from the mains supply before other parts of the analyzer. The front-panel switch is only a standby switch and is not a LINE switch (disconnecting device).

Rear-Panel Features



pl72

- 1 **Power input** is the input for the ac line power source. Make sure that the line-power source outlet has a protective ground contact.
- 2 **DC Power** is the input for the dc power source. Refer to the “Power Requirements” section in the specifications guide for your analyzer.

CAUTION

AC line power and dc power should not be plugged in simultaneously.

- 3 **Line Fuse.** The fuse is removed by twisting counterclockwise 1/4 turn. Replace only with a fuse of the same rating. See the label on the rear panel.
- 4 **Service Connector.** The service connector is for service use only.

5 Inputs/Outputs (Refer to the specifications guide for more information.)

- 5a** **VGA OUTPUT** drives an external VGA compatible monitor with a signal that has 31.5 kHz horizontal, 60 Hz vertical synchronizing rate, non-interlaced.
- 5b** **GATE/HI SWP OUT (TTL)** is high when the analyzer is sweeping or when **Gate** (Option 1D6) is active.
- 5c** **GATE TRIG/EXT TRIG IN (TTL)** accepts the positive edge of an external voltage input that triggers the analyzer internal sweep source or the gate function (Time Gate, Option 1D6).

Table 2-6. and Table 2-7. show the appropriate rear panel slots to be used for the optional cards available with the Agilent ESA Spectrum Analyzers. Refer to Table 2-6. if you have an Agilent ESA-L Series Spectrum Analyzer. Refer to Table 2-7. if you have an Agilent ESA-E Series Spectrum Analyzer.

- (P) = Preferred Card Slot
- (A) = Acceptable Card Slot
- (-) = Unacceptable Card Slot

Table 1-1 Agilent ESA-L Series (E4403B, E4408B, E4411B)

Slot #	1	2	5	6
GPIB and Parallel (Option A4H)	P	A	-	-
Serial and Parallel Interface (Option 1AX)	P	A	-	-
IF, Video, and Sweep Ports (Option A4J)	-	-	P	-
Frequency Extension ¹		-	-	P

1. The Frequency Extension Assembly comes standard with the Agilent E4408B.

Table 1-2 Agilent ESA-E Series (E4401B, E4402B, E4404B, E4405B, E4407B)

Slot #	1 ¹	2	3	4	5	6
GPIB and Parallel Interface (Option A4H) ²	P	A	A	A	–	–
RS-232 and Parallel Interface (Option 1AX) ^b	P	A	A	A	–	–
Fast Time Domain Sweeps (Option AXX) ³	–	A	P	A	–	–
IF, Video, and Sweep Ports (Option A4J) ^c	A	A	A	A	P	A
FM Demodulation (Option BAA) ⁴	–	A	P	A	A	A
Frequency Extension ⁵	–	A	A	A	A	P
Digital Signal Processing and Fast ADC (Option B7D)	–	–	–	P	–	–
RF Communications Hardware (Option B7E)	–	–	–	–	P	–
ACPR Dynamic Range Extension (Option 120)	–	P	A	A	A	A
Bluetooth™ ⁶ FM Demodulation (Option 106) ^{d,7}	–	A	P	A	A	A

1. Some cards may not be installed due to mechanical interference.
2. Only one optional remote interface (Option A4H or Option 1AX) can be installed at a time.
3. Only one IF and Sweep Port option (Option A4J or Option AXX) can be installed at a time.
4. Only one demod option (Option BAA or Option 106) can be installed at a time.
5. The Frequency Extension Assembly comes standard with the Agilent E4404B, E4405B and E4407B.
6. Bluetooth™ is a trademark owned by its proprietor and used by Agilent Technologies under license .
7. Option 106 is required to make measurements in Bluetooth™ Measurement Personality (Option 228)

6 GPIB and parallel interface (Option A4H) is an optional interface. GPIB supports remote analyzer operation. A parallel port is included for printing only.

7 RS-232 and parallel interface (Option 1AX) is an optional interface. RS-232 supports remote analyzer operation. A parallel port is included for printing only.

NOTE Printing is only supported from the parallel port.

8 IF, Video, and Sweep Ports (Option A4J or Option AYX): (Refer to the specifications guide for more information.)

SWP OUT provides a voltage ramp corresponding to the sweep of the analyzer (0 V to 10 V).

HI SWP IN (TTL) can be grounded to stop and reset the sweep. Once the sweep has been stopped, removing the ground will trigger the start of a new sweep.

HI SWP OUT (TTL) is high when the analyzer is sweeping.

AUX VIDEO OUT provides detected video output (before the analog-to-digital conversion) proportional to vertical deflection of the trace. Output is from 0 V to 1 V. Amplitude-correction factors are not applied to this signal.

AUX IF OUT is a 50 Ω , 21.4 MHz IF output that is the down-converted signal of the RF input of the analyzer. Amplitude-correction factors are not applied to this signal. This output is taken after the resolution bandwidth filters and step gains and before the log amplifier.

NOTE

Only one IF and Sweep Port option (Option A4J or Option AYX) can be installed at a time.

9 FM Demod (Option BAA) allows you to demodulate, display, and measure deviation on FM signals. You can listen to audio signals on a built-in speaker or with an earphone. Refer to your Getting Started guide for more information.

Bluetooth™ FM Demodulation (Option 106) allows you to demodulate, display and measure deviation on Bluetooth™ signals. Refer to your Getting Started guide for more information.

- 10** **Frequency Extension Assembly** controls the microwave front-end components in the Agilent E4404B, E4405B, E4407B, and E4408B.
- PRESEL TUNE OUTPUT** provides a signal to control external preselected mixers if [External Mixing \(Option AYZ\)](#) is installed.
- 11** **Card Slot Identification Numbers.** Refer to Table 2-6. and Table 2-7. for card slot versus option card compatibility information.
- 12** **10 MHz REF IN** accepts an external frequency source to provide the 10 MHz, -15 to +10 dBm as a timebase.

NOTE

It is not necessary to connect the 10 MHz REF OUT to the 10 MHz REF IN on the rear panel of the analyzer. Doing so will result in a Frequency Reference Error message.

- 13** **10 MHz REF OUT** provides a 10 MHz, 0 dBm minimum, timebase reference signal.
- 14** **Power On Selection** selects an analyzer power preference.

The **PWR ALWAYS ON** setting turns the analyzer on whenever external power is applied. This mode is useful if an external power switch is used to control a rack of several instruments. Nevertheless, if you set the analyzer to standby using the front panel **Standby** key (see Figure 2-1. on page 22, item 23) and the external power is removed and restored within 20 seconds, the analyzer will remain in standby.

Power Always On		
Analyzer state before removing power	A lapse in power < 20 sec.	A lapse in power > 20 sec.
On	On	On
Standby	Standby	On

The **PWR NORM** setting assigns analyzer on/off control to the front-panel **On** and **Standby** keys (see Figure 2-1. on page 22, item 23). If the analyzer is on and the external power is removed and restored within 20 seconds, the analyzer will turn on. On the other hand, if the external power is removed and restored after 20 seconds, the analyzer will remain in standby regardless of the front panel switch settings.


Power Norm		
Analyzer state before removing power	A lapse in power < 20 sec.	A lapse in power > 20 sec.
On	On	Standby
Standby	Standby	Standby

- 15** DC Fuse protects the analyzer from drawing too much dc power. Replace only with a fuse of the same rating. See the label on the rear panel.

Display Annotation

Here is an example of the annotation that may appear on an analyzer display. The display annotation is referenced by numbers which are listed in the following table. The Function Key column indicates which key activates the function related to the annotation. Refer to your User's guide for more information on a specific function key.

Figure 1-1 Screen Annotation



pl727b

Table 1-3 Screen Annotation

Item	Description	Function Key
1 ¹	Detector mode	Detector
2	Reference level	Ref Level
3	Active function block	Refer to the description of the activated function.
4	Screen title	Change Title
5	Time and date display	Time/Date On Off

Table 1-3 Screen Annotation (Continued)

Item	Description	Function Key
6 ^{1,2}	RF attenuation	Attenuation Auto Man
7	Marker frequency	Marker or Marker Count On Off
8	Marker amplitude	Marker
9	GPIB annunciators	See Table 2-2. on page 32 for more information.
10 ³	Data invalid indicator	Sweep (Single) or View/Trace
11	Status Informational messages	See your Instrument Messages and Functional Tests manual for more information.
12	Key menu title	Dependent on key selection.
13	Key menu	See key label descriptions in the User's guide for more information.
14	Frequency span or stop frequency	Span or Stop Freq
15 ^a	Sweep time/Points	Sweep Time Auto Man, Sweep Points
16 ^a	Video bandwidth	Video BW Auto Man
17	Frequency offset	Freq Offset
18	Display status line	Displays analyzer status and error messages. Cleared by pressing Esc key. See your User's guide for more information.
19 ^a	Resolution bandwidth	Resolution BW Auto Man
20	Center frequency or start frequency	Center Freq or Start Freq
21	Signal track	Frequency, Signal Track
22	Internal preamp	Amplitude, Int Preamp
23 ⁴	Auto alignment routine is on	Auto Align
24	Amplitude corrections are on (This indicates that the overall correction state is On. There may be any or none of the individual corrections On.)	Correction On Off
25	Trigger/Sweep	Trig, Sweep See tables below for more information.
26	Trace mode	Trace See tables below for more information.

Table 1-3 Screen Annotation (Continued)

Item	Description	Function Key
27	Average	Average On Off V_{Avg} indicates video average on. P_{Avg} indicates power average on.
28	Display line	Display Line On Off
29	Amplitude offset	Ref Lvl Offst
30	Amplitude scale	Scale Type Log Lin

1. A # in front of any display annotation indicates that the function is uncoupled. (Refer to your User's guide)
2. When the analyzer is set to the external mixer state (Option AYZ), item 6 changes to display $Ext\ Mix$ in place of $Atten\ XdB$. In addition, if Mixer Bias is on, a +I or -I is appended to $Ext\ Mix$.
3. When the (*) is displayed, it means that some or all trace data may not match the annotation due to possible changes in analyzer settings.
4. **AA** indicates that auto alignment of all analyzer parameters, except the tracking generator and FM demodulation options, will occur. **AB** indicates that auto alignment of all analyzer functions except the RF section (and tracking generator and FM demodulation options) will occur. No indicator will appear if auto alignment is off.

Refer to the following tables for the screen annotation codes for trace, trigger, and sweep modes.

Table 1-4 Screen Annotation for GPIB Annunciators

Screen Annotation	Description
R	Remote Operation
L	GPIB Listen
T	GPIB Talk
S	GPIB SRQ

Table 1-5 Screen Annotation for Trigger Mode

Screen Annotation	Description
F	Free Run
L	Line
V	Video
E	External
T ¹	TV
B ²	RF Burst

1. Option BAA and B7B only.
2. Option B7E only.

Table 1-6 Screen Annotation for Sweep Mode

Screen Annotation	Description
C	Continuous
S	Single Sweep

Table 1-7 Screen Annotation for Trace Mode

Screen Annotation	Description
W	Clear Write
M	Maximum Hold
V	View
S	Store Blank
m	Minimum Hold
1	Trace 1
2	Trace 2
3	Trace 3

Key Overview

The keys labeled **FREQUENCY Channel**, **System**, and **Marker** are all examples of front-panel keys. The front-panel keys are dark gray, light gray, green, or white in color. Front-panel keys that are white perform an immediate action rather than bringing up a menu. The only green key is the **Preset** key, which performs an analyzer reset (A summary of all front panel keys and their related menu keys can be found in user's guide for your analyzer). Pressing most of the dark or light gray front-panel keys accesses menus of functions that are displayed along the right side of the display. These are called menu keys.

Menu keys list functions other than those accessed directly by the front panel keys. To activate a menu key function, press the key immediately to the right of the annotation on the screen. The menu keys that are displayed depend on which front-panel key is pressed and which menu level is enabled.

If a menu key function's value can be changed, it is called an active function. The function label of the active function is highlighted after that key has been selected. For example, press **AMPLITUDE Y Scale**. This calls up the menu of related amplitude functions. Note the function labeled **Ref Level** (the default selected key in the Amplitude menu) is highlighted. **Ref Level** also appears in the active function block, indicating that it is the active amplitude function and can now be changed using any of the data entry controls.

A menu key with **On** and **Off** in its label can be used to turn the menu key's function on or off. To turn the function on, press the menu key so that **On** is underlined. To turn the function off, press the menu key so that **Off** is underlined. In the manual, when **On** should be underlined, it will be indicated as **Function (On)**.

A function with **Auto** and **Man** in the label can either be auto-coupled or have its value manually changed. The value of the function can be changed manually using the numeric keypad, knob, or step keys. To auto-couple a function, press the menu key so that **Auto** is underlined. In the manual, when **Auto** should be underlined, it will be indicated as **Function (Auto)**.

In some key menus, one key label will always be highlighted to show which key has been selected. For example, when you press **Marker**, you will access a menu of keys in which some of the keys are grouped together by a blue bar (on analyzers with a color display) on the left side of the menu. The **Normal** key, which is the **Marker** menu default key, will be highlighted. When you press another key within the blue bar region, such as **Delta**, the highlight will move to that key to show it has been selected.

In other key menus, one key label will always be highlighted to show which key has been selected but the menu is immediately exited when a selection is made. For example, when you press the **Orientation** key (on the **Print Setup** menu), it will bring up its own menu of keys. The **Portrait** key, which is the Orientation menu default key, will be highlighted. When you press the **Landscape** key, the highlight will move to that key to show it has been selected and the screen will return to the **Print Setup** menu.

Making a Basic Measurement

This section provides information on basic analyzer operation. For more information on making measurements, see the measurement guide for your analyzer.

Here you will learn the following:

- [“Using the Front Panel” on page 29.](#)
- [“Presetting the Spectrum Analyzer” on page 30.](#)
- [“Viewing a Signal” on page 31.](#)

CAUTION

Ensure that the total power of all signals at the analyzer input does *not* exceed +30 dBm (1 watt).

Basic Assumption

The material in this section is presented with the assumption that you understand the front and rear panel layout of the analyzer, and display annotations. If you do not, refer to [“Front-Panel Connectors and Keys” on page 11](#) and [“Rear-Panel Features” on page 16](#).

Using the Front Panel

Entering Data


When setting measurement parameters, there are several ways to enter or modify the value of the *active* function:


Knob	Increments or decrements the current value.
Arrow Keys	Increments or decrements the current value.
Numeric Keypad	Enters a specific value. Then press the desired terminator (either a unit softkey, or the Enter hardkey).
Unit Softkeys	Terminate a value that requires a unit-of-measurement.
Enter Key	Terminates an entry when either no unit of measure is needed, or you want to use the default unit.

Using Menu Keys


Menu Keys (which appear along the right side of the display) provide access to many analyzer functions. Here are examples of menu key types:

Toggle Allows you to activate/deactivate states.

Example:  Toggles the selection (underlined choice) each time you press the key.




Submenu Displays a new menu of softkeys.

Example:  A submenu key allows you to view a new menu of softkeys related to the submenu key category.






Choice Allows you to make a selection from a list of values.

Example:  A choice key displays the currently selected submenu choice, in this example, dBm. When the choice is made, the submenu automatically returns.



Adjust Highlights the softkey and sets the active function.

Examples:  Press this type of key and enter a value.



The default for softkeys with an automatic (**Auto**) or manual (**Man**) choice is automatic. After you enter a value, the selection changes to manual. You can also press the softkey twice to change to manual.

Presetting the Spectrum Analyzer

Preset provides a known starting point for making measurements. The analyzer has three types of preset:

- Factory Preset** Restores the analyzer to its factory-defined state.
- User Preset** Restores the analyzer to a user-defined state.
- Mode Preset** This type of preset restores the currently selected mode to a known state.

For details, see the User's guide.

When **Preset Type** is set to **Factory**, pressing the green **Preset** key triggers a factory preset. When **Preset Type** is set to **User**, pressing **Preset** displays the softkeys **Factory Preset**, **User Preset**, and **Mode Preset** (if applicable); you then select the preset you want. If **Preset Type** is set to **Mode**, but a personality is not installed, pressing **Preset** triggers a factory preset.

Creating a User Preset

If you constantly use settings which are not the factory defaults, use the following steps to create a user-defined preset:

1. Set analyzer parameters as desired.
2. Press **System, Power On/Preset, Save User Preset** to set the current parameters as the user preset state.
3. Press **Preset** to select **User** in the same softkey menu to enable user preset as an option.

Disabling User Preset

Go to the **Power On/Preset** menu (press **System, Power On/Preset**) and select a **Preset Type** of **Factory** or **Mode**.

Viewing a Signal

1. Press **Preset**. If the softkeys **Factory Preset** and **User Preset** appear, select **Factory Preset**.
2. Connect the analyzer's rear panel **10 MHz REF OUT** to the front-panel input.

Setting Reference Level and Center Frequency


NOTE

The display examples in this section are made using various analyzer models, you may see some variations depending upon your analyzer.

3. Set the reference level to 10 dBm: Press **AMPLITUDE**, **10**, **dBm**.
4. Set the center frequency to 30 MHz: Press **FREQUENCY**, **Center Freq**, **30**, **MHz**.

The 10 MHz reference signal spectrum appears on the display, as shown in [Figure 1-2](#).

Figure 1-2 10 MHz Internal Reference Signal and Associated Spectrum




Setting Frequency Span

5. Set the frequency span to 50 MHz: Press **SPAN**, **5**, **0**, **MHz**.

This displays the signal as shown in [Figure 1-3](#).

Figure 1-3 Span Changed to 50 MHz



Reading Frequency & Amplitude

6. Place a marker (labeled 1) on the 10 MHz peak, as shown in [Figure 1-4](#).

Press **Peak Search**.

Note that the frequency and amplitude of the marker appear both in the active function block, and in the upper-right corner of the screen. You can use the knob, the arrow keys, or the softkeys in the Peak Search menu to move the marker. Pressing **Esc** removes the value from the display.

7. If you have moved the marker, return it to the peak of the 10 MHz signal.

Changing Reference Level

8. Press **AMPLITUDE**, and note that reference level (Ref Level) is now the active function. Press **Marker** →, **Mkr** → **Ref Lvl**.

Note that changing the reference level changes the amplitude value of the top graticule line.

Figure 1-5 shows the relationship between center frequency and reference level. The box represents the analyzer display. Changing the center frequency changes the horizontal placement of the signal on the display. Changing the reference level changes the vertical placement of the signal on the display. Increasing the span increases the frequency range that appears horizontally across the display.

Figure 1-4 A Marker on the 10 MHz Peak





Figure 1-5 Relationship Between Frequency and Amplitude



bd21_5l.cdr

Improving Frequency Accuracy

9. While not all of the zeros following the decimal in the active function block are significant, the numbers after the decimal in the marker annotation (upper-right corner of screen) *are* significant. To improve the accuracy of the frequency reading in the marker annotation, turn on the frequency count function by pressing **Freq Count**.
10. Note softkey **Marker Count On Off**. If **Off** is underlined, press the softkey to toggle marker count on.

As shown in [Figure 1-6](#):

- The marker annotation changes from **Mkr1** to **Cntrl**.
- The displayed resolution in the marker annotation improves.


NOTE

When you use the frequency count function, if the ratio of the resolution bandwidth to the span is less than 0.002, the following message appears on the display: **Marker Count: Widen Res BW**

This indicates that the resolution bandwidth is too narrow.

11. Press **Marker →, Mkr → CF** to move the 10 MHz peak to the center of the display.

Figure 1-7 Using Marker Counter



Analyzer Accuracy and the Internal Alignment Process

Data from the internal alignment routine is necessary for spectrum analyzer operation. The internal alignment routine runs continuously to ensure that the analyzer is using current alignment data that improves the analyzer frequency and amplitude accuracy. Press the **System, Alignments** keys to view the alignment menus. For more detailed information on the alignment keys, refer to [“Alignments” on page 259](#).

Warm-up Time

In order for the analyzer to meet published specifications, allow it to warm up for 5 minutes after being turned on before attempting to make any calibrated measurements. If the analyzer is an Agilent E4402B, E4403B, E4404B, E4405B, E4407B, or E4408B, connect a BNC cable between AMPTD REF OUT and INPUT 50 Ω using an adapter. After a 5 minute warm-up, press **System, Alignments, Align Now, All**. If the analyzer is equipped with a 3.0 GHz tracking generator (Option 1DN on Agilent E4402B, E4403B, E4404B, E4405B, E4407B, or E4408B), connect a short cable from AMPTD REF OUT to INPUT 50 Ω , and press **System, Alignments, Align Now, TG**. If the analyzer is equipped with FM Demod (Option BAA) or Bluetooth™ FM Demodulation (Option 106), press **System, Alignments, Align Now, FM Demod**. If **Auto Align Off** is selected, refer to the analyzer specifications for the conditions required to maintain calibration.

NOTE

Under certain conditions the warm-up time may vary. For more information about warm-up times and the special conditions that may affect them, refer to the specifications guide for your instrument.

File Menu Functions

This section describes how to use the functions located under the front-panel **File** key. Data storage and retrieval are handled similarly to that of personal computers (PCs). Like PCs, these analyzers include an internal storage drive and a floppy disk drive, both of which have directory and sub-directory capability.

NOTE

The descriptions in this section assume the analyzer has firmware revision A.04.00 or later. The file menu functions in earlier firmware are different. If you would like to upgrade your analyzer to the latest firmware revision, please visit the following web site:

<http://www.agilent.com/find/esa>

You will learn how to do all of the following:

- locate and view files in the catalog
- create a directory
- format a floppy disk
- save a file
- load a file
- rename a file
- copy a file
- delete a file

NOTE


The display examples in this section are made using various analyzer models, you may see some variations depending upon your analyzer.

Locating and viewing files in the catalog

Techniques for locating files and directories are consistent throughout the various file menu functions. Although this section provides specific information about navigation in the catalog, you may wish to refer back to this section when performing other operations of the file menu.

Press **File, Catalog** to bring up a screen display as shown in Figure 4-1.

Figure 1-8 Catalog Menu



pl72e

1. The entry fields show the parameters for the files viewed. Entry fields that are being modified or are modifiable are indicated by highlighting (inverse video). Each file menu function has its own unique set of entry fields pertaining to that function. Below are the fields listed under the catalog key:
 - a. Name: field states the filename.
 - b. Show Type: field displays the type of files viewed.
 - c. Path: field displays the drive and directory location of the files.

2. The directory information box displays the drives, directories, and/or files currently described in the entry fields. Highlighting a row of information selects that location and updates the entry fields. There are four column headings in this area of the display. They are described as follows:
 - a. **Name:** column states the drive ([-A-] or [-C-]) if at the top level on the drive, directory name, or filename.
 - b. **Type:** column displays the extension of the filename, for example, .SET, .STA, .TRC. Directories are displayed as DIR and drives have nothing listed under **Type:**. They are only designated by the **Name:** column ([-A-] or [-C-]).
 - c. **Size:** column displays the size of the file in bytes.
 - d. **Modified:** column displays the date and time the last change occurred.
3. The softkey menu has four options:
 - a. **Type:** allows you to choose the type of file you wish to view. (You may view all types by using the **All** key under **Type**.)
 - b. **Sort:** Under the **Sort** key, you can sort by any of the four columns and you can choose up (ascending) or down (descending).
 - c. **Dir Up:** moves you up one directory level. If you are already at the top level, this key moves you up to the drive level, displaying the available disk drives.
 - d. **Dir Select:** moves you down into the highlighted directory or up into the next level (directory or drive) if the “. .” under the **Name:** column is highlighted.

NOTE

Navigation keys: Use the front-panel **Step Keys** or **Knob** and the **Dir Up** or **Dir Select** keys to move around in the directory information box.

4. The drive space line shows the number of bytes used on the drive and the number of bytes still free on the drive.

Creating a directory

Directories and sub-directories can be created on both the A: floppy disc and the internal C: drive. This allows maximum flexibility in organizing files. For this example, we will create a directory on the C: drive.

1. Press **File, More 1 of 2, Create Dir**. Your screen should look similar to Figure 4-1, except the entry fields will be `Dir Name:` and `Path:` and the Heading will read: `Directories`.
2. Navigate through the file system until the `Path:` field displays `C:\`. (Use the Step Keys, Knob, Dir Up, and/or Dir Select keys.)
3. Press **Name** and enter the name, "START" using the Alpha Editor. (The numeric keypad is also available for the filename.) Press **Enter** (hardkey) when the `Dir Name:` field contains this directory title. (Use the **Bk Sp** hardkey on the front panel to make corrections.)
4. Press **Create Dir Now** to execute the operation. The message: `Creating Directory` appears on the screen. Then the status bar displays: `Directory C:\START created`.
5. To make a sub-directory, scroll down to the `START` directory you just created and press **Dir Select**. The `Path:` field should now read: `C:\START\`. Repeat Steps 3 and 4 above, using a *new name*. The status bar now should read: `Directory C:\START\new name created`.

Formatting a Floppy Disk

You can format a floppy disk in the analyzer. The format is MS-DOS®¹. Note that it is not necessary to format your floppy disk with the analyzer; preformatted disks can be used with the analyzer.


1. Place the 1.44-MB disk you wish to format into the floppy drive (A:\) of the analyzer. Only 1.44-MB floppy disks are supported by the analyzer. Therefore, 720-kB floppy disks will not work reliably.
2. Access the **Format** key by pressing **File**, **More**, and then **Format**. The directory information box is active (highlighted), however, only the floppy disk volume [-A-] is shown on the display.

The directory information box displays all files present on the floppy disk inserted in drive "A:". If you have not inserted a disk into drive "A:", or the disk you are attempting to format has no pre-existing formatting, the error message: bad, missing, or unformatted disk is displayed in the status line.

3. Press **Format Now**. The following message appears in the display window: WARNING: You are about to destroy ALL data on Volume A:. Press Format Now again to proceed or any other key to abort. **To abort disk format, press any key but Format Now.** *When a disk is formatted, all data on the disk is destroyed.*
4. Press **Format Now** a second time to format the disk. You will see the message: Formatting Disk in the display window. Pressing any other key after receiving the warning in step 3 on [page 42](#), will abort the formatting process. See Figure 4-2. The format process takes approximately three minutes.

1. MS-DOS® is a U.S. registered trademark of Microsoft Corporation.

Figure 1-9 **Format Menu**



5. When formatting is complete, a message, Volume A: formatted appears on the status line. The disk is now ready to save files.


Saving a File

You can save files (setups, states, traces, limits, corrections, measurement results, or screens) to a floppy disk (A:\), or the internal drive (C:\). In this example you will save a trace to the internal C: drive.

Step 1. Set up the analyzer trace


1. Perform a factory preset by pressing **Preset, Factory Preset** (if present).
2. Turn on the internal 50 MHz alignment signal of the analyzer as follows:
 - For the *Agilent E4401B and E4411B*, use the internal 50 MHz alignment signal of the analyzer as the signal being measured. Press **Input/Output, Amptd Ref (On)**.
 - For all other models connect a cable between the front-panel **AMPTD REF OUT** to the analyzer **INPUT**, then press **Input/Output, Amptd Ref Out (On)**.
3. Set the center frequency to 50 MHz by pressing **FREQUENCY, Center Freq, 50, MHz**.
4. Set the span to 75 MHz by pressing **SPAN, Span, 75, MHz**. The reference signal will appear on the display.
5. View trace 1 and put it into maximum hold by pressing **View/Trace, Max Hold**. (Trace 1 should already be underlined, but if not, press **Trace 1 2 3** until 1 is underlined and then press **Max Hold**.) Your analyzer display should look similar to Figure 4-3.

Figure 1-10 Viewing Trace 1




6. Activate trace 2 and put it into minimum hold by pressing **Trace (2)**, **Min Hold**. Your analyzer display should look similar to Figure 4-4.

Figure 1-11 Viewing Traces 1 and 2



7. Activate trace 3 by pressing **Trace (3)**, **Clear Write**. Your analyzer display should look similar to Figure 4-5.

Figure 1-12 Viewing Traces 1, 2, and 3



Step 2. Save the file

1. To access the **Save** menu, press, **File, Save**.
2. Select the type of file you want to save. In this example you are saving a trace; press **Type, Trace**.
3. Select the trace you wish to save (1, 2, 3, or all traces). In this example you will save trace 3; press **Source (softkey), Trace 3**.
4. Select the format you wish to use for saving the trace, either trace plus state (**Trace + State**) or comma separated value (**CSV**). In this example you will save as trace plus state; press **Format, Trace + State**.

5. Enter a filename by pressing **Name**. The Alpha Editor appears. For this example you will name the file, "TEST1". (The numeric keypad is also available for the filename.) Note that the file extension is always set by the system and for this file type the extension is `TRC`. You must now press the **Enter** (hardkey) to get back to the **Save** menu.

NOTE

You need to use a filename that does not already exist in the current directory. The filename is limited to eight characters, alpha (A-Z) or numeric (0-9) in any combination. The analyzer will not allow you to overwrite an existing file. If you select a filename that already exists, the status bar will display the message: `File already exists`. If you do not choose a filename, the analyzer will automatically generate a name based on the type of file you are saving (Setup: `SETUP`, State: `STATE`, Trace: `TRACE`, Limits: `LIMIT`, Corrections: `CORREC`, Screen: `SCREEN`). It also generates a three digit integer (starting at 000 and extending through 999, remembering the previously saved value through a power cycle) which it adds to the name, for example: `TRACE056.TRC`. Also note that this three digit integer increments upon each attempted save until a unique filename is created, without regard to the success of the save.

-
6. The destination for the saved file is shown in the `Path:` field. In this example, you will select the path as `C:\START\`. If the correct location is not listed in the `Path:` field, change directories as follows:
 - a. Press **Dir Up** or **Dir Select** and use the step keys or knob, to highlight the desired destination directory.
 - b. Press **Dir Select** and confirm your choice displayed in the `Path:` field.
 7. Press **Save Now** or **Save** (hardkey) to save the file to the `C:\Start\` location. The message `Saving Now` is displayed during this operation. For this example, the status line displays:
`C:\START\TEST1.TRC file saved.`

NOTE

When saving to drive (A:), never remove the floppy disk during the save operation. To do so could corrupt *all* data on the floppy disk.

Loading a file


1. Reset the analyzer by pressing **Preset, Factory Preset** (if present).
2. To access the **Load** menu, press **File, Load**.
3. Select the type of file you want to load (setup, state, trace, limits, or corrections). In this example you are loading a trace file; press **Type, Trace**.

NOTE

Not all file types can be loaded back into the analyzer. For example, Screen files and CSV (comma separated value) files cannot be loaded. CSV and Screen files are designed for use with a PC.

4. Select the directory where your file is located. In this example, select the **C:\START** directory. (Use the front-panel step keys, knob, **Dir Up**, and/or **Dir Select** keys to locate the directory.)
5. Select the file you want to load into the analyzer by moving the cursor with the front-panel knob to highlight the file name. In this example the file is **TEST1.TRC**. Select the trace into which you wish to load the file. In this example, load it into Trace 2. (**Destination, Trace 2**).
6. Press **Load Now** to load the specified file. Your display should look similar to Figure 4-6. The status bar reads: **C:\START\TEST1.TRC file loaded**.


Figure 1-13 File Loaded



NOTE You should notice that the trace you saved, in this example trace 3, is loaded to trace 2. If you wish to verify this condition, remove the signal input. For Agilent E4401B and E4411B, press **Input/Output, Amptd Ref (Off)**, for all other models, press **Input/Output, Amptd Ref Out (Off)**.

Note that when a trace is loaded, it is placed in view mode. To see that trace 2 is in view mode, blank traces 1 and 3 by pressing **View/Trace, Trace 1, Blank, Trace 3, Blank**. Then press **Trace 2**. Notice that trace 2 is the only trace displayed in view mode (the view key is selected, and the trace is not sweeping). Your display should look similar to Figure 4-7.

Figure 1-14 Verifying Trace 1




CAUTION When operating in dc coupled mode, ensure protection of the input mixer by limiting the input level to 0 Vdc and +30 dBm.

NOTE When loading Limits files, be sure you have selected the appropriate X Axis Units: frequency or time (Display, Limits, Properties, X Axis Units). If you are in time X-Axis Units, and you load frequency limits, all current limit line data will be erased and the analyzer will switch to the frequency domain. The reverse of the this situation also holds true.

Renaming a File

1. To access the **Rename** menu, press **File, Rename**.
2. Select the type of file you want to rename (setup, state, trace, limits, screens, or corrections). In this example you are renaming a trace file; press **Type, Trace**.
3. Select the drive and directory where your file is located. In this example, choose drive **C:\START**.
4. Select the file you want to rename. In this example, choose the file **TEST1.TRC**.
5. Press **Name** to open the Alpha Editor menu. For this example, rename the file to **RENAME** using the Alpha Editor softkeys. (The **Name:** field is limited to eight characters.) Your display should look similar to Figure 4-8.
6. Press **Enter, Rename Now:** your file is now renamed and visible within the directory displayed on your analyzer. The status line displays the message: **C:\START\TEST1.TRC file renamed to C:\START\RENAME.TRC.**


Figure 1-15 Renaming a File



Copying a File

1. To access the Copy menu, press **File, Copy**. This menu function brings up 2 directory boxes as described by the **From:** and **To:** fields located directly above the boxes. Refer to Figure 4-9.

Figure 1-16 Copy Menu



2. Put a formatted floppy in the A: drive.
3. Select the type of file you want to copy (setup, state, trace, limits, screens, or corrections). In this example you are copying a trace file from the C: drive to the A: drive; press, **Type, Trace**.
4. Press **Dir** (in the key menu) to underline **From:.** Notice the **From:** field (just above the top directory box) highlights the location from which you will be copying. Using the navigation keys (**Dir Up**, **Direct select**, step keys, or front panel knob), locate the C:\START\ directory.
5. Scroll to highlight the file displayed in the directory box from which you wish to copy. In this example, you will need to highlight the file RENAME.

6. Press **Dir** (in the key menu) to underline **To:**. The **To:** field (just above the bottom directory box) is highlighting the location to which you will be copying. Using the navigation keys as described above, highlight the **A:** drive.

NOTE When pressing **Dir (To)**, the file chosen in the **From:** location is no longer highlighted, however the **Name:** field above the **From** directory box displays the chosen file; in this example: **RENAME.TRC**.

NOTE Highlighting a filename in the **To:** directory box has no significance. The file cannot be placed inside another file.

7. Press **Copy Now** to execute the operation. The message: "Copying file" is displayed during the copying process. Upon completion, the status bar reads: "C:\START\RENAME.TRC file copied". You have now copied the file **RENAME** from the **C:** drive to the **A:** drive.

Deleting a File

1. To access the Delete menu, press **File, Delete**.
2. Select the type of file you want to delete (setup, state, trace, limits, screens, or corrections). In this example, you are deleting a trace file; press **Type, Trace**.
3. Select the drive and directory where the file you wish to delete is located. In this example, choose **C:\START**. Use the navigation keys (**Dir Up, Dir Select, step keys, front panel knob**) to highlight this location in the **Path:** field. (Refer to "[Locating and viewing files in the catalog](#)" on page 39 for more instructions.)
4. Select the file you want to delete. In this example, choose the file **RENAME.TRC**. Move the cursor with the navigation keys to highlight the file name.
5. Press **Delete Now**. The message: **Deleting file** pops up on the display during the operation. Upon completion, the status bar reads: **C:\START\RENAME.TRC file deleted**. Your file is now deleted and is no longer visible in the directory displayed on your analyzer.

Using the Alpha Editor

The Alpha Editor enables you to select letters to enter a name for a file or directory (**File**, **Rename**, for example).

1. Use the **More** keys to display the softkey that lists the character you want. Each softkey has several characters on it.
2. When you press a softkey, its characters are displayed on individual softkeys.
3. Select the one you want.

Printer Setup and Operation

A printer can be connected to your analyzer if it is equipped with an external I/O interface. Supported printers accept Hewlett-Packard Printer Control Language Level 3 (PCL3) or 5 (PCL5). Refer to the documentation or specifications supplied with your printer, or contact the manufacturer to identify your printer's language.

Equipment

- IEEE 1284 compliant printer cable.
- Supported and tested printers are listed below. Note that there are many PCL3/5 printers that may work with your analyzer, however, they have not been tested.
 - PCL3 printers include most HP DeskJet printers.
 - PCL5 printers include most HP LaserJet printers.

NOTE

The following printers are not compatible with your analyzer.

- HP Deskjet 720C, 722C, 820C and 1600C
 - Epson MX-80, FX-85, Stylus, and LQ-570
-

Printer Models	Language Type	Color Capable
HP DeskJet 310, 320, 350C, 400L	PCL3	yes
HP DeskJet 500C, 550C, 600, 660C, 672C, 680C, 682C, 690C, 693C	PCL3	yes
HP DeskJet 840C, 850C, 870C, 890C, 895C	PCL3	yes
HP DeskJet 935C, 970C, 990C	PCL3	yes
HP DeskJet 1120C, 1150C	PCL3	yes
HP Inkjet 2000C	PCL 3	yes
HP LaserJet III	PCL3/5	no
HP LaserJet 4P	PCL3/5	no
HP LaserJet 5L, 5M, 5N, 5P, 5SI	PCL3/5	no
HP LaserJet 6L, 6MP	PCL5	no
HP LaserJet 2100 Series,	PCL3/5	no
HP LaserJet 4050N	PCL3/5	yes
HP LaserJet 5000GN	PCL3/5	yes
HP Professional Series 2500CM	PCL3	yes
HP Professional Series 2500CM	PCL3	yes

Interconnection and Setup

1. Turn off the printer and the analyzer.
2. Connect the printer to the analyzer parallel I/O interface connector using an IEEE 1284 compliant parallel printer cable.
3. If appropriate, configure your printer using configuration menus or switches. Refer to your printer's documentation for more specific information on configuring your printer.
4. Turn on the analyzer and printer.
5. Press **Print Setup** on the front panel and then press the **Printer Type** menu key. **Printer Type** accesses the following keys:

None **None** disables the analyzer from attempting to print to a printer. This is the appropriate setting if no printer is connected to the analyzer.

Custom **Custom** allows you to access the **Define Custom** menu keys. The **Define Custom** menu keys allow you to specify printer characteristics such as PCL Level and printer color capability.

Auto **Auto** enables the analyzer to automatically attempt to identify the connected printer when the **Print** key is pressed or when **Printer Type** is set to **Auto**.

6. Press **Printer Type** to access the **Printer Type** menu keys. Press **Auto** to make the analyzer attempt to identify the connected printer. When you press **Auto**, the analyzer will respond in one of the three following ways:

- The **Print Setup** menu will be displayed with the **Auto** key selected and no new message will be displayed in the display status line. This indicates that the analyzer has successfully identified the connected printer and no further setup is required. As long as **Auto** remains selected in the **Printer Type** menu, the analyzer will attempt to identify the printer when the front panel **Print** key is pressed. The selected printer will be displayed by pressing **System, More 1 of 3, Show System**.
- The **Print Setup** menu will be displayed with the **Custom** key selected and one of the following diagnostic messages will be displayed in the display status line:

Unknown printer, Define Custom to set up printer

No printer response, Define Custom to set up printer

Invalid printer response, Define Custom to set up printer

This indicates that the analyzer was unable to automatically identify the connected printer, and **Custom** has been selected in the **Printer Type** menu. Press **Print Setup, Define Custom** to select specific printer characteristics such as the printer language (PCL3 or PCL5) and color printing capability. Once you have set these characteristics to match those of your connected printer, the printer setup process is complete. As long as **Custom** remains selected in the **Printer Type** menu, the analyzer will not attempt to automatically identify the connected printer when the front panel **Print** key is pressed.

- The **Print Setup** menu will be displayed with the **None** key selected and the following message will appear in the display status line:

Unsupported printer, Printer Type set to None

This indicates that the analyzer has successfully identified the connected printer, but the printer is not supported by the analyzer. As long as **None** is selected in the **Printer Type** menu, the analyzer will respond to any print command by displaying the message `Printer Type is None` in the display status line.

7. Select the desired paper size by pressing **Print Setup, More, Page Size**, then choose the appropriate page size for which your printer is configured. This setting will remain unchanged with **Preset** or **Power Cycle**.

The factory default page size is **Letter**. The page size will be reset to **Letter** if **System, More, Restore Sys Defaults** is executed.

Testing Printer Operation

When you have completed the analyzer's printer setup, press **Print Setup**, then press **Print** on the front panel. If the printer is ready and the printer setup was successful, a printout of the analyzer display will be printed. If the printer is not ready, the message `Printer Timeout` will appear on the analyzer display. `Printer Timeout` will remain on the display until the printer is ready or until you press **ESC** to cancel the printout request.

NOTE

There may be some small discrepancies in the color mapping of the analyzer display to your color printer. Due to differences in display and printer technologies, the default display colors do not map exactly to the printer colors. For example trace 1 is yellow on your analyzer display while it maps to green on your printer.

Analyzer Battery Information

The analyzer uses a lithium battery to enable the internal memory to retain data. The date when the battery was installed is on a label on the rear panel of the analyzer. See [Figure 1-17](#).

The minimum life expectancy of the battery is 7 years at 25 °C, or 1 year at 55 °C. If you experience problems with the battery or the recommended time period for battery replacement has elapsed, see “How to Return Your Analyzer for Service” in the Getting Started Guide for your instrument.

If you wish to replace the battery yourself, you can purchase the service documentation that provides all necessary test and maintenance information.

You can order the service documentation for an Agilent ESA spectrum analyzer through your Agilent Sales and Service office. The documentation is described in your Getting Started Guide.

After replacing the analyzer battery, write the date of battery replacement on the rear-panel label.

Figure 1-17

Rear-Panel Battery Information Label



pb930a

2

Menu Maps

This chapter provides a visual representation of the front panel keys and their associated menu keys when the analyzer is in spectrum analyzer (SA) mode. Refer to [Chapter 3 , “Front-Panel Key Reference,”](#) on page 97 for key function descriptions.


What You Will Find in This Chapter

This chapter provides menu maps for the front-panel keys having associated menus. The Alpha Editor Menu is associated with many keys, but is shown separately. The front-panel key menus appear in alphabetical order as follows:

Table 2-1

Alpha Editor Menus	Page 61
AMPLITUDE Y Scale	Page 62, Page 63
Auto Couple	Page 64
BW/Avg	Page 65
Det/Demod	Page 66
Display	Page 67
File	Page 68, Page 69, Page 70
Freq Count	Page 71
FREQUENCY Channel	Page 72
Input/Output	Page 73
Marker	Page 74
Marker →	Page 75
Meas Control	Page 76
Meas Setup	Page 77, Page 78, Page 79
MEASURE	Page 80
Mode Setup	Page 81
Peak Search	Page 82
Preset	Page 83
Print Setup	Page 84
Source	Page 85
SPAN X Scale	Page 86
Sweep	Page 87
System	Page 88
Trace/View	Page 89, Page 90, Page 91, Page 92, Page 93, Page 94, Page 95
Trig	Page 96


AMPLITUDE Y Scale Menu



- a. Agilent E4404B, E4405B, E4407B and E4408B only
 - b. ESA-E Series only (E4401B, E4402B, E4404B, E4405B and E4407B)
 - c. Grayed out in FM Demod. **Demod View (On)**
 - d. Not available in External Mixing Mode (Option AYZ)
 - e. Available only with Option 1DR (Narrow Resolution Bandwidth) and firmware revision \geq A.06.00
 - f. Grayed out when Demod View is accessed through Option 106 (Bluetooth FM Demodulation)
- * An active function which allows data entry

pl749b


Amplitude Y Scale: Corrections Menu



* An active function which allows data entry

pl750b


Auto Couple Menu



a. Not available on models E4401B and E4411B.

p1753b


BW/Avg Menu



a. Available only with Option 1DR (narrow resolution bandwidth) and spans < 5MHz
 * An active function which allows data entry

pi754b


Det/Demod Menu



- a. Agilent ESA-E Series only (E4401B, E4402B, E4404B, E4405B and E4407B)
- b. Available only with Option BAA (FM Demod) or Option 106 (Bluetooth FM Demodulation)
- c. Grayed out unless **AM** or **FM Demod** is on
- d. Grayed out when span = 0 Hz
- e. Turns the speaker on
- f. Turns the speaker off
- * An active function which allows data entry

pl756b


Display Menu



* An active function which allows data entry


pl758b

File Menus (1 of 3)



- a. Grayed out if no directory selected.
- b. Continued on sheet 1 of 3.
- c. Continued on sheet 3 of 3.
- d. Available only when **Type** is set to **Trace** or **Screen**.
- e. Available only when **Type** is set to **Trace**, **Limits**, or **Corrections**.


File Menus (2 of 3)



- a. Grayed out if no directory selected.
- b. Continued on sheet 1 of 3.
- c. Continued on sheet 3 of 3.
- d. Only available when **Type** is set to **Trace** or **Limits**.

pl73d


File Menus (3 of 3)



- a. Grayed out if no directory selected.
- b. See sheet 1 of 3.
- c. Continued on sheet 2 of 3.

pl760b

Freq Count (Marker) Menu




* An active function which allows data entry

a. Not available when **Frequency, Scale Type (Log)** is selected.

pl76


FREQUENCY Channel Menu



- a. Not available when **FREQUENCY, Scale Type (Log)** is selected.
b. Agilent ESA-E Series only (E4401B, E4402B, E4405B and E4407B)
* An active function which allows data entry

pl763b


Input/Output Menu



- a. Agilent E4402B or E4407B with Option UKB, E4404B, and E4405B only
- b. Key label is **Amptd Ref** for E4401B and E4411B
- c. Grayed out if **Mixer Type** is **Presel**
- d. E4407B Option AYZ (External Mixing) only
- e. Grayed out if **Input Mixer** is **Int**
- f. Grayed out if the Tracking Generator is on
(**Source, Amplitude (On)**) or **Internal Preamp (On)**
is selected.
- g. Not available when **Frequency, Scale Type (Log)** is selected.
- * An active function which allows data entry

pl729b

Marker Menu




a. Available in zero span with **Marker Delta** active.

* An active function which allows data entry

pl764b


Marker → Menu



- a. Not active when **span** is set to zero (Zero Span)
- b. Active only when **Marker, Delta** is selected.

pb910a

Meas Control Menu




a. Appears only when **Channel Power, Occupied BW, ACP, Multi-Carrier Power, Power Stat CCDF, Harmonic Distortion, Burst Power, Intermod (TOI), Spurious Emissions,** or **Spectrum Emissions Mask** is selected in the **Measure** menu.

b. Displays "Resume" if the measurement is paused.

pn82a

Meas Setup Menu for Channel Power, Occupied BW, and ACP




- a. Appears only when **Channel Power** is selected in the **MEASURE** menu.
 b. Appears only when **Occupied BW** is selected in the **MEASURE** menu.
 c. Appears only when **ACP** is selected in the **MEASURE** menu.
 d. Always grayed out except when **Radio Std, NADC** or **Radio Std, W-CDMA 3GPP** is selected.

* An active function which allows data entry.

pl773b


Meas Setup Menu for Multi-Carrier Power, Power Stat CCDF, Harmonic Distortion, and Burst Power



- a. Appears only when **Multi Carrier Power** is selected in the **MEASURE** menu.
- b. Appears only when **Power Stat CCDF** is selected in the **MEASURE** menu.
- c. Appears only when **Harmonic Dist** is selected in the **MEASURE** menu.
- d. Appears only when **Burst Power** is selected in the **MEASURE** menu.
- e. Greyed out when **Meas Method, Above Threshold Lvl** is selected.
- * An active function which allows data entry.

p1765b


Meas Setup Menu for Intermod (TOI), Spurious Emissions and Spectrum Emission Mask



- a. Appears only when **Intermod (TOI)** is selected in the **MEASURE** menu
- b. Appears only when **Spurious Emissions** is selected in the **MEASURE** menu
- c. Appears only when **Spectrum Emission Mask** is selected in the **MEASURE** menu

pl783b


MEASURE Menu



- a. Option AYX (Fast Digitized Time Sweeps) or Option B7D (Digital Signal Processing and Fast ADC) is required to ensure measurement accuracy.
- b. Only available in firmware revision A.08.00 and later.
- c. Only available in firmware revision A.07.00 and later.

p1766b


Mode Setup Menu



- a. After selecting **Radio Std, None, Std Setup**, this menu appears.
- b. After selecting **Std Setup**, this menu appears for the following radio standards: IS95, J-STD-008, cdma2000, W-CDMA, NADC, PDC, or GSM.
- c. After selecting **Std Setup** this menu appears for the Bluetooth radio standard.

pn84a


Peak Search Menu



* An active function which allows data entry
a. Unavailable in zero span

pl777b


Preset Menu



a. Appears only when Preset is set to User in the **System, Power On/Preset, Preset Type** menu. Otherwise **Preset** performs a **Factory Preset**.

pl768b


Print Setup Menu



- a. Available only with PCL5 printers.
- b. Grayed out unless **Custom** is selected in the **Printer Type** menu.
- c. Available only with color printers.

pl792a


Source Menu



- a. Source menu available only with Option 1DN or Option 1DQ installed
 b. Agilent E4402B, E4403B, E4404B, E4405B, E4407B and E4408B only
 * An active function which allows data entry

pl779b


SPAN (X Scale) Menu



- a. Appears only when **Power Stat CCDF** is selected in the **MEASURE** menu.
- b. Appears only when **Spectrum Emission Mask** is selected in the **MEASURE** menu.
- c. Available only when the upper window is active.
- * An active function which allows data entry.

pl714a


Sweep Menu



- a. Agilent ESA-E Series only (E4401B, E4402B, E4404B, E4405B and E4407B)
- b. Grayed out unless **Edge** is selected as **Gate Control**
- c. Grayed out unless **Level** is selected as **Gate Control**
- d. Agilent ESA - E Series only with Option 1D6 (Time Gated Spectrum Analysis) (E4401B, E4402B, E4404B, E4405B and E4407B)
- * An active function which allows data entry

pl769b


System Menu



- a. Agilent E4402B, E4403B, E4404B, E4405B, E4407B and E4408B with Option 1 DN only
- b. For Service menus, refer to the ESA Spectrum Analyzers Service Guide
- c. Available only with Option BAA (FM Demodulation)
- d. Agilent ESA-E series only (E4401B, E4402B, E4404B, E4405B, and E4407B)
- e. Grayed out when on the last page or if there is only one page
- f. Grayed out when on the first page or if there is only one page
- * An active function which allows data entry

pl774b


Trace/View Menu



* An active function which allows data entry

pl778b


Trace/View Menu (Channel Power)



a. Appears only when **Channel Power** is selected in the **MEASURE** menu.

pl786b


Trace/View Menu (ACP)



b. Appears only when **ACP** is selected in the **MEASURE** menu.

pl787b


Trace/View Menu (Multi-Carrier Power)



a. Appears only when **Multi Carrier Power** is selected in the **MEASURE** menu.

pl793b


Trace/View Menu (Harmonic Distortion)



c. Appears only when **Harmonic Distortion** is selected in the **MEASURE** menu.

pl788b


Trace/View Menu (Burst Power)



d. Appears only when **Burst Power** is selected in the **MEASURE** menu.

pl789b

Trace/View Menu (Power Stat CCDF and Spectrum Emission Mask)




e. Appears only when **Power Stat CCDF** is selected in the **MEASURE** menu.

f. Appears only when **Spectrum Emission Mask** is selected in the **MEASURE** menu.

pl790b

Trig Menu



- a. Agilent ESA-E Series only (E4401B, E4402B, E4404B, E4405B, and E4407B)
- b. Available only with Option B7B (TV Trigger and Picture on Screen)
- c. Trig Delay cannot be turned on if Gate is turned on
- d. Available only in zero span and in resolution bandwidths ≥ 1 kHz
- e. Available only in **Line** and **External** trigger modes
- f. Available only with Option B7E (RF Communications Hardware)
- * An active function which allows data entry

pl772b

Front-Panel Key Reference

Key Label	Page Location
< Display Line	page 221
> Display Line	page 221
1 ↔ 2	page 269
1 → 3	page 269
2 → 3	page 269
2 ↔ 3	page 269
2 – DL → 2	page 269
2nd Car Offs	page 188
120 kHz	page 133
200 Hz	page 133
9 kHz	page 133
Above Threshold Level	page 192
Abs AND Rel	page 203
Abs OR Rel	page 203
Abs Start	page 202
Abs Stop Couple Man	page 202
Absolute	page 203
Absolute Limit	page 198
ACP	page 184, page 206
Align Now	page 260
Alignments	page 259
All	page 260
All but RF	page 259
AM	page 136
Amplitude	page 141,
AMPLITUDE Y Scale	page 106
Amplitude On Off	page 234
Amptd Interp Log Lin	page 143
Amptd Offset	page 235

Key Label	Page Location
Amptd Ref (f = 50 MHz) On Off	page 168
Amptd Ref Out (f=50 MHz) On Off	page 168
Amptd Step Auto Man	page 235
Annotation On Off	page 145
Antenna	page 109, page 152
Apply Corrections Yes No	page 108
Attenuation Auto Man	page 106, page 235
Auto	page 228
Auto All	page 121
Auto Align	page 259
Auto Couple	page 121
Average	page 135
Average On Off	page 131
Average Mode Exp Repeat	page 180, page 182, page 184, page 190, page 191, page 194, page 196
Avg Number On Off	page 180, page 181, page 184, page 187, page 191, page 194, page 195, page 200
Avg Type Auto Man	page 126, page 131
Avg Type Video Power	page 192
Band Power	page 175, page 217

Key Label	Page Location
Bitmap	page 152
Blank	page 269
Bluetooth™	page 215
Burst Power	page 191, page 209
Burst Width Auto Man	page 193
BW/Avg	page 129
Cable	page 111, page 152
cdma2000 SR1	page 214
cdma2000 SR3-DS	page 214
cdma2000 SR3-MC	page 214
Center Freq	page 163
CF Step Auto Man	page 163
Channel Power	page 180, page 204
Chan Span	page 200
Chan Pwr Span	page 181
Change Title	page 144
Chan Integ BW	page 184, page 200
Clear Error Queue	page 257
Clear Title	page 144
Clear Write	page 268
Coarse	page 261
Color Capable Yes No	page 229
Color On Off	page 229
Color Palette	page 262
Connected To Previous Pt Yes No	page 141
Continuous Pk On Off	page 218
Copy	page 156

Key Label	Page Location
Copy Now	page 156
Corrections	page 108, page 148, page 151, page 156, page 157, page 159
Corrections On Off	page 109, page 111, page 114, page 116
Counts 100.000 k	page 189
Coupling AC DC	page 167
Create Dir	page 160
CSV	page 149
Custom	page 228
Date Format MDY DMY	page 258
Define Custom	page 228
Default	page 262
Delete	page 155
Delete All Corrections	page 119
Delete All Limits	page 144
Delete Corrections	page 111, page 113, page 116, page 119
Delete Point	page 110, page 113, page 116, page 118, page 142
Delta	page 172, page 217
Delta Pair Ref Delta	page 173
Demod	page 136
Demod Time	page 137

Front-Panel Key Reference

Key Label	Page Location
Demod View On Off	page 137
Det/Demod	page 134
Detector Auto Man	page 122, page 134
Device BTS MS	page 215
Diagnostics	page 263
Dir Select	page 153
Display	page 139
Display Line On Off	page 139
Edge Gate	page 248
Edge Pos Neg	page 248
Edit	page 111, page 114, page 116, page 140
Eject Page	page 229
EMI Res BW	page 133
Enter	page 146
Entire Frame	page 280
ESC	page 147
Exp	page 180, page 182, page 184, page 188, page 190, page 191, page 194, page 196
Ext Amp Gain	page 119
Ext Mix Band	page 168
External Pos Neg	page 278
Fail Mask	page 203
Field	page 280
Field One	page 281

Key Label	Page Location
Field Two	page 281
File	page 148
Filter On Off	page 187
Fine	page 261
FM	page 136
FM Demod	page 260
Format	page 149, page 160
Free Run	page 278
Freq Correct On Off	page 261
Freq Count	page 162
Freq Interp Log Lin	page 119, page 142
Freq Offset	page 164
Frequency	page 109, page 112, page 115, page 117, page 141, page 174
FREQUENCY Channel	page 163
Front Panel Test	page 263
Full Screen	page 139
Full Span	page 238
Function	page 175, page 217
Gate	page 247
Gate Delay	page 248
Gate Length	page 248
Gate On Off	page 247
Graticule On Off	page 145
GSM/EDGE	page 214
Harmonic Auto Man	page 170

Key Label	Page Location
Harmonic Distortion	page 190, page 208
Harmonics	page 191
Help	page 166
High	page 248
IF Gain Auto Fixed	page 120
Image Shift	page 170
Image Suppress	page 169
Input/Output	page 167
Input Mixer	page 168
Input Mixer Int Ext	page 168
Input Z Corr 50 Ω 75 Ω	page 167
Install	page 265
Int Preamp On Off	page 108
Integ BW	page 180
Intermod (TOI)	page 194, page 211
Inverse Time	page 174
IS95	page 213
J-STD-008	page 213
Landscape	page 229
Language PCL3 PCL5	page 228
Last Span	page 239
Level Gate	page 248
Limit 1 2	page 139
Limits	page 139, page 148, page 151, page 154, page 156, page 157, page 159

Key Label	Page Location
Limits On Off	page 187, page 188
Limits Fixed Rel	page 143
Line	page 278
Load	page 153
Load Defaults	page 261
Local (System)	page 256
Low	page 248
Lower Offset Limit	page 188
Man Track Adj	page 237
Margin On Off	page 140
Marker	page 172
Marker →	page 177
Marker All Off	page 176
Marker Count On Off	page 162
Marker Noise	page 175, page 217
Marker Table On Off	page 176
Marker Trace Auto 1 2 3	page 174
Max Hold	page 268
Max Hold On Off	page 182
Max Mixer Lvl	page 119, page 195
Measured Burst Width	page 192
Meas BW 5.0 MHz	page 189
Meas Control	page 179
Meas Interval 1.00 ms	page 189
Meas Method	page 192
Meas Off	page 204
Meas Setup	page 180
Meas Tools	page 217

Key Label	Page Location
Meas Type	page 186, page 200
Meas Type Examine Full	page 198
Measure	page 204
Measure Cont Single	page 179
Measurement Results	page 149, page 151, page 154, page 156, page 157, page 159
Metafile	page 149
Method IBW RBW	page 187
Min Hold	page 268
Min Search	page 218
Mixer Bias On Off	page 171
Mixer Config	page 170
Mixer Type Presel Unpre	page 170
Mkr → CF	page 177
Mkr → CF Step	page 177
Mkr → Ref Lvl	page 178
Mkr → Start	page 177
Mkr → Stop	page 177
Mkr Δ → Span	page 177
MODE	page 212
Mode Setup	page 213
Monochrome	page 262
Multi-Carrier Power	page 187, page 206
NADC	page 213
N dB On Off	page 218
Negative Peak	page 134
Neg Offset Limit	page 186

Key Label	Page Location
Next Peak	page 218
Next Pk Left	page 218
Next Pk Right	page 218
Next Window	page 216
Noise Corr On Off	page 187
None	page 228
Norm Ref Lvl	page 270
Norm Ref Posn	page 271
Normal	page 172
Normalize	page 269
OBW Span	page 182
Occ BW % Pwr	page 182
Occupied BW	page 181, page 205
Off	page 259
Offset A B C D	page 188, page 201, page 202
Offset	page 186
Offset Freq	page 186
Offsets/Limits	page 186, page 188
Operations	page 269
Optical Filter	page 262
Optimize f(f)	page 122
Optimize LO for Fast Tuning	page 122

Key Label	Page Location
Optimize Ref Level	page 181, page 184, page 187, page 188, page 190, page 191, page 194, page 195, page 203
Orientation	page 229
Other	page 114
Packet Type DH1 DH3 DH5	page 215
Pause	page 179
PDC	page 214
Peak	page 134
Peak Excursn	page 198, page 219
Peak Readout	page 221
Peak Search	page 217
Peak Search Param Max	page 220
Peak Sort Freq Ampl	page 221
Peak Table	page 221
Peak Table On Off	page 221
Peak Threshold	page 198
Period	page 174
PhNoise Opt Auto Man	page 122
Pk-Pk Search	page 218
Pk Threshold	page 220
Point	page 109, page 112, page 114, page 117, page 140
	page 249, page 254

Key Label	Page Location
Portrait	page 229
Pos Offset Limit	page 186
Power On Last Preset	page 257
Power On/Preset	page 257
Power Stat CCDF	page 189, page 206
Power Sweep On Off	page 234
Preferences	page 145
Presel Adjust	page 107
Presel Center	page 107
Preset	page 222
Print	page 227
Print Setup	page 228
Printer Type	page 228
Prints/Page 1 2	page 229
PSD Ref	page 186, page 200
Radio Std	page 213
Range On Off	page 197
Range Table	page 196
Readout	page 174
Ref BW	page 186
Ref Channel	page 200
Ref Lvl Offst	page 108
Ref Level	page 106
Ref Level Auto Man	page 199
Rel Start	page 202
Rel Stop Couple Man	page 202
Relative	page 203
Remote Port	page 261

Key Label	Page Location
Rename	page 158
Repeat	page 180, page 182, page 184, page 188, page 191, page 191, page 194, page 196
Resolution Auto Man	page 162
Res BW Auto Man	page 129, page 197, page 200, page 202
Restart	page 179
Restore Sys Defaults	page 263
Return	page 231
Reverse Bitmap	page 149
Reverse Metafile	page 149
RF (Ext Cable)	page 260
RRC Filter On Off	page 189
SA	page 212
Sample	page 134
Save	page 232
Scale/Div	page 106
Scale Type Log Lin	page 106
Screen	page 148
Search	page 217
Search Param	page 219
Segmented Sweep	page 249
Select Marker 1 2 3 4	page 174
Service	page 266
Set Date	page 259
Set Time	page 258

Key Label	Page Location
Setup	page 148
Show Errors	page 256
Show Hdwr	page 262
Show System	page 261
Signal BW 3.00000000 MHz	page 215
Signal ID Mode	page 169
Signal Ident On Off	page 169
Signal Track On Off	page 164
Single Sweep	page 233
Source	page 234
Span	page 238
Span Pair Span Center	page 173
Span X Scale	page 238
Span Zoom	page 238
Speaker On Off	page 137
Spectrum Emission Mask	page 200, page 211
Spur	page 199
Spurious Emissions	page 195, page 211
ST/Harmonic Auto Man	page 191
Standard	page 281
Standby	page 245
Start Freq	page 163, page 197
Start Freq On Off	page 201
State	page 148
Stop Freq	page 163, page 197, page 201
Sweep	page 246

Key Label	Page Location
Sweep Time	page 202
Sweep Cont Single	page 247
Sweep Time Auto Man	page 197, page 200, page 202, page 246
Swp Coupling SR SA	page 247
Sync Pos Neg	page 281
System (Local)	page 256
Test On Off	page 140
TG (Ext Cable)	page 260
Threshold Lvl Abs Rel	page 192
Time	page 174
Time/Date	page 258
Time/Date On Off	page 258
Time Base	page 261
Title	page 144
TOI Span	page 194
Total Pwr Ref	page 186, page 200
Total Pwr Ref Auto Man	page 187, page 200
Trace	page 268
Trace 1 2 3	page 268
Tracking Peak	page 237
Trig	page 278
Trig Delay On Off	page 279
Trig Type Edge Level	page 248
TV	page 278
TV Monitor	page 281
TV Source	page 281
TV Trig Setup	page 279

Key Label	Page Location
Type Upper Lower	page 139
User	page 116
User Preset	page 226
VBW/RBW Auto Man	page 130
Verbose SCPI On Off	page 257
Video Avg	page 127, page 132
Video	page 278
Video BW Auto Man	page 129, page 197
View	page 269
Trace/View	page 268
Upper Offset Limit	page 188
Viewing Angle	page 284
Vision Impair 1	page 262
Vision Impair 2	page 262
W-CDMA 3GPP	page 214
x dB	page 183
X Axis Units Freq Time	page 143
Y Axis Units	page 107
Zero Span	page 239
Zone	page 239
Zone Center	page 240
Zone On Off	page 240
Zone Pk Left	page 242
Zone Pk Right	page 241
Zone Span	page 241
Zoom	page 285

AMPLITUDE Y Scale

Activates the reference level function and accesses the amplitude menu keys. Amplitude menu keys allow you to set functions that affect the way data on the vertical axis is displayed or corrected.

Ref Level Allows the reference level to be changed. This function is activated when **AMPLITUDE Y Scale** is pressed. The reference level is the amplitude power or voltage represented by the top graticule on the display. Changing the value of the reference level changes the absolute amplitude level (in the selected amplitude units) of the top graticule line. The reference level can be changed using the step keys, the knob, or the numeric keypad. Pressing any digit (0 through 9) on the numeric keypad brings up the terminator menu.

Key Access: **AMPLITUDE / Y Scale**

Attenuation Auto Man Sets the input attenuation to manual or automatic and allows you to set the attenuation level in 5 dB increments when **Attenuation (Man)** is selected. The analyzer input attenuator, which is normally coupled to the reference level control, reduces the power level of the analyzer input signal at the input mixer. The attenuator is recoupled when **Attenuation (Auto)** is selected. Attenuation can be changed using the step keys, the knob, or the numeric keypad. To select 0 dB, the numeric keypad must be used (except for E4401B or E4411B.)

Key Access: **AMPLITUDE / Y Scale**

CAUTION To prevent damage to the input mixer, do not exceed a power level of +30 dBm at the input. To prevent signal compression, keep the power at the input mixer below 0 dBm. With the attenuator set to Auto, a signal at or below the reference level will result in a mixer level at or below the **Max Mixer Lvl.**

Scale/Div Sets the logarithmic units per vertical graticule division on the display. The **Scale/Div** function is only available when the **Scale Type** key is set to **Log**. Scale/Div values may range from 0.1 to 20 dB per division. With FM Demod (Option BAA) installed and **Demod View (On)** selected, the range is 1 kHz to 240 kHz/div. With Bluetooth™ FM Demodulation (Option 106) installed and **Demod View (On)** selected, the scale/division is fixed at approximately 40 kHz/division.

Key Access: **AMPLITUDE / Y Scale**

Scale Type Log Lin Scales the vertical graticule divisions in logarithmic units when **Log** is underlined. Logarithmic units may range from 0.1 to 20 dB per division. When **Lin** is underlined, the vertical divisions are linearly scaled and the default amplitude units are volts. The top of the display

is set to the reference-level value and the bottom graticule becomes zero volts. (Each division of the graticule is one-tenth of the reference level in volts.) Pressing **Scale Type** always sets the units specified for the current amplitude scale. When **Power On** is set to **Preset** and **Preset Type** is set to **Factory**, pressing **Preset** or powering on the analyzer sets the default units.

Key Access: **AMPLITUDE / Y Scale**

Presel Center

Agilent E4404B, E4405B, E4407B and E4408B only. Adjusts the frequency of the preselector filter (above 2.85 GHz) to optimize the amplitude accuracy at the active marker frequency. With **Input Mixer (Ext)** selected and the **Mixer Type** set to **Presel** (preselected), **Presel Center** adjusts the frequency of the external preselector filter to maximize the amplitude at the active marker frequency. If activated in a non-preselected band, **Presel Center** does nothing.

Preselector center should be used to improve amplitude accuracy for signals which fall into any one of the harmonic mixing bands. The harmonic mixing bands Frequency Ranges are:

Band	Frequency Range
1	2.85 - 6.7 GHz
2	6.2 - 13.2 GHz
3	12.8 - 19.2 GHz
4	18.7 - 26.5 GHz

Key Access: **AMPLITUDE / Y Scale**

Presel Adjust

Agilent E4404B, E4405B, E4407B and E4408B only. Allows manual adjustment of the preselector frequency to optimize its response on the signal of interest.

By changing the **Presel Adjust**, the center of the preselector filter can be moved in frequency. The signal of interest will appear to change in amplitude with the frequency response of the preselector filter.

Key Access: **AMPLITUDE / Y Scale**

Y Axis Units

Accesses the menu keys that change the amplitude units. Amplitude units are maintained for both logarithmic and linear modes. The amplitude units can be changed by pressing **dBm**, **dBmV**, **dBμV**, **dBμA**, **Watts**, **Volts**, and **Amps**. This key is unavailable when **FM Demod** and **Demod View** are on.

Key Access: **AMPLITUDE Y Scale, More**

Ref Lvl Offst Adds an offset value to the displayed reference level. Reference-level offsets are only entered by using the numeric keypad. Entering an offset does not affect the trace or the attenuation value. Reference-level offsets are used when gain or loss occurs between a device under test and the analyzer input. Thus, the signal level measured by the analyzer may be referred to as the level at the input of an external amplitude-conversion device. When an amplitude offset is entered, its value appears on the left side of the display under *Offst* (as opposed to frequency offsets which appear at the bottom of the display). To eliminate an offset, press **Ref Lvl Offst, 0, dB**. When **Preset Type** is set to **Factory**, pressing **Preset** also sets the offset to zero. See also the **Ext Amp Gain** key description.

Key Access: **AMPLITUDE Y Scale, More**

Int Preamp On Off *Agilent ESA-E Series only (E4401B, E4402B, E4404B, E4405B and E4407B) with Option 1DS.* Turns the internal preamp on and off. Pressing **Int Preamp (On)** results in a correction being applied to compensate for the gain of the preamp so that amplitude readings show the value at the input connector. When the preamp is on, a **PA** indication appears on the left side of the display. The preamp is switched off in frequency bands above 3 GHz and the correction is not applied. In this case, the **PA** indication will still appear even though the preamp is not activated.

The preamp is specified to operate over a 1 MHz to 3 GHz range for the E4402B, E4404B, E4405B and E4407B. The preamp range for the E4401B is 100 kHz to 1.5 GHz, except for Option 1DP, which is 1 MHz to 1.5 GHz.

Key Access: **AMPLITUDE Y Scale, More**

Corrections Accesses the **Corrections** menu keys which allow you to enable the corrections function and to select which set of correction factors you wish to modify.

Key Access: **AMPLITUDE Y Scale, More**

Apply Corrections

Yes No Pressing **Apply Corrections (Yes)** turns on the amplitude-correction factors. Corrections will only be applied to the sets of correction factors whose correction state is set to **On**. To turn a set of correction factors on, use the **Correction On Off** key in the **Antenna, Cable, Other, or User** menus. When **Apply Corrections (Yes)** is selected, an **A** will appear on the screen annotation whether or not a correction set has been turned on using the **Correction (On)** key in the **Antenna, Cable, Other, or User** menus.

Key Access: **AMPLITUDE / Y Scale, More, Corrections**

Antenna Accesses the Antenna menu of keys which allow you to correct for antenna loss, but may be used for any kind of correction.

Key Access: **AMPLITUDE / Y Scale, More, Corrections**

Correction On Off Turns the amplitude correction function on or off for the selected set. The corrections state must be set to On for the correction to be applied.

Key Access: **AMPLITUDE / Y Scale, More, Corrections, Antenna**

NOTE Antenna, Cable, and Other correction factors are generally entered as positive values. This indicates a loss in the external device. User correction factors are typically entered as negative values which indicate a gain in the external device.

Edit Accesses menu keys that allow you to create and edit an amplitude-correction factor set. It puts the analyzer into a split-screen mode where the correction data is displayed in a table under the trace data. Pressing **ESC** while in this menu will exit the menu and remove the table from the screen. New will be applied only after the editor is closed. The Tab keys are very useful for navigation between rows in the corrections table.

Key Access: **AMPLITUDE Y Scale, More, Corrections, Antenna**

Point

Allows you to create or edit an amplitude-correction factor data point. Up to 200 may be defined for each set. Enter the point number to be created or edited by using the numeric keypad, then press **Enter**, or use the knob, tab, or step keys to move to an existing point. Press **Bk Sp** to correct errors. After selecting a point, **Frequency** becomes active.

Key Access: **AMPLITUDE Y Scale, More, Corrections, Antenna, Edit**

Frequency

Allows you to enter the frequency value for an amplitude-correction point. Enter the frequency value by using the numeric keypad. Change the frequency value by using the step keys or the knob. Press **Bk Sp** to correct errors. After selecting a point, **Amplitude** becomes active.

A frequency coordinate must always be specified for amplitude-correction factors.

Key Access: **AMPLITUDE Y Scale, More, Corrections, Antenna, Edit**

NOTE The amplitude correction entered for the lowest frequency will be applied to all frequencies less than the lowest frequency entered. Similarly, the amplitude correction for the highest frequency entered will be applied to all frequencies greater than the highest frequency entered.

NOTE For amplitude-correction factors, a maximum of two entries with the same frequency are valid. Only the first and last of a series with the same frequency values are used; any middle are ignored.

NOTE Amplitude-correction data is sorted in the table by frequency. The sorting occurs immediately after you have entered the frequency value via the front-panel.

Amplitude

Allows you to enter the amplitude value for the current amplitude-correction point. After selecting a point, the point number automatically increments and **Frequency** becomes active to allow entry of the frequency of the next point. Press **Bk Sp** to correct errors.

Key Access: **AMPLITUDE Y Scale, More, Corrections, Antenna, Edit**

Delete Point

Allows you to delete the amplitude-correction data for the currently selected point. The prompt **If you are sure, press key again to**

delete will appear on the display. Pressing **Delete Point** again will delete the point and adjust all of the point numbers as appropriate.

Key Access: **AMPLITUDE Y Scale, More, Corrections, Antenna, Edit**

Delete Correction Allows you to clear all data from the selected amplitude-correction set. The prompt *If you are sure, press key again to delete will appear on the display.* Pressing **Delete** again will delete the correction set.

Key Access: **AMPLITUDE Y Scale, More, Corrections, Antenna**

Cable Allows you to correct for cable loss, but may be used for any kind of correction.

Key Access: **AMPLITUDE / Y Scale, More, Corrections**

Correction On Off Turns the amplitude correction function on or off for the selected set. The corrections state must be set to On for the correction to be applied.

Key Access: **AMPLITUDE / Y Scale, More, Corrections, Cable**

NOTE Antenna, Cable, and Other correction factors are generally entered as positive values. This indicates a loss in the external device. User correction factors are typically entered as negative values which indicate a gain in the external device.

Edit Accesses menu keys that allow you to create and edit an amplitude-correction factor set. It puts the analyzer into a split-screen mode where the correction data is displayed in a table under the trace data. Pressing **ESC** while in this menu will exit the menu and remove the table from the screen. New will be applied only after the editor is closed. The Tab keys are very useful for navigation between rows in the corrections table.

Key Access: **AMPLITUDE Y Scale, More, Corrections, Cable**

Point

Allows you to create or edit an amplitude-correction factor data point. Up to 200 may be defined for each set. Enter the point number to be created or edited by using the numeric keypad, then press **Enter**, or use the knob, tab, or step keys to move to an existing point. Press **Bk Sp** to correct errors. After selecting a point, **Frequency** becomes active.

Key Access: **AMPLITUDE Y Scale, More, Corrections, Cable, Edit**

Frequency

Allows you to enter the frequency value for an amplitude-correction point. Enter the frequency value by using the numeric keypad. Change the frequency value by using the step keys or the knob. Press **Bk Sp** to correct errors. After selecting a point, **Amplitude** becomes active.

A frequency coordinate must always be specified for amplitude-correction factors.

Key Access: **AMPLITUDE Y Scale, More, Corrections, Cable, Edit**

NOTE

The amplitude correction entered for the lowest frequency will be applied to all frequencies less than the lowest frequency entered. Similarly, the amplitude correction for the highest frequency entered will be applied to all frequencies greater than the highest frequency entered.

NOTE For amplitude-correction factors, a maximum of two entries with the same frequency are valid. Only the first and last of a series with the same frequency values are used; any middle are ignored.

NOTE Amplitude-correction data is sorted in the table by frequency. The sorting occurs immediately after you have entered the frequency value via the front-panel.

Amplitude

Allows you to enter the amplitude value for the current amplitude-correction point. After selecting a point, the point number automatically increments and **Frequency** becomes active to allow entry of the frequency of the next point. Press **Bk Sp** to correct errors.

Key Access: **AMPLITUDE Y Scale, More, Corrections, Cable, Edit**

Delete Point

Allows you to delete the amplitude-correction data for the currently selected point. The prompt *If you are sure, press key again to delete* will appear on the display. Pressing **Delete Point** again will delete the point and adjust all of the point numbers as appropriate.

Key Access: **AMPLITUDE Y Scale, More, Corrections, Cable, Edit**

Delete Correction Allows you to clear all data from the selected amplitude-correction set. The prompt *If you are sure, press key again to delete* will appear on the display. Pressing **Delete** again will delete the correction set.

Key Access: **AMPLITUDE Y Scale, More, Corrections, Cable**

Other Allows you to correct for gain or loss other than for antenna, cable, or user.

Key Access: **AMPLITUDE / Y Scale, More, Corrections**

Correction On Off Turns the amplitude correction function on or off for the selected set. The corrections state must be set to On for the correction to be applied.

Key Access: Amplitude Y Scale, More, Corrections, Other

NOTE Antenna, Cable, and Other correction factors are generally entered as positive values. This indicates a loss in the external device. User correction factors are typically entered as negative values which indicate a gain in the external device.

Edit Accesses menu keys that allow you to create and edit an amplitude-correction factor set. It puts the analyzer into a split-screen mode where the correction data is displayed in a table under the trace data. Pressing **ESC** while in this menu will exit the menu and remove the table from the screen. New will be applied only after the editor is closed. The Tab keys are very useful for navigation between rows in the corrections table.

Key Access: **AMPLITUDE Y Scale, More, Corrections, Other**

Point

Allows you to create or edit an amplitude-correction factor data point. Up to 200 may be defined for each set. Enter the point number to be created or edited by using the numeric keypad, then press **Enter**, or use the knob, tab, or step keys to move to an existing point. Press **Bk Sp** to correct errors. After selecting a point, **Frequency** becomes active.

Key Access: **AMPLITUDE Y Scale, More, Corrections, Other, Edit**

Frequency

Allows you to enter the frequency value for an amplitude-correction point. Enter the frequency value by using the numeric keypad. Change the frequency value by using the step keys or the knob. Press **Bk Sp** to correct errors. After selecting a point, **Amplitude** becomes active.

A frequency coordinate must always be specified for amplitude-correction factors.

Key Access: **AMPLITUDE Y Scale, More, Corrections, Other, Edit**

NOTE The amplitude correction entered for the lowest frequency will be applied to all frequencies less than the lowest frequency entered. Similarly, the amplitude correction for the highest frequency entered will be applied to all frequencies greater than the highest frequency entered.

NOTE For amplitude-correction factors, a maximum of two entries with the same frequency are valid. Only the first and last of a series with the same frequency values are used; any middle are ignored.

NOTE Amplitude-correction data is sorted in the table by frequency. The sorting occurs immediately after you have entered the frequency value via the front-panel.

Amplitude

Allows you to enter the amplitude value for the current amplitude-correction point. After selecting a point, the point number automatically increments and **Frequency** becomes active to allow entry of the frequency of the next point. Press **Bk Sp** to correct errors.

Key Access: **AMPLITUDE Y Scale, More, Corrections, Other, Edit**

Delete Point

Allows you to delete the amplitude-correction data for the currently selected point. The prompt *If you are sure, press key again to delete* will appear on the display. Pressing **Delete Point** again will delete the point and adjust all of the point numbers as appropriate.

Key Access: **AMPLITUDE Y Scale, More, Corrections, Other, Edit**

Delete Correction Allows you to clear all data from the selected amplitude-correction set. The prompt *If you are sure, press key again to delete* will appear on the display. Pressing **Delete** again will delete the correction set.

Key Access: **AMPLITUDE Y Scale, More, Corrections, Other**

User Allows you to correct for gain or loss and may be used for any type of correction.

Key Access: **AMPLITUDE / Y Scale, More, Corrections**

Correction On Off Turns the amplitude correction function on or off for the selected set. The corrections state must be set to **On** for the correction to be applied.

Key Access: **AMPLITUDE / Y Scale, More, Corrections, User**

NOTE

Antenna, Cable, and Other correction factors are generally entered as positive values. This indicates a loss in the external device. User correction factors are typically entered as negative values which indicate a gain in the external device.

Edit Accesses menu keys that allow you to create and edit an amplitude-correction factor set. It puts the analyzer into a split-screen mode where the correction data is displayed in a table under the trace data. Pressing **ESC** while in this menu will exit the menu and remove the table from the screen. New will be applied only after the editor is closed. The Tab keys are very useful for

navigation between rows in the corrections table.

Key Access: AMPLITUDE Y Scale, More, Corrections, User

Point

Allows you to create or edit an amplitude-correction factor data point. Up to 200 may be defined for each set. Enter the point number to be created or edited by using the numeric keypad, then press **Enter**, or use the knob, tab, or step keys to move to an existing point. Press **Bk Sp** to correct errors. After selecting a point, **Frequency** becomes active.

Key Access: AMPLITUDE Y Scale, More, Corrections, User, Edit

Frequency

Allows you to enter the frequency value for an amplitude-correction point. Enter the frequency value by using the numeric keypad. Change the frequency value by using the step keys or the knob. Press **Bk Sp** to correct errors. After selecting a point, **Amplitude** becomes active.

A frequency coordinate must always be specified for amplitude-correction factors.

Key Access: AMPLITUDE Y Scale, More, Corrections, User, Edit

NOTE

The amplitude correction entered for the lowest frequency will be applied to all frequencies less than the lowest frequency entered. Similarly, the amplitude correction for the highest frequency entered will be applied to all frequencies greater than the highest frequency entered.

NOTE

For amplitude-correction factors, a maximum of two entries with the same frequency are valid. Only the first and last of a series with the same frequency values are used; any middle are ignored.

NOTE Amplitude-correction data is sorted in the table by frequency. The sorting occurs immediately after you have entered the frequency value via the front-panel.

Amplitude

Allows you to enter the amplitude value for the current amplitude-correction point. After selecting a point, the point number automatically increments and **Frequency** becomes active to allow entry of the frequency of the next point. Press **Bk Sp** to correct errors.

Key Access: **AMPLITUDE Y Scale, More, Corrections, User, Edit**

Delete Point

Allows you to delete the amplitude-correction data for the currently selected point. The prompt *If you are sure, press key again to delete* will appear on the display. Pressing **Delete Point** again will delete the point and adjust all of the point numbers as appropriate.

Key Access: **AMPLITUDE Y Scale, More, Corrections, User, Edit**

Delete Correction Allows you to clear all data from the selected amplitude-correction set. The prompt *If you are sure, press key again to delete* will appear on the display. Pressing **Delete** again will delete the correction set.

Key Access: **AMPLITUDE Y Scale, More, Corrections, User**

**Freq Interp
Log Lin**

Allows you to determine how trace values are computed between in a correction table. If the linear mode is selected, a straight line is used between in a correction table. If the logarithmic mode is selected, frequency values between are computed by first taking the logarithm of both table values and the intermediate value.

Key Access: **AMPLITUDE Y Scale, More, Corrections, More**

Delete all Corrections Allows you to delete all amplitude-correction sets.

Key Access: **AMPLITUDE Y Scale, More, Corrections, More**

Ext Amp Gain

Adds a positive or negative preamplifier gain value, which is subtracted from the displayed signal. (Use negative values for gain and positive values for loss.) The function is similar to the **Ref Lvl Offset** function, however with the **Ext Amp Gain** function, the attenuation may be changed depending on the preamplifier gain entered. A preamplifier gain offset is used for measurements that require an external preamplifier or long cables. The offset is subtracted from the amplitude readout so that the displayed signal level represents the signal level at the input of the preamplifier. The preamplifier gain offset is displayed at the top of the screen and is removed by entering zero. The preamplifier gain offset can only be entered using the numeric keypad. The preamplifier gain value is not affected by an instrument preset or a power cycle.

Key Access: **AMPLITUDE Y Scale, More**

Max Mixer Lvl

Allows you to change the maximum input mixer level from 10 dBm to -100 dBm in 10 dB steps using the step keys, and 1 dB steps using the knob. In addition, you may use the keypad to specify a value. The mixer level is equal to the reference level minus the attenuator setting. As the reference level changes, the input attenuator setting is changed to keep the power levels of on-screen signals less than the selected level at the input mixer. When **Preset Type** is set to **Factory**, pressing **Preset** resets the maximum input mixer level to -10 dBm.

Key Access: **AMPLITUDE Y Scale, More**

IF Gain
Auto Fixed

When using digital resolution bandwidths ($RBW < 1$ kHz), the analyzer uses IF Gain autoranging to set the optimum signal gain for digital processing. This technique produces the maximum measurement range without overloading the digital system. To increase measurement speed, select **IF Gain (Fixed)**. This setting decreases the display range to 70 dB, so you may have to adjust the reference level to ensure complete view of the signal.

Key Access: **Amplitude, More, More**

Auto Couple

Accesses the menus to couple functions in your analyzer. Coupled functions are functions that are linked.

Auto All Auto-couples all coupled functions. If **Auto All** is pressed all coupled functions are set to **Auto**.

NOTE This function is not available when the segmented sweep function is set to On, (**Segmented (On)**).

Coupled functions are functions that are linked. If one function is changed, the coupled function is changed. During normal operation, the sweep time, resolution bandwidth, video bandwidth, and center frequency step are coupled to span; the input attenuation is coupled to the reference level.

If any of these functions become uncoupled (is set to manual), a # sign appears next to the screen annotation representing the function on the screen. If one or more functions are manually set so that the amplitude or frequency becomes uncalibrated “Meas Uncal” appears on the top right side of the graticule.

To recouple the analyzer functions, the uncoupled function(s) must be individually set back to Auto. Or, you can press **Auto All** to return all of the functions to their default auto state. Pressing **Auto All** will couple the following functions:

- Sweep time will couple to the span, resolution bandwidth, and video bandwidth.
- **Detector (Auto)** is set.
- **Avg Type (Auto)** is set.
- **PHNoise Opt (Auto)** is set.
- RF attenuation couples to reference level.
- Center frequency step size will couple to 10% of span.
- Sweep coupling (SR/SA) will couple back to SA mode.
- Source attenuation couples to source amplitude.
- Source power step couples to one vertical scale division.

Key Access: **Auto Couple**

NOTE Although **Marker Count**, **Gate Time**, and **Marker Trace** have **Auto** settings, they are not affected by **Auto All**.

**PhNoise Opt
Auto Man**

Chooses the LO (local oscillator) phase noise behavior that is optimum for measurement accuracy.

Key Access: Auto Couple

Auto Allows the analyzer to automatically select an LO phase noise behavior that is optimum for the selected span and RBW. The **Auto** rules choose **Fast Tuning** whenever the span is >10 MHz otherwise the **Auto** rules choose **Optimize £(f)**.

Key Access: **Auto Couple, PhNoise Opt Auto Man**

Optimize £(f) Optimizes for LO phase noise.

Key Access: **Auto Couple, PhNoise Opt Auto Man**

Optimize LO for Fast Tuning The LO behavior compromises phase noise within approximately 10 MHz of the carrier. This allows rapid measurement throughput when changing the center frequency or span.

Key Access: **Auto Couple, PhNoise Opt Auto Man**

Detector Auto Man Selects a specific detector, or in **Auto**, picks the appropriate detector for a particular measurement.

When discussing detectors, it is important to understand the concept of a trace “bucket.” For every trace point displayed, there is a finite time during which the data for that point is collected. The analyzer has the ability to look at all of the data collected during that time and present a single point of trace data based on the detector mode. We call the interval during which the data for that trace point is being collected, the “bucket.” Thus a trace is more than a series of single . It is actually a series of trace “buckets.” The data may be sampled many times within each bucket.

Selecting **Detector (Auto)** and **BW/Avg, Average (On)** changes the detector. The **Auto** choice depends on marker functions, trace functions, and the trace averaging function. If a marker function or measurement is running, the **Auto** choice of detector is either **Average** or **Sample**. When one of the detectors (such as **Average**) is manually selected instead of **Auto**, that detector is used regardless of other analyzer settings.

The **Average** detector displays the average of the signal within the bucket. The averaging method depends upon **Avg Type** selection (Video or RMS).

The **Peak** detector displays the maximum of the signal within the bucket.

The **Sample** detector displays the instantaneous level of the signal at the time of the sampling.

The **Negative Peak** detector displays the minimum of the signal within the bucket.

Neither average nor sample detectors measure amplitudes of CW signals as accurately as peak, because they may not find a spectral component's true peak, but they do measure noise without the biases of peak detection.


The detector in use is indicated on the left side of the display. A # will appear next to it if the detector has been manually selected.

Key Access: Auto Couple

Auto The system selects peak detection as the default, but if a condition arises where a different type of detection scheme provides greater accuracy, the system will use the alternate scheme. For example, when using the Marker Noise function, Auto mode selects Average detection for Res BWs > 300 Hz and Sample for Res BWs \leq 300 Hz as shown in [Figure 3-1](#).

Key Access: Auto Couple, Detector Auto Man

Figure 3-1 Detector (Auto) Selection Flowchart



cl72a

Average

Allows you to select between video and power (RMS) averaging, via the **Average Type** key.

Average detection is used when measuring the average value of the amplitude across each trace interval (bucket). The averaging method used by the Average detector will be set to either Video or Power as appropriate when the Average Type is Auto coupled or may be set explicitly through the **BW/Avg, Avg Type Auto Man** key.

Video Average detection computes the averaged trace interval as appropriate to the Y-axis scale:

- Log-power average when in log scale.
- Voltage average when in linear scale.
- Frequency deviation when Demod View is enabled for FM Demod.

Power Average (“root mean square” or RMS) detection computes the RMS of the samples collected across the trace interval. The number of samples included in the RMS average for each trace interval depends on the sweep time, the resolution bandwidth, and whether or not option B7D is installed. With option B7D installed, more samples are available as appropriate for wider resolution bandwidths and faster sweep times. Slower sweep times also increase the number of samples averaged for each trace interval.

When **Average** is selected, **Avg** appears on the left side of the display.

Key Access: **Auto Couple, Detector Auto Man**

Peak Peak detection is used primarily when measuring sinusoidal (spectral) components. Peak detection obtains the maximum video signal value between the last display point and the present display point and stores this value in memory. When **Preset Type** is set to **Factory**, peak detection is selected at power on and by pressing **Preset**. When **Peak** detection is selected, **Peak** appears in the upper-left corner of the display.

Key Access: **Auto Couple, Detector Auto Man**

Sample Sample detection is used primarily to display noise or noise-like signals. This detection should not be used to make the most accurate amplitude measurement of non noise-like signals. In sample mode, the instantaneous signal value at the present display point is placed in memory. When **Sample** detection is selected, **Samp** appears in the upper-left corner of the display.

Key Access: **Auto Couple, Detector Auto Man**

Negative Peak Negative peak detection functions the same as peak detection, but selects the minimum video signal value. This detection should not be used to make the most accurate amplitude measurements of signals. When **Negative Peak** is selected, **NPeak** appears in the upper-left corner of the screen.

Key Access: **Auto Couple, Detector Auto Man**

Avg Type Auto Man Accesses the functions to automatically or manually choose from one of the following averaging scales: Video or Power (RMS).


NOTE If video averaging is selected, the measurement results are the average of the signal level in the y-axis scale. If the power average (RMS) is selected, all measured results are converted into power units before averaging and filtering operations, and converted back to decibels for displaying. The main point to remember is that there can be significant differences between the average of the log of power and the log of the average power.

There are actually four types of averaging processes within a spectrum analyzer. All, except VBW filtering, are affected by this setting. They are:

- Trace averaging (see **BW/Avg, Average (On)**).
Averages signal amplitudes on a trace-to-trace basis. (The type of averaging (Video or Power (RMS)) is selected by pressing **BW/Avg, Avg Type**.)
- Average detector (see **Det/Demod, Detector, Average (Video/RMS)**).
Averages signal amplitudes during the time or frequency interval represented by a particular measurement point. The method is determined by selection of either Video or RMS.
- Noise Marker (see **Marker, Noise**)
Averages signal amplitudes across measurement to reduce variations for noisy signals.
- VBW filtering.
Filtering the video is a form of averaging the video signal.

When trace average is on (**BW/Avg, Average (On)**), the Average Type is shown on the left side of the display. When **Avg Type (Auto)** is selected, the analyzer chooses the type of averaging to be used as shown in [Figure 3-2](#). When one of the average types is selected manually, the analyzer uses that type without regard to the other analyzer settings and sets **Avg Type to Man**.

Figure 3-2 Auto Rules for Average Type



cl79a

Key Access: Auto Couple

Video Avg Video averaging averages the data as appropriate for the y-axis scale. When **Avg Type, Video Avg** is selected, **VAvg** appears on the left side of the analyzer display if **Average** is On.

Key Access: Auto Couple, Avg Type

Pwr Avg Power averaging is performed by converting the trace data from logarithmic to linear power units, and then averaging the power trace data. When **Avg Type, Pwr Avg** is selected, **PAvg** appears on the left side of the analyzer display if **Average** is On.

Key Access: Auto Couple, Avg Type

Bk Sp (Backspace)

The backspace key is located on the front panel and is used to change or correct an active function entry or a text entry before you save to a file.

BW/Avg

Activates the resolution bandwidth function and accesses the menu keys that control the bandwidth functions and averaging.

Res BW
Auto Man

Changes the 3 dB resolution bandwidth on the analyzer from 1 kHz to 5 MHz in a 1, 3, 10 sequence using the knob or step keys. If an unavailable bandwidth is entered using the numeric keypad, the closest available bandwidth in the 1, 3, 10 sequence is used. (Option 1DR provides additional 300 Hz, 200 Hz, 100 Hz, 30 Hz and 10 Hz bandwidths. For firmware revision A.08.00 and later, the bandwidth range is from 1 Hz to 5 MHz if you have both Options 1D5 and 1DR.) As the resolution bandwidth is decreased, the sweep time is modified to maintain amplitude calibration. Resolution bandwidth is also related to span. As span is decreased, the resolution bandwidth is decreased. As the resolution bandwidth changes, the video bandwidth, if in auto couple mode, changes to maintain the VBW/RBW ratio.

NOTE

With firmware A.08.00 and greater, in zero span, the auto/manual function of this key is not applicable. When **Res BW (Auto)** is selected in non-zero span, any changes to Res BW while in zero span will revert to the Auto value when you return to non-zero span. When **Res BW (Man)** is selected in non-zero span, any changes to Res BW while in zero span will be maintained when you return to non-zero span.

A “#” mark appears next to **Res BW** on the display when it is not coupled. To recouple the resolution bandwidth, press **Res BW (Auto)** (or press **Auto Couple, Auto All**). The resolution bandwidth can be changed using the step keys, the knob, or the numeric keypad.

Key Access: **BW/Avg**

Video BW
Auto Man

Changes the analyzer post-detection filter from 30 Hz to 3 MHz in a 1, 3, 10 sequence using the knob, step keys, or the numeric keypad. If an unavailable bandwidth is entered using the numeric keypad, the closest available bandwidth in the 1, 3, 10 sequence is used. (Option 1DR provides additional 1 Hz, 3 Hz and 10 Hz video bandwidths when the resolution bandwidth is ≤ 300 Hz.)


As the video bandwidth is decreased, the sweep time is increased to maintain amplitude calibration. A “#” mark appears next to **VBW** on the bottom of the analyzer display when it is not coupled. To couple the video bandwidth, press **Video BW (Auto)** (or press **Auto All**).

Key Access: **BW/Avg**

**VBW/RBW
Auto Man**

Selects the ratio between the video and resolution bandwidths. If signal responses near the noise level are visually masked by the noise, the ratio can be set to less than 1 to lower the noise. The knob and step keys change the ratio in a 1, 3, 10 sequence. When **Preset Type** is set to **Factory** and **Preset** is pressed or **Auto Couple**, **Auto All** have been selected, the ratio is set to 1.000 X. The ratio can be changed using the step keys, knob, or numeric keypad. When **VBW/RBW (Auto)** is selected, the ratio is determined by the rules in **Figure 3-3**.

Figure 3-3 VBW/RBW Ratio Auto Rules



c1710a

Key Access: **BW/Avg**

**Average
 On Off**

Initiates a digital averaging routine that averages the trace in a number of successive sweeps resulting in trace “smoothing”. The number of sweeps (average number) can be selected. Increasing the average number will further smooth the trace. The type of averaging used is selected by pressing **BW/Avg, Avg Type**.

The average is restarted when any of the following occurs:

- a new average number is entered.
- any measurement related parameter (e.g., Center Frequency) is changed.
- **Restart** is pressed.
- **Single Sweep** is pressed.

When in Single Sweep, the specified number of averages is taken, then the sweep stops. When in continuous sweep, the specified number of averages is taken, then the averaging continues with each new sweep averaged in with a weight of $\frac{1}{\text{Average Number}}$ and the old average reduced

by multiplying it by $\left(\text{Average Number} - \frac{1}{\text{Average Number}}\right)$.

To turn off averaging, press **Average (Off)**. The number of sweeps can only be entered using the numeric keypad, not the knob or step keys.

Key Access: **BW/Avg**

**Avg Type
 Auto Man**

Accesses the functions to automatically or manually choose from one of the following averaging scales: Video or Power (RMS).

NOTE

If video averaging is selected, the measurement results are the average of the signal level in the y-axis scale. If the power average (RMS) is selected, all measured results are converted into power units before averaging and filtering operations, and converted back to decibels for displaying. The main point to remember is that there can be significant differences between the average of the log of power and the log of the average power.

There are actually four types of averaging processes within a spectrum analyzer. All, except VBW filtering, are affected by this setting. They are:

BW/Avg

- Trace averaging (see **BW/Avg**).
Averages signal amplitudes on a trace-to-trace basis. (Press Video or Power (RMS) when **Avg Type (Man)** is selected.)
- Average detector (see **Detector, Average**).
Averages signal amplitudes during the time or frequency interval represented by a particular measurement point.
- Noise Marker (see **Marker, Noise**)
Averages signal amplitudes across measurement to reduce variations for noisy signals.
- VBW filtering.
Filtering the video is a form of averaging the video signal.

When trace average is on (**BW/Avg, Average (On)**), the Average Type is shown on the left side of the display. When **Avg Type (Auto)** is selected, the analyzer chooses the type of averaging to be used as shown in [Figure 3-2 on page 127](#). When one of the average types is selected manually, the analyzer uses that type without regard to the other analyzer settings and sets **Avg Type** to **Man**.

Key Access: **BW/Avg**


Video Avg Video averaging averages the data as appropriate for the y-axis scale. When **Avg Type, Video Avg** is selected, **vAvg** appears on the left side of the analyzer display if **Average** is On.

Key Access: **BW/Avg, Avg Type**

Pwr Avg Power averaging is performed by converting the trace data from logarithmic to linear power units, and then averaging the power trace data. When **Avg Type, Pwr Avg** is selected, **PAvg** appears on the left side of the analyzer display if **Average** is On.

Key Access: **BW/Avg, Avg Type**

Figure 3-4 VBW/RBW Ratio Auto Rules



cl710a

EMI Res BW

Accesses the **EMI Res BW** menu keys and allows you to choose between 6 dB bandwidths of **120 kHz**, **9 kHz** and **200 Hz**. The 200 Hz bandwidth is only available if Option 1DR (narrow resolution bandwidth) is installed and the span is less than 5 MHz. *(Option 1DR is available with Agilent ESA-E Series only (E4401B, E4402B, E4404B, E4405B and E4407B.))*

This function is set to **None** when the resolution bandwidth is set to any other value using the **Resolution BW** key.

Key Access: **BW/Avg**

Det/Demod

Accesses the menu keys controlling detector functions, demodulation functions, if an FM Demod Option is installed (Option BAA or Option 106), and the speaker.

NOTE The FM Demod internal circuitry must be aligned before use. Press **System, Alignments, Align Now, FM Demod**.

Detector Auto Man Selects a specific detector, or uses the system to pick the appropriate detector (through **Auto**) for a particular measurement.

When discussing detectors, it is important to understand the concept of a trace “bucket.” For every trace point displayed, there is a finite time during which the data for that point is collected. The analyzer has the ability to look at all of the data collected during that time and present a single point of trace data based on the detector mode. We call the interval during which the data for that trace point is being collected, the “bucket.” Thus a trace is more than a series of single . It is actually a series of trace “buckets.” The data may be sampled many times within each bucket.

When the detector choice is **Auto**, selecting trace averaging (**BW/Avg, Average (On)**) changes the detector. The **Auto** choice depends on marker functions, trace functions, and the trace averaging function. If a marker function or measurement is running, the **Auto** choice of detector is either **Average** or **Sample**. When one of the detectors (such as **Average**) is manually selected instead of **Auto**, that detector is used without regard to other analyzer settings.

The **Average** detector displays the average of the signal within the bucket. The averaging method depends upon **Avg Type** selection (Video or RMS).

The **Sample** detector displays the instantaneous level of the signal at the center of the bucket represented by each display point.

The **Peak** detector displays the maximum of the signal within the bucket.

The **Negative Peak** detector displays the minimum of the signal within the bucket.

Neither average nor sample detectors measure amplitudes of CW signals as accurately as peak, because they may not find a spectral component’s true peak, but they do measure noise without the biases of peak detection.

The detector in use is indicated on the left side of the display. A # will appear next to it if the detector has been manually selected.

Key Access: Det/Demod

Auto The system selects peak detection as the default, but if a condition arises where a different type of detection scheme should be better utilized, the system will use the alternate scheme. For example, the Marker Noise function uses Average detection when in Auto mode because the system determines that the data will be more accurate for noise-type signals.

Key Access: Det/Demod, Detector Auto Man

Average Average detection is used when measuring the average value of the amplitude across each trace interval (bucket). The averaging method used by the Average detector will be set to either Video or Power as appropriate when the Average Type is Auto coupled or may be set explicitly through the **BW/Avg, Avg Type Auto Man** key.

Video Average detection computes the averaged trace interval as appropriate to the Y-axis scale:

- Log-power average when in log scale.
- Voltage average when in linear scale.
- Frequency deviation when Demod View is enabled for FM Demod.

Power Average (“root mean square” or RMS) detection computes the RMS of the samples collected across the trace interval. The number of samples included in the RMS average for each trace interval depends on the sweep time, the resolution bandwidth, and whether or not option B7D is installed. With option B7D installed, more samples are available as appropriate for wider resolution bandwidths and faster sweep times. Slower sweep times also increase the number of samples averaged for each trace interval.

When **Average** is selected, **Avg** appears on the left side of the display.

Key Access: Det/Demod, Detector Auto Man

Peak Peak detection is used primarily when measuring sinusoidal (spectral) components. Peak detection obtains the maximum video signal value between the last display point and the present display point and stores this value in memory. Peak detection is selected at power on and by pressing **Preset** when **Preset Type** is

set to **Factory** and **Power On** is set to **Preset**. When **Peak** detection is selected, **Peak** appears in the upper-left corner of the display.

Key Access: **Det/Demod**, **Detector Auto Man**

Sample Sample detection is used primarily to display noise or noise-like signals. This detection should not be used to make the most accurate amplitude measurement of non noise-like signals. In sample mode, the instantaneous signal value at the present display point is placed in memory. When **Sample** detection is selected, **Samp** appears in the upper-left corner of the display.

Key Access: **Det/Demod**, **Detector Auto Man**

Negative Peak Negative peak detection functions the same as peak detection, but selects the minimum video signal value. This detection should not be used to make the most accurate amplitude measurements of signals. When **Negative Peak** is selected, **NPk** appears in the upper-left corner of the screen.

Key Access: **Det/Demod**, **Detector Auto Man**

Demod Accesses the menu keys to select **AM** demodulation, **FM** demodulation or demodulation **Off**. It also accesses the **Demod View On Off**, **Speaker On Off**, and **Demod Time** menu keys described below.

Key Access: **Det/Demod**

NOTE The **FM** menu key only appears when the FM demod option (Option BAA) or Bluetooth™ FM Demodulation (Option 106) is installed. The two options are available on *Agilent ESA-E Series spectrum analyzers only (E4401B, E4402B, E4404B, E4405B and E4407B)*.

NOTE Segmented sweep is not available with the demodulation functions in this section.

Off Turns demodulation off.

Key Access: **Det/Demod**, **Demod**

AM Activating AM demodulation turns off FM demodulation (if it is on). For non-zero spans, a 10 kHz resolution bandwidth is used during demodulation, regardless of the screen annotation.

Key Access: **Det/Demod**, **Demod**

FM Turning FM demodulation on turns off AM demodulation (if it is on). For non-zero spans, a 100 kHz resolution bandwidth is used during the

demodulation, regardless of the screen annotation. When the span is set to zero span, the displayed bandwidth is used. For best results, move the signal to be demodulated to within 3 graticules of the top of the display.

Key Access: **Det/Demod**, **Demod**

Demod View
On Off

When **Demod View (On)** is pressed, the vertical scaling of the display is in frequency, and marker will read out the FM deviation in kHz. When Demod View is On, the following functions are not available: Log/Lin (the display is always linear and calibrated in Hz), Y Axis Units, Normalize, Display Line, Peak Excursion, and Peak Threshold. In AM Demod, pressing **Demod View (On)** has no effect. The Bluetooth™ FM Demod (Option 106) has a fixed vertical scale of approximately 40 kHz/Div.

Key Access: **Det/Demod**, **Demod**

Speaker
On Off

Turns the internal speaker on and off. The volume from the speaker is controlled by the front-panel volume control knob. Selecting AM or FM turns the speaker on. Turning AM or FM off, pressing **Preset** when **Preset Type** is set to **Factory**, or cycling the power sets the speaker function to off.

Key Access: **Det/Demod**, **Demod**

Demod Time

Allows you to set the time, in non-zero spans, to pause and demodulate the signal after each sweep. The demodulated signal can be heard during demodulation when in **Speaker (On)** mode. (In zero span, demodulation is performed (and can be heard) throughout the sweep.) In AM, the Video BW is set to 3 kHz and the Resolution BW is set to 10 kHz. In FM, the Video BW is set to 30 kHz and the Resolution BW is set to 100 kHz.

When AM or FM Demod is enabled, the instrument will tune to the marker frequency and wait for the Demod to take place. For long Demod times, pressing **Preset** when **Preset Type** is set to **Factory** will abort the Demod function. The default value is 500 ms.

Key Access: **Det/Demod**, **Demod**

NOTE

It is normal to hear clicking sounds when the Auto Alignment function is On. During retrace, a small portion of the analyzer circuitry is realigned. Some of the switching of the analyzer circuitry is done using relays. It is the rapid switching of these relays during retrace that causes the clicking sounds. To eliminate the clicking sounds, turn the auto alignment off by pressing **System, Alignments, Auto Align, Off**. When this is done, the **Align Now, All** function should be performed periodically. Refer to the Specifications Guide for your instrument to learn more information on how often to perform **Align Now, All** when the auto alignment is off.

Display

Accesses menu keys that allow you to control what is displayed on the analyzer, including titles, the display line, graticule and annotation, as well as the testing of trace data against user entered limits.

Full Screen Allows the measurement window to expand horizontally over the entire instrument display. Pressing a key that brings up a new menu will cancel the full screen function.

Key Access: **Display**

Display Line On Off Activates an adjustable horizontal line that is used as a visual reference line. The line, which can be used for trace arithmetic, has amplitude values that correspond to its vertical position when compared to the reference level. The value of the display line appears in the active function block and on the left side of the display. The display line can be adjusted using the step keys, knob, or numeric keypad. Pressing any digit, 0 through 9, on the numeric keypad brings up the selected terminator menu. To deactivate the display line, press **Display Line (Off)**.

Key Access: **Display**

Limits Accesses menu keys that allow you to create and define the parameters of limit lines.

Key Access: **Display**

Limit 1

Limit 2 Allows you to select either of the two available limits. The **Limit 1** and **Limit 2** keys access menu keys that allow you to set parameters for the selected limit.

Key Access: **Display, Limits**

Type

Upper Lower Allows you to define the limit you are editing as either an upper or lower limit. An upper limit fails if the trace exceeds the limit. A lower limit fails if the trace falls below the limit.

Key Access: **Display, Limits, Limit 1 or Limit 2**

Limit On Off Turns the limit line display on and off. Either **Limit** or **Margin**, as well as **Test**, must be turned on for a limit test to work.

Key Access: **Display, Limits, Limit 1 or Limit 2**

**Test
On Off**

Turns the testing of the limit lines on and off. If the trace is at or within the bounds of the set limit or margin, **PASS LIMIT #** or **PASS MARGIN #** is displayed in green in the upper left corner of the measurement area where # is the number of the selected limit line. (Colored annotation appears only with a color display.) Only positive margins are allowed for lower limits and only negative margins are allowed for upper limits. If the trace is out of the limit or margin boundaries, **FAIL LIMIT #** or **FAIL MARGIN #** is displayed in red. The results for Limit 2 are displayed below those for Limit 1. Either **Limit** or **Margin** must be turned on for **Test** to work.

Key Access: **Display, Limits, Limit 1** or **Limit 2**

**Margin
On Off**

Margin (Off) turns the margin off. **Margin (On)** allows you to set a limit line offset for the selected limit line. Either **Limit** or **Margin** as well as **Test**, must be turned on for a limit test to work.

Key Access: **Display, Limits, Limit 1** or **Limit 2**

Edit

Accesses the **Edit** menu keys which include **Point**, **Frequency** (or **Time** if **Display, Limits, X Axis Units (Time)** has been selected), **Amplitude**, **Connected to Previous Pt**, and **Delete Point**. **Edit** also accesses the limits table. The **Tab** keys allow you to move between the rows in the limits table. New limit segments will only be applied after the editor is closed. Pressing **Return**, or any key not associated with the editor, will close the editor.

Key Access: **Display, Limits, Limit 1** or **Limit 2**

Point

Allows you to create or edit a limit point. Up to 200 may be defined for

each limit line. Enter the point number to be created or edited using the numeric keypad, then Press **Enter**, or use the knob, Tab or step keys to move to an existing point. After selecting a point, **Frequency** (or **Time**) becomes active.

Key Access: Display, Limits, Limit 1 or Limit 2, Edit

Frequency (The key label is **Time** if **X Axis Units (Time)** has been selected.)

Allows you to enter the frequency value for a limit point. After entering a value, the limit table is sorted to place the frequency or time in the correct order. For a new point, **Amplitude** defaults to 0 dBm and **Connected to Previous Pt** defaults to **Yes**. **Amplitude** then becomes active.

Key Access: Display, Limits, Limit 1 or Limit 2, Edit

Amplitude

Allows you to enter the amplitude value for the current limit point. After entering a value, **Connected to Previous Pt** becomes active. If a Tab key is pressed without entering a value, the current **Amplitude** and **Connected to Previous Pt** values of the point are selected. If Tab ↑ is pressed, the point number automatically increments to allow entry of the amplitude of the next point, or if a new point, to allow **Frequency** to be entered for the new point.

Key Access: Display, Limits, Limit 1 or Limit 2, Edit

Connected to Previous Pt
Yes No

Allows you to determine whether the current point will be connected to the previous point. No limit testing is performed between disconnected . Pressing this key when the **Connected**

field is selected toggles the Connected value of the current point and increments the Point number to allow entry or editing of the Frequency of the next point. If a Tab key is pressed without entering a value, the current Connected value of the point is selected. If Tab ↑ is pressed, the Point number automatically increments to allow entry of the Connected value of the next point, or if a new point, to allow Frequency to be entered for the new point.

Key Access: **Display, Limits, Limit 1 or Limit 2, Edit**

Delete Point

Allows you to delete the current point in the limit line. You will be prompted with the message *If you are sure, press key again to delete.* Pressing **Delete Point** again will delete the point.

Key Access: **Display, Limits, Limit 1 or Limit 2, Edit**

Delete Limit

Allows you to delete the current limit set. You will be prompted with the message *If you are sure, press key again to delete.* Pressing **Delete** again will delete the limit set.

Key Access: **Display, Limits, Limit 1 or Limit 2**

Freq Interp Log Lin

Allows you to determine how limit trace values are computed between in a limit table. The available interpolation modes are linear and logarithmic. If the linear mode is used for both frequency and amplitude, a straight line is used when interpolating between in a limit table. If frequency interpolation is logarithmic, frequency values between limit are computed by first taking the logarithm of both the table values and the intermediate value. A linear interpolation is then performed in this

logarithmic frequency space. An exactly analogous manipulation is done for logarithmic amplitude interpolation.

Key Access: **Display**, **Limits**, **Limit 1** or **Limit 2**, **More**

**Amptd Interp
Log Lin**

Allows you to determine how limit trace values are computed between in a limit table. The available interpolation modes are linear and logarithmic. If the linear mode is used for both frequency and amplitude, a straight line is used when interpolating between in a limit table.

Key Access: **Display**, **Limits**, **Limit 1** or **Limit 2**, **More**

NOTE

Interpolation modes determine how limit values are computed between in the limit table. The appearance of a limit trace is also affected by the amplitude scale, which may be linear or logarithmic.

**X Axis Units
Freq Time**

Selects whether limit lines will be entered using frequency or sweep time to define the segments. They can be specified as a table of limit line segments of amplitude versus frequency, or of amplitude versus time. Time values are evaluated with respect to the analyzer sweep time. A time value of zero corresponds to the start of the sweep, which is at the left edge of the graticule.

Switching the limit line definition between frequency and time will erase both of the current limit lines. The message Changing X axis units will delete all limits. If you are sure, press key again to change units will appear. Press **X Axis Units Freq Time** again to purge both limit lines and switch between frequency and time.

Key Access: **Display**, **Limits**

Limits Fixed Rel

Allows you to choose fixed or relative limit lines. The fixed (**Fixed**) type uses the current limit line as a reference with fixed frequency and amplitude values. The relative (**Rel**) setting causes the current limit line value to be relative to the displayed center frequency and reference level amplitude values. When limit lines are specified with time, rather than frequency, the **Rel** setting only affects the amplitude values. The current amplitude values will be relative to the displayed reference level amplitude, but the time values will always start at the left edge of the graticule.

As an example, assume you have a frequency limit line. If the limit line is specified as fixed, entering a limit line segment with a frequency coordinate of 300 MHz displays the limit line segment at 300 MHz. If the same limit line table is specified as relative, it is displayed relative to the analyzer center frequency and reference level. If the center frequency is at 1.0 GHz, a relative limit line segment with a frequency coordinate of 300 MHz will display the limit line segment at 1.3 GHz. If the amplitude component of the relative limit line segment is -10 dB, then -10 dB is added to the reference level value to obtain the amplitude of the given segment (reference level offset included).

A limit line entered as fixed may be changed to relative, and one entered as relative may be changed to fixed. When changing between fixed and relative limit lines, the frequency and amplitude values in the limit line table change so that the limit line remains in the same position for the current frequency and amplitude settings of the analyzer. If a time and amplitude limit line is used, the amplitude values change but the time values remain the same.

Key Access: **Display, Limits**

**Delete
All Limits**

Allows you to purge data from the limit-line tables. Pressing **Delete Limits** after the prompt, If you are sure, press key again to delete, will delete the limits.

Key Access: **Display, Limits**

Title

Accesses the following **Title** menu keys which allows you to change or clear a title on your display.

Key Access: **Display**

Change Title Allows you to write a title across the top of the display. The marker readout may interfere with the last characters. The markers can be turned off by pressing **Marker, More, Marker All Off**. Pressing **Change Title** accesses the Alpha Editor Menus that contain available characters and symbols.

NOTE

Pressing **ESC** before exiting the Alpha Editor menus will retain the previous title.

The display title will remain until either **Change Title** is pressed again, or a trace is recalled that was previously saved with a title. A display title can also be cleared by using the clear function. Press **Display, Title, Clear Title**.

Key Access: **Display, Title**

Clear Title Allows you to clear a title from the front-panel display. Once cleared, the title cannot be retrieved.

Key Access: Display, Title

Preferences

Accesses a menu of the following display functions which allow you to turn the graticule and annotation on or off.

Key Access: Display

Graticule

On Off Turns the display graticule on and off.

Key Access: Display, Preferences

Annotation

On Off Turns the screen annotation on or off, however, menu key annotation will remain on the screen. The screen annotation may not be required for prints or during remote operation.

Key Access: Display, Preferences

Enter

Terminates and enters into the analyzer a numerical value that has been entered from the front panel using the numeric keypad. (For most applications, it is better to use the units menu keys.)

When using the **File** key menus, the **Enter** key is used to terminate filename entries. When entering titles (**Display**, **Title**, **Change Title**), the **Enter** key is used to terminate title entries.

ESC

Use the escape key to exit any function without modifying current parameters. Pressing the **ESC** key will:

- Clear any numeric entry that you have begun to enter and cancels the active function (see the section on display annotation, active function area, and other display features in the Getting Started guide for your instrument).
- Clear any title entry that you have begun to enter and cause the title to revert to the previous name.
- Clear input or output overloads.
- Clear error messages from the status line along the bottom of the display.
- Clear peak threshold from the display (turn it off) if the peak threshold line is on.
- Cancels a print, if one is in progress.

File

Accesses the menu keys used to view, save, load, and manage data on a floppy disk or the internal analyzer drive. Refer to the Getting Started Guide for your instrument for more information on file menu functions.

Catalog

Displays all directories and files located on the selected drive, depending upon the preferences set under the **Type** and **Sort** keys defined below.

Key Access: **File**

Type Allows you to select all types or one type of file(s) for viewing.

Key Access: **File, Catalog**

All Displays all files located on the selected drive.

Key Access: **File, Catalog, Type**

Setup Displays all setup files (.SET) in the selected directory. Setups are a complete set of instrument parameters including traces, states, limits, and corrections.

Key Access: **File, Catalog, Type**

State Displays all state files (.STA) in the selected directory. State files contain most instrument settings.

Key Access: **File, Catalog, Type**

Trace Displays all trace files (.TRC and .CSV) in the selected directory.

Key Access: **File, Catalog, Type**

Limits Displays all limits files (.LIM) in the selected directory.

Key Access: **File, Catalog, Type**

Screen Displays all screen (.GIF and .WMF) files in the selected directory.

Key Access: **File, Catalog, Type**

Corrections Displays all correction files (.ANT, .CBL, .OTH, .AMP) in the selected directory.

Key Access: **File, Catalog, Type, More**

Measurement Results Displays all measurement results files in the selected directory. Measurement results files are saved in .CSV format (for importing into spreadsheets).

Key Access: **File, Catalog, Type, More**

Sort Accesses the **Sort** menu keys that allow you to sort your files according to a selected file attribute. The selections include, **By Date, By Name, By Extension, By Size, and Order Up Down**. **Order (Up)** allows you to sort files in ascending order (for instance, A,B,C). **Order (Down)** allows you to sort files in descending order (for instance, C,B,A).

Key Access: **File, Catalog**

Dir Up Allows you to move up one directory level. If at the top level, **Dir Up** moves to the drive level, displaying the available disk drives.

Key Access: **File, Catalog**

Dir Select Accesses the highlighted directory on your display.

Key Access: **File, Catalog**

Save Accesses menu keys that allow you to save analyzer setups, states, traces, limits, corrections and screen data to a floppy (A:) drive or internal flash (C:) drive.

NOTE If you intend to save trace files for use with a personal computer, save them as .CSV (comma separated values). However, files formatted in this way cannot be loaded back into the analyzer.

NOTE Never remove the floppy disk during a save operation. To do so could corrupt *all* data on the floppy disk.

Key Access: **File**

Save Now Executes the save function. When the save is complete, the message `XXXXXX file saved` (where XXXXXX is the filename) will appear in the status line on your display.

Note that once you have used the **File, Save, Save Now** keys to setup and save a file, the **Save** hardkey will perform an immediate **Save Now** of your file in the same format and to the same location.

Key Access: **File, Save**

NOTE If the **Path:** field above the directory box is empty when pressing **Save Now**, the status line will display the error message: Unable to save file, invalid path. In this case, please select a drive.

Type Allows you to select the type of data you want to save.

Setup Displays all previously saved setup files and detects the current setup parameters in preparation to save them in a file for retrieval at a future date. Setup files include all instrument settings including traces, states, limits, and corrections.

NOTE When viewing a floppy disc with saved Setup files (filename.set) on a personal computer, notice there are also many similarly named files with extensions like .s01, .s02, etc. Do not delete these files as they are necessary to allow complete restoration of originally saved Setup.

Key Access: File, Save, Type

State Displays all previously saved state files and detects the current state parameters in preparation to save them in a file for retrieval at a future date. State files include all instrument settings but not traces, limits, and corrections. (This is the default setting when power is applied to the analyzer.)

Key Access: File, Save, Type

Trace Displays all previously saved trace files (.TRC) and detects the current trace in preparation to save it in a file for retrieval at a future date. A trace can be saved individually or as a group of traces. It can also be saved in .CSV (comma separated values) format (for importing into spreadsheets) or in .TRC format, accompanied by the analyzer state (for later recalling into the analyzer). (Note that CSV formatted data cannot be reloaded into the analyzer and TRC formatted data cannot be loaded into most personal computer programs.) Refer to the **Format** key description.

Key Access: File, Save, Type

Limits Displays all previously saved limits files and detects the current limits in preparation to save them in a file for retrieval at a future date. Limits provide data sets to determine whether a trace has exceeded preset specifications. Limit sets can hold up to 200 and can only be saved individually. Refer to the **File, Source** key description.

Key Access: **File, Save, Type**

Screen Displays all previously saved screen files and captures the current screen displayed in preparation to save it in a file for retrieval at a future date. Screen files can be saved in any of the following formats: Bitmap, Metafile, Reverse Bitmap, and Reverse Metafile. Refer to the **Format** key description.

Key Access: **File, Save, Type**

NOTE Screen files saved in WMF format can *only* be loaded into Microsoft®¹ applications such as Microsoft Word.

NOTE The screen saved is that which was displayed before pressing **File**. For this reason, the screens seen while in the file menus cannot be saved.

Corrections Displays all previously saved correction files and detects the current corrections in preparation to save them in a file for retrieval at a future date. Corrections provide a way to adjust the trace display for preset gain factors (such as for cable loss). A correction set may hold up to 200 . Pressing **Corrections** activates the **Source** key. Refer to the **Source** key description.

Key Access: **File, Save, Type, More**

Measurement Results Displays all previously saved measurement results files and detects the current measurement results in preparation to save them in a file for retrieval at a future date.

1. Microsoft® is a U.S. registered trademark of Microsoft Corporation.

Measurement results files are saved in .CSV format (for importing into spreadsheets).

Key Access: **File, Save, Type, More**

Format	<p><i>When Type is set to Trace, Format allows you to save a trace accompanied by the analyzer state. The CSV format is readable by a spreadsheet on your PC, but cannot be loaded back into the analyzer. The TRC format cannot be loaded into a PC, but can be loaded back into the analyzer. TRC files include the state of the analyzer and restore all settings when loaded.</i></p> <p><i>When Type is set to Screen, Format allows you to choose between bitmap and metafile formats. Bitmap saves the screen image in Graphics Interchange Format (GIF) and Metafile saves the screen image in Windows Metafile Format (WMF). Reverse Bitmap and Reverse Metafile turn black backgrounds to white and yellow traces to green so they can be printed visibly and with less use of black ink. Screen images cannot be loaded back into the analyzer.</i></p> <p>Key Access: File, Save</p>
Source	<p><i>When Type is set to Trace, Source allows you to save trace 1, 2, or 3 along with state. Saving trace All saves all traces in a single .trc file, along with the state.</i></p> <p><i>When Type is set to Corrections, Source accesses the Antenna, Cable, Other and User menu keys, which allow you to select the type of correction to be saved.</i></p> <p><i>When Type is set to Limits, Source accesses the Limit 1 and Limit 2 menu keys. Limit 1 and Limit 2 provide data sets to determine whether a trace has exceeded preset specifications. Limit sets can hold up to 200 and can only be saved individually.</i></p> <p>Key Access: File, Save</p>
Name	<p>Accesses the Alpha Editor and allows you to enter a filename. The external keyboard can also be used to enter a filename while the alpha editor is accessed.</p> <p>Key Access: File, Save</p>

NOTE

Only capital letters (A-Z) and digits (0-9) may appear in file names (8 characters, maximum). Additionally, file names include a 3 character extension which is automatically set by the instrument.

Dir Up	<p>Allows you to move up one directory level. If at the top level, Dir Up moves to the drive level, displaying the available disk drives.</p> <p>Key Access: File, Save</p>
Dir Select	<p>Accesses the highlighted directory on your display.</p> <p>Key Access: File, Save</p>
Load	<p>Accesses menu keys that allow you to load analyzer setups, states, traces, limits and corrections into the analyzer from a floppy (A:) drive or internal flash (C:) drive.</p> <p>Key Access: File</p>
Load Now	<p>Executes the load function. When the load is complete, the message <code>XXXXXX file loaded</code> (where <code>XXXXXX</code> is the filename) will appear in the status line on your display.</p> <p>Key Access: File, Load</p>
Type	<p>Allows you to select the type of file you want to load.</p>
Setup	<p>Displays all setup files you may wish to load (.SET). Setup files include a complete set of instrument parameters including traces, states, limits, and corrections. Loading a setup restores the analyzer (as closely as possible) to all previous instrument settings at the time of the save.</p> <p>Key Access: File, Load, Type</p>
State	<p>Displays all state files you may wish to load (.STA). Loading a state restores most settings to the previously saved values.</p> <p>Key Access: File, Load, Type</p>
Trace	<p>Displays all trace files (.TRC) you may wish to load. Traces can be loaded individually or as a group. When a trace is loaded, the state that existed when that trace was saved is loaded along with the trace. Also, the loaded trace is placed in view mode.</p> <p>Key Access: File, Load, Type</p>

NOTE If you wish to compare two saved traces, place traces in view mode before saving them. This prevents the trace from being rewritten based on a state change from subsequent loads.

Limits Displays all limits files you may wish to load to determine whether a trace has exceeded preset specifications (.LIM). Limit sets can hold up to 200 . Limits can only be loaded individually.

Key Access: **File, Load, Type**

NOTE When loading Limits files, be sure you have selected the appropriate X Axis Units: frequency or time (**Display, Limits, X Axis Units**). If you are in time X-Axis Units, and you load frequency limits, all current limit line data will be erased and the analyzer will switch to frequency units. The reverse of the this situation also holds true.

Corrections Displays all corrections files you may wish to load (.CBL, .ANT, .OTH, .AMP). Corrections provide a way to adjust the trace display for preset gain factors (such as for cable loss). A correction set may hold up to 200 .

Key Access: **File, Load, Type, More**

Measurement Results Displays all previously saved measurement results files you may wish to load. Measurement results files are saved in .CSV format (for importing into spreadsheets).

Key Access: **File, Load, Type, More**

Sort Accesses the **Sort** menu key.

Sort accesses a menu of keys that allow you to view your saved files according to a selected file attribute. The selections include, **By Date, By Name, By Extension, By Size, and Order Up Down**. **Order (Up)** allows you to view files in ascending order (for instance, A,B,C).

Order (Down) allows you to view files in descending order (for instance, C,B,A).

Key Access: **File, Load**

Destination *When Type is set to Trace*, **Destination** allows you to direct your data to **Trace 1, Trace 2, or Trace 3**. If the data is for all three traces (for instance, **Source** was **All** when they were saved), the data will be returned to the original trace registers.

When **Type** is set to **Limits**, **Destination** allows you to direct your data to **Limit 1** or **Limit 2**.

Key Access: **File, Load**

Dir Up Allows you to move up one directory level. If at the top level, **Dir Up** moves to the drive level, displaying the available disk drives.

Key Access: **File, Load**

Dir Select Accesses the highlighted directory on your display. If [. .] is highlighted, this key acts in the same manner as **Dir Up**.

Key Access: **File, Load**

Delete Allows you to delete files and directories.

Key Access: **File**

Delete Now Executes the delete function. If a directory is selected to be deleted, the message **WARNING: You are about to delete the contents of directory XXXXXX (where XXXXXX is the full path and directory name)** will appear on your display. After a successful delete, the message **XXXXXX file deleted (where XXXXXX is the filename)** will appear in the status line on your display.

Key Access: **File, Delete**

Type Allows you to select the type of file you want to delete.

Key Access: **File, Delete**

All Displays all files you may wish to delete.

Key Access: **File, Delete, Type**

Setup Displays all setup files you may wish to delete (.SET). A Setup file is a complete state of instrument parameters including traces, states, limits and corrections.

Key Access: **File, Delete, Type**

State Displays all state files you may wish to delete (.STA).

Key Access: **File, Delete, Type**

Trace Displays all trace files you may wish to delete (.TRC and .CSV).

Key Access: **File, Delete, Type**

	Limits	Displays all limits files you may wish to delete (.LIM). Key Access: File, Delete, Type
	Screen	Displays all screen files you may wish to delete (.GIF and .WMF). Key Access: File, Delete, Type
	Corrections	Displays all corrections files you may wish to delete (.CBL, .ANT, .OTH, .AMP). Key Access: File, Delete, Type, More
	Measurement Results	Displays all previously saved measurement results files you may wish to delete. Measurement results files are saved in (.CSV) format (for importing into spreadsheets). Key Access: File, Delete, Type, More
Sort		Sort accesses a menu of keys that allow you view the files you wish to delete, according to a selected file attribute. The selections include, By Date, By Name, By Extension, By Size, and Order Up Down . Order (Up) allows you to view files you may wish to delete in ascending order (for instance, A,B,C). Order (Down) allows you to view files you may wish to delete in descending order (for instance, C,B,A). Key Access: File, Delete
	Dir Up	Allows you to move up one directory level. If at the top level, Dir Up moves to the drive level, displaying the available disk drives. Key Access: File, Delete
	Dir Select	Accesses the highlighted directory on your display. If [. .] is highlighted, this key acts in the same manner as Dir Up . Key Access: File, Delete
Copy		Allows you to copy files from one directory to another or to one or more mass storage devices. Key Access: File
	Copy Now	Executes the copy function. If the copy is successful, the message xxxxx file copied (where xxxxx is the filename) will appear on the display.

Key Access: File, Copy

Type	Allows you to select the type of file you want to copy.
	Key Access: File, Copy
All	Displays all files you may wish to copy. Key Access: File, Copy, Type
Setup	Displays all setup (.SET) files you may wish to copy. A Setup file is a complete state of instrument parameters including traces, states, limits and corrections.

NOTE When using a personal computer to copy Setup files, ensure the similarly named files with extensions like .s01, .s02, etc. are also copied. These files are necessary to allow complete restoration of originally saved Setup.

	Key Access: File, Copy, Type
State	Displays all state (.STA) files you may wish to copy. Key Access: File, Copy, Type
Trace	Displays all trace (.TRC and .CSV) files you may wish to copy. Key Access: File, Copy, Type
Limits	Displays all limit (.LIM) files you may wish to rename. Key Access: File, Copy, Type
Screen	Displays all screen (.GIF and .WMF) files you may wish to rename. Key Access: File, Copy, Type
Corrections	Displays all corrections (.CBL, .ANT, .OTH, .AMP) files you may wish to rename. Key Access: File, Copy, Type, More
Measurement Results	Displays all previously saved measurement results files you may wish to delete. Measurement results files are saved in (.CSV) format (for importing into spreadsheets).

Key Access: **File, Copy, Type, More**

Sort **Sort** accesses a menu of keys that allow you to view the files you wish to copy according to a selected file attribute. The selection includes, **By Date, By Name, By Extension, By Size,** and **Order Up Down.** **Order (Up)** allows you to view files you may wish to copy in ascending order (for instance, A,B,C). **Order (Down)** allows you to view files you may wish to copy in descending order (for instance, C,B,A).

Key Access: **File, Copy**

Dir From To Allows you to select the source and destination directories for your copy on one or more drives.

Key Access: **File, Copy**

Dir Up Allows you to move up one directory level. If at the top level, **Dir Up** moves to the drive level, displaying the available disk drives.

Key Access: **File, Copy**

Dir Select Accesses the highlighted directory on your display.

Key Access: **File, Copy**

Rename Allows you to rename a file.

Key Access: **File**

Rename Now Executes the rename function. When the rename is complete, the message `XXXXXX file renamed to YYYYYY` (where `XXXXXX` and `YYYYYY` are the filenames) will appear in the status line on your display.

Key Access: **File, Rename**

Type Allows you to select the type of file you want to rename.

Key Access: **File, Rename**

All Displays all files you may wish to rename.

Key Access: **File, Rename, Type**

Setup Displays all setup (.SET) files you may wish to rename. A Setup file is a complete state of instrument parameters including traces, states, limits and corrections.

Key Access: **File, Rename, Type**

State	Displays all state (.STA) files you may wish to rename. Key Access: File, Rename, Type
Trace	Displays all trace (.TRC and .CSV) files you may wish to rename. Key Access: File, Rename, Type
Limits	Displays all limit (.LIM) files you may wish to rename. Key Access: File, Rename, Type
Screen	Displays all screen (.GIF and .WMF) files you may wish to rename. Key Access: File, Rename, Type
Corrections	Displays all corrections (.CBL, .ANT, .OTH, .AMP) files you may wish to rename. Key Access: File, Rename, Type, More
Measurement Results	Displays all previously saved measurement results files you may wish to rename. Measurement results files are saved in (.CSV) format (for importing into spreadsheets). Key Access: File, Rename, Type, More

Sort **Sort** accesses a menu of keys that allow you to view the files you wish to rename according to a selected file attribute. The selections include, **By Date, By Name, By Extension, By Size, and Order Up Down**. **Order (UP)** allows you to view files you may wish to rename in ascending order (for instance, A,B,C). **Order (Down)** allows you to view files you may wish to rename in descending order (for instance, C,B,A).

Key Access: **File, Rename**

Name **Accesses the Alpha Editor and allows you to enter a filename. The external keyboard can also be used to enter a filename while the alpha editor is accessed. Complete your entry by pressing Return or Enter.**

NOTE

Only capital letters (A-Z) and digits (0-9) may appear in file names (8 characters, maximum). Additionally, file names include a 3 character extension which is automatically set by the instrument.

Key Access: **File, Rename**

	Dir Up	Allows you to move up one directory level. If at the top level, Dir Up moves to the drive level, displaying the available disk drives. Key Access: File, Rename
	Dir Select	Accesses the highlighted directory on your display. Key Access: File, Rename
Create Dir		Allows you to create subdirectories. Key Access: File, More
	Create Dir Now	Executes the create directory function. When the directory has been created, the message <code>Directory XXXXXX created</code> (where XXXXXX is the directory name) will appear in the status line on your display. Key Access: File, More, Create Dir
	Name	Accesses the Alpha Editor and allows you to enter a filename. The external keyboard can also be used to enter a filename while the alpha editor is accessed. Complete your entry by pressing Return or Enter . Key Access: File, More, Create Dir
<hr/> NOTE <hr/>		Only capital letters (A-Z) and digits (0-9) may appear in file names (8 characters, maximum). Additionally, file names include a 3 digit extension which is automatically set by the instrument.
	Dir Up	Allows you to move up one directory level. If at the top level, Dir Up moves to the drive level, displaying the available disk drives. Key Access: File, More, Create Dir
	Dir Select	Accesses the highlighted directory on your display. Key Access: File, More, Create Dir
Format		Formats a double-density floppy disk to 1.44 MB format. 720 kB disks are not supported. Key Access: File, More
	Format Now.	Executes the format function. After pressing Format Now , the following message will appear on the display: <code>WARNING: You are about to destroy ALL data on volume A: Press Format Now again to proceed or any other key to abort. During the formatting, Formatting Disk will appear on the display. Once formatted, Volume A: formatted will appear in the status line on the display.</code>

NOTE

When using a personal computer to manipulate Setup files (filename.set) saved to a floppy, ensure the similarly named files with extensions like .s01, .s02, etc. are handled in a like manner. For example, if you rename of the .set file, you must rename all the .s0x files, as well. These files are necessary to allow complete restoration of the originally saved Setup.

Key Access: **File, More, Format**

Freq Count

Activates the **Marker Normal** function if there are no markers, and then turns the marker count function on.

Marker Count On Off

Marker Count (On) turns on the marker counter. If no marker is active before **Marker Count (On)** is pressed, a marker is activated at the center of the display. Press **Marker Count (Off)** to turn the marker counter off. Press **Resolution (Man)** to change the marker counter resolution to an uncoupled value.

NOTE

Marker Count frequency readings are not affected by the frequency offset function.

An asterisk (*) may appear in the upper-right area of the display along with the message **Cntr 1** (the number in the message depends on the active marker). The ratio of the resolution bandwidth to span must be greater than 0.002 for the marker count function to work properly. **Marker Count: Widen Res BW** appears on the display if the bandwidth to span ratio is less than 0.002. **Widen RES BW** indicates that the resolution bandwidth must be increased or the span decreased.

Key Access: **Freq Count**

Resolution Auto Man

Allows the resolution of the marker counter to be selected manually or auto-coupled. The marker counter has a resolution range of 1 Hz to 100 kHz. The available resolution values are 1 Hz, 10 Hz, 100 Hz, 1 kHz, 10 kHz, and 100 kHz. The resolution can be changed by using the step keys or by entering the resolution using the numeric keypad or knob. The marker counter resolution can be auto coupled to the span by pressing **Resolution (Auto)**.

Key Access: **Freq Count**

FREQUENCY Channel

Activates the center frequency function, and accesses the menu of frequency functions. The center frequency, or start and stop frequency values appear below the graticule on the display.

Although the analyzer allows entry of frequencies greater than the specified frequency range, using frequencies greater than the frequency range of the analyzer is not recommended

NOTE When changing both the center frequency and the span, change the frequency first since the span can be limited by the frequency value.

CAUTION When operating in dc coupled mode, take care to protect the input mixer by limiting the input level to 0 Vdc and +30 dBm.

Center Freq Activates the center frequency function (when **Scale Type** is set to **Lin**) which allows you to set the horizontal center of the display to a specific frequency. When **Scale Type** is set to **Log**, **Center Freq** activates the center frequency function which allows you to move the average of the start and stop frequencies. In this scale type the center frequency value will not necessarily represent the horizontal center of the display.

Key Access: **FREQUENCY Channel**

Start Freq Sets the frequency at the left side of the graticule. The left and right sides of the graticule correspond to the start and stop frequencies. When these frequencies are activated, their values are displayed below the graticule in place of center frequency and span.

Key Access: **FREQUENCY Channel**

Stop Freq Sets the frequency at the right side of the graticule. The left and right sides of the graticule correspond to the start and stop frequencies. When these frequencies are activated, their values are displayed below the graticule in place of center frequency and span.

Key Access: **FREQUENCY Channel**

CF Step Auto Man Changes the step size for the center frequency function. Once a step size has been selected and the center frequency function is activated, the step keys change center frequency by the step-size value. The step size function is useful for finding harmonics and sidebands beyond the current frequency span of the analyzer. When auto-coupled, the center frequency step size is set to one division (10 percent of the span).

Key Access: **FREQUENCY Channel**

Freq Offset

Allows you to input a frequency offset value that is added to the frequency readout of the marker, to account for frequency conversions external to the analyzer. Offset entries are added to all frequency readouts including marker, start frequency, and stop frequency. Offsets may only be entered using the numeric keypad. Offsets are not added to the span or frequency count readouts. Entering an offset does not affect the trace display. When a frequency offset is entered, its value appears on the bottom of the display. To eliminate an offset, perform a **Factory Preset**, or press **Freq Offset, 0, Hz**.

When a frequency offset is entered, its value appears on the bottom of the display (as opposed to reference level offsets, which appear on the left side of the display). To eliminate an offset, press **Freq Offset, 0**, and **Enter**. Pressing **Preset** also sets the offset to zero.

NOTE This function is not available when **FREQUENCY, Scale Type (Log)** is selected.

NOTE **Frequency, Scale Type (Log)** is not available when utilizing the frequency offset function.

Key Access: **FREQUENCY Channel**

Signal Track On Off

Moves the signal that is nearest to the active marker to the center of the display and keeps the signal there. **ST** appears in the lower-left corner of the display. An (*) may appear in the upper-right corner of the display while the analyzer is verifying that it has the correct signal.

Pressing **Signal Track (Off); Preset** (with **Preset Type** set to **Factory**); or **Marker, More, Marker All Off** turns off the signal track function.

When signal track is on and the span is reduced, an automatic zoom is performed and the span is reduced in steps so that the signal remains at the center of the display. If the span is zero, signal track cannot be activated.

Key Access: **FREQUENCY Channel**

NOTE If no marker is active, pressing **Signal Track (On)** will activate a marker, perform a peak search, and center the marker on the display.

NOTE Switching to zero span sets **Signal Track (Off)**.

NOTE **FREQUENCY, Scale Type (Log)** and **Segmented (On)** are not available when **Signal Track (On)** is selected.

Scale Type
Log Lin

Agilent ESA-E Series only (E4401B, E4402B, E4404B, E4405B and E4407B). Scales the horizontal (x-axis or frequency) graticule divisions logarithmically when **Scale Type (Log)** is selected. When **Scale Type (Lin)** is selected, the horizontal divisions are linearly scaled.

In **Scale Type (Log)**, the number of sweep is limited to a multiple of the number of sweep segments. For example, if you select 308 when 3 segments are required to create a logarithmic display, the will be set at 306 . The span determines the minimum number of sweep . Pressing **Preset** (when **Preset Type** is set to **Factory**) sets **Scale Type** to **Lin**.

NOTE

Sweep time is auto-coupled when **Scale Type (Log)** is selected.

NOTE

Marker Span Pair, Frequency Offset, Input Mixer (Ext), Segmented (On), Signal Track (On), and Demod View (On), are not available when **Scale Type (Log)** is selected.

NOTE

FREQUENCY, Scale Type (Log) is not available when **Frequency Offset, Segmented (On), Input Mixer (Ext), Zero Span, Signal Track (On)** is selected.

Key Access: **FREQUENCY Channel**

Help

Accesses a short description of any front panel or menu key. After pressing **Help**, an explanation of the next key pressed will appear on the display. After the information is displayed, press any key to remove the help window. Pressing **ESC** allows you to remove the help window without changing functions.

Input/Output

Input Z Corr
 50Ω 75Ω

Sets the input impedance for voltage-to-power conversions. The impedance you select is for computational purposes only, since the actual impedance is set by internal hardware to 50 Ω (except for Option 1DP). The default is 50 Ω (75 Ω with Option 1DP). Setting the computational input impedance to 75 Ω is useful when using a 75 Ω to 50 Ω adapter to measure a 75 Ω device on an analyzer having a 50 Ω input impedance.

Key Access: **Input/Output**

Coupling
 AC DC

Only available in Agilent models E4402B or E4407B with Option UKB, and E4404B or E4405B. Specifies alternating current (ac) or direct current (dc) coupling at the analyzer input. Selecting ac coupling blocks any dc voltage at the analyzer input, but also decreases the frequency range of the analyzer. Input coupling is set to ac by an instrument preset (With **Preset Type** set to **Factory**). Some amplitude specifications apply only when coupling is set to dc. Refer to the appropriate amplitude specifications and characteristics for your analyzer.

Table 3-1

Selecting Input Coupling

ESA Model #	AC Frequency Range	DC Frequency Range
E4402B with Option UKB	100 kHz to 3 GHz	100 Hz to 3 GHz
E4404B	100 kHz to 6.7 GHz	9 kHz to 6.7 GHz
E4404B with Option UKB	100 kHz to 6.7 GHz	100 Hz to 6.7 GHz
E4405B	100 kHz to 13.2 GHz	9 kHz to 13.2 GHz
E4405B with Option UKB	100 kHz to 13.2 GHz	100 Hz to 13.2 GHz
E4407B with Option UKB	10 MHz to 26.5 GHz	100 Hz to 26.5 GHz

CAUTION	When operating in dc coupled mode, ensure protection of the input mixer by limiting the input level to 0 Vdc, +30 dBm.
----------------	--

	Key Access: Input/Output
--	---------------------------------

Amptd Ref (f=50 MHz) On Off	<i>Agilent E4401B and E4411B only.</i> Turns the internal amplitude reference signal on or off. When the internal amplitude reference signal is on, the RF input is disabled.
--	---

	Key Access: Input/Output
--	---------------------------------

Amptd Ref Out (f=50 MHz) On Off	<i>Agilent E4402B, E4403B, E4404B, E4405B, E4407B and E4408B only.</i> Turns the external amplitude reference signal on or off.
--	---

	Key Access: Input/Output
--	---------------------------------

Input Mixer	<i>Agilent E4407B with Option AYZ only.</i> Accesses the following Input Mixer menu keys:
--------------------	---

	Key Access: Input/Output
--	---------------------------------

Input Mixer	
Int Ext	Allows you to select either the internal or an externally connected mixer as the input device. Selecting Input Mixer (Ext) activates all other keys in the Input Mixer menu and changes the attenuator annotation to Ext Mix . When Input Mixer (Ext) is selected, the attenuator function in the AMPLITUDE key menu is unavailable.
	Key Access: Input/Output, Input Mixer

NOTE	When Input Mixer (Ext) is selected, FREQUENCY, Scale Type (Log) is not available.
-------------	---

NOTE	Input Mixer (Ext) is not available when FREQUENCY, Scale Type (Log) is selected.
-------------	--

Ext Mix Band	Accesses the Ext Mix Band key menus and allows you to select one of the pre-defined bands corresponding to the external mixer being used. The start and stop frequencies and a letter corresponding to the waveguide band in use, appears on each menu key. If Mixer Type (Presel) is selected, selecting (K), (E), (W), (F), (D), (G), (Y), or (J) is not allowed. If Harmonic (Man) is selected, the word User will appear on the Ext Mix Band key.
	Key Access: Input/Output, Input Mixer

NOTE Segmented sweep is only operable for this function when center frequency and span are set within the frequency band of the mixer. If the mixer range is changed, segmented sweep is turned off.

Signal Ident

On Off

Activates a signal identification algorithm when **Signal Ident (On)** is selected, that either removes or aids with the identification of multiple and image responses of true input signals. Multiple and image responses maybe generated when using unpreselected external mixers.

Key Access: **Input/Output, Input Mixer**

NOTE Segmented sweep is not available when **Signal Ident (On)** is selected.

NOTE If the input signal is too broad band or unstable for the identification process to properly identify it, turn off the signal identification and look for two similar responses separated by approximately 642.8 MHz (twice the 321.4 MHz first IF). If a “-” mixer mode (for example: 8-) is active, the right member of the response pair is the correct response; if a “+” mixer mode is active, the left member of the response pair is the correct response.

The amplitude accuracy of the analyzer is degraded when signal identification is active, and the message Signal Ident On, Amptd Uncal will appear on the display.

Signal ID Mode

Allows you to select either of the following types of signal identification methods:

Key Access: **Input/Output, Input Mixer**

Image Suppress Selects a signal identification mode that attempts to suppress all but valid responses by mathematically removing all image and multiple responses of signals present at the mixer input. The analyzer internally acquires the data in a two sweep sequence, operates on the acquired data, and displays the result in Trace 1. Since two measurements are taken for each display cycle, the display update rate is reduced.

Key Access: **Input/Output, Input Mixer, Signal ID Mode**

Image Shift	<p>Allows the analyzer, in a two sweep sequence, to place data from the first sweep in Trace 1, and data from the second (frequency shifted) sweep in Trace 2. Signal responses of Trace 1 and Trace 2 having the same horizontal position are considered to be in the current band and therefore can be analyzed with the amplitude and frequency measurement systems of the analyzer. All other responses are invalid and should be ignored.</p> <p>Key Access: Input/Output, Input Mixer, Signal ID Mode</p>
Mixer Config	<p>Accesses the Mixer Config menu keys allowing you to manually set the harmonic, control the preselected mixers, and adjust the internal bias source for use with mixers requiring bias.</p> <p>Key Access: Input/Output, Input Mixer</p>
Harmonic Auto Man	<p>The harmonic value with its associated sign is automatically determined from the Ext Mix Band selected when in Harmonic (Auto) mode. Harmonic (Man) allows you to enter a harmonic value when required. If the harmonic mode for the external mixer is listed as “8 -”, for example, enter the harmonic number as “- 8”. The minus sign indicates that the tuned frequency is below the desired LO harmonic by the IF of 321.4 MHz. Similarly, if the harmonic mode of the external mixer is listed as “8 +”, enter the harmonic number as “8”.</p> <p>Key Access: Input/Output, Input Mixer, Mixer Config</p>
Mixer Type Presel Unpre	<p>Allows you to select which type of mixer is in use. Mixer Type (Presel) activates a tuning signal that is routed to the PRESEL TUNE OUTPUT connector on the rear panel of the analyzer. This signal has a sensitivity of 1.5V/GHz of the LO frequency and drives the tune input of the HP/Agilent 11974 series of</p>

preselected mixers. The sweep rate in **Presel** mode is limited to 40 MHz/msec.

Key Access: Input/Output, Input Mixer, Mixer Config

**Mixer Bias
On Off**

Mixer Bias (On) activates and allows adjustment of an internal bias source for use with external mixers. The bias signal is present on the center conductor of the IF INPUT connector on the front panel. The mixer bias will be **Off** if **Harmonic (Auto)** and **Mixer Type (Presel)** is selected.

Key Access: Input/Output, Input Mixer, Mixer Config

Marker

Accesses the marker control keys which select the type and number of markers and turns them on and off. Markers are diamond-shaped characters that identify traces. Up to four pairs of markers may appear on the display simultaneously; only one pair can be controlled at a time. The marker that is controlled is called the “active” marker. Pressing **Marker** activates the **Normal** menu key.

Select Marker 1 2 3 4

Selects one of the four possible markers. A marker that has already been turned on will become active when it is selected. If a marker has been turned on and assigned to a specific trace, it will become active on that trace if that marker is selected.

Key Access: **Marker**

Normal

Activates a single frequency marker at the center position of the active trace if a marker is not already displayed. If a marker is displayed before the **Normal** function is enabled, the marker is enabled at the position of the selected marker. The marker number is indicated above the marker. Use the data controls to position the marker. The knob and/or Up/Down keys move the marker left or right. If a value is entered from the numeric keypad, the marker is moved to the trace point nearest to that value. Annotation in the active function block and in the upper-right corner of the display indicates the frequency and amplitude of the marker (time and amplitude, if in zero span.) The marker stays on the trace at the horizontal screen position where it was placed unless **Signal Track**, or a “marker to” key function (such as **Mkr** → **CF**, **Mkr** → **RL**, **Mkr** → **CF STEP**, **Mkr** Δ **Span**, or **Min Search**) is selected. Pressing **Normal** turns off the **Delta** function and moves the active marker to the delta marker position.

Key Access: **Marker**

Delta

Activates a second marker at the position of the first marker. (If no marker is present, two markers appear at the center of the display.) The amplitude and frequency (or time) of the first marker is fixed. The marker number is indicated above the delta marker, and the same number is indicated with an \mathbb{R} (for example, $1\mathbb{R}$) above the reference marker. Use the data controls to position the delta marker. Annotation in the active function block and in the upper-right corner of the display indicates the frequency (or time) and amplitude differences between the two markers. The markers will be turned off if the scale type is changed between log and linear. (For information on using this function while in segmented sweep, refer to [“Interaction with Other Analyzer Functions”](#) in the segmented sweep section of this chapter which begins on [“Segmented” on page 249.](#))

Key Access: **Marker**

NOTE Pressing **Delta** again moves the reference marker to the active marker position, so you can make delta measurements from differing reference without having to turn off the markers and begin again.

NOTE The delta marker function permits signal-to-noise measurements provided the signal is a single spectral component (sinusoid). Place a normal marker on the signal, press **Delta**, place the delta marker in the noise, and activate **Marker Noise** (see below). The indicated amplitude difference is signal-to-noise/Hz.

Delta Pair
Ref Delta

Enters a mode that allows adjustment of both the **Ref** (start) and **Delta** (stop) markers independently. Pressing **Delta Pair**, toggles between the reference and delta markers. The start marker number is indicated with a number and an \mathbb{R} above the marker (for example, 1 \mathbb{R}) and the delta marker is indicated with a marker number. This mode is useful in functions such as **Band Power**. (For information on using this function while in segmented sweep, refer to “[Interaction with Other Analyzer Functions](#)” in the segmented sweep section of this chapter which begins on “[Segmented](#)” on page 249.)

Key Access: **Marker**

NOTE Ref and Delta markers maintain their displayed x-axis location, but not their frequency values when you change a parameter that redefines the x-axis scale. Reset these markers when parameters such as Span or Center Freq are changed.

Span Pair
Span Center

Enters a mode that allows adjustment of both the ref and delta markers. Pressing **Span Pair**, toggles between the span and center markers. The start marker number is indicated with a number and an \mathbb{R} above the marker (for example, 1 \mathbb{R}) and the stop marker is indicated with a marker number. Adjusting the span changes the frequency difference between the two markers while maintaining the midpoint between the two markers at a fixed frequency. Changing the center changes the center point between the two markers while maintaining the frequency difference. This mode is useful in functions such as **Band Power**. (For information on using this function while in segmented sweep, refer to “[Interaction with Other Analyzer Functions](#)” in the segmented sweep section of this chapter which begins on “[Segmented](#)” on page 249.)

NOTE Span Pair is not available when **FREQUENCY, Scale Type (Log)** is selected.

Key Access: **Marker**

Off Turns off the marker that has been selected by the **Select Marker 1 2 3 4** key. **Off** also turns off functions related to the selected marker such as signal track and demodulation. It also removes marker annotation from the display.

Key Access: **Marker**

Select Marker 1 2 3 4 Selects one of the four possible markers. A marker that has already been turned on will become active when it is selected. If a marker has already been turned on and assigned to a specific trace, it will become active on that trace if that marker is selected.

Key Access: **Marker, More**

Marker Trace Auto 1 2 3 Assigns a marker to a trace. Pressing **Marker Trace Auto 1 2 3** will activate a marker on trace 1 if there are no markers turned on. If a marker is currently active, press **Marker Trace Auto 1 2 3** until 1, 2, or 3 is underlined. The active marker will be moved to the selected trace.

Selecting the **Auto** mode will move the marker to the trace that is automatically selected. The selection order is to look for the lowest numbered trace in the following order of trace modes: clear-write, max-hold, min-hold, view-mode. If there are no traces in any of these modes, it selects trace 1.

Key Access: **Marker, More**

Readout Accesses the following menu keys that allow you to change the active marker readout.

Key Access: **Marker, More**

Frequency Sets the marker to **Frequency**. The default selection in non-zero spans, displays the absolute frequency of a normal marker or the frequency of the delta marker relative to the reference marker.

Key Access: **Marker, More, Readout**

Period Sets the marker readout to **Period**. Displays the reciprocal of the above frequency.

Key Access: **Marker, More, Readout**

Time Sets the marker readout to **Time**. The default selection in zero span, displays the time interval between a normal marker and the start of the sweep or the time of the delta marker relative to the reference marker.

Key Access: **Marker, More, Readout**

Inverse Time Sets the marker readout to **Inverse Time**. Displays the reciprocal of the above time interval.

Key Access: **Marker, More, Readout**

Function Accesses the following marker function menu keys listed below.
Key Access: **Marker, More**

Band Power Indicates the power over that part of the trace between the reference and active markers. If only one marker is present when you press **Band Power**, a second marker is placed at the same location as the first marker. To reposition the markers, press **Marker** to access **Delta Pair** and **Span Pair** keys. If **Detector (Auto)** is selected, average detection is used for $RBW \geq 1$ kHz, and Sample detection is used for $RBW < 1$ kHz.

Key Access: **Marker, More, Function**

NOTE For best accuracy, set the video bandwidth to at least ten times the resolution bandwidth to minimize its averaging effect.

NOTE **Band Power** has no meaning in zero span, and the indicated value is independent of signal level and marker placement.

Marker Noise Reads out the average noise level, referenced to a 1 Hz noise power bandwidth. If no marker is present, a marker appears at the center of the display. When Marker Noise is enabled in resolution bandwidths of 1 kHz and above, the auto coupled detector selection is set to Average and the Avg Type is set to Power because the trade-off between sweep time and variance of the result is best with power Average detection. In resolution bandwidths < 1 kHz, the auto coupled detector selection is Sample. However, the Marker Noise function generates appropriately corrected values for all supported detector modes. If the marker delta function is on and the noise marker is activated and moved to measure the noise floor, the marker readout will display the signal-to-noise ratio.

NOTE You can use **Delta** and **Marker Noise** to indicate noise level relative to sinusoidal signal (signal to noise). However, be sure to activate the delta marker before pressing **Marker Noise** or the reference marker units may be incorrect.

The noise marker averages 5% of the trace data values (one-half a horizontal division), centered on the location of the marker on the frequency or time scale. Marker noise indicates noise power density per Hertz or noise voltage per root Hertz depending upon the amplitude units selected. The number of sweep is noted in parenthesis to the right of the sweep time in the lower right corner of the graticule.

Note that the data values averaged will not always be symmetrical with respect to the marker position. If the marker is positioned within 2.5% of the beginning of the trace (one-quarter division), the trace data values in the first half-division will be averaged. Similarly, if the marker is positioned within 2.5% of the end of the trace, the trace data values in the last half-division will be averaged.

NOTE Do not use Marker Noise to evaluate the displayed average noise level of the analyzer relative to the specification. Read the displayed average noise level directly from the display or use the normal marker. Refer to Application Note 150 for a discussion of how noise is displayed on a spectrum analyzer.

To guarantee accurate data for noise-like signals, a correction for equivalent noise bandwidth for each resolution bandwidth is measured and included in the measurement. The Marker Noise function accuracy is optimal when the detector is set either to Average or to Sample because neither of these detectors peak-biases the noise.

Key Access: Marker, More, Function

Off Turns off the active function markers.
Key Access: Marker, More, Function

Marker Table On Off Compresses the graticule and displays marker information in a table. The information includes the marker number, trace number, marker type, X axis value, and the amplitude.
Key Access: Marker, More

Marker All Off Turns off all of the markers, including markers used for signal track and demodulation. Marker annotation is also removed.
Key Access: Marker, More

Marker →

Accesses the following marker function menu keys:

Mkr → CF Sets the center frequency of the analyzer to the marker frequency. In Delta mode, **Mkr → CF** sets the center frequency to the marker delta value. **Mkr → CF** is not available in zero span.

NOTE When the frequency scale is in log mode, the center frequency is not at the center of the display.

Key Access: **Marker** →

Mkr → CF Step Changes the center-frequency step size to match the value of the active marker. Press **Frequency** then **CF Step Auto Man** to view the step size. If marker delta is active, the step size will be set to the frequency difference between the markers. This function can be used to step from one signal harmonic to another. **Mkr → CF Step** is not available in zero span.

Key Access: **Marker** →

Mkr → Start Changes the start frequency so that it is equal to the frequency of the active marker. In Delta mode, **Mkr → Start** sets the start frequency to the marker delta value. **Mkr → Start** is not available in zero span.

Key Access: **Marker** →

Mkr → Stop Changes the stop frequency so that it is equal to the frequency of the active marker. In Delta mode, **Mkr → Stop** sets the stop frequency to the marker delta value. **Mkr → Stop** is not available in zero span.

Key Access: **Marker** →

Mkr Δ → Span Sets the start and stop frequencies to the values of the delta markers. The marker is then set to normal at the center frequency. **Mkr Δ → Span** is not available if the marker is off, or in zero span.

Key Access: **Marker** →

NOTE The above menu keys are not available when **Segmented (On)** is selected.

Mkr → Ref Lvl

Changes the reference level to the active marker value, moving the marked point to the reference level (top line of the graticule). In Delta mode, **Mkr → Ref Lvl** sets the reference level to the amplitude difference between the markers. (For example, if the difference is -15 dB, the reference level will be set to -15 dBm.)

Key Access: **Marker** →

Meas Control

If in a measurement, accesses a menu of keys that allow you to pause, resume, or restart one of the measurements available in the **MEASURE** key menu. **Meas Control** also allows you to select between continuous and single sweeps or measurements.

Press **MEASURE** and then select one of the available measurements (**Channel Power**, **Occupied BW**, **ACP**, **Multi-Carrier Power**, **Power Stat CCDF**, **Harmonic Distortion**, **Burst Power**, **Intermod (TOI)**, **Spurious Emissions**, or **Spectrum Emission Mask**). Once the desired measurement is selected, press **Meas Control**. **Meas Control** accesses the following keys:

Restart Performs the same functions as the “**Restart**” front-panel key. Repeats your measurement from the beginning. Pressing **Restart** while a measurement is being made will halt the current measurement routine at the first possible stopping point and repeat the measurement.

Key Access: **Meas Control**

Measure Single Cont **Measure (Single)** allows you to take one measurement sweep and display the measurement results. **Measure (Cont)** allows you to continuously run a measurement, displaying the results after each measurement sweep.

Key Access: **Meas Control**

Pause Allows you to pause a measurement. Pressing **Pause** will toggle between pausing and resuming your measurement. The key label will toggle between **Pause** and **Resume**. If an averaged measurement was in progress, the average counter is frozen and the measurement sweeping is halted.

Key Access: **Meas Control**

NOTE The measurements described above are those available in SA mode (see **Mode** key). Other measurements are available in other modes if an optional personality is installed.

Meas Setup

If in a measurement, **Meas Setup** displays one of six measurement setup menus. The setup menu displayed depends on which measurement (**Channel Power**, **Occupied BW**, **ACP**, **Multi-Carrier Power**, **Power Stat CCDF**, **Harmonic Distortion**, **Burst Power**, **Intermod (TOI)**, **Spurious Emissions**, or **Spectrum Emission Mask**) has been selected in the **MEASURE** menu.

NOTE The measurements described below are those available in SA mode (see **Mode** key). Other measurements are available in other modes if an optional personality is installed.

Channel Power Meas Setup Menu Keys

To access the following keys for setting up a channel power measurement, press **MEASURE**, **Channel Power** and then the front-panel **Meas Setup** key.

Avg Number On Off Press **Avg Number (On)** to specify the number of averages used when calculating the measurement result. The average will be displayed at the end of each sweep. **Avg Number (Off)** disables measurement averaging.

Key Access: **Meas Setup**

Avg Mode Exp Repeat Allows you to select the type of termination control used for the averaging function. This determines the averaging action after the specified number of measurements (average count) is reached. **Avg Mode** has no effect on measurements that are not averaged.

Exp Each successive data acquisition after the average count is reached is exponentially weighted and combined with the existing average. Exponential averaging weights new data more than old data, which facilitates tracking of slow-changing signals.

Repeat After reaching the average count, all previous result data is cleared and the average count is set back to 1.

Key Access: **Meas Setup**

Integ BW Allows you to specify the range of integration used in calculating the power in the channel, defaults to 2.0 MHz, or is defined by the radio standard selected. See Table 3-2, “Channel Power Default Settings for Radio Standards”. The range for this parameter is the available non-zero span range of the analyzer.

Key Access: **Meas Setup**

Table 3-2 Channel Power Default Settings for Radio Standards

Standard	Format	Device	Integration BW	Chan Pwr Span	VBW/RBW
None	N/A	N/A	2 MHz	3 MHz	10/1
IS95	N/A	BTS/MS	1.23 MHz	1.845 MHz	100 kHz/ 10 kHz
NADC	N/A	BTS/MS	32.8 kHz	49.2 kHz	10 kHz/ 1 kHz
W-CDMA	3GPP	BTS/MS	5.0 MHz	7.5 MHz	100 kHz/ 10 kHz
cdma2000	SR1	BTS/MS	1.23 MHz	1.845 MHz	100 kHz/ 10 kHz
cdma2000	SR3	BTS/MS	3.69 MHz	5.535 MHz	300 kHz/ 30 kHz
PDC	N/A	BTS/MS	21 kHz	31.5 kHz	100 kHz/ 10 kHz

Chan Pwr Span Allows you to specify the frequency span for the channel power measurement, defaults to 3.0 MHz, or is defined by the radio standard selected. See Table 3-2, “Channel Power Default Settings for Radio Standards”. Although channel power span is coupled to the integration bandwidth (IBW) at approximately 1.6 times the IBW, this parameter can be set manually: minimum = IBW, maximum = 10 times the IBW or the span of the analyzer.

Key Access: **Meas Setup**

Optimize Ref Level Sets the reference level and attenuator to optimum values based on the signal present at the input.

Key Access: **Meas Setup**

Occupied BW Meas Setup Menu Keys

To access the following keys for setting up an occupied bandwidth measurement, press **MEASURE**, **Occupied BW** and then the front-panel **Meas Setup** key.

Avg Number On Off Press **Avg Number (On)** to specify the number of averages used when calculating the measurement result. The average will be displayed at the end of each sweep. **Avg Number (Off)** disables measurement averaging.

Key Access: **Meas Setup**

**Avg Mode
Exp Repeat**

Allows you to select the type of termination control used for the averaging function. This determines the averaging action after the specified number of measurements (average count) is reached. **Avg Mode** has no effect on measurements that are not averaged.

Exp Each successive data acquisition after the average count is reached is exponentially weighted and combined with the existing average. Exponential averaging weights new data more than old data, which facilitates tracking of slow-changing signals.

Repeat After reaching the average count, all previous result data is cleared and the average count is set back to 1.

Key Access: **Meas Setup**

**Max Hold
On Off**

Allows you to turn maximum hold trace feature **On** or **Off** for the measurement. Maximum hold displays and holds the maximum responses of a signal.

Key Access: **Meas Setup**

Occ BW % Pwr

Allows you to change the percentage of the total input signal power used when determining the occupied bandwidth. The acceptable range for this parameter is from 10% to 99.99%.

Key Access: **Meas Setup**

OBW Span

Allows you to specify the range of integration used in calculating the total power from which the percent occupied bandwidth is then calculated. The analyzer span will be set to the same value as the OBW Span for the measurement. OBW Span should be set to approximately 2 times the expected occupied bandwidth result. Refer to Table 3-3, "Occupied Bandwidth Default Settings for Radio Standards".

Key Access: **Meas Setup**

Table 3-3

Occupied Bandwidth Default Settings for Radio Standards

Standard	Format	Device	OBW Span	VBW/RBW
None	N/A	N/A	3 MHz	10/1 ¹
IS95	N/A	BTS/MS	2.0 MHz	100 kHz/ 10 kHz
NADC	N/A	BTS/MS	80 kHz	10 kHz/ 1 kHz
W-CDMA	3GPP	BTS/MS	6.0 MHz	1 MHz/ 100 kHz
cdma2000	SR1	BTS/MS	2.0 MHz	100 kHz/ 10 kHz

Table 3-3 Occupied Bandwidth Default Settings for Radio Standards


Standard	Format	Device	OBW Span	VBW/RBW
cdma2000	SR3	BTS/MS	6.0 MHz	1 MHz/ 100 kHz
PDC	N/A	BTS/MS	31.5 kHz	3 kHz/ 300 Hz

1. Maximum RBW available and < 1% of the OBW span.

x dB Allows you to specify the power level used to determine the emission bandwidth as the number of dB down from the highest signal point (P_1), within the occupied bandwidth span. Frequencies f_1 and f_2 are determined as the furthest frequencies x dB below and above P_1 , respectively. The emission bandwidth is then calculated as $f_2 - f_1$ as shown in Figure 6-1.

NOTE The asterisk next to the x dB value in Figure 3-5 indicates the results may not have been determined with optimal analyzer settings. If emission bandwidth is your primary interest, select **Meas Setup, Max Hold**. Then change detector mode to peak by pressing **Det/Demod, Detector, Peak**. Acquiring peak data ensures accuracy of this measurement.

Figure 3-5 Occupied Bandwidth Measurement Results



NOTE The “Transmit Freq Error” displayed above is defined as the difference between the $(f_2 + f_1)/2$ and the tuned center frequency of the signal.

Optimize Ref Level Sets the reference level and attenuator to optimum values based on the signal present at the input.
Key Access: **Meas Setup**

ACP Meas Setup Menu Keys

To access the following keys for setting up an adjacent channel power measurement, press **MEASURE**, **ACP** and then the front-panel **Meas Setup** key.

Avg Number On Off Press **Avg Number (On)** to specify the number of averages used when calculating the measurement result. The average will be displayed at the end of each measurement. **Avg Number (Off)** disables measurement averaging.

Key Access: **Meas Setup**

Avg Mode Exp Repeat Allows you to select the type of termination control used for the averaging function. This determines the averaging action after the specified number of measurements (average count) is reached. **Avg Mode** has no effect on measurements that are not averaged.

Exp Each successive data acquisition after the average count is reached is exponentially weighted and combined with the existing average. Exponential averaging weights new data more than old data, which facilitates tracking of slow-changing signals.

Repeat After reaching the average count, all previous result data is cleared and the average count is set back to 1.

Key Access: **Meas Setup**

Chan Integ BW Allows you to specify the range of integration used in calculating the power in the main channel. The default value is 2.0000 MHz. The range for this parameter is 300 Hz to 20 MHz. When selecting a radio standard by pressing **Mode Setup**, **Radio Std**, this parameter is defined by Table 3-4, “Adjacent Channel Power Default Settings for Radio Standards”.

Table 3-4 Adjacent Channel Power Default Settings for Radio Standards

Parameter	None	IS-95	J-STD-008	NADC	3GPP W-CDMA	cd.a2000 SR1	cdma2000 SR3-MC	cdma2000 SR3-DS	PDC
Detector	Avg	Avg	Avg	Avg (BTS) Peak (MS)	Avg	Avg	Avg	Avg	Peak
Sweep Time	5.12 ms	59.4 ms	59.4 ms	337.6 ms (BTS) 8.02 s (MS)	43.6 ms	59.4 ms	59.4 ms	59.4 ms	8.02 s
Span	8 MHz	0 Hz	0 Hz	212.8 kHz	24.68 MHz	0 Hz	0 Hz	0 Hz	221 kHz
RBW	100 kHz	3.0 MHz	3.0 MHz	1 kHz	30 kHz	3.0 MHz	5.0 MHz	5.0 MHz	1 kHz
VBW	1 MHz	3.0 MHz	3.0 MHz	10 kHz	300 kHz	3.0 MHz	3.0 MHz	3.0 MHz	10 kHz
Main Channel IBW	2.00 MHz	1.23 MHz	1.23 MHz	40 kHz (not filtered)	3.84 MHz (displayed) 4.68 MHz (actual, RRC filtered)	1.23 MHz	3.96 MHz	3.96 MHz	21 kHz
Offset A Freq	3.00 MHz	750 kHz (BTS)	885 kHz (BTS)	30 kHz	5 MHz	750 kHz (BTS)	2.13 MHz (BTS)	2.65 MHz	50 kHz
Offset A Freq	N/A	885 kHz (MS)	1.265 MHz (MS)	N/A	N/A	885 kHz (MS)	2.65 MHz (MS)	N/A	N/A
Offset A BW	2.00 MHz	30 kHz	30 kHz (BTS & MS)	24.3 kHz (displayed) 32.8 kHz (actual, RRC Filtered)	3.84 MHz (displayed) 4.68 MHz (actual, RRC filtered)	30 kHz	30 kHz (BTS & MS)	30 kHz	21 kHz
Offset A RBW	N/A	30 kHz	30 kHz	N/A	N/A	30 kHz	30 kHz	30 kHz	N/A
Offset A VBW	N/A	300 kHz	300 kHz	N/A	N/A	300 kHz	300 kHz	300 kHz	N/A
Offset B Freq	N/A	1.98 MHz	1.256 MHz	60 kHz	10 MHz	1.98 MHz	2.5 MHz (BTS) 3.75 (MS)	3.75 MHz	100 kHz
Offset B BW	N/A	30 kHz	12.5 kHz (BTS)	24.3 kHz (displayed) 32.8 kHz (actual, RRC Filtered)	3.84 MHz (displayed) 4.68 MHz (actual, RRC filtered)	30 kHz	30 kHz (BTS & MS)	30 kHz	21 kHz
Offset B RBW	N/A	30 kHz	10 kHz (BTS)	N/A	N/A	30 kHz	30 kHz	30 kHz	N/A
Offset B VBW	N/A	300 kHz	100 kHz (BTS)	N/A	N/A	300 kHz	300 kHz	300 kHz	N/A
Offset C Freq	N/A	N/A	N/A	90 kHz	N/A	N/A	N/A	N/A	N/A

Table 3-4 Adjacent Channel Power Default Settings for Radio Standards

Parameter	None	IS-95	J-STD-008	NADC	3GPP W-CDMA	cd,a2000 SR1	cdma2000 SR3-MC	cdma2000 SR3-DS	PDC
Offset C IBW	N/A	N/A	N/A	24.3 kHz (displayed) /32.8 kHz (actual, RRC Filtered)	N/A	N/A	N/A	N/A	N/A
RRC Filter State	N/A	N/A	N/A	N/A	On	N/A	N/A	N/A	N/A
RRC Filter α	N/A	N/A	N/A	.35	.22	N/A	N/A	N/A	N/A

Key Access: **Meas Setup**

Offset/Limits

Allows you to edit frequencies and reference bandwidths for a maximum of 6 offsets (labeled A-F).

Key Access: **Meas Setup**

Offset Allows you to select which offset (A-F) you wish to define.

Offset Freq Sets the frequency difference from the center of the main channel to the center of the offset. When **Radio Std, None** is selected, the default is 3.0 MHz.

Ref BW Sets the reference bandwidth (integration bandwidth) for each offset. When **Radio Std, None** is selected, the default is 2.0 MHz.

Pos Offset Limit Sets the limit for the upper segment of the specified offset pair.

Neg Offset Limit Sets the limit for the lower segment of the specified offset pair.

Key Access: **Meas Setup, Offset/Limits**

Meas Type

Allows you to specify the reference for the ACP measurement. Relative values can be displayed referenced to either the total power or the power spectral density measured in the main channel.

Total Pwr Ref Press **Total Pwr Ref** to specify the reference for the measurement to the total power.

PSD Ref Press **PSD Ref** to specify the reference for the measurement to power spectral density.

Key Access: **Meas Setup, Meas Type**

Optimize Ref Level Sets the reference level and attenuator to optimum values based on the signal present at the input.

Key Access: **Meas Setup**

Method IBW RBW Allows you to select between the integration bandwidth measurement method (IBW), or the resolution bandwidth measurement method (RBW). The resolution bandwidth method is most useful for measuring cdmaOne and cdma2000 SRI signals.

Key Access: **Meas Setup, More**

Total Pwr Ref Auto Man Allows you to specify the reference for the adjacent channel power measurement when set to **Auto**. Relative values are displayed, referenced to the total power measured in the main channel.

Key Access: **Meas Setup, More**

Limits On Off Turns the testing of the limit line on or off. Any offsets that are in the Off state are not measured and their results will not appear on the display.

Key Access: **Meas Setup, More**

Filter On Off Adds root raised cosine filtering required by the standards when **Radio Std, NADC** or **Radio Std, W-CDMA 3GPP** are selected. The filter rolloff (α) is 0.22 for W-CDMA 3GPP and 0.35 for NADC.

Key Access: **Meas Setup, More**

Noise Corr On Off When **Noise Corr (On)** is selected, a calibration of the noise floor is performed and used to correct for analyzer noise floor contribution to measurement levels.

Key Access: **Meas Setup, More**

Multi-Carrier Power Meas Setup Menu Keys

To access the following keys for setting up a multi-carrier power measurement, press **MEASURE**, **Multi-Carrier Power** and then the front-panel **Meas Setup** key.

The multi-carrier power measurement is a measure of the power that leaks into adjacent transmit channels. The results reported are identical to the adjacent channel power measurement, but the setup is different to allow for two or more carriers present.

Avg Number On Off Press **Avg Number (On)** to specify the number of averages used when calculating the measurement result. The average will be displayed at the end of each sweep. **Avg Number (Off)** disables measurement averaging.

Key Access: **Meas Setup**

**Avg Mode
Exp Repeat**

Allows you to select the type of termination control used for the averaging function. This determines the averaging action after the specified number of measurements (average count) is reached. **Avg Mode** has no effect on measurements that are not averaged.

Exp Each successive data acquisition after the average count is reached is exponentially weighted and combined with the existing average. Exponential averaging weights new data more than old data, which facilitates tracking of slow-changing signals.

Repeat After reaching the average count, all previous result data is cleared and the average count is set back to 1.

Key Access: **Meas Setup**

2nd Car Offs

Allows you to change the frequency difference from the main carrier to the second carrier, measured in MHz. The center frequency of the main carrier is the analyzer center frequency less half of the second carrier offset in MHz. The second carrier center frequency is the main carrier center frequency plus the second carrier offset value in MHz. The available offset values are -15, -10, -5, 5, 10, and 15 MHz. The negative values set the offset below the main carrier frequency, and the positive values set the offset above the main carrier frequency.

Key Access: **Meas Setup**

**Optimize
Ref Level**

Sets the reference level and attenuator to optimum values based on the signal present at the input.

Key Access: **Meas Setup**

Offset/Limits

Displays menu keys that allow you to configure the offsets for the multi-carrier power measurement.

Key Access: **Meas Setup, More**

Offset

A B C D Selects the offset the menu keys will affect. Press **Offset** until the letter of the desired offset (A, B, C, or D) is underlined.

Upper Offset

Limit Sets the limit for the upper segment of the specified offset pair.

Lower Offset

Limit Sets the limit for the lower segment of the specified offset pair.

Key Access: **Meas Setup, More, Ofs & Limits**

**Limits
On Off**

Turns the limits on or off.

Key Access: **Meas Setup, More**

**RRC Filter
On Off**

Turns the Root Raised Cosine filter on or off. The RRC filter is the type specified in the W-CDMA 3GPP standards, with rolloff (α)=0.2.

Key Access: **Meas Setup, More**

Table 3-5 Multi-Carrier Power Default Settings for 3GPP W-CDMA

Parameter	None	3GPP W-CDMA
Detector	Avg	Avg
Sweep Time	86.4 ms	87.6 ms
Span	48.84 MHz	49.68 MHz
RBW	30 kHz	30 kHz
VBW	300 kHz	300 kHz
RRC Filter a	N/A	.22

Power Stat CCDF Meas Setup Menu Keys

To access the following keys for setting up a power statistics or complementary cumulative distribution function (CCDF) measurement, press **MEASURE, Power Stat CCDF** and then the front-panel **Meas Setup** key.

Power complimentary cumulative distribution function (CCDF) curves characterize the higher-level power of the signal. It provides the distribution of peak-to-average power ratios versus probability. A CCDF curve is defined by how much time the waveform spends at or above the given power level. The percent of time the signal spends at or above the level defines the probability for that particular power level.

**Meas BW
5.0 MHz**

Allows you to set the measurement bandwidth according to the channel bandwidth. The range is 1.00 kHz to 5.00 MHz.

Key Access: **Meas Setup**

**Counts
100.000 k**

Allows you to set the accumulated number of sampling for data acquisition. The range is 1.00 k (1×10^3) to 1.00 G (1×10^9).

Key Access: **Meas Setup**

**Meas Interval
1.00 ms**

Allows you to specify the time interval over which the measurement is made. The range is dependent upon the measurement bandwidth.

Key Access: **Meas Setup**

**Optimize
Ref Level**

Sets the reference level and attenuator to optimum values based on the signal present at the input.

Key Access: **Meas Setup**

Table 3-6

CCDF Default Settings for Radio Standards

Standard	Format	Device	Meas Interval	VBW/RBW
None	N/A	N/A	1.0 ms	Wide open/ 5 MHz
IS95	N/A	BTS/MS	1.0 ms	Wide open/ 3 MHz
GSM/EDGE	N/A	BTS/MS	1.0 ms	Wide open/ 1 MHz
W-CDMA	3GPP	BTS/MS	1.0 ms	Wide open/ 5 MHz
cdma2000	SR1	BTS/MS	1.0 ms	Wide open/ 5 MHz
cdma2000	SR3	BTS/MS	1.0 ms	Wide open/ 5 MHz
NADC	N/A	BTS/MS	1.0 ms	Wide open/ 100 kHz
PDC	N/A	BTS/MS	1.0 ms	Wide open/ 100 kHz

Harmonic Distortion Meas Setup Menu Keys

To access the following keys for setting up a harmonic distortion measurement, press **MEASURE**, **Harmonic Distortion** and then the front-panel **Meas Setup** key.

**Avg Number
On Off**

Press **Avg Number (On)** to specify the number of averages used when calculating the measurement result. The average will be displayed at the end of each sweep. **(Off)** disables measurement averaging.

Key Access: **Meas Setup**

**Avg Mode
Exp Repeat**

Allows you to select the type of termination control used for the averaging function. This determines the averaging action after the specified number of measurements (average count) is reached. **Avg Mode** has no effect on measurements that are not averaged.

Exp. Each successive data acquisition after the average count is reached is exponentially weighted and combined with the existing average. Exponential averaging weights new data more than old data, which facilitates tracking of slow-changing signals.

Repeat. After reaching the average count, all previous result data is cleared and the average count is set back to 1.

Key Access: **Meas Setup**

Harmonics **Harmonics** indicates the number of harmonics to measure before computing the total harmonic distortion. The minimum number is 2 (only the fundamental and second harmonic will be measured). The maximum number is 10.

Key Access: **Meas Setup**

ST/Harmonic Auto Man **ST/Harmonic (Auto)** sets the sweeptime to 200 divided by the resolution bandwidth or 10 ms, whichever is greater. **ST/Harmonic (Man)** allows you to specify any sweeptime from 10 ms to the analyzer maximum. This sweeptime is used only for measuring harmonics. The sweeptime set before the measurement began is used for finding the fundamental.

Key Access: **Meas Setup**

Optimize Ref Level Sets the reference level and attenuator to optimum values based on the signal present at the input.

Key Access: **Meas Setup**

Burst Power Meas Setup Menu Keys

To access the following keys for setting up a burst power measurement, press **MEASURE**, **Burst Power** and then the front-panel **Meas Setup** key.

Key Access: **Meas Setup**

Avg Number On Off Press **Avg Number (On)** to specify the number of averages used when calculating the measurement result. The average will be displayed at the end of each sweep. **Avg Number (Off)** disables measurement averaging.

Key Access: **Meas Setup**

Avg Mode Exp Repeat Allows you to select the type of termination control used for the averaging function. This determines the averaging action after the specified number of measurements (average count) is reached. **Avg Mode** has no effect on measurements that are not averaged.

Exp Each successive data acquisition after the average count is reached is exponentially weighted and combined with the existing average. Exponential averaging weights new data more than old data, which facilitates tracking of slow-changing signals.

Repeat After reaching the average count, all previous result data is cleared and the average count is set back to 1.

Key Access: **Meas Setup**

Avg Type Video Power	Allows you to specify the type of result averaging to be performed. Video Selects averaging that sums the trace data and divides by the number of data . Power Selects averaging that converts trace data from dBm to power units, then averages the power trace data. This selection requires more time to perform. Key Access: Meas Setup
Threshold Lvl Abs Rel	Allows you to set the level above which the mean carrier power calculation is based upon. The threshold level may be described in dB (relative to the carrier) or dBm (absolute). Key Access: Meas Setup
Meas Method Above Threshold Lvl	Allows you to select the measurement method. Selects the user defined threshold level or default level (-3.00 dB) as the criteria in making the measurement.
Measured Burst Width	This measurement method is not available for the following radio standards: IS95, J-STD-008, cdma2000-SR1, cdma2000-SR3, W-DCMA 3GPP. Key Access: Meas Setup

Table 3-7 Burst Power Default Settings for Radio Standards

Standard	Format	Device	Method	Sweep Time	Burst Width	Threshold Level	Resolution BW	Video BW
None	N/A	N/A	ATL ¹	640 μs	N/A	-30 dB	3 MHz	Wide Open
IS95		BTS/MS	ATL ²	2 ms	N/A	-30 dB	3 MHz	Wide Open
GSM/EDGE	N/A	BTS/MS	MBW ³	2 ms	N/A	-20 dB	300 kHz	300 kHz
W-CDMA	3GPP	BTS/MS	ATL ²	2 ms	N/A	-30 dB	5 MHz	Wide Open
cdma2000	SR1	BTS/MS	ATL ²	2 ms	N/A	-30 dB	3 MHz	Wide Open
cdma2000	SR3	BTS/MS	ATL ²	2 ms	N/A	-30 dB	5 MHz	Wide Open
NADC	N/A	BTS	MBW ³	10 ms	Auto	-30 dB	100 kHz	Wide Open
NADC	N/A	MS	ATL ²	6 ms	N/A	-30 dB	100 kHz	Wide Open
PDC	N/A	BTS	MBW ³	10 ms	Auto	-30 dB	100 kHz	Wide Open
PDC	N/A	MS	MBW ³	6 ms	N/A	-30 dB	100 kHz	Wide Open
Bluetooth™	DH1,DH3,DH5	N/A	N/A	N/A	N/A	N/A	3 MHz	Wide Open

1. Above threshold level
2. Above threshold level
3. Measured Burst Width

NOTE The measurements described above are those available in SA mode (see **Mode** key). Other measurements are available in other modes if an optional personality is installed.

Burst Width Sets the burst width parameter to automatic mode (**Auto**) or manual mode (**Man**).
Auto Man

In **Auto** the burst width is automatically calculated based on the threshold level. For example, if the threshold level is set to 3 dB, the burst width will be the time between the two 3 dB. This will update after each sweep, but before any results are calculated. Since the measurement only measures over the burst width, this will force a measurement between the 3 dB.

In **Man** you can specify the burst width to measure a portion of the burst. You can enter a fixed-time value in seconds, or specify the burst width as a percentage of the last measured burst width. If you specify the burst width as a percentage, the fixed-value time is instantaneously calculated and displayed on the menu key.

Key Access: **Meas Setup**

**Optimize
Ref Level**

Sets the reference level and attenuator to optimum values based on the signal present at the input.

Key Access: **Meas Setup, More**

Intermod (TOI) Meas Setup Menu Keys

To access the following keys for setting up a third order intercept (TOI) measurement, press **MEASURE**, **Intermod (TOI)**, and then the front-panel **Meas Setup** key.

Key Access: **Meas Setup**

**Avg Number
On Off**

Press **Avg Number (On)** to specify the number of averages used when calculating the measurement result. The average will be displayed at the end of each sweep. **Avg Number (Off)** disables measurement averaging.

Key Access: **Meas Setup**

**Avg Mode
Exp Repeat**

Allows you to select the type of termination control used for the averaging function. This determines the averaging action after the specified number of measurements (average count) is reached. **Avg Mode** has no effect on measurements that are not averaged.

Exp Each successive data acquisition after the average count is reached is exponentially weighted and combined with the existing average. Exponential averaging weights new data more than old data, which facilitates tracking of slow-changing signals.

Repeat After reaching the average count, all previous result data is cleared and the average count is set back to 1.

Key Access: **Meas Setup**

TOI Span

Press **TOI Span** to specify the frequency span in which intermodulation products are measured. The preset value (when **Preset Type** is set to **Factory**) is 15 MHz, or as defined in the following table by the radio standard selected.

Radio Standard	Device	Span	VBW	RBW
None	N/A	15 MHz	100 kHz	100 kHz
IS95	BTS/MS	10 MHz	100 kHz	100 kHz
cdma2000 SR1	BTS/MS	10 MHz	100 kHz	100 kHz
cdma2000 SR3	BTS/MS	30 MHz	300 kHz	300 kHz
W-CDMA 3GPP	BTS/MS	30 MHz	300 kHz	300 kHz
NADC	BTS/MS	400 kHz	3 kHz	3 kHz
PDC	BTS/MS	250 kHz	3 kHz	3 kHz

Key Access: **Meas Setup**

Max Mixer Lvl

Allows you to change the maximum input mixer level from 10 dBm to –100 dBm in 10 dB steps using the step keys, and in 1 dB steps using the knob. In addition, you may use the keypad to specify a value. The mixer level is equal to the reference level minus the attenuator setting. As the reference level changes, the input attenuator setting is changed to keep the power levels of on-screen signals less than the selected level at the input mixer. Performing a **Factory Preset** resets the maximum input mixer level to –10 dBm.

Key Access: **Meas Setup**

**Optimize
Ref Level**

Sets the reference level and attenuator to optimum values based on the signal present at the input.

Key Access: **Meas Setup**

Spurious Emissions Meas Setup Menu Keys

To access the following keys for setting up a spurious emissions measurement, press **MEASURE**, **Spurious Emissions** and then the front-panel **Meas Setup** key. The spurious emissions measurement identifies and determines the power level of spurious emissions in certain frequency bands.

Key Access: **Meas Setup**

**Avg Number
On Off**

Press **Avg Number (On)** to specify the number of averages used when calculating the measurement result. The average will be displayed at the end of each sweep. **Avg Number (Off)** disables measurement averaging.

Key Access: **Meas Setup**

Avg Mode
Exp Repeat

Allows you to select the type of termination control used for the averaging function. This determines the averaging action after the specified number of measurements (average count) is reached. **Avg Mode** has no effect on measurements that are not averaged.

Exp Each successive data acquisition after the average count is reached is exponentially weighted and combined with the existing average. Exponential averaging weights new data more than old data, which facilitates tracking of slow-changing signals.

Repeat After reaching the average count, all previous result data is cleared and the average count is set back to 1.

Key Access: **Meas Setup**

Range Table

Allows you to enter the settings for up to twenty ranges using the instrument front panel keys or remotely. Upon entering the range table the measurement is stopped, then the analyzer is set to a constantly sweeping idle state. The analyzer will then be set to the current values for range 1 (whether range 1 is on or off.) If a range is currently off, the values in the range table for that range will be replaced with (---) to indicate that the range is currently inactive.

Key Access: **Meas Setup**

NOTE

The range table can be exited at anytime by pressing any front-panel key with the exception of the following: **ESC, System, File, Save, Print Setup, Print, Marker, Peak Search, Freq Count, Next Marker, Next Window, and Zoom.**

The following table defines the default settings for the range table. The values for ranges 1 through 5 are based on the W-CDMA (3GPP) BTS Spurious Emission measurement.

Range	Start Freq (GHz)	Stop Freq (GHz)	Res BW (kHz)	Video BW	Sweep Time	Absolute Limit	Peak Threshold	Peak Excursion
1	1.920	1.980	1200	Auto	Auto	-50 dBm	-90 dBm	6 dB
2	1.894	1.920	510	Auto	Auto	-50 dBm	-90 dBm	6 dB
3	2.100	2.102	100	Auto	Auto	-50 dBm	-90 dBm	6 dB
4	2.175	2.180	100	Auto	Auto	-50 dBm	-90 dBm	6 dB
5	0.800	1.000	4000	Auto	Auto	-50 dBm	-90 dBm	6 dB
6-20	1.5	2.5	Auto	Auto	Auto	-50 dBm	-90 dBm	6 dB

Range On Off	<p>Allows you to select from the 20 ranges in the range table. When a range has been selected, the values of the range table parameters will appear on the Range Table menu keys. If Range is set to On, the selected range values will be used in your measurement. If Range is set to Off, the selected range values will not be used. The range parameters are listed in the table above.</p> <p>Key Access: Meas Setup, Range Table</p>
Start Freq	<p>Allows you to set the start frequency for the selected range.</p> <p>Key Access: Meas Setup, Range Table</p>
Stop Freq	<p>Allows you to set the stop frequency for the selected range.</p> <p>Key Access: Meas Setup, Range Table</p>
Res BW Auto Man	<p>Allows you to set the resolution bandwidth for the selected range. When Auto is selected, the analyzer determines the optimum setting, while Man allows you to enter the setting.</p> <p>Key Access: Meas Setup, Range Table</p>
Video BW Auto Man	<p>Allows you to set the video bandwidth for the selected range. When Auto is selected, the analyzer determines the optimum setting, while Man allows you to enter the setting.</p> <p>Key Access: Meas Setup, Range Table</p>
Sweep Time Auto Man	<p>Allows you to set the sweep time for the selected range. When Auto is selected, the analyzer determines the optimum setting, while Man allows you to enter the setting.</p> <p>Key Access: Meas Setup, Range Table</p>
Range On Off	<p>Allows you to select from the 20 ranges in the range table. When a range has been selected, the values of the range table parameters will appear on the Range Table menu keys. If Range is set to On, the selected range values will be used in your measurement. If Range is set to Off, the selected range values will not be used. The range parameters are listed in the table above.</p>

Key Access: **Meas Setup, Range Table, More**

Absolute Limit Allows you to determine the limit above which spurs will report a failure. Any spur located above the current setting of **Peak Excursn** will be added to the results table. An **F** (in red on analyzers with a color display) will be appended to the amplitude value of the spur if the measured amplitude of the spur is above the limit set with **Absolute Limit**.

Key Access: **Meas Setup, Range Table, More**

Peak Excursn Sets the minimum amplitude variation of signals that can be identified as peaks. For example, if a value of 6 dB is selected, peaks that rise and fall more than 6 dB above the peak threshold value are identified.

Key Access: **Meas Setup, Range Table, More**

Pk Threshold Sets the minimum amplitude of signals that can be identified as peaks. For example, if a value of -90 dBm is selected, only peaks that rise and fall more than the peak excursn value, which is above -90 dBm, are identified.

Key Access: **Meas Setup, Range Table, More**

Meas Type
Examine Full

Allows you to specify the measurement type, either **Examine** or **Full**. This parameter is coupled to the average mode. If the measurement type selected is **Examine**, the measurement sets **Avg Mode** to **Exp**. When **Full** is selected as the measurement type, the measurement sets **Avg Mode** to **Rep**. The behavior of each measurement type is described below.

	Single		Continuous	
	No Spurs	Spurs	No Spurs	Spurs
Examine	All active ranges are measured. Upon completion the measurement is set to the idle state and No Spurs is then displayed.	All active ranges are measured and the found spurs are reported. Upon completion the measurement is set to the idle state and the trace containing the worst spur is restored. Spur is then enabled (no longer greyed out). A marker is also added which is set to the frequency of the worst spur.	All active ranges are measured. Upon completion the analyzer remains set to the last range checked with an active trace and No Spurs is then displayed.	All active ranges are measured and the found spurs are reported. Upon completion the analyzer is set to the range containing the worst spur found and continually sweeps this range. Spur is then enabled (no longer greyed out). A marker is also added which is set to the frequency of the worst spur.
Full	All active ranges are measured. Upon completion the measurement is set to the idle state and No Spurs is then displayed.	All active ranges are measured and the found spurs are reported. Upon completion the measurement is set to the idle state, displaying the trace of the last active range.	Measurement continually cycles through all active ranges.	All active ranges are measured and the found spurs are reported. On each cycle of the active ranges the spurs found is reset. This ensures any remote queries retrieve the trace data that matches the currently displayed results.

Key Access: **Meas Setup**

Spur

Press **Spur** to view any spurs which have been found. The measurement will set the analyzer to the range in which the currently selected spur was found. The range settings will only change if the selected spur is in a range which is different from the current range settings.

Key Access: **Meas Setup**

**Ref Level
Auto Man**

Sets the reference level of the analyzer.

Key Access: **Meas Setup**

Spectrum Emission Mask Meas Setup Menu Keys

To access the following keys for setting up a spectrum emission mask measurement, press **MEASURE**, **Spectrum Emission Mask**, and then the front-panel **Meas Setup** key.

**Avg Number
On Off**

Press **Avg Number (On)** to specify the number of averages used when calculating the measurement result. The average will be displayed at the end of each sweep. **Avg Number (Off)** disables measurement averaging.

Key Access: **Meas Setup**

Meas Type

Allows you to specify the reference for the spectrum emission mask measurement.

Total Pwr Ref Press **Total Pwr Ref** to specify the reference for the measurement to the total power.

PSD Ref Press **PSD Ref** to specify the reference for the measurement to power spectral density.

Key Access: **Meas Setup, Meas Type**

Ref Channel

Chan Integ BW Allows you to specify the channel integration bandwidth used in calculating the power in the main channel.

Chan Span Allows you to specify the channel span used in calculating the power in the main channel.

**Sweep Time
Auto Man** Allows you to specify the sweep time used in calculating the power in the main channel.

**Res BW
Auto Man** Allows you to specify the resolution bandwidth used in calculating the power in the main channel.

**Total Pwr Ref
Auto Man** This parameter allows you to select whether to calculate the carrier power based on the signal at the analyzer input, or use a fixed value as reference. Enables the use of the Agilent Dynamic Range Extender. The Agilent Dynamic Range Extender will effectively “remove” the carrier from the signal coming into the analyzer. The fixed value can be entered manually.

Key Access: **Meas Setup, Ref Channel**

Offset/Limits Accesses the following parameters for offset frequency settings and pass/fail tests: **Offset**, **Start Freq**, **Stop Freq**, **Sweep Time**, **Res BW**, and **Limits**. The following Tables show the default settings for BTS and MS measurements.

Key Access: **Meas Setup**

Table 3-1 Offsets & Limits Defaulted for BTS Measurements

Offset	Start Freq (MHz)	Stop Freq (MHz)	Sweep Time (us)	ResBW (kHz)	Abs Start (dBm)	Abs Stop (dBm)	Rel Start (dBc)	Rel Stop (dBc)	Fail Mask	Meas BW (MHz)
A, On	2.515	2.715	Auto	30.00	-14.00	-14.00	-30.00	-30.00	Abs	1
B, On	2.715	3.515	Auto	30.00	-14.00	-26.00	-30.00	-30.00	Abs	1
C, On	3.515	4.000	Auto	30.00	-26.00	-26.00	-30.00	-30.00	Abs	1
D, Off	4.000	7.500	Auto	1000.0	-13.00	-13.00	-30.00	-30.00	Abs	20
E, Off	7.500	12.500	Auto	1000.0	-13.00	-13.00	-30.00	-30.00	Abs	1

Table 3-2 Offsets & Limits Defaulted for MS Measurements

Offset	Start Freq (MHz)	Stop Freq (MHz)	Sweep Time (us)	ResBW (kHz)	Abs Start (dBm)	Abs Stop (dBm)	Rel Start (dBc)	Rel Stop (dBc)	Fail Mask	Meas BW (MHz)
A, On	2.515	3.485	Auto	30.00	-71.07	-71.07	-35.23	-49.78	AND	1
B, On	4.000	7.500	Auto	1000.0	-55.84	-55.84	-35.50	-39.00	AND	1
C, On	7.500	8.500	Auto	1000.0	-55.84	-55.84	-39.00	-49.00	AND	1
D, Off	8.500	12.500	Auto	1000.0	-55.84	-55.84	-49.00	-49.00	AND	1
E, Off	12.500	15.000	Auto	1000.0	-55.84	-55.84	-49.00	-49.00	AND	1

Offset

A B C D E

Allows you to select an offset that will determine the settings of the parameters in the Offset/Limits key menus. The default settings for 5 sets of offsets (A through E) for both MS and BTS measurements are shown in [Table 3-1](#), and [Table 3-2](#). Press Offset until the letter of the desired offset (A, B, C, D or E) is underlined.

Start Freq

On Off

Allows you to specify the limit (start frequency) for the upper segment of the specified offset pair, and to toggle this function between **On** and **Off** for each offset.

Stop Freq

Allows you to specify the limit (stop frequency) for the upper segment of the specified offset pair.

Sweep Time**Auto Man**

Allows you to specify the sweep time for the currently selected offset, and to toggle this function between **Auto** and **Man** for each offset.

Res BW**Auto Man**

Sets the limit for the upper segment of the specified offset pair, and allows you to toggle this function between **Auto** and **Man**.

Key Access: **Meas Setup, Offset/Limits**

Offset**A B C D E**

Allows you to select an offset that will determine the settings of the parameters in the Offset/Limits key menus. The default settings for 5 sets of offsets (A through E) for both MS and BTS measurements are shown in [Table 3-1](#), and [Table 3-2](#). Press Offset until the letter of the desired offset (A, B, C, D or E) is underlined.

Abs Start

Allows you to enter an absolute level limit at **Start Freq** ranging from -200.00 to $+50.00$ dBm with 0.01 dB resolution.

Key Access: **Meas Setup, Offset/Limits, More**

Abs Stop**Couple Man**

Sets the limit for the upper segment of the specified offset pair, and allows you to enter an absolute level limit at **Stop Freq** ranging from -200.00 to $+50.00$ dBm with 0.01 dB resolution. When set to **Couple**, **Abs Stop** is coupled to **Abs Start** to make a flat limit line. When **Abs Start** has been pressed, and **Abs Stop** is set to **Man**, you can enter different values to make a sloped limit line.

Key Access: **Meas Setup, Offset/Limits, More**

Rel Start

Sets the limit for the upper segment of the specified offset pair. **Rel Start** allows you to enter a relative level limit at **Start Freq** ranging from -150.00 to $+50.00$ dBc with 0.01 dB resolution.

Key Access: **Meas Setup, Offset/Limits, More**

Rel Stop**Couple Man**

Sets the limit for the upper segment of the specified offset pair. **Rel Stop** allows you to enter a relative level limit at **Stop Freq** ranging from -150.00 to $+50.00$ dBc with 0.01 dB resolution. When set to **Couple**, **Rel Stop** is coupled to **Rel Start** to make a flat limit line. When **Rel Start** has been pressed, and **Rel Stop** is set to **Man**, you can enter different values to make a sloped limit line.

Key Access: **Meas Setup, Offset/Limits, More**

Fail Mask

Allows you to select from a menu of logic keys for fail conditions between the measurement results and the test limits.

Key Access: **Meas Setup, Offset/Limits, More**

Absolute Sets the limit test to show **Fail** if one of the absolute spectrum emission mask measurement results is larger than the limit for **Abs Start** and/or **Abs Stop**

Relative Sets the limit test to show **Fail** if one of the relative spectrum emission mask measurement results is larger than the limit for **Rel Start** and/or **Rel Stop**.

Abs AND Rel Sets the limit test to show **Fail** if one of the absolute spectrum emission mask measurement results is larger than the limit for **Abs Start** and **Abs Stop** *and* one of the relative spectrum emission mask measurement results is larger than the limit for **Rel Start** and **Rel Stop**.

Abs OR Rel Sets the limit test to show **Fail** if one of the absolute spectrum emission mask measurement results is larger than the limit for **Abs Start** and **Abs Stop** *or* one of the relative spectrum emission mask measurement results is larger than the limit for **Rel Start** and **Rel Stop**.

Key Access: **Meas Setup, Offset/Limits, More, Fail Mask**

**Optimize
Ref Level**

Sets the reference level and attenuator to optimum values based on the signal present at the input.

Key Access: **Meas Setup**

MEASURE

In the Spectrum Analysis mode, **MEASURE** accesses a menu of keys that allow you to make channel power, occupied bandwidth, adjacent channel power, multi-carrier power, complementary cumulative distribution function (CCDF), harmonic distortion, burst power, intermodulation (TOI), spurious emissions, and spectrum emission mask measurements. These measurements can be setup by you or you may select one of several radio standards available by pressing **Mode Setup, Radio Standard**. The standards currently available are: IS95, J-STD-008, cdma2000 (SR1), W-CDMA (3GPP), cdma2000 (SR3-MC), cdma2000 (SR3-DS), NADC, PDC, GSM/EDGE, and Bluetooth™.

NOTE The measurements described below are those available in SA mode (see **Mode** key). Other measurements are available in other modes if an optional personality is installed.

NOTE When a measurement is activated, Signal Track, Video Averaging, Segmented Sweep, Band Power and Marker Noise will be turned off.

NOTE When Signal Track, Video Averaging, Band Power, Marker Noise or Span Zoom are activated, a running measurement will be turned off.

Meas Off Turns the active measurement function off.
Key Access: **MEASURE**


Channel Power Measures and reports the power in the channel (integration) bandwidth as well as the computed power spectral density as shown in [Figure 3-6](#).
The power calculation method used to determine the channel power is a traditional method known as the integration bandwidth (IBW) method. A swept spectrum is used as the basis for this calculation. Therefore, it is important to set the resolution bandwidth correctly before making this measurement using the following formula:

$$RBW = k(span)/n$$

Where k is a value between 1.2 and 4.0 and n is the number of trace.

NOTE Because of the noise-like nature of the signals being measured, the video bandwidth should be ≥ 10 times the resolution bandwidth.

Figure 3-6 Channel Power Measurement Results



NOTE The displayed trace is the current trace, not the averaged trace.

Pressing **Meas Setup** after **Channel Power** has been selected will access the channel power measurement setup menu. Pressing **Radio Standard** after **Mode Setup** has been selected will access all the Radio Standards available for which this measurement can be applied (NADC MS, excluded). Pressing **Meas Control** after **Channel Power** has been selected will access the channel power measurement control menu which allows you to pause or restart your measurement, or toggle between continuous and single measurement.

Key Access: **MEASURE**

Occupied BW Integrates the power of the displayed spectrum and puts markers at the frequencies between which the selected percentage of the power is contained. (Refer to [Figure 3-5 on page 183](#).) The measurement defaults to 99% of the occupied bandwidth power. The power-bandwidth routine first computes the combined power of all signal responses contained in the trace. For 99% occupied power bandwidth, markers are placed at the frequencies on either side of 99% of the power. 1% of the power is evenly distributed outside the markers. The difference between the marker frequencies is the 99% power bandwidth and is the value displayed.

The occupied bandwidth function also indicates the difference between the analyzer center frequency and the center frequency of the channel. This difference is referred to as “Transmit Freq Error” in [Figure 3-5 on page 183](#).

MEASURE

Pressing **Meas Setup** after **Occupied BW** has been selected will access the occupied bandwidth power measurement setup menu. Pressing **Radio Standard** after **Mode Setup** has been selected will access all the Radio Standards available for which this measurement can be applied (GSM/EDGE and Bluetooth™, excluded). Pressing **Meas Control** after **Occupied BW** has been selected will access the occupied bandwidth measurement control menu which allows you to pause or restart your measurement, or toggle between continuous and single measurement.

Key Access: **MEASURE**

ACP

Measures the power present in adjacent transmit channels. The span is set according to the six available offsets and their associated integration bandwidths defined by you or the selected radio standard (**Mode Setup, Radio Std**). The root-raised cosine filter also affects the span and is only available for NADC and W-CDMA 3GPP radio standards.

When **Method** is set to **IBW**, one sweep of the trace will be taken, and the band power for each offset will be computed. Results will be displayed relative to the total power or the power spectral density, depending on your selection after pressing **Meas Setup, Meas Type**. You may view the results as the current trace, bar graph, or a combination. When **Method** is set to **RBW**, the main channel and offsets will be measured in zero span and the combined results reported according to the **Meas Type** selection.

Pressing **Meas Setup** after **ACP** has been selected will access the adjacent channel power measurement setup menu. Pressing **Radio Standard** after **Mode Setup** has been selected will access all the Radio Standards available for which this measurement can be applied (GSM/EDGE and Bluetooth™, excluded). Pressing **Meas Control** after **ACP** has been selected will access the adjacent channel power measurement control menu which allows you to pause or restart your measurement, or toggle between continuous and single measurement.

Key Access: **MEASURE**

Multi-Carrier Power

Multi-Carrier Power is the measure of the power that leaks into adjacent transmit channels. The results reported are identical to the adjacent power measurement, but the setup is different to allow for two or more carriers present.

Key Access: **MEASURE**

Power Stat CCDF

Plots curves which characterize the signal's higher level power. It provides the distribution of peak-to-average power ratios versus probability. A CCDF curve is defined by how much time the waveform spends at or above the given power level. The percent of time the signal spends at or above the level defines the probability for that particular power level.

NOTE CCDF measurement requires the installation of Option AYX or Option B7D to ensure measurement accuracy.

For each single sweep of this measurement, the average power is defined by:

$$P_{avg} = \left(\sum_{1}^n (V^2/Z_0) \right) / n$$


where V is the envelope voltage, Z₀ is the characteristic impedance, and n is the number of samples (32k maximum).

P_{avg} is used as a guideline to define the probability of the samples, which is x dB above the average power. The number of samples collected per sweep depends upon the sampling rate and the setting of the measurement interval. Multiple sweeps may be required if the sample number exceeds the number of samples collected per sweep. The results and the CCDF curve are updated after every single sweep.

Results from a 2.17 GHz W-CDMA 3GPP input signal are shown below in [Figure 3-7](#).

NOTE It is important to set the correct center frequency before initiating this measurement.

Figure 3-7 Power Stat CCDF Measurement Results



Pressing **Meas Setup** after **Power Stat CCDF** has been selected will access the Power Stat CCDF measurement setup menu. The factory defaults provide a good starting point for this measurement. The settings are adjustable, however, to meet specific requirements. Pressing **Radio Standard** after **Mode Setup** has been selected will access all the Radio Standards available for which this measurement can be applied. Pressing **Meas Control** after **Power Stat CCDF** has been selected will access the Power Stat CCDF measurement control menu which allows you to pause or restart your measurement, or toggle between continuous and single measurement.

Key Access: **MEASURE**

Harmonic Distortion

Measures the harmonics of the strongest signal present in the span and computes the total harmonic distortion for the signal. The carrier must be the strongest peak (having a frequency > 0 Hz, a peak excursion > 6 dB on both sides, and an amplitude ≥ -50 dBm) on the display at the time the measurement is started. The total harmonic distortion is then calculated from the measured harmonics and displayed as a percentage according to the following equation:

$$\%THD = 100 \times \frac{\sqrt{\sum_{h=2}^{H_{\max}} E_h^2}}{E_f}$$

Where:

%THD = Total Harmonic Distortion as a percentage

h = harmonic number

H_{\max} = Maximum Harmonic Value listed

E_h = voltage of harmonic h

E_f = voltage of fundamental signal

Refer to the *Agilent Technologies ESA Spectrum Analyzers Measurement Guide* for examples of this measurement and the calculation of Total Harmonic Distortion.

NOTE

Limit the span to a bandwidth sufficient to view the modulated signal before initiating this measurement. Because resolution bandwidth is coupled to span, this provides the resolution bandwidth enough range to capture all the harmonics.


Pressing **Meas Setup** after **Harmonic Distortion** has been selected will access the harmonic distortion measurement setup menu. Pressing **Meas Control** after **Harmonic Distortion** has been selected will access the harmonic distortion control menu which allows you to pause or restart your measurement, or toggle between continuous and single measurement.

Key Access: **MEASURE, More**

Burst Power

Measures the average power in zero-span mode for the captured burst. This measurement is primarily for use with time domain modulated signals (Bluetooth™, GSM /Edge, and NADC). The burst width, if not user defined, is determined by finding the peak in the captured data, then searching for the first place that the trace is higher than the threshold level. This is considered to be the start of the burst. The stop of the burst is the first position in the trace that falls below the threshold level. The mean carrier power is calculated based on the burst width and the threshold level. Refer to [Figure 3-8](#) for clarification of these parameters.

Figure 3-8 Burst Power Measurement



pl746b

The burst power measurement acquired data from the “Measured Area” above when a radio standard is chosen or when **Meas Setup, Meas Method, Measured Burst Width** is selected. When **Meas Setup, Meas Method, Above Threshold Lvl** is selected, the “Measured Area” extends the burst width delimiter lines to the start and stop.

The mean carrier power is calculated by:

1. Converting each trace point amplitude from dBm into linear power.
2. Adding the above amplitudes together and dividing by the number of included in the average.
3. This value is then displayed in logarithmic form (dBm).


$$(P_{avg}) = 10 \log 10 \left\{ \frac{\left(\sum_n^m \left(10^{\frac{p}{10}} \right) \right)}{m - n} \right\}$$

where P_{avg} = average power, n is the start trace point, m = the stop trace point, and p = the trace point amplitude power in dBm.

The figure below shows an example of the results obtained when measuring a Bluetooth™ signal and with a user-defined burst width.

Figure 3-9

Burst Power Measurement Results



NOTE The analyzer defaults to zero-span mode and the sweep time is set to capture at least one burst. The sweep time can be changed by pressing **Sweep, Sweep Time**.

Pressing **Meas Setup** after **Burst Power** has been selected will access the burst power measurement setup menu. Pressing **Meas Control** after **Burst Power** has been selected will access the burst power control menu which allows you to pause or restart your measurement, or toggle between continuous and single measurement.

Key Access: **MEASURE, More**

NOTE The measurements described above are those available in SA mode (see **Mode** key). Other measurements are available in other modes if an optional personality is installed.

Intermod (TOI) Computes and displays the third order intercept (TOI) point and places markers on the trace to indicate the measured signals and third-order products.

Key Access: **MEASURE, More**

Spurious Emissions The spurious emissions measurement identifies and determines the power level of spurious emissions in certain frequency bands.

Key Access: **MEASURE, More**

Spectrum Emission Mask The spectrum emission mask measurement includes the in-band and out-of-band spurious emissions. It may also be expressed as a ratio of power spectral densities between the carrier and the specified offset frequency band.

Key Access: **MEASURE, More**

MODE

Selects the measurement mode of your analyzer. Spectrum analyzer mode (**Spectrum Analysis**) is the default mode. Other modes include GSM (requires Option BAH) and cdmaOne (requires Option BAC).

Mode Setup

Brings up a menu for setting up the current mode. The **SA** mode has the following mode setup functions.

Radio Std

Accesses the radio standards key menu. Selecting a radio standard modifies spectrum analyzer settings only when one of the measurements (Channel Power, Occupied BW, ACP, Multi-Carrier Power, Power Stat CCDF, Harmonic Distortion, Burst Power, Intermod (TOI), Spurious Emissions, Spectrum Emission Mask) have been activated under the **MEASURE** menu.

Key Access: **Mode Setup**

None Selects no radio standard. If **Radio Std, None** is selected when a measurement is running, essentially a “mini-preset” occurs. All instrument parameters set by the formerly active measurement (**Meas Setup** key menu) are restored to their factory default values. Analyzer parameters outside the **MEASURE** or **Meas Setup** key menus are not affected.

Key Access: **Mode Setup, Radio Std**

IS95 Sets the specific parameters for the selected measurement (located under the “**MEASURE**” key description) appropriate for industry standard IS95. All measurements are available for this standard.

Key Access: **Mode Setup, Radio Std**

J-STD-008 Sets the specific parameters for the selected measurement (located under the “**MEASURE**” key description) appropriate for industry standard J-STD-008. All measurements are available for this standard.

Key Access: **Mode Setup, Radio Std**

NADC Sets the specific parameters for the selected measurement (located under the “**MEASURE**” key description) appropriate for industry standard NADC. The Burst Power measurement is not available when **Device (BTS)** is selected. The Channel Power measurement is not available when **Device (MS)** is selected. All other measurements are available for this standard.

Key Access: **Mode Setup, Radio Std**

GSM/EDGE	<p>Sets the specific parameters for the selected measurement (located under the “MEASURE” key description) appropriate for industry standard GSM/EDGE. All measurements are available for this standard except Channel Power, ACP, and Occupied BW.</p> <p>Key Access: Mode Setup, Radio Std</p>
W-CDMA 3GPP	<p>Sets the specific parameters for the selected measurement (located under the “MEASURE” key description) appropriate for industry standard W-CDMA. All measurements are available for this standard.</p> <p>Key Access: Mode Setup, Radio Std</p>
cdma2000 SR1	<p>Sets the specific parameters for the selected measurement (located under the “MEASURE” key description) appropriate for industry standard cdma2000-SR1. All measurements are available for this standard.</p> <p>Key Access: Mode Setup, Radio Std, More</p>
cdma2000 SR3-MC	<p>Sets the specific parameters for the selected measurement (located under the “MEASURE” key description) appropriate for industry standard cdma2000:SR3-MC. All measurements are available for this standard.</p> <p>Key Access: Mode Setup, Radio Std, More</p>
cdma2000 SR3-DS	<p>Sets the specific parameters for the selected measurement (located under the “MEASURE” key description) appropriate for industry standard cdma2000:SR3-DS. All measurements are available for this standard.</p> <p>Key Access: Mode Setup, Radio Std, More</p>
PDC	<p>Sets the specific parameters for the selected measurement (located under the “MEASURE” key description) appropriate for industry standard PDC. The Burst Power measurement is not available when Device (BTS) is selected. The Channel Power measurement is not available when Device (MS) is selected. All other measurements are available for this standard.</p>

Key Access: **Mode Setup, Radio Std, More**

Bluetooth™ Sets the specific parameters for the selected measurement (located under the **“MEASURE”** key description) appropriate for industry standard Bluetooth™. All measurements are available for this standard except Channel Power, ACP, and Occupied BW.

Key Access: **Mode Setup, Radio Std, More**

Std Setup Accesses the key menu for selecting the device, packet type, or signal bandwidth to be measured.

Key Access: **Mode Setup**

Device

BTS MS Allows you to select either the base transmitter station (BTS) or the mobile station (MS) for all radio standards except Bluetooth™.

Key Access: **Mode Setup, Std Setup**

Packet Type

DH1 DH3 DH5 Allows you to select the packet type for Bluetooth™ measurement.

Key Access: **Mode Setup, Std Setup**

Signal BW

3.0000000 MHz Allows you to set the measurement bandwidth when **Radio Std (None)** is selected.

Key Access: **Mode Setup, Radio Std, None, Std Setup**

Next Window

Allows you to select the active window in functions which support split-screen display modes, such as zone span. In split-screen display modes, pressing **Zoom** allows you to switch between split-screen and full-sized displays of the active window. See also "[Zoom](#)".

NOTE

The active window is indicated by a solid green box around the window.

Peak Search

Places a marker on the highest peak based on the setting of the search parameters, **Max** (default) or **Param**. Refer to [Peak Search Type on page 220](#), for more information on the effect of setting **Peak Search** to **Max** or **Param**. When you preset the analyzer, the **Peak Search** is set to **Max** unless you save **Peak Search** (Param) as part of the user preset conditions and set **Preset** to **User**. Refer to [Preset on page 222](#), for more information on presetting the analyzer.

NOTE All peak search functions ignore the LO feedthrough. Peak Search may locate the LO feedthrough when **FREQUENCY**, **Scale Type (Log)** is selected.

Meas Tools Accesses the following frequently used menu keys which are replicated here for your convenience.

- | | |
|----------------------|--|
| Peak Search | Performs peak search as described above.
Key access: Peak Search , Meas Tools |
| Next Pk Right | Refer to “Next Pk Right” on page 218 .
Key access: Peak Search , Meas Tools |
| Next Pk Left | Refer to “Next Pk Left” on page 218 of this chapter.
Key access: Peak Search , Meas Tools |
| Delta | Refer to “Delta” on page 172 .
Key access: Peak Search , Meas Tools |
| Mkr → CF | Refer to Mkr → CF on page 120.
Key access: Peak Search , Meas Tools |
| Mkr → Ref Lvl | Refer to Mkr → Ref on page 121.
Key access: Peak Search , Meas Tools |
| Function | Refer to “Function” on page 175 .
Key Access: Peak Search , Meas Tools |
| Band Power | Refer to “Band Power” on page 175 .
Key Access: Peak Search , Meas Tools ,
Function |
| Marker Noise | Refer to “Marker Noise” on page 175 .
Key Access: Peak Search , Meas Tools ,
Function |

	Off	Refer to “Off” on page 174. Key Access: Peak Search, Meas Tools, Function
Next Peak		Places the marker on the next highest peak. The signal peak must exceed the peak threshold value by the peak excursion value. If there is no peak, the marker will not move. (Also see the Peak Excursion and Peak Threshold key descriptions.) Key Access: Search
Next Pk Right		Moves the marker to the next peak to the right of the current marker. The signal peak must exceed the peak threshold value by the peak excursion value. If there is no peak to the right, the marker will not move and the No Peak Found error message will appear on the display. (Also see the Peak Excursion and Peak Threshold key descriptions.) Key Access: Search
Next Pk Left		Moves the marker to the next peak to the left of the current marker. The signal peak must exceed the peak threshold value by the peak excursion value. If there is no peak to the left, the marker will not move and the No Peak Found error message will appear on the display. (Also see the Peak Excursion and Peak Threshold key descriptions.) Key Access: Search
Min Search		Moves the active marker to the minimum detected amplitude value. Key Access: Search
Pk-Pk Search		Finds and displays the frequency (or time, if in zero span) and amplitude differences between the highest and lowest trace. Key Access: Search
Continuous Pk On Off		When a marker is placed on a signal and Continuous Pk (On) is pressed, the marker will remain on the signal even if the signal changes in frequency and amplitude. Key Access: Search, More
N dB On Off		Activates the N dB function. Pressing N dB (On) turns on the N dB feature and activates two arrows that are N dB down from the marker. The frequency difference between the two arrows will be displayed in the upper right-hand corner of the display. If the feature is unable to find data N dB below the marker, the value of –100 Hz will be displayed in the upper right-hand corner of the display.

For example, N dB can be used to measure the 3 dB bandwidth of a filter in a transmission test with the tracking generator. The default value is -3 dB. Possible values range from -1.00 dB to -80.00 dB. You can enter values to a resolution of 0.01 dB using the numeric key pad, 0.1 dB using the knob, or 10 dB using the step keys.

The measured signal cannot have more than one peak that is greater than or equal to N dB. A signal must be greater than the peak excursion above the peak threshold to be identified. The setting for peak excursion may be increased from the -6 dB default value so that noise will not be identified as signals. Increasing the value too much may cause a smaller signal to be missed or misinterpreted as part of a larger signal. The amplitude scale may be either linear or logarithmic.

The N dB function follows the active marker. If you turn on a marker after N dB has been activated, the arrows will follow that marker. If the marker associated with N dB moves, the arrows will move with the marker unless there is no data N dB below the marker.

Key Access: **Search, More**

Search Criteria Accesses the following menu keys:

Key access: **Search, More**

Peak Excursion Sets the minimum amplitude variation of signals that the marker can identify as a peak. If a value of 10 dB is selected, the marker moves only to peaks that rise and fall more than 10 dB above the peak threshold value. Pressing **Preset** (when **Preset Type** is set to **Factory**) or turning on power resets the excursion to 6 dB and the threshold to 90 dB below the reference level.

NOTE Two signal peaks, which are so close together that the amplitude drop between them is less than the peak-excursion value, are not recognized as two peaks. A signal peak is recognized only if it has a peak excursion drop above the noise floor, on both sides of the signal.

When the peak excursion value is 6 dB or higher, the marker-peaking functions do not recognize signals less than the peak excursion value above the noise floor. To correct this, when measuring signals near the noise floor, the excursion value can be reduced even further. To prevent the marker from identifying noise as signals, reduce the noise floor variance to a value less than the peak-excursion value by reducing the video bandwidth or by using video averaging.

Key access: **Peak Search, More, Search Criteria**

Peak Threshold Sets the minimum amplitude of signals that the marker can identify as a peak. For example, if a value of -90 dBm is selected, the marker moves only to peaks that rise and fall more than the peak excursion value above -90 dBm. Pressing **Preset** or turning the Power on resets the excursion to 6 dB and the threshold to -90 dBm.

The value of the threshold appears in the active-function block and on the lower-left side of the display. The threshold level does not influence the trace memory or marker position. The value of the peak threshold level can be changed using the step keys, the knob, or the numeric keypad. Pressing any digit, 0 through 9, on the numeric keypad brings up the selected terminator menu.

Key access: **Peak Search, More, Search Criteria**

Peak Search Type

Allows you to select the peak search mode.

Key access: **Peak Search, More, Search Criteria**

Max Value When **Peak Search Type** is set to **Max Value**, a peak search places a marker on the highest peak, excluding the LO feedthrough peak.

Key Access: **Peak Search, More, Search Criteria, Peak Search Type**

Excursion & Threshold

When **Peak Search** is set to **Excursion & Threshold**, a peak search places a marker on a peak that meets the **Peak Excursion** and **Peak Threshold** parameters. If **Peak Search Type** is set to **Excursion & Threshold** and no peak satisfies the selected parameters, a marker is placed at the center of the trace, and the error message, **No Peak Found** will appear. Refer to [Show Errors on page 256](#), to remove the error message.

Key Access: **Peak Search, More, Search Criteria, Peak Search Type**

Peak Table

Accesses the following **Peak Table** menu keys:

Key Access: Peak Search, More 1 of 2

Peak Table

On Off

Displays a list of up to ten signal peaks that is updated at the end of each sweep. The peaks can be sorted in order by descending amplitude or by ascending frequency. Peaks above or below the display line can be excluded from the table. The peak table function works with trace 1 only.

Key Access: Search, More, Peak Table

Peak Sort

Freq Amptd

Switches the peak table sorting routine between listing the peaks in order by descending amplitude or by ascending frequency.

Key Access: Search, More, Peak Table

Peak Readout

Accesses the following **Peak Readout** menu keys:

Key Access: Search, More, Peak Table

Normal

Shows up to ten signal peaks.

Key Access: Search, More, Peak Table, Peak Readout

> Display Line

Shows only peaks above the display line.

Key Access: Search, More, Peak Table, Peak Readout

< Display Line

Shows only peaks below the display line.

Key Access: Search, More, Peak Table, Peak Readout

Preset

Provides a known convenient starting point of the instrument state for making measurements. You can select whether a user preset, mode preset, or factory preset is performed. When you press **Preset**, the default is **Mode** preset, which will set the analyzer to the default state for the current mode. The user preset is user-defined using the **Save User Preset** function in the **System** menu (Press **System**, **Power On/Preset**, **Save User Preset**.) The **Preset Type** selection (**User**, **Mode** or **Factory**) can be set by pressing **System**, **Power On/Preset**, **Preset Type**.

NOTE The **Preset** menu keys are only available when the **Preset Type** key in the **System** menu is set to **User**. Press **System**, **Power On/Preset**, **Preset Type**, **User**.

If **Preset Type** is set to **Factory** in the **System** menu:

Pressing the **Preset** front-panel key performs a factory preset, which performs the following:

- Resets the analyzer to Spectrum Analyzer (SA) mode.
- Brings up the **Freq/Channel** menu.
- Sets certain conditions to their default values.
- Performs a processor test, but does not affect alignment data.
- Clears both the input and output buffers and clears all trace data.
- Sets the amplitude values of trace 2 and 3 to the bottom of the screen.
- Amplitude-correction factors are turned off, but remain in analyzer memory.
- Limit line testing is turned off, but the limit line tables remain in analyzer memory.
- Segmented sweep is turned off, but the segmented sweep tables remain in analyzer memory.
- The status byte is set to 0.

See [Table 3-8 on page 223](#) for the conditions established by performing a factory preset.

NOTE For *Agilent E4402B or E4407B with Option UKB, E4404B, and E4405B* only, you can specify alternating current (ac) or direct current (dc) coupling at the analyzer input. Selecting ac coupling blocks any dc voltage at the analyzer input, but also decreases the frequency range of the analyzer. Make sure the analyzer is dc coupled when measuring below 100 kHz for Agilent E4402B, E4404B, and E4405B and below 10 MHz for *Agilent E4407B*. (See [“Input/Output”](#) in this chapter for more information on this setting.)

If **Preset Type** is set to **User** in the **System** menu:

Pressing the **Preset** front-panel key brings up the **User Preset**, **Mode Preset**, and **Factory Preset** menu keys.

- If **User Preset** is pressed, the user preset state is recalled. To set the user preset state, change the analyzer settings as desired, then press **System**, **Power On/Preset**, **Save User Preset**.
- If **Mode Preset** is pressed, the current mode settings are reset to the factory defaults. Pressing **Mode Preset** does not change the mode.
- If **Factory Preset** is pressed, a factory preset will be performed as described above.

NOTE Recalling any state, including the user preset state, will affect the conditions of more parameters than are affected by a factory preset. For example, external preamp gain and input impedance correction are not affected by a factory preset but may be affected by a user preset.

NOTE In the **System** menu, if **Power On** is set to **Preset**, and **Preset Type** is set to **Factory**, turning on the analyzer performs a factory preset. The last state of the analyzer (before it was turned off) is recalled if **Power On** is set to **Last**. The user preset state is recalled if **Power On** is set to **Preset** and **Preset Type** is set to **User**.

Table 3-8 Factory Preset Conditions

Amplitude correction factors	off
Amplitude Ref (Signal)	off
Amplitude units	50 Ω input – dBm log 75 Ω input – dBmV log
Annotation and graticule display	on
Attenuation	10 dB (auto-coupled)
Center frequency:	
E4401B and E4411B	750 MHz
E4402B and E4403B	1.5 GHz
E4404B	3.35 GHz
E4405B	6.6 GHz
E4407B and E4408B	13.25 GHz
CF step size	10% of span
Coupled functions	all set to AUTO
Detector	Peak (auto-coupled)
Display line level	-25 dBm, display off

Table 3-8 Factory Preset Conditions (Continued)

Frequency (scale type)	Linear
Frequency offset	0 Hz
IF Gain	Auto
Input Coupling ¹ E4402B & E4407B with Option UKB, E4404B, and E4405B	AC
Int Preamp	off
Limit line testing	off
Log scale (Amplitude)	10 dB/division
Marker count	off
Marker counter resolution	auto-coupled
Markers	off
Max Mixer level	-10 dBm
Measure	Meas Off
Radio Std	None
Reference level	0 dBm in power-on units
Reference level offset	0 dB
Reference level position	top (10th) graticule
Resolution bandwidth	3 MHz (auto-coupled)
Span E4401B and E4411B E4402B and E4403B E4404B E4405B E4407B and E4408B	1.5 GHz 3.0 GHz 6.7 GHz 13.2 GHz 26.5 GHz
Speaker	Off
SRQ mask	40
Start Frequency	0 Hz

Table 3-8 Factory Preset Conditions (Continued)

Stop Frequency	
E4401B and E4411B	1.5 GHz
E4402B and E4403B	3.0 GHz
E4404B	6.7 GHz
E4405B	13.2 GHz
E4407B and E4408B	26.5 GHz
State Registers	unaffected
Segmented Sweep	off
Sweep	continuous
Sweep Time	
E4401B and E4411B	4 ms (auto coupled)
E4402B and E4403B	5 ms (auto coupled)
E4404B	16.75 ms (auto coupled)
E4405B	33 ms (auto coupled)
E4407B and E4408B	265 ms (auto coupled)
Sweep	401
Threshold level	-90 dBm, display off
Title	cleared
Trace 1	clear-write
Trace 2	blank, at bottom of display
Trace 3	blank, at bottom of display
Trigger	free run
Trig Delay Off	1 μ sec
Trig Offset Off	0 sec
VBW/RBW ratio	1.000 X (auto-coupled)
Video averaging	off
Video bandwidth	3 MHz (auto-coupled)

1. E4401B, E4402B without Option UKB, E4403B, and E4411B have fixed AC coupling. E4407B without Option UKB and E4408B have fixed DC coupling.

- User Preset** This key is only available when the **Preset Type** key is set to **User**. Press **System, Power On/Preset, Preset Type, User**.
- User Preset** loads the analyzer configuration that existed when **Save User Preset** was pressed. If **Save User Preset** has never been pressed, the factory preset state is loaded. If the user preset state has been saved but the load fails for any reason, the error message: `Unable to load user state` is displayed in the status line and the state is reset to whatever it was before the **Preset** key was pressed. This can sometimes happen if firmware has been upgraded or applications have been (un)installed after the user preset state was saved. **Save User Preset** can be accessed by pressing **System, Power On/Preset**.
- Key Access: **Preset**
- Mode Preset** This key is only available when the **Preset Type** key is set to **User**. Press **System, Power On/Preset, Preset Type, User**.
- Mode Preset** does not change the mode. It only resets the current mode settings to the factory defaults and to continuous sweeps/measurements.
- Key Access: **Preset**
- Factory Preset** This key is only available when the **Preset Type** key is set to **User**. Press **System, Power On/Preset, Preset Type, User**.
- A factory preset is executed so all of the instrument modes are returned to the factory default state (i.e. Spectrum Analysis Mode and continuous sweep.) If you are not already in the spectrum analysis mode, it switches to that mode. A factory preset will not reset “persistent” functions such as GPIB address, time/date display style, or auto alignment state to the factory defaults.
- Key Access: **Preset**
- Save User Preset** This key is only available when the **Preset Type** key is set to **User**. Press **System, Power On/Preset, Preset Type, User**.
- This key saves the current state of the analyzer into the **User Preset** state for recalling when the instrument is user preset. After you save a state here, you must go to the **Preset Type** key and select **User** in order to have this state used as the preset state.
- Key Access: **Preset**

Print

Option A4H (GPIB and Parallel) or Option 1AX (RS-232 and Parallel) only. **Print** initiates an output of the display data, without an external controller, to a previously specified graphics printer. Refer to “Printer Setup and Operation” in your Getting Started or Programmer’s Guide for detailed information about printing.

Press the **Print** key to immediately print the screen to the currently-defined printer. The screen remains frozen (no further sweeps are taken) until the data transfer to the printer is complete. Refer to the **Print Setup** key description in this chapter for more information about the structure and definitions of the printer keys.

If you need to abort a print in progress, use the **ESC** (escape) key.

NOTE

Printing requires an I/O interface. The *Agilent ESA Spectrum Analyzers Programmer’s Guide*, included with the optional interfaces, provides interface details. Refer to “Printer Setup and Operation” in the *Agilent ESA Spectrum Analyzers Getting Started Guide* for more information about printing.

Print Setup

Option A4H (GPIB and Parallel) or 1AX (RS-232 and Parallel) only.
Accesses the menu keys which allow you to define a printer and select printer options.

Printer Type	<p>Accesses the Printer Type menu keys. When you connect your printer and press the Print key, the analyzer will attempt to identify your printer. If identification is unsuccessful, None or Custom will automatically be set in the Printer Type menu.</p> <p>Key Access: Print Setup</p> <table><tr><td>None</td><td><p>The Printer Type will automatically be set to None when you press the Print key with an unsupported printer connected to your analyzer.</p><p>Key Access: Print Setup, Printer Type</p></td></tr><tr><td>Custom</td><td><p>When you press the Print key and the analyzer cannot identify your printer, Custom will automatically be set in the Printer Type menu. Setting the Printer Type menu key to Custom allows you to define your printer using the Define Custom menu keys.</p><p>Key Access: Print Setup, Printer Type</p></td></tr><tr><td>Auto</td><td><p>When Auto is selected, and the Print key is pressed, the analyzer will attempt to communicate with the printer and obtain its identification. If the printer is identified, the print will be successful and no message will appear on the display. If the analyzer is not able to identify the printer, the Printer Type will automatically be set to Custom and an error message asking you to press Define Custom to set up your printer will be displayed. If the printer is not supported, the Printer Type will automatically be set to None and an error message will inform you that your printer is unsupported.</p><p>Key Access: Print Setup, Printer Type</p></td></tr></table>	None	<p>The Printer Type will automatically be set to None when you press the Print key with an unsupported printer connected to your analyzer.</p> <p>Key Access: Print Setup, Printer Type</p>	Custom	<p>When you press the Print key and the analyzer cannot identify your printer, Custom will automatically be set in the Printer Type menu. Setting the Printer Type menu key to Custom allows you to define your printer using the Define Custom menu keys.</p> <p>Key Access: Print Setup, Printer Type</p>	Auto	<p>When Auto is selected, and the Print key is pressed, the analyzer will attempt to communicate with the printer and obtain its identification. If the printer is identified, the print will be successful and no message will appear on the display. If the analyzer is not able to identify the printer, the Printer Type will automatically be set to Custom and an error message asking you to press Define Custom to set up your printer will be displayed. If the printer is not supported, the Printer Type will automatically be set to None and an error message will inform you that your printer is unsupported.</p> <p>Key Access: Print Setup, Printer Type</p>
None	<p>The Printer Type will automatically be set to None when you press the Print key with an unsupported printer connected to your analyzer.</p> <p>Key Access: Print Setup, Printer Type</p>						
Custom	<p>When you press the Print key and the analyzer cannot identify your printer, Custom will automatically be set in the Printer Type menu. Setting the Printer Type menu key to Custom allows you to define your printer using the Define Custom menu keys.</p> <p>Key Access: Print Setup, Printer Type</p>						
Auto	<p>When Auto is selected, and the Print key is pressed, the analyzer will attempt to communicate with the printer and obtain its identification. If the printer is identified, the print will be successful and no message will appear on the display. If the analyzer is not able to identify the printer, the Printer Type will automatically be set to Custom and an error message asking you to press Define Custom to set up your printer will be displayed. If the printer is not supported, the Printer Type will automatically be set to None and an error message will inform you that your printer is unsupported.</p> <p>Key Access: Print Setup, Printer Type</p>						
Define Custom	<p>Allows you to define your printer.</p> <p>Key Access: Print Setup, Printer Type</p> <table><tr><td>Language</td><td></td></tr><tr><td>PCL3 PCL5</td><td><p>Allows you to define your printer as a Hewlett-Packard PCL3. (Most DeskJets) or Hewlett-Packard PCL5 (LaserJets and DeskJets: 1100,1200,1600,2000 series) printer.</p><p>Key Access: Print Setup, Define Custom</p></td></tr></table>	Language		PCL3 PCL5	<p>Allows you to define your printer as a Hewlett-Packard PCL3. (Most DeskJets) or Hewlett-Packard PCL5 (LaserJets and DeskJets: 1100,1200,1600,2000 series) printer.</p> <p>Key Access: Print Setup, Define Custom</p>		
Language							
PCL3 PCL5	<p>Allows you to define your printer as a Hewlett-Packard PCL3. (Most DeskJets) or Hewlett-Packard PCL5 (LaserJets and DeskJets: 1100,1200,1600,2000 series) printer.</p> <p>Key Access: Print Setup, Define Custom</p>						

Color Capable Yes No	Allows you to define the color capability of your printer. Key Access: Print Setup, Define Custom
Orientation	Allows you to select either Portrait or Landscape printing. The Orientation key will not function with a PCL3 (HP DeskJet) printer. Key Access: Print Setup
Prints/Page 1 2	Selects the number of prints per page when orientation is set to Portrait . In Landscape printing, Prints/Page is always set to 1. Key Access: Print Setup
Eject Page	Ejects your printed page. Key Access: Print Setup
Page Size	Allows you to select from the following page sizes: Executive, Letter, Legal, Ledger, A4, and A3 . Key Access: Print Setup, More
Color On Off	Allows you to select between color or black and white printing. This key will not function when pressed unless the connected printer supports color. Key Access: Print Setup, More

Restart

Restarts the current measurement activated in the **Measure** key menu.

When in **Average (On)** mode, (**BW/Avg, Average**) the averaging function is restarted (the trace is reset and the average number is reset to zero).

If no measurement is active and **Sweep (Single)** is selected, a new sweep is initiated.

Return

Returns you to the previous menu. Repeated presses of this key move back through previously selected menus (including previous pages selected by the **MORE** key).

NOTE When a menu requiring a yes or no key press has been accessed, the **Return** key will not respond.

NOTE When entering an alphanumeric value (a screen title or filename), pressing **Return** terminates the entry.

Save

Executes a save operation as though you were in the **File, Save** menu and had pressed **Save Now**. If you have previously used the **File, Save, Save Now** keys to setup and save a file, the **Save** hardkey will save your file in the same format and to the same location using a new automatically generated filename. If you have not saved a file since power on, a state file (.STA format) will be saved to the C: drive.

For example, if you use the **File, Save** menu to configure the analyzer to save Trace 1 in .CSV format on the C: drive, using the automatically generated file name (TRACE001.CSV), then every time the front panel **Save** key is pressed, Trace 1 will be saved in .CSV format and the filename will be incremented (TRACE002.CSV, TRACE003.CSV). This provides a convenient format for saving several files with the same format quickly.

NOTE

In the event that a valid save cannot be performed because a drive has not been selected, the **Save** key will report the error `No drive selected`. In this case, press **File, Save** and select a drive.

Single

When analyzer is in continuous sweep mode and not in a measurement (**Measure**, **Meas Off**), this key changes the sweep control to single sweep and executes a sweep after the trigger condition is met. If the analyzer is already in single sweep, pressing **Single** executes a new sweep after the trigger condition is met.

When analyzer is in continuous sweep mode and also in a measurement (selected under the **Measure** key), this key changes the measurement control to take a single measurement and executes a single measurement after the trigger condition is met. If the analyzer is already in single sweep, pressing **Single** executes a new measurement after the trigger condition is met.

If Average is on (**BW/Avg**, **Average (On)**), pressing **Single** resets the average trace and starts the average again from a count of zero. Sweeps are averaged until N sweeps are then taken (where N is the average number), and then the sweep is halted.

Source

Accesses the tracking generator key functions (Options 1DN or 1DQ only). Without Option 1DN or 1DQ, pressing **Source** will cause the error message `Option not installed` to appear on the analyzer display.

CAUTION

If **Auto Align** is on, the 3 GHz tracking generator will be momentarily retuned to approximately 1.557 GHz between most sweeps. Some devices under test (for example, amplifiers with AGC) may be susceptible to damage due to this momentary retuning. To avoid this momentary retuning, turn the auto align off by pressing **System, Alignments, Auto Align, Off**. Refer to the Specifications Guide for your instrument to learn more information about using the analyzer with Auto Align set to off.

**Amplitude
On Off**

Activates (**On**) or deactivates (**Off**) the output power of the tracking generator. The power level can then be adjusted using the numeric keypad, step keys, or knob. Pressing any digit, 0 through 9, on the numeric keypad brings up the selected terminator menu. See the specifications chapter in the calibration guide for the available output power for your tracking generator.

Key Access: **Source**

CAUTION

When the source attenuation is set manually, the actual source amplitude may be greater than the amplitude indicated by the source amplitude. With source attenuation set to manual, source amplitude is permitted to be set to values beyond output levels to accommodate the full range of the analyzer capabilities. As a result, exercise caution when connecting a power-level sensitive device to the tracking generator output

NOTE

For spectrum analyzers with Option 1DN or Option 1DQ, the tracking generator must be turned on (**Source, Amplitude (On)**) before you set up the segmented sweep table.

NOTE

When **Amplitude (Off)** is selected, the output attenuation on the Agilent E4402B, E4403B, E4404B, E4405B, E4407B, and E4408B is set to the maximum attenuation.

**Power Sweep
On Off**

Sets the power-sweep function to **On** or **Off**. The value of the power-sweep range is displayed in the active-function block when you press **Power Sweep (On)**. The analyzer continues to sweep the specified frequency range when power sweep is on. (To do a power sweep at a fixed frequency, set the analyzer to zero span at the desired frequency.)

The available power-sweep range is a function of the source attenuator setting. For your instrument's available power sweep range refer to the appropriate Specifications Guide for your analyzer.

The output power of the tracking generator is swept according to the sweep rate of the analyzer. The output power is always swept from the source power setting to a higher power setting (negative source power sweep values are not allowed).

Power-sweep measurements are particularly useful in making gain compression measurements or output power versus frequency measurements.

Key Access: **Source**

**Attenuation
 Auto Man**

Allows you to select between automatic and manual adjustment of the tracking generator's output attenuator. The Agilent E4401B and E4411B can be manually adjusted from 0 to 60 dB in 10 dB steps. All other Agilent ESA analyzers can be manually adjusted from 0 to 56 dB in 8 dB steps. When auto-coupled, the attenuation function automatically adjusts the attenuator to yield the source amplitude level specified by the **Amplitude On Off** softkey function. For the Agilent E4401B and E4411B, press **Attenuation (Man)** for power sweeps greater than 10 dB.

Key Access: **Source**

CAUTION

When the source attenuation is set manually, the actual source amplitude may be greater than the amplitude indicated by the source amplitude. With source attenuation set to manual, source amplitude is permitted to be set to values beyond output levels to accommodate the full range of the analyzer capabilities. As a result, exercise caution when connecting a power-level sensitive device to the tracking generator output

**Amptd Step
 Auto Man**

Allows you to set the step size of the power level range of the tracking generator. The default setting is one vertical scale division when in a logarithmic amplitude scale.

Key Access: **Source**

Amptd Offset

Offsets the displayed power of the tracking generator. Using the amplitude offset capability of the tracking generator allows you to take system losses or gains into account, thereby displaying the actual power delivered to the device under test.

Key Access: **Source**

Normalize

Key Access: **Source**

**Store Ref
(1→3)**

Copies trace 1 into trace 3. **Store Ref (1→3)** must be pressed before pressing **Normalize (On)**. If **Normalize (On)** is pressed before **Store Ref (1→3)**, the error message: Store reference trace before turning on **Normalize** is displayed in the status line, however **Normalize** has been activated.

Key Access: **Source, More, Normalize**

**Normalize
On Off**

Normalize (On) Activates the normalize function. On each sweep, the normalized trace (Trace 3) is subtracted from Trace 1 and the result is added to the normalized reference level. The display shows the result of the following calculation:

Trace 1 – Normalized Trace + Normalized Reference Level

The trace data is normalized with respect to the normalized reference level, even if the value of the normalized reference level is changed. This function remains in effect on all subsequent sweeps until it is turned off.

NOTE Segmented sweep is not available when **Normalize (On)** is selected.

CAUTION Trace 1 should be in clear write mode prior to setting normalize to on.

The normalize function is most useful for applying correction data to a trace while making a stimulus response measurement with a tracking generator. For example, connect the cables and a thru line, in place of the device to be measured, between the tracking generator and the analyzer input. Notice that the frequency response is not perfectly flat, showing the response of the cables, as well as the flatness of both the tracking generator and the analyzer.

Now press **Store Ref (1→3)**, **Normalize On**. Notice that the displayed trace is now flat, or normalized. The position of the normalized trace can now be moved to a different position on the display by changing the normalized reference position. This may be useful if the device to be tested has positive gain, such as an amplifier. Now replace the thru line with the device under test, and an accurate measurement of the gain or loss can be made.

	Key Access: Source, More, Normalize
Norm Ref Lvl	Sets the level (in dB) of the normalized reference. Key Access: Source, More, Normalize
Norm Ref Posn	Offsets the displayed trace without affecting the instrument gain or attenuation settings. This allows the displayed trace to be moved without decreasing measurement accuracy. The normalized reference position is indicated with a (>) character on the left side of the display and a (<) character on the right side of the display. Key Access: Source, More, Normalize
Ref Trace View BLank	Allows you to view or blank the reference trace on the display. Key Access: Source, More, Normalize
Tracking Peak	<i>Agilent E4402B, E4403B, E4404B, E4405B, E4407B, and E4408B only.</i> Activates a routine that automatically adjusts fine tracking adjustments to obtain the peak response of the tracking generator on the spectrum analyzer display. Tracking Peak is performed in the active resolution bandwidth. Key Access: Source, More
Man Track Adj	<i>Agilent E4402B, E4403B, E4404B, E4405B, E4407B, and E4408B only.</i> Allows you to adjust the frequency of the tracking generator oscillator manually using the step keys, knob, or numeric keypad. The tracking adjust is tuned to maximize the amplitude of the trace. Key Access: Source, More
<hr/> NOTE <hr/>	When Source is On, resolution bandwidths less than 1 kHz are not available.
<hr/> NOTE <hr/>	When the resolution bandwidth is less than 1 kHz, Source may not be turned on.

SPAN X Scale

NOTE If **Power Stat CCDF** is selected in the **MEASURE** menu, see “[SPAN X Scale \(CCDF\)](#)” on page 243 for **Span X Scale** key descriptions.

If **Spectrum Emission Mask** is selected in the **MEASURE** menu, see “[SPAN X Scale \(Spectrum Emission Mask\)](#)” on page 244 for **Span X Scale** key descriptions.

Activates the **Span** function and accesses the menu of span functions. Pressing **SPAN X Scale** allows you to change the frequency range symmetrically about the center frequency. The frequency-span readout describes the total displayed frequency range. To determine frequency span per horizontal graticule division (when the frequency scale type is set to linear), divide the frequency span by 10.

Span Allows you to enter a span frequency range value.

Key Access: **SPAN X Scale**

Span Zoom Performs an automatic zoom so that the signal at the marker remains at the center of the display. If a marker is already on, the zoom begins at the frequency of the marker. If a marker is not already on, a marker is placed on the highest on-screen signal (ignoring the LO feedthrough). Signal-track is turned on, and the span function is activated. Entering a new span value causes the analyzer to change the span in steps, keeping the signal centered on the screen until the desired span is reached. The analyzer is left in Signal Track mode. Pressing **Span Zoom** performs the routine similar to pressing the following keys: **Search**, **Frequency**, **Signal Track (On)**, and **Span**.

NOTE **Span Zoom** is not available when the **Frequency**, **Scale Type (Log)** is selected.

NOTE **Span Zoom** leaves the analyzer in Signal Track mode.

NOTE **Span Zoom** is not available when **Segmented (On)** is selected.

Key Access: **SPAN X Scale**

Full Span Changes the analyzer span to full span showing the full frequency range of the analyzer. In external mixing mode, pressing **Full Span** changes the analyzer span to the specified range for the selected external mixing band. Full span sets **Signal Track (Off)** and **Segmented (Off)**.

Key Access: **SPAN X Scale**

Zero Span Changes the frequency span to zero. In this mode, the current center frequency is displayed in the time domain (the x-axis is displayed in units of time), like a conventional oscilloscope.

Sweep times faster than those in the frequency domain display mode are available if Option AYX or B7D are installed.

Resolution Bandwidths less than 1 kHz are unavailable when in zero span if the sweep time is being achieved by utilizing the Option AYX or B7D.

Key Access: **SPAN X Scale**

NOTE Sweep times that would require Option AYX or Option B7D are not available in zero span if the Resolution Bandwidth is less than 1 kHz.

NOTE Zero Span is not available when **Segmented (On)** is selected. Segments in the segmented sweep function can be set to zero span by setting the span parameter in the segmented sweep editor to 0 Hz. (**Sweep, Segmented, Modify, Edit, Span**)

NOTE The minimum number of sweep in zero span varies with firmware revision:

Firmware Revision	Minimum # of Sweep in Zero Span
≤ A.03.03	401 (fixed)
A.04.xx	101
≥ A.05.00	2

NOTE Zero Span sets **Signal Track (Off)** and **FREQUENCY, Scale Type** to linear mode.

Last Span Changes the analyzer frequency span to the previous span setting. If pressed after **Signal Track** is turned off, the span setting returns to the span that was in effect before **Signal Track** was turned on. This is true, even if **Signal Track** was turned on as part of **Span Zoom**. Last span sets **Segmented (Off)**. The state of **Frequency, Scale Type Log Lin** is included in the recalled information.

Key Access: **SPAN X Scale**

Zone Accesses menu keys that allow you to control the two-window zone function. This function allows you to have an upper window with a broad display of frequency and two zone markers (vertical bars) that define the span for the lower window. This function is only available on ESA-E Series Analyzers (E4401B, E4402B, E4404B, E4405B, and E4407B).

Key Access: **SPAN X Scale**

Zone

On Off

Zone (On) allows you to change from a one-window to a two-window display. The top window will display the trace with two vertical lines (**Zone Markers**) displayed at center frequency plus and minus 5% of the current span. (You can change the default zone frequency and zone span values using the **Zone Center** and **Zone Span** keys.) The top window will be inactive.

The bottom window will display the section of the trace in the top window that is between the **Zone Markers**. The span of the bottom window is 10% of the span of the top window. (You can change the default zone frequency and zone span values using the **Zone Center** and **Zone Span** keys.) When first activated, both windows have the same center frequency. The bottom window is active and the sweep time, resolution bandwidth, and video bandwidth have been coupled to the bottom window span.

There are separate annotations for frequency, bandwidth, sweep time, reference level, amplitude scale and scale/div for each window. The values for these parameters can be changed for each window independently.

To activate the top window, press the **Next Window** key located below the display. The active window is distinguished by a green border. Only the active window will have a sweep taken and updated to the display. When the active window is toggled, the state for the active window is saved, and the last state of the inactive window is recalled. When the window becomes inactive, its data invalid indicator will appear on the display. The data invalid indicator will remain until the window becomes the active window and a complete sweep has been executed. Pressing **Zoom** will change to a one-window display showing only the active window. Pressing **Zoom** again will return you to the two-window display. Pressing **Zone (Off)** will return you to a one-window display of the active window.

Key Access: **SPAN X Scale, Zone**

NOTE

Pressing **Zoom** will set **Zone (On)**, if it is off.

Zone Center

Allows you to change the frequency of the zone markers without changing the zone span. The zone markers are vertical lines marking the zone in the upper window.

They determine the frequency range displayed in the lower window. As the zone markers in the upper window are moved, the center frequency of the lower window is changed but the lower window will not be updated to reflect the change unless it is selected as the active window. (See **Zone On Off**.)

The center frequency for the lower window is not limited by the selected start and stop frequencies in the upper window. However, if the frequency span of the lower window is outside of the span for the upper window, the vertical span markers will be displayed at the edge of the graticule. When the lower window is active, the **FREQUENCY Channel** key will allow you to change **Zone Center**. Any change to the lower window while it is active will change the center frequency.

Key Access: **SPAN X Scale, Zone**

Zone Span

Allows the span of the zone markers to be changed without changing the center frequency. The zone markers are vertical lines marking the zone in the upper window. They determine the frequency range displayed in the lower window. As the zone markers are moved, the span of the lower window is changed but the lower window will not be updated to reflect the change unless it is selected as the active window. (See **Zone On Off**.)

The span limit of the lower window is the same as the span limit of the analyzer. The span for the lower window is not limited to the selected span of the upper window. However, if the frequency span of the lower window is outside of the span of the upper window, the vertical span markers will not be displayed. When the lower window is active, the **SPAN X Scale** key will change **Zone Span**, and any change to **Zone Span** while the lower window is active, will change the span.

Key Access: **SPAN X Scale, Zone**

NOTE

Zone Span is not available when **Segmented (On)** is selected.

Zone Pk Right Finds the next peak to the right of the zone center frequency on the upper window trace and then moves the zone so that it is centered around the new peak. The zone span is not changed. The center frequency of the lower window changes to reflect the new zone center frequency. The lower window will not be updated until it is made active. If no peak is found, the zone will not be moved. A signal must obey the parameters defined

in **Search**, **Search Param** to be identified as a peak signal. Pressing **Zone Pk Right** will have no effect if the upper window is not the active window or if it is in zero span.

Key Access: **SPAN X Scale**, **Zone**

Zone Pk Left

Finds the next peak to the left of the zone center frequency on the upper window trace and then moves the zone so that it is centered around the new peak. The zone span is not changed. The center frequency of the lower window changes to reflect the new zone center frequency. The lower window will not be updated until it is made active. If no peak is found, the zone will not be moved. A signal must obey the parameters defined in **Search**, **Search Param** to be identified as a peak signal. Pressing **Zone Pk Left** will have no effect if the upper window is not the active window or if it is in zero span.

Key Access: **SPAN X Scale**, **Zone**

SPAN X Scale (CCDF)

If **Power Stat CCDF** is selected in the **MEASURE** menu, **SPAN X Scale** accesses the following key.

X-Axis

Allows you to enter a numeric value to change the horizontal display sensitivity. The range is 0.1 to 20.00 dB with 0.01 dB resolution. The default setting is dependent upon the radio standard selected. Refer to [“Mode Setup” on page 213](#) for a list of available standards.

Key Access: **MEASURE**, **Power Stat CCDF**, **SPAN X Scale**

SPAN X Scale (Spectrum Emission Mask)

If **Spectrum Emission Mask** is selected in the **MEASURE** menu, **SPAN X Scale** accesses the following keys.

Scale/Div	<p>Sets the frequency units per horizontal graticule division on the display. To determine full display frequency span, multiply the frequency span per horizontal graticule division by 10.</p> <p>Key Access: MEASURE, Spectrum Emission Mask, SPAN X Scale</p>
Ref Value	<p>Sets the frequency represented by the selected horizontal graticule line on the display (the reference). The current value is indicated by Ref in the upper left corner of the display. You can change the reference value using the step keys, the knob, or the numeric keypad. You can set the reference line location using the Ref Position setting.</p> <p>Key Access: MEASURE, Spectrum Emission Mask, SPAN X Scale</p>
Ref Position	<p>Positions the X-Scale reference to the extreme left line, center line, or extreme right line of the display graticule.</p> <p>Key Access: MEASURE, Spectrum Emission Mask, SPAN X Scale</p>

Standby

Removes power from the analyzer, except for a small portion of circuitry inside the switching power supply. No internal time base circuitry, or any other function outside of the power supply is powered when the analyzer is in “standby.”

Sweep

Activates the sweep time function and accesses the following menu keys:

Sweep Time Auto Man

Selects the length of time the analyzer takes to tune across the displayed frequency span (or, in zero span, the time the analyzer takes to sweep the full screen). Reducing the sweep time increases the sweep rate. The sweep time can be changed using the step keys, the knob, or the numeric keypad.

In non-zero spans:

When the sweep time is auto-coupled, the analyzer selects the optimum (shortest) sweep time for the current settings. This selection process is influenced by several factors:

- The maximum tuning rate of the spectrum analyzer
- The selected Resolution Bandwidth and Video Bandwidth filters
- The maximum sample rate of the Analog-to-Digital converter (ADC) (Trace data are digitized and stored in memory)
- The number of trace (**Sweep**)

You may select a sweep time less than the auto-coupled value; however this may generate measurement errors. If this happens, the error message: **Meas Uncal** will appear in the upper right corner of the display.

In zero span:

The minimum sweep time is determined by the maximum sample rate of the ADC and the number of sweep . With Option B7D, the fastest sweep time is 2.5 microseconds (with 101 sweep). As the number of increases, the sweep time increases. With Option AYX, the fastest sweep time is 5 microseconds (with 101 sweep). With neither option installed, the fastest sweep time is 1 millisecond (with 101 sweep) and 4 milliseconds (with 401 sweep).

NOTE

With firmware A.08.00 and greater, in zero span, the auto/manual function of this key is not applicable. When **Sweep Time (Auto)** is selected in non-zero span, any changes to Sweep Time while in zero span will revert to the Auto value when you return to non-zero span. When **Sweep Time (Man)** is selected in non-zero span, any changes to Sweep Time while in zero span will be maintained when you return to non-zero span.

The maximum sweep time is 4000 seconds for any set of conditions. Refer to your instrument's appropriate Specifications Guide for more information about Sweep Time and its relation to other instrument settings.

Key Access: **Sweep**

**Sweep
Single Cont**

Switches the analyzer between the continuous-sweep mode and the single-sweep mode. Pressing **Sweep (Single)** puts the analyzer in single-sweep mode. Press **Single** on the front panel, to enable a sweep when in single-sweep mode. When **Sweep (Cont)** is selected, one sweep follows another as soon as it is triggered. Pressing **Preset (When Preset Type is set to Factory)** or turning the power on, sets the sweep mode to continuous sweep.

Key Access: **Sweep**

**Auto Swp
Coupling
SR SA**

Selects stimulus-response (SR) or spectrum-analyzer (SA) (default) auto-coupled sweep times. In stimulus-response mode, auto-coupled sweep times are usually much faster for swept-response measurements. Stimulus-response auto-coupled sweep times are typically valid in stimulus-response measurements when the system's frequency span is less than 20 times the bandwidth of the device under test.

Key Access: **Sweep**

Gate

Requires Option 1D6 (Time Gate). Accesses the following menu keys that allow you to setup various gate parameters:

Key Access: **Sweep**

Gate On Off *Requires Option 1D6 (Time Gate).* Turns the gate function on and off. When set to **Gate (On)**, the video signal that is digitized is controlled by the gate circuitry. The gate circuitry switches between two states. When the gate is "open", the normal video signal of the analyzer is passed through the video filters to the peak detectors and digitizer of the analyzer. When the gate is "closed", the video filters, peak detectors, and digitizer are given a signal at the bottom of the display.

The gate function requires that a gate trigger signal be connected to the **GATE TRIG/EXT TRIG IN (TTL)** input on the rear panel. When the gate function is on, the state of the gate appears at the **GATE/HI SWP OUT (TTL)** rear panel connector. A TTL high output indicates that the gate is open. The gate out signal is only valid while the analyzer is sweeping. Between sweeps, the gate out signal is invalid. You can adjust the gate delay and gate length using an oscilloscope to view the gate out signal. The analyzer sweep time should be set to a large value (50 sec) during the adjustment so that the gate signal is valid most of the time. When the adjustment is done you can set the analyzer back to the desired sweep time, or set it back to **Auto Couple**.

Key Access: **Sweep, Gate**

NOTE **Trig Delay (On)** and **Gate (On)** cannot be active at the same time. If **Trig Delay (On)** has been previously selected, it will be reset to **Trig Delay (Off)** when **Gate (On)** is selected. Conversely, if **Gate (On)** has been previously selected, it will be reset to **Gate (Off)** when **Trig Delay (On)** is selected.

NOTE If **Gate (On)** is selected without an external trigger signal present, operating other functions, such as: tracking, frequency count, or preselector centering, may cause the analyzer to stop functioning until it is powered on again.

Gate Control

Edge Level Allows you to select between **Edge** and **Level** triggering of the gate. **Gate Control (Edge)** opens the gate in response to an edge trigger on the trigger input after a delay set in **Gate Delay**. The gate stays open for the selected **Gate Length**. When **Gate Control (Level)** is selected, the gate is open as long as the trigger input is true, as defined under the **Level Gate** key.

Key Access: **Sweep, Gate**

Edge Gate Accesses menu keys that allow you to set up edge triggering.

Key Access: **Sweep, Gate**

Slope Pos Neg Sets the polarity for edge triggering of the gate. When **Slope (Pos)** is pressed, a positive-going edge will trigger the opening of the gate, after the delay set with the **Gate Delay** key. When **Slope (Neg)** is pressed, a negative-going edge will trigger the opening of the gate after the set delay.

Key Access: **Sweep, Gate, Edge Gate**

Gate Delay Controls the length of time from the trigger until the gate is turned on.

Key Access: **Sweep, Gate, Edge Gate**

Gate Length Controls the length of time that the gate is on when using edge triggering to control the gate.

Key Access: **Sweep, Gate, Edge Gate**

Level Gate

High Low Sets up level polarity that will open the gate. Requires Option 1D6.

Level Gate (High) Selects a high TTL level to open the gate. **Level Gate (Low)** selects a low TTL level to open the gate.

Key Access: **Sweep, Gate**

Allows you to set the number of per sweep, from 101 to 8192 in non-zero span and 2 to 8192 in zero span (firmware revision A.05.00 and greater). Use the knob, step keys, or numeric keypad to set this value. When the sweep time is limited by the Analog to Digital Converter (ADC) sample rate, the sweep time changes with the number of selected. The greater the number of , the longer the sweep time becomes. If **Preset** is pressed (and **Preset Type** is set to **Factory**), or the analyzer power is cycled, the number of per sweep will default to 401. The current value of is displayed next to the sweep time.

When **FREQUENCY, Scale Type (Log)** is selected, the desired number of sweep may not be possible. Refer to [“Scale Type Log Lin” on page 165](#) for more information.

Changing the number of has several effects on the analyzer. Since markers are read at the point location, the marker reading may change. Press **Peak Search**, again for greater accuracy in the marker reading. All trace data for the current window is cleared. If in continuous sweep mode, (**Sweep, Sweep (Cont)**), a new sweep begins immediately. If average is on (**BW/Avg, Average (On)**), the averaging starts over with a count of 0. With firmware revisions prior to A.08.00, if Limit Lines are on (**Display, Limits, Modify, Limit 1 or 2 (On)**), they are turned off.

Key Access: **Sweep**

NOTE

By selecting a number of sweep greater than 401, you are optimizing frequency resolution and accuracy while accepting a reduced measurement speed. In addition to sweep , the span, resolution bandwidth, video bandwidth, average detection and center frequency will also affect measurement speed.

This function is not available when signal identification is on (**Input/Output, Input Mixer, Signal Ident (On)**).

When zone span is on (**Span, Zone. Zone (On)**), each window has its own value for .

This feature is not available in the E4403B, E4408B, or E4411B (ESA-L Series). The number of per sweep for these models is always set to 401.

Segmented

Accesses the segmented sweep function and its editor.

Segmented sweep is a method in which you can select multiple frequency bands (a maximum of 32), specify their parameters individually, and display them as a single trace. This function of the analyzer results in faster measurements and provides greater detail

and resolution in particular bands of interest. To set the parameters of individual segments, go to the editor (**Sweep, Segmented, Modify, Edit**) and refer to the parameter key descriptions below. For measurement examples of the segmented sweep function, refer to the *Agilent ESA Spectrum Analyzers Measurement Guide*.

Key Access: **Sweep**

NOTE	This feature is only available on ESA-E series analyzers (E4401B, E4402B, E4404B, E4405B, E4407B) with firmware revision \geq A.05.00.
------	--

Segmented On Off

Turning segmented sweep on (**Sweep, Segmented, Segmented (On)**) displays each sweep segment from left to right in order of increasing start frequency. When segments have the same start frequency, the segments are displayed in order of increasing stop frequency. Overlapping segments are acceptable. (Note however; the reference marker for a marker delta will be displayed in the first segment).

Segments are demarcated by vertical lines. The width of a given segment is determined by the ratio of the number of sweep in the segment to the number of sweep in the total trace. For example, if there are five segments with 101 sweep each (505 total), each segment occupies 20% of trace. If you increase the number of in one of the segments to 404 (808 total), that segment will occupy half of the trace; the other four segments, 12.5% each. You can define up to 32 segments with a total maximum number of sweep equal to 8192.

NOTE	Frequency, Scale Type (Log) is not available when Segmented (On) is selected.
------	---

Key Access: **Sweep, Segmented**

Modify

Accesses the segmented sweep editor described below.

Key Access: **Sweep, Segmented**

Segmented Sweep Editor

When the editor is entered (**Sweep, Segmented, Modify, Edit**), the segmented sweep mode is turned on, and a dual-display appears. The upper window shows the trace, displayed as described above. The lower window shows the editor data in tabular form: one segment per row with segment number and parameter values occupying the seven columns. The parameters that can be set are:

- Center Freq
- Span
- Resolution BW

- Video BW
- Sweep Time (Zero Span only)

The trace is updated after each segment has a complete row of data entered. Although thirty-two segments are possible, only 8 rows of data are shown in the table at a time.

Use the tab keys or softkey menu to navigate the editor. When defining a new segment, you may use the numeric keypad to set values. Pressing **Enter** places the value in the table and highlights the next parameter available for modification.

NOTE

The order of the segments may change when you enter center frequency or span because the sequence is based upon increasing start frequency.

Various parameters are coupled to ensure accurate measurements. You will not be able to enter a value that would result in a measurement that is uncalibrated.

Amplitude parameters are common to all segments and are defined via the amplitude softkey menu. Refer to [“AMPLITUDE Y Scale” on page 106](#) for more information.

The data in the segmented sweep table is retained through a power cycle. Table values can only be deleted by the **Delete** keys described below.

To exit the editor press any key except **Print**, **Help**, and the viewing angle adjustments.

NOTE

Exiting the editor does not turn off segmented sweep. **Segmented (Off)** must be selected.

Interaction with Other Analyzer Functions

Certain conditions prevent segmented sweep from being activated, while others cause this mode to be turned off. For analyzers with Option AYZ, the mixer frequency range (**Input**, **Input Mixer (Ext)**, **Ext Mix Band**) must be set to include the frequencies of interest in the segmented sweep table. If the mixer range is not the same, segmented sweep will not turn on. If the mixer range is changed, segmented sweep will be turned off.

Segmented sweep is not available when the following analyzer functions are turned on: Demod, Signal ID, and Signal Track. In addition, keys which access these functions are grayed out if segmented sweep is on. This is also true for the following functions: Mkr→CF, Mkr→CF Step, Mkr→CF Start, Mkr→CF Stop, MkrΔ→Span, Span Zoom, Zone Span, and Zero Span.

Confining marker pairs (marker delta, delta pair, and span pair) to one segment facilitates interpretation of marker readings. However, marker pairs can provide useful information across segments. Amplitude readings are straightforward because the y-axis is consistent over all segments. Frequency or time readings require consideration of differences in sweep time, number of , and span when interpreting measurements across segments.

Marker delta functions differently depending upon the type of segment in which it is activated. If you turn on marker delta in a segment set to 0 Hz span, it remains in that segment and provides amplitude and time difference measurements. If you initiate a marker delta in a non-zero span segment, it will function across segments and continue to display frequency and amplitude information.

Delta pair and span pair function similarly to marker delta in segmented sweep with some characteristics which need to be noted. When a delta or span pair is initiated in segmented sweep, the analyzer defaults to the frequency domain. If you wish to make time measurements in a zero-span segment, the domain must be set to time (**Marker, More, Readout, Time**). The delta or span pair can traverse all segments without regard to the type of segment in which they were initiated.

NOTE

Turn markers off (**Marker, Off**) when entering or exiting segmented sweep (**Segmented, Segmented (Off)**).

Performing a factory preset will turn segmented sweep off. This is also true if you select full span or last span.

Functions which are parameters of segmented sweep are not available when accessed by pressing the following front-panel keys: **Auto Couple**, **BW/Avg (Resolution BW and Video BW)**, **Frequency** (the entire softkey menu), **Span** (see above), and **Sweep (Sweep Time and)**.

When the sweep trigger is set to any of the trigger selections other than free run, no sweep occurs until the trigger condition is met. Once the trigger occurs, all segments are swept, completing the entire trace.

NOTE

For spectrum analyzers with Option 1DN or Option 1DQ, the tracking generator must be turned on (**Source, Amplitude (On)**) before you set up the segmented sweep table.

The on/off state of the segmented sweep mode and the segmented sweep table can be saved as a “state” type file (see [“Save” on page 232](#)) or as part of the power on/preset function (see [“Power On/Preset” on page 257](#)).

NOTE When loading a “state” type file, segmented sweep will not turn on if any of the parameters in the file contain optional instrument settings not currently loaded on the analyzer or frequency settings outside the current range of the analyzer.

Edit Accesses the segmented sweep editor, where a maximum of thirty-two segments can be defined by the segment number and the six parameters described below. Use the data control keys described in the *Agilent ESA Spectrum Analyzer Getting Started Guide* to enter the setting as each parameter is highlighted. Refer to the “Editor” section above for more information.

Key Access: **Sweep, Segmented, Modify**

Segment Allows you to select a previously defined segment or the next segment for modification. Use the numeric keypad to select a specific segment or press the **Tab** keys to access adjacent segments.

Key Access: **Sweep, Segmented, Modify, Edit**

Center Freq Allows you to specify the center frequency for a particular segment using the data control keys. For more information on this function, refer to “[Center Freq](#)” on page 163.

Key Access: **Sweep, Segmented, Modify, Edit**

Span Allows you to select a frequency range symmetrically about the center frequency for the current segment using the data control keys.

NOTE The order of the segments may change when you enter center frequency or span because the sequence is based upon increasing start frequency. Refer to the “Displaying the Trace” section above, for clarification.

Zero span is available for any or all segments. It must be set by pressing **Span, 0, Hz**. For more information on this function, refer to “[Zero Span](#)” on page 239.

Key Access: **Sweep, Segmented, Modify, Edit**

Res BW Allows you to select the resolution bandwidth to a value between 1 kHz and 5 MHz for the current segment using the data control keys. For more information on this function, refer to [“BW/Avg” on page 129](#).

Key Access: **Sweep, Segmented, Modify, Edit**

Video BW Allows you to set the video bandwidth for the current segment to a value between 30 Hz and 3 MHz. For more information, refer to [“Video BW Auto Man” on page 129](#).

Key Access: **Sweep, Segmented, Modify, Edit**

Allows you to set the number of for the current segment. The minimum number of in a zero span segment is 2; in a non-zero-span segment, 101. The maximum number of in the total sweep is 8192. If you exceed the number of available in one segment, the message: Too much data; total sweep limited will be displayed in the status line (yellow on color displays).

Key Access: **Sweep, Segmented, Modify, Edit**

Sweep Time Allows you to set the sweep time for the current zero span segment. For a non-zero span segment, the sweep time is auto-coupled to Span, Resolution Bandwidth, and Video Bandwidth and cannot be manually defined. The minimum sweep time is displayed. Refer to [“Sweep Time Auto Man” on page 246](#) for more information.

Key Access: **Sweep, Segmented, Modify, Edit, More**

NOTE The parameters for each segment are limited to ensure the occurrence of only calibrated measurements.

Delete Segment . Deletes the highlighted segment.

Key Access: **Sweep, Segmented, Modify, Edit, More**

**Delete
Segment**

Initiates the deletion of all segments. After pressing this key once, the message: If you are sure, press key again to delete will be displayed. Pressing **Delete** again will complete the process.

Key Access: **Sweep, Segmented, Modify**

System (Local)

Accesses the System menu keys. Pressing **System (Local)** after the analyzer has been placed in the remote mode, places the analyzer in the local mode and enables front-panel control. During remote operation, **R** appears in the upper-right corner of the screen. **R**, **T**, **L**, or **S** may appear during remote operation, indicating talk, listen, or service request. Pressing the **System (Local)** key removes the **R** symbol in the upper-right corner.

Show Errors

Accesses a display of the last 30 errors reported. The most recent error will appear at the top of the list. The first error listed will be the first error removed if the error list is longer than 30 entries. If the same error message occurs several times the error message will be incremented rather than added to the list as a new error message.

The date and time identify the first time and the last time (if there is more than one of the same type of error) an error occurred. The number of identical errors is shown, and the error number is also shown with firmware revision A.08.00 and later.

Key Access: **System**

Prev Page Allows you to access the previous page of error messages. It is grayed out if you are on the first page or only one page exists.

Key Access: **System, Show Errors**

Next Page Allows you to access the next page of error messages. It is grayed out if you are on the last page or only one page exists.

Key Access: **System, Show Errors**

**Verbose SCPI
On Off**

The information in the Error History Screen is formatted to fit the screen size. Additional information is available via the `SYSTem:ERRor?` command. It indicates which SCPI command was executing when the error occurred and what about that command was unacceptable.

Example: First set `SYST:ERR:VERBOSE ON`

If the command `SENSe:FREQuently:CENTer 942.6MHz` is sent, then sending `SYST:ERR?` returns:

```
-113, "Undefined
header;SENSe:FREQuently:<Err>CENTer 942.6MHz
${<NL>}"
```

Key Access: **System, Show Errors**

**Clear Error
Queue**

Clears the error queue in the **Show Errors** display.

Key Access: **System, Show Errors**

Power On/Preset Accesses the following menu keys.

Key Access: **System**

**Power On
Last Preset**

Determines the state of the analyzer when the analyzer is powered on. If the Power On function is set to **Preset**, the state of the analyzer is the same as it is after **Preset** is pressed, when the analyzer is powered on. If the Power On function is set to **Last**, then the state that the analyzer was in when it was powered off is recalled.

The setting (Last or Preset) of the Power On function is not changed by pressing **Preset**. Use the **Power On/Preset** menu key function to change the setting of the analyzer state that is recalled at power on. Limit lines are not recalled when the analyzer is powered on. Refer to "**Preset**" in this chapter for more information.

Key Access: **System, Power On/Preset**

Preset Type Allows you to select User, Mode, or Factory preset.

Key Access: **System, Power On/Preset**

User Pressing **Preset (User)** sets the analyzer to the settings defined by the **Save User Preset** key. Refer to "**Preset**" in this chapter for more information.

Key Access: **System, Power On/Preset, Preset Type**

	Mode	Selects the mode preset type to be the instrument state that will be restored when you do a preset. A mode preset does not change the mode and it only resets the settings of the current mode to their factory defaults. Key Access: System, Power On/Preset, Preset Type
	Factory	Pressing Factory presets the analyzer to the configuration originally set at the factory. Refer to the “ Preset ” key description for the default factory-configuration settings. Key Access: System, Power On/Preset, Preset Type
		Key Access: System, Power On/Preset, Preset Type
	Save User Preset	Saves the active state of the analyzer into the User Preset register for recall on Preset if Preset (User) is selected. Refer to “ Preset ” in this chapter for more information. Key Access: System, Power On/Preset
Time/Date		Accesses the following Time/Date menu keys used to set and display the real-time clock: Key Access: System
	Time/Date On Off	Turns the display of the real-time clock on or off. Key Access: System, Time/Date
	Date Format MDY DMY	Changes the display of the date from a month-day-year format to a day-month-year format. Key Access: System, Time/Date
	Set Time	Allows you to set the time of the real-time clock. Enter the time in 24 hour HHMMSS format, using the numeric keypad and pressing Enter . Valid hour (HH) values are from 00 to 23. Valid minute (MM) and second (SS) values are from 00 to 59. Key Access: System, Time/Date

Set Date Allows you to set the date of the real-time clock. Enter the date in the YYYYMMDD format using the numeric keypad and press **Enter**. Valid year (YYYY) values are 0000 through 9999. Valid month (MM) values are from 01 to 12, and valid day values are from 01 to 31.

Key Access: **System, Time/Date**

Alignments

Accesses the following **Alignments** menu keys which align the internal circuitry of the analyzer, load default values for the alignment system, and adjust the 10 MHz reference.

Key Access: **System**

Auto Align Accesses the **Auto Align** menu keys.

All Turns on the automatic alignment of all measurement systems. When **Auto Align, All** is selected, “**AA**” appears along the left edge of the display.

Key Access: **System, Alignments**

All but RF Turns on the automatic alignment of all measurement systems except the RF section. (Eliminating automatic alignment of the RF prevents changes in the input impedance between sweeps, which could cause input device instability.) When **Auto Align, All but RF** is selected, “**AB**” appears along the left edge of the display.

Key Access: **System, Alignments**

Off Turns off automatic alignment.

Key Access: **System, Alignments**

NOTE

It is normal to hear clicking sounds when the Auto Alignment function is On. During retrace, a small portion of the analyzer circuitry is realigned. Some of the switching of the analyzer circuitry is done using relays. It is the rapid switching of these relays during retrace that causes the clicking sounds. To eliminate the clicking sounds, turn the auto alignment off by pressing **System, Alignments, Auto Align, Off**. When this is done, the **Align Now, All** function should be performed periodically. Refer to the appropriate “Specifications and Characteristics” chapter your Specifications Guide for more information on how often to perform **Align Now, All** when the auto alignment is off

Align Now	Accesses the Align Now menu keys and immediately executes an alignment cycle of the selected system(s). Menu key selections include: Key Access: System, Alignments
All	Initiates the alignment of all systems. Except the Option 1DN Tracking Generator for models E4402B, E4403B, E4404B, E4405B, E4407B, and E4408B. Key Access: System, Alignments, Align Now
RF (Ext Cable)	Initiates the alignment of the RF system with a cable connected from AMPTD REF OUT to INPUT 50 Ω . <i>Models E4402B, E4403B, E4404B, E4405B, E4407B, and E4408B.</i> Key Access: System, Alignments, Align Now
RF	Initiates the alignment of the RF system. <i>Models E4401B and E4411B only.</i> This Alignment uses an Internal Signal Source. Key Access: System, Alignments, Align Now
TG (Ext Cable)	Initiates the alignment of the tracking generator only when the Option 1DN is installed in Agilent E4402B, E4403B, E4404B, E4405B, E4407B, and E4408B. You must connect a cable from RF OUT 50 Ω to INPUT 50 Ω Key Access: System, Alignments, Align Now
FM Demod	Initiates an alignment of the FM demodulation system only when Option BAA or Option 106 is installed. Key Access: System, Alignments, Align Now

After a five minute warm-up, **Align Now, All** (with a cable connected from AMPTD REF OUT to INPUT 50 Ω) should be performed on Agilent E4402B, E4403B,

E4404B, E4405B, E4407B, and E4408B. Refer to your analyzer's appropriate Specifications Guide for details on using **Align Now** when **Auto Align** is **Off**.

**Freq Correct
On Off**

Controls use of some of the correction factors. When **On** is underlined, frequency correction factors are used. When **Off** is underlined, frequency correction factors are not used, and **Freq Corr Off** appears on the display. Turning the correction factors off degrades frequency accuracy.

Key Access: **System, Alignments**

NOTE

Frequency correction factors must be on for the analyzer to meet its specified performance.

Timebase

Accesses the **Fine** and **Coarse** Timebase menu keys, which allow control of the 10 MHz time base frequency. This function is used to verify the settability of the 10 MHz reference and to adjust for changed operating conditions, such as temperature. Pressing **Load Defaults** or cycling power, resets the time base to its original value.

Key Access: **System, Alignments**

Load Defaults

Loads the default values for the alignment system, turns on the frequency corrections, and resets the time base to the factory values. **Align Now, All**, will automatically execute three times after pressing **Load Defaults**.

Key Access: **System, Alignments**

Remote Port

With Option A4H (GPIB and Parallel) only. Allows the GPIB address to be entered. The default address is 18.

With Option 1AX (RS-232 and Parallel) only. Allows the baud rate to be set. The available baud rate values are as follows: 110, 300, 600, 1200, 2400, 4800, 9600, 19200, 38400, 57600, 115200. The default baud rate is 9600.

Key Access: **System**

Show System

Displays the number and description of the options installed in your analyzer. It also displays the instrument model number, product number, serial number, firmware revision number, Host ID (for licensing), bootrom revision, and amount of RAM and ROM.

Key Access: **System, More**

Prev Page

Allows you to access the previous page of show system.

	<p>It is grayed out if you are on the first page or only one page exists.</p> <p>Key Access: System, More, Show System</p>
Next Page	<p>Allows you to access the next page of show system. It is grayed out if you are on the last page or only one page exists.</p> <p>Key Access: System, More, Show System</p>
Show Hdwr	<p>Gives detailed information about the hardware installed on your analyzer.</p> <p>Key Access: System, More</p>
Prev Page	<p>Allows you to access the previous page of show hardware. It is grayed out if you are on the first page or only one page exists.</p> <p>Key Access: System, More, Show Hdwr</p>
Next Page	<p>Allows you to access the next page of show hardware. It is grayed out if you are on the last page or only one page exists.</p> <p>Key Access: System, More, Show Hdwr</p>
Color Palette	<p>Agilent ESA-E Series only (E4401B, E4402B, E4404B, E4405B and E4407B). Accesses the Color Palette menu keys. These keys are only available with analyzers having a color display.</p> <p>Key Access: System, More</p>
Default	<p>Sets all the display screen attributes to the factory defined colors.</p> <p>Key Access: System, More, Color Palette</p>
Vision Impair 1 and Vision Impair 2	<p>The special colors built into the Vision Impair 1 and Vision Impair 2 keys accommodate most color-deficient vision problems.</p> <p>Key Access: System, More, Color Palette</p>
Optical Filter	<p>Accommodates the use of protective goggles while viewing lasers.</p> <p>Key Access: System, More, Color Palette</p>
Monochrome	<p>Sets the display screen to green monochrome. The monochrome display uses different shades of green for each green value. This is especially useful for driving external monochrome monitors.</p>

Key Access: **System, More, Color Palette**

Diagnostics

Accesses the **Front Panel Test** menu key.

Key Access: **System, More**

Front Panel

Test

Allows you to verify the functionality of each front-panel key (except **Preset**). The number next to each key name increments once each time the key is pressed. Rotating the knobs causes the number of pulses to be counted. Press **ESC** to exit.

Key Access: **System, More, Diagnostics**

Restore Sys Defaults

Resets the “persistent” state variables to their defaults. These are values, such as the GPIB address, that are unaffected by a power cycle or a preset (when **Preset Type** is set to **Factory**.)

Key Access: **System, More**

Table 3-9

System Default Settings

Feature	Default Setting
Color Printing	On
Custom Printer, Color Capability	No
Custom Printer, Language	PCL3
Date Format	MDY
Display Viewing Angle	4
External Amplifier Gain	0 dBm
GPIB Address	18
Input Impedance	50 (Ohm) ¹
Instrument Color Palette	Default palette
Manual Tracking Adjustment	2048
Page Size	Letter
Power On Last/Preset	Preset
Preset Factory/User	Mode
Print Format	Print screen mode
Print Orientation	Portrait
Printer Selection	Auto
Prints/ Page	1

Table 3-9 System Default Settings (Continued)

Feature	Default Setting
RS-232 Baud Rate	9600
RS-232 DTR Control	On (hardware pacing)
RS-232 Receive Pacing	None (data pacing)
RS-232 RTS Control	IBFULL (hardware pacing)
RS-232 Transmit Pacing	None (data pacing)
Speaker Volume	0
Time Date Display	On
Verbose SCPI	Off

1. This value may be 75 ohms, depending upon the analyzer hardware configuration.

Licensing Accesses the security system to enable licensing for individual options. For information on how to use this system, see the installation information for individual options in the measurement personalities' user's guides.

NOTE Not all options can be enabled using this system and there is no way to turn *off* an option through this system. Once an option has been licensed for a given analyzer, it cannot be transferred to a different analyzer.

Key Access: **System, More, More**

Option Accesses the Alpha Editor allowing you to enter a three character option number. To terminate the entry, press **Enter** or **Return**. An external keyboard may also be used for this entry. The option number will appear on the second line of the **Option** key. Key

Access: **System, More, Licensing**

License Key Accesses the Alpha Editor allowing you to enter the license key number. To terminate the entry, press **Enter** or **Return**. An external keyboard may also be used for this entry. The license key number will appear on the second line of the **License Key** menu key.

Key Access: **System, More, Licensing**

Activate Allows you to activate the option. When a valid option key number and license key number have been entered, press **Activate**. If your entry was correct, the option will be enabled and the message: `Option activated` will appear in the status line of your display. The option number and license key number will also be cleared from the **License Key** and **Option key**.

If your entry was incorrect, the error message: **License key invalid** will appear in the status line of your display. The option number and license key number can be edited until they are correct.

Key Access: **System, More, Licensing**

NOTE It is possible to enable an option for which the analyzer is not yet configured. Therefore, the message `Option activated` does not mean that the option will immediately function. For a display of options that are enabled and for which the analyzer is properly configured, press **System, More, Show System**.

Personalities Accesses a display listing the personalities that are currently installed in the analyzer. Information about the personalities are under the column headings **Opt** (option number), **Name** (option name), **Version** (personality version), **Licensed** (whether or not the personality is licensed), and **Size** (personality memory). At the bottom of the display is a line showing the available memory for installing personalities.

Key Access: **System, More, More**

NOTE Some files are shared between personalities. If shared files are installed, a personality may require less room than is indicated on the display. The **Uninstall** key will not delete any shared file unless the personality being deleted is the last personality to use the shared file.

Prev Page Allows you to view a previous page of installed personalities. It is grayed out if you are on the first page or only one page exists.

Key Access: **System, More, More, Personalities**

Next Page Allows you to view the next page of installed personalities. It is grayed out if you are on the last page or only one page exists.

Key Access: **System, More, More, Personalities**

Install Allows you to install personalities in the analyzer. For more information on this key, see the documentation that accompanies the personalities software.

Key Access: **System, More, More, Personalities**

Uninstall Allows you to uninstall a personality. Highlight the appropriate personality and press **Uninstall, Uninstall Now**. You will be prompted with the displayed message If you are sure you want to uninstall, press Uninstall Now again.

Some personalities may not be deleted. If the attempt is made to do so, the message Can't uninstall this program will appear on the display.

Key Access: **System, More, More, Personalities**

Service Accesses the **Service** menu keys. You must have a password to access this menu. For information, refer to the troubleshooting chapter in the your Service Guide.

Key Access: **System, More, More**

Tab Keys

The Tab keys are located below the display and are used to move between fields in the tables and forms.

Trace/View

Accesses the trace keys that allow you to store and manipulate trace information. Each trace is comprised of a series of data in which amplitude information is stored. The analyzer updates the information for any active trace with each sweep.

NOTE If you have selected **Channel Power**, **ACP**, **Harmonic Distortion**, **Burst Power**, **Power Stat CCDF**, or **Spectrum Emission Mask** in the **MEASURE** menu, refer to the **Trace/View** sections specific to those measurements.

Trace 1 2 3 Selects the menu keys used for trace 1, trace 2, or trace 3 functions. Press **Trace 1 2 3** until the number of the desired trace is underlined.

Key Access: **Trace/View**

CAUTION When using normalization, the mode of traces 2 and 3 should not be changed.

Clear Write Erases any data previously stored in the selected trace and continuously displays any signals during the sweep of the analyzer. This function is activated for trace 1 at power-on and by pressing **Preset**.

Key Access: **Trace/View**

Max Hold Maintains the maximum level for each trace point of the selected trace (1, 2 or 3), and updates each trace point if a new maximum level is detected in successive sweeps.

Key Access: **Trace/View**

NOTE Changing the vertical scale (**Amplitude**, **Scale Type**, **Log** or **Lin**), pressing **Restart**, turning averaging on (**BW/Avg**, **Average (On)**), or switching window in Zone Span (**Span**, **Zone**) restarts the held trace.

Min Hold Maintains the minimum level for each trace point of the selected trace (1, 2 or 3), and updates each trace point if a new minimum level is detected in successive sweeps.

Key Access: **Trace/View**

NOTE Changing the vertical scale (**Amplitude**, **Scale Type**, **Log** or **Lin**), pressing **Restart**, turning averaging on (**BW/Avg**, **Average (On)**), or switching window in Zone Span (**Span**, **Zone**) restarts the held trace.

View Holds and displays the amplitude data of the selected trace. The trace register is not updated as the analyzer sweeps. If a trace is deactivated by pressing **Blank**, the stored trace data can be retrieved by pressing **View**.

Key Access: **Trace/View**

Blank Stores the amplitude data for the selected trace, and removes it from the display. The selected trace register will not be updated as the analyzer sweeps. This function is activated for traces 2 and 3 at power-on and by pressing **Preset** (when **Preset Type** is set to **Factory**.)

Key Access: **Trace/View**

Operations Accesses the following **Operations** menu keys:

Key Access: **Trace/View, More**

1↔2 Exchanges the contents of the trace 1 register with the trace 2 register and puts trace 1 and 2 in view mode.

Key Access: **Trace/View, More, Operations**

2 – DL → 2 Subtracts the display line from trace 2 and places the result in trace 2 and puts trace 2 in view mode. The **2 – DL → 2** function is a math operation.

Key Access: **Trace/View, More, Operations**

2 ↔ 3 Exchanges the contents of trace 2 with trace 3 and puts trace 2 and 3 in view mode.

Key Access: **Trace/View, More, Operations**

1 → 3 Copies trace 1 into trace 3 and puts trace 3 in view mode.

Key Access: **Trace/View, More, Operations**

2 → 3 Copies trace 2 into trace 3 and puts trace 3 in view mode.

Key Access: **Trace/View, More, Operations**

Normalize Accesses the following **Normalize** menu keys:

Key Access: **Trace/View, More**

Store Ref

(1→3) Copies trace 1 into trace 3. **Store Ref (1→3)** must be pressed before pressing **Normalize (On)**. If **Normalize (On)** is pressed before **Store Ref (1→3)**, the error message: Store reference trace before turning on Normalize is displayed in the status line, however Normalize has been activated.

Key Access: **View/Trac, More, Normalize**

Normalize

On Off

Normalize (On) Activates the normalize function. On each sweep, the normalized trace (Trace 3) is subtracted from Trace 1 and the result is added to the normalized reference level. The display shows the result of the following calculation:

$$\text{Trace 1} - \text{Normalized Trace} + \text{Normalized Reference Level}$$

The trace data is normalized with respect to the normalized reference level, even if the value of the normalized reference level is changed. This function remains in effect on all subsequent sweeps until it is turned off.

NOTE Segmented sweep is not available when **Normalize (On)** is selected.

CAUTION Trace 1 should be in clear write mode prior to setting normalize to on.

The normalize function is most useful for applying correction data to a trace while making a stimulus response measurement with a tracking generator. For example, connect the cables and a thru line, in place of the device to be measured, between the tracking generator and the analyzer input. Notice that the frequency response is not perfectly flat, showing the response of the cables, as well as the flatness of both the tracking generator and the analyzer.

Now press **Store Ref (1→3)**, **Normalize On**. Notice that the displayed trace is now flat, or normalized. The position of the normalized trace can now be moved to a different position on the display by changing the normalized reference position. This may be useful if the device to be tested has positive gain, such as an amplifier. Now replace the thru line with the device under test, and an accurate measurement of the gain or loss can be made.

Key Access: **Trace/View, More, Normalize**

Norm Ref Lvl Sets the level (in dB) of the normalized reference.

Key Access: **Trace/View, More, Normalize**

Norm Ref Posn Offsets the displayed trace without affecting the instrument gain or attenuation settings. This allows the displayed trace to be moved without decreasing measurement accuracy. The normalized reference position is indicated with a (>) character on the left side of the display and a (<) character on the right side of the display.

Key Access: **Trace/View, More, Normalize**

**Ref Trace
View Blank**

Allows you to view or blank the reference trace on the display.

Key Access: **Trace/View, More, Normalize**

Trace/View (ACP)

If **ACP** is selected in the **MEASURE** menu, **Trace/View** displays the following menu for the adjacent channel power (ACP) measurement.

Spectrum	Selects the spectral display of the measurement. Key Access: Measure, ACP, Trace/View
Bar Graph	Turns the graphic bar display on or off. The bar graph display overlays the spectrum. Key Access: Measure, ACP, Trace/View
Combined	Selects the measurement to be displayed as a bar graph and spectrum. Key Access: Measure, ACP, Trace/View
Combined Rel Abs	Key Access: Measure, ACP, Trace/View
Trace	Accesses menu keys that allow you to set how the trace information is stored and displayed. Refer to “Trace/View” on page 268 for Trace menu key information. Key Access: Measure, ACP, Trace/View

Trace/View (Burst Power)

If **Burst Power** is selected in the **MEASURE** menu, **Trace/View** displays the following menu for the burst power measurement.

RF Envelope

Key Access: **Measure, Burst Power, Trace/View**

Combined

Displays the measurement results the same as RF Envelope, but has a blue bar between the markers to indicate the measured output power level. The actual measured output power is displayed at the bottom of the bar.

Key Access: **Measure, Burst Power, Trace/View**

Trace

Accesses menu keys that allow you to set how the trace information is stored and displayed. Refer to [“Trace/View” on page 268](#) for **Trace** menu key information.

Key Access: **Measure, Burst Power, Trace/View**

Trace/View (Channel Power)

If **Channel Power** is selected in the **MEASURE** menu, **Trace/View** displays the following menu for the channel power measurement.

- | | |
|-----------------|---|
| Spectrum | Selects the spectral display of the measurement.
Key Access: Measure, Channel Power, Trace/View |
| Combined | Selects the measurement to be displayed as a bar graph and spectrum.
Key Access: Measure, Channel Power, Trace/View |
| Trace | Accesses menu keys that allow you to set how the trace information is stored and displayed. Refer to “Trace/View” on page 268 for Trace menu key information.
Key Access: Measure, Channel Power, Trace/View |

Trace/View (Harmonic Distortion)

If **Harmonic Distortion** is selected in the **MEASURE** menu, **Trace/View** displays the following menu for the harmonic distortion measurement.

Harmonics	Displays the harmonic number, frequency, and amplitude of the harmonic found in the lower window on the analyzer display. Key Access: Measure, Harmonic Distortion, Trace/View
Harmonics & THD	Displays the harmonic number, frequency, and amplitude of the harmonic found in the lower window on the analyzer display, as well as the total harmonic distortion (THD), which is shown as a percentage and as a dB value. Key Access: Measure, Harmonic Distortion, Trace/View
Trace	Accesses menu keys that allow you to set how the trace information is stored and displayed. Refer to “Trace/View” on page 268 for Trace menu key information. Key Access: Measure, Harmonic Distortion, Trace/View

Trace/View (Power Stat CCDF)

If **Power Stat CCDF** is selected in the **MEASURE** menu, **Trace/View** displays the following menu for the complimentary cumulative distribution function (CCDF) measurement.

CCDF

Performs a CCDF measurement. The measurement bandwidth is set to 5 MHz, counts to 100 k, measurement interval to 1.00 ms and the x-axis scale to 2.00 dB/div. The displayed traces are a Gaussian line and the current measured trace.

Power complimentary cumulative distribution function (CCDF) curves characterize the higher-level power of the signal. It provides the distribution of peak-to-average power ratios versus probability. A CCDF curve is defined by how much time the waveform spends at or above the given power level. The percent of time the signal spends at or above the level defines the probability for that particular power level.

Key Access: Measure, Power Stat CCDF, Trace/View

Trace/View (Spectrum Emission Mask)

If **Spectrum Emission Mask** is selected in the **MEASURE** menu, **Trace/View** displays the following menu for the spectrum emission mask measurement.

Abs Pwr & Freq

Allows you to view the measurement results of spectrum measurements in the graph window as absolute peak power and frequency. The absolute peak power levels in dBm and corresponding offset frequency ranges on both sides of the reference channel are displayed in the text window.

Key Access: **Measure, Spectrum Emission Mask, Trace/View**

Rel Pwr & Freq

Allows you to view the measurement results of spectrum measurements in the graph window as power relative to the carrier power and frequency. The relative power levels in dBc and corresponding offset frequency ranges on both sides of the reference channel are displayed in the text window

Key Access: **Measure, Spectrum Emission Mask, Trace/View**

Integrated Power

Allows you to view the measurement results of spectrum measurements in the graph window as integrated absolute and relative peak power and frequency. The absolute and relative peak power levels integrated throughout the bandwidths between the start and stop frequencies, and corresponding offset frequency ranges on both sides of the reference channel, are displayed in the text window

Key Access: **Measure, Spectrum Emission Mask, Trace/View**

Trig

Accesses the menu of keys that allow you to select the sweep mode and trigger mode of the analyzer.

Free Run	New sweep starts as soon as possible after the current sweep ends. Key Access: Trig
Video	Activates the trigger condition that allows the next sweep to start if the detected RF envelope voltage rises to a level set by the video trigger level. When Video is pressed, a line appears on the display. The analyzer triggers when the input signal exceeds the trigger level at the left edge of the display. You can change the trigger level using the step keys, the knob, or the numeric keypad Key Access: Trig

NOTE This function is not available when the Resolution Bandwidth is less than 1 kHz. If a Resolution Bandwidth less than 1 kHz is selected while in Video Trigger mode, the Trigger mode changes to Free Run.

Line	Activates the trigger condition that allows the next sweep to be synchronized with the next cycle of the line voltage. Key Access: Trig
-------------	---

NOTE Line trigger is not available when operating from a dc power source.

External Pos Neg	Activates the trigger condition that allows the next sweep to start when the external voltage (connected to GATE TRIG/EXT TRIG IN on the rear panel) passes through approximately 1.5 volts. The external trigger signal must be a 0 V to +5 V TTL signal. This function also controls the trigger polarity (for positive or negative-going signals). Key Access: Trig
-------------------------	---

TV	<i>Option B7B (TV Trigger and Picture on Screen) only.</i> Activates the trigger condition that allows the next sweep to be synchronized with the next occurrence of the synchronizing pulse of a selected TV line.
-----------	---

Line number range is dependent on the settings of the **Standard** and **Field** menus within the **TV Trig Setup** menu. When the line number is incremented beyond the upper limit, the value will change to the lower limit and continue incrementing from there. When the line number is decremented below the lower limit, the value will change to the upper limit and continue decrementing from there.

Key Access: **Trig**

RF Burst *Option B7E (RF Communications Hardware) only.* Allows the analyzer to be triggered by an RF burst envelope signal. The trigger level can be set to either a level relative to the peak of the burst or to an absolute value.

Key Access: **Trig**

Trig Delay On Off Allows you to set and turn on or off a delay, during which the analyzer will wait to begin a sweep after receiving an external trigger signal. This function is not available when **Gate** is on. **Trig Delay** is active when **External** is selected.

Key Access: **Trig, More**

NOTE This function is not available in Free Run or Video Trigger modes.

Trig Offset On Off Allows you to set and turn on or off an offset value from the trigger point of the sweep at which to begin storing data in the trace of the analyzer. The offset is specified as a function of time, and permits positive (pre trigger) and negative (post trigger) values to be specified.

Key Access: **Trig, More**

NOTE This function is only available when in Zero Span. (It is grayed out when in swept span.) If this key is pressed in swept spans, the error message: `Trigger Offset unavailable in swept spans` is displayed in the status line. The value and state of Trigger Offset is remembered if Zero Span is exited and restored when Zero Span is reselected.

NOTE This function is only available with Resolution Bandwidths of 1 kHz or greater. If this key is pressed when the Resolution Bandwidths is less than 1 kHz, the error message: `Trigger Offset unavailable in bandwidths < 1 kHz` is displayed in the status line. While Trigger Offset is on, it is not possible for the instrument to be set to a Resolution Bandwidth less than 1 kHz. Any attempt to do so will cause the error message: `Bandwidths <1 kHz unavailable with Trigger Offset on` to be displayed in the status line.

TV Trig Setup *Option B7B (TV Trigger and Picture on Screen) only.* Accesses the setup functions for TV Trigger.

Key Access: **Trig**

Field

Allows you to determine how the fields of the TV picture signal will be affected by the trigger system. One complete TV image consists of one frame of 525 or 625 horizontal lines depending on the TV standard being used. Each frame is composed of two fields of interlacing lines, each consisting of 262 1/2 lines (or 312 1/2 lines). The fields are called Field One and Field Two. Field One is viewed as having 263 lines (or 313 lines) and Field Two is viewed as having 262 lines (or 312 lines).

For the 525 line NTSC video standard, we refer to TV lines as follows (these are the Field Modes):

Entire Frame, lines 1 to 525

Field One, lines 1 to 263

Field Two, lines 1 to 262 (note that this really refers to “actual” lines 264 to 525)

For the 625 line PAL and SECAM video standards, we refer to TV lines as follows:

Entire Frame, lines 1 to 625

Field One, lines 1 to 313

Field Two, lines 314 to 625

As the Field is changed, the appropriate value for Line is chosen to keep triggering on the same line as before, or if this is not possible, the corresponding line in the new Field. For example, suppose line 264 is selected while in the NTSC-M standard and the Entire Frame mode. This is the first line in Field Two. If Field Two is then selected, the Line number changes to Line 1, the same actual line in the TV signal. If Field One is then selected, the line number stays at 1, but now we are triggering in the first line in Field One. The only exception to this is if we are on the last line of Field One and change to Field Two. In this case, we go to the last line in Field Two.

Key Access: Trig, More, TV Trig Setup

Entire Frame Causes the selected line number to be viewed as an offset into the entire frame starting with line 1, the first line in Field One.

Key Access: Trig, More, TV Trig Setup, Field

Field One	<p>Causes the selected line number to be viewed as an offset into the first field starting with Line 1, the first line in Field One.</p> <p>Key Access: Trig, More, TV Trig Setup, Field</p>
Field Two	<p>Causes the selected line number to be viewed as an offset into the second field. If Line 1 is selected, it is the 264th line of the frame (NTSC-M, NTSC-Japan, PAL-M) or the 314th line of the frame (PAL-B,D,G,H,I, PAL-N-Combin, SECAM-L).</p> <p>Key Access: Trig, More, TV Trig Setup, Field</p>
Sync Pos Neg	<p>Refers to the nature of the video waveform. Normal baseband video has a TV line sync pulse on the bottom of the waveform (more negative voltage). This is referred to as “negative” (Sync Neg). When the analyzer is used as a TV receiver to produce baseband video, the detected video is “upside down” with the sync pulse on the top of the waveform (this is true only for NTSC and PAL transmission standards, not for SECAM). This orientation is referred to as “positive” (Sync Pos).</p> <p>Key Access: Trig, More, TV Trig Setup</p>
Standard	<p>Accesses the Standard menu keys which allow you to select from the following TV standards: NTSC-M, NTSC-Japan, PAL-M, PAL-B,D,G,H,I, PAL-N, PAL-N-Combin, SECAM-L.</p> <p>Key Access: Trig, More, TV Trig Setup</p>
TV Source	<p>Allows you to select between the internal analyzer path (SA) or the EXT VIDEO IN connector on the rear panel (Ext Video In) as the source for the TV Trigger and TV Monitor functions. Note that this does not affect the signal viewed on the analyzer.</p> <p>Key Access: Trig, More, TV Trig Setup</p>
TV Monitor	<p>When TV Monitor is pressed, the selected Standard is used to determine the proper setup of the analyzer hardware for presentation of the TV picture. When the TV picture is active and on the display, pressing a key that normally accesses a menu, instead restores the original ESA graphical display with the selected menu enabled. The active function remains active and can be adjusted while the picture is displayed.</p>

Key Access: **Trig, More, TV Trig Setup**

NOTE The color decoding circuitry is always enabled, even for weak and monochrome signals.

RF Burst Setup *Option B7E (RF Communications Hardware) only.* Accesses the setup functions for RF burst trigger.

Key Access: **Trig, More**

Trigger Level

Abs Rel Allows you to set the trigger level to a level relative to the peak of the burst or to an absolute value.

Key Access: **Trig, More, RF Burst**

Frequency Selectivity

On Off Allows you to turn frequency selectivity on or off. With **Frequency Selectivity (Off)** selected, the trigger occurs on the signal prior to the resolution bandwidth filter. When **Frequency Selectivity (On)** is selected, the trigger occurs on the signal after the resolution bandwidth filter.

Key Access: **Trig, More, RF Burst**

Narrow Pulse Discriminator

On Off Turns the narrow pulse discriminator on or off. For modulation formats that have undesirable envelope ripple, **Narrow Pulse Discriminator (On)** allows you to prevent re-triggering on the ripple.

Key Access: **Trig, More, RF Burst**

↑ (UP) and ↓ (DOWN) Arrow Keys

The ↑ (UP) and ↓ (DOWN) arrow keys can be used to adjust the analyzer parameters incrementally. The arrow keys are also used to select between files or on a list. These keys are also called step keys.

Viewing Angle

Controls the optimum viewing angle of the display. The viewing angle keys are located next to each other at the upper left-hand corner of the analyzer, bordering the display. These two keys allow you to adjust the intensity of the objects on the display so that it can be optimally viewed from different angles.

The **Viewing Angle** keys automatically repeat when they are held down.

Zoom

Allows you to switch between the split-screen and full-sized display of the active window in zone span and other functions which support split-screen display modes. The active window is indicated by a solid green line surrounding the window.

If **Zoom** is pressed while in a non-split-screen display mode, it will activate the zone span mode. (See **Span**, **Zone**, and also **Next Window**.) If **Zoom** is pressed when zone markers are off, it will turn on zone markers and put the display in split-screen mode. (See **Span**, **Zone**.)

4 Instrument Messages

Instrument Messages Introduction

The analyzer can generate various messages that appear on the display during operation. There are four types of messages.

- **Status Messages**, beginning on [page 329](#), appear on the right side of the analyzer display and/or set status bits in the SCPI Status Register system. These messages indicate a condition that may result in erroneous data being displayed. Most messages will only be displayed until the error condition is corrected. Multiple messages can be displayed and will be listed in the display area. In each case the name of the corresponding status bit is indicated in parenthesis. It will be noted if only a status bit is used (no message).
- **Informational Messages**, beginning on [page 335](#), provide information that requires intervention. These messages appear in the status line at the bottom of the display. If you have a color display and are using the default display colors, the message will appear in green. The message will remain until you preset the analyzer, press **ESC**, or another message is displayed in the status line. The information provided in brackets, for example <filename> or <directory>, is a variable that represents a specific input provided previously.
- **Annunciator Bar Messages**, beginning on [page 341](#), provide Status Message information and appear on the left or right side of the annunciator bar of the analyzer display when running measurements. Some of the messages appear on the left side of the annunciator bar in red and other appear on the right side of the annunciator bar in green. An annunciator bar message may map to several different status messages, and you should check the related status messages to determine the cause of your annunciator message. For more information on status messages, refer to [Status Messages](#) above.
- User **Error Messages**, beginning on [page 292](#), appear when an attempt has been made to set a parameter incorrectly or an operation has failed (such as saving a file). These messages are often generated during remote operation when an invalid programming command has been entered. These messages appear in the status line at the bottom of the display. If you have a color display and are using the default display colors, the message will appear in yellow. The message will remain until you preset the analyzer, press **ESC**, or another message is displayed in the status line. A summary of the last 30 error messages preceded by an error number may be viewed in the Error Queue by pressing, **System** then **Show Errors**. Refer to [Table 4-1](#) for more information on the characteristics of the Error Queue. When a remote interface initiates activity that generates an error, the messages are output to the remote bus. When output to the remote interface, they are preceded by an error number.

When a user error condition occurs in the analyzer as a result of SCPI (remote interface) activity, it is reported to both the front panel display error queue and the SCPI error queue. If it is a result of front panel activity, it reports to the front panel display error queue, and depending on the error, may also report to the SCPI error queue. These two queues are viewed and managed separately.

Table 4-1 Characteristics of the Error Queue

Characteristic	Front Panel Display Error Queue	SCPI Remote Interface Error Queue
Capacity (number of errors)	30	30
Overflow Handling	Circular (rotating). Drops oldest error as new error comes in.	Linear, first-in/first-out. Replaces newest error with: -350, Queue overflow
Viewing Entries	Press: System, Show Errors	Use SCPI query SYSTem:ERRor?
Clearing the Queue	Press: System, Show Errors, Clear Error Queue	Power up. Send a *CLS command. Read last item in the queue.

Note that the error number is displayed under the **System, Show Errors** key sequence.

- Pop-up Messages indicate a condition that may require intervention. They appear in the middle of the display in a framed box. The message will remain until the appropriate intervention has taken place or the condition has been corrected.

Error Message Format


The system-defined error numbers are chosen on an enumerated (“1 of N”) basis. The error messages are listed in numerical order according to the error message number. Status and Informational messages without numbers will be listed in alphabetical order following the numerical listing.

NOTE To see an error *number*, view the error queue as described on [page 289](#).

In this chapter, an explanation is included with each error to further clarify its meaning. The last error described in each class (for example, -400, -300, -200, -100) is a “generic” error. There are also references to the IEEE Standard 488.2-1992, *IEEE Standard Codes, Formats, Protocols and Common Commands for Use with ANSI/IEEE Std 488.1-1987*. New York, NY, 1992.

Error messages are displayed at the bottom of the screen in the status line (yellow on color displays). The error number is available through the remote interface and the show errors screen; it is not displayed in the status line.

Figure 4-1 Error Message Example



pk716b

Error Message Types

Events do not generate more than one type of error. For example, an event that generates a query error will not generate a device-specific, execution, or command error.

-499 to -400: Query Errors

These errors indicate that the analyzer output queue control has detected a problem with the message exchange protocol described in IEEE 488.2, Chapter 6. Errors in this class set the query error bit (bit 2) in the event status register (IEEE 488.2, section 11.5.1). These errors correspond to message exchange protocol errors described in IEEE 488.2, 6.5. In this case:

- Either an attempt is being made to read data from the output queue when no output is either present or pending, or
- data in the output queue has been lost.

-399 to -300: Device-Specific Errors

An error number in the range -399 to -300 indicates that the analyzer has detected an error where some device operations did not properly complete, possibly due to an abnormal hardware or firmware condition. This is not a error in response to a SCPI query or command, or command execution. The occurrence of any error in this class will cause the device-specific error bit (bit 3) in the event status register to be set.

-299 to -200: Execution Errors

These errors indicate that an error has been detected during analyzer execution.

**-199 to -100:
Command Errors** These errors indicate that the analyzer parser detected an IEEE 488.2 syntax error. Errors in this class set the command error bit (bit 5) in the event status register (IEEE 488.2, section 11.5.1). In this case:

- Either an IEEE 488.2 syntax error has been detected by the parser (a control-to-device message was received that is in violation of the IEEE 488.2 standard. Possible violations include a data element which violates device listening formats or whose type is unacceptable to the device.), or
- an unrecognized header was received. These include incorrect device-specific headers and incorrect or unimplemented IEEE 488.2 common commands.

**201 to 799:
Device-Specific
Errors** These errors indicate that a device operation did not properly complete, possibly due to an abnormal hardware or firmware condition. These codes are also used for self-test response errors. Errors in this class set the device-specific error bit (bit 3) in the event status register (IEEE 488.2, section 11.5.1).

The <error_message> string for a positive error is not part of the SCPI standard. A positive error indicates that the analyzer detected an error within the GPIB system, within the analyzer firmware or hardware, during the transfer of block data, or during calibration.

**Greater than
10000:
Measurement
Applications
Errors** These errors indicate that an error has been detected while executing measurements requiring a personality option such as Option BAH, the GSM Measurement Personality or those measurements found under the **MEASURE** front-panel key in Spectrum Analyzer mode.

Instrument Messages

Error Messages

NOTE Error numbers are displayed in the error queue, *not* on the display.
To see an error *number*, view the error queue as described on [page 289](#).

0 No error

The queue is empty. Every error in the queue has been read or the queue was purposely cleared by power-on or *CLS.

-499 to -400: Query Errors

NOTE Error numbers are displayed in the error queue, *not* on the display.
To see an error *number*, view the error queue as described on [page 289](#).

-440 Query UNTERMINATED after indefinite response

Indicates that a query was received in the same program message after a query requesting an indefinite response was executed (see IEEE 488.2, 6.3.7.5).

-430 Query DEADLOCKED

Indicates that a condition causing a DEADLOCKED query error occurred (see IEEE 488.2, 6.3.1.7). For example, both the input buffer and the output buffer are full and the analyzer cannot continue. The analyzer automatically discards output to correct the deadlock.

-420 Query UNTERMINATED

Indicates that a condition causing an UNTERMINATED query error occurred (see IEEE 488.2, 6.3.2.2). For example, the device was addressed to talk and an incomplete program message was received.

-410 Query INTERRUPTED

Indicates that a condition causing an INTERRUPTED query error occurred (see IEEE 488.2, 6.3.2.7). For example, a query was followed by DAB or GET before a response was completely sent.

-400 Query Error

This is a generic query error for devices that cannot detect more specific errors. The code indicates only that a query error as defined in IEEE 488.2, 11.5.1.1.7, and 6.3 has occurred.

-399 to -300: Device-Specific Errors

NOTE Error numbers are displayed in the error queue, *not* on the display.
To see an error *number*, view the error queue as described on [page 289](#).

-310 System error

Indicates that an error, termed “system error” by the device, has occurred.

-300 Device-specific error

This is a generic device-dependent error for devices that cannot detect more specific errors. The code indicates only that a device-dependent error as defined in IEEE 488.2, 11.5.1.1.6 has occurred.

-299 to -200: Execution Errors

NOTE Error numbers are displayed in the error queue, *not* on the display.
To see an error *number*, view the error queue as described on [page 289](#).

-230 Data corrupt or stale.

Possibly invalid data. A new measurement was started but not completed.

-223 Too much data; <description of the type of data exceeded>

Indicates that a legal program data element of block, expression or string type was received that contained more data than the device could handle due to memory or related device-specific requirements.

- 221 Settings conflict; parameter currently disabled
- This parameter is grayed out (unavailable) in the current context. Check the individual parameter help/documentation for more information.
- 200 Execution error
- This is a generic execution error for devices that cannot detect more specific errors. The code indicates only that an execution error as defined in IEEE 488.2, 11.5.1.1.4 has occurred

-199 to -100: Command Errors

NOTE Error numbers are displayed in the error queue, *not* on the display.
To see an error *number*, view the error queue as described on [page 289](#).

- 178 Expression data not allowed
- A legal expression data was encountered, but was not allowed by the device at this point in parsing.
- 171 Invalid expression
- The expression data element was invalid (see IEEE 488.2, 7.7.7.2). For example, unmatched parentheses or an illegal character.
- 170 Expression data error
- This error, as well as errors -171 through -179, is generated when parsing an expression data element. This particular error message is used if the device cannot detect a more specific error.
- 168 Block data not allowed
- A legal block data element was encountered, but not allowed by the device at this point in the parsing.

- 161** Invalid block data
A block data element was expected, but was invalid (see IEEE 488.2, 7.7.6.2). For example, an END message was received before the end length was satisfied.
- 160** Block data error
This error, as well as errors –161 through –169, is generated when parsing a block data element. This particular error message is used if the device cannot detect a more specific error.
- 158** String data not allowed
A string data element was encountered, but not allowed by the device at this point in the parsing.
- 151** Invalid string data
A string data element was expected, but was invalid (see IEEE 488.2, 7.7.5.2). For example, an END message was received before the terminal quote character.
- 150** String data error
This error, as well as errors –151 through –159, is generated when parsing a string data element. This particular error message is used if the device cannot detect a more specific error.
- 148** Character data not allowed
A legal character data element was encountered where prohibited by the device.
- 144** Character data too long
The character data element contains more than twelve characters (see IEEE 488.2, 7.7.1.4).

- 141** Invalid character data
Either the character data element contains an invalid character or the particular element received is not valid for the header.
- 140** Character data error
This error, as well as errors -141 through -149, is generated when parsing a character data element. This particular error message is used if the device cannot detect a more specific error.
- 138** Suffix not allowed
A suffix was encountered after a numeric element which does not allow suffixes.
- 134** Suffix too long
The suffix contained more than twelve characters (see IEEE 488.2, 7.7.3.4).
- 131** Invalid suffix
The suffix does not follow the syntax described in IEEE 488.2, 7.7.3.2, or the suffix is inappropriate for this device.
- 130** Suffix error
This error, as well as errors -131 through -139, is generated when parsing a suffix. This particular error message is used if the device cannot detect a more specific error.
- 128** Numeric data not allowed
A legal numeric data element was received, but the device does not accept one in this position for the header.

- 124 Too many digits
The mantissa of a decimal-numeric data element contained more than 255 digits excluding leading zeros (see IEEE 488.2, 7.7.2.4.1).
- 123 Exponent too large
The magnitude of an exponent was greater than 32000 (see IEEE 488.2, 7.7.2.4.1).
- 121 Invalid character in number
An invalid character for the data type being parsed was encountered. For example, an alpha in a decimal numeric or a “9” in octal data.
- 120 Numeric data error
This error, as well as errors –121 through –129, is generated when parsing a data element which appears to be numeric, including non-decimal numeric types. This particular error message is used if the device cannot detect a more specific error.
- 114 Header suffix out of range
The value of a header suffix attached to a program mnemonic makes the header invalid.
- 113 Undefined header
The header is syntactically correct, but it is undefined for this specific device. For example, *XYZ is not defined for any device.
- 112 Program mnemonic too long
The header contains more than twelve characters (see IEEE 488.2, 7.6.1.4.1).
- 111 Header separator error
A character which is not a legal header separator was encountered while parsing the header.

- 110 Command header error
- An error was detected in the header. This message is used when the device cannot detect the more specific errors described for errors -111 through -119.**
- 109 Missing parameter
- Fewer parameters were received than required for the header. For example, the *ESE common command requires one parameter, so receiving *ESE is not allowed.**
- 108 Parameter not allowed
- More parameters were received than expected for the header. For example, the *ESE common command only accepts one parameter, so receiving *ESE 0,1 is not allowed.**
- 105 GET not allowed
- A Group Execute Trigger was received within a program message (see IEEE 488.2, 7.7). Correct the GPIB controller program so that the GET does not occur within a line of GPIB program code.**
- 104 Data type error
- The parser recognized a data element that is not allowed. For example, numeric or string data was expected, but block data was encountered.**
- 103 Invalid separator
- The parser was expecting a separator and encountered an illegal character. For example, the semicolon was omitted after a program message unit.**
- 102 Syntax error
- An unrecognized command or data type was encountered. For example, a string was received when the device does not accept strings.**

- 101 Invalid character
- A syntactic command contains a character which is invalid for that type. For example, a header containing an ampersand, such as "SETUP&". This error might be used in place of error numbers -114, -121, -141, and some others.
- 100 Command error
- This is a generic syntax error for devices that cannot detect more specific errors. The code indicates only that a command error as defined in IEEE 488.2, 11.5.1.1.4 has occurred.

201 to 799: Device-Specific Errors

NOTE

Error numbers are displayed in the error queue, *not* on the display.
To see an error *number*, view the error queue as described on [page 289](#).

- 201 Option not installed
- The desired operation cannot be performed because a required option is not installed. For example, pressing **Source** with no tracking generator installed in the analyzer will generate this error.
- 202 No peak found
- No signal peak was found.
- 204 TG Frequency Limit
- The tracking generator has reached the limit of its allowable frequency range.
- 205 Command not recognized
- Indicates that the command sent from the remote interface was not recognized. Check the programming guide for correct syntax.

- 206 Unable to initialize flatness data
A failure occurred in setting the flatness data in the internal EEROM. Get in touch with your local Agilent Technologies sales and service office.
- 207 Unable to store flatness data
A failure occurred in setting the flatness data in the internal EEROM. Get in touch with your local Agilent Technologies sales and service office.
- 209 Preselector centering failed
An attempt to center the preselector failed.
- 211 RBW limited to 1 kHz when Span > 5 MHz
In spans greater than 5 MHz, narrow (digital) resolution bandwidths, below 1 kHz, are not available.
- 213 Span limited to 5 MHz when RBW < 1 kHz
In narrow (digital) resolution bandwidths, below 1 kHz, spans greater than 5 MHz are not available.
- 214 TG start freq is less than 9 kHz
Tracking generator uncalibrated below 9 kHz.
- 215 TG start freq is less than 1/2 res bw
Tracking generator uncalibrated at start frequencies below 1/2 the current resolution bandwidth.
- 216 Invalid Baud Rate
Attempt to use invalid baud rate. Refer to the programming language chapter of *Agilent Technologies ESA Series Spectrum Analyzer Programmer's Guide* for more information.

- 217 RS-232 Interface Error
An error occurred on the serial interface.
- 219 Command not valid in this model
Indicates that the command sent from the remote interface does not apply to this model number. For example, attempting to center the preselector in an analyzer without a preselector will generate this error.
- 221 Invalid option, unable to uninstall package
You have attempted to remove a personality that is not currently installed. Verify command was entered correctly.
- 222 Command not valid when no measurement is active
Indicates that the command sent from the remote interface must be issued while a measurement is running in the analyzer.
- 223 Trigger Offset unavailable in swept spans
Trigger Offset is only available in Zero Span. Refer to “Trig” in the Agilent ESA Spectrum Analyzer User’s Guide for a description of this function.
- 224 Option not licensed.
The selected option requires a license. Refer to the installation procedures in the user’s guide available for this particular option.
- 332 Average Type incompatible for scale.
Amplitude Scale command should be sent prior to the Average Type command.
- 601 Floppy disk full
The floppy disk is full. Clear some space by deleting unwanted files.

- 602** Floppy disk error
An unknown error has occurred while accessing the floppy disk.
- 604** File already exists
Attempt to save to a file that already exists. Delete or rename the old file and try again.
- 605** Media is protected
A save was attempted to a write-protected device.
- 606** Media is corrupt
A save was attempted to a corrupt device.
- 607** File Name Error
An invalid file name has been specified. Use filenames with a maximum of 8 characters (letters and digits only) and use a 3 character extension. Note that lowercase and uppercase are perceived as the same. This error will also occur if you attempt to delete a nonexistent file.
- 609** Media is not writable
A save was attempted to a read-only device.
- 610** File access is denied
The file is protected or hidden and cannot be accessed.
- 612** File not found
The analyzer could not find the specified file.
- 613** Flash memory is full
The internal flash memory is full. Clear some space by deleting unwanted files. If your analyzer has a serial number less than US41440000 or MY41440000and

Option B72 has not been installed, you may also increase the flash memory size by purchasing Option B72.

- 614 Bad or missing floppy disk
The floppy is not inserted or the directory could not be read. Insert a known good disk and try again.
- 615 Corrupted file
The file that you were trying to load is corrupt.
- 617 Wrong density floppy inserted
The floppy disk has the wrong density. It should be 1.44 MB.
- 618 Illegal write access of Flash memory
Attempt to write to an unavailable area of internal flash memory.
- 619 Can't Auto-Couple RBW in Zero Span
You sent a remote command to set the RBW into auto while in zero span. (Remote interface only.)
- 620 Can't Auto-Couple Sweep Time in Zero Span
You sent a remote command to set the sweep time to auto while in zero span. (Remote interface only.)
- 651 Connect RF OUT to INPUT
Attempt to align the tracking generator without its output connected. Connect the tracking generator RF OUT to the analyzer INPUT.
- 652 Connect Amptd Ref Output to Input
For Agilent Technologies E4402B, E4403B, E4404B, E4405B, E4407B, and E4408B only: you must connect the AMPTD REF OUTPUT to the analyzer INPUT with the appropriate cable.

- 653 Auto Align not available when using Calibration Defaults
- The Auto Alignment system cannot be used until an **Align Now All** is executed by pressing **System, Alignments, Align Now, All**. On all Agilent Technologies ESA spectrum analyzer models except Agilent Technologies E4401B and E4411B, you must connect the **AMPTD REF OUT** to the **INPUT** with the appropriate cable to perform this alignment. *For Agilent Technologies E4401B and E4411B only:* disconnect any signals from the **INPUT** prior to performing this procedure.
- 701 Invalid printer response
- In attempting to identify the printer an invalid response was received. Check that you are using a supported printer. Be sure you are using the proper cable and that it is securely fastened.
- 702 Unsupported printer
- A printer which is recognized, but known to be unsupported was identified. This printer cannot be used with the analyzer. For example, a printer only supported by Microsoft Windows will generate this error.
- 703 Unknown printer
- In attempting to identify the printer, a valid response was received but the printer is not known to the analyzer. Use the **Custom** printer menu under **Print Setup** to configure the printer.
- 704 Printer interface error
- An error occurred while trying to print. Make sure the printer is turned on and properly connected.
- 705 Printer Type is None
- The current printer type is set to **None**, so no print operations are possible. Change the type in the **Print Setup** menu and try again.

- 727 In <filename>: [DATA] header missing
This message indicates that the data section of a file did not begin with the token [DATA].
- 728 In <filename>, line <nnn>: separator missing
The [HEADER] section of a file contains entries requiring an equal (=) sign, such as <keyword> = <value>. This message appears if the equal sign does not appear on the line.
- 729 In <filename>: error reading file
Appears when loading data from a limit line or corrections disk file and a failure to the file occurs.
- 730 In <filename>, line <numeric_value>: line too long
When loading data from a limit line or corrections disk file, this message will appear if the length of any line in the file exceeds 255 characters.
- 731 In <command>: bad data count (<numeric_value>): expected multiple of <numeric_value>
This message indicates that the data sent to a corrections or limit table via the **DATA** or **MERGE** commands does not have the expected length for the table. For example, this message would appear if an attempt were made to merge 7 numeric values into a limit table, since each logical entry requires 3 values (frequency, amplitude, and connected).
- 732 In <filename>, line <numeric_value>: error parsing tokens
This message may appear when loading data from a limit line or corrections disk file. It indicates a problem in the attempt to break a string of text into tokens. There may be too few tokens in the string. In other words, the file content must match the expected format. This typically happens when there are too few numeric values in the [DATA] section of a limit or corrections file.

733 In <filename>, line <numeric_value>: <xxx> is not numeric

This message may appear when loading data from a limit line or corrections disk file. It indicates that a non-numeric token <xxx> was found where a numeric token was expected. In other words, the file content must match the expected format.

734 Interpolation error: cannot compute log of <negative_frequency_value>

Occurs when the frequency interpolation of a limit line is set to log and the start frequency of the instrument is negative. The <negative_frequency_value> is limited to - 80 MHz, so it may not match the frequency that caused the error.

735 In <filename>: bad amplitude unit <unit>

This message indicates that unit <unit> is not recognized or supported.

736 Too many data values at <freq_or_time_value>

This message may appear when data is sent to a corrections or limit table using the **DATA or **MERGE** commands. These tables limit the number of amplitudes associated with a frequency or time to 2 or less. This message will appear if an attempt is made to attach 3 or more values to a frequency or time.**

751 Instrument state may be corrupt, state has been reset to initial values

An error in the internal instrument state has been detected. The state has been reset to a default value.

752 Unable to load state from file

Loading of state from a file failed.

753 Unable to save state to file

Saving of state to a file failed.

- 755 Unable to load state from register
Loading a state from an internal state register failed.
- 756 Unable to save state to register
Saving of state to an internal register failed.
- 757 Unable to load user state, factory preset was done
An attempt to perform a User Preset failed, so the Factory Preset values were used. Save a valid state into User Preset and try again.
- 758 Unable to save user state
An attempt to save to the User Preset state failed.
- 759 Unable to load state
A saved state file from a newer firmware revision was attempted to be loaded into an older instrument.
- 760 Unable to query state
Query of state over the remote interface was unsuccessful.
- 761 Unable to set state
Attempt to set the state over the remote interface was unsuccessful.
- 762 Incorrect filename, allowable extensions are .trc or .csv
Attempt to save a trace to a file with an incorrect extension.
- 762 Unable to load file
A failure occurred while loading a file; the file was not loaded.

- 763 Incorrect filename, allowable extensions are .gif or .wmf
Attempt to save a screen image to a file with an incorrect extension.
- 764 Unable to save file
A failure occurred while saving a file; the file was not saved.
- 769 Invalid instrument mode
You have attempted to switch to an instrument mode that is currently not installed. Confirm that the mode name (for INST:SEL) or number (for INST:NSEL) was entered correctly and that the requested personality is actually installed in the instrument.
- 770 Instrument mode requested is not supported
Instrument mode specified with: INST command is not valid. Refer to Chapter 5, “Instrument Subsystem” of *Agilent Technologies ESA Series Spectrum Analyzer Programmer’s Guide* for more information.
- 771 Store Ref trace before turning on Normalize
A reference trace must be available for the Normalize function to be activated. Refer to “View/Trace” in the Agilent ESA Spectrum Analyzer User’s Guide where the **Normalize key function is explained in detail.**
- 772 Cannot load a directory, please choose a file
You have selected a directory instead of a file when attempting to perform the Load function under the **File front-panel key.**

Greater than 10000: Measurement Applications Errors

NOTE

Error numbers are displayed in the error queue, *not* on the display.

To see an error *number*, view the error queue as described on [page 289](#).

- 10010** One or more harmonics beyond freq limit:
number decreased.

Highest harmonic was past the frequency limit of the analyzer, so the number of measured harmonics was decreased.
- 10011** Second harmonic is beyond analyzer frequency limit.

The frequency range of your analyzer does not include the first multiple of the captured fundamental frequency in internal mixing.
- 10012** No Fundamental > 0 Hz found in given span.

There were no frequencies greater than 0 Hz in the starting span, so the measurement was stopped.
- 10013** No Fundamental > -50 dBm found in given span.

A fundamental was not found, so the measurement was stopped.
- 10138** Valid GSM burst not found in frame (Burst Type).

No active GSM bursts that match the selected Burst Type have been detected in the RF input signal. The search was performed over the complete GSM frame.
- 10139** Valid GSM burst not found in specified timeslot (Burst Type).

No active GSM bursts that match the selected Burst Type have been detected in the RF input signal. The search was only performed over the specified timeslot setting.

- 10140** Valid GSM burst not found in frame (Ref Burst).
No active GSM bursts that match the selected Burst Type have been detected in the RF input signal. The search was performed using the Ref Burst type setting over the complete GSM frame.
- 10141** Sync word not found in frame (Burst Type)
One or more active GSM bursts that match the selected Burst Type have been detected in the RF Input signal, but none contain the selected Training Sequence Code (TSC). The search was performed over the complete GSM frame.
- 10142** Sync word not found in specified timeslot (Burst Type)
One or more active GSM bursts that match the selected Burst Type have been detected in the RF Input signal, but none contain the selected Training Sequence Code (TSC). The search was only performed over the specified timeslot setting.
- 10143** Sync word not found in frame (Ref Burst)
One or more active GSM bursts that match the selected Burst Type have been detected in the RF Input signal, but none contain the selected Training Sequence Code (TSC). The search was only performed using the Reference Burst type and Reference TSC settings over the complete GSM frame.
- 10144** Unknown demod status.
Demodulation is in an unknown state. Press **Preset. If the error persists, get in touch with your service center.**
- 10145** Opt AYX hardware required. Meas unavailable.
Option AYX must be installed for this measurement to be enabled.

- 10146** Opt B7D & B7E hardware required. Meas unavailable.
The RF Communications Hardware (Option B7E) and Digital Signal Fast ADC (Option B7D) cards required to perform the demodulation are not present in the analyzer.
- 10147** Opt B7D bootrom requires upgrade.
The (Option B7D) bootrom revision is not supported by the currently loaded personality version. Refer to the user's guide for the personality in use.
- 10148** Opt BAH DSP algorithm files not installed. Meas unavailable.
The Digital Signal Processor algorithm files required to perform the demodulation are not present in the analyzer.
- 10149** Opt BAH DSP algorithm code file requires upgrade.
The Digital Signal Processing algorithm code file revision is not supported by the currently loaded personality version. Refer to the user's guide for the personality in use for more information on installation/upgrade.
- 10150** Opt BAH DSP algorithm coef. file requires upgrade.
The Digital Signal Processor algorithm coefficient file revision is not supported by the currently loaded personality version. Refer to the user's guide for the personality in use.
- 10151** Opt BAH DSP algorithm files failed to load, aborting measure.
The Digital Signal Processor algorithm files required to perform the demodulation are corrupt and cannot be loaded properly. Reinstall measurement personality.

- 10152** Lost trigger, aborting measurement.
The selected trigger source was present at the start of the measurement, but timed out before the measurement completed.
- 10153** DSP algorithm timeout, aborting measurement
The Digital Signal Processor demodulation algorithm timed-out for an unknown reason. This message normally indicates a problem with the modulated signal.
- 10154** Measurement not defined for Out of Band.
You have changed to an out-of-band frequency range. The band measurement only operates in the selected band.
- 10155** No Fast ADC hardware installed. Meas unavailable.
The analyzer cannot use sweep times of less than 5 msec when Option B7D or Option AXX is not installed. Therefore the measurement will not be executed.
- 10156** No Fast ADC hardware installed.
The analyzer cannot use sweep times of less than 5 msec when Option B7D or Option AXX is not installed resulting in all the radio standards not being supported.
- 10157** Tracking Generator hardware is not present. Meas unavailable.
The measurement requires a built-in tracking generator.
- 10159** Entire trace is below threshold level
The measurement cannot operate properly because the trace has completely fallen below the threshold level. Change the threshold level to view trace.

- 10160** Upper Custom Mask is Invalid!
The user-specified upper custom mask cannot be resolved into a limit line. The format is incorrect.
- 10161** Lower Custom Mask is Invalid!
The user-specified lower custom mask cannot be resolved into a limit line.
- 10162** Resolution BW <300 kHz.
This error message is a warning that the resolution bandwidth has been set below 300 kHz. The test results will not meet GSM specifications.
- 10163** Cannot find the Power vs Time Limits File.
The limit line definition file for the GSM standards has been deleted. This message is displayed while the **Measure key is grayed out. Reinstall the GSM measurement personality.**
- 10164** Band Measurement not defined for Out of Band.
You are attempting to monitor the band but have set the frequency outside the band. Reset the band for the particular standard for which you are testing or use the channel setting which does not require a frequency to be set. (Meas Setup, Method (Channel)**).**
- 10166** Cannot update the list of cable types.
The cable file may have been moved or deleted accidentally. Reinstall the measurement personality. This message is applicable to the GSM (Option BAH) and Distance to Fault (Option 226) measurement personality options.
- 10168** Cannot update the list of cable types on drive C:
The file update failed.

- 10170 The Cable Fault Measurement is active. Mode Setup is disabled.
Mode setup is not available in the cable fault utility.
- 10172 Sweep Time too fast (<2 sec)
The sweep time must be set to 2 seconds or longer for the results to be valid.
- 10177 There are no spurs to inspect.
You have attempted to switch the **Inspect Spur softkey to the **On** position after the measurement has finished, but found no spurs.**
- 10179 Carrier Present. Test Stopped!
A carrier was found in the transmit band. Either disable the carrier or insert a bandpass filter for the receive bandwidth.
- 10180 Gate option not installed. Results may not be accurate.
This measurement method requires the use of the time-gate (option 1D6) in order to gate the spectrum during the 50-90% part of the burst. If the gate option is not installed, the measurement will still run although this warning will be displayed.
- 10186 Measurement does not support the current radio standard.
The measurement you have chosen is currently greyed out. Select a radio standard which is supported (Mode Setup, Radio Std**) or configure the measurement manually.**
- 10187 Radio standard is not supported by the current measurement.
The standard you have chosen is currently greyed out. Select a radio standard which is supported by the current measurement (Mode Setup, Radio Std**) or configure the measurement manually.**

- 10218 Hardkeys are disabled.
- Some of the forms (for example Receiver Spurious in GSM) do not allow you to close the form without either formally accepting or cancelling the form settings. For this reason, all of the hardkeys are disabled until you terminate the form.
- 10219 Awaiting trigger
- The measurement requires a trigger to be present. If the trigger does not occur or is delayed, this message will be displayed. Check your trigger settings.
- 10227 Measurement suspended until carrier is turned off.
- The receive channel power and the receive spur measurements are specified with the attenuation set to 0 dB. To prevent overload, the frequency spectrum of interest is monitored for signal levels which exceed a specified threshold before setting the attenuator to 0 dB. If a carrier is found, this message is displayed and the completion of the measurement will not occur until the carrier is removed. The carrier check may be turned off using the properties form under the front-panel **Mode Setup** key. You may also change the signal threshold which determines a carrier on the properties form.
- 10228 Cannot correlate to input signal.
- This error is normally generated because of one of the following reasons:
1. There is no carrier signal.
 2. Walsh channels other than the pilot are active.
 3. There is some other modulation problem that will prevent the measurement from being made.
- This problem must be corrected before the measurement can continue.
- 10229 The regression portion failed.
- This message occurs when (Option B7D) is not functioning properly. Demodulation measurements (modulation accuracy and code domain) might fail as a result of this error.

- 10230** DSP timed out, resetting DSP.
Digital Signal Processor was unable to finish the selected measurement within the given period of time. Restart the measurement.
- 10231** Measurement failed for unknown reasons.
Check instrument settings and restart measurement.
- 10232** RF Signal not found.
This message is generated if there is no signal at the center frequency that is greater than 10 dB above the displayed average noise level.
- 10233** Level is low, results may degrade.
The signal being measured is of low power. The results may not be as accurate as they would be if the signal level was higher.
- 10237** RF Board LO Unlocked. Contact service center.
This message occurs if the local oscillator on the (Option B7E) is in an unlocked state. This indicates broken hardware.
- 10238** RF Board SR Osc Unlocked. Contact service center.
This message occurs if the sample rate (SR) oscillator on Option B7E is in an unlocked state. This indicates broken hardware.
- 10239** Opt Freq Ref setting does not match external reference.
This message is generated if Source is set to External on the properties form under the front-panel **Mode Setup key and the frequency on the same form is set to a frequency that does not match the frequency of the signal being used as the external reference.**

- 10240** RF Board RF Osc Unlocked. Contact service center.
- This message occurs if the reference oscillator on the (Option B7E) is in an unlocked state. This indicates broken hardware.**
- 10241** RF Board could not detect any bursts in signal.
- This message is generated when the trigger is set to RF Burst and (Option B7E) cannot detect a burst.**
- 10245** Error reading file: SPCLIMIT.CSV. Cannot use custom limits.
- The file could be missing or corrupt. Create a new limits file. Alternatively, the actual limits defined in the file might not allow the measurement to be executed. Redefine the limits or use the default limits. Restart the measurement.**
- 10246** Error reading file: CDMASTUN.CSV. Please reinstall cdmaOne.
- The file is missing or corrupt. Please reinstall the cdmaOne personality.**
- 10247** Error reading file: CDPMDA. Please reinstall cdmaOne.
- The file is missing or corrupt. Please reinstall the cdmaOne personality.**
- 10248** Error reading file: CDPPMCO. Please reinstall cdmaOne.
- The file is missing or corrupt. Please reinstall the cdmaOne personality.**
- 10249** Error reading file: CDPPMDA. Please reinstall cdmaOne.
- The file is missing or corrupt. Please reinstall the cdmaOne personality.**

10250 Error reading file: RHODMDA. Please reinstall cdmaOne.

The file is missing or corrupt. Please reinstall the cdmaOne personality.

10251 Error reading file: RHOPMCO. Please reinstall cdmaOne.

The file is missing or corrupt. Please reinstall the cdmaOne personality.

10256 Error reading file: OOBSTAB.CSV. Use Edit Table | Save Table.

This error is generated when you try to load a table (using the **Load Table** key on page 2 of the edit table form menu) before a table has been saved. You must first save a table using the **Save Table** key before trying to load a table using the **Load Table** key.

10259 Table could not be saved.

This message occurs if the C: drive is full or corrupt. Check the amount of space left on the drive.

10260 Table could not be loaded.

When trying to load a table, the previous table has been somehow corrupted. Use the **Save Table** key to save a valid table. Then edit the valid table, save it, and try to load it again.

10264 Emission bandwidth not found. Consider increasing span.

This error is normally generated when attempting occupied bandwidth measurements. The "X dB" value you entered (**Meas Setup, X dB**) to calculate the emission bandwidth is the difference between the highest point on the trace and the point "X dB" down on either side of the maximum. If the actual difference is less than the value entered, the emission bandwidth cannot be computed. Some responses to this situation are as follows:

1. Connect a signal to the input. (If there is no signal present, the difference between the trace minimum and maximum will generally be less than “X dB”.)
2. Increase the span. (If the signal is wide, the shoulders of the signal might not be present on the screen, and again, the difference between the trace minimum and maximum will be less than “X dB”.)
3. Center the signal. (There must be a point on the trace that is “X dB” down from the maximum on both sides of that maximum.)

- 10286** Burst not found.

The signal being analyzed has insufficient power, the rising or falling edges cannot be detected, or the burst is less than 120 microseconds.
- 10287** Valid Bluetooth burst not found. (Check Packet Type)

The burst that has been found does not correspond to the currently selected Bluetooth™ packet type (the burst length may be too short).
- 10288** Opt B7D or AYX FADC hardware required. Meas unavailable.

The measurement you are attempting requires either the DSP and Fast ADC (Option B7D) or the Fast ADC (Option AYX) card to perform the demodulation, but neither are present in the analyzer.
- 10289** Opt 106 demod hardware required. Meas unavailable.

A demod measurement was attempted with no Bluetooth™ FM demod card present (Option 106).
- 10290** Parameter unavailable in demod measurements.

You have selected (by remote SCPI command) either RF Amplitude sync or Video trigger while running one of the demod measurements.

- 10291** Opt B7E RF hardware required. RF Burst unavailable.
You have selected (by remote SCPI command) RF Burst Trigger with no digital demodulation RF card present (RF Communications Hardware (Option B7E)).
- 10320** Opt 106 hardware required. Preamble sync unavailable.
You have selected (by remote SCPI command) preamble sync with no Bluetooth™ FM demodulation card present (Option 106).
- 10321** Start Marker must be at least 1% < Stop Marker.
You have attempted to input a start marker value that will result in the difference between the start and stop markers being less than 1%.
- 10322** Stop Marker must be at least 1% > Start Marker.
You have attempted to input a stop marker value that will result in the difference between the start and stop markers being less than 1%.
- 10323** Unable to Calculate Result using Current Setup.
You have changed the setup parameters such that the marker lines used to measure the power cannot be displayed therefore accurate measurements cannot be made.
- 10340** '10101010' pattern not detected - results may be inaccurate.
This message is displayed if the measurement cannot detect the '10101010' pattern in the payload. The measurement will continue and carry out the calculations on the payload data supplied, but may not be correct.

- 10350** Payload data pattern '10101010' not present.
This message is displayed when the “Payload Data” parameter is set to Auto and the measurement has not detected either of the required patterns in the payload.
- 10351** Required payload data pattern '10101010' not present.
This message is displayed after successfully measuring and holding the '11110000' pattern if the measurement is restarted and the '10101010' data pattern is not detected.
- 10352** Required payload data pattern '11110000' not present.
This message is displayed after successfully measuring and holding the '10101010' pattern if the measurement is restarted and the '11110000' data pattern is not detected.
- 10353** There is no valid result to hold.
You have attempted to hold either $\Delta f1$ or $\Delta f2$ before it has been measured.
- 10360** Can't compute result - not enough transitions.
This message is displayed when the measurement cannot find either a 111, 000, 101 or 010 pattern and is therefore unable to calculate the low or high frequency deviations.
- 10400** Valid signal not found.
This error is normally generated because of one of the following reasons:
- 1. There is no carrier signal.**
 - 2. The carrier signal power has changed during the measurement, causing ADC to over/under range.**
 - 3. There is some other modulation problem that will prevent the measurement from being made. This problem must be corrected before the measurement can continue.**

- 10401** Valid burst not found in frame (Burst Type).
No active bursts that match the Burst Type have been detected in the RF input signal. The search was performed over the complete frame.
- 10402** Valid burst not found in specified timeslot (Burst Type).
No active bursts that match the Burst Type have been detected in the RF input signal. The search was only performed over the specified timeslot setting.
- 10403** Sync word not found in frame (TSC).
One or more active EDGE bursts that match the Normal Burst Type have been detected in the RF Input signal, but none contain the selected Training Sequence Code (TSC). The search was performed over the complete EDGE frame.
- 10404** Sync word not found in specified timeslot (TSC).
One or more active EDGE bursts that match the Normal Burst Type have been detected in the RF Input signal, but none contain the selected Training Sequence Code (TSC). The search was only performed over the specified timeslot setting.
- 10409** Wideband calibration not valid until Align Now, All performed.
Wideband calibration corrections cannot be applied to current demodulation results. Results will not meet specified demodulation performance levels until an Align Now, All has been performed.
- 10410** Measurement uncalibrated, wideband calibration required.
Wideband calibration corrections cannot be applied to the current demodulation results. Results will not meet specified demodulation performance levels until **Wideband Cal has been selected and successfully performed.**

- 10411** Measurement uncalibrated, symbol rate exceeds +/-10% nominal.
Wideband calibration corrections cannot be applied to current demodulation results, due to the **Symbol Rate setting exceeding +/-10% of the nominal value. Results may not meet specified demodulation performance levels.**
- 10412** Cal Data corrupt. Wideband cal failed. Using previous data.
Wideband calibration procedure failed for an unknown reason. New calibration data was not saved. Previous wideband calibration data is being used, if available. However, it is not acceptable. Before re-attempting Wideband Cal, ensure connection between the **AMPTD REF OUT and the **INPUT 50 Ω** is in place. If the error persists, get in touch with your service center.**
- 10413** B7D DSP Code Install Fail Opt.229.Contact your Service Center.
The Digital Signal Processor algorithm files required to perform the demodulation are not present in the analyzer. Reinstall the measurement personality and contact your service center.
- 10414** Opt 229 DSP algorithm code file requires upgrade.
The Digital Signal Processing algorithm code file revision is not supported by the currently loaded personality version. Refer to the user's guide for the personality in use for more information on installation/upgrade.
- 10415** Opt 229 DSP algorithm coef. file requires upgrade.
The Digital Signal Processor algorithm coefficient file revision is not supported by the currently loaded personality version. Refer to the user's guide for the personality in use for more information on installation/upgrade.

- 10416** B7D DSP Code Reload Fail Opt.229.Contact your Service Center.
- The Digital Signal Processor algorithm files required to perform the demodulation are corrupt and cannot be loaded properly. Reinstall the measurement personality and contact your service center.**
- 10417** This operation requires a measurement to be active.
- The analyzer cannot perform this operation, because it requires a measurement to be running and no measurement is running.**
- 10418** Demod Format setting does not allow this value for Points/Symbol.
- Invalid Points/Symbol selection attempted for the given Demod Format setting.**
- 10419** Carrier Not Present.
- A carrier signal/burst is expected at the analyzer input. This signal cannot be found; however, the measurement will still run. Check input signal connection.**
- 10420** Valid burst not found.
- This error only occurs when RF Amptd is selected for Burst Sync. It indicates that a valid burst envelope which meets the specified Burst Search Threshold was not found within the specified Burst Search Length. Note that the demodulation measurement will proceed by attempting to demodulate the signal without Burst Sync alignment. Possible causes may be:**
- 1. Carrier signal is not actually bursted.**
 - 2. Burst Search Threshold and/or Burst Search Length may need to be adjusted.**
- 10421** Cannot lock to carrier.
- This error only occurs when attempting to demodulate OFFSET QPSK signals. It indicates that the demodulation algorithm is unable to lock to your signal. Possible causes may be:**

1. There is no carrier signal.
2. Carrier signal is present, but Demod settings do not match the modulation format of the OFFSET QPSK signal being measured.
3. OFFSET QPSK signal is too noisy to achieve carrier lock.

10425 B7D DSP Code Install Fail Opt.231.Contact your Service Center.

The Digital Signal Processor algorithm files required to for the 89600 VSA SW are not present in the analyzer. Reinstall the measurement personality and contact your service center.

10426 Opt 231 DSP algorithm code file requires upgrade.

The Digital Signal Processing algorithm code file revision is not supported by the currently loaded personality version. Refer to the user's guide for the personality in use for more information on installation/upgrade.

10427 Opt 231 DSP algorithm coef. file requires upgrade.

The Digital Signal Processor algorithm coefficient file revision is not supported by the currently loaded personality version. Refer to the user's guide for the personality in use for more information on installation/upgrade.

10428 B7D DSP Code Reload Fail. Opt.231.Contact your Service Center.

The Digital Signal Processor algorithm files required for the 89600 VSA SW are corrupt and cannot be loaded properly. Reinstall the measurement personality and contact your service center.

10450 Avg Mode changed to Repeat for Full Meas Type.

Avg Mode and Meas Type are coupled. Selecting Full Meas Type forces Repeat Avg Mode.

- 10451 Avg Mode changed to Exp for Examine Meas Type.
Avg Mode and Meas Type are coupled. Selecting Examine Meas Type forces Exp Avg Mode.
- 10452 Meas Type changed to Examine for Exp Avg Mode.
Avg Mode and Meas Type are coupled. Selecting Exp Avg Mode forces Examine Meas Type.
- 10453 Meas Type changed to Full for Repeat Avg Mode.
Avg Mode and Meas Type are coupled. Selecting Repeat Avg Mode forces Full Meas Type.
- 10511 100 spurs found. Additional spurs ignored.
The maximum number of spurs have been found. Any additional spurs found during this measurement will not be logged.
- 10512 No spurs have been found.
There were no spurs found using the current range setup.
- 10513 No ranges are defined.
All ranges are currently set to off.
- 10524 This measurement does not support the *.CSV file format.
You cannot load CSV format trace files or save traces in the CSV format in the Log Plot measurement of the Phase Noise Measurement Personality.
- 10525 Use View/Trace menu when loading or saving logarithmic traces.
You cannot load CSV format trace files or save traces in the CSV format in the Log Plot measurement of the Phase Noise Measurement Personality.

- 10526** Cannot display Trace because it contains no data.

Reference trace cannot be displayed, as there is currently no data assigned to it - use the functions under the Store Ref Trace menu, or load a trace to assign some data.
- 10527** Invalid Marker Trace.

Cannot place markers on the reference trace, because the reference trace is currently turned off or has no data.
- 10529** Failed to Load trace. Bad file format.

The load trace operation could not be completed, as the input file was not in the expected format. You can only load traces that were previously saved using the 'Save Trace' feature.
- 10530** Trace file contains no compatible traces.

The trace file may have been created by another version of the Phase Noise personality, which uses a different trace format that is incompatible with the version you are running. Please check you are running the most up to date version of the personality.
- 10531** Trace file was created by incompatible version of Opt. 226

The trace file may have been created by another version of the Phase Noise personality, which uses a different trace format that is incompatible with the version you are running. Please check you are running the most up to date version of the personality.
- 10532** Cannot open trace file for writing. Save Failed.

Cannot write the trace file to the destination filename. This could be because the disk is full, or possibly due to a filename error. If using a floppy disk, check there is a formatted disk in the drive.

- 10533** Cannot save Trace because it contains no data.
Check the Ref Trace is turned on, and contains some valid trace data.
- 10534** Trace file saved successfully.
The trace saving operation was successful.
- 10535** Cancellation trace is not set to Reference or has no data.
When performing phase noise cancellation, you need to supply a reference trace that will be used to cancel out the background noise of the analyzer. The reference trace must be in Reference (View) mode, and selected by the Ref Trace parameter under the Cancellation menu.
- 10536** Cancellation disabled while measuring DANL Floor.
Phase Noise cancellation does not make sense when measuring the DANL Floor, so for this reason it has been disabled.
- 10537** 10537 Cancellation trace has different X-Scale to Smoothed trace.
When performing phase noise cancellation, you need to supply a reference trace that will be used to cancel out the background noise of the analyzer. The reference trace must have been measured over the same range of offsets, and on the same instrument as the current measurement being performed.
- 10560** Carrier Not Present. Verify frequency and amplitude settings.
No Carrier > -50 dBm found at the analyzer input within the search span. Solution: Modify center frequency to be closer to actual carrier, or alternatively apply carrier of sufficient amplitude at the current center frequency.

10561 Signal Tracking disabled when measuring DANL Floor (Removal).

Measuring the DANL Floor with DANL Method set to Removal requires that the user remove the signal and attach a load to the analyzer RF Input. Signal Tracking requires that the carrier be measured many times per measurement, so the two are inherently incompatible.

Instrument Messages without Numbers

Error Messages

Unable to uninstall personality, file not deletable.

This message occurs when you try to delete a personality which has been marked as non-deletable. The personality is marked non-deletable at the factory. Get in touch with your nearest service center for further assistance.

Status Messages

Status * (Invalid Data)

This indicator is displayed when data on the screen may not match the screen annotation, for example while analyzer settings are changing or when any trace is in view mode.

Status 50 MHz Osc Unlevel (50 MHz Osc Unleveled)

The internal 50 MHz amplitude reference source has become unlevelled. This condition must be corrected before a valid alignment can be performed.

Status (ADC Align Failure)

A status bit only, no message. The alignment routine was unable to align the analog-to-digital converter (ADC).

Status Align Now All Needed (Align Needed)

The instrument requires complete alignment. Press **System, Alignments, Align Now, All**. On all Agilent Technologies ESA spectrum analyzer models except Agilent Technologies E4401B and E4411B, you must connect the **AMPTD REF OUT** to the **INPUT** with the appropriate cable to perform this alignment. *For Agilent Technologies E4401B and E4411B only:* disconnect any signals from the **INPUT** prior to performing this procedure. If this message recurs, load defaults (**System, Alignments, Load Defaults**) and then perform **Alignment Now, All**.

Status Align Now RF Needed (Align Now RF Needed)

The instrument requires RF alignment. Press **System, Alignments, Align Now, RF (EXT Cable)**. On all Agilent Technologies ESA spectrum analyzer models except Agilent Technologies E4401B and E4411B, you must connect the **AMPTD REF OUT** to the **INPUT** with the appropriate cable to perform this alignment. *For Agilent Technologies E4401B and E4411B only:* disconnect any signals from the **INPUT** prior to performing this procedure.

Status Align RF Skipped (Align RF Skipped)

The RF alignment has been skipped because a 50 MHz signal was detected at the **INPUT**; alignment will resume when the 50 MHz signal is removed. The alignment will not work when there is too much input power at 50 MHz. The instrument may not continue to measure properly. To remove the message, remove the 50 MHz input signal, then perform an **Align Now, RF**. Press **System, Alignments, Align Now, RF**. On all Agilent Technologies ESA spectrum analyzer models except E4401B and E4411B, you must connect the **AMPTD REF OUT** to the **INPUT** with the appropriate cable to perform this alignment. *For Agilent Technologies E4401B and E4411B only:* disconnect any signals from the **INPUT** prior to performing this procedure.

If this message occurs and you are going to make a measurement near 50 MHz, select **System, Alignments, Auto Align**, and **All but RF**.

Status	DC Coupled Indicates the input of the analyzer is DC coupled (Input/Output, Coupling (DC)). This setting is necessary when measuring frequencies below 100 kHz on E4402B with Option UKB, E4404B, and E4405B analyzers. For E4407B analyzers with Option UKB, you must set the coupling to DC when measuring below 10 MHz. Take care to limit the input level to 0 Vdc and +30 dBm whenever you are in DC coupled mode.
Status	Demod ON: reduce span for audible detection When the Demod function is active and the speaker is turned on, the ratio of the resolution bandwidth to span must be greater than 0.002 to properly demodulate and listen to the resulting audio signal. You must decrease the span to continue the measurement
Status	Ext Ref (no corresponding status bit) Indicates that the frequency reference is being supplied by an external 10 MHz source.
Status	Flat corr off (no corresponding status bit) Indicates that the flatness corrections have been turned off.
Status	(FM Demod Align Failure) status bit only, no message A failure has occurred during the FM Demod alignment. Measurement results may be invalid.
Status	Freq corr off (no corresponding status bit) Indicates that the frequency corrections have been manually disabled. Press System, Alignments, Freq Correct, (On) to restore.
Status	Frequency Reference Error (Freq Ref Unlocked) The frequency reference has been tuned too far off of 10 MHz. This condition may be corrected by cycling power on the analyzer.

Status (IF Align Failure) status bit only, no message
A failure has occurred during the IF alignment. Measurement results may be invalid.

Status IF Gain fixed
The autoranging function of the analyzer has been turned off (**Amplitude, More, More, IF Gain (Fixed)**). This setting is useful when measuring signals that require fast measurement time, narrow resolution bandwidths (< 1 kHz), and < 70 dB of display range. For more information on this setting, refer to IF Gain key description in the *ESA Spectrum Analyzer User's Guide*.

Status IF Overload (IF/ADC Over Range)
The IF section has been overloaded. Measurement results may be invalid.

Status Input is internal (no corresponding status bit)
This message applies to the Agilent Technologies E4401B and E4411B only. Indicates the **50 MHz Amptd Ref** selection is **On**. With the 50 MHz amplitude reference on, the input is routed through an internal signal path.

Status (LO Align Failure) status bit only, no message
A failure has occurred during the alignment of the local oscillator (LO). Measurement results may be invalid.

Status LO Out Unlevel (LO Out Unleveled)
Indicates the output of the local oscillator (LO) has become unlevelled. This condition must be corrected to make valid measurements.

Status LO Unlevel (LO Unleveled)
Indicates the internal circuitry of the local oscillator (LO) has become unlevelled. This condition must be corrected to make valid measurements.

Status	LO Unlock (Synth Unlocked) Indicates the phase locked circuitry of the local oscillator (LO) has become unlocked. This condition must be corrected to make valid measurements.
Status	Log Corr Off (no corresponding status bit) The log amplifier corrections have been turned off.
Status	Marker Count:Widen Res BW The ratio of the resolution bandwidth to span must be greater than 0.002 for the marker count function to work properly. Increase the resolution bandwidth or decrease the span to continue the measurement.
Status	Meas Uncal (Oversweep) The measurement is uncalibrated. Check the sweep time, span and bandwidth settings, or press Auto Couple and Auto All .
Status	Overload: Reduce Signal and press <ESC> (Input Overload Tripped) <i>This message applies to the Agilent Technologies E4401B and E4411B only.</i> A signal has been applied to the input connector that caused the overload protection circuitry to engage. The input signal must be reduced. After the signal is reduced, press ESC to reset the overload detector so that you can continue using the analyzer.

CAUTION

Exposing the analyzer to high levels of input power over a prolonged period of time can damage the internal circuitry.

Status	Peaking Signal (no corresponding status bit) The instrument is executing a tracking generator peak.
Status	Preferred resolution bandwidth not available. The calculated required resolution bandwidth for this measurement is not available.

Status (RF Align Failure) status bit only, no message
A failure has occurred during the alignment of the RF section. Measurement results may be invalid.

Status Signal Ident On, Amptd Uncal (Signal Ident On)
Indicates that the amplitude measurement could be uncalibrated because the signal identification feature is on.

Status Signal level is low.
Indicates the signal can be correlated, however the level is below that specified to ensure accurate measurement results.

Status Source LO Unlevel (Source LO Unleveled)
The internal circuitry of the local oscillator (LO) in the tracking generator has become unlevelled. This condition must be corrected to make valid measurements.

Status Source LO Unlock (Source Synth Unlocked)
The phase-locked circuitry of the local oscillator (LO) in the tracking generator has become unlocked. This condition must be corrected to make valid measurements.

Status Source Unlevel (Source Unleveled)
Indicates the source power is set higher or lower than the analyzer can provide, the frequency span extends beyond the specified frequency range of the tracking generator, or the calibration data for the source is incorrect.

Status System Alignments, Align Now, All Required
Internal alignment correction data has been lost. Press **System, Alignments, Align Now, All to clear this message from the display.**

Status (TG Align Failure) status bit only, no message
A failure has occurred during the tracking generator (TG) alignment.

Status Video shift off (no corresponding status bit)
Indicates the video shift has been manually disabled; this will impair readings.

Informational Messages

Informational Atten auto set to 15 dB
Indicates that an input signal has been detected which is of sufficient level to damage the input circuitry and the input attenuator has been automatically set to 15 dB. If the signal level is reduced, the attenuator will stay at 15 dB. This overload protection occurs at an input power level of 13 dBm (68 dBmV for Option 1DP) ± 7 dB when the input attenuation is auto coupled and set to <15 dB. To return to the original measurement setup, reduce the input signal level and press **Amplitude**. Then press **Attenuation (Auto)**.
Overload protection is only available in the Agilent Technologies E4401B and E4411B.

Informational Auto ranging...
Displayed during autoranging.

Informational B7D and/or B7E not found. Code Domain not available.
Digital Signal Processing and Fast Analog to Digital Converter (Option B7D) and/or RF Communications Hardware (Option B7E) are not installed options on your analyzer. Code domain is therefore not available.

Informational B7D and/or B7E not found. Mod Acc not available.
Digital Signal Processing and Fast Analog to Digital Converter (B7D) and/or RF Communications Hardware (B7E) are not installed options on your analyzer. Modulation accuracy is therefore not available.

- Informational** Carrier Not Present.
A carrier signal/burst is expected at the analyzer input. This signal cannot be found; however, the measurement will still run. Check input signal connection.
- Informational** Channel frequency outside device's transmit band.
Reset channel number or frequency.
- Informational** Default spur table values loaded.
No spur table has been previously saved when the Out-of-Band Spurious measurement begins. Press **Meas Setup, Edit Table** to enter the frequency ranges of interest and press **Save Table** to save that information. This saved table will be loaded the next time the measurement is run.
- Informational** Device = Mobile. Code Domain not available.
Code Domain measurement is grayed out when the device is set to mobile under the **Mode Setup** front-panel key. Code Domain measurement is only accessible when the device is set to base and RF Communications Hardware (Option B7E) or Enhanced Memory Upgrade (Option B72) are installed.
- Informational** Device = Mobile. Mod Acc not available.
Modulation accuracy measurement is grayed out when the device is set to mobile under **Mode Setup**, front-panel key. Modulation accuracy is only accessible when the device is set to base and RF Communications Hardware (Option B7E) or Enhanced Memory Upgrade (Option B72) are installed.
- Informational** <directoryname> directory deleted
The directory indicated has been successfully deleted.
- Informational** <directoryname1> directory renamed to <directoryname2>
Directory name1 has been successfully renamed to directory name2.

- Informational** Directory already exists
- Each directory and file must have a unique name. The directory name you have entered is currently being used on the selected drive. You may either enter a new name or rename the directory currently existent. Refer to “File Menu Functions” in the Agilent *ESA Spectrum Analyzer User’s Guide*.
- Informational** Entire trace is below the threshold level.
- The measurement cannot operate properly because the trace has fallen completely below the threshold level. Change the threshold level to view signal.
- Informational** <filename> file copied
- The filename indicated has been successfully copied.
- Informational** <filename> file deleted
- The filename indicated has been successfully deleted.
- Informational** <filename> file loaded
- The filename indicated has been successfully loaded.
- Informational** <filename1> file renamed to <filename2>
- Filename1 has been successfully renamed to filename2.
- Informational** <filename> file saved
- The filename indicated has been successfully saved.
- Informational** <filename> too many data entries
- This message may appear when loading data from a limit line or ampcor disk file. The [DATA] section of such a file can contain at most 200 lines of data. This message is displayed if that limit is exceeded.
- Informational** Invalid format: CSV files are not supported by this measurement.

When utilizing the Phase Noise Personality: Option 226, the *.CSV file format is not available.

Informational Measurement halted. Press a measurement key to continue.

This error occurs after you choose **Cancel** to refrain from setting the attenuator to 0 dB during the Receive Channel Power and Receive Spur measurements.

Informational No Fast ADC hardware installed. Meas unavailable.

The analyzer cannot use sweep times of less than 5 milliseconds when Option B7D or Option AYX is not installed. Therefore the measurement will not be executed.

Informational Not enough frequency range to measure harmonics for channel.

Selected harmonics are above the frequency range of the analyzer.

Informational One or more harmonics beyond freq limit: number decreased.

The highest harmonic was beyond the frequency limit of the analyzer, so the number of measured harmonics was decreased.

Informational Option activated

This message is displayed after entering the selected option's License Key.

Informational Please set RF input range (INPUT menu) to manual first.

In order to manually set the reference level and/or the attenuation under the **Amplitude** front-panel key, the RF Input Range menu under the **Input** front-panel key must be set to **Man** (manual).

- Informational** Shutdown in process.
The analyzer is responding to the **Standby** key selection, and is executing the shutdown procedure.
- Informational** Table loaded successfully.
When the **Load Table** key was pressed on the second page of the edit table form while in the out-of-band spurious measurement, the file was present. The information has been loaded into the measurement where it may be edited again. This message will also appear when the out-of-band spurious measurement is opened if a spur table has been previously saved.
- Informational** Table saved successfully.
This message appears after you press the **Save Table** key on the second page of the edit table for the out-of-band spurious measurement. It indicates that the current spur table has been written successfully to disk and is available to be loaded by means of the **Load Table** key.
- Informational** The calibration data is invalid, and has been cleared.
A parameter has changed that affects calibration. Therefore the calibration data has been reset, and for best results recalibration is recommended.
- Informational** The file containing the list of cable types has been updated.
The file update was successful.
- Informational** This measurement does not support the *.CSV file format.
When utilizing the Phase Noise Personality: Option 226, *.CSV (comma separated values) file format is not available.

Informational This operation requires a measurement to be active.

The analyzer cannot perform this operation, because it requires a measurement to be running and no measurement is running.

Informational Tracking Peak Needed.

This message is displayed when there has been a change in Resolution Bandwidth, Span, or Alignment since the previous Tracking Peak.

The message does not apply to the E4401B or E4411B Spectrum Analyzer.

Informational WARNING: You are about to delete all of the contents on directory "x:\xxxxx\". Press Delete Now again to proceed or any other key to abort.

If you select a directory or subdirectory to delete, this popup message is displayed when you press **Delete Now. ("x:\xxxxx\" in the message is the full path and directory name).**

Informational Volume <name> formatted

The indicated disk has been successfully formatted.

Annunciator Bar Messages

Annunciator Align

This message appears in the left side of the annunciator bar in red. When this message appears it indicates that there is one or more condition that has affected the alignment. For the possible conditions and suggested resolutions, refer to [Align Now All Needed \(Align Needed\) on page 330](#), [Align Now RF Needed \(Align Now RF Needed\) on page 330](#), [Align RF Skipped \(Align RF Skipped\) on page 330](#), and [System Alignments, Align Now, All Required on page 334](#).

Annunciator Ext Ref

This message appears in the right side of the annunciator bar in green. When this message appears it indicates that there is one or more condition that affects the reference source. For the possible conditions and suggested resolutions, refer to [Ext Ref on page 331](#).

Annunciator FreqRefUnlock

This message appears in the left side of the annunciator bar in red. When this message appears it indicates that there is one or more condition that results in a frequency reference error. For the possible conditions and suggested resolutions, refer to [Frequency Reference Error on page 331](#).

Annunciator Overload

This message appears in the left side of the annunciator bar in red. When this message appears it indicates that there is one or more condition that causes a system overload. For the possible conditions and suggested resolutions, refer to [IF Overload on page 332](#) and [Overload on page 333](#).

Annunciator Uncal

This message appears in the left side of the annunciator bar in red. When this message appears it indicates that there is one or more condition that results in uncalibrated results. For the possible conditions and suggested resolutions, refer to [Meas Uncal on page 333](#).

Annunciator Unlevel

This message appears in the left side of the annunciator bar in red. When this message appears it indicates that there is one or more condition that affects the leveling of an internal signal, such as the local oscillator (LO) or the tracking generator (source). For the possible conditions and suggested resolutions, refer to [50 MHz Osc Unlevel on page 329](#), [LO Out Unlevel on page 332](#), [Source LO Unlevel on page 334](#), and [Source Unlevel on page 334](#).

Annunciator Unlock

This message appears in the left side of the annunciator bar in red. When this message appears it indicates that there is one or more condition that affects locking one or more of the local oscillators (LOs). For the possible conditions and suggested resolutions, refer to [LO Unlock on page 333](#).

AM, FM, and Pulsed RF Reference Charts

This appendix contains charts and graphs that are helpful when you are performing amplitude modulation, frequency modulation, or pulsed RF measurements.

Modulation information can easily be determined from the carrier signal and a sideband.

The difference in amplitude between the two signals can be used to determine percent of modulation. Markers read the frequency difference between the two signals, which is equal to the modulating frequency. The following table and graph help you to determine amplitude modulation information.

Table 5-1 **Determining Amplitude Modulation**

% Modulation	Sideband Level below Carrier (dB)		Sideband Level below Carrier (dB)	% Modulation
1	46		10	63
2	40		20	20
10	26		30	6.3
20	20		40	2.0
30	16.5		50	0.63
40	14		60	0.2
12	60		70	0.063
70	9.1		80	0.02
80	7.9			
90	6.9			
100	6.0			

Figure 5-1 **Amplitude Modulation**




Table 5-2 Carrier and First Sideband Charts for Calibrating Deviation

Carrier Bessel NULL Order	$t^* = \Delta F/f$	First Sideband	$t^* = \Delta F/f$
1st	2.4048	1st	3.83
2nd	5.5201	2nd	7.02
3rd	8.6531	3rd	10.17
4th	11.7915	4th	13.32
5th	14.9309	5th	16.47
6th	18.0711	6th <td 19.62	
7th	21.2116	7th	22.76
8th	24.3525	8th	25.90
9th	27.4935	9th	29.05
10th	30.6346		

* t=modulation index

Figure 5-2 Bessel Null Graph




Figure 5-3 **Loss in Sensitivity (Pulsed RF versus CW)**




Figure 5-4 RES BW Setting for Pulsed RF Computed from $t_0B = 0.1$

