

NADC, PDC Guide

Agilent Technologies PSA Series Spectrum Analyzers

Option BAE

This manual provides documentation for the following instruments:

E4440A (3 Hz - 26.5 GHz)

E4443A (3 Hz - 6.7 GHz)

E4445A (3 Hz - 13.2 GHz)



Agilent Technologies

Manufacturing Part Number: E4440-90055

Printed in USA

November 2001

© Copyright 1999 - 2001 Agilent Technologies, Inc.

The information contained in this document is subject to change without notice.

Agilent Technologies makes no warranty of any kind with regard to this material, including but not limited to, the implied warranties of merchantability and fitness for a particular purpose. Agilent Technologies shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance, or use of this material.



1. Understanding NADC	
What is the NADC Communications System?	30
What does the Agilent PSA Series Do?	33
Other Sources of Measurement Information	34
Instrument Updates at www.agilent.com	34
2. Setting Up the NADC Mode	
NADC Mode	36
Making a Measurement	37
Changing the Mode Setup	38
Changing the Frequency Channel	42
NADC Measurement Key Flow	44
Using Basic Mode	53
Installing Optional Measurement Personalities	54
Available Measurement Personality Options	54
Loading an Optional Measurement Personality	55
Installing a License Key	56
Viewing a License Key	56
Using the Delete License Key	57
3. Making NADC Measurements	
NADC Measurements	60
Preparing for Measurements	61
Initial Setup	61
Measure	61
Measure Control	63
Measurement Setup	63
Making the Adjacent Channel Power Measurement	67
Purpose	67
Measurement Method	67
Making the Measurement	68
Results	68
Changing the Measurement Setup	69
Changing the View	72
Troubleshooting Hints	73
Making the Error Vector Magnitude (EVM) Measurement	74
Purpose	74
Measurement Method	74
Making the Measurement	75
Results	75
Changing the Measurement Setup	76
Changing the View	77
Changing the Display	78
Troubleshooting Hints	80
Making the Spectrum (Frequency Domain) Measurement	81
Purpose	81
Measurement Method	81
Making the Measurement	81

Contents

Results	82
Changing the Measurement Setup	83
Changing the View	87
Changing the Display	88
Using the Markers	90
Troubleshooting Hints	91
Making the Waveform (Time Domain) Measurement	92
Purpose	92
Measurement Method	92
Making the Measurement	92
Results	93
Changing the Measurement Setup	93
Changing the View	96
Changing the Display	97
Using the Markers	99
Troubleshooting Hints	100
4. NADC Programming Commands	
SCPI Command Subsystems	102
Programming Command Compatibility	
Across Model Numbers and Across Modes	103
Across PSA Modes: Command Subsystem Similarities	103
Across PSA Modes: Specific Command Differences	105
Using Applications in PSA Series vs. VSA E4406A	106
CALCulate Subsystem	108
Adjacent Channel Power—Limit Test	108
Test Current Results Against all Limits	108
Data Query	108
Calculate/Compress Trace Data Query	109
Calculate Peaks of Trace Data	116
EVM - Limits	117
CALCulate:MARKers Subsystem	119
CONFigure Subsystem	130
Configure the Selected Measurement	130
Configure Query	130
DISPlay Subsystem	131
Adjacent Channel Power - View Selection	131
Error Vector Magnitude - View Selection	131
Select Display Format	132
Select Display Format	132
Spectrum - Y-Axis Scale/Div	132
Spectrum - Y-Axis Reference Level	133
Turn a Trace Display On/Off	134
Waveform - Y-Axis Scale/Div	138
Waveform - Y-Axis Reference Level	138
FETCh Subsystem	140
Fetch the Current Measurement Results	140
FORMat Subsystem	141
Byte Order	141

Numeric Data format	141
INITiate Subsystem	143
Take New Data Acquisition for Selected Measurement	143
Continuous or Single Measurements	143
Take New Data Acquisitions	144
Restart the Measurement	144
INSTRument Subsystem.	145
Catalog Query	145
Select Application by Number	145
Select Application	146
MEASure Group of Commands	148
CONFigure, FETCh, MEASure, READ Interactions	148
Adjacent Channel Power Ratio (ACP) Measurement	152
Error Vector Magnitude Measurement	158
Spectrum (Frequency Domain) Measurement	162
Waveform (Time Domain) Measurement	164
READ Subsystem	166
Initiate and Read Measurement Data	166
SENSe Subsystem	167
Adjacent Channel Power Measurement	167
Channel Commands	173
Signal Corrections Commands	175
Error Vector Magnitude Measurement	176
Select the Input Signal	179
RF Power Commands	180
Radio Standards Commands	182
Spectrum (Frequency-Domain) Measurement	183
Synchronization Commands	195
Waveform (Time-Domain) Measurement	196
TRIGger Subsystem	203
Automatic Trigger Control	203
Automatic Trigger Time	203
External Trigger Delay	204
External Trigger Level	204
External Trigger Slope	205
Frame Trigger Adjust	205
Frame Trigger Period	205
Frame Trigger Sync Source	206
Frame Trigger Synchronization Offset	206
Trigger Holdoff	207
Video (IF) Trigger Delay	207
Video (IF) Trigger Level	207
Video (IF) Trigger Slope	208
RF Burst Trigger Delay	208
RF Burst Trigger Level	208
RF Burst Trigger Slope	209

5. Understanding PDC	
What is the PDC Communications System?	212
What Does the Agilent PSA Series Do?	213
Other Sources of Measurement Information	214
Instrument Updates at www.agilent.com	214
6. Setting Up the PDC Mode	
PDC Mode	216
Making a Measurement	217
Changing the Mode Setup	218
Changing the Frequency Channel	222
PDC Measurement Key Flow	224
Using Basic Mode	234
Installing Optional Measurement Personalities	235
Available Measurement Personality Options	235
Loading an Optional Measurement Personality	236
Installing a License Key	237
Viewing a License Key	237
Using the Delete License Key	238
7. Making PDC Measurements	
PDC Measurements	240
Preparing for Measurements	241
Initial Setup	241
Measure	241
Measure Control	243
Measurement Setup	243
Making the Adjacent Channel Power Measurement	247
Purpose	247
Measurement Method	247
Making the Measurement	248
Results	248
Changing the Measurement Setup	249
Changing the View	252
Troubleshooting Hints	253
Making the Error Vector Magnitude (EVM) Measurement	254
Purpose	254
Measurement Method	254
Making the Measurement	255
Results	255
Changing the Measurement Setup	256
Changing the View	257
Changing the Display	258
Troubleshooting Hints	260
Making the Occupied Bandwidth Measurement	261
Purpose	261
Measurement Method	261
Making the Measurement	261

Results	262
Changing the Measurement Setup	263
Changing the Display	263
Troubleshooting Hints	264
Making the Spectrum (Frequency Domain) Measurement	265
Purpose	265
Measurement Method	265
Making the Measurement	265
Results	266
Changing the Measurement Setup	267
Changing the View	271
Changing the Display	271
Using the Markers	272
Troubleshooting Hints	273
Making the Waveform (Time Domain) Measurement	274
Purpose	274
Measurement Method	274
Making the Measurement	274
Results	275
Changing the Measurement Setup	275
Changing the View	278
Changing the Display	279
Using the Markers	281
Troubleshooting Hints	282
8. PDC Programming Commands	
SCPI Command Subsystems	284
Programming Command Compatibility	
Across Model Numbers and Across Modes	285
Across PSA Modes: Command Subsystem Similarities	285
Across PSA Modes: Specific Command Differences	287
Using Applications in PSA Series vs. VSA E4406A	288
CALCulate Subsystem	290
Adjacent Channel Power—Limit Test	290
Test Current Results Against all Limits	290
Data Query	290
Calculate/Compress Trace Data Query	291
Calculate Peaks of Trace Data	298
EVM - Limits	299
CALCulate:MARKers Subsystem	301
Occupied Bandwidth—Frequency Band Limit	312
Occupied Bandwidth—Limit Test	312
CONFigure Subsystem	313
Configure the Selected Measurement	313
Configure Query	313
DISPlay Subsystem	314
Adjacent Channel Power - View Selection	314
Error Vector Magnitude - View Selection	314
Select Display Format	315

Contents

Select Display Format	315
Spectrum - Y-Axis Scale/Div	315
Spectrum - Y-Axis Reference Level	316
Turn a Trace Display On/Off	317
Waveform - Y-Axis Scale/Div	321
Waveform - Y-Axis Reference Level	321
FETCh Subsystem	323
Fetch the Current Measurement Results	323
FORMat Subsystem	324
Byte Order	324
Numeric Data format	324
INITiate Subsystem	326
Take New Data Acquisition for Selected Measurement	326
Continuous or Single Measurements	326
Take New Data Acquisitions	327
Restart the Measurement	327
INSTrument Subsystem	328
Catalog Query	328
Select Application by Number	328
Select Application	329
MEASure Group of Commands	331
CONFigure, FETCh, MEASure, READ Interactions	331
Adjacent Channel Power Ratio (ACP) Measurement	335
Error Vector Magnitude Measurement	341
Occupied Bandwidth Measurement	345
Spectrum (Frequency Domain) Measurement	346
Waveform (Time Domain) Measurement	348
READ Subsystem	350
Initiate and Read Measurement Data	350
SENSE Subsystem	351
Adjacent Channel Power Measurement	351
Channel Commands	356
Signal Corrections Commands	358
Error Vector Magnitude Measurement	359
Select the Input Signal	362
Occupied Bandwidth Measurement	363
RF Power Commands	366
Radio Standards Commands	368
Spectrum (Frequency-Domain) Measurement	369
Synchronization Commands	381
Waveform (Time-Domain) Measurement	382
TRIGger Subsystem	389
Automatic Trigger Control	389
Automatic Trigger Time	389
External Trigger Delay	390
External Trigger Level	390
External Trigger Slope	391
Frame Trigger Adjust	391
Frame Trigger Period	391

Frame Trigger Sync Source	392
Frame Trigger Synchronization Offset	392
Trigger Holdoff	393
Video (IF) Trigger Delay	393
Video (IF) Trigger Level	393
Video (IF) Trigger Slope	394
RF Burst Trigger Delay	394
RF Burst Trigger Level	394
RF Burst Trigger Slope	395
9. Specifications	
NADC Specifications	398
Measurements	399
Frequency	400
General	401
PDC Specifications	402
Measurements	403
Frequency	404
General	405
Specifications Applicable to All Digital Comms Personalities	406
Frequency	406
Amplitude	407
Measurements	410
Inputs and Outputs	413

Contents

Table of Contents

List of Commands

Understanding NADC

Setting Up the NADC Mode

Commands

:CALCulate:<measurement>:MARKer:AOFF	121
:CALCulate:<measurement>:MARKer:AOFF	303
:CALCulate:<measurement>:MARKer[1] 2 3 4:FUNcTION:RESult?	122
:CALCulate:<measurement>:MARKer[1] 2 3 4:FUNcTION:RESult?	304
:CALCulate:<measurement>:MARKer[1] 2 3 4:MAXimum	122
:CALCulate:<measurement>:MARKer[1] 2 3 4:MAXimum	304
:CALCulate:<measurement>:MARKer[1] 2 3 4:MINimum	123
:CALCulate:<measurement>:MARKer[1] 2 3 4:MINimum	305
:CALCulate:<measurement>:MARKer[1] 2 3 4:MODE POSition DELTa	121
:CALCulate:<measurement>:MARKer[1] 2 3 4:MODE POSition DELTa	123
:CALCulate:<measurement>:MARKer[1] 2 3 4:MODE POSition DELTa	303
:CALCulate:<measurement>:MARKer[1] 2 3 4:MODE POSition DELTa	305
:CALCulate:<measurement>:MARKer[1] 2 3 4:MODE POSition DELTA RMSDegree RMSRadian RFM RMSJitter OFF	123
:CALCulate:<measurement>:MARKer[1] 2 3 4:MODE POSition DELTA RMSDegree RMSRadian RFM RMSJitter OFF	305
:CALCulate:<measurement>:MARKer[1] 2 3 4:MODE?	121
:CALCulate:<measurement>:MARKer[1] 2 3 4:MODE?	123
:CALCulate:<measurement>:MARKer[1] 2 3 4:MODE?	303
:CALCulate:<measurement>:MARKer[1] 2 3 4:MODE?	305
:CALCulate:<measurement>:MARKer[1] 2 3 4:TRACe <trace_name>	124
:CALCulate:<measurement>:MARKer[1] 2 3 4:TRACe <trace_name>	306
:CALCulate:<measurement>:MARKer[1] 2 3 4:TRACe?	124
:CALCulate:<measurement>:MARKer[1] 2 3 4:TRACe?	306
:CALCulate:<measurement>:MARKer[1] 2 3 4:X <param>	128
:CALCulate:<measurement>:MARKer[1] 2 3 4:X <param>	310
:CALCulate:<measurement>:MARKer[1] 2 3 4:X:POSition <integer>	129
:CALCulate:<measurement>:MARKer[1] 2 3 4:X:POSition <integer>	311
:CALCulate:<measurement>:MARKer[1] 2 3 4:X:POSition?	129
:CALCulate:<measurement>:MARKer[1] 2 3 4:X:POSition?	311
:CALCulate:<measurement>:MARKer[1] 2 3 4:X?	128
:CALCulate:<measurement>:MARKer[1] 2 3 4:X?	310

Commands

:CALCulate:<measurement>:MARKer[1] 2 3 4:Y?	129
:CALCulate:<measurement>:MARKer[1] 2 3 4:Y?	311
:CALCulate:<measurement>:MARKer[1] 2 3 4[:STATe] OFF ON 0 1	124
:CALCulate:<measurement>:MARKer[1] 2 3 4[:STATe] OFF ON 0 1	306
:CALCulate:<measurement>:MARKer[1] 2 3 4[:STATe]?	124
:CALCulate:<measurement>:MARKer[1] 2 3 4[:STATe]?	306
:CALCulate:ACP:LIMit[:TEST] OFF ON 0 1	108
:CALCulate:ACP:LIMit[:TEST] OFF ON 0 1	290
:CALCulate:ACP:LIMit[:TEST]?	108
:CALCulate:ACP:LIMit[:TEST]?	290
:CALCulate:CLIMits:FAIL?	108
:CALCulate:CLIMits:FAIL?	290
:CALCulate:DATA<n>:COMPRESS? BLOCK CFIT MAXimum MEAN MINimum RMS SAMPLe SDEViation [,<soffset>[,<length>[,<roffset>[,<rlimit>]]]]	109
:CALCulate:DATA<n>:COMPRESS? BLOCK CFIT MAXimum MEAN MINimum RMS SAMPLe SDEViation [,<soffset>[,<length>[,<roffset>[,<rlimit>]]]]	291
:CALCulate:DATA<n>:PEAKs? <threshold>,<excursion>[,AMPLitude FREQuency TIME] . . .	116
:CALCulate:DATA<n>:PEAKs? <threshold>,<excursion>[,AMPLitude FREQuency TIME] . . .	298
:CALCulate:DATA[n]?	108
:CALCulate:DATA[n]?	290
:CALCulate:EVM:LIMit:F10 <percent>	117
:CALCulate:EVM:LIMit:F10?	117
:CALCulate:EVM:LIMit:IQOOffset <dB>	117
:CALCulate:EVM:LIMit:IQOOffset <dB>	299
:CALCulate:EVM:LIMit:IQOOffset?	117
:CALCulate:EVM:LIMit:IQOOffset?	299
:CALCulate:EVM:LIMit:PEAK <percent>	117
:CALCulate:EVM:LIMit:PEAK <percent>	299
:CALCulate:EVM:LIMit:PEAK?	117
:CALCulate:EVM:LIMit:PEAK?	299

Commands

:CALCulate:EVM:LIMit:RMS <percent>	118
:CALCulate:EVM:LIMit:RMS <percent>	299
:CALCulate:EVM:LIMit:RMS?	118
:CALCulate:EVM:LIMit:RMS?	299
:CALCulate:EVM:LIMit[:TEST] OFF ON 0 1	118
:CALCulate:EVM:LIMit[:TEST] OFF ON 0 1	300
:CALCulate:EVM:LIMit[:TEST]?	118
:CALCulate:EVM:LIMit[:TEST]?	300
:CALCulate:EVM:TTSWord?	118
:CALCulate:EVM:TTSWord?	300
:CALCulate:OBW:LIMit:FBLimit <freq>	312
:CALCulate:OBW:LIMit:FBLimit?	312
:CALCulate:OBW:LIMit[:TEST] OFF ON 0 1	312
:CALCulate:OBW:LIMit[:TEST]?	312
:CONFigure:<measurement>	130
:CONFigure:<measurement>	313
:CONFigure:ACP	152
:CONFigure:ACP	335
:CONFigure:EVM	158
:CONFigure:EVM	341
:CONFigure:OBW	345
:CONFigure:SPEctrum	162
:CONFigure:SPEctrum	346
:CONFigure:WAVEform	164
:CONFigure:WAVEform	348
:CONFigure?	130
:CONFigure?	313
:DISPlay:ACP:VIEW BGRaph SPEctrum	131
:DISPlay:ACP:VIEW BGRaph SPEctrum	314
:DISPlay:ACP:VIEW?	131
:DISPlay:ACP:VIEW?	314

Commands

:DISPlay:EVMagnitude:VIEW POLar CONSTIn QUAD	131
:DISPlay:EVMagnitude:VIEW POLar CONSTIn QUAD	314
:DISPlay:EVMagnitude:VIEW?	131
:DISPlay:EVMagnitude:VIEW?	314
:DISPlay:FORMat:TILE	132
:DISPlay:FORMat:TILE	315
:DISPlay:FORMat:ZOOM	132
:DISPlay:FORMat:ZOOM	315
:DISPlay:SPECTrum[n]:WINDow[m]:TRACe:Y[:SCALe]:PDIVision <power>	132
:DISPlay:SPECTrum[n]:WINDow[m]:TRACe:Y[:SCALe]:PDIVision <power>	315
:DISPlay:SPECTrum[n]:WINDow[m]:TRACe:Y[:SCALe]:PDIVision?	132
:DISPlay:SPECTrum[n]:WINDow[m]:TRACe:Y[:SCALe]:PDIVision?	315
:DISPlay:SPECTrum[n]:WINDow[m]:TRACe:Y[:SCALe]:RLEVEL <power>	133
:DISPlay:SPECTrum[n]:WINDow[m]:TRACe:Y[:SCALe]:RLEVEL <power>	316
:DISPlay:SPECTrum[n]:WINDow[m]:TRACe:Y[:SCALe]:RLEVEL?	133
:DISPlay:SPECTrum[n]:WINDow[m]:TRACe:Y[:SCALe]:RLEVEL?	316
:DISPlay:TRACe[n][:STATe] OFF ON 0 1	134
:DISPlay:TRACe[n][:STATe] OFF ON 0 1	317
:DISPlay:TRACe[n][:STATe]?	134
:DISPlay:TRACe[n][:STATe]?	317
:DISPlay:WAVEform[n]:WINDow[m]:TRACe:Y[:SCALe]:PDIVision <power>	138
:DISPlay:WAVEform[n]:WINDow[m]:TRACe:Y[:SCALe]:PDIVision <power>	321
:DISPlay:WAVEform[n]:WINDow[m]:TRACe:Y[:SCALe]:PDIVision?	138
:DISPlay:WAVEform[n]:WINDow[m]:TRACe:Y[:SCALe]:PDIVision?	321
:DISPlay:WAVEform[n]:WINDow[m]:TRACe:Y[:SCALe]:RLEVEL <power>	138
:DISPlay:WAVEform[n]:WINDow[m]:TRACe:Y[:SCALe]:RLEVEL <power>	321
:DISPlay:WAVEform[n]:WINDow[m]:TRACe:Y[:SCALe]:RLEVEL?	138
:DISPlay:WAVEform[n]:WINDow[m]:TRACe:Y[:SCALe]:RLEVEL?	321
:FETCh:<measurement>[n]?	140
:FETCh:<measurement>[n]?	323
:FETCh:ACP[n]?	152

Commands

:FETCh:ACP[n]?	335
:FETCh:EVM[n]?	158
:FETCh:EVM[n]?	341
:FETCh:OBW[n]?	345
:FETCh:SPECTrum[n]?	162
:FETCh:SPECTrum[n]?	346
:FETCh:WAVEform[n]?	164
:FETCh:WAVEform[n]?	348
:FORMat:BORDER NORMal SWAPped	141
:FORMat:BORDER NORMal SWAPped	324
:FORMat:BORDER?	141
:FORMat:BORDER?	324
:FORMat[:DATA] ASCii REAL,32 REAL,64	141
:FORMat[:DATA] ASCii REAL,32 REAL,64	324
:FORMat[:DATA]?	141
:FORMat[:DATA]?	324
:FORMat[:TRACe][:DATA] ASCii INTeger,16 INTeger,32 REAL,32 REAL,64 UINTegeR,16..	141
:FORMat[:TRACe][:DATA] ASCii INTeger,16 INTeger,32 REAL,32 REAL,64 UINTegeR,16..	324
:FORMat[:TRACe][:DATA]?	141
:FORMat[:TRACe][:DATA]?	324
:INITiate:<measurement_name>	143
:INITiate:<measurement_name>	326
:INITiate:CONTInuous OFF ON 0 1	143
:INITiate:CONTInuous OFF ON 0 1	326
:INITiate:CONTInuous?	143
:INITiate:CONTInuous?	326
:INITiate:REStart	144
:INITiate:REStart	327
:INITiate[:IMMediate]	144
:INITiate[:IMMediate]	327
:INSTrument:CATalog?	145

Commands

:INSTrument:CATalog?	328
:INSTrument:NSElect <integer>	145
:INSTrument:NSElect <integer>	328
:INSTrument:NSElect?	145
:INSTrument:NSElect?	328
:INSTrument[:SElect] SA PNOISE BASIC CDMA CDMA2K EDGEgSM NADC PDC WCDMA	146
:INSTrument[:SElect] SA PNOISE BASIC CDMA CDMA2K EDGEgSM NADC PDC WCDMA	329
:INSTrument[:SElect]?	146
:INSTrument[:SElect]?	329
:MEASure:ACP[n]?	152
:MEASure:ACP[n]?	335
:MEASure:EVM[n]?	158
:MEASure:EVM[n]?	341
:MEASure:OBW[n]?	345
:MEASure:SPECtrum[n]?	162
:MEASure:SPECtrum[n]?	346
:MEASure:WAVEform[n]?	164
:MEASure:WAVEform[n]?	348
:READ:<measurement>[n]?	166
:READ:<measurement>[n]?	350
:READ:ACP[n]?	152
:READ:ACP[n]?	335
:READ:EVM[n]?	158
:READ:EVM[n]?	341
:READ:OBW[n]?	345
:READ:SPECtrum[n]?	162
:READ:SPECtrum[n]?	346
:READ:WAVEform[n]?	164
:READ:WAVEform[n]?	348
:TRIGger[:SEquence]:AUTO:STATe OFF ON 0 1	203

Commands

:TRIGger[:SEQuence]:AUTO:STATe OFF ON 0 1	389
:TRIGger[:SEQuence]:AUTO:STATe?	203
:TRIGger[:SEQuence]:AUTO:STATe?	389
:TRIGger[:SEQuence]:AUTO[:TIME] <time>	203
:TRIGger[:SEQuence]:AUTO[:TIME] <time>	389
:TRIGger[:SEQuence]:AUTO[:TIME]?	203
:TRIGger[:SEQuence]:AUTO[:TIME]?	389
:TRIGger[:SEQuence]:EXTErnal[1] 2:DELAy <time>	204
:TRIGger[:SEQuence]:EXTErnal[1] 2:DELAy <time>	390
:TRIGger[:SEQuence]:EXTErnal[1] 2:DELAy?	204
:TRIGger[:SEQuence]:EXTErnal[1] 2:DELAy?	390
:TRIGger[:SEQuence]:EXTErnal[1] 2:LEVel <voltage>	204
:TRIGger[:SEQuence]:EXTErnal[1] 2:LEVel <voltage>	390
:TRIGger[:SEQuence]:EXTErnal[1] 2:LEVel?	204
:TRIGger[:SEQuence]:EXTErnal[1] 2:LEVel?	390
:TRIGger[:SEQuence]:EXTErnal[1] 2:SLOPe NEGative POSitive	205
:TRIGger[:SEQuence]:EXTErnal[1] 2:SLOPe NEGative POSitive	391
:TRIGger[:SEQuence]:EXTErnal[1] 2:SLOPe?	205
:TRIGger[:SEQuence]:EXTErnal[1] 2:SLOPe?	391
:TRIGger[:SEQuence]:FRAME:ADJust <time>	205
:TRIGger[:SEQuence]:FRAME:ADJust <time>	391
:TRIGger[:SEQuence]:FRAME:PERiod <time>	205
:TRIGger[:SEQuence]:FRAME:PERiod <time>	391
:TRIGger[:SEQuence]:FRAME:PERiod?	205
:TRIGger[:SEQuence]:FRAME:PERiod?	391
:TRIGger[:SEQuence]:FRAME:SYNC EXTFront EXTReAr OFF	206
:TRIGger[:SEQuence]:FRAME:SYNC EXTFront EXTReAr OFF	392
:TRIGger[:SEQuence]:FRAME:SYNC:OFFSet <time>	206
:TRIGger[:SEQuence]:FRAME:SYNC:OFFSet <time>	392
:TRIGger[:SEQuence]:FRAME:SYNC:OFFSet?	206
:TRIGger[:SEQuence]:FRAME:SYNC:OFFSet?	392

Commands

:TRIGger[:SEQuence]:FRAMe:SYNC?	206
:TRIGger[:SEQuence]:FRAMe:SYNC?	392
:TRIGger[:SEQuence]:HOLDOff <time>	207
:TRIGger[:SEQuence]:HOLDOff <time>	393
:TRIGger[:SEQuence]:HOLDOff?	207
:TRIGger[:SEQuence]:HOLDOff?	393
:TRIGger[:SEQuence]:IF:DELay <time>	207
:TRIGger[:SEQuence]:IF:DELay <time>	393
:TRIGger[:SEQuence]:IF:DELay?	207
:TRIGger[:SEQuence]:IF:DELay?	393
:TRIGger[:SEQuence]:IF:LEVel <ampl>	207
:TRIGger[:SEQuence]:IF:LEVel <ampl>	393
:TRIGger[:SEQuence]:IF:LEVel?	207
:TRIGger[:SEQuence]:IF:LEVel?	393
:TRIGger[:SEQuence]:IF:SLOPe NEGative POSitive	208
:TRIGger[:SEQuence]:IF:SLOPe NEGative POSitive	394
:TRIGger[:SEQuence]:IF:SLOPe?	208
:TRIGger[:SEQuence]:IF:SLOPe?	394
:TRIGger[:SEQuence]:RFBurst:DELay <time>	208
:TRIGger[:SEQuence]:RFBurst:DELay <time>	394
:TRIGger[:SEQuence]:RFBurst:DELay?	208
:TRIGger[:SEQuence]:RFBurst:DELay?	394
:TRIGger[:SEQuence]:RFBurst:LEVel <rel_power>	208
:TRIGger[:SEQuence]:RFBurst:LEVel <rel_power>	394
:TRIGger[:SEQuence]:RFBurst:LEVel?	208
:TRIGger[:SEQuence]:RFBurst:LEVel?	394
:TRIGger[:SEQuence]:RFBurst:SLOPe NEGative POSitive	209
:TRIGger[:SEQuence]:RFBurst:SLOPe NEGative POSitive	395
:TRIGger[:SEQuence]:RFBurst:SLOPe?	209
:TRIGger[:SEQuence]:RFBurst:SLOPe?	395
[:SENSe]:ACP:AVERAge:COUNt <integer>	167

Commands

[:SENSe]:ACP:AVERAge:COUNT <integer>	351
[:SENSe]:ACP:AVERAge:COUNT?	167
[:SENSe]:ACP:AVERAge:COUNT?	351
[:SENSe]:ACP:AVERAge:TCONtrol EXPonential REPeat	168
[:SENSe]:ACP:AVERAge:TCONtrol EXPonential REPeat	352
[:SENSe]:ACP:AVERAge:TCONtrol?	168
[:SENSe]:ACP:AVERAge:TCONtrol?	352
[:SENSe]:ACP:AVERAge[:STATe] OFF ON 0 1	167
[:SENSe]:ACP:AVERAge[:STATe] OFF ON 0 1	351
[:SENSe]:ACP:AVERAge[:STATe]?	167
[:SENSe]:ACP:AVERAge[:STATe]?	351
[:SENSe]:ACP:LIST:ALIMit <abs_powr>,<abs_powr>,<abs_powr>,<abs_powr>	168
[:SENSe]:ACP:LIST:ALIMit <abs_powr>,<abs_powr>,<abs_powr>,<abs_powr>	352
[:SENSe]:ACP:LIST:ALIMit?	168
[:SENSe]:ACP:LIST:ALIMit?	352
[:SENSe]:ACP:LIST:POWER INTEg PEAK,INTEg PEAK,INTEg PEAK,INTEg PEAK,INTEg PEAK	169
[:SENSe]:ACP:LIST:POWER?	169
[:SENSe]:ACP:LIST:RLIMit <rel_powr>,<rel_powr>,<rel_powr>,<rel_powr>	169
[:SENSe]:ACP:LIST:RLIMit <rel_powr>,<rel_powr>,<rel_powr>,<rel_powr>	353
[:SENSe]:ACP:LIST:RLIMit?	169
[:SENSe]:ACP:LIST:RLIMit?	353
[:SENSe]:ACP:LIST:STATe OFF ON 0 1, OFF ON 0 1, OFF ON 0 1, OFF ON 0 1	170
[:SENSe]:ACP:LIST:STATe OFF ON 0 1, OFF ON 0 1, OFF ON 0 1, OFF ON 0 1	354
[:SENSe]:ACP:LIST:STATe?	170
[:SENSe]:ACP:LIST:STATe?	354
[:SENSe]:ACP:LIST:TEST ABSolute AND RELative OR, ABSolute AND RELative OR, ABSolute AND RELative OR, ABSolute AND RELative OR, ABSolute AND RELative OR	170
[:SENSe]:ACP:LIST:TEST ABSolute AND RELative OR, ABSolute AND RELative OR, ABSolute AND RELative OR, ABSolute AND RELative OR, ABSolute AND RELative OR	354

Commands

[:SENSe]:ACP:LIST:TEST?	170
[:SENSe]:ACP:LIST:TEST?	354
[:SENSe]:ACP:LIST[:FREQuency] <f_offset>,<f_offset>,<f_offset>,<f_offset>,<f_offset>	169
[:SENSe]:ACP:LIST[:FREQuency] <f_offset>,<f_offset>,<f_offset>,<f_offset>,<f_offset>	353
[:SENSe]:ACP:LIST[:FREQuency]?	169
[:SENSe]:ACP:LIST[:FREQuency]?	353
[:SENSe]:ACP:TRIGger:SOURce EXTernal[1] EXTernal2 FRAME IF IMMEDIATE RFBURSt ..	171
[:SENSe]:ACP:TRIGger:SOURce EXTernal[1] EXTernal2 FRAME IF IMMEDIATE RFBURSt ..	354
[:SENSe]:ACP:TRIGger:SOURce?	171
[:SENSe]:ACP:TRIGger:SOURce?	354
[:SENSe]:ACP:TYPE PSDRef TPRef	171
[:SENSe]:ACP:TYPE PSDRef TPRef	355
[:SENSe]:ACP:TYPE?	171
[:SENSe]:ACP:TYPE?	355
[:SENSe]:CHANnel:BURSt TCH CCH	173
[:SENSe]:CHANnel:BURSt TCH CCH	356
[:SENSe]:CHANnel:BURSt?	173
[:SENSe]:CHANnel:BURSt?	356
[:SENSe]:CHANnel:SLOT <integer>	173
[:SENSe]:CHANnel:SLOT <integer>	356
[:SENSe]:CHANnel:SLOT:AUTO OFF ON 0 1	174
[:SENSe]:CHANnel:SLOT:AUTO OFF ON 0 1	357
[:SENSe]:CHANnel:SLOT:AUTO?	174
[:SENSe]:CHANnel:SLOT:AUTO?	357
[:SENSe]:CHANnel:SLOT?	173
[:SENSe]:CHANnel:SLOT?	356
[:SENSe]:CORRection:BS[:RF]:LOSS <rel_power>	175
[:SENSe]:CORRection:BS[:RF]:LOSS <rel_power>	358
[:SENSe]:CORRection:BS[:RF]:LOSS?	175
[:SENSe]:CORRection:BS[:RF]:LOSS?	358
[:SENSe]:CORRection:MS[:RF]:LOSS <rel_power>	175

Commands

[:SENSe]:CORRection:MS[:RF]:LOSS <rel_power>	358
[:SENSe]:CORRection:MS[:RF]:LOSS?	175
[:SENSe]:CORRection:MS[:RF]:LOSS?	358
[:SENSe]:EVM:AVERAge:COUNT <integer>	176
[:SENSe]:EVM:AVERAge:COUNT <integer>	359
[:SENSe]:EVM:AVERAge:COUNT?	176
[:SENSe]:EVM:AVERAge:COUNT?	359
[:SENSe]:EVM:AVERAge:TCONtrol EXPonential REPeat	176
[:SENSe]:EVM:AVERAge:TCONtrol EXPonential REPeat	359
[:SENSe]:EVM:AVERAge:TCONtrol?	176
[:SENSe]:EVM:AVERAge:TCONtrol?	359
[:SENSe]:EVM:AVERAge[:STATe] OFF ON 0 1	176
[:SENSe]:EVM:AVERAge[:STATe] OFF ON 0 1	359
[:SENSe]:EVM:AVERAge[:STATe]?	176
[:SENSe]:EVM:AVERAge[:STATe]?	359
[:SENSe]:EVM:BSYNc:SOURce RFBurst TSEQuence NONE	177
[:SENSe]:EVM:BSYNc:SOURce RFBurst TSEQuence NONE	360
[:SENSe]:EVM:BSYNc:SOURce?	177
[:SENSe]:EVM:BSYNc:SOURce?	360
[:SENSe]:EVM:TRACe:PPSYmbol <integer>	177
[:SENSe]:EVM:TRACe:PPSYmbol <integer>	360
[:SENSe]:EVM:TRACe:PPSYmbol?	177
[:SENSe]:EVM:TRACe:PPSYmbol?	360
[:SENSe]:EVM:TRIGger:SOURce EXTernal[1] EXTernal2 FRAMe IF IMMEDIATE RFBurst	178
[:SENSe]:EVM:TRIGger:SOURce EXTernal[1] EXTernal2 FRAMe IF IMMEDIATE RFBurst	361
[:SENSe]:EVM:TRIGger:SOURce?	178
[:SENSe]:EVM:TRIGger:SOURce?	361
[:SENSe]:FEED RF AREFERENCE IFAlign	179
[:SENSe]:FEED RF AREFERENCE IFAlign	362
[:SENSe]:FEED?	179
[:SENSe]:FEED?	362

Commands

[:SENSe]:OBW:AVERAge:COUNT <integer>	363
[:SENSe]:OBW:AVERAge:COUNT?	363
[:SENSe]:OBW:AVERAge:TCONtrol EXPONential REPeat	364
[:SENSe]:OBW:AVERAge:TCONtrol?	364
[:SENSe]:OBW:AVERAge[:STATe] OFF ON 0 1	363
[:SENSe]:OBW:AVERAge[:STATe]?	363
[:SENSe]:OBW:FREQuency:SPAN <freq>	364
[:SENSe]:OBW:FREQuency:SPAN?	364
[:SENSe]:OBW:TRIGger:SOURce EXTernal[1] EXTernal2 FRAMe IF IMMEDIATE LINE RFBurst	365
[:SENSe]:OBW:TRIGger:SOURce EXTernal[1] EXTernal2 IF IMMEDIATE RFBurst	365
[:SENSe]:OBW:TRIGger:SOURce?	365
[:SENSe]:OBW:TRIGger:SOURce?	365
[:SENSe]:POWer[:RF]:ATTenuation <rel_power>	180
[:SENSe]:POWer[:RF]:ATTenuation <rel_power>	366
[:SENSe]:POWer[:RF]:ATTenuation?	180
[:SENSe]:POWer[:RF]:ATTenuation?	366
[:SENSe]:POWer[:RF]:RANGe:AUTO OFF ON 0 1	180
[:SENSe]:POWer[:RF]:RANGe:AUTO OFF ON 0 1	366
[:SENSe]:POWer[:RF]:RANGe:AUTO?	180
[:SENSe]:POWer[:RF]:RANGe:AUTO?	366
[:SENSe]:POWer[:RF]:RANGe[:UPPer] <power>	180
[:SENSe]:POWer[:RF]:RANGe[:UPPer] <power>	366
[:SENSe]:POWer[:RF]:RANGe[:UPPer]?	180
[:SENSe]:POWer[:RF]:RANGe[:UPPer]?	366
[:SENSe]:RADio:DEVice BS MS	182
[:SENSe]:RADio:DEVice BS MS	368
[:SENSe]:RADio:DEVice?	182
[:SENSe]:RADio:DEVice?	368
[:SENSe]:RADio:TRATe FULL HALF	182
[:SENSe]:RADio:TRATe FULL HALF	368

Commands

<code>[:SENSe]:RADio:TRATe?</code>	182
<code>[:SENSe]:RADio:TRATe?</code>	368
<code>[:SENSe]:SPECtrum:ACQuisition:PACKing AUTO LONG MEDium SHORt</code>	183
<code>[:SENSe]:SPECtrum:ACQuisition:PACKing AUTO LONG MEDium SHORt</code>	369
<code>[:SENSe]:SPECtrum:ACQuisition:PACKing?</code>	183
<code>[:SENSe]:SPECtrum:ACQuisition:PACKing?</code>	369
<code>[:SENSe]:SPECtrum:ADC:DITHer[:STATe] AUTO ON OFF 2 1 0</code>	183
<code>[:SENSe]:SPECtrum:ADC:DITHer[:STATe] AUTO ON OFF 2 1 0</code>	369
<code>[:SENSe]:SPECtrum:ADC:DITHer[:STATe]?</code>	183
<code>[:SENSe]:SPECtrum:ADC:DITHer[:STATe]?</code>	369
<code>[:SENSe]:SPECtrum:ADC:RANGe AUTO APEak APLock NONE P0 P6 P12 P18</code>	184
<code>[:SENSe]:SPECtrum:ADC:RANGe AUTO APEak APLock NONE P0 P6 P12 P18</code>	370
<code>[:SENSe]:SPECtrum:ADC:RANGe?</code>	184
<code>[:SENSe]:SPECtrum:ADC:RANGe?</code>	370
<code>[:SENSe]:SPECtrum:AVERAge:CLEar</code>	185
<code>[:SENSe]:SPECtrum:AVERAge:CLEar</code>	371
<code>[:SENSe]:SPECtrum:AVERAge:COUNT <integer></code>	185
<code>[:SENSe]:SPECtrum:AVERAge:COUNT <integer></code>	371
<code>[:SENSe]:SPECtrum:AVERAge:COUNT?</code>	185
<code>[:SENSe]:SPECtrum:AVERAge:COUNT?</code>	371
<code>[:SENSe]:SPECtrum:AVERAge:TCONtrol EXPonential REPeat</code>	186
<code>[:SENSe]:SPECtrum:AVERAge:TCONtrol EXPonential REPeat</code>	372
<code>[:SENSe]:SPECtrum:AVERAge:TCONtrol?</code>	186
<code>[:SENSe]:SPECtrum:AVERAge:TCONtrol?</code>	372
<code>[:SENSe]:SPECtrum:AVERAge:TYPE LOG MAXimum MINimum RMS SCALar</code>	186
<code>[:SENSe]:SPECtrum:AVERAge:TYPE LOG MAXimum MINimum RMS SCALar</code>	372
<code>[:SENSe]:SPECtrum:AVERAge:TYPE?</code>	186
<code>[:SENSe]:SPECtrum:AVERAge:TYPE?</code>	372
<code>[:SENSe]:SPECtrum:AVERAge[:STATe] OFF ON 0 1</code>	185
<code>[:SENSe]:SPECtrum:AVERAge[:STATe] OFF ON 0 1</code>	371
<code>[:SENSe]:SPECtrum:AVERAge[:STATe]?</code>	185

Commands

[[:SENSe]:SPECTrum:AVERage[:STATe]?	371
[[:SENSe]:SPECTrum:BANDwidth BWIDth:IF:AUTO OFF ON 0 1	187
[[:SENSe]:SPECTrum:BANDwidth BWIDth:IF:AUTO OFF ON 0 1	373
[[:SENSe]:SPECTrum:BANDwidth BWIDth:IF:AUTO?	187
[[:SENSe]:SPECTrum:BANDwidth BWIDth:IF:AUTO?	373
[[:SENSe]:SPECTrum:BANDwidth BWIDth:IF:FLATness OFF ON 0 1	187
[[:SENSe]:SPECTrum:BANDwidth BWIDth:IF:FLATness OFF ON 0 1	373
[[:SENSe]:SPECTrum:BANDwidth BWIDth:IF:FLATness?	187
[[:SENSe]:SPECTrum:BANDwidth BWIDth:IF:FLATness?	373
[[:SENSe]:SPECTrum:BANDwidth BWIDth:PADC OFF ON 0 1	187
[[:SENSe]:SPECTrum:BANDwidth BWIDth:PADC OFF ON 0 1	373
[[:SENSe]:SPECTrum:BANDwidth BWIDth:PADC?	187
[[:SENSe]:SPECTrum:BANDwidth BWIDth:PADC?	373
[[:SENSe]:SPECTrum:BANDwidth BWIDth:PFFT:TYPE FLAT GAUSSian	188
[[:SENSe]:SPECTrum:BANDwidth BWIDth:PFFT:TYPE FLAT GAUSSian	374
[[:SENSe]:SPECTrum:BANDwidth BWIDth:PFFT:TYPE?	188
[[:SENSe]:SPECTrum:BANDwidth BWIDth:PFFT:TYPE?	374
[[:SENSe]:SPECTrum:BANDwidth BWIDth:PFFT[:SIZE] <freq>	188
[[:SENSe]:SPECTrum:BANDwidth BWIDth:PFFT[:SIZE] <freq>	374
[[:SENSe]:SPECTrum:BANDwidth BWIDth:PFFT[:SIZE]?	188
[[:SENSe]:SPECTrum:BANDwidth BWIDth:PFFT[:SIZE]?	374
[[:SENSe]:SPECTrum:BANDwidth BWIDth[:RESolution] <freq>	188
[[:SENSe]:SPECTrum:BANDwidth BWIDth[:RESolution] <freq>	374
[[:SENSe]:SPECTrum:BANDwidth BWIDth[:RESolution]:AUTO OFF ON 0 1	189
[[:SENSe]:SPECTrum:BANDwidth BWIDth[:RESolution]:AUTO OFF ON 0 1	375
[[:SENSe]:SPECTrum:BANDwidth BWIDth[:RESolution]:AUTO?	189
[[:SENSe]:SPECTrum:BANDwidth BWIDth[:RESolution]:AUTO?	375
[[:SENSe]:SPECTrum:BANDwidth BWIDth[:RESolution]?	188
[[:SENSe]:SPECTrum:BANDwidth BWIDth[:RESolution]?	374
[[:SENSe]:SPECTrum:DECimate[:FACTor] <integer>	189
[[:SENSe]:SPECTrum:DECimate[:FACTor] <integer>	375

Commands

[:SENSe]:SPECTrum:DECimate[:FACTor]?	189
[:SENSe]:SPECTrum:DECimate[:FACTor]?	375
[:SENSe]:SPECTrum:FFT:LENGth <integer>	190
[:SENSe]:SPECTrum:FFT:LENGth <integer>	376
[:SENSe]:SPECTrum:FFT:LENGth:AUTO OFF ON 0 1	190
[:SENSe]:SPECTrum:FFT:LENGth:AUTO OFF ON 0 1	376
[:SENSe]:SPECTrum:FFT:LENGth:AUTO?	190
[:SENSe]:SPECTrum:FFT:LENGth:AUTO?	376
[:SENSe]:SPECTrum:FFT:LENGth?	190
[:SENSe]:SPECTrum:FFT:LENGth?	376
[:SENSe]:SPECTrum:FFT:RBWPoints <real>	191
[:SENSe]:SPECTrum:FFT:RBWPoints <real>	377
[:SENSe]:SPECTrum:FFT:RBWPoints?	191
[:SENSe]:SPECTrum:FFT:RBWPoints?	377
[:SENSe]:SPECTrum:FFT:WINDow:DELay <real>	191
[:SENSe]:SPECTrum:FFT:WINDow:DELay <real>	377
[:SENSe]:SPECTrum:FFT:WINDow:DELay?	191
[:SENSe]:SPECTrum:FFT:WINDow:DELay?	377
[:SENSe]:SPECTrum:FFT:WINDow:LENGth <integer>	192
[:SENSe]:SPECTrum:FFT:WINDow:LENGth <integer>	378
[:SENSe]:SPECTrum:FFT:WINDow:LENGth?	192
[:SENSe]:SPECTrum:FFT:WINDow:LENGth?	378
[:SENSe]:SPECTrum:FFT:WINDow[:TYPE] BH4Tap BLACKman FLATtop GAUSSian HAMMING HANNing KB70 KB90 KB110 UNIFORM	192
[:SENSe]:SPECTrum:FFT:WINDow[:TYPE] BH4Tap BLACKman FLATtop GAUSSian HAMMING HANNing KB70 KB90 KB110 UNIFORM	378
[:SENSe]:SPECTrum:FFT:WINDow[:TYPE]?	192
[:SENSe]:SPECTrum:FFT:WINDow[:TYPE]?	378
[:SENSe]:SPECTrum:FREQuency:SPAN <freq>	193
[:SENSe]:SPECTrum:FREQuency:SPAN <freq>	379
[:SENSe]:SPECTrum:FREQuency:SPAN?	193
[:SENSe]:SPECTrum:FREQuency:SPAN?	379

Commands

[[:SENSe]:SPEcTrum:SWEEp:TIME:AUTO OFF ON 0 1	194
[[:SENSe]:SPEcTrum:SWEEp:TIME:AUTO OFF ON 0 1	380
[[:SENSe]:SPEcTrum:SWEEp:TIME:AUTO	194
[[:SENSe]:SPEcTrum:SWEEp:TIME:AUTO	380
[[:SENSe]:SPEcTrum:SWEEp:TIME?	193
[[:SENSe]:SPEcTrum:SWEEp:TIME?	379
[[:SENSe]:SPEcTrum:SWEEp:TIME[:VALue] <time>	193
[[:SENSe]:SPEcTrum:SWEEp:TIME[:VALue] <time>	379
[[:SENSe]:SPEcTrum:TRIGger:SOURce EXTernal[1] EXTernal2 FRAMe IF LINE IMMEDIATE RFBurst.	194
[[:SENSe]:SPEcTrum:TRIGger:SOURce EXTernal[1] EXTernal2 FRAMe IF LINE IMMEDIATE RFBurst.	380
[[:SENSe]:SPEcTrum:TRIGger:SOURce?	194
[[:SENSe]:SPEcTrum:TRIGger:SOURce?	380
[[:SENSe]:SYNC:BURSt:DELay <time>	195
[[:SENSe]:SYNC:BURSt:DELay <time>	381
[[:SENSe]:SYNC:BURSt:DELay?	195
[[:SENSe]:SYNC:BURSt:DELay?	381
[[:SENSe]:SYNC:STHReshold <rel_power>	195
[[:SENSe]:SYNC:STHReshold <rel_power>	381
[[:SENSe]:SYNC:STHReshold?	195
[[:SENSe]:SYNC:STHReshold?	381
[[:SENSe]:WAVEform:ACQuIstion:PACKing AUTO LONG MEDium SHORt	196
[[:SENSe]:WAVEform:ACQuIstion:PACKing AUTO LONG MEDium SHORt	382
[[:SENSe]:WAVEform:ACQuIstion:PACKing?	196
[[:SENSe]:WAVEform:ACQuIstion:PACKing?	382
[[:SENSe]:WAVEform:ADC:DITHer[:STATe] OFF ON 0 1	196
[[:SENSe]:WAVEform:ADC:DITHer[:STATe] OFF ON 0 1	382
[[:SENSe]:WAVEform:ADC:DITHer[:STATe]?	196
[[:SENSe]:WAVEform:ADC:DITHer[:STATe]?	382
[[:SENSe]:WAVEform:ADC:FILTer[:STATe] OFF ON 0 1	196
[[:SENSe]:WAVEform:ADC:FILTer[:STATe] OFF ON 0 1	382

<code>[:SENSe]:WAVeform:ADC:FILTer[:STATe]?</code>	196
<code>[:SENSe]:WAVeform:ADC:FILTer[:STATe]?</code>	382
<code>[:SENSe]:WAVeform:ADC:RANGe AUTO APEak APLock GROund NONE P0 P6 P12 P18</code>	197
<code>[:SENSe]:WAVeform:ADC:RANGe AUTO APEak APLock GROund NONE P0 P6 P12 P18</code>	383
<code>[:SENSe]:WAVeform:ADC:RANGe?</code>	197
<code>[:SENSe]:WAVeform:ADC:RANGe?</code>	383
<code>[:SENSe]:WAVeform:APERture?</code>	197
<code>[:SENSe]:WAVeform:APERture?</code>	383
<code>[:SENSe]:WAVeform:AVERage:COUNT <integer></code>	198
<code>[:SENSe]:WAVeform:AVERage:COUNT <integer></code>	384
<code>[:SENSe]:WAVeform:AVERage:COUNT?</code>	198
<code>[:SENSe]:WAVeform:AVERage:COUNT?</code>	384
<code>[:SENSe]:WAVeform:AVERage:TCONtrol EXPonential REPEAT</code>	198
<code>[:SENSe]:WAVeform:AVERage:TCONtrol EXPonential REPEAT</code>	384
<code>[:SENSe]:WAVeform:AVERage:TCONtrol?</code>	198
<code>[:SENSe]:WAVeform:AVERage:TCONtrol?</code>	384
<code>[:SENSe]:WAVeform:AVERage:TYPE LOG MAXimum MINimum RMS SCALar</code>	199
<code>[:SENSe]:WAVeform:AVERage:TYPE LOG MAXimum MINimum RMS SCALar</code>	385
<code>[:SENSe]:WAVeform:AVERage:TYPE?</code>	199
<code>[:SENSe]:WAVeform:AVERage:TYPE?</code>	385
<code>[:SENSe]:WAVeform:AVERage[:STATe] OFF ON 0 1</code>	198
<code>[:SENSe]:WAVeform:AVERage[:STATe] OFF ON 0 1</code>	384
<code>[:SENSe]:WAVeform:AVERage[:STATe]?</code>	198
<code>[:SENSe]:WAVeform:AVERage[:STATe]?</code>	384
<code>[:SENSe]:WAVeform:BANDwidth:RESolution]:ACTual?</code>	200
<code>[:SENSe]:WAVeform:BANDwidth:RESolution]:ACTual?</code>	386
<code>[:SENSe]:WAVeform:BANDwidth BWIDth[:RESolution] <freq></code>	199
<code>[:SENSe]:WAVeform:BANDwidth BWIDth[:RESolution] <freq></code>	385
<code>[:SENSe]:WAVeform:BANDwidth BWIDth[:RESolution]:TYPE FLATtop GAUSSian</code>	200
<code>[:SENSe]:WAVeform:BANDwidth BWIDth[:RESolution]:TYPE FLATtop GAUSSian</code>	386

Commands

<code>[:SENSe]:WAVeform:BANDwidth BWIDth[:RESolution]:TYPE?</code>	200
<code>[:SENSe]:WAVeform:BANDwidth BWIDth[:RESolution]:TYPE?</code>	386
<code>[:SENSe]:WAVeform:BANDwidth BWIDth[:RESolution]?</code>	199
<code>[:SENSe]:WAVeform:BANDwidth BWIDth[:RESolution]?</code>	385
<code>[:SENSe]:WAVeform:DECimate:STATe OFF ON 0 1</code>	201
<code>[:SENSe]:WAVeform:DECimate:STATe OFF ON 0 1</code>	387
<code>[:SENSe]:WAVeform:DECimate:STATe?</code>	201
<code>[:SENSe]:WAVeform:DECimate:STATe?</code>	387
<code>[:SENSe]:WAVeform:DECimate[:FACTor] <integer></code>	200
<code>[:SENSe]:WAVeform:DECimate[:FACTor] <integer></code>	386
<code>[:SENSe]:WAVeform:DECimate[:FACTor]?</code>	200
<code>[:SENSe]:WAVeform:DECimate[:FACTor]?</code>	386
<code>[:SENSe]:WAVeform:SWEEp:TIME <time></code>	201
<code>[:SENSe]:WAVeform:SWEEp:TIME <time></code>	387
<code>[:SENSe]:WAVeform:SWEEp:TIME?</code>	201
<code>[:SENSe]:WAVeform:SWEEp:TIME?</code>	387
<code>[:SENSe]:WAVeform:TRIGger:SOURce EXTernal[1] EXTernal2 FRAME IF IMMEDIATE LINE RFBurst</code>	202
<code>[:SENSe]:WAVeform:TRIGger:SOURce EXTernal[1] EXTernal2 FRAME IF IMMEDIATE LINE RFBurst</code>	388
<code>[:SENSe]:WAVeform:TRIGger:SOURce?</code>	202
<code>[:SENSe]:WAVeform:TRIGger:SOURce?</code>	388

1 Understanding NADC

What is the NADC Communications System?

The North American Dual-Mode Cellular (NADC) is one of the cellular communications systems. NADC is also referred to as North American Digital Cellular, or American Digital Cellular (ADC). Occasionally it is also referred to as Digital Advanced Mobile Phone Service (D-AMPS) or NADC-TDMA.

The NADC communications system is defined in the Electronics Industry Alliance (EIA) and Telecommunication Industry Association (TIA) standard documents. The following is a list of all relevant and applicable standard documents:

- TIA/EIA IS-136.1
TDMA Cellular/PCS - Radio Interface - Mobile Station - Base Station Compatibility - Digital Control Channel
- TIA/EIA IS-136.2
TDMA Cellular/PCS - Radio Interface - Mobile Station - Base Station Compatibility - Traffic Channels and FSK Control Channel
- TIA/EIA IS-137
TDMA Cellular/PCS - Radio Interface - Minimum Performance Standards for Mobile Stations
- TIA/EIA IS-138
TDMA Cellular/PCS - Radio Interface - Minimum Performance Standards for Base Stations
- TIA/EIA-627
800 MHz Cellular System, TDMA Radio Interface, Dual-Mode Mobile Station - Base Station Compatibility Standard (ANSI/TIA/EIA-627-96), which replaced IS-54-B
- TIA/EIA-628
800 MHz Cellular System, TDMA Radio Interface, Minimum Performance Standards for Dual-Mode Mobile Stations (TIA/EIA-628-96), which replaced IS-55-A
- TIA/EIA-629
800 MHz Cellular System, TDMA Radio Interface, Minimum Performance Standards for Base Stations Supporting Dual-Mode Mobile Stations (ANSI/TIA/EIA-629-96), which replaced IS-56-A

Each base station retains the analog control channels and analog traffic channels of the advanced mobile phone service (AMPS) system. In addition, a base station can have digital traffic channels. The mobile stations are dual mode and access the network via the analog control channel. They are capable of using either analog or digital traffic channel. Digital control channel and digital only mobile stations are also currently being produced.

The AMPS system and the analog part of the NADC IS-54 system employ a frequency division multiple access (FDMA). FDMA means that each traffic channel is assigned to a separate RF frequency. A pair of frequencies with 45 MHz apart (80 MHz apart for 1900 MHz band) is used to provide full duplex operation of the NADC system. The RF channel spacing is 30 kHz. The modulation for the analog portion is frequency modulation (FM).

The digital part of the NADC system employs a combination of FDMA and time division multiple access (TDMA). The NADC time division multiple access structure allows up to six users to share a single carrier frequency. The TDMA frame structure divides time on a carrier into a stream of frames. Each frame is 40 ms long consisting of 6 timeslots; thus, one timeslot is 6.67 ms long. A digital traffic channel is defined by a carrier frequency (or channel number) and a timeslot number. Each user must transmit data only on his carrier frequency, at a time defined by timeslot number. Currently, 2 timeslots per frame are required for each user because more time is required to transmit voice using full-rate speech codecs presently available. When half-rate speech codecs are incorporated into the system, each traffic channel will require just one timeslot per frame.

NADC digital mobile stations transmit a burst of data when their assigned timeslot occurs. This means a mobile station transmits a bursted amplitude modulation signal, ramping transmission power on and off. An NADC digital base station transmits continuously, switching digital modulation on at the appropriate timeslots.

The digital modulation format used in the NADC system is the $\pi/4$ differential quadrature phase shift keying ($\pi/4$ DQPSK). The $\pi/4$ DQPSK modulation causes both phase and amplitude variations on the RF signal. The quadrature nature of this modulation allows 2 bits to be transmitted at the same time on orthogonal carriers. These 2 bits make one NADC symbol. The digital modulation operates at 162 symbols, or 324 bits in each timeslot. Since there are 1944 bits in 6 timeslots and 25 frames in one second, the transmission bit rate is 48,600 bits per second.

The key objectives of the NADC system are to increase the subscriber capacity, provide more secure voice communications, and be backwards compatible with the existing AMPS analog cellular system.

Understanding NADC

What is the NADC Communications System?

Since the system transmits all information in a digital form, it will be much harder to listen to someone else's cellular phone conversation. This is a key benefit for people using cellular phones that convey confidential information. The NADC is backwards compatible with the existing AMPS system so that analog cellular phones would not be obsolete. Therefore, all NADC mobiles have the capability to operate using the existing analog base stations as well as the digital base stations.

Following is a summary of the NADC air interface. Note that the frequency range is the same as the analog cellular. Since it is a dual-mode system, NADC will use the same frequency band currently assigned to the AMPS cellular. The available channels are divided into analog and digital channels. The channel spacing is 30 kHz each, and the RX/TX frequency difference is 45 MHz as in the AMPS cellular. NADC has a RX/TX time spacing of 1.85 ms. It uses the $\pi/4$ DQPSK modulation and the modulation rate is 24.3 ksymbols/sec. NADC will initially allow 3 users per frequency pair and will allow 6 when implemented with the half-rate voice coder. One frame is 40 ms and consists of 6 timeslots that are each 6.667 ms long. There are 162 symbols per timeslot and the symbol period is 41.16 μ s.

800 MHz	Uplink	825.030 to 848.970 MHz	824.040 to 825.000 MHz
	Downlink	870.030 to 893.970 MHz	869.040 to 870.000 MHz
	Channel Numbers	1 to 799	991 to 1023
1900 MHz	Uplink	1850.040 to 1909.920 MHz	
	Downlink	1930.080 to 1989.990 MHz	
	Channel Numbers	2 to 1998	

What does the Agilent PSA Series Do?

This instrument can help determine if an NADC transmitter operates correctly. When configured for NADC, the instrument can be used to test an NADC transmitter according to the TIA/EIA standards, 627, 628, 629, IS-136, IS-137, and IS-138.

This document defines complex and multiple-part measurements used to maintain an interference-free environment. For example, the document includes the testing method for carrier power. The instrument automatically makes these measurements based on the TIA/EIA standards. The detailed measurement result displays allow you to analyze NADC system performance. You may alter the measuring parameters for your specific measurement and analysis.

Other Sources of Measurement Information

Additional measurement application information is available through your local Agilent Technologies sales and service office. The following application notes explain digital communications measurements in much greater detail than discussed in this guide.

- Application Note 1298
Digital Modulation in Communications Systems - An Introduction
part number 5965-7160E
- Application Note 1324
Understanding PDC and NADC Transmitter Measurements for
Base Transceiver Stations and Mobile Stations
part number 5968-5537E

Instrument Updates at www.agilent.com

These web locations can be used to access the latest information about the instrument, including the latest firmware version.

www.agilent.com/find/vsa

www.agilent.com/find/psa

2

Setting Up the NADC Mode

NADC Mode

You may want to install a new personality, reinstall a personality that you have previously uninstalled, or uninstall a personality option. Instructions can be found in [“Installing Optional Measurement Personalities”](#) on page 54.

To access the NADC measurement personality press the **Mode** key and select **NADC**.

If you want to set the NADC mode to a known, factory default state, press the **Preset** key. This will preset the mode setup and all of the NADC measurements to the factory default parameters.

NOTE

Note that pressing the **Preset** key does not switch instrument modes if the Mode type of preset is selected under **System, Power On/Preset**.

Mode settings are persistent. When you switch from one mode to another mode, the settings you originally chose for the modes will remain active until you change them. This allows you to switch back and forth between modes without having to reset settings each time. Presetting the instrument or powering the instrument off and on will return all mode settings to their default values.

Making a Measurement

This instrument enables you to make a wide variety of measurements on digital communications equipment using the Spectrum Analysis Mode measurement capabilities. It also has optional measurement personalities that make measurements based on established industry standards.

To set up the instrument to make measurements, you need to:

1. Select a **Mode** or personality which corresponds to a digital communications format, like cdma2000, W-CDMA, or GSM w/EDGE. Or use the Basic mode to make measurements on signals with non-standard formats. After selecting the mode, make any required adjustments to the mode settings.
2. Press **Measure** to select a specific measurement to be performed, like ACP, Channel Power, or EVM, etc. After selection of a measurement, make any required adjustments to the measurement settings.

Depending on the current settings of **Meas Control**, the instrument will begin making the selected measurement. The resulting data will be shown on the display or available for export.

3. Select a front panel **View** to display the data from the current measurement. Depending on the mode and measurement selected, various graphical and tabular presentations are available.

If you have a problem, and get an error message, see the “If You Have a Problem” section in each measurement description.

The main keys used in the three steps are shown in the table below.

Step	Primary Key	Setup Keys	Related Keys
1. Select & setup a mode	MODE	Mode Setup, Input, FREQUENCY/ Channel	System
2. Select & setup a measurement	MEASURE	Meas Setup	Meas Control, Restart
3. Select & setup a view	View/TraceTrace/View	SPAN X Scale, AMPLITUDE Y Scale, Display, Zoom, Next Window	File, Save, Print, Print Setup, Marker, PeakSearch

A setting may be reset at any time, and will be in effect on the next measurement cycle or View.

Changing the Mode Setup

Numerous settings can be changed at the mode level by pressing the **Mode Setup** key. This will access the selection menu listed below. These settings affect only the measurements in the NADC mode.

Radio

The **Radio** key accesses the menu as follows:

- **Traffic Rate** - Allows you to toggle the traffic rate between **Full** and **Half**.
- **Device** - Allows you to toggle the test device between **BS** (Base Station) and **MS** (Mobile Station).

Radio Default Settings	
Traffic Rate	Full
Device	BS

Input

The **Input** key accesses the menu as follows: (You can also access this menu from the front-panel **Input** key.)

- **RF Input Range** - Allows you to toggle the RF input range between **Auto** and **Man** (manual). **Auto** is not used for Spectrum measurements. If **Auto** is chosen, the instrument automatically sets the attenuator based on the carrier power level, where it is tuned. Once you change the **Max Total Pwr** or **Input Atten** value with the **RPG** knob, for example, the **RF Input Range** key is automatically set to **Man**. If there are multiple carriers present, the total power might overdrive the front end amplifiers. In this case you need to set the **RF Input Range** to **Man** and enter the expected maximum total power by activating the **Max Total Pwr** key. **Man** is also useful to hold the input attenuation constant for the best relative power accuracy. For single carriers it is generally recommended to set this to **Auto**.
- **Max Total Pwr** - Allows you to set the maximum total power from the UUT (Unit Under Test). The range is -200.00 to $+50.00$ dBm with 0.01 dB resolution. This is the expected maximum value of the mean carrier power referenced to the output of the UUT; it may include multiple carriers. The **Max Total Pwr** setting is coupled together with the **Input Atten** and **Ext Atten** settings. Once you change the **Max Total Pwr** value with the **RPG** knob, for example, the **RF Input Range** key is automatically set to **Man**.

- **Input Atten** - Allows you to control the input attenuator setting. The range is 0 to 40 dB with 1 dB resolution. The **Input Atten** key reads out the actual hardware value that is used for the current measurement. If more than one input attenuator value is used in a single measurement, the value used at the carrier frequency will be displayed. The **Input Atten** setting is coupled together with the **Max Total Pwr** setting. Once you change the **Input Atten** value with the **RPG** knob, for example, the **RF Input Range** key is automatically set to **Man**.
- **Ext Atten** - Allows you to enter the external attenuation value for either BS or MS. The range is -50.00 to +50.00 dB with 0.01 dB resolution. This will allow the instrument to display the measurement results referred to the output of the UUT.

NOTE

The **Max Total Pwr** and **Input Atten** settings are coupled together, so changing the input **Max Total Pwr** setting by x dB changes the **Input Atten** setting by x dB. When you switch to a different measurement, the **Max Total Pwr** setting is kept constant, but the **Input Atten** may change if the two measurements have different mixer margins. Therefore, you can set the input attenuator manually, or you can set it indirectly by specifying the expected maximum power from the UUT.

Input Default Settings	
RF Input Range	Auto ^a
Max Total Power	-15.00 dBm ^b
Input Atten	0.00 dB ^b
Ext Atten MS	0.00 dB
Ext Atten BS	0.00 dB

a. **Auto** is not used for Spectrum measurements.

b. This may differ if the maximum input power is more than -15.00 dBm.

Trigger

The **Trigger** key allows you: (1) to access the **RF Burst (Wideband)**, **Video (IF Envlp)**, **Ext Front** and **Ext Rear** trigger source selection menu to specify the triggering conditions for each trigger source, (2) to modify the default trigger holdoff time using the **Trig Holdoff** key, (3) to modify the auto trigger time and to activate or deactivate the **Auto Trigger** feature using the **Auto Trig** key, and (4) to modify the period of the frame timer using the **Frame Timer** key.

NOTE

The actual trigger source is selected separately for each measurement under the **Meas Setup** key

- **RF Burst (Wideband)**, **Video (IF Envlp)**, **Ext Front** and **Ext Rear** - Pressing one of these trigger keys will access each triggering condition setup menu. This menu is used to specify the **Delay**, **Level** and **Slope** settings for each trigger source as follows:

Delay - Allows you to enter numerical values to modify the delay time. The range is -500.000 to $+500.000$ ms with 1 ns resolution. For trigger delay use a positive value, and for pre-trigger use a negative value.

Level - Allows you to enter a numerical value to adjust the trigger level depending on the trigger source selected.

- For **RF Burst** selection, the RF level range is -200.00 to 0.00 dB with 0.01 dB resolution, relative to the peak RF signal level. The realistic range can be down to -20 dB.
- For **Video** selection, the video level range is -200.00 to $+50.00$ dBm with 0.01 dB resolution at the RF input. The realistic range can be down to around -40 dBm, depending on the noise level of the signal.
- For **Ext Front** or **Ext Rear** selection, the level range is -5.00 to $+5.00$ V with 1 mV resolution.

Slope Pos Neg - Allows you to toggle the trigger slope between **Pos** at the positive-going edge and **Neg** at the negative-going edge of the burst signal.

Other keys accessed under the **Trigger** key:

- **Trig Holdoff** - Allows you to set the period of time before the next trigger can occur. The range is 0.000 to 500.0 ms with 1 μ s resolution.
- **Auto Trig** - Allows you to specify a time for a trigger timeout. The range is 0.000 to 1000 sec with 1 μ s resolution. If no trigger occurs by the specified time, a trigger is automatically generated.
- **Frame Timer** - Allows you to access the **Frame Timer** menu to manually control the frame timer:

Period - Allows you to set the period of the frame clock. The range is 1.000 to 559.0 ms. Finest resolution is 1 ns. When **Traffic Rate** is **Full**, the default is 20.0 ms. When **Traffic Rate** is **Half**, the default is 40.0 ms.

Trigger Default Settings	
RF Burst:	
Delay	0.000 sec
Peak Level	-10.0 dB
Slope	Pos
Video:	
Delay	0.000 s
Level	-30.00 dBm
Slope	Pos
Ext Front & Ext Rear:	
Delay	0.000 s
Level	2.00 V
Slope	Pos
Trig Holdoff	10.00 ms
Auto Trig	100.0 ms, On
Frame Timer Period	20.00000 ms when Traffic Rate is Full 40.00000 ms when Traffic Rate is Half

Burst

The **Burst** key allows you to access the following menu to set the trigger condition for the ACP and EVM measurements.

- **Delay** - Allows you to set the delay time after searching a threshold level of NADC bursts. The range is -500.0 to $+500.0$ ms with 1 ns resolution.
- **Search Threshold** - Allows you to set the threshold level used in search for NADC bursts after data is acquired. The range is -200.00 to -0.01 dB with 0.01 dB resolution. The realistic lower range can be down to the noise floor level of the signal.

Burst Default Settings	
Delay	0.000 s
Search Threshold	-30.00 dB

Changing the Frequency Channel

After selecting the desired mode setup, you will need to select the desired center frequency, burst type and slot. Press the **Frequency Channel** key to access the following menu:

- **Center Freq** - Enter a frequency value that corresponds to the desired RF channel to be measured. This is the current instrument center frequency for any measurement function.
- **Burst Type** - Choose an NADC burst type from the following selections only when **Device** under **Radio** is previously set to **MS**, otherwise this key is unavailable. This is used only when making EVM measurements.

Traffic (TCH) - Sets to the traffic channel burst signal of which burst length is 324 bits or 162 symbols.

Control (CCH) - Sets to the control channel burst signal of which burst length is 280 bits or 140 symbols.

- **Slot (Std)** - Allows you to toggle the slot selection function between **Auto** and **Man**, and also to specify the particular timeslot to be measured when **Man** is selected. This is used only when making EVM measurements.

Auto - In auto, the measurement is made on the first timeslot found to have any one of the valid sync words, corresponding to slots 1 to 6. The measurement may be made on various timeslots if more than one timeslot has a valid sync word.

Man - In manual, the measurement is made on the first timeslot found to have the selected sync word in the range of 1 to 6. The measurement will be made only on the specified timeslot.

When the NADC mode is selected, the instrument will default to the following settings.

Frequency Channel Default Settings	
Center Frequency	1.00000 GHz
Burst Type ^a	Traffic (TCH)
Slot (Std)	1, Auto


a. This is used only when Device is MS.

NADC Measurement Key Flow

The key flow diagrams, shown in a hierarchical manner on the following pages, will help the user to grasp the overall functional relationships for the front-panel keys and the softkeys displayed at the extreme right side of the screen. The diagrams are:

- “Mode Setup / Frequency Channel Key Flow” on page 45.
- “ACP Measurement Key Flow” on page 46.
- “EVM Measurement Key Flow” on page 47.
- “Spectrum Measurement Key Flow (1 of 3)” on page 48.
- “Waveform Measurement Key Flow (1 of 2)” on page 51.

Use these flow diagrams as follows:



1. There are some basic conventions:

An oval represents one of the front-panel keys.

This box represents one of the softkeys displayed.

Default conditions are shown as much as possible (underlined).

2. Start from the extreme upper left corner of each measurement diagram to the right direction.
3. Proceed from the top to the bottom.
4. When defining a key from auto to manual, for example, just press that key one time.
5. When entering a numeric value of **Frequency**, for example, use the numeric keypad by terminating with the appropriate unit selection from the keys displayed.
6. When entering a numeric value of **Slot**, for example, use the numeric keypad by terminating with the **Enter** front-panel key.
7. Instead of using the numeric keypad to enter a value, it may be easier to use the **RPG** knob or **Up/Down** keys depending on the input field of a parameter.

Figure 2-1 Mode Setup / Frequency Channel Key Flow




Figure 2-2 ACP Measurement Key Flow




Figure 2-3 EVM Measurement Key Flow




Figure 2-4 Spectrum Measurement Key Flow (1 of 3)




Figure 2-5 Spectrum Measurement (2 of 3)




Figure 2-6 Spectrum Measurement (3 of 3)




Figure 2-7 Waveform Measurement Key Flow (1 of 2)





Figure 2-8 **Waveform Measurement (2 of 2)**



Using Basic Mode

Basic mode is not related to a particular communications standard. That is, it does not default to measurement settings that are for any specific standard. You may want to use Basic Mode if you are making measurements on a signal that is not part of a specific digital communications standard.

There are two measurements available under the **Measure** key in Basic mode:

- Spectrum measurement (frequency domain).
- Waveform measurement (time domain)

These measurements provide a measurement mode that is similar to a standard spectrum analyzer. Unlike the standard analyzer, these measurements are optimized for measuring digitally modulated signals, so they can be used to output the measured I/Q data.

The Spectrum and Waveform measurements are also available in this mode, with the same functionality, so you can refer to this manual for information about using them.

Installing Optional Measurement Personalities

When you **install** a measurement personality, you follow a two step process.

1. Install the measurement personality firmware into the instrument memory. See [“Loading an Optional Measurement Personality” on page 55.](#)
2. Enter a license key number that activates the measurement personality. See [“Installing a License Key” on page 56.](#)

Adding additional measurement personalities requires purchasing a retrofit kit for the desired option. The retrofit kit contains the measurement personality firmware and a license key certificate. It documents the license key number that is for your specific option and instrument serial number.

Available Measurement Personality Options

Available Personality Options ^a	Option
Digital Demod Hardware (with Basic Mode)	B7J
GSM (with EDGE) measurement personality	202
cdmaOne measurement personality	BAC
NADC, PDC measurement personalities	BAE
W-CDMA measurement personality	BAF
cdma2000 measurement personality	B78
Phase noise measurement personality	226

a. Available as of the print date of this guide.

You need two pieces of information about your instrument to order a retrofit kit adding an option. You need the Host ID, and the instrument serial number.

Required Information:	Key Path:
Host ID: _____	System, Show System
Instrument Serial Number: _____	System, Show System

NOTE The instrument must have Option B7J in order to add most of the measurement personality options. (Basic, cdmaOne, cdma2000, W-CDMA, GSM, NADC, PDC.)

Loading an Optional Measurement Personality

You must load the desired option into your instrument memory. Loading can be done from a CD-ROM or a www location. The automated loading program runs from your PC and comes with the firmware.

NOTE When you add a new option, or update an existing option, you will get the updated version of all your current options since they are reloaded simultaneously. This process may also require you to update the instrument core firmware so that it is compatible with the new option.

You may not be able to fit all of the available measurement personalities in instrument memory at the same time. The approximate memory requirements for the options are listed below. These numbers are worst case examples. Many options share components/libraries so the total memory usage of multiple options may not be exactly equal to the combined total.

Available Personality Options	Approximate File Size (PSA - A.02.06)
GSM (with EDGE) measurement personality	3.3 MB
cdmaOne measurement personality	2.0 MB
NADC measurement personalities	1.3 MB
PDC measurement personalities	1.4 MB
W-CDMA measurement personality	4.2 MB ^a
cdma2000 measurement personality	3.8 MB ^a
Phase noise measurement personality	2.6 MB
“Shared measurement library” (see footnote)	1.5 MB

a. This application uses the “shared measurement library”, so you have to add its memory requirements to this value.

You can install an updated version of firmware and your licensed options using a LAN connection and your PC. Instructions for loading future firmware updates are available at the following URL:

www.agilent.com/find/psa/

Installing a License Key

To install a license key number for the selected option, use the following procedure.

NOTE You can also use this to reinstall a license key number that has been deleted during an uninstall process, or lost due to a memory failure

1. Press **System, More, More, Licensing, Option**. The **Option** key accesses the alpha editor menu. Use the alpha editor to enter letters (upper-case) and the front-panel numeric keys to enter numbers for the option designation. Then press the **Enter** key. As you enter the option, you will see your entry in the active function area of the display.
2. Press **License Key**. Enter the letters/digits of your license key. You will see your entry in the active function area of the display. When you have completed entering the license key number, press the **Enter** key.
3. Press the **Activate License** key.

Viewing a License Key

Measurement personalities purchased with your instrument have been installed and activated at the factory. You will receive a unique **License Key** number with every measurement personality purchased. The license key number is a hexadecimal number that is for your specific measurement personality, instrument serial number and host ID. It enables you to install, or reactivate that particular personality.

Follow these steps to display the unique license key for a measurement personality that is already installed in your instrument:

1. Press **System, More, More, Licensing, Show License**. The **System, Personalities** key shows you if the option has been activated.

You will want to keep a copy of your license key number in a secure location. Please enter your license key numbers below for future reference. If you should lose your license key number, call your nearest Agilent Technologies service or sales office for assistance.

License Key Numbers for Instrument with Serial # _____	
For Option _____	the license key number is _____
For Option _____	the license key number is _____
For Option _____	the license key number is _____
For Option _____	the license key number is _____
For Option _____	the license key number is _____

License Key Numbers for Instrument with Serial # _____
For Option _____ the license key number is _____

Using the Delete License Key

The following procedure removes the license key number for the selected option. This will make the option unavailable for use. Please write down the 12-digit license key number for the option before proceeding. If you want to use that measurement personality at a later date you will need the license key number to reactivate the personality firmware.

NOTE

Using the **Delete License** key does not remove the personality from the instrument memory, and does not free memory to be available to install another option. If you need to free memory to install another option, refer to the instructions for loading firmware updates located at the URL: www.agilent.com/find/psa/

1. Press **System, More, More, Licensing, Option**. Pressing the **Option** key will activate the alpha editor menu. Use the alpha editor to enter the letters (upper-case) and the front-panel numeric keyboard to enter the digits (if required) for the option, then press the **Enter** key. As you enter the option, you will see your entry in the active function area of the display.
2. Press **Delete License** to remove the license key from memory.

Setting Up the NADC Mode
Installing Optional Measurement Personalities

3 Making NADC Measurements

NADC Measurements

Once in the NADC mode the following measurements for the NADC band are available by pressing the **Measure** key.

- “Making the Adjacent Channel Power Measurement” on page 67.
- “Making the Error Vector Magnitude (EVM) Measurement” on page 74.
- “Making the Spectrum (Frequency Domain) Measurement” on page 81.
- “Making the Waveform (Time Domain) Measurement” on page 92.

These are referred to as one-button measurements. When you press the key to select a measurement, it will become active using settings and a display unique to that measurement. Data acquisitions will automatically begin when trigger requirements, if any, are met.

Preparing for Measurements

If you want to set the NADC mode to a known, factory default state, press **Preset**. This will preset the mode setup and all of the measurements to the factory default parameters. You should often be able to make a measurement using these defaults.

NOTE

Pressing the **Preset** key does not switch instrument modes.

To preset only the settings that are specific to the selected measurement, press **Meas Setup, More (1 of 2), Restore Meas Defaults**. This will reset the measure setup parameters, for the currently selected measurement only, to the factory defaults.

Initial Setup

Before making a measurement, make sure the mode setup and frequency channel parameters are set to the desired settings. Refer to the sections “Making a Measurement” and “Changing the Frequency Channel” in the previous chapter.

Measure

The **Measure** front-panel key accesses the menu to select one of the following measurements:

- **ACP** - Press this key to make adjacent channel power measurements. The following menu is activated by the **View/Trace** front-panel key:
 - Bar Graph** - Displays the ACP bar graph at ± 30 , ± 60 and ± 90 kHz offsets from the center frequency of the carrier signal. The summary data is also available in the text window.
 - Spectrum** - Displays the ACP spectrum graph (with ± 24.3 kHz bandwidth marker lines) at ± 30 , ± 60 and ± 90 kHz offsets from the center frequency of the carrier signal. The summary data is also available in the text window.
- **EVM** - Press this key to make error vector magnitude measurements. The following menu is activated by the **View/Trace** front-panel key:
 - I/Q Measured Polar Vector** - Displays the EVM polar vector graph of the I/Q demodulated signal. The summary data is also available in the text window.
 - I/Q Measured Polar ConstIn** - Displays the EVM polar constellation graph of the I/Q demodulated signal. The summary data is also available in the text window.

Making NADC Measurements

Preparing for Measurements

I/Q Error (Quad-View) - Displays four windows for the **EVM**, **Magnitude Error**, **Phase Error** graphs and the **EVM** summary data. By selecting one of the windows with the **Next Window** front-panel key, you can enlarge it to the full display area by pressing the **Zoom** key.

- **Spectrum (Freq Domain)** - Press this key to make spectrum measurements with the spectrum and I/Q waveform display windows. The following menu is activated by the **View/Trace** front-panel key:

Spectrum - Switches from the **I/Q Waveform** window to **Spectrum** window. This is equivalent to the **Next Window** front-panel key.

I/Q Waveform - Switches the display window from the **Spectrum** window. This is equivalent to the **Next Window** front-panel key.

Trace Display - Allows you to control the traces displayed for the current measurement data and/or the averaged data as follows:

All - Displays both current and average traces if the **Average** function is already activated.

Average (or Max & Min) - Displays only the average trace if it is already activated.

Current - Displays only the current data trace.

- **Waveform (Time Domain)** - Press this key to make time-domain waveform measurements with either display of the **RF Envelope** graph and summary data windows or the **I/Q Waveform** window. The following menu is activated by the **View/Trace** front-panel key:

RF Envelope - Changes to display the RF envelope graph window and the summary data window. This is the default selection for waveform (time domain) measurements.

I/Q Waveform - Changes to display the I/Q waveform graph window.

Measure Control

The **Meas Control** front-panel key accesses the menu to control processes that affect the running of the current measurement.

- **Restart** - Press this **Restart** key to repeat the current measurement from the beginning, while retaining the current measurement settings. This is equivalent to the **Restart** front-panel key.
- **Measure** - Press **Meas Control**, **Measure** (not to be confused with the front-panel **Measure** key which has a different function) to toggle the measurement state between **Single** and **Cont** (Continuous). When set to single, the measurement will continue until it has reached the specified number of averages set by the average counter. When set to continuous, the measurement will run continuously and execute averaging according to the current average type, either repeat or exponential. The default setting is **Cont**.
- **Pause** - Press **Meas Control**, **Pause** to pause the current measurement until you reactivate the measurement. Once toggled, the label of the **Pause** key changes to read **Resume**. The **Resume** key, once pressed, continues the active measurement from the point at which it was paused.

Measurement Setup

The **Meas Setup** key accesses the features that enable you to adjust parameters of the current measurement, such as resolution bandwidth. You will also use the **Meas Setup** menu to access the **Avg Number**, **Avg Mode** and **Trig Source** keys.

The following measure setup feature can be used with many or all measurements:

- **Restore Meas Defaults** - Allows you to preset only the settings that are specific to the selected measurement by pressing **Meas Setup**, **More (1 of 2)**, **Restore Meas Defaults**. This will set the measure setup parameters, for the currently selected measurement only, to the factory defaults.

Averaging

Selecting one of the averaging keys in the **Meas Setup** menu will allow you to modify the average number and averaging mode you use for the currently selected measurement. For spectrum (frequency domain) and waveform (time domain) measurements, the **Average** key activates the following menu:

- **Avg Number** - Allows you to change the number of N averages to be made.

Making NADC Measurements

Preparing for Measurements

- **Avg Mode Exp Repeat** - Allows you to choose either exponential or repeat averaging mode. This selection only effects the averaging result after the number of N averages is reached. The N is set using the **Avg Number** key.

Normal averaging: Normal (linear) averaging is always used until the specified number of N averages is reached. When the **Measure** key under **Meas Control** is set to **Single**, data acquisition is stopped when the number of N averages is reached, thus **Avg Mode** has no effect in **Single** measurement mode.

Exponential averaging: When **Measure** is set to **Cont**, data acquisition will continue indefinitely. Exponential averaging is used with a weighting factor of N (the displayed count of averages stops at N). Exponential averaging weights new data more heavily than old data, which allows tracking of slow-changing signals. The weighting factor N is set using the **Avg Number** key.

Repeat averaging: When **Measure** is set to **Cont**, data acquisition will continue indefinitely. After the number of N averages is reached, all previous result data is cleared and the displayed count of averages is set back to 1. This is equivalent to being in **Measure Single** and pressing the **Restart** key each time the single measurement finishes.

- **Avg Type** - Allows you to access the following menu only for making spectrum (frequency domain) and waveform (time domain) measurements:

Pwr Avg (RMS) - Executes the true power averaging which is equivalent to taking the rms of the voltage. This is the most accurate type.

Log-Pwr Avg (Video) - Simulates the traditional spectrum analyzer type of averaging by calculating an average of the log power.

Voltage Avg - Executes the voltage averaging.

Maximum - Executes the maximum voltage averaging by capturing peak data.

Minimum - Executes the minimum voltage averaging.

Trigger Source

Changing the selection in the **Trig Source** menu alters the trigger source for the selected measurement only. Not all of the selections are available for all measurements. Choose one of the following trigger sources:

NOTE

The **RF Burst (Wideband)**, **Video (IF Envlp)**, **Ext Front** and **Ext Rear** keys found under the **Trigger** menu enable you to change the default settings of the delay, level and slope for each of these trigger sources.

- **Free Run (Immediate)** - A trigger occurs at the time the data is requested, completely asynchronous with the RF or IF signal.
- **RF Burst (Wideband)** - An internal wideband RF burst trigger that has the automatic level control for burst signals. It triggers at the level that is set relative to the peak RF signal (12 MHz bandwidth) input level.
- **Video (IF Envlp)** - An internal IF envelope trigger that occurs at the absolute threshold level of the IF signal level. This source is not available for ACP measurements.
- **Ext Front** - Activates the front-panel external trigger input (**EXT TRIGGER INPUT**) port. The external signal must be between -5.00 and $+5.00$ V with 1 mV resolution.
- **Ext Rear** - Activates the rear panel external trigger input (**TRIGGER IN**) port. The external signal must be between -5.00 and $+5.00$ V with 1 mV resolution.
- **Frame** - Uses the internal frame clock to generate a trigger signal. The clock parameters are controlled under the **Mode Setup** key or the measurement firmware, but not both. See the specific measurement for details.
- **Line** - Sets the trigger to the line mode. Sweep triggers occur at intervals synchronous to the line frequency. This trigger source is available for spectrum and waveform measurements.

The rear panel **TRIGGER 1 OUT** and **TRIGGER 2 OUT** connectors are coupled to the selected trigger source. These trigger outputs are always on at the rising edge with a pulse width of at least 1 μ s.

Making NADC Measurements

Preparing for Measurements

Burst Sync

This menu is only used for EVM measurements. Pressing the **Burst Sync** key allows you to choose the source used to synchronize the measurement to the “point 0” of the NADC burst. The “point 0” is defined as the start of symbol 1 in a timeslot. The **Search Threshold** setting in the **Burst** menu under **Mode Setup** applies to the **RF Amptd**. Pressing the **Burst Sync** key accesses the menu with some or all of the following choices:

- **Sync Word** - Synchronizes the measurement to the sync word which is one of the six possible 28-bit NADC timeslot synchronization words contained in the signal. This is the default when **Device** is set to **MS**.
- **RF Amptd** - Synchronizes the measurement to the rising edge of the bursted RF carrier.
- **None** - Measurements are made without synchronizing with the NADC burst. This is the default when **Device** is set to **BS**.

Making the Adjacent Channel Power Measurement

Purpose

To maintain a quality call by avoiding channel interference, it is quite important to measure and reduce an adjacent channel power (ACP) transmitted from an NADC mobile phone. The characteristics of adjacent channel power are mainly determined by the transmitter design, including a digital filter called a root Nyquist filter.

Adjacent channel power is defined by the NADC standard as the total power within the defined bandwidth, centered at Δf kHz offset from the carrier frequency. The carrier is modulated by the standard coding test signal which has the same coding speed as the NADC modulation signal. The following specifications from the TIA/EIA IS-136, IS-137 and IS-138 standards apply to both base stations and mobile stations:

- (1) At ± 30 kHz offsets: Less than -26 dBc
- (2) At ± 60 kHz offsets: Less than -45 dBc
- (3) At ± 90 kHz offsets: Less than -45 dBc or -13 dBm, whichever is the lowest power

For Tx power > 50 W: -60 dBc

Measurement Method

This measurement analyzes the total power levels within the defined bandwidth at given offset frequencies on both sides of the carrier frequency using Fast Fourier Transform (FFT). If **Offset Power** is set to **Integ** (integration), the total power within the 32.8 kHz bandwidth, using the root-raised cosine weighting filter, is measured at each offset frequency. The equivalent 3-dB bandwidth is 24.3 kHz. If **Offset Power** is set to **Peak**, the total peak power is measured with 1 kHz resolution bandwidth through the entire NADC bandwidth of 30 kHz.

The measurement functions, such as averaging, trigger source, limit test, offsets and limits, need to be set up to make a measurement and pass/fail test based on the NADC channel width and weighting prescribed in the NADC standard. The test result is displayed in either bar graph window or spectrum window. Both the absolute power levels and the power levels relative to the center power band are displayed in the text window. When **Spectrum View** is selected, the vertical scale can be varied for your optimum observation by pressing the **Amplitude Y Scale** front-panel key.

Making the Measurement

NOTE The factory default parameters provided for this measurement will give you an NADC compliant measurement for the instrument setup. You should be able to make a measurement often using these defaults.

Select the desired center frequency as described in “[Changing the Frequency Channel](#)” on page 42.


Press **Measure, ACP** to immediately make an adjacent channel power measurement.

To change any of the measurement parameters from the factory default values, refer to “[Changing the Measurement Setup](#)” on page 69 for this measurement.

Results

The next figure shows an example result of adjacent channel power measurements in the bar graph window. The power levels on both sides of the carrier frequency are displayed in the graph window and text window.

Figure 3-1 Adjacent Channel Power Measurement - Bar Graph View



Changing the Measurement Setup

The next table shows the factory default settings for adjacent channel power measurements.

Table 3-1 Adjacent Channel Power Measurement Defaults

Measurement Parameter	Factory Default Condition
View/Trace	Bar Graph
Meas Setup:	
Avg Number	10, On
Avg Mode	Repeat
Trig Source: (when Device is MS) (when Device is BS)	Free Run (Immediate) RF Burst (Wideband)
Limit Test	On
Ofs & Limits:	
Offset	A
Offset Freq:	
A	30.000 kHz, On
B	60.000 kHz, On
C	90.000 kHz, On
D	120.000 kHz, Off
E	0.0 Hz, Off
Offset Power	Integ
Abs Limit:	
A, B, D, E	0.00 dBm
C	-13.00 dBm
Fail:	
A, B	Relative
C	OR
D, E	AND
Rel Lim (Car):	
A	-26.00 dB
B, C	-45.00 dB
D, E	0.00 dB

Making NADC Measurements

Making the Adjacent Channel Power Measurement

Make sure the **ACP** measurement is selected under the **Measure** menu. The **Meas Setup** key accesses the menu which allows you to modify the average number, average mode and trigger source for this measurement as described in “[Measurement Setup](#)” on page 63. However, the trigger source does not include **Video** and **Line**. In addition, the following parameters for adjacent channel power measurements can be modified:

- **Limit Test** - Allows you to toggle the limit test function between **On** and **Off**. If set to **On**, **Abs Limit** and/or **Rel Lim (Car)** need to be specified to execute pass/fail tests with the logical judgement under the **Fail** key. Pass/fail results are shown in the active display window with the number of averages. In the text window, a red character F is shown on the right side of each measurement result, either relative or absolute, if it exceeds the limits with its logical judgement.
- **Ofs & Limits** - Allows you to access the menu to change the following parameters for pass/fail tests:

Offset - Allows you to access the memory selection menu to store 5 offset frequency values in **A** through **E**. Only one selection at a time (**A**, **B**, **C**, **D**, or **E**) is shown on this key label. The default selection is **A**.

Offset Freq - Allows you to enter an offset frequency value and toggle the offset frequency function between **On** and **Off**, according to each offset key selected. The allowable range is 0 Hz to 200.000 kHz. While this key is activated, enter an offset value from the numeric keypad by terminating with one of the frequency unit keys shown. For NADC measurements offsets **A**, **B** and **C** are defaulted to 30.000 kHz **On**, 60.000 kHz **On**, and 90.000 kHz **On**, respectively. Offset **D** is temporarily defaulted to 120.000 kHz **Off** while offset **E** is defaulted to 0.00 Hz **Off**. One offset frequency value selected from the **Offset** menu is shown on this key label. The default state shows 30.000 kHz **On**.

Offset Power - Allows you to select either one of the following power measurement methods:

Integ (integration) - Measures the total power within the NADC bandwidth of 32.8 kHz with the root-raised cosine weighting filter.

Peak - In a 1 kHz resolution bandwidth, the peak frequency amplitude across the 30 kHz channel is reported. When averaging is on, an rms average is computed prior to the peak selection. This creates a banded limit line measurement, similar to other standards which call for a close-in spurious response measurement. Limits can be relative or absolute. When the limits are relative, the average power in the reference channel, normalized to a 1 kHz bandwidth, is used to compute the ratio.

Abs Limit - Allows you to enter an absolute limit value ranging from -200.00 to $+50.00$ dBm with the best resolution of 0.01 dB. The default settings for offsets A, B, D and E are 0.00 dBm, while offset C is defaulted to -13.00 dBm to make the OR logical judgement with its relative limit of -45.00 dB.

Fail - Allows you to access the following menu to select one of the logic keys for fail conditions between the measurement results and the test limits:

AND - Fail is shown if one of the relative ACP measurement results is larger than **Rel Lim (Car)** AND one of the absolute ACP measurement results is larger than **Abs Limit**. This is the default setting for offsets D and E.

OR - Fail is shown if one of the relative ACP measurement results is larger than **Rel Lim (Car)** OR one of the absolute ACP measurement results is larger than **Abs Limit**. This is the default setting for offset C.

Absolute - Fail is shown if one of the absolute ACP measurement results is larger than **Abs Limit**.

Relative - Fail is shown if one of the relative ACP measurement results is larger than **Rel Lim (Car)**. This is the default setting for offsets A and B.

Rel Lim (Car)- Allows you to enter a relative limit value ranging from -200.00 to $+50.00$ dB with the best resolution of 0.01 dB. The default settings for offsets A, B and C are -26.00 , -45.00 and -45.00 dB, respectively, while offsets D and E are defaulted to 0.00 dB.

Making NADC Measurements

Making the Adjacent Channel Power Measurement


Changing the View

The **View/Trace** key accesses the menu which allows you to select the desired measurement view from the following selections:

- **Bar Graph** - In the factory default condition, 7 of the total integration power levels, centered at the carrier frequency and ± 30 kHz, ± 60 kHz and ± 90 kHz offset frequencies, are shown in the bar graph window. The corresponding measured data is shown in the text window as shown in [Figure 3-1 on page 68](#).
- **Spectrum** - Once this view is selected, [Figure 3-1 on page 68](#) changes as shown below. In the factory default condition, the swept frequency spectrum is displayed with the bandwidth marker lines in the spectrum graph window. The corresponding measured data in the text window is the total integration power within the defined bandwidth. While in this view, you can change the vertical scale by pressing the **Amplitude Y Scale** key.

Figure 3-2

Adjacent Channel Power Measurement - Spectrum View



Troubleshooting Hints

The adjacent channel power measurements suggest us numerous faults in the transmitter section of the UUT, as follows:

- (1) Faults caused by a malfunction of the baseband circuitry consisting of a code generator, a digital filter, digital-to-analog converters, 90-degree phase shifter, and I/Q modulators.
- (2) Faults due to high phase noise levels from the local oscillators.
- (3) Faults due to excessive noise floor levels from the up-converter, output amplifier, and/or analog filters.

Making the Error Vector Magnitude (EVM) Measurement

Purpose

Phase and frequency errors are the measures of modulation quality for the NADC system. Since the NADC system uses the $\pi/4$ DQPSK modulation technique, the phase and frequency accuracies of the NADC transmitter are critical to the communications system performance and ultimately affect range.

NADC receivers rely on the phase and frequency quality of the $\pi/4$ DQPSK modulation signal in order to achieve the expected carrier to noise ratio. A transmitter with high phase and frequency errors will often still be able to support phone calls during a functional test. However, it will tend to provide difficulty for mobiles trying to maintain service at the edge of the cell with low signal levels or under difficult fading and Doppler conditions.

Measurement Method

The phase error of the unit under test is measured by computing the difference between the phase of the transmitted signal and the phase of a theoretically perfect signal.

The instrument samples the transmitter output in order to capture the actual phase trajectory. This is then demodulated and the ideal phase trajectory is mathematically derived. Subtracting one from the other results in an error signal.

For base stations, the NADC standard specifies that the phase error should not exceed 5 degrees rms or 20 degrees peak, and that the mean frequency error across the burst must not exceed 0.05 ppm. These specifications hold true for normal and extreme temperature conditions, and with exposure to vibration.

This measurement allows you to display these errors numerically and graphically on the instrument display. There are graphs for EVM, Phase Error and Mag Error in the graph windows. In the text window, there are EVM: in % rms, in % peak at the highest symbol number, in % rms on the first 10 symbols (only when Device is MS), Mag Error: in % rms, Phase Error: in degrees, Freq Error: in Hz, and I/Q Offset: in dB.

Making the Measurement

NOTE

The factory default settings provide an NADC compliant measurement. For special requirements, you may need to change some of the settings. Press **Meas Setup, More (1 of 2), Restore Meas Defaults** at any time to return all parameters for the current measurement to their default settings.

Select the desired center frequency, burst type, and slot as described in [“Changing the Frequency Channel”](#) on page 42.

Press **Measure, EVM** to immediately make the error vector magnitude measurement.


To change any of the measurement parameters from the factory default values, refer to [“Changing the Measurement Setup”](#) below, for this measurement.

Results

The next figure shows an example of measurement result with the graphic and text windows. The measured summary data is shown on the left window and the dynamic vector trajectory of the I/Q demodulated signal is shown as a polar vector display in the right window. When **Device** is set to **MS**, the **First 10 Symbols EVM** result is also shown in the left window.

Figure 3-3

Error Vector Magnitude Measurement - Polar Vector View



Changing the Measurement Setup

The next table shows the factory default settings for error vector magnitude measurements.

Table 3-2 Error Vector Magnitude Measurement Defaults

Measurement Parameter	Factory Default Condition
Avg Number	10, On
Avg Mode	Exponential
Trigger Source	Free Run when Device is BS RF Burst when Device is MS
Burst Sync	None when Device is BS Sync Word when Device is MS
View/Trace	I/Q Measured Polar Vector
Limit Test	On
Limits: RMS EVM	12.5%
Limits: Peak EVM	40.0%
Limits: First 10 EVM (MS only)	25.0%
Limits: Origin Offset	-20 dB

Make sure the **Error Vector Magnitude (EVM)** measurement is selected under the **Measure** menu. The **Meas Setup** key accesses a menu which allows you to modify the averaging, trigger source and burst sync for this measurement as described in “[Measurement Setup](#)” earlier in this chapter. However, the trigger source does not include **Line**. In addition, the following error vector magnitude measurement parameters can be modified:

- **Limit Test** - Allows you to toggle the limit test function between **On** and **Off**. If set to **On**, the **Limits** key needs to be pressed to specify the limit values for rms EVM, peak EVM and origin offset. Pass/fail results are shown in the active display window with the number of averages.
- **Limits** - Allows you to access the menu to change the following test parameter limits:
 - RMS EVM** - Allows you to enter a limit value ranging from 0.0 to 50.0% for the pass/fail test of the rms error vector magnitude measured on all of the symbols. The default setting is 12.5%.
 - Peak EVM** - Allows you to enter a limit value ranging from 0.0 to 50.0% for the pass/fail test of the peak error vector magnitude measured on all of the symbols. The default setting is 40.0%.

First 10 EVM (MS only) - Allows you to enter a limit value ranging from 0.0 to 50.0% for the Pass/Fail test of the error vector magnitude measured on the first 10 symbols. The default setting is 25.0%. This is valid when **Devise** is set to **MS**

Origin Offset - Allows you to enter an offset value ranging from -100.00 to 0.00 dB for the pass/fail test of the origin offset. The default setting is -20.00 dB.


Changing the View

The **View/Trace** key accesses the menu which allows you to select the desired measurement view from the following selections:

- **I/Q Measured Polar Vector** - The measured summary data is shown in the left window and the dynamic vector trajectory of the I/Q demodulated signal is shown as a polar vector display in the right window, as shown in [Figure 3-3 on page 75](#).
- **I/Q Measured Polar Constln** - The measured summary data is shown in the left window and the dynamic vector constellation of the I/Q demodulated signal is shown as a polar vector display in the right window, as shown in [Figure 3-4](#).
- **I/Q Error (Quad-View)** - Four display windows show EVM, Mag Error and Phase Error graphs, and the EVM summary data text.

Figure 3-4

Error Vector Magnitude Measurement - Polar Constln




Making NADC Measurements

Making the Error Vector Magnitude (EVM) Measurement

Figure 3-5

Error Vector Magnitude Measurement - Quad View



Changing the Display

The **Display** key accesses the menu to allow the following selections for changing the graph displays:

- **Pts/Symb Displayed** - Allows you to specify the number of displayed points per symbol, either 1 or 5. The default setting is 5.
- **Symbol Dots** - Allows you to toggle the symbol dots between **On** and **Off**. The default setting is **On**.

When either EVM, Phase Error or Mag Error window is active in the I/Q Error (Quad-View) display, the **Span X Scale** key accesses the menu to allow the following selections:

- **Scale/Div** - Allows you to define the horizontal scale by changing the symbol value per division. The range is 1 to 100 symbols per division. The default setting is 16.1 (for BS) or 15.6 for MS) symbols per division.
- **Ref Value** - Allows you to set the symbol reference value ranging from 0 to 1000 symbols. The default setting is 0.
- **Ref Position** - Allows you to set the reference position to either **Left**, **Ctr** (center) or **Right**. The default setting is **Left**.
- **Scale Coupling** - Allows you to toggle the scale coupling function between **On** and **Off**. The default setting is **On**. This function automatically determines the scale per division and reference value by the magnitude of the measurement results.

When either `EVM:` or `Mag Error:` window is active in the I/Q Error (Quad-View) display, the **Amplitude Y Scale** key accesses the menu to allow the following selections:

- **Scale/Div** - Allows you to define the vertical scale by changing the value per division. The range is 0.1 to 50% per division. The default setting is 20.0%. However, since the **Scale Coupling** default is set to **On**, this value is automatically determined by the measurement results.
- **Ref Value** - Allows you to set the reference value ranging from 0 to 500%. The default setting is 0%.
- **Ref Position** - Allows you to set the reference position to either **Top**, **Ctr** (center) or **Bot** (bottom). For the `EVM:` graph, the default setting is **Bot**. For the `Mag Error:` graph the default setting is **Ctr**.
- **Scale Coupling** - Allows you to toggle the scale coupling function between **On** and **Off**. The default setting is **On**. This function automatically determines the scale per division and reference value by the magnitude of the measurement results.

When the `Phase Error:` window is active in the I/Q Error display, the **Amplitude Y Scale** key accesses the menu to allow the following selections:

- **Scale/Div** - Allows you to define the vertical scale by changing the value per division. The range is 0.01 to 3600 degrees. The default setting is 20.0 degrees per division. However, since the **Scale Coupling** default is set to **On**, this value is automatically determined by the measurement results.
- **Ref Value** - Allows you to set the reference value ranging from 0 to 500%. The default setting is 0%.
- **Ref Position** - Allows you to set the reference position to either **Top**, **Ctr** (center) or **Bot** (bottom). For the EVM graph, the default setting is **Bot**. For the `Mag Error` graph, the default setting is **Ctr**.
- **Scale Coupling** - Allows you to toggle the scale coupling function between **On** and **Off**. The default setting is **On**. This function automatically determines the scale per division and reference value by the magnitude of the measurement results.

Troubleshooting Hints

First use the spectrum (frequency domain) measurement to verify that the signal is present and approximately centered on the display.

Poor phase error indicates a problem at the I/Q baseband generator, filters, and/or modulator in the transmitter circuitry. The output amplifier in the transmitter can also create distortion that causes unacceptably high phase error. In a real system, poor phase error will reduce the ability of a receiver to correctly demodulate the signal, especially in marginal signal conditions.

Making the Spectrum (Frequency Domain) Measurement

Purpose

The spectrum measurement provides spectrum analysis capability for the instrument. The control of the measurement was designed to be familiar to those who are accustomed to using swept spectrum analyzers.

This measurement is FFT (Fast Fourier Transform) based. The FFT-specific parameters are located in the **Advanced** menu. Also available under basic mode spectrum measurements is an I/Q window, which shows the I and Q signal waveforms in parameters of voltage versus time. The advantage of having an I/Q view available while in the spectrum measurement is that it allows you to view complex components of the same signal without changing settings or measurements.

Measurement Method

The measurement uses digital signal processing to sample the input signal and convert it to the frequency domain. With the instrument tuned to a fixed center frequency, samples are digitized at a high rate, converted to I and Q components with DSP hardware, and then converted to the frequency domain with FFT software.

Making the Measurement

NOTE

The factory default parameters provide a good starting point. You will likely want to change some of the settings. Press **Meas Setup, More (1 of 2), Restore Meas Defaults** at any time to return all parameters for the current measurement to their default settings.

Press **Measure, Spectrum (Freq Domain)** to immediately make a spectrum measurement.

To change any of the measurement parameters from the factory default values, refer to the “Changing the Measurement Setup” section for this measurement.

Making NADC Measurements


Making the Spectrum (Frequency Domain) Measurement

Results

A display with both a Spectrum window and an I/Q Waveform window will appear when you activate a spectrum measurement. Use the **Next Window** key to select a window, and the **Zoom** key to enlarge a window.

Figure 3-6

Spectrum Measurement - Spectrum and I/Q Waveform View



Changing the Measurement Setup

The following table shows the factory default settings for spectrum (frequency domain) measurements.

Table 3-3

Spectrum (Frequency Domain) Measurement Defaults

Measurement Parameter	Factory Default Condition
View/Trace	Spectrum
Trace Display	All
Res BW	20.0000 kHz; Auto
Averaging:	
Avg Number	25; On
Avg Mode	Exp
Avg Type	Log-Pwr Avg (Video)
Trig Source	Free Run (Immediate)
Spectrum View:	
SPAN	1.00000 MHz
AMPLITUDE Y Scale - Scale/Div	10.00 dB
I/Q Waveform View:	
Capture Time	188.00 μ s
AMPLITUDE Y Scale - Scale/Div	100.0 mV
Advanced	
Pre-ADC BPF	On
Pre-FFT Filter	Flat
Pre-FFT BW	1.55000 MHz; Auto
FFT Window	Flat Top (High Amptd Acc)
FFT Size:	
Length Control	Auto
Min Points/RBW	3.100000
Window Length	706
FFT Length	1024
ADC Range	Auto Peak
Data Packing	Auto
ADC Dither	Auto
Decimation	0; Auto
IF Flatness	On

Making NADC Measurements

Making the Spectrum (Frequency Domain) Measurement

NOTE

Parameters under the **Advanced** key seldom need to be changed. Any changes from the default advanced values may result in invalid measurement data.

Make sure the **Spectrum (Freq Domain)** measurement is selected under the **Measure** menu. Press the **Meas Setup** key to access a menu which allows you to modify the averaging and trigger source for this measurement (as described in the “Measurement Setup” section). In addition, the following parameters can be modified:

- **Span** - Allows you to modify the frequency span. The range is 10.000 Hz to 10.000 MHz with 1 Hz resolution, depending on the **Res BW** setting. Changing the span causes the resolution bandwidth to change automatically, and will affect data acquisition time.
- **Res BW** - Allows you to set the resolution bandwidth for the FFT, and to toggle its mode between **Auto** and **Man** (manual). If set to **Auto**, the resolution bandwidth is set to **Span/50** (2% of the span). If set to **Man**, you can enter a value ranging from 100.0 mHz to 3.00000 MHz. A narrower bandwidth will result in a longer data acquisition time.
- **Advanced** - Allows you to access the menu to change the following parameters. The FFT advanced features should be used only if you are familiar with their operation. Changes from the default values may result in invalid data.
 - **Pre-ADC BPF** - Allows you to toggle the pre-ADC bandpass filter function between **On** and **Off**. The pre-ADC bandpass filter is useful for rejecting nearby signals, so that sensitivity within the span range can be improved by increasing the ADC range gain.
 - **Pre-FFT Fitr** - Allows you to toggle the pre-FFT filter between **Flat** (flat top) and **Gaussian**. The pre-FFT filter defaults to a flat top filter which has better amplitude accuracy. The Gaussian filter has better pulse response.
 - **Pre-FFT BW** - Allows you to toggle the pre-FFT bandwidth function between **Auto** and **Man** (manual). The pre-FFT bandwidth filter can be set between 1 Hz and 10 MHz. If set to **Auto**, this pre-FFT bandwidth is nominally 50% wider than the span. This bandwidth determines the ADC sampling rate.
 - **FFT Window** - Allows you to access the following selection menu. Unless you are familiar with FFT windows, use the flat top filter (the default filter).
 - **Flat Top** - Selects this filter for best amplitude accuracy by reducing scalloping error.
 - **Uniform** - Select this filter to have no window active by using the uniform setting.

- **Hanning** - Press this key to activate the Hanning filter.
 - **Hamming** - Press this key to activate the Hamming filter.
 - **Gaussian** - Press this key to activate the Gaussian filter with the roll-off factor (alpha) of 3.5.
 - **Blackman** - Press this key to activate the Hamming filter.
 - **Blackman Harris** - Press this key to activate the Hamming filter.
 - **K-B 70dB/90dB/110dB (Kaiser-Bessel)** - Select one of the Kaiser-Bessel filters with sidelobes at -70 , -90 , or -110 dBc.
- **FFT Size** - Allows you to access the menu to change the following parameters:
- **Length Ctrl** - Allows you to toggle the FFT and window length setting function between **Auto** and **Man** (manual).
 - **Min Pts in RBW** - Allows you to set the minimum number of data points that will be used inside the resolution bandwidth. The range is 0.10 to 100.00 points with 0.01 resolution. This key is grayed out if **Length Ctrl** is set to **Man**.
 - **Window Length** - Allows you to enter the FFT window length in the number of capture samples, ranging from 8 to 1048576. This length represents the actual quantity of I/Q samples that are captured for processing by the FFT (“Capture Time” is the associated parameter shown on the screen). This key is grayed out if **Length Control** is set to **Auto**.
 - **FFT Length** - Allows you to enter the FFT length in the number of captured samples, ranging from 8 to 1048576. The FFT length setting is automatically limited so that it is equal to or greater than the FFT window length setting. Any amount greater than the window length is implemented by zero-padding. This key is grayed out if **Length Control** is set to **Auto**.
- **ADC Range** - Allows you to access the menu to define one of the following ADC ranging functions:
- **Auto** - Select this to set the ADC range automatically. For most FFT spectrum measurements, the auto feature should not be selected. An exception is when measuring a signal which is “bursty”, in which case auto can maximize the time domain dynamic range, if FFT results are less important to you than time domain results.
 - **Auto Peak** - Select this to set the ADC range automatically to the peak signal level. Auto peak is a compromise that works well for both CW and burst signals.

Making NADC Measurements

Making the Spectrum (Frequency Domain) Measurement

- **Auto Peak Lock** - Select this to hold the ADC range automatically at the peak signal level. Auto peak lock is more stable than auto peak for CW signals, but should not be used for “bursty” signals.
- **Manual** - Allows you to access the selection menu of values to set the ADC range level. Also note that manual ranging is best for CW signals.
- **Data Packing** - Allows you to select **Auto** (the default) or the **Short (16 bit)**, **Medium (24 bit)** and **Long (32 bit)** methods of data packing. The short, medium, and long methods are not compatible with all settings and should not be used unless you are familiar with data packing methods. **Auto** is the preferred choice.
 - **Auto** - The data packing value most appropriate for current instrument settings is selected automatically.
 - **Short (16 bit)** - Select this to pack data every 16 bits.
 - **Medium (24 bit)** - Select this to pack data every 24 bits.
 - **Long (32 bit)** - Select this to pack data every 32 bits.
- **ADC Dither** - Allows you to toggle the ADC dither function between **Auto**, **On**, and **Off**. When set to **Auto** (the default), the ADC dither function will be activated when a narrow bandwidth is being measured, and deactivated when a wide bandwidth is being measured. “ADC dither” refers to the introduction of noise to the digitized steps of the analog-to-digital converter; the result is an improvement in amplitude accuracy. Use of the ADC dither, however, reduces dynamic range by approximately 3 dB.
- **Decimation** - Allows you to toggle the decimation function between **Auto** and **Man**, and to set the decimation value. **Auto** is the preferred setting, and the only setting that guarantees alias-free FFT spectrum measurements. If you are familiar with the decimation feature, you can change the decimation value by setting to **Man**, but be aware that aliasing can result in higher values. Decimation numbers 1 to 1000 describe the factor by which the number of points are reduced. The default setting is 0, which results in no data point reduction. Decimation by 3 keeps every 3rd sample, throwing away the 2 in between.
- **IF Flatness** - Allows you to toggle the IF flatness function between **On** and **Off**. If set to **On** (the default), the IF flatness feature causes background amplitude corrections to be performed on the FFT spectrum. The **Off** setting is used for adjustment and troubleshooting of the test instrument.

Changing the View

The View/Trace key allows you to select the desired view of the measurement from the following. You can use the Next Window key to move between the multiple windows (if any) and make it full size by Zoom.

- **Spectrum** - Provides a combination view of the spectrum graph in parameters of power versus frequency with the semi-log graticules, and the I/Q waveform graph in the parameters of voltage and time. Changes to frequency span or power will sometimes affect data acquisition.
- **I/Q Waveform** - Provides a view of the I/Q waveform graph in parameters of voltage versus time in the linear graticules. Changes to sweep time or resolution bandwidth will sometimes affect data acquisition.

Changing the Display

The **Span** key under the **Meas Setup** menu controls the horizontal span of the spectrum window. If the **SPAN X Scale** key is pressed, this **Span** key is activated, while the **AMPLITUDE Y Scale** key allows you to access the menus to modify the vertical parameters depending on the selected windows.

Changing the Spectrum Display

If the window is active in the **Spectrum** view, the **SPAN X Scale** and **AMPLITUDE Y Scale** keys access the menus to modify the following parameters:

- With the **SPAN X Scale** key:
 - **Span** - Allows you to modify the frequency span. The range is 10.000 Hz to 10.000 MHz with 1 Hz resolution, depending on the **Res BW** setting. Changing the span causes the resolution bandwidth to change automatically, and will affect data acquisition time.
- With the **AMPLITUDE Y Scale** key:
 - **Scale/Div** - Allows you to set the vertical scale by changing an amplitude value per division. The range is 1.00 nV to 20.00 V per division. The default setting is 100.0 mV. However, since the **Scale Coupling** default is **On**, this value is automatically determined by the measurement results. To manually set this value **Scale Coupling** must be **Off**.
 - **Ref Value** - Allows you to set the reference value ranging from -250.00 to 250.00 V. The default setting is 0.00 V. However, since the **Scale Coupling** default is **On**, this value is automatically determined by the measurement results. To manually set this value **Scale Coupling** must be **Off**.
 - **Ref Position** - Allows you to set the reference position to either **Top**, **Ctr** (center) or **Bot** (bottom). The default setting is **Ctr**.
 - **Scale Coupling** - Allows you to toggle the scale coupling function between **On** and **Off**. The default setting is **On**. Upon pressing the **Restart** front-panel key or **Restart** softkey under the **Meas Control** menu, this function automatically determines the scale per division and reference values based on the measurement results. To manually set either **Scale/Div** or **Ref Value** values, **Scale Coupling** must be **Off**.

Selecting Displayed Traces Within Windows

The **View/Trace** key allows you to access the **Trace Display** key to reveal the trace selection menu. The currently selected trace type is shown on the **Trace Display** key.

- **All** - Allows you to view both the current trace and the average trace.
- **Average** - Allows you to view only the average trace (in blue color).
- **Current** - Allows you to view only the trace (in yellow color) for the latest data acquisition.

Using the Markers

The **Marker** front-panel key accesses the menu to configure the markers. If you want to use the marker function in the I/Q waveform window, press **Marker**, **Trace**, **I/Q Waveform**.

- **Select 1 2 3 4** - Allows you to activate up to four markers with the corresponding numbers, respectively. The selected number is underlined and its function is defined by pressing the **Function** key. The default is 1.
- **Normal** - Allows you to activate the selected marker to read the frequency and amplitude of the marker position on the spectrum trace. Marker position is controlled by the **RPG** knob.
- **Delta** - Allows you to read the differences in frequencies and amplitudes between the selected marker and the next.
- **Function Off** - Allows you to define the selected marker function to be **Band Power**, **Noise**, or **Off**. The default is **Off**. If set to **Band Power**, you need to select **Delta**.
- **Trace Spectrum** - Allows you to place the selected marker on the **Spectrum**, **Spectrum Avg**, or **I/Q Waveform** trace. The default is **Spectrum**.
- **Off** - Allows you to turn off the selected marker.
- **Shape Diamond** - Allows you to access the menu to define the selected marker shape to be **Diamond**, **Line**, **Square**, or **Cross**. The default shape is **Diamond**.
- **Marker All Off** - Allows you to turn off all of the markers.

The front panel **Search** key performs a peak search when pressed. A marker will automatically be activated at the highest peak.

Measuring Band Power

A band power measurement using the markers calculates the average power between two adjustable markers. To make a band power measurement:

1. Press the **Marker** key.
2. Press **Trace**, **Spectrum** to activate a marker on the instantaneous spectrum signal.
3. Press the **Spectrum Avg** key to activate a marker on the average spectrum trace.
4. Press **Function**, **Band Power**.
5. Two marker lines are activated at the extreme left side of the horizontal scale. Press **Normal** and move marker 1 to the desired place by rotating the **RPG** knob.

6. Press **Delta** to bring marker 2 to the same place as marker 1.
7. Move marker 1 to the other desired position by rotating the **RPG** knob. Band power measures the average power between the two markers.
8. When the band power markers are active, the results are shown in the results window as `Mean Pwr (Between Mks)`. When the band power function is off the results window reads `Mean Pwr (Entire Trace)`.

Troubleshooting Hints

Changes made by the user to advanced spectrum settings, particularly to ADC range settings, can inadvertently result in spectrum measurements that are invalid and cause error messages to appear. Care needs to be taken when using advanced features.

Making the Waveform (Time Domain) Measurement

Purpose

The waveform measurement is a generic measurement for viewing the input signal waveforms in the time domain. This measurement is how the instrument performs the zero span functionality found in traditional spectrum analyzers. Also available under basic mode waveform measurements is an I/Q window, which shows the I and Q signal waveforms in parameters of voltage versus time. The advantage of having an I/Q view available while in the waveform measurement is that it allows you to view complex components of the same signal without changing settings or measurements.

The waveform measurement can be used to perform general purpose power measurements to a high degree of accuracy.

Measurement Method

The instrument makes repeated power measurements at a set frequency, similar to the way a swept-tuned spectrum analyzer makes zero span measurements. The input analog signal is converted to a digital signal, which then is processed into a representation of a waveform measurement. The measurement relies on a high rates of sampling to create an accurate representation of a time domain signal.

This measurement is available for use with both the RF input and baseband I/Q inputs. For details on Baseband I/Q operation see the section on [“Using Option B7C Baseband I/Q Inputs”](#).

Making the Measurement

NOTE

The factory default parameters provide a good starting point. You may want to change some of the settings. Press Meas Setup, More (1 of 2), Restore Meas Defaults at any time to return all parameters for the current measurement to their default settings.

Press **MEASURE, Waveform (Time Domain)** to immediately make a waveform (time domain) measurement.


To change any of the measurement parameters from the factory default values, refer to the [“Changing the Measurement Setup”](#) section for this measurement.

Results

The next figure shows an example of an RF Envelope result for the waveform (time domain) measurements in the graph window. The measured values for the mean power and peak-to-mean power are shown in the text window.

Figure 3-7

Waveform Measurement - RF Envelope View



Changing the Measurement Setup

This table shows the factory default settings for waveform (time domain) measurements.

Table 3-4

Waveform (Time Domain) Measurement Defaults

Measurement Parameter	Factory Default Condition
View/Trace	RF Envelope
Sweep Time	10.00 ms
Res BW	100.000 kHz
Averaging:	
Avg Number	10; Off
Avg Mode	Exp
Avg Type	Pwr Avg (RMS)
Trig Source	Free Run (Immediate)

Table 3-4 **Waveform (Time Domain) Measurement Defaults**

Measurement Parameter	Factory Default Condition
RF Envelope View: SPAN X Scale - Scale/Div AMPLITUDE Y Scale - Scale/Div	200.0 μ s 10.00 dB
I/Q Waveform View: SPAN X Scale -Scale/Div AMPLITUDE Y Scale - Scale/Div	200.0 μ s 100.0 mV
Advanced	
Pre-ADC BPF	Off
RBW Filter	Gaussian
ADC Range	Auto
Data Packing	Auto
ADC Dither	Off
Decimation	Off

NOTE Parameters that are under the **Advanced** key seldom need to be changed. Any changes from the default values may result in invalid measurement data.

Make sure the **Waveform (Time Domain)** measurement is selected under the **MEASURE** menu. Press the **Meas Setup** key to access a menu which allows you to modify the averaging, and trigger source for this measurement (as described in the “Measurement Setup” section).

In addition, the following parameters can be modified:

- **Sweep Time** - Allows you to specify the measurement acquisition time which is used as the length of the time capture record. The range is 1.0 μ s and 100.0 s, depending upon the resolution bandwidth setting and the available internal memory size for acquisition points.
- **Res BW** - Allows you to set the measurement bandwidth. The range is 10 Hz to 7.5 MHz. A larger bandwidth results in a larger number of acquisition points and reduces the maximum value allowed for the sweep time.
- **Advanced** - Allows you to access the menu to change the following parameters. Changes from the default values may result in invalid data.

- **Pre-ADC BPF** - Allows you to toggle the pre-ADC bandpass filter function between **On** or **Off**. The default setting is **Off**. The pre-ADC bandpass filter is useful for rejecting nearby signals, so that sensitivity within the span range can be improved by increasing the ADC range gain.
- **RBW Filter** - Allows you toggle the resolution bandwidth filter selection between **Flat** and **Gaussian**. If set to **Gaussian**, the filter provides more even time-domain response, particularly for “bursts”. If set to **Flat**, the filter provides a flatter bandwidth but is less accurate for “pulse responses”. A flat top filter also requires less memory and allows longer data acquisition times. For most waveform applications, the Gaussian filter is recommended.
- **ADC Range** - Allows you to access the menu to select one of the ADC ranging functions:
 - **Auto** - Select this to cause the instrument to automatically adjust the signal range for optimal measurement results.
 - **AutoPeak** - Select this to cause the instrument to continuously seek the highest peak signal.
 - **AutoPeakLock** - Select this to cause the instrument to adjust the range for the highest peak signal it identifies, and retains the range settings determined by that peak signal, even when the peak signal is no longer present.
 - **Manual** - Allows you to access the selection menu of values to set the ADC range level. Also note that manual ranging is best for CW signals.
- **Data Packing** - Allows you to select **Auto** (the default) or the **Short (16 bit)**, **Medium (24 bit)** and **Long (32 bit)** methods of data packing. The short, medium, and long methods are not compatible with all settings and should not be used unless you are familiar with data packing methods. **Auto** is the preferred choice.
 - **Auto** - The data packing value most appropriate for current instrument settings is selected automatically.
 - **Short (16 bit)** - Select this to pack data every 16 bits.
 - **Medium (24 bit)** - Select this to pack data every 24 bits.
 - **Long (32 bit)** - Select this to pack data every 32 bits.
- **ADC Dither** - Allows you to toggle the ADC dither function between **On** and **Off**. The default setting is **Off**. If set to **On**, the ADC dither refers to the introduction of noise to the digitized steps of the analog-to-digital converter, and results in better amplitude linearity and resolution in low level signals. However, it also results in reduced dynamic range by approximately 3 dB.

Making NADC Measurements

Making the Waveform (Time Domain) Measurement

- **Decimation** - Allows you to toggle the decimation function between **On** and **Off**, and to set the decimation value. Decimation allows longer acquisition times for a given bandwidth by eliminating data points. Long time captures can be limited by the instrument data acquisition memory. Decimation numbers 1 to 4 describe the factor by which the number of points are reduced. The default setting is 1, which results in no data point reduction.

Changing the View


The **Trace/View** key allows you to access the selection menu for the desired measurement view. You can use the **Next Window** key to move between the multiple windows (if any) and make it full size by **Zoom**.

Windows Available for Waveform Measurements

The following views are available to display measurement data, and are accessed by pressing the **Trace/View** key:


- **RF Envelope** - Provides a combination view of the waveform graph in parameters of power versus time with the semi-log graticules, and the measurement results for Mean Pwr (Entire Trace), Pk-to-Mean, Current Data for Max Pt and Min Pt are shown in the text window. Changes to sweep time or resolution bandwidth will sometimes affect data acquisition.

Figure 3-8 Waveform Measurement - RF Envelope View



I/Q Waveform - Provides a view of the I/Q waveform graph in parameters of voltage versus time in the linear graticules. Changes to sweep time or resolution bandwidth will sometimes affect data acquisition.

Figure 3-9 Waveform Measurement - I/Q Waveform View



Changing the Display

The **Sweep Time** key under the **Meas Setup** menu controls the horizontal time span for this measurement, while the **SPAN X Scale** key allows you to access the menu to modify the horizontal parameters common to the rectangular windows for this measurement:

- **Scale/Div** - Allows you to set the horizontal scale by changing a time value per division. The range is 1.0 ns to 1.000 s per division with 0.01 ns resolution. The default setting is 200.0 μ s per division. When the **Scale Coupling** default setting **On** is in effect, displayed plots use a Scale/Div value determined by the analyzer, based on the measurement result.
- **Ref Value** - Allows you to set the reference value ranging from -1.0 to 10.0 s. The default setting is 0.00 s. When the **Scale Coupling** default setting **On** is in effect, displayed plots use a Scale/Div value determined by the analyzer, based on the measurement result.
- **Ref Position** - Allows you to set the reference position to either **Left**, **Ctr** (center) or **Right**. The default setting is **Left**.

Making NADC Measurements

Making the Waveform (Time Domain) Measurement

- **Scale Coupling** - Allows you to toggle the scale coupling function between **On** and **Off**. The default setting is **On**. Upon pressing the **Restart** front-panel key or **Restart** softkey under the **Meas Control** menu, this function automatically determines the scale per division and reference values based on the measurement results.

If the RF Envelope window is active in the RF Envelope view, the **AMPLITUDE Y Scale** key accesses the menu to modify the following parameters:

- **Scale/Div** - Allows you to set the vertical scale by changing an amplitude value per division. The range is 0.10 to 20.00 dB per division with 0.01 dB resolution. The default setting is 10.00 dB per division. When the **Scale Coupling** default setting **On** is in effect, displayed plots use a Scale/Div value determined by the analyzer, based on the measurement result.
- **Ref Value** - Allows you to set the reference value ranging from -250.00 to 250.00 dBm. The default setting is 0.00 dBm. When the **Scale Coupling** default setting **On** is in effect, displayed plots use a Scale/Div value determined by the analyzer, based on the measurement result.
- **Ref Position** - Allows you to set the reference position to either **Top**, **Ctr** (center) or **Bot** (bottom). The default setting is **Top**.
- **Scale Coupling** - Allows you to toggle the scale coupling function between **On** and **Off**. The default setting is **On**. Upon pressing the **Restart** front-panel key or **Restart** softkey under the **Meas Control** menu, this function automatically determines the scale per division and reference values based on the measurement results.

If the I/Q Waveform window is active in the I/Q Waveform view, the **AMPLITUDE Y Scale** key accesses the menu to modify the following parameters:

- **Scale/Div** - Allows you to set the vertical scale by changing an amplitude value per division. The range is 1.00 nV to 20.00 V per division. The default setting is 100.0 mV. When the **Scale Coupling** default setting **On** is in effect, displayed plots use a Scale/Div value determined by the analyzer, based on the measurement result.
- **Ref Value** - Allows you to set the reference value ranging from -250.00 to 250.00 V. The default setting is 0.00 V. When the **Scale Coupling** default setting **On** is in effect, displayed plots use a Scale/Div value determined by the analyzer, based on the measurement result.
- **Ref Position** - Allows you to set the reference position to either **Top**, **Ctr** (center) or **Bot** (bottom). The default setting is **Ctr**.
- **Scale Coupling** - Allows you to toggle the scale coupling function between **On** and **Off**. The default setting is **On**. Upon pressing the

Restart front-panel key or **Restart** softkey under the **Meas Control** menu, this function automatically determines the scale per division and reference values based on the measurement results.

The **Display** key is not available for this measurement.

Using the Markers

The **Marker** front-panel key accesses the menu to configure the markers.

- **Select 1 2 3 4** - Allows you to activate up to four markers with the corresponding numbers, respectively. The selected number is underlined and its function is defined by pressing the **Function** key. The default is 1.
- **Normal** - Allows you to activate the selected marker to read the time position and amplitude of the marker on the RF envelope trace. Marker position is controlled by the **RPG** knob.
- **Delta** - Allows you to read the differences in time positions and amplitudes between the selected marker and the next.
- **Function Off** - Allows you to define the selected marker function to be **Band Power**, **Noise**, or **Off**. The default is **Off**. If set to **Band Power**, you need to select **Delta**.
- **Trace** - Allows you to place the selected marker on **RF Envelope**, or **I/Q Waveform**.
- **Off** - Allows you to turn off the selected marker.
- **Shape Diamond** - Allows you to access the menu to define the selected marker shape to be **Diamond**, **Line**, **Square**, or **Cross**. The default shape is **Diamond**.
- **Marker All Off** - Allows you to turn off all of the markers.

The front panel **Search** key performs a peak search when pressed. A marker will automatically be activated at the highest peak.

NOTE

In the Waveform measurement, the **Mean Pwr (Entire Trace)** value plus the **Pk-to-Mean** value will sum to equal the current **Max Pt.** value as shown in the data window below the RF Envelope display. If you do a marker peak search (**Search**) with averaging turned off, the marker will find the same maximum point. However, if you turn averaging on, the **Pk-to-Mean** value will use the highest peak found for any acquisition during averaging, while the marker peak will look for the peak of the display, which is the result of n-averages. This will usually result in differing values for the maximum point.

Troubleshooting Hints

Changes made to advanced waveform settings can inadvertently result in measurements that are invalid and cause error messages to appear. Care needs to be taken when using advanced features, as some settings may incorrectly appear to provide a valid result. Use the Meas Setup, More, Restore Meas Defaults function to return the measurement settings to a known state, and then vary settings only as necessary.

4

NADC Programming Commands

These commands are only available when the NADC mode has been selected using `INSTRUMENT:SElect NADC`. If NADC mode is selected, commands that are unique to another mode are not available.

SCPI Command Subsystems

- “CALCulate Subsystem” on page 108.
- “CONFigure Subsystem” on page 130.
- “DISPlay Subsystem” on page 131.
- “FETCh Subsystem” on page 140.
- “FORMat Subsystem” on page 141.
- “INITiate Subsystem” on page 143.
- “INSTRument Subsystem” on page 145.
- “MEASure Group of Commands” on page 148.
- “READ Subsystem” on page 166.
- “SENSe Subsystem” on page 167.
- “TRIGger Subsystem” on page 203.

Programming Command Compatibility Across Model Numbers and Across Modes

Across PSA Modes: Command Subsystem Similarities

When you select different modes you get different sets of available programming commands. That is, *only* the commands that are appropriate for the current mode are available. Also, some commands have the same syntax in different modes but have different ranges or settings that are only appropriate to the current mode.

The following table shows which command subsystems are the same across different modes. If there is no “X” by a particular subsystem, then the set of available commands is different in those modes. Command ranges or defaults may also be different. Refer to the programming command descriptions in the documentation for each mode for details.

Command Subsystem	Same command set is available: SA mode compared with the application modes: W-CDMA, cdmaOne, cdma2000, Basic, GSM, EDGE, NADC, or PDC	Same command set is available: SA mode compared with the application mode: Phase Noise
IEEE common commands	X	X
ABORt	X	X
CALCulate		
CALibration	X	X
CONFigure		
COUPlE	not available in these application modes	not available in this application modes
DISPlay		
FETCh		
FORMat		X
HCOPy	X	X
INITiate		
INPut	not available in these application modes	X

NADC Programming Commands
 Programming Command Compatibility Across Model Numbers and Across Modes

Command Subsystem	Same command set is available: SA mode compared with the application modes: W-CDMA, cdmaOne, cdma2000, Basic, GSM, EDGE, NADC, or PDC	Same command set is available: SA mode compared with the application mode: Phase Noise
MEASure		
MEMory	X	X
MMEMory	X	X
MMEMory:STORe:TRACe	not available in application modes	X
READ		
[SENSe] [SENSe:]CHANnel [SENSe:]CORRection [SENSe:]FEED [SENSe:]FREQUency:CENTer [SENSe:]FREQUency: <other subsystems> [SENSe:]<measurement> [SENSe:]POWer [SENSe:]RADio [SENSe:]SYNC	X not available in application modes	 not available in application modes
STATus	X	X
SYSTem	X	X
TRACe	not available in application modes	X
TRIGger		
UNIT	X	X

Across PSA Modes: Specific Command Differences

Some programming commands operate differently depending on which Mode the analyzer is set to.

Command	Spectrum Analysis and Phase Noise Mode	Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, PDC Modes
*RST	Resets instrument, putting it in continuous measurement mode and turning off the current measurement.	Resets instrument, putting it in continuous measurement mode, but leaving the current measurement active.
CONFigure: <measurement>	Accesses the measurement and sets the instrument settings to the defaults. Averaging is turned on and set to 10. The instrument is put in single measurement mode. It does not initiate a measurement. Use INIT:IMM to make one measurement.	Accesses the measurement and sets the instrument settings to the defaults. If you were already in single measurement mode, it takes one measurement and then waits. If you were in continuous measurement mode it continues to measure.
*ESE default	Default is 255 which means that every error/status bit change that has occurred will be returned with a *ESR? query. You must set the value of *ESE to choose only the bits/status that you want returned.	Default is 0 which means that none of the error/status bit changes that have occurred will be returned with a *ESR? query. You must set the value of *ESE to choose the bits/status that you want returned.
TRIGger commands	For these modes, only one trigger source can be selected and it will be common across the modes. Also, only one value can be set for the trigger delay, level, or polarity.	For these modes, a unique trigger source can be selected for each mode. Also, each trigger source can have unique settings for the its delay, level, and polarity.
Saving and recalling traces	Traces can only be saved when in the Spectrum Analysis mode (MMEM:STOR:TRAC). This is because the instrument state must be saved along with the trace data and the state data varies depending on the number of modes currently available in the instrument.	

Using Applications in PSA Series vs. VSA E4406A

NOTE This information *only* applies to the application modes: Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, and PDC.

Command	PSA Series	VSA E4406A: A.04.00	VSA E4406A: A.05.00
*RST	Resets instrument, putting it in continuous measurement mode. Use INIT:CONT OFF to select single measurement mode and INIT:IMM to start one measurement.	Resets instrument, putting it in single measurement mode. One measurement is initiated when the command is sent.	Resets instrument, putting it in single measurement mode. No measurement is initiated when the command is sent. Use INIT:IMM to start one measurement.
CONFigure: <measurement>	Accesses the measurement and sets the instrument settings to the defaults. If you were already in single measurement mode, it takes one measurement and then waits.	Same as PSA. Accesses the measurement and sets the instrument settings to the defaults. If you were already in single measurement mode, it takes one measurement and then waits.	Accesses the measurement and sets the instrument settings to the defaults. If you were already in single measurement mode, it does not initiate a measurement. Use INIT:IMM to make one measurement.
*ESE default	Default is 255 which means that every error/status bit change that has occurred will be returned with a *ESR? query. You must set the value of *ESE to choose only the bits/status that you want returned.	Default is 0 which means that none of the error/status bit changes that have occurred will be returned with a *ESR? query. You must set the value of *ESE to choose the bits/status that you want returned.	Same as VSA A.04.00. Default is 0 which means that none of the error/status bit changes that have occurred will be returned with a *ESR? query. You must set the value of *ESE to choose the bits/status that you want returned.
TRIGger commands	In Spectrum Analysis mode only one value can be set for the trigger's source, delay, level, or polarity. Basic, GSM, EDGE, cdmaOne, cdma2000, W-CDMA, NADC, PDC modes function the same as VSA	You can select a unique trigger source for each mode. Each trigger source can have unique settings for the its delay, level, and polarity.	Same as VSA A.04.00. You can select a unique trigger source for each mode. Each trigger source can have unique settings for the its delay, level, and polarity.

Command	PSA Series	VSA E4406A: A.04.00	VSA E4406A: A.05.00
AUTO ON OFF control and setting manual values	<p>We recommend that you set a function's automatic state to OFF, before you send it your manual value.</p> <p>Some functions will turn off the automatic mode when you send a specific manual value, but others will not. This also varies with the instrument model.</p>	<p>We recommend that you set a function's automatic state to OFF, before you send it your manual value.</p> <p>Some functions will turn off the automatic mode when you send a specific manual value, but others will not. This also varies with the instrument model.</p>	<p>We recommend that you set a function's automatic state to OFF, before you send it your manual value.</p> <p>Some functions will turn off the automatic mode when you send a specific manual value, but others will not. This also varies with the instrument model.</p>

CALCulate Subsystem

This subsystem is used to perform post-acquisition data processing. In effect, the collection of new data triggers the CALCulate subsystem. In this instrument, the primary functions in this subsystem are markers and limits.

The SCPI default for data output format is ASCII. The format can be changed to binary with FORMat:DATA which transports faster over the bus.

Adjacent Channel Power—Limit Test

```
:CALCulate:ACP:LIMit[:TEST] OFF|ON|0|1
```

```
:CALCulate:ACP:LIMit[:TEST]?
```

Turn limit test on or off.

Factory Preset: On

Remarks: You must be in the NADC, PDC mode to use this command. Use INSTRument:SElect to set the mode.

Test Current Results Against all Limits

```
:CALCulate:CLIMits:FAIL?
```

Queries the status of the current measurement limit testing. It returns a 0 if the measured results pass when compared with the current limits. It returns a 1 if the measured results fail any limit tests.

Data Query

```
:CALCulate:DATA[n]?
```

Returns the designated measurement data for the currently selected measurement and sub-opcode.

n = any valid sub-opcode for the current measurement. See the “MEASure Group of Commands” on page 148 for information on the data that can be returned for each measurement.

For sub-opcodes that return trace data use the :CALCulate:DATA[n]:COMPRESS? command below.

Calculate/Compress Trace Data Query

```
:CALCulate:DATA<n>:COMPRESS?
BLOCK|CFIT|MAXimum|MEAN|MINimum|RMS|SAMPLE|SDEVIation
[,<soffset>[,<length>[,<roffset>[,<rlimit>]]]]
```

Returns compressed data for the specified trace data. The data is returned in the same units as the original trace and only works with the currently selected measurement. The command is used with a sub-opcode *<n>* since measurements usually return several types of trace data. See the following table for the sub-opcodes for the trace data names that are available in each measurement. For sub-opcodes that return scalar data use the :CALCulate:DATA[n]? command above.

This command is used to compress or decimate a long trace to extract and return only the desired data. A typical example would be to acquire N frames of GSM data and return the mean power of the first burst in each frame. The command can also be used to identify the best curve fit for the data.

BLOCK or block data - returns all the data points from the region of the trace data that you specify. For example, it could be used to return the data points of an input signal over several timeslots, excluding the portions of the trace data that you do not want.

CFIT or curve fit - applies curve fitting routines to the data. *<soffset>* and *<length>* are required to define the data that you want. *<roffset>* is an optional parameter for the desired order of the curve equation. The query will return the following values: the x-offset (in seconds) and the curve coefficients ((order + 1) values).

MAX, **MEAN**, **MIN**, **RMS**, **SAMP**, and **SDEV** return one data value for each specified region (or *<length>*) of trace data, for as many regions as possible until you run out of trace data (using *<roffset>* to specify regions). Or they return the number regions you specify (using *<rlimit>*) ignoring any data beyond that.

MAXimum - returns the maximum data point for the specified region(s) of trace data. For I/Q trace data, the maximum magnitude of the I/Q pairs is returned.

MEAN - returns the arithmetic mean of the data point values for the specified region(s) of trace data. For I/Q trace data, the mean of the magnitudes of the I/Q pairs is returned. Note: If the original trace data is in dB, this function returns the arithmetic mean of those log values, not log of the mean power, which is a more useful value.

MINimum - returns the minimum data point for the specified region(s) of trace data. For I/Q trace data, the minimum magnitude of the I/Q pairs is returned.

RMS - returns the arithmetic rms of the data point values for the specified region(s) of trace data. For I/Q trace data, the rms of the magnitudes of the I/Q pairs is returned. Note: This function is very useful for I/Q trace data. However, if the original trace data is in dB, this function returns the rms of the log values which is not usually needed.

Once you have the rms value for a region of I/Q trace data, you may want to calculate the mean power. You must convert this rms I/Q value (peak volts) to power in dB.

$$10 \times \log[10 \times (\text{rms value})^2]$$

SAMPLE - returns the first data value for the specified region(s) of trace data. For I/Q trace data, the first I/Q pair is returned.

SDEViation - returns the arithmetic standard deviation for the data point values for the specified region(s) of trace data. For I/Q trace data, the standard deviation of the magnitudes of the I/Q pairs is returned.

Figure 4-1 Sample Trace Data - Constant Envelope





Figure 4-2 Sample Trace Data - Not Constant Envelope



<soffset> - start offset is an optional real number (in seconds). It specifies the amount of data at the beginning of the trace that will be ignored before the decimation process starts. It is the time from the start of the trace to the point where you want to start using the data. The default value is zero.

<length> - is an optional real number (in seconds). It defines how much data will be compressed into one value. This parameter has a default value equal to the current trace length.

<roffset> - repeat offset is an optional real number (in seconds). It defines the beginning of the next field of trace elements to be compressed. This is relative to the beginning of the previous field. This parameter has a default value equal to the <length> variable.

<rlimit> - repeat limit is an optional integer. It specifies the number of data items that you want returned. It will ignore any additional items beyond that number. You can use the Start offset and the Repeat limit to pick out exactly what part of the data you want to use. The default value is all the data.

Example: To query the mean power of a set of GSM bursts:

1. Set the waveform measurement sweep time to acquire at least one burst.
2. Set the triggers such that acquisition happens at a known position relative to a burst.
3. Then query the mean burst levels using,
`CALC:DATA2:COMP? MEAN,24e-6,526e-6` (These parameter values correspond to GSM signals, where 526e-6 is the length of the burst in the slot and you just want 1 burst.)

NOTE There is a more detailed example in the “Improving the Speed of Your Measurements” section in the PSA Series *User’s and Programmer’s Reference*. There is also a sample program in the Programming Fundamentals chapter of that book, and a copy of it is on the documentation CD-ROM.

Remarks: The optional parameters must be entered in the specified order. For example, if you want to specify <length>, you must also specify <soffset>.

This command uses the data in the format specified by FORMat:DATA, returning either binary or ASCII data.

History: Added in revision A.03.00

Measurement	Available Traces	Markers Available?
ACP - adjacent channel power (Basic, cdmaOne, cdma2000, W-CDMA, NADC, PDC modes)	no traces ($n=0$) ^a for I/Q points	no markers
CDPower - code domain power (cdmaOne mode)	POWer ($n=2$) ^a TIMing ($n=3$) ^a PHASe ($n=4$) ^a ($n=0$) ^a for I/Q points	yes
CDPower - code domain power (cdma2000, W-CDMA modes)	CDPower ($n=2$) ^a EVM ($n=5$) ^a MERRor ($n=6$) ^a PERRor ($n=7$) ^a SPOWer ($n=9$) ^a CPOWer ($n=10$) ^a ($n=0$) ^a for I/Q points	yes
CHPower - channel power (Basic, cdmaOne, cdma2000, W-CDMA modes)	SPECtrum ($n=2$) ^a ($n=0$) ^a for I/Q points	no markers
CSPur - spurs close (cdmaOne mode)	SPECtrum ($n=2$) ^a ULIMit ($n=3$) ^a ($n=0$) ^a for I/Q points	yes

Measurement	Available Traces	Markers Available?
EEVM - EDGE error vector magnitude (EDGE mode)	EVMError ($n=2$) ^a MError ($n=3$) ^a PError ($n=4$) ^a ($n=0$) ^a for I/Q points	yes
EORFspectr - EDGE output RF spectrum (EDGE mode)	RFEMod ($n=2$) ^a RFESwitching ($n=3$) ^a SPEMod ($n=4$) ^a LIMMod ($n=5$) ^a ($n=0$) ^a for I/Q points	yes, only for a single offset yes, only for multiple offsets
EPVTime - EDGE power versus time (EDGE mode)	RFENvelope ($n=2$) ^a UMASk ($n=3$) ^a LMASk ($n=4$) ^a ($n=0$) ^a for I/Q points	yes
ETSPur - EDGE transmit band spurs (EDGE mode)	SPECtrum ($n=2$) ^a ULIMit ($n=3$) ^a ($n=0$) ^a for I/Q points	yes
EVM - error vector magnitude (NADC, PDC modes)	EVM ($n=2$) ^a MError ($n=3$) ^a PError ($n=4$) ^a ($n=0$) ^a for I/Q points	yes
EVMQpsk - QPSK error vector magnitude (cdma2000, W-CDMA modes)	EVM ($n=2$) ^a MError ($n=3$) ^a PError ($n=4$) ^a ($n=0$) ^a for I/Q points	yes
IM - intermodulation (cdma2000, W-CDMA modes)	SPECtrum ($n=2$) ^a ($n=0$) ^a for I/Q points	yes
MCPower - multi-carrier power (W-CDMA mode)	no traces ($n=0$) ^a for I/Q points	no markers

NADC Programming Commands
CALCulate Subsystem

Measurement	Available Traces	Markers Available?
OBW - occupied bandwidth (cdmaOne, cdma2000, PDC, W-CDMA modes)	no traces $(n=0)^a$ for I/Q points	no markers
ORFSpectrum - output RF spectrum (GSM, EDGE mode)	RFEMod $(n=2)^a$ RFESwitching $(n=3)^a$ SPEMod $(n=4)^a$ LIMMod $(n=5)^a$ $(n=0)^a$ for I/Q points	yes, only for a single offset yes, only for multiple offsets
PFERror - phase and frequency error (GSM, EDGE mode)	PERRor $(n=2)^a$ PFERror $(n=3)^a$ RFENvelope $(n=4)^a$ $(n=0)^a$ for I/Q points	yes
PStatistic - power statistics CCDF (Basic, cdma2000, W-CDMA modes)	MEASured $(n=2)^a$ GAUSian $(n=3)^a$ REFerence $(n=4)^a$ $(n=0)^a$ for I/Q points	yes
PVTime - power versus time (GSM, EDGE modes)	RFENvelope $(n=2)^a$ UMASk $(n=3)^a$ LMASk $(n=4)^a$ $(n=0)^a$ for I/Q points	yes
RHO - modulation quality (cdmaOne, cdma2000, W-CDMA mode)	$(n=0)^a$ for I/Q points EVM $(n=2)^a$ MERRor $(n=3)^a$ PERRor $(n=4)^a$ $(n=0)^a$ for I/Q points	yes
SEMask - spectrum emissions mask (cdma2000, W-CDMA mode)	SPECtrum $(n=2)^a$ $(n=0)^a$ for I/Q points	yes

Measurement	Available Traces	Markers Available?
TSPur - transmit band spurs (GSM, EDGE mode)	SPECtrum ($n=2$) ^a ULIMit ($n=3$) ^a ($n=0$) ^a for I/Q points	yes
TXPower - transmit power (GSM, EDGE mode)	RFENvelope ($n=2$) ^a IQ ($n=8$) ^a ($n=0$) ^a for I/Q points	yes
SPECtrum - (frequency domain) (all modes)	IQ ($n=3$) ^a SPECtrum ($n=4$) ^a ASPECtrum ($n=7$) ^a ($n=0$) ^a for I/Q points	yes
WAVEform - (time domain) (all modes)	RFENvelope ($n=2$) ^a (also for Signal Envelope trace) IQ ($n=5$) ^a ($n=0$) ^a for I/Q points	yes

a. The n number indicates the sub-opcode that corresponds to this trace. Detailed descriptions of the trace data can be found in the MEASure subsystem documentation by looking up the sub-opcode for the appropriate measurement.

Calculate Peaks of Trace Data

```
:CALCulate:DATA<n>:PEAKs?  
<threshold>,<excursion>[,<AMPLitude>|<FREQuency>|<TIME>]
```

Returns a list of peaks for the designated trace data *n* for the currently selected measurement. The peaks must meet the requirements of the peak threshold and excursion values.

The command can only be used with specific *<n>* (sub-opcode) values, for measurement results that are trace data. See the table above for the appropriate sub-opcodes. Both real and complex traces can be searched, but complex traces are converted to magnitude in dBm. Sub-opcode *n=0*, is the raw trace data which cannot be searched for peaks. Sub-opcode *n=1*, is the scaler data which also cannot be searched for peaks.

Threshold - is the level below which trace data peaks are ignored

Excursion - To be defined as a peak, the signal must rise above the threshold by a minimum amplitude change. Excursion is measured from the lowest point above the threshold (of the rising edge of the peak), to the highest signal point that begins the falling edge.

Amplitude - lists the peaks in order of descending amplitude, so the highest peak is listed first. This is the default peak order listing if the optional parameter is not specified.

Frequency - lists the peaks in order of occurrence, left to right across the x-axis

Time - lists the peaks in order of occurrence, left to right across the x-axis

Example: Select the spectrum measurement.

Use `CALC:DATA4:PEAK? -40,10,FREQ` to identify the peaks above -40 dBm, with excursions of at least 10 dB, in order of increasing frequency.

Query Results: Returns a list of floating-point numbers. The first value in the list is the number of peak points that follow. A peak point consists of two values: a peak amplitude followed by the its corresponding frequency (or time).

If no peaks are found the peak list will consist of only the number of peaks, (0).

The peak list is limited to 100 peaks. Peaks in excess of 100 are ignored.

Remarks: This command uses the data setting specified by the `FORMat:DATA` command and can return real 32-bit, real 64-bit, or ASCII data. The default data format is ASCII.

EVM - Limits

Error Vector Magnitude—First 10 Symbols EVM Limit

`:CALCulate:EVM:LIMit:F10 <percent>`

`:CALCulate:EVM:LIMit:F10?`

Set the first 10 symbols EVM limit in percent. This functionality is only for mobile testing.

Factory Preset: 25.0%

Range: 0 to 50%

Remarks: You must be in the NADC mode to use this command. Use `INSTRument:SElect` to set the mode.

Error Vector Magnitude—I/Q Origin Offset Error Limit

`:CALCulate:EVM:LIMit:IQOffset <dB>`

`:CALCulate:EVM:LIMit:IQOffset?`

Set the I/Q origin offset error limit in dB.

Factory Preset: -20 dB

Range: -100 dB to 0 dB

Remarks: You must be in the NADC or PDC mode to use this command. Use `INSTRument:SElect` to set the mode.

History: Version A.02.00 or later

Error Vector Magnitude—Peak EVM Limit

`:CALCulate:EVM:LIMit:PEAK <percent>`

`:CALCulate:EVM:LIMit:PEAK?`

Set the peak EVM limit in percent.

Factory Preset: 40.0%

Range: 0 to 50%

Remarks: You must be in the NADC or PDC mode to use this command. Use `INSTRument:SElect` to set the mode.

NADC Programming Commands
CALCulate Subsystem

Error Vector Magnitude—RMS EVM Limit

`:CALCulate:EVM:LIMit:RMS <percent>`

`:CALCulate:EVM:LIMit:RMS?`

Set the RMS EVM limit in percent.

Factory Preset: 12.5%

Range: 0 to 50%

Remarks: You must be in the NADC or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Error Vector Magnitude—Limit Test

`:CALCulate:EVM:LIMit[:TEST] OFF|ON|0|1`

`:CALCulate:EVM:LIMit[:TEST]?`

Turn limit test on or off.

Factory Preset: On

Remarks: You must be in the NADC or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Error Vector Magnitude—Time to Sync Word

`:CALCulate:EVM:TTSWord?`

Query returns the time between the trigger and the start of the first sync word.

Default Unit: Seconds

Remarks: You must be in the NADC or PDC mode to use this command. Use INSTRument:SElect to set the mode.

CALCulate:MARKers Subsystem

Markers can be put on your displayed measurement data to supply information about specific points on the data. Some of the things that markers can be used to measure include: precise frequency at a point, minimum or maximum amplitude, and the difference in amplitude or frequency between two points.

When using the marker commands you must specify the measurement in the SCPI command. We recommend that you use the marker commands only on the current measurement. Many marker commands will return invalid results, when used on a measurement that is not current. (This is true for commands that do more than simply setting or querying an instrument parameter.) No error is reported for these invalid results.

You must make sure that the measurement is completed before trying to query the marker value. Using the MEASure or READ command, before the marker command, forces the measurement to complete before allowing the next command to be executed.

Each measurement has its own instrument state for marker parameters. Therefore, if you exit the measurement, the marker settings in each measurement are saved and are then recalled when you change back to that measurement.

Basic Mode - <measurement> key words

- SPECTrum - markers available
- WAVEform - markers available

cdmaOne Mode - <measurement> key words

- ACPr - no markers
- CHPower - no markers
- CDPower - markers available
- CSPur - markers available
- RHO - markers available
- SPECTrum - markers available
- WAVEform - markers available

cdma2000 Mode - <measurement> key words

- ACP - no markers
- CDPower - markers available
- CHPower - no markers
- EVMQpsk - markers available
- IM - markers available
- OBW - no markers
- PStatistic - markers available
- RHO - markers available
- SEMask - markers available

NADC Programming Commands

CALCulate Subsystem

- SPECTrum - markers available
- WAVEform - markers available

GSM (with EDGE) Mode - <measurement> key words

- EEVM - markers available
- EORFspectr - markers available
- EPVTime - no markers
- ETSPur - markers available
- ORFSpectrum - markers available
- PFERror - markers available
- PVTime - no markers
- SPECTrum - markers available
- TSPur - markers available
- TXPower - no markers
- WAVEform - markers available

NADC Mode - <measurement> key words

- ACP - no markers
- EVM - markers available
- SPECTrum - markers available
- WAVEform - markers available

PDC Mode - <measurement> key words

- ACP - no markers
- EVM - markers available
- OBW - no markers
- SPECTrum - markers available
- WAVEform - markers available

W-CDMA Mode - <measurement> key words

- ACP - no markers
- CDPower - markers available
- CHPower - no markers
- EVMQpsk - markers available
- IM - markers available
- MCPower - no markers
- OBW - no markers
- PStatistic - markers available
- RHO - markers available
- SEMask - markers available
- SPECTrum - markers available
- WAVEform - markers available

Example:

Suppose you are using the Spectrum measurement in your measurement personality. To position marker 2 at the maximum peak value of the trace that marker 2 is currently on, the command is:

```
:CALCulate:SPECTrum:MARKer2:MAXimum
```

You must make sure that the measurement is completed before trying to query the marker value. Use the MEASure or READ command before using the marker command. This forces the measurement to complete before allowing the next command to be executed.

Markers All Off on All Traces

```
:CALCulate:<measurement>:MARKer:AOFF
```

Turns off all markers on all the traces in the specified measurement.

Example: `CALC:SPEC:MARK:AOFF`

Remarks: The keyword for the current measurement must be specified in the command. (Some examples include: SPECTrum, WAVEform)

Front Panel

Access: **Marker, More, Marker All Off**

Marker Mode

```
:CALCulate:<measurement>:MARKer[1]|2|3|4:MODE  
POSITION|DELTA
```

```
:CALCulate:<measurement>:MARKer[1]|2|3|4:MODE?
```

Selects the type of marker to be a normal position-type marker or a delta marker. A specific measurement may not have both types of markers. For example, several measurements only have position markers.

The marker must have already been assigned to a trace. Use

```
:CALCulate:<measurement>:MARKer[1]|2|3|4:TRACe
```

to assign a marker to a particular trace.

Example: `CALC:SPEC:MARK:MODE DELTA`

Remarks: For the delta mode only markers 1 and 2 are valid.

The keyword for the current measurement must be specified in the command. (Some examples include: SPECTrum, WAVEform)

NADC Programming Commands

CALCulate Subsystem

Front Panel

Access: **Marker, Marker [Delta]**

Marker Function Result

:CALCulate:<measurement>:MARKer[1]|2|3|4:FUNCTION:RESult?

Queries the result of the currently active marker function. The measurement must be completed before querying the marker. A particular measurement may not have all the types of markers available.

The marker must have already been assigned to a trace. Use

:CALCulate:<measurement>:MARKer[1]|2|3|4:TRACe to assign a marker to a particular trace.

Example: **CALC:SPEC:MARK:FUNC:RES?**

Remarks: The keyword for the current measurement must be specified in the command. (Some examples include: SPECTrum, WAVeform)

Front Panel

Access: **Marker, Marker Function**

Marker Peak (Maximum) Search

:CALCulate:<measurement>:MARKer[1]|2|3|4:MAXimum

Places the selected marker on the highest point on the trace that is assigned to that particular marker number.

The marker must have already been assigned to a trace. Use

:CALCulate:<measurement>:MARKer[1]|2|3|4:TRACe to assign a marker to a particular trace.

Example: **CALC:SPEC:MARK1:MAX**

Remarks: The keyword for the current measurement must be specified in the command. (Some examples include: SPECTrum, WAVeform)

Front Panel

Access: **Search**

Marker Peak (Minimum) Search

`:CALCulate:<measurement>:MARKer[1] | 2 | 3 | 4:MINimum`

Places the selected marker on the lowest point on the trace that is assigned to that particular marker number.

The marker must have already been assigned to a trace. Use `:CALCulate:<measurement>:MARKer[1] | 2 | 3 | 4:TRACe` to assign a marker to a particular trace.

Example: `CALC:SPEC:MARK2 MIN`

Remarks: The keyword for the current measurement must be specified in the command. (Some examples include: SPECTrum, WAVeform)

Marker Mode

PSA Series (not for Spectrum Analysis or Phase Noise mode):

`:CALCulate:<measurement>:MARKer[1] | 2 | 3 | 4:MODE
POSition|DELTA`

ESA/PSA Series Phase Noise mode only:

`:CALCulate:<measurement>:MARKer[1] | 2 | 3 | 4:MODE
POSition|DELTA|RMSDegree|RMSRadian|RFM|RMSJitter|OFF`

`:CALCulate:<measurement>:MARKer[1] | 2 | 3 | 4:MODE?`

Selects the type of marker to be a normal position-type marker or a delta marker. A specific measurement may not have both types of markers. For example, several measurements only have position markers

The marker must have already been assigned to a trace. Use `:CALCulate:<measurement>:MARKer[1] | 2 | 3 | 4:TRACe` to assign a marker to a particular trace.

Example: `CALC:SPEC:MARK:MODE DELTA`

Remarks: For the delta mode only markers 1 and 2 are valid.

The keyword for the current measurement must be specified in the command. (Some examples include: SPECTrum, WAVeform)

Front Panel

Access: **Marker, Marker [Delta]**

NADC Programming Commands

CALCulate Subsystem

Marker On/Off

:CALCulate:<measurement>:MARKer[1]|2|3|4[:STATe] OFF|ON|0|1

:CALCulate:<measurement>:MARKer[1]|2|3|4[:STATe]?

Turns the selected marker on or off.

The marker must have already been assigned to a trace. Use

:CALCulate:<measurement>:MARKer[1]|2|3|4:TRACe to assign a marker to a particular trace.

Example: **CALC:SPEC:MARK2: on**

Remarks: The keyword for the current measurement must be specified in the command. (Some examples include: SPECTrum, AREFERENCE, WAVeform)

The WAVeform measurement only has two markers available.

Front Panel

Access: **Marker, Select then Marker Normal or Marker On Off**

Marker to Trace

:CALCulate:<measurement>:MARKer[1]|2|3|4:TRACe <trace_name>

:CALCulate:<measurement>:MARKer[1]|2|3|4:TRACe?

Assigns the specified marker to the designated trace. Not all types of measurement data can have markers assigned to them.

Example: With the WAVeform measurement selected, a valid command is **CALC:SPEC:MARK2:TRACE rfenvelope**.

Range: The names of valid traces are dependent upon the selected measurement. See the following table for the available trace names. The trace name assignment is independent of the marker number.

Remarks: The keyword for the current measurement must be specified in the command. (Some examples include: SPECTrum, WAVeform)

Front Panel

Access: **Marker, Marker Trace**

Measurement	Available Traces	Markers Available?
ACP - adjacent channel power (Basic, cdmaOne, cdma2000, W-CDMA, NADC, PDC modes)	no traces $(n=0)^a$ for I/Q points	no markers

Measurement	Available Traces	Markers Available?
CDPower - code domain power (cdmaOne mode)	POWER ($n=2$) ^a TIMing ($n=3$) ^a PHASe ($n=4$) ^a ($n=0$) ^a for I/Q points	yes
CDPower - code domain power (cdma2000, W-CDMA modes)	CDPower ($n=2$) ^a EVM ($n=5$) ^a MERRor ($n=6$) ^a PERRor ($n=7$) ^a SPOWer ($n=9$) ^a CPOWer ($n=10$) ^a ($n=0$) ^a for I/Q points	yes
CHPower - channel power (Basic, cdmaOne, cdma2000, W-CDMA modes)	SPECTrum ($n=2$) ^a ($n=0$) ^a for I/Q points	no markers
CSPur - spurs close (cdmaOne mode)	SPECTrum ($n=2$) ^a ULIMit ($n=3$) ^a ($n=0$) ^a for I/Q points	yes
EEVM - EDGE error vector magnitude (EDGE mode)	EVMerror ($n=2$) ^a MERRor ($n=3$) ^a PERRor ($n=4$) ^a ($n=0$) ^a for I/Q points	yes
EORFspectr - EDGE output RF spectrum (EDGE mode)	RFEMod ($n=2$) ^a RFESwitching ($n=3$) ^a SPEMod ($n=4$) ^a LIMMod ($n=5$) ^a ($n=0$) ^a for I/Q points	yes, only for a single offset yes, only for multiple offsets

NADC Programming Commands
CALCulate Subsystem

Measurement	Available Traces	Markers Available?
EPVTime - EDGE power versus time (EDGE mode)	RFENvelope ($n=2$) ^a UMASk ($n=3$) ^a LMASk ($n=4$) ^a ($n=0$) ^a for I/Q points	yes
ETSPur - EDGE transmit band spurs (EDGE mode)	SPECtrum ($n=2$) ^a ULIMit ($n=3$) ^a ($n=0$) ^a for I/Q points	yes
EVM - error vector magnitude (NADC, PDC modes)	EVM ($n=2$) ^a MERRor ($n=3$) ^a PERRor ($n=4$) ^a ($n=0$) ^a for I/Q points	yes
EVMQpsk - QPSK error vector magnitude (cdma2000, W-CDMA modes)	EVM ($n=2$) ^a MERRor ($n=3$) ^a PERRor ($n=4$) ^a ($n=0$) ^a for I/Q points	yes
IM - intermodulation (cdma2000, W-CDMA modes)	SPECtrum ($n=2$) ^a ($n=0$) ^a for I/Q points	yes
MCPower - multi-carrier power (W-CDMA mode)	no traces ($n=0$) ^a for I/Q points	no markers
OBW - occupied bandwidth (cdmaOne, cdma2000, PDC, W-CDMA modes)	no traces ($n=0$) ^a for I/Q points	no markers
ORFSpectrum - output RF spectrum (GSM, EDGE mode)	RFEMod ($n=2$) ^a RFESwitching ($n=3$) ^a SPEMod ($n=4$) ^a LIMMod ($n=5$) ^a ($n=0$) ^a for I/Q points	yes, only for a single offset yes, only for multiple offsets

Measurement	Available Traces	Markers Available?
PFERror - phase and frequency error (GSM, EDGE mode)	PERRor ($n=2$) ^a PFERror ($n=3$) ^a RFENvelope ($n=4$) ^a ($n=0$) ^a for I/Q points	yes
PStatistic - power statistics CCDF (Basic, cdma2000, W-CDMA modes)	MEASured ($n=2$) ^a GAUSian ($n=3$) ^a REFerence ($n=4$) ^a ($n=0$) ^a for I/Q points	yes
PVTime - power versus time (GSM, EDGE modes)	RFENvelope ($n=2$) ^a UMASk ($n=3$) ^a LMASk ($n=4$) ^a ($n=0$) ^a for I/Q points	yes
RHO - modulation quality (cdmaOne, cdma2000, W-CDMA mode)	($n=0$) ^a for I/Q points EVM ($n=2$) ^a MERRor ($n=3$) ^a PERRor ($n=4$) ^a ($n=0$) ^a for I/Q points	yes
SEMAsk - spectrum emissions mask (cdma2000, W-CDMA mode)	SPECtrum ($n=2$) ^a ($n=0$) ^a for I/Q points	yes
TSPur - transmit band spurs (GSM, EDGE mode)	SPECtrum ($n=2$) ^a ULIMit ($n=3$) ^a ($n=0$) ^a for I/Q points	yes
TXPower - transmit power (GSM, EDGE mode)	RFENvelope ($n=2$) ^a IQ ($n=8$) ^a ($n=0$) ^a for I/Q points	yes

NADC Programming Commands

CALCulate Subsystem

Measurement	Available Traces	Markers Available?
SPECtrum - (frequency domain) (all modes)	IQ ($n=3$) ^a SPECtrum ($n=4$) ^a ASPECTrum ($n=7$) ^a ($n=0$) ^a for I/Q points	yes
WAVEform - (time domain) (all modes)	RFENvelope ($n=2$) ^a (also for Signal Envelope trace) IQ ($n=5$) ^a ($n=0$) ^a for I/Q points	yes

a. The n number indicates the sub-opcode that corresponds to this trace. Detailed descriptions of the trace data can be found in the MEASure subsystem documentation by looking up the sub-opcode for the appropriate measurement.

Marker X Value

```
:CALCulate:<measurement>:MARKer[1]|2|3|4:X <param>
```

```
:CALCulate:<measurement>:MARKer[1]|2|3|4:X?
```

Position the designated marker on its assigned trace at the specified X value. The parameter value is in X-axis units (which is often frequency or time).

The marker must have already been assigned to a trace. Use `:CALCulate:<measurement>:MARKer[1]|2|3|4:TRACe` to assign a marker to a particular trace.

The query returns the current X value of the designated marker. The measurement must be completed before querying the marker.

Example: `CALC:SPEC:MARK2:X 1.2e6 Hz`

Default Unit: Matches the units of the trace on which the marker is positioned

Remarks: The keyword for the current measurement must be specified in the command. (Some examples include: SPECtrum, WAVEform)

Front Panel

Access: **Marker, <active marker>, RPG**

Marker X Position

:CALCulate:<measurement>:MARKer[1] | 2 | 3 | 4:X:POSition
<integer>

:CALCulate:<measurement>:MARKer[1] | 2 | 3 | 4:X:POSition?

Position the designated marker on its assigned trace at the specified X position. A trace is composed of a variable number of measurement points. This number changes depending on the current measurement conditions. The current number of points must be identified before using this command to place the marker at a specific location.

The marker must have already been assigned to a trace. Use **:CALCulate:<measurement>:MARKer[1] | 2 | 3 | 4:TRACe** to assign a marker to a particular trace.

The query returns the current X position for the designated marker. The measurement must be completed before querying the marker.

Example: **CALC:SPEC:MARK:X:POS 500**

Range: 0 to a maximum of (3 to 920,000)

Remarks: The keyword for the current measurement must be specified in the command. (Some examples include: SPECTrum, WAVeform)

Front Panel

Access: **Marker, <active marker>, RPG**

Marker Readout Y Value

:CALCulate:<measurement>:MARKer[1] | 2 | 3 | 4:Y?

Readout the current Y value for the designated marker on its assigned trace. The value is in the Y-axis units for the trace (which is often dBm).

The marker must have already been assigned to a trace. Use **:CALCulate:<measurement>:MARKer[1] | 2 | 3 | 4:TRACe** to assign a marker to a particular trace.

The measurement must be completed before querying the marker.

Example: **CALC:SPEC:MARK1:Y?**

Default Unit: Matches the units of the trace on which the marker is positioned

Remarks: The keyword for the current measurement must be specified in the command. (Some examples include: SPECTrum, WAVeform)

CONFigure Subsystem

The CONFigure commands are used with several other commands to control the measurement process. The full set of commands are described in the section “[MEASure Group of Commands](#)” on page 148.

Selecting measurements with the CONFigure/FETCH/MEASure/READ commands sets the instrument state to the defaults for that measurement and to make a single measurement. Other commands are available for each measurement to allow you to change: settings, view, limits, etc. Refer to:

```
SENSE:<measurement>, SENSE:CHANnel, SENSE:CORRection,  
SENSE:DEFaults, SENSE:DEViation, SENSE:FREQuency,  
SENSE:PACKet, SENSE:POWer, SENSE:RADio, SENSE:SYNC  
CALCulate:<measurement>, CALCulate:CLIMits  
DISPlay:<measurement>  
TRIGger
```

The INITiate[:IMMediate] or INITiate:REStart commands will initiate the taking of measurement data without resetting any of the measurement settings that you have changed from their defaults.

Configure the Selected Measurement

```
:CONFigure:<measurement>
```

A CONFigure command must specify the desired measurement. It will set the instrument settings for that measurements standard defaults, but should not initiate the taking of data. The available measurements are described in the MEASure subsystem.

NOTE

If CONFigure initiates the the taking of data, the data should be ignored. Other SCPI commands can be processed immediately after sending CONFigure. You do not need to wait for the CONF command to complete this 'false' data acquisition.

Configure Query

```
:CONFigure?
```

The CONFigure query returns the name of the current measurement.

DISPlay Subsystem

The DISPlay controls the selection and presentation of textual, graphical, and TRACe information. Within a DISPlay, information may be separated into individual WINDows.

Adjacent Channel Power - View Selection

```
:DISPlay:ACP:VIEW BGRaph|SPECTrum
```

```
:DISPlay:ACP:VIEW?
```

Select the adjacent channel power measurement display of bar graph or spectrum.

You may want to disable the spectrum trace data part of the measurement so you can increase the speed of the rest of the measurement display. Use SENSE:ACP:SPECTrum:ENABLE to turn on or off the spectrum trace. (Basic and cdmaOne modes only)

Factory Preset: Bar Graph (BGRaph)

Remarks: You must be in the cdmaOne, cdma2000, W-CDMA (3GPP), NADC or PDC mode to use this command. Use INSTRument:SELEct to set the mode.

Front Panel

Access: ACP, View/Trace

Error Vector Magnitude - View Selection

```
:DISPlay:EVMagnitude:VIEW POLar|CONStIn|QUAD
```

```
:DISPlay:EVMagnitude:VIEW?
```

Select the view of EVM measurement

Factory Preset: POLar

Remarks: You must be in the NADC or PDC mode to use this command. Use INSTRument:SELEct to set the mode.

Select Display Format

:DISPlay:FORMat:TILE

Selects the viewing format that displays multiple windows of the current measurement data simultaneously. Use DISP:FORM:ZOOM to return the display to a single window.

Remarks: You must be in the Basic, cdmaOne,cdma2000, W-CDMA, GSM (w/EDGE), NADC, or PDC mode to use this command. Use INSTRument:SElect to set the mode

Front Panel

Access: **Zoom** (toggles between Tile and Zoom)

Select Display Format

:DISPlay:FORMat:ZOOM

Selects the viewing format that displays only one window of the current measurement data (the current active window). Use DISP:FORM:TILE to return the display to multiple windows.

Remarks: You must be in the Basic, cdmaOne,cdma2000, W-CDMA, GSM (w/EDGE), NADC, or PDC mode to use this command. Use INSTRument:SElect to set the mode

Front Panel

Access: **Zoom** (toggles between Tile and Zoom)

Spectrum - Y-Axis Scale/Div

**:DISPlay:SPECTrum[n]:WINDow[m]:TRACe:Y[:SCALE]:PDIVision
<power>**

:DISPlay:SPECTrum[n]:WINDow[m]:TRACe:Y[:SCALE]:PDIVision?

Sets the amplitude reference level for the y-axis.

n – selects the view, the default is Spectrum.

m – selects the window within the view. The default is 1.

- n=1, m=1 Spectrum
- n=1, m=2 I/Q Waveform
- n=1, m=2 I and Q Waveform (Basic, W-CDMA, cdma2000)
- n=3, m=1 I/Q Polar (Basic, W-CDMA, cdma2000)

— n=4, m=1 Linear Spectrum (Basic, W-CDMA, cdma2000)

Factory Preset: 10 dB per division, for Spectrum

100 mV per division, for I/Q Waveform

Range: 0.1 dB to 20 dB per division, for Spectrum

1 nV to 20 V per division, for I/Q Waveform

Default Unit: 10 dB per division, for Spectrum

Remarks: May affect input attenuator setting.

You must be in Basic, cdmaOne, cdma2000, W-CDMA GSM w/EDGE, NADC, or PDC mode. Set the mode with INSTRUMENT:SElect.

Front Panel

Access: When in Spectrum measurement: **Amplitude Y Scale, Scale/Div.**

History: Added revision A.02.00

Spectrum - Y-Axis Reference Level

```
:DISPlay:SPECTrum[n]:WINDow[m]:TRACe:Y[:SCALE]:RLEVEL
<power>
```

```
:DISPlay:SPECTrum[n]:WINDow[m]:TRACe:Y[:SCALE]:RLEVEL?
```

Sets the amplitude reference level for the y-axis.

n, selects the view, the default is RF envelope.

— n=1, m=1 Spectrum

— n=1, m=2 I/Q Waveform

— n=1, m=2 I and Q Waveform (Basic, W-CDMA, cdma2000)

— n=3, m=1 I/Q Polar (Basic, W-CDMA, cdma2000)

— n=4, m=1 Linear Spectrum (Basic, W-CDMA, cdma2000)

m – selects the window within the view. The default is 1.

Factory Preset: 0 dBm, for Spectrum

Range: –250 to 250 dBm, for Spectrum

Default Unit: dBm, for Spectrum

Remarks: May affect input attenuator setting.

You must be in Basic, cdmaOne, cdma2000, W-CDMA GSM w/EDGE, NADC, or PDC mode. Set the mode with INSTRUMENT:SElect.

NADC Programming Commands DISPlay Subsystem

Front Panel

Access: When in Spectrum measurement: **Amplitude Y Scale, Ref Level**

History: Added revision A.02.00

Turn a Trace Display On/Off

```
:DISPlay:TRACe[n][:STATe] OFF|ON|0|1
```

```
:DISPlay:TRACe[n][:STATe]?
```

Controls whether the specified trace is visible or not.

n is a sub-opcode that is valid for the current measurement. See the “[MEASure Group of Commands](#)” on page 148 for more information about sub-opcodes.

Factory Preset: On

Range: The valid traces and their sub-opcodes are dependent upon the selected measurement. See the following table.

The trace name assignment is independent of the window number.

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM (w/EDGE), NADC, or PDC mode to use this command. Use INSTRument:SElect to set the mode

Front Panel

Access: **Display, Display Traces**

Measurement	Available Traces	Markers Available?
ACP - adjacent channel power (Basic, cdmaOne, cdma2000, W-CDMA, NADC, PDC modes)	no traces $(n=0)^a$ for I/Q points	no markers
CDPower - code domain power (cdmaOne mode)	POWer $(n=2)^a$ TIMing $(n=3)^a$ PHASe $(n=4)^a$ $(n=0)^a$ for I/Q points	yes

Measurement	Available Traces	Markers Available?
CDPower - code domain power (cdma2000, W-CDMA modes)	CDPower ($n=2$) ^a EVM ($n=5$) ^a MERRor ($n=6$) ^a PERRor ($n=7$) ^a SPOWer ($n=9$) ^a CPOWer ($n=10$) ^a ($n=0$) ^a for I/Q points	yes
CHPower - channel power (Basic, cdmaOne, cdma2000, W-CDMA modes)	SPECTrum ($n=2$) ^a ($n=0$) ^a for I/Q points	no markers
CSPur - spurs close (cdmaOne mode)	SPECTrum ($n=2$) ^a ULIMit ($n=3$) ^a ($n=0$) ^a for I/Q points	yes
EEVM - EDGE error vector magnitude (EDGE mode)	EVMerror ($n=2$) ^a MERRor ($n=3$) ^a PERRor ($n=4$) ^a ($n=0$) ^a for I/Q points	yes
EORFspectr - EDGE output RF spectrum (EDGE mode)	RFEMod ($n=2$) ^a RFESwitching ($n=3$) ^a SPEMod ($n=4$) ^a LIMMod ($n=5$) ^a ($n=0$) ^a for I/Q points	yes, only for a single offset yes, only for multiple offsets
EPVTime - EDGE power versus time (EDGE mode)	RFENvelope ($n=2$) ^a UMASk ($n=3$) ^a LMASk ($n=4$) ^a ($n=0$) ^a for I/Q points	yes
ETSPur - EDGE transmit band spurs (EDGE mode)	SPECTrum ($n=2$) ^a ULIMit ($n=3$) ^a ($n=0$) ^a for I/Q points	yes

NADC Programming Commands
DISPlay Subsystem

Measurement	Available Traces	Markers Available?
EVM - error vector magnitude (NADC, PDC modes)	EVM ($n=2$) ^a MERRor ($n=3$) ^a PERRor ($n=4$) ^a ($n=0$) ^a for I/Q points	yes
EVMQpsk - QPSK error vector magnitude (cdma2000, W-CDMA modes)	EVM ($n=2$) ^a MERRor ($n=3$) ^a PERRor ($n=4$) ^a ($n=0$) ^a for I/Q points	yes
IM - intermodulation (cdma2000, W-CDMA modes)	SPECtrum ($n=2$) ^a ($n=0$) ^a for I/Q points	yes
MCPower - multi-carrier power (W-CDMA mode)	no traces ($n=0$) ^a for I/Q points	no markers
OBW - occupied bandwidth (cdmaOne, cdma2000, PDC, W-CDMA modes)	no traces ($n=0$) ^a for I/Q points	no markers
ORFSpectrum - output RF spectrum (GSM, EDGE mode)	RFEMod ($n=2$) ^a RFESwitching ($n=3$) ^a SPEMod ($n=4$) ^a LIMMod ($n=5$) ^a ($n=0$) ^a for I/Q points	yes, only for a single offset yes, only for multiple offsets
PFERror - phase and frequency error (GSM, EDGE mode)	PERRor ($n=2$) ^a PFERror ($n=3$) ^a RFENvelope ($n=4$) ^a ($n=0$) ^a for I/Q points	yes
PStatistic - power statistics CCDF (Basic, cdma2000, W-CDMA modes)	MEASured ($n=2$) ^a GAUSian ($n=3$) ^a REFerence ($n=4$) ^a ($n=0$) ^a for I/Q points	yes

Measurement	Available Traces	Markers Available?
PVTime - power versus time (GSM, EDGE modes)	RFENvelope ($n=2$) ^a UMASk ($n=3$) ^a LMASk ($n=4$) ^a ($n=0$) ^a for I/Q points	yes
RHO - modulation quality (cdmaOne, cdma2000, W-CDMA mode)	($n=0$) ^a for I/Q points EVM ($n=2$) ^a MERRor ($n=3$) ^a PERRor ($n=4$) ^a ($n=0$) ^a for I/Q points	yes
SEMask - spectrum emissions mask (cdma2000, W-CDMA mode)	SPECtrum ($n=2$) ^a ($n=0$) ^a for I/Q points	yes
TSPur - transmit band spurs (GSM, EDGE mode)	SPECtrum ($n=2$) ^a ULIMit ($n=3$) ^a ($n=0$) ^a for I/Q points	yes
TXPower - transmit power (GSM, EDGE mode)	RFENvelope ($n=2$) ^a IQ ($n=8$) ^a ($n=0$) ^a for I/Q points	yes
SPECtrum - (frequency domain) (all modes)	IQ ($n=3$) ^a SPECtrum ($n=4$) ^a ASPectrum ($n=7$) ^a ($n=0$) ^a for I/Q points	yes
WAVEform - (time domain) (all modes)	RFENvelope ($n=2$) ^a (also for Signal Envelope trace) IQ ($n=5$) ^a ($n=0$) ^a for I/Q points	yes

a. The n number indicates the sub-opcode that corresponds to this trace. Detailed descriptions of the trace data can be found in the MEASure subsystem documentation by looking up the sub-opcode for the appropriate measurement.

Waveform - Y-Axis Scale/Div

```
:DISPlay:WAVEform[n]:WINDow[m]:TRACe:Y[:SCALe]:PDIVision
<power>
```

```
:DISPlay:WAVEform[n]:WINDow[m]:TRACe:Y[:SCALe]:PDIVision?
```

Sets the scale per division for the y-axis.

n, selects the view, the default is RF envelope.

n=1, m=1 RF envelope

n=2, m=1 I/Q Waveform

n=4, m=1 I/Q Polar (Basic, W-CDMA, cdma2000)

m, selects the window within the view. The default is 1.

Factory Preset: 10 dBm, for RF envelope

Range: .1 dB to 20 dB, for RF envelope

Default Unit: dBm, for RF envelope

Remarks: May affect input attenuator setting.

You must be in Basic, cdmaOne, cdma2000, W-CDMA
GSM w/EDGE, NADC, or PDC mode. Set the mode
with INSTRument:SElect.

Front Panel

Access: When in Waveform measurement: **Amplitude Y Scale,
Scale/Div.**

History: Added revision A.02.00

Waveform - Y-Axis Reference Level

```
:DISPlay:WAVEform[n]:WINDow[m]:TRACe:Y[:SCALe]:RLEVEL
<power>
```

```
:DISPlay:WAVEform[n]:WINDow[m]:TRACe:Y[:SCALe]:RLEVEL?
```

Sets the amplitude reference level for the y-axis.

n, selects the view, the default is RF envelope.

n=1, m=1 RF envelope

n=2, m=1 I/Q Waveform

n=4, m=1 I/Q Polar (Basic, W-CDMA, cdma2000)

m, selects the window within the view. The default is 1.

Factory Preset: 0 dBm, for RF envelope

Range: -250 to 250 dBm, for RF envelope

Default Unit: dBm, for RF envelope

Remarks: May affect input attenuator setting.
You must be in Basic, cdmaOne, cdma2000, W-CDMA
GSM w/EDGE, NADC, or PDC mode. Set the mode
with INSTRument:SElect.

**Front Panel
Access:** When in Waveform measurement: **Amplitude Y Scale,
Ref Level**

History: Added revision A.02.00

FETCh Subsystem

The FETCh? queries are used with several other commands to control the measurement process. These commands are described in the section on the “[MEASure Group of Commands](#)” on [page 148](#). These commands apply only to measurements found in the MEASURE menu.

This command puts selected data from the most recent measurement into the output buffer (new data is initiated/measured). Use FETCh if you have already made a good measurement and you want to look at several types of data (different [n] values) from the single measurement. FETCh saves you the time of re-making the measurement. You can only fetch results from the measurement that is currently active.

If you need to make a new measurement, use the READ command, which is equivalent to an INITiate[:IMMediate] followed by a FETCh.

:FETCh <meas>? will return valid data only when the measurement is in one of the following states:

- idle
- initiated
- paused

Fetch the Current Measurement Results

:FETCh:<measurement>[n]?

A FETCh? command must specify the desired measurement. It will return the valid results that are currently available, but will not initiate the taking of any new data. You can only fetch results from the measurement that is currently selected. The code number n selects the kind of results that will be returned. The available measurements and data results are described in the “[MEASure Group of Commands](#)” on [page 148](#).

FORMat Subsystem

The FORMat subsystem sets a data format for transferring numeric and array information. The TRACe[:DATA] command is affected by FORMat subsystem commands.

Byte Order

`:FORMat:BORDER NORMAl | SWAPped`

`:FORMat:BORDER?`

Selects the binary data byte order for numeric data transfer. In normal mode the most significant byte is sent first. In swapped mode the least significant byte is first. (PCs use the swapped order.) Binary data byte order functionality does not apply to ASCII.

Factory Preset: Normal

Numeric Data format

`:FORMat[:DATA] ASCii | REAL, 32 | REAL, 64`

`:FORMat[:DATA]?`

For PSA Spectrum Analysis mode only:

`:FORMat[:TRACe][:DATA]`

`ASCii | INTEger, 16 | INTEger, 32 | REAL, 32 | REAL, 64 | UNINTEger, 16`

`:FORMat[:TRACe][:DATA]?`

This command controls the format of data output, that is, data transfer across any remote port. The REAL and ASCII formats will format trace data in the current amplitude units.

The format of state data cannot be changed. It is always in a machine readable format only.

ASCII - Amplitude values are in ASCII, in amplitude units, separated by commas. ASCII format requires more memory than the binary formats. Therefore, handling large amounts of this type of data, will take more time and storage space.

Integer,16 - Binary 16-bit integer values in internal units (dBm), in a definite length block. **PSA, SA mode only.

Integer,32 - Binary 32-bit integer values in internal units (dBm), in a definite length block.

NADC Programming Commands

FORMat Subsystem

Real,32 (or 64) - Binary 32-bit (or 64-bit) real values in amplitude unit, in a definite length block. Transfers of real data are done in a binary block format.

UINteger,16 - Binary 16-bit unsigned integer that is uncorrected ADC values, in a definite length block. This format is almost never applicable with current data.

A definite length block of data starts with an ASCII header that begins with # and indicates how many additional data points are following in the block. Suppose the header is #512320.

- The first digit in the header (5) tells you how many additional digits/bytes there are in the header.
- The 12320 means 12 thousand, 3 hundred, 20 data bytes follow the header.
- Divide this number of bytes by your selected data format bytes/point, either 8 (for real 64), or 4 (for real 32). In this example, if you are using real 64 then there are 1540 points in the block.

Example: `FORM REAL,64`

Factory Preset: `Real,32` for Spectrum Analysis mode

ASCII for Basic, cdmaOne, cdma2000, W-CDMA, GSM with EDGE, NADC, PDC modes

Remarks: The acceptable settings for this command changes for different modes.

INITiate Subsystem

The INITiate subsystem is used to initiate a trigger for a measurement. They only initiate measurements from the MEASURE front panel key or the “MEASure Group of Commands” on page 148. Refer to the TRIGger and ABORt subsystems for related commands.

Take New Data Acquisition for Selected Measurement

`:INITiate:<measurement_name>`

This command initiates a trigger cycle for the measurement specified. The available measurement names are described in the MEASure subsystem. It also holds off additional commands on GPIB until the acquisition is complete. So if it is followed by a FETCh command, valid data will be returned.

If your selected measurement is currently active (in the idle state) it triggers the measurement, assuming the trigger conditions are met. Then it completes one trigger cycle. Depending upon the measurement and the number of averages, there may be multiple data acquisitions, with multiple trigger events, for one full trigger cycle.

If your selected measurement is not currently active it will change to the measurement in your INIT:<meas_name> command and initiate a trigger cycle.

Example: INIT:ACP

Continuous or Single Measurements

`:INITiate:CONTinuous OFF|ON|0|1`

`:INITiate:CONTinuous?`

Selects whether a trigger is continuously initiated or not. Each trigger initiates a single, complete, measurement operation.

When set to ON another trigger cycle is initiated at the completion of each measurement.

When set to OFF, the trigger system remains in the “idle” state until an INITiate[:IMMediate] command is received. On receiving the INITiate[:IMMediate] command, it will go through a single trigger/measurement cycle, and then return to the “idle” state.

Example: INIT:CONT ON

Factory Preset: On

*RST: Off (recommended for remote operation)

NADC Programming Commands

INITiate Subsystem

Front Panel

Access: **Meas Control, Measure Cont Single**

Take New Data Acquisitions

:INITiate[:IMMediate]

The instrument must be in the single measurement mode. If INIT:CONT is ON, then the command is ignored. The desired measurement must be selected and waiting. The command causes the system to exit the “waiting” state and go to the “initiated” state.

The trigger system is initiated and completes one full trigger cycle. It returns to the “waiting” state on completion of the trigger cycle. Depending upon the measurement and the number of averages, there may be multiple data acquisitions, with multiple trigger events, for one full trigger cycle.

This command triggers the instrument, if external triggering is the type of trigger event selected. Otherwise, the command is ignored. Use the TRIGger[:SEquence]:SOURce EXT command to select the external trigger.

Example: INIT:IMM

Remarks: See also the *TRG command and the TRIGger subsystem.

Front Panel

Access: **Meas Control, Measure Cont Single**

Restart the Measurement

:INITiate:REStart

This command applies to measurements found in the MEASURE menu. It restarts the current measurement from the “idle” state regardless of its current operating state. It is equivalent to:

INITiate[:IMMediate]

ABORt (for continuous measurement mode)

Example: INIT:REST

Front Panel

Access: **Restart**

or

Meas Control, Restart

INSTrument Subsystem

This subsystem includes commands for querying and selecting instrument measurement (personality option) modes.

Catalog Query

`:INSTrument:CATalog?`

Returns a comma separated list of strings which contains the names of all the installed applications. These names can only be used with the `INST:SELECT` command.

Example: `INST:CAT?`

Query response: "CDMA"4,"PNOISE"14

Select Application by Number

`:INSTrument:NSElect <integer>`

`:INSTrument:NSElect?`

Select the measurement mode by its instrument number. The actual available choices depends upon which applications are installed in the instrument.

- 1 = SA
- 4 = CDMA (cdmaOne)
- 5 = NADC
- 6 = PDC
- 8 = BASIC
- 9 = WCDMA (3GPP)
- 10 = CDMA2K (cdma2000)
- 13 = EDGE GSM

14 = PNOISE (phase noise)

NOTE

If you are using the SCPI status registers and the analyzer mode is changed, the status bits should be read, and any errors resolved, prior to switching modes. Error conditions that exist prior to switching modes cannot be detected using the condition registers after the mode change. This is true unless they recur after the mode change, although transitions of these conditions can be detected using the event registers.

Changing modes resets all SCPI status registers and mask registers to their power-on defaults. Hence, any event or condition register masks must be re-established after a mode change. Also note that the power up status bit is set by any mode change, since that is the default state after power up.

Example: INST:NSEL 4

Factory Preset: Persistent state with factory default of 1

Range: 1 to x, where x depends upon which applications are installed.

Front Panel

Access: **Mode**

Select Application

PSA Series:

```
:INSTrument [ :SElect ]
```

```
SA | PNOISE | BASIC | CDMA | CDMA2K | EDGE GSM | NADC | PDC | WCDMA
```

```
:INSTrument [ :SElect ]?
```

Select the measurement mode. The actual available choices depend upon which modes (measurement applications) are installed in the instrument. A list of the valid choices is returned with the INST:CAT? query.

Once an instrument mode is selected, only the commands that are valid for that mode can be executed.

1 = SA
4 = CDMA (cdmaOne)
5 = NADC
6 = PDC
8 = BASIC
9 = WCDMA (3GPP)
10 = CDMA2K (cdma2000)
13 = EDGE GSM
14 = PNOISE (phase noise)

NOTE

If you are using the status bits and the analyzer mode is changed, the status bits should be read, and any errors resolved, prior to switching modes. Error conditions that exist prior to switching modes cannot be detected using the condition registers after the mode change. This is true unless they recur after the mode change, although transitions of these conditions can be detected using the event registers.

Changing modes resets all SCPI status registers and mask registers to their power-on defaults. Hence, any event or condition register masks must be re-established after a mode change. Also note that the power up status bit is set by any mode change, since that is the default state after power up.

Example: ESA Series instruments: INST:SEL 'CDMA'

Example: PSA Series instruments: INST:SEL CDMA

Factory Preset: Persistent state with factory default of Spectrum Analyzer mode

Front Panel

Access: **Mode**

MEASure Group of Commands

This group includes the CONFigure, FETCh, MEASure, and READ commands that are used to make measurements and return results. The different commands can be used to provide fine control of the overall measurement process, like changing measurement parameters from their default settings. Most measurements should be done in single measurement mode, rather than measuring continuously.

The SCPI default for the format of any data output is ASCII. The format can be changed to binary with FORMat:DATA which transports faster over the bus.

CONFigure, FETCh, MEASure, READ Interactions

These commands are all inter-related. See [Figure 4-3 on page 149](#).

Measure Commands

`:MEASure:<measurement>[n]?`

This is a fast single-command way to make a measurement using the factory default instrument settings. These are the settings and units that conform to the Mode Setup settings (e.g. radio standard) that you have currently selected.

- Stops the current measurement (if any) and sets up the instrument for the specified measurement using the factory defaults
- Initiates the data acquisition for the measurement
- Blocks other SCPI communication, waiting until the measurement is complete before returning results.
- After the data is valid it returns the scalar results, or the trace data, for the specified measurement. The type of data returned may be defined by an [n] value that is sent with the command.

The scalar measurement results will be returned if the optional [n] value is not included, or is set to 1. If the [n] value is set to a value other than 1, the selected trace data results will be returned. See each command for details of what types of scalar results or trace data results are available.


ASCII is the default format for the data output. The binary data formats should be used for handling large blocks of data since they are smaller and faster than the ASCII format. Refer to the FORMat:DATA command for more information.

If you need to change some of the measurement parameters from the factory default settings you can set up the measurement with the CONFIgure command. Use the commands in the SENSE:<measurement> and CALCulate:<measurement> subsystems to change the settings. Then you can use the READ? command to initiate the measurement and query the results. See Figure 4-3.

If you need to repeatedly make a given measurement with settings other than the factory defaults, you can use the commands in the SENSE:<measurement> and CALCulate:<measurement> subsystems to set up the measurement. Then use the READ? command to initiate the measurement and query results.

Measurement settings persist if you initiate a different measurement and then return to a previous one. Use READ:<measurement>? if you want to use those persistent settings. If you want to go back to the default settings, use MEASure:<measurement>?.

Figure 4-3 Measurement Group of Commands



Configure Commands

:CONFIgure:<measurement>

This command stops the current measurement (if any) and sets up the instrument for the specified measurement using the factory default instrument settings. It sets the instrument to single measurement mode but should not initiate the taking of measurement data unless INIT:CONTinuous is ON. After you change any measurement settings, the READ command can be used to initiate a measurement without changing the settings back to their defaults.

The CONFIgure? query returns the current measurement name.

Fetch Commands

:FETCh:<measurement>[n]?

This command puts selected data from the most recent measurement into the output buffer. Use FETCh if you have already made a good measurement and you want to return several types of data (different [n] values, e.g. both scalars and trace data) from a single measurement. FETCh saves you the time of re-making the measurement. You can only FETCh results from the measurement that is currently active, it will not change to a different measurement.

If you need to get new measurement data, use the READ command, which is equivalent to an INITiate followed by a FETCh.

The scalar measurement results will be returned if the optional [n] value is not included, or is set to 1. If the [n] value is set to a value other than 1, the selected trace data results will be returned. See each command for details of what types of scalar results or trace data results are available. The binary data formats should be used for handling large blocks of data since they are smaller and transfer faster than the ASCII format. (FORMat:DATA)

FETCh may be used to return results other than those specified with the original READ or MEASure command that you sent.

Read Commands

:READ:<measurement>[n]?

- Does not preset the measurement to the factory default settings. For example, if you have previously initiated the ACP measurement and you send READ:ACP? it will initiate a new measurement using the same instrument settings.
- Initiates the measurement and puts valid data into the output buffer. If a measurement other than the current one is specified, the instrument will switch to that measurement before it initiates the measurement and returns results.

For example, suppose you have previously initiated the ACP measurement, but now you are running the channel power measurement. Then you send READ:ACP? It will change from channel power back to ACP and, using the previous ACP settings, will initiate the measurement and return results.

- Blocks other SCPI communication, waiting until the measurement is complete before returning the results

If the optional [n] value is not included, or is set to 1, the scalar measurement results will be returned. If the [n] value is set to a value other than 1, the selected trace data results will be returned. See each command for details of what types of scalar results or trace data results are available. The binary data formats should be used when handling large blocks of data since they are smaller and faster than the ASCII format. (FORMat:DATA)

Adjacent Channel Power Ratio (ACP) Measurement

This measures the total rms power in the specified channel and in 5 offset channels. You must be in cdmaOne, cdma2000, W-CDMA (3GPP), NADC or PDC mode to use these commands. Use INSTRument:SElect to set the mode.

The general functionality of CONFigure, FETCh, MEASure, and READ are described at the beginning of this section. See the SENSE:ACP commands for more measurement related commands.

:CONFigure:ACP

:FETCh:ACP[n]?

:READ:ACP[n]?

:MEASure:ACP[n]?

For Basic mode, a channel frequency and power level can be defined in the command statement to override the default standard setting. A comma must precede the power value as a place holder for the frequency, when no frequency is sent.

Front Panel

Access: **Measure, ACPor ACPR**

After the measurement is selected, press **Restore Meas Defaults** to restore factory defaults.

Measurement Results Available

Measurement Type	n	Results Returned
	0	Returns unprocessed I/Q trace data, as a series of comma-separated trace points, in volts. The I values are listed first in each pair, using the 0 through even-indexed values. The Q values are the odd-indexed values.
	not specified or n=1 NADC and PDC mode	Returns 22 comma-separated scalar results, in the following order: <ol style="list-style-type: none"> 1. Center frequency – absolute power (dBm) 2. Center frequency – absolute power (W) 3. Negative offset frequency (1) – relative power (dB) 4. Negative offset frequency (1) – absolute power (dBm) 5. Positive offset frequency (1) – relative power (dB) 6. Positive offset frequency (1) – absolute power (dBm) <p style="text-align: center;">. . .</p> <ol style="list-style-type: none"> 21. Positive offset frequency (5) – relative power (dB) 22. Positive offset frequency (5) – absolute power (dBm)

Measurement Type	n	Results Returned
Total power reference	not specified or n=1 Basic, cdmaOne, cdma2000, W-CDMA (3GPP) mode	Returns 24 comma-separated scalar results, in the following order: <ol style="list-style-type: none"> 1. Upper adjacent chan center frequency - relative power (dB) 2. Upper adjacent chan center frequency - absolute power (dBm) 3. Lower adjacent chan center frequency - relative power (dB) (same as upper) 4. Lower adjacent chan center frequency - absolute power (dBm) (same as upper) 5. Negative offset frequency (1) - relative power (dB), 6. Negative offset frequency (1) - absolute power (dBm) 7. Positive offset frequency (1) - relative power (dB) 8. Positive offset frequency (1) - absolute power (dBm) ... 23. Positive offset frequency (5) - relative power (dB) 24. Positive offset frequency (5) - absolute power (dBm)
Power spectral density reference	not specified or n=1 Basic, cdmaOne, cdma2000, W-CDMA (3GPP) mode	Returns 24 comma-separated scalar results, in the following order: <ol style="list-style-type: none"> 1. Upper adjacent chan center frequency - relative power (dB) 2. Upper adjacent chan center frequency - absolute power (dBm/Hz) 3. Lower adjacent chan center frequency - relative power (dB) (same as upper) 4. Lower adjacent chan center frequency - absolute power (dBm/Hz) (same as upper) 5. Negative offset frequency (1) - relative power (dB) 6. Negative offset frequency (1) - absolute power (dBm/Hz) 7. Positive offset frequency (1) - relative power (dB) 8. Positive offset frequency (1) - absolute power (dBm/Hz) ... 23. Positive offset frequency (5) - relative power (dB) 24. Positive offset frequency (5) - absolute power (dBm/Hz)
	2 NADC and PDC mode	Returns 10 comma-separated scalar values of the pass/fail (0=passed, or 1=failed) results determined by testing the absolute power of the offset frequencies: <ol style="list-style-type: none"> 1. Negative offset frequency (1) absolute power 2. Positive offset frequency (1) absolute power ... 9. Negative offset frequency (5) absolute power 10. Positive offset frequency (5) absolute power

Measurement Type	n	Results Returned
Total power reference	2 Basic, cdmaOne, cdma2000, W-CDMA (3GPP) mode	Returns 11 comma-separated scalar values (in dBm) corresponding to the total power histogram display. The values are returned in ascending frequency order: <ol style="list-style-type: none"> 1. Negative offset frequency (5) 2. Negative offset frequency (4) ... 6. Center frequency 7. Positive offset frequency (1) ... 11. Positive offset frequency (5)
	3 NADC and PDC mode	Returns 10 comma-separated scalar values of the pass/fail (0=passed, or 1=failed) results determined by testing the relative power of the offset frequencies: <ol style="list-style-type: none"> 1. Negative offset frequency (1) relative power 2. Positive offset frequency (1) relative power ... 9. Negative offset frequency (5) relative power 10. Positive offset frequency (5) relative power
Power spectral density reference	3 Basic, cdmaOne, cdma2000, W-CDMA (3GPP) mode	Returns 11 comma-separated scalar values (in dBm/Hz) corresponding to the power spectral density histogram display. The values are returned in ascending frequency order: <ol style="list-style-type: none"> 1. Negative offset frequency (5) 2. Negative offset frequency (4) ... 6. Center frequency 7. Positive offset frequency (1) ... 11. Positive offset frequency (5)
	4 NADC and PDC mode	Returns the frequency-domain spectrum trace (data array) for the entire frequency range being measured. In order to return spectrum data, the ACP display must be in the spectrum view and you must not turn off the spectrum trace.

Measurement Type	n	Results Returned
(For cdma2000 and W-CDMA the data is only available with spectrum display selected)	4 Basic, cdmaOne, cdma2000, W-CDMA (3GPP) mode	<p>Returns the frequency-domain spectrum trace data for the entire frequency range being measured.</p> <p>With the spectrum view selected (DISPlay:ACP:VIEW SPECTrum) and the spectrum trace on (SENSE:ACP:SPECTrum:ENABLE):</p> <ul style="list-style-type: none"> In FFT mode (SENSE:ACP:SWEep:TYPE FFT) the number of trace points returned are 343 (cdma2000) or 1715 (W-CDMA). This is with the default span of 5 MHz (cdma2000) or 25 MHz (W-CDMA). The number of points also varies if another offset frequency is set. In sweep mode (SENSE:ACP:SWEep:TYPE SWEep), the number of trace points returned is 601 (for cdma2000 or W-CDMA) for any span. <p>With bar graph display selected, one point of -999.0 will be returned.</p>
Total power reference	5 Basic, cdmaOne, cdma2000, W-CDMA (3GPP) mode	<p>Returns 12 comma-separated scalar values (in dBm) of the absolute power of the center and the offset frequencies:</p> <ol style="list-style-type: none"> Upper adjacent chan center frequency Lower adjacent chan center frequency Negative offset frequency (1) Positive offset frequency (1) ... Negative offset frequency (5) Positive offset frequency (5)
Power spectral density reference	5 Basic, cdmaOne, cdma2000, W-CDMA (3GPP) mode	<p>Returns 12 comma-separated scalar values (in dBm/Hz) of the absolute power of the center and the offset frequencies:</p> <ol style="list-style-type: none"> Upper adjacent chan center frequency Lower adjacent chan center frequency Negative offset frequency (1) Positive offset frequency (1) ... Negative offset frequency (5) Positive offset frequency (5)

NADC Programming Commands
MEASure Group of Commands

Measurement Type	n	Results Returned
Total power reference	6 Basic, cdmaOne, cdma2000, W-CDMA (3GPP) mode	Returns 12 comma-separated scalar values (total power in dB) of the power relative to the carrier at the center and the offset frequencies: <ol style="list-style-type: none"> 1. Upper adjacent chan center frequency 2. Lower adjacent chan center frequency 3. Negative offset frequency (1) 4. Positive offset frequency (1) 5. Negative offset frequency (5) <p style="text-align: center;">. . .</p> <ol style="list-style-type: none"> 11. Negative offset frequency (5) 12. Positive offset frequency (5)
Power spectral density reference	6 Basic, cdmaOne, cdma2000, W-CDMA (3GPP) mode	Returns 12 comma-separated scalar values (power spectral density in dB) of the power relative to the carrier at the center and offset frequencies: <ol style="list-style-type: none"> 1. Upper adjacent chan center frequency 2. Lower adjacent chan center frequency 3. Negative offset frequency (1) 4. Positive offset frequency (1) <p style="text-align: center;">. . .</p> <ol style="list-style-type: none"> 11. Negative offset frequency (5) 12. Positive offset frequency (5)
Total power reference	7 Basic, cdmaOne, cdma2000, W-CDMA (3GPP) mode	Returns 12 comma-separated scalar values of the pass/fail (0=passed, or 1=failed) results determined by testing the absolute power limit of the center and offset frequencies (measured as total power in dB): <ol style="list-style-type: none"> 1. Upper adjacent chan center frequency 2. Lower adjacent chan center frequency 3. Negative offset frequency (1) 4. Positive offset frequency (1) <p style="text-align: center;">. . .</p> <ol style="list-style-type: none"> 11. Negative offset frequency (5) 12. Positive offset frequency (5)

Measurement Type	n	Results Returned
Power spectral density reference	7 Basic, cdmaOne, cdma2000, W-CDMA (3GPP) mode	Returns 12 comma-separated scalar values of the pass/fail (0=passed, or 1=failed) results determined by testing the absolute power limit of the center and offset frequencies (measured as power spectral density in dB): <ol style="list-style-type: none"> 1. Upper adjacent chan center frequency 2. Lower adjacent chan center frequency 3. Negative offset frequency (1) 4. Positive offset frequency (1) ... 11. Negative offset frequency (5) 12. Positive offset frequency (5)
Total power reference	8 Basic, cdmaOne, cdma2000, W-CDMA (3GPP) mode	Returns 12 comma-separated scalar values of the pass/fail (0=passed, or 1=failed) results determined by testing the power limit relative to the center frequency (measured as total power spectral in dB): <ol style="list-style-type: none"> 1. Upper adjacent chan center frequency 2. Lower adjacent chan center frequency 3. Negative offset frequency (1) 4. Positive offset frequency (1) ... 11. Negative offset frequency (5) 12. Positive offset frequency (5)
Power spectral density reference	8 Basic, cdmaOne, cdma2000, W-CDMA (3GPP) mode	Returns 12 comma-separated scalar values of the pass/fail (0=passed, or 1=failed) results determined by testing the power limit relative to the center frequency (measured as power spectral density in dB): <ol style="list-style-type: none"> 1. Upper adjacent chan center frequency 2. Lower adjacent chan center frequency 3. Negative offset frequency (1) 4. Positive offset frequency (1) ... 11. Negative offset frequency (5) 12. Positive offset frequency (5)

NADC Programming Commands
 MEASure Group of Commands

Error Vector Magnitude Measurement

This measures the vector error of the magnitude of each symbol. You must be in the NADC or PDC mode to use these commands. Use INSTRument:SElect to set the mode.

The general functionality of CONFigure, FETCh, MEASure, and READ are described at the beginning of this section. See the SENSE:EVM commands for more measurement related commands.

:CONFigure:EVM

:FETCh:EVM[n]?

:READ:EVM[n]?

:MEASure:EVM[n]?

History: Version A.02.00 or later

Front Panel

Access: **Measure, EVM**

After the measurement is selected, press **Restore Meas Defaults** to restore factory defaults.

Measurement Results Available

n	Results Returned
0	Returns unprocessed I/Q trace data, as a data array of comma-separated trace points, in volts.

n	Results Returned
<p>1 (default) EDGE GSM mode</p>	<p>Returns the following 8 comma-separated scalar results, in order.</p> <ol style="list-style-type: none"> 1. RMS EVM – a floating point number (in percent) of EVM over the entire measurement area. 2. Peak EVM error – a floating point number (in percent) of the peak EVM in the measurement area. 3. Symbol position of the peak EVM error – an integer number of the symbol position where the peak EVM error is detected. 4. First 10 symbols EVM error – a floating point number (in percent) of EVM over the first 10 symbols. 5. Magnitude error – a floating point number (in percent) of average magnitude error over the entire measurement area. 6. Phase error – a floating point number (in degree) of average phase error over the entire measurement area. 7. Frequency error – a floating point number (in Hz) of the frequency error in the measured signal. 8. I/Q origin offset – a floating point number (in dB) of the I and Q error (magnitude squared) offset from the origin.
<p>1 (default) NADC mode</p>	<p>Returns the following 8 comma-separated scalar results, in order.</p> <ol style="list-style-type: none"> 1. RMS EVM – a floating point number (in percent) of EVM over the entire measurement area. 2. Peak EVM error – a floating point number (in percent) of the peak EVM in the measurement area. 3. Symbol position of the peak EVM error – an integer number of the symbol position where the peak EVM error is detected. 4. First 10 symbols EVM error – a floating point number (in percent) of EVM over the first 10 symbols. 5. Magnitude error – a floating point number (in percent) of average magnitude error over the entire measurement area. 6. Phase error – a floating point number (in degree) of average phase error over the entire measurement area. 7. Frequency error – a floating point number (in Hz) of the frequency error in the measured signal. 8. I/Q origin offset – a floating point number (in dB) of the I and Q error (magnitude squared) offset from the origin.

NADC Programming Commands
MEASure Group of Commands

n	Results Returned
1 (default) PDC mode	<p>Returns the following 7 comma-separated scalar results, in order.</p> <ol style="list-style-type: none"> 1. RMS EVM – a floating point number (in percent) of EVM over the entire measurement area. 2. Peak EVM error – a floating point number (in percent) of peak EVM in the measurement area. 3. Symbol position of the peak EVM error – an integer number of the symbol position where the peak EVM error is detected. 4. Magnitude error – a floating point number (in percent) of average magnitude error over the entire measurement area. 5. Phase error – a floating point number (in degree) of average phase error over the entire measurement area. 6. Frequency error – a floating point number (in Hz) of the frequency error in the measured signal. 7. I/Q origin offset – a floating point number (in dB) of the I and Q error (magnitude squared) offset from the origin.
2	Returns series of floating point numbers (in percent) that represent each sample in the EVM trace. The first number is the symbol 0 decision point and there are 5 points per symbol. Therefore, the decision points are at 0, 5, 10, 15. . . .
3	Returns series of floating point numbers (in percent) that represent each sample in the magnitude error trace. The first number is the symbol 0 decision point and there are 5 points per symbol. Therefore, the decision points are at 0, 5, 10, 15. . . .
4	Returns series of floating point numbers (in degree) that represent each sample in the phase error trace. The first number is the symbol 0 decision point and there are 5 points per symbol. Therefore, the decision points are at 0, 5, 10, 15
5	<p>Returns series of floating point numbers that alternately represent I and Q pairs of the corrected measured trace. The magnitude of each I and Q pair are normalized to 1.0. The first number is the in-phase (I) sample of symbol 0 decision point and the second is the quadrature-phase (Q) sample of symbol 0 decision point. As in the EVM, there are 5 points per symbol, so the series of numbers is:</p> <p style="margin-left: 40px;">1st number = I of the symbol 0 decision point 2nd number = Q of the symbol 0 decision point</p> <p style="margin-left: 40px;">$(2 \times 5) + 1$ (or 11th) number = I of the symbol 1 decision point $(2 \times 5) + 2$ (or 12th) number = Q of the symbol 1 decision point</p> <p style="margin-left: 40px;">$(2 \times 5) \times N + 1$ number = I of the symbol N decision point $(2 \times 5) \times N + 2$ number = Q of the symbol N decision point</p>

n	Results Returned
<p>6 NADC mode</p>	<p>Returns the following 4 comma-separated scalar values of 1 or 0, in the order given. The pass/fail results (0=passed, or 1=failed) are determined by testing the EVM, peak EVM, first 10 symbols EVM and IQ origin offsets.</p> <p>Test result of EVM Test result of peak EVM Test result of first 10 symbols EVM Test result of IQ origin offset</p>
<p>6 PDC mode</p>	<p>Returns the following 3 comma-separated scalar values of 1 or 0, in the order given. The pass/fail results (0=passed, or 1=failed) are determined by testing the EVM, peak EVM, and IQ origin offsets.</p> <p>Test result of EVM Test result of peak EVM Test result of IQ origin offset</p>

Spectrum (Frequency Domain) Measurement

This measures the amplitude of your input signal with respect to the frequency. It provides spectrum analysis capability using FFT (fast Fourier transform) measurement techniques. You must be in the Basic, cdmaOne, cdma2000, W-CDMA (3GPP), GSM (w/EDGE), NADC, or PDC mode to use these commands. Use INSTRument:SElect, to select the mode.

The general functionality of CONFigure, FETCh, MEASure, and READ are described at the beginning of this section. See the SENSE:SPECTrum commands for more measurement related commands.

:CONFigure:SPECTrum

:FETCh:SPECTrum[n]?

:READ:SPECTrum[n]?

:MEASure:SPECTrum[n]?

Front Panel

Access: **Measure, Spectrum (Freq Domain)**

After the measurement is selected, press **Restore Meas Defaults** to restore factory defaults.

Measurement Results Available

n	Results Returned
0	Returns unprocessed I/Q trace data, as a series of comma-separated trace points, in volts. The I values are listed first in each pair, using the 0 through even-indexed values. The Q values are the odd-indexed values.

n	Results Returned
not specified or n=1	<p>Returns the following comma-separated scalar results:</p> <ol style="list-style-type: none"> 1. FFT peak is the FFT peak amplitude. 2. FFT frequency is the FFT frequency of the peak amplitude. 3. FFT points is the Number of points in the FFT spectrum. 4. First FFT frequency is the frequency of the first FFT point of the spectrum. 5. FFT spacing is the frequency spacing between the FFT points of the spectrum. 6. Time domain points is the number of points in the time domain trace used for the FFT. The number of points doubles if the data is complex instead of real. See the time domain scaler description below. 7. First time point is the time of the first time domain point, where time zero is the trigger event. 8. Time spacing is the time spacing between the time domain points. The time spacing value doubles if the data is complex instead of real. See the time domain scaler description below. 9. Time domain returns a 1 if time domain is complex (I/Q) and complex data will be returned. It returns a 0 if the data is real. (raw ADC samples) When this value is 1 rather than 0 (complex vs. real data), the time domain points and the time spacing scalars both increase by a factor of two. 10. Scan time is the total scan time of the time domain trace used for the FFT. The total scan time = (time spacing) X (time domain points – 1) 11. Current average count is the current number of data measurements that have already been combined, in the averaging calculation.
3	Returns the I and Q trace data. It is represented by I and Q pairs (in volts) versus time.
4	Returns spectrum trace data. That is, the trace of log-magnitude versus frequency. (The trace is computed using a FFT.)
6	Not used.
7	Returns the averaged spectrum trace data. That is, the trace of the averaged log-magnitude versus frequency.
8	Not used.
11, cdma2000, W-CDMA, Basic modes only	Returns comma-separated linear spectrum trace data in Volts RMS.
12, cdma2000, W-CDMA, Basic modes only	Returns comma-separated averaged linear spectrum trace data in Volts RMS.

NADC Programming Commands
 MEASure Group of Commands

Waveform (Time Domain) Measurement

This measures the amplitude of your input signal with respect to the frequency. It provides spectrum analysis capability using FFT (fast Fourier transform) measurement techniques. You must be in the Basic, cdmaOne, cdma2000, W-CDMA (3GPP), GSM (w/EDGE), NADC, or PDC mode to use these commands. Use INSTRument:SElect, to select the mode.

The general functionality of CONFigure, FETCh, MEASure, and READ are described at the beginning of this section. See the SENSE:WAVEform commands for more measurement related commands.

:CONFigure:WAVEform

:FETCh:WAVEform[n]?

:READ:WAVEform[n]?

:MEASure:WAVEform[n]?

Front Panel

Access: **Measure, Waveform (Time Domain)**

After the measurement is selected, press **Restore Meas Defaults** to restore factory defaults.

Measurement Results Available

n	Results Returned
0 (see also 5)	Returns unprocessed I/Q trace data, as a series of comma-separated trace points, in volts. The I values are listed first in each pair, using the 0 through even-indexed values. The Q values are the odd-indexed values.

n	Results Returned
not specified or n=1	<p>Returns the following comma-separated scalar results:</p> <ol style="list-style-type: none"> 1. Sample time is a floating point number representing the time between samples when using the trace queries (n=0,2,etc). 2. Mean power is the mean power (in dBm). This is either the power across the entire trace, or the power between markers if the markers are enabled. If averaging is on, the power is for the latest acquisition. 3. Mean power averaged is the power (in dBm) for N averages, if averaging is on. This is either the power across the entire trace, or the power between markers if the markers are enabled. If averaging is on, the power is for the latest acquisition. If averaging is off, the value of the mean power averaged is the same as the value of the mean power. 4. Number of samples is the number of data points in the captured signal. This number is useful when performing a query on the signal (i.e. when n=0,2,etc.). 5. Peak-to-mean ratio has units of dB. This is the ratio of the maximum signal level to the mean power. Valid values are only obtained with averaging turned off. If averaging is on, the peak-to-mean ratio is calculated using the highest peak value, rather than the displayed average peak value. 6. Maximum value is the maximum of the most recently acquired data (in dBm). 7. Minimum value is the minimum of the most recently acquired data (in dBm).
2	<p>Returns comma-separated trace points of the entire captured trace data. These data points are floating point numbers representing the power of the signal (in dBm). There are N data points, where N is the number of samples. The period between the samples is defined by the sample time.</p>
5, cdma2000, W-CDMA, Basic modes only	<p>In input modes other than Ionly and Qonly returns comma-separated values of both I and Q trace data in Volts. The values are in pairs with the I value first. If the input mode is Ionly and Qonly the data returned is comma-separated values of just the I data or the Q data.</p>

READ Subsystem

The READ? commands are used with several other commands and are documented in the section on the “[MEASure Group of Commands](#)” on [page 148](#).

Initiate and Read Measurement Data

`:READ:<measurement>[n]?`

A READ? query must specify the desired measurement. It will cause a measurement to occur without changing any of the current settings and will return any valid results. The code number *n* selects the kind of results that will be returned. The available measurements and data results are described in the “[MEASure Group of Commands](#)” on [page 148](#).

SENSe Subsystem

These commands are used to set the instrument state parameters so that you can measure a particular input signal. Some SENSe commands are only for use with specific measurements found under the MEASURE key menu or the “MEASure Group of Commands” on page 148. The measurement must be active before you can use these commands.

The SCPI default for the format of any data output is ASCII. The format can be changed to binary with FORMat:DATA which transports faster over the bus.

Adjacent Channel Power Measurement

Commands for querying the adjacent channel power measurement results and for setting to the default values are found in the “MEASure Group of Commands” on page 148. The equivalent front panel keys for the parameters described in the following commands, are found under the Meas Setup key, after the ACP or ACPR measurement has been selected from the MEASURE key menu.

Adjacent Channel Power—Average Count

```
[ :SENSe ] :ACP :AVERAge :COUNT <integer>
```

```
[ :SENSe ] :ACP :AVERAge :COUNT ?
```

Set the number of data acquisitions that will be platform averaged. After the specified number of average counts, the average mode (termination control) setting determines the average action.

Factory Preset: 10 for cdma2000, W-CDMA

20 for Basic, cdmaOne

Range: 1 to 10,000

Remarks: Use INSTRument:SElect to set the mode.

Front Panel

Access: Meas Setup

Adjacent Channel Power—Averaging State

```
[ :SENSe ] :ACP :AVERAge [ :STATe ] OFF | ON | 0 | 1
```

```
[ :SENSe ] :ACP :AVERAge [ :STATe ] ?
```

Turn average on or off.

Factory Preset: On

NADC Programming Commands SENSe Subsystem

Remarks: Use INSTRument:SElect to set the mode.

Front Panel

Access: Meas Setup

Adjacent Channel Power—Averaging Termination Control

```
[ :SENSe ]:ACP:AVERAge:TCONtrol EXPONential|REPeat
```

```
[ :SENSe ]:ACP:AVERAge:TCONtrol?
```

Select the type of termination control used for averaging. This determines the averaging action after the specified number of data acquisitions (average count) is reached.

EXPONential – Each successive data acquisition after the average count is reached, is exponentially weighted and combined with the existing average.

REPeat – After reaching the average count, the averaging is reset and a new average is started.

Factory Preset: REPeat for cdmaOne, cdma2000, W-CDMA

EXPONential for NADC, PDC

Remarks: Use INSTRument:SElect to set the mode.

Adjacent Channel Power—Offset Frequency Absolute Limit

```
[ :SENSe ]:ACP:LIST:ALIMit
```

```
<abs_powr>,<abs_powr>,<abs_powr>,<abs_powr>,<abs_powr>
```

```
[ :SENSe ]:ACP:LIST:ALIMit?
```

Set the absolute limit on offset frequencies relative to the carrier. You can turn off (not use) specific offsets with the [:SENSe]:ACP:LIST:STATe command.

Factory Preset:

Mode	Offset A	Offset B	Offset C	Offset D	Offset E
NADC	0 dBm	0 dBm	-13 dBm	0 dBm	0 dBm
PDC	0 dBm	0 dBm	0 dBm	0 dBm	0 dBm

Range: -200 to 50 dBm

Remarks: You must be in the NADC, cdmaOne, or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Adjacent Channel Power—Offset Frequency

```
[ :SENSe ]:ACP:LIST[ :FREQuency ]
<f_offset>,<f_offset>,<f_offset>,<f_offset>,<f_offset>
```

```
[ :SENSe ]:ACP:LIST[ :FREQuency ]?
```

Define the offset frequencies. You can turn off (not use) specific offsets with the [:SENSe]:ACP:LIST:STATe command.

Factory Preset:

Mode	Offset A	Offset B	Offset C	Offset D	Offset E
NADC	30 kHz	60 kHz	90 kHz	120 kHz	0 Hz
PDC	50 kHz	100 kHz	0 kHz	0 kHz	0 kHz

Range: 10 Hz to 45 MHz
0 to 200 kHz

Default Unit: Hz

Remarks: You must be in the NADC, cdmaOne, or PDC mode to use this command. Use INSTRument:SELEct to set the mode.

Adjacent Channel Power—Offset Frequency Power Mode

```
[ :SENSe ]:ACP:LIST:POWer
INTeg | PEAK,INTeg | PEAK,INTeg | PEAK,INTeg | PEAK,INTeg | PEAK
```

```
[ :SENSe ]:ACP:LIST:POWer?
```

Define the power measurement mode for each of the offset frequencies. You can turn off (not use) specific offsets with the SENS:ACP:LIST:STATe command.

Factory Preset: INTeg, INTeg, INTeg, INTeg, INTeg

Remarks: You must be in the NADC mode to use this command. Use INSTRument:SELEct to set the mode.

Adjacent Channel Power—Offset Frequency Relative Limit

```
[ :SENSe ]:ACP:LIST:RLIMit
<rel_powr>,<rel_powr>,<rel_powr>,<rel_powr>,<rel_powr>
```

```
[ :SENSe ]:ACP:LIST:RLIMit?
```

Set the relative limit on offset frequencies. You can turn off (not use) specific offsets with the SENS:ACP:LIST:STATe command.

NADC Programming Commands

SENSe Subsystem

Factory Preset: -45 dB

Mode	Offset A	Offset B	Offset C	Offset D	Offset E
NADC	-26 dB	-45 dB	-45 dB	0 dB	0 dB
PDC	-45 dB	-60 dB	0 dB	0 dB	0 dB

Range: -200 to 50 dB

Remarks: You must be in the NADC, cdmaOne, or PDC mode to use this command. Use INSTRUMENT:SElect to set the mode.

Adjacent Channel Power—Offset Frequency Control

```
[ :SENSe ]:ACP:LIST:STATE OFF|ON|0|1, OFF|ON|0|1, OFF|ON|0|1,
OFF|ON|0|1, OFF|ON|0|1
```

```
[ :SENSe ]:ACP:LIST:STATE?
```

Turn measurement on or off for the custom offset frequencies.

Factory Preset:

Mode	Offset A	Offset B	Offset C	Offset D	Offset E
NADC	ON	ON	ON	OFF	OFF
PDC	ON	ON	OFF	OFF	OFF

Remarks: You must be in the NADC, cdmaOne, or PDC mode to use this command. Use INSTRUMENT:SElect to set the mode.

Adjacent Channel Power—Offset Frequency Test Mode

```
[ :SENSe ]:ACP:LIST:TEST ABSolute|AND|RELative|OR,
ABSolute|AND|RELative|OR, ABSolute|AND|RELative|OR,
ABSolute|AND|RELative|OR, ABSolute|AND|RELative|OR
```

```
[ :SENSe ]:ACP:LIST:TEST?
```

Define the type of testing to be done for the five custom offset frequencies. You can turn off (not use) specific offsets with the SENS:ACP:LIST:STATE command.

Factory Preset: RELative, RELative, OR, AND, AND for NADC, PDC mode

Remarks: You must be in the NADC, cdmaOne, or PDC mode to use this command. Use INSTRUMENT:SELEct to set the mode.

Adjacent Channel Power—Trigger Source

```
[ :SENSE ] : ACP : TRIGger : SOURce  
EXTernal [ 1 ] | EXTernal2 | FRAMe | IF | IMMEDIATE | RFBurst
```

```
[ :SENSE ] : ACP : TRIGger : SOURce?
```

Select the trigger source used to control the data acquisitions.

EXTernal 1 – front panel external trigger input

EXTernal 2 – rear panel external trigger input

FRAMe – internal frame trigger from front panel input

IF – internal IF envelope (video) trigger

IMMEDIATE – the next data acquisition is immediately taken, capturing the signal asynchronously (also called free run).

RFBurst – wideband RF burst envelope trigger that has automatic level control for periodic burst signals.

Factory Preset: IMMEDIATE for BS

RFBurst for MS

Remarks: You must be in cdmaOne, NADC, or PDC mode to use this command. Use INSTRUMENT:SELEct to set the mode.

In Basic mode, for offset frequencies >12.5 MHz, the external triggers will be a more reliable trigger source than RF burst. Also, you can use the Waveform measurement to set up trigger delay.

Adjacent Channel Power—Power Reference

```
[ :SENSE ] : ACP : TYPE PSDRef | TPRef
```

```
[ :SENSE ] : ACP : TYPE?
```

Selects the measurement type. This allows you to make absolute and relative power measurements of either total power or the power normalized to the measurement bandwidth.

Power Spectral Density Reference (PSDRef) - the power spectral density is used as the power reference

NADC Programming Commands
SENSE Subsystem

Total Power Reference (TPRef) - the total power is used as the power reference

Factory Preset: Total power reference (TPRef)

Remarks: You must be in the cdmaOne, cdma2000, W-CDMA, NADC, or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Channel Commands

Burst Type

`[:SENSe]:CHANnel:BURSt TCH|CCH`

`[:SENSe]:CHANnel:BURSt?`

Set the burst type for mobile station testing.

Traffic Channel (TCH) – burst for traffic channel

Control Channel (CCH) – burst for control channel

Factory Preset: TCH

Remarks: The command is only applicable for mobile station testing, device = MS.

You must be in the NADC or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Time Slot number

`[:SENSe]:CHANnel:SLOT <integer>`

`[:SENSe]:CHANnel:SLOT?`

Select the slot number that you want to measure.

In GSM mode the measurement frame is divided into the eight expected measurement timeslots.

Factory Preset: 0 for GSM, EDGE, PDC mode

1 for NADC mode

Range: 0 to 5 for PDC mode

1 to 6 for NADC mode

0 to 7 for GSM, EDGE mode

Remarks: You must be in GSM, EDGE, NADC, PDC mode to use this command. Use INSTRument:SElect to set the mode.

Front Panel

Access: **Mode Setup, Radio, Frequency Hopping Repetition Factor**

NADC Programming Commands

SENSe Subsystem

Time Slot Auto

```
[ :SENSe ] :CHANnel :SLOT :AUTO OFF | ON | 0 | 1
```

```
[ :SENSe ] :CHANnel :SLOT :AUTO?
```

Select auto or manual control for slot searching. The feature is only supported in external and frame trigger source modes. In external trigger mode when timeslot is set on, the demodulation measurement is made on the nth timeslot specified by the external trigger point + n timeslots, where n is the selected timeslot value 0 to 7. In frame trigger mode when timeslot is set on, then demodulation measurement is only made on the nth timeslot specified by bit 0 of frame reference burst + n timeslots, where n is the selected timeslot value 0 to 7 and where the frame reference burst is specified by Ref Burst and Ref TSC (Std) combination.

Factory Preset: ON, for NADC, PDC mode

OFF, for GSM, EDGE mode

Remarks: The command is only applicable for mobile station testing, device = MS.

You must be in GSM, EDGE, NADC, PDC mode to use this command. Use INSTRument:SElect to set the mode.

Signal Corrections Commands

Correction for Base Station RF Port External Attenuation

```
[ :SENSE]:CORREction:BS[:RF]:LOSS <rel_power>
```

```
[ :SENSE]:CORREction:BS[:RF]:LOSS?
```

Set the correction equal to the external attenuation used when measuring base stations.

Factory Preset: 0 dB

Range: -50 to 100 dB for cdmaOne
 -50 to 50 dB for NADC or PDC

Default Unit: dB

Remarks: You must be in the cdmaOne, NADC or PDC mode to use this command. Use INSTRUMENT:SElect to set the mode.

Value is global to the current mode.

Correction for Mobile Station RF Port External Attenuation

```
[ :SENSE]:CORREction:MS[:RF]:LOSS <rel_power>
```

```
[ :SENSE]:CORREction:MS[:RF]:LOSS?
```

Set the correction equal to the external attenuation used when measuring mobile stations.

Factory Preset: 0.0 dB

Range: -50 to 100.0 dB for cdmaOne, GSM, EDGE
 -100.0 to 100.0 dB for cdma2000, W-CDMA
 -50.0 to 50.0 dB for NADC, PDC

Default Unit: dB

Remarks: You must be in the cdmaOne, GSM (w/EDGE), cdma2000, W-CDMA, NADC or PDC mode to use this command. Use INSTRUMENT:SElect to set the mode.

Value is global to the current mode.

Error Vector Magnitude Measurement

Commands for querying the error vector magnitude measurement results and for setting to the default values are found in the “[MEASure Group of Commands](#)” on page 148. The equivalent front panel keys for the parameters described in the following commands, are found under the **Meas Setup** key, after the **EVM** measurement has been selected from the **MEASURE** key menu.

Error Vector Magnitude—Average Count

```
[ :SENSe ] :EVM:AVERAge:COUNT <integer>
```

```
[ :SENSe ] :EVM:AVERAge:COUNT?
```

Set the number of data acquisitions that will be averaged. After the specified number of average counts, the average mode (termination control) setting determines the average action.

Factory Preset: 10

Range: 1 to 10,000

Remarks: You must be in the NADC or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Error Vector Magnitude—Averaging State

```
[ :SENSe ] :EVM:AVERAge[ :STATe ] OFF | ON | 0 | 1
```

```
[ :SENSe ] :EVM:AVERAge[ :STATe ]?
```

Turn average on or off.

Factory Preset: ON

Remarks: You must be in the NADC or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Error Vector Magnitude—Averaging Termination Control

```
[ :SENSe ] :EVM:AVERAge:TCONTRol EXPonential | REPeat
```

```
[ :SENSe ] :EVM:AVERAge:TCONTRol?
```

Select the type of termination control used to averaging. This determines the averaging action after the specified number of data acquisitions (average count) is reached.

EXPonential – Each successive data acquisition after the average count is reached, is exponentially weighted and combined with the existing average.

REPeat – After reaching the average count, the averaging is reset and a new average is started.

Factory Preset: EXPOnential

Remarks: You must be in the NADC or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Error Vector Magnitude—Burst Synchronization Source

[:SENSE] :EVM:BSYNc:SOURce RFBurst | TSEQuence | NONE

[:SENSE] :EVM:BSYNc:SOURce?

Select the method of synchronizing the measurement to the bursts.

RFBurst – The burst sync approximates the start and stop of the useful part of the burst without demodulation of the burst.

Training Sequence (TSEQuence)– The burst sync performs a demodulation of the burst and determines the start and stop of the useful part of the burst based on the midamble training sync sequence.

NONE – The measurement is performed without searching burst.

Factory Preset: NONE for BS

TSEQuence for MS

Remarks: You must be in the NADC or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Error Vector Magnitude—Points/Symbol

[:SENSE] :EVM:TRACe:PPSYmbol <integer>

[:SENSE] :EVM:TRACe:PPSYmbol?

Select the points/symbol for EVM measurement. Only 1 or 5 are valid entries.

Factory Preset: 5

Range: 1, 5

Remarks: You must be in the NADC or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Error Vector Magnitude—Trigger Source

```
[ :SENSe ] :EVM:TRIGger:SOURce  
EXTernal[1] | EXTernal2 | FRAME | IF | IMMEDIATE | RFBurst
```

```
[ :SENSe ] :EVM:TRIGger:SOURce?
```

Select the trigger source used to control the data acquisitions.

EXTernal 1 – front panel external trigger input

EXTernal 2 – rear panel external trigger input

IF – internal IF envelope (video) trigger

IMMEDIATE – the next data acquisition is immediately taken, capturing the signal asynchronously (also called free run)

FRAME – internal frame trigger from front panel input

RFBurst – wideband RF burst envelope trigger that has automatic level control for periodic burst signals

Factory Preset: IMMEDIATE for BS

RFBurst for MS

Remarks: You must be in the NADC or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Select the Input Signal

```
[ :SENSE]:FEED RF|AREference|IFAlign
```

```
[ :SENSE]:FEED?
```

Selects the input signal. The default input signal is taken from the front panel RF input port. For calibration and testing purposes the input signal can be taken from an internal 321.4 MHz IF alignment signal or an internal 50 MHz amplitude reference source.

RF selects the signal from the front panel RF INPUT port.

AREference selects the internal 50 MHz amplitude reference signal.

IFAlign selects the internal, 321.4 MHz, IF alignment signal.

Factory Preset: RF

Front Panel

Access: **Input, Input Port**

RF Power Commands

RF Port Input Attenuation

```
[ :SENSe ] :POWER [ :RF ] :ATTenuation <rel_power>
```

```
[ :SENSe ] :POWER [ :RF ] :ATTenuation?
```

Set the RF input attenuator. This value is set at its auto value if RF input attenuation is set to auto.

Factory Preset: 0 dB

Range: 0 to 40 dB

Default Unit: dB

Front Panel

Access: Input, Input Atten

RF Port Power Range Auto

```
[ :SENSe ] :POWER [ :RF ] :RANGe :AUTO OFF | ON | 0 | 1
```

```
[ :SENSe ] :POWER [ :RF ] :RANGe :AUTO?
```

Select the RF port power range to be set either automatically or manually.

ON - power range is automatically set as determined by the actual measured power level at the start of a measurement.

OFF - power range is manually set

Factory Preset: ON

Remarks: You must be in the cdmaOne, GSM, EDGE, NADC, PDC, cdma2000, W-CDMA, mode to use this command. Use INSTRument:SElect to set the mode.

Front Panel

Access: Input, Max Total Pwr (at UUT)

RF Port Power Range Maximum Total Power

```
[ :SENSe ] :POWER [ :RF ] :RANGe [ :UPPer ] <power>
```

```
[ :SENSe ] :POWER [ :RF ] :RANGe [ :UPPer ]?
```

Set the maximum expected total power level at the radio unit under test. This value is ignored if RF port power range is set to auto. External attenuation required above 30 dBm.

Factory Preset: -15.0 dBm

Range: –100.0 to 80.0 dBm for EDGE, GSM
 –100.0 to 27.7 dBm for cdmaOne
 –200.0 to 50.0 dBm for NADC, PDC
 –200.0 to 100.0 dBm for cdma2000, W-CDMA

Default Unit: dBm

Remarks: Global to the current mode. This is coupled to the RF input attenuation

You must be in the cdmaOne, GSM, EDGE, NADC, PDC, cdma2000, W-CDMA mode to use this command. Use INSTRument:SELEct to set the mode.

Front Panel

Access: **Input, Max Total Pwr (at UUT)**

Radio Standards Commands

Radio Device Under Test

```
[ :SENSe ] :RADio :DEVIce BS | MS
```

```
[ :SENSe ] :RADio :DEVIce ?
```

Select the type of radio device to be tested.

BS – Base station transceiver test

MS – Mobile station transceiver test

Factory Preset: BS

Remarks: You must be in the NADC, or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Global to current mode.

Front Panel

Access: **Mode Setup, Radio, Device**

Radio Traffic Rate

```
[ :SENSe ] :RADio :TRATe FULL | HALF
```

```
[ :SENSe ] :RADio :TRATe ?
```

Select the traffic rate.

FULL – full traffic rate (a slot is every 20 ms)

HALF – half traffic rate (a slot is every 40 ms)

Factory Preset: FULL

Remarks: You must be in the NADC or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Spectrum (Frequency-Domain) Measurement

Commands for querying the spectrum measurement results and for setting to the default values are found in the “[MEASure Group of Commands](#)” on page 148. The equivalent front panel keys for the parameters described in the following commands, are found under the **Meas Setup** key, after the **Spectrum (Freq Domain)** measurement has been selected from the **MEASURE** key menu.

Spectrum—Data Acquisition Packing

```
[ :SENSE]:SPECTrum:ACQuisition:PACKing  
AUTO|LONG|MEDIum|SHORT
```

```
[ :SENSE]:SPECTrum:ACQuisition:PACKing?
```

Select the amount of data acquisition packing. This is an advanced control that normally does not need to be changed.

Factory Preset: AUTO

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRUMENT:SElect to set the mode.

Spectrum—ADC Dither

```
[ :SENSE]:SPECTrum:ADC:DITHer[ :STATe] AUTO|ON|OFF|2|1|0
```

```
[ :SENSE]:SPECTrum:ADC:DITHer[ :STATe]?
```

Turn the ADC dither on or off. This is an advanced control that normally does not need to be changed.

Factory Preset: AUTO

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRUMENT:SElect to set the mode.

Spectrum—ADC Range

```
[ :SENSe ] :SPEctrum:ADC:RANGe
AUTO | APEak | APLOCK | NONE | P0 | P6 | P12 | P18
```

```
[ :SENSe ] :SPEctrum:ADC:RANGe?
```

Select the range for the gain-ranging that is done in front of the ADC. This is an advanced control that normally does not need to be changed. Auto peak ranging is the default for this measurement. If you are measuring a CW signal please see the description below.

- **AUTO** - automatic range

For FFT spectrums - auto ranging should not be used. An exception to this would be if you know that your signal is “bursty”. Then you might use auto to maximize the time domain dynamic range as long as you are not very interested in the FFT data.
- **Auto Peak (APEak)** - automatically peak the range

For CW signals, the default of auto-peak ranging can be used, but a better FFT measurement of the signal can be made by selecting one of the manual ranges that are available: M6, P0 - P24. Auto peaking can cause the ADC range gain to move monotonically down during the data capture. This movement should have negligible effect on the FFT spectrum, but selecting a manual range removes this possibility. Note that if the CW signal being measured is close to the auto-ranging threshold, the noise floor may shift as much as 6 dB from sweep to sweep.
- **Auto Peak Lock (APLOCK)** - automatically peak lock the range

For CW signals, auto-peak lock ranging may be used. It will find the best ADC measurement range for this particular signal and will not move the range as auto-peak can. Note that if the CW signal being measured is close to the auto-ranging threshold, the noise floor may shift as much as 6 dB from sweep to sweep. For “bursty” signals, auto-peak lock ranging should not be used. The measurement will fail to operate, since the wrong (locked) ADC range will be chosen often and overloads will occur in the ADC.
- **NONE** - turns off any auto-ranging without making any changes to the current setting.
- **P0 to P18** - manually selects ADC ranges that add 0 to 18 dB of fixed gain across the range. Manual ranging is best for CW signals.

Factory Preset: APEak

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRUMENT:SElect to set the mode.

Spectrum—Average Clear

[:SENSE] :SPECTrum:AVERAge:CLEar

The average data is cleared and the average counter is reset.

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRUMENT:SElect to set the mode.

Spectrum—Number of Averages

[:SENSE] :SPECTrum:AVERAge:COUNT <integer>

[:SENSE] :SPECTrum:AVERAge:COUNT?

Set the number of 'sweeps' that will be averaged. After the specified number of 'sweeps' (average counts), the averaging mode (terminal control) setting determines the averaging action.

Factory Preset: 25

Range: 1 to 10,000

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRUMENT:SElect to set the mode.

Spectrum—Averaging State

[:SENSE] :SPECTrum:AVERAge[:STATE] OFF | ON | 0 | 1

[:SENSE] :SPECTrum:AVERAge[:STATE]?

Turn averaging on or off.

Factory Preset: ON

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRUMENT:SElect to set the mode.

Spectrum—Averaging Mode

```
[ :SENSe ] :SPECTrum:AVERAge:TCONtrol EXPONential | REPeat
[ :SENSe ] :SPECTrum:AVERAge:TCONtrol?
```

Select the type of termination control used for the averaging function. This determines the averaging action after the specified number of 'sweeps' (average count) is reached.

EXPONential - Each successive data acquisition after the average count is reached, is exponentially weighted and combined with the existing average.

REPeat - After reaching the average count, the averaging is reset and a new average is started.

Factory Preset: EXPONential

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Spectrum—Averaging Type

```
[ :SENSe ] :SPECTrum:AVERAge:TYPE
LOG | MAXimum | MINimum | RMS | SCALar
[ :SENSe ] :SPECTrum:AVERAge:TYPE?
```

Select the type of averaging.

LOG – The log of the power is averaged. (This is also known as video averaging.)

MAXimum – The maximum values are retained.

MINimum – The minimum values are retained.

RMS – The power is averaged, providing the rms of the voltage.

SCALar – The voltage is averaged.

Factory Preset: LOG

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Spectrum— Select Pre-FFT Bandwidth

```
[ :SENSe]:SPECTrum:BA NDwidth|BWIDth:IF:AUTO OFF|ON|0|1
```

```
[ :SENSe]:SPECTrum:BA NDwidth|BWIDth:IF:AUTO?
```

Select auto or manual control of the pre-FFT BW.

Factory Preset: AUTO, 1.55 MHz

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Front Panel

Access: Measure, Spectrum, Meas Setup, More, Advanced, Pre-FFT BW.

Spectrum — IF Flatness Corrections

```
[ :SENSe]:SPECTrum:BA NDwidth|BWIDth:IF:FLATness OFF|ON|0|1
```

```
[ :SENSe]:SPECTrum:BA NDwidth|BWIDth:IF:FLATness?
```

Turns IF flatness corrections on and off.

Factory Preset: ON

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Front Panel

Access: Measure, Spectrum, Meas Setup, More, Advanced, Pre-FFT BW

Spectrum—Pre-ADC Bandpass Filter

```
[ :SENSe]:SPECTrum:BA NDwidth|BWIDth:PADC OFF|ON|0|1
```

```
[ :SENSe]:SPECTrum:BA NDwidth|BWIDth:PADC?
```

Turn the pre-ADC bandpass filter on or off. This is an advanced control that normally does not need to be changed.

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Spectrum—Pre-FFT BW

```
[ :SENSe ]:SPECTrum:BA NDwidth|BWIDth:PFFT[:SIZE] <freq>
```

```
[ :SENSe ]:SPECTrum:BA NDwidth|BWIDth:PFFT[:SIZE]?
```

Set the pre-FFT bandwidth. This is an advanced control that normally does not need to be changed.

Frequency span, resolution bandwidth, and the pre-FFT bandwidth settings are normally coupled. If you are not auto-coupled, there can be combinations of these settings that are not valid.

Factory Preset: 1.55 MHz

1.25 MHz for cdmaOne

Range: 1 Hz to 10.0 MHz

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRument:SELEct to set the mode.

Spectrum—Pre-FFT BW Filter Type

```
[ :SENSe ]:SPECTrum:BA NDwidth|BWIDth:PFFT:TYPE FLAT|GAUSSian
```

```
[ :SENSe ]:SPECTrum:BA NDwidth|BWIDth:PFFT:TYPE?
```

Select the type of pre-FFT filter that is used. This is an advanced control that normally does not need to be changed.

Flat top (FLAT)- a filter with a flat amplitude response, which provides the best amplitude accuracy.

GAUSSian - a filter with Gaussian characteristics, which provides the best pulse response.

Factory Preset: FLAT

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRument:SELEct to set the mode.

Spectrum—Resolution BW

```
[ :SENSe ]:SPECTrum:BA NDwidth|BWIDth[:RESolution] <freq>
```

```
[ :SENSe ]:SPECTrum:BA NDwidth|BWIDth[:RESolution]?
```

Set the resolution bandwidth for the FFT. This is the bandwidth used for resolving the FFT measurement. It is not the pre-FFT bandwidth.

This value is ignored if the function is auto-coupled.

Frequency span, resolution bandwidth, and the pre-FFT bandwidth settings are normally coupled. If you are not auto-coupled, there can be combinations of these settings that are not valid.

Factory Preset: 20.0 kHz

Range: 0.10 Hz to 3.0 MHz

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRUMENT:SElect to set the mode.

Spectrum—Resolution BW Auto

```
[ :SENSE ] :SPECTrum: BANDwidth | BWIDth [ :RESolution ] :AUTO  
OFF | ON | 0 | 1
```

```
[ :SENSE ] :SPECTrum: BANDwidth | BWIDth [ :RESolution ] :AUTO?
```

Select auto or manual control of the resolution BW. The automatic mode couples the resolution bandwidth setting to the frequency span.

Factory Preset: ON

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRUMENT:SElect to set the mode.

Decimation of Spectrum Display

```
[ :SENSE ] :SPECTrum: DECimate [ :FACTor ] <integer>
```

```
[ :SENSE ] :SPECTrum: DECimate [ :FACTor ] ?
```

Sets the amount of data decimation done by the hardware and/or the software. Decimation by *n* keeps every *n*th sample, throwing away each of the remaining samples in the group of *n*. For example, decimation by 3 keeps every third sample, throwing away the two in between. Similarly, decimation by 5 keeps every fifth sample, throwing away the four in between.

Using zero (0) decimation selects the automatic mode. The measurement will then automatically choose decimation by “1” or “2” as is appropriate for the bandwidth being used.

This is an advanced control that normally does not need to be changed.

Factory Preset: 0

NADC Programming Commands

SENSe Subsystem

Range: 0 to 1,000, where 0 sets the function to automatic

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Spectrum—FFT Length

```
[ :SENSe ] :SPEctrum:FFT:LENGth <integer>
```

```
[ :SENSe ] :SPEctrum:FFT:LENGth?
```

Set the FFT length. This value is only used if length control is set to manual. The value must be greater than or equal to the window length value. Any amount greater than the window length is implemented by zero-padding. This is an advanced control that normally does not need to be changed.

Factory Preset: 706

Range: min, depends on the current setting of the spectrum window length
max, 1,048,576

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Spectrum—FFT Length Auto

```
[ :SENSe ] :SPEctrum:FFT:LENGth:AUTO OFF|ON|0|1
```

```
[ :SENSe ] :SPEctrum:FFT:LENGth:AUTO?
```

Select auto or manual control of the FFT and window lengths.

This is an advanced control that normally does not need to be changed.

On - the window lengths are coupled to resolution bandwidth, window type (FFT), pre-FFT bandwidth (sample rate) and SENSe:SPEctrum:FFT:RBWPoints.

Off - lets you set SENSe:SPEctrum:FFT:LENGth and SENSe:SPEctrum:FFT:WINDow:LENGth.

Factory Preset: ON

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Spectrum—FFT Minimum Points in Resolution BW

```
[ :SENSe ]:SPECTrum:FFT:RBWPoints <real>
```

```
[ :SENSe ]:SPECTrum:FFT:RBWPoints?
```

Set the minimum number of data points that will be used inside the resolution bandwidth. The value is ignored if length control is set to manual. This is an advanced control that normally does not need to be changed.

Factory Preset: 1.30

Range: 0.1 to 100

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Spectrum—Window Delay

```
[ :SENSe ]:SPECTrum:FFT:WINDow:DELay <real>
```

```
[ :SENSe ]:SPECTrum:FFT:WINDow:DELay?
```

Set the FFT window delay to move the FFT window from its nominal position of being centered within the time capture. This function is not available from the front panel. It is an advanced control that normally does not need to be changed.

Factory Preset: 0

Range: -10.0 to +10.0s

Default Unit: seconds

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Spectrum—Window Length

```
[ :SENSe ] :SPEctrum:FFT:WINDow:LENGth <integer>
```

```
[ :SENSe ] :SPEctrum:FFT:WINDow:LENGth?
```

Set the FFT window length. This value is only used if length control is set to manual. This is an advanced control that normally does not need to be changed.

Factory Preset: 706

Range: 8 to 1,048,576

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Spectrum—FFT Window

```
[ :SENSe ] :SPEctrum:FFT:WINDow[ :TYPE]
```

```
BH4Tap | BLACkman | FLATtop | GAUSSian | HAMMING | HANNing | KB70 | KB90 |  
KB110 | UNIFORM
```

```
[ :SENSe ] :SPEctrum:FFT:WINDow[ :TYPE]?
```

Select the FFT window type.

BH4Tap - Blackman Harris with 4 taps

BLACkman - Blackman

FLATtop - flat top, the default (for high amplitude accuracy)

GAUSSian - Gaussian with alpha of 3.5

HAMMING - Hamming

HANNing - Hanning

KB70, 90, and 110 - Kaiser Bessel with sidelobes at -70, -90, or -110 dBc

UNIFORM - no window is used. (This is the unity response.)

Factory Preset: FLATtop

Remarks: This selection affects the acquisition point quantity and the FFT size, based on the resolution bandwidth selected.

You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Spectrum—Frequency Span

[:SENSe] :SPECTrum:FREQuency:SPAN <freq>

[:SENSe] :SPECTrum:FREQuency:SPAN?

Set the frequency span to be measured.

Factory Preset: 1.0 MHz

Range: 10 Hz to 10.0 MHz (15 MHz when Service mode is selected)

Default Unit: Hz

Remarks: The actual measured span will generally be slightly wider due to the finite resolution of the FFT.

You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Spectrum—Sweep (Acquisition) Time

[:SENSe] :SPECTrum:SWEep:TIME[:VALue] <time>

[:SENSe] :SPECTrum:SWEep:TIME?

Set the sweep (measurement acquisition) time. It is used to specify the length of the time capture record. If the value you specify is less than the capture time required for the specified span and resolution bandwidth, the value is ignored. The value is set at its auto value when auto is selected. This is an advanced control that normally does not need to be changed.

Factory Preset: 188.0 μ s

Range: 100 ns to 10 s

Default Unit: seconds

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Spectrum—Sweep (Acquisition) Time Auto

```
[ :SENSe ] :SPECTrum:SWEep:TIME:AUTO OFF|ON|0|1
```

```
[ :SENSe ] :SPECTrum:SWEep:TIME:AUTO
```

Select auto or manual control of the sweep (acquisition) time. This is an advanced control that normally does not need to be changed.

AUTO - couples the Sweep Time to the Frequency Span and Resolution BW

Manual - the Sweep Time is uncoupled from the Frequency Span and Resolution BW.

Factory Preset: AUTO

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Spectrum—Trigger Source

```
[ :SENSe ] :SPECTrum:TRIGger:SOURce  
EXTErnal[1] | EXTErnal2 | FRAME | IF | LINE | IMMEDIATE | RFBURSt
```

```
[ :SENSe ] :SPECTrum:TRIGger:SOURce?
```

Select the trigger source used to control the data acquisitions.

EXTErnal1 - front panel external trigger input

EXTErnal2 - rear panel external trigger input

FRAME - internal frame timer from front panel input

IF - internal IF envelope (video) trigger

LINE - internal line trigger

IMMEDIATE - the next data acquisition is immediately taken (also called free run)

RFBURSt - wideband RF burst envelope trigger that has automatic level control for periodic burst signals

Factory Preset: IMMEDIATE (free run)

RFBURSt, for GSM mode

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Synchronization Commands

Burst Sync Delay

`[:SENSe]:SYNC:BURSt:DELay <time>`

`[:SENSe]:SYNC:BURSt:DELay?`

Set the delay for the burst measurement position from the reference position that is determined by sync word or the burst rising/falling edges.

Factory Preset: 0 sec

Range: -500 ms to 500 ms

Default Unit: seconds

Remarks: You must be in the NADC or PDC mode to use this command. Use `INSTRument:SElect` to set the mode.

Burst Search Threshold

`[:SENSe]:SYNC:STHReshold <rel_power>`

`[:SENSe]:SYNC:STHReshold?`

Set the power threshold, relative to the peak power, that is used to determine the burst rising edge and falling edge.

Factory Preset: -30 dB

Range: -200 to -0.01 dB

Default Unit: dB

Remarks: You must be in the NADC or PDC mode to use this command. Use `INSTRument:SElect` to set the mode.

Front Panel

Access: **Mode Setup, Trigger, Burst Search Threshold**

Waveform (Time-Domain) Measurement

Commands for querying the waveform measurement results and for setting to the default values are found in the “[MEASure Group of Commands](#)” on page 148. The equivalent front panel keys for the parameters described in the following commands, are found under the **Meas Setup** key, after the **Waveform (Time Domain)** measurement has been selected from the **MEASURE** key menu.

Waveform—Data Acquisition Packing

```
[ :SENSe ] :WAVEform:ACQuIstion:PACKIng AUTO | LONG | MEDium | SHORt
```

```
[ :SENSe ] :WAVEform:ACQuIstion:PACKIng?
```

This is an advanced control that normally does not need to be changed.

Factory Preset: AUTO

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Waveform—ADC Dither State

```
[ :SENSe ] :WAVEform:ADC:DITHer [ :STATe ] OFF | ON | 0 | 1
```

```
[ :SENSe ] :WAVEform:ADC:DITHer [ :STATe ] ?
```

This is an Advanced control that normally does not need to be changed.

Factory Preset: OFF

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Waveform—Pre-ADC Bandpass Filter

```
[ :SENSe ] :WAVEform:ADC:FILTer [ :STATe ] OFF | ON | 0 | 1
```

```
[ :SENSe ] :WAVEform:ADC:FILTer [ :STATe ] ?
```

Turn the pre-ADC bandpass filter on or off. This is an Advanced control that normally does not need to be changed.

Preset: OFF

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Waveform—ADC Range

[:SENSe] :WAVEform:ADC:RANGe
 AUTO | APEak | APLOCK | GROund | NONE | P0 | P6 | P12 | P18

[:SENSe] :WAVEform:ADC:RANGe?

Select the range for the gain-ranging that is done in front of the ADC. This is an Advanced control that normally does not need to be changed.

AUTO - automatic range

Auto Peak (APEak) - automatically peak the range

Auto Peak Lock (APLOCK)- automatically peak lock the range

GROund - ground

NONE - turn off auto-ranging without making any changes to the current setting.

P0 to P18 - adds 0 to 18 dB of fixed gain across the range

Factory Preset: AUTO

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Waveform - Query Aperture Setting

[:SENSe] :WAVEform:APERTure?

Returns the waveform sample period (aperture) based on current resolution bandwidth, filter type, and decimation factor. Sample rate is the reciprocal of period.

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Waveform—Number of Averages

```
[ :SENSe ] :WAVeform:AVERAge:COUNT <integer>
```

```
[ :SENSe ] :WAVeform:AVERAge:COUNT?
```

Set the number of sweeps that will be averaged. After the specified number of sweeps (average counts), the averaging mode (terminal control) setting determines the averaging action.

Factory Preset: 10

Range: 1 to 10,000

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Waveform—Averaging State

```
[ :SENSe ] :WAVeform:AVERAge[ :STATe ] OFF|ON|0|1
```

```
[ :SENSe ] :WAVeform:AVERAge[ :STATe ]?
```

Turn averaging on or off.

Factory Preset: OFF

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Waveform—Averaging Mode

```
[ :SENSe ] :WAVeform:AVERAge:TCONtrol EXPOnential|REPeat
```

```
[ :SENSe ] :WAVeform:AVERAge:TCONtrol?
```

Select the type of termination control used for the averaging function. This determines the averaging action after the specified number of 'sweeps' (average count) is reached.

EXPOnential - Each successive data acquisition after the average count is reached, is exponentially weighted and combined with the existing average.

REPeat - After reaching the average count, the averaging is reset and a new average is started.

Factory Preset: EXPOnential

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Waveform—Averaging Type

```
[ :SENSe ] :WAVeform:AVERAge:TYPE
LOG | MAXimum | MINimum | RMS | SCALar
```

```
[ :SENSe ] :WAVeform:AVERAge:TYPE?
```

Select the type of averaging.

LOG - The log of the power is averaged. (This is also known as video averaging.)

MAXimum - The maximum values are retained.

MINimum - The minimum values are retained.

RMS - The power is averaged, providing the rms of the voltage.

Factory Preset: RMS

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Waveform—Resolution BW

```
[ :SENSe ] :WAVeform:BANDwidth|BWIDth[:RESolution] <freq>
```

```
[ :SENSe ] :WAVeform:BANDwidth|BWIDth[:RESolution]?
```

Set the resolution bandwidth. This value is ignored if the function is auto-coupled.

Factory Preset: 100.0 kHz for NADC, PDC, cdma2000, W-CDMA, Basic
500.0 kHz for GSM
2.0 MHz for cdmaOne

Range: 1.0 kHz to 5.0 MHz

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Waveform - Query Actual Resolution Bandwidth

`[:SENSe] :WAVEform :BANDwidth :RESolution] :ACTual ?`

Due to memory constraints the actual resolution bandwidth value may vary from the value entered by the user. For most applications the resulting difference in value is inconsequential but for some it is necessary to know the actual value; this query retrieves the actual resolution bandwidth value.

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Waveform—Resolution BW Filter Type

`[:SENSe] :WAVEform :BANDwidth | BWIDth [:RESolution] :TYPE
FLATtop | GAUSSian`

`[:SENSe] :WAVEform :BANDwidth | BWIDth [:RESolution] :TYPE ?`

Select the type of Resolution BW filter that is used. This is an Advanced control that normally does not need to be changed.

FLATtop - a filter with a flat amplitude response, which provides the best amplitude accuracy.

GAUSSian - a filter with Gaussian characteristics, which provides the best pulse response.

Factory Preset: GAUSSian

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Waveform—Decimation of Waveform Display

`[:SENSe] :WAVEform :DECimate [:FACTOR] <integer>`

`[:SENSe] :WAVEform :DECimate [:FACTOR] ?`

Set the amount of data decimation done on the IQ data stream. For example, if 4 is selected, three out of every four data points will be thrown away. So every 4th data point will be kept.

Factory Preset: 1

Range: 1 to 4

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Waveform—Control Decimation of Waveform Display

[:SENSe] :WAVEform :DECimate :STATe OFF | ON | 0 | 1

[:SENSe] :WAVEform :DECimate :STATe ?

Set the amount of data decimation done by the hardware in order to decrease the number of acquired points in a long capture time. This is the amount of data that the measurement ignores.

Factory Preset: OFF

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Waveform—Sweep (Acquisition) Time

[:SENSe] :WAVEform :SWEep :TIME <time>

[:SENSe] :WAVEform :SWEep :TIME ?

Set the measurement acquisition time. It is used to specify the length of the time capture record.

Factory Preset: 2.0 ms

10.0 ms, for NADC, PDC

Range: 1 μ s to 100 s

Default Unit: seconds

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Waveform—Trigger Source

```
[ :SENSe]:WAVeform:TRIGger:SOURce EXTeRnal[1] |
EXTeRnal2 | FRAMe | IF | IMMEDIATE | LINE | RFBURst
```

```
[ :SENSe]:WAVeform:TRIGger:SOURce?
```

Select the trigger source used to control the data acquisitions.

EXTeRnal 1 - front panel external trigger input

EXTeRnal 2 - rear panel external trigger input

FRAMe - internal frame timer from front panel input

IF - internal IF envelope (video) trigger

IMMEDIATE - the next data acquisition is immediately taken (also called free run)

LINE - internal line trigger

RFBURst - wideband RF burst envelope trigger that has automatic level control for periodic burst signals

Factory Preset: IMMEDIATE (free run), for Basic, cdmaOne, NADC, PDC mode

RFBURst, for GSM mode

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRUMENT:SElect to set the mode.

TRIGger Subsystem

The Trigger Subsystem is used to set the controls and parameters associated with triggering the data acquisitions. Other trigger-related commands are found in the INITiate and ABORt subsystems.

The trigger parameters are global within a selected Mode. The commands in the TRIGger subsystem set up the way the triggers function, but selection of the trigger source is made from each measurement. There is a separate trigger source command in the SENSE:<meas> subsystem for each measurement. The equivalent front panel keys for the parameters described in the following commands, can be found under the **Mode Setup, Trigger** key.

Automatic Trigger Control

```
:TRIGger[:SEquence]:AUTO:STATE OFF|ON|0|1
```

```
:TRIGger[:SEquence]:AUTO:STATE?
```

Turns the automatic trigger function on and off. This function causes a trigger to occur if the designated time has elapsed and no trigger occurred. It can be used with unpredictable trigger sources, like external or burst, to make sure a measurement is initiated even if a trigger doesn't occur. Use TRIGger[:SEquence]:AUTO[:TIME] to set the time limit.

Factory Preset
and *RST Off for cdma2000, W-CDMA, NADC, PDC, 1xEV-DO

Front Panel
Access **Mode Setup, Trigger, Auto Trig**

Automatic Trigger Time

```
:TRIGger[:SEquence]:AUTO[:TIME] <time>
```

```
:TRIGger[:SEquence]:AUTO[:TIME]?
```

After the measurement is activated the instrument will take a data acquisition immediately upon receiving a signal from the selected trigger source. If no trigger signal is received by the end of the time specified in this command, a data acquisition is taken anyway. TRIGger[:SEquence]:AUTO:STATE must be on.

Factory Preset: 100.0 ms

NADC Programming Commands

TRIGger Subsystem

Range: 1.0 ms to 1000.0 s
0.0 to 1000.0 s for cdma2000, W-CDMA, 1xEV-DO

Default Unit: seconds

External Trigger Delay

```
:TRIGger[:SEquence]:EXTernal[1]|2:DELay <time>
```

```
:TRIGger[:SEquence]:EXTernal[1]|2:DELay?
```

Set the trigger delay when using an external trigger. Set the trigger value to zero (0) seconds to turn off the delay.

EXT or EXT1 is the front panel trigger input

EXT2 is the rear panel trigger input

Factory Preset: 0.0 s

Range: -100.0 ms to 100.0 ms
-100.0 ms to 500.0 ms for 1xEV-DO

Default Unit: seconds

Front Panel

Access: **Mode Setup, Trigger, Ext Rear (or Ext Front), Delay**

External Trigger Level

```
:TRIGger[:SEquence]:EXTernal[1]|2:LEVel <voltage>
```

```
:TRIGger[:SEquence]:EXTernal[1]|2:LEVel?
```

Set the trigger level when using an external trigger input.

EXT or EXT1 is the front panel trigger input

EXT2 is the rear panel trigger input

Factory Preset: 2.0 V

Range: -5.0 to +5.0 V

Default Unit: volts

Front Panel

Access: **Mode Setup, Trigger, Ext Rear, Level**

Mode Setup, Trigger, Ext Front, Level

External Trigger Slope

```
:TRIGger[:SEquence]:EXTernal[1]|2:SLOPE NEGative|POSitive
```

```
:TRIGger[:SEquence]:EXTernal[1]|2:SLOPe?
```

Sets the trigger slope when using an external trigger input.

EXT or EXT1 is the front panel trigger input

EXT2 is the rear panel trigger input

Factory Preset: Positive

Front Panel

Access: Mode Setup, Trigger, Ext Rear (or Ext Front), Slope

Frame Trigger Adjust

```
:TRIGger[:SEquence]:FRAMe:ADJust <time>
```

Lets you advance the phase of the frame trigger by the specified amount. It does not change the period of the trigger waveform. If the command is sent multiple times, it advances the phase of the frame trigger more each time it is sent.

Factory Preset: 0.0 s

Range: 0.0 to 10.0 s

Default Unit: seconds

Front Panel

Access: None

Frame Trigger Period

```
:TRIGger[:SEquence]:FRAMe:PERiod <time>
```

```
:TRIGger[:SEquence]:FRAMe:PERiod?
```

Set the frame period that you want when using the external frame timer trigger. If the traffic rate is changed, the value of the frame period is initialized to the preset value.

Factory Preset: 250.0 μ s for Basic, cdmaOne

4.615383 ms, for GSM

26.666667 ms for cdma2000 and 1xEV-DO

10.0 ms (1 radio frame) for W-CDMA

20.0 ms with rate=full for NADC, PDC

40.0 ms with rate=half for NADC, PDC

NADC Programming Commands

TRIGger Subsystem

Range: 0.0 ms to 559.0 ms for Basic, cdmaOne, GSM, cdma2000, W-CDMA, 1xEV-DO

1.0 ms to 559.0 ms for NADC, PDC

Default Unit: seconds

Front Panel

Access: Mode Setup, Trigger, Frame Timer, Period

Frame Trigger Sync Source

```
:TRIGger[:SEquence]:FRAME:SYNC EXTFront|EXTRear|OFF
```

```
:TRIGger[:SEquence]:FRAME:SYNC?
```

Selects the input port location for the external frame trigger that you are using.

Factory Preset: Off

Remarks: You must be in the Basic, cdmaOne, EDGE (w/GSM), GSM, NADC, PDC, Service mode to use this command. Use INSTRument:SElect to set the mode.

Front Panel

Access: Mode Setup, Trigger, Frame Timer, Sync Source

History Changed firmware revision A.05.00.

Frame Trigger Synchronization Offset

```
:TRIGger[:SEquence]:FRAME:SYNC:OFFSet <time>
```

```
:TRIGger[:SEquence]:FRAME:SYNC:OFFSet?
```

Lets you adjust the frame triggering with respect to the external trigger input that you are using.

Factory Preset: 0.0 s

Range: 0.0 to 10.0 s

Default Unit: seconds

Remarks: You must be in the Basic, cdmaOne, GSM, EDGE, NADC, PDC, Service mode to use this command. Use INSTRument:SElect to set the mode.

History: Revision A.03.27 or later

Front Panel

Access: Mode Setup, Trigger, Frame Timer, Offset

Trigger Holdoff

:TRIGger[:SEquence]:HOLDoff <time>

:TRIGger[:SEquence]:HOLDoff?

Set the holdoff time between triggers. After a trigger, another trigger will not be allowed until the holdoff time expires. This parameter affects all trigger sources.

Factory Preset: 0.0 s

10.0 ms for NADC or PDC

Range: 0.0 to 500.0 ms

Default Unit: seconds

Front Panel

Access: **Mode Setup, Trigger, Trig Holdoff**

Video (IF) Trigger Delay

:TRIGger[:SEquence]:IF:DELay <time>

:TRIGger[:SEquence]:IF:DELay?

Set the trigger delay when using the IF (video) trigger (after the Resolution BW filter).

Factory Preset: 0.0 s

Range: -100.0 ms to 500.0 ms

-100.0 ms to 100.0 ms for cdma2000, W-CDMA

Default Unit: seconds

Front Panel

Access: **Mode Setup, Trigger, Video (IF Envlp), Delay**

Video (IF) Trigger Level

:TRIGger[:SEquence]:IF:LEVel <amp;l>

:TRIGger[:SEquence]:IF:LEVel?

Set the trigger level when using the IF (video) trigger.

Factory Preset: -6.0 dBm for cdmaOne, GSM, EDGE, Basic,
cdma2000, W-CDMA, 1xEV-DO

-30.0 dBm for NADC, PDC

Range: -200.0 to 50.0 dBm

NADC Programming Commands

TRIGger Subsystem

Default Unit: dBm

Front Panel

Access: **Mode Setup, Trigger, Video (IF Envlp), Level**

Video (IF) Trigger Slope

```
:TRIGger[:SEquence]:IF:SLOPe NEGative|POSitive
```

```
:TRIGger[:SEquence]:IF:SLOPe?
```

Sets the trigger slope when using the IF (video) trigger.

Factory Preset: Positive

Front Panel

Access: **Mode Setup, Trigger, Video (IF Envlp), Slope**

RF Burst Trigger Delay

```
:TRIGger[:SEquence]:RFBurst:DELAy <time>
```

```
:TRIGger[:SEquence]:RFBurst:DELAy?
```

Set the trigger delay when using the RF burst (wideband) trigger.

Factory Preset: 0.0 s

Range: -100.0 ms to 500.0 ms

Default Unit: seconds

Front Panel

Access: **Mode Setup, Trigger, RF Burst, Delay**

RF Burst Trigger Level

```
:TRIGger[:SEquence]:RFBurst:LEVel <rel_power>
```

```
:TRIGger[:SEquence]:RFBurst:LEVel?
```

Set the trigger level when using the RF Burst (wideband) Trigger. The value is relative to the peak of the signal. RF Burst is also known as RF Envelope.

Factory Preset: -6.0 dB

Range: -25.0 to 0.0 dB

-200.0 to 0.0 dB for NADC, PDC

Default Unit: dB

Front Panel

Access: **Mode Setup, Trigger, RF Burst, Peak Level**

RF Burst Trigger Slope

`:TRIGger[:SEquence]:RFBurst:SLOPe NEGative|POSitive`

`:TRIGger[:SEquence]:RFBurst:SLOPe?`

Set the trigger slope when using the RF Burst (wideband) Trigger.

Factory Preset: Positive

Remarks: You must be in the cdmaOne, cdma2000, W-CDMA mode to use this command. Use `:INSTrument:SElect` to set the mode.

Front Panel

Access: **Mode Setup, Trigger, RF Burst, Slope**

NADC Programming Commands
TRIGger Subsystem

5

Understanding PDC

What is the PDC Communications System?

Personal Digital Cellular (PDC) is one of the cellular communications systems.

The PDC communications system is defined in the Research and Development Center for Radio Systems document, RCR STD-27, the Personal Digital Cellular Telecommunication System Standard.

The PDC system is a digital communications system that employs a combination of a frequency division multiple access (FDMA) and a time division multiple access (TDMA). A pair of frequencies (130 or 50 MHz apart in the 800 MHz bands and 48 MHz apart in the 1500 MHz band) is used to provide the full duplex operation with RF channels spacing 50 kHz each with interleaving by 25 kHz.

800 MHz	Uplink	940 to 958 MHz	887 to 889 MHz
	Downlink	810 to 828 MHz	832 to 834 MHz
800 MHz	Uplink	898 to 901 MHz	915 to 940MHz
	Downlink	843 to 846 MHz	860 to 885 MHz
1500 MHz	Uplink	1429 to 1453 MHz	
	Downlink	1477 to 1501 MHz	

One TDMA frame is structured with 6 timeslots, so each channel frequency can support up to 6 timeslots. Currently, two timeslots of each frame are used for one traffic channel, which is required for the full-rate speech codec. When half-rate speech codecs are incorporated into the system, each traffic channel will require just one timeslot per frame. One frame is 40 ms long and each timeslot is 6.667 ms long. Thus, the mobile stations have burst carriers that are turned on for two timeslots (full-rate codec) or one timeslot (half-rate codec). When an RF channel is in use by a digital base station, the base station carrier will be turned on for one entire frame. This is true even if only one traffic channel is in use on that RF channel. However, the carrier power can be different at each timeslot.

The digital modulation format used in the PDC system is $\pi/4$ differential quadrature phase shift keying ($\pi/4$ DQPSK). The $\pi/4$ DQPSK modulation causes both phase and amplitude variations on the RF signal. The quadrature nature of this modulation allows 2 bits to be transmitted at the same time on orthogonal carriers. There are 140 symbol periods in each timeslot, and each symbol contains 2 bits of information. Therefore, there are 280 bits in each timeslot. Since there are 1,680 bits in 6 timeslots and 25 frames in one second, the transmission bit rate is 42,000 bits per second.

What Does the Agilent PSA Series Do?

When configured for PDC, the instrument can be used to test a PDC transmitter according to the Research and Development Center for Radio Systems (RCR) document, RCR STD-27F or RCR STD-27G. This instrument can help determine if a PDC transmitter operates correctly.

This document defines complex and multiple-part measurements used to maintain an interference-free environment. For example, the document includes the testing method for carrier power. The instrument automatically makes these measurements based on the RCR standard. The detailed measurement result displays allow you to analyze PDC system performance. You may alter the measuring parameters for your specific measurement and analysis.

Other Sources of Measurement Information

Additional measurement application information is available through your local Agilent sales and service office. The following application notes explain digital communications measurements in much greater detail than discussed in this guide.

- Digital Modulation in Communications Systems - An Introduction
Application Note 1298
Part number 5965-7160E
- Understanding PDC and NADC Transmitter Measurements for Base Transceiver Stations and Mobile Stations
Application Note 1324
Part number 5968-5537E

Instrument Updates at www.agilent.com

These web locations can be used to access the latest information about the instrument, including the latest firmware version.

www.agilent.com/find/vsa

www.agilent.com/find/psa

6 Setting Up the PDC Mode

PDC Mode

You may want to install a new personality, reinstall a personality that you have previously uninstalled, or uninstall a personality option. Instructions can be found in [“Installing Optional Measurement Personalities” on page 235](#).

To access the PDC measurement personality press the **Mode** key and select **PDC**.

If you want to set the PDC mode to a known, factory default state, press **Preset**. This will preset the mode setup and all of the PDC measurements to the factory default parameters.

NOTE

Note that pressing the **Preset** key does not switch instrument modes if the Mode type of preset is selected under **System, Power On/Preset**.

Mode settings are persistent. When you switch from one mode to another mode, the settings you originally chose for the modes will remain active until you change them. This allows you to switch back and forth between modes without having to reset settings each time. Presetting the instrument or powering the instrument off and on will return all mode settings to their default values.

Making a Measurement

This instrument enables you to make a wide variety of measurements on digital communications equipment using the Spectrum Analysis Mode measurement capabilities. It also has optional measurement personalities that make measurements based on established industry standards.

To set up the instrument to make measurements, you need to:

1. Select a **Mode** or personality which corresponds to a digital communications format, like cdma2000, W-CDMA, or GSM w/EDGE. Or use the Basic mode to make measurements on signals with non-standard formats. After selecting the mode, make any required adjustments to the mode settings.
2. Press **Measure** to select a specific measurement to be performed, like ACP, Channel Power, or EVM, etc. After selection of a measurement, make any required adjustments to the measurement settings.

Depending on the current settings of **Meas Control**, the instrument will begin making the selected measurement. The resulting data will be shown on the display or available for export.

3. Select a front panel **View** to display the data from the current measurement. Depending on the mode and measurement selected, various graphical and tabular presentations are available.

If you have a problem, and get an error message, see the “If You Have a Problem” section in each measurement description.

The main keys used in the three steps are shown in the table below.

Step	Primary Key	Setup Keys	Related Keys
1. Select & setup a mode	MODE	Mode Setup, Input, FREQUENCY/ Channel	System
2. Select & setup a measurement	MEASURE	Meas Setup	Meas Control, Restart
3. Select & setup a view	View/TraceTrace/View	SPAN X Scale, AMPLITUDE Y Scale, Display, Zoom, Next Window	File, Save, Print, Print Setup, Marker, PeakSearch

A setting may be reset at any time, and will be in effect on the next measurement cycle or View.

Changing the Mode Setup

Numerous settings can be changed at the mode level by pressing the **Mode Setup** key. This will access the menu with the selections listed below. These settings affect only the measurements in the PDC mode.

Radio

The **Radio** key accesses the menu as follows:

- **Traffic Rate** - Allows you to toggle the traffic rate between **Full** and **Half**.
- **Device** - Allows you to toggle the test device between **BS** (Base Station) and **MS** (Mobile Station).

Radio Default Settings	
Traffic Rate	Full
Device	BS

Input

The **Input** key accesses the menu as follows: (You can also access this menu from the front-panel **Input** key.)

- **RF Input Range** - Allows you to toggle the RF input range between **Auto** and **Man** (manual). **Auto** is not used for Spectrum measurements. If **Auto** is chosen, the instrument automatically sets the attenuator based on the carrier power level, where it is tuned. Once you change the **Max Total Pwr** or **Input Atten** value with the **RPG** knob, for example, the **RF Input Range** key is automatically set to **Man**. If there are multiple carriers present, the total power might overdrive the front end amplifiers. In this case you need to set the **RF Input Range** to **Man** and enter the expected maximum total power by activating the **Max Total Pwr** key. **Man** is also useful to hold the input attenuation constant for the best relative power accuracy. For single carriers it is generally recommended to set this to **Auto**.

- **Max Total Pwr** - Allows you to set the maximum total power from the UUT (Unit Under Test). The range is -200.00 to $+50.00$ dBm with 0.01 dB resolution. This is the expected maximum value of the mean carrier power referenced to the output of the UUT; it may include multiple carriers. The **Max Total Pwr** setting is coupled together with the **Input Atten** and **Ext Atten** settings. Once you change the **Max Total Pwr** value with the **RPG** knob, for example, the **RF Input Range** key is automatically set to **Man**.
- **Input Atten** - Allows you to control the input attenuator setting. The range is 0 to 40 dB with 1 dB resolution. The **Input Atten** key reads out the actual hardware value that is used for the current measurement. If more than one input attenuator value is used in a single measurement, the value used at the carrier frequency will be displayed. The **Input Atten** setting is coupled together with the **Max Total Pwr** setting. Once you change the **Input Atten** value with the **RPG** knob, for example, the **RF Input Range** key is automatically set to **Man**.
- **Ext Atten** - Allows you to enter the external attenuation value for either BS or MS. The range is -50.00 to $+50.00$ dB with 0.01 dB resolution. This will allow the instrument to display the measurement results referred to the output of the UUT.

NOTE

The **Max Total Pwr** and **Input Atten** settings are coupled together, so changing the input **Max Total Pwr** setting by x dB changes the **Input Atten** setting by x dB. When you switch to a different measurement, the **Max Total Pwr** setting is kept constant, but the **Input Atten** may change if the two measurements have different mixer margins. Therefore, you can set the input attenuator manually, or you can set it indirectly by specifying the expected maximum power from the UUT.

Input Default Settings	
RF Input Range	Auto ^a
Max Total Power	-15.00 dBm ^b
Input Atten	0.00 dB ^b
Ext Atten MS	0.00 dB
Ext Atten BS	0.00 dB

a. **Auto** is not used for Spectrum measurements.

b. This may differ if the maximum input power is more than -15.00 dBm.

Trigger

The **Trigger** key allows you: (1) to access the **RF Burst (Wideband)**, **Video (IF Envlp)**, **Ext Front** and **Ext Rear** trigger source selection menu to specify the triggering conditions for each trigger source, (2) to modify the default trigger holdoff time using the **Trig Holdoff** key, (3) to modify the auto trigger time and to activate or deactivate the **Auto Trigger** feature using the **Auto Trig** key, and (4) to modify the period of the frame timer using the **Frame Timer** key.

NOTE

The actual trigger source is selected separately for each measurement under the **Meas Setup** key

- **RF Burst (Wideband)**, **Video (IF Envlp)**, **Ext Front** and **Ext Rear** - Pressing one of these trigger keys will access each triggering condition setup menu. This menu is used to specify the **Delay**, **Level** and **Slope** settings for each trigger source as follows:

Delay - Allows you to enter numerical values to modify the delay time. The range is -500.000 to $+500.000$ ms with 1 ns resolution. For trigger delay use a positive value, and for pre-trigger use a negative value.

Level - Allows you to enter a numerical value to adjust the trigger level depending on the trigger source selected.

- For **RF Burst** selection, the RF level range is -200.00 to 0.00 dB with 0.01 dB resolution, relative to the peak RF signal level. The realistic range can be down to -20 dB.
- For **Video** selection, the video level range is -200.00 to $+50.00$ dBm with 0.01 dB resolution at the RF input. The realistic range can be down to around -40 dBm, depending on the noise level of the signal.
- For **Ext Front** or **Ext Rear** selection, the level range is -5.00 to $+5.00$ V with 1 mV resolution.

Slope Pos Neg - Allows you to toggle the trigger slope between **Pos** at the positive-going edge and **Neg** at the negative-going edge of the burst signal.

Other keys accessed under the **Trigger** key:

- **Trig Holdoff** - Allows you to set the period of time before the next trigger can occur. The range is 0.000 to 500.0 ms with 1 μ s resolution.
- **Auto Trig** - Allows you to specify a time for a trigger timeout. The range is 0.000 to 1000 sec with 1 μ s resolution. If no trigger occurs by the specified time, a trigger is automatically generated.

- **Frame Timer** - Allows you to access the **Frame Timer** menu to manually control the frame timer:

Period - Allows you to set the period of the frame clock. The range is 1.000 to 559.0 ms. Finest resolution is 1 ns. When **Traffic Rate** is **Full**, the default is 20.0 ms. When **Traffic Rate** is **Half**, the default is 40.0 ms.

Trigger Default Settings	
RF Burst:	
Delay	0.000 sec
Peak Level	-10.0 dB
Slope	Pos
Video:	
Delay	0.000 s
Level	-30.00 dBm
Slope	Pos
Ext Front & Ext Rear:	
Delay	0.000 s
Level	2.00 V
Slope	Pos
Trig Holdoff	10.00 ms
Auto Trig	100.0 ms, On
Frame Timer Period	20.00000 ms when Traffic Rate is Full 40.00000 ms when Traffic Rate is Half

Burst

The **Burst** key allows you to access the following menu to set the trigger condition for the ACP and EVM measurements.

- **Delay** - Allows you to set the delay time after searching a threshold level of PDC bursts. The range is -500.0 to $+500.0$ ms with 1 ns resolution.
- **Search Threshold** - Allows you to set the threshold level used in search for PDC bursts after data is acquired. The range is -200.00 to -0.01 dB with 0.01 dB resolution. The realistic lower range can be down to the noise floor level of the signal.

Burst Default Settings	
Delay	0.000 s
Search Threshold	-30.00 dB

Changing the Frequency Channel

After selecting the desired mode setup, you will need to select the desired center frequency, burst type, and slot. The selections made here will apply to all measurements in the mode. Press the **Frequency Channel** key to access the following menu:

- **Center Freq** - Enter a frequency value that corresponds to the desired RF channel to be measured. This is the current instrument center frequency for any measurement function.
- **Burst Type** - Choose a PDC burst type from the following selections only when **Device** under **Radio** is previously set to **MS**, otherwise this softkey is unavailable:

Traffic (TCH) - Sets to the traffic channel burst signal of which burst length is 270 bits or 135 symbols.

Control (CCH) - Sets to the control channel burst signal of which burst length is 258 bits or 129 symbols.

- **Slot (Std)** - Allows you to toggle the slot selection function between **Auto** and **Man**, and also to specify the particular timeslot to be measured when **Man** is selected. This is used only when making EVM measurements.

Auto - In auto, the measurement is made on the first timeslot found to have any one of the valid sync words in the range of 0 to 5. The measurement may be made on various timeslots if more than one timeslot has the valid sync word.

Man - In manual, the measurement is made on the first burst found to have the selected sync word in the range of 0 to 5. The measurement will be made only on the specified timeslot.

When the PDC mode is selected, the instrument will default to the following settings:

Frequency Channel Default Settings	
Center Frequency	1.00000 GHz
Burst Type ^a	Traffic (TCH)
Slot (Std)	0, Auto

a. This is valid only when Device is MS.

PDC Measurement Key Flow

The key flow diagrams, shown in a hierarchical manner on the following pages, will help the user to grasp the overall functional relationships for the front-panel keys and the softkeys displayed at the extreme right side of the screen. The diagrams are:

Figure 6-1, “Mode Setup / Frequency Channel Key Flow,” on page 225.

Figure 6-2, “ACP Measurement Key Flow,” on page 226.

Figure 6-3, “EVM Measurement Key Flow,” on page 227.

Figure 6-4, “Occupied Bandwidth Measurement Key Flow,” on page 228.

Figure 6-5, “Spectrum Measurement Key Flow (1 of 3),” on page 229.

Figure 6-6, “Spectrum Measurement Key Flow (2 of 3),” on page 230.

Figure 6-7, “Spectrum Measurement Key Flow (3 of 3),” on page 231.

Figure 6-8, “Waveform Measurement Key Flow (1 of 2),” on page 232.

Figure 6-9, “Waveform Measurement Key Flow (2 of 2),” on page 233.

Use these flow diagrams as follows:

1. There are some basic conventions:

An oval represents one of the front-panel keys.

This box represents one of the softkeys displayed.

Default conditions are shown as much as possible (underlined>).

2. Start from the extreme upper left corner of each measurement diagram to the right direction.

3. Proceed from the top to the bottom.

4. When defining a key from auto to manual, for example, just press that key one time.

5. When entering a numeric value of **Frequency**, for example, use the numeric keypad by terminating with the appropriate unit selection from the keys displayed.

6. When entering a numeric value of **Slot**, for example, use the numeric keypad by terminating with the **Enter** front-panel key.

7. Instead of using the numeric keypad to enter a, it may be easier to use the **RPG** knob or **Up/Down** keys depending on the input field of a parameter.




Figure 6-1 Mode Setup / Frequency Channel Key Flow




Figure 6-2 ACP Measurement Key Flow





Figure 6-3 EVM Measurement Key Flow



Setting Up the PDC Mode
PDC Measurement Key Flow

Figure 6-4 Occupied Bandwidth Measurement Key Flow





Figure 6-5 Spectrum Measurement Key Flow (1 of 3)



Setting Up the PDC Mode
PDC Measurement Key Flow

Figure 6-6 Spectrum Measurement Key Flow (2 of 3)





Figure 6-7 Spectrum Measurement Key Flow (3 of 3)



Setting Up the PDC Mode
PDC Measurement Key Flow

Figure 6-8 Waveform Measurement Key Flow (1 of 2)





Figure 6-9 Waveform Measurement Key Flow (2 of 2)



Using Basic Mode

Basic mode is not related to a particular communications standard. That is, it does not default to measurement settings that are for any specific standard. You may want to use Basic Mode if you are making measurements on a signal that is not part of a specific digital communications standard.

There are two measurements available under the **Measure** key in Basic mode:

- Spectrum measurement (frequency domain).
- Waveform measurement (time domain)

These measurements provide a measurement mode that is similar to a standard spectrum analyzer. Unlike the standard analyzer, these measurements are optimized for measuring digitally modulated signals, so they can be used to output the measured I/Q data.

The Spectrum and Waveform measurements are also available in this mode, with the same functionality, so you can refer to this manual for information about using them.

Installing Optional Measurement Personalities

When you **install** a measurement personality, you follow a two step process.

1. Install the measurement personality firmware into the instrument memory. See “[Loading an Optional Measurement Personality](#)” on page 236.
2. Enter a license key number that activates the measurement personality. See “[Installing a License Key](#)” on page 237.

Adding additional measurement personalities requires purchasing a retrofit kit for the desired option. The retrofit kit contains the measurement personality firmware and a license key certificate. It documents the license key number that is for your specific option and instrument serial number.

Available Measurement Personality Options

Available Personality Options ^a	Option
Digital Demod Hardware (with Basic Mode)	B7J
GSM (with EDGE) measurement personality	202
cdmaOne measurement personality	BAC
NADC, PDC measurement personalities	BAE
W-CDMA measurement personality	BAF
cdma2000 measurement personality	B78
Phase noise measurement personality	226

a. Available as of the print date of this guide.

You need two pieces of information about your instrument to order a retrofit kit adding an option. You need the Host ID, and the instrument serial number.

Required Information:	Key Path:
Host ID: _____	System, Show System
Instrument Serial Number: _____	System, Show System

NOTE The instrument must have Option B7J in order to add most of the measurement personality options. (Basic, cdmaOne, cdma2000, W-CDMA, GSM, NADC, PDC.)

Loading an Optional Measurement Personality

You must load the desired option into your instrument memory. Loading can be done from a CD-ROM or a www location. The automated loading program runs from your PC and comes with the firmware.

NOTE When you add a new option, or update an existing option, you will get the updated version of all your current options since they are reloaded simultaneously. This process may also require you to update the instrument core firmware so that it is compatible with the new option.

You may not be able to fit all of the available measurement personalities in instrument memory at the same time. The approximate memory requirements for the options are listed below. These numbers are worst case examples. Many options share components/libraries so the total memory usage of multiple options may not be exactly equal to the combined total.

Available Personality Options	Approximate File Size (PSA - A.02.06)
GSM (with EDGE) measurement personality	3.3 MB
cdmaOne measurement personality	2.0 MB
NADC measurement personalities	1.3 MB
PDC measurement personalities	1.4 MB
W-CDMA measurement personality	4.2 MB ^a
cdma2000 measurement personality	3.8 MB ^a
Phase noise measurement personality	2.6 MB
“Shared measurement library” (see footnote)	1.5 MB

a. This application uses the “shared measurement library”, so you have to add its memory requirements to this value.

You can install an updated version of firmware and your licensed options using a LAN connection and your PC. Instructions for loading future firmware updates are available at the following URL:
www.agilent.com/find/psa/

Installing a License Key

To install a license key number for the selected option, use the following procedure.

NOTE

You can also use this to reinstall a license key number that has been deleted during an uninstall process, or lost due to a memory failure

1. Press **System, More, More, Licensing, Option**. The **Option** key accesses the alpha editor menu. Use the alpha editor to enter letters (upper-case) and the front-panel numeric keys to enter numbers for the option designation. Then press the **Enter** key. As you enter the option, you will see your entry in the active function area of the display.
2. Press **License Key**. Enter the letters/digits of your license key. You will see your entry in the active function area of the display. When you have completed entering the license key number, press the **Enter** key.
3. Press the **Activate License** key.

Viewing a License Key

Measurement personalities purchased with your instrument have been installed and activated at the factory. You will receive a unique **License Key** number with every measurement personality purchased. The license key number is a hexadecimal number that is for your specific measurement personality, instrument serial number and host ID. It enables you to install, or reactivate that particular personality.

Follow these steps to display the unique license key for a measurement personality that is already installed in your instrument:

1. Press **System, More, More, Licensing, Show License**. The **System, Personalities** key shows you if the option has been activated.

You will want to keep a copy of your license key number in a secure location. Please enter your license key numbers below for future reference. If you should lose your license key number, call your nearest Agilent Technologies service or sales office for assistance.

License Key Numbers for Instrument with Serial # _____	
For Option _____	the license key number is _____
For Option _____	the license key number is _____
For Option _____	the license key number is _____
For Option _____	the license key number is _____
For Option _____	the license key number is _____

License Key Numbers for Instrument with Serial # _____

For Option _____ the license key number is _____
--

Using the Delete License Key

The following procedure removes the license key number for the selected option. This will make the option unavailable for use. Please write down the 12-digit license key number for the option before proceeding. If you want to use that measurement personality at a later date you will need the license key number to reactivate the personality firmware.

NOTE

Using the **Delete License** key does not remove the personality from the instrument memory, and does not free memory to be available to install another option. If you need to free memory to install another option, refer to the instructions for loading firmware updates located at the URL: www.agilent.com/find/psa/

1. Press **System, More, More, Licensing, Option**. Pressing the **Option** key will activate the alpha editor menu. Use the alpha editor to enter the letters (upper-case) and the front-panel numeric keyboard to enter the digits (if required) for the option, then press the **Enter** key. As you enter the option, you will see your entry in the active function area of the display.
2. Press **Delete License** to remove the license key from memory.

7

Making PDC Measurements

PDC Measurements

Once in the PDC mode the following measurements for the PDC band are available by pressing the **Measure** key.

- “Making the Adjacent Channel Power Measurement” on page 247.
- “Making the Error Vector Magnitude (EVM) Measurement” on page 254.
- “Making the Occupied Bandwidth Measurement” on page 261.
- “Making the Spectrum (Frequency Domain) Measurement” on page 265.
- “Making the Waveform (Time Domain) Measurement” on page 274.

These are referred to as one-button measurements. When you press the key to select a measurement it will become the active measurement, using settings and a display unique to that measurement. Data acquisitions will automatically begin when trigger requirements, if any, are met.

Preparing for Measurements

If you want to set the PDC mode to a known, factory default state, press **Preset**. This will preset the mode setup and all of the measurements to the factory default parameters.

NOTE Pressing the **Preset** key does not switch instrument modes.

To preset only the settings that are specific to the selected measurement, press **Meas Setup, More, Restore Meas Defaults**. This will reset the measure setup parameters, for the currently selected measurement only, to the factory defaults.

Initial Setup

Before making a measurement, make sure the mode setup and frequency channel parameters are set to the desired settings. Refer to the sections “[Changing the Mode Setup](#)” and “[Changing the Frequency Channel](#)” in the previous chapter.

How to Make a Measurement

Follow the three-step process shown in the table below:

Measure

The **Measure** front-panel key accesses the menu to select one of the following measurements:

- **ACP** - Press this key to make adjacent channel power measurements. The following menu is activated by the **View/Trace** front-panel key:
 - Bar Graph** - Displays the ACP bar graph with ± 21.0 kHz power bandwidths centered at ± 50 and ± 100 kHz offsets from the center frequency of the carrier signal. The summary data is also available in the text window.
 - Spectrum** - Displays the ACP spectrum graph (with ± 21.0 kHz bandwidth marker lines) at ± 50 and ± 100 kHz offsets from the center frequency of the carrier signal. The summary data is also available in the text window.
- **EVM** - Press this key to make error vector magnitude measurements. The following keys are activated by the **View/Trace** front-panel key:
 - I/Q Measured Polar Vector** - Displays the EVM polar vector graph of the I/Q demodulated signal. The summary data is also available in the text window.

I/Q Measured Polar ConstIn - Displays the EVM polar constellation graph of the I/Q demodulated signal. The summary data is also available in the text window.

I/Q Error (Quad-View) - Displays four windows for the EVM, **Magnitude Error** and **Phase Error** graphs and the EVM summary data. By selecting one of the windows with the **Next Window** front-panel key, you can enlarge it by pressing the **Zoom** key.

- **Occupied BW** - Press this key to make occupied bandwidth measurements with the occupied bandwidth graph window and summary data window. Two vertical lines mark the $\pm 0.5\%$ power points on the display. The **View/Trace**, **Span X Scale**, and **Marker** menus are not available for this measurement, but the **Amplitude Y Scale** menu is available.
- **Spectrum (Freq Domain)** - Press this key to make spectrum measurements with the spectrum and I/Q waveform display windows. The following menu is activated by the **View/Trace** front-panel key:

Spectrum - Switches the display window from the **I/Q Waveform** window. This is equivalent to the **Next Window** front-panel key.

I/Q Waveform - Switches the display window from the **Spectrum** window. This is equivalent to the **Next Window** front-panel key.

Trace Display - Allows you to control the traces displayed for the current measurement data and/or the averaged data as follows:

All - Displays both current and average traces if the **Average** function is already activated.

Average (or Max & Min) - Displays only the average trace if it is already activated.

Current - Displays only the current data trace.

- **Waveform (Time Domain)** - Press this key to make time-domain waveform measurements with either display of the **RF Envelope** graph and summary data windows or the **I/Q Waveform** window. The following menu is activated by the **View/Trace** front-panel key:

RF Envelope - Changes to display the RF envelope graph window and the summary data window. This is the default selection for waveform (time domain) measurements.

I/Q Waveform - Changes to display the I/Q waveform graph window.

Measure Control

The **Meas Control** front-panel key accesses the menu to control processes that affect on running the current measurement.

- **Restart** - Press this **Restart** key to repeat the current measurement from the beginning, while retaining the current measurement settings. This is equivalent to the **Restart** front-panel key.
- **Measure** - Press **Meas Control**, **Measure** (not to be confused with the front-panel **Measure** key which has a different function) to toggle the measurement state between **Single** and **Cont** (Continuous). When set to single, the measurement will continue until it has reached the specified number of averages set by the average counter. When set to continuous, the measurement will run continuously and execute averaging according to the current average type, either repeat or exponential. The default setting is **Cont**.
- **Pause** - Press **Meas Control**, **Pause** to pause the current measurement until you reactivate the measurement. Once toggled, the label of the **Pause** key changes to read **Resume**. The **Resume** key, once pressed, continues the active measurement from the point at which it was paused.

Measurement Setup

The **Meas Setup** key accesses the features that enable you to adjust parameters of the current measurement, such as resolution bandwidth. You will also use the **Meas Setup** menu to access the **Avg Number**, **Avg Mode**, and **Trig Source** keys.

The following measure setup feature can be used with many or all measurements.

- **Restore Meas Defaults** - Allows you to preset only the settings that are specific to the selected measurement by pressing **Meas Setup**, **More (1 of 2)**, **Restore Meas Defaults**. This will set the measure setup parameters, for the currently selected measurement only, to the factory defaults.

Averaging

Selecting one of the averaging keys in the **Meas Setup** menu will allow you to modify the average number and averaging mode you use for the currently selected measurement. For spectrum (frequency domain) and waveform (time domain) measurements, the **Average** key activates the following menu:

- **Avg Number** - Allows you to change the number of N averages to be made.

- **Avg Mode Exp Repeat** - Allows you to choose either exponential or repeat averaging mode. This selection only effects the averaging result after the number of N averages is reached. The N is set using the **Avg Number** key.

Normal averaging: Normal (linear) averaging is always used until the specified number of N averages is reached. When the **Measure** key under **Meas Control** is set to **Single**, data acquisition is stopped when the number of N averages is reached, thus **Avg Mode** has no effect in **Single** measurement mode.

Exponential averaging: When **Measure** is set to **Cont**, data acquisition will continue indefinitely. Exponential averaging is used with a weighting factor of N (the displayed count of averages stops at N). Exponential averaging weights new data more heavily than old data, which allows tracking of slow-changing signals. The weighting factor N is set using the **Avg Number** key.

Repeat averaging: When **Measure** is set to **Cont**, data acquisition will continue indefinitely. After the number of N averages is reached, all previous result data is cleared and the displayed count of averages is set back to 1. This is equivalent to being in **Measure Single** and pressing the **Restart** key each time the single measurement finishes.

- **Avg Type** - Allows you to access the following menu only for making spectrum (frequency domain) and waveform (time domain) measurements:

Pwr Avg (RMS) - Executes the true power averaging which is equivalent to taking the rms of the voltage. This is the most accurate type.

Log-Pwr Avg (Video) - Simulates the traditional spectrum analyzer type of averaging by calculating the log of the power.

Voltage Avg - Executes the voltage averaging.

Maximum - Executes the maximum voltage averaging by capturing peak data.

Minimum - Executes the minimum voltage averaging.

Trigger Source

Changing the selection in the **Trig Source** menu alters the trigger source for the selected measurement only. Not all of the selections are available for all measurements. Choose one of the following trigger sources:

NOTE

The **RF Burst (Wideband)**, **Video (IF Envlp)**, **Ext Front** and **Ext Rear** keys found under the **Trigger** menu enable you to change the default settings of the delay, level and slope for each of these trigger sources.

- **Free Run (Immediate)** - A trigger occurs at the time the data is requested, completely asynchronous with the RF or IF signal.
- **RF Burst (Wideband)** - An internal wideband RF burst trigger that has the automatic level control for burst signals. It triggers at the level that is set relative to the peak RF signal (12 MHz bandwidth) input level.
- **Video (IF Envlp)** - An internal IF envelope trigger that occurs at the absolute threshold level of the IF signal level. This source is not available for ACP measurements.
- **Ext Front** - Activates the front-panel external trigger input (**EXT TRIGGER INPUT**) port. The external signal must be between -5.00 and $+5.00$ V with 1 mV resolution.
- **Ext Rear** - Activates the rear panel external trigger input (**TRIGGER IN**) port. The external signal must be between -5.00 and $+5.00$ V with 1 mV resolution.
- **Frame** - Uses the internal frame clock to generate a trigger signal. The clock parameters are controlled under the **Mode Setup** key or the measurement firmware, but not both. See the specific measurement for details. This trigger source is not available for occupied bandwidth measurements.
- **Line** - Sets the trigger to the line mode. Sweep triggers occur at intervals synchronous to the line frequency. This trigger source is available for spectrum and waveform measurements.

The rear panel **TRIGGER 1 OUT** and **TRIGGER 2 OUT** connectors are coupled to the selected trigger source. These trigger outputs are always on at the rising edge with a pulse width of at least 1 μ s.

Burst Sync

This menu is only used for EVM measurements. Pressing the **Burst Sync** key allows you to choose the source used to synchronize the measurement to the “point 0” of the PDC burst. The “point 0” is defined as the start of symbol 0 in timeslot 0. The **Search Threshold** setting in the **Burst** menu under **Mode Setup** applies to the **RF Amptd**. Pressing the **Burst Sync** key will bring up a menu with some or all of the following choices:

- **Sync Word** - Synchronizes the measurement to the sync word which is one of the six possible 20-bit PDC timeslot synchronization words contained in the signal. This is the default when **Device** is set to **MS**.
- **RF Amptd** - Synchronizes the measurement to the burst transition of the measured RF carrier.
- **None** - Measurements are made without synchronizing with the PDC burst. This is the default when **Device** is set to **BS**.

Making the Adjacent Channel Power Measurement

Purpose

To maintain a quality call by avoiding channel interference, it is quite important to measure and reduce an adjacent channel power (ACP) transmitted from a PDC mobile phone. The characteristics of adjacent channel power are mainly determined by the transmitter design, including a digital filter called a root Nyquist filter.

Adjacent channel power is defined by the PDC standard as the total power within the defined bandwidth, centered at Δf kHz offset from the carrier frequency. The carrier is modulated by the standard coding test signal which has the same coding speed as the PDC modulation signal. The following specifications from the RCR STD-27 standards apply to both base stations and mobile stations:

- (1) At ± 50 kHz offset: Less than -45 dB
- (2) At ± 100 kHz offset: Less than -60 dB

Measurement Method

This measurement analyzes the total power levels within the defined bandwidth of 21.0 kHz at given offset frequencies on both sides of the carrier frequency using Fast Fourier Transform (FFT).

The measurement functions, such as averaging, trigger source, limit test, offsets and limits, need to be setup for a measurement and pass/fail test. The test result is displayed in either bar graph window or spectrum window. Both the absolute power levels and the power levels relative to the center power band are displayed in the text window. When **Spectrum View** is selected, the vertical scale can be varied for your optimum observation by pressing the **Amplitude Y Scale** front-panel key.

Making the Measurement

NOTE The factory default parameters provided for this measurement will give you a PDC compliant measurement for the instrument setup. You should be able to make a measurement often using these defaults.

Select the desired center frequency as described in [“Changing the Frequency Channel”](#) on page 222.

Press **Measure, ACP** to immediately make an adjacent channel power measurement.


To change any of the measurement parameters from the factory default values, refer to [“Changing the Measurement Setup”](#) on page 249 for this measurement.

Results

The next figure shows an example result of adjacent channel power measurements in the bar graph window. The power levels on both sides of the carrier frequency are displayed in the graph window and text window.

Figure 7-1

Adjacent Channel Power Measurement - Bar Graph View



Changing the Measurement Setup

The next table shows the factory default settings for adjacent channel power measurements.

Table 7-1 Adjacent Channel Power Measurement Defaults

Measurement Parameter	Factory Default Condition
View/Trace	Bar Graph
Meas Setup:	
Avg Number	10, On
Avg Mode	Repeat
Trig Source: (when Device is MS) (when Device is BS)	RF Burst (Immediate) Free Run (Wideband)
Limit Test	On
Offs & Limits:	
Offset	A
Offset Freq:	
A	50.000 kHz, On
B	100.000 kHz, On
C, D, E	0.0 Hz, Off
Abs Limit:	
A, B, C, D, E	0.00 dBm
Fail:	
A, B	Relative
C	OR
D, E	AND
Rel Limit (Car):	
A	-45.00 dB
B	-60.00 dB
C, D, E	0.00 dB

Make sure the **ACP** measurement is selected under the **Measure** menu. The **Meas Setup** key accesses the menu which allows you to modify the average number, average mode and trigger source for this measurement as described in “**Measurement Setup**” on page 243. However, the trigger source does not include **Video** and **Line**. In addition, the following parameters for adjacent channel power measurements can be modified:

- **Limit Test** - Allows you to toggle the limit test function between **On** and **Off**. If set to **On**, **Abs Limit** and/or **Rel Lim (Car)** need to be specified to execute pass/fail tests with the logical judgement under the **Fail** key. Pass/fail results are shown in the active display window with the number of averages. In the text window, a red character F is shown on the right side of each measurement result, either relative or absolute, if it exceeds the limits with its logical judgement.
- **Ofs & Limits** - Allows you to access the menu to change the following parameters for pass/fail tests:

Offset - Allows you to access the memory selection menu to store 5 offset frequency values in **A** through **E**. Only one selection at a time (**A**, **B**, **C**, **D**, or **E**) is shown on this key label. The default selection is **A**.

Offset Freq - Allows you to enter an offset frequency value and toggle the offset frequency function between **On** and **Off**, according to each offset key selected. The allowable range is 0 Hz to 200.000 kHz. While this key is activated, enter an offset value from the numeric keypad by terminating with one of the frequency unit keys shown. For PDC measurements offsets **A** and **B** are defaulted to 50.000 kHz **On** and 100.000 kHz **On**, respectively, while offsets **C**, **D** and **E** are defaulted to 0.0 Hz **Off**. One offset frequency value selected from the **Offset** menu is shown on this key label. The default state shows 50.000 kHz **On**.

Abs Limit - Allows you to enter an absolute limit value ranging from -200.00 to +50.00 dBm with the best resolution of 0.01 dB. The default settings for all offsets are 0.00 dBm.

Fail - Allows you to access the following menu to select one of the logic keys for fail conditions between the measurement results and the test limits:

AND - Fail is shown if one of the relative ACP measurement results is larger than **Rel Lim (Car)** AND one of the absolute ACP measurement results is larger than **Abs Limit**. This is the default setting for offsets **D** and **E**.

OR - Fail is shown if one of the relative ACP measurement results is larger than **Rel Lim (Car)** OR one of the absolute ACP measurement results is larger than **Abs Limit**. This is the default setting for offset **C**.

Absolute - Fail is shown if one of the absolute ACP measurement results is larger than **Abs Limit**.

Relative - Fail is shown if one of the relative ACP measurement results is larger than **Rel Lim (Car)**. This is the default setting for offsets A and B.

Rel Lim (Car) - Allows you to enter a relative limit value ranging from -200.00 to $+50.00$ dB with the best resolution of 0.01 dB. The default settings for offsets A and B are -45.00 and -60.00 dB, respectively, while offsets C, D and E are defaulted to 0.00 dB.


Changing the View

The **View/Trace** key accesses the menu which allows you to select the desired measurement view from the following selections:

- **Bar Graph** - In the factory default condition, 5 of the total integration power levels within 21.0 kHz bandwidth, centered at the carrier frequency and ± 50 kHz and ± 100 kHz offset frequencies, are shown in the bar graph window. The corresponding measured data is shown in the text window as shown in [Figure 7-1 on page 248](#).
- **Spectrum** - Once this view is selected, [Figure 7-1 on page 248](#) changes as shown below. In the factory default condition, the swept frequency spectrum is displayed with the bandwidth marker lines in the spectrum graph window. The corresponding measured data in the text window is the total integration power within the defined bandwidth of 21.0 kHz. While in this view, you can change the vertical scale by pressing the **Amplitude Y Scale** key.

Figure 7-2

Adjacent Channel Power Measurement - Spectrum View



Troubleshooting Hints

The adjacent channel power measurements suggest us numerous faults in the transmitter section of the UUT, as follows:

- (1) Faults caused by a malfunction of the baseband circuitry consisting of a code generator, a digital filter, digital-to-analog converters, 90-degree phase shifter, and I/Q modulators.
- (2) Faults due to high phase noise levels from the local oscillators.
- (3) Faults due to excessive noise floor levels from the up-converter, output amplifier, and/or analog filters.

Making the Error Vector Magnitude (EVM) Measurement

Purpose

Phase and frequency errors are the measures of modulation quality for the PDC system. Since the PDC system uses the $\pi/4$ DQPSK modulation technique, the phase and frequency accuracies of the PDC transmitter are critical to the communications system performance and ultimately affect range.

PDC receivers rely on the phase and frequency quality of the $\pi/4$ DQPSK modulation signal in order to achieve the expected carrier to noise ratio. A transmitter with high phase and frequency errors will often still be able to support phone calls during a functional test. However, it will tend to provide difficulty for mobiles trying to maintain service at the edge of the cell with low signal levels or under difficult fading and Doppler conditions.

Measurement Method

The phase error of the unit under test is measured by computing the difference between the phase of the transmitted signal and the phase of a theoretically perfect signal.

The instrument samples the transmitter output in order to capture the actual phase trajectory. This is then demodulated and the ideal phase trajectory is mathematically derived. Subtracting one from the other results in an error signal.

For base stations, the PDC standard specifies that the phase error should not exceed 5 degrees rms or 20 degrees peak, and that the mean frequency error across the burst must not exceed 0.05 ppm. These specifications hold true for normal and extreme temperature conditions, and with exposure to vibration.

This measurement allows you to display these errors numerically and graphically on the instrument display. There are graphs for EVM, Phase Error and Mag Error in the graph windows. In the text window, there are Evm: in % rms, in % peak at the highest symbol number, Mag Error: in % rms, Phase Error: in degrees, Freq Error: in Hz, and I/Q Offset: in dB.

Making the Measurement

NOTE

The factory default settings provide a PDC compliant measurement. For special requirements, you may need to change some of the settings. Press **Meas Setup, More (1 of 2), Restore Meas Defaults** at any time to return all parameters for the current measurement to their default settings.

Select the desired center frequency, burst type, and slot as described in [“Changing the Frequency Channel” on page 222](#).

Press **Measure, EVM** to immediately make the error vector magnitude measurement.


To change any of the measurement parameters from the factory default values, refer to [“Changing the Measurement Setup”](#) below, for this measurement.

Results

The next figure shows an example of measurement result with the graphic and text windows. The measured summary data is shown in the left window and the dynamic vector trajectory of the I/Q demodulated signal is shown as a polar vector display in the right window.

Figure 7-3

Error Vector Magnitude Measurement - Polar Vector View



Changing the Measurement Setup

The next table shows the factory default settings for error vector magnitude measurements.

Table 7-2 Error Vector Magnitude Measurement Defaults

Measurement Parameter	Factory Default Condition
Avg Number	10, On
Avg Mode	Exponential
Trigger Source	Free Run when Device is BS RF Burst when Device is MS
Burst Sync	None when Device is BS Sync Word when Device is MS
View/Trace	I/Q Measured Polar Vector
Limit Test	On
Limits: RMS EVM	12.5%
Limits: Peak EVM	40.0%
Limits: Origin Offset	-20 dB

Make sure the **Error Vector Magnitude (EVM)** measurement is selected under the **Measure** menu. The **Meas Setup** key accesses a menu which allows you to modify the averaging, trigger source and burst sync for this measurement as described in “[Measurement Setup](#)” earlier in this chapter. However, the trigger source does not include **Line**. In addition, the following error vector magnitude measurement parameters can be modified:

- **Limit Test** - Allows you to toggle between **On** and **Off**. If set to **On**, the **Limits** key needs to be pressed to specify the limit values for rms EVM, peak EVM and origin offset. Pass/fail results are shown in the active display window with the number of averages.
- **Limits** - Allows you to access the menu to change the following test parameter limits:

RMS EVM - Allows you to enter a limit value ranging from 0.0 to 50.0% for the pass/fail test of the rms error vector magnitude measured on all of the symbols. The default setting is 12.5%.

Peak EVM - Allows you to enter a limit value ranging from 0.0 to 50.0% for the pass/fail test of the peak error vector magnitude measured on all of the symbols. The default setting is 40.0%.


Origin Offset - Allows you to enter a limit value ranging from -100.00 to 0.00 dB for the pass/fail test of the origin offset. The default setting is -20.00 dB.

Changing the View

The **View/Trace** key accesses the menu which allows you to select the desired measurement view from the following selections:

- **I/Q Measured Polar Vector** - The measured summary data is shown in the left window and the dynamic vector trajectory of I/Q demodulated signal is shown as a polar vector display in the right window, as shown in [Figure 7-3 on page 255](#).
- **I/Q Measured Polar Constln** - The measured summary data is shown in the left window and the dynamic vector constellation of I/Q demodulated signal is shown as a polar vector display in the right window as shown in [Figure 7-4 on page 257](#).

Figure 7-4 Error Vector Magnitude Measurement - Polar Constln




Making PDC Measurements

Making the Error Vector Magnitude (EVM) Measurement

- **I/Q Error (Quad-View)** - Four display windows show EVM, Mag Error and Phase Error graphs, and the EVM summary data text.

Figure 7-5 Error Vector Magnitude Measurement - Quad View



Changing the Display

The **Display** key accesses the menu to allow the following selections for changing the graph displays:

- **Pts/Symb Displayed** - Allows you to specify the number of displayed points per symbol, either 1 or 5. The default setting is 5.
- **Symbol Dots** - Allows you to toggle the symbol dots between **On** and **Off**. The default setting is **On**.

When either **EVM**, **Phase Error** or **Mag Error** window is active in the **I/Q Error (Quad-View)** display, the **Span X Scale** key accesses the menu to allow the following selections:

- **Scale/Div** - Allows you to define the horizontal scale by changing the symbol value per division. The range is 1 to 100 symbols per division. The default setting is 13.7 (for BS) or 13.4 (for MS) symbols per division.
- **Ref Value** - Allows you to set the symbol reference value ranging from 0 to 1000 symbols. The default setting is 0.
- **Ref Position** - Allows you to set the reference position to either **Left**, **Ctr** (center) or **Right**. The default setting is **Left**.

- **Scale Coupling** - Allows you to toggle the scale coupling function between **On** and **Off**. The default setting is **On**. This function automatically determines the scale per division and reference value by the magnitude of the measurement results.

When either **EVM:** or **Mag Error:** window is active in the I/Q Error (Quad-View) display, the **Amplitude Y Scale** key accesses the menu to allow the following selections:

- **Scale/Div** - Allows you to define the vertical scale by changing the value per division. The range is 0.01 to 3600 degrees. The default setting is 20.0 degrees per division. However, since the **Scale Coupling** default is set to **On**, this value is automatically determined by the measurement results.
- **Ref Value** - Allows you to set the reference value ranging from 0 to 500%. The default setting is 0%.
- **Ref Position** - Allows you to set the reference position to either **Top**, **Ctr** (center) or **Bot** (bottom). For the **EVM:** graph the, default setting is **Bot**. For the **Mag Error:** graph the default setting is **Ctr**.
- **Scale Coupling** - Allows you to toggle the scale coupling function between **On** and **Off**. The default setting is **On**. This function automatically determines the scale per division and reference value by the magnitude of the measurement results.

When the **Phase Error:** window is active in the I/Q Error display, the **Amplitude Y Scale** key accesses the menu to allow the following selections:

- **Scale/Div** - Allows you to define the vertical scale by changing the value per division. The range is 0.01 to 3600 degrees. The default setting is 20.0 degrees per division. However, since the **Scale Coupling** default is set to **On**, this value is automatically determined by the measurement results.
- **Ref Value** - Allows you to set the reference value ranging from 0 to 500%. The default setting is 0%.
- **Ref Position** - Allows you to set the reference position to either **Top**, **Ctr** (center) or **Bot** (bottom). For the **EVM** graph, the default setting is **Bot**. For the **Mag Error** graph, the default setting is **Ctr**.
- **Scale Coupling** - Allows you to toggle the scale coupling function between **On** and **Off**. The default setting is **On**. This function automatically determines the scale per division and reference value by the magnitude of the measurement results.

Troubleshooting Hints

Use the spectrum (frequency domain) measurement to verify that the signal is present and approximately centered on the display.

Poor phase error indicates a problem at the I/Q baseband generator, filters, and/or modulator in the transmitter circuitry. The output amplifier in the transmitter can also create distortion that causes unacceptably high phase error. In a real system, poor phase error will reduce the ability of a receiver to correctly demodulate the signal, especially in marginal signal conditions.

Making the Occupied Bandwidth Measurement

Purpose

To utilize the limited resource of radio frequency bands to provide as many communication channels as possible, it is critical to measure and control the occupied bandwidth transmitted from a mobile phone. This occupied bandwidth is defined as the frequency bandwidth in which 99% of the total power is measured.

The occupied bandwidth of a mobile phone tends to be improved if its adjacent channel power is reduced. To provide as many channels as possible to meet the increasing number of subscribers, both of these characteristics of a mobile phone need to be measured and analyzed for further performance improvement.

Measurement Method

This measurement is made to analyze the frequency bandwidth in which 99% of the total power is measured, based on Fast Fourier Transform (FFT) theory.

In the actual measuring process, first the total channel power is measured using a sampling method. Then each power sample is integrated up to 0.5% of the total power from the lowest and highest frequency sides to determine the low and high limit frequencies. The difference derived from these frequencies is the occupied bandwidth.

The measurement functions, such as averaging, trigger source, limit test and limit, need to be setup to make a measurement and pass/fail test. The test results are displayed in the graphic window and in the text window.

Making the Measurement

NOTE

The factory default settings provide a PDC compliant measurement. For special requirements, you may need to change some of the settings. Press **Meas Setup, More (1 of 2), Restore Meas Defaults** at any time to return all parameters for the current measurement to their default settings.

Select the desired center frequency as described in [“Changing the Frequency Channel” on page 222](#).


Press **Measure, Occupied BW** to immediately make the occupied bandwidth measurement.

To change any of the measurement parameters from the factory default values, refer to “Changing the Measurement Setup” below, for this measurement.

Results

In the upper window, the spectrum is displayed with vertical lines marking the 0.5% power points. The actual measured data of the occupied bandwidth and the total channel power are shown in the lower window.

Figure 7-6 Occupied Bandwidth Measurement



Changing the Measurement Setup

The next table shows the factory default settings for occupied bandwidth measurements.

Table 7-3

Occupied Bandwidth Measurement Defaults

Measurement Parameter	Factory Default Condition
Log Scale	10.00 dB/div
Avg Number	10, On
Avg Mode	Exponential
Trigger Source	Free Run
Limit Test	On
Limit	32.000 kHz

Make sure the **Occupied Bandwidth** measurement is selected under the **Measure** menu. The **Meas Setup** key accesses the menu which allows you to modify the averaging and trigger source for this measurement as described in “**Measurement Setup**” earlier in this chapter. However, the trigger source does not include **Frame** and **Line**. In addition, the following occupied bandwidth measurement parameters can be modified:

- **Limit Test** - Allows you to toggle the limit test function between **On** and **Off**. Pass/fail results are shown in the active display window with the number of averages.
- **Limit** - Allows you to specify the frequency limit value ranging from 10.000 to 60.000 kHz with 0.1 kHz resolution. The default value is 32.000 kHz.

Changing the Display

The **Amplitude Y Scale** key accesses the menu to allow the following selections:

- **Scale/Div** - Allows you to change the vertical scale per division. The range is 0.10 to 20.00 dB per division with 0.01 dB resolution. The default setting is 10.00 dB.
- **Ref Value** - Allows you to set the reference value ranging from -250.00 to +250.00 dBm with 0.01 dB resolution. This value is automatically determined in 10 dB steps by the magnitude of measurement results because **Scale Coupling** is defaulted to **On**.
- **Ref Position** - Allows you to set the reference position to either **Top**, **Ctr** (center) or **Bot** (bottom). The default setting is **Top**.

[Making PDC Measurements](#)

[Making the Occupied Bandwidth Measurement](#)

- **Scale Coupling** - Allows you to toggle the scale coupling function between **On** and **Off**. The default setting is **On**. If set to **On**, **Ref Value** automatically changes to the appropriate value by 10 dB increments according to the channel power level.

Troubleshooting Hints

The occupied bandwidth measurements can suggest some defective parts in the I/Q modulator section of the UUT.

Making the Spectrum (Frequency Domain) Measurement

Purpose

The spectrum measurement provides spectrum analysis capability for the instrument. The control of the measurement was designed to be familiar to those who are accustomed to using swept spectrum analyzers.

This measurement is FFT (Fast Fourier Transform) based. The FFT-specific parameters are located in the **Advanced** menu. Also available under basic mode spectrum measurements is an I/Q window, which shows the I and Q signal waveforms in parameters of voltage versus time. The advantage of having an I/Q view available while in the spectrum measurement is that it allows you to view complex components of the same signal without changing settings or measurements.

Measurement Method

The measurement uses digital signal processing to sample the input signal and convert it to the frequency domain. With the instrument tuned to a fixed center frequency, samples are digitized at a high rate, converted to I and Q components with DSP hardware, and then converted to the frequency domain with FFT software.

Making the Measurement

NOTE

The factory default parameters provide a good starting point. You will likely want to change some of the settings. Press **Meas Setup, More (1 of 2), Restore Meas Defaults** at any time to return all parameters for the current measurement to their default settings.


Press **Measure, Spectrum (Freq Domain)** to immediately make a spectrum measurement.

To change any of the measurement parameters from the factory default values, refer to the “Changing the Measurement Setup” section for this measurement.

Results

A display with both a Spectrum window and an I/Q Waveform window will appear when you activate a spectrum measurement. Use the **Next Window** key to select a window, and the **Zoom** key to enlarge a window.

Figure 7-7 Spectrum Measurement - Spectrum and I/Q Waveform View



Changing the Measurement Setup

The following table shows the factory default settings for spectrum (frequency domain) measurements.

Table 7-4

Spectrum (Frequency Domain) Measurement Defaults

Measurement Parameter	Factory Default Condition
View/Trace	Spectrum
Trace Display	All
Res BW	20.0000 kHz; Auto
Averaging:	
Avg Number	25; On
Avg Mode	Exp
Avg Type	Log-Pwr Avg (Video)
Trig Source	Free Run (Immediate)
Spectrum View:	
SPAN	1.00000 MHz
AMPLITUDE Y Scale - Scale/Div	10.00 dB
I/Q Waveform View:	
Capture Time	188.00 μ s
AMPLITUDE Y Scale - Scale/Div	100.0 mV
Advanced	
Pre-ADC BPF	On
Pre-FFT Filter	Flat
Pre-FFT BW	1.55000 MHz; Auto
FFT Window	Flat Top (High Amptd Acc)
FFT Size:	
Length Control	Auto
Min Points/RBW	3.100000
Window Length	706
FFT Length	1024
ADC Range	Auto Peak
Data Packing	Auto
ADC Dither	Auto
Decimation	0; Auto
IF Flatness	On

NOTE Parameters under the **Advanced** key seldom need to be changed. Any changes from the default advanced values may result in invalid measurement data.

Make sure the **Spectrum (Freq Domain)** measurement is selected under the **Measure** menu. Press the **Meas Setup** key to access a menu which allows you to modify the averaging and trigger source for this measurement (as described in the “Measurement Setup” section). In addition, the following parameters can be modified:

- **Span** - Allows you to modify the frequency span. The range is 10.000 Hz to 10.000 MHz with 1 Hz resolution, depending on the **Res BW** setting. Changing the span causes the resolution bandwidth to change automatically, and will affect data acquisition time.
- **Res BW** - Allows you to set the resolution bandwidth for the FFT, and to toggle its mode between **Auto** and **Man** (manual). If set to **Auto**, the resolution bandwidth is set to **Span/50** (2% of the span). If set to **Man**, you can enter a value ranging from 100.0 mHz to 3.00000 MHz. A narrower bandwidth will result in a longer data acquisition time.
- **Advanced** - Allows you to access the menu to change the following parameters. The FFT advanced features should be used only if you are familiar with their operation. Changes from the default values may result in invalid data.
 - **Pre-ADC BPF** - Allows you to toggle the pre-ADC bandpass filter function between **On** and **Off**. The pre-ADC bandpass filter is useful for rejecting nearby signals, so that sensitivity within the span range can be improved by increasing the ADC range gain.
 - **Pre-FFT Fitr** - Allows you to toggle the pre-FFT filter between **Flat** (flat top) and **Gaussian**. The pre-FFT filter defaults to a flat top filter which has better amplitude accuracy. The Gaussian filter has better pulse response.
 - **Pre-FFT BW** - Allows you to toggle the pre-FFT bandwidth function between **Auto** and **Man** (manual). The pre-FFT bandwidth filter can be set between 1 Hz and 10 MHz. If set to **Auto**, this pre-FFT bandwidth is nominally 50% wider than the span. This bandwidth determines the ADC sampling rate.
 - **FFT Window** - Allows you to access the following selection menu. Unless you are familiar with FFT windows, use the flat top filter (the default filter).
 - Flat Top** - Selects this filter for best amplitude accuracy by reducing scalloping error.
 - Uniform** - Select this filter to have no window active by using the uniform setting.

- Hanning** - Press this key to activate the Hanning filter.
 - Hamming** - Press this key to activate the Hamming filter.
 - Gaussian** - Press this key to activate the Gaussian filter with the roll-off factor (alpha) of 3.5.
 - Blackman** - Press this key to activate the Hamming filter.
 - Blackman Harris** - Press this key to activate the Hamming filter.
 - K-B 70dB/90dB/110dB (Kaiser-Bessel)** - Select one of the Kaiser-Bessel filters with sidelobes at -70 , -90 , or -110 dBc.
- **FFT Size** - Allows you to access the menu to change the following parameters:
- Length Ctrl** - Allows you to toggle the FFT and window length setting function between **Auto** and **Man** (manual).
 - Min Pts in RBW** - Allows you to set the minimum number of data points that will be used inside the resolution bandwidth. The range is 0.10 to 100.00 points with 0.01 resolution. This key is grayed out if **Length Ctrl** is set to **Man**.
 - Window Length** - Allows you to enter the FFT window length in the number of capture samples, ranging from 8 to 1048576. This length represents the actual quantity of I/Q samples that are captured for processing by the FFT (“Capture Time” is the associated parameter shown on the screen). This key is grayed out if **Length Control** is set to **Auto**.
 - FFT Length** - Allows you to enter the FFT length in the number of captured samples, ranging from 8 to 1048576. The FFT length setting is automatically limited so that it is equal to or greater than the FFT window length setting. Any amount greater than the window length is implemented by zero-padding. This key is grayed out if **Length Control** is set to **Auto**.
- **ADC Range** - Allows you to access the menu to define one of the following ADC ranging functions:
- Auto** - Select this to set the ADC range automatically. For most FFT spectrum measurements, the auto feature should not be selected. An exception is when measuring a signal which is “bursty”, in which case auto can maximize the time domain dynamic range, if FFT results are less important to you than time domain results.
 - Auto Peak** - Select this to set the ADC range automatically to the peak signal level. Auto peak is a compromise that works well for both CW and burst signals.

Making PDC Measurements

Making the Spectrum (Frequency Domain) Measurement

- Auto Peak Lock** - Select this to hold the ADC range automatically at the peak signal level. Auto peak lock is more stable than auto peak for CW signals, but should not be used for “bursty” signals.
- Manual** - Allows you to access the selection menu of values to set the ADC range level. Also note that manual ranging is best for CW signals.
- **Data Packing** - Allows you to select **Auto** (the default) or the **Short (16 bit)**, **Medium (24 bit)** and **Long (32 bit)** methods of data packing. The short, medium, and long methods are not compatible with all settings and should not be used unless you are familiar with data packing methods. **Auto** is the preferred choice.
 - Auto** - The data packing value most appropriate for current instrument settings is selected automatically.
 - Short (16 bit)** - Select this to pack data every 16 bits.
 - Medium (24 bit)** - Select this to pack data every 24 bits.
 - Long (32 bit)** - Select this to pack data every 32 bits.
- **ADC Dither** - Allows you to toggle the ADC dither function between **Auto**, **On**, and **Off**. When set to **Auto** (the default), the ADC dither function will be activated when a narrow bandwidth is being measured, and deactivated when a wide bandwidth is being measured. “ADC dither” refers to the introduction of noise to the digitized steps of the analog-to-digital converter; the result is an improvement in amplitude accuracy. Use of the ADC dither, however, reduces dynamic range by approximately 3 dB.
- **Decimation** - Allows you to toggle the decimation function between **Auto** and **Man**, and to set the decimation value. **Auto** is the preferred setting, and the only setting that guarantees alias-free FFT spectrum measurements. If you are familiar with the decimation feature, you can change the decimation value by setting to **Man**, but be aware that aliasing can result in higher values. Decimation numbers 1 to 1000 describe the factor by which the number of points are reduced. The default setting is 0, which results in no data point reduction. Decimation by 3 keeps every 3rd sample, throwing away the 2 in between.
- **IF Flatness** - Allows you to toggle the IF flatness function between **On** and **Off**. If set to **On** (the default), the IF flatness feature causes background amplitude corrections to be performed on the FFT spectrum. The **Off** setting is used for adjustment and troubleshooting of the test instrument.

Changing the View

The View/Trace key allows you to select the desired view of the measurement from the following. You can use the Next Window key to move between the multiple windows (if any) and make it full size by Zoom.

- **Spectrum** - Provides a combination view of the spectrum graph in parameters of power versus frequency with the semi-log graticules, and the I/Q waveform graph in the parameters of voltage and time. Changes to frequency span or power will sometimes affect data acquisition.
- **I/Q Waveform** - Provides a view of the I/Q waveform graph in parameters of voltage versus time in the linear graticules. Changes to sweep time or resolution bandwidth will sometimes affect data acquisition.

Changing the Display

The **Span** key under the **Meas Setup** menu controls the horizontal span of the spectrum window. If the **SPAN X Scale** key is pressed, this **Span** key is activated, while the **AMPLITUDE Y Scale** key allows you to access the menus to modify the vertical parameters depending on the selected windows.

Changing the Spectrum Display

If the window is active in the **Spectrum** view, the **SPAN X Scale** and **AMPLITUDE Y Scale** keys access the menus to modify the following parameters:

- With the **SPAN X Scale** key:
 - **Span** - Allows you to modify the frequency span. The range is 10.000 Hz to 10.000 MHz with 1 Hz resolution, depending on the **Res BW** setting. Changing the span causes the resolution bandwidth to change automatically, and will affect data acquisition time.
- With the **AMPLITUDE Y Scale** key:
 - **Scale/Div** - Allows you to set the vertical scale by changing an amplitude value per division. The range is 1.00 nV to 20.00 V per division. The default setting is 100.0 mV. However, since the **Scale Coupling** default is **On**, this value is automatically determined by the measurement results. To manually set this value **Scale Coupling** must be **Off**.

Making PDC Measurements

Making the Spectrum (Frequency Domain) Measurement

- **Ref Value** - Allows you to set the reference value ranging from -250.00 to 250.00 V. The default setting is 0.00 V. However, since the **Scale Coupling** default is **On**, this value is automatically determined by the measurement results. To manually set this value **Scale Coupling** must be **Off**.
- **Ref Position** - Allows you to set the reference position to either **Top**, **Ctr** (center) or **Bot** (bottom). The default setting is **Ctr**.
- **Scale Coupling** - Allows you to toggle the scale coupling function between **On** and **Off**. The default setting is **On**. Upon pressing the **Restart** front-panel key or **Restart** softkey under the **Meas Control** menu, this function automatically determines the scale per division and reference values based on the measurement results. To manually set either **Scale/Div** or **Ref Value** values, **Scale Coupling** must be **Off**.

Selecting Displayed Traces Within Windows

The **View/Trace** key allows you to access the **Trace Display** key to reveal the trace selection menu. The currently selected trace type is shown on the **Trace Display** key.

- **All** - Allows you to view both the current trace and the average trace.
- **Average** - Allows you to view only the average trace (in blue color).
- **Current** - Allows you to view only the trace (in yellow color) for the latest data acquisition.

Using the Markers

The **Marker** front-panel key accesses the menu to configure the markers. If you want to use the marker function in the I/Q waveform window, press **Marker**, **Trace**, **I/Q Waveform**.

- **Select 1 2 3 4** - Allows you to activate up to four markers with the corresponding numbers, respectively. The selected number is underlined and its function is defined by pressing the **Function** key. The default is 1.
- **Normal** - Allows you to activate the selected marker to read the frequency and amplitude of the marker position on the spectrum trace. Marker position is controlled by the **RPG** knob.
- **Delta** - Allows you to read the differences in frequencies and amplitudes between the selected marker and the next.
- **Function Off** - Allows you to define the selected marker function to be **Band Power**, **Noise**, or **Off**. The default is **Off**. If set to **Band Power**, you need to select **Delta**.

- **Trace Spectrum** - Allows you to place the selected marker on the **Spectrum**, **Spectrum Avg**, or **I/Q Waveform** trace. The default is **Spectrum**.
- **Off** - Allows you to turn off the selected marker.
- **Shape Diamond** - Allows you to access the menu to define the selected marker shape to be **Diamond**, **Line**, **Square**, or **Cross**. The default shape is **Diamond**.
- **Marker All Off** - Allows you to turn off all of the markers.

The front panel **Search** key performs a peak search when pressed. A marker will automatically be activated at the highest peak.

Measuring Band Power

A band power measurement using the markers calculates the average power between two adjustable markers. To make a band power measurement:

1. Press the **Marker** key.
2. Press **Trace**, **Spectrum** to activate a marker on the instantaneous spectrum signal.
3. Press the **Spectrum Avg** key to activate a marker on the average spectrum trace.
4. Press **Function**, **Band Power**.
5. Two marker lines are activated at the extreme left side of the horizontal scale. Press **Normal** and move marker 1 to the desired place by rotating the **RPG** knob.
6. Press **Delta** to bring marker 2 to the same place as marker 1.
7. Move marker 1 to the other desired position by rotating the **RPG** knob. Band power measures the average power between the two markers.
8. When the band power markers are active, the results are shown in the results window as **Mean Pwr (Between Mks)**. When the band power function is off the results window reads **Mean Pwr (Entire Trace)**.

Troubleshooting Hints

Changes made by the user to advanced spectrum settings, particularly to ADC range settings, can inadvertently result in spectrum measurements that are invalid and cause error messages to appear. Care needs to be taken when using advanced features.

Making the Waveform (Time Domain) Measurement

Purpose

The waveform measurement is a generic measurement for viewing the input signal waveforms in the time domain. This measurement is how the instrument performs the zero span functionality found in traditional spectrum analyzers. Also available under basic mode waveform measurements is an I/Q window, which shows the I and Q signal waveforms in parameters of voltage versus time. The advantage of having an I/Q view available while in the waveform measurement is that it allows you to view complex components of the same signal without changing settings or measurements.

The waveform measurement can be used to perform general purpose power measurements to a high degree of accuracy.

Measurement Method

The instrument makes repeated power measurements at a set frequency, similar to the way a swept-tuned spectrum analyzer makes zero span measurements. The input analog signal is converted to a digital signal, which then is processed into a representation of a waveform measurement. The measurement relies on a high rates of sampling to create an accurate representation of a time domain signal.

This measurement is available for use with both the RF input and baseband I/Q inputs. For details on Baseband I/Q operation see the section on [“Using Option B7C Baseband I/Q Inputs”](#).

Making the Measurement

NOTE

The factory default parameters provide a good starting point. You may want to change some of the settings. Press Meas Setup, More (1 of 2), Restore Meas Defaults at any time to return all parameters for the current measurement to their default settings.

Press **MEASURE, Waveform (Time Domain)** to immediately make a waveform (time domain) measurement.


To change any of the measurement parameters from the factory default values, refer to the “Changing the Measurement Setup” section for this measurement.

Results

The next figure shows an example of an RF Envelope result for the waveform (time domain) measurements in the graph window. The measured values for the mean power and peak-to-mean power are shown in the text window.

Figure 7-8

Waveform Measurement - RF Envelope View



Changing the Measurement Setup

This table shows the factory default settings for waveform (time domain) measurements.

Table 7-5

Waveform (Time Domain) Measurement Defaults

Measurement Parameter	Factory Default Condition
View/Trace	RF Envelope
Sweep Time	10.00 ms
Res BW	100.000 kHz
Averaging:	
Avg Number	10; Off
Avg Mode	Exp
Avg Type	Pwr Avg (RMS)
Trig Source	Free Run (Immediate)

Table 7-5

Waveform (Time Domain) Measurement Defaults

Measurement Parameter	Factory Default Condition
RF Envelope View: SPAN X Scale - Scale/Div AMPLITUDE Y Scale - Scale/Div	200.0 μ s 10.00 dB
I/Q Waveform View: SPAN X Scale -Scale/Div AMPLITUDE Y Scale - Scale/Div	200.0 μ s 100.0 mV
Advanced	
Pre-ADC BPF	Off
RBW Filter	Gaussian
ADC Range	Auto
Data Packing	Auto
ADC Dither	Off
Decimation	Off

NOTE

Parameters that are under the **Advanced** key seldom need to be changed. Any changes from the default values may result in invalid measurement data.

Make sure the **Waveform (Time Domain)** measurement is selected under the **MEASURE** menu. Press the **Meas Setup** key to access a menu which allows you to modify the averaging, and trigger source for this measurement (as described in the “Measurement Setup” section).

In addition, the following parameters can be modified:

- **Sweep Time** - Allows you to specify the measurement acquisition time which is used as the length of the time capture record. The range is 1.0 μ s and 100.0 s, depending upon the resolution bandwidth setting and the available internal memory size for acquisition points.
- **Res BW** - Allows you to set the measurement bandwidth. The range is 10 Hz to 7.5 MHz. A larger bandwidth results in a larger number of acquisition points and reduces the maximum value allowed for the sweep time.
- **Advanced** - Allows you to access the menu to change the following parameters. Changes from the default values may result in invalid data.

- **Pre-ADC BPF** - Allows you to toggle the pre-ADC bandpass filter function between **On** or **Off**. The default setting is **Off**. The pre-ADC bandpass filter is useful for rejecting nearby signals, so that sensitivity within the span range can be improved by increasing the ADC range gain.
- **RBW Filter** - Allows you toggle the resolution bandwidth filter selection between **Flat** and **Gaussian**. If set to **Gaussian**, the filter provides more even time-domain response, particularly for “bursts”. If set to **Flat**, the filter provides a flatter bandwidth but is less accurate for “pulse responses”. A flat top filter also requires less memory and allows longer data acquisition times. For most waveform applications, the Gaussian filter is recommended.
- **ADC Range** - Allows you to access the menu to select one of the ADC ranging functions:
 - Auto** - Select this to cause the instrument to automatically adjust the signal range for optimal measurement results.
 - AutoPeak** - Select this to cause the instrument to continuously seek the highest peak signal.
 - AutoPeakLock** - Select this to cause the instrument to adjust the range for the highest peak signal it identifies, and retains the range settings determined by that peak signal, even when the peak signal is no longer present.
 - Manual** - Allows you to access the selection menu of values to set the ADC range level. Also note that manual ranging is best for CW signals.
- **Data Packing** - Allows you to select **Auto** (the default) or the **Short (16 bit)**, **Medium (24 bit)** and **Long (32 bit)** methods of data packing. The short, medium, and long methods are not compatible with all settings and should not be used unless you are familiar with data packing methods. **Auto** is the preferred choice.
 - Auto** - The data packing value most appropriate for current instrument settings is selected automatically.
 - Short (16 bit)** - Select this to pack data every 16 bits.
 - Medium (24 bit)** - Select this to pack data every 24 bits.
 - Long (32 bit)** - Select this to pack data every 32 bits.
- **ADC Dither** - Allows you to toggle the ADC dither function between **On** and **Off**. The default setting is **Off**. If set to **On**, the ADC dither refers to the introduction of noise to the digitized steps of the analog-to-digital converter, and results in better amplitude linearity and resolution in low level signals. However, it also results in reduced dynamic range by approximately 3 dB.

Making PDC Measurements

Making the Waveform (Time Domain) Measurement

- **Decimation** - Allows you to toggle the decimation function between **On** and **Off**, and to set the decimation value. Decimation allows longer acquisition times for a given bandwidth by eliminating data points. Long time captures can be limited by the instrument data acquisition memory. Decimation numbers 1 to 4 describe the factor by which the number of points are reduced. The default setting is 1, which results in no data point reduction.

Changing the View


The **Trace/View** key allows you to access the selection menu for the desired measurement view. You can use the **Next Window** key to move between the multiple windows (if any) and make it full size by **Zoom**.

Windows Available for Waveform Measurements

The following views are available to display measurement data, and are accessed by pressing the **Trace/View** key:


- **RF Envelope** - Provides a combination view of the waveform graph in parameters of power versus time with the semi-log graticules, and the measurement results for Mean Pwr (Entire Trace), Pk-to-Mean, Current Data for Max Pt and Min Pt are shown in the text window. Changes to sweep time or resolution bandwidth will sometimes affect data acquisition.

Figure 7-9 Waveform Measurement - RF Envelope View



I/Q Waveform - Provides a view of the I/Q waveform graph in parameters of voltage versus time in the linear graticules. Changes to sweep time or resolution bandwidth will sometimes affect data acquisition.

Figure 7-10 Waveform Measurement - I/Q Waveform View



Changing the Display

The **Sweep Time** key under the **Meas Setup** menu controls the horizontal time span for this measurement, while the **SPAN X Scale** key allows you to access the menu to modify the horizontal parameters common to the rectangular windows for this measurement:

- **Scale/Div** - Allows you to set the horizontal scale by changing a time value per division. The range is 1.0 ns to 1.000 s per division with 0.01 ns resolution. The default setting is 200.0 μ s per division. When the **Scale Coupling** default setting **On** is in effect, displayed plots use a Scale/Div value determined by the analyzer, based on the measurement result.
- **Ref Value** - Allows you to set the reference value ranging from -1.0 to 10.0 s. The default setting is 0.00 s. When the **Scale Coupling** default setting **On** is in effect, displayed plots use a Scale/Div value determined by the analyzer, based on the measurement result.
- **Ref Position** - Allows you to set the reference position to either **Left**, **Ctr** (center) or **Right**. The default setting is **Left**.

Making PDC Measurements

Making the Waveform (Time Domain) Measurement

- **Scale Coupling** - Allows you to toggle the scale coupling function between **On** and **Off**. The default setting is **On**. Upon pressing the **Restart** front-panel key or **Restart** softkey under the **Meas Control** menu, this function automatically determines the scale per division and reference values based on the measurement results.

If the RF Envelope window is active in the RF Envelope view, the **AMPLITUDE Y Scale** key accesses the menu to modify the following parameters:

- **Scale/Div** - Allows you to set the vertical scale by changing an amplitude value per division. The range is 0.10 to 20.00 dB per division with 0.01 dB resolution. The default setting is 10.00 dB per division. When the **Scale Coupling** default setting **On** is in effect, displayed plots use a Scale/Div value determined by the analyzer, based on the measurement result.
- **Ref Value** - Allows you to set the reference value ranging from -250.00 to 250.00 dBm. The default setting is 0.00 dBm. When the **Scale Coupling** default setting **On** is in effect, displayed plots use a Scale/Div value determined by the analyzer, based on the measurement result.
- **Ref Position** - Allows you to set the reference position to either **Top**, **Ctr** (center) or **Bot** (bottom). The default setting is **Top**.
- **Scale Coupling** - Allows you to toggle the scale coupling function between **On** and **Off**. The default setting is **On**. Upon pressing the **Restart** front-panel key or **Restart** softkey under the **Meas Control** menu, this function automatically determines the scale per division and reference values based on the measurement results.

If the I/Q Waveform window is active in the I/Q Waveform view, the **AMPLITUDE Y Scale** key accesses the menu to modify the following parameters:

- **Scale/Div** - Allows you to set the vertical scale by changing an amplitude value per division. The range is 1.00 nV to 20.00 V per division. The default setting is 100.0 mV. When the **Scale Coupling** default setting **On** is in effect, displayed plots use a Scale/Div value determined by the analyzer, based on the measurement result.
- **Ref Value** - Allows you to set the reference value ranging from -250.00 to 250.00 V. The default setting is 0.00 V. When the **Scale Coupling** default setting **On** is in effect, displayed plots use a Scale/Div value determined by the analyzer, based on the measurement result.
- **Ref Position** - Allows you to set the reference position to either **Top**, **Ctr** (center) or **Bot** (bottom). The default setting is **Ctr**.

- **Scale Coupling** - Allows you to toggle the scale coupling function between **On** and **Off**. The default setting is **On**. Upon pressing the **Restart** front-panel key or **Restart** softkey under the **Meas Control** menu, this function automatically determines the scale per division and reference values based on the measurement results.

The **Display** key is not available for this measurement.

Using the Markers

The **Marker** front-panel key accesses the menu to configure the markers.

- **Select 1 2 3 4** - Allows you to activate up to four markers with the corresponding numbers, respectively. The selected number is underlined and its function is defined by pressing the **Function** key. The default is 1.
- **Normal** - Allows you to activate the selected marker to read the time position and amplitude of the marker on the RF envelope trace. Marker position is controlled by the **RPG** knob.
- **Delta** - Allows you to read the differences in time positions and amplitudes between the selected marker and the next.
- **Function Off** - Allows you to define the selected marker function to be **Band Power**, **Noise**, or **Off**. The default is **Off**. If set to **Band Power**, you need to select **Delta**.
- **Trace** - Allows you to place the selected marker on **RF Envelope**, or **I/Q Waveform**.
- **Off** - Allows you to turn off the selected marker.
- **Shape Diamond** - Allows you to access the menu to define the selected marker shape to be **Diamond**, **Line**, **Square**, or **Cross**. The default shape is **Diamond**.
- **Marker All Off** - Allows you to turn off all of the markers.

The front panel **Search** key performs a peak search when pressed. A marker will automatically be activated at the highest peak.

NOTE

In the Waveform measurement, the **Mean Pwr (Entire Trace)** value plus the **Pk-to-Mean** value will sum to equal the current **Max Pt.** value as shown in the data window below the RF Envelope display. If you do a marker peak search (**Search**) with averaging turned off, the marker will find the same maximum point. However, if you turn averaging on, the **Pk-to-Mean** value will use the highest peak found for any acquisition during averaging, while the marker peak will look for the peak of the display, which is the result of n-averages. This will usually result in differing values for the maximum point.

[Making PDC Measurements](#)[Making the Waveform \(Time Domain\) Measurement](#)

Troubleshooting Hints

Changes made to advanced waveform settings can inadvertently result in measurements that are invalid and cause error messages to appear. Care needs to be taken when using advanced features, as some settings may incorrectly appear to provide a valid result. Use the Meas Setup, More, Restore Meas Defaults function to return the measurement settings to a known state, and then vary settings only as necessary.

8 PDC Programming Commands

These commands are only available when the PDC mode has been selected using `INSTRument:SElect PDC`. If PDC mode is selected, commands that are unique to another mode are not available.

SCPI Command Subsystems

- “CALCulate Subsystem” on page 290.
- “CONFigure Subsystem” on page 313.
- “DISPlay Subsystem” on page 314.
- “FETCh Subsystem” on page 323.
- “FORMat Subsystem” on page 324.
- “INITiate Subsystem” on page 326.
- “INSTrument Subsystem” on page 328.
- “MEASure Group of Commands” on page 331.
- “READ Subsystem” on page 350.
- “SENSe Subsystem” on page 351.
- “TRIGger Subsystem” on page 389.

Programming Command Compatibility Across Model Numbers and Across Modes

Across PSA Modes: Command Subsystem Similarities

When you select different modes you get different sets of available programming commands. That is, *only* the commands that are appropriate for the current mode are available. Also, some commands have the same syntax in different modes but have different ranges or settings that are only appropriate to the current mode.

The following table shows which command subsystems are the same across different modes. If there is no “X” by a particular subsystem, then the set of available commands is different in those modes. Command ranges or defaults may also be different. Refer to the programming command descriptions in the documentation for each mode for details.

Command Subsystem	Same command set is available: SA mode compared with the application modes: W-CDMA, cdmaOne, cdma2000, Basic, GSM, EDGE, NADC, or PDC	Same command set is available: SA mode compared with the application mode: Phase Noise
IEEE common commands	X	X
ABORt	X	X
CALCulate		
CALibration	X	X
CONFigure		
COUPle	not available in these application modes	not available in this application modes
DISPlay		
FETCh		
FORMat		X
HCOPy	X	X
INITiate		
INPut	not available in these application modes	X

PDC Programming Commands
 Programming Command Compatibility Across Model Numbers and Across Modes

Command Subsystem	Same command set is available: SA mode compared with the application modes: W-CDMA, cdmaOne, cdma2000, Basic, GSM, EDGE, NADC, or PDC	Same command set is available: SA mode compared with the application mode: Phase Noise
MEASure		
MEMory	X	X
MMEMory	X	X
MMEMory:STORe:TRACe	not available in application modes	X
READ		
[SENSe] [SENSe:]CHANnel [SENSe:]CORRection [SENSe:]FEED [SENSe:]FREQuency:CENTer [SENSe:]FREQuency: <other subsystems> [SENSe:]<measurement> [SENSe:]POWer [SENSe:]RADio [SENSe:]SYNC	X not available in application modes	 not available in application modes
STATus	X	X
SYSTem	X	X
TRACe	not available in application modes	X
TRIGger		
UNIT	X	X

Across PSA Modes: Specific Command Differences

Some programming commands operate differently depending on which Mode the analyzer is set to.

Command	Spectrum Analysis and Phase Noise Mode	Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, PDC Modes
*RST	Resets instrument, putting it in continuous measurement mode and turning off the current measurement.	Resets instrument, putting it in continuous measurement mode, but leaving the current measurement active.
CONFigure: <measurement>	Accesses the measurement and sets the instrument settings to the defaults. Averaging is turned on and set to 10. The instrument is put in single measurement mode. It does not initiate a measurement. Use INIT:IMM to make one measurement.	Accesses the measurement and sets the instrument settings to the defaults. If you were already in single measurement mode, it takes one measurement and then waits. If you were in continuous measurement mode it continues to measure.
*ESE default	Default is 255 which means that every error/status bit change that has occurred will be returned with a *ESR? query. You must set the value of *ESE to choose only the bits/status that you want returned.	Default is 0 which means that none of the error/status bit changes that have occurred will be returned with a *ESR? query. You must set the value of *ESE to choose the bits/status that you want returned.
TRIGger commands	For these modes, only one trigger source can be selected and it will be common across the modes. Also, only one value can be set for the trigger delay, level, or polarity.	For these modes, a unique trigger source can be selected for each mode. Also, each trigger source can have unique settings for the its delay, level, and polarity.
Saving and recalling traces	Traces can only be saved when in the Spectrum Analysis mode (MMEM:STOR:TRAC). This is because the instrument state must be saved along with the trace data and the state data varies depending on the number of modes currently available in the instrument.	

Using Applications in PSA Series vs. VSA E4406A

NOTE This information *only* applies to the application modes: Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, and PDC.

Command	PSA Series	VSA E4406A: A.04.00	VSA E4406A: A.05.00
*RST	Resets instrument, putting it in continuous measurement mode. Use INIT:CONT OFF to select single measurement mode and INIT:IMM to start one measurement.	Resets instrument, putting it in single measurement mode. One measurement is initiated when the command is sent.	Resets instrument, putting it in single measurement mode. No measurement is initiated when the command is sent. Use INIT:IMM to start one measurement.
CONFigure: <measurement>	Accesses the measurement and sets the instrument settings to the defaults. If you were already in single measurement mode, it takes one measurement and then waits.	Same as PSA. Accesses the measurement and sets the instrument settings to the defaults. If you were already in single measurement mode, it takes one measurement and then waits.	Accesses the measurement and sets the instrument settings to the defaults. If you were already in single measurement mode, it does not initiate a measurement. Use INIT:IMM to make one measurement.
*ESE default	Default is 255 which means that every error/status bit change that has occurred will be returned with a *ESR? query. You must set the value of *ESE to choose only the bits/status that you want returned.	Default is 0 which means that none of the error/status bit changes that have occurred will be returned with a *ESR? query. You must set the value of *ESE to choose the bits/status that you want returned.	Same as VSA A.04.00. Default is 0 which means that none of the error/status bit changes that have occurred will be returned with a *ESR? query. You must set the value of *ESE to choose the bits/status that you want returned.
TRIGger commands	In Spectrum Analysis mode only one value can be set for the trigger's source, delay, level, or polarity. Basic, GSM, EDGE, cdmaOne, cdma2000, W-CDMA, NADC, PDC modes function the same as VSA	You can select a unique trigger source for each mode. Each trigger source can have unique settings for the its delay, level, and polarity.	Same as VSA A.04.00. You can select a unique trigger source for each mode. Each trigger source can have unique settings for the its delay, level, and polarity.

Command	PSA Series	VSA E4406A: A.04.00	VSA E4406A: A.05.00
AUTO ON OFF control and setting manual values	<p>We recommend that you set a function's automatic state to OFF, before you send it your manual value.</p> <p>Some functions will turn off the automatic mode when you send a specific manual value, but others will not. This also varies with the instrument model.</p>	<p>We recommend that you set a function's automatic state to OFF, before you send it your manual value.</p> <p>Some functions will turn off the automatic mode when you send a specific manual value, but others will not. This also varies with the instrument model.</p>	<p>We recommend that you set a function's automatic state to OFF, before you send it your manual value.</p> <p>Some functions will turn off the automatic mode when you send a specific manual value, but others will not. This also varies with the instrument model.</p>

CALCulate Subsystem

This subsystem is used to perform post-acquisition data processing. In effect, the collection of new data triggers the CALCulate subsystem. In this instrument, the primary functions in this subsystem are markers and limits.

The SCPI default for data output format is ASCII. The format can be changed to binary with FORMat:DATA which transports faster over the bus.

Adjacent Channel Power—Limit Test

```
:CALCulate:ACP:LIMit[:TEST] OFF|ON|0|1
```

```
:CALCulate:ACP:LIMit[:TEST]?
```

Turn limit test on or off.

Factory Preset: On

Remarks: You must be in the NADC, PDC mode to use this command. Use INSTRument:SElect to set the mode.

Test Current Results Against all Limits

```
:CALCulate:CLIMits:FAIL?
```

Queries the status of the current measurement limit testing. It returns a 0 if the measured results pass when compared with the current limits. It returns a 1 if the measured results fail any limit tests.

Data Query

```
:CALCulate:DATA[n]?
```

Returns the designated measurement data for the currently selected measurement and sub-opcode.

n = any valid sub-opcode for the current measurement. See the “MEASure Group of Commands” on page 331 for information on the data that can be returned for each measurement.

For sub-opcodes that return trace data use the :CALCulate:DATA[n]:COMPRESS? command below.

Calculate/Compress Trace Data Query

```
:CALCulate:DATA<n>:COMPRESS?  
BLOCK|CFIT|MAXimum|MEAN|MINimum|RMS|SAMPLE|SDEVIation  
[,<soffset>[,<length>[,<roffset>[,<rlimit>]]]]
```

Returns compressed data for the specified trace data. The data is returned in the same units as the original trace and only works with the currently selected measurement. The command is used with a sub-opcode *<n>* since measurements usually return several types of trace data. See the following table for the sub-opcodes for the trace data names that are available in each measurement. For sub-opcodes that return scalar data use the :CALCulate:DATA[n]? command above.

This command is used to compress or decimate a long trace to extract and return only the desired data. A typical example would be to acquire N frames of GSM data and return the mean power of the first burst in each frame. The command can also be used to identify the best curve fit for the data.

BLOCK or block data - returns all the data points from the region of the trace data that you specify. For example, it could be used to return the data points of an input signal over several timeslots, excluding the portions of the trace data that you do not want.

CFIT or curve fit - applies curve fitting routines to the data. *<soffset>* and *<length>* are required to define the data that you want. *<roffset>* is an optional parameter for the desired order of the curve equation. The query will return the following values: the x-offset (in seconds) and the curve coefficients ((order + 1) values).

MAX, **MEAN**, **MIN**, **RMS**, **SAMP**, and **SDEV** return one data value for each specified region (or *<length>*) of trace data, for as many regions as possible until you run out of trace data (using *<roffset>* to specify regions). Or they return the number regions you specify (using *<rlimit>*) ignoring any data beyond that.

MAXimum - returns the maximum data point for the specified region(s) of trace data. For I/Q trace data, the maximum magnitude of the I/Q pairs is returned.

MEAN - returns the arithmetic mean of the data point values for the specified region(s) of trace data. For I/Q trace data, the mean of the magnitudes of the I/Q pairs is returned. Note: If the original trace data is in dB, this function returns the arithmetic mean of those log values, not log of the mean power, which is a more useful value.

MINimum - returns the minimum data point for the specified region(s) of trace data. For I/Q trace data, the minimum magnitude of the I/Q pairs is returned.

RMS - returns the arithmetic rms of the data point values for the specified region(s) of trace data. For I/Q trace data, the rms of the magnitudes of the I/Q pairs is returned. Note: This function is very useful for I/Q trace data. However, if the original trace data is in dB, this function returns the rms of the log values which is not usually needed.

Once you have the rms value for a region of I/Q trace data, you may want to calculate the mean power. You must convert this rms I/Q value (peak volts) to power in dB.

$$10 \times \log[10 \times (\text{rms value})^2]$$

SAMPLE - returns the first data value for the specified region(s) of trace data. For I/Q trace data, the first I/Q pair is returned.

SDEViation - returns the arithmetic standard deviation for the data point values for the specified region(s) of trace data. For I/Q trace data, the standard deviation of the magnitudes of the I/Q pairs is returned.

Figure 8-1 Sample Trace Data - Constant Envelope





Figure 8-2 Sample Trace Data - Not Constant Envelope



<soffset> - start offset is an optional real number (in seconds). It specifies the amount of data at the beginning of the trace that will be ignored before the decimation process starts. It is the time from the start of the trace to the point where you want to start using the data. The default value is zero.

<length> - is an optional real number (in seconds). It defines how much data will be compressed into one value. This parameter has a default value equal to the current trace length.

<roffset> - repeat offset is an optional real number (in seconds). It defines the beginning of the next field of trace elements to be compressed. This is relative to the beginning of the previous field. This parameter has a default value equal to the <length> variable.

<rlimit> - repeat limit is an optional integer. It specifies the number of data items that you want returned. It will ignore any additional items beyond that number. You can use the Start offset and the Repeat limit to pick out exactly what part of the data you want to use. The default value is all the data.

Example: To query the mean power of a set of GSM bursts:

1. Set the waveform measurement sweep time to acquire at least one burst.
2. Set the triggers such that acquisition happens at a known position relative to a burst.

- Then query the mean burst levels using,
`CALC:DATA2:COMP? MEAN,24e-6,526e-6` (These parameter values correspond to GSM signals, where 526e-6 is the length of the burst in the slot and you just want 1 burst.)

NOTE There is a more detailed example in the “Improving the Speed of Your Measurements” section in the PSA Series *User’s and Programmer’s Reference*. There is also a sample program in the Programming Fundamentals chapter of that book, and a copy of it is on the documentation CD-ROM.

Remarks: The optional parameters must be entered in the specified order. For example, if you want to specify <length>, you must also specify <soffset>.

This command uses the data in the format specified by FORMat:DATA, returning either binary or ASCII data.

History: Added in revision A.03.00

Measurement	Available Traces	Markers Available?
ACP - adjacent channel power (Basic, cdmaOne, cdma2000, W-CDMA, NADC, PDC modes)	no traces ($n=0$) ^a for I/Q points	no markers
CDPower - code domain power (cdmaOne mode)	POWer ($n=2$) ^a TIMing ($n=3$) ^a PHASe ($n=4$) ^a ($n=0$) ^a for I/Q points	yes
CDPower - code domain power (cdma2000, W-CDMA modes)	CDPower ($n=2$) ^a EVM ($n=5$) ^a MERRor ($n=6$) ^a PERRor ($n=7$) ^a SPOWer ($n=9$) ^a CPOWer ($n=10$) ^a ($n=0$) ^a for I/Q points	yes
CHPower - channel power (Basic, cdmaOne, cdma2000, W-CDMA modes)	SPECtrum ($n=2$) ^a ($n=0$) ^a for I/Q points	no markers

Measurement	Available Traces	Markers Available?
CSPur - spurs close (cdmaOne mode)	SPECTrum ($n=2$) ^a ULIMit ($n=3$) ^a ($n=0$) ^a for I/Q points	yes
EEVM - EDGE error vector magnitude (EDGE mode)	EVMError ($n=2$) ^a MERRor ($n=3$) ^a PERRor ($n=4$) ^a ($n=0$) ^a for I/Q points	yes
EORFspectr - EDGE output RF spectrum (EDGE mode)	RFEMod ($n=2$) ^a RFESwitching ($n=3$) ^a SPEMod ($n=4$) ^a LIMMod ($n=5$) ^a ($n=0$) ^a for I/Q points	yes, only for a single offset yes, only for multiple offsets
EPVTime - EDGE power versus time (EDGE mode)	RFENvelope ($n=2$) ^a UMASk ($n=3$) ^a LMASk ($n=4$) ^a ($n=0$) ^a for I/Q points	yes
ETSPur - EDGE transmit band spurs (EDGE mode)	SPECTrum ($n=2$) ^a ULIMit ($n=3$) ^a ($n=0$) ^a for I/Q points	yes
EVM - error vector magnitude (NADC, PDC modes)	EVM ($n=2$) ^a MERRor ($n=3$) ^a PERRor ($n=4$) ^a ($n=0$) ^a for I/Q points	yes
EVMQpsk - QPSK error vector magnitude (cdma2000, W-CDMA modes)	EVM ($n=2$) ^a MERRor ($n=3$) ^a PERRor ($n=4$) ^a ($n=0$) ^a for I/Q points	yes

PDC Programming Commands
CALCulate Subsystem

Measurement	Available Traces	Markers Available?
IM - intermodulation (cdma2000, W-CDMA modes)	SPECTrum ($n=2$) ^a ($n=0$) ^a for I/Q points	yes
MCPower - multi-carrier power (W-CDMA mode)	no traces ($n=0$) ^a for I/Q points	no markers
OBW - occupied bandwidth (cdmaOne, cdma2000, PDC, W-CDMA modes)	no traces ($n=0$) ^a for I/Q points	no markers
ORFSpectrum - output RF spectrum (GSM, EDGE mode)	RFEMod ($n=2$) ^a RFESwitching ($n=3$) ^a SPEMod ($n=4$) ^a LIMMod ($n=5$) ^a ($n=0$) ^a for I/Q points	yes, only for a single offset yes, only for multiple offsets
PFERror - phase and frequency error (GSM, EDGE mode)	PERRor ($n=2$) ^a PFERror ($n=3$) ^a RFENvelope ($n=4$) ^a ($n=0$) ^a for I/Q points	yes
PStatistic - power statistics CCDF (Basic, cdma2000, W-CDMA modes)	MEASured ($n=2$) ^a GAUSian ($n=3$) ^a REFerence ($n=4$) ^a ($n=0$) ^a for I/Q points	yes
PVTime - power versus time (GSM, EDGE modes)	RFENvelope ($n=2$) ^a UMASk ($n=3$) ^a LMASk ($n=4$) ^a ($n=0$) ^a for I/Q points	yes
RHO - modulation quality (cdmaOne, cdma2000, W-CDMA mode)	($n=0$) ^a for I/Q points EVM ($n=2$) ^a MERRor ($n=3$) ^a PERRor ($n=4$) ^a ($n=0$) ^a for I/Q points	yes

Measurement	Available Traces	Markers Available?
SEMask - spectrum emissions mask (cdma2000, W-CDMA mode)	SPECtrum ($n=2$) ^a ($n=0$) ^a for I/Q points	yes
TSPur - transmit band spurs (GSM, EDGE mode)	SPECtrum ($n=2$) ^a ULIMit ($n=3$) ^a ($n=0$) ^a for I/Q points	yes
TXPower - transmit power (GSM, EDGE mode)	RFENvelope ($n=2$) ^a IQ ($n=8$) ^a ($n=0$) ^a for I/Q points	yes
SPECtrum - (frequency domain) (all modes)	IQ ($n=3$) ^a SPECtrum ($n=4$) ^a ASPECtrum ($n=7$) ^a ($n=0$) ^a for I/Q points	yes
WAVEform - (time domain) (all modes)	RFENvelope ($n=2$) ^a (also for Signal Envelope trace) IQ ($n=5$) ^a ($n=0$) ^a for I/Q points	yes

a. The n number indicates the sub-opcode that corresponds to this trace. Detailed descriptions of the trace data can be found in the MEASure subsystem documentation by looking up the sub-opcode for the appropriate measurement.

Calculate Peaks of Trace Data

```
:CALCulate:DATA<n>:PEAKs?  
<threshold>,<excursion>[,<AMPLitude>|<FREQuency>|<TIME>]
```

Returns a list of peaks for the designated trace data *n* for the currently selected measurement. The peaks must meet the requirements of the peak threshold and excursion values.

The command can only be used with specific *<n>* (sub-opcode) values, for measurement results that are trace data. See the table above for the appropriate sub-opcodes. Both real and complex traces can be searched, but complex traces are converted to magnitude in dBm. Sub-opcode *n=0*, is the raw trace data which cannot be searched for peaks. Sub-opcode *n=1*, is the scaler data which also cannot be searched for peaks.

Threshold - is the level below which trace data peaks are ignored

Excursion - To be defined as a peak, the signal must rise above the threshold by a minimum amplitude change. Excursion is measured from the lowest point above the threshold (of the rising edge of the peak), to the highest signal point that begins the falling edge.

Amplitude - lists the peaks in order of descending amplitude, so the highest peak is listed first. This is the default peak order listing if the optional parameter is not specified.

Frequency - lists the peaks in order of occurrence, left to right across the x-axis

Time - lists the peaks in order of occurrence, left to right across the x-axis

Example: Select the spectrum measurement.

Use `CALC:DATA4:PEAK? -40,10,FREQ` to identify the peaks above -40 dBm, with excursions of at least 10 dB, in order of increasing frequency.

Query Results: Returns a list of floating-point numbers. The first value in the list is the number of peak points that follow. A peak point consists of two values: a peak amplitude followed by the its corresponding frequency (or time).

If no peaks are found the peak list will consist of only the number of peaks, (0).

The peak list is limited to 100 peaks. Peaks in excess of 100 are ignored.

Remarks: This command uses the data setting specified by the `FORMat:DATA` command and can return real 32-bit, real 64-bit, or ASCII data. The default data format is ASCII.

EVM - Limits

Error Vector Magnitude—I/Q Origin Offset Error Limit

`:CALCulate:EVM:LIMit:IQOffset <dB>`

`:CALCulate:EVM:LIMit:IQOffset?`

Set the I/Q origin offset error limit in dB.

Factory Preset: -20 dB

Range: -100 dB to 0 dB

Remarks: You must be in the NADC or PDC mode to use this command. Use INSTRument:SElect to set the mode.

History: Version A.02.00 or later

Error Vector Magnitude—Peak EVM Limit

`:CALCulate:EVM:LIMit:PEAK <percent>`

`:CALCulate:EVM:LIMit:PEAK?`

Set the peak EVM limit in percent.

Factory Preset: 40.0%

Range: 0 to 50%

Remarks: You must be in the NADC or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Error Vector Magnitude—RMS EVM Limit

`:CALCulate:EVM:LIMit:RMS <percent>`

`:CALCulate:EVM:LIMit:RMS?`

Set the RMS EVM limit in percent.

Factory Preset: 12.5%

Range: 0 to 50%

Remarks: You must be in the NADC or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Error Vector Magnitude—Limit Test

```
:CALCulate:EVM:LIMit[:TEST] OFF|ON|0|1
```

```
:CALCulate:EVM:LIMit[:TEST]?
```

Turn limit test on or off.

Factory Preset: On

Remarks: You must be in the NADC or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Error Vector Magnitude—Time to Sync Word

```
:CALCulate:EVM:TTSWord?
```

Query returns the time between the trigger and the start of the first sync word.

Default Unit: Seconds

Remarks: You must be in the NADC or PDC mode to use this command. Use INSTRument:SElect to set the mode.

CALCulate:MARKers Subsystem

Markers can be put on your displayed measurement data to supply information about specific points on the data. Some of the things that markers can be used to measure include: precise frequency at a point, minimum or maximum amplitude, and the difference in amplitude or frequency between two points.

When using the marker commands you must specify the measurement in the SCPI command. We recommend that you use the marker commands only on the current measurement. Many marker commands will return invalid results, when used on a measurement that is not current. (This is true for commands that do more than simply setting or querying an instrument parameter.) No error is reported for these invalid results.

You must make sure that the measurement is completed before trying to query the marker value. Using the MEASure or READ command, before the marker command, forces the measurement to complete before allowing the next command to be executed.

Each measurement has its own instrument state for marker parameters. Therefore, if you exit the measurement, the marker settings in each measurement are saved and are then recalled when you change back to that measurement.

Basic Mode - <measurement> key words

- SPECTrum - markers available
- WAVEform - markers available

cdmaOne Mode - <measurement> key words

- ACPr - no markers
- CHPower - no markers
- CDPower - markers available
- CSPur - markers available
- RHO - markers available
- SPECTrum - markers available
- WAVEform - markers available

cdma2000 Mode - <measurement> key words

- ACP - no markers
- CDPower - markers available
- CHPower - no markers
- EVMQpsk - markers available
- IM - markers available
- OBW - no markers
- PStatistic - markers available
- RHO - markers available
- SEMask - markers available

PDC Programming Commands
CALCulate Subsystem

- SPECTrum - markers available
- WAVEform - markers available

GSM (with EDGE) Mode - <measurement> key words

- EEVM - markers available
- EORFspectr - markers available
- EPVTime - no markers
- ETSPur - markers available
- ORFSpectrum - markers available
- PFERror - markers available
- PVTime - no markers
- SPECTrum - markers available
- TSPur - markers available
- TXPower - no markers
- WAVEform - markers available

NADC Mode - <measurement> key words

- ACP - no markers
- EVM - markers available
- SPECTrum - markers available
- WAVEform - markers available

PDC Mode - <measurement> key words

- ACP - no markers
- EVM - markers available
- OBW - no markers
- SPECTrum - markers available
- WAVEform - markers available

W-CDMA Mode - <measurement> key words

- ACP - no markers
- CDPower - markers available
- CHPower - no markers
- EVMQpsk - markers available
- IM - markers available
- MCPower - no markers
- OBW - no markers
- PStatistic - markers available
- RHO - markers available
- SEMask - markers available
- SPECTrum - markers available
- WAVEform - markers available

Example:

Suppose you are using the Spectrum measurement in your measurement personality. To position marker 2 at the maximum peak value of the trace that marker 2 is currently on, the command is:

```
:CALCulate:SPECTrum:MARKer2:MAXimum
```

You must make sure that the measurement is completed before trying to query the marker value. Use the MEASure or READ command before using the marker command. This forces the measurement to complete before allowing the next command to be executed.

Markers All Off on All Traces

```
:CALCulate:<measurement>:MARKer:AOFF
```

Turns off all markers on all the traces in the specified measurement.

Example: **CALC:SPEC:MARK:AOFF**

Remarks: The keyword for the current measurement must be specified in the command. (Some examples include: SPECTrum, WAVeform)

Front Panel

Access: **Marker, More, Marker All Off**

Marker Mode

```
:CALCulate:<measurement>:MARKer[1] | 2 | 3 | 4:MODE  
POSITION|DELTA
```

```
:CALCulate:<measurement>:MARKer[1] | 2 | 3 | 4:MODE?
```

Selects the type of marker to be a normal position-type marker or a delta marker. A specific measurement may not have both types of markers. For example, several measurements only have position markers.

The marker must have already been assigned to a trace. Use

```
:CALCulate:<measurement>:MARKer[1] | 2 | 3 | 4:TRACe
```

to assign a marker to a particular trace.

Example: **CALC:SPEC:MARK:MODE DELTA**

Remarks: For the delta mode only markers 1 and 2 are valid.

The keyword for the current measurement must be specified in the command. (Some examples include: SPECTrum, WAVeform)

PDC Programming Commands

CALCulate Subsystem

Front Panel

Access: **Marker, Marker [Delta]**

Marker Function Result

:CALCulate:<measurement>:MARKer[1]|2|3|4:FUNCTION:RESult?

Queries the result of the currently active marker function. The measurement must be completed before querying the marker. A particular measurement may not have all the types of markers available.

The marker must have already been assigned to a trace. Use

:CALCulate:<measurement>:MARKer[1]|2|3|4:TRACe to assign a marker to a particular trace.

Example: **CALC:SPEC:MARK:FUNC:RES?**

Remarks: The keyword for the current measurement must be specified in the command. (Some examples include: SPECTrum, WAVeform)

Front Panel

Access: **Marker, Marker Function**

Marker Peak (Maximum) Search

:CALCulate:<measurement>:MARKer[1]|2|3|4:MAXimum

Places the selected marker on the highest point on the trace that is assigned to that particular marker number.

The marker must have already been assigned to a trace. Use

:CALCulate:<measurement>:MARKer[1]|2|3|4:TRACe to assign a marker to a particular trace.

Example: **CALC:SPEC:MARK1:MAX**

Remarks: The keyword for the current measurement must be specified in the command. (Some examples include: SPECTrum, WAVeform)

Front Panel

Access: **Search**

Marker Peak (Minimum) Search

:CALCulate:<measurement>:MARKer[1] | 2 | 3 | 4:MINimum

Places the selected marker on the lowest point on the trace that is assigned to that particular marker number.

The marker must have already been assigned to a trace. Use

:CALCulate:<measurement>:MARKer[1] | 2 | 3 | 4:TRACe to assign a marker to a particular trace.

Example: **CALC:SPEC:MARK2 MIN**

Remarks: The keyword for the current measurement must be specified in the command. (Some examples include: SPECTrum, WAVeform)

Marker Mode

PSA Series (not for Spectrum Analysis or Phase Noise mode):

**:CALCulate:<measurement>:MARKer[1] | 2 | 3 | 4:MODE
POSition|DELTA**

ESA/PSA Series Phase Noise mode only:

**:CALCulate:<measurement>:MARKer[1] | 2 | 3 | 4:MODE
POSition|DELTA|RMSDegree|RMSRadian|RFM|RMSJitter|OFF**

:CALCulate:<measurement>:MARKer[1] | 2 | 3 | 4:MODE?

Selects the type of marker to be a normal position-type marker or a delta marker. A specific measurement may not have both types of markers. For example, several measurements only have position markers

The marker must have already been assigned to a trace. Use

:CALCulate:<measurement>:MARKer[1] | 2 | 3 | 4:TRACe to assign a marker to a particular trace.

Example: **CALC:SPEC:MARK:MODE DELTA**

Remarks: For the delta mode only markers 1 and 2 are valid.

The keyword for the current measurement must be specified in the command. (Some examples include: SPECTrum, WAVeform)

Front Panel

Access: **Marker, Marker [Delta]**

PDC Programming Commands

CALCulate Subsystem

Marker On/Off

`:CALCulate:<measurement>:MARKer[1]|2|3|4[:STATe] OFF|ON|0|1`

`:CALCulate:<measurement>:MARKer[1]|2|3|4[:STATe]?`

Turns the selected marker on or off.

The marker must have already been assigned to a trace. Use

`:CALCulate:<measurement>:MARKer[1]|2|3|4:TRACe` to assign a marker to a particular trace.

Example: `CALC:SPEC:MARK2: on`

Remarks: The keyword for the current measurement must be specified in the command. (Some examples include: SPECTrum, AREFERENCE, WAVeform)

The WAVeform measurement only has two markers available.

Front Panel

Access: **Marker, Select then Marker Normal or Marker On Off**

Marker to Trace

`:CALCulate:<measurement>:MARKer[1]|2|3|4:TRACe <trace_name>`

`:CALCulate:<measurement>:MARKer[1]|2|3|4:TRACe?`

Assigns the specified marker to the designated trace. Not all types of measurement data can have markers assigned to them.

Example: With the WAVeform measurement selected, a valid command is `CALC:SPEC:MARK2:TRACE rfenvelope`.

Range: The names of valid traces are dependent upon the selected measurement. See the following table for the available trace names. The trace name assignment is independent of the marker number.

Remarks: The keyword for the current measurement must be specified in the command. (Some examples include: SPECTrum, WAVeform)

Front Panel

Access: **Marker, Marker Trace**

Measurement	Available Traces	Markers Available?
ACP - adjacent channel power (Basic, cdmaOne, cdma2000, W-CDMA, NADC, PDC modes)	no traces $(n=0)^a$ for I/Q points	no markers

Measurement	Available Traces	Markers Available?
CDPower - code domain power (cdmaOne mode)	POWER ($n=2$) ^a TIMing ($n=3$) ^a PHASe ($n=4$) ^a ($n=0$) ^a for I/Q points	yes
CDPower - code domain power (cdma2000, W-CDMA modes)	CDPower ($n=2$) ^a EVM ($n=5$) ^a MERRor ($n=6$) ^a PERRor ($n=7$) ^a SPOWer ($n=9$) ^a CPOWer ($n=10$) ^a ($n=0$) ^a for I/Q points	yes
CHPower - channel power (Basic, cdmaOne, cdma2000, W-CDMA modes)	SPECTrum ($n=2$) ^a ($n=0$) ^a for I/Q points	no markers
CSPur - spurs close (cdmaOne mode)	SPECTrum ($n=2$) ^a ULIMit ($n=3$) ^a ($n=0$) ^a for I/Q points	yes
EEVM - EDGE error vector magnitude (EDGE mode)	EVMerror ($n=2$) ^a MERRor ($n=3$) ^a PERRor ($n=4$) ^a ($n=0$) ^a for I/Q points	yes
EORFspectr - EDGE output RF spectrum (EDGE mode)	RFEMod ($n=2$) ^a RFESwitching ($n=3$) ^a SPEMod ($n=4$) ^a LIMMod ($n=5$) ^a ($n=0$) ^a for I/Q points	yes, only for a single offset yes, only for multiple offsets

PDC Programming Commands
CALCulate Subsystem

Measurement	Available Traces	Markers Available?
EPVTime - EDGE power versus time (EDGE mode)	RFENvelope ($n=2$) ^a UMASk ($n=3$) ^a LMASk ($n=4$) ^a ($n=0$) ^a for I/Q points	yes
ETSPur - EDGE transmit band spurs (EDGE mode)	SPECtrum ($n=2$) ^a ULIMit ($n=3$) ^a ($n=0$) ^a for I/Q points	yes
EVM - error vector magnitude (NADC, PDC modes)	EVM ($n=2$) ^a MERRor ($n=3$) ^a PERRor ($n=4$) ^a ($n=0$) ^a for I/Q points	yes
EVMQpsk - QPSK error vector magnitude (cdma2000, W-CDMA modes)	EVM ($n=2$) ^a MERRor ($n=3$) ^a PERRor ($n=4$) ^a ($n=0$) ^a for I/Q points	yes
IM - intermodulation (cdma2000, W-CDMA modes)	SPECtrum ($n=2$) ^a ($n=0$) ^a for I/Q points	yes
MCPower - multi-carrier power (W-CDMA mode)	no traces ($n=0$) ^a for I/Q points	no markers
OBW - occupied bandwidth (cdmaOne, cdma2000, PDC, W-CDMA modes)	no traces ($n=0$) ^a for I/Q points	no markers
ORFSpectrum - output RF spectrum (GSM, EDGE mode)	RFEMod ($n=2$) ^a RFESwitching ($n=3$) ^a SPEMod ($n=4$) ^a LIMMod ($n=5$) ^a ($n=0$) ^a for I/Q points	yes, only for a single offset yes, only for multiple offsets

Measurement	Available Traces	Markers Available?
PFERror - phase and frequency error (GSM, EDGE mode)	PERRor ($n=2$) ^a PFERror ($n=3$) ^a RFENvelope ($n=4$) ^a ($n=0$) ^a for I/Q points	yes
PStatistic - power statistics CCDF (Basic, cdma2000, W-CDMA modes)	MEASured ($n=2$) ^a GAUSian ($n=3$) ^a REFerence ($n=4$) ^a ($n=0$) ^a for I/Q points	yes
PVTime - power versus time (GSM, EDGE modes)	RFENvelope ($n=2$) ^a UMASk ($n=3$) ^a LMASk ($n=4$) ^a ($n=0$) ^a for I/Q points	yes
RHO - modulation quality (cdmaOne, cdma2000, W-CDMA mode)	($n=0$) ^a for I/Q points EVM ($n=2$) ^a MERRor ($n=3$) ^a PERRor ($n=4$) ^a ($n=0$) ^a for I/Q points	yes
SEMAsk - spectrum emissions mask (cdma2000, W-CDMA mode)	SPECtrum ($n=2$) ^a ($n=0$) ^a for I/Q points	yes
TSPur - transmit band spurs (GSM, EDGE mode)	SPECtrum ($n=2$) ^a ULIMit ($n=3$) ^a ($n=0$) ^a for I/Q points	yes
TXPower - transmit power (GSM, EDGE mode)	RFENvelope ($n=2$) ^a IQ ($n=8$) ^a ($n=0$) ^a for I/Q points	yes

PDC Programming Commands

CALCulate Subsystem

Measurement	Available Traces	Markers Available?
SPECtrum - (frequency domain) (all modes)	IQ ($n=3$) ^a SPECtrum ($n=4$) ^a ASPECTrum ($n=7$) ^a ($n=0$) ^a for I/Q points	yes
WAVEform - (time domain) (all modes)	RFENvelope ($n=2$) ^a (also for Signal Envelope trace) IQ ($n=5$) ^a ($n=0$) ^a for I/Q points	yes

a. The n number indicates the sub-opcode that corresponds to this trace. Detailed descriptions of the trace data can be found in the MEASure subsystem documentation by looking up the sub-opcode for the appropriate measurement.

Marker X Value

```
:CALCulate:<measurement>:MARKer[1]|2|3|4:X <param>
```

```
:CALCulate:<measurement>:MARKer[1]|2|3|4:X?
```

Position the designated marker on its assigned trace at the specified X value. The parameter value is in X-axis units (which is often frequency or time).

The marker must have already been assigned to a trace. Use `:CALCulate:<measurement>:MARKer[1]|2|3|4:TRACe` to assign a marker to a particular trace.

The query returns the current X value of the designated marker. The measurement must be completed before querying the marker.

Example: `CALC:SPEC:MARK2:X 1.2e6 Hz`

Default Unit: Matches the units of the trace on which the marker is positioned

Remarks: The keyword for the current measurement must be specified in the command. (Some examples include: SPECtrum, WAVEform)

Front Panel

Access: **Marker, <active marker>, RPG**

Marker X Position

:CALCulate:<measurement>:MARKer[1] | 2 | 3 | 4:X:POSition
<integer>

:CALCulate:<measurement>:MARKer[1] | 2 | 3 | 4:X:POSition?

Position the designated marker on its assigned trace at the specified X position. A trace is composed of a variable number of measurement points. This number changes depending on the current measurement conditions. The current number of points must be identified before using this command to place the marker at a specific location.

The marker must have already been assigned to a trace. Use **:CALCulate:<measurement>:MARKer[1] | 2 | 3 | 4:TRACe** to assign a marker to a particular trace.

The query returns the current X position for the designated marker. The measurement must be completed before querying the marker.

Example: **CALC:SPEC:MARK:X:POS 500**

Range: 0 to a maximum of (3 to 920,000)

Remarks: The keyword for the current measurement must be specified in the command. (Some examples include: SPECTrum, WAVeform)

Front Panel

Access: **Marker, <active marker>, RPG**

Marker Readout Y Value

:CALCulate:<measurement>:MARKer[1] | 2 | 3 | 4:Y?

Readout the current Y value for the designated marker on its assigned trace. The value is in the Y-axis units for the trace (which is often dBm).

The marker must have already been assigned to a trace. Use **:CALCulate:<measurement>:MARKer[1] | 2 | 3 | 4:TRACe** to assign a marker to a particular trace.

The measurement must be completed before querying the marker.

Example: **CALC:SPEC:MARK1:Y?**

Default Unit: Matches the units of the trace on which the marker is positioned

Remarks: The keyword for the current measurement must be specified in the command. (Some examples include: SPECTrum, WAVeform)

Occupied Bandwidth—Frequency Band Limit

PDC, cdma2000, W-CDMA mode

:CALCulate:OBW:LIMit:FBLimit <freq>

:CALCulate:OBW:LIMit:FBLimit?

Set the frequency bandwidth limit in Hz.

Factory Preset: 32 kHz for PDC

1.48 MHz for cdma2000

5 MHz for W-CDMA

Range: 10 kHz to 60 kHz for PDC

10 kHz to 10 MHz for cdma2000, W-CDMA

Default Unit: Hz

Remarks: You must be in the PDC, cdma2000, or W-CDMA mode to use this command. Use INSTRument:SElect to set the mode.

Occupied Bandwidth—Limit Test

PDC, cdma2000, W-CDMA mode

:CALCulate:OBW:LIMit[:TEST] OFF|ON|0|1

:CALCulate:OBW:LIMit[:TEST]?

Turn limit testing on or off.

Factory Preset: On

Remarks: You must be in the PDC, cdma2000, or W-CDMA mode to use this command. Use INSTRument:SElect to set the mode.

CONFigure Subsystem

The CONFigure commands are used with several other commands to control the measurement process. The full set of commands are described in the section “[MEASure Group of Commands](#)” on page 331.

Selecting measurements with the CONFigure/FETCh/MEASure/READ commands sets the instrument state to the defaults for that measurement and to make a single measurement. Other commands are available for each measurement to allow you to change: settings, view, limits, etc. Refer to:

```
SENSe:<measurement>, SENSe:CHANnel, SENSe:CORRection,  
SENSe:DEFaults, SENSe:DEViation, SENSe:FREQuency,  
SENSe:PACKet, SENSe:POWer, SENSe:RADio, SENSe:SYNC  
CALCulate:<measurement>, CALCulate:CLIMits  
DISPlay:<measurement>  
TRIGger
```

The INITiate[:IMMediate] or INITiate:REStart commands will initiate the taking of measurement data without resetting any of the measurement settings that you have changed from their defaults.

Configure the Selected Measurement

```
:CONFigure:<measurement>
```

A CONFigure command must specify the desired measurement. It will set the instrument settings for that measurements standard defaults, but should not initiate the taking of data. The available measurements are described in the MEASure subsystem.

NOTE

If CONFigure initiates the the taking of data, the data should be ignored. Other SCPI commands can be processed immediately after sending CONFigure. You do not need to wait for the CONF command to complete this 'false' data acquisition.

Configure Query

```
:CONFigure?
```

The CONFigure query returns the name of the current measurement.

DISPlay Subsystem

The DISPlay controls the selection and presentation of textual, graphical, and TRACe information. Within a DISPlay, information may be separated into individual WINDows.

Adjacent Channel Power - View Selection

```
:DISPlay:ACP:VIEW BGRaph|SPECTrum
```

```
:DISPlay:ACP:VIEW?
```

Select the adjacent channel power measurement display of bar graph or spectrum.

You may want to disable the spectrum trace data part of the measurement so you can increase the speed of the rest of the measurement display. Use SENSE:ACP:SPECTrum:ENABLE to turn on or off the spectrum trace. (Basic and cdmaOne modes only)

Factory Preset: Bar Graph (BGRaph)

Remarks: You must be in the cdmaOne, cdma2000, W-CDMA (3GPP), NADC or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Front Panel

Access: **ACP, View/Trace**

Error Vector Magnitude - View Selection

```
:DISPlay:EVMagnitude:VIEW POLar|CONStln|QUAD
```

```
:DISPlay:EVMagnitude:VIEW?
```

Select the view of EVM measurement

Factory Preset: POLar

Remarks: You must be in the NADC or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Select Display Format

:DISPlay:FORMat:TILE

Selects the viewing format that displays multiple windows of the current measurement data simultaneously. Use DISP:FORM:ZOOM to return the display to a single window.

Remarks: You must be in the Basic, cdmaOne,cdma2000, W-CDMA, GSM (w/EDGE), NADC, or PDC mode to use this command. Use INSTRUMENT:SElect to set the mode

Front Panel

Access: **Zoom** (toggles between Tile and Zoom)

Select Display Format

:DISPlay:FORMat:ZOOM

Selects the viewing format that displays only one window of the current measurement data (the current active window). Use DISP:FORM:TILE to return the display to multiple windows.

Remarks: You must be in the Basic, cdmaOne,cdma2000, W-CDMA, GSM (w/EDGE), NADC, or PDC mode to use this command. Use INSTRUMENT:SElect to set the mode

Front Panel

Access: **Zoom** (toggles between Tile and Zoom)

Spectrum - Y-Axis Scale/Div

:DISPlay:SPECTrum[n]:WINDow[m]:TRACe:Y[:SCALE]:PDIVision
<power>

:DISPlay:SPECTrum[n]:WINDow[m]:TRACe:Y[:SCALE]:PDIVision?

Sets the amplitude reference level for the y-axis.

n – selects the view, the default is Spectrum.

m – selects the window within the view. The default is 1.

— n=1, m=1 Spectrum

— n=1, m=2 I/Q Waveform

— n=1, m=2 I and Q Waveform (Basic, W-CDMA, cdma2000)

— n=3, m=1 I/Q Polar (Basic, W-CDMA, cdma2000)

PDC Programming Commands
DISPlay Subsystem

— n=4, m=1 Linear Spectrum (Basic, W-CDMA, cdma2000)

Factory Preset: 10 dB per division, for Spectrum

100 mV per division, for I/Q Waveform

Range: 0.1 dB to 20 dB per division, for Spectrum

1 nV to 20 V per division, for I/Q Waveform

Default Unit: 10 dB per division, for Spectrum

Remarks: May affect input attenuator setting.

You must be in Basic, cdmaOne, cdma2000, W-CDMA GSM w/EDGE, NADC, or PDC mode. Set the mode with INSTRument:SElect.

Front Panel

Access: When in Spectrum measurement: **Amplitude Y Scale, Scale/Div.**

History: Added revision A.02.00

Spectrum - Y-Axis Reference Level

```
:DISPlay:SPECTrum[n]:WINDow[m]:TRACe:Y[:SCALE]:RLEVel
<power>
```

```
:DISPlay:SPECTrum[n]:WINDow[m]:TRACe:Y[:SCALE]:RLEVel?
```

Sets the amplitude reference level for the y-axis.

n, selects the view, the default is RF envelope.

— n=1, m=1 Spectrum

— n=1, m=2 I/Q Waveform

— n=1, m=2 I and Q Waveform (Basic, W-CDMA, cdma2000)

— n=3, m=1 I/Q Polar (Basic, W-CDMA, cdma2000)

— n=4, m=1 Linear Spectrum (Basic, W-CDMA, cdma2000)

m – selects the window within the view. The default is 1.

Factory Preset: 0 dBm, for Spectrum

Range: –250 to 250 dBm, for Spectrum

Default Unit: dBm, for Spectrum

Remarks: May affect input attenuator setting.

You must be in Basic, cdmaOne, cdma2000, W-CDMA GSM w/EDGE, NADC, or PDC mode. Set the mode with INSTRument:SElect.

Front Panel
Access: When in Spectrum measurement: **Amplitude Y Scale, Ref Level**

History: Added revision A.02.00

Turn a Trace Display On/Off

`:DISPlay:TRACe[n][:STATe] OFF|ON|0|1`

`:DISPlay:TRACe[n][:STATe]?`

Controls whether the specified trace is visible or not.

n is a sub-opcode that is valid for the current measurement. See the [“MEASure Group of Commands” on page 331](#) for more information about sub-opcodes.

Factory Preset: On

Range: The valid traces and their sub-opcodes are dependent upon the selected measurement. See the following table.

The trace name assignment is independent of the window number.

Remarks: You must be in the Basic, cdmaOne,cdma2000, W-CDMA, GSM (w/EDGE), NADC, or PDC mode to use this command. Use INSTRument:SElect to set the mode

Front Panel
Access: **Display, Display Traces**

Measurement	Available Traces	Markers Available?
ACP - adjacent channel power (Basic, cdmaOne, cdma2000, W-CDMA, NADC, PDC modes)	no traces $(n=0)^a$ for I/Q points	no markers
CDPower - code domain power (cdmaOne mode)	POWer $(n=2)^a$ TIMing $(n=3)^a$ PHASe $(n=4)^a$ $(n=0)^a$ for I/Q points	yes

PDC Programming Commands
DISPlay Subsystem

Measurement	Available Traces	Markers Available?
CDPower - code domain power (cdma2000, W-CDMA modes)	CDPower ($n=2$) ^a EVM ($n=5$) ^a MERRor ($n=6$) ^a PERRor ($n=7$) ^a SPOWer ($n=9$) ^a CPOWer ($n=10$) ^a ($n=0$) ^a for I/Q points	yes
CHPower - channel power (Basic, cdmaOne, cdma2000, W-CDMA modes)	SPECtrum ($n=2$) ^a ($n=0$) ^a for I/Q points	no markers
CSPur - spurs close (cdmaOne mode)	SPECtrum ($n=2$) ^a ULIMit ($n=3$) ^a ($n=0$) ^a for I/Q points	yes
EEVM - EDGE error vector magnitude (EDGE mode)	EVMerror ($n=2$) ^a MERRor ($n=3$) ^a PERRor ($n=4$) ^a ($n=0$) ^a for I/Q points	yes
EORFspectr - EDGE output RF spectrum (EDGE mode)	RFEMod ($n=2$) ^a RFESwitching ($n=3$) ^a SPEMod ($n=4$) ^a LIMMod ($n=5$) ^a ($n=0$) ^a for I/Q points	yes, only for a single offset yes, only for multiple offsets
EPVTime - EDGE power versus time (EDGE mode)	RFENvelope ($n=2$) ^a UMASk ($n=3$) ^a LMASk ($n=4$) ^a ($n=0$) ^a for I/Q points	yes
ETSPur - EDGE transmit band spurs (EDGE mode)	SPECtrum ($n=2$) ^a ULIMit ($n=3$) ^a ($n=0$) ^a for I/Q points	yes

Measurement	Available Traces	Markers Available?
EVM - error vector magnitude (NADC, PDC modes)	EVM ($n=2$) ^a MERRor ($n=3$) ^a PERRor ($n=4$) ^a ($n=0$) ^a for I/Q points	yes
EVMQpsk - QPSK error vector magnitude (cdma2000, W-CDMA modes)	EVM ($n=2$) ^a MERRor ($n=3$) ^a PERRor ($n=4$) ^a ($n=0$) ^a for I/Q points	yes
IM - intermodulation (cdma2000, W-CDMA modes)	SPECtrum ($n=2$) ^a ($n=0$) ^a for I/Q points	yes
MCPower - multi-carrier power (W-CDMA mode)	no traces ($n=0$) ^a for I/Q points	no markers
OBW - occupied bandwidth (cdmaOne, cdma2000, PDC, W-CDMA modes)	no traces ($n=0$) ^a for I/Q points	no markers
ORFSpectrum - output RF spectrum (GSM, EDGE mode)	RFEMod ($n=2$) ^a RFESwitching ($n=3$) ^a SPEMod ($n=4$) ^a LIMMod ($n=5$) ^a ($n=0$) ^a for I/Q points	yes, only for a single offset yes, only for multiple offsets
PFERror - phase and frequency error (GSM, EDGE mode)	PERRor ($n=2$) ^a PFERror ($n=3$) ^a RFENvelope ($n=4$) ^a ($n=0$) ^a for I/Q points	yes
PStatistic - power statistics CCDF (Basic, cdma2000, W-CDMA modes)	MEASured ($n=2$) ^a GAUSian ($n=3$) ^a REFerence ($n=4$) ^a ($n=0$) ^a for I/Q points	yes

PDC Programming Commands
DISPlay Subsystem

Measurement	Available Traces	Markers Available?
PVTime - power versus time (GSM, EDGE modes)	RFENvelope ($n=2$) ^a UMASk ($n=3$) ^a LMASk ($n=4$) ^a ($n=0$) ^a for I/Q points	yes
RHO - modulation quality (cdmaOne, cdma2000, W-CDMA mode)	($n=0$) ^a for I/Q points EVM ($n=2$) ^a MERRor ($n=3$) ^a PERRor ($n=4$) ^a ($n=0$) ^a for I/Q points	yes
SEMask - spectrum emissions mask (cdma2000, W-CDMA mode)	SPECtrum ($n=2$) ^a ($n=0$) ^a for I/Q points	yes
TSPur - transmit band spurs (GSM, EDGE mode)	SPECtrum ($n=2$) ^a ULIMit ($n=3$) ^a ($n=0$) ^a for I/Q points	yes
TXPower - transmit power (GSM, EDGE mode)	RFENvelope ($n=2$) ^a IQ ($n=8$) ^a ($n=0$) ^a for I/Q points	yes
SPECtrum - (frequency domain) (all modes)	IQ ($n=3$) ^a SPECtrum ($n=4$) ^a ASpectrum ($n=7$) ^a ($n=0$) ^a for I/Q points	yes
WAVEform - (time domain) (all modes)	RFENvelope ($n=2$) ^a (also for Signal Envelope trace) IQ ($n=5$) ^a ($n=0$) ^a for I/Q points	yes

a. The n number indicates the sub-opcode that corresponds to this trace. Detailed descriptions of the trace data can be found in the MEASure subsystem documentation by looking up the sub-opcode for the appropriate measurement.

Waveform - Y-Axis Scale/Div

`:DISPlay:WAVEform[n]:WINDow[m]:TRACe:Y[:SCALe]:PDIVision`
`<power>`

`:DISPlay:WAVEform[n]:WINDow[m]:TRACe:Y[:SCALe]:PDIVision?`

Sets the scale per division for the y-axis.

n, selects the view, the default is RF envelope.

n=1, m=1 RF envelope

n=2, m=1 I/Q Waveform

n=4, m=1 I/Q Polar (Basic, W-CDMA, cdma2000)

m, selects the window within the view. The default is 1.

Factory Preset: 10 dBm, for RF envelope

Range: .1 dB to 20 dB, for RF envelope

Default Unit: dBm, for RF envelope

Remarks: May affect input attenuator setting.

You must be in Basic, cdmaOne, cdma2000, W-CDMA
 GSM w/EDGE, NADC, or PDC mode. Set the mode
 with INSTRument:SElect.

Front Panel

Access: When in Waveform measurement: **Amplitude Y Scale,
 Scale/Div.**

History: Added revision A.02.00

Waveform - Y-Axis Reference Level

`:DISPlay:WAVEform[n]:WINDow[m]:TRACe:Y[:SCALe]:RLEVEL`
`<power>`

`:DISPlay:WAVEform[n]:WINDow[m]:TRACe:Y[:SCALe]:RLEVEL?`

Sets the amplitude reference level for the y-axis.

n, selects the view, the default is RF envelope.

n=1, m=1 RF envelope

n=2, m=1 I/Q Waveform

n=4, m=1 I/Q Polar (Basic, W-CDMA, cdma2000)

m, selects the window within the view. The default is 1.

Factory Preset: 0 dBm, for RF envelope

PDC Programming Commands
DISPlay Subsystem

Range: -250 to 250 dBm, for RF envelope

Default Unit: dBm, for RF envelope

Remarks: May affect input attenuator setting.

You must be in Basic, cdmaOne, cdma2000, W-CDMA
GSM w/EDGE, NADC, or PDC mode. Set the mode
with INSTRument:SElect.

Front Panel

Access: When in Waveform measurement: **Amplitude Y Scale,
Ref Level**

History: Added revision A.02.00

FETCh Subsystem

The FETCh? queries are used with several other commands to control the measurement process. These commands are described in the section on the “[MEASure Group of Commands](#)” on page 331. These commands apply only to measurements found in the MEASURE menu.

This command puts selected data from the most recent measurement into the output buffer (new data is initiated/measured). Use FETCh if you have already made a good measurement and you want to look at several types of data (different [n] values) from the single measurement. FETCh saves you the time of re-making the measurement. You can only fetch results from the measurement that is currently active.

If you need to make a new measurement, use the READ command, which is equivalent to an INITiate[:IMMediate] followed by a FETCh.

:FETCh <meas>? will return valid data only when the measurement is in one of the following states:

- idle
- initiated
- paused

Fetch the Current Measurement Results

:FETCh:<measurement>[n]?

A FETCh? command must specify the desired measurement. It will return the valid results that are currently available, but will not initiate the taking of any new data. You can only fetch results from the measurement that is currently selected. The code number n selects the kind of results that will be returned. The available measurements and data results are described in the “[MEASure Group of Commands](#)” on page 331.

FORMat Subsystem

The FORMat subsystem sets a data format for transferring numeric and array information. The TRACe[:DATA] command is affected by FORMat subsystem commands.

Byte Order

`:FORMat:BORDER NORMAL | SWAPped`

`:FORMat:BORDER?`

Selects the binary data byte order for numeric data transfer. In normal mode the most significant byte is sent first. In swapped mode the least significant byte is first. (PCs use the swapped order.) Binary data byte order functionality does not apply to ASCII.

Factory Preset: Normal

Numeric Data format

`:FORMat[:DATA] ASCii | REAL,32 | REAL,64`

`:FORMat[:DATA]?`

For PSA Spectrum Analysis mode only:

`:FORMat[:TRACe][:DATA]`

`ASCii | INTEger,16 | INTEger,32 | REAL,32 | REAL,64 | UNINTEger,16`

`:FORMat[:TRACe][:DATA]?`

This command controls the format of data output, that is, data transfer across any remote port. The REAL and ASCII formats will format trace data in the current amplitude units.

The format of state data cannot be changed. It is always in a machine readable format only.

ASCII - Amplitude values are in ASCII, in amplitude units, separated by commas. ASCII format requires more memory than the binary formats. Therefore, handling large amounts of this type of data, will take more time and storage space.

Integer,16 - Binary 16-bit integer values in internal units (dBm), in a definite length block. **PSA, SA mode only.

Integer,32 - Binary 32-bit integer values in internal units (dBm), in a definite length block.

Real,32 (or 64) - Binary 32-bit (or 64-bit) real values in amplitude unit, in a definite length block. Transfers of real data are done in a binary block format.

UINTegeR,16 - Binary 16-bit unsigned integer that is uncorrected ADC values, in a definite length block. This format is almost never applicable with current data.

A definite length block of data starts with an ASCII header that begins with # and indicates how many additional data points are following in the block. Suppose the header is #512320.

- The first digit in the header (5) tells you how many additional digits/bytes there are in the header.
- The 12320 means 12 thousand, 3 hundred, 20 data bytes follow the header.
- Divide this number of bytes by your selected data format bytes/point, either 8 (for real 64), or 4 (for real 32). In this example, if you are using real 64 then there are 1540 points in the block.

Example: `FORM REAL,64`

Factory Preset: Real,32 for Spectrum Analysis mode

ASCII for Basic, cdmaOne, cdma2000, W-CDMA, GSM with EDGE, NADC, PDC modes

Remarks: The acceptable settings for this command changes for different modes.

INITiate Subsystem

The INITiate subsystem is used to initiate a trigger for a measurement. They only initiate measurements from the MEASURE front panel key or the “MEASURE Group of Commands” on page 331. Refer to the TRIGGER and ABORT subsystems for related commands.

Take New Data Acquisition for Selected Measurement

```
:INITiate:<measurement_name>
```

This command initiates a trigger cycle for the measurement specified. The available measurement names are described in the MEASURE subsystem. It also holds off additional commands on GPIB until the acquisition is complete. So if it is followed by a FETCH command, valid data will be returned.

If your selected measurement is currently active (in the idle state) it triggers the measurement, assuming the trigger conditions are met. Then it completes one trigger cycle. Depending upon the measurement and the number of averages, there may be multiple data acquisitions, with multiple trigger events, for one full trigger cycle.

If your selected measurement is not currently active it will change to the measurement in your INIT:<meas_name> command and initiate a trigger cycle.

Example: INIT:ACP

Continuous or Single Measurements

```
:INITiate:CONTinuous OFF|ON|0|1
```

```
:INITiate:CONTinuous?
```

Selects whether a trigger is continuously initiated or not. Each trigger initiates a single, complete, measurement operation.

When set to ON another trigger cycle is initiated at the completion of each measurement.

When set to OFF, the trigger system remains in the “idle” state until an INITiate[:IMMEDIATE] command is received. On receiving the INITiate[:IMMEDIATE] command, it will go through a single trigger/measurement cycle, and then return to the “idle” state.

Example: INIT:CONT ON

Factory Preset: On

*RST: Off (recommended for remote operation)

Front Panel
Access: **Meas Control, Measure Cont Single**

Take New Data Acquisitions

:INITiate[:IMMEDIATE]

The instrument must be in the single measurement mode. If INIT:CONT is ON, then the command is ignored. The desired measurement must be selected and waiting. The command causes the system to exit the “waiting” state and go to the “initiated” state.

The trigger system is initiated and completes one full trigger cycle. It returns to the “waiting” state on completion of the trigger cycle. Depending upon the measurement and the number of averages, there may be multiple data acquisitions, with multiple trigger events, for one full trigger cycle.

This command triggers the instrument, if external triggering is the type of trigger event selected. Otherwise, the command is ignored. Use the TRIGger[:SEquence]:SOURce EXT command to select the external trigger.

Example: INIT:IMM

Remarks: See also the *TRG command and the TRIGger subsystem.

Front Panel
Access: **Meas Control, Measure Cont Single**

Restart the Measurement

:INITiate:REStart

This command applies to measurements found in the MEASURE menu. It restarts the current measurement from the “idle” state regardless of its current operating state. It is equivalent to:

INITiate[:IMMEDIATE]

ABORt (for continuous measurement mode)

Example: INIT:REST

Front Panel
Access: **Restart**

or

Meas Control, Restart

INSTrument Subsystem

This subsystem includes commands for querying and selecting instrument measurement (personality option) modes.

Catalog Query

`:INSTrument:CATalog?`

Returns a comma separated list of strings which contains the names of all the installed applications. These names can only be used with the `INST:SELECT` command.

Example: `INST:CAT?`

Query response: `"CDMA"4,"PNOISE"14`

Select Application by Number

`:INSTrument:NSElect <integer>`

`:INSTrument:NSElect?`

Select the measurement mode by its instrument number. The actual available choices depends upon which applications are installed in the instrument.

- 1 = SA
- 4 = CDMA (cdmaOne)
- 5 = NADC
- 6 = PDC
- 8 = BASIC
- 9 = WCDMA (3GPP)
- 10 = CDMA2K (cdma2000)
- 13 = EDGE GSM
- 14 = PNOISE (phase noise)

NOTE

If you are using the SCPI status registers and the analyzer mode is changed, the status bits should be read, and any errors resolved, prior to switching modes. Error conditions that exist prior to switching modes cannot be detected using the condition registers after the mode change. This is true unless they recur after the mode change, although transitions of these conditions can be detected using the event registers.

Changing modes resets all SCPI status registers and mask registers to their power-on defaults. Hence, any event or condition register masks must be re-established after a mode change. Also note that the power up status bit is set by any mode change, since that is the default state after power up.

Example: INST:NSEL 4

Factory Preset: Persistent state with factory default of 1

Range: 1 to x, where x depends upon which applications are installed.

Front Panel

Access: **Mode**

Select Application

PSA Series:

```
:INSTrument[:SElect]
SA|PNOISE|BASIC|CDMA|CDMA2K|EDGEgSM|NADC|PDC|WCDMA
```

```
:INSTrument[:SElect]?
```

Select the measurement mode. The actual available choices depend upon which modes (measurement applications) are installed in the instrument. A list of the valid choices is returned with the INST:CAT? query.

Once an instrument mode is selected, only the commands that are valid for that mode can be executed.

- 1 = SA
- 4 = CDMA (cdmaOne)
- 5 = NADC
- 6 = PDC
- 8 = BASIC
- 9 = WCDMA (3GPP)
- 10 = CDMA2K (cdma2000)
- 13 = EDGEgSM
- 14 = PNOISE (phase noise)

NOTE

If you are using the status bits and the analyzer mode is changed, the status bits should be read, and any errors resolved, prior to switching modes. Error conditions that exist prior to switching modes cannot be detected using the condition registers after the mode change. This is true unless they recur after the mode change, although transitions of these conditions can be detected using the event registers.

Changing modes resets all SCPI status registers and mask registers to their power-on defaults. Hence, any event or condition register masks must be re-established after a mode change. Also note that the power up status bit is set by any mode change, since that is the default state after power up.

Example: ESA Series instruments: INST:SEL 'CDMA'

Example: PSA Series instruments: INST:SEL CDMA

Factory Preset: Persistent state with factory default of Spectrum Analyzer mode

Front Panel

Access: **Mode**

MEASure Group of Commands

This group includes the CONFigure, FETCh, MEASure, and READ commands that are used to make measurements and return results. The different commands can be used to provide fine control of the overall measurement process, like changing measurement parameters from their default settings. Most measurements should be done in single measurement mode, rather than measuring continuously.

The SCPI default for the format of any data output is ASCII. The format can be changed to binary with FORMat:DATA which transports faster over the bus.

CONFigure, FETCh, MEASure, READ Interactions

These commands are all inter-related. See [Figure 8-3 on page 332](#).

Measure Commands

:MEASure: <measurement>[n]?

This is a fast single-command way to make a measurement using the factory default instrument settings. These are the settings and units that conform to the Mode Setup settings (e.g. radio standard) that you have currently selected.

- Stops the current measurement (if any) and sets up the instrument for the specified measurement using the factory defaults
- Initiates the data acquisition for the measurement
- Blocks other SCPI communication, waiting until the measurement is complete before returning results.
- After the data is valid it returns the scalar results, or the trace data, for the specified measurement. The type of data returned may be defined by an [n] value that is sent with the command.

The scalar measurement results will be returned if the optional [n] value is not included, or is set to 1. If the [n] value is set to a value other than 1, the selected trace data results will be returned. See each command for details of what types of scalar results or trace data results are available.


ASCII is the default format for the data output. The binary data formats should be used for handling large blocks of data since they are smaller and faster than the ASCII format. Refer to the FORMat:DATA command for more information.

If you need to change some of the measurement parameters from the factory default settings you can set up the measurement with the CONFigure command. Use the commands in the SENSE:<measurement> and CALCulate:<measurement> subsystems to change the settings. Then you can use the READ? command to initiate the measurement and query the results. See [Figure 8-3](#).

If you need to repeatedly make a given measurement with settings other than the factory defaults, you can use the commands in the SENSE:<measurement> and CALCulate:<measurement> subsystems to set up the measurement. Then use the READ? command to initiate the measurement and query results.

Measurement settings persist if you initiate a different measurement and then return to a previous one. Use READ:<measurement>? if you want to use those persistent settings. If you want to go back to the default settings, use MEASure:<measurement>?.

Figure 8-3 Measurement Group of Commands



ca81a

Configure Commands

:CONFigure:<measurement>

This command stops the current measurement (if any) and sets up the instrument for the specified measurement using the factory default instrument settings. It sets the instrument to single measurement mode but should not initiate the taking of measurement data unless INIT:CONTinuous is ON. After you change any measurement settings, the READ command can be used to initiate a measurement without changing the settings back to their defaults.

The CONFigure? query returns the current measurement name.

Fetch Commands

:FETCh: <measurement> [n]?

This command puts selected data from the most recent measurement into the output buffer. Use FETCh if you have already made a good measurement and you want to return several types of data (different [n] values, e.g. both scalars and trace data) from a single measurement. FETCh saves you the time of re-making the measurement. You can only FETCh results from the measurement that is currently active, it will not change to a different measurement.

If you need to get new measurement data, use the READ command, which is equivalent to an INITiate followed by a FETCh.

The scalar measurement results will be returned if the optional [n] value is not included, or is set to 1. If the [n] value is set to a value other than 1, the selected trace data results will be returned. See each command for details of what types of scalar results or trace data results are available. The binary data formats should be used for handling large blocks of data since they are smaller and transfer faster than the ASCII format. (FORMat:DATA)

FETCh may be used to return results other than those specified with the original READ or MEASure command that you sent.

Read Commands

:READ: <measurement> [n]?

- Does not preset the measurement to the factory default settings. For example, if you have previously initiated the ACP measurement and you send READ:ACP? it will initiate a new measurement using the same instrument settings.
- Initiates the measurement and puts valid data into the output buffer. If a measurement other than the current one is specified, the instrument will switch to that measurement before it initiates the measurement and returns results.

For example, suppose you have previously initiated the ACP measurement, but now you are running the channel power measurement. Then you send READ:ACP? It will change from channel power back to ACP and, using the previous ACP settings, will initiate the measurement and return results.

- Blocks other SCPI communication, waiting until the measurement is complete before returning the results

If the optional [n] value is not included, or is set to 1, the scalar measurement results will be returned. If the [n] value is set to a value other than 1, the selected trace data results will be returned. See each command for details of what types of scalar results or trace data results are available. The binary data formats should be used when handling large blocks of data since they are smaller and faster than the ASCII format. (FORMat:DATA)

Adjacent Channel Power Ratio (ACP) Measurement

This measures the total rms power in the specified channel and in 5 offset channels. You must be in cdmaOne, cdma2000, W-CDMA (3GPP), NADC or PDC mode to use these commands. Use INSTRument:SElect to set the mode.

The general functionality of CONFigure, FETCh, MEASure, and READ are described at the beginning of this section. See the SENSE:ACP commands for more measurement related commands.

:CONFigure:ACP

:FETCh:ACP[n]?

:READ:ACP[n]?

:MEASure:ACP[n]?

For Basic mode, a channel frequency and power level can be defined in the command statement to override the default standard setting. A comma must precede the power value as a place holder for the frequency, when no frequency is sent.

Front Panel

Access: **Measure, ACPor ACPR**

After the measurement is selected, press **Restore Meas Defaults** to restore factory defaults.

Measurement Results Available

Measurement Type	n	Results Returned
	0	Returns unprocessed I/Q trace data, as a series of comma-separated trace points, in volts. The I values are listed first in each pair, using the 0 through even-indexed values. The Q values are the odd-indexed values.
	not specified or n=1 NADC and PDC mode	Returns 22 comma-separated scalar results, in the following order: <ol style="list-style-type: none"> 1. Center frequency – absolute power (dBm) 2. Center frequency – absolute power (W) 3. Negative offset frequency (1) – relative power (dB) 4. Negative offset frequency (1) – absolute power (dBm) 5. Positive offset frequency (1) – relative power (dB) 6. Positive offset frequency (1) – absolute power (dBm) <p style="text-align: center;">. . .</p> <ol style="list-style-type: none"> 21. Positive offset frequency (5) – relative power (dB) 22. Positive offset frequency (5) – absolute power (dBm)

Measurement Type	n	Results Returned
Total power reference	not specified or n=1 Basic, cdmaOne, cdma2000, W-CDMA (3GPP) mode	Returns 24 comma-separated scalar results, in the following order: <ol style="list-style-type: none"> 1. Upper adjacent chan center frequency - relative power (dB) 2. Upper adjacent chan center frequency - absolute power (dBm) 3. Lower adjacent chan center frequency - relative power (dB) (same as upper) 4. Lower adjacent chan center frequency - absolute power (dBm) (same as upper) 5. Negative offset frequency (1) - relative power (dB), 6. Negative offset frequency (1) - absolute power (dBm) 7. Positive offset frequency (1) - relative power (dB) 8. Positive offset frequency (1) - absolute power (dBm) <p style="text-align: center;">. . .</p> <ol style="list-style-type: none"> 23. Positive offset frequency (5) - relative power (dB) 24. Positive offset frequency (5) - absolute power (dBm)
Power spectral density reference	not specified or n=1 Basic, cdmaOne, cdma2000, W-CDMA (3GPP) mode	Returns 24 comma-separated scalar results, in the following order: <ol style="list-style-type: none"> 1. Upper adjacent chan center frequency - relative power (dB) 2. Upper adjacent chan center frequency - absolute power (dBm/Hz) 3. Lower adjacent chan center frequency - relative power (dB) (same as upper) 4. Lower adjacent chan center frequency - absolute power (dBm/Hz) (same as upper) 5. Negative offset frequency (1) - relative power (dB) 6. Negative offset frequency (1) - absolute power (dBm/Hz) 7. Positive offset frequency (1) - relative power (dB) 8. Positive offset frequency (1) - absolute power (dBm/Hz) <p style="text-align: center;">. . .</p> <ol style="list-style-type: none"> 23. Positive offset frequency (5) - relative power (dB) 24. Positive offset frequency (5) - absolute power (dBm/Hz)
	2 NADC and PDC mode	Returns 10 comma-separated scalar values of the pass/fail (0=passed, or 1=failed) results determined by testing the absolute power of the offset frequencies: <ol style="list-style-type: none"> 1. Negative offset frequency (1) absolute power 2. Positive offset frequency (1) absolute power <p style="text-align: center;">. . .</p> <ol style="list-style-type: none"> 9. Negative offset frequency (5) absolute power 10. Positive offset frequency (5) absolute power

Measurement Type	n	Results Returned
Total power reference	2 Basic, cdmaOne, cdma2000, W-CDMA (3GPP) mode	Returns 11 comma-separated scalar values (in dBm) corresponding to the total power histogram display. The values are returned in ascending frequency order: 1. Negative offset frequency (5) 2. Negative offset frequency (4) . . . 6. Center frequency 7. Positive offset frequency (1) . . . 11. Positive offset frequency (5)
	3 NADC and PDC mode	Returns 10 comma-separated scalar values of the pass/fail (0=passed, or 1=failed) results determined by testing the relative power of the offset frequencies: 1. Negative offset frequency (1) relative power 2. Positive offset frequency (1) relative power . . . 9. Negative offset frequency (5) relative power 10. Positive offset frequency (5) relative power
Power spectral density reference	3 Basic, cdmaOne, cdma2000, W-CDMA (3GPP) mode	Returns 11 comma-separated scalar values (in dBm/Hz) corresponding to the power spectral density histogram display. The values are returned in ascending frequency order: 1. Negative offset frequency (5) 2. Negative offset frequency (4) . . . 6. Center frequency 7. Positive offset frequency (1) . . . 11. Positive offset frequency (5)
	4 NADC and PDC mode	Returns the frequency-domain spectrum trace (data array) for the entire frequency range being measured. In order to return spectrum data, the ACP display must be in the spectrum view and you must not turn off the spectrum trace.

Measurement Type	n	Results Returned
(For cdma2000 and W-CDMA the data is only available with spectrum display selected)	4 Basic, cdmaOne, cdma2000, W-CDMA (3GPP) mode	<p>Returns the frequency-domain spectrum trace data for the entire frequency range being measured.</p> <p>With the spectrum view selected (DISPlay:ACP:VIEW SPECTrum) and the spectrum trace on (SENSE:ACP:SPECTrum:ENABLE):</p> <ul style="list-style-type: none"> In FFT mode (SENSE:ACP:SWEep:TYPE FFT) the number of trace points returned are 343 (cdma2000) or 1715 (W-CDMA). This is with the default span of 5 MHz (cdma2000) or 25 MHz (W-CDMA). The number of points also varies if another offset frequency is set. In sweep mode (SENSE:ACP:SWEep:TYPE SWEep), the number of trace points returned is 601 (for cdma2000 or W-CDMA) for any span. <p>With bar graph display selected, one point of -999.0 will be returned.</p>
Total power reference	5 Basic, cdmaOne, cdma2000, W-CDMA (3GPP) mode	<p>Returns 12 comma-separated scalar values (in dBm) of the absolute power of the center and the offset frequencies:</p> <ol style="list-style-type: none"> Upper adjacent chan center frequency Lower adjacent chan center frequency Negative offset frequency (1) Positive offset frequency (1) ... Negative offset frequency (5) Positive offset frequency (5)
Power spectral density reference	5 Basic, cdmaOne, cdma2000, W-CDMA (3GPP) mode	<p>Returns 12 comma-separated scalar values (in dBm/Hz) of the absolute power of the center and the offset frequencies:</p> <ol style="list-style-type: none"> Upper adjacent chan center frequency Lower adjacent chan center frequency Negative offset frequency (1) Positive offset frequency (1) ... Negative offset frequency (5) Positive offset frequency (5)

Measurement Type	n	Results Returned
Total power reference	6 Basic, cdmaOne, cdma2000, W-CDMA (3GPP) mode	Returns 12 comma-separated scalar values (total power in dB) of the power relative to the carrier at the center and the offset frequencies: <ol style="list-style-type: none"> 1. Upper adjacent chan center frequency 2. Lower adjacent chan center frequency 3. Negative offset frequency (1) 4. Positive offset frequency (1) 5. Negative offset frequency (5) <p style="text-align: center;">. . .</p> <ol style="list-style-type: none"> 11. Negative offset frequency (5) 12. Positive offset frequency (5)
Power spectral density reference	6 Basic, cdmaOne, cdma2000, W-CDMA (3GPP) mode	Returns 12 comma-separated scalar values (power spectral density in dB) of the power relative to the carrier at the center and offset frequencies: <ol style="list-style-type: none"> 1. Upper adjacent chan center frequency 2. Lower adjacent chan center frequency 3. Negative offset frequency (1) 4. Positive offset frequency (1) <p style="text-align: center;">. . .</p> <ol style="list-style-type: none"> 11. Negative offset frequency (5) 12. Positive offset frequency (5)
Total power reference	7 Basic, cdmaOne, cdma2000, W-CDMA (3GPP) mode	Returns 12 comma-separated scalar values of the pass/fail (0=passed, or 1=failed) results determined by testing the absolute power limit of the center and offset frequencies (measured as total power in dB): <ol style="list-style-type: none"> 1. Upper adjacent chan center frequency 2. Lower adjacent chan center frequency 3. Negative offset frequency (1) 4. Positive offset frequency (1) <p style="text-align: center;">. . .</p> <ol style="list-style-type: none"> 11. Negative offset frequency (5) 12. Positive offset frequency (5)

Measurement Type	n	Results Returned
Power spectral density reference	7 Basic, cdmaOne, cdma2000, W-CDMA (3GPP) mode	Returns 12 comma-separated scalar values of the pass/fail (0=passed, or 1=failed) results determined by testing the absolute power limit of the center and offset frequencies (measured as power spectral density in dB): <ol style="list-style-type: none"> 1. Upper adjacent chan center frequency 2. Lower adjacent chan center frequency 3. Negative offset frequency (1) 4. Positive offset frequency (1) ... 11. Negative offset frequency (5) 12. Positive offset frequency (5)
Total power reference	8 Basic, cdmaOne, cdma2000, W-CDMA (3GPP) mode	Returns 12 comma-separated scalar values of the pass/fail (0=passed, or 1=failed) results determined by testing the power limit relative to the center frequency (measured as total power spectral in dB): <ol style="list-style-type: none"> 1. Upper adjacent chan center frequency 2. Lower adjacent chan center frequency 3. Negative offset frequency (1) 4. Positive offset frequency (1) ... 11. Negative offset frequency (5) 12. Positive offset frequency (5)
Power spectral density reference	8 Basic, cdmaOne, cdma2000, W-CDMA (3GPP) mode	Returns 12 comma-separated scalar values of the pass/fail (0=passed, or 1=failed) results determined by testing the power limit relative to the center frequency (measured as power spectral density in dB): <ol style="list-style-type: none"> 1. Upper adjacent chan center frequency 2. Lower adjacent chan center frequency 3. Negative offset frequency (1) 4. Positive offset frequency (1) ... 11. Negative offset frequency (5) 12. Positive offset frequency (5)

Error Vector Magnitude Measurement

This measures the vector error of the magnitude of each symbol. You must be in the NADC or PDC mode to use these commands. Use INSTRument:SElect to set the mode.

The general functionality of CONFigure, FETCh, MEASure, and READ are described at the beginning of this section. See the SENSE:EVM commands for more measurement related commands.

:CONFigure:EVM

:FETCh:EVM[n]?

:READ:EVM[n]?

:MEASure:EVM[n]?

History: Version A.02.00 or later

Front Panel

Access: **Measure, EVM**

After the measurement is selected, press **Restore Meas Defaults** to restore factory defaults.

Measurement Results Available

n	Results Returned
0	Returns unprocessed I/Q trace data, as a data array of comma-separated trace points, in volts.

n	Results Returned
1 (default) EDGE GSM mode	<p>Returns the following 8 comma-separated scalar results, in order.</p> <ol style="list-style-type: none"> 1. RMS EVM – a floating point number (in percent) of EVM over the entire measurement area. 2. Peak EVM error – a floating point number (in percent) of the peak EVM in the measurement area. 3. Symbol position of the peak EVM error – an integer number of the symbol position where the peak EVM error is detected. 4. First 10 symbols EVM error – a floating point number (in percent) of EVM over the first 10 symbols. 5. Magnitude error – a floating point number (in percent) of average magnitude error over the entire measurement area. 6. Phase error – a floating point number (in degree) of average phase error over the entire measurement area. 7. Frequency error – a floating point number (in Hz) of the frequency error in the measured signal. 8. I/Q origin offset – a floating point number (in dB) of the I and Q error (magnitude squared) offset from the origin.
1 (default) NADC mode	<p>Returns the following 8 comma-separated scalar results, in order.</p> <ol style="list-style-type: none"> 1. RMS EVM – a floating point number (in percent) of EVM over the entire measurement area. 2. Peak EVM error – a floating point number (in percent) of the peak EVM in the measurement area. 3. Symbol position of the peak EVM error – an integer number of the symbol position where the peak EVM error is detected. 4. First 10 symbols EVM error – a floating point number (in percent) of EVM over the first 10 symbols. 5. Magnitude error – a floating point number (in percent) of average magnitude error over the entire measurement area. 6. Phase error – a floating point number (in degree) of average phase error over the entire measurement area. 7. Frequency error – a floating point number (in Hz) of the frequency error in the measured signal. 8. I/Q origin offset – a floating point number (in dB) of the I and Q error (magnitude squared) offset from the origin.

n	Results Returned
<p>1 (default) PDC mode</p>	<p>Returns the following 7 comma-separated scalar results, in order.</p> <ol style="list-style-type: none"> 1. RMS EVM – a floating point number (in percent) of EVM over the entire measurement area. 2. Peak EVM error – a floating point number (in percent) of peak EVM in the measurement area. 3. Symbol position of the peak EVM error – an integer number of the symbol position where the peak EVM error is detected. 4. Magnitude error – a floating point number (in percent) of average magnitude error over the entire measurement area. 5. Phase error – a floating point number (in degree) of average phase error over the entire measurement area. 6. Frequency error – a floating point number (in Hz) of the frequency error in the measured signal. 7. I/Q origin offset – a floating point number (in dB) of the I and Q error (magnitude squared) offset from the origin.
<p>2</p>	<p>Returns series of floating point numbers (in percent) that represent each sample in the EVM trace. The first number is the symbol 0 decision point and there are 5 points per symbol. Therefore, the decision points are at 0, 5, 10, 15. . . .</p>
<p>3</p>	<p>Returns series of floating point numbers (in percent) that represent each sample in the magnitude error trace. The first number is the symbol 0 decision point and there are 5 points per symbol. Therefore, the decision points are at 0, 5, 10, 15. . . .</p>
<p>4</p>	<p>Returns series of floating point numbers (in degree) that represent each sample in the phase error trace. The first number is the symbol 0 decision point and there are 5 points per symbol. Therefore, the decision points are at 0, 5, 10, 15</p>
<p>5</p>	<p>Returns series of floating point numbers that alternately represent I and Q pairs of the corrected measured trace. The magnitude of each I and Q pair are normalized to 1.0. The first number is the in-phase (I) sample of symbol 0 decision point and the second is the quadrature-phase (Q) sample of symbol 0 decision point. As in the EVM, there are 5 points per symbol, so the series of numbers is:</p> <p style="margin-left: 40px;">1st number = I of the symbol 0 decision point 2nd number = Q of the symbol 0 decision point (2 × 5) + 1 (or 11th) number = I of the symbol 1 decision point (2 × 5) + 2 (or 12th) number = Q of the symbol 1 decision point (2 × 5) × N + 1 number = I of the symbol N decision point (2 × 5) × N + 2 number = Q of the symbol N decision point</p>

n	Results Returned
6 NADC mode	<p>Returns the following 4 comma-separated scalar values of 1 or 0, in the order given. The pass/fail results (0=passed, or 1=failed) are determined by testing the EVM, peak EVM, first 10 symbols EVM and IQ origin offsets.</p> <p>Test result of EVM Test result of peak EVM Test result of first 10 symbols EVM Test result of IQ origin offset</p>
6 PDC mode	<p>Returns the following 3 comma-separated scalar values of 1 or 0, in the order given. The pass/fail results (0=passed, or 1=failed) are determined by testing the EVM, peak EVM, and IQ origin offsets.</p> <p>Test result of EVM Test result of peak EVM Test result of IQ origin offset</p>

Occupied Bandwidth Measurement

The general functionality of CONFigure, FETCh, MEASure, and READ are described at the beginning of this section. See the SENSE:OBW commands for more measurement related commands.

:CONFigure:OBW

:FETCh:OBW[n]?

:READ:OBW[n]?

:MEASure:OBW[n]?

Front Panel

Access: **Measure, Occupied BW**

After the measurement is selected, press **Restore Meas Defaults** to restore factory defaults.

Measurement results available

n	Results Returned
0	Returns unprocessed I/Q trace data, as a data array of comma-separated trace points, in volts.
1 (default) PDC, cdma2000, or W-CDMA (3GPP) mode	Returns 2 comma-separated scalar results, in the following order: 1. Occupied bandwidth - Hz 2. Absolute Carrier Power - dBm
2 PDC, cdma2000, W-CDMA (3GPP) mode	Returns the frequency-domain spectrum trace (data array) for the entire frequency range being measured

Spectrum (Frequency Domain) Measurement

This measures the amplitude of your input signal with respect to the frequency. It provides spectrum analysis capability using FFT (fast Fourier transform) measurement techniques. You must be in the Basic, cdmaOne, cdma2000, W-CDMA (3GPP), GSM (w/EDGE), NADC, or PDC mode to use these commands. Use INSTRument:SElect, to select the mode.

The general functionality of CONFigure, FETCh, MEASure, and READ are described at the beginning of this section. See the SENSE:SPECTrum commands for more measurement related commands.

:CONFigure:SPECTrum

:FETCh:SPECTrum[n]?

:READ:SPECTrum[n]?

:MEASure:SPECTrum[n]?

Front Panel

Access: **Measure, Spectrum (Freq Domain)**

After the measurement is selected, press **Restore Meas Defaults** to restore factory defaults.

Measurement Results Available

n	Results Returned
0	Returns unprocessed I/Q trace data, as a series of comma-separated trace points, in volts. The I values are listed first in each pair, using the 0 through even-indexed values. The Q values are the odd-indexed values.

n	Results Returned
not specified or n=1	<p>Returns the following comma-separated scalar results:</p> <ol style="list-style-type: none"> 1. FFT peak is the FFT peak amplitude. 2. FFT frequency is the FFT frequency of the peak amplitude. 3. FFT points is the Number of points in the FFT spectrum. 4. First FFT frequency is the frequency of the first FFT point of the spectrum. 5. FFT spacing is the frequency spacing between the FFT points of the spectrum. 6. Time domain points is the number of points in the time domain trace used for the FFT. The number of points doubles if the data is complex instead of real. See the time domain scaler description below. 7. First time point is the time of the first time domain point, where time zero is the trigger event. 8. Time spacing is the time spacing between the time domain points. The time spacing value doubles if the data is complex instead of real. See the time domain scaler description below. 9. Time domain returns a 1 if time domain is complex (I/Q) and complex data will be returned. It returns a 0 if the data is real. (raw ADC samples) When this value is 1 rather than 0 (complex vs. real data), the time domain points and the time spacing scalars both increase by a factor of two. 10. Scan time is the total scan time of the time domain trace used for the FFT. The total scan time = (time spacing) X (time domain points – 1) 11. Current average count is the current number of data measurements that have already been combined, in the averaging calculation.
3	Returns the I and Q trace data. It is represented by I and Q pairs (in volts) versus time.
4	Returns spectrum trace data. That is, the trace of log-magnitude versus frequency. (The trace is computed using a FFT.)
6	Not used.
7	Returns the averaged spectrum trace data. That is, the trace of the averaged log-magnitude versus frequency.
8	Not used.
11, cdma2000, W-CDMA, Basic modes only	Returns comma-separated linear spectrum trace data in Volts RMS.
12, cdma2000, W-CDMA, Basic modes only	Returns comma-separated averaged linear spectrum trace data in Volts RMS.

Waveform (Time Domain) Measurement

This measures the amplitude of your input signal with respect to the frequency. It provides spectrum analysis capability using FFT (fast Fourier transform) measurement techniques. You must be in the Basic, cdmaOne, cdma2000, W-CDMA (3GPP), GSM (w/EDGE), NADC, or PDC mode to use these commands. Use INSTRument:SElect, to select the mode.

The general functionality of CONFigure, FETCh, MEASure, and READ are described at the beginning of this section. See the SENSE:WAVEform commands for more measurement related commands.

:CONFigure:WAVEform

:FETCh:WAVEform[n]?

:READ:WAVEform[n]?

:MEASure:WAVEform[n]?

Front Panel

Access: **Measure, Waveform (Time Domain)**

After the measurement is selected, press **Restore Meas Defaults** to restore factory defaults.

Measurement Results Available

n	Results Returned
0 (see also 5)	Returns unprocessed I/Q trace data, as a series of comma-separated trace points, in volts. The I values are listed first in each pair, using the 0 through even-indexed values. The Q values are the odd-indexed values.

n	Results Returned
not specified or n=1	<p>Returns the following comma-separated scalar results:</p> <ol style="list-style-type: none"> 1. Sample time is a floating point number representing the time between samples when using the trace queries (n=0,2,etc). 2. Mean power is the mean power (in dBm). This is either the power across the entire trace, or the power between markers if the markers are enabled. If averaging is on, the power is for the latest acquisition. 3. Mean power averaged is the power (in dBm) for N averages, if averaging is on. This is either the power across the entire trace, or the power between markers if the markers are enabled. If averaging is on, the power is for the latest acquisition. If averaging is off, the value of the mean power averaged is the same as the value of the mean power. 4. Number of samples is the number of data points in the captured signal. This number is useful when performing a query on the signal (i.e. when n=0,2,etc.). 5. Peak-to-mean ratio has units of dB. This is the ratio of the maximum signal level to the mean power. Valid values are only obtained with averaging turned off. If averaging is on, the peak-to-mean ratio is calculated using the highest peak value, rather than the displayed average peak value. 6. Maximum value is the maximum of the most recently acquired data (in dBm). 7. Minimum value is the minimum of the most recently acquired data (in dBm).
2	<p>Returns comma-separated trace points of the entire captured trace data. These data points are floating point numbers representing the power of the signal (in dBm). There are N data points, where N is the number of samples. The period between the samples is defined by the sample time.</p>
5, cdma2000, W-CDMA, Basic modes only	<p>In input modes other than Ionly and Qonly returns comma-separated values of both I and Q trace data in Volts. The values are in pairs with the I value first. If the input mode is Ionly and Qonly the data returned is comma-separated values of just the I data or the Q data.</p>

READ Subsystem

The READ? commands are used with several other commands and are documented in the section on the “[MEASure Group of Commands](#)” on [page 331](#).

Initiate and Read Measurement Data

`:READ:<measurement>[n]?`

A READ? query must specify the desired measurement. It will cause a measurement to occur without changing any of the current settings and will return any valid results. The code number *n* selects the kind of results that will be returned. The available measurements and data results are described in the “[MEASure Group of Commands](#)” on [page 331](#).

SENSe Subsystem

These commands are used to set the instrument state parameters so that you can measure a particular input signal. Some SENSe commands are only for use with specific measurements found under the MEASURE key menu or the “MEASure Group of Commands” on page 331. The measurement must be active before you can use these commands.

The SCPI default for the format of any data output is ASCII. The format can be changed to binary with FORMat:DATA which transports faster over the bus.

Adjacent Channel Power Measurement

Commands for querying the adjacent channel power measurement results and for setting to the default values are found in the “MEASure Group of Commands” on page 331. The equivalent front panel keys for the parameters described in the following commands, are found under the Meas Setup key, after the ACP or ACPR measurement has been selected from the MEASURE key menu.

Adjacent Channel Power—Average Count

```
[ :SENSe ] :ACP :AVERAge :COUNT <integer>
```

```
[ :SENSe ] :ACP :AVERAge :COUNT ?
```

Set the number of data acquisitions that will be platform averaged. After the specified number of average counts, the average mode (termination control) setting determines the average action.

Factory Preset: 10 for cdma2000, W-CDMA

20 for Basic, cdmaOne

Range: 1 to 10,000

Remarks: Use INSTRument:SElect to set the mode.

Front Panel

Access: Meas Setup

Adjacent Channel Power—Averaging State

```
[ :SENSe ] :ACP :AVERAge [ :STATe ] OFF | ON | 0 | 1
```

```
[ :SENSe ] :ACP :AVERAge [ :STATe ] ?
```

Turn average on or off.

Factory Preset: On

PDC Programming Commands

SENSe Subsystem

Remarks: Use INSTRument:SElect to set the mode.

Front Panel

Access: Meas Setup

Adjacent Channel Power—Averaging Termination Control

```
[ :SENSe ] :ACP:AVERAge:TCONtrol EXPONential | REPeat
```

```
[ :SENSe ] :ACP:AVERAge:TCONtrol?
```

Select the type of termination control used for averaging. This determines the averaging action after the specified number of data acquisitions (average count) is reached.

EXPONential – Each successive data acquisition after the average count is reached, is exponentially weighted and combined with the existing average.

REPeat – After reaching the average count, the averaging is reset and a new average is started.

Factory Preset: REPeat for cdmaOne, cdma2000, W-CDMA

EXPONential for NADC, PDC

Remarks: Use INSTRument:SElect to set the mode.

Adjacent Channel Power—Offset Frequency Absolute Limit

```
[ :SENSe ] :ACP:LIST:ALIMit
```

```
<abs_powr> , <abs_powr> , <abs_powr> , <abs_powr> , <abs_powr>
```

```
[ :SENSe ] :ACP:LIST:ALIMit?
```

Set the absolute limit on offset frequencies relative to the carrier. You can turn off (not use) specific offsets with the [:SENSe]:ACP:LIST:STATe command.

Factory Preset:

Mode	Offset A	Offset B	Offset C	Offset D	Offset E
NADC	0 dBm	0 dBm	-13 dBm	0 dBm	0 dBm
PDC	0 dBm	0 dBm	0 dBm	0 dBm	0 dBm

Range: -200 to 50 dBm

Remarks: You must be in the NADC, cdmaOne, or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Adjacent Channel Power—Offset Frequency

```
[ :SENSe ]:ACP:LIST[ :FREQuency ]
<f_offset>,<f_offset>,<f_offset>,<f_offset>,<f_offset>
```

```
[ :SENSe ]:ACP:LIST[ :FREQuency ]?
```

Define the offset frequencies. You can turn off (not use) specific offsets with the [:SENSe]:ACP:LIST:STATe command.

Factory Preset:

Mode	Offset A	Offset B	Offset C	Offset D	Offset E
NADC	30 kHz	60 kHz	90 kHz	120 kHz	0 Hz
PDC	50 kHz	100 kHz	0 kHz	0 kHz	0 kHz

Range: 10 Hz to 45 MHz
0 to 200 kHz

Default Unit: Hz

Remarks: You must be in the NADC, cdmaOne, or PDC mode to use this command. Use INSTRument:SELEct to set the mode.

Adjacent Channel Power—Offset Frequency Relative Limit

```
[ :SENSe ]:ACP:LIST:RLIMit
<rel_powr>,<rel_powr>,<rel_powr>,<rel_powr>,<rel_powr>
```

```
[ :SENSe ]:ACP:LIST:RLIMit?
```

Set the relative limit on offset frequencies. You can turn off (not use) specific offsets with the SENS:ACP:LIST:STATe command.

Factory Preset: -45 dB

Mode	Offset A	Offset B	Offset C	Offset D	Offset E
NADC	-26 dB	-45 dB	-45 dB	0 dB	0 dB
PDC	-45 dB	-60 dB	0 dB	0 dB	0 dB

Range: -200 to 50 dB

Remarks: You must be in the NADC, cdmaOne, or PDC mode to use this command. Use INSTRument:SELEct to set the mode.

Adjacent Channel Power—Offset Frequency Control

```
[ :SENSe]:ACP:LIST:STATE OFF|ON|0|1, OFF|ON|0|1, OFF|ON|0|1,  
OFF|ON|0|1, OFF|ON|0|1
```

```
[ :SENSe]:ACP:LIST:STATE?
```

Turn measurement on or off for the custom offset frequencies.

Factory Preset:

Mode	Offset A	Offset B	Offset C	Offset D	Offset E
NADC	ON	ON	ON	OFF	OFF
PDC	ON	ON	OFF	OFF	OFF

Remarks: You must be in the NADC, cdmaOne, or PDC mode to use this command. Use INSTRUMENT:SElect to set the mode.

Adjacent Channel Power—Offset Frequency Test Mode

```
[ :SENSe]:ACP:LIST:TEST ABSolute|AND|RELative|OR,  
ABSolute|AND|RELative|OR, ABSolute|AND|RELative|OR,  
ABSolute|AND|RELative|OR, ABSolute|AND|RELative|OR
```

```
[ :SENSe]:ACP:LIST:TEST?
```

Define the type of testing to be done for the five custom offset frequencies. You can turn off (not use) specific offsets with the SENS:ACP:LIST:STATE command.

Factory Preset: RELative, RELative, OR, AND, AND for NADC, PDC mode

Remarks: You must be in the NADC, cdmaOne, or PDC mode to use this command. Use INSTRUMENT:SElect to set the mode.

Adjacent Channel Power—Trigger Source

```
[ :SENSe]:ACP:TRIGger:SOURce  
EXTErnal[1]|EXTErnal2|FRAME|IF|IMMediate|RFBurst
```

```
[ :SENSe]:ACP:TRIGger:SOURce?
```

Select the trigger source used to control the data acquisitions.

EXTErnal 1 – front panel external trigger input

EXTErnal 2 – rear panel external trigger input

FRAMe – internal frame trigger from front panel input

IF – internal IF envelope (video) trigger

IMMEDIATE – the next data acquisition is immediately taken, capturing the signal asynchronously (also called free run).

RFBurst – wideband RF burst envelope trigger that has automatic level control for periodic burst signals.

Factory Preset: IMMEDIATE for BS

RFBurst for MS

Remarks: You must be in cdmaOne, NADC, or PDC mode to use this command. Use INSTRUMENT:SELEct to set the mode.

In Basic mode, for offset frequencies >12.5 MHz, the external triggers will be a more reliable trigger source than RF burst. Also, you can use the Waveform measurement to set up trigger delay.

Adjacent Channel Power—Power Reference

[:SENSe] :ACP :TYPE PSDRef | TPreF

[:SENSe] :ACP :TYPE?

Selects the measurement type. This allows you to make absolute and relative power measurements of either total power or the power normalized to the measurement bandwidth.

Power Spectral Density Reference (PSDRef) - the power spectral density is used as the power reference

Total Power Reference (TPRef) - the total power is used as the power reference

Factory Preset: Total power reference (TPRef)

Remarks: You must be in the cdmaOne, cdma2000, W-CDMA, NADC, or PDC mode to use this command. Use INSTRUMENT:SELEct to set the mode.

Channel Commands

Burst Type

```
[ :SENSe ] :CHANnel :BURSt TCH | CCH
```

```
[ :SENSe ] :CHANnel :BURSt ?
```

Set the burst type for mobile station testing.

Traffic Channel (TCH) – burst for traffic channel

Control Channel (CCH) – burst for control channel

Factory Preset: TCH

Remarks: The command is only applicable for mobile station testing, device = MS.

You must be in the NADC or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Time Slot number

```
[ :SENSe ] :CHANnel :SLOT <integer>
```

```
[ :SENSe ] :CHANnel :SLOT ?
```

Select the slot number that you want to measure.

In GSM mode the measurement frame is divided into the eight expected measurement timeslots.

Factory Preset: 0 for GSM, EDGE, PDC mode

1 for NADC mode

Range: 0 to 5 for PDC mode

1 to 6 for NADC mode

0 to 7 for GSM, EDGE mode

Remarks: You must be in GSM, EDGE, NADC, PDC mode to use this command. Use INSTRument:SElect to set the mode.

Front Panel

Access: **Mode Setup, Radio, Frequency Hopping Repetition Factor**

Time Slot Auto

```
[ :SENSE ]:CHANnel:SLOT:AUTO OFF|ON|0|1
```

```
[ :SENSE ]:CHANnel:SLOT:AUTO?
```

Select auto or manual control for slot searching. The feature is only supported in external and frame trigger source modes. In external trigger mode when timeslot is set on, the demodulation measurement is made on the nth timeslot specified by the external trigger point + n timeslots, where n is the selected timeslot value 0 to 7. In frame trigger mode when timeslot is set on, then demodulation measurement is only made on the nth timeslot specified by bit 0 of frame reference burst + n timeslots, where n is the selected timeslot value 0 to 7 and where the frame reference burst is specified by Ref Burst and Ref TSC (Std) combination.

Factory Preset: ON, for NADC, PDC mode

OFF, for GSM, EDGE mode

Remarks: The command is only applicable for mobile station testing, device = MS.

You must be in GSM, EDGE, NADC, PDC mode to use this command. Use INSTRUMENT:SELEct to set the mode.

Signal Corrections Commands

Correction for Base Station RF Port External Attenuation

```
[ :SENSe ]:CORRection:BS[:RF]:LOSS <rel_power>
```

```
[ :SENSe ]:CORRection:BS[:RF]:LOSS?
```

Set the correction equal to the external attenuation used when measuring base stations.

Factory Preset: 0 dB

Range: –50 to 100 dB for cdmaOne
 –50 to 50 dB for NADC or PDC

Default Unit: dB

Remarks: You must be in the cdmaOne, NADC or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Value is global to the current mode.

Correction for Mobile Station RF Port External Attenuation

```
[ :SENSe ]:CORRection:MS[:RF]:LOSS <rel_power>
```

```
[ :SENSe ]:CORRection:MS[:RF]:LOSS?
```

Set the correction equal to the external attenuation used when measuring mobile stations.

Factory Preset: 0.0 dB

Range: –50 to 100.0 dB for cdmaOne, GSM, EDGE
 –100.0 to 100.0 dB for cdma2000, W-CDMA
 –50.0 to 50.0 dB for NADC, PDC

Default Unit: dB

Remarks: You must be in the cdmaOne, GSM (w/EDGE), cdma2000, W-CDMA, NADC or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Value is global to the current mode.

Error Vector Magnitude Measurement

Commands for querying the error vector magnitude measurement results and for setting to the default values are found in the “[MEASure Group of Commands](#)” on page 331. The equivalent front panel keys for the parameters described in the following commands, are found under the **Meas Setup** key, after the **EVM** measurement has been selected from the **MEASURE** key menu.

Error Vector Magnitude—Average Count

```
[ :SENSe ]:EVM:AVERAge:COUNT <integer>
```

```
[ :SENSe ]:EVM:AVERAge:COUNT?
```

Set the number of data acquisitions that will be averaged. After the specified number of average counts, the average mode (termination control) setting determines the average action.

Factory Preset: 10

Range: 1 to 10,000

Remarks: You must be in the NADC or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Error Vector Magnitude—Averaging State

```
[ :SENSe ]:EVM:AVERAge[ :STATe ] OFF | ON | 0 | 1
```

```
[ :SENSe ]:EVM:AVERAge[ :STATe ]?
```

Turn average on or off.

Factory Preset: ON

Remarks: You must be in the NADC or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Error Vector Magnitude—Averaging Termination Control

```
[ :SENSe ]:EVM:AVERAge:TCONtrol EXPONential | REPEat
```

```
[ :SENSe ]:EVM:AVERAge:TCONtrol?
```

Select the type of termination control used to averaging. This determines the averaging action after the specified number of data acquisitions (average count) is reached.

EXPONential – Each successive data acquisition after the average count is reached, is exponentially weighted and combined with the existing average.

PDC Programming Commands

SENSe Subsystem

REPeat – After reaching the average count, the averaging is reset and a new average is started.

Factory Preset: EXPOnential

Remarks: You must be in the NADC or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Error Vector Magnitude—Burst Synchronization Source

[:SENSe] :EVM:BSYNc:SOURce RFBurst | TSEQUence | NONE

[:SENSe] :EVM:BSYNc:SOURce?

Select the method of synchronizing the measurement to the bursts.

RFBurst – The burst sync approximates the start and stop of the useful part of the burst without demodulation of the burst.

Training Sequence (TSEQUence)– The burst sync performs a demodulation of the burst and determines the start and stop of the useful part of the burst based on the midamble training sync sequence.

NONE – The measurement is performed without searching burst.

Factory Preset: NONE for BS

TSEQUence for MS

Remarks: You must be in the NADC or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Error Vector Magnitude—Points/Symbol

[:SENSe] :EVM:TRACe:PPSYmbol <integer>

[:SENSe] :EVM:TRACe:PPSYmbol?

Select the points/symbol for EVM measurement. Only 1 or 5 are valid entries.

Factory Preset: 5

Range: 1, 5

Remarks: You must be in the NADC or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Error Vector Magnitude—Trigger Source

[:SENSE] :EVM:TRIGger:SOURce
EXTernal[1] | EXTernal2 | FRAMe | IF | IMMEDIATE | RFBURSt

[:SENSe] :EVM:TRIGger:SOURce?

Select the trigger source used to control the data acquisitions.

EXTernal 1 – front panel external trigger input

EXTernal 2 – rear panel external trigger input

IF – internal IF envelope (video) trigger

IMMEDIATE – the next data acquisition is immediately taken, capturing the signal asynchronously (also called free run)

FRAMe – internal frame trigger from front panel input

RFBURSt – wideband RF burst envelope trigger that has automatic level control for periodic burst signals

Factory Preset: IMMEDIATE for BS

RFBURSt for MS

Remarks: You must be in the NADC or PDC mode to use this command. Use INSTRUMENT:SElect to set the mode.

Select the Input Signal

```
[[:SENSe]:FEED RF|AREFERENCE|IFALIGN
```

```
[[:SENSe]:FEED?
```

Selects the input signal. The default input signal is taken from the front panel RF input port. For calibration and testing purposes the input signal can be taken from an internal 321.4 MHz IF alignment signal or an internal 50 MHz amplitude reference source.

RF selects the signal from the front panel RF INPUT port.

AREFERENCE selects the internal 50 MHz amplitude reference signal.

IFALIGN selects the internal, 321.4 MHz, IF alignment signal.

Factory Preset: RF

Front Panel

Access: **Input, Input Port**

Occupied Bandwidth Measurement

Commands for querying the occupied bandwidth measurement results and for setting to the default values are found in the “[MEASure Group of Commands](#)” on page 331. The equivalent front panel keys for the parameters described in the following commands, are found under the **Meas Setup** key, after the **Occupied BW** measurement has been selected from the **MEASURE** key menu.

Occupied Bandwidth—Average Count

```
[ :SENSE ] :OBW :AVERAGE :COUNT <integer>
```

```
[ :SENSE ] :OBW :AVERAGE :COUNT ?
```

Set the number of data acquisitions that will be averaged. After the specified number of average counts, the average mode (termination control) setting determines the average action.

Factory Preset: 10

Range: 1 to 10,000

Remarks: This command is used for measurements in the MEASURE menu.

You must be in the PDC, cdma2000, or W-CDMA mode to use this command. Use INSTRUMENT:SELEct to set the mode.

Front Panel

Access: **Meas Setup, Avg Number**

Occupied Bandwidth—Averaging State

```
[ :SENSE ] :OBW :AVERAGE [ :STATE ] OFF | ON | 0 | 1
```

```
[ :SENSE ] :OBW :AVERAGE [ :STATE ] ?
```

Turn averaging on or off.

Factory Preset: ON

Remarks: You must be in the PDC, cdma2000, or W-CDMA mode to use this command. Use INSTRUMENT:SELEct to set the mode.

Front Panel

Access: **Meas Setup, Avg Number**

Occupied Bandwidth—Averaging Termination Control

[:SENSe] :OBW:AVERAge:TCONtrol EXPonential|REPeat

[:SENSe] :OBW:AVERAge:TCONtrol?

Select the type of termination control used for the averaging function. This determines the averaging action after the specified number of data acquisitions (average count) is reached.

EXPonential - After the average count is reached, each successive data acquisition is exponentially weighted and combined with the existing average.

REPeat - After reaching the average count, the averaging is reset and a new average is started.

Factory Preset: EXPonential for PDC

REPeat for cdma2000, W-CDMA

Remarks: You must be in the PDC, cdma2000, or W-CDMA mode to use this command. Use INSTRument:SElect to set the mode.

Front Panel

Access: Meas Setup, Avg Mode

Occupied Bandwidth—Span

[:SENSe] :OBW:FREQuency:SPAN <freq>

[:SENSe] :OBW:FREQuency:SPAN?

Set the occupied bandwidth span. The analyzer span will retain this value throughout the measurement.

Factory Preset: 10.0 MHz

3.75 MHz for cdma2000

Range: 10.0 kHz to 10.0 MHz

Default Unit: Hz

Remarks: You must be in the PDC, cdma2000 or W-CDMA mode to use this command. Use INSTRument:SElect to set the mode.

Occupied Bandwidth—Trigger Source

PDC mode

```
[ :SENSE ]:OBW:TRIGger:SOURce  
EXTernal[1] | EXTernal2 | IF | IMMEDIATE | RFBurst
```

```
[ :SENSE ]:OBW:TRIGger:SOURce?
```

cdma2000, W-CDMA mode

```
[ :SENSE ]:OBW:TRIGger:SOURce  
EXTernal[1] | EXTernal2 | FRAME | IF | IMMEDIATE | LINE | RFBurst
```

```
[ :SENSE ]:OBW:TRIGger:SOURce?
```

Select the trigger source used to control the data acquisitions for the occupied bandwidth measurement.

EXTernal1 – rear panel external trigger input

EXTernal2 – front panel external trigger input

FRAME – internal frame trigger (cdma2000, W-CDMA mode only)

IF – internal IF envelope (video) trigger

IMMEDIATE – the next data acquisition is immediately taken, capturing the signal asynchronously (also called free run)

LINE – power line (cdma2000, W-CDMA mode only)

RFBurst – wideband RF burst envelope trigger that has automatic level control for periodic burst signals

Factory Preset: IMMEDIATE for BS in PDC, cdma2000, W-CDMA modes

RFBurst for MS in PDC mode

Remarks: You must be in the PDC, cdmaOne, cdma2000, or W-CDMA mode to use this command. Use INSTRUMENT:SELEct to set the mode.

RF Power Commands

RF Port Input Attenuation

```
[ :SENSe ] :POWER [ :RF ] :ATTenuation <rel_power>
```

```
[ :SENSe ] :POWER [ :RF ] :ATTenuation?
```

Set the RF input attenuator. This value is set at its auto value if RF input attenuation is set to auto.

Factory Preset: 0 dB

Range: 0 to 40 dB

Default Unit: dB

Front Panel

Access: Input, Input Atten

RF Port Power Range Auto

```
[ :SENSe ] :POWER [ :RF ] :RANGe :AUTO OFF | ON | 0 | 1
```

```
[ :SENSe ] :POWER [ :RF ] :RANGe :AUTO?
```

Select the RF port power range to be set either automatically or manually.

ON - power range is automatically set as determined by the actual measured power level at the start of a measurement.

OFF - power range is manually set

Factory Preset: ON

Remarks: You must be in the cdmaOne, GSM, EDGE, NADC, PDC, cdma2000, W-CDMA, mode to use this command. Use INSTRument:SElect to set the mode.

Front Panel

Access: Input, Max Total Pwr (at UUT)

RF Port Power Range Maximum Total Power

```
[ :SENSe ] :POWER [ :RF ] :RANGe [ :UPPer ] <power>
```

```
[ :SENSe ] :POWER [ :RF ] :RANGe [ :UPPer ]?
```

Set the maximum expected total power level at the radio unit under test. This value is ignored if RF port power range is set to auto. External attenuation required above 30 dBm.

Factory Preset: -15.0 dBm

Range: –100.0 to 80.0 dBm for EDGE, GSM
 –100.0 to 27.7 dBm for cdmaOne
 –200.0 to 50.0 dBm for NADC, PDC
 –200.0 to 100.0 dBm for cdma2000, W-CDMA

Default Unit: dBm

Remarks: Global to the current mode. This is coupled to the RF
 input attenuation

You must be in the cdmaOne, GSM, EDGE, NADC,
PDC, cdma2000, W-CDMA mode to use this command.
Use INSTRUMENT:SElect to set the mode.

Front Panel

Access: **Input, Max Total Pwr (at UUT)**

Radio Standards Commands

Radio Device Under Test

```
[ :SENSe ]:RADio:DEVIce BS|MS
```

```
[ :SENSe ]:RADio:DEVIce?
```

Select the type of radio device to be tested.

BS – Base station transceiver test

MS – Mobile station transceiver test

Factory Preset: BS

Remarks: You must be in the NADC, or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Global to current mode.

Front Panel

Access: **Mode Setup, Radio, Device**

Radio Traffic Rate

```
[ :SENSe ]:RADio:TRATe FULL|HALF
```

```
[ :SENSe ]:RADio:TRATe?
```

Select the traffic rate.

FULL – full traffic rate (a slot is every 20 ms)

HALF – half traffic rate (a slot is every 40 ms)

Factory Preset: FULL

Remarks: You must be in the NADC or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Spectrum (Frequency-Domain) Measurement

Commands for querying the spectrum measurement results and for setting to the default values are found in the “[MEASure Group of Commands](#)” on page 331. The equivalent front panel keys for the parameters described in the following commands, are found under the **Meas Setup** key, after the **Spectrum (Freq Domain)** measurement has been selected from the **MEASURE** key menu.

Spectrum—Data Acquisition Packing

```
[ :SENSE]:SPECTrum:ACQuisition:PACKing  
AUTO|LONG|MEDIum|SHORT
```

```
[ :SENSE]:SPECTrum:ACQuisition:PACKing?
```

Select the amount of data acquisition packing. This is an advanced control that normally does not need to be changed.

Factory Preset: AUTO

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRUMENT:SElect to set the mode.

Spectrum—ADC Dither

```
[ :SENSE]:SPECTrum:ADC:DITHer[ :STATe] AUTO|ON|OFF|2|1|0
```

```
[ :SENSE]:SPECTrum:ADC:DITHer[ :STATe]?
```

Turn the ADC dither on or off. This is an advanced control that normally does not need to be changed.

Factory Preset: AUTO

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRUMENT:SElect to set the mode.

Spectrum—ADC Range

```
[ :SENSe ] :SPEctrum:ADC:RANGe
AUTO | APEak | APLOCK | NONE | P0 | P6 | P12 | P18
```

```
[ :SENSe ] :SPEctrum:ADC:RANGe?
```

Select the range for the gain-ranging that is done in front of the ADC. This is an advanced control that normally does not need to be changed. Auto peak ranging is the default for this measurement. If you are measuring a CW signal please see the description below.

- **AUTO** - automatic range

For FFT spectrums - auto ranging should not be used. An exception to this would be if you know that your signal is “bursty”. Then you might use auto to maximize the time domain dynamic range as long as you are not very interested in the FFT data.
- **Auto Peak (APEak)** - automatically peak the range

For CW signals, the default of auto-peak ranging can be used, but a better FFT measurement of the signal can be made by selecting one of the manual ranges that are available: M6, P0 - P24. Auto peaking can cause the ADC range gain to move monotonically down during the data capture. This movement should have negligible effect on the FFT spectrum, but selecting a manual range removes this possibility. Note that if the CW signal being measured is close to the auto-ranging threshold, the noise floor may shift as much as 6 dB from sweep to sweep.
- **Auto Peak Lock (APLOCK)** - automatically peak lock the range

For CW signals, auto-peak lock ranging may be used. It will find the best ADC measurement range for this particular signal and will not move the range as auto-peak can. Note that if the CW signal being measured is close to the auto-ranging threshold, the noise floor may shift as much as 6 dB from sweep to sweep. For “bursty” signals, auto-peak lock ranging should not be used. The measurement will fail to operate, since the wrong (locked) ADC range will be chosen often and overloads will occur in the ADC.
- **NONE** - turns off any auto-ranging without making any changes to the current setting.
- **P0 to P18** - manually selects ADC ranges that add 0 to 18 dB of fixed gain across the range. Manual ranging is best for CW signals.

Factory Preset: APEak

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRUMENT:SElect to set the mode.

Spectrum—Average Clear

```
[ :SENSE ] :SPECTrum:AVERAge:CLEar
```

The average data is cleared and the average counter is reset.

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRUMENT:SElect to set the mode.

Spectrum—Number of Averages

```
[ :SENSE ] :SPECTrum:AVERAge:COUNT <integer>
```

```
[ :SENSE ] :SPECTrum:AVERAge:COUNT?
```

Set the number of 'sweeps' that will be averaged. After the specified number of 'sweeps' (average counts), the averaging mode (terminal control) setting determines the averaging action.

Factory Preset: 25

Range: 1 to 10,000

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRUMENT:SElect to set the mode.

Spectrum—Averaging State

```
[ :SENSE ] :SPECTrum:AVERAge[ :STATE ] OFF | ON | 0 | 1
```

```
[ :SENSE ] :SPECTrum:AVERAge[ :STATE ]?
```

Turn averaging on or off.

Factory Preset: ON

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRUMENT:SElect to set the mode.

Spectrum—Averaging Mode

```
[ :SENSe ] :SPECTrum:AVERAge:TCONtrol EXPONential | REPeat
```

```
[ :SENSe ] :SPECTrum:AVERAge:TCONtrol?
```

Select the type of termination control used for the averaging function. This determines the averaging action after the specified number of 'sweeps' (average count) is reached.

EXPONential - Each successive data acquisition after the average count is reached, is exponentially weighted and combined with the existing average.

REPeat - After reaching the average count, the averaging is reset and a new average is started.

Factory Preset: EXPONential

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Spectrum—Averaging Type

```
[ :SENSe ] :SPECTrum:AVERAge:TYPE
```

```
LOG | MAXimum | MINimum | RMS | SCALar
```

```
[ :SENSe ] :SPECTrum:AVERAge:TYPE?
```

Select the type of averaging.

LOG – The log of the power is averaged. (This is also known as video averaging.)

MAXimum – The maximum values are retained.

MINimum – The minimum values are retained.

RMS – The power is averaged, providing the rms of the voltage.

SCALar – The voltage is averaged.

Factory Preset: LOG

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Spectrum— Select Pre-FFT Bandwidth

```
[ :SENSE]:SPECTrum:Bandwidth|BWIDth:IF:AUTO OFF|ON|0|1
```

```
[ :SENSE]:SPECTrum:Bandwidth|BWIDth:IF:AUTO?
```

Select auto or manual control of the pre-FFT BW.

Factory Preset: AUTO, 1.55 MHz

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRUMENT:SElect to set the mode.

Front Panel

Access: Measure, Spectrum, Meas Setup, More, Advanced, Pre-FFT BW.

Spectrum — IF Flatness Corrections

```
[ :SENSE]:SPECTrum:Bandwidth|BWIDth:IF:FLATness OFF|ON|0|1
```

```
[ :SENSE]:SPECTrum:Bandwidth|BWIDth:IF:FLATness?
```

Turns IF flatness corrections on and off.

Factory Preset: ON

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRUMENT:SElect to set the mode.

Front Panel

Access: Measure, Spectrum, Meas Setup, More, Advanced, Pre-FFT BW

Spectrum—Pre-ADC Bandpass Filter

```
[ :SENSE]:SPECTrum:Bandwidth|BWIDth:PADC OFF|ON|0|1
```

```
[ :SENSE]:SPECTrum:Bandwidth|BWIDth:PADC?
```

Turn the pre-ADC bandpass filter on or off. This is an advanced control that normally does not need to be changed.

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRUMENT:SElect to set the mode.

Spectrum—Pre-FFT BW

```
[ :SENSe ] :SPECTrum: BANDwidth | BWIDth: PFFT [ :SIZE ] <freq>
```

```
[ :SENSe ] :SPECTrum: BANDwidth | BWIDth: PFFT [ :SIZE ] ?
```

Set the pre-FFT bandwidth. This is an advanced control that normally does not need to be changed.

Frequency span, resolution bandwidth, and the pre-FFT bandwidth settings are normally coupled. If you are not auto-coupled, there can be combinations of these settings that are not valid.

Factory Preset: 1.55 MHz

1.25 MHz for cdmaOne

Range: 1 Hz to 10.0 MHz

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRument:SELEct to set the mode.

Spectrum—Pre-FFT BW Filter Type

```
[ :SENSe ] :SPECTrum: BANDwidth | BWIDth: PFFT: TYPE FLAT | GAUSSian
```

```
[ :SENSe ] :SPECTrum: BANDwidth | BWIDth: PFFT: TYPE ?
```

Select the type of pre-FFT filter that is used. This is an advanced control that normally does not need to be changed.

Flat top (FLAT)- a filter with a flat amplitude response, which provides the best amplitude accuracy.

GAUSSian - a filter with Gaussian characteristics, which provides the best pulse response.

Factory Preset: FLAT

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRument:SELEct to set the mode.

Spectrum—Resolution BW

```
[ :SENSe ] :SPECTrum: BANDwidth | BWIDth [ :RESolution ] <freq>
```

```
[ :SENSe ] :SPECTrum: BANDwidth | BWIDth [ :RESolution ] ?
```

Set the resolution bandwidth for the FFT. This is the bandwidth used for resolving the FFT measurement. It is not the pre-FFT bandwidth.

This value is ignored if the function is auto-coupled.

Frequency span, resolution bandwidth, and the pre-FFT bandwidth settings are normally coupled. If you are not auto-coupled, there can be combinations of these settings that are not valid.

Factory Preset: 20.0 kHz

Range: 0.10 Hz to 3.0 MHz

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRUMENT:SElect to set the mode.

Spectrum—Resolution BW Auto

```
[ :SENSE ] :SPECTrum: BANDwidth | BWIDth [ :RESolution ] :AUTO  
OFF | ON | 0 | 1
```

```
[ :SENSE ] :SPECTrum: BANDwidth | BWIDth [ :RESolution ] :AUTO?
```

Select auto or manual control of the resolution BW. The automatic mode couples the resolution bandwidth setting to the frequency span.

Factory Preset: ON

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRUMENT:SElect to set the mode.

Decimation of Spectrum Display

```
[ :SENSE ] :SPECTrum: DECimate [ :FACTor ] <integer>
```

```
[ :SENSE ] :SPECTrum: DECimate [ :FACTor ] ?
```

Sets the amount of data decimation done by the hardware and/or the software. Decimation by n keeps every n th sample, throwing away each of the remaining samples in the group of n . For example, decimation by 3 keeps every third sample, throwing away the two in between. Similarly, decimation by 5 keeps every fifth sample, throwing away the four in between.

Using zero (0) decimation selects the automatic mode. The measurement will then automatically choose decimation by “1” or “2” as is appropriate for the bandwidth being used.

This is an advanced control that normally does not need to be changed.

Factory Preset: 0

PDC Programming Commands

SENSe Subsystem

Range: 0 to 1,000, where 0 sets the function to automatic

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Spectrum—FFT Length

```
[ :SENSe ] :SPEctrum:FFT:LENGth <integer>
```

```
[ :SENSe ] :SPEctrum:FFT:LENGth?
```

Set the FFT length. This value is only used if length control is set to manual. The value must be greater than or equal to the window length value. Any amount greater than the window length is implemented by zero-padding. This is an advanced control that normally does not need to be changed.

Factory Preset: 706

Range: min, depends on the current setting of the spectrum window length

max, 1,048,576

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Spectrum—FFT Length Auto

```
[ :SENSe ] :SPEctrum:FFT:LENGth:AUTO OFF|ON|0|1
```

```
[ :SENSe ] :SPEctrum:FFT:LENGth:AUTO?
```

Select auto or manual control of the FFT and window lengths.

This is an advanced control that normally does not need to be changed.

On - the window lengths are coupled to resolution bandwidth, window type (FFT), pre-FFT bandwidth (sample rate) and SENSe:SPEctrum:FFT:RBWPoints.

Off - lets you set SENSe:SPEctrum:FFT:LENGth and SENSe:SPEctrum:FFT:WINDow:LENGth.

Factory Preset: ON

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRUMENT:SElect to set the mode.

Spectrum—FFT Minimum Points in Resolution BW

```
[ :SENSe ]:SPECTrum:FFT:RBWPoints <real>
```

```
[ :SENSe ]:SPECTrum:FFT:RBWPoints?
```

Set the minimum number of data points that will be used inside the resolution bandwidth. The value is ignored if length control is set to manual. This is an advanced control that normally does not need to be changed.

Factory Preset: 1.30

Range: 0.1 to 100

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRUMENT:SElect to set the mode.

Spectrum—Window Delay

```
[ :SENSe ]:SPECTrum:FFT:WINDow:DELay <real>
```

```
[ :SENSe ]:SPECTrum:FFT:WINDow:DELay?
```

Set the FFT window delay to move the FFT window from its nominal position of being centered within the time capture. This function is not available from the front panel. It is an advanced control that normally does not need to be changed.

Factory Preset: 0

Range: -10.0 to +10.0s

Default Unit: seconds

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRUMENT:SElect to set the mode.

Spectrum—Window Length

```
[ :SENSe ] :SPECTrum:FFT:WINDow:LENGth <integer>
```

```
[ :SENSe ] :SPECTrum:FFT:WINDow:LENGth?
```

Set the FFT window length. This value is only used if length control is set to manual. This is an advanced control that normally does not need to be changed.

Factory Preset: 706

Range: 8 to 1,048,576

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Spectrum—FFT Window

```
[ :SENSe ] :SPECTrum:FFT:WINDow[ :TYPE]
```

```
BH4Tap | BLACkman | FLATtop | GAUSSian | HAMMING | HANNing | KB70 | KB90 |  
KB110 | UNIFORM
```

```
[ :SENSe ] :SPECTrum:FFT:WINDow[ :TYPE]?
```

Select the FFT window type.

BH4Tap - Blackman Harris with 4 taps

BLACkman - Blackman

FLATtop - flat top, the default (for high amplitude accuracy)

GAUSSian - Gaussian with alpha of 3.5

HAMMING - Hamming

HANNing - Hanning

KB70, 90, and 110 - Kaiser Bessel with sidelobes at -70, -90, or -110 dBc

UNIFORM - no window is used. (This is the unity response.)

Factory Preset: FLATtop

Remarks: This selection affects the acquisition point quantity and the FFT size, based on the resolution bandwidth selected.

You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Spectrum—Frequency Span

```
[ :SENSe ] :SPECTrum:FREQUency:SPAN <freq>
```

```
[ :SENSe ] :SPECTrum:FREQUency:SPAN?
```

Set the frequency span to be measured.

Factory Preset: 1.0 MHz

Range: 10 Hz to 10.0 MHz (15 MHz when Service mode is selected)

Default Unit: Hz

Remarks: The actual measured span will generally be slightly wider due to the finite resolution of the FFT.

You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Spectrum—Sweep (Acquisition) Time

```
[ :SENSe ] :SPECTrum:SWEep:TIME[ :VALue ] <time>
```

```
[ :SENSe ] :SPECTrum:SWEep:TIME?
```

Set the sweep (measurement acquisition) time. It is used to specify the length of the time capture record. If the value you specify is less than the capture time required for the specified span and resolution bandwidth, the value is ignored. The value is set at its auto value when auto is selected. This is an advanced control that normally does not need to be changed.

Factory Preset: 188.0 μ s

Range: 100 ns to 10 s

Default Unit: seconds

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Spectrum—Sweep (Acquisition) Time Auto

```
[ :SENSe ] :SPECTrum:SWEep:TIME:AUTO OFF|ON|0|1
```

```
[ :SENSe ] :SPECTrum:SWEep:TIME:AUTO
```

Select auto or manual control of the sweep (acquisition) time. This is an advanced control that normally does not need to be changed.

AUTO - couples the Sweep Time to the Frequency Span and Resolution BW

Manual - the Sweep Time is uncoupled from the Frequency Span and Resolution BW.

Factory Preset: AUTO

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Spectrum—Trigger Source

```
[ :SENSe ] :SPECTrum:TRIGger:SOURce  
EXTErnal[1] | EXTErnal2 | FRAME | IF | LINE | IMMEDIATE | RFBURSt
```

```
[ :SENSe ] :SPECTrum:TRIGger:SOURce?
```

Select the trigger source used to control the data acquisitions.

EXTErnal1 - front panel external trigger input

EXTErnal2 - rear panel external trigger input

FRAME - internal frame timer from front panel input

IF - internal IF envelope (video) trigger

LINE - internal line trigger

IMMEDIATE - the next data acquisition is immediately taken (also called free run)

RFBURSt - wideband RF burst envelope trigger that has automatic level control for periodic burst signals

Factory Preset: IMMEDIATE (free run)

RFBURSt, for GSM mode

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Synchronization Commands

Burst Sync Delay

`[:SENSE]:SYNC:BURSt:DELay <time>`

`[:SENSE]:SYNC:BURSt:DELay?`

Set the delay for the burst measurement position from the reference position that is determined by sync word or the burst rising/falling edges.

Factory Preset: 0 sec

Range: -500 ms to 500 ms

Default Unit: seconds

Remarks: You must be in the NADC or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Burst Search Threshold

`[:SENSE]:SYNC:STHReshold <rel_power>`

`[:SENSE]:SYNC:STHReshold?`

Set the power threshold, relative to the peak power, that is used to determine the burst rising edge and falling edge.

Factory Preset: -30 dB

Range: -200 to -0.01 dB

Default Unit: dB

Remarks: You must be in the NADC or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Front Panel

Access: **Mode Setup, Trigger, Burst Search Threshold**

Waveform (Time-Domain) Measurement

Commands for querying the waveform measurement results and for setting to the default values are found in the “[MEASure Group of Commands](#)” on page 331. The equivalent front panel keys for the parameters described in the following commands, are found under the **Meas Setup** key, after the **Waveform (Time Domain)** measurement has been selected from the **MEASURE** key menu.

Waveform—Data Acquisition Packing

```
[ :SENSe ] :WAVEform:ACQuIstion:PACKIng AUTO | LONG | MEDium | SHORt
```

```
[ :SENSe ] :WAVEform:ACQuIstion:PACKIng?
```

This is an advanced control that normally does not need to be changed.

Factory Preset: AUTO

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Waveform—ADC Dither State

```
[ :SENSe ] :WAVEform:ADC:DITHer [ :STATe ] OFF | ON | 0 | 1
```

```
[ :SENSe ] :WAVEform:ADC:DITHer [ :STATe ] ?
```

This is an Advanced control that normally does not need to be changed.

Factory Preset: OFF

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Waveform—Pre-ADC Bandpass Filter

```
[ :SENSe ] :WAVEform:ADC:FILTer [ :STATe ] OFF | ON | 0 | 1
```

```
[ :SENSe ] :WAVEform:ADC:FILTer [ :STATe ] ?
```

Turn the pre-ADC bandpass filter on or off. This is an Advanced control that normally does not need to be changed.

Preset: OFF

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRUMENT:SElect to set the mode.

Waveform—ADC Range

[:SENSe] :WAVEform:ADC:RANGe
 AUTO | APEak | APLOCK | GROund | NONE | P0 | P6 | P12 | P18

[:SENSe] :WAVEform:ADC:RANGe?

Select the range for the gain-ranging that is done in front of the ADC. This is an Advanced control that normally does not need to be changed.

AUTO - automatic range

Auto Peak (APEak) - automatically peak the range

Auto Peak Lock (APLOCK)- automatically peak lock the range

GROund - ground

NONE - turn off auto-ranging without making any changes to the current setting.

P0 to P18 - adds 0 to 18 dB of fixed gain across the range

Factory Preset: AUTO

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRUMENT:SElect to set the mode.

Waveform - Query Aperture Setting

[:SENSe] :WAVEform:APERTure?

Returns the waveform sample period (aperture) based on current resolution bandwidth, filter type, and decimation factor. Sample rate is the reciprocal of period.

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRUMENT:SElect to set the mode.

Waveform—Number of Averages

```
[ :SENSe ] :WAVeform:AVERAge:COUNT <integer>
```

```
[ :SENSe ] :WAVeform:AVERAge:COUNT?
```

Set the number of sweeps that will be averaged. After the specified number of sweeps (average counts), the averaging mode (terminal control) setting determines the averaging action.

Factory Preset: 10

Range: 1 to 10,000

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Waveform—Averaging State

```
[ :SENSe ] :WAVeform:AVERAge[ :STATe ] OFF|ON|0|1
```

```
[ :SENSe ] :WAVeform:AVERAge[ :STATe ]?
```

Turn averaging on or off.

Factory Preset: OFF

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Waveform—Averaging Mode

```
[ :SENSe ] :WAVeform:AVERAge:TCONtrol EXPOnential|REPeat
```

```
[ :SENSe ] :WAVeform:AVERAge:TCONtrol?
```

Select the type of termination control used for the averaging function. This determines the averaging action after the specified number of 'sweeps' (average count) is reached.

EXPOnential - Each successive data acquisition after the average count is reached, is exponentially weighted and combined with the existing average.

REPeat - After reaching the average count, the averaging is reset and a new average is started.

Factory Preset: EXPOnential

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Waveform—Averaging Type

```
[ :SENSe ] :WAVeform:AVERAge :TYPE
LOG | MAXimum | MINimum | RMS | SCALar
```

```
[ :SENSe ] :WAVeform:AVERAge :TYPE?
```

Select the type of averaging.

LOG - The log of the power is averaged. (This is also known as video averaging.)

MAXimum - The maximum values are retained.

MINimum - The minimum values are retained.

RMS - The power is averaged, providing the rms of the voltage.

Factory Preset: RMS

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Waveform—Resolution BW

```
[ :SENSe ] :WAVeform:BANDwidth | BWIDth [ :RESolution ] <freq>
```

```
[ :SENSe ] :WAVeform:BANDwidth | BWIDth [ :RESolution ]?
```

Set the resolution bandwidth. This value is ignored if the function is auto-coupled.

Factory Preset: 100.0 kHz for NADC, PDC, cdma2000, W-CDMA, Basic
500.0 kHz for GSM
2.0 MHz for cdmaOne

Range: 1.0 kHz to 5.0 MHz

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Waveform - Query Actual Resolution Bandwidth

[:SENSe] :WAVEform :BANDwidth :RESolution] :ACTual ?

Due to memory constraints the actual resolution bandwidth value may vary from the value entered by the user. For most applications the resulting difference in value is inconsequential but for some it is necessary to know the actual value; this query retrieves the actual resolution bandwidth value.

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Waveform—Resolution BW Filter Type

[:SENSe] :WAVEform :BANDwidth | BWIDth [:RESolution] :TYPE
FLATtop | GAUSSian

[:SENSe] :WAVEform :BANDwidth | BWIDth [:RESolution] :TYPE ?

Select the type of Resolution BW filter that is used. This is an Advanced control that normally does not need to be changed.

FLATtop - a filter with a flat amplitude response, which provides the best amplitude accuracy.

GAUSSian - a filter with Gaussian characteristics, which provides the best pulse response.

Factory Preset: GAUSSian

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Waveform—Decimation of Waveform Display

[:SENSe] :WAVEform :DECimate [:FACTor] <integer>

[:SENSe] :WAVEform :DECimate [:FACTor] ?

Set the amount of data decimation done on the IQ data stream. For example, if 4 is selected, three out of every four data points will be thrown away. So every 4th data point will be kept.

Factory Preset: 1

Range: 1 to 4

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Waveform—Control Decimation of Waveform Display

```
[ :SENSe ]:WAVEform:DECimate:STATe OFF|ON|0|1
```

```
[ :SENSe ]:WAVEform:DECimate:STATe?
```

Set the amount of data decimation done by the hardware in order to decrease the number of acquired points in a long capture time. This is the amount of data that the measurement ignores.

Factory Preset: OFF

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Waveform—Sweep (Acquisition) Time

```
[ :SENSe ]:WAVEform:SWEep:TIME <time>
```

```
[ :SENSe ]:WAVEform:SWEep:TIME?
```

Set the measurement acquisition time. It is used to specify the length of the time capture record.

Factory Preset: 2.0 ms

10.0 ms, for NADC, PDC

Range: 1 μ s to 100 s

Default Unit: seconds

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRument:SElect to set the mode.

Waveform—Trigger Source

```
[ :SENSe]:WAVeform:TRIGger:SOURce EXTernal[1] |
EXTernal2 | FRAMe | IF | IMMEDIATE | LINE | RFBurst
```

```
[ :SENSe]:WAVeform:TRIGger:SOURce?
```

Select the trigger source used to control the data acquisitions.

EXTernal 1 - front panel external trigger input

EXTernal 2 - rear panel external trigger input

FRAMe - internal frame timer from front panel input

IF - internal IF envelope (video) trigger

IMMEDIATE - the next data acquisition is immediately taken (also called free run)

LINE - internal line trigger

RFBurst - wideband RF burst envelope trigger that has automatic level control for periodic burst signals

Factory Preset: IMMEDIATE (free run), for Basic, cdmaOne, NADC, PDC mode

RFBurst, for GSM mode

Remarks: You must be in the Basic, cdmaOne, cdma2000, W-CDMA, GSM, EDGE, NADC, or PDC mode to use this command. Use INSTRUMENT:SElect to set the mode.

TRIGger Subsystem

The Trigger Subsystem is used to set the controls and parameters associated with triggering the data acquisitions. Other trigger-related commands are found in the INITiate and ABORt subsystems.

The trigger parameters are global within a selected Mode. The commands in the TRIGger subsystem set up the way the triggers function, but selection of the trigger source is made from each measurement. There is a separate trigger source command in the SENSE:<meas> subsystem for each measurement. The equivalent front panel keys for the parameters described in the following commands, can be found under the **Mode Setup, Trigger** key.

Automatic Trigger Control

```
:TRIGger[:SEQuence]:AUTO:STATE OFF|ON|0|1
```

```
:TRIGger[:SEQuence]:AUTO:STATE?
```

Turns the automatic trigger function on and off. This function causes a trigger to occur if the designated time has elapsed and no trigger occurred. It can be used with unpredictable trigger sources, like external or burst, to make sure a measurement is initiated even if a trigger doesn't occur. Use TRIGger[:SEQuence]:AUTO[:TIME] to set the time limit.

Factory Preset
and *RST Off for cdma2000, W-CDMA, NADC, PDC, 1xEV-DO

Front Panel
Access **Mode Setup, Trigger, Auto Trig**

Automatic Trigger Time

```
:TRIGger[:SEQuence]:AUTO[:TIME] <time>
```

```
:TRIGger[:SEQuence]:AUTO[:TIME]?
```

After the measurement is activated the instrument will take a data acquisition immediately upon receiving a signal from the selected trigger source. If no trigger signal is received by the end of the time specified in this command, a data acquisition is taken anyway. TRIGger[:SEQuence]:AUTO:STATE must be on.

Factory Preset: 100.0 ms

Range: 1.0 ms to 1000.0 s
 0.0 to 1000.0 s for cdma2000, W-CDMA, 1xEV-DO

Default Unit: seconds

External Trigger Delay

`:TRIGger[:SEquence]:EXTErnal[1]|2:DELay <time>`

`:TRIGger[:SEquence]:EXTErnal[1]|2:DELay?`

Set the trigger delay when using an external trigger. Set the trigger value to zero (0) seconds to turn off the delay.

EXT or EXT1 is the front panel trigger input

EXT2 is the rear panel trigger input

Factory Preset: 0.0 s

Range: -100.0 ms to 100.0 ms

-100.0 ms to 500.0 ms for 1xEV-DO

Default Unit: seconds

Front Panel

Access: **Mode Setup, Trigger, Ext Rear (or Ext Front), Delay**

External Trigger Level

`:TRIGger[:SEquence]:EXTErnal[1]|2:LEVEl <voltage>`

`:TRIGger[:SEquence]:EXTErnal[1]|2:LEVEl?`

Set the trigger level when using an external trigger input.

EXT or EXT1 is the front panel trigger input

EXT2 is the rear panel trigger input

Factory Preset: 2.0 V

Range: -5.0 to +5.0 V

Default Unit: volts

Front Panel

Access: **Mode Setup, Trigger, Ext Rear, Level**

Mode Setup, Trigger, Ext Front, Level

External Trigger Slope

```
:TRIGger[:SEquence]:EXTernal[1]|2:SLOPE NEGative|POSitive
```

```
:TRIGger[:SEquence]:EXTernal[1]|2:SLOPe?
```

Sets the trigger slope when using an external trigger input.

EXT or EXT1 is the front panel trigger input

EXT2 is the rear panel trigger input

Factory Preset: Positive

Front Panel

Access: Mode Setup, Trigger, Ext Rear (or Ext Front), Slope

Frame Trigger Adjust

```
:TRIGger[:SEquence]:FRAMe:ADJust <time>
```

Lets you advance the phase of the frame trigger by the specified amount. It does not change the period of the trigger waveform. If the command is sent multiple times, it advances the phase of the frame trigger more each time it is sent.

Factory Preset: 0.0 s

Range: 0.0 to 10.0 s

Default Unit: seconds

Front Panel

Access: None

Frame Trigger Period

```
:TRIGger[:SEquence]:FRAMe:PERiod <time>
```

```
:TRIGger[:SEquence]:FRAMe:PERiod?
```

Set the frame period that you want when using the external frame timer trigger. If the traffic rate is changed, the value of the frame period is initialized to the preset value.

Factory Preset: 250.0 μ s for Basic, cdmaOne

4.615383 ms, for GSM

26.666667 ms for cdma2000 and 1xEV-DO

10.0 ms (1 radio frame) for W-CDMA

20.0 ms with rate=full for NADC, PDC

40.0 ms with rate=half for NADC, PDC

PDC Programming Commands

TRIGger Subsystem

Range: 0.0 ms to 559.0 ms for Basic, cdmaOne, GSM, cdma2000, W-CDMA, 1xEV-DO
1.0 ms to 559.0 ms for NADC, PDC

Default Unit: seconds

Front Panel

Access: Mode Setup, Trigger, Frame Timer, Period

Frame Trigger Sync Source

```
:TRIGger[:SEquence]:FRAME:SYNC EXTFront|EXTRear|OFF
```

```
:TRIGger[:SEquence]:FRAME:SYNC?
```

Selects the input port location for the external frame trigger that you are using.

Factory Preset: Off

Remarks: You must be in the Basic, cdmaOne, EDGE (w/GSM), GSM, NADC, PDC, Service mode to use this command. Use INSTRument:SElect to set the mode.

Front Panel

Access: Mode Setup, Trigger, Frame Timer, Sync Source

History Changed firmware revision A.05.00.

Frame Trigger Synchronization Offset

```
:TRIGger[:SEquence]:FRAME:SYNC:OFFSet <time>
```

```
:TRIGger[:SEquence]:FRAME:SYNC:OFFSet?
```

Lets you adjust the frame triggering with respect to the external trigger input that you are using.

Factory Preset: 0.0 s

Range: 0.0 to 10.0 s

Default Unit: seconds

Remarks: You must be in the Basic, cdmaOne, GSM, EDGE, NADC, PDC, Service mode to use this command. Use INSTRument:SElect to set the mode.

History: Revision A.03.27 or later

Front Panel

Access: Mode Setup, Trigger, Frame Timer, Offset

Trigger Holdoff

:TRIGger[:SEquence]:HOLDoff <time>

:TRIGger[:SEquence]:HOLDoff?

Set the holdoff time between triggers. After a trigger, another trigger will not be allowed until the holdoff time expires. This parameter affects all trigger sources.

Factory Preset: 0.0 s

10.0 ms for NADC or PDC

Range: 0.0 to 500.0 ms

Default Unit: seconds

Front Panel

Access: **Mode Setup, Trigger, Trig Holdoff**

Video (IF) Trigger Delay

:TRIGger[:SEquence]:IF:DELay <time>

:TRIGger[:SEquence]:IF:DELay?

Set the trigger delay when using the IF (video) trigger (after the Resolution BW filter).

Factory Preset: 0.0 s

Range: -100.0 ms to 500.0 ms

-100.0 ms to 100.0 ms for cdma2000, W-CDMA

Default Unit: seconds

Front Panel

Access: **Mode Setup, Trigger, Video (IF Envlp), Delay**

Video (IF) Trigger Level

:TRIGger[:SEquence]:IF:LEVel <amp;l>

:TRIGger[:SEquence]:IF:LEVel?

Set the trigger level when using the IF (video) trigger.

Factory Preset: -6.0 dBm for cdmaOne, GSM, EDGE, Basic,
cdma2000, W-CDMA, 1xEV-DO

-30.0 dBm for NADC, PDC

Range: -200.0 to 50.0 dBm

PDC Programming Commands
TRIGger Subsystem

Default Unit: dBm

Front Panel

Access: **Mode Setup, Trigger, Video (IF Envlp), Level**

Video (IF) Trigger Slope

`:TRIGger[:SEquence]:IF:SLOPe NEGative|POSitive`

`:TRIGger[:SEquence]:IF:SLOPe?`

Sets the trigger slope when using the IF (video) trigger.

Factory Preset: Positive

Front Panel

Access: **Mode Setup, Trigger, Video (IF Envlp), Slope**

RF Burst Trigger Delay

`:TRIGger[:SEquence]:RFBurst:DELAy <time>`

`:TRIGger[:SEquence]:RFBurst:DELAy?`

Set the trigger delay when using the RF burst (wideband) trigger.

Factory Preset: 0.0 s

Range: -100.0 ms to 500.0 ms

Default Unit: seconds

Front Panel

Access: **Mode Setup, Trigger, RF Burst, Delay**

RF Burst Trigger Level

`:TRIGger[:SEquence]:RFBurst:LEVel <rel_power>`

`:TRIGger[:SEquence]:RFBurst:LEVel?`

Set the trigger level when using the RF Burst (wideband) Trigger. The value is relative to the peak of the signal. RF Burst is also known as RF Envelope.

Factory Preset: -6.0 dB

Range: -25.0 to 0.0 dB

-200.0 to 0.0 dB for NADC, PDC

Default Unit: dB

Front Panel

Access: **Mode Setup, Trigger, RF Burst, Peak Level**

RF Burst Trigger Slope

`:TRIGger[:SEQuence]:RFBurst:SLOPe` **NEGative|POSitive**

`:TRIGger[:SEQuence]:RFBurst:SLOPe?`

Set the trigger slope when using the RF Burst (wideband) Trigger.

Factory Preset: Positive

Remarks: You must be in the cdmaOne, cdma2000, W-CDMA mode to use this command. Use `:INSTrument:SElect` to set the mode.

Front Panel

Access: **Mode Setup, Trigger, RF Burst, Slope**

PDC Programming Commands
TRIGger Subsystem

9 Specifications

NADC Specifications

All specifications apply:

- Over 0°C to +55°C, except when otherwise specified.
- Within the in-band frequency ranges documented on page 400.
- After 2 hours of storage at a constant temperature, within the operating temperature range, 1 hour after the instrument is turned on and within 24 hours after “Align All Now” has been run.

Because digital communications signals are noise-like, all measurements will have variations. The specifications apply only with adequate averaging to remove those variations

Measurements

Measurement	Specifications	Supplemental Information
Adjacent Channel Power Ratio Minimum Power at RF Input ACPR Dynamic Range At 30 kHz offset ^a At 60 kHz offset At 90 kHz offset ACPR Relative Accuracy	 ± 0.08 dB ^b	-50 dBm (nominal) 74 dB (nominal) 77 dB (nominal)
Error Vector Magnitude (EVM) Minimum Power at RF Input EVM Range Floor Accuracy ^c Frequency Error Accuracy I/Q Origin offset Range	 0.5%	-45 dBm (nominal) 0 to 18% (nominal) $\pm 0.6\%$ (nominal) ± 2.0 Hz (nominal) + (transmitter frequency \times frequency reference accuracy) -10 to -50 dBc (nominal)
Spectrum	See Spectrum on page 410	
Waveform (Time Domain)	See Waveform on page 411	

- a. An ideal NADC signal, filtered by a perfect root-raised-cosine filter, shows about -35.4 dB ACPR at the 30 kHz offset. The added noise power due to intermodulation distortions and phase noise in the analyzer is well below this level. Therefore, measurement accuracy at 30 kHz offset is not significantly impacted by the dynamic range of the analyzer.
- b. The specified ACPR accuracy applies if the measured ACPR substantially exceeds the analyzer dynamic range at the specified offset. At the nominal test limits for the offsets (-26, -45 and -45 dBc for 30, 60 and 90 kHz offsets respectively), for RF power above -25 dBm, this condition is met. When this condition is not met, there are additional errors due to the addition of analyzer spectral components to UUT spectral components. The spectral components from the analyzer will be non-coherent with the components from the UUT at the 60 and 90 kHz offsets. Because of this, the errors add in a power sense. The error is a function of the signal (UUT ACPR) to noise (analyzer ACPR dynamic range limitation) ratio, SN, in decibels.
 The function is: $\text{error} = 10 \times \log(1 + 10^{(-SN/10)})$
 For example, if the UUT ACPR is -64 dB and the measurement floor is -74 dB, the SN ratio is 10 dB and the error due to adding the analyzer's noise to that of the UUT is 0.41 dB

Specifications
NADC Specifications

- c. The accuracy specification applies when the EVM to be measured is well above the measurement floor. When the EVM does not greatly exceed the floor, the errors due to the floor add to the accuracy errors. The errors due to the floor are noise-like and add incoherently with the UUT EVM. The errors depend on the EVM of the UUT and the floor as follows: $\text{error} = \sqrt{\text{EVMUUT}^2 + \text{EVMsa}^2} - \text{EVMUUT}$, where EVMUUT is the EVM of the UUT in percent, and EVMsa is the EVM floor of the analyzer in percent. For example, if the EVM of the UUT is 7%, and the floor is 2.5%, the error due to the floor is 0.43%.

Frequency

Description	Specifications	Supplemental Information
In-Band Frequency Range		
Cellular Band	824 to 849 MHz 869 to 894 MHz	
PCS Band	1850 to 1910 MHz 1930 to 1990MHz	

General

Description	Specifications	Supplemental Information
<p>Trigger</p> <p>Trigger source</p> <p>Trigger delay, level, and slope</p> <p>Trigger delay Range Repeatability Resolution</p> <p>External trigger inputs Level Impedance</p>	<p>–500 to +500 ms ±33 ns 33 ns</p>	<p>RF burst (wideband), Video (IF envelope), Ext Front, Ext Rear. Actual available choices dependent on measurement.</p> <p>Each trigger source has a separate set of these parameters.</p> <p>–5V to +5V (nominal) > 10 kΩ (nominal)</p>
<p>Range Control</p>		<p>RF Input Autorange^a Manually set Max Total Pwr Manually set Input Atten</p>

- a. Autorange is *not* continuous with each measurement acquisition; it will run only once immediately following a measurement restart, initiated either by pressing the **Restart** hardkey, or by sending the GPIB command `INIT:IMM`. This behavior was chosen to maintain best measurement speed, but it requires caution when input power levels change.

If the input signal power changes, the analyzer will not readjust the input attenuators for optimal dynamic range unless a measurement restart is initiated. For example, if a sequence of power measurements is made, beginning with a maximum power level that is large enough to require non-zero input attenuation, it is advisable to do a measurement restart to automatically set a lower input attenuator value to maintain optimal dynamic range for approximately every 3 dB the input signal power level is reduced, or smaller, depending upon how precisely dynamic range needs to be optimized. Conversely, if the input signal power increases to a high enough level, input overloading will occur if the input attenuators are not readjusted by doing a measurement restart.

PDC Specifications

All specifications apply:

- Over 0°C to +55°C, except when otherwise specified.
- Within the in-band frequency ranges documented on page 404.
- After 2 hours of storage at a constant temperature, within the operating temperature range, 1 hour after the instrument is turned on and within 24 hours after “Align All Now” has been run.

Because digital communications signals are noise-like, all measurements will have variations. The specifications apply only with adequate averaging to remove those variations

Measurements

Description	Specifications	Supplemental Information
Adjacent Channel Power Ratio Minimum Power at RF Input ACPR Dynamic Range At 50 kHz offset At 100 kHz offset ACPR Relative Accuracy	 $\pm 0.08 \text{ dB}^a$	-36dBm (nominal) 74 dB (nominal) 78 dB (nominal)
Error Vector Magnitude (EVM) Minimum Power at RF Input EVM Range Floor Accuracy ^b I/Q Origin offset Range Frequency Error Accuracy	 0.5%	-50 dBm (nominal) 0 to 18% (nominal) $\pm 0.6\%$ (nominal) -12 to -50 dBc (nominal) $\pm 2.0 \text{ Hz}$ (nominal) + (transmitter frequency \times frequency reference accuracy)
Occupied Bandwidth Minimum power at RF Input Frequency Resolution Frequency Accuracy	 100 Hz	-60dBm (nominal) -30 to +70 Hz (nominal) ^c

- a. The specified ACPR accuracy applies if the measured ACPR substantially exceeds the analyzer dynamic range at the specified offset. When this condition is not met, there are additional errors due to the addition of analyzer spectral components to UUT spectral components. The spectral components from the analyzer will be noncoherent with the components from the UUT. Because of this, the errors add in a power sense. The error is a function of the signal (UUT ACPR) to noise (analyzer ACPR dynamic range limitation) ratio, SN, in decibels.

The function is: $\text{error} = 10 \times \log(1 + 10^{(-\text{SN}/10)})$

For example, if the UUT ACPR is -64 dB and the measurement floor is -74 dB, the SN ratio is 10 dB and the error due to adding the analyzer's noise to that of the UUT is 0.41 dB.

With the nominal dynamic ranges shown, and with ACP at the nominal test limits of -45 and -60 dB, and with an input RF power well above -18 dBm, the errors due to dynamic range limitations are nominally 0.005 dB at 50 kHz offset and 0.07 dB at 100 kHz offset.

- b. The accuracy specification applies when the EVM to be measured is well above the measurement floor. When the EVM does not greatly exceed the floor, the errors due to the floor add to the accuracy errors. The errors due to the floor are noise-like and add incoherently with the UUT EVM. The errors depend on the EVM of the UUT and the floor as follows: $\text{error} = \sqrt{\text{EVMUUT}^2 + \text{EVMsa}^2} - \text{EVMUUT}$, where EVMUUT is the EVM of the UUT in percent, and EVMsa is the EVM floor of the analyzer in percent. For example, if the EVM of the UUT is 7%, and the floor is 2.5%, the error due to the floor is 0.43%.

Specifications

PDC Specifications

- c. The errors in the Occupied Bandwidth measurement are mostly due to the noisiness of any measurement of a noise-like signal, such as the PDC signal. The observed standard deviation of the OBW measurement is 270 Hz, so with 100 averages, the standard deviation should be well under the display resolution. The frequency errors due to the FFT processing are computed to be only 2.9 Hz with the narrow RBW (140 Hz) used. The sum of observed algorithmic errors and display resolution effects, using non-PDC signals, is the *nominal* shown.

Description	Specifications	Supplemental Information
Spectrum	See Spectrum on page 410.	
Waveform (Time Domain)	See Waveform on page 411.	

Frequency

Description	Specifications	Supplemental Information
In-Band Frequency Range		
800MHz Band #1	810 to 828 MHz 940to 958MHz	
800MHz Band #2	870 to 885 MHz 925 to 940 MHz	
800MHz Band #3	838 to 840 MHz 893 to 895 MHz	
1500 MHz Band	1477 to 1501MHz 1429 to 1453 MHz	

General

Description	Specifications	Supplemental Information
<p>Trigger</p> <p>Trigger source</p> <p>Trigger delay, level, and slope</p> <p>Trigger delay Range Repeatability Resolution</p> <p>External trigger inputs Level Impedance</p>	<p>–500 to +500 ms ±33 ns 33 ns</p>	<p>RF burst (wideband), Video (IF envelope), Ext Front, Ext Rear, Frame Timer. Actual available choices dependent on measurement.</p> <p>Each trigger source has a separate set of these parameters.</p> <p>–5V to +5V (nominal) >10 kΩ (nominal)</p>
<p>Range Control</p>		<p>RF Input Autorange^a Manually set Max Total Pwr Manually set Input Atten</p>

- a. Autorange is *not* continuous with each measurement acquisition; it will run only once immediately following a measurement restart, initiated either by pressing the **Restart** hardkey, or by sending the GPIB command `INIT:IMM`. This behavior was chosen to maintain best measurement speed, but it requires caution when input power levels change.

If the input signal power changes, the analyzer will not readjust the input attenuators for optimal dynamic range unless a measurement restart is initiated. For example, if a sequence of power measurements is made, beginning with a maximum power level that is large enough to require non-zero input attenuation, it is advisable to do a measurement restart to automatically set a lower input attenuator value to maintain optimal dynamic range for approximately every 3 dB the input signal power level is reduced, or smaller, depending upon how precisely dynamic range needs to be optimized. Conversely, if the input signal power increases to a high enough level, input overloading will occur if the input attenuators are not readjusted by doing a measurement restart.

Specifications Applicable to All Digital Comms Personalities

All specifications apply:

- Over 0 to +55°C, except when otherwise specified.
- Within the frequency ranges documented for each personality. Refer to the specs for each individual personality.
- After 2 hours of storage at a constant temperature, within the operating temperature range, 1 hour after the instrument is turned on and within 24 hours after “Align All Now” has been run.

Because digital communications signals are noise-like, all measurements will have variations. The specifications apply only with adequate averaging to remove those variations.

Frequency

Description	Specifications	Supplemental Information
Frequency Range	7 MHz to 3 GHz	

Amplitude

Description	Specifications		Supplemental Information
<p>Frequency Response At all input attenuations. Maximum error relative to reference condition (50 MHz).</p> <p><i>Attenuation = 0 to 2 dB</i></p> <p style="padding-left: 40px;">7 to 810 MHz</p> <p style="padding-left: 40px;">810 to 960 MHz</p> <p style="padding-left: 40px;">960 to 1428 MHz</p> <p style="padding-left: 40px;">1428 to 1503 MHz</p> <p style="padding-left: 40px;">1503 to 1710 MHz</p> <p style="padding-left: 40px;">1710 to 2205 MHz</p> <p style="padding-left: 40px;">2205 to 3000 MHz</p> <p><i>Attenuation ≥ 3 dB</i></p> <p style="padding-left: 40px;">7 to 810 MHz</p> <p style="padding-left: 40px;">810 to 960 MHz</p> <p style="padding-left: 40px;">960 to 1428 MHz</p> <p style="padding-left: 40px;">1428 to 1503 MHz</p> <p style="padding-left: 40px;">1503 to 1710 MHz</p> <p style="padding-left: 40px;">1710 to 2205 MHz</p> <p style="padding-left: 40px;">2205 to 3000 MHz</p>	<p>+20 to +30°C</p>	<p>0 to +55°C</p>	<p>Typical</p> <p>±0.60 dB</p> <p>±0.22 dB</p> <p>±0.22 dB</p> <p>±0.15 dB</p> <p>±0.22 dB</p> <p>±0.15 dB</p> <p>±0.66 dB</p> <p>±0.28 dB</p> <p>±0.15 dB</p> <p>±0.22 dB</p> <p>±0.15 dB</p> <p>±0.22 dB</p> <p>±0.15 dB</p> <p>±0.50 dB</p>
<p>Electronic Input Attenuator</p> <p>Range</p> <p>Step size</p> <p>Accuracy at 50 MHz +20°C to +30°C</p>	<p>0 to +40 dB</p> <p>1 dB steps</p> <p>±0.15 dB relative to 10 dB electronic attenuation</p>		<p>The standard mechanical input attenuator is locked to 6 dB when using the electronic input attenuator.</p> <p>±0.05 dB (typical)</p>

Specifications

Specifications Applicable to All Digital Comms Personalities

Description	Specifications	Supplemental Information
<p>Absolute Amplitude Accuracy Excluding: mismatch, scalloping, and IF flatness^a Including: linearity, RBW switching, attenuator,^b differences from swept^c</p> <p>Freq. tuned to the input CW freq.</p>		
At 50 MHz, +20°C to +30°C	±0.25 dB	±0.10 dB (typical)
At 50 MHz, all temperatures	±0.33 dB	
50 MHz Amplitude Ref. Accuracy		±0.05 dB (nominal)
At all frequencies (Absolute amplitude accuracy at 50 MHz + Frequency Response)		
+20°C to +30°C	±(0.25 dB + frequency response)	±(0.10 dB + frequency response) (typical)
0°C to +55°C	±(0.33 dB + frequency response)	

- a. Absolute amplitude error does not include input mismatch errors. It is tested only when the analyzer center frequency is tuned to the input CW frequency. In this test condition, the effects of FFT scalloping error and IF Flatness do not apply. FFT scalloping error, the possible variation in peak level as the signal frequency is varied between FFT bins, is a mathematical parameter of the FFT window; it is under 0.01 dB for the flattop window. IF flatness, the variation in measured amplitude with signal frequency variations across the span of an FFT result, is not specified separately for the digital communications personalities, but the errors caused by IF flatness are included in all individual personality specifications.
- b. Absolute amplitude error is tested at a combination of signal levels, spans, bandwidths and input attenuator settings. As a result, it is a measure of the sum of many errors normally specified separately for a spectrum analyzer: detection linearity (also known as scale or log fidelity), RBW switching uncertainty, attenuator switching uncertainty, IF gain accuracy, Amplitude Calibrator accuracy, and the accuracy with which the analyzer aligns itself to its internal calibrator.
- c. The Absolute Amplitude Accuracy for digital communications personalities differs from the Absolute Amplitude Accuracy given in the PSA Specifications Guide. The specification given here is more complete in that it applies to all settings of the electronic attenuator, with the mechanical attenuator locked in its 6 dB setting, whereas the non-personalities specification applies to only one attenuation setting -- the mechanical attenuator set to 10 dB.

Specifications

Specifications Applicable to All Digital Comms Personalities

Measurements

These specifications apply to the measurements available in Basic Mode.

Measurement	Specifications	Supplemental Information
Spectrum		
Range at RF Input Maximum Minimum	Refer to PSA Specifications Guide	
Span range	10 Hz to 10 MHz	1, 1.5, 2, 3, 5, 7.5, 10 sequence or arbitrary user-definable
Capture time		66 ns to 40s 2 points to 200k points Coupled to span and RBW
Resolution BW range Overall	100 mHz to 1 MHz	1, 1.5, 2, 3, 5, 7.5, 10 sequence or arbitrary user-definable
Span = 10 MHz	3 kHz to 1 MHz	
Span = 100 kHz	30 Hz to 500 kHz	
Span = 1 kHz	400 mHz to 7.5 kHz	
Span = 100 Hz	100 mHz to 2 kHz	
Pre-FFT filter Type BW	Gaussian, Flat Auto, Manual 1 Hz to 10 MHz	
FFT window	Flat Top (high amplitude accuracy); Uniform; Hanning; Hamming; Gaussian; Blackman; Blackman-Harris; Kaiser-Bessel 70; K-B 90; K-B 110	
Averaging Avg number Avg mode Avg type	1 to 10,000 Exponential, Repeat Power Avg (RMS), Log-Power Avg (Video), Voltage Avg, Maximum, Minimum	
Displays	Spectrum, I/Q waveform, Simultaneous Spectrum & I/Q waveform	
Y-axis display Controls	Scale/Div, Ref Value, and Ref Position	Allows expanded views of portions of the trace data
Markers	Normal, Delta, Band Power, Noise	
Trigger Source	Free Run (immediate), Video (IF envelope), RF Burst (wideband), Ext Front, Ext Rear, Frame, Line	
Delay, Holdoff, & Auto		See Trigger on page 412

Measurement	Specifications	Supplemental Information
Waveform		
Range at RF Input Maximum Minimum	Refer to PSA Specifications Guide	
Sweep time range ^a RBW ≤ 7.5 MHz RBW ≤ 1 MHz RBW ≤ 100 kHz RBW ≤ 10 kHz	10 μs to 200 ms 10 μs to 400 ms 10 μs to 2s 10 μs to 20s	
Time record length		2 to >900k points (nominal)
Resolution bandwidth filter Gaussian Flat Top Frequency response	10 Hz to 8 MHz 10 Hz to 10 MHz	1, 1.5, 2, 3, 5, 7.5, 10 sequence or arbitrary user-definable ±0.25 dB over 8 MHz (nominal) –3 dB rolloff bandwidth is 10 MHz (nominal)
Averaging Avg Number Avg Mode Avg Type	1 to 10,000 Exponential, Repeat Power Avg (RMS), Log-power Avg (Video), Maximum, Minimum	
Displays	RF envelope, I/Q waveform	
Y-axis display Controls	Scale/Div, Ref Value, and Ref Position	Allows expanded views of portions of the trace data.
X-axis display Range Controls	10 divisions × scale/div Scale/Div, Ref Value, and Ref Position	Allows expanded views of portions of the trace data.
Markers	Normal, Delta, Band Power, Noise	
Trigger Source	Free Run (immediate), Video (IF envelope), RF Burst (wideband), Ext Front, Ext Rear, Frame, Line	
Delay, Holdoff, and Auto		See Trigger on page 412

a. The maximum available sweep time range is proportional to the setting of the decimation (Meas Setup > Advanced > Decimation).
The limits shown are for decimation = 4, the maximum allowed. The default for decimation is 1.

Specifications
Specifications Applicable to All Digital Comms Personalities

Measurement	Specifications	Supplemental Information
Both Spectrum and Waveform		
Trigger		
Trigger delay		For Video, RF Burst, Ext Front, Ext Rear
Range	-500 ms to +500 ms	
Repeatability	±33 ns	
Resolution	33 ns	
Trigger slope	Positive, Negative	
Trigger holdoff		
Range	0 to 500 ms	
Resolution	1 μs	
Auto trigger	On, Off	
Time interval range		0 to 10s (nominal) Does an immediate trigger if no trigger occurs before the set time interval.
RF burst trigger		Wideband IF for repetitive burst signals.
Peak carrier power range at RF Input	+27 dBm to -40 dBm	
Trigger level range	0 to -25 dB	Relative to signal peak
Bandwidth		>15 MHz (nominal)
Video (IF envelope) trigger		
Range	+30 dBm to noise floor	
Measurement Control		Single, Continuous, Restart, Pause, Resume

Inputs and Outputs

Front Panel

Description	Specifications	Supplemental Information
RF INPUT VSWR (with electronic attenuator) 7 MHz to 3 GHz < 2 dB input attenuation ≥ 2 dB input attenuation		< 1.3:1 (nominal) < 1.2:1 (nominal)

Rear Panel

Description	Specifications	Supplemental Information
321.4 MHz IF OUT Conversion Gain (Input Attenuator = 0 dB) Tuned Frequency 50 MHz 600 MHz 1000 MHz 2500 MHz 3000 MHz		+2.0 dB (nominal) +2.0 dB (nominal) +2.0 dB (nominal) +1.7 dB (nominal) +1.7 dB (nominal)

Specifications
Specifications Applicable to All Digital Comms Personalities

Index

- A**
- absolute limit
 - ACP, 168, 352
 - ACP
 - absolute limits, 168, 352
 - limit testing, 108, 169, 290
 - offset frequencies, 170, 354
 - relative limits, 169, 353
 - trigger source, 171, 354
 - view of data, 131, 314
 - ACP Meas Setup keys, 46, 224, 226
 - ACP View/Trace keys, 46, 224, 226
 - ACPR
 - testing choices, 171, 355
 - acquisition packing
 - WAVEform, 196, 382
 - active license key, 56, 237
 - how to locate, 56, 237
 - ADC Dither key
 - spectrum measurement, 86, 270
 - ADC dithering
 - SPECTrum, 183, 369
 - WAVEform, 196, 382
 - ADC filter
 - WAVEform, 196, 382
 - ADC range
 - SPECTrum, 184, 370
 - WAVEform, 197, 383
 - ADC Range key
 - spectrum measurement, 85, 269
 - ADC ranging function
 - automatic control, 95, 277
 - automatic peak control, 95, 277
 - automatic peak lock, 95, 277
 - manual control, 95, 277
 - adjacent channel power
 - measuring, 67, 74, 247, 261
 - adjacent channel power
 - measurement, 167, 351
 - adjacent channel power ratio
 - measurement, 152, 167, 335, 351
 - See also ACPR
 - Advanced menu
 - spectrum, 84, 268
 - waveform, 94, 276
 - advanced menu
 - ADC dither, 95, 277
 - ADC ranging function, 95, 277
 - decimation, 96, 278
 - pre-ADC bandpass filter, 95, 277
 - resolution bandwidth filter, 95, 277
 - Amp Y Scale keys
 - Occupied BW, 228
 - Waveform, 52, 224, 232
 - amplitude
 - input range, 180, 366
 - maximizing input signal, 180, 366
 - applications
 - currently available, 145, 328
 - applications, selecting, 145, 146, 328, 329
 - ASCII data format, 141, 324
 - attenuation
 - setting, 180, 366
 - averaging
 - ACP, 167, 168, 351, 352
 - ACPR, 167, 168, 351, 352
 - CHPower, 363, 364
 - EVM, 176, 359
 - OBW, 363
 - SPECTrum, 185, 186, 371, 372
 - traces, 364
 - transmit band spurs, 197, 383
 - WAVEform, 198, 199, 384, 385
- B**
- bandwidth
 - SPECTrum, 188, 189, 374, 375
 - WAVEform, 199, 200, 385, 386
 - base station
 - loss correction, 175, 358
 - base station testing, 182, 368
 - basic mode, 53, 234
 - binary data order, 141, 324
 - burst synchronization, 177, 360
 - burst trigger
 - level, 208, 394
 - byte order of data, 141, 324
- C**
- CDMA measurement, 167, 351
 - cdma2000 measurement, 152, 167, 335, 345, 351, 363
 - cdmaOne measurement, 152, 335
 - changing
 - instrument settings, 167, 351
 - Choose Option key, 56, 237
 - code, programming
 - compatibility across PSA modes, 103, 105, 285, 287
 - compatibility, PSA series versus VSA, 106, 288
 - commands
 - compatibility across PSA modes, 103, 105, 285, 287
 - CONFigure, 149, 332
 - FETCh, 150, 333
 - MEASure, 148, 331
 - PSA series versus VSA
 - compatibility, 106, 288
 - READ, 151, 333
 - compatibility, programming across PSA modes, 103, 285
 - PSA series versus VSA, 106, 288
 - CONFigure command use, 148, 331
 - CONFigure commands, 149, 332
 - continuous vs. single
 - measurement mode, 143, 326
 - control measurement commands, 143, 326
 - correction
 - base station loss, 175, 358
 - mobile station loss, 175, 358
 - current measurement, 130, 313
 - curve fit the data, 109, 116, 291, 298
- D**
- data
 - querying, 108, 109, 116, 290, 291, 298
 - data decimation, 189, 375
 - WAVEform, 200, 201, 386, 387
 - data format, 141, 324
 - data from measurements, 148, 331
 - Data Packing
 - spectrum measurement, 86, 95, 270, 277
 - Decimation
 - spectrum measurement, 86, 270
 - decimation
 - SPECTrum, 189, 375
 - decimation of data
 - WAVEform, 200, 201, 386, 387
 - default states, 36, 216
 - default values, setting remotely, 149, 332
 - deleting an
 - application/personality, 54, 235
 - delta markers, 121, 123, 303, 305
 - display
 - spectrum window, 132, 133, 138, 315, 316, 321
 - tiling, 132, 315
 - trace, 134, 317
 - window tile, 132, 315
 - zoom, 132, 315
 - display ACP data, 131, 314
 - display commands, 131, 314
 - display EVM data, 131, 314
 - Display keys

Index

- EVM, 47, 224, 227
- dithering of ADC
 - WAVEform, 196, 382
- dithering the ADC, 183, 369
- E**
- error vector magnitude
 - measuring, 254
- error vector magnitude
 - measurement, 158, 176, 341, 359
- error vector measurement
 - See also EVM
- EVM
 - averaging, 176, 359
 - burst synchronization, 177, 360
 - limit testing, 117, 118, 299, 300
 - points per symbol, 177, 360
 - sync word, 118, 300
 - trigger source, 178, 361
 - view of data, 131, 314
- EVM Display keys, 47, 224, 227
- EVM Meas Setup keys, 47, 224, 227
- EVM View/Trace keys, 47, 224, 227
- external trigger
 - delay, 204, 390
 - level, 204, 390
 - slope, 205, 391
- F**
- FETCh command use, 148, 331
- FETCh commands, 150, 333
- FFT
 - SPECTrum, 190, 191, 192, 376, 377, 378
- FFT bandwidth, SPECTrum, 187, 188, 373, 374
- FFT Length key, 85, 269
- FFT Size menu, 85, 269
- FFT Window key., 84, 268
- format, data, 141, 324
- frame trigger adjustment, 205, 206, 391, 392
- frame trigger period, 205, 391
- frame trigger sync mode, 206, 392
- frequencies offset
 - ACP, 170, 354
- frequency band limits
 - OBW, 312
- frequency span
 - SPECTrum, 193, 379
- front panel key map, 45, 46, 47, 48, 49, 50, 51, 52, 224, 225, 226, 227, 228, 229, 231, 232
- I**
- I or Q waveform window
 - span X scale
 - reference position, 97, 279
 - reference value, 97, 279
 - scale coupling, 98, 280
 - scale per division, 97, 279
- I waveform window
 - amplitude Y scale, 98, 280
 - reference position, 98, 280
 - scale coupling, 98, 281
 - scale per division, 98, 280
- I/Q data output, 53, 234
- I/Q data results, 162, 164, 346, 348
- I/Q waveform view
 - I/Q waveform window, 98, 280
- I/Q waveform window, 97, 98, 279, 280
 - amplitude Y scale, 98, 280
 - reference position, 98, 280
 - reference value, 98, 280
 - scale coupling, 98, 281
 - scale per division, 98, 280
- iDEN
 - trigger source, 365
- iDEN averaging, 176, 359
- iDEN limit testing, 169
- iDEN measurement, 345, 363
- iDEN offset frequencies, 170, 354
- iDEN trigger source, 171, 178, 354, 361
- IF Flatness
 - advanced spectrum feature, 86, 270
- IF trigger delay, 207, 393
- IF trigger level, 207, 393
- IF trigger slope, 208, 394
- initiate measurement, 143, 144, 326, 327
- input attenuation, 180, 366
- input port selection, 179, 362
- input power
 - maximum, 180, 366
 - range, 180, 366
- Install Now key, 56, 237
- installing measurement
 - personalities, 54, 235
- instrument configuration, 145, 328
- internal reference selection, 179, 362
- IQ port selection, 179, 362
- K**
- key map
 - ACP Meas Setup, 46, 224, 226
 - ACP View/Trace, 46, 224, 226
 - EVM Display, 47, 224, 227
 - EVM Meas Setup, 47, 224, 227
 - EVM View/Trace, 47, 224, 227
 - NADC Mode Setup, 45, 224
 - Occupied BW Amp Y Scale, 228
 - PDC Mode Setup, 225
 - Spectrum Marker, 50, 224, 231
 - Spectrum View/Trace, 50, 224, 231
 - Waveform Amp Y Scale, 52, 224, 232
 - Waveform Marker, 52, 224, 232
 - Waveform Span X Scale, 52, 224, 232
 - Waveform View/Trace, 51, 224, 232
- L**
- Length Ctrl key, 85, 269
- Length key, 85, 269
- limit line testing, 108, 290
- limit testing
 - ACP, 108, 168, 169, 290, 352, 353
 - EVM, 117, 118, 299, 300
 - NADC, 108, 117, 118, 290, 299, 300
 - OBW, 312
 - PDC, 108, 117, 118, 290, 299, 300
- linear envelope window, 97, 98, 279, 280
- linear spectrum window
 - amplitude Y scale, 88, 271
 - reference position, 88, 272
 - reference value, 88, 272
 - scale coupling, 88, 272
 - scale per division, 88, 271
 - Span key, 88, 271
- loading an
 - application/personality, 54, 235
- M**
- making measurements, 148, 331
- Marker keys
 - Spectrum, 50, 224, 231
 - Waveform, 52, 224, 232
- markers, 119, 301
 - assigning them to traces, 124, 306
 - maximum, 122, 304
 - minimum, 123, 305
 - off, 124, 306

Index

- trace assignment, 128, 129, 310, 311
- turn off, 121, 303
- type, 121, 123, 303, 305
- valid measurement, 119, 301
- value, 129, 311
- value of, 122, 304
- x-axis location, 128, 129, 310, 311
- y-axis, 129, 311
- maximum value of trace data, 109, 116, 291, 298
- mean value of trace data, 109, 116, 291, 298
- Meas Setup keys
 - ACP, 46, 224, 226
 - EVM, 47, 224, 227
 - Occupied BW
 - key map
 - Occupied BW Meas Setup, 228
 - Spectrum
 - key map
 - Spectrum Meas Setup, 48, 49, 224, 229, 231
- Waveform
 - key map
 - Waveform Meas Setup, 51, 224, 232
- MEASure command use, 148, 331
- MEASure commands, 148, 331
- measurement
 - adjacent channel power, 167, 351
 - adjacent channel power ratio, 167, 351
 - error vector magnitude, 176, 359
 - markers, 119, 301
 - occupied BW, 363
 - query current, 130, 313
 - spectrum
 - display, 89, 272
 - spectrum (frequency domain), 183, 369
 - waveform (time domain), 196, 382
- measurement modes
 - currently available, 145, 328
 - selecting, 145, 146, 328, 329
- measurements
 - adjacent channel power ratio, 152, 335
 - CONF/FETC/MEAS/READ
 - commands, 148, 331
 - control of, 143, 326
 - error vector magnitude, 158, 341
 - getting results, 148, 331
 - occupied BW, 345
 - setting default values remotely, 149, 332
 - single/continuous, 143, 326
 - spectrum (frequency domain), 162, 346
 - waveform (time domain), 164, 348
- measuring I/Q data, 162, 164, 346, 348
- Min Pts in RBW key, 85, 269
- minimum value of trace data, 109, 116, 291, 298
- mobile station
 - loss correction, 175, 358
- mobile station testing, 182, 368
- Mode Setup keys
 - NADC, 45, 224
 - PDC, 225
- N**
- NADC
 - averaging, 176, 359
 - burst power threshold, 195, 381
 - limit testing, 168, 169, 352, 353
 - offset frequencies, 170, 354
 - trigger source, 171, 178, 354, 361
- NADC measurement, 158, 167, 176, 341, 351, 359
- NADC Mode Setup keys, 45, 224
- normal marker, 121, 123, 303, 305
- O**
- OBW
 - limit testing, 312
 - trigger source, 365
- OBW averaging, 363
- Occupied BW Amp Y Scale keys, 228
- Occupied BW Meas Setup keys, 228
- occupied BW measurement, 345, 363
 - See also OBW
- offset frequencies
 - ACP, 170, 354
- P**
- packing
 - SPECTrum, 183, 369
- pass/fail test, 108, 290
- PDC
 - averaging, 176, 359
 - burst power threshold, 195, 381
 - limit testing, 168, 169, 352, 353
 - offset frequencies, 170, 354
 - trigger source, 171, 178, 354, 361, 365
- PDC measurement, 158, 167, 176, 341, 345, 351, 359, 363
- PDC Mode Setup keys, 225
- personalities
 - currently available, 145, 328
 - selecting, 145, 146, 328, 329
- phase window, 97, 98, 279, 280
- points per symbol
 - EVM, 177, 360
- pre-ADC bandpass filter
 - SPECTrum, 187, 373
- Pre-ADC BPF key
 - spectrum measurement, 84, 268
- pre-FFT bandwidth, SPECTrum, 187, 188, 373, 374
- Pre-FFT BW key, 84, 268
- Pre-FFT Fltr key, 84, 268
- preset states, 36, 216
- programming
 - compatibility among PSA
 - modes, 103, 105, 285, 287
 - compatibility, PSA series versus VSA, 106, 288
 - PSA series versus VSA
 - (programming compatibility), 106, 288
- Q**
- Q waveform window
 - amplitude Y scale, 98, 280
 - reference position, 98, 280
 - reference value, 98, 280
 - scale coupling, 98, 281
 - scale per division, 98, 280
- query data, 108, 109, 116, 290, 291, 298
- R**
- READ command use, 148, 331
- READ commands, 151, 333
- real number data format, 141, 324
- rear panel external trigger
 - delay, 204, 390
 - slope, 205, 391
- reference, selecting internal, 179, 362
- relative limit
 - ACP, 169, 353

Index

- Res BW key
 - spectrum measurement, 84, 268
 - waveform measurement, 94, 276
- restart measurement, 144, 327
- return data, 108, 109, 116, 290, 291, 298
- RF input, selection, 179, 362
- RMS of trace data, 109, 116, 291, 298

- S**
- sampling trace data, 109, 116, 291, 298
- signal envelope view
 - signal envelope window, 98, 280
 - signal envelope window, 97, 98, 279, 280
 - amplitude Y scale, 98, 280
 - reference position, 98, 280
 - reference value, 98, 280
 - scale coupling, 98, 280
 - scale per division, 98, 280
- single vs. continuous
 - measurement mode, 143, 326
- span
 - SPECTrum, 193, 379
- Span key
 - spectrum measurement, 84, 268
- Span X Scale keys
 - Waveform, 52, 224, 232
- SPECTrum
 - acquisition packing, 183, 369
 - ADC range, 184, 370
 - data decimation, 189, 375
 - FFT length, 190, 376
 - FFT resolution BW, 191, 377
 - FFT window, 192, 378
 - FFT window delay, 191, 377
 - frequency span, 193, 379
 - sweep time, 193, 194, 379, 380
 - trigger source, 194, 380
- spectrum
 - all traces, 89, 272
 - amplitude Y scale, 88, 271
 - averaged trace, 89, 272
 - changing the display, 88, 271
 - changing views, 87, 271
 - current trace, 89, 272
 - next window selection, 87, 271
 - span X scale, 88, 271
 - trace display, 89, 272
 - view/trace, 87, 271
 - zoom a window, 87, 271
- Spectrum (Frequency Domain)
 - key, 81, 265
 - spectrum (frequency domain)
 - measurement, 162, 183, 346, 369
 - See also SPECTrum
 - spectrum linear view
 - linear spectrum window, 88, 271
 - Spectrum Marker keys, 50, 224, 231
 - Spectrum Meas Setup keys, 48, 49, 224, 229, 231
 - spectrum measurement
 - basic mode, 53, 234
 - making the measurement, 81, 265
 - method, 81, 265
 - results, 82, 266
 - spectrum measurement display, 132, 133, 138, 315, 316, 321
 - Spectrum View/Trace keys, 50, 224, 231
 - standard deviation of trace data, 109, 116, 291, 298
 - start measurement, 143, 144, 326, 327
 - state
 - changing, 167, 351
 - sweep time
 - SPECTrum, 193, 194, 379, 380
 - WAVEform, 201, 387
 - Sweep Time key, 94, 276
 - symbol, points per, 177, 360
 - sync word
 - NADC/PDC, 118, 300
 - synchronization
 - EVM, 177, 360
 - NADC, 195, 381
 - PDC, 195, 381

- T**
- test limit
 - OBW, 312
- test limits, 108, 290
 - NADC, 108, 117, 118, 290, 299, 300
 - PDC, 108, 117, 118, 290, 299, 300
- tile the display, 132, 315
- time domain measurement, 164, 196, 348, 382
- time slot auto, 174, 357
- time slot number, 173, 356
- trace averaging, 364
- trace data
 - processing, 109, 116, 291, 298
- trace display, 134, 317
- trace format, 141, 324
- trace names for markers, 124, 306
- trace/view selection
 - log envelope graph view, 96, 278
 - magnitude & phase graph view, 97, 279
- transmit band spurs - averaging state, 197, 383

- trigger
 - auto time, 203, 389
 - burst level, 208, 394
 - commands, 203, 389
 - delay, 204, 390
 - delay, IF, 207, 393
 - external, 204, 205, 390, 391
 - frame adjustment, 205, 206, 391, 392
 - frame period, 205, 391
 - frame sync mode, 206, 392
 - holdoff, 207, 393
 - level, 204, 390
 - level, IF, 207, 393
 - on/off, 203, 389
 - slope, 205, 391
 - slope, IF, 208, 394
 - SPECTrum, 194, 380
 - timeout, 203, 389
 - WAVEform, 202, 388
- trigger measurement, 143, 144, 326, 327
- trigger source
 - ACP, 171, 354
 - EVM, 178, 361
 - OBW, 365

- U**
- Uninstall Now, 57, 238
- uninstalling measurement personalities, 54, 235

- V**
- view ACP data, 131, 314
- view commands, 131, 314
- view EVM data, 131, 314
- view/trace
 - spectrum graph, 87, 271
- View/Trace keys
 - ACP, 46, 224, 226
 - EVM, 47, 224, 227
 - Spectrum, 50, 224, 231
 - Waveform, 51, 224, 232
- view/trace selection
 - magnitude & phase graph view, 87, 271
- VSA versus PSA series (programming compatibility), 106, 288

Index

W

WAVEform

acquisition packing, [196](#), [382](#)
 ADC dithering, [196](#), [382](#)
 ADC filter, [196](#), [382](#)
 ADC range, [197](#), [383](#)
 data decimation, [200](#), [201](#), [386](#),
[387](#)
 sweep time, [201](#), [387](#)
 trigger source, [202](#), [388](#)
 waveform
 advanced menu, [94](#), [276](#)
 changing displays, [97](#), [279](#)
 changing views, [96](#), [278](#)
 trace/view selection, [96](#), [278](#)
 I/Q waveform view, [98](#), [280](#)
 making the measurement, [92](#),
[274](#)
 method, [92](#), [274](#)

next window selection, [96](#), [278](#)
 resolution bandwidth, [94](#), [276](#)
 results, [92](#), [93](#), [274](#), [275](#)
 span X scale, [97](#), [279](#)
 sweep time, [94](#), [97](#), [276](#), [279](#)
 using markers, [99](#), [281](#)
 zoom a window, [96](#), [278](#)
 Waveform (Time Domain) key, [92](#),
[274](#)
 waveform (time domain)
 measurement, [164](#), [196](#), [348](#),
[382](#)
 See also WAVEform
 Waveform Amp Y Scale keys, [52](#),
[224](#), [232](#)
 Waveform Marker keys, [52](#), [224](#),
[232](#)
 Waveform Meas Setup keys, [51](#),
[224](#), [232](#)

waveform measurement

basic mode, [53](#), [234](#)
 display, [99](#), [281](#)
 Waveform Span X Scale keys, [52](#),
[224](#), [232](#)
 Waveform View/Trace keys, [51](#),
[224](#), [232](#)
 W-CDMA (3GPP) measurement,
[152](#), [335](#), [345](#), [363](#)
 W-CDMA (Trial & ARIB)
 measurement, [152](#), [335](#)
 W-CDMA measurement, [167](#), [351](#)
 Window Length key, [85](#), [269](#)

Z

zero span measurement, [164](#),
[196](#), [348](#), [382](#)
 zoom the display, [132](#), [315](#)