

**User's and Programmer's Reference
IQ Analyzer Mode
N9060A Spectrum Analyzer Measurement
Application**

For use with the MXA Signal Analyzer



Manufacturing Part Number: N9060-90009

Printed in USA

October 2006

© Copyright 2006 Agilent Technologies, Inc.

Legal Information

The information contained in this document is subject to change without notice.

Agilent Technologies makes no warranty of any kind with regard to this material, including but not limited to, the implied warranties of merchantability and fitness for a particular purpose. Agilent Technologies shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance, or use of this material.

Where to Find the Latest Information

Documentation is updated periodically.

- For the latest information about Agilent Technologies **MXA** Spectrum Analyzers, including firmware upgrades and application information, please visit the following Internet URL:

<http://www.agilent.com/find/mxa>

Technology Licenses

The hardware and/or software described in this document are furnished under a license and may be used or copied only in accordance with the terms of such license.

Restricted Rights Legend

If software is for use in the performance of a U.S. Government prime contract or subcontract, Software is delivered and licensed as “Commercial computer software” as defined in DFAR 252.227-7014 (June 1995), or as a “commercial item” as defined in FAR 2.101(a) or as “Restricted computer software” as defined in FAR 52.227-19 (June 1987) or any equivalent agency regulation or contract clause. Use, duplication or disclosure of Software is subject to Agilent Technologies’ standard commercial license terms, and non-DOD Departments and Agencies of the U.S. Government will receive no greater than Restricted Rights as defined in FAR 52.227-19(c)(1-2) (June 1987). U.S. Government users will receive no greater than Limited Rights as defined in FAR 52.227-14 (June 1987) or DFAR 252.227-7015 (b)(2) (November 1995), as applicable in any technical data.

Contents

1. Introduction

Using the Electronic Attenuator Hardware (Option N9020AK EA3)	36
Using the Wideband Analysis Hardware (Option N9020AK B25)	37
Installing Application Software.....	38
Viewing a License Key	38
Obtaining and Installing a License Key	38
Missing and Old Measurement Application Software	39

2. Utility Functions

System.....	42
Show.....	42
Power On	46
Alignments	49
I/O Config	68
Restore Defaults	73
Control Panel.....	77
Licensing.....	77
List installed Options (Remote Command Only)	78
Lock the Front Panel keys (Remote Command Only).....	78
List SCPI Commands (Remote Command Only).....	79
SCPI Version Query (Remote Command Only).....	79
Date (Remote Command Only).....	79
Time (Remote Command Only)	79
Save.....	81
State.....	81
Trace (+State)	84
Data (Mode Specific)	86
Screen Image.....	90
Save As Dialog and Menu.....	93
Quick Save	97
Recall.....	98
State.....	98
Trace (+State)	101
Data (Mode Specific)	103
File Open Dialog and Menu	106
Mode Preset	110
How-To Preset	110
Restore Mode Defaults	111
*RST (Remote Command Only)	112
Spectrum Analyzer Mode - Preset Information.....	112
User Preset	121
User Preset All Modes	122
Save User Preset	123
File	124
File Explorer	124
Page Setup.....	124
Print.....	124

Contents

Exit	124
Print	126
Service	127
Diagnostics	128
Show Hardware Statistics	128
Advanced	130
License Remote Commands	131
STATUS Subsystem (No equivalent front panel keys)	133
Detailed Description	135
STATUS Subsystem Command Descriptions	147
IEEE Common Commands	176
Calibration Query	176
Clear Status	176
Standard Event Status Enable	176
Standard Event Status Register Query	177
Identification Query	177
Operation Complete	178
Query Instrument Options	178
Recall Instrument State	179
Reset	179
Save Instrument State	179
Service Request Enable	180
Status Byte Query	180
Trigger	180
Self Test Query	181
Wait-to-Continue	181
Display Control Keys	182
Multi-Window	182
Zoom	182
Next Window	184
Select Display Format Tiled (remote command only)	185
Window Focus Move Control (remote command only)	186

3. Analyzer Setup Functions

AMPTD Y Scale	189
Reference Level	189
Attenuation	190
Scale / Div	195
Scale Type	196
Presel Center	197
Preselector Adjust	198
Y Axis Unit	199
Reference Level Offset	201
Internal Preamp	202
Auto Couple	205
BW	207
Res BW	207
Video BW	208
VBW:3dB RBW	209

Contents

Span:3dB RBW	211
RBW Control	212
FREQ Channel	219
Center Freq	219
Input/Output	221
RF Input	221
RF Calibrator	223
External Gain	224
Restore Input/Output Defaults	227
Freq Ref In	227
Output Config	230
Span	233
Span	233
Full Span	235
Zero Span	235
Last Span	237
Signal Track (Span Zoom)	240
Trace/Detector	243
View/Display	245
Display	245
Full Screen	252
Display Enable (Remote Command Only)	252

4. Marker Functions

Marker	256
Select Marker	258
Normal	259
Delta	259
Fixed	259
Off	260
Properties	261
Marker Table	266
Marker Count	267
Couple Markers	269
All Markers Off	269
Marker Fctn	270
Select Marker	271
Marker Noise	271
Band/Interval Power	272
Band/Interval Density	273
Off	274
Band Adjust	275
Marker To	279
Mkr->CF	279
Mkr->CF Step	279
Mkr->Start	280
Mkr->Stop	280
MkrΔ->Span	281
MkrΔ->CF	281

Contents

Mkr->Ref Lvl	282
Peak Search	283
Next Peak	283
Next Pk Right	284
Next Pk Left	284
Marker Delta	284
Mkr->CF	285
Mkr->Ref Lvl	285
Peak Criteria	285
Peak Table	289
Continuous Peak Search On/Off	292
Pk-Pk Search	293
Min Search	294
Peak Data Query (SCPI Command Only)	294

5. Measurement Functions

Meas	299
Current Measurement Query (Remote Command Only)	302
Test current results against all limits (Remote Command Only)	303
Data Query (Remote Command Only)	303
Calculate/Compress Trace Data Query (Remote Command Only)	303
Calculate peaks of trace data (Remote Command Only)	308
Meas Setup	309
Mode	311
Application Mode Number Selection (Remote command only)	312
Application Mode Catalog Query (Remote command only)	313
Application Identification (Remote commands only)	313
Application Identification Catalog (Remote commands only)	315
Spectrum Analyzer	317
IQ Analyzer (Basic)	317
W-CDMA with HSDPA/HSUPA	318
802.16 OFDMA (WiMAX/WiBro)	318
Mode Setup	319
Sweep/Control	321
Sweep Time	321
Pause/Resume	323
Sweep Setup	323
Points	329
Restart	330
Single/Cont key (Continuous Measurement)	331
Abort (Remote Only)	332
Trigger	335
Free Run	336
Video	336
Line	338
External 1	340
External 2	341
RF Burst (Wideband)	343
Periodic Timer (Frame Trigger)	345

Contents

Auto Trig	352
Trig Holdoff	352
6. Complex Spectrum	
Measurement Results View	358
Trace Results	359
Spectrum Window	359
I/Q SPECTrum Window	359
Span X Scale	360
Span (Spectrum View)	360
Ref Value (Waveform View)	360
Scale/Div (Waveform View)	361
Ref Position (Waveform View)	362
Auto Scaling (Waveform View)	362
AMPTD Y Scale	364
Ref Value	364
Attenuation	366
Scale/Div	366
Internal Preamp	367
Ref Position	367
Auto Scaling	368
View/Display	370
Display	370
Change Title	370
Trace/Detector	371
BW	372
Res BW	372
Meas Setup	373
Avg/Hold Num	373
Avg Mode	373
Avg Type	374
Meas Preset	375
Advanced	375
Trigger	384
Trigger Source	384
Sweep/Control	385
Pause/Resume	385
Marker	386
Marker Type	386
Marker X Axis Value	387
Marker X Axis Position	388
Marker Y Axis Value	388
Relative To	389
Marker Trace	390
Couple Marker	390
All Markers Off	391
Backward Compatibility SCPI Commands	391
Peak Search	392
Min Search	392

Contents

Mkr->CF	392
Marker To.	393
Mkr -> CF	393
Mkr -> Ref Lvl	394
Marker Function	395
Marker Function Type	395
Band Adjust	395

7. Waveform

Measurement Results	401
Graphic Results View	401
Numeric Results	402
Span X Scale	403
Ref Value	403
Scale/Div	403
Ref Position	404
Auto Scaling	405
AMPTD Y Scale	406
Ref Value	406
Attenuation	407
Scale/Div	407
Internal Preamp	409
Ref Position	409
Auto Scaling	410
View/Display	411
Display	411
View	411
Trace/Detector	413
BW	414
Info BW	414
Filter Type	414
Meas Setup	416
Average/Hold Number	416
Avg Mode	416
Avg Type	417
Meas Time	417
Meas Preset	418
Advanced	418
Trigger	422
Trigger	422
Sweep/Control	423
Pause and Resume	423
Marker	424
Marker Type	424
Marker X Axis Value	425
Marker X Axis Position	425
Marker Y Axis Value	426
Relative To	427
Marker Trace	428

Contents

Couple Marker.....	428
All Markers Off.....	429
Peak Search.....	430
Min Search.....	430
Marker To.....	431
Marker Function.....	432
Marker Function Type.....	432
Band Adjust.....	433

List of Commands

*CAL?	57
*CLS	176
*ESE <integer>	176
*ESE?	176
*ESR?	177
*IDN?	178
*OPC?	178
*OPC	178
*OPT?	178
*RCL <register #>	179
*RST	112
*RST	179
*SAV <register #>	179
*SRE <integer>	180
*SRE?	180
*STB?	180
*TRG	181
*TST?	181
*WAI	181
:ABORt	333
:CALCulate:CLIMits:FAIL?	303
:CALCulate:DATA[1] 2 3 4 5 6:PEAKs? <real>,<real>[,AMPLitude FREQuen- cy TIME[,ALL GTDLine LTDLine]]	295
:CALCulate:DATA[n]:PEAKs?	308
:CALCulate:DATA[n]? <real>,...	303
:CALCulate:MARKer:AOFF	269
:CALCulate:MARKer:COUPle[:STATe] OFF ON 0 1	269
:CALCulate:MARKer:COUPle[:STATe]?	269
:CALCulate:MARKer:PEAK:EXCursion <rel_ampl>	287
:CALCulate:MARKer:PEAK:EXCursion?	287
:CALCulate:MARKer:PEAK:SEARch:MODE MAXimum PARAmeter	286

List of Commands

:CALCulate:MARKer:PEAK:SEARch:MODE?	286
:CALCulate:MARKer:PEAK:SORT FREQuency AMPLitude	290
:CALCulate:MARKer:PEAK:SORT?	290
:CALCulate:MARKer:PEAK:TABLE:READout ALL GTDLine LTDLine	291
:CALCulate:MARKer:PEAK:TABLE:READout?	291
:CALCulate:MARKer:PEAK:TABLE:STATe OFF ON 0 1	290
:CALCulate:MARKer:PEAK:TABLE:STATe?	290
:CALCulate:MARKer:PEAK:THReshold <ampl>	288
:CALCulate:MARKer:PEAK:THReshold?	288
:CALCulate:MARKer:TABLE[:STATe] OFF ON 0 1	266
:CALCulate:MARKer:TABLE[:STATe]?	266
:CALCulate:MARKer:TRCKing[:STATe] OFF ON 0 1	240
:CALCulate:MARKer:TRCKing[:STATe]?	240
:CALCulate:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:CPSearch[:STATe] ON OFF 1 0	293
:CALCulate:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:CPSearch[:STATe]?	293
:CALCulate:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:FCOunt:X?	269
:CALCulate:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:FCOunt[:STATe] OFF ON 0 1	267
:CALCulate:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:FCOunt[:STATe]?	267
:CALCulate:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:FUNction NOISe BPOWer BDENsi- ty OFF	270
:CALCulate:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:FUNction:BAND:LEFT <freq>	276
:CALCulate:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:FUNction:BAND:LEFT?	276
:CALCulate:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:FUNction:BAND:RIGHT <freq>	278
:CALCulate:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:FUNction:BAND:RIGHT?	278
:CALCulate:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:FUNction:BAND:SPAN <freq>	275
:CALCulate:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:FUNction:BAND:SPAN?	275
:CALCulate:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:FUNction?	270
:CALCulate:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:LINes[:STATe] OFF ON 0 1	266
:CALCulate:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:LINes[:STATe]?	266
:CALCulate:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:MAXimum	283
:CALCulate:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:MAXimum:LEFT	284

List of Commands

:CALCulate:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:MAXimum:NEXT	283
:CALCulate:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:MAXimum:RIGHT	284
:CALCulate:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:MINimum	294
:CALCulate:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:MODE POSition DELTA FIXed OFF	256
:CALCulate:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:MODE?	256
:CALCulate:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:PTPeak	293
:CALCulate:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:REFerence <integer>	261
:CALCulate:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:REFerence?	261
:CALCulate:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:TRACe 1 2 3 4 5 6	265
:CALCulate:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:TRACe:AUTO OFF ON 0 1	266
:CALCulate:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:TRACe:AUTO?	266
:CALCulate:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:TRACe?	265
:CALCulate:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:X <freq>	257
:CALCulate:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:X:POSition <real>	257
:CALCulate:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:X:POSition?	257
:CALCulate:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:X:READout FREQuen- cy TIME ITime PERiod	262
:CALCulate:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:X:READout:AUTO ON OFF 1 0	262
:CALCulate:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:X:READout:AUTO?	262
:CALCulate:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:X:READout?	262
:CALCulate:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:X?	257
:CALCulate:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:Y <real>	258
:CALCulate:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:Y?	258
:CALCulate:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12[:SET]:CENTer	279
:CALCulate:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12[:SET]:DELTA:CENTer	281
:CALCulate:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12[:SET]:DELTA:SPAN	281
:CALCulate:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12[:SET]:RLEVel	282
:CALCulate:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12[:SET]:STARt	280
:CALCulate:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12[:SET]:STEP	280
:CALCulate:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12[:SET]:STOP	281
:CALCulate:SPECTrum:MARKer:AOFF	391

List of Commands

:CALCulate:SPECTrum:MARKer:COUPlE[:STATe] ON OFF 1 0	390
:CALCulate:SPECTrum:MARKer:COUPlE[:STATe]?	390
:CALCulate:SPECTrum:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:FUNCTion NOISe BPOW-er BDENsity OFF	395
:CALCulate:SPECTrum:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:FUNCTion:BAND:LEFT <freq>	396
:CALCulate:SPECTrum:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:FUNCTion:BAND:LEFT?	396
:CALCulate:SPECTrum:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:FUNCTion:BAND:RIGHT <freq>	397
:CALCulate:SPECTrum:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:FUNCTion:BAND:RIGHT?	397
:CALCulate:SPECTrum:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:FUNCTion:BAND:SPAN <freq>	396
:CALCulate:SPECTrum:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:FUNCTion:BAND:SPAN?	396
:CALCulate:SPECTrum:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:FUNCTion?	395
:CALCulate:SPECTrum:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:MAXimum	392
:CALCulate:SPECTrum:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:MINimum	392
:CALCulate:SPECTrum:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:MODE POSition DELTA OFF	386
:CALCulate:SPECTrum:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:MODE?	386
:CALCulate:SPECTrum:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:REFerence <integer>	389
:CALCulate:SPECTrum:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:REFerence?	389
:CALCulate:SPECTrum:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:STATe OFF ON 0 1	391
:CALCulate:SPECTrum:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:STATe?	391
:CALCulate:SPECTrum:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:TRACe SPECTrum ASpec-trum IQ	390
:CALCulate:SPECTrum:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:TRACe?	390
:CALCulate:SPECTrum:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:X <real>	387
:CALCulate:SPECTrum:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:X:POSition <real>	388
:CALCulate:SPECTrum:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:X:POSition?	388
:CALCulate:SPECTrum:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:X?	387
:CALCulate:SPECTrum:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:Y?	388
:CALCulate:SPECTrum:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12[:SET]:CENTer	393
:CALCulate:SPECTrum:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12[:SET]:RLEVel	394

List of Commands

:CALCulate:WAVeform:MARKer:AOff	429
:CALCulate:WAVeform:MARKer:COUple[:STATe] ON OFF 1 0	428
:CALCulate:WAVeform:MARKer:COUple[:STATe]?	428
:CALCulate:WAVeform:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:FUNcTION BPOWer BDENsi-ty OFF	432
:CALCulate:WAVeform:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:FUNcTION:Band:LEfT <time>	433
:CALCulate:WAVeform:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:FUNcTION:Band:LEfT?...	433
:CALCulate:WAVeform:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:FUNcTION:Band:RIghT <time>	434
:CALCulate:WAVeform:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:FUNcTION:Band:RIghT?..	434
:CALCulate:WAVeform:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:FUNcTION:Band:SPAN <time>	433
:CALCulate:WAVeform:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:FUNcTION:Band:SPAN?...	433
:CALCulate:WAVeform:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:FUNcTION?	432
:CALCulate:WAVeform:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:MAXimum	430
:CALCulate:WAVeform:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:MINimum	430
:CALCulate:WAVeform:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:MODE POSition DELTA OFF	424
:CALCulate:WAVeform:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:MODE?	424
:CALCulate:WAVeform:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:REFerence <integer>...	427
:CALCulate:WAVeform:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:REFerence?	427
:CALCulate:WAVeform:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:TRACe RFENvelope IQ	428
:CALCulate:WAVeform:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:TRACe?	428
:CALCulate:WAVeform:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:X <time>...	425
:CALCulate:WAVeform:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:X:POSition <real>	426
:CALCulate:WAVeform:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:X:POSition?	426
:CALCulate:WAVeform:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:X?	425
:CALCulate:WAVeform:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:Y?	426
:CALCulate:ZONE:MAXimum:LEfT	240
:CALCulate:ZONE:MAXimum:RIghT	239
:CALibration:AUTO ON PARTial OFF ALERT	50
:CALibration:AUTO:ALERT TTEMPerature DAY WEEK NONE	53

List of Commands

:CALibration:AUTO:ALERt?	53
:CALibration:AUTO:MODE ALL NRF	52
:CALibration:AUTO:MODE?	52
:CALibration:AUTO:TIME:OFF?	65
:CALibration:AUTO?	50
:CALibration:DATA:DEFault	68
:CALibration:FREQuency:REFerence:COARse <integer>	66
:CALibration:FREQuency:REFerence:COARse?	66
:CALibration:FREQuency:REFerence:FINE <integer>	66
:CALibration:FREQuency:REFerence:FINE?	66
:CALibration:FREQuency:REFerence:MODE CALibrated USER	65
:CALibration:FREQuency:REFerence:MODE?	65
:CALibration:NRF?	58
:CALibration:NRF	58
:CALibration:RF?	59
:CALibration:RF	59
:CALibration:TEMPerature:CURRent?	63
:CALibration:TEMPerature:LALL?	63
:CALibration:TEMPerature:LPReselector?	64
:CALibration:TEMPerature:LRf?	64
:CALibration:TIME:LALL?	63
:CALibration:TIME:LPReselector?	64
:CALibration:TIME:LRf?	63
:CALibration:YTF?	60
:CALibration:YTF	60
:CALibration[:ALL]?	56
:CALibration[:ALL]	56
:CONFigure:SPECTrum	355
:CONFigure:SPECTrum	375
:CONFigure:WAVeform	418
:CONFigure:WAVeform	399

List of Commands

:CONFigure?	303
:COUple ALL NONE	205
:DISPlay:ACTivefunc[:STATe] ON OFF 1 0	248
:DISPlay:ACTivefunc[:STATe]?	248
:DISPlay:ANNotation:MBAR[:STATe] OFF ON 0 1	246
:DISPlay:ANNotation:MBAR[:STATe]?	246
:DISPlay:ANNotation:SCReen[:STATe] OFF ON 0 1	247
:DISPlay:ANNotation:SCReen[:STATe]?	247
:DISPlay:ANNotation:TITLe:DATA <string>	248
:DISPlay:ANNotation:TITLe:DATA?	248
:DISPlay:ANNotation:TRACe[:STATe] ON OFF 1 0	247
:DISPlay:ANNotation:TRACe[:STATe]?	247
:DISPlay:BACKlight ON OFF	251
:DISPlay:BACKlight:INTensity <integer>	252
:DISPlay:BACKlight:INTensity?	252
:DISPlay:BACKlight?	251
:DISPlay:ENABle OFF ON 0 1	253
:DISPlay:ENABle?	253
:DISPlay:FSCReen[:STATe] OFF ON 0 1	252
:DISPlay:FSCReen[:STATe]?	252
:DISPlay:SPECtrum:ANNotation:TITLe:DATA <string>	370
:DISPlay:SPECtrum:ANNotation:TITLe:DATA?	370
:DISPlay:SPECtrum:VIEW[1]:WINDow[1]:TRACe:Y[:SCALe]:PDIVision <rel_amp>	366
:DISPlay:SPECtrum:VIEW[1]:WINDow[1]:TRACe:Y[:SCALe]:PDIVision?	366
:DISPlay:SPECtrum:VIEW[1]:WINDow[1]:TRACe:Y[:SCALe]:RLEVel <ampl>	364
:DISPlay:SPECtrum:VIEW[1]:WINDow[1]:TRACe:Y[:SCALe]:RLEVel?	364
:DISPlay:SPECtrum:VIEW[1]:WINDow[1]:TRACe:Y[:SCALe]:RPOSition TOP CENTer BOTTom	368
:DISPlay:SPECtrum:VIEW[1]:WINDow[1]:TRACe:Y[:SCALe]:RPOSition?	368
:DISPlay:SPECtrum:VIEW[1]:WINDow[1] 2:TRACe:Y[:SCALe]:COUple ON OFF 1 0	369
:DISPlay:SPECtrum:VIEW[1]:WINDow[1] 2:TRACe:Y[:SCALe]:COUple?	369

List of Commands

:DISPlay:SPECtrum:VIEW[1]:WINDow2:TRACe:X[:SCALe]:COUPle 0 1 OFF ON	362
:DISPlay:SPECtrum:VIEW[1]:WINDow2:TRACe:X[:SCALe]:COUPle	362
:DISPlay:SPECtrum:VIEW[1]:WINDow2:TRACe:X[:SCALe]:PDIVision <time>	361
:DISPlay:SPECtrum:VIEW[1]:WINDow2:TRACe:X[:SCALe]:PDIVision?	361
:DISPlay:SPECtrum:VIEW[1]:WINDow2:TRACe:X[:SCALe]:RLEVel <time>	361
:DISPlay:SPECtrum:VIEW[1]:WINDow2:TRACe:X[:SCALe]:RLEVel?	361
:DISPlay:SPECtrum:VIEW[1]:WINDow2:TRACe:X[:SCALe]:RPOSition LEFT CENTer RIGHT	362
:DISPlay:SPECtrum:VIEW[1]:WINDow2:TRACe:X[:SCALe]:RPOSition?	362
:DISPlay:SPECtrum:VIEW[1]:WINDow2:TRACe:Y[:SCALe]:PDIVision <voltage>	367
:DISPlay:SPECtrum:VIEW[1]:WINDow2:TRACe:Y[:SCALe]:PDIVision?	367
:DISPlay:SPECtrum:VIEW[1]:WINDow2:TRACe:Y[:SCALe]:RLEVel <voltage>	365
:DISPlay:SPECtrum:VIEW[1]:WINDow2:TRACe:Y[:SCALe]:RLEVel?	365
:DISPlay:SPECtrum:VIEW[1]:WINDow2:TRACe:Y[:SCALe]:RPOSition TOP CENTer BOTTom...	368
:DISPlay:SPECtrum:VIEW[1]:WINDow2:TRACe:Y[:SCALe]:RPOSition?	368
:DISPlay:THEME TDColor TDMonochrome FCOLor FMONochrome	251
:DISPlay:THEME?	251
:DISPlay:WAVeform:ANNotation:TITLe:DATA <string>	411
:DISPlay:WAVeform:ANNotation:TITLe:DATA?	411
:DISPlay:WAVeform:VIEW:NSElect <integer>	412
:DISPlay:WAVeform:VIEW:NSElect?	412
:DISPlay:WAVeform:VIEW[:SElect] RFENvelope IQ	411
:DISPlay:WAVeform:VIEW[:SElect]?	411
:DISPlay:WAVeform:VIEW[1]:WINDow[1]:TRACe:Y[:SCALe]:PDIVision <rel_amp>	408
:DISPlay:WAVeform:VIEW[1]:WINDow[1]:TRACe:Y[:SCALe]:PDIVision?	408
:DISPlay:WAVeform:VIEW[1]:WINDow[1]:TRACe:Y[:SCALe]:RLEVel <amp>	406
:DISPlay:WAVeform:VIEW[1]:WINDow[1]:TRACe:Y[:SCALe]:RLEVel?	406
:DISPlay:WAVeform:VIEW[1]:WINDow[1]:TRACe:Y[:SCALe]:RPOSition TOP CENTer BOTTom...	409
:DISPlay:WAVeform:VIEW[1]:WINDow[1]:TRACe:Y[:SCALe]:RPOSition?	409
:DISPlay:WAVeform:VIEW[1] 2:WINDow[1]:TRACe:X[:SCALe]:COUPle 0 1 OFF ON	405
:DISPlay:WAVeform:VIEW[1] 2:WINDow[1]:TRACe:X[:SCALe]:COUPle?	405

List of Commands

:DISPlay:WAVeform:VIEW[1] 2:WINDow[1]:TRACe:X[:SCALe]:PDIVision <time>	404
:DISPlay:WAVeform:VIEW[1] 2:WINDow[1]:TRACe:X[:SCALe]:PDIVision?	404
:DISPlay:WAVeform:VIEW[1] 2:WINDow[1]:TRACe:X[:SCALe]:RLEVel <time>	403
:DISPlay:WAVeform:VIEW[1] 2:WINDow[1]:TRACe:X[:SCALe]:RLEVel?	403
:DISPlay:WAVeform:VIEW[1] 2:WINDow[1]:TRACe:X[:SCALe]:RPOStion LEFT CENTer RIGHT	404
:DISPlay:WAVeform:VIEW[1] 2:WINDow[1]:TRACe:X[:SCALe]:RPOStion?	404
:DISPlay:WAVeform:VIEW[1] 2:WINDow[1]:TRACe:Y[:SCALe]:COUPle 0 1 OFF ON	410
:DISPlay:WAVeform:VIEW[1] 2:WINDow[1]:TRACe:Y[:SCALe]:COUPle?	410
:DISPlay:WAVeform:VIEW2:WINDow[1]:TRACe:Y[:SCALe]:PDIVision <voltage>	408
:DISPlay:WAVeform:VIEW2:WINDow[1]:TRACe:Y[:SCALe]:PDIVision?	408
:DISPlay:WAVeform:VIEW2:WINDow[1]:TRACe:Y[:SCALe]:RLEVel <voltage>	407
:DISPlay:WAVeform:VIEW2:WINDow[1]:TRACe:Y[:SCALe]:RLEVel?	407
:DISPlay:WAVeform:VIEW2:WINDow[1]:TRACe:Y[:SCALe]:RPOStion TOP CENTer BOTTom	410
:DISPlay:WAVeform:VIEW2:WINDow[1]:TRACe:Y[:SCALe]:RPOStion?	410
:DISPlay:WINDow:FORMat:TILE	185
:DISPlay:WINDow:FORMat:ZOOM	185
:DISPlay:WINDow[:SElect] <number>	186
:DISPlay:WINDow[:SElect]?	186
:DISPlay:WINDow[1]:ANNotation[:ALL] OFF ON 0 1	250
:DISPlay:WINDow[1]:ANNotation[:ALL]?	250
:DISPlay:WINDow[1]:TRACe:GRATicule:GRID[:STATe] OFF ON 0 1	249
:DISPlay:WINDow[1]:TRACe:GRATicule:GRID[:STATe]?	249
:DISPlay:WINDow[1]:TRACe:Y:DLINe <ampl>	249
:DISPlay:WINDow[1]:TRACe:Y:DLINe:STATe OFF ON 0 1	249
:DISPlay:WINDow[1]:TRACe:Y:DLINe:STATe?	249
:DISPlay:WINDow[1]:TRACe:Y:DLINe?	249
:DISPlay:WINDow[1]:TRACe:Y[:SCALe]:PDIVision <rel_ampl>	196
:DISPlay:WINDow[1]:TRACe:Y[:SCALe]:PDIVision?	196
:DISPlay:WINDow[1]:TRACe:Y[:SCALe]:RLEVel <rel>	189
:DISPlay:WINDow[1]:TRACe:Y[:SCALe]:RLEVel:OFFSet <rel_ampl>	202

List of Commands

:DISPlay:WINDow[1]:TRACe:Y[:SCALe]:RLEVel:OFFSet?	202
:DISPlay:WINDow[1]:TRACe:Y[:SCALe]:RLEVel?	189
:DISPlay:WINDow[1]:TRACe:Y[:SCALe]:SPACing LINear LOGarithmic	196
:DISPlay:WINDow[1]:TRACe:Y[:SCALe]:SPACing?	196
:FETCh:SPECtrum[n]	355
:FETCh:WAVEform[n].	399
:INITiate:CONTInuous OFF ON 0 1	332
:INITiate:CONTInuous?	332
:INITiate:PAUSE	323
:INITiate:REStart	331
:INITiate:RESUme.	323
:INITiate:SPECtrum	355
:INITiate:WAVEform.	399
:INITiate[:IMMediate]	330
:INPut:COUPling AC DC	223
:INPut:COUPling?	223
:INSTrument:CATalog?	313
:INSTrument:DEFault.	112
:INSTrument:NSElect <integer>	312
:INSTrument:NSElect?	312
:INSTrument[:SElect] SA BASIC WCDMA	311
:INSTrument[:SElect]?	311
:MEASure:SPECtrum[n]	355
:MEASure:WAVEform[n]	399
:MMEMory:LOAD:STATe <filename>	101
:MMEMory:LOAD:TRACe TRACE1 TRACE2 TRACE3 TRACE4 TRACE5 TRACE6, <filename> 103	
:MMEMory:LOAD:TRACe:DATA TRACE1 TRACE2 TRACE3 TRACE4 TRACE5 TRACE6, <file- name>	106
:MMEMory:LOAD:ZMAP <filename>	106
:MMEMory:STORe:RESults <filename>	89
:MMEMory:STORe:SCReen <filename>	92

List of Commands

:MMEMory:STORe:SCReen:THEME TDColor TDMonochrome FCOLor FMONochrome ...	91
:MMEMory:STORe:SCReen:THEMe?	91
:MMEMory:STORe:STATe <filename>	84
:MMEMory:STORe:TRACe TRACE1 TRACE2 TRACE3 TRACE4 TRACE5 TRACE6 ALL,<file- name>	85
:MMEMory:STORe:TRACe:DATA TRACE1 TRACE2 TRACE3 TRACE4 TRACE5 TRACE6,<filename>	89
:MMEMory:STORe:ZMAP <filename>	90
:READ:SPECtrum[n]	355
:READ:WAVEform[n]	399
:STATus:OPERation:CONDition?	147
:STATus:OPERation:ENABle <integer>	148
:STATus:OPERation:ENABle?	148
:STATus:OPERation:NTRansition <integer>	149
:STATus:OPERation:NTRansition?	149
:STATus:OPERation:PTRansition <integer>	149
:STATus:OPERation:PTRansition?	149
:STATus:OPERation[:EVENT]?	148
:STATus:PRESet	149
:STATus:QUEStionable:CALibration:CONDition?	152
:STATus:QUEStionable:CALibration:ENABle <integer>	152
:STATus:QUEStionable:CALibration:ENABle?	152
:STATus:QUEStionable:CALibration:EXTended:FAILure:CONDition?	156
:STATus:QUEStionable:CALibration:EXTended:FAILure:ENABle <integer>	157
:STATus:QUEStionable:CALibration:EXTended:FAILure:ENABle?	157
:STATus:QUEStionable:CALibration:EXTended:FAILure:NTRansition <integer>	158
:STATus:QUEStionable:CALibration:EXTended:FAILure:NTRansition?	158
:STATus:QUEStionable:CALibration:EXTended:FAILure:PTRansition <integer>	158
:STATus:QUEStionable:CALibration:EXTended:FAILure:PTRansition?	158
:STATus:QUEStionable:CALibration:EXTended:FAILure[:EVENT]?	157
:STATus:QUEStionable:CALibration:EXTended:NEEDed:CONDition?	159
:STATus:QUEStionable:CALibration:EXTended:NEEDed:ENABle <integer>	159

List of Commands

:STATus:QUEStionable:CALibration:EXTended:NEEDed:ENABle?	159
:STATus:QUEStionable:CALibration:EXTended:NEEDed:NTRansition <integer>	160
:STATus:QUEStionable:CALibration:EXTended:NEEDed:NTRansition?	160
:STATus:QUEStionable:CALibration:EXTended:NEEDed:PTRansition <integer>	161
:STATus:QUEStionable:CALibration:EXTended:NEEDed:PTRansition?	161
:STATus:QUEStionable:CALibration:EXTended:NEEDed[:EVENT]?	160
:STATus:QUEStionable:CALibration:NTRansition <integer>	153
:STATus:QUEStionable:CALibration:NTRansition?	153
:STATus:QUEStionable:CALibration:PTRansition <integer>	154
:STATus:QUEStionable:CALibration:PTRansition?	154
:STATus:QUEStionable:CALibration:SKIPped:CONDition?	154
:STATus:QUEStionable:CALibration:SKIPped:ENABle <integer>	155
:STATus:QUEStionable:CALibration:SKIPped:ENABle?	155
:STATus:QUEStionable:CALibration:SKIPped:NTRansition <integer>	155
:STATus:QUEStionable:CALibration:SKIPped:NTRansition?	155
:STATus:QUEStionable:CALibration:SKIPped:PTRansition <integer>	156
:STATus:QUEStionable:CALibration:SKIPped:PTRansition?	156
:STATus:QUEStionable:CALibration:SKIPped[:EVENT]?	155
:STATus:QUEStionable:CALibration[:EVENT]?	153
:STATus:QUEStionable:CONDition?	150
:STATus:QUEStionable:ENABle 16	150
:STATus:QUEStionable:ENABle?	150
:STATus:QUEStionable:FREQuency:CONDition?	161
:STATus:QUEStionable:FREQuency:ENABle <integer>	161
:STATus:QUEStionable:FREQuency:ENABle?	161
:STATus:QUEStionable:FREQuency:NTRansition <integer>	162
:STATus:QUEStionable:FREQuency:NTRansition?	162
:STATus:QUEStionable:FREQuency:PTRansition <integer>	163
:STATus:QUEStionable:FREQuency:PTRansition?	163
:STATus:QUEStionable:FREQuency[:EVENT]?	162
:STATus:QUEStionable:INTegrity:CONDition?	163

List of Commands

:STATus:QUEStionable:INTEgrity:ENABle <integer>	164
:STATus:QUEStionable:INTEgrity:ENABle?	164
:STATus:QUEStionable:INTEgrity:NTRansition <integer>	165
:STATus:QUEStionable:INTEgrity:NTRansition?	165
:STATus:QUEStionable:INTEgrity:PTRansition <integer>	165
:STATus:QUEStionable:INTEgrity:PTRansition?	165
:STATus:QUEStionable:INTEgrity:SIGNal:CONDition?	166
:STATus:QUEStionable:INTEgrity:SIGNal:ENABle <integer>	166
:STATus:QUEStionable:INTEgrity:SIGNal:ENABle?	166
:STATus:QUEStionable:INTEgrity:SIGNal:NTRansition <integer>	167
:STATus:QUEStionable:INTEgrity:SIGNal:NTRansition?	167
:STATus:QUEStionable:INTEgrity:SIGNal:PTRansition <integer>	167
:STATus:QUEStionable:INTEgrity:SIGNal:PTRansition?	167
:STATus:QUEStionable:INTEgrity:SIGNal[:EVENT]?	167
:STATus:QUEStionable:INTEgrity:UNCalibrated:CONDition?	168
:STATus:QUEStionable:INTEgrity:UNCalibrated:ENABle?	168
:STATus:QUEStionable:INTEgrity:UNCalibrated:ENABle	168
:STATus:QUEStionable:INTEgrity:UNCalibrated:NTRansition <integer>	169
:STATus:QUEStionable:INTEgrity:UNCalibrated:NTRansition?	169
:STATus:QUEStionable:INTEgrity:UNCalibrated:PTRansition <integer>	170
:STATus:QUEStionable:INTEgrity:UNCalibrated:PTRansition?	170
:STATus:QUEStionable:INTEgrity:UNCalibrated[:EVENT]?	169
:STATus:QUEStionable:INTEgrity[:EVENT]?	164
:STATus:QUEStionable:NTRansition 16	151
:STATus:QUEStionable:NTRansition?	151
:STATus:QUEStionable:POWer:CONDition?	170
:STATus:QUEStionable:POWer:ENABle <integer>	171
:STATus:QUEStionable:POWer:ENABle?	171
:STATus:QUEStionable:POWer:NTRansition <integer>	172
:STATus:QUEStionable:POWer:NTRansition?	172
:STATus:QUEStionable:POWer:PTRansition <integer>	172

List of Commands

:STATus:QUEStionable:POWer:PTRansition?>	172
:STATus:QUEStionable:POWer[:EVENT]?	171
:STATus:QUEStionable:PTRansition <integer>	152
:STATus:QUEStionable:PTRansition?	152
:STATus:QUEStionable:TEMPerature:CONDition?	173
:STATus:QUEStionable:TEMPerature:ENABle <integer>	173
:STATus:QUEStionable:TEMPerature:ENABle?	173
:STATus:QUEStionable:TEMPerature:NTRansition <integer>	174
:STATus:QUEStionable:TEMPerature:NTRansition?	174
:STATus:QUEStionable:TEMPerature:PTRansition <integer>	174
:STATus:QUEStionable:TEMPerature:PTRansition?	174
:STATus:QUEStionable:TEMPerature[:EVENT]?	174
:STATus:QUEStionable[:EVENT]?	151
:SYSTem:APPLication:CATalog:OPTion? <model>	316
:SYSTem:APPLication:CATalog:REVision? <model>	316
:SYSTem:APPLication:CATalog[:NAME]:COUNT?	315
:SYSTem:APPLication:CATalog[:NAME]?	315
:SYSTem:APPLication[:CURRent]:OPTion?	314
:SYSTem:APPLication[:CURRent]:REVision?	314
:SYSTem:APPLication[:CURRent][:NAME]?	313
:SYSTem:COMMunicate:GPIB[1][:SELF]:ADDRess <integer>	69
:SYSTem:COMMunicate:GPIB[1][:SELF]:ADDRess?	69
:SYSTem:COMMunicate:LAN:SCPI:SICL:ENABle OFF ON 0 1	71
:SYSTem:COMMunicate:LAN:SCPI:SICL:ENABle?	71
:SYSTem:COMMunicate:LAN:SCPI:SOCKet:CONTRol?	70
:SYSTem:COMMunicate:LAN:SCPI:SOCKet:ENABle OFF ON 0 1	70
:SYSTem:COMMunicate:LAN:SCPI:SOCKet:ENABle?	70
:SYSTem:COMMunicate:LAN:SCPI:TELNet:ENABle OFF ON 0 1	69
:SYSTem:COMMunicate:LAN:SCPI:TELNet:ENABle?	69
:SYSTem:COMMunicate:USB:CONNecTion?	72
:SYSTem:COMMunicate:USB:PACKets?	73

List of Commands

:SYSTem:COMMunicate:USB:STATus?	72
:SYSTem:DATE "<year>,<month>,<day>"	79
:SYSTem:DATE?	79
:SYSTem:DEFault [ALL] ALIGn INPut MISC MODes PON	73
:SYSTem:ERRor:VERBose OFF ON 0 1	44
:SYSTem:ERRor:VERBose?	44
:SYSTem:ERRor[:NEXT]?	43
:SYSTem:HELP:HEADers?	79
:SYSTem:KLOCK OFF ON 0 1	78
:SYSTem:KLOCK?	78
:SYSTem:MRELay:COUNt?	129
:SYSTem:OPTions?	78
:SYSTem:PON:ETime?	130
:SYSTem:PON:MODE SA CDMA DMOdulation EDGEgsm NADC NFIGure PDC PNoise TDScdma	48
:SYSTem:PON:MODE?	48
:SYSTem:PON:TIME?	62
:SYSTem:PON:TYPE MODE USER LAST PRESet	47
:SYSTem:PON:TYPE?	47
:SYSTem:PRESet	110
:SYSTem:PRESet:USER	121
:SYSTem:PRESet:USER:ALL	122
:SYSTem:PRESet:USER:SAVE	123
:SYSTem:PRINt:THEMe TDColor TDMonochrome FCOLor FMONochrome	124
:SYSTem:PRINt:THEMe?	124
:SYSTem:TEMPerature:HEXTreme?	130
:SYSTem:TEMPerature:LEXTreme?	129
:SYSTem:TIME "<hour>,<minute>,<second>"	80
:SYSTem:TIME?	80
:SYSTem:VERSion?	79
:TRIGger:SPECTrum[:SEQUence]:SOURce EXTernal[1] EXTernal2 IMMediate IF VID- eo LINE RFBurst FRAME	384

List of Commands

:TRIGger:SPEctrum[:SEQuence]:SOURce?	384
:TRIGger[:SEQuence]:ATRigger <time>	352
:TRIGger[:SEQuence]:ATRigger:STATe OFF ON 0 1	352
:TRIGger[:SEQuence]:ATRigger:STATe?	352
:TRIGger[:SEQuence]:ATRigger?	352
:TRIGger[:SEQuence]:EXTernal1:DELay <time>	341
:TRIGger[:SEQuence]:EXTernal1:DELay:STATe OFF ON 0 1	341
:TRIGger[:SEQuence]:EXTernal1:DELay:STATe?	341
:TRIGger[:SEQuence]:EXTernal1:DELay?	341
:TRIGger[:SEQuence]:EXTernal1:LEVel <level>	340
:TRIGger[:SEQuence]:EXTernal1:LEVel?	340
:TRIGger[:SEQuence]:EXTernal1:SLOPe POSitive NEGative	340
:TRIGger[:SEQuence]:EXTernal1:SLOPe?	340
:TRIGger[:SEQuence]:EXTernal2:DELay <time>	343
:TRIGger[:SEQuence]:EXTernal2:DELay:STATe OFF ON 0 1	343
:TRIGger[:SEQuence]:EXTernal2:DELay:STATe?	343
:TRIGger[:SEQuence]:EXTernal2:DELay?	343
:TRIGger[:SEQuence]:EXTernal2:LEVel	342
:TRIGger[:SEQuence]:EXTernal2:LEVel?	342
:TRIGger[:SEQuence]:EXTernal2:SLOPe POSitive NEGative	342
:TRIGger[:SEQuence]:EXTernal2:SLOPe?	342
:TRIGger[:SEQuence]:FRAME:ADJust <time>	347
:TRIGger[:SEQuence]:FRAME:DELay <time>	352
:TRIGger[:SEQuence]:FRAME:DELay:STATe OFF ON 0 1	352
:TRIGger[:SEQuence]:FRAME:DELay:STATe?	352
:TRIGger[:SEQuence]:FRAME:DELay?	352
:TRIGger[:SEQuence]:FRAME:EXTernal1:LEVel <voltage>	348
:TRIGger[:SEQuence]:FRAME:EXTernal1:LEVel?	348
:TRIGger[:SEQuence]:FRAME:EXTernal1:SLOPe POSitive NEGative	349
:TRIGger[:SEQuence]:FRAME:EXTernal1:SLOPe?	349
:TRIGger[:SEQuence]:FRAME:EXTernal2:LEVel	350

List of Commands

:TRIGger[:SEQuence]:FRAMe:EXTernal2:LEVel?	350
:TRIGger[:SEQuence]:FRAMe:EXTernal2:SLOPe POSitive NEGative	350
:TRIGger[:SEQuence]:FRAMe:EXTernal2:SLOPe?	350
:TRIGger[:SEQuence]:FRAMe:OFFSet <time>	346
:TRIGger[:SEQuence]:FRAMe:OFFSet:DISPlay:RESet.	347
:TRIGger[:SEQuence]:FRAMe:OFFSet?	346
:TRIGger[:SEQuence]:FRAMe:PERiod <time>.	345
:TRIGger[:SEQuence]:FRAMe:PERiod?	345
:TRIGger[:SEQuence]:FRAMe:RFBurst:LEVel:ABSolute <ampl>	351
:TRIGger[:SEQuence]:FRAMe:RFBurst:LEVel:ABSolute?	351
:TRIGger[:SEQuence]:FRAMe:RFBurst:SLOPe POSitive NEGative.	351
:TRIGger[:SEQuence]:FRAMe:RFBurst:SLOPe?	351
:TRIGger[:SEQuence]:FRAMe:SYNC EXTernal1 EXTernal2 RFBurst OFF.	348
:TRIGger[:SEQuence]:FRAMe:SYNC?	348
:TRIGger[:SEQuence]:HOLDoff <time>	353
:TRIGger[:SEQuence]:HOLDoff:STATe OFF ON 0 1	353
:TRIGger[:SEQuence]:HOLDoff:STATe?	353
:TRIGger[:SEQuence]:HOLDoff?	353
:TRIGger[:SEQuence]:LINE:DELay <time>.	339
:TRIGger[:SEQuence]:LINE:DELay:STATe OFF ON 0 1	339
:TRIGger[:SEQuence]:LINE:DELay:STATe?.	339
:TRIGger[:SEQuence]:LINE:DELay?	339
:TRIGger[:SEQuence]:LINE:SLOPe POSitive NEGative	339
:TRIGger[:SEQuence]:LINE:SLOPe?	339
:TRIGger[:SEQuence]:RFBurst:DELay <time>	344
:TRIGger[:SEQuence]:RFBurst:DELay:STATe OFF ON 0 1	344
:TRIGger[:SEQuence]:RFBurst:DELay:STATe?	344
:TRIGger[:SEQuence]:RFBurst:DELay?	344
:TRIGger[:SEQuence]:RFBurst:LEVel:ABSolute <ampl>	343
:TRIGger[:SEQuence]:RFBurst:LEVel:ABSolute?	343
:TRIGger[:SEQuence]:RFBurst:SLOPe POSitive NEGative	344

List of Commands

:TRIGger[:SEQuence]:RFBurst:SLOPe?	344
:TRIGger[:SEQuence]:SOURce EXTernal1 EXTernal2 IMMEDIATE LINE FRAME RFBurst VIDEO TV	335
:TRIGger[:SEQuence]:SOURce?	335
:TRIGger[:SEQuence]:VIDeo:DELay <time>	338
:TRIGger[:SEQuence]:VIDeo:DELay:STATe OFF ON 0 1	338
:TRIGger[:SEQuence]:VIDeo:DELay:STATe?	338
:TRIGger[:SEQuence]:VIDeo:DELay?	338
:TRIGger[:SEQuence]:VIDeo:LEVel <ampl>	337
:TRIGger[:SEQuence]:VIDeo:LEVel?	337
:TRIGger[:SEQuence]:VIDeo:SLOPe POSitive NEGative	338
:TRIGger[:SEQuence]:VIDeo:SLOPe?	338
:TRIGger TRIGger1 TRIGger2[:SEQuence]:OUTPut HSWP MEASuring MAIN GATE GTRigger OEVEN SUVideo SPOint SPATtern PROGRAMmable OFF.	230
:TRIGger TRIGger1 TRIGger2[:SEQuence]:OUTPut:POLarity POSitive NEGative	230
:TRIGger TRIGger1 TRIGger2[:SEQuence]:OUTPut:POLarity?	230
:TRIGger TRIGger1 TRIGger2[:SEQuence]:OUTPut?	230
:UNIT:POWer DBM DBMV DBMA V W A DBUV DBUA DUVM DUAM DBPT DBG	199
:UNIT:POWer?	199
<threshold>,<excursion>[,AMPLitude FREQuency TIME]	308
[:SENSe]:BANDwidth BWIDth:SHAPe GAUSSian FLATtop EMI	212
[:SENSe]:BANDwidth BWIDth:SHAPe?	212
[:SENSe]:BANDwidth BWIDth:TYPE DB3 DB6 IMPulse NOISe	216
[:SENSe]:BANDwidth BWIDth:TYPE?	216
[:SENSe]:BANDwidth BWIDth:VIDeo <freq>	209
[:SENSe]:BANDwidth BWIDth:VIDeo:AUTO OFF ON 0 1	209
[:SENSe]:BANDwidth BWIDth:VIDeo:AUTO?	209
[:SENSe]:BANDwidth BWIDth:VIDeo:RATio <real>	210
[:SENSe]:BANDwidth BWIDth:VIDeo:RATio:AUTO OFF ON 0 1	210
[:SENSe]:BANDwidth BWIDth:VIDeo:RATio:AUTO?	210
[:SENSe]:BANDwidth BWIDth:VIDeo:RATio?	210
[:SENSe]:BANDwidth BWIDth:VIDeo?	209

List of Commands

[[:SENSe]:BANDwidth BWIDth[:RESolution] <freq>	207
[[:SENSe]:BANDwidth BWIDth[:RESolution]:AUTO OFF ON 0 1	207
[[:SENSe]:BANDwidth BWIDth[:RESolution]:AUTO?	207
[[:SENSe]:BANDwidth BWIDth[:RESolution]?	207
[[:SENSe]:CORRection:BTS[:RF]:GAIN <rel_ampl>	226
[[:SENSe]:CORRection:BTS[:RF]:GAIN?	226
[[:SENSe]:CORRection:IMPedance[:INPut][:MAGNitude] 50 75	222
[[:SENSe]:CORRection:IMPedance[:INPut][:MAGNitude]?	222
[[:SENSe]:CORRection:MS[:RF]:GAIN <rel_ampl>	226
[[:SENSe]:CORRection:MS[:RF]:GAIN?	226
[[:SENSe]:CORRection:SA[:RF]:GAIN <rel_ampl>	225
[[:SENSe]:CORRection:SA[:RF]:GAIN?	225
[[:SENSe]:FEED RF IQ EXTMixer AREFERENCE	221
[[:SENSe]:FEED:AREFERENCE REF50 REF4800 COMB OFF	223
[[:SENSe]:FEED:AREFERENCE?	223
[[:SENSe]:FEED:DATA:STORe	227
[[:SENSe]:FEED?	221
[[:SENSe]:FREQUency:CENTer <freq>	219
[[:SENSe]:FREQUency:CENTer?	219
[[:SENSe]:FREQUency:SPAN <freq>	233
[[:SENSe]:FREQUency:SPAN:BANDwidth[:RESolution]:RATio <integer>	211
[[:SENSe]:FREQUency:SPAN:BANDwidth[:RESolution]:RATio:AUTO OFF ON 0 1	211
[[:SENSe]:FREQUency:SPAN:BANDwidth[:RESolution]:RATio:AUTO?	211
[[:SENSe]:FREQUency:SPAN:BANDwidth[:RESolution]:RATio?	211
[[:SENSe]:FREQUency:SPAN:FULL	235
[[:SENSe]:FREQUency:SPAN:PREVious	237
[[:SENSe]:FREQUency:SPAN?	233
[[:SENSe]:POWer[:RF]:ATTenuation <rel_ampl>	190
[[:SENSe]:POWer[:RF]:ATTenuation:STEP[:INCReMENT] 10dB 2dB	195
[[:SENSe]:POWer[:RF]:ATTenuation:STEP[:INCReMENT]?	195
[[:SENSe]:POWer[:RF]:ATTenuation?	190

List of Commands

<code>[:SENSe]:POWer[:RF]:EATTenuation <rel_ampl></code>	192
<code>[:SENSe]:POWer[:RF]:EATTenuation:STATe OFF ON 0 1</code>	192
<code>[:SENSe]:POWer[:RF]:EATTenuation:STATe?</code>	192
<code>[:SENSe]:POWer[:RF]:EATTenuation?</code>	192
<code>[:SENSe]:POWer[:RF]:GAIN:BAND LOW FULL</code>	203
<code>[:SENSe]:POWer[:RF]:GAIN:BAND?</code>	203
<code>[:SENSe]:POWer[:RF]:GAIN[:STATe] OFF ON 0 1</code>	203
<code>[:SENSe]:POWer[:RF]:GAIN[:STATe]?</code>	203
<code>[:SENSe]:POWer[:RF]:MIXer:RANGe[:UPPer] <real></code>	195
<code>[:SENSe]:POWer[:RF]:MIXer:RANGe[:UPPer]?</code>	195
<code>[:SENSe]:POWer[:RF]:PADJust <freq></code>	198
<code>[:SENSe]:POWer[:RF]:PADJust:PRESelector MWAVE MMWave EXTernal</code>	199
<code>[:SENSe]:POWer[:RF]:PADJust:PRESelector?</code>	199
<code>[:SENSe]:POWer[:RF]:PADJust?</code>	198
<code>[:SENSe]:POWer[:RF]:PCENter</code>	197
<code>[:SENSe]:POWer[:RF]:RANGe:AUTO ON OFF 1 0</code>	194
<code>[:SENSe]:POWer[:RF]:RANGe:AUTO?</code>	194
<code>[:SENSe]:POWer[:RF]:RANGe:OPTimize IMMEDIATE</code>	193
<code>[:SENSe]:POWer[:RF]:RANGe:OPTimize:ATTenuation OFF ELECTrical COMBined</code>	194
<code>[:SENSe]:POWer[:RF]:RANGe:OPTimize:ATTenuation?</code>	194
<code>[:SENSe]:ROSCillator:EXTernal:FREQuency <freq></code>	229
<code>[:SENSe]:ROSCillator:EXTernal:FREQuency?</code>	229
<code>[:SENSe]:ROSCillator:SOURce:TYPE INTernal EXTernal SENSe</code>	228
<code>[:SENSe]:ROSCillator:SOURce:TYPE?</code>	228
<code>[:SENSe]:ROSCillator:SOURce?</code>	228
<code>[:SENSe]:SPECTrum:ADC:DITHer:AUTO[:STATe] ON OFF 1 0</code>	381
<code>[:SENSe]:SPECTrum:ADC:DITHer:AUTO[:STATe]?</code>	381
<code>[:SENSe]:SPECTrum:ADC:DITHer[:STATe] ON OFF 1 0</code>	381
<code>[:SENSe]:SPECTrum:ADC:DITHer[:STATe]?</code>	381
<code>[:SENSe]:SPECTrum:AVERage:COUNT <integer></code>	373
<code>[:SENSe]:SPECTrum:AVERage:COUNT?</code>	373

List of Commands

[[:SENSe]:SPEcTrum:AVErAge:TCONtrol EXPONential REPeat	374
[[:SENSe]:SPEcTrum:AVErAge:TCONtrol?	374
[[:SENSe]:SPEcTrum:AVErAge:TYPE LOG MAXimum MINimum RMS SCALar	374
[[:SENSe]:SPEcTrum:AVErAge:TYPE?	374
[[:SENSe]:SPEcTrum:AVErAge[:STATE] ON OFF 1 0	373
[[:SENSe]:SPEcTrum:AVErAge[:STATE]?	373
[[:SENSe]:SPEcTrum:BANDwidth:IF:FLATness ON OFF 1 0	383
[[:SENSe]:SPEcTrum:BANDwidth:IF:FLATness?	383
[[:SENSe]:SPEcTrum:BANDwidth:PADC ON OFF 1 0	375
[[:SENSe]:SPEcTrum:BANDwidth:PADC?	375
[[:SENSe]:SPEcTrum:BANDwidth:PFFT:AUTO ON OFF 1 0	377
[[:SENSe]:SPEcTrum:BANDwidth:PFFT:AUTO?	377
[[:SENSe]:SPEcTrum:BANDwidth:PFFT:TYPE	376
[[:SENSe]:SPEcTrum:BANDwidth:PFFT:TYPE?	376
[[:SENSe]:SPEcTrum:BANDwidth:PFFT[:SIZE] <bandwidth>	377
[[:SENSe]:SPEcTrum:BANDwidth:PFFT[:SIZE]?	377
[[:SENSe]:SPEcTrum:BANDwidth[:RESolution] <bandwidth>	372
[[:SENSe]:SPEcTrum:BANDwidth[:RESolution]:AUTO ON OFF 1 0	372
[[:SENSe]:SPEcTrum:BANDwidth[:RESolution]:AUTO?	372
[[:SENSe]:SPEcTrum:BANDwidth[:RESolution]?	372
[[:SENSe]:SPEcTrum:FFT:LENGth <integer>	380
[[:SENSe]:SPEcTrum:FFT:LENGth:AUTO ON OFF 1 0	379
[[:SENSe]:SPEcTrum:FFT:LENGth:AUTO?	379
[[:SENSe]:SPEcTrum:FFT:LENGth?	380
[[:SENSe]:SPEcTrum:FFT:RBWPoints <real>	379
[[:SENSe]:SPEcTrum:FFT:RBWPoints?	379
[[:SENSe]:SPEcTrum:FFT:WINDow:LENGth <integer>	380
[[:SENSe]:SPEcTrum:FFT:WINDow:LENGth?	380
[[:SENSe]:SPEcTrum:FFT:WINDow[:TYPE] BH4Tap BLACKman FLATtop GAUSSian HAM- Ming HANNing KB70 KB90 KB110 UNIFORM	378
[[:SENSe]:SPEcTrum:FFT:WINDow[:TYPE]?	378

List of Commands

[[:SENSe]:SPEcTrum:FREQuency:SPAN <freq>	360
[[:SENSe]:SPEcTrum:FREQuency:SPAN?	360
[[:SENSe]:SPEcTrum:IF:GAIN:AUTO[:STATe] ON OFF 1 0	382
[[:SENSe]:SPEcTrum:IF:GAIN:AUTO[:STATe]?	382
[[:SENSe]:SPEcTrum:IF:GAIN[:STATe] AUTOOrange LOW HIGH	382
[[:SENSe]:SPEcTrum:IF:GAIN[:STATe]?	382
[[:SENSe]:SWEep:FFT:WIDTh <real>	328
[[:SENSe]:SWEep:FFT:WIDTh:AUTO OFF ON 0 1	329
[[:SENSe]:SWEep:FFT:WIDTh:AUTO?	329
[[:SENSe]:SWEep:FFT:WIDTh?	328
[[:SENSe]:SWEep:POINts <integer>	329
[[:SENSe]:SWEep:POINts?	329
[[:SENSe]:SWEep:TIME <time>	321
[[:SENSe]:SWEep:TIME:AUTO OFF ON 0 1	321
[[:SENSe]:SWEep:TIME:AUTO:RULEs NORMAl ACCuracy SRESponse	324
[[:SENSe]:SWEep:TIME:AUTO:RULEs:AUTO[:STATe] ON OFF 1 0	324
[[:SENSe]:SWEep:TIME:AUTO:RULEs:AUTO[:STATe]?	324
[[:SENSe]:SWEep:TIME:AUTO:RULEs?	324
[[:SENSe]:SWEep:TIME:AUTO?	321
[[:SENSe]:SWEep:TIME?	321
[[:SENSe]:SWEep:TYPE FFT SWEep	326
[[:SENSe]:SWEep:TYPE:AUTO OFF ON 0 1	326
[[:SENSe]:SWEep:TYPE:AUTO:RULEs SPEed DRANge	327
[[:SENSe]:SWEep:TYPE:AUTO:RULEs:AUTO[:STATe] OFF ON 0 1	327
[[:SENSe]:SWEep:TYPE:AUTO:RULEs:AUTO[:STATe]?	327
[[:SENSe]:SWEep:TYPE:AUTO:RULEs?	327
[[:SENSe]:SWEep:TYPE:AUTO?	326
[[:SENSe]:SWEep:TYPE?	326
[[:SENSe]:WAVEform:ADC:DITHer:AUTO[:STATe] OFF ON 0 1	419
[[:SENSe]:WAVEform:ADC:DITHer:AUTO[:STATe]?	419
[[:SENSe]:WAVEform:ADC:DITHer[:STATe] OFF ON 0 1	419

List of Commands

[[:SENSe]:WAVeform:ADC:DITHer[:STATe]?	419
[[:SENSe]:WAVeform:AVERAge:COUNT <integer>	416
[[:SENSe]:WAVeform:AVERAge:COUNT?	416
[[:SENSe]:WAVeform:AVERAge:TCONtrol EXPonential REPeat	417
[[:SENSe]:WAVeform:AVERAge:TCONtrol?	417
[[:SENSe]:WAVeform:AVERAge:TYPE LOG MAXimum MINimum RMS SCALar	417
[[:SENSe]:WAVeform:AVERAge:TYPE?	417
[[:SENSe]:WAVeform:AVERAge[:STATe] OFF ON 0 1	416
[[:SENSe]:WAVeform:AVERAge[:STATe]?	416
[[:SENSe]:WAVeform:BANDwidth:SHAPe GAUSSian FLATtop	414
[[:SENSe]:WAVeform:BANDwidth:SHAPe?	414
[[:SENSe]:WAVeform:BANDwidth[:RESolution] <freq>	414
[[:SENSe]:WAVeform:BANDwidth[:RESolution]?	414
[[:SENSe]:WAVeform:IF:GAIN:AUTO[:STATe] ON OFF 1 0	420
[[:SENSe]:WAVeform:IF:GAIN:AUTO[:STATe]?	420
[[:SENSe]:WAVeform:IF:GAIN[:STATe] AUTOrange LOW HIGH	420
[[:SENSe]:WAVeform:IF:GAIN[:STATe]?	420
[[:SENSe]:WAVeform:SWEep:TIME <time>	418
[[:SENSe]:WAVeform:SWEep:TIME?	418
FLAT GAUSSian	376
INST:NSEL 1	317
INST:NSEL 75	318
INST:NSEL 8	317
INST:NSEL 9	318
INST:SEL BASIC	317
INST:SEL SA	317
INST:SEL W-CDMA	318
INST:SEL WIMAXOFDMA	318
SYSTem:HID?	132
SYSTem:LKEY <"OptionInfo">	131
SYSTem:LKEY:DELeTe <"OptionInfo">	131

List of Commands

SYSTem:LKEY:LIST?	131
SYSTem:LKEY? <"OptionInfo">	132
TRIGger:WAVeform:SOURce EXTernal[1] EXTernal2 FRAME IF VIDeo IMMediate LINE RF- Burst	422
TRIGger:WAVeform:SOURce?	422

This chapter provides information on using the IQ Analyzer Mode in the Agilent MXA Signal Analyzer. It also documents some of the available optional hardware that can be used in this mode. This includes N9020AK options EA3 (electronic attenuator), B25 (wide analysis bandwidth), and the preamp options (P02, p08, p13, p26). Option B25 must be used with the measurements found in IQ Analyzer Mode since the optional wideband hardware cannot be accessed in other modes.

What Does IQ Analyzer Mode Do?

IQ Analyzer Mode makes frequency domain and time domain measurements. These measurements often use alternate hardware signal paths then a comparable measurement in the Signal Analysis Mode using the Swept SA measurement. These frequency domain and time domain measurements can be used to output I/Q data results when measuring complex modulated digital signals.

- Spectrum Measurement (Frequency Domain)

This measurement is comparable to a precision microwave spectrum analyzer measurement that also provides demodulated I/Q data for individual I and Q amplitude data pairs.

- Waveform Measurement (Time Domain)

This measurement is comparable to a precision vector signal analyzer measurement that also provides demodulated I/Q data for individual magnitude and phase analysis.

The following optional alternate hardware is typically used with IQ Analyzer Mode:

- **Option N9020AK EA3** provides an alternate attenuator that switches electronically. It has a maximum of 40 dB in 1 dB steps. (The standard attenuator is 70 dB maximum attenuation in 2 dB steps.). This hardware may be accessed from within IQ Analyzer Mode, but only with the narrowband IF path. It cannot be used with the N9020AK B25 wideband path.
- **Option N9020AK B25** provides an alternate wideband digital IF signal path with a maximum bandwidth of 25 MHz. This hardware can only be accessed from within IQ Analyzer Mode.

Using the Electronic Attenuator Hardware (Option N9020AK EA3)

Option N9020AK EA3 is required for many of the optional measurement personalities. This optional attenuator does the fast switching necessary to accommodate the complicated multiple-sweep, averaged measurements required for digital communication systems testing. The hardware is specified for measurements up to a maximum of 3.6 GHz and works with many different measurement personalities. These additional measurement personalities are purchased separately and are accessed using the **Mode** key. See [“Installing Application Software” on page 38](#) for information about loading measurement instrument software.

Using the Wideband Analysis Hardware (Option N9020AK B25)

Option N9020AK B25 hardware enables up to 25 MHz of capture bandwidth. IQ Analyzer Mode is provided to access this wideband hardware.

There are couplings and interactions when using the optional hardware with other options and hardware.

- The wideband functionality is only available in IQ Analyzer Mode. It cannot be accessed from the Spectrum Analysis Mode nor from other optional measurement modes.
- If this wideband hardware is installed, IQ Analyzer Mode will always make measurements above 3.6 GHz using the wideband path. The standard “narrowband” path is not available in IQ Analyzer Mode above 3.6 GHz.
- Option N9020AK EA3 (1 dB electronic attenuator for digital communications) is not required for operation of the wideband option (N9020AK B25).
- If the wideband hardware is installed, but the electronic attenuator (N9020AK EA3) is *not* installed, then the wideband input path will be used for all measurements in IQ Analyzer Mode. Since the standard “narrowband” path is not available in IQ Analyzer Mode without Option EA3, only the Option B25 specifications will apply.
- The preamp options (N9020AK P03,P08, P13, P26) cannot be used in IQ Analyzer Mode with Option the wideband option N9020AK B25.

TIP Improved accuracy can be obtained using an external calibration. This capability is available using the Agilent 89600A Vector Signal Analysis Software.

Installing Application Software

When you want to install a measurement application after your initial hardware purchase, you actually only need to license it. All of the available applications are loaded in your analyzer at the time of purchase.

So when you purchase an application, you will receive an entitlement certificate that is used to obtain a license key for that particular measurement application. Enter the license key that you obtain into the N9020A Signal Analyzer to activate the new measurement application. For more information see “[Obtaining and Installing a License Key](#)” below.

For the latest information on Agilent MXA Signal Analyzer measurement applications and upgrade kits, visit the following internet URL.

http://www.agilent.com/find/sa_upgrades

Viewing a License Key

Measurement personalities purchased with your instrument have been installed and activated at the factory before shipment. The instrument requires a unique **License Key** for every measurement application purchased. The license key is a hexadecimal string that is specific to your measurement application, instrument model number and serial number. It enables you to install, or reactivate that particular application.

Press **System, Show, System** to display which measurement applications are currently licensed in your analyzer.

Press **System, More, Licensing . . .** to view the license keys for the installed measurement applications.

NOTE You may want to keep a copy of your license key in a secure location. You can print out a copy of the display showing the license numbers to do this. If you should lose your license key, call your nearest Agilent Technologies service or sales office for assistance.

Obtaining and Installing a License Key

If you purchase an additional application that requires installation, you will receive an “Entitlement Certificate” which may be redeemed for a license key for one instrument. Follow the instructions that accompany the certificate to obtain your license key.

Installing a license key for the selected application can be done automatically using a USB memory device. To do this, you would put the license file on the USB memory device at the root level. Follow the instructions that come with your software installation kit.

Installing a license key can also be done manually using the license management application in the instrument. It is found through the instrument front panel keys at **System, Licensing . . .**, or internally at C:\Programming Files\Agilent\Licensing.

NOTE You can also use these procedures to reinstall a license key that has been

_____ accidentally deleted, or lost due to a memory failure.

Missing and Old Measurement Application Software

All the software applications were loaded at the time of original instrument manufacture. It is a good idea to regularly update your software with the latest available version. This assures that you get any improvements and expanded functionality that is available.

Because the software was loaded at the initial purchase, there may be additional measurement applications that are now available. If the application you are interested in licensing is not available, you will need to do a software update. (Press **System, Show, System.**)

Check the Agilent internet website for the latest software versions available for downloading:

http://www.agilent.com/find/mxa_software

You must load the updated software package into the analyzer from a USB drive, or directly from the internet. An automatic loading program is included with the files.

The front-panel key functions in this section are accessible when you are using any of the measurements available in this application.

System

Opens a menu of keys that access various configuration menus and dialogs.

Remote Command Notes	No remote command for this key specifically.
Key Path	Front-panel key

Show

Opens a menu of choices that enable you to select the information window you want to view.

Key Path	System
----------	---------------

Errors

There are two modes for the Errors selection, **History** and **Status**.

Errors does not automatically refresh; you must press the Refresh button or leave the screen and return to it to refresh it.

History brings up a screen displaying the event log in chronological order, with the newest event at the top.

The history queue can hold up to 100 messages (if a message has a repeat count greater than 1 it only counts once against this number of 100). Note that this count bears no relation to the size of the SCPI queue. If the queue extends onto a second page, a scroll bar appears to allow scrolling with a mouse. Time is displayed to the second.

Status brings up a screen summarizing the status conditions currently in effect. Note that time is displayed to the second.

The fields on the Errors display are:

Type (unlabeled)

Displays the icon identifying the event or condition as an error or warning.

ID

Displays the error number.

Message

Displays the message text.

Repeat (RPT)

This field shows the number of consecutive instances of the event, uninterrupted by other events. In other words, if an event occurs 5 times with no other intervening event, the value of repeat will be 5.

If the value of Repeat is 1 the field does not display. If the value of Repeat is >1, the time

and date shown are those of the most recent occurrence. If the value of repeat reaches 999,999 it stops there.

Time

Shows the most recent time (including the date) at which the event occurred.

Mode All
Key Path **System, Show**

Saved State No

Mode All

Remote Command :SYSTem:ERRor [:NEXT] ?

Example :SYST:ERR?

Restriction and Notes The return string has the format:
“<Error Number>,<Error>”
Where <Error Number> and <Error> are defined in the Master Error Messages document.

Next Page

Next Page and Previous Page menu keys move the user between pages of the log, if it fills more than one page. These keys are grayed out in some cases:

If on the last page of the log, the Next Page key is grayed out

If on the first page of the log, the Previous Page key is grayed out.

If there is only one page, both keys are grayed out.

Key Path **System, Show, Show Errors**

Previous Page

See [Next Page](#).

History

The History and Status keys select the Errors view. The Status key has a second line which shows a number in [square brackets]. This is the number of currently open status items.

Key Path **System, Show, Show Errors**

Status

See [History](#).

Verbose SCPI On/Off

This is a capability that will allow the SCPI data stream to be displayed when a SCPI error is detected, showing the characters which stimulated the error and several of the characters preceding the error.

Mode	All
Remote Command	:SYSTem:ERRor:VERBoSe OFF ON 0 1 :SYSTem:ERRor:VERBoSe?
Example	:SYST:ERR:VERB ON
Preset	This is unaffected by Preset but is set to OFF on a “Restore System Defaults->Misc”
State Saved	No
Range	On Off
Key Path	System, Show, Show Errors

Refresh

When pressed, refreshes the Show Errors display.

Key Path	System, Show, Show Errors
----------	----------------------------------

Clear Error Queue

This clears all errors in all error queues.

NOTE **Clear Error Queue** does not affect the current status conditions.

Mode Preset does not clear the error queue.

Restore System Defaults will clear all error queues.

*CLS only clears the queue if it is sent remotely and *RST does not affect any error queue.

Switching modes does not affect any error queues.

Key Path	System, Show, Show Errors
----------	----------------------------------

System

The System screen is formatted into three groupings: product descriptive information, options tied to the hardware, and software products:

```

<Product Name> <Product Description>
Product Number: N9020A
Serial Number: US46220924
Firmware Revision: A.01.01
Computer Name: <hostname>
Host ID: N9020A,US44220924

N9020A-503      Frequency Range to 3.6 GHz
N9020A-PFR     Precision Frequency Reference
N9020A-P03     Preamp 3.6 GHz

N9060A-2FP     Spectrum Analysis Measurement Suite  1.0.0.0
N9073A-1FP     WCDMA                                1.0.0.0
N9073A-2FP     WCDMA with HSDPA                     1.0.0.0

```

The Previous Page is grayed-out if the first page of information is presently displayed. The Next Page menu key is grayed-out if the last page is information is presently displayed.

Mode	All
Preset	OFF
State Saved	No
Range	On Off
Key Path	System, Show

Show Hardware

The Hardware screen is used to view details of the installed hardware. The screen is formatted into two groupings: product descriptive information and hardware information. The hardware information is listed in a table format:

Utility Functions System

```
<Product Name> <Product Description>
Product Number: N9020A
Serial Number: US44240924
Firmware Revision: A.01.01
Computer name: <hame>
Host ID: N9020A,US44220924

Assembly Name | Part # | Serial # | Matl Rev | Bd Rev | OF Rev | Hw Id | Misc
Analog IF     | E441060104 | 7804400066 | 003 | 0 | A | 15 | 1.0.0.0
```

The Previous Page key is grayed-out if the first page of information is presently displayed. The Next Page menu key is grayed-out if the last page of information is presently displayed.

Mode	All
Preset	OFF
State Saved	No
Range	On Off
Key Path	System, Show

LXI

This key shows you the product number, serial number, firmware revision, computer name, IP address, Host ID, LXI Class, LXI Version, MAC Address, and the Auto-MDIX Capability.

Key Path	System, Show
----------	---------------------

LAN Reset

This key resets the LAN connection.

Key Path	System, Show, LXI
----------	--------------------------

Power On

The Power On menu key enables you to select how the instrument should power on. The

options are: Mode Preset, User Preset and Last State.

Mode	All
Remote Command	:SYSTem:PON:TYPE MODE USER LAST PRESet :SYSTem:PON:TYPE?
Example	:SYST:PON:TYPE MODE
Preset	This is unaffected by Preset but is set to Mode on a “Restore System Defaults->All”
State Saved	No
Key Path	System

Mode Preset

Sets **Power On** to **Mode Preset**. When the analyzer is powered on in Mode Preset, it will perform a Mode Preset to all modes in the instrument and it will wake up in the power-on mode. It will not affect any settings beyond what a normal Mode Preset affects.

Mode	All
Example	SYST:PON:TYPE MODE
Key Path	System, Power On

User Preset

Sets **Power On** to **User Preset**. When the analyzer is powered on in User Preset, it will User Preset each mode and switch to the power-on mode. Power On User Preset will not affect any settings beyond what a normal User Preset affects.

NOTE An instrument could never power up for the first time in User Preset.

Mode	All
Example	SYST:PON:TYPE USER
Key Path	System, Power On

Last State

Sets **Power On** to **Last**. When the analyzer is powered on, it will put all modes in the last state they were in prior to when the analyzer was put into Power Standby and it will wake up in the mode it was last in prior to powering off the instrument. The saving of the active mode prior to shutdown happens behind the scenes when a controlled shutdown is requested by using the front panel power **Standby** key or by using the remote command SYSTem:PDOWn. The non-active modes are saved as they are deactivated and recalled by Power On Last State.

NOTE An instrument could never power up for the first time in Last. If line power to the analyzer is interrupted, for example by pulling the line cord plug or by switching off power to a test rack, Power On Last State will not work properly. For more information see Power Standby (Instrument Shutdown).

Mode	All
Example	SYST:PON:TYPE LAST
Restriction and Notes	Power on Last State only works if the user has done a controlled shutdown prior to powering on in Last. If a controlled shutdown is not done when in Power On Last State, the instrument will power up in the last active mode, but it may not power up in the active mode's last state. If an invalid mode state is detected, a Mode Preset will occur. To control the shutdown under remote control use the :SYSTem:PDOWn command.
Key Path	System, Power On

Power On Mode

This menu key brings up a Mode Menu that lists the available modes and enables the user to select which Mode to be the power-on mode. This Mode Menu is a 1-of-N list of available modes; not the Mode Menu under the Mode front-panel key. They will look the same, but have very different behavior.

This Mode will be used for Power On Mode Preset and Restore System Defaults All. The factory will load a default power-on mode using what modes are installed in the instrument and the precedence table documented in the Power-On Mode section.


NOTE When measurement applications are loaded, this Mode Menu contains a menu key for each loaded application. Under the Service subsystem, there is a way to change the factory default Power On Mode.

Mode	All
Remote Command	:SYSTem:PON:MODE SA CDMA DMOdulation EDGEgsm NADC NFIGure PDC PNoise TDScdma :SYSTem:PON:MODE?
Example	SYST:PON:MODE SA
Restriction and Notes	The list of possible modes (and remote parameters) to choose from is dependent on which modes are installed in the instrument.

Preset	This is unaffected by Preset but is set on a “Restore System Defaults->All” to SA unless Spectrum Analysis mode is not installed in the instrument in which case the factory will load the default power-on mode.
State Saved	No
Key Path	System, Power On

Restore Power On Defaults

This selection causes the Power On Type and Power On Mode settings to be a reset to their default value. This level of Restore System Defaults does not affect any other system settings, mode settings and does not cause a mode switch. The Power On menu key under the Restore System Defaults menu causes the same action.



If you press any key other than OK or Enter, it is construed as a Cancel, because the only path that will actually cause the reset to be executed is through OK or Enter.

Example	:SYST:DEF PON
Key Path	System, Power On

Alignments

The Alignments Menu controls and displays the automatic alignment of the instrument, and provides the ability to restore the default alignment values.

Key Path	System
----------	---------------

Auto Align

Configures the method for which the automatic background alignment is run.

Automatic background alignments are run periodically between measurement acquisitions. The instrument’s software determines when alignments are to be performed to maintain warranted operation. Highest measurement throughput is obtained with Auto Align Off, however the user assumes responsibility for warranted measurements by periodically performing an Align Now, All. The instrument will inform the user that an

alignment is needed based on the Alert setting.

When Auto Align is executing, Bit 0 in the Status Operational register is set.

An Auto Align execution cannot be aborted with the Cancel (ESC) key. To interrupt an Auto Align execution, select **Auto Align Off**.

Mode	All
Remote Command	:CALibration:AUTO ON PARTial OFF ALERT :CALibration:AUTO?
Example	:CAL:AUTO ON
Restriction and Notes	While Auto Align is executing, bit 0 of Status Operation register is set.
Dependencies/Couplings	Auto Align is set to Off if Restore Align Data is invoked.
Preset	This is unaffected by Preset but is set to ON upon a “Restore System Defaults->Align”.
State Saved	No
Key Path	System, Alignments

Normal

Auto Align, Normal turns on the automatic alignment of all measurement systems. Auto Align, Normal maintains the instrument in warranted operation across varying temperature and over time.

If the condition “Align Now, All required” is set, transition to Auto Align, Normal will perform a full alignment and clear the “Align Now, All required” condition before beginning the auto alignment processing.

An interfering user signal may prevent automatic alignment of the RF subsystem. If this occurs, the Error Condition “Align skipped: 50 MHz interference” or “Align skipped: 4.8 GHz interference” is reported, the Status Questionable Calibration bit 11 is set, and the alignment proceeds. When a subsequent alignment of the RF subsystem succeeds, either by the next cycle of automatic alignment or from an Align Now, RF, the Error Condition and Status Questionable Calibration bit 11 are cleared.

When Auto Align, Normal is selected the Auto Align Off time is set to zero.

When Auto Align, Normal is selected the Settings Panel indicates ALIGN AUTO:

Mode	All
Example	:CAL:AUTO ON

Restriction and Notes Alignment processing as a result of the transition to Normal will be executed sequentially. Thus, *OPC? or *WAI following CAL:AUTO ON will return when the alignment processing is complete.

The presence of an external signal may interfere with the RF portion of the alignment. If so, the Error Condition “Align skipped: 50 MHz interference” or “Align skipped: 4.8 GHz interference” is reported, and bit 11 is set in the Status Questionable Calibration register. A subsequent alignment of the RF will clear the condition, and clear bit 11 in the Status Questionable Calibration register.

Key Path System, Alignments, Auto Align

Partial

Auto Align, Partial disables thorough automatic alignment and the maintenance of warranted operation for the benefit of improved measurement throughput, with accuracy retained for the Resolution Bandwidths. With Auto Align set to Partial, the operator is responsible for maintaining warranted operation by performing Align Now, All on a periodic basis. The Auto Align, Alert mechanism will notify the operator when an Align Now, All should be performed.

When Auto Align, Partial is selected the elapsed time counter begins for Auto Align Off time.

When Auto Align, Partial is selected the Settings Panel indicates ALIGN PARTIAL with a warning icon (warning icon is intended to inform the operator they are responsible for the maintaining the warranted operation of the instrument):



Mode All

Example :CAL:AUTO PART

Restriction and Notes Auto Align Partial begins the elapsed time counter for Auto Align Off time.

Key Path System, Alignments, Auto Align


Off

Auto Align, Off disables automatic alignment and the maintenance of warranted operation, for the benefit of maximum measurement throughput. With Auto Align set to Off, the operator is responsible for maintaining warranted operation by performing Align Now, All on a periodic basis. The Auto Align, Alert mechanism will notify the operator when and Align Now, All should be performed.

When Auto Align, Off is selected the elapsed time counter begins for Auto Align Off time is initialized.

When Auto Align, Off is selected the Settings Panel indicates ALIGN OFF with a warning

icon (warning icon is intended to inform the operator they are responsible for the maintaining the warranted operation of the instrument):



Mode	All
Example	:CAL:AUTO OFF
Restriction and Notes	Auto Align Off begins the elapsed time counter for Auto Align Off time.
Dependencies/Couplings	Auto Align is set to Off if Restore Align Data is invoked.
Key Path	System, Alignments, Auto Align

All but RF

Auto Align, All but RF, configures automatic alignment to include or exclude the RF subsystem. (Eliminating the automatic alignment of the RF subsystem prevents changes in the input impedance between measurements, which could cause input device instability.) When Auto Align, All but RF ON is selected, the operator is responsible for performing an Align Now, RF with every 3 degrees Celsius temperature change, or a time span of 24 hours since the last Align Now, RF. The Auto Align, Alert mechanism will notify the operator to perform an Align Now, All when the time expires or temperature variation is exceeded.

When Auto Align, All but RF ON is selected the Settings Panel indicates ALIGN AUTO/NO RF with a warning icon (warning icon is intended to inform the operator they are responsible for the maintaining the RF alignment of the instrument):



Mode	All
Remote Command	:CALibration:AUTO:MODE ALL NRF :CALibration:AUTO:MODE?
Example	:CAL:AUTO:MODE NRF
Preset	This is unaffected by Preset but is set to ALL on a “Restore System Defaults->Align”.
State Saved	No
Key Path	System, Alignments, Auto Align

Alert

The instrument will signal an Alert when conditions exist such that the user will need to perform a full alignment (for example, Align Now, All). The alert is the Error Condition “Align Now, All required” and bit 14 is set in the Status Questionable Calibration register.

The Alert can be configured in one of four settings; Time & Temperature, 24 hours, 7 days,

or None.

A confirmation is required when a selection other than Time & Temperature is chosen. This prevents accidental deactivation of alerts.

With Auto Align set to Normal the configuration of Alert is not relevant as the instrument's software maintains the instrument in warranted operation.

Mode	All
Remote Command	:CALibration:AUTO:ALERT TTEMPerature DAY WEEK NONE :CALibration:AUTO:ALERT?
Example	:CAL:AUTO:ALERT TTEM
Remote Command Notes	The alert that alignment is needed is the setting of bit 14 in the Status Questionable Calibration register.
Preset	This is unaffected by Preset but is set to TTEMPerature on a "Restore System Defaults->Align".
State Saved	No
Key Path	System, Alignments, Auto Align

Time & Temperature


With Auto Align Alert set to Time & Temperature the instrument will signal an alert after 3 degrees Celsius temperature change or a time span of 24 hours since the last successful full alignment (for example, Align Now, All or completion of a thorough Auto Align). The alert is the Error Condition "Align Now, All required" and bit 14 is set in the Status Questionable Calibration register

Mode	All
Example	:CAL:AUTO:ALERT TTEM
Key Path	System, Alignments, Auto Align, Alert

24 hours

With Auto Align Alert set to 24 Hours the instrument will signal an alert after a time span of 24 hours since the last successful full alignment (for example, Align Now, All or completion of a thorough Auto Align). An operator may choose this selection in an environment where the temperature is stable on a daily basis. The alert is the Error Condition "Align Now, All required" and bit 14 is set in the Status Questionable Calibration register.

For front panel operation, confirmation is required to transition into this setting of Alert. The confirmation dialog is:




No confirmation is required when Alert is configured through a remote command.

Mode	All
Example	:CAL:AUTO:ALER DAY
Key Path	System, Alignments, Auto Align, Alert

7 days

With Auto Align Alert is set to 7 days the instrument will signal an alert after a time span of 168 hours since the last successful full alignment (for example, Align Now, All or completion of a thorough Auto Align). An operator may choose this selection in an environment where the temperature is stable on a weekly basis. The alert is the Error Condition “Align Now, All required” and bit 14 is set in the Status Questionable Calibration register.

For front panel operation, confirmation is required for the customer to transition into this setting of Alert. The confirmation dialog is:




No confirmation is required when Alert is configured through a remote command.

Mode	All
Example	:CAL:AUTO:ALER WEEK
Key Path	System, Alignments, Auto Align, Alert

None

With Auto Align Alert set to None the instrument will not signal an alert. This is provided for rare occasions where the operator is making a long measurement which cannot tolerate Auto Align interruptions, and must have the ability to capture a screen image at the end of the measurement without an alert posted to the display.

For front panel operation, confirmation is required to transition into this setting of Alert. The confirmation dialog is:



No confirmation is required when Alert is configured through a remote command.

Mode	All
Example	:CAL:AUTO:ALER NONE
Key Path	System, Alignments, Auto Align, Alert

Align Now

Accesses alignment processes that are immediate action operations that perform complete operations that run until complete.

Key Path	System, Alignments
----------	---------------------------

All

Immediately executes an alignment of all subsystems. The instrument stops any measurement currently underway, performs the alignment, then restarts the measurement from the beginning (similar to pressing the Restart key).

If an interfering user signal is present at the RF Input, the alignment is performed on all subsystems except the RF. After completion, the Error Condition “Align skipped: 50 MHz interference” or “Align skipped: 4.8 GHz interference” is set. In addition the Error Condition “Align Now, RF required” is set, and bits 11 and 12 are set in the Status Questionable Calibration register.

The query form of the remote commands (:CALibration[:ALL]? or *CAL?) invokes the alignment of all subsystems and returns a success or failure value. An interfering user signal is not grounds for failure; if the alignment was able to succeed on all portions but unable to align the RF because of an interfering signal, the resultant will be the success value.

Successful completion of Align Now, All will clear the “Align Now, All required” Error Condition, and clear bit 14 in the Status Questionable Calibration register. It will also begin the elapsed time counter for Last Align Now, All Time, and capture the Last Align Now, All Temperature.

If the Align RF subsystem succeeded in aligning (no interfering signal present), the elapsed time counter begins for Last Align Now, RF Time, and the temperature is captured for the Last Align Now, RF Temperature. In addition the Error Conditions “Align skipped: 50 MHz interference” and “Align skipped: 4.8 GHz interference” are cleared, the Error Condition “Align Now, RF required” is cleared, and bits 11 and 12 are cleared in the Status Questionable Calibration register

Align Now, All can be interrupted by pressing the Cancel (ESC) front panel key or remotely with Device Clear followed by the :ABORt SCPI command. When this occurs the Error Condition “Align Now, All required” is set, and bit 14 is set in the Status Questionable Condition register. This is because new alignment data may be employed for an individual subsystem, but not a cohesive set of data for all subsystems.

Mode	All
Remote Command	:CALibration[:ALL] :CALibration[:ALL]?
Example	:CAL
Restriction and Notes	An interfering user supplied signal will result in the instrument requiring an Align Now, RF with the interfering signal removed.
Dependencies/Couplings	Initializes the time for the Last Align Now, All Time. Records the temperature for the Last Align Now, All Temperature. If Align RF component succeeded, initializes the time for the Last Align Now, RF Time. If Align RF component succeeded, records the temperature for the Last Align Now, RF Temperature.

Remote Command	:CALibration[:ALL]? returns 0 if successful
Notes	:CALibration[:ALL]? returns 1 if failed :CALibration[:ALL]? is the same as *CAL? While Align Now, All is performing the alignment, bit 0 in the Status Operation register is set. Completion, or termination, will clear bit 0 in the Status Operation register. This command is sequential; it must complete before further SCPI commands are processed. Interrupting the alignment from remote is accomplished by invoking Device Clear followed by the :ABORt command. Successful completion will clear bit 14 in the Status Questionable Calibration register. An interfering user signal is not grounds for failure of Align Now, All. However, bits 11 and 12 are set in the Status Questionable Calibration register to indicate Align Now, RF is required.
Key Path	System, Alignments, Align Now
Mode	All
Remote Command	*CAL?
Example	*CAL?
Restriction and Notes	Everything about :CALibration[:ALL]? is synonymous with *CAL? including all conditions, status register bits, and couplings
Remote Command	*CAL? returns 0 if successful
Notes	*CAL? returns 1 if failed :CALibration[:ALL]? is the same as *CAL? See additional remarks described with :CALibration[:ALL]?

All but RF

Immediately executes an alignment of all subsystems except the RF subsystem. The instrument will stop any measurement currently underway, perform the alignment, then restart the measurement from the beginning (similar to pressing the Restart key). This can be used to align portions of the instrument that are not impacted by an interfering user signal.

The query form of the remote commands (:CALibration:NRf?) will invoke the alignment and return a success or failure value.

Successful completion of Align Now, All but RF will clear the “Align Now, All required” Error Condition, and clear bit 14 in the Status Questionable Calibration register. If “Align

Now, All required” was in effect prior to executing the All but RF, the Error Condition “Align Now, RF required” is asserted and bit 12 in the Status Questionable Calibration register is set. It will also begin the elapsed time counter for Last Align Now, All Time, and capture the Last Align Now, All Temperature.

Align Now, All but RF can be interrupted by pressing the Cancel (ESC) front panel key or remotely with Device Clear followed by the :ABORt SCPI command. When this occurs the Error Condition “Align Now, All required” is set, and bit 14 is set in the Status Questionable Condition register. This is because new alignment data may be employed for an individual subsystem, but not a cohesive set of data for all subsystems.

Mode	All
Remote Command	:CALibration:NRF :CALibration:NRF?
Example	:CAL:NRF
Dependencies/Couplings	Initializes the time for the Last Align Now, All Time. Records the temperature for the Last Align Now, All Temperature.
Remote Command Notes	:CALibration:NRF? returns 0 if successful :CALibration:NRF? returns 1 if failed While Align Now, All but RF is performing the alignment, bit 0 in the Status Operation register is set. Completion, or termination, will clear bit 0 in the Status Operation register. This command is sequential; it must complete before further SCPI commands are processed. Interrupting the alignment from remote is accomplished by invoking Device Clear followed by the :ABORt command. Successful completion will clear bit 14 in the Status Questionable Calibration register and set bit 12 if invoked with “Align Now, All required”.
Key Path	System, Alignments, Align Now

RF

Immediately executes an alignment of the RF subsystem. The instrument stops any measurement currently underway, performs the alignment, then restarts the measurement from the beginning (similar to pressing the Restart key).

If an interfering user signal is present at the RF Input, the alignment will terminate and raise the Error Condition “Align skipped: 50 MHz interference” or “Align skipped: 4.8 GHz interference”, and Error Condition “Align Now, RF required”. In addition, bits 11 and 12 will be set in the Status Questionable Calibration register.

The query form of the remote commands (:CALibration:RF?) will invoke the alignment of the RF subsystem and return a success or failure value. An interfering user signal is grounds for failure.

A failure encountered during alignment will set the Error Condition “Align RF failed” and set bit 3 in the Status Questionable Calibration register.

Successful completion of Align Now, RF clears the Error Conditions “Align skipped: 50 MHz interference” and “Align skipped: 4800 MHz interference” and the Error Conditions “Align RF failed” and “Align Now, RF required”, and clears bits 3, 11, and 12 in the Status Questionable Calibration register. It will also begin the elapsed time counter for Last Align Now, RF Time, and capture the Last Align Now, RF Temperature.

Align Now, RF can be interrupted by pressing the Cancel (ESC) front panel key or remotely with Device Clear followed by the :ABORt SCPI command. When this occurs, the Error Condition “Align Now, RF required” is set, and bit 12 is set in the Status Questionable Condition register. No new alignment data is employed.

Mode	All
Remote Command	:CALibration:RF :CALibration:RF?
Example	:CAL:RF
Restriction and Notes	An interfering user supplied signal will result in the instrument requiring an Align Now, RF with the interfering signal removed.
Dependencies/Couplings	Initializes the time for the Last Align Now, RF Time. Records the temperature for the Last Align Now, RF Temperature.
Remote Command Notes	:CALibration:RF? returns 0 if successful :CALibration:RF? returns 1 if failed (including interfering user signal) While Align Now, RF is performing the alignment, bit 0 in the Status Operation register is set. Completion, or termination, will clear bit 0 in the Status Operation register. This command is sequential; it must complete before further SCPI commands are processed. Interrupting the alignment from remote is accomplished by invoking Device Clear followed by the :ABORt command. Successful completion will clear bits 3, 11, and 12 in the Status Questionable Calibration register. A failure encountered during alignment will set the Error Condition “Align RF failed” and set bit 3 in the Status Questionable Calibration register. An interfering user signal will result in bits 11 and 12 to be set in the Status Questionable Calibration register to indicate Align Now, RF is required.
Key Path	System, Alignments, Align Now

Advanced

Advanced accesses alignment processes that are immediate action operations that perform operations that run until complete. Advanced alignments are performed on an irregular basis, or require additional operator interaction

Key Path **System, Alignments**

Characterize Preselector (Only with Option 508, 513, or 526)

The Preselector tuning curve drifts over temperature and time. The Amplitude, Presel Center function adjusts the preselector for accurate amplitude measurements at an individual frequency. Characterize Preselector improves the amplitude accuracy by ensuring the Preselector is approximately centered at all frequencies. Character Preselector is used in situations where absolute amplitude accuracy is not of utmost importance, and the throughput savings or convenience of not performing a Presel Center is desired. Presel Center is required prior to any measurement for best amplitude accuracy.

Characterize Preselector immediately executes a characterization of the Preselector. The instrument stops any measurement currently underway, performs the characterization, then restarts the measurement from the beginning (similar to pressing the Restart key).

The query form of the remote commands (:CALibration:YTF?) will invoke the alignment of the YTF subsystem and return a success or failure value.

A failure encountered during alignment will set the Error Condition “Characterize YTF failed” and set bit 9 in the Status Questionable Calibration register.

Successful completion of Advanced, Characterize Preselector will clear the Error Condition “Characterize YTF failed”, and clear bit 9 in the Status Questionable Calibration register. It will also begin the elapsed time counter for Last Characterize Preselector Time, and capture the Last Characterize Preselector Temperature.

The Last Characterize Preselector Time and Temperature must survive across the power cycle as this operation is performed infrequently.

Advanced, Characterize Preselector can be interrupted by pressing the Cancel (ESC) front panel key or remotely with Device Clear followed by the :ABORt SCPI command. No new characterization data is employed.

Mode	All
Remote Command	:CALibration:YTF :CALibration:YTF?
Example	:CAL:YTF
Restriction and Notes	For Option 508, 513, and 526 only.
Dependencies/Couplings	Initializes the time for the Last Characterize Preselector Time. Records the temperature for the Last Characterize Preselector Temperature.

Remote Command	:CALibration:YTF? returns 0 if successful
Notes	<p>:CALibration:YTF? returns 1 if failed (including interfering user signal)</p> <p>While Advanced, Characterize Preselector is performing the alignment, bit 0 in the Status Operation register is set. Completion, or termination, will clear bit 0 in the Status Operation register.</p> <p>This command is sequential; it must complete before further SCPI commands are processed. Interrupting the alignment from remote is accomplished by invoking Device Clear followed by the :ABORT command.</p> <p>Successful completion will clear bit 9 in the Status Questionable Calibration register.</p> <p>A failure encountered during alignment will set the Error Condition “Characterize Preselector failed” and set bit 9 in the Status Questionable Calibration register.</p>
Key Path	System, Alignments, Align Now

Show Alignment Statistics

Shows alignment information you can use to ensure that the instrument is operating in a specific manner. The Show Alignment Statistics screen is where you can view time and temperature information.

Values which are displayed are only updated when the Show Alignment Statistics screen is invoked, they are not updated while the Show Alignment Statistics screen is being displayed. The remote commands which access this information obtain current values.

The screen for Show Alignment Statistics is a Text Screen similar to Show System or Show Errors. Previous Page and Next Page menu key selections are available in conformance with the Text Screen standard.

The screen contents can be printed. The Show Alignment Statistics screen will be exited in conformance with the Text Screen standard.

An example of the Show Alignment Statistics screen would be similar to:

Utility Functions
System

Std Header	Product Number: N9020A Serial Number: US46340924 Firmware Revision: A.01.01		
Instrument Info	Time since start-up: Current Temperature:	300 hrs +28 degC	}
Auto Align Info	Time while Auto Align off:	90 min	
Std Align Now	Time since last Align Now All:	12.5 hrs	}
	Temperature since last Align Now All:	-1.3 degC	
	Time since last Align Now RF:	5 min	
If TG Option (Not Zorro1)	Temperature since last Align Now RF:	+0.1 degC	}
	Time since last Align TG:	2.5 hrs	
Opts 508,513 526	Temperature since last Align TG:	+0.2 degC	}
	Last Characterize Preselector:	Jun 1, 2006 15:00:00	
	Last Characterize Preselector Temperature:	+32.1 degC	} Time & Temperature 'stamp'

A successful Align Now, RF will set the Last Align RF temperature to the current temperature, and reset the Last Align RF time. A successful Align Now, All or Align Now, All but RF will set the Last Align Now All temperature to the current temperature, and reset the Last Align Now All time. A successful Align Now, All will also reset the Last Align RF items if the RF portion of the Align Now succeeded.

Mode All
Restriction and Notes The values displayed on the screen are only updated upon entry to the screen and not updated while the screen is being displayed.

Key Path **System, Alignments**

Saved State No

Mode All

Remote Command :SYSTem:PON:TIME?

Example :SYST:PON:TIME?

Restriction and Notes Value is the time since the present application start-up in seconds.

Key Path **Visual annotation in the Show Alignment Statistics screen**

Saved State No

Mode All

Remote Command	:CALibration:TEMPerature:CURRent?
Example	:CAL:TEMP:CURR?
Restriction and Notes	Value is in degrees Centigrade. Value is invalid if using default alignment data (Align Now, All required)
Key Path	Visual annotation in the Show Alignment Statistics screen
Saved State	No
Mode	All
Remote Command	:CALibration:TIME:LALL?
Example	:CAL:TIME:LALL?
Restriction and Notes	Value is the elapsed time, in seconds, since the last successful Align Now, All or Align Now, All but RF was executed. Returns NaN if no Align Now, All or Align Now, All but RF executed since power-up.
Key Path	Visual annotation in the Show Alignment Statistics screen
Saved State	No
Mode	All
Remote Command	:CALibration:TEMPerature:LALL?
Example	:CAL:TEMP:LALL?
Restriction and Notes	Value is in degrees Centigrade at which the last successful Align Now, All or Align Now, All but RF was executed. Returns NaN if no Align Now, All or Align Now, All but RF executed since power-up.
Key Path	Visual annotation in the Show Alignment Statistics screen
Saved State	No
Mode	All
Remote Command	:CALibration:TIME:LRF?
Example	:CAL:TIME:LRF?

Restriction and Notes Value is the elapsed time, in seconds, since the last successful Align Now, RF was executed, either individually or as a component of Align Now, All. Returns NaN if no Align Now, RF executed since power-up.

Key Path **Visual annotation in the Show Alignment Statistics screen**

Saved State No

Mode All

Remote Command :CALibration:TEMPerature:LRF?

Example :CAL:TEMP:LRF?

Restriction and Notes Value is in degrees Centigrade at which the last successful Align Now, RF was executed, either individually or as a component of Align Now, All. Returns NaN if no Align Now, RF executed since power-up.

Key Path **Visual annotation in the Show Alignment Statistics screen**

Saved State No

Mode All

Remote Command :CALibration:TIME:LPreselector?

Example :CAL:TIME:LPR?

Restriction and Notes Value is date and time the last successful Characterize Preselector was executed. The date is separated from the time by a space character. Returns "" if no Characterize Preselector has ever been performed on the instrument.

Key Path **Visual annotation in the Show Alignment Statistics screen**

Saved State No

Mode All

Remote Command :CALibration:TEMPerature:LPreselector?

Example :CAL:TEMP:LPR?

Restriction and Notes Value is in degrees Centigrade at which the last successful Characterize Preselector was executed. Returns NaN if no Characterize Preselector has ever been performed on the instrument.

Key Path	Visual annotation in the Show Alignment Statistics screen
Saved State	No
Mode	All
Remote Command	:CALibration:AUTO:TIME:OFF?
Example	:CAL:AUTO:TIME:OFF?
Restriction and Notes	Value is the elapsed time, in seconds, since Auto Align has been set to Off or Off with Alert. The value is 0 if Auto Align is ALL or NORF.
Key Path	Visual annotation in the Show Alignment Statistics screen

Timebase DAC

Allows control of the internal 10 MHz reference oscillator timebase. This may be used to adjust for minor frequency alignment between the signal and the internal frequency reference. This adjustment has no effect if the instrument is operating with an External Frequency Reference.

If the value of the Timebase DAC changes (by switching to Calibrated from User with User set to a different value, or in User with a new value entered) an alignment may be necessary. The alignment system will take appropriate action; which will either invoke an alignment or cause an Alert.

Mode	All
Remote Command	:CALibration:FREquency:REFerence:MODE CALibrated USER :CALibration:FREquency:REFerence:MODE?
Example	:CAL:FREQ:REF:MODE CAL
Restriction and Notes	If the value of the timebase is changed the alignment system automatically performs an alignment or alerts that an alignment is due.
Remote Command Notes	If the value of the timebase is changed the alignment system automatically performs an alignment or alerts that an alignment is due.
Preset	This is unaffected by Preset but is set to CALibrated on a "Restore System Defaults->Align".
State Saved	No
Key Path	System, Alignments

Calibrated

Sets the Timebase DAC to the value established during factory or field calibration. The value displayed on the menu key is the calibrated value.

Mode	All
Example	:CAL:FREQ:REF:MODE CAL
Key Path	System, Alignments, Timebase DAC

User

Allows setting the Timebase DAC to a value other than the value established during the factory or field calibration. The value displayed on the menu key is the calibrated value.

Mode	All
Example	:CAL:FREQ:REF:MODE USER
Key Path	System, Alignments, Timebase DAC

Mode	All
Remote Command	:CALibration:FREQuency:REFeRence:FINE <integer> :CALibration:FREQuency:REFeRence:FINE?
Example	:CAL:FREQ:REF:FINE 8191
Restriction and Notes	If the value of the timebase is changed the alignment system automatically performs an alignment or alerts that an alignment is due.
Dependencies/Couplings	Setting :CAL:FREQ:REF:FINE sets :CAL:FREQ:REF:MODE USER
Preset	This is unaffected by Preset but is set to the factory setting on a "Restore System Defaults->Align".
State Saved	No
Min	0
Max	16383
Key Path	System, Alignments, Timebase DAC


Remote Command	:CALibration:FREQuency:REFeRence:COARse <integer> :CALibration:FREQuency:REFeRence:COARse?
Example	:CAL:FREQ:REF:COAR 8191

Dependencies/Couplings	Setting :CAL:FREQ:REF:COAR sets :CAL:FREQ:REF:MODE USER
Remote Command Notes	This is an alias for CAL:FREQ:REF:FINE any change to COARse is reflected in FINE and vice-versa. See CAL:FREQ:REF:FINE for description of functionality.

Restore Align Defaults

Initializes the alignment user interface settings, not alignment data, to the factory default values. Align Now, All must be executed if the value of the Timebase DAC results in a change.

For front panel operation, the operator is prompted to confirm action before setting the alignment parameters to factory defaults:



The parameters affected are:


Parameter	Setting
Timebase DAC	Calibrated
Timebase DAC setting	Calibrated value
Auto Align State	Normal (if the instrument is not operating with default alignment data, Off otherwise)
Auto Align All but RF	Off
Auto Align Alert	Time & Temperature

Mode	All
Example	:SYST:DEF ALIG
Restriction and Notes	Alignment processing that results as the transition to Auto Alignment Normal will be executed sequentially; thus *OPC? or *WAI will wait until the alignment processing is complete.
Key Path	System, Alignments

Restore Align Data

Initializes the alignment data to the factory default values. This action is normally not necessary. It is recommended if alignment errors occur. If alignment errors continue to occur after Restore Align Data, the instrument is in need of repair. Align Now, All must be executed to regain warranted operation, and the user is responsible for configuring Auto Align thereafter.

For front panel operation, confirmation is required before setting the alignment data to factory defaults. The confirmation dialog is:



The Error Condition “Align Now, All required” is set, and bit 14 in the Status Questionable Calibration register is set. Auto Align is set to Off.

Mode	All
Remote Command	:CALibration:DATA:DEFault
Example	:CAL:DATA:DEF
Dependencies/Couplings	Sets Auto Align to Off. Sets bit 14 in the Status Questionable Calibration register. The Error Condition “Align Now, All required” is set.
Key Path	System, Alignments

I/O Config

Activates a menu for identifying and changing the I/O configuration for remote control.

Key Path	System
----------	---------------

GPIO Address (Remote Only)

Select the GPIO remote address.

Mode	All
------	-----

Remote Command	:SYSTem:COMMunicate:GPIB[1] [:SELF]:ADDRess <integer> :SYSTem:COMMunicate:GPIB[1] [:SELF]:ADDRess?
Example	:SYST:COMM:GPIB:ADDR 17
Remote Command Notes	NOTE: Changing the Address on the GPIB port requires all further communication to use the new address.
Preset	This is unaffected by Preset but is set to 18 on a “Restore System Defaults->Misc”
State Saved	No
Range	0 to 30
Key Path	System, I/O Config

SCPI LAN Menu

Activates a menu for identifying and changing the SCPI over LAN configuration. There are a number of different ways to send SCPI remote commands to the instrument over LAN. It can be a problem to have multiple users simultaneously accessing the instrument over the LAN. These keys limit that somewhat by disabling the telnet, socket, and/or SACL capability.

Key Path	System, I/O Config
----------	---------------------------

SCPI Telnet

Turns the SCPI LAN telnet capability On or Off allowing you to limit SCPI access over LAN through telnet.

Mode	All
Remote Command	:SYSTem:COMMunicate:LAN:SCPI:TELNet:ENABle OFF ON 0 1 :SYSTem:COMMunicate:LAN:SCPI:TELNet:ENABle?
Example	:SYST:COMM:LAN:SCPI:TELN:ENAB OFF
Preset	This is unaffected by Preset but is set to ON on a “Restore System Defaults->Misc”
State Saved	No
Range	On Off
Key Path	System, I/O Config, SCPI LAN

SCPI Socket

Turns the capability of establishing Socket LAN sessions On or Off. This allows you to limit SCPI access over LAN through socket sessions.

Mode	All
------	-----

Remote Command	:SYSTem:COMMunicate:LAN:SCPI:SOCKEt:ENABle OFF ON 0 1 :SYSTem:COMMunicate:LAN:SCPI:SOCKEt:ENABle?
Example	:SYST:COMM:LAN:SCPI:SOCK:ENAB OFF
Preset	This is unaffected by Preset but is set to ON on a “Restore System Defaults->Misc”
State Saved	No
Range	On Off
Key Path	System, I/O Config, SCPI LAN

SCPI Socket Control Port (remote command only)

Returns the TCP/IP port number of the control socket associated with the SCPI socket session. This query enables you to obtain the unique port number to open when a device clear is to be sent to the instrument. Every time a connection is made to the SCPI socket, the instrument creates a peer control socket. The port number for this socket is random. The user must use this command to obtain the port number of the control socket. To force a device clear on this socket, open the port and send the string “DCL ” to the instrument.

If this SCPI command is sent to a non SCPI Socket interface, then 0 is returned.

Mode	All
Remote Command	:SYSTem:COMMunicate:LAN:SCPI:SOCKEt:CONTRol?
Example	:SYST:COMM:LAN:SCPI:SOCK:CONT?
Preset	This is unaffected by Preset or “Restore System Defaults->Misc”.
State Saved	No
Range	0 to 65534

SICL Server

Turns the SICL server capability On or Off, enabling you to limit SCPI access over LAN through the SICL server. (SICL IEEE 488.2 protocol.)

PSA Manual Table 4–1 SCPI Default Settings

Parameter	Description	Setting
Maximum Connections	The maximum number of connections that can be accessed simultaneously	5
Instrument Name	The name (same as the remote SICL address) of your analyzer	inst0
Instrument Logical Unit	The unique integer assigned to your analyzer when using SICL LAN	8

Emulated GPIB Name	The name (same as the remote SICL address) of the device used when communicating with your analyzer	gpib7
Emulated GPIB Logical Unit	The unique integer assigned to your device when it is being controlled using SICL LAN	8
Emulated GPIB Address	The emulated GPIB address assigned to your transmitter tester when it is a SICL server (the same as your GPIB address)	18

Mode All

Remote Command :SYSTem:COMMunicate:LAN:SCPI:SICL:ENABle OFF|ON|0|1
:SYSTem:COMMunicate:LAN:SCPI:SICL:ENABle?

Example :SYST:COMM:LAN:SCPI:SICL:ENAB OFF

Preset This is unaffected by Preset, but is set to ON on a “Restore System Defaults->Misc”

State Saved No


Range On | Off

Key Path **System, I/O Config, SCPI LAN**

Reset Web Password

The embedded web server contains certain capability which are password protected; modifying the LAN configuration of the instrument, and access to web pages that can change the settings of the instrument. The default password from the factory is ‘agilent’ (without the quotes). The control provided here is the means to set the web password as the user desires, or to reset the password to the factory default.

Selecting Reset web password brings up a control for resetting the password as the user desires, or to the factory default. An external keyboard is required to change the password from the factory default of ‘agilent’ or to set a new password that contains alphabetic characters. The control is:



If this control is entered without an external keyboard or mouse connected, you can cancel

the control by pressing the Cancel (ESC) key.

Mode	All
Key Path	System, I/O Config

Query USB Connection (Remote Command Only)

Enables you to determine the speed of USB connection.

Mode	All
Remote Command	:SYSTem:COMMunicate:USB:CONNectioN?
Example	:SYST:COMM:USB:CONN?
Remote Command Notes	NONE – Indicates no USB connection has been made. LSpeed – Indicates a USB low speed connection (1.5 Mbps). Note: this is reserved for future use, the T+M488 protocol is not supported on low speed connections. HSPeed – Indicates that a USB high speed connection (480 Mbps) has been negotiated. FSPEed – Indicates that a USB full speed connection (12 Mbps) has been negotiated.
State Saved	No
Range	NONE LSPeed HSPeed FSPEed

USB Connection Status (Remote Command Only)

Enables you to determine the current status of the USB connection.

Mode	All
Remote Command	:SYSTem:COMMunicate:USB:STATus?
Example	:SYST:COMM:USB:STAT?
Remote Command Notes	SUSPended – Indicates that the USB bus is currently in its suspended state. The bus is in the suspended state when: The bus is not connected to any controller The controller is currently powered off The controller has explicitly placed the USB device into the suspended state. When in the suspended state, no USB activity, including start of frame packets are received. ACTive – Indicates that the USB device is in the active state. When the device is in the active state, it is receiving periodic start of frames but it isn't necessarily receiving or transmitting data.

State Saved	No
Range	SUSPended ACTive

USB Packet Count (Remote Command Only)

Enables you to determine the number of packets received and transmitted on the USB bus.

Mode	All
Remote Command	:SYSTem:COMMunicate:USB:PACKets?
Example	:SYST:COMM:USB:PACK?
Remote Command Notes	Two integers are returned. The first is the number of packets received since application invocation, the second is the number of packets transmitted since application invocation. If no packets have been received or transmitted the response is 0,0. The packet count is initialized to 0,0 when the instrument application is started.
State Saved	No

Restore Defaults


Provides incremental initialization of the system setting groups along with supporting a comprehensive reset of the entire instrument back to a factory default state. The menu selections are the groups of system settings and when one is selected, that particular group of system settings is reset back to their default values. The menu options are: Input/Output Settings, Power On, Alignments, Misc, All Modes, and All.

Mode	All
Remote Command	:SYSTem:DEFault [ALL] ALIGn INPut MISC MODes PON
Example	SYST:DEF
State Saved	No
Key Path	System

Input/Output Settings

Causes the group of settings and data associated with Input/Output front panel key to be a reset to their default values. This level of Restore System Defaults does not affect any other system settings, mode settings and does not cause a mode switch.

Confirmation is required to restore the Input/Output setting. The confirmation dialog is:




Example :SYST:DEF INP
Key Path **System, Restore System Defaults**

Power On

This selection causes the Power On settings to be a reset to their default value. This level of Restore System Defaults does not affect any other system settings, mode settings and does not cause a mode switch. The Power On settings and their default values are Power On Type reset to Mode Preset and Power On Mode reset to whatever the factory set as its default value.

Confirmation is required to restore the factory default values. The confirmation dialog is:




Example :SYST:DEF PON
Key Path **System, Restore System Defaults**

Align

This selection causes the Alignment system settings to be a reset to their default values. This does not affect any Alignment data stored in the system. This level of Restore System Defaults does not affect any other system settings, mode settings and does not cause a mode switch.

After performing this function, it may impact the auto-alignment time of the instrument until a new alignment baseline has been established.

Confirmation is required to restore the factory default values. The confirmation dialog is:



Example :SYST:DEF ALIG
Key Path **System, Restore System Defaults**


Misc

This selection causes miscellaneous system settings to be reset to their default values. With this reset, you lose the GPIB address and it is reset to 18, so this should be used with caution. This level of Restore System Defaults does not affect any other system settings, mode settings and does not cause a mode switch. This miscellaneous group contains the rest of the settings that have not been part of the other Restore System Defaults groups. The following table is a complete list of settings associated with this group:

Miscellaneous Setting	Default Value
Verbose SCPI	Off
GPIB Address	18
Auto File Name Number	000
Save Type	State
State Save To	Register 1
Screen Save To	SCREEN000.png
DISP:ENABle	ON
Full Screen	Off
SCPI Telnet	ON
SCPI Socket	ON
SILC Server	ON
Display Intensity	100
Display Backlight	ON
Display Theme	TDColor
System Annotation	ON

The SYST:PRES:TYPE MODE

Confirmation is required to restore the factory default values. The confirmation dialog is:




Example :SYST:DEF MISC

Key Path **System, Restore System Defaults**

All Modes

This selection resets all of the modes in the instrument back to their default state just as a Restore Mode Defaults does and it switches the instrument to the power-on mode and causes the default measurement for the power-on mode to be active. This level of Restore System Defaults does not affect any system settings, but it does affect the state of all modes and does cause a mode switch unless the instrument was already in the power-on mode. Confirmation is required to restore the factory default values. The confirmation dialog is:



Example :SYST:DEF MOD


Dependencies/Couplings An All Mode will cause the currently running measurement to be aborted, mode switch to the power-on mode and activate the default measurement for the power-on mode. It gets the mode to a consistent state with all of the default couplings set.

Key Path **System, Restore System Defaults**

All

This is the catastrophic function that does a comprehensive reset of ALL analyzer settings to their factory default values. It resets all of the system setting groups, causes a Restore Mode Defaults for all modes in the instrument and switches back to the power-on mode. It does not affect the User Preset file or any user saved files.

Confirmation is required to restore the factory default values. The confirmation dialog is:



Example	:SYST:DEF ALL
Dependencies/Couplings	An All will cause the currently running measurement to be aborted and get all modes to a consistent state, so it is unnecessary to couple any settings.
Key Path	System, Restore System Defaults

Control Panel...

Opens the Windows Control Panel.

Pressing any key will cause the Control Panel to exit.

Remote Command	No remote command for this key.
Notes	
Key Path	System

Licensing...

Opens the license explorer.

For Help on this key, select Help in the menu bar at the top of the license explorer window.

Remote Command	No remote command for this key.
Notes	
Key Path	System

List installed Options (Remote Command Only)

Lists the installed options that pertain to the instrument (N9020A). .

Saved State	No
Mode	All
Remote Command	:SYSTem:OPTions?
Example	:SYST:OPT?
Restriction and Notes	The return string is a comma separated list of the installed options. For example: "503,P03,FPR"

:SYSTem:OPTions? and *OPT? are synonymous.

Lock the Front Panel keys (Remote Command Only)

Disables the instrument keyboard to prevent local input when the instrument is controlled remotely. An annunciator reading "K" for 'Klock' alerts the local user that the keyboard is locked. Klock is similar to the GPIB Local Lockout function; namely that no front panel keys are active with the exception of the Power Standby key. (The instrument is allowed to be turned-off if Klock is ON.) The Klock command is used in remote control situations where Local Lockout cannot be used.

Although primary intent of Klock is to lock-out the front panel, it will lock-out externally connected keyboards through USB. Klock has no effect on externally connected pointing devices (mice).

The front panel 'Local' key (Cancel/Esc) has no effect if Klock is ON.

Mode	All
Remote Command	:SYSTem:KLOCK OFF ON 0 1 :SYSTem:KLOCK?
Example	:SYST:KLOC ON
Remote Command Notes	Keyboard lock remains in effect until turned-off or the instrument is power-cycled
Preset	Initialized to OFF at startup, unaffected by Preset
State Saved	No

List SCPI Commands (Remote Command Only)

Outputs a list of the valid SCPI commands for the currently selected Mode.

Remote Command	:SYSTem:HELP:HEADers?
Example	:SYST:HELP:HEAD?
Remote Command Notes	The output is an IEEE Block format with each command separated with the New-Line character (hex 0x0A)

SCPI Version Query (Remote Command Only)

Returns the SCPI version number with which the instrument complies. The SCPI industry standard changes regularly. This command indicates the version used when the instrument SCPI commands were defined.

Remote Command	:SYSTem:VERSion?
Example	:SYST:VERS?

Date (Remote Command Only)

The recommended access to the Date, Time, and Timezone of the instrument is through the Windows native control (Control Panel or accessing the Task Bar). You may also access this information remotely, as shown in this command and Time (below).

Sets or queries the date in the instrument.

Mode	All
Remote Command	:SYSTem:DATE "<year>, <month>, <day>" :SYSTem:DATE?
Example	:SYST:DATE "2006,05,26"
Remote Command Notes	<year> is the four digit representation of year. (for example, 2006) <month> is the two digit representation of year. (for example, 01 to 12) <day> is the two digit representation of day. (for example, 01 to 28, 29, 30, or 31) depending on the month and year

Time (Remote Command Only)

Sets or queries the time in the instrument.

Mode	All
------	-----

Remote Command :SYSTem:TIME "<hour>,<minute>,<second>"
 :SYSTem:TIME?

Example :SYST:TIME "13,05,26"

Remote Command <hour> is the two digit representation of the hour in 24 hour
Notes format

 <minute> is the two digit representation of minute

 <day> is the two digit representation of second

Save

Accesses a menu that provides the save type options. The Save Type options are State, Trace, Data, or a Screen Image depending on the active mode.

Mode	All
Remote Command Notes	No remote command for this key specifically.
Key Path	Save

State

Selects State as the save type and accesses a menu that provides the options of where to save. You can save either to a register or a file. This menu key will not actually cause the save until the location is chosen.

Saving the state is the only way to save this exact measurement context for the current active mode. The entire state of the active mode is saved in a way that when a recall is requested, the mode will return to as close as possible the context in which the save occurred. This includes all settings and data for only the current active mode.

It should be noted that the Input/Output settings will be saved when saving State, since these settings plus the state of the mode best characterize the current context of the mode, but the mode independent System settings will not be saved.

This softkey will not actually cause the save, since the save feature still needs to know where to save the state. Pressing this key will bring up the Save State menu that provides the user with these options.

For rapid saving, the State menu lists registers to save to, or the user can select a file to save to. Once they pick the destination of the save in the State menu, the save will occur.

Mode	All
Key Path	Save

Register 1 thru Register 6

Selecting any one of these register menu keys causes the State of the currently active mode to be saved to the specified Register. Only the State save type supports writing to registers. The other save types can only write to files. The registers are provided for rapid saving and recalling, since you do not need to specify a filename or navigate to a file. Each of the register menu keys annotates whether it is empty or at what date and time it was last modified.

These 6 registers are all that is available from the front panel for all modes in the instrument. There are not 6 registers available for each mode. From remote, 127 Registers are available. Registers are files that are visible to the user in the same folder as

other State Files.

Mode	All
Example	*SAV 1
Key Path	Save, State

Mode	All
Example	*SAV 2
Key Path	Save, State

Mode	All
Example	*SAV 3
Key Path	Save, State

Mode	All
Example	*SAV 4
Key Path	Save, State

Mode	All
Example	*SAV 5
Key Path	Save, State

Mode	All
Example	*SAV 6
Key Path	Save, State

To File...

Accesses a menu that enables you to select the location for saving the State. This menu is similar to a standard Windows® Save As dialog.

The default path for all State Files is:

My Documents\`<mode name>`\state

where `<mode name>` is the parameter used to select the mode with the INST:SEL command (for example, SA for the Spectrum Analyzer). This path is the Save In: path in the Save As dialog for all State Files when they first enter this dialog.

The Save As dialog is loaded with the file information related to the State Save Type. The filename is filled in using the auto file naming algorithm for the State Save Type and is highlighted. Also, the only files that are visible are the *.state files and the Save As type is *.state, since .state is the file suffix for the State Save Type.

Mode	All
Restriction and Notes	Brings up Save As dialog for saving a State Save Type
Key Path	Save, State

Save As...

Accesses a menu that enables you to select the location where you can save the State. This menu is a standard Windows® dialog with Save As menu keys. The Save As dialog is loaded with the file information related to the State Save Type. The filename is filled in using the auto file naming algorithm for the State Save Type and is highlighted.

The Save As dialog is loaded with the file information related to the State Save Type. The filename is filled in using the auto file naming algorithm for the State Save Type and is highlighted.

The default path for all State Files is:

My Documents\`<mode name>`\state

where `<mode name>` is the parameter used to select the mode with the INST:SEL command (e.g., SA for the Spectrum Analyzer).

This path is the Save In: path in the Save As dialog for all State Files when they first enter this dialog.

The only files that are visible are the *.state files and the Save As type is *.state, since.state is the file suffix for the State Save Type.

Mode	All
Restriction and Notes	Brings up Save As dialog for saving a State Save Type
Key Path	Save, State

Save

Saves all of the State of the currently active mode plus the system level Input/Output settings to the specified file.

While the save is being performed, the floppy icon shows up in the settings bar near the Continuous\Single icon. After the save completes, the Advisory Event "File <register

number> saved” is displayed.

Mode	All
Remote Command	:MMEMory:STORe:STATe <filename>
Example	:MMEM:STOR:STAT “myState.state” saves the file myState.state on the default path
Restriction and Notes	If the file already exists, the file will be overwritten. Using the C: drive is strongly discouraged, since it runs the risk of being overwritten during a instrument software upgrade. Both single and double quotes are supported for any filename parameter over remote. Auto return to the State menu and the Save As dialog goes away.
Key Path	Save, State, To File...

Trace (+State)

Selects a state file which includes trace data for recalling as the save type and accesses a menu that enables you to select which trace to save. Not all modes support saving trace data with the state; and for modes that do, not all measurements do. This key is grayed out for measurements that do not support trace saves. It is blanked for modes that do not support trace saves. Saving Trace is identical to saving State except a .trace extension is used on the file instead of .state, and internal flags are set in the file indicating which trace was saved. You may also select to save ALL traces.

This softkey will not actually cause the save, since the save feature still needs to know which trace to save and where to save it. Pressing this key will bring up the Save Trace menu that provides the user with these options.

Mode	All
Key Path	Save

From Trace

Accesses a menu that enables you to select the trace to be saved. You can choose either 1, 2, 3, 4, 5, 6 or All. Once a trace is selected, the key returns back to the Save Trace menu and the selected Trace number is annotated on the key. The default is Trace 1. To save the Trace you must select Save As.

Mode	All
Key Path	Save, Trace + State,

Save As...

Accesses a menu that enables you to select the location where you can save the Trace. This menu is a standard Windows® dialog with Save As menu keys. The Save As dialog is

loaded with the file information related to the Trace Save Type. The filename is filled in using the auto file naming algorithm for the State Save Type and is highlighted.

The Save As dialog is loaded with the file information related to the Trace Save Type. The filename is filled in using the auto file naming algorithm for the State Save Type and is highlighted.

The default path for all State Files including .trace files is:

```
My Documents\<<mode name>\state
```

where <mode name> is the parameter used to select the mode with the INST:SEL command (for example, SA for the Spectrum Analyzer).

This path is the Save In: path in the Save As dialog for all State Files when they first enter this dialog.

The only files that are visible are the *.trace files and the Save As type is *.trace, since .trace is the file suffix for the Trace Save Type.

Mode	All
Restriction and Notes	Brings up Save As dialog for saving a Trace Save Type
Key Path	Save, Trace (+State)

Save

This key initiates the save of the .trace file. All of the State of the currently active mode plus the system level Input/Output settings are saved to the specified file as well as all of the trace data, including internal flags set in the file indicating which trace is to be saved.

While the save is being performed, the floppy icon shows up in the settings bar near the Continuous\Single icon. After the save completes, the Advisory Event “File <register number> saved” is displayed.

Mode	All
Remote Command	:MMEMory:STORe:TRACe TRACE1 TRACE2 TRACE3 TRACE4 TRACE5 TRACE6 ALL, <fil ename>
Example	:MMEM:STOR:TRAC TRACE1,“myState.trace” saves the file myState.trace on the default path and flags it as a “single trace” file with Trace 1 as the single trace (even though all of the traces are in fact stored). :MMEM:STOR:TRAC ALL,“myState.trace” saves the file myState.trace on the default path and flags it as an “all traces” file

Restriction and Notes	<p>If the file already exists, the file will be overwritten. Using the C: drive is strongly discouraged, since it runs the risk of being overwritten during a instrument software upgrade. Both single and double quotes are supported for any filename parameter over remote.</p> <p>Auto return to the State menu and the Save As dialog goes away.</p>
Remote Command Notes	<p>This command actually performs a save state, which in GPSA includes the trace data, however it flags it (in the file) as a “save trace” file of the specified trace (or all traces).</p>
Key Path	<p>Save, Trace, Save As...</p>

Data (Mode Specific)

Accesses a menu that enables you to select the type of data to export. Each mode determines what data it will allow to be exported and imported based on what data it produces. Exporting Data stores measurement data to the specified file which can then be imported into Excel, Matlab and other PC applications for viewing and manipulation. The data that is typically available in all modes is Measurement Results and this data type will not only be mode specific, but also measurement specific. An example of mode specific Export Data is Traces which is a data type typically only associated with the Spectrum Analyzer mode.

Selecting an Export Data menu key will not actually cause the exporting to occur, since the export feature still needs to know where to save the data. Pressing the Save As key in this menu brings up the Save As dialog and Save As menu that provides the user with the options of where to save the data. Once a filename has been selected or entered in the Save As menu, the save will occur.

Mode	<p>All</p>
Dependencies/Couplings	<p>If a file type is not used by a certain measurement, that type is grayed out for that measurement. Forceful -221.3200</p>
Remote Command Notes	<p>No SCPI command directly controls the Data Type that this key controls. The Data Type is included in the MMEM:STORE commands.</p>
Preset	<p><mode specific>; not affected by Preset, but is reset during Restore Mode Defaults and survives subsequent running of the mode.</p>
Key Path	<p>Save</p>

Trace

Pressing this key selects the Traces as the data type to be exported with this save request. This key brings up the Trace Menu that allows you to select which Trace to save. This key

is grayed out when SA measurements are running that do not support trace exporting.

Mode	SA
Dependencies/Couplings	Trace data is not available from all Measurements. In that case, the key will be grayed out.
Preset	1; not part of Preset, but is reset by Restore Mode Defaults and survives power cycles
State Saved	Saved in State
Key Path	Save, Data

Trace 1, 2, 3, 4, 5, 6

These softkey selections let you pick which Trace to save; either 1, 2, 3, 4, 5, or 6. The default is 1. Once selected, the key returns back to the Export Data menu and the selected Trace number is annotated on the key. Now you have selected exactly what needs to be saved. In order to trigger a save of the selected Trace, you must select the Save As key in the Export Data menu.

An example of using this menu is: If you select 4, Trace 4 is saved to the file selected or entered in File Name option in the Save As dialog.

Mode	SA
Key Path	Save, Data, Trace

Measurement Results

Measurement results are not available for all measurements. Also, different types of results are available from the different measurements. For example, this key is grayed out in the Spectrum Analyzer Mode while the active measurement is Swept SA.

Mode	All
Key Path	Save, Data

Zone Map

A map file contains zone definitions that will help simplify making measurements of frequently used signals. The OFDMA frame structure can contain multiple-zone definitions for the uplink and downlink subframes and multiple data burst allocations. You can store map files in which you have saved complicated OFDMA frame analysis zone definitions. This can save you time and ensure the accuracy of repeated measurements. Map files are also useful for recreating measurement settings so they can be used by other users.

Mode	WIMAXOFDMA
Key Path	Save, Data

Capture Data

Capture Data functionality is not available for all measurements. Also, different types of results are available from the different measurements. For example, this key is grayed out in the Spectrum Analyzer Mode while the active measurement is Swept SA.

Mode	IQ, WCDMA
Key Path	Save, Data

Save As...

Accesses a menu that enables you to select the location where you can save the Data Type. This menu is a standard Windows® dialog with Save As menu keys. The Save As dialog is loaded with the file information related to the Data Type. The filename is filled in using the auto file naming algorithm for the specific Data Type and is highlighted. The “auto file name” feature automatically generates a file name for use when saving a file.

When you navigate to this selection, you have already determined that you are saving Data and now you want to specify to which file to direct the save. When you first enter this dialog, the path in the Save In: field in this Save As dialog depends on which export data type you navigated here from. The only files that are visible are the files with the corresponding data type suffix, and the Save As type lists the same suffix.

For example, if the Data Type is Amplitude Corrections, the file suffix is .csv and the *.csv files are the only visible files in the Save As dialog and .csv is the Save As Type.

Each mode may allow additional Data Types. Examples are data files that are produced by Matlab or XML files.

Restriction and Notes	Brings up Save As dialog for saving a <mode specific> Save Type
Key Path	Save, Data, <N> (Key number depends on mode specific Export)

Save

Saves the specified Data Type.

This section describes any specific save behavior relevant to Data that is common to all modes.

When a Save of a specific Data File is requested, the specified data is saved to the specified or selected file. The save is performed immediately and does not wait until the measurement is complete.

If the file already exists, a dialog will popup that allows you to replace the existing file by selecting an OK or you can Cancel the request.

While the save is being performed, the floppy icon will show up in the settings bar near the Continuous/Single icon. After a register save completes, the corresponding register softkey annotation is updated with the date the time and an advisory message that the file was

saved appears in the message bar.

Mode	All
Restriction and Notes	<p>If the file already exists, the file will be overwritten. Using the C: drive is strongly discouraged, since it runs the risk of being overwritten during an instrument software upgrade. Both single and double quotes are supported for any filename parameter over remote.</p> <p>Auto return to the Export Data menu and the Save As dialog goes away.</p> <p>Advisory Event “File <file name> saved” after save is complete.</p>
Key Path	Save, Data, Save As...

Mode	All
Remote Command	<code>:MMEMory:STORe:RESults <filename></code>
Example	<p><code>:MMEM:STOR:RES “myResults.csv”</code> saves the results from the current measurement to the file myResults.csv in the default path.</p> <p><code>:MMEM:STOR:RES “MyDocuments\Basic\data\ComplexSpectrum\results\myResults.xml”</code> saves the results from the current measurement (Complex Spectrum) to the file myResults.xml in the default path for IQ Analyzer (Basic) Mode.</p>
Remote Command Notes	<p>If the save is initiated via SCPI, and the file already exists, the file will be overwritten.</p> <p>Using the C: drive is strongly discouraged, since it runs the risk of being overwritten during an instrument software upgrade. Both single and double quotes are supported for any filename parameter over remote.</p>

Mode	SA
Remote Command	<code>:MMEMory:STORe:TRACe:DATA TRACE1 TRACE2 TRACE3 TRACE4 TRACE5 TRACE6, <filename></code>
Example	<code>:MMEM:STOR:TRAC:DATA TRACE2,”myTrace2.csv”</code> exports the 2nd trace to the file myTrace2.csv in the default path.

Remote Command Notes	<p>If the save is initiated via SCPI, and the file already exists, the file will be overwritten.</p> <p>Using the C: drive is strongly discouraged, since it runs the risk of being overwritten during an instrument software upgrade. Both single and double quotes are supported for any filename parameter over remote.</p>
Mode	WIMAXOFDMA
Remote Command	:MMEMory:STORe:ZMAP <filename>
Example	:MMEM:STOR:ZMAP "myZoneMap.omf" saves current Zone Map as 89601 compatible file type.
Restriction and Notes	<p>If a file with the same name already exists, the file will be overwritten. Using the C: drive is strongly discouraged, since it runs the risk overwriting the file during a instrument software upgrade. Both single and double quotes are supported for any filename parameter over remote.</p> <p>Once a save is complete, the Export Data menu will appear, and the Save As dialog will disappear.</p> <p>The message "File <file name> saved" will appear after the save is complete.</p>
Key Path	Save, Data, Zone Map

Screen Image

Accesses a menu of functions that enable you to specify a format and location for the saved screen image.

Pressing Screen Image brings up the 2 key dialogs and their corresponding menu – Themes and Save As. When the user navigates to this selection, they have already determined they are saving a Screen Image and now they want to specify how to layout the page prior to saving and to which file to direct the save. The resulting screen image file cannot be recalled.

Mode	All
Key Path	Save

Themes

Accesses a menu of function that enable you to choose the theme to be used when saving the screen image.

The Themes option is the same as the Themes option under the Display and Page Setup dialogs. It allows the user to pick between themes to be used when saving the screen image. Select one of the following for more information on each theme:

- “3D Color” on page 91
- “3D Monochrome” on page 91
- “Flat Color” on page 91
- “Flat Monochrome” on page 92

Mode	All
Remote Command	:MMEMory:STORe:SCReen:THEMe TDColor TDMonochrome FCOLor FMONochrome :MMEMory:STORe:SCReen:THEMe?
Example	MMEM:STOR:SCR:THEM TDM
Preset	3D Color; not part of Preset, but is reset by Restore Misc Defaults or Restore System Defaults All and survives subsequent running of the modes
Key Path	Save, Screen Image

3D Color

Selects a standard color theme with each object filled, shaded and colored as designed.

Mode	All
Example	MMEM:STOR:SCR:THEM TDC
Key Path	Save, Screen Image, Themes

3D Monochrome

Selects a format that is like 3D color but shades of gray are used instead of colors.

Mode	All
Example	MMEM:STOR:SCR:THEM TDM
Key Path	Save, Screen Image, Themes

Flat Color

Selects a format that is best when the screen is to be printed on an InkJet printer.

Mode	All
Example	MMEM:STOR:SCR:THEM FCOL
Key Path	Save, Screen Image, Themes

Flat Monochrome

Selects a format that is like Flat Color, but only black is used (no colors, not even gray), and no fill.

Mode	All
Example	MMEM:STOR:SCR:THEM FMON
Key Path	Save, Screen Image, Themes

Save As...

Accesses a menu that enables you to select the location where you can save the Screen Image. This menu is a standard Windows® dialog with Save As menu keys. The Save As dialog is loaded with the file information related to the Screen Image Type. The filename is filled in using the auto file naming algorithm for the Screen Image Type and is highlighted. The only files that are visible are the *.png files and the Save As Type is *.png, since .png is the file suffix for the Screen Image Type.

The default path for Screen Images is

My Documents\`<mode name>`\screen.

where `<mode name>` is the parameter used to select the mode with the INST:SEL command (for example, SA for the Spectrum Analyzer).

This path is the Save In: path in the Save As dialog for all Screen Files when the user first enters this dialog.

Mode	All
Restriction and Notes	Brings up Save As dialog for saving a Screen Image Save Type
Key Path	Save, Screen Image

Save

Saves the screen image to the specified file using the selected theme. The image that is saved is the measurement display prior to when the Save As dialog appeared. The save is performed immediately and does not wait until the measurement is complete.

Mode	All
Remote Command	:MMEMory:STORe:SCReen <filename>
Example	:MMEM:STOR:SCR "myScreen.png"

Restriction and Notes	<p>If the file already exists, the file will be overwritten. Using the C: drive is strongly discouraged, since it runs the risk of being overwritten during a instrument software upgrade. Both single and double quotes are supported for any filename parameter over remote.</p> <p>Auto return to the Screen Image menu and the Save As dialog goes away.</p> <p>Advisory Event “File <file name> saved” after save is complete.</p>
Key Path	Save, Screen Image, Save As...

Save As Dialog and Menu

Save

Performs the actual save to the specified file of the selected type. The act of saving does not affect the currently running measurement and does not require you to be in single measurement mode to request a save. It performs the save as soon as the currently running measurement is in the idle state; when the measurement completes. This ensures the State or Data that is saved includes complete data for the current settings. The save only waits for the measurement to complete when the state or data that depends on the measurement setup is being saved. The save happens immediately when exporting corrections or when saving a screen image.

If the file already exists, a dialog will popup with corresponding menu keys that allows you to replace the existing file with an OK or to Cancel the request.

While the save is being performed, the floppy icon shows up in the settings bar near the Continuous\Single icon. After the save completes, the corresponding register menu key annotation is updated with the date the time and the message “File <file name> saved” appears in the message bar.

Mode	All
Restriction and Notes	<p>If the file already exists, the File Exist dialog pops up and allows the user to replace it or not by selecting the Yes or No menu keys that appear with the dialog. Then the key causes an auto return and Save As dialog goes away.</p> <p>Advisory Event “File <file name> saved” after save is complete.</p>

File/Folder List

Enables you to navigate to the center of the dialog that contains the list of files and folders. Once here you can get information about the file.

Mode	All
------	------------


Utility Functions
Save

Restriction and Notes Pressing this key navigates the user to the files and folders list in the center of the dialog.

Key Path **Save, <various>, Save As...**

File Name

Brings up the Alpha Editor as shown in the screen image. Use the knob to choose the letter to add and the Enter front panel key to add the letter to the file name. In addition to the list of alpha characters, this editor includes a Space menu key and a Done menu key. The Done menu key completes the filename, removes the Alpha Editor and returns back to the File Open dialog and menu, but does not cause the save to occur. You can also use Enter to complete the file name entry and this will cause the save to occur. The pulldown menu associated with the File Name: selection is not supported.



Mode **All**

Restriction and Notes Brings up the Alpha Editor. The editor created file name is loaded in the File name field of the Save As dialog.

Key Path **Save, <various>, Save As...**

Save As Type

This key corresponds to the Save As Type selection in the dialog. It follows the standard Windows® supported Save As Type behavior. It shows the current file suffix that corresponds to the type of file you have selected to save. If you navigated here from saving State, “State File (*.state)” is in the dialog selection and is the only type available under the pull down menu. If you navigated here from saving Trace, “Trace+State File (*.trace)” is in the dialog selection and is the only type available under the pull down menu. If you navigated here from exporting a data file, “Data File (*.csv)” is in the dialog and is available in the pull down menu. Modes can have other data file types and they would also be listed in the pull down menu.

Mode	All
Restriction and Notes	Pressing this key causes the pull down menu to list all possible file types available in this context. All types available are loaded in a 1-of-N menu key for easy navigation.
Key Path	Save, <various>, Save As...

Up One Level

This key corresponds to the icon of a folder with the up arrow that is in the tool bar of the dialog. It follows the standard Windows® supported Up One Level behavior. When pressed, it causes the file and folder list to navigate up one level in the directory structure.

Mode	All
Restriction and Notes	When pressed, the file and folder list is directed up one level of folders and the new list of files and folders is displayed
Key Path	Save, <various>, Save As...

Create New Folder

This key corresponds to the icon of a folder with the “*” that is in the tool bar of the dialog. It follows the standard Windows® supported Create New Folder behavior. When pressed, a new folder is created in the current directory with the name New Folder and allows you to enter a new folder name using the Alpha Editor.

Mode	All
Restriction and Notes	Creates a new folder in the current folder and lets the user fill in the folder name using the Alpha Editor.
Key Path	Save, <various>, Save As...

Cancel

This key corresponds to the Cancel selection in the dialog. It follows the standard Windows

Utility Functions
Save

supported Cancel behavior. It causes the current Save As request to be cancelled.

Mode	All
Restriction and Notes	Pressing this key causes the Save As dialog to go away and auto return.
Key Path	Save, <various>, Save As...

Quick Save

The Quick Save front panel key repeats the last save in the directory. If the last save was to a register, Quick Save saves the State of the currently active mode to the next register. If the last register was register 6, it wraps around to register 1.

If the last save was to a file, Quick Save repeats the last type of save in the last save directory by creating a unique filename using the Auto File Naming algorithm. If the Quick Save is pressed when the instrument is powered up for the first time prior to pressing the Save front panel key, the Quick Save saves State to Register 1.

Remote Command Notes	No remote command for this key specifically.
Key Path	Quick Save

Recall

Accesses a menu that provides the options that enables you to select the Type of file to recall. The options are State, Trace and Data (Screen Image can be saved, but not recalled.) The default paths for Recall are data type dependent and are the same as for Save.

Mode	All
Remote Command Notes	No remote command directly controls the Recall Type that this key controls. The Recall type is a node in the :MMEM:LOAD command. An example is :MMEM:LOAD:STATe <filename> .
Key Path	Recall

State

When this key is pressed, the user has determined what they want to recall is State. Recalling State is used to return as close as possible to the mode context of the save. Recalling State may cause a mode switch if the file selected is not for the currently active mode. This menu key will not actually cause the recall, since the recall feature still needs to know from where to recall the state. State can be recalled from either a register or a file. Pressing this key will bring up the State menu that provides the user with the options of where to retrieve the state. For quick recalls, the State menu lists 6 registers to recall from or the user can select a file to recall from.

Mode	All
Remote Command Notes	No remote command directly controls the recall type that this key controls. The recall type is a parameter in the :MMEM:LOAD command. An example is :MMEM:LOAD:STATe <filename> .
Key Path	Recall

Register 1 thru Register 6

Selecting any one of these register keys causes the State of the mode from the specified Register to be recalled. Only the Recall Type of State supports reading from registers. The other Recall Types can only read from files. Each of the register keys annotates whether it is empty or at what date and time it was last modified.

Registers are shared by all modes, so recalling from any one of the 6 registers may cause a mode switch to the mode that was active when the save to the Register occurred.

After the recall completes, the message “Register <register number> recalled” appears in the message bar.

Selecting any one of these register menu keys: Register 1, Register 2, Register 3, Register 4, Register 5, Register 6 causes the state of the mode from the specified Register to be

recalled. The registers are provided for easy saving and recalling, since the user does not have to specify a filename or navigate to a specific file. The date will follow the format specified in the Date Format setting under the Control Panel. The time will show hours, minutes and seconds.

Mode	All
Example	*RCL 1
Key Path	Recall, State

Mode	All
Example	*RCL 2
Key Path	Recall, State

Mode	All
Example	*RCL 3
Key Path	Recall, State

Mode	All
Example	*RCL 4
Key Path	Recall, State

Mode	All
Example	*RCL 5
Key Path	Recall, State

Mode	All
Example	*RCL 6
Key Path	Recall, State

From File\ File Open

Brings up the File Open standard Windows® dialog and its corresponding File Open key menu.

When you first enter this dialog, the State File default path is in the LookIn: box in this File Open dialog. The File Open dialog is loaded with the file information related to the State Save Type. The first *.state file is highlighted. The only files that are visible are the *.state files and the Files of type is *.state, since .state is the file suffix for the State Save Type.

Mode	All
Restriction and Notes	Brings up Open dialog for recalling a State Save Type
Key Path	Recall, State

Open

Recalling State function first must verify the file is recallable in the current instrument by checking the software version and model number of the instrument. If everything matches, a full recall proceeds by aborting the currently running measurement, and then loading the State from the saved state file to as close as possible to the context in which the save occurred. You can open state files from any mode, so recalling a State File switches to the mode that was active when the save occurred. After switching to the mode of the saved state file, mode settings and data (if any for the mode) are loaded with values from the saved file. The saved measurement of the mode becomes the newly active measurement and the data relevant to the measurement (if there is any) is recalled.

If there is a mismatch between file version or model number or instrument version or model number, the recall still tries to recall as much as possible and it returns a warning message of what it did.

NOTE	No Trace data is loaded when recalling a State File; measurements that support loading of trace data will include a Trace key in the Recall menu and will load State + Trace data from .trace files under that key.
-------------	---

The state of a mode includes all of the variables affected by doing a full preset. It not only recalls Mode Preset settings, but it also recalls all of the mode persistent settings and data if the mode has either. Each mode determines whether data is part of a mode state and if the mode has any persistent settings. Recall State also recalls all of the Input/Output system settings, since they are saved with each State File for each mode. Input/Output settings are listed under Input/Output in the Analyzer Setup Functions Section.

The **Recall State** function does the following:

Verifies that the file is recallable on this instrument using the version number and model number.

Aborts the currently running measurement.

Clears any pending operations.

Switches to the mode of the selected Save State file.

Sets mode State and Input/Output system settings to the values in the selected Saved State file.

Limits settings that differ based on model number, licensing or version number.

Makes the saved measurement for the mode the active measurement.

Clears the input and output buffers.

Status Byte is set to 0.

*CLS.]

Mode	All
Remote Command	:MMEMory:LOAD:STATe <filename>
Example	:MMEM:LOAD:STAT "myState.state" recalls the file myState.state on the default path
Restriction and Notes	Auto return to the State menu and the Open dialog goes away. Advisory Event "Recalled File <file name>" after recall is complete.
Remote Command Notes	Although the trace data is included in the .state file, it is not recalled; that is left for .trace files only for measurements that support recalling of trace data. If the file specified is empty an error is generated. If the specified file does not exist, another error is generated. If there is a mismatch between the file and the proper file type, an error is generated. If there is a mismatch between file version or model number or instrument version or model number, a warning is displayed.
Key Path	Recall, State, From File...

Trace (+State)

When this key is pressed, the user has determined what they want to recall is Trace. Trace files include the state of the mode they were saved from as well as the trace data, with internal flags to indicate which trace the user was trying to save which may include ALL traces. They are otherwise identical to State files. Recalling Trace may cause a mode switch if the file selected is not for the currently active mode.

Not all modes support saving of trace data with the state; and for modes that do, not all measurements do. The Trace key is grayed out for measurements that do not support trace recall. It is blanked for modes that do not support trace recall.

This softkey will not actually cause the recall, since the recall feature still needs to know from which file to recall the trace and which trace to recall it into. Pressing this key will bring up the Recall Trace menu that provides the user with the options of where to retrieve

the trace.

Mode	SA
Key Path	Recall

To Trace

These softkey selections let you pick which Trace to recall the saved trace into; either 1, 2, 3, 4, 5, or 6. The default is 1. If the .trace file is an “all trace” file, “To Trace” is ignored and the traces each go back to the trace they were saved from.

Once selected, the key returns back to the Recall Trace menu and the selected Trace number is annotated on the key. Now you have selected exactly where the trace needs to be recalled. In order to trigger a recall of the selected Trace, you must select the Open key in the Recall Trace menu.

Mode	SA
Key Path	Save, Data, Trace

Open...

Pressing Open brings up the File Open standard Windows dialog and its corresponding File Open softkey menu. When the user navigates to this selection, they have already determined they are recalling Trace and now they want to specify from which file to do the recall.

When the user first enters this dialog, the State File default path is in the Look In: box in this File Open dialog. The File Open dialog is loaded with the file information related to the State Save Type. The first *.trace file is highlighted. Also, the only files that are visible are the *.trace files and the Files of type is *.trace, since .trace is the file suffix for the Trace Save Type. For more details, refer to Section "File Open Dialog and Menu".

Mode	SA
Restriction and Notes	Brings up Open dialog for recalling a Trace Save Type
Key Path	Recall, Trace

Open

Recalling Trace first must verify the file is recallable in this instrument by checking the instrument software version and model number, since it includes State. If everything matches, a full recall proceeds by aborting the currently running measurement, loads the state from the saved state file to as close as possible to the context in which the save occurred. Users can open .trace files from any mode that supports them, so recalling a Trace File switches to the mode that was active when the save occurred. After switching to the mode of the saved state file, mode settings and data (if any for the mode) are loaded with values from the saved file and the saved measurement of the mode becomes the newly active measurement and the data relevant to the measurement (if there is any) is recalled.

Once the state is loaded the trace data must be loaded. The internal flags are consulted to see which trace to load and the “To Trace” setting to see where to load it. Trace data is always loaded with the specified trace set to View, so that the data is visible and not updating (so as not to wipe out the recalled data). If the file is an “all trace” file, all traces are loaded with the saved data (to the original trace the data was saved from) and set to View. Traces whose data is not loaded are restored to the update state that existed when they were saved.

In every other way a Trace load is identical to a State load. See section "Open" for details.

Mode	SA
Remote Command	:MMEMory:LOAD:TRACe TRACE1 TRACE2 TRACE3 TRACE4 TRACE5 TRACE6 , <filenam e>
Example	:MMEM:LOAD:TRAC TRACE2,“myState.trace” recalls the file myState.trace on the default path; if it is a “single trace” save file, that trace is loaded to trace 2, not updating
Restriction and Notes	Auto return to the Trace menu and the Open dialog goes away. Advisory Event “Recalled File <file name>” after recall is complete.
Remote Command Notes	This command actually performs a load state, which in GPSA includes the trace data, however it looks in the recalled state file to see how it was flagged at save time. The possibilities are: Flagged as a single trace save file: the trace which was flagged as the one that was saved is loaded, to the trace specified. The trace is loaded with update off and display on, and none of the other traces are loaded. Flagged as an “all traces” file: all traces are loaded. All of the traces are loaded with Update=Off to keep them from updating, regardless of the setting of “Recall State w/Trace Update”
Key Path	Recall, Trace, Open...

Data (Mode Specific)

Importing a data file is a way to replace current measurement data with data that was previously saved from this measurement or from other measurements that produce the same type of data. This import feature also allows the user to import data from different modes that produce the same type of data. The Import Menu only includes Data Types that are supported by the current mode. Based on the currently active measurement, Data Types that are not relevant to the currently active measurement may be grayed out in the menu.

Since the commonly exported data files are in .csv format, the data can be edited by the user prior to importing. This allows the user to export a data file, manipulate the data in

Excel (the most common PC Application for manipulating .csv files) and then import it.

When this key is pressed, the user has determined that they want to Import Data. Each mode determines what data it will allow to be exported and imported based on what data it produces. Importing Data loads measurement data from the specified file into the destination implied by the Import Data Type selected. The one data type that is available to all modes is Amplitude Corrections. The other data that is typically available in all modes is Measurement Results, but Measurement Results can not be imported. Other examples of mode specific Import Data are Traces and Limits which are Import Data associated with the Spectrum Analyzer mode.

The mode specific Import Data can be grayed out depending on the specific measurement that is running within the mode. For example, when in the SA mode and in the ACP measurement, the Trace Import Data is grayed out, since a user trace (Trace1, Trace2, ...) is not relevant when the ACP measurement is running.

Selecting an Import Data menu key will not actually cause the importing to occur, since the recall feature still needs to know from where to get the data. Pressing the Open key in this menu brings up the Open dialog and Open menu that provides the user with the options from where to recall the data. Once a filename has been selected or entered in the Open menu, the recall will occur. See Section "File Open Dialog and Menu" for more details.

Mode	All
Remote Command Notes	No SCPI command directly controls the Data Type that this key controls. The Data Type is included in the MMEM:LOAD commands.
Preset	<mode specific>; not affected by Preset, but is reset during Restore Mode Defaults and survives subsequent running of the mode.
Key Path	Recall

Trace

This key selects the Traces as the data type to be imported with this recall request. It brings up the Trace Menu that lets you select which Trace to import the data into.

This key is grayed out when measurements are running that do not support trace importing.

Mode	SA
Dependencies/Couplings	Trace data is not available from all Measurements. In that case, the key will be grayed out.
Preset	1; not part of Preset, but is reset by Restore Mode Defaults and survives power cycles
State Saved	Saved in State
Key Path	Recall, Data

Trace 1, 2, 3, 4, 5, 6

These keys let you pick which Trace to import the data into; either 1, 2, 3, 4, 5 or 6. The default is 1.

Once selected, the key returns back to the Import Data menu and the selected Trace number is annotated on the key. Now you have selected exactly what needs to be imported. In order to trigger a import of the selected Trace, you must select the Open key in the Import Data menu.

An example of using this menu is: If you select 4 and continue to the File Open dialog, then import Trace 4 from the file selected or entered in File Name option in the File Open dialog.

Mode	SA
Key Path	Recall, Data, Trace

Zone Map

A map file contains zone definitions that will help simplify making measurements of frequently used signals. The OFDMA frame structure can contain multiple-zone definitions for the uplink and downlink subframes and multiple data burst allocations. You can recall map files in which you have saved complicated OFDMA frame analysis zone definitions; this can save you time and ensure the accuracy of repeat measurements. Map files are also useful for recreating measurement settings so they can be used by other users.

Mode	WIMAXOFDMA
Key Path	Recall, Data

File Open...

Pressing File Open brings up the File Open standard Windows dialog and the File Open key menu. When the user navigates to this selection, they have already determined they are recalling a specific Data Type and now they want to specify which file to open.

When you first enter this dialog, the path is in the Look In: field in this File Open dialog depends on which import data type you navigated here from.

The only files that are visible are those specific to the file type being recalled.

Mode	All
Restriction and Notes	Brings up Open dialog for recalling a <mode specific> Save Type
Key Path	Recall, Data, <N> (Key number depends on mode specific Export)

Open

The import starts by checking that all is well. If the file specified is empty an error is

generated (If the specified file does not exist, another error is generated. If there is a mismatch between the file and the proper file type, an error is generated.

If there is a mismatch between the file version or model number or instrument version or model number, a warning is displayed. Note that if there is a mismatch between file version or model number or instrument version or model number, the import still tries to load as much as possible.

Now the import can start. For all data types, the actual import starts by aborting the currently running measurement. Then the import does data type specific behavior:

Trace Import: A trace cannot be imported if the trace points in the file do not match the sweep points in the mode. If this happens, an error is generated. When a trace is imported, then Trace Update is always turned OFF for that trace and Trace Display is always turned ON. The trace file has meta data. If the meta data in the file does not match the corresponding SA state, N error message will appear.

Mode	SA
Remote Command	:MMEMory:LOAD:TRACe:DATA TRACE1 TRACE2 TRACE3 TRACE4 TRACE5 TRACE6, <filename>
Example	:MMEM:LOAD:TRAC DATA TRACE2,"myTrace2.csv" imports the 2nd trace from the file myTrace2.csv in the default path.
Remote Command Notes	If the file is empty, error -250.3005 is reported. If the file does not exist error -256 is reported. If there is a mismatch between the file and the destination data type, an error is reported. -250.3003. If the number of points in the file don't match the current SA points, an error is reported. -250.3006.

Mode	WIMAXOFDMA
Remote Command	:MMEMory:LOAD:ZMAP <filename>
Example	:MMEM:LOAD:ZMAP "myZoneMap.omf" recalls the Zone Map data from the file myZoneMap.omf on the default directory to the Custom Map for Modulation Analysis measurement.
Key Path	Recall, Data, Zone Map

File Open Dialog and Menu

Open

This selection and the Enter key when a filename has been selected or specified actually cause the load to occur. Open loads the specified or selected file to the previously selected recall type of either State or a specific import data type. The open behavior is enough different between State and Data that it is fully described in the corresponding State and

Data sections – Section Open.

Mode	All
Restriction and Notes	Advisory Event “File <file name> recalled” after recall is complete.

File/Folder List

This menu key navigates to the center of the dialog that contains the list of files and folders. Once here the user can get information about the file.

Mode	All
Restriction and Notes	Pressing this key navigates the user to the files and folders list in the center of the dialog.
Key Path	Recall, <various>, Open...

Sort

Pressing this key brings up the Sort menu that allows the user a way to sort the files within the File Open scope. Only one sorting type can be selected at a time and the sorting happens immediately.

Mode	All
Remote Command Notes	No SCPI command directly controls the sorting.
Key Path	Recall,<various>,Open...

By Date

This allows the user to sort the list of files within the scope of the File Open dialog in ascending or descending data order. The date is the last data modified.

Mode	All
Restriction and Notes	Files in File Open dialog are sorted immediately in the selected order
Key Path	Recall,<various>,Open..., Sort

By Name

This allows the user to sort the list of files within the scope of the File Open dialog in ascending or descending order based on the filename.

Mode	All
Restriction and Notes	Files in File Open dialog are sorted immediately in the selected order

Key Path **Recall,<various>,Open..., Sort**

By Extension

This allows the user to sort the list of files within the scope of the File Open dialog in ascending or descending order based on the file extension for each file.

Mode **All**

Restriction and Notes Files in File Open dialog are sorted immediately in the selected order

Key Path **Recall,<various>,Open..., Sort**

By Size

This allows the user to sort the list of files within the scope of the File Open dialog in ascending or descending order based on file size.

Mode **All**

Restriction and Notes Files in File Open dialog are sorted immediately in the selected order

Key Path **Recall,<various>,Open..., Sort**

Ascending

This causes the display of the file list to be sorted, according to the sort criteria above, in ascending order.

Mode **All**

Restriction and Notes Files in File Open dialog are sorted immediately in the selected order

Key Path **Recall,<various>,Open..., Sort**

Descending

This causes the display of the file list to be sorted, according to the sort criteria above, in descending order.

Mode **All**

Restriction and Notes Files in File Open dialog are sorted immediately in the selected order

Key Path **Recall,<various>,Open..., Sort**

Files Of Type

This menu key corresponds to the Files Of Type selection in the dialog. It follows the

standard Windows supported Files Of Type behavior. It shows the current file suffix that corresponds to the type of file the user has selected to save. If the user navigated here from recalling State, “State File (*.state)” is in the dialog selection and is the only type available in the pull down menu. If the user navigated here from recalling Trace, “Trace+State File (*.trace)” is in the dialog selection and is the only type available under the pull down menu. If the user navigated here from importing a data file, “Data File (*.csv)” is in the dialog and is the only type available in the pull down menu. Modes can have other data file types and they would also be listed in the pull down menu.

Mode	All
Restriction and Notes	Pressing this key causes the pull down menu to list all possible file types available in this context.
Key Path	Recall, <various>, Open...

Up One Level

This menu key corresponds to the icon of a folder with the up arrow that is in the tool bar of the dialog. It follows the standard Windows supported Up One Level behavior. When pressed, it causes the file and folder list to navigate up one level in the directory structure.

Mode	All
Restriction and Notes	When pressed, the file and folder list is directed up one level of folders and the new list of files and folders is displayed.
Key Path	Recall, <various>, Open...

Cancel

This menu key corresponds to the Cancel selection in the dialog. It causes the current File Open request to be cancelled. It follows the standard Windows supported Cancel behavior.

Mode	All
Restriction and Notes	Pressing this key causes the Open dialog to go away and auto return.
Key Path	Recall, <various>, Open...

Mode Preset

The Mode preset is the most common way to get the active mode back to a known state. It will keep you in the currently active mode and reset the mode settings to their mode preset state. It will never cause a mode switch. It does a partial preset. It does not affect any mode persistent settings or any system settings.

The **Mode Preset** does the following for the currently active mode:

- Aborts the currently running measurement.
- Brings up the default menu for the mode, with no active function.
- Sets Measurement settings to their preset values for the active mode only.
- Activates the default measurement.
- Brings up the default menu for the mode.
- Clears the input and output buffers.
- Sets Status Byte to 0.

Remote Command	:SYSTem:PRESet
Example	:SYST:PRES
Restriction and Notes	Clears all pending OPC bits. The Status Byte is set to 0.
Dependencies/Couplings	A Mode Preset will cause the currently running measurement to be aborted and cause the default measurement to be active. Mode Preset gets the mode to a consistent state with all of the default couplings set.
Remote Command Notes	*RST is preferred over :SYST:PRES for remote operation. *RST does a Mode Preset as done by the :SYST:PRES command and it sets the measurement mode to Single measurement rather than Continuous for optimal remote control throughput.
Key Path	Front-panel key

How-To Preset

The table below shows all possible presets, their corresponding SCPI commands and front panel access. Instrument settings depend on the current measurement context. Some settings are local to the current measurement, some are global (common) across all the measurement in the current mode, and some are global to all the available modes. In a similar way, restoring the settings to their preset state can be done within the different contexts.

The Auto Couple front panel key is a Meas local key. It sets all Auto/Man parameter couplings in the measurement to Auto. Any Auto/Man selection that is local to the other measurements in the mode will not be affected by Auto Couple.

The Meas Preset key is a Meas local key. Meas Preset resets all the variables local to the current measurement except the persistent ones.

The Mode Preset (front-panel key on front panel) resets all the current mode's Meas local and Meas global variables except the persistent ones.

The Restore Mode Defaults key resets ALL the Mode variables (and all the Meas global and Meas local variables), including the persistent ones.

Type Of Preset	SCPI Command	Front Panel Access
Auto Couple	:COUPLe ALL	Auto Couple front-panel key
Meas Preset	:CONFIgure:<Measurement>	Meas Setup Menu
Mode Preset	:SYSTem:PRESet	Mode Preset (green key)
Restore Mode Defaults	:INSTrument:DEFault	Mode Setup Menu
Restore All Mode Defaults	:SYSTem:DEFault MODEs	System Menu; Restore System Default Menu
*RST	*RST	not possible (Mode Preset with Single)
Restore Input/Output Defaults	:SYSTem:DEFault INPut	System Menu; Restore System Default Menu
Restore Power On Defaults	:SYSTem:DEFault PON	System Menu; Restore System Default Menu
Restore Alignment Defaults	:SYSTem:DEFault ALIGn	System Menu; Restore System Default Menu
Restore Miscelaneous Defaults	:SYSTem:DEFault MISC	System Menu; Restore System Default Menu
Restore All System Defaults	:SYSTem:DEFault [ALL] :SYSTem:PRESet:PERSiStent (bc)	System Menu; Restore System Default Menu
User Preset	:SYSTem:PRESet:USER	User Preset Menu
User Preset All Modes	:SYSTem:PRESet:USER:ALL	User Preset Menu
Power On Mode Preset	:SYSTem:PON:TYPE MODE	System Menu
Power On User Preset	:SYSTem:PON:TYPE USER	System Menu
Power On Last State	:SYSTem:PON:TYPE LAST	System Menu

Restore Mode Defaults

Restore Mode Defaults resets the state for the currently active mode by resetting the mode persistent settings to their factory default values, clearing mode data and by performing a Mode Preset. This function will never cause a mode switch. This function performs a full preset for the currently active mode; whereas, Mode Preset performs a partial preset.

Restore Mode Defaults does not affect any system settings. System settings are reset by Restore System Defaults. This function does reset mode data; as well as settings.

Remote Command	:INSTRument:DEFault
Example	:INST:DEF
Restriction and Notes	A pop-up message comes up saying: "If you are sure, press key again".
Dependencies/Couplings	A Restore Mode Defaults will cause the currently running measurement to be aborted and causes the default measurement to be active. It gets the mode to a consistent state with all of the default couplings set.
Remote Command Notes	Clears all pending OPC bits. The Status Byte is set to 0.
Key Path	Mode Setup

*RST (Remote Command Only)

*RST is equivalent to :SYST:PRES;:INIT:CONT OFF which is a Mode Preset in Single measurement state. This remote command is preferred over Mode Preset remote command - :SYST:PRES, as optimal remote programming occurs with the instrument in single measurement state.

Remote Command	*RST
Example	*RST
Restriction and Notes	Clears all pending OPC bits and the Status Byte is set to 0.
Dependencies/Couplings	A *RST will cause the currently running measurement to be aborted and cause the default measurement to be active. *RST gets the mode to a consistent state with all of the default couplings set.
Remote Command Notes	Sequential

Spectrum Analyzer Mode - Preset Information

The **Mode Preset** key sets most analyzer functions to their default values. They are listed below. Also shown is a list of MXA persistent settings and their default values.

Because the Input/Output function is common to all modes and all measurements, those default settings are also listed here. These are set when you select the **Mode Preset** key as well.

This key also performs the following functions:

Activates the Swept SA measurement.

Brings up the Freq/Channel menu.

Clears any trace that is active after the preset but does not change the data in inactive traces.

Spectrum Analyzer Mode Preset Settings and their default values

SA Mode, Preset Settings	Default Value(s)
AC/DC	AC
ADC Dither	Off
Amplitude corrections	Off
Amplitude correction frequency interpolation	Linear
Amplitude correction selection	1
Amplitude corrections apply	Off
Antenna corrections	Off
Annotation and graticule	On
Annotation - extended panel	Off
Annotation - trace	Auto
Attenuation (coupled function)	10 dB
Attenuation step	10 dB
Average count	100
Average type (coupled function)	Log Pwr
Byte order	Normal
Center frequency:	
Option 503	1.805 GHz
Option 508	4.205 GHz
Option 513	6.805 GHz
Option 526	13.255 GHz
CF step size (coupled function)	10 % of Span
Continuous peak search	Off
Coupled functions	All set to Auto
Detector (coupled function)	Normal
Display enable	On
Display line	Off
Display line level	-25 dBm
FFT/Span (coupled function)	1
Frequency offset	0 Hz

Frequency scale	Linear
Limit line display	Off
Limit line domain	Frequency
Limit line control domain	Fixed
Limit line table	Off
Limit line test state	Off
Log scale (amplitude)	10 dB/division
Marker count	Off
Markers mode	Off
Marker couple	Off
Marker lines	Off
Marker function	Off
Marker function band span	5 % of Span
Marker function band interval left	5 % of Span
Marker function band interval right	5 % of Span
Marker table	Off
Marker trace (coupled function)	Trace1
Marker x:	
Option 503	1.805 GHz
Option 508	4.205 GHz
Option 513	6.805 GHz
Option 526	13.255 GHz
Marker x position	501
Marker x readout (coupled function)	Frequency
Marker y	0 dBm
Max mixer level	-10 dBm
Normalize	Off
Normalize reference level	0 dB
Normalize reference position	0
N DB points	Off
N DB points offset	-3.01 dB
Peak readout	All

Utility Functions
Mode Preset

Peak excursion	6.0 dB
Peak excursion state	Off
Peak sort	Frequency
Peak table	Off
Peak threshold	-90 dBm
Peak threshold state	Off
Phase noise option (coupled function)	Fast tune
Preselector adjust	0 Hz
Preselector select	3-26 GHz
Reference level	0 dBm
Reference level offset	0 dBm
Resolution bandwidth (coupled function)	3 MHz
Resolution bandwidth filter type	Gaussian
Resolution bandwidth filter bandwidth	DB3
Scale type	Log
Signal track	Off
Span:	
Option 503	3.59 GHz
Option 508	8.39 GHz
Option 513	13.59 GHz
Option 526	26.49 GHz
Span/RBW ratio (coupled function)	106
Span Zone	Off
SRQ mask?	40
Start frequency	10 MHz
Stop frequency:	
Option 503	3.6 GHz
Option 508	8.4 GHz
Option 513	13.6 GHz
Option 526	26.5 GHz
State registers	Unaffected
Sweep control	Continuous

Sweep points	1001
Sweep spacing (frequency scale)	Linear
Sweep time (coupled function)	66.24 ms (option dependent)
Sweep type (coupled function)	Swp
Title	Cleared
Trace display	1, 0,0,0,0,0
Trace copy source, destination	Trace1, trace2
Trace exchange source, destination	Trace1, trace2
Trace math	Off
Trace math first operand	5,6,1,2,3,4
Trace math second operand	6,1,2,3,4,5
Trace numeric data format	Ascii
Trace type	Clearwrite
Trace update	1,0,0,0,0,0
TV monitor	Off
Video Bandwidth (coupled function)	3 MHz
VBW/RBW ratio (coupled function)	1.000
Y axis units	dBm
Trigger	Freerun
Trigger ATrigger	100.0 ms
Trigger ATrigger state	Off
Trigger External 1 delay	1.000 ms
Trigger External 1 delay state	Off
Trigger External 1 level	1.2 V
Trigger External 1 periodic timer level	1.2 V
Trigger External 1 periodic timer slope	Positive
Trigger External 1 slope	Positive
Trigger External 2 delay	1.000 ms
Trigger External 2 delay state	Off
Trigger External 2 level	1.2 V

Utility Functions
Mode Preset

Trigger External 2 periodic timer level	1.2 V
Trigger External 2 periodic timer slope	Positive
Trigger External 2 slope	Positive
Trigger Holdoff	100.0 ms
Trigger Holdoff state	Off
Trigger Line delay	1.000 ms
Trigger Line delay state	Off
Trigger Line level	1.2 V
Trigger Line slope	Positive
Trigger periodic timer	20 ms
Trigger periodic timer adjust	0.00 s
Trigger periodic timer sync source	Off
Trigger RF Burst delay	1.000 ms
Trigger RF Burst delay state	Off
Trigger RF Burst level	1.2 V
Trigger RF Burst level absolute	0.0 dBm
Trigger RF Burst level relative	-6.0 dB
Trigger RF Burst periodic timer selectivity state	Off
Trigger RF Burst periodic timer level absolute	0.0 dBm
Trigger RF Burst periodic timer level relative	-6.0 dB
Trigger RF Burst periodic timer slope	Positive
Trigger RF Burst periodic timer level type	Absolute
Trigger RF Burst periodic timer selectivity	Off
Trigger RF Burst slope	Positive
Trigger source	Off
Trigger Video delay	1.000 ms
Trigger Video delay state	Off
Trigger Video level	1.2 V
Trigger Video level frequency	0 Hz
Trigger Video slope	Positive
Trigger TV FMode	Entire

Trigger TV line	17
Trigger TV slope	Positive
Trigger TV Source	SAnalyzer
Trigger TV Standard	NTSC-M

Persistent Settings and their default values

MXA Persistent Settings	Default Value(s)
E/I Input Correction selection	1
E/I Limit Line selection	1
E/I Trace selection	1
Export Data Type	Trace
Import Data Type	Trace
Last Save To Name	1
Last Save To Type	Register
Last Save Type	State
Limit Line Ampl. Interpolation	Log
Limit Line Interpolation	Linear
Limit Line Margin States	OFF
Limit Line Margins	0
Limit Line Types	Upper, Lower
Marker References	2,3,4,5,6,7,8,9,10,11,12,1

Input/Output Settings and their default values

Settings	Default Value(s)
Amplitude Reference	AREF_50MHZ
Analog Out	SA
BTS (ext gain for base station test)	0 dB
Data Source	Input
Down Converter Analog Out Channel 1	Log Video
Down Converter Analog Out Channel 2	Off
External Amp Gain	0 dB

Utility Functions
Mode Preset

External Mixer Band	A
I Offset	0.00 V
I/Q Input Z	UIMohm (1 mohm)
I/Q Voltage Range	1.00 V
I/Q Z Ref for Input Z	50 ohms
Input Corrections	Off
Input Correction Interpolation	Linear
Input Correction Selection	1
Input Corrections Apply	Off
Input Antenna Corrections	Off
Input Port	RF
Input Z Corr	50 ohms
Microwave Preselector	Off
Mixer Bias	0
Mixer Bias State	Off
Mixer Harmonic (coupled function)	-8
Mixer Type	Unpreselect
MS (ext gain for mobile station test)	0 dB
Polarity	Positive
Pre Amp Gain	0 dB
Q Offset	0.00 V
SA Channel 1	Log Video
SA Channel 2	Off
Signal ID	Off
Signal ID Mode	ISuppress
Trigger 2 Output	Main

User Preset

User Preset behaves similarly to **Recall State** in that it recalls a hidden Save State file with the exception that **User Preset** will never cause a mode switch. Recalling a Save State file may cause a mode switch, if the Save State file was saved while in a different mode. There is a User Preset file per mode. The User Preset file is a Save State file. **User Preset** sets the state of currently active mode back to the state that was previously saved for this mode using the **Save User Preset** menu key or the `SYST:PRES:USER:SAVE` command. Each mode will have no knowledge of another user preset file from any other mode or how to invoke them. The user has no control over the user preset filename and has no direct access to the user preset file.

User Preset recalls a mode's state which includes all of the variables affected by doing a Mode Preset. It not only recalls Mode Preset settings, but it also recalls all of the mode persistent settings. User Preset also recalls all of the Input/Output system settings.

If a **Save User Preset** has not been done at any time, **User Preset** recalls the default user preset file for the currently active mode. The default user preset files are created at power-on when each mode detects there is no user preset file, so there will never be a scenario when there is no user preset file to restore. For each mode, the default user preset state is the same state that would be saved if a **Save User Preset** is performed in each mode right after doing a Restore Mode Default and after a Restore Input/Output Settings Defaults.

NOTE When the instrument is secured, all of the user preset files are converted back to their default user preset files.

User Preset does the following:

- Aborts the currently running measurement.
- Sets the mode state to the values defined by **Save User Preset**.
- Makes the saved measurement for the currently running mode the active measurement.
- Brings up the saved menu for the power-on mode.
- Clears the input and output buffers.
- Sets the Status Byte to 0.

Remote Command :SYSTem:PRESet:USER

Example :SYST:PRES:USER:SAVE
 :SYST:PRES:USER

Restriction and Notes Clears all pending OPC bits. The Status Byte is set to 0.

Dependencies/Couplings	A user preset will cause the currently running measurement to be aborted and cause the saved measurement to be active. Recalling a User Preset file has the same issues that recalling a Save State file has. Some settings may need to be limited and therefore re-coupled, since the capabilities of the mode may have changes when the User Preset file was last saved.
Remote Command Notes	:SYST:PRES:USER:SAVE is used to save the current state as the user preset state.
Key Path	User Preset

User Preset All Modes

User Preset All Modes behaves similarly to Power On User Preset, since it recalls all of the User Preset files for each mode, switches to the power-on mode and activates the saved measurement from the power-on mode User Preset file.

NOTE When the instrument is secured, all of the user preset files are converted back to their default user preset files.

User Preset does the following:

- Aborts the currently running measurement.
- Switches the Mode to the power-on mode.
- Restores the User Preset files for each mode.
- Makes the saved measurement for the power-on mode the active measurement.
- Brings up the saved menu for the power-on mode.
- Clears the input and output buffers.
- Sets the Status Byte to 0.

Remote Command :SYSTem:PRESet:USER:ALL

Example :SYST:PRES:USER:SAVE

:SYST:PRES:USER:ALL

Restriction and Notes Clears all pending OPC bits. The Status Byte is set to 0.

Dependencies/Couplings A user preset will cause the currently running measurement to be aborted, cause a mode switch to the power-on mode and cause the saved measurement to be active in the power-on mode. Recalling a User Preset file has the same issues that recalling a Save State file has. Some settings may need to be limited and therefore re-coupled, since the capabilities of the mode may have changes when the User Preset file was last saved.

Remote Command :SYST:PRES:USER:SAVE is used to save the current state as
 Notes the user preset state.

Key Path **User Preset**

Save User Preset

Save User Preset saves the currently active mode and its state. The way the user recalls this User Preset file is by pressing the User Preset menu key or sending the SYST:PRES:USER remote command. This same state is also saved by the Save State function.

Remote Command :SYSTem:PRESet:USER:SAVE

Example :SYST:PRES:USER:SAVE

Restriction and Notes :SYST:PRES:SAVE creates the same file as if the user requested a *SAV or a MMEM:STOR:STAT, except User Preset Save does not allow the user to specify the filename or the location of the file.

Key Path **User Preset**

File

Opens a menu of keys which access various standard and custom Windows dialogs. Pressing any other front-panel key exits any of these dialogs.

File Explorer

Opens the standard Windows File Explorer. Pressing any front panel key closes the Explorer application.

File Explorer opens up in My Documents.

NOTE My Documents must be located on the user data partition.

Page Setup

Refer to your Microsoft Windows Operating System manual.

Print Theme – Remote Command

The graphical user interface contains a selection for choosing the Theme to use when printing. An equivalent remote command is provided. Refer to the View/Display section for more detail on Themes.


Mode	All
Remote Command	:SYSTem:PRINT:THEMe TDCOLOR TDMonochrome FCOLor FMONochrome :SYSTem:PRINT:THEMe?
Example	:SYST:PRIN:THEM FCOL
Preset	FCOL; not part of Preset, but is reset by Restore Misc Defaults or Restore System Defaults All and survives subsequent running of the modes
State Saved	No

Print

Refer to your Microsoft Windows Operating System manual.

Exit

This key, when pressed, will exit the Instrument Application. A dialog box will be used to confirm that the user intended to exit the application:



Mode

All

Key Path

File, Exit

Print


The Print front-panel key is equivalent to performing a File, Print, OK. It immediately performs the currently configured Print to the current printer.

Key Path

Front-panel key


Service

Accesses capabilities performed in the factory or under instructions from repair procedures. This menu key is only visible when the logged-in user is “advanceduser” or “saservice” (or the factory image). The first access to the Service Menu after invoking the instrument application will require an authentication, which is to enter the Service Code. Subsequent accesses to the Service Menu are unimpeded. The Authentication dialog looks like:



The image shows a dialog box titled "LoginForm" with a blue header. It contains two text input fields: "User Name:" with the text "advanceduser" entered, and "Service Code:" which is empty. Below the fields are two buttons: "OK" and "Cancel".

“OK” is the default key thus the Enter key is used to complete the entry. If an invalid Service Code is entered authentication is not granted and the user is provided the following dialog:



The image shows an error dialog box with a blue header and a red 'X' icon in the top right corner. The text inside reads: "Mismatching service code. Please enter the service code and try again." Below the text is a single "OK" button.

Key Path

System

Diagnostics

The Diagnostics key in the System menu gives you access to basic diagnostic capabilities of the instrument.

Key Path **System**

Show Hardware Statistics

Provides a display of various hardware statistics. The statistics include the following:

Mechanical relay cycles

High and Low temperature extremes

Elapsed time that the instrument has been powered-on (odometer)

The display should appear listing the statistics, product number, serial number, and firmware revision.

Std Header	Product Number: N9020A	
	Serial Number: US46340924	
	Firmware Revision: A.01.01	
Mechanical relays	Calibrator Switch Cycles:	1800
	AC/DC Switch Cycles:	60
	2 dB #1 Mechanical Atten Cycles	23489
	2 dB #2 Mechanical Atten Cycles	23400
	6 dB Mechanical Atten Cycles	500000
	10 dB Mechanical Atten Cycles	1000000
	20 dB Mechanical Atten Cycles	2500
	30 dB Mechanical Atten Cycles	60000
	4339	
	High operating temperature extreme:	+37.2degC
	Low operating temperature extreme	+18.1degC
Odometer	Elapsed Time (on time) (hours):	1600

The data will be updated only when the Show Hardware Statistics menu key is pressed, it will not be updated while the screen is displayed.

The tabular data should be directly printable.

Mode	All
Restriction and Notes	The values displayed on the screen are only updated upon entry to the screen and not updated while the screen is being displayed.
Key Path	System, Diagnostics

Each of the hardware statistic items can be queried.

Query the Mechanical Relay Cycle Count

Returns the count of mechanical relay cycles.

Remote Command	:SYSTem:MRELay:COUNT?
Example	:SYST:MREL:COUN?
Restriction and Notes	The return value is a comma separated list of the individual counts for each mechanical relay. The position of the relays in the list is: “<Cal Signal>,<AC/DC>,<2dB #1 Atten>,<2dB #2 Atten>,<6dB Atten>,<10dB Atten>,<20dB Atten>,<30dB Atten>”
Remote Command Notes	Query Only

Query the Operating Temperature Extremes

Returns the low operating temperature extreme value. The value survives a power-cycle and is the temperature extreme encountered since the value was reset by the factory or service center.

Saved State	No
Mode	All
Remote Command	:SYSTem:TEMPerature:LEXTreme?
Example	:SYST:TEMP:LEXT?
Restriction and Notes	Value is in degrees Centigrade at which the lowest operating temperature has been recorded since 1st power-up.

Returns the high operating temperature extreme value. The value survives a power-cycle and is the temperature extreme encountered since the value was reset by the factory or service center.

Saved State	No
-------------	----

Mode	All
Remote Command	:SYSTem:TEMPerature:HEXTreme?
Example	:SYST:TEMP:HEXT?
Restriction and Notes	Value is in degrees Centigrade at which the highest operating temperature has been recorded since 1st power-up.


Query the Elapsed Time since 1st power on

Returns the elapsed on-time since 1st power-on (odometer).


Remote Command	:SYSTem:PON:ETIMe?
Example	:SYST:PON:ETIM?
Remote Command Notes	Query Only

Advanced

Accesses advanced diagnostic capabilities performed in the factory or under instructions from repair procedures. This menu key is only visible when the logged-in user is “saservice”. The first access to the Advanced Diagnostic Menu after invoking the instrument application will require an authentication, which is to enter the Service Code. Subsequent accesses to the Advanced Diagnostic Menu are unimpeded. The Authentication dialog looks like:



“OK” is the default key thus the Enter key is used to complete the entry. If invalid Service Code is entered authentication is not granted and the user is provided the following dialog:



Restriction and Notes	Password is required to traverse into this menu.
Key Path	System, Diagnostics

License Remote Commands

There are five remote commands available for licensing.

Remote Command SYSTem:LKEY <"OptionInfo">
Example SYST:LKEY "N9073A-1FP"
 SYST:LKEY "N9073A-1F1,1.000"
 SYST:LKEY "N9000-001,1.000"
Remote Command Notes The <"OptionInfo"> contains the feature and the version. You must specify the feature but can omit the version. If you omit the version, the system regards it as the latest one. Because the system knows which version is supported for each feature.

Remote Command SYSTem:LKEY:DELeTe <"OptionInfo">
Example SYST:LKEY:DEL "N9073A-1FP"
 SYST:LKEY:DEL "N9073A-1F1,1.000"
Remote Command Notes The <"OptionInfo"> contains the feature and the version. You must specify the feature but can omit the version. If you omit the version, the system regards it as the latest one, if more than one version is installed.

Remote Command SYSTem:LKEY:LIST?
Return Value An <arbitrary block data> of all the installed instrument licenses.
 The format of each license is as follows.
 <Feature>,<Version>,<Signature>,<Expiration
 Date>,<Serial Number for Transport>
Return value Example #3136
 N9073A-1FP,1.000,B043920A51CA
 N9060A-2FP,1.000,4D1D1164BE64
 N9020A-508,1.000,389BC042F920
 N9073A-1F1,1.000,5D71E9BA814C,13-aug-2005

NOTE <arbitrary block data> is an <IEEBlock> format. The format of an IEEBlock is:
 #NMMM<data>

Where:

N is the number of digits that describes the number of MMM characters. For example if the data was 55 bytes, N would be 2.

MMM would be the ASCII representation of the number of bytes. In the previous example, N would be 55.

<data> ASCII contents of the data


Return Value	<"LicenseInfo"> if the license is valid, null otherwise. <"LicenseInfo"> contains the signature, the expiration date, and serial number if transportable.
Return value Example	"B043920A51CA"
Remote Command	SYSTem:LKEY? <"OptionInfo">
Example	SYST:LKEY? "N9073A-1FP"
Remote Command Notes	The <"OptionInfo"> contains the feature and the version. You must specify the feature but can omit the version. If you omit the version, the system regards it as the latest one.

Remote Command	SYSTem:HID?
Return Value	Return value is the host ID as a string


STATUS Subsystem (No equivalent front panel keys)

The following graphics show the overall status register system.

Overall Status Byte Register System



Additional Fanout



Detailed Description

The STATus subsystem remote commands set and query the status hardware registers. This system of registers monitors various events and conditions in the instrument. Software written to control the instrument may need to monitor some of these events and conditions.

NOTE	All status register commands are sequential. Most commands can be started immediately and will overlap with any existing commands that are already running. This is not true of status commands. All the commands in the spectrum analyzer are assumed to be overlapped unless a command description specifically says that it is sequential.
-------------	---

What Are Status Registers

The status system contains multiple registers that are arranged in a hierarchical order. The lower-level status registers propagate their data to the higher-level registers in the data structures by means of summary bits. The status byte register is at the top of the hierarchy and contains general status information for the instrument's events and conditions. All other individual registers are used to determine the specific events or conditions. For a diagram of the registers and their interconnections, see above.

The operation and questionable status registers are sets of registers that monitor the overall instrument condition. They are accessed with the STATus:OPERation and STATus:QUEStionable commands in the STATus command subsystem. Each register set is made up of five registers:

- **Condition Register** It reports the real-time state of the signals monitored by this register set. There is no latching or buffering for a condition register.
- **Positive Transition Register** This filter register controls which signals will set a bit in the event register when the signal makes a low to high transition (when the condition bit changes from 0 to 1).
- **Negative Transition Register** This filter register controls which signals will set a bit in the event register when the signal makes a high to low transition (when the condition bit changes from 1 to 0).
- **Event Register** It latches any signal state changes, in the way specified by the filter registers. Bits in the event register are never cleared by signal state changes. Event registers are cleared when read. They are also cleared by *CLS and by presetting the instrument.
- **Event Enable Register** It controls which of the bits, being set in the event register, will be summarized as a single output for the register set. Summary bits are then used by the next higher register.

The STATus:QUEStionable registers report abnormal operating conditions. The status register hierarchy is:

1. The summary outputs from the six STATus:QUEStionable:<keyword> detail registers are inputs to the STATus:QUEStionable register.

2. The summary output from the STATUS:QUESTIONable register is an input to the Status Byte Register. See the overall system in Figure at the beginning of this section.

The STATUS:OPERation register set has no summarized inputs. The inputs to the STATUS:OPERation:CONDition register indicate the real time state of the instrument. The STATUS:OPERation:EVENT register summary output is an input to the Status Byte Register.

What Are Status Register SCPI Commands

Most monitoring of the instrument conditions is done at the highest level using the IEEE common commands indicated below. Complete command descriptions are available in the IEEE commands section at the beginning of the language reference. Individual status registers can be set and queried using the commands in the STATUS subsystem of the language reference.

- *CLS (clear status) clears the status byte by emptying the error queue and clearing all the event registers.
- *ESE, *ESE? (event status enable) sets and queries the bits in the enable register part of the standard event status register.
- *ESR? (event status register) queries and clears the event register part of the standard event status register.
- *OPC, *OPC? (operation complete) sets the standard event status register to monitor the completion of all commands. The query stops any new commands from being processed until the current processing is complete, then returns a '1'.
- *PSC, *PSC? (power-on state clear) sets the power-on state so that it clears the service request enable register and the event status enable register at power on.
- *SRE, *SRE? (service request enable) sets and queries the value of the service request enable register.
- *STB? (status byte) queries the value of the status byte register without erasing its contents.

How to Use the Status Registers

A program often needs to be able to detect and manage error conditions or changes in instrument status. There are two methods you can use to programmatically access the information in status registers:

- The polling method
- The service request (SRQ) method

In the polling method, the instrument has a passive role. It only tells the controller that conditions have changed when the controller asks the right question. In the SRQ method, the instrument takes a more active role. It tells the controller when there has been a condition change without the controller asking. Either method allows you to monitor one or more conditions.

The polling method works well if you do not need to know about changes the moment they

occur. The SRQ method should be used if you must know immediately when a condition changes. To detect a change using the polling method, the program must repeatedly read the registers.

Use the SRQ method when:

- you need time-critical notification of changes
- you are monitoring more than one device which supports SRQs
- you need to have the controller do something else while waiting
- you can not afford the performance penalty inherent to polling

Use polling when:

- your programming language/development environment does not support SRQ interrupts
- you want to write a simple, single-purpose program and do not want the added complexity of setting up an SRQ handler
- To monitor a condition:
 1. Determine which register contains the bit that reports the condition.
 2. Send the unique SCPI query that reads that register.
 3. Examine the bit to see if the condition has changed.

You can monitor conditions in different ways.

- Check the current instrument hardware and firmware status.

Do this by querying the condition registers which continuously monitor status. These registers represent the current state of the instrument. Bits in a condition register are updated in real time. When the condition monitored by a particular bit becomes true, the bit is set to 1. When the condition becomes false, the bit is reset to 0.

- Monitor a particular condition (bit).

You can enable a particular bit(s), using the event enable register. The instrument will then monitor that particular condition(s). If the bit becomes true (0 to 1 transition) in the event register, it will stay set until the event register is cleared. Querying the event register allows you to detect that this condition occurred even if the condition no longer exists. The event register can only be cleared by querying it or sending the *CLS command.


- Monitor a particular type of change in a condition (bit).
 - The transition registers are preset to register if the condition goes from 0 to 1 (false to true, or a positive transition).
 - This can be changed so the selected condition is detected if the bit goes from 1 to 0 (true to false, or a negative transition).
 - It can also be set for both types of transitions occurring.

- Or it can be set for neither transition. If both transition registers are set to 0 for a particular bit position, that bit will not be set in the event register for either type of change.

Using a Status Register

Each bit in a register is represented by a numerical value based on its location. See the next figure. This number is sent with the command to enable a particular bit. If you want to enable more than one bit, you would send the sum of all the bits that you want to monitor.

Figure: Status Register Bit Values



Bit 15 is not used to report status.

Example 1:

1. To enable bit 0 and bit 6 of standard event status register, you would send the command `*ESE 65` because $1 + 64 = 65$.
2. The results of a query are evaluated in a similar way. If the `*STB?` command returns a decimal value of 140, ($140 = 128 + 8 + 4$) then bit 7 is true, bit 3 is true and bit 2 is true.

Example 2:

1. Suppose you want to know if an Auto-trigger Timeout occurs, but you only cared about that specific condition. So you would want to know what was happening with bit 10 in the Status Questionable Integrity register, and not about any other bits.
2. It's usually a good idea to start by clearing all the status registers with `*CLS`.
3. Sending the `STAT:QUES:INT:ENAB 1024` command lets you monitor only bit 10 events, instead of the default monitoring all the bits in the register. The register default is for positive transition events (0 to 1 transition). That is, when an auto-trigger timeout occurs. If instead, you wanted to know when the Auto-trigger timeout condition is cleared, then you would set the `STAT:QUES:INT:PTR 0` and the `STAT:QUES:INT:NTR 32767`.
4. So now the only output from the Status Questionable Integrity register will come from a bit 10 positive transition. That output goes to the Integrity Sum bit 9 of the Status

Questionable register.

5. You can do a similar thing with this register to only look at bit 9 using, STAT:QUES:ENAB 512.
6. The Status Questionable register output goes to the “Status Questionable Summary” bit 3 of the Status Byte Register. The output from this register can be enabled using the *SRE 8 command.
7. Finally, you would use the serial polling functionality available for the particular bus/software that you are using to monitor the Status Byte Register. (You could also use *STB? to poll the Status Byte Register.)

Using the Service Request (SRQ) Method

Your language, bus and programming environment must be able to support SRQ interrupts. (For example, BASIC used with VXI–11.3 (GPIB over LAN). When you monitor a condition with the SRQ method, you must:

1. Determine which bit monitors the condition.
2. Determine how that bit reports to the request service (RQS) bit of the status byte.
3. Send SCPI commands to enable the bit that monitors the condition and to enable the summary bits that report the condition to the RQS bit.
4. Enable the controller to respond to service requests.

When the condition changes, the instrument sets its RQS bit. The controller is informed of the change as soon as it occurs. As a result, the time the controller would otherwise have used to monitor the condition can be used to perform other tasks. Your program determines how the controller responds to the SRQ.

Generating a Service Request

To use the SRQ method, you must understand how service requests are generated. Bit 6 of the status byte register is the request service (RQS) bit. The *SRE command is used to configure the RQS bit to report changes in instrument status. When such a change occurs, the RQS bit is set. It is cleared when the status byte register is queried using *SRE? (with a serial poll.) It can be queried without erasing the contents with *STB?.

When a register set causes a summary bit in the status byte to change from 0 to 1, the instrument can initiate the service request (SRQ) process. However, the process is only initiated if both of the following conditions are true:

- The corresponding bit of the service request enable register is also set to 1.
- The instrument does not have a service request pending. (A service request is considered to be pending between the time the instrument’s SRQ process is initiated and the time the controller reads the status byte register.)

The SRQ process sets the SRQ true. It also sets the status byte’s request service (RQS) bit to 1. Both actions are necessary to inform the controller that the instrument requires service. Setting the SRQ line only informs the controller that some device on the bus requires service. Setting the RQS bit allows the controller to determine which instrument requires service.

If your program enables the controller to detect and respond to service requests, it should instruct the controller to perform a serial poll when the SRQ is set true. Each device on the bus returns the contents of its status byte register in response to this poll. The device whose RQS bit is set to 1 is the device that requested service.

NOTE

When you read the instrument's status byte register with a serial poll, the RQS bit is reset to 0. Other bits in the register are not affected.


If the status register is configured to SRQ on end-of-measurement and the measurement is in continuous mode, then restarting a measurement (INIT command) can cause the measuring bit to pulse low. This causes an SRQ when you have not actually reached the "end-of-measurement" condition. To avoid this:

1. Set INITiate:CONTinuous off.
 2. Set/enable the status registers.
 3. Restart the measurement (send INIT).
-

Status Register System

The hardware status registers are combined to form the instrument status system. Specific status bits are assigned to monitor various aspects of the instrument operation and status. See the diagram of the status system for information about the bit assignments and status register interconnections.

The Status Byte Register



ck776a

The RQS bit is read and reset by a serial poll. The same bit position (MSS) is read, non-destructively by the *STB? command. If you serial poll bit 6 it is read as RQS, but if you send *STB it reads bit 6 as MSS. For more information refer to IEEE 488.2 standards, section 11.

Bit Number	7	6	5	4	3	2	1	0
Description	Standard Operation Status Summary Bit	Request Service (RQS) Summary Bit	Standard Event Status Summary Bit	Message Available (MAV)	Data Questionable Status Summary Bit	Error/Event Queue Summary Bit	Unused	Unused

*STB?

Status Byte Register

ck725a


- | Bit | Description |
|------|---|
| 0, 1 | These bits are always set to 0. |
| 2 | A 1 in this bit position indicates that the SCPI error queue is not empty which means that it contains at least one error message. |
| 3 | A 1 in this bit position indicates that the data questionable summary bit has been set. The data questionable event register can then be read to determine the specific condition that caused this bit to be set. |
| 4 | A 1 in this bit position indicates that the instrument has data ready in the output queue. There are no lower status groups that provide input to this bit. |
| 5 | A 1 in this bit position indicates that the standard event summary bit has been set. The standard event status register can then be read to determine the specific event that caused this bit to be set. |
| 6 | A 1 in this bit position indicates that the instrument has at least one reason to report a status change. This bit is also called the master summary status bit (MSS). |
| 7 | A 1 in this bit position indicates that the standard operation summary bit has been set. The standard operation event register can then be read to determine the specific condition that caused this bit to be set. |

To query the status byte register, send the command *STB?. The response will be the decimal sum of the bits which are set to 1. For example, if bit number 7 and bit number 3 are set to 1, the decimal sum of the 2 bits is 128 plus 8. So the decimal value 136 is returned. The *STB command does not clear the status register.

In addition to the status byte register, the status byte group also contains the service request enable register. This register lets you choose which bits in the status byte register will trigger a service request.

Send the *SRE <integer> command where <integer> is the sum of the decimal values of the bits you want to enable plus the decimal value of bit 6. For example, assume that you want to enable bit 7 so that whenever the standard operation status register summary bit is set to 1 it will trigger a service request. Send the command *SRE 192 (because $192 = 128 + 64$). You must always add 64 (the numeric value of RQS bit 6) to your numeric sum when you enable any bits for a service request. The command *SRE? returns the decimal value of the sum of the bits previously enabled with the *SRE <integer> command.

The service request enable register presets to zeros (0).




*SRE <num>
*SRE?

Service Request Enable Register

ck726a

Standard Event Status Register



The standard event status register contains the following bits:

Bit Number	7	6	5	4	3	2	1	0
Description	Power On	User Request Key (Local)	Command Error	Execution Error	Device Dependent Error	Query Error	Request Control	Operation Complete

*ESR?

Standard Event Status Register

ck727a


Bit Description

- 0 A 1 in this bit position indicates that all pending operations were completed following execution of the *OPC command.
- 1 This bit is for GPIB handshaking to request control. Currently it is set to 0 because there are no implementations where the spectrum analyzer controls another instrument.
- 2 A 1 in this bit position indicates that a query error has occurred. Query errors have SCPI error numbers from -499 to -400.
- 3 A 1 in this bit position indicates that a device dependent error has occurred. Device dependent errors have SCPI error numbers from -399 to -300 and 1 to 32767.
- 4 A 1 in this bit position indicates that an execution error has occurred. Execution errors have SCPI error numbers from -299 to -200.
- 5 A 1 in this bit position indicates that a command error has occurred. Command errors have SCPI error numbers from -199 to -100.
- 6 A 1 in this bit position indicates that the LOCAL key has been pressed. This is true even if the instrument is in local lockout mode.
- 7 A 1 in this bit position indicates that the instrument has been turned off and then on.

The standard event status register is used to determine the specific event that set bit 5 in the status byte register. To query the standard event status register, send the command *ESR?. The response will be the decimal sum of the bits which are enabled (set to 1). For example, if bit number 7 and bit number 3 are enabled, the decimal sum of the 2 bits is 128 plus 8. So the decimal value 136 is returned.

In addition to the standard event status register, the standard event status group also contains a standard event status enable register. This register lets you choose which bits in the standard event status register will set the summary bit (bit 5 of the status byte register) to 1. Send the *ESE <integer> command where <integer> is the sum of the decimal values of the bits you want to enable. For example, to enable bit 7 and bit 6 so that whenever either of those bits is set to 1, the standard event status summary bit of the status byte register will be set to 1, send the command *ESE 192 (128 + 64). The command *ESE? returns the decimal value of the sum of the bits previously enabled with the *ESE <integer> command.

The standard event status enable register presets to zeros (0).



*ESE <num>
*ESE?

Standard Event Status Enable Register

ck728a

Operation and Questionable Status Registers

The operation and questionable status registers are registers that monitor the overall instrument condition. They are accessed with the `STATUS:OPERation` and `STATUS:QUEStionable` commands in the `STATUS` command subsystem. See the figure at the beginning of this chapter.

Operation Status Register

The operation status register monitors the current instrument measurement state. It checks to see if the instrument is calibrating, sweeping, or waiting for a trigger. For more information see the `*OPC?` command located in the IEEE Common Commands section.

Bit	Condition	Operation
0	Calibrating	The instrument is busy executing its Align Now process.
3	Sweeping	The instrument is busy taking a sweep.
4	Measuring	The instrument is busy making a measurement. Measurements often require multiple sweeps. They are initiated by keys under the MEASURE key or with the MEASure group of commands.
5	Waiting for trigger	The instrument is waiting for the trigger conditions to be met, then it will trigger a sweep or measurement.
8	Paused	The instrument is paused (waiting) because you have pressed the Pause Meas Control key or send the INITiate:PAUSE command.

Questionable Status Register

The questionable status register monitors the instrument's condition to see if anything questionable has happened to it. It is looking for anything that might cause an error or a bad measurement like a hardware problem, an out of calibration situation, or an unusual signal. All the bits are summary bits from lower-level event registers.

Bit	Condition	Operation
-----	-----------	-----------

3	Power summary	The instrument hardware has detected a power unlevelled condition.
4	Temperature summary	The instrument is still warming up.
5	Frequency summary	The instrument hardware has detected an unlocked condition or a problem with the external frequency reference.
8	Calibration summary	The instrument has detected a hardware problem while doing the automatic internal alignment process.
9	Integrity summary	The instrument has detected a questionable measurement condition such as: bad timing, bad signal/data, timeout problem, signal overload, or “meas uncal”.

STATus Subsystem Command Descriptions

The STATus subsystem controls the SCPI-defined instrument status reporting structures. Each status register has a set of five commands used for querying or masking that particular register.

Numeric values for bit patterns can be entered using decimal or hexadecimal representations. (for example, 0 to 32767 is equivalent to #H0 to #H7FFF. It is also equal to all ones, 11111111111111) See the SCPI Basics information about using bit patterns for variable parameters.

Operation Register

Operation Condition Query

This query returns the decimal value of the sum of the bits in the Status Operation Condition register.

The data in this register is continuously updated and reflects the current conditions.

Mode	All
Remote Command	:STATus:OPERation:CONDition?
Example	STAT:OPER:COND?
Preset	0
SCPI Status Bits/OPC Dependencies	Sequential command

Operation Enable

This command determines which bits in the Operation Event register, will set the Operation Status Summary bit (bit 7) in the Status Byte Register. The variable <integer> is the sum of the decimal values of the bits you want to enable.

NOTE The preset condition is to have all bits in this enable register set to 0. To have any Operation Events reported to the Status Byte Register, one or more bits need to be set to 1.

Mode	All
Remote Command	:STATus:OPERation:ENABle <integer> :STATus:OPERation:ENABle?
Example	STAT:OPER:ENAB 1 Sets the register so that Align Now operation will be reported to the Status Byte Register.
Preset	0
Min	0
Max	32767
SCPI Status Bits/OPC Dependencies	Sequential command

Operation Event Query

This query returns the decimal value of the sum of the bits in the Operation Event register.

The register requires that the associated PTR or NTR filters be set before a condition register bit can set a bit in the event register. The data in this register is latched until it is queried. Once queried, the register is cleared.

Mode	All
Remote Command	:STATus:OPERation[:EVENT]?
Example	STAT:OPER?
Preset	0
SCPI Status Bits/OPC Dependencies	Sequential command

Operation Negative Transition

This command determines which bits in the Operation Condition register will set the corresponding bit in the Operation Event register when the condition register bit has a negative transition (1 to 0). The variable <integer> is the sum of the decimal values of the bits that you want to enable.

Mode	All
------	-----

Remote Command :STATus:OPERation:NTRansition <integer>
 :STATus:OPERation:NTRansition?

Example STAT:OPER:NTR 1
 Align Now operation complete will be reported to the
 Status Byte Register.

Preset 0
Min 0
Max 32767
SCPI Status Bits/OPC Sequential command
Dependencies

Operation Positive Transition

This command determines which bits in the Operation Condition register will set the corresponding bit in the Operation Event register when the condition register bit has a positive transition (0 to 1). The variable <integer> is the sum of the decimal values of the bits that you want to enable.

Mode All

Remote Command :STATus:OPERation:PTRansition <integer>
 :STATus:OPERation:PTRansition?

Example STAT:OPER:PTR 1
 Align Now operation beginning will be reported to the
 Status Byte Register.

Preset 32767
Min 0
Max 32767
SCPI Status Bits/OPC Sequential command
Dependencies

Preset the Status Byte

Sets bits in most of the enable and transition registers to their default state. It presets all the Transition Filters, Enable Registers, and the Error/Event Queue Enable. It has no effect on Event Registers, Error/Event QUEUE, IEEE 488.2 ESE, and SRE Registers as described in IEEE Standard 488.2–1992, IEEE Standard Codes, Formats, Protocols and Common Commands for Use with ANSI/IEEE Std 488.1–1987. New York, NY, 1992.

Remote Command :STATus:PRESet

Example STAT:PRES

Questionable Register

Questionable Condition

This query returns the decimal value of the sum of the bits in the Questionable Condition register.

The data in this register is continuously updated and reflects the current conditions.

Mode	All
Remote Command	:STATus:QUEStionable:CONDition?
Example	STAT:QUES:COND?
Preset	0
SCPI Status Bits/OPC Dependencies	Sequential command

Questionable Enable

This command determines which bits in the Questionable Event register will set the Questionable Status Summary bit (bit3) in the Status Byte Register. The variable <integer> is the sum of the decimal values of the bits you want to enable.

The preset condition is all bits in this enable register set to 0. To have any Questionable Events reported to the Status Byte Register, one or more bits need to be set to 1. The Status Byte Event Register should be queried after each measurement to check the Questionable Status Summary (bit 3). If it is equal to 1, a condition during the test may have made the test results invalid. If it is equal to 0, this indicates that no hardware problem or measurement problem was detected by the analyzer.

Mode	All
Remote Command	:STATus:QUEStionable:ENABle 16 Sets the register so that temperature summary will be reported to the Status Byte Register :STATus:QUEStionable:ENABle?
Example	STAT:OPER:PTR 1 Align Now operation beginning will be reported to the Status Byte Register.
Preset	0
Min	0
Max	32767
SCPI Status Bits/OPC Dependencies	Sequential command

Questionable Event Query

This query returns the decimal value of the sum of the bits in the Questionable Event register.

The register requires that the associated PTR or NTR filters be set before a condition register bit can set a bit in the event register. The data in this register is latched until it is queried. Once queried, the register is cleared.

Mode	All
Remote Command	:STATus:QUESTionable[:EVENT]?
Example	STAT:QUES?
Preset	0
SCPI Status Bits/OPC Dependencies	Sequential command

Questionable Negative Transition

This command determines which bits in the Questionable Condition register will set the corresponding bit in the Questionable Event register when the condition register bit has a negative transition (1 to 0). The variable <integer> is the sum of the decimal values of the bits that you want to enable.

Mode	All
Remote Command	:STATus:QUESTionable:NTRansition 16 Temperature summary 'questionable cleared' will be reported to the Status Byte Register. :STATus:QUESTionable:NTRansition?
Example	STAT:QUES:NTR 16 Temperature summary 'questionable cleared' will be reported to the Status Byte Register.
Preset	0
Min	0
Max	32767
SCPI Status Bits/OPC Dependencies	Sequential command

Questionable Positive Transition

This command determines which bits in the Questionable Condition register will set the corresponding bit in the Questionable Event register when the condition register bit has a positive transition (0 to 1). The variable <integer> is the sum of the decimal values of the bits that you want to enable.

Mode	All
------	-----

Remote Command	:STATus:QUEStionable:PTRansition <integer> :STATus:QUEStionable:PTRansition?
Example	STAT:QUES:PTR 16 Temperature summary 'questionable asserted' will be reported to the Status Byte Register.
Preset	32767
Min	0
Max	32767
SCPI Status Bits/OPC	Sequential command
Dependencies	

Questionable Calibration Register

Questionable Calibration Condition

This query returns the decimal value of the sum of the bits in the Questionable Calibration Condition register.

The data in this register is continuously updated and reflects the current conditions.

Mode	All
Remote Command	:STATus:QUEStionable:CALibration:CONDition?
Example	STAT:QUES:CAL:COND?
Preset	0
SCPI Status Bits/OPC	Sequential command
Dependencies	

Questionable Calibration Enable

This command determines which bits in the Questionable Calibration Condition Register will set bits in the Questionable Calibration Event register, which also sets the Calibration Summary bit (bit 8) in the Questionable Register. The variable <integer> is the sum of the decimal values of the bits you want to enable.

Mode	All
Remote Command	:STATus:QUEStionable:CALibration:ENABle <integer> :STATus:QUEStionable:CALibration:ENABle?
Example	STAT:QUES:CAL:ENAB 16384 Can be used to query if an alignment is needed, if you have turned off the automatic alignment process.
Min	0
Max	32767

SCPI Status Bits/OPC Sequential command
 Dependencies

Questionable Calibration Event Query

This query returns the decimal value of the sum of the bits in the Questionable Calibration Event register.

NOTE The register requires that the associated PTR or NTR filters be set before a condition register bit can set a bit in the event register. The data in this register is latched until it is queried. Once queried, the register is cleared.

Mode All

Remote Command :STATus:QUESTionable:CALibration[:EVENT]?

Example STAT:QUES:CAL?

Preset 0

SCPI Status Bits/OPC Sequential command
 Dependencies

Questionable Calibration Negative Transition

This command determines which bits in the Questionable Calibration Condition register will set the corresponding bit in the Questionable Calibration Event register when the condition register bit has a negative transition (1 to 0). The variable <integer> is the sum of the decimal values of the bits that you want to enable.

Mode All

Remote Command :STATus:QUESTionable:CALibration:NTRansition
 <integer>
 :STATus:QUESTionable:CALibration:NTRansition?

Example STAT:QUES:CAL:NTR 16384
 Alignment is not required.

Preset 0

Min 0

Max 32767

SCPI Status Bits/OPC Sequential command
 Dependencies

Questionable Calibration Positive Transition

This command determines which bits in the Questionable Calibration Condition register

will set the corresponding bit in the Questionable Calibration Event register when the condition register bit has a positive transition (0 to 1). The variable <integer> is the sum of the decimal values of the bits that you want to enable.

Mode	All
Remote Command	:STATus:QUEStionable:CALibration:PTRansition <integer> :STATus:QUEStionable:CALibration:PTRansition?
Example	STAT:QUES:CAL:PTR 16384 Alignment is required.
Preset	32767
Min	0
Max	32767
SCPI Status Bits/OPC Dependencies	Sequential command

Questionable Calibration Skipped Register

Questionable Calibration Skipped Condition

This query returns the decimal value of the sum of the bits in the Questionable Calibration Skipped Condition register.

NOTE	The data in this register is continuously updated and reflects the current conditions.
-------------	--

Mode	All
Remote Command	:STATus:QUEStionable:CALibration:SKIpped:CONDition?
Example	STAT:QUES:CAL:SKIP:COND?
Preset	0
SCPI Status Bits/OPC Dependencies	Sequential command

Questionable Calibration Skipped Enable

This command determines which bits in the Questionable Calibration Skipped Condition Register will set bits in the Questionable Calibration Skipped Event register, which also sets bit 11 of the Questionable Calibration Register. The variable <integer> is the sum of the decimal values of the bits you want to enable.

Mode	All
------	-----

Remote Command	:STATus:QUEStionable:CALibration:SKIPped:ENABle <integer> :STATus:QUEStionable:CALibration:SKIPped:ENABle?
Example	STAT:QUES:CAL:SKIP:ENAB 1 Can be used to query if an EMI alignment skipped condition is detected
Preset	32767
Min	0
Max	32767
SCPI Status Bits/OPC Dependencies	Sequential command

Questionable Calibration Skipped Event Query

This query returns the decimal value of the sum of the bits in the Questionable Calibration Event register.

NOTE	The register requires that the associated PTR or NTR filters be set before a condition register bit can set a bit in the event register. The data in this register is latched until it is queried. Once queried, the register is cleared.
-------------	---

Mode	All
Remote Command	:STATus:QUEStionable:CALibration:SKIPped[:EVENT]?
Example	STAT:QUES:CAL:SKIP?
Preset	0
SCPI Status Bits/OPC Dependencies	Sequential command

Questionable Calibration Skipped Negative Transition

This command determines which bits in the Questionable Calibration Skipped Condition register will set the corresponding bit in the Questionable Calibration Skipped Event register when the condition register bit has a negative transition (1 to 0). The variable <integer> is the sum of the decimal values of the bits that you want to enable.

Mode	All
Remote Command	:STATus:QUEStionable:CALibration:SKIPped:NTRansiti on <integer> :STATus:QUEStionable:CALibration:SKIPped:NTRansiti on?

Example	STAT:QUES:CAL:SKIP:NTR 1 Align RF skipped is not required.
Preset	0
Min	0
Max	32767
SCPI Status Bits/OPC Dependencies	Sequential command

Questionable Calibration Skipped Positive Transition

This command determines which bits in the Questionable Calibration Skipped Condition register will set the corresponding bit in the Questionable Calibration Skipped Event register when the condition register bit has a positive transition (0 to 1). The variable <integer> is the sum of the decimal values of the bits that you want to enable.

Mode	All
Remote Command	:STATus:QUEStionable:CALibration:SKIpped:PTRansition <integer> :STATus:QUEStionable:CALibration:SKIpped:PTRansition?
Example	STAT:QUES:CAL:SKIP:PTR 1 Align RF skipped is required.
Preset	32767
Min	0
Max	32767
SCPI Status Bits/OPC Dependencies	Sequential command

Questionable Calibration Extended Failure Register

Questionable Calibration Extended Failure Condition

This query returns the decimal value of the sum of the bits in the Questionable Calibration Extended Failure Condition register.

NOTE The data in this register is continuously updated and reflects the current conditions.

Mode	All
Remote Command	:STATus:QUEStionable:CALibration:EXTended:FAILure:CONDition?

Example	STAT:QUES:CAL:EXT:FAIL:COND?
Preset	0
SCPI	Sequential command
Status	
Bits/OPC	
Dependencies	

Questionable Calibration Extended Failure Enable

This command determines which bits in the Questionable Calibration Extended Failure Condition Register will set bits in the Questionable Calibration Extended Failure Event register, which also sets bit 9 of the Questionable Calibration Register. The variable <integer> is the sum of the decimal values of the bits you want to enable.

Mode	All
Remote Command	:STATus:QUESTionable:CALibration:EXTended:FAILure:ENABLE <integer> :STATus:QUESTionable:CALibration:EXTended:FAILure:ENABLE?
Example	STAT:QUES:CAL:EXT:FAIL:ENAB 1 Can be used to query if an EMI conducted alignment is needed.
Preset	32767
Min	0
Max	32767
SCPI Status Bits/OPC	Sequential command
Dependencies	

Questionable Calibration Extended Failure Event Query

This query returns the decimal value of the sum of the bits in the Questionable Calibration Extended Failure Event register.

NOTE	The register requires that the associated PTR or NTR filters be set before a condition register bit can set a bit in the event register. The data in this register is latched until it is queried. Once queried, the register is cleared.
-------------	---

Mode	All
Remote Command	:STATus:QUESTionable:CALibration:EXTended:FAILure[:EVENT]?
Example	STAT:QUES:CAL:EXT:FAIL?
Preset	0

SCPI Status Sequential command
 Bits/OPC
 Dependencies

Questionable Calibration Extended Failure Negative Transition

This command determines which bits in the Questionable Calibration Extended Failure Condition register will set the corresponding bit in the Questionable Calibration Extended Failure Event register when the condition register bit has a negative transition (1 to 0). The variable <integer> is the sum of the decimal values of the bits that you want to enable.

Mode All

Remote Command :STATus:QUEStionable:CALibration:EXTended:FAILure:NTRansition
 <integer>
 :STATus:QUEStionable:CALibration:EXTended:FAILure:NTRansition?

Example STAT:QUES:CAL:EXT:FAIL:NTR 1
 EMI conducted align failure is not required.

Preset 0

Min 0

Max 32767

SCPI Status Bits/OPC Sequential command
 Dependencies

Questionable Calibration Extended Failure Positive Transition

This command determines which bits in the Questionable Calibration Extended Failure Condition register will set the corresponding bit in the Questionable Calibration Extended Failure Event register when the condition register bit has a positive transition (0 to 1). The variable <integer> is the sum of the decimal values of the bits that you want to enable.

Mode All

Remote Command :STATus:QUEStionable:CALibration:EXTended:FAILure:PTRansition
 <integer>
 :STATus:QUEStionable:CALibration:EXTended:FAILure:PTRansition?

Example STAT:QUES:CAL:EXT:FAIL:PTR 1
 EMI conducted align failure is required.

Preset 32767

Min 0

Max 32767

SCPI Status Bits/OPC Sequential command
 Dependencies

Questionable Calibration Extended Needed Register

Questionable Calibration Extended Needed Condition

This query returns the decimal value of the sum of the bits in the Questionable Calibration Extended Needed Condition register.

NOTE The data in this register is continuously updated and reflects the current conditions.

Mode	All
Remote Command	:STATus:QUESTionable:CALibration:EXTended:NEEDED:CONDition?
Example	STAT:QUES:CAL:EXT:NEED:COND?
Preset	0
SCPI Status Bits/OPC Dependence	Sequential commands

Questionable Calibration Extended Needed Enable

This command determines which bits in the Questionable Calibration Extended Needed Condition Register will set bits in the Questionable Calibration Extended Needed Event register, which also sets bit 14 of the Questionable Calibration Register. The variable <integer> is the sum of the decimal values of the bits you want to enable.

Mode	All
Remote Command	:STATus:QUESTionable:CALibration:EXTended:NEEDED:ENABle <integer> :STATus:QUESTionable:CALibration:EXTended:NEEDED:ENABle?
Example	STAT:QUES:CAL:EXT:NEED:ENAB 2 Can be used to query if an EMI conducted alignment is needed.
Preset	32767
Min	0
Max	32767
SCPI Status Bits/OPC Dependence	Sequential command

Questionable Calibration Extended Needed Event Query

This query returns the decimal value of the sum of the bits in the Questionable Calibration Extended Needed Event register.

NOTE The register requires that the associated PTR or NTR filters be set before a condition register bit can set a bit in the event register. The data in this register is latched until it is queried. Once queried, the register is cleared.

Mode All

Remote Command :STATus:QUEStionable:CALibration:EXTended:NEEDED[:EVENT]?

Example STAT:QUES:CAL:EXT:NEED?

Preset 0

SCPI Status Bits/OPC Sequential command

Dependencies

Questionable Calibration Extended Needed Negative Transition

This command determines which bits in the Questionable Calibration Extended Needed Condition register will set the corresponding bit in the Questionable Calibration Extended Needed Event register when the condition register bit has a negative transition (1 to 0). The variable <integer> is the sum of the decimal values of the bits that you want to enable.

Mode All

Remote Command :STATus:QUEStionable:CALibration:EXTended:NEEDED:NTRansition<integer>

:STATus:QUEStionable:CALibration:EXTended:NEEDED:NTRansition?

Example STAT:QUES:CAL:EXT:NEED:NTR 2
Align EMI conducted is not required.

Preset 0

Min 0

Max 32767

SCPI Status Bits/OPC Sequential command

Dependencies

Questionable Calibration Extended Needed Positive Transition

This command determines which bits in the Questionable Calibration Extended Needed Condition register will set the corresponding bit in the Questionable Calibration Extended Needed Event register when the condition register bit has a positive transition (0 to 1). The variable <integer> is the sum of the decimal values of the bits that you want to enable.

Mode All

Remote Command	:STATus:QUESTionable:CALibration:EXTended:NEEDED:PTRansition <integer> :STATus:QUESTionable:CALibration:EXTended:NEEDED:PTRansition?
Example	STAT:QUES:CAL:EXT:NEED:PTR 2 Align EMI conducted is required.
Preset	32767
Min	0
Max	32767
SCPI Status Bits/OPC Dependencies	Sequential command

Questionable Frequency Register

Questionable Frequency Condition

This query returns the decimal value of the sum of the bits in the Questionable Frequency Condition register.

NOTE The data in this register is continuously updated and reflects the current conditions.

Mode	All
Remote Command	:STATus:QUESTionable:FREQuency:CONDition?
Example	STAT:QUES:FREQ:COND?
Preset	0
SCPI Status Bits/OPC Dependencies	Sequential command

Questionable Frequency Enable

This command determines which bits in the Questionable Frequency Condition Register will set bits in the Questionable Frequency Event register, which also sets the Frequency Summary bit (bit 5) in the Questionable Register. The variable <integer> is the sum of the decimal values of the bits you want to enable.

Mode	All
Remote Command	:STATus:QUESTionable:FREQuency:ENABLE <integer> :STATus:QUESTionable:FREQuency:ENABLE?

Example	STAT:QUES:FREQ:ENAB 2 Frequency Reference Unlocked will be reported to the Frequency Summary of the Status Questionable register.
Preset	32767
Min	0
Max	32767
SCPI Status Bits/OPC Dependencies	Sequential command

Questionable Frequency Event Query

This query returns the decimal value of the sum of the bits in the Questionable Frequency Event register.

NOTE	The register requires that the associated PTR or NTR filters be set before a condition register bit can set a bit in the event register. The data in this register is latched until it is queried. Once queried, the register is cleared.
-------------	---

Mode	All
Remote Command	:STATus:QUEStionable:FREQuency[:EVENT]?
Example	STAT:QUES:FREQ?
Preset	0
SCPI Status Bits/OPC Dependencies	Sequential command

Questionable Frequency Negative Transition

This command determines which bits in the Questionable Frequency Condition register will set the corresponding bit in the Questionable Frequency Event register when the condition register bit has a negative transition (1 to 0). The variable <integer> is the sum of the decimal values of the bits that you want to enable.

Mode	All
Remote Command	:STATus:QUEStionable:FREQuency:NTRansition <integer> :STATus:QUEStionable:FREQuency:NTRansition?
Example	STAT:QUES:FREQ:NTR 2 Frequency Reference 'regained lock' will be reported to the Frequency Summary of the Status Questionable register.
Preset	0

Min	0
Max	32767
SCPI Status Bits/OPC Dependencies	Sequential command

Questionable Frequency Positive Transition

This command determines which bits in the Questionable Frequency Condition register will set the corresponding bit in the Questionable Frequency Event register when the condition register bit has a positive transition (0 to 1). The variable <integer> is the sum of the decimal values of the bits that you want to enable.

Mode	All
Remote Command	:STATus:QUESTionable:FREQuency:PTRansition <integer> :STATus:QUESTionable:FREQuency:PTRansition?
Example	STAT:QUES:FREQ:PTR 2 Frequency Reference 'became unlocked' will be reported to the Frequency Summary of the Status Questionable register.
Preset	32767
Min	0
Max	32767
SCPI Status Bits/OPC Dependencies	Sequential command

Questionable Integrity Register

Questionable Integrity Condition

This query returns the decimal value of the sum of the bits in the Questionable Integrity Condition register.

NOTE The data in this register is continuously updated and reflects the current conditions.

Mode	All
Remote Command	:STATus:QUESTionable:INTEgrity:CONDition?
Example	STAT:QUES:INT:COND?
Preset	0
SCPI Status Bits/OPC Dependencies	Sequential command

Questionable Integrity Enable

This command determines which bits in the Questionable Integrity Condition Register will set bits in the Questionable Integrity Event register, which also sets the Integrity Summary bit (bit 9) in the Questionable Register. The variable <integer> is the sum of the decimal values of the bits you want to enable.

Mode	All
Remote Command	:STATus:QUESTionable:INTEgrity:ENABLE <integer> :STATus:QUESTionable:INTEgrity:ENABLE?
Example	STAT:QUES:INT:ENAB 8 Measurement Uncalibrated Summary will be reported to the Integrity Summary of the Status Questionable register.
Preset	32767
Min	0
Max	32767
SCPI Status Bits/OPC	Sequential command
Dependencies	

Questionable Integrity Event Query

This query returns the decimal value of the sum of the bits in the Questionable Integrity Event register.

NOTE	The register requires that the associated PTR or NTR filters be set before a condition register bit can set a bit in the event register. The data in this register is latched until it is queried. Once queried, the register is cleared.
-------------	---

Mode	All
Remote Command	:STATus:QUESTionable:INTEgrity[:EVENT]?
Example	STAT:QUES:INT?
Preset	0
SCPI Status Bits/OPC	Sequential command
Dependencies	

Questionable Integrity Negative Transition

This command determines which bits in the Questionable Integrity Condition register will set the corresponding bit in the Questionable Integrity Event register when the condition register bit has a negative transition (1 to 0). The variable <integer> is the sum of the

decimal values of the bits that you want to enable.

Mode	All
Remote Command	:STATus:QUEStionable:INTEgrity:NTRansition <integer> :STATus:QUEStionable:INTEgrity:NTRansition?
Example	STAT:QUES:INT:NTR 8 Measurement 'regained calibration' Summary will be reported to the Integrity Summary of the Status Questionable register.
Preset	0
Min	0
Max	32767
SCPI Status Bits/OPC Dependencies	Sequential command

Questionable Integrity Positive Transition

This command determines which bits in the Questionable Integrity Condition register will set the corresponding bit in the Questionable Integrity Event register when the condition register bit has a positive transition (0 to 1). The variable <integer> is the sum of the decimal values of the bits that you want to enable.

Mode	All
Remote Command	:STATus:QUEStionable:INTEgrity:PTRansition <integer> :STATus:QUEStionable:INTEgrity:PTRansition?
Example	STAT:QUES:INT:PTR 8 Measurement 'became uncalibrated' Summary will be reported to the Integrity Summary of the Status Questionable register.
Preset	32767
Min	0
Max	32767
SCPI Status Bits/OPC Dependencies	Sequential command

Questionable Integrity Signal Register

Questionable Integrity Signal Condition

This query returns the decimal value of the sum of the bits in the Questionable Integrity Signal Condition register.

NOTE The data in this register is continuously updated and reflects the current conditions.

Mode	All
Remote Command	:STATus:QUESTionable:INTEgrity:SIGNal:CONDition?
Example	STAT:QUES:INT:SIGN:COND?
Preset	0
SCPI Status Bits/OPC Dependencies	Sequential command

Questionable Integrity Signal Enable

This command determines which bits in the Questionable Integrity Signal Condition Register will set bits in the Questionable Integrity Signal Event register, which also sets the Integrity Summary bit (bit 9) in the Questionable Register. The variable <integer> is the sum of the decimal values of the bits you want to enable.

Mode	All
Remote Command	:STATus:QUESTionable:INTEgrity:SIGNal:ENABle <integer> :STATus:QUESTionable:INTEgrity:SIGNal:ENABle?
Example	STAT:QUES:INT:SIGN:ENAB 4 Burst Not Found will be reported to the Integrity Summary of the Status Questionable register.
Preset	32767
Min	0
Max	32767
SCPI Status Bits/OPC Dependencies	Sequential command

Questionable Integrity Signal Event Query

This query returns the decimal value of the sum of the bits in the Questionable Integrity Signal Event register.

NOTE The register requires that the associated PTR or NTR filters be set before a condition register bit can set a bit in the event register. The data in this register is latched until it is queried. Once queried, the

register is cleared.

Mode	All
Remote Command	:STATus:QUESTionable:INTEgrity:SIGNal[:EVENT]?
Example	STAT:QUES:INT:SIGN?
Preset	0
SCPI Status Bits/OPC	Sequential command
Dependencies	

Questionable Integrity Signal Negative Transition

This command determines which bits in the Questionable Integrity Signal Condition register will set the corresponding bit in the Questionable Integrity Signal Event register when the condition register bit has a negative transition (1 to 0). The variable <integer> is the sum of the decimal values of the bits that you want to enable.

Mode	All
Remote Command	:STATus:QUESTionable:INTEgrity:SIGNal:NTRansition <integer> :STATus:QUESTionable:INTEgrity:SIGNal:NTRansition?
Example	STAT:QUES:INT:SIGN:NTR 4 Burst found will be reported to the Integrity Summary of the Status Questionable register.
Preset	0
Min	0
Max	32767
SCPI Status Bits/OPC	Sequential command
Dependencies	

Questionable Integrity Signal Positive Transition

This command determines which bits in the Questionable Integrity Signal Condition register will set the corresponding bit in the Questionable Integrity Signal Event register when the condition register bit has a positive transition (0 to 1). The variable <integer> is the sum of the decimal values of the bits that you want to enable.

Mode	All
Remote Command	:STATus:QUESTionable:INTEgrity:SIGNal:PTRansition <integer> :STATus:QUESTionable:INTEgrity:SIGNal:PTRansition?

Example	STAT:QUES:INT:SIGN:PTR 4 Burst not found will be reported to the Integrity Summary of the Status Questionable register.
Preset	32767
Min	0
Max	32767
SCPI Status Bits/OPC Dependencies	Sequential command

Questionable Integrity Uncalibrated Register

Questionable Integrity Uncalibrated Condition

This query returns the decimal value of the sum of the bits in the Questionable Integrity Uncalibrated Condition register.

NOTE	The data in this register is continuously updated and reflects the current conditions.
-------------	--

Mode	All
Remote Command	:STATus:QUESTionable:INTEgrity:UNCalibrated:CONDition?
Example	STAT:QUES:INT:UNC:COND?
Preset	0
SCPI Status Bits/OPC Dependencies	Sequential command

Questionable Integrity Uncalibrated Enable

This command determines which bits in the Questionable Integrity Uncalibrated Condition Register will set bits in the Questionable Integrity Uncalibrated Event register, which also sets the Data Uncalibrated Summary bit (bit 3) in the Questionable Integrity Register. The variable <integer> is the sum of the decimal values of the bits you want to enable.

Mode	All
Remote Command	:STATus:QUESTionable:INTEgrity:UNCalibrated:ENABLE :STATus:QUESTionable:INTEgrity:UNCalibrated:ENABLE ?

Example	STAT:QUES:INT:UNC:ENAB 1 Oversweep (Meas Uncal) will be reported to the Integrity Summary of the Status Questionable register.
Preset	32767
Min	0
Max	32767
SCPI Status Bits/OPC Dependencies	Sequential command

Questionable Integrity Uncalibrated Event Query

This query returns the decimal value of the sum of the bits in the Questionable Integrity Uncalibrated Event register.

NOTE	The register requires that the associated PTR or NTR filters be set before a condition register bit can set a bit in the event register. The data in this register is latched until it is queried. Once queried, the register is cleared.
-------------	---

Mode	All
Remote Command	:STATus:QUESTionable:INTEgrity:UNCalibrated[:EVENT]?
Example	STAT:QUES:INT:UNC?
Preset	0
SCPI Status Bits/OPC Dependencies	Sequential command

Questionable Integrity Uncalibrated Negative Transition

This command determines which bits in the Questionable Integrity Uncalibrated Condition register will set the corresponding bit in the Questionable Integrity Uncalibrated Event register when the condition register bit has a negative transition (1 to 0). The variable <integer> is the sum of the decimal values of the bits that you want to enable.

Mode	All
Remote Command	:STATus:QUESTionable:INTEgrity:UNCalibrated:NTRansition <integer> :STATus:QUESTionable:INTEgrity:UNCalibrated:NTRansition?
Example	STAT:QUES:INT:UNC:NTR 1 Oversweep cleared will be reported to the Integrity Summary of the Status Questionable register.

Preset	0
Min	0
Max	32767
SCPI Status Bits/OPC	Sequential command
Dependencies	

Questionable Integrity Uncalibrated Positive Transition

This command determines which bits in the Questionable Integrity Uncalibrated Condition register will set the corresponding bit in the Questionable Integrity Uncalibrated Event register when the condition register bit has a positive transition (0 to 1). The variable <integer> is the sum of the decimal values of the bits that you want to enable.

Mode	All
Remote Command	:STATus:QUEStionable:INTEgrity:UNCalibrated:PTRansition <integer> :STATus:QUEStionable:INTEgrity:UNCalibrated:PTRansition?
Example	STAT:QUES:INT:UNC:PTR 1 Oversweep (Meas Uncal) occurred will be reported to the Integrity Summary of the Status Questionable register.
Preset	32767
Min	0
Max	32767
SCPI Status Bits/OPC	Sequential command
Dependencies	

Questionable Power Register

Questionable Power Condition

This query returns the decimal value of the sum of the bits in the Questionable Power Condition register.

NOTE The data in this register is continuously updated and reflects the current conditions.

Mode	All
Remote Command	:STATus:QUEStionable:POWer:CONDition?
Example	STAT:QUES:POW:COND?
Preset	0

SCPI Status Bits/OPC Sequential command
Dependencies

Questionable Power Enable

This command determines which bits in the Questionable Power Condition Register will set bits in the Questionable Power Event register, which also sets the Power Summary bit (bit 3) in the Questionable Register. The variable <integer> is the sum of the decimal values of the bits you want to enable.

Mode All

Remote Command :STATus:QUESTionable:POWer:ENABle <integer>
 :STATus:QUESTionable:POWer:ENABle?

Example STAT:QUES:POW:ENAB 32
 50 MHz Input Pwr too High for Cal will be reported to the
 Power Summary of the Status Questionable register.

Preset 32767

Min 0

Max 32767

SCPI Status Bits/OPC Sequential command
Dependencies

Questionable Power Event Query

This query returns the decimal value of the sum of the bits in the Questionable Power Event register.

NOTE The register requires that the associated PTR or NTR filters be set before a condition register bit can set a bit in the event register. The data in this register is latched until it is queried. Once queried, the register is cleared.

Mode All

Remote Command :STATus:QUESTionable:POWer[:EVENT]?

Example STAT:QUES:POW?

Preset 0

SCPI Status Bits/OPC Sequential command
Dependencies

Questionable Power Negative Transition

This command determines which bits in the Questionable Power Condition register will

set the corresponding bit in the Questionable Power Event register when the condition register bit has a negative transition (1 to 0). The variable <integer> is the sum of the decimal values of the bits that you want to enable.

Mode	All
Remote Command	:STATus:QUEStionable:POWer:NTRansition <integer> :STATus:QUEStionable:POWer:NTRansition?
Example	STAT:QUES:POW:NTR 32 50 MHz Input Power became OK for Cal will be reported to the Power Summary of the Status Questionable register.
Preset	0
Min	0
Max	32767
SCPI Status Bits/OPC Dependencies	Sequential command

Questionable Power Positive Transition

This command determines which bits in the Questionable Power Condition register will set the corresponding bit in the Questionable Power Event register when the condition register bit has a positive transition (0 to 1). The variable <integer> is the sum of the decimal values of the bits that you want to enable.

Mode	All
Remote Command	:STATus:QUEStionable:POWer:PTRansition <integer> :STATus:QUEStionable:POWer:PTRansition?>
Example	STAT:QUES:POW:PTR 32 50 MHz Input Power became too high for Cal will be reported to the Power Summary of the Status Questionable register.
Preset	32767
Min	0
Max	32767
SCPI Status Bits/OPC Dependencies	Sequential command

Questionable Temperature Register

Questionable Temperature Condition

This query returns the decimal value of the sum of the bits in the Questionable Temperature Condition register.

NOTE The data in this register is continuously updated and reflects the current conditions.

Mode All

Remote Command :STATus:QUESTionable:TEMPerature:CONDition?

Example STAT:QUES:TEMP:COND?

Preset 0

SCPI Status Bits/OPC Sequential command

Dependencies

Questionable Temperature Enable

This command determines which bits in the Questionable Temperature Condition Register will set bits in the Questionable Temperature Event register, which also sets the Temperature Summary bit (bit 4) in the Questionable Register. The variable <integer> is the sum of the decimal values of the bits you want to enable.

Mode All

Remote Command :STATus:QUESTionable:TEMPerature:ENABLE <integer>
 :STATus:QUESTionable:TEMPerature:ENABLE?

Example STAT:QUES:TEMP:ENAB 1
 Reference Oscillator Oven Cold will be reported to the Temperature Summary of the Status Questionable register.

Preset 32767

Min 0

Max 32767

SCPI Status Bits/OPC Sequential command

Dependencies

Questionable Temperature Event Query

This query returns the decimal value of the sum of the bits in the Questionable Temperature Event register.

NOTE The register requires that the associated PTR or NTR filters be set before a condition register bit can set a bit in the event register. The data in this register is latched until it is queried. Once queried, the register is cleared

Mode All

Remote Command	:STATus:QUEStionable:TEMPerature[:EVENT]?
Example	STAT:QUES:TEMP?
Preset	0
SCPI Status Bits/OPC	Sequential command
Dependencies	

Questionable Temperature Negative Transition

This command determines which bits in the Questionable Temperature Condition register will set the corresponding bit in the Questionable Temperature Event register when the condition register bit has a negative transition (1 to 0). The variable <integer> is the sum of the decimal values of the bits that you want to enable.

Mode	All
Remote Command	:STATus:QUEStionable:TEMPerature:NTRansition <integer> :STATus:QUEStionable:TEMPerature:NTRansition?
Example	STAT:QUES:TEMP:NTR 1 Reference Oscillator Oven not cold will be reported to the Temperature Summary of the Status Questionable register.
Preset	0
Min	0
Max	32767
SCPI Status Bits/OPC	Sequential command
Dependencies	

Questionable Temperature Positive Transition

This command determines which bits in the Questionable Temperature Condition register will set the corresponding bit in the Questionable Temperature Event register when the condition register bit has a positive transition (0 to 1). The variable <integer> is the sum of the decimal values of the bits that you want to enable.

Mode	All
Remote Command	:STATus:QUEStionable:TEMPerature:PTRansition <integer> :STATus:QUEStionable:TEMPerature:PTRansition?
Example	STAT:QUES:TEMP:PTR 1 Reference Oscillator Oven became cold will be reported to the Temperature Summary of the Status Questionable register.
Preset	32767

Min	0
Max	32767
SCPI Status Bits/OPC Dependencies	Sequential command

IEEE Common Commands

Numeric values for bit patterns can be entered using decimal or hexadecimal representations. (for example, 0 to 32767 is equivalent to #H0 to #H7FFF).

Calibration Query

*CAL? Performs a full alignment and returns a number indicating the success of the alignment. A zero is returned if the alignment is successful. A one is returned if any part of the alignment fails. The equivalent SCPI command is CALibrate[:ALL]?

Clear Status

Clears the status byte register. It does this by emptying the error queue and clearing all bits in all of the event registers. The status byte register summarizes the states of the other registers. It is also responsible for generating service requests.

Remote Command	*CLS
Example	*CLS Clears the error queue and the Status Byte Register.
Remote Command Notes	For related commands, see the SYSTem:ERRor[:NEXT]? command. See also the STATus:PRESet command and all commands in the STATus subsystem.
Key Path	No equivalent key. Related key System, Show Errors, Clear Error Queue
SCPI Status Bits/OPC Dependencies	Resets all bits in all event registers to 0, which resets all the status byte register bits to 0 also.

Standard Event Status Enable

Selects the desired bits from the standard event status enable register. This register monitors I/O errors and synchronization conditions such as operation complete, request control, query error, device dependent error, status execution error, command error and power on. The selected bits are OR'd to become a summary bit (bit 5) in the byte register which can be queried.

The query returns the state of the standard event status enable register.

Remote Command	*ESE <integer> *ESE?
Example	*ESE 36 Enables the Standard Event Status Register to monitor query and command errors (bits 2 and 5). *ESE? Returns a 36 indicating that the query and command status bits are enabled.

Remote Command Notes	For related commands, see the STATus subsystem and SYSTem:ERRor[:NEXT]? commands.
Preset	255
State Saved	Not saved in state.
Min	0
Max	255
Key Path	No equivalent key. Related key System, Show Errors, Clear Error Queue
SCPI Status Bits/OPC Dependencies	Event Enable Register of the Standard Event Status Register.

Standard Event Status Register Query

Queries and clears the standard event status event register. (This is a destructive read.) The value returned is a hexadecimal number that reflects the current state (0/1) of all the bits in the register.

Remote Command	*ESR?
Example	*ESR? Returns a 1 if there is either a query or command error, otherwise it returns a zero.
SCPI Status Bits/OPC Dependencies	Standard Event Status Register (bits 0 – 7).
Remote Command Notes	For related commands, see the STATus subsystem commands.
Preset	0
Min	0
Max	255

Identification Query

Returns a string of instrument identification information. The string will contain the model number, serial number and firmware revision.

The response is organized into four fields separated by commas. The field definitions are as follows:

- Manufacturer
- Model
- Serial number

- Firmware version

Remote Command	*IDN?
Example	*IDN? Returns instrument identification information, such as: Agilent Technologies,N9020A,US00000713,A.01.02
Key Path	No equivalent key. See related key System, Show System.

Operation Complete

The *OPC command sets bit 0 in the standard event status register (SER) to “1” when pending operations have finished, that is when all overlapped commands are complete. It does not hold off subsequent operations. You can determine when the overlapped commands have completed either by polling the OPC bit in SER, or by setting up the status system such that a service request (SRQ) is asserted when the OPC bit is set.

The *OPC? query returns a “1” after all the current overlapped commands are complete. So it holds off subsequent commands until the “1” is returned, then the program continues. This query can be used to synchronize events of other instruments on the external bus.

Remote Command	*OPC *OPC?
Example	INIT:CONT 0 Selects single sweeping. INIT:IMM Initiates a sweep. *OPC? Holds off any further commands until the sweep is complete.
SCPI Status Bits/OPC Dependencies	Not global to all remote ports or front panel. *OPC only considers operation that was initiated on the same port as the *OPC command was issued from. *OPC is an overlapped command, but *OPC? is sequential.

Query Instrument Options

Returns a string of all the installed instrument options. It is a comma separated list with quotes, such as: “503,P03,FPR”. To be IEEE compliant, this command should return an arbitrary ascii variable that would not begin and end with quotes. But the quotes are needed to be backward compatible with previous SA products and software. So, the actual implementation will use arbitrary ascii. But quotes will be sent as the first and last ascii characters that are sent with the comma-separated option list.

Remote Command	*OPT?
-----------------------	-------

Recall Instrument State

This command recalls the instrument state from the specified instrument memory register.

- If the state being loaded has a newer firmware revision than the revision of the instrument, no state is recalled and an error is reported.
- If the state being loaded has a firmware revision equal to the revision of the instrument, the state will be loaded.
- If the state being loaded has an older firmware revision than the revision of the instrument, the instrument will only load the parts of the state that apply to the older revision.

Remote Command	*RCL <register #>
Example	*RCL 7 Recalls the instrument state that is currently stored in register 7.
Restriction and Notes	Registers 0 through 6 are accessible from the front panel in menu keys for Recall Registers.
SCPI Status Bits/OPC Dependencies	The command is sequential.
Min	0
Max	127

Reset

This command does a Mode Preset and selects single sweep/measurement. It does not change the mode, and only resets the parameters for the current mode. And it does not do a *CLS which would clear the STATUS bits and the error queue.

Remote Command	*RST
Example	*RST Presets the settings of the current mode.
Restriction and Notes	See the Mode Preset key description for more details about the implementation.

Save Instrument State

This command saves the current instrument state and mode to the specified instrument memory register.

Remote Command	*SAV <register #>
Example	*SAV 9 Saves the instrument state in register 9.
Restriction and Notes	Registers 0 through 6 are accessible from the front panel in menu keys for Save Registers.

SCPI Status Bits/OPC Dependencies	The command is sequential.
Min	0
Max	127

Service Request Enable

This command enables the desired bits of the service request enable register.

The query returns the value of the register, indicating which bits are currently enabled.

Remote Command	*SRE <integer> *SRE?
Example	*SRE 22 Enables bits 1, 2, and 4 in the service request enable register.
SCPI Status Bits/OPC Dependencies	Service Request Enable Register (all bits, 0 – 7).
Remote Command Notes	For related commands, see the STATus subsystem and SYSTem:ERRor[:NEXT]? commands.
Preset	255
Min	0
Max	255

Status Byte Query

Returns the value of the status byte register without erasing its contents.

Remote Command	*STB?
Example	*STB? Returns a decimal value for the bits in the status byte register. For example, if a 16 is returned, it indicates that bit 5 is set and one of the conditions monitored in the standard event status register is set.
SCPI Status Bits/OPC Dependencies	Status Byte Register (all bits, 0 – 7).
Remote Command Notes	See related command *CLS.

Trigger

This command triggers the instrument. Use the :TRIGger[:SEQuence]:SOURce command

to select the trigger source.

Remote Command	*TRG
Example	*TRG Triggers the instrument to take a sweep or start a measurement, depending on the current instrument settings.
Remote Command Notes	See related command :INITiate:IMMediate.
Key Path	No equivalent key. See related keys Single and Restart.

Self Test Query

This query performs the internal self-test routines and returns a number indicating the success of the testing. A zero is returned if the test is successful, 1 if it fails.

Remote Command	*TST?
Example	*TST? Runs the self-test routines and returns 0=passed, 1=some part failed.


Wait-to-Continue

This command causes the instrument to wait until all overlapped commands are completed before executing any additional commands. There is no query form for the command.

Remote Command	*WAI
Example	INIT:CONT OFF; INIT;*WAI Sets the instrument to single sweep. Starts a sweep and waits for its completion.
SCPI Status Bits/OPC Dependencies	Not global to all remote ports or front panel. *OPC only considers operation that was initiated on the same port as the *OPC command was issued from.

Display Control Keys

The instrument provides three front-panel keys for controlling windows. They are **Multi Window**, **Zoom**, and **Next Window**. These are all “immediate action” keys.



Multi Window Zoom Next Window

Multi-Window

The **Multi Window** front-panel key is a Measurement dependent key. Each Measurement in a mode may define the operation of the **Multi-Window** key as most appropriate for that Measurement. It may do nothing. It may invoke a different measurement or a different view or both. It may toggle or step through multiple choices.

If **Multi-Window** is pressed in a Measurement for which its use is not defined, one of two warnings is generated:

“This measurement is always in a Multi-Window view.” (for multi-window measurements that can’t turn off Multi-Window), or

“There is no Multi-Window view for this Measurement.” (for measurements for which Multi-Window operation is undefined).

For example, in the Swept SA measurement, **Multi-Window** switches to the Alternate Sweep View with Zone Markers turned on.

A Measurement may elect to provide controls that vary the relative duty cycles of a multi-window view, so that (for example) the top window in a two-window display sweeps once for every five sweeps of the bottom window. These controls would be found in the View/Display menu. See the Navigation example.

Key Path	Front-panel key
----------	-----------------

Zoom

Zoom is a toggle function. Pressing the Zoom key once enlarges the selected window; pressing this key again returns the window to normal size.

When Zoom is on for a window, that window occupies the entire primary display area. The

zoomed window, since it is the selected window, is outlined in green.

Only primary windows can be zoomed.

Zoom is local to each Measurement. Each Measurement remembers its Zoom state. The Zoom state of each Measurement is part of the Mode's state.

The state of zoom, and which window is zoomed, is saved in State.

Data acquisition and processing for the other windows continues while a window is zoomed, as does all SCPI communication with the other windows.


If you have a mouse and you double click on a window, that window is selected and zoomed.

Key Path

Front-panel key


Navigation Example

In the example below, we start in a four-window state with Window 1 selected:




Now Next Window has been pressed, so Window 2 is selected:

Utility Functions Display Control Keys



Now Zoom has been pressed, so window 2 has been zoomed:



If a secondary window had been present, its size and position would have remained unchanged while the primary windows were being selected and zoomed.

Next Window

This key selects the next window of the current view.

When this key is selected in Help mode, it toggles focus between the table of contents window and the topic pane window.

Selected Window

One and only one primary window is always selected.

The selected window has the focus; as far as the user is concerned, all key presses are going to that window.

All windows have a 3 pixel wide boundary. The selected window has a green boundary. If a window is not selected, its boundary is gray.

Only primary windows may be selected.

If a primary window in a multi-window display is zoomed it is still outlined in green. If there is only one primary window, the green outline is not used. This allows the user to distinguish between a zoomed window and a display with only one primary window.

The selected window is local to each Measurement. Each Measurement remembers which window is selected. The selected window for each Measurement is remembered in Mode state.

If you have a mouse and you click on a window, that window is selected.

Navigating Windows

When the Next Window key is pressed, the next window in the order of precedence (see next topic) becomes selected. If the selected window was zoomed, the next window will also be zoomed.

Window precedence

The standard precedence that is used for primary windows is left/right top/bottom; that is, in the 4 primary-window case, window 1 is the top left, window 2 is the top right, window 3 is the bottom left, window 4 is the bottom right.

Secondary windows have no precedence; they are never selected.

Select Display Format Tiled (remote command only)

Sets the display format for the current measurement to “un-zoomed”. This is the preset state of all measurements.

Remote Command :DISPlay:WINDow:FORMat:TILE

Example :DISP:WIND:FORM:TILE

Select Display Format Zoomed (remote command only)

Sets the display format for the current measurement to “zoomed”. Zooms the currently selected window.

Remote Command :DISPlay:WINDow:FORMat:ZOOM

Example :DISP:WIND:FORM:ZOOM

Window Focus Move Control (remote command only)

Selects a window for control and zooming for the current measurement.

Remote Command	:DISPlay:WINDow[:SElect] <number> :DISPlay:WINDow[:SElect]?
Example	:DISP:WIND 1
Preset	1
Min	1
Max	If <number> is greater than the number of windows, limit to <number of windows>

This section describes both common analyzer setup functionality and functionality that is unique to the IQ Analyzer measurement application mode. These functions are context dependent and can change depending on the current settings at the Mode and Measurement levels. Some of the content is not directly applicable to the IQ Analyzer mode. This common MXA functionality information is provided as reference material to better understand some of the unique features that are available in this mode.

The remote commands are mode dependent. Most are only available when the IQ Analyzer mode is selected. (INSTRument:SElect BASIC)

AMPTD Y Scale

The Amplitude key activates the Amplitude menu and selects Reference Level as the active function.

Key Path **Front-panel key**

Reference Level

The reference level specifies the amplitude of a signal which would be displayed on the top graticule line.

Changing the reference level does not restart a measurement, and instead adjusts all displayed traces and markers to the new value. If a change to the reference level changes an auto-coupled attenuation value, the measurement will be restarted.

Remote Command	<code>:DISPlay:WINDow[1]:TRACe:Y[:SCALE]:RLEVel <real></code> <code>:DISPlay:WINDow[1]:TRACe:Y[:SCALE]:RLEVel?</code>
Example	<code>DISP:WIND:TRAC:Y:RLEV 20 dBm</code> Sets the reference level to 20 dBm, which displays in the current Y axis unit. For example, if the Y axis unit is dB μ V, then 126.99 dB μ V will be displayed.
Dependencies/Couplings	The value is constrained within the MAX and MIN values, but is otherwise generally not adjusted. Note: If you reduce the attenuation setting, the analyzer may have to lower the reference level to maintain the proper level at the top of the screen. If you then increase attenuation, the reference level does not increase to its previous value.
Preset	0 dBm
State Saved	Saved in State
Min	$\text{RefLevelMin} = -170 \text{ dBm} + \text{RefLevelOffset} - \text{ExtGain}$.
Key Path	AMPTD
Default Unit	Depends on the current selected Y axis unit.
Annotation	The reference level is displayed above and to the left of the graticule with the title "Ref".

Attenuation

This menu controls both the electrical and mechanical attenuators and their interactions. The value read back on the key in square brackets is the current Total (Elec + Mech) attenuation. Note that when in “Pre-Adjust for Min Clip” this value can change at the start of every measurement.

All parameters in the Attenuation menus are Meas Global, meaning they are unaffected by Meas Preset.

Key Path AMPTD Y Scale

Mech Atten Auto/Man

You can modify the mechanical attenuation applied to the RF input signal path with this feature. This value is normally auto coupled to the Ref Level, the Internal Preamp Gain, any External Gain that is entered, and the Max Mixer Level, as described in the below. However, when the electrical attenuator is enabled, there is no Auto/Man functionality for the mechanical attenuator, and the third line of the key disappears. The Auto/Man state of the key is remembered and restored when the electrical attenuator is once again disabled.

Remote Command [:SENSe]:POWer[:RF]:ATTenuation <rel_ampl>
[:SENSe]:POWer[:RF]:ATTenuation?

Example POW:ATT 20
Sets the attenuator to manual mode, and sets the value to 20 dB.

Dependencies/Couplings When the electrical attenuator is enabled, the mechanical attenuator has no auto setting and Auto/Man line on the key disappears. The state of Auto/Man is remembered and restored when the electrical attenuator is once again disabled. If it is restored to Man, the mechanical attenuation is set to the sum of the current values of mechanical and electrical attenuation, but if it is restored to Auto it recouples according to the Couplings, listed below.

When the Input Attenuator is in Auto, it uses the following algorithm to determine a value.

Calculate a new value = ReferenceLevel + PreAmpGain + ExternalGain – RefLevelOffset - MaxMixerLevel + IF Gain.

Limit this new value to be between 6 and 70 dB (no value below 6 dB can ever be chosen by Auto)

The resulting value should be rounded up to the largest value possible given the attenuation step setting. for example, 50.01 dB would change to 60 dB (for a 10dB attenuation step).

Preset Auto

State Saved Saved in State

Min	0 dB
	The mechanical attenuation cannot be decreased below 6 dB with the knob or step keys. To get to a value below 6 dB it has to be directly entered from the keypad or via SCPI. This protects from adjusting the attenuation to a dangerously small value which can put the instrument at risk of damage to input circuitry. However, if the current mechanical attenuation is below 6 dB it can be increased with the knob and step keys, but not decreased.
Max	70 dB
Key Path	AMPTD, Attenuation

Enable Elec Atten

You can enable or disable the Electrical Attenuator.

The Electrical Attenuator offers no significant advantage over the Mechanical Attenuator for front-panel operation; therefore it is assumed you will use the Mechanical Attenuator when operating the analyzer from the front-panel.

When the Electrical Attenuator is enabled, the Mechanical Attenuator transitions to a state in which it has no Auto function. Here are the rules for transitioning the Mechanical Attenuator:

When the Electrical Attenuator is enabled:

- The Mechanical Attenuator is initialized to 10 dB (this is its optimal performance setting). You can then set it as desired with SCPI, numeric keypad, step keys, or the knob, and it behaves as it normally would in manual mode
- The Auto/Man state of Mech Atten is saved
- The Auto/Man line on the Mech Atten softkey disappears and the Auto rules are disabled
- The Electrical Attenuator is set to 10 dB less than the previous value of the Mechanical Attenuator, within the limitation that it must stay within the range of 0 to 24 dB of attenuation.

Examples:

- Mech Atten at 20 dB. Elec Atten enabled, Mech Atten set to 10 dB, Elect Atten set to 10 dB. New total attenuation equals the value before Elec Atten enabled.
- Mech Atten at 0 dB. Elec Atten enabled, Mech Atten set to 10 dB, Elect Atten set to 0 dB. New total attenuation does not equal the value before Elec Atten enabled.
- Mech Atten at 40 dB. Elec Atten enabled, Mech Atten set to 10 dB, Elect Atten set to 24 dB. New total attenuation does not equal the value before Elec Atten enabled.

When the Electrical Attenuator is disabled:

- The Elec Atten key is grayed out
- The Auto/Man state of Mech Atten is restored
- If now in Auto, Mech Atten recouples
- If now in Man, Mech Atten sets to the value of the total attenuation that existed before the Elec

AMPTD Y Scale

Atten was disabled. The resulting value should be rounded up to the smallest value possible given the Mech Atten Step setting - (for example, 57 dB would change to 58 dB when the Mech Atten Step is 2 dB.)

The electronic attenuator is unavailable above 3.6 GHz. Therefore, if the Stop Frequency of the analyzer is > 3.6 GHz then Enable Elec Atten is grayed out; if the Elec Atten is enabled, then the Stop Freq of the analyzer is limited to 3.6 GHz, which is to say the UI start, stop, center frequency and span values are all limited to a maximum of 3.6 GHz + Frequency Offset.

Remote Command [:SENSe]:POWER[:RF]:EATTenuation:STATE OFF|ON|0|1
[:SENSe]:POWER[:RF]:EATTenuation:STATE?

Remote Command POW:EATT ON
Example

Dependencies/Couplings The electronic attenuator is unavailable above 3.6 GHz. Therefore, if the Stop Frequency of the analyzer is > 3.6 GHz then the Elec Atten is grayed out.

If the Elec Atten is enabled, then the Stop Freq of the analyzer is limited to 3.6 GHz. See Frequency section.

Preset OFF

State Saved Saved in instrument state.

Key Path **AMPTD, Attenuation**

Elec Atten

You can modify the electrical attenuation using this function

Remote Command [:SENSe]:POWER[:RF]:EATTenuation <rel_ampl>
[:SENSe]:POWER[:RF]:EATTenuation?

Restriction and Notes Electrical Attenuation specification is defined only when Mechanical Attenuation is 6 dB.

Dependencies/Couplings When Enable Elec Atten is off, the Elec Atten key is grayed out.
ngs

Preset 0 dB

State Saved Saved in instrument state.

Min 0 dB

Max 24 dB

Key Path **AMPTD, Attenuation**

Adjust Atten for Min Clip


This function is similar to the “Optimize Ref Level” function. Its purpose is to set the combination of mechanical and electrical attenuation based on the current measured signal level so that clipping

will be at a minimum.

This is a “one-time” function, that is, it executes once, when the key is pressed.

This key is grayed out in measurements that do not support this functionality. The spectrum analyzer measurement, Swept SA, does not support this functionality.

The algorithm to be used is as follows:



Remote Command `[[:SENSE]:POWER[:RF]:RANGE:OPTimize IMMEDIATE`

Key Path **AMPTD, Attenuation**

Pre-Adjust for Min Clip

When on, it executes the adjustment algorithm each time a measurement restarts. (Therefore, in Continuous, it only executes before the first measurement.)

This key is grayed out in measurements that do not support this functionality. The spectrum

AMPTD Y Scale

analyzer measurement, Swept SA, does not support this functionality.

Remote Command	<code>[:SENSe] :POWer [:RF] :RANGe:OPTimize:ATTenuation OFF ELECTrical COMBined [:SENSe] :POWer [:RF] :RANGe:OPTimize:ATTenuation?</code>
State Saved	Saved in State
Key Path	AMPTD, Attenuation

Remote Command	<code>[:SENSe] :POWer [:RF] :RANGe:AUTO ON OFF 1 0 [:SENSe] :POWer [:RF] :RANGe:AUTO?</code>
Remote Command Notes	ON aliases to “Elec Atten Only” OFF aliases to “Off” The query returns true if not “Off”

Off

Sets the optional attenuation Off.

Example	<code>:POW:RANGe:OPT:ATT OFF</code>
Key Path	AMPTD, Attenuation, Pre-Adjust for Min Clip

Elec Atten Only

Sets the optional attenuation to Electrical.

Example	<code>:POW:RANGe:OPT:ATT ELEC</code>
Key Path	AMPTD, Attenuation, Pre-Adjust for Min Clip

Mech + Elec Atten

Sets the optional attenuation to a combination of mechanical and electrical.

Example	<code>:POW:RANGe:OPT:ATT COMB</code>
Key Path	AMPTD, Attenuation, Pre-Adjust for Min Clip

Mech Atten Step

This controls what step size is used when making adjustments to the Input Attenuation.

Remote Command	<code>[:SENSE] :POWER [:RF] :ATTenuation:STEP [:INCRement] 10dB 2dB</code> <code>[:SENSE] :POWER [:RF] :ATTenuation:STEP [:INCRement] ?</code>
Example	POW:ATT:STEP 2
Dependencies/Couplings	When the attenuation step size changes, the current mechanical attenuation value is adjusted (if necessary) to be quantized to the new step size. For example, if step is set to 10 dB, mechanical attenuation is increased if necessary so it is a multiple of 10 dB
Remote Command Notes	This feature works like a 1-N choice from the front panel, but it takes a specific value (in dB) when used remotely. The only valid values are 2 and 10.
Preset	2 dB
State Saved	Saved in State
Key Path	AMPTD, Attenuation

Max Mixer Level

The Max Mixer Level controls the limitation on the Ref Level for a given attenuation setting, and therefore also interacts with the Auto rules for selecting the attenuation as a coupling from the reference level.

Remote Command	<code>[:SENSE] :POWER [:RF] :MIXer:RANGe [:UPPer] <real></code> <code>[:SENSE] :POWER [:RF] :MIXer:RANGe [:UPPer] ?</code>
Example	POW:MIX:RANG -15 dBm
Preset	-10 dBm
State Saved	Saved in State
Min	-50 dBm
Max	-10 dBm
Key Path	AMPTD, Attenuation
Default Unit	Depends on the current selected Y-axis unit.

Scale / Div

Sets the units per vertical graticule division on the display. This function is only available when Scale Type (Log) is selected and the vertical scale is power. When Scale Type (Lin) is selected,

AMPTD Y Scale

Scale/Div is grayed out.

Remote Command	<code>:DISPlay:WINDow[1]:TRACe:Y[:SCALE]:PDIVision <rel_amp1></code> <code>:DISPlay:WINDow[1]:TRACe:Y[:SCALE]:PDIVision?</code>
Example	<code>DISP:WIND:TRAC:Y:PDIV 5 DB</code>
Dependencies/Couplings	Scale/Div is grayed out in linear Y scale. Sending the equivalent SCPI command does change the Scale/Div, though it has no affect while in Lin.
Preset	10.00 dB / Div
State Saved	Saved in State
Min	0.10 dB
Max	20 dB
Key Path	AMPTD

Scale Type

Chooses a linear or logarithmic vertical scale for the display and for remote data readout.

When Scale Type (Log) is selected, the vertical graticule divisions are scaled in logarithmic units. The top line of the graticule is the Reference Level and uses the scaling per division (Scale/Div) to assign values to the other locations on the graticule.

When Scale Type (Lin) is selected, the vertical graticule divisions are linearly scaled with the reference level value at the top of the display and zero volts at the bottom. Each vertical division of the graticule represents one-tenth of the Reference Level.

NOTE The Y Axis Unit used for each type of display is set by pressing Y Axis Unit. The analyzer remembers separate Y Axis Unit settings for both Log and Lin.

Remote Command	<code>:DISPlay:WINDow[1]:TRACe:Y[:SCALE]:SPACing</code> <code>LINear LOGarithmic</code> <code>:DISPlay:WINDow[1]:TRACe:Y[:SCALE]:SPACing?</code>
Example	<code>DISP:WIND:TRAC:Y:SPAC LOG</code> <code>DISP:WIND:TRAC:Y:SPAC?</code>
Dependencies/Couplings	If Normalize is on, Scale Type is forced to Log and is grayed out. Changing the Scale Type always sets the Y Axis unit to the last unit specified for the current amplitude scale. In other words, we restore the Y Axis unit setting appropriate per log/lin.
Preset	LOG
State Saved	Saved in State

Key Path

AMPTD

Presel Center

When this key is pressed, the centering of the preselector filter is adjusted to optimize the amplitude accuracy at the frequency of the selected marker. If the selected marker is not on when Presel Center is pressed, the analyzer will turn on the selected marker, perform a peak search, then perform centering on the marker's center frequency. If the selected marker is already on, and between the start and stop frequencies of the analyzer, the analyzer performs the preselector calibration on that marker's frequency. If the selected marker is already on, but outside the frequency range between Start Freq and Stop Freq, the analyzer will first perform a peak search, then perform centering on the marker's center frequency.

A number of considerations should be observed to ensure proper operation:

If the selected marker is already on, the analyzer will attempt the centering at that marker's frequency

There is no preselector for signals below approximately 3.6 GHz

The preselector can be bypassed (see **Input/Output, Preselector On/Off**). If it is bypassed, no centering will be attempted in that range.

When centering the preselector, *OPC will not return true until the process is complete and a subsequent measurement has completed, nor will results be returned to a READ or MEASure command. If the box is in a measurement such as averaging when this happens, the act of centering the preselector will restart averaging but the first average trace will not be taken until the centering is completed.

Remote Command	<code>[:SENSE] :POWER [:RF] :PCENter</code>
Example	POW:PCEN
Dependencies/Couplings	<p>Grayed out if microwave preselector is off (see Input/Output, Microwave Preselector On/Off).</p> <p>If the selected marker's frequency is below Band 1, advisory 0.5001 is generated and no action is taken.</p> <p>Grayed out if entirely in Band 0.</p> <p>Blank in models that do not include a preselector, such as option 503. If the SCPI is sent in such models, it generates an error.</p> <p>Active marker position determines where the centering will be attempted.</p>
Remote Command Notes	<p>The rules outlined above under the key description apply for the remote command as well as the key. Hence, the result of the command is dependent on marker position, and so on.</p> <p>Any message thrown by the keypress is also thrown in response to the remote command.</p>
Preset	n/a (see Presel Adjust)

AMPTD Y Scale

State Saved	n/a (see Presel Adjust)
Key Path	AMPTD
SCPI Status Bits/OPC Dependencies	The Measuring bit should remain set while this command is operating and should not go false until the subsequent sweep/measurement has completed.

Preselector Adjust

Allows you to manually adjust the preselector filter frequency to optimize its response to the signal of interest. This function is only available when **Presel Center** is available.

For general purpose signal analysis, using Presel Center is recommended. Centering the filter minimizes the impact of long-term preselector drift. Presel Adjust can be used instead to manually optimize the preselector. One application of manual optimization would be to peak the preselector response, which both optimizes the signal-to-noise ratio and minimizes amplitude variations due to small (short-term) preselector drifting.

Preselector Adjust is a meas global parameter so it is common across all measurements.

Remote Command	<code>[:SENSe] :POWER [:RF] :PADJust <freq></code> <code>[:SENSe] :POWER [:RF] :PADJust?</code>
Example	<code>POW:PADJ 100KHz</code> <code>POW:PADJ?</code>
Dependencies/Couplings	Grayed out if microwave preselector is off (see Input/Output, Microwave Preselector On/Off) Grayed out if entirely in Band 0. Blank in models that do not include a preselector, such as option 503. If the SCPI is sent in such models, it generates an error.
Preset	0 MHz
State Saved	The Presel Adjust value set by Presel Center , or by manually adjusting Presel Adjust , is not saved in Instrument State, and does not survive Preset or power cycle.
Min	-500 MHz
Max	500 MHz
Key Path	AMPTD
Default Unit	Hz

Remote Command [:SENSe]:POWer[:RF]:PADJust:PRESelector
MWAVe|MMWave|EXTernal

[:SENSe]:POWer[:RF]:PADJust:PRESelector?

Remote Command Notes [:SENSe]:POWer[:RF]:PADJust:PRESelector
MWAVe|MMWave|EXTernal

where

MWAV = 3–26 GHz

MMWave = 26–50 GHz

EXTernal = External

The command form is a NOP

The query, will return MWAVe for MXA.

Y Axis Unit

Displays the menu keys that enable you to change the vertical (Y) axis amplitude unit. The analyzer retains the entered Y Axis Unit separately for both Log and Lin amplitude scale types. For example, if Scale Type has been set to Log, and you set Y Axis Unit to dBm, pressing Scale Type (Log) sets the Y Axis Unit to dBm. If Scale Type has been set to Lin and you set Y Axis Unit to V, pressing Scale Type (Lin) sets the Y Axis Unit to V. Pressing Scale Type (Log) again sets the Y axis unit back to dBm.

Remote Command :UNIT:POWer
DBM|DBMV|DBMA|V|W|A|DBUV|DBUA|DUVM|DUAM|DBPT|DBG
:UNIT:POWer?

Example UNIT:POW dBmV
UNIT:POW?

Dependencies/Couplings The analyzer retains the entered Y-Axis Unit separately for both Log and Lin amplitude scale types (see key descriptions).

AMPTD Y Scale

Remote Command Notes The settings of Y Axis Unit and Scale Type, affect how the data is read over the remote interface. When using the remote interface no unit is returned, so you must know what the Y axis unit is to interpret the results:

Example 1, set the following:

Scale Type (Log)

Y Axis Unit, dBm

Scale/Div, 1 dB

Ref Level, 10 dBm

This sets the top line to 10 dBm with each vertical division representing 1 dB. Thus, if a point on trace 1 is on the fifth graticule line from the top, it represents 5 dBm and will read out remotely as 5.

Example 2, set the following:

Scale Type (Lin)

Y Axis Unit, Volts

Ref Level, 100 mV (10 mV/div)

This sets the top line to 100 mV and the bottom line to 0 V, so each vertical division represents 10 mV. Thus, if a point on trace 1 is on the fifth graticule line from the top, it represents 50 mV and will read out remotely as 50.

Preset dBm for log scale, V for linear. The true 'preset' value is dBm, since at preset the Y Scale type is set to logarithmic.

State Saved Saved in State

Key Path **AMPTD**

dBm

Sets the amplitude unit for the selected amplitude scale (log/lin) to dBm.

Remote Command Example UNIT:POW DBM

Key Path **AMPTD, Y Axis Unit**

dBmV

Sets the amplitude unit for the selected amplitude scale (log/lin) to dBmV.

Remote Command Example UNIT:POW DBMV

Key Path **AMPTD, Y Axis Unit**

dBmA

Sets the amplitude unit for the selected amplitude scale (log/lin) to dBmA.

Remote Command Example UNIT:POW DBMA

Key Path **AMPTD, Y Axis Unit**

W

Sets the amplitude unit for the selected amplitude scale (log/lin) to watt.

Remote Command Example UNIT:POW W

Key Path **AMPTD, Y Axis Unit**

V

Sets the amplitude unit for the selected amplitude scale (log/lin) to volt.

Remote Command Example UNIT:POW V

Key Path **AMPTD, Y Axis Unit**

A

Sets the amplitude unit for the selected amplitude scale (log/lin) to Ampere.

Remote Command Example UNIT:POW A

Key Path **AMPTD, Y Axis Unit**

dB μ V

Sets the amplitude unit for the selected amplitude scale (log/lin) to dB μ V.

Remote Command Example UNIT:POW DBUV

Key Path **AMPTD, Y Axis Unit**

dB μ A

Sets the amplitude unit for the selected amplitude scale (log/lin) to dB μ A.

Remote Command Example UNIT:POW DBUA

Key Path **AMPTD, Y Axis Unit**

Reference Level Offset

Adds an offset value to the displayed reference level. The reference level is the absolute amplitude represented by the top graticule line on the display.

AMPTD Y Scale

Offsets are used when gain or loss occurs between a device under test and the analyzer input. Thus, the signal level measured by the analyzer may be thought of as the level at the input of an external amplitude conversion device. Entering an offset does not affect the trace position or attenuation value, just the value of the top line of the display and the values represented by the trace data. Thus, the values of exported trace data, queried trace data, marker amplitudes, trace data used in calculations such as N dB points, trace math, peak threshold, and so forth, are all affected by Ref Level Offset.

NOTE	Changing the offset causes the analyzer to immediately stop the current sweep and prepare to begin a new sweep, but the data will not change until the trace data updates, because the offset is applied to the data as it is taken. If a trace is exported with a nonzero Ref Level Offset, the exported data will contain the trace data with the offset applied.
-------------	---

The maximum reference level available is dependent on the reference level offset. That is, Ref Level - Ref Level Offset must be in the range -170 to $+30$ dBm. For example, the reference level value range can be initially set to values from -170 dBm to 30 dBm with no reference level offset. If the reference level is first set to -20 dBm, then the reference level offset can be set to values of -150 to $+50$ dB.

If the reference level offset is first set to -30 dB, then the reference level can be set to values of -200 dBm to 0 dBm. In this case, the reference level is held at 0 dBm because the maximum limit of $+30$ dBm is reached with a reference level setting of 0 dBm with an offset of -30 dB. If instead, the reference level offset is first set to 30 dB, then the reference level can be set to values of -140 to $+60$ dBm.

Remote Command	:DISPlay:WINDow[1]:TRACe:Y[:SCALE]:RLEVel:OFFSet <rel_ampl> :DISPlay:WINDow[1]:TRACe:Y[:SCALE]:RLEVel:OFFSet?
-----------------------	---

Example	DISP:WIND:TRAC:Y:RLEV:OFFS 12.7 Sets the Ref Level Offset to 12.7 dB. The only valid suffix is dB. If no suffix is sent, dB will be assumed.
----------------	---

Preset	0 dBm
State Saved	Saved in State
Min	The range for Ref Lvl Offset is variable. It is limited to values that keep the reference level within the range of -327.6 dB to 327.6 dB.
Max	327.6 dB
Key Path	AMPTD

Internal Preamp

Accesses keys that control the internal preamps. Turning on the preamp gives a better noise figure, but a poorer TOI to noise floor dynamic range. You can optimize this setting for your particular measurement.

Preamp On/Off and Preamp Band are Meas Global parameters.

Remote Command	<code>[:SENSe] :POWer [:RF] :GAIN [:STATe] OFF ON 0 1</code> <code>[:SENSe] :POWer [:RF] :GAIN [:STATe] ?</code>
Dependencies/Couplings	Preamp is not available on all hardware platforms. If the preamp is not present or is unlicensed, the key is not shown.
Preset	OFF
State Saved	Saved in state.
Key Path	AMPTD

Preamp Band

Sets the preamplifier band.

Remote Command	<code>[:SENSe] :POWer [:RF] :GAIN :BAND LOW FULL</code> <code>[:SENSe] :POWer [:RF] :GAIN :BAND ?</code>
Dependencies/Couplings	Preamp is not available on all hardware platforms. If the preamp is not present or is unlicensed, the key is not shown.
Preset	OFF
State Saved	Saved in state.
Key Path	AMPTD, Internal Preamp

Off

Turns the internal preamp off.

Remote Command Example	<code>:POW:GAIN OFF</code>
Key Path	AMPTD, Internal Preamp

Low Band

Sets the internal preamp to use only the low band (0–3 GHz).

Remote Command Example	<code>:POW:GAIN ON</code> <code>:POW:GAIN:BAND LOW</code>
Key Path	AMPTD, Internal Preamp

Full Range

Sets the internal preamp to use its full range. The low band (0–3) GHz is supplied by the low band preamp and the frequencies above 3.6 GHz are supplied by the high band preamp.

The instrument compensates for the preamp gain(s) as it sweeps. For the value of “Int Preamp

AMPTD Y Scale

Gain” in the Ref Levl equations, we assume a preamp gain of 20 dB in Low Band Preamp mode and 35 dB in Full Range preamp mode. These gain rules are not dependent on start and stop frequencies. These gains are the maximum gain of the preamp hardware; we will always have the same or less actual gain, providing clipping margin.

The frequency range of the installed (optional) preamp is displayed in square brackets on the key label. If the high band option is not installed the Full Range key does not appear.

Remote Command Example : POW:GAIN ON
: POW:GAIN:BAND FULL

Key Path **AMPTD, Internal Preamp**

Auto Couple

The Auto Couple feature provides a quick and convenient way to automatically couple multiple instrument settings. This helps ensure accurate measurements and optimum dynamic range. When the Auto Couple feature is activated, either from the front panel or remotely, all instrument parameters which have an Auto/Manual mode are set to Auto mode and all instrument settings dependent on (or coupled to) the Auto/Man parameters are automatically adjusted for optimal performance.

Remote Command	:COUPle ALL NONE
Remote Command Example	:COUP ALL
Remote Command Notes	:COUPle ALL puts all Auto/Man parameters in Auto mode (equivalent to pressing the Auto Couple key). :COUPLE NONE puts all Auto/Man parameters in Manual mode. It de-couples all the coupled instrument parameters and is not recommended for making measurements.

The Auto Couple front-panel key sets all Auto/Man parameter couplings in the measurement to Auto. This includes couplings that may be unavailable or grayed out due to the current state (for example, in the Swept SA measurement, there is no Auto/Man coupling for RBW while in Zero Span. Nonetheless if Auto Couple were pressed while in Zero Span it would set RBW to Auto "behind the scenes" so that on exit from Zero Span it would be in Auto).

Any Auto/Man selection specific to the other measurements in the mode won't be affected by Auto Couple. Any functions that are NOT coupled with other instrument parameters, such as ranging or leveling variables, such as "AutoRange" or "AutoScale", won't be affected by Auto Couple.

Pressing Auto Couple in the Swept SA measurement sets the Auto/Man coupling to Auto for the following parameters:

Center Frequency Step

Attenuation

Sweep Time

Detector

Resolution BW

Video BW

VBW/RBW Ratio

Average Type

Span/RBW Ratio

Phase Noise Optimization

Auto Couple

ADC Dither

Sweep Type

Swept IF Gain (MXA)

FFT IF Gain

Sweep Time Rules

Sweep Type

Sweep Type Rules

FFT Width

Pressing the Auto Couple key does not affect markers, marker functions, trace or display attributes, or any other instrument setting other than those specifically mentioned above.

BW

The BW key opens the BW menu, which contains keys to control the Resolution Bandwidth and Video Bandwidth functions of the instrument.

The Res BW functions control filter bandwidth and filter type. There are three filter types: Gaussian, Flattop, and CISPR/MIL. The Gaussian filters have a response curve that is parabolic on a log scale. The Flattop filter shape is a close approximation of a rectangular filter.

NOTE The AVERAGE functions, which appeared in the BW menu in earlier analyzers, can now be found in the Trace menu and the Meas Setup menu. In the Trace menu, you may turn Trace Averaging on or off for the desired traces (rather than globally as in the past); and in the Meas Setup menu you may configure Averaging, by setting the Average Number and the Average Type.

Key Path

Front-panel key

Res BW

Activates the **Res BW** active function, which allows you to manually set the resolution bandwidth (RBW) of the analyzer. Normally, **Res BW (Auto)** selects automatic coupling of the Res BW to **Span** using the ratio set by the Span:3 dB RBW key. To de-couple the resolution bandwidth, press Res BW until **Man** is underlined, or simply enter a different value for **Res BW**.

When the **Res BW** is manually selected, it may be returned to the coupled state by pressing the **Res BW** key until **Auto** is underlined. This may also be done by pressing Auto Couple or by performing a **Preset**.

When **Res BW** is set to **Auto**, the bandwidth selected depends on the Filter Type.

Only certain discrete resolution bandwidths are available. The available bandwidths are dependent on the **Filter Type**. If an unavailable bandwidth is entered with the numeric keypad, the closest available bandwidth is selected.

The zero-span case deserves some mention, because RBW is coupled to Span when in a swept (non-zero) span and in zero span there is normally no meaningful RBW coupling.

Remote Command

```
[ :SENSe ] :BANDwidth|BWIDth[:RESolution] <freq>
[ :SENSe ] :BANDwidth|BWIDth[:RESolution]?
[ :SENSe ] :BANDwidth|BWIDth[:RESolution]:AUTO OFF|ON|0|1
[ :SENSe ] :BANDwidth|BWIDth[:RESolution]:AUTO?
```

BW

Example	BAND 1 KHZ BAND? BWID:AUTO ON BWID:AUTO?
Dependencies/Couplings	<p>When in Zero Span, there is no Auto setting for Res BW. The Auto/Man line on the Res BW softkey disappears in this case, and if the SCPI command [:SENSe]:BWID[:RESolution]:AUTO ON is sent, it generates an error.</p> <p>Sweep time is coupled to RBW when in a non-zero span. If Sweep Time is set to Auto, then the sweep time is changed as the RBW changes, to maintain amplitude calibration.</p> <p>Video bandwidth (VBW) is normally coupled to RBW. If VBW is set to Auto, then the VBW is changed as the RBW changes, to maintain the ratio set by VBW:3 dB RBW. See the VBW:3 dB RBW key description.</p> <p>Because the above couplings depend on which traces are active, they must be re-examined whenever any trace goes active or inactive, except when this leaves no traces active. Transitioning to the state where no traces are active should not affect the couplings; in that way, the annotation will always reflect the state of the last trace which was active.</p>
Remote Command Notes	The setting and querying of values depends on the current bandwidth type.
Preset	3 MHz ON
State Saved	Saved in Instrument State
Min	1 Hz
Max	8 MHz is the max equivalent -3 dB RBW, which means that the named RBW (the one shown on the key and so forth) can actually exceed 8 MHz if using a filter other than -3 dB Gaussian.
Key Path	BW
Default Unit	Hz

Video BW

Lets you change the analyzer post-detection filter (VBW) from 1 Hz to 8 MHz in approximately 10% steps. In addition, a wide-open video filter bandwidth may be chosen by selecting 50 MHz.

Normally, Video BW (Auto) selects automatic coupling of the Video BW filter to the resolution bandwidth filter using the ratio set by the VBW:3 dB RBW key. To de-couple the video bandwidth, press Video BW until Man is underlined, or enter a new value.

When the **Video BW** is manually selected, it may be returned to the coupled state by pressing the **Video BW** key until **Auto** is underlined. This may also be done by pressing Auto Couple or by

performing a **Preset**.

Remote Command	<pre>[:SENSE] :BANDwidth BWIDth:VIDeo <freq> [:SENSE] :BANDwidth BWIDth:VIDeo? [:SENSE] :BANDwidth BWIDth:VIDeo:AUTO OFF ON 0 1 [:SENSE] :BANDwidth BWIDth:VIDeo:AUTO?</pre>
Example	<pre>BAND:VID 1 KHZ BAND:VID? BWID:VID:AUTO ON BWID:VID:AUTO?</pre>
Dependencies/Couplings	<p>In this special case the Video BW is not coupled to Res BW and is determined in a different way.</p> <p>When the Average Detector is selected and Sweep Type is set to Swept, the video bandwidth filter cannot be used, because it uses the same hardware as the Average Detector.</p>
Remote Command Notes	<p>The values shown in this table reflect the conditions after a Mode Preset.</p>
Preset	<pre>3 MHz ON</pre>
State Saved	<p>Saved in Instrument State</p>
Min	<pre>1 Hz</pre>
Max	<pre>50 HMz</pre>
Key Path	<p>BW</p>
Default Unit	<pre>Hz</pre>

VBW:3dB RBW

Selects the ratio between the video bandwidth and the equivalent 3 dB resolution bandwidth to be used for setting VBW when VBW is in Auto.

Normally, VBW:3dB RBW (Auto) selects automatic coupling of the VBW:3 dB RBW ratio to **Detector**. To de-couple the ratio, press VBW:3 dB RBW until Man is underlined, or enter a new value.

When the VBW:3dB RBW is manually selected, it may be returned to the coupled state by pressing the VBW:3 dB RBW key until **Auto** is underlined. This may also be done by pressing Auto Couple or

by performing a **Preset**.

Remote Command	[:SENSe]:BANDwidth BWIDth:VIDeo:RATio <real> [:SENSe]:BANDwidth BWIDth:VIDeo:RATio? [:SENSe]:BANDwidth BWIDth:VIDeo:RATio:AUTO OFF ON 0 1 [:SENSe]:BANDwidth BWIDth:VIDeo:RATio:AUTO?
Example	BAND:VID:RAT 2 BAND:VID:RAT? BAND:VID:RAT:AUTO 0 BAND:VID:RAT:AUTO?
Dependencies/Couplings	See Coupling Auto Rules.
Remote Command Notes	The values shown in this table reflect the conditions after a Mode Preset.
Preset	1 ON
State Saved	Saved in Instrument State
Min	0.00001
Max	3000000
Key Path	BW

Coupling Auto Rules:

The Auto Rules for the **VBW:3dB RBW** function follow.

First, we go through the following list and find the lowest numbered detector being used on any active traces (traces for which Update is On):

Peak

Normal

Average

Sample

Negative Peak

Use that detector to pick the ratio based on the following criteria:

If the detector is **Negative Peak**, use 1.0

If the detector is **Normal**, use 1.0.

If the detector is **Average**, use 0.1.

The use of a small ratio in Average detection is desirable because of its effect on the sweep time equations. The VBW filter is not actually in-circuit when the average detector is on.

Otherwise, the detector is **Peak** or **Sample**. These two detectors can use the same rules.

In these cases:

If all active traces have Averaging on, use 0.1.

This is because when doing trace averaging, reducing the VBW reduces the variance. You may have chosen the peak detector to get very accurate averaged CW measurements, and a narrow VBW helps with that.

If any active trace is in max hold or min hold, use 10.0, because Max and Min Hold operations will usually be intended to capture peaks and pits without smoothing from the VBW filter.

If any marker function is on, choose 0.1, because Marker functions are all designed for power averaging, so we will often want a narrow VBW for better repeatability.

Otherwise, use 1.0 as a compromise; because you have not set the analyzer in a way that implies that you are measuring noise, pulsed-RF or CW signals.

Because the above couplings depend on which traces are active, they are re-examined whenever any trace goes active or inactive, except when this leaves no traces active. Transitioning to the state where no traces are active should not affect the couplings; in that way, the annotation will always reflect the state of the last trace which was active.

Span:3dB RBW

Selects the ratio between span and resolution bandwidth.

Normally, Span:3dB RBW (Auto) selects a Span:3 dB RBW ratio of 106:1. If you manually enter the ratio, Man will become underlined, which enables you to manually select ratios more suitable for certain measurements.

When the Span:3dB RBW is manually selected, it may be returned to the coupled state by pressing the Span:3dB RBW key until **Auto** is underlined. This may also be done by pressing Auto Couple or by performing a **Preset**.

Remote Command

```
[ :SENSE ] :FREQuency:SPAN:BANDwidth[ :RESolution ] :RATio
<integer>

[ :SENSe ] :FREQuency:SPAN:BANDwidth[ :RESolution ] :RATio?

[ :SENSE ] :FREQuency:SPAN:BANDwidth[ :RESolution ] :RATio:A
UTO OFF|ON|0|1

[ :SENSe ] :FREQuency:SPAN:BANDwidth[ :RESolution ] :RATio:A
UTO?
```

Example

```
FREQ:SPAN:BAND:RAT 200 sets a ratio of 200:1, and turns off
the auto coupling.

FREQ:SPAN:BAND:RAT:AUTO ON

FREQ:SPAN:BAND:RAT?
```

Dependencies/Couplings

If the grayed out key is pressed, an advisory message is generated. If the equivalent SCPI command is sent, the command is acted upon, but it doesn't affect the current measurement.

BW

Remote Command Notes	The values shown in this table reflect the conditions after a Mode Preset.
Preset	106 ON
State Saved	Saved in Instrument State
Min	2
Max	10000
Key Path	BW

RBW Control

Selects the type/shape for the resolution bandwidth filters. Historically, the Res BW filters in Agilent spectrum analyzers were Gaussian filters, specified using the -3 dB bandwidth of the filter. That is, a 10 MHz Res BW filter was a Gaussian shape with its -3 dB points 10 MHz apart. In this analyzer you can, using the **Filter BW** key, specify bandwidths other than the -3 dB bandwidth (-6 dB, Noise, Impulse) for the width of the Gaussian filters. Furthermore, there are certain special filter types, such as Flat Top and CISPR/MIL, that are desirable under certain measurement conditions. These available under the **Filter Type** key.

Key Path	BW
----------	-----------

Filter Type

Besides the Gaussian filter shape, there are certain special filter types, such as Flat Top, that are desirable under certain conditions. The **Filter Type** menu gives you control over these types.

Remote Command	<code>[:SENSe] :BANDwidth BWIDth:SHAPE GAUSSian FLATtop EMI</code> <code>[:SENSe] :BANDwidth BWIDth:SHAPE?</code>
Example	<code>BAND:SHAP GAUS</code>
Dependencies/Couplings	none
Preset	Auto Couple chooses the preset value
State Saved	Saved in State
Key Path	BW, RBW Control

Gaussian filters

MXA provides four ways of specifying the bandwidth of a Gaussian filter:


The -3 dB bandwidth of the filter

The -6 dB bandwidth of the filter

The equivalent Noise bandwidth of the filter, which is defined as the bandwidth of a rectangular filter with the same peak gain which would pass the same power for noise signals.

The equivalent Impulse bandwidth of the filter, which is defined as the bandwidth of a rectangular filter with the same peak gain which would pass the same power for impulsive (narrow pulsed) signals.

The [] readback on the **RBW Control** key shows the Filter Type selection, and for the Gaussian type, the Filter BW selection, as:




The annotation at the bottom of the screen shows the filter type that is used, or for the Gaussian type, the filter bandwidth type (unless it is Normal). This will be shown parenthetically between the words “Res BW” and the value, for example

Res BW 10.0 Hz (Normal bandwidth)

Res BW (Impulse) 14.8 Hz (Impulse bandwidth)

The figure below shows the relationships of the various filter bandwidths for filters with MXA’s shape factor (shape factor is defined as the ratio of the -60 dB bandwidth to the -3 dB bandwidth):



The table below compares the above bandwidths, in terms of the -3 dB bandwidth B_3 , for filters with true Gaussian characteristics, as well as for the actual MXA swept filters, and for the MXA FFT (Kaiser-Bessel) filters:

	Ideal Gaussian	MXA Swept	MXA FFT
-6 dB BW	$1.414 * B_3$	$1.407 * B_3$	$\sim 1.404 * B_3$
Noise BW	$1.065 * B_3$	$1.058 * B_3$	$\sim 1.055 * B_3$
Impulse BW	$1.505 * B_3$	$1.479 * B_3$	n/a
Shape factor	4.472	4.1	~ 3.6

The **RBW Control** menu lets you choose the filter type, using the **Filter Type** menu, and for the Gaussian shape, the filter bandwidth (-3 dB, -6 dB, Noise or Impulse) that will be used when

specifying the width of the filter, using the **Filter BW** menu. Note that for a given Gaussian filter, changing the filter bandwidth specification does not affect the filter width at all but only the means of specifying it. For example, the filter whose -3 dB bandwidth is 1.0 kHz is the same as the filter whose -6 dB bandwidth is 1.41 kHz, whose Noise bandwidth is 1.06 kHz, and whose Impulse bandwidth is 1.48 kHz. As you cycle through these various filter bandwidths the filter does not change, but the way the filter is annotated and the value which appears in the active function area and on the softkey does.

The actual bandwidths used to realize MXA's Gaussian filters are chosen to come as close as possible to the E24 series (24 per decade) within the limitations of Boris.

Flattop filters

When the Flattop filter type is chosen, a new set of 134 RBW hardware settings are available. These settings realize filters that are approximately rectangular in shape. When this shape is chosen the filter bandwidth options are irrelevant and therefore unavailable.

The Flat Top bandwidths that we will allow will be in the range of 3.0 Hz to 8 MHz. There are three distinct regions which comprise the set of available bandwidths. The first region uses the main list of E24 bandwidths constructed to be 3.1 MHz divided by N, where N is large enough that we can find a suitable N within the E24 series of 24 settings per decade. The maximum N is 220, giving a minimum bandwidth of 3.0 Hz. Bandwidths up through 270 kHz are part of this series, giving 120 bandwidth choices. The next series is the ten choices for small N numbers, which are 300, 330, 390, 430, 510, 620 and 750 kHz and 1.0, 1.5 and 3.0 MHz. The final four choices are the 4, 5, 6 and 8 MHz choices from the Gaussian (normal) list. The 6 MHz choice is an alignment that was specially designed for its flat top characteristic in Boris. The total number of choices are thus 120 + 10 + 4, or 134 total

The [] readback on the **RBW Control** key shows the Flattop filter type selection, as:



The annotation at the bottom of the screen will show that the Flattop shape is being used, for example:

Res BW (Flattop) 10 Hz

Gaussian

Selects the Gaussian filter type. There are 160 of these RBWs. They are arranged in a 24-per-decade sequence from 1 Hz through 3 MHz, plus the 4, 5, 6 and 8 MHz settings.

Example	BAND:SHAP GAUS
Remote Command Notes	Parameter is GAUSSian.
Key Path	BW, RBW Control, Filter Type

BW

Flattop

Selects the flat top filter type.

Example	BAND:SHAP FLAT
Key Path	BW, RBW Control, Filter Type

Filter BW

When using the Gaussian filters for certain types of applications it can be useful to be able to specify the filter width using points other than the -3 dB points. The Filter BW function allows you to pick the filter based on its -3 dB (Normal) bandwidth, its -6 dB bandwidth, its Noise bandwidth, or its Impulse bandwidth. In all four cases the -3 dB bandwidth is the same. The filter does not change, but the way you specify it changes.

Remote Command	<code>[:SENSe] :BANDwidth BWIDth :TYPE DB3 DB6 IMPulse NOISe</code> <code>[:SENSe] :BANDwidth BWIDth :TYPE?</code>
-----------------------	---

Example BAND:TYPE NOIS

Dependencies/Couplings Grayed out unless the Gaussian filter type is selected. Benign 0.1002

Because the above couplings depend on which traces are active, they must be re-examined whenever any trace goes active or inactive, except when this leaves no traces active. Transitioning to the state where no traces are active should not affect the couplings; in that way, the annotation will always reflect the state of the last trace which was active.

Preset	Auto Couple chooses the preset value
State Saved	Saved in State
Key Path	BW, RBW Control

-3 dB (Normal)

Selects the normal gaussian-shaped bandwidths that are defined by their -3 dB bandwidths.

Example	BAND:TYPE DB3
Key Path	BW, RBW Control, Filter BW

-6 dB

Selects the filter bandwidths where the bandwidth is defined at the -6 dB points. This uses the normal RBW filters, but the value displayed on the key, active function line and screen annotation changes to reflect the -6 dB bandwidth instead of the -3 dB bandwidth.

Example	BAND:TYPE DB6
Key Path	BW, RBW Control, Filter BW

Noise

Selects the noise filter bandwidths. This uses the normal RBW filters, but the value displayed on the key, active function line and screen annotation changes to reflect the equivalent noise bandwidth, instead of the -3 dB bandwidth.

Example	BAND:TYPE NOIS
Key Path	BW, RBW Control, Filter BW

Impulse

Selects the impulse bandwidths. This uses the normal RBW filters, but the value displayed on the key, active function line and screen annotation changes to reflect the equivalent impulse bandwidth instead of the -3 dB bandwidth.

Example	BAND:TYPE IMP
Key Path	BW, RBW Control, Filter BW

FREQ Channel

Pressing this key allows you to select frequency or Channel Number settings, depending on the measurement.

Key Path	Front panel key
----------	-----------------

Center Freq

Specify the frequency that an analyzer acquires the IQ waveform.

Mode	BASIC
Remote Command	<code>[:SENSe] :FREQuency:CENTer <freq></code> <code>[:SENSe] :FREQuency:CENTer?</code>
Remote Command Notes	This command is the same in all modes, but the parameter is Measurement Global. So the value is independent in each mode and common across all the measurements in the mode.
Preset	1.0 GHz
State Saved	Saved in instrument state.
Min	-79.999995 MHz
Max	Hardware Dependent: Opt503 = 3.699999995 GHz Opt508 = 8.499999995 GHz Opt513 = 13.799999995 GHz Opt526 = 26.999999995 GHz
Key Path	Frequency/Channel

Input/Output

The Input/Output key opens up a menu of softkeys that allow you to control the Input/Output parameters of the instrument. Input choices include the RF input and the Amplitude Reference (50 MHz, 4.8 GHz or 300 MHz comb signal). You can also specify the input impedance for unit conversions.

Other functions related to the input/output connections can be found under Trig (trigger input controls) and System (LAN and other I/O bus configurations) and Amplitude (optional internal preamp).

NOTE The functions in the Input/Output menu are common to all Modes (applications). They are Mode global. But individual functions are only available in a mode if they makes sense. These will be grayed out (as opposed to not showing them at all). This is a special behavior of the Input/Output Menu, which is the only menu that is common across all applications.

Remote Command	<code>[:SENSE] :FEED RF IQ EXTMixer AREference</code> <code>[:SENSE] :FEED?</code>
Preset	This setting is unaffected by a Preset or power cycle. It survives Mode Preset and mode changes. It is set to RF on a “Restore Input/Output Defaults” or “Restore System Defaults->All”
State Saved	Saved in state

Input/Output variables - Preset behavior

Virtually all the input/output settings are NOT a part of mode preset. They can be set to their default value by one of the three ways - by using the Restore Input/Output Defaults key on the first page of the input/output menu, by using the System->Restore System Defaults->Input/Output Settings or by using the System -> Restore System Defaults->All. Also, they survive Preset and Power cycle.

A very few of the Input/Output settings do respond to a Mode Preset; for example, if the Calibrator is on it turns off on a Preset, and if DC coupling is in effect it switches to AC on a Preset. These exceptions are made in the interest of reliability and usability, which overrides the need for absolute consistency. Exceptions are noted in the SCPI table for the excepted functions.

RF Input

Selects the front panel RF input port to be the analyzer signal input. If RF is already selected, pressing this key accesses the RF input setup functions.

Example `[:SENSE] :FEED RF`

Key Path **Input/Output**

Input Z Correction

Sets the input impedance for unit conversions. This affects the results when the y axis unit is voltage or current units (dBmV, dBµV, dBµA, V, A) but not when it is power units (dBm, W). The impedance you select is for computational purposes only, since the actual impedance is set by internal hardware to 50 ohms. Setting the computational input impedance to 75 ohms is useful when using a 75 ohm to 50 ohm adapter to measure a 75 ohm device on an analyzer with 50 ohm input impedance.

There are a variety of ways to make 50 to 75 ohm transitions, such as impedance transformers or minimum loss pads. The choice of the solution that is best for your measurement situation requires balancing the amount of loss that you can tolerate with the amount of measurement frequency range that you need. If you are using one of these pads/adaptors with the Input Z Corr function, you might also want to use the Ext Gain key. This function is used to set a correction value to compensate for the gain (loss) through your pad. This correction factor is applied to the displayed measurement values.

Remote Command `[:SENSe] :CORRection:IMPedance [:INPut] [:MAGNitude] 50 | 75`
`[:SENSe] :CORRection:IMPedance [:INPut] [:MAGNitude] ?`

Example `CORR:IMP 75` sets the input impedance correction to 75 ohms.
`CORR:IMP?`

Preset This is unaffected by Preset but is set to 50 Ω on a “Restore Input/Output Defaults” or “Restore System Defaults->All”
 Some instruments/options may have 75 Ω available.

State Saved Saved in State

Key Path **Input/Output, RF**

RF Coupling

Specifies alternating current (AC) or direct current (DC) coupling at the analyzer RF input port. Selecting AC coupling switches in a blocking capacitor that blocks any DC voltage present at the analyzer input. This decreases the input frequency range of the analyzer, but prevents damage to the input circuitry of the analyzer if there is a DC voltage present at the RF input.

In AC coupling mode, you can view signals less than 10 MHz but the amplitude accuracy is not specified. To accurately see a signal of less than 10 MHz, you must switch to DC coupling.

Some amplitude specifications apply only when coupling is set to DC. Refer to the appropriate amplitude specifications and characteristics for your analyzer.

This key is not available for MXA instruments with options 544 and 550 (44 & 50 GHz). The coupling is always DC.

When operating in DC coupled mode, ensure protection of the External Mixer by limiting the DC part of the input level to within 200 mV of 0 Vdc. In AC or DC coupling, limit the input RF power to +30 dBm (1 Watt).

Selecting Input Coupling

N6020A Option	AC Frequency Range	DC Frequency Range
Option 503	10 MHz to 3.6 GHz	3 Hz to 3.6 GHz
Option 508	10 MHz to 8.4 GHz	3 Hz to 8.4 GHz
Option 513	10 MHz to 13.6 GHz	3 Hz to 13.6 GHz
Option 526	10 MHz to 26.5 GHz	3 Hz to 26.5 GHz

This function presets to AC on a Mode Preset.

Remote Command	:INPut:COUPling AC DC :INPut:COUPling?
Example	INP:COUP DC
Dependencies/Couplings	Not available on 44 GHz or 50 GHz analyzers (Options 544 and 550). Grayed out when External Mixer is selected
Remote Command Notes	In instruments with options 544 and 550, the SCPI query INP:COUP? Always returns a DC
Preset	AC
State Saved	Saved in State
Key Path	Input/Output, RF

RF Calibrator

Lets you choose a calibrator signal to look at or turns the calibrator “off” (meaning switches back to the selected input). If one of the three calibrator signals (50 MHz, –25 dBm, the 4.8GHz internal amplitude reference or the 300 MHz comb signal) is chosen (as opposed to OFF), the analyzer routes the selected internal amplitude reference as the input signal, while leaving the input selection in the menus (RF, Ext Mix or I/Q) unchanged.

The 50 MHz internal reference and the 300 MHz comb signal are available with all the frequency options, that is 503, 508, 513, 526. The 4.8 GHz internal reference is only available with 508, 513, 526.

This function presets to OFF on a Mode Preset, which causes the internal circuitry to switch back to the selected input (RF, Ext Mix or I/Q).

Remote Command	[:SENSE] :FEED:AREference REF50 REF4800 COMB OFF [:SENSE] :FEED:AREference?
-----------------------	--

Input/Output

Example	<p>FEED:AREF REF50 selects the 50 MHz amplitude reference as the signal input.</p> <p>FEED:AREF REF4800 selects the 4.8 GHz amplitude reference as the signal input</p> <p>FEED:AREF COMB selects the 300 MHz comb modulated signal as the signal input</p> <p>FEED:AREF OFF turns the calibrator Off (meaning it switches back to the selected input – RF, ExtMix or I/Q)</p>
Dependencies/Couplings	Selecting an input (RF, Ext Mix or I/Q) turns the Calibrator OFF. This is true whether the input is selected by the softkeys or with the [:SENSe]:FEED command.
Preset	OFF
State Saved	Saved in State
Key Path	Input/Output

50 MHz

Selects the 50 MHz internal reference as the input signal. This choice is available in all options: 503, 508, 513, 526.

Key Path **Input/Output, RF Calibrator**

4.8 GHz

Selects the 4.8GHz internal reference as the input signal.

Key Path **Input/Output, Amptd Ref**

Comb

Selects the 300 MHz comb modulated signal as the input signal. This choice is available in all options: 503, 508, 513, 526

Key Path **Input/Output, RF Calibrator**

Off

Switches the input back to the selected input (RF, Ext Mix or I/Q)

Key Path **Input/Output, RF Calibrator**

External Gain

Compensates for gain/loss in the measurement system outside the spectrum analyzer. The External Gain is subtracted from the amplitude readout (or the loss is added to the amplitude readout). So, the displayed signal level represents the signal level at the output of the device-under-test, which

can be the input of an external device that provides gain/loss.

Entering an External Gain value does not affect the Reference Level, therefore the trace position on screen changes, as do all of values represented by the trace data. Thus, the values of exported trace data, queried trace data, marker amplitudes, trace data used in calculations such as N dB points, trace math, peak threshold, and so forth, are all affected by External Gain. Changing the External Gain, even on a trace which is not updating, will immediately change all of the above, without new data needing to be taken.

NOTE Changing the External Gain causes the analyzer to immediately stop the current sweep and prepare to begin a new sweep, but the data will not change until the trace data updates, because the offset is applied to the data as it is taken. If a trace is exported with a nonzero External Gain, the exported data will contain the trace data with the offset applied.

In the Spectrum Analyzer mode, a Preamp is the common external device providing gain/loss. In a measurement application mode like GSM or W-CDMA, the gain/loss could be from a BTS (Base Transceiver Station) or a MS (Mobile Station). So in the Spectrum Analyzer mode MS and BTS would be grayed out and the only choice would be Ext Preamp. Similarly in the communications applications, Ext Preamp will be grayed out and you would have a choice of MS or BTS.

Dependencies/Couplings The Ext Preamp, MS and BS keys may be grayed out depending on which measurement is currently selected. If any of the grayed out keys are pressed, or the equivalent SCPI command is sent, an advisory message is generated.

Key Path **Input/Output**

Ext Preamp

This function is similar to the reference level offset function. Both affect the displayed signal level. Ref Lvl Offset is a mathematical offset only, no analyzer configuration is affected. Ext Preamp gain is used when determining the auto-coupled value of the Attenuator. The External Gain value and the Maximum Mixer Level settings are both part of the automatic setting equation for the RF attenuation setting. (10 dB of Attenuation is added for every 10 dB of External Gain.)

The Ref Lvl Offset and Maximum Mixer Level are described in the Amplitude section. They are reset by the instrument Preset. The External Preamp Gain is reset by the “Restore Input/Output Defaults” or “Restore System Defaults->All functions. The External Gain is subtracted from the amplitude readout so that the displayed signal level represents the signal level at the output of the device-under-test, which is the input of the external device that is providing gain/loss.

Remote Command [:SENSe]:CORREction:SA[:RF]:GAIN <rel_amp>
[:SENSe]:CORREction:SA[:RF]:GAIN?

Example CORR:SA:GAIN 10 sets the Ext Gain value to 10 dB
CORR:SA:GAIN -10 sets the Ext Gain value to -10 dB (that is, an attenuation of 10 dB)

Input/Output

Dependencies/Couplings	The reference level limits are determined in part by the External Gain/Atten, Max Mixer Level, RF Atten. This key is grayed out in many application Modes.
Preset	This is unaffected by Preset but is set to 0 dB on a “Restore Input/Output Defaults” or “Restore System Defaults->All”
State Saved	Saved in State
Min	-81.90 dB
Max	81.90 dB
Key Path	Input/Output, Ext Gain

MS

Sets an external gain/attenuation value for MS (Mobile Station) tests.

Remote Command	<code>[:SENSe] :CORRection:MS[:RF]:GAIN <rel_ampl></code> <code>[:SENSe] :CORRection:MS[:RF]:GAIN?</code>
Example	<code>CORR:MS:GAIN 10</code> sets the Ext Gain value to 10 dB <code>CORR:MS:GAIN -10</code> sets the Ext Gain value to -10 dB (i.e. a loss of 10 dB)
Dependencies/Couplings	The reference level limits are determined in part by the External Gain, Max Mixer Level, RF Atten This key is grayed out in the SA Mode.
Preset	This is unaffected by Preset but is set to 0 dB on a “Restore Input/Output Defaults” or “Restore System Defaults->All”
State Saved	Saved in State
Min	-50 dB
Max	50 dB
Key Path	Input/Output, Ext Gain

BTS

Sets an external attenuation value for BTS (Base Transceiver Station) tests.

Remote Command	<code>[:SENSe] :CORRection:BTS[:RF]:GAIN <rel_ampl></code> <code>[:SENSe] :CORRection:BTS[:RF]:GAIN?</code>
Example	<code>CORR:BTS:GAIN 10</code> sets the Ext Gain value to 10 dB <code>CORR:BTS:GAIN -10</code> sets the Ext Gain value to -10 dB (i.e. a loss of 10 dB)

Dependencies/Couplings	The reference level limits are determined in part by the External Gain, Max Mixer Level, RF Atten This key is grayed out in the SA Mode.
Preset	This is unaffected by Preset but is set to 0 dB on a “Restore Input/Output Defaults” or “Restore System Defaults->All”
State Saved	Saved in State
Min	-50 dB
Max	50 dB
Key Path	Input/Output, Ext Gain

Restore Input/Output Defaults

This selection causes the group of settings and data associated with Input/Output key to be a reset to their default values. This level of Restore System Defaults does not affect any other system settings or mode settings and does not cause a mode switch. All the features described in this section are reset using this key.

Example	:SYST:DEF INP presets all the Input/Output variables to their factory default values.
Key Path	Input/Output

Current Meas -> Capture Buffer

Pressing this key stores the raw data of one measurement in the internal memory of the instrument where it can then be used by a different measurement by pressing “Stored Data”. When raw data is stored, then the data source selection switch automatically changes to “Stored Data”. Stored raw data cannot be directly accessed. There is no save/recall function to save the raw data in an external media. However if you want to get the stored raw data, you must first perform a measurement using the stored raw data. Now you can access the used raw data, which is the same as stored raw data via the FETCh or READ commands.

Remote Command	[:SENSe] :FEED:DATA:STORe
Example	:SENSe:FEED:DATA:STOR stores recorded data
Remote Command Notes	This is command only, there is no query
Key Path	Input/Output, Data Source

Freq Ref In

Specifies the frequency reference as being the internal reference, external reference or sensing the presence of an external reference.

When the frequency reference is set to internal, the internal 10 MHz reference is used even if an external reference is connected.

Input/Output

When the frequency reference is set to external, the instrument will use the external reference. However, if there is no external signal present, or it is not within the proper amplitude range, an error condition detected message is generated. When the external signal becomes valid, the error is cleared.

If Sense is selected, the instrument checks whether a signal is present at the external reference connector and will automatically switch to the external reference when a signal is detected. When no signal is present, it automatically switches to the internal reference. No message is generated as the reference switches between external and internal. The monitoring of the external reference occurs approximately on 1 millisecond intervals, and never occurs in the middle of a measurement acquisition, only at the end of the measurement.

If for any reason the instrument's frequency reference is not able to obtain lock, Status bit 2 in the Questionable Frequency register will be true and an error condition detected message is generated. When lock is regained, Status bit 2 in the Questionable Frequency register will be cleared and an error message is cleared will be sent.

If an external frequency reference is being used, you must enter the frequency of the external reference if it is not exactly 10 MHz. The **External Ref Freq** key is provided for this purpose.

Remote Command	<code>[:SENSe]:ROSCillator:SOURce:TYPE</code> <code>INTernal EXTernal SENSe</code> <code>[:SENSe]:ROSCillator:SOURce:TYPE?</code>
Preset	This is unaffected by Preset but is set to SENSE on a "Restore Input/Output Defaults" or "Restore System Defaults->All".
State Saved	Saved in State.
Key Path	Input/Output
SCPI Status Bits/OPC Dependencies	STATus:QUEStionable:FREQuency bit 2 set if unlocked.
Remote Command	<code>[:SENSe]:ROSCillator:SOURce?</code>
Remote Command Notes	The query <code>[SENSe]:ROSCillator:SOURce?</code> returns the current switch setting. This means: If it was set to SENSE but there is no external reference so the instrument is actually using the internal reference, then this query returns INTernal and not SENSE. If it was set to SENSE and there is an external reference present, the query returns EXTernal and not SENSE. If it was set to EXTernal, then the query returns "EXTernal" If it was set to INTernal, then the query returns INTernal
Preset	SENSe

Sense

The external reference is used if a valid signal is sensed at the Ext Ref input. Otherwise the internal reference is used.

Remote Command Example :ROSC:SOUR:TYPE SENS

Key Path Input/Output, Freq Ref In

Internal

The internal reference is used.

Remote Command Example :ROSC:SOUR:TYPE INT

Key Path Input/Output, Freq Ref In

External

The external reference is used.

Example :ROSC:SOUR:TYPE EXT

Key Path Input/Output, Freq Ref In

Ext Ref Freq

This key tells the analyzer the frequency of the external reference. When the external reference is in use (either because the reference has been switched to External or because the Reference has been switched to Sense and there is a valid external reference present). This information is used by the analyzer to determine the internal settings needed to lock to that particular external reference signal.

For the instrument to stay locked, the value entered must be within 5 ppm of the actual ext ref frequency. So it is important to get it close, or you risk an unlock condition.

This value only affects the instrument's ability to lock. It does not affect any calculations or measurement results. See "Freq Offset" in the Frequency section for information on how to offset frequency values.

Remote Command [:SENSe]:ROSCillator:EXTernal:FREQuency <freq>

[:SENSe]:ROSCillator:EXTernal:FREQuency?

Example ROSC:EXT:FREQ 20 MHz sets the external reference frequency to 20 MHz, but does not select the external reference.

ROSC:SOUR:TYPE EXT selects the external reference.

Preset This is unaffected by Preset but is set to 10 MHz on a "Restore Input/Output Defaults" or "Restore System Defaults->All"

Min 1 MHz

Max 50 MHz

Input/Output

Key Path	Input/Output, Freq Ref In
Default Unit	Hz

Output Config

Accesses keys that configure various output settings, like the frequency reference output, trigger output and analog output.

Trig 1 Out

Selects the type of output signal that will be output from the rear panel Trig 1 Out connector.

Remote Command	:TRIGger TRIGger1 TRIGger2[:SEQuence]:OUTPut HSWP MEASuring MAIN GATE GTRigger OEVEN SUVideo SPOint SPATtern PROGrammable OFF :TRIGger TRIGger1 TRIGger2[:SEQuence]:OUTPut?
Example	TRIG:OUTP HSWP
Preset	This is unaffected by Preset but is set to HSWP on a “Restore Input/Output Defaults” or “Restore System Defaults->All”
State Saved	Saved in instrument state
Key Path	Input/Output, Output Config

Polarity

Sets the output to the Trig 1 Out connector to trigger on either the positive or negative polarity.

Remote Command	:TRIGger TRIGger1 TRIGger2[:SEQuence]:OUTPut:POLarity POSitive NEGative :TRIGger TRIGger1 TRIGger2[:SEQuence]:OUTPut:POLarity?
Example	TRIG1:OUTP:POL POS
Preset	This is unaffected by Preset but is set to POSitive on a “Restore Input/Output Defaults” or “Restore System Defaults->All”
State Saved	Saved in state
Key Path	Input/Output, Output Config, Trig 1 Output

Sweeping (HSWP)

Selects the Sweeping trigger signal to be output to the Trig 1 Out connector. This signal has historically been known as “HSWP” but care should be taken to understand that in MXA, its function does not exactly match legacy behavior.

Example	TRIG1:OUTP HSWP
Key Path	Input/Output, Output Config, Trig 1 Output

Measuring

Selects the Measuring trigger signal to be output to the Trig 1 Out connector. This signal is true while the Measuring status bit is true.

Example	TRIG1:OUTP MEAS
Key Path	Input/Output, Output Config, Trig 1 Output

Main Trigger

Selects the current instrument trigger signal to be output to the Trig 1 Out connector.

Example	TRIG1:OUTP MAIN
Key Path	Input/Output, Output Config, Trig 1 Output

Odd/Even Trace Point

Selects either the odd or even trace points as the signal to be output to the Trig 1 Out connector when performing swept spectrum analysis. When the polarity is positive, this output goes high during the time the analyzer is sweeping past the first point (Point 0) and every other following trace point. The opposite is true if the polarity is negative.

Example	TRIG1:OUTP OEV
Key Path	Input/Output, Output Config, Trig 1 Output

Off

Selects no signal to be output to the Trig 1 Out connector.

Example	TRIG1:OUTP OFF
Key Path	Input/Output, Output Config, Trig 1 Output

Trig 2 Out

See [Trig 1 Out](#).

Off

Turns off the analog output.

Example	OUTP:ANAL:SA:OUTP OFF
Key Path	Input/Output, Output Config, Analog Outputs

Screen Video

Selects the analog output to be the screen video signal. That is, what you see on the screen is what

Input/Output

you get at the output. This depends on the Log/Lin display Scale, Reference Level and dB per division.

Example	OUTP:ANAL:SA:OUTP SVID
Key Path	Input/Output, Output Config, Analog Outputs

Log Video (Log Envelope)

Selects the analog output to be the log of the video signal.

A “log video” signal has a slope and an offset. This output has the slope and the offset required by the analyzer to do the required analysis. That way, the rear panel output does not interfere with instrument operation. The full scale range of the output is about 192 dB. The offset is independent of the reference level and depends only on the input attenuation. Digital corrections for flatness are not be present in this output.

Example	OUTP:ANAL:SA:CHAN1:OUTP LVID
Key Path	Input/Output, Output Config, Analog Outputs

Envelope (AM Demod, Lin)

Selects the analog output to be the envelope signal on a linear (voltage) scale. The scaling is set so that 1 V output occurs with an instantaneous video level equal to the reference level. This gives you the ability to control the gain without having another setup control for the key. But it requires you to control the look of the display (the reference level) in order to control the analog output.

Example	OUTP:ANAL:SA:OUTP ENV
Key Path	Input/Output, Output Config, Analog Outputs

Span

The Span key activates the Span function and displays the menu of span functions.

Span

Changes the displayed frequency range symmetrically about the center frequency. While adjusting the Span the Center Frequency is held constant, which means that both Start Frequency and Stop Frequency will change.

Span also sets the frequency entry mode to Center/Span. In Center/Span mode, the center frequency and span values are displayed below the graticule, and the default active function in the Frequency menu is **Center Freq**.

While discussing the Span function we make the distinction between “swept spans” and “zero span”. We use the term “swept spans” to mean spans other than zero; recognizing that, because of this terminology, the user can be in what we call a “swept span” even while performing an FFT “sweep”.

While in swept spans, setting the span to 0 Hz through SCPI or the front panel numeric key pad puts the analyzer into zero span. However, using the Step keys and the knob in swept spans, the Span can only go as far down as 10 Hz and cannot be set to zero.

While in zero span, setting the Span to a non-zero value through SCPI or the Front Panel puts the analyzer in swept spans.

If the Span is set to a value greater than the maximum allowable span of the instrument, an error is generated indicating the data is out of range and was clipped to the upper limit.

Remote Command [:SENSE] :FREQUENCY:SPAN <freq>
 [:SENSE] :FREQUENCY:SPAN?

Example FREQ:SPAN 2GHz sets the span to 2GHz
 FREQ:SPAN 0 Hz sets the span to 0 Hz and puts the instrument
 in Zero Span

Span

Dependencies/Couplings	<p>Start, Stop, Center and Span have interdependencies. These must be strictly enforced when any of these four values is modified.</p> <p>The Span can be limited by Start or Stop Freq limits, if the Center Frequency is such that Start or Stop hit their limit. If the electrical attenuator is enabled, any attempt to set Span such that the Stop Frequency would be >3.6GHz results in an error. If the key is pressed, an advisory message is generated. If the equivalent SCPI command is sent, this same message is generated as part of a “-221, Settings conflict” warning.</p> <p>Span affects RBW, sweep time, FFT and Sweep choice (including FFT Width, Phase Noise Optimization and ADC Dither auto couplings.)</p> <p>When operating in “swept span”:</p> <ul style="list-style-type: none">• Any value of the Center Frequency or Span that is within the frequency range of the analyzer is allowed when the value is being set through the front panel numeric key pad or the SCPI command. The other parameter is forced to a different value if needed, to keep the Start and the Stop Frequencies within the analyzer’s frequency range• When using the knob or the step up/down keys or the UP DOWN keywords in SCPI, the value that is being changed, for example, the Center Frequency or Span, is limited so that the other parameter is not forced to a new value <p>The Span cannot be set to Zero by setting Start Frequency = Stop Frequency. The value of the last setting will be changed to maintain a minimum value of 10 Hz for the difference between start and stop frequencies.</p>
Remote Command Notes	Preset and Max values depend on the Hardware Options (503, 508, 513, 526)
Preset	SA Mode: Option 503: 3.59 GHz Option 508: 8.39 GHz Option 513: 13.59 GHz Option 526: 26.49 GHz
Preset	Depends on instrument maximum frequency
State Saved	Saved in State.
Min	10 Hz unless entered directly, then 0 Hz is allowed, but nothing between 0 and 10 is ever allowed.

Max	Option 503: 3.6 GHz Option 508: 8.4 GHz Option 513: 13.6 GHz Option 526: 26.5 GHz If the knob or step keys are being used, depends on the value of the other three interdependent parameters.
Key Path	Span/XScale
Default Unit	Hz
SCPI Status Bits/OPC Dependencies	Overlapped if Signal Track is on (OPC shouldn't return or clear until the zooming has completed for the new span)

Full Span

Changes the frequency span of the analyzer to the Preset frequency span of the analyzer and sets the Frequency entry mode to Center/Span.

The span is dependent on the currently selected Input (see Input/Output section).

Pressing this key while in zero span puts the analyzer back in swept span.

Remote Command	[:SENSe] :FREQUency :SPAN :FULL
Example	FREQ:SPAN:FULL sets the span to full frequency range of the analyzer
Dependencies/Couplings	Turns off signal tracking (span zoom). It does NOT turn off the markers, nor the current active function.
Key Path	Span/XScale

Zero Span

Changes the displayed frequency span to 0 Hz. The horizontal axis changes to time rather than frequency. The amplitude displayed is the input signal level at the current center frequency. This is a time-domain operation mode that changes several measurement functions/couplings. The instrument behavior is similar to an oscilloscope with a frequency selective detector installed in front of the oscilloscope.

Press the Zero Span key in Span

Set Span=0 Hz

Press last Span if the last span was 0

Start the Alternate Sweep measurement in a view that includes zero span.

You cannot go to Zero Span by setting start freq = stop freq, or rolling span down with the knob, that will limit you to 10 Hz

You can go back to Swept Span by setting Span to a nonzero value or pressing Last Span, assuming

Span

the last span was not also zero span.

Pressing Zero Span places the analyzer in Center/Span frequency entry mode.

The following table summarizes the differences between Zero Span and Swept Spans:

Zero Span	Swept SA.
X axis is time	X axis is frequency.
There is no auto-RBW selection.	RBW coupled to Span when RBW in auto.
There is no auto sweep time	Sweep time coupled to RBW when sweep time in auto.
Interval Power calculated in Mkr Function	Band Power calculated in Mkr Function.
Can only define time limits when in zero span	Can only define frequency limits when in swept SA.
Marker Count counts at the center frequency	Marker Count counts at the marker frequency.
CF Step Size set to RBW value	CF Step auto-couples to 10% of Span.
Some “Marker ->” commands not available.	Other “Marker ->” commands not available.
Freq entry mode always Center/Span	Freq entry mode can be Center/Span or Start/Stop.
N dB points reports a time difference.	N dB points reports a frequency difference.
Example	FREQ:SPAN 0 Hz sets the span to zero, switches to Zero Span. Sending FREQ:SPAN 1 MHz while in Zero Span, switches to Swept span.
Dependencies/Couplings	Zero Span key is unavailable (grayed out) if the following is true: Frequency scale type is LOG (for example, Log Sweep is On). Pressing Zero Span key (switching to Zero Span): Turns off signal track function (span zoom). Turns off the auto-coupling of RBW and sweep time.
Remote Command Notes	Setting the Span to 0 Hz will change to Zero Span and setting the span to a non-zero value will select a swept span.
Key Path	Span/XScale

Last Span

Changes the displayed frequency span to the previous span setting. If it is pressed immediately after Signal Track is turned off, then the span setting returns to the span that was in effect before Signal Track was turned on.

If this key is pressed while in a nonzero span, and the previous value of span was 0, it will put the analyzer back in Zero Span. And if it is pressed while in zero span, it will set the analyzer back to its last nonzero span.

Pressing Last Span places the analyzer in Center/Span frequency entry mode.

Remote Command	<code>[:SENSe] :FREQuency:SPAN:PREVious</code>
Example	FREQ:SPAN:PREV sets the span to the previous value
Key Path	Span/XScale

Zone On/Off

Turning Zone ON will put the analyzer in the dual domain “Zone Span” view. If you are in Zone Span, turning Zone Off will put the analyzer in Swept or Zero Span depending on whether the bottom window is Swept or Zero Span.

In Zone Span the top window will display the trace with two vertical lines (Zone Markers) displayed at center frequency plus and minus 5% of the current span. (You can change the default zone frequency and zone span values using the Zone Center and Zone Span keys.) The top window will be inactive.

The bottom window will display the section of the trace in the top window that is between the Zone Markers. The span of the bottom window is 10% of the span of the top window. (You can change the default zone frequency and zone span values using the Zone Center and Zone Span keys.) When first activated, both windows have the same center frequency. The bottom window is active and the sweep time, resolution bandwidth, and video bandwidth have been coupled to the bottom window span.

There are separate annotations for frequency, res bandwidth, video bandwidth, sweep time, reference level, amplitude scale and scale/div for each window. The values for these parameters can be changed for each window independently.

To activate the top window, press the Next Window key located below the display. The active window is distinguished by a green border. Only the active window will have a sweep taken and updated to the display. When the active window is toggled, the state for the active window is saved, and the last state of the inactive window is recalled. When the window becomes inactive, its data invalid indicator will appear on the display. The data invalid indicator will remain until the window becomes the active window and a complete sweep has been executed.

Pressing Zoom will change to a one-window display showing only the active window. Pressing Zoom again will return you to the two-window display. (Pressing Zoom will set Zone (On), if it is off.)

Pressing Zone (Off) will return you to a one-window display of the active window.

Preset	Off
--------	-----

Span

State Saved	Saved in State
Key Path	Span/XScale, Zone

Zone Center

Allows you to change the frequency of the zone markers without changing the zone span. The zone markers are vertical lines marking the zone in the upper window. They determine the frequency range displayed in the lower window. As the zone markers in the upper window are moved, the center frequency of the lower window is changed but the lower window will not be updated to reflect the change unless it is selected as the active window. (See Zone On Off.) The center frequency for the lower window is not limited by the selected start and stop frequencies in the upper window. However, if the frequency span of the lower window is outside of the span for the upper window, the vertical span markers will be displayed at the edge of the graticule. When the lower window is active, the **FREQ Channel** key will allow you to change Zone Center. Any change to the lower window while it is active will change the center frequency.

Unless Zone is on, only the Zone On/Off key is available and the rest of the Zone menu is grayed out.

Dependencies/Couplings	Unavailable (grayed out) when segmented sweep is on. Center Frequency of lower window changes so that it is always the same as Zone Center, and vice-versa.
Remote Command Notes	Min and Max values depend on the Hardware Options (503, 508, 513, 526)
Preset	1.5 GHz
State Saved	Saved in State
Min	Zone Center cannot go so low as to force Zone Left to be <0
Max	Zone Center can not go so high as to force Zone Right above the max freq of the instrument
Key Path	Span/XScale, Zone
Default Unit	Hz
SCPI Status Bits/OPC Dependencies	non-overlapped

Zone Span

Allows the span of the zone markers to be changed without changing the center frequency. The zone markers are vertical lines marking the zone in the upper window. They determine the frequency range displayed in the lower window. As the zone markers are moved, the span of the lower window is changed but the lower window will not be updated to reflect the change unless it is selected as the active window. (See Zone On Off.) The span limit of the lower window is the same as the span limit of the analyzer. The span for the lower window is not limited to the selected span of the upper window. However, if the frequency span of the lower window is outside of the span of the upper window, the vertical span markers will not be displayed. When the lower window is active, the **SPAN X Scale** key will change Zone Span, and any change to Zone Span while the lower window is

active, will change the span.

Unless Zone is on, only the Zone On/Off key is available and the rest of the Zone menu is grayed out.

Dependencies/Couplings	Unavailable (grayed out) when segmented sweep is on. Span of lower window changes so that it is always the same as Zone Span, and vice-versa
Remote Command Notes	Min and Max values depend on the Hardware Options (503, 508, 513, 526)
Preset	2 GHz
State Saved	Saved in State
Min	Zone Span cannot go so low as to force Zone Left to be <0
Max	Zone Span can not go so high as to force Zone Right above the max freq of the instrument
Key Path	Span/XScale, Zone
Default Unit	Hz
SCPI Status Bits/OPC Dependencies	non-overlapped
SCPI Status Bits/OPC Dependencies	Overlapped if Signal Track is on (OPC shouldn't return or clear until the zooming has completed for the new span)

Zone Pk Right

Finds the next peak to the right of the zone center frequency on the upper window trace and then moves the zone so that it is centered around the new peak. The zone span is not changed. The center frequency of the lower window changes to reflect the new zone center frequency. The lower window will not be updated until it is made active. If no peak is found, the zone will not be moved. A signal must obey the parameters defined in Search, Search Param to be identified as a peak signal. Pressing Zone Pk Right will have no effect if the upper window is not the active window or if it is in zero span.

Unless Zone is on, only the Zone On/Off key is available and the rest of the Zone menu is grayed out.

Remote Command	:CALCulate:ZONE:MAXimum:RIGHT
Example	CALC:ZONE:MAX:RIGH
State Saved	Not part of saved state
Key Path	Span/XScale, Zone

Zone Pk Left

Finds the next peak to the left of the zone center frequency on the upper window trace and then

Span

moves the zone so that it is centered around the new peak. The zone span is not changed. The center frequency of the lower window changes to reflect the new zone center frequency. The lower window will not be updated until it is made active. If no peak is found, the zone will not be moved. A signal must obey the parameters defined in Search, Search Param to be identified as a peak signal. Pressing Zone Pk Left will have no effect if the upper window is not the active window or if it is in zero span.

Unless Zone is on, only the Zone On/Off key is available and the rest of the Zone menu is grayed out.

Remote Command :CALCulate:ZONE:MAXimum:LEFT

Example CALC:ZONE:MAX:LEFT

State Saved Not part of saved state

Key Path **Span/XScale, Zone**

Signal Track (Span Zoom)

When Marker 1 is placed on a signal and Signal Track is pressed, the marker remains on the signal while the analyzer retunes the center frequency to the marker frequency. The analyzer keeps the signal at the center of the display, as long as the amplitude of the signal does not change by more than ± 3 dB from one sweep to another. If Marker 1 is not in Normal or Delta, turning on Signal Track sets it to Normal, performs a peak search, and centers the marker on the display.

Remote Command :CALCulate:MARKer:TRCKing[:STATE] OFF|ON|0|1

:CALCulate:MARKer:TRCKing[:STATE] ?

Example CALC:MARK:TRCK ON turns on Signal Track using Marker 1.

CALC:MARK:TRCK?.

Dependencies/Couplings	<p>Signal Track is associated with Marker 1. When marker 1 is turned off or set to Fixed, signal track is turned off as well.</p> <p>Signal Track is not available (grayed out) when any of the following is true: Signal ID = on, Frequency scale type = Log</p> <p>Signal Track and Continuous Pk cannot be used with each other. If one is on, the other is grayed out.</p> <p>Signal Track is grayed out if in Zero Span.</p> <p>But if Zero Span is entered while in Signal Track, Signal Track is turned off.</p> <p>Signal Track can only function properly if the trace Marker 1 is on and is updating. Therefore if Signal Track is on and the trace Marker 1 is on and is put into View, Signal Track is turned off and the Signal Track key grayed out. Whenever the trace Marker 1 is on and is not updating, the Signal Track key is grayed out.</p> <p>Signal Track is only available in the SA measurement. It should be grayed out in other Measurements.</p> <p>Signal Track can only function properly if the trace Marker 1 is on, is in Trace Update = Active. Therefore if the trace Marker 1 is on and is in Update Off mode when Signal Track is turned on, it is changed to Update On. If the trace Marker 1 is on is set to Update Off while Signal Track is on, it turns off Signal Track.</p>
Preset	OFF
State Saved	Saved in State
Key Path	FREQUENCY, Signal Track
SCPI Status Bits/OPC Dependencies	Overlapped until target span is achieved. The Measuring bit remains set until all signal track actions are complete (any re-acquisition or zooming required).

If marker 1 is off when Signal Track is turned on, marker 1 is turned on in the center of the screen and a peak search is performed. If marker 1 is already on, it stays on and is used where it is. If it is Fixed, it is set to Normal.

If you move the marker during Signal Track, a Mkr-> CF is performed and the signal track function starts over.

If the signal is lost, an attempt will be made to find it again and continue tracking. If there are other signals on the screen that are near the same amplitude, one of them may be found instead since the algorithm is seeking a signal with amplitude similar to the amplitude of the original signal.

Signals near 0 Hz cannot be tracked effectively as they cannot be distinguished from the LO feed-through, which is excluded by intent from the search algorithm.

As a speed optimization, the center frequency is only changed if it differs from the marker position by 1% or more of the span.

If the analyzer is in Single Sweep and Signal Track is turned on, then nothing happens until a

Span

sweep is actually initiated (for example, by an INIT:IMM or Single keypress, and a trigger). Once the sweep is initiated, the entire set of sweeps necessary to complete a pass through the signal track algorithm ensues before the box returns *OPC true, returns results to a READ or MEASure, or returns to the idle state.

If the span is changed while in Signal Track, either by you or because moving the instrument to the signal's frequency results in Span Limiting, an "auto-zoom" algorithm is executed to get to the new span without losing the signal. In "auto zoom", the span is reduced in stages, with a sweep between each stage. You will see this zooming occur as each sweep is performed, and the new span is set. This has in the past been referred to as "auto zoom" and in MXA, an informational message that says "Auto Zoom" will be displayed while this is happening and removed when it completes.

When auto-zooming, the set of steps necessary to achieve the target span is to be considered a "measurement," thus the entire process executes even if the analyzer is in single sweep. *OPC will not return true until the process is complete nor will results be returned to a READ or MEASure command. If the analyzer is in a measurement such as averaging when this happens, the act of changing the span restarts averaging but the first average trace is the last trace of the auto zoom.

When you increase the span, we go directly to the new span. No zooming is required.

This function is intended to track signals with a frequency that is changing (drifting), and an amplitude that is not changing. It keeps tracking if you are in continuous-sweep mode. If in single-sweep mode, as described above, the analyzer only does one center frequency adjustment as necessary.

Trace/Detector

There are no Trace/Detector functions for IQ Analyzer (Basic) mode.

Key Path

Front Panel

View/Display

The View/Display key opens the View menu for the current measurement. This menu includes the **Display** key for controlling items on the display.

The **Display** key precedes the **View** keys. The “views” that are available are specific to the current measurement selected under the **Meas** key.

Views are different ways of looking at data, usually different ways of looking at the same data, especially when the data represents a time record that is being digitally processed with an FFT and/or other digital signal processing algorithms. In some modes, like the Spectrum Analyzer mode, we are mostly concerned with swept spectrum analysis, and those views may represent different ways of looking at the same signal.

Key Path	Front-panel key
----------	------------------------

Display

This is a menu common to all measurements for configuring items on the display. Keys not relevant to a given measurement should be grayed out. Keys not relevant to any measurement in a mode should be blanked. The Display menu settings are specific to the measurement selected under the **Meas** key, except for those settings under the **System Display Settings** key.

Key Path	View/Display
----------	---------------------

Annotation

Use to turn on/off various parts of the display annotation. The annotation is divided up into four categories:


Meas Bar: This is the measurement bar at the top of the screen. When the Meas Bar is off, the graticule area expands to fill the area formerly occupied by the Meas Bar.

Screen Annotation: this is the annotation and annunciation around the graticule, including any annotation on lines (such as the display line, the threshold line, etc). This does NOT include the marker number or the N dB result. When off, the graticule expands to fill the entire graticule area.

Trace annotation—these are the labels on the traces, showing their detector (or their math mode).

Active Function annotation—this is the active function display in the meas bar, and all of the active function values displayed on softkeys.

See the following figure. Each type of annotation can be turned on and off individually.



Key Path

View/Display, Display

Meas Bar On/Off

This function turns the Measurement Bar On and Off, including the settings panel. When off, the graticule area expands to fill the area formerly occupied by the Measurement Bar.

Remote Command :DISPlay:ANNotation:MBAR[:STATE] OFF|ON|0|1
 :DISPlay:ANNotation:MBAR[:STATE]?

Example DISP:ANN:MBAR OFF

Dependencies/Couplings Grayed out and forced to OFF when **System Display Settings, Annotation** is set to Off.

Preset	This should remain Off through a Preset when System Display Settings, Annotation is set to Off
State Saved	Saved in instrument state.
Key Path	View/Display, Display, Annotation

Screen

This controls the display of the annunciation and annotation around the graticule, including any annotation on lines (such as the display line, the threshold line, and so forth) and the y-axis annotation. This does NOT include marker annotation (or the N dB result). When off, the graticule expands to fill the entire graticule area.

Remote Command	:DISPlay:ANNotation:SCReen[:STATe] OFF ON 0 1 :DISPlay:ANNotation:SCReen[:STATe]?
Example	DISP:ANN:SCR OFF
Dependencies/Couplings	Grayed out and forced to OFF when System Display Settings, Annotation is set to Off.
Preset	This should remain Off through a Preset when System Display Settings, Annotation is set to Off
State Saved	Saved in instrument state.
Key Path	View/Display, Display, Annotation

Trace

Turns on and off the labels on the traces, showing their detector (or their math mode) as described in the Trace/Detector section.

If trace math is being performed with a trace, then the trace math annotation will replace the detector annotation.

Remote Command	:DISPlay:ANNotation:TRACe[:STATe] ON OFF 1 0 :DISPlay:ANNotation:TRACe[:STATe]?
Example	DISP:ANN:TRAC OFF
Preset	Off
State Saved	Saved in instrument state.
Key Path	View/Display, Display, Annotation

Active Function Values On/Off

Turns On/Off the active function display in the Meas Bar, and all of the active function values displayed on the softkeys.

View/Display

All of the softkeys that have active functions have these numeric values blanked when this function is on. This is a security feature.

Remote Command	:DISPlay:ACTivefunc[:STATE] ON OFF 1 0 :DISPlay:ACTivefunc[:STATE]?
Example	DISP:ACT OFF
Dependencies/Couplings	Grayed out and forced to OFF when System Display Settings, Annotation is set to Off.
Preset	This should remain Off through a Preset when System Display Settings, Annotation is set to Off
State Saved	Saved in instrument state.
Key Path	View/Display, Display, Annotation

Title

Displays menu keys that enable you to change or clear a title on your display.

Key Path	View/Display, Display
----------	------------------------------

Change Title

Writes a title into the “measurement name” field in the banner (for example, “Swept SA”).

Press Change Title to enter a new title through the alpha editor. Press Enter or Return to complete the entry. Press ESC to cancel the entry and preserve your existing title.

The display title will replace the measurement name. It remains for this measurement until you press Change Title again, or you recall a state, or a Preset is performed. A title can also be cleared by pressing Title, Clear Title.

Pressing this key cancels any active function.

When a title is edited the previous title remains intact (it is not cleared) and the cursor goes at the end so that characters can be added or backspace (BKSP) can be used to go back over previous characters.

Remote Command	:DISPlay:ANNotation:TITLe:DATA <string> :DISPlay:ANNotation:TITLe:DATA?
Example	DISP:ANN:TITL:DATA “This Is My Title”
Preset	No title (measurement name instead)
State Saved	Saved in instrument state.
Key Path	View/Display, Display, Title

Clear Title

Clears a title from the front-panel display. Once cleared, the title cannot be retrieved. After the title

is cleared, the current Measurement Name replaces it in the title bar.

Example	DISP:ANN:TITL:DATA "" clears any existing title characters.
Remote Command Notes	Use the :DISPlay:ANNotation:TITLe:DATA <string> command with an empty string.
Preset	Performed on Preset.
Key Path	View/Display, Display, Title

Graticule

Pressing Graticule turns the display graticule On or Off. It also turns the graticule y-axis annotation on and off.

Remote Command	:DISPlay:WINDow[1]:TRACe:GRATicule:GRID[:STATE] OFF ON 0 1 :DISPlay:WINDow[1]:TRACe:GRATicule:GRID[:STATE]?
Example	DISP:WIND:TRAC:GRAT:GRID OFF
Preset	On
State Saved	Saved in instrument state.
Key Path	View/Display, Display

Display Line

Activates an adjustable horizontal line that is used as a visual reference line. The line's vertical position corresponds to its amplitude value. The value of the display line (for example, "–20.3 dBm") appears above the line itself on the right side of the display in the appropriate font.

The display line can be adjusted using the step keys, knob, or numeric keypad. The unit of the Display Line is determined by the Y axis unit setting under Amplitude. If more than one window has a display line, the display line of the selected window is controlled.

If the display line is off the screen, it shows as a line at the top/bottom of the screen with an arrow pointing up or down. As with all such lines (Pk Thresh, Trigger Level, and so forth) it is drawn on top of all traces.

The display line is unaffected by Auto Couple.

Remote Command	:DISPlay:WINDow[1]:TRACe:Y:DLINe <ampl> :DISPlay:WINDow[1]:TRACe:Y:DLINe? :DISPlay:WINDow[1]:TRACe:Y:DLINe:STATe OFF ON 0 1 :DISPlay:WINDow[1]:TRACe:Y:DLINe:STATe?
Example	DISP:WIND:TRAC:Y:DLIN:STAT ON DISP:WIND:TRAC:Y:DLIN:STAT –32 dBm

View/Display

Preset	Set the Display Line to -25 dBm on Preset. When the Display Line goes from Off to On, if it is off screen, set it to either the top or bottom of screen, depending on which direction off screen it was. The Display Line's value does not change when it is turned off.
State Saved	Saved in instrument state.
Min	$-\infty$ (minus infinity) in current units
Max	$+\infty$ (plus infinity) in current units
Key Path	View/Display, Display
Knob Increment/Decrement	Display scale Log: Step/100 but never < 0.01 dB, Clicks/ $360^\circ = 160$ (5 rev/FS) Display scale Linear: Step/10 but never < 0.1 dB, Clicks/ $360^\circ = 24$ (4 rev/FS) For the linear amplitude units, the knob has the same dB increments as when amplitude units is set to be dB. The only difference is that the annotation is shown in the linear units, and the numeric entry terminator key set is different.
Default Unit	Depends on the current selected Y-axis unit.

System Display Settings

These settings are Mode Global – they affect all modes and measurements and are reset only by **Restore Misc Defaults** or **Restore System Defaults** under System.

Key Path	View/Display, Display, System Display Settings
----------	---

Annotation On/Off

This is a Mode Global override of the meas local annotation settings. When it is OFF, it forces Screen Annotation, Meas Bar, Trace and Active Function Values settings to be OFF for all measurements in all modes. This provides the security based “annotation off” function of previous analyzers, hence it uses the legacy SCPI. Command.

When it is OFF, **Screen, Meas Bar, Trace** and **Active Function Values** keys under the **Display, Annotation** menu are grayed out and forced to OFF. When it is ON, it allows the local annotation settings to be set on a measurement by measurement basis.

To implement this feature properly will require overriding but not changing the local settings for the current measurement. If the measurement changes, the settings for the new measurement must also be overridden but not changed. Then if this function turns off, the settings will be returned to their local values.

Remote Command	:DISPlay:WINDow[1]:ANNotation[:ALL] OFF ON 0 1 :DISPlay:WINDow[1]:ANNotation[:ALL]?
Example	:DISP:WIND:ANN OFF

Preset	On (set by Restore Misc Defaults)
State Saved	Not saved in instrument state.
Key Path	View/Display, Display, System Display Settings, Annotation

Theme

This key allows you to change the Display theme. This is similar to the **Themes** selection under **Page Setup** and **Save Screen Image**. The four themes are detailed below.

Remote Command	:DISPlay:THEMe TDCoLor TDMoNochrome FCOLor FMONochrome :DISPlay:THEMe?
Example	DISP:THEM TDM sets the display theme to 3D Monochrome.
Remote Command Notes	TDCoLor – 3D is the standard color theme with filling and shading TDMoNochrome – is similar to 3D color, but only black is used FCOLor – flat color is intended for inkjet printers to conserve ink. It uses a white background instead of black. FMONochrome – is like flat color, but only black is used
Preset	TDCoLor (set by Restore Misc Defaults)
State Saved	Not saved in instrument state.
Key Path	View/Display, Display, System Display Settings

Backlight On/Off

Allows you to turn the backlight On or Off. This setting interacts with settings under the Windows “Power” menu.

When the backlight is off, pressing ESC, TAB, SPACE, ENTER, UP, DOWN, LEFT, RIGHT, DEL, BKSP, CTRL, or ALT turns the backlight on without affecting the application. Pressing any other key will turn backlight on and could potentially perform the action as well.

Pressing this softkey (Backlight On/Off) will turn the backlight back on, simply because a key has been pressed, and then will turn it back off as the key action is taken. So the display will flash and go back to being off.

Remote Command	:DISPlay:BACKlight ON OFF :DISPlay:BACKlight?
Preset	ON (set by Restore Misc Defaults)
Key Path	View/Display, Display, System Display Settings

Backlight Intensity

View/Display

An active function used to set the backlight intensity. It goes from 0 to 100 where 100 is full on and 0 is off. This value is independent of the values set under the Backlight On/Off key.

Remote Command	:DISPlay:BACKlight:INTensity <integer> :DISPlay:BACKlight:INTensity?
Example	DISP:BACK:INT 50
Preset	100 (set by Restore Misc Defaults)
Min	0
Max	100
Key Path	View/Display, Display, System Display Settings

Full Screen



When Full Screen is pressed the measurement window expands horizontally over the entire instrument display. The screen graticule area expands to fill the available display area.

It turns off the display of the softkey labels, however the menus and active functions still work. (Though it would obviously be very hard to navigate without the key labels displayed.) Pressing **Full Screen** again while Full Screen is in effect cancels Full Screen.

The banner and status lines are unaffected. You can get even more screen area for your data display by turning off the Meas Bar (in the Display menu) which also turns off the settings panel.

Full Screen is a Mode Global function; hence it is not cancelled by the Preset key.

Remote Command	:DISPlay:FSCreen[:STATE] OFF ON 0 1 :DISPlay:FSCreen[:STATE]?
Preset	By SYST:DEF MISC
State Saved	Not saved in state.
Key Path	Display

Display Enable (Remote Command Only)

Turns the display On/Off, including the display drive circuitry and the backlight. The goals of turning the display off are three:

To increase speed as much as possible by freeing the instrument from having to update the display

To reduce emissions from the display, drive circuitry and backlight

For security purposes

If you have turned off the display:

and you are in local operation, the display can be turned back on by pressing any key or by sending the `SYSTEM:DEFAULTS MISC` command or the `DISPLAY:ENABLE ON` (neither `*RST` nor `SYSTEM:PRESET` enable the display.)

and you are in remote operation, the display can be turned back on by pressing the Local or **Esc** keys or by sending the `SYSTEM:DEFAULTS MISC` command or the `DISPLAY:ENABLE ON` (neither `*RST` nor `SYSTEM:PRESET` enable the display.)

and you are using either the `SYSTEM:KLOCK` command or GPIB local lockout, then no front panel key press will turn the display back on. You must turn it back on remotely.

Remote Command	<code>:DISPLAY:ENABLE OFF ON 0 1</code> <code>:DISPLAY:ENABLE?</code>
Example	<code>DISP:ENAB OFF</code>
Dependencies/Couplings	<code>DISP:ENAB OFF</code> turns Backlight OFF and <code>DISP:ENAB ON</code> turns Backlight ON. However, settings of Backlight do not change the state of <code>DISP:ENAB</code>
Preset	By <code>SYST:DEF MISC</code> but Not affected by <code>*RST</code> or <code>SYSTEM:PRESET</code>
State Saved	Not saved in instrument state.

4 Marker Functions

Marker

The Marker key accesses the Marker menu. A marker can be placed on a trace to allow the value of the trace at the marker point to be determined precisely. The functions in this menu include a 1-of-N selection of the control mode Normal, Delta, Fixed, or Off for the selected marker. If the selected marker is Off, pressing Marker sets it to Normal and places it at the center of the screen on the trace determined by the Marker Trace rules.

Markers may also be used in pairs to read the difference (or delta) between two data points. They can be used in Marker Functions to do advanced data processing, or to specify operating points in functions like Signal Track and N dB Points.

The SCPI command in the table below selects the marker and sets the marker control mode as described under **Normal**, **Delta**, **Fixed** and **Off**, below. All interactions and dependencies detailed under the key description are enforced when the remote command is sent.

Remote Command	:CALCulate:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:MODE POSITION DELTA FIXed OFF :CALCulate:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:MODE?
Preset	OFF (all markers)
State Saved	The marker control mode is saved in instrument state
Key Path	Front-panel key

Control Mode

There are four control modes for markers:

Normal (POSITION) - A marker that can be moved to any point on the X Axis by specifying its X Axis value, and whose absolute Y Axis value is then the value of the trace point at that X Axis value.

Delta (DELTA) - A marker that can be moved to any point on the X Axis by specifying its X Axis offset from a reference marker, and whose absolute Y Axis value is then the value of the trace point at that X Axis value.

Fixed (FIXed) - A marker whose X Axis and Y Axis values may be directly or indirectly specified by you, but whose Y Axis value remains fixed, once specified, and does not follow the trace. Fixed markers are useful as reference markers for Delta markers, as operands in a Peak Search operation, and as arbitrary reference points that you can set. These markers are represented on the display by an “X” rather than a diamond.

Off (OFF) - A marker which is not in use.

In the Swept SA measurement, the Preset control mode is **Off** for all markers. The command below sets the marker X Axis value in the current marker X Axis Scale unit. In each case the marker that is addressed becomes the selected marker. It has no effect (other than to cause the marker to become selected) if the control mode is **Off**, but it is the SCPI equivalent of entering an X value if the

control mode is **Normal**, **Delta**, or **Fixed**.

Remote Command	:CALCulate:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:X <freq> :CALCulate:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:X?
Remote Command Notes	<p>If no suffix is sent it will use the fundamental units for the current marker X Axis Scale. If a suffix is sent that does not match the current marker X Axis Scale unit, an invalid suffix error will be generated.</p> <p>If the specified marker is Fixed and a Marker Function is on, a message is generated. If the key is pressed, an advisory message is generated. If the equivalent SCPI command is sent, this same message is generated as part of a “-221, Settings conflict” warning.</p> <p>The query returns the marker’s absolute X Axis value if the control mode is Normal or Fixed. It returns the offset from the marker’s reference marker if the control mode is Delta. The query is returned in the fundamental units for the current marker X Axis scale: Hz for Frequency and Inverse Time, seconds for Period and Time. If the marker is Off the response is not a number.</p>
Preset	After a preset, if X is queried with no value sent first, the center of screen value will be returned. This will depend on the frequency range of the instrument. 13.255 GHz is correct for the 26 GHz instruments only (Option 526).
Min	- ∞ (minus infinity)
Max	+ ∞ (plus infinity)
Default Unit	determined by X Axis Scale

The command below sets the marker X position in trace points. It has no effect if the marker control mode is **Off**. But it is the SCPI equivalent of entering a value if the control mode is **Normal** or **Delta** or **Fixed** – except the setting is in trace points rather than X Axis Scale units.

NOTE The entered value in Trace Points is immediately translated into the current X Axis Scale units for setting the value of the marker. The marker’s value in X Axis Scale Units, NOT trace points, will be preserved if a change is made to the X Axis scale settings. Thus, if you use this command to place a marker on bucket 500, which happens at that time to correspond to 13 GHz, and then you change the Start Frequency so that bucket 500 is no longer 13 GHz, the marker will stay at 13 GHz, NOT at bucket 500! This is important to realize as it differs from the behavior of past Agilent analyzers.

Remote Command	:CALCulate:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:X:POSitio n <real> :CALCulate:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:X:POSitio n?
-----------------------	--

Remote Command Notes	<p>If the specified marker is Fixed and a Marker Function is on, a message is generated. If the key is pressed, an advisory message is generated. If the equivalent SCPI command is sent, this same message is generated as part of a “-221, Settings conflict” warning.</p> <p>The query returns the marker’s absolute X Axis value in trace points if the control mode is Normal or Fixed. It returns the offset from the marker’s reference marker in trace points if the control mode is Delta. The value is returned as a real number, not an integer, corresponding to the translation from X Axis Scale units to trace points</p>
Preset	After a preset, if X is queried with no value sent first, the center of the screen value will be returned. So if per default, the number of Trace points is 1001, the center value will be 500.
Min	0
Max	Number of trace points – 1
Default Unit	unitless

The command below selects the marker and sets the marker Y Axis value; the default unit is the current Y Axis unit. It has no effect (other than selecting the marker) unless the marker control mode is **Fixed**.

Remote Command	<pre>:CALCulate:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:Y <real></pre> <pre>:CALCulate:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:Y?</pre>
Example	<p>CALC:MARK2:MODE POS turns on marker 2 as a normal marker.</p> <p>CALC:MARK2:X 20 GHZ moves marker 2 to 20 GHz if X Axis Scale is Frequency. If X Axis Scale is Time, the -131 invalid suffix error is generated.</p>
Preset	Trace value at center of screen. There is no way to predict what this will be after a preset.
Min	- ∞ (minus infinity)
Max	+ ∞ (plus infinity)

4.0.1 Select Marker

Specifies the selected marker. The term “selected marker” is used throughout this document to specify which marker will be affected by the functions.

Preset	Marker 1
State Saved	The number of the selected marker is saved in instrument state.
Key Path	Marker

4.0.2 Normal

Sets the control mode for the selected marker to **Normal** and turns on the active function for setting its value. If the selected marker was **Off**, it is placed at the center of the screen on the trace specified by the marker's Trace attribute.

A **Normal** mode (POSition type) marker can be moved to any point on the X Axis by specifying its X Axis value. Its absolute Y Axis value is then the value of the trace point at that X Axis value.

Example	:CALC:MARK:MODE POS sets Marker 1 to Normal.
Dependencies/Couplings	The marker addressed by this command becomes the selected marker on the front panel
Remote Command Notes	See the description under the Marker key.
State Saved	The marker control mode (Normal, Delta, Fixed, Off) and X Axis value are saved in instrument state.
Key Path	Marker

4.0.3 Delta

Sets the control mode for the selected marker to Delta and turns on the active function for setting its delta value. If the selected marker was **Off**, it is placed at the center of the screen on the trace specified by the marker's Trace attribute.

In Delta mode the marker result shows the relative result between the selected (Delta) marker and its reference marker. A delta marker can be moved to any point on the X Axis by specifying its X Axis offset from a reference marker. Its absolute Y Axis value is then the value of the trace point at that X Axis value.

Example	:CALC:MARK:MODE DELT sets marker 1 to Delta.
Remote Command Notes	See the description under the Marker key.
State Saved	The marker control mode (Normal, Delta, Fixed, Off) and X Axis value are saved in instrument state.
Key Path	Marker

4.0.4 Fixed

Sets the control mode for the selected marker to Fixed. A fixed marker is fixed in the sense that it stays where you place it. It can be directly moved in both X and Y. It can be moved with a Peak Search. It can also be indirectly moved by re-zeroing the delta if it is a relative marker. If it is moved, it again becomes fixed at the X Axis point it moved to and it has a Y-axis result that it took on when it moved there. If a Normal or Delta marker is changed to Fixed it becomes fixed at the X Axis point it was at, and with the Y-axis result it had when it was set to Fixed.

In Fixed mode the marker result shows:

- If no Marker Function is on, the absolute X Axis and Y axis value of the marker.

Marker

- If a Marker Function is on, the X Axis value and the Y-axis function result in the one the marker had when it became fixed.

Example	:CALC:MARK:MODE FIX sets Marker 1 to Fixed.
Dependencies/Couplings	<p>You cannot directly set the X or Y value of a Fixed marker which has a Marker Function turned on. If an attempt is made to actually adjust it while a Marker Function is on, a message is generated. If the key is pressed, an advisory message is generated. If the equivalent SCPI command is sent, this same message is generated as part of a “-221, Settings conflict” warning.</p> <p>You cannot directly set the Y value of a Fixed marker while Normalize is turned on. If an attempt is made to do so while Normalize is on, a message is generated. If the key is pressed, an advisory message is generated. If the equivalent SCPI command is sent, this same message is generated as part of a “-221, Settings conflict” warning.</p>
Remote Command Notes	See the description under the Marker key.
State Saved	The marker control mode (Normal, Delta, Fixed, Off) and X and Y Axis values are saved in instrument state.
Key Path	Marker, Fixed

Example	:CALC:MARK:MODE FIX sets Marker 1 to Fixed.
Dependencies/Couplings	<p>You cannot directly set the X or Y value of a Fixed marker which has a marker function turned on. If an attempt is made to actually adjust it while a Marker Function is on, a message is generated. If the key is pressed, an advisory message is generated. If the equivalent SCPI command is sent, this same message is generated as part of a “-221, Settings conflict” warning.</p>
Remote Command Notes	See the description under the Marker key.
State Saved	The marker control mode (Normal, Delta, Fixed, Off) and X and Y Axis values are saved in instrument state.
Key Path	Marker, Fixed
Default Unit	Depends on the current selected Y axis unit.

4.0.5 Off

Turns off the selected marker and its marker function setting, if any. However, Off does not affect which marker is selected.

Example	:CALC:MARK:MODE OFF sets Marker 1 to Off.
Remote Command Notes	See the Marker key description.

State Saved The marker control mode (Normal, Delta, Fixed, Off) is saved in instrument state.

Key Path **Marker**

4.0.6 Properties

Opens a menu used to set certain properties of the selected marker.

Key Path **Marker**

4.0.6.1 Select Marker

Refer to the Select Marker key information under the Marker front-panel key.

4.0.6.2 Relative To

Selects the marker that the selected marker will be relative to (its reference marker).

Every marker has another marker to which it is relative. This marker is referred to as the “reference marker” for that marker. This attribute is set by the **Marker, Properties, Relative To** key. The marker must be a **Delta** marker to make this attribute relevant. If it is a **Delta** marker, the reference marker determines how the marker is controlled and how its value is displayed. A marker cannot be relative to itself.

Remote Command :CALCulate:MARKer [1] | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 :REFerence
<integer>

:CALCulate:MARKer [1] | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 :REFerence
?

Example CALC:MARK1:REF 2 sets marker 1’s reference marker to 2 and turns marker 1 on as a delta marker.

Dependencies/Couplings The act of specifying the selected marker’s reference marker makes the selected marker a Delta marker. If the reference marker is off it is turned on in **Fixed** mode at the delta marker location.

Remote Command Notes This command causes the marker specified with the subopcode to become selected.

Range (for SCPI command): 1 to 12. If the range is exceeded the value is clipped.

Preset The preset default “Relative To” marker (reference marker) is the next higher numbered marker (current marker +1). For example, if marker 2 is selected, then it’s default reference marker is marker 3. The exception is marker 12, which has a default reference of marker 1.

Set to the defaults by using **Restore Mode Defaults**. This is not reset by **Marker Off, All Markers Off, or Preset**.

State Saved Saved in instrument state. Not affected by Marker Off and hence not affected by Preset or power cycle.

Marker

Min	1
Max	12
Key Path	Marker, Properties
SCPI Status Bits/OPC	none
Dependencies	Default (selected when Restore Mode Defaults is pressed): next higher numbered marker or 1 if marker 12.

4.0.6.3 X Axis Scale (formerly Readout)

Accesses a menu that enables you to affect how the X Axis information for the selected marker is displayed in the marker area (top-right of display) and the active function area of the display and how the marker is controlled. The available settings for the X Axis Scale are Frequency, Period, Time, and Inverse Time.

Remote Command	:CALCulate:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12 :X:READout FREQuency TIME ITIME PERiod :CALCulate:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12 :X:READout ? :CALCulate:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12 :X:READout :AUTO ON OFF 1 0 :CALCulate:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12 :X:READout :AUTO?
-----------------------	--

Example CALC:MARK3:X:READ TIME sets the marker 3 X Axis Scale to Time.

Remote Command Notes This command causes the specified marker to become selected.

Preset AUTO
Marker Preset (selected when a marker is turned **Off**): **Auto**. In most measurements the Auto settings results in Frequency being the preset readout.

State Saved Saved in instrument state.

Key Path **Marker, Properties**

4.0.6.3.1 Auto

When in Auto, the X Axis Scale is **Frequency** if the Marker Trace is a frequency domain trace, **Time** if the Marker Trace is a time domain trace. When in Auto, if the marker changes traces, or the domain of the trace the marker is on changes, the Auto result is re-evaluated. If the X Axis Scale is chosen manually, that Scale is used regardless of the domain of the trace.

Example CALC:MARK2:X:READ:AUTO ON sets the marker 2 X-axis scaling to automatically select the most appropriate units.

Key Path **Marker, Properties, X Axis Scale**

4.0.6.3.2 Frequency

Sets the marker X Axis scale to Frequency, displaying the absolute frequency of a normal marker or the frequency of the delta marker relative to the reference marker. Frequency is the auto setting for frequency domain traces.

If Frequency is selected for a time domain trace, all of the points in the trace will show the same value. Attempting to use the knob or step keys to adjust the X Axis value of the marker or entering an X Axis value from the numeric keypad or remotely will have no effect but will generate no error.

Example	CALC:MARK2:X:READ FREQ sets the marker 2 X Axis scale to Frequency.
Remote Command Notes	See the X Axis Scale key description.
State Saved	The X Axis Scale setting is saved in instrument state
Key Path	Marker, Properties, X Axis Scale

4.0.6.3.3 Period

Sets the marker X Axis scale to Period, displaying the reciprocal of the frequency of the marker, or the reciprocal of the frequency separation of the two markers in a delta-marker mode. The units are those of time (sec, msec, etc). If the markers are at the same frequency in a delta marker mode, the result will be the reciprocal of 0, which is infinitely large. The display will show “---“ and a SCPI query will return infinity.

If Period is selected for a time domain trace, all of the points in the trace will show the same value. Attempting to use the knob or step keys to adjust the X Axis value of the marker or entering an X Axis value from the numeric keypad or remotely will have no effect, but will generate no error.

Example	CALC:MARK2:X:READ PER sets the marker 2 X Axis scale to Period.
Remote Command Notes	See the X Axis Scale key description.
State Saved	The X Axis Scale setting is saved in instrument state.
Key Path	Marker, Properties, X Axis Scale

4.0.6.3.4 Time

Sets the marker X Axis scale to Time, displaying the time interval between a normal marker and the start of a sweep or the time of the delta marker relative to the reference marker. Time is the auto setting for time domain traces. In a delta-marker mode it is the (sweep) time interval between the two markers.

Example	CALC:MARK2:X:READ TIME sets the marker 2 X Axis Scale to Time
Dependencies/Couplings	Frequency domain traces taken in FFT mode have no valid time data. Therefore when Time is selected for markers on such traces, the X Axis value is taken as the appropriate percentage of the displayed sweep time, which is a calculated estimate.

Remote Command Notes	See the X Axis Scale key description.
State Saved	The X Axis Scale setting is saved in instrument state.
Key Path	Marker, Properties, X Axis Scale

4.0.6.3.5 Inverse Time

Sets the marker X Axis scale to Inverse Time, displaying the reciprocal time. It is useful in a delta mode to show the reciprocal of (sweep) time between two markers. This function is only meaningful when on a time domain trace and in the **Delta** control mode. If the markers are at the same X Axis value, the time between them is 0, so the reciprocal of sweep time is infinitely large. The display will show “---“ and a SCPI query will return infinity.

Example	:CALC:MARK2:X:READ ITIM sets the marker 2 X Axis scale to Inverse Time.
Dependencies/Couplings	Frequency domain traces taken in FFT mode have no valid time data. Therefore when Inverse Time is selected for markers on such traces, the X Axis value is undefined, shows as “---“ and returns not a number to a query.
Remote Command Notes	See the X Axis Scale key description.
State Saved	The X Axis Scale setting is saved in instrument state
Key Path	Marker, Properties, X Axis Scale

4.0.6.4 Marker Trace

Selects the trace that you want your marker to be placed on. A marker is associated with one and only one trace. This trace is used to determine the placement, result, and X Axis Scale of the marker. All markers have an associated trace, even **Fixed** markers; it is from that trace that they determine their attributes and behaviors, and it is to that trace that they go when they become Normal or Delta markers.


When **Auto Init** is true, the marker’s trace attribute is re-determined automatically by the analyzer whenever the marker turns on (Normal, Delta or Fixed) from an Off state. (The trace attribute is also determined for all markers that are on, whenever **Auto Init** is turned on).

When the marker moves between traces the marker’s X position in trace points is retained as it moves. For moving between active traces this generally means the x-axis value of the marker will not change. But for moving to or from an inactive trace, the x-axis value will take on that of the new trace at the bucket the marker was on the old trace (and is still on, on the new trace, since the bucket doesn’t change).

NOTE This is true even if the marker is off screen. Thus, a marker that is at the center of the screen on the old trace stays at the center of the screen on the new trace. A marker that is off screen one whole screen to the left on the old trace remains off screen one whole screen to the left on the new trace – even if this means it will be at negative time.

Marker Trace is set to 1, and Auto Init is set to On, on a Preset or All Markers Off.

The following flowchart depicts the Auto Init rules:



Remote Command

:CALCulate:MARKer [1] | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 :TRACe 1 | 2 | 3 | 4 | 5 | 6

:CALCulate:MARKer [1] | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 :TRACe?

Example

CALC:MARK1:TRAC 2 places marker 1 on trace 2.

Dependencies/Couplings

This is not affected by Auto Coupling.

Sending the remote command causes the addressed marker to become selected.

Preset

Presets on Preset or All Markers Off

State Saved

The Marker Trace and state of **Auto Init** for each marker is saved in instrument state.

Min

1

Max

6

Key Path

Marker, Properties

4.0.6.4.1 Marker Trace Auto Init (Remote command only) This command associates the marker with the specified trace and turns Marker Trace Auto Init OFF for that marker. If the marker is not **Off** it moves the marker from the trace it was on to the new trace. If the marker is **Off** it stays off but is now associated with the specified trace.

The query returns the number of the trace on which the marker is currently placed, even if that

marker is in Auto mode.

Remote Command	:CALCulate:MARKer [1] 2 3 4 5 6 7 8 9 10 11 12 :TRACe:AUTO OFF ON 0 1 :CALCulate:MARKer [1] 2 3 4 5 6 7 8 9 10 11 12 :TRACe:AUTO?
Remote Command Notes	Turning Marker Trace Auto Init off has no effect on the trace on which the marker is currently placed. The response to the query will be 0 if OFF, 1 if ON.
Preset	ON

4.0.6.5 Lines

When on, displays a vertical line of graticule height and a horizontal line of graticule width, intersecting at the indicator point of the marker (that is, the center of the X or the bottom tip of the diamond). The lines are blue (0,0,255) in color.

If the marker is off screen the lines should be extended from the marker so that they go through the screen area if possible. This is really useful for off screen Fixed markers as it lets you see their amplitude even though they are off the X Axis.

Remote Command	:CALCulate:MARKer [1] 2 3 4 5 6 7 8 9 10 11 12 :LINes [:STATe] OFF ON 0 1 :CALCulate:MARKer [1] 2 3 4 5 6 7 8 9 10 11 12 :LINes [:STATe] ?
Example	:CALC:MARK2:LIN:ON turns Lines on for marker.
Dependencies/Couplings	Sending the remote command causes the addressed marker to become selected.
Preset	OFF
State Saved	Saved in State.
Key Path	Marker, Properties

4.0.7 Marker Table

Turns the state of the Marker Table On or Off.

Remote Command	:CALCulate:MARKer:TABLE [:STATe] OFF ON 0 1 :CALCulate:MARKer:TABLE [:STATe] ?
Example	CALC:MARK:TABL ON turns on the marker table.
Preset	OFF
State Saved	Whether the marker table is on is saved in instrument state
Key Path	Marker

4.0.8 Marker Count

Accesses the marker count menu.

Key Path **Marker**

4.0.8.1 Counter On/Off

Turns the marker frequency counter on and off. The selected marker is counted, and if the selected marker is a delta marker and its reference marker is not fixed, the reference marker is counted as well.

Remote Command :CALCulate:MARKer [1] | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 :FCOunt [:S
TATe] OFF|ON|0|1

:CALCulate:MARKer [1] | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 :FCOunt [:S
TATe] ?

Example CALC:MARK2:FCO ON selects marker 2, turns it on, and turns on the counter.

CALC:MARK2:FCO:X? returns the counted frequency.

Dependencies/Couplings If the selected marker is **Off** when the counter is turned on, the selected marker is set to Normal and placed at the center of the screen on the trace determined by the Marker Trace rules.

The counter is turned OFF when the selected marker is turned OFF.

Remote Command Notes This command causes the specified marker to become selected.

Preset OFF

State Saved The state of the counter (On/Off) is saved in instrument state. In the case of Fixed markers, the count stored in the marker is saved in instrument state.

Key Path **Marker Fctn, Marker Count**

Using the internal counter we can count the frequency of a marker, but we cannot count while we are actually sweeping. So, once we are done with a sweep, we move to the selected marker frequency and count that frequency. Then, if the marker is a Delta marker, the count is also taken for its reference marker. The count is actually performed by moving the LO to the frequency (or frequencies in the case of a delta marker) we wish to count. The count is executed on a marker by marker basis and no further count is taken until after the next sweep (even if the marker moves before another sweep has completed).

The Marker Count is taken by tuning the instrument to the frequency of the marker and counting the IF, with the instrument not sweeping. The count is adjusted for display by adding or subtracting it (as appropriate) from the LO frequency, so that you see a count that represents the signal frequency. This is true even if External Mixing is on. Since all this happens between sweeps, you never see the instrument retuning to do the counts.

Fixed markers have a count stored in them that is generally kept fixed and not updated. If a fixed

marker is selected, or used as a reference, the signal at the marker frequency is not counted; rather the stored count is seen or used as the reference.

If you wish to see the entered frequency of a counted marker it will appear in the active function area when that marker is selected (for Fixed markers, you have to use the hollow point function to view or adjust the x or y marker values).

If the selected marker is off the X-axis the instrument can still be tuned to the marker (unless it is outside the range of the instrument), so the count can still be displayed. This means you can see a count for an off screen marker even though there may be no valid Y-value for the marker. If the marker frequency is outside the range of the instrument, the display will show three dashes in the count block (---), and not a number is returned to a SCPI count query.

When a Delta Marker is selected while Marker Count is on:

If the reference marker is not a fixed marker, the display shows the difference between the count of the selected marker and the count of the reference marker

If the reference marker is a fixed marker and there is a count stored in the marker (because Marker Count was on when the marker became a fixed marker), the display shows the difference between the count at the marker and the count stored in the reference marker.

Marker Count works in zero span as well as in Swept SA. The instrument tunes to the frequency of the selected marker, which, for active zero span traces, is simply the center frequency of the analyzer.

Fixed markers have a count stored in them that is generally kept fixed and not updated. If a fixed marker is selected, or used as a reference, the signal at the marker frequency is not counted; rather the stored count is seen or used as the reference. The count is stored, if Count is on, when the marker becomes fixed or when, while fixed, the marker is moved by re-zeroing the reference (if it is the reference marker) or via a peak search (since both of these, by definition, use valid trace data). The count stored in a Fixed marker is lost if the counter is turned off, if the marker is moved to an inactive trace, or if the marker is moved by adjusting its x-value.

When the counter is on, the count (or the delta count) for the selected marker is displayed.

The invalid data indicator (*) will turn on until the completion of the first count.

Marker Count frequency readings are corrected using the **Freq Offset** function. However, Marker Delta readings are not corrected, as any offset would be applied to both.

In zero span on active traces the counter continues to function, counting any signal near the center frequency of the analyzer.

NOTE No signal farther from the marker frequency than the Res BW will be seen by the counter.

The above command turns on or off the frequency counter. If the specified marker number in the command is not the selected marker, it becomes the selected marker. If the specified marker number is not on, FCount ON sets it to Normal and places it at the center of the screen on the trace determined by the Marker Trace rules. Once the Marker Count is on, it is on for any selected marker, not just for the one used in the command. A 1 is returned to the state query only if marker count is on and the specified number is the selected marker. The invalid data indicator (*) will turn

on until the completion of the first count, but this does not keep a value from being returned.

Query count value:

Remote Command	:CALCulate:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:FCOUNT:X?
Remote Command Notes	This query does NOT cause the specified marker to become selected.

The above command queries the frequency count.

The query returns the absolute count unless the specified marker is in Delta mode, then it returns the relative count. A marker with no stored count, or a non-**Fixed** marker on a stored trace, will also return not a number to a SCPI count query. This result may mean that the first sweep after the counter turned on has not yet completed.

4.0.9 Couple Markers

When this function is true, moving any marker causes an equal X Axis movement of every other marker which is not Fixed or Off. By “equal X Axis movement” we mean that we preserve the difference between each marker’s X Axis value (in the fundamental x-axis units of the trace that marker is on) and the X Axis value of the marker being moved (in the same fundamental x-axis units).

Fixed markers do not couple. They stay where they were while all the other markers move. Of course, if a Fixed marker is being moved, all the non-fixed markers do move with it. This may result in markers going off screen.

Remote Command	:CALCulate:MARKer:COUple[:STATE] OFF ON 0 1 :CALCulate:MARKer:COUple[:STATE]?
Example	:CALC:MARK:COUP ON sets Couple Markers on.
Preset	Off, presets on Mode Preset and All Markers Off.
State Saved	Saved in State.
Key Path	Marker

4.0.10 All Markers Off

Turns off all markers. See Marker, Off.

Remote Command	:CALCulate:MARKer:AOFF
Example	CALC:MARK:AOFF turns off all markers.
Dependencies/Couplings	Sets the selected marker to 1.
Preset	n/a.
Key Path	Marker

Marker Fctn

The Marker Function key opens up a menu of keys that allow you to control the Marker Functions of the instrument. Marker Functions perform post-processing operations on marker data. Band Functions are Marker Functions that allow you to define a band of frequencies around the marker. The band defines the region of data used for the numerical calculations. These marker functions also allow you to perform mathematical calculations on trace and marker data and report the results of these calculations in place of the normal marker result.

NOTE Unlike regular markers, marker function markers are not placed directly on the trace. They are placed at a location which is relative to the result of the function calculation.

Remote Command	<code>:CALCulate:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:FUNCTION NOISe BPOWer BDENsity OFF</code> <code>:CALCulate:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:FUNCTION?</code>
Dependencies/Couplings	Fixed markers: It is not possible to change the Band Function for a Fixed marker; so all of the Band Function keys are grayed out for a Fixed marker. If a marker function was already on when the marker became Fixed then the selected Band Function is shown but cannot be changed. Therefore, you cannot directly set the X or Y value of a Fixed marker which has a marker function turned on. To turn off the function, turn off the marker.
Remote Command Notes	Sending this command selects the subcoded marker. The marker function result is queried in the same fashion as the Marker Result, as outlined in the Marker section, with the <code>CALC:MARK:Y?</code> command.
Preset	OFF
State Saved	The band function for each marker is saved in Instrument State.
Key Path	Front-panel key

The units to be used for displaying Marker Function results in Delta mode vary depending on the reference marker and what it is referenced to.

Marker Functions are different from Measurements, which automatically perform complex sequences of setup, data acquisition, and display operations in order to measure specified signal characteristics. Marker Functions are specified for each individual marker and may be turned on individually for each marker.

The **Marker Fctn** menu controls which marker functions are turned on and allows you to adjust setup parameters for each function. The Marker Functions are **Marker Noise**, **Band/Interval Power**, and **Band/Interval Density**, only one of which can be on for a given marker.

If the selected marker is off, pressing Marker Fctn sets it to Normal and places it at the center of the display on the trace determined by the Marker Trace rules. However, if the selected marker was **Off**, **Marker Function Off** had to be the selected function, and it remains so even after the marker is turned on, although you may then change it.

Fixed marker functions

In the case of a fixed marker, it is not possible to turn on or change a band function. This is because a Fixed marker holds the value it had when it became fixed; the trace it was on may keep on changing, so the function value, which depends on trace data, could not be calculated on an ongoing basis.

It is possible to have a Marker Function on for a Fixed marker, in the case where a function was already on when the marker became Fixed. In this case the function value will be retained in the marker. It is also possible to have a Marker Function on for a Fixed marker in the case when the marker was off and was turned on as **Fixed** because **Delta** was pressed to create a reference marker - in which case the marker function, marker function width, Y Axis value and marker function result that the **Delta** marker had when **Delta** was pressed are copied into the Fixed marker. If **Delta** is pressed again, causing the fixed reference marker to move to the delta marker's position, the marker function, marker function width, Y Axis value and marker function result that the **Delta** marker had when **Delta** was pressed are again copied into the fixed reference marker.

If a Marker Function is on for a Fixed marker, the marker's reported value is derived by the function. Therefore you cannot directly set the X or Y value of a Fixed marker which has a marker function turned on. Indirect setting as detailed above or when a Peak Search is performed is allowed, as the Fixed marker is always placed on a trace and can derive its function value from the trace at the moment when it is placed.

Interval Markers

What is an interval marker? The band power marker computes the total power within a span in a nonzero span. The results computation must include the RBW. The interval power marker measures the average power across some time interval in zero span.

Interval Density is defined to be Interval Power divided by Bn. Bn is the noise bandwidth of the RBW filter, as noted and used within the Band Power computation.

4.0.11 Select Marker

Refer to the Select Marker key information.

4.0.12 Marker Noise

Turns on the Marker Noise function for the selected marker, making it a noise marker. If the selected marker is off, it is turned on in **Normal** mode and located at the center of the screen.

When **Marker Noise** is selected while in the **Marker Function Off** state, the **Band Span** or **Interval Span** is initialized to 5% of the screen width.

When **Marker Noise** is on, the marker's Y Axis Result is the average noise level, normalized to a 1 Hz

noise power bandwidth, in the band specified under the **Band Adjust** key.

Example	<p>CALC:MARK:FUNC NOIS turns on marker 1 as a noise marker.</p> <p>CALC:MARK:FUNC? returns the current marker function for the marker specified. In this case it returns the string: NOIS.</p> <p>CALC:MARK:Y? returns the y-axis value of the Marker Noise function for marker 1 (if Marker Noise is ON for marker 1). The delta value when the Y axis unit is Watt is the square of the delta value when the Y axis unit is Volt. For example, when the percent ratio with Y axis unit in Volt is 0.2, the percent ratio with Y axis unit in Watt will be $0.2^2 = 0.04$. When you read the value out remotely you have to know whether your Y Axis Unit is log (dB), linear (V or A), or power (W).</p>
Dependencies/Couplings	<p>Fixed markers: It is not possible to change the Band Function for a Fixed marker; so all of the Band Function keys are grayed out for a Fixed marker.</p> <p>See also the Trace/Detector section.</p> <p>Average detector and Power Averaging auto selected when Marker Noise on.</p> <p>See also the Trace/Detector section.</p> <p>If the selected (specified) marker is off, selecting Marker Noise through the front panel or SCPI will turn the marker on.</p>
Remote Command Notes	See the description under the Marker Fctn key.
Key Path	Marker Fctn

To guarantee accurate data for noise-like signals, a correction for the equivalent noise bandwidth is made by the analyzer. The **Marker Noise** function accuracy is best when the detector is set to Average or Sample, because neither of these detectors will peak-bias the noise. The tradeoff between sweep time and variance of the result is best when Average Type is set to Power Averaging. Therefore, Auto coupling chooses the Average detector and Power Averaging when Marker Noise is on. Though the Marker Noise function works with all settings of detector and Average Type, using the positive or negative peak detector gives less accurate measurement results.

Off-trace Markers

If a **Normal** or **Delta** noise marker is so near to the left or right edge of the trace that some of the band is off the trace, then it uses only that subset of the Band Width that is on-trace. If the marker itself is off-trace, its value becomes undefined.

Neither band/interval power nor band/interval density markers are defined if any part of the band is off-trace (unless they are Fixed with a stored function value in them), except when the edges of the bandwidth are trivially off-screen, due to mathematical limitations in the analyzer or in the controlling computer, the result will still be considered valid.

4.0.13 Band/Interval Power

Turns on the Band/Interval Power function for the selected marker. If the selected marker is off it is

turned on in **Normal** marker and located at the center of the screen.

When **Band/Interval Power** is selected while in the **Marker Function Off** state, the **Band Span** or **Interval Span** is initialized to 5% of the screen width.

If the detector mode for the detector on the marker's trace is set to Auto, the average detector is selected. If the Average type is set to Auto, Power Averaging is selected. Other choices for the detector or Average type will usually cause measurement inaccuracy.

Example	<p>CALC:MARK:FUNC BPOW turns on marker 1 as a band power marker.</p> <p>CALC:MARK2:FUNC? returns the current setting of the marker function for marker 2. In this case it returns the string: BPOW.</p> <p>CALC:MARK:Y? returns the y-axis value of the Band Power function for marker 1. The delta value when the Y axis unit is Watt is the square of the delta value when the Y axis unit is Volt. For example, when the percent ratio with Y axis unit in Volt is 0.2, the percent ratio with Y axis unit in Watt will be $0.22 = 0.04$. When you read the value out remotely you have to know whether your Y Axis Unit is log (dB), linear (V or A), or power (W).</p>
Dependencies/Couplings	<p>Fixed markers: It is not possible to change the Band Function for a Fixed marker; so all of the Band Function keys are grayed out for a Fixed marker.</p> <p>See also the Trace/Detector section.</p> <p>If the detector mode for the detector on the marker's trace is set to Auto, the average detector is selected. If the Average type is set to Auto, Power Averaging is selected.</p> <p>See also the Trace/Detector section.</p> <p>If the selected (specified) marker is off, selecting Band Power through the front panel or SCPI will turn the marker on.</p>
Remote Command Notes	See the description under the Marker Fctn key.
Key Path	Marker Fctn

4.0.14 Band/Interval Density

Turns on the Band/Interval Density function for the selected marker. If the selected marker is off, it is turned on in **Normal** marker mode and located at the center of the screen.

When **Band/Interval Density** is selected while in the **Marker Function Off** state, the **Band Span** or **Interval Span** is initialized to 5% of the screen width.

It may seem like the band density marker function is exactly like a function of a noise marker with variable width. But they are somewhat different. The Noise markers assume that the signal to be measured is noise-like. Based on this assumption, we can actually make reasonable measurements under very non-ideal conditions: any detector may be used, any averaging type, any VBW. In contrast, the Band Power and Band Density markers make no assumption about the statistics of the signal.

If the detector mode for the detector on the marker's trace is set to Auto, the average detector is selected. If the Average type is set to Auto, Power Averaging is selected. Other choices for the detector or Average type will usually cause measurement inaccuracy.

What is band/interval density?

On frequency domain traces, the average density across a band is the total band power divided by the bandwidth over which it is measured.

On time domain traces, interval density is the average power in the interval divided by the noise bandwidth of the RBW of the trace.

Example	<p>CALC:MARK:FUNC BDEN turns on marker 1 as a band density marker.</p> <p>CALC:MARK:FUNC? returns the current setting of band function for the marker specified. In this case it returns the string: BDEN.</p> <p>CALC:MARK:Y? returns the y-axis value of the Band Density function for marker 1. The delta value when the Y axis unit is Watt is the square of the delta value when the Y axis unit is Volt. For example, when the percent ratio with Y axis unit in Volt is 0.2, the percent ratio with Y axis unit in Watt will be $0.2^2 = 0.04$. When you read the value out remotely you have to know whether your Y Axis Unit is log (dB), linear (V or A), or power (W).</p>
---------	--

Dependencies/Couplings	<p>Fixed markers: It is not possible to change the Band Function for a Fixed marker; so all of the Band Function keys are grayed out for a Fixed marker.</p> <p>See also the Trace/Detector section.</p> <p>If the detector mode for the detector on the marker's trace is set to Auto, the average detector is selected. If the Average type is set to Auto, Power Averaging is selected.</p> <p>See also the Trace/Detector section.</p> <p>If the selected (specified) marker is off, selecting Band Density through the front panel or SCPI will turn the marker on.</p>
------------------------	--

Remote Command Notes	See the description under the Marker Fctn key.
----------------------	---

State Saved	n/a.
-------------	------

Key Path	Marker Fctn
----------	--------------------

4.0.15 Off

Turns off band functions for the selected marker.

Example	:CALC:MARK:FUNC OFF turns off marker functions for marker 1
---------	---

Dependencies/Couplings	Fixed markers: It is not possible to change the Band Function for a Fixed marker; so all of the Band Function keys are grayed out for a Fixed marker, including Off. We could allow OFF, but it is hard to disable all but one node in a 1-of-N and still generate a -221 error. Turning off the marker function has no effect on the band span nor does it turn the marker off.
Remote Command Notes	See the description under the Marker key.
Key Path	Marker, Marker Fctn

4.0.16 Band Adjust

Opens a menu that lets you set the width or left or right edges of the band.

It is legal to change the width of the band even if there is no marker function on. Generally, this can only happen by sending the SCPI command since access to the menu is restricted if no marker function is on.

Dependencies/Couplings	If the marker is Fixed, Band Adjust is grayed out. If the marker function is Off, Band Adjust is grayed out. If any of the Band Adjust functions are the active function, the wings and arms of the selected marker display in green; otherwise they display in white.
Key Path	Marker Function

4.0.16.1 Band/Interval Span

Sets the width of the span for the selected marker.

It is legal to change the width of the band even if there is no marker function on. Generally, this can only happen by sending the SCPI command since access to the menu is restricted if no marker function is on.

In the table below, $\text{sweep_width} = \max(1, \text{sweep_points} - 1)$ and sweep_points is the number of sweep points, set in the **Sweep** menu.

Remote Command	:CALCulate:MARKer [1] 2 3 4 5 6 7 8 9 10 11 12 :FUNction: BAND:SPAN <freq> :CALCulate:MARKer [1] 2 3 4 5 6 7 8 9 10 11 12 :FUNction: BAND:SPAN?
Example	:CALC:MARK12:FUNC:BAND:SPAN 20 MHz sets the band span of marker 12 to 20 MHz. :CALC:MARK:FUNC:BAND:SPAN? queries the band span of Marker 1.

Dependencies/Couplings	<p>Changing the Band/Interval Span necessarily changes the Band/Interval Left and Band/Interval Right values.</p> <p>Band/Interval Span is set to 0 when the marker is turned off.</p> <p>Band/Interval Span is set to 5% of the span when any marker function is turned on if and only if it is zero at that time.</p>
Remote Command Notes	<p>Sending this command selects the subopcoded marker</p> <p>The unit of the parameter must match the current domain of the trace the selected marker is on, or an invalid suffix error will be generated. If no unit is sent, the fundamental unit for the trace domain will be used (Hz for freq domain traces, s for time domain traces).</p> <p>All the values provided in this table are only valid for frequency domain traces. If the current domain of the trace is time domain, values and unit will be different. In frequency domain, the Preset value is dependant on the frequency range of the instrument. The default value 1.3245 GHz is appropriate only if the instrument is a 26.5GHz instrument (Option 526). In a 26.5GHz Instrument, the default span is 26.49 GHz, so 5% of the span corresponds to 1.3245 GHz.</p>
Preset	<p>If 0, Band/Interval Span is set to 5% of the span, when a marker function is turned on.</p>
State Saved	<p>Saved in Instrument State</p>
Min	<p>0 Hz</p>
Max	<p>Infinity</p>
Key Path	<p>Marker Fctn, Band Adjust</p>

4.0.16.2 Band/Interval Left

Sets the left edge frequency or time for the band of the selected marker. The right edge is unaffected.

It is legal to change the width of the band even if there is no marker function on. Generally this can only happen by sending the SCPI command since access to the menu is restricted if no marker function is on.

In the table below, $sweep_width = \max(1, sweep_points - 1)$ and $sweep_points$ is the number of sweep points, set in the **Sweep** menu.

Remote Command	<pre>:CALCulate:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:FUNCTION: BAND:LEFT <freq></pre> <pre>:CALCulate:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:FUNCTION: BAND:LEFT?</pre>
-----------------------	---

Example	<p>:CALC:MARK12:FUNC:BAND:LEFT 20 GHz sets the left edge of the band span of marker 12 to 20 GHz.</p> <p>:CALC:MARK:FUNC:BAND:LEFT? queries the band span of Marker 1.</p>
Dependencies/Couplings	<p>Changing the Band/Interval Left necessarily changes the Band/Interval Span and Band/Interval Center values.</p> <p>Band/Interval Span is set to 0 when the marker is turned off so that means Band/Interval Left is set to the center value at this time.</p> <p>Band/Interval Span is set to 5% of the span when any marker function is turned on if and only if it is zero at that time.</p>
Remote Command Notes	<p>Sending this command selects the subopcoded marker.</p> <p>The unit of the parameter must match the current domain of the trace the selected marker is on, or an invalid suffix error will be generated. If no unit is sent, the fundamental unit for the trace domain will be used (Hz for freq domain traces, s for time domain traces).</p> <p>All the values provided in this table are only valid for frequency domain traces. If the current domain of the trace is time domain, values and unit will be different. In frequency domain, the Preset value is dependant on the frequency range of the instrument. The default value 1.3245 GHz is appropriate only if the instrument is a 26.5GHz instrument (Option 526). In a 26.5GHz Instrument, the default span is 26.49 GHz, so 5% of the span corresponds to 1.3245 GHz.</p>
Preset	If 0, Band/Interval Span is set to 5% of the span, when a marker function is turned on, which affects Band/Interval Left
State Saved	Saved in Instrument State.
Min	0 Hz
Max	Infinity
Key Path	Marker Fctn, Band Adjust

4.0.16.3 Band/Interval Right

Sets the right edge frequency or time for the band of the selected marker. The left edge is unaffected.

In the table below, $\text{sweep_width} = \max(1, \text{sweep_points} - 1)$ and sweep_points is the number of sweep points, set in the **Sweep** menu.

It is legal to change the width of the band even if there is no marker function on. Generally this can only happen by sending the SCPI command since access to the menu is restricted if no marker

function is on.

Remote Command	<pre>:CALCulate:MARKer [1] 2 3 4 5 6 7 8 9 10 11 12 :FUNction: BAND:RIGHT <freq></pre> <pre>:CALCulate:MARKer [1] 2 3 4 5 6 7 8 9 10 11 12 :FUNction: BAND:RIGHT?</pre>
Example	<pre>:CALC:MARK12:FUNC:BAND:RIGHT 20 GHz</pre> sets the right edge of the band span of marker 12 to 20 GHz. <pre>:CALC:MARK:FUNC:BAND:RIGHT?</pre> queries the band span of Marker 1.
Dependencies/Couplings	<p>Changing the Band/Interval Right necessarily changes the Band/Interval Span and Band/Interval Center values.</p> <p>Band/Interval Span is set to 5% of span when any marker function is turned on if and only if it is zero at that time.</p>
Remote Command Notes	<p>Sending this command selects the subcoded marker.</p> <p>The unit of the parameter must match the current domain of the trace the selected marker is on, or an invalid suffix error will be generated. If no unit is sent, the fundamental unit for the trace domain will be used (Hz for freq domain traces, s for time domain traces).</p> <p>All the values provided in this table are only valid for frequency domain traces. If the current domain of the trace is time domain, values and unit will be different. In frequency domain, the Preset value is dependant on the frequency range of the instrument. The default value 1.3245 GHz is appropriate only if the instrument is a 26.5GHz instrument (Option 526). In a 26.5GHz Instrument, the default span is 26.49 GHz, so 5% of the span corresponds to 1.3245 GHz.</p>
Preset	If 0, Band/Interval Span is set to 5% of the span, when a marker function is turned on, which affects Band/Interval Right.
State Saved	Saved in Instrument State.
Min	0 Hz
Max	Infinity
Key Path	Marker Fctn, Band Adjust

Marker To

The **Marker ->** key accesses menu keys that can copy the current marker value into other instrument parameters (for example, Center Freq). The currently selected marker is made the active function on entry to this menu (if the currently selected marker is not on when you press this front panel key, it will be turned on at the center of the screen as a normal type marker and then made the active function).

The **Marker ->** (or Marker To) feature is used to quickly assign a marker's x- or y-axis value to another parameter. For example, if a marker's x-axis value is 500 MHz and y-axis value is -20 dBm, pressing **Mkr -> CF** would assign 500 MHz to **Center Freq** and pressing **Mkr ->Ref Lvl** would assign -20 dBm to **Ref Level**.

Key Path	Front-panel key
----------	-----------------

4.0.17 Mkr->CF

Sets the center frequency of the analyzer to the frequency of the selected marker. The marker stays at this frequency, so it moves to the center of the display. In delta marker mode, this function sets the center frequency to the x-axis value of the delta marker. When the frequency scale is in log mode, the center frequency is not at the center of the display.

If the currently selected marker is not on when this key is pressed, it will be turned on at the center of the screen as a normal type marker.

Remote Command	:CALCulate:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12[:SET]:CEN Ter
Example	CALC:MARK2:CEN sets the CF of the analyzer to the value of marker 2.
Dependencies/Couplings	This function is not available (key is grayed out) when x-axis is the time domain. All the usual couplings associated with setting the Center Frequency apply (see the Frequency Section).
Remote Command Notes	Sending this command selects the subcoded marker. If the specified marker is off, this command will turn it on at the center of the screen as a normal type marker.
Key Path	Marker ->

4.0.18 Mkr->CF Step

Sets the center frequency (CF) step size of the analyzer to the marker frequency, or in delta-marker mode, to the frequency difference between the delta and reference markers.

If the currently selected marker is not on when this key is pressed, it will be turned on at the center

Marker To

of the screen as a normal type marker.

Remote Command	:CALCulate:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12[:SET]:STEP
Example	CALC:MARK1:STEP sets the CF step to the value (or delta value) of marker 1.
Dependencies/Couplings	This function is not available (key is grayed out) when x-axis is the time domain. All the usual couplings associated with setting CF Step apply (see the Frequency Section).
Remote Command Notes	Sending this command selects the subopcoded marker. If the specified marker is off, this command will turn it on at the center of the screen as a normal type marker.
Key Path	Marker ->

4.0.19 Mkr->Start

Changes the start frequency to the frequency of the selected marker. The marker stays at this frequency, so it moves to the left edge of the display. In delta marker mode, this function sets the start frequency to the x-axis value of the delta marker.

If the currently selected marker is not on when this key is pressed, it will be turned on at the center of the screen as a normal type marker.

Remote Command	:CALCulate:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12[:SET]:STARt
Example	CALC:MARK1:STAR sets the start frequency to the value (or delta value) of marker 1.
Dependencies/Couplings	This function is not available (key is grayed out) when x-axis is the time domain. All the usual couplings associated with setting the Start Frequency apply (see the Frequency Section).
Remote Command Notes	Sending this command selects the subopcoded marker. If the specified marker is off, this command will turn it on at the center of the screen as a normal type marker.
Key Path	Marker ->

4.0.20 Mkr->Stop

Changes the stop frequency to the frequency of the selected marker. The marker stays at this frequency, so it moves to the right edge of the display. In delta marker mode, this function sets the stop frequency to the x-axis value of the delta marker.

If the currently selected marker is not on when this key is pressed, it will be turned on at the center

of the screen as a normal type marker.

Remote Command	:CALCulate:MARKer [1] 2 3 4 5 6 7 8 9 10 11 12 [:SET] :STOP
Example	CALC:MARK3:STOP sets the stop frequency to the value (or delta value) of marker 3.
Dependencies/Couplings	This function is not available (key is grayed out) when x-axis is the time domain. All the usual couplings associated with setting the Stop Frequency apply (see the Frequency Section).
Remote Command Notes	Sending this command selects the subopcoded marker. If the specified marker is off, this command will turn it on at the center of the screen as a normal type marker.
Key Path	Marker ->

4.0.21 Mkr Δ ->Span

Sets the start and stop frequencies to the values of the delta markers. That is, it moves the lower of the two marker frequencies to the start frequency and the higher of the two marker frequencies to the stop frequency. The marker mode is unchanged and the two markers (delta and reference) end up on opposite edges of the display.

Remote Command	:CALCulate:MARKer [1] 2 3 4 5 6 7 8 9 10 11 12 [:SET] :DEL Ta:SPAN
Example	CALC:MARK2:DELT:SPAN sets the start and stop frequencies to the values of marker 2 and its reference marker.
Dependencies/Couplings	This function is only available when the selected marker is a delta marker. Otherwise the key is grayed out. In addition, this function is not available when the x-axis is the time domain. All the usual couplings associated with setting the Span apply (see the Span Section).
Remote Command Notes	Sending this command selects the subopcoded marker.
Key Path	Marker ->

4.0.22 Mkr Δ ->CF

Sets the center frequency to the frequency difference between the selected marker and its reference marker. The marker is then changed to a Normal marker and placed at the center of the span.

Remote Command	:CALCulate:MARKer [1] 2 3 4 5 6 7 8 9 10 11 12 [:SET] :DEL Ta:CENTer
-----------------------	---

Marker To

Example	CALC:MARK2:CENT sets the CF of the analyzer to the value of marker 2.
Dependencies/Couplings	This function is only available when the selected marker is a delta marker. Otherwise the key is grayed out. In addition, this function is not available when the x-axis is the time domain.
Remote Command Notes	Sending this command selects the subopcoded marker.
Key Path	Marker ->

4.0.23 Mkr->Ref Lvl

Sets the reference level to the amplitude value of the selected marker, moving the marked point to the reference level (top line of the graticule). The marker’s mode (Normal, Delta, Fixed) does not matter in this case. For example, given a delta marker, if the delta marker is the selected marker, its amplitude is applied to the reference level. If the reference marker is selected, its amplitude is applied to the reference level.

If the currently selected marker is not on when this key is pressed, it will be turned on at the center of the screen as a normal type marker, and its amplitude applied to the reference level.

Remote Command	:CALCulate:MARKer [1] 2 3 4 5 6 7 8 9 10 11 12 [:SET] :RLEVel
Example	CALC:MARK2:RLEV sets the reference level of the analyzer to the amplitude of marker 2.
Dependencies/Couplings	All the usual couplings associated with setting the Reference Level apply (see the Amplitude Section).
Remote Command Notes	Sending this command selects the subopcoded marker. If the specified marker is off, this command will turn it on at the center of the screen as a normal type marker.
Key Path	Marker ->

Peak Search

Pressing the Peak Search key displays the Peak Search menu and places the selected marker on the trace point with the maximum y-axis value for that marker's trace. The Peak Search features allow you to define specific search criteria to determine which signals can be considered peaks, excluding unwanted signals from the search.

If **Same as "Next Peak" Criteria** is selected, and either **Pk Excursion** or **Pk Threshold** are on, a signal must meet those criteria. If no valid peak is found, a message is generated and the marker is not moved. When **Highest Peak** is on, or both **Pk Excursion** and **Pk Threshold** are off, the marker is always placed at the point on the trace with the maximum y-axis value, even if that point is on the very edge of the trace (exception: negative frequencies and signals close to the LO are not searched at all).

Pressing Peak Search with the selected marker off causes the selected marker to be set to **Normal** at the center of the screen, then a peak search is immediately performed.

Pressing the front panel Peak Search key always does a peak search. Occasionally, you may need to get to the Peak Search menu key functions without doing a peak search. You can do this by first accessing the Peak Search menu. Then go to the other menus that you need to access. Finally, you can get back to the Peak Search key menu by using the front panel Return key and pressing it as many times as required to navigate back through the previously accessed menus until you get back to the Peak Search menu.

Remote Command	:CALCulate:MARKer [1] 2 3 4 5 6 7 8 9 10 11 12 :MAXimum
Example	CALC:MARK2:MAX performs a peak search using marker 2. CALC:MARK2:Y? queries the marker amplitude (Y-axis) value for marker 2. CALC:MARK2:X? queries the marker frequency or time (X-axis) value for marker 2. SYST:ERR? can be used to query the errors to determine if a peak is found. The error -200 will be returned after an unsuccessful search.
Remote Command Notes	Sending this command selects the subopcoded marker.

4.0.24 Next Peak

Pressing Next Peak moves the selected marker to the peak that has the next highest amplitude less than the marker's current value. Only peaks which meet all enabled peak criteria are considered. If there is no valid peak lower than the current marker position, an error is generated and the marker is not moved.

If the selected marker was off, then it is turned on as a normal marker and a peak search is performed.

Remote Command	:CALCulate:MARKer [1] 2 3 4 5 6 7 8 9 10 11 12 :MAXimum:N EXT
-----------------------	--

Example	CALC:MARK2:MAX:NEXT selects marker 2 and moves it to the peak that is closest in amplitude to the current peak, but the next lower value.
Remote Command Notes	Sending this command selects the subopcoded marker
State Saved	Not part of saved state
Key Path	Peak Search

4.0.25 Next Pk Right

Pressing Next Pk Right moves the selected marker to the nearest peak right of the current marker which meets all enabled peak criteria. If there is no valid peak to the right of the current marker position, an error is generated and the marker is not moved. If the selected marker was off, then it is turned on as a normal marker and a peak search is performed.

Remote Command	:CALCulate:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:MAXimum:RIGHT
Example	CALC:MARK2:MAX:RIGH selects marker 2 and moves it to the next peak to the right of the current marker position.
Remote Command Notes	Sending this command selects the subopcoded marker.
State Saved	Not part of saved state.
Key Path	Peak Search

4.0.26 Next Pk Left

Pressing Next Pk Left moves the selected marker to the nearest peak left of the current marker which meets all enabled peak criteria. If there is no valid peak to the left of the current marker position, an error is generated and the marker is not moved. If the selected marker was off, then it is turned on as a normal marker and a peak search is performed.

Remote Command	:CALCulate:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:MAXimum:LEFT
Example	CALC:MARK2:MAX:LEFT selects marker 2 and moves it to the next peak to the left of the current marker position.
State Saved	Not part of saved state.
Key Path	Peak Search

4.0.27 Marker Delta

Performs the same function as the Delta 1-of-N selection key in the Marker menu. Basically this sets the control mode for the selected marker to Delta mode. See the Marker section for the complete description of this function. The key is duplicated here in the Peak Search Menu to allow you to conveniently perform a peak search and change the marker's control mode to Delta without

having to access two separate menus.

Key Path	Peak Search or Marker
----------	------------------------------

4.0.28 Mkr->CF

Assigns the selected marker's frequency to the Center Frequency setting. See the Marker To section for the description of this function. The key is duplicated here in the Peak Search Menu to allow you to conveniently perform a peak search and marker to CF without having to access two separate menus.

Dependencies/Couplings	Same as specified under Marker To.
------------------------	------------------------------------

Key Path	Peak Search or Marker ->
----------	------------------------------------

4.0.29 Mkr->Ref Lvl

Assigns the selected marker's level to the Reference Level setting. See the Marker To section for the description of this function. The key is duplicated here in the Peak Search Menu to allow you to conveniently perform a peak search and marker to RL without having to access two separate menus.

Dependencies/Couplings	Same as specified under Marker To
------------------------	-----------------------------------

Key Path	Peak Search or Marker ->
----------	------------------------------------

4.0.30 Peak Criteria

Pressing this key opens the Peak Criteria menu and allows you to adjust the Pk Threshold and Pk Excursion parameters used for peak search functions.

For a signal to be identified as a peak it must meet certain criteria. Signals in the negative frequency range and signals very close to 0 Hz are ignored. If either the peak excursion or peak threshold functions are on, then the signal must satisfy those criteria before being identified as a peak.

When peak excursion and peak threshold are both off:

Peak Search, **Continuous Peak Search**, and the maximum part of **Pk-Pk Search** will search the trace for the point with the highest y-axis value which does not violate the LO feedthrough rules. A rising and falling slope are not required for these three peak search functions.

The remaining search functions **Next Peak**, **Next Pk Right**, and so forth, will only consider trace points which have a rising and falling slope on the left and right respectively.

Key Path	Peak Search
----------	--------------------

4.0.30.1 "Peak Search" Criteria

This menu lets you decide what kind of search you want to do when the Peak Search key is pressed

(or the equivalent SCPI command sent).

There are two “types” of peak search functions. One type is the “Peak Search” type, the other type is the “Next Peak” type. “Next Peak” searches (for example, Next Peak, Next Pk Left, Next Pk Right) are always checked using the Excursion and Threshold criteria as long as these criteria are On. The “Peak Search” type of search, simply finds the highest point on the trace. However you can change the “Peak Search” type of search so that it also uses the Excursion and Threshold criteria. This allows you to find the Maximum point on the trace that also obeys the Excursion and/or Threshold criteria.

When **Highest Peak** is selected, pressing **Peak Search** simply finds the highest peak on the marker’s trace. If **Same as “Next Peak” Criteria** is selected, then the search is also forced to consider the Excursion and Threshold found under the **“Next Peak” Criteria** menu.

Remote Command	:CALCulate:MARKer:PEAK:SEARch:MODE MAXimum PARAmeter :CALCulate:MARKer:PEAK:SEARch:MODE?
Remote Command Notes	MAXimum corresponds to the Highest Peak setting. PARAmeter corresponds to the Same as “Next Peak” Criteria setting.
Preset	MAXimum
State Saved	Saved in state
Key Path	Peak Search, Peak Criteria

4.0.30.1.1 Highest Peak

When this key is selected, pressing the Peak Search key or issuing the equivalent SCPI command finds the maximum point on the trace, subject to the peak-search qualifications. This also affects the Peak Search half of Pk-Pk search and the Continuous Peak Search.

Example	CALC:MARK:PEAK:SEAR:MODE MAX
Remote Command Notes	See
Key Path	Peak Search, Peak Criteria, “Peak Search” Criteria

4.0.30.1.2 Same as “Next Peak” Criteria

When this key is selected, pressing the Peak Search key or issuing the equivalent SCPI command finds the maximum point on the trace, but subject to the Excursion and Threshold set under the Next Peak Criteria menu. The search is, of course, also subject to the peak-search qualifications. This also affects the Peak Search half of Pk-Pk search and the Continuous Peak Search.

Example	CALC:MARK:PEAK:SEAR:MODE PAR
Remote Command Notes	See
Key Path	Peak Search, Peak Criteria, “Peak Search” Criteria

4.0.30.2 “Next Peak” Criteria

This key opens a menu which allows you to independently set the Peak Excursion and Peak Threshold and turn them on and off.

Key Path **Peak Search, Peak Criteria**

4.0.30.2.1 Pk Excursion On/Off

Turns the peak excursion requirement On/Off and sets the excursion value. The value defines the minimum amplitude variation (rise and fall) required for a signal to be identified as peak. For example, if a value of 6 dB is selected, peak search functions like the marker Next Pk Right function move only to peaks that rise and fall 6 dB or more.

When both Pk Excursion and Pk Threshold are on, a signal must rise above the Pk Threshold value by at least the **Peak Excursion** value and then fall back from its local maximum by at least the **Peak Excursion** value to be considered a peak.

NOTE In the event that a sequence of trace points with precisely the same values represent the maximum, the left-most point is found.

Remote Command	:CALCulate:MARKer:PEAK:EXCursion <rel_ampl> :CALCulate:MARKer:PEAK:EXCursion?
Example	:CALC:MARK:PEAK:EXC:STAT ON :CALC:MARK:PEAK:EXC 30 DB sets the minimum peak excursion requirement to 30 dB.
Dependencies/Couplings	Available only when Y axis unit is amplitude units, otherwise grayed out. Whenever you adjust the value of Pk Excursion (with the knob, step keys, or by completing a numeric entry), and Peak Threshold is turned ON, the Peak Threshold Line and the Peak Excursion Region are displayed.
Preset	6.0 dB ON
State Saved	Saved in State.
Min	0.0 dB
Max	100.0 dB
Key Path	Peak Search, Peak Criteria, “Next Peak” Criteria

If two signals are very close together and the peak excursion and threshold criteria are met at the outside edges of the combined signals, this function finds the highest of these two signals as a peak (or next peak). However, if a signal appears near the edge of the screen such that the full extent of either the rising or falling edge cannot be determined, and the portion that is on screen does not

meet the excursion criteria, then the signal cannot be identified as a peak.

When measuring signals near the noise floor, you can reduce the excursion value even further to make these signals recognizable. To prevent the marker from identifying noise as signals, reduce the noise floor variations to a value less than the peak-excursion value by reducing the video bandwidth or by using trace averaging.

4.0.30.2.2 Pk Threshold On/Off

Turns the peak threshold requirement On/Off and sets the threshold value. The peak threshold value defines the minimum signal level (or min threshold) that the peak identification algorithm uses to recognize a peak.

When both Pk Excursion and Pk Threshold are on, a signal must rise above the Pk Threshold value by at least the **Peak Excursion** value and then fall back from its local maximum by at least the **Peak Excursion** value to be considered a peak.

For example, if a threshold value of -90 dBm is selected, the peak search algorithm will only consider signals with amplitude greater than the -90 dBm threshold. If a threshold value of -90 dBm is selected, and **Peak Excursion** is **On** and set to 6 dB, the peak search algorithm will only consider signals with amplitude greater than the -90 dBm threshold which rise 6 dB above the threshold and then fall back to the threshold.


Remote Command	:CALCulate:MARKer:PEAK:THReshold <ampl> :CALCulate:MARKer:PEAK:THReshold?
Example	CALC:MARK:PEAK:THR:STAT ON turns on the threshold criterion. CALC:MARK:PEAK:THR -60 dBm sets the threshold to -60 dBm.
Dependencies/Couplings	When Ref Level Offset changes, Peak Threshold must change by the same amount.
Preset	-90.0 dBm ON
State Saved	Saved in State
Min	-200 dBm
Max	The current displayed Ref Level. This means the current Ref Level, offset by the Ref Level Offset.
Key Path	Peak Search, Peak Criteria, "Next Peak Criteria"
Default Unit	Depends on the current selected Y axis unit, see section.

4.0.30.2.3 Pk Threshold Line On/Off

Turns the peak threshold line on or off. Preset state is off. No equivalent SCPI command.

The Peak Threshold line is green and has the value of the peak threshold (for example, -20.3 dBm) written above its right side, above the line itself. If Peak Excursion is ON it shows on the left side

as a region above the Peak Threshold line. As with all such lines (Display Line, Trigger Level line, etc) it is drawn on top of all traces.



This function is automatically set to ON (thus turning on the Peak Threshold line) whenever the value of Peak Threshold or Peak Excursion becomes the active function, unless Peak Threshold is OFF. It is automatically set to OFF whenever Peak Threshold is set to OFF. Manually turning it ON automatically turns on Pk Threshold.

The Peak Excursion part is on whenever the Pk Threshold part is on, unless Peak Excursion is OFF.

Dependencies/Couplings If Peak Threshold is Off and the Peak Threshold line is turned On, it should turn on Peak Threshold.

Key Path **Peak Search, Peak Criteria, “Next Peak Criteria”**

4.0.31 Peak Table

Opens the Peak Table menu.

The Peak Table provides a displayed list of up to 20 signal peaks from the selected trace. If more than one trace window is displayed, the selected trace in the selected window is used. If there are more than 20 signals which meet the peak search criteria, only the 20 highest peaks are listed.

The Peak Table is updated after each sweep. The list of peaks in the Peak Table can be ordered either by ascending frequency or by descending amplitude. In either case, the entire trace is first evaluated and the 20 highest peaks are selected for inclusion in the list. After the peaks are

selected, they are then sorted and displayed according to the Peak Sort setting.

Key Path **Peak Search**

4.0.31.1 Peak Table On/Off

Turns Peak Table On/Off. When turned On, the display is split into a measurement window and a peak table display window. Turning the Peak Table on turns the Marker Table off and vice versa.

Remote Command :CALCulate:MARKer:PEAK:TABLE:STATE OFF|ON|0|1
 :CALCulate:MARKer:PEAK:TABLE:STATE?

Example CALC:MARK:PEAK:TABL:STAT ON turns on and displays the peak table.

Preset OFF

State Saved Saved in State.

Key Path **Peak Search, Peak Table**

4.0.31.2 Peak Sort

Sets the peak table sorting routine to list the peaks in order of descending amplitude or ascending frequency. The remote command can also be used to sort the peaks found using the :CALCulate:DATA:PEAKs command.

Remote Command :CALCulate:MARKer:PEAK:SORT FREQuency|AMPLitude
 :CALCulate:MARKer:PEAK:SORT?

Example CALC:MARK:PEAK:SORT AMPL sets the sorting routine to list peaks in order of descending amplitude.
 CALC:MARK:PEAK:SORT?

Preset AMPLitude

State Saved Saved in State.

Key Path **Peak Search, Peak Table**

4.0.31.3 Peak Readout

Shows up to twenty signal peaks as defined by the setting:

All (ALL) - lists all the peaks defined by the peak criteria, in the current sort setting.

Above Display Line (GTDLine) - lists the peaks that are greater than the defined display line, and that meet the peak criteria. They are listed in the current sort order.

Below Display Line (LTDLine) - lists the peaks that are less than the defined display line, and that meet the peak criteria. They are listed in the current sort order.

If the peak threshold is defined and turned on, then the peaks must meet this peak criteria in

addition to the display line requirements.

Remote Command	:CALCulate:MARKer:PEAK:TABLE:READout ALL GTDLine LTDLine :CALCulate:MARKer:PEAK:TABLE:READout?
Example	CALC:MARK:PEAK:TABL:READ GTDL
Dependencies/Couplings	Turning Display Line off forces Readout to ALL.
Preset	All
State Saved	Saved in State
Key Path	Peak Search, Peak Table

If the Display Line (see View/Display Section) is turned on, the Peak Table can be selected to include all peaks, only those above the Display Line, or only those below the Display Line. See Figures 1-2 and 1-3 to understand what happens if both Display Line and Pk Threshold are turned on.




Figure 1- 2 Above Display Line Peak Identification




Figure 1- 3 Below Display Line Peak Identification

4.0.31.3.1 All

Sets the peak table to display the 20 highest peaks in the order specified by the current Peak Sort

setting. If the Peak Criteria are turned on, then only peaks that meet the defined Pk Excursion and Pk Threshold values will be found.

Example	CALC:MARK:PEAK:TABL:READ ALL
Remote Command Notes	See the Peak Readout section
Key Path	Peak Search, Peak Table, Peak Readout

4.0.31.3.2 Above Display Line

Sets the peak table to display only the 20 highest peaks above the display line in the order specified by the current Sort setting. If the Peak Criteria are turned on, then only peaks that meet the defined criteria will be found. If the display line is not already on, it is turned on (it has to be on or it cannot be used to exclude peaks).

Example	CALC:MARK:PEAK:TABL:READ GTDL
Remote Command Notes	See the Peak Readout section
Key Path	Peak Search, Peak Table, Peak Readout

4.0.31.3.3 Below Display Line

Sets the peak table to display only the 20 highest peaks below the display line as defined by the peak in the order specified by the current Sort setting. If the Peak Criteria are turned on, then only peaks that meet the defined criteria will be found. If the display line is not already on, it is turned on (it has to be on or it cannot be used to exclude peaks).

Example	CALC:MARK:PEAK:TABL:READ LTDL
Remote Command Notes	See the Peak Readout section
Key Path	Peak Search, Peak Table, Peak Readout

4.0.32 Continuous Peak Search On/Off

Turns Continuous Peak Search on or off. When Continuous Peak Search is on, a peak search is automatically performed for the selected marker after each sweep. The rules for finding the peak are exactly the same as for **Peak Search**, including the use of the peak criteria rules. If no valid peak is found, a warning is generated after each sweep.

When Continuous Peak Search is turned on a peak search is immediately performed and then is repeated after each sweep. If Continuous Peak Search is turned on with the selected marker off, the selected marker is set to **Normal** at the center of the screen, and then a peak search is immediately performed and subsequently repeated after each sweep.

When in Continuous Peak Search, *OPC will not return true, nor will READ or MEASure return any data, until the sweep is complete and the marker has been re-peaked. If the box is in a measurement such as averaging, and Continuous Peak Search is on, the entire measurement will be allowed to complete (for example, all the averages taken up to the average number) before the re-peak takes place, and only THEN will *OPC go true and READ or MEASure return data.

This function is not the “Continuous Peak” function found in some other instruments. That function was designed to track the signal; this function simply does a Peak Search after each sweep.

When Continuous Peak Search is turned on for a marker, a little “hat” is placed above the marker.

Remote Command	:CALCulate:MARKer [1] 2 3 4 5 6 7 8 9 10 11 12 :CPSearch [:STATe] ON OFF 1 0 :CALCulate:MARKer [1] 2 3 4 5 6 7 8 9 10 11 12 :CPSearch [:STATe] ?
Example	CALC:MARK:CPS ON Turns on Continuous Peak Search.
Dependencies/Couplings	The Continuous Peak Search key is grayed out when the selected marker is a Fixed marker. Also, if Continuous Peak Search is on and the selected marker becomes a fixed marker, then Continuous Peak Search is turned off and the key grayed out. Signal Track and Continuous Peak Search are mutually exclusive so if Signal Track is on, Continuous Peak Search will be grayed out and vice versa.
Remote Command Notes	Sending this command selects the subopcoded marker.
Preset	Mode Preset
State Saved	Saved in State
Key Path	Peak Search
SCPI Status Bits/OPC Dependencies	The Measuring bit should remain set while this command is operating and should not go false until the marker position has been updated.

4.0.33 Pk-Pk Search

Finds and displays the amplitude and frequency (or time, if in zero span) differences between the highest and lowest y-axis value. It places the selected marker on the minimum value on its selected trace and places that marker’s reference marker on the peak of its selected trace. This function turns on the reference marker and sets its mode to **Fixed** if it is not already on. (These markers may be on two different traces.)

The rules for finding the maximum peak are exactly the same as for **Peak Search**, including the use of the peak criteria rules. However, the minimum trace value is not required to meet any criteria other than being the minimum y-axis value in the trace.

When Pk-Pk Search is successful, a message is displayed on the message line.

If the selected marker is off, a delta type marker is turned on and the peak-to-peak search is done. If the selected marker is on, but it is not a delta marker, then it is changed to delta which turns on the reference marker if needed, and then it performs the peak-to-peak function.

Remote Command	:CALCulate:MARKer [1] 2 3 4 5 6 7 8 9 10 11 12 :PTPeak
-----------------------	--

Example	CALC:MARK:PTP CALC:MARK:Y? queries the delta amplitude value for marker 1.
Dependencies/Couplings	Pk-Pk Search is not available (key is grayed out) when Coupled Markers is on. Selected marker becomes a delta marker if not already in delta mode.
Remote Command Notes	Sending this command selects the subopcoded marker.
State Saved	Not part of saved state.
Key Path	Peak Search

4.0.34 Min Search

Moves the selected marker to the minimum y-axis value on the current trace. Minimum (negative) peak searches do not have to meet the peak search criteria. It just looks for the lowest y-axis value. If the selected marker is Off, it is turned on before the minimum search is performed.

Remote Command	:CALCulate:MARKer [1] 2 3 4 5 6 7 8 9 10 11 12 :MINimum
Example	CALC:MARK:MIN selects marker 1 and moves it to the minimum amplitude value.
Remote Command Notes	Sending this command selects the subopcoded marker.
State Saved	Not part of saved state.
Key Path	Peak Search

4.0.35 Peak Data Query (SCPI Command Only)

CALC:DATA[n]:PEAK? returns a list of all the peaks for the currently selected measurement and subopcode.

n = any valid subopcode for the current measurement.

Sub-opcode 0 is not valid for :CALCulate:DATA:PEAKs. If subopcode 0 is sent, an error is generated.

This command uses the data setting specified by the FORMat:BORDER and FORMat:DATA commands and can return real or ASCII data. If the format is set to INT,32 it returns REAL,32 data.

The Peak Data Query command has four types of parameters:

- Threshold (in dBm),
- Excursion (in dB)
- Sorting order (amplitude, frequency, time)

- Display line use (all, >display line, <display line)

Remote Command :CALCulate:DATA[1] | 2 | 3 | 4 | 5 | 6:PEAKs?
<real>, <real> [, AMPLitude | FREQuency | TIME [, ALL | GTDLine | LTDLine]]

Example CALC:DATA4:PEAK? -40,10,FREQ,GTDL This will identify the peaks of trace 4 that are above -40 dBm, with excursions of at least 10 dB. The peaks are returned in order of increasing frequency, starting with the lowest frequency. Only the peaks that are above the display line are returned.

Query Results 1:

With FORMat:DATA REAL,32 selected, it returns a list of floating-point numbers. The first value in the list is the number of peak points that are in the following list. A peak point consists of two values: a peak amplitude followed by the its corresponding frequency (or time).

If no peaks are found the peak list will consist of only the number of peaks, (0).

Dependencies/Couplings Values must be provided for threshold and excursion. The sorting and display line parameters are optional (defaults are AMPLitude and ALL).

There is always a Y-axis value for the display line, regardless of whether the display line state is on or off. It is the current Y-axis value of the display line which is used by this command to determine whether a peak should be reported.

Remote Command Notes

<n> - is the trace that will be used

<threshold> - is the level below which trace data peaks are ignored. The threshold value is required and is always used as a peak criterion. To effectively disable the threshold criterion for this command, provide a substantially low threshold value such as -200 dBm. The threshold value used in this command is independent of and has no effect on the threshold value stored under the Peak Criteria menu.

<excursion> - is the minimum amplitude variation (rise and fall) required for a signal to be identified as peak. The excursion value is required and is always used as a peak criterion. To effectively disable the excursion criterion for this command, provide the minimum value of 0.0dB. The excursion value used in this command is independent of and has no effect on the excursion value stored under the Peak Criteria menu.

Sorting order:

AMPLitude - lists the peaks in order of descending amplitude, with the highest peak first (default if optional parameter not sent).

FREQuency - lists the peaks in order of occurrence, left to right across the x-axis.

TIME - lists the peaks in order of occurrence, left to right across the x-axis.

Peaks vs. Display Line:

ALL - lists all of the peaks found (default if optional parameter not sent).

GTDLine (greater than display line) - lists all of the peaks found above the display line.

LTDLine (less than display line) - lists all of the peaks found below the display line.

Some of the content described in this section is not directly applicable to the IQ Analyzer Mode. This is common MXA functionality information that can be used as reference material. It provides additional information about some of the unique features that are available in the measurements in this mode.

Meas

For key and remote command information on each measurement, refer to the section which describes the measurement of interest.

Measurements available under the **Meas** key are specific to the current Mode.

When viewing Help for measurements, note the following:

NOTE You cannot get help for a measurement by pressing one of the measurement softkeys. One way to get help for a measurement is through the Help table of contents, which contains a book for each measurement. To see help for a measurement, click its book in the table of contents. For example, click the "ACP Measurement" book in the table of contents to display help for the ACP measurement.

NOTE Operation for some keys differ between measurements. The information displayed in Help pertains to the current measurement. To see how a key operates in a different measurement, exit Help (press the Cancel/Esc key), select the measurement, then reenter Help (press the Help key) and press that key.

Key Path

Front-panel key

Command Interactions: MEASure, CONFigure, FETCh, INITiate and READ

Each one-button measurement has a group of commands that work together to make the measurement fast, but flexible.

Figure 5-1 Measurement Group of Commands




Table 5-1

Measure Commands:

:MEASure:<measurement> [n] ?

This is a fast single-command way to make a measurement using the factory default instrument settings. These are the settings and units that conform to the Mode Setup settings (e.g. radio standard) that you have currently selected.

- Stops the current measurement (if any) and sets up the instrument for the specified measurement using the factory defaults
- Initiates the data acquisition for the measurement
- Blocks other SCPI communication, waiting until the measurement is complete before returning results.
- If the function does averaging, it is turned on and the number of averages is set to 10.
- After the data is valid it returns the scalar results, or the trace data, for the specified measurement. The type of data returned may be defined by an [n] value that is sent with the command.

The scalar measurement results will be returned if the optional [n] value is not included, or is set to 1. If the [n] value is set to a value other than 1, the selected trace data results will be returned. See each command for details of what types of scalar results or trace data results are available.

ASCII is the default format for the data output. (Older versions of Spectrum Analysis and Phase Noise mode measurements only use ASCII.) The binary data formats should be used for handling large blocks of data since they are smaller and faster than the ASCII format. Refer to the FORMat:DATA command for more information.

If you need to change some of the measurement parameters from the factory default settings you can set up the measurement with the CONFigure command. Use the commands in the SENSE:<measurement> and CALCulate:<measurement> subsystems to change the settings. Then you can use the READ? command to initiate the measurement and query the results.

If you need to repeatedly make a given measurement with settings other than the factory defaults, you can use the commands in the SENSE:<measurement> and CALCulate:<measurement> subsystems to set up the measurement. Then use the READ? command to initiate the measurement and query results.

Measurement settings persist if you initiate a different measurement and then return to a previous one. Use READ:<measurement>? if you want to use those persistent settings. If you want to go back to the default settings, use MEASure:<measurement>?.

Table 5-1

Configure Commands:
<p>:CONFigure: <measurement></p> <p>This command stops the current measurement (if any) and sets up the instrument for the specified measurement using the factory default instrument settings. It sets the instrument to single measurement mode but should not initiate the taking of measurement data unless INIT:CONTinuous is ON. If you change any measurement settings after using the CONFigure command, the READ command can be used to initiate a measurement without changing the settings back to their defaults. In Spectrum Analysis mode the CONFigure command also turns the averaging function on and sets the number of averages to 10 for all measurements.</p> <p>The CONFigure? query returns the current measurement name.</p>
Fetch Commands:
<p>:FETCh: <measurement> [n] ?</p> <p>This command puts selected data from the most recent measurement into the output buffer. Use FETCh if you have already made a good measurement and you want to return several types of data (different [n] values, e.g. both scalars and trace data) from a single measurement. FETCh saves you the time of re-making the measurement. You can only FETCh results from the measurement that is currently active, it will not change to a different measurement. An error is reported if a measurement other than the current one, is specified.</p> <p>If you need to get new measurement data, use the READ command, which is equivalent to an INITiate followed by a FETCh.</p> <p>The scalar measurement results will be returned if the optional [n] value is not included, or is set to 1. If the [n] value is set to a value other than 1, the selected trace data results will be returned. See each command for details of what types of scalar results or trace data results are available. The binary data formats should be used for handling large blocks of data since they are smaller and transfer faster than the ASCII format. (FORMat:DATA)</p> <p>FETCh may be used to return results other than those specified with the original READ or MEASure command that you sent.</p>

INITiate Commands:
<p>:INITiate:<measurement></p> <p>This command is not available for measurements in all the instrument modes:</p> <ul style="list-style-type: none"> • Initiates a trigger cycle for the specified measurement, but does not output any data. You must then use the FETCh<meas> command to return data. If a measurement other than the current one is specified, the instrument will switch to that measurement and then initiate it. <p>For example, suppose you have previously initiated the ACP measurement, but now you are running the channel power measurement. If you send INIT:ACP? it will change from channel power to ACP and will initiate an ACP measurement.</p> <ul style="list-style-type: none"> • Does not change any of the measurement settings. For example, if you have previously started the ACP measurement and you send INIT:ACP? it will initiate a new ACP measurement using the same instrument settings as the last time ACP was run. • If your selected measurement is currently active (in the idle state) it triggers the measurement, assuming the trigger conditions are met. Then it completes one trigger cycle. Depending upon the measurement and the number of averages, there may be multiple data acquisitions, with multiple trigger events, for one full trigger cycle. It also holds off additional commands on GPIB until the acquisition is complete.
READ Commands:
<p>:READ:<measurement> [n] ?</p> <ul style="list-style-type: none"> • Does not preset the measurement to the factory default settings. For example, if you have previously initiated the ACP measurement and you send READ:ACP? it will initiate a new measurement using the same instrument settings. • Initiates the measurement and puts valid data into the output buffer. If a measurement other than the current one is specified, the instrument will switch to that measurement before it initiates the measurement and returns results. <p>For example, suppose you have previously initiated the ACP measurement, but now you are running the channel power measurement. Then you send READ:ACP? It will change from channel power back to ACP and, using the previous ACP settings, will initiate the measurement and return results.</p> <ul style="list-style-type: none"> • Blocks other SCPI communication, waiting until the measurement is complete before returning the results <p>If the optional [n] value is not included, or is set to 1, the scalar measurement results will be returned. If the [n] value is set to a value other than 1, the selected trace data results will be returned. See each command for details of what types of scalar results or trace data results are available. The binary data formats should be used when handling large blocks of data since they are smaller and faster than the ASCII format. (FORMat:DATA)</p>

Current Measurement Query (Remote Command Only)

This command returns the name of the measurement that is currently running.

Remote Command:

:CONFigure?

Example: CONF?

Test current results against all limits (Remote Command Only)

Queries the status of the current measurement limit testing. It returns a 0 if the measured results pass when compared with the current limits. It returns a 1 if the measured results fail any limit tests.

Mode	WCDMA
Remote Command	:CALCulate:CLIMits:FAIL?
Range	0 1

Data Query (Remote Command Only)

Returns the designated measurement data for the currently selected measurement and subopcode.

n = any valid subopcode for the current measurement. See Remote command results in each measurement section for information on the data that can be returned for each measurement.

Mode	WCDMA
Remote Command	:CALCulate:DATA[n]? <real>,...
Notes	The return trace depends on the measurement. In CALCulate:DATA[n], n is any valid subopcode for the current measurement.

Calculate/Compress Trace Data Query (Remote Command Only)

:CALCulate:DATA<n>:COMPRESS?

BLOCK | CFIT | MAXimum | MINimum | MEAN | DMEan | RMS | SAMPLE | SDEViation | PPHase
[,<soffset>[,<length>[,<roffset>[,<rlimit>]]]]

Returns compressed data for the specified trace data. The data is returned in the same units as the original trace and only works with the currently selected measurement. The command is used with a subopcode <n> since measurements usually return several types of trace data. See the following

table for the subopcodes for the trace data names that are available in each measurement. For subopcodes that return scalar data use the :CALCulate:DATA [n] ? command above.

This command is used to compress or decimate a long trace to extract and return only the desired data. A typical example would be to acquire N frames of GSM data and return the mean power of the first burst in each frame. The command can also be used to identify the best curve fit for the data.

- BLOCk or block data - returns all the data points from the region of the trace data that you specify. For example, it could be used to return the data points of an input signal over several timeslots, excluding the portions of the trace data that you do not want.
- CFIT or curve fit - applies curve fitting routines to the data. <soffset> and <length> are required to define the data that you want. <roffset> is an optional parameter for the desired order of the curve equation. The query will return the following values: the x-offset (in seconds) and the curve coefficients ((order + 1) values).

MAX, MEAN, MIN, RMS, SAMP, SDEV and PPH return one data value for each specified region (or <length>) of trace data, for as many regions as possible until you run out of trace data (using <roffset> to specify regions). Or they return the number regions you specify (using <rlimit>) ignoring any data beyond that.

- MAXimum - returns the maximum data point for the specified region(s) of trace data. For I/Q trace data, the maximum magnitude of the I/Q pairs is returned.
- MEAN - returns the arithmetic mean of the data point values for the specified region(s) of trace data. See “Mean Value of I/Q Data Points for Specified Region(s)” on page 304. For I/Q trace data, the mean of the magnitudes of the I/Q pairs is returned. See “Mean Value of I/Q Data Pairs for Specified Region(s)” on page 304.

Note: If the original trace data is in dB, this function returns the arithmetic mean of those log values, not log of the mean power, which is a more useful value.

Equation 5-1 Mean Value of I/Q Data Points for Specified

$$\text{Region(s)MEAN} = \frac{1}{n} \sum_{X_i \in \text{region(s)}} X_i$$

where X_i is a data point value, and n is the number of data points in the specified region(s).

Equation 5-2 Mean Value of I/Q Data Pairs for Specified

$$\text{Region(s)MEAN} = \frac{1}{n} \sum_{X_i \in \text{region(s)}} |X_i|$$

where $|X_i|$ is the magnitude of an I/Q pair, and n is the number of I/Q pairs in the specified region(s).

- **MINimum** - returns the minimum data point for the specified region(s) of trace data. For I/Q trace data, the minimum magnitude of the I/Q pairs is returned.
- **RMS** - returns the arithmetic rms of the data point values for the specified region(s) of trace data. See [“RMS Value of Data Points for Specified Region\(s\)” on page 305](#).

For I/Q trace data, the rms of the magnitudes of the I/Q pairs is returned. See [“RMS Value of I/Q Data Pairs for Specified Region\(s\)” on page 305](#).

Note: This function is very useful for I/Q trace data. However, if the original trace data is in dB, this function returns the rms of the log values which is not usually needed.

Equation 5-3 RMS Value of Data Points for Specified Region(s)

$$\text{RMS} = \sqrt{\frac{1}{n} \sum_{X_i \in \text{region}(s)} X_i^2}$$

where X_i is a data point value, and n is the number of data points in the specified region(s).

Equation 5-4 RMS Value of I/Q Data Pairs for Specified Region(s)

$$\text{RMS} = \sqrt{\frac{1}{n} \sum_{X_i \in \text{region}(s)} X_i X_i^*}$$

where X_i is the complex value representation of an I/Q pair, X_i^* its conjugate complex number, and n is the number of I/Q pairs in the specified region(s).

Once you have the rms value for a region of I/Q trace data, you may want to calculate the mean power. You must convert this rms I/Q value (peak volts) to power in dB.

$$10 \times \log[10 \times (\text{rms value})^2]$$

- **SAMple** - returns the first data value for the specified region(s) of trace data. For I/Q trace data, the first I/Q pair is returned.
- **SDEViation** - returns the arithmetic standard deviation for the data point values for the specified region(s) of trace data. See [“Standard Deviation of Data Point Values for Specified Region\(s\)” on page 305](#).

For I/Q trace data, the standard deviation of the magnitudes of the I/Q pairs is returned. See [“Standard Deviation of I/Q Data Pair Values for Specified Region\(s\)” on page 306](#).

Equation 5-5 Standard Deviation of Data Point Values for Specified

$$\text{Region}(s)\text{SDEV} = \sqrt{\frac{1}{n} \sum_{X_i \in \text{region}(s)} (X_i - \bar{X})^2}$$

where X_i is a data point value, \bar{X} is the arithmetic mean of the data point values for the specified region(s), and n is the number of data points in the specified region(s).

Equation 5-6 Standard Deviation of I/Q Data Pair Values for Specified

$$\text{Region(s)SDEV} = \sqrt{\frac{1}{n} \sum_{X_i \in \text{region(s)}} (|X_i| - \bar{X})^2}$$

where $|X_i|$ is the magnitude of an I/Q pair, \bar{X} is the mean of the magnitudes for the specified region(s), and n is the number of data points in the specified region(s).

- PPH - returns the pairs of rms power (dBm) and arithmetic mean phase (radian) for every specified region and frequency offset (Hz). The number of pairs is defined by the specified number of regions.

Assuming this command can be used for I/Q vector (n=0) in Waveform (time domain) measurement and all parameters are specified by data point in PPH.

The rms power of the specified region may be expressed as:

$$\text{Power} = 10 \times \log [10 \times (\text{RMS I/Q value})] + 10$$

The RMS I/Q value (peak volts) =

$$\sqrt{\frac{1}{n} \sum_{X_i \in \text{region}} X_i X_i^*}$$



where X_i is the complex value representation of an I/Q pair, X_i^* its conjugate complex number, and n is the number of I/Q pairs in the specified region.

The arithmetic mean phase of the specified region may be expressed as:

$$\text{Phase} = \frac{1}{n} \sum_{Y_i \in \text{region}} Y_i$$

Where Y_i is the unwrapped phase of I/Q pair with applying frequency correction and n is the number of I/Q pairs in the specified region.

The frequency correction is made by the frequency offset calculated by the arithmetic mean of every specified region's frequency offset. Each frequency offset is calculated by the least square method against the unwrapped phase of I/Q pair.

Figure 5-2 Sample Trace Data - Constant Envelope**Figure 5-3 Sample Trace Data - Not Constant Envelope**

<soffset> - start offset is an optional real number (in seconds). It specifies the amount of data at the beginning of the trace that will be ignored before the decimation process starts. It is the time from the start of the trace to the point where you want to start using the data. The default value is zero.

<length> - is an optional real number (in seconds). It defines how much data will be compressed into one value. This parameter has a default value equal to the current trace length.

<roffset> - repeat offset is an optional real number (in seconds). It defines the beginning of the next field of trace elements to be compressed. This is relative to the beginning of the previous field. This parameter has a default value equal to the <length> variable.

<rlimit> - repeat limit is an optional integer. It specifies the number of data items that you want returned. It will ignore any additional items beyond that number. You can use the Start offset and the Repeat limit to pick out exactly what part of the data you want to use. The default value is all the data.

Example: To query the mean power of a set of GSM bursts:

1. Set the waveform measurement sweep time to acquire at least one burst.
2. Set the triggers such that acquisition happens at a known position relative to a

Meas

burst.

3. Then query the mean burst levels using, **CALC:DATA2:COMP?**
MEAN, 24e-6, 526e-6 (These parameter values correspond to GSM signals, where 526e-6 is the length of the burst in the slot and you just want 1 burst.)

Remarks: The optional parameters must be entered in the specified order. For example, if you want to specify <length>, you must also specify <soffset>.

This command uses the data in the format specified by **FORMat:DATA**, returning either binary or ASCII data.

Calculate peaks of trace data (Remote Command Only)

Returns a list of peaks for the designated trace data *n* for the currently selected measurement. The peaks must meet the requirements of the peak threshold and excursion values. The command can only be used with specific [*n*] (subopcode) values, for measurement results that are trace, or scalar, data. See the remote command section of each measurement for the appropriate subopcodes. Both real and complex traces can be searched, but complex traces are converted to magnitude in dBm. Subopcode *n*=0, is the raw trace data which cannot be searched for peaks. Subopcode *n*=1, is the scalar data which also cannot be searched for peaks.

Mode	WCDMA
Remote Command	:CALCulate:DATA [<i>n</i>] :PEAKs? <threshold>, <excursion> [, AMPLitude FREQuency TIME]
Notes	The return trace depends on the measurement.

Meas Setup

The Meas Setup key displays the menu keys that allow you to control the parameters for the current measurement. Descriptions and remote commands for these keys are located under the specific section for the measurement of interest.

Key Path

Front-Panel key

Mode

Modes, also known as applications in MXA, are a collection of measurement capabilities packaged together to provide you with a personality specific to your measurement needs. In MXA, each mode has a Model Number and is an individually licensed application.

NOTE To change Modes, when you are consulting Help in the analyzer, you must first exit Help (by pressing the Cancel (Esc) key) and then select the mode of interest.

When viewing Help for modes, note the following:

NOTE You cannot get help for the current mode by pressing one of the mode softkeys. Each mode is described below.

NOTE Operation for some keys differ between modes. The information displayed in Help pertains to the current mode. To see how a key operates in a different mode, exit Help (press the Cancel/Esc key), select the mode, then reenter Help (press the Help key) and press that key.

Mode	All
Remote Command	:INSTrument [:SElect] SA BASIC WCDMA WIMAXOFDMA :INSTrument [:SElect] ?
Example	:INST SA
Remote Command Notes	The available parameters are dependent upon installed and licensed applications resident in the instrument. Parameters given here are an example, specific parameters are in the PD for the individual Application. Once an instrument mode is selected, only the commands that are valid for that mode can be executed.
Preset	Not affected by Preset. Set to SA following Restore System Defaults if SA is the default mode.
State Saved	Saved in instrument state.
Key Path	Mode

Activates a menu for selection of the measurement mode of the analyzer. The default measurement mode is the 1st listing in the menu. Only licensed and installed measurement modes are displayed.

Mode

A list of the valid mode choices is returned with the INST:CAT? Query.

Once an instrument mode is selected, only the commands that are valid for that mode can be executed.

Mode	All
Example	:INST 'SA'
Remote Command Notes	NOTE: The query is not a quoted string. It is an enumeration as indicated in the Instrument Select table above.

The command must be sequential: i.e. continued parsing of commands cannot proceed until the instrument select is complete and the resultant SCPI trees are available.

Application Mode Number Selection (Remote command only)

Select the measurement mode by its mode number. The actual available choices depend upon which applications are installed in your instrument.

Mode	:INSTrument:NSElect value	:INSTrument[:SElect] parameter
Spectrum Analyzer	1	SA
WCDMA	9	WCDMA
I/Q Analyzer (Basic)	8	BASIC
Wimax OFDMA	75	WIMAXOFDMA

Mode	All
Remote Command	:INSTrument:NSElect <integer> :INSTrument:NSElect?
Example	:INST:NSEL 1

Remote Command Notes	SA mode is 1
	The command must be sequential: i.e. continued parsing of commands cannot proceed until the instrument select is complete and the resultant SCPI trees are available.
Preset	Not affected by Preset. Set to default mode (1 for MXA) following Restore System Defaults.
State Saved	Saved in instrument state.

Application Mode Catalog Query (Remote command only)

Returns a string containing a comma separated list of names of all the installed and licensed measurement modes (applications). These names can only be used with the :INSTrument[:SElect] command.

Mode	All
Remote Command	:INSTrument :CATalog?
Example	:INST:CAT?
Remote Command Notes	Query returns a quoted string of the installed and licensed modes separated with a comma. Example: "SA,BASIC,WCDMA"

Application Identification (Remote commands only)

Each entry in the Mode Menu will have a Model Number and associated information: Version, and Options.

This information is displayed in the Show System screen. The corresponding SCPI is defined here.

Current Application Model

Returns a string which is the Model Number of the currently selected application (mode).

Mode	All
Remote Command	:SYSTem:APPLication[:CURRent] [:NAME] ?
Example	:SYST:APPL?

Mode

Remote Command Notes	Query returns a quoted string which is the Model Number of the currently selected application (Mode). Example: "N9060A" String length is 6 characters.
Preset	Not affected by Preset
State Saved	Not saved in state per se, value will be the selected application when Save is invoked

Current Application Revision

Returns a string which is the Revision of the currently selected application (mode).

Mode	All
Remote Command	:SYSTem:APPLication[:CURRent]:REVision?
Example	:SYST:APPL:REV?
Remote Command Notes	Query returns a quoted string which is the Revision of the currently selected application (Mode). Example: "1.0.0.0" String length is a maximum of 23 characters. (each numeral can be an integer + 3 decimal points) The format is Major.Minor.Build.Compile, where Major must correspond to the Integer portion of the Version in the license file for the application.
Preset	Not affected by Preset
State Saved	Not saved in state per se, value will be the selected application when Save is invoked

Current Application Options

Returns a string which is the Options list of the currently selected application (mode).

Mode	All
Remote Command	:SYSTem:APPLication[:CURRent]:OPTion?
Example	:SYST:APPL:OPT?

Remote Command Notes	Query returns a quoted string which is the Option list of the currently selected application (Mode). The format is the name as the *OPT? or SYSTem:OPTion command: a comma separated list of option identifiers. Example: “1FP,2FP” String length is a maximum of 255 characters.
Preset	Not affected by Preset
State Saved	Not saved in state per se, value will be the selected application when Save is invoked

Application Identification Catalog (Remote commands only)

Application Catalog number of entries

Returns the number of installed and licensed applications (Modes).

Mode	All
Remote Command	:SYSTem:APPLication:CATalog[:NAME]:COUNT?
Example	:SYST:APPL:CAT:COUN?
Preset	Not affected by Preset
State Saved	Not saved in state.

Application Catalog Model Numbers

Returns a list of Model Numbers for the installed and licensed applications (Modes).

Mode	All
Remote Command	:SYSTem:APPLication:CATalog[:NAME]?
Example	:SYST:APPL:CAT?

Mode

Remote Command Notes	Returned value is a quoted string of a comma separated list of Model Numbers. Example, if SAMS and Phase Noise are installed and licensed: “N9060A,N9068A” String length is $COUNT * 7 - 1$. (7 = Model Number length + 1 for comma. -1 = no comma for the 1st entry.)
Preset	Not affected by Preset
State Saved	Not saved in state.

Application Catalog Revision

Returns the Revision of the provided Model Number.

Mode	All
Remote Command	:SYSTem:APPLication:CATalog:REVisIon? <model>
Example	:SYST:APPL:CAT:REV? 'N9060A'
Remote Command Notes	Returned value is a quoted string of revision for the provided Model Number. The revision will be a null-string (“”) if the provided Model Number is not installed and licensed. Example, if SAMS is installed and licensed: “1.0.0.0” String length is a maximum of 23 characters. (each numeral can be an integer + 3 decimal points)
Preset	Not affected by Preset
State Saved	Not saved in state.

Application Catalog Options

Returns a list of Options for the provided Model Number

Mode	All
Remote Command	:SYSTem:APPLication:CATalog:OPTion? <model>
Example	:SYST:APPL:CAT:OPT? 'N9060A'

Remote Command Notes	Returned value is a quoted string of a comma separated list of Options, in the same format as *OPT? or :SYSTem:OPTion?. If the provided Model Number is not installed and licensed a null-string (“”) will be returned. Example, if SAMS is installed and licensed: “2FP” String length is a maximum of 255 characters.
Preset	Not affected by Preset
State Saved	Not saved in state.

Spectrum Analyzer

Selects the Spectrum Analyzer mode for general purpose measurements. There are several measurements available in this mode. General spectrum analysis measurements, in swept and zero span, can be done using the first key in the **Meas** menu, labeled **Swept SA**. Other measurements in the **Meas** Menu are designed to perform specialized tasks, including power and demod measurements.

Key Path	Mode
Example	INST:SEL SA INST:NSEL 1

IQ Analyzer (Basic)

Selects the IQ Analyzer mode. The measurements available in this mode are Complex Spectrum and Waveform.

Key Path	Mode
Example	INST:SEL BASIC INST:NSEL 8

Mode

W-CDMA with HSDPA/HSUPA

Selects the W-CDMA with HSDPA/HSUPA mode for general purpose measurements. There are several measurements available in this mode.

Key Path	Mode
Example	INST:SEL W-CDMA INST:NSEL 9

802.16 OFDMA (WiMAX/WiBro)

Selects the WiMAX-OFDMA mode for general purpose measurements. There are several measurements available in this mode.

Key Path	Mode
Example	INST:SEL WIMAXOFDMA INST:NSEL 75

Mode Setup

There are no Mode Setup functions for IQ Analyzer (Basic) mode.

Key Path

Front Panel

Sweep/Control

This section describes the keys in the Sweep, Control and Capture menu that are applicable to the Swept SA measurement. It also describes the Restart, Single, and Cont key functions that control the data acquisition of the instrument.

Meas Uncal note:

The Meas Uncal (measurement uncalibrated) warning is given in the Status Bar in the lower right corner of the screen when the manual sweep time entered is shorter than what is computed by the instrument.

Key Path	Front-panel key
----------	-----------------

Sweep Time

Selects the length of time in which the spectrum analyzer sweeps the displayed frequency span. Note that additional overhead time is required by the analyzer. It impacts the sweep rate, but is not calculated as part of the sweep time. Reducing the sweep time increases the rate of sweeps.

In FFT spans, you cannot control the sweep time, it is set by the analyzer based on an estimate of the time required to make FFT measurements.

Sweep time is coupled to RBW and VBW, and is impacted by the number of sweep points. So changing those parameters may change the sweep time. The Auto/Man line on this key disappears when in Zero Span. This is because there is no “Auto Sweep Time” when in zero span.

The Auto/Man line also disappears when in an FFT sweep. In this case, the key is grayed out. The approximate sweep time is calculated and displayed on the key.

See table below for more detail.

Remote Command	<code>[:SENSe] :SWEep:TIME <time></code>
	<code>[:SENSe] :SWEep:TIME?</code>
	<code>[:SENSe] :SWEep:TIME:AUTO OFF ON 0 1</code>
	<code>[:SENSe] :SWEep:TIME:AUTO?</code>
Example	<code>SWE:TIME 500 ms</code>
	<code>SWE:TIME:AUTO OFF</code>

Sweep/Control

Dependencies/Couplings	<p>The third line of the softkey (Auto/Man) disappears in Zero Span. The SCPI command :SWEep:TIME:AUTO ON if sent in Zero Span it generates an error message.</p> <p>Softkey grayed out and third line of the softkey (Auto/Man) disappears in FFT sweeps. Pressing the key or sending the SCPI for sweep time while the instrument is in FFT sweep generates a -221, "Settings Conflict;" error. The SCPI command :SWEep:TIME:AUTO ON if sent in FFT sweeps generates an error.</p> <p>Key is grayed out in Measurements that don't support swept mode.</p> <p>Key is blanked in Modes that don't support swept mode.</p> <p>Set to Auto when Auto Couple is pressed or sent remotely.</p> <p>The Sweep Time used upon entry to Zero Span is simply the same as the Sweep Time which was in effect before entering Zero Span. The Sweep Time can be changed while in Zero Span. Upon leaving Zero Span, the Auto/Man state of Sweep Time which existed before entering Zero Span is restored.</p> <p>If Sweep Time was in Auto before entering Zero Span, or if it is set to Auto while in zero span (which can happen through remote command or if Auto Couple is pressed) it returns to Auto and recouples when returning to non-zero spans.</p> <p>If Sweep Time was in Man before entering Zero Span, it returns to Man when returning to non-zero spans, and any changes to Sweep Time which were made while in Zero Span are retained in the non-zero span (except where constrained by minimum limits, which are different in and out of zero span).</p>
Remote Command Notes	<p>The values shown in this table reflect the "swept spans" conditions which are the default settings after a preset. See "Couplings" for values in the zero span domain.</p>
Preset	<p>The preset Sweep Time value is hardware dependent since Sweep Time presets to Auto. Therefore the above number is meaningless.</p>
State Saved	<p>Saved in State.</p>
Min	<p>In zero span: 1 μs In swept spans: 1 ms</p>
Max	<p>In zero span: 6000s In swept spans: 4000s</p>
Key Path	<p>Sweep/Control</p>
SCPI Status Bits/OPC Dependencies	<p>Meas Uncal is Bit 0 in the STATUS:QUEStionable:INTegrity:UNCalibrated register</p>

Pause/Resume

Pauses a measurement after the current data acquisition is complete. When Paused, the label on the key changes to Resume. Pressing the Resume key resumes the measurement from the point it was at when paused.

Remote Command	:INITiate:PAUSE
Example	:INIT:PAUS
Dependencies/Couplings	Unavailable (grayed out) in measurements that do not support Pausing. Blanked in modes that do not support Pausing.
Key Path	Sweep/Control

Remote Command	:INITiate:RESUme
Example	:INIT:RESU
Dependencies/Couplings	Unavailable (grayed out) in measurements that do not support Pausing. Blanked in modes that do not support Pausing.
Key Path	Sweep/Control

Sweep Setup

Lets you set the sweep functions that control features such as sweep type and time.

Dependencies/Couplings	The whole Sweep Setup menu is grayed out in Zero Span, however the menus under Sweep Setup can be changed remotely with no error indication. Grayed out in measurements that do not support swept mode. Blanked in modes that do not support swept mode
Key Path	Sweep/Control

Sweep Time Rules

Allows the choice of three distinct sets of sweep time rules. These are the rules that are used to set the sweep time when **Sweep Time** is in **Auto**. These rules only apply when in the Swept **Sweep Type** (either manually or automatically chosen) and not when in FFT sweeps.

The first set of rules is called **SA – Normal**. **Sweep Time Rules** is set to **SA-Normal** on a **Preset** or **Auto Couple**. These rules give optimal sweep times at the cost of a bit of accuracy. This means that in the Preset or Auto Coupled state, instrument amplitude accuracy specifications do not apply.

Setting **Sweep Time Rules** to **SA-Accuracy** will result in slower sweep times than **SA-Normal**, usually

about three times as long, but better amplitude accuracy for CW signals. The instrument absolute amplitude accuracy specifications only apply when **Sweep Time** is set to **Auto**, and **Sweep Time Rules** are set to **SA-Accuracy**. Additional amplitude errors which occur when **Sweep Time Rules** are set to **SA-Normal** are usually well under 0.1 dB, though this is not guaranteed. Because of the faster sweep times and still low errors, **SA-Normal** is the preferred setting of **Sweep Time Rules**.

The third set of sweep times rules is called **Stimulus/Response** and is automatically selected when an integrated source is turned on, such as a Tracking Generator or a synchronized external source. The sweep times for this set of rules are usually much faster for swept-response measurements. Stimulus-response auto-coupled sweep times are typically valid in stimulus-response measurements when the system’s frequency span is less than 20 times the bandwidth of the device under test. You can select these rules manually (even if not making Stimulus-Response measurements) to get faster sweeps without the “Meas Uncal” warning. but you are then not protected from the oversweep condition and may end up with uncalibrated results. However, it is commonplace in measuring non-CW signals such as noise to be able to get excellent measurement accuracy at sweep rates higher than those required for CW signal accuracy, so this is a valid measurement technique.

Remote Command	[:SENSe] :SWEep:TIME:AUTO:RULes NORMAl ACCuracy SRESponse [:SENSe] :SWEep:TIME:AUTO:RULes?
Example	SWE:TIME:AUTO:RUL ACC
Dependencies/Couplings	In Zero Span, this key is irrelevant and cannot be accessed (because the whole Sweep Setup menu is grayed out), however its settings can be changed remotely with no error indication. Grayed out in FFT sweeps. Pressing the key while the instrument is in FFT sweep generates an advisory message. The SCPI is acted upon if sent, but will have no effect other than to change the readout on the key, as long as the analyzer is in an FFT sweep. Set to Auto on Auto Couple.
Preset	AUTO
State Saved	Saved in instrument state.
Key Path	Sweep/Control, Sweep Setup

Auto

Sets the analyzer to automatically choose Sweep Time Rules.

Remote Command	[:SENSe] :SWEep:TIME:AUTO:RULes:AUTO[:STATe] ON OFF 1 0 [:SENSe] :SWEep:TIME:AUTO:RULes:AUTO[:STATe] ?
Example	:SWE:TIME:AUTO:RUL:AUTO ON
Dependencies/Couplings	Set on Preset or Auto Couple.
Preset	ON

Key Path **Sweep/Control, Sweep Setup, Sweep Time Rules**

SA - Normal

Chooses Sweep Time Auto Rules for optimal speed and generally sufficient accuracy.

Example :SWE:TIME:AUTO:RUL NORM

Dependencies/Couplings Automatically selected unless Source is on.
If directly selected sets AUTO to Off.

Remote Command Notes See Sweep Time Rules.

Key Path **Sweep/Control, Sweep Setup, Sweep Time Rules**

SA - Accuracy

Chooses Sweep Time Auto Rules for specified absolute amplitude accuracy.

Example :SWE:TIME:AUTO:RUL ACC

Dependencies/Couplings If directly selected sets AUTO to Off.
See Sweep Time Rules.
Do not allow sweep time to fall below 20 ms when in SA - Accuracy

Key Path **Sweep/Control, Sweep Setup, Sweep Time Rules**

Stimulus/Response

Chooses Sweep Time Auto Rules for use with a source.

Example :SWE:TIME:AUTO:RUL SRES

Dependencies/Couplings Automatically selected when Source is on
May not be available when in an FFT sweep.
If directly selected, sets AUTO to Off.

Remote Command Notes See Sweep Time Rules.

Key Path **Sweep/Control, Sweep Setup, Sweep Time Rules**

Sweep Type

Chooses between the FFT and Sweep types of sweep.

Sweep Type refers to whether or not the instrument is in Swept or FFT analysis. When in Auto, the selection of sweep type is governed by two different sets of rules, depending on whether you want to optimize for dynamic range or for speed.

Sweep/Control

This function is irrelevant in zero span, because in zero span the instrument is not sweeping.

Remote Command	<code>[:SENSe] :SWEep:TYPE FFT SWEep</code> <code>[:SENSe] :SWEep:TYPE?</code>
Dependencies/Couplings	In Zero Span, this key is irrelevant and cannot be accessed (because the whole Sweep Setup menu is grayed out), however its settings can be changed remotely with no error indication.
Preset	AUTO
Key Path	Sweep/Control, Sweep Setup

Auto

When in Auto, the selection of sweep type is governed by two different sets of rules, depending on whether you want to optimize for dynamic range or for speed. These rules are chosen under the **Sweep Type Rules** key.

Remote Command	<code>[:SENSe] :SWEep:TYPE:AUTO OFF ON 0 1</code> <code>[:SENSe] :SWEep:TYPE:AUTO?</code>
Example	<code>:SWE:TYPE:AUTO ON</code>
Dependencies/Couplings	Pressing Auto Couple always sets Sweep Type to Auto.
Preset	ON
State Saved	Saved in instrument state.
Key Path	Sweep/Control, Sweep Setup, Sweep Type

Swept

Manually selects swept analysis, so it cannot change automatically to FFT.

Example	<code>SWE:TYPE SWE</code>
State Saved	Saved in instrument state.
Key Path	Sweep/Control, Sweep Setup, Sweep Type

FFT

Manually selects FFT analysis, so it cannot change automatically to Swept.

Example	<code>SWE:TYPE FFT</code>
Dependencies/Couplings	If Manual FFT is selected, the Signal ID key is grayed out. When Signal ID is on, Manual FFT is grayed out. For both the dynamic range case and the speed case, swept is chosen whenever any form of Signal ID is on.

State Saved	Saved in instrument state.
Key Path	Sweep/Control, Sweep Setup, Sweep Type

Sweep Type Rules

Selects which set of rules will be used for automatically choosing the Sweep Type when Sweep Type is in Auto.

Remote Command	<code>[:SENSe] :SWEep:TYPE:AUTO:RULEs SPEed DRANge</code> <code>[:SENSe] :SWEep:TYPE:AUTO:RULEs?</code>
Dependencies/Couplings	In Zero Span, this key is irrelevant and cannot be accessed (because the whole Sweep Setup menu is grayed out), however its settings can be changed remotely with no error indication.
Preset	DRANge
State Saved	Saved in instrument state.
Key Path	Sweep/Control, Sweep Setup

Auto

This selection is automatically chosen when Auto Couple is pressed. When in Auto, the Sweep Type Rules are simply set to Best Dynamic Range. It seems like a very simple Auto function, but the use of this construct allows a consistent statement about what the Auto Couple key does.

Remote Command	<code>[:SENSe] :SWEep:TYPE:AUTO:RULEs:AUTO [:STATe]</code> <code>OFF ON 0 1</code> <code>[:SENSe] :SWEep:TYPE:AUTO:RULEs:AUTO [:STATe] ?</code>
Example	<code>:SWE:TYPE:AUTO:RUL:AUTO ON</code>
Dependencies/Couplings	Pressing Auto Couple always sets Sweep Type Rules to Auto.
Preset	ON
State Saved	Saved in instrument state.
Key Path	Sweep/Control, Sweep Setup, Sweep Type Rules

Best Dynamic Range

This selection tells the analyzer to choose between swept and FFT analysis with the primary goal of optimizing dynamic range. If the dynamic range is very close between swept and FFT, then it chooses the faster one. This auto selection also depends on RBW Type.

In determining the Swept/FFT setting the auto rules use the following approach:

If the RBW Filter Type is Gaussian use the RBW for the Normal Filter BW and if that RBW > 210 Hz, use swept; for RBW <= 210 Hz, use FFT.

If the RBW Filter Type is Flat Top, use the same algorithm, but use 420 Hz instead of 210 Hz for the transition point between Swept and FFT.

Sweep/Control

If the RBW Filter Type is CISPR/MIL, always use Swept.

Example	SWE:TYPE:AUTO:RUL DRAN sets the auto rules to dynamic range.
Dependencies/Couplings	Directly selecting this setting sets AUTO to OFF.
Key Path	Sweep/Control, Sweep Setup, Sweep Type Rules

Best Speed

Selecting Best Speed tells the analyzer to choose between FFT or swept analysis based on the fastest analyzer speed.

Example	SWE:TYPE:AUTO:RUL SPE sets the rules for the auto mode to speed
Dependencies/Couplings	Directly selecting this setting sets AUTO to OFF.
Key Path	Sweep/Control, Sweep Setup, Sweep Type Rules

FFT Width

This menu displays and controls the width of the FFT's performed while in FFT mode.

Remote Command	<code>[:SENSe] :SWEep:FFT:WIDTh <real></code> <code>[:SENSe] :SWEep:FFT:WIDTh?</code>
Example	SWE:FFT:WIDTh 167 kHz sets this function to "<167.4 kHz"
Dependencies/Couplings	In Zero Span, this key is irrelevant and cannot be accessed (because the whole Sweep Setup menu is grayed out). However, its settings can be changed remotely with no error indication.
Remote Command Notes	The parameter is in units of frequency; the setting is chosen that is closest to the sent parameter. For example, 8 MHz would select ~7.99 MHz whereas 5 kHz would select <4.01 kHz. The readback is the number that was chosen not the number that was sent; for example, 4.01 E+3 or 25 E+6. For the last key, ~Maximum, the value that will get used is option dependant. Normally, it will be equivalent to ~10 MHz but with the wide bandwidth option installed it will be equivalent to ~25 MHz. Any value sent from SCPI 10 MHz or greater will select ~Maximum. For example, if 11 MHz is sent it will select ~Maximum even though 8 MHz is closer to 11 MHz than 25 MHz.
Preset	The Preset is Auto, but Preset will also pick Best Dynamic Range and this function will be set to ~Maximum
State Saved	Saved in Instrument State.
Key Path	Sweep/Control, Sweep Setup

Remote Command	<code>[:SENSe] :SWEep:FFT:WIDTh:AUTO OFF ON 0 1</code> <code>[:SENSe] :SWEep:FFT:WIDTh:AUTO?</code>
Example	<code>:SWE:FFT:WIDT:AUTO ON</code>
Dependencies/Couplings	Pressing Auto Couple always sets FFT Width to Auto.
Preset	ON
State Saved	Saved in instrument state.
Key Path	Sweep/Control, Sweep Setup

Points

Sets the number of points per sweep, from 1 to 20001. By selecting a number of sweep points greater than 1001 you are optimizing the frequency resolution and accuracy while accepting a reduced measurement speed. In addition to sweep points, the span, resolution bandwidth, video bandwidth, average detection and center frequency will also affect measurement speed.

When in a split screen display each window may have its own value for points.

Remote Command	<code>[:SENSe] :SWEep:POINts <integer></code> <code>[:SENSe] :SWEep:POINts?</code>
Example	<code>SWE:POIN 501</code> <code>SWE:POIN?</code>
Dependencies/Couplings	Grayed out in measurements that don't support swept Blanked in modes that don't support swept. Will be affected by: log sweep Whenever the number of sweep points change: All trace data is erased Any traces with Update Off will also go to Display Off (like going from View to Blank in the older analyzers) Sweep time is re-quantized Any limit lines that are on will be updated If averaging/hold is on, averaging/hold starts over
Preset	1001
State Saved	Saved in instrument state.
Min	1
Max	20001
Key Path	Sweep

Restart

The Restart function restarts the current sweep, or measurement, or set of averaged/held sweeps or measurements.

The Restart function is accessed in several ways:

Pressing the Restart key

sending the remote command INIT:IMMEDIATE

sending the remote command INIT:RESTART

The **Restart** function first aborts the current sweep/measurement as quickly as possible. It then resets the sweep and trigger systems, sets up the measurement and initiates a new data measurement sequence with a new data acquisition (sweep) taken once the trigger condition is met.

If the analyzer is in the process of aligning when **Restart** is executed, the alignment finishes before the restart function is performed.

Even when set for Single operation, multiple sweeps may be taken when **Restart** is pressed (for example, when averaging/holding is on). When we say that **Restart** “restarts a measurement,” we may mean:

- It restarts the current sweep

- It restarts the current measurement

- It restarts the current set of sweeps if any trace is in Trace Average, Max Hold or Min Hold

- It restarts the current set of measurements if Averaging, or Max Hold, or Min Hold is on for the measurement

depending on the current settings.

With **Average/Hold Number** (in **Meas Setup** menu) set to 1, or Averaging off, or no trace in Trace Average or Hold, a single sweep is equivalent to a single measurement. A single sweep is taken after the trigger condition is met; and the analyzer stops sweeping once that sweep has completed. However, with **Average/Hold Number** >1 and at least one trace set to **Trace Average**, **Max Hold**, or **Min Hold** (SA Measurement) or Averaging on (most other measurements), multiple sweeps/data acquisitions are taken for a single measurement. The trigger condition must be met prior to each sweep. The sweep is stopped when the average count k equals the number N set for **Average/Hold Number**. A measurement average usually applies to all traces, marker results, and numeric results; but sometimes it only applies to the numeric results.

Once the full set of sweeps has been taken, the analyzer will go to idle state. To take one more sweep without resetting the average count, increment the average count by 1, by pressing the step up key while **Average/Hold Number** is the active function, or sending the remote command CALC:AVER:TCON UP.

Certain conditions may cause an implicit restart to be performed.

Remote Command :INITiate[:IMMEDIATE]

Example :INIT:IMM

Dependencies/Couplings	Resets average/hold count k. For the first sweep overwrites all active (update=on) traces with new current data. For application modes, it resets other parameters as required by the measurement.
Remote Command Notes	:INITiate:REStart :INITiate:IMMediate Either of the above commands perform exactly the same function.
SCPI Status Bits/OPC Dependencies	This is an Overlapped command. The STATus:OPERation register bits 0 through 8 are cleared. The STATus:QUEStionable register bit 9 (INTegrity sum) is cleared. The SWEEPING bit is set. The MEASURING bit is set.
Key Path	Front-panel key

Remote Command	:INITiate:REStart
Example	:INIT:REST
Dependencies/Couplings	Resets average/hold count k. For the first sweep overwrites all active (update=on) traces with new current data. For application modes, it resets other parameters as required by the measurement.
Remote Command Notes	:INITiate:REStart :INITiate:IMMediate Either of the above commands perform exactly the same function.
SCPI Status Bits/OPC Dependencies	This is an Overlapped command. The STATus:OPERation register bits 0 through 8 are cleared. The STATus:QUEStionable register bit 9 (INTegrity sum) is cleared. The SWEEPING bit is set. The MEASURING bit is set.

Single/Cont key (Continuous Measurement)

The **Single** key sets the analyzer for single measurement operation.

The **Cont** key sets the analyzer for Continuous measurement operation. Pressing this key is equivalent to sending the remote command INIT:CONT ON.

In Spectrum Analysis Mode:

The analyzer takes repetitive sweeps, averages, measurements, and so forth when in Continuous mode. When the average count reaches the **Average/Hold Number** the count stops incrementing, but the analyzer keeps sweeping. See the Trace/Detector section for the averaging formula used both before and after the **Average/Hold Number** is reached. The trigger condition must be met prior to each sweep. The type of trace processing for multiple sweeps, is set under the **Trace/Detector** key, with choices of **Trace Average**, **Max Hold**, or **Min Hold**.

In Other Modes:

With **Avg Number** (in **Meas Setup** menu) set to **Off** or set to **On** with a value of 1, a sweep is taken after the trigger condition is met; and the analyzer continues to take new sweeps after the current sweep has completed and the trigger condition is again met. However, with **Avg Number** set to **On** with a value >1, multiple sweeps (data acquisitions) are taken for the measurement. The trigger condition must be met prior to each sweep. The sweep is not stopped when the average count k equals the number N set for Avg Number is reached, but the number k stops incrementing. A measurement average usually applies to all traces, marker results, and numeric results. But sometimes it only applies to the numeric results.

If the analyzer is set for a Single measurement, pressing the **Cont** key does not change k and does not cause the sweep to be reset; the only action is to put the analyzer into Continuous measurement operation.

If it is already in continuous sweep:

The INIT:CONT 1 command has no effect

The INIT:CONT 0 command will place the analyzer in Single Sweep but will have no effect on the current sequence until k=N, at which point the current sequence will stop and the instrument will go to the idle state.

Remote Command	:INITiate:CONTinuous OFF ON 0 1 :INITiate:CONTinuous?
Example	:INIT:CONT 0 puts analyzer in Single measurement operation. :INIT:CONT 1 puts analyzer in Continuous measurement operation
Preset	ON (Note that SYST:PRESet sets INIT:CONT to ON but *RST sets INIT:CONT to OFF)
State Saved	Saved in Instrument State.
Key Path	Front-panel key

Abort (Remote Only)

This command is used to stop the current measurement. It aborts the current measurement as quickly as possible, resets the sweep and trigger systems, and puts the measurement into an idle state. If the analyzer is in the process of aligning when ABORT is sent, the alignment finishes before the abort function is performed. So ABORT does not abort an alignment.

If the analyzer is set for Continuous measurement, it sets up the measurement and initiates a new

data measurement sequence with a new data acquisition (sweep) taken once the trigger condition is met.

If the analyzer is set for Single measurement, it remains in an idle state until an :INIT:IMM command is received.

Remote Command	:ABORt
Example	:ABOR
Remote Command Notes	<p>If :INITiate:CONTInuous is ON, then a new continuous measurement will start immediately; with sweep (data acquisition) occurring once the trigger condition has been met.</p> <p>If :INITiate:CONTInuous is OFF, then :INITiate:IMMEDIATE is used to start a single measurement; with sweep (data acquisition) occurring once the trigger condition has been met.</p>
SCPI Status Bits/OPC Dependencies	<p>The STATus:OPERation register bits 0 through 8 are cleared.</p> <p>The STATus:QUEStionable register bit 9 (INTegrity sum) is cleared.</p> <p>Since all the bits that feed into OPC are cleared by the ABORt, the ABORt will cause the *OPC query to return true.</p>

Trigger

The Trig key accesses the **Trigger** menu which contains keys to control the 1-of-N selection of the Trigger source.

The trigger functions let you select the trigger settings for a sweep or measurement. When using a trigger source other than Free Run, the analyzer will begin a sweep only when the selected trigger conditions are met. A trigger event is defined as the point at which your trigger source signal meets the specified trigger level and polarity requirements (if any). In FFT measurements, the trigger controls when the data is acquired for FFT conversion.

For each source in the Trigger menu, a setup menu exists which can be accessed by pressing the key for that trigger source a second time. For example, one press of Video selects the Video trigger as the source. The Video key becomes highlighted and the hollow arrow on the key turns black. Now a second press of the key takes you into the Video Trigger Setup menu. The setup menus (there is one for each trigger source) allow you to set all of the settings for that trigger source as desired. Each source's trigger settings (for example, level, delay and slope) are the same for the **Trigger** menu, and the Sync Source menu that is part of the **Periodic Timer Trigger Setup** menu. That is, if **Ext1** trigger level is set to 1v in the **Trigger** menu, it will appear as 1v in the Sync Source menus. For this reason, the only SCPI node that exists for the settings is the `:TRIGger[:SEQuence]` menu.

The trigger settings are common to all applications (modes). However, each application may have its own ranges and default value settings. Also, some applications may have trigger features that are unavailable because they do not make sense for that particular application.

The trigger source, on the other hand, is uniquely selected for each measurement. The trigger source setting is the only trigger parameter that is measurement dependent.

The syntax of all the Trigger SCPI commands described in this section will be the same for every measurement in all of the applications. The exception is the trigger source selection command which will have unique syntax for each measurement (for example, `:TRIGger:<measurement name>:SOURce`).

Remote Command	<code>:TRIGger [:SEQuence] :SOURce</code> <code>EXTernal1 EXTernal2 IMMEDIATE LINE FRAME RFBurst VIDEO</code> <code> TV</code> <code>:TRIGger [:SEQuence] :SOURce?</code>
Example	<code>TRIG:SOUR VID</code>
Dependencies/Couplings	Cancel the active function whenever the trigger source is changed, because it could be a trigger level from one of the other trigger sources.

Trigger

Remote Command Notes	IMMEDIATE - free run triggering VIDEo - triggers on the video signal level LINE - triggers on the power line signal EXTernal1 - triggers on an externally connected trigger source on the rear panel EXTernal2 - triggers on an externally connected trigger source on the front panel FRAMe - triggers on the periodic timer RFBurst - triggers on the bursted frame TV (television) - triggers on the selected line of a TV frame Other trigger-related commands are found in the INITiate and ABORt subsystems. *OPC should be used after requesting data. This will hold off any subsequent changes to the selected trigger source, until after the sweep is completed and the data is returned.
Preset	IMMEDIATE
State Saved	Saved in instrument state.

Free Run

Pressing this key, when it is not selected, selects free-run triggering. Free run triggering occurs immediately after the sweep/measurement is initiated.

Example	TRIG:SOUR IMM
State Saved	Saved in instrument state.
Key Path	Trig
SCPI Status Bits/OPC Dependencies	The Status Operation Register bit 5 “Waiting for Trigger” is set at the same time as the Sweeping or Measuring bit is set. It is cleared when the trigger actually occurs (for example, after the trigger event occurs and all the applicable trigger criteria have been met).

Video

Pressing this key, when it is not selected, selects the video signal as the trigger. The Video trigger condition is met when the video signal (the filtered and detected version of the input signal, including both RBW and VBW filtering) crosses the video trigger level.

NOTE When the detector selected for all active traces is the average detector, the video signal for triggering does not include any VBW filtering.

The video trigger level is shown as a labeled line on the display. The line is displayed as long as

video is the selected trigger source.

Pressing this key, when it is already selected, accesses the video trigger setup functions.

Dependencies/Couplings	Video trigger is allowed in average detector mode.
Example:	TRIG:SOUR VID selects video triggering.
State Saved:	Saved in instrument state.
Key Path:	Trig
SCPI Status Bits/OPC Dependencies:	The Status Operation Register bit 5 “Waiting for Trigger” is set at the same time as the Sweeping or Measuring bit is set. It is cleared when the trigger actually occurs (for example, after the trigger event occurs and all the applicable trigger criteria have been met).

Trigger Level

Sets a level for the video signal trigger. When the video signal crosses this level, with the chosen slope, the trigger occurs. This level is displayed with a horizontal line only if Video is the selected trigger source.

Remote Command	:TRIGger[:SEquence]:VIDeo:LEVel <ampl> :TRIGger[:SEquence]:VIDeo:LEVel?
Example	TRIG:VID:LEV -40 dBm
Dependencies/Couplings	This same level is used for the Video trigger source in the Trigger menu. The range of the Video Trigger Level is dependent on the Reference Level.
Preset	Set the Video Trigger Level -25 dBm on Preset. When the Video Trigger Level becomes the active function, if the value is off screen, set it to either the top or bottom of screen, depending on which direction off screen it was.
State Saved	Saved in instrument state.
Min	Same as the reference level.
Max	Same as the reference level.
Key Path	Trig, Video
Default Unit	Depends on the current selected Y axis unit.

Trig Slope

Controls the trigger polarity. It is set positive to trigger on a rising edge and negative to trigger on a

Trigger

falling edge.

Remote Command	:TRIGger[:SEquence]:VIDeo:SLOPe POSitive NEGative :TRIGger[:SEquence]:VIDeo:SLOPe?
Example	TRIG:VID:SLOP NEG
Preset	POSitive
State Saved	Saved in instrument state.
Key Path	Trig, Video

Trig Delay

Controls a time delay during which the analyzer will wait to begin a sweep after meeting the trigger criteria. You can use negative delay to pre-trigger the instrument in time domain or FFT, but not in swept spans.

Remote Command	:TRIGger[:SEquence]:VIDeo:DELay <time> :TRIGger[:SEquence]:VIDeo:DELay? :TRIGger[:SEquence]:VIDeo:DELay:STATe OFF ON 0 1 :TRIGger[:SEquence]:VIDeo:DELay:STATe?
Example	TRIG:VID:DEL:STAT ON TRIG:VID:DEL 100 ms
Preset	1 us OFF
State Saved	Saved in instrument state.
Min	-150 ms
Max	+500 ms
Key Path	Trig, Video
Default Unit	s

Line

Pressing this key, when it is not selected, selects the line signal as the trigger. A new sweep/measurement will start synchronized with the next cycle of the line voltage. Pressing this key, when it is already selected, access the line trigger setup menu.

Example	TRIG:SOUR LINE selects line triggering.
Dependencies/Couplings	Line trigger is not available when operating from a “dc power source”, for example, when the instrument is powered from batteries.

State Saved	Saved in instrument state.
Key Path	Trig
SCPI Status Bits/OPC Dependencies	The Status Operation Register bit 5 “Waiting for Trigger” is set at the same time as the Sweeping or Measuring bit is set. It is cleared when the trigger actually occurs (for example, after the trigger event occurs and all the applicable trigger criteria have been met).

Trig Slope

Controls the trigger polarity. It is set positive to trigger on a rising edge and negative to trigger on a falling edge.

Remote Command	:TRIGger[:SEquence]:LINE:SLOPe POSitive NEGative :TRIGger[:SEquence]:LINE:SLOPe?
Example	TRIG:LINE:SLOP NEG
Preset	POSitive
State Saved	Saved in instrument state.
Key Path	Trig, Line

Trig Delay

Controls a time delay during which the analyzer will wait to begin a sweep after meeting the trigger criteria. You can use negative delay to pre-trigger the instrument in time domain or FFT, but not in swept spans.

Remote Command	:TRIGger[:SEquence]:LINE:DELAy <time> :TRIGger[:SEquence]:LINE:DELAy? :TRIGger[:SEquence]:LINE:DELAy:STATe OFF ON 0 1 :TRIGger[:SEquence]:LINE:DELAy:STATe?
Example	TRIG:LINE:DEL:STAT ON TRIG:LINE:DEL 100 ms
Preset	1.000 us OFF
State Saved	Saved in instrument state.
Min	-150 ms
Max	500 ms
Key Path	Trig, Line
Default Unit	s

Trigger

External 1

Pressing this key, when it is not selected, selects an external input signal as the trigger. A new sweep/measurement will start when the external trigger condition is met using the external 1 input connector on the rear panel.

Pressing this key, when it is already selected, accesses the external 1 trigger setup menu.

Example	TRIG:SOUR EXT1 this selects the external 1 trigger input on the rear panel.
State Saved	Saved in instrument state.
Key Path	Trig
SCPI Status Bits/OPC Dependencies	The Status Operation Register bit 5 “Waiting for Trigger” is set at the same time as the Sweeping or Measuring bit is set. It is cleared when the trigger actually occurs (for example, after the trigger event occurs and all the applicable trigger criteria have been met).

Trigger Level

Sets the value where the external 1 trigger input will trigger a new sweep/measurement.

Remote Command	:TRIGger[:SEquence]:EXTernal1:LEVel <level> :TRIGger[:SEquence]:EXTernal1:LEVel?
Example	TRIG:EXT1:LEV 0.4 V
Dependencies/Couplings	This same level is used for the Ext1 trigger source in the Trigger menu, for the Ext1 selection in the Periodic Timer sync source (in the Trigger menu).
Preset	1.2 V
State Saved	Saved in instrument state.
Min	-5 V
Max	5 V
Key Path	Trig, External 1
Default Unit	V

Trig Slope

Controls the trigger polarity. It is set positive to trigger on a rising edge and negative to trigger on a falling edge.

Remote Command	:TRIGger[:SEquence]:EXTernal1:SLOPe POSitive NEGative :TRIGger[:SEquence]:EXTernal1:SLOPe?
Example	TRIG:EXT1:SLOP NEG

Dependencies/Couplings	This same slope is used in the Ext1 selection for the trigger source in the Trigger menu and for the period timer sync source (in the Trigger menu).
Preset	POSitive
State Saved	Saved in instrument state.
Key Path	Trig, External 1

Trig Delay

Controls a time delay during which the analyzer will wait to begin a sweep after meeting the trigger criteria. You can use negative delay to pre-trigger the instrument in time domain or FFT, but not in swept spans.

Remote Command	:TRIGger[:SEquence]:EXTernal1:DELay <time> :TRIGger[:SEquence]:EXTernal1:DELay? :TRIGger[:SEquence]:EXTernal1:DELay:STATE OFF ON 0 1 :TRIGger[:SEquence]:EXTernal1:DELay:STATE?
Example	TRIG:EXT1:DEL:STAT ON TRIG:EXT1:DEL 100 ms
Preset	1 us OFF
State Saved	Saved in instrument state.
Min	-150 ms
Max	+500 ms
Key Path	Trig, External 1
Default Unit	s

External 2

Pressing this key, when it is not selected, selects an external input signal as the trigger. A new sweep/measurement will start when the external trigger condition is met using the external 2 input connector. The external trigger 2 input connector is on the rear panel.

Pressing this key, when it is already selected, accesses the external 2 trigger setup menu.

Example	TRIG:SOUR EXT2 this selects the rear panel external 2 trigger input.
State Saved	Saved in instrument state.
Key Path	Trig

Trigger

SCPI Status Bits/OPC Dependencies
The Status Operation Register bit 5 “Waiting for Trigger” is set at the same time as the Sweeping or Measuring bit is set. It is cleared when the trigger actually occurs (for example, after the trigger event occurs and all the applicable trigger criteria have been met).

Trigger Level

Sets the value where the external 2 trigger input will trigger a new sweep/measurement.

Remote Command	:TRIGger[:SEquence]:EXTernal2:LEVel :TRIGger[:SEquence]:EXTernal2:LEVel?
Example	TRIG:EXT2:LEV 1.1 V
Dependencies/Couplings	This same level is used for the Ext2 trigger source in the Trigger menu, for the Ext2 selection in the Periodic Timer sync source (in the Trigger menu).
Preset	1.2 V
State Saved	Saved in instrument state.
Min	-5 V
Max	5 V
Key Path	Trig, External 2
Default Unit	V

Trig Slope

Controls the trigger polarity. It is set positive to trigger on a rising edge and negative to trigger on a falling edge.

Remote Command	:TRIGger[:SEquence]:EXTernal2:SLOPe POSitive NEGative :TRIGger[:SEquence]:EXTernal2:SLOPe?
Example	TRIG:EXT2:SLOP NEG
Dependencies/Couplings	This same slope is used in the Ext2 selection for the trigger source in the Trigger menu and for the period timer sync source (in the Trigger menu).
Preset	POSitive
State Saved	Saved in instrument state.
Key Path	Trig, External 2

Trig Delay

Controls a time delay during which the analyzer will wait to begin a sweep after meeting the trigger criteria. You can use negative delay to pre-trigger the instrument in time domain or FFT, but not in

swept spans.

Remote Command	:TRIGger[:SEquence]:EXTErnal2:DELay <time> :TRIGger[:SEquence]:EXTErnal2:DELay? :TRIGger[:SEquence]:EXTErnal2:DELay:STATe OFF ON 0 1 :TRIGger[:SEquence]:EXTErnal2:DELay:STATe?
Example	TRIG:EXT2:DEL:STAT ON TRIG:EXT2:DEL 100 ms
Preset	1 us OFF
State Saved	Saved in instrument state.
Min	-150 ms
Max	500 ms
Key Path	Trig, External 2
Default Unit	s

RF Burst (Wideband)

Pressing this key, when it is not selected, selects the RF Burst as the trigger. A new sweep/measurement will start when an RF burst envelope signal is identified from the signal at the RF Input connector. Pressing this key, when it is already selected, accesses the RF Burst trigger setup menu.

Example	TRIG:SOUR RFB
Remote Command Notes	
State Saved	Saved in instrument state.
Key Path	Trig
SCPI Status Bits/OPC Dependencies	The Status Operation Register bit 5 “Waiting for Trigger” is set at the same time as the Sweeping or Measuring bit is set. It is cleared when the trigger actually occurs (for example, after the trigger event occurs and all the applicable trigger criteria have been met).

Trigger Level

Sets the absolute trigger level for the RF burst envelope. See key notes regarding the relative trigger level.

Remote Command	:TRIGger[:SEquence]:RFBurst:LEVel:ABSolute <ampl> :TRIGger[:SEquence]:RFBurst:LEVel:ABSolute?
----------------	--

Trigger

Dependencies/Couplings	This same level is used for the RF Burst trigger source in the Trigger menu, for the RF Burst selection in the Periodic Timer sync source (in the Trigger menu).
Preset	-20 dBm
State Saved	Saved in instrument state.
Min	-200 dBm
Max	100 dBm
Key Path	Trig, RF Burst
Default Unit	Absolute trig level: depends on the current selected amplitude units.

Trigger Slope

It is set positive to trigger on a rising edge and negative to trigger on a falling edge.

Remote Command	:TRIGger[:SEquence]:RFBurst:SLOPe POSitive NEGative :TRIGger[:SEquence]:RFBurst:SLOPe?
Example	TRIG:RFB:SLOP NEG
Couplings	This same slope is used in the RF Burst selection for the trigger source in the Trigger menu and for the period timer sync source (in the Trigger menu).
Preset	POSitive
State Saved	Saved in instrument state.
Key Path	Trig, RF Burst

Trig Delay

Controls a time delay during which the analyzer will wait to begin a sweep after meeting the trigger criteria. You can use negative delay to pre-trigger the instrument in the time domain or FFT, but not in swept spans.

Remote Command	:TRIGger[:SEquence]:RFBurst:DELay <time> :TRIGger[:SEquence]:RFBurst:DELay? :TRIGger[:SEquence]:RFBurst:DELay:STATe OFF ON 0 1 :TRIGger[:SEquence]:RFBurst:DELay:STATe?
Example	TRIG:RFB:DEL:STAT ON TRIG:RFB:DEL 100 ms
Preset	1 us OFF

State Saved	Saved in instrument state.
Min	–150 ms
Max	500 ms
Key Path	Trig, RF Burst
Default Unit	s

Periodic Timer (Frame Trigger)

Pressing this key, when it is not selected, selects the internal periodic timer signal as the trigger. Triggering occurrences are set by the Period parameter, which is modified by the Sync Source and Offset. Pressing this key, when it is already selected, accesses the periodic timer trigger setup functions.

If you do not have a sync source selected (it is Off), then the internal timer will not be synchronized with any external timing events.

Example	TRIG:SOUR FRAM
Remote Command Notes	
State Saved	Saved in instrument state.
Key Path	Trig
SCPI Status Bits/OPC	The Status Operation Register bit 5 “Waiting for Trigger” is set at the same time as the Sweeping or Measuring bit is set. It is cleared when the trigger actually occurs (i.e. after the trigger event occurs and all the applicable trigger criteria have been met).
Dependencies	

Period

Sets the period of the internal periodic timer clock. For digital communications signals, this is usually set to the frame period of your current input signal. In the case that sync source is not set to OFF, and the external sync source rate is changed for some reason, the periodic timer is synchronized at every external synchronization pulse by resetting the internal state of the timer circuit.

Remote Command	:TRIGger[:SEQuence]:FRAMe:PERiod <time> :TRIGger[:SEQuence]:FRAMe:PERiod?
Example	TRIG:FRAM:PER 100 ms
Dependencies/Couplings	The invalid data indicator turns on when the period is changed, until the next sweep/measurement completes.
Preset	20 ms
State Saved	Saved in instrument state.

Trigger

Min	100.000 ns
Max	559.0000 ms
Key Path	Trig, Periodic Timer
Default Unit	s

Offset

Adjusts the accumulated offset between the periodic timer events and the trigger event. Adjusting the accumulated offset is different than setting an offset, and requires explanation.

The periodic timer is usually unsynchronized with any external events, so the timing of its output events has no absolute meaning. Since the timing relative to external events (RF signals) is important, you need to be able to adjust (offset) it. However, you have no direct way to see when the periodic timer events occur. All that you can see is the trigger timing. When you want to adjust the trigger timing, you will be changing the internal offset between the periodic timer events and the trigger event. Because the absolute value of that internal offset is unknown, we will just call that the accumulated offset. Whenever the Offset parameter is changed, you are changing that accumulated offset. You can reset the displayed offset using Reset Offset Display. Changing the display does not change the value of the accumulated offset, and you can still make additional changes to accumulated offset.

To avoid ambiguity, we define that an increase in the “offset” parameter, either from the RPG or the SCPI adjust command, serves to delay the timing of the trigger event.

Remote Command	:TRIGger[:SEQuence]:FRAMe:OFFSet <time> :TRIGger[:SEQuence]:FRAMe:OFFSet?
Example	TRIG:FRAM:OFFS 1.2 ms
Dependencies/Couplings	The invalid data indicator turns on when the offset is changed, until the next sweep/measurement completes.
Remote Command Notes	When the SCPI command is sent the value shown on the key (and the Active Function, if this happens to be the active function) is updated with the new value. However, the actual amount sent to the hardware is the delta value, that is, the current accumulated offset value minus the previous accumulated offset value. The SCPI query simply returns the value currently showing on the key.
Preset	0 s
State Saved	Saved in instrument state.
Min	-10.000 s
Max	10.000 s
Key Path	Trig, Periodic Timer
Default Unit	s

Offset Adjust (remote command only)

Remote Command	:TRIGger[:SEquence]:FRAMe:ADJust <time>
Example	TRIG:FRAM:ADJ 1.2 ms
Dependencies/Couplings	The invalid data indicator turns on when the offset is changed, until the next sweep/measurement completes.
Remote Command Notes	<p>The front panel interface (for example, the knob) and the :TRIG:FRAM:OFFS command adjust the accumulated offset, which is shown on the active function display. However, the actual amount sent to the hardware is the delta value, that is, the current offset value minus the previous offset value.</p> <p>This remote command does not work at all like the front panel keys. This command lets you advance the phase of the frame trigger by the amount you specify.</p> <p>It does not change the period of the trigger waveform. If the command is sent multiple times, it advances the phase of the frame trigger an additional amount each time it is sent. Negative numbers are permitted.</p> <p>When the SCPI command is sent the value shown on the key (and the Active Function, if this happens to be the active function) is updated by increasing it (or decreasing it if the value sent is negative) by the amount specified in the SCPI command.</p> <p>This is a “command only” SCPI command, with no query.</p>
Preset	0 s
State Saved	Saved in instrument state.
Min	-10.000 s
Max	10.000 s
Default Unit	s

Reset Offset Display

Resets the value of the periodic trigger offset display setting to 0.0 seconds. The current displayed trigger location may include an offset value defined with the Offset key. Pressing this key redefines the currently displayed trigger location as the new trigger point that is 0.0s offset. The Offset key can then be used to add offset relative to this new timing.

Remote Command	:TRIGger[:SEquence]:FRAMe:OFFSet:DISPlay:RESet
Example	TRIG:FRAM:OFFS:DISP:RES
Key Path	Trig, Periodic Timer

Sync Source

Selects a signal source for you to synchronize your periodic timer trigger to, otherwise you are

Trigger

triggering at some arbitrary location in the frame. Synchronization reduces the precision requirements on the setting of the period.

For convenience you may adjust the level and slope of the selected sync source in a conditional branch setup menu accessed from the Sync Source menu. These settings match those in the **Trigger** and **Gate Source** menus; that is, each trigger source has only one value of level and slope, regardless of which menu it is accessed from.

Remote Command	:TRIGger [:SEquence] :FRAMe:SYNC EXTernal1 EXTernal2 RFBurst OFF :TRIGger [:SEquence] :FRAMe:SYNC?
Example	TRIG:FRAM:SYNC EXT2
Preset	OFF
State Saved	Saved in instrument state.
Key Path	Trig, Periodic Timer

Off

Turns off the sync source for your periodic trigger. With the sync source off, the timing will drift unless the signal source frequency is locked to the analyzer frequency reference.

Example	TRIG:FRAM:SYNC OFF
Remote Command Notes	See the "Sync Source" section.
Key Path	Trig, Periodic Timer, Sync Source

External 1

Pressing this key, when it is not selected, selects the external input port that you will use for the periodic trigger synchronization. Pressing this key, when it is already selected, accesses the external 1 sync source setup menu.

Example	TRIG:FRAM:SYNC EXT
Dependencies/Couplings	Same as External 1 trigger source.
Remote Command Notes	See the "Sync Source" section.
Key Path	Trig, Periodic Timer, Sync Source

Trigger Level

Sets the value where the signal at the external 1 trigger input will synchronize with the periodic timer trigger.

Remote Command	:TRIGger [:SEquence] :FRAMe:EXTernal1:LEVel <voltage> :TRIGger [:SEquence] :FRAMe:EXTernal1:LEVel?
----------------	---

Example	TRIG:FRAM:EXT1:LEV 0.5 V
Dependencies/Couplings	This same level is used in the Ext1 trigger source in the Trigger menu, for the period timer sync source (in the Trigger menu).
Preset	1.2 V
State Saved	Yes
Min	-5 V
Max	5 V
Key Path	Trig, Periodic Timer, Sync Source, External 1
Default Unit	V

Trig Slope

Controls the trigger polarity. It is set positive to trigger on a rising edge and negative to trigger on a falling edge.

Remote Command	:TRIGger[:SEquence]:FRAMe:EXTernal1:SLOPe POSitive NEGative :TRIGger[:SEquence]:FRAMe:EXTernal1:SLOPe?
Example	TRIG:FRAM:EXT1:SLOP NEG
Dependencies/Couplings	This same slope is used in the Ext1 selection for the trigger source in the Trigger menu and for the period timer sync source (in the Trigger menu).
Preset	POSitive
State Saved	Saved in instrument state.
Key Path	Trig, Periodic Timer, Sync Source, External 1

External 2

Pressing this key, when it is not selected, selects the external input port that you will use for the periodic frame trigger synchronization.

Pressing this key, when it is already selected, accesses the external 2 sync source setup menu.

Example	TRIG:FRAM:SYNC EXT2
Dependencies/Couplings	Same as External 2 trigger source.
Remote Command Notes	See the "Sync Source" section.
Key Path	Trig, Periodic Timer, Sync Source

Trigger Level

Trigger

Sets the value where the signal at the external 2 trigger input will synchronize with the frame timer trigger.

Remote Command	:TRIGger[:SEquence]:FRAMe:EXTernal2:LEVel :TRIGger[:SEquence]:FRAMe:EXTernal2:LEVel?
Example	TRIG:FRAM:EXT2:LEV 0.5 V
Dependencies/Couplings	This same level is used in the Ext2 trigger source in the Trigger menu, for the period timer sync source (in the Trigger menu).
Preset	1.2 V
State Saved	Saved in instrument state.
Min	-5 V
Max	5 V
Key Path	Trig, Periodic Timer, Sync Source, External 2
Default Unit	V

Trig Slope

Controls the trigger polarity. It is set positive to trigger on a rising edge and negative to trigger on a falling edge.

Remote Command	:TRIGger[:SEquence]:FRAMe:EXTernal2:SLOPe POSitive NEGative :TRIGger[:SEquence]:FRAMe:EXTernal2:SLOPe?
Example	TRIG:FRAM:EXT2:SLOP NEG
Dependencies/Couplings	This same slope is used in the Ext2 trigger source in the Trigger menu and for the period timer sync source (in the Trigger menu).
Preset	POSitive
State Saved	Saved in instrument state.
Key Path	Trig, Periodic Timer, Sync Source, External 2

RF Burst (Wideband)

Pressing the key once selects the RF burst envelope signal to be used for the periodic timer trigger synchronization.

Press the key a second time to access the RF burst sync source setup menu.

Example	TRIG:FRAM:SYNC RFB
Dependencies/Couplings	Same as RF Burst trigger source.
Remote Command Notes	See the "Sync Source" section.
Key Path	Trig, Periodic Timer, Sync Source

Trigger Level

Sets the absolute trigger level for the RF burst envelope. See key notes regarding the relative trigger level..

Remote Command	:TRIGger[:SEquence]:FRAMe:RFBurst:LEVel:ABSolute <ampl> :TRIGger[:SEquence]:FRAMe:RFBurst:LEVel:ABSolute?
Dependencies/Couplings	This same level is used in the RF Burst trigger source in the Trigger menu, for the period timer sync source (in the Trigger menu).
Preset	-20 dBm
State Saved	Saved in instrument state.
Min	-100 dBm
Max	100 dBm
Key Path	Trig, Periodic Timer, Sync Source, RF Burst
Default Unit	Absolute trig level: depends on the current selected amplitude units.

Trig Slope

Controls the trigger polarity. It is set positive to trigger on a rising edge and negative to trigger on a falling edge.

Remote Command	:TRIGger[:SEquence]:FRAMe:RFBurst:SLOPe POSitive NEGative :TRIGger[:SEquence]:FRAMe:RFBurst:SLOPe?
Example	TRIG:FRAM:RFB:SLOP NEG
Dependencies/Couplings	This same slope is used in the RF Burst trigger source in the Trigger menu and for the period timer sync source (in the Trigger menu).
Preset	POSitive
State Saved	Saved in instrument state.
Key Path	Trig, Periodic Timer, Sync Source, RF Burst

Trigger

Trig Delay

This setting delays the measurement timing relative to the Periodic Timer.

Remote Command	<code>:TRIGger[:SEquence]:FRAMe:DELay <time></code> <code>:TRIGger[:SEquence]:FRAMe:DELay?</code> <code>:TRIGger[:SEquence]:FRAMe:DELay:STATe OFF ON 0 1</code> <code>:TRIGger[:SEquence]:FRAMe:DELay:STATe?</code>
Preset	1 us OFF
State Saved	Saved in instrument state.
Min	-150 ms
Max	+500 ms
Key Path	Trig, Periodic Timer
Default Unit	s

Auto Trig

Sets the time that the analyzer will wait for the trigger conditions to be met. If they are not met after that much time, then the analyzer is triggered anyway.

Remote Command	<code>:TRIGger[:SEquence]:ATRigger <time></code> <code>:TRIGger[:SEquence]:ATRigger?</code> <code>:TRIGger[:SEquence]:ATRigger:STATe OFF ON 0 1</code> <code>:TRIGger[:SEquence]:ATRigger:STATe?</code>
Example	TRIG:ATR:STAT ON TRIG:ATR 100 ms
Preset	100 ms OFF
State Saved	Saved in instrument state.
Min	0 s
Max	100 s
Key Path	Trig
Default Unit	s

Trig Holdoff

Sets the holdoff time between triggers. When the trigger condition is satisfied, the trigger occurs,

the delay begins, and the holdoff time begins. New trigger conditions will be ignored until the holdoff time expires. For a free-running trigger, the holdoff value is the minimum time between triggers.

Remote Command	:TRIGger[:SEQuence]:HOLDoff <time> :TRIGger[:SEQuence]:HOLDoff? :TRIGger[:SEQuence]:HOLDoff:STATe OFF ON 0 1 :TRIGger[:SEQuence]:HOLDoff:STATe?
Example	TRIG:HOLD:STAT ON TRIG:HOLD 100 ms
Preset	100 ms OFF
State Saved	Saved in instrument state.
Min	0 s
Max	.5 s
Key Path	Trig
Default Unit	s

Trigger

6 Complex Spectrum

The complex spectrum measurement provides spectrum analysis capability for the instrument. The control of the measurement was designed to be familiar to those who are accustomed to using swept spectrum analyzers.

This measurement is FFT (Fast Fourier Transform) based. The FFT-specific parameters are located in the advanced menu. Also available under basic mode spectrum measurements is an I/Q window, which shows the I and Q signal waveforms in parameters of voltage versus time. The advantage of having an I/Q view available while in the spectrum measurement is that it allows you to view complex components of the same signal without changing settings or measurements.

Key Path	Front-panel key
----------	-----------------

The following table shows the returned results of the FETCh | MEASure | READ commands.

```
:CONFigure:SPECTrum
:INITiate:SPECTrum
:FETCh:SPECTrum [n]
:MEASure:SPECTrum [n]
:READ:SPECTrum [n]
```

The general functionality of CONFigure, INITiate, FETCh, MEASure, and READ are described in this section. See the SENSE subsystem commands for more measurement related commands.

n	Results Returned
0	Returns unprocessed I/Q trace data, as a series of trace point values, in volts. The I values are listed first in each pair, using the 0 through even-indexed values. The Q values are the odd-indexed values.

not specified or n=1	<p>Returns the following comma-separated scalar results:</p> <ol style="list-style-type: none"> 1. FFT peak is the FFT peak amplitude. 2. FFT frequency is the FFT frequency of the peak amplitude. 3. FFT points is the Number of points in the FFT spectrum. 4. First FFT frequency is the frequency of the first FFT point of the spectrum. 5. FFT spacing is the frequency spacing between the FFT points of the spectrum. 6. Time domain points is the number of points in the time domain trace used for the FFT. The number of points doubles if the data is complex instead of real. See the time domain scalar description below. 7. First time point is the time of the first time domain point, where time zero is the trigger event. 8. Time spacing is the time spacing between the time domain points. The time spacing value doubles if the data is complex instead of real. See the time domain scaler description below. 9. Time domain returns a 1 if time domain is complex (I/Q) and complex data will be returned. It returns a 0 if the data is real. (raw ADC samples) When this value is 1 rather than 0 (complex vs. real data), the time domain points and the time spacing scalars both increase by a factor of two. 10. Scan time is the total scan time of the time domain trace used for the FFT. The total scan time = (time spacing) (time domain points 1) 11. Current average count is the current number of data measurements that have already been combined, in the averaging calculation.
2	Returns the trace data of the log-magnitude versus time. (That is, the RF envelope.)
3	Returns the I and Q trace data. It is represented by I and Q pairs (in volts) versus time.
4	Returns spectrum trace data. That is, the trace of log-magnitude versus frequency. (The trace is computed using a FFT.)
5	Returns the averaged trace data of log-magnitude versus time. (That is, the RF envelope.)
6	Not used.
7	Returns the averaged spectrum trace data. That is, the trace of the averaged log-magnitude versus frequency.
8	Not used.
9	Returns a trace containing the shape of the FFT window.
10	Returns trace data of the phase of the FFT versus frequency.
11	Returns comma-separated linear spectrum trace data in Volts RMS.
12	Returns comma-separated averaged linear spectrum trace data in Volts RMS.

Measurement Results View

Figure 1-2 Complex Spectrum Measurement Spectrum View shows an example of a Spectrum view for the Complex Spectrum Measurement. The upper half Spectrum window shows the trace of the signal and its average in the frequency domain. In the lower half, the I/Q SPECTrum window shows the traces of the I and Q of the input signal. The measured values for the mean power and peak-to-mean power are shown in the text window.




Figure 1-2 Complex Spectrum Measurement Spectrum View

Trace Results

There are two trace views: Spectrum and I/Q Spectrum.

Spectrum Window

Marker Trace	Yes
Corresponding Trace	Returns spectrum trace data. That is, the trace of log-magnitude versus frequency. (The trace is computed using a FFT.) (n=4)
Corresponding Trace	Returns the averaged trace data of log-magnitude versus time. (That is, the RF envelope.) (n=5)

I/Q SPECTrum Window

Marker Trace	Yes
Corresponding Trace	Returns the I and Q trace data. It is represented by I and Q pairs (in volts) versus time. (n=3)

Span X Scale

Accesses the frequency span menu when the spectrum view is active, or the horizontal time menu when the waveform view is active.

Key Path **Front-panel key**

Span (Spectrum View)

Allows you to modify the frequency span in spectrum view for the complex spectrum measurement. This is translated to the required IF bandwidth for the FFT analysis. The analyzer's IF bandwidth is always equal or greater than this value.

Since the max IF Bandwidth is 8 MHz for narrowband mode, the Span's max IF Bandwidth will be 8 MHz.

Mode	BASIC
Remote Command	<code>[:SENSe] :SPECTrum:FREQuency:SPAN <freq></code> <code>[:SENSe] :SPECTrum:FREQuency:SPAN?</code>
Example	<code>:SPEC:FREQ:SPAN 10Hz</code>
Dependencies/Couplings	Changing the span causes the resolution bandwidth to change automatically, and will affect data acquisition time.
Remote Command Notes	You must be in IQ Analyzer (Basic) mode to use this command. Use <code>INSTRument:SElect</code> to set the mode.
Preset	8 MHz
State Saved	Saved in instrument state.
Min	10 Hz
Max	Hardware Dependent: No Option = 8.0 MHz Option B25 = 25.0 MHz
Key Path	SPAN X Scale

Ref Value (Waveform View)

Sets the horizontal scale reference value in the waveform view window.

Mode BASIC

Remote Command	<code>:DISPlay:SPECTrum:VIEW[1]:WINDow2:TRACe:X[:SCALE]:RLEVel <time></code> <code>:DISPlay:SPECTrum:VIEW[1]:WINDow2:TRACe:X[:SCALE]:RLEVel?</code>
Restriction and Notes	If the Auto Scaling is set to On, this value is automatically determined by the measurement result. When you set this value manually, Auto Scaling automatically changes to Off.
Dependencies/Couplings	When you set a value manually, Auto Scaling automatically changes to Off.
Remote Command Notes	You must be in IQ Analyzer (Basic) mode to use this command. Use INSTRUMENT:SELEct to set the mode.
Preset	0.000 s
State Saved	Saved in instrument state.
Min	-1.00 s
Max	10.00 s
Key Path	SPAN X Scale

Scale/Div (Waveform View)

Allows you to set the horizontal scale in the waveform view window by changing the time value per division.

Mode	BASIC
Remote Command	<code>:DISPlay:SPECTrum:VIEW[1]:WINDow2:TRACe:X[:SCALE]:PDIvIson <time></code> <code>:DISPlay:SPECTrum:VIEW[1]:WINDow2:TRACe:X[:SCALE]:PDIvIson?</code>
Restriction and Notes	If the Auto Scaling is set to On, this value is automatically determined by the measurement result. When you set this value manually, Auto Scaling automatically changes to Off.
Dependencies/Couplings	When you set a value manually, Auto Scaling automatically changes to Off.
Remote Command Notes	You must be in IQ Analyzer (Basic) mode to use this command. Use INSTRUMENT:SELEct to set the mode.
Preset	18.80 us
State Saved	Saved in instrument state.
Min	1.000 ns

Max	1.000 s
Key Path	SPAN X Scale

Ref Position (Waveform View)

Allows you to set the reference position in the waveform view window to Left, Ctr (center) or Right.

Mode	BASIC
Remote Command	<code>:DISPlay:SPECTrum:VIEW[1]:WINDow2:TRACe:X[:SCALe]:RPOS ition LEFT CENTer RIGHT</code> <code>:DISPlay:SPECTrum:VIEW[1]:WINDow2:TRACe:X[:SCALe]:RPOS ition?</code>
Remote Command Notes	You must be in IQ Analyzer (Basic) mode to use this command. Use INSTRument:SElect to set the mode.
Preset	LEFT
State Saved	Saved in instrument state.
Range	Left Ctr Right
Key Path	SPAN X Scale

Auto Scaling (Waveform View)

Allows you to toggle the Auto Scaling function in the waveform view window between On and Off.

Mode	BASIC
Remote Command	<code>:DISPlay:SPECTrum:VIEW[1]:WINDow2:TRACe:X[:SCALe]: COUple 0 1 OFF ON</code> <code>:DISPlay:SPECTrum:VIEW[1]:WINDow2:TRACe:X[:SCALe]: COUple</code>
Restriction and Notes	Upon pressing the Restart front-panel key, this function automatically determines the scale per division and reference values based on the measurement results. When you set a value to either Scale/Div or Ref Value manually, Auto Scaling automatically changes to Off.

Remote Command Notes	You must be in IQ Analyzer (Basic) mode to use this command. Use INSTRUMENT:SElect to set the mode.
Preset	ON
State Saved	Saved in instrument state.
Range	On Off
Key Path	SPAN X Scale

AMPTD Y Scale

Accesses the vertical scale parameters menu. The menu selection is dependant on the active window view.

Key Path **Front-panel key**

Ref Value

Enables you to adjust the absolute power reference value. Ref in the upper left corner of the display, indicates the current value. To change the reference level, use the front-panel step keys, knob, or numeric keypad.

Ref Value (Spectrum window)

Enables you to adjust the absolute power reference value in the spectrum view window. Ref in the upper left corner of the display, indicates the current value. To change the reference level, use the front-panel step keys, knob, or numeric keypad.

Mode	BASIC
Remote Command	:DISPlay:SPECTrum:VIEW[1]:WINDow[1]:TRACe:Y[:SCALe]:RLEVel <ampl> :DISPlay:SPECTrum:VIEW[1]:WINDow[1]:TRACe:Y[:SCALe]:RLEVel?
Example	:DISP:SPEC:VIEW:WIND:TRAC:Y:RLEV 100
Restriction and Notes	The default setting is 0.00 dBm. However, since the Auto Scaling default is On, this value is automatically determined by the measurement result.
Dependencies/Couplings	When Auto Scaling is turned on, this value is automatically determined by the measurement result. When this value is set, Auto Scaling is turned off. Attenuation is not coupled to Ref Value.
Remote Command Notes	You must be in IQ Analyzer (Basic) mode to use this command. Use INSTRument:SElect to set the mode.
Preset	0.00 dBm
State Saved	Saved in instrument state.
Min	-250 dBm
Max	250 dBm
Key Path	AMPTD Y Scale

Ref Value (I/Q Waveform window)

Enables you to adjust the absolute voltage reference value in the waveform view window. Ref in the upper left corner of the display, indicates the current value. To change the reference level, use the front-panel step keys, knob, or numeric keypad.

Mode	BASIC
Remote Command	:DISPlay:SPECTrum:VIEW[1]:WINDow2:TRACe:Y[:SCALE]:RLEVel <voltage> :DISPlay:SPECTrum:VIEW[1]:WINDow2:TRACe:Y[:SCALE]:RLEVel?
Example	:DISP:SPEC:VIEW:WIND2:TRAC:Y:RLEV 120
Restriction and Notes	The default setting is 0.0 V. However, since the Auto Scaling default is On, this value is automatically determined by the measurement result.
Dependencies/Couplings	When Auto Scaling is turned on, this value is automatically determined by the measurement result. When this value is set, Auto Scaling is turned off.
Remote Command Notes	You must be in IQ Analyzer (Basic) mode to use this command. Use INSTRument:SELEct to set the mode.
Preset	0 V
State Saved	Saved in instrument state.
Min	-250 V
Max	250 V
Key Path	AMPTD Y Scale

Attenuation

Accesses the Attenuation menu to change attenuation settings. This key has a readback text that describes total attenuator value. Refer to the Spectrum Analyzer mode for more information.

Key Path **AMPTD Y Scale**

Scale/Div

Sets the units per vertical graticule division on the display.

Scale/Div (Spectrum)

Sets the vertical scale in spectrum view by changing the amplitude value per division.

Mode	BASIC
Remote Command	:DISPlay:SPECTrum:VIEW[1]:WINDow[1]:TRACe:Y[:SCALe]:PDIVision <rel_ampl> :DISPlay:SPECTrum:VIEW[1]:WINDow[1]:TRACe:Y[:SCALe]:PDIVision?
Example	:DISP:SPEC:VIEW:WIND:TRAC:Y:PDIV 10
Restriction and Notes	The default setting is 10.00 dB. However, since the Auto Scaling default is On, this value is automatically determined by the measurement result.
Dependencies/Couplings	When you set a value manually, Auto Scaling automatically changes to Off. When Auto Scaling is turned on, this value is automatically determined by the measurement result.
Remote Command Notes	You must be in IQ Analyzer (Basic) mode to use this command. Use INSTRument:SELEct to set the mode.
Preset	10 dB
State Saved	Saved in instrument state.
Min	0.10 dB
Max	20 dB
Key Path	AMPTD Y Scale

Scale/Div (I/Q Waveform)

Sets the vertical scale in waveform view by changing the amplitude value per division.

Mode	BASIC
Remote Command	:DISPlay:SPECTrum:VIEW[1]:WINDow2:TRACe:Y[:SCALe]: PDIVision <voltage> :DISPlay:SPECTrum:VIEW[1]:WINDow2:TRACe:Y[:SCALe]: PDIVision?
Example	:DISP:SPEC:VIEW:WIND2:TRAC:Y:PDIV 10
Restriction and Notes	The default setting is 100.0 mV. However, since the Auto Scaling default is On, this value is automatically determined by the measurement result.
Dependencies/Couplings	When you set a value manually, Auto Scaling automatically changes to Off. When Auto Scaling is turned on, this value is automatically determined by the measurement result.
Remote Command Notes	You must be in IQ Analyzer (Basic) mode to use this command. Use INSTRument:SELEct to set the mode.
Preset	100.0 mV
State Saved	Saved in instrument state.
Min	1.00 nV
Max	20.0 V
Key Path	AMPTD Y Scale

Internal Preamp

Accesses keys that control the internal preamps. Turning on the preamp gives a better noise figure, but a poorer TOI to noise floor dynamic range. You can optimize this setting for your particular measurement. Refer to the Spectrum Analyzer mode for more information.

Key Path	AMPTD Y Scale
----------	----------------------

Ref Position

Allows you to set the reference position to either Left, Ctr (center) or Right.

Ref Position (Spectrum)

Allows you to set the spectrum reference position to either Top, Ctr (center) or Bottom.

Mode	BASIC
Remote Command	:DISPlay:SPECTrum:VIEW[1]:WINDow[1]:TRACe:Y[:SCALe]:RPO Sition TOP CENTer BOTTom :DISPlay:SPECTrum:VIEW[1]:WINDow[1]:TRACe:Y[:SCALe]:RPO Sition?
Example	:DISP:SPEC:VIEW:WIND2:TRAC:Y:RPOS CENT
Remote Command Notes	You must be in IQ Analyzer (Basic) mode to use this command. Use INSTRument:SELEct to set the mode.
Preset	TOP
State Saved	Saved in instrument state.
Range	Top Ctr Bot
Key Path	AMPTD Y Scale, More

Ref Position (IQ Waveform)

Allows you to set the spectrum reference position to either Top, Ctr (center) or Bottom.

Mode	BASIC
Remote Command	:DISPlay:SPECTrum:VIEW[1]:WINDow2:TRACe:Y[:SCALe]:RPOS ition TOP CENTer BOTTom :DISPlay:SPECTrum:VIEW[1]:WINDow2:TRACe:Y[:SCALe]:RPOS ition?
Example	:DISP:SPEC:VIEW:WIND2:TRAC:Y:RPOS TOP
Remote Command Notes	You must be in IQ Analyzer (Basic) mode to use this command. Use INSTRument:SELEct to set the mode.
Preset	CENTer
State Saved	Saved in instrument state.
Range	Top Ctr Bot
Key Path	AMPTD Y Scale, More

Auto Scaling

Allows you to toggle the Auto Scaling function between On and Off. Upon pressing the Restart front-panel key or Restart softkey under the Meas Control menu, the Auto Scaling function automatically determines the scale per division and reference values based on the measurement

results.

Mode	BASIC
Remote Command	:DISPlay:SPECTrum:VIEW[1]:WINDow[1] 2:TRACe:Y[:SCALe]:COUPlE ON OFF 1 0 :DISPlay:SPECTrum:VIEW[1]:WINDow[1] 2:TRACe:Y[:SCALe]:COUPlE?
Example	:DISP:SPEC:VIEW:WIND2:TRAC:Y:COUP 0
Dependencies/Couplings	When you set a value to either Scale/Div or Ref Value manually, Auto Scaling automatically changes to Off. When this value is turned on, Ref Value and Scale/Div are automatically determined by the measurement result.
Remote Command Notes	You must be in IQ Analyzer (Basic) mode to use this command. Use INSTRument:SELEct to set the mode.
Preset	OFF
State Saved	Saved in instrument state.
Range	On Off
Key Path	AMPTD Y Scale, More

View/Display

Accesses the Display menu that allows you to control certain functions related to the display of the analyzer. Refer to the Spectrum Analyzer mode for more information.

Display

Invokes the Display menu and allows you to control certain functions related to the display of the analyzer. Refer to the Spectrum Analyzer mode for more information.

Change Title

Writes a title across the top of the display. Press Change Title to access the Alpha Editor Menus that contain available characters and symbols. You may also use the numeric keypad to enter numbers. Press Enter or Return to complete the entry. Press ESC to cancel the entry and preserve your existing title.

The display title will remain until you press Change Title again, or you recall a trace or state, or a Factory Preset is performed. A title can also be cleared by pressing Title, Clear Title.

Pressing this key cancels any active function.

Mode	BASIC
Remote Command	:DISPlay:SPECTrum:ANNotation:TITLe:DATA <string> :DISPlay:SPECTrum:ANNotation:TITLe:DATA?
Example	DISP:SPEC:ANN:TITL:DATA "Agilent" DISP:SPEC:ANN:TITL:DATA?
Preset	Complex Spectrum
State Saved	Saved in instrument state.
Range	Uppercase, Lowercase, Numeric, Symbol
Key Path	View/Display, Display, Title

Trace/Detector

There is no Trace/Detector functionality supported in Complex Spectrum so this front-panel key will display a blank menu key when pressed.

BW

Opens the Bandwidth menu.

Key Path **Front-panel key**

Res BW

Allows you to set the resolution bandwidth setting. This is the resolution bandwidth of the FFT analysis. So, changing this value will change the FFT Window size, FFT length and the sweep time (measurement capture length).

If FFT Length Ctrl in the FFT Size menu under Meas Setup, Advanced is set to Manual, Res BW is grayed out and shows the resolution bandwidth determined by the FFT Window size.

Mode	BASIC
Remote Command	<code>[:SENSe] :SPECTrum: BANDwidth [:RESolution] <bandwidth></code> <code>[:SENSe] :SPECTrum: BANDwidth [:RESolution] ?</code> <code>[:SENSe] :SPECTrum: BANDwidth [:RESolution] :AUTO ON OFF 1 0</code> <code>[:SENSe] :SPECTrum: BANDwidth [:RESolution] :AUTO?</code>
Example	<code>:SENS:SPEC:BAND:RES:AUTO OFF</code>
Remote Command Notes	You must be in IQ Analyzer (Basic) mode to use this command. Use <code>INSTRument:SElect</code> to set the mode. You must be in IQ Analyzer (Basic) mode to use this command. Use <code>INSTRument:SElect</code> to set the mode.
Preset	160 kHz ON
State Saved	Saved in instrument state.
Min	0.1 Hz
Max	3.0 MHz
Key Path	BW

Meas Setup

Opens the menu that allows you to set up the measurement parameters.

Key Path **Front-panel key**

Avg/Hold Num

Sets the number of ‘sweeps’ that will be averaged. After the specified number of ‘sweeps’ (average counts), the averaging mode (terminal control) setting determines the averaging action.

Mode	BASIC
Remote Command	[:SENSE]:SPECTrum:AVERAge:COUNT <integer> [:SENSE]:SPECTrum:AVERAge:COUNT? [:SENSE]:SPECTrum:AVERAge[:STATe] ON OFF 1 0 [:SENSE]:SPECTrum:AVERAge[:STATe]?
Example	:SPEC:AVER:COUN 10 :SPEC:AVER 0
Remote Command Notes	You must be in IQ Analyzer (Basic) mode to use this command. Use INSTRument:SElect to set the mode. You must be in IQ Analyzer (Basic) mode to use this command. Use INSTRument:SElect to set the mode.
Preset	25 ON
State Saved	Saved in instrument state.
Min	1
Max	20001
Key Path	Meas Setup

Avg Mode

Press Avg Mode (Exp) to continue measurement averaging, using the specified number of averages to compute each averaged value. The average will be displayed at the end of each sweep. Avg Mode

(Repeat) will cause the measurement to reset the average counter each time the specified number of averages is reached.

Mode	BASIC
Remote Command	<code>[:SENSe] :SPECTrum:AVERAge:TCONtrol EXPONential REPEAT</code> <code>[:SENSe] :SPECTrum:AVERAge:TCONtrol?</code>
Example	<code>SPEC:AVER:TCON REP</code>
Remote Command Notes	You must be in IQ Analyzer (Basic) mode to use this command. Use <code>INSTRument:SELEct</code> to set the mode.
Preset	EXPONential
State Saved	Saved in instrument state.
Range	Exp Repeat
Key Path	Meas Setup

Avg Type

Allows you to select the type of averaging.

Mode	BASIC
Remote Command	<code>[:SENSe] :SPECTrum:AVERAge:TYPE</code> <code>LOG MAXimum MINimum RMS SCALar</code> <code>[:SENSe] :SPECTrum:AVERAge:TYPE?</code>
Remote Command Notes	You must be in IQ Analyzer (Basic) mode to use this command. Use <code>INSTRument:SELEct</code> to set the mode.
Preset	LOG
State Saved	Saved in instrument state.
Range	Pwr Avg(RMS) Log-Pwr Avg(Video) Voltage Avg
Key Path	Meas Setup

Meas Preset

Returns all measurement local parameters to the factory default values.

Mode	BASIC
Remote Command	:CONFigure:SPECTrum
Remote Command Notes	You must be in IQ Analyzer (Basic) mode to use this command. Use INSTRument:SElect to set the mode.
Key Path	Meas Setup, More

Advanced

Opens a menu of advanced settings for the complex spectrum measurement.

Key Path	Front-panel key
----------	------------------------

Pre-ADC BPF

Enables or disables the Pre-ADC bandpass filter.

Mode	BASIC
Remote Command	[[:SENSe]:SPECTrum:BANDwidth:PADC ON OFF 1 0 [:SENSe]:SPECTrum:BANDwidth:PADC?
Remote Command Notes	You must be in IQ Analyzer (Basic) mode to use this command. Use INSTRument:SElect to set the mode.
Preset	ON
State Saved	Saved in instrument state.
Range	ON OFF
Key Path	Meas Setup, More, Advanced

Pre-FFT Fltr

Allows the user to select the type of pre-FFT filter (FPGA post ADC, digital filter) that is used. This

is an advanced control that normally does not need to be changed.

Mode	BASIC
Remote Command	<code>[:SENSe] :SPECTrum: BANDwidth: PFFT: TYPE</code> <code>FLAT GAUSSian</code> <code>[:SENSe] :SPECTrum: BANDwidth: PFFT: TYPE?</code>
Remote Command Notes	You must be in IQ Analyzer (Basic) mode to use this command. Use INSTRument:SELEct to set the mode.
Preset	FLAT
State Saved	Saved in instrument state.
Range	Gaussian Flat
Key Path	Meas Setup, More, Advanced

Pre-FFT BW

Allows you to select auto or manual control for the pre-FFT Bandwidth setting. This is an advanced control that normally does not need to be changed. This parameter is also called “IFBw” or “InfoBw”.

Mode	BASIC
Remote Command	<pre>[:SENSe] :SPECTrum:BAWdwidth:PFfT[:SIZE] <bandwidth> [:SENSe] :SPECTrum:BAWdwidth:PFfT[:SIZE] ? [:SENSe] :SPECTrum:BAWdwidth:PFfT:AUTO ON OFF 1 0 [:SENSe] :SPECTrum:BAWdwidth:PFfT:AUTO?</pre>
Dependencies/Couplings	<p>The bandwidth of the Pre-FFTBPF is coupled to the span by the following equations.</p> $\text{PreFFT-BW} = \text{Span} * 1.5$ <p>Since the PreFFT-BW can only set to discrete values, PreFFT-BW will not always be set by the exact value above.</p> <p>If the hardware cannot set to the exact value of the requested PreFFT-BW, it will use “the next wider BW” available.</p> <p>For instance, a PreFFT-BW requested to be set at 3.01 MHz will actually be set to 3.1 MHz in the hardware.</p>
Remote Command Notes	You must be in IQ Analyzer (Basic) mode to use this command. Use INSTRUMENT:SELEct to set the mode.
Preset	<p>Hardware Dependent:</p> <p>No Option = 10.0 MHz</p> <p>Option B25 = 25.0 MHz</p> <p>ON</p>
State Saved	Saved in instrument state.
Min	10 Hz
Max	<p>Hardware Dependent:</p> <p>No Option = 10.0 MHz</p> <p>Option B25 = 25.0 MHz</p>
Key Path	Meas Setup, More, Advanced

FFT Window

Opens a menu selection that allows you to choose one of several available FFT filtering windows.

Mode	BASIC
Remote Command	<code>[:SENSe] :SPECTrum:FFT:WINDow[:TYPE]</code> BH4Tap BLACKman FLATtop GAUSSian HAMMING HANNing KB70 KB90 KB110 UNIFORM <code>[:SENSe] :SPECTrum:FFT:WINDow[:TYPE] ?</code>
Remote Command Notes	This selection affects the acquisition point quantity and the FFT size, based on the resolution bandwidth selected. You must be in IQ Analyzer (Basic) mode to use this command. Use INSTRUMENT:SELEct to set the mode.
Preset	FLATtop
State Saved	Saved in instrument state.
Range	Flat Top (High AmptdAcc) Uniform Hanning Hamming Gaussian (Alpha3.5) Blackman Blackman-Harris K-B 70 dB (Kaiser-Bessel) K-B 90 dB (Kaiser-Bessel) K-B 110 dB (Kaiser-Bessel)
Key Path	Meas Setup, More, Advanced

FFT Size

Opens a menu that allows you to set FFT or window length parameters.

Key Path	Meas Setup, Advanced
----------	-----------------------------

Length Ctrl

Length Ctrl (Man) enables control of FFT window or length settings. Press Length Ctrl (Auto) to disable FFT window or length settings. This setting is directly coupled to Res BW as follows: Enabling Length Ctrl disables Res BW, while disabling Length Ctrl allows Res BW control.

Mode	BASIC
Remote Command	<code>[:SENSe] :SPECTrum:FFT:LENGth:AUTO ON OFF 1 0</code> <code>[:SENSe] :SPECTrum:FFT:LENGth:AUTO?</code>
Remote Command Notes	You must be in IQ Analyzer (Basic) mode to use this command. Use INSTRument:SElect to set the mode.
Preset	ON
State Saved	Saved in instrument state.
Range	Auto Man
Key Path	Meas Setup, More, Advanced, FFT Size

Min Pnts/RBW

Sets the minimum number of data points that will be used inside the resolution bandwidth. The value is ignored if length control is set to manual. This is an advanced control that normally does not need to be changed.

Mode	BASIC
Remote Command	<code>[:SENSe] :SPECTrum:FFT:RBWPoints <real></code> <code>[:SENSe] :SPECTrum:FFT:RBWPoints?</code>
Remote Command Notes	You must be in IQ Analyzer (Basic) mode to use this command. Use INSTRument:SElect to set the mode.
Preset	3.1
State Saved	Saved in instrument state.
Min	0.1
Max	100
Key Path	Meas Setup, More, Advanced, FFT Size

WindowLength

Sets the FFT window length. This value is only used if length control is set to manual. This is an advanced control that normally does not need to be changed.

Note that the “points” is the number of points for IQ pairs. For example, if the WindowLength is set to 10, it means the window length is for 10 I and 10 Q points. Not 5 I and 5 Q points.

Mode	BASIC
Remote Command	<code>[:SENSe] :SPECTrum:FFT:WINDow:LENGth <integer></code> <code>[:SENSe] :SPECTrum:FFT:WINDow:LENGth?</code>
Remote Command Notes	You must be in IQ Analyzer (Basic) mode to use this command. Use INSTRument:SElect to set the mode.
Preset	1694
State Saved	Saved in instrument state.
Min	8
Max	1048576
Key Path	Meas Setup, More, Advanced, FFT Size

FFT Length

Allows you to set the FFT length. This value is only used if length control is set to manual. The value must be greater than or equal to the window length value. Any amount greater than the window length is implemented by zero padding. This is an advanced control that normally does not need to be changed.

Note that the “points” is the number of points for IQ pairs. For example, if the WindowLength is set to 10, it means the window length is for 10 I and 10 Q points. Not 5 I and 5 Q points.

Mode	BASIC
Remote Command	<code>[:SENSe] :SPECTrum:FFT:LENGth <integer></code> <code>[:SENSe] :SPECTrum:FFT:LENGth?</code>
Remote Command Notes	You must be in IQ Analyzer (Basic) mode to use this command. Use INSTRument:SElect to set the mode.
Preset	2048
State Saved	Saved in instrument state.
Min	566
Max	1048576
Key Path	Meas Setup, More, Advanced, FFT Size

ADC Dither

Opens the ADC Dither menu.

ADC Dither Auto Sets ADC Dither to Auto..

Mode	BASIC
Remote Command	<code>[:SENSe] :SPECTrum:ADC:DITHer:AUTO [:STATe] ON OFF 1 0</code> <code>[:SENSe] :SPECTrum:ADC:DITHer:AUTO [:STATe] ?</code>
Remote Command Notes	You must be in IQ Analyzer (Basic) mode to use this command. Use INSTRument:SElect to set the mode.
Preset	ON
State Saved	Saved in instrument state.
Range	Auto Man
Key Path	Meas Setup, More, Advanced, More, ADC Dither

ADC Dither State Turns ADC Dither on or off. .

Mode	BASIC
Remote Command	<code>[:SENSe] :SPECTrum:ADC:DITHer [:STATe] ON OFF 1 0</code> <code>[:SENSe] :SPECTrum:ADC:DITHer [:STATe] ?</code>
Remote Command Notes	You must be in IQ Analyzer (Basic) mode to use this command. Use INSTRument:SElect to set the mode.
Preset	OFF
State Saved	Saved in instrument state.
Range	On Off
Key Path	Meas Setup, More, Advanced, More, ADC Dither

IF Gain

Opens a menu that allows you to manually select IF Gain settings.

IF Gain Auto Returns manually selected IF Gain settings to the auto (default) setting.

Mode	BASIC
Remote Command	[:SENSe] :SPECTrum:IF:GAIN:AUTO [:STATe] ON OFF 1 0 [:SENSe] :SPECTrum:IF:GAIN:AUTO [:STATe] ?
Example	:SPEC:IF:GAIN:AUTO ON
Restriction and Notes	This table is for SCPI definition purpose only.
Remote Command Notes	You must be in IQ Analyzer (Basic) mode to use this command. Use INSTRument:SELEct to set the mode.
Preset	ON
State Saved	Saved in instrument state.
Range	On Off
Key Path	Meas Setup, More, Advanced, More, IF Gain

IF Gain State Allows you to optimize IF Gain for specific signals or signal levels.

Mode	BASIC, PN, WCDMA, C2K, 1XEVD0, GSM
Remote Command	[:SENSe] :SPECTrum:IF:GAIN [:STATe] AUTOrange LOW HIGH [:SENSe] :SPECTrum:IF:GAIN [:STATe] ?
Example	SPEC:IF:GAIN HIGH
Restriction and Notes	This table is for SCPI definition purpose only.
Remote Command Notes	You must be in IQ Analyzer (Basic) mode to use this command. Use INSTRument:SELEct to set the mode.
Preset	AUTO
State Saved	Saved in instrument state.
Range	Autorange (Slower Follows Signals) Low (Best for Large Signals) High (Best Noise Level)
Key Path	Meas Setup, More, Advanced, More, IF Gain

IF Flatness

Allows you to turn IF flatness corrections on and off. This overrides the system setting for the IF

flatness correction.

Mode	BASIC
Remote Command	<code>[:SENSe] :SPECTrum: BANDwidth: IF: FLATness ON OFF 1 0</code> <code>[:SENSe] :SPECTrum: BANDwidth: IF: FLATness?</code>
Remote Command Notes	You must be in IQ Analyzer (Basic) mode to use this command. Use INSTRUMENT:SElect to set the mode.
Preset	ON
State Saved	Saved in instrument state.
Range	On Off
Key Path	Meas Setup, More, Advanced, More

Trigger

Displays menu keys that allow you to select and control the trigger source for the current measurement. Refer to Measurement Functions for more information.

Trigger Source

Allows you to choose a trigger source for the current measurement. Trigger settings are mode global. Refer to “Trigger” in the Measurement Functions section.

Mode	BASIC
Remote Command	:TRIGger:SPECTrum[:SEQuence]:SOURce EXTernal [1] EXTernal2 IMMEDIATE IF VIDEO LINE RFBurst FRAME :TRIGger:SPECTrum[:SEQuence]:SOURce?
Restriction and Notes	IF is the same as VIDEO and it's for backward compatibility purpose
Remote Command Notes	You must be in the IQ Analyzer (Basic) mode to use this command. Use INSTRUMENT:SElect to set the mode.
Preset	IMMEDIATE
State Saved	Saved in instrument state.
Range	Free Run Video Line External 1 External 2 RF Burst(Wideband) Periodic Timer
Key Path	Trigger

Sweep/Control

Accesses the keys to control pausing/resuming the sweep or measurement. Refer to Measurement Functions for more information.

Pause/Resume

Pauses a measurement after the current data acquisition is complete. When Paused, the label on the key changes to Resume. Pressing Resume continues the paused measurement.

Key Path

Sweep/Control

Marker

The Marker front-panel key opens the marker menu.

Key Path	Front-panel key
----------	-----------------

Marker Type

Sets the marker control mode as described under **Normal**, **Delta** and **Off**, below. All interactions and dependencies detailed under the key description are enforced when the remote command is sent.

Mode	BASIC
Remote Command	:CALCulate:SPECTrum:MARKer [1] 2 3 4 5 6 7 8 9 10 11 12 :MODE POSITION DELTA OFF :CALCulate:SPECTrum:MARKer [1] 2 3 4 5 6 7 8 9 10 11 12 :MODE?
Example	:CALC:SPEC:MARK:MODE OFF
Restriction and Notes	If the selected marker is Off, pressing Marker sets it to Normal and places it at the center of the screen on the trace determined by the Marker Trace rules. At the same time, Marker X Axis Value appears on the Active Function area. Default Active Function: the active function for the selected marker's current control mode. Note that if the current control mode is Off, there is no active function and the active function is turned off. Active Function Display: the marker X axis value entered in the active function area will display the marker value to its full entered precision.
Remote Command Notes	You must be in IQ Analyzer (Basic) mode to use this command. Use INSTRument:SElect to set the mode.
Preset	OFF
State Saved	Saved in instrument state.
Range	Normal Delta Off
Key Path	Marker

Marker X Axis Value

Sets the marker X Axis value in the current marker X Axis Scale unit. It has no effect if the control mode is **Off**, but is the SCPI equivalent of entering an X value if the control mode is **Normal** or **Delta**.

Mode	BASIC
Remote Command	:CALCulate:SPECTrum:MARKer [1] 2 3 4 5 6 7 8 9 10 11 12:X <real> :CALCulate:SPECTrum:MARKer [1] 2 3 4 5 6 7 8 9 10 11 12:X?
Example	CALC:SPEC:MARK3:X?
Restriction and Notes	If no suffix is sent it will use the fundamental units for the current marker X Axis Scale. If a suffix is sent that does not match the current marker X Axis Scale unit, an error “Invalid suffix” will be generated. The query returns the marker’s absolute X Axis value if the control mode is Normal , or the offset from the marker’s reference marker if the control mode is Delta . The query is returned in the fundamental units for the current marker X Axis scale: Hz for Frequency and Inverse Time , seconds for Period and Time . If the marker is Off the response is not a number.
Remote Command Notes	You must be in IQ Analyzer (Basic) mode to use this command. Use INSTRument:SELEct to set the mode.
Preset	After a preset, all markers are turned OFF, so Marker X Axis Value query will return a not a number (NAN).
State Saved	No
Range	Depends on X axis range of selected Trace.

Marker X Axis Position

Sets the marker X position in trace points. It has no effect if the control mode is **Off**, but is the SCPI equivalent of entering a value if the control mode is **Normal** or **Delta** - except in trace points rather than X Axis Scale units. The entered value is immediately translated into the current X Axis Scale units for setting the value of the marker.

Mode	BASIC
Remote Command	:CALCulate:SPECTrum:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:X:POSition <real> :CALCulate:SPECTrum:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:X:POSition?
Example	CALC:SPEC:MARK10:X:POS?
Restriction and Notes	The query returns the marker's absolute X Axis value in trace points if the control mode is Normal , or the offset from the marker's reference marker in trace points if the control mode is Delta . The value is returned as a real number, not an integer, corresponding to the translation from X Axis Scale units to trace points. If the marker is Off the response is not a number.
Remote Command Notes	You must be in IQ Analyzer (Basic) mode to use this command. Use INSTRument:SELEct to set the mode.
Preset	After a preset, all markers are turned OFF, so Marker X Axis Value query will return a not a number (NAN).
State Saved	No
Range	Depends on length of selected Trace.

Marker Y Axis Value

Gets the marker Y value. Query only.

Mode	BASIC
Remote Command	:CALCulate:SPECTrum:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:Y?
Example	CALC:SPECTrum:MARK11:Y?
Remote Command Notes	You must be in IQ Analyzer (Basic) mode to use this command. Use INSTRument:SELEct to set the mode.
Preset	Result dependant on markers setup and signal source
State Saved	No

Relative To

Selects the marker relative to (its reference marker).

Mode	BASIC
Remote Command	:CALCulate:SPECTrum:MARKer [1] 2 3 4 5 6 7 8 9 10 11 12:REFerence <integer> :CALCulate:SPECTrum:MARKer [1] 2 3 4 5 6 7 8 9 10 11 12:REFerence?
Example	CALC:SPEC:MARK6:REF 8 CALC:SPEC:MARK:REF?
Restriction and Notes	A marker cannot be relative to itself so that choice is grayed out, and if sent from SCPI generates error -221: "Settings conflict; marker cannot be relative to itself."
Remote Command Notes	When queried a single value will be returned (the specified marker numbers relative marker).
Preset	2 3 4 5 6 7 8 9 10 11 12 1
State Saved	Saved in instrument state.
Min	1
Max	12
Key Path	Marker, Properties

Marker Trace

Assigns the specified marker to the designated trace.

Mode	BASIC
Remote Command	:CALCulate:SPECTrum:MARKer [1] 2 3 4 5 6 7 8 9 10 11 12:TRACe SPECTrum ASPECTrum IQ :CALCulate:SPECTrum:MARKer [1] 2 3 4 5 6 7 8 9 10 11 12:TRACe?
Example	CALC:SPEC:MARK:TRACE?
Remote Command Notes	You must be in IQ Analyzer (Basic) mode to use this command. Use INSTRument:SELEct to set the mode.
Preset	SPECTrum
State Saved	Saved in instrument state.
Range	Spectrum Spectrum Avg I/Q Waveform
Key Path	Marker

Couple Marker

When this function is true, moving any marker causes an equal X Axis movement of every other marker which is not **Off**. Note that “equal X Axis movement” preserves the difference between each marker’s X Axis value (in the fundamental x-axis units of the trace that marker is on) and the X Axis value of the marker being moved (in the same fundamental x-axis units).

Mode	BASIC
Remote Command	:CALCulate:SPECTrum:MARKer:COUPlE[:STATE] ON OFF 1 0 :CALCulate:SPECTrum:MARKer:COUPlE[:STATE] ?
Example	:CALC:SPEC:MARK:COUP ON
Remote Command Notes	You must be in IQ Analyzer (Basic) mode to use this command. Use INSTRument:SELEct to set the mode.
Preset	OFF
State Saved	Saved in instrument state.
Range	On Off
Key Path	Marker, More

All Markers Off

Turns off all markers.

Mode	BASIC
Remote Command	:CALCulate:SPECTrum:MARKer:AOFF
Example	CALC:SPEC:MARK:AOFF
Remote Command Notes	You must be in IQ Analyzer (Basic) mode to use this command. Use INSTRument:SELEct to set the mode.
Key Path	Marker, More

Backward Compatibility SCPI Commands

Sets or queries the state of a marker. Setting a marker which is OFF to state ON or 1 puts it in Normal mode and places it at the center of the screen.

Mode	BASIC
Remote Command	:CALCulate:SPECTrum:MARKer [1] 2 3 4 5 6 7 8 9 10 11 12:STATE OFF ON 0 1 :CALCulate:SPECTrum:MARKer [1] 2 3 4 5 6 7 8 9 10 11 12:STATE?
Example	CALC:SPEC:MARK3:STATE ON
Remote Command Notes	You must be in IQ Analyzer (Basic) mode to use this command. Use INSTRument:SELEct to set the mode.
Preset	OFF
State Saved	Saved in instrument state.
Range	On Off

Peak Search

Pressing the Peak Search front-panel key places the selected marker on the trace point with the maximum y-axis value for that marker's trace and opens this Peak Search menu.

Mode	BASIC
Remote Command	:CALCulate:SPECTrum:MARKer [1] 2 3 4 5 6 7 8 9 10 11 12 :MAXimum
Example	CALC:SPEC:MARK2:MAX
Remote Command Notes	You must be in IQ Analyzer (Basic) mode to use this command. Use INSTRument:SELEct to set the mode.
Key Path	Peak Search

Min Search

Moves the selected marker to the minimum y-axis value on the current trace.

Mode	BASIC
Remote Command	:CALCulate:SPECTrum:MARKer [1] 2 3 4 5 6 7 8 9 10 11 12 :MINimum
Example	CALC:SPEC:MARK:MIN
Remote Command Notes	You must be in IQ Analyzer (Basic) mode to use this command. Use INSTRument:SELEct to set the mode.
Key Path	Peak Search

Mkr->CF

Assigns the selected marker's frequency to the Center Frequency parameter.

See Mkr-> CF under "Marker To".

Marker To

Accesses menu keys that can copy the current marker value into another instrument parameter (for example, Center Freq). If the currently selected marker is not on when you press this front panel key, it will be turned on at the center of the screen as a normal marker.

Key Path **Front-panel key**

Mkr -> CF

Sets the center frequency to the frequency of the selected marker. The marker stays at this frequency, so it moves to the center of the display.

Mode	BASIC
Remote Command	:CALCulate:SPECTrum:MARKer [1] 2 3 4 5 6 7 8 9 10 11 12 [:SET] :CENTer
Example	CALC:SPEC:MARK4:SET:CENTER
Restriction and Notes	This key is not available (grayed out) when the selected marker is not on the spectrum trace. In delta marker mode, this function sets the center frequency to the x-axis value of the delta marker. If the currently selected marker is not on when this key is pressed, it will be turned on at the center of the screen as a normal type marker.
Remote Command Notes	You must be in IQ Analyzer (Basic) mode to use this command. Use INSTRument:SElect to set the mode.
Key Path	Marker ->

Mkr -> Ref Lvl

Sets the reference level to the amplitude value of the selected marker, moving the marked point to the reference level (top line of the graticule).

Mode	BASIC
Remote Command	:CALCulate:SPECTrum:MARKer [1] 2 3 4 5 6 7 8 9 10 11 12 [:SET] :RLEVEL
Example	CALC:SPEC:MARK4:SET:RLEVEL
Restriction and Notes	Make the Marker Y value display the reference value. If the currently selected marker is not on when this key is pressed, it will be turned on at the center of the screen as a normal type marker, and its amplitude applied to the reference value.
Remote Command Notes	You must be in IQ Analyzer (Basic) mode to use this command. Use INSTRument:SElect to set the mode.
Key Path	Marker ->

Marker Function

Opens the Marker Function menu.

Key Path **Front-panel key**

Marker Function Type

Sets the marker control mode as described under **Normal**, **Delta** and **Off**, below. All interactions and dependencies detailed under the key description are enforced when the remote command is sent.

Mode	BASIC
Remote Command	:CALCulate:SPECTrum:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:FUNction NOISe BPOWer BDENsity OFF :CALCulate:SPECTrum:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:FUNction?
Example	CALC:SPEC:MARK:FUNC NOIS
Remote Command Notes	You must be in IQ Analyzer (Basic) mode to use this command. Use INSTRument:SELEct to set the mode.
Preset	OFF
State Saved	Saved in instrument state.
Range	Marker Noise Band/Interval Power Band Interval Density Marker Function Off
Key Path	Marker Fctn

Band Adjust

Opens a menu of keys that allow you to modify the band.

Key Path **Marker Function**

Band/Interval Span for Frequency Domain

Sets the width of the span for the selected marker.

Mode	BASIC
Remote Command	:CALCulate:SPECTrum:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:FUNCTion:BAND:SPAN <freq> :CALCulate:SPECTrum:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:FUNCTion:BAND:SPAN?
Example	:CALC:SPEC:MARK12:FUNC:BAND:SPAN 20 MHz
Dependencies/Couplings	Changing the Band/Interval Span necessarily changes the Band/Interval Left and Band/Interval Right values
Remote Command Notes	You must be in IQ Analyzer (Basic) mode to use this command. Use INSTRument:SELEct to set the mode.
Preset	10% of Span
State Saved	Saved in instrument state.
Min	0
Max	26.5GHz
Key Path	Marker Fctn

Band/Interval Left for Frequency Domain

Sets the left edge frequency or time for the band of the selected marker.

Mode	BASIC
Remote Command	:CALCulate:SPECTrum:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:FUNCTion:BAND:LEFT <freq> :CALCulate:SPECTrum:MARKer[1] 2 3 4 5 6 7 8 9 10 11 12:FUNCTion:BAND:LEFT?
Example	:CALC:SPEC:MARK12:FUNC:BAND:LEFT 20 GHz
Dependencies/Couplings	Changing the Band/Interval Left necessarily changes the Band/Interval Span and Band/Interval Right values
Remote Command Notes	You must be in IQ Analyzer (Basic) mode to use this command. Use INSTRument:SELEct to set the mode.
Preset	5% of Span
State Saved	Saved in instrument state.
Min	0
Max	26.5GHz

Key Path **Marker Fctn**

Band/Interval Right for Frequency Domain

Sets the right edge frequency or time for the band of the selected marker.

Mode BASIC

Remote Command :CALCulate:SPECTrum:MARKer [1] | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 |
12:FUNction:BAND:RIGHT <freq>

:CALCulate:SPECTrum:MARKer [1] | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 |
12:FUNction:BAND:RIGHT?

Example :CALC:SPEC:MARK12:FUNC:BAND:RIGHT 20 GHz

Dependencies/Couplings Changing the Band/Interval Right necessarily changes the
Band/Interval Left and Band/Interval Span values

Remote Command You must be in IQ Analyzer (Basic) mode to use this command.
Notes Use INSTRument:SElect to set the mode.

Preset 5% of Span

State Saved Saved in instrument state.

Min 0

Max 26.5GHz

Key Path **Marker Fctn**

7 Waveform

The waveform measurement is a generic measurement for viewing the input signal waveforms in the time domain. This measurement is how the instrument performs the zero span functionality found in traditional spectrum analyzers. Also available under basic waveform measurements is an I/Q window, which shows the I and Q signal waveforms in parameters of voltage versus time to disclose the voltages which comprise the complex modulated waveform of a digital signal.

The waveform measurement can be used to perform general purpose power measurements to a high degree of accuracy as well.

Key Path **Meas**

The general functionality of CONFigure, INITiate, FETCh, MEASure, and READ are described at this section. See the SENSE subsystem commands for more measurement related commands.

The following table denotes the returned results from the FETCh | MEASure | READ commands:

:CONFigure:WAVeform
:INITiate:WAVeform
:FETCh:WAVeform [n]
:MEASure:WAVeform [n]
:READ:WAVeform [n]

n	Results Returned
----------	-------------------------

0	Returns unprocessed I/Q trace data, as a series of trace point values, in volts. The I values are listed first in each pair, using the 0 through even-indexed values. The Q values are the odd-indexed values.
---	--


- 1 Returns the following scalar results:
 - Sample Time is a floating point number representing the time between samples when using the trace queries (n=0, 2, etc.).
 - Mean Power is the mean power (in dBm). This is either the power across the entire trace, or the power between markers if the markers are enabled. If averaging is on, the power is for the latest acquisition.
 - Mean Power Averaged is the power (in dBm) for N averages, if averaging is on. This is either the power across the entire trace, or the power between markers if the markers are enabled. If averaging is on, the power is for the latest acquisition. If averaging is off, the value of the mean power averaged is the same as the value of the mean power.
 - Number of samples is the number of data points in the captured signal. This number is useful when performing a query on the signal (i.e. when n=0,2, and so forth.).
 - Peak-to-mean ratio has units of dB. This is the ratio of the maximum signal level to the mean power. Valid values are only obtained with averaging turned off. If averaging is on, the peak-to-mean ratio is calculated using the highest peak value, rather than the displayed average peak value.
 - Maximum value is the maximum of the most recently acquired data (in dBm).
 - Minimum value is the minimum of the most recently acquired data (in dBm).
- 2 Returns trace point values of the entire captured signal envelope trace data. These data points are floating point numbers representing the power of the signal (in dBm). There are N data points, where N is the number of samples. The period between the samples is defined by the sample time.

7.1 Measurement Results


The following information describes the Waveform measurement results.

7.1.1 Graphic Results View

This view shows an example of the RF Envelope result for the waveform (time domain) measurements in the graph window. The measured values for the mean power and peak-to-mean power are shown in the text window.



This view shows the I and Q signal waveforms in parameters of voltage versus time.



7.1.2 Numeric Results

Name	Type	Description	Unit	Format
Mean Pwr	Float64	The mean power (dBm). This is either the power across the entire trace, or the power between markers if the markers are enabled.	dBm	XX.XX dBm
Pk-to-Mean	Float64	This is the ratio of the maximum signal level to the mean power.	dB	XX.XX dB
Max Pt	Float64	The maximum of the most recently acquired data.	dBm	XX.XX dBm
Min Pt	Float64	The minimum of the most recently acquired data.	dBm	XX.XX dBm

7.2 Span X Scale

Accesses a menu of functions that enable you to set the horizontal scale parameters.

Key Path **Front-panel key**

7.2.1 Ref Value

Sets the reference value for time on the horizontal axis. When Auto Scaling is set to On, the displayed plots use a Scale/Div value determined by the analyzer, based on the measurement result.

Mode	BASIC, PN, WCDMA, C2K, 1XEVD0, GSM, WIMAXOFDMA
Remote Command	:DISPlay:WAVeform:VIEW[1] 2:WINDow[1]:TRACe:X[:SCALe]:RLEVel <time> :DISPlay:WAVeform:VIEW[1] 2:WINDow[1]:TRACe:X[:SCALe]:RLEVel?
Example	DISP:WAV:VIEW:WIND:TRAC:X:RLEV 10 ms DISP:WAV:VIEW:WIND:TRAC:X:RLEV?
Restriction and Notes	If the Auto Scaling is set to On, this value is automatically determined by the measurement result. When you set this value manually, Auto Scaling automatically changes to Off.
Dependencies/Couplings	When you set a value manually, Auto Scaling automatically changes to Off.
Remote Command Notes	You must be in the mode that includes Waveform measurements to use this command. Use INSTRument:SElect to set the mode.
Preset	0.00 s
State Saved	Saved in instrument state.
Min	-1.000 s
Max	10.00 s
Key Path	SPAN X Scale

7.2.2 Scale/Div

Sets the horizontal scale by changing a time value per division.

Mode **BASIC, PN, WCDMA, C2K, 1XEVD0, GSM, WIMAXOFDMA**

Remote Command	<code>:DISPlay:WAVeform:VIEW[1] 2:WINDow[1] :TRACe:X[:SCALe]:PDIVision <time></code> <code>:DISPlay:WAVeform:VIEW[1] 2:WINDow[1] :TRACe:X[:SCALe]:PDIVision?</code>
Example	<code>DISP:WAV:VIEW:WIND:TRAC:X:PDIV 500 us</code> <code>DISP:WAV:VIEW:WIND:TRAC:X:PDIV?</code>
Restriction and Notes	If the Auto Scaling is set to On, this value is automatically determined by the measurement result. When you set this value manually, Auto Scaling automatically changes to Off.
Dependencies/Couplings	When you set a value manually, Auto Scaling automatically changes to Off.
Remote Command Notes	You must be in the mode that includes Waveform measurements to use this command. Use <code>INSTrument:SElect</code> to set the mode.
Preset	200.0 us
State Saved	Saved in instrument state.
Min	1.000 ns
Max	1.000 s
Key Path	SPAN X Scale

7.2.3 Ref Position

Sets the reference position for the X axis to either Left, Center or Right.

Mode	BASIC, PN, WCDMA, C2K, 1XEVD0, GSM, WIMAXOFDMA
Remote Command	<code>:DISPlay:WAVeform:VIEW[1] 2:WINDow[1] :TRACe:X[:SCALe]:RPOStion LEFT CENTer RIGHT</code> <code>:DISPlay:WAVeform:VIEW[1] 2:WINDow[1] :TRACe:X[:SCALe]:RPOStion?</code>
Example	<code>DISP:WAV:VIEW:WIND:TRAC:X:RPOS LEFT</code> <code>DISP:WAV:VIEW:WIND:TRAC:X:RPOS?</code>
Restriction and Notes	Allows you to set the reference position to either Left, Ctr (center) or Right.
Remote Command Notes	You must be in the mode that includes Waveform measurements to use this command. Use <code>INSTrument:SElect</code> to set the mode.
Preset	LEFT

State Saved	Saved in instrument state.
Range	Left Ctr Right
Key Path	SPAN X Scale

7.2.4 Auto Scaling

Toggles the scale coupling function between On and Off.

Mode	BASIC, PN, WCDMA, C2K, 1XEVD0, GSM, WIMAXOFDMA
Remote Command	:DISP:WAVEform:VIEW[1] 2:WINDow[1] :TRACe:X[:SCALE]]:COUPle 0 1 OFF ON :DISP:WAVEform:VIEW[1] 2:WINDow[1] :TRACe:X[:SCALE]]:COUPle?
Example	DISP:WAV:VIEW:WIND:TRAC:X:COUP ON DISP:WAV:VIEW:WIND:TRAC:X:COUP?
Dependencies/Couplings	When Auto Scaling is On and the Restart front-panel key is pressed, this function automatically determines the scale per division and reference values based on the measurement results. When you set a value to either Scale/Div or Ref Value manually, Auto Scaling automatically changes to Off.
Remote Command Notes	You must be in the mode that includes Waveform measurements to use this command. Use INSTRument:SElect to set the mode.
Preset	1
State Saved	Saved in instrument state.
Range	On Off
Key Path	SPAN X Scale

7.3 AMPTD Y Scale

Accesses a menu of functions that enable you to set the vertical scale parameters.

Key Path	Front-panel key
----------	-----------------

7.3.1 Ref Value

Sets the absolute power reference value. However, since the Auto Scaling is defaulted to On, this value is automatically determined by the measurement result. When you set a value manually, Auto Scaling automatically changes to Off.

7.3.1.1 Ref Value (RF Envelope View)

Sets the Y Scale reference value (in dBm) when the RF Envelope View is active. By default, the measurement determines the reference value with Auto Scaling. Entering a reference value manually turns Auto Scaling off.

Mode	BASIC, PN, WCDMA, C2K, 1XEVD0, GSM, WIMAXOFDMA
Remote Command	:DISPlay:WAVeform:VIEW[1]:WINDow[1]:TRACe:Y[:SCALe]:RLEVel <ampl> :DISPlay:WAVeform:VIEW[1]:WINDow[1]:TRACe:Y[:SCALe]:RLEVel?
Example	DISP:WAV:VIEW:WIND:TRAC:Y:RLEV -50 dBm DISP:WAV:VIEW:WIND:TRAC:Y:RLEV?
Dependencies/Couplings	When the Auto Scaling is On, this value is automatically determined by the measurement result. When you set a value manually, Auto Scaling automatically changes to Off.
Remote Command Notes	You must be in the mode that includes Waveform measurements to use this command. Use INSTRument:SElect to set the mode.
Preset	10.00 dBm
State Saved	Saved in instrument state.
Range	-250.00 dBm to 250.00 dBm
Key Path	AMPTD/Y Scale

7.3.1.2 Ref Value (I/Q Waveform View)

Sets the Y Scale reference value (in volts) when the I/Q Waveform View is active. By default, the measurement determines the reference value with Auto Scaling. Entering a reference value

manually turns Auto Scaling off.

Mode	BASIC, PN, WCDMA, C2K, 1XEVD0, GSM, WIMAXOFDMA
Remote Command	:DISPlay:WAVeform:VIEW2:WINDow[1]:TRACe:Y[:SCALe]:RLEVel <voltage> :DISPlay:WAVeform:VIEW2:WINDow[1]:TRACe:Y[:SCALe]:RLEVel?
Example	DISP:WAV:VIEW2:WIND:TRAC:Y:RLEV 25 V DISP:WAV:VIEW2:WIND:TRAC:Y:RLEV?
Dependencies/Couplings	When the Auto Scaling is On, this value is automatically determined by the measurement result. When you set a value manually, Auto Scaling automatically changes to Off.
Remote Command Notes	You must be in the mode that includes Waveform measurements to use this command. Use INSTRument:SElect to set the mode.
Preset	0 V
State Saved	Saved in instrument state.
Min	-250 V
Max	250 V
Key Path	AMPTD/Y Scale

7.3.2 Attenuation

Accesses a menu of functions that enable you to change the attenuation settings. This key has a readback text that describes total attenuator value

See AMPTD Y Scale, Attenuation in the “Analyzer Setup Functions” section for more information.

Key Path	AMPTD Y Scale
----------	----------------------

7.3.3 Scale/Div

Sets the units per division of vertical scale in the logarithmic display. However, since the Auto Scaling is defaulted to On, this value is automatically determined by the measurement result. When you set a value manually, Auto Scaling automatically changes to Off.

7.3.3.1 Scale/Div (RF Envelope View)

Sets the scale per division for the RF Envelope result waveform (time domain) measurements in the graph window.

Mode	BASIC, PN, WCDMA, C2K, 1XEVD0, GSM, WIMAXOFDMA
------	--

Remote Command	:DISPlay:WAVEform:VIEW[1]:WINDow[1]:TRACe:Y[:SCALe]:PDIVision <rel_ampl> :DISPlay:WAVEform:VIEW[1]:WINDow[1]:TRACe:Y[:SCALe]:PDIVision?
Example	DISP:WAV:VIEW:WIND:TRAC:Y:PDIV 5 dB DISP:WAV:VIEW:WIND:TRAC:Y:PDIV?
Dependencies/Couplings	When the Auto Scaling is On, this value is automatically determined by the measurement result. When you set a value manually, Auto Scaling automatically changes to Off.
Remote Command Notes	You must be in the mode that includes Waveform measurements to use this command. Use INSTRument:SElect to set the mode.
Preset	10.00 dB
State Saved	Saved in instrument state.
Range	0.10 dB to 20.00 dB
Key Path	AMPTD/Y Scale

7.3.3.2 Scale/Div (I/Q Waveform View)

Sets the scale per division for the I/ Q signal waveform graph.

Mode	BASIC, PN, WCDMA, C2K, 1XEVD0, GSM, WIMAXOFDMA
Remote Command	:DISPlay:WAVEform:VIEW2:WINDow[1]:TRACe:Y[:SCALe]:PDIVision <voltage> :DISPlay:WAVEform:VIEW2:WINDow[1]:TRACe:Y[:SCALe]:PDIVision?
Example	DISP:WAV:VIEW2:WIND:TRAC:Y:PDIV 25 mV DISP:WAV:VIEW2:WIND:TRAC:Y:PDIV?
Dependencies/Couplings	When the Auto Scaling is On, this value is automatically determined by the measurement result. When you set a value manually, Auto Scaling automatically changes to Off.
Remote Command Notes	You must be in the mode that includes Waveform measurements to use this command. Use INSTRument:SElect to set the mode.
Preset	100.0 mV
State Saved	Saved in instrument state.
Min	1.0 nV

Max	20 V
Key Path	AMPTD/Y Scale

7.3.4 Internal Preamp

Accesses a menu of functions that enable you to control the internal preamplifiers.

See AMPTD Y Scale, Internal Preamp in the “Analyzer Setup Functions” section for more information.

Key Path	AMPTD Y Scale
----------	----------------------

7.3.5 Ref Position

Positions the reference level at the top, center or bottom of the Y Scale display. Changing the reference position does not change the reference level value.

7.3.5.1 Ref Position (RF Envelope View)

Positions the reference level at the top, center or bottom of the Y Scale display. Changing the reference position does not change the reference level value.

Mode	BASIC, PN, WCDMA, C2K, 1XEVD0, GSM, WIMAXOFDMA
Remote Command	:DISPlay:WAVeform:VIEW[1]:WINDow[1]:TRACe:Y[:SCALe]:RPOSition TOP CENTer BOTTom :DISPlay:WAVeform:VIEW[1]:WINDow[1]:TRACe:Y[:SCALe]:RPOSition?
Example	DISP:WAV:VIEW:WIND:TRAC:Y:RPOS CENT DISP:WAV:VIEW:WIND:TRAC:Y:RPOS?
Remote Command Notes	You must be in the mode that includes Waveform measurements to use this command. Use INSTRument:SElect to set the mode.
Preset	TOP
State Saved	Saved in instrument state.
Range	Top Ctr Bot
Key Path	AMPTD/Y Scale

7.3.5.2 Ref Position (I/Q Waveform View)

Positions the reference level at the top, center or bottom of the Y Scale display. Changing the reference position does not change the reference level value.

Mode	BASIC, PN, WCDMA, C2K, 1XEVD0, GSM, WIMAXOFDMA
------	--

Remote Command	:DISPlay:WAVEform:VIEW2:WINDow[1]:TRACe:Y[:SCALE]:RPOsition TOP CENTer BOTTom :DISPlay:WAVEform:VIEW2:WINDow[1]:TRACe:Y[:SCALE]:RPOsition?
Example	DISP:WAV:VIEW2:WIND:TRAC:Y:RPOS CENT DISP:WAV:VIEW2:WIND:TRAC:Y:RPOS?
Remote Command Notes	You must be in the mode that includes Waveform measurements to use this command. Use INSTRument:SElect to set the mode.
Preset	CENT
State Saved	Saved in instrument state.
Range	Top Ctr Bot
Key Path	AMPTD/Y Scale

7.3.6 Auto Scaling

Toggles the Auto Scaling function between On and Off. When the **Restart** front panel key is pressed, this function automatically determines the scale per division and reference values based on the measurement results.

Mode	BASIC, PN, WCDMA, C2K, 1XEVD0, GSM, WIMAXOFDMA
Remote Command	:DISPlay:WAVEform:VIEW[1] 2:WINDow[1]:TRACe:Y[:SCALE]:COUPle 0 1 OFF ON :DISPlay:WAVEform:VIEW[1] 2:WINDow[1]:TRACe:Y[:SCALE]:COUPle?
Example	DISP:WAV:VIEW:WIND:TRAC:Y:COUP OFF DISP:WAV:VIEW:WIND:TRAC:Y:COUP?
Dependencies/Couplings	When Auto Scaling is On, upon pressing the Restart front-panel key, this function automatically switches the scale per division and reference values into the defaults. When the user sets a value to either Scale/Div or Ref Value manually, Auto Scaling automatically changes to Off.
Remote Command Notes	You must be in the mode that includes Waveform measurements to use this command. Use INSTRument:SElect to set the mode.
Preset	OFF
State Saved	Saved in instrument state.
Range	On Off
Key Path	AMPTD Y Scale

7.4 View/Display

Accesses a menu of functions that enable you to set up and control the display parameters for the current measurement

Key Path **Front-panel key**

7.4.1 Display

Accesses a menu of functions that enable you to set the display parameters. See Display in the "Analyzer Setup Functions" section for more information.

Key Path **Front-panel key**

7.4.1.1 Change Title

Accesses an Alpha Editor menu that enables you to write a title across the top of the display. This menu contains characters and symbols that may also be used with the numeric keypad. Press Enter or Return to complete the entry. Press ESC to cancel the entry and preserve your existing title.

The display title will remain until you press Change Title again, or you recall a trace or state, or a Factory Preset is performed. A title can also be cleared by pressing Title, Clear Title.

This table is for SCPI definition purpose only and SCPI command and Preset/Default value are defined on measurement basis.

Mode	BASIC, PN, WCDMA, C2K, 1XEVD0, GSM, WIMAXOFDMA
Remote Command	:DISPlay:WAVeform:ANNotation:TITLe:DATA <string> :DISPlay:WAVeform:ANNotation:TITLe:DATA?
Example	DISP:WAV:ANN:TITL:DATA "Agilent"
Preset	IQ Waveform
State Saved	Saved in instrument state.
Range	Uppercase, Lowercase, Numeric, Symbol
Key Path	View/Display, Display, Title

7.4.2 View

Selects the results view.

Mode	BASIC, PN, WCDMA, C2K, 1XEVD0, GSM, WIMAXOFDMA
Remote Command	:DISPlay:WAVeform:VIEW[:SELEct] RFENvelope IQ :DISPlay:WAVeform:VIEW[:SELEct]?

Example	DISP:WAV:VIEW RFEN DISP:WAV:VIEW?
Remote Command Notes	You must be in the mode that includes Waveform measurements to use this command. Use INSTRUMENT:SELEct to set the mode.
Preset	RFENvelope
State Saved	Saved in instrument state.
Range	RF Envelope IQ Waveform
Key Path	View/Display

7.4.2.1 View Selection by number (SCPI only)

Displays the numeric values of the measurement results.

Mode	BASIC, PN, WCDMA, C2K, 1XEVDO, GSM, WIMAXOFDMA
Remote Command	:DISPlay:WAVeform:VIEW:NSElect <integer> :DISPlay:WAVeform:VIEW:NSElect?
Example	DISP:WAV:VIEW:NSEL 1 DISP:WAV:VIEW:NSEL?
Remote Command Notes	You must be in the mode that includes Waveform measurements to use this command. Use INSTRUMENT:SELEct to set the mode.
Preset	1
State Saved	Saved in instrument state.
Min	1
Max	2

7.5 Trace/Detector

There is no 'Trace/Detector' functionality supported in the Waveform measurement. The front-panel key will display a blank menu key when pressed.

Key Path

Front-panel key

7.6 BW

Accesses a menu that enables you to control the information bandwidth functions of the instrument. You can also select the filter type for the measurement.

Key Path **Front-panel key**

7.6.1 Info BW

Enables you to set the information bandwidth (Info BW) of the analyzer.

Mode	BASIC, PN, WCDMA, C2K, 1XEVDO, GSM, WIMAXOFDMA
Remote Command	<code>[:SENSe] :WAVeform :BANDwidth [:RESolution] <freq></code> <code>[:SENSe] :WAVeform :BANDwidth [:RESolution] ?</code>
Example	WAV:BAND 1 KHZ WAV:BAND?
Remote Command Notes	You must be in the mode that includes Waveform measurements to use this command. Use INSTRUMENT:SElect to set the mode.
Preset	100 kHz
State Saved	Saved in instrument state.
Min	10 Hz
Max	Hardware Dependent: No Option = 10 MHz Option B25 = 25 MHz
Key Path	BW

7.6.2 Filter Type

Selects the type of bandwidth filter that is used. The choices are Gaussian or Flat top.

Mode	BASIC, PN, WCDMA, C2K, 1XEVDO, GSM, WIMAXOFDMA
Remote Command	<code>[:SENSe] :WAVeform :BANDwidth :SHAPE</code> <code>GAUSSian FLATtop</code> <code>[:SENSe] :WAVeform :BANDwidth :SHAPE?</code>
Example	WAV:BAND:SHAP GAUS WAV:BAND:SHAP?

Dependencies/Couplings	See the description above
Remote Command Notes	You must be in the mode that includes Waveform measurements to use this command. Use INSTRUMENT:SElect to set the mode.
Preset	GAUSSian
State Saved	Saved in instrument state.
Range	Gaussian FlatTop
Key Path	BW, RBW Control, Filter Type

7.7 Meas Setup

Displays the setup menu keys that enables you to control the parameters for the current measurement.

Key Path	Front-panel key
----------	------------------------

7.7.1 Average/Hold Number

Sets the number of sweeps (average counts) that will be averaged. After the specified number of sweeps, the averaging mode (terminal control) setting determines the averaging action.

Mode	BASIC, PN, WCDMA, C2K, 1XEVD0, GSM, WIMAXOFDMA
------	--

Remote Command	[:SENSe] :WAVeform:AVERAge:COUNT <integer> [:SENSe] :WAVeform:AVERAge:COUNT? [:SENSe] :WAVeform:AVERAge [:STATe] OFF ON 0 1 [:SENSe] :WAVeform:AVERAge [:STATe] ?
-----------------------	--

Example	WAV:AVER:COUN 1001 WAV:AVER:COUN? WAV:AVER ON WAV:AVER?
---------	--

Remote Command Notes	You must be in the mode that includes Waveform measurements to use this command. Use INSTRument:SElect to set the mode. You must be in the mode that Waveform measurement is included to use this command. Use INSTRument:SElect to set the mode.
----------------------	--

Preset	10 OFF
--------	-----------

State Saved	Saved in instrument state.
-------------	----------------------------

Min	1
-----	---

Max	20001
-----	-------

Key Path	Meas Setup
----------	-------------------

7.7.2 Avg Mode

Enables you to set the averaging mode.

When set to Exponential (Exp) the measurement averaging continues using the specified number of averages to compute each averaged value. The average will be displayed at the end of each sweep.

When set to Repeat, the measurement resets the average counter each time the specified number of averages is reached.

Mode	BASIC, PN, WCDMA, C2K, 1XEVD0, GSM, WIMAXOFDMA
Remote Command	[:SENSe] :WAVeform:AVERAge:TCONtrol EXPONential REPEAT [:SENSe] :WAVeform:AVERAge:TCONtrol?
Example	WAV:AVER:TCON REP WAV:AVER:TCON?
Remote Command Notes	You must be in the mode that includes Waveform measurements to use this command. Use INSTRUMENT:SElect to set the mode.
Preset	EXPONential
State Saved	Saved in instrument state.
Range	Exp Repeat
Key Path	Meas Setup

7.7.3 Avg Type

Selects the type of averaging.

Mode	BASIC, PN, WCDMA, C2K, 1XEVD0, GSM, WIMAXOFDMA
Remote Command	[:SENSe] :WAVeform:AVERAge:TYPE LOG MAXimum MINimum RMS SCALar [:SENSe] :WAVeform:AVERAge:TYPE?
Example	WAV:AVER:TYPE MAX WAV:AVER:TYPE?
Restriction and Notes	The SCPI selection of MAX and MIN are kept because of BWCC reason, but they are removed from the front panel access because they are not Average.
Remote Command Notes	You must be in the mode that includes Waveform measurements to use this command. Use INSTRUMENT:SElect to set the mode.
Preset	RMS
State Saved	Saved in instrument state.
Range	Pwr Avg(RMS) Log-Pwr Avg(Video) Voltage Avg
Key Path	Meas Setup

7.7.4 Meas Time

Sets how long the measurement is performed. X Scale only changes the representation of the

display.

Mode	BASIC, PN, WCDMA, C2K, 1XEVD0, GSM, WIMAXOFDMA
Remote Command	[:SENSe] :WAVeform:SWEep:TIME <time> [:SENSe] :WAVeform:SWEep:TIME?
Example	WAV:SWE:TIME 50 ms WAV:SWE:TIME?
Restriction and Notes	Specifies and returns how long the measurement is performed. It is the time record length of the measurement waveform. The Max time may be reduced when the sample frequency is high due to the memory limitation.
Remote Command Notes	You must be in the mode that includes Waveform measurements to use this command. Use INSTRument:SElect to set the mode.
Preset	2.000000 ms
State Saved	Saved in instrument state.
Range	1.000 (s to 100.00 s)
Key Path	Meas Setup

7.7.5 Meas Preset

Restores all the measurement parameters to their default values.

Mode	BASIC, PN, WCDMA, C2K, 1XEVD0, GSM, WIMAXOFDMA
Remote Command	:CONFIgure:WAVeform
Example	CONF:WAV
Restriction and Notes	Restore default values of all parameters.
Remote Command Notes	You must be in the mode that includes Waveform measurements to use this command. Use INSTRument:SElect to set the mode.
Key Path	Meas Setup

7.7.6 Advanced

Accesses a menu of “advanced” functions that are used for specific applications.

Key Path:	Meas Setup
-----------	-------------------

7.7.6.1 ADC Dither

Accesses the ADC Dither control menu.

Key Path: **Meas Setup, Advanced**

7.7.6.1.1 ADC Dither Auto

Sets ADC dithering to automatically select whether dithering is needed.

Mode	BASIC, PN, WCDMA, C2K, 1XEVD0, GSM, WIMAXOFDMA
Remote Command	[:SENSe] :WAVeform:ADC:DITHer:AUTO [:STATe] OFF ON 0 1 [:SENSe] :WAVeform:ADC:DITHer:AUTO [:STATe] ?
Example	WAV:ADC:DITH:AUTO ON WAV:ADC:DITH:AUTO?
Restriction and Notes	The dither function improves linearity for low level signals, at the expense of a higher noise floor. Behavior of this function is the same as the Spectrum Analyzer. Refer to the SA PD for detail. This table is for SCPI definition purpose only.
Remote Command Notes	You must be in the mode that includes Waveform measurements to use this command. Use INSTRument:SElect to set the mode.
Preset	OFF
State Saved	Saved in instrument state.
Range	On Off
Key Path	Meas Setup, Advanced, ADC Dither

7.7.6.1.2 ADC Dither

Toggles the dither function On and Off. The dither function improves linearity for low level signals, at the expense of a higher noise floor.

Mode	BASIC, PN, WCDMA, C2K, 1XEVD0, GSM, WIMAXOFDMA
Remote Command	[:SENSe] :WAVeform:ADC:DITHer [:STATe] OFF ON 0 1 [:SENSe] :WAVeform:ADC:DITHer [:STATe] ?
Example	WAV:ADC:DITH ON WAV:ADC:DITH?
Restriction and Notes	The dither function improves linearity for low level signals, at the expense of a higher noise floor.
Remote Command Notes	You must be in the mode that includes Waveform measurements to use this command. Use INSTRument:SElect to set the mode.
Preset	OFF

State Saved	Saved in instrument state.
Range	Auto Man
Key Path	Meas Setup, Advanced, ADC Dither

7.7.6.2 IF Gain

Sets the IF Gain function to Auto, Low Gain or High Gain. These settings affect sensitivity and IF overloads.

Key Path	Meas Setup Advanced
----------	----------------------------

7.7.6.2.1 IF Gain Auto

Activates the auto rules for IF Gain. When Auto is active, the IF Gain is set to High Gain under and of the following conditions:

- The input attenuator is set to 0 dB
- the preamp is turned On and the frequency range is under 3.6 GHz

For other settings, Auto sets the IF Gain to Low Gain.

Mode	BASIC, PN, WCDMA, C2K, 1XEVD0, GSM, WIMAXOFDMA
------	--

Remote Command	[:SENSe] :WAVeform:IF:GAIN:AUTO [:STATe] ON OFF 1 0 [:SENSe] :WAVeform:IF:GAIN:AUTO [:STATe] ?
-----------------------	---

Example	WAV:IF:GAIN:AUTO ON WAV:IF:GAIN:AUTO?
---------	--

Restriction and Notes	This table is for SCPI definition purpose only.
-----------------------	---

Remote Command Notes	You must be in the mode that includes Waveform measurements to use this command. Use INSTRument:SElect to set the mode.
----------------------	---

Preset	ON
--------	----

State Saved	Saved in instrument state.
-------------	----------------------------

Range	On Off
-------	----------

Key Path	Meas Setup, Advanced, IF Gain
----------	--------------------------------------

7.7.6.2.2 IF Gain State

Selects the range of IF gain.

Mode	BASIC, PN, WCDMA, C2K, 1XEVD0, GSM, WIMAXOFDMA
------	--

Remote Command	[:SENSe] :WAVeform:IF:GAIN [:STATe] AUTOrange LOW HIGH [:SENSe] :WAVeform:IF:GAIN [:STATe] ?
-----------------------	---

Example	WAV:IF:GAIN HIGH WAV:IF:GAIN?
Restriction and Notes	This table is for SCPI definition purpose only.
Remote Command Notes	You must be in the mode that includes Waveform measurements to use this command. Use INSTRument:SElect to set the mode.
Preset	AUTO
State Saved	Saved in instrument state.
Range	Autorange (Slower Follows Signals) Low (Best for Large Signals) High (Best Noise Level)
Key Path	Meas Setup, Advanced, IF Gain

7.8 Trigger

Accesses a menu of functions that enable you to select and control the trigger source for the current measurement

.See Trigger in the "Measurement Functions" section for more information.

Key Path **Front-panel key**

7.8.1 Trigger

Selects a trigger source. Trigger settings are mode global. Refer to Mode functionality section for trigger settings. Refer to "Trigger" in the "Measurement Functions" section.

Mode	WCDMA, C2K, WIMAXOFDMA
Remote Command	TRIGger:WAVeform:SOURce EXTErnal [1] EXTErnal2 FRAME IF VIDEo IMMEDIATE LINE RF Burst TRIGger:WAVeform:SOURce?
Example	TRIG:WAV:SOUR LINE TRIG:WAV:SOUR?
Restriction and Notes	IF in SCPI selection is the same as VIDEo. IF is kept because of BWCC
Remote Command Notes	The selections of VIDEo and IF point the same trigger source (video trigger). You must be in the mode that Waveform measurement is included to use this command. Use INSTRument:SElect to set the mode.
Preset	IMMEDIATE
State Saved	Saved in instrument state.
Range	Free Run Video Line External 1 External 2 RF Burst (Wideband) Periodic Timer
Key Path	Trigger

7.9 Sweep/Control

Accesses the Sweep menu that allows you to pause and restart the measurement.

Key Path **Front-panel key**

7.9.1 Pause and Resume

Pauses a measurement after the current data acquisition is complete. When Paused, the label on the key changes to Resume. Pressing Resume un-pauses the measurement.

See Sweep/Control in the "Analyzer Setup Functions" section for more information.

Key Path **Sweep/Control, Pause/Resume**

7.10 Marker

Accesses a menu that enables you to select, set up and control the markers for the current measurement.

See the "Marker Functions" section for more information

Key Path Front-panel key

7.10.1 Marker Type

Sets the marker control mode to **Normal**, **Delta**, **Fixed** or **Off**. All interactions and dependencies detailed under the key description are enforced when the remote command is sent. If the selected marker is Off, pressing Marker sets it to Normal and places it at the center of the screen on the trace determined by the **Marker Trace** rules. At the same time, **Marker X Axis Value** appears on the Active Function area.

The default active function is the active function for the currently selected marker control mode. Note that if the current control mode is Off, there is no active function and the active function is turned off.

Mode	BASIC, PN, WCDMA, C2K, 1XEVD0, GSM, WIMAXOFDMA
Remote Command	:CALCulate:WAVEform:MARKer [1] 2 3 4 5 6 7 8 9 10 11 12:MODE POSition DELTA OFF :CALCulate:WAVEform:MARKer [1] 2 3 4 5 6 7 8 9 10 11 12:MODE?
Example	CALC:WAV:MARK:MODE OFF CALC:WAV:MARK:MODE?
Restriction and Notes	If the selected marker is Off, pressing Marker sets it to Normal and places it at the center of the screen on the trace determined by the Marker Trace rules. At the same time, Marker X Axis Value appears on the Active Function area. Default Active Function: the active function for the selected marker's current control mode. Note that if the current control mode is Off, there is no active function and the active function is turned off. Active Function Display: the marker X axis value entered in the active function area will display the marker value to its full entered precision.
Remote Command Notes	NORMAL is changed to POSition in the new SA. You must be in the mode that Waveform measurement is included to use this command. Use INSTRUMENT:SELEct to set the mode.
Preset	OFF

State Saved	Saved in instrument state.
Range	Normal Delta Off
Key Path	Marker

7.10.2 Marker X Axis Value

Sets the marker X Axis value in the current marker X Axis Scale unit. It has no effect if the control mode is **Off**, but is the SCPI equivalent of entering an X value if the control mode is **Normal** or **Delta**.

Mode	BASIC, PN, WCDMA, C2K, 1XEVD0, GSM, WIMAXOFDMA
Remote Command	:CALCulate:WAVEform:MARKer [1] 2 3 4 5 6 7 8 9 10 11 12 :X <time> :CALCulate:WAVEform:MARKer [1] 2 3 4 5 6 7 8 9 10 11 12 :X?
Example	CALC:WAV:MARK7:X 50 ms CALC:WAV:MARK3:X?
Restriction and Notes	If no suffix is sent it will use the fundamental units for the current marker X Axis Scale. If a suffix is sent that does not match the current marker X Axis Scale unit, an error “Invalid suffix” will be generated. If the specified marker is Fixed and a Marker Function is on, error –221 “Settings conflict; cannot adjust Fixed marker while Marker Function is on” is generated. The query returns the marker’s absolute X Axis value if the control mode is Normal , or the offset from the marker’s reference marker if the control mode is Delta . The query is returned in the fundamental units for the current marker X Axis scale: Hz for Frequency and Inverse Time , seconds for Period and Time . If the marker is Off the response is not a number. .
Remote Command Notes	You must be in the mode that includes Waveform measurements to use this command. Use INSTRument:SElect to set the mode.
Preset	After a preset, all markers are turned OFF, so Marker X Axis Value query will return a not a number (NAN).
State Saved	No
Min	–9.9E+37
Max	9.9E+37

7.10.3 Marker X Axis Position

Sets the marker X position in trace points. It has no effect if the control mode is **Off**, but is the SCPI

equivalent of entering a value if the control mode is **Normal** or **Delta**. The entered value is immediately translated into the current X Axis Scale units for setting the value of the marker.

Mode	BASIC, PN, WCDMA, C2K, 1XEVD0, GSM, WIMAXOFDMA
Remote Command	:CALCulate:WAVEform:MARKer [1] 2 3 4 5 6 7 8 9 10 11 12 : X : POSition <real> :CALCulate:WAVEform:MARKer [1] 2 3 4 5 6 7 8 9 10 11 12 : X : POSition?
Example	CALC:WAV:MARK3:X:POS 500 CALC:WAV:MARK10:X:POS?
Restriction and Notes	The query returns the marker's absolute X Axis value in trace points if the control mode is Normal or the offset from the marker's reference marker in trace points if the control mode is Delta . The value is returned as a real number, not an integer, corresponding to the translation from X Axis Scale units to trace points .
Remote Command Notes	You must be in the mode that includes Waveform measurements to use this command. Use INSTRument:SElect to set the mode.
Preset	After a preset, all markers are turned OFF, so Marker X Axis Value query will return a not a number (NAN).
State Saved	No
Min	-9.9E+37
Max	9.9E+37

7.10.4 Marker Y Axis Value

Queries the marker Y Axis value in the current marker Y Axis unit.

Mode	BASIC, PN, WCDMA, C2K, 1XEVD0, GSM, WIMAXOFDMA
Remote Command	:CALCulate:WAVEform:MARKer [1] 2 3 4 5 6 7 8 9 10 11 12 : Y ?
Example	CALC:WAVEform:MARK11:Y?

Restriction and Notes	When the marker is on IQ waveform, returns I and Q values. Case #1 - Trace RF: returns a single double value. >:CALC:WAV:MARK1:Y? -2.402406506109E+001 Case #2 - Trace IQ: returns an double array of two values, the first is X, and the second is Y. >:CALC:WAV:MARK1:Y? -3.0069444493834E-003,+9.9870666467354E-004
Remote Command Notes	You must be in the mode that Waveform measurement is included to use this command. Use INSTRUMENT:SELEct to set the mode.
Preset	Result dependant on markers setup and signal source
State Saved	No

7.10.5 Relative To

Selects the marker the selected marker will be relative to (its reference marker).

Mode	BASIC, PN, WCDMA, C2K, 1XEVD0, GSM, WIMAXOFDMA
Remote Command	:CALCulate:WAVEform:MARKer [1] 2 3 4 5 6 7 8 9 10 11 12:REFerence <integer> :CALCulate:WAVEform:MARKer [1] 2 3 4 5 6 7 8 9 10 11 12:REFerence?
Example	CALC:WAV:MARK6:REF 8 CALC:WAVEform:MARK:REF?
Restriction and Notes	A marker cannot be relative to itself so that choice is grayed out, and if sent from SCPI generates error -221: "Settings conflict; marker cannot be relative to itself."
Remote Command Notes	When queried a single value will be returned (the specified marker numbers relative marker). A marker cannot be relative to itself so that choice is grayed out, and if sent from SCPI generates error -221: "Settings conflict; marker cannot be relative to itself." You must be in the mode that Waveform measurement is included to use this command. Use INSTRUMENT:SELEct to set the mode.
Preset	2 3 4 5 6 7 8 9 10 11 12 1
State Saved	Saved in instrument state.
Min	1

Max	12
Key Path	Marker, Properties

7.10.6 Marker Trace

Assigns the specified marker to the designated trace.

Mode	BASIC, PN, WCDMA, C2K, 1XEVD0, GSM, WIMAXOFDMA
Remote Command	:CALCulate:WAVEform:MARKer [1] 2 3 4 5 6 7 8 9 10 11 12:TRACe RFENvelope IQ :CALCulate:WAVEform:MARKer [1] 2 3 4 5 6 7 8 9 10 11 12:TRACe?
Example	CALC:WAV:MARK6:TRAC RFEN CALC:WAVEform:MARK:TRACE?
Restriction and Notes	Assigns the specified marker to the designated trace.
Remote Command Notes	You must be in the mode that includes Waveform measurements to use this command. Use INSTRument:SElect to set the mode.
Preset	RFEN
State Saved	Saved in instrument state.
Range	RF Envelope IQ Waveform
Key Path	Marker

7.10.7 Couple Marker

Toggles the state of the markers to be coupled On or Off. When this function is true (On), moving any marker causes an equal X axis movement of every other marker which is not **Off**. “Equal X axis movement” refers to the difference between each marker’s X Axis value (in the fundamental x-axis units of the trace that marker is on) and the X Axis value of the marker being moved (in the same fundamental x-axis units) are preserved.

Mode	BASIC, PN, WCDMA, C2K, 1XEVD0, GSM, WIMAXOFDMA
Remote Command	:CALCulate:WAVEform:MARKer:COUple [:STATe] ON OFF 1 0 :CALCulate:WAVEform:MARKer:COUple [:STATe] ?
Example	CALC:WAV:MARK:COUP ON CALC:WAVEform:MARK:COUP ON
Remote Command Notes	You must be in the mode that includes Waveform measurements to use this command. Use INSTRument:SElect to set the mode.

Preset	OFF
State Saved	Saved in instrument state.
Range	On Off
Key Path	Marker

7.10.8 All Markers Off

Turns off all markers.

Mode	BASIC, PN, WCDMA, C2K, 1XEVD0, GSM, WIMAXOFDMA
Remote Command	:CALCulate:WAVeform:MARKer:AOff
Example	CALC:WAV:MARK:AOff
Remote Command Notes	You must be in the mode that includes Waveform measurements to use this command. Use INSTRument:SElect to set the mode.
Key Path	Marker

7.11 Peak Search

Places the selected marker on the trace point with the maximum y-axis value for that marker's trace and accesses a menu that enables you to select to do a minimum peak search.

Mode	BASIC, PN, WCDMA, C2K, 1XEVD0, GSM, WIMAXOFDMA
Remote Command	:CALCulate:WAVEform:MARKer [1] 2 3 4 5 6 7 8 9 10 11 12 :MAXimum
Example	CALC:WAV:MARK2:MAX
Remote Command Notes	You must be in the mode that includes Waveform measurements to use this command. Use INSTRument:SElect to set the mode.
Key Path	Front-panel key

7.11.1 Min Search

Moves the selected marker to the minimum y-axis value on the current trace.

Mode	BASIC, PN, WCDMA, C2K, 1XEVD0, GSM, WIMAXOFDMA
Remote Command	:CALCulate:WAVEform:MARKer [1] 2 3 4 5 6 7 8 9 10 11 12 :MINimum
Example	CALC:WAV:MARK:MIN
Remote Command Notes	You must be in the mode that includes Waveform measurements to use this command. Use INSTRument:SElect to set the mode.
Key Path	Peak Search

7.12 Marker To

There is no 'Marker To' functionality supported in Waveform measurements. The front-panel key will display a blank menu key when pressed..

Key Path

Front-panel key

7.13 Marker Function

Accesses a menu of marker functions that perform post-processing operations on markers based on the measurement specifications. Marker functions are distinct from Measurement functions, which automatically perform complex sequences of setup, data acquisition, and display operations in order to measure specified signal characteristics. Marker Functions are specified for each individual marker and may be turned on individually for each marker.

The Marker Fctn menu controls which marker functions are turned on and allows you to adjust the setup parameters for each function. These parameters include the following, but only one parameter can be assigned to a given marker:

- **Marker Noise**
- **Band/Interval Power**
- **Band/Interval Density**
- **Marker Function Off**

Key Path	Front-panel key
----------	-----------------

7.13.1 Marker Function Type

Sets the marker control function type to, Marker Noise, Band/Interval Power, Band Interval Density, or Marker Function Off

Mode	BASIC, PN, WCDMA, C2K, 1XEVD0, GSM, WIMAXOFDMA
Remote Command	:CALCulate:WAVeform:MARKer [1] 2 3 4 5 6 7 8 9 10 11 12 :FUNctioN BPOwer BDENsity OFF :CALCulate:WAVeform:MARKer [1] 2 3 4 5 6 7 8 9 10 11 12 :FUNctioN?
Example	CALC:WAVeform:MARK:FUNC BPOW CALC:WAV:MARK10:FUNC?
Remote Command Notes	You must be in the mode that Waveform measurement is included to use this command. Use INSTRument:SElect to set the mode.
Preset	OFF
State Saved	Saved in instrument state.
Range	Band/Interval Power Band Interval Density Marker Function Off
Key Path	Marker Fctn

7.13.2 Band Adjust

Accesses a menu that enables you to set the frequency span width and the left and right edge, or time values, for the band or interval of the selected marker.

Key Path **Marker Fctn**

7.13.2.1 Band/Interval Span for Time Domain

Sets the width of the frequency span for the selected marker.

Mode BASIC, PN, WCDMA, C2K, 1XEVD0, GSM, WIMAXOFDMA

Remote Command :CALCulate:WAVEform:MARKer [1] | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 |
12:FUNction:BAND:SPAN <time>

:CALCulate:WAVEform:MARKer [1] | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 |
12:FUNction:BAND:SPAN?

Example CALC:WAV:MARK12:FUNC:BAND:SPAN 20 ms
CALC:WAV:MARK3:FUNC:BAND:SPAN?

Dependencies/Couplings Changing the Band/Interval Span necessarily changes the Band/Interval Left and Band/Interval Right values

Remote Command Notes You must be in the mode that includes Waveform measurements to use this command. Use INSTRument:SElect to set the mode.

Preset 10% of Meas Time

State Saved Saved in instrument state.

Min 0

Max 100s

Key Path **Marker Fctn**

7.13.2.2 Band/Interval Left for Time Domain

Sets the left edge frequency or time value for the band of the selected marker.

Mode BASIC, PN, WCDMA, C2K, 1XEVD0, GSM, WIMAXOFDMA

Remote Command :CALCulate:WAVEform:MARKer [1] | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 |
12:FUNction:BAND:LEFT <time>

:CALCulate:WAVEform:MARKer [1] | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 |
12:FUNction:BAND:LEFT?

Example CALC:WAVEform:MARK12:FUNC:BAND:LEFT 1 s
CALC:WAV:MARK12:FUNC:BAND:LEFT?

Dependencies/Couplings	Changing the Band/Interval Left necessarily changes the Band/Interval Span and Band/Interval Right values
Remote Command Notes	You must be in the mode that includes Waveform measurements to use this command. Use INSTRUMENT:SELECT to set the mode.
Preset	5% of Meas Time
State Saved	Saved in instrument state.
Min	0
Max	100s
Key Path	Marker Fctn

7.13.2.3 Band/Interval Right for Time Domain

Sets the right edge frequency or time value for the band of the selected marker.

Mode	BASIC, PN, WCDMA, C2K, 1XEVD0, GSM, WIMAXOFDMA
Remote Command	:CALCulate:WAVEform:MARKer [1] 2 3 4 5 6 7 8 9 10 11 12 :FUNction:BAND:RIGHT <time> :CALCulate:WAVEform:MARKer [1] 2 3 4 5 6 7 8 9 10 11 12 :FUNction:BAND:RIGHT?
Example	CALC:WAV:MARK12:FUNC:BAND:LEFT 1 s CALC:WAV:MARK12:FUNC:BAND:RIGH?
Dependencies/Couplings	Changing the Band/Interval Left necessarily changes the Band/Interval Span and Band/Interval Right values
Remote Command Notes	You must be in the mode that includes Waveform measurements to use this command. Use INSTRUMENT:SELECT to set the mode.
Preset	5% of Meas Time
State Saved	Saved in instrument state.
Min	0
Max	100s
Key Path	Marker Fctn