

Ericsson TACS Cell Site Test Software  
**HP 11807B Option 052 Software**  
**User's Guide**  
**for the HP 8921A**

Software Revision B.00.01 and above

**HP Part No. 11807-90108**  
**Printed in U. S. A.**  
**May 1996**

**Rev D**

Copyright © Hewlett-Packard Company 1995

**RESTRICTED  
RIGHTS LEGEND**

Use, duplication or disclosure by the U.S. Government is subject to restrictions as set forth in subparagraph (c) (ii) of the Rights in Technical Data and Computer Software clause in DFARS 252.227-7013.

Hewlett-Packard Company  
3000 Hanover Street  
Palo Alto, CA 94304 U.S.A.

Rights for non-DOD U.S. Government Departments and Agencies are as set forth in FAR 52.227-19 (c) (1, 2).

---

## Contents

### **1 Getting Started with FW Revision Above A.14.00**

Firmware Enhancements 20

Test Set or System is Defined As: 20

What You'll Test and What You'll Need 21

Test Set Overview 23

Load the Software 24

Initialize a Memory Card (for local control file storage) 26

Initialize a Memory Card (Cont.) 28

Initialize a Memory Card (Cont.) 29

Transfer the Local Control Program 30

Transfer the Local Control Program (Cont.) 31

Transfer the Local Control Program (Cont.) 32

Transfer the Local Control Program (Cont.) 33

Verify Local Control Transfer (Transmitter Power Test) 34

Verify Local Control Transfer (Cont.) 35

Verify Local Control Transfer (Cont.) 36

Verify Local Control Transfer (Cont.) 37

### **2 Getting Started with FW Revision Below A.14.00**

Firmware Enhancements 40

Test Set or System is Defined As: 40

What You'll Test and What You'll Need 41

Test Set Overview 43

Load the Software 44

Initialize a Memory Card (for local control file storage) 46

Initialize a Memory Card (Continued) 48

Initialize a Memory Card (Continued) 49

Transfer the Local Control Program 50

Transfer the Local Control Program (Continued) 51

Transfer the Local Control Program (Continued) 52

Transfer the Local Control Program (Continued) 53

Verify Local Control Transfer (Transmitter Power Test) 54

Verify Local Control Transfer (Continued) 55

Verify Local Control Transfer (Continued) 56

Verify Local Control Transfer (Continued) 57

---

## Contents

### **3 Product Description**

[HP 11807B Option 052 Software](#) 60

Items Included in the HP 11807B Option 052 Software 60

Software Features 61

Equipment Needed to Begin Testing 61

[Finding the Information You Need](#) 62

[Additional Services Available](#) 63

---

## Contents

### **4 Making Connections**

Connection Cables and Adapters Needed 68

Ericsson Model 883 Connections 70

Ericsson Microcell Connections 71

Cable and Antenna Measurement Connections 72

Determining Calibration Parameters 74

### **5 Using the Software with FW Above Rev. A.14.00**

Firmware Enhancements 76

Test Set or System is Defined As: 77

Introduction 77

Testing Overview 78

Before Running Tests 80

Running Tests 81

Selecting a Test Procedure 82

Customizing Testing 84

Beginning Software Customization 85

Changing the Order of Tests 86

How to Change the Order of Tests 87

Changing Pass/Fail Limits 89

How to Change Pass/Fail Limits 89

Changing the Test Parameters 92

How to Change the Test Environment and Conditions 92

Saving a Test Procedure 94

How to Save a Test Procedure 95

Changing Test Execution Conditions 98

How to Change Test Execution Conditions 99

Printing and Saving Test Results 99

### **6 Using the Software/HP 8921A FW Rev. Below A.14.00**

Firmware Enhancements 102

Test Set or System is Defined As: 103

Introduction 104

Running Tests Overview 105

Before Running Tests 106

Running Tests 107

Selecting a Test Procedure 108

Customizing the Software 110

Beginning Software Customization 112

Changing a Sequence of Tests (Edit Sequence) 113

How to Change a Sequence of Tests 114

Changing Pass/Fail Limits (Edit Specifications) 116

How to Change Pass/Fail Limits 116

Changing the Test Environment and Conditions (Edit Parameters) 119

How to Change the Test Environment and Conditions 119

Saving a Test Procedure Using the Procedure Manager 121

How to Save a Test Procedure 122

Changing Test Execution Conditions 125

How to Change Test Execution Conditions 126

Printing and Saving Test Results 126



### 7 Test, Parameter, Pass/Fail Limit (Specification) Descriptions

#### Test Descriptions 128

|  |     |
|--|-----|
| TEST_01 - GN Laptop Emulator                   | 129 |
| TEST_02 - Memory Card Initialisation           | 130 |
| TEST_03 - Local Control File Transfer          | 131 |
| TEST_04 - GN Swept Return Loss                 | 132 |
| Estimating Antenna Return Loss                 | 134 |
| TEST_05 - GN Discrete Channel Return Loss      | 134 |
| TEST_06 - GN Cable Fault Versus Distance       | 135 |
| Cable Fault Performance                        | 135 |
| Selecting Cable Type                           | 136 |
| Entering Cable Length                          | 136 |
| Interpreting Cable Fault Location Results      | 137 |
| TEST_07 - GN Measure Cable Loss                | 137 |
| TEST_08 - GN Data Collection File Transfer     | 138 |
| TEST_09 - TX Frequency Adjustment              | 139 |
| TEST_10 - TX Power Adjustment                  | 139 |
| TEST_11 - TX Audio Level Adjustment            | 140 |
| TEST_12 - TX Voice Channel Deviation           | 140 |
| TEST_13 - TX Voice and SAT Deviation           | 141 |
| TEST_14 - TX Maximum Voice Deviation           | 141 |
| TEST_15 - TX Data Deviation                    | 142 |
| TEST_16 - TX SAT Frequency Error and Deviation | 142 |
| TEST_17 - TX Calculate ERP                     | 142 |
| TEST_18 - RX Line Level Adjustment             | 143 |
| TEST_19 - RX Sensitivity                       | 144 |
| TEST_20 - RX Diversity Sensitivity             | 145 |
| TEST_21 - RX Desense                           | 146 |
| TEST_22 - RX Squelch Test                      | 146 |
| TEST_23 - RX RF Level Calibration (AIO)        | 147 |
| TEST_24 - RX Loop Gain Adjustment              | 147 |
| TEST_25 - RX SAT Detector                      | 148 |

#### Parameter Descriptions 149

|   |     |
|---|-----|
| GN model number [1=883 2=MCBS]            | 149 |
| GN CU serial control [0=PC 1=HP8921]      | 149 |
| GN auto exit adj [0=no, xx=times in spec] | 150 |

---

## Contents

|   |     |
|---|-----|
| GN RF level for return loss tests (dBm)       | 150 |
| RT default channel                            | 150 |
| RT audio excitation frequency (kHz)           | 150 |
| RT units for audio measurements [0=mV, 1=dBm] | 150 |
| TX units for RF pwr measure [0=W 1=dBm]       | 150 |
| TX path loss (dB)                             | 151 |
| TX audio adjustment excitation level (mV/dBm) | 151 |
| TX max voice audio level (mV/dBm)             | 151 |
| RX RF level for audio adjust (dBm)            | 152 |
| RX path loss (dB)                             | 152 |
| RX sensitivity SINAD level (dB)               | 152 |
| RX squelch threshold [0=relative 1=abs]       | 152 |
| RX RF level for AIO/RSSI test (dBm)           | 152 |
| RX system deviation (kHz)                     | 153 |
| RX deviation for RF level test (AIO) (kHz)    | 153 |
| RX deviation for sensitivity tests (kHz)      | 153 |
| RX RF level for SAT detector test (dBm)       | 153 |
| ZZ test mode [0=normal 1=demo]                | 153 |
| RX sens floating audio input [0=no 1=yes]     | 153 |
| GN check MCBS on only RXA [0=no 1=yes]        | 154 |
| GN no prompt at end of test [0=no 1=yes]      | 154 |

### Pass/Fail Limit (Specification) Descriptions 155

|   |     |
|---|-----|
| GN return loss (dB)                     | 155 |
| TX frequency error (Hz)                 | 155 |
| TX output power (W/dBm)                 | 156 |
| TX audio level (mV/dBm)                 | 156 |
| TX voice channel deviation (kHz)        | 156 |
| TX voice and SAT deviation (kHz)        | 157 |
| TX maximum voice deviation (kHz)        | 157 |
| TX constant symbol data frequency (kHz) | 157 |
| TX constant symbol data deviation (kHz) | 157 |
| TX SAT deviation (kHz)                  | 157 |
| TX SAT frequency error (Hz)             | 158 |
| RX line level (mV/dBm)                  | 158 |
| RX sensitivity (dBm)                    | 158 |
| RX diversity sensitivity (dB/dBm)       | 158 |
| RX desense (dB)                         | 159 |

---

## Contents

|  |     |
|--|-----|
| RX squelch threshold (dB/dBm)            | 159 |
| RX squelch hysteresis (dB)               | 159 |
| RX RF level from AIO                     | 159 |
| RX loop gain level (mV/dBm)              | 160 |
| RX SAT detector level                    | 160 |
| RX SAT detector SNR                      | 160 |
| RXB microcell line level difference (dB) | 160 |

### **8 Reference (Alphabetical)**

Conventions Used 162

Copying Files 163

Data Collection (Saving and Retrieving Test Results) 164

Collection to a Memory Card or Disk 164

Retrieving Data from a Memory Card 166

Collection to a PC 168

Configuration for Terminal or PC Operation 171

Disks 173

Initializing a Disk 173

Retrieving Data from a Disk 174

Exiting a Program 176

HP-IB Control Annunciators 177

Logging 178

178

Memory Cards 179

SRAM Memory Cards 180

Memory Card Storage Space 181

Initializing a Memory Card 181

Retrieving Data from a Memory Card 183

Parameters 186

Pass/Fail Limits (Specifications) 187

Pausing or Stopping a TEST 188

Printing 189

Supported Printers 189

Printer Connection 190

---

## Contents

Configuring the Test Set for Printing 192  
To Setup Printer 192

### Procedures 195

Saving a Procedure 195  
Loading a Procedure 197  
Deleting a Procedure 197  
Securing a Procedure 198

### RAM 200

Initializing RAM Disks 201

### Saving Tests Results 202

### Serial Port 203

Operating Considerations 203

### Test Execution Conditions 206

Output Results To: (Output Destination) 206  
Output Results For: (Output Results) 206  
Output Heading 206  
If Unit-Under-Test Fails (If UUT Fails) 207  
Test Procedure Run Mode (Run Mode) 207  
Autostart Test Procedure on Power-Up 207

### USER Keys 208

---

## Contents

### **9 Problem Solving**

Data-Collection Function Does Not Work 213

Memory Space Problems 215

Printing Problems 216

Test Results are Unexpected 217

Test Set Doesn't Power Up 218

Error Messages 219

Error Message Reference 220

---

## Contents

### A Cable Wiring Diagrams

---

## Contents

Glossary 227



---

## Contents

**Index 231**

---

## Contents

---

**Getting Started with FW Revision Above  
A.14.00**

## Firmware Enhancements

**NOTE:**

The firmware revision A.14.00 in the HP 8921A,D had several enhancements. This chapter applies to users with:

- **HP 8921A test sets with firmware revision above A.14.00**

The Test Set's firmware revision is displayed on the top right corner of the configuration screen.

- Press SHIFT CONFIG to display the configuration screen and read the firmware revision.

If you have an HP 8921A Test Set with firmware revision below A.14.00, refer to **"Getting Started with FW Revision Below A.14.00" on page 39**. Contact Hewlett-Packard at 1-800-922-8920 for details on upgrading your firmware if desired.

---

### Test Set or System is Defined As:

- HP 8921A, Option 500, Dual-Mode Cellular Test System
- HP 8921D, Dual-Mode Cell Site Test System

---

## What You'll Test and What You'll Need

Getting Started will quickly acquaint you with the operation of the Test Set and the HP 11807B Option 052 Software. You will do the following:

**1. Run the local control file transfer test.**

This will transfer the local control (FX) file from your laptop to the Test Set. Once this transfer has been done the Test Set will automatically download the local control file to the base station under test when other tests are run on a model 883 or Microcell transceiver. You will be initializing a memory card in the Test Set for storage of the local control file.


**2. Run the transmitter power adjustment test on a model 883 transceiver.** This will verify that the local control file was transferred to the Test Set and downloaded successfully to the base station.

You will need the following in order to complete the testing in Getting Started:


- HP 11807B Option 052 Software
- One of the following:
  - HP 8921A, Option 500, Dual-Mode Cellular Test System
  - HP 8921D, Dual-Mode Cell Site Test System
- An Ericsson Model 883 Transceiver Module
- Type N (m) to Type N (m) 6 ft. RJ214 cable for transmitter output to Test Set RF IN/OUT connection
- RJ-11(m) to DB-9 (f) 4 wire cable for laptop to Test Set connection, supplied with HP 11807B Option 052 Software (part no. 08921-61038)
- Quarter Plug to RJ-11 (m) cable for local control connection, supplied with HP 11807B Option 052 Software (part no. 08921-61032)
- A laptop (PC compatible) with the local control program applicable to the Model 883

At the time of this writing, the HP 11807B Option 052 software is known to be compatible with Ericsson local control revision R14.

## Test Set Overview



## Load the Software





**For Visual Reference Only**

*Field entries on your screen may be different.*

```

          TESTS (Main Menu)
Please select a procedure to load.

LOAD TEST PROCEDURE:
Select Procedure Location:
Card
Select Procedure Filename:  Library  Program
Description:

CUSTOMIZE TEST PROCEDURE  SETUP TEST SET











Freq Channel Information  Exec Test Conditions
Parm Test Parameters      Cnfg External Devices
Seqn Order of Tests      Print Printer Setup
Spec Pass/Fail Limits    IBASIC IBASIC Cntrl
Proc Save/Delete Procedure

1 Run Test
2 Continue
4 Help

RF GEN
RF ANL
AF ANL
SCOPE
SPEC ANL
ENCODER
DECODER
RADIO INT
More
```


POWER2A

## Initialize a Memory Card (for local control file storage)

|  |  |
|--|--|
| <p><b>1</b> Insert Opt 052 program card into memory slot on test set front panel.</p>   | <p><b>2</b> Press <b>TESTS</b> to display <b>TESTS (Main Menu)</b> screen.</p>   |
| <p><b>3</b> Position cursor at <b>Select Procedure Location</b> and select it.</p> <p><b>Position</b></p>  <p><b>Select</b></p>  | <p><b>4</b> Position cursor at <b>Card</b> and select it.</p> <p><b>Position</b></p>  <p><b>Select</b></p>  <p>Choices :</p> <ul style="list-style-type: none"> <li><input checked="" type="checkbox"/> Card</li> <li><input type="checkbox"/> ROM</li> <li><input type="checkbox"/> RAM</li> <li><input type="checkbox"/> Disk</li> </ul>  |
| <p><b>5</b> Position cursor at <b>Select Procedure Filename</b> and select it.</p> <p><b>Position</b></p>  <p><b>Select</b></p>  | <p><b>6</b> Position cursor at <b>CARD_INIT</b> and select it.</p> <p><b>Position</b></p>  <p><b>Select</b></p>  <p>Choices :</p> <ul style="list-style-type: none"> <li><input checked="" type="checkbox"/> ERICS_883</li> <li><input type="checkbox"/> ERICS_MC</li> <li><input type="checkbox"/> LAPTOP_EM</li> <li><input type="checkbox"/> CARD_INIT</li> <li><input type="checkbox"/> FX_XFER</li> <li><input type="checkbox"/> GET_START</li> <li><input type="checkbox"/> D_C_XFER</li> </ul> |

INT1a

Next: Turn page to continue



Init2a



## Initialize a Memory Card (Cont.)


**7** Confirm that entries are made as shown below then continue.

Select Procedure Location:  
Card

Select Procedure Filename:  
CARD\_INIT


**8** Position cursor at **RUN TEST** and select it.

**Position**   1 Run Test  
2 Continue  
4 Help


**Select** 

**9** Opt. 052 program takes approx. two min to load and signals an audible beep when finished. When screen below appears continue at step 10.

**Position**



**Select**



TESTS (IBASIC Controller)

Install the card to be initialized.  
Press Continue.

1 Continue

2 Exit

3

4

5


---

To Screen

RF GEN



RF ANL


**10** Slide write protect tab on the SRAM card to the up position.



INT3a

**11** Insert SRAM card, then position cursor at **Continue** and select it.



**Position**  

**Select** 



Turn page to continue

## Initialize a Memory Card (Cont.)



**12** At this screen, position cursor at **DOS** and select it.

|  |                           |                               |
|--|---------------------------|-------------------------------|
| <b>Position</b><br> | TESTS (IBASIC Controller) | 1 DOS                         |
|  |                           | 2 LIF                         |
| <b>Select</b><br>   | Select DOS or LIF format. | 3                             |
|  |                           | 4                             |
|  |                           | 5                             |
|  |                           | To Screen<br>RF GEN<br>RF ANL |

**13** At this screen, position cursor at **Yes** and select it.

|  |                           |                               |
|--|---------------------------|-------------------------------|
| <b>Position</b><br> | TESTS (IBASIC Controller) | 1 Yes                         |
|  |                           | 2 No                          |
| <b>Select</b><br>   | Ready to initialize card? | 3                             |
|  |                           | 4                             |
|  |                           | 5                             |
|  |                           | To Screen<br>RF GEN<br>RF ANL |

**14** Initialization is confirmed.


|  |                           |                               |
|--|---------------------------|-------------------------------|
| <b>Position</b><br> | TESTS (IBASIC Controller) | 1 Run                         |
|  |                           | 2 Continue                    |
| <b>Select</b><br>   | Card is initialized.      | 3 Snel Step                   |
|  |                           | 4 Clr Scr                     |
|  |                           | To Screen<br>RF GEN<br>RF ANL |

INIT4a


Next: Turn page to begin Local Control Program transfer

## Transfer the Local Control Program


**1** Connect pc to test set with cable RJ-11 (M) to DB-9 (F), part number 8921 - 61038. (supplied)



**2** Insert Opt 052 program card into memory slot on test set front panel.




**3** Press **TESTS** to display **TESTS** screen.




**4** Position cursor at **Location** and select it.

Position




Select




**5** Position cursor at **Card** and select it.

Position



Select




Continue on next page

## Transfer the Local Control Program (Cont.)


**6** Position cursor at **Select Procedure Filename** and select it.


**Position**



Select Procedure Filename:


**Select**






**7** Position cursor at **FX\_XFER** and select it.

**Position**




**Select**



Choices :

- ERIC8\_883
- ERIC8\_MC
- LAPTOP\_EM
- CARD\_INIT
- FX\_XFER
- GET\_START
- D\_C\_XFER



**8** Confirm that entries are made as shown below then continue.

Select Procedure Location:


Card

Select Procedure Filename:


FX\_XFER

**9** Position cursor at **RUN TEST** and select it.

**Position**




**Select**



1 Run Test

2 Continue

4 Help



**10** When screen below appears continue at step 11.

TESTS (IBASIC Controller)

Insert initialized RAM card.  
Press Continue.

1 Continue

2

3

4

5







To Screen

RF GEN

RF ANL

LCP2 Turn page to continue

## Transfer the Local Control Program (Cont.)


|   |   |   |          |   |  |   |  |   |  |   |  |
|---|---|---|----------|---|--|---|--|---|--|---|--|
| <p><b>11</b> Remove Opt.052 card and insert previously initialized SRAM card</p>   | <p><b>12</b> Position cursor at <b>Continue</b> and select it.</p> <p>Position</p>  <p>Select</p>  <table border="1" data-bbox="1039 651 1193 871"><tr><td>1</td><td>Continue</td></tr><tr><td>2</td><td></td></tr><tr><td>3</td><td></td></tr><tr><td>4</td><td></td></tr><tr><td>5</td><td></td></tr></table> | 1 | Continue | 2 |  | 3 |  | 4 |  | 5 |  |
| 1   | Continue  |   |          |   |  |   |  |   |  |   |  |
| 2   |   |   |          |   |  |   |  |   |  |   |  |
| 3   |   |   |          |   |  |   |  |   |  |   |  |
| 4   |   |   |          |   |  |   |  |   |  |   |  |
| 5   |   |   |          |   |  |   |  |   |  |   |  |
| <p><b>13</b> At dos prompt on your pc enter <b>mode com1:48,n,8,1</b></p>   | <p><b>14</b> From directory containing your fx1 file enter, <b>copy fx1.mpr com1</b></p>   |   |          |   |  |   |  |   |  |   |  |
| <p><b>15</b> Confirm that fx1 file was copied from pc to SRAM card.</p> <p>When test set screen stops scrolling and "<b>Testing complete</b>" appears at top of test set screen, file has been successfully copied to the SRAM card..</p> | <p><b>16</b> Remove SRAM card from test set.</p>    |   |          |   |  |   |  |   |  |   |  |

Next: Verify Local Control Transfer



---


## Transfer the Local Control Program (Cont.)




You have now completed local control file transfer. To verify that the local control program has been successfully transferred to the memory card, turn the page and follow the steps to load and run **GET\_START**. GET\_START contains a test (transmitter power) that will download the local control program from the memory card to the base station.

## Verify Local Control Transfer (Transmitter Power Test)


**1** Disconnect pc from test set rear panel, then connect powered radio as shown below (Ericsson Model 883 transceiver).



**2** Insert Opt 052 program card into memory slot on test set front panel.



**3** Press TESTS to display TESTS screen.




VLCT1

Continue on next page

## Verify Local Control Transfer (Cont.)

**4** Position cursor at **Select Procedure Filename** and select it.


**Position**



Select Procedure Filename:


**FX\_XFER**

**Select**



**5** Position cursor at **GET\_START** and select it.


**Position**




**Choices :**

- ERIC5\_883
- ERIC5\_MC
- LAPTOP\_EM
- CARD\_INIT
- FX\_XFER
- GET\_START
- D\_C\_XFER

**Select**



*For Visual Reference Only*



TESTS (Main Menu)

Please select a procedure to load.

**LOAD TEST PROCEDURE:**

Select Procedure Location:  
 Card

Select Procedure Filename:    Library:    Program:

**FILE\_XFER**

Description:

**CUSTOMIZE TEST PROCEDURE:**    **SET UP TEST SET:**

|                                   |                              |
|-----------------------------------|------------------------------|
| <b>Freq</b> Channel Information   | <b>Exec</b> Execution Cond   |
| <b>Parm</b> Test Parameters       | <b>Cnfg</b> External Devices |
| <b>Seqn</b> Order of Tests        | <b>Print</b> Printer Setup   |
| <b>Spec</b> Pass/Fail Limits      | <b>IBASIC</b> IBASIC Cntrl   |
| <b>Proc</b> Save/Delete Procedure |                              |

**Choices:**


- ERIC5\_883
- ERIC5\_MC
- LAPTOP\_EM
- CARD\_INIT
- FX\_XFER
- GET\_START
- D\_C\_XFER

LOADTX2a


Turn page to continue

## Verify Local Control Transfer (Cont.)


**6** Remove Opt.052 card and insert previously initialized SRAM card




**7** Position cursor at **Run Test** and select it.



**8** When test set "beeps," position cursor at **Continue** and select it. To change channel no., use keypad to enter new number, then select **Continue**.




**9** When this screen appears, position cursor at **Done** and select it. Adjusting meter is not required for verifying software operation.



Continue on next page

---

## Verify Local Control Transfer (Cont.)



You have now completed the tasks associated with Getting Started. You have transferred the local control program from your laptop and have run the transmitter power test to confirm the functionality of the Test Set and local control program transfer. Proceed to [chapter 3, "Product Description"](#) for an introduction to the HP 11807B Option 052 Software and a guide to the organization of this manual.



---

## **Getting Started with FW Revision Below A.14.00**

---

## Firmware Enhancements

---

**NOTE:**

The firmware revision A.14.00 in the HP 8921A,D had several enhancements. This chapter applies to users with:

- **HP 8921A test sets with firmware revision below A.14.00**

The Test Set's firmware revision is displayed on the top right corner of the configuration screen.

- Press SHIFT CONFIG to display the configuration screen and read the firmware revision.

If you have an HP 8921A with firmware revision above A.14.00, refer to [chapter 1, "Getting Started with FW Revision Above A.14.00"](#). Contact Hewlett-Packard at 1-800-922-8920 for details on upgrading your firmware if desired.

---

### Test Set or System is Defined As:

- HP 8921A, Option 500, Dual-Mode Cellular Test System
- HP 8921D, Dual-Mode Cell Site Test System



---

## What You'll Test and What You'll Need

Getting Started will quickly acquaint you with the operation of the Test Set and the HP 11807B Option 052 Software. You will do the following:

**1. Run the local control file transfer test.**

This will transfer the local control (FX) file from your laptop to the Test Set. Once this transfer has been done the Test Set will automatically download the local control file to the base station under test when other tests are run on a model 883 or Microcell transceiver. You will be initializing a memory card in the Test Set for storage of the local control file.

**2. Run the transmitter power adjustment test on a model 883 transceiver.**


This will verify that the local control file was transferred to the Test Set and downloaded successfully to the base station.

You will need the following in order to complete the testing in Getting Started:

- HP 11807B Option 052 Software
- One of the following:
  - HP 8921A, Option 500, Dual-Mode Cellular Test System
  - HP 8921D, Dual-Mode Cell Site Test System
- An Ericsson Model 883 Transceiver Module
- Type N (m) to Type N (m) 6 ft. RJ214 cable for transmitter output to Test Set RF IN/OUT connection
- RJ-11(m) to DB-9 (f) 4 wire cable for laptop to Test Set connection, supplied with HP 11807B Option 052 Software (part no. 08921-61038)
- Quarter Plug to RJ-11 (m) cable for local control connection, supplied with HP 11807B Option 052 Software (part no. 08921-61032)
- A laptop (PC compatible) with the local control program applicable to the Model 883

At the time of this writing, the HP 11807B Option 052 software is known to be compatible with Ericsson local control revision R14.

## Test Set Overview




## Load the Software

**1** Power up the test set by doing the steps below.

(After step 3, screen should look like figure on facing page.)

Press TESTS **3**



**1** Press POWER

**2** Wait about 20 sec. for display to appear, then go to step 3.

POWER1

Next: Turn page to begin Memory Card initialization

**For Visual Reference Only**

*Field entries on your screen may be different.*

The screenshot shows a test configuration menu with several sections and a list of options on the right. Arrows from the text above point to the following fields:











- Procedure: Location
- Library
- Program
- Autostart: Off/On
- Comment
- Test Execution Conditions
- On UUT Failure: Continue/Stop
- Fun Mode: Continuous/Single Step
- Output Results: All/Failure
- Output Destination: Crt/Printer
- Output Headers
- Test Function: Edit/Arm

Options on the right side of the screen:


- 1 Run Test
- 2 Continue
- 3 Edit Sean
- 4 Edit Freq
- 5 Edit Sped
- To Screen
- RF GEN
- RF ANL
- AF ANL
- SCOPE
- SPEC ANL
- ENCODER
- DECODER
- RADIO INT
- More

POWER2

## Initialize a Memory Card (for local control file storage)

|  |   |
|--|---|
| <p><b>1</b> Insert Opt 052 program card into memory slot on test set front panel.</p>   | <p><b>2</b> Press <b>TESTS</b> to display <b>TESTS</b> screen.</p>    |
| <p><b>3</b> Position cursor at <b>Location</b> and select it.</p> <p><b>Position</b></p>  <p><b>Select</b></p>    | <p><b>4</b> Position cursor at <b>Card</b> and select it.</p> <p><b>Position</b></p>  <p><b>Select</b></p>        |
| <p><b>5</b> Position cursor at <b>Procedure</b> and select it.</p> <p><b>Position</b></p>  <p><b>Select</b></p>  | <p><b>6</b> Position cursor at <b>CARD_INIT</b> and select it.</p> <p><b>Position</b></p>  <p><b>Select</b></p>  |

Next: Turn page to continue




INT2


## Initialize a Memory Card (Continued)

**7** Confirm that entries are made as shown below then continue.

Procedure: Location  
**CARD\_INIT** : Card


**8** Position cursor at **RUN TEST** and select it.


**Position** 

**Select** 

- 1 Run Test
- 2 Continue
- 3 Edit Seqn
- 4 Edit Freq
- 5 Edit Spec

**9** Opt. 052 program takes approx. two min to load and signals an audible beep when finished. When screen below appears continue at step 10.

**Position** 

**Select** 

TESTS (IBASIC Controller)

Install the card to be initialized.  
Press Continue.

1 Continue

2 Exit

3

4

5


---

To Screen


RF GEN


RF ANL


**10** Slide write protect tab on the SRAM card to the up position.



**11** Insert SRAM card, then position cursor at **Continue** and select it.

**Position** 

**Select** 





Turn page to continue





## Initialize a Memory Card (Continued)



**12** At this screen, position cursor at **DOS** and select it.

|  |                           |  |
|--|---------------------------|--|
| <b>Position</b><br><br><b>Select</b><br> | TESTS (IBASIC Controller) | 1 DOS ←<br>2 LIF<br>3<br>4<br>5<br>To Screen<br>RF GEN<br>RF ANL |
|  | Select DOS or LIF format. |  |

**13** At this screen, position cursor at **Yes** and select it.

|  |                           |   |
|--|---------------------------|---|
| <b>Position</b><br><br><b>Select</b><br> | TESTS (IBASIC Controller) | 1 Yes ←<br>2 No<br>3<br>4<br>5<br>To Screen<br>RF GEN<br>RF ANL |
|  | Ready to initialize card? |   |

**14** Initialization is confirmed.


|  |                           |  |
|--|---------------------------|--|
| <b>Position</b><br><br><b>Select</b><br> | TESTS (IBASIC Controller) | 1 Run<br>2 Continue<br>3 Sngl Step<br>4 Clr Scr<br>To Screen<br>RF GEN<br>RF ANL |
|  | Card is initialized.      |  |

INT4


Next: Turn page to begin Local Control Program transfer

## Transfer the Local Control Program


**1** Connect pc to test set with cable RJ-11 (M) to DB-9 (F), part number 8921 - 61038. (supplied)



**2** Insert Opt 052 program card into memory slot on test set front panel.




**3** Press **TESTS** to display **TESTS** screen.



**4** Position cursor at **Location** and select it.

Position




Select

Procedure: Location

**5** Position cursor at **Card** and select it.

Position



Select

Choices :

- Card
- ROM
- RAM
- Disk


LCP1

Continue on next page


## Transfer the Local Control Program (Continued)

**6** Position cursor at **Procedure** and select it.

**Position**



**Select**




Procedure: Location


█ : Card

**7** Position cursor at **FX\_XFER** and select it.

**Position**



**Select**



Choices :

ERICS\_883  
 ERICS\_MC  
 LAPTOP\_EM  
 CARD\_INIT  
 FX\_XFER  
 GET\_START  
 D\_C\_XFER

**8** Confirm that entries are made as shown below then continue.

Procedure: Location


FX\_XFER

 : 


Card

**9** Position cursor at **RUN TEST** and select it.

**Position**



**Select**



Run Test

2 Continue  
 3 Edit Seqn  
 4 Edit Freq  
 5 Edit Spec

**10** When screen below appears continue at step 11.

TESTS (IBASIC Controller)

Insert initialized RAM card.  
Press Continue.

1 Continue

2

3

4

5

To Screen







RF GEN

RF ANL

Turn page to continue

LCP2

## Transfer the Local Control Program (Continued)


|  |   |   |          |   |  |   |  |   |  |   |  |
|--|---|---|----------|---|--|---|--|---|--|---|--|
| <p><b>11</b> Remove Opt.052 card and insert previously initialized SRAM card</p>    | <p><b>12</b> Position cursor at <b>Continue</b> and select it.</p> <p>Position</p>  <p>Select</p>  <table border="1" data-bbox="1047 630 1201 850"> <tr><td>1</td><td>Continue</td></tr> <tr><td>2</td><td></td></tr> <tr><td>3</td><td></td></tr> <tr><td>4</td><td></td></tr> <tr><td>5</td><td></td></tr> </table> | 1 | Continue | 2 |  | 3 |  | 4 |  | 5 |  |
| 1  | Continue  |   |          |   |  |   |  |   |  |   |  |
| 2  |   |   |          |   |  |   |  |   |  |   |  |
| 3  |   |   |          |   |  |   |  |   |  |   |  |
| 4  |   |   |          |   |  |   |  |   |  |   |  |
| 5  |   |   |          |   |  |   |  |   |  |   |  |
| <p><b>13</b> At dos prompt on your pc enter <code>mode com1:48,n,8,1</code></p>    | <p><b>14</b> From directory containing your fx1 file enter, <code>copy fx1.mpr com1</code></p>   |   |          |   |  |   |  |   |  |   |  |
| <p><b>15</b> Confirm that fx1 file was copied from pc to SRAM card.</p> <p>When test set screen stops scrolling and "Testing complete" appears at top of test set screen, file has been successfully copied to the SRAM card..</p> | <p><b>16</b> Remove SRAM card from test set.</p>    |   |          |   |  |   |  |   |  |   |  |

LAPTOP1

Next: Verify Local Control Transfer


---

## Transfer the Local Control Program (Continued)



You have now completed local control file transfer. To verify that the local control program has been successfully transferred to the memory card, turn the page and follow the steps to load and run **GET\_START**. GET\_START contains a test (transmitter power) that will download the local control program from the memory card to the base station.

## Verify Local Control Transfer (Transmitter Power Test)




Continue on next page

## Verify Local Control Transfer (Continued)

**4** Position cursor at **Procedure** and select it.


**Position**



Procedure: Location


**FX\_XFER** : Card

**Select**



**5** Position cursor at **GET\_START** and select it.


**Position**



**Choices :**

- ERICs\_883
- ERICs\_MC
- LAPTOP\_EM
- CARD\_INIT
- FX\_XFER
- GET\_START**
- D\_C\_XFER

**Select**



*For Visual Reference Only*

**4**

| TESTS   |                        |         |           |
|---|------------------------|---------|-----------|
| Procedure:  | Library                | Program | Autostart |
| FX_XFER : Card  | ERI_TCS                | :Card   | Off/On    |
| <b>Comment</b>  |                        |         |           |
| This procedure is used to transfer the FX file from a personal computer to a memory card. |                        |         |           |
| <b>Test Execution Conditions</b>  |                        |         |           |
| On UUT Failure  | Run Mode               |         |           |
| Continue/Stop   | Continuous/Single Step |         |           |
| Output Results  | Output Destination     |         |           |
| All/Failures  | Crt/Printer            |         |           |
| Output Headings   |                        |         |           |
|   |                        |         |           |
| <b>Test Function</b>  |                        |         |           |
| Edit Sean   |                        |         |           |

**Choices:**

- ERICs\_883
- ERICs\_MC
- LAPTOP\_EM
- CARD\_INIT
- FX\_XFER
- GET\_START**
- D\_C\_XFER


**5**

VLC12

Turn page to continue


## Verify Local Control Transfer (Continued)

**6** Remove Opt.052 card and insert previously initialized SRAM card




**7** Position cursor at **Run Test** and select it.

**Position**




**Select**




- 1 Run Test
- 2 Continue
- 3 Edit Seqn
- 4 Edit Freq
- 5 Edit Spec

**8** When test set "beeps," position cursor at **Continue** and select it. To change channel no., use keypad to enter new number, then select **Continue**.

**Position**



**Select**



channel no. →

TESTS (IBASIC Controller)

350

<Ericsson 882 Transceiver>

RXA 0

RXB 0

Test

Tx

<HP 8921A>

---RF--- -AUDIO-

I/O DUP OUT IN

1 Run

2 Continue ←

3 Encl Step

4 Clr Scr

To Screen


RF GEN

RF ANL


RF ANL

**9** When this screen appears, position cursor at **Done** and select it. Adjusting meter is not required for verifying software operation.

**Position**




**Select**



TESTS (IBASIC Controller)

Power = 43.92 Watts



30.00 <---- 0 K ----> 60.00

Hewlett-Packard

1 Done ←

2

3

4 Tns quiet

5 Laptop

To Screen

RF GEN

RF ANL


RF ANL

Continue on next page



---

## Verify Local Control Transfer (Continued)



You have now completed the tasks associated with Getting Started. You have transferred the local control program from your laptop and have run the transmitter power test to confirm the functionality of the Test Set and local control program transfer. Proceed to [chapter 3, "Product Description"](#) for an introduction to the HP 11807B Option 052 Software and a guide to the organization of this manual.



---

## Product Description

## HP 11807B Option 052 Software

The HP 11807B Software performs fast, accurate, automated tests that determine RF and audio performance of cellular base stations. Most of the measurement methods and specifications used for these tests are based on methods and values from Ericsson and CRAG test procedures.

The HP 11807B Option 052 software can be used for the installation, maintenance, and/or repair of:

- Model 883
- Model 883M (MCBS, Microcell)

This manual shows connection diagrams for Models 883 and Microcell base stations.

Base station equipment to be tested may be located at an active cell site or where suitable dc power can be supplied to a Transceiver Module (TRM). Testing with the Test Set and HP 11807B Option 052 Cell Site Software is possible on any transceiver that can successfully be controlled by the local control program.

For a complete list of Tests and their descriptions, [see "Test Descriptions" on page 128](#).

### Items Included in the HP 11807B Option 052 Software

- An RJ-11(m) to DB-9(f) cable (part number 08921-61038) for PC (laptop) to test set connection to transfer the FX1 file from the personal computer to the memory card
- An RJ-11(m) to quarter plug cable (part number 08921-61032) for Test Set to transceiver connection to download the local control program and control the transceiver
- A One Time Programmable (OTP) memory card containing the preprogrammed HP 11807B Option 052 software
- A 128 Kbyte SRAM memory card for storing the Ericsson local control program, test procedures and test results
- The User's Guide presently being used

## Software Features

The following features simplify testing:

- While adjustments are being made, a large meter display and auditory feedback are provided.
- When cable connections need to change, system interconnects are graphically shown on the Test Set CRT display.
- Results of tests and pass/fail indications are displayed on the Test Set CRT, and can be printed, or collected in a disk drive, memory card, PC, or HP Palmtop.
- The software allows the operator to change test order, pass/fail limits, testing conditions and equipment configurations.
- RF path losses can be determined and corrected.

## Equipment Needed to Begin Testing

- HP 11807B Option 052 Ericsson Cell Site Test Software
- HP Test Set consisting of one of the following:
  - HP 8921A, Option 500, Dual-Mode Cellular Test System
  - HP 8921D, Dual-Mode Cell Site Test System
- The HP 11807B Option 052 software runs on the HP 8921A Cell Site Test Set.

In this manual, the term Test Set refers to the HP 8921A, HP 8921D, or the HP 8921A, Option 500.


The HP 8921A firmware revision number must be A.08.04 or higher. You can determine the revision of the firmware by pressing SHIFT CONFIG on the Test Set front panel. The revision number will be displayed in the CONFIGURE screen.

- SRAM memory card(s) for storing Ericsson local control program, test setups and test results (supplied with Option 052).
- Ericsson local control software
- A Personal Computer capable of downloading the Ericsson local control program to the Test Set
- Connection arrangements, [see "Making Connections," in chapter 4, on page 65](#) for more detail
- Optional
  - HP 83202A Option 042 Ericsson Base Station Accessory Kit, [see "Connection Cables and Adapters Needed," in chapter 4, on page 68](#) for more detail.
  - Printer and cables to document results.
  - PC, disk drive, or HP Palmtop to store data.

---


## Finding the Information You Need

This manual describes the setup and use of the HP 11807B Software with the Test Set. The book is arranged in self contained chapters to meet the following objectives:




### GETTING STARTED

- Fast paced, hands on tutorial.
- Basic test set/software operation.
- First time or occasional users.



### CONNECTIONS-CHAPTER 4

- Instructions for cabling test set.



### USING THE SOFTWARE-CHAPTER 5

- How to load
- How to run
- How to customize
- Conceptual overview



### TEST DESCRIPTIONS-CHAPTER 7

Definitions, special conditions and restrictions for:

- Tests
- Specifications-Pass/fail limits
- Parameters-Test conditions



### REFERENCE-CHAPTER 8

- Alphabetically listed
- Detailed descriptions of all the features and functions of the software.
- For the advanced level user.





### PROBLEM SOLVING-CHAPTER 9

- Alphabetically listed
- Symptoms and possible corrections to frequent user problems.
- Error Messages



MANUAL

---

### Additional Services Available



Consult the Test Set User's Guide or call the HP 8921A Hotline 1-800-922-8920 and give your software model number.



Contact your local HP Sales Representative for information about the Software Upgrade Service and the Start Up Assistance Training Course.





---

## Making Connections

This chapter lists cables and adapters you need plus the connection diagrams you will use when setting up the HP 11807B software to test your base station.

---

**CAUTION:** The Test Set can be damaged by transient RF power, continuous RF power, high voltage, electrostatic discharge from cables and other sources. Connections to equipment must be chosen to reduce the risk of damage to the equipment.

The application of RF power greater than 200 mW (+23 dBm) can damage the Test Set DUPLEX OUT port.

---

Two interface cables are supplied with the HP 11807B Option 052 software.

- An RJ-11(m) to DB-9(f) cable (part number 08921-61038) for PC (laptop) to test set connection to transfer the FX1 file from the personal computer to a memory card. This cable can also be used to transfer test results from the Test Set to a personal computer (data collection).
- An RJ-11(m) to quarter plug cable (part number 08921-61032) for Test Set to base station serial control.

There are other cables and adapters required for audio and RF connections. These cables and adapters are listed in the following **table 1**. You may use your own cables and adapters or the HP 83202A Option 042 Ericsson Base Station Accessory Kit sold separately. The kits' contents are also listed in the following **table 1**. Connections and configuration for printers or peripherals are not covered in this chapter. **See "Data Collection (Saving and Retrieving Test Results)," in chapter 8, on page 164 .**

## Connection Cables and Adapters Needed

**Table 1** Connection Cables and Adapters Needed


| Reference # | Description                               | Purpose   | Quantity Needed | Part Number    | HP 83202A Kit |
|-------------|---|---|-----------------|----------------|---------------|
| 1           | N(m) to N(m) RG214 cable, 6ft             | TX output to Test Set RF IN/OUT   | 1               | HP 08921-61029 | Yes           |
| 2           | Power splitter, 2 Gz, BNC(f) resistive    | Connect between the HP 8921A DUPLEX OUT and transceiver RXA and RXB. It also is used to test for cable faults | 1               | HP 0955-0733   | Yes           |
| 3           | BNC(f) to TNC(m) adapter                  | Adapt BNC cable to RXA, RXB   | 3               | HP 1250-2441   | Yes           |
| 4           | BNC(m) to BNC(m) cable RG223, 4ft         | RXA, RXB and audio to Test Set AUDIO IN/OUT and DUPLEX OUT  | 4               | HP 8120-1840   | Yes           |
| 5           | BNC(m) to BNC(m) cable RG223, 1ft         | Connect RXA, RXB to power splitter  | 2               | HP 8120-1838   | Yes           |
| 6           | BNC(m) to Banana(f) adapter               | AUDIO IN, HI and LO   | 2               | HP 1250-2164   | Yes           |
| 7           | Banana(m) to BNC(f) adapter               | Test Set AUDIO IN   | 1               | HP 1251-2277   | Yes           |
| 8           | 50Ω termination BNC(m)                    | Splitter termination for diversity test   | 1               | HP 1250-0207   | Yes           |
| 9           | Audio Break Out Box, BNC(f)               | Breaks out the audio lines on the Ericsson 882  | 1               | HP 1150-1987   | Yes           |
| 10          | RJ-11(m) to RJ-11(f) dual adapter, 6 wire | Test Set serial "Y" adapter   | 1               | HP 08921-61031 | Yes           |

**Table 1 Connection Cables and Adapters Needed**


| <b>Reference #</b> | <b>Description</b>                                      | <b>Purpose</b>   | <b>Quantity Needed</b> | <b>Part Number</b>                            | <b>HP 83202A Kit</b> |
|--------------------|---|--|------------------------|---|----------------------|
| <b>11</b>          | RJ-11(m) to Ericsson Quarter Plug, BNC cable (supplied) | Test Set serial to base station Local Cntrl                    | 1                      | HP<br>08921-61032                             | Yes                  |
| <b>12</b>          | RJ-11(m) to DB-9(f) cable                               | Serial connection to laptop                                    | 1                      | HP<br>08921-61035                             | Yes                  |
| <b>13</b>          | RJ-11(m) to DB-9(f) cable (supplied)                    | For local control transfer and Data Collection to PC           | 1                      | HP<br>08921-61038                             | Yes                  |
| <b>14</b>          | DB-25(m) to RJ-11(m) cable                              | For Data Collection to serial printer                          | 1                      | HP<br>08921-61039                             | Yes                  |
| <b>15</b>          | SWR Bridge Type N(m)                                    | For swept and channel VSWR                                     | 1                      | Eagle<br>RLB150N3B or equivalent <sup>1</sup> | No                   |
| <b>16</b>          | 6 dB Pad, BNC(f) to BNC(m)                              | SWR bridge to Test Set matching. Also used to test cable loss. | 2                      | HP<br>0955-0698                               | No                   |
| <b>17</b>          | BNC(f) to N(m) adapter                                  | SWR bridge to BNC cable  | 2                      | HP<br>1250-0780                               | No                   |

1. Eagle Wichita, Box 4010, Sedona, AZ 86340 (Tel: 520-204-2597) (Fax: 520-204-2568)

## Ericsson Model 883 Connections



## Ericsson Microcell Connections



---

## Cable and Antenna Measurement Connections




Figure 1 TEST\_04 GN Swept Return Loss and TEST\_05 GN Discrete Channel Return Loss





Figure 2 TEST\_06 GN Cable Fault Versus Distance





vswrc.tif

Figure 3 TEST\_07 GN Measure Cable Loss

---

## Determining Calibration Parameters

Inaccuracies can occur in your measurements due to cable losses and impedance mismatches in your test system. Calibration factors should be entered as parameters into the TESTS (Edit Parameters) screen. The test program will use these calibration factors when running tests. The test software will run with the default values in parameters TX path loss and RX path loss, but you should adjust these values based on your actual cable configuration. TEST\_07 GN Measure Cable Loss can be used to measure path losses.

---

**5**

---

**Using the Software with FW Above Rev.  
A.14.00**

---

## Firmware Enhancements

---

**NOTE:**

The firmware revision A.14.00 in the HP 8921A,D had several enhancements. This chapter applies to users with:

- **HP 8921A test sets with firmware revision above A.14.00**

The test set's firmware revision is displayed on the top right corner of the configuration screen.

- Press SHIFT CONFIG to display the configuration screen and read the firmware revision.

If you have an HP 8921A test set with firmware revision below A.14.00, refer to [chapter 6, "Using the Software/HP 8921A FW Rev. Below A.14.00," on page 101](#). Contact Hewlett-Packard at 1-800-922-8920 for details on upgrading your firmware if desired.

---

---

## Test Set or System is Defined As:

- HP 8921A, Option 500, Dual-Mode Cellular Test System
- HP 8921D, Dual-Mode Cell Site Test System

## Introduction

The software can be run on the factory default settings or customized to your individual needs and specific requirements. This chapter provides detailed information on how to load, run, and customize the software.

The test set has two methods of accessing on-line help. In each of the screens in the test environment, k4 (**He1p**) accesses specific information about how to set up/use the current screen. SHIFT HELP accesses the master help file, with an alphabetical listing of help topics.

---

## Testing Overview

Pressing TESTS will display what is called the TESTS (Main Menu) screen. To begin testing, you must first load the software and make connections. From this screen you have the option to: **Begin running tests:**


- The factory default settings are acceptable for your application or
- The software has already been customized and saved to a memory card

### **Customize the software:**

- Decide which tests you desire to run (Order of Tests)
  - you may want to run all, some, or just one of the tests.
- Change the pass/fail limits for specific measurements (Pass/Fail Limits)
  - you may want the pass/fail limits to have tighter or looser specifications than the default settings.
- Change the test environment and conditions (Test Parameters)
  - decide output format.
  - enter specific information about radio equipment and/or environment.
- Save any or all of the above customized changes to a memory card (Save/Delete Procedure)

### **Set Up Test Set:**

- Print test results or certain screens.
- Decide when and where test results are displayed (**Test Execution Conditions/External Devices**)



## Before Running Tests








- You must do “Getting Started” before running tests on a model 883 or Microcell transceiver. “Getting Started” stores your local control (FX) file on an SRAM (Static Random Access Memory) memory card so that it may be downloaded to the transceiver before tests are run.
- Select a test procedure from the HP 11807B Option 052 software card. The software is shipped with the following preprogrammed test procedures on the program card.
  - ERIC8\_883** is used for Model 883 testing.
  - ERIC8\_MC** is used for Microcell testing.
  - LAPTOP\_EM** runs **TEST\_01 - GN Laptop Emulator**.
  - CARD\_INIT** runs **TEST\_02 - Memory Card Initialisation**.
  - FX\_XFER** runs **TEST\_03 - Local Control File Transfer**.
  - GET\_START** runs **TEST\_10 - TX Power Adjustment** used in “Getting Started”.
  - D\_C\_XFER** runs **TEST\_08 - GN Data Collection File Transfer**.
  - CAB\_LOSS** runs **TEST\_07 - GN Measure Cable Loss**.
  - ANT\_SWEEP** runs **TEST\_04 - GN Swept Return Loss**.
  - CAB\_FLT** runs **TEST\_06 - GN Cable Fault Versus Distance**.
- Before you begin testing, you should have made the appropriate hardware connections. See [chapter 4, "Making Connections"](#) if you have not done so already.



## Running Tests

- When tests begin to run, they are executed in the order in which they were entered into the Test Procedure.
- Pressing CANCEL will pause the current test (press **Continue** to continue the test).
- When the **Run Test** softkey is pressed, the test set will check to see if the program is already resident in RAM memory. If it is not, it will be loaded from the memory card, a process which takes about two minutes. The contents of the HP 8921A RAM memory are retained even while the instrument is powered down.
- After all testing is complete on a given transceiver, you must exit local control so that the transceiver can be put back into service. Run TEST\_01 Laptop Emulator as your last test and select **EXIT LOCAL CONTROL**.

## Selecting a Test Procedure

|   |   |
|---|---|
| <p><b>1</b> Insert Opt. 052 card, or card containing desired procedure.</p>    | <p><b>2</b> Press <b>TESTS</b> to display <b>TESTS (Main Menu)</b> screen.</p> <p>If you are running <b>IBASIC</b>, press <b>SHIFT, CANCEL</b> before pressing <b>TESTS</b>.</p>   |
| <p><b>3</b> Position cursor at <b>Select Procedure Filename</b> and select it.</p> <p><b>Position</b></p>  <p><b>Select</b></p>   | <p><b>4</b> Position cursor at desired procedure and select it.</p> <p><b>Position</b></p>  <p><b>Select</b></p>  <div style="border: 1px solid black; padding: 5px; margin-left: 100px;"> <p>Choices :</p> <ul style="list-style-type: none"> <li>UUUU_UU</li> <li>VVVV_VVV</li> <li>WWW_WWW</li> <li>XXXX_XXX</li> <li>YYYY_YYY</li> <li>ZZZZ_ZZZ</li> </ul> </div> |
| <p><b>5</b> To run the test, position cursor at <b>Run Test</b> and select it. To customize the procedure, refer to <b>Customizing the Software</b> in this chapter.</p> <div style="margin-left: 150px;">  <div style="border: 1px solid black; padding: 5px; display: inline-block;"> <p><b>1</b> Run Test</p> <p>2 Continue</p> <p>4 Help</p> </div> </div> |   |

PROC1a

The usual sequence for testing an operational cell site is as follows:

1. Use the Ericsson FIOL program running on a personal computer (PC) to contact the Mobile Telephone Switching Office (MTSO) in order to “block” a set of transceivers to be tested. It is convenient to block a set of four which are connected to the same star junction.
2. Run the **ERICCS\_883** or **ERICCS\_MC** procedure on each transceiver as appropriate. Model 883 and Microcell transceivers can be tested without having anything loaded from the MTSO or PC because they receive a download of the local control (FX) file from the memory card automatically (if required) at the beginning of each test procedure.
3. Run the **LAPTOP\_EM** procedure to key up and display the spectrum of each transceiver for combiner tuning.
4. Continue to run the **LAPTOP\_EM** procedure to de-key each transmitter and exit local control on each transceiver.
5. Use the FIOL program to request the MTSO to “unblock” the transceivers which have just been tested.
6. Repeat steps 1 through 5 for a new set of transceivers.
  - The PC can remain connected to the ERI panel (or telephone line) for the duration of testing. There it can be used to block transceivers and to query the MTSO for transceiver channel assignments so that each transceiver can be tested on the channel it will be operating on.
  - Test results can be printed, stored on a memory card or transferred to a PC. [See "Printing" on page 189](#) and ["Data Collection \(Saving and Retrieving Test Results\)" on page 164](#).
  - Individual transceivers can be tested on the workbench, in which case only step 2 above applies.

## Customizing Testing

Because of the diversity of individual testing needs, the software has been designed so that changes may be easily made from the test set's front panel. You may store these changes on a memory card so that you may skip these steps in the future. **"Saving a Test Procedure" on page 94.**

Because your needs change, the software allows changes to its default settings whenever you need to make them. For example, tests may be inserted or deleted, and later after running the tests you can change the pass/fail limits or decide to test different channels.

Most testing customization is accomplished through the customization screens. These customization screens are accessed from the main TESTS (Main Menu) screen as shown in the following figure. Customizing procedures is explained later in this chapter.

---


**NOTE:** Channel Information, External Devices, Printer Setup, and IBASIC will not be explained in this customizing section.

---

- Channel Information is not used by the HP 11807B Option 052 software.
- External Devices are used when setting up printers and external disk drives which is explained in **"Disks" on page 173** and **"Printing" on page 189**.
- Printer Setup is used with B.xx.xx revision software only. Currently not available with HP 11807B Option 052 software.
- IBASIC is used when writing your own programs and is not explained in this manual. If you need to write your own IBASIC programs you may acquire the following manuals:
  - HP 8921A,D
    - *HP Instrument Basic User's Handbook* HP part number E2083-90601.
    - *HP 8921 Programming Manual* HP part number 08921-90031.

## Beginning Software Customization

All software customization begins by accessing the TESTS Main Menu screen first and then selecting the **CUSTOMIZE TEST PROCEDURE** filed of your choice. Press TESTS on the front panel of the test set to access the TESTS Main Menu screen.






















## Changing the Order of Tests

You may define the order of tests to include all, some, or just one of the tests available. When the first test is finished, the next will run. The test sequence will remain in the test set's battery backed-up memory until another test sequence is loaded or set up. For information on saving a customized test sequence, see ["Saving a Test Procedure" on page 94](#).

Defining the order of tests is accomplished by inserting or deleting tests from the list of tests that come with the software package. See ["Test Descriptions" in chapter 7](#), for descriptions of tests included in this package.

















The following describes how to create a new test sequence.

## How to Change the Order of Tests

|  |  |                 |   |  |                          |               |  |               |                     |   |                       |   |                            |  |     |            |  |
|--|--|-----------------|---|--|--------------------------|---------------|--|---------------|---------------------|---|-----------------------|---|----------------------------|--|-----|------------|--|
| <p><b>1</b> Press <b>TESTS</b> to display the <b>TESTS (Main Menu)</b> screen.</p> <p><i>If you are in IBASIC, press SHIFT, CANCEL before pressing TESTS.</i></p>   | <p><b>2</b> Position cursor at <b>Seqn Order of Tests</b> and select it.</p> <table border="1"> <tr> <td><b>Position</b></td> <td></td> </tr> <tr> <td></td> <td>Freq Channel Information</td> </tr> <tr> <td></td> <td>Parm Test Parameters</td> </tr> <tr> <td><b>Select</b></td> <td>Seqn Order of Tests</td> </tr> <tr> <td></td> <td>Spec Pass Fail Limits</td> </tr> <tr> <td></td> <td>Proc Save/Delete Procedure</td> </tr> </table> | <b>Position</b> |   |   | Freq Channel Information |               | Parm Test Parameters   | <b>Select</b> | Seqn Order of Tests |  | Spec Pass Fail Limits |   | Proc Save/Delete Procedure |  |     |            |  |
| <b>Position</b>  |  |                 |   |  |                          |               |  |               |                     |   |                       |   |                            |  |     |            |  |
|   | Freq Channel Information   |                 |   |  |                          |               |  |               |                     |   |                       |   |                            |  |     |            |  |
|  | Parm Test Parameters   |                 |   |  |                          |               |  |               |                     |   |                       |   |                            |  |     |            |  |
| <b>Select</b>  | Seqn Order of Tests  |                 |   |  |                          |               |  |               |                     |   |                       |   |                            |  |     |            |  |
|   | Spec Pass Fail Limits  |                 |   |  |                          |               |  |               |                     |   |                       |   |                            |  |     |            |  |
|  | Proc Save/Delete Procedure   |                 |   |  |                          |               |  |               |                     |   |                       |   |                            |  |     |            |  |
| <p>The Order of Tests screen is now present on your CRT.</p>   | <p><b>3</b> Position cursor at <b>Step #</b> field and select it.</p> <table border="1"> <tr> <td><b>Position</b></td> <td></td> </tr> <tr> <td></td> <td>Example</td> </tr> <tr> <td><b>Select</b></td> <td> <table border="1"> <tr> <td>"#"</td> <td>"TEST_#"</td> </tr> <tr> <td>↑</td> <td>"Test name"</td> </tr> </table> </td> </tr> <tr> <td></td> <td></td> </tr> </table>  | <b>Position</b> |   |  | Example                  | <b>Select</b> | <table border="1"> <tr> <td>"#"</td> <td>"TEST_#"</td> </tr> <tr> <td>↑</td> <td>"Test name"</td> </tr> </table> | "#"           | "TEST_#"            | ↑   | "Test name"           |  |                            |  |     |            |  |
| <b>Position</b>  |  |                 |   |  |                          |               |  |               |                     |   |                       |   |                            |  |     |            |  |
|    | Example  |                 |   |  |                          |               |  |               |                     |   |                       |   |                            |  |     |            |  |
| <b>Select</b>  | <table border="1"> <tr> <td>"#"</td> <td>"TEST_#"</td> </tr> <tr> <td>↑</td> <td>"Test name"</td> </tr> </table>   | "#"             | "TEST_#"  | ↑  | "Test name"              |               |  |               |                     |   |                       |   |                            |  |     |            |  |
| "#"  | "TEST_#"   |                 |   |  |                          |               |  |               |                     |   |                       |   |                            |  |     |            |  |
| ↑  | "Test name"  |                 |   |  |                          |               |  |               |                     |   |                       |   |                            |  |     |            |  |
|   |  |                 |   |  |                          |               |  |               |                     |   |                       |   |                            |  |     |            |  |
| <p><b>4</b> Rotate knob until <b>Step #</b> which precedes the insertion point of the new test you are adding is highlighted, then select it.</p> <table border="1"> <tr> <td><b>Rotate</b></td> <td></td> </tr> <tr> <td></td> <td></td> </tr> <tr> <td><b>Select</b></td> <td></td> </tr> <tr> <td></td> <td></td> </tr> </table> <p><i>For example, select step 7 if you want to insert the new test as step 8.</i></p> <table border="1"> <tr> <td>"7"</td> <td>"TEST_#"</td> </tr> <tr> <td></td> <td>"Test name"</td> </tr> <tr> <td>↻</td> <td></td> </tr> <tr> <td>"8"</td> <td>"New test"</td> </tr> </table> | <b>Rotate</b>  |                 |  |  | <b>Select</b>            |               |                               |               | "7"                 | "TEST_#"  |                       | "Test name"   | ↻                          |  | "8" | "New test" |  |
| <b>Rotate</b>  |  |                 |   |  |                          |               |  |               |                     |   |                       |   |                            |  |     |            |  |
|   |  |                 |   |  |                          |               |  |               |                     |   |                       |   |                            |  |     |            |  |
| <b>Select</b>  |  |                 |   |  |                          |               |  |               |                     |   |                       |   |                            |  |     |            |  |
|   |  |                 |   |  |                          |               |  |               |                     |   |                       |   |                            |  |     |            |  |
| "7"  | "TEST_#"   |                 |   |  |                          |               |  |               |                     |   |                       |   |                            |  |     |            |  |
|  | "Test name"  |                 |   |  |                          |               |  |               |                     |   |                       |   |                            |  |     |            |  |
| ↻  |  |                 |   |  |                          |               |  |               |                     |   |                       |   |                            |  |     |            |  |
| "8"  | "New test"   |                 |   |  |                          |               |  |               |                     |   |                       |   |                            |  |     |            |  |

SEQ1a

Continue on next page

|  |  |             |             |             |   |   |          |          |             |             |
|--|--|-------------|-------------|-------------|---|---|----------|----------|-------------|-------------|
| <p><b>5</b> Position cursor at <b>Insrt Stp</b> and select it.</p>   | <p><b>6</b> Position cursor back at <b>Step #</b> field and select it.</p>           |             |             |             |   |   |          |          |             |             |
| <p><b>Position</b></p>  <p><b>Select</b></p>   <table border="1" data-bbox="548 596 688 806"> <tr><td>Insrt Stp</td></tr> <tr><td>2 Delet Stp</td></tr> <tr><td>3 Print All</td></tr> <tr><td>4 Help</td></tr> <tr><td>5 Main Menu</td></tr> </table> | Insrt Stp  | 2 Delet Stp | 3 Print All | 4 Help      | 5 Main Menu   | <p><b>Position</b></p>  <p><b>Select</b></p>   <table border="1" data-bbox="967 638 1224 722"> <tr><td>"7"</td><td>"TEST_#"</td></tr> <tr><td></td><td>"Test name"</td></tr> </table> | "7"      | "TEST_#" |             | "Test name" |
| Insrt Stp  |  |             |             |             |   |   |          |          |             |             |
| 2 Delet Stp  |  |             |             |             |   |   |          |          |             |             |
| 3 Print All  |  |             |             |             |   |   |          |          |             |             |
| 4 Help   |  |             |             |             |   |   |          |          |             |             |
| 5 Main Menu  |  |             |             |             |   |   |          |          |             |             |
| "7"  | "TEST_#"   |             |             |             |   |   |          |          |             |             |
|  | "Test name"  |             |             |             |   |   |          |          |             |             |
| <p><b>7</b> Highlight <b>Step #</b> of the newly inserted test, then select it.</p>  | <p><b>8</b> Position cursor at <b>Test Name</b> field, then select it.</p>           |             |             |             |   |   |          |          |             |             |
| <p><b>Highlight</b></p>  <p><b>Select</b></p>   <table border="1" data-bbox="451 1016 721 1100"> <tr><td>"8"</td><td>"TEST_#"</td></tr> <tr><td></td><td>"Test name"</td></tr> </table>  | "8"  | "TEST_#"    |             | "Test name" | <p><b>Position</b></p>  <p><b>Select</b></p>   <table border="1" data-bbox="967 1016 1224 1100"> <tr><td>"8"</td><td>"TEST_#"</td></tr> <tr><td></td><td>"Test name"</td></tr> </table> | "8"   | "TEST_#" |          | "Test name" |             |
| "8"  | "TEST_#"   |             |             |             |   |   |          |          |             |             |
|  | "Test name"  |             |             |             |   |   |          |          |             |             |
| "8"  | "TEST_#"   |             |             |             |   |   |          |          |             |             |
|  | "Test name"  |             |             |             |   |   |          |          |             |             |
| <p><b>9</b> Rotate knob until desired <b>Test Name</b> appears, then select it.</p>  | <p><b>10</b> Press <b>TESTS</b> to return to the <b>TESTS (Main Menu)</b> screen</p> |             |             |             |   |   |          |          |             |             |
| <p><b>Rotate</b></p>  <p><b>Select</b></p>   <table border="1" data-bbox="451 1373 721 1457"> <tr><td>"#"</td><td>"TEST_#"</td></tr> <tr><td></td><td>"Test name"</td></tr> </table>  | "#"  | "TEST_#"    |             | "Test name" |   |   |          |          |             |             |
| "#"  | "TEST_#"   |             |             |             |   |   |          |          |             |             |
|  | "Test name"  |             |             |             |   |   |          |          |             |             |

SEQU2a

**NOTE:** The A11 Chans? field is not used by the HP 11807B Option 052 software.





## Changing Pass/Fail Limits

Pass/Fail limits define the values a measurement's result is compared against to determine if the UUT meets its specified standards. Default values are set in the test software. These default values may be changed to suit your particular requirements.

















The following describes how to change the pass/fail (upper and lower) limits. See ["Pass/Fail Limit \(Specification\) Descriptions" in chapter 7](#) for descriptions of each pass/fail limit. For information on saving customized pass/fail limits, see ["Saving a Test Procedure" on page 94](#).

### How to Change Pass/Fail Limits

|  |  |                 |  |  |                          |  |                      |  |                     |               |                       |  |                            |
|--|--|-----------------|--|--|--------------------------|--|----------------------|--|---------------------|---------------|-----------------------|--|----------------------------|
| <p><b>1</b> Press <b>TESTS</b> to display the <b>TESTS (Main Menu)</b> screen.</p> <p><i>IF you're in IBASIC, press SHIFT, CANCEL before pressing TESTS.</i></p>  | <p><b>2</b> Position cursor at <b>Spec Pass Fail Limits</b> and select it.</p> <table border="1"> <tr> <td><b>Position</b></td> <td></td> </tr> <tr> <td></td> <td>Freq Channel Information</td> </tr> <tr> <td></td> <td>Parm Test Parameters</td> </tr> <tr> <td></td> <td>Seqn Order of Tests</td> </tr> <tr> <td><b>Select</b></td> <td>Spec Pass Fail Limits</td> </tr> <tr> <td></td> <td>Proc Save/Delete Procedure</td> </tr> </table> | <b>Position</b> |  |  | Freq Channel Information |  | Parm Test Parameters |  | Seqn Order of Tests | <b>Select</b> | Spec Pass Fail Limits |  | Proc Save/Delete Procedure |
| <b>Position</b>  |  |                 |  |  |                          |  |                      |  |                     |               |                       |  |                            |
|  | Freq Channel Information   |                 |  |  |                          |  |                      |  |                     |               |                       |  |                            |
|  | Parm Test Parameters   |                 |  |  |                          |  |                      |  |                     |               |                       |  |                            |
|  | Seqn Order of Tests  |                 |  |  |                          |  |                      |  |                     |               |                       |  |                            |
| <b>Select</b>  | Spec Pass Fail Limits  |                 |  |  |                          |  |                      |  |                     |               |                       |  |                            |
|  | Proc Save/Delete Procedure   |                 |  |  |                          |  |                      |  |                     |               |                       |  |                            |
| <p>The Pass/Fail Limits screen is now present on your CRT.</p>   | <p><b>3</b> Position cursor at <b>Spec #</b> field and select it.</p> <p>(Disregard this number)</p>    |                 |  |  |                          |  |                      |  |                     |               |                       |  |                            |



SPEC1a

Continue on next page




|  |   |
|--|---|
| <p><b>4</b> Scroll to the desired <b>Spec #</b> and select it.</p>   | <p><b>5</b> Position cursor at <b>Lower limit</b> field and select it.</p>  |
| <p><b>Scroll</b><br/></p> <p><b>Select</b><br/></p> <p>(This <b>Spec #</b> is an example)</p> <p><b>6</b> FCC TX output p<br/>-1.000000 <b>1.</b></p> <p></p> | <p><b>Position</b><br/></p> <p><b>Select</b><br/></p> <p><b>6</b> FCC TX output p<br/>-1.000000 <b>1.</b></p> <p></p>              |
| <p><b>6</b> Use <b>DATA</b> keys to enter new value, then select it.</p>   | <p><b>7</b> Position cursor at <b>Upper Limit</b> field and select it.</p>  |
| <p><b>Enter</b><br/></p> <p><b>Select</b><br/></p> <p><b>6</b> FCC TX output p<br/>-0.500000 <b>1.</b></p> <p>(enter your desired value)</p>   | <p><b>Position</b><br/></p> <p><b>Select</b><br/></p> <p>C TX output power adjustme<br/>.500000 <b>1.000000</b> dB</p> <p></p> |
| <p><b>8</b> Use <b>DATA</b> keys to enter new value, then select it.</p>   | <p><b>9</b> Position cursor at <b>Check</b> field and select it.</p>  |
| <p><b>Enter</b><br/></p> <p><b>Select</b><br/></p> <p>C TX output power adjustme<br/>.500000 <b>0.500000</b> dB</p> <p>(enter your desired value)</p>  | <p><b>Position</b><br/></p> <p><b>Select</b><br/></p> <p><b>Both</b></p> <p></p>   |

SPEC2a

Continue on next page

|  |  |
|--|--|
| <b>10</b> <i>Position cursor for how limits should apply and select it.</i>                          |  |
| <b>Position</b><br> | <b>Choices :</b><br>Upper<br>Lower<br><input checked="" type="checkbox"/> Both<br>None |
| <b>Select</b><br>   |  |

SPEC3a








|  |   |
|--|---|
| <b>11</b> <i>Press TESTS to return to the TESTS (Main Menu) screen.</i>                              |   |
| <b>Position</b><br> |  |
| <b>Select</b><br>   |   |

## Changing the Test Parameters

The software uses parameters to optimize the test environment and conditions for your testing situation. Many of the test parameters are determined by examining your test needs. The software comes with default settings for test parameters. Review the defaults for your particular needs. See ["Test Descriptions" in chapter 7](#) for descriptions of each test parameter. For information on saving customized test parameters, see ["Saving a Test Procedure" on page 94](#).





















The following describes how you can change test parameters through the Test Parameter screen to optimize your testing conditions.

### How to Change the Test Environment and Conditions

|  |  |  |  |             |                     |             |                 |      |                  |      |                       |      |                       |  |  |
|--|--|--|--|-------------|---------------------|-------------|-----------------|------|------------------|------|-----------------------|------|-----------------------|--|--|
| <p><b>1</b> Press <b>TESTS</b> to display the <b>TESTS (Main Menu)</b> screen.</p>   | <p><b>2</b> Position cursor at <b>Parm</b> Test Parameters and select it.</p>  |  |  |             |                     |             |                 |      |                  |      |                       |      |                       |  |  |
| <p><i>If you are in IBASIC, press SHIFT, CANCEL before pressing TESTS.</i></p>  | <table border="1"><tr><td data-bbox="795 970 922 1081"><p><b>Position</b></p></td><td data-bbox="950 1008 1274 1165"><table><tr><td>Freq</td><td>Channel Information</td></tr><tr><td><b>Parm</b></td><td>Test Parameters</td></tr><tr><td>Seqn</td><td>Order of Tests</td></tr><tr><td>Spec</td><td>Pass Fail Limits</td></tr><tr><td>Proc</td><td>Save/Delete Procedure</td></tr></table></td></tr><tr><td data-bbox="795 1081 922 1213"><p><b>Select</b></p></td><td></td></tr></table> | <p><b>Position</b></p>  | <table><tr><td>Freq</td><td>Channel Information</td></tr><tr><td><b>Parm</b></td><td>Test Parameters</td></tr><tr><td>Seqn</td><td>Order of Tests</td></tr><tr><td>Spec</td><td>Pass Fail Limits</td></tr><tr><td>Proc</td><td>Save/Delete Procedure</td></tr></table> | Freq        | Channel Information | <b>Parm</b> | Test Parameters | Seqn | Order of Tests   | Spec | Pass Fail Limits      | Proc | Save/Delete Procedure | <p><b>Select</b></p>  |  |
| <p><b>Position</b></p>    | <table><tr><td>Freq</td><td>Channel Information</td></tr><tr><td><b>Parm</b></td><td>Test Parameters</td></tr><tr><td>Seqn</td><td>Order of Tests</td></tr><tr><td>Spec</td><td>Pass Fail Limits</td></tr><tr><td>Proc</td><td>Save/Delete Procedure</td></tr></table>   | Freq   | Channel Information  | <b>Parm</b> | Test Parameters     | Seqn        | Order of Tests  | Spec | Pass Fail Limits | Proc | Save/Delete Procedure |      |                       |  |  |
| Freq   | Channel Information  |  |  |             |                     |             |                 |      |                  |      |                       |      |                       |  |  |
| <b>Parm</b>  | Test Parameters  |  |  |             |                     |             |                 |      |                  |      |                       |      |                       |  |  |
| Seqn   | Order of Tests   |  |  |             |                     |             |                 |      |                  |      |                       |      |                       |  |  |
| Spec   | Pass Fail Limits   |  |  |             |                     |             |                 |      |                  |      |                       |      |                       |  |  |
| Proc   | Save/Delete Procedure  |  |  |             |                     |             |                 |      |                  |      |                       |      |                       |  |  |
| <p><b>Select</b></p>    |  |  |  |             |                     |             |                 |      |                  |      |                       |      |                       |  |  |

PARM1a

Continue on next page

|  |   |
|--|---|
| <p>The Tests Parameters screen is now present on your CRT.</p>   | <p><b>3</b> Position cursor at <b>Parm #</b> field and select it.</p> <p><b>Position</b><br/> <br/> <b>Select</b><br/> </p> <p>(Entries on your display may be different)</p> <p> RT audio test to<br/> </p> <p></p> |
| <p><b>4</b> Scroll to <b>Parm #</b> to be changed and select it.</p> <p><b>Scroll</b><br/> <br/> <b>Select</b><br/> </p> <p>(This parameter number and description are examples)</p> <p> TX cable loss<br/> </p>                                   | <p><b>5</b> Position cursor at <b>Value</b> field and select it.</p> <p><b>Position</b><br/> <br/> <b>Select</b><br/> </p> <p> TX cable loss<br/> <br/> </p>   |
| <p><b>6</b> Use <b>DATA</b> keys to enter new value, then select it.</p> <p><b>Enter</b><br/> <br/> <b>Select</b><br/> </p> <p> TX cable loss<br/> <br/> </p> | <p><b>7</b> Press <b>TESTS</b> to return to the <b>TESTS (Main Menu)</b> screen.</p> <p></p>   |

PARM2a
























## Saving a Test Procedure

A Test Procedure is a collection of channel information, test parameters, testing order, and pass/fail limits saved in a file that customizes the test software to a specific application. You may save the file to a memory card or disk.

When you save a procedure you will be saving channel information, test parameters, pass/fail limits, and testing order, plus a library that contains the names of all test parameters, pass/fail limits, and tests that are resident in the software. The library file comes from the software and cannot be modified. The library file will be automatically saved on the card or disk that is being used to store the new test procedure.

The following example shows how to save a new procedure to a memory card. For more information concerning procedures, see "[Procedures](#)" in [chapter 8](#).

## How to Save a Test Procedure


|   |   |   |  |                                 |  |  |   |               |   |                            |  |                               |                              |   |   |  |
|---|---|---|--|---------------------------------|--|--|---|---------------|---|----------------------------|--|-------------------------------|------------------------------|---|---|--|
| <p><b>1</b> Press <b>TESTS</b> to display the <b>TESTS (Main Menu)</b> screen.</p>  | <p><b>2</b> Position cursor at <b>Proc Save/ Delete Pro...</b> and select it.</p>   |   |  |                                 |  |  |   |               |   |                            |  |                               |                              |   |   |  |
| <p>If you are in <b>IBASIC</b>, press <b>SHIFT, CANCEL</b> before pressing <b>TESTS</b>.</p>   | <table border="1"> <tr> <td><b>Position</b></td> <td></td> <td><b>Freq</b> Channel Information</td> </tr> <tr> <td></td> <td></td> <td><b>Parm</b> Test Parameters</td> </tr> <tr> <td></td> <td></td> <td><b>Seqn</b> Order of Tests</td> </tr> <tr> <td></td> <td></td> <td><b>Spec</b> Pass Fail Limits</td> </tr> <tr> <td><b>Select</b></td> <td></td> <td><b>Proc</b> Save/Delete Procedure</td> </tr> </table> | <b>Position</b>   |   | <b>Freq</b> Channel Information |  |  | <b>Parm</b> Test Parameters   |               |   | <b>Seqn</b> Order of Tests |  |                               | <b>Spec</b> Pass Fail Limits | <b>Select</b>   |  | <b>Proc</b> Save/Delete Procedure  |
| <b>Position</b>   |    | <b>Freq</b> Channel Information   |  |                                 |  |  |   |               |   |                            |  |                               |                              |   |   |  |
|   |   | <b>Parm</b> Test Parameters   |  |                                 |  |  |   |               |   |                            |  |                               |                              |   |   |  |
|   |   | <b>Seqn</b> Order of Tests  |  |                                 |  |  |   |               |   |                            |  |                               |                              |   |   |  |
|   |   | <b>Spec</b> Pass Fail Limits  |  |                                 |  |  |   |               |   |                            |  |                               |                              |   |   |  |
| <b>Select</b>   |    | <b>Proc</b> Save/Delete Procedure   |  |                                 |  |  |   |               |   |                            |  |                               |                              |   |   |  |
| <p>The <b>Save/Delete Procedure</b> screen is now present on your CRT.</p>  | <p><b>3</b> Position cursor at <b>Select Procedure Loc...</b> and select it.</p> <table border="1"> <tr> <td><b>Position</b></td> <td></td> <td>Select Procedure Location:</td> </tr> <tr> <td></td> <td></td> <td></td> </tr> <tr> <td><b>Select</b></td> <td></td> <td></td> </tr> </table>                                 | <b>Position</b>   |  | Select Procedure Location:      |  |  |  | <b>Select</b> |  |                            |  |                               |                              |   |   |  |
| <b>Position</b>   |   | Select Procedure Location:  |  |                                 |  |  |   |               |   |                            |  |                               |                              |   |   |  |
|   |   |  |  |                                 |  |  |   |               |   |                            |  |                               |                              |   |   |  |
| <b>Select</b>   |    |   |  |                                 |  |  |   |               |   |                            |  |                               |                              |   |   |  |
| <p><b>4</b> Position cursor at <b>Card</b> and select it.</p>   | <p><b>5</b> Insert an initialized <b>SRAM</b> memory card.</p>  |   |  |                                 |  |  |   |               |   |                            |  |                               |                              |   |   |  |
| <table border="1"> <tr> <td><b>Position</b></td> <td></td> <td>Choices :</td> </tr> <tr> <td></td> <td></td> <td><input checked="" type="checkbox"/> Card</td> </tr> <tr> <td></td> <td></td> <td><input type="checkbox"/> RAM</td> </tr> <tr> <td></td> <td></td> <td><input type="checkbox"/> Disk</td> </tr> <tr> <td><b>Select</b></td> <td></td> <td></td> </tr> </table> <p>(You can also save procedures to an internal RAM disk or external disk drive. See chapter 8 - Disks.)</p> | <b>Position</b>   |    | Choices :  |                                 |  | <input checked="" type="checkbox"/> Card |   |               | <input type="checkbox"/> RAM  |                            |  | <input type="checkbox"/> Disk | <b>Select</b>                |  |   |  <p>(For detailed memory card initialization instructions. see chapter 8 - Memory Cards.)</p> |
| <b>Position</b>   |    | Choices :   |  |                                 |  |  |   |               |   |                            |  |                               |                              |   |   |  |
|   |   | <input checked="" type="checkbox"/> Card  |  |                                 |  |  |   |               |   |                            |  |                               |                              |   |   |  |
|   |   | <input type="checkbox"/> RAM  |  |                                 |  |  |   |               |   |                            |  |                               |                              |   |   |  |
|   |   | <input type="checkbox"/> Disk   |  |                                 |  |  |   |               |   |                            |  |                               |                              |   |   |  |
| <b>Select</b>   |    |   |  |                                 |  |  |   |               |   |                            |  |                               |                              |   |   |  |

PROCMA1a


Continue on next page

**6** *Position cursor at **Enter Procedure File...** and select it.*



**Position**



**Select**




Enter Procedure Filename:





**7** *Select characters to name the procedure, then select **Done**.*

**Position**





**Select**




Choices :

- Done
- Position
- Over/Ins
- Delete
- Del End
- Bk space
- A
- B
- C





**8** *Position cursor at **Enter Description for ...** and select it.*



**Position**



**Select**




Enter Description for r





**9** *Select characters for the description, then select **Done**.*

**Position**





**Select**




Choices :

- Done
- Position
- Over/Ins
- Delete
- Del End
- Bk space
- A
- B
- C





**10** *Position cursor at **Procedure Library:** and select **Current**.*

**Position**





**Select**



Procedure Library:

Current / [NO LIB]





*(The underline indicates which option is selected. Pressing knob changes the selection.)*

**11** *Position cursor at **Code Location:** and select it.*




Code Location:




Card




**Continue on next page**



|  |   |
|--|---|
| <b>12</b> Position cursor at <b>Card</b> and select it.  |   |
| <b>Position</b><br> |  |
| <b>Select</b><br>   |   |

|  |   |
|--|---|
| <b>13</b> Position cursor at <b>Save Proc</b> and select it.   |   |
| <b>Position</b><br> |  |
| <b>Select</b><br>   |   |

**14** Press **TESTS** to return to the **TESTS (Main Tests)** screen.



**15** To run the saved procedure, follow the instructions below.

- 1) Insert the RAM card with your saved procedure.
- 2) On the **TESTS (Main Menu)** screen, a) position cursor and select **Select Procedure Location:**, then select **Card**, b) position cursor and select **Select Procedure Filename:**, then select your saved file name.)
- 3) Remove your RAM card and insert the original HP 11807B ROM memory card.
- 4) Press **Run Test** .

The original card contains the full program needed to run your procedure.

PROCMA3a

## Changing Test Execution Conditions

**Test Execution Conditions** define where and when test output occurs. You may decide to:

- Display output on CRT only, or display on CRT and print hardcopy (**Output Results To**).

---

**NOTE:**

If printing test results is desired, after selecting **Printer**, additional steps are necessary to connect and configure the printer. See "**Printing**," in chapter 8, on page 189.

- Display (or print) only measurements that fail, or display (or print) all measurements that pass or fail (**Output Results For**).
- Enter a title for an output heading for the displayed or printed results (**Output Heading**).
- Stop testing when a measurement fails or continue through all of the tests without stopping (**If Unit-Under-Test-Fails**).
- Pause between each measurement, or run through entire test (**Test Procedure Run Mode**).
- Start the program automatically when the Test System is powered on. (**Autostart Test Procedure on Power-up**)


**Test Execution Conditions** is accessed from the **SETUP TEST SET:** list. To change a default setting, position the cursor to the desired field. Pressing the knob ("selecting") will toggle the underlined selection.

**Test Execution Conditions** settings are not retained after a power-down/power-up cycle, and will return to their default settings.



## How to Change Test Execution Conditions

**1** Press **TESTS** to display the **TESTS (Main Menu)** screen.

If you are in IBASIC, press **SHIFT, CANCEL** before pressing **TESTS**.



**2** Position cursor at **Exec.** **Execution Cond** and select it.

|                 |   |                              |
|-----------------|---|------------------------------|
| <b>Position</b> |  | <b>Exec</b> Execution Cond   |
|                 |   | <b>Cnfg</b> External Devices |
|                 |   | <b>Print</b> Printer Setup   |
| <b>Select</b>   |  | <b>IBASIC</b> IBASIC Cntrl   |

**3**

Select **Printer** to output test procedure results to the CRT and a printer.

Select **Failures** to display only the CRT and printer measurements that fail.

Select **Stop** to stop a Test Procedure when a failure occurs.

Select **Single Step** to stop a Test Procedure at the end of each measurement.

TESTS (Execution Conditions)

|                                       |                               |
|---------------------------------------|-------------------------------|
| Output Results To:                    | <b>Print/Printer</b>          |
| Output Results For:                   | <b>All/Failures</b>           |
| Output Heading:                       | <b>[REDACTED]</b>             |
| If Unit-Under-Test Fails:             |                               |
| Test Procedure Run Mode:              | <b>Continuous/Single Step</b> |
| Autostart Test Procedure on Power-Up: | <b>Off/On</b>                 |

- 1 Run Test
- 2 Continue
- 4 Help
- 5 Main Menu

To Screen

**RF GEN**

**RF ANL**

**AF ANL**

**SCOPE**

**SPEC ANL**

**ENCODER**

**DECODER**

**RADIO INT**

More

TESTEX1a

## Printing and Saving Test Results

Printing and saving test results are features of the software which require additional equipment and configuration. See "Printing," in chapter 8, on page 189 for detailed descriptions and instructions for these features.



---

**Using the Software/HP 8921A FW Rev.  
Below A.14.00**

## Firmware Enhancements

---

**NOTE:**

The firmware revision A.14.00 in the HP 8921A,D had several enhancements. This chapter applies to users with:

- **HP 8921A test sets with firmware revision below A.14.00**

The test set's firmware revision is displayed on the top right corner of the configuration screen.

- Press SHIFT CONFIG to display the configuration screen and read the firmware revision.

If you have an HP 8921A with firmware revision above A.14.00, refer to [chapter 5, "Using the Software with FW Above Rev. A.14.00," on page 75](#). Contact Hewlett-Packard at 1-800-922-8920 for details on upgrading your firmware if desired.

---

---

**Test Set or System is Defined As:**

- HP 8921A, Option 500, Dual-Mode Cellular Test System
- HP 8921D, Dual-Mode Cell Site Test System


## **Introduction**

The HP 11807B software can be run on the factory default settings or customized to your individual needs and the specific requirements.

This chapter provides detailed information on how to run, and customize the software.



## Running Tests Overview



MANVIEW








## Before Running Tests

- You must do “Getting Started” before running tests on a model 883 or Microcell transceiver. “Getting Started” stores your local control (FX) file on an SRAM (Static Random Access Memory) memory card so that it may be downloaded to the transceiver before tests are run.
- Select a test procedure from the HP 11807B Option 052 software card. The software is shipped with the following preprogrammed test procedures on the program card.
  - ERIC\_883** is used for Model 883 testing.
  - ERIC\_MC** is used for Microcell testing.
  - LAPTOP\_EM** runs **TEST\_01 - GN Laptop Emulator**.
  - CARD\_INIT** runs **TTEST\_02 - Memory Card Initialisation**.
  - FX-XFER** runs **TEST\_03 - Local Control File Transfer**.
  - GET\_START** runs **TEST\_10 - TX Power Adjustment** used in “Getting Started”.
  - D\_C\_XFER** runs **TEST\_08 - GN Data Collection File Transfer**.
  - CAB\_LOSS** runs **TEST\_07 - GN Measure Cable Loss**.
  - ANT\_SWEEP** runs **TEST\_04 - GN Swept Return Loss**.
  - CAB\_FLT** runs **TEST\_06 - GN Cable Fault Versus Distance**.
- Before you begin testing, you should have made the appropriate hardware connections. [See chapter 4, "Making Connections"](#) if you have not done so already.

## Running Tests

- When tests begin to run, they are executed in the order in which they were entered into the Test Procedure.
- Pressing CANCEL will pause the current test (press **Continue** to continue the test).
- When the **Run Test** softkey is pressed, the test set will check to see if the program is already resident in RAM memory. If it is not, it will be loaded from the memory card, a process which takes about two minutes. The contents of the HP 8921A RAM memory are retained even while the instrument is powered down.
- After all testing is complete on a given transceiver, you must exit local control so that the transceiver can be put back into service. Run TEST\_01 Laptop Emulator as your last test and select **EXIT LOCAL CONTROL**.

## Selecting a Test Procedure

|   |  |
|---|--|
| <p><b>1</b> Insert Opt. 052 card, or card containing desired procedure.</p>    | <p><b>2</b> Press <b>TESTS</b> to display <b>TESTS</b> screen.</p> <p>If you are running <b>IBASIC</b>, press <b>SHIFT, CANCEL</b> before pressing <b>TESTS</b>.</p>    |
| <p><b>3</b> Position cursor at <b>Procedure</b> and select it.</p> <p><b>Position</b></p>  <p>Procedure: Location</p> <p>XXXX_XXXX : Card</p> <p><b>Select</b></p>    | <p><b>4</b> Position cursor at desired procedure and select it.</p> <p><b>Position</b></p>  <p><b>Choices :</b></p> <ul style="list-style-type: none"> <li>UUUU_UU</li> <li>VVVV_VVV</li> <li>WWW_WW</li> <li>XXXX_XXX</li> <li>YYYY_YYY</li> <li>ZZZ_ZZZ</li> </ul> <p><b>Select</b></p>  |
| <p><b>5</b> To run test, position cursor at <b>Run Test</b> and select it. To customize the procedure, refer to <b>Customizing the Software</b> in this chapter.</p>  <ul style="list-style-type: none"> <li><b>1</b> Run Test</li> <li>2 Continue</li> <li>3 Edit Seqn</li> <li>4 Edit Freq</li> <li>5 Edit Spec</li> </ul> |  |

PROC1

The usual sequence for testing an operational cell site is as follows:

1. Use the Ericsson FIOL program running on a personal computer (PC) to contact the Mobile Telephone Switching Office (MTSO) in order to “block” a set of transceivers to be tested. It is convenient to block a set of four which are connected to the same star junction.
2. Run the **ERICCS\_883** or **ERICCS\_MC** procedure on each transceiver as appropriate. Model 883 and Microcell transceivers can be tested without having anything loaded from the MTSO or PC because they receive a download of the local control (FX) file from the memory card automatically (if required) at the beginning of each test procedure.
3. Run the **LAPTOP\_EM** procedure to key up and display the spectrum of each transceiver for combiner tuning.
4. Continue to run the **LAPTOP\_EM** procedure to de-key each transmitter and exit local control on each transceiver.
5. Use the FIOL program to request the MTSO to “unblock” the transceivers which have just been tested.
6. Repeat steps 1 through 5 for a new set of transceivers.
  - The PC can remain connected to the ERI panel (or telephone line) for the duration of testing. There it can be used to block transceivers and to query the MTSO for transceiver channel assignments so that each transceiver can be tested on the channel it will be operating on.
  - Test results can be printed, stored on a memory card or transferred to a PC. See **"Printing" in chapter 8, "Reference (Alphabetical)" on page 189.** and **"Data Collection (Saving and Retrieving Test Results)" on page 164 in chapter 8.**
  - Individual transceivers can be tested on the workbench, in which case only step 2 above applies.

## Customizing the Software

The HP 11807B software may need some customizing before it performs in a way that is specific to your testing needs. Because of the diversity of individual testing needs, the HP 11807B software has been designed so that changes may be easily made from the HP 8921A/D front panel. You may store these changes on an SRAM card so that you may skip these steps in the future. See "[Saving a Test Procedure Using the Procedure Manager](#)" on page 121.

You may customize your software at any time. Because your needs change, the software allows changes to its default settings when you need to make them and in any order that you choose. For example, tests may be inserted or deleted, and later after running the tests you can change the pass/fail limits or decide to test different channels.

Most testing customization is accomplished through the HP 8921A/D Test Function screens. These Test Function screens are accessed from the main **TESTS** screen as shown in the following figure. All Test Functions are explained in this chapter by function.

- Decide which tests you need to run (**Edit Sequence**).
  - You may want to run all, some, or just one of the tests.
- Change the pass/fail limits for specific measurements (**Edit Specifications**)
  - You may want the pass/fail limits to have tighter or looser specifications than the default settings.
- Change the test environment and conditions (**Edit Parameters**).
  - Enter specific information about radio equipment and/or environment.
- Save any or all of the above customized changes (to an SRAM card)
- Select options (**Test Execution Conditions**).
  - Print test results.
  - Stop after each test, stop on failure or always continue.
  - Display all test results or only those that fail.

---


**NOTE:**

Edit Configuration (Edit Cnfg), Edit Frequency (Edit Freq) and IBASIC will not be explained in this customizing section.

- Edit Configuration (Edit Cnfg) is used when setting up printers and external disk drives which is explained in "**Disks**" on page 173 in chapter 8 and "**Printing**" on page 189 in chapter 8.
  - Edit Frequency (Edit Freq) is not used by the HP 11807B Option 052 software.
  - IBASIC is used when writing your own programs and is not explained in this manual. If you need to write your own IBASIC programs you may acquire the *Instrument BASIC Handbook*, HP part number E2083-90000.
-

## Beginning Software Customization

All software customization begins by accessing the TESTS screen first and then selecting the **Test Function** which will open the **Choices** menu. To access the TESTS screen, press TESTS on the front panel of the test set.



















## Changing a Sequence of Tests (Edit Sequence)

You may define a test sequence to include all, some, or just one of the tests available. When the first test is finished, the next will run. The test sequence will remain in the Test Systems' battery backed-up memory until another test sequence is loaded or set up. For information on saving a customized test sequence, see ["Saving a Test Procedure Using the Procedure Manager" on page 121](#).

Creation of a test sequence is accomplished by inserting or deleting tests from the list of tests that come with the HP 11807B software package. See ["Test Descriptions" on page 128 in chapter 7](#), for test descriptions.



















The following describes how to create a new test sequence.

### How to Change a Sequence of Tests

|   |  |
|---|--|
| <p><b>1</b> Press <b>TESTS</b> to display the <b>TESTS</b> screen.</p>  | <p><b>2</b> Position cursor at <b>Test Function</b> and select it.</p>   |
| <p>If you are in <b>IBASIC</b>, press <b>SHIFT, CANCEL</b> before pressing <b>TESTS</b>.</p>   | <p><b>Position</b></p>  <p><b>Select</b></p>  <p>Test Function</p>   |
| <p><b>3</b> Position cursor at <b>Edit Seqn</b> and select it.</p>  | <p><b>4</b> Position cursor at <b>Step #</b> field and select it.</p>  |
| <p><b>Position</b></p>  <p><b>Select</b></p>  <p>Choices :</p> <ul style="list-style-type: none"> <li>█ Edit Seqn</li> <li>█ Edit Freq</li> <li>█ Edit Spec</li> <li>█ Edit Parm</li> <li>█ Edit Cnfg</li> <li>█ Proc Mngr</li> <li>█ IBASIC</li> </ul>  | <p><b>Position</b></p>  <p><b>Select</b></p>  <p>Example</p> <p>"#"</p>  <p>"TEST_#"</p> <p>"Test name"</p>  |
| <p><b>5</b> By rotating knob, highlight the <b>Step #</b> which precedes the insertion point of the new test that you are adding, then select it.</p>   |  |
| <p><b>Position</b></p>  <p><b>Select</b></p>    | <p>For example, select step 7 if you want to insert the new test as step 8.</p> <p>"7"</p>  <p>"8"</p> <p>"TEST_#"</p> <p>"Test name"</p> <p>"New test"</p>   |

SEQ1

Continue on next page

|  |  |
|--|--|
| <p><b>6</b> Position cursor at <b>Insrt Stp</b> and select it.</p>   | <p><b>7</b> Position cursor back at <b>Step #</b> field and select it.</p>   |
| <p><b>Position</b></p>  <p><b>Select</b></p>    | <p><b>Position</b></p>  <p><b>Select</b></p>    |
| <p><b>8</b> Highlight <b>Step #</b> of the newly inserted test, then select it.</p>  | <p><b>9</b> Position cursor at <b>Test name</b> field and select it.</p>   |
| <p><b>Position</b></p>  <p><b>Select</b></p>  <p>This is the test that you selected at step 5.</p>  | <p><b>Position</b></p>  <p><b>Select</b></p>    |
| <p><b>10</b> Rotate knob until desired <b>Test Name</b> appears, then select it</p>  | <p><b>11</b> Position cursor at <b>All Chans?</b> field and select <b>Yes</b> or <b>No</b>.</p>  |
| <p><b>Rotate</b></p>  <p><b>Select</b></p>    | <p><b>Position</b></p>  <p><b>Select</b></p>   <p>(Press the knob to change the selection.)</p> |

5EQ2

Continue on next page










**NOTE:** The **A11 Chans?** field is not used by the HP 11807B Option 052 software.

## Changing Pass/Fail Limits (Edit Specifications)

Specifications are values that set pass/fail limits for tests. Default values are available in the test software. These default values may be changed to suit your particular requirements.

















The following describes how to change the pass/fail (upper and lower) limits in the HP 8921A/D “Edit Specification” screen. See ["Pass/Fail Limit \(Specification\) Descriptions" on page 155 in chapter 7](#) for descriptions and default values for each specification. For information on saving customized specifications, see ["Saving a Test Procedure Using the Procedure Manager" on page 121 in chapter 6](#).

### How to Change Pass/Fail Limits

|   |  |
|---|--|
| <p><b>1</b> Press <b>TESTS</b> to display the <b>TESTS</b> screen.</p>  | <p><b>2</b> Position cursor at <b>Test Function</b> and select it.</p>   |
| <p><i>If you're in IBASIC, press <b>SHIFT, CANCEL</b> before pressing <b>TESTS</b>.</i></p>    | <p><b>Position</b></p>  <p><b>Select</b></p>  <p>Test Function</p>              |
| <p><b>3</b> Position cursor at <b>Edit Spec</b> and select it.</p>  | <p><b>4</b> Position cursor at <b>Spec #</b> field and select it.</p>  |
| <p><b>Position</b></p>  <p><b>Select</b></p>  <p>Choices :</p> <ul style="list-style-type: none"> <li>Edit Seqn</li> <li>Edit Freq</li> <li>█ Edit Spec</li> <li>Edit Parm</li> <li>Edit Cnfg</li> <li>Proc Mngr</li> <li>IBASIC</li> </ul> | <p><b>Position</b></p>  <p><b>Select</b></p>  <p>(Disregard this number)</p>  |







SPEC1

Continue on next page

|   |   |
|---|---|
| <p><b>5</b> Scroll to the desired <b>Spec #</b> and select it.</p>  | <p><b>6</b> Position cursor at <b>Lower limit</b> field and select it.</p>  |
| <p><b>Position</b></p>  <p>(This <b>Spec #</b> is an example)</p> <p><b>Select</b></p>  <p>6 FCC TX output p<br/>-1.000000 1.</p>  | <p><b>Position</b></p>  <p>6 FCC TX output p<br/>-1.000000 1.</p> <p><b>Select</b></p>                       |
| <p><b>7</b> Use <b>DATA</b> keys to enter new value, then select it.</p>  | <p><b>8</b> Position cursor at <b>Upper Limit</b> field and select it.</p>  |
| <p><b>Position</b></p>  <p>6 FCC TX output p<br/>-0.500000 1.</p> <p><b>Select</b></p>  <p>(enter your desired value)</p>   | <p><b>Position</b></p>  <p>C TX output power adjustme<br/>.500000 1.000000 dB</p> <p><b>Select</b></p>   |
| <p><b>9</b> Use <b>DATA</b> keys to enter new value, then select it.</p>  | <p><b>10</b> Position cursor at <b>Check field</b> and select it.</p>   |
| <p><b>Position</b></p>  <p>C TX output power adjustme<br/>.500000 0.500000 dB</p> <p><b>Select</b></p>  <p>(enter your desired value)</p>   | <p><b>Position</b></p>  <p>Both</p> <p><b>Select</b></p>     |

SPEC2

Continue on next page











|  |  |
|--|--|
| <b>11</b> <i>Position cursor for how limits should apply and select it.</i>                          |  |
| <b>Position</b><br> | <b>Choices :</b><br>Upper<br>Lower<br><input checked="" type="checkbox"/> Both<br>None |
| <b>Select</b><br>   |       |
| <small>SPEC3</small>   |  |
| <b>12</b> <i>Press TESTS to return to the TESTS screen.</i>  |  |
| <b>Position</b><br> |     |
| <b>Select</b><br>   |  |

## Changing the Test Environment and Conditions (Edit Parameters)

The software uses parameters to optimize the test environment and conditions for your testing situation. Many of the parameters are determined by examining your test needs. Other parameters are determined by performing measurements to calibrate items in your system. Examples of parameters include cable losses, rated system deviation, and what audio test tone frequency your system requires. The HP 11807B software comes with default settings for parameters. The defaults should be reviewed for your particular needs. See "[Parameter Descriptions](#)" on [page 149 in chapter 7](#) descriptions and default values for each parameter. For information on saving customized parameters, see "[Saving a Test Procedure Using the Procedure Manager](#)" on [page 121](#).











The following describes how you can change parameters through the Edit Parameter screen to optimize your testing conditions.

### How to Change the Test Environment and Conditions

|  |  |  |   |  |  |
|--|--|--|---|--|--|
| <b>1</b> Press <b>TESTS</b> to display the <b>TESTS</b> screen.  | <b>2</b> Position cursor at <b>Test Function</b> and select it.  |  |   |  |  |
| <p>If you are in <b>IBASIC</b>, press <b>SHIFT, CANCEL</b> before pressing <b>TESTS</b>.</p>  | <table border="1"><tr><td data-bbox="850 1113 982 1228"><b>Position</b><br/></td><td data-bbox="985 1113 1346 1228"><b>Test Function</b><br/></td></tr><tr><td data-bbox="850 1232 982 1358"><b>Select</b><br/></td><td data-bbox="985 1232 1346 1358"></td></tr></table> | <b>Position</b><br> | <b>Test Function</b><br> | <b>Select</b><br> |  |
| <b>Position</b><br>   | <b>Test Function</b><br>  |  |   |  |  |
| <b>Select</b><br>   |  |  |   |  |  |

PARM1

Continue on next page

|   |  |
|---|--|
| <p><b>3</b> Position cursor at <b>Edit Parm</b> and select it.</p> <p><b>Position</b><br/> <br/> <b>Select</b><br/> </p> <p>Choices :<br/>         Edit Seqn<br/>         Edit Freq<br/>         Edit Spec<br/>         Edit Parm<br/>         Edit Cnfg<br/>         Proc Mngr<br/>         IBASIC</p> | <p><b>4</b> Position cursor at <b>Parm #</b> field and select it.</p> <p><b>Position</b><br/> <br/> <b>Select</b><br/> </p> <p>(Entries on your display may be different)</p> <p>1 RT audio test to<br/>         0.00000</p> |
| <p><b>5</b> Scroll to <b>Parm #</b> to be changed and select it</p> <p><b>Position</b><br/> <br/> <b>Select</b><br/> </p> <p>(This parameter number and description are examples)</p> <p>15 TX cable loss</p>  | <p><b>6</b> Position cursor at <b>Value</b> field and select it.</p> <p><b>Position</b><br/> <br/> <b>Select</b><br/> </p> <p>15 TX cable loss<br/>         0.000000</p>  |
| <p><b>7</b> Use <b>DATA</b> keys to enter new value, and select it.</p> <p><b>Position</b><br/> <br/> <b>Select</b><br/> </p> <p>15 TX cable loss<br/>         1.000000</p>   | <p><b>8</b> Press <b>TESTS</b> to return to the <b>TESTS</b> screen.</p> <p>TE</p>   |

PAPM2

















## **Saving a Test Procedure Using the Procedure Manager**

A test procedure is a collection of pass/fail limits (specifications), the test environment and conditions (parameters), and a TEST sequence, saved in a file that customizes the test software to a specific application. You may save the file to a memory card or disk.

When you save a procedure you will be saving parameters, specifications, and a test sequence, plus a library that contains the names of all parameters, specifications, and tests that are resident in the HP 11807B software. The library file comes from the HP 11807B software and cannot be modified. The library file will be automatically saved on the card or disk that is being used to store the new test procedure.

The following example shows how to save a new procedure to a memory card. For more information concerning procedures, see ["Procedures" on page 195 in chapter 8.](#)

## How to Save a Test Procedure

|   |  |
|---|--|
| <p><b>1</b> Press <b>TESTS</b> to display the <b>TESTS</b> screen.</p>  | <p><b>2</b> Position cursor at <b>Test Function</b> and select it.</p>   |
| <p>If you are running <b>IBASIC</b>, press <b>SHIFT, CANCEL</b> before pressing <b>TESTS</b>.</p>    | <p><b>Position</b></p>  <p><b>Select</b></p>       |
| <p><b>3</b> Position cursor at <b>Proc Mngr</b> and select it.</p>  | <p><b>4</b> Position cursor at <b>Procedure</b> field and select it.</p>   |
| <p><b>Position</b></p>  <p><b>Select</b></p>     | <p><b>Position</b></p>  <p><b>Select</b></p>   |
| <p><b>5</b> Select characters to name the <b>Procedure</b>, then select <b>Done</b>.</p>  | <p><b>6</b> Insert an initialized <b>SRAM</b> memory card.</p>   |
| <p><b>Position</b></p>  <p><b>Select</b></p>   |  <p>(For detailed memory card initialization instructions see Chapter 8 -Memory Cards.)</p>   |

PROCMA11

Continue on next page

**7** Position cursor at **Location** and select it.

Procedure: Location

**8** Position cursor at **Card** and select it.

**Position**

**Select**

Choices :

- Card
- RAM
- Disk

(You can also save procedures to an internal RAM disk or external disk drive. See Chapter 5-Disks.)

**9** Position cursor at **Comment** and select it.

**Position**

**Select**

Comment

**10** Select characters for the **Comment**, then select **Done**.

**Position**

**Select**

Choices :

- Done
- Position
- Over/Ins
- Delete
- Del End
- Bk space
- A
- B
- C

**11** Position cursor at **Library for new p....**, and select **Current**.

**Position**

**Select**

Library for new procedure

Current / [NO LIB]

(The underline indicates which option is selected. Pressing knob changes the selection.)






**12** Position cursor at **Program location for ....** and select it.

Program location for new procedure

Card

FROCMAN2

Continue on next page

|  |  |
|--|--|
| <p><b>13</b> Position cursor at <b>Card</b> and select it.</p>   | <p><b>14</b> Position cursor at <b>Action</b> and select <b>Make Procedure</b>.</p>  |
| <p><b>Position</b></p>  <p><b>Select</b></p>  <p>Choices :</p> <ul style="list-style-type: none"><li>■ Card</li><li>RAM</li><li>Disk</li></ul> | <p><b>Position</b></p>  <p><b>Action</b></p> <ul style="list-style-type: none"><li>■ Make Procedure</li><li>Delete Procedure</li></ul> <p><b>Select</b></p>  <p>(To make selection, position the cursor in front of <b>Make Procedure</b>, then press the knob.)</p> |
| <p><b>15</b> Press <b>TESTS</b> to return to the <b>TESTS</b> screen.</p>  | <p><i>To run the saved procedure;</i></p> <ol style="list-style-type: none"><li>1) Load the <b>Procedure</b></li><li>2) Insert the original HP 11807B memory card</li><li>3) Press <b>Run Test</b>.</li></ol> <p><i>The original card contains the full program needed to allow your procedure to run.</i></p>   |
|    |  |

PROCMANS

## Changing Test Execution Conditions

**Test Execution Conditions** define how your testing program starts and where and when test output occurs. You may decide to:

- Start the program automatically when the Test System is powered on. (**Autostart**)
- Stop testing when a measurement fails or continue through all of the tests without stopping. (**On UUT Failure**)
- Display (or print) only measurements that fail, or display (or print) all measurements that pass or fail. (**Output Results**)
- Pause between each measurement, or run through the entire test sequence. (**Run Mode**)
- Display output on CRT only, or display on CRT and print hardcopy. (**Output Destination**)

---

**NOTE:**

If printing test results is desired, after selecting **Printer** additional steps are necessary to connect and configure the printer. See "**Printing**" on page 189 in chapter 8.

- Enter a title for an output heading for the displayed or printed results. (**Output Heading**) Select the field with the knob and enter the output heading by selecting the appropriate letters and the select **Done**.

**Test Execution Conditions** is located on the TESTSs screen. Press TESTS to display them. To change a default setting, position the cursor to the desired field. Pressing the knob ("selecting") will toggle the underlined selection.

**Test Execution Conditions** settings (except for **Autostart**) are not retained after a power-down/power-up cycle, and will return to their default settings. They are not stored on the memory card when a test procedure is saved.

## How to Change Test Execution Conditions

Selecting Stop causes the Test Procedure to stop when a failure occurs. You can then repeat the failed test, or continue.

Selecting Single Step causes the Test Procedure to stop at the end of each measurement. You can then repeat the previous step, or continue.

Selecting Autostart On causes testing to begin after power up.

Selecting Printer causes the test procedure results to be output to the CRT and a printer

Selecting Failures causes the CRT and printer to display only the measurements that fail

The screenshot shows a terminal window with the following content:

```

TESTS
-----
Procedure: Location Library Program Autostart
: Card : Off/On
Comment
-----
Test Execution Conditions
-----
On UUT Failure      Run Mode
Continue/Stop       Continuous/Single Step
Output Results      Output Destination
All/Failures        Crt/Printer
Output leading
-----
Test Function
Edit C
-----
1 Run Test
2 Continue
3 Edit Sean
4 Edit Frea
5 Edit Spec
-----
To Screen
RF GEN
RF ANL
AF ANL
SCOPE
SPEC ANL
ENCODER
DECODER
RADIO INT
More
    
```

## Printing and Saving Test Results

Printing and saving test results are features of the HP 11807B software which require additional equipment and configuration. See ["Printing" on page 189 in chapter 8](#) for detailed description and instructions for these features.

---

## Test, Parameter, Pass/Fail Limit (Specification) Descriptions

## Test Descriptions

Tests are a series of measurements and one or more Tests make up a Procedure (See "[Selecting a Test Procedure](#)" on page 82). While you may change the Tests that make up a Procedure, you may not change the measurements the test will perform. Generally, the order in which the Tests are run is not important.

The first few capital letters in the title of each test indicate what the test refers to:

GN = General system parameters

RT = Receiver and Transmitter

RX = Receiver

TX = Transmitter



## TEST\_01 - GN Laptop Emulator

This test allows the operator to control the model 883 or Microcell transceiver manually from the Test Set via the RS-232 connection. The following operations are possible:

- Turning the SAT tone on and off and selecting its frequency.
- Setting “data sending” to OFF or CONSTANT SYMBOL.
- Setting the channel number.
- Setting squelch to ENABLED or DISABLED.
- Keying and de-keying the transmitter.
- Setting audio-ways to SPEECH or LINE LOOP
- Reading alarm status.
- Accessing the Test Set’s spectrum analyzer screen.
- Exiting local control.

This test must have your local control (FX) program stored on an SRAM card that is resident in the memory card slot on the Test Set. See [chapter 1, "Getting Started with FW Revision Above A.14.00"](#) or see [chapter 2, "Getting Started with FW Revision Below A.14.00"](#) for instructions to copy and store your local control program from your laptop. The following is an ordered sequence for combiner tuning:

1. Connect the RF IN/OUT connector on the Test Set to the channel tester port on the star junction.
2. Connect the local control cable from the Test Set to each transceiver in turn and using the appropriate fields, select the channel number and key the transmitter.
3. When all of the transmitters connected to a given combiner have been keyed, the **GOTO SPECTRUM ANALYZER** field should be selected. The spectrum analyzer will be set to a 25 MHz span to show the entire cellular band and the program will pause.
4. Select the spectrum analyzer under **To Screen** on the Test Set. Adjust the center frequency (**Center Freq**), reference level (**Ref Level**) and frequency span (**Span**) for best on-screen signal representation. The vertical scale can be set to 1 dB/div or 2 dB/div while tuning the combiner.
5. Tune the combiner. When tuning is complete press the TESTS key and then press **Continue**.
6. Each transceiver in turn should have the local control cable from the Test Set reconnected and the **EXIT LOCAL CONTROL** field should be selected to put each transceiver back into service.

### Pass/fail limits used

None

### Parameters used

None

## TEST\_02 - Memory Card Initialisation

This test allows SRAM memory cards to be conveniently initialised. All SRAM memory cards must be initialised before they can be used for the first time.

---

**NOTE:** When a memory card is initialised, any pre-existing data on the card is lost.

The software will prompt the operator to choose either DOS or LIF format for the card. DOS format is preferable if the card is to be used for data collection because DOS files are “extensible”. This means that the file can grow in size as data is added to it and the operator need not know in advance how many records to reserve for the file. See "[Data Collection \(Saving and Retrieving Test Results\)](#)," in [chapter 8, on page 164](#).

### Pass/fail limits Used

None

### Parameters Used

None

## TEST\_03 - Local Control File Transfer

This test copies the local control program (FX File) from your PC or laptop computer to an SRAM memory card. After this test is run you will be able to control a model 883 or Microcell transceiver from the Test Set without use of your laptop. This will free you from connecting your laptop to the base station under test and allow your laptop to be used for MTSO communication. Local control file transfer is accomplished by the following:

1. Load the Option 052 software.
2. Initialize the SRAM memory card supplied with the software. See [TEST\\_02 - Memory Card Initialisation](#).
3. Connect your laptop (serial port 1) to the Test Set (serial port) via the supplied interface cable (RJ-11(m) to DB-9(f), part no. 08921-61038).
4. Run TEST\_03.
5. Select **Continue** in response to inserting an initialized memory card.
6. On the laptop at the `c:\` enter, `mode com1:48,n,8,1`
7. On the laptop at the `c:\` prompt enter, the directory where the local program resides and copy the program. For example, `copy a:\fx1.mpr com1`.

For a complete illustrated method see [chapter 1, "Getting Started with FW Revision Above A.14.00"](#) or see [chapter 2, "Getting Started with FW Revision Below A.14.00"](#) in this guide.

### Pass/fail limits used

None

### Parameters used

None

## TEST\_04 - GN Swept Return Loss

### Test Signal Can Cause Interference

---

**NOTE:**

This test radiates a test signal when it is used to test antennas or cables with antennas attached to them. Verify that the level and frequency span used for the test cannot result in interference to another antenna nearby. Set the parameter **GN RF level for return loss tests (dBm)** to the minimum level that provides good resolution for the measurement you are making. Set the frequency range carefully.

After a single sweep is taken, the tracking generator RF level is not changed. A CW signal is therefore being applied to the antenna even after the test finishes.

If you are in an area with other receive antennas nearby, you may want to use **TEST\_05 - GN Discrete Channel Return Loss**. This test measures the return loss at a frequency offset from a selectable range of TACS channels. The offset (in kHz) from the TACS channels can be set.

---

This test measures the return loss of a cable or device in the swept mode. An SWR bridge and a 6-dB pad are connected to the Test Set. The pad is used to improve the mismatch between the SWR bridge and the ANT IN port on the Test Set. The user is prompted at the start of the test to enter the start and stop frequencies. This test uses the spectrum analyzer and tracking generator in the HP 8921A. A reference level is measured on the spectrum analyzer with a short or open on the SWR bridge DUT port. The return loss is then measured with the cable-or-antenna-under-test on the SWR bridge DUT port. A plot of return loss versus frequency is displayed on the screen. The measurement value returned is the worst case return loss in the sweep.

The return loss plot can be viewed real time at the end of the test by pressing CANCEL, TESTS, and selecting **Spec An1** from the **To Screen** menu. To print this screen, press SHIFT PRINT (a compatible printer must be connected, and the Test Set must be configured appropriately. See "**Printing**" in **chapter 8, Reference (Alphabetical)**. VSWR can be calculated from the return loss. The following **table 2** and **table 3** contain some of the values from a calculation.

**Table 2 Return Loss (0 to 20 dB) to VSWR**

| Return Loss(dB) | 0        | 2   | 4   | 6   | 8   | 10   | 12   | 14   | 16   | 18   | 20   |
|-----------------|----------|-----|-----|-----|-----|------|------|------|------|------|------|
| VSWR            | infinity | 8.7 | 4.4 | 3.0 | 2.3 | 1.92 | 1.67 | 1.50 | 1.38 | 1.29 | 1.22 |

**Table 3 Return Loss (20 to 40 dB) to VSWR**

| Return Loss(dB) | 20   | 22   | 24   | 26   | 28   | 30   | 32   | 34   | 36   | 38   | 40   |
|-----------------|------|------|------|------|------|------|------|------|------|------|------|
| VSWR            | 1.22 | 1.17 | 1.13 | 1.11 | 1.08 | 1.07 | 1.05 | 1.04 | 1.03 | 1.03 | 1.02 |

The following formula can be used to determine the VSWR from the return loss (=RL in dB):

$$VWSR = \frac{1 + 10^{\frac{-RL}{20}}}{1 - 10^{\frac{-RL}{20}}}$$

VSWR is sometimes stated as a ratio. For example: 1.2:1 or “one point two to one” VSWR. The first number is given in the tables and formula. The second number is always one.

## Estimating Antenna Return Loss

If you are measuring the return loss of an antenna connected to the end of a known good feed line, you can approximately determine the return loss of the antenna by subtracting twice the loss. For example, if you measure a return loss of 24 dB and the line is known to have a 2 dB loss, the estimated return loss of the antenna is 20 dB. This estimate is in error if the coaxial line and connectors do not have a return loss somewhat greater than 24 dB.

### Pass/fail limits used

[GN return loss \(dB\)](#)

### Parameters used

[GN RF level for return loss tests \(dBm\)](#)

## TEST\_05 - GN Discrete Channel Return Loss

This test measures the return loss for discrete channels. This test is performed at channels entered by the user and offset by a frequency to make the measurement between actual channels. An SWR bridge and a 6 dB pad are required. The pad is used to improve the impedance match at the ANT IN part on the Test Set. A reference level is measured on the spectrum analyzer with a short or open on the SWR bridge DUT port. The return loss is then measured with the cable or antenna-under-test on the SWR bridge DUT port.

This test should be used when there is a chance that a full frequency sweep of the band to be tested may cause interference. In this test, the chance of interference is greatly reduced by selecting an offset that sets a CW test frequency in between the assigned TACS channels. For example, selecting an offset of 12.5 kHz places the test signal between adjacent TACS channels.

See [TEST\\_04 - GN Swept Return Loss](#) for a return loss to VSWR conversion table and formula and a way to estimate the return loss of an antenna connected to the end of a feed line.

### Pass/fail limits used

[GN return loss \(dB\)](#)

### Parameters used

[GN RF level for return loss tests \(dBm\)](#)

## TEST\_06 - GN Cable Fault Versus Distance

### Test Signal Can Cause Interference

---

**NOTE:**

This test radiates a test signal when it is used to test cables with antennas attached to them. Verify that the signal used for the test cannot result in interference to another antenna. The software reduces the signal generator level except when it is needed to actually perform the measurement.

Frequencies outside the cellular band will be swept. The frequency range used for this test depends on the cable length value you enter. For example, the frequency range of 10 MHz to approximately 1000 MHz is used for a 21 meter cable, 10 MHz to approximately 500 MHz for a 42 meter cable and so on.

---

This test displays the relative mismatch of a transmission line as a function of the distance down the line. A frequency-swept signal from the DUPLEX OUT port is applied through a resistive power splitter to the cable under test. HP part number, 0955-0733, is a suitable power splitter for this purpose. Signals reflected from faults in the cable are combined with the DUPLEX OUT signal in the power splitter and applied to the ANT IN port. The changing interference of the forward and reflected signals, over the swept frequency band, contains information about the distance to one or more faults. The software uses a Fast Fourier Transform (FFT) to convert the frequency domain into the distance domain. The distance displayed on the Test Set CRT is the physical distance to the fault with correction for the velocity factor of the cable.

### Cable Fault Performance

Measurements of the cable fault location can typically be made up to 1,000 feet on low loss cables and 300 feet on higher loss cables. Resolution of the fault location is approximately 0.4 feet for cable lengths up to 100 feet and then linearly increases to 4 feet for a 1000 foot cable.

Typical accuracy is approximately  $\pm 1$  foot for a fault located up to 100 feet away. The typical accuracy increases linearly to  $\pm 10$  feet for faults located 1,000 feet away.

## Selecting Cable Type

The velocity factors of many (RG) types of cable are stored in a table in the software. If you are using cable without an RG number, do the following:

1. Determine the velocity factor of the cable.
2. Enter “0” for the RG type when the question is displayed.
3. Begin test.
4. Enter the velocity factor when the question is displayed.

### Velocity Factors

---

**NOTE:** Cables that use polyethylene dielectric typically have a propagation velocity of 0.66, cables that use a teflon dielectric typically have a propagation velocity of 0.70.

---

## Entering Cable Length

The greatest accuracy is obtained when you enter a cable length slightly greater than the actual cable length, considering length uncertainty. If you are not sure of the cable length, enter a value 1.5 times the estimated length. Depending on the return loss of the antenna or device at the end of the cable, you may see a high relative mismatch displayed at the actual length of the cable.



## Interpreting Cable Fault Location Results

Distance to the cable fault is accurately quantified when you select the USER (**Disp data**) field. The relative mismatch levels and distance at which the mismatch occurs is displayed.

Numeric data for the six largest values of data from the graph is listed. Each data point is shown on a scale from 0 to 1. The scaling does not have an absolute significance, rather, the value only indicates the relative likelihood of a fault. Values less than 0.1 are typically due to noise.

The largest relative mismatch is most likely the location of a cable fault. Other numeric data points, particularly if they are further down the line from a point of high relative mismatch, can be ignored. Data points on the fringe of a point of high relative mismatch are usually attributable to the single fault.

### Pass/fail limits used

None

### Parameters used

None

## TEST\_07 - GN Measure Cable Loss

This test can be used to measure the loss in a two-port device or cable when both ends of the cable are accessible. The loss is measured over a range of RF frequencies specified by the operator.

1. Individual 6 dB attenuators should be connected to the DUPLEX OUT and ANT IN connectors on the Test Set to improve the impedance match on these two ports. HP part number 0955-0698 is a suitable attenuator for this purpose.
2. The operator is prompted to connect a short length of cable between the two pads so that a reference sweep can be made.
3. Finally, the operator is prompted to connect the cable under test between the short calibration cable and one of the pads so that its loss can be measured. A plot of insertion loss versus frequency is displayed.

The insertion loss plot can be viewed real-time at the end of the test by pressing CANCEL, TESTS, and selecting **Spec Anal** from the **To Screen** menu.

### Pass/fail limits used

None

### Parameters used

**GN RF level for return loss tests (dBm)**

## TEST\_08 - GN Data Collection File Transfer

This test reads files from a memory card and transmits them out of the serial port or HP-IB port on the Test Set.

The intended use of this test is to transfer test results which have been stored on an SRAM memory card to a personal computer (PC) or printer. For a discussion of how to store test results on a memory card, see "[Data Collection \(Saving and Retrieving Test Results\)](#)," in [chapter 8, on page 164](#). Perform the following steps to accomplish data collection file transfer:

1. Do one of the following:
  - a. Connect a PC to the Test Set serial port via the supplied interface cable part number 08921-61038. Set up your terminal emulator software to log received data to a disk file or printer.
  - b. Connect a serial printer to the Test Set serial port via cable part number 08921-61039 or equivalent.
  - c. Connect an HP-IB printer to the Test Set HP-IB port.
2. Run TEST\_08 GN Data Collection File Transfer
3. Insert the SRAM memory card containing the desired test results when prompted to do so and press **Continue**.
4. Use the knob to select the desired output port, either the serial port or HP-IB.
5. A list of all files found on the card will be displayed on the screen. Use the knob to select those that you want to transfer. An asterisk will be appended to each selected file name on the screen to indicate that it has been selected.
6. Use the knob to select the "Transfer Selected Files" field. Each of the selected files will be transmitted out of the selected port along with the associated file name.
7. If you wish to purge (delete) selected files from the memory card, select the "Purge (Delete) Selected Files" field.
8. Use the knob to select the "Exit Data-Collection-File-Transfer" field to terminate this test.

---

**NOTE:** The serial port parameters are fixed at 9600 baud, 8 data bits, 1 stop bit, and no parity for this test. The terminal emulator or serial printer parameters must be set to match.

---

### Pass/fail limits Used

- None

### Parameters Used

- None

## TEST\_09 - TX Frequency Adjustment

This test measures the transmitter's carrier frequency. An analog on screen frequency error meter is used so that the user may tune the base station's carrier frequency. The user is prompted to adjust the transmitter frequency until the meter needle is centered. The user then selects **Done**. The meter incorporates plus and minus specification limits that are set by the pass/fail limit, **TX frequency error (Hz)**.

### Pass/fail limits used

**TX frequency error (Hz)**

### Parameters used

**GN CU serial control [0=PC 1=HP8921]**  
**RT audio excitation frequency (kHz)**  
**RT units for audio measurements [0=mV, 1=dBm]**  
**TX audio adjustment excitation level (mV/dBm)**

## TEST\_10 - TX Power Adjustment

This test measures the transmitter's output power in Watts or dBm. An analog meter showing TX power is provided for adjustment purposes. The user selects **Done** to accept the value after adjusting the TX power to within the pass/fail limits set by the pass/fail limit, **TX output power (W/dBm)**.

### Pass/fail limits used

**TX output power (W/dBm)**

### Parameters used

**GN CU serial control [0=PC 1=HP8921]**  
**RT audio excitation frequency (kHz)**  
**RT units for audio measurements [0=mV, 1=dBm]**  
**TX units for RF pwr measure [0=W 1=dBm]**  
**TX audio adjustment excitation level (mV/dBm)**  
**TX path loss (dB)**

## TEST\_11 - TX Audio Level Adjustment

This test measures and allows adjustment of the audio level produced by the transmitter when driven by a specified audio level at the TX LINE input. The audio level from the transmitter is measured between TX MOD and GND on the audio breakout box.

1. The user is prompted to make connections for transmitter audio level adjustment.
2. A specified audio level is provided by the Test Set while the transmitter audio level is monitored on an analog meter.
3. The user then adjusts the TX audio (TX Sens) until the meter reflects a pass condition.
4. The user then selects **Done**.

### Pass/fail limits used

**TX audio level (mV/dBm)**

### Parameters used

**RT audio excitation frequency (kHz)**

**RT units for audio measurements [0=mV, 1=dBm]**

**TX audio adjustment excitation level (mV/dBm)**

## TEST\_12 - TX Voice Channel Deviation

This test measures the frequency deviation produced by the transmitter when driven by a specified audio level at the TX LINE input. The result of the measurement is compared to a limit set in the TX voice channel deviation pass/fail limit.

### Pass/fail limits used

**TX voice channel deviation (kHz)**

### Parameters used

**GN CU serial control [0=PC 1=HP8921]**

**RT audio excitation frequency (kHz)**

**RT units for audio measurements [0=mV, 1=dBm]**

**TX audio adjustment excitation level (mV/dBm)**

### TEST\_13 - TX Voice and SAT Deviation

This test measures the peak frequency deviation of the base station. The transceiver is commanded to generate a 5970 Hz SAT tone, and the transmitter is turned on. An audio input defined by the parameters, TX audio adjustment excitation frequency and TX audio adjustment excitation level, is applied to the TX LINE input of the transceiver and the resulting peak frequency deviation is measured.

#### Pass/fail limits used

**TX voice and SAT deviation (kHz)**

#### Parameters used

**GN CU serial control [0=PC 1=HP8921]**

**RT audio excitation frequency (kHz)**

**RT units for audio measurements [0=mV, 1=dBm]**

**TX audio adjustment excitation level (mV/dBm)**

### TEST\_14 - TX Maximum Voice Deviation

This test verifies that the instantaneous peak frequency deviation of the transmitter does not exceed the pass/fail limit, TX maximum voice deviation, even when the TX LINE input is overdriven. An audio input defined by the parameters, TX audio adjustment excitation frequency and TX max voice audio level, is applied to the TX LINE input of the transceiver and the resulting peak frequency deviation is measured.

#### Pass/fail limits used

**TX maximum voice deviation (kHz)**

#### Parameters used

**GN CU serial control [0=PC 1=HP8921]**

**RT audio excitation frequency (kHz)**

**RT units for audio measurements [0=mV, 1=dBm]**

**TX max voice audio level (mV/dBm)**

### TEST\_15 - TX Data Deviation

In this test, the transceiver is commanded to generate the CONSTANT SYMBOL data stream. The resulting peak frequency deviation is measured.

#### Pass/fail limits used

**TX constant symbol data deviation (kHz)**  
**TX constant symbol data frequency (kHz)**

#### Parameters used

**GN CU serial control [0=PC 1=HP8921]**

### TEST\_16 - TX SAT Frequency Error and Deviation

This test measures the frequency error and deviation of the SAT (supervisory audible tone).

#### Pass/fail limits used

**TX SAT deviation (kHz)**  
**TX SAT frequency error (Hz)**

#### Parameters used

**GN CU serial control [0=PC 1=HP8921]**

### TEST\_17 - TX Calculate ERP

This test calculates the power from the transmitter, in Watts, required to produce the desired ERP. The user inputs the following:

1. The desired effective radiated power from the antenna.
2. The lengths of RF transmission line between the transmitter and the antenna.
3. All other known losses between the transmitter and the antenna (such as the combiner, etc.).

#### Pass/fail limits used

None

#### Parameters used

None

## TEST\_18 - RX Line Level Adjustment

This test measures the audio line level output of the receiver. The user is prompted to make the correct audio connections to the receiver. A modulated RF signal is applied to the receiver and its audio output level is measured.

The user is prompted to adjust the RX Lev potentiometer on the base station until the meter indicates an in-limit level. The user then selects **Done**.

For the analog microcell transmitter the RX level adjustment is performed on the RXA receiver. The user is then prompted to change to the RXB receiver, and the line level difference from the RXA Receiver is measured in dB. If the parameter GN check MCBS on only RXA is set to 1=yes, the RXB receiver is not checked.

### Pass/fail limits used

**RX line level (mV/dBm)**

### Parameters used

**GN CU serial control [0=PC 1=HP8921]**

**RT audio excitation frequency (kHz)**

**RX system deviation (kHz)**

**RT units for audio measurements [0=mV, 1=dBm]**

**RX RF level for audio adjust (dBm)**

**RX path loss (dB)**

**GN check MCBS on only RXA [0=no 1=yes]**

## TEST\_19 - RX Sensitivity

This test measures the sensitivity of the base station's receiver. The Test Set outputs a modulated RF signal to the receiver and varies the RF output level until a SINAD level defined by the parameter, RX sensitivity SINAD level, is obtained with a tolerance of  $\pm 0.8$  dB. The associated RF output level is reported as the test result.

The receive audio output on a locating receiver (MLOC) does not have a high gain output. Therefore, to test sensitivity on an MLOC it may be desirable to set the Test Set AUDIO IN impedance to float rather than 600 ohm. To select a floating input impedance set parameter **RX sens floating audio input [0=no 1=yes]** to 1=yes. Consult your Ericsson MLOC documentation for proper setting of this parameter.

---

**NOTE:** This test is only done on RXA on the analog microcell; therefore, this test should be selected instead on TEST 20 if you want to test the microcell on only RXA.

---

### Pass/fail limits used

**RX sensitivity (dBm)**

### Parameters used

**RT audio excitation frequency (kHz)**

RT full rated system deviation (kHz)

**RX path loss (dB)**

**RX sensitivity SINAD level (dB)**

**RX sens floating audio input [0=no 1=yes]**



## TEST\_20 - RX Diversity Sensitivity

This test is identical to TEST\_19 RX Sensitivity except that the user is prompted to connect only one of the receiver antenna ports at a time (RXA or RXB). For the model 883 transceiver, the user must terminate the unused port on the power splitter with a 50 ohm load. Sensitivity is measured for each of the two antenna ports individually. The diversity sensitivity for each of the antenna ports is reported as an offset, in dB, from the sensitivity measured with both parts driven.

For the microcell transceiver, the user is prompted to connect the generator output to RXB without a splitter. Sensitivity is measured on RXB, and the user is prompted to connect to RXA to measure sensitivity. Checking RXB first minimizes the cable movements if this test is preceded by T18. The diversity sensitivity for each antenna is reported as absolute RF level in dBm.

If you only want to check the microcell on RXA, substitute TEST\_19 for this test.

---

**NOTE:**

See the description of [TEST\\_19 - RX Sensitivity](#) for more information about how the sensitivity measurement is made.

### Pass/fail limits used

[RX diversity sensitivity \(dB/dBm\)](#)

### Parameters used

[RT audio excitation frequency \(kHz\)](#)  
[RX deviation for sensitivity tests \(kHz\)](#)  
[RX path loss \(dB\)](#)  
[RX sensitivity SINAD level \(dB\)](#)

## TEST\_21 - RX Desense

This test measures the receiver's desensitization when the transmitter is keyed. First the receiver's sensitivity is measured as in TEST\_19. Then the transceiver is commanded to key the transmitter, and the receiver sensitivity is measured again. The measured sensitivity must remain the same within a tolerance set by the pass/fail limit, **RX desense (dB)**.

This test is done on RXA for the microcell transceiver.

### Pass/fail limits used

**RX desense (dB)**

### Parameters used

**GN CU serial control [0=PC 1=HP8921]**  
**RT audio excitation frequency (kHz)**  
**RX deviation for sensitivity tests (kHz)**  
**RX path loss (dB)**  
**RX sensitivity SINAD level (dB)**

## TEST\_22 - RX Squelch Test

This test measures and sets the receiver's squelch threshold and hysteresis. The Test Set generates an RF carrier and adjusts the level of this carrier while measuring the audio noise on the RX LINE output of the receiver. The Test Set finds the RF levels at which the squelch opens and closes and reports them as squelch threshold and squelch hysteresis.

The squelch threshold is reported either as an absolute value in dBm or as an offset from the usable sensitivity, depending upon the setting of the RX squelch threshold parameter.

For the microcell transceiver, this test is only performed on RXA.

### Pass/fail limits used

**RX squelch hysteresis (dB)**  
**RX squelch threshold (dB/dBm)**

### Parameters used

**GN CU serial control [0=PC 1=HP8921]**  
**RT audio excitation frequency (kHz)**  
**RX system deviation (kHz)**  
**RX path loss (dB)**  
**RX sensitivity SINAD level (dB)**  
**RX squelch threshold [0=relative 1=abs]**

## TEST\_23 - RX RF Level Calibration (AIO)

This test verifies the ability of the base station to measure the level of a received RF signal. The Test Set outputs a modulated RF signal at a specified level to the receiver. The base station internally measures the received RF signal's level and reports back to the Test Set. The value is then compared to the upper and lower limits of signal level in the pass/fail limit, **RX RF level from AIO**.

For the microcell transceiver, this test is performed first on RXA then on RXB. The user is prompted to change cables between the tests. If the parameter GN check MCBS on only RXA is set to 1=yes, the RXB receiver is not checked.

### Pass/fail limits used

**RX RF level from AIO**

### Parameters used

**GN CU serial control [0=PC 1=HP8921]**  
**RT audio excitation frequency (kHz)**  
**RX path loss (dB)**  
**RX RF level for AIO/RSSI test (dBm)**  
**ZZ test mode [0=normal 1=demo]**  
**RX deviation for RF level test (AIO) (kHz)**  
**GN check MCBS on only RXA [0=no 1=yes]**

## TEST\_24 - RX Loop Gain Adjustment

This test measures the transceiver's audio loop gain. The transceiver is commanded to set its internal audio path to LINE LOOP. An audio tone with a level given by the parameter, TX audio adjustment excitation level, is applied to the TX LINE input of the transceiver. The audio level returned from the transceiver via the RX LINE output is measured and displayed on a simulated analog meter to facilitate adjustment. The measured loop gain level is compared to the pass/fail limit, **RX loop gain level (mV/dBm)**.

### Pass/fail limits used

**RX loop gain level (mV/dBm)**

### Parameters used

**GN CU serial control [0=PC 1=HP8921]**  
**RT audio excitation frequency (kHz)**  
**RT units for audio measurements [0=mV, 1=dBm]**  
**TX audio adjustment excitation level (mV/dBm)**

## **TEST\_25 - RX SAT Detector**

This test measures the ability of the transceiver under test to detect a SAT tone.

An RF carrier is generated by the Test Set with a level set by the RX RF level for SAT detector test parameter. The carrier is modulated with each of the three SAT tones in turn.

The AIO levels for SAT and signal-to-noise are read back from the transceiver to the Test Set via RS-232 and reported. They are compared to the RX SAT detector level and RX SAT detector signal-to-noise pass/fail limits.

### **Pass/fail limits used**

- RX SAT detector level**
- RX SAT detector SNR**

### **Parameters used**

- RX RF level for SAT detector test (dBm)**
- RX path loss (dB)**
- RX system deviation (kHz)**

---

## Parameter Descriptions

Parameters are values you enter that optimize test environment or conditions of the software. Many of the parameters are determined by examining your test needs. Other parameters are determined by performing measurements to calibrate items in your system. Default values are set into the software. Some of these are derived from standard methods of measurement and some are derived from the manufacturer's requirements.

For information on editing parameters, see [chapter 5, "Using the Software with FW Above Rev. A.14.00"](#) or [chapter 6, "Using the Software/HP 8921A FW Rev. Below A.14.00"](#).

Parameters remain in battery-backed-up memory until you select a Procedure to run. If you wish to prevent them from being lost when a new Procedure is selected, you will have to save them in a Procedure. See ["Saving a Test Procedure" on page 94](#).

To print the parameters list, see ["To print TESTS screens" on page 194](#).

The first few capital letters in the title of each parameter indicate what the parameter refers to:

- GN = General system parameters
- RT = Receiver and Transmitter
- RX = Receiver
- TX = Transmitter
- ZZ = Other

### **GN model number [1=883 2=MCBS]**

This parameter sets the transceiver model to be tested.

### **GN CU serial control [0=PC 1=HP8921]**

This parameter sets the type of serial control unit that will be used to communicate with the Base Station Transceiver Modules. The choices are either a personal computer or the HP 8921 (Test Set)

### **GN auto exit adj [0=no, xx=times in spec]**

This parameter sets the number of measurements that must be in specification to automatically exit from the meter screen.

#### **Example**

If you wish to stop testing after 6 successive measurements have met the pass/fail limits set (pass), enter **6**

### **GN RF level for return loss tests (dBm)**

This parameter sets the RF level that the Test Set outputs for TEST\_04 - GN Swept Return Loss, TEST\_05 - GN Discrete Channel return Loss and TEST\_07 - GN Measure Cable Loss.

#### **Example**

If you wish the RF level to be 0 dBm, enter **0**.

### **RT default channel**

This parameter sets the default channel for transceiver testing. The user may change the channel when prompted at the beginning of each procedure.

### **RT audio excitation frequency (kHz)**

This parameter sets the audio test tone frequency to be used in testing for both the receiver and transmitter.

#### **Example**

If you wish the audio frequency to be 1 kHz, enter **1**.

### **RT units for audio measurements [0=mV, 1=dBm]**

This parameter sets the measurement units, mV or dBm to be used in the audio tests for both the receiver and transmitter.

### **TX units for RF pwr measure [0=W 1=dBm]**

This parameter sets the measurement units, Watts or dBm to be used in transmitter power measurements.

### **TX path loss (dB)**

This parameter sets the cable loss between the Test Set's input (RF IN/OUT or ANT IN) and the transmitter's output. This value will be added to all RF level measurements performed on the transmitter.

#### **Example**

If the cable loss between the transmitter and the Test Set is 2 dB, enter **2**.

### **TX audio adjustment excitation level (mV/dBm)**

This parameter sets the level of the audio signal that will be applied to the TX LINE input of the transceiver in the following tests: TEST\_09 - TX Frequency Adjustment, TEST\_10 - TX Power Adjustment, TEST\_11 - TX Audio Level Adjustment, TEST\_12 - TX Voice Channel Deviation, TEST\_13 - TX Voice and SAT Deviation and TEST\_24 - RX Loop Gain Adjustment. The units (mV or dBm) of the signal are set in the parameter, RT units for audio measurements.

The Test Set has an output impedance of less than 1  $\Omega$  on the AUDIO OUT port. The TX audio excitation level parameter can be set to a value slightly higher than the specified test line level, for example 183 mV instead of 167 mV (-12.5 dBm instead of -13.3 dBm). This should be done to simulate the unequal voltage division which occurs when the TX LINE input of the transceiver is driven by a 600  $\Omega$  audio source.

#### **Example**

If the desired excitation level is 183 mV, enter **183**.

### **TX max voice audio level (mV/dBm)**

This parameter sets the level of the audio signal that modulates the transmitter to produce maximum deviation. The units, mV or dBm of the signal are specified in the parameter, RT units for audio measurements. It is used in TEST\_14 - TX Maximum Voice Deviation.

#### **Example**

If the desired audio level is 500 mV, enter **500**.

### **RX RF level for audio adjust (dBm)**

This parameter sets the RF level of the Test Set's DUPLEX OUT output (plus the parameter, RX path loss ) to be used in TEST\_18 - RX Line Level Adjustment.

#### **Example**

If you wish the RF level to be -60 dBm, enter **-60**

### **RX path loss (dB)**

This parameter sets the amount of loss in the path between the Test Set's DUPLEX OUT connection and the receiver's RXA and RXB inputs. This value includes the power splitter's loss.

#### **Example**

If the pad and cable loss is 7 dB between the Test Set and the RXA and RXB inputs, enter **7**.

### **RX sensitivity SINAD level (dB)**

This parameter sets the SINAD level used in sensitivity measurements.

#### **Example**

If you wish to set the SINAD level to 12 dB which is the standard level used for most sensitivity testing, enter **12**.

### **RX squelch threshold [0=relative 1=abs]**

This parameter sets whether the pass/fail limit, **RX squelch threshold [0=relative 1=abs]** is relative or absolute.

### **RX RF level for AIO/RSSI test (dBm)**

This parameter sets the RF level of the Test Set's DUPLEX OUT output (plus the parameter, RX path loss) to be used in TEST\_23 RX RF Level Calibration (AIO).

#### **Example**

To set a level of -87 dBm, enter **-87**



### **RX system deviation (kHz)**

This parameter sets the rated deviation to be used in TEST\_18 - RX Line Level Adjustment; TEST\_22 - RX Squelch Test, and TEST\_25 - RX\_SAT Detector.

#### **Example**

If you wish the deviation to be 5.7 kHz, enter **5.7**.

### **RX deviation for RF level test (AIO) (kHz)**

This parameter sets the frequency deviation to be used in TEST\_23 - RX RF Level Calibration (AIO).

#### **Example**

To set 2.9 kHz of deviation, enter **2.9**

### **RX deviation for sensitivity tests (kHz)**

This parameter sets the frequency deviation to be used in TEST\_19 - RX Sensitivity, TEST\_20 - RX Diversity Sensitivity and TEST-21 - RX Desense.

### **RX RF level for SAT detector test (dBm)**

This parameter sets the RF level used in TEST\_25 - RX SAT Detector.

### **ZZ test mode [0=normal 1=demo]**

Select 0=normal to choose the standard test mode. 1=demo will select the demo test mode which simulates the actual test without requiring that the DUT to be connected.

### **RX sens floating audio input [0=no 1=yes]**

This parameter configures the audio impedance during T19-RX Sensitivity test. Setting this parameter to 0=no establishes a 600 ohm impedance between the AUDIO IN LO and AUDIO IN HI connectors during this test. When the parameter is set to 1=yes, the AUDIO IN connector center pins are isolated from the ground, providing a floating audio input. Set this parameter to 0=no for voice transceiver testing. The receive audio output on a locating receiver (MLOC) does not have a high gain output. Therefore, it may be desirable to set this parameter to 1=yes for MLOC testing. Consult your Ericsson MLOC documentation for proper setting of this parameter.

**GN check MCBS on only RXA [0=no 1=yes]**

Some 882M analog microcell transceivers are only used with the RXA antenna. Selecting 1=yes for this parameter only checks the RXA antenna on the microcell. Testing only one antenna reduces test time because the user does not have to change antenna connections during test 18, test 20, and test 23. If 0=no is selected, the user will be prompted to connect to RXA and RXB individually during test 18, test 20, and test 23.

**GN no prompt at end of test [0=no 1=yes]**

Setting this parameter to 0=no will prompt the user to exit local control at the end of an analog transceiver test sequence. Exiting local control is necessary to put the transceiver back in service after testing.

---

## Pass/Fail Limit (Specification) Descriptions

Pass/Fail Limits define the values a measurement's result is compared against to determine if the UUT meets its specified standards. Default values are available in the test software. They have been derived from standard methods of measurement. Pass/fail limits remain in the Test Set's battery-backed-up memory until you select a new procedure to run.

To print the pass/fail limits list, see ["To print TESTS screens" on page 194](#).

The first few capital letters in the title indicate what the pass/fail limit refers to:

GN = General system pass/fail limits

RX = Receiver pass/fail limits

TX = Transmitter pass/fail limits

### GN return loss (dB)

This pass/fail limit sets a limit on the maximum acceptable return loss for the return loss tests, [TEST\\_04 - GN Swept Return Loss](#) and [TEST\\_05 - GN Discrete Channel Return Loss](#). Only a lower limit is applicable for this pass/fail limit.

#### Example

If you want a lower limit of 10 dB set, enter **10**.

### TX frequency error (Hz)

This sets the limits in Hertz used in [TEST\\_09 - TX Frequency Adjustment](#). These limits are applied to a frequency meter on the Test Set. The user adjusts the transmitter's frequency within the limits.

#### Example

If a tolerance of  $\pm 1$  kHz is desired, enter **-1000** for the lower limit and **1000** for the upper limit.

### **TX output power (W/dBm)**

This pass/fail limit sets the limits used in **TEST\_10 - TX Power Adjustment**. The limits are shown on the scale of a simulated analog power meter which is displayed on the screen of the Test Set to facilitate adjustment of transceiver output power.

If the parameter, **TX units for RF pwr measure [0=W 1=dBm]** is set to **0**, then the values entered in this pass/fail limit will be interpreted as Watts. If the parameter, **TX units for RF pwr measure [0=W 1=dBm]** is set to **1**, then the values entered in this pass/fail limit will be interpreted as dBm.

#### **Example**

Assume that the base station being tested has a nominal output of 45 Watts and should be within  $\pm 5$  Watts. Enter **40** as the lower limit and **50** as the upper limit.

### **TX audio level (mV/dBm)**

This sets the limits used in **TEST\_11 - TX Audio Level Adjustment**. The TX audio level is adjusted through the front panel TX Sens potentiometer and is compared with the set limits.

If the parameter, **TX units for RF pwr measure [0=W 1=dBm]** is set to **0**, then the values entered in this pass/fail limit will be interpreted as Watts. If the parameter, **TX units for RF pwr measure [0=W 1=dBm]** is set to **1**, then the values entered in this pass/fail limit will be interpreted as dBm.

#### **Example**

To set limits of  $\pm 5$  mV around 775 mV, enter **770** as the lower limit and **780** as the upper limit.

### **TX voice channel deviation (kHz)**

This pass/fail limit sets the limits used in **TEST\_12 - TX Voice Channel Deviation**.

#### **Example**

To set limits of  $\pm 1.1$  kHz on 6.4 kHz of deviation, enter **5.3** as the lower limit and **7.5** as the upper limit.

### **TX voice and SAT deviation (kHz)**

This pass/fail limit sets the limits used in [TEST\\_13 - TX Voice and SAT Deviation](#).

#### **Example**

To set limits of  $\pm 1.1$  kHz on 8.1 kHz of deviation, enter 7 as the lower limit and 9.2 as the upper limit.

### **TX maximum voice deviation (kHz)**

This sets the limits used in [TEST\\_14 - TX Maximum Voice Deviation](#).

#### **Example**

To set limits of +.5, -4.5 kHz on 9.5 kHz of deviation, enter 5 as the lower limit and 10 as the upper limit.

### **TX constant symbol data frequency (kHz)**

This sets the frequency limits used in [TEST\\_15 - TX Data Deviation](#).

#### **Example**

To set limits of  $\pm 5$  Hz on a data rate of 8 kHz, enter 7.995 as the lower limit and 8.005 as the upper limit.

### **TX constant symbol data deviation (kHz)**

This sets the deviation limits used in [TEST\\_15 - TX Data Deviation](#).

#### **Example**

To set limits of  $\pm 1.1$  kHz on a deviation of 6.4 kHz, enter 5.3 as the lower limit and 7.5 as the upper limit.

### **TX SAT deviation (kHz)**

This sets the deviation limits used in [TEST\\_16 - TX SAT Frequency Error and Deviation](#).

#### **Example**

To set limits of  $\pm 3$  kHz on a deviation of 1.7 kHz, enter 1.4 as the lower limit and 2 as the upper limit.

### **TX SAT frequency error (Hz)**

This sets the frequency error limits used in [TEST\\_16 - TX SAT Frequency Error and Deviation](#).

#### **Example**

To set limits of  $\pm 3$  Hz on the SAT, enter **-3** as the lower limit and **3** as the upper limit.

### **RX line level (mV/dBm)**

This sets the line level limits used in [TEST\\_18 - RX Line Level Adjustment](#). The units (mV or dBm) of the signal are specified in the parameter [RT units for audio measurements \[0=mV, 1=dBm\]](#).

#### **Example**

To set limits of  $\pm 5$  mV on a line level of 167 mV, enter **162** as the lower limit and **172** as the upper limit.

### **RX sensitivity (dBm)**

This sets the sensitivity upper limit used in [TEST\\_19 - RX Sensitivity](#). The limit represents the amount that the receiver's sensitivity cannot exceed.

#### **Example**

To set a limit of  $-116$  dBm sensitivity, enter **-116** as the upper limit.

### **RX diversity sensitivity (dB/dBm)**

This sets the sensitivity limits used in [TEST\\_20 - RX Diversity Sensitivity](#). In this test, only one of the two receiver inputs is driven at a time. For the model 883 transceiver, the limits represent the amount that the receiver's usable sensitivity is allowed to degrade in comparison with the case in which both receiver inputs are driven simultaneously. For the microcell transceiver, the limits represent absolute RF levels in dBm.

#### **Example**

To set a lower limit of 2 dB and an upper limit of 9 dB sensitivity, enter **2** as the lower limit and **9** as the upper limit.

### **RX desense (dB)**

This sets the limits used in [TEST\\_21 - RX Desense](#). The limits represent the amount that the receiver's sensitivity (SINAD) is allowed to change when the transmitter is keyed.

#### **Example**

To set a lower limit of -1 dB from the sensitivity (SINAD) level and an upper limit of 1 dB from the sensitivity, enter -1 as the lower limit and 1 as the upper limit.

### **RX squelch threshold (dB/dBm)**

This sets the squelch threshold limits used in [TEST\\_22 - RX Squelch Test](#). If the parameter, [RX squelch threshold \[0=relative 1=abs\]](#) is set to 0, then the values entered in this pass/fail limit will be interpreted as an offset expressed in dB from the usable sensitivity. If the parameter, [RX squelch threshold \[0=relative 1=abs\]](#) is set to 1, then the values entered in this pass/fail limit will be interpreted as an offset expressed in dBm.

#### **Example**

If it is desired to have a squelch threshold between 0 dB and 7 dB higher than the usable sensitivity, enter 0 as the lower limit and 7 as the upper limit.

### **RX squelch hysteresis (dB)**

This sets the hysteresis limits used in [TEST\\_22 - RX Squelch Test](#).

#### **Example**

To set a window of (window of hysteresis below the RX squelch threshold) of 1 dB to 4 dB. Enter 1 as the lower limit and 4 as the upper limit.

### **RX RF level from AIO**

This pass/fail limit sets the range of acceptable values to be returned by the transceiver when it makes a signal level measurement in [TEST\\_23 - RX RF Level Calibration \(AIO\)](#). There are no units associated with this pass/fail limit.

#### **Example**

To set a lower limit of 113 and an upper limit of 147, enter 113 as the lower limit and 147 as the upper limit.

### **RX loop gain level (mV/dBm)**

This sets the limits used in **TEST\_24 - RX Loop Gain Adjustment**. The units (mV or dBm) of the signal are specified in the parameter **RT units for audio measurements [0=mV, 1=dBm]**.

#### **Example**

To set limits of  $\pm 5$  mV on a loop gain level of 167 mV, enter **162** as the lower limit and **172** as the upper limit.

### **RX SAT detector level**

This sets the lower limit of acceptable values to be returned by the transceiver when it measures the level of detected SAT in **TEST\_25 - RX SAT Detector**. Note that there are no units associated with this pass/fail limit.

#### **Example**

To set a lower limit of 50, enter **50** as the lower limit.

### **RX SAT detector SNR**

This sets the lower limit of acceptable values to be returned by the transceiver when it measures the signal to noise ratio of the detected SAT in **TEST\_25 - RX SAT Detector**. Note that there are no units associated with this pass/fail limit.

#### **Example**

To set a lower limit of 50, enter **50** as the lower limit.

### **RXB microcell line level difference (dB)**

This specification sets the pass/fail limits for the difference in dB between measured receiver B and receiver A line levels. This specification is used during the RX Line Level Adjustment Test and only for analog microcell transceivers. The parameter, **GN check MCBS on only RXA [0=no 1=yes]** must be set to 0=no for this specification to be used.



---

## Reference (Alphabetical)

This chapter provides detailed descriptions of the features and functions of the HP 11807B software. Topics are arranged alphabetically for quick, easy reference.

---

## Conventions Used

Special presentations of text in this manual reflect the appearance of the item being referred to.

Examples of these special presentations are:

TESTS

*A key on the Test Set.*

**Procedure:**

*Characters displayed on the CRT display.*

k1 (**Run Test**)

*A USER key, in the key column next to the CRT. **Run Test** is displayed on the CRT.*

0.000000

*A field on the CRT where entries can be made.*

*Titles of documentation are printed in italics.*

The term Test Set refers to the HP 8921D or the HP 8921A, Option 500. In the steps in this manual the following words are used to describe cursor and entry actions:

- **select** refers to pressing the knob after positioning the cursor in front of the appropriate field (**inverse video** area).
- **choose** means to position the cursor in front of an item in the **Choices:** or **To Screen** menu in the lower right corner of the CRT display, and then press the knob.
- **enter** means to use the numeric keypad, and the ENTER key or measurement units keys to make entries to fields. In some procedures, *enter* is used to describe the action of entering characters into a field.

---

## Copying Files

Files can be copied from one mass-storage device to another using IBASIC COPY commands. For example, to copy a file from an inserted memory card to the left drive of an external dual-disk drive with HP-IB address 700, press TESTS. Select IBASIC Cntrl from the **SET UP TEST SET** list (or **IBASIC** from the **Test Function** field). Position the cursor to the IBASIC command line and select it. Using the character list that appears in the **Choices** menu, enter the following command:

```
COPY "MY_TEST:INTERNAL" TO "MYFILE:,700,0"
```

You can copy a file from a memory card to an SRAM memory card by loading the program from the memory card into the Test Set, inserting an initialized SRAM memory card, and then using the IBASIC SAVE command. Enter the following:

```
SAVE "MY_TEST:INTERNAL"
```

You can list the names of the files stored in a memory card or disk catalog by using the IBASIC CAT command. To display a list of file names on a memory card, enter the following:

```
CAT ":INTERNAL or CAT
```

If the mass storage is already defined to be the memory card, then **":INTERNAL"** is optional. If you are entering many characters into the IBASIC command line, you will want to connect a terminal to the Test Set. See ["Configuring the Test Set for Printing" on page 192](#). You will also want to use a terminal if you have many files to list because file names displayed with the **CAT** IBASIC command scroll past the top of the Test Set's CRT display and cannot be scrolled down.

IBASIC is used when writing your own programs and is not explained in this manual. If you need to write your own IBASIC programs you may acquire the following manuals:

- HP 8921A,D
  - *HP Instrument BASIC User's Handbook* HP part number E2083-90000.
  - *HP 8921 Programming Manual* HP part number 08920-90031.

See also: ["Data Collection \(Saving and Retrieving Test Results\)" on page 164](#) and ["To initialize an SRAM card using IBASIC" on page 182](#).

## Data Collection (Saving and Retrieving Test Results)

The software has the capability to save test results to an SRAM memory card, to a disk drive, or to a PC.

### Collection to a Memory Card or Disk

You will have to make entries into the **External Devices** (Edit Config) screen to describe the type of data collection you are using.

#### To configure External Devices entries:

1. Press TESTS
2. Select **External Devices** from the **SET UP TEST SET** list (or **Edit Cnfg** from the **Test Function** field).
3. Position the cursor to the **Calling Name** field and select it.
4. Using the list of characters in the **Choices** menu, enter **DATA C** into the **Calling Name** next to **Inst# 1**. The entry will look like:

```
DATA C
```

Note: For some SW revisions, DATA C will appear in the **Choices** menu. In this case, you may select DATA C, then Done instead of typing each character individually.

5. Position cursor to the **Addr** field and select it.
6. Using the DATA keypad, enter a number into **Addr**, depending on the type of storage media you will be using (press ENTER when complete):

If you are using a memory card, enter **1** into the **Addr**:

```
1  DATA C      1
```

If you are using a disk drive, enter the HP-IB disk address. For example, if the drive you are using is set to 700, then the display needs to look like:

```
1  DATA C      700
```

The test software supports data storage on Logical Interchange Format (LIF) and Disk Operating System (DOS) disk formats. Storage can be to any of the following file types:

Calling names can be entered in any order.

- ASCII files under LIF
- BDAT files under LIF
- HP-UX files under LIF
- DOS files under DOS

You will be specifying the file type with the entry you make into the **Options** field immediately below **DATA C**. If no file type is entered, and the disk format is LIF, the software will select an HP-UX file type. If no file type is entered, and the disk format is DOS, the software will select a DOS file type. For example, if you are using a DOS file and you are not using an extension on the file name, the entry on this screen will look like (**x** is first unused **Inst#**):

```
x   DATA C           700
```

If you are using an ASCII, BDAT or HP-UX file, you can specify the number of records allocated to the file. The DOS file is automatically updated as data is stored, so record allocation is not required. If you are using HP-UX files, you will have to enter **REC=** to establish a usable number of records. **REC=20480** sets the size to be the same as the default number of 256 byte records used for ASCII files ( $80 \times 256$ ). You can enter the **REC=** after the file type. For example, to use an ASCII file with 200 records of 256 bytes each, you will enter **ASCII REC=200** into the **Options** field.

---

**NOTE:**

For some software revisions, **REC=** and **ASCII REC=** will appear in the **Choices** menu. In this case, you may select **REC=** or **ASCII REC=**, enter the number of records using the **DATA** keypad, then select **Done**, instead of typing in each character individually.

The display will appear as follows:

```
x   DATA C           700
   ASCII REC=200
```

The default number of records, used when no **REC=** entry is made, is 80.

Items in the **Options** field can be separated by a comma or a space.

See "**Initializing a Disk**" on page 173 if using a new disk. See "**Initializing a Memory Card**" on page 181 if using a new memory card. The file types under LIF can be used by the Test Set's IBASIC controller and some HP workstations. The DOS format is required if you wish to use the disk with a PC.

**Table 4 Data Collection (Saving/Retrieving Tests) Configuration Summary**

| <b>Inst#</b>          | <b>Calling Name Options</b>   | <b>Model</b> | <b>Addr</b>      | <b>Description</b>  |
|-----------------------|---|--------------|------------------|---|
| x<br>(first unused #) | DATA Collection   | don't care   | 7xx <sup>1</sup> | To HP-IB disk drive   |
| x<br>(first unused #) | DATA Collection   | don't care   | 1                | To memory card  |
| Options: <sup>2</sup> | File types of ASCII,<br>or BDAT,<br>or (EXT), <sup>3</sup><br>or blank, <sup>4</sup><br>REC=xxxxx,<br>(number of records) | don't care   | 7xx <sup>1</sup> | LIF format<br>LIF format<br>DOS file type<br>DOS or HP-UX file type <sup>4</sup><br>Number of records |
| x<br>(first unused #) | DATA Collection   | don't care   | 9                | Serial to external computer<br>(laptop)   |

1. xx=Last two digits of HP-IB address.
2. These options apply to disk drive and memory card data collection. They do not apply when collecting data with Addr=9.
3. A DOS file name extension. For example, the file name may be CELL1.EXT.
4. DOS is used if the disk format is DOS. HP-UX is used if the disk format is LIF.

### Retrieving Data from a Memory Card

The easiest way to retrieve test results after they have been saved on an SRAM memory card is to run the Data Collection File Transfer Test (TEST 08). See the description of "[TEST\\_08 - GN Data Collection File Transfer](#)" in [chapter 7](#).

Alternatively, a program to transfer data from a memory card to a terminal emulator is listed below. You can type the program lines into the IBASIC command line from a terminal emulator. See "[Configuration for Terminal or PC Operation](#)" on [page 171](#).

**To enter the data  
retrieval program:**

1. Press TESTS.
2. Select **IBASIC Cntrl** from the **SET UP TEST SET** list (or **IBASIC** from the **Test Function** field).
3. Position the cursor to the IBASIC command field (large field in the upper part of the display) and select it. From the list of characters in the **Choices** field, enter the following IBASIC program statements and commands.
4. Enter **SCRATCH** to delete the previous IBASIC program. Be sure it's saved first.
5. Enter the following program:

```
10 DIM A$(120)
```

*Sets the string length to 120.*

```
20 ASSIGN @File TO "RES:INTERNAL";FORMAT ON
```

*Opens a path to the memory card file called "RES" (for results).*

```
30 ON ERROR GOTO 80
```

*Exits at end of file if an error is encountered.*

```
40 LOOP
```

*Extracts file contents.*

```
50 ENTER @File;A$
```

*Transfers part of the file to the string.*

```
60 OUTPUT 9;A$
```

*The string is output at the Serial port.*

```
70 END LOOP
```

*Goes back to get more of the file.*

```
80 END
```

*End of the program.*

6. Press k1 (**Run**) to run the entered IBASIC program.

**NOTE:**

**Difference between Run and Run Test**

The USER (**Run**) key, assigned as a default key on the TESTS (IBASIC Controller) screen, will start an IBASIC program that is resident in the Test Set's memory. The USER (**Run Test**) key, assigned as a default key on the TESTS screens, will load and run the program that is called from the **Select Procedure Filename:** and **Select Procedure Location:** entries on the TESTS (Main Menu) screen.

**Collection to a PC**

Test results can be output through the serial port. A variety of devices can receive the data. An HP Palmtop computer, PC, laptop, or terminal can be used. A terminal emulator can log the test results to a file. Examples of terminal emulator programs are HP AdvanceLink and ProComm, a product of DataStorm Technologies, Inc.

**For example: Configuring an IBM-Compatible PC with HP AdvanceLink for DOS**

1. Load and run HP AdvanceLink on your PC.
2. Use the following tables to set the *Global Configuration*, *Terminal Configuration*, and *Remote Configuration* settings.

**Table 5 Global Configuration Settings**

| <b>FIELD</b>  | <b>SETTING</b>                  | <b>FIELD</b> | <b>SETTING</b>                  |
|---------------|---------------------------------|--------------|---------------------------------|
| Keyboard      | USASCII                         | Memory Size  | 32K                             |
| Personality   | HP                              | Plotter I/F  | None                            |
| Language      | English                         | HP Mode      | Yes                             |
| Terminal Mode | Alphanumeric                    | Video Type   | <i>Select your display type</i> |
| Remote to     | <i>enter PC's serial port #</i> | Forms Path   | <i>Enter path if used</i>       |
| Printer I/F   | None                            | Screen Size  | <i>Enter the size</i>           |



**Table 6 Terminal Configuration Settings**

| <b>FIELD</b> | <b>SETTING</b> | <b>FIELD</b>         | <b>SETTING</b> |
|--------------|----------------|----------------------|----------------|
| Terminal ID  | 2392A          | Esc Xfer(N)          | YES            |
| Local Echo   | OFF            | ASCII 8 Bits         | YES            |
| CapsLock     | OFF            | FldSeparator         | US             |
| Start Col    | 01             | BlkTerminator        | RS             |
| Bell         | ON             | ReturnDef            | CR             |
| XmitFnctn(A) | NO             | Copy                 | Fields         |
| SPOW(B)      | NO             | Type Ahead           | NO             |
| InhEolWrp(C) | NO             | ROW Size             | 80             |
| Line/Page(D) | LINE           | Host Prmpt Char      | D1             |
| InhHndShk(G) | NO             | Horiz. Scroll. Incr. | 08             |
| Inh DC2(H)   | NO             | Large [+] Key        | +              |

**Table 7 Remote Configuration Settings**

| <b>FIELD</b>     | <b>SETTING</b> | <b>FIELD</b> | <b>SETTING</b> |
|------------------|----------------|--------------|----------------|
| Baud Rate        | 4800           | SR(CH)       | LO             |
| Parity/Data Bits | None/8         | Recv Pace    | None           |
| Eng Ack          | No             | Xmit Pace    | None           |
| Asterisk         | OFF            | CS(CB)Xmit   | NO             |
| Chk Parity       | NO             |              |                |

**To set up for data collection to a PC:**

1. Press TESTS.
2. Select **External Devices** from the **SET UP TEST SET** list (or **Edit Cnfg** from the **Test Function** field).
3. Position the cursor to the **Calling Name** field and select it.
4. Using the list of characters in the **Choices** menu, enter **DATA C** (next to **Inst# 1**):  
1 DATA C
5. Position the cursor to the **Addr** field and select it.
6. Using DATA keypad, enter **9** and press ENTER :

1 DATA C

Calling names can be entered in any order.

## Configuration for Terminal or PC Operation

It is preferable to enter long strings of characters into fields using a terminal. The characteristics of the serial port, when used for instrument control from a terminal or terminal emulator, are determined by settings on the Test Set's I/O CONFIGURE screen.

Set the following:

- **Serial In** to **Inst**
- **IBASIC Echo** to **On**
- **Inst Echo** to **On**

Set the remaining configuration entries to match the settings of your terminal or PC program.

### Equivalent Front-Panel Control Characters

The following [table 8](#) lists the terminal/computer keystrokes that equate to front-panel controls. *Each equivalent character must be preceded by the Escape key.*

For example, to remotely access the CONFIGURE screen, you type Esc, C on your terminal/computer. (Be sure to use upper-case C for this example.)

Alternate sequences for 5 commonly-used functions are also available. Hold down the Ctrl (control) key and select the corresponding key for the desired function. (Example: Ctrl/H moves the cursor to the left one space.)

ENTER - ^J or ^M

CANCEL - ^C

BACKSPACE - ^H

KNOB\_TURN\_CW - ^R

KNOB\_TURN\_CCW - ^L

**Table 8                      Equivalent Front-Panel Control Characters**

| Function      | Equiv. ESC Char. | Function   | Equiv. ESC Char. | Function         | Equiv. ESC Char. |
|---------------|------------------|------------|------------------|------------------|------------------|
| CANCEL        | !                | SAVE       | G                | PRESET           | i                |
| PERCENT MHZ_V | (                | REF_SET    | J                | INCR_DIV_10      | j                |
| S_KHZ_MV      | )                | METER      | K                | INCR_SET         | k                |
| BACKSPACE     | -                | AVG        | L                | INCR_TIMES_10    | l                |
| ENTER         | .                | LO_LIMIT   | M                | DOWN             | m                |
| RELEASE       | 0                | HI_LIMIT   | N                | UP               | n                |
| K1            | 1                | E          | R                | SEVEN            | o                |
| K2            | 2                | F          | S                | EIGHT            | p                |
| K3            | 3                | B          | U                | NINE             | q                |
| K4            | 4                | C          | V                | FOUR             | r                |
| K5            | 5                | D          | W                | FIVE             | s                |
| K1_PRIME      | 6                | A          | X                | SIX              | t                |
| K2_PRIME      | 7                | EEX        | Z                | ONE              | u                |
| K3_PRIME      | 8                | YES_ON_OFF | [                | TWO              | v                |
| ASSIGN        | 9                | NO_PPM_W   | ]                | THREE            | w                |
| KNOB_TURN_CCW | <                | RX         | a                | ZERO             | x                |
| KNOB_TURN_CW  | >                | TX         | b                | POINT            | y                |
| MSSG          | A                | DUPLEX     | c                | PLUS_MINUS       | z                |
| HELP          | B                | PREV       | d                | OHM_PCT_DEL_DBUV | {                |
| CONFIG        | C                | TESTS_MAIN | e                | DB_GHZ_DBM       |                  |
| HOLD          | D                | LOCAL      | f                | MS_HZ_UV         | }                |
| PRINT         | E                | RECALL     | g                |                  |                  |
| ADRS          | F                | MEAS_RESET | h                |                  |                  |

---

## Disks

### Initializing a Disk

If you are starting with a blank disk, you will have to initialize it to the format you have chosen. Disk drives require specific commands to perform initialization. The Test Set's IBASIC commands to initialize some disks are described here. You should verify that the drive you are using can be controlled by the Test Set and that you are initializing a disk using a drive or PC that has a compatible format.

#### To initialize a disk to LIF in an HP-IB disk drive:

1. Verify that the Test Set **Mode** on the I/O CONFIGURE screen is set to **Control**:
  - Press TESTS.
  - Select **IBASIC Cntrl** from the **SET UP TEST SET** list (or **IBASIC** from the **Test Function** field).
  - Position the cursor to the IBASIC command field and select it.
  - With the list of characters in the **Choices** menu, enter the following:

```
INITIALIZE ":,7xx,y"
```

where:

xx = the HP-IB address of the disk drive, and  
y = the unit number of the drive.

#### To initialize a disk to DOS in an HP-IB disk drive:

Follow the procedure for the LIF format, replacing the INITIALIZE statement with **INITIALIZE "DOS: ,7xx,y"**.

### Retrieving Data from a Disk

One way to retrieve the test results from a disk is to run an IBASIC program. A program to transfer data from a disk to a terminal emulator is given below. You can type it into the IBASIC command line from the terminal emulator.

Be sure your program is saved, because it will be deleted from programmable memory. The file name for this example is "RES". The disk address is 700, and the drive number is 0. The entire file name is **RES : , 700 , 0**.

**To enter the data  
retrieval program:**

1. Press TESTS.
2. Select **IBASIC Cntrl** from the **SET UP TEST SET** list (or **IBASIC** from the **Test Function** field).
3. Position the cursor to the IBASIC command field (large field in the upper part of the display) and select it. From the list of characters in the **Choices** field, enter the following IBASIC program statements and commands.
4. Enter **SCRATCH** to delete the previous IBASIC program. Be sure it's saved first.
5. Enter the following program:

```
10 DIM A$(120)
```

*Sets the string length to 120.*

```
20 ASSIGN @File TO "RES:,700,0"
```

*Opens a path to the file called "RES" (for results).*

```
30 ON ERROR GOTO 80
```

*Exits at end of file if an error is encountered.*

```
40 LOOP
```

*Extracts file contents.*

```
50 ENTER @File;A$
```

*Transfers part of the file to the string.*

```
60 OUTPUT 9;A$
```

*The string is output at the serial port.*

```
70 END LOOP
```

*Goes back to get more of the file.*

```
80 END
```

*End of the program.*

6. Press k1 (**Run**) to run the entered IBASIC program.

---

## Exiting a Program

Do not press RX or TX to exit the program. Selecting the RX TEST or TX TEST screen causes signal paths internal to the Test Set to be modified. If you exit the program to a screen other than RX TEST or TX TEST, the settings necessary to resume testing will be retained.

After you have made the manual settings you want, press the DUPLEX key as a last step before continuing the software. This will cause the Test Set to be properly set up.

Another way to safely exit is to:

1. Press CANCEL.
2. Press DUPLEX.
3. Press SHIFT SAVE.
4. Using list of characters in the **Choices** menu, enter a register name or number.
5. Select **Done**.
6. Operate the Test Set manually.
7. Press RECALL.
8. Choose the name of the saved setup.
9. Press TESTS.
10. Press k2 (**Continue**).



---

## HP-IB Control Annunciators

The words, letters, and symbols at the top right corner of the CRT display indicate these conditions:

- **R** indicates remote operation from an external controller or IBASIC program in the Test Set. This letter will be displayed while the software is running.
- **L** indicates that the Test Set is listening, and is ready to receive a manual or remote command.
- **T** indicates that the Test Set is talking to another HP-IB device.
- **S** indicates that a service request has been generated.
- **C** indicates that the Test Set is currently an active controller. Control mode is set on the I/O CONFIGURE screen. The Test Set must be a controller if HP-IB peripherals are to be controlled.
- **\*** indicates that an IBASIC program is running, or that the IBASIC controller is executing a command.
- **?** indicates that an IBASIC program is waiting for a user response.
- **-** indicates that the IBASIC program is paused.
- **SHIFT** indicates that the SHIFT key was pressed, and that the next key entry will be shifted. (Press SHIFT again to clear).

---

## Logging

Logging is used to monitor all the commands from the HP 8921A/D to the base station and all the messages returning from the base station. These commands and messages may be displayed on the CRT or output to a printer.

### To enable the logging function:

1. Press TESTS.
2. Select **External Devices** from the **SET UP TEST SET** list (or **Edit Cnfg** from the **Test Function** field) .
3. **1 Insrt Ins** Press k1 .
4. Position the cursor to the **Inst#** field and select it.
5. Rotate the knob to the first vacant **Calling Name** field and select it.
6. Position the cursor to the **Calling Name** field and select it.
7. Enter L O G into the Calling Name field by:
  - a. rotating the knob and positioning the cursor beside L in the **Choices** field and selecting it.
  - b. repeating for O and G.
  - c. positioning the cursor to **Done** in the **Choices** field and selecting it.
8. Position the cursor to the **Addr** field and select it.
9. Choose output mode:
  - a. For CRT: Press 1 on the DATA keypad and press ENTER.
  - b. For HP-IB printer: Press 70x on the DATA keypad and press ENTER.
  - c. For serial printer: Press 9 on the DATA keypad and press ENTER.
10. Press TESTS to return to the TEST (Main Menu) screen.

---

### NOTE:

Logging occurs rapidly on the screen. To stop for inspection, press CANCEL. To continue, press the k2: (**2 Continue**).

---

---

## Memory Cards

Memory cards are inserted into the slot on the Test Set's front panel. The memory card is powered by the Test Set while it is inserted. Arrows printed on the memory card and the Test Set's front panel indicate the direction and orientation of card insertion.

Memory cards are used to store or retrieve the following:

- Software code
- An HP-supplied Procedure, containing:
  - A default TEST sequence
  - Default test parameter values
  - Default pass/fail limit (specification) values
- A Library file
- Procedures you make, optimized for your application
- Data collection files
- Channel Information
- User defined keys

Two types of memory cards are available:

- Static Random Access Memory (SRAM)
- One-Time Programmable (OTP)

SRAM cards have read and write capability. Once programmed, OTP cards have read-only capability.

The software memory card can be removed after the program is loaded into the Test Set memory. The program will remain in memory after a power-down/power-up cycle, until a new program is loaded. Loading a new program will replace the existing program.

## SRAM Memory Cards

A Static Random Access Memory (SRAM) Card can be used to store test results and procedures you make. The following parts can be used.

**Table 9**                      **SRAM Memory Card Part Numbers**

| <b>Memory</b> | <b>Part Number</b> |
|---------------|--------------------|
| 32 kilobytes  | HP 85700A          |
| 128 kilobytes | HP 85702A          |
| 256 kilobytes | HP 85704A          |
| 512 kilobytes | HP 85705A          |

SRAM memory cards use a lithium battery (part number CR 2016 or HP part number 1420-0383). Programs and data will be retained for over one year if the memory card is stored at 25° C. The memory card is powered by the Test Set while it is inserted. Replace the battery while the memory card is inserted into a powered-up test set. To retain data and programs, it should be replaced annually. See the *HP 8921A/D User's Guide*. The write-protect switch on an SRAM memory card will write protect the card when it is set toward the outside of the card.

## Memory Card Storage Space

Procedures use 12-16 records each. A Library uses 20-35 records. A single library must be included on the card. A record is 256 bytes. Approximately 11 kilobytes of overhead is required on each card.

Use the following formula to estimate the storage space needed:

$$\text{Storage Space (in kilobytes)} = (\text{Number of Procedures} \times 4.1) + 20$$

For example, if you want to save ten different procedures, you will need 61 kilobytes of memory. The 64 kilobyte or 128 kilobyte card is sufficient.

The storage space you need for data collection depends on the number of test results that are saved. You will need approximately 4 kilobytes per page of test results that you save. A page of test results is about 57 lines of CRT or printer output.

The storage space of smaller SRAM cards can be quickly used. If you are collecting large quantities of data, data collection using a PC or printer may be preferable.

## Initializing a Memory Card

There are several ways to initialize a memory card using this software. One method which is not dependent upon your firmware revision is to run the Memory Card Initialization Test (TEST 02). See the description of "[TEST\\_02 - Memory Card Initialisation](#)" in chapter 7.

You may also initialize memory cards using the **Save/Delete Procedure** screen. However, this is only available on test sets with firmware above revision A.14.00.

- Press TESTS.
- Select **Save/Delete Procedure** from the **CUSTOMIZE TEST PROCEDURE** list.
- Insert the SRAM card in the slot on the front panel. (Make sure the switch on the card is not in the write-protected position).
- Press k3 (**Init Card**).
- Press Yes if you want to continue.

If you have firmware below revision A.14.00, there are two other methods described below in which you may initialize the card and select the format. If you have a terminal emulator attached to the Test Set, you can type a command into the IBASIC command line. A second way to initialize a card is to run the ROM program RAM\_MNG.

**To initialize an SRAM card using IBASIC**

1. Press TESTS.
2. Select **IBASIC Cntrl** from the **SET UP TEST SET** list (or **IBASIC** from the **Test Function** field).
3. Position the cursor to the IBASIC command line and select it.
4. Using the list of characters under the **Choices** menu, enter the following IBASIC command:

For LIF format: **INITIALIZE ":INTERNAL"**

For DOS format: **INITIALIZE "DOS:INTERNAL"**

#### To initialize an SRAM card using RAM\_MNG

1. Press TESTS.
2. Position the cursor to the **Select Procedure Location** (or **Location**) field and select it.
3. From the **Choices** menu, select **ROM**.
4. Position the cursor to the **Select Procedure Filename** (or **Procedure**) field and select it.
5. From the **Choices** menu, select **IB\_UTIL** (or **RAM\_MNG**).
6. Press k1 (**Run Test**).
7. Follow the displayed instructions.

---

**NOTE:** Loading RAM\_MNG will delete any procedure or program in memory.

#### Retrieving Data from a Memory Card

The easiest way to retrieve test results after they have been saved on an SRAM memory card is to run the Data Collection File Transfer Test (TEST 08). See the description of "[TEST\\_08 - GN Data Collection File Transfer](#)" in [chapter 7](#).

Alternatively, a program to transfer data from a memory card to a terminal emulator is listed below. You can type the program lines into the IBASIC command line from a terminal emulator. See "[Configuration for Terminal or PC Operation](#)" on [page 171](#).

**To enter the data retrieval program:**

1. Press TESTS.
2. Select **IBASIC Cntrl** from the **SET UP TEST SET** list (or **IBASIC** from the **Test Function** field).
3. Position the cursor to the IBASIC command field (large field in the upper part of the display) and select it. From the list of characters in the **Choices** field, enter the following IBASIC program statements and commands.
4. Enter **SCRATCH** to delete the previous IBASIC program. Be sure it's saved first.
5. Enter the following program:

```
10 DIM A$(120)
```

*Sets the string length to 120.*

```
20 ASSIGN @File TO "RES:INTERNAL";FORMAT ON
```

*Opens a path to the memory card file called "RES" (for results).*

```
30 ON ERROR GOTO 80
```

*Exits at end of file if an error is encountered.*

```
40 LOOP
```

*Extracts file contents.*

```
50 ENTER @File;A$
```

*Transfers part of the file to the string.*

```
60 OUTPUT 9;A$
```

*The string is output at the serial port.*

```
70 END LOOP
```

*Goes back to get more of the file.*

```
80 END
```

*End of the program.*

6. Press k1 (**Run**) to run the entered IBASIC program.



---

**NOTE:**

**Difference between Run and Run Test**

The USER (**Run**) key, assigned as a default key on the TESTS (IBASIC Controller) screen, will start an IBASIC program that is resident in the Test Set's memory. The USER (**Run Test**) key, assigned as a default key on the other TESTS screens, will load and run the program that is called from the **Select Procedure Filename** and **Select Procedure Location** entries on the TESTS (Main Menu) screen.

---

---

## Parameters

Parameters are values you enter that optimize your use of the test software. Many of the parameters are determined by examining your test needs.

Default values are set into the software. Some of these values are derived from standard methods of measurement and some are derived from the industry standard requirements. Load a Procedure and select the **Test Parameters** screen from the **CUSTOMIZE TEST PROCEDURE** list, to see the default values.

You should verify that parameters are properly set after you select the tests to be placed in your procedure.

Parameters remain in battery-backed-up memory until you select a procedure to run. If you wish to prevent them from being lost when a new procedure is selected, you will have to save them in a procedure. See "[Saving a Procedure](#)" on [page 195](#).

To print the parameters list, see "[To print TESTS screens](#)" on [page 194](#).

### To edit a parameter value:

1. Press TESTS.
2. Select **Test Parameters** from the **CUSTOMIZE TEST PROCEDURE** list (or **Edit Parm** from the **Test Function** field).
3. Position the cursor to the **Parm#** field and select it.
4. Rotate the knob to the desired parameter number and select it.
5. Position the cursor to the **Value** field and select it.
6. Enter the desired value using the DATA keypad and press ENTER.
  - Use the ← key to backspace.
  - a. Press CANCEL to cancel entries and retain the old value.
7. Press k5 (**Main Menu**) (or TESTS) to return to the TESTS screen.

---

## Pass/Fail Limits (Specifications)

Pass/Fail Limits are values you enter that set passing limits for tests. Default values are available in the test software. They have been derived from standard methods of measurement.

Pass/Fail Limits do not have to be changed when you select a test or change the tests in your procedure. Each test has pass/fail limits that apply to it.

You should verify that pass/fail limits are properly set after you select the tests to be placed in your procedure. Lists of the pass/fail limits used by each of the tests are contained in the "[Test Descriptions](#)" in [chapter 7](#) of this manual. A lock is provided to prevent access to the pass/fail limits. See "[Securing a Procedure](#)" on [page 198](#).

Pass/fail limits remain in the Test Set's battery-backed-up memory until you select a procedure to run. If you wish to prevent pass/fail limits from being lost when a new procedure is selected, you will have to save them in a procedure. See "[Saving a Procedure](#)" on [page 195](#).

To print the pass/fail limits list, see "[To print TESTS screens](#)" on [page 194](#).

### To edit a pass/fail limit value:

1. Press TESTS.
2. Select **Pass/Fail Limits** from the **CUSTOMIZE TEST SET** list (or **Edit Spec** from the **Test Function** field).
3. Position the cursor to the **Spec#** field and select it.
4. Rotate the knob to the desired pass/fail limit number and select it.
5. Position the cursor to the **Lower Limit** or the **Upper Limit** field and select it.
6. Enter desired value using the DATA keypad and press ENTER.
  - a. Use the ← key to backspace.
  - b. Press CANCEL to cancel entries and retain the old value.
7. Position the cursor to the **Check** field and select it.
8. From the **Choices** menu, select the combination of upper and lower limits to be checked.

---

## Pausing or Stopping a TEST

To pause the program, press CANCEL.

To stop the program, press SHIFT then CANCEL. This performs an IBASIC RESET operation.

---

### **NOTE:**

#### **Changing Settings while Paused**

If you make changes to instrument settings while the program is paused, subsequent operation may be unpredictable. Error messages may or may not be displayed. See "[Exiting a Program](#)" on page 176.

---

### **To continue a paused program:**

1. Press TESTS.
2. Press k1 (**C**ontinue).

The test time is displayed when the test is completed. This time includes the time that the program is paused and the time that it is waiting for connection and inputs to be made. If you are testing through midnight, the test time will not display properly.

---

## Printing

You can print any of the following:

- Test results
- TESTS screens
  - "External Devices" (Edit Cnfg)
  - "Order of Tests" (Edit Seqn)
  - "Channel Information" (Edit Freq)
  - "Pass/Fail Limits" (Edit Spec)
  - "Test Parameters" (Edit Parm)

**How to Print (task list)** There are five basic steps to printing listed below. A detailed description of each of these steps is at the end of this section.

1. Check to see if your printer is supported by the Test Set (see "[Supported Printers](#)" on [page 189](#)).
2. Determine if your printer requires serial, parallel, or HP-IB connection. Connect the printer to the appropriate port on the Test Set (see "[Printer Connection](#)" on [page 190](#)).
3. Configure the Test Set for your printer and its interface (see "[Configuring the Test Set for Printing](#)" on [page 192](#)).
4. Instruct the Test Set what to print (see "[To print test results](#)" on [page 193](#)).

## Supported Printers

- HP ThinkJet printer
- HP QuietJet printer
- HP PaintJet printer
- HP DeskJet printer
- HP LaserJet printer
- Epson FX-80 printer
- Epson LQ-850 printer

If you do not have one of these printers, consult your printer's manual for the correct printer settings to emulate one of the supported printers.

## Printer Connection

### HP-IB Connection

An HP-IB printer can be connected to the Test Set's rear-panel HP-IB connector with an HP-IB cable.

### Serial Connection

A serial printer can be attached to the serial port. See [figure 4](#). Use the following RJ-11 pins for this connection.

- RJ-11 Pin 2 - Test Set Receive Data
- RJ-11 Pin 4 - Ground
- RJ-11 Pin 5 - Test Set Transmit Data





Figure 4 Test Set RJ-11 Serial Port Connections

**NOTE:** To connect a serial printer and the UUT to the Test Set use a single RJ-11 to dual RJ-11 adapter (HP part number 08921-61031). Connect the single end of the adapter to the RJ-11 connector on the rear panel of the Test Set and then connect the serial printer and the UUT RJ-11 cables to either of the ports on the dual end.

**Parallel Connection**

A parallel printer can be attached to the parallel port. Use the following [figure 5](#) for pin information.



**Figure 5 Test Set Parallel Port Connections**

## Configuring the Test Set for Printing

If using a serial printer, you cannot use the serial port for other connections at the same time, such as Data Collection (saving test results). Serial port connections are shown earlier in this section.

### To Setup Printer

---

**NOTE:** The use of the **Printer Setup** screen is not yet available with this version of software (A.xx.xx). To setup a printer, use the following procedure.

---

1. Press TESTS
2. Select **External Devices** from the **SET UP TEST SET** list (or **Edit Cnfg** from the **Test Function** field).
3. Position the cursor to the **Inst#** field and select it.
4. Rotate the knob until an empty **Calling Name** field appears, and select it.
5. Position the cursor to the **Calling Name** field and select it.
6. Using the list of characters in the **Choices** menu, enter the word **Printer**. Select **Done** when complete.
7. Position the cursor to the **Model** field and select it (optional).
8. Using the DATA keypad, enter the Model # and press ENTER.
9. Position the cursor to the **Addr** (address) field and select it.
10. Using the DATA keypad, enter **9** for serial printers, **15** for parallel printers, or **70X** for HP-IB printers, then press ENTER. .
11. Position the cursor to the **Options** field (directly under **Calling Name**) and select it.
12. Using the list of characters from the **Choices** menu, the following commands may be entered. Separate the commands with commas (example; **LN=60 , START , END**)
  - a. **LN** equals the number of printed lines per page.
  - b. **START** causes a form feed at the start of each printout.
  - c. **END** causes a form feed at the end of each printout.
13. From the **To Screen** menu, select **More**.
14. From the **Choices** menu, select **IO CONFIG**.



15. For Serial Printers:

- a. Set the **Serial Baud** field and other serial communications fields listed under it to correspond to your printer's configuration.

16. For HP-IB Printers:

- a. Position the cursor to the **Mode** field and select it.
- b. From the **Choices** menu, select **Control**.
- c. Position the cursor to the **Print Adrs** field and select it.
- d. Rotate the knob and select the HP-IB address of your printer.
- e. Position the cursor to the **Print To** field. Pressing knob will toggle the underlined selection. Select to underline **HP-IB**.

17. Press TESTS to return to the TESTS screen.

**To print test results**

1. Make sure that your printer is properly connected and configured as explained earlier in this section.
2. Press TESTS.
3. Access the **Test Execution Conditions** either by selecting it from the **SET UP TEST SET** list (fw above rev A.14.00) or by positioning the cursor to the middle portion of the TESTS screen (fw below rev A.14.00).
4. Position the cursor to the **Output Results To:** field (or the **Output Destination** field). Pressing knob will toggle the underlined selection. Select to underline **Printer**.
5. Position the cursor to the **Output Heading** field and select it.
6. Using the list of characters in the **Choices** menu, enter a printout heading (optional). Select **Done** when the heading is complete.

**To print TESTS screens**

TESTS screens include:

- External Devices ("Edit Cnfg")
- Order of Tests ("Edit Sequence")
- Pass/Fail Limits ("Edit Specifications")
- Test Parameters ("Edit Parameters")

The same general process is used to print the information for all of the above TESTS screens.

1. Make sure that your printer is properly connected and configured as explained earlier in this section.
2. Press TESTS.
3. Select the TESTS screen you desire.
4. (**Print All**) and select it.
5. Press TESTS to return to the TESTS screen.

---

## Procedures

A procedure is a collection of test parameters, pass/fail limits and a testing order, saved in a file that customizes the test software to a specific application. You may save the file on a memory card or disk.

You do not have to save a test sequence in a procedure. Each test can be stand-alone if desired. After you choose a procedure, you can choose which of the tests you want to run.

When you save a procedure you will only be saving test parameters, pass/fail limits and a testing order. The memory card or disk must also contain a library file. A library file contains the names of all of the test parameters, pass/fail limits and tests that are in the test software. The library you use will be the library that is supplied with your software. When you save your procedure, the library will be automatically saved on the same card or disk.

The procedure(s) supplied with your software will be listed in the **Choices:** column when you select the **Select Procedure Filename:** (or **Procedure**) field. Procedures will be displayed if your software memory card is plugged in.

## Saving a Procedure

After you have set up the test software you can save the setup to an SRAM memory card, disk, or internal RAM memory by doing the following.

The memory card or disk you use must be initialized before its first use. See ["Initializing a Memory Card" on page 181](#) or ["Initializing a Disk" on page 173](#). If you are using a disk drive, you may have to enter the **External Disk Specification** into the TESTS **External Devices** screen (or **Edit Cnfg** screen). It will be used when the **Select Procedure Location:** field on the TESTS screen is **Disk**.

- To save a procedure:**
1. Press TESTS.
  2. Select **Save/Delete Procedure** from the **CUSTOMIZE TEST PROCEDURE** list (or **Proc Mngr** from the **Test Function** field).
  3. Position the cursor to the **Select Procedure Location** (or **Location**) field and select it.
  4. From the **Choices** menu, select the desired location. The media must be initialized before a file can be saved. To initialize an SRAM card (HP 8921A,D firmware above revision A.14.00 only, otherwise see "[Initializing a Memory Card](#)" on page 181):
    - a. Insert card in the slot on the Test Set's front panel.
    - b. Press k3 (**Init Card**)
    - c. Press **Yes**. Note: this will delete any procedures or programs from memory.To initialize a RAM disk, see "Memory Cards/Mass Storage" in the *HP 8920 Programmer's Guide*.
  5. Position the cursor to the **Enter Procedure Filename** (or **Procedure**) field and select it.
  6. From the list of characters in the **Choices** menu, enter a filename. Filename must be nine characters or less. When filename is complete, position cursor to **Done** and select it. Procedure filenames that already exist on the card will appear at the top of the list of characters.
  7. If you selected **Card**, insert an initialized memory card into the slot on the Test Set's front-panel.
  8. Verify that the card or other media is not write-protected. See "[Memory Cards](#)" on page 179.
  9. Position the cursor to the **Enter Description for New Procedure** (or **Comment for new procedure**) field and select it. From the list of characters in the **Choices** menu, enter comments. When the comments are complete, position the cursor to **Done** and select it.
  10. Position the cursor to the **Procedure Library** (or **Library for new procedure**) field and select **Current** (Current underlined). The name of the Library is displayed on the TESTS screen.
  11. Position the cursor to the **Code Location** (or **Program location for new procedure**) field and select it.

From the **Choices** menu, choose memory **Card**, **ROM**, **RAM** or **Disk**. When a procedure is run, the test system will look in this location for a code file if it is not resident in the Test Set's battery-backed-up memory. This location will usually be the software memory card.
  12. Press k1 (**Save Proc**) (or position the cursor to the **Action** field and select **Make Procedure**). A procedure will be saved at the location you chose.

## Loading a Procedure

A procedure can be loaded from storage media into the Test Set's battery-backed-up memory by doing the following.

- To load a procedure:**
1. Press TESTS.
  2. Position the cursor to the **Select Procedure Location** (or **Location**) field and select it.
  3. From the **Choices** menu, choose the desired location where the procedure is stored and select: **Card, ROM, RAM** or **Disk**.
  4. Position the cursor to the **Select Procedure Filename** (or **Procedure**) field and select it.
  5. From the **Choices** menu, choose the procedure file that you want to load.
  6. Read the **Description** (or **Comment**) field to ensure that the loaded procedure file is the one you want.

## Deleting a Procedure

Procedures can be removed from an SRAM memory card, disk or RAM by doing the following.

- To delete a Procedure:**
1. Press TESTS.
  2. Select **Save/Delete Procedure** from the **CUSTOMIZE TEST PROCEDURE** list (or **Proc Mngr** from the **Test Function** field).
  3. Position the cursor to the **Select Procedure Location** (or **Location**) field and select it.
  4. From the **Choices** menu, select the desired location.
  5. Position the cursor to the **Enter Procedure Filename** (or **Procedure**) field and select it.
  6. From the **Choices** menu, select the name of the procedure you wish to delete.
  7. Press k2 (**Del Proc**) (or position the cursor to the **Action** field and select **Delete Procedure**).
  8. Press Yes if you wish to continue.

## Securing a Procedure

After you have set up your test software with a testing order, channel information, test parameters, and pass/fail limits, you may wish to secure it. This operation will prevent the viewing and changing of those functions. You can select the items you wish to secure or un-secure. An IBASIC ROM program is stored in the Test Set's firmware to do this.

You can secure the procedure that is supplied with the test software. It is shipped un-secured.

After you make a procedure, you can secure it.

### To secure a Procedure:

1. Press TESTS.
2. Position the cursor to the **Select Procedure Location** (or **Location**) field and select it.
3. From the **Choices** menu, select **ROM**.
4. Position the cursor to the **Select Procedure Filename** (or **Procedure**) field and select it.
5. From the **Choices** menu, select **IB\_UTIL** (or **SECURE\_IT**).
6. Press k1 (**Run Test**).
7. Select the location of the procedure you want to secure: k1 memory (**Card**) or k2 (**RAM**).

---

### NOTE:

RAM refers to the RAM Disk memory within the Test Set. Before selecting RAM, you must initialize the RAM as a disk. See "[Initializing RAM Disks](#)" on page 201.

8. Proceed with the on-line instructions. You may wish to secure only one of the items, such as pass/fail limits.
9. When you are prompted to enter the **pass number**, enter any sequence of numerals 0 through 9 using the DATA keypad. Enter 9 digits or less.

**To un-secure a procedure:**

To un-secure a procedure, you must know the **pass number**.

1. Press TESTS.
2. Position the cursor to the **Select Procedure Location** (or **Location**) field and select it.
3. From the **Choices** menu, select **ROM**.
4. Position the cursor to the **Select Procedure Filename** (or **Procedure**) field and select it.
5. From the **Choices** menu, select **IB\_UTIL** (or **SECURE\_IT**).
6. Press k1 (**Run Test**).
7. Select the location of the procedure you want to un-secure: k1 memory (**Card**) or k2 (**RAM**).
8. Enter the name of the procedure you wish to un-secure.
9. If the procedure has any item secured, you will be asked for the **pass number**.
10. Proceed with the on-line instructions. Select the items you wish to un-secure.
11. When you are prompted, enter the **pass number** using the DATA keypad.

---

## RAM

RAM disk is a section of internal memory that acts much like a flexible disk. Programs can be stored, re-stored, erased, and retrieved.

The RAM disk is partitioned into four separate volumes; 0-3. Each volume is treated as a separate 'disk'. You can also specify the size of each disk in 256-byte increments.

The four RAM disk volumes are designated **:MEMORY, 0, 0** to **:MEMORY, 0, 3**. For example, to catalogue the contents of RAM disk volume '0' from the IBASIC Cntrl screen, enter

```
CAT " :MEMORY, 0, 0"
```

Volume 0's contents can be viewed and loaded from the three screens mentioned at the beginning of this section. Volumes 1, 2, and 3 can *only* be accessed from the IBASIC Controller.

---

### **NOTE:**

#### **RAM Disk Erasure**

Any existing programs or formatting on RAM is erased if you use the **RAM\_MNG** or **COPY\_PL** ROM programs, or the SERVICE screen's **RAM Initialize** function.

Therefore, you should only use RAM disks for short-term storage of files.

---



## Initializing RAM Disks

Each RAM disk volume must be initialized before it can be used. Volume 0 can be initialized using the RAM\_MNG procedure stored on the internal ROM's **IB\_UTIL** menu. Volumes 1, 2, and 3 must be initialized from the **IBASIC Cntrl** screen.

The optional 'volume size' in the following procedure lets you specify the memory area set aside for each disk in 256 byte blocks.

Follow these steps to initialize volumes 1, 2, or 3:

1. Press **TESTS**.
2. Select **IBASIC Cntrl** from the **SET UP TEST SET** list.
3. Position the cursor to the data entry field and select it.
4. Using the list of characters from the **Choices** menu, enter the following command:

```
INITIALIZE ":MEMORY,0,<volume number 1-3>",<volume size>
           or
INITIALIZE ":MEMORY,0,1",50
```

---

## **Saving Tests Results**

See "[Data Collection \(Saving and Retrieving Test Results\)](#)" on page 164.

---

## Serial Port

This 6-pin, RJ-11 serial port is used to input and output serial data. Serial data is used for entering programs, printing, and for sending test results to a connected controller, disk drive, or terminal.

### Operating Considerations

The two independently controllable serial ports have fixed select codes. Select code 9 is assigned to the primary serial port and select code 10 to the “B” serial port. The primary serial port (select code 9 ) configuration settings can be made from either the I/O CONFIG screen or from an IBASIC program. The “B” serial port configuration settings can only be made from an IBASIC program. The two serial ports use a three wire connection format:

Primary Serial Port (select code 9):

- Transmit (pin 5)
- Receive (pin 2)
- Ground (pin 4)

B Serial Port (select code 10):

- Transmit B (pin 6)
- Receive B (pin 1)
- Ground (pin 4)

The single ground pin is shared by both ports (see [figure 4, "Test Set RJ-11 Serial Port Connections," on page 190](#)). The IBASIC Controller can send and receive data from either port by using its assigned select code. The primary serial port (select code 9) is used exclusively by the Test System for printing screen dumps to a serial printer. The “B” serial port (select code 10) is used exclusively by the software for control of the UUT.

Use an RJ-11/25 pin RS-232 adapter (HP p/n 98642-66508) and RJ-11 cable (HP p/n 98642-66505) to connect the Test Set to a serial printer, terminal or computer.

To connect a serial printer and the UUT simultaneously use a single RJ-11 to dual RJ-11 adapter (HP p/n 08921-61031). Connect the single end of the adapter to the RJ-11 connector on the rear panel of the Test Set and then connect the serial printer and the UUT RJ-11 cables to either of the ports on the dual end.

---

**NOTE:**

**RJ-11 Connectors**

RJ-11 cables and adapters can be wired several ways. If you buy a cable or adapter other than the HP parts listed, verify the connections for the pins indicated in the following [table 10](#) before connecting cables to the instruments.

The following [table 10](#) lists connections for Transmit, Receive, and Ground pins (address 9).

**Table 10**                      **Connections for Transmit, Receive, and Ground Pins**

| <b>HP 8921A/D<br/>RJ-11 Serial Port</b> |    | <b>Terminal/PC<br/>25-Pin RS-232</b> |    | <b>Terminal/PC<br/>9-Pin RS-232</b> |
|---|----|--------------------------------------|----|-------------------------------------|
| Pin 2 (RX)                              | to | pin 2 (TX)                           | or | pin 3 (TX)                          |
| Pin 5 (TX)                              | to | pin 3 (RX)                           | or | pin 2 (RX)                          |
| Pin 4 (GND)                             | to | pin 7 (GND)                          | or | pin 5 (GND)                         |




Figure 6 Test Set RJ-11 Serial Port Connections

---

## Test Execution Conditions

In some situations, you may wish to change the way the software works when a test result is obtained. **Test Execution Conditions** allow you to do this.

**Test Execution Conditions** are accessed from the **SET UP TEST SET** list on the TESTS (Main Menu) screen. Press TESTS, then select **Execution Cond** to display them. (They are displayed directly on the main TESTS screen in firmware below revision A.14.00).

**Test Execution Conditions** are not retained after a power-down/power-up cycle.

The following **Test Execution Conditions** can be set as needed:

### Output Results To: (Output Destination)

You can select either: **Crt** or **Printer** Default:**Crt**

You can specify where test results are to be placed. If you select **Crt**, results will be displayed on the Test Set's CRT. If you select **Printer**, test results will be sent to the CRT and to a printer. You must connect and configure a printer if you select **Printer**. See "[Printing](#)" on page 189.

### Output Results For: (Output Results)

You can select either: **All** or **Failures** Default:**All**

You can specify if you want only the failed results to be displayed or printed. This will be useful if you generally do not print test results, and want to ensure that failed results are displayed or printed.

### Output Heading

You can use this field to enter a heading that will be printed or displayed.

Select the **Output Heading** field. Use the knob to choose and enter the characters that you want to appear in the heading.

Choose **Done** when you are finished.

### **If Unit-Under-Test Fails (If UUT Fails)**

You can select either: **Continue** or **Stop** Default: **Continue**

If you set this to **Stop**, and a pass/fail result is **F**, the program will stop.

### **Test Procedure Run Mode (Run Mode)**

You can select either: **Continuous** or **Single Step** Default: **Continuous**

You can make tests pause at certain times. If you set this to **Single Step**, the program will pause after a comparison is made between a test determination and the expected result. For example, tests will pause after the program compares the results to a specification. You can continue from the paused state by pressing k2 (**Continue**).

### **Autostart Test Procedure on Power-Up**

You can select either: **On** or **Off** Default: **Off**

You can set up the Test Set so that if the procedure was previously loaded, the procedure will be immediately executed when the test set is powered on.

---

## USER Keys

When you are using the Test Set, you will see the following USER keys assigned appear at times in the top right corner of the display. These keys are assigned to the hard keys k1 through k5. In many cases, these keys can be used as “shortcuts” instead of positioning the cursor and selecting. USER keys are sometimes referred to as softkeys.

**Clr Scr** clears the Test Set’s CRT display.

**Continue** continues the program after it has been paused.

**Delet Stp** is used to edit items in a test sequence. When you press this key, the test in the displayed sequence that has its **Step #** highlighted (inverse video) will be deleted. The tests that follow in the sequence will be scrolled up by one step.

**Del Proc** is used to delete the selected procedure. When you press this key, you will be prompted to verify the command by pressing Yes.

Press **Done** when you want to exit a test or have completed a task. The program will continue if there is a next test in the sequence or if there are additional program steps in the test being run.

**Help** provides information on how to use the current TEST screen.

**Init Card** is used to initialize a memory card. Before you press this key, verify that the card is inserted correctly and not in the write-protected position.

**Insrt Stp** is used to enter items into a test sequence. When you press this key, the test in the displayed sequence that has its **Step #** highlighted (inverse video) will be copied into a new sequence location, immediately after the highlighted one. The tests that follow in the sequence will be scrolled down by one step. This key does nothing if there are no items in the sequence. Choose a test before using this key to insert another.

**Main Menu** is used to return to the main TESTS screen. The same result is achieved by pressing TESTS.

**Page Up**\Page Down are used to quickly display items in the list when some of the items won’t fit on the screen.

**Run** starts an IBASIC program that has been loaded into the Test Set’s memory.



**Run Test** loads and runs the program that is called from the procedure that has been entered into the TESTS screen **Select Procedure Filename:** entry. If the program is already loaded into the Test Set's memory, it will be started.

**Save Proc** is used to save the specified procedure.

**Sngl Step** steps the IBASIC program one line at a time. This is different from **Continuous/Single Step** run mode. See "**Test Execution Conditions**" on page 206.

**Stop Test** pauses the test software.

**Take It** causes the program to accept the setting of an adjustment, and proceed with the program. The test, determining if the adjustment is within limits, is ceased.

**Yes\No** are pressed when answering questions displayed on the Test Set's CRT display.



---

## Problem Solving

This chapter contains problem modules and error messages. Problem modules alphabetically list the location of the problem with a brief symptom (for example, Test Set Doesn't Power Up). Each problem module describes possible causes and corrections. The error messages section is located at the end of the chapter and provides a brief description of the message as well as possible corrective actions.

If a problem persists, call the HP Factory Hotline from anywhere in the USA (1-800-922-8920, 8:30 a.m. - 5:00 p.m. Pacific time).

---

**NOTE:** If the Test Set displays an error that states “One or more self-tests failed”, you have a hardware problem. In this case, refer to the Test Set’s *Assembly Level Repair* manual.

---

---

## Data-Collection Function Does Not Work

- Check that you have **DATA C** entered in the TESTS (**External Devices**) (or **Edit Config**) menu.
  1. Press TESTS.
  2. Select the **External Devices** screen, from the **SET UP TEST SET** list (or **Edit Config** from the **Test Function** field).
  3. Position the cursor to the **Calling Name** field, push the knob and enter:  
**DATA C.**
- Check the **Model** field, it should be kept empty since it is not used.
- Check the **Addr** (address) field to make sure the correct address is entered for where the data is to be stored.
  1. If data is to be stored on an SRAM memory card, enter “1” into the **Addr** field.
  2. If data is to be stored on an external computer through the Test Set’s RS-232 serial port (if available), enter “9” into the **Addr** field.
  3. If data is to be stored on an external disk drive over HP-IB, enter an address of “700” or greater into the **Addr** field.
- Check the **Options** field to make sure it is correctly set up:
  1. **For an external disk drive (LIF format) or an SRAM memory card:**
    - a. Enter **ASCII** for saving data as an ASCII file.
    - b. Enter **BDAT** for saving data as a Binary-Data file.
    - c. As an option, you may enter **REC=xxx**, where “xxx” is the number of records for each file. (*The software defaults to 80 records. However, if too small a record size is used, you’ll get an “End of file error” when the test is run.*)
  2. **For a DOS disk drive, you may keep the Options field empty, or you may enter any of the following key words:**
    - a. Enter **ASCII** for saving data as an ASCII file.
    - b. Enter **BDAT** for saving data as a Binary-Data file.
    - c. Enter **REC=xxx** for the file’s record size, where “xxx” is the number of records for each file. (*The software defaults to 80 records. However, DOS systems automatically change record size if it’s too small.*)
    - d. Enter a (**dot extension**) of 3 characters or less for the file name. For example, all model ABCD radio’s tested may be organized to have a “.ABC” file extension.
- Check the Test Set to make sure it’s in the controller mode *if you are using an external disk drive*.
  1. Access the I/O CONFIGURE screen from the **More** field in the **To Screen** menu.
  2. Position the cursor to the **Mode** field and select **Control**.

---

**NOTE:**

When the test operator is prompted to enter a file name where data is to be stored, the protocol for the mass-storage device being used must be followed.

Hierarchical directory paths are not allowed, and all files are created with "FORMAT ON".

Also, when initializing a disk, use the following format ("7xx" is the disk address, "y" is the device selector):

**DOS disk: INITIALIZE "DOS:CS80,7xx,y"**

**LIF disk: INITIALIZE ":,7xx,y"**

---

---

## Memory Space Problems

The program uses a substantial amount of the Test Set RAM space. If you see a message that indicates a memory problem, check the memory space that has been used.

### To determine the memory space used:

1. Load the program, if it is not already loaded, by pressing USER (**Run Test**) and waiting for the program display to appear.
2. Press SHIFT CANCEL to stop the program.
3. Press DUPLEX to exit the TESTS screen.
4. Press SHIFT SAVE.
5. Read the number in front of **free memory**.

If this number is a few percent or less, you may get an error message after saving additional set-ups to SAVE registers.

If you do not have sufficient memory space available, you may need to delete unnecessary save registers.

### To delete save\_recall registers:

1. Press DUPLEX.
2. Press RECALL.
3. Press ON/OFF to clear register.
4. Press the ON/OFF button again to answer **YES**.

---

## Printing Problems

- Check that the printer is turned on.
- Check that the HP-IB, parallel, or serial cable from the Test Set to the printer is connected.

**If have firmware below revision A.14.00 Or you are using software with Revision A.xx.xx**

1. Press TESTS.
2. Check that **Printer** was selected as the **Output Results To:** (or **Output Destination**) in the **Test Execution Conditions**.
3. Check that the Test Set is correctly configured for HP-IB, parallel, or serial printing:

**For a HP-IB printer:**

- a. Check that the printer's **Calling Name** is "PRINTER" and its address is correctly set up in the **External Devices** (or **Edit Cnfg**) screen.
- b. Check that the I/O CONFIGURE screen has been set up correctly:
  - i. Mode=Control
  - ii. Print To=HP-IB
  - iii. Print Adrs=address of your printer

**For a parallel printer:**

- a. Check that the printer's **Calling Name** is **PRINTER** and its address is set to **15** in the **External Devices** (or **Edit Cnfg**) screen.

**For a serial printer:**

- a. Check that the printer's **Calling Name** is **PRINTER** and its address is set to **9** in the **External Devices** (or **Edit Cnfg**) screen.
- b. Check that the I/O CONFIGURE screen has been set up correctly for the printer's baud rate, parity, and so forth.

Refer to the Test Set's *User's Guide* for details about configuring the printer.



---

## Test Results are Unexpected

If one or more tests fail unexpectedly, or you believe there is a problem with the way tests are running, check the settings that are used for the tests.

1. Press TESTS.
2. Select **Execution Cond** from the **SET UP TEST SET** list (HP 8920B and HP 8921A,D fw above rev A.14.00 only).
3. Position the cursor to the **Run Mode** field (in Test Execution Conditions) and select **Single Step**.
  - a. Run the test.
2. When the message **Press continue when ready** is displayed in the top line of the IBASIC CONTROLLER tests screen, press CANCEL to pause the IBASIC program.
4. From the **To Screen** menu, position the cursor to the desired instrument screen and select it.
5. After viewing the instrument settings, press PREV to return to the TESTS screen.

---

### **NOTE:**

Do not alter the instrument settings. The IBASIC program will not re-configure the settings when continue is executed. You can alter settings to experiment with the measurement, but they must be returned to their initial settings before leaving the instrument screen.

6. (**Continue**) Press k2 to return to the IBASIC controller.
7. Press k2 (**Continue**) to continue the program.

---

## Test Set Doesn't Power Up

Check the AC or DC power connection and the setting of the AC/DC switch on the rear panel. See the Test Set's *User's Guide*.

---

## Error Messages

Many error messages are coded into the Test Set firmware and test software. If the problem is related to Test Set operation, access the MESSAGE screen to see any messages that have occurred since the instrument was turned on. To do this, press the SHIFT then RX.

Many of the error messages are listed below, alphabetically, with a description of the problem and possible corrections. If you see a message that is not described here, press CANCEL, and then the MSSG key. Other related error messages may be displayed.

For a listing of additional error messages, see:

- the Test Set's *User's Guide*
- the Test Set's *Programmer's Guide*
- the Test Set's *Assembly Level Repair manual*

If you see an error message that contains a program line number, and it is not listed in this section, please write down the message with the line number and call the factory at 1-800-922-8920.

## Error Message Reference

**Base station failed to respond as expected to an attempt to program its state (frequency etc).**

### Program terminated

- Verify all equipment is powered on.
- Verify that the cable interfacing the Test Set's serial port to the base station's local control port is functioning. See Appendix A "[Cable Wiring Diagrams](#)" on page 225.
- Cycle the power to the base station.

**Base station failed to respond as expected to an attempt to download the local control program.**

### Program terminated

- Verify all equipment is powered on.
- Verify that the cable interfacing the Test Set's serial port to the base station's local control port is functioning. See Appendix A "[Cable Wiring Diagrams](#)" on page 225.
- Verify that the local control program has been stored on an SRAM memory card and is in the memory card slot on the Test Set's front panel. See [chapter 1, "Getting Started with FW Revision Above A.14.00," on page 19](#) or [chapter 2, "Getting Started with FW Revision Below A.14.00," on page 39](#) for the procedure to store the local control program.
- Cycle the power to the base station.

**Data collection address cannot be set to 10. Program stopped.**

The second serial port in the Test Set has an address of 10. It is used for base station control. The Serial port, having an address of 9, can be used for data collection. If you are collecting data to an HP-IB device, you have to enter all three digits of the address. For additional information, see "[Data Collection \(Saving and Retrieving Test Results\)](#)" in [chapter 8](#).

**Duplicate file. Over-write old file?**

A file name can only be used once. The entered file name has the same name as one that is already stored on the storage media. If you answer **Yes** to Over-write old file?, the old file will be over-written. Once a file is over-written, it is unretrievable. There is no back-up.

**Error 56 in (line number) File name is undefined.**

This message is displayed when the Test Set is unable to find a particular file on the memory card. If the message occurs at the beginning of transceiver testing, it is usually the FX1 file which is missing.

- Test 08 can be used to display a catalog of all files on a memory card.
- Test 03 can be used to transfer the FX1 file from a personal computer to a memory card.

**Error 80 during Procedure catalog. Catalog aborted.**

This message is displayed when the Test System is unable to load a Procedure from a memory card.

- Check that the card is properly inserted and has Procedures saved on it.

**ERROR 80 in (line number) Medium changed or not in drive Re-try?**

This message is displayed when the Test Set is unable to access valid files from a memory card.

- Check that the card is properly inserted and has Procedures saved on it.

**Error in data collection information on cnfg screen.**

This message is displayed if the file type or record number is not properly entered into the **External Devices** (or **Edit Configuration**) screen.

To access the **External Devices** (or **Edit Configuration**) screen:

1. Press TESTS.
2. Select **External Devices** from the **SET UP TEST SET** list (or **Edit Cnfg** from the **Test Function** field).
3. Verify that the entries are correct.

For additional information, see "[Data Collection \(Saving and Retrieving Test Results\)](#)" in chapter 8.

**HP-IB Command not accepted. Option not installed.** This message may be displayed when the software tries to control a non-existent Radio Interface Card or non-existent other Test Set option.

- Check the Test Set rear panel for the Radio Interface connector.
- Check which options are installed in the Test Set

---

**CAUTION:**

Loading this program into the Test Set memory will erase any other programs and Procedures you have loaded. If you have not already done so, save your setups to a Procedure on an SRAM memory card before loading the "LIST\_OPTS" program. See "**Procedures**" in **chapter 8** .

---

1. Press TESTS.
2. Position the cursor to the **Location** field and select it.
3. From the **Choices** menu, select **ROM**.
4. Position the cursor to the **Procedure** field and select it.
5. From the **Choices** menu, select **LIST\_OPTS**.
6. Press k1 (**Run Test**) to display the installed options.

**Printer address cannot be set to 10.**

The second Test Set serial port, Serial B, has an address of 10. The Serial port, having an address of 9, can be used for printing. If you are using an HP-IB printer, you need to enter all three digits of the printer address. See "**Printing**" in **chapter 8**.

**The Test Set must be configured in Control Mode. No other controllers may be on the HP-IB bus. Do you want to put the Test Set in Control Mode? Select desired softkey.**

The Test Set can be set to operate in the HP-IB **Control** mode or can be set to operate in the **Talk&Lstn** mode. This selection is made on the test Set I/O CONFIGURE screen. If the **External Devices** (or **Edit Cnfg**) screen has entries that require the Test Set to operate as a controller, the software will verify that the Test Set is configured properly. Answer the question **Yes** if you wish to have the entry on the I/O CONFIGURE screen changed.

**This software will not run with firmware revision (FW rev. #) presently installed in the Test Set. Consult software users manual for correct firmware revision. The Test Set must have a firmware revision A.08.00 or higher. To determine the revision of the firmware:**

- Press CANCEL or shift CANCEL to pause the program.
- Press SHIFT CONFIG to display the CONFIGURE screen.
- View the revision number of the firmware in the upper right corner of the display.

Contact the factory (1-800-922-8920) if you do not have the necessary revision. Firmware is installed in the Test Set by removing the instrument cover and replacing the EPROMS in the controller section, and in some cases, the EPROM on the signaling board.

#### **Timeout error from an external instrument.**

This message will be displayed if the Test Set tries to control a device on the HP-IB bus and is unable to do so for 5 seconds.

- Check cables.
- Verify that the HP-IB address and other setup conditions of your device are set properly.
- Verify entries made to the **External Devices** (or **Edit Cnfg**) screen.

#### **Timeout from printer at address (printer address). Retry?**

- Check the cable and the connections.





---

# A

---

## Cable Wiring Diagrams

The HP 11807B Option 052 software utilizes various cables when tests are run. So that new cables may be constructed the following diagrams show pin connections for interface cables that the software uses. Refer to [chapter 4, "Making Connections," on page 65](#) for the purpose of the cables.

| QUARTEPLUG TO RJ11/BNC<br>08921-61032 |    |    |
|---------------------------------------|----|----|
|                                       |    |    |
| FROM                                  | TO | TO |
| B2                                    |    | 1  |
| * A2 to A6                            |    |    |
| A2                                    |    | 2  |
| A4                                    | 1  |    |
| A6                                    | 4  |    |
| A8                                    | 6  |    |

| RJ11(M) TO DB25 (M) 08921-61039 |    |
|---------------------------------|----|
|                                 |    |
| FROM                            | TO |
| 5                               | 3  |
| 4                               | 7  |
| 3                               | NC |
| 2                               | 2  |

| RJ11(M) TO DB9 (F) 08921-61038 |               |
|--------------------------------|---------------|
|                                |               |
| FROM                           | TO            |
| 5                              | 2             |
| 4                              | 5             |
| 3                              | NC            |
| 2                              | 3             |
|                                | * 7 to 8      |
|                                | * 1 to 4 to 6 |

CONNECT1

\* indicates jumpered connection

**BPF** Band Pass Filter. A filter that increasingly rejects signals as their frequency increases and decreases outside of certain cutoff frequencies. In the test set, audio band pass filters are used to reduce the level of out-of-band signals during certain measurements.

**CANCEL** A key used to pause (stop) the IBASIC program running in the test set.

**card** Refers to the memory card containing the procedures for testing the base station.

**Choices** Refers to a field in the lower right of the test set screen that displays several possible functions for selection.

**Continue** Proceed with the IBASIC software program if it has been stopped (paused).

**cursor** Refers to the brightened region of the test set screen used to indicate the field/function currently being accessed.

**Del Step** A function to delete a step in the procedure.

**Disp Loc** A menu function which presents an assembly diagram that displays location of the adjustable component.

**Edit Cnfg (configuration)** Title of an test set screen that allows you to set up (configure) printers, PCs, disks...

**Edit Freq (frequency)** Function which allows you to edit the values of the test frequencies.

**Edit Parm (parameters)** Function

which allows you to edit the values of the test parameters. See also "parameters".

**Edit Seqn (sequence)** Function which allows you to select a single test and run it or to create your own sequence of tests.

**Edit Spec (specifications)** Function which allows you to edit the limits of the test specifications. See also "pass/fail limits".

**ESD** ElectroStatic Discharge - A transfer of electric charge from one place to another. Devices can be damaged by the energy transferred during the discharge.

**field** An area on the CRT with an inverse video display (**example**) where entries can be made.

**function** Refers to a particular field, feature, or operation of the test set.

**GN** Abbreviation for General. GN appears in some titles in the software and indicates that it relates to the general system, as opposed to a transmitter (TX) or receiver (RX).

**Help** A feature providing specific information about how to use the current screen in the TESTS environment. This feature is accessed by pressing k4 (**Help**) from any TEST screen. Note: this feature is only available in the HP 8921A,D firmware above revision A.14.00.

**HELP** A feature providing additional test set information accessed by pressing SHIFT, then TX (**HELP**) keys.

---

## Glossary

**highlight** Refers to the brightened region (cursor) of the test set screen used to indicate the field/function currently being accessed.

**HPF** High Pass Filter. A filter that increasingly passes signals as their frequency increases towards, and then is greater than, a certain cutoff frequency. In the test set, audio high pass filters are used to reduce the level of low frequency signals during certain measurements.

**IBASIC** Instrument BASIC is the computer language (code or software) used by the Test Sets' built-in controller. The IBASIC software is downloaded from the CARD into the Test Sets' RAM.

**initialize** The process of formatting a card or disk prior to storing data.

**key (USER keys)** Keys refer to any of the push buttons on the front panel. The USER keys are a specific grouping of keys labeled k1 to k5 which perform the associated numbered function in the action field located in the upper right of the screen. The USER keys are user programmable.

**knob** The large tuning dial for cursor control located in the center of the Test Sets' front panel. This knob is rotated to position the cursor on the screen and then pressed to select the particular field or function.

**library** A collection of the names of all of the parameters, specifications, and tests in the test software. The test software and the Test Set's firmware use the library, test software program code file, and a procedure to run a customized application program. A

library is stored as a file on a memory card or other mass storage with its associated procedure files.

**Location** Where to retrieve or save a particular testing procedure, for example, disk, CARD, RAM, PC, etc.

**LPF** Low Pass Filter. A filter that increasingly rejects signals as their frequency increases towards, and then is greater than, a certain cutoff frequency. In the test set, audio low pass filters are used to reduce the level of high frequency signals during certain measurements.

**measurement** A series of calculations on data measured by the test set. These calculations provide a value to be compared against pass/fail values that verify the performance of the unit-under-test.

**Main Menu** The screen accessed by pressing the TESTS key, or k5 (**Main Menu**). It is used to customize and execute (run) automated testing.

Also referred to as the "TESTS" screen.

**menu** The test set screen displays various tasks to be selected with the cursor control knob or the USER keys; this display is the menu.

**message** The upper portion of the test set screen is reserved for messages and prompts. Messages give an indication of the status of the test set, for example, **System initialization**.

---

## Glossary

**OTP** One Time Programmable (OTP) refers to a memory card on which code or data may only be stored once; similar to ROM.

**parameters** Entries you make for calibration data, base station characteristics, or test customization. They give you flexibility in the way you use the software. Default values for parameters are entered into the software.

**pass/fail limits** Pass/fail limits are the names of criteria verifying the performance of the unit-under-test. Usually, the associated measurement value must fall within the HI/LO limits of pass/fail values to verify performance of the unit-under-test. Default values in the test software have been derived from standard methods of measurement or from the unit-under-test requirements.

**pause** Using the CANCEL key pauses the running of IBASIC software and allows access to the keyboard functions. CONTINUE allows the software to proceed.

**peak+/- max** A detector in the test set that measures and computes the maximum of the absolute value of the positive and negative excursions of the measurement. For example, when an FM waveform with a +10 kHz and -9 kHz deviation is applied, 10 kHz will be displayed.

**PRESET** Sets the test set to its initial power-up state.

**procedure** A shortened label for test procedure. A procedure is a collection of channels, parameters, pass/fail limits, and

testing order, saved in a file, that customizes the test software to a specific application. Procedures are made by editing existing channels, parameters, pass/fail limits, and testing order, and saving the resulting files to a memory card, disk or internal test set RAM.

**prompts** The upper portion of the test set (inverse video field) is reserved for prompts and messages. The prompt directs the user to take some action. Messages give an indication of the status of the test set.

**RAM** Random Access Memory - The memory in the test set that is used to store program code and data. The test set RAM is battery-backed-up, retaining data and program code when the power is turned off.

**ROM** Read Only Memory

**Run Test** Directs the test set to load the program from the current procedure and begin testing (may take up to two minutes).

**SAT** Supervisory Audio Tone - A 5970 Hz, 6000 Hz, or 6030 Hz sine-wave signal that frequency modulates an AMPS cell site voice channel transmitter. The signal is transponded by the base station and is used to help determine RF path integrity.

**screen** Refers to the video display of the test set.

---

## Glossary

**select** To choose a particular field or function. Rotate the CURSOR CONTROL knob and position the highlighted cursor on the chosen field or function, then press the knob. An alternative method is to press the numbered USER key having the same number as displayed alongside the desired function.

**sequence** The method used in the test set to run one or more TESTs in a desired order. A sequence is entered using the TESTS (**Edit Sequence**) screen.

**SINAD** Signal plus Noise And Distortion divided by noise and distortion. A measurement result that determines the quality of an audio tone in the presence of noise and distortion. A 12 dB SINAD value is often used when measuring the receiver sensitivity.

**softkey** The name of the set of keys next to the CRT display that can be assigned to certain special actions or fields. The keys are also called USER keys.

**specifications** Specifications are the names of criteria verifying the performance of the base station (used in fw below rev A.14.00. See also "pass/fail limits". The specification value may be changed by using the **Edit Spec** function. Usually the associated measurement value must fall within the HI/LO limits of specification values to verify performance of the base station. Default values in the test software have been derived from standard methods of measurements.

**SRAM** Static Random Access Memory - A data storage device. SRAM memory cards can be used with the test set to save programs and test results.

**Step#** Orders the sequence of tests, for example, Step #1 may be Test\_5, and Step #2 may be Test\_26, etc.

**Test Function** Used only in fw below Rev A.14.00. A field, in the lower left corner of the tests screen that provides access to the editing features: **Edit\_Seqn**, **Edit\_Freq**, **Edit\_Parm**, **Edit\_Cnfg**, **Proc\_Mgr**, and **IBASIC**.

**tests** Tests are a collection of measurements (or a series of other tests) which verify a particular specification value or operation of the UUT. A sequence of tests are contained in a test procedure.

**TESTS screen** The screen accessed by pressing the TESTS key. It is used to customize and execute (run) all automated testing. Also referred to as the "Main Menu".

**USER keys** A group of keys located immediately to the right of the test set screen that allow the user to more rapidly select certain functions without rotating and pressing the knob. These key assignments are displayed in the upper right portion of the test set screen. The number on the left of the function corresponds to the number on the user key k1 to k5.

**values** The scaler quantities or numbers entered in the inverse video fields of the specifications or parameters. Units of measure (dB, inches, volts, watts, etc.) are contained in the pass/fail limits and test parameters.

---

**Numerics**

1-800 help line, [63](#)

**A**

additional services available, [63](#)

AdvanceLink, [168](#)

ASCII file type, [165](#)

Autostart, [125](#)

Autostart Test Procedure on Power-Up,  
[207](#)

**B**

base station

connections, [67](#)

BDAT file type, [165](#)

---

**C**

cable wiring diagrams, 225  
cables/adapters needed, 68  
calibration  
  determining calibration parameters, 74  
CANCEL, 188, 227  
card  
  OTP, 78, 105  
  SRAM, 78, 105  
CAT IBASIC command, 163  
Cell Site Test Set  
  description, 61  
Changing the Order of Tests, 86  
channel information  
  securing, 198  
Choices, 162, 227  
choose, 162  
Clr Scr, 208  
configuration  
  for data collection, 164  
  for terminal or PC operation, 171  
configuring an IBM-compatible PC with  
  HP AdvanceLink, 168  
connecting a printer, 190  
connections  
  base station, 67  
  cables/adapters needed, 68  
  diagram for, 68  
  equipment, 65  
  Microcell, 71  
  Model 882, 70  
  parallel printer, 191  
  RJ-11 connector, 190  
  serial printer, 190  
  VSWR measurements, 72  
Continue, 208, 227  
Continue USER key, 188  
continuing a paused program, 188  
conventions used, 162  
COPY IBASIC command, 163  
copying files, 163  
cursor, 227  
customizing testing, 84  
customizing the software, 110

**D**

damage  
  equipment, 65  
  Test Set, 65  
  to the DUPLEX OUT port, 65  
data collection  
  description, 164  
  entering the configuration for, 164  
  example configuration, 165  
  memory card part numbers, 180  
  retrieving data, 166, 174, 183  
  saving to a memory card or disk, 164  
  to a PC, 168  
  to a PC, setting up, 170  
data-collection  
  doesn't work, 213  
Del Proc, 208  
Delet Stp, 208, 227  
deleting a procedure, 197  
disk  
  initializing, 173  
  retrieving data from, 174  
disk drive  
  External Disk Specification, 195  
disk formats, LIF and DOS, 165  
Done, 208  
DOS disk format, 165  
DOS file type, 165

**E**

Edit Cnfg, 227  
Edit Configuration  
  data collection to a PC, 170  
Edit Freq, 227  
Edit Frequency  
  TEST screen, 110  
Edit Parameter, 92, 119  
Edit Parm, 227  
Edit Seqn, 227  
Edit Sequence, 113  
Edit Spec, 187, 227  
Edit Specifications, 89, 116  
enter, 162  
ENTER key, 162  
equipment needed, 61  
Ericsson models tested, 60  
error messages, 212, 219  
exiting a program, 176



**F**

Factory Hot Line, [63](#)  
field, [227](#)  
  selecting a, [162](#)  
file name  
  disk example, [174](#)  
file types, ASCII, BDAT, DOS, and HP-UX, [165](#)  
files  
  copying, [163](#)  
firmware  
  determining the revision of the Test Set, [61](#)  
front-panel control characters, [171](#)

**G**

Getting Started  
  initializing a memory card, [26, 46](#)  
  loading the software, [24, 44](#)  
  local control transfer, [30, 50](#)  
  Test System overview, [23, 43](#)  
  verify local control transfer, [34, 54](#)  
  what's tested, needed, [21, 41](#)  
GN, [227](#)  
GN auto exit adj  
  parameter description, [150](#)  
GN check MCBS on only RXA  
  parameter descriptions, [154](#)  
GN CU serial control  
  parameter description, [149](#)  
GN model number  
  parameter description, [149](#)  
GN no prompt at end of test  
  parameter descriptions, [154](#)  
GN return loss  
  pass/fail limit description, [155](#)  
GN RF level for return loss tests  
  parameter description, [150](#)

**H**

hardware problems, [212](#)  
Help, [208](#)  
HP-IB control annunciators, [177](#)  
HP-IB printer, [192](#)  
HP-IB printer connections, [190](#)  
HP-UX file type, [165](#)

**I**

IBASIC, 228  
  copying files, 163  
  initializing a disk, 173  
  initializing RAM, 201  
  retrieving data from a card, 167, 184  
  retrieving data from a disk, 174  
  TESTS screen, 84, 110  
IBASIC commands  
  entering from a terminal, 163  
If Unit-Under-Test Fails, 207  
If Unit-Under-Test-Fails, 98  
If UUT Fails, 207  
Init Card, 208  
initializing, 228  
initializing a disk, 173  
initializing a memory card, 26, 46  
initializing an SRAM memory card, 181  
initializing RAM disks, 201  
Insrt Stp, 208

**L**

library, 228  
  definition, 94, 121  
  saving, 94, 121, 195  
LIF disk format, 165  
loading a procedure, 197  
local control  
  copy from laptop, 30, 50  
  downloading from laptop, 26, 46  
  exit, 81, 107  
local control file, 21, 41, 80, 106, 130  
Location, 228  
logging, 178

**M**

Main Menu, 208, 228  
measurement, 228  
memory card, 227  
memory cards  
  are used for, 179  
  determining whether it is OTP or  
    SRAM, 78, 105  
  how they're powered, 179  
  initializing, 181  
  inserting, 179  
  OTP, 179  
  removing, 179  
  retrieving data from, 166, 183  
  saving data to, 164  
  software, 78, 105  
  SRAM, 179  
  SRAM battery part number, 180  
  Static Random Access Memory  
    (SRAM), 180  
  storage space needed, 181  
  write protect switch, 180  
memory space  
  determining the amount used, 215  
  problems, 215  
monitoring commands, 178

**N**

No, [208](#)

**O**

On UUT Failure, [125](#)  
option  
  listing them, [222](#)  
order of tests  
  printing, [189](#)  
  saving, [196](#)  
OTP card, [78](#), [105](#), [229](#)  
Output Destination, [125](#), [206](#)  
Output Heading, [98](#), [125](#), [206](#)  
Output Results, [125](#), [206](#)  
Output Results For, [98](#), [206](#)  
Output Results To, [98](#), [206](#)

**P**

Page Down, [208](#)  
Page Up, [208](#)  
parallel printer connections, [191](#)  
Parameter description  
  RT default channel, [150](#)  
Parameter descriptions  
  GN auto exit adj, [150](#)  
  GN check MCBS on only RXA, [154](#)  
  GN CU serial control, [149](#)  
  GN model number, [149](#)  
  GN no prompt at end of test, [154](#)  
  GN RF level for return loss tests, [150](#)  
  RT audio excitation frequency, [150](#)  
  RT full rated system deviation, [153](#)  
  RT units for audio measurements, [150](#)  
  RX deviation for RF level test (AIO),  
    [153](#)  
  RX deviation for sensitivity tests, [153](#)  
  RX external pad and cable loss, [152](#)  
  RX RF level for AIO/RSSI test, [152](#)  
  RX RF level for audio adjust, [152](#)  
  RX RF level for SAT detector test, [153](#)  
  RX sens floating audio input, [153](#)  
  RX sensitivity SINAD level, [152](#)  
  RX squelch threshold, [152](#)  
  TX audio adjustment excitation level,  
    [151](#)  
  TX max voice audio level, [151](#)  
  TX path loss, [151](#)  
  TX units for RF pwr measure, [150](#)  
  ZZ test mode, [153](#)  
parameters, [229](#)  
  calibration, [74](#)  
  default values, [149](#)  
  editing values, [92](#), [119](#), [186](#)  
  general description, [92](#), [119](#), [186](#)  
  overall description, [149](#)  
  printing, [189](#)  
  saving, [94](#), [121](#), [186](#), [196](#)  
  saving them, [149](#)  
  securing, [198](#)  
part numbers  
  base station connection kit, [61](#)  
  memory card battery, [180](#)  
  SRAM Memory Cards, [180](#)  
pass number, [198](#)  
pass/fail limit descriptions

- 
- GN return loss, 155
  - RX desense, 159
  - RX diversity sensitivity, 158
  - RX line level, 158
  - RX loop gain level, 160
  - RX RF level from AIO, 159
  - RX SAT detector level, 160
  - RX SAT detector SNR, 160
  - RX sensitivity, 158
  - RX squelch hysteresis, 159
  - RX squelch threshold, 159
  - RXB microcell line level difference, 160
  - TX audio level, 156
  - TX constant symbol data deviation, 157
  - TX constant symbol data frequency, 157
  - TX frequency error, 155
  - TX maximum voice deviation, 157
  - TX output power, 156
  - TX SAT deviation, 157
  - TX SAT frequency error, 158
  - TX voice and SAT deviation, 157
  - TX voice channel deviation, 156
  - pass/fail limits, 229
    - editing values, 89, 116, 187
    - general description, 89, 116, 187
    - overall description, 155
    - printing, 189
    - saving, 94, 187, 196
    - securing, 198
  - pause, 229
  - pausing a test, 81, 107, 188
  - PC
    - collecting data to, 168
  - PRESET, 229
  - printer
    - HP-IB, 192
    - output heading, 206
    - problems, 216
    - serial, 192
  - printers supported, 189
  - printing, 189
    - problems, 216
    - test results, 193, 206
    - TESTS Screens, 194
  - problem solving, 211
    - memory space problems, 215
    - printer problems, 216
    - Test Set doesn't power up, 218
  - procedure, 229
    - deleting, 197
    - general description, 94, 121, 195
    - loading into Test Set memory, 197
    - names, 195
    - saving, 94, 121, 195
    - securing, 198
    - un-securing, 199
    - what is saved, 195
  - product description, 60
  - program
    - exiting a program, 176
    - stored in Test Set memory, 179
- R**
- RAM, 229
    - disk, 200
    - initializing, 200
  - REC=
    - entering record number, 165
  - REC= to set record size, 165
  - retrieving data from a memory card, 166
  - RJ-11 connectors, 203
  - ROM, 229
  - RT audio excitation frequency
    - parameter description, 150
  - RT default channel
    - parameter description, 150
  - RT full rated system deviation
    - parameter description, 153
  - RT units for audio measurements
    - parameter description, 150
  - Run, 208
  - Run Mode, 125, 207
  - Run Test, 208, 229
    - difference between Run and, 167, 184
  - running tests, 76
    - overview, 78
  - RX desense
    - pass/fail limit description, 159
  - RX deviation for RF level test (AIO)
    - parameter description, 153
  - RX deviation for sensitivity tests
    - parameter description, 153
  - RX diversity sensitivity
    - pass/fail limit description, 158
  - RX external pad and cable loss
    - parameter description, 152
  - RX line level
    - pass/fail limit description, 158
  - RX loop gain level
    - pass/fail limit description, 160
  - RX RF level for AIO/RSSI test
    - parameter description, 152
  - RX RF level for audio adjust
    - parameter description, 152
  - RX RF level for SAT detector test
    - parameter description, 153
  - RX RF level from AIO
    - pass/fail limit description, 159
  - RX SAT detector level
    - pass/fail limit description, 160
-

---

RX SAT detector SNR  
  pass/fail limit description, 160  
RX sens floating audio input  
  parameter description, 153  
RX sensitivity  
  pass/fail limit description, 158  
RX sensitivity SINAD level  
  parameter description, 152  
RX squelch hysteresis  
  pass/fail limit description, 159  
RX squelch threshold  
  parameter description, 152  
  pass/fail limit description, 159  
RXB microcell line level difference  
  pass/fail limit description, 160

**S**  
SAVE IBASIC command, 163  
Save Proc, 208  
saving  
  procedure, 94, 121  
  test procedure, 94  
  test results, 164  
saving a procedure, 195  
SECURE IT ROM program, 198  
securing a procedure, 198  
select, 162, 230  
self test failed, 212  
sequence, 230  
  changing, 86  
  editing, 113  
  general description, 86, 113  
  saving, 94, 121  
Serial Port, 203  
serial port  
  B, 203  
  primary, 203  
serial port connections  
  figure, 204  
serial printer, 192  
serial printer connections, 190  
SINAD, 230  
Sngl Step, 208  
softkey, 230  
softkeys, 208  
software  
  error messages, 219  
  features, 61  
  overview, 78, 105  
  stopping the, 188  
software contents, 60  
special display conventions used, 162  
specifications, 230  
  editing values, 89, 116  
  general description, 89, 116, 187  
  overall description, 155  
  saving, 94, 121  
SRAM, 230  
  memory cards, 180  
SRAM card  
  write protect switch, 78, 105  
Stop Test, 208  
stopping a test, 81, 107, 188  
stopping the program

using Test Execution Conditions, 98,  
125, 206

## T

- Take It, 208
- terminal emulator, 174
  - configuration, 171
  - DataStorm Technologies, Inc. Pro-Comm, 168
  - HP AdvanceLink, 168
- Test Execution Conditions, 98, 125, 206
- Test Function, 230
  - Edit Parameter, 92, 119
  - Edit Sequence, 113
  - Edit Specifications, 89, 116
  - Procedure Manager, 94, 121
- Test Functions, 84, 110
- test parameters
  - editing values, 186
  - general description, 186
- test plan, 121
- test procedure, 94
  - saving, 195
- Test Procedure Run Mode, 98, 207
- test results
  - printing, 193
  - retrieving from a disk, 174
  - retrieving from a memory card, 166, 183
  - saving, 164
  - where sent, 206
- test results unexpected, 216
- Test Set
  - doesn't power up, 218
  - firmware, 61
  - how to determine settings, 216
  - HP 8921A description, 61
  - HP 8921A, Option 500, 20, 40, 77, 103
  - HP 8921D, 20, 40, 77, 103
- test system
  - overall description, 60
- test time, 188
- TEST\_01 - GN Laptop Emulator
  - description, 129
  - parameters used, 129
  - pass/fail limits used, 129
- TEST\_02 - Memory Card Initialisation
  - description, 130
  - parameters used, 130
  - pass/fail limits used, 130
- TEST\_03 - Local Control File Transfer
  - description, 131
  - parameters used, 131
  - pass/fail limits used, 131
- TEST\_04 - GN Swept Return Loss
  - description, 132
  - parameters used, 134
  - pass/fail limits used, 134
- TEST\_05 - GN Discrete Channel Return Loss
  - description, 134
  - parameters used, 134
  - pass/fail limits used, 134
- TEST\_05 - GN Discrete Return Loss, 134
- TEST\_06 - GN Cable Fault Versus Distance, 135
  - parameters used, 137
  - pass/fail limits used, 137
- TEST\_07 - GN Measure Cable Loss
  - description, 137
  - parameters used, 137
  - pass/fail limits used, 137
- TEST\_08 - GN Data Collection File Transfer, 138
  - pass/fail limits used, 138
- TEST\_09 - TX Frequency Adjustment, 139
  - parameters used, 139
  - pass/fail limits used, 139
- TEST\_10 - TX Power Adjustment
  - description, 139
  - parameters used, 139
  - pass/fail limits used, 139
- TEST\_11 - TX Audio Level Adjustment, 140
  - parameters used, 140
  - pass/fail limits used, 140
- TEST\_12 - TX Voice Channel Deviation, 140
  - parameters used, 140
  - pass/fail limits used, 140
- TEST\_13 - TX Voice and SAT Deviation, 141
  - parameters used, 141
  - pass/fail limits used, 141
- TEST\_14 - TX Maximum Voice Deviation, 141
  - parameters used, 141
  - pass/fail limits used, 141
- TEST\_15 - TX Data Deviation, 142
  - parameters used, 142
  - pass/fail limits used, 142
- TEST\_16 - TX SAT Frequency Error and Deviation, 142
  - parameters used, 142
  - pass/fail limits used, 142
- TEST\_17 - TX Calculate ERP, 142
  - parameters used, 142
  - pass/fail limits used, 142
- TEST\_18 - RX Line Level Adjustment, 143
  - parameters used, 143
  - pass/fail limits used, 143
- TEST\_19 - RX Sensitivity, 144
  - parameters used, 144
  - pass/fail limits used, 144
- TEST\_20 - RX Diversity Sensitivity, 145
  - parameters used, 145
  - pass/fail limits used, 145
- TEST\_21 - RX Desense, 146
  - parameters used, 146
  - pass/fail limits used, 146
- TEST\_22 - RX Squelch Test, 146
  - parameters used, 146
  - pass/fail limits used, 146
- TEST\_23 - RX RF Level Calibration (AIO), 147
  - parameters used, 147
  - pass/fail limits used, 147
- TEST\_24 - RX Loop Gain Adjustment, 147
  - parameters used, 147
  - pass/fail limits used, 147
- TEST\_25 - RX SAT Detector, 148
  - parameters used, 148
  - pass/fail limits used, 148
- TEST-08 - GN Data Collection File Transfer
  - parameters used, 138
- testing order
  - securing, 198
- testresults
  - output failures, 206
- tests, 230
  - entering a sequence of, 86, 113
  - environment and conditions, 92, 119

---

pausing, [81](#), [107](#)  
pausing or stopping, [188](#)  
running, [76](#), [81](#), [107](#)  
stopping, [81](#), [107](#)  
TESTS (Edit Parameters) screen, [149](#)  
TESTS (Edit Specifications) screen, [155](#)  
TESTS (Pass/Fail Limits) screen  
entering into, [187](#)  
TESTS screen, [230](#)  
TX audio adjustment excitation level  
parameter description, [151](#)  
TX audio level  
pass/fail limit description, [156](#)  
TX constant symbol data deviation  
pass/fail limit description, [157](#)  
TX constant symbol data frequency  
pass/fail limit description, [157](#)  
TX frequency error  
pass/fail limit description, [155](#)  
TX max voice audio level  
parameter description, [151](#)  
TX maximum voice deviation  
pass/fail limit description, [157](#)  
TX output power  
pass/fail limit description, [156](#)  
TX path loss  
parameter description, [151](#)  
TX SAT deviation  
pass/fail limit description, [157](#)  
TX SAT frequency error  
pass/fail limit description, [158](#)  
TX units for RF pwr measure  
parameter description, [150](#)  
TX voice and SAT deviation  
pass/fail limit description, [157](#)  
TX voice channel deviation  
pass/fail limit description, [156](#)

**U**  
unexpected test results, [216](#)  
Updated Software Service, [63](#)  
user key, [162](#)  
USER keys, [208](#), [230](#)

**Y**  
Yes, [208](#)

---

**Z**

ZZ test mode  
parameter description, [153](#)