

About this Manual

We've added this manual to the Agilent website in an effort to help you support your product. This manual is the best copy we could find; it may be incomplete or contain dated information. If we find a more recent copy in the future, we will add it to the Agilent website.

Support for Your Product

Agilent no longer sells or supports this product. Our service centers may be able to perform calibration if no repair parts are needed, but no other support from Agilent is available. You will find any other available product information on the Agilent Test & Measurement website, www.tm.agilent.com.

HP References in this Manual

This manual may contain references to HP or Hewlett-Packard. Please note that Hewlett-Packard's former test and measurement, semiconductor products and chemical analysis businesses are now part of Agilent Technologies. We have made no changes to this manual copy. In other documentation, to reduce potential confusion, the only change to product numbers and names has been in the company name prefix: where a product number/name was HP XXXX the current name/number is now Agilent XXXX. For example, model number HP8648A is now model number Agilent 8648A.

SDH Concept
Guide

HP 37717C
Communications
Performance Analyzer

© Copyright Hewlett-Packard Ltd.1998

All rights reserved.
Reproduction, adaption,
or translation without prior
written permission is
prohibited, except as
allowed under the
copyright laws.

Information in this
document may apply to
modules which use the
VxWORKS TM software.
The VxWORKS TM
software was developed by
Wind River Systems, Inc.,
which has copyright to it.

HP Part No. 37717-90417

First Edition, Feb 98

Printed in U.K.

Warranty

The information contained
in this document is subject
to change without notice.

*Hewlett-Packard makes no
warranty of any kind with
regard to this material,
including, but not limited
to, the implied warranties
or merchantability and
fitness for a particular
purpose.*


Hewlett-Packard shall not
be liable for errors
contained herein or for
incidental or
consequential damages in
connection with the
furnishing, performance,
or use of this material.

WARNING

Warning Symbols Used on the Product



The product is marked
with this symbol when the
user should refer to the
instruction manual in order
to protect the apparatus
against damage.



The product is marked
with this symbol to
indicate that hazardous
voltages are present



EN 60825 1991

The product is marked
with this symbol to
indicate that a laser is
fitted. The user should
refer to the laser safety
information in the
Calibration Manual.

HP 37717C Communications Performance Analyzer

About This Book

The information on SDH testing in this book covers the following subjects:

- An Introduction to SDH, the SDH modules and their features.
- Measurement examples.
- Measurement result definitions
- Logging messages
- Self test error codes

For some operations and measurements, information from one of the associated books listed at the rear of this guide may be required.

1 Introduction to SDH Testing

- Introduction to SDH 2
- Option A3R [A3S] SDH Generation and Analysis 4

2 SDH Testing

- Add/Drop Multiplexer Testing 6
- Alarm Stimulus/Response 11
- DCC Testing 15
- Desynchroniser Stress 18
- Frame Synchronization 21
- SDH Jitter Transfer 27
- MSP Stimulus/Response 30
- Optical Clock Recovery Stress 34
- Payload Mapping/Demapping 36
- Performance Monitor Stimulus / Response 42
- Selective Jitter Transfer Measurement 46
- Automatic Alarm and BIP Error Monitoring 50
- Automatic Verification of ADM Installation 53
- Verification of Protection Switching 57

3 Result Definitions

- Trouble Scan 62
- Error Summary 62
- Short Term Results 63
- Cumulative Results 64
- SDH Error Analysis 65

| | |
|---|-----------|
| G.826 Analysis B1 BIP | 65 |
| G.826 Analysis B2 BIP | 66 |
| G.826 Analysis MS-REI | 67 |
| G.826 B3 BIP Analysis | 68 |
| G.826 HP-REI Analysis | 69 |
| G.826 HP-IEC Analysis | 70 |
| G.826 TU BIP Analysis - 34 Mb/s Payload | 71 |
| G.826 TU BIP Analysis - 2 Mb/s Payload | 72 |
| G.826 LP-REI Analysis - 34 Mb/s Payload | 73 |
| G.826 LP-REI Analysis - 2 Mb/s Payload | 74 |
| SDH Pointer Value Results | 75 |
| SDH Alarm Seconds | 76 |
| Frequency Measurement | 77 |
| Optical Power | 77 |

4 SDH Logging Messages

| | |
|--------------------------------------|----|
| Logging Devices | 80 |
| Results Logging | 81 |
| 81 | |
| During the Measurement Period | 81 |
| At the End of the Measurement Period | 86 |
| Bar Graph Logging | 87 |
| Graphics Text Results Logging | 88 |
| Results Snapshot Logging | 89 |
| Overhead Capture Logging | 91 |
| Overhead Snapshot Logging | 92 |
| SDH Tributary Scan Logging | 93 |
| Pointer Graph Logging | 94 |

5 SDH Self Test Error Codes

6 Terminology

ETSI / ANSI Equivalent Terms 116

Current / Previous Terminology 118

1

Introduction to SDH page 2

37717C SDH Options page 3

Introduction to SDH Testing

Information on SDH in general and the SDH test features of the HP 37717C.

Introduction to SDH

Synchronous Digital Hierarchy (SDH) is an international standard (ETSI) for high speed synchronous optical telecommunications networks.

The concept of a synchronous transport system, based on SDH standards, goes beyond the basic needs of a point to point transmission system. It includes the requirements of telecommunications networking - switching, transmission and network control. These capabilities allow SDH to be used in all three traditional network application areas - Local Network, Inter-exchange Network and Long Haul Network - thus providing a unified telecommunication network structure.

The SDH standards are based on the principle of direct synchronous multiplexing. This means that individual tributary signals (Payload) may be multiplexed directly into a higher rate SDH signal without intermediate stages of multiplexing. SDH network elements, even those supplied by different manufacturers, can be interconnected directly giving cost and equipment savings.

SDH is capable of transporting all the common tributary signals E1 (2.048 Mb/s), E3 (34.368 Mb/s), E4 (139.264 Mb/s), DS1 (1.544 Mb/s) and DS3 (44.736 Mb/s) currently in use. In addition SDH has the flexibility to readily accommodate any new types of service which are being introduced for example (ATM) or which may be required in the future. Approximately 5% of the SDH signal structure (Overhead) is reserved for network management and maintenance.

This means that SDH can be deployed as an overlay to the existing network thus providing enhanced network flexibility.

The HP 37717C provides comprehensive testing of both payload and overhead at electrical and optical SDH interfaces.

37717C SDH Options

Option A3R [A3S] SDH Generation and Analysis page 4

SDH generation and analysis with STM-0 and STM-1 electrical interfaces, Option A3R.

Additional SDH interface capability is provided by the following Options::


STM-1 Optical Interface, Option UH1.

STM-0, STM-1 and STM-4 optical interfaces at 1310nm, Option 131.

STM-0, STM-1 and STM-4 optical interfaces at 1310nm and 1550nm, Option 130.

STM-0, STM-1, and STM4 binary interfaces, Option 0YH

Option A3R [A3S] SDH Generation and Analysis



Option A3R [A3S] provides STM-0 and STM-1 Electrical interfaces.

When Option UH1 is fitted STM-1 Optical interfaces are provided.

When Option 130 or 131 is fitted STM-1 and STM-4 optical interfaces are provided.

When STM1-1 Optical is selected, the STM-1 electrical output is also active.

The THRU mode capability allows you to overwrite the TU-2, TU-3, AU-3, TU12 and AU-4 payloads and the section overhead of the incoming STM-0/STM-1/STM-4 signal.

Frequency offset of the SDH signal of 999 ppm is available.

Bulk Filled and Mixed payloads are available. If Option UKJ, Structured PDH, is fitted, DS1 and DS3 payloads are available and a 2 Mb/s, 34 Mb/s and 140 Mb/s Insert Port is provided. Bit errors can be added to the payload.Errors & Alarms can be added to the SDH signal.

AU and TU Pointer Movements can be added to the SDH signal and a Graphical display of Pointer activity is available.

Section and path Overhead bytes are user programmable and can be monitored and displayed in Hexadecimal or as 8 bit bytes. Selected overhead bytes can be transmitted with a programmed sequence of data.

Receive sequences can be captured and displayed. K4 and V5 overhead bytes can be accessed.

Allows BER testing of section and path overhead bytes.

Allows testing of MSP Linear and Ring architectures.

DCC Drop and Insert capability is included.

Allows Protection Switch time testing if Option UKJ, Structured PDH, is fitted.

Optical Power measurement is available.

Optical Clock stress capability at STM-1 and STM-4 is included.

Provides SDH Alarm Scan and Tributary Scan.

Option A3R

| | |
|--|---------|
| Add/Drop Multiplexer Testing | page 6 |
| Alarm Stimulus/Response | page 11 |
| DCC Testing | page 15 |
| Desynchroniser Stress | page 18 |
| Frame Synchronization | page 21 |
| SDH Jitter Transfer | page 27 |
| MSP Stimulus/Response | page 30 |
| Optical Clock Recovery Stress | page 34 |
| Payload Mapping/Demapping | page 36 |
| Performance Monitor Stimulus / Response | page 42 |
| Selective Jitter Transfer Measurement | page 46 |
| Automatic Alarm and BIP Error Monitoring | page 50 |
| Automatic Verification of ADM Installation | page 53 |
| Verification of Protection Switching | page 57 |

SDH Testing

This Chapter gives examples of the instrument operation in typical SDH test applications.

Add/Drop Multiplexer Testing

Application

The insertion of tributary signals into the Add/Drop multiplexer, which are then mapped into the SDH signal, should take place without introducing errors. The insertion and mapping process is tested by adding a test pattern to the tributary inserted at the tributary insert port. At the SDH side of the Add/Drop multiplexer the tributary is demapped by the HP 37717C Communications Performance Analyzer. By using the Optical Splitter, at the optical side of the Add/Drop multiplexer, the Add/Drop multiplexer need not be taken out of service. A Bit error rate (BER) test is performed on the recovered tributary test pattern to determine whether errors have been introduced by the Add/Drop multiplexer.

Default (Known State) Settings

It is advisable to set the HP 37717C to a known state before setting up a measurement. This clears all previous settings and provides a clearly defined instrument state. The default settings are set by selecting **OTHER STORED SETTINGS** STORED SETTING NUMBER 0 and pressing **RECALL**

Add/Drop Multiplexer Testing Test Setup Procedure

The following Options must be fitted to the HP 37717C to perform this test :

- UKJ [USA]or UKK [USB] - PDH Module
- A3R [A3S] - SDH Module
- 130 or 131 - STM-0/1/4 Optical Interface


In this setup a 2 Mb/s payload, containing a test pattern, is inserted at the tributary insert port of the Add/Drop multiplexer multiplexer. A portion of the STM4 Optical signal is tapped off by the Optical Splitter (approx 10%) and the 2 Mb/s tributary is demapped by the HP 37717C Communications Performance Analyzer.

An Error measurement is performed on the demapped 2 Mb/s tributary test pattern.

A SINGLE test period of 24 HOURS is used and the internal printer is enabled to record results and alarms.

The HP 37717C Communications Performance Analyzer GRAPHICS function is enabled. The graphical results can be viewed on the **GRAPH** display

SDH Testing Add/Drop Multiplexer Testing



1. Connect the HP 37717C to the network equipment and set the **OTHER** **SETTINGS CONTROL** TRANSMITTER AND RECEIVER to INDEPENDENT.

Changes made on the **TRANSMIT** display will not affect the **RECEIVE** display and changes made on the **RECEIVE** display will not affect the **TRANSMIT** display.

2. Set up the **TRANSMIT** display as shown opposite.

The PAYLOAD TYPE determines the Framing. .

| | |
|-----------------------------|-----------------------------|
| TRANSMITTER OUTPUT | [PDH] |
| PAID STRUCT-B JITTER | TEST |
| SETTINGS SETTINGS | FUNCTION |
| SIGNAL | [2 Mb/s] |
| CLOCK SYNC [INTERNAL] | |
| TERMINATION | [75% UNBAL] |
| LINE CODE | [HDB3] |
| FREQUENCY OFFSET | [OFF] |
| PAYLOAD TYPE | [PCM30CRC] |
| PATTERN | [2 ¹¹ -1 PRBS] |
| PRBS POLARITY | [INU] NON-ITU] |
| 2N CR5 ABCD BITS | [1111] |
| STATUS: | |
| MULTIPLE WINDOW | |

SDH Testing

Add/Drop Multiplexer Testing

3. Set up the **RECEIVE** display as shown opposite.

| | | | | |
|--------------------|-----------------|------------------|---------|------------------------|
| RECEIVER INPUT | | [SDH] | | |
| SDH | STRUCT'D | TEST OVERHEAD | | |
| | PAYLOAD | FUNCTION MONITOR | | |
| SIGNAL [STM-4 OPT] | | | | |
| | | | | |
| MAPPING | [AU-4] | [TU-12] | | |
| | | [ASYNC 2Mb/s] | | |
| CHANNEL | STM-1 | TUG3 | TUG2 | TU |
| | [1] | [1] | [1] | [1] |
| TU PAYLOAD | [PCM30CRC] | | | |
| PATTERN | [2*11-1 PRBS] | [INVERT] | NON-ITU | |
| | | | | |
| STATUS: | | | | MULTIPLE WINDOW |

Continuity Check

Before running the test carry out a continuity test to verify the measurement path.

1. Set up the **RESULTS** display as shown opposite.

2. Press **RUN/STOP** to start a measurement.

3. Press error add **SINGLE** three times and check that the errors are recorded on the **RESULTS** display.

3. Check that the errors are recorded on the **RESULTS** display.

4. Press **RUN/STOP** to stop the measurement.

| | | |
|-------------------------|--------|----------------|
| RESULTS [PDH PAYLOAD] | | [CUMULATIVE] |
| BIT | FAS | CRC |
| | 2 Mb/s | REBE |
| | | |
| BIT EC | | |
| BIT ER | | |
| | | |
| ELAPSED TIME | | |
| | | |
| STATUS: | | |
| MULTIPLE WINDOW | | |

Select the required logging DEVICE and set up the **OTHER** display: **LOGGING** function, as shown opposite.

| | | |
|--------------------|---------------|------------------------|
| FUNCTION | | [LOGGING] |
| LOGGING SETUP | | [CONTROL] |
| LOGGING | | [ON] |
| LOGGING PERIOD | | [1 HOUR] |
| RESULTS LOGGED | | [SELECTED] |
| WHEN | | [PERIOD EXCD] |
| CONTENT | | [ER & ANRL] |
| | | [PER & CUMUL] |
| LOG ERROR SECONDS | | [OFF] |
| LOG AT END OF TEST | | ALL RESULTS |
| LOG ON DEMAND | | RESULTS |
| | | |
| STATUS: | | |
| ALWAYS | PERIOD | MULTIPLE WINDOW |
| | EC > 0 | |

SDH Testing

Add/Drop Multiplexer Testing


Start the Add/Drop Multiplexer Test

1. Set up the **RESULTS** display as shown opposite. If you do not require stored graphics results select STORAGE [OFF].

Graphics results can be stored to the instrument store - INTERNAL or to DISK.

SHORT TERM PERIOD need only be set if it is intended to view Short Term results.


2. Press **RUN/STOP** to start the measurement.



The measurement results and alarms are available on the **RESULTS** display during the test period.

The graphical measurement results and alarms are stored in non volatile memory for viewing later on the GRAPH display.

The test can be halted at any time by pressing **RUN/STOP**



Add/Drop Multiplexer Testing

At the End of the Test (Add/Drop Multiplexer Testing)

- The Date and Time the test started and the instrument setup are logged To the selected logging device.
- Results are logged To the selected logging device at 1 hour intervals if the error count is greater than 0.
- Any alarms which occur during the test period will be logged To the selected logging device.
- At the end of the test period a complete set of cumulative results are logged To the selected logging device.
- A graphical record of the results during the test period can be viewed on the **GRAPH** display. If a printer option is fitted the graph results can be logged to a printer, at a later date.
- Results and Alarm summaries can be viewed on the **GRAPH** display.

The total graphics store capacity is normally 20,000 events. An event is the occurrence of an error or an alarm.

The resolution, determined by the selection made under STORAGE on the **RESULTS** display, affects the ZOOM capability when viewing the bar graphs. If 1 SECOND is selected all resolutions are available under ZOOM. If 1 MIN is selected only 1 MIN/BAR, 15 MINS/BAR and 60 MINS/BAR are available. If 15 MINS is selected only 15 MINS/BAR and 60 MINS/BAR are available. If 1 HOUR is selected only 60 MINS/BAR is available.

Up to 10 sets of graphical results can be stored. If an attempt is made to store more than 10 sets of results, then a first in first out policy is operated and the oldest set of results will be lost. If graphics are enabled and a test is run which exceeds the remaining storage capacity, then some previously stored graphical results will be lost.

To prevent accidental overwriting of previously stored results the graphics capability should be disabled, when graphical results are not required, by selecting STORAGE [OFF] on the **RESULTS** display.

Alarm Stimulus/Response

Application

SDH Network elements transmit alarms in response to certain error/alarm conditions to advise upstream and downstream equipment that these conditions exist. If these alarms are not transmitted in the proper manner, at the proper time, degradations in service will occur.

Alarm testing entails transmitting an alarm signal from the Communications Performance Analyzer and monitoring the network equipment alarm indicators and the upstream or downstream signal for the correct response.

Default (Known State) Settings

It is advisable to set the HP 37717C to a known state before setting up a measurement. This clears all previous settings and provides a clearly defined instrument state. The default settings are set by selecting **OTHER STORED SETTINGS** STORED SETTING NUMBER 0 and pressing **RECALL**.

Alarm Stimulus/Response Test Setup Procedure


The following options must be fitted to the HP 37717C to perform this test:

- A3R [A3S] - SDH module
- UH1, - STM-1 Optical interface or 130 or 131 STM-0/1/4 Optical interface

In this setup the Communications Performance Analyzer transmits MS-AIS Alarm (Line AIS) into the network. The network equipment alarm indicators are monitored for the appropriate alarms. The upstream signal is monitored for occurrences of MS-RDI . The downstream signal can be monitored for occurrences of AU-AIS.

A similar procedure can be used for testing all other SDH alarms. See the following tables.

SDH Testing
Alarm Stimulus/Response



SDH Alarms

| Alarm | RSTE | | MSTE | | PTE | |
|-----------------|--------|-----|--------|--------|--------|--------|
| | Down | Up | Down | Up | Down | Up |
| Loss Of Signal | MS-AIS | N/A | AU-AIS | MS-RDI | TU-AIS | LP-RDI |
| Loss Of Frame | MS-AIS | N/A | AU-AIS | MS-RDI | TU-AIS | LP-RDI |
| Loss Of Pointer | N/A | N/A | AU-AIS | MS-RDI | TU-AIS | LP-RDI |
| MS-AIS | N/A | N/A | AU-AIS | MS-RDI | TU-AIS | LP-RDI |
| MS-RDI | N/A | N/A | N/A | N/A | N/A | N/A |

SDH Testing Alarm Stimulus/Response

1. Set up the **OTHER**; **SETTINGS CONTROL** display as shown opposite.

Any changes made on the **TRANSMIT** or **RECEIVE** display will affect the other.

| | |
|--------------------------------------|---------|
| FUNCTION [SETTINGS CONTROL] | |
| TRANSMITTER AND RECEIVER [COUPLED] | |
| RECEIVER COUPLED TO TRANSMITTER | |
| | |
| STATUS: | |
| INDEPENDENT | COUPLED |
| MULTIPLE WINDOW | |

2. Set up the **TRANSMIT**; **SDH** display as shown opposite.

| | | | | |
|----------------------------|----------|-----------------|----------|----------|
| TRANSMITTER OUTPUT [SDH] | | | | |
| SDH | STRUCT'D | JITTER | TEST | OVERHEAD |
| PAYLOAD | | FUNCTION SETUP | | |
| SIGNAL [STM-1 OPT JC] | | 1310 | INTERNAL | |
| CLOCK [INTERNAL] | | OFFSET [OFF] | | |
| | | | | |
| MAPPING | AU-4 | [FOREGROUND] | | |
| | | [UC-4] | | |
| 140M OFFSET | | [140 Mb/s] | | |
| | | [0 pph] | | |
| | | | | |
| PAYLOAD TYPE | | [UNFRAMED] | | |
| PATTERN [2^23-1 PRBS] | | [INVERT] ITU | | |
| | | | | |
| STATUS: | | MULTIPLE WINDOW | | |

3. Set up the **TRANSMIT**; **TEST FUNCTION** display as shown opposite.

The ERROR ADD TYPE selected does not matter as long as RATE [OFF] is selected.


| | | | |
|----------------------------|---------|-----------------|----------|
| TRANSMITTER OUTPUT [SDH] | | | |
| SDH | JITTER | TEST | OVERHEAD |
| FUNCTION | | SETUP | |
| TEST FUNCTION [SDH] | | [ERR & ALARM] | |
| ERROR ADD TYPE | | [AIR2 FRAME] | |
| RATE | | [OFF] | |
| | | | |
| ALARM TYPE | | [NS AIS] | |
| | | | |
| STATUS: | | MULTIPLE WINDOW | |
| NS AIS | NS FERF | LOSS OF POINTER | PATH AIS |
| MORE | | MULTIPLE WINDOW | |

SDH Testing

Alarm Stimulus/Response

4. Set up the **RESULTS** display as shown opposite

SHORT TERM PERIOD need only be set if it is intended to view Short Term results




Start the Alarm Stimulus/Response Test

1. Connect the Communications Performance Analyzer to the upstream port of the network equipment and press **RUN/STOP** on the HP 37717C.

2. Check that the network equipment registers MS-AIS and that MS-RDI alarm seconds are recorded on the **RESULTS** display .

ALARM SECONDS are displayed but any of the other results can be selected from the softkey menu without affecting the measurement

The MS-RDI indicator on the front panel in conjunction with **SHOW HISTORY** will also give an indication that the MS-RDI alarm has occurred.



DCC Testing

Application

The section overhead contains two Data Communication Channels (DCC), Regenerator Section DCC at 192 kb/s (overhead bytes D1- D3) and Multiplexer Section DCC at 576 kb/s (overhead bytes D4 - D12). The DCC communicates network management messages between network elements and the network controller via the operations support computer system.

If the DCC is not operating correctly these network management messages will be lost and degradations in network performance will pass unnoticed. This may result in a failure condition.

Full testing of the line and section DCC's can be carried out using a protocol analyzer connected via the HP 37717C Communications Performance Analyzer to the appropriate overhead bytes. At the far end the HP 37717C Communications Performance Analyzer can drop the selected DCC to the protocol analyzer allowing the DCC integrity to be analyzed.

If you do not have access to a protocol analyzer capable of handling SDH DCC protocol, the DCC integrity can be verified by a BER test using an HP 37732A, Digital Telecomm/Datacomm Analyzer.

Default (Known State) Settings

It is advisable to set the HP 37717C to a known state prior to setting up a measurement. This clears all previous settings and provides a clearly defined instrument state. The default settings are set by selecting **OTHER STORED SETTINGS** STORED SETTING NUMBER 0 and pressing **RECALL**

DCC Test Setup Procedure

Alarm Stimulus/Response Test Setup Procedure

The following options must be fitted to the HP 37717C to perform this test:


- A3R [A3S]- SDH module
- UH1, - STM-1 Optical interface or 130 or 131 STM-0/1/4 Optical interface

In this procedure the HP 37717C Communications Performance Analyzer accepts a 576 kb/s test pattern via the protocol analyzer port, inserting the test pattern in bytes D4 - D12 of the Multiplexer Section overhead and transmitting an STM-1 optical


SDH Testing DCC Testing

signal. The HP 37717C Communications Performance Analyzer receives the STM-1 optical signal and drops the Multiplexer Section DCC, via the protocol analyzer port, to the HP 37732A which performs the BER measurement.

HP 37732A DIGITAL
TELECOMM/DATACOMM
ANALYSER




1. Connect the HP 37732A and the HP 37717C to the network element, as shown and set up the **OTHER**; **SETTINGS CONTROL** display as shown opposite.



2. Set up the **TRANSMIT** SDH display as shown opposite.

The **CLOCK SYNC** selection determines the synchronization source for the **TRANSMIT** clock. If **EXTERNAL MTS** is selected a 2 Mb/s reference must be connected to the front panel 2M REF IN port. The format can be **CLOCK** or **DATA**.



SDH Testing

DCC Testing

3. Set up the **TRANSMIT**; TEST FUNCTION display as shown opposite.

| | | |
|---------------------|----------|-----------------|
| TRANSMITTER OUTPUT | | [SDH] |
| SDH | JITTER | TEST OVERHEAD |
| | FUNCTION | SETUP |
| TEST FUNCTION [SDH | | IF DCC INSERT] |
| | | MS DCC |
| DCC BYTE POLARITY | | [NORMAL] |
| STATUS: | | |
| MS DCC | MS DCC | MULTIPLE |
| D1-D2 | D4-D12 | WINDOW |

4. Set up the **RECEIVE**; TEST FUNCTION display as shown opposite.

| | | |
|-------------------|----------|------------------|
| RECEIVER INPUT | | [SDH] |
| SDH | STRUCT'D | TEST OVERHEAD |
| | PAYLOAD | FUNCTION MONITOR |
| TEST FUNCTION | | [DCC DROP] |
| | | [MS DCC] |
| DCC BYTE POLARITY | | [NORMAL] |
| STATUS: | | |
| | | MULTIPLE |
| | | WINDOW |

Start the DCC Test

1. Select TEST SELECT DATACOM on the HP 37732A.
2. Set TX Clock Source and RX Clock Source to [INTERFACE] on the HP 37732A (Clock from HP 37717C protocol port).
3. Select the required pattern and monitor logic errors and frequency to verify the integrity of the DCC.

Desynchroniser Stress

Application

At the boundary of the SDH network the 2 Mb/s or 140 Mb/s payload is demapped from the SDH signal. Pointer adjustments in the signal may cause high levels of tributary jitter in the output payload. Excessive amounts of tributary jitter will result in errors.

The desynchronizing phase lock loop of the network element should minimize the level of tributary jitter in the payload but correct operation under stress conditions must be verified. The desynchronizing phase lock loop can be stressed by adding pointer movement sequences (defined in CCITT standard G.783) to the SDH signal such that the test virtual container moves with respect to the SDH frame.

A jitter measurement is made to verify that the desynchroniser output jitter is within the required specification.

Default (Known State) Settings

It is advisable to set the HP 37717C to a known state before setting up a measurement. This clears all previous settings and provides a clearly defined instrument state. The default settings are set by selecting **OTHER STORED SETTINGS** STORED SETTING NUMBER 0 and pressing **RECALL**.

Desynchroniser Stress Test Setup Procedure


The following options must be fitted to the HP 37717C to perform this test:

- UKK [USB] or UKJ [USA]- PDH module
- A3L, A3V or A3N - Jitter measurement module
- A3R [A3S]- SDH module
- 130 or 131 STM-0/1/4 Optical interface

The HP 37717C Communications Performance Analyzer transmits an STM-4 optical signal carrying 2 Mb/s payload. Pointer movement sequences are added in a controlled manner. The desynchroniser output is returned to the HP 37717C and a jitter measurement is performed on the demapped 2 Mb/s signal.

SDH Testing Desynchroniser Stress

TEST SET



1. Connect the HP 37717C to the network equipment and set up the **TRANSMIT**; **SDH** display as shown opposite. The **CLOCK SYNC** selection determines the synchronization source for the **TRANSMIT** clock. If **EXTERNAL MTS** is selected a 2 Mb/s reference must be connected to the 2M REF IN port. The format can be **CLOCK** or **DATA**.

| TRANSMITTER OUTPUT | | [SDH] |
|---|----------|----------|
| SDH | STRUCT'D | JITTER |
| PAYLOAD | TEST | OVERHEAD |
| | FUNCTION | SETUP |
| SIGNAL [STM-4 OPTIC] 1310 [INTERNAL] | | |
| CLOCK [EXT MTS CLK] OFFSET [OFF] | | |
| MAPPING [AU-4] [FOREGROUND] | | |
| 2M OFFSET [TU-12] [2Mb/s] | | |
| CHANNEL [STM-1] TUG3 TUG2 TU | | |
| TU PAYLOAD [1] [1] [UNFRAMED] [1] | | |
| PATTERN [2*15-1 PRBS] [INVERT] ITU | | |
| STATUS: | | |
| CFG | B/B | MULTIPLE |
| WRAPPING | MAPPING | WINDOW |

2. Set up the **TRANSMIT**; **TEST FUNCTION** display as shown opposite.

Pointer adjustments are made every 10 ms with an extra **ADDED** adjustment as defined in CCITT standard G.783.

Pointer sequences are started by selecting **STARTED**.

| TRANSMITTER OUTPUT | | [SDH] |
|--------------------------------------|----------|----------|
| SDH | JITTER | TEST |
| | FUNCTION | OVERHEAD |
| | SETUP | |
| TEST FUNCTION [SDH] [ADJUST PTR] | | |
| POINTER TYPE [TU POINTER] | | |
| ADJUSTMENT TYPE [G.783] | | |
| POLARITY [SINGLE] | | |
| INTERVAL [WITH ADDED] | | |
| [POSITIVE] | | |
| POINTER SEQUENCES [STOPPED] | | |
| STATUS: | | |
| NEGATIVE | POSITIVE | MULTIPLE |
| | | WINDOW |

SDH Testing

Desynchroniser Stress

3. Set up the **RECEIVE**; **PDH** JITTER display as shown opposite.

SHORT TERM PERIOD need only be set if it is intended to view Short Term results

```

RECEIVER INPUT [ PDH ]
MAIN STRUCT'D JITTER
SETTINGS SETTINGS
SIGNAL FREQUENCY 2 Mb/s
RECEIVER RANGE [ 1.6 UI ]
HIT THRESHOLD [ 0.50 UI ]
FILTER [ OFF ]
ADDITIONAL RMS FILTER [ OFF ]
WANDER [ ON ]
WANDER REFERENCE [ 75% UNBAL ]
WANDER REF. FORMAT [ HD33 DATA ]
CONNECT 2Mb/s SOURCE to JITTER RX MODULE

STATUS:
MULTIPLE WINDOW
  
```

4. Set up the **RESULTS** display as shown opposite. .

```

RESULTS [TIMING CONTROL]
SHORT TERM PERIOD [ 1 SECOND ]
TEST TIMING [ MANUAL ]
GRAPH STORAGE [ OFF ]
[ INTERNAL ]

STATUS:
OFF 1 SEC RESOL'N 1 MIN RESOL'N 15 MIN RESOL'N 1 HR RESOL'N MULTIPLE WINDOW
  
```

Start the Desynchroniser Stress Test

1. Press **RUN/STOP** to start the Jitter measurement.

Jitter Hits or any other result can also be viewed without affecting the measurement

```

RESULTS [ JITTER ] [ CUMULATIVE ]
HITS [ ANAL ]
[ HOLD ]

+VE PEAK UI
-VE PEAK UI
PEAK-PEAK UI
FILTERS OFF
ELAPSED TIME

STATUS:
MULTIPLE WINDOW
  
```

Frame Synchronization

Application

A network element should maintain synchronization even in the presence of some frame errors. If the number of frame errors exceeds the specified threshold for 3 ms, the network element will lose frame synchronization causing a new search for frame alignment to begin.

The frame synchronization process of the network element can be stressed by injecting frame errors, into the A1 and A2 framing bytes of the Regenerator Section overhead. As the frame error injection rate is increased to the frame synchronization threshold, the network element should indicate Out Of Frame (OOF) and Loss Of Frame (LOF) conditions. As the frame error injection rate is decreased again, the network element should regain frame synchronization.

Default (Known State) Settings

It is advisable to set the HP 37717C to a known state before setting up a measurement. This clears all previous settings and provides a clearly defined instrument state. The default settings are set by selecting **OTHER STORED SETTINGS** STORED SETTING NUMBER 0 and pressing **RECALL**


Frame Synchronization Test Setup Procedure

Frame Error Add Test Function In this setup the HP 37717C Communications Performance Analyzer is used to insert frame errors in the A1 and A2, framing bytes of the Regenerator section overhead of an STM-1 optical signal. The STM-1 optical signal is transmitted to the network equipment. The network equipment OOF and LOF alarms are monitored as the frame error add rate is increased and decreased.


Sequence Generation Test Function

In this setup procedure the HP 37717C Communications Performance Analyzer generates a sequence of errored framing bytes to test the OOF and LOF alarm threshold criteria. The upstream STM-1 optical signal is monitored for occurrences of Multiplexer Section FERF. The downstream STM-1 optical signal can be monitored for AIS.

SDH Testing Frame Synchronization




1. Connect the HP 37717C to the network equipment and set up the **OTHER**; **SETTINGS CONTROL** display as shown opposite.



2. Set up the **TRANSMIT**; **SDH** display as shown opposite.

The **CLOCK SYNC** selection determines the synchronization source for the **TRANSMIT** clock. If **EXTERNAL MTS** is selected a 2 Mb/s reference must be connected to the front panel 2M REF IN port. The format can be **CLOCK** or **DATA**.




SDH Testing

Frame Synchronization


3. Set up the **RESULTS** display as shown opposite

SHORT TERM PERIOD need only be set if it is intended to view Short Term results.




4.,ALARM SECONDS are displayed but any of the other results can be selected from the softkey menu without affecting the measurement

The MS-RDI indicator on the front panel in conjunction with **SHOW HISTORY** will also give an indication that the MS-RDI alarm has occurred.



5. Set up the **TRANSMIT**; TEST FUNCTION display as shown opposite.



SDH Testing


Frame Synchronization

Start the Frame Synchronization Test (Frame Error Add)

1. Check that the Loss Of Frame (LOF) alarm indicator on the network element remains unlit and no occurrences of MS-RDI are recorded.
2. Increase the Frame Error Add Rate to 2 IN 4 and check that the Loss Of Frame (LOF) alarm indicator on the network element remains unlit and no occurrences of MS-RDI are recorded.
3. Increase the Frame Error Add Rate to 3 IN 4 and check that the Loss Of Frame (LOF) alarm indicator on the network element remains unlit and no occurrences of MS-RDI are recorded.
4. Increase the Frame Error Add Rate to 4 IN 4 and check that the OOF and LOF alarm indicators on the network equipment are lit and occurrences of MS-RDI are recorded.
5. Decrease the Frame Error Add Rate to 3 IN 4 and check that the OOF and LOF alarm indicators on the network equipment remain lit and occurrences of MS-RDI are still being recorded.
6. Decrease the Frame Error Add Rate to 2 IN 4 and check that the OOF and LOF alarm indicators on the network equipment go off, and no further occurrences of MS-RDI are recorded.

Sequence Generation Test Function

1. Connect the HP 37717C to the network equipment and set up the **OTHER** **SETTINGS CONTROL** display as shown opposite.



SDH Testing

Frame Synchronization

2. Set up the **TRANSMIT**; **SDH** display as shown opposite.

The **CLOCK SYNC** selection determines the synchronization source for the **TRANSMIT** clock. If **EXTERNAL MTS** is selected a 2 Mb/s reference must be connected to the front panel 2M REF IN port. The format can be **CLOCK** or **DATA**.

| | | |
|--------------------|-----------------|------------------------|
| TRANSMITTER OUTPUT | | [SDH] |
| SDH | STRUCT'D | JITTER |
| PAYLOAD | FUNCTION | OVERHEAD SETUP |
| SIGNAL | [STM-1 OPTIC] | 1310 [INTERNAL] |
| CLOCK | [INTERNAL] | OFFSET [OFF] |
| MAPPING | RU-4 | [FOREGROUND] |
| | | [UC-4] |
| 140M OFFSET | | [140 Mb/s] |
| | | [0 PPM] |
| PAYLOAD TYPE | | [UNFRAMED] |
| PATTERN | [2*23-1 PRBS] | [INVERT] ITU |
| STATUS: | | |
| | | MULTIPLE WINDOW |

3. Set up the **RESULTS** display as shown opposite

SHORT TERM PERIOD need only be set if it is intended to view Short Term results.

| | |
|--------------------------|------------------------|
| RESULTS [TIMING CONTROL] | |
| SHORT TERM PERIOD | [1 SECOND] |
| TEST TIMING | [MANUAL] |
| GRAPH STORAGE | [OFF] |
| | [INTERNAL] |
| STATUS: | |
| OFF | 1 SEC RESOL'N |
| 1 MIN RESOL'N | 15 MIN RESOL'N |
| 1 HR RESOL'N | MULTIPLE WINDOW |

4..**ALARM SECONDS** are displayed but any of the other results can be selected from the softkey menu without affecting the measurement.

| | | |
|----------------------|-----------------------|------------------------|
| RESULTS [SDH] | | [ALARM SECONDS] |
| POWER LOSS | K1/K2 CHANGE | |
| LOS | MS-RDI | |
| LOF | HP-RDI | |
| DDF | H4 LDM | |
| RU-LOP | TU-LOP | |
| MS-RIS | TU-RIS | |
| RU-RIS | LP-RDI | |
| ELAPSED TIME | | |
| STATUS: | | |
| ALARM SECONDS | FREQ- UENCY | POINTER VAL'UES |
| POINTER GRAPH | MORE | MULTIPLE WINDOW |

SDH Testing

Frame Synchronization

Start the Frame Synchronization Test (Sequence Test)

1. Set up the **TRANSMIT** TEST FUNCTION display as shown opposite.
2. Press **STARTED** on the **TRANSMIT** TEST FUNCTION display to start the sequence. As a result of this sequence one OOF alarm second and one LOF alarm second should occur every two seconds.
3. Check that the network element OOF and LOF alarm indicators cycle ON and OFF and that an occurrence of MS-RDI is recorded every two seconds.
3. Press **STOPPED** to stop the sequence and set up the **TRANSMIT** TEST FUNCTION display as shown opposite.
4. Press **STARTED** on the **TRANSMIT** TEST FUNCTION display to start the sequence. As a result of this sequence one OOF alarm second should occur every two seconds but LOF should not occur.
5. Check that the network element OOF alarm indicator cycles ON and OFF. The LOF alarm should not occur and no occurrences of MS-RDI should be recorded.

```

TRANSMITTER OUTPUT [ SDH ]
SDH STRUCT ID JITTER TEST OVERHEAD
PAYLOAD FUNCTION SETUP

TEST FUNCTION [ SDH ] SEQUENCES ]
[ REPEAT RUN ] [ STOPPED ] -SEQUENCE STOPPED ]
OVERHEAD CHANNEL [ RSDH ] [ 3xR1, 3xR2 ]
A [ F8F8F8282828 ]
B [ 090909D7D7D7 ]
C [ 000000000000 ]
D [ 000000000000 ]
E [ 000000000000 ]
SEQUENCE [ 15974 ] FRAMES OF [ A ] THEN
[ 26 ] [ AB ]
[ 0 ] [ CD ]
[ 0 ] [ DE ]
[ 0 ] [ EF ]

STATUS:
A B C D E MULTIPLE WINDOW

```

```

TRANSMITTER OUTPUT [ SDH ]
SDH STRUCT ID JITTER TEST OVERHEAD
PAYLOAD FUNCTION SETUP

TEST FUNCTION [ SDH ] SEQUENCES ]
[ REPEAT RUN ] [ STOPPED ] -SEQUENCE STOPPED ]
OVERHEAD CHANNEL [ RSDH ] [ 3xR1, 3xR2 ]
A [ F8F8F8282828 ]
B [ 090909D7D7D7 ]
C [ 000000000000 ]
D [ 000000000000 ]
E [ 000000000000 ]
SEQUENCE [ 15974 ] FRAMES OF [ A ] THEN
[ 24 ] [ AB ]
[ 0 ] [ CD ]
[ 0 ] [ DE ]
[ 0 ] [ EF ]

STATUS:
A B C D E MULTIPLE WINDOW

```


SDH Jitter Transfer

Digital transmission systems use Regenerators to transport the signal over long distances. These Regenerators are cascaded together and it is important that each regenerator adds minimal amounts of jitter to the signal.

It is necessary during installation and maintenance to measure the degree to which jitter present at the input is amplified or attenuated by the network elements (Jitter Gain/Transfer).

The jitter transfer measurement entails measuring the input and output jitter at selected jitter frequencies within the jitter bandwidth. The jitter gain is calculated :
Jitter Gain (dB) = 20 Log {Jitter out \\over Jitter in}

When the network equipment meets CCITT specification G.823 it should be possible to connect network elements without incurring bit errors.



Default (Known State) Settings

It can be advisable to set the HP 37717C to a known state prior to setting up to make a measurement. This clears all previous settings and provides a clearly defined instrument state. The default settings are set by selecting **OTHER** **STORED** **SETTINGS** STORED SETTING NUMBER 0 and pressing **RECALL**

Test Setup Procedure (Jitter Transfer Test)

The following Options must be fitted to the HP 37717C to perform this test :

- A3K - Jitter and Wander Generation

SDH Testing

SDH Jitter Transfer

- A3V or A3N- SDH Jitter Measurement
- A3R [A3S] - SDH Module

This setup procedure is based on 155.52 Mb/s (STM-1), 140 Mb/s payload, PRBS test data with jitter. The Jitter frequency is varied within the jitter bandwidth and the received jitter is measured to allow calculation of the jitter gain.

1. Set up the OTHER SETTINGS CONTROL display as shown opposite.

Any SDH settings change made on the **TRANSMIT** or **RECEIVE** displays will automatically occur on the other.

| | |
|---|--|
| FUNCTION [SETTINGS CONTROL] | |
| TRANSMITTER AND RECEIVER [COUPLED] | |
| RECEIVER COUPLED TO TRANSMITTER | |
| STATUS: [INDEPENDENT] [COUPLED] [MULTIPLE WINDOW] | |

2. Connect the HP 37717C to the line equipment, select **TRANSMIT**; **SDH** and set up the display as shown opposite.

| | |
|-------------------------------------|---|
| TRANSMITTER OUTPUT [SDH] | |
| [SDH] | [STRUCT'D] [JITTER] [TEST] [OVERHEAD] |
| [PAYLOAD] | [FUNCTION] [SETUP] |
| SIGNAL [STM-1] | [INTERNAL] |
| CLOCK [INTERNAL] | [OFF] |
| MAPPING AU-4 | [FOREGROUND] |
| | [UC-4] |
| 140M OFFSET | [140 Mb/s] |
| | [0 ppm] |
| PAYLOAD TYPE | [UNFRAMED] |
| PATTERN [2 ²³ -1 PRBS] | [INVERT] [ITU] |
| STATUS: [MULTIPLE WINDOW] | |

3. Select **TRANSMIT**; **JITTER** and set up the display as shown opposite.

Select the required Jitter MODULATING FREQUENCY and AMPLITUDE.


| | |
|-----------------------------|---|
| TRANSMITTER OUTPUT [SDH] | |
| [SDH] | [STRUCT'D] [JITTER] [TEST] [OVERHEAD] |
| [PAYLOAD] | [FUNCTION] [SETUP] |
| JITTER / WANDER | [JITTER] |
| JITTER | [ON] |
| SIGNAL FREQUENCY | [STM-1] |
| MODULATION SOURCE | [INTERNAL] |
| JITTER MASK | [OFF] |
| CLOCK SYNC | INTERNAL |
| RANGE | [1.0 UI] |
| MODULATION FREQUENCY | [1000 Hz] |
| AMPLITUDE | [1.00 UI] |
| STATUS: [MULTIPLE WINDOW] | |

SDH Testing

SDH Jitter Transfer

4. Setup the **RECEIVE**; **SDH JITTER** display as shown opposite.

If Jitter filtering is required select from the softkey menu.




Run the Test (Jitter Transfer)

1. Select **RESULTS** and set up the display as shown opposite.

SHORT TERM PERIOD need only be set if it is intended to view Short Term results.


2. Press **RUN/STOP** to start the measurement.



3. Record the Jitter Amplitude result from the **RESULTS** display.

4. Select each jitter Modulating Frequency and Amplitude in turn on the **TRANSMIT** display, press **RUN/STOP** twice and record the Jitter Amplitude result from the RESULTS display.

5. Calculate the Jitter gain for each frequency selected.



Jitter Gain (dB) = 20 Log {Jitter out / Jitter in}. Where Jitter In is the AMPLITUDE selected on the **TRANSMIT** display.

MSP Stimulus/Response

Application

Multiplexer Section Protection (MSP) is an optional feature for SDH Multiplexer Section Terminating Equipment (MSTE). For those MSTE's, in which it is provided, the MSP system is standardized to ensure the interworking of MSP between MSTE's from different suppliers.

Standard messages, carried in the K1 and K2 bytes of the SDH signal transport overhead, indicate the state of the MSP.

Switching to the protection line occurs when one of the following conditions exists for a specified length of time :

- Loss Of Signal (LOS)
- Loss Of Frame (LOF)
- Signal Fail - Bit Error Ratio $> 1 \times 10^{-3}$
- Signal Degrade - Bit Error Ratio programmable
- MS-AIS

The Signal Degrade Bit Error Ratio threshold is normally programmable in the range 1×10^{-5} to 1×10^{-9} .

The HP 37717C Communications Performance Analyzer can be used to test Multiplexer Section Protection switching by :


Generating the switching conditions listed above.

Transmitting and monitoring the K1 K2 messages.

MSP Stimulus/Response 1+1 Architecture Test Setup Procedure

In this setup the HP 37717C PDH/SDH test set, inserted in the working line, generates B2 BIP errors in sufficient quantity to violate the Signal Degrade threshold of the Multiplexer Section Protection. The network equipment Service Terminal indicates that switching to the standby line has occurred. The activity on the K1 K2 bytes can be monitored on the TRANSMIT TEST FUNCTION MSP Messages display.

SDH Testing MSP Stimulus/Response



1. Set up the **TRANSMIT**; **SDH** display as shown opposite.


The **CLOCK SYNC** selection determines the synchronization source for the **TRANSMIT** clock. If **EXTERNAL MTS** is selected a 2 Mb/s reference must be connected to the front panel 2M REF IN port. The format can be **CLOCK** or **DATA**.

| TRANSMITTER OUTPUT | | [SDH] | | |
|------------------------|-----------------|------------------|------|----------|
| SDH | STRUCT'D | JITTER | TEST | OVERHEAD |
| PAYLOAD | FUNCTION | SETUP | | |
| SIGNAL [STM-1 OPT]C | 1310 | [INTERNAL] | | |
| CLOCK [INTERNAL] | | [OFFSET [OFF] | | |
| MAPPING | AU-4 | [FOREGROUND] | | |
| | | [VC-4] | | |
| 140M OFFSET | | [140 Mb/s] | | |
| | | [0 ppm] | | |
| PAYLOAD TYPE | | [UNFARMED] | | |
| PATTERN | [2^23-1 PRBS] | [INVERT] | ITU | |
| STATUS: | | | | |
| MULTIPLE WINDOW | | | | |

SDH Testing MSP Stimulus/Response

2. Set up the **TRANSMIT**; TEST FUNCTION display as shown opposite.

1530 B2 BIP errors in 1 second corresponds to a BER of 1 in 10^{-5} . The Service terminal should indicate switching to standby within 1 second.




MSP Stimulus/Response 1:N Architecture

The HP 37717C Communications Performance Analyzer **TRANSMIT**;TEST FUNCTION ; **MSP MESSAGES** can be used to transmit and monitor the K1 K2 messages.

The MSP Messages are transmitted when **DOWNLOAD** is pressed.

Two displays of K1 and K2 are provided :

1. **Current TX** - Values of K1 and K2 bytes which are currently being transmitted.
2. **Current RX** - Values of K1 and K2 bytes which are currently being received.



K1 Bits 1 ->4 Selects the MSP message to be transmitted.

Table 1

K1 Bits 1 - >4

| Selection | Message | Selection | Message |
|-----------|-----------------|-----------|--------------------|
| 0000 | NO REQUEST | 1000 | MANUAL SWITCH |
| 0001 | DO NOT REVERT | 1001 | NOT USED |
| 0010 | REVERSE REQUEST | 1010 | SD - Low Priority |
| 0011 | NOT USED | 1011 | SD - High Priority |

SDH Testing
MSP Stimulus/Response

Table 1

K1 Bits 1 - >4

| Selection | Message | Selection | Message |
|-----------|-----------------|-----------|--------------------|
| 0100 | EXERCISE | 1100 | SF - Low Priority |
| 0101 | NOT USED | 1101 | SF - High Priority |
| 0110 | WAIT TO RESTORE | 1110 | FORCED SWITCH |
| 0111 | NOT USED | 1111 | LOCKOUT OF PROT |

SD - High Priority and SF - High Priority are only available when K2 bit 5 is set to 1 (1 : N architecture).

K1 Bits 5 ->8 Selects the channel used by the MSP Messages.

Table 2

K1 Bits 5 - >8

| Selection | Message | Selection | Message |
|-----------|--------------------|-----------|-----------------------|
| 0000 | NULL CHANNEL | 1000 | WORKING CHANNEL #8 |
| 0001 | WORKING CHANNEL #1 | 1001 | WORKING CHANNEL #9 |
| 0010 | WORKING CHANNEL #2 | 1010 | WORKING CHANNEL #10 |
| 0011 | WORKING CHANNEL #3 | 1011 | WORKING CHANNEL #11 |
| 0100 | WORKING CHANNEL #4 | 1100 | WORKING CHANNEL #12 |
| 0101 | WORKING CHANNEL #5 | 1101 | WORKING CHANNEL #13 |
| 0110 | WORKING CHANNEL #6 | 1110 | WORKING CHANNEL #14 |
| 0111 | WORKING CHANNEL #7 | 1111 | EXTRA TRAFFIC CHANNEL |

WORKING CHANNEL #2 through WORKING CHANNEL #14 and EXTRA TRAFFIC CHANNEL are only available when K2 Bit 5 is set to 1 : N architecture. If K1 bits 1 >4 are set to 1111 LOCKOUT OF PROT then K1 bits 5 ->8 are fixed at 0000 NULL CHANNEL.

K2 bits 1 - >4 Selects the bridged channel used by the MSP Messages. Can be set in the range 0000 to 1111.

K2 bit 5 Determines the automatic protection switch architecture.
 0 (1 + 1 architecture), 1 (1 : N architecture)

Optical Clock Recovery Stress

Application

Ideally the clock recovery circuits in the network equipment optical interfaces should recover a clock even in the presence of long strings of 0's.


The optical clock recovery performance of the network equipment can be measured by increasing the length of a zero substitution block until errors occur.

Default (Known State) Settings

It is advisable to set the HP 37717C to a known state before setting up a measurement. This clears all previous settings and provides a clearly defined instrument state. The default settings are set by selecting **OTHER STORED SETTINGS** STORED SETTING NUMBER 0 and pressing **RECALL**

Optical Clock Recovery Stress Test Setup Procedure

In this setup procedure the HP 37717C Communications Performance Analyzer transmits an STM-1 optical signal with zero's substituted into the payload data pattern. The length of the block of zero's is increased until the network equipment alarms are triggered.



SDH Testing

Optical Clock Recovery Stress

1. Connect the HP 37717C to the network equipment and set up the **TRANSMIT**; **SDH** display as shown opposite.

The CLOCK SYNC selection determines the synchronization source for the **TRANSMIT** clock. If **EXTERNAL MTS** is selected a 2 Mb/s reference must be connected to the front panel 2M REF IN port. The format can be CLOCK or DATA.

| | | |
|------------------------|-------------------------------|----------------|
| TRANSMITTER OUTPUT | | [SDH] |
| SDH | STRUCT'D | JITTER |
| PAYLOAD | TEST | OVERHEAD |
| | FUNCTION | SETUP |
| SIGNAL | [STM-1 OPT] | 1310 |
| CLOCK | [EXT MTS CLK] | [INTERNAL] |
| | | [OFF] |
| MAPPING | RU-4 | [FOREGROUND] |
| | | [UC-4] |
| 140M OFFSET | | [140 Mb/s] |
| | | [0 ppm] |
| PAYLOAD TYPE | | [UNFRAMED] |
| PATTERN | [2 ⁿ -15-1 PRBS] | [INVERT] ITU |
| STATUS: | | |
| MULTIPLE WINDOW | | |

2. Set up the **TRANSMIT**; **TEST FUNCTION** display as shown opposite

G.958 Test Pattern consists of consecutive blocks of four types of data :

All 1's

PRBS

All 0's

a data block consisting of the first row of section overhead bytes.

| | | |
|------------------------|-------------|-----------------|
| TRANSMITTER OUTPUT | | [SDH] |
| SDH | STRUCT'D | JITTER |
| PAYLOAD | TEST | OVERHEAD |
| | FUNCTION | SETUP |
| TEST FUNCTION | [SDH] | [STRESS TEST] |
| STRESSING PATTERN | | [ALL ZEROS] |
| BLOCK LENGTH | | [2] BYTES |
| STATUS: | | |
| MULTIPLE WINDOW | | |

Start the Optical Clock Recovery Stress Test

Increase the Block Length until the network equipment alarms are triggered.

Payload Mapping/Demapping

Application

The mapping and demapping of a 2 Mb/s or 140 Mb/s payload into/from the appropriate SDH containers should take place without introducing errors.

The mapping process is tested by inserting a test pattern in the 2 Mb/s or 140 Mb/s payload at the low-rate side of the terminal multiplexer. On the high-rate side of the terminal multiplexer, the payload is demapped from the SDH signal by the HP 37717C Communications Performance Analyzer.

The demapping process is tested by transmitting a SDH signal to the high-rate side of the multiplexer. On the low-rate side of the multiplexer the payload is received by the HP 37717C Communications Performance Analyzer.

A Bit error rate (BER) test is performed on the recovered payload test pattern to determine whether errors have been introduced by the mapping process.

Default (Known State) Settings

It is advisable to set the HP 37717C to a known state before setting up a measurement. This clears all previous settings and provides a clearly defined instrument state. The default settings are set by selecting **OTHER STORED SETTINGS** STORED SETTING NUMBER 0 and pressing **RECALL**

Payload Mapping/Demapping Test Setup Procedure

The following Options must be fitted to the HP 37717C to perform this test :

- UKJ or UKK - PDH Module
- A3R [A3S] - SDH Module
- UH1, 130 or 131 - STM-1/STM-4 Optical Interface

For mapping a 140 Mb/s payload, containing a test pattern, is transmitted into the low-rate side of the terminal multiplexer. The 140 Mb/s payload is demapped from the STM-4 Optical signal at the high-rate side of the terminal multiplexer.

For demapping an STM-4 Optical signal is transmitted into the high-rate side of the Add Drop multiplexer. The 140 Mb/s signal, on the low-rate side of the Add Drop multiplexer, is received by the HP 37717C Communications Performance Analyzer.

A BER measurement is performed on the demapped 140 Mb/s payload test pattern.


SDH Testing

Payload Mapping/Demapping


A SINGLE test period of 24 HOURS is used and the internal printer is enabled to record results and alarms.

The HP 37717C Communications Performance Analyzer GRAPHICS function is enabled. The graphical results can be viewed on the GRAPH display

Payload Mapping




Payload Demapping




SDH Testing Payload Mapping/Demapping


1. Connect the HP 37717C to the network equipment and set up the **OTHER** **SETTINGS CONTROL** display as shown opposite.



2. For Mapping set up the **TRANSMIT** display as shown opposite.



2a. For Demapping set up the **TRANSMIT** display as shown opposite.



SDH Testing Payload Mapping/Demapping

3. For Mapping set up the **RECEIVE** display as shown opposite.

| | |
|-----------------------------------|------------------------------------|
| RECEIVER INPUT | [SDH] |
| SDH STRUCT'D TEST OVERHEAD | |
| PAYLOAD FUNCTION MONITOR | |
| SIGNAL | [STM-1 OPT] |
| MAPPING | AU-4 [UC-4] [140 Mb/s] |
| PAYLOAD TYPE | [UNFRAMED] |
| PATTERN | [2^23-1 PRBS] [INVERT] [ITU] |
| STATUS: | |
| | MULTIPLE WINDOW |

3a. For Demapping set up the **RECEIVE** display as shown opposite.

| | |
|-----------------------------|------------------------|
| RECEIVER INPUT | [PDH] |
| MAIN STRUCT'D JITTER | |
| SETTINGS SETTINGS | |
| SIGNAL | [140 Mb/s] |
| TERMINATION | [75% UNBAL] |
| LINE CODE | [CMI] |
| LEVEL | [TERMINATE] |
| PAYLOAD TYPE | [UNFRAMED] |
| PATTERN | [2^23-1 PRBS] |
| PRBS POLARITY | [INU] [ITU] |
| STATUS: | |
| | MULTIPLE WINDOW |

4. Set up the **OTHER** display, **LOGGING** function, as shown opposite.

All results are logged to the selected logging device at 1 hour intervals. Any alarms which occur during the test period will be logged To the selected logging device.

| | |
|--------------------|-------------------------------|
| FUNCTION | [LOGGING] |
| LOGGING SETUP | [CONTROL] |
| LOGGING PERIOD | [ON] [1 HOUR] |
| RESULTS LOGGED | [SELECTED] |
| WHEN | [PERIOD] [0] |
| CONTENT | [ER & ANAL] [PER & CUMUL] |
| LOG ERROR SECONDS | [OFF] [ALL RESULTS] |
| LOG AT END OF TEST | |
| LOG ON DEMAND | RESULTS |
| STATUS: | |
| ALWAYS | PERIOD EC > 0 |
| | MULTIPLE WINDOW |

SDH Testing

Payload Mapping/Demapping

Start the Payload Mapping/Demapping Test

1. Set up the **RESULTS** display as shown opposite. If you do not require stored graphics results select STORAGE [OFF].

SHORT TERM PERIOD need only be set if it is intended to view Short Term results.

2. Press **RUN/STOP** to start the measurement.

```
RESULTS [TIMING CONTROL]
SHORT TERM PERIOD [1 SECOND ]
TEST TYPING [ SINGLE ] [ 24 HOURS ]
GRAPH STORAGE [ 15 MIN RESOL'N ]
[ INTERNAL ]

STATUS:
OFF 1 SEC 1 MIN 15 MIN 1 HR MULTIPLE
RESOL'N RESOL'N RESOL'N RESOL'N WINDOW
```

The measurement results and alarms are available on the RESULTS display during the test period.

The graphical measurement results and alarms are stored in non volatile memory for viewing later on the **GRAPH** display.

The test can be halted at any time by pressing **RUN/STOP** .

```
RESULTS [ PDH PAYLOAD ] [ ERROR ANALYSIS ]
G.821 G.826 M.2100 M.2110
BIT
EC AnD ES 2
ES 2
EFS 2
SES 2
UNRV 2
DEG_MIN 2
CODE_ES 2
ELAPSED TIME

STATUS: MULTIPLE WINDOW
```

Payload Mapping/Demapping

At the End of the Test (Payload Mapping/Demapping)

- The Date and Time the test started and the instrument setup are logged to the selected logging device.
- All results are logged to the selected logging device at 1 hour intervals.
- Any alarms which occur during the test period will be logged to the selected logging device.
- At the end of the test period a complete set of cumulative results are logged to the selected logging device.
- A graphical record of the results during the test period can be viewed on the GRAPH display. If a printer option is fitted the graph results can be logged to a printer, at a later date.
- Results and Alarm summaries can be viewed on the **GRAPH** display.

The total graphics store capacity is normally 20,000 events. An event is the occurrence of an error or an alarm.

The resolution, determined by the selection made under STORAGE on the **RESULTS** display, affects the ZOOM capability when viewing the bar graphs. If 1 SECOND is selected all resolutions are available under ZOOM. If 1 MIN is selected only 1 MIN/BAR, 15 MINS/BAR and 60 MINS/BAR are available. If 15 MINS is selected only 15 MINS/BAR and 60 MINS/BAR are available. If 1 HOUR is selected only 60 MINS/BAR is available.

Up to 10 sets of graphical results can be stored. If an attempt is made to store more than 10 sets of results, then a first in first out policy is operated and the oldest set of results will be lost. If graphics are enabled and a test is run which exceeds the remaining storage capacity, then some previously stored graphical results will be lost.

To prevent accidental overwriting of previously stored results the graphics capability should be disabled, when graphical results are not required, by selecting STORAGE [OFF] on the **RESULTS** display.

Performance Monitor Stimulus / Response

Application

Performance monitors built into the SDH network equipment count BIP errors, and communicate the results to the network controller via the Data Communication Channel (DCC). Performance monitors in Path Terminating Equipment (PTE) also communicate with the upstream equipment.

If the performance monitors are not operating correctly, degradations in network performance will pass unnoticed and may result in a failure condition.

The performance monitors can be tested by the Communications Performance Analyzer transmitting BIP errors in the appropriate byte of the overhead and monitoring upstream for the correct response :

Regenerator Section (RS) - B1 Byte of regenerator section overhead

Multiplexer Section (MS) - B2 Bytes of multiplexer section overhead

PATH B3 - B3 Byte of path overhead

Default (Known State) Settings

It is advisable to set the HP 37717C to a known state before setting up a measurement. This clears all previous settings and provides a clearly defined instrument state. The default settings are set by selecting **OTHER STORED SETTINGS** STORED SETTING NUMBER 0 and pressing **RECALL**.


Performance Monitor Stimulus/Response Test Setup Procedure

The following Options must be fitted to the HP 37717C to perform this test :


- A3R - SDH Module
- UH1,130 or 131 - STM-1/STM-4 Optical Interface

In this setup the HP 37717C Communications Performance Analyzer inserts "PATH" B3 BIP errors in byte B3 of the path overhead of the SDH signal. The upstream signal is monitored to provide a measure of the FEBE (Far End Block Error) count.

SDH Testing Performance Monitor Stimulus / Response




1. Connect the HP 37717C to the network equipment and set up the **OTHER**; **SETTINGS CONTROL** display as shown opposite.



2. Set up the **TRANSMIT**; **SDH** display as shown opposite.

The **CLOCK SYNC** selection determines the synchronization source for the **TRANSMIT** clock.



SDH Testing Performance Monitor Stimulus / Response

3. Set up the **RESULTS** display as shown opposite.

SHORT TERM PERIOD need only be set if it is intended to view Short Term results

| | | | | | |
|--------------------------|-------------------|-------------------|--------------------|------------------|---------------------|
| RESULTS [TIMING CONTROL] | | | | | |
| SHORT TERM PERIOD | [1 SECOND] | | | | |
| TEST TIMING | [MANUAL] | | | | |
| GRAPH STORAGE | [OFF] | | | | |
| | [INTERNAL] | | | | |
| STATUS: | | | | | |
| OFF | [1 SEC RESOL'N] | [1 MIN RESOL'N] | [15 MIN RESOL'N] | [1 HR RESOL'N] | [MULTIPLE WINDOW] |

HP-REI ERROR RESULTS are displayed but any of the other results can be selected from the softkey menu without affecting the measurement.

| | | | | |
|-----------------|----------|------|-----|---------------------|
| RESULTS [SDH] | | | | [CUMULATIVE] |
| PATH B3 | [PATH] | PATH | IEC | MORE |
| BIP | [FEBC] | | | |
| FEBE EC | | | | |
| FEBE ER | | | | |
| ELAPSED TIME | | | | |
| STATUS: | | | | |
| | | | | [MULTIPLE WINDOW] |

4. Set up the **TRANSMIT**; TEST FUNCTION display as shown opposite.

The ERROR RATE required can be selected from the softkey menu.

| | | | | |
|-----------------------|----------|-----------------|----------|---------------------|
| TRANSMITTER OUTPUT | | | | [SDH] |
| SDH | STRUCT'D | JITTER | [TEST] | OVERHEAD |
| | PAYLOAD | | FUNCTION | SETUP |
| TEST FUNCTION [SDH] | | [ERR & ALARM] | | |
| ERROR ADD TYPE | | [B3 BIP] | | |
| RATE | | [1E-4] | | |
| ALARM TYPE | | [OFF] | | |
| STATUS: | | | | |
| | | | | [MULTIPLE WINDOW] |

SDH Testing

Performance Monitor Stimulus / Response

Start the Performance Monitor Stimulus/Response Test

1. Press **RUN/STOP** on the HP 37717C Communications Performance Analyzer.
2. Check that the HP-REI error rate is the same as the generated B3 BIP rate.

All the measurement results are available, throughout the test, on the **RESULTS** display .

At the end of the test :

- the cumulative measurement results are available on the **RESULTS** display.

Selective Jitter Transfer Measurement

The problem with many SDH jitter analyzers is the fact that their receivers are wideband receivers and are not able to measure within a sufficiently narrow bandwidth. The reason is that these instruments are designed to measure peak to peak jitter in the transmission network for troubleshooting purposes and are not designed to make selective jitter measurements. The jitter analyzer just measures the peak-peak value of the incoming jitter over a wide frequency range. The problem occurs when testing the jitter transfer of real network equipment i.e. SDH regenerators.

The regenerator produces intrinsic jitter and this disturbs the measurement as the jitter receiver cannot determine whether it is measuring the jitter produced by the jitter analyzers transmitter or the intrinsic jitter which is generated, at a different frequency, by the regenerator. The problem is greatest at the higher jitter modulating frequencies when the amount of jitter generated, as per ITU-T G.958, is much smaller. The measurement is corrupted by the higher amplitude intrinsic jitter generated by the regenerator at lower frequencies and incorrectly measured by the analyzer.

The accurate method for measuring jitter transfer requires a selective measurement. One such method is to use a network analyzer in conjunction with the HP 37717C. The network analyzer provides the capability to measure jitter selectively and has increased sensitivity.

Default (Known State) Settings

It can be advisable to set the HP 37717C to a known state prior to setting up to make a measurement. This clears all previous settings and provides a clearly defined instrument state. The default settings are set by selecting **OTHER** **STORED** **SETTINGS** STORED SETTING NUMBER 0 and pressing **RECALL**

Test Setup Procedure (Jitter Transfer Test)


The following Options must be fitted to the HP 37717C to perform this test:

- A3K - Jitter Generation
- A3L or A3V or A3N - SDH Jitter Measurement
- A3R [A3S] - SDH Module
- UH1, 130 or 131 - STM-1/4 Optical interface

SDH Testing

Selective Jitter Transfer Measurement


This setup procedure is based on 155.52 Mb/s (STM-1), 140 Mb/s payload, PRBS test data with jitter. The jitter modulation is provided by the network analyzer. The HP 37717C demodulated jitter output is returned to the network analyzer for measurement. Before connecting to the regenerator to be tested the HP 37717C is looped back to back and the network analyzer is programmed to sweep over the required frequency range at the required amplitude. This provides a reference trace and removes the inaccuracies of the of the test configuration (inaccuracies of the HP 37717C and the Network Analyzer). The HP 37717C is connected to the regenerator and the network analyzer sweep is repeated. The difference between the two traces is the jitter transfer result.



Selective Jitter Transfer Test

1. Set up the OTHER SETTINGS CONTROL display as shown opposite.

Any SDH settings change made on the **TRANSMIT** or **RECEIVE** displays will automatically occur on the other.



SDH Testing

Selective Jitter Transfer Measurement

2. Connect the HP 37717C to the network analyzer as shown. Connect STM-1/STM-4 IN to STM-1/STM-4 OUT. Select

TRANSMIT **SDH** SDH and set up the display as shown opposite.

| | | |
|--------------------|-----------------------------|-----------------------|
| TRANSMITTER OUTPUT | | [SDH] |
| SDH | STRUCT'D | JITTER |
| PAYLOAD | TEST | OVERHEAD |
| | FUNCTION | SETUP |
| SIGNAL | [STM-4 OPT] | [1310] [INTERNAL] |
| CLOCK | [EXT MTS CLK] | [OFFSET] [OFF] |
| MAPPING | [RU-4] | [FOREGROUND] |
| | | [UC-4] |
| | | [140 Mb/s] |
| 140M OFFSET | | [0 ppm] |
| CHANNEL | STM-1 | |
| | [1] | |
| PAYLOAD TYPE | | [UNFRAMED] |
| PATTERN | [2 ²³ -1 PRBS] | [INVERT] ITU |
| STATUS: | | |
| | | MULTIPLE WINDOW |

3. Select **TRANSMIT** **SDH** **JITTER** and set up the display as shown opposite.

| | | |
|------------------------|-----------|-----------------|
| TRANSMITTER OUTPUT | | SDH |
| SDH | JITTER | TEST |
| | FUNCTION | OVERHEAD |
| | | SETUP |
| JITTER / WANDER | | [JITTER] |
| JITTER | | [ON] |
| SIGNAL FREQUENCY | | [STM-4] |
| MODULATION SOURCE | | [EXTERNAL] |
| RANGE | | [2 UI] |
| CLOCK SYNC | | EXT MTS |
| CONNECT 2MHz SOURCE TO | | SDH MODULE |
| STATUS: | | |
| [2 UI] | [10 UI] | MULTIPLE WINDOW |

4. Setup the **RECEIVE** **SDH JITTER** display as shown opposite.

If Jitter filtering is required select from the softkey menu.


| | |
|-----------------|----------------|
| RECEIVER INPUT | [SDH JITTER] |
| SIGNAL | [STM-4 OPT] |
| RECEIVER RANGE | [1.6 UI] |
| HIT THRESHOLD | [1.00 UI] |
| FILTER | [HPI] |
| LEVEL | [TERMINATE] |
| STATUS: | |
| SDH | SDH JITTER |
| MULTIPLE WINDOW | |

SDH Testing

Selective Jitter Transfer Measurement


5. Select **RESULTS** and set up the display as shown opposite.

Press **RUN/STOP** to start the measurement.



6. Adjust the network analyzer output level until the **RESULTS** display records the required peak-peak jitter value.

7. Press **RUN/STOP** to stop the measurement.



8. Start the network analyzer sweep and store the resultant "reference trace"

9. Connect the HP 37717C to the regenerator as shown (loopback removed) and repeat the network analyzer sweep.

The difference between the two traces is the Jitter Transfer result.

Automatic Alarm and BIP Error Monitoring

Application

Problems in the network at all levels in the hierarchy can be detected by the occurrence of alarms or BIP errors in each tributary of SDH systems. Since an STM-4 fibre contains up to 252 TU-12 tributaries, checking each tributary individually is time consuming and laborious.

Using the HP 37717C in a *receive only* mode, each tributary is scanned and any alarm or BIP occurrence is flagged on the **RESULTS** display. If the fibre contains an unknown signal structure (mixed payloads) the HP 37717C will quickly determine and scan that structure.

Default (Known State) Settings

It can be advisable to set the HP 37717C to a known state prior to setting up to make a measurement. This clears all previous settings and provides a clearly defined instrument state. The default settings are set by selecting **OTHER** **STORED SETTINGS** STORED SETTING NUMBER 0 and pressing **RECALL**

Test Setup Procedure (Alarm Monitoring)

The following Options must be fitted to the HP 37717C to perform this test:

- UKJ or UKK - PDH Module
- A3R [A3S] - SDH Module
- 130 or 131 - STM-1/4 Optical Interface

This setup procedure is based on STM-4 line traffic with mixed payload.

The instrument is used in a *receive only* mode to monitor Loss of Pointer, AU-AIS, HP-RDI, H4 Loss of Multiframe, TU-Loss Of Pointer, TU-AIS, LP-RDI alarms and BIP errors in AU-4, AU-3, TU-3, TU-2 and TU-12 payloads.

SDH Testing

Automatic Alarm and BIP Error Monitoring

Start the Test (Alarm Monitoring)

1. Select **START** on the **RESULTS SDH ALM SCAN** display.

If any of the alarms, Loss of Pointer, AU-AIS, HP-RDI, H4 Loss of Multiframe, TU Loss of Pointer, TU-AIS or LP-RDI has occurred the appropriate point in the hierarchy will be highlighted.

If a BIP error has occurred in the AU-4, AU-3, TU-3, TU-2 or TU-12 payload the appropriate point in the hierarchy will be highlighted.

If Unequiped is identified, the appropriate point in the hierarchy will be changed to U.

The test can be halted at any time by selecting **STOP** on the **RESULTS SDH ALM SCAN** display.

Automatic Verification of ADM Installation

Application

An important part of the ADM installation process is the verification of path routing through an ADM (or Digital Cross Connect). In order to verify the routing of VC-n paths which are terminated by the network element, the mapped payload, dropped to a PDH tributary port, must be looped back at the digital distribution frame and mapped into the VC-n at the PDH tributary insert port. VC-n paths which are not terminated must be looped back at the STM-n level. Since an STM-1 contains 63 VC-12's and a STM-4 contains 252 VC-12's, manually checking each path is time consuming and laborious.

Using the HP 37717C Tributary Scan feature the installation of ADM's can be automated and any Bit errors or Pattern Sync Loss will be flagged on the **RESULTS** display.

Default (Known State) Settings

It can be advisable to set the HP 37717C to a known state prior to setting up to make a measurement. This clears all previous settings and provides a clearly defined instrument state. The default settings are set by selecting **OTHER** **STORED SETTINGS** STORED SETTING NUMBER 0 and pressing **RECALL**

Test Setup Procedure (Alarm Monitoring)

The following Options must be fitted to the HP 37717C to perform this test:

- UKJ or UKK - PDH Module
- A3R [A3S]- SDH Module
- 130 or 131 - STM-1/4 Optical Interface


This setup procedure is based on STM-4 with 252 TU-12 payloads.

The instrument generates a STM-4 signal with 252 TU-12 tributaries. The tributaries are mapped into the STM-4 received signal and scanned by the Tributary Scan for bit errors and Pattern Sync Loss.

The Parallel printer port is enabled and the Tributary Scan results are logged to a Centronics printer

SDH Testing

Automatic Verification of ADM Installation




ADM Installation

1. Connect the HP 37717C to the ADM and set up the **OTHER** display as shown opposite.



Any changes made on the **TRANSMIT** or **RECEIVE** display will affect the other.

2. Connect a Centronics printer to the HP 37717C Parallel printer port.



3. Set up the **TRANSMIT** **SDH** display as shown below.

The MAPPING and TU PAYLOAD selections should reflect the mapping and TU payload employed in the ADM



SDH Testing

Automatic Verification of ADM Installation

4. Set up the **TRANSMIT** TEST FUNCTION display as shown opposite.

The BIT ERROR THRESHOLD setting has three choices:

> 0 - Any bit error will highlight the tributary in error.

>1E-6 - Bit error rate greater than 1 in 10^6 will highlight the tributary in error.

>1E-3 - Bit error rate greater than 1 in 10^3 will highlight the tributary in error.

| | | | | |
|--|------------------|------------------|---------------|-----------------|
| TRANSMITTER OUTPUT | | [SDH] | | |
| SDH | STRUCT'D PAYLOAD | JITTER | TEST FUNCTION | OVERHEAD |
| TEST FUNCTION | | TRIB SCAN | [STOP] | |
| BIT ERROR THRESHOLD | | [> 0] | | |
| TEST TIMING | | SINGLE | [10 SECS] | |
| SEE RESULTS PAGE FOR TRIBUTARY SCAN RESULTS | | | | |
| STATUS: | | | | |
| NONE | SDH | PDH PAYLOAD | SDH TRIB SCAN | MULTIPLE WINDOW |

TEST TIMING determines the time taken to verify each tributary. If 10 seconds is selected, in this example 252 TU-12 tributaries, the test will take approximately 55 minutes.

Start the Test (ADM Installation)

1. Select **START** on the **RESULTS SDH TRIB SCAN** display.

The "flashing" message on the status line indicates that the SDH Tributary Scan is active.

For STM-4 signals only one STM-1 is displayed at a time. To view the other STM-1's select the required number 1, 2, 3 or 4 on the **RESULTS SDH TRIB SCAN** display.

| | | |
|---|---------------|-----------------|
| RESULTS [SDH TRIB SCAN] | | START |
| STM-1 [1] | | |
| AU-4 | | |
| 1 2 3 | | |
| TUG-3 | | |
| 1 2 3 4 5 6 7 | 1 2 3 4 5 6 7 | 1 2 3 4 5 6 7 |
| 1 1 1 1 1 1 1 | 1 1 1 1 1 1 1 | 1 1 1 1 1 1 1 |
| 2 2 2 2 2 2 2 | 2 2 2 2 2 2 2 | 2 2 2 2 2 2 2 |
| 3 3 3 3 3 3 3 | 3 3 3 3 3 3 3 | 3 3 3 3 3 3 3 |
| TU-12 | | TU-12 |
| | | TU-12 |
| STATUS: | | |
| STOP | START | MULTIPLE WINDOW |

A PRBS is inserted in each tributary. If Pattern Synchronization is not achieved in 3 seconds the relevant tributary is highlighted. A Bit error measurement is performed in each tributary. The timing of the measurement is determined by the TEST TIMING selection made on the **TRANSMIT** TEST FUNCTION display, in this example 10 Seconds. If the Bit error rate exceeds the BIT ERROR THRESHOLD selected on the **TRANSMIT** TEST FUNCTION display the relevant tributary is highlighted.

SDH Testing

Automatic Verification of ADM Installation

2. Set up the **OTHER LOGGING** display as shown opposite.

PRINTER TYPE allows selection of HP printer or Alternative suppliers printer.

If [ALT. PRINTER] is selected a choice of **NORMAL** (80 column) or **COMPRESS** (40 column) is provided.

| FUNCTION | [LOGGING] |
|---------------------|------------------|
| LOGGING SETUP | [DEVICE] |
| LOGGING PORT | [PARALLEL] |
| REMOTE CONTROL PORT | HP1B |
| PRINTER TYPE | [ALT. PRINTER] |
| MODE | NORMAL |

STATUS:
NORMAL **COMPRESS** **MULTIPLE WINDOW**

3. Set up the **OTHER LOGGING** display as shown opposite.

LOG ON DEMAND [TRIB SCAN] ensures that the SDH Tributary Scan is logged to the Centronics printer when **PRINT NOW** is pressed.

At the end of the SDH Tributary Scan (the status line message is no longer "flashing") press **PRINT NOW** to log the results of all four STM-1's on the Centronics printer.

| FUNCTION | [LOGGING] |
|---------------|-------------|
| LOGGING SETUP | [CONTROL] |
| LOGGING | [OFF] |

LOG ON DEMAND **TRIB SCAN**

STATUS:
RESULTS **OVERHEAD** **OVERHEAD** **PRINTER** **SDH TRIB** **MULTIPLE**
SNAPSHOT **SNAPSHOT** **CAPTURE** **GRAPH** **SCAN** **WINDOW**

Verification of Protection Switching

Application

An important part of the installation process is the verification of protection switching mechanisms. Switching verification ensures that data integrity is maintained and revenue protected when equipment failure or fibre cuts occur. Measuring the speed of the network elements protection switch mechanism ensures data loss is minimized. The protection switch can be invoked by either removing the STM-n fibre or using the network management system to make the switch.

The protection switch times can then be measured using the HP 37717C's Service Disruption Time measurement. The measurement is made at the Path or Payload level carrying the actual service and therefore provides a real indication of the time the network takes to self heal.

Capability is also provided to invoke protection switching at the Multiplexer Section level using the K1K2 byte textual decodes otherwise known as MSP Message Generation. Both Linear Architecture MSP Messages as described in ITU-T G.783 and Ring Architecture MSPRing Messages as described in ITU-T G.841 are provided.

Default (Known State) Settings

It can be advisable to set the HP 37717C to a known state prior to setting up to make a measurement. This clears all previous settings and provides a clearly defined instrument state. The default settings are set by selecting **OTHER** **STORED SETTINGS** STORED SETTING NUMBER 0 and pressing **RECALL**

Test Setup Procedure (Verification of Protection Switching)

The following Options must be fitted to the HP 37717C to perform this test:


- UKJ or UKK - PDH Module
- A3R [A3S] - SDH Module
- 130 or 131 - STM-1/4 Optical Interface

This setup procedure is based on STM-1 with Structured PDH payload.

SDH Testing

Verification of Protection Switching

The instrument generates a STM-1 signal with a structured payload with PRBS pattern. This is inserted into the network element. The Receiver locks on to the PRBS pattern. The management system is used to invoke the protection switching. At the time of switching, pattern synchronization will be lost and will not be regained until the standby line is in place. The time interval between pattern sync loss and pattern sync gain is a measure of the disruption of service due to protection switching. This is measured by the HP 37717C.




Protection Switching Verification

SDH Testing


Verification of Protection Switching

1. Connect the HP 37717C to the ADM and set up the **OTHER** display as shown opposite.


Any changes made on the **TRANSMIT** or **RECEIVE** display will affect the other.



2. Set up the **TRANSMIT SDH** display as shown opposite.



3. Set up the **TRANSMIT STRUCTURED PAYLOAD** display as shown opposite.



SDH Testing

Verification of Protection Switching

Start the Test (Protection Switch Verification)

Press **RUN/STOP** to start the test.

Check that pattern synchronization is achieved (no errors).

Invoke the protection switch using the network management system.

Set up the **RESULTS** display as shown opposite.

The Service Disruption result is displayed when pattern synchronization is regained.

LONGEST - Longest burst of errors during measurement.

SHORTEST - Shortest burst of errors during measurement.

LAST - Length of last burst of errors detected during measurement.

| RESULTS | |
|--------------|----|
| LONGEST | ms |
| SHORTEST | ms |
| LAST | ms |
| ELAPSED TIME | |

| | | | | | |
|-----------|---------|-----------|----------|-------|----------|
| STATUS: | SERVICE | SDH | SDH TRIB | MORE | MULTIPLE |
| PDH | DISRUPT | ALM. SCAN | SCAN | | WINDOW |
| ALM. SCAN | | | | | |

Result Definitions

Information about SDH results.

Result Definitions

Trouble Scan

Trouble Scan

All possible error sources and alarms are scanned simultaneously. If any error counts are not zero then these are displayed. Up to 4 non-zero error counts are displayed in priority order

Error Count Priority

| UPDH (Option UKK[USB]) | SDH (Option A3R [A3S]) | SPDH (Option UKJ[USA]) | ATM (Option UKN) + SDH | ATM (Option UKN) + SPDH |
|-------------------------------------|---|---|---|---|
| CRC BIT CODE FRAME REBE | RS B1 BIP or B1 BIP MS B2 BIP or B2 BIP Path B3 BIP or B3 BIP VC3 PATH BIP TU2 BIP TU12 BIP A1A2 FRAME MS FEBE or MS REI PATH FEBE or HP REI PATH IEC or HP IEC VC3 PATH FEBE or HP REI TU2 FEBE or LP REI TU12 FEBE or LP REI BIT | CRC BIT CODE FAS 140M FAS 34M FAS 8M FAS 2M REBE | B1 BIP (SDH only) B2 BIP (SDH only) B3 BIP (SDH only) Non Corrected HEC Corrected HEC Lost Cells Misinserted Cells Path FEBE or REI Bit Errored Cells | EM BIP Non Corrected HEC Corrected HEC Lost Cells Misinserted Cells EM FEBE Bit Errored Cells |

If any alarms are active "ALARMS ACTIVE" is displayed.

SHOW HISTORY and the alarm led's can be used to determine which alarms are active.

If no alarms are active and no non-zero error counts are detected then "NO TROUBLE" is displayed.

Error Summary

A summary of the short term / cumulative results as counts or ratios and optical power on one display.

Short Term Results

Displays period results obtained during the measurement. The period is user-defined under SHORT TERM PERIOD on the **RESULTS** display. Many result parameters are presented in two forms: a count of error events (EC or COUNT) and a ratio of the number of errors to the total possible in the time period (ER or RATIO).

Error Count and Error Ratio results for the following error sources are available:

| | |
|-------------------|--|
| A1A2 FRAME | Compares the received Framing bytes with the known value. (Option A1T[A1U] only) |
| B1 BIP | Compares the received B1 with the recalculated value. |
| B2 BIP | Compares the received B2 with the recalculated value. |
| MS-REI | Calculated from the REI bits in the received M1 overhead byte. (Option A1T[A1U] only) |
| B3 BIP | Compares the received B3 with the recalculated value. |
| HP-REI | Calculated from the REI bits in the received G1 overhead byte. |
| HP-IEC | Calculated from the IEC bits in the received Z5 Path overhead byte. (Option A1T[A1U] only) |

If a Payload of 34 Mb/s is selected, Error Count and Error Ratio results for the following additional error sources are also available:

| | |
|---------------|--|
| TU BIP | Compares the received VC3, B3 with the recalculated value. |
| LP-REI | Calculated from the FEBE bits in the received VC3, G1 overhead byte. |

If a Payload of 2 Mb/s is selected, Error Count and Error Ratio results for the following additional error sources are also available:

| | |
|---------------|--|
| TU BIP | Compares the received V5, BIP-2 in the TU12 selected for test with the recalculated value. |
| LP-REI | Calculated from the FEBE bits in the V5 overhead byte of the TU12 selected for test. |

Cumulative Results

Provides a cumulative display of the results during the measurement period. Many result parameters are presented in two forms: a count of error events (EC or COUNT) and a ratio of the number of errors to the total possible in the time period (ER or RATIO).

Error Count and Error Ratio results for the following error sources are available:

| | |
|-------------------|---|
| A1A2 FRAME | Compares the received Framing bytes with the known value. (Option A1T[A1U] only) |
| B1 BIP | Compares the received B1 with the recalculated value. |
| B2 BIP | Compares the received B2 with the recalculated value. |
| MS-REI | Calculated from the REI bits in the received M1 overhead byte. (Option A1T[A1U] only) |
| B3 BIP | Compares the received B3 with the recalculated value. |
| HP-REI | Calculated from the REI bits in the received G1 overhead byte. |
| HP-IEC | Calculated from the PIEC bits in the received Z5 Path overhead byte. (Option A1T[A1U] only) |

If a Payload of 34 Mb/s is selected, Error Count and Error Ratio results for the following additional error sources are also available:

| | |
|---------------|--|
| TU BIP | Compares the received VC3, B3 with the recalculated value. |
| LP-REI | Calculated from the FEBE bits in the received VC3, G1 overhead byte. |

If a Payload of 2 Mb/s is selected, Error Count and Error Ratio results for the following additional error sources are also available:

| | |
|---------------|--|
| TU BIP | Compares the received V5, BIP-2 in the TU12 selected for test with the recalculated value. |
| LP-REI | Calculated from the FEBE bits in the V5 overhead byte of the TU12 selected for test. |

Result Definitions

SDH Error Analysis

SDH Error Analysis

Analysis results are calculated for the following error sources:

B1 BIP; B2 BIP; MS-REI; B3 BIP; HP-REI and HP-IEC. If a Payload of 34 Mb/s or 2 Mb/s is selected additional error sources of TU BIP and LP-REI are also available.

G.826 Analysis B1 BIP

These calculations are based on "Errored Blocks". A Block is a set of consecutive bits associated with the Path. Each bit belongs to one and only one block. If an STM-4 interface is selected an errored block is a BIP with one or more bits in error.

Table 3-1

G.826 Analysis B1 BIP

| Display | Definition |
|---------|---|
| ES | Errored Seconds - Cumulative count of 1 second periods that contain at least 1 Errored Block. |
| EB | Errored Block count - cumulative count of errored blocks. |
| SES | Severely errored Seconds - Cumulative count of 1 second periods with ≥ 2400 Errored Blocks, or containing a "defect". Defects are LOS and LOF. |
| UNAV | Unavailability - Cumulative count of unavailable seconds. A period of unavailability begins at the start of 10 or more consecutive severely errored seconds, and ends at the start of 10 or more consecutive non severely errored seconds. |
| ESR | Error Second Ratio - The ratio of errored seconds to the total seconds of available time. A period of unavailability begins at the start of 10 or more consecutive Severely Errored Seconds, and ends at the start of 10 or more non Severely Errored Seconds. |
| SESR | Severely Errored Second Ratio - The ratio of severely errored seconds to the total seconds of available time. |
| BBEC | Background Block error count - Cumulative count of errored blocks which occur outwith a severely errored second. |
| BBER | Background Block error Ratio - The ratio of errored blocks to total blocks. Total blocks excludes severely errored seconds and periods of unavailability. |

Result Definitions
SDH Error Analysis

G.826 Analysis B2 BIP

These calculations are based on "Errored Blocks". A Block is a set of consecutive bits associated with the Path. Each bit belongs to one and only one block. If an STM-4 interface is selected an errored block is a BIP with one or more bits in error.

Table 3-2

G.826 Analysis MS B2 BIP

| Display | Definition |
|---------|---|
| ES | Errored Seconds - Cumulative count of 1 second periods that contain at least 1 Errored Block. |
| EB | Errored Block count - cumulative count of errored blocks. |
| SES | Severely errored Seconds - Cumulative count of 1 second periods with ≥ 2400 Errored Blocks, or containing a "defect". Defects are LOS, LOF and MS-AIS. |
| UNAV | Unavailability - Cumulative count of unavailable seconds. A period of unavailability begins at the start of 10 or more consecutive severely errored seconds, and ends at the start of 10 or more consecutive non severely errored seconds. |
| ESR | Error Second Ratio - The ratio of errored seconds to the total seconds of available time. A period of unavailability begins at the start of 10 or more consecutive Severely Errored Seconds, and ends at the start of 10 or more non Severely Errored Seconds. |
| SESR | Severely Errored Second Ratio - The ratio of severely errored seconds to the total seconds of available time. |
| BBEC | Background Block error count - Cumulative count of errored blocks which occur outwith a severely errored second. |
| BBER | Background Block error Ratio - The ratio of errored blocks to total blocks. Total blocks excludes severely errored seconds and periods of unavailability. |

Result Definitions

SDH Error Analysis

G.826 Analysis MS-REI

These calculations are based on "Errored Blocks". A Block is a set of consecutive bits associated with the Path. Each bit belongs to one and only one block. If an STM-4 interface is selected an errored block is a REI with one or more bits in error.

Table 3-3

G.826 Analysis MS-REI

| Display | Definition |
|---------|---|
| ES | Errored Seconds - Cumulative count of 1 second periods that contain at least 1 Errored Block. |
| EB | Errored Block count - cumulative count of errored blocks. |
| SES | Severely errored Seconds - Cumulative count of 1 second periods with \geq 2400 Errored Blocks, or MS-RDI. |
| UNAV | Unavailability - Cumulative count of unavailable seconds. A period of unavailability begins at the start of 10 or more consecutive severely errored seconds, and ends at the start of 10 or more consecutive non severely errored seconds. |
| ESR | Error Second Ratio - The ratio of errored seconds to the total seconds of available time. A period of unavailability begins at the start of 10 or more consecutive Severely Errored Seconds, and ends at the start of 10 or more non Severely Errored Seconds. |
| SESR | Severely Errored Second Ratio - The ratio of severely errored seconds to the total seconds of available time. |
| BBEC | Background Block error count - Cumulative count of errored blocks which occur outwith a severely errored second. |
| BBER | Background Block error Ratio - The ratio of errored blocks to total blocks. Total blocks excludes severely errored seconds and periods of unavailability. |

NOTE

Near End Failures of LOS, LOF and MS-AIS produce "dead time" in the MS-REI measurement such that result accumulation is suspended.

Result Definitions
SDH Error Analysis

G.826 B3 BIP Analysis

These calculations are based on "Errored Blocks". A Block is a set of consecutive bits associated with the Path. Each bit belongs to one and only one block.

Table 3-4

G.826 Analysis B3 BIP

| Display | Definition |
|---------|---|
| ES | Errored Seconds - Cumulative count of 1 second periods that contain at least 1 Errored Block. |
| EB | Errored Block count - cumulative count of errored blocks. |
| SES | Severely errored Seconds - Cumulative count of 1 second periods with ≥ 2400 Errored Blocks, or containing a "defect". Defects are LOS, LOF, MS-AIS, LOP and AU-AIS. |
| UNAV | Unavailability - Cumulative count of unavailable seconds. A period of unavailability begins at the start of 10 or more consecutive severely errored seconds, and ends at the start of 10 or more consecutive non severely errored seconds. |
| ESR | Error Second Ratio - The ratio of errored seconds to the total seconds of available time. A period of unavailability begins at the start of 10 or more consecutive Severely Errored Seconds, and ends at the start of 10 or more non Severely Errored Seconds. |
| SESR | Severely Errored Second Ratio - The ratio of severely errored seconds to the total seconds of available time. |
| BBEC | Background Block error count - Cumulative count of errored blocks which occur outwith a severely errored second. |
| BBER | Background Block error Ratio - The ratio of errored blocks to total blocks. Total blocks excludes severely errored seconds and periods of unavailability. |
| PUAS | Path Unavailable Second count - Logical OR of the Near and Far end unavailable seconds. |

Result Definitions
SDH Error Analysis

G.826 HP-REI Analysis

These calculations are based on "Errored Blocks". A Block is a set of consecutive bits associated with the Path. Each bit belongs to one and only one block.

Table 3-5

G.826 Analysis HP-REI

| Display | Definition |
|---------|---|
| ES | Errored Seconds - Cumulative count of 1 second periods that contain at least 1 Errored Block. |
| EB | Errored Block count - cumulative count of errored blocks. |
| SES | Severely errored Seconds - Cumulative count of 1 second periods with >= 2400 Errored Blocks, or HP-RDI. |
| UNAV | Unavailability - Cumulative count of unavailable seconds. A period of unavailability begins at the start of 10 or more consecutive severely errored seconds, and ends at the start of 10 or more consecutive non severely errored seconds. |
| ESR | Error Second Ratio - The ratio of errored seconds to the total seconds of available time. A period of unavailability begins at the start of 10 or more consecutive Severely Errored Seconds, and ends at the start of 10 or more non Severely Errored Seconds. |
| SESR | Severely Errored Second Ratio - The ratio of severely errored seconds to the total seconds of available time. |
| BBEC | Background Block error count - Cumulative count of errored blocks which occur outwith a severely errored second. |
| BBER | Background Block error Ratio - The ratio of errored blocks to total blocks. Total blocks excludes severely errored seconds and periods of unavailability. |
| PUAS | Path Unavailable Second count - Logical OR of the Near and Far end unavailable seconds. |

NOTE

Near End Failures of LOS, LOF, MS-AIS, AU-LOP and AU-AIS produce "dead time" in the HP-REI measurement such that result accumulation is suspended.

Result Definitions
SDH Error Analysis

G.826 HP-IEC Analysis

These calculations are based on "Errored Blocks". A Block is a set of consecutive bits associated with the Path. Each bit belongs to one and only one block.

Table 3-6

G.826 Analysis HP-IEC

| Display | Definition |
|---------|---|
| ES | Errored Seconds - Cumulative count of 1 second periods that contain at least 1 Errored Block. |
| EB | Errored Block count - cumulative count of errored blocks. |
| SES | Severely errored Seconds - Cumulative count of 1 second periods with ≥ 2400 Errored Blocks, or containing a "defect". Defects are LOS, LOF, MS-AIS, LOP, AU-AIS and HP-RDI. |
| UNAV | Unavailability - Cumulative count of unavailable seconds. A period of unavailability begins at the start of 10 or more consecutive severely errored seconds, and ends at the start of 10 or more consecutive non severely errored seconds. |
| ESR | Error Second Ratio - The ratio of errored seconds to the total seconds of available time. A period of unavailability begins at the start of 10 or more consecutive Severely Errored Seconds, and ends at the start of 10 or more non Severely Errored Seconds. |
| SESR | Severely Errored Second Ratio - The ratio of severely errored seconds to the total seconds of available time. |
| BBEC | Background Block error count - Cumulative count of errored blocks which occur outwith a severely errored second. |
| BBER | Background Block error Ratio - The ratio of errored blocks to total blocks. Total blocks excludes severely errored seconds and periods of unavailability. |
| PUAS | Path Unavailable Second count - Logical OR of the Near and Far end unavailable seconds. |

NOTE

Near End Failures of LOS, LOF, MS-AIS, AU-LOP and AU-AIS produce "dead time" in the HP-IEC measurement such that result accumulation is suspended.

Result Definitions
SDH Error Analysis

G.826 TU BIP Analysis - 34 Mb/s Payload

These calculations are based on "Errored Blocks". A Block is a set of consecutive bits associated with the Path. Each bit belongs to one and only one block.

Table 3-7

G.826 Analysis TU BIP - 34 Mb/s Payload

| Display | Definition |
|---------|---|
| ES | Errored Seconds - Cumulative count of 1 second periods that contain at least 1 Errored Block. |
| EB | Errored Block count - cumulative count of errored blocks. |
| SES | Severely errored Seconds - Cumulative count of 1 second periods with \geq 2400 Errored Blocks, or containing a "defect". Defects are LOS, LOF, MS AIS, LOP, AU-AIS, H4 LOM, TU3-AIS and TU3-LOP. |
| UNAV | Unavailability - Cumulative count of unavailable seconds. A period of unavailability begins at the start of 10 or more consecutive severely errored seconds, and ends at the start of 10 or more consecutive non severely errored seconds. |
| ESR | Error Second Ratio - The ratio of errored seconds to the total seconds of available time. A period of unavailability begins at the start of 10 or more consecutive Severely Errored Seconds, and ends at the start of 10 or more non Severely Errored Seconds. |
| SESR | Severely Errored Second Ratio - The ratio of severely errored seconds to the total seconds of available time. |
| BBEC | Background Block error count - Cumulative count of errored blocks which occur outwith a severely errored second. |
| BBER | Background Block error Ratio - The ratio of errored blocks to total blocks. Total blocks excludes severely errored seconds and periods of unavailability. |
| PUAS | Path Unavailable Second count - Logical OR of the Near and Far end unavailable seconds. |

Result Definitions
SDH Error Analysis

G.826 TU BIP Analysis - 2 Mb/s Payload

These calculations are based on "Errored Blocks". A Block is a set of consecutive bits associated with the Path. Each bit belongs to one and only one block.

Table 3-8

G.826 Analysis TU BIP - 2 Mb/s Payload

| Display | Definition |
|---------|---|
| ES | Errored Seconds - Cumulative count of 1 second periods that contain at least 1 Errored Block. |
| EB | Errored Block count - cumulative count of errored blocks. |
| SES | Severely errored Seconds - Cumulative count of 1 second periods with ≥ 600 Errored Blocks, or containing a "defect". Defects are LOS, LOF, MS AIS, LOP, AU-AIS, H4 LOM, TU-IS and TU-LOP. |
| UNAV | Unavailability - Cumulative count of unavailable seconds. A period of unavailability begins at the start of 10 or more consecutive severely errored seconds, and ends at the start of 10 or more consecutive non severely errored seconds. |
| ESR | Error Second Ratio - The ratio of errored seconds to the total seconds of available time. A period of unavailability begins at the start of 10 or more consecutive Severely Errored Seconds, and ends at the start of 10 or more non Severely Errored Seconds. |
| SESR | Severely Errored Second Ratio - The ratio of severely errored seconds to the total seconds of available time. |
| BBEC | Background Block error count - Cumulative count of errored blocks which occur outwith a severely errored second. |
| BBER | Background Block error Ratio - The ratio of errored blocks to total blocks. Total blocks excludes severely errored seconds and periods of unavailability. |
| PUAS | Path Unavailable Second count - Logical OR of the Near and Far end unavailable seconds. |

Result Definitions
SDH Error Analysis

G.826 LP-REI Analysis - 34 Mb/s Payload

These calculations are based on "Errored Blocks". A Block is a set of consecutive bits associated with the Path. Each bit belongs to one and only one block.

Table 3-9

G.826 Analysis LP-REI, 34 Mb/s Payload

| Display | Definition |
|---------|---|
| ES | Errored Seconds - Cumulative count of 1 second periods that contain at least 1 Errored Block. |
| EB | Errored Block count - cumulative count of errored blocks. |
| SES | Severely errored Seconds - Cumulative count of 1 second periods with >= 2400 Errored Blocks, or LP-RDI. |
| UNAV | Unavailability - Cumulative count of unavailable seconds. A period of unavailability begins at the start of 10 or more consecutive severely errored seconds, and ends at the start of 10 or more consecutive non severely errored seconds. |
| ESR | Error Second Ratio - The ratio of errored seconds to the total seconds of available time. A period of unavailability begins at the start of 10 or more consecutive Severely Errored Seconds, and ends at the start of 10 or more non Severely Errored Seconds. |
| SESR | Severely Errored Second Ratio - The ratio of severely errored seconds to the total seconds of available time. |
| BBEC | Background Block error count - Cumulative count of errored blocks which occur outwith a severely errored second. |
| BBER | Background Block error Ratio - The ratio of errored blocks to total blocks. Total blocks excludes severely errored seconds and periods of unavailability. |
| PUAS | Path Unavailable Second count - Logical OR of the Near and Far end unavailable seconds. |

NOTE

Near End Failures of LOS, LOF, MS-AIS, AU-LOP, AU-AIS, H4 LOM, TU-LOP and TU-AIS produce "dead time" in the LP-REI measurement such that result accumulation is suspended.

Result Definitions
SDH Error Analysis

G.826 LP-REI Analysis - 2 Mb/s Payload

These calculations are based on "Errored Blocks". A Block is a set of consecutive bits associated with the Path. Each bit belongs to one and only one block.

Table 3-10

G.826 Analysis LP-REI - 2 Mb/s Payload

| Display | Definition |
|---------|---|
| ES | Errored Seconds - Cumulative count of 1 second periods that contain at least 1 Errored Block. |
| EB | Errored Block count - cumulative count of errored blocks. |
| SES | Severely errored Seconds - Cumulative count of 1 second periods with >= 600 Errored Blocks, or TU3 Path FERF . |
| UNAV | Unavailability - Cumulative count of unavailable seconds. A period of unavailability begins at the start of 10 or more consecutive severely errored seconds, and ends at the start of 10 or more consecutive non severely errored seconds. |
| ESR | Error Second Ratio - The ratio of errored seconds to the total seconds of available time. A period of unavailability begins at the start of 10 or more consecutive Severely Errored Seconds, and ends at the start of 10 or more non Severely Errored Seconds. |
| SESR | Severely Errored Second Ratio - The ratio of severely errored seconds to the total seconds of available time. |
| BBEC | Background Block error count - Cumulative count of errored blocks which occur outwith a severely errored second. |
| BBER | Background Block error Ratio - The ratio of errored blocks to total blocks.Total blocks excludes severely errored seconds and periods of unavailability. |
| PUAS | Path Unavailable Second count - Logical OR of the Near and Far end unavailable seconds. |

NOTE

Near End Failures of LOS, LOF, MS-AIS, AU-LOP, AU-AIS, H4 LOM, TU-LOP and TU-AIS produce "dead time" in the LP-REI measurement such that result accumulation is suspended.

Result Definitions
SDH Pointer Value Results

SDH Pointer Value Results

Table 3-11 **Pointer Value**

| Display | Definition |
|--------------------|--|
| Pointer Value | The received Pointer value. |
| NDF | The number of seconds containing one or more active New Data Flag |
| Missing NDF | The number of seconds containing one or more VC moves with no accompanying active New Data Flag. |
| POS ADJUSTMENTS | The number of positive pointer adjustments in the measurement period and the number of seconds in the measurement period which contain one or more positive adjustments. |
| NEG ADJUSTMENTS | The number of negative pointer adjustments in the measurement period and the number of seconds in the measurement period which contain one or more negative adjustments. |
| IMPLIED VC4 OFFSET | The total number of positive and negative pointer movements during the measurement are counted and the implied mean VC offset, is calculated in ppm. |

Result Definitions
SDH Pointer Value Results

SDH Alarm Seconds

Table 3-12

SDH Alarm Seconds

| Alarm | Payload | STM-1 | STM-4 |
|-----------------------------|----------------------|-------|-------|
| Power Loss | Yes | Yes | Yes |
| Loss of Signal (LOS) | Yes | Yes | Yes |
| Loss of Frame (LOF) | Yes | Yes | Yes |
| Out of Frame (OOF) | Yes | Yes | Yes |
| Loss of Pointer (AU-LOP) | Yes | Yes | No |
| MS-AIS | Yes | Yes | Yes |
| K1K2 Change (A1T[A1U] only) | Yes | Yes | Yes |
| AU-AIS | Yes | Yes | No |
| MS-RDI | Yes | Yes | Yes |
| HP-RDI | Yes | Yes | No |
| H4 LOM | Not 140 Mb/s Payload | No | No |
| TU-LOP | Not 140 Mb/s Payload | No | No |
| TU-AIS | Not 140 Mb/s Payload | No | No |
| LP-RDI | Not 140 Mb/s Payload | No | No |

Frequency Measurement

Frequency measurement is available at standard PDH and SDH rates.

The measured frequency is displayed in Hz with 1 Hz resolution.

Offset from the standard rate is displayed in Hz and ppm (parts per million).

Optical Power

Optical Power measurement is available for SDH optical signals.

The received optical power, 0 to -30dBm is displayed with an accuracy of ± 1 dB.

Result Definitions
Optical Power

SDH Logging Messages

Logging Devices

Results may be logged to the Disc Drive. A bit map of graphics results can be recorded on the disk drive by using the screen dump feature.

If Remote Control Option A3X is fitted, results may be logged to the Internal Printer.

If Remote Control Option A3B or A3D, is fitted the following types of External printer can be used for results logging:

- HP-IB HP 550C DeskJet printer
- RS-232-C HP 550C DeskJet printer
- An alternative suppliers RS-232-C printer

The alternative suppliers RS-232-C printer can be 40 column width or 80 column width. If a 40 column width printer is used Graphics results cannot be logged.

- A Centronics parallel printer

Results Logging

Header and results are logged to the selected device when:

- **PRINT NOW** is pressed.
- If LOGGING [ON] is selected on the **OTHER LOGGING** display and a measurement is started by pressing **RUN/STOP**

```

=====
                        Hewlett Packard HP37717C
                        Instrument Configuration
=====
RECEIVER
Receive Signal   : STM-1 ELECTRICAL
Level           : TERMINATE
Mapping         : AU-4      VC-4      140 Mb/s
Payload Type    : UNFRAMED
Pattern        : 2^23-1      Polarity      : INVERTED
MEASUREMENT STARTED  23 Jul 97  10:27:13      Print Period  10 Minutes
=====

```

Logging Header Example

If **PRINT NOW** is pressed the cumulative results are logged. If a measurement is in progress the current results are logged. If a measurement is not in progress the cumulative results for the last measurement are logged.

During the Measurement Period

If LOG ERROR SECOND [ON] is selected on the **OTHER LOGGING** display all occurrences of an Error Second will be logged:

- Bit
- Code (PDH)
- Frame (PDH)
- CRC (PDH)
- REBE (PDH)
- DS3 Frame (SDH)
- DS3 P-Bit (SDH)

SDH Logging Messages

Results Logging

- DS3 C-Bit (SDH)
- DS3 FEBE (SDH)
- DS1 Frame (SDH)
- DS1 CRC6 (SDH)
- A1A2 FRAME (SDH)
- RS B1 BIP/B1 BIP (SDH)
- MS B2 BIP/B2 BIP (SDH)
- MS FEBE/RS REI (SDH)
- Path B3 BIP/B3 BIP (SDH)
- Path FEBE/HP REI (SDH)
- Path IEC/HP IEC (SDH)
- TU Path BIP (SDH)
- TU Path FEBE/LP REI (SDH)
- Hit Count (Jitter)
- Hit seconds (Jitter)
- Positive Peak Amplitude (Jitter)
- Negative Peak Amplitude (Jitter)
- Peak to Peak Amplitude (Jitter)
- RMS Amplitude (Jitter)
- Positive Peak (2Mb/s Wander)
- Negative Peak (2Mb/s Wander)
- Peak to Peak (2Mb/s Wander)
- Peak to Peak (15 min) (2Mb/s Wander)
- Peak to Peak (24 hours) (2Mb/s Wander)
- Time Interval Error (2Mb/s Wander)
- Estimated Bit Slips (2Mb/s Wander)
- Estimated Frame Slips (2Mb/s Wander)
- EM BIP (ATM)

SDH Logging Messages

Results Logging

- FEBE/REI (ATM)
- Corrected HEC (ATM)
- Non Corrected HEC (ATM)
- Cell Loss (ATM)
- Errored Cells (ATM)
- Misinserted Cells (ATM)

All Alarm occurrences will be logged both when set and cleared:

- Signal Loss
- AIS (PDH & ATM)
- Pattern Sync Loss (PDH & ATM)
- Loss Of Frame (SDH, PDH & ATM)
- Out Of Frame (SDH)
- Multiframe (PDH)
- Remote Loss (PDH)
- Remote Multiframe Loss (PDH)
- Loss of Pointer (SDH)
- MS AIS (SDH)
- Path AIS/AU AIS (SDH)
- Pattern Loss (SDH)
- Clock Loss (SDH)
- MS FERF/MS RDI (SDH)
- Path FERF/HP RDI (SDH)
- K1K2 Change (SDH)
- H4 Multiframe Loss (SDH)
- TU Loss of Pointer (SDH)
- TU AIS (SDH)
- TU Path FERF/LP RDI (SDH)
- DS3 Frame Loss (SDH)

SDH Logging Messages

Results Logging

- DS3 AIS (SDH)
- DS3 FERF (SDH)
- DS1 Frame Loss (SDH)
- DS1 AIS (SDH)
- DS1 FERF (SDH)
- Jitter Lock Loss (Option UHN[US9])
- Excess Jitter (Option UHN[US9])
- Excess Wander (Option UHN[US9])
- Wander Ref Loss (Option UHN[US9])
- Wander Signal Loss (Option UHN[US9])
- FERF/RDI (ATM)
- Loss of Cell Sync (ATM)
- Selected Cell Not Received (ATM)
- Congestion Experienced (ATM)
- Test Cell Loss (ATM)
- VP AIS (ATM)
- VP FERF/VP RDI (ATM)
- VC AIS (ATM)
- VC FERF/VC RDI (ATM)

In addition the following events are logged:

- All Alarms Clear
- Power Failure
- Power Restored
- New Day
- Squelched - Printing stopped to conserve paper during period of Unavailability
- Unsquelched - Printing restarted after period of Unavailability
- Print Demanded - if **PRINT NOW** is pressed.

SDH Logging Messages

Results Logging

- Print Period - if selected on **OTHER LOGGING** display.
- Printing Enabled - if Printer enabled during a measurement.
- Measurement Complete

```
| 10:27:32 LOS SET
| 10:27:32 LOF SET
| 10:27:32 OOF SET
| 10:27:32 AU-LOP SET
| 10:27:32 Pattern Loss SET
| 10:27:35 LOS CLEAR
| 10:27:35 LOF CLEAR
| 10:27:35 OOF CLEAR
| 10:27:35 AU-LOP CLEAR
| 10:27:35 Pattern Loss CLEAR
| 10:27:35 OOF SET
| 10:27:35 OOF CLEAR
| 10:27:35 ALL ALARMS CLEAR
| 10:27:36 Pattern Loss SET
| 10:27:36 Pattern Loss CLEAR
| 10:27:37 ALL ALARMS CLEAR
| 10:27:41 OOF SET
| 10:27:41 OOF CLEAR
| 10:27:42 Pattern Loss SET
| 10:27:42 Pattern Loss CLEAR
| 10:27:42 ALL ALARMS CLEAR
| 10:27:44 OOF SET
| 10:27:44 OOF CLEAR
| 10:27:45 Pattern Loss SET
| 10:27:45 Pattern Loss CLEAR
| 10:27:46 ALL ALARMS CLEAR
| 10:28:42 LOS SET
| 10:28:42 LOF SET
| 10:28:42 OOF SET
| 10:28:42 AU-LOP SET
| 10:28:42 Pattern Loss SET
| 10:28:44 LOS CLEAR
| 10:28:44 LOF CLEAR
| 10:28:44 OOF CLEAR
| 10:28:44 AU-LOP CLEAR
| 10:28:44 Pattern Loss CLEAR
| 10:28:44 OOF SET
| 10:28:44 OOF CLEAR
| 10:28:44 ALL ALARMS CLEAR
| 10:28:45 Pattern Loss SET
| 10:28:45 Pattern Loss CLEAR
| 10:28:46 ALL ALARMS CLEAR
```

Logging During Measurement Example

SDH Logging Messages

Results Logging

At the End of the Measurement Period

A complete set of measurement results are logged.

```

=====
MEASUREMENT COMPLETE 23 Jul 97 10:28:57 Elapsed Time 00d 00h 01m 43s
=====
Cumulative Results

Error Results :
          A1A2      RS B1      MS B2      MS-      PATH B3
          FRAME     BIP       BIP       REI      BIP
Error Count      393          93        307    1.065E+06    244201
Error Ratio      9.860E-06    5.761E-09    1.923E-08    6.965E-05    1.565E-05

          HP-      HP-      TU      LP-
          REI      IEC      BIP     REI
Error Count      69      239895    N/A     N/A
Error Ratio      4.617E-09    1.605E-05    N/A     N/A

          BIT (test)      CODE      CRC      REBE
Error Count      2.463E+08    N/A     N/A     N/A
Error Ratio      1.704E-02    N/A     N/A     N/A

Analysis Results :
          G.826 ANALYSIS
          RS B1      MS B2      MS-      PATH B3
          BIP       BIP       REI      BIP
Errored Blocks      20          23      64000    79708
Errored Seconds      10          10       10       39
Severely Errored Seconds      6          6         9       18
Unavailable Seconds      0          0         0         0
Path Unavailable Seconds      N/A         0         0         0
Background Block Errors      14          16         1      10477
Errored Second Ratio      9.709E-02    9.709E-02    1.031E-01    3.786E-01
Severely Errored Sec Ratio      5.825E-02    5.825E-02    9.278E-02    1.748E-01
Background Block Err Ratio      1.804E-05    2.062E-05    1.420E-06    1.541E-02

          HP-      HP-      TU      LP-
          REI      IEC      BIP     REI
Errored Blocks      10      122155    N/A     N/A
Errored Seconds      4         3       N/A     N/A
Severely Errored Seconds      0         0       N/A     N/A
Unavailable Seconds      0         19      N/A     N/A
Path Unavailable Seconds      0         N/A     N/A     N/A
Background Block Errors      10         9       N/A     N/A
Errored Second Ratio      4.124E-02    3.846E-02    N/A     N/A
Severely Errored Sec Ratio      0         0       N/A     N/A
Background Block Err Ratio      1.289E-05    1.442E-05    N/A     N/A

          G.821 ANALYSIS
          BIT (test)      FAS 140M      FAS 34M      FAS 8M      FAS 2M
Errored Sec      14          N/A     N/A     N/A     N/A
%Errored Sec      13.59223    N/A     N/A     N/A     N/A
%ES (Annex D)      6.79612    N/A     N/A     N/A     N/A
Error Free Sec      89          N/A     N/A     N/A     N/A
%Error Free Sec      86.40777    N/A     N/A     N/A     N/A
Severely Err Sec      14          N/A     N/A     N/A     N/A
%Severely Err Sec      13.59223    N/A     N/A     N/A     N/A
Degraded Minutes      0          N/A     N/A     N/A     N/A
%Degraded Minutes      0.00000    N/A     N/A     N/A     N/A
Unavailable Sec      0          N/A     N/A     N/A     N/A
%Unavailable Sec      0.00000    N/A     N/A     N/A     N/A
    
```

SDH Logging Messages

Results Logging

| | | | | |
|----------------------------|--------------|--------------|---------------|---------------|
| G.826 ANALYSIS | | | | |
| | Near 140Mb/s | Far | Near 34Mb/s | Far |
| Errored Seconds | 6 | N/A | N/A | N/A |
| Severely Errored Seconds | 6 | N/A | N/A | N/A |
| Unavailable Seconds | 0 | N/A | N/A | N/A |
| Errored Second Ratio | 5.825E-02 | N/A | N/A | N/A |
| Severely Errored Sec Ratio | 5.825E-02 | N/A | N/A | N/A |
| M.2100 ANALYSIS | | | | |
| | Rx 140Mb/s | Tx | Rx 34Mb/s | Tx |
| Errored Seconds | 14 | N/A | N/A | N/A |
| Severely Errored Seconds | 14 | N/A | N/A | N/A |
| Unavailable Seconds | 0 | N/A | N/A | N/A |
| M.2110 ANALYSIS | | | | |
| BIS Results | | 2-hr WAIT | 24-hr WAIT | 7-day WAIT |
| Frequency : | N/A Hz | Offset : | N/AHz | Offset : |
| | | | | N/Appm |
| Pointer Results : | AU POINTER | | TU POINTER | |
| | Count | Seconds | Count | Seconds |
| NDF | | 3 | | N/A |
| Missing NDF | | 4 | | N/A |
| +ve Pointer Adjustments | 3 | 3 | N/A | N/A |
| -ve Pointer Adjustments | 5 | 4 | N/A | N/A |
| Implied VC Offset | 0.0 | | N/A | |
| Pointer Value | 256 | | N/A | |

Logging At End of Measurement Example

Bar Graph Logging

To log the Bar Graphs:

On the **OTHER LOGGING** display, LOGGING SETUP **DEVICE**, select the required logging device under LOGGING PORT .

On the **OTHER LOGGING** CONTROL display, select LOGGING [ON] .


Display the Bar Graphs required on the Bar Graph display and press **PRINT** .

Select **THIS SCREEN**

The Error Summary, the Alarm Summary, the selected Bar Graphs and the Alarms Graph are logged.

SDH Logging Messages

Results Logging



Bar Graph Logging Example

Graphics Text Results Logging

To log the Alarm Summaries:

Select the required logging device under LOGGING PORT on the **OTHER LOGGING** display.

Select LOGGING [ON] on the **OTHER LOGGING** display.

Display the results required on the Text Results display and press **PRINT**.

The Error Summary and Alarm Summary are logged.

SDH Logging Messages

Results Logging

Results Snapshot Logging

To log the Results Snapshot:

Select the required External logging device under LOGGING PORT on the **OTHER LOGGING** display.

Select LOGGING [ON] on the **OTHER LOGGING** display.

Select LOG ON DEMAND [RESULTS] on the **OTHER LOGGING** display and press **PRINT NOW**.

```
=====
                                Hewlett Packard HP37717C
                                Instrument Configuration
=====
RECEIVER
  Receive Signal   : STM-1 ELECTRICAL
  Level           : TERMINATE
  Mapping         : AU-4      VC-4      140 Mb/s
  Payload Type    : UNFRAMED
  Pattern         : 2^23-1      Polarity      : INVERTED

MEASUREMENT STARTED 23 Jul 97 10:35:59      Print Period 10 Minutes
=====
10:37:19 PRINT DEMANDED- RESULTS SNAPSHOT      Elapsed Time 00d 00h 01m 20s
=====
                                Cumulative Results

Error Results :

          A1A2      RS B1      MS B2      MS-      PATH B3
          FRAME    BIP        BIP        REI      BIP
Error Count      293      81633     261      876107    95
Error Ratio      9.538E-06  6.561E-06  2.121E-08  7.793E-05  7.899E-09

          HP-      HP-      TU      LP-
          REI      IEC      BIP      REI
Error Count      23      607484    N/A      N/A
Error Ratio      1.961E-09  5.181E-05  N/A      N/A

          BIT (test)      CODE      CRC      REBE
Error Count      1.840E+08  N/A      N/A      N/A
Error Ratio      1.651E-02  N/A      N/A      N/A

Analysis Results :

          G.826 ANALYSIS
          RS B1      MS B2      MS-      PATH B3
          BIP        BIP        REI      BIP
Errored Blocks      42284      18      45573      20
Errored Seconds      19      5      12      5
Severely Errored Seconds      9      3      11      3
Unavailable Seconds      0      0      0      0
Path Unavailable Seconds      N/A      0      0      0
Background Block Errors      643      12      2189      18
Errored Second Ratio      2.375E-01  6.250E-02  1.558E-01  6.250E-02
Severely Errored Sec Ratio      1.125E-01  3.750E-02  1.429E-01  3.750E-02
Background Block Err Ratio      1.132E-03  1.948E-05  4.146E-03  2.922E-05
=====
```

SDH Logging Messages

Results Logging

| | HP- REI | HP- IEC | TU BIP | LP- REI | |
|----------------------------|--------------|--------------|---------------|---------------|---------|
| Errored Blocks | 5 | 316822 | N/A | N/A | |
| Errored Seconds | 2 | 1 | N/A | N/A | |
| Severely Errored Seconds | 0 | 0 | N/A | N/A | |
| Unavailable Seconds | 0 | 40 | N/A | N/A | |
| Path Unavailable Seconds | 0 | N/A | N/A | N/A | |
| Background Block Errors | 5 | 1426 | N/A | N/A | |
| Errored Second Ratio | 2.597E-02 | 2.703E-02 | N/A | N/A | |
| Severely Errored Sec Ratio | 0 | 0 | N/A | N/A | |
| Background Block Err Ratio | 8.117E-06 | 4.818E-03 | N/A | N/A | |
| G.821 ANALYSIS | | | | | |
| | BIT (test) | FAS 140M | FAS 34M | FAS 8M | FAS 2M |
| Errored Sec | 9 | N/A | N/A | N/A | N/A |
| %Errored Sec | 11.25000 | N/A | N/A | N/A | N/A |
| %ES (Annex D) | 5.00000 | N/A | N/A | N/A | N/A |
| Error Free Sec | 71 | N/A | N/A | N/A | N/A |
| %Error Free Sec | 88.75000 | N/A | N/A | N/A | N/A |
| Severely Err Sec | 9 | N/A | N/A | N/A | N/A |
| %Severely Err Sec | 11.25000 | N/A | N/A | N/A | N/A |
| Degraded Minutes | 0 | N/A | N/A | N/A | N/A |
| %Degraded Minutes | 0.00000 | N/A | N/A | N/A | N/A |
| Unavailable Sec | 0 | N/A | N/A | N/A | N/A |
| %Unavailable Sec | 0.00000 | N/A | N/A | N/A | N/A |
| G.826 ANALYSIS | | | | | |
| | | Near 140Mb/s | Far | Near 34Mb/s | Far |
| Errored Seconds | | 3 | N/A | N/A | N/A |
| Severely Errored Seconds | | 3 | N/A | N/A | N/A |
| Unavailable Seconds | | 0 | N/A | N/A | N/A |
| Errored Second Ratio | | 3.750E-02 | N/A | N/A | N/A |
| Severely Errored Sec Ratio | | 3.750E-02 | N/A | N/A | N/A |
| M.2100 ANALYSIS | | | | | |
| | | Rx 140Mb/s | Tx | Rx 34Mb/s | Tx |
| Errored Seconds | | 9 | N/A | N/A | N/A |
| Severely Errored Seconds | | 9 | N/A | N/A | N/A |
| Unavailable Seconds | | 0 | N/A | N/A | N/A |
| M.2110 ANALYSIS | | | | | |
| BIS Results | | 2-hr WAIT | 24-hr WAIT | 7-day WAIT | |
| Frequency : | 155520000 Hz | Offset : | +0Hz | Offset : | +0.0ppm |
| Pointer Results : | | | | | |
| | | AU POINTER | | TU POINTER | |
| | | Count | Seconds | Count | Seconds |
| NDF | | | 3 | | N/A |
| Missing NDF | | | 2 | | N/A |
| +ve Pointer Adjustments | | 3 | 3 | N/A | N/A |
| -ve Pointer Adjustments | | 1 | 1 | N/A | N/A |
| Implied VC Offset | | -0.0 | | N/A | |
| Pointer Value | | 512 | | N/A | |

Results Snapshot Logging Example

SDH Logging Messages

Results Logging

Overhead Capture Logging

To log the Overhead Capture:

Select the required External logging device under LOGGING PORT on the **OTHER** **LOGGING** display.

Select LOGGING [ON] on the **OTHER** **LOGGING** display.

Select LOG ON DEMAND [O/H CAPTURE] on the **OTHER** **LOGGING** display and press **PRINT NOW**.

```
=====
10:58:17 PRINT DEMANDED- O/H CAPTURE           Elapsed Time  00d 00h 00m 02s
=====
| Setup : STM-1e
| Capture of channel [ 3xA1, 3xA2 ] Trigger OFF
-----
          DATA                FRAME COUNT
F6F6F6282828                64000
F6F6F6282828                64000
F6F6F6282828                40041
B626D6289828                 1002
F6F6F6282828                64000
3636C4F82828                 10
B626D6289828                 1002
F6F6F6282828                64000
=====
```

Overhead Capture Logging Example

SDH Logging Messages

Results Logging

SDH Tributary Scan Logging

To log the SDH Tributary Scan:

Select the required External logging device under LOGGING PORT on the **OTHER** **LOGGING** display.

Select LOGGING [ON] on the **OTHER** **LOGGING** display.

Select LOG ON DEMAND [TRIB SCAN] on the **OTHER** **LOGGING** display and press **PRINT NOW**.

```
=====
11:20:26 PRINT DEMANDED- TRIBUTARY SCAN          Elapsed Time  00d 00h 00m 10s
=====
RECEIVE SIGNAL      : STM-1
MAPPING             : AU-4   TU-12
TEST TIME           : 10 SECS
ERROR THRESHOLD     : > 0
=====
TU-12
TRIBS
-----
TUG-3 #1
-----
TUG-2 #1 | TUG-2 #2 | TUG-2 #3 | TUG-2 #4 | TUG-2 #5 | TUG-2 #6 | TUG-2 #7
-----
#1 PASS | #1 PASS | #1 PASS | #1 PASS | #1 PASS | #1 PASS | #1 PASS
#2 PASS | #2 PASS | #2 PASS | #2 PASS | #2 PASS | #2 PASS | #2 PASS
#3 PASS | #3 PASS | #3 PASS | #3 PASS | #3 PASS | #3 PASS | #3 PASS
-----
TUG-3 #2
-----
TUG-2 #1 | TUG-2 #2 | TUG-2 #3 | TUG-2 #4 | TUG-2 #5 | TUG-2 #6 | TUG-2 #7
-----
#1 PASS | #1 PASS | #1 PASS | #1 PASS | #1 PASS | #1 PASS | #1 PASS
#2 PASS | #2 PASS | #2 PASS | #2 PASS | #2 PASS | #2 PASS | #2 PASS
#3 PASS | #3 PASS | #3 PASS | #3 PASS | #3 PASS | #3 PASS | #3 PASS
-----
TUG-3 #3
-----
TUG-2 #1 | TUG-2 #2 | TUG-2 #3 | TUG-2 #4 | TUG-2 #5 | TUG-2 #6 | TUG-2 #7
-----
#1 PASS | #1 PASS | #1 PASS | #1 PASS | #1 PASS | #1 PASS | #1 PASS
#2 PASS | #2 PASS | #2 PASS | #2 PASS | #2 PASS | #2 PASS | #2 PASS
#3 PASS | #3 PASS | #3 PASS | #3 PASS | #3 PASS | #3 PASS | #3 PASS
=====
```

SDH Tributary Scan Logging Example

SDH Logging Messages

Results Logging

Pointer Graph Logging

To log the Pointer Graph:

Select the required External logging device under LOGGING PORT on the **OTHER** **LOGGING** display.

Select LOGGING [ON] on the **OTHER** **LOGGING** display.

Select LOG ON DEMAND [PTR GRAPH] on the **OTHER** **LOGGING** display and press **PRINT NOW**.

```
=====
11:31:16 PRINT DEMANDED- POINTER GRAPH           Elapsed Time 00d 00h 01m 22s
=====
CAPTURE INTERVAL      : 1 Second
POINTER UNDER TEST   : AU-4
=====
```

| Period | MAX | MIN | Period | MAX | MIN | Period | MAX | MIN | Period | MAX | MIN |
|--------|-----|-----|--------|-----|-----|--------|-----|-----|--------|-----|-----|
| 1 | 0 | -18 | 73 | UR | UR | 145 | NR | NR | 217 | NR | NR |
| 2 | UR | UR | 74 | UR | UR | 146 | NR | NR | 218 | NR | NR |
| 3 | UR | UR | 75 | UR | UR | 147 | NR | NR | 219 | NR | NR |
| 4 | UR | UR | 76 | UR | UR | 148 | NR | NR | 220 | NR | NR |
| 5 | UR | UR | 77 | UR | UR | 149 | NR | NR | 221 | NR | NR |
| 6 | UR | UR | 78 | UR | UR | 150 | NR | NR | 222 | NR | NR |
| 7 | UR | UR | 79 | UR | UR | 151 | NR | NR | 223 | NR | NR |
| 8 | UR | UR | 80 | UR | UR | 152 | NR | NR | 224 | NR | NR |
| 9 | UR | UR | 81 | UR | UR | 153 | NR | NR | 225 | NR | NR |
| 10 | UR | UR | 82 | UR | UR | 154 | NR | NR | 226 | NR | NR |
| 11 | UR | UR | 83 | NR | NR | 155 | NR | NR | 227 | NR | NR |
| 12 | UR | UR | 84 | NR | NR | 156 | NR | NR | 228 | NR | NR |
| 13 | UR | UR | 85 | NR | NR | 157 | NR | NR | 229 | NR | NR |
| 14 | UR | UR | 86 | NR | NR | 158 | NR | NR | 230 | NR | NR |
| 15 | UR | UR | 87 | NR | NR | 159 | NR | NR | 231 | NR | NR |
| 16 | UR | UR | 88 | NR | NR | 160 | NR | NR | 232 | NR | NR |
| 17 | UR | UR | 89 | NR | NR | 161 | NR | NR | 233 | NR | NR |
| 18 | UR | UR | 90 | NR | NR | 162 | NR | NR | 234 | NR | NR |
| 19 | UR | UR | 91 | NR | NR | 163 | NR | NR | 235 | NR | NR |
| 20 | UR | UR | 92 | NR | NR | 164 | NR | NR | 236 | NR | NR |
| 21 | UR | UR | 93 | NR | NR | 165 | NR | NR | 237 | NR | NR |
| 22 | UR | UR | 94 | NR | NR | 166 | NR | NR | 238 | NR | NR |
| 23 | UR | UR | 95 | NR | NR | 167 | NR | NR | 239 | NR | NR |
| 24 | UR | UR | 96 | NR | NR | 168 | NR | NR | 240 | NR | NR |
| 25 | UR | UR | 97 | NR | NR | 169 | NR | NR | 241 | NR | NR |
| 26 | UR | UR | 98 | NR | NR | 170 | NR | NR | 242 | NR | NR |
| 27 | UR | UR | 99 | NR | NR | 171 | NR | NR | 243 | NR | NR |
| 28 | UR | UR | 100 | NR | NR | 172 | NR | NR | 244 | NR | NR |
| 29 | UR | UR | 101 | NR | NR | 173 | NR | NR | 245 | NR | NR |
| 30 | UR | UR | 102 | NR | NR | 174 | NR | NR | 246 | NR | NR |
| 31 | UR | UR | 103 | NR | NR | 175 | NR | NR | 247 | NR | NR |
| 32 | UR | UR | 104 | NR | NR | 176 | NR | NR | 248 | NR | NR |
| 33 | UR | UR | 105 | NR | NR | 177 | NR | NR | 249 | NR | NR |
| 34 | UR | UR | 106 | NR | NR | 178 | NR | NR | 250 | NR | NR |
| 35 | UR | UR | 107 | NR | NR | 179 | NR | NR | 251 | NR | NR |
| 36 | UR | UR | 108 | NR | NR | 180 | NR | NR | 252 | NR | NR |
| 37 | UR | UR | 109 | NR | NR | 181 | NR | NR | 253 | NR | NR |
| 38 | UR | UR | 110 | NR | NR | 182 | NR | NR | 254 | NR | NR |
| 39 | UR | UR | 111 | NR | NR | 183 | NR | NR | 255 | NR | NR |

SDH Logging Messages

Results Logging

| | | | | | | | | | | | |
|----|----|----|-----|----|----|-----|----|----|-----|----|----|
| 40 | UR | UR | 112 | NR | NR | 184 | NR | NR | 256 | NR | NR |
| 41 | UR | UR | 113 | NR | NR | 185 | NR | NR | 257 | NR | NR |
| 42 | UR | UR | 114 | NR | NR | 186 | NR | NR | 258 | NR | NR |
| 43 | UR | UR | 115 | NR | NR | 187 | NR | NR | 259 | NR | NR |
| 44 | UR | UR | 116 | NR | NR | 188 | NR | NR | 260 | NR | NR |
| 45 | UR | UR | 117 | NR | NR | 189 | NR | NR | 261 | NR | NR |
| 46 | UR | UR | 118 | NR | NR | 190 | NR | NR | 262 | NR | NR |
| 47 | UR | UR | 119 | NR | NR | 191 | NR | NR | 263 | NR | NR |
| 48 | UR | UR | 120 | NR | NR | 192 | NR | NR | 264 | NR | NR |
| 49 | UR | UR | 121 | NR | NR | 193 | NR | NR | 265 | NR | NR |
| 50 | UR | UR | 122 | NR | NR | 194 | NR | NR | 266 | NR | NR |
| 51 | UR | UR | 123 | NR | NR | 195 | NR | NR | 267 | NR | NR |
| 52 | UR | UR | 124 | NR | NR | 196 | NR | NR | 268 | NR | NR |
| 53 | UR | UR | 125 | NR | NR | 197 | NR | NR | 269 | NR | NR |
| 54 | UR | UR | 126 | NR | NR | 198 | NR | NR | 270 | NR | NR |
| 55 | UR | UR | 127 | NR | NR | 199 | NR | NR | 271 | NR | NR |
| 56 | UR | UR | 128 | NR | NR | 200 | NR | NR | 272 | NR | NR |
| 57 | UR | UR | 129 | NR | NR | 201 | NR | NR | 273 | NR | NR |
| 58 | UR | UR | 130 | NR | NR | 202 | NR | NR | 274 | NR | NR |
| 59 | UR | UR | 131 | NR | NR | 203 | NR | NR | 275 | NR | NR |
| 60 | UR | UR | 132 | NR | NR | 204 | NR | NR | 276 | NR | NR |
| 61 | UR | UR | 133 | NR | NR | 205 | NR | NR | 277 | NR | NR |
| 62 | UR | UR | 134 | NR | NR | 206 | NR | NR | 278 | NR | NR |
| 63 | UR | UR | 135 | NR | NR | 207 | NR | NR | 279 | NR | NR |
| 64 | UR | UR | 136 | NR | NR | 208 | NR | NR | 280 | NR | NR |
| 65 | UR | UR | 137 | NR | NR | 209 | NR | NR | 281 | NR | NR |
| 66 | UR | UR | 138 | NR | NR | 210 | NR | NR | 282 | NR | NR |
| 67 | UR | UR | 139 | NR | NR | 211 | NR | NR | 283 | NR | NR |
| 68 | UR | UR | 140 | NR | NR | 212 | NR | NR | 284 | NR | NR |
| 69 | UR | UR | 141 | NR | NR | 213 | NR | NR | 285 | NR | NR |
| 70 | UR | UR | 142 | NR | NR | 214 | NR | NR | 286 | NR | NR |
| 71 | UR | UR | 143 | NR | NR | 215 | NR | NR | 287 | NR | NR |
| 72 | UR | UR | 144 | NR | NR | 216 | NR | NR | 288 | NR | NR |

Pointer Graph Logging Example

SDH Logging Messages

Results Logging

SDH Self Test Error Codes

SDH Self Test Error Codes

When self test is run fail numbers may be displayed. The fail numbers and a description are listed below.

Table 5-3 Processor Self Test

| No. | Description | No. | Description |
|------|---|------|---|
| 1020 | SRAM Error | 1021 | SRAM Error |
| 1022 | SRAM Error | 1023 | SRAM Error |
| 1024 | SRAM Address Error | 1040 | RS232 DCD |
| 1041 | RS232 R1 | 1042 | RS232 DSR |
| 1043 | RS232 CTS | 1044 | RS232 Rx too many bytes |
| 1045 | RS232 Tx time out | 1046 | RS232 Rx too few bytes |
| 1047 | RS232 Tx/Rx Data t | 1052 | HP-IB Driver Chip |
| 1060 | Real Time Clock Set Incorrectly | 1061 | Real Time Clock Not Ticking correctly |
| 1070 | Parallel Port No Send Data | 1080 | Internal Printer |
| 1081 | Keyboard Processor Internal RAM | 1082 | Keyboard Processor External RAM |
| 1083 | Keyboard Processor ROM | 1084 | Front Panel No Response |
| 1085 | Front Panel Bad Command | 1086 | Front Panel Invalid Error Returned |
| 1087 | Front Panel CPU or UART | 1088 | Cannot Detect Front Panel Printer |
| 1090 | VRAM Data Error | 1100 | No Disk in Drive |
| 1101 | Disk Full | 1102 | Disk Write Fail |
| 1103 | Disk Read Fail | 1104 | Disk Verify Read/Write Fail |
| 1110 | LAN Failed Power-On Test | 1111 | LAN Returned Invalid Error Number |
| 1112 | LAN Hardware Not Found | 1113 | Lan Fitted No Test Result |
| 1120 | Front Panel No Response | 1121 | Front Panel Bad Command |
| 1122 | Front Panel Returned Invalid Error Number | 1123 | Dual Port SRAM Data Error |
| 1124 | Dual Port SRAM Address Error | 1130 | Front Panel No Response |
| 1131 | Front Panel Bad Command | 1132 | Front Panel Returned Invalid Error Number |
| 1133 | Front Panel FEPRAM Sum-check Error | 1140 | Front Panel No Response |
| 1141 | Front Panel Bad Command | 1142 | Front Panel Returned Invalid Error Number |
| 1143 | Front Panel SRAM Data Error | 1144 | Front Panel SRAM Address Error |
| 1145 | Front Panel Address Range Invalid | 1150 | Front Panel No Response |
| 1151 | Front Panel Bad Command | 1152 | Front Panel Returned Invalid Error Number |
| 1153 | Front Panel VRAM Data Error | 1154 | Front Panel Stored Fonts Corrupted |

SDH Self Test Error Codes

Table 5-3 Processor Self Test

| No. | Description | No. | Description |
|------|---|------|---------------------------------------|
| 1155 | Front Panel Address Range Invalid | 1156 | Front Panel VGA Controller Error |
| 1160 | Front Panel No Response | 1161 | Front Panel Bad Command |
| 1162 | Front Panel Returned Invalid Error Number | 1163 | Front Panel UART Tx/Rx Error Internal |
| 1164 | Front Panel Internal Loopback not Reset | 1166 | Front Panel UART Tx/Rx Error External |

Table 5-4 SDH Tests Option A3R (STM-1)

| No. | Description | No. | Description |
|-----|---------------------|-----|-------------------|
| 721 | Sync Loss | 724 | Bit Errors |
| 731 | Monitor, False Sync | 741 | Rx loss of Signal |

Table 5-5 SDH Tests Option A3R (STM-1, Overhead)

| No. | Description | No. | Description |
|------|-------------------------------|------|----------------------------------|
| 7101 | Overhead processor failed | 7102 | Path Overhead fail |
| 7104 | section Overhead fail | 7111 | VC4 J1 fail |
| 7121 | B1 Error Add, Sync Loss | 7123 | B1 Errors, Result Low |
| 7124 | B1 Errors, Result High | 7131 | B2 Error Add, Sync Loss |
| 7133 | B2 Errors, Result Low | 7134 | B2 Errors, Result High |
| 7141 | B3 Error Add, Sync Loss | 7143 | B3 Errors, Result Low |
| 7144 | B3 Errors, Result High | 7151 | MS-REI Error Add, Sync Loss |
| 7153 | MS-REIE Errors, Result Low | 7154 | RS-REI Errors, Result High |
| 7161 | PIEC Error Add, Sync Loss | 7163 | PIEC Errors, Result Low |
| 7164 | PIEC Errors, Result High | | |
| 7171 | Error Add Off - Loss of Frame | 7172 | Error Add 1 in 4 - Loss of Frame |

SDH Self Test Error Codes

Table 5-5 SDH Tests Option A3R (STM-1, Overhead)

| No. | Description | No. | Description |
|------|----------------------------------|------|----------------------------------|
| 7173 | Error Add 2 in 4 - Loss of Frame | 7174 | Error Add 3 in 4 - Loss of Frame |
| 7175 | Error Add 4 in 4 - Frame Sync | 7176 | Error Add 3 in 4 - Frame Sync |
| 7177 | Error Add 2 in 4 - Loss of Frame | 7178 | Error Add 1 in 4 - Loss of Frame |
| 7179 | Error Add Off - Loss of Frame | | |

Table 5-6 SDH Tests Option A3R (140 Mb/s Payload)

| No. | Description | No. | Description |
|------|--|------|--|
| 7181 | Bit Errors - Sync Loss | 7183 | Bit Errors - Result Low |
| 7184 | Bit Errors - Result High | 7191 | Error Add 1E3, Offset +100 ppm - Sync Loss |
| 7193 | Error Add 1E3, Offset +100 ppm - Result Low | 7194 | Error Add 1E3, Offset +100 ppm - Result High |
| 7201 | Error Add 1E3, Offset -100 ppm - Sync Loss | 7203 | Error Add 1E3, Offset -100 ppm - Result Low |
| 7204 | Error Add 1E3, Offset -100 ppm - Result High | | |

Table 5-7 SDH Tests Option A3R (TU3 Payload)

| No. | Description | No. | Description |
|------|---|------|---|
| 7211 | VC3 J1 Fail | 7221 | VC3 B3 Single Error - Sync Loss |
| 7223 | VC3 B3 Single Error - Result Low | 7224 | VC3 B3 Single Error - Result High |
| 7231 | VC3 REI Single Error - Sync Loss | 7233 | VC3 REI Single Error - Result Low |
| 7234 | VC3 REI Single Error - Result High | 7241 | Payload Bit Single Error - Sync Loss |
| 7243 | Payload Bit Single Error - Result Low | 7244 | Payload Bit Single Error - Result High |
| 7251 | Background Pattern - RX False Sync | 7261 | Background Pattern - TUG 1 Pattern Loss |
| 7262 | Background Pattern - TUG 3 Pattern Loss | | |

SDH Self Test Error Codes

Table 5-8 SDH Tests Option A3R (TU12 Payload Overhead)

| No. | Description | No. | Description |
|------|--|------|---|
| 7271 | Async - A1,A2 Sync Loss | 7284 | Async - B1 Errors |
| 7294 | Async - B2 errors | 7304 | Async - B3 Errors |
| 7314 | Async - REI Errors | 7324 | Async - V5 BIP2 Errors |
| 7334 | Async - V5 REI Errors | 7341 | Floating Byte - A1,A2 Sync Loss |
| 7354 | Floating Byte - B1 Errors | 7364 | Floating Byte - B2 Errors |
| 7374 | Floating Byte - B3 Errors | 7384 | Floating Byte - REI Errors |
| 7394 | Floating Byte - V5 BIP2 Errors | 7404 | Floating Byte - V5 BIP2 Errors |
| 7411 | Async V5 BIP2 Add - Sync Loss | 7413 | Async V5 BIP2 Add - Result Low |
| 7414 | Async V5 BIP2 Add - Result High | 7421 | Async V5 REI Add - Sync Loss |
| 7423 | Async V5 REI Add - Result Low | 7424 | Async V5 REI Add - Result High |
| 7431 | Async Payload Bit Add - Sync Loss | 7433 | Async Payload Bit Add - Result Low |
| 7434 | Async Payload Bit Add - Result High | 7441 | Floating Byte Payload Bit Add - Sync Loss |
| 7433 | Floating Byte Payload Bit Add - Result Low | 7434 | Floating Byte Payload Bit Add - Result High |

Table 5-9 SDH Tests Option A3R (Payload Pattern)

| No. | Description | No. | Description |
|------|--|------|--|
| 7451 | 140 Mb/s, PRBS23 - Sync Loss | 7453 | 140 Mb/s, PRBS23 - Result Low |
| 7454 | 140 Mb/s, PRBS23 - Result High | 7461 | TU3, PRBS15 - Sync Loss |
| 7463 | TU3, PRBS15 - Result Low | 7464 | TU3, PRBS15 - Result High |
| 7471 | TU12, WORD - Sync Loss | 7473 | TU12, WORD - Result Low |
| 7474 | TU12, WORD - Result High | 7481 | TU2, PRBS9 - Sync Loss |
| 7483 | TU2, PRBS9 - Result Low | 7484 | TU2, PRBS9 - Result High |
| 7491 | Background PRBS9 - False Pattern Sync TUG1 | 7501 | Background PRBS9 - False Pattern Sync TUG2 |

SDH Self Test Error Codes

Table 5-10 SDH Tests Option A3R (TU12 Payload Bit Error Add)

| No. | Description | No. | Description |
|------|-------------|------|-------------|
| 7511 | Sync Loss | 7513 | Result Low |
| 7514 | Result High | | |

Table 5-11 SDH Tests Option A3R (Freq Offset/Pointer Movements)

| No. | Description | No. | Description |
|------|---|------|--|
| 7521 | 140 Mb/s, A1,A2 - Sync Loss | 7531 | 140 Mb/s, H1,H2 - Loss of Pointer |
| 7544 | 140 Mb/s, B1 - Errors | 7554 | 140 Mb/s, B2 - Errors |
| 7564 | 140 Mb/s, B3 - Errors | 7573 | 140 Mb/s, +100 ppm - Implied VC Offset Low |
| 7574 | 140 Mb/s, +100 ppm - Implied VC Offset High | 7583 | 140 Mb/s, -100 ppm - Implied VC Offset Low |
| 7584 | 140 Mb/s, -100 ppm - Implied VC Offset High | 7591 | TU3, A1,A2 - Sync Loss |
| 7601 | TU3, H1,H2 - Loss of Pointer | 7614 | TU3, B1 - Errors |
| 7624 | TU3, B2 - Errors | 7634 | TU3, B3 - Errors |
| 7644 | TU3, TU BIP - Errors | 7653 | TU3, +100 ppm - Implied VC Offset Low |
| 7654 | TU3, +100 ppm - Implied VC Offset High | 7663 | TU3, -100 ppm - Implied VC Offset Low |
| 7664 | TU3, -100 ppm - Implied VC Offset High | 7671 | TU12, A1,A2 - Sync Loss |
| 7681 | TU12, H1,H2 - Loss of Pointer | 7694 | TU12, B1 - Errors |
| 7704 | TU12, B2 - Errors | 7714 | TU12, B3 - Errors |
| 7724 | TU12, TU BIP - Errors | 7733 | TU12, +100 ppm - Implied VC Offset Low |
| 7734 | TU12, +100 ppm - Implied VC Offset High | 7743 | TU12, -100 ppm - Implied VC Offset Low |
| 7744 | TU12, -100 ppm - Implied VC Offset High | | |

Table 5-12 SDH Tests Option A3R (Thru Mode and DCC)

| No. | Description | No. | Description |
|-----|-------------|-----|-------------|
|-----|-------------|-----|-------------|

SDH Self Test Error Codes

Table 5-12 SDH Tests Option A3R (Thru Mode and DCC)

| | | | |
|------|--------------------------------|------|----------------------|
| 7751 | Thru Mode - H4 Frame Sync Loss | 7761 | RS DCC Loopback Fail |
| 7771 | MS DCC Loopback Fail | | |

Table 5-13 SDH Tests Option A3R (Bulk Filled Payload Pattern)

| No. | Description | No. | Description |
|------|-------------------------|------|------------------------|
| 7781 | AU-4 Bulk - False Sync | 7782 | AU-4 Bulk - Sync Loss |
| 7791 | TU-3 Bulk - False Sync | 7792 | TU-3 Bulk - Sync Loss |
| 7801 | TU-12 Bulk - False Sync | 7802 | TU-12 Bulk - Sync Loss |

Table 5-14 SDH Tests Option A3R (DS3/DS1 Framing)

| No. | Description | No. | Description |
|------|---------------------------|------|--------------------------|
| 7811 | DS3 Unframed - False Sync | 7812 | DS3 Unframed - Sync Loss |
| 7821 | DS3 M23 - False Sync | 7822 | DS3 M23 - Sync Loss |
| 7831 | DS3 C-Bit - False Sync | 7832 | DS3 C-Bit - Sync Loss |
| 7841 | DS1 Unframed - False Sync | 7842 | DS1 Unframed - Sync Loss |
| 7851 | DS1 D4 - False Sync | 7852 | DS1 D4 - Sync Loss |
| 7861 | DS1 ESF - False Sync | 7862 | DS1 ESF - Sync Loss |
| 7871 | DS1 SLC-96 - False Sync | 7872 | DS1 SLC-96 - Sync Loss |

Table 5-15 SDH Tests Option A3R (STM-1 J0 Message)

| No. | Description | No. | Description |
|------|-------------|-----|-------------|
| 7881 | No Errors | | |

SDH Self Test Error Codes

Table 5-16 SDH Tests Option A3R (Payload Patterns)

| No. | Description | No. | Description |
|------|----------------------------------|------|-----------------------------------|
| 7891 | C-4 Bulk, PRBS11 - Sync Loss | 7893 | C-4 Bulk, PRBS11 - Result Low |
| 7894 | C-4 Bulk, PRBS11 - Result High | 7901 | C-3 Bulk, PRBS9 - Sync Loss |
| 7903 | C-3 Bulk, PRBS9 - Result Low | 7904 | C-3 Bulk, PRBS9 - Result High |
| 7911 | C-12 Bulk, Word - Sync Loss | 7913 | C-12 Bulk, Word - Result Low |
| 7914 | C-12 Bulk, Word - Result High | 7921 | DS3 Unframed PRBS20 - Sync Loss |
| 7923 | DS3 Unframed PRBS20 - Result Low | 7924 | DS3 Unframed PRBS20 - Result High |
| 7931 | DS1 Unframed QRSS - Sync Loss | 7933 | DS1 Unframed QRSS - Result Low |
| 7934 | DS1 Unframed QRSS - Result High | | |

Table 5-17 SDH Tests Option A3R (Mixed Payloads)

| No. | Description | No. | Description |
|------|---------------------------------------|------|--|
| 7945 | TUG3 No 2,TU-3 Mapping - TU AIS Alarm | 7946 | TUG3 No 2,TU-3 Mapping - LP-RDIF Alarm |
| 7947 | TUG3 No 2,TU-3 Mapping - TU LOP Alarm | 7951 | TUG3 No 1,TU-3 Mapping - Sync Loss |
| 7961 | TUG3 No 3,TU-3 Mapping - Sync Loss | 7975 | TUG3 No 1,TU-12Mapping - TU AIS Alarm |
| 7976 | TUG3 No 1,TU-12Mapping - LP-RDI Alarm | 7977 | TUG3 No 1,TU-12Mapping - TU LOP Alarm |
| 7981 | TUG3 No 2, TU-12 Mapping - Sync Loss | 7991 | TUG3 No 3,TU-12Mapping - Sync Loss |

Table 5-18 SDH Tests Option A3R (TU-12 Background Pattern)

| No. | Description | No. | Description |
|-------|------------------------------------|-------|------------------------------|
| 22001 | Unframed, PRBS9 - F/G Pattern Loss | 22002 | D4, PRBS9 - B/G Pattern Loss |
| 22011 | ESF, PRBS15 - F/G Pattern Loss | 22012 | D4, PRBS15- B/G Pattern Loss |

SDH Self Test Error Codes

Table 5-19 SDH Tests Option A3R (Service Disruption Test)

| No. | Description | No. | Description |
|-------|----------------------|-------|----------------------|
| 22021 | Sync Loss | 22025 | Shortest Burst Error |
| 22026 | Longest Burst Error | 22027 | Last Burst Error |
| 22035 | Shortest Burst Error | 22036 | Longest Burst Error |
| 22037 | Last Burst Error | 22045 | Shortest Burst Error |
| 22046 | Longest Burst Error | 22047 | Last Burst Error |

Table 5-20 SDH Tests Option A3R (STM-0)

| No. | Description | No. | Description |
|-------|---|-------|---|
| 22051 | STM-0 Loopback - Signal Present | 22061 | STM-0 Loopback - Sync Loss |
| 22064 | STM-0 Loopback - Result High | 22071 | STM-0 Loopback - False Signal Present |
| 22081 | Pulse Shape HI - Sync Loss | 22084 | Pulse Shape HI - Result High |
| 22091 | Pulse Shape LO - Sync Loss | 22094 | Pulse Shape LO - Result High |
| 22101 | Pulse Shape XCONNECT - Sync Loss | 22104 | Pulse Shape XCONNECT - Result High |
| 22111 | Frequency Measurement - Signal Loss | 22113 | Frequency Measurement - Sync Loss |
| 22114 | Frequency Measurement - Result High | 22121 | C-3 Bulk Framing - False Sync |
| 22122 | C-3 Bulk Framing - Sync Loss | 22131 | TU-2 Bulk Framing - False Sync |
| 22132 | TU-12 Bulk Framing - Sync Loss | 22141 | DS1 Unframed - False Sync |
| 22142 | DS1 Unframed - Sync Loss | 22151 | B1 Error Add - Sync Loss |
| 22153 | B1 Error Add - Result Low | 22154 | B1 Error Add - Result High |
| 22161 | B2 Error Add - Sync Loss | 22163 | B2 Error Add - Result Low |
| 22164 | B2 Error Add - Result High | 22171 | B3 Error Add - Sync Loss |
| 22173 | B3 Error Add - Result Low | 22174 | B3 Error Add - Result High |
| 22181 | MS-REI Error Add - Sync Loss | 22183 | MS-REI Error Add - Result Low |
| 22184 | MS -REI Error Add - Result High | 22191 | IEC Error Add - Sync Loss |
| 22193 | IEC Error Add - Result Low | 22194 | IEC Error Add - Result High |
| 22201 | 34 Mb/s Mapping, Offset +100ppm - Sync Loss | 22203 | 34 Mb/s Mapping, Offset +100ppm - Result Low |
| 22204 | 34 Mb/s Mapping, Offset +100ppm - Result High | 22211 | 34 Mb/s Mapping, Offset -100ppm - Sync Loss |
| 22213 | 34 Mb/s Mapping, Offset -100ppm - Result Low | 22214 | 34 Mb/s Mapping, Offset -100ppm - Result High |
| 22221 | DS3 Mapping, Offset +100ppm - Sync Loss | 22223 | DS3 Mapping, Offset +100ppm - Result Low |

SDH Self Test Error Codes

Table 5-20 SDH Tests Option A3R (STM-0)

| No. | Description | No. | Description |
|-------|---|-------|---|
| 22224 | DS3 Mapping, Offset +100ppm - Result High | 22231 | DS3 Mapping, Offset -100ppm - Sync Loss |
| 22233 | DS3 Mapping, Offset -100ppm- Result Low | 22234 | DS3 Mapping, Offset +100ppm - Result High |
| 22241 | THRU Mode Fail | | |

Table 5-21 SDH Tests (Round Trip Delay)

| | | | |
|------|--|------|---|
| 8911 | STM-1, 140 Mb/s, 1 μ s- Pattern Loss | 8913 | STM-1, 140 Mb/s, 1 μ s - Result Low |
| 8914 | STM-1, 140 Mb/s, 1 μ s - Result High | 8921 | STM-1, 140 Mb/s, 2s - Pattern Loss |
| 8923 | STM-1, 140 Mb/s, 2s - Result Low | 8924 | STM-1, 140 Mb/s, 2s - Result High |
| 8931 | STM-1, 34 Mb/s, 1 μ s - Pattern Loss | 8933 | STM-1, 34 Mb/s, 1 μ s - Result Low |
| 8934 | STM-1, 34 Mb/s, 1 μ s - Result High | 8941 | STM-1, 34 Mb/s, 2s - Pattern Loss |
| 8943 | STM-1, 34 Mb/s, 2s - Result Low | 8944 | STM-1, 34 Mb/s, 2s - Result High |
| 8951 | STM-1, 2 Mb/s, 1 μ s - Pattern Loss | 8953 | STM-1, 2 Mb/s, 1 μ s - Result Low |
| 8954 | STM-1, 2 Mb/s, 1 μ s - Result High | 8961 | STM-1, 2 Mb/s, 2s - Pattern Loss |
| 8963 | STM-1, 2 Mb/s, 2s - Result Low | 8964 | STM-1, 2 Mb/s, 2s - Result High |

Table 5-22 Error Add Tests Options 130, 131

| No. | Description | No. | Description |
|-------|--|-------|---|
| 10011 | 1310 nm STM-1 Pattern Sync Loss | 10012 | 1310 nm STM-1 Signal Loss |
| 10015 | 1550 nm STM-1 Pattern Sync Loss | 10016 | 1550 nm STM-1 Signal Loss |
| 10022 | 1310 nm STM-1 - Alarms Present | 10026 | 1550 nm STM-1 - Alarms Present |
| 10031 | 1310 nm STM-1, Error Add - Pattern Sync Loss | 10033 | 1310 nm STM-1, Error Add - Bit Error Rate Low |
| 10034 | 1310 nm STM-1, Error Add - Bit Error Rate High | 10035 | 1550 nm STM-1, Error Add - Pattern Sync Loss |

SDH Self Test Error Codes

Table 5-22 Error Add Tests Options 130, 131

| No. | Description | No. | Description |
|-------|---|-------|---|
| 10037 | 1550 nm STM-1, Error Add - Bit Error Rate Low | 10038 | 1550 nm STM-1, Error Add - Bit Error Rate High |
| 10041 | 1310 nm TX OFF - No Alarms | 10042 | 1310 nm TX OFF - No Signal Loss |
| 10045 | 1550 nm TX OFF - No Alarms | 10046 | 1550 nm TX OFF - No Signal Loss |
| 10051 | 1310 nm STM-1 - Failed Frame Sync | 10055 | 1550 nm STM-1 - Failed Frame Sync |
| 10061 | 1310 nm STM-1 - Frame Alarm (LOF or OOF) | 10065 | 1550 nm STM-1 - Frame Alarm (LOF or OOF) |
| 10071 | 1310 nm STM-1 #1 - Alarms Present | 10072 | 1310 nm STM-1 #1 - Signal Loss |
| 10075 | 1550 nm STM-1 #1 - Alarms Present | 10076 | 1550 nm STM-1 #1 - Signal Loss |
| 10081 | 1310 nm STM-1 #1, Error Add - Pattern Sync Loss | 10083 | 1310 nm STM-1 #1, Error Add - Bit Error Rate Low |
| 10084 | 1310 nm STM-1 #1, Error Add - Bit Error Rate High | 10085 | 1550 nm STM-1 #1, Error Add - Pattern Sync Loss |
| 10087 | 1550 nm STM-1 #1, Error Add - Bit Error Rate Low | 10088 | 1550 nm STM-1 #1, Error Add - Bit Error Rate High |
| 10091 | 1310 nm STM-1 #1 - TX OFF - No Alarms | 10092 | 1310 nm STM-1 #1 - TX OFF - No Signal Loss |
| 10095 | 1550 nm STM-1 #1 - TX OFF - No Alarms | 10096 | 1550 nm STM-1 #1 - TX OFF - No Signal Loss |
| 10101 | 1310 nm STM-1 #2 - Alarms Present | 10102 | 1310 nm STM-1 #2 - Signal Loss |
| 10111 | 1310 nm STM-1 #2, Error Add - Pattern Sync Loss | 10113 | 1310 nm STM-1 #2, Error Add - Bit Error Rate Low |
| 10114 | 1310 nm STM-1 #2, Error Add - Bit Error Rate High | 10121 | 1310 nm STM-1 #2 - TX OFF - No Alarms |
| 10122 | 1310 nm STM-1 #2 - TX OFF - No Signal Loss | 10131 | 1310 nm STM-1 #3 - Alarms Present |
| 10132 | 1310 nm STM-1 #3 - Signal Loss | 10141 | 1310 nm STM-1 #3, Error Add - Pattern Sync Loss |
| 10143 | 1310 nm STM-1 #3, Error Add - Bit Error Rate Low | 10144 | 1310 nm STM-1 #3, Error Add - Bit ErrorRate High |
| 10151 | 1310 nm STM-1 #3 - TX OFF - No Alarms | 10152 | 1310 nm STM-1 #3 - TX OFF - No Signal Loss |
| 10161 | 1310 nm STM-1 #4 - Alarms Present | 10162 | 1310 nm STM-1 #4 - Signal Loss |
| 10171 | 1310 nm STM-1 #4, Error Add - Pattern Sync Loss | 10173 | 1310 nm STM-1 #4, Error Add - Bit Error Rate Low |
| 10174 | 1310 nm STM-1 #4, Error Add - Bit Error Rate High | 10181 | 1310 nm STM-1 #4 - TX OFF - No Alarms |
| 10182 | 1310 nm STM-1 #4 - TX OFF - No Signal Loss | 10191 | 1310 nm STM-4 - Failed Frame Sync |
| 10192 | 1310 nm STM-4 - B1 Errors | 10195 | 1550 nm STM-4 - Failed Frame Sync |
| 10196 | 1550 nm STM-4 - B1 Errors | 10202 | 1310 nm STM-4 - B2 Errors |

SDH Self Test Error Codes

Table 5-22 Error Add Tests Options 130, 131

| No. | Description | No. | Description |
|-------|--|-------|--|
| 10206 | 1550 nm STM-4 - B2 Errors | 10211 | 1310 nm STM-4, B2 Error Add - Frame Alarm (OOF or LOF) |
| 10213 | 1310 nm STM-4, B2 Error Add - Bit Error Rate Low | 10214 | 1310 nm STM-4, B2 Error Add - Bit ErrorRate High |

Table 5-23 Clock Recovery Tests Options 130, 131

| No. | Description | No. | Description |
|-------|--------------------------------------|-------|--------------------------------------|
| 10221 | STM-4, STM-1 #1 LOF, OOF or LOP | 10222 | STM-4, STM-1 #1 Signal Loss |
| 10225 | STM-4, STM-1 #1 LOF, OOF or LOP | 10226 | STM-4, STM-1 #1 Signal Loss |
| 10231 | STM-4 Clock Recovery LOF, OOF or LOP | 10235 | STM-4 Clock Recovery LOF, OOF or LOP |
| 10241 | STM-4 Clock Recovery LOF, OOF or LOP | 10245 | STM-4 Clock Recovery LOF, OOF or LOP |
| 10251 | STM-4 Clock Recovery LOF, OOF or LOP | 10255 | STM-4 Clock Recovery LOF, OOF or LOP |

Table 5-24 Overhead Tests Options 130, 131

| No. | Description | No. | Description |
|-------|--|-------|--|
| 10261 | STM-4 Overhead Pattern 1 - Fail to Sync | 10262 | STM-4 Overhead Pattern 1 - Pattern Error |
| 10271 | STM-4 Overhead Pattern 1 - Fail to Sync | 10272 | STM-4 Overhead Pattern 1 - Pattern Error |
| 10281 | STM-1 Overhead Pattern 1, Columns 1,4,7 - Fail to Sync | 10282 | STM-1 Overhead Pattern 1, Columns1,4,7 - Pattern Error |
| 10291 | STM-1 Overhead Pattern 1, Columns 2,5,8 - Fail to Sync | 10292 | STM-1 Overhead Pattern 1, Columns2,5,8 - Pattern Error |
| 10301 | STM-1 Overhead Pattern 1, Columns 3,6,9 - Fail to Sync | 10302 | STM-1 Overhead Pattern 1, Columns3,6,9 - Pattern Error |
| 10311 | STM-1 Overhead Pattern 2, Columns 1,4,7 - Fail to Sync | 10312 | STM-1 Overhead Pattern 2, Columns1,4,7 - Pattern Error |
| 10321 | STM-1 Overhead Pattern 2, Columns 2,5,8 - Fail to Sync | 10322 | STM-1 Overhead Pattern 2, Columns2,5,8 - Pattern Error |

SDH Self Test Error Codes

Table 5-24 Overhead Tests Options 130, 131

| No. | Description | No. | Description |
|-------|---|-------|--|
| 10331 | STM-1 Overhead Pattern 2, Columns 3,6,9 - Fail to Sync | 10332 | STM-1 Overhead Pattern 2, Columns 3,6,9 - Pattern Error |
| 10341 | STM-1 #1 Overhead Pattern 1, Columns 1,4,7 - Fail to Sync | 10342 | STM-1 #1 Overhead Pattern 1, Columns 1,4,7 - Pattern Error |
| 10351 | STM-1 #1 Overhead Pattern 1, Columns 2,5,8 - Fail to Sync | 10352 | STM-1 #1 Overhead Pattern 1, Columns 2,5,8 - Pattern Error |
| 10361 | STM-1 #1 Overhead Pattern 1, Columns 3,6,9 - Fail to Sync | 10362 | STM-1 #1 Overhead Pattern 1, Columns 3,6,9 - Pattern Error |
| 10371 | STM-1 #2 Overhead Pattern 1, Columns 1,4,7 - Fail to Sync | 10372 | STM-1 #2 Overhead Pattern 1, Columns 1,4,7 - Pattern Error |
| 10381 | STM-1 #2 Overhead Pattern 1, Columns 2,5,8 - Fail to Sync | 10382 | STM-1 #2 Overhead Pattern 1, Columns 2,5,8 - Pattern Error |
| 10391 | STM-1 #2 Overhead Pattern 1, Columns 3,6,9 - Fail to Sync | 10392 | STM-1 #2 Overhead Pattern 1, Columns 3,6,9 - Pattern Error |
| 10401 | STM-1 #3 Overhead Pattern 1, Columns 1,4,7 - Fail to Sync | 10402 | STM-1 #3 Overhead Pattern 1, Columns 1,4,7 - Pattern Error |
| 10411 | STM-1 #3 Overhead Pattern 1, Columns 2,5,8 - Fail to Sync | 10412 | STM-1 #3 Overhead Pattern 1, Columns 2,5,8 - Pattern Error |
| 10421 | STM-1 #3 Overhead Pattern 1, Columns 3,6,9 - Fail to Sync | 10422 | STM-1 #3 Overhead Pattern 1, Columns 3,6,9 - Pattern Error |
| 10431 | STM-1 #4 Overhead Pattern 1, Columns 1,4,7 - Fail to Sync | 10432 | STM-1 #4 Overhead Pattern 1, Columns 1,4,7 - Pattern Error |
| 10441 | STM-1 #4 Overhead Pattern 1, Columns 2,5,8 - Fail to Sync | 10442 | STM-1 #4 Overhead Pattern 1, Columns 2,5,8 - Pattern Error |
| 10451 | STM-1 #4 Overhead Pattern 1, Columns 3,6,9 - Fail to Sync | 10452 | STM-1 #4 Overhead Pattern 1, Columns 3,6,9 - Pattern Error |
| 10461 | STM-1 #1 Overhead Pattern 2, Columns 1,4,7 - Fail to Sync | 10462 | STM-1 #1 Overhead Pattern 2, Columns 1,4,7 - Pattern Error |
| 10471 | STM-1 #1 Overhead Pattern 2, Columns 2,5,8 - Fail to Sync | 10472 | STM-1 #1 Overhead Pattern 2, Columns 2,5,8 - Pattern Error |
| 10481 | STM-1 #1 Overhead Pattern 2, Columns 3,6,9 - Fail to Sync | 10482 | STM-1 #1 Overhead Pattern 2, Columns 3,6,9 - Pattern Error |
| 10491 | STM-1 #2 Overhead Pattern 2, Columns 1,4,7 - Fail to Sync | 10492 | STM-1 #2 Overhead Pattern 2, Columns 1,4,7 - Pattern Error |

SDH Self Test Error Codes

Table 5-24 Overhead Tests Options 130, 131

| No. | Description | No. | Description |
|-------|---|-------|---|
| 10501 | STM-1 #2 Overhead Pattern 2, Columns 2,5,8 - Fail to Sync | 10502 | STM-1 #2 Overhead Pattern 2,Columns 2,5,8 - Pattern Error |
| 10511 | STM-1 #2 Overhead Pattern 2, Columns 3,6,9 - Fail to Sync | 10512 | STM-1 #2 Overhead Pattern 2,Columns 3,6,9 - Pattern Error |
| 10521 | STM-1 #3 Overhead Pattern 2, Columns 1,4,7 - Fail to Sync | 10522 | STM-1 #3 Overhead Pattern 2,Columns 1,4,7 - Pattern Error |
| 10531 | STM-1 #3 Overhead Pattern 2, Columns 2,5,8 - Fail to Sync | 10532 | STM-1 #3 Overhead Pattern 2,Columns 2,5,8 - Pattern Error |
| 10541 | STM-1 #3 Overhead Pattern 2, Columns 3,6,9 - Fail to Sync | 10542 | STM-1 #3 Overhead Pattern 2,Columns 3,6,9 - Pattern Error |
| 10551 | STM-1 #4 Overhead Pattern 2, Columns 1,4,7 - Fail to Sync | 10552 | STM-1 #4 Overhead Pattern 2,Columns 1,4,7 - Pattern Error |
| 10561 | STM-1 #4 Overhead Pattern 2, Columns 2,5,8 - Fail to Sync | 10562 | STM-1 #4 Overhead Pattern 2,Columns 2,5,8 - Pattern Error |
| 10571 | STM-1 #4 Overhead Pattern 2, Columns 3,6,9 - Fail to Sync | 10572 | STM-1 #4 Overhead Pattern 2,Columns 3,6,9 - Pattern Error |

Table 5-25 STM-4 Alarms Options 130, 131

| No. | Description | No. | Description |
|-------|--|-------|--|
| 10591 | 1310 nm, No Frame Errors - OOF Alarm Test Fail | 10592 | 1310 nm, No Frame Errors - LOF Alarm Test Fail |
| 10601 | 1310 nm, 3 in 4 Frame Errors - OOF Alarm Test Fail | 10602 | 1310 nm, 3 in 4 Frame Errors - LOF Alarm Test Fail |
| 10611 | 1310 nm, No Alarms - Pattern Sync Loss | 10622 | 1310 nm, MS-AIS Alarm - Alarm Not Detected |
| 10632 | 1310 nm, No Alarms - MS-AIS Alarm | 10641 | 1310 nm, No Alarms - Pattern Sync Loss |
| 10652 | 1310 nm, MS-RDI Alarm - Alarm Not Detected | 10662 | 1310 nm, No Alarms - MS-RDI Alarm |

SDH Self Test Error Codes

Table 5-26 Binary Interface Options 0YH with 130 or 131

| No. | Description | No. | Description |
|-------|---|-------|---|
| 10701 | STM-1 Binary - Signal Loss | 10702 | STM-1 Binary - Pattern Sync Loss |
| 10711 | STM-1 Binary, Error Add - Alarms Detected | 10721 | STM-1 Binary, Error Add - Pattern Sync Loss |
| 10723 | STM-1 Binary, Error Add - Bit Error Rate Low | 10724 | STM-1 Binary, Error Add - Bit Error Rate High |
| 10731 | STM-1 Binary, TX OFF - No Alarms | 10732 | STM-1 Binary, TX OFF - No Signal Loss |
| 10751 | STM-4 Binary, Error Add - No Alarms | 10752 | STM-4 Binary, Error Add - No Signal Loss |
| 10761 | STM-4 Binary, Error Add - Pattern Sync Loss | 10763 | STM-4 Binary, Error Add - Bit Error Rate Low |
| 10764 | STM-4 Binary, Error Add - Bit Error Rate High | 10771 | STM-4 Binary, TX OFF - No Alarms |
| 10772 | STM-4 Binary, TX OFF - No Signal Loss | 10781 | STM-4 Binary - Frame Sync Loss |
| 10782 | STM-4 Binary - B1 Errors | 10792 | STM-4 Binary - B2 Errors |

Table 5-27 Optical Power Measurement Options 130, 131

| No. | Description | No. | Description |
|-------|-----------------------------|-------|-----------------------------|
| 10801 | 1310 nm STM-1 - Alarm Sync | 10803 | 1310 nm STM-1 - Result Low |
| 10804 | 1310 nm STM-1 - Result High | 10805 | 1550 nm STM-1 - Alarm Sync |
| 10807 | 1550 nm STM-1 - Result Low | 10808 | 1550 nm STM-1 - Result High |
| 10811 | 1310 nm STM-4 - Alarm Sync | 10813 | 1310 nm STM-4 - Result Low |
| 10814 | 1310 nm STM-4 - Result High | 10815 | 1550 nm STM-4 - Alarm Sync |
| 10817 | 1550 nm STM-4 - Result Low | 10818 | 1550 nm STM-4 - Result High |

SDH Self Test Error Codes

Table 5-28 Frequency Measurement Options 130, 131

| No. | Description | No. | Description |
|-------|--------------------------------|-------|--------------------------------|
| 10821 | 1310 nm STM-1 - Loss Of Signal | 10823 | 1310 nm STM-1 - Result Low |
| 10824 | 1310 nm STM-1 - Result High | 10825 | 1550 nm STM-1 - Loss Of Signal |
| 10827 | 1550 nm STM-1 - Result Low | 10828 | 1550 nm STM-1 - Result High |
| 10831 | 1310 nm STM-4 - Loss Of Signal | 10833 | 1310 nm STM-4 - Result Low |
| 10834 | 1310 nm STM-4 - Result High | 10835 | 1550 nm STM-4 - Loss Of Signal |
| 10837 | 1550 nm STM-4 - Result Low | 10838 | 1550 nm STM-4 - Result High |

Table 5-29 Error Add Tests Options 130, 131

| No. | Description | No. | Description |
|-------|---|-------|---|
| 10841 | 1310 nm STM-4 B2 - Frame Sync Loss | 10843 | 1310 nm STM-4 - B2 Error Rate Low |
| 10844 | 1310 nm STM-4 - B2 Error Rate High | 10853 | 1310 nm STM-4 - Frame Error Rate Low |
| 10854 | 1310 nm STM-4 - Frame Error Rate High | 10855 | 1310 nm STM-4 - B1 Error Rate Low |
| 10856 | 1310 nm STM-4 - B1 Error Rate High | 10857 | 1310 nm STM-4- MS FEBE//MS REI Error Rate Low |
| 10858 | 1310 nm STM-4 - MS FEBE//MS REI Error Rate High | | |

SDH Self Test Error Codes

Table 5-30 STM-4 Stress Test Options 130, 131

| No. | Description | No. | Description |
|-------|---------------------------|-------|---------------------|
| 10861 | 1310 nm - Frame Sync Loss | 10862 | 1310 nm - OOF Alarm |
| 10865 | 1550 nm - Frame Sync Loss | 10866 | 1550 nm - OOF Alarm |

Table 5-31 Loss of Signal Tests Options 130, 131

| No. | Description | No. | Description |
|-------|-------------------------------------|-------|----------------------------------|
| 10872 | 1310 nm - No Loss of Optical Signal | 10873 | 1310 nm - Loss of Optical Signal |
| 10876 | 1550 nm - No Loss of Optical Signal | 10877 | 1550 nm - Loss of Optical Signal |
| 10882 | 1310 nm - No Loss of Binary Signal | 10883 | 1310 nm - Loss of Binary Signal |
| 10886 | 1550 nm - No Loss of Binary Signal | 10887 | 1550 nm - Loss of Binary Signal |

Table 5-32 STM-4c Tests Options 130, 131

| No. | Description | No. | Description |
|-------|---|-------|---|
| 10891 | 1310 nm - POH J1 Byte error | 10901 | 1310 nm, PRBS 2 ²³ - Frame Sync Loss |
| 10903 | 1310 nm, PRBS 2 ²³ - Error Rate Low | 10904 | 1310 nm, PRBS 2 ²³ - Error Rate High |
| 10911 | 1310 nm, PRBS 2 ¹⁵ - Frame Sync Loss | 10913 | 1310 nm, PRBS 2 ¹⁵ - Error Rate Low |
| 10914 | 1310 nm, PRBS 2 ¹⁵ - Error Rate High | 10921 | 1310 nm, Word - Frame Sync Loss |
| 10923 | 1310 nm, Word - Error Rate Low | 10924 | 1310 nm, Word - Error Rate High |
| 10931 | 1310 nm, PRBS 2 ⁹ - Frame Sync Loss | 10933 | 1310 nm, PRBS 2 ⁹ - Error Rate Low |
| 10934 | 1310 nm, PRBS 2 ⁹ - Error Rate High | 10941 | 1310 nm, Frequency Offset - Frame Sync Loss |
| 10942 | 1310 nm, Frequency Offset - Pointer Alarm | 10943 | 1310 nm, Frequency Offset - B1 Bip Errors |
| 10944 | 1310 nm, Frequency Offset - B2 Bip Errors | 10945 | 1310 nm, Frequency Offset - B3 Bip Errors |
| 10953 | 1310 nm, +100 ppm Offset - Result Low | 10954 | 1310 nm, +100ppm Offset -Result High |
| 10955 | 1310 nm, -100 ppm Offset - Result Low | 10956 | 1310 nm, -100ppm Offset -Result High |

SDH Self Test Error Codes

Table 5-33 STM-4 Payloads Tests Options 130, 131

| No. | Description | No. | Description |
|-------|--|-------|--|
| 10961 | Background Payload - Frame Sync Loss | 10962 | Background Payload - Errors Detected |
| 10971 | F/G Payload STM-1 #1 - Frame Sync Loss | 10972 | F/G Payload STM-1 #1 - Error Count Wrong |
| 10973 | F/G Payload STM-1 #2 - Frame Sync Loss | 10974 | F/G Payload STM-1 #2 - Error Count Wrong |
| 10975 | F/G Payload STM-1 #4 - Frame Sync Loss | 10976 | F/G Payload STM-1 #4 - Error Count Wrong |
| 10981 | ThruMode- H4Frame Fail | 10991 | Overhead Processor Fail |
| 10992 | STM-1-POHFail | 10994 | STM-1- SOH Fail |
| 10995 | RegeneratorSOHDCCFail | 10996 | Multiplexer SOH DCC Fail |

Terminology

Tables of ETSI Terms with their ANSI equivalents
and current terms with their equivalent earlier terms.

Terminology
ETSI / ANSI Equivalent Terms

ETSI / ANSI Equivalent Terms

The Terminology used on the instrument display is mainly ETSI terminology. The equivalent ANSI terminology is given in the following table

| ETSI Term | ANSI Term |
|------------------------------|--------------------------|
| I-n Intra Office, STM-n | Intermediate Reach (IR) |
| L-n.1 or L-n.2 long haul | LR long reach |
| Multiplexer Section (MS) | Line |
| MS-AIS | AIS-L (Line AIS) |
| MS-BIP | Line BIP |
| MS-DCC | Line DCC |
| MS-RD (MS FERF) | RDI-L (Line FERF) |
| Multiplexer Section Overhead | Line Overhead |
| Network Node Interface | Line Interface |
| AU-AIS (Path AIS) | AIS-P |
| HP-RDI (Path FERF) | RDI-P |
| Regenerator | Repeater |
| Regenerator Section (RS) | Section |
| Remote Alarm Indicator | Yellow Alarm |
| Regenerator Section Overhead | Section Overhead |
| RS-DCC | Section DCC |
| S-n.1 or S-n.2 short haul | Short Reach (SR) |
| STM-n | STS-n |
| SOH | TOH |
| Section Overhead (SOH) | Transport Overhead (TOH) |
| Tributary Unit (TU) | Virtual Tributary (VT) |

Terminology
ETSI / ANSI Equivalent Terms

| ETSI Term | ANSI Term |
|------------------------|------------------------------------|
| TU | VT |
| TU-AIS | VT AIS (AIS-V) |
| TU FERF / TU RDI | RDI-V / VT FERF |
| TU REI | VT FEBE |
| VC | SPE |
| Virtual Container | Payload Envelope |
| Virtual Container (VC) | Synchronous Payload Envelope (SPE) |
| VP-RDI (VP-FERF) | VP-RDI |
| VC-RDI (VC-FERF) | VC-RDI |

NOTE: VC is an ETSI abbreviation for Virtual Container and an ETSI / ANSI abbreviation for (ATM) Virtual Channel. The context of VC must therefore be taken into account when converting between standards.

Terminology
Current / Previous Terminology

Current / Previous Terminology

| Current Terminology | Previous Terminology |
|----------------------------|-----------------------------|
| B1 BIP | RS B1 BIP |
| B2 BIP | MS B2 BIP |
| B3 BIP | Path B3 BIP |
| MS-AIS | MS AIS |
| MS-RDI | MS RDI |
| MS-REI | MS FEBE |
| HP-IEC | Path IEC |
| AU-LOP | LOP |
| AU-AIS | Path AIS |
| HP-RDI | Path FERF |
| HP-REI | Path FEBE |
| TU-LOP | TU LOP |
| TU-AIS | TU Path AIS |
| LP-RDI | TU Path FERF |
| LP-REI | TU Path FEBE |

Index

A

Add/Drop Multiplexer Testing, 6, 10
Alarm Seconds
 SDH, 76
Alarm Stimulus/Response, 11
Alarms
 SDH, 12
ANSI / ETSI Equivalent Terms, 116

B

Bar Graph Logging, 87

C

Cumulative Results
 SDH, 64

D

DCC Testing, 14, 15, 17
Desynchroniser Stress, 18, 20

E

ERROR ADD TYPE Selection, 13
Error Summary, 62
ETSI / ANSI Equivalent Terms, 116

F

Frame Loss, 52
Frame Synchronization, 21
Frequency Measurement, 77

G

G.826 Analysis
 B1 BIP, 65
 B2 BIP, 66
 B3 BIP, 68
 HP-IEC, 70
 HP-REI, 69
 LP-REI 2 Mb/s, 74
 MS-REI, 67
 TLP-REI 34 Mb/s, 73
 TU BIP 2 Mb/s, 72
 TU BIP 34 Mb/s, 71
Graphics

 Bar Graph Logging, 88
 Logging Bar Graphs, 87

I

Introduction to SDH, 2

L

Logging At End of Measurement, 87
Logging Bar Graphs, 88
Logging Devices, 80
Logging During Measurement, 85
Logging Header, 81
Logging Results
 At end of Measurement, 86
 Bar Graphs, 86
 During Measurement, 81
 Error & Alarm Summaries, 88
 Graphics Text, 88
 Logging Header, 81
 Overhead Capture, 91
 Overhead Snapshot, 92
 Pointer Graph, 94
 Result Snapshot, 89
 Tributary Scan, 93

M

MSP Stimulus/Response, 30, 34

N

NetworkStress Testing
 Desynchroniser Stress, 18

O

Optical Clock Recovery Stress, 34, 35
Optical Power Measurement, 77
Overhead Capture Logging Example, 91
Overhead Snapshot Logging Example, 92

P

Payload Mapping/Demapping, 36, 41
PDH Alarm Scan, 52, 55
Performance Monitor Stimulus/Response,
 45
PerformanceMonitor Stimulus/Response,
 42
Pointer Graph Logging Example, 95

R

Results Definitions
 Cumulative SDH, 64
 Error Summary, 62
 Frequency Measurement, 77
 G.826 B1 BIP Analysis, 65
 G.826 B2 BIP Analysis, 66

 G.826 B3 BIP Analysis, 68
 G.826 HP-IEC, 70
 G.826 HP-REI, 69
 G.826 LP-REI 2 Mb/s, 74
 G.826 LP-REI 34 Mb/s, 73
 G.826 MS-REI Analysis, 67
 G.826 TU BIP 2 Mb/s, 72
 G.826 TU BIP 34 Mb/s, 71
 Optical Power, 77
 SDH Alarm Seconds, 76
 Short Term SDH, 63
 Trouble Scan, 62
Results Snapshot Logging Example, 90

S

SDH Alarm Seconds, 76
SDH Alarms, 12
SDH Error Analysis, 65–74
SDH Introduction, 2
SDH Jitter Transfer, 27
SDH measurement
 option A3R {A3S}, 4
SDH Options, 3
SDH Results
 Cumulative, 64
 G.826 B1 BIP, 65
 G.826 B2 BIP, 66
 G.826 B3 BIP, 68
 G.826 HP-IEC, 70
 G.826 HP-REI, 69
 G.826 LP-REI 2 Mb/s, 74
 G.826 LP-REI 34 Mb/s, 73
 G.826 MS-REI, 67
 G.826 TU BIP 2 Mb/s, 72
 G.826 TU BIP 34 Mb/s, 71
 Short Term, 63
Selective Jitter Transfer Measurement, 46
Self Test error codes
 processor tests, 98
Short Term Results
 SDH, 63

T

Terminology
 Current / previous, 118
 ETSI / ANSI, 116
Tributary Scan Logging Example, 93
Trouble Scan, 62

Index

Hewlett-Packard Sales and Service Offices

If you need technical assistance with a Hewlett-Packard test and measurement product or application please contact the Hewlett-Packard office or distributor in your country.

Asia Pacific:

Hong Kong:

Tel: (852) 2599 7889

India:

Tel: (91-11) 682-6000

Japan:

Hewlett-Packard Japan Ltd.
Measurement Assistance Center
9-1, Takakura-Cho, Hachioji-Shi,
Tokyo 192-8510, Japan

Tel: (81) 426-56-7832

Fax: (81) 426-56-7840

Korea:

Tel: (82-2) 769 0800

Malaysia:

Tel: (60-3) 291 0213

Philippines:

Tel: (63-2) 894 1451

People's Republic of China:

Tel: (86-10) 6505 0149

Singapore:

Tel: (1800) 292 8100

Taiwan:

Tel: (886-3) 492 9666

Thailand:

Tel: (66-2) 661 3900

For countries in Asia Pacific not listed, contact:

Hewlett-Packard Asia Pacific Ltd
17-21/F Shell Tower, Times Square,
1 Matheson Street
Causeway Bay
Hong Kong
Tel: (852) 2599 7777
Fax: (852) 2506 9285

Australia/New Zealand:

Hewlett-Packard Australia Ltd.
31-41 Joseph Street
Blackburn, Victoria 3130
Australia
Tel: 1 800 629 485

Canada:

Hewlett-Packard Canada Ltd.
5150 Spectrum Way
Mississauga, Ontario
L4W 5G1
Tel: (905) 206 4725

Europe, Africa and Middle East:

Austria:

Tel: (0)1 25000-0

Belgium and Luxembourg:

Tel: (02) 778 3417

Baltic Countries:

Tel: (358) 08872 2100

Czech Republic:

Tel: 420-2-4743111

Denmark:

Tel: 45 99 10 00

Hewlett-Packard Sales and Service Offices (cont'd)

Finland:

Tel: (90) 88 721

France:

Tel: (0)1 69.82.60.60

Germany:

Tel: (0180) 532 62-33

Greece:

Tel: 30-1-7264045

Hungary:

Tel: 36-1-4618219

Ireland:

Tel: (01) 284 4633

Israel:

Tel: 972-3-5380333

Italy:

Tel: 02 - 92 122 241

Netherlands:

Tel: (020) 547 6669

Norway:

Tel: (22) 73 57 50

Poland:

Tel: 48-22-6087700

Portugal:

Tel: (11) 482 85 00

Russia:

Tel: (7/095) 928 6885

Fax: (7/095) 916 9844

South Africa:

Tel: 27-22-8061000

Spain:

Tel: (34) 1 631 1323

Sweden:

Tel: (08) 444 22 77

Switzerland:

Tel: (01) 735 7111

Turkey:

Tel: 90-212-2245925

United Kingdom:

Tel: (01344) 366 666

***For countries in Europe/Middle East
and Africa not listed, contact:***

Hewlett-Packard
International Sales Europe
Geneva, Switzerland
Tel: +41-22-780-4111
Fax: +41-22-780-4770

Latin America:

Hewlett-Packard
Latin American Region Headquarters
5200 Blue Lagoon Drive
9th Floor
Miami, Florida 33126
U.S.A.
Tel: (305) 267-4245
Tel: (305) 267-4220
Fax: (305) 267-4288

United States:

Hewlett-Packard Company
Test and Measurement Organization
5301 Stevens Creek Blvd.
Bldg. 51L-SC
Santa Clara, CA 95052-8059
Tel: 1 800 452 4844

About This Edition

This is the 1st edition of
the 37717-90417 manual.
It documents the product
as of February 1998.
Edition dates are as
follows:

1st Edition, February 1998

© Copyright Hewlett-
Packard Company 1998.
All rights reserved.
Reproduction, adaption,
or translation without prior
written permission is
prohibited, except as
allowed under the
copyright laws.

In This Book

This book provides information on HP 37717C modules with SDH capability. It also provides applications associated with these modules.

The individual applications contain techniques which may be of value for purposes other than those shown

