
Contents

About This Document.....	1
1 Introduction to the Site Maintenance Terminal.....	1-1
1.1 Definition of the Site Maintenance Terminal.....	1-2
1.2 Functions of the Site Maintenance Terminal.....	1-2
1.3 Logical Objects.....	1-2
1.4 Site Maintenance Terminal System Software Window.....	1-3
2 Installing the Site Maintenance Terminal.....	2-1
2.1 Configuration Requirements of the Site Maintenance Terminal PC.....	2-2
2.2 Installing the Site Maintenance Terminal (Site Maintenance Terminal System).....	2-3
3 Getting Started with the Site Maintenance Terminal	3-1
3.1 Starting the Site Maintenance Terminal.....	3-2
3.1.1 Setting the IP Address of the Site Maintenance Terminal PC.....	3-2
3.1.2 Connecting the Site Maintenance Terminal PC with the BTS.....	3-3
3.1.3 Locally Logging in to the BTS.....	3-3
3.2 Exiting the Site Maintenance Terminal.....	3-5
4 Using the Site Management Rights.....	4-1
4.1 Site Management Rights.....	4-2
4.2 Obtaining the Site Management Rights.....	4-2
4.3 Releasing the site management rights.....	4-3
5 Managing Sites.....	5-1
5.1 Viewing Site Resources.....	5-3
5.2 Hierarchically Resetting Sites.....	5-4
5.3 Testing Sites.....	5-5
5.4 Testing Transport Performance.....	5-6
5.5 Viewing Site Alarm Delay Time.....	5-8
5.6 Monitoring Site Environment.....	5-9
5.7 Testing RF Performance.....	5-11
5.8 Viewing Ring Topology Parameters.....	5-13
5.9 Viewing Bar Codes.....	5-14
6 Managing Board Software.....	6-1
6.1 Introduction to Board Software.....	6-2

6.2 Downloading Board Software.....	6-5
6.3 Activating Board Software.....	6-6
6.4 Checking Software Versions.....	6-9
7 Managing Cells.....	7-1
7.1 Managing Cell Attributes.....	7-2
7.2 Managing Cell Extended Attributes.....	7-5
7.3 Changing Cell Management States.....	7-7
7.4 Testing Cell Performance.....	7-8
8 Managing BTs.....	8-1
8.1 Changing BT Management States.....	8-2
8.2 Initializing BTs.....	8-3
8.3 Testing BTs.....	8-4
8.4 Viewing Channel States.....	8-5
8.5 Testing TRX Transmit Power Levels.....	8-5
9 Managing RCs.....	9-1
9.1 Managing RC Attributes.....	9-2
9.2 Managing RC Extended Attributes.....	9-3
9.3 Changing RC Management States.....	9-5
9.4 Initializing RCs.....	9-6
9.5 Obtaining Automatic Power Control Type.....	9-7
9.6 Obtaining RC Power Modes.....	9-7
10 Managing Channels.....	10-1
10.1 Managing Channel Attributes.....	10-2
10.2 Changing Channel Management States.....	10-3
10.3 Performing Loopback Test on Channels.....	10-4
11 Managing Equipment.....	11-1
11.1 Configuring Racks.....	11-3
11.2 Configuring Boards.....	11-4
11.3 Resetting Boards.....	11-5
11.4 Testing Boards.....	11-6
11.5 Changing Board Management States.....	11-8
11.6 Viewing Board Information.....	11-9
11.7 Viewing Extended Information on Boardd.....	11-11
11.8 Performing Loopback Test on Board Communication Links.....	11-12
11.9 Viewing Board Alarms.....	11-14
11.10 Setting BTS Clock.....	11-16
11.11 Setting Antenna and Feeder Parameters.....	11-18
11.12 Configuring Antenna System and TMA Parameters.....	11-20
11.13 Viewing Board Parameters.....	11-22
11.14 Switching Over Active and Standby DTMUs.....	11-24

11.15 Viewing DPMU Parameters.....11-26

11.16 Maintaining Battery Parameters.....11-27

11.17 Viewing Parameter States and Slot Information.....11-29

Figures

Figure 1-1 Logical structure	1-3
Figure 1-2 Site Maintenance Terminal System software window.....	1-4
Figure 3-1 Failure in configuring a site.....	3-4
Figure 3-2 Site Maintenance Terminal System window.....	3-4
Figure 3-3 Setting communication port parameters.....	3-5
Figure 4-1 Obtaining the site management rights.....	4-3
Figure 4-2 Releasing the site management rights.....	4-4
Figure 5-1 Viewing resources.....	5-3
Figure 5-2 Hierarchical reset of a site.....	5-5
Figure 5-3 Site Test dialog box.....	5-6
Figure 5-4 Transport Performance Test dialog box.....	5-8
Figure 5-5 Viewing site alarm delay time.....	5-9
Figure 5-6 Environment monitoring.....	5-11
Figure 5-7 RF specification test.....	5-13
Figure 5-8 Viewing ring topology parameters.....	5-14
Figure 5-9 Viewing bar codes.....	5-15
Figure 6-1 Forced software download.....	6-6
Figure 6-2 Activating the DTMU software.....	6-8
Figure 6-3 Activating the DTRU software.....	6-9
Figure 6-4 DTRU board management.....	6-10
Figure 6-5 DTRU board information.....	6-10
Figure 7-1 Cell attributes management.....	7-4
Figure 7-2 Cell extended attributes management.....	7-6
Figure 7-3 Changing the cell management state.....	7-7
Figure 7-4 Cell performance test.....	7-8
Figure 8-1 Changing the BT management state.....	8-2
Figure 8-2 BT reinitialization.....	8-3
Figure 8-3 BT Loopback Test dialog box.....	8-4
Figure 8-4 View Channel State dialog box.....	8-5
Figure 8-5 TRX full power emission.....	8-6
Figure 9-1 RC attributes management.....	9-2
Figure 9-2 RC extended attribute management.....	9-4
Figure 9-3 Changing the RC management state.....	9-5

Figure 9-4 RC reinitialization.....	9-6
Figure 9-5 Get Auto Power Adjustment Type dialog box.....	9-7
Figure 9-6 Obtaining the RC power mode.....	9-8
Figure 10-1 Channel attributes management.....	10-3
Figure 10-2 Changing channel management state.....	10-4
Figure 10-3 Loopback test.....	10-6
Figure 11-1 Rack configuration.....	11-3
Figure 11-2 Board configuration.....	11-5
Figure 11-3 Board management.....	11-6
Figure 11-4 Resetting a board.....	11-6
Figure 11-5 Board management.....	11-7
Figure 11-6 Board test.....	11-7
Figure 11-7 Board management.....	11-8
Figure 11-8 Changing the board management state.....	11-9
Figure 11-9 Board management.....	11-10
Figure 11-10 Board information.....	11-10
Figure 11-11 Board management.....	11-11
Figure 11-12 Board extended information.....	11-12
Figure 11-13 Board management.....	11-13
Figure 11-14 Performing loopback test.....	11-14
Figure 11-15 Board management.....	11-15
Figure 11-16 Board alarm information.....	11-15
Figure 11-17 Board management.....	11-17
Figure 11-18 Clock mode selection.....	11-18
Figure 11-19 Board management.....	11-19
Figure 11-20 Antenna and feeder setup.....	11-20
Figure 11-21 Board management.....	11-21
Figure 11-22 Configuring antenna system and TMA.....	11-22
Figure 11-23 Board management.....	11-23
Figure 11-24 Parameter management.....	11-24
Figure 11-25 Board management.....	11-25
Figure 11-26 Changeover dialog box.....	11-25
Figure 11-27 Board management.....	11-26
Figure 11-28 Configuration and Information dialog box.....	11-27
Figure 11-29 Board management.....	11-28
Figure 11-30 Battery Operation dialog box.....	11-28
Figure 11-31 Board management.....	11-30
Figure 11-32 Parameter state and slot information.....	11-30

Tables

Table 2-1 Hardware requirements.....	2-2
Table 2-2 Software requirements.....	2-2
Table 5-1 Parameters in the Site Reset Hierarchically dialog box.....	5-4
Table 5-2 Parameters in the Transport Performance Test dialog box.....	5-6
Table 5-3 Parameters in the Environment Monitor dialog box.....	5-10
Table 6-1 Parameters in the Software Download dialog box.....	6-5
Table 6-2 Parameters in the Software Activation dialog box.....	6-7
Table 7-1 Parameters in the Cell Attributes Management dialog box.....	7-2
Table 7-2 Parameters in the Cell Extended Attributes Management dialog box.....	7-5
Table 9-1 Parameters in the RC Attributes Management dialog box.....	9-2
Table 9-2 Parameters in the RC Extended Attribute Management dialog box.....	9-3
Table 10-1 Parameters in the Channel Attributes Management dialog box.....	10-2
Table 10-2 Parameters in the Cell Extended Attributes Management dialog box.....	10-5
Table 11-1 Parameters in the Loop Test dialog box.....	11-12
Table 11-2 Parameters in the Clock Setup dialog box.....	11-16
Table 11-3 Parameters in the Antenna Feeder Setup dialog box.....	11-18
Table 11-4 Parameters in the Configure CDU dialog box.....	11-20
Table 11-5 Parameters in the Changeover dialog box.....	11-24