

IBM 8285 Nways ATM Workgroup Switch

Installation Instruction

for

ATM firmware upgrade kit

FPGA level C31, C30, B50

Operational Microcode Version v.1.5.2

Boot Microcode Version v.1.5.2

MES 5099

PN N.A. 1 of 21	EC N.A. 18Jun97				
--------------------	--------------------	--	--	--	--

1.0 Contents

- 1.1 Trademarks and Service Marks 3
- 2.0 Installation Instruction** 4
- 2.1 Before Installation 4
 - 2.1.1 Purpose 4
 - 2.1.2 Prerequisite 4
 - 2.1.3 Machines affected 5
 - 2.1.4 Distribution Files 6
 - 2.1.5 Requirements 7
 - 2.1.6 References 8
 - 2.1.7 Copying the Distribution files on your Workstation 8
- 2.2 Upgrading the 8285 10
 - 2.2.1 Step 0: Saving Configuration before the upgrade 10
 - 2.2.2 Step 1: Download Inband the 8285 boot microcode 11
 - 2.2.3 Step 2: Download Inband the 8285 operational microcode 12
 - 2.2.4 Step 3 : Download Inband the 8285 FPGA picocode 13
 - 2.2.5 Step 4 : Download Inband the FPGA picocode on media modules 13
 - 2.2.6 Step 5 : Activate the new 8285 microcodes and FPGA picocode 18
 - 2.2.7 Step 6 : Check the new levels of codes : 20
 - 2.2.8 Step 7 : Checking Network and Saving Configuration 20
- 2.3 Upgrading a new ATM module 21
 - 2.3.1 Step 8: Upgrading a new ATM module 21
- 2.4 After Installation 21
 - 2.4.1 Publication Update 21

PN N.A. 2 of 21	EC N.A. 18Jun97				
--------------------	--------------------	--	--	--	--

1.1 Trademarks and Service Marks

The following terms, denoted by an asterisk (*), used in this Installation Instruction, are trademarks or service marks of the IBM Corporation in the United States or other countries.

OS/2	AIX
IBM	PS/2
UNIX	AT&T

PN N.A. 3 of 21	EC N.A. 18Jun97				
--------------------	--------------------	--	--	--	--

2.0 Installation Instruction

2.1 Before Installation

2.1.1 Purpose

The purpose of this document is to provide instructions for upgrading the 8285.

2.1.2 Prerequisite

Here follow the different pre-requisite levels:

1. If you **NEVER** applied the field **B/M 10J2451 EC Number E28237**, here under are the minimum required levels for the ATM components:

Component	Feature Code	Operational FPGA Version	Flash EEPROM Version	Boot EEPROM Version
8285	----	1	v1.0.0	v1.0.0
A4-FB100 (MIC)	5004	6	n/a	n/a
A4-FB100 (SC)	5104	6	n/a	n/a
A2-MB155	5002	7/81	n/a	n/a
A3-MB155	5003	1	n/a	n/a
A12-TP25	5012	1	n/a	n/a
A-CMU1	5102	B3E3/B3F3	n/a	n/a
A-CMU2	5202	B3E3/B3F3	n/a	n/a
A04MB-BRG	5204	B3E3/B3F3	n/a	n/a
A2-WAN	5302	B3E3/B3F3	n/a	n/a

Field B/M 51H4282 EC E28134 will allow to upgrade ATM Media Modules (A4-FB100 MIC,A4-FB100 SC,A2-MB155) to the latest FPGA 8/81 level.

PN N.A. 4 of 21	EC N.A. 18Jun97				
--------------------	--------------------	--	--	--	--

2. If you **ALREADY** applied the field B/M 10J1995 EC Number E95670, here under are the minimum required levels for the ATM components:

Component	Feature Code	Operational FPGA Version	Flash EEPROM Version	Boot EEPROM Version
8285	----	C10	v.1.4.0	v.1.4.0
A4-FB100 (MIC)	5004	B40	n/a	n/a
A4-FB100 (SC)	5104	B40	n/a	n/a
A2-MB155	5002	B40	n/a	n/a
A3-MB155	5003	C10	n/a	n/a
A12-TP25	5012	C10	n/a	n/a
A-CMU1	5102	B40	n/a	n/a
A-CMU2	5202	B40	n/a	n/a
A04MB-BRG	5204	B40	n/a	n/a
A2-WAN	5302	B40	n/a	n/a

2.1.3 Machines affected

This installation instruction, Part Number 10J2452, applies to the following 8285 levels:

Component	Flash EEPROM Version	Boot EEPROM Version
8285	v.1.0.0	v.1.0.0
	v.1.0.1	v.1.0.1
	v.1.2.0	v.1.2.0
	v.1.3.0	v.1.3.0
	v.1.4.0	v.1.4.0
	v.1.4.3	v.1.4.3
	v.1.5.0	v.1.5.0
	v.1.5.1	

To know the current version of the operational code on your 8285, use the command "SHOW DEVICE" and look for the line beginning with "Flash EEPROM Version".

PN N.A. 5 of 21	EC N.A. 18Jun97				
--------------------	--------------------	--	--	--	--

2.1.4 Distribution Files

These files should be placed in a directory reachable through TFTP, like /tmp for a UNIX/AIX station.

The present kit contains 10 diskette images :

1. The diskette image, Part Number 10J2408, contains for A-CPSW 8260:
 - a. A notice file (README.826)
 - b. A-CPSW boot microcode (oper252.bin)
 - c. A-CPSW operational microcode (boot252.bin)
 - d. A soft copy of this installation instruction (inst8260.doc)
 - e. A soft copy of the release note (rel8260.doc)
2. The diskette image, Part Number 10J2409, contains:
 - a. A-CPSW FPGA picocode (swpgab50.enc)
 - b. 8285 FPGA picocode (85pgac30.enc)
 - c. A new MIB version 1.7 (mib1.7)
3. The diskette image, Part Number 10J2410, contains:
 - a. HS 100Mbps MIC connector FPGA picocode (100mc50.enc)
 - b. HS 100Mbps SC connector FPGA picocode (100sc50.enc)
4. The diskette image, Part Number 10J2411, contains:
 - a. HS 155Mbps 2 ports FPGA picocode (1552p50.enc)
 - b. HS 155Mbps 3 ports FPGA picocode (1553p31.enc)
5. The diskette image, Part Number 10J2412, contains:
 - a. Carrier module FPGA picocode (cmpga50.enc)
 - b. 12 port 25 Mbps module FPGA picocode (25pga30.enc)
6. The diskette image, Part Number 10J2413, contains for 8285:
 - a. A notice file (README.285)
 - b. 8285 boot microcode (boot152.bin)
 - c. 8285 operational microcode (oper152.bin)
 - d. A soft copy of the installation instruction (inst8285.doc)
 - e. A soft copy of the release note (rel8285.doc)
7. The diskette image, Part Number 10J2414, contains:
 - a. 12 port 25 Mbps module Back level FPGA picocode (25old1.enc)
 - b. 8285 Back level FPGA picocode (8285old3.enc)
8. The diskette image, Part Number 10J2415, contains:
 - a. HS 100Mbps MIC connector FPGA picocode (100mold8.enc)
 - b. HS 100Mbps SC connector FPGA picocode (100sold8.enc)
9. The diskette image, Part Number 10J2416, contains:
 - a. HS 155Mbps 2 ports FPGA picocode (155old81.enc)
 - b. HS 155Mbps 3 ports FPGA picocode (155old1.enc)
10. The diskette image, Part Number 10J2417, contains:
 - a. Carrier module FPGA picocode (cmoldb3.enc)

PN N.A. 6 of 21	EC N.A. 18Jun97				
--------------------	--------------------	--	--	--	--

2.1.5 Requirements

2.1.5.1 In-band download method

You need to perform an in-band download operation for the FPGA picocode upgrade.

For the in-band download, you **must** have a TFTP Server connected to the ATM network, either in Classical IP, or in Ethernet or Token Ring LAN-Emulation, or in SLIP through the 8285 Console port.

* Classical IP mode

Make sure that your ATM network is configured for IP Over ATM (RFC 1577).

To configure your ATM network for IP over ATM:

1. Connect an ARP server to the ATM network. The ARP server will be used to map IP addresses to ATM addresses.
2. For each 8285 verify that the following parameters are configured:
 - ATM address of the ARP server
 - IP address and IP mask of the 8285
 - IP address of the default gateway
3. Verify the IP connectivity to the ARP server by entering a PING command on each 8285.
4. If your TFTP Server is not the ARP-Server, verify the IP connectivity to the TFTP Server by entering a PING command on each 8285.

The microcode file must be installed on that TFTP Server, in a directory reachable through TFTP.

* Ethernet or Token Ring LAN-Emulation mode

Make sure your network is configured in Ethernet or Token Ring LAN-Emulation.

To configure your network in Ethernet or Token Ring LAN-Emulation :

1. you must have an Ethernet or Token Ring LAN-Emulation server configured and ready.

You may use the local LES of the 8285. Refer to the section "Setting Up LAN Emulation Servers" in the Chapter 6 of the IBM 8285 Installation and User 's guide (SA33-0381-00), or in the Chapter 14 of the IBM 8285 Installation and User 's guide (SA33-0381-01).
2. you must configure the Ethernet or Token Ring LAN-Emulation Client on your 8285.

Refer to the section "Setting SNMP Parameters" in Chapter 6 of the IBM 8285 Installation and User 's guide (SA33-0381-00), or to the section "Setting Up a LAN-Emulation Client" in Chapter 14 of the IBM 8285 Installation and User 's guide (SA33-0381-01).
3. you must have a TFTP Server somewhere in the IP network (either on the Emulated LAN, either behind an IP Gateway), and the microcode files installed on that TFTP Server.

* Serial Line IP (SLIP) mode

Make sure your SLIP workstation can act as a TFTP server.

Note: If you have TCP/IP for OS/2, the TFTP Server is 'TFTPD.EXE'.

1. Set up the 8285 Console configuration in SLIP Mode:

PN N.A. 7 of 21	EC N.A. 18Jun97				
--------------------	--------------------	--	--	--	--

Refer to the section "Setting Up a Configuration Console in SLIP Mode" in Chapter 5 of the *IBM 8285 Installation and User's guide (SA33-0381-00)*, or in Chapter 9 of the *IBM 8285 Installation and User's guide (SA33-0381-01)*, for details on this.

2. Then set the TFTP server address to the SLIP remote address, to allow you to perform in-band download between your workstation and the 8285.

2.1.5.2 Out-of-Band download method

WARNING

The download out-of-band is not supported for this release.

2.1.6 References

- * Release Note, Part number 10J2329, EC level E95670.
- * Installation Instruction for IBM Universal Code Download Kit, Part Number 80G3152
- * IBM 8285 Installation and User's guide (SA33-0381-01)
- * IBM 8285 Installation and User's guide (SA33-0381-00)
- * IBM 8285/8260 ATM Command Reference Guide (SA33-0385)
- * ProComm Reference Manual

2.1.7 Copying the Distribution files on your Workstation

Important

This is a necessary step for downloading the 8285 software microcodes from a workstation.

1. Use the diskette image to copy to the directory where you want the microcodes to reside, the following files:
8285 boot microcode, file name: **boot152.bin**.
8285 operational microcode, file name: **oper152.bin**.
2. Use the diskette image to copy to the directory where you want the picocode to reside, the following file:
8285 FPGA picocode file name : **85pgac30.enc**.
3. Use the diskette image to copy to the directory where you want the picocode to reside, the following files:
HS 100Mbps MIC connector FPGA picocode file name : **100mc50.enc**.
HS 100Mbps SC connector FPGA picocode file name : **100sc50.enc**.
4. Use the diskette image to copy to the directory where you want the picocode to reside, the following files:
HS 155Mbps 2 ports FPGA picocode file name : **1552p40.enc**.

PN N.A. 8 of 21	EC N.A. 18Jun97				
--------------------	--------------------	--	--	--	--

HS 155Mbps 3 ports FPGA picocode file name : **1553p31.enc**.

5. Use the diskette image to copy to the directory where you want the picocode to reside, the following file:

Carrier Module FPGA picocode file name : **cmpga40.enc**.

12 ports 25 Mbps module FPGA picocode file name : **25pga30.enc**.

6. Use the diskette image to copy to the directory where you want the picocode to reside, the following file:

12 ports 25 Mbps module old FPGA picocode file name : **25old1.enc**.

8285 old FPGA picocode file name : **8285old3.enc**.

7. Use the diskette image to copy to the directory where you want the picocode to reside, the following file:

HS 100Mbps MIC connector FPGA picocode file name: **100mold8.enc**.

HS 100Mbps SC connector FPGA picocode file name: **100sold8.enc**.

8. Use the diskette image to copy to the directory where you want the picocode to reside, the following file:

HS 155Mbps 2 ports FPGA picocode file name: **155old81.enc**.

HS 155Mbps 3 ports FPGA picocode file name: **155old1.enc**.

9. Use the diskette image to copy to the directory where you want the picocode to reside, the following file:

Carrier module FPGA picocode file name: **cmoldb3.enc**.

10. On an AIX Workstation make sure that the files can be read by all users :

Log in as "root"

Set the path to the microcode files directory

Enter: `chmod a+r boot152.bin`

Enter: `chmod a+r oper152.bin`

Enter: `chmod a+r 85pgac30.enc`

Enter: `chmod a+r 100mc50.enc`

Enter: `chmod a+r 100sc50.enc`

Enter: `chmod a+r 1552p50.enc`

Enter: `chmod a+r 1553p31.enc`

Enter: `chmod a+r cmpga50.enc`

Enter: `chmod a+r 25pga30.enc`

Enter: `chmod a+r 25old1.enc`

Enter: `chmod a+r 8285old3.enc`

Enter: `chmod a+r 100mold8.enc`

Enter: `chmod a+r 100sold8.enc`

Enter: `chmod a+r 155old81.enc`

Enter: `chmod a+r 155old1.enc`

Enter: `chmod a+r cmoldb3.enc`

2.2 Upgrading the 8285

Before upgrade Reminder

Check that all the ATM components of your network are at the PREREQUISITE levels: refer to chapters "Prerequisite" and "Machines Affected" above.

IMPORTANT

The following steps are showing an example of Inband Download in Classical IP mode, using the ARP server as TFTP server .

It is recommended to update **all** 8285 ATM hubs starting with the 8285 module that is the farthest from the ARP server in terms of SSI/NNI links hops.

You may log in to the 8285 console either **locally** using an ASCII terminal connected to the 8285 console port, or **remotely** using a TELNET session.

WARNING WARNING WARNING WARNING

It is recommended to keep the previous level of FPGA picocode as backup on each blade for later on.

Due to the incompatibility between previous level of FPGA picocode and new level of 8285 operational microcode, you have to follow carefully the installation procedure.

Just in case

Since a new migration process exists for the ATM FIRMWARE upgrade kit, you might encounter new MAINTENANCE codes (please refer to the Release Note REL8285 in the appendix B).

2.2.1 Step 0: Saving Configuration before the upgrade

REMINDER

It is recommended to perform the following steps with **NO OPERATIONAL TRAFFIC** flowing in your ATM campus network. Typically, this would be scheduled as part of a maintenance period. You would better save all your configuration parameters before.

Before you begin the upgrade procedure we recommend to upload the configuration of each 8285 in your network :

1. Setup the TFTP parameters by entering the following commands:
SET TFTP SERVER_IP_ADDRESS <ip address of the TFTP server>
SET TFTP FILE_TYPE CONFIGURATION
SET TFTP FILE_NAME
Provide the full path of the file when prompted
2. Start the upload inband procedure by entering:
UPLOAD
When prompted, type "Y" to confirm.

PN N.A. 10 of 21	EC N.A. 18Jun97				
---------------------	--------------------	--	--	--	--

8285 UPGRADE

PLEASE, READ WHAT FOLLOWS CAREFULLY :

In case you **have just a NEW ATM media blade** to upgrade in an **8285 already upgraded** with the Firmware upgrade kit, follow the **Step 8 only**.

In case you **have a full 8285** to migrate, follow the **Steps 1 to 7**.

2.2.2 Step 1: Download Inband the 8285 boot microcode

Upgrade the 8285 boot microcode as follows:

1. Log in as the **Administrator** on the 8285 console

MANDATORY for v.1.3.0

If the current level of microcode on the 8285 is v.1.3.0, perform the following command:

```
SET DEVICE MIGRATION ALLOWED
SAVE DEVICE
```

MANDATORY for v.1.4.0 or v.1.4.3

If the current level of microcode on the 8285 is v.1.4.0 or v.1.4.3 perform the following command:

```
SET DEVICE MIGRATION NOT_ALLOWED
SAVE DEVICE
```

2. Upgrade the 8285 boot microcode (Boot EEPROM) as follows:

- a. Configure the TFTP parameters by entering the following commands:

```
SET TFTP SERVER_IP_ADDRESS <ip address of the TFTP server>
SET TFTP FILE_TYPE BOOT
SET TFTP FILE_NAME
```

Type the full path name of the boot microcode file (**boot152.bin**) when prompted.

- b. Make sure you can reach the TFTP server by entering:

```
PING <ip address of the TFTP server>
(Stop ping by entering: Ctrl+C)
```

- c. Start the download inband procedure by entering:

```
DOWNLOAD INBAND
```

When prompted, type "Y" to confirm.

- d. Wait for successful termination of the download operation. The message *Download successful* is displayed.

This may also be checked by displaying the TFTP last transfer result with the command: "SHOW TFTP".

Note

The command "SHOW DEVICE" displays the new BOOT code version which will become active.

It will be displayed as **v.1.5.2**.

In Case of Failure

If the download inband operation fails, retry this step. If the failure recurs, refer to the Troubleshooting chapter of *IBM 8285 Nways ATM Workgroup Switch: Installation and User's Guide*.

2.2.3 Step 2: Download Inband the 8285 operational microcode

Upgrade the active 8285 operational microcode (Flash EEPROM) as follows:

1. Configure the TFTP parameters by entering the following commands:

```
SET TFTP SERVER_IP_ADDRESS <ip address of the TFTP server>
SET TFTP FILE_TYPE OPERATIONAL
SET TFTP FILE_NAME
```

Type the full path name of the operational microcode file (**oper152.bin**) when prompted.

2. Make sure you can reach the TFTP server by entering:
PING <ip address of the TFTP server>
(Stop ping by entering: Ctrl+C)
3. Start the download inband procedure by entering:
DOWNLOAD INBAND
When prompted, type "Y" to confirm.
4. Wait for successful termination of the download operation. The message *Download successful* is displayed.

This may also be checked by displaying the TFTP last transfer result through the command: "SHOW TFTP".

Note

The command "SHOW DEVICE" displays the operational code level in backup.

It will appear as **v.1.5.2**.

In Case of Failure

If the download inband operation fails, retry this step. If the failure recurs, refer to the Troubleshooting chapter of *IBM 8285 Nways ATM Workgroup Switch: Installation and User's Guide*.

PN N.A. 12 of 21	EC N.A. 18Jun97				
---------------------	--------------------	--	--	--	--

2.2.4 Step 3 : Download Inband the 8285 FPGA picocode

1. Configure the TFTP parameters by entering the following commands:

```
SET TFTP SERVER_IP_ADDRESS <ip address of the TFTP server>
SET TFTP FILE_TYPE FPGA
SET TFTP FILE_NAME
Type the full path name of the FPGA file (85pgac30.enc) when prompted.
SET TFTP TARGET_MODULE 1
```

2. Make sure you can reach the TFTP server by entering:

```
PING <ip address of the TFTP server>
(Stop ping by entering: Ctrl+C)
```

3. Start the download inband procedure by entering:

```
DOWNLOAD INBAND
When prompted, type "Y" to confirm.
```

4. Wait for successful termination of the download operation (it may take up to 10 minutes). The message *Download successful* is displayed.

This may also be checked by displaying the TFTP last transfer result with the command: "SHOW TFTP".

Note

The command **SHOW MODULE 1 VERBOSE** displays the FPGA level in backup. It will appear as **C30**.

In Case of Failure

If the download inband operation fails, retry this step. If the failure recurs, refer to the Troubleshooting chapter of *IBM 8285 Nways ATM Workgroup Switch: Installation and User's Guide*.

2.2.5 Step 4 : Download Inband the FPGA picocode on media modules

WARNING

You must download the new FPGA picocode on all of the blades of the 8285 expansion before proceeding to the next steps.

1. Be sure that the status of **all** ATM media modules plugged in the 8285 is **connected**. This is a prerequisite for performing a download operation on an ATM media module. To verify that a module is **connected**, enter the SHOW MODULE ALL command from the 8285 console. To connect an isolated ATM media module, enter the SET MODULE n CONNECTED command, where "n" is the number of the slot where the ATM media module is installed.
2. Display the configuration of your **connected** ATM media modules by entering a SHOW MODULE ALL VERBOSE command. This allows you to distinguish the different media modules installed in the 8285
3. For **each** A4-FB100 module with MIC connectors (FC 5004)

PN N.A. 13 of 21	EC N.A. 18Jun97				
---------------------	--------------------	--	--	--	--

- a. **Please check first, that FPGA level B50 is not already present in the A4-FB100 MIC (as operational or as backup) :**

SHOW MODULE n VERBOSE (n is the position of the blade)

If FPGA level is B50, then skip to next blade

- b. Configure the TFTP parameters by entering the following commands:

SET TFTP SERVER_IP_ADDRESS <ip address of the TFTP server>

SET TFTP FILE_TYPE FPGA

SET TFTP FILE_NAME

Type the full path name of the FPGA file (**100mc50.enc**) when prompted

SET TFTP TARGET_MODULE n

Where "n" is the number of the slot where the A4-FB100 module is installed.

- c. Start the download inband procedure by entering:

DOWNLOAD INBAND

When prompted, type "Y" to confirm.

- d. Wait for successful termination of the download operation (it may take up to 10 minutes). The message *Download successful* is displayed.

Note

The command **SHOW MODULE n VERBOSE** (where "n" is the number of the slot where the A4-FB100 MIC module is installed) displays the FPGA level in backup.

It will appear as **B50**.

In Case of Failure

If the download inband operation fails, retry the download. If the failure recurs, refer to the Troubleshooting chapter of *IBM 8285 Nways ATM Workgroup Switch: Installation and User's Guide*.

4. For **each** A4-FB100 with SC connectors (FC 5104):

- a. **Please check first, that FPGA level B50 is not already present in the A4-FB100 (as operational or as backup) :**

SHOW MODULE n VERBOSE (n is the position of the blade)

If FPGA level is B50, then skip to next blade

- b. Configure the TFTP parameters by entering the following commands:

SET TFTP SERVER_IP_ADDRESS <ip address of the TFTP server>

SET TFTP FILE_TYPE FPGA

SET TFTP FILE_NAME

Type the full path name of the FPGA file (**100sc50.enc**) when prompted

SET TFTP TARGET_MODULE n

Where "n" is the number of the slot where the A4-FB100 module is installed.

- c. Start the download inband procedure by entering:

DOWNLOAD INBAND

When prompted, type "Y" to confirm.

- d. Wait for successful termination of the download operation (it may take up to 10 minutes). The message *Download successful* is displayed.

Note

The command **SHOW MODULE n VERBOSE** (where "n" is the number of the slot where the A4-FB100 SC module is installed) displays the FPGA level in backup.

It will appear as **B50**.

In Case of Failure

If the download inband operation fails, retry the download. If the failure recurs, refer to the Troubleshooting chapter of *IBM 8285 Nways ATM Workgroup Switch: Installation and User's Guide*.

- 5. For **each** A2-MB155 (FC 5002):

- a. **Please check first, that FPGA level B50 is not already present in the A2-MB155 (as operational or as backup) :**

SHOW MODULE n VERBOSE (n is the position of the blade)

If FPGA level is B50, then skip to next blade

- b. Configure the TFTP parameters by entering the following commands:

SET TFTP SERVER_IP_ADDRESS <ip address of the TFTP server>

SET TFTP FILE_TYPE FPGA

SET TFTP FILE_NAME

Type the full path name of the FPGA file (**1552p40.enc**) when prompted

SET TFTP TARGET_MODULE n

Where "n" is the number of the slot where the A2-MB155 module is installed.

- c. Start the download inband procedure by entering:

DOWNLOAD INBAND

When prompted, type "Y" to confirm.

- d. Wait for successful termination of the download operation (it may take up to 10 minutes). The message *Download successful* is displayed.

Note

The command **SHOW MODULE n VERBOSE** (where "n" is the number of the slot where the A2-MB155 module is installed) displays the FPGA level in backup.

It will appear as **B50**.

In Case of Failure

If the download inband operation fails, retry the download. If the failure recurs, refer to the Troubleshooting chapter of *IBM 8285 Nways ATM Workgroup Switch: Installation and User's Guide*.

- 6. For **each** A3-MB155 (FC 5003):

PN N.A. 15 of 21	EC N.A. 18Jun97				
---------------------	--------------------	--	--	--	--

- a. **Please check first, that FPGA level C31 is not already present in the A3-MB155 (as operational or as backup) :**

SHOW MODULE n VERBOSE (n is the position of the blade)

If FPGA level is C31, then skip to next blade

- b. Configure the TFTP parameters by entering the following commands:

SET TFTP SERVER_IP_ADDRESS <ip address of the TFTP server>

SET TFTP FILE_TYPE FPGA

SET TFTP FILE_NAME

Type the full path name of the FPGA file (**1553p31.enc**) when prompted

SET TFTP TARGET_MODULE n

Where "n" is the number of the slot where the A3-MB155 module is installed.

- c. Start the download inband procedure by entering:

DOWNLOAD INBAND

When prompted, type "Y" to confirm.

- d. Wait for successful termination of the download operation (it may take up to 10 minutes). The message *Download successful* is displayed.

Note

The command **SHOW MODULE n VERBOSE** (where "n" is the number of the slot where the A3-MB155 module is installed) displays the FPGA level in backup.

It will appear as **C31**.

In Case of Failure

If the download inband operation fails, retry the download. If the failure recurs, refer to the Troubleshooting chapter of *IBM 8285 Nways ATM Workgroup Switch: Installation and User's Guide*.

7. For **each** A12-TP25 (FC 5012):

- a. **Please check first, that FPGA level C30 is not already present in the A12-TP25 (as operational or as backup) :**

SHOW MODULE n VERBOSE (n is the position of the blade)

If FPGA level is C30, then skip to next blade

- b. Configure the TFTP parameters by entering the following commands:

SET TFTP SERVER_IP_ADDRESS <ip address of the TFTP server>

SET TFTP FILE_TYPE FPGA

SET TFTP FILE_NAME

Type the full path name of the FPGA file (**25pga30.enc**) when prompted

SET TFTP TARGET_MODULE n

Where "n" is the number of the slot where the A12-TP25 module is installed.

- c. Start the download inband procedure by entering:

DOWNLOAD INBAND

When prompted, type "Y" to confirm.

PN N.A. 16 of 21	EC N.A. 18Jun97				
---------------------	--------------------	--	--	--	--

- d. Wait for successful termination of the download operation (it may take up to 10 minutes). The message *Download successful* is displayed.

Note

The command **SHOW MODULE n VERBOSE** (where "n" is the number of the slot where the A12-TP25 module is installed) displays the FPGA level in backup.

It will appear as **C30**.

In Case of Failure

If the download inband operation fails, retry the download. If the failure recurs, refer to the Troubleshooting chapter of *IBM 8285 Nways ATM Workgroup Switch: Installation and User's Guide*.

8. For **each** A-CMU1, A-CMU2, A04MB-BRG, A2-WAN (FC 5102, 5202, 5204, 5300, 5008 and 5302) :

- a. **Please check first, that FPGA level B50 is not already present in the blade (as operational or as backup) :**

SHOW MODULE n VERBOSE (n is the position of the blade)

If FPGA level is B50, then skip to next blade

- b. Configure the TFTP parameters by entering the following commands:

SET TFTP SERVER_IP_ADDRESS <ip address of the TFTP server>

SET TFTP FILE_TYPE FPGA

SET TFTP FILE_NAME

Type the full path name of the FPGA file (**cmpg40.enc**) when prompted

SET TFTP TARGET_MODULE n

Where "n" is the number of the slot where the module is installed.

- c. Start the download inband procedure by entering:

DOWNLOAD INBAND

When prompted, type "Y" to confirm.

- d. Wait for successful termination of the download operation (it may take up to 10 minutes). The message *Download successful* is displayed.

Note

The command **SHOW MODULE n VERBOSE** (where "n" is the number of the slot where the ATM module is installed) displays the FPGA level in backup.

It will appear as **B50**.

In Case of Failure

If the download inband operation fails, retry the download. If the failure recurs, refer to the Troubleshooting chapter of *IBM 8285 Nways ATM Workgroup Switch: Installation and User's Guide*.

2.2.6 Step 5 : Activate the new 8285 microcodes and FPGA picocode

REMINDER

This must be performed with **NO OPERATIONAL TRAFFIC** flowing in your ATM campus network. Typically, this would be scheduled as part of a maintenance period.

1. Check for all the ATM module if a new level of FPGA C31, C30 or B50 is present in operational or backup :

```
SHOW MODULE n VERBOSE
```

Where "n" is the number of the slot where the ATM module is present.

2. Activate the new version of 8285 operational microcode by entering the command:

```
CLEAR ERROR_LOG
```

```
SAVE ALL
```

```
SWAP MICROCODE and confirm with Y
```

ERROR CASE

In the case, the FPGA picocode download on the 8285 **has failed** or **has not been done**, the 8285 will first try to SWAP the microcode , then will find out that no FPGA is compatible with this operational code and finally it will SWAP back the operational code to the original level.

However, in this process you might lose your configuration. You will need, if this happens, to **DOWNLOAD** the configuration uploaded in **Step 0**, then perform **Step 3** successfully, before retrying this **Step 5** once more.

3. The telnet session, if any, is broken.
(.../...)

4.

Case 1

If the previous microcode level of the 8285 was lower than or equal to v.1.3.0:

a. The locally attached terminal displays , for example :

Terminal console display during migration

```
Migration allowed; checking for needed FPGA swaps
Some SWAP FPGA commands will be executed now...
Generated command: SWAP FPGA 2 ...Completed
Generated command: SWAP FPGA 3 ...Completed
Generated command: SWAP FPGA 1 ...
Press Enter
```

The 8285 module will enter a reset sequence that will activate operational microcode and the FPGA picocode on all the blades.

5.

Case 2

If the previous microcode level of the 8285 was v.1.4.0 or above:

- a. Login as **Administrator** on the 8285 console
- b. Perform the FPGA picocode SWAP, issue the command:

```
SWAP FPGA_PICOCODE slot1 ... slot4
```

WARNING

You must perform the FPGA SWAP for all the ATM Media blades for which you have downloaded FPGA picocode.

If the FPGA picocode B50, C31 or C30 is already present as OPERATIONAL, then the SWAP for that slot is not needed.

2.2.7 Step 6 : Check the new levels of codes :

1. Log in as the **Administrator** on the 8285 console
2. The following table lists the microcode and FPGA versions that must be displayed for the 8285 at completion of the upgrade. Use the following commands :

```
SHOW DEVICE
SHOW MODULE n VERBOSE
```

Component	Feature Code	Operational FPGA Version	Flash EEPROM Version	Boot EEPROM Version
8285	----	C30	v.1.5.2	v.1.5.2
A4-FB100 (MIC)	5004	B50	n/a	n/a
A4-FB100 (SC)	5104	B50	n/a	n/a
A2-MB155	5002	B50	n/a	n/a
A3-MB155	5003	C31	n/a	n/a
A12-TP25	5012	C30	n/a	n/a
A-CMU1	5102	B50	n/a	n/a
A-CMU2	5202	B50	n/a	n/a
A04MB-BRG	5204	B50	n/a	n/a
A2-WAN	5302	B50	n/a	n/a

2.2.8 Step 7 : Checking Network and Saving Configuration

After you complete the upgrade procedure for every 8285 ATM hub in your network, verify that your network is operational. To do this:

Check that all links are active, specifically the SSI and NNI links.

Check the connectivity between the TFTP server and each 8285 in the network using the PING command.

Once the links are up and running successfully, we recommend to upload the configuration of each 8285 in your network :

1. Setup the TFTP parameters by entering the following commands:
 - SET TFTP SERVER_IP_ADDRESS <ip address of the TFTP server>
 - SET TFTP FILE_TYPE CONFIGURATION
 - SET TFTP FILE_NAME

Provide the full path of the file when prompted

2. Start the upload inband procedure by entering:

```
UPLOAD
```

When prompted, type "Y" to confirm.

PN N.A. 20 of 21	EC N.A. 18Jun97				
---------------------	--------------------	--	--	--	--

MIGRATION COMPLETE

You have successfully completed the ATM FIRMWARE upgrade.

2.3 Upgrading a new ATM module

2.3.1 Step 8: Upgrading a new ATM module

In case you have ordered a module to be plugged in the 8285 expansion unit, this module may arrive with a non compatible level. To upgrade this module to level B50, C31 or C30 do the following :

Perform **Step 4**

Activate the FPGA picocode just downloaded by entering the command:

- SWAP FPGA PICOCODE n
- Where "n" is the number of the slot where the module is installed

MIGRATION COMPLETE

You have successfully completed the ATM media module upgrade.

2.4 After Installation

2.4.1 Publication Update

Insert the companion release note REL8285 in your publications binder.

End of Document

PN N.A. 21 of 21	EC N.A. 18Jun97				
---------------------	--------------------	--	--	--	--