

Ice Lake-LP Intel[®] Management Engine Firmware 13.0

Consumer Firmware Bring Up Guide

November 2019

| Revision 1.3

Intel Confidential



By using this document, in addition to any agreements you have with Intel, you accept the terms set forth below. You may not use or facilitate the use of this document in connection with any infringement or other legal analysis concerning Intel products described herein. You agree to grant Intel a non-exclusive, royalty-free license to any patent claim thereafter drafted which includes subject matter disclosed herein.

INFORMATION IN THIS DOCUMENT IS PROVIDED IN CONNECTION WITH Intel® PRODUCTS. NO LICENSE, EXPRESS OR IMPLIED, BY ESTOPPEL OR OTHERWISE, TO ANY INTELLECTUAL PROPERTY RIGHTS IS GRANTED BY THIS DOCUMENT. EXCEPT AS PROVIDED IN INTEL'S TERMS AND CONDITIONS OF SALE FOR SUCH PRODUCTS, INTEL ASSUMES NO LIABILITY WHATSOEVER, AND INTEL DISCLAIMS ANY EXPRESS OR IMPLIED WARRANTY, RELATING TO SALE AND/OR USE OF INTEL PRODUCTS INCLUDING LIABILITY OR WARRANTIES RELATING TO FITNESS FOR A PARTICULAR PURPOSE, MERCHANTABILITY, OR INFRINGEMENT OF ANY PATENT, COPYRIGHT OR OTHER INTELLECTUAL PROPERTY RIGHT.

A "Mission Critical Application" is any application in which failure of the Intel Product could result, directly or indirectly, in personal injury or death. SHOULD YOU PURCHASE OR USE INTEL'S PRODUCTS FOR ANY SUCH MISSION CRITICAL APPLICATION, YOU SHALL INDEMNIFY AND HOLD INTEL AND ITS SUBSIDIARIES, SUBCONTRACTORS AND AFFILIATES, AND THE DIRECTORS, OFFICERS, AND EMPLOYEES OF EACH, HARMLESS AGAINST ALL CLAIMS COSTS, DAMAGES, AND EXPENSES AND REASONABLE ATTORNEYS' FEES ARISING OUT OF, DIRECTLY OR INDIRECTLY, ANY CLAIM OF PRODUCT LIABILITY, PERSONAL INJURY, OR DEATH ARISING IN ANY WAY OUT OF SUCH MISSION CRITICAL APPLICATION, WHETHER OR NOT INTEL OR ITS SUBCONTRACTOR WAS NEGLIGENT IN THE DESIGN, MANUFACTURE, OR WARNING OF THE INTEL PRODUCT OR ANY OF ITS PARTS.

Intel may make changes to specifications and product descriptions at any time, without notice. Designers must not rely on the absence or characteristics of any features or instructions marked "reserved" or "undefined". Intel reserves these for future definition and shall have no responsibility whatsoever for conflicts or incompatibilities arising from future changes to them. The information here is subject to change without notice.

The Ice Lake Platform and Ice Lake PCH products may contain design defects or errors known as errata which may cause the product to deviate from published specifications. Current characterized errata are available on request.

Intel® AMT should be used by a knowledgeable IT administrator and requires enabled systems, software, activation, and connection to a corporate network. Intel AMT functionality on mobile systems may be limited in some situations. Your results will depend on your specific implementation. Learn more by visiting [Intel® Active Management Technology](#).

Intel® Small Business Technology (Intel® SBT) requires an Intel® Small Business Technology enabled system and proper configuration. Availability of features will depend upon the setup and configuration by your PC manufacturer. Consult your system manufacturer.

Intel® vPro™ Technology requires setup and activation by a knowledgeable IT administrator. Availability of features and results will depend upon the setup and configuration of your hardware, software and IT environment. Learn more at: <http://www.intel.com/technology/vpro>.

Any software source code reprinted in this document is furnished under a software license and may only be used or copied in accordance with the terms of that license.

64-bit computing on Intel architecture requires a computer system with a processor, chipset, BIOS, operating system, device drivers and applications enabled for Intel® 64 architecture. Processors will not operate (including 32-bit operation) without an Intel® 64 architecture-enabled BIOS. Performance will vary depending on your hardware and software configurations. Consult with your system vendor for more information.

Intel processor numbers are not a measure of performance. Processor numbers differentiate features within each processor family, not across different processor families. See http://www.intel.com/products/processor_number for details. I2C is a two-wire communications bus/protocol developed by Philips. SMBus is a subset of the I2C bus/protocol and was developed by Intel. Implementations of the I2C bus/protocol may require licenses from various entities, including Philips Electronics N.V. and North American Philips Corporation.

Microsoft*, Windows* and the Windows* logo are trademarks or registered trademarks of Microsoft Corporation in the United States and/or other countries.

Intel, Celeron, Pentium, Intel Xeon, Intel Core, Intel vPro™, and the Intel logo are trademarks of Intel Corporation in the United States and/or other countries. *Other names and brands may be claimed as the property of others.

KVM Remote Control (Keyboard, Video, Mouse) is only available with Intel® Core™ i5 vPro™ and Core™ i7 vPro™ processors with integrated graphics and Intel® Active Management technology activated. Discrete graphics are not supported.

Copyright © 2014-2019, Intel Corporation. All rights reserved.



Contents

1	Introduction	6
1.1	Related Documentation	6
1.2	Intel® ME FW Features.....	6
1.3	Prerequisites.....	6
1.4	Acronyms and Definitions	7
1.4.1	General.....	7
1.4.2	Intel® Management Engine.....	8
1.4.3	System States and Power Management	9
1.5	Reference Documents	9
1.6	Format and Notation.....	9
1.7	Kit Contents	11
1.8	External Hardware Requirements for Bring Up	18
2	Image Creation: Intel® Flash Image Tool	19
2.1	Start Intel® FIT	19
2.2	Step-by-Step Guide to Build SPI Flash Image with Intel® FIT Interface.....	19
3	Programming SPI Flash Devices and Checking Firmware Status	134
3.1	Flash Burner/Programmer	134
3.1.1	In-Circuit SPI Flash Programming for CRB.....	134
3.2	Flash Programming Tool (Intel® FPT)	134
3.2.1	Intel® FPT Windows* Version.....	135
3.3	Checking Intel® ME Firmware Status.....	136
3.4	Common Bring Up Issues and Troubleshooting Table.....	138
A	Appendix — Flash Configurations	139
B	Appendix — Intel® ICCS SKU Support Matrix	142
C	Appendix — Boot Guard Configuration	143
D	Appendix — Intel® Platform Trust Technology	145
E	Appendix — Integrated Sensor Hub (ISH) Public Key Settings	146



Figures

Tables

1-1	Number Format Notation	10
1-2	Data Format Notation	10
1-3	Kit Contents	11
2-1	- Initial Screen Layout	20
2-2	- Build Settings	29
2-3	- Flash Layout	32
2-4	- Flash Settings	37
2-5	- Intel® ME Kernel	46
2-6	- Intel® AMT	50
2-7	- Platform Protection	57
2-8	- Integrated Clock Controller	66
2-9	- Networking & Connectivity	72
2-10	- Internal PCH Buses	75
2-11	- Power	80
2-12	- Integrated Sensor Hub	82
2-13	- Camera	84
2-14	- Debug	86
2-15	- CPU Straps	91
2-16	- Flex I/O Straps	93
2-17	- GPIO	110
2-18	- Intel® Precise Touch and Stylus	127
2-19	- FW Update Image Build	128
2-20	- Intel® FIT - Build Image	133
3-1	Common Bring Up Issues and Troubleshooting Table	138



Revision History

Document Number	Revision Number	Description	Revision Date
	0.7	Initial Release: See change bars on the left side of the page.	July 2017
	0.71	See change bars on left side of the page	September 2017
	0.72	See change bars on left side of the page	October 2017
	0.73	See change bars on left side of the page	January 2018
	0.74	See change bars on left side of the page	March 2018
	0.75	See change bars on left side of the page	March 2018
	0.8	Removed PCH USB3 Type-C Connector type references they are not valid for ICL-LP	April 2018
	0.81	Added Exclusion Ranges and Descriptor Configuration settings. Updated Deep Sx Mode Configuration setting value.	June 2018
	0.82	Changed Master access values over to full Dword format. Removed SE Key Mode and VDDQ TX Rail Supply from CPU settings. Updated FW kit directory tree	September 2018
	0.9	Updated new UI screen captures	October 2018
	0.91	Changed Intel® SMLink0 MCTP Address default	November 2018
	0.92	Updated GPIO voltages RVP voltage values for GPP_A23, GPP_C11, GPP_D11, GPP_D12 and GPP_E22	November 2018
	0.93	Added IO Manageability Engine OEM configuration Binary setting Added PCH Configuration settings Added Intel FPF Anti-Rollback Configuration settings	December 2018
	1.0	Updated screen captures in Image Creation: Intel® Flash Image Tool chapter	March 2019
	1.1	Updated Platform IMON setting	July 2019
	1.2	Changed MG PHY to NPHY for Type-C Firmware Anti-Rollback Configuration	September 2019
	1.3	Corrected Deep Sx Mode Configuration setting value that got changed back to prior to Rev 0.81	November 2019

§ §



1 Introduction

This document covers the Intel® Management Engine Firmware (Intel® ME) 13.0 - Consumer Firmware bring up procedure. Intel® ME is tied to essential platform functionality — this dependency cannot be avoided for engineering reasons.

The bring up procedure primarily involves building a Serial Peripheral Interface (SPI) Flash image that will contain:

- **[required]** Descriptor region — Contains sizing information for all other SPI Flash image regions, SPI settings (including Vendor Specific Configuration - or VSCC - tables, SPI device parameters), and region access permissions.
- **[required]** BIOS region — Contains firmware for the processor (or host) and/or Embedded Controller (EC).
- **[required]** Intel® ME FW region — Contains firmware for the Intel® Management Engine.
- **[optional]** GbE region — Contains firmware for Intel LAN solution.

For more details on SPI Flash layout, see the document **Ice Lake-H / LP SPI Programming Guide** SPI Programming Guide and [Appendix A](#). Once the SPI Flash image is built, it will be programmed to the target based platform and the platform will be booted. This document also covers any tests and checks required to ensure that this boot process is successful and that Intel® ME Consumer FW is operating as expected.

1.1 Related Documentation

VIP: Kit# xxxxxx - Intel® Ethernet Network Connections (20.1 OEM Gen) - LAN Software Production Candidate 20.1

CDI # xxxxxx Intel® Ethernet Connection i2xx [TBD]

1.2 Intel® ME FW Features

This firmware release includes the following applications:

- Platform Clocks – Tune clock silicon to the parameters of a specific board, configure clocks at run time, and power management clocks. **Benefit:** Allows extensive customization and soft control of “Third generation” clock solution and makes clocks available before CPU powers up.
- Silicon Workaround Capability – Intel® ME FW will have limited capabilities to perform targeted workarounds for silicon issues. **Benefit:** Allows Intel® ME FW to address some issues that otherwise would require a new silicon stepping.

1.3 Prerequisites

Before this document is read and utilized, it is essential that the reader first review the Consumer FW Release Notes (included with this Intel® ME Consumer FW kit).



This document is constructed so that the reader can complete the bring up steps as given for the Intel Customer Reference Board (CRB). However, in the case that bring up is being performed on a different Intel® x based platform, this document will highlight any changes that must be imposed onto the bring up steps accordingly.

This document makes only the following limited assumptions regarding hardware:

- The platform is Ice Lake LP/H based
- The platform is equipped with one or more SPI Flash devices with a total capacity sufficient for storing all relevant firmware images.

1.4 Acronyms and Definitions

1.4.1 General

Acronym or Term	Definition
BIOS	Basic Input Output System
DIMM	Dual In-line Memory Module
DMI	Direct Media Interface
EC	Embedded Controller
FPF	Field Programmable Fuses
FW	Firmware
GbE	Gigabit Ethernet
HECI	Host Embedded Controller Interface (aka Intel® MEI)
Intel® ICCS	Intel® Integrated Clock Controller Service
Intel® ME	Intel® Management Engine (Intel®ME)
Intel® MEI	Intel® Management Engine Interface (Intel® MEI) (renamed from HECI)
Intel® PTT	Intel® Platform Trusted Technology (Intel® PPT)
Intel® MSS	Intel® Management and Security Status Application
KVM	Keyboard, Video, Mouse
LAN	Local Area Network
MCP	Multi-Chip Package (Central Processing Unit / Platform Controller Hub)
NVM	Non-Volatile Memory
OOB	Out-of-Band
OS	Operating System
PAVP	Protected Audio and Video Path
PCI	Peripheral Component Interconnect
PCIe*	Peripheral Component Interconnect Express
PHY	Physical Layer (Networking)
RTC	Real Time Clock
SMBus	System Management Bus
SPI Flash	Serial Peripheral Interface Flash
TPM	Trusted Platform Module
VSCC	Vendor Specific Configuration



1.4.2 Intel® Management Engine

Acronym or Term	Definition
3PDS	3rd Party Data Storage
Agent	Software that runs on a client PC with OS running
End User	The person who uses the computer (either Desktop or Mobile). In corporate, the user usually does not have administrator privileges.
Host or Host CPU	The processor that is running the operating system. This is different than the management processor running the Intel® Management Engine Firmware.
Host Service/Application	An application that is running on the host CPU
INF	An information file (.inf) used by Microsoft* operating systems that supports the Plug & Play feature. When installing a driver, this file provides the OS the necessary information about driver filenames, driver components, and supported hardware.
Intel® Management Engine Interface (Intel® MEI)	Interface between the Management Engine and the Host system
Intel® MEI driver	Intel® ME host driver that runs on the host and interfaces between ISV Agents and the Intel® ME HW.
IT User	Information Technology User. Typically very technical and uses a management console to ensure functionality of multiple PCs on a network.
LMS	Local Management Service: A SW application which runs on the host machine and provide a secured communication between the ISV agent and the Intel® Management Engine Firmware.
Intel® ME	Intel® Management Engine: The embedded processor residing in the chipset MCP
MECI	ME-VE Communication Interface
NVM	Non-Volatile Memory: A type of memory that will retain its contents even if power is removed. In the Intel® AMT current implementation, this is achieved using a FLASH memory device.
OOB Interface	Out Of Band interface: This is WSMAN interface over secure or non-secure TCP protocol.
OS not Functional	The Host OS is considered non-functional in Sx power state and any one of the following cases when system is in S0 power state: <ul style="list-style-type: none"> • OS is hung • After PCI reset • OS watch dog expires • OS is not present
System States	Operating System power states such as S0. See detailed definitions in System States and Power Management section.



1.4.3 System States and Power Management

Acronym or Term	Definition
G3	A system state of Mechanical Off where all power is disconnected from the system. G3 power state does not necessarily indicate that RTC power is removed.
CM0	Intel® Management Engine firmware power state where all hardware power planes are activated. The host power state is S0.
CM3	Intel® Management Engine power state where the host is in Sx. The processor DRAM Controller is turned off and DRAM power stays in off/self refresh mode. There is no UMA usage in CM3 state. Less than 1MB of SRAM used for code and data. Code is executed off of flash takes ~1mS.
CM0-PG	Core Well Powered; Intel® ME Well Powered; (Intel® ME core not consuming power) DRAM available.
CM3-PG	An Intel® ME Firmware power state where no power is applied to the Management Engine subsystem. (Intel® ME firmware is shut down).
OS Hibernate	System state where the OS state is saved on the hard drive.
S0	A system state where power is applied to all HW devices and the system is running normally.
S1, S2, S3	A system state where the host CPU is halted but power remains available to the memory system (memory is in self-refresh mode).
S4	A system state where the host CPU and memory are not active.
S5	A system state where all power to the host system is off, however the power cord (and/or battery in mobile designs) is still connected.
Shut Down	Equivalent to the S5 state.
Snooze Mode	Intel® Management Engine activities are mostly suspended to save power. The Intel® Management Engine monitors HW activities and can restore its activities depending on the HW event.
Standby	System state where the OS state is saved in memory and resumed from the memory when mouse/keyboard is clicked.
Sx	All S states which are different than S0.

1.5 Reference Documents

Document	Doc Number/ Location*
<i>Ice Lake Intel® Management Engine (Intel® ME) and Embedded Controller Interaction Product Specification Revision 0.5</i>	549024 / CDI
<i>Intel® Management Engine BIOS Writers Guide</i>	TBD / *
<i>Intel® Management Engine (Intel® ME) 11 SKU Firmware Consumer Compliance Guide for Ice Lake PCH-H/LP Chipset Family - Ice Lake Platform Compliancy and Testing Guide - Revision 1.1</i>	TBD / CDI

Note: * Unless specified otherwise, a document can be ordered by providing its reference number to your Intel Field Applications Engineer.

1.6 Format and Notation

The formats and notations used within this document model are those typically used by BIOS vendors. This section describes the formatting and the notations that will be followed in this document.



Table 1-1. Number Format Notation

Number Format	Notation	Example
Decimal (default)	d	14d. Note that any number without an explicit suffix can be assumed to be decimal.
Binary	b	1110b
Hex	h	0Eh
Hex	0x	0x0E

Table 1-2. Data Format Notation

Data Type	Notation	Size
Bit	b	Smallest unit, 0 or 1
Byte	B	8 bits
Word	W	16 bits or 2 bytes
Double-word	DW	32 bits or 4 bytes
Quad-word	QW	8 bytes or 4 words
Kilobyte	KB	1024 bytes
Megabit	Mb	1,048,576 bits or 128 KB
Megabyte	MB	1,048,576 bytes or 1024 KB
Gigabit	Gb	1,073,741,824 bits
Gigabyte	GB	1024 MB



1.7 Kit Contents

The Intel® ME Consumer FW kit can be downloaded from VIP (<https://platformsw.intel.com/>). The contents of this kit are detailed below (Note that only key files are listed).

Table 1-3. Kit Contents (Sheet 1 of 7)

File or [Directory]	Content Description
[root]	Root directory
Consumer CL-LP Consumer Bring Up Guide.pdf	This document
Icelake-LP Client SPI Programming Guide.pdf	How to program SPI device parameters and descriptor region details. Also contains a complete SPI Flash softstrap reference.
[Image Components]	
[3rd party Licenses in FW]	Third Party Licenses used in firmware
Apache Harmony Apache Version 2.0, January 2004 w header.txt	
Apache-Xerces-Java-XML-Parser.txt	
ConvertUTF unicode license.txt	
CxlImage license complete.txt	
HTTP Client C MIT license.txt	
Illum.org University of Illinois_NCSA.txt	
Minix 3.pdf	
MIT Kerberos for Windows.pdf	
newlib_licenses.txt	
wpa supplicant license.txt	
zlib license.txt	
[CSME]	Intel® ME firmware image (Non Production FW Rom Bypass) - supports unfused Icelake PCH-LP Platform I/O MCP steppings:
[Silicon]	<ul style="list-style-type: none"> • Unfused (Super SKU) <p>Note: For PAVP Testing, you must match Production FW with Production Part and Non Production FW with Non Production Parts.</p>
[LP]	
CSME_FW_Consumer_ICP-LP_BO_PCH.bin	Intel® ME firmware image (Non Production FW) - supports unfused Ice Lake PCH-LP Platform I/O MCP steppings:
CSME_FW_Consumer_ICP-H_AO_PCH.bin	<ul style="list-style-type: none"> • Unfused (Super SKU) <p>Note: For PAVP Testing, you must match Production FW with Production Part and Non Production FW with Non Production Parts.</p>
[Documentation]	
ICL_Intel_IOM_FW_Release_Notes_02.009.0.00.pdf	
ICL_Intel_NPhy_FW_RN_7.0.2.6.pdf	
TBT Release Notes for Burnside Bridge A-Step Rev12.0.pdf	
TBT Release Notes for YFL B Rev 28.pdf	



Table 1-3. Kit Contents (Sheet 2 of 7)

File or [Directory]	Content Description
[IOM]	IOM binary
iomp_02.009.00.bin	
[NPHY]	NPHY Binary
nphyfwpkg_7.0.2.6.bin	
[Retimer]	Retimer Binaries
BBR_CDR_A1_ICL_PORTS_0_1_rev12_sign.bin	
BBR_CDR_A1_ICL_PORTS_2_3_rev12_sign.bin	
[TBTYFL]	Thunderbolt ^(TM) binary
TBT_YFL_B0_REV28_signed.bin	
[Installers]	
Intel®_ME SW Installation Guide.pdf	Intel® CSME Software installation Guide.
[3rd party Licenses SW]	Third Party Licenses used in software
ACE-TAO-CIAO.pdf	
Apache-Xerces-C++-XML-Parser.txt	
libxml2.txt	
Microsoft Windows Classic Samples.txt	
openwsman.pdf	
Windows driver samples.txt	
WixLicenseNote.txt	
[ME_SW_MSI]	
IntelMEFWVer.dll	DLL file
MUP	XML file
SetupME	Intel® CSME software installer
[MEI-Only Installer MSI]	
IntelMEFWVer.dll	DLL file
MEI Setup	MEI software installer
MUP	XML file
[WindowsDriverPackages]	Windows* driver packages
[ICLS]	Intel® Capability Licensing Service drivers
iclsClient.cat	
iclsClient..inf	
[iCLS]	
[conf]	
cacert.pem	
epid_paramcert.dat	
epid2_paramacert.dat	
EPI DGroupCertLegacy.cer	
EPI DGroupdCertX509.cer	
iclsProxy.conf	



Table 1-3. Kit Contents (Sheet 3 of 7)

File or [Directory]	Content Description
[Documents]	Documents for Intel® Capability Licensing Service
development_tools.txt	
License.txt	
Readme.txt	
redist.txt	
Third Party Licenses.txt	
[x64]	x64 drivers
iclsClient.dll	
iclsClientInternal.dll	
iclsProxy.dll	
iclsProxyInternal.dll	
IntelPTTEKRecertification.exe	
libcrypto-1_1-x64.dll	
libssl-1_1-x64.dll	
SocketHeciServer.exe	
TPMProvisioningService.exe	
[x86]	x86 drivers
x86_iclsClient.dll	
x86_iclsClientInternal.dll	
x86_iclsProxy.dll	
x86_iclsProxyInternal.dll	
x86_IntelPTTEKRecertification.exe	
x86_libcrypto-1_1-x64.dll	
x86_libssl-1_1-x64.dll	
x86_SocketHeciServer.exe	
x86_TPMProvisioningService.exe	
[vs2015]	
[x64]	x64 Visual Studio* runtime DLLs
msvcp140.dll	
vcruntime140.dll	
[x86]	x86 Visual Studio* runtime DLLs
x86_msvc140.dll	
x86_vcruntime140.dll	
[JHI]	



Table 1-3. Kit Contents (Sheet 4 of 7)

File or [Directory]	Content Description
[win10]	Intel® Dynamic Application Loader drivers
bhPlugin.dll	
bhPluginV2.dll	
dal.cat	
DAL.inf	
JHI.dll	
jhi_service.exe	
JHI64.dll	
SpoolerApplet.dalp	
TEEManagement.dll	
TEEManagement64.dll	
TEETransport.dll	
[MEI]	Intel® MEI drivers files
heci.cat	
heci.inf	x64 driver
[x64]	
TeeDriverW8x64.sys	x86 driver
[x86]	
TeeDriverW8.sys	OEM Extension driver
OemExtension]	
OemExtension.cat	
OemExtension.inf	
[Tools]	
[3rd party Licenses in Tools]	Third part Licenses in Tools
Android Autogenerated Files Apache 2.0.pdf	
C Make License.pdf	
EFI tool kit intel BSD 2 clause license.txt	
Expat XMLparser MIT license.txt	
Jquery MIT license.txt	
JsonCpp MIT license.txt	
MSDN Example code.pdf	
pugixml license.txt	
[ICC_Tools]	
Intel® ME Firmware ICC Tools User Guide.pdf	ICC Tools User Guide
[CCT]	
cct	Exe file
cct	Ini file
cctDll.dll	
cctDllx64.dll	
cctWin	Exe file



Table 1-3. Kit Contents (Sheet 5 of 7)

File or [Directory]	Content Description
[EFI]	
cct.efi	CCT for EFI
[System Tools]	
System Tools User Guide.pdf	System Tools User Guide
[FIT]	
[system32]	
fit.exe	Intel® Flash Image Tool (Intel® FIT)
vsccommn.bin	Binary containing the supported SPI parts
VSCCommn_bin Content.pdf	Documentation listing the SPI parts supported by vsccommn.bin
[FPT]	
[EFI64]	
fparts.txt	List of supported SPI Flash devices with specific Flash parameters
fpt.efi	FPT for EFI
[Windows]	
fparts.txt	List of supported SPI Flash devices with specific Flash parameters
fptw.exe	FPT for Windows*
ldrdrv.dll	
Pmxdll.dll	
[Windows64]	
fparts.txt	List of supported SPI Flash devices with specific Flash parameters
fptw64.exe	Intel® FPT for Windows* (64-bit) OS
ldrdrv32e.dll	
Pmxdll32e.dll	
[FWUpdate]	
[EFI64]	
FWUpdLcl.efi	FW Update Tool (EFI version)
fwudef.h	
FwUpdateEfiLib.lib	
fwupdatelib.h	
fwupdatelibdeprecated.h	
[Win]	
FWUpdLcl.exe	FW Update Tool (Windows* version 32bit)
ldrdrv.dll	
Pmxdll.dll	
errorlist.c	



Table 1-3. Kit Contents (Sheet 6 of 7)

File or [Directory]	Content Description
errorlist.h	
fwudef.h	
fwupdatelib.h	
FWUpdateLib.lib	
fwupdatelibdeprecated.h	
FWUpdateSample.c	
[Win64]	
FWUpdLcl64.exe	FW Update Tool (Windows* version 64bit)
ldrdrvll32e.dll	
Pmxdll32e.dll	
errorlist.c	
errorlist.h	
fwudef.h	
fwupdatelib.h	
FWUpdateLib.lib	
fwupdatelibdeprecated.h	
FWUpdateSample.c	
[FWUpdate_RS]	FW Update Tool API code
[Efi64]	
fwUpdLcl.efi	
errorlist.c	
errorlist.h	
fwudef.h	
fwupdatelib.h	
FWUpdateLib.lib	
fwupdatelibdeprecated.h	
FWUpdateSample.c	
[MEInfo]	
[EFI64]	
MEInfo.efi	Intel® ME Information Tool (EFI version)
[Windows]	
MEInfoWin.exe	Intel® ME Information Tool (Windows* version 32bit)
ldrdrvll.dll	
Pmxdll.dll	
[Windows64]	
MEInfoWin64.exe	Intel® ME Information Tool (Windows* version 64bit)
ldrdrvll32e.dll	
Pmxdll32e.dll	



Table 1-3. Kit Contents (Sheet 7 of 7)

File or [Directory]	Content Description
[MEManuf]	
[EFI64]	
MEManuf.efi	Intel® ME Manufacturing Tool (EFI version)
[Windows]	
ldrvidll.dll	
MEManufWin.exe	Intel® ME Manufacturing Tool (Windows* version 32bit)
Pmxdll.dll	
[Windows64]	
ldrvidll32e.dll	
MEManufWin64.exe	Intel® ME Manufacturing Tool (Windows* version 64bit)
Pmxdll32e.dll	
(empty)	
[Manifest Extension Utility]	
[Win]	
Signing and Manifesting Guide.pdf	
[Windows32]	
meu.exe	Intel® Manifest Extension Utility (MEU) executable file that allows input of FW binary and outputs and independent updatable partition that is compressed and signed.

|||



1.8 External Hardware Requirements for Bring Up

Acquire the following hardware tools before moving on to the next step.

Windows* OS System	Flash Burner	DOS Bootable USB Key
		
<p>Equipment:</p> <ul style="list-style-type: none"> Laptop or desktop that supports win32 applications <p>Purpose:</p> <ul style="list-style-type: none"> Will run firmware image assembly and build process software. 	<p>Equipment:</p> <ul style="list-style-type: none"> (Optional) For platforms that don't boot, a Flash Chip Programmer will be required For platforms that can boot to DOS or Windows*, a Intel® FPT is provided in this kit <p>Purpose:</p> <ul style="list-style-type: none"> Will burn firmware images onto the target system Flash device(s). 	<p>Equipment:</p> <ul style="list-style-type: none"> A DOS Bootable USB Key (Size > 512 MB) <p>Purpose:</p> <ul style="list-style-type: none"> Acting as a bootable device and will be used to run Intel® FPT (fpt.exe) directly on the system that is undergoing Bring Up process. Or will be used to transfer a firmware image onto a Flash burner.

§ §



2 Image Creation: Intel® Flash Image Tool

Intel® Flash Image Tool (Intel® FIT) can be used to generate either a full SPI Flash binary image with Descriptor, GbE, BIOS, and Intel® ME Regions. Additionally, it can be used to create a simple image containing only the Intel® ME Region only for use with custom SPI Flash binary image assembly solutions. Use the steps shown in following sections.

After this image has been created, it will need to be burned onto the target platform's SPI Flash device(s). [Section 3, "Programming SPI Flash Devices and Checking Firmware Status"](#) later in this document provides steps to do this.

Note: The Flash Image Tool may be updated throughout the release cycles. As a general rule, please ensure you use the tools, images and other content from the same kit and refrain from using different version tools.

2.1 Start Intel® FIT

1. Invoke Intel® Flash Image Tool. Using Explorer*, navigate to **[root]\Tools\System Tools\Flash Image Tool**. Verify that the directory contents are correct (see [Section 1.7](#)). Double-click **FIT.exe**.
2. **NOTE:** In the tables below, where default settings are listed for ICL LP/H, if the value is the same one value will be listed. If there is a different default value when the program loads with either platform, both values will be listed to show the difference.

2.2 Step-by-Step Guide to Build SPI Flash Image with Intel® FIT Interface



Table 2-1. - Initial Screen Layout (Sheet 1 of 9)

#	Label	Contents
1	New	This button labeled 'New' on rollover allows opening of a new session with default values
2	Open	This button labeled 'Open' on rollover allows opening of an xml or bin file
3	Save	This button labeled 'Save' on rollover allows saving of xml file
4	Clear Console	This button labeled 'Clear Console' clears the console area (see page 23)
5	Build Settings	This button labeled 'Build Settings' brings up the build settings popup Window see (Table 2-2)
6	Build Image	This button labeled 'Build Image' on rollover allows build of the image
7	Build Image For FWUpdate	This button labeled 'Build Image For FWUpdate' allows the user to build separate firmware update binaries.



Table 2-1. - Initial Screen Layout (Sheet 2 of 9)

#	Label	Contents
8	Drop Down Selector	This drop down allows selection of platform
9	Drop Down Selector	This drop down allows selection of SKU within platform selected



Table 2-1. - Initial Screen Layout (Sheet 3 of 9)

#	Label	Contents



Table 2-1. - Initial Screen Layout (Sheet 4 of 9)

#	Label	Contents
10	Flash Layout Tab	Flash Layout which contains (see Table 2-3): <ul style="list-style-type: none"> • Descriptor Region • BIOS Region • IFWI: Intel® ME and PMC Region • EC Region • GBE Region • SubPartitions • PDR Region
11	Flash Settings Tab	Flash Settings which contains (see Table 2-4): <ul style="list-style-type: none"> • Flash Components • Host CPU/ BIOS Master Access • Intel® ME Master Access • GBE Master Access • EC Master Access • Flash Configuration • VSCC Table - VSCC Entry • BIOS Configuration • OEM and Platform IDs • FPF Configuration
12	Intel® ME Kernel Tab	Intel® ME Kernel which contains (see Table 2-5): <ul style="list-style-type: none"> • Processor • Intel® ME Firmware Update • Intel® Services Configuration • Image Identification • Firmware Diagnostics • Post Manufacturing Lock • MCTP Configuration • Intel® ME Boot Configuration • Reserved



Table 2-1. - Initial Screen Layout (Sheet 5 of 9)

#	Label	Contents
13	Intel® AMT Tab	Intel® AMT which contains (see Table 2-6): <ul style="list-style-type: none"> • Intel® AMT Configuration • KVM Configuration • Provisioning Configuration • OEM Customizable Certificates (1, 2, 3) • OEM Default Certificates (1, 2, 3, 4, 5) • Redirection Configuration • TLS Configuration
14	Platform Protection Tab	Platform Protection which contains (see Table 2-7): <ul style="list-style-type: none"> • Content Protection • Graphics uController • Hash Key Configuration for Bootguard / ISH • Exclusion Ranges • Descriptor Configuration • Boot Guard Configuration • Type-C Firmware Anti-Rollback Configuration • Intel® PTT Configuration • TPM Over SPI Bus Configuration • BIOS Guard Configuration • TXT Configuration • Crypto HW Support • Intel FPF Anti-Rollback Configuration
15	Integrated Clock Controller Tab	Integrated Clock Controller which contains (see Table 2-8): <ul style="list-style-type: none"> • Integrated Clock Controller Policies • Profiles



Table 2-1. - Initial Screen Layout (Sheet 6 of 9)

#	Label	Contents
16	Networking & Connectivity Tab	Networking & Connectivity which contains (see Table 2-9): <ul style="list-style-type: none">• Platform vPro NIC• Wired LAN Configuration• Wireless LAN Configuration• Time Sensitive Networking Configuration



Table 2-1. - Initial Screen Layout (Sheet 7 of 9)

#	Label	Contents
17	Internal PCH Buses Tab	Internal PCH Buses which contains (see Table 2-10): <ul style="list-style-type: none"> • PCH Timer Configuration • SMBus / SMLink Configuration • DMI Configuration • OPI /DMI Configuration • eSPI Configuration
18	Power Tab	Power which contains (see Table 2-11): <ul style="list-style-type: none"> • Platform Power • Deep Sx • PCH Thermal Reporting
19	Integrated Sensor Hub Tab	Integrated Sensor Hub which contains (see Table 2-12): <ul style="list-style-type: none"> • Integrated Sensor Hub • ISH Image • ISH Data
20	Camera	<ul style="list-style-type: none"> • IPU Security (see Table 2-13): • IPU Debug • IPU PHY



Table 2-1. - Initial Screen Layout (Sheet 8 of 9)

#	Label	Contents
21	Debug Tab	Debug which contains (see Table 2-14): <ul style="list-style-type: none"> • IDLM • Delayed Authentication Mode Configuration • Intel® Trace Hub Technology • Intel® ME Firmware Debugging Overrides • Direct Connection Interface Configuration • Early USB DBC over Type-A Configuration • eSPI Feature Overrides
22	CPU Straps Tab	CPU Straps which contain a detailed list of parameters (see Table 2-15) <ul style="list-style-type: none"> • CPU Straps
23	Flex I/O Tab	Flex I/O which contains (see Table 2-16): <ul style="list-style-type: none"> • Intel® RST for PCIe Configuration • PCIe Lane Reversal Configuration • PCIe Port Configuration • SATA / PCIe Combo Port Configuration • USB3 Port Configuration • USB2 Port Configuration • Type-C Subsystem Configuration • Thunderbolt Configuration • UFS Storage Configuration • Power Delivery PD Controller Configuration



Table 2-1. - Initial Screen Layout (Sheet 9 of 9)

#	Label	Contents
24	GPIO Tab	GPIO which contains (see Table 2-17): <ul style="list-style-type: none"> • LAN / GPIO Select • WLAN / GPIO Select • Platform Power / GPIO • ME Feature Pins • Touch Controller Pins • SMLink1 Pins • GPIO VCCIO Voltage Control • Thunderbolt LSx/BSSB-LS Configuration
25	Intel® Precise Touch and Stylus	Intel® Precise Touch and Stylus which contains (see Table 2-18): <ul style="list-style-type: none"> • Integrated Touch Configuration • Intel® Integrated Touch and Stylus Configuration
26	FW Update Image Build	FW Update Image Build which contains (see Table 2-19): <ul style="list-style-type: none"> • ME Image • PMC Image • OEM KM Image • IOM Image • MG Image • TBT Image • ISH Image • INUIT Image • PCHC Image
	Console Window Area	Displays opening messages, log file entries, and build activity messages



Table 2-2. - Build Settings (Sheet 1 of 3)

Click on Build Button in the top menu bar > Build Settings window pop up is displayed:

Parameter	Value	Help Text	
Output Path	\$DestDir\outimage.bin	-	1
FWUpdate Output Path	\$DestDir\FWUpdate.bin	-	2
Build FWUpdate With Full Image	No	-	3
Generate Intermediate Files	Yes	-	4
Enable Boot Guard warning me...	Yes	-	5
Enable Intel (R) Platform Trust ...	Yes	-	6
Region Order	53241	1=BIOS, 2=ME/IFWI, 3=GbE, 4=PDR, 5=EC	7
IfwiBuildVersion	0x0	32-bit value to use as the IFWI build version number	8
Intel(R) Manifest Extension Utili...		-	9
Signing Tool Path		-	10
Signing Tool	OpenSSL	-	11

Parameter	Value	Help Text	
\$WorkingDir	.	Path for environment variable \$WorkingDir	
\$SourceDir	.	Path for environment variable \$SourceDir	
\$DestDir	.	Path for environment variable \$DestDir	12
\$UserVar1	.	Path for environment variable \$UserVar1	
\$UserVar2	.	Path for environment variable \$UserVar2	
\$UserVar3	.	Path for environment variable \$UserVar3	

#	Parameter	CRB	Values
1	Output Path		Double click to the right of outimage.bin and click to get browse button to specify path and name of file to create for the build - default is outimage.bin in the same folder as Intel® FIT tool
2	FWUpdate Output Path		Double click to the right of FWUpdate.bin and click to get browse button to specify path and name of file to create for the build - default is FWUpdate.bin in the same folder as Intel® FIT tool
3	Build FWUpdate With Full Image	No	Yes/No - No is default



Table 2-2. - Build Settings (Sheet 2 of 3)

Click on Build Button in the top menu bar > Build Settings window pop up is displayed:			
4	Generate Intermediate Files	Yes	Yes/No - Yes is default
5	Enable Boot Guard warning message at build time	Yes	Yes/No - Yes is default
6	Enable Intel (R) Platform Trust Technology warning message at build time	Yes	Yes/No - Yes is default
7	Region Order	Yes	53241 - is default
8	IFWI Build Version	Yes	32-bit value to use as the IFWI build version number.
9	Intel® Manifest Extension Utility Path	Yes	Yes/No - Yes is default
10	Signing Tool Path		This determines the path where the signing tool is located.
11	Signing Tool	OpenSSL	OpenSSL
12			\$WorkingDir and \$DestDir can be left at the default '.' Click on \$SourceDir Value field and type in path where the Image Components are located for the Manageability Engine kit



Table 2-2. - Build Settings (Sheet 3 of 3)

Click on Build Button in the top menu bar> Build Settings window pop up is displayed:			
#	Parameter	CRB	Values
5	Region Order	Yes	53241 - is default
6	IFWI Build Version	Yes	0x0 is default
7			\$WorkingDir and \$DestDir can be left at the default '.' Click on \$SourceDir Value field and type in path where the Image Components are located for the Manageability Engine kit




Table 2-3. - Flash Layout (Sheet 1 of 5)

Click on Flash Layout in the left tabs menu> Descriptor Region is expanded by default:															
<p>▼ Descriptor Region 1</p> <hr style="border: 1px solid yellow;"/> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 30%;">Parameter</th> <th style="width: 30%;">Value</th> <th colspan="2"></th> </tr> </thead> <tbody> <tr> <td>OEM Section Binary</td> <td></td> <td colspan="2">This loads the OEM Sec</td> </tr> </tbody> </table>				Parameter	Value			OEM Section Binary		This loads the OEM Sec					
Parameter	Value														
OEM Section Binary		This loads the OEM Sec													
#	Parameter	Platform	Settings												
1	OEM Section Binary This loads the OEM Section binary that will be merged into the output image generated by the Intel® FIT tool.	ICL-Y ICL-U	OEM Binary (optional)												
Click on Flash Layout in the left tabs menu> BIOS Region is expanded by default:															
<p>▼ BIOS Region 2</p> <hr style="border: 1px solid yellow;"/> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 30%;">Parameter</th> <th style="width: 30%;">Value</th> <th colspan="2">Help Text</th> </tr> </thead> <tbody> <tr> <td>Length</td> <td>0</td> <td colspan="2">-</td> </tr> <tr> <td>BIOS Binary File</td> <td></td> <td colspan="2">This loads the BIOS binary that will be merged</td> </tr> </tbody> </table>				Parameter	Value	Help Text		Length	0	-		BIOS Binary File		This loads the BIOS binary that will be merged	
Parameter	Value	Help Text													
Length	0	-													
BIOS Binary File		This loads the BIOS binary that will be merged													
#	Parameter	Platform	Settings												
2	BIOS Region														
	BIOS Region - Length -This displays the length of the BIOS binary. <i>Note:</i> This value will be automatically populated by Intel® FIT during image build.														
	BIOS Binary File Navigate to path to load bios.rom file. This loads the BIOS binary that will be merged into the output image generated by the Intel® FIT tool.	ICL-Y ICL-U	biosimage.bin biosimage.bin												
Click on Flash Layout in the left tabs menu> Intel® ME Region is expanded by default:															



Table 2-3. - Flash Layout (Sheet 2 of 5)

▼ Ifwi: Intel(R) Me and Pmc Region 3			
Parameter		Value	
Intel(R) ME Binary File		This loads the Intel(R) ME binary that will b	
Major Version	0	This displays Major revision number of the	
Minor Version	0	This displays Minor revision number of the	
Hotfix Version	0	This displays Hot-Fix revision number of the	
Build Version	0	This displays Build version number of the c	
Chipset Initialization Version		This displays the current Chipset Initializati	
Chipset Initialization Binary		This loads the Chipset Initialization binary t	
ChipsetInit Override Version		This displays the version of the Chipset Init	
PMC Binary File		This loads the PMC binary that will be merg	
PMC Length	0x20000	-	
Version		-	

#	Parameter	Platform	Settings
3	IFWI Intel® ME and Pmc Region		
	Intel® CSME Binary File Navigate to your Source Directory (as specified in Table 2-2) and switch to the ME subdirectory. Choose the appropriate Intel® CSME Firmware binary image. This loads the Intel® CSME binary that will be merged into the into the output image generated by the Intel® FIT tool. Note: You may choose to build the Intel® CSME Region only. To do so, the Number of Flash Components in Flash Settings> Flash Components must be set to 0. Note: If loading meimage.bin file, check that the ME region is enabled in tool before building image.	ICL-Y ICL-U	meimage.bin meimage.bin
	Major Version - This displays Major revision number of the currently loaded Intel® CSME binary.		
	Minor Version - This displays Minor revision number of the currently loaded Intel® CSME binary.		
	Hotfix Version - This displays Hot-Fix revision number of the currently loaded Intel® CSME binary.		
	Build Version - This displays Build version number of the currently loaded Intel® CSME binary.		
	Chipset Initialization Version - This displays the current Chipset Initialization version contained in the currently loaded Intel® CSME binary.		



Table 2-3. - Flash Layout (Sheet 3 of 5)

	<p>Chipset Initialization Binary - This loads the Chipset Initialization binary that will be merged into the output image generated by the Intel® FIT. If specified, this will override the version contained in the Intel® ME binary.</p> <p>Note: When BIOS passes new Chipset Initialization settings to Intel® CSME, a Global Reset is initiated (only required on the first boot, subsequent boots will not incur a global reset). This allows for the new settings to be stored in the Intel® CSME Region and programmed into the PCH. This global reset can be avoided by loading the proper chipset initialization binary in to the Intel® CSME Region when building the image that aligns with the values in BIOS. The Chipset Initialization Binary will be included in BIOS RC package. If BIOS contains an older version of Chipset Initialization settings Intel® CSME will be updated at boot with the older settings regardless of any newer settings being present in firmware. In order to avoid this problem and the additional Global Reset customers should ensure that both BIOS and Intel® CSME are updated with same Chipset Initialization binary.</p>	ICL-Y ICL-U	Chipset.bin (Optional) Chipset.bin (Optional)															
	<p>Chipset Init Override Version - This displays the version of the Chipset Initialization Binary override if specified.</p>																	
	<p>PMC Binary File - This loads the PMC binary that will be merged into the output image generated by the Intel® FIT tool.</p>	ICL-Y ICL-U	PMC.bin PMC.bin															
	<p>PMC Length - This displays the length of the PMC binary. Note: This value will be automatically populated by Intel® FIT during image build.</p>																	
	<p>Version - This displays the version of PMC</p>																	
Click on Flash Layout in the left tabs menu> EC Region is expanded by default:																		
<p>▼ EC Region 4</p>																		
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 25%;">Parameter</th> <th style="width: 25%;">Value</th> <th style="width: 50%;">Help Text</th> </tr> </thead> <tbody> <tr> <td>Length</td> <td>0</td> <td>-</td> </tr> <tr> <td>EC Binary File</td> <td></td> <td>This loads the Embedded Controller binary used for eSPI that will</td> </tr> <tr> <td>EC Region Enable</td> <td>Disabled</td> <td>This option allows the user to enable or disable the Embedded Co</td> </tr> <tr> <td>EC Region Pointer File</td> <td></td> <td>This loads a binary containing the 16 byte value to be written in th</td> </tr> </tbody> </table>				Parameter	Value	Help Text	Length	0	-	EC Binary File		This loads the Embedded Controller binary used for eSPI that will	EC Region Enable	Disabled	This option allows the user to enable or disable the Embedded Co	EC Region Pointer File		This loads a binary containing the 16 byte value to be written in th
Parameter	Value	Help Text																
Length	0	-																
EC Binary File		This loads the Embedded Controller binary used for eSPI that will																
EC Region Enable	Disabled	This option allows the user to enable or disable the Embedded Co																
EC Region Pointer File		This loads a binary containing the 16 byte value to be written in th																
		Platform	Settings															
4	EC Region																	
	<p>EC Region - Length Note: This value will be automatically populated by Intel® FIT during image build.</p>																	
	<p>EC Binary File Navigate to path to load EC bin file. This loads the Embedded Controller binary used for eSPI that will be merged into the output image generated by the Intel® FIT tool.</p>	ICL-Y ICL-U	EC Binary EC Binary															
	<p>EC Region Enable Values: Enabled/Disabled This option allows the user to enable or disable the Embedded Controller data region.</p>	ICL-Y ICL-U	Enabled Enabled															
	<p>EC Region Pointer File This loads a binary file containing the 16 byte Embedded Controller pointer value at the start of the flash descriptor</p>	ICL-Y ICL-U	EC Pointer Binary EC Pointer Binary															



Table 2-3. - Flash Layout (Sheet 4 of 5)

Click on Flash Layout in the left tabs menu> Gbe Region is expanded by default:			
<p>▼ GbE Region 5</p>			
Parameter	Value	Help Text	
Length	0	-	
GbE Binary File		This loads the Intel(R) Integrated LAN binary that will be merged into the output image generated by the Intel® FIT tool.	
GbE Region Enable	Enabled	This option allows the user to enable or disable the Gigabit Ethernet Region.	
Image Id	0	This displays Image ID of the currently loaded Intel (R) Integrated LAN binary.	
Major Version	0	This displays Major revision number of the currently loaded Intel® Integrated LAN binary.	
Minor Version	0	This displays Minor revision number of the currently loaded Intel® Integrated LAN binary.	
#	Parameter	Platform	Settings
5	GbE Region This loads the Intel® Integrated LAN binary that will be merged into the output image generated by the Intel® FIT tool.		
	GbE Region - Length <i>Note:</i> This value will be automatically populated by Intel® FIT during image build.		
	GbE Binary File Navigate to your Source Directory (as specified in Table 2-2) and switch to the GbE subdirectory. Choose the appropriate Intel GbE LAN Firmware binary image. If not using Intel LAN then load the GbE image before disabling the region along with changing additional settings below. This loads the Intel® integrated LAN binary that will be merged into the output image generated by the Intel® FIT tool. Note: If loading gbeimage.bin file, check that the GbE region is enabled in tool before building image.	ICL-Y ICL-U	gbeimage.bin gbeimage.bin
	GbE Region Enable Values: Enabled/Disabled - This option allows the user to enable or disable the Gigabit Ethernet Region. NOTE: If choosing a configuration that does not include the GbE LAN the following settings need to be adjusted:	ICL-Y ICL-U	Enabled Enabled
	Image Id - This displays the Image ID of the currently loaded Intel® Integrated LAN binary.		
	Major Version - This displays the Major revision number of the currently loaded Intel® Integrated LAN binary.		
	Minor Version - This displays the Minor revision number of the currently loaded Intel® Integrated LAN binary.		
Click on Flash Layout in the left tabs menu> IUnit Sub-Partition is expanded by default:			
<p>▼ IUnit Sub-Partition 6</p>			
Parameter	Value	Help Text	
IUnit Binary File		This loads the IUnit binary that will be merged into the output image generated by the Intel® FIT tool.	
Length	0xA000	-	
#	Parameter	Platform	Settings



Table 2-3. - Flash Layout (Sheet 5 of 5)

6	IUNIT Sub-Partition Binary This loads the IUnit Sub Partition binary that will be merged into the output image generated by the Intel® FIT tool.	ICL-Y ICL-U	Iunit.bin (Optional) Iunit.bin (Optional)												
	Length - This displays the length of the IUNIT Sub-Partition. <i>Note:</i> This value will be automatically populated by Intel® FIT during image build.														
Click on Flash Layout in the left tabs menu> PCH Configuration Sub-Partition is expanded by default:															
▼ PCH Configuration Sub-Partition 7															
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 30%;">Parameter</th> <th style="width: 30%;">Value</th> <th style="width: 40%;">Help Text</th> </tr> </thead> <tbody> <tr> <td>PCH Configuration File</td> <td></td> <td>This loads the PCH Configuration binary that will be merged into the output image.</td> </tr> <tr> <td>Length</td> <td>0x1000</td> <td>-</td> </tr> </tbody> </table>				Parameter	Value	Help Text	PCH Configuration File		This loads the PCH Configuration binary that will be merged into the output image.	Length	0x1000	-			
Parameter	Value	Help Text													
PCH Configuration File		This loads the PCH Configuration binary that will be merged into the output image.													
Length	0x1000	-													
7	PCH Configuration Sub-Partition This loads the PCH Configuration binary that will be merged in the output image generated by the Intel® FIT tool.														
	PCH Configuration File Navigate to path to load PCHC.bin file. This loads the PCH Configuration binary.	ICL-Y ICL-U	PCHC.bin PCHC.bin												
	Length - This displays the length of the PCH Configuration Sub-Partition. <i>Note:</i> This value will be automatically populated by Intel® FIT during image build.														
Click on Flash Layout in the left tabs menu> PDR Region is expanded by default:															
▼ PDR Region 8															
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 30%;">Parameter</th> <th style="width: 30%;">Value</th> <th style="width: 40%;">Help Text</th> </tr> </thead> <tbody> <tr> <td>Length</td> <td>0</td> <td>-</td> </tr> <tr> <td>PDR Binary File</td> <td></td> <td>This loads the Platform Data region binary that will be merged into the output image.</td> </tr> <tr> <td>PDR Region Enable</td> <td>Disabled</td> <td>This option allows the user to enable or disable the PDR region.</td> </tr> </tbody> </table>				Parameter	Value	Help Text	Length	0	-	PDR Binary File		This loads the Platform Data region binary that will be merged into the output image.	PDR Region Enable	Disabled	This option allows the user to enable or disable the PDR region.
Parameter	Value	Help Text													
Length	0	-													
PDR Binary File		This loads the Platform Data region binary that will be merged into the output image.													
PDR Region Enable	Disabled	This option allows the user to enable or disable the PDR region.													
8	PDR Region - This loads the Platform Data region binary that will be merged into the output image generated by the Intel® FIT tool.														
	PDR Region - Length Region is disabled by default. Displays Region size information when Binary input file is specified.														
	PDR Binary File Navigate to path to load pdrimage.bin file if required and available.	ICL-Y ICL-U	PDR.bin (Optional) PDR.bin (Optional)												
	PDR Region Enable Values: Enabled/Disabled - This option allows the user to enable or disable the Platform Data Region. Note: If loading PDR.bin file, check that the PDR region is enabled in tool before building image.	ICL-Y ICL-U	Disabled Disabled												



Table 2-4. - Flash Settings (Sheet 1 of 9)

Click on Flash Settings in the left tabs menu> Flash Components is expanded by default:

▼ Flash Components **1**

Parameter	Value	Help Te
Number of Flash Components	1	Specifies the number of Flash components
Flash component 1 Size	16MB	This field identifies the size of the 1st Flas
Flash component 2 Size	8MB	This field identifies the size of the 2nd Flas
SPI Global Protected Range	0x0	Sets the default value of the Global Protect
SPI Idle to Deep Power Down Timeout	0x5	SPI Idle to Deep Power Down Timeout Defi
SPI Out of Order operation Enabled	Yes	When this setting is enabled priority operat
SPI Resume Hold-off Delay	8us	Specifies the time after the completion of a
SPI Max write / erase Resume to Suspend intervals	No Ceiling	This setting specifies the maximum value f
SPI Suspend / Resume Enabled	Yes	When this setting is enabled writes and era
Software Re-Binding Enabled	No	When enabled this settings will allow for S

#	Parameter	Platform	Settings
1	Flash Components		
	Number of Components Values: 0, 1, 2 - This setting configures the total number of flash components for the platform. Note: Choosing a selection of '0' part will cause the Intel® FIT tool to build an output image containing only the Intel® ME region.	ICL-Y ICL-U	1 1
	Flash component 1 Size Values: 512KB, 1MB, 2MB, 4MB, 8MB, 16MB, 32MB, 64MB - This setting determines the size of Flash component 1 for the platform image.	ICL-Y ICL-U	16MB 16MB
	Flash component 2 Size Values: 512KB, 1MB, 2MB, 4MB, 8MB, 16MB, 32MB, 64MB - This setting determines the size of Flash component 2 for the platform image. Note: This setting is only applicable when the Number of Flash Components option is set to '2'.	ICL-Y ICL-U	Greyed Out Greyed Out
	SPI Global Protected Range - This sets the default value of the Global Protected Range register in the SPI Flash Controller.	ICL-Y ICL-U	0x0 0x0
	SPI Idle to Deep Power Down Timeout - This sets SPI Idle to Deep Power Down Timeout Default Specifies the time in microseconds that the Flash Controller waits after all activity is idle before commanding the flash devices to Deep Power down, time = 2^N microseconds.	ICL-Y ICL-U	0x5 0x5
	SPI Out of Order operation Enabled - When this setting is enabled priority operations may be issued while waiting for write / erase operations to complete on the flash device. When this setting is disabled all write / erase type operations in order.	ICL-Y ICL-U	Yes Yes
	SPI Resume Hold-off Delay - This specifies the time after the completion of a pri_op before the flash controller sends the resume instruction. If a new pri_op is eligible to be issued prior to the end of this delay time then the pri_op is issued and the timer is reinitialized to tRHD. 3-bit field encodes count with range 0-7. tRHD = count * 2us.	ICL-Y ICL-U	8us 8us



Table 2-4. - Flash Settings (Sheet 3 of 9)

	<p>Host CPU / BIOS Read Access Values: 0xFFFF, 0x000F, 0x001F, 0x010F, 0x011F - This setting determines read access control for the BIOS region. 0xFFFF = Debug/Manufacturing 0x000F = Production 0x001F = Production with access to PDR (should ONLY be used if PDR region is implemented). 0x010F = Production with access to EC 0x011F = Production with access to EC and PDR Custom = User custom Host / BIOS Read Access values</p> <p>For further details on Region Access Control see Ice Lake LP SPI Programming guide.</p>	<p>ICL-Y ICL-U</p>	<p>0xFFFF 0xFFFF</p>															
	<p>Host CPU / BIOS Read Access Custom - This setting allows free form user customized Host CPU / BIOS Read Access regions permissions</p> <p>Note: This setting is grayed out unless Custom is selected under the Host CPU / BIOS Read Access Intel Recommended drop down menu.</p> <p>Warning: Setting region access permission values outside of Intel recommendation could result in compromised platform security</p>	<p>ICL-Y ICL-U</p>	<p>Hex Input</p>															
<p>Click on Flash Settings in the left tabs menu> Intel® ME Master Access is expanded by default:</p>																		
<p>▼ Intel(R) ME Master Access 3</p>																		
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 35%;">Parameter</th> <th style="width: 25%;">Value</th> <th style="width: 40%;">Help Text</th> </tr> </thead> <tbody> <tr> <td>Intel(R) ME Write Access Intel Recommended</td> <td>0xFFFF</td> <td>This setting determines read access control for the</td> </tr> <tr> <td>Intel(R) ME Write Access Custom</td> <td>0x0000</td> <td>This setting determines read access control for the</td> </tr> <tr> <td>Intel(R) ME Read Access Intel Recommended</td> <td>0xFFFF</td> <td>This setting determines read access control for the</td> </tr> <tr> <td>Intel(R) ME Read Access Custom</td> <td>0x0000</td> <td>This setting determines read access control for the</td> </tr> </tbody> </table>				Parameter	Value	Help Text	Intel(R) ME Write Access Intel Recommended	0xFFFF	This setting determines read access control for the	Intel(R) ME Write Access Custom	0x0000	This setting determines read access control for the	Intel(R) ME Read Access Intel Recommended	0xFFFF	This setting determines read access control for the	Intel(R) ME Read Access Custom	0x0000	This setting determines read access control for the
Parameter	Value	Help Text																
Intel(R) ME Write Access Intel Recommended	0xFFFF	This setting determines read access control for the																
Intel(R) ME Write Access Custom	0x0000	This setting determines read access control for the																
Intel(R) ME Read Access Intel Recommended	0xFFFF	This setting determines read access control for the																
Intel(R) ME Read Access Custom	0x0000	This setting determines read access control for the																
<p>#</p> <p>3</p>	<p>Parameter</p> <p>Intel® ME Master Access</p>	<p>Platform</p>	<p>Settings</p>															
	<p>Intel® ME Write Access Intel Recommended Values: 0xFFFF, 0x0004 - This setting determines write access control for the ME region. 0xFFFF = Debug/Manufacturing 0x0004 = Production Custom = User custom Intel® ME Write Access values</p> <p>For further details on Region Access Control see Ice Lake LP SPI Programming guide further details.</p>	<p>ICL-Y ICL-U</p>	<p>0xFFFF 0xFFFF</p>															
	<p>Intel® ME Write Access Custom - This setting allows free form user customized Intel® ME Write Access regions permissions</p> <p>Note: This setting is grayed out unless Custom is selected under the Intel® ME Write Access Intel Recommended drop down menu.</p> <p>Warning: Setting region access permission values outside of Intel recommendation could result in compromised platform security</p>	<p>ICL-Y ICL-U</p>	<p>Hex Input</p>															



Table 2-4. - Flash Settings (Sheet 4 of 9)

	<p>Intel® ME Read Access Intel Recommended Values: 0xFFFF, 0x00D - This setting determines read access control for the Intel®ME region. 0xFFFF = Debug/Manufacturing 0x000D = Production Custom = User custom Intel® ME Read Access values</p> <p>For further details on Region Access Control see Ice Lake LP SPI Programming guide further details.</p>	<p>ICL-Y ICL-U</p>	<p>0xFFFF 0xFFFF</p>															
	<p>Intel® ME Read Access Custom - This setting allows free form user customized Intel® ME Read Access regions permissions</p> <p>Note: This setting is grayed out unless Custom is selected under the Intel® ME Read Access Intel Recommended drop down menu.</p> <p>Warning: Setting region access permission values outside of Intel recommendation could result in compromised platform security</p>	<p>ICL-Y ICL-U</p>	<p>Hex Input</p>															
<p>Click on Flash Settings in the left tabs menu> GbE Master Access is expanded by default:</p>																		
<p>▼ GbE Master Access 4</p>																		
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 30%;">Parameter</th> <th style="width: 30%;">Value</th> <th style="width: 40%;">Help Text</th> </tr> </thead> <tbody> <tr> <td>GbE Write Access Intel Recommended</td> <td>0xFFFF</td> <td>This setting determines read access control for the C</td> </tr> <tr> <td>GbE Write Access Custom</td> <td>0x0000</td> <td>This setting determines read access control for the C</td> </tr> <tr> <td>GbE Read Access Intel Recommended</td> <td>0xFFFF</td> <td>This setting determines read access control for the C</td> </tr> <tr> <td>GbE Read Access Custom</td> <td>0x0000</td> <td>This setting determines read access control for the C</td> </tr> </tbody> </table>				Parameter	Value	Help Text	GbE Write Access Intel Recommended	0xFFFF	This setting determines read access control for the C	GbE Write Access Custom	0x0000	This setting determines read access control for the C	GbE Read Access Intel Recommended	0xFFFF	This setting determines read access control for the C	GbE Read Access Custom	0x0000	This setting determines read access control for the C
Parameter	Value	Help Text																
GbE Write Access Intel Recommended	0xFFFF	This setting determines read access control for the C																
GbE Write Access Custom	0x0000	This setting determines read access control for the C																
GbE Read Access Intel Recommended	0xFFFF	This setting determines read access control for the C																
GbE Read Access Custom	0x0000	This setting determines read access control for the C																
<p>#</p>	<p>Parameter</p>	<p>Platform</p>	<p>Settings</p>															
<p>4</p>	<p>GbE Master Access</p>																	
	<p>GbE Write Access Intel Recommended Values: 0xFFFF, 0x0008 - This setting determines write access control for the Gigabit Ethernet Region. 0xFFFF = Debug/Manufacturing 0x0008 = Production Custom = User custom GbE Write Access values</p> <p>For further details on Region Access Control see Ice Lake LP SPI Programming guide further details.</p>	<p>ICL-Y ICL-U</p>	<p>0xFFFF 0xFFFF</p>															
	<p>GbE Write Access Custom - This setting allows free form user customized GbE Write Access regions permissions</p> <p>Note: This setting is grayed out unless Custom is selected under the GbE Write Access Intel Recommended drop down menu.</p> <p>Warning: Setting region access permission values outside of Intel recommendation could result in compromised platform security</p>	<p>ICL-Y ICL-U</p>	<p>Hex Input</p>															



Table 2-4. - Flash Settings (Sheet 5 of 9)

	<p>GbE Read Access Intel Recommended Values: 0xFFFF, 0x0009 - This setting determines read access control for the Gigabit Ethernet Region. 0xFFFF = Debug/Manufacturing 0x0009 = Production Custom = User custom GbE Read Access values</p> <p>For further details on Region Access Control see Ice Lake LP SPI Programming guide further details.</p>	ICL-Y ICL-U	0xFFFF 0xFFFF															
	<p>GbE Read Access Custom - This setting allows free form user customized GbE Read Access regions permissions</p> <p>Note: This setting is grayed out unless Custom is selected under the GbE Read Access Intel Recommended drop down menu.</p> <p>Warning: Setting region access permission values outside of Intel recommendation could result in compromised platform security</p>	ICL-Y ICL-U	Hex Input															
Click on Flash Settings in the left tabs menu> EC Master Access is expanded by default:																		
<p>▼ EC Master Access 5</p>																		
	<table border="1"> <thead> <tr> <th>Parameter</th> <th>Value</th> <th>Help Text</th> </tr> </thead> <tbody> <tr> <td>Embedded Controller Read Access Intel Recommended</td> <td>0xFFFF</td> <td>This setting determines read access control</td> </tr> <tr> <td>Embedded Controller Read Access Custom</td> <td>0x0000</td> <td>This setting determines read access control</td> </tr> <tr> <td>Embedded Controller Write Access Intel Recommended</td> <td>0xFFFF</td> <td>This setting determines write access contro</td> </tr> <tr> <td>Embedded Controller Write Access Custom</td> <td>0x0000</td> <td>This setting determines write access contro</td> </tr> </tbody> </table>	Parameter	Value	Help Text	Embedded Controller Read Access Intel Recommended	0xFFFF	This setting determines read access control	Embedded Controller Read Access Custom	0x0000	This setting determines read access control	Embedded Controller Write Access Intel Recommended	0xFFFF	This setting determines write access contro	Embedded Controller Write Access Custom	0x0000	This setting determines write access contro		
Parameter	Value	Help Text																
Embedded Controller Read Access Intel Recommended	0xFFFF	This setting determines read access control																
Embedded Controller Read Access Custom	0x0000	This setting determines read access control																
Embedded Controller Write Access Intel Recommended	0xFFFF	This setting determines write access contro																
Embedded Controller Write Access Custom	0x0000	This setting determines write access contro																
#	Parameter	Platform	Settings															
5	EC Master Access																	
	<p>EC Write Access Intel Recommended Values: 0xFFFF, 0x0100 - This setting determines write access control for the Embedded Controller Region. 0xFFFF = Debug/Manufacturing 0x0100 = Production Custom = User custom EC Write Access values</p> <p>For further details on Region Access Control see Ice Lake LP SPI Programming guide further details.</p>	ICL-Y ICL-U	0xFFFF 0xFFFF															
	<p>EC Write Access Custom - This setting allows free form user customized EC Write Access regions permissions</p> <p>Note: This setting is grayed out unless Custom is selected under the EC Write Access Intel Recommended drop down menu.</p> <p>Warning: Setting region access permission values outside of Intel recommendation could result in compromised platform security</p>	ICL-Y ICL-U	Hex Input															



Table 2-4. - Flash Settings (Sheet 6 of 9)

	<p>EC Read Access Intel Recommended Values: 0xFFFF, 0x0101, 0x0103 - This setting determines read access control for the Embedded Controller Region. 0xFFFF = Debug/Manufacturing 0x0101 = Production 0x0103 = Production with EC BIOS Read Access Custom = User custom EC Read Access values</p> <p>For further details on Region Access Control see Ice Lake LP SPI Programming guide further details.</p>	<p>ICL-Y ICL-U</p>	<p>0xFFFF 0xFFFF</p>
	<p>EC Read Access Custom - This setting allows free form user customized EC Read Access regions permissions</p> <p>Note: This setting is grayed out unless Custom is selected under the EC Read Access Intel Recommended drop down menu.</p> <p>Warning: Setting region access permission values outside of Intel recommendation could result in compromised platform security</p>	<p>ICL-Y ICL-U</p>	<p>Hex Input</p>
<p>Click on Flash Layout in the left tabs menu> IUnit Sub-Partition is expanded by default:</p>			
<p>▼ Flash Configuration 6</p>			
Parameter	Value	Help Text	
Dual I/O Read Enable	No	This soft-strap only has effect if Dual I/O Read is discovered as suppo	
Dual Output Read Enable	No	This soft-strap only has effect if Dual Output Read is discovered as su	
Fast Read Clock Frequency	48MHz	This setting allows customers to configure the flash component clock	
Fast Read Supported	Yes	This setting allows customers to enable support for Fast Read capabil	
Invalid Instruction 0	0x21	This setting allows customers to configure invalid instruction to protec	
Invalid Instruction 1	0x42	This setting allows customers to configure invalid instruction to protec	
Invalid Instruction 2	0x60	This setting allows customers to configure invalid instruction to protec	
Invalid Instruction 3	0xAD	This setting allows customers to configure invalid instruction to protec	
Invalid Instruction 4	0xB7	This setting allows customers to configure invalid instruction to protec	
Invalid Instruction 5	0xB9	This setting allows customers to configure invalid instruction to protec	
Invalid Instruction 6	0xC4	This setting allows customers to configure invalid instruction to protec	
Invalid Instruction 7	0xC7	This setting allows customers to configure invalid instruction to protec	
Quad I/O Read Enable	No	This soft-strap only has effect if Quad I/O Read is discovered as supp	
Quad Output Read Enable	No	This soft-strap only has effect if Quad Output Read is discovered as s	
Read ID and Read Status Clock Frequency	48MHz	This setting allows customers to configure the flash component clock	
Write and Erase Clock Frequency	48MHz	This setting allows customers to configure the flash component clock	
#	Parameter	Platform	Settings
6	Flash Configuration		



Table 2-4. - Flash Settings (Sheet 7 of 9)

	Dual I/O Read Enabled Values: Yes/No - This setting allows the customer to enable support for Dual I/O Read capabilities for flash components. See Ice Lake LP SPI Programming guide for further details.	ICL-Y ICL-U	Yes Yes
	Dual Output Read Enabled Values: Yes/No - This setting allows the customer to enable support for Dual Output Read capabilities for flash components. See Ice Lake LP SPI Programming guide for further details.	ICL-Y ICL-U	Yes Yes
	Fast Read Clock Frequency Values: 17MHz, 30MHz, 48MHz - This setting allows the customer to configure the flash component clock frequency setting for Fast Read. See Ice Lake LP SPI Programming guide for further details.	ICL-Y ICL-U	48MHz 48MHz
	Fast Read Supported Values: Yes/No - This setting allows the customer to enable support for Fast Read capabilities for flash components. See Ice Lake LP SPI Programming guide for further details. Note: If fast read supported is set to "No" any changes made to Dual I/O, Quad I/O, Dual Output, or Quad Output will not be affected if set to yes. Fast read supported should also be set to enable frequencies greater than 20MHz.	ICL-Y ICL-U	Yes Yes
	Invalid Instruction 0 - This setting allows the customer to configure invalid instruction to protect against Chip Erase. See Ice Lake LP SPI Programming guide for further details. Note: This setting should be set to '0' if there are not Invalid instructions.	ICL-Y ICL-U	0x00000021 0x00000021
	Invalid Instruction 1 - This setting allows the customer to configure invalid instruction to protect against Chip Erase. See Ice Lake LP SPI Programming guide for further details. Note: This setting should be set to '0' if there are not Invalid instructions.	ICL-Y ICL-U	0x00000042 0x00000042
	Invalid Instruction 2 - This setting allows the customer to configure invalid instruction to protect against Chip Erase. See Ice Lake LP SPI Programming guide for further details. Note: This setting should be set to '0' if there are not Invalid instructions.	ICL-Y ICL-U	0x00000060 0x00000060
	Invalid Instruction 3 - This setting allows the customer to configure invalid instruction to protect against Chip Erase. See Ice Lake LP SPI Programming guide for further details. Note: This setting should be set to '0' if there are not Invalid instructions.	ICL-Y ICL-U	0x000000AD 0x000000AD
	Invalid Instruction 4 - This setting allows the customer to configure invalid instruction to protect against Chip Erase. See Ice Lake LP SPI Programming guide for further details. Note: This setting should be set to '0' if there are not Invalid instructions.	ICL-Y ICL-U	0x000000B7 0x000000B7
	Invalid Instruction 5 - This setting allows the customer to configure invalid instruction to protect against Chip Erase. See Ice Lake LP SPI Programming guide for further details. Note: This setting should be set to '0' if there are not Invalid instructions.	ICL-Y ICL-U	0x000000B9 0x000000B9
	Invalid Instruction 6 - This setting allows the customer to configure invalid instruction to protect against Chip Erase. See Ice Lake LP SPI Programming guide for further details. Note: This setting should be set to '0' if there are not Invalid instructions.	ICL-Y ICL-U	0x000000C4 0x000000C4
	Invalid Instruction 7 - This setting allows the customer to configure invalid instruction to protect against Chip Erase. See Ice Lake LP SPI Programming guide for further details. Note: This setting should be set to '0' if there are not Invalid instructions.	ICL-Y ICL-U	0x000000C7 0x000000C7
	Quad I/O Read Enabled Values: Yes/No - This setting allows the customer to enable support for Quad I/O Read capabilities for flash components. See Ice Lake LP SPI Programming guide for further details.	ICL-Y ICL-U	Yes Yes
	Quad Output Read Enabled Values: Yes/No - This setting allows the customer to enable support for Quad Output Read capabilities for flash components. See Ice Lake LP SPI Programming guide for further details.	ICL-Y ICL-U	Yes Yes
	Read ID and Read Status clock frequency Values: 17MHz, 30MHz, 48MHz - This setting allows the customer to configure the flash component clock frequency setting for Read ID and Read Status. See Ice Lake LP SPI Programming guide for further details.	ICL-Y ICL-U	48MHz 48MHz



Table 2-4. - Flash Settings (Sheet 8 of 9)

	Write and Erase clock frequency Values: 17MHz, 30MHz, 48MHz - This setting allows the customer to configure the flash component clock frequency setting for Write and Erase. See Ice Lake / Ice Lake LP SPI Programming guide for further details.	ICL-Y ICL-U	48MHz 48MHz
Click on Flash Settings in the left tabs menu> Legacy VSCC Table is expanded by default:			
▼ Legacy VSCC Table 7			
▼ VSCC Entries 8			
W25Q128BV			9 + Add VSCC Entry
Parameter	Value	Help Text	
Part Name	W25Q128BV	This setting allow the OEM input a name designation for each flash...	
Vendor ID	0xEF	This configures the JEDEC vendor specific byte ID of the SPI flash ...	
Device ID 0	0x40	This configures the JEDEC device specific byte ID 0 of the SPI flas...	
Device ID 1	0x18	This configures the JEDEC device specific byte ID 1 of the SPI flas...	
#	Parameter	Platform	Settings
7	Flash Settings - VSCC Table VSCC Entries		
	W25Q128BV		
8	VSCC Entry	ICL-Y ICL-U	
	Name - This setting allow the OEM input a name designation for each flash component being used. Note: This is a free form entry field it does not affect actual flash component operation.	ICL-Y ICL-U	Winbond Winbond
	Vendor ID - This configures the JEDEC vendor specific byte ID of the SPI flash component. See Ice Lake LP SPI Programming guide for further details.	ICL-Y ICL-U	0xEF 0xEF
	Device ID 0 - This configures the JEDEC device specific byte ID 0 of the SPI flash component. See Ice Lake LP SPI Programming guide for further details.	ICL-Y ICL-U	0x40 0x40
	Device ID 1 - This configures the JEDEC device specific byte ID 1 of the SPI flash component. See Ice Lake LP SPI Programming guide for further details.	ICL-Y ICL-U	0x18 0x18
9	+ Add VSCC Entry		
Click on Flash Settings in the left tabs menu> BIOS Configuration is expanded by default:			



Table 2-4. - Flash Settings (Sheet 9 of 9)

▼ Bios Configuration 10												
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 30%;">Parameter</th> <th style="width: 30%;">Value</th> <th style="width: 40%;">Help</th> </tr> </thead> <tbody> <tr> <td>Top Swap Block Size</td> <td>64KB</td> <td>This configures the Top Swap Block size for th</td> </tr> <tr> <td>BIOS Boot Select</td> <td>Boot from SPI</td> <td>This setting determines if BIOS will be booted</td> </tr> </tbody> </table>				Parameter	Value	Help	Top Swap Block Size	64KB	This configures the Top Swap Block size for th	BIOS Boot Select	Boot from SPI	This setting determines if BIOS will be booted
Parameter	Value	Help										
Top Swap Block Size	64KB	This configures the Top Swap Block size for th										
BIOS Boot Select	Boot from SPI	This setting determines if BIOS will be booted										
#	Parameter	Platform										
10	BIOS Configuration	ICL-Y	128KB									
	Top Swap Block Size Values: 64KB, 128KB, 256KB, 512KB, 1MB - This configures the Top Swap Block size for the platform. For further details see Ice Lake LP Platform Controller Hub EDS.	ICL-U	128KB									
	BIOS Boot Select Values: Boot from SPI / Boot from LPC This setting determines if BIOS will be booted from LPC or SPI.	ICL-Y ICL-U	Boot from SPI Boot from SPI									
Click on Flash Settings in the left tabs menu > OEM and Platform IDs												
▼ OEM and Platform IDs 11												
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 30%;">Parameter</th> <th style="width: 30%;">Value</th> <th style="width: 40%;">Help</th> </tr> </thead> <tbody> <tr> <td>OEM Vendor ID</td> <td>0x0</td> <td>This setting allows OEMs to configure their Unique</td> </tr> <tr> <td>OEM Platform ID</td> <td>0x0</td> <td>This setting allows OEMs to configure a Unique Pla</td> </tr> </tbody> </table>				Parameter	Value	Help	OEM Vendor ID	0x0	This setting allows OEMs to configure their Unique	OEM Platform ID	0x0	This setting allows OEMs to configure a Unique Pla
Parameter	Value	Help										
OEM Vendor ID	0x0	This setting allows OEMs to configure their Unique										
OEM Platform ID	0x0	This setting allows OEMs to configure a Unique Pla										
11	OEM Vendor ID - This is a free form 32bit field that allows the OEM to configure their unique Vendor identifier in the firmware image.	ICL-Y ICL-U										
	OEM Platform ID - This is a free form 32bit field that allows the OEM to configure their unique platform identifier in the firmware image.	ICL-Y ICL-U										
Click on Flash Settings in the left tabs menu> BIOS Configuration is expanded by default:												
▼ FPF Configuration 11												
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 30%;">Parameter</th> <th style="width: 30%;">Value</th> <th style="width: 40%;">H</th> </tr> </thead> <tbody> <tr> <td>FPF Hardware Binding Enabled</td> <td>Disabled</td> <td>This setting configures the FPF Hardware bi</td> </tr> </tbody> </table>				Parameter	Value	H	FPF Hardware Binding Enabled	Disabled	This setting configures the FPF Hardware bi			
Parameter	Value	H										
FPF Hardware Binding Enabled	Disabled	This setting configures the FPF Hardware bi										
12	FPF Configuration <i>Note:</i>											
	Hardware Binding Enabled Values: Enabled / Disabled This setting configures the FPF Hardware binding behavior for the platform image. If this setting is enabled FPF Hardware binding will occur when platform close manufacturing flow is executed with Intel® FPT. If this setting is disabled FPF Hardware binding will not take place when close manufacturing flow is executed. For Revenue parts this setting will be ignored and FPF Hardware binding will take place when close manufacturing flow is executed.	ICL-Y ICL-U	Disabled Disabled									



Table 2-5. - Intel® ME Kernel (Sheet 1 of 4)

Click on Intel® ME Kernel in the left tabs menu> Processor is expanded by default:

<p>▼ Processor 1</p>											
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 30%;">Parameter</th> <th style="width: 30%;">Value</th> <th colspan="2" style="width: 40%;">Help Text</th> </tr> </thead> <tbody> <tr> <td>Processor Emulation</td> <td>No Emulation</td> <td colspan="2">-</td> </tr> </tbody> </table>				Parameter	Value	Help Text		Processor Emulation	No Emulation	-	
Parameter	Value	Help Text									
Processor Emulation	No Emulation	-									
#	Parameter	Platform	Settings								
1	Processor										
	<p>Processor Emulation Values: No Emulation EMULATE Intel® vPro (TM) capable Processor EMULATE Intel® Core (TM) branded Processor EMULATE Intel® Celeron (R) branded Processor EMULATE Intel® Pentium (R) branded Processor EMULATE Intel® Xeon (R) branded Processor EMULATE Intel® Xeon (R) Manageability capable Processor</p> <p>This setting determines processor type to be emulated on pre-production silicon. Set this parameter to the type of processor that the target system will use during production. This field will emulate that processor class for pre-production silicon. It is necessary to set this to Emulate Intel® vPro™ Processor in order to enable Intel® AMT.</p>	ICL-Y ICL-U	Emulate Intel® Core™ branded Processor Emulate Intel® Core™ branded Processor								

Click on Intel® ME Kernel in the left tabs menu> Intel® ME Firmware Update is expanded by default:

<p>▼ Intel (R) ME Firmware Update 2</p>																			
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 30%;">Parameter</th> <th style="width: 30%;">Value</th> <th colspan="2" style="width: 40%;">Help Text</th> </tr> </thead> <tbody> <tr> <td>Firmware Update OEM ID</td> <td>00000000-0000-0000-0000-000...</td> <td colspan="2">-</td> </tr> <tr> <td>Hide MEBx Firmware Update ...</td> <td>No</td> <td colspan="2">-</td> </tr> <tr> <td>Intel(R) ME Region Flash Prot...</td> <td>Yes</td> <td colspan="2">-</td> </tr> </tbody> </table>				Parameter	Value	Help Text		Firmware Update OEM ID	00000000-0000-0000-0000-000...	-		Hide MEBx Firmware Update ...	No	-		Intel(R) ME Region Flash Prot...	Yes	-	
Parameter	Value	Help Text																	
Firmware Update OEM ID	00000000-0000-0000-0000-000...	-																	
Hide MEBx Firmware Update ...	No	-																	
Intel(R) ME Region Flash Prot...	Yes	-																	
#	Parameter	Platform	Settings																
2	Intel® ME Firmware Update																		
	<p>Firmware Update OEM ID - This setting allows configuration of an OEM unique ID to ensure that customers can only update their platform with images from the OEM of the platform.</p>	ICL-Y ICL-U	0 string 0 string																
	<p>Hide Intel® MEBx Firmware Update Control Values: Yes/No - This setting allows the customer to hide the Firmware Update option in the Intel®MEBx interface.</p>	ICL-Y ICL-U	No No																
	<p>Intel® ME Region Flash Protection Override Values: Yes/No - This setting enables descriptor unlock of the Intel® ME Region when the HMRFP0 message is sent to firmware prior to BIOS End of POST.</p>	ICL-Y ICL-U	Yes Yes																

Click on Intel® ME Kernel in the left tabs menu> Image Identification is expanded by default:



Table 2-5. - Intel® ME Kernel (Sheet 2 of 4)

<p>▼ Image Identification 3</p>											
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 30%;">Parameter</th> <th style="width: 30%;">Value</th> <th colspan="2" style="width: 40%;">Help Text</th> </tr> </thead> <tbody> <tr> <td>OEM Tag</td> <td>0x00000000</td> <td colspan="2">-</td> </tr> </tbody> </table>				Parameter	Value	Help Text		OEM Tag	0x00000000	-	
Parameter	Value	Help Text									
OEM Tag	0x00000000	-									
#	Parameter	Platform	Settings								
3	Image Identification										
	OEM Tag - This is a free form 32bit field that allows the OEM to configure their own unique identifier in the firmware image.	ICL-Y ICL-U	0x00000000 0x00000000								
Click on Intel® ME Kernel in the left tabs menu> Firmware Diagnostics is expanded by default:											
<p>▼ Firmware Diagnostics 4</p>											
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 30%;">Parameter</th> <th style="width: 30%;">Value</th> <th colspan="2" style="width: 40%;">Help Text</th> </tr> </thead> <tbody> <tr> <td>Automatic Built in Self Test</td> <td>Disabled</td> <td colspan="2">-</td> </tr> </tbody> </table>				Parameter	Value	Help Text		Automatic Built in Self Test	Disabled	-	
Parameter	Value	Help Text									
Automatic Built in Self Test	Disabled	-									
#	Parameter	Platform	Settings								
4	Firmware Diagnostics										
	Automatic Built in Self Test Values: Enabled/Disabled This setting enables the firmware Automatic Built in Self Test which is executed during first platform boot after initial image flashing.	ICL-Y ICL-U	Disabled Disabled								
Click on Intel® ME Kernel in the left tabs menu> Post Manufacturing Lock is expanded by default:											
<p>▼ Post Manufacturing Lock 5</p>											
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 30%;">Parameter</th> <th style="width: 30%;">Value</th> <th colspan="2" style="width: 40%;">Help Text</th> </tr> </thead> <tbody> <tr> <td>Post Manufacturing NVAR Configuration Enabled</td> <td>Yes</td> <td colspan="2">This setting determines if modifications to Cust</td> </tr> </tbody> </table>				Parameter	Value	Help Text		Post Manufacturing NVAR Configuration Enabled	Yes	This setting determines if modifications to Cust	
Parameter	Value	Help Text									
Post Manufacturing NVAR Configuration Enabled	Yes	This setting determines if modifications to Cust									
#	Parameter	Platform	Settings								
5	Post Manufacturing Lock										
	Post Manufacturing NVAR Configuration Enabled - This setting determines if modifications to Customer configurable NVARS is to be allowed after close of manufacturing.	ICL-Y ICL-U	Yes Yes								
Click on Intel® ME Kernel in the left tabs menu> MCTP Configuration is expanded by default:											



Table 2-5. - Intel® ME Kernel (Sheet 3 of 4)

▼ MCTP Configuration 6			
Parameter	Value	Help Text	
MCTP Stack Configuration	0x920030	Defines the ME's 8-bits MCTP Endpoint IDs for each SMBus physical interface (SMBus, ...	
MctpDevicePortEc	0x02	-	
MctpDevicePortSio	0x00	-	
MctpDevicePortIsh	0x00	-	
MctpDevicePortBmc	0x00	-	
#	Parameter	Platform	Settings
6	MCTP Configuration		
	MCTP Stack Configuration Defines the Intel® ME's 8-bits MCTP Endpoint ID's for each SMBus physical interface (SMBus, SMLink0, and SMLink1). These values are needed for FW to communicate with MCTP end points. For each of these 3 bytes, a value of 0x00 means not used, and values 0xFF or 0x01 - 0x07 or 0x20 - 0x2F are not allowed.	ICL-Y ICL-U	0x920030 0x920030
	MctpDevicePortEc	ICL-Y ICL-U	0x02 0x02
	MctpDevicePortSio	ICL-Y ICL-U	0x00 0x00
	MctpDevicePortIsh	ICL-Y ICL-U	0x00 0x00
	MctpDevicePortBmc	ICL-Y ICL-U	0x00 0x00
Click on Intel® ME Kernel in the left tabs menu> Intel® ME Boot Configuration is expanded by default:			
▼ Intel (R) ME Boot Configuration 7			
Parameter	Value	Help Text	
Persistent PRTC Backup Power	Exists	FPF that indicates if the device is designe	
#	Parameter	Platform	Settings
7	Intel® ME Boot Configuration		
	Persistent PRTC Backup Power Values: None / Exists FPF that indicates if the device is designed such that it may lose PRTC power more than 10 times throughout the normal life-cycle of the product and hence has no persistent time or AR protection. At EOM this value is burned to the FPF, and can never be changed	ICL-Y ICL-U	Exists Exists



Table 2-5. - Intel® ME Kernel (Sheet 4 of 4)

Click on Intel® ME Kernel in the left tabs menu> Reserved is expanded by default:

▼ Reserved **8**

Parameter	Value	Help Text	
Reserved	No	-	
8	Reserved		
	Reserved Values: Yes/No	ICL-Y ICL-U	No No



Table 2-6. - Intel® AMT (Sheet 1 of 7)

Click on Intel® AMT in the left tabs menu> Intel® AMT is expanded by default:

Intel(R) AMT Configuration 1

Parameter	Value	Help Text
Intel(R) AMT Supported	Yes	This setting allows customers to disable Intel(R) AMT on the plat...
Intel(R) ME Network Services S...	Yes	This setting allows customers to enable / disable Intel(R) ME Net...
Manageability Application Supp...	Yes	This setting allows customers to permanently disable Intel(R) AM...
Manageability Application initial...	Enabled	This setting allows customers to determine the power up state f...
Intel(R) AMT Idle Timeout	0xFFFF	This setting configures the idle timeout value before Intel(R) AM...
Intel(R) AMT Watchdog Autom...	No	This setting allows customers to enable the Intel (R) ME firmwar...

#	Parameter	Platform	Settings
1	Intel® AMT Configuration		
	Intel® AMT Supported Values: Yes/No - This setting allows customers to disable Intel® AMT on the platform and force the platform into Standard Manageability mode. Note: If this setting has been set to disabled Intel® AMT cannot be re-enabled once the descriptor has been locked.	ICL-Y ICL-U	No No No
	Intel® ME Network Services Supported Values: Yes/No - This setting allows customers to enable / disable Intel® ME Network Services on the platform. Note: This setting and TLS needs to be enabled for proper operation of Intel® Authenticate (Corporate Only). In addition if this setting is disabled Intel® AMT will also be disabled.	ICL-Y ICL-U	No No No
	Intel® Manageability Application Supported Values: Yes/No - This setting allows customers to force Intel® AMT enabled platforms to operate in Standard Manageability mode. Note: This setting only applies to Desktop and Workstation platforms.	ICL-Y ICL-U	No No No
	Manageability Application initial power-up state Values: Enabled/Disabled This setting allows customers to determine the power up state for Intel® AMT or Standard Manageability. Note: If this setting is disabled Intel® AMT or Standard Manageability can still be re-enabled through the Intel® MEBx interface.	ICL-Y ICL-U	Disabled Disabled Disabled
	Intel® AMT Idle Timeout Values: 0xFFFF - This setting configures the idle timeout value before Intel® AMT enters into an off state.	ICL-Y ICL-U	0xFFFF 0xFFFF
	Intel® AMT Watchdog Automatic Reset Enabled Values: Yes/No - This setting allows customers to enable the Intel® ME firmware to trigger an automatic platform reset if either the MEI or Agent Presence are in a hung state. Note: This feature only allows one reset at a time when the watchdog expires. After this feature has triggered a reset, it must be re-armed for reuse via management console.	ICL-Y ICL-U	No No No

Click on Intel® AMT in the left tabs menu> KVM Configuration is expanded by default:

KVM Configuration 2

Parameter	Value	Help Text
Firmware KVM Screen Blanking	No	-
KVM Redirection Supported	Yes	-



Table 2-6. - Intel® AMT (Sheet 2 of 7)

#	Parameter	Platform	Settings												
2	KVM Configuration														
	Firmware KVM Screen Blanking Values: Yes/No - This setting enables KVM Screen blanking capabilities in the firmware image. Note: This feature is dependent on processor level support.	ICL-Y ICL-U	No No												
	KVM Redirection Supported Values: Yes/No - This setting allows OEMs to enable / disable the KVM Redirection capabilities of the firmware. Note: If this setting has been set to disabled it cannot be re-enabled once the descriptor has been locked.	ICL-Y ICL-U	No No												
Click on Intel® AMT in the left tabs menu> Provisioning Configuration is expanded by default:															
▼ Provisioning Configuration 3															
<table border="1"> <thead> <tr> <th>Parameter</th> <th>Value</th> <th>Help Text</th> </tr> </thead> <tbody> <tr> <td>Embedded Host Based Config...</td> <td>No</td> <td>-</td> </tr> <tr> <td>PKI Domain Name Suffix</td> <td></td> <td>-</td> </tr> </tbody> </table>				Parameter	Value	Help Text	Embedded Host Based Config...	No	-	PKI Domain Name Suffix		-			
Parameter	Value	Help Text													
Embedded Host Based Config...	No	-													
PKI Domain Name Suffix		-													
#	Parameter	Platform	Settings												
3	Provisioning Configuration														
	Embedded Host Based Configuration Values: Yes/No - This setting allows customers to enable / disable Embedded Host Based Configuration. Important - EHBC is primarily intended for use in embedded systems as it offers less user privacy/security protection than may be appropriate for business client systems. Note: The Intel® FIT tool will not adjust the Redirection Privacy/Security value based on selection here. Please set security level as needed.	ICL-Y ICL-U	No No												
	PKI Domain Name Suffix - This setting allow OEMs to pre-configure the Domain Name Suffix used for PKI provisioning in their firmware image. Note: For normal out-of-box provisioning functionality this setting should be left empty.	ICL-Y ICL-U	- -												
Click on Intel® AMT in the left tabs menu> OEM Customizable Certificate 1 is expanded by default:															
▼ OEM Customizable Certificate 1 4															
<table border="1"> <thead> <tr> <th>Parameter</th> <th>Value</th> <th>Help Text</th> </tr> </thead> <tbody> <tr> <td>Certificate Enabled</td> <td>No</td> <td>This setting allows customers to enable PKI provisioning Custo...</td> </tr> <tr> <td>Certificate Friendly Name</td> <td></td> <td>This setting allows customers to assign a user friendly name for...</td> </tr> <tr> <td>Certificate Stream</td> <td></td> <td>This setting allows customers to input hash stream for PKI provi...</td> </tr> </tbody> </table>				Parameter	Value	Help Text	Certificate Enabled	No	This setting allows customers to enable PKI provisioning Custo...	Certificate Friendly Name		This setting allows customers to assign a user friendly name for...	Certificate Stream		This setting allows customers to input hash stream for PKI provi...
Parameter	Value	Help Text													
Certificate Enabled	No	This setting allows customers to enable PKI provisioning Custo...													
Certificate Friendly Name		This setting allows customers to assign a user friendly name for...													
Certificate Stream		This setting allows customers to input hash stream for PKI provi...													
#	Parameter	Platform	Settings												
4	OEM Customizable Certificate 1														
	Certificate Enabled Values: Yes/No - This setting allows customers to enable PKI provisioning Custom Certificate 1.	ICL-Y ICL-U	No No												



Table 2-6. - Intel® AMT (Sheet 3 of 7)

	Certificate Friendly Name - This setting allows customers to assign a user friendly name for PKI provisioning Custom Certificate 1. Maximum of 32 characters.	ICL-Y ICL-U	- -												
	Certificate Stream - This setting allows customers to input hash stream for PKI provisioning Custom Certificate 1. If enabled the certificate will be used in addition to those already pre-loaded in base firmware during provisioning. Note: If the platform is un-configured the Custom Certificate Hash will be deleted.	ICL-Y ICL-U	- -												
Click on Intel® AMT in the left tabs menu> OEM Customizable Certificate 2 is expanded by default:															
<div style="display: flex; align-items: center;"> ▼ OEM Customizable Certificate 2 5 </div> <table border="1" style="width: 100%; border-collapse: collapse; margin-top: 10px;"> <thead> <tr> <th style="width: 30%;">Parameter</th> <th style="width: 20%;">Value</th> <th style="width: 50%;">Help Text</th> </tr> </thead> <tbody> <tr> <td>Certificate Enabled</td> <td>No</td> <td>This setting allows customers to enable PKI provisioning Custo...</td> </tr> <tr> <td>Certificate Friendly Name</td> <td></td> <td>This setting allows customers to assign a user friendly name for...</td> </tr> <tr> <td>Certificate Stream</td> <td></td> <td>This setting allows customers to input hash stream for PKI provi...</td> </tr> </tbody> </table>				Parameter	Value	Help Text	Certificate Enabled	No	This setting allows customers to enable PKI provisioning Custo...	Certificate Friendly Name		This setting allows customers to assign a user friendly name for...	Certificate Stream		This setting allows customers to input hash stream for PKI provi...
Parameter	Value	Help Text													
Certificate Enabled	No	This setting allows customers to enable PKI provisioning Custo...													
Certificate Friendly Name		This setting allows customers to assign a user friendly name for...													
Certificate Stream		This setting allows customers to input hash stream for PKI provi...													
#	Parameter	Platform	Settings												
5	OEM Customizable Certificate 2														
	Certificate Enabled Values: Yes/No - This setting allows customers to enable PKI provisioning Custom Certificate 2.	ICL-Y ICL-U	No No												
	Certificate Friendly Name - This setting allows customers to assign a user friendly name for PKI provisioning Custom Certificate 2. Maximum of 32 characters.	ICL-Y ICL-U	- -												
	Certificate Stream - This setting allows customers to input hash stream for PKI provisioning Custom Certificate 2. If enabled the certificate will be used in addition to those already pre-loaded in base firmware during provisioning. Note: If the platform is un-configured the Custom Certificate Hash will be deleted.	ICL-Y ICL-U	- -												
Click on Intel® AMT in the left tabs menu> OEM Customizable Certificate 3 is expanded by default:															
<div style="display: flex; align-items: center;"> ▼ OEM Customizable Certificate 3 6 </div> <table border="1" style="width: 100%; border-collapse: collapse; margin-top: 10px;"> <thead> <tr> <th style="width: 30%;">Parameter</th> <th style="width: 20%;">Value</th> <th style="width: 50%;">Help Text</th> </tr> </thead> <tbody> <tr> <td>Certificate Enabled</td> <td>No</td> <td>This setting allows customers to enable PKI provisioning Custo...</td> </tr> <tr> <td>Certificate Friendly Name</td> <td></td> <td>This setting allows customers to assign a user friendly name for...</td> </tr> <tr> <td>Certificate Stream</td> <td></td> <td>This setting allows customers to input hash stream for PKI provi...</td> </tr> </tbody> </table>				Parameter	Value	Help Text	Certificate Enabled	No	This setting allows customers to enable PKI provisioning Custo...	Certificate Friendly Name		This setting allows customers to assign a user friendly name for...	Certificate Stream		This setting allows customers to input hash stream for PKI provi...
Parameter	Value	Help Text													
Certificate Enabled	No	This setting allows customers to enable PKI provisioning Custo...													
Certificate Friendly Name		This setting allows customers to assign a user friendly name for...													
Certificate Stream		This setting allows customers to input hash stream for PKI provi...													
#	Parameter	Platform	Settings												
6	OEM Customizable Certificate 3														
	Certificate Enabled Values: Yes/No - This setting allows customers to enable PKI provisioning Custom Certificate 3.	ICL-Y ICL-U	No No												
	Certificate Friendly Name - This setting allows customers to assign a user friendly name for PKI provisioning Custom Certificate 3. Maximum 32 characters.	ICL-Y ICL-U	- -												
	Certificate Stream - This setting allows customers to input hash stream for PKI provisioning Custom Certificate 3. If enabled the certificate will be used in addition to those already pre-loaded in base firmware during provisioning. Note: If the platform is un-configured the Custom Certificate Hash will be deleted.	ICL-Y ICL-U	- -												



Table 2-6. - Intel® AMT (Sheet 4 of 7)

Click on Intel® AMT in the left tabs menu> OEM Default Certificate 1 is expanded by default:															
<div style="display: flex; align-items: center;"> ▼ OEM Default Certificate 1 7 </div>															
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 30%;">Parameter</th> <th style="width: 20%;">Value</th> <th style="width: 50%;">Help Text</th> </tr> </thead> <tbody> <tr> <td>Certificate Enabled</td> <td>No</td> <td>This setting allows customers to enable PKI provisioning Default...</td> </tr> <tr> <td>Certificate Friendly Name</td> <td></td> <td>This setting allows customers to assign a user friendly name for...</td> </tr> <tr> <td>Certificate Stream</td> <td></td> <td>This setting allows customers to input hash stream for PKI provi...</td> </tr> </tbody> </table>				Parameter	Value	Help Text	Certificate Enabled	No	This setting allows customers to enable PKI provisioning Default...	Certificate Friendly Name		This setting allows customers to assign a user friendly name for...	Certificate Stream		This setting allows customers to input hash stream for PKI provi...
Parameter	Value	Help Text													
Certificate Enabled	No	This setting allows customers to enable PKI provisioning Default...													
Certificate Friendly Name		This setting allows customers to assign a user friendly name for...													
Certificate Stream		This setting allows customers to input hash stream for PKI provi...													
#	Parameter	Platform	Settings												
7	OEM Default Certificate 1														
	Certificate Enabled Values: Yes/No - This setting allows customers to enable PKI provisioning Default certificate 1.	ICL-Y ICL-U	No No												
	Certificate Friendly Name - This setting allows customers to assign a user friendly name for PKI provisioning Default Certificate 1. Maximum 32 characters.	ICL-Y ICL-U	- -												
	Certificate Stream - This setting allows customers to input hash stream for PKI provisioning custom certificate 1. Note: Default Certificates if enabled will be used in addition to those already pre-loaded in firmware during provisioning. Unlike Customizable Certificates the Default Certificates are not deleted when the platform is un-provisioned.	ICL-Y ICL-U	- -												
Click on Intel® AMT in the left tabs menu> OEM Default Certificate 2 is expanded by default:															
<div style="display: flex; align-items: center;"> ▼ OEM Default Certificate 2 8 </div>															
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 30%;">Parameter</th> <th style="width: 20%;">Value</th> <th style="width: 50%;">Help Text</th> </tr> </thead> <tbody> <tr> <td>Certificate Enabled</td> <td>No</td> <td>This setting allows customers to enable PKI provisioning Default...</td> </tr> <tr> <td>Certificate Friendly Name</td> <td></td> <td>This setting allows customers to assign a user friendly name for...</td> </tr> <tr> <td>Certificate Stream</td> <td></td> <td>This setting allows customers to input hash stream for PKI provi...</td> </tr> </tbody> </table>				Parameter	Value	Help Text	Certificate Enabled	No	This setting allows customers to enable PKI provisioning Default...	Certificate Friendly Name		This setting allows customers to assign a user friendly name for...	Certificate Stream		This setting allows customers to input hash stream for PKI provi...
Parameter	Value	Help Text													
Certificate Enabled	No	This setting allows customers to enable PKI provisioning Default...													
Certificate Friendly Name		This setting allows customers to assign a user friendly name for...													
Certificate Stream		This setting allows customers to input hash stream for PKI provi...													
#	Parameter	Platform	Settings												
8	OEM Default Certificate 2														
	Certificate Enabled Values: Yes/No - This setting allows customers to enable PKI provisioning Default certificate 2.	ICL-Y ICL-U	No No												
	Certificate Friendly Name - This setting allows customers to assign a user friendly name for PKI provisioning Default Certificate 2. Maximum 32 characters.	ICL-Y ICL-U	- -												
	Certificate Stream - This setting allows customers to input hash stream for PKI provisioning custom certificate 2. Note: Default Certificates if enabled will be used in addition to those already pre-loaded in firmware during provisioning. Unlike Customizable Certificates the Default Certificates are not deleted when the platform is un-provisioned.	ICL-Y ICL-U	- -												
Click on Intel® AMT in the left tabs menu> OEM Default Certificate 3 is expanded by default:															



Table 2-6. - Intel® AMT (Sheet 5 of 7)

▼ OEM Default Certificate 3 9			
Parameter	Value	Help Text	
Certificate Enabled	No	This setting allows customers to enable PKI provisioning Default...	
Certificate Friendly Name		This setting allows customers to assign a user friendly name for...	
Certificate Stream		This setting allows customers to input hash stream for PKI provi...	
#	Parameter	Platform	Settings
9	OEM Default Certificate 3		
	Certificate Enabled Values: Yes/No - This setting allows customers to enable PKI provisioning Default certificate 3.	ICL-Y ICL-U	No No
	Certificate Friendly Name - This setting allows customers to assign a user friendly name for PKI provisioning Default Certificate 3. Maximum 32 characters.	ICL-Y ICL-U	- -
	Certificate Stream - This setting allows customers to input hash stream for PKI provisioning custom certificate 3. Note: Default Certificates if enabled will be used in addition to those already pre-loaded in firmware during provisioning. Unlike Customizable Certificates the Default Certificates are not deleted when the platform is un-provisioned.	ICL-Y ICL-U	- -
Click on Intel® AMT in the left tabs menu> OEM Default Certificate 4 is expanded by default:			
▼ OEM Default Certificate 4 10			
Parameter	Value	Help Text	
Certificate Enabled	No	This setting allows customers to enable PKI provisioning Default...	
Certificate Friendly Name		This setting allows customers to assign a user friendly name for...	
Certificate Stream		This setting allows customers to input hash stream for PKI provi...	
#	Parameter	Platform	Settings
10	OEM Default Certificate 4		
	Certificate Enabled Values: Yes/No - This setting allows customers to enable PKI provisioning Default certificate 4.	ICL-Y ICL-U	No No
	Certificate Friendly Name - This setting allows customers to assign a user friendly name for PKI provisioning Default Certificate 4.	ICL-Y ICL-U	- -
	Certificate Stream - This setting allows customers to input hash stream for PKI provisioning custom certificate 4. Note: Default Certificates if enabled will be used in addition to those already pre-loaded in firmware during provisioning. Unlike Customizable Certificates the Default Certificates are not deleted when the platform is un-provisioned.	ICL-Y ICL-U	- -
Click on Intel® AMT in the left tabs menu> OEM Default Certificate 5 is expanded by default:			



Table 2-6. - Intel® AMT (Sheet 6 of 7)

<p>▼ OEM Default Certificate 5 11</p>															
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 25%;">Parameter</th> <th style="width: 25%;">Value</th> <th style="width: 50%;">Help Text</th> </tr> </thead> <tbody> <tr> <td>Certificate Enabled</td> <td>No</td> <td>This setting allows customers to enable PKI provisioning Default...</td> </tr> <tr> <td>Certificate Friendly Name</td> <td></td> <td>This setting allows customers to assign a user friendly name for...</td> </tr> <tr> <td>Certificate Stream</td> <td></td> <td>This setting allows customers to input hash stream for PKI provi...</td> </tr> </tbody> </table>				Parameter	Value	Help Text	Certificate Enabled	No	This setting allows customers to enable PKI provisioning Default...	Certificate Friendly Name		This setting allows customers to assign a user friendly name for...	Certificate Stream		This setting allows customers to input hash stream for PKI provi...
Parameter	Value	Help Text													
Certificate Enabled	No	This setting allows customers to enable PKI provisioning Default...													
Certificate Friendly Name		This setting allows customers to assign a user friendly name for...													
Certificate Stream		This setting allows customers to input hash stream for PKI provi...													
#	Parameter	Platform	Settings												
11	OEM Default Certificate 5														
	Certificate Enabled Values: Yes/No - This setting allows customers to enable PKI provisioning Default certificate 5.	ICL-Y ICL-U	No No												
	Certificate Friendly Name - This setting allows customers to assign a user friendly name for PKI provisioning Default Certificate 5.	ICL-Y ICL-U	- -												
	Certificate Stream - This setting allows customers to input hash stream for PKI provisioning custom certificate 5. Note: Default Certificates if enabled will be used in addition to those already pre-loaded in firmware during provisioning. Unlike Customizable Certificates the Default Certificates are not deleted when the platform is un-provisioned.	ICL-Y ICL-U	- -												
<p>Click on Intel® AMT in the left tabs menu> Redirection Configuration is expanded by default:</p>															
<p>▼ Redirection Configuration 12</p>															
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 25%;">Parameter</th> <th style="width: 25%;">Value</th> <th style="width: 50%;">Help Text</th> </tr> </thead> <tbody> <tr> <td>Redirection Localized Language</td> <td>English</td> <td>This setting allows customers to configure which localized langu...</td> </tr> <tr> <td>Redirection Privacy / Security ...</td> <td>Default</td> <td>This setting allows customers to configure the Privacy and Secu...</td> </tr> </tbody> </table>				Parameter	Value	Help Text	Redirection Localized Language	English	This setting allows customers to configure which localized langu...	Redirection Privacy / Security ...	Default	This setting allows customers to configure the Privacy and Secu...			
Parameter	Value	Help Text													
Redirection Localized Language	English	This setting allows customers to configure which localized langu...													
Redirection Privacy / Security ...	Default	This setting allows customers to configure the Privacy and Secu...													
#	Parameter	Platform	Settings												
12	Redirection Configuration														
	Redirection Localized Language - This setting allows customers to configure which localized language will be used initially by firmware for user consent output information (Examples: May be displayed before SOL / KVM session starts).	ICL-Y ICL-U	English English												
	Redirection Privacy / Security Level - This setting allows customers to configure the Privacy and Security level for redirection operations. Default enables all redirection ports (User consent is configurable). Enhanced - Enables all redirection ports. (User consent is required and cannot be disabled). Extreme - Disables Redirection and Remote Configuration / Client Control Mode. Note: The Intel® FIT tool will not adjust the Embedded Host Based Configuration value based on selection here. Please set EHBC to yes or no as needed.	ICL-Y ICL-U	Default Default												
<p>Click on Intel® AMT in the left tabs menu> TLS Configuration is expanded by default:</p>															



Table 2-6. - Intel® AMT (Sheet 7 of 7)

▼ TLS Configuration 13			
Parameter		Value	Help Text
Transport Layer Security Supp...		Yes	This setting allows customers to enable / disable firmware Trans...
#	Parameter	Platform	Settings
13	TLS Configuration		
	Transport Layer Security Supported Values: Yes/No - This setting allows customers to enable / disable firmware Transport Layer Security support. Note: If this is disabled TLS will be permanently disabled in the firmware image. This setting needs to be enabled along with along with the Intel® ME Network Services Supported for proper operation of the Intel® Authenticate (Corporate Only) feature.	ICL-Y ICL-U	Yes Yes



Table 2-7. - Platform Protection (Sheet 1 of 9)

Click on Platform Protection in the left tabs menu> Content Protection is expanded by default:			
<p>▼ Content Protection 1</p>			
Parameter	Value	Help	
PAVP Supported	Yes	This setting determines if the Protected Au	
HDCP Internal Display Port 1 - 5K	PortA	This setting determines which port is conr	
HDCP Internal Display Port 2 - 5K	None	This setting determines which port is conr	
#	Parameter	Platform	Settings
1	Content Protection		
	PAVP Supported Values: Yes/No This setting determines if the Protected Audio Video Path (PAVP) feature will be permanently disabled in the FW image.	ICL-Y ICL-U	Yes Yes
	HDCP Internal Display Port 1 - 5K Values: None, Port A, Port B, Port C, Port D This setting determines which port is connected for 5K output on the Internal Display 1. Note: Both Display Port 1 & 2 need to be configured for proper operation.	ICL-Y ICL-U	None None
	HDCP Internal Display Port 2 - 5K Values: None, Port A, Port B, Port C, Port D This setting determines which port is connected for 5K output on the Internal Display 2. Note: Both Display Port 1 & 2 need to be configured for proper operation.	ICL-Y ICL-U	None None
Click on Platform Protection in the left tabs menu> Graphics uController is expanded by default:			
<p>▼ Graphics uController 2</p>			
Parameter	Value	Help	
GuC Encryption Key	00 00 00 00 00 00 00 00 00 00 ...	This option is for entering the raw ha:	
#	Parameter	Platform	Settings
2	Graphics UController		
	GuC Encryption Key Values: This option is for entering the raw hash 256 bit string or certificate file for the Graphics uController.	ICL-Y ICL-U	0x00000000 0x00000000
Click on Platform Protection in the left tabs menu> Hash Key Configuration for Bootguard / ISH is expanded by default:			



Table 2-7. - Platform Protection (Sheet 2 of 9)

▼ Hash Key Configuration for Bootguard / ISH 3			
Parameter		Value	
OEM Public Key Hash		00 00 00 00 00 00 00 00 00 00 ...	Raw hash string for the SHA-256 has
OEM Key Manifest Binary			Signed manifest file containing hashe
#	Parameter	Platform	
3	Hash Key Configuration for Bootguard / ISH		
	OEM Public Key Hash Values: This option is for entering the raw hash string or certificate file for Boot Guard and ISH. This 256-bit field represents the SHA-256 hash of the OEM public key corresponding to the private key used to sign the BIOS-SM or ISH image. Please see Appendix F for further details.	ICL-Y ICL-U	0x00000000 0x00000000
	OEM Key Manifest Binary Signed manifest file containing hashes of keys used for signing components of image. This setting is only configurable when OEM signing is enabled (See PlatformIntegrity / OemPublicKeyHash).	ICL-Y ICL-U	
Click on Platform Protection in the left tabs menu> Exclusion Ranges is expanded by default:			



Table 2-7. - Platform Protection (Sheet 3 of 9)

▼ Exclusion Ranges 4			
	Parameter	Value	Help
	Range 1 offset	0x800	Range 1 offset covers manifest, cannot be change
	Range 1 size	0x400	Range 1 size covers manifest, cannot be change
	Range 2 offset	0x80	Range 2 offset covers OEM defined unprotected
	Range 2 size	0x20	Range 2 size covers OEM defined unprotected ra
	Range 3 offset	0x0	Range 3 offset covers OEM defined unprotected
	Range 3 size	0x0	Range 3 size covers OEM defined unprotected ra
	Range 4 offset	0x0	Range 4 offset covers OEM defined unprotected
	Range 4 size	0x0	Range 4 size covers OEM defined unprotected ra
	Range 5 offset	0x0	Range 5 offset covers OEM defined unprotected
	Range 5 size	0x0	Range 5 size covers OEM defined unprotected ra
	Range 6 offset	0x0	Range 6 offset covers OEM defined unprotected
	Range 6 size	0x0	Range 6 size covers OEM defined unprotected ra
	Range 7 offset	0x0	Range 7 offset covers OEM defined unprotected
	Range 7 size	0x0	Range 7 size covers OEM defined unprotected ra
	Range 8 offset	0x0	Range 8 offset covers OEM defined unprotected
	Range 8 size	0x0	Range 8 size covers OEM defined unprotected ra

#	Parameter	Platform	
4	Exclusion Ranges <i>Note:</i> The values for Range 1 and 2 are automatically populated and not user configurable. The remaining Range 3-8 values are configurable by the OEM to allow for unprotected ranges not covered by the descriptor signature these settings are only configurable when Flash Descriptor Verification Enabled setting is configured to "Yes".		
	Range 1 offset	ICL-Y	0x800
		ICL-U	0x800
	Range 1 size	ICL-Y	0x400
		ICL-U	0x400
	Range 2 offset	ICL-Y	0x80
		ICL-U	0x80
	Range 2 size	ICL-Y	0x20
		ICL-U	0x20
	Range 3 offset	ICL-Y	0x0
	Values: This offset covers Range 3 OEM defined unprotected range start	ICL-U	0x0
	Range 3 size	ICL-Y	0x0
	Values: This offset covers Range 3 OEM defined unprotected range length	ICL-U	0x0
	Range 4 offset	ICL-Y	0x0
	Values: This offset covers Range 4 OEM defined unprotected range start	ICL-U	0x0



Table 2-7. - Platform Protection (Sheet 4 of 9)

	Range 4 size Values: This offset covers Range 4 OEM defined unprotected range length	ICL-Y ICL-U	0x0 0x0
	Range 5 offset Values: This offset covers Range 5 OEM defined unprotected range start	ICL-Y ICL-U	0x0 0x0
	Range 5 size Values: This offset covers Range 5 OEM defined unprotected range length	ICL-Y ICL-U	0x0 0x0
	Range 6 offset Values: This offset covers Range 6 OEM defined unprotected range start	ICL-Y ICL-U	0x0 0x0
	Range 6 size Values: This offset covers Range 6 OEM defined unprotected range length	ICL-Y ICL-U	0x0 0x0
	Range 7 offset Values: This offset covers Range 7 OEM defined unprotected range start	ICL-Y ICL-U	0x0 0x0
	Range 7 size Values: This offset covers Range 7 OEM defined unprotected range length	ICL-Y ICL-U	0x0 0x0
	Range 8 offset Values: This offset covers Range 8 OEM defined unprotected range start	ICL-Y ICL-U	0x0 0x0
	Range 8 size Values: This offset covers Range 8 OEM defined unprotected range length	ICL-Y ICL-U	0x0 0x0
Click on Platform Protection in the left tabs menu> Descriptor Configuration is expanded by default:			
<div style="display: flex; align-items: center;"> ▼ Descriptor Configuration 5 </div>			
	Parameter	Value	Help
	Flash Descriptor Verification En...	No	-
	Descriptor Signing Key		This is the path to the private key used to sign th
	exclude master access in the si...	Yes	include/exclude master access in the signature.
#	Parameter	Platform	
5	Descriptor Configuration		
	Flash Descriptor Verification Enabled Value: Yes/No This settings enables / disables Flash Descriptor verification.	ICL-Y ICL-U	No No
	Descriptor Signing Key This is the path to the private key used to sign the Descriptor, while public key hash of it is included in the OEM hash manifest. This setting is only configurable when Flash Descriptor Verification is enabled (See Platform Integrity/Fdv Enabled).	ICL-Y ICL-U	None None
	exclude master access in the signature Value: Yes/No This setting excludes the region master access values in the descriptor signature.	ICL-Y ICL-U	Yes Yes
Click on Platform Protection in the left tabs menu> Boot Guard Configuration is expanded by default:			



Table 2-7. - Platform Protection (Sheet 5 of 9)

▼ Boot Guard Configuration 6			
Parameter	Value		
Key Manifest ID	0	ODM identifier used during the Key mani	
Boot Guard Profile Configuration	Boot Guard Profile 0 - No_FVME	Boot Guard Profile 0 - Legacy is for platf	
CPU Debugging	Enabled	This setting determines if CPU debug mc	
BSP Initialization	Enabled	This setting determines BSP behavior w/	
S3 Optimization	Enabled	This setting overrides Boot Guard S3 opt	
#	Parameter	Platform	Settings
6	Boot Guard Configuration		
	Key Manifest ID Values: This option is for entering the hash of another public key, used by the ACM to verify the Boot Policy Manifest.	ICL-Y ICL-U	0x0 0x0
	Boot Guard Profile Configuration Values: Boot Guard Profile 0 - No_FVME Boot Guard Profile 3 - VM Boot Guard Profile 4 - FVE Boot Guard Profile 5 - FVME This option configures which Boot Guard Policy Profile will be used.	ICL-Y ICL-U	Boot Guard Profile 0 - No_FVME Boot Guard Profile 0 - No_FVME
	CPU Debugging Values: Enabled/Disabled This setting determines if CPU debug modes will be displayed. When set to 'Enabled' CPU debugging is enabled.	ICL-Y ICL-U	Enabled Enabled
	BSP Initialization Values: Enabled/Disabled This setting determines BSP behavior when it receives an INIT signal. When set to 'Enabled' BSP will behave normally if it receives an INIT (Disabled BSP Initialization (DBI) bit=0). When set to 'Disabled' BSP will shutdown if it receives an INIT ("DBI" bit=1).	ICL-Y ICL-U	Enabled Enabled
	S3 Optimization Values: Enabled/Disabled This setting overrides Boot Guard S3 optimization. <i>Note:</i> Used for testing only.	ICL-Y ICL-U	Enabled Enabled
Click on Platform Protection in the left tabs menu> Type-C Firmware Anti-Rollback Configuration is expanded by default:			



Table 2-7. - Platform Protection (Sheet 6 of 9)

▼ Type-C Firmware Anti-Rollback Configuration 7			
Parameter		Value	
IO Manageability Engine Manifest Anti-Rollback Enabled		Yes	This setting enabl
NPHY Manifest Anti-Rollback Enabled		Yes	This setting enabl
Thunerbolt(TM) Manifest Anti-Rollback Enabled		Yes	This setting enabl
#	Parameter	Platform	Settings
7	Boot Guard Configuration		
	IO Manageability Engine Manifest Anti-Rollback Enabled Values: Yes/No - This setting enables Anti-Rollback for the Type-C Subsystem IO Manageability Engine binary.	ICL-Y ICL-U	Yes Yes
	NPHY Manifest Anti-Rollback Enabled Values: Yes/No - This setting enables Anti-Rollback for the Type-C Subsystem NPHY binary.	ICL-Y ICL-U	Yes Yes
	Thunderbolt(TM) Manifest Anti-Rollback Enabled Values: Yes/No - This setting enables Anti-Rollback for the Type-C Subsystem Thunderbolt(TM) binary.	ICL-Y ICL-U	Yes Yes
	Click on Platform Protection in the left tabs menu> Intel® PTT Configuration is expanded by default:		
▼ Intel(R) PTT Configuration 8			
Parameter		Value	
Intel(R) PTT Supported		Yes	This setting permanently disables
Intel(R) PTT initial power-up state		Enabled	-
Intel(R) PTT Supported [FPF]		Yes	This setting will permanently disa
Intel(R) PTT RPMC Supported		No	This setting determines if RPMC is
Intel(R) PTT RPMC Rebinding Enabled		No	This setting determines if Rebindi
#	Parameter	Platform	Settings
8	Intel® PTT Configuration		
	Intel® PTT initial power-up state Values: Enabled/Disabled - This setting determines if Intel® PTT is enabled on platform power-up.	ICL-Y ICL-U	Enabled Enabled
	Intel® PTT Supported Values: Yes/No - This setting permanently disables Intel® PTT in the firmware image.	ICL-Y ICL-U	Yes Yes



Table 2-7. - Platform Protection (Sheet 7 of 9)

	Intel® PTT Supported [FPF] Values: Yes/No - This setting will permanently disable Intel® PTT through platform FPFs. Caution: Using this option will permanently disable Intel® PTT on the platform hardware.	ICL-Y ICL-U	Yes Yes												
	Intel® PTT RPMC Supported Values: Yes/No - This setting determines if RPMC is enabled for Intel® PTT. <i>Note:</i> The SPI parts being used need to support RPMC in order to use this feature.	ICL-Y ICL-U	No No												
	Intel® PTT RPMC Rebinding Enabled Values: Yes/No - This setting determines if Rebinding of RPMC enabled SPI parts is supported.	ICL-Y ICL-U	No No												
Click on Platform Protection in the left tabs menu> TPM Over SPI Bus Configuration is expanded by default:															
▼ TPM Over SPI Bus Configuration 9															
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 30%;">Parameter</th> <th style="width: 20%;">Value</th> <th colspan="2" style="width: 50%;">Help Text</th> </tr> </thead> <tbody> <tr> <td>TPM Clock Frequency</td> <td>17MHz</td> <td colspan="2">This setting determines the clock frequency setting to be used fo...</td> </tr> <tr> <td>TPM Over SPI Bus Enabled</td> <td>Yes</td> <td colspan="2">This setting determines if TPM over SPI bus is enabled on the pl...</td> </tr> </tbody> </table>				Parameter	Value	Help Text		TPM Clock Frequency	17MHz	This setting determines the clock frequency setting to be used fo...		TPM Over SPI Bus Enabled	Yes	This setting determines if TPM over SPI bus is enabled on the pl...	
Parameter	Value	Help Text													
TPM Clock Frequency	17MHz	This setting determines the clock frequency setting to be used fo...													
TPM Over SPI Bus Enabled	Yes	This setting determines if TPM over SPI bus is enabled on the pl...													
#	Parameter	Platform	Settings												
9	TPM Over SPI Bus Configuration														
	TPM Clock Frequency Values: 17MHz, 30MHz, 48MHz - This setting determines the clock frequency setting to be used for the TPM over SPI bus.	ICL-Y ICL-U	17MHz 17MHz												
	TPM Over SPI Bus Enabled Values: Yes/No - This setting determines if TPM over SPI bus is enabled on the platform.	ICL-Y ICL-U	Yes Yes												
Click on Platform Protection in the left tabs menu> BIOS Guard Configuration is expanded by default:															
▼ BIOS Guard Configuration 10															
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 30%;">Parameter</th> <th style="width: 20%;">Value</th> <th colspan="2" style="width: 50%;">Help Text</th> </tr> </thead> <tbody> <tr> <td>BIOS Guard Protection Override Enabled</td> <td>Yes</td> <td colspan="2">This setting allows BIOS Guard to bypass SPI flash controlle</td> </tr> </tbody> </table>				Parameter	Value	Help Text		BIOS Guard Protection Override Enabled	Yes	This setting allows BIOS Guard to bypass SPI flash controlle					
Parameter	Value	Help Text													
BIOS Guard Protection Override Enabled	Yes	This setting allows BIOS Guard to bypass SPI flash controlle													
#	Parameter	Platform	Settings												
10	BIOS Guard Configuration														
	BIOS Guard Protection Override Enabled This setting allows BIOS Guard to bypass SPI flash controller protections (i.e. Protected Range Registers and Top Swap).	ICL-Y ICL-U	Yes Yes												
Click on Platform Protection in the left tabs menu> TXT Configuration is expanded by default:															



Table 2-7. - Platform Protection (Sheet 8 of 9)

▼ TXT Configuration 11			
Parameter		Value	Help Text
TXT Supported		No	This setting determines is enabled for the platform.
#	Parameter	Platform	Settings
11	TXT Configuration		
	TXT Supported Values: Yes/No - This setting determines if enabled for the platform.	ICL-Y ICL-U	No No
Click on Platform Protection in the left tabs menu> TXT Configuration is expanded by default:			
▼ Crypto Hardware Support 12			
Parameter		Value	Help Text
Crypto HW Support		Yes	This setting can be used to disable crypto
#	Parameter	Platform	Settings
12	Crypto HW Support		
	Crypto HW Support Values: Yes/No - This setting can be used to disable crypto functionality. This setting disables all crypto related features.	ICL-Y ICL-U	Yes Yes
Click on Platform Protection in the left tabs menu> Intel FPF Anti-Rollback Configuration is expanded by default:			
#	Parameter	Platform	Settings
13	Intel FPF Anti-Rollback Configuration		
	FPF SVN Enabled Values: Enabled/Disabled - This option enables usage of Intel FPF of the Anti-Rollback mechanism for all firmware components.	ICL-Y ICL-U	Custom Custom
	RBE SVN Enabled Values: Enabled/Disabled - This option enables usage of Intel FPF of the Anti-Rollback mechanism for the RBE SVN firmware component.	ICL-Y ICL-U	Enabled Enabled



Table 2-7. - Platform Protection (Sheet 9 of 9)

	IDLM SVN Enabled Values: Enabled/Disabled - This option enables usage of Intel FPF of the Anti-Rollback mechanism for the IDLM SVN firmware component.	ICL-Y ICL-U	Enabled Enabled



Table 2-8. - Integrated Clock Controller (Sheet 1 of 6)

Click on Integrated Clock Controller in the left tabs menu> Integrated Clock Controller Policies are expanded by default:

Integrated Clock Controller Policies		
Parameter	Value	Help Text
Register Lock Policy	0:Default	Policy applied to ICC Registers at EOP.
Boot Profile	Profile 0	Profile applied during each boot.
Failsafe Boot Profile	Profile 0	Boot profile used when system instability is detected.
Profile Changeable	true	Allows user to change boot profile via BIOS menu or 3rd party appli...

#	Parameter	Platform	Settings
1	Integrated Clock Controller Policies		
	Boot Profile This parameter allows user to select default profile to be used by the final generated SPI Flash binary image for the target platform at boot time. Selection is limited to the profiles defined under "Integrated Clock Controller Profiles" up to maximum 16 profiles. Profiles can be added by clicking on "Add profile" button under "Integrated Clock Controller Profiles". The 'Record #' refers to profile created under the "Integrated Clock Controller Profiles". Default boot profile for system is Profile 0. Double click on value column of this parameter to choose from available options.	ICL-Y ICL-U	Profile 0 Profile 0
	Failsafe Profile This parameter specifies the profile index of the fail-safe profile. On boot failure detection or CMOS clear the Intel® ME firmware will revert to this profile if "Integrated Clock Controller Integrated Clock Controller Policies - Profile Changeable" is set to True. If profile Changeable parameter is set to False, User can not select Failsafe Boot Profile and profile 0 will be selected as a fail safe boot profile by default. The 'Record #' refers to profile created under the "Integrated Clock Controller Profiles". Default Failsafe boot profile for system is Profile 0. Double click on value column of this parameter to choose from available options.	ICL-Y ICL-U	Profile 0 Profile 0
	Profile Changeable Values: True/False This parameter allows the ICC boot profile to be changed via BIOS menu or third party applications.	ICL-Y ICL-U	true true

Click on Integrated Clock Controller in the left tabs menu> Profiles are expanded by default:



Table 2-8. - Integrated Clock Controller (Sheet 2 of 6)

#	Parameter	Platform	Settings
2	<p>Profile 0</p> <p>Note: Intel® ME image has to be loaded to enable other ICC profile settings.</p> <p>For ICL/CFL-Y/U, Intel® FIT provides 2 pre- defined ICC profiles to choose from.</p> <ul style="list-style-type: none"> •Standard: This profile provides default settings for standard configuration, no adaptive clocking is allowed. Platform clocks output internal and external are driven from USB3PCIe clock. Default clock frequency is 100 MHz with 0.47%DownSpread. BCLK clock source should be turned off in this case to save power. •Adaptive: This profile provides Wimax/3G friendly configuration. This profile will configure the platform based on the Adaptive profile allowing adaptive clocking adjustment for BCLK clock source to reduce EMI interference. It supports default clock frequency of 98.875 MHz with 0.48% Downspread. <p>For ICL/CFL-Y/U, Intel® FIT provides 5 pre-defined ICC profiles to choose from.</p> <ul style="list-style-type: none"> •Standard •Adaptive <p>Note: User can select pre-defined profiles via “Integrated Clock Controller Profiles - Profile Type “ parameter</p> <p>User can add up to maximum 16 profiles.To add new profile, please use “Integrated Clock Controller Profiles - + Add Profile Button”</p>	ICL-Y ICL-U	Standard Standard
	<p>Profile Name</p> <p>This parameter allows user to customize profile name for easy identification. By default it uses pre-defined profile name like Profile 0.</p>	ICL-Y ICL-U	Profile 0 Profile 0
	<p>Profile Type</p> <p>Available ICC profiles for ICL/CFL-Y/U are Standard, Adaptive.</p> <p>This parameter indicates which pre- defined profile selected for each profile#.</p> <p>Double click on value column of this parameter to choose from available options.</p>	ICL-Y ICL-U	Standard Standard
3	<p>+ Add Profile Button</p> <p>This button is used to add new ICC profile. User can add up to maximum 16 profiles. New profile will be added under “Integrated Clock Controller Profiles” tab.</p>	ICL-Y ICL-U	

Click on Integrated Clock Controller in the left tabs menu > Profiles > Profile > Bclk Clock Configuration is expanded by default:



Table 2-8. - Integrated Clock Controller (Sheet 3 of 6)

▼ BclkClockConfiguration 4																		
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 25%;">Parameter</th> <th style="width: 25%;">Value</th> <th style="width: 50%;">Help Text</th> </tr> </thead> <tbody> <tr> <td>BCLK Clock Frequency</td> <td>This parameter is not configura...</td> <td>Select the nominal frequency for the selected clock. Range is limited based on the Clock ...</td> </tr> <tr> <td>BCLK Spread setting</td> <td>This parameter is not configura...</td> <td>Select the percentage of Spread setting for the selected clock. Range is limited based on...</td> </tr> </tbody> </table>				Parameter	Value	Help Text	BCLK Clock Frequency	This parameter is not configura...	Select the nominal frequency for the selected clock. Range is limited based on the Clock ...	BCLK Spread setting	This parameter is not configura...	Select the percentage of Spread setting for the selected clock. Range is limited based on...						
Parameter	Value	Help Text																
BCLK Clock Frequency	This parameter is not configura...	Select the nominal frequency for the selected clock. Range is limited based on the Clock ...																
BCLK Spread setting	This parameter is not configura...	Select the percentage of Spread setting for the selected clock. Range is limited based on...																
#	Parameter	Platform	Settings															
4	Profiles - Profile BclkClockConfiguration																	
	BCLK Clock Frequency - This parameter allows user to select the nominal frequency for the selected clock. Range is limited based on the Clock Range Definition record and HW SKU. Standard Setting Profile Type - Option is grayed out. Adaptive Setting Profile Type - Option is able to be edited.	ICL-Y ICL-U																
	BCLK Spread Setting - This parameter allows user to select the percentage of Spread setting for the selected clock. Range is limited based on the Clock Range Definition record and HW SKU. BCLK Clock Frequency Standard Setting Profile Type - Option is grayed out. Adaptive Setting Profile Type - Option is able to be edited.	ICL-Y ICL-U																
Click on Integrated Clock Controller in the left tabs menu > Profiles > Profile > Clock Range Definition Record is expanded by default:																		
▼ Clock Range Definition Record 5																		
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 25%;">Parameter</th> <th style="width: 25%;">Value</th> <th style="width: 50%;">Help Text</th> </tr> </thead> <tbody> <tr> <td>BCLK PLL Clock Source Maximum Frequency</td> <td>100 MHz</td> <td>Specifies the maximum frequency that can be ap</td> </tr> <tr> <td>BCLK PLL Clock Source Minimum Frequency</td> <td>100 MHz</td> <td>Specifies the minimum frequency that can be app</td> </tr> <tr> <td>BCLK SSC Halt Allowed</td> <td>No</td> <td>If set to Yes, the spread generator can be enable</td> </tr> <tr> <td>BCLK SSC Maximum Percentage</td> <td>0.50 %</td> <td>Specifies the maximum percentage of spread ad</td> </tr> </tbody> </table>				Parameter	Value	Help Text	BCLK PLL Clock Source Maximum Frequency	100 MHz	Specifies the maximum frequency that can be ap	BCLK PLL Clock Source Minimum Frequency	100 MHz	Specifies the minimum frequency that can be app	BCLK SSC Halt Allowed	No	If set to Yes, the spread generator can be enable	BCLK SSC Maximum Percentage	0.50 %	Specifies the maximum percentage of spread ad
Parameter	Value	Help Text																
BCLK PLL Clock Source Maximum Frequency	100 MHz	Specifies the maximum frequency that can be ap																
BCLK PLL Clock Source Minimum Frequency	100 MHz	Specifies the minimum frequency that can be app																
BCLK SSC Halt Allowed	No	If set to Yes, the spread generator can be enable																
BCLK SSC Maximum Percentage	0.50 %	Specifies the maximum percentage of spread ad																
#	Parameter	Platform	Settings															
5	Profile ClockRangeDefinitionRecord																	
	BCLK PLL Clock Source Maximum Frequency - This parameter allows user to specify the maximum frequency that can be applied to BCLK clock source when overclocking the platform. Value is limited by divider/frequency limits determined by HW SKU, and cannot be less than 100 MHz. Standard Setting Profile Type - Option is grayed out. Adaptive Setting Profile Type - Option is able to be edited.	ICL-Y ICL-U																
	BCLK PLL Clock Source Minimum Frequency - This parameter allows user to specify the minimum frequency that can be applied to BCLK clock source when underclocking the platform. Value is limited by divider/frequency limits determined by HW SKU, and cannot be greater than 100 MHz. Standard Setting Profile Type - Option is grayed out. Adaptive Setting Profile Type - Option is able to be edited.	ICL-Y ICL-U																




Table 2-8. - Integrated Clock Controller (Sheet 4 of 6)

	<p>BCLK SSC Halt Allowed - This parameter allows user to select if the spread generator can be disabled at runtime or not. If set to "True", the spread generator can be enabled and disabled at runtime.</p> <p>Standard Setting Profile Type - Option is grayed out.</p> <p>Adaptive Setting Profile Type - Option is able to be edited.</p>	ICL-Y ICL-U																												
	<p>BCLK SSC Percentage - This parameter Specifies the maximum percentage of spread adjustment that can be applied to the clock. Value is specified in 1/100th of percent (50=0.5%)</p> <p>Standard Setting Profile Type - Option is grayed out.</p> <p>Adaptive Setting Profile Type - Option is able to be edited.</p>	ICL-Y ICL-U																												
<p>Click on Integrated Clock Controller in the left tabs menu > Profiles > Profile > Clock Output Configuration is expanded by default:</p>																														
<p>▼ ClockOutputConfiguration 6</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 20%;">Parameter</th> <th style="width: 20%;">Value</th> <th style="width: 60%;">Help Text</th> </tr> </thead> <tbody> <tr> <td>SRC0</td> <td>Enabled</td> <td>Enable/Disable the CLKOUT_SRC0 differential output buffer.</td> </tr> <tr> <td>SRC1</td> <td>Enabled</td> <td>Enable/Disable the CLKOUT_SRC1 differential output buffer.</td> </tr> <tr> <td>SRC2</td> <td>Enabled</td> <td>Enable/Disable the CLKOUT_SRC2 differential output buffer.</td> </tr> <tr> <td>SRC3</td> <td>Enabled</td> <td>Enable/Disable the CLKOUT_SRC3 differential output buffer.</td> </tr> <tr> <td>SRC4</td> <td>Enabled</td> <td>Enable/Disable the CLKOUT_SRC4 differential output buffer.</td> </tr> <tr> <td>SRC5</td> <td>Enabled</td> <td>Enable/Disable the CLKOUT_SRC5 differential output buffer.</td> </tr> <tr> <td>LPC0</td> <td>Enabled</td> <td>Enable/Disable the CLKOUT_LPC0 single ended output buffer.</td> </tr> <tr> <td>LPC1</td> <td>Enabled</td> <td>Enable/Disable the CLKOUT_LPC1 single ended output buffer.</td> </tr> </tbody> </table>				Parameter	Value	Help Text	SRC0	Enabled	Enable/Disable the CLKOUT_SRC0 differential output buffer.	SRC1	Enabled	Enable/Disable the CLKOUT_SRC1 differential output buffer.	SRC2	Enabled	Enable/Disable the CLKOUT_SRC2 differential output buffer.	SRC3	Enabled	Enable/Disable the CLKOUT_SRC3 differential output buffer.	SRC4	Enabled	Enable/Disable the CLKOUT_SRC4 differential output buffer.	SRC5	Enabled	Enable/Disable the CLKOUT_SRC5 differential output buffer.	LPC0	Enabled	Enable/Disable the CLKOUT_LPC0 single ended output buffer.	LPC1	Enabled	Enable/Disable the CLKOUT_LPC1 single ended output buffer.
Parameter	Value	Help Text																												
SRC0	Enabled	Enable/Disable the CLKOUT_SRC0 differential output buffer.																												
SRC1	Enabled	Enable/Disable the CLKOUT_SRC1 differential output buffer.																												
SRC2	Enabled	Enable/Disable the CLKOUT_SRC2 differential output buffer.																												
SRC3	Enabled	Enable/Disable the CLKOUT_SRC3 differential output buffer.																												
SRC4	Enabled	Enable/Disable the CLKOUT_SRC4 differential output buffer.																												
SRC5	Enabled	Enable/Disable the CLKOUT_SRC5 differential output buffer.																												
LPC0	Enabled	Enable/Disable the CLKOUT_LPC0 single ended output buffer.																												
LPC1	Enabled	Enable/Disable the CLKOUT_LPC1 single ended output buffer.																												
#	Parameter	Platform	Settings																											
6	<p>Profile Clock Output Configuration</p>																													
	<p>SRC0[6:15] Values: Enabled/Disabled These parameters come under the Power Management section and they control Enabling /Disabling of specific Output Clocks at boot time. These settings should match with platform hardware design.</p> <p>For CRB, recommend keeping defaults for bring up with Intel® ME FW.</p> <p>These parameters are specifically used to Enable/Disable the respective CLKOUT_XXX differential output buffers</p>	ICL-Y ICL-U	Enabled Enabled																											
	<p>SRC1 Values: Enabled/Disabled Enables or Disables the CLKOUT_SRC1 differential output buffer.</p>	ICL-Y ICL-U	Enabled Enabled																											
	<p>SRC2 Values: Enabled/Disabled Enables or Disables the CLKOUT_SRC2 differential output buffer.</p>	ICL-Y ICL-U	Enabled Enabled																											
	<p>SRC3 Values: Enabled/Disabled Enables or Disables the CLKOUT_SRC3 differential output buffer.</p>	ICL-Y ICL-U	Enabled Enabled																											



Table 2-8. - Integrated Clock Controller (Sheet 5 of 6)

	SRC4 Values: Enabled/Disabled Enables or Disables the CLKOUT_SRC4 differential output buffer.	ICL-Y ICL-U	Enabled Enabled
	SRC5 Values: Enabled/Disabled Enables or Disables the CLKOUT_SRC5 differential output buffer.	ICL-Y ICL-U	Enabled Enabled
	SRC6 Values: Enabled/Disabled Enables or Disables the CLKOUT_SRC6 differential output buffer.	ICL-Y ICL-U	NA NA
Click on Integrated Clock Controller in the left tabs menu > Profiles > Profile > Power Management Configuration is expanded by default:			
<div style="display: flex; align-items: center;"> ▼ Power Management Configuration 7 </div>			
	Parameter	Value	Help Te
	SRC0 CLKREQ# Mapping	GPP_D5	Assign the CLKREQ# signal associated with CLK
	SRC1 CLKREQ# Mapping	GPP_D6	Assign the CLKREQ# signal associated with CLK
	SRC2 CLKREQ# Mapping	GPP_D7	Assign the CLKREQ# signal associated with CLK
	SRC3 CLKREQ# Mapping	GPP_D8	Assign the CLKREQ# signal associated with CLK
	SRC4 CLKREQ# Mapping	GPP_H10	Assign the CLKREQ# signal associated with CLK
	SRC5 CLKREQ# Mapping	GPP_H11	Assign the CLKREQ# signal associated with CLK
#	Parameter	Platform	Settings
7	Profile Power Management Configuration Configuring CLKREQ# and assigning GPIO depends on how CLKOUT_SRCx configuration via FIT is done (Enabled or Disabled) and if CLKREQ is required or not. Please refer to Appendix B.3 (How to configure CLKREQ# parameters) for the detail of CLKREQ configuration for SRC Output clocks. Please configure CLKREQ parameters accordingly.		
	SRC0[5:0] CLKREQ# Mapping Possible configuration: Select one of the GPIOs from the list to map it as a CLKREQ# for specific SRC# Output clock. This parameter controls association of dynamic CLKREQ control with SRC (PCIe) clocks. SRC[15:6] CLKREQ# Mapping - ICL/CFL H/S Only Possible configuration: Select one of the GPIOs from the list to map it as a CLKREQ# for specific SRC# Output put clock. This parameter controls association of dynamic CLKREQ control with SRC (PCIe) clocks.	ICL-Y ICL-U	GPP_D5 GPP_D5
	SRC1 CLKREQ# Mapping Assign the CLKREQ# signal associated with CLKOUT_SRC1.	ICL-Y ICL-U	GPP_D6 GPP_D6
	SRC2 CLKREQ# Mapping Assign the CLKREQ# signal associated with CLKOUT_SRC2.	ICL-Y ICL-U	GPP_D7 GPP_D7



Table 2-8. - Integrated Clock Controller (Sheet 6 of 6)

	SRC3 CLKREQ# Mapping Assign the CLKREQ# signal associated with CLKOUT_SRC3.	ICL-Y ICL-U	GPP_D8 GPP_D8
	SRC4 CLKREQ# Mapping Assign the CLKREQ# signal associated with CLKOUT_SRC4.	ICL-Y ICL-U	GPP_H10 GPP_H10
	SRC5 CLKREQ# Mapping Assign the CLKREQ# signal associated with CLKOUT_SRC5.	ICL-Y ICL-U	GPP_H11 GPP_H11



Table 2-9. - Networking & Connectivity (Sheet 1 of 3)

Click on Networking & Connectivity in the left tabs menu> Discrete vPro NIC is expanded by default:			
<p>▼ Platform vPro NIC 1</p>			
Parameter		Value	
Platform Discrete vPro NIC Enabled	No	YES = Discrete NIC enabled in platform NO = Integrated GBE LAN enabled in platform	
Platform Discrete vPro NIC SMBUS slave address	0x49	Platform discrete NIC slave address Note: Input needs to be in HEX format(OEM spec	
#	Parameter	Platform	Settings
1	Platform vPro NIC		
	Platform Discrete vPro NIC Enabled Values: Yes/No This setting enables the discrete vPro LAN on the platform.	ICL-Y ICL-U	No No
	Platform Discrete vPro NIC slave SMBus Address Values: Hex	ICL-Y ICL-U	0x49 0x49
Click on Networking & Connectivity in the left tabs menu> Wired LAN Configuration is expanded by default:			
<p>▼ Wired LAN Configuration 2</p>			
Parameter		Value	
LAN Power Well	SLP_LAN#	This setting allows the customer to con	
LAN PHY Power Up Time	100ms	This bit determines how long the delay	
Intel(R) Integrated Wired LAN E...	Yes	This setting allows customers to enable	
GbE PCIe Port Select	Port9	This setting allows customers to configi	
TSN GbE Port Select	None	This setting allows customers to configi	
GbE PHY SMBus Address	0x00000064	This is the Intel PHY's SMBus address.	
GbE MAC SMBus Address Enabled	Yes	This enables the Intel(R) Integrated Wi	
GbE MAC SMBus Address	0x00000070	This setting configures Intel(R) Integrat	
PHY Connection	PHY on SMLink0	This selects which SMBus network is us	
LAN PHY Power Control GPD11 ...	Enable as LANPHYPC	This setting allows the user to assign th	
#	Parameter	Platform	Settings
2	Wired LAN Configuration		
	LAN Power Well Values: Core Well, Sus Well, ME Well, SLP_LAN - This setting allows customers to configure the power well that will be used by Intel® Integrated LAN. Note: Recommended setting is SLP_LAN#.	ICL-Y ICL-U	SLP_LAN# SLP_LAN#



Table 2-9. - Networking & Connectivity (Sheet 2 of 3)

	LAN PHY Power Up Time Values: 50ms, 100ms	ICL-Y ICL-U	100ms 100ms
	Intel® Integrated Wired LAN Enable Values: Enabled/Disabled - This setting enables or disables the Intel® Integrated LAN.	ICL-Y ICL-U	Enabled Enabled
	GbE PCIe Port Select Values: None, PORT7, PORT8, PORT9, PORT13, PORT14 - This setting allows customers to configure the PCIe Port that will Intel® Integrated LAN will operate on.	ICL-Y ICL-U	Port 14 Port 14
	TSN GbE Port Select Values: None, TSN PORT7, TSN PORT8, TSN PORT11, TSN PORT12 - This setting allows customers to configure the PCIe Port that Time Sensitive Networking will operate on. Note: In order to use Time Sensitive Networking you must set to Time Sensitive Networking setting to TSN Enabled	ICL-Y ICL-U	None None
	GbE PHY SMBus Address This setting configures Intel® Integrated Wired LAN SMBus address to accept SMBus cycles from the MAC. Note: Recommended setting is 64h.	ICL-Y ICL-U	0x64 0x64
	GbE SMBus Address Enabled Values: Yes/No - This enables the Intel® Integrated Wired LAN MAC SMBus address. Note: This setting must be enabled if using Intel® Integrated LAN.	ICL-Y ICL-U	Yes Yes
	GbE MAC SMBus Address	ICL-Y ICL-U	0x70 0x70
	PHY Connection Values: No PHY connected, PHY on SMLink0	ICL-Y ICL-U	PHY on SMLink0 PHY on SMLink0
	LAN PHY Power Control GPD11 Signal Configuration Values: GPD11, LANPHYPC - This setting allows the customer to assign the LAN PHY Power Control signal to GbE or as GDP11. Note: If using Intel® Integrated LAN this setting should be set to "Enable as LANPHYPC".	ICL-Y ICL-U	LANPHYPC LANPHYPC

Click on Networking & Connectivity in the left tabs menu> Wireless LAN Configuration is expanded by default:

▼ Wireless LAN Configuration

3

Parameter	Value	Help Text
Intel(R) ME CLINK Signal Enabled	Yes	This setting allows customers to enable / disable th
SLP_WLAN# / GDP9 Signal Configuration	Enable as SLP_WLAN#	This setting allows user the to assign the WLAN Pow
WLAN Microcode	0x9DF0 PULSAR	This setting allows OEMs to configure which Intel(R
WLAN Power Well	SLP_WLAN#	-

#	Parameter	Platform	Settings
3	Wireless LAN Configuration		
	CLINK Enabled Values: Yes/No - This setting allows customers to enable / disable the Wireless LAN CLINK signal through Intel® ME firmware. Note: For using Intel® vPro™ Wireless solutions this should be set to "Yes".	ICL-Y ICL-U	No No



Table 2-9. - Networking & Connectivity (Sheet 3 of 3)

	SLP_WLAN# / GPD9 Signal Configuration Values: SLP_WLAN#, GPD9 - This setting allows the customer to assign the WLAN Power Control signal to WLAN or as GDP9. Note: If using Intel® Wireless LAN this setting should be set to "Enable as SLP_WLAN#".	ICL-Y ICL-U	Enable as SLP_WLAN# Enabled as SLP_WLAN #
	WLAN Microcode - This setting allow OEMs to configure which Intel® Wireless LAN card microcode to load into the firmware image.	ICL-Y ICL-U	0x9DF0 0x9DF0
	WLAN Power Well Values: Disabled, Sus Well, ME Well, SLP_M# SPDA, SLP_WLAN# - This setting allows OEMs to configure the power well that will be used by Intel® Wireless LAN. WLAN Sleep via SLP_WLAN# (default) Note: Recommended setting is SLP_WLAN#.	ICL-Y ICL-U	SLP_WLAN# SLP_WLAN#
Click on Networking & Connectivity in the left tabs menu> Time Sensitive Networking Configuration is expanded by default:			
▼ Time Sensitive Networking Configuration 4			
<hr style="border: 1px solid yellow;"/>			
	Parameter	Value	Hel
	Time Sensitive Networking	TSN Disabled	This setting allows customers to enable / dis
#	Parameter	Platform	Settings
4	Time Sensitive Networking Configuration		
	Time Sensitive Networking Values: TSN Enable / TSN Disabled Note: Time Sensitive Networking and Wired LAN are mutually exclusive only one other these features can enabled on the platform.	ICL-Y ICL-U	Disabled Disabled



Table 2-10. - Internal PCH Buses (Sheet 1 of 5)

Click on Internal PCH Buses in the left tabs menu> PCH Timer Configuration is expanded by default:			
<p>▼ PCH Timer Configuration 1</p>			
Parameter		Value	
PCH clock output stable to PROCPWRGD high...	1ms	This setting configures the mini	
PCIe Power Stable Timer (tPCH33)	Disabled	This setting configures the enat	
PROCPWRGD and SYS_PWROK high to SUS_...	1ms	This setting configures the mini	
APWROK Timing	2ms	This soft strap determines the t	
Over Clocking Watchdog Self Start Enable	OC WDT Disabled	This setting affect whether the	
#	Parameter	Platform	Settings
1	PCH Timer Configuration		
	PCH clock output stable to PROCPWRGD high (tPCH45) Values: 100ms, 50ms, 5ms, 1ms - This setting configures the minimum timing from XCK_PLL locked to CPUPWRGD high. For further details see Ice Lake LP Platform Controller Hub EDS.	ICL-Y ICL-U	1ms 1ms
	PCIe Power Stable Timer (tPCH33) Values: Enabled/Disabled - This setting configures the enables / disables the t36 timer. When enabled PCH will count 99ms from PWROK assertion before PLTRST# is de-asserted. Note: The recommended setting is "Disabled".	ICL-Y ICL-U	Disabled Disabled
	PROCPWRGD and SYS_PWROK high to SUS_STAT# de-assertion (tPCH46) Values: 1ms, 2ms, 5ms - This setting configures the minimum timing from CPUPWRGD assertion to SUS_STAT#. For further details see Ice Lake LP Platform Controller Hub EDS.	ICL-Y ICL-U	1ms 1ms
	APWROK Timing Values: 2ms, 4ms, 8ms, 16ms - This soft strap determines the time between the SLP_A# pin de-asserting and the APWROK timer expiration. For further details see Ice Lake LP Platform Controller Hub EDS.	ICL-Y ICL-U	2ms 2ms
	Over Clocking Watchdog Self Start Enable Values: OC WDT Disabled, OC WDT 3 Second Timeout, OC WDT 5 Second Timeout, OC WDR 10 Second Timeout, OC WDT 15 Second Timeout, OC WDT 30 Second Timeout, OC WDT 45 Second Timeout, OC WDT 60 Second Timeout - This setting affect whether the Over Clocking Watchdog Timer is enabled to automatically start on Host power cycle	ICL-Y ICL-U	OC WDT Disabled OC WDT Disabled
Click on Internal PCH Buses in the left tabs menu> SMBus / SMLink Configuration is expanded by default:			



Table 2-10. - Internal PCH Buses (Sheet 2 of 5)

▼ SMBus / SMLink Configuration 2			
	Parameter	Value	Help Tex
	Intel(R) SMLink0 MCTP Address	0x0	This setting configures the Intel(R) SMLink0b MCTP
	Intel(R) SMLink0 MCTP Address Enabled	No	This setting enables / disables the Intel(R) SMLink
	Intel(R) SMBus ASD Address	0x0	This setting configures the Intel(R) SMBus Alert S
	Intel(R) SMBus ASD Address Enabled	No	This setting enables / disables the Intel(R) SMBus
	Intel(R) SMBus Subsystem Vendor and D...	0x0	This setting configures the Intel(R) SMBus Subsys
	Intel(R) SMBus I2C Address	0x0	This setting configures the Intel(R) SMBus I2C Ad
	Intel(R) SMBus I2C Address Enabled	No	This setting enables / disables the Intel(R) SMBus
	SMBus / SMLink TCO Slave Connection	Intel(R) SMBus	This setting configures the TCO Slave connection
	SMLink0 Enabled	Yes	This setting enables / disables SMLink0b interface
	SMLink0 Frequency	1 MHz	This setting determines the frequency at which th
	SMLink1 I2C Target Address	0x0	This setting configures SMLink1 I2C Target Adre
	SMLink1 I2C Target Address Enabled	No	This setting configures SMLink1 I2C Target Adre
	SMLink1 GP Target Address	0x0	This setting configures SMLink1 GP Target Adres
	SMLink1 GP Target Address Enabled	No	This setting enables / disables SMLink1 GP Target
	SMLink1 Enabled	No	This setting enables / disables SMLink1 interface.
	SMLink1 Frequency	100 KHz	This setting determines the frequency at which th
	Intel(R) SMBus ASD Mode Configuration	Enable as GPP_C2	This setting determines the native mode of opera

#	Parameter	Platform	Settings
2	SMBus / SMLink Configuration		
	Intel® SMLink0 MCTP Address Value: Hex This setting configures the Intel® SMLink0b MCTP Address. <i>Note:</i> This setting is only used for testing.	ICL-Y ICL-U	0x0 0x0
	Intel® SMLink0 MCTP Address Enabled Value: Yes / No This setting enables / disables the Intel® SMLink0b MCTP Address. <i>Note:</i> This setting is only used for testing.	ICL-Y ICL-U	No No
	Intel® SMBus ASD Address - This setting configures the Intel® SMBus Alert Sending Device Address. For details see Ice Lake LP SPI Programming guide for further details.	ICL-Y ICL-U	0x00000000 0x00000000
	Intel® SMBus ASD Address Enable Values: Yes/No - This setting enables / disables the Intel® SMBus Alert Sending Device. For details see Ice Lake LP SPI Programming guide for further details.	ICL-Y ICL-U	No No



Table 2-10. - Internal PCH Buses (Sheet 3 of 5)

	Intel® SMBus Subsystem Vendor & Device ID for ASF - This setting configures the Intel® SMBus Subsystem Vendor & Device ID for ASF. For details see Ice Lake LP SPI Programming guide further details.	ICL-Y ICL-U	0x00000000 0x00000000
	Intel® SMBus I2C Address - This setting configures the Intel® SMBus I2C Address. Note: This setting is only used for testing purposes. The recommended setting is "00000000".	ICL-Y ICL-U	0x00000000 0x00000000
	Intel® SMBus I2C Address Enabled Values: Yes/No - This setting enables / disables the Intel® SMBus I2C Address. Note: This setting is only used for testing purposes. The recommended setting is "No".	ICL-Y ICL-U	No No
	Intel® SMBus MCTP Address - This setting configures the Intel® SMBus MCTP Address. Note: This setting is only used for testing purposes. The default setting is "00000000".	ICL-Y ICL-U	0x00000000 0x00000000
	Intel® SMBus MCTP Address Enabled Values: Yes/No - This setting enables / disables the Intel® SMBus MCTP Address. Note: This setting is only used for testing purposes. The recommended setting is "No".	ICL-Y ICL-U	No No
	SMBus / SMLink TCO Slave Connection Values: Intel® SMBus, SMLink0 - This setting configures the TCO Slave connection to ether the Intel® SMBus or SMLink0. For further details see Ice Lake LP Platform Controller Hub EDS.	ICL-Y ICL-U	Intel® SMBus Intel® SMBus
	SMLink0 Enabled Values: Yes/No - This setting enables / disables SMLink0 interface. For further details see Ice Lake LP Platform Controller Hub EDS.	ICL-Y ICL-U	Yes Yes
	SMLink0 Frequency Values: 100KHz, 400KHz, 1 MHz - This setting determines the frequency at which the SMLink0 will operate. Note: The recommended setting is "1MHz".	ICL-Y ICL-U	1 MHz 1 MHz
	SMLink1 I2C Target Address - This setting configures SMLink1 I2C Target Address. For further details see Ice Lake LP Platform Controller Hub EDS.	ICL-Y ICL-U	0x00000000 0x00000000
	SMLink1 I2C Target Address Enabled Values: Yes/No - This setting configures SMLink1 I2C Target Address. For further details see Ice Lake LP Platform Controller Hub EDS.	ICL-Y ICL-U	No No
	SMLink1 Enabled Values: Yes/No - This setting enables / disables SMLink1 interface. For further details see Ice Lake LP Platform Controller Hub EDS. Note: This setting must be set to "Yes" if using PCH / MCP Thermal reporting.	ICL-Y ICL-U	No No
	SMLink1 GP Target Address - This setting configures SMLink1 GP Target Address. For further details see Ice Lake LP Platform Controller Hub EDS.	ICL-Y ICL-U	0x00000000 0x00000000
	SMLink1 Frequency Values: 100KHz, 400KHz, 1 MHz - This setting determines the frequency at which the SMLink1 will operate. Note: The recommended setting is "100KHz".	ICL-Y ICL-U	100 KHz 100 KHz
	Intel® SMBus ASD Mode Configuration This setting determines the native mode of operation for the Intel® SMBus ASD signal.	ICL-Y ICL-U	Enable as GPP_C2 Enable as GPP_C2

Click on Internal PCH Buses in the left tabs menu> DMI Configuration is expanded by default:

▼ **DMI Configuration** 3

Parameter	Value	Help Text
DMI Lane Reversal	No	This setting allow the DMI Lane signals to be revers
DMI Port Staggering Enabled	Yes	This setting configures DMI for Port Staggering. For

#	Parameter	Platform	Settings
---	-----------	----------	----------



Table 2-10. - Internal PCH Buses (Sheet 4 of 5)

3	DMI Configuration																
	DMI Lane Reversal Values: Yes/No - This setting allows the DMI Lane signals to be reversed. For further details see Ice Lake LP Platform Controller Hub EDS.	ICL-Y ICL-U	No No														
	DMI Port Staggering Values: Yes/No - This setting configures DMI for Port Staggering. For further details see Ice Lake LP Platform Controller Hub EDS.	ICL-Y ICL-U	Yes Yes														
Click on Internal PCH Buses in the left tabs menu> OPI Configuration is expanded by default:																	
<div style="display: flex; align-items: center;"> ▼ OPI / DMI Configuration 4 </div>																	
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 30%;">Parameter</th> <th style="width: 30%;">Value</th> <th style="width: 40%;">Help</th> </tr> </thead> <tbody> <tr> <td>OPI / DMI Link Speed</td> <td>4 GT/s</td> <td>This setting configures the OPI Link Speed. For further details see Ice Lake PCH EDS.</td> </tr> <tr> <td>OPI / DMI Link Voltage</td> <td>0.95 Volts</td> <td>This setting configures the OPI Link Voltage. For further details see Ice Lake PCH EDS.</td> </tr> <tr> <td>OPI / DMI Link Width</td> <td>8 Lanes</td> <td>This setting configures the OPI Link Width. For further details see Ice Lake PCH EDS.</td> </tr> </tbody> </table>				Parameter	Value	Help	OPI / DMI Link Speed	4 GT/s	This setting configures the OPI Link Speed. For further details see Ice Lake PCH EDS.	OPI / DMI Link Voltage	0.95 Volts	This setting configures the OPI Link Voltage. For further details see Ice Lake PCH EDS.	OPI / DMI Link Width	8 Lanes	This setting configures the OPI Link Width. For further details see Ice Lake PCH EDS.		
Parameter	Value	Help															
OPI / DMI Link Speed	4 GT/s	This setting configures the OPI Link Speed. For further details see Ice Lake PCH EDS.															
OPI / DMI Link Voltage	0.95 Volts	This setting configures the OPI Link Voltage. For further details see Ice Lake PCH EDS.															
OPI / DMI Link Width	8 Lanes	This setting configures the OPI Link Width. For further details see Ice Lake PCH EDS.															
#	Parameter	Platform	Settings														
4	OPI / DMI Configuration																
	OPI Link Speed Values: GT2/GT4 - This setting configures the OPI / DMI Link Speed. For further details see Ice Lake PCH EDS.	ICL-Y ICL-U	4 GT/s 4 GT/s														
	OPI Link Voltage Values: 0.85 Volts, 0.95 Volts - This setting configures the OPI / DMI Link Voltage. For further details see Ice Lake PCH EDS.	ICL-Y ICL-U	0.95 Volts 0.95 Volts														
	OPI Link Width Values: 1 Lanes, 2 Lanes, 4 Lanes, 8 Lanes - This setting configures the OPI / DMI Link Width. For further details see Ice Lake PCH EDS.	ICL-Y ICL-U	8 Lanes 8 Lanes														
Click on Internal PCH Buses in the left tabs menu> eSPI Configuration is expanded by default:																	
<div style="display: flex; align-items: center;"> ▼ eSPI Configuration 5 </div>																	
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 60%;">Parameter</th> <th style="width: 40%;">Value</th> </tr> </thead> <tbody> <tr> <td>eSPI / EC Bus Frequency</td> <td>60MHz</td> </tr> <tr> <td>eSPI / EC Maximum I/O Mode</td> <td>Single, Dual and Quad</td> </tr> <tr> <td>eSPI / EC CRC Check Enabled</td> <td>Yes</td> </tr> <tr> <td>eSPI / EC Max Outstanding Request for Master Attached Flash Channel</td> <td>2</td> </tr> <tr> <td>eSPI / EC Slave Attached Flash Multiple Outstanding Requests Enable</td> <td>Single Outstanding Request</td> </tr> <tr> <td>eSPI / EC Slave Attached Flash Channel OOO Enable</td> <td>In-Order SAF Requests</td> </tr> </tbody> </table>				Parameter	Value	eSPI / EC Bus Frequency	60MHz	eSPI / EC Maximum I/O Mode	Single, Dual and Quad	eSPI / EC CRC Check Enabled	Yes	eSPI / EC Max Outstanding Request for Master Attached Flash Channel	2	eSPI / EC Slave Attached Flash Multiple Outstanding Requests Enable	Single Outstanding Request	eSPI / EC Slave Attached Flash Channel OOO Enable	In-Order SAF Requests
Parameter	Value																
eSPI / EC Bus Frequency	60MHz																
eSPI / EC Maximum I/O Mode	Single, Dual and Quad																
eSPI / EC CRC Check Enabled	Yes																
eSPI / EC Max Outstanding Request for Master Attached Flash Channel	2																
eSPI / EC Slave Attached Flash Multiple Outstanding Requests Enable	Single Outstanding Request																
eSPI / EC Slave Attached Flash Channel OOO Enable	In-Order SAF Requests																



Table 2-10. - Internal PCH Buses (Sheet 5 of 5)

#	Parameter	Platform	Settings
5	eSPI Configuration		
	eSPI / EC Bus Frequency Values: 20MHz, 24MHz, 30MHz, 40MHz, 60MHz This setting determines the maximum frequency of the eSPI bus that is supported by the eSPI Master and platform configuration. <i>Note:</i> The actual frequency depends on trace length, number of eSPI Slaves, etc.	ICL-Y ICL-U	60MHz 60MHz
	eSPI / EC Maximum I/O Mode Values: Single, Single and Dual, Single and Quad, Single Dual and Quad This setting determines the maximum IO Mode (Single/Dual/Quad) of the eSPI bus that is supported by the eSPI Master and specific platform configuration. <i>Note:</i> The actual IO Mode of the eSPI bus will be the minimum of this field and the Slave's maximum IO Mode advertised in its General Capabilities register.	ICL-Y ICL-U	Single, Dual and Quad Single, Dual and Quad
	eSPI / EC CRC Check Enabled Values: Yes/No This setting enables CRC checking on eSPI Slave 0 channel.	ICL-Y ICL-U	Yes Yes
	eSPI / EC Max Outstanding Request for Master Attached Flash Channel Values: 1, 2 This setting determines the Maximum outstanding requests on the eSPI / EC Master Attached Flash Channel.	ICL-Y ICL-U	2 2
	eSPI / EC Slave Attached Flash Multiple Outstanding Requests Enable Values: Single Outstanding Request, Multiple Outstanding Requests This setting enabled multiple outstanding requests for the eSPI / EC Slave Attached Flash device.	ICL-Y ICL-U	Single Outstanding Request Single Outstanding Request
	eSPI / EC Slave Attached Flash Channel OOO Enable Values: In-Order SAF Requests, Out-of-Order SAF Requests This setting enables Out or Order requests on the eSPI / EC Slave Attached Flash device.	ICL-Y ICL-U	In-Order SAF Requests In-Order SAF Requests



Table 2-11. - Power (Sheet 1 of 2)

Click on Power in the left tabs menu> Platform Power is expanded by default:			
<p>▼ Platform Power 1</p>			
Parameter	Value	Help Text	
SLP_S5# / GPD10 Signal Config...	Enable as SLP_S5#	This setting allows the user to assign	
SLP_S3# / GPD4 Signal Configu...	Enable as SLP_S3#	This setting allows the user to assign	
SLP_S4# / GPD5 Signal Configu...	Enable as SLP_S4#	This setting allows the user to assign	
SLP_A# / GPD6 Signal Configur...	Enable as SLP_A#	This setting allows the user to assign	
SLP_S0# Tunnel	Disabled	This setting Enables / Disables the tur	
#	Parameter	Platform	Settings
1	Platform Power		
	SLP_S3# / GPD4 Signal Configuration Values: SLP_S3#, GPD4 - This setting allows the customer to assign the SLP_S3# Power Control signal as SLP_S3# or as GDP4. For further details see Ice Lake LP Platform Controller Hub EDS.	ICL-Y ICL-U	SLP_S3# SLP_S3#
	SLP_S4# / GPD5 Signal Configuration Values: SLP_S4#, GPD5 - This setting allows the customer to assign the SLP_S4# Power Control signal as SLP_S4# or as GDP5. For further details see Ice Lake LP Platform Controller Hub EDS.	ICL-Y ICL-U	SLP_S4# SLP_S4#
	SLP_S5# / GPD10 Signal Configuration Values: SLP_S5#, GPD10 - This setting allows the customer to assign the SLP_S5# Power Control signal as SLP_S5# or as GDP10. For further details see Ice Lake LP Platform Controller Hub EDS.	ICL-Y ICL-U	SLP_S5# SLP_S5#
	SLP_A# / GPD6 Signal Configuration Values: SLP_A#, GPD6 - This setting allows the customer to assign the SLP_A# Power Control signal as SLP_A# or as GDP6. For further details see Ice Lake LP Platform Controller Hub EDS.	ICL-Y ICL-U	SLP_A# SLP_A#
	SLP_S0# Tunnel This setting Enables / Disables the tunneling of the SLP_S0# pin over ESPI to the EC when in ESPI mode.	ICL-Y ICL-U	Disabled Disabled
Click on Power in the left tabs menu> Deep Sx is expanded by default:			
<p>▼ Deep Sx 2</p>			
Parameter	Value	Help Text	
Deep Sx Enabled	Yes	This requires the target platform to support Deep SX state	
#	Parameter	Platform	Settings
2	Deep Sx		
	Deep Sx Enabled Values: Yes/ No - This setting enables / disables support for Deep Sx operation. For further details see Ice Lake LP Platform Controller Hub EDS. Note: Support for Deep Sx is board design dependent.	ICL-Y ICL-U	Yes Yes
Click on Power in the left tabs menu> PCH Thermal Reporting is expanded by default:			



Table 2-11. - Power (Sheet 2 of 2)

▼ PCH Thermal Reporting 3			
Parameter		Value	
Thermal Power Reporting Enabled		Yes	This setting enabled a or
#	Parameter	Platform	Settings
3	PCH Thermal Reporting		
	Thermal Power Reporting Enabled This setting enabled a once-per-second timer interrupt is enabled which triggers firmware to report power and temperature information as enabled by configuration registers. Note: When this setting is disabled ensure that the once-per-second timer interrupt associated with this feature is also disabled.	ICL-Y ICL-U	Yes Yes



Table 2-12. - Integrated Sensor Hub (Sheet 1 of 2)

Click on Integrated Sensor Hub in the left tabs menu> Integrated Sensor Hub is expanded by default:			
▼ Integrated Sensor Hub 1			
Parameter		Value	
Integrated Sensor Hub Supported		Yes	This setting allows customers to enable
Integrated Sensor Hub Initial Power State		Disabled	This setting allows customers to deterr
#	Parameter	Platform	Settings
1	Integrated Sensor Hub		
	Integrated Sensor Hub Supported Values: Yes/No This setting allows customers to disable ISH on the platform.	ICL-Y ICL-U	Yes Yes
	Integrated Sensor Hub Power Up State Values: Enabled/Disabled Field is enabled for editing if "Integrated Sensor Hub Supported" field above is set to "Yes". This setting allows customers to determine the power up state for ISH.	ICL-Y ICL-U	Disabled Disabled
Click on Integrated Sensor Hub in the left tabs menu> ISH Image is expanded by default:			
▼ ISH Image 2			
Parameter	Value	Help Text	
Length	0x40000	Total size (in bytes) of the ISH code partition including reserved space. It is recommended to be at leas...	
InputFile		Path to your ISH firmware binary file.	
#	Parameter	Platform	Settings
2	ISH Image		
	Length - Total size (in bytes) of the ISH code partition including reserved space. It is recommended to be at least 256kb.		
	Input File	ICL-Y ICL-U	
Click on Integrated Sensor Hub in the left tabs menu> ISH Data is expanded by default:			
▼ ISH Data 3			
Parameter	Value	Help Text	
PDT Binary File		Path to your PDT binary file	
#	Parameter	Platform	Settings
3	ISH Data		



Table 2-12. - Integrated Sensor Hub (Sheet 2 of 2)

	PDT Binary File	ICL-Y ICL-U	Path for PDT Binary file Path for PDT Binary file





Table 2-13. - Camera (Sheet 1 of 2)

Click on Camera in the left tabs menu> IPU Security is expanded by default:			
<div style="display: flex; align-items: center;"> ▼ IPU Security 1 </div>			
Parameter		Value	
Secure Touch	Disabled	When set, CAMERA_MASK register bits p	
FW Secure Mode	Enabled	If enabled, access blockers in IS and PS	
Secure Touch Camera Mask	0xFF	Camera mask bits per CSI port. When SI	
SW Driver Controls Port Configuration	Enabled	When set, port config is taken from the v	
#	Parameter	Platform	Settings
1	IPU Security		
	Secure Touch When set, CAMERA_MASK register bits per CSI port are used to mask the data of cameras. When cleared, camera data is not masked.	ICL-Y ICL-U	Disabled Disabled
	FW Secure Mode If enabled, access blockers in IS and PS are enabled, and FW is read from IMR. Must be enabled for FW authentication flow and execution of authenticated FW.	ICL-Y ICL-U	Enabled Enabled
	Secure Touch Camera Mask Camera mask bits per CSI port. When SECURE_TOUCH is set each set bit masks a CSI port for secure touch. When SECURE_TOUCH is cleared this register has no impact on the CSI ports.	ICL-Y ICL-U	0xFF 0xFF
	SW Driver Controls Port Configuration When set, port config is taken from the value IPU driver configures in IPU. When cleared, port config is taken from: CSI2_PORT_CONFIG_MSB.PORT_ID and CSI2_PORT_CONFIG_LSB.PORT_ID	ICL-Y ICL-U	Enabled Enabled
Click on Camera in the left tabs menu> IPU Debug is expanded by default:			
<div style="display: flex; align-items: center;"> ▼ IPU Debug 2 </div>			
Parameter		Value	
IPU Debugging Enabled	Enabled	If enabled, IPU Debugging is enabled, otherwise	
#	Parameter	Platform	Settings
2	IPU Debug		
	IPU Debugging Enabled If enabled, IPU Debugging is enabled, otherwise internal setup is checked to see if the IPU Debugging feature should be enabled or not.	ICL-Y ICL-U	Enabled Enabled
Click on Camera in the left tabs menu> IPU PHY is expanded by default:			



Table 2-13. - Camera (Sheet 2 of 2)

▼ IPU PHY 3			
#	Parameter	Platform	Settings
	Port Configuration For 8 LSB Lanes		0x0000
	Port Configuration For 8 MSB Lanes		0x0000
	Port Configuration For 8 LSB Lanes	ICL-Y ICL-U	0x0000 0x0000
	Port Configuration for 8 MSB Lanes	ICL-Y ICL-U	0x0000 0x0000



Table 2-14. - Debug (Sheet 1 of 5)

Click on Debug in the left tabs menu> Intel® ME Firmware Debugging Overrides is expanded by default:			
<div style="display: flex; align-items: center;"> ▼ IDLM 1 </div>			
Parameter		Value	
IDLM Binary		This allows an IDLM binary to be merged in	
#	Parameter	Platform	Settings
1	IDLM		
	IDLM Binary This allows an IDLM binary to be merged into output image built by Intel® FIT.	ICL-Y ICL-U	
Click on Debug in the left tabs menu> Intel® Trace Hub Technology is expanded by default:			
<div style="display: flex; align-items: center;"> ▼ Intel(R) Trace Hub Technology 2 </div>			
Parameter		Value	
Intel(R) Trace Hub Binary		This loads the Intel(R) Trace	
Intel(R) Trace Hub Emergency Mode Enabled		No	When enabled, Intel(R) ME p
Intel(R) Trace Hub Debug Messages Enabled		Yes	Intel(R) Trace Hub Debug Me
Unlock Token		This allows the OEM to input	
#	Parameter	Platform	Settings
2	Intel® Trace Hub Technology		
	Intel® Trace Hub Binary - This loads the Intel® Trace Hub binary that will be merged into the output image generated by the Intel® FIT tool.	ICL-Y ICL-U	Trace Hub Binary Trace Hub Binary
	Intel® Trace Hub Emergency Mode Enabled Values: Yes/No - This setting enable / disables Intel® Trace Hub in the firmware base image.	ICL-Y ICL-U	No No
	Intel® Trace Hub Debug Message Enabled Values: Yes/No - This setting enables/disables the Intel® Trace Hub debug messages. Note: When enabling this setting you also need to enable Intel® Trace Hub Soft Enable setting for proper operation.	ICL-Y ICL-U	Yes Yes
	Unlock Token This allows the OEM to input an Unlock Token binary file for closed chassis debug.	ICL-Y ICL-U	
Click on Debug in the left tabs menu> Intel® ME Debugging Overrides is expanded by default:			



Table 2-14. - Debug (Sheet 2 of 5)

▼ Intel(R) ME Firmware Debugging Overrides 3			
Parameter		Value	
Debug Override Pre-Production Silicon		0x0	
Debug Override Production Silicon		0x0	
Intel(R) ME Reset Behavior		Intel(R) ME will Halt	
Enable Intel(R) ME Reset Capture on CLR_RST#		No	
Firmware ROM Bypass		No	
AFS Idle Flash Reclaim Enabled		Yes	

#	Parameter	Platform	Settings
3	Intel® ME Firmware Debugging Overrides		
	Debug Override Pre-Production Silicon - Allows the OEM to control FW features to assist with pre-production platform debugging. This control has no effect if used on production silicon. Bit 0: Disable DRAM_INIT_DONE (default timeout 60 seconds) Bit 1: Disable Host Reset Timer Bit 2: Disable CPU_RESET_DONE timeout Bit 3: Reserved Bit 4: Disable Intel® ME Power Gating Bit 5: Reserved Bit 6: Secure Boot debug hook. Used to shorten wait time before ENF shutdown. Bit 7: Force real FPFs on preproduction (default is to use flash) Bit 8: Secure Boot debug hook. Used to reduce S3 or FFS optimization tries. Bit 9: Reserved Bit 10: Override power package to always enter M3. Note: Certain options do not work when the descriptor is locked.	ICL-Y ICL-U	0x00000000 0x00000000
	Debug Override Production Silicon - Allows the OEM to control FW features to assist with production platform debugging. Bit 0: Extend DRAM_INIT_DONE timeout to 30 minutes (default timeout 15 seconds) Bit 1: Disable Host Reset Timer Bit 2: Disable CPU_RESET_DONE timeout Note: Certain options do not work when the descriptor is locked.	ICL-Y ICL-U	0x00000000 0x00000000
	Intel® ME Reset Behavior This setting determines Intel® ME behavior when boot image errors are encountered. Warning: This setting should be used for debug purposes only. Note: This may block normal Firmware functional flows.	ICL-Y ICL-U	Intel® ME will Halt Intel® ME will Halt
	Enable Intel® ME Reset Capture on CLR_RST#	ICL-Y ICL-U	No No
	Firmware ROM Bypass Values: Yes/No - This setting enables / disables firmware ROM bypass. Note: This setting only has affect when the firmware being used has ROM Bypass code present.	ICL-Y ICL-U	No No
	ASF Idle Flash Reclaim Enabled Values: Yes / No This controls enabling / disable the Intel® AFS Idle flash reclaim capabilities. Note: This setting should be used for debug purposes only.	ICL-Y ICL-U	Yes Yes

Click on Debug in the left tabs menu> Direct Connection Interface Configuration is expanded by default:



Table 2-14. - Debug (Sheet 3 of 5)

▼ Direct Connect Interface Configuration 4			
	Parameter	Value	Header
	Direct Connect Interface (DCI) Enabled	No	This setting enables / disables the DCI interface.
	DCI BSSB over USB3 Port1 Enabled	Yes	This setting determines if the USB port 1 has BSSB (Boundary Scan Side Band) enabled.
	DCI BSSB over USB3 Port2 Enabled	No	This setting determines if the USB port 2 has BSSB (Boundary Scan Side Band) enabled.
	DCI BSSB over USB3 Port3 Enabled	Yes	This setting determines if the USB port 3 has BSSB (Boundary Scan Side Band) enabled.
	DCI BSSB over USB3 Port4 Enabled	Yes	This setting determines if the USB port 4 has BSSB (Boundary Scan Side Band) enabled.
	DCI BSSB over USB3 Port5 Enabled	No	This setting determines if the USB port 5 has BSSB (Boundary Scan Side Band) enabled.
	DCI BSSB over USB3 Port6 Enabled	No	This setting determines if the USB port 6 has BSSB (Boundary Scan Side Band) enabled.
#	Parameter	Platform	Settings
4	Direct Connection Interface Configuration <i>Note:</i> When any of the DCI BSSB USB3 Port interfaces are enabled the associated USB3 port selection control will be greyed out under the USB3 Port Configuration settings section under the Flex I/O tab		
	Direct Connect Interface (DCI) Enabled Values: Yes/No - This setting enables / disables the DCI interface used for Intel® Trace Hub debugging.	ICL-Y ICL-U	No No
	DCI BSSB over USB3 Port 1 Enabled This setting determines if the USB port 1 has BSSB (Boundary Scan Side Band) enabled. <i>Note:</i> For S0ix and reset flows BSSB should be enabled. <i>Note:</i> When this setting is enabled the corresponding USB3 Combo Port in the Flex I/O Tab will be Grayed out.	ICL-Y ICL-U	Yes Yes
	DCI BSSB over USB3 Port 2 Enabled This setting determines if the USB port 2 has BSSB (Boundary Scan Side Band) enabled. <i>Note:</i> For S0ix and reset flows BSSB should be enabled. <i>Note:</i> When this setting is enabled the corresponding USB3 Combo Port in the Flex I/O Tab will be Grayed out.	ICL-Y ICL-U	Yes Yes
	DCI BSSB over USB3 Port 3 Enabled This setting determines if the USB port 3 has BSSB (Boundary Scan Side Band) enabled. <i>Note:</i> For S0ix and reset flows BSSB should be enabled. <i>Note:</i> When this setting is enabled the corresponding USB3 Combo Port in the Flex I/O Tab will be Grayed out.	ICL-Y ICL-U	No No
	DCI BSSB over USB3 Port 4 Enabled This setting determines if the USB port 4 has BSSB (Boundary Scan Side Band) enabled. <i>Note:</i> For S0ix and reset flows BSSB should be enabled. <i>Note:</i> When this setting is enabled the corresponding USB3 Combo Port in the Flex I/O Tab will be Grayed out.	ICL-Y ICL-U	No No



Table 2-14. - Debug (Sheet 4 of 5)

	DCI BSSB over USB3 Port 5 Enabled This setting determines if the USB port 5 has BSSB (Boundary Scan Side Band) enabled. <i>Note:</i> For S0ix and reset flows BSSB should be enabled. <i>Note:</i> When this setting is enabled the corresponding USB3 Combo Port in the Flex I/O Tab will be Grayed out.	ICL-Y ICL-U	No No
	DCI BSSB over USB3 Port 6 Enabled This setting determines if the USB port 5 has BSSB (Boundary Scan Side Band) enabled. <i>Note:</i> For S0ix and reset flows BSSB should be enabled. <i>Note:</i> When this setting is enabled the corresponding USB3 Combo Port in the Flex I/O Tab will be Grayed out.	ICL-Y ICL-U	No No
Click on Debug in the left tabs menu> Early USB DBC Type-A Configuration is expanded by default:			
▼ Early USB DBC over Type-A Configuration 5			
Parameter	Value		
Intel(R) ME Boot Stall Enabled	No Boot Stall	This setting enables a delay c	
USB2 DbC port enable	No USB2 Ports	This setting determines whic	
USB Connector's Associated USB3 Port enable	No USB3 Ports	This setting determines whic	
USB2 / USB3 Port 1 DbC AFE Signal Strength	Unused	This setting determines the D	
USB2 / USB3 Port 2 DbC AFE Signal Strength	Unused	This setting determines the D	
USB2 / USB3 Port 3 DbC AFE Signal Strength	Unused	This setting determines the D	
USB2 / USB3 Port 4 DbC AFE Signal Strength	Unused	This setting determines the D	
USB2 / USB3 Port 5 DbC AFE Signal Strength	Unused	This setting determines the D	
USB2 / USB3 Port 6 DbC AFE Signal Strength	Unused	This setting determines the D	
USB2 Port 7 DbC AFE Signal Strength	Unused	This setting determines the D	
USB2 Port 8 DbC AFE Signal Strength	Unused	This setting determines the D	
USB2 Port 9 DbC AFE Signal Strength	Unused	This setting determines the D	
USB2 Port 10 DbC AFE Signal Strength	Unused	This setting determines the D	
#	Parameter	Platform	Settings
5	Early USB DBC Type-A Configuration		
	Intel® ME Boot Stall Enabled This setting enables a delay during Intel® ME FW bring-up to allow USB DCI to be established and Early DbC arbitration to be granted.	ICL-Y ICL-U	No Boot Stall No Boot Stall
	USB2 DbC port enable This setting determines which USB2 ports are enabled for Early DbC debugging.	ICL-Y ICL-U	No USB2 Ports No USB2 Ports
	USB Connectors associated USB3 Port enable This setting determines which USB3 ports goes to the target USB2 ports connector for Early DbC debugging.	ICL-Y ICL-U	No USB3 Ports No USB3 Ports



Table 2-14. - Debug (Sheet 5 of 5)

	USB2 / USB3 Port 1 DbC AFE Signal Strength This setting determines the DbC Analog Front End signal strength for USB2 / USB3 port 1.	ICL-Y ICL-U	Unused Unused
	USB2 / USB3 Port 2 DbC AFE Signal Strength This setting determines the DbC Analog Front End signal strength for USB2 / USB3 port 2.	ICL-Y ICL-U	Unused Unused
	USB2 / USB3 Port 3 DbC AFE Signal Strength This setting determines the DbC Analog Front End signal strength for USB2 / USB3 port 3.	ICL-Y ICL-U	Unused Unused
	USB2 / USB3 Port 4 DbC AFE Signal Strength This setting determines the DbC Analog Front End signal strength for USB2 / USB3 port 4.	ICL-Y ICL-U	Unused Unused
	USB2 / USB3 Port 5 DbC AFE Signal Strength This setting determines the DbC Analog Front End signal strength for USB2 / USB3 port 5.	ICL-Y ICL-U	Unused Unused
	USB2 / USB3 Port 6 DbC AFE Signal Strength This setting determines the DbC Analog Front End signal strength for USB2 / USB3 port 6.	ICL-Y ICL-U	Unused Unused
	USB2 Port 7 DbC AFE Signal Strength This setting determines the DbC Analog Front End signal strength for USB2 port 7.	ICL-Y ICL-U	Unused Unused
	USB2 Port 8 DbC AFE Signal Strength This setting determines the DbC Analog Front End signal strength for USB2 port 8.	ICL-Y ICL-U	Unused Unused
	USB2 Port 9 DbC AFE Signal Strength This setting determines the DbC Analog Front End signal strength for USB2 port 9.	ICL-Y ICL-U	Unused Unused
	USB2 Port 10 DbC AFE Signal Strength This setting determines the DbC Analog Front End signal strength for USB2 port 10.	ICL-Y ICL-U	Unused Unused
Click on Debug in the left tabs menu > eSPI Feature Overrides is expanded by default:			
Parameter		Value	
eSPI / EC Low Frequency Debug Override		No	When enabled this setting will divide eSPI clock frequency by 8.
#	Parameter	Platform	Settings
6	eSPI Feature Overrides		
	eSPI / EC Low Frequency Debug Override When enabled this setting will divide eSPI clock frequency by 8. Note: This setting should only be used for debugging purposes. Leaving this setting enable will impact eSPI performance.	ICL-Y ICL-U	No No



Table 2-15. - CPU Straps (Sheet 1 of 2)

Click on CPU Straps in the left tabs menu > CPU Straps are expanded by default:

▼ CPU Straps 1

Parameter	Value	He
Disable Hyperthreading	No	This setting control enabling / disabling of Hyp
Number of Active Cores	All Cores Active	This setting controls the number of active proc
BIST Initialization	No	This setting determines if BIST will be run at p
Flex Ratio	0x0	This setting controls the maximum processor r
Processor Boot at P1 Frequency	Yes	Processor Boot at P1 Frequency
JTAG Power Disable	No JTAG Power on C10 and Lo...	This setting determines if JTAG power will be r
SVID Presence	SVID is present	This setting determine if SVID rails are presen
Platform IMON Disable	0x1	This strap should be left at the recommended
VCC Aux Present	No	This setting determines if VCC Aux exists as a
VCC IN SVID VR Address	0x0	This setting determines the VCC IN SVID VR Ad
VCC IN SVID VR Type	SVID	This setting determines the VCC IN SVID VR Ty
VCC SFR OC PG Present	No	This setting determines if VCC SFR OC PG is pi
VCC ST PG Present	No	This setting determines if VCC ST PG is preser
VCC STG PG Present	No	This setting determines if VCC STG PG is prese
VCCIN Aux Level LP	1.8v	This setting determines the VCCIN Aux Level LI

#	Parameter	Platform	Settings
1	CPU Straps		
	Disable Hyperthreading Values: Yes/No This setting controls enabling or disabling of Hyper threading. Note: This strap is intended for debugging purposes only. See BIOS Spec for more details on enabling / disabling Hyperthreading.	ICL-Y ICL-U	No No



Table 2-15. - CPU Straps (Sheet 2 of 2)

	Number of Active Cores Values: All, 1, 2, 3, 4, 5, 6, 7, 8 This setting controls the number of active processor cores. Note: This strap is intended for debugging purposes only. See BIOS Spec for more details on enabling or disabling processor cores.	ICL-Y ICL-U	All All
	BIST Initialization Values: Yes/No This setting determines if BIST will be run at platform reset after BIOS requested actions. Note: This strap is intended for debugging purposes only.	ICL-Y ICL-U	No No
	Flex Ratio This setting controls the maximum processor non-turbo ratio. Note: This strap is intended for debugging purposes only. See BIOS Spec for more details on maximum processor non-turbo ratio configuration.	ICL-Y ICL-U	0x0 0x0
	Processor Boot at P1 Frequency Values: Yes/No This setting determines if the processor will operate at maximum frequency at power-on and boot. Note: This strap is intended for debugging purposes only.	ICL-Y ICL-U	Yes Yes
	JTAG Power Disable Values: Yes - JTAG Power on C10 and Lower/No - No Power on C10 and Lower This setting determines if JTAG power will be maintained on C10 or lower power states. Note: This strap is intended for debugging purposes only.	ICL-Y ICL-U	No JTAG Power on C10 and Lower No JTAG Power on C10 and Lower
	SVID Presence Value: SVID Present/SVID Not Present This setting determines if SVID rails are present on the platform. See Processor EDS for details.	ICL-Y ICL-U	SVID Present SVID Present
	Platform IMON This strap should be left at the recommended default setting.	ICL-Y ICL-U	Enabled Enabled
	VCCIN Aux Present Values: Yes/No This setting determines if VCC Aux exists as a separate VR.	ICL-Y ICL-U	No No
	VCCIN SVID Address This setting determines the VCCIN SVID Address. See Processor EDS for details. Note: This strap should be left at the recommended default setting.	ICL-Y ICL-U	0x0 0x0
	VCC SVID VR Type Values: SVID/Fixed VR This setting determines the VCC IN SVID VR Type. See Processor EDS for details.	ICL-Y ICL-U	SVID SVID
	VCC SFR OC PG Present Values: Yes/No This setting determines if VCC SFR OC PG is present on the platform.	ICL-Y ICL-U	No No
	VCC ST PG Present Values: Yes/No This setting determines if VCC ST PG is present on the platform.	ICL-Y ICL-U	No No
	VCC STG PG Present Values: Yes/No This setting determines if VCC STG PG is present on the platform.	ICL-Y ICL-U	No No
	VCCIN Aux Level LP Values: 1.8v/1.65v This setting determines the VCCIN Aux Level LP Voltage. Note: On Y based MCPs this setting can be configured to 1.65v. On all other MCP types set to 1.8v	ICL-Y ICL-U	1.65v or 1.8v 1.8v



Table 2-16. - Flex I/O Straps (Sheet 1 of 17)

Click on Flex I/O in the left tabs menu> Intel® RST for PCIe Configuration is expanded by default:			
▼ Intel(R) RST for PCIe Configuration 1			
Parameter	Value	Help Text	
PCIe Controller 3 Port 1 SRIS Enabled	No	This is used to configure SRIS Port 1 for Intel(R) RST for PCIe on PCIe Controller 3. No	
PCIe Controller 3 Port 2 SRIS Enabled	No	This is used to configure SRIS Port 2 for Intel(R) RST for PCIe on PCIe Controller 3. No	
PCIe Controller 3 Port 3 SRIS Enabled	No	This is used to configure SRIS Port 1 for Intel(R) RST for PCIe on PCIe Controller 3. No	
PCIe Controller 3 Port 4 SRIS Enabled	No	This is used to configure SRIS Port 4 for Intel(R) RST for PCIe on PCIe Controller 3. No	
PCIe Controller 4 Port 1 SRIS Enabled	No	This is used to configure SRIS Port 1 for Intel(R) RST for PCIe on PCIe Controller 4. No	
PCIe Controller 4 Port 2 SRIS Enabled	No	This is used to configure SRIS Port 2 for Intel(R) RST for PCIe on PCIe Controller 4. No	
PCIe Controller 4 Port 3 SRIS Enabled	No	This is used to configure SRIS Port 3 for Intel(R) RST for PCIe on PCIe Controller 4. No	
PCIe Controller 4 Port 4 SRIS Enabled	No	This is used to configure SRIS Port 4 for Intel(R) RST for PCIe on PCIe Controller 4. No	
Intel(R) RST for PCIe-C2 Select x2 or x4	x2	This is used to configure NAND Cycle routers for the Intel(R) RST for PCIe interface as e	
Intel(R) RST for PCIe-C3 Select x2 or x4	x2	This is used to configure NAND Cycle routers for the Intel(R) RST for PCIe interface as e	
Intel® RST for PCIe Controller 2	2x2	This is used to configure PCIe Controller 2 for Intel(R) RST for PCIe interface as either :	
Intel® RST for PCIe Controller 3	2x2	This is used to configure PCIe Controller 4 for Intel(R) RST for PCIe interface as either :	

#	Parameter	Platform	Settings
1	Intel® RST for PCIe Configuration		
	PCIe Controller 3 Port 1 SRIS Enabled Values: Yes/ No - This is used to configure SRIS Port 1 for Intel® RST for PCIe on PCIe Controller 3. Note: Configuration of this setting is only required if the NVM device will be connected external SATA Express cable.	ICL-Y ICL-U	No No
	PCIe Controller 3 Port 2 SRIS Enabled Values: Yes/ No - This is used to configure SRIS Port 2 for Intel® RST for PCIe on PCIe Controller 3. Note: Configuration of this setting is only required if the NVM device will be connected external SATA Express cable.	ICL-Y ICL-U	No No
	PCIe Controller 3 Port 3 SRIS Enabled Values: Yes/ No - This is used to configure SRIS Port 3 for Intel® RST for PCIe on PCIe Controller 3. Note: Configuration of this setting is only required if the NVM device will be connected external SATA Express cable.	ICL-Y ICL-U	No No
	PCIe Controller 3 Port 4 SRIS Enabled Values: Yes/ No - This is used to configure SRIS Port 4 for Intel® RST for PCIe on PCIe Controller 3. Note: Configuration of this setting is only required if the NVM device will be connected external SATA Express cable.	ICL-Y ICL-U	No No



Table 2-16. - Flex I/O Straps (Sheet 2 of 17)

	PCIe Controller 4 Port 1 SRIS Enabled Values: Yes/ No - This is used to configure SRIS Port 1 for Intel® RST for PCIe on PCIe Controller 4. Note: Configuration of this setting is only required if the NVM device will be connected external SATA Express cable.	ICL-Y ICL-U	No No															
	PCIe Controller 4P Port 2 SRIS Enabled Values: Yes/ No - This is used to configure SRIS Port 2 for Intel® RST for PCIe on PCIe Controller 4. Note: Configuration of this setting is only required if the NVM device will be connected external SATA Express cable.	ICL-Y ICL-U	No No															
	PCIe Controller 4 Port 3 SRIS Enabled Values: Yes/ No - This is used to configure SRIS Port 3 for Intel® RST for PCIe on PCIe Controller 4. Note: Configuration of this setting is only required if the NVM device will be connected external SATA Express cable.	ICL-Y ICL-U	No No															
	PCIe Controller 4 Port 4 SRIS Enabled Values: Yes/ No - This is used to configure SRIS Port 4 for Intel® RST for PCIe on PCIe Controller 4. Note: Configuration of this setting is only required if the NVM device will be connected external SATA Express cable.	ICL-Y ICL-U	No No															
	Intel® RST for PCIe-C2 Select x2 or x4 Values: x2, x4 - This is used to configure NAND Cycle routers for the Intel® RST for PCIe interface as either x2 or x4 lane operation on PCIe Controller 2.	ICL-Y ICL-U	x2 x2															
	Intel® RST for PCIe-C3 Select x2 or x4 Values: x2, x4 - This is used to configure NAND Cycle routers for the Intel® RST for PCIe interface as either x2 or x4 lane operation on PCIe Controller 3.	ICL-Y ICL-U	x2 x2															
	Intel® RST for PCIe Controller 2 Values: 1x4, 2x2 - This is used to configure PCIe Controller 2 for Intel® RST for PCIe interface as either x2 or x4 lane operation on PCIe Controller 2.	ICL-Y ICL-U	2x2 2x2															
	Intel® RST for PCIe Controller 3 Values: 1x4, 2x2 - This is used to configure PCIe Controller 3 for Intel® RST for PCIe interface as either x2 or x4 lane operation on PCIe Controller 3.	ICL-Y ICL-U	2x2 2x2															
Click on Flex I/O in the left tabs menu> PCIe Lane Reversal Configuration is expanded by default:																		
▼ PCIe Lane Reversal Configuration 2																		
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 30%;">Parameter</th> <th style="width: 30%;">Value</th> <th style="width: 40%;"></th> </tr> </thead> <tbody> <tr> <td>PCIe Controller 1 Lane Reversal...</td> <td>No</td> <td>This setting allows the PCIe lanes on C</td> </tr> <tr> <td>PCIe Controller 2 Lane Reversal...</td> <td>No</td> <td>This setting allows the PCIe lanes on C</td> </tr> <tr> <td>PCIe Controller 3 Lane Reversal...</td> <td>Yes</td> <td>This setting allows the PCIe lanes on C</td> </tr> <tr> <td>PCIe Controller 4 Lane Reversal...</td> <td>No</td> <td>This setting allows the PCIe lanes on C</td> </tr> </tbody> </table>				Parameter	Value		PCIe Controller 1 Lane Reversal...	No	This setting allows the PCIe lanes on C	PCIe Controller 2 Lane Reversal...	No	This setting allows the PCIe lanes on C	PCIe Controller 3 Lane Reversal...	Yes	This setting allows the PCIe lanes on C	PCIe Controller 4 Lane Reversal...	No	This setting allows the PCIe lanes on C
Parameter	Value																	
PCIe Controller 1 Lane Reversal...	No	This setting allows the PCIe lanes on C																
PCIe Controller 2 Lane Reversal...	No	This setting allows the PCIe lanes on C																
PCIe Controller 3 Lane Reversal...	Yes	This setting allows the PCIe lanes on C																
PCIe Controller 4 Lane Reversal...	No	This setting allows the PCIe lanes on C																
#	Parameter	Platform	Settings															
2	PCIe Lane Reversal Configuration																	
	PCIe Controller 1 Lane Reversal Enabled Values: Yes/ No - This setting allows the PCIe lanes on Controller 1 to be reversed. Note: Refer to EDS for PCIe supported port configurations.	ICL-Y ICL-U	No No															



Table 2-16. - Flex I/O Straps (Sheet 3 of 17)

	PCIe Controller 2 Lane Reversal Enabled Values: Yes/ No - This setting allows the PCIe lanes on Controller 2 to be reversed. Note: Refer to EDS for PCIe supported port configurations.	ICL-Y ICL-U	No No
	PCIe Controller 3 Lane Reversal Enabled Values: Yes/ No - This setting allows the PCIe lanes on Controller 3 to be reversed. Note: Refer to EDS for PCIe supported port configurations.	ICL-Y ICL-U	Yes Yes
	PCIe Controller 4 Lane Reversal Enabled Values: Yes/ No - This setting allows the PCIe lanes on Controller 4 to be reversed. Note: Refer to EDS for PCIe supported port configurations.	ICL-Y ICL-U	No No
Click on Flex I/O in the left tabs menu> PCIe Port Configuration is expanded by default:			
<div style="display: flex; align-items: center;"> ▼ PCIe Port Configuration 3 </div>			
Parameter		Value	
PCIe Controller 1 (Port 1-4)	4x1	This setting controls PCIe Port con	
PCIe Controller 2 (Port 5-8)	1x4	This setting controls PCIe Port con	
PCIe Controller 3 (Port 9-12)	1x4	This setting controls PCIe Port con	
PCIe Controller 4 (Port 13-16)	4x1	This setting controls PCIe Port con	
#	Parameter	Platform	Settings
3	PCIe Port Configuration		
	PCIe Controller 1 (Port 1-4) Values: 4x1, (1x2, 2x1), 2x2, 1x4 - This setting controls PCIe Port configurations for PCIe Controller 1. For further details see Ice Lake LP Platform Controller Hub EDS.	ICL-Y ICL-U	4x1 4x1
	PCIe Controller 2 (Port 5-8) Values: 4x1, (1x2, 2x1), 2x2, 1x4 - This setting controls PCIe Port configurations for PCIe Controller 2. For further details see Ice Lake LP Platform Controller Hub EDS.	ICL-Y ICL-U	1x4 1x4
	PCIe Controller 3 (Port 9-12) Values: 4x1, (1x2, 2x1), 2x2, 1x4 - This setting controls PCIe Port configurations for PCIe Controller 3. For further details see Ice Lake LP Platform Controller Hub EDS.	ICL-Y ICL-U	1x4 1x4
	PCIe Controller 4 (Port 13-16) Values: 4x1, (1x2, 2x1), 2x2, 1x4 - This setting controls PCIe Port configurations for PCIe Controller 4. For further details see Ice Lake LP Platform Controller Hub EDS.	ICL-Y ICL-U	4x1 4x1
Click on Flex I/O in the left tabs menu> SATA / PCIe Combo Port Configuration is expanded by default:			



Table 2-16. - Flex I/O Straps (Sheet 4 of 17)

▼ SATA / PCIe Combo Port Configuration 4			
Parameter	Value		
SATA / PCIe Combo Port 0 Mode Select	PCIe CLKREQ#	The corresponding	
SATA / PCIe Combo Port 1 Mode Select	PCIe CLKREQ#	The corresponding	
SATA / PCIe Combo Port 2 Mode Select	PCIe CLKREQ#	The corresponding	
SATA / PCIe Combo Port 3 Mode Select	PCIe CLKREQ#	The corresponding	
SATA / PCIe Combo Port 0	PCIe	This setting configu	
SATA / PCIe Combo Port 1	GPIO Polarity PCIe	This setting configu	
SATA / PCIe Combo Port 2	PCIe	This setting configu	
SATA / PCIe Combo Port 3	SATA	This setting configu	

#	Parameter	Platform	Settings
4	SATA / PCIe Combo Port Configuration		
	SATA / PCIe Combo Port 0 Mode Select The corresponding CLKREQ# GPIO can only function as DEVSLP# if SATA / PCIe Combo Port 0 is assigned to SATA, and SATA / PCIe Combo Port 0 Mode Select is configured to SATA	ICL-Y ICL-U	PCIe CLKREQ# PCIe CLKREQ#
	SATA / PCIe Combo Port 1 Mode Select The corresponding CLKREQ# GPIO can only function as DEVSLP# if SATA / PCIe Combo Port 1 or Combo Port 2 is assigned to SATA, and SATA / PCIe Combo Port 1 or Combo Port 2 Mode Select is configured to SATA	ICL-Y ICL-U	PCIe CLKREQ# PCIe CLKREQ#
	SATA / PCIe Combo Port 2 Mode Select The corresponding CLKREQ# GPIO can only function as DEVSLP# if SATA / PCIe Combo Port 2 is assigned to SATA, and SATA / PCIe Combo Port 2 Mode Select is configured to SATA <i>Note: Applicable to Premium U SKUs only</i>	ICL-Y ICL-U	PCIe CLKREQ# PCIe CLKREQ#
	SATA / PCIe Combo Port 3 Mode Select The corresponding CLKREQ# GPIO can only function as DEVSLP# if SATA / PCIe Combo Port 3 is assigned to SATA, and SATA / PCIe Combo Port 3 Mode Select is configured to SATA <i>Note: Applicable to Premium U SKUs only</i>	ICL-Y ICL-U	PCIe CLKREQ# PCIe CLKREQ#
	SATA / PCIe Combo Port 0 Values: SATA, PCIe (or GbE), GPIO - This setting configures the PCIe port to operate as either: PCIe Port 11 or SATA Port 0 For further details on Flex I/O see Ice Lake LP Platform Controller Hub EDS.	ICL-Y ICL-U	PCIe PCIe



Table 2-16. - Flex I/O Straps (Sheet 5 of 17)

	<p>SATA / PCIe Combo Port 1 Values: SATA, PCIe (or GbE), GPIO - This setting configures the PCIe port to operate as either: PCIe Port 12 or SATA Port 1 For further details on Flex I/O see Ice Lake LP Platform Controller Hub EDS.</p>	<p>ICL-Y ICL-U</p>	<p>GPIO Polarity PCIe GPIO Polarity PCIe</p>
	<p>SATA / PCIe Combo Port 2 Values: SATA, PCIe (or GbE), GPIO - This setting configures the PCIe port to operate as either: PCIe Port 15 or SATA Port 1 For further details on Flex I/O see Ice Lake LP Platform Controller Hub EDS.</p> <p><i>Note: Applicable to Premium U SKUs only</i></p>	<p>ICL-Y ICL-U</p>	<p>NA PCIe</p>
	<p>SATA / PCIe Combo Port 3 Values: SATA, PCIe (or GbE), GPIO - This setting configures the PCIe port to operate as either: PCIe Port 16 or SATA Port 2 For further details on Flex I/O see Ice Lake LP Platform Controller Hub EDS.</p> <p><i>Note: Applicable to Premium U SKUs only</i></p>	<p>ICL-Y ICL-U</p>	<p>NA SATA</p>
<p>Click on Flex I/O in the left tabs menu> USB3 Port Configuration is expanded by default:</p>			



Table 2-16. - Flex I/O Straps (Sheet 6 of 17)

▼ USB3 Port Configuration 5		
Parameter	Value	
USB3 / PCIe Combo Port 0	USB3	This setting configures the PCIe port to oper
USB3 / PCIe Combo Port 1	USB3	This setting configures the PCIe port to oper
USB3 / PCIe Combo Port 2	PCIe	This setting configures the PCIe port to oper
USB3 / PCIe Combo Port 3	USB3	This setting configures the PCIe port to oper
USB3 / PCIe Combo Port 4	USB3	This setting configures the PCIe port to oper
USB3 / PCIe Combo Port 5	USB3	This setting configures the PCIe port to oper
USB3 Port 1 Connector Type Se...	Type A	This setting configures the physical connecto
USB3 Port 2 Connector Type Se...	Type A	This setting configures the physical connecto
USB3 Port 3 Connector Type Se...	Type A	This setting configures the physical connecto
USB3 Port 4 Connector Type Se...	Type A	This setting configures the physical connecto
USB3 Port 5 Connector Type Se...	Type A	This setting configures the physical connecto
USB3 Port 6 Connector Type Se...	Type A	This setting configures the physical connecto
USB3 Port 1 Initialization Speed...	USB3.1 Gen1 LBPM	This setting determines USB3 Port 1 speed d
USB3 Port 2 Initialization Speed...	USB3.1 Gen1 LBPM	This setting determines USB3 Port 2 speed d
USB3 Port 3 Initialization Speed...	USB3.1 Gen1 LBPM	This setting determines USB3 Port 3 speed d
USB3 Port 4 Initialization Speed...	USB3.1 Gen1 LBPM	This setting determines USB3 Port 4 speed d
USB3 Port 5 Initialization Speed...	USB3.1 Gen1 LBPM	This setting determines USB3 Port 5 speed d
USB3 Port 6 Initialization Speed...	USB3.1 Gen1 LBPM	This setting determines USB3 Port 6 speed d
USB3 Port 1 Speed Capability	USB 3.1 Gen2	This setting determines the USB3 Port 1 spe
USB3 Port 2 Speed Capability	USB 3.1 Gen2	This setting determines the USB3 Port 2 spe
USB3 Port 3 Speed Capability	USB 3.1 Gen2	This setting determines the USB3 Port 3 spe
USB3 Port 4 Speed Capability	USB 3.1 Gen2	This setting determines the USB3 Port 4 spe
USB3 Port 5 Speed Capability	USB 3.1 Gen2	This setting determines the USB3 Port 5 spe
USB3 Port 6 Speed Capability	USB 3.1 Gen2	This setting determines the USB3 Port 6 spe
USB Type AB Mode Select	USB Type AB SW Select	This setting determines how the USB Type A



Table 2-16. - Flex I/O Straps (Sheet 7 of 17)

#	Parameter	Platform	Settings
5	USB3 Port Configuration		
	USB3 / PCIe Combo Port 0 Values: PCIe (or GbE), USB3 - This setting configures the PCIe port to operate as either: PCIe Port 1 or USB3 Port 1 For further details on Flex I/O see Ice Lake LP Platform Controller Hub EDS. <i>Note:</i> If DCI BSSB for this USB3 Combo port it will be Grayed out.	ICL-Y ICL-U	USB3 USB3
	USB3 / PCIe Combo Port 1 Values: PCIe (or GbE), USB3 - This setting configures the PCIe port to operate as either: PCIe Port 2 or USB3 Port 2 For further details on Flex I/O see Ice Lake LP Platform Controller Hub EDS. <i>Note:</i> If DCI BSSB for this USB3 Combo port it will be Grayed out.	ICL-Y ICL-U	USB3 USB3
	USB3 / PCIe Combo Port 2 Values: PCIe (or GbE), USB3 - This setting configures the PCIe port to operate as either: PCIe Port 3 or USB3 Port 3 For further details on Flex I/O see Ice Lake LP Platform Controller Hub EDS. <i>Note:</i> If DCI BSSB for this USB3 Combo port it will be Grayed out.	ICL-Y ICL-U	PCIe PCIe
	USB3 / PCIe Combo Port 3 Values: PCIe (or GbE), USB3 - This setting configures the PCIe port to operate as either: PCIe 4 or USB3 Port 4 For further details on Flex I/O see Ice Lake LP Platform Controller Hub EDS. <i>Note:</i> If DCI BSSB for this USB3 Combo port it will be Grayed out.	ICL-Y ICL-U	PCIe USB3
	USB3 / PCIe Combo Port 4 Values: PCIe (or GbE), USB3 - This setting configures the PCIe port to operate as either: PCIe Port 5 or USB3 Port 5 For further details on Flex I/O see Ice Lake LP Platform Controller Hub EDS. <i>Note:</i> If DCI BSSB for this USB3 Combo port it will be Grayed out.	ICL-Y ICL-U	PCIe PCIe
	USB3 / PCIe Combo Port 5 Values: PCIe (or GbE), USB3 - This setting configures the PCIe port to operate as either: PCIe Port 6 or USB3 Port 6 For further details on Flex I/O see Ice Lake LP Platform Controller Hub EDS. <i>Note:</i> If DCI BSSB for this USB3 Combo port it will be Grayed out.	ICL-Y ICL-U	PCIe PCIe
	USB3 Port 1 Connector Type Select This setting configures the physical connector type to be used for USB 3.1 Port 1.	ICL-Y ICL-U	Type-A Type-A
	USB3 Port 2 Connector Type Select This setting configures the physical connector type to be used for USB 3.1 Port 2.	ICL-Y ICL-U	Type-A Type-A
	USB3 Port 3 Connector Type Select This setting configures the physical connector type to be used for USB 3.1 Port 3.	ICL-Y ICL-U	Type-A Type-A
	USB3 Port 4 Connector Type Select This setting configures the physical connector type to be used for USB 3.1 Port 4.	ICL-Y ICL-U	Type-A Type-A
	USB3 Port 5 Connector Type Select This setting configures the physical connector type to be used for USB 3.1 Port 5.	ICL-Y ICL-U	Type-A Type-A



Table 2-16. - Flex I/O Straps (Sheet 8 of 17)

USB3 Port 6 Connector Type Select This setting configures the physical connector type to be used for USB 3.1 Port 6.	ICL-Y ICL-U	Type-A Type-A
USB3 Port 1 Initialization Speed Select This setting determines USB3 Port 1 speed during platform power-up.	ICL-Y ICL-U	USB3.1 Gen1 LBPM USB3.1 Gen1 LBPM
USB3 Port 2 Initialization Speed Select This setting determines USB3 Port 2 speed during platform power-up.	ICL-Y ICL-U	USB3.1 Gen1 LBPM USB3.1 Gen1 LBPM
USB3 Port 3 Initialization Speed Select This setting determines USB3 Port 3 speed during platform power-up.	ICL-Y ICL-U	USB3.1 Gen1 LBPM USB3.1 Gen1 LBPM
USB3 Port 4 Initialization Speed Select This setting determines USB3 Port 4 speed during platform power-up.	ICL-Y ICL-U	USB3.1 Gen1 LBPM USB3.1 Gen1 LBPM
USB3 Port 5 Initialization Speed Select This setting determines USB3 Port 5 speed during platform power-up.	ICL-Y ICL-U	USB3.1 Gen1 LBPM USB3.1 Gen1 LBPM
USB3 Port 6 Initialization Speed Select This setting determines USB3 Port 6 speed during platform power-up.	ICL-Y ICL-U	USB3.1 Gen1 LBPM USB3.1 Gen1 LBPM
USB3 Port 1 Speed Capability This setting determines the USB3 Port 1 speed capabilities.	ICL-Y ICL-U	USB 3.1 Gen2 USB 3.1 Gen2
USB3 Port 2 Speed Capability This setting determines the USB3 Port 2 speed capabilities.	ICL-Y ICL-U	USB 3.1 Gen2 USB 3.1 Gen2
USB3 Port 3 Speed Capability This setting determines the USB3 Port 3 speed capabilities.	ICL-Y ICL-U	USB 3.1 Gen2 USB 3.1 Gen2
USB3 Port 4 Speed Capability This setting determines the USB3 Port 4 speed capabilities.	ICL-Y ICL-U	USB 3.1 Gen2 USB 3.1 Gen2
USB3 Port 5 Speed Capability This setting determines the USB3 Port 5 speed capabilities.	ICL-Y ICL-U	USB 3.1 Gen2 USB 3.1 Gen2
USB3 Port 6 Speed Capability This setting determines the USB3 Port 6 speed capabilities.	ICL-Y ICL-U	USB 3.1 Gen2 USB 3.1 Gen2
USB Type AB Mode Select This setting determines how the USB Type AB connector switching is handled.	ICL-Y ICL-U	USB Type AB SW Select USB Type AB SW Select

Click on Flex I/O in the left tabs menu> USB2 Port Configuration is expanded by default:

▼ **USB2 Port Configuration**



Parameter	Value	
USB2 Port 1 Connector Type Select	Type A / Type C	This setting configures the p
USB2 Port 2 Connector Type Select	Express Card / M.2 S2	This setting configures the p
USB2 Port 3 Connector Type Select	Express Card / M.2 S2	This setting configures the p
USB2 Port 4 Connector Type Select	Type C	This setting configures the p
USB2 Port 5 Connector Type Select	Type C	This setting configures the p
USB2 Port 6 Connector Type Select	Type C	This setting configures the p
USB2 Port 7 Connector Type Select	Type C	This setting configures the p
USB2 Port 8 Connector Type Select	Type A / Type C	This setting configures the p
USB2 Port 9 Connector Type Select	Type A / Type C	This setting configures the p
USB2 Port 10 Connector Type Select	Type A / Type C	This setting configures the p



Table 2-16. - Flex I/O Straps (Sheet 9 of 17)

#	Parameter	Platform	Settings
6	USB2 Port Configuration		
	USB2 Port 1 Connector Type This setting configures the physical connector type to be used for USB2 Port 1.	ICL-Y ICL-U	Type-A Type-A
	USB2 Port 2 Connector Type This setting configures the physical connector type to be used for USB2 Port 2.	ICL-Y ICL-U	Express Card / M.2 S2 Express Card / M.2 S2
	USB2 Port 3 Connector Type This setting configures the physical connector type to be used for USB2 Port 3.	ICL-Y ICL-U	Express Card / M.2 S2 Express Card / M.2 S2
	USB2 Port 4 Connector Type This setting configures the physical connector type to be used for USB2 Port 4.	ICL-Y ICL-U	Type-C Type-C
	USB2 Port 5 Connector Type This setting configures the physical connector type to be used for USB2 Port 5.	ICL-Y ICL-U	Type-C Type-C
	USB2 Port 6 Connector Type This setting configures the physical connector type to be used for USB2 Port 6.	ICL-Y ICL-U	Type-C Type-C
	USB2 Port 7 Connector Type This setting configures the physical connector type to be used for USB2 Port 7.	ICL-Y ICL-U	Type-A / Type-C Type-C
	USB2 Port 8 Connector Type This setting configures the physical connector type to be used for USB2 Port 8.	ICL-Y ICL-U	Type-A / Type-C Type-A / Type-C
	USB2 Port 9 Connector Type This setting configures the physical connector type to be used for USB2 Port 9.	ICL-Y ICL-U	Type-A / Type-C Type-A / Type-C
	USB2 Port 10 Connector Type This setting configures the physical connector type to be used for USB2 Port 10.	ICL-Y ICL-U	Type-A / Type-C Type-A / Type-C
Click on Flex I/O in the left tabs menu > Type-C Subsystem Configuration is expanded by default:			



Table 2-16. - Flex I/O Straps (Sheet 10 of 17)

▼ Type-C Subsystem Configuration 7			
Parameter		Value	
IO Manageability Engine Binary File		This loads the Type-C Subsystem IO Manageability Engine binary.	
IO Manageability Engine Length	0x11000	Set the length of IOM sub partition.	
IO Manageability Engine version		-	
IO Manageability Engine OEM configuration Binary File		This loads the Type-C Subsystem IO Manageability Engine OEM configuration binary.	
PHY Binary File		This loads the Type-C Subsystem PHY binary that will be merged with the IOM binary.	
PHY Length	0x8000	Set the length of sub partition.	
PHY version		-	
Thunderbolt(TM) Binary File		This loads the Type-C Subsystem Thunderbolt(TM) binary that will be merged with the IOM binary.	
Thunderbolt(TM) Length	0x40000	Set the length of Thunderbolt(TM) sub partition.	
Thunderbolt version		-	
Tcss - Partial Update Enabled	Disabled	This setting enables partial update for TCSS partitions	
Type-C Subsystem Port Enable Mask	0xF	This setting determines the Type-C Subsystem Port Enable Mask.	
Type-C Port 1 Configuration	No Restrictions	This setting determines the configuration of Type-C Port 1.	
Type-C Port 2 Configuration	No Restrictions	This setting determines the configuration of Type-C Port 2.	
Type-C Port 3 Configuration	No Restrictions	This setting determines the configuration of Type-C Port 3.	
Type-C Port 4 Configuration	No Restrictions	This setting determines the configuration of Type-C Port 4.	
Type-C Port 1 Speed Capability	USB 3.1 Gen2	This setting determines the Type-C Port 1 speed capabilities.	
Type-C Port 2 Speed Capability	USB 3.1 Gen2	This setting determines the Type-C Port 2 speed capabilities.	
Type-C Port 3 Speed Capability	USB 3.1 Gen2	This setting determines the Type-C Port 3 speed capabilities.	
Type-C Port 4 Speed Capability	USB 3.1 Gen2	This setting determines the Type-C Port 4 speed capabilities.	
Type-C Port 1 Initialization Speed Select	USB3.1 Gen1 LBPM	This setting determines Type-C Port 1 speed during platform power up.	
Type-C Port 2 Initialization Speed Select	USB3.1 Gen1 LBPM	This setting determines Type-C Port 2 speed during platform power up.	
Type-C Port 3 Initialization Speed Select	USB3.1 Gen1 LBPM	This setting determines Type-C Port 3 speed during platform power up.	
Type-C Port 4 Initialization Speed Select	USB3.1 Gen1 LBPM	This setting determines Type-C Port 4 speed during platform power up.	
xDCI Split Die Configuration	xDCI Split Die Enabled	This setting determines if xDCI Split die configuration is enabled.	

#	Parameter	Platform	Settings
7	Type-C Subsystem Configuration		



Table 2-16. - Flex I/O Straps (Sheet 11 of 17)

	IO Manageability Engine Binary File - This loads the IO Manageability binary that will be merged into the output image generated by the Intel® FIT.	ICL-Y ICL-U	IOM Binary IOM Binary
	IO Manageability Engine Length		
	IO Manageability Engine version		
	IO Manageability Engine OEM configuration Binary File - This loads the Type-C Subsystem IO Manageability Engine OEM Configuration binary that will be written to the OEM config data section.	ICL-Y ICL-U	OEM Config Binary OEM Config Binary
	PHY Binary File - This loads the PHY binary that will be merged into the output image generated by the Intel® FIT.	ICL-Y ICL-U	PHY Binary PHY Binary
	PHY Length		
	PHY Version		
	Thunderbolt™ Binary File Values: Yes/No This setting enables Anti-Roll back for the Type-C Subsystem Thunderbolt™ binary.	ICL-Y ICL-U	TBT Binary TBT Binary
	Thunderbolt™ Length		
	Thunderbolt™ Version		
	Tcss - Partial Update Enabled Values: Enabled/Disabled This setting enabled partial firmware update of the TCSS partitions.	ICL-Y ICL-U	Disabled Disabled
	Type-C Subsystem Port Enable Mask This setting determines the Type-C Subsystem Port Enable Mask	ICL-Y ICL-U	0x3F 0x3F
	Type-C Subsystem Authentication Enabled Values: Yes/No This setting enables / disables firmware authentication for the Type-C Subsystem on power-up.	ICL-Y ICL-U	Yes Yes
	Type-C Port 1 Configuration Value: No Restrictions/DP Fixed Connection/No Thunderbolt This setting determines the configuration for Type-C Port 1	ICL-Y ICL-U	No Restrictions No Restrictions
	Type-C Port 2 Configuration Value: No Restrictions/DP Fixed Connection/No Thunderbolt This setting determines the configuration for Type-C Port 2	ICL-Y ICL-U	No Restrictions No Restrictions
	Type-C Port 3 Configuration Value: No Restrictions/DP Fixed Connection/No Thunderbolt This setting determines the configuration for Type-C Port 3	ICL-Y ICL-U	No Restrictions No Restrictions
	Type-C Port 4 Configuration Value: No Restrictions/DP Fixed Connection/No Thunderbolt This setting determines the configuration for Type-C Port 4	ICL-Y ICL-U	No Restrictions No Restrictions
	Type-C Port 1 Speed Capability Values: USB 3.1 Gen2/USB 3.1 Gen1 This setting determines the Type-C Port 1 speed capability	ICL-Y ICL-U	USB 3.1 Gen2 USB 3.1 Gen2
	Type-C Port 2 Speed Capability Values: USB 3.1 Gen2/USB 3.1 Gen1 This setting determines the Type-C Port 2 speed capability	ICL-Y ICL-U	USB 3.1 Gen2 USB 3.1 Gen2
	Type-C Port 3 Speed Capability Values: USB 3.1 Gen2/USB 3.1 Gen1 This setting determines the Type-C Port 3 speed capability	ICL-Y ICL-U	USB 3.1 Gen2 USB 3.1 Gen2
	Type-C Port 4 Speed Capability Values: USB 3.1 Gen2/USB 3.1 Gen1 This setting determines the Type-C Port 4 speed capability	ICL-Y ICL-U	USB 3.1 Gen2 USB 3.1 Gen2
	Type-C Port 1 Initialization Speed Select Values: USB3.1 Gen1 LBPM/USB3.1 Gen2 skip LBPM This setting determines Type-C Port 1 speed during platform power-up.	ICL-Y ICL-U	USB3.1 Gen1 LBPM USB3.1 Gen1 LBPM
	Type-C Port 2 Initialization Speed Select Values: USB3.1 Gen1 LBPM/USB3.1 Gen2 skip LBPM This setting determines Type-C Port 2 speed during platform power-up.	ICL-Y ICL-U	USB3.1 Gen1 LBPM USB3.1 Gen1 LBPM



Table 2-16. - Flex I/O Straps (Sheet 12 of 17)

	Type-C Port 3 Initialization Speed Select Values: USB3.1 Gen1 LBPM/USB3.1 Gen2 skip LBPM This setting determines Type-C Port 3 speed during platform power-up.	ICL-Y ICL-U	USB3.1 Gen1 LBPM USB3.1 Gen1 LBPM						
	Type-C Port 4 Initialization Speed Select Values: USB3.1 Gen1 LBPM/USB3.1 Gen2 skip LBPM This setting determines Type-C Port 4 speed during platform power-up.	ICL-Y ICL-U	USB3.1 Gen1 LBPM USB3.1 Gen1 LBPM						
	xDCI Split Die Configuration Values: xDCI Split Die Enabled / xDCI Split Die Disabled This setting determines if xDCI Split Die Configuration is enabled / disabled on the platform.	ICL-Y ICL-U	xDCI Split Die Enabled xDCI Split Die Enabled						
Click on Flex I/O in the left tabs menu> Thunderbolt Configuration is expanded by default:									
<p>▼ Thunderbolt Configuration 8</p> <hr/> <table border="1"> <thead> <tr> <th>Parameter</th> <th>Value</th> <th></th> </tr> </thead> <tbody> <tr> <td>Thunderbolt Enable</td> <td>Yes</td> <td>This setting determines if the</td> </tr> </tbody> </table>				Parameter	Value		Thunderbolt Enable	Yes	This setting determines if the
Parameter	Value								
Thunderbolt Enable	Yes	This setting determines if the							
#	Parameter	Platform	Settings						
8	Thunderbolt Configuration								
	Thunderbolt Enable Values: Yes/No This setting determines if the Thunderbolt ^(tm) interface is enabled on the platform.	ICL-Y ICL-U	Yes Yes						
Click on Flex I/O in the left tabs menu> UFS Storage Configuration is expanded by default:									
<p>▼ UFS Storage Configuration 9</p> <hr/> <table border="1"> <thead> <tr> <th>Parameter</th> <th>Value</th> <th></th> </tr> </thead> <tbody> <tr> <td>UFS Configuration</td> <td>None</td> <td>This setting configures UFS sortage for ></td> </tr> </tbody> </table>				Parameter	Value		UFS Configuration	None	This setting configures UFS sortage for >
Parameter	Value								
UFS Configuration	None	This setting configures UFS sortage for >							
#	Parameter	Platform	Settings						
9	UFS Storage Configuration								
	UFS Configuration Leave settings at Intel® FIT default values	ICL-Y ICL-U	None None						
Click on Flex I/O in the left tabs menu> Power Delivery PD Controller Configuration is expanded by default:									



Table 2-16. - Flex I/O Straps (Sheet 13 of 17)

▼ Power Delivery PD Controller Configuration 10		
Parameter	Value	
PMC-PD controller USB-C Mode Enabled	PMC / SMBus	This bit defines how the PMC interfaces with the typ
Re-timer Power Gating Enabled	No	Indicates whether platform Re-timer power gating is
Type-C port 1 Enabled	Yes	Indicates whether the associated Type-C port is ena
USB2 Port Number associated for Type-C Port 1	USB2 Port 5	USB2 port number for the associated Type-C port
USB3 Port Number associated for Type-C Port 1	USB3 Port 2	USB3 port number for the associated Type-C port
Type-C Port 1 Re-Timer Present	Yes	Indicates whether a re-timer is present for the asso
Type-C Port 1 Re-timer Configuration Enabled	No	Indicates whether the associated re-timer requires c
Type-C Port 1 Re-timer SMBus Address	0x40	SMBus address for the associated re-timer.
Type C Port 1 SMBus Address	0x50	SMBus address for the associated type C port
Type-C port 2 Enabled	Yes	Indicates whether the associated Type-C port is ena
USB2 Port Number associated for Type-C Port 2	USB2 Port 6	USB2 port number for the associated Type-C port
USB3 Port Number associated for Type-C Port 2	USB3 Port 3	USB3 port number for the associated Type-C port
Type-C Port 2 Re-Timer Present	Yes	Indicates whether a re-timer is present for the asso
Type-C Port 2 Re-timer Configuration Enabled	No	Indicates whether the associated re-timer requires c
Type-C Port 2 Re-timer SMBus Address	0x41	SMBus address for the associated re-timer
Type-C Port 2 SMBus Address	0x51	SMBus address for the associated Type-C port
Type-C port 3 Enabled	Yes	Indicates whether the associated Type-C port is ena
USB2 Port Number associated for Type-C Port 3	USB2 Port 7	USB2 port number for the associated Type-C port
USB3 Port Number associated for Type-C Port 3	USB3 Port 4	USB3 port number for the associated Type-C port
Type-C Port 3 Re-Timer Present	Yes	Indicates whether a re-timer is present for the asso
Type-C Port 3 Re-timer Configuration Enabled	No	Indicates whether the associated re-timer requires c
Type-C Port 3 Re-timer SMBus Address	0x42	SMBus address for the associated re-timer
Type-C Port 3 SMBus Address	0x52	SMBus address for the associated Type-C port
Type-C port 4 Enabled	Yes	Indicates whether the associated Type-C port is ena
USB2 Port Number associated for Type-C Port 4	USB2 Port 8	USB2 port number for the associated Type-C port
USB3 Port Number associated for Type-C Port 4	USB3 Port 5	USB3 port number for the associated Type-C port
Type-C Port 4 Re-Timer Present	Yes	Indicates whether a re-timer is present for the asso
Type-C Port 4 Re-timer Configuration Enabled	No	Indicates whether the associated re-timer requires c
Type-C Port 4 Re-timer SMBus Address	0x0	SMBus address for the associated re-timer
Type-C Port 4 SMBus Address	0x53	SMBus address for the associated Type-C port
10	Power Delivery PD Controller Configuration	



Table 2-16. - Flex I/O Straps (Sheet 14 of 17)

	<p>PMC-PD controller USB-C Mode Enabled Values: 0: PMC interfaces with an eSPI connected agent via eSPI OOB 1: PMC interfaces with PD chips/Re-timer via ALERT# pin which triggers SMBus transactions.</p> <p>This bit defines how the PMC interfaces with the Type-C components on the board.</p> <p>Notes: 1. This setting is greyed and not configurable for LP based SKUs. for LP SKUs, PMC interfaces with PD chips/Re-timer via ALERT# pin. 2. if user selection is 0 where PMC interfaces with an eSPI connected agent, all of the below parameters are N/A and will be grayed out.</p>	ICL-Y ICL-U	PMC / SMBus PMC / SMBus
	<p>Re-timer Power Gating Enabled Values: Yes / No This setting indicates whether platform Re-timer power gating is enabled.</p>	ICL-Y ICL-U	Yes Yes
	<p>Type-C port 1 Enabled Values: Yes / No This setting indicates whether the associated Type-C port1 is enabled.</p> <p>Note: This setting is only available for configuration when PMC-PD controller USB-C Mode Enabled parameter is set to 1.</p>	ICL-Y ICL-U	Yes Yes
	<p>USB2 Port Number associated for Type-C Port 1 Values: USB2 Port 1,USB2 Port 2,USB2 Port 3,USB2 Port 4,USB2 Port 5,USB2 Port 6,USB2 Port 7,USB2 Port 8,USB2 Port 9,USB2 Port 10 This indicates the USB2 port number for the associated Type-C port1.</p> <p>Notes: 1. This parameter is applicable only when Type-C port 1 Enabled is set to yes. 2. Once user selects USB2 port number associated with Type-C port1,the respective USB2 port connector selection will be greyed out and auto set to Type-C under the USB2 Port Configuration section. example: if USB2 Port number associated for Type-C Port 1 is set to "USB2 Port 2" ,Parameter under Flex I/O->USB2 Port Configuration->USB2 Port 2 Connector Type Select will be grayed out and auto set to "Type C". 3. OEMs are recommended to configure different USB-C connectors with increasing port numbers (TCP0_*, TCP1_*, TCP2_*, TCP3_*), should be paired with increasing number of USB2 ports from PCH. (this is needed to make split xDCI controller work functionally)E.g. (TCP0_*, USB2*_1), (TCP1_*, USB2*_3), (TCP2_*, USB2*_4), (TCP3_*, USB2*_5)</p>	ICL-Y ICL-U	USB2 Port 4 USB2 Port 4
	<p>USB3 Port number associated for Type-C Port 1 Values: USB3 Port 1,USB3 Port 2,USB3 Port 3,USB3 Port 4 This indicates the USB3 port number for the associated Type-C port1.</p> <p>Notes: 1. This parameter is applicable only when Type-C port 1 Enabled is set to yes. 2. Once user selects USB3 port number associated with Type-C port1,the respective USB3 port connector selection will be greyed out and auto set to Type-C under the USB3 Port Configuration section. example: if USB Port number associated for Type-C Port 1 is set to "USB3 Port 6" ,Parameter under Flex I/O->USB3 Port Configuration->USB3 Port 6 Connector Type Select will be grayed out and auto set to "Type C". 3. OEMs are recommended to configure different USB-C connectors with increasing port numbers (TCP0_*, TCP1_*, TCP2_*, TCP3_*), should be paired with increasing number of USB2 ports from PCH. (this is needed to make split xDCI controller work functionally)E.g. (TCP0_*, USB2*_1), (TCP1_*, USB2*_3), (TCP2_*, USB2*_4), (TCP3_*, USB2*_5)</p>	ICL-Y ICL-U	USB3 Port 1 USB3 Port 1
	<p>Type-C Port 1 Re-timer Present Values: Yes / No This indicates whether a re-timer is present for the associated Type-C port.</p>	ICL-Y ICL-U	Yes Yes



Table 2-16. - Flex I/O Straps (Sheet 15 of 17)

	Type-C Port 1 Re-timer Configuration Enabled Values: Yes / No Indicates whether the associated re-timer requires configuration. Yes = configuration done via PMC; No = configuration done via PD Controller.	ICL-Y ICL-U	Yes No
	Type-C Port 1 Re-timer SMBus Address Value: Hex This indicates the SMBus address for the associated re-timer.	ICL-Y ICL-U	0x40 0x40
	Type-C Port 1 SMBus Address Value: Hex This indicates the SMBus address for the associated Type-C port. <i>Note:</i> OEMs are recommended to set unique SMBus address allocation for Type-C port and Re-timer associated.	ICL-Y ICL-U	0x20 0x50
	Type-C port 2 Enabled Values: Yes / No This setting indicates whether the associated Type-C port is enabled. <i>Note:</i> This setting is only available for configuration when PMC-PD controller USB-C Mode Enabled parameter is set to 1.	ICL-Y ICL-U	Yes Yes
	USB2 Port Number associated for Type-C Port 2 Values: USB2 Port 1,USB2 Port 2,USB2 Port 3,USB2 Port 4,USB2 Port 5,USB2 Port 6,USB2 Port 7,USB2 Port 8,USB2 Port 9,USB2 Port 10 This indicates the USB2 port number for the associated Type-C port. <i>Notes:</i> <ol style="list-style-type: none"> This parameter is applicable only when Type-C port 2 Enabled is set to yes. Once user selects USB2 port number associated with Type-C port2,the respective USB2 port connector selection will be greyed out and auto set to Type-C under the USB2 Port Configuration section. example: if USB2 Port number associated for Type-C Port 2 is set to "USB2 Port 2" ,Parameter under Flex I/O->USB2 Port Configuration->USB2 Port 2 Connector Type Select will be grayed out and auto set to "Type C". OEMs are recommended to configure different USB-C connectors with increasing port numbers (TCP0_*, TCP1_*, TCP2_*, TCP3_*), should be paired with increasing number of USB2 ports from PCH. (this is needed to make split xDCI controller work functionally)E.g. (TCP0_* , USB2*_1), (TCP1_* , USB2*_3), (TCP2_* , USB2*_4), (TCP3_* , USB2*_5) 	ICL-Y ICL-U	USB2 Port 5 USB2 Port 5
	USB3 Port number associated for Type-C Port 2 Values: USB3 Port 1,USB3 Port 2,USB3 Port 3,USB3 Port 4 This indicates the USB3 port number for the associated Type-C port. <i>Notes:</i> <ol style="list-style-type: none"> This parameter is applicable only when Type-C port 2Enabled is set to yes. Once user selects USB3 port number associated with Type-C port2,the respective USB3 port connector selection will be greyed out and auto set to Type-C under the USB3 Port Configuration section. example: if USB Port number associated for Type-C Port 2is set to "USB3 Port 6" ,Parameter under Flex I/O->USB3 Port Configuration->USB3 Port 6 Connector Type Select will be grayed out and auto set to "Type C". OEMs are recommended to configure different USB-C connectors with increasing port numbers (TCP0_*, TCP1_*, TCP2_*, TCP3_*), should be paired with increasing number of USB2 ports from PCH. (this is needed to make split xDCI controller work functionally)E.g. (TCP0_* , USB2*_1), (TCP1_* , USB2*_3), (TCP2_* , USB2*_4), (TCP3_* , USB2*_5) 	ICL-Y ICL-U	USB3 Port 2 USB3 Port 2
	Type-C Port 2 Re-timer Present Values: Yes / No This indicates whether a re-timer is present for the associated Type-C port.	ICL-Y ICL-U	Yes Yes
	Type-C Port 2 Re-timer Configuration Enabled Values: Yes / No Indicates whether the associated re-timer requires configuration. Yes = configuration done via PMC; No = configuration done via PD Controller.	ICL-Y ICL-U	Yes No



Table 2-16. - Flex I/O Straps (Sheet 16 of 17)

	Type-C Port 2 Re-timer SMBus Address Value: Hex This indicates the SMBus address for the associated re-timer.	ICL-Y ICL-U	0x41 0x41
	Type-C Port 2 SMBus Address Value: Hex This indicates the SMBus address for the associated Type-C port. <i>Note:</i> OEMs are recommended to set unique SMBus address allocation for Type-C port and Re-timer associated.	ICL-Y ICL-U	0x24 0x51
	Type-C port 3 Enabled Values: Yes / No This setting indicates whether the associated Type-C port is enabled. <i>Note:</i> This setting is only available for configuration when PMC-PD controller USB-C Mode Enabled parameter is set to 1.	ICL-Y ICL-U	Yes Yes
	USB2 Port Number associated for Type-C Port 3 Values: USB2 Port 1,USB2 Port 2,USB2 Port 3,USB2 Port 4,USB2 Port 5,USB2 Port 6,USB2 Port 7,USB2 Port 8,USB2 Port 9,USB2 Port 10 This indicates the USB2 port number for the associated Type-C port. <i>Notes:</i> <ol style="list-style-type: none"> This parameter is applicable only when Type-C port 3 Enabled is set to yes. Once user selects USB2 port number associated with Type-C port3 ,the respective USB2 port connector selection will be greyed out and auto set to Type-C under the USB2 Port Configuration section. example: if USB2 Port number associated for Type-C Port 3 is set to "USB2 Port 2" ,Parameter under Flex I/O->USB2 Port Configuration->USB2 Port 2 Connector Type Select will be grayed out and auto set to "Type C". OEMs are recommended to configure different USB-C connectors with increasing port numbers (TCP0_*, TCP1_*, TCP2_*, TCP3_*), should be paired with increasing number of USB2 ports from PCH. (this is needed to make split xDCI controller work functionally)E.g. (TCP0_*, USB2*_1), (TCP1_*, USB2*_3), (TCP2_*, USB2*_4), (TCP3_*, USB2*_5) 	ICL-Y ICL-U	USB2 Port 6 USB2 Port 6
	USB3 Port number associated for Type-C Port 3 Values: USB3 Port 1,USB3 Port 2,USB3 Port 3,USB3 Port 4 This indicates the USB3 port number for the associated Type-C port. <i>Notes:</i> <ol style="list-style-type: none"> This parameter is applicable only when Type-C port 3 Enabled is set to yes. Once user selects USB3 port number associated with Type-C port3 ,the respective USB3 port connector selection will be greyed out and auto set to Type-C under the USB3 Port Configuration section. example: if USB Port number associated for Type-C Port 3 is set to "USB3 Port 6" ,Parameter under Flex I/O->USB3 Port Configuration->USB3 Port 6 Connector Type Select will be grayed out and auto set to "Type C". OEMs are recommended to configure different USB-C connectors with increasing port numbers (TCP0_*, TCP1_*, TCP2_*, TCP3_*), should be paired with increasing number of USB2 ports from PCH. (this is needed to make split xDCI controller work functionally)E.g. (TCP0_*, USB2*_1), (TCP1_*, USB2*_3), (TCP2_*, USB2*_4), (TCP3_*, USB2*_5) 	ICL-Y ICL-U	USB3 Port 3 USB3 Port 3
	Type-C Port 3 Re-timer Present Values: Yes / No This indicates whether a re-timer is present for the associated Type-C port.	ICL-Y ICL-U	Yes Yes
	Type-C Port 3 Re-timer Configuration Enabled Values: Yes / No Indicates whether the associated re-timer requires configuration. Yes = configuration done via PMC; No = configuration done via PD Controller.	ICL-Y ICL-U	Yes No
	Type-C Port 3 Re-timer SMBus Address Value: Hex This indicates the SMBus address for the associated re-timer.	ICL-Y ICL-U	0x42 0x42



Table 2-16. - Flex I/O Straps (Sheet 17 of 17)

Type-C Port 3 SMBus Address Value: Hex This indicates the SMBus address for the associated Type-C port. <i>Note:</i> OEMs are recommended to set unique SMBus address allocation for Type-C port and Re-timer associated.	ICL-Y ICL-U	0x23 0x52
Type-C port 4 Enabled Values: Yes / No This setting indicates whether the associated Type-C port is enabled. <i>Note:</i> This setting is only available for configuration when PMC-PD controller USB-C Mode Enabled parameter is set to 1.	ICL-Y ICL-U	Yes Yes
USB2 Port Number associated for Type-C Port 4 Values: USB2 Port 1,USB2 Port 2,USB2 Port 3,USB2 Port 4,USB2 Port 5,USB2 Port 6,USB2 Port 7,USB2 Port 8,USB2 Port 9,USB2 Port 10 This indicates the USB2 port number for the associated Type-C port. <i>Notes:</i> 1. This parameter is applicable only when Type-C port 4 Enabled is set to yes. 2. Once user selects USB2 port number associated with Type-C port4,the respective USB2 port connector selection will be greyed out and auto set to Type-C under the USB2 Port Configuration section. example: if USB2 Port number associated for Type-C Port 4 is set to "USB2 Port 2" ,Parameter under Flex I/O->USB2 Port Configuration->USB2 Port 2 Connector Type Select will be grayed out and auto set to "Type C". 3. OEMs are recommended to configure different USB-C connectors with increasing port numbers (TCP0_*, TCP1_*, TCP2_*, TCP3_*), should be paired with increasing number of USB2 ports from PCH. (this is needed to make split xDCI controller work functionally)E.g. (TCP0_*, USB2*_1), (TCP1_*, USB2*_3), (TCP2_*, USB2*_4), (TCP3_*, USB2*_5)	ICL-Y ICL-U	USB2 Port 7 USB2 Port 7
USB3 Port number associated for Type-C Port 4 Values: USB3 Port 1,USB3 Port 2,USB3 Port 3,USB3 Port 4 This indicates the USB3 port number for the associated Type-C port. <i>Notes:</i> 1. This parameter is applicable only when Type-C port 4 Enabled is set to yes. 2. Once user selects USB3 port number associated with Type-C port4,the respective USB3 port connector selection will be greyed out and auto set to Type-C under the USB3 Port Configuration section. example: if USB Port number associated for Type-C Port 4 is set to "USB3 Port 6" ,Parameter under Flex I/O->USB3 Port Configuration->USB3 Port 6 Connector Type Select will be grayed out and auto set to "Type C". 3. OEMs are recommended to configure different USB-C connectors with increasing port numbers (TCP0_*, TCP1_*, TCP2_*, TCP3_*), should be paired with increasing number of USB2 ports from PCH. (this is needed to make split xDCI controller work functionally)E.g. (TCP0_*, USB2*_1), (TCP1_*, USB2*_3), (TCP2_*, USB2*_4), (TCP3_*, USB2*_5)	ICL-Y ICL-U	USB3 Port 4 USB3 Port 4
Type-C Port 4 Re-timer Present Values: Yes / No This indicates whether a re-timer is present for the associated Type-C port.	ICL-Y ICL-U	Yes Yes
Type-C Port 4 Re-timer Configuration Enabled Values: Yes / No Indicates whether the associated re-timer requires configuration. Yes = configuration done via PMC; No = configuration done via PD Controller.	ICL-Y ICL-U	No No
Type-C Port 4 Re-timer SMBus Address Value: Hex This indicates the SMBus address for the associated re-timer.	ICL-Y ICL-U	0x43 0x43
Type-C Port 4 SMBus Address Value: Hex This indicates the SMBus address for the associated Type-C port. <i>Note:</i> OEMs are recommended to set unique SMBus address allocation for Type-C port and Re-timer associated.	ICL-Y ICL-U	0x53 0x53



Table 2-17. - GPIO (Sheet 1 of 17)

Click on GPIO in the left tabs menu> LAN / GPIO Select is expanded by default:

LAN / GPIO Select 1

Parameter	Value	Help Text
LAN PHY Power Control GPD11 ...	Enable as LANPHYPC	-

#	Parameter	Platform	Settings
1	LAN / GPIO Select		
	LAN PHY Power Control GPD11 Signal Configuration	ICL-Y ICL-U	LANPHYPC LANPHYPC

Click on GPIO in the left tabs menu> WLAN / GPIO Select is expanded by default:

WLAN / GPIO Select 2

Parameter	Value	Help Text
SLP_WLAN# / GDP9 Signal Con...	Enable as SLP_WLAN#	-

#	Parameter	Platform	Settings
2	WLAN / GPIO Select		
	SLP_WLAN# / GDP9 Signal Configuration	ICL-Y ICL-U	SLP_WLAN# SLP_WLAN#

Click on GPIO in the left tabs menu> Platform Power / GPIO is expanded by default:

Platform Power / GPIO 3

Parameter	Value	Help Text
SLP_A# / GPD6 Signal Configur...	SLP_A#	-
SLP_S3# / GPD4 Signal Configu...	SLP_S3#	-
SLP_S4# / GPD5 Signal Configu...	SLP_S4#	-
SLP_S5# / GPD10 Signal Config...	SLP_S5#	-

#	Parameter	Platform	Settings



Table 2-17. - GPIO (Sheet 2 of 17)

3	Platform Power / GPIO																														
	SLP_A# / GPD6 Signal Configuration	ICL-Y ICL-U	SLP_A# SLP_A#																												
	SLP_S3# / GPD4 Signal Configuration	ICL-Y ICL-U	SLP_S3# SLP_S3#																												
	SLP_S4# / GPD5 Signal Configuration	ICL-Y ICL-U	SLP_S4# SLP_S4#																												
	SLP_S5# / GPD10 Signal Configuration	ICL-Y ICL-U	SLP_S5# SLP_S5#																												
Click on GPIO in the left tabs menu> ME Feature Pins is expanded by default:																															
<div style="display: flex; justify-content: space-between; align-items: center;"> ▼ ME Feature Pins 4 </div> <hr style="border: 1px solid yellow;"/> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 50%;">Parameter</th> <th style="width: 20%;">Value</th> <th style="width: 30%;"></th> </tr> </thead> <tbody> <tr> <td>Intel(R) Precise Touch and Stylus Reset GPIO Select</td> <td>None</td> <td>Configure Intel(R) Precise</td> </tr> <tr> <td>Intel(R) Precise Touch and Stylus Interrupt GPIO Select</td> <td>None</td> <td>Configure Intel(R) Precise</td> </tr> </tbody> </table>				Parameter	Value		Intel(R) Precise Touch and Stylus Reset GPIO Select	None	Configure Intel(R) Precise	Intel(R) Precise Touch and Stylus Interrupt GPIO Select	None	Configure Intel(R) Precise																			
Parameter	Value																														
Intel(R) Precise Touch and Stylus Reset GPIO Select	None	Configure Intel(R) Precise																													
Intel(R) Precise Touch and Stylus Interrupt GPIO Select	None	Configure Intel(R) Precise																													
4	ME Feature Pins																														
	Intel® Precise Touch and Stylus Reset GPIO Select Configure Intel® Precise Touch and Stylus Reset GPIO.	ICL-Y ICL-U	None None																												
	Intel® Precise Touch and Stylus Interrupt GPIO Select Configure Intel® Precise Touch and Stylus Interrupt GPIO.	ICL-Y ICL-U	None None																												
Click on GPIO in the left tabs menu> Touch Controller Pins is expanded by default:																															
<div style="display: flex; justify-content: space-between; align-items: center;"> ▼ Touch Controller Pins 5 </div> <hr style="border: 1px solid yellow;"/> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 30%;">Parameter</th> <th style="width: 30%;">Value</th> <th style="width: 20%;"></th> <th style="width: 20%;"></th> </tr> </thead> <tbody> <tr> <td>GPP_E_1</td> <td>GPIO</td> <td>-</td> <td></td> </tr> <tr> <td>GPP_E_2</td> <td>GPIO</td> <td>-</td> <td></td> </tr> <tr> <td>GPP_E_10</td> <td>GPIO</td> <td>-</td> <td></td> </tr> <tr> <td>GPP_E_11</td> <td>GPIO</td> <td>-</td> <td></td> </tr> <tr> <td>GPP_E_12</td> <td>GPIO</td> <td>-</td> <td></td> </tr> <tr> <td>GPP_E_13</td> <td>GPIO</td> <td>-</td> <td></td> </tr> </tbody> </table>				Parameter	Value			GPP_E_1	GPIO	-		GPP_E_2	GPIO	-		GPP_E_10	GPIO	-		GPP_E_11	GPIO	-		GPP_E_12	GPIO	-		GPP_E_13	GPIO	-	
Parameter	Value																														
GPP_E_1	GPIO	-																													
GPP_E_2	GPIO	-																													
GPP_E_10	GPIO	-																													
GPP_E_11	GPIO	-																													
GPP_E_12	GPIO	-																													
GPP_E_13	GPIO	-																													
5	Touch Controller Pins																														
	GPP_E_1	GPIO	-																												
	GPP_E_2	GPIO	-																												
	GPP_E_10	GPIO	-																												
	GPP_E_11	GPIO	-																												
	GPP_E_12	GPIO	-																												
	GPP_E_13	GPIO	-																												
#	Parameter	Platform	Settings																												



Table 2-17. - GPIO (Sheet 3 of 17)

5	Touch Controller Pins		
	GPP_E_1	ICL-Y ICL-U	GPIO GPIO
	GPP_E_2	ICL-Y ICL-U	GPIO GPIO
	GPP_E_10	ICL-Y ICL-U	GPIO GPIO
	GPP_E_11	ICL-Y ICL-U	GPIO GPIO
	GPP_E_12	ICL-Y ICL-U	GPIO GPIO
	GPP_E_13	ICL-Y ICL-U	GPIO GPIO
Click on GPIO in the left tabs menu> SMLink1 Pins is expanded by default:			
<div style="display: flex; align-items: center;"> ▼ SMLink1 Pins 6 </div>			
	Parameter	Value	
	GPP_C_6	GPIO -	
	GPP_C_7	GPIO -	
#	Parameter	Platform	Settings
6	SMLink1 Pins		
	GPP_C_6	ICL-Y ICL-U	GPIO GPIO
	GPP_C_7	ICL-Y ICL-U	GPIO GPIO
Click on GPIO in the left tabs menu> GPIO VCCIO Voltage Control is expanded by default:			



Table 2-17. - GPIO (Sheet 4 of 17)

▼ GPIO VCCIO Voltage Control 7			
	Parameter	Value	
	GPP_A0 Individual Voltage Select	1.8Volts	This setting controls the VCCIO voltage for
	GPP_A1 Individual Voltage Select	1.8Volts	This setting controls the VCCIO voltage for
	GPP_A2 Individual Voltage Select	1.8Volts	This setting controls the VCCIO voltage for
	GPP_A3 Individual Voltage Select	1.8Volts	This setting controls the VCCIO voltage for
	GPP_A4 Individual Voltage Select	1.8Volts	This setting controls the VCCIO voltage for
	GPP_A5 Individual Voltage Select	1.8Volts	This setting controls the VCCIO voltage for
	GPP_A6 Individual Voltage Select	1.8Volts	This setting controls the VCCIO voltage for
	GPP_A7 Individual Voltage Select	1.8Volts	This setting controls the VCCIO voltage for
	GPP_A8 Individual Voltage Select	1.8Volts	This setting controls the VCCIO voltage for
	GPP_A9 Individual Voltage Select	1.8Volts	This setting controls the VCCIO voltage for
	GPP_A10 Individual Voltage Select	1.8Volts	This setting controls the VCCIO voltage for
	GPP_A11 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage for
	GPP_A12 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage for
	GPP_A13 Individual Voltage Select	1.8Volts	This setting controls the VCCIO voltage for
	GPP_A14 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage for
	GPP_A15 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage for
	GPP_A16 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage for
	GPP_A17 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage for
	GPP_A17 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage for
	GPP_A19 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage for
	GPP_A20 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage for
	GPP_A21 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage for
	GPP_A22 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage for
	GPP_A23 Individual Voltage Select	1.8Volts	This setting controls the VCCIO voltage for

#	Parameter	Platform	Settings
7	GPIO VCCIO Voltage Control		
	<i>Warning:</i> Incorrectly configuring GPIO voltages may result in MCP damage.		
	GPP_A0 Individual Voltage Select	ICL-Y ICL-U	1.8 Volts 1.8 Volts
	GPP_A1 Individual Voltage Select	ICL-Y ICL-U	1.8 Volts 1.8 Volts
	GPP_A2 Individual Voltage Select	ICL-Y ICL-U	1.8 Volts 1.8 Volts
	GPP_A3 Individual Voltage Select	ICL-Y ICL-U	1.8 Volts 1.8 Volts
	GPP_A4 Individual Voltage Select	ICL-Y ICL-U	1.8 Volts 1.8 Volts



Table 2-17. - GPIO (Sheet 5 of 17)

	GPP_A5 Individual Voltage Select	ICL-Y	1.8 Volts
		ICL-U	1.8 Volts
	GPP_A6 Individual Voltage Select	ICL-Y	1.8 Volts
		ICL-U	1.8 Volts
	GPP_A7 Individual Voltage Select	ICL-Y	1.8 Volts
		ICL-U	1.8 Volts
	GPP_A8 Individual Voltage Select	ICL-Y	1.8 Volts
		ICL-U	1.8 Volts
	GPP_A9 Individual Voltage Select	ICL-Y	1.8 Volts
		ICL-U	1.8 Volts
	GPP_A10 Individual Voltage Select	ICL-Y	1.8 Volts
		ICL-U	1.8 Volts
	GPP_A11 Individual Voltage Select	ICL-Y	3.3 Volts
		ICL-U	3.3 Volts
	GPP_A12 Individual Voltage Select	ICL-Y	3.3 Volts
		ICL-U	3.3 Volts
	GPP_A13 Individual Voltage Select	ICL-Y	1.8 Volts
		ICL-U	1.8 Volts
	GPP_A14 Individual Voltage Select	ICL-Y	3.3 Volts
		ICL-U	3.3 Volts
	GPP_A15 Individual Voltage Select	ICL-Y	3.3 Volts
		ICL-U	3.3 Volts
	GPP_A16 Individual Voltage Select	ICL-Y	3.3 Volts
		ICL-U	3.3 Volts
	GPP_A17 Individual Voltage Select	ICL-Y	3.3 Volts
		ICL-U	3.3 Volts
	GPP_A18 Individual Voltage Select	ICL-Y	3.3 Volts
		ICL-U	3.3 Volts
	GPP_A19 Individual Voltage Select	ICL-Y	3.3 Volts
		ICL-U	3.3 Volts
	GPP_A20 Individual Voltage Select	ICL-Y	3.3 Volts
		ICL-U	3.3 Volts
	GPP_A21 Individual Voltage Select	ICL-Y	3.3 Volts
		ICL-U	3.3 Volts
	GPP_A22 Individual Voltage Select	ICL-Y	3.3 Volts
		ICL-U	3.3 Volts
	GPP_A23 Individual Voltage Select	ICL-Y	1.8 Volts
		ICL-U	1.8 Volts



Table 2-17. - GPIO (Sheet 6 of 17)

GPP_B0 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage for the	
GPP_B1 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage for the	
GPP_B2 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage for the	
GPP_B3 Individual Voltage Select	1.8Volts	This setting controls the VCCIO voltage for the	
GPP_B4 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage for the	
GPP_B5 Individual Voltage Select	1.8Volts	This setting controls the VCCIO voltage for the	
GPP_B6 Individual Voltage Select	1.8Volts	This setting controls the VCCIO voltage for the	
GPP_B7 Individual Voltage Select	1.8Volts	This setting controls the VCCIO voltage for the	
GPP_B8 Individual Voltage Select	1.8Volts	This setting controls the VCCIO voltage for the	
GPP_B9 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage for the	
GPP_B10 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage for the	
GPP_B11 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage for the	
GPP_B12 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage for the	
GPP_B13 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage for the	
GPP_B14 Individual Voltage Select	1.8Volts	This setting controls the VCCIO voltage for the	
GPP_B15 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage for the	
GPP_B16 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage for the	
GPP_B17 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage for the	
GPP_B18 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage for the	
GPP_B19 Individual Voltage Select	1.8Volts	This setting controls the VCCIO voltage for the	
GPP_B20 Individual Voltage Select	1.8Volts	This setting controls the VCCIO voltage for the	
GPP_B21 Individual Voltage Select	1.8Volts	This setting controls the VCCIO voltage for the	
GPP_B22 Individual Voltage Select	1.8Volts	This setting controls the VCCIO voltage for the	
GPP_B23 Individual Voltage Select	1.8Volts	This setting controls the VCCIO voltage for the	
#	Parameter	Platform	Settings
	GPP_B0 Individual Voltage Select	ICL-Y ICL-U	3.3 Volts 3.3 Volts



Table 2-17. - GPIO (Sheet 7 of 17)

	GPP_B1 Individual Voltage Select	ICL-Y	3.3 Volts
		ICL-U	3.3 Volts
	GPP_B2 Individual Voltage Select	ICL-Y	3.3 Volts
		ICL-U	3.3 Volts
	GPP_B3 Individual Voltage Select	ICL-Y	1.8 Volts
		ICL-U	1.8 Volts
	GPP_B4 Individual Voltage Select	ICL-Y	3.3 Volts
		ICL-U	3.3 Volts
	GPP_B5 Individual Voltage Select	ICL-Y	1.8 Volts
		ICL-U	1.8 Volts
	GPP_B6 Individual Voltage Select	ICL-Y	1.8 Volts
		ICL-U	1.8 Volts
	GPP_B7 Individual Voltage Select	ICL-Y	1.8 Volts
		ICL-U	1.8 Volts
	GPP_B8 Individual Voltage Select	ICL-Y	1.8 Volts
		ICL-U	1.8 Volts
	GPP_B9 Individual Voltage Select	ICL-Y	3.3 Volts
		ICL-U	3.3 Volts
	GPP_B10 Individual Voltage Select	ICL-Y	3.3 Volts
		ICL-U	3.3 Volts
	GPP_B11 Individual Voltage Select	ICL-Y	3.3 Volts
		ICL-U	3.3 Volts
	GPP_B12 Individual Voltage Select	ICL-Y	3.3 Volts
		ICL-U	3.3 Volts
	GPP_B13 Individual Voltage Select	ICL-Y	3.3 Volts
		ICL-U	3.3 Volts
	GPP_B14 Individual Voltage Select	ICL-Y	1.8 Volts
		ICL-U	1.8 Volts
	GPP_B15 Individual Voltage Select	ICL-Y	3.3 Volts
		ICL-U	3.3 Volts
	GPP_B16 Individual Voltage Select	ICL-Y	3.3 Volts
		ICL-U	3.3 Volts
	GPP_B17 Individual Voltage Select	ICL-Y	3.3 Volts
		ICL-U	3.3 Volts
	GPP_B18 Individual Voltage Select	ICL-Y	3.3 Volts
		ICL-U	3.3 Volts
	GPP_B19 Individual Voltage Select	ICL-Y	1.8 Volts
		ICL-U	1.8 Volts
	GPP_B20 Individual Voltage Select	ICL-Y	1.8 Volts
		ICL-U	1.8 Volts
	GPP_B21 Individual Voltage Select	ICL-Y	1.8 Volts
		ICL-U	1.8 Volts
	GPP_B22 Individual Voltage Select	ICL-Y	1.8 Volts
		ICL-U	1.8 Volts
	GPP_B23 Individual Voltage Select	ICL-Y	1.8 Volts
		ICL-U	1.8 Volts



Table 2-17. - GPIO (Sheet 8 of 17)

GPP_C0 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage fo
GPP_C1 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage fo
GPP_C2 Individual Voltage Select	1.8Volts	This setting controls the VCCIO voltage fo
GPP_C3 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage fo
GPP_C4 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage fo
GPP_C5 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage fo
GPP_C6 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage fo
GPP_C7 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage fo
GPP_C8 Individual Voltage Select	1.8Volts	This setting controls the VCCIO voltage fo
GPP_C9 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage fo
GPP_C10 Individual Voltage Select	1.8Volts	This setting controls the VCCIO voltage fo
GPP_C11 Individual Voltage Select	1.8Volts	This setting controls the VCCIO voltage fo
GPP_C12 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage fo
GPP_C13 Individual Voltage Select	1.8Volts	This setting controls the VCCIO voltage fo
GPP_C14 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage fo
GPP_C15 Individual Voltage Select	1.8Volts	This setting controls the VCCIO voltage fo
GPP_C16 Individual Voltage Select	1.8Volts	This setting controls the VCCIO voltage fo
GPP_C17 Individual Voltage Select	1.8Volts	This setting controls the VCCIO voltage fo
GPP_C18 Individual Voltage Select	1.8Volts	This setting controls the VCCIO voltage fo
GPP_C19 Individual Voltage Select	1.8Volts	This setting controls the VCCIO voltage fo
GPP_C20 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage fo
GPP_C21 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage fo
GPP_C22 Individual Voltage Select	1.8Volts	This setting controls the VCCIO voltage fo
GPP_C23 Individual Voltage Select	1.8Volts	This setting controls the VCCIO voltage fo



Table 2-17. - GPIO (Sheet 9 of 17)

#	Parameter	Platform	Settings
	GPP_C0 Individual Voltage Select	ICL-Y ICL-U	3.3 Volts 3.3 Volts
	GPP_C1 Individual Voltage Select	ICL-Y ICL-U	3.3 Volts 3.3 Volts
	GPP_C2 Individual Voltage Select	ICL-Y ICL-U	1.8 Volts 1.8 Volts
	GPP_C3 Individual Voltage Select	ICL-Y ICL-U	3.3 Volts 3.3 Volts
	GPP_C4 Individual Voltage Select	ICL-Y ICL-U	3.3 Volts 3.3 Volts
	GPP_C5 Individual Voltage Select	ICL-Y ICL-U	3.3 Volts 3.3 Volts
	GPP_C6 Individual Voltage Select	ICL-Y ICL-U	3.3 Volts 3.3 Volts
	GPP_C7 Individual Voltage Select	ICL-Y ICL-U	3.3 Volts 3.3 Volts
	GPP_C8 Individual Voltage Select	ICL-Y ICL-U	1.8 Volts 1.8 Volts
	GPP_C9 Individual Voltage Select	ICL-Y ICL-U	3.3 Volts 3.3 Volts
	GPP_C10 Individual Voltage Select	ICL-Y ICL-U	1.8 Volts 1.8 Volts
	GPP_C11 Individual Voltage Select	ICL-Y ICL-U	3.3 Volts 1.8 Volts
	GPP_C12 Individual Voltage Select	ICL-Y ICL-U	3.3 Volts 3.3 Volts
	GPP_C13 Individual Voltage Select	ICL-Y ICL-U	1.8 Volts 1.8 Volts
	GPP_C14 Individual Voltage Select	ICL-Y ICL-U	3.3 Volts 3.3 Volts
	GPP_C15 Individual Voltage Select	ICL-Y ICL-U	1.8 Volts 1.8 Volts
	GPP_C16 Individual Voltage Select	ICL-Y ICL-U	1.8 Volts 1.8 Volts
	GPP_C17 Individual Voltage Select	ICL-Y ICL-U	1.8 Volts 1.8 Volts
	GPP_C18 Individual Voltage Select	ICL-Y ICL-U	1.8 Volts 1.8 Volts
	GPP_C19 Individual Voltage Select	ICL-Y ICL-U	1.8 Volts 1.8 Volts
	GPP_C20 Individual Voltage Select	ICL-Y ICL-U	3.3 Volts 3.3 Volts
	GPP_C21 Individual Voltage Select	ICL-Y ICL-U	3.3 Volts 3.3 Volts
	GPP_C22 Individual Voltage Select	ICL-Y ICL-U	1.8 Volts 1.8 Volts
	GPP_C23 Individual Voltage Select	ICL-Y ICL-U	1.8 Volts 1.8 Volts



Table 2-17. - GPIO (Sheet 10 of 17)

GPP_D0 Individual Voltage Select	1.8Volts	This setting controls the VCCIO voltage for
GPP_D1 Individual Voltage Select	1.8Volts	This setting controls the VCCIO voltage for
GPP_D2 Individual Voltage Select	1.8Volts	This setting controls the VCCIO voltage for
GPP_D3 Individual Voltage Select	1.8Volts	This setting controls the VCCIO voltage for
GPP_D4 Individual Voltage Select	1.8Volts	This setting controls the VCCIO voltage for
GPP_D5 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage for
GPP_D6 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage for
GPP_D7 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage for
GPP_D8 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage for
GPP_D9 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage for
GPP_D10 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage for
GPP_D11 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage for
GPP_D12 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage for
GPP_D13 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage for
GPP_D14 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage for
GPP_D15 Individual Voltage Select	1.8Volts	This setting controls the VCCIO voltage for
GPP_D16 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage for
GPP_D17 Individual Voltage Select	1.8Volts	This setting controls the VCCIO voltage for
GPP_D18 Individual Voltage Select	1.8Volts	This setting controls the VCCIO voltage for
GPP_D19 Individual Voltage Select	1.8Volts	This setting controls the VCCIO voltage for
GPP_D20 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage for
GPP_D21 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage for
GPP_D22 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage for
GPP_D23 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage for



Table 2-17. - GPIO (Sheet 11 of 17)

#	Parameter	Platform	Settings
	GPP_D0 Individual Voltage Select	ICL-Y ICL-U	1.8 Volts 1.8 Volts
	GPP_D1 Individual Voltage Select	ICL-Y ICL-U	1.8 Volts 1.8 Volts
	GPP_D2 Individual Voltage Select	ICL-Y ICL-U	1.8 Volts 1.8 Volts
	GPP_D3 Individual Voltage Select	ICL-Y ICL-U	1.8 Volts 1.8 Volts
	GPP_D4 Individual Voltage Select	ICL-Y ICL-U	1.8 Volts 1.8 Volts
	GPP_D5 Individual Voltage Select	ICL-Y ICL-U	3.3 Volts 3.3 Volts
	GPP_D6 Individual Voltage Select	ICL-Y ICL-U	3.3 Volts 3.3 Volts
	GPP_D7 Individual Voltage Select	ICL-Y ICL-U	3.3 Volts 3.3 Volts
	GPP_D8 Individual Voltage Select	ICL-Y ICL-U	3.3 Volts 3.3 Volts
	GPP_D9 Individual Voltage Select	ICL-Y ICL-U	3.3 Volts 3.3 Volts
	GPP_D10 Individual Voltage Select	ICL-Y ICL-U	3.3 Volts 3.3 Volts
	GPP_D11 Individual Voltage Select	ICL-Y ICL-U	1.8 Volts 3.3 Volts
	GPP_D12 Individual Voltage Select	ICL-Y ICL-U	1.8 Volts 3.3 Volts
	GPP_D13 Individual Voltage Select	ICL-Y ICL-U	3.3 Volts 3.3 Volts
	GPP_D14 Individual Voltage Select	ICL-Y ICL-U	3.3 Volts 3.3 Volts
	GPP_D15 Individual Voltage Select	ICL-Y ICL-U	1.8 Volts 1.8 Volts
	GPP_D16 Individual Voltage Select	ICL-Y ICL-U	3.3 Volts 3.3 Volts
	GPP_D17 Individual Voltage Select	ICL-Y ICL-U	1.8 Volts 1.8 Volts
	GPP_D18 Individual Voltage Select	ICL-Y ICL-U	1.8 Volts 1.8 Volts
	GPP_D19 Individual Voltage Select	ICL-Y ICL-U	1.8 Volts 1.8 Volts
	GPP_D20 Individual Voltage Select	ICL-Y ICL-U	3.3 Volts 3.3 Volts
	GPP_D21 Individual Voltage Select	ICL-Y ICL-U	3.3 Volts 3.3 Volts
	GPP_D22 Individual Voltage Select	ICL-Y ICL-U	3.3 Volts 3.3 Volts
	GPP_D23 Individual Voltage Select	ICL-Y ICL-U	3.3 Volts 3.3 Volts



Table 2-17. - GPIO (Sheet 12 of 17)

GPP_E0 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage for
GPP_E1 Individual Voltage Select	1.8Volts	This setting controls the VCCIO voltage for
GPP_E2 Individual Voltage Select	1.8Volts	This setting controls the VCCIO voltage for
GPP_E3 Individual Voltage Select	1.8Volts	This setting controls the VCCIO voltage for
GPP_E4 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage for
GPP_E5 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage for
GPP_E6 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage for
GPP_E7 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage for
GPP_E8 Individual Voltage Select	1.8Volts	This setting controls the VCCIO voltage for
GPP_E9 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage for
GPP_E10 Individual Voltage Select	1.8Volts	This setting controls the VCCIO voltage for
GPP_E11 Individual Voltage Select	1.8Volts	This setting controls the VCCIO voltage for
GPP_E12 Individual Voltage Select	1.8Volts	This setting controls the VCCIO voltage for
GPP_E13 Individual Voltage Select	1.8Volts	This setting controls the VCCIO voltage for
GPP_E14 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage for
GPP_E15 Individual Voltage Select	1.8Volts	This setting controls the VCCIO voltage for
GPP_E16 Individual Voltage Select	1.8Volts	This setting controls the VCCIO voltage for
GPP_E17 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage for
GPP_E18 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage for
GPP_E19 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage for
GPP_E20 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage for
GPP_E21 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage for
GPP_E22 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage for
GPP_E23 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage for



Table 2-17. - GPIO (Sheet 13 of 17)

#	Parameter	Platform	Settings
	GPP_E0 Individual Voltage Select	ICL-Y ICL-U	3.3 Volts 3.3 Volts
	GPP_E1 Individual Voltage Select	ICL-Y ICL-U	1.8 Volts 1.8 Volts
	GPP_E2 Individual Voltage Select	ICL-Y ICL-U	1.8 Volts 1.8 Volts
	GPP_E3 Individual Voltage Select	ICL-Y ICL-U	1.8 Volts 1.8 Volts
	GPP_E4 Individual Voltage Select	ICL-Y ICL-U	3.3 Volts 3.3 Volts
	GPP_E5 Individual Voltage Select	ICL-Y ICL-U	3.3 Volts 3.3 Volts
	GPP_E6 Individual Voltage Select	ICL-Y ICL-U	3.3 Volts 3.3 Volts
	GPP_E7 Individual Voltage Select	ICL-Y ICL-U	3.3 Volts 3.3 Volts
	GPP_E8 Individual Voltage Select	ICL-Y ICL-U	1.8 Volts 1.8 Volts
	GPP_E9 Individual Voltage Select	ICL-Y ICL-U	3.3 Volts 3.3 Volts
	GPP_E10 Individual Voltage Select	ICL-Y ICL-U	1.8 Volts 1.8 Volts
	GPP_E11 Individual Voltage Select	ICL-Y ICL-U	1.8 Volts 1.8 Volts
	GPP_E12 Individual Voltage Select	ICL-Y ICL-U	1.8 Volts 1.8 Volts
	GPP_E13 Individual Voltage Select	ICL-Y ICL-U	1.8 Volts 1.8 Volts
	GPP_E14 Individual Voltage Select	ICL-Y ICL-U	3.3 Volts 3.3 Volts
	GPP_E15 Individual Voltage Select	ICL-Y ICL-U	1.8 Volts 1.8 Volts
	GPP_E16 Individual Voltage Select	ICL-Y ICL-U	1.8 Volts 1.8 Volts
	GPP_E17 Individual Voltage Select	ICL-Y ICL-U	3.3 Volts 3.3 Volts
	GPP_E18 Individual Voltage Select	ICL-Y ICL-U	3.3 Volts 3.3 Volts
	GPP_E19 Individual Voltage Select	ICL-Y ICL-U	3.3 Volts 3.3 Volts
	GPP_E20 Individual Voltage Select	ICL-Y ICL-U	3.3 Volts 3.3 Volts
	GPP_E21 Individual Voltage Select	ICL-Y ICL-U	3.3 Volts 3.3 Volts
	GPP_E22 Individual Voltage Select	ICL-Y ICL-U	1.8 Volts 3.3 Volts
	GPP_E23 Individual Voltage Select	ICL-Y ICL-U	3.3 Volts 3.3 Volts



Table 2-17. - GPIO (Sheet 14 of 17)

GPP_G Group Master Voltage Select	3.3 Volts	This setting controls configures the VCCIO voltage all of the GPP_G	
GPP_G0 Individual Voltage Select	3.3 Volts	This setting controls the VCCIO voltage for the GPP_G0 GPIO pin.	
GPP_G1 Individual Voltage Select	3.3 Volts	This setting controls the VCCIO voltage for the GPP_G1 GPIO pin.	
GPP_G2 Individual Voltage Select	3.3 Volts	This setting controls the VCCIO voltage for the GPP_G2 GPIO pin.	
GPP_G3 Individual Voltage Select	3.3 Volts	This setting controls the VCCIO voltage for the GPP_G3 GPIO pin.	
GPP_G4 Individual Voltage Select	3.3 Volts	This setting controls the VCCIO voltage for the GPP_G4 GPIO pin.	
GPP_G5 Individual Voltage Select	3.3 Volts	This setting controls the VCCIO voltage for the GPP_G5 GPIO pin.	
GPP_G6 Individual Voltage Select	3.3 Volts	This setting controls the VCCIO voltage for the GPP_G6 GPIO pin.	
GPP_G7 Individual Voltage Select	3.3 Volts	This setting controls the VCCIO voltage for the GPP_G7 GPIO pin.	
#	Parameter	Platform	Settings
	GPP_G0 Individual Voltage Select	ICL-Y ICL-U	3.3 Volts 3.3 Volts
	GPP_G1 Individual Voltage Select	ICL-Y ICL-U	3.3 Volts 3.3 Volts
	GPP_G2 Individual Voltage Select	ICL-Y ICL-U	3.3 Volts 3.3 Volts
	GPP_G3 Individual Voltage Select	ICL-Y ICL-U	3.3 Volts 3.3 Volts
	GPP_G4 Individual Voltage Select	ICL-Y ICL-U	3.3 Volts 3.3 Volts
	GPP_G5 Individual Voltage Select	ICL-Y ICL-U	3.3 Volts 3.3 Volts
	GPP_G6 Individual Voltage Select	ICL-Y ICL-U	3.3 Volts 3.3 Volts
	GPP_G7 Individual Voltage Select	ICL-Y ICL-U	3.3 Volts 3.3 Volts



Table 2-17. - GPIO (Sheet 15 of 17)

GPP_H0 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage for
GPP_H1 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage for
GPP_H2 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage for
GPP_H3 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage for
GPP_H4 Individual Voltage Select	1.8Volts	This setting controls the VCCIO voltage for
GPP_H5 Individual Voltage Select	1.8Volts	This setting controls the VCCIO voltage for
GPP_H6 Individual Voltage Select	1.8Volts	This setting controls the VCCIO voltage for
GPP_H7 Individual Voltage Select	1.8Volts	This setting controls the VCCIO voltage for
GPP_H8 Individual Voltage Select	1.8Volts	This setting controls the VCCIO voltage for
GPP_H9 Individual Voltage Select	1.8Volts	This setting controls the VCCIO voltage for
GPP_H10 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage for
GPP_H11 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage for
GPP_H12 Individual Voltage Select	1.8Volts	This setting controls the VCCIO voltage for
GPP_H13 Individual Voltage Select	1.8Volts	This setting controls the VCCIO voltage for
GPP_H14 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage for
GPP_H15 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage for
GPP_H16 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage for
GPP_H17 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage for
GPP_H18 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage for
GPP_H19 Individual Voltage Select	3.3Volts	This setting controls the VCCIO voltage for
GPP_H20 Individual Voltage Select	1.8Volts	This setting controls the VCCIO voltage for
GPP_H21 Individual Voltage Select	1.8Volts	This setting controls the VCCIO voltage for
GPP_H22 Individual Voltage Select	1.8Volts	This setting controls the VCCIO voltage for
GPP_H23 Individual Voltage Select	1.8Volts	This setting controls the VCCIO voltage for
Deep Sx Mode Configuration	1.8Volts	This setting controls the VCCIO voltage for
Intel(R) HD Audio Voltage Select	3.3Volts	This setting controls configures the VCCIO



Table 2-17. - GPIO (Sheet 16 of 17)

#	Parameter	Platform	Settings
	GPP_H0 Individual Voltage Select	ICL-Y ICL-U	3.3 Volts 3.3 Volts
	GPP_H1 Individual Voltage Select	ICL-Y ICL-U	3.3 Volts 3.3 Volts
	GPP_H2 Individual Voltage Select	ICL-Y ICL-U	3.3 Volts 3.3 Volts
	GPP_H3 Individual Voltage Select	ICL-Y ICL-U	3.3 Volts 3.3 Volts
	GPP_H4 Individual Voltage Select	ICL-Y ICL-U	1.8 Volts 1.8 Volts
	GPP_H5 Individual Voltage Select	ICL-Y ICL-U	1.8 Volts 1.8 Volts
	GPP_H6 Individual Voltage Select	ICL-Y ICL-U	1.8 Volts 1.8 Volts
	GPP_H7 Individual Voltage Select	ICL-Y ICL-U	1.8 Volts 1.8 Volts
	GPP_H8 Individual Voltage Select	ICL-Y ICL-U	1.8 Volts 1.8 Volts
	GPP_H9 Individual Voltage Select	ICL-Y ICL-U	1.8 Volts 1.8 Volts
	GPP_H10 Individual Voltage Select	ICL-Y ICL-U	3.3 Volts 3.3 Volts
	GPP_H11 Individual Voltage Select	ICL-Y ICL-U	3.3 Volts 3.3 Volts
	GPP_H12 Individual Voltage Select	ICL-Y ICL-U	1.8 Volts 1.8 Volts
	GPP_H13 Individual Voltage Select	ICL-Y ICL-U	1.8 Volts 1.8 Volts
	GPP_H14 Individual Voltage Select	ICL-Y ICL-U	3.3 Volts 3.3 Volts
	GPP_H15 Individual Voltage Select	ICL-Y ICL-U	3.3 Volts 3.3 Volts
	GPP_H16 Individual Voltage Select	ICL-Y ICL-U	3.3 Volts 3.3 Volts
	GPP_H17 Individual Voltage Select	ICL-Y ICL-U	3.3 Volts 3.3 Volts
	GPP_H18 Individual Voltage Select	ICL-Y ICL-U	3.3 Volts 3.3 Volts
	GPP_H19 Individual Voltage Select	ICL-Y ICL-U	3.3 Volts 3.3 Volts
	GPP_H20 Individual Voltage Select	ICL-Y ICL-U	1.8 Volts 1.8 Volts
	GPP_H21 Individual Voltage Select	ICL-Y ICL-U	1.8 Volts 1.8 Volts
	GPP_H22 Individual Voltage Select	ICL-Y ICL-U	1.8 Volts 1.8 Volts
	GPP_H23 Individual Voltage Select	ICL-Y ICL-U	1.8 Volts 1.8 Volts
	Deep Sx Mode Configuration	ICL-Y ICL-U	3.3 Volts 3.3 Volts
	Intel® HD Audio Voltage Select	ICL-Y ICL-U	1.8 Volts 1.8 Volts



Table 2-17. - GPIO (Sheet 17 of 17)

▼ Thunderbolt LSx/BSSB-LS Configuration 8			
Parameter		Value	
Thunderbolt LSx/BSSB-LS 0 VCCIO		TX VCCIO	
Thunderbolt LSx/BSSB-LS 1 VCCIO		TX VCCIO	
Thunderbolt LSx/BSSB-LS 2 VCCIO		TX VCCIO	
Thunderbolt LSx/BSSB-LS 3 VCCIO		TX VCCIO	
#	Parameter	Platform	Settings
8	Thunderbolt LSx/BSSB-LS Configuration		
	Thunderbolt LSx/BSSB-LS 0 VCCIO Values: TX VCCIO / Legacy VCCIO This setting configured Thunderbolt LSx/BSSB-LS 0 VCCIO.	ICL-Y ICL-U	TX VCCIO TX VCCIO
	Thunderbolt LSx/BSSB-LS 1 VCCIO Values: TX VCCIO / Legacy VCCIO This setting configured Thunderbolt LSx/BSSB-LS 0 VCCIO.	ICL-Y ICL-U	TX VCCIO TX VCCIO
	Thunderbolt LSx/BSSB-LS 2 VCCIO Values: TX VCCIO / Legacy VCCIO This setting configured Thunderbolt LSx/BSSB-LS 0 VCCIO.	ICL-Y ICL-U	TX VCCIO TX VCCIO
	Thunderbolt LSx/BSSB-LS 3 VCCIO Values: TX VCCIO / Legacy VCCIO This setting configured Thunderbolt LSx/BSSB-LS 0 VCCIO.	ICL-Y ICL-U	TX VCCIO TX VCCIO



Table 2-18. - Intel® Precise Touch and Stylus

Click on Intel® Precise Touch and Stylus in the left tabs menu> IntegratedTouchConfiguration is expanded by default:

▼ **IntegratedTouchConfiguration** 1

Parameter	Value	
Intel(R) Precise Touch and Stylus Enabled	No	-

#	Parameter	Platform	Settings
1	IntegratedTouchConfiguration		
	Intel® Precise Touch and Stylus Enabled	ICL-Y ICL-U	No No

Click on Intel® Precise Touch and Stylus in the left tabs menu> IntegratedTouchAndStylusConfiguration is expanded by default:

▼ **IntelPreciseTouchAndStylusConfiguration** 2

Parameter	Value	
Intel(R) Precise Touch and Stylus Controller 1 Maximum Frequency	30 MHz	This setting allows custom

#	Parameter	Platform	Settings
2	IntelPerciseTouchandStylusConfiguration		
	Intel® Precise Touch and Stylus Controller 1 Maximum Frequency	ICL-Y ICL-U	30MHz 30MHz



Table 2-19. - FW Update Image Build

Click on FW Update Image Build in the left tabs menu> ME Image is expanded by default:			
<p>▼ ME Image 1</p>			
Parameter		Value	
ME Binary File		This loads the Embedded Controller binary	
#	Parameter	Platform	Settings
	The FW Update Image Build tab allows users to build firmware update image binaries based on one or several of the following elements combined together: Intel® ME, PMC, OEM KM, IOM, MG, TBT, ISH, iUnit		
1	ME Image		
	ME Binary Image Values: Binary File This loads the Embedded Controller binary that will be merged into the FWUpdate image generated by the Intel® FIT tool.	ICL-Y ICL-U	ME Binary ME Binary
Click on FW Update Image Build in the left tabs menu> PMC Image is expanded by default:			
<p>▼ PMC Image 2</p>			
Parameter		Value	
PMC Max Length		0x20000	
PMC Binary File		This loads the PMC binary that will be mer	
#	Parameter	Platform	Settings
2	PMC Image		
	PMC Max Length		
	PMC Binary Image Values: Binary File This loads the PMC binary that will be merged into the FWUpdate image generated by the Intel® FIT tool.	ICL-Y ICL-U	PMC Binary PMC Binary
Click on FW Update Image Build in the left tabs menu> OEM KM Image is expanded by default:			
<p>▼ OEM KM Image 3</p>			
Parameter		Value	
OEM KM Enable		Enabled	
OEM KM Max Length		0x1000	
OEM Key Manifest Binary File		This loads the OEM Key manifest binary m	



Table 2-19. - FW Update Image Build

#	Parameter	Platform	Settings
3	OEM KM Image		
	OEM KM Enable Values: Enabled/Disabled This setting Enables / Disables OEM KM in the FWUpdate image.	ICL-Y ICL-U	Enabled Enabled
	OEM KM Max Length		
	OEM Key Manifest Binary File Values: Binary File This loads the OEM Key manifest binary merged into the output image generated by the Intel® FIT tool.	ICL-Y ICL-U	OEM KM Binary OEM KM Binary
Click on FW Update Image Build in the left tabs menu> IOM Image is expanded by default:			
▼ IOM Image 4			
	Parameter	Value	He
	IOM Enable	Enabled	This setting Enables / Disables IOM in the f
	IO Manageability Engine Max Le...	0xC000	-
	IO Manageability Engine Binary ...		This loads the IO Manageability Engine bin;
#	Parameter	Platform	Settings
4	IOM Image		
	IOM Enable Values: Enabled/Disabled This setting Enables / Disables IOM in the FWUpdate image.	ICL-Y ICL-U	Enabled Enabled
	IO Manageability Engine Max Length		
	IO Manageability Engine Binary File Values: Binary File This loads the IO Manageability binary merged into the output image generated by the Intel® FIT tool.	ICL-Y ICL-U	IOM Binary IOM Binary
Click on FW Update Image Build in the left tabs menu> MG Image is expanded by default:			
▼ NPHY Image 5			
	Parameter	Value	He
	NPHY Enable	Enabled	This setting Enables / Disables NPHY in the FV
	PHY Max Length	0x8000	-
	PHY Binary File		This loads the NPHY binary merged into the ou
#	Parameter	Platform	Settings



Table 2-19. - FW Update Image Build

5	NPHY Image																						
	NPHY Enable Values: Enabled/Disabled This setting Enables / Disables NPHY in the FWUpdate image.	ICL-Y ICL-U	Enabled Enabled																				
	PHY Max Length																						
	PHY Binary File Values: Binary File This loads the NPHY binary merged into the output image generated by the Intel® FIT tool.	ICL-Y ICL-U	NPHY Binary NPHY Binary																				
Click on FW Update Image Build in the left tabs menu> TBT Image is expanded by default:																							
▼ TBT Image 6																							
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 30%;">Parameter</th> <th style="width: 30%;">Value</th> <th style="width: 40%;"></th> </tr> </thead> <tbody> <tr> <td>TBT Enable</td> <td>Enabled</td> <td>This setting Enables / Disables Thunderbol</td> </tr> <tr> <td>Thunderbolt(TM) Max Length</td> <td>0x40000</td> <td>-</td> </tr> <tr> <td>Thunerbolt(TM) Binary File</td> <td></td> <td>This loads the Thunderbolt(TM) binary me</td> </tr> </tbody> </table>				Parameter	Value		TBT Enable	Enabled	This setting Enables / Disables Thunderbol	Thunderbolt(TM) Max Length	0x40000	-	Thunerbolt(TM) Binary File		This loads the Thunderbolt(TM) binary me								
Parameter	Value																						
TBT Enable	Enabled	This setting Enables / Disables Thunderbol																					
Thunderbolt(TM) Max Length	0x40000	-																					
Thunerbolt(TM) Binary File		This loads the Thunderbolt(TM) binary me																					
6	<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 5%;">#</th> <th style="width: 60%;">Parameter</th> <th style="width: 15%;">Platform</th> <th style="width: 20%;">Settings</th> </tr> </thead> <tbody> <tr> <td></td> <td>TBT Image</td> <td></td> <td></td> </tr> <tr> <td></td> <td> TBT Enable Values: Enabled/Disabled This setting Enables / Disables Thunderbolt(TM) in the FWUpdate image. </td> <td>ICL-Y ICL-U</td> <td>Enabled Enabled</td> </tr> <tr> <td></td> <td>Thunderbolt(TM) Max Length</td> <td></td> <td></td> </tr> <tr> <td></td> <td> Thunderbolt(TM) Binary File Values: Binary File This loads the Thunderbolt(TM) binary merged into the output image generated by the Intel® FIT tool. </td> <td>ICL-Y ICL-U</td> <td>TBT Binary TBT Binary</td> </tr> </tbody> </table>	#	Parameter	Platform	Settings		TBT Image				TBT Enable Values: Enabled/Disabled This setting Enables / Disables Thunderbolt(TM) in the FWUpdate image.	ICL-Y ICL-U	Enabled Enabled		Thunderbolt(TM) Max Length				Thunderbolt(TM) Binary File Values: Binary File This loads the Thunderbolt(TM) binary merged into the output image generated by the Intel® FIT tool.	ICL-Y ICL-U	TBT Binary TBT Binary		
#	Parameter	Platform	Settings																				
	TBT Image																						
	TBT Enable Values: Enabled/Disabled This setting Enables / Disables Thunderbolt(TM) in the FWUpdate image.	ICL-Y ICL-U	Enabled Enabled																				
	Thunderbolt(TM) Max Length																						
	Thunderbolt(TM) Binary File Values: Binary File This loads the Thunderbolt(TM) binary merged into the output image generated by the Intel® FIT tool.	ICL-Y ICL-U	TBT Binary TBT Binary																				
Click on FW Update Image Build in the left tabs menu> ISH Image is expanded by default:																							
▼ ISH Image 7																							
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 30%;">Parameter</th> <th style="width: 30%;">Value</th> <th style="width: 40%;"></th> </tr> </thead> <tbody> <tr> <td>ISH Enable</td> <td>Enabled</td> <td>This setting Enables / Disables ISH in the F</td> </tr> <tr> <td>ISH Max Length</td> <td>0x40000</td> <td>-</td> </tr> <tr> <td>ISH Binary File</td> <td></td> <td>This loads the ISH binary merged into the</td> </tr> </tbody> </table>				Parameter	Value		ISH Enable	Enabled	This setting Enables / Disables ISH in the F	ISH Max Length	0x40000	-	ISH Binary File		This loads the ISH binary merged into the								
Parameter	Value																						
ISH Enable	Enabled	This setting Enables / Disables ISH in the F																					
ISH Max Length	0x40000	-																					
ISH Binary File		This loads the ISH binary merged into the																					
7	<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 5%;">#</th> <th style="width: 60%;">Parameter</th> <th style="width: 15%;">Platform</th> <th style="width: 20%;">Settings</th> </tr> </thead> <tbody> <tr> <td></td> <td>ISH Image</td> <td></td> <td></td> </tr> </tbody> </table>	#	Parameter	Platform	Settings		ISH Image																
#	Parameter	Platform	Settings																				
	ISH Image																						



Table 2-19. - FW Update Image Build

	ISH Enable Values: Enabled/Disabled This setting Enables / Disables ISH in the FWUpdate image.	ICL-Y ICL-U	Enabled Enabled
ISH Max Length			
	ISH Binary File Values: Binary File This loads the ISH binary merged into the output image generated by the Intel® FIT tool.	ICL-Y ICL-U	ISH Binary ISH Binary
Click on FW Update Image Build in the left tabs menu> IUNIT Image is expanded by default:			
▼ IUNIT Image 8			
<hr style="border: 1px solid orange;"/>			
	Parameter	Value	
	Iunit Enable	Enabled	This setting Enables / Disables IUNIT in the
	IUnit Max Length	0xA000	-
	IUnit Binary File		This loads the Iuint binary merged into the
#	Parameter	Platform	Settings
8	IUNIT Image		
	IUnit Enable Values: Enabled/Disabled This setting Enables / Disables IUNIT in the FWUpdate image.	ICL-Y ICL-U	Enabled Enabled
IUnit Max Length			
	IUnit Binary File Values: Binary File This loads the IUnit binary merged into the output image generated by the Intel® FIT tool.	ICL-Y ICL-U	IUnit Binary IUnit Binary
Click on FW Update Image Build in the left tabs menu> PCHC Image is expanded by default:			
▼ PCHC Image 9			
<hr style="border: 1px solid orange;"/>			
	Parameter	Value	
	PCH Configuration Enable	Enabled	This setting Enables / Disables PCHC in the FWUpdate image.
	PCH Configuration Max Length	0x1000	-
	PCH Configuration File		This loads the PCH Configuration binary merged into the outp
#	Parameter	Platform	Settings
9	PCHC Image		
	PCH Configuration Enable Values: Enabled/Disabled This setting Enables / Disables PCHC in the FWUpdate image.	ICL-Y ICL-U	Enabled Enabled
PCH Configuration Max Length			



Table 2-19. - FW Update Image Build

	Values: Binary File This loads the PCHC binary merged into the output image generated by the Intel® FIT tool.	ICL-Y ICL-U	PCHC Binary PCHC Binary



Table 2-20. - Intel® FIT - Build Image

#	Parameter	CRB	Values
1	Green Build button		Can also select CTRL+B, or Build> Build Image from the menu bar along the top of the screen
2	Console shows status of build and path where saved		
3	Console shows status of build and path where saved		



3 Programming SPI Flash Devices and Checking Firmware Status

Now that the Flash image file has been created, it can be programmed into the SPI Flash device(s) of the target machine. For platforms that don't boot, a Flash Chip Programmer will be required. For platforms that can boot to DOS or Windows*, the Intel® FPT can be used.

3.1 Flash Burner/Programmer

The specific use of a Flash burner/programmer is beyond the scope of this document. Here are some general steps that may be followed:

1. Navigate to your **Output Directory** (as specified in Table 2-2) where your generated SPI Flash image(s) are saved. It is assumed that this image file is named **outimage.bin**.

If two total SPI Flash devices were specified during the build process, then additional image files will be saved, one for each SPI Flash device. These files are assumed to be named **outimage(1).bin** and **outimage(2).bin**.

2. Utilize a Flash burner/programmer to program the image(s). For multiple SPI Flash devices, the images are numbered sequentially to correspond to the first and second SPI Flash device accordingly.

3.1.1 In-Circuit SPI Flash Programming for CRB

Mobile CRBs have the SPI Flash devices soldered down. As a result, to program the SPI Flash for mobile CRBs, follow these steps:

1. Leave CRB powered on.
2. Connect Flash Programmer (such as DediProg SF600) header to connector **J3F3** which is labelled "**SPI TPM**". Make sure to line up pin 1 on the header.
3. Program the first image [outimage(1).bin] to the CRB.
4. In DediProg software, select application memory chip 2 button and load second image if created.
5. Program the second image [outimage(2).bin] to the CRB if created.
6. Once programming is complete, disconnect the Flash Programmer header. Power off and unplug CRB. Remove cell coin battery, wait approximately 10 seconds. Replace cell coin battery, plug CRB back in and power on.

3.2 Flash Programming Tool (Intel® FPT)

Intel® FPT can be used to substitute for a Flash burner/programmer, provided the system is capable of booting to a DOS or Windows* OS.

Note: Intel® FPT will automatically disable the Intel® ME or EFI prior to flashing the image to the platform.



Intel® FPT DOS Version

The DOS versions supported by Intel® FPT are: DOS, Free DOS, and DRMK DOS. Use the following steps to program the SPI Flash devices,

1. Copy all the files in the “(root)\Tools\System Tools\Flash Programming Tool\DOS” directory to the root directory of a bootable USB key.
2. Navigate to your **Output Directory** (as specified in Table 2-2) where your generated SPI Flash image(s) are saved. It is assumed that this image file is named **outimage.bin**. Copy this image file to the root directory of the USB key.
3. Boot the target system to DOS and change to the root directory of the bootable USB key. At the DOS prompt type:

```
fpt.exe -i
```

The system should respond with the number of SPI Flash devices available. For example:

```
--- Flash Devices Found ---
W25Q64BV ID:0xEF4017 Size: 8192KB (65536Kb)
W25Q64BV ID:0xEF4017 Size: 8192KB (65536Kb)
```

Note: If the SPI Flash device does not currently contain a descriptor it may report only a single device.

4. Program the SPI Flash image to the Flash device(s) by issuing the following command at the prompt:

```
fpt.exe -f outimage.bin
```

If the programming was successful, then the following message will be shown.

```
FPT Operation Passed
```

If the programming was **NOT** successful, then repeat this step to try again. If programming problems persist, then check the SPI Flash devices and platform hardware.

5. Execute a platform global reset using Intel® FPT -greset. Next go to [Section 3.3](#) to check the Intel® ME Firmware status.

3.2.1 Intel® FPT Windows* Version

The Windows* OS versions supported by Intel® FPT are: Windows* PE 64, Windows* 7, Windows* 8/8.1. There are two versions of Intel® FPT for Windows*: a 32-bit version and a 64-bit version. Most Windows* OS, Windows* 7 (32-bit or 64-bit), Windows* 8/8.1 (32-bit or 64-bit) can use Windows* version of Intel® FPT. However, Windows* OS which do not support 32 bit compatible mode (Win PE 64-bit) **must use** Intel® FPT Windows* 64-bit version due to compatibility issues.



Use the following steps to program the SPI Flash devices,

1. Navigate to your **Output Directory** (as specified in [Table 2-2](#)) where your generated SPI Flash image(s) are saved. It is assumed that this image file is named **outimage.bin**. Copy this image file to Intel® FPT directory located at "(root)\Tools\System Tools\Flash Programming Tool\Windows".
2. Boot the target system to Windows* and open a Command Prompt window. In this window, change to the Intel® FPT directory and at the prompt type:

```
fptw.exe -i
```

The system should respond with the number of SPI Flash devices available. For example:

```
--- Flash Devices Found ---  
W25Q64BV ID:0xEF4017 Size: 8192KB (65536Kb)  
W25Q64BV ID:0xEF4017 Size: 8192KB (65536Kb)
```

Note: If the SPI Flash device does not currently contain a descriptor it may report only a single device.

3. Program the SPI Flash image to the Flash device(s) by issuing the following command at the prompt:

```
fptw.exe -f outimage.bin
```

If the programming was successful, then the following message will be shown.

```
FPT Operation Passed
```

If the programming was **NOT** successful, then repeat this step to try again. If programming problems persist, then check the SPI Flash devices and platform hardware.

4. Use `fptw.exe -greset` to perform a G3 power cycle. Next go to [Section 3.3](#) to check the Intel® ME Firmware status.

3.3 Checking Intel® ME Firmware Status

Use the following steps to check the platform health and Intel® ME FW status,

1. Copy the file **MEInfo.exe** in the "(root)\Tools\System Tools\MEInfo\DOS" directory to the root directory of a bootable USB key.
2. Boot the target system and use F2 or Del to enter the BIOS setup menu. Load default values for BIOS (on Intel® CRBs press F3 to load default values). Save and reboot (on Intel® CRBs press F4 and select Yes).
3. Boot the target system to DOS and change to the root directory of the bootable USB key. At the DOS prompt type:

```
MEInfo.exe -fwsts
```



The system should respond with a message similar to below.

```
Intel® MEInfo Version: 13.0.0.xxxx
Copyright(C) 2005 - 2017, Intel Corporation. All rights reserved.

FW Status Register1: 0x1E000255
FW Status Register2: 0x60002306
FW Status Register3: 0x00000300
FW Status Register4: 0x00004001
FW Status Register5: 0x00000101
FW Status Register6: 0x03C00FC9

Current State: Normal
ManufacturingMode: Enabled
FlashPartition: Valid
OperationalState: M0 with UMA
InitComplete: Complete
BUPLoadState: Success
ErrorCode: No Error
ModeOfOperation: Normal
Phase: HOSTCOMM Module
ICC: Valid OEM data, ICC programmed
SPI Flash Log: Not Present
ME File System Corrupted: No
FPF and ME Config Status: Not committed
```

As in the above example if there are NO errors shown, then

- your platform's health is good
- Intel® ME FW has successfully initialized
- Intel® ME FW is operating normally

Note: This section is only intended to show how to use the MEInfo.exe tool for checking firmware status. For full usage and capabilities of the MEInfo.exe tool, please see the System Tools User Guide.



3.4 Common Bring Up Issues and Troubleshooting Table

Table 3-1. Common Bring Up Issues and Troubleshooting Table

Problem / Issue	Solution / Workaround
System does not boot to DOS	By default, the system will boot to EFI Shell. To boot to DOS, <ol style="list-style-type: none"> 1. Enter BIOS menu, then go to the 'Boot' screen 2. Change 'Boot Option #1' to be your USB key (ensure USB key is formatted to be DOS bootable) 3. Press 'F4' to save settings and reboot
Hear 3 beeps when platform powers on	Possible device is disconnected or device not found, check <ul style="list-style-type: none"> • platform power and MCP fan power connectors • DIMM memory modules (if applicable for memory down modules) • USB devices (keyboard, mouse, USB key) may be plugged into inactive USB port • missing/incorrect jumpers • missing or poorly socketed MCP
No display on monitor	Ensure Corporate FW SKU supports integrated graphics. Try external graphics card.
USB device not detected or does not work	USB device may be plugged into inactive USB port
System does not boot (Post Code 00)	Incorrect Flash image – possible reasons: <ul style="list-style-type: none"> • wrong FW selected during Flash image build process • wrong Flash size selected Re-build image with correct settings and re-flash using Flash burner.

§ §



A Appendix — Flash Configurations

This chapter covers only the basic information needed for clock control parameter programming. For a more detailed treatment of Mainstream - Mobile Family clocks, see Intel® Ice Lake PCH-H / LP Clocks and Intel® Management Engine — Platform Compliancy Guide for ME Hardware.

Figure A-1. Configuration “A” — Desktop/Server/Workstation or Mobile






Figure A-2. Configuration “B” — Mobile Only




Figure A-3. Configuration “C” — Desktop/Server/Workstation Only







Figure A-4. Configuration “D” — Mobile Only



§ §



B Appendix — Intel® ICCS SKU Support Matrix

The following table describes ICC features supported for specific PCH SKU, clock range (maximum and minimum), spread mode supported by Ice Lake-LP SKUs.

Note: Please refer to Ice Lake-H/LP Platform Controller Hub (PCH) External Design Specification (EDS) for details about Ice Lake-H/LP Chipset Clock architecture

In below tables,

Min = Clock Div Max (minimum allowed frequency)

Max = Clock Div Min (maximum allowed frequency)

B.1 Intel® ICCS SKU Matrix - CNP-LP

Note: ICC SKU is divided into 2 categories: Basic and Enhanced. Mark "x" indicates category supported by PCH SKU.

Table B-1. Intel® ICCS SKU Matrix - CNP-LP

PCH SKU	Basic	Enhanced
Premium Y		x
Premium U		x
Base U		x
Features Supported	Standard Clock Configuration	Standard Clock Configuration Adaptive Clock Configuration
Pre-Defined ICC profile supported	Standard	Standard Adaptive
Clock Range Supported	[Min-Max]=100 MHz.	BCLK [Min-Max] = 98 - 100 MHz.
SSC Supported	Down SSC: 0 - 0.5%	Down SSC: 0 - 0.5%



C Appendix — Boot Guard Configuration

C.1 Boot Guard Profiles

The following table describes the profiles available for Boot Guard Configuration.

Table C-1. Profile Description

Index	Profile Name	F	V	M	ENF	PBE	Description
0	Boot Guard Profile - No_FVME	0	0	0	00	0	This configuration will invoke Boot Guard during boot with neither Verification nor Measurement. For platforms with all the required Boot Guard components but do not wish to enable Boot Guard boot block verification protection.
1	Boot Guard VE	0	1	0	01	1	When Verification is desired but if verification fails the platform will continue to boot with the unverified IBB for a short period, to allow remediation.
2	Boot Guard VME	0	1	1	01	1	When Verification and Measured are desired and the asset protection is provided by both TPM protection and a timed remediation period.
3	Boot Guard VM	0	1	1	00	1	When Verification and Measured are desired and the asset protection is provided by TPM protection.
4	Boot Guard FVE	1	1	0	11	1	Strict Verification enforcement.
5	Boot Guard FVME	1	1	1	11	1	Strict Verification and Measured enforcement. Prevents unverified IBB from running.

C.2 Enforcement Policies

Table C-2. Enforcement Policy Description

Error Enforcement Policy (ENF)	Enforcement Mode Name	Description
0	Unrestricted Mode	Infinite time before shutdown – don't shutdown the platform, let everything run normally.
1	Remediation Mode	30 minutes before shutdown – enough time to remediate the system, e.g. update BIOS or other data on flash via host tools.
2	Reserved	
3	Restricted Mode	0 minutes before shutdown – instant shutdown policy.



C.3 OEM Profile Parameters

Table C-3. Profile Parameters Description

Parameter	Description	Settings
Force Boot Guard ACM Enabled (F)	Force Boot Guard Boot determines if the platform starts the Force Boot Guard Boot timer. If it successfully starts it indicates success. When the Force Boot Guard timer stops, it starts the Protect Bios Environment timer, if indicated by the boot policy restrictions. Anchor ACM then jumps to the Initial Boot Block (IBB) with the Force Boot Guard Boot time stopped and the Protect BIOS enable timer running.	false - Allow the CPU to jump to the legacy reset vector if the Boot Guard Module cannot be successfully loaded. (default) true - Force the Boot Guard ACM to execute.
Verified Boot Enabled (V)	Boot Guard cryptographically verifies the platform Initial Boot Block (IBB) using the boot policy key. On successful verification, Boot Guard executes Initial Boot Block (IBB) using the boot policy key. If the verification fails, Anchor signals or enters Remediation.	false - Platform does not perform verified boot (default) true - Platform performs verified boot
Measured Boot Enabled (M)	Boot Guard measures the Initial Boot Block (IBB) into the TPM. Boot Guard perform no verification that the IBB is correct or from the platform manufacturer. The Skylake implementation of Boot Guard will support measurements into TPM or Intel's Platform Trust Technology.	false - Platform does not perform measured boot (default) true - Platform performs measured boot
Protect Bios Environment Enabled (PBE)	Platform manufacturer may want Initial boot block to be protected between verification/ measurement and execution from attacks on buses and non-CPU components. Boot Guard accomplishes this by allowing the initial boot block to be verified and executed in LLC in NEM if PBE is enabled.	false - Take no actions to control the environment during execution of the BIOS components (default) true - Takes actions to control the environment during the execution of the BIOS components.
Error Enforcement Policy (ENF)	Boot Guard invokes the Enforcement Policy when a fatal error is encountered. The action taken by ENF is determined by the OEM set persistent policies. Like, <ul style="list-style-type: none"> • Allowing platform to continue to boot • Immediate Shutdown • Shutdown with Timeout intervals When the ENF logic is invoked, PTT or TPM also disconnects.	See Section C-2 for details.



D Appendix — Intel® Platform Trust Technology

D.1 Intel® Platform Trust Technology

The following table describes the platform configurations supported by Intel® Platform Trust Technology.

Note: Intel® Platform Trust Technology does not support the full TPM functionality requirements and should not be used for Intel® vPro™ based platforms.

Table D-1. Intel® Platform Trust Technology Configuration table

Configuration	Platform Protection> Intel® PTT Configuration Intel® PTT Initial power up state	Platform Protection> Intel® PTT Configuration Intel® PTT Supported	Platform Protection> Intel® PTT Configuration Intel® PTT Supported [FPF]	Description
Intel® PTT Permanently Disabled in HW via FPF	Disabled	No	No	After the End of Manufacturing command, this setting will permanently set into the FPFs contained in the MCP. If disabled, the specific MCP can never be enabled for Intel® PTT.
Intel® PTT Permanently Disabled in base firmware image	Disabled	No	Yes	This setting allows Intel® PTT to be set to disabled without disabling the MCP FPFs. This is the recommended option to permanently disable Intel® PTT on a platform.
Intel® PTT Ship State Disabled in base firmware image	Disabled	Yes	Yes	Intel® PTT initially shipped in disabled mode, can be enabled by BIOS command.
Intel® PTT Enabled	Enabled	Yes	Yes	This is the recommended option to enable Intel® PTT on a platform.



E Appendix — Integrated Sensor Hub (ISH) Public Key Settings

The following table describes the configuration matrix required for ISH configuration for the Intel® FIT tool. Please see System Tools User Guide within ME kit, Manufacturing Test with Intel® Management Engine (Intel® ME) Firmware 12 and Intel® Integrated Sensor Solution on Ice Lake Mobile, Ice Lake Desktop, (CDI # WIP) for additional details.

CLSMNF = Close Manufacturing switch used with Intel® Flash Programming Tool (FPT)

PV = Production Version

For additional information on FPT see System Tools User Guide included with ME kit under system tools folder.

Table E-1. ISH Public Key Settings

Firmware	MCP	FPF Automatic Commit	FPF MEI command after CLSMNF (Yes/No)	FPF MEI command before CLSMNF (Yes/No)
Pre-production	Production	No	No - Not a valid combination	No - Not a valid combination
Production (PV not set)	Pre-production	No	Yes	No
Production (PV not set)	Production	No	Yes	No
Pre-production	Pre-production	No	Yes	No
Production (PV not set)	Production	Yes	No	No

Note: The Intel® FIT allows integration of binary files within Integrated Sensor Hub section under ISH Image and ISH Data. The Intel® FIT does not generate or create the required files. The table above lists configuration combinations that can be used.

