

# JVC

Digital Photo Navigator

ENGLISH



***INSTRUCTIONS***

LYT0966-001A

<b>INTRODUCTION</b> .....	4
Reading this document .....	4
<b>ENDLESS POSSIBILITIES</b> .....	5
Create a virtual album .....	5
Send your favorite images by e-mail .....	5
<b>Loading Still Images</b> .....	6
<b>ADDING STILL IMAGES TO AN ALBUM</b> .....	7
<b>EXITING DIGITAL PHOTO NAVIGATOR</b> .....	9
<b>Playing Back and Handling Images</b> .....	10
<b>LOADING AN ALBUM</b> .....	11
<b>DISPLAYING STILL IMAGES</b> .....	12
Displaying a selected still image .....	12
Displaying a series of images .....	12
Enlarging and reducing images .....	13
<b>ORGANIZING ALBUMS</b> .....	14
Selecting multiple still images .....	14
Deleting unnecessary still images .....	15
Copying still images .....	15
<b>SENDING IMAGES FROM AN ALBUM IN E-MAIL</b> .....	16
<b>CREATING A WEB PAGE</b> .....	17
<b>CHANGING THE IMAGE SIZE OR PICTURE QUALITY</b> .....	19
Changing the image size .....	19
Changing the picture quality, etc. ....	20
<b>RETRIEVING STILL IMAGES FROM AN ALBUM</b> .....	21
<b>CREATING A LIST OF STILL IMAGES</b> .....	22
<b>CREATING A SLIDE SHOW OR AN ANIMATION</b> .....	23
<b>Appendix</b> .....	24
<b>TROUBLESHOOTING</b> .....	25
<b>INDEX</b> .....	26

**CAUTION:**

- Operate this equipment according to the operating procedures described in this manual.
- Use only the provided CD-ROM. Never use any other CD-ROM to run this software.
- Do not attempt to modify this software.
- Changes or modifications not approved by JVC could void user's authority to operate the equipment.

**How to handle a CD-ROM**

- Take care not to soil or scratch the mirror surface (opposite to the printed surface). Do not write anything or put a sticker on either the front or back surface. If the CD-ROM gets dirty, gently wipe it with a soft cloth outward from the center hole using a circular motion.
  - Do not use conventional disc cleaners or cleaning spray.
  - Do not bend the CD-ROM or touch its mirror surface.
  - Do not store your CD-ROM in a dusty, hot or humid environment. Keep it away from direct sunlight.
- **You can find the latest information (in English) on the provided software program at our world wide web server at <http://www.jvc-victor.co.jp/english/index-e.html>**
- Microsoft® and Windows® are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.
  - Other product and company names included in this instruction manual are trademarks and/or registered trademarks of their respective holders.

## Reading this document

This document consists of the following two sections and an Appendix.  
Before use, please refer to the Software Installation and USB Connection Guide for preparation.

### ■ Loading Still Images

This section explains how to load still images into the album of the Digital Photo Navigator software.

### ■ Playing Back and Handling Images

This section explains how to handle still images using the Digital Photo Navigator software. You can send still images by e-mail and store an album as a web page.

### ■ Appendix

This appendix contains troubleshooting and index.

## Create a virtual album

If you have a lot of image files with similar names, it can be hard to remember which file contains which image.

You can use this software to display these images on your PC just as if you had pasted them in a photo album. Because you can scan through these images just as if you were flipping through a photo album, you can quickly find a specific image that you want to send through e-mail, for example.

### Can I distribute copies of albums?

You can save albums in web page format. When the album is saved in this format, anyone with a browser can view the album on any type of PC. Because the album is already in web page format, you can also exhibit your photos on the Internet.

Under copyright law, it is illegal to distribute copyrighted images without the permission of the copyright holder. Make sure that you have permission to distribute such images before actually doing so.

## Send your favorite images by e-mail

Everyone has memory cards containing images that they never get to show to anyone.

No matter how wonderful, the only people that got to see them were families and guests, because there was no convenient way to show them except in your own home on the TV. Friends and relatives who live far away had no way of viewing them. And you don't want to throw those memory cards away because they hold treasured memories.

Now you can solve all of these problems with a PC. By using a USB cable to connect a camcorder to a PC, you can copy images from the memory card to the PC (Refer to "Software Installation and USB Connection Guide"). You can then send the files to anyone as an e-mail attachment.

---

---


## Loading Still Images

---

---



The Digital Photo Navigator software allows you to store and view still images in a photo album format.

The icons on the Digital Photo Navigator window have the same functions as the menus. In this section, almost all the procedures are explained using the icons.



You can use Digital Photo Navigator to create an album that contains a collection of still images.

- 1** Select [Start] – [Programs] – [Digital Photo Navigator] – [Digital Photo Navigator 1.0].
  - Digital Photo Navigator starts.
  - Close any other programs running on the PC.
  - Disable any programs that run in the background, such as screen savers, e-mail applications, virus checkers, schedulers, etc.
  - Turn off file and printer sharing.
  
- 2** Click [Import].
- 3** Click [Image].
  - The [Open] dialog box appears.
- 4** Open the folder that contains the desired still images.
  - Select the folder of the still images copied to the PC and click [Open].
  - When loading images from a memory card, select the folder in the [DCIM] folder within [Removable Disk] and click [Open].
 The still image files appear in the window.



- 5** Select the desired still image files and click [Open].
  - The still images are added to the right-hand side of the Digital Photo Navigator window.
  - You may select more than one file.
  - You can also add files by dragging and dropping them in the Digital Photo Navigator window.
- 6** Add additional still images as desired by repeating steps 3 – 5.

**NOTES:**

- When loading images from a memory card, never disconnect the USB cable while the message [ACCESSING FILES] is displayed.
- Digital Photo Navigator can only load still images.



- 7 Click [Export].
- 8 Click [Album].  
The [Save As] dialog box appears.
- 9 Specify the location where you want to save the album, input the file name of the album, and then click [Save].  
The album is saved.



- If you save an album for the first time after the software installation, a message appears and asks if you want to register the association of the file extension name “jia”. Then, click [Yes].
- To exit Digital Photo Navigator, refer to “Exiting Digital Photo Navigator” (pg. 9).



- 1 Click the [File] menu and then click [Exit].
  - If you have already saved an album, a confirmation message appears. Then, go to step 2.



- If you have not saved an album after loading still images, a confirmation message appears.  
To save an album, click [Yes]. The [Save as] dialog box appears. Specify the location where you want to save the album, input the file name of the album, and then click [Save]. A confirmation message appears. Then, go to step 2.  
To exit Digital Photo Navigator without saving an album, click [No]. A confirmation message appears. Then, go to step 2.



- 2 Click [Yes].  
Digital Photo Navigator closes.



---

---

## Playing Back and Handling Images

---

---


This section explains how to handle still images using Digital Photo Navigator.

You can send still image files as an e-mail attachment and store an album as a web page. Be sure to read “Loading Still Images” before reading this section.


The icons on the Digital Photo Navigator window have the same functions as the menus. In this section, almost all the procedures are explained using the icons.



- 1 Start Digital Photo Navigator.
- 2 Click [Import].
- 3 Click [Album].  
The [Open] dialog box appears.



- 4 Open the folder where the album was saved.




- 5 Click the desired album file, and then click [Open].  
The contents of the album are displayed in the right-hand side of the Digital Photo Navigator window.
- 6 Click [Export].



#### NOTES:

- You can also open the album file by dragging and dropping it in the Digital Photo Navigator window.
- If an album is currently open, a confirmation message appears.
  - If you want to open the newly selected album instead of the one already opened, click [Yes]. If you have not saved the album already opened, a confirmation message appears. If you want to save the album, click [Yes]. If you do not want to save the album, click [No].
  - If you want to add still images from the newly selected album to the album already opened, click [No].



## Displaying a selected still image


You can select for display any of the still images that are displayed in the right-hand side of the Digital Photo Navigator window.

- 1 Double-click the still image to be displayed.  
The [Image Viewer] window appears, and the selected image is displayed.



## Displaying a series of images

To display a series of images in “slide show” fashion, click the  button in the [Image Viewer] window. You can also move through the images manually in either direction by clicking the  and  buttons.



To adjust the speed of the slide show, right-click the [Image Viewer] window and then, in the menu that appears, click [Slide show] – [Setting Interval Time]. Set the length of the interval (in seconds), and then click [OK].

### NOTE:

*The interval for a slide show is a little longer than the setting because of display processing time.*

## Enlarging and reducing images

The following procedure describes how to change the display size of a still image.

- 1 Drag the corner of the [Image Viewer] window to change the size of the window to the desired display size.
- 2 Right-click the [Image Viewer] window and then, in the menu that appears, click [Zoom] – [Auto].


The size of the still image is automatically enlarged or reduced to fit the window, and the display magnification (enlargement/reduction percentage) indicated in the title bar of the window changes accordingly.

### Other enlargement/reduction functions

In addition to adjusting the size of the image to the size of the window, the display size of a still image can also be changed by the methods described below. Each of these functions can be selected by right-clicking the [Image Viewer] window.

- [Zoom] – [Real Size]: Displays the image in its original size (display magnification of 100%).
- [Zoom] – [Zoom In]: Displays the image at twice its current display magnification (up to 400%).
- [Zoom] – [Zoom Out]: Displays the image at half its current display magnification (up to 20%).

Display magnification



Whenever necessary, you can delete or copy still images that you have added to an album. The procedure described below only affects the still image in the album. It does not affect the original file of the still image that was added to the album.

## Selecting multiple still images

To delete or copy multiple still Images at once, select them in advance. You can also select all still images in the album.


### Selecting still images continuously

Click still images while holding down the Shift key.




### Selecting still images one by one

Click still images while holding down the Ctrl key.




### Selecting all of the still images

Click [Select All] in the [Edit] menu.




## Deleting unnecessary still images

- 1 Click the still image that you want to delete, and then click [Delete] in the [Edit] menu.  
A confirmation message appears.




- 2 Click [Yes].  
The selected still images are deleted.



## Copying still images


- 1 Click the still image that you want to copy, and then click [Copy] in the [Edit] menu.



- 2 Click the image that is located right after the insertion point.
  - To add the images at the end of the album, click the blank space in the right-hand side of the window.
- 3 Click [Paste] in the [Edit] menu.  
The copied still images are inserted right before the selected image.

### NOTE:

You can delete, copy or paste an image also by right-clicking it.



Insertion point

Still images in an album can be sent as an e-mail attachment.

### Preparation: Before using the [E-Mail] function


If you use the Internet Explorer, be sure to use the version 5.5 or later.  
When installing the Internet Explorer, select a typical set of components.

1 Click the still image that you want to send, and then click [E-Mail].

The new message window in your e-mail program appears, and the still image file is registered as an attachment.

#### NOTES:

- Depending on an e-mail software, a new message window may not open when the [E-Mail] button is clicked.
- Depending on an e-mail software, settings such as "Set as MAPI client" or "Used by MAPI application" are necessary.
- The maximum number of messages that can be created at once is three.



You can save the contents of an album in HTML format. This is useful in the following instances:


- When creating a web page: You can create a web page that features a collection of photos.
- When distributing an album: You can create an album in a format that can be displayed by a web browser. This is useful if you want to distribute the album on CD-R, etc.

- 1** Select the still images that you want to save in HTML format.
  - To select more than one still image, hold down the Shift key or the Ctrl key while clicking the images.
  - To select all of the still images, click [Select All] in the [Edit] menu.

- 2** Click [Web Page].  
The [Web Page] dialog box appears.



- 3** Set the following items when necessary.
  - [Title]: This will be the title of the web page.
  - [Font Color]: This specifies the color of the title text.
  - [Back Color]: This specifies the background color of the web page. (Specify a color other than the font color.)
  - [Limit horizontal size of the images]: This allows you to specify the maximum width of the image when displayed by a web browser. (Set the number of pixels much smaller than the width of the PC's display.)




- 4** Click [OK], specify the save location, and then click [Save].

The HTML file is saved, and a folder with the same name is saved at the same time. A confirmation message appears next, asking whether to display the web page.

- 5** Click [Yes].

The web browser opens, and the HTML file that was created is displayed.

- Click on an image on the web page to enlarge it.



## What Next?

You can also view an HTML file through the web browser by double-clicking the HTML file. You can upload the HTML file to your home page, or save it on a CD-R or some other media and distribute it. Always handle HTML files and folders as a set. Without its folder, an HTML file cannot be viewed by a web browser.

### NOTES:

- For more details on how to create a home page, consult your Internet service provider's web site or one of the many reference books available.
- Use third-party home page creation software or similar software to edit HTML files.

## Changing the image size


This procedure describes how to change the size of an image that has been loaded into Digital Photo Navigator. This procedure is used to reduce the size of an image that is being attached to an e-mail or saved in an album.

- 1** Select the still image to be changed.
  - To select more than one still image, hold down the Shift key or the Ctrl key while clicking the images.
  - To select all of the still images, click [Select All] in the [Edit] menu.
- 2** Click [Change Format].  
The [Image Format] dialog box appears.



- 3** Select one of the following items:
  - [Expansion/Reduction]: Set any desired image size in the [Width] and [Height] fields. If the [Keep aspect ratio] check box is not selected (off), both [Width] and [Height] fields can be changed.
  - [Generic Size]: Select the size from a list of generic sizes.
  - [PDA Size]: This is an image size (160 x 160) that can be displayed on most PDAs.
- 4** Click [OK].

- If you select more than one still image in step 1, a confirmation message appears.
    - If you want to apply the same format to all images, click [Yes].
    - If you do not want to apply the same format, click [No]. The first image is saved. Then, select the image size for each image.
- The image size is changed to the selected size. If the vertical-to-horizontal ratio was changed, the blank spaces are shown as black.



## Changing the picture quality, etc.

In addition to changing the size of an image, it is also possible to rotate images, change or correct the quality of an image, and change the file format of an image. The role of each setting is described in more detail below.

### [90 degrees Rotation]

If you hold the camcorder sideways when recording an image, you can create an image that is taller than it is wide. Because this still image will be displayed sideways, use this function to rotate the image 90 degrees to the portrait orientation.

[None]: No correction

[Clockwise]: Rotates the image 90 degrees clockwise.

[Counterclockwise]: Rotates the image 90 degrees counterclockwise.



### [Image Correction (DV)]

Sometimes, when you shoot a subject that is moving very quickly, the resulting image will be blurred. It is possible to correct this blurring to a certain extent. Because the optimal type of correction depends on the still image, we recommend making a copy of the image and experimenting with the copy. It is not possible to correct for blurring caused by shaking the camera while shooting.

[None]: No correction

[Movement]: Corrects only the blurred portions.

[Field]: Corrects blurring more quickly than [Movement].

### [Format]

You can select the file format of an image.

[JPEG]: This is the format that is typically used on the Internet. This format has a smaller file size.

[BITMAP]: This is the standard Windows® image format (BMP). Many applications can use this format.

### [JPEG Quality]


This setting is available when JPEG was selected in the [Format] field. Moving the slider to the left makes the file smaller. Moving the slider to the right results in less deterioration in the image quality. The initial setting is 75.

#### NOTES:


- When [JPEG] is selected in the [Format] field, the quality of the image deteriorates slightly each time that [OK] is clicked for the [Image Format] dialog box. To restore the original image quality, reload the original still image file.
- The setting in the [Image Correction (DV)] field has an effect only when the still image was shot with a digital video camera.
- When [Field] is selected in the [Image Correction (DV)] field, the quality of the original image deteriorates.
- To confirm the file size, right-click the still image and then select [Properties].

You can retrieve still images from an album and save them as a file.

- 1** Select the still image to be retrieved.
  - To select more than one still image, hold down the Shift key or the Ctrl key while clicking the images.
  - To select all of the still images, click [Select All] in the [Edit] menu.
- 2** Click [Image].  
The [Image Format] dialog box appears.



- 3** Change the image format as desired. (☞ pg. 19, 20)  
Then, click [OK].
  - At this point, you can change the image size and picture quality as desired. (☞ pg. 19)  
The [Save As] dialog box appears.
- 4** Specify the location where you want to save the file, input the file name, and then click [Save].  
The image file is saved.



- If you select more than one still image in step 1, a confirmation message appears.
  - If you want to save all images with the same image format and their default name, click [Yes]. The [Auto Save Result] dialog box appears. Then, click [OK].
  - If you want to set the image format and input file name for each image, click [No]. The first image is saved. The [Image Format] dialog box appears for the second image. Repeat steps 3 and 4 as many times as necessary.

You can arrange multiple still images together and save them in a single still image file.

**1** Holding down the Shift key or the Ctrl key, select the still images that are to be added to the list.

**2** Click [Multi Image].

The [Multi Image] dialog box appears.



**3** Select the number of partitions.

- Either 4, 9, or 16 partitions may be selected.

**4** Click [Back Color], select the color for the overall background, and then click [OK].




**5** Change the positions of the still images as desired.

- Deleting an image: Right-click the still image and then select [Delete].
- Adding an image: Drag an image from the right-hand side of the Digital Photo Navigator window to the [Multi Image] dialog box.

**6** Click [Save].

The [Image Format] dialog box appears.




**7** Change the image format as desired. (☞ pg. 19, 20) Then, click [OK].

- At this point, you can change the image size and picture quality as desired. (☞ pg. 19) The [Save As] dialog box appears.

**8** Specify the location where you want to save the file, input the file name, and then click [Save].

The still image list file is saved.




You can create a slide show or an animation in which a series of still images are displayed, and then save those images as a movie file (extension “.avi”).


[Slide Show]: Still images are displayed for several seconds each, one at a time.

[Animation]: Several still images are displayed per second. We recommend that you select a series of still images that create the appearance of continuous movement.

- 1** Holding down the Shift key or the Ctrl key, select several still images.
- 2** Click [Movie].  
The [Movie Settings] dialog box appears.



- 3** Select either [Slide Show] or [Animation], which ever is desired.
  - For a slide show, set the length of the interval (in seconds).
  - For an animation, set the number of displayed frames (images) per second.
- 4** Set the following items when necessary.
  - [Image Size]: Select the size of the movie file.
  - [Compressor]: Select the type of compressor.
  - [Back Color]: This item is used if the aspect ratio of the images is not 4:3.



- 5** Click [OK].  
The [Save As] dialog box appears.
- 6** Specify the location where you want to save the file, input the file name, and then click [Save].
  - The file name can be changed.
 The movie file is saved, and a confirmation message that asks if you want to play the movie now appears.
- 7** Click [Yes].  
The movie file is played back.

**NOTES:**

- If you change the [Compressor] item, make sure that the playback system supports that type of compressor.
- Depending on the selected type for [Compressor], a movie file cannot be created.
- In some cases, the settings in the [Video Compression] dialog box are invalid.



---

---

## Appendix

---

---

This appendix contains troubleshooting and index.

SYMPTOM	CORRECTIVE ACTION	REFER TO:
Although the USB cable is connected, PC operating system does not recognize the memory card in the camcorder.	<ul style="list-style-type: none"> <li>• Make sure that the AC Adapter is connected to the camcorder and that the power is on.</li> <li>• Make sure that the USB cable is connected securely.</li> <li>• Either use a USB hub that has its own power supply, or connect the USB cable directly to the PC's USB connector.</li> <li>• Windows® might not be recognizing the USB connector. Make sure that the Universal Serial Bus controller is enabled on the [System Properties] sheet in the Control Panel.</li> </ul>	Software Installation and USB Connection Guide (☞ pg. 7)
Cannot copy or save files.	<ul style="list-style-type: none"> <li>• Make sure that there is enough free space available in the drive where you are trying to copy or save a file.</li> <li>• Make sure that the drive where you are trying to copy or save a file is not write-protected.</li> <li>• Make sure that a file with the same name does not already exist where you are trying to copy or save a file.</li> <li>• Either use a USB hub that has its own power supply, or connect the USB cable directly to the PC's USB connector.</li> </ul>	—
Cannot load still images into Digital Photo Navigator.	<ul style="list-style-type: none"> <li>• Sometimes the format of the still image data prevents it from being loaded into Digital Photo Navigator. Use other graphics drawing or processing software to convert the file to either bitmap format or JPEG format.</li> <li>• Make sure that there is enough free space available in the drive in which Digital Photo Navigator is installed.</li> </ul>	—
Still images have a mosaic appearance.	<ul style="list-style-type: none"> <li>• When a small image is loaded and enlarged, it will take on a mosaic appearance.</li> <li>• If an image is saved with a lower JPEG quality or if the format of the image is changed, it will take on a mosaic appearance.</li> </ul>	pg. 13 pg. 20
The colors displayed on the PC are odd.	<ul style="list-style-type: none"> <li>• Images will not be displayed correctly if the display is set for 256-color (or fewer) display.</li> </ul>	—

**A**

Adding still images to an album .....7

**C**

Changing the image size ..... 19

Changing the picture quality, etc. ....20

Copying still images ..... 15

Creating a list of still images .....22

Creating a slide show or

    an animation .....23

Creating a web page ..... 17

**D**

Deleting unnecessary still images ..... 15

Displaying a selected still image ..... 12

Displaying a series of images ..... 12

**E**

Enlarging and reducing images ..... 13

Exiting Digital Photo Navigator .....9

**L**

Loading an album ..... 11

**R**

Retrieving still images from  
    an album ..... 21

**S**

Selecting multiple still images ..... 14

Sending images from an album  
    in e-mail ..... 16

