

Kodak













**i50 Scanner
i60 Scanner**












**User's
Guide**

A-61182

Contents

Contents	i
Introduction	1
Safety	2
Safety and regulatory agency approvals	2
Acoustic emission	2
Electromagnetic compliance statements	3
For the United States	3
For Japan	3
Scanning specifications	4
Acceptable paper sizes	4
Document types to avoid in the ADF	4
Installation	5
Precautions	5
Shipping switch	5
Unlocking the scanner	5
Locking the scanner.....	6
Making connections	6
SCSI interface device ID	7
Setting the SCSI terminator	7
Adjusting the trays.....	8
ADF tray.....	8
Output tray	9
Powering up the scanner	9
Turning on the scanner	9
Turning off the scanner.....	9

Requirements and software installation.....	10
Installing the scanner drivers	10
Scanning your documents	11
Loading documents.....	11
Using the ADF.....	11
Using the flatbed	11
Scanning with TWAIN or ISIS	12
Making the most of your scanned images.....	13
 Scan Method	13
 Image Type	14
 Resolution	15
 Brightness	16
 Contrast	16
Enhancing your images.....	17
 Invert.....	17
 Mirror	17
 Preview Auto-Area	17
 Paper Size	17
 Units	17
 Descreen.....	18
 Sharpen.....	18

	Color Adjustment.....	18
	Auto Level	18
	Advanced Settings.....	18
	Highlight / Shadow.....	19
	Curves.....	20
	Color Balance	20
	Hue / Saturation / Lightness	21
	Color Drop-out.....	22
	Custom Settings.....	23
	Scan Settings.....	23
	Configuration Settings.....	24
	Other tools.....	25
	Width.....	25
	Height.....	25
	Size	25
	Lock scale	25
	Information	25
	Starting the final scan.....	26
	Preview	26
	Zoom View	26
	Scan (TWAIN) / OK (ISIS)	26
	Exit	26

Maintenance.....	27
Cleaning the glass scanning areas	27
Cleaning the ADF	28
Replacing the ADF snap-in feed module	29
Troubleshooting.....	30
Getting service	32
Equipment disposal.....	32
Scanner supplies.....	32
Specifications	33


Introduction

Thank you for purchasing a KODAK scanner.

- The KODAK i50 Scanner is a desktop *simplex* color scanner.
- The KODAK i60 Scanner is a desktop *duplex* color scanner.

Both scanners have automatic document feeders and flatbed platens to accommodate a wide range of general purpose, departmental, and office capture needs.

Before you install and operate your scanner, take a few minutes to read through this guide. It contains information about how to install, operate, and maintain your scanner. The illustration below shows how the scanner is packed.



Safety

- Use only the power supply that was provided with the scanner (Sino-American model SA60-24).

IMPORTANT: Do not substitute another power supply model or another manufacturer's power supply.

- Avoid the danger of electric shock. Only use the scanner and power supply indoors in a dry location.
- When positioning the scanner, make sure that the electrical power outlet is located within 1.52 metres (5 feet) of the scanner and is easily accessible.
- Locate the scanner on a stable, level work surface capable of supporting 8 kg (17.6 lb.).

Safety and regulatory agency approvals

The i50 Scanner and i60 Scanner conform to all applicable national and international product safety and electronic emission regulatory requirements. This includes, but is not limited to, the following:

- Underwriters Laboratories Inc. listing to UL 1950
- Underwriters Laboratories Inc. listing to CSA C22.2 No. 950
- TUV Rheinland approval to EN60950
- CFR 47 Part 15, Subpart B (FCC Class B)
- Canadian ICES-003 Class B
- CE Mark (Europe)
- CISPR22 Class B
- EN55022 Class B
- EN55024
- EN61000-3-2
- EN61000-3-3
- AS/NZS 3548 C-Tick Mark (Australia)
- VCCI Class B
- Taiwan CNS 13438 Class B

Acoustic emission

Operator position sound pressure levels (L_{pA}):

- Standby: < 46 dB(A)
- Full system: < 58 dB(A)
- Instantaneous peak values \geq 130 dB(C): None

Electromagnetic compliance statements

For the United States

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

For Japan

This is a Class B product based on the standard of the Voluntary Control Council for Interference from Information Technology Equipment (VCCI). If this is used near a radio or television receiver in a domestic environment, it may cause radio interference. Install and use the equipment according to the instruction manual.

この装置は、情報処理装置等電波障害自主規制協議会（VCCI）の基準に基づくクラスB情報技術装置です。この装置は、家庭環境で使用することを目的としていますが、この装置がラジオやテレビジョン受信機に近接して使用されると、受信障害を引き起こすことがあります。
取扱説明書に従って正しい取り扱いをして下さい。

Scanning specifications

Acceptable paper sizes

You can use the i50 Scanner and i60 Scanner to scan documents that have a paper weight between 50 and 105 g (14 and 28 lb.) and that are within the following sizes:

In the ADF (automatic document feeder)

- 94 x 140 mm (3.7 x 5.5 in.) minimum
- 216 x 356 mm (8.5 x 14 in.) maximum

On the flatbed

- up to A4 size (8.3 x 11.7 in.)

Document types to avoid in the ADF

Do not use the ADF (automatic document feeder) to scan the document types listed below. Instead, use the flatbed to scan documents that cannot be fed by the ADF.

- Paper with clips or staples attached
- Paper with wet or damp ink
- Paper with inconsistent thickness, such as envelopes
- Paper with wrinkles, curls, folds, or tears
- Tracing paper
- Carbonless paper
- Items other than paper, such as cloth, metal, or OHP film
- Notched paper
- Paper with an odd (non-rectangular) shape
- Paper weight less than 50 g (14 lb.) or greater than 105 g (28 lb.)

Installation

Unpack the scanner carefully and check the contents. If any items are missing or damaged, contact your authorized dealer immediately.

Precautions

- Keep the scanner out of direct sunlight. Direct exposure to sun or excessive heat may cause damage to the unit.
- Do not install the scanner in a humid or dusty area.
- Be sure to use the proper AC power source.
- Place the scanner securely on a level surface. Tilted or uneven surfaces may cause mechanical or paper-feeding problems.
- Keep the scanner box and packing materials for shipping purposes.
- Unlock the shipping switch (see instructions below) *before* you power up the scanner.
- Make sure that the scanner is on and has completed its self-test before you turn on the PC to begin scanning.


Shipping switch

The scanner has a shipping switch that locks the carrier mechanism to avoid causing damage during transportation.

- Unlock the shipping switch before you connect the cord and cable and before you power up the scanner.
- Lock the shipping switch before moving the scanner to a new location.

Unlocking the scanner

1. Place the scanner in an upright position on its front.
2. Unlock the scanner by moving the shipping switch (located on the bottom of the scanner) to the unlocked position.



3. Place the scanner back in its normal position.


Locking the scanner

1. Make sure that the scanner is off.
2. Raise the document cover to reveal the flatbed platen and scanning unit.
3. Turn on the scanner.
The scanning unit begins moving.
4. Wait until the scanning unit has moved to the end (opposite the scanner ADF).
5. Turn the scanner off after the scanning unit has finished moving.
6. Place the scanner in an upright position on its front.
7. Lock the scanner by moving the shipping switch (located on the bottom of the scanner) to the locked position.
8. Place the scanner back in its normal position.

Making connections

Connect the power cord and SCSI signal cable as shown below.

NOTE: There are two SCSI ports on the scanner. You can use either a DB25 (male) or a 50-pin Amphenol connector to connect to the scanner.




SCSI interface device ID

When you have several devices on a SCSI chain, you may need to adjust the SCSI ID selector on the scanner. This selector assigns a specific device ID to the scanner. If the assignment conflicts with an existing SCSI device, select a new ID.

NOTE: The factory setting for the scanner is ID 6. ID 0 is usually assigned to an internal hard disk drive and ID 7, ID 8, and ID 9 are not in actual use. The scanner will not operate properly if the SCSI ID is set to ID 7, ID 8, or ID 9.

- Using a suitable tool, turn the SCSI ID selector switch until the arrow points to the desired ID number.



Setting the SCSI terminator

The scanner comes with a built-in SCSI terminator. The terminator on/off switch is located on the scanner between the SCSI cable connectors.


- If the scanner is the only or the last device in a SCSI chain, place the terminator switch in the ON position.
- If the scanner is to be located between the computer and another SCSI device, place the terminator switch in the OFF position.

Adjusting the trays


There are two trays on the scanner: the ADF tray for loading documents to be scanned through the automatic document feeder and the output tray which receives scanned documents from the ADF.

ADF tray


1. Lift the ADF tray to about a 45° angle.
2. Pull the ADF tray wire leg down on top of the clips on the document cover.



3. Press down slightly on the ADF tray to snap the wire leg into the clips.




4. Pull the ADF tray extension wire out to the desired length.



Output tray

1. Lift the output tray to about a 30° angle.
2. Insert the three protrusions on the output tray into the three slots on the ADF.
3. Release the output tray.



4. Make sure that the output tray is firmly attached to the ADF.
5. Pull the output tray extension wire out to the desired length.

Powering up the scanner

Make sure that you press the I/O power switch and not the SCSI terminator switch (which has an ON/OFF label under it) when you want to turn the scanner on or off. The scanner must be on and its self-test completed before you power up the PC.

IMPORTANT: Before you power up the scanner, make sure that there are no documents in the ADF or on the flatbed platen.

Turning on the scanner

- Press the side of the power switch that is marked "I" to turn on the scanner. The power light on the ADF illuminates. If it does not, check the power source.

Turning off the scanner

- Press the side of the power switch that is marked "O" to turn off the scanner.

Requirements and software installation

To operate the scanner at its optimum speed, the following minimum configuration is required.

NOTE: The actual performance of the system depends on the scanning application, choice of scanning parameters, and the PC configuration. If the scanner is not performing at the optimal speed, using a faster PC and/or more RAM may be necessary to obtain the rated throughput.

- IBM PC (or compatible) with a Pentium 933 MHz processor
- Microsoft Windows 95, Windows 98, Windows NT 4.0, Windows 2000, or Windows Millennium Edition (Me)
- 100 MB of available hard disk space (200 MB is recommended)
- 128 MB of RAM
- Monitor (VGA)
- Mouse
- CD-ROM drive

Installing the scanner drivers

1. Start your PC and Windows application.
2. Insert the KODAK i50/i60 Scanner CD that contains the device drivers in your CD-ROM drive.

NOTE: If the CD does not start automatically, click on the **Start** button and choose *Run*, then type **d:\driver\setup.exe** (where "d" is the letter of your CD-ROM drive). Click on the **OK** button.

3. Follow the instructions on the screen to complete the driver installation.

Scanning your documents


Loading documents

Make sure that the scanner is on and has completed its self-test before you turn on the PC to begin scanning. See the section entitled “Scanning specifications” for information about the sizes and types of documents that you can scan.

Using the ADF

Use the ADF to feed multiple documents automatically in a batch.


1. Fan documents before loading to prevent paper jams.
2. Place the documents face down under the balance wire in the ADF tray, with the leading edges in the auto feeder entrance.
3. Adjust the left and right guides until they are snug against the document sides.



Using the flatbed

Use the flatbed to scan documents that cannot be scanned using the ADF.

1. Place the document face down on the glass platen.
2. Position the document with the upper right corner aligned with the reference mark.



Scanning with TWAIN or ISIS

1. Open your scanning application.

2. Choose **Select Source** or **Select Scanner** on the File menu.

If the Select Source or Select Scanner command is not available on the File menu, see your application's user's guide to determine how the application link is used.

A dialog box with a list of scanning sources appears.


3. Select your **Kodak scanner model**.

You need to select the source only once, unless you want to choose another scanner.


4. Place the document to be scanned in the ADF or on the flatbed glass platen.


5. Pull down the File menu and choose **Acquire**.

A dialog box containing scanning features appears. (The TWAIN dialog box is shown below.)



6. Select a scanning method on the **Scan Method**  drop-down menu.

7. Select a scanning mode on the **Image Type**  drop-down menu.

8. Select a scanning resolution on the **Resolution**  drop-down menu.

9. Select the settings for the scanning features (e.g., Sharpen, Descreen, etc.) that you want to use.

NOTE: Refer to the driver feature descriptions in the following section, "Making the most of your scanned images."

10. Click on the **Preview** button to preview your document(s).

11. Click on the **Scan** (TWAIN) or **OK** (ISIS) button scan your document(s).

Making the most of your scanned images

The features in the TWAIN and ISIS dialog boxes are described in this section.

Note that not all features are available at all times. The availability of some features may depend on the scanner model or other feature selections.

Scan Method



Select how you want to scan on the **Scan Method** drop-down menu.

TWAIN

Simplex/One-page—select this setting if you are using the automatic document feeder (ADF) to scan one side of a document at a time.

Simplex/Multi-page—select this setting if you are using the automatic document feeder (ADF) to scan one side of a document at a time in a batch of documents.

Flatbed—select this setting if you are using the flatbed to scan one side of a document at a time.

Duplex/One-page—select this setting if you are using the automatic document feeder (ADF) to scan both sides of one document at a time (i60 Scanner only).

Duplex/Multi-page—select this setting if you are using the automatic document feeder (ADF) to scan both sides of documents in a batch of documents (i60 Scanner only).

ISIS

Simplex—select this setting if you are using the automatic document feeder (ADF) to scan one side of a document at a time in a batch of documents.

Flatbed—select this setting if you are using the flatbed to scan one side of a document at a time.

Duplex—select this setting if you are using the automatic document feeder (ADF) to scan both sides of documents in a batch of documents (i60 Scanner only).

Image Type



Select the mode you want to use for your scans on the **Image Type** drop-down menu.

Black and White—the image appears in black and white with no intermediate shades of gray. That means that each pixel of the image is either 100% black or 100% white.

Choose *Black and White* if you are scanning text or pen and ink drawings. Since only one bit of black or white information is required per pixel, the file size of a *Black and White* image is only about 1/24 the size of a *24-Bit Color* image.

Halftone—a halftone is a picture like that which is usually seen in a newspaper or magazine. Since a halftone is a type of black-and-white image, the file size of a halftone image is only about 1/24 the size of a *24-Bit Color* image.

Halftone simulates grayscale by using varying dot sizes. If you view a halftone image at a certain distance, it looks much like a grayscale image, but the file size is smaller.

When you select *Halftone*, a submenu appears that allows you to select a halftone pattern.

8-Bit Gray—a single-channel image consists of at least 256 shades of gray. An 8-bit scanner produces a grayscale image with 1024 shades of gray between pure black and pure white. Choose this option if you are scanning black-and-white photographs.

With 8 bits of color information per pixel, the file size of an image is eight times larger than a *Black and White* image and 1/3 the size of a *24-Bit Color* image.

8-Bit Color—an *8-Bit Color* image provides 256 color hues in the image. The file size of a *256 color* image is 1/3 the size of a *24-Bit Color* image (TWAIN only).

24-Bit Color—a *24-Bit Color* image consists of three 8-bit color channels. The red, green, and blue channels are mixed together to create a combination of one billion colors which give a more true-to-life quality to the image. Choose *24-Bit Color* if you are scanning color photos.

Resolution



Resolution or dots per inch (dpi) indicates the scanning resolution, which largely determines the quality of the scanned image. The greater the resolution, the better the reproduction will be.

However, scanning at a higher resolution also increases scanning time and file size. Therefore, up to a certain dpi level, the resolution will not be visually improved, but the file size will be larger.

Tips

An A4-size color image scanned at 300 dpi in *24-Bit Color* mode is approximately 25 MB in size. A higher resolution (usually over 600 dpi) is recommended only when you need to scan a small area in *24-Bit Color* mode.

Refer to the following table to choose the best image resolution for use with your application.

Scanner Settings Application	Image Type	Resolution (dpi)
File, Fax, E-mail Your Document	Black and White	200
View, Copy, Edit Your Color Picture	24-Bit Color	100
OCR* Your Document	Black and White	300

* OCR (Optical Character Recognition): the process of converting an image to a text format.

Brightness



This function allows you to adjust the image brightness, making it lighter or darker.

You can adjust the brightness setting from -100 to 100 by dragging the Brightness sliding control bar. The default is "0." The smaller the number, the darker the image. Scan the document and check the brightness.

A darker setting is recommended for blurred character documents. With a brighter setting, background noise in a color document disappears.

Contrast



The **Contrast** option sets the image contrast by adjusting the difference between black and white, thereby making an image sharper or softer.

You can adjust the contrast setting from -100 to 100 by dragging the Contrast sliding control bar. The default is "0." Scan the document and check the contrast.

In a low-contrast setting, the difference between black and white is small, so the image is softer. In a high-contrast setting, the difference between black and white is large, so the image is clearer.

Enhancing your images

These features allow you to improve or enhance the appearance of scanned images.

Invert



Click on the **Invert** button to reverse the brightness and color in the image.

For black-and-white images, black areas will be white and white areas will be black. For color images, inverting the image will cause each pixel to be changed into its complementary color.

Mirror




Click on the **Mirror** button to reverse the image (create a mirror image).

Preview Auto-Area



Clicking on this button automatically crops the preview scan area to the previewed document. This will then be the cropping area for all of the scanned documents.

Click on the arrows  at the lower right side of the Preview box to view the front and rear scanned images (i60 Scanner only).

NOTE: The arrows appear in the dialog box only when a duplex scanning method has been selected (i60 scanner only).

Using **Preview Auto-Area** on batches of mixed-size documents is not recommended because cropping is not performed separately on each document in the batch.

If *Black and White* is selected on the **Image Type** drop-down menu, documents may be cropped to the document content when using **Preview Auto-Area**.

Paper Size



Select a size on the **Paper Size** list of frequently used scan sizes, including business card, 5 x 3 in., 6 x 4 in., Letter, Legal, B5, A5, A4, or your current scan area to perform an immediate selection of your scan size.

Units



The **Units** button indicates the measuring system that is in use (Inch, Cm, or Pixel).

Descreen



Click on the **Descreen** button to access a drop-down menu that allows you to specify the type of document you are scanning in order to eliminate the moiré pattern* commonly found in printed matter. You can specify *Newspaper*, *Magazine*, or *Catalog*.

* Moiré pattern: an undesirable pattern resulting from the incorrect screen angle of the overprinting halftone.


Sharpen



Click on the **Sharpen** button to access a drop-down menu that allows you to specify a level to sharpen the scanned image. You can specify a Sharpen setting of *Light*, *More*, *Heavy*, or *Extra Heavy*.

Color Adjustment



Click on the **Color Adjustment** button to enable the button  for the **Hue**, **Saturation**, and **Lightness** feature.

NOTE: The **Advanced Settings** button  must be enabled in order to use the **Hue**, **Saturation**, and **Lightness** feature.

Auto Level



Click on the **Auto Level** button to add shadow to reveal more details in an image.

Advanced Settings




Click on the **Advanced Settings** button to view the advanced settings buttons for Highlight / Shadow, Curves, Color Balance, Hue / Saturation / Lightness, Color Drop-out, and Custom Settings (six buttons on the right side of the dialog box).

Highlight / Shadow



This feature is available when *8-Bit Gray*, *8-Bit Color*, or *24-Bit Color* is selected on the **Image Type** drop-down menu. Highlight refers the lightest point in a scanned image; shadow refers the darkest point.

Click on the **Highlight / Shadow** button to access the Highlight / Shadow Levels dialog box. You can type values in the text boxes or you can place the mouse cursor on the arrow at the bottom of the box, hold down the right mouse button, and drag the arrow to specify the values you want.




(S = Shadow, G = Gamma, H = Highlight)


Use the **Highlight** and **Shadow** settings together to extend the range of color and reveal more details in a color image.

Curves



When you select the **Curves** button, a dialog box appears that allows you to adjust the midtone of the image without losing details in the lightest and darkest areas.

Select the *Curve* or the *Line* button  on the bottom right of the Curves dialog box, depending on whether you want a curved or an angled setting. Place the mouse cursor over the line, click the right mouse button, and drag the line to set a curve.




Color Balance



When you select the **Color Balance** button, a dialog box appears that allows you to adjust the color of the image so that it comes close to that of the original.


The default parameters are used to adjust the image. You can type values in the *Color Levels* text boxes or you can drag the sliding arrow under the color.



Hue / Saturation / Lightness



Click on this button to access a dialog box that allows you to adjust the hue, saturation, and lightness of an image.



Hue—specify a value in the **Hue** text box or click and drag the sliding arrow under the box to adjust the hue up to 360°.

Saturation—specify a value in the **Saturation** text box or click and drag the sliding arrow under the box to adjust the saturation level of the color.

The level of saturation indicates whether the color is pale or rich.


Lightness—specify a value in the **Lightness** text box or click and drag the sliding arrow under the box to adjust the color strength.

NOTE: Select the **Color Adjustment** button  to enable the Hue / Saturation / Lightness button.

Color Drop-out



This feature is available when *Black and White*, *Halftone*, or *8-Bit Gray* is selected on the **Image Type** drop-down menu. Click on the **Color Drop-out** button to access a dialog box that allows you to choose to remove the R (Red), G (Green), or B (Blue) color channel while scanning.



For example, if your image contains red text or a red background, choose **R channel** (red) to remove the red text or red background.

This feature is applicable only for black-and-white and grayscale images. Make sure that you have selected a black-and-white or grayscale image type (on the **Image Type** drop-down menu) when you use this option.

Tip

Increasing the brightness after removing one of the color channels will make the image clearer.


Custom Settings



Click on the **Custom Settings** button to access a dialog box where you can save your scan settings and configuration settings. There are two tabs: Scan Settings and Configuration Settings.

Scan Settings

The Scan Settings tab allows you to save your scanning feature settings in a file, load an existing file, or delete an existing file.



Saving a scan settings file

Type a name for your settings in the **File Name** text box and click on the **Save** button. Your settings will be saved and the file name will appear in the list box.

Using a scan settings file


You can use an existing settings file. Right-click on the file name for the settings you want to use and click on the **Load** button. The settings in the file will automatically be specified in the scanning features dialog box.

Deleting a scan settings file

Right-click on a file name and press the **Delete** button on the computer keyboard to delete the file. You cannot delete the default scan settings file *default.av2*.

Configuration Settings

The Configuration Settings tab allows you to customize some special settings.



Energy Saving Mode—check the **Enable** box to enable automatic lamp shut-off. Specify a time delay of 1 to 60 minutes in the **Minutes** box. This is the amount of time that the scanner will wait before shutting off the lamps after the last scan operation. Click on the **Apply** button to save the changes.

Hint Setting—check the **Show Hints** box if you want to have flags showing feature names appear when you place the mouse cursor on features in the dialog box. Click on the **Apply** button to save the changes.

Other tools

In addition to the image enhancement options, the dialog box contains the items described below.

Width

Shows the current image width. You can enter a custom value in the **Width** box.

NOTE: If you manually change the width value with **Lock scale** enabled, the value in the **Height** box will automatically change proportionally.

Height

Shows the current image height. You can enter a custom value in the **Height** box.

NOTE: If you manually change the height value with **Lock scale** enabled, the value in the **Width** box will automatically change proportionally.

Size

Shows the current file size of the scanned image.

Lock scale



Click on the **Lock scale** button to enable lock scaling, which keeps the scanning width and height proportional to the paper size selected in the **Paper Size** setting.

When **Lock scale** is enabled and you manually change the value in the **Width** box, the value in the **Height** box will automatically change proportionally, and vice versa.

Information



Click on the **Information** button to access a window that gives you information about the scanner and driver.


Starting the final scan

The buttons shown below allow you to begin scanning or to exit the job.

Preview

Click on the **Preview** button to scan a document so you can review the scanned image. This allows you to specify an area to be scanned and any scanning feature settings to be used for future scans. When a scanning feature is changed and applied, the Preview image is updated for a real-time view of the change.

You can define the area to be scanned by dragging the cursor lines with the mouse.

Click on the arrows  at the lower right side of the Preview box to view the front and rear scanned images (i60 Scanner only).

NOTE: The arrows appear in the dialog box only when a duplex scanning method has been selected (i60 Scanner only).

Zoom View

Click on the **Zoom View** button to view a selected area.

Scan (TWAIN)

OK (ISIS)

Click on the **Scan** (TWAIN) or **OK** (ISIS) button to scan the area with the specified parameters.

You can define the area to be scanned by dragging the cursor lines with the mouse.

Exit

Click on the **Exit** button to cancel the current job.

Maintenance

The scanner is designed to be maintenance free. However, it must be cleaned occasionally to ensure optimum image quality and performance.

Cleaning the glass scanning areas

1. Moisten a lint-free cloth with isopropyl alcohol (95%).

WARNING: Isopropyl alcohol is a flammable liquid.


CAUTION: Do not use isopropyl alcohol around open flame or on hot surfaces.

Avoid vigorous rubbing; use gentle contact.

Isopropyl alcohol may cause eye irritation and dry skin.

For additional information, contact your isopropyl alcohol supplier.

2. Open the ADF and document cover.



3. Wipe the platen glass and ADF area glass side to side with the cloth.
4. Close the ADF and document cover.

The scanner is now ready for use.

Cleaning the ADF

The ADF feed module and the feed rollers may become contaminated with ink, toner, and paper dust. If the scanner does not feed documents smoothly or if multiple-sheet feeding occurs, you must clean the scanner.

1. Moisten a lint-free cloth with isopropyl alcohol (95%).

WARNING: Isopropyl alcohol is a flammable liquid.

CAUTION: Do not use isopropyl alcohol around open flame or on hot surfaces.


Avoid vigorous rubbing; use gentle contact.

Isopropyl alcohol may cause eye irritation and dry skin.

For additional information, contact your isopropyl alcohol supplier.

2. Open the ADF.
3. Wipe the ADF feed module with the cloth.
4. Wipe the feed rollers with the cloth from side to side and top to bottom. Rotate the rollers by hand as you clean them.

Be careful not to snag or damage the springs.



5. Close the ADF.

The scanner is now ready for use.


Replacing the ADF snap-in feed module

After approximately 100,000 pages have been scanned through the ADF, the separation pad may become worn and cause document feeding problems. In this case, you should replace the feed module.


Four replacement ADF snap-in feed modules are included with your scanner. To order more feed modules, consult your dealer or order online at www.kodak.com/go/shop (order KODAK Feed Module for Scanners i50/i60; catalog number 181-4300.)

Follow the procedure below to replace the feed module.

1. Open the ADF.
2. Remove the ADF snap-in feed module by pinching the gray tabs.
3. Pull out the upper part of the pad clamp.



4. Take the ADF feed module out of its box.
5. Hold the upper part of the pad clamp and place it on the pad holder.



6. Close the ADF.

The scanner is now ready for use.

Troubleshooting

The scanner automatically performs a simple self-test each time it is powered up. This helps spot major system errors in the scanner itself. When the self-test is initiated, the READY light flashes. When the self-test is completed, if no error has occurred, the READY light is steadily illuminated.

Occasionally, you may experience a problem with your scanner. In many cases, you can easily fix the problem yourself. Refer to the following chart for some common problems and their solutions.

Problem	Solution
The light indicates that the scanner is ready, but the scanner does not respond to the scan command from the host computer.	<ul style="list-style-type: none">• Verify that the signal cable is firmly seated, then invoke the scan command again. If there is still no response, reset the scanner by turning it off, then on again. Reboot the host computer.• Verify that the driver is correctly installed.
The red error light is illuminated or is flashing after the scanner's power cycle.	<ul style="list-style-type: none">• The scanner self-test has failed. Reset the scanner by turning it off, then on again. If the problem persists, contact service.
The red error light is illuminated while scanning.	<ul style="list-style-type: none">• The scanner has jammed or a multifeed has been detected.• There is a hardware problem. Reset the scanner by turning it off, then on again. If the problem persists, contact service.
Paper becomes jammed during scanning.	<ul style="list-style-type: none">• Open the ADF and pull out the jammed paper. Close the ADF.
More than one sheet of paper was fed into the scanner (a multifeed).	<ul style="list-style-type: none">• Flatten document corners and edges. Fan the paper before you load it in the ADF tray.• Check the feed roller condition. Clean the rollers, if necessary.
Paper becomes skewed in the scanner.	<ul style="list-style-type: none">• Check the feed roller condition. Clean the rollers, if necessary.• Use the paper guides when feeding documents.
When the scanner is powered up, it makes noise and does not come to the READY state.	<ul style="list-style-type: none">• The shipping switch was not unlocked from the scanner. Unlock it.• The scanner is not located on a level surface. This may cause the scanner to function improperly.
You can specify an image from the scanner, but the scanner or computer crashes when scanning.	<ul style="list-style-type: none">• Verify that the cable is firmly seated.• Only two SCSI terminators can be connected to the SCSI daisy chain: one is at the end of the SCSI device and the other is already in the host adapter.

Problem	Solution
When the scanner is powered up, the lamp does not light.	<ul style="list-style-type: none"> • The lamp is dead. Contact your dealer to change the lamp. Lamp life is about 15,000 hours. • If the power light on the ADF is flashing, the power adapter is malfunctioning or the main board has short-circuited. Contact your dealer to replace the power adapter or main board.
The scanned image is too dark.	<ul style="list-style-type: none"> • Modify the Curves setting to 2.2 and 1.8 for your printer and monitor, respectively. • Use the Brightness setting to get a brighter image.
The scanned lines of <i>Black and White</i> images seem much thicker than those of the original.	<ul style="list-style-type: none"> • Use the Brightness or Threshold setting to adjust <i>Black and White</i> images.
The color image quality is not acceptable.	<p>Color image quality is highly subjective. Here are some things to consider when scanning in color:</p> <ul style="list-style-type: none"> • The differing color gamuts of capture, display, and output devices can affect color perception. Computer monitor displays and printer output can vary from model to model and from manufacturer to manufacturer. An image may be acceptable on one monitor and unacceptable on another. • Area lighting (fluorescent, natural, incandescent) can affect color perception. • The appearance of a colored area within an image can be perceived differently, based on what surrounds it. • The characteristics and condition of a document can have an impact on color consistency. • Color requirements may differ between environments (e.g., in a business document environment, images are generally viewed on a monitor, whereas in a “print on demand” environment, scanned images are printed.) • Make sure that the ADF and the glass areas are clean.

Getting service

If you believe that your scanner needs service, go to www.kodak.com/go/docimaging. There you can find out how best to obtain service for your scanner.

Equipment disposal

The i50 Scanner and i60 Scanner contain lead in the circuit board and mercury in the lamp. Disposal of these materials may be regulated due to environmental considerations. For disposal or recycling information, please contact your local authorities or visit the Electronics Industry Alliance web site at www.eiae.org.

Scanner supplies

Order scanner supplies from your dealer or online at www.kodak.com/go/shop.

Item	Catalog Number
KODAK Feed Module for Scanners i50/i60 (ADF snap-in feed module)	181-4300

Specifications

Scanner type	i50 Scanner: ADF/flatbed desktop simplex color scanner i60 Scanner: ADF/flatbed desktop duplex color scanner	
Optical resolution	300 dpi	
Scanning output	24-bit (RGB) color, 8-bit grayscale, or 1-bit bitonal	
Light source	Cold cathode fluorescent lamp	
ADF capacity	75 sheets of 16 lb. bond or 50 sheets of 20 lb. bond	
ADF scanning speed	<p style="text-align: center;"><u>i50 Scanner</u></p> 20 ppm (200 dpi, B&W mode, ADF) 13 ppm (200 dpi, grayscale mode, ADF) 10 ppm (150 dpi, color mode, ADF) NOTE: Results may vary depending on your scanning application and computer processor speed.	<p style="text-align: center;"><u>i60 Scanner</u></p> 25 ppm (200 dpi, B&W mode, ADF) 13 ppm (200 dpi, grayscale mode, ADF) 10 ppm (150 dpi, color mode, ADF) NOTE: Results may vary depending on your scanning application and computer processor speed.
Scan area	ADF 94 x 140 mm (3.7 x 5.5 in.) minimum 216 x 356 mm (8.5 x 14 in.) maximum Flatbed up to A4 size (8.3 x 11.7 in.)	
Electrical requirements	Voltage 100-240V Frequency 50/60 Hz	
Scanner power	Voltage / Current: 24 Vdc / 1.2 A and 1.5 A, max.	
Power source	Sino-American model SA60-24 (provided with the scanner) <i>IMPORTANT: Do not substitute another power supply model or another manufacturer's power supply.</i>	
Power consumption	i50 Scanner: < 30 watts i60 Scanner: < 36 watts	
Host connection	Interface SCSI-2 SCSI Ports 1 - 50 contact receptacle (Amphenol-style) 1 - DB25-style female, 25 socket Termination internal/external (switch selectable)	
Operating temperature	5 to 35 °C	
Storage temperature	-40 to 60 °C	
Humidity	20 to 80% RH	
Dimensions	Without output tray: 567 x 350 x 199 mm (22.3 x 13.8 x 7.8 in.) With output tray: 833 x 350 x 199 mm (32.8 x 13.8 x 7.8 in.)	
Weight	i50 Scanner: 6.7 kg (14.8 lb.) i60 Scanner: 7.55 kg (16.64 lb.)	

Specification values apply to both the i50 Scanner and i60 Scanner except where noted. All specifications are subject to change without notice.

EASTMAN KODAK COMPANY
Document Imaging
Rochester, New York 14650

www.kodak.com/go/docimaging

Kodak is a trademark of
Eastman Kodak Company.

A-61182 10/2001
©Eastman Kodak Company, 2001

DOCUMENT
IMAGING

