



2. General Information

2.1 Product Assistance

Help on installation, calibration, and the use of LeCroy equipment is available from your local LeCroy office, or from LeCroy's

- Customer Care Center, 700 Chestnut Ridge Road, Chestnut Ridge, New York 10977-6499, U.S.A., tel. (845) 578-6020
- European Service Center, 4, Rue Moïse Marcinhes, Case postale 341, 1217 Meyrin 1, Geneva Switzerland, tel. (41) 22/719 21 11.
- LeCroy Japan Corporation, Sasazuka Center Bldg – 6th floor, 1-6, 2-Chome, Sasazuka, Shibuya-ku, Tokyo Japan 151-0073, tel. (81) 3 3376 9400

2.2 Installation for Safe and Efficient Operation

Operating Environment

The oscilloscope will operate to its specifications if the environment is maintained within the following parameters:

Temperature5 to 40 °C (41 to 104 °F) rated.

HumidityMaximum relative humidity 80 % RH (non-condensing) for temperatures up to 31 °C decreasing linearly to 50 % relative humidity at 40 °C

Altitude2000 m (6560 ft)

The oscilloscope has been qualified to the following EN61010-1 category:

Installation (Overvoltage) CategoryII

Pollution Degree2

Safety Symbols

Where these symbols or indications appear on the front or rear panels, and in this manual, they have the following meanings:



..... **CAUTION:** Refer to accompanying documents (for Safety-related information). See *elsewhere in this manual wherever the symbol is present, as indicated in the Table of Contents.*



..... **CAUTION:** Risk of electric shock



..... **On (Supply)**



..... **Off (Supply)**



..... **Earth (Ground) Terminal**



..... **Protective Conductor Terminal**



..... **Earth (Ground) Terminal on BNC Connectors**

WARNING Denotes a hazard. If a **WARNING** is indicated on the instrument, do not proceed until its conditions are understood and met.



WARNING

Any use of this instrument in a manner not specified by the manufacturer may impair the instrument's safety protection.

The oscilloscope has *not* been designed to make direct measurements on the human body. Users who connect a LeCroy oscilloscope directly to a person do so at their own risk.

Power Requirements

The oscilloscope operates from a 115 V (90 to 132 V) or 220 V (180 to 250 V) AC power source at 45 Hz to 66 Hz. No voltage selection is required, since the instrument automatically adapts to the line voltage present.

The power supply of the oscilloscope is protected against short-circuit and overload by means of a 10.0 A/250 V AC, "T" rated fuses (size: 5 X 20 mm), located above the mains plug. Disconnect the power cord before inspecting or replacing a fuse. Open the fuse box by inserting a small screwdriver into the slot and turning counter clockwise.

For continued fire protection at all line voltages, replace only with fuse of the specified type and rating (T 10.0 A/250 V).

Maintain the ground line to avoid an electric shock.

None of the current-carrying conductors may exceed 250 V rms with respect to ground potential. The oscilloscope is provided with a three-wire electrical cord containing a three-terminal polarized plug for mains voltage and safety ground connection.

The plug's ground terminal is connected directly to the frame of the unit. For adequate protection against electrical hazard, this plug must be inserted into a mating outlet containing a safety ground contact.

Cleaning And Maintenance

Maintenance and repairs should be carried out exclusively by a LeCroy technician. Cleaning should be limited to the exterior of the instrument only, using a damp, soft cloth. Do not use chemicals or abrasive elements. Under no circumstances should moisture be allowed to penetrate the oscilloscope. To avoid electric shocks, disconnect the instrument from the power supply before cleaning.



CAUTION

**Risk of electrical shock:
No user serviceable parts
inside. Leave repair to
qualified personnel.**



This page intentionally left blank