

Nokia Customer Care
2112 (RH-57) Series Transceivers

System Module

Contents	Page
Introduction	3
Baseband Module	3
UEM	4
BB-RF Interface Connections	6
UPP.....	9
NOR Flash Memory and SRAM	10
User Interface Hardware	10
LCD.....	10
Keyboard.....	11
Power Key	11
Lights.....	11
Flashlight.....	11
Vibra	11
Audio Hardware	12
Earpiece	12
Microphone	12
MIDI Speaker.....	12
Audio Amplifier Interface.....	12
Battery	12
Battery Connector	13
Accessories Interface	14
System Connector.....	14
Charger IF.....	16
Test Interfaces	16
Production Test Pattern	16
General Information About Testing	19
Phone Operating Modes	19
RF Module	19
Requirements.....	19
Antenna	19
Transmitter	20
Synthesizer	22
Receiver.....	24

Introduction

The 2112 is available as a CDMA single-band engine (800 MHz CDMA). There are several different operational modes, which have different states controlled by the cellular SW. Some examples include:

- Idle State (on ACCH)
- Camping (on DCCH)
- Scanning
- Conversation
- No Service Power Save (NSPS)

In the power-off mode, only the circuits needed for power-up are supplied.

In the idle mode, circuits are powered down and only the sleep clock is running.

In the active mode, all the circuits are supplied with power, although some parts might be in idle state part of the time.

The charge mode is effective in parallel with all previous modes. The charge mode itself consists of two different states, the fast charge and the maintenance mode.

The Local Mode is used for alignment and testing.

Baseband Module

The baseband module is an 800 MHz CDMA DCT4 transceiver based on the DCT4 Apollo engine. The baseband consists of three ASICs:

- Universal Energy Management (UEM)
- Universal Phone Processor (UPP)
- 64-megabit FLASH




Figure 1: Baseband module diagram

UEM

The UEM is the Universal Energy Management IC for DCT4 digital handportable phones. In addition to energy management, it performs all the baseband mixed-signal functions.

Most UEM pins have 2kV ESD protection. Those signals that are considered to be exposed more easily to ESD have 8kV protection inside the UEM. Such signals are all audio, headset, BSI, Btemp, Fbus, and Mbus signals.

The baseband is powered from five different UEM regulators.

Table 1: Baseband Regulators

Regulator	Maximum Current (mA)	Vout (V)	Notes
VCORE	300	1.57/1.35	Power up default 1.57V and 1.35 in Sleep Mode.
VIO	150	1.8	Enabled always except during power-off mode
VFLASH1	70	2.78	Enabled always except during power-off mode

Table 1: Baseband Regulators (Continued)

Regulator	Maximum Current (mA)	Vout (V)	Notes
VFLASH2	40	2.78	Enabled only when data cable is connected
VANA	80	2.78	Enabled only when the system is awake (Off during sleep and power off-modes)
VSIM	25	3.0	Enabled only when SIM card is used

Table 2 includes the UEM regulators for the RF.

Table 2: RF Regulators

Regulator	Maximum Current (mA)	Vout (V)	Notes
VR1A	10	4.75	Enabled when cell transmitter is on
VR1B	10	4.75	Enabled when the transmitter is on
VR2	100	2.78	Enabled when the transmitter is on
VR3	20	2.78	Enabled when SleepX is high
VR4	50	2.78	Enabled when the receiver is on
VR5	50	2.78	Enabled when the receiver is on
VR6	50	2.78	Enabled when the transmitter is on
VR7	45	2.78	Enabled when the receiver is on

The charge pump that is used by VR1A is constructed around the UEM. The charge pump works with the Cbus (1.2 MHz) oscillator and gives a 4.75 V regulated output voltage to the RF.

RF Interface

In addition to the RF regulators mentioned, the UEM handles the interface between the baseband and the RF section. It provides A/D and D/A conversion of the in-phase and quadrature receive and transmit signal paths, and also A/D and D/A conversions of received and transmitted audio signals to and from the UI section. The UEM supplies the analog AFC signal to the RF section according to the UPP DSP digital control. It also converts the PA temperature into real data for the DSP. The UPP controls the RFIC through the 3-wire RFIC bus. In addition, the UPP provides a PDM regulator for RF interface (RX/TX AGC control).

Charging Control

The CHACON block of the UEM controls charging. Needed functions for charging controls are the PWM-controlled battery charging switch, charger-monitoring circuitry, battery voltage monitoring circuitry, and RTC supply circuitry for backup battery charging. In

In addition, external components are needed for EMC protection of the charger input to the baseband module. The DCT4 baseband is designed to electrically support both DCT3 and DCT4 chargers.

Digital Interface

Data transmission between the UEM and the UPP is implemented using two serial connections: DBUS (9.6 MHz) for the DSP and CBUS (1.2 MHz in CDMA) for the MCU. The UEM is a dual-voltage circuit. The digital parts run from 1.8 V and the analog parts run from 2.78 V. The Vbat (3.6 V) voltage regulator inputs are also used.

Audio Codec

The baseband supports two external microphone inputs and one external earphone output. The inputs can be taken from an internal microphone, from a headset microphone, or from an external microphone signal source through a headset connector. The output for the internal earpiece is a dual-ended output, and the differential output is capable of driving 4Vpp to the earpiece with a 60 dB minimum signal to total distortion ratio. Input and output signal source selection and gain control is performed inside the UEM ASIC according to control messages from the UPP. Both the buzzer and external vibra alert control signals are generated by the UEM with separate PWM outputs.

MIDI

The MIDI audio signal generated by the DSP and UEM audio CoDec is routed to the XEAR output of the UEM. An audio amplifier (LM4890) is used to boost enough power for the speaker.

UI Drivers

The vibra, display LED, and keyboard LEDs are driven by open collector output drivers inside the UEM. These drivers can generate PWM square wave signals to these devices.

AD Converters

There is an 11-channel analog-to-digital converter in the UEM. The AD converters are calibrated in the production line.

BB-RF Interface Connections

All the signal descriptions and properties in the following tables are valid only for active signals.

Table 3: PDM Interface

Signal Name	From	To	Parameter	Min	Type	Max	Unit	Function
RX_IF_AGC	UPP GenIO 9	Yoda	Voltage Min	0.0	1.8	0.1	V	Controls gain of VGA r in receiver
			Max	1.75		1.86		
			----- Clk Rate ⁽¹⁾	-----	----- 9.6	----- 19.2	----- MHz	

Table 3: PDM Interface (Continued)

Signal Name	From	To	Parameter	Min	Type	Max	Unit	Function
TX_IF_AGC	UPP GenIO 7	Jedi	Voltage Min	0.0	1.8	0.1	V	Controls gain of VGA in IF VGA
			Max	1.75		1.86		
			----- Clk Rate ⁽¹⁾	-----	-----	-----	----- MHz	
TX_RF_AGC	UPP GenIO 26	Jedi	Voltage Min	0.0	1.8	0.1	V	Controls gain of TX driver
			Max	1.75		1.86		
			----- Clk Rate ⁽³⁾	-----	-----	-----	----- MHz	

Table 4: General I/O Interface

Signal Name	From	To	Parameter	Input Characteristics	Function
TX_Gate	UPP Gen IO 8 pullup	Jedi and PA Gating Transistors	"0" Transmitter Off "1" Transmitter On Timing Accuracy	1.38 1.88 V 0 0.4 V 4 chips, and can be up to a total of 255 chips	Punctures the PAs and the Jedi ASIC Digital Into RF
D0	UPP Gen IO 10	PMIC	Voltage Min Max	0.4V max 1.72V-1.86V	Enable PMIC
D1	UPP Gen IO 13	PMIC	Voltage Min Max	0.4V max 1.72V-1.86V	Set PMIC output voltage
D2	UPP Gen IO 12	PMIC	Voltage Min Max	0.4V max 1.72V-1.86V	Set PMIC output voltage

Table 5: VCTCXO Interface

Signal Name	From	To	Parameter	Min	Type	Max	Unit	Function
19.2M_UPP	Yoda	UPP	Frequency	-----	19.2	-----	MHz	High stability clock signal for logic circuits, AC coupled sinewave.
			----- Signal amplitude	0.5	1.0	1.5		
AFC	UEM	VCT CXO	Voltage Min	0.0	-----	0.1	V	Automatic frequency control signal for VCTCXO Digital Into RF
			Max	2.4		2.55		
			----- Settling time ⁽⁴⁾	-----	--	0.2	----- ms	

Table 6: Regulated Supplies from UEM to RF

Signal Name	From	To	Parameter	Min	Type	Max	Unit	Function
VBAT	Battery	PA & UEM, external driver amps	Voltage ----- Current	3.2 ----- 0	3.5 ----- -	5.1 ----- 2A peak	V -----	Battery supply. Lower limit is to guarantee regulator PSRR
VR1A	UEM	PA Vref	Voltage ----- Current	4.6 ----- 0	4.75 ----- 4	4.9 ----- 5	V ----- mA	Charge pump + linear regulator.
VR2	UEM	Jedi	Voltage ----- Current	2.70 -----	2.78 -----	2.86 ----- 100	V ----- mA	Linear regulator
VR3	UEM	VCTCXO, Yoda	Voltage ----- Current	2.70 -----	2.78 -----	2.8 ----- 20	V ----- mA	Low noise linear regulator for VCTCXO
VR4	UEM	Alfred	Voltage ----- Current	2.70 -----	2.78 -----		V ----- mA	Low Iq linear regulator
VR5	UEM	Jedi	Voltage ----- Current	2.70 -----	2.78 -----		V ----- mA	Low Iq linear regulator
VR6	UEM	Yoda	Voltage ----- Current	2.70 -----	2.78 -----		V ----- mA	Low Iq linear regulator
VR7	UEM	Jedi	Voltage ----- Current	2.70 -----	2.78 -----		V ----- mA	Low noise linear regulator for synthesizer
VIO	UEM	Jedi, Yoda	Voltage	1.70	1.8	1.88 ----- 50	V ----- mA	Supply for RF-BB digital signal interface and some digital parts of RF
Vref_rf01	UEM	Yoda	Voltage	1.334	1.35	1.366	V	Voltage refer for Yoda I/or de-modulator

Table 7: Slow A/D Converters

Signal Name	From	To	Parameter	Min	Type	Max	Unit	Function
PA_TEMP	Thermistor	UEM	Input voltage range	0		2.78	V	PA temperature sensor output voltage Analog Out of RF
PWROUT	Jedi	UEM	Input voltage range	0		2.78	V	Buffered output of TX output detector

Table 8: RF-BB Analog Signals

Signal Name	From	To	Parameter	Min	Type	Max	Unit	Function
RX_IP_RF RX_IN_RF RX_QP_RF RX_QN_RF	Yoda	UEM	Differential voltage swing (static)	0.3	0.5	1.0	Vpp	Differential in-phase and quadrature RX baseband signal
			DC level	1.3	1.35	1.4	V	
			Input Bandwidth			615	kHz	Analog Out of RF
TX_IP_RF TX_IN_RF TX_QP_RF TX_QN_RF	UEM	Jedi	Differential voltage swing (static)	0.4	0.8	1.2	Vpp	Differential quadrature phase TX baseband signal for RF modulator
			DC level	1.65	1.7	1.75	V	
			-3 dB Bandwidth	650		1950	kHz	Analog into RF

Table 9: RFIC Control

Signal Name	From	To	Parameter	Min	Type	Max	Unit	Function
RF_BUS_CLK RF_BUS_DATA RF_BUS_EN1X	UPP	Jedi, Yoda	High-level input voltage, V _{IH}	1.72	1.8	1.86	V	Serial Clock = Digital Into RF
			Low-level input voltage, V _{IL}			0.4	V	Bidirectional Serial Data = Digital I/O
			High-level output voltage, V _{OH}	1.72	1.8	1.86	V	Latch enable for Jedi and Yoda = Digital Into RF
			Low-level output voltage, V _{OL}			0.4	V	
			Clock		9.6		MHz	

UPP

The 2112 uses a UPP8Mv3.5 ASIC with an 8Mbit RAM size. The UPP ASIC is designed to operate in a DCT4 engine, and is designed as part of the DCT4 common baseband task force. The DCT4 processor architecture consists of both DSP and MCU processors.

The UPP is internally partitioned into two main parts: the Brain and the Body.

The Brain consists of the processor and memory system (i.e., processor cores, mega-cells, internal memories, peripherals, and the external memory interface). The following blocks are included:

- DSP Subsystem (DSPSS)
- MCU Subsystem (MCUSS)
- Emulation control EMUCTI

- Program/data RAM PDRAM
- Brain Peripherals–subsystem (BrainPer)

The Body consists of the NMP custom cellular logic functions. These contain all interfaces and functions needed for interfacing with other DCT4 baseband and RF parts. The following sub-blocks are included:

- MFI
- SCU
- CTSI
- RxModem
- AccIF
- UIF
- Coder
- GPRSCip
- BodyIF
- SIMIF
- PUP
- CDMA (Corona)

NOR Flash Memory and SRAM

This device is a 64Mbit, mixed burst, multi-bank Flash and 8Mbit Muxed fCMOS SRAM combined in a multi-chip package memory.

The 64Mbit Flash memory is organized as 8M x 16 bit, and the 8Mbit SRAM is organized as 512K x 16 bit. The Flash memory architecture is designed to divide its memory arrays into 263 blocks, which provides highly flexible erase and program capability. This device is capable of reading data from one bank while programming or erasing in the other banks with multi-bank organization.

The Flash memory performs a program operation in units of 16 bits (Word) and erases in units of a block. Single or multiple blocks can be erased. The block erase operation is completed for typically 0.7 sec.

The 8Mbit Muxed fCMOS SRAM supports low data retention voltage for the battery backup operation with a low data retention current.

User Interface Hardware

LCD

The 2112 uses a black and white, 96 X 65 display. The LCD is controlled by UI SW and control signals.

Keyboard

The keyboard design is a 4-way scroll with navigation keys, two soft keys, and 12 number keys. The power key is located on top.

Power Key

All signals for the keyboard come from the UPP ASIC, except the power key signal, which is connected directly to the UEM. Pressing the power key creates an interrupt and connects the PWONX to the GND.

Lights

The 2112 has six white LEDs for keyboard lighting purposes. The LEDs for the display are integrated into the display module.

Display lighting and keyboard lights are controlled by the UEM Klight signal (8-bit register DriverPWMR, bits 7...4). The Klight output is a Pulse Width Modulation (PWM) signal, which is used to control the average current going through the LEDs. A step-up converter and a constant current source are used to ensure that the LEDs provide uniform intensity.

Flashlight

The flashlight feature is driven by the White LED Driver and controlled by the UEM. The circuit for the flashlight is driven by TK11851TL. In this situation, the driver is used as a boost DC/DC. Vout is set using three precision resistors in R300, R316, and 317. $V_{out} = V_{fb} * (1 + (R_{316} + R_{317}) / R_{300})$. The TK11851L is an active-high enable device, whose enable signal is tied to Klight/Dlight signals from the UEM. When Klight goes high it turns on the TK11851TL driver and the V301 transistor, which allows a path to GND.

Vibra

The vibra is located on the bottom of the D-cover and is connected by spring connectors on the PWB.

The vibra is controlled by a VIBRA PWM signal from the UEM. This signal allows control of both frequency and pulse width of the signal. Pulse width is used to control the current when the battery voltage changes. Frequency control searches for optimum frequency to ensure silent and efficient vibrating.

Table 10: Vibra Parameters

Parameter	Requirement	Unit
Rated DC voltage	1.3	V
Rated speed	9500 ± 3000	rpm
Rated current	115 ± 20	mA
Starting current	150 ± 20	mA
Armature resistant	8.6	ohm

Table 10: Vibra Parameters (Continued)

Parameter	Requirement	Unit
Rated DC voltage available	1.2 to 1.7	V
Starting DC voltage	min 1.2	V

Audio Hardware

Earpiece

The 2112 uses the 13 mm speaker capsule that is used in DCT3. The speaker is dynamic, very sensitive, and capable of producing relatively high sound pressure at low frequencies. The speaker capsule and surrounding mechanics comprise the earpiece.

Microphone

The microphone is an electric microphone with an omnidirectional polar pattern. It consists of an electrically polarized membrane and a metal electrode, both of which form a capacitor. Air pressure changes (i.e., sound) move the membrane, which causes voltage changes across the capacitor. Since the capacitance is typically 2 pF, a FET buffer is needed inside the microphone capsule for the signal generated by the capacitor. The microphone needs bias voltage as a result of the FET.

MIDI Speaker

Musical Instrument Digital Interface (MIDI) defines the data interchange format. By implementing a MIDI engine, enriched sound effects are achieved, which include ring tones, UI event sounds, and music for games and entertainment.

The MIDI data stream is a unidirectional, asynchronous bit stream at maximum 31.25 kbits/sec with 10 bits transmitted per byte (a start bit, 8 data bits, and one stop bit).

MIDI data includes two categories of signals: MIDI tones and Alerting Tones. Both are generated from the DSP and sent to the MIDI speaker.

Audio Amplifier Interface

Because the audio output from the UEM is not strong enough to produce enough power for the speaker, an audio amplifier is required. The MIDI audio signal generated by the DSP and UEM audio CoDec is routed to the XEAR output of the UEM. An audio amplifier is used to boost enough power for the speaker. GENIO (28) is used to enable/disable the audio amplifier as needed.

Battery

An 850 mAh Li-ion battery (BL-5C) is standard in the 2112. The battery block contains BSI resistors for battery identification. The BSI fixed resistor value indicates the chemistry and default capacity of a battery. This resistor is connected to the BSI pin of

the battery connector. The phone has pull-up resistors (R202) for these lines so that they can be read by A/D inputs in the phone. There also are spark caps in the BSI line to prevent ESD. The battery also has internal protection for overvoltage and overcurrent.




Figure 2: Battery interface

Battery Connector

The 2112 uses a spring-type battery connector. This ensures a more reliable connection between the battery and PWB




Figure 3: Battery pack pin order

Table 11 shows the properties for the battery pack pins.

Table 11: Battery Pin Properties

Signal Name	Connected From - To	Batt I/O	Signal Properties A/D Levels Freq/Timing	Description
1	VBAT	(+) (batt.)	VBAT	I/O
2	BSI	BSI (batt.)	UEM	Out
3	GND	GND	GND	

Accessories Interface

System Connector

The 2112 uses Tomahawk accessories via the Tomahawk connector. The Tomahawk bottom connector consists of a charging plug socket and a Tomahawk System connector (see figures that follow). The minimum configuration for the Tomahawk interface includes charging, mono audio, power out, ACI, and Fbus. The USB and stereo audio out are optional.

The Tomahawk system connector includes:

- Charging
 - Pads for 2 -wire charging in cradles
- Audio
 - 2 -wire fully differential output audio
 - 2-wire differential mic input
- Power out
 - 2.78V 70 mA output to accessories
- Detection/controlling
 - ACI
 - Point to point bi-directional data line
- Fbus
 - Standard Fbus
 - AT command mode (Nokia Serial Bus)
 - Phone message mode
 - Fast Fbus, fast data bus to add on modules




Figure 4: Tomahawk system connector




Figure 5: Mechanical dimensions and signals of Tomahawk bottom connectors

An accessory is detected by the ACI-line. All accessories will generate interrupt while inserted or removed from the phone's Tomahawk system connector. Insertion of an accessory will generate HEADINT interrupt by pulling the ACI line down. Vout is enabled by the UPP. The MBUS line is connected to the HEADINT line. If the HEADINT interrupt from low to high transition occurs within 20msec, either a more advanced accessory is connected or a basic headset is connected.

Charger IF

The charger connection is implemented through the bottom connector. The DCT-4 bottom connector supports charging with both plug chargers and desktop stand chargers.

There are three signals for charging. The charger GND pin is used for both desktop and for plug chargers as well as the charger voltage. The PWM control line, which is needed for 3-wire chargers, is connected directly to the GND in the PWB so the 2112 engine does not provide any PWM control to chargers. Charge controlling is done inside the UEM by switching the UEM internal charger switch on/off.

The fuse (F100) protects from high currents (e.g., when broken or pirate chargers are used). The L100 protects the engine from RF noises that may occur in a charging cable. V100 protects the UEM ASIC from reverse-polarity charging and from high-charging voltage. The C106 is also used for ESD and EMC protection.

Test Interfaces

Production Test Pattern

The interface for 2112 production testing is a 5-pin pad layout in the BB area (see Figure 6). A production tester connects to these pads using spring connectors. The interface includes MBUS, USRX, FBUSTX, VPP, and GND signals. The pad size is 1.7mm. The same pads also are used for AS test equipment, such as a module jig and a service cable.




Figure 6: 5-pin layout in BB area




Figure 7: Test points (bottom)




Figure 8: Test points (top)

General Information About Testing

Phone Operating Modes

The phone has three different modes for test/repair. Modes can be selected with suitable resistors connected to BSI lines as follows:

Table 12: Test/Repair Modes

Mode	BSI Resistor	Notes
Normal	75k	
Local	3.3k	
Test	6.8k	Recommended with baseband testing. Similar to Local mode, but making a phone call is possible.

The MCU software enters automatically to Local or Test mode at start-up if corresponding resistors are connected.

Note: The baseband does not wake up automatically when the battery voltage is connected (Normal Mode).

RF Module

Requirements

The 2112 supports CDMA 800 MHz as described in the following documents:

- *IS2000-2-A Physical Layer Standard for CDMA2000 Spread Spectrum Systems*
- *IS-98D (Draft 4) Recommended Minimum Performance Standard for Spread Spectrum Mobile Stations*

Antenna

An internal antenna is used.

Transmitter




Figure 9: RF transmitter block diagram

The transmit chain up to the RF driver stage is integrated into one transmit-integrated circuit (Jedi) with external power amplifiers (PA). The channel spacing is 30 kHz.

All data transmitted on the channel is convolutionally encoded and block-interleaved. Modulation is 64-ary orthogonal (RC1 and RC2) and the direct sequence is spread by a quadrature pair of PN sequences at a fixed chip rate. The data is filtered, O-QPSK modulated, and up-converted to the appropriate transmission frequency. RC3 and RC4 use HPSK modulation at data rates up to 153.6 kbps (RC3) and 115.2 kbps (RC4).

The baseband I/Q signals are converted to an IF frequency in the I/Q modulator by quadrature mixing. The modulated IF signals go through a variable gain amplifier (IF AGC) and then are routed to the Cell Tx path. The path consists of an upconverter and a variable gain RF amplifier. The IF signal is converted up to RF with a differential output upconverter and then fed to the RF amplifier. The RF amplifier has variable gain capability (RF AGC) with up to 40 dB of dynamic gain control.

The output of Jedi's Cell RF amplifier is connected to an RF filter to reject TX noise in the RX band. The output of the RF filter goes to the PA, to an isolator, and finally to the antenna.

Synthesizer

Figure 10 illustrates the synthesizers and how they interconnect in the system.




Figure 10: Synthesizer system block diagram

1st TX VHF LO Synthesizer (Jedi)

The TX VHF synthesizer is integrated within the Jedi RFIC and generates the LO signals for the IQ-modulator in Jedi. The synthesizer has an internal VCO with an external resonator. The VCO operates at two times the Cell IF frequencies. A band-switch signal (VCO_Band) is used to shift the center frequency of the external resonator.

The synthesizer is a dual-modulus prescaler and utilizes a phase detector with a charge pump that sinks or sources currents, depending on the phase difference between the detector input signals. The width of the pulses depends on the phase difference between the signals at input of the phase detector. The main divider, auxiliary divider, and reference divider are programmable through the serial interface to Jedi.

The TX VHF synthesizer generates 457.2MHz, and the comparison frequency is 30 kHz.

2nd RX VHF LO Synthesizer (Yoda)

The RX VHF synthesizer is integrated within the Yoda RFIC and generates the LO signals for the IQ demodulator in Yoda. The synthesizer has an internal VCO with an external resonator. The VCO operates at two times the common 183.6 MHz (367.2 MHz) RX IF frequency.

The synthesizer is a dual-modulus prescaler and utilizes a phase detector with a charge pump that signals or sources currents, depending upon the phase difference between the detector input signals. The width of the pulses depends on the phase difference between the signals at input of the phase detector. The main divider, auxiliary divider, and reference divider are programmable through the serial interface to Yoda.

The RX VHF synthesizer generates 367.2 MHz.

VCTCXO - System Reference Oscillator

The VCTCXO provides the frequency reference for all the synthesizers. It is a voltage-controlled, temperature-compensated, 19.2MHz crystal oscillator that can be pulled over a small range of its output frequency. This allows for an AFC function to be implemented for any frequency accuracy requirements. This is done by DSP processing of received I/Q signals.

Closed loop AFC operation allows very close frequency tracking of the base station to be done in CDMA mode. This enables the unit to track out aging effects and gives the required center frequency accuracy in Cell band.

The most practical way of clock distribution is driving the two chips (Yoda and Jedi) directly from the VCTCXO. An internal buffer is used to drive the UPP in order to isolate the UPP's digital noise from the VCTCXO, which prevents contamination of the 19.2 MHz reference onto the PLL chips of the system. Because the VCTCXO output is a sinewave, clock distribution does not cause any clock signal integrity problems, even for relatively long traces (which might occur in the case of a digital square waveform with fast transition times). The VCTCXO output is AC, coupled to Yoda, Jedi, and the digital ASICs.




Figure 11: Receiver block diagram

The receiver is a dual conversion I/Q receiver with a first IF of 183.6 MHz. The front-end RFIC (Alfred) contains a low noise amplifier (LNA), a radio frequency amplifier (RFA), a down-converter, an intermediate frequency amplifier (IFA), and a local oscillator amplifier (LOA). Between the LNA and the RFA is a bandpass filter, which rejects out-of-band spurious and acts as image rejection. The IF filter is between the Alfred IC and the Yoda IC. The purpose of this filter is to guarantee rejection in adjacent and alternate channels.

The RX IF ASIC Yoda is used to convert the IF down to baseband I and Q. The ASIC contains a VGA section, an IQ demodulator, and baseband filters (BBFIL) for CDMA. Fix gain baseband amplifier (BBAMP), and RX VHF PLL. The I/Q BB signals are output to the UEM chip for analog-to-digital conversion and further signal processing.

This page intentionally left blank.