

**Nokia Customer Care  
3155/3155i (RM-41), 3152 (RM-61)  
Mobile Terminal**

**RF Description and  
Troubleshooting**

<b>Contents</b>	<b>Page</b>
Mobile Terminal Components .....	5
Main PWB .....	5
Preliminary RF Troubleshooting.....	8
Mobile Terminal Cannot Make a Call .....	8
Tx Power Low .....	8
Transmitter RF Troubleshooting .....	9
Transmitter Block Diagram .....	10
Transmitter Schematics .....	11
Transmitter Troubleshooting Setup .....	13
AMPS Tx Setup .....	13
Cell Tx Setup .....	16
PCS Setup.....	18
Transmitter RF Troubleshooting Procedures .....	20
Failed Test: Tx PA Detector .....	21
Tx Output Spectrum.....	22
Tx DC Test Points - Bottom Side .....	23
Tx RF Test Points - Bottom Side.....	24
RF Power Supply DC Test Points - Bottom Side.....	25
Receiver RF Troubleshooting .....	27
Receiver Block Diagram .....	28
Receiver Schematics .....	29
RF AGC Status .....	31
Turning on the Rx Path .....	32
Switching the Rx Gain States .....	34
Checking AMPS from RF to IQ.....	34
Checking Cell Receiver from RF to IQ.....	35
Checking PCS Receiver from RF to IQ.....	37
Receiver Diagnostic Signal Tracing .....	38
Receiver DC Test Points.....	39
Receiver RF Test Points .....	40
Receiver IF Test Points.....	41
Receiver Logic Input Voltages .....	42
N7160 Receiver Overview .....	43
Synthesizer Troubleshooting .....	45
Synthesizer Block Diagram .....	46
Synthesizer Schematics .....	47
Synthesizer Troubleshooting Setup .....	48
Incorrect PLL Frequencies.....	48
VCTCXO Manual Tuning .....	50
AFC Voltage Troubleshooting .....	51
UHF Synthesizer .....	52
UHF Synthesizer Test Points .....	53
Rx VHF LO (N7100) Schematic .....	54
Rx VHF LO Troubleshooting .....	55
Tx UHF LO (N7000) Schematic .....	56
Tx UHF LO (N7000) Troubleshooting .....	57
GPS Troubleshooting.....	58

---

GPS RF Block Diagram .....	58
GPS RF Schematic .....	59
GPS Troubleshooting Setup .....	60
Self Test Failure .....	61
Oscillator Failure .....	61
CW Test Failure.....	61
GPS RF Troubleshooting.....	61
GPS DC Test Points.....	62
GPS RF Test Points.....	64
FM Radio Troubleshooting .....	65
FM Radio Schematic .....	65
FM Radio Troubleshooting Setup .....	66

This page intentionally left blank.

## Mobile Terminal Components

The mobile terminal includes two PWB boards, the main PWB and the UI PWB.

### Main PWB

Following are the components of the main PWB.




Figure 1: Main PWB component layout - top




Figure 2: Main PWB component layout – bottom




Figure 3: UI PWB component layout - bottom

## Preliminary RF Troubleshooting

The following sections identify steps to troubleshoot some common RF issues.

### Mobile Terminal Cannot Make a Call

Verify the following if the mobile terminal cannot make a call:

1. The mobile terminal is in Normal Mode (i.e., the mobile terminal is searching for a signal, net server is on).
2. The Preferred Roaming List (PRL) is loaded into the mobile terminal.
3. The mobile terminal is tuned and has passed tuning. Read the tuning parameters using the **Read Parameters** component in Phoenix. An untuned mobile terminal has all zeros in the tuning file.
4. The call box channel is set for a channel in PRL.
5. The SID is correct and entered into the mobile terminal.
6. The VCTCXO is centered as described in the "[VCTCXO Manual Tuning](#)" section on page 50.
7. The transmitter and receiver are working properly in Local Mode. See "[Transmitter RF Troubleshooting](#)" on page 9 and "[Receiver RF Troubleshooting](#)" on page 27 for detailed information.

### Tx Power Low

Complete the following steps if Tx power is low:

1. Use Phoenix to turn on the transmitter in Local Mode.
2. Perform a visual inspection of the PWB under a microscope to check for the proper placement, rotation, and soldering of components.
3. Look for the presence of a Tx signal on a spectrum analyzer at the correct frequency.
  - If a signal is present but off-frequency, check the synthesizers for proper frequency and amplitude. One of the synthesizers may be unlocked or the VCO has no output signal.
  - If a signal is not present or is present but is low in amplitude, check the probing diagrams to determine where in the chain the fault occurs. (See "[Tx RF Test Points - Bottom Side](#)" on page 24.)
4. Ensure that the power supplies to the Tx have the correct voltage. (See "[Tx DC Test Points - Bottom Side](#)" on page 23)
5. Ensure that the AGC PDMs are set for the desired Tx power and that the AGC voltages are correct. (See "[AMPS Tx Setup](#)" on page 13, "[Cell Tx Setup](#)" on page 16, or "[PCS Setup](#)" on page 18.)





### Transmitter Block Diagram

Following is the block diagram for the Tx RF system.




Figure 5: Tx system block diagram

**Transmitter Schematics**

The following schematics are for general reference only. See the *Schematics* chapter for detailed versions.




Figure 6: Transmitter schematic 1




Figure 7: Transmitter schematic 2

## Transmitter Troubleshooting Setup

Use the following sets of procedures to troubleshoot the transmitter using Phoenix. Due to the compact layout of the mobile terminal, some of the major test points are not accessible without destroying the shield frames and the EL lamp. For example, duplexers/diplexer/couplers test points are blocked by the test jig, the PA test points are underneath the shield frame, and the BBIQ points are underneath the EL lamp.

To minimize effort, check the following in order:

1. Tx power at the RF connector.
2. All Tx DC points.
3. All soldering jig points for the whole Tx chain.
4. UHF LO presence:
  - If the UHF LO is present, check the N7000 output.
  - If the UHF LO is not present, it is a synthesizer problem.
5. If there is no N7000 output:
  - a. Change the N7000.
  - b. If the problem persists, reflow the duplexers, diplexer, and couplers.
  - c. If the problem persists, change the PA.
6. If there are several failed mobile terminals with the same symptoms, it may be necessary to break one to determine the cause.

Use the following sections to set up troubleshooting in Phoenix according to the band you are using:

- ["AMPS Tx Setup"](#) on page 13
- ["Cell Tx Setup"](#) on page 16
- ["PCS Setup"](#) on page 18

### AMPS Tx Setup

Use the following procedures to prepare for AMPS Tx troubleshooting using Phoenix.

1. Connect the RF test connector to a spectrum analyzer.
2. Connect the mobile terminal to the PC via a test jig. (The bottom connector is a USB port.)
3. Connect a power supply to the mobile terminal.
4. Open the **Troubleshooting** menu, and click **Phone Control**.  
The **Phone Control** dialog box appears.

- Click the **LOCAL** button in the **Phone State** area to put the mobile terminal into Local Mode.




Figure 8: Phone Control dialog box

- Open the **Troubleshooting** menu, point to **AMPS**, and click **AMPS Control**.  
The **AMPS Control** dialog box appears.




Figure 9: AMPS Control dialog box

- Click the **Tx Control** tab.
- In the **Set Channel** field, type 384.
- In the **Power Level** field, type 2.
- Select the **Transmitter ON** option, and click **Execute**.

11. Configure the spectrum analyzer using the following values:

- Center Frequency = 836.52 MHz
- Span = 100 MHz
- Amplitude = 30 dBm
- Attenuation = Auto
- BW = Auto

Table 1: RF PDM Values at Power Level 2

Description/Field	Reference Value
AGC1	50
AGC2	-31
AGC3	-400
Rx IF AGC	0
AFC	0
Pout at RF connector	+14dBm
Current	400-500mA




Figure 10: RF PDM dialog box for AMPS

12. Click **Read Phone** to update the values.

## Cell Tx Setup

Use the following procedures to prepare for Cell Tx troubleshooting using Phoenix.

1. Connect an RF test connector to a call box.
2. Connect the mobile terminal to the PC via a test jig.
3. Connect a power supply to the mobile terminal.
4. On the **Phone Control** dialog box, click the **LOCAL** button in the **Phone State** area to put the mobile terminal into Local Mode. (See [Figure 8](#) on page 14.)
5. Open the **Troubleshooting** menu, point to **RF**, and click **RF Main Mode**.

The **RF Main Mode** dialog box appears.




Figure 11: RF Main Mode dialog box for Cell Mode

6. Select the following values on the **RF Main Mode** dialog box:
  - **Band** = Cell (CDMA)
  - **Channel** = 384
  - **Mode** = Rx/Tx
7. Click **Set**.

*Note: Be sure that the “RF Main Mode set successfully” message appears in the status bar.*

8. Open the **Troubleshooting** menu, point to **RF**, and click **CDMA Control**.



The CDMA Control dialog box appears.




Figure 12: CDMA Control dialog box for Cell Tx troubleshooting

9. Select the following values:

- **State** = Rho ON
- **Band** = Cell
- **Radio Configuration** = Mode 1: IS-95 Voice

*Note: Do NOT select the Set default PDM values option*

10. Click **Execute**.

11. Configure the spectrum analyzer using the following values:

- Center Frequency = 836.52 MHz
- Span = 5MHz
- Amplitude = 0 dBm
- Attenuation = Auto
- BW = Auto
- VID AVG = 10

Table 2: RF PDM Values

Description/Field	Reference Value
AGC1	50
PA_Bias	128
PA_DC_DC	100
Pout at RF connector	-28dBm peak
Current	240mA typ




Figure 13: RF PDM Control dialog box for Cell band

12. Click **Read Phone** to update the values.

### PCS Setup

Use the following procedures to prepare for PCS Tx troubleshooting using Phoenix.

1. Connect an RF test connector to a call box.
2. Connect the mobile terminal to the PC via a test jig. (The bottom connector is a USB port.)
3. Connect a power supply to the mobile terminal.
4. Open the **Troubleshooting** menu, and point to **Phone Control**.  
The **Phone Control** dialog box appears. (See [Figure 8](#) on page 14.)
5. Click the **LOCAL** button in the **Phone State** area to put the mobile terminal into Local Mode.
6. Open the **Troubleshooting** menu, point to **RF**, and click **RF Main Mode**.

The **RF Main Mode** dialog box appears. (See [Figure 11](#) on page 16.)

7. Select the following values on the **RF Main Mode** dialog box:

- **Band** = PCS (CDMA)
- **Channel** = 600
- **Mode** = Rx/Tx

8. Click **Set**.

*Note: Be sure that the “RF Main Mode set successfully” message appears in the status bar.*

9. Open the **Troubleshooting** menu, point to **RF**, and click **CDMA Control**.

The **CDMA Control** dialog box appears. (See [Figure 12](#) on page 17.)

10. Select the following values on the **CDMA Control** dialog box.

- **State** = Rho ON
- **Band** = PCS
- **Radio Configuration** = Mode 1: IS-95 Voice

*Note: Do NOT select the Set default PDM values option.*

11. Click **Execute**.

12. Open the **Troubleshooting** menu, point to **RF**, and click **PDM Control**.

13. Configure the spectrum analyzer using the following values:

- Center Frequency = 1880 MHz
- Span = 100 MHz
- Amplitude = 0 dBm
- Attenuation = Auto
- BW = Auto
- VID AVG = 10

**Table 3: RF PDM Values**

Description/Field	Reference Value
AGC1	50
PA_Bias	128
PA_DC_DC	100
Pout at RF connector	-35dBm peak
Current	250mA typ




Figure 14: RF PDM Control dialog box for PCS band

14. Click **Read Phone** to update the values.

## Transmitter RF Troubleshooting Procedures

After Phoenix is set up using either the AMPS, Cell, or PCS setup procedures, use the following steps to troubleshoot the transmitter.

1. Using a voltmeter, check to see that all VIO, VR2, VR6, and VR1B are on the transmit system. (See "[Tx DC Test Points - Bottom Side](#)" on page 23.)
  - If any are missing, look for SMD problems around the N7000 and the UEME.
  - If SMD is good, replace the UEME.
2. Once all DC voltages are present, check the AGC control voltages. (See "[AMPS Tx Setup](#)" on page 13, "[Cell Tx Setup](#)" on page 16, or "[PCS Setup](#)" on page 18.)
  - If the voltages are incorrect, check the SMD around TX\_AGC1.
  - If the SMDs are correct, replace the D2800.
3. Using an oscilloscope, check the input modulation BBIQ wave forms at R7021, R7022, R7023, and R7024. They should all be present with an AC swing of about 500mVpp, with an offset of +1.2V.
  - If one or more waveforms are missing, look for SMD problems around these resistors.
  - If the SMD is good, replace the UEM.

4. Use an AAS-10 RF probe to probe the Cell Tx output of the N7000.
  - If there is no RF or low RF, look for SMD everywhere around the N7000.
  - If the SMD is okay, replace the N7000.
5. Probe the PA input.
  - If the level is low, look for an SMD issue on the Tx filter or discrete balun.
  - Reflow or replace the filter as necessary.
6. Probe the PA output.
  - If the RF is missing or low, look for Vbatt voltages, Vcc PA voltages and SMD issues on and around the PA.
  - If these are okay, replace the PA.
7. Probe the duplexer output.
  - If the RF is missing or low, reflow or replace the duplexer.
8. Probe the coupler output.
  - If the RF is missing or low, reflow or replace the coupler.
9. Probe the diplexer output.
  - If the RF is missing or low, reflow or replace the diplexer.

#### Failed Test: Tx PA Detector

Use the following steps if you encounter a failed test for the Tx PA detector:

1. Use Phoenix to set the mobile terminal into Local Mode and activate the Tx with default output power.
2. The output power at the RF test connector should read -32dBm peak +/- 4dB. If not, follow the procedures above.
3. Using a voltmeter on DC, probe the detector output at C7303. The voltmeter should read approximately 1.4V. If not, replace N7302.

### Tx Output Spectrum

Following is the correct output of the mobile terminal on a spectrum analyzer with 100MHz span. Note that if you are using the AAS-10 probe with the mobile terminal connected to the call box, the amplitude should be approximately -7dBm at the antenna test point on the top of the PWB.




Figure 15: Correct output spectrum

Following is an example of *incorrect* output.




Figure 16: Incorrect output spectrum



Table 4: Tx DC Test Point Description and Values - Main PWB - Bottom Side (Continued)

Test Point	Description	Values
7	AGC1	0.1V to 1.8V
8	VR6	2.8V
9	VR2	2.8V
10	VR1B	4.8V

**Tx RF Test Points - Bottom Side**

Figure 18 shows the Tx RF test points located on the bottom side of the main PWB.




Figure 18: Tx RF test points on the bottom side of the main PWB

Table 5 shows the values for the test points in Figure 18. These values are based on a PCS frequency of 1880MHz and an AMPS/Cell frequency of 836.25MHz.

Table 5: Tx RF Test Point Descriptions and Values - Main PWB - Bottom Side

Test Point	Description	Values
1	Cell PA out	-14dBm
2	PCS PA out	-23dBm



Table 5: Tx RF Test Point Descriptions and Values - Main PWB - Bottom Side (Continued)

Test Point	Description	Values
3	RF out	AMPS: +24dBm Cell: -13dBm PCS: -23dBm
4	Tx UHF LO	Cell: 3346.08MHz -52dBm PCS: 3760MHz -57dBm
5	PCS N7000 out	-46dBm
6	Cell N7000 out	Cell: -40dBm AMPS: 0dBm

**RF Power Supply DC Test Points - Bottom Side**

Following are the RF power supply DC test points located on the bottom side of the main PWB.




Figure 19: RF power supply DC test points on the bottom side of the main PWB

Table 6 shows the values for the test points in Figure 19.

Table 6: RF Power Supply DC Test Points (Main PWB - Bottom Side)

Probe Point	Description	Value
1	VIO	1.8V

Table 6: RF Power Supply DC Test Points (Main PWB – Bottom Side) (Continued)

Probe Point	Description	Value
2	VR3	2.8V (Synthesizer)
3	VR7	2.8V (Rx)
4	VR4	2.8V (Rx)
5	VR1B	4.7V (Tx)
6	VR5	2.8V (Rx)
7	VR6	2.8V (Tx)
8	VR2	2.8V (Tx)
9	VR1A	4.7V (Synthesizer)

## Receiver RF Troubleshooting

The heart of the receiver is the N7160 Rx IC, which contains two LNAs and mixers. The other components are passive. There are two RF SAW filters for the Cell and PCS bands. In addition, there are two additional IF filters, an IF SAW for CDMA and an IF Crystal for AMPS. The back-end of the receiver consists of the N7100 IC, which handles the VGA and IQ demodulator functions.

## Receiver Block Diagram

Following is the Rx system block diagram.




Figure 20: Receiver system block diagram

**Receiver Schematics**

The following schematics are for general reference only. See the *Schematics* chapter for detailed versions.





Figure 21: Receiver schematics - 1



N7100 Rx downconverter

Figure 22: Receiver schematic - 2

### RF AGC Status

When configuring the values on the **RF AGC Status** dialog box, note the following:

- The RF AGC status functionality only works in Call Mode.
- In the **PLL Lock Status** area, bright green indicates a locked PLL and dark green indicates an unlocked PLL.
- In the **Baseband Type** field, ensure that the correct baseband is selected (Tiku BB 4.5).
- Clicking the **Stop Updating** button allows you to toggle between the **Update Every 2 Seconds** and **Stop Updating** functions.




Figure 23: RF AGC Status dialog box

## Turning on the Rx Path

Use the following steps to turn on the Rx path using Phoenix.

1. On the **Phone Control** dialog box, click the **LOCAL** button in the **Phone State** area to put the mobile terminal into Local Mode.




Figure 24: Phone Control dialog box

2. Click the **Execute** button.
3. Depending on the band, use the applicable settings from the table below on the **RF Main Mode** dialog box.

Table 7: RF Main Mode Dialog Box Settings

Band	Mode	Channel
AMPS	Rx = 881.52 MHz	384
Cell	Rx = 881.52 MHz	384
PCS	Rx = 1960 MHz	600






Figure 25: RF Main Mode dialog box for AMPS (top), Cell (middle), and PCS (bottom)

## Switching the Rx Gain States

Use the RF Gen I/O dialog box to switch the gain state (Hi and Lo) for CDMA and AMPS modes.




Figure 26: RF Gen I/O dialog box

## Checking AMPS from RF to IQ

Use the following steps to check the AMPS receiver functionality from RF to IQ output.

1. Start Phoenix in Local Mode with only the Rx path turned on.
2. Inject a -75dBm CW signal of 881.53MHz (i.e. 10kHz offset from 881.52MHz) into the RF.
3. Measure a 10kHz tone on the analyzer. You should see a typical -25 to -35Bm IQ tone for AMPS.




Figure 27: Receiver IQ Level on AMPS band

Figure 28 shows the AMPS spectrum and the test points located on the top side of the main PWB. All four test points should be approximately equal. *WARNING: Direct current is present on these test points.*




Figure 28: AMPS spectrum and the test points on the top side of the main PWB

**Checking Cell Receiver from RF to IQ**

Use the following values to check the Cell receiver functionality RF to IQ output.

1. Start Phoenix in Local Mode with only the Rx path turned on.
2. Inject a -75dBm CW signal of 881.82MHz (i.e. 300kHz offset from 881.52MHz or 10 channels away).

3. Measure a 300kHz tone on the analyzer. You should see a typical -5dBm IQ tone for CDMA Cell.




Figure 29: Receiver IQ level on Cell band

Figure 30 shows the Cell spectrum and the test points located on the top side of the main PWB. All four test points should be approximately equal.

*WARNING: Direct current is present on these test points.*




Figure 30: Cell spectrum and test points on the top side of the main PWB

### Checking PCS Receiver from RF to IQ

Use the following values to check the PCS receiver functionality from RF to IQ output.

1. Start Phoenix in Local Mode with only the Rx path turned on.
2. Inject a -75dBm CW signal of 1960.5MHz (i.e. 500kHz offset from 1960MHz or 10 channels away).
3. Measure a 500kHz tone on the analyzer. (If a 300kHz tone works but a 500kHz tone does not, the problem is in the BB filter, possibly not set by Phoenix.) You should see a typical 5dBm IQ tone for CDMA PCS.




Figure 31: Receiver IQ Level on PCS Band

Figure 31 shows the PCS spectrum and the test points located on the top side of the main PWB. All four test points should be approximately equal. *WARNING: Direct current is present on these test points.*




Figure 32: PCS spectrum and the test points on the top side of the main PWB

## Receiver Diagnostic Signal Tracing

Use the following steps to trace the receiver signal.

1. Inject an external signal source of  $-25\text{dBm}$  to the RF input. An Agilent call box 8960 is recommended.
2. Press the Call Setup button, press the Active Cell soft button, and select CW.
3. Inject a CW signal for PCS (1960MHz) or Cell/AMPS (881.52MHz) at a fixed  $-25\text{dBm}$  power level.
4. Use an AAS-10 probe to take measurements. Signal levels are approximate, and accuracy may be  $\pm 2\text{dB}$  or more depending on the position and grounding of the probe.

Receiver DC Test Points




Figure 33: Receiver DC troubleshooting test points on the bottom side of the main PWB

Table 8 includes the descriptions and values for the Rx DC test points from Figure 33.

Table 8: Receiver DC Test Point Values

Test Point	Description	Value
1	LO Vdd	2.6 VDC LO Amp supply lines for Cell and PCS
2	RFA Vdd	2.8 VDC RF Amp Vdd supply line for Cell band
3	C_LNA Vdd	2.8 VDC external Vdd supply line for Cell LNA
4	P_LNA Vdd	2.8 VDC external Vdd supply line for PCS LNA
5	IFA Vdd	2.8 VDC IF Amp Vdd supply line for CDMA and AMPS IFs
6	IFA Vdd	2.8 VDC IF Amp Vdd supply line for CDMA and AMPS IFs
7	Rx LO lock voltage	1.2 to 1.7 Vdc

**Receiver RF Test Points**




Figure 34: Rx RF test points on the bottom side of the main PWB

Table 9 includes the descriptions and values for the Rx RF test points from Figure 34.

Table 9: Receiver RF Test Point Values

Test Point	Description	Value
1	PCS_CEL_LO (from VCO)	Cell: 1009.62MHz at -15dBm PCS: 2088.1MHz at -17dBm
2	Cell channel 384 (from duplexer)	881.52MHz at -33dBm
3	Cell channel 384 (to RF SAW)	High gain: 881.52MHz at -21dBm Low gain: 881.52MHz at -36dBm
4	PCS channel 600 (from duplexer)	1960MHz at -46dBm
5	PCS channel 600 (to RF SAW)	High gain: 1960MHz at -32dBm Low gain: 1960MHz at -49dBm
6	IF MIX OUT (from N7160)	High gain: 128.1MHz at -21dBm Low gain: 128.1MHz at -34dBm
7	IFA_IN (to N7160)	High gain: 128.1MHz at -18dBm Low gain: 128.1MHz at -34dBm



Receiver IF Test Points




Figure 35: Receiver IF test points on the bottom side of the main PWB

Table 10 includes the descriptions and values for Rx IF test points from Figure 35.

Table 10: Receiver IF Test Point Values

Test Point	Description	Value
1	Rx VHF LO	256.2MHz at -70dBm
2	CDMA IF (to SAW) 128.1MHz	High gain: Cell channel 384 at -9dBm Low gain: Cell channel 384 at -25dBm High gain: PCS channel 600 at -8dBm Low gain: PCS channel 600 at -24dBm
3	CDMA_IF_P (to the N7100) 128.1MHz	Cell high gain: -29dBm Cell low gain: -45dBm PCS high gain: -29dBm PCS low gain: -45dBm
4	CDMA_IF_N	Cell high gain: -29dBm Cell low gain: -45dBm PCS high gain: -29dBm PCS low gain: -45dBm
5	AMPS IF (to MCF) 128.1MHz	High gain: Cell channel 384 at -19dBm Low gain: Cell channel 384 at -35dBm
6	AMPS_IF_N (to the N7100) 128.1MHz	Cell high gain: -28dBm Cell low gain: -44dBm
7	AMPS_IF_P	Cell high gain: -28dBm Cell low gain: -44dBm

## Receiver Logic Input Voltages

Figure 36 shows the receiver logic input voltages.




Figure 36: Receiver logic input voltage test points

Table 11 includes the measure logic levels for the N7160.

Table 11: Rx Front-end (N7160) Logic Levels

Mode	Logic Input Voltages		
	IF_SEL	BAND	GAIN_CTL
AMPS High Gain	2.8 V	0.1 V	2.8 V
AMPS Low Gain	2.8 V	0.1 V	0 V
Cell CDMA High Gain	0 V	0.1 V	2.8 V
Cell CDMA Low Gain	0 V	0.1 V	0 V
PCS CDMA High Gain	0 V	2.7 V	2.8 V
PCS CDMA Low Gain	0 V	2.7 V	0 V

If the logic levels are significantly off ( $\pm 0.2V$ ), replace the N7160 and re-measure. If the voltages are still out of specifications, refer to the *Baseband Troubleshooting* chapter.

## **N7160 Receiver Overview**

Keep the following points in mind regarding the N7160 receiver:

- There is a separate LNA for 800MHz (Cell and AMPS) and 1900MHz (PCS).
- There is a separate RFA (inside N7160) for 800MHz (Cell and AMPS) and 1900MHz (PCS).
- After the RFA, there is a mixer, and then the signals are separated by CDMA (Cell and PCS) and AMPS.

For example, if there is no IF frequency (128.1MHz) check both Cell and PCS. If only one has 128.1MHz at L753, ensure that IF\_SEL is working. If it is, then replace the N750 due to a bad RFA.

If Cell and AMPS are working but PCS is not, look at the band select line and the PCS LNA before replacing the N7160.




Figure 37: N7160 Receiver

There are two common explanations for an N7160 failure consisting of high current in Local Mode with just the Rx turned on:

- No presence of an LO signal
- Input impedance drop is shorting out one of the DC supply pins to the chip

**IMPORTANT: You must check for both conditions before replacing the chip.** If you have no LO signal, refer to "[UHF Synthesizer](#)" on page 52. If you have a significant supply voltage drop on one of the supply pins, then replace the N7160.

Table 12: N7160 Conditions and Supply Currents

Condition: Local Mode, Set Rx Only in RF Main Mode	Supply Current (From Power Supply)
Good mobile terminal	100mA
No UHF LO signal present	254mA
Pin 13 shorted	255mA

## Synthesizer Troubleshooting

Faulty synthesizers can cause Rx and Tx failures during tuning, in addition to the VCTCXO tuning. However, first check for the presence of various LO signals and their proper levels. If everything fails, it may be necessary to check the reference clock (19.2MHz) which is needed for the mobile terminal to power up. The 19.2MHz signal is important because the D2800 processor is sensitive enough to pick up a very weak 19.2MHz clock, resulting in intermittent problems such as a constant mobile terminal reset.

Following are the synthesizers used in the mobile terminal:

- Dual-band UHF (1009.62MHz for channel 384 in Cell and AMPS bands, and 2088.1MHz for channel 600 in PCS band) with a separate LMX2310 PLL IC
- Rx VHF (256.2MHz for Cell, AMPS, and PCS) with PLL inside the N7100 IC
- Tx UHF (3296.16MHz~3395.88 for Cell and AMPS, 3700~3819.9MHz for PCS) with PLL inside the N7000 IC

### Synthesizer Block Diagram




Figure 38: Synthesizer block diagram

**Synthesizer Schematics**

The following schematics are for general reference only. See the *Schematics* chapter for detailed versions.




Figure 39: Synthesizer schematic

## Synthesizer Troubleshooting Setup

Use the following steps to troubleshoot the synthesizer using Phoenix:

1. On the **Phone Control** dialog box, click the **LOCAL** button in the **Phone State** area to put the mobile terminal into Local Mode.




Figure 40: Phone Control dialog box

2. Select the following values on the **RF Main Mode** dialog box:

Table 13: RF Main Mode Dialog Box Settings

Synthesizer	Band	Mode	Channel
UHF	Cell	Rx/Tx	384
	PCS	Rx/Tx	600
Rx VHF	(one band is enough)	Rx	
Tx VHF	Cell	Rx/Tx	384
	PCS	Rx/Tx	600

### Incorrect PLL Frequencies

Following are some possible causes for incorrect PLL frequencies:

- Power supplies to PLL portion
- Control line to VCO
- Loop filter or resonator components missing or incorrectly installed
- 19.2MHz reference clock missing or low
- Component failure (PLL IC, N7100, N7000, VCO, or VCTCX0)



for the presence of the 19.2MHz signal.




Figure 41: VCTCXO test point output values

Table 14 includes the descriptions and values for VCTCXO test points from Figure 41.

Table 14: VCTCXO Test Point Output Values

Test Point	Description	Value
1	VR3	2.8V
2	AFC voltage	1 to 3 Volts (adjustable with the AFC slider on the RF PDM Control in Phoenix) 1.2V for PDM 0 0V for PDM -1024 2.4V for PDM 1024
3	OSC IN to UHF PLL	~ -9dBm
4	F_REF_RX, clock reference to the N7100	~ -9dBm
5	CLK19M2_TIKU, clock reference to Tiku	~ -9dBm, and ~2 dB less on the other side of R7204 (located adjacent to the D2800)
6	CLK19M2_GPS, clock reference to the GPS subsystem	~ -9dBm

### VCTCXO Manual Tuning

The VCTCXO can be manually tuned to verify when a mobile terminal is tuned incorrectly or if mobile terminal cannot make a call. Monitor the RF signal at the mobile terminal's output.

1. On the **Phone Control** dialog box, click the **LOCAL** button in the **Phone State** area to put the mobile terminal into Local Mode. (See [Figure 8](#) on page 14 for an example of the **Phone Control** dialog box.)
2. Click the **Execute** button.
3. On the **AMPS Control** dialog box, set the **Set Channel** field to 384, the **Power Level** field to 5, and select the **Transmitter ON** check box. (See [Figure 9](#) on page 14 for an example of the **AMPS Control** dialog box.)
4. Click the **Rx RFI** tab, make sure the **AFC Control** check box is cleared, and click **Execute**.
5. The frequency accuracy of the VCTCXO can be measured using an HP8960 callbox in AMPS mode or a spectrum analyzer at the output of the transmit chain.
  - If using a spectrum analyzer, set the center frequency to 836.52MHz and the span to 2MHz initially. Establish a marker at 836.52Mhz.
  - If using an HP8960, set the callbox System Type to AMPS, and set the ACC channel to 384. Use the Frequency Stability measurement to center the VCTCXO (minimum Frequency Error).
6. Use the RF PDM component to adjust the AFC to center the VCTCXO. The tuning range is approximately +/-10kHz.
7. Adjust the AFC so that the output signal is within +/-150MHz. If using a spectrum analyzer, narrow the span to 1kHz or less.
8. Replace the UEM if the VCTCXO does not tune correctly.

### AFC Voltage Troubleshooting

Use the following steps to monitor the AFC voltage.

1. In Phoenix, open the **RF PDM** dialog box.




Figure 42: RF PDM dialog box for AFC troubleshooting

Figure 43 shows a partial schematic of the R7205.




Figure 43: Partial schematic showing the R7205

2. Measure the DC voltage at R7205. The following typical voltages are shown in Figure 44.
  - 1 = AFC PDM[-1024]=0V
  - 2 = AFC PDM[0]=1.2V
  - 3 = AFC PDM[1024]=2.4V




Figure 44: Tx Output for AMPS channel 384, power level 5

## UHF Synthesizer

The UHF LO frequency varies with the channel and can be calculated using the Frequency Calculator dialog box in the Phoenix RF component. Use the following steps to troubleshoot the UHF LO frequency.

1. Ensure that the LO is locked. Set a channel and check the output of the UHF LO at L7200 within a very narrow span of 100KHz. The LO must be virtually immobile.
2. Measure the nominal UHF LO signal levels (see "[UHF Synthesizer Test Points](#)" on page 53).
3. If you do not see the presence of any LOs, check the DC voltages at the following:
  - R7209, VR4, supply line for VCO IC and PLL IC = 2.76VDC
4. If the frequency of the LO is not correct, check the DC voltages at the following:
  - R7208, VR1A, supply line for PLL charge pump = 4.76VDC
5. Ensure that the lock voltage at C7220 is between 1V and 3V.
6. Check the RF return at R7210.
  - **TX UHF LO (Cell/AMPS)** = Tx frequency x 4
  - **TX UHF LO (PCS)** = Tx frequency x 2



### Rx VHF LO (N7100) Schematic

Following are the main layout components on a partial view of the Rx VHF schematic. See the *Schematics* chapter for detailed versions.




Figure 46: Rx VHF schematic, partial view

### Rx VHF LO Troubleshooting

The VHF LO operates at a fixed frequency of 256.2MHz. It is the second LO for down-conversion to I and Q for baseband processing. Use the following steps to troubleshoot the VHF LO.

1. Monitor the test point at C710. Ensure that a locked and stable 256.2MHz with amplitude ~ -60dBm is present on the spectrum analyzer (or, with a high impedance probe, ~ -2dBm at C7104).
2. Monitor the control voltage at C7100. The control voltage at a locked state must be between 1.2 and 1.7 Vdc for the proper operation of the VHF LO.




Figure 47: Rx VHF LO test points

Table 16 shows the description for each component in Figure 47.

Table 16: Rx VHF Layout Components

Test Point	Description	Value
1	VIO	1.8V
2	Rx LO 256.2MHz	-60 to -65dBm
3	Rx LO lock voltage	1.2 to 1.7Vdc
4	VR7	2.8V
5	VR5	2.8V

### Tx UHF LO (N7000) Schematic

The following partial schematic is for general reference only. See the *Schematics* chapter for complete detailed versions.




Figure 48: Tx UHF LO (N7000) schematic





## GPS Troubleshooting

### GPS RF Block Diagram




Figure 50: GPS block diagram

**GPS RF Schematic**

The following schematic is for general reference only. See the *Schematics* chapter for a detailed version.




Figure 51: GPS RF schematic

## GPS Troubleshooting Setup

Use the following steps to set up GPS signal using Phoenix.

1. On the **Phone Control** dialog box, click the **LOCAL** button in the **Phone State** area to put the mobile terminal into Local Mode. (See [Figure 8](#) on page 14 for an example of the **Phone Control** dialog box.)
2. Click the **Execute** button.
3. Inject a -110dBm tone at 1575.52MHz at the GPS connector (X6250) with a signal generator or call box.




Figure 52: X3155 on the bottom side of the UI PWB

4. Open the **Troubleshooting** menu, and click **GPS Testing**.

The **GPS Control** dialog box appears.




Figure 53: GPS Control dialog box

5. In the **Test Mode** field, ensure that **BB/Hdw** is selected.
6. Click **Execute**.

### Self Test Failure

If the test fails, repeat steps 1–6. If the test fails again, continue with the following self-test failure troubleshooting:

1. Verify the DC voltages at VRF\_GPS and VIO\_GPS. ("[GPS DC Test Points](#)" on page 62 for test point locations and values.)
2. Inspect all GPS circuit elements around the GPS BB chip (N6200).
3. If the elements pass a visual inspection, replace the N6200.

### Oscillator Failure

1. Inspect all GPS circuit elements around the GPS RF chip (N6250).
2. If the elements pass a visual inspection, replace the GPS TCXO (B6250).

### CW Test Failure

1. Check that the signal generator is on and sourcing a signal to the GPS RF input port (X6250).
2. Inspect all GPS RF circuit elements.
3. Probe the GPS RF test points on page 64.
4. If the elements pass a visual inspection and the RF is good, replace the GPS RF IC (N6250).

### GPS RF Troubleshooting

Use the following steps to trouble shoot the GPS receiver.

1. On the **GPS Control** dialog box, select **On**.

2. Click **Execute**.




Figure 54: Turning on the GPS receiver on the GPS Control dialog box

3. Inject a -50dBm tone at 1575.52MHz at the GPS connector (X6250) with a signal generator or a call box. (See [Figure 52](#).)

### GPS DC Test Points

Measure the following test points with an AAS-10B probe and spectrum analyzer set at center frequency 1575.25MHz (span = 500kHz), or with a voltmeter as required.




Figure 55: GPS DC probe points on the top side of the UI PWB

Table 18 shows the values for the GPS DC test points in Figure 55.

Table 18: GPS DC Test Point Values

Test Point	Description	Value
1	VRF_GPS	2.8V
2	LNA base	0.8V
3	VIO	1.8V
4	LNA Vcc	1.5V
5	GPS RF connector	
6	Ceramic filter	
7	GPS TCXO	

GPS RF Test Points




Figure 56: GPS RF probe points on the top side of the UI PWB

Table 19 shows the values for the GPS RF test points in Figure 56. All points are 1575.52MHz, except TCXO.

Table 19: GPS RF Test Point Values

Test Point	Description	Value
1	First RF filter input	-62dBm
2	First RF filter output	-65Dbm
3	GPS TCXO	16.368MHz = -4dBm
4	LNA out	-48dBm
5	Second RF filter input	-48dBm
6	GPS TCXO	16.368MHz = -19dBm
7	GPS RF connector	



## FM Radio Troubleshooting

### FM Radio Schematic

The following schematic is for general reference only. See the *Schematics* chapter for a detailed version.




Figure 57: FM radio schematic

## FM Radio Troubleshooting Setup

Use the following steps to troubleshoot the FM radio while using a Pop-Port™ headset.

1. Connect the Pop-Port™ headset (HDS-3) to the Pop-Port™ connector (bottom connector).
2. Select the **Menu > Media > Radio** from the mobile terminal user interface.
3. In an FM radio broadcast coverage area, set a local radio channel by scanning automatically using the **Automatic tuning** option. (Scanning up and down the channels by pressing the "Up" and "Down" key respectively).
4. If no channel could be found, inspect all the components in the FM radio circuitry.
  - If the circuits pass a visual inspection, check the existence of the LO (by radiative pickup) near the VCO of the FM Radio IC.
  - If no LO is found, replace the FM radio IC.
5. Listen for sound out of the headset.
  - If there is a signal present, continue to step 6.
  - If there is no static sound present, inspect all FM Radio circuits on the PCB and refer to the "Audio" section of the *Baseband Description and Troubleshooting* chapter for more information.
6. Disconnect the Pop-Port™ headset and connect the universal headset to the UHJ (top connector).
7. With the universal headset connected, repeat steps 1–5.
  - If there is a signal present, the FM Radio is working properly.
  - If there is no static sound present, refer to the "Audio" section of the *Baseband Description and Troubleshooting* chapter for more information.

## FM Radio Part Layouts and Test Points

Use the following values when probing the LO near the VCO of the FM radio IC (N6100). See [Figure 58](#) for the location of the N6100.

Table 20: FM Radio Test Point Values

Description	Value
LO frequency	(Rx frequency + IF frequency) x 2
IF frequency	225kHz

For example, if the Rx frequency is 87.5 and the IF frequency is 225kHz, the LO equals 175.45MHz [(87.5+0.225)\*2 = 175.45MHz].




Figure 58: FM radio test points on the top side of the main PWB

This page intentionally left blank.