

*Cucina*

**Café duo**

HD7140




**PHILIPS**

## Important

Read these instructions for use carefully before using the appliance and save them for future reference.

- ▶ Check if the voltage indicated on the appliance corresponds to the local mains voltage before you connect the appliance.
- ▶ Do not use the appliance if the mains cord, the plug or the appliance itself is damaged.
- ▶ If the mains cord is damaged, it must be replaced by Philips, a service centre authorised by Philips or similarly qualified persons in order to avoid a hazard.
- ▶ Keep the appliance and its cord out of the reach of children. Do not let the mains cord hang over the edge of the table or worktop on which the appliance is standing.
- ▶ Do not place the appliance on a hot surface and prevent the mains cord from coming into contact with hot surfaces.
- ▶ Never pour milk or coffee into the water tank.

## Preparing for use




- 1** Place the appliance on a horizontal surface.
- 2** Put the plug in the wall socket.
- 3** Wind excess cord clockwise around the cord storage facility at the back of the appliance.

Prevent the cord from coming into contact with hot surfaces.


## Using the appliance



- 1** Fill the cup or cups you are going to use with fresh, cold water.
- 2** Pour the water into the water tank.  
Do not fill the water tank beyond the maximum level indication ('MAX').



- 3** Put a paper filter (no. 101) in the filter holder.



- 9** If you have used the permanent filter, empty and rinse it.

Let the appliance cool down for at least 4 minutes before you start making coffee again.

## Cleaning

- 1** Unplug the appliance.
- 2** Clean the appliance with a moist cloth.

Never immerse the appliance in water!

- 3** Clean the separate parts (drip tray, filter holder and permanent filter, if any) in warm water with some washing-up liquid or in the dishwasher.

## Descaling

Regular descaling will prolong the life of your appliance and will guarantee optimal brewing results for a long time.


In case of normal use, descale the appliance:

- 2 or 3 times a year if you are using soft water (up to 18 dH);
- 4 or 5 times a year if you are using hard water (over 18 dH).

Turn to your local water board for information about the water hardness in your area.

- 1** Fill the water tank with white vinegar (4% acetic acid). Do not put a filter or coffee in the filter holder.
- 2** Let the appliance run twice.  
You can use the same vinegar for both runs.
- 3** Let the appliance complete two more runs with fresh, cold water to remove any vinegar and scale residues.
- 4** Clean the separate parts (see chapter 'Cleaning').


► You can also use an appropriate liquid descaler. In that case, follow the instructions on the package of the descaler.



**3** Some types come with a permanent filter.


Never use a permanent filter and a paper filter at the same time.

- ▶ You can also order the permanent filter separately (see chapter 'Ordering cups and filter').




**4** Put ground coffee (filter-fine grind) in the filter.

- If you grind the coffee beans yourself, do not grind them too finely.
- Take approx. two level measuring spoons of ground coffee for each cup when you are using large cups (for instance the cups that come with the appliance).
- Take one level measuring spoon of ground coffee for each cup when you are using smaller cups.
- Of course you can adapt the amount of coffee to your own taste.



**5** Place the cup or cups under the dispensing openings.



**6** Switch the appliance on by pressing the button.


The on/off light goes on.

Do not remove the cup or cups while the appliance is brewing!

- ▶ During brewing, you can only switch the appliance off by removing the mains plug from the wall socket. When you reinsert the plug into the wall socket, the appliance will continue brewing until the water reservoir is empty.

**7** The appliance switches off automatically after brewing. After the on/off light has gone out, wait until no more coffee drips from the filter before you remove the cup or cups.

- NB: the appliance does not keep the coffee hot!
- The after-brew drip stop prevents coffee from dripping onto the drip tray after brewing. This drip stop may cause some water to remain behind in the filter holder. This does not mean that the filter is clogged.



**8** If you have used a paper filter, throw it away.

## Ordering accessories

### Cups

- You can order new cups (type no. HD7978) from your Philips service centre.

### Permanent filter

- The permanent filter is available under type no. HD7951.

## Guarantee & service

If you need information or if you have a problem, please visit the Philips website at [www.philips.com](http://www.philips.com) or contact the Philips Customer Care Centre in your country (you will find its phone number in the worldwide guarantee leaflet). If there is no Customer Care Centre in your country, turn to your local Philips dealer or contact the Service Department of Philips Domestic Appliances and Personal Care BV.

