

Table of Contents

OVERALL MACHINE INFORMATION

1. SPECIFICATIONS	1-1
2. DIFFERENCE BETWEEN VT2000 SERIES AND VT2105	1-4
3. ELECTRICAL COMPONENT DESCRIPTIONS	1-6

DETAILED SECTION DESCRIPTIONS

1. OPTICS	2-1
1.1 OVERALL	2-1
1.2 CIRCUIT	2-2
1.3 THERMAL HEAD	2-4
2. DRUM	2-6
2.1 DRUM CONNECTION MECHANISM	2-6
2.2 CIRCUIT	2-7
3. PAPER DELIVERY	2-8
3.1 EXIT PAWL AIR PUMP MECHANISM	2-8

INSTALLATION

1. INSTALLATION PROCEDURE	3-1
---------------------------------	-----

SERVICE TABLES

1. MAINTENANCE TABLE	4-1
1.1 TABLE OF SERVICE CALL INDICATIONS	4-1
2. DIP SW, LED, VR, AND TP TABLES	4-2
2.1 DIP SW TABLE (ON THE MAIN BOARD)	4-2
2.2 DIP SW TABLE (Image Processing Board)	4-3
2.3 LED TABLE	4-3

2.4 VR TABLE (Main Board)	4-4
2.5 VR TABLE (AD Conversion Board)	4-4
2.6 TEST PIN TABLE (Main Board)	4-4
2.7 TEST PIN TABLE (A/D Conversion Board)	4-4
3. SERVICE PROGRAM TABLE: VT2105	4-5
3.1 HOW TO ACCESS I/O CHECK MODE	4-5
3.2 OUTPUT MODE:	4-6
3.3 INPUT MODE:	4-7
4. TEST PATTERN IMAGE MODE	4-8
4.1 OPERATION: (To Enter Test Pattern Image Mode)	4-9
5. AVAILABLE OPTION/SUPPLY TABLE	4-10

REPLACEMENT AND ADJUSTMENT

1. OPTICS ADJUSTMENT	5-2
1.1 PREPARATION FOR ADJUSTMENT	5-2
1.2 BLACK LEVEL ADJUSTMENT	5-3
1.3 SHADING ADJUSTMENT	5-3
1.4 SCAN LINE POSITION ADJUSTMENT	5-4
1.5 READING START POSITION ADJUSTMENT (In The Main Scan Direction)	5-4
1.6 FOCUS ADJUSTMENT	5-5
1.7 REDUCTION RATIO ADJUSTMENT	5-5
1.8 WHITE LEVEL ADJUSTMENT	5-6
1.9 IMAGE MAGNIFICATION IN THE SUB-SCAN DIRECTION ADJUSTMENT	5-6
2. THERMAL HEAD VOLTAGE ADJUSTMENT	5-7
3. AIR PUMP TIMING ADJUSTMENT	5-8