



ROHDE & SCHWARZ

Test and Measurement
Division

Release Notes

Firmware Release 4.32 (XP)

for R&S ESCI EMI Test Receivers
with order number: **1166.5950.03**

and R&S ESPI Test Receivers
with order number: **1164.6407.xx**

New Features:

- Required sweep time reduced for video bandwidth < resolution bandwidth.
- New SAVE//RECALL menu and dialogs.
- ASCII Export function for Marker Peak List.
- Adjustable marker position knob stepsize.
- New trace average function Power.
- Easy access to Windows XP Start menu.
- HP emulation: Personality Spurious supported.
- HP emulation: Personality Phase Noise supported.
- HP Emulation: additional commands supported
- Option FSP-B10: Frequency range of SMF100A increased to 43.5 GHz
- International keyboard driver package supported (German, Spanish, French, Italian and Portuguese)
- New dialogs available for file/path selection (e.g. for Trace Export, Firmware Update Path)
- Additional soft keys available to change the LAN configuration
- ACP: Extended upper limits for Ch. Bandwidth (5 GHz) and Ch. Spacing (20 GHz)
Overlapping Adjacent Channels allowed now for parallel measurements
New result output format for number of adj. channels > 3
- ACP Measurement: New result output format for number of ADJ Channels > 3
- FS-K7: Deemphasis is available for active Weighting AF Filter CCTTT and CCIR
New measurement function MC PHASE RESPONSE
- FSU-B9: The number of sweep points allowed in analyzer mode is now supported in NETWORK mode, too.
- Statusbit 4 (0x10) is set in Status Operation Register when scan is running
- New parameter coupling "Analyzer Marker Frequency -> Receiver Frequency"

Release Note Revision: 3

Contents

History	6
General Topics	6
Firmware Update	6
Generation of the update disk set.....	6
Preparing an installation via LAN or USB stick:.....	7
Performing the firmware update on the instrument	7
Known problems during firmware update	8
Firmware installation of the R&S FS-K7 FM demodulator software	9
Enabling the option via option key code entry	9
Modified Functions.....	10
Problems Eliminated.....	14
Known Problems	16
Modifications to the Operating Manual	17
Last minute changes to the operating manual.....	17
Basic Settings - Instrument Drives Usage.....	17
Basic Settings - International Keyboard Support	17
Basic Settings - File and Path Selection using front panel keys	20
External Generator Control – Option R&S FSP-B10	21
Menu AMPT (only ESCI Receiver)	21
Menu FILE	22
Menu MEAS (Receiver)	23
Menu MEAS – CHAN PWR ACP / MULTI CHAN ACP (Analyzer).....	25
Menu MEAS – CHAN PWR ACP / MULT PWR ACP – CP/ACP CONFIG (Analyzer).....	25
Menu MEAS - DEMOD - SQUELCH (Receiver).....	26
Menu MEAS – MULT CARR ACP – CP/ACP CONFIG (Analyzer)	26
Menu MEAS – SIGNAL STATISTICS - NEXT	27
Menu MEAS – SPURIOUS EMISSION	30
Menu MEAS – NEXT – HARMONIC DIST (Analyzer).....	37

Menu MEAS – STATISTICS – CCDF ON / APD ON – SCALING (Analyzer)	37
Menu MKR - NEXT (Analyzer).....	38
Menu MKR – NEXT – NEXT (Analyzer)	39
Menu MKR→ – NEXT – NEXT (Analyzer).....	39
Menu MKR FCTN (Analyzer).....	39
Menu MKR FCT - MARKER DEMOD - SQUELCH (Analyzer).....	40
Menu MKR FCTN – PHASE NOISE (Analyzer).....	40
Menu MKR FCTN – PEAK LIST (Analyzer).....	40
Menu NETWORK with option R&S FSP-B9	40
Menu NETWORK with option R&S FSP-B10 – EXT SOURCE.....	41
Menu NETWORK with option R&S FSP-B10	43
Menu TRACE (Receiver).....	44
Menu TRACE - NEXT (Analyzer)	45
Menu TRACE – NEXT (Analyzer).....	45
Menu TRACE – DETECTOR – NEXT (Analyzer).....	47
Menu TRIG	47
Menu TRIG - NEXT (Analyzer).....	47
Menu SETUP – NEXT	48
Menu SETUP - GENERAL SETUP - GPIB.....	48
Menu SETUP - GENERAL SETUP - GPIB.....	48
Menu SETUP - GENERAL SETUP - GPIB.....	48
Menu SETUP – GENERAL SETUP - CONFIGURE NETWORK.....	49
Menu SETUP – SYSTEM INFO MEAS – STATISTICS	50
Menu SETUP - TRANSDUCER.....	50
Hotkey RECEIVER, Menu MEAS (Receiver)	51
Remote Control – VXI11 support.....	52
Remote Control – Description of Commands – CALCulate:LIMit Subsystem	53
Remote Control – Description of Commands – CALCulate:PEAKsearch Subsystem	53
Remote Control – Description of Commands – INITiate Subsystem	54
Remote Control – Description of Commands – MMEMory Subsystem.....	54
Remote Control – Description of Commands – SENSE:CORRection Subsystem	55
Remote Control – Description of Commands – SENSE:LIST Subsystem.....	56
Remote Control – Description of Commands – SENSE:MPOWer Subsystem	56

Remote Control – Description of Commands – SENSE:SWEep Subsystem	56
Remote Control – Description of Commands – SYSTEM Subsystem.....	56
Remote Control – Description of Commands – SYSTEM:COMMunicate Subsystem.....	57
Remote Control – Description of Commands – TRACe Subsystem	57
TRACe<trace #>:IMMEDIATE:LEVel? and TRACe<trace #>:IMMEDIATE:RESult?	58
Supported 85xx-commands.....	59
Model dependent default settings.....	62
Trace data output formats	62
GPIB status reporting system	62
R&S FS-K7 Extensions	64
Menu FREQUENCY	64
Menu FM DEMOD	64
HIGH PASS AF FILTER	65
LOW PASS AF FILTER.....	65
DEEMPHASIS	66
WEIGHTING AF FILTER.....	66
Menu FM DEMOD - RANGE - UNIT	66
Appendix: Contact to our hotline.....	68

History

Date	Rel Note Rev	Changes
7 Nov 2007	1	First Revision for 4.12
28 Nov 2007	2	Headline changed
20 Aug 2008	3	First Revision for 4.32

General Topics

Firmware Update

Generation of the update disk set

The files needed for the firmware update are grouped according to the disk contents:

Disk 1:	disk1.bin	(self-extracting ZIP file; needs to be renamed to disk1.exe before unpacking)
Disk 2:	data3.cab	(packed contents of disk 2, will be automatically unpacked by FW update)
Disk 3:	data4.cab	(packed contents of disk 3, will be automatically unpacked by FW update)
...
Disk 13:	data14.cab	(packed contents of disk 13, will be automatically unpacked by FW update)
Disk 14:	data15.cab	(packed contents of disk 14, will be automatically unpacked by FW update)

Please note that the difference in disk number and filename of the corresponding archive file is by intention, not by chance!

The contents of disk 1 are packed in a self-extracting ZIP file and need to be unzipped. For this purpose the following steps are necessary:

1. Create a temporary directory on your local PC (e.g. MyTemp on drive C:)
2. Copy disk1.bin into that directory and rename it to disk1.exe
3. Execute disk1.exe. Under Windows 95/98/NT/2000 this is done best using the following sequence:
`<CTRL><ESC> - RUN - C:\MyTemp\Disk1 - <ENTER>`
 or
`<CTRL><ESC> - AUSFÜHREN - C:\MyTemp\Disk1 - <ENTER>` for a German Windows version.

The files will be unzipped

4. Delete disk1.exe from the temporary directory.
The temporary directory will now contain the following files:

data1.cab	data1.hdr	data2.cab	ExecCtrl.exe	ikernel.ex_	ISSetup.exe
layout.bin	RestInst.exe	Setup.exe	Setup.ini	setup.inx	

Please make sure that all the filenames are spelt correctly on your disks before you try to use them for the firmware update. Especially the trailing underscore('_) as used in ikernel.ex_ is essential for correct operation of the update program.

5. Copy the contents of the temporary directory onto update disk #1.

The contents of the other disks are already packed in the format required by the firmware update program and need no further processing. The files only need to be copied onto disks #2 to #14, the number in the filename (minus 1) indicating the corresponding disk number (data3.cab => disk #2, data4.cab => disk#3, etc.).

Preparing an installation via LAN or USB stick:

If the installation is performed via LAN or USB stick please set up a directory structure as shown on the right.

Copy all files as mentioned in the previous section in the directories Disk1 – Diskxx.

The directory path shall not contain more the 64 characters.



Performing the firmware update on the instrument

A new method to install the base system is available, if the installed base system firmware is V4.12 or newer. The sub directories for all update sets have to be arranged as described in the section "*Preparing installation via LAN or USB stick*". The new update manager will search for available update sets.

For updating to version 4.12 first update the bases system only to get the new update manager. Then update base system using the new update manager.

Skip the part *Base System Update*, if base system firmware V4.12 or newer is already installed and the directories are arranged as described above (with LAN or USB stick).

Base System Update:


The firmware update process is performed in the following steps:

- Switch the instrument on and wait until the Analyzer has resumed operation.
- For updates from LAN or USB use the SETUP | NEXT | FIRMWARE UPDATE | UPDATE PATH softkey to specify any path for the location of the disk directory (e.g. F:\MyTemp). For floppy usage the default A:\ must not be changed.
- Press SETUP → NEXT → FIRMWARE UPDATE
- Confirm the query "Do you really want to update the firmware?" with OK
- Insert update disk #1 to #14 as requested (for LAN or USB just confirm the copy process)
- The instrument will perform several automatic shutdowns, until the new firmware is installed properly.
Do not switch the instrument off until the update process has been finished completely.

Complete Update with update manager:

- Use the SETUP | NEXT | FIRMWARE UPDATE | UPDATE PATH softkey to specify any path for the location of the disk directory (e.g. F:\MyTemp).
- Press SETUP → NEXT → FIRMWARE UPDATE

The *Installation Manager* will terminate the analyzer application, search for available application update set and will show a selection list.



- Start the installation process with INSTALL.
REBOOT will abort the update and restart the analyzer application without any changes.
- The instrument will perform several automatic shutdowns, until the new firmware and all applications are installed properly.

Do not switch the instrument off until the update process has been finished completely.

After a successful firmware update it is necessary to execute the instrument's self alignment process by pressing CAL and softkey CAL TOTAL.

Known problems during firmware update

After switching on the instrument for the first time after a successful firmware update, the following system message might occur once:

System Message
CDS: Error...

In this case the unit needs to be switched off and on again. This system message does not appear again during further power-on cycles.

Note: *If the unit is not restarted as described, system error correction data (CAL TOTAL) of a later date will be lost when switching the unit on again.*

Firmware update with ESPI-B20 and ESCI-B20 (flash disk):

At the final step of the setup, backup files are stored for the 'Analyzer Firmware Backup' (option during the start-up of the instrument). This backup is only available for analyzers equipped with hard discs. Therefore an error message "Add folder icon failed" occurs twice if the ESxI-B20 is installed.

Workaround: Accept that message via the 'OK' button twice. The firmware update will continue without any problem! This problem is solved with version 3.50 or later.

Message box: Can't open front panel driver, error code=0x2

For some constellations this message box occurs after the last reboot of the device. Please start the WDMutility with START | PROGRAMS | WDM Utility and click the START button. The device will boot twice (the message box will be still shown after the first boot) and after the second boot the measurement application comes up and the problem is solved.

Firmware installation of the R&S FS-K7 FM demodulator software

The R&S FS-K7 FM demodulator software package is included in the basic instrument firmware. It therefore needs no separate firmware update procedure.

Enabling the option via option key code entry

For activation of the R&S FS-K7 a license key for validation must be entered. The license key is printed either on a label on the rear panel of the R&S ESPI or delivered as a part of the R&S FS-K7 option package. The key sequence for entering the license key is:

SETUP - GENERAL SETUP – OPTIONS - INSTALL OPTION

Use the numeric keypad to input the option key number and press ENTER.

- On a successful validation the message 'option key valid' will appear.
- If the validation failed, the option software is not installed.

Modified Functions

1. (V3.32SP3) Receiver: Number of stored results per trace increased to 1 Mio.

The maximal number of measured frequencies is limited to 1.000.000. A maximum of 3 x 1.000.000 values (1.000.000 per detector) can be stored for postprocessing (was 100.000 before).

2. (V3.32SP3) Receiver: Downrange limit for Quasipeak Detector

The level limit for the autoranging function has been increased. Attenuation is now decreased earlier to get a better signal to noise ratio.

3. (V3.32SP3) Receiver: Audio not longer disabled with Quasipeak settling time

4. (V3.82) Receiver: Improved frequency tuning with Quasipeak Detector.

The level bargraph will not longer be blanked when the frequency is tuned manually.

5. (V3.82) Analyzer: Active transducer and adjust reference level procedure:

If transducers are active and the adjust reference level procedure (in measurements like ACP, occupied bandwidth, signal statistics, etc.) is invoked, the REFLVL ADJ AUTO/MANUAL of the SETUP|TRANSDUCER menu is set to AUTO thus the best dynamic performance is obtained.

6. (V3.82) Analyzer: Marker peak list in continuous sweep mode

In continuous sweep mode the marker peak list is not any longer executing a single sweep and then peak list search, but the peak list will immediately work on the current trace. This allows peak list functionality on averaged or max holded traces in continuous sweep mode. The single sweep mode is unchanged.

7. (V3.82) Analyzer: Harmonic measurement

The mixer level within the harmonic measurement is changed to -10 dBm. The value update in the lower screen happens during the sweep and not only at sweep end.

8. (V3.82) Display of RBW type

The selected type of the resolution bandwidth is displayed as label on the right side of the diagram.

3DB	NORMAL (3dB)
6DB	NORMAL (3dB)
FFT	FFT
CHN	CHANNEL
RRC	RRC

9. (V3.82) 1 MHz 6 dB Resolution Bandwidth

The 1 MHz 6 dB resolution bandwidth has been adjusted to better match the impulse bandwidth.

10. (V4.12) CCDF measurement result table extended by 0.01% value.
11. (V4.12) New marker functions AUTO MAX PEAK and AUTO MIN PEAK.
12. (V4.12) HP emulation: HP Models 71100C, 71200C and 71209A are using 800 sweep points.
13. (V4.12) Additional number of sweep points 201, 401, 801 and 1601.
14. (V4.12) HP emulation: Additional models 8568A_DC and 8568B_DC using DC coupling.
15. (V4.12) HP emulation: GENERAL SETTINGS - GPIB menu extended by IF GAIN NORM / PULS.
16. (V4.12) New spurious emissions measurement LIST EVALUATION.
17. (V4.12) FS-K7: The THD Unit is selectable (dB / %) in the AM signal / AF spectrum result.
18. (V4.12) New function MARKER FILE EXPORT.
19. (V4.12) Signal Track: Enhanced sensitivity in marker tracking function.
The marker is now set to the signal peak after very single sweep. In previous versions, this only happened if the difference between signal peak and center frequency exceeded 20 % of the Resolution Bandwidth.
20. (V4.12) Improved Firmware Update.
21. (V4.12) Gated statistics measurements APD, CCDF.
22. (V4.12) GPIB: Basic remote control of the signal generator which is connected to the additional FSP-B10 GPIB Interface.
23. (V4.12) GPIB: New commands available

:SENSe<1 2>:]CORRection:TRANsducer:ACTive?	returns active transducer
:CALCulate<1 2>:LIMit<1...8>:ACTive?	returns active limit line(s)
24. (V4.12) Trigger Line for video trigger now also visible outside of the trigger menu.
25. (V4.12) HP emulation: The OL command returns the mixer level in byte 23
26. (V4.12) HP emulation: The commands MKPK NH | NL | NR and KSK do not perform a sweep start when marker is already switched on.
27. (V4.12) HP emulation: The commands SNGLS and CONTS are setting the command complete bit (bit 4) in STB
28. (V4.12) HP emulation: New softkey SETUP - GENERAL SETUP - GPIB - SWEEP REP ON/OFF"
29. (V4.12) HP emulation: New commands: VARDEF, CTA, ADD, SUB, MPY, DIV
30. (V4.12) HP emulation: New command NORMLIZE for tracking generator
31. (V4.12) HP emulation: The command LF performs a reset
32. (V4.12) Scan needs to be interrupted for a hardcopy but it may be resumed after having done the hardcopy.
33. (V4.32) The Aquisition Time (for FFT filter) is now readable with remote command "SENS:SWE:TIME?".
34. (V4.32) New Save/Recall menu and dialogs.
35. (V4.32) Easy access to Windows XP Start menu (setup menu described in "Modifications to the Operating Manual").
36. (V4.32) Required sweep time reduced for video bandwidth < resolution bandwidth.
37. (V4.32) ASCII Export function for Marker Peak List.
38. (V4.32) Adjustable marker position knob stepsize.
49. (V4.32) New trace average function Power.
40. (V4.32) HP emulation: Personality Spurious supported.

41. (V4.32) HP emulation: Personality Phase Noise supported.
42. (V4.32) FSP-B10: Upper frequency limit of SMF100A is now 43.5 GHz .
43. (V4.32) FSP-B10: Support for SMA100, SMB100 (1/2/3/6GHz), SMF (22/43GHz) SMJ (3/6GHz).
44. (V4.32) FSP-B10: Support for SMF100a - TTL mode.
45. (V4.32) Function “CISPR RBW UNCOUPLED (SENSE1:BANDwidth:RESolution:AUTO)” changed.
In earlier versions this command was effective only when the quasipeak detector was activated in the receiver mode. Now this command is effective if any CISPR detector (Quasipeak, CISPR-RMS, CISPR-AV) is switched on.
46. (V4.32) Statusbit 4 (0x10) is set in Status Operation Register when scan is running.
47. (V4.32) All analyzer traces that are set to “MAX HOLD”, “MIN HOLD” or “AVERAGE” are set to “VIEW” after switching to receiver or mixed mode and back to analyzer mode.
48. (V4.32) Compatible limit lines keep active when switching between analyzer and receiver mode.
49. (V4.32) For local lockout the alias remote command SYSTem:KLOCK ON | OFF is provided.
50. (V4.32) International keyboard driver package supported (German, Spanish, French, Italian and Portuguese).
51. (V4.32) New dialogs available for file/path selection (e.g. for Trace Export, Firmware Update Path).
52. (V4.32) ACP: Extended upper limits for Channel Bandwidth (5GHz) and Channel Spacing (20GHz).
53. (V4.32) ACP: Overlapping Adjacent Channels allowed now for parallel measurements.
It is now possible to configure overlapping adjacent channels. Based on a common carrier channel setting, it is now possible to measure with two slightly different ADJ channel settings with one measurement.
Example: TX Channel / TX Bandwidth (common for both measurement A and B)
ADJ used for measurement A
ALT1 used for measurement A

ALT2 used as ADJ for measurement B
ALT3 used as ALT1 for measurement B
54. (V4.32) ACP Measurement: Result output format changed for number of ADJ channels > 3.
55. (V4.32) Additional soft keys available to change the LAN configuration.
56. (V4.32) Save dialog reports a warning, if no item to save is selected.
57. (V4.32) The increment behaviour of the step keys for parameter SWEEP POINTS is changed.
The behaviour of the knob wheel still has the highest possible resolution.
58. (V4.32) Dummy Video Bandwidth 0 Hz returned for active FFT filter.
59. (V4.32) Availability changed for Spurious Measurement.
The Spurious Measurement is not available if the ACP measurement is active.
60. (V4.32) HP emulation: Additional remote commands are supported.
The following commands are supported: ML, MEAS, SUM, LIMIPURGE, EDITLIML, LIMIREL, SDEL, SADD, LIMF, LIMU, LIML, LIMM, LIMD, LIMTFL, LIMTSL, SDON, EDITDONE, LIMISAV, LIMIRCL, LIMITEST, LIMIFAIL
61. (V4.32) HP emulation: A new softkey COUPLING FSP/HP is now available to change the Span/RBW and RBW/VBW default coupling.
62. (V4.32) HP emulation: The default for Sweep Repeats is now OFF for 856x and 859x.

63. (V4.32) FSU-B9: The number of sweep points allowed in analyzer mode is now supported in NETWORK mode, too.

64. (V4.32) FS-K7: Deemphasis is now additionally supported for active Weighting AF Filter CCTTT and CCIR.

65. (V4.32) New coupling parameter “Analyzer Marker Frequency -> Receiver Frequency”

IEEE/IEC bus command: INSTRument:COUPlE:MARKer ALL|NONE

If this coupling parameter is selected, the receiver frequency is set to the stimulus of the actual selected marker in analyzer mode. This coupling becomes effective only when switching from analyzer to receiver, IF analysis or APD mode.

66. (V4.32) CISPR detector not available in receiver mode if a previously started scan with 3dB filter was interrupted.

If a scan was started and interrupted (HOLD) with an 3dB filter, no CISPR detector can be activated.

67. (V4.32) Baud rate speed on COM (RS232) interface increased up to 128000 bps.

Now the following additional baud rates are available:

38400

57600

115200

128000

Problems Eliminated

The version numbers in brackets indicate the version in which the problem was observed for the first time.

Problem solved in version 3.82:

1. (V3.32) **Measurement in Receiver scan mode too fast**
The measurement time in scans started from below 150 kHz could be faster than defined in the scan table.
2. (V3.32) **Level of Display line could not be changed (Receiver mode)**
The Level value of a display line was fixed.
3. (V3.32) **Changing from a Setup, Hardcopy or File Menu to another menu needed two keystrokes**
4. (V3.32) **Video trigger in conjunction with transducer factors corrected.**
5. (V3.32) **FS-K7: all marker info disappears when markers are switched off.**

Problem solved in version 3.82 SP1:

6. (V3.82) **Instrument Firmware did not start.**
When the instrument has been switched off with full screen in receiver mode, the firmware did not start when the instrument was switched on again.
7. (V3.32) **Video Trigger and Transducer**
The Video Trigger level does now take active transducer factors into account.

Problem solved in version 3.92:

8. (V3.82) **Error Message: Your trial period will expire**
This error message now is only displayed when the option for a trial period is installed.
9. (V3.32) **Reception of a spurious signal with 100 Hz and 200 Hz RBW**
A spurious signal 1.8666 MHz away from the real signal has been removed.
10. (V3.32) **Display of RBW filter type with active OBW function**
Switching on the OBW function with RBW filter type FFT, the displayed filter type remained FFT instead of 3DB. .
11. (V3.32) **Remote Control: Block ready bit after Scan continue**
The block ready bit in the status reporting system is now correctly set after continuing a scan.
12. (V3.32) **Transducer factor with unit dBpW**
Transducer factors with unit dBpW are not longer based on the unit dB μ V.
13. (V3.32) **Squelch setting after power on**
The squelch setting is now properly restored after power on.
14. (V3.32) **Coupled Reference Level in Split Screen**
Switching on REF LEVEL COUPLED in the DISP menu could give an offset in the displayed level values.

Problem solved in version 3.92 SP1:

15. (V3.82) **FSP-B9: Amplitude droop of tracking generator output signal at 9kHz fixed**
This problem was reported for B9 board revisions with HWC 01 (see table SETUP - SYSTEM INFO - HARDWARE INFO, column HWC).

Problems solved in version 3.92 SP2:

- 16. (V3.92) Pressing the HCOPIY key does not longer close open tables on the screen**
It is now again possible to make hardcopies from tables.
- 17. (V3.92) Marker Next Peak in Receiver Scan**
The MKR→ NEXT PEAK softkey didn't work.
- 18. (V3.92) Autorange function in Receiver Mode**
The bargraph measurement function could display results before the final attenuator setting had been reached.

Problems solved in version 4.12:

- 19. (V3.92) Marker not available after Hardcopy**
Pressing the Hardcopy key while scanning made the marker function unavailable.
- 20. (V3.92) MMEMory command could block instument**
The instrument firmware could be blocked after several hundred MMEMory commands.
- 21. (V3.92) Wrong frequencies in trace export file with logarithmic x axis scaling in analyzer sweep**

Problems solved in version 4.32:

- 22. (V4.12) Device hangs after changing from local to remote state or vice versa when a scan is running.**
If a scan was running in remote state, the ESPI/ESCI hangs if the "Local" button was pressed. The same effect occurred when a scan was running in local state and the ESPI/ESCI was set to remote state. Now a running scan is stopped if the remote state is to be changed. The same error occurred if the display state was changed in remote state when a scan was running.
- 23. (V4.12) Lower limit line check did not work for a scan in receiver mode.**
Now the lower limit line check is available for a scan in receiver mode. If threshold scan is active and the lower limit line check is selected, a final measurement is performed if the signal level is lower than the limit value.
- 24. (V4.12) No IF-Overload was detected with analog RBW's.**
- 25. (V4.12) Wrong limit check if a dBuA transducer was active.**
If a transducer with dBuA and a compatible limit line was active, the signal level had to be 34 dB higher than the limit value to generate a limit failure.
- 26. (V4.12) Level error in analyzer sweep with preselector from 2MHz up to 8MHz.**
If a sweep with preselector from 2 MHz up to 8 MHz was performed, the signal was about 10 dB down at 2 MHz.
- 27. (V4.12) Wrong measurement time in receiver mode after "Recall" and changing frequency.**
If the receiver measurement time was set manually and a saveset with a different measurement time was recalled, the previously active time was adjusted again after changing the receiver frequency.
- 28. (V4.12) Wrong scan measurement time after activating the quasipeak detector.**
If two scan ranges with a short measurement time – for example 100 us – are defined the measurement time of all scan ranges was not set correctly to 500 us after activating the quasipeak detector.
- 29. (V4.12) Coupling of IF bandwidth to frequency range did not work correct with CISPR detectors in receiver mode.**
If CISPR RBW COUPLING is active and the CISPR RMS or CISPR AVERAGE detector is active, the resolution bandwidth was set to 120 kHz instead of 1 MHz if the receiver frequency was tuned to a value greater than 1 GHz. If the quasipeak detector is active, the maximum value of the resolution bandwidth is 120 kHz.

Known Problems

1. (V4.12) Underload detection in Status Reporting not available.

The detection of an underload in receiver mode is not available. Bit 1 and bit 9 in the STATUS:QUESTIONABLE:POWER register will not be set.

Modifications to the Operating Manual

The order numbers for the current manual sets for R&S ESCI are

- 1166.6004.11-01
1166.6004.81-01 (German)
- 1166.6004.12- 01
1166.6004.82-02 (English).
- 1166.6004.19-01
1166.6004.89-02 (English, letter format).

The order numbers for the current manual sets for R&S ESPI (XP) are

- 1164.6459.11-01
1164.6459.81-01 (German)
- 1164.6459.12-01
1164.6459.82-01 (English).
- 1164.6459.19-01
1164.6459.89-01 (English, letter format).

The corresponding PDF-Files for the operating manuals are separately available on our web page.

Last minute changes to the operating manual

Basic Settings - Instrument Drives Usage

The instrument's harddisk is divided in 3 (or 2) logical drives:

C: Contains the operating system Windows XP, printer driver, network driver,...

Other user programs, applications, driver should be stored/installed on drive C:.

D: Contains instrument's firmware and related data sets (limit lines, transducer,...)
D:\user\config is the default location for customer's instrument settings
D:\R_S\instr\temp is the default directory for hardcopy files.

Other user data should be stored on drive D:.

E: Backup storage location for Windows XP. Here a copy of the operating system is saved.
This drive is used to restore Windows XP using "Analyzer Firmware Backup" function on Power On. A copy of the currently installed update sets are located on this drive, too.
This drive is not available on instruments with option B18 Removable Harddisk

No additional data should be stored on this drive.

Basic Settings - International Keyboard Support


Since firmware version 4.3x following international keyboard drivers are supported.

- **French Keyboards**
- **German Keyboards**
- **Italian Keyboards**
- **Portuguese Keyboards**
- **Spanish Keyboards**

These drivers are pre installed if the instrument is shipped with version 4.3x or later. A separate installer file is available on the instrument's download area.

To change the keyboard driver language proceed with the following steps:


- 1) Start Windows Explorer
- 2) Start the installation procedure with double click onto the file **FsxInternationalKeyboards.msi**.
- 3) Reboot the analyzer.
- 4) Now open the windows start menu by pressing the windows key or <CTRL> <ESC>.
- 5) Select *Settings - Control Panel - Regional and Language Options - Languages*.



- 6) Select *Details*.



- 7) Select *Add*, choose one of the available input languages and confirm with OK and the dialog will be close.
8) Now change the *Default input language* as needed and close all open dialogs with OK.







- 9) Reboot the analyzer.

Basic Settings - File and Path Selection using front panel keys

Since firmware version 4.3x the analyzer base system firmware supports new dialogs to select a folder and/or a file, e.g. for trace export.

The following section describes the usage of the instrument's front panel keys using TRACE EXPORT as an example.

	<p><i>TRACE - NEXT - ASCII FILE EXPORT</i> opens the dialog. <i>File name</i> has the focus and it is now possible to edit the filename using numerical keys, CURSOR LEFT/RIGHT and BACK.</p> <p>The drive to be used is checked in following order:</p> <ul style="list-style-type: none"> ▪ Connected USB memory stick if not available then ▪ Drive A: if not available or no floppy disk inserted then ▪ Drive D: <p>Note: Path and filename are reset to default values with PRESET.</p>
	<p>To <i>change the drive</i> use the rotary knob until <i>Save in</i> gets the focus and press CURSOR RIGHT. Now use CURSOR UP/DOWN to select the drive and press ENTER key or the rotary knob.</p>
	<p>To <i>select a sub folder</i> or to <i>select a file</i> use the rotary knob until the file/sub folder list gets the focus. A selection frame is visible in that case.</p> <p>Now use CURSOR UP/DOWN to select a folder and press ENTER key or the rotary knob to change the path or select a file to overwrite this file with the new data.</p>
	<p>To enter alpha numeric characters for the file name use the rotary knob to set the focus on <i>edit filename</i> and press ENTER key or the rotary knob.</p>


External Generator Control – Option R&S FSP-B10

Note: The external generator control is only available in the spectrum analyzer mode and not in the receiver mode.

Menu AMPT (only ESCI Receiver)


RF INPUT AC/DC

The RF INPUT AC/DC softkey switches between AC and DC coupling of the instrument input. The state of the input coupling is displayed with an enhancement label on the right side of the diagram.




Frequency range	R&S ESCI DC coupled AC coupled	9 kHz to 3 GHz 1 MHz to 3 GHz
------------------------	--------------------------------------	----------------------------------

Measurements outside the valid frequency range are marked with the AC label in red



IEC/IEEE bus command: INP:COUP AC|DC

Menu FILE




SAVE -
Edit File Name

Sets the focus on the File Name field.

In the Save dialog box, the field already contains a suggestion for a new name: the file name used in the last saving process is counted up to the next unused name. For example, if the name last used was "test_004", the new name "test_005" is suggested, but only if this name is not in use. If the name "test_005" is already in use, the next free name is suggested, e.g. "test_006". You can change the suggested name to any name conform to the following naming conventions.

The name of a settings file consists of a base name followed by an underscore and three numbers, e.g. "limit_lines_005". In the example, the base name is "limit_lines". The base name can contain characters, numbers and underscores. The file extension is added automatically and can not be changed.


Menu MEAS (Receiver)



The *DETECTOR* softkey opens a submenu to select the detector and combinations of detectors.

A maximum of three detectors can be switched on simultaneously.

Note: *This softkey is also available in the Receiver-menu.*



The *CISPR RMS* softkey activates the weighting average detector according to to a proposed amendment of CISPR 16-1-1 (CISPR/A/628/CD). The IF bandwidth is automatically set to the required value according to the receiving frequency. This coupling can be cancelled by the *QP RBW UNCOUPLED* softkey.

IEC/IEEE-bus command: `DET:REC CRMS`

- The CISPR rms detector supplies a weighted average. When measuring the average according to CISPR 16-1, the maximum value of the linear average during the measurement time is displayed. The detector is used, for example, to measure pulsed sinusoidal signals with a low pulse frequency. It is calibrated with the rms value of an unmodulated sinusoidal signal. Averaging is with lowpass filters of the 2nd order (simulation of a mechanical instrument). The lowpass time constants and the IF bandwidths are fixed depending on the frequency. The main parameters are listed in the following table:

	CISPR Band A	CISPR Band B	CISPR Band C/D	CISPR Band E
Frequency range	9 kHz to 150 kHz	150 kHz to 30 MHz	30 MHz to 1000 MHz	> 1000 MHz
IF bandwidth	200 Hz	9 kHz	120 kHz	1 MHz
Lowpass time constant	160 ms	160 ms	100 ms	100 ms
Corner frequency	10 Hz	100 Hz	100 Hz	1 kHz

Effect of measurement time:

CISPR average and CISPR rms measurement: With a CISPR average or a CISPR rms measurement, the maximum value of the weighted signal during the measurement time is displayed. The relatively long time constants used with CISPR average and CISPR rms detectors result in long measurement times in order to obtain a correct measurement result. If unknown signals are measured, the measurement time should be at least one second so that pulses down to a frequency of 5 Hz are correctly weighted.

After a frequency change or a modification of the attenuation, the receiver waits until the lowpass has settled before the measurement time starts. The measurement time is selected depending on the IF bandwidth and the characteristics of the signal to be measured. Unmodulated sinusoidal signals as well as signals with high modulation frequency can be measured within a short time. Slowly fluctuating signals or pulse signals require longer measurement times.

Menu MEAS – CHAN PWR ACP / MULTI CHAN ACP (Analyzer)



The *CP/ACP STANDARD* softkey opens a list of selectable standards. WLAN 802.11A and WLAN 802.11B is appended to that list.

Notes:

FAST ACP is not available if a WLAN standard is selected.

IEC/IEEE-bus command:

CALC:MARK:FUNC:POW:PRES AWLan | BWLan

Menu MEAS – CHAN PWR ACP / MULT PWR ACP – CP/ACP CONFIG (Analyzer)



The *NO. OF ADJ CHAN* softkey enables input of the number ±n of adjacent channels which are taken into account for the adjacent channel power measurement.

Numbers between 0 and 12 can be entered.

IEC/IEEE bus command:

:SENS:POW:ACH:ACP 0..12

This increased number of adjacent channels is realized through all the relevant settings like:

ACLR LIMIT CHECK

:CALC:LIM:ACP:ACH:RES?
:CALC:LIM:ACP:ALT1..11:RES?

The following summary bits are introduced to STAT:QUES:ACPL:

Bit 14 : ALT3..11 LOWER or UPPER FAIL (screen B)
Bit 6 : ALT3..11 LOWER or UPPER FAIL (screen A)

EDIT ACLR LIMITS

:CALC:LIM:ACP:ACH:STAT ON
:CALC:LIM:ACP:ACH:ABS -10dBm, -10dBm
:CALC:LIM:ACP:ACH:ABS:STAT ON
:CALC:LIM:ACP:ALT1..11 0dB, 0dB
:CALC:LIM:ACP:ALT1..11:STAT ON
:CALC:LIM:ACP:ALT1..11:ABS -10dBm, -10dBm
:CALC:LIM:ACP:ALT1..11:ABS:STAT ON


ADJ CHAN BANDWIDTH

:SENS:POW:ACH:BWID:ALT1..11 30kHz

ADJ CHAN SPACING

:SENS:POW:ACH:SPAC:ALT1..11 4MHz


The *POWER MODE* sub menu allows to change between the normal (*CLEAR/WRITE*) and the max hold power mode. In the *CLEAR/WRITE* mode the channel power and the adjacent channel powers are calculated directly from the current trace. In *MAX HOLD* mode the power values are still derived from the current trace, but they are compared with a maximum algorithm to the previous power value. The greater value is remained.



IEC/IEEE bus command:

:CALC:MARK:FUNC:POW:MODE WRIT|MAXH

Menu MEAS - DEMOD - SQUELCH (Receiver)



The *SQUELCH* softkey enables the input of a level threshold below which the audible AF is cut off. The squelch function is associated with the internal trigger function (TRIGGER menu), which will be switched on automatically with the squelch. Squelch level and trigger level do have the same value.

The default setting for the squelch is off.

IEC/IEEE-bus command:

```
:SENS:DEM:SQU ON | OFF
:SENS:DEM:SQU:LEV 80 PCT
```

Menu MEAS – MULT CARR ACP – CP/ACP CONFIG (Analyzer)



The softkey CHANNEL SPACING opens a table which allows to set the spacings for the TX channels as well as for the adjacent channels. Up to now the TX spacing was a single parameter valid for all TX channels. Now the spacing between every TX channels can be defined separately. Therefore a TX spacing 1-2 for the spacing between the first and the second carrier, a TX spacing 2-3 for the spacing between the second and the third carrier and so on can be defined. In order to allow a convenient setup for the system with equal TX channel spacing, the value of TX spacing 1-2 will be copied in all the spacing below after entry, the TX spacing 2-3 will be copied in all the spacing below after entry and so forth. For different spacings a setup from top to bottom is necessary.

If the spacings are not equal the channel distribution according to the center frequency is as follows:

Odd number of TX channels:

The middle TX channel is centered to center frequency.

Even number of TX channels:

The two TX channels in the middle are used to calculate the frequency between those two channels. This frequency is aligned to the center frequency.

IEC/IEEE-bus command:

```
[SENSe<1|2>:]POWER:ACHannel:SPACing:CHANnel<1..11>
100 Hz ... 2000 MHz
```

This command defines the channel spacing of the carriers. At the same time the spacing of carriers with higher channel number are set to the same value. If the spacing is equal between all carriers it is sufficient to set the spacing between carrier 1 and 2 with the command `SENS:POW:ACP:SPAC:CHAN1` or `SENS:POW:ACP:SPAC:CHAN`. If the spacing are set in ascending order individual spacing of the carriers can be set.

Example: `"POW:ACH:SPAC:CHAN2 4.8MHz"`
'sets the spacing between TX carrier 2 and 3 to 4.8 MHz.

Note:

If the ACP or MCACP measurement is started all settings according to the standard including the channel bandwidths and channel spacings are set and can be adjusted afterwards.

With the softkey NO. OF TX CHAN now up to 12 carriers can be measured.




IEC/IEEE-bus command:

```
[:SENSe<1|2>:]POWER:ACHannel:TXChannel:COUNT 1..12
```


Menu MEAS – SIGNAL STATISTICS - NEXT

Statistic measurements on pulsed signals can be done using GATED TRIGGER. An external frame trigger is required as a time (frame) reference.



The gate ranges define the part of the I/Q capture data taken into account for the statistics calculation. These ranges are defined relative to a reference point $T=0$. The gate interval is repeated every period time until the end of the I/Q capture buffer.

The reference point $T=0$ is defined by the external trigger event and the instrument's trigger offset.




GATED TRIGGER activates the gating for statistics functions. The trigger source is changed to EXTERN if this function is switched on.

Note:

The I/Q data capturing is repeated until the configured number of valid samples is reached. If the active gate period is outside the I/Q capture buffer or the resulting gate time is zero the measurement will not reach its end. In this case, the range start and stop values have to be checked.

IEC/IEEE-bus command:

[SENSe<1|2>]:SWEep:EGATE ON | OFF



GATED RANGE opens a table to configure up to 3 gate ranges for each trace.

GATE RANGES			
	Trace 1	Trace 2	Trace 3
Comment			
Period	4.615 ms		
Range 1 Start	0 us		
Range 1 Stop	200 us		
Range 1 Use Range	YES		
Range 2 Start			
Range 2 Stop			
Range 2 Use Range			
Range 3 Start			
Range 3 Stop			
Range 3 Use Range			

- Comment: Comment string
- Period: Period of the signal to be measured.
The signal period is common for all ranges.
- Range x Start: Begin of time period to be taken into account.
- Range x Stop: End of time period to be taken into account.
- Use Range: YES / NO: Allows to temporarily disable a range.


Note: The timing values have full numerical resolution and are only rounded for display.

IEC/IEEE-bus command:

[:SENSe<1|2>]:SWEep:EGATE:TRACe<1...3>:COMMENT
 [:SENSe<1|2>]:SWEep:EGATE:TRACe<1...3>:STATe<1...3> ON | OFF
 [:SENSe<1|2>]:SWEep:EGATE:TRACe<1...3>: START<1...3> value
 [:SENSe<1|2>]:SWEep:EGATE:TRACe<1...3>: STOP<1...3> value
 [:SENSe<1|2>]:SWEep:EGATE:TRACe<1...3>: PERiod value

Gated statistics configuration example:

A statistics evaluation has to be done over the useful part of the signal between t3 and t4.
 The period of the GSM signal is 4.61536 ms




- t1: External positive trigger slope
- t2: Begin of burst (after 25 μ s)
- t3: Begin of useful part, to be used for statistics (after 40 μ s)
- t4: End of useful part, to be used for statistics (after 578 μ s)
- t5: End of burst (after 602 μ s)

The instrument has to be configured as follows:

Trigger Offset	$t2 - t1 = 25 \mu\text{s}$	now the gate ranges are relative to t2
Range1 Start	$t3 - t2 = 15 \mu\text{s}$	start of range 1 relative to t2
Range1 End	$t4 - t2 = 553 \mu\text{s}$	end of range 1 relative to t2

Menu MEAS – SPURIOUS EMISSION

All real amplifiers also generate unwanted RF products outside the assigned frequency band. These spurious emissions are usually measured across a wide frequency range, for example from 9 kHz to 12.75 GHz (ETSI). The spectrum analyzer settings are specified for each frequency range.




In the Spurious Emissions mode, the analyzer performs measurements in predefined frequency ranges with settings that can be specified individually for each of these ranges.

For this purpose, the SWEEP TABLE settings or the current device settings are used. Up to 20 subranges can be defined (they need not directly follow one another) across which the analyzer sweeps in subsequent order. However, the measurement ranges must not overlap. The measurement parameters can be selected independently from each other in every subrange (SWEEP LIST menu, EDIT SWEEP LIST).

Limit lines are defined and displayed irrespective of the sweep ranges, i.e. they are not part of the sweep ranges. The unit of the limit lines is restricted to dB or dBm.

The frequency range where measurements are actually performed is set by the start and stop frequency parameters of the analyzer; these parameters are independent of the sweep ranges. It is thus possible to define sweep ranges for a measurement task that can be stored and reloaded and to quickly and easily set the frequency range to be actually measured by means of two parameters; complex editing in the sweep table is not necessary.

Note: When a limit line is defined in steps, the weaker limit is used at the frequency point with the straight vertical section.



The SPURIOUS ON OFF softkey switches the spurious emissions measurement on or off according to the current configuration.

IEC/IEEE bus command: SWEEP:MODE LIST switches the spurious list on
SWEEP:MODE AUTO switches the spurious list off



The SWEEP LIST softkey opens a submenu where predefined sweep ranges can be edited, or new ranges generated or deleted. A table listing the current sweep ranges is displayed.


IEC/IEEE bus command: --



The softkey LIST EVALUATION activates or deactivates spurious emission measurement LIST EVALUATION. The peak search evaluation is automatically done during measurement and the results are displayed in a table in the lower part of the screen.

Following results are listed:

- Frequency range
- Frequency of the absolute peak power in this range in dBm
- Level delta to the limit with margin in dB
- Limit check state (by color change and an asterisk at the end of the line if failed).



If LIST EVALUATION is switched on, the functions PEAKS PER RANGE, MARGIN, PEAK SEARCH and VIEW PEAK LIST are not available.

IEC/IEEE bus command: :CALCulate1:PEAKsearch:AUTO ON | OFF



The EDIT SWEEP LIST softkey opens the table for editing the sweep range.


In the SWEEP LIST table, the individual sweep ranges are set.

- Range Start: Start frequency of the range
- Range Stop: Stop frequency of the range
- Filter Type: Filter type: NORMAL, CHANNEL, RRC
- RBW: Resolution filter bandwidth
- VBW: Video filter bandwidth; not applicable for CHANNEL and RRC filters
- Sweep Time Mode: AUTO / MANUAL
- Sweep Time: Sweep time; if AUTO is indicated for the sweep time mode, the automatically calculated sweep time is displayed. If the cell is edited, the associated sweep time mode is automatically set to MANUAL.
- Detector: Specifies the range detector: Sample, Average, Max Peak, RMS, Min Peak and Auto Peak
- REF-Level: Reference level in dBm
The upper edge of the displayed screen area is the value of the maximum reference level, corrected by the associated transducer factor.
- RF-Attenuator-Mode: AUTO / MANUAL
- RF-Attenuator: Number; as with Sweep Time
- PRE-AMP: ON / OFF; preamplifier selection (options B23, B25, if available)


Sweep Points	Number of sweep points per range (sweep segment). The number of sweep points must not exceed 100001 .
Stop after Sweep	ON / OFF; if ON, the sweep is stopped after the range and continued only if confirmed by you via a message box.
Transd. factor	NONE or factor (enter via selection list)
Limit check	ON / OFF (common for all ranges).
Limit	Limit in dBm (enter via selection list) A temporary limit line '_SPUL_IN_' is used, based on the range limits. This temporary limit line is created at measurement start and may be copied for other purposes.

IEC/IEEE bus commands: SENS:LIST:RANGE<1...20>:...


SWEEP LIST					
	RANGE 1	RANGE 2	RANGE 3	RANGE 4	RANGE 5
Range Start	9 kHz	50 MHz	500 MHz		
Range Stop	50 MHz	500 MHz	1 GHz		
Filter Type	NORMAL	CHANNEL	RRC		
RBW	10 kHz	100 kHz	1.28 MHz		
VBW	30 kHz	300 kHz	10 MHz		
Sweep time mode	AUTO	MANUAL	AUTO		
Sweep time	500 ms	10 s	65 ms		
Detector	Peak	RMS	Peak		
REF-Level	-20 dBm	-20 dBm	-20 dBm		
RF-Att. mode	AUTO	MANUAL	AUTO		
RF-Attenuator	10 dB	5 dB	10 dB		
PRE-AMP	OFF	OFF	OFF		
Sweep Points	501	501	501		
Stop after sweep	ON	OFF	OFF		
Transd. factor	LOWFREQ	MIDFREQ	MIDFREQ		
Limit check	ON	ON	ON		
Limit	-13 dBm	-13 dBm	-13 dBm		




The *INS BEFORE RANGE* softkey inserts a range in front of the marked line.
IEC/IEEE bus command --



The *INS AFTER RANGE* softkey inserts a range following the marked line.
IEC/IEEE bus command --




The *DELETE RANGE* softkey deletes the current range. All higher ranges are set back by one.
IEC/IEEE bus command `LIST:RANGe<1...20>:DELeTe`




The *NEXT RANGE* softkey activates the displays of the next higher subranges, i.e. 6 to 10, 11 to 15 or 16 to 20.
IEC/IEEE bus command --




The *PREVIOUS RANGE* softkey activates the displays of the next lower subranges, i.e. 1 to 5, 6 to 10 or 11 to 15.
IEC/IEEE bus command: --



The *ADJUST AXIS* softkey automatically adjusts the frequency axis of measurement diagram so that the start frequency matches the start frequency of the first sweep range, and the stop frequency of the last sweep range.
IEC/IEEE bus command: -- (via `FREQuency:STARt <num_value> / FREQuency:STOP <num_value>`)




The *STOP MEAS* softkey stops the measurement. The measurement data can be analyzed.
IEC/IEEE bus command: `ABORt`



Using the *START MEAS* softkey, you can start the measurement while the submenu is simultaneously exited.
When the measurement is started, the analyzer sets up the measurement diagram in the selected measurement window and starts the measurement in the selected mode.
With *SINGLE*, a single frequency sweep occurs; afterwards the analyzer remains on the stop frequency.
With *CONTINUOUS*, the measurement continues until it is stopped.
You can stop the measurement with *STOP SWEEP*.
If a *STOP AFTER SWEEP* point has been defined in the range, the sweep stops automatically at the end of the respective range to allow you to change the external circuitry, for example. This is indicated in a message box:
SWEEP Range# reached CONTINUE/BREAK
If *CONTINUE* is selected, the sweep is continued in the next range. If *BREAK* is selected, the sweep is stopped.
IEC/IEEE bus command: `INIT:SPUR` starts the measurement
`INIT:CONM` starts the measurement after a BREAK has been reached
`ABORt` stops the measurement after a range has


been reached



The *PEAK SEARCH* softkey starts the process of determining the list of the subrange maximums from the existing sweep results. This procedure can be repeated as often as desired, e.g. to experiment with the various threshold settings.

It is activated only after a measurement has been performed with *START MEAS*.


IEC/IEEE bus command `CALC:PEAK`



The *PEAKS PER RANGE* softkey activates entry of the number of peaks per range that are stored in the list. The value range extends from 1 to 50. Once the selected number of peaks has been reached, the peak search is stopped in the current range and continued in the next range.

IEC/IEEE bus command: `CALC:PEAK:SUBR 1...50`

Default: 25;



The *MARGIN* softkey activates entry of the margin, i.e. the acceptance threshold for determining the peak list. The limit line is shifted by this value when the maximums are determined. The value range extends from -200 dB to 200 dB.

IEC/IEEE bus command: `CALC:PEAK:MARG -200dB...200dB`

Default: 6 dB



The *VIEW PEAK LIST* softkey opens the submenu for viewing the peak list.


It is activated for display only after a *PEAK SEARCH* has been performed with *PEAK SEARCH*.

A delta limit of +200dB is listed if no limit check is active.

IEC/IEEE bus command: `TRACe? SPURious`


The table below shows a peak list after a *PEAK SEARCH*:

VIEW PEAK LIST			
TRACE / Detector	FREQUENCY	LEVEL dBm	DELTA LIMIT dB
1 RMS	80.0000 MHz	-36.02	-5.02
1 RMS	80.0001 MHz	-30.07	+0.24
1 RMS	85.1234 MHz	-30.02	-0.02
1 AVERAGE	130.234 MHz	-29.12	-5.12



The *SORT BY FREQUENCY* softkey sorts the table according to the entries in the *FREQUENCY* column in descending order.

IEC/IEEE bus command `--`



The *SORT BY DELTA LIM* softkey sorts the table according to the entries in the *DELTA LIM* column (default) in descending order. If no limit line has been specified, an offset of 200 dB is assumed for all peaks.

IEC/IEEE bus command: `--`



The *ASCII FILE EXPORT* softkey stores the peak list in ASCII format to a file on a diskette.

IEC/IEEE bus command: `MMEM:STOR:SPUR, 'A:\TEST.ASC'`


The file has a header containing important parameters for scaling, several data sections containing the sweep settings per range and a data section containing the peak list.

The header data is made up of three columns, separated by ';':
parameter name; numeric value; basic unit

The data section for the measurement values starts with the keyword "TRACE <n>:", where <n> includes the number of the used trace. Next comes the peak list with several columns also separated by ';':

Spreadsheet programs such as MS Excel can read this format. Use ';' as the delimiter for the table cells.

Note: *Different language versions of evaluation programs may require different handling of the decimal point. Using the DECIM SEP softkey, you can thus choose between the delimiters '.' (decimal point) and ',' (comma).*




In the case of floating-point numbers, use the *DECIM SEP* softkey to select between '.' (decimal point) and ',' (comma) as the decimal delimiter for the ASCII FILE EXPORT function.

By selecting the decimal delimiter, various language versions of evaluation programs (e.g. MS Excel) are supported.

IEC/IEEE bus command: FORM:DEXP:DSEP POIN


The ASCII export table is structured as shown below:

	File contents	Explanation
File header	Type;FSP; Version;3.90; Date;02.Aug 2004; Mode;ANALYZER; SPURIOUS; Start;9000.000000;Hz Stop;8000000000.000000;Hz x-Axis;LIN; Sweep Count;1;	Model Firmware version Storage date of data set Operating mode of the device Start/stop of the span Unit: Hz Linear (LIN) or logarithmic (LOG) (future feature) scaling of the x-axis Selected number of sweeps
File data section	TRACE 1: Trace Mode;CLR/WRITE; x-Unit;Hz; y-Unit;dBm; Margin;6.000000:s Values;8; 1;1548807257.5999999000;- 65.602280;-5.602280 1;1587207214.4000001000;- 65.327530;-5.327530 1;2112006624.0000000000;- 4.388008;55.611992	Selected trace Display mode of trace: CLR/WRITE,AVERAGE,MAX HOLD,MIN HOLD, VIEW, BLANK Unit of x values: Unit of y values: Peak List margin Number of measurement points Measurement values: <Trace>;<x value>; <y value>;<delta limit>




Using PAGE UP and PAGE DOWN, you can scroll forward and backward through the peak list pages.

They are active only as long as a peak list is displayed.



See above.



See above.

Menu MEAS – NEXT – HARMONIC DIST (Analyzer)

HARMONIC ON OFF
NO. OF HARMONICS
HARMONIC SWEEPTIME
HARMONIC RBW AUTO
ADJUST SETTINGS

The softkey *HARMONIC DISTORTION* opens this menu and activates the harmonic distortion measurement. With this measurement it is possible to measure easily the harmonics e.g. from a VCO. In addition the THD (total harmonic distortion) is calculated in % and dB.

There are 2 possible modes within the harmonic measurement. When entering the harmonic measurement from a frequency sweep (span > 0 Hz) an automatic search for the first harmonic is carried out within that given frequency range. Also a level adjust will be carried out. Is the zero span mode active before entering the harmonic measurement, the center frequency is unchanged.

IEC/IEEE-bus command:

```
:CALCulate:MARKer:FUNCTion:HARMonics:STATe ON | OFF
```

With the softkey *NO. OF HARMONICS* the number of harmonics which shall be measured can be adjusted. The range is from 1 to 26.

IEC/IEEE-bus command:

```
:CALCulate:MARKer:FUNCTion:HARMonics:NHARmonics  
<numerical value>
```

The *HARMONIC SWEEPTIME* softkey allows to set the value how long the zero span measurement on each harmonic frequency shall take place. This is an alias softkey to the normal sweep time of the zero span, therefore the same parser command is to be used.

In the upper screen the zero span sweeps on all harmonics are shown, separated by a grid line. This allows a very good overview about the measurement. In the lower screen the mean RMS results are displayed in numerical values and the THD values can be seen in the marker info field.

The resolution bandwidth will be automatically adjusted: $RBW_n = RBW_1 * n$, if that RBW is not available the next higher value is used. This feature can be disabled with the softkey *HARMONIC RBW AUTO*.

IEC/IEEE-bus command:

```
:CALCulate:MARKer:FUNCTion:HARMonics:BANDwidth:AUTO  
ON | OFF
```

With the adjust setting function the frequency search in the frequency range from before starting the harmonic measurement (if harmonic measurement was started from frequency sweep) and the level adjust can be activated.

IEC/IEEE-bus command:

```
:CALCulate:MARKer:FUNCTion:HARMonics:PRESet
```

The results can be obtained via IEC/IEEE-bus via the following commands: Trace read out via the normal trace subsystem. The first harmonic frequency can be read out via the center frequency command.

THD value comma separated in % and dB:

```
:CALCulate:MARKer:FUNCTion:HARMonics:DISToRTion? TOTal
```

Comma separated list of harmonic levels, for each harmonic one value:

```
:CALCulate:MARKer:FUNCTion:HARMonics:LIST?
```

Menu MEAS – STATISTICS – CCDF ON / APD ON – SCALING (Analyzer)



The softkey *Y-UNIT %/ABS* defines the scaling type on the y-axis. The default case are the absolute probability. This can be changed to percent values. The softkeys *Y-AXIS MIN* and *Y-AXIS MAX* are using values based on the *Y-UNIT* setting.

IEC/IEEE-bus command:

```
:CALC:STAT:SCAL:Y:UNIT PCT | ABS
```

The 0.1%, 1% and 10% value from the CCDF measurement are shown in the bottom screen half. Those values can also queried via remote:

IEC/IEEE-bus command:

```
:CALCulate<1|2>:STATistics:CCDF:X<1..4>? P0_1 | P1 | P10
```

Menu MKR - NEXT (Analyzer)



With the softkey *LINK MKR1 AND DELTA1* the delta marker1 can be linked to marker1, so if the x-axis value of the marker1 is changed the delta marker1 will follow on the same x-position. The link is default off, and can be switched on.

Example for setup:

- PRESET
- TRACE | MAX HOLD
- TRACE | SELECT TRACE | 2 | AVERAGE
- MKR (Switches marker1 on)
- MARKER NORM DELTA | DELTA (Delta Marker 1 ON)
- MKR-> | MKR->TRACE | 2
- LINK MKR1 AND DELTA1

Now select the Marker1 (by switching MARKER1 from DELTA back to NORM) and when changing the x-axis value (by knob wheel or UP/DOWN keys) the delta marker1 will follow automatically.

The delta marker1 x-value can not be changed away from 0 as long as the link functionality is active.

IEC/IEEE-bus command:

```
CALCulate<1|2>:DELTAmarker<1...4>:LINK ON | OFF
```

The suffix at *DELTAmarker* can only be 1 or not present, because the functionality is only available for marker1.

Menu MKR – NEXT – NEXT (Analyzer)

STEPSIZE
STANDARD

STEPSIZE
SPW POINTS

These softkeys control the knob increment/decrement of the marker position. STEPSIZE STANDARD uses the grid resolution (span/625), STEPSIZE SWP POINTS uses the available sweep points configured in the SWEEP menu.

IEC/IEEE-bus command:

CALC:MARK:X:SSIZE STANDARD | POINTS

MKR FILE
EXPORT

DECIM SEP

The MKR FILE EXPORT softkey stores the content of the active markers in ASCII format to the specified file.

IEC/IEEE-bus command: MMEM:STOR:MARK "filename"

“DECIM SEP” selects '.' or ',' as the decimal point.

Menu MKR→ – NEXT – NEXT (Analyzer)

AUTO MAX
PEAK

AUTO MIN
PEAK



AUTO MAX PEAK / AUTO MIN PEAK adds an automatic peak search action for marker 1 at the end of each particular sweep. This function may be used during adjustments of a device under test to keep track of the actual peak marker position and level. The actual marker search limit settings (*LEFT LIMIT*, *RIGHT LIMIT*, *THRESHOLD*, *EXCLUDE LO*) are taken into account.

IEC/IEEE-bus command:

CALCulate<1|2>:MARKer<1...4>:MAXimum:AUTO ON | OFF
CALCulate<1|2>:MARKer<1...4>:MINimum:AUTO ON | OFF

The suffix at MARKer is ignored.

Menu MKR FCTN (Analyzer)

N DB DOWN




The softkey *N DB DOWN* is now also available in zero span mode. The pulse width result (PWIDTH) is shown at the display.

IEC/IEEE-bus command:

```
:CALCulate<1|2>:MARKer<1..4>:FUNction:NDBDown:
STATe ON|OFF
//switches ndb down on or off
:CALCulate<1|2>:MARKer<1..4>:FUNction:NDBDown:RESult?
//queries the result pulse width
:CALCulate<1|2>:MARKer<1..4>:FUNction:NDBDown:TIME?
//queries the two marker x-values in seconds
separated by a comma
```

Menu MKR FCT - MARKER DEMOD - SQUELCH (Analyzer)



The *SQUELCH* softkey enables the input of a level threshold below which the audible AF is cut off. The squelch function is associated with the internal trigger function (TRIGGER menu), which will be switched on automatically with the squelch. Squelch level and trigger level do have the same value.

The default setting for the squelch is off.

IEC/IEEE-bus command:

```
:CALC:MARK1:FUNC:DEM:SQU ON | OFF
:CALC:MARK1:FUNC:DEM:SQU:LEV 80 PCT
```

Menu MKR FCTN – PHASE NOISE (Analyzer)



The phase noise *AUTO PEAK SEARCH* adds an automatic peak search action for the reference fixed marker 1 at the end of each particular sweep. This function may be used for tracking of a drifting source whilst phase noise measurement. The delta marker 2 which shows the phase noise measurement result keeps the delta frequency value. Therefore the phase noise measurement in a certain offset is valid although the source is drifting. Only when the marker 2 is reaching the border of the span the delta marker value is adjusted to be within the span. Choose a larger span in such situations.

IEC/IEEE-bus command:

```
CALCulate<1|2>:DELTamarker<1...4>:FUNCTION:PNOise:
AUTO ON | OFF
```

The suffix at DELTmarker is ignored.

Menu MKR FCTN – PEAK LIST (Analyzer)



The PEAK LIST EXPORT softkey stores the content of the marker peak list in ASCII format to the specified file.

IEC/IEEE-bus command: MMEM:STOR:PEAK "ilename"

“DECIM SEP” selects '.' or ',' as the decimal point.

Menu NETWORK with option R&S FSP-B9



The softkey *POWER SWP ON/OFF* activates or deactivates the power sweep. If the power sweep is ON the enhancement label TGPWR is shown and the analyzer is set in zero span mode (span = 0Hz). During the sweep time of the zero span the power at the internal tracking generator is changed linear from start power to stop power. The start and stop power values are shown on the right side below the diagram.

IEC/IEEE-bus command:

```
:SOUR:POW:MODE SWE
:SOUR:POW:MODE FIX
```



The softkey *START POWER* defines the start power of the power sweep.

The start power can be set between -30 and +0 dBm for the R&S FSP and between -30 dBm and +5 dBm for the R&S FSU. With the option FSU-B12 the power can be set between -100 and + 5 dBm.

IEC/IEEE-bus command:

:SOUR:POW:STAR -20dBm



The softkey *STOP POWER* defines the stop power of the power sweep.

The stop power can be set between -30 and +0 dBm for the R&S FSP and between -30 dBm and +5 dBm for the R&S FSU. With the option FSU-B12 the power can be set between -100 and + 5 dBm.

The stop value can be smaller than the start value.

IEC/IEEE-bus command:

:SOUR:POW:STOP -10dBm

Menu NETWORK with option R&S FSP-B10 – EXT SOURCE



Within the list of types of external generators the following R&S SMU models can be selected in addition: SMU02, SMU02B31, SMU03, SMU03B31, SMU04, SMU04B31, SMU06, SMU06B31.

Note:

There is a minimum version requirement of the R&S SMU firmware. Please install V1.10 or higher on the R&S SMU!

IEC/IEEE-bus command:

SYST:COMM:RDEV:GEN2:TYPE 'SMU03'



The *FREQUENCY SWEEP* softkey opens a table for setting the generator level as well as the multiplier and the offset used to derive the generator frequency from the analyzer frequency.

Since version 3.7x the external generator can also be used to sweep in the reverse direction. This can be achieved by setting a **negative** offset in the following formula:

$$F_{Generator} = \left| F_{Analyzer} * \frac{Numerator}{Denominator} + F_{Offset} \right|$$

Example for reverse sweep:

$$\begin{aligned} F_{AnalyzerStart} &= 100 \text{ MHz} \\ F_{AnalyzerStop} &= 200 \text{ MHz} \\ F_{Offset} &= -300 \text{ MHz} \\ Numerator = Denominator &= 1 \\ \rightarrow F_{GeneratorStart} &= 200 \text{ MHz} \\ \rightarrow F_{GeneratorStop} &= 100 \text{ MHz} \end{aligned}$$

If the offset is adjusted in a way that the sweep of the generator crosses the 0 Hz Frequency, it is indicated by the additional statement "via 0 Hz".


Example for reverse sweep via 0 Hz

$$\begin{aligned} F_{AnalyzerStart} &= 100 \text{ MHz} \\ F_{AnalyzerStop} &= 200 \text{ MHz} \\ F_{Offset} &= -150 \text{ MHz} \\ Numerator = Denominator &= 1 \\ \rightarrow F_{GeneratorStart} &= 50 \text{ MHz} \\ \rightarrow F_{GeneratorStop} &= 50 \text{ MHz via 0 Hz} \end{aligned}$$

IEC/IEEE-bus command:

```
SOUR:EXT:FREQ:NUM 1
SOUR:EXT:FREQ:DEN 1
SOUR:EXT:FREQ:OFFS -300MHZ
```

Menu NETWORK with option R&S FSP-B10



The *SOURCE POWER* softkey activates the input of the generator output level. The value range depends on the selected generator (See table of chapter "Configuration of the External Generator").

If both option External Generator Control FSP-B10 and option Tracking Generator B9 are installed, the softkey will modify the output power of the generator currently in use.

The default output power is -20 dBm.


IEC/IEEE-bus command: `SOUR:EXT:POW -20dBm`



The *GEN REF INT/EXT* softkey selects the reference signal for the external generator. Selection EXT allows connecting the external generator to an external reference frequency source. By default the external generator will use its internal frequency reference.

IEC/IEEE-bus command: `SOUR:EXT1:ROSC INT | EXT`


Menu TRACE (Receiver)



The *FINAL CISPR RMS* selects the weighting rms detector according to CISPR 16-1 for the final measurement.

IEC/IEEE bus command :DET:FME CRMS

Menu TRACE - NEXT (Analyzer)



The *HOLD CONT* softkey defines whether the traces in min hold and max hold mode are reset after some definite parameter changes.

- OFF The traces are reset after some definite parameter changes (default)
- ON This mechanism is switched off.


In general, parameter changes require a restart of the measurement before results are evaluated (e. g. with markers). For those changes that are known to require a new measurement (e. g. modification of the span), the trace is automatically reset so that erroneous evaluations of previous results are avoided.

This mechanism can be switched off for those exceptional cases where the described behavior is unwelcome.

IEC/IEEE-bus command

```
:DISPlay[:WINDow<1|2>]:TRACe<1..4>:MODE:HCON ON|OFF
```

Menu TRACE – NEXT (Analyzer)



The *AVG MODE* softkey selects logarithmic or linear averaging for the logarithmic level display mode.

At the same time the difference calculation is switched between linear and logarithmic in submenu *TRACE MATH*.

AVG MODE

The *AVG MODE* softkey selects logarithmic or linear averaging for the logarithmic level display mode.


At the same time the difference calculation is switched between linear and logarithmic in submenu *TRACE MATH*.

With logarithmic averaging, the dB values of the display voltage are averaged or subtracted from each other with trace mathematical functions. With linear averaging the level values in dB are converted into linear voltages or powers prior to averaging. Voltage or power values are averaged or offset against each other and reconverted into level values.

For stationary signals the two methods yield the same result.

Logarithmic averaging is recommended if sinewave signals are to be clearly visible against noise since with this type of averaging noise suppression is improved while the sinewave signals remain unchanged.

For noise or pseudo-noise signals the positive peak amplitudes are decreased in logarithmic averaging due the characteristic involved and the negative peak values are increased relative to the average value. If the distorted amplitude distribution is averaged, a value is obtained that is smaller than the actual average value. The difference is -2.5 dB.



This low average value is usually corrected in noise power measurements by a 2.5 dB factor. Therefore the FSG offers the selection of linear averaging. The trace data are delogarithmized prior to averaging, then averaged and logarithmized again for display on the screen. The average value is always correctly displayed irrespective of the signal characteristic.

Following selections are available:

- LOG: logarithmic averaging
- LIN linear averaging (delogarithmization depends on selected unit)
For units VOLT and AMPERE the level values are converted into linear voltages prior to averaging.
- POWER linear averaging (delogarithmization to power for all units)

Note: For correct power averaging with units VOLT or AMPERE, selection POWER has to be used.

IEC/IEEE-bus command `CALC:MATH:MODE LIN | LOG | POW`

Menu TRACE – DETECTOR – NEXT (Analyzer)





The *DETECTOR CISPR RMS* softkey activates the weighting detector according to a proposed amendment of CISPR 16-1-1 (CISPR/A/628/CD). The CISPR RMS average detector supplies a weighted reading of the input signal. When measuring the RMS-average according to the proposed amendment of CISPR 16-1-1, the maximum value of the RMS-average during the measurement time is displayed. The detector is used, for example, to measure pulsed sinusoidal signals with a low pulse repetition frequency. It is calibrated with the RMS value of an unmodulated sinusoidal signal. Averaging is with lowpass filters of the 2nd order (simulation of a mechanical instrument).

The *DETECTOR CISPR AVERAGE* softkey activates the weighting average detector according to CISPR 16-1-1. The CISPR average detector supplies a weighted average. When measuring the average according to CISPR 16-1-1, the maximum value of the linear average during the measurement time is displayed. The detector is used, for example, to measure pulsed sinusoidal signals with a low pulse repetition frequency. It is calibrated with the rms value of an unmodulated sinusoidal signal. Averaging is with lowpass filters of the 2nd order (simulation of a mechanical instrument).

Both softkeys are only available in zero span mode. The bandwidth is limited to the values 200Hz, 9kHz, 120kHz and 1 MHz. In order to use the normal bandwidths again, the detector must be changed e.g. AUTO SELECT.

IEC/IEEE-bus command:
 DETector<1|2> CRMS
 DETector<1|2> CAverage

Menu TRIG




With the softkey *EXTERN* the external trigger source can be selected. From firmware V2.60/3.60 on also the external trigger level can be adjusted in the range from 0.5V to 3.5V. The default value is 1.4V.

IEC/IEEE-bus command:
 :TRIGger[:SEquence]:LEVel[:EXternal] <numeric_value>

Menu TRIG - NEXT (Analyzer)




The *DELAY COMP ON/OFF* softkey enables the filter group delay compensation for the external trigger. If a bursted signal is analyzed in zero span and the delay compensation is on, a change of the RBW will not change the rising slope of the signal. Default is OFF.

IEC/IEEE-bus command:
 TRIG:HOLD:ADJ:AUTO <boolean>

Menu SETUP – NEXT



Softkey OPEN START MENU opens the windows XP start menu. and provides an easy access to standard windows functions if a mouse is connect.

IEC/IEEE-bus command: -

Menu SETUP - GENERAL SETUP - GPIB



The GPIB LANGUAGE softkey opens a list of selectable remote-control languages:
 SCPI, 8560E, 8561E, 8562E, 8563E, 8564E, 8565E, 8566A, 8566B, 8568A, 8568B, 8591E, 8594E, 71100C, 71200C, 71209A

Notes:


Selecting a language different from "SCPI" will set the GPIB address to 18 if it was 20 before.

Start / stop frequency, reference level and # of sweep points will be adapted to the selected instrument model.

IEC/IEEE-bus command:

```
SYST:LANG "SCPI" | "8560E" | "8561E" | "8562E" |
"8564E" | "8565E" | "8566A" | "8566B" | "8568A" |
"8568B" | "8591E" | "8594E" | "71100C" | "71200C" |
"71209A"
```

Menu SETUP - GENERAL SETUP - GPIB



Softkey SWEEP REP ON/OFF controls a repeated sweep of the commands E1 and MKPK HI. If the repeated sweep is OFF, the marker is set without sweeping before.

IEC/IEEE bus command: -

Menu SETUP - GENERAL SETUP - GPIB




Softkey COUPLING FSP/HP controls the default coupling ratios for for span and resolution bandwidth (Span/RBW) and for resolution bandwidth and video bandwidth (RBW/VBW) for the HP emulation mode. In case of FSP the standard parameter coupling of the instrument is used. As a result in most cases a shorter sweep time is used than in case of HP.

The softkey is only available in HP emulation mode.

IEC/IEEE bus command: SYSTem:HPCoupling FSP | HP

Menu SETUP – GENERAL SETUP - CONFIGURE NETWORK



COMPUTER NAME Softkey COMPUTERNAME opens a dialog to enter the computer name. The naming conventions of Windows apply. For further details refer to the *Quickstart Guide, Appendix B: LAN Interface*.

IP ADDRESS Softkey IP ADDRESS opens a dialog to configure the instrument's IP address. The TCP/IP protocol is preinstalled with the IP address 10.0.0.10. If the DHCP server is available (DHCP ON) the softkey is not available. For further details refer to the *Quickstart Guide, Appendix B: LAN Interface*.

SUBNET MASK Softkey SUBNET MASK opens a dialog to configure the instrument's TCP/IP subnet mask. The TCP/IP protocol is preinstalled with the subnet mask 255.255.255.0. The subnet mask consists of four number blocks separated by dots. Each block contain 3 numbers in maximum (e.g.100.100.100.100), but also one ore two numbers are allowed in a block (as an example see the preinstalled address). For further details refer to the *Quickstart Guide, Appendix B: LAN Interface*.

SHOW CONFIG Softkey SHOW CONFIG show the current network configuration.

NETWORK ADAPTER – CONFIGURATION	
DHCP	ON
COMPUTER NAME	MYINSTRUMENT
IP ADDRESS	10.114.10.235
NETMASK	255.255.0.0

Note: The Network Configuration softkeys above are available since Firmware Version 4.3x. Instruments shipped with Windows XP Service Pack1 require an additional installation package (LXI installer) if the softkeys are not visible. This installation package is available on the R&S instrument's download area.

The configuration via softkeys is only possible if the LAN is connected to the instrument.

CONFIGURE NETWORK

The CONFIGURE NETWORK softkey opens the windows dialog box with the network settings. The most important parameters are accessible by the softkeys COMPUTER NAME, IP ADDRESS, SUBNET MASK and DHCP ON/OFF.

Menu SETUP – SYSTEM INFO MEAS – STATISTICS

For new delivered devices the specifications version (document of the hardware properties) is shown. For already delivered device dashes (--.--) are displayed.

Menu SETUP - TRANSDUCER



When a transducer factor is used, the trace is moved by a calculated shift. However, an upward shift reduces the dynamic range for the displayed values. With the softkey REFLVL ADJ an automatic reference level offset adaptation allows to restore the original dynamic range by also shifting the reference level by the maximum value of the transducer factor.

IEC/IEEE-bus command:

```
[ :SENSe<1|2>: ]CORRection:TRANsducer:ADJust:
RLEVel[:STATE] ON | OFF
```

Note: Command `SENS:CORR:TRAN:SEL` or `SENS:CORR:TSET:SEL` has to be sent prior to this command

Hotkey RECEIVER, Menu MEAS (Receiver)

Fehler! Es ist nicht möglich, durch die Bearbeitung von Feldfunktionen Objekte zu erstellen.

RUN PRE-
SCAN+FINAL



The softkey *RUN PRESCAN+FINAL* is starting a sequence, consisting of a prescan, the peak search-function and the final measurement.

IEC/IEEE-bus command: `INITiate:EMITest`

CONTINUOUS
BAR GRAPH



The *CONTINUOUS BARGRAPH* softkey selects the continuous measurement mode.

IEC/IEEE-bus command: `INITiate:CONTInuous ON`

SINGLE
BAR GRAPH



Pressing the *SINGLE BARGRAPH* softkey triggers a single level measurement.

The enhancement label *SGL* displayed at the screen edge indicates that the single-measurement mode is set.

IEC/IEEE-bus command: `INITiate:CONTInuous OFF`

ADD TO
PEAK LIST



The *ADD TO PEAK LIST* softkey adds the current receiver frequency to the peak list (see also Section "Data Reduction and Peak List").

IEC/IEEE-bus command: `--`

Remote Control – VXI11 support

The VXI-11 channel is now also supported. To remote control the instrument via LAN beside RSIB also the TCPIP connection is possible.

Remote Control – Description of Commands – CALCulate:LIMit Subsystem

CALCulate<1|2>:LIMit<1...8>:CATalog?

This command queries all the names of the limit lines saved on the hard disc.

The syntax of the output is:

<sum of file length of all following files>,<free spaces on hard disc>,<1st file name>,<1st file length>,
<2nd file name>,<2nd file length>,<...>,<nth file name>,<nth file . length>

Example: " :CALC:LIM:CAT?"

Characteristics: *RST value: -
SCPI: device-specific

Mode: R, A

CALCulate<1|2>:LIMit<1...8>:ACTive?

This commands queries the names of all active limit lines. The numeric suffixes at CALCulate and LIMit are ignored. The list is sorted in alphabetic order. Any empty string is returned, if no limit line is active.

Example: " :CALC:LIM:ACT?"

Characteristics: *RST value : -
SCPI: device-specific

Remote Control – Description of Commands – CALCulate:PEAKsearch Subsystem

CALCulate:PEAKsearch:ADD <numeric_value>

This command adds a frequency value to the peaklist in receiver mode. (RECEIVER – FINAL MEAS – EDIT PEAK LIST). Only frequencies in the currently displayed frequency range of the receiver scan are allowed.

Example: "CALC:PEAK:ADD 93 MHZ"
'The frequency 93 MHz as added to the peak list

Characteristics: *RST value: -
SCPI: device-specific

Mode: R

CALCulate:PEAKsearch:CLEar[:IMMEDIATE]

The peaklist in receiver mode (RECEIVER – FINAL MEAS – EDIT PEAK LIST) is cleared.


Example: "CALC:PEAK:CLE"
'The peak list is cleared

Characteristics: *RST value: -
SCPI: device-specific

Mode: R

Remote Control – Description of Commands – INITiate Subsystem

Controlling a scan in Receiver Mode.



Remote Control – Description of Commands – MMEMory Subsystem

MMEMory:CATalog:LONG? <path>

This command queries the directories and files in the given path.

Parameter: <path>::= DOS path

Example: "MMEM:CAT:LONG? 'D:\USER\DATA' 'queries the contents of directory D:\USER\DATA

Return value: <used_bytes_in_this_directory>,<free_bytes_on_this_disk>,
 "<file_name>,<file_type>,<filesize_in_bytes>",
 "<file_name>,<file_type>,<filesize_in_bytes>", ...

with

<file_name>

name of file or directory

<file_type>

file type: DIR (directory), ASCII (ASCII file),

BINARY (binary file) and STATE (file with device settings)

<filesize_in_bytes>

size of file, 0 for directories

Remote Control – Description of Commands – SENSE:CORRection Subsystem

[SENSe<1|2>:]CORRection:TRANsducer:CATalog?

This command reads out the names of all transducer factors stored on the internal drive.

Syntax of output format:

<Sum of file lengths of all subsequent files>,<free memory on hard disk>,
<1st file name>,<1st file length>,<2nd file name>,<2nd file length>.....,<nth file name>,
<nth file length>

Example: "CORR:TRAN:CAT?"

Characteristics: *RST value: -
SCPI: device-specific

Mode: R, A

[SENSe<1|2>:]CORRection:TSET:CATalog?

This command reads out the names of all transducer sets stored on the internal drive.

Syntax of output format:

<Sum of file lengths of all subsequent files>,<free memory on hard disk>,
<1st file name>,<1st file length>,<2nd file name>,<2nd file length>.....,<nth file name>,
<nth file length>

Example: "CORR:TSET:CAT?"

Characteristics: *RST value: -
SCPI: device-specific

Mode: R, A

[SENSe<1|2>:]CORRection:TRANsducer:ACTive?

This command queries the active transducer factor. Any empty string is returned, if no transducer factor is active.

Example: ":CORR:TRAN:ACT?"

Characteristics: *RST value : -
SCPI: device-specific

Mode: R, A

Remote Control – Description of Commands – SENSE:LIST Subsystem

[SENSE<1|2>:]LIST:POWER:SET:AVERAGE:TYPE LINear | LOGarithmic

With this command the average type of the sense list measurement can be set either to linear (default) or logarithmic. In linear mode voltages are averaged in logarithmic mode levels.

Example: "LIST:POW:SET:AVER LOG" 'sets log averaging for list measurement.

[SENSE<1|2>:]LIST:POWER[:SEQUence] <analyzer freq>,<ref level>,<rf att>,<el att>,<filter type>,<rbw>,<vbw>,<meas time>,<trigger level>,...

The LIST:POW command supports now the following filter types:

<filter type>:	NORMAL:	normal resolution filter
	CFILter:	channel filter. These are especially steep-edged filters, which are used for example in Fast ACP measurement to ensure the band-limiting of a transmission channel in the time domain.
	RRC:	Root Raised Cosine filter. This special filter form is used to determine the channel power for some mobile radio standards.

For allowed <rbw> setting for <filter type> = CFILter and <filter type> = RRC see table "List of available channel filters" in section "Setting Bandwidths and Sweep Time – Key BW".

Remote Control – Description of Commands – SENSE:MPOWER Subsystem

[SENSE<1|2>:]MPOWER[:SEQUence] <analyzer freq>,<rbw>,<meas time>,<trigger source>,<trigger level>,<trigger offset>,<type of meas>,<# of meas>

For MPOW also the RRC and CFILter can be used by defining the filter type with the command: [SENSE<1|2>:]BANDwidth|BWIDth[:RESolution]:TYPE NORMAL | FFT | CFILter | RRC

before using the MPOW command.

Remote Control – Description of Commands – SENSE:SWEep Subsystem

[SENSE<1|2>:]SWEep:COUNt:CURRent?

This query command returns the current number of started sweeps. A sweep count value should be set and the device should be in single sweep mode.

Example:	"SWE:COUNt 64"	'sets sweep count to 64
	"INIT:CONT OFF"	'switches to single sweep mode
	"INIT"	'starts a sweep (without waiting for the sweep end!)
	"SWE:COUN:CURR?"	'queries the number of started sweeps

Remote Control – Description of Commands – SYSTEM Subsystem

SYSTEM:IDENTify:FACTory

With this command it is possible to reset the *IDN string to the factory default (Softkey: ID STRING FACTORY).

Example: " :SYST:IDEN:FACT?"

Remote Control – Description of Commands – SYSTem:COMMunicate Subsystem

SYSTem:COMMunicate:GPIB:RDEvice:COMManD 0..30,<command string>

This command sends a command or query string to the device using the GPIB interface FSP-B10. Usually an external generator is connected to this interface.

Note: Only basic I/O is possible with this device. The first parameter is the GPIB address of the device connected with GPIB interface of option FSP-B10.

Example:

```

":SYST:COMM:GPIB:RDEF:COMM 18, '*RST'"      ' generator reset
                                           ' gen. frequency 2 GHz
":SYST:COMM:GPIB:RDEF:COMM 18, 'SOURCE:FREQ:CW 2E9' "
                                           ' gen. power 0dBm
":SYST:COMM:GPIB:RDEF:COMM 18, 'SOUR:POW 0'"
":SYST:COMM:GPIB:RDEF:COMM? 18, 'SENS:POW?' "
                                           'queries the generator power

```

Characteristics: *RST value: -
SCPI: device-specific

Remote Control – Description of Commands – TRACe Subsystem

TRACe:POINts LIMit, 1 to 10000

This command defines the maximum number of measurement points which are transferred in one block after the query command `TRACe? SCAN`. The total amount of bytes which is transferred depends on the number of active traces.

Example:

```

"TRAC:POIN LIM, 8000"
'A maximum of 8000 measurement values per trace will be transferred with a single
'query

```

Characteristics: *RST value: 1000
SCPI: device-specific

Mode: R

TRACe<trace #>:IMMEDIATE:LEVEL? and TRACe<trace #>:IMMEDIATE:RESULT?

These query command returns instantaneous measurement results. During a sweep which shall not have a synchronization on the sweep end last measured value can be read out. This makes sense if measurement values shall be obeyed during long sweep times. The `LEVEL?` command only returns the level, where the `RESULT?` command returns comma separated the x and y value. For a better time resolution the number of sweep points can be increased.

Example:	"INIT:CONT OFF"	'switches to single sweep mode
	"INIT"	'starts a sweep (without waiting for the sweep end!)
	"TRAC1:IMM:LEV?"	'queries the level of the last measured measurement point

Supported 85xx-commands

85xx - command	Modification	Description
AMB ON OFF		Trace A minus B
ADJALL		Adjust all
ADJCRT	1)	Adjust CRT
ADJIF	1)	Auto adjust IF
APB		Trace A plus B
AUTOCPPL		Coupling default
AXB		Exchange trace A and B
BL, BML		B - display line --> B
BTC		Transfer B to C
BXC		Exchange B and C
CHNPWR		Channel power
CHPWRBW		Channel power bandwidth
COUPLE AC DC		Select input coupling
D1	1)	Display size normal
DA	1)	Display address
DEMODAGC	1)	Demodulation AGC
DEMODT		Demodulation time
DLE		Display line enable
DW	1)	Write to display and increment address
ERR	Now some errors are mapped to HP errors: ERR 250 cal level error ERR 300 LO unlock ERR 472 cal error digital filter ERR 473 cal error analog filter ERR 552 cal error log amp ERR 902 unscale tracking generator ERR 906 oven cold ERR117 numeric unit error ERR112 Unrecognized Command	Error
ERR?		Erases the error bit in the status register but always returns 0.
EX		Exchange trace A and B
FREF		Reference frequency internal/external
FUNCDEF		Define Function Function must be in one line between delimiters @
GRAT ON OFF	1)	Grid on/off
KEYDEF		Key definition
KEYEXEC		Key execute
KS(Lock registers
KS)		Unlock registers
KS91		Read amplitude error
KS/	1)	Manual peaking
KSK		Marker to next peak

¹⁾ Command accepted, but ignored

85xx - command	Modification	Description
KSO		Delta marker to span
KSQ		Band lock off
KSG		CRT beam off
KSh		CRT beam on
KSn	1)	Grid on
KSo		Character display off
KSp		Character display on
KSr		Create service request
KSt		Band lock on
KSV		Signal ident on
L0		Display line off
LB		Label
LF		Preset with low frequency band selection
LL	1)	Cursor to lower left corner
M3	M3 M3 <numeric_value> HZ KHZ MHZ GHZ M3 DN M3 UP M3?	Default value value range step size. Noise measurement activated with KSM is automatically switched off with any M3- command..
MDS		Measurement data size
MKA		Marker amplitude
MKDR		Delta Marker reverse
MKDR?		Delta marker reverse query
MKFC ON/OFF		Marker frequency count
MKP		Marker position
MKPT	MKPT MKPT HI MKPT NH MKPT NR MKPT NL	
MKSP		Deltamarker to span
MKT		Marker to time point
MKTYPE AMP		Marker type
NORMALIZE		Normalize trace
NRPOS		Normalize trace position
O2		Trace readout
OT	OT after CF or SP now returns Center/Span values rather than Start/Stop string 27 now indicates the current sweep status	Output annotations
PA	1)	Plot absolute
PD	1)	Pen down
PLOTORG	1)	Plot origin
PLOTSRC	1)	Plot source
PWRBW		Power Bandwidth
PRINT	accept numeric parameter	Print
PSDAC	1)	Preselector DAC
PSTATE	1)	Protect state
PU	1)	Pen up
RBR		Resolution bandwidth/span ratio
RLCAL	1)	Reference level cal
RCLOSCAL		Recall open/short reference trace into trace B, set instrument to the stored open/short reference state.

¹⁾ Command accepted, but ignored

85xx - command	Modification	Description
RCLT TRA TRB, <number>		Recall Trace Data
RCLTHRU		Recall the thru-reference trace into trace B, set instrument to stored thru-reference state.
SAVET TRA TRB, <number>		Save Trace Data
SMOOTH		Smooth trace
SQUELCH	1)	Squelch
STOREOPEN		Set open/short reference
STORESHORT		Set open/short reference
STORETHRU		Set thru reference
SWPCPL SA SR	1)	
SWPOUT	1)	Sweep Output
T2	1)	Line trigger
TACL?, TBCL?, TCCL?		Returns instantaneous measurement results. See TRACe<trace #>:IMMEDIATE:LEVel? for full description.
TACR?, TBCR?, TCCR?		Returns instantaneous measurement results. See TRACe<trace #>:IMMEDIATE:RESult? for full description.
TDF	Parameters: P Meas Unit, like dBm, V etc. (already supported) M Display Unit B Binary A Binary with length I Binary without length	Trace data format
THE		Threshold enable
TM LINE	1)	Trigger Line
TRSTAT		The TRSTAT command returns trace states to the controller: clear-write, off, view, or blank.
UR	1)	Cursor to upper right corner
OA		
OT		
RESET		
REV?		
TRA/TRB	Trace input in the following format: B Binary data without header A Binary data with length I Binary data without length	
TRA?		
TRB?		
TDF	TDF P	
VARDEF		Variable definition, Command ignored
VTL		Video trigger level

¹⁾ Command accepted, but ignored

Model dependent default settings

When selecting a 85xx model language the GPIB address will be automatically set to 18, if the FSP default address (20) is active. Other values than 20 will be left unchanged. On return to GPIB language SCPI the current GPIB address will be preserved.

The following table shows the default settings which will be set when selecting the GPIB language or when using the commands IP, KST and RESET.

Model	# of Trace Points	Start Freq.	Stop Freq.	Ref Level	Input Coupling
8566A/B	1001	2 GHz	22 GHz	0 dBm	DC (FSU) AC (FSP)
8568A/B	1001	0 Hz	1.5 GHz	0 dBm	AC
8560E	601	0 Hz	2.9 GHz	0 dBm	AC
8561E	601	0 Hz	6.5 GHz	0 dBm	AC
8562E	601	0 Hz	13.2 GHz	0 dBm	AC
8563E	601	0 Hz	26.5 GHz	0 dBm	AC
8564E	601	0 Hz	40 GHz	0 dBm	AC
8565E	601	0 Hz	50 GHz	0 dBm	AC
8594E	401	0 Hz	3 GHz	0 dBm	AC

Note on selected stop frequency:

The stop frequency indicated in the table will be limited by the maximum stop frequency of the analyzer.

Note on the selected number of trace points:

The adaptation of the number of trace points will only be performed on the LOCAL -> REMOTE transition.

Trace data output formats

Two formats are supported for trace data output: display units (command O1) and physical values (commands O3 or TDF P). With format "display units" the level data will be converted into value range and resolution of the 8566/8568 models. On transition to REMOTE state the number of trace points will be reconfigured in order to be conforming to the selected instrument model (1001 for 8566A/B and 8568 A/B, 601 for 8560E to 8565E, 401 for 8594E).

GPIB status reporting system

The assignment of the status bits performed by commands R1, R2, R3, R4, RQS is supported since firmware V1.80. Commands STB and a serial poll on the GPIB will return an 8 bit value with the following bit assignment:


Bit enabled by RQS
1 (Units key pressed)
2 (End of Sweep)
3 (Device Error)
4 (Command Complete)
5 (Illegal Command)
6 (Service Request)

Bits 0 and 7 are unused and always set to 0.

Please note that the FSP reports any key pressed on the front panel rather than only the unit keys if bit 1 was enabled.

Another difference is the behavior of bit 6 when using the STB? query. On the HP analyzers this bit monitors the state of the SRQ line on the bus. On the FSP this is not possible. Therefore this bit is set, as soon as one of the bits 1 to 5 is set. It won't be reset by performing a serial poll.

HIGH PASS AF FILTER



The 25 HZ, 50 HZ and 300 HZ softkeys switch on a high pass filter with the given limit to separate the DC component. The filters are indicated by the 3 dB cutoff frequency. The 50 Hz and 300 Hz filters are designed as 2nd-order Butterworth filter (12 dB/octave). The 20 Hz filter is designed as 3rd-order Butterworth filter (18 dB/octave).

The *NONE* softkey deactivates the AF high pass filter. Default is *NONE*.

The high pass filter are active in the following demodulation bandwidth range:

20 Hz	100 Hz ≤ demodulation bandwidth ≤ 1.6 MHz
50 Hz	200 Hz ≤ demodulation bandwidth ≤ 3 MHz
300 Hz	800 Hz ≤ demodulation bandwidth ≤ 8 MHz

IEC/IEEE-bus command:

```
[SENSe:]FILTeR:HPASs[:STATe] ON | OFF
[SENSe:]FILTeR:HPASs:FREQuency 20 Hz | 50 Hz | 300 Hz
```

LOW PASS AF FILTER



The 5 %, 10% and 25% HZ softkeys switch on a relative low pass filter. The filter (3 dB) can be selected in % of the demodulation bandwidth. The filters are designed as 5th-order Butterworth filter (30 dB/octave).

The 3 KHZ, 15 KHZ, 23 KHZ and 150 KHZ softkeys switch on a absolute low pass filter. The filter are indicated by the 3 dB cutoff frequency. The 3 kHz, 15 kHz and 23 kHz filters are designed as 5th-order Butterworth filter (30 dB/octave). The 150 kHz filter is designed as 8th-order Butterworth filter (48 dB/octave).

The *NONE* softkey deactivates the AF low pass filter. Default is *NONE*.


The relative low pass filters are active for all demodulation bandwidth's. The absolute low pass filters are active in the following demodulation bandwidth range:

3 kHz	6.4 kHz ≤ demodulation bandwidth ≤ 3 MHz
15 kHz	50 kHz ≤ demodulation bandwidth ≤ 8 MHz
23 kHz	50 kHz ≤ demodulation bandwidth ≤ 8 MHz
150 kHz	400 kHz ≤ demodulation bandwidth ≤ 8 MHz

IEC/IEEE-bus command:

```
[SENSe:]FILTeR:LPASs[:STATe] ON | OFF
[SENSe:]FILTeR:LPASs:FREQuency:RELAtive 5 | 10 | 25
[SENSe:]FILTeR:LPASs:FREQuency 3 kHz | 15 kHz |
23 kHz | 150 kHz
```

DEEMPHASIS



The *25 us*, *50 us*, *75 us* and *750 us* softkeys switch on a de-emphasis with the given time constant.
 The *NONE* softkey deactivates the de-emphasis. Default is *NONE*.

The de-emphasis is active in the following demodulation bandwidth range:

- 25 μ s 25 kHz \leq demodulation bandwidth \leq 30 MHz
- 50 μ s 6.4 kHz \leq demodulation bandwidth \leq 18 MHz
- 75 μ s 6.4 kHz \leq demodulation bandwidth \leq 18 MHz
- 750 μ s 800 Hz \leq demodulation bandwidth \leq 3 MHz

The following table shows the required demodulation bandwidth for an error less than 0.5 dB up to a maximum AF frequency.


Deemphasis	25 μ s	50 μ s	75 μ s	750 μ s
Maximum AF Frequency	25 kHz	12 kHz	8 kHz	800 Hz
Required demodulation bandwidth	\geq 200 kHz	\geq 100 kHz	\geq 50 kHz	\geq 6.4 kHz

For higher AF frequencies the demodulation bandwidth must be increased.

IEC/IEEE-bus command:

```
[SENSe:]FILTeR:DEMPHasis[:STATe] ON | OFF
[SENSe:]FILTeR:DEMPHasis:TCONstant 25 us | 50 us |
                                         75 us | 750 us
```

WEIGHTING AF FILTER



The *CCITT* (CCITT P.53) and *CCIR* (CCIR unweighted) softkeys switch on a weighting filter. The *CCIR* unweighted filter is the combination of the 20 Hz highpass and 23 kHz lowpass filter.

The *NONE* softkey deactivates the weighting filter. Default is *NONE*.


The weighting filter are active in the following demodulation bandwidth range:

- CCITT 25 kHz \leq demodulation bandwidth \leq 3 MHz
- CCIR 50 kHz \leq demodulation bandwidth \leq 1.6 MHz

IEC/IEEE-bus command:

```
[SENSe:]FILTeR:CCITt[:STATe] ON | OFF
[SENSe:]FILTeR:CCIR[:STATe] ON | OFF
```

Menu FM DEMOD - RANGE - UNIT



The *THD UNIT %/DB* softkey selects between % and dB for displaying the THD measurement result.

```
IEC/IEEE bus command:      UNIT:THD PCT | DB
```

The FS-K7 has been extended about the AM result display. With active FM demodulator (ADEM ON or INST:SEL ADEM) the AM evaluation can be activated with the command CALC:FEED 'XTIM:AM:REL'. The settings and measurement result queries are similar as in the FM evaluation. The diagram scaling is in the unit % instead of Hz.

command for FM

```
CALC:FEED 'XTIM:FM'
CALC:FEED 'XTIM:FMS'
CALC:FEED 'XTIM:FM:AFSP'
CALC:MARK:FUNC:ADEM:FM:RES
ADEM:FM:TYPE
ADEM:FM:RES
TRIG:SOUR FM
TRIG:LEV:FM
```

command for AM

```
CALC:FEED 'XTIM:AM:REL'
CALC:FEED 'XTIM:AMS:REL'
CALC:FEED 'XTIM:AM:REL:AFSP'
CALC:MARK:FUNC:ADEM:AM:RES
ADEM:AM:REL:TYPE
ADEM:AM:REL:RES
TRIG:SOUR AMR
TRIG:LEV:AM:REL
```

The other commands of the AM evaluation are identical to the FM evaluation. In addition to the FM evaluation the modulation depth of AM modulated signals can be queried with CALC:MARK:FUNC:MDEP:RES?.

The PM demodulation has been extended about the following new functions:



The *ZERO PHASE REF POINT* softkey activates the input of the reference point, where the phase is set to 0 rad.

IEC/IEEE-bus command: SENS:ADEM:PM:RPO:X 10us



The *PHASE WRAP ON/OFF* softkey activates the phase wrapping to $-\pi \dots +\pi$ ($-180^\circ \dots +180^\circ$).

IEC/IEEE-bus command: CALC:FORM PHAS | UPH



The *PM UNIT RAD/DEG* softkey selects the unit for PM traces.

IEC/IEEE-bus command: UNIT:ANGL RAD | DEG

The range of the demodulation bandwidth has been extended down to 100 Hz.

new demodulation bandwidth	sampling rate
6.4 kHz	7.8125 kHz
3.2 kHz	3.90625 kHz
1.6 kHz	1.953125 kHz
800 Hz	976.5625 Hz
400 Hz	488.28125 Hz
200 Hz	244.140625 Hz
100 Hz	122.0703125 Hz

Information to Demod BW 8 MHz:

This filter is only flat for about 6 MHz, it has a 3dB decay at 7 MHz.

Appendix: Contact to our hotline

Any questions or ideas concerning the instrument are welcome by our hotline:

USA & Canada

Monday to Friday (except US public holidays)
8:00 AM – 8:00 PM Eastern Standard Time (EST)
Tel. from USA 888-test-rsa (888-837-8772) (opt 2)
From outside USA +1 410 910 7800 (opt 2)
Fax +1 410 910 7801
E-mail Customer.Support@rsa.rohde-schwarz.com

East Asia

Monday to Friday (except Singaporean public holidays)
8:30 AM – 6:00 PM Singapore Time (SGT)
Tel. +65 6 513 0488
Fax + 65 6 846 1090
E-mail Customersupport.asia@rohde-schwarz.com

Rest of the World

Monday to Friday (except German public holidays)
08:00 – 17:00 Central European Time (CET)
Tel. from Europe +49 (0) 180 512 42 42
From outside Europe +49 89 4129 13776
Fax +49 (0) 89 41 29 637 78
E-mail CustomerSupport@rohde-schwarz.com