


R&S® FSV-K10

Firmware Option GSM Measurement

Operating Manual



1173.0689.02 – 07.1

This manual describes the following options:

- R&S FSV-K10 (1310.8055.02)

The contents of this manual correspond to the following R&S®FSVR models with firmware version 1.56 or higher:

- R&S®FSVR7 (1311.0006K7)
- R&S®FSVR13 (1311.0006K13)
- R&S®FSVR30 (1311.0006K30)
- R&S®FSVR40 (1311.0006K40)

The firmware of the instrument makes use of several valuable open source software packages. The most important of them are listed below together with their corresponding open source license. The verbatim license texts are provided on the user documentation CD-ROM (included in delivery).

Package	Link	License
OpenSSL	http://www.openssl.org	OpenSSL/SSLLeavy
Xitami	http://www.xitami.com	2.5b6
PHP	http://www.php.net	PHP v.3
DOJO-AJAX	http://www.dojotoolkit.org	Academic Free License (BSD)
ResizableLib	http://www.geocities.com/ppescher	Artistic License
BOOST Library	http://www.boost.org	Boost Software v.1
ONC/RPC	http://www.plt.rwth-aachen.de/index.php?id=258	SUN

The product Open SSL includes cryptographic software written by Eric Young (eay@cryptsoft.com) and software written by Tim Hudson (tjh@cryptsoft.com).

Rohde & Schwarz would like to thank the open source community for their valuable contribution to embedded computing.

© 2011 Rohde & Schwarz GmbH & Co. KG

Muehldorfstr. 15, 81671 Munich, Germany

Phone: +49 89 41 29 - 0

Fax: +49 89 41 29 12 164

E-mail: info@rohde-schwarz.com

Internet: <http://www.rohde-schwarz.com>

Printed in Germany – Subject to change – Data without tolerance limits is not binding.

R&S® is a registered trademark of Rohde & Schwarz GmbH & Co. KG.

Trade names are trademarks of the owners.

The following abbreviations are used throughout this manual: R&S®FSV is abbreviated as R&S FSV. R&S®FSVR is abbreviated as R&S FSVR.

Contents

1	Preface	5
1.1	Documentation Overview.....	5
1.2	Conventions Used in the Documentation.....	7
1.3	How to Use the Help System.....	8
2	Introduction	10
3	Instrument Functions GSM	11
3.1	Measurements and Result Displays.....	12
3.2	Further Information.....	31
3.3	Softkeys and Settings of the GSM Menu.....	54
3.4	FREQ Key.....	86
3.5	AMPT Key.....	86
3.6	AUTO SET Key.....	86
3.7	SWEEP Key.....	86
3.8	TRACE Key.....	86
3.9	TRIG Key.....	87
3.10	Softkeys of the Marker Menu – MKR Key.....	87
3.11	Softkeys of the Marker to Menu – MKR-> Key.....	88
3.12	Softkeys of the Input/Output Menu.....	89
4	Remote Commands (GSM)	91
4.1	Notation.....	91
4.2	ABORt Subsystem.....	94
4.3	CALCulate Subsystem.....	94
4.4	CONFigure Subsystem.....	104
4.5	DISPlay Subsystem.....	149
4.6	FETCh Subsystem.....	152
4.7	INITiate Subsystem.....	188
4.8	INPut Subsystem.....	189
4.9	INSTrument Subsystem.....	193
4.10	MMEMory Subsystem.....	194
4.11	READ Subsystem.....	196

4.12	SENSe Subsystem.....	236
4.13	STATus Subsystem.....	239
4.14	TRACe Subsystem.....	241
4.15	TRIGger Subsystem.....	243
5	Status Reporting System.....	248
	List of Commands.....	251
	Index.....	258

1 Preface

1.1 Documentation Overview

The user documentation for the R&S FSVR is divided as follows:

- Quick Start Guide
- Operating Manuals for base unit and options
- Service Manual
- Online Help
- Release Notes

Quick Start Guide

This manual is delivered with the instrument in printed form and in PDF format on the CD. It provides the information needed to set up and start working with the instrument. Basic operations and basic measurements are described. Also a brief introduction to remote control is given. The manual includes general information (e.g. Safety Instructions) and the following chapters:

Chapter 1	Introduction, General information
Chapter 2	Front and Rear Panel
Chapter 3	Preparing for Use
Chapter 4	Firmware Update and Installation of Firmware Options
Chapter 5	Basic Operations
Chapter 6	Basic Measurement Examples
Chapter 7	Brief Introduction to Remote Control
Appendix 1	Printer Interface
Appendix 2	LAN Interface

Operating Manuals

The Operating Manuals are a supplement to the Quick Start Guide. Operating Manuals are provided for the base unit and each additional (software) option.

The Operating Manual for the base unit provides basic information on operating the R&S FSVR in general, and the "Spectrum" mode in particular. Furthermore, the software options that enhance the basic functionality for various measurement modes are described here. The set of measurement examples in the Quick Start Guide is expanded by more advanced measurement examples. In addition to the brief introduction to remote control in the Quick Start Guide, a description of the basic analyzer commands and programming examples is given. Information on maintenance, instrument interfaces and error messages is also provided.

In the individual option manuals, the specific instrument functions of the option are described in detail. For additional information on default settings and parameters, refer to the data sheets. Basic information on operating the R&S FSVR is not included in the option manuals.

The following Operating Manuals are available for the R&S FSVR:

- R&S FSVR base unit; in addition:
 - R&S FSV-K7S Stereo FM Measurements
 - R&S FSV-K9 Power Sensor Support
 - R&S FSV-K14 Spectrogram Measurement
- R&S FSV-K10 GSM/EDGE Measurement
- R&S FSV-K30 Noise Figure Measurement
- R&S FSV-K40 Phase Noise Measurement
- R&S FSV-K70 Vector Signal Analysis Operating Manual
R&S FSV-K70 Vector Signal Analysis Getting Started (First measurements)
- R&S FSV-K72 3GPP FDD BTS Analysis
- R&S FSV-K73 3GPP FDD UE Analysis
- R&S FSV-K76/77 3GPP TD-SCDMA BTS/UE Measurement
- R&S FSV-K82/83 CDMA2000 BTS/MS Analysis
- R&S FSV-K84/85 1xEV-DO BTS/MS Analysis
- R&S FSV-K91 WLAN IEEE 802.11a/b/g/j/n
- R&S FSV-K93 WiMAX IEEE 802.16 OFDM/OFDMA Analysis
- R&S FSV-K100/K104 EUTRA / LTE Downlink Measurement Application
- R&S FSV-K101/K105 EUTRA / LTE Uplink Measurement Application

These manuals are available in PDF format on the CD delivered with the instrument. The printed manual can be ordered from Rohde & Schwarz GmbH & Co. KG.

Service Manual

This manual is available in PDF format on the CD delivered with the instrument. It describes how to check compliance with rated specifications, instrument function, repair, troubleshooting and fault elimination. It contains all information required for repairing the R&S FSVR by replacing modules. The manual includes the following chapters:

Chapter 1	Performance Test
Chapter 2	Adjustment
Chapter 3	Repair
Chapter 4	Software Update / Installing Options
Chapter 5	Documents

Online Help

The online help contains context-specific help on operating the R&S FSVR and all available options. It describes both manual and remote operation. The online help is installed

on the R&S FSVR by default, and is also available as an executable .chm file on the CD delivered with the instrument.

Release Notes

The release notes describe the installation of the firmware, new and modified functions, eliminated problems, and last minute changes to the documentation. The corresponding firmware version is indicated on the title page of the release notes. The current release notes are provided in the Internet.

1.2 Conventions Used in the Documentation

1.2.1 Typographical Conventions

The following text markers are used throughout this documentation:

Convention	Description
"Graphical user interface elements"	All names of graphical user interface elements on the screen, such as dialog boxes, menus, options, buttons, and softkeys are enclosed by quotation marks.
KEYS	Key names are written in capital letters.
File names, commands, program code	File names, commands, coding samples and screen output are distinguished by their font.
<i>Input</i>	Input to be entered by the user is displayed in italics.
Links	Links that you can click are displayed in blue font.
"References"	References to other parts of the documentation are enclosed by quotation marks.

1.2.2 Conventions for Procedure Descriptions

When describing how to operate the instrument, several alternative methods may be available to perform the same task. In this case, the procedure using the touch screen is described. Any elements that can be activated by touching can also be clicked using an additionally connected mouse. The alternative procedure using the keys on the instrument or the on-screen keyboard is only described if it deviates from the standard operating procedures.

The term "select" may refer to any of the described methods, i.e. using a finger on the touchscreen, a mouse pointer in the display, or a key on the instrument or on a keyboard.

1.3 How to Use the Help System

Calling context-sensitive and general help

- ▶ To display the general help dialog box, press the HELP key on the front panel.
The help dialog box "View" tab is displayed. A topic containing information about the current menu or the currently opened dialog box and its function is displayed.



For standard Windows dialog boxes (e.g. File Properties, Print dialog etc.), no context-sensitive help is available.

- ▶ If the help is already displayed, press the softkey for which you want to display help.
A topic containing information about the softkey and its function is displayed.



If a softkey opens a submenu and you press the softkey a second time, the submenu of the softkey is displayed.

Contents of the help dialog box

The help dialog box contains four tabs:

- "Contents" - contains a table of help contents
- "View" - contains a specific help topic
- "Index" - contains index entries to search for help topics
- "Zoom" - contains zoom functions for the help display

To change between these tabs, press the tab on the touchscreen.

Navigating in the table of contents

- To move through the displayed contents entries, use the UP ARROW and DOWN ARROW keys. Entries that contain further entries are marked with a plus sign.
- To display a help topic, press the ENTER key. The "View" tab with the corresponding help topic is displayed.
- To change to the next tab, press the tab on the touchscreen.

Navigating in the help topics

- To scroll through a page, use the rotary knob or the UP ARROW and DOWN ARROW keys.
- To jump to the linked topic, press the link text on the touchscreen.

Searching for a topic

1. Change to the "Index" tab.

2. Enter the first characters of the topic you are interested in. The entries starting with these characters are displayed.
3. Change the focus by pressing the ENTER key.
4. Select the suitable keyword by using the UP ARROW or DOWN ARROW keys or the rotary knob.
5. Press the ENTER key to display the help topic.
The "View" tab with the corresponding help topic is displayed.

Changing the zoom

1. Change to the "Zoom" tab.
2. Set the zoom using the rotary knob. Four settings are available: 1-4. The smallest size is selected by number 1, the largest size is selected by number 4.

Closing the help window

- ▶ Press the ESC key or a function key on the front panel.

2 Introduction

This document contains all information required for operation of an R&S FSVR equipped with Application Firmware R&S FSV-K10. It covers operation via menus and the remote control commands for GSM/EDGE, EDGE Evolution (EGPRS2) and VAMOS (Voice services over Adaptive Multi-user channels on One Slot) measurements.

This part of the documentation consists of the following chapters:

- [chapter 3, "Instrument Functions GSM"](#), on page 11
describes the overall instrument functions and provides further information
- [chapter 4, "Remote Commands \(GSM\)"](#), on page 91
describes all remote control commands defined for the GSM/EDGE, EDGE Evolution (EGPRS2) and VAMOS measurements.
- [chapter 5, "Status Reporting System"](#), on page 248
provides a description of the status registers

This part of the documentation includes only functions of the Application Firmware R&S FSV-K10. For all other descriptions, refer to the description of the base unit.

3 Instrument Functions GSM

The R&S FSVR equipped with the GSM option performs measurements on downlink or uplink signals according to the Third Generation Partnership Project (3GPP) standards for GSM/EDGE, EDGE Evolution (EGPRS2) and Voice services over Adaptive Multi-user Channels on One Slot (VAMOS) in different domains (Time, Frequency, IQ). Signals with GMSK, AQPSK, QPSK, 8PSK, 16QAM and 32QAM modulation, normal or higher symbol rate and different TX filters (e.g narrow and wide pulse) can be measured. The measurements for Power vs Time, Modulation Accuracy and Modulation and Transient Spectrum as required in the standard can be performed.

The measurements and the physical layer – the layer of the GSM network on which modulation, transmission of RF signals, reception of RF signals, and demodulation take place – is defined in the standards:

Table 3-1: GSM standards

• 3GPP TS 45.004	Details on Modulation
• 3GPP TS 45.005	General measurement specifications and limit values
• 3GPP TS 45.010	Details on Synchronization and Timing
• 3GPP TS 51.010	Detailed measurement specifications and limit values for mobile stations (MS)
• 3GPP TS 51.021	Detailed measurement specifications and limit values for base transceiver stations (BTS)

To open the GSM menu

- If the "GSM" mode is not the active measurement mode, press the MODE key and activate the "GSM" option by selecting "GSM".
- If the "GSM" mode is already active, press the HOME key. The "GSM" menu is displayed.

Menu and softkey description

For a description of the GSM-specific softkeys see [chapter 3.3, "Softkeys and Settings of the GSM Menu"](#), on page 54.

The "Span", "BW", "Mkr Func", "Lines" menus are not available in GSM mode.

For all menus not described here, see the description of the R&S FSVR base unit.

To display help to a softkey, press the HELP key and then the softkey for which you want to display help. To close the help window, press the ESC key. For further information refer to section "How to use the Help System".

• Measurements and Result Displays	12
• Further Information	31
• Softkeys and Settings of the GSM Menu	54
• FREQ Key	86
• AMPT Key	86
• AUTO SET Key	86
• SWEEP Key	86

• TRACE Key.....	86
• TRIG Key.....	87
• Softkeys of the Marker Menu – MKR Key.....	87
• Softkeys of the Marker to Menu – MKR-> Key.....	88
• Softkeys of the Input/Output Menu.....	89

3.1 Measurements and Result Displays

This chapter provides information about the measurement and result displays of the GSM application.



Multiple measurement mode

The multiple measurement mode allows you to perform several measurements on the same captured I/Q data in parallel. In this case, the results of the selected measurements are available immediately, without starting a new measurement. Simply select the softkey for the performed measurement.

To retrieve the results for other measurement types, you must perform a new measurement first. The softkeys for the measurements not included in the multiple measurement selection only become available again when you deactivate multiple measurement mode or include the measurement in the multiple measurement selection.

• Screen Layout.....	12
• Modulation Accuracy.....	13
• Phase Error vs Time.....	14
• EVM vs Time.....	15
• Magnitude Error vs Time.....	17
• Constellation.....	18
• Trigger to Sync.....	19
• Power vs Time.....	20
• Modulation Spectrum.....	23
• Transient Spectrum.....	26
• Wide Modulation Spectrum.....	27

3.1.1 Screen Layout

Within the GSM measurement option, each measurement has its own screen layout (see e.g. [chapter 3.1.8, "Power vs Time"](#), on page 20). This is typically a combination of a graph in the upper screen part and a table in the lower screen part.

You can switch between the screens and select a split screen layout (to see all displays) or a full screen layout (to see only the graph or the table in more detail).



Table content in split screen mode

Due to the reduced space available for each result in split screen mode, the content of the tables may be reduced.

Via remote control, all results are available in any table state.

3.1.2 Modulation Accuracy

The fundamental characteristics of the signal to be analyzed in the vector (IQ) domain are error vector magnitude (EVM), magnitude and phase error, IQ imbalance, etc. The numerical readings are displayed in the "Modulation Accuracy" table.

B: Modulation Accuracy							
		Current	Average	Peak	Std Dev	Unit	
EVM	RMS	0.30	0.42	1.02	0.11	%	
	Peak	0.73	1.14	2.36	0.26	%	
Mag Error	RMS	0.06	0.06	0.07	0.00	%	
	Peak	0.19	0.19	0.24	0.02	%	
Phase Error	RMS	0.17	0.24	0.58	0.06	deg	
	Peak	- 0.42	0.65	1.35	0.15	deg	
Origin Offset Suppression		63.11	65.56	53.88	4.54	dB	
IQ Offset		0.07	0.06	0.20	0.03	%	
IQ Imbalance		0.03	0.05	0.12	0.02	%	
Frequency Error		14.80	13.64	16.87	1.90	Hz	
Burst Power		- 0.57	- 0.56	- 0.56	0.00	dBm	
Amplitude Droop		- 0.00	- 0.00	- 0.01	0.00	dB	
95%tile							
		EVM	0.86 %	Mag Error	0.15 %	Phase Error	0.49 deg

Fig. 3-1: Modulation Accuracy

To display a "Modulation Accuracy" table, select: "Demod > Modulation Accuracy" (see "Modulation Accuracy" on page 80) and then start a measurement (RUN SINGLE/RUN CONT key).



Modulation Accuracy results can be included in multiple measurements (see "Multi Meas Tab" on page 76). In this case, you do not need to start a new measurement.

If the "Modulation Accuracy" softkey is not available, include "Demod" in the multiple measurement selection or disable the multiple measurement mode.

The following default settings are used for a "Modulation Accuracy" table.

Setting	Default
Measurement Scope	The slot selected as "Slot to measure" in "Measurement Settings" (see " Slot to Measure " on page 65).
Averaging Configuration	Number of bursts as selected in "Statistic Count" in "General Settings" (" Statistic Count " on page 60).
Limit Check	None

Amplitude Droop

The "Amplitude Droop" value shown in the result table indicates the total change in amplitude (in dB) over the estimation range. The estimation range is set according to the 3GPP standard:

Modulation type	Estimation Range
GMSK	147 normal symbol periods
8PSK, 16QAM and 32 QAM (EGPRS2 Level A)	142 normal symbol periods
QPSK, 16QAM and 32QAM (EGPRS2 Level B)	169 reduced symbol periods

3.1.3 Phase Error vs Time

This measurement displays the phase error over time. The measurement consists of a graph and a table which is a condensed version of the "Modulation Accuracy" table (see [chapter 3.1.2, "Modulation Accuracy"](#), on page 13).




Fig. 3-2: Phase Error vs Time graph

Modulation Accuracy: List						
Item		Current	Average	Peak	Std Dev	Unit
Phase Error	RMS	0.18	0.21	0.35	0.05	deg
	Peak	0.56	0.62	0.92	0.13	deg
Origin Offset Suppression		6.42	5.44	4.51	0.84	dB
IQ Offset		0.06	0.26	0.55	0.16	%
IQ Imbalance		0.06	0.06	0.11	0.03	%
Frequency Error		- 1.09	4.48	- 7.18	1.42	Hz
Burst Power		- 77.00	- 77.00	- 77.00	- 77.00	dBm

Fig. 3-3: Phase Error values in Modulation Accuracy list

To start a "Phase Error vs Time" measurement, select: "Demod > Phase Error" (see "Phase Error" on page 81) and then start a measurement (RUN SINGLE/RUN CONT key).



Phase Error vs Time results can be included in multiple measurements (see "Multi Meas Tab" on page 76). In this case, you do not need to start a new measurement.

If the "Phase Error" softkey is not available, include "Demod" in the multiple measurement selection or disable the multiple measurement mode.

The following default settings are used for a "Phase Error vs Time" measurement.

Setting	Default
Measurement Scope	The slot selected as "Slot to measure" in "Measurement Settings" (see "Slot to Measure" on page 65).
Averaging Configuration	Number of bursts as selected in "Statistic Count" in "General Settings" "Statistic Count" on page 60.
Limit Check	None

3.1.4 EVM vs Time

This measurement displays the error vector magnitude over time. The measurement consists of a graph and a table which is a condensed version of the "Modulation Accuracy" table (see chapter 3.1.2, "Modulation Accuracy", on page 13).




Fig. 3-4: EVM vs Time graph

Modulation Accuracy: List						
Item		Current	Average	Peak	Std Dev	Unit
EVM	RMS	0.39	0.65	1.28	0.36	%
	Peak	6.39	6.71	7.38	0.39	%
Origin Offset Suppression		6.42	5.44	4.51	0.84	dB
IQ Offset		0.06	0.26	0.55	0.16	%
IQ Imbalance		0.06	0.06	0.11	0.03	%
Frequency Error		- 1.09	4.48	- 7.18	1.42	Hz
Burst Power		- 77.00	- 77.00	- 77.00	- 77.00	dBm

Fig. 3-5: EVM vs Time values in Modulation Accuracy list

To start a "EVM vs Time" measurement, select: "Demod > EVM" (see "EVM" on page 81) and then start a measurement (RUN SINGLE/RUN CONT key).



EVM vs Time results can be included in multiple measurements (see "Multi Meas Tab" on page 76). In this case, you do not need to start a new measurement. If the "EVM vs Time" softkey is not available, include "Demod" in the multiple measurement selection or disable the multiple measurement mode.

The following default settings are used for a "EVM vs Time" measurement.

Setting	Default
Measurement Scope	The slot selected as "Slot to measure" in "Measurement Settings" (see "Slot to Measure" on page 65).
Averaging Configuration	Number of bursts as selected in "Statistic Count" in "General Settings" (see "Statistic Count" on page 60).
Limit Check	None

3.1.5 Magnitude Error vs Time

This measurement displays the magnitude error over time. The measurement consists of a graph and a table which is a condensed version of the "Modulation Accuracy" table (see [chapter 3.1.2, "Modulation Accuracy"](#), on page 13).




Fig. 3-6: Magnitude Error vs Time graph

Magnitude Error vs Time: Modulation Accuracy		Current	Average	Peak	Std Dev	Unit
Mag Error	RMS	0.20	0.20	0.24	0.02	%
	Peak	0.50	0.52	0.63	0.05	%
Burst Power		- 30.40	- 30.56	- 30.40	0.17	dBm
Amplitude Droop		0.00	0.00	0.00	0.00	dB

Fig. 3-7: Magnitude Error values in Modulation Accuracy list

To start a "Magnitude Error vs Time" measurement, select: "Demod > Magnitude Error" (see ["Magnitude Error"](#) on page 81) and then start a measurement (RUN SINGLE/RUN CONT key).



Magnitude Error vs Time results can be included in multiple measurements (see ["Multi Meas Tab"](#) on page 76). In this case, you do not need to start a new measurement.

If the "Magnitude Error" softkey is not available, include "Demod" in the multiple measurement selection or disable the multiple measurement mode.

The following default settings are used for a "Magnitude Error vs Time" measurement.

Setting	Default
Measurement Scope	The slot selected as "Slot to measure" in "Measurement Settings" (see " Slot to Measure " on page 65).
Averaging Configuration	Number of bursts as selected in "Statistic Count" in "General Settings" (see " Statistic Count " on page 60).
Limit Check	None

3.1.6 Constellation

This measurement displays the constellation diagram. The measurement consists of a graph and a table which is a condensed version of the "Modulation Accuracy" table (see [chapter 3.1.2, "Modulation Accuracy"](#), on page 13).




Fig. 3-8: Constellation

To display a "Constellation" diagram, select: "Demod > Constell" (see "[Constell](#)" on page 81) and then start a measurement (RUN SINGLE/RUN CONT key).



Constellation diagrams can be included in multiple measurements (see "[Multi Meas Tab](#)" on page 76). In this case, you do not need to start a new measurement.

If the "Constell" softkey is not available, include "Constellation" in the multiple measurement selection or disable the multiple measurement mode.

The following default settings are used for a "Constellation" display.

Setting	Default
Measurement Scope	The slot selected as "Slot to measure" in "Measurement Settings" (see " Slot to Measure " on page 65).
Averaging Configuration	Number of bursts as selected in "Statistic Count" in "General Settings" (see " Statistic Count " on page 60).
Limit Check	None

3.1.7 Trigger to Sync

This measurement measures the time between an external trigger event and the start of the first symbol of the training sequence. The start of the first symbol corresponds to the time 0 of the symbol period (see [chapter 3.2.10, "Definition of the Symbol Period"](#), on page 48).




Fig. 3-9: Trigger to Sync

To start a "Trigger to Sync" measurement, select "Demod > More > Trigger to Sync" (see "[Trigger to Sync](#)" on page 81). Then start a measurement (RUN SINGLE/RUN CONT key).



Trigger to Sync measurements only provide one value per I/Q capture. In order to improve the measurement speed, set the capture time to 10 ms (see "[Capture Time](#)" on page 59).

3.1.8 Power vs Time

The "Power vs Time" (PvT) measurement is the most important GSM measurement in the time domain. It displays the power of all slots (bursts) in the selected slot scope (see [chapter 3.2.8, "Defining the Scope of the Measurement"](#), on page 43) and runs an evaluation against the specified template mask.

The measurement consists of a graph showing the "Power vs Time" trace including the limit lines, and a table that displays the slot powers of all slots in the slot scope.

In the graph display, it is possible to focus on different parts of the signal:

- "Full" on page 82: Displays all bursts in the slot scope
- "Rising" on page 82: Displays rising edges only (the rest of the burst is removed)
- "Falling" on page 82: Displays falling edges only (the rest of the burst is removed)
- "Rise & Fall" on page 83: Rising and falling edges zoomed
- "Top" on page 83: Useful part high resolution (same as "Full" on page 82, but y-axis zoomed)

To start a "Power vs Time" measurement, select "PvT" and then the required measurement type. Then start a measurement (RUN SINGLE/RUN CONT key).



Power vs. Time results can be included in multiple measurements (see ["Multi Meas Tab"](#) on page 76). In this case, you do not need to start a new measurement.

If the "PvT" softkey is not available, include "Power vs. Time" in the multiple measurement selection or disable the multiple measurement mode.




Fig. 3-10: Full Burst view in Power vs Time




Fig. 3-11: Rising and Falling Edge view in Power vs Time




Fig. 3-12: Top High Resolution view in Power vs Time



To zoom into the trace in the Power vs Time Full Burst view, activate a marker and use the marker zoom (see "Marker Zoom" on page 88).

The table displays the following information (see figure 3-13):

- The slot powers of all slots in the slot scope (see [chapter 3.2.8, "Defining the Scope of the Measurement"](#), on page 43). The average power, the peak power and the crest factor on a per-slot basis are displayed. The table contains results of the current ("Curr") frame as well as the statistics done over all ("All") analyzed frames according to the set statistic count.
- The "Delta to Sync" values correspond to the distance between the center of the [Training Sequence TSC](#) in a given slot and the center of the TSC in the [Slot to Measure](#). The unit is normal symbol periods (NSP = 1 / Normal Symbol Rate = 6 / 1625000 s = 3.69 us). These values are either assumed to be constant (according to the 3GPP standard) or measured, depending on the setting of the [Limit Time Alignment](#) parameter ("Slot to measure" or "Per Slot").

B: Power vs Time: List										
Slot		0	1	2	3	4	5	6	7	Unit
Power	Avg			-0.7	0.2	0.1	-73.6	-0.6		dBm
	Curr			2.6	4.4	4.7	-63.9	-0.6		dBm
	Crest			3.3	4.2	4.6	9.7	0.0		dB
Power	All			-0.6	0.0	-0.1	-73.9	-0.6		dBm
	Peak			2.6	4.5	4.9	-61.6	-0.6		dBm
	Crest			3.5	4.8	5.6	13.6	0.1		dB
Delta to	Sync			-156.00	0.00	156.00		469.00		NSP

Fig. 3-13: Power vs Time list display



According to the standard (see "Timeslot length" in 3GPP TS 45.010), there are either eight slots of equal length (156.25 NSP), or slot 0 and slot 4 have a length of 157 NSP while all other slots have a length of 156 NSP. For details see [chapter 3.2.11, "Timeslot Alignment"](#), on page 51.

The timeslot length is defined as the distance between the centers of the TSCs in successive slots. By setting the "Limit Time Alignment" parameter to "Per Slot" the "Delta to Sync" values can be measured and used in order to verify the timeslot lengths.

Setting the [Limit Time Alignment](#) to "Slot to measure" displays the expected values (according to the standard and depending on the value of [Equal Timeslot Length](#)). These values are summarized in [table 3-2](#) (Slot to measure = 0, No. of slots = 8 and First slot to measure = 0).

Table 3-2: Expected "Delta to Sync" values in normal symbol periods

Slot Number	0 = Slot to measure	1	2	3	4	5	6	7
Equal Timeslot Length = On	0	156.25	312.50	468.75	625.00	781.25	937.50	1093.75
Equal Timeslot Length = Off	0	157	313	469	625	782	938	1094

Default measurement settings

The following default settings are used for the "Power vs Time" measurement:

Setting	Default
Measurement Scope	The slot scope defined by First Slot to measure and Number of Slots to measure in "Measurement Settings" (see chapter 3.2.8, "Defining the Scope of the Measurement" , on page 43).
Averaging Configuration	Number of frames as selected in "Statistic Count" in "General Settings" (see "Statistic Count" on page 60)..
Limit Check	<p>According to standard.</p> <ul style="list-style-type: none"> • The maximum (Max) trace is checked against the upper limit. • The minimum (Min) trace is checked against the lower limit. • The limit masks are generated adaptively from the measured signal according to the following parameters: <ul style="list-style-type: none"> – Frequency band (special masks for PCS1900 and MXM11800 BTS with GMSK) – Burst type – Modulation – Filter – The reference burst power is measured and the "0 dB line" of the limit mask is assigned to it. – For MS, the "-6 dB line" of the limit mask depends on the PCL. The PCL is derived from the measured burst power.



Measurement and Zoom

When switching between Full, Rising, Falling, Rise & Fall, and Top, neither the measurement itself, nor the limit checking is changed. The only change is that the displayed signal data is cropped.

Remote commands

The results of the "Power vs Time" measurement can be queried using the following remote commands:

[FETCh:BURSt:SPoWer:SLOT<s>:ALL:AVERage](#) on page 177

[FETCh:BURSt:SPoWer:SLOT<s>:ALL:CRESt](#) on page 178

[FETCh:BURSt:SPoWer:SLOT<s>:ALL:MAXimum](#) on page 179

[FETCh:BURSt:SPoWer:SLOT<s>:CURRent:AVERage](#) on page 180

[FETCh:BURSt:SPoWer:SLOT<s>:CURRent:CRESt](#) on page 181

[FETCh:BURSt:SPoWer:SLOT<s>:CURRent:MAXimum](#) on page 182

[FETCh:BURSt:SPoWer:SLOT<s>:DELtAtosync](#) on page 183

3.1.9 Modulation Spectrum

The "Modulation Spectrum" measurement evaluates the spectral property (shape and values at certain fixed frequency offsets) of a certain part of the burst (50 to 90 % of the

useful part, excluding the training sequence TSC) by measuring the average power in this part over several bursts. The results of this measurement can be displayed in a graph or list.



The full list of measured frequency and filter bandwidths is provided in [table 3-3](#).




Fig. 3-14: Frequency Domain of modulation spectrum with traces and limits (red)

Modulation Spectrum: List						
Offset /kHz	/dB	Lower /dBm	Δ to Lim	/dB	Upper /dBm	Δ to Lim
100	- 7.3	- 45.7	7.83	- 8.0	- 46.4	8.53
200	- 37.1	- 75.5	10.45	- 37.2	- 75.6	10.59
250	- 41.2	- 79.5	14.55	- 42.5	- 80.8	15.83
400	- 65.6	- 104.0	38.96	- 66.7	- 105.1	40.08
600	- 69.3	- 107.6	42.65	- 70.2	- 108.6	43.60
800	- 69.7	- 108.0	43.03	- 70.1	- 108.4	43.45
1000	- 70.7	- 109.0	44.04	- 70.5	- 108.8	43.85
1200	- 69.5	- 107.8	42.83	- 70.0	- 108.4	43.39
1400	- 70.5	- 108.9	43.86	- 69.4	- 107.8	42.81
1600	- 69.9	- 108.3	43.32	- 70.0	- 108.4	43.41
1800	- 70.7	- 109.0	44.05	- 70.7	- 109.1	44.12

Fig. 3-15: Results Table in Modulation Spectrum

To start a "Modulation Spectrum" measurement, select: "Spectrum > Modulation Spectrum" (see "[Modulation Spectrum](#)" on page 83) and then start a measurement (RUN SINGLE/RUN CONT key).



Modulation Spectrum results can be included in multiple measurements (see "[Multi Meas Tab](#)" on page 76). In this case, you do not need to start a new measurement.

If the "Modulation Spectrum" softkey is not available, include "Modulation Spectrum" in the multiple measurement selection or disable the multiple measurement mode.

The following default settings are used for a "Modulation Spectrum" measurement.

Setting	Default
Measurement Scope	The slot selected as "Slot to measure" in "Measurement Settings" (see " Slot to Measure " on page 65).
Averaging Configuration	Number of bursts as selected in "Statistic Count" in "General Settings" (see " Statistic Count " on page 60)..
Limit Check	<p>According to standard.</p> <ul style="list-style-type: none"> • Frequency Domain: Limit check of average (Avg) trace • List: Limit check of absolute and relative scalar values • The limits depend on the following parameters: <ul style="list-style-type: none"> – Frequency band – Device Type (only BTS type, not MS type) – Burst Type / Modulation / Filter - limits are different for Higher Symbol Rate and Wide Pulse Filter (case 2) and others (case 1), see 3GPP TS 45.005, chapter 4.2.1.3 – The measured reference power (30 kHz bandwidth) – No. of active Carriers for multi-carrier BTS. The limit is relaxed by $10 \cdot \log_{10}(N)$ dB for offset frequencies ≥ 1.8 MHz, see 3GPP TS 45.005 chapter 4.2.1.2

Table 3-3: Frequencies and filter bandwidths in modulation spectrum measurements

Offset Frequency (kHz)	RBW (kHz)	VBW (kHz)
± 100	30	30
± 200	30	30
± 250	30	30
± 400	30	30
± 600	30	30
± 800	30	30
± 1000	30	30
± 1200	30	30
± 1400	30	30
± 1600	30	30
± 1800	30	30

Remote commands

The "Modulation Spectrum" measurement is started using the `CONFigure:SPECTrum:MODulation[:IMMediate]` command.

The gating parameters of the "Modulation Spectrum" measurement can be queried using `READ:WSpectrum:MODulation:GATing`.

The results of the "Modulation Spectrum" measurement can be queried using `READ:WSpectrum:MODulation[:ALL]`.

3.1.10 Transient Spectrum

The "Transient Spectrum" measurement is done in a very similar way to the modulation spectrum measurement.

The differences to the modulation spectrum measurement are:

- Instead of measuring only in the useful part of the burst (in the "Slot to measure", see "Slot to Measure" on page 65), the measurement is performed over the interval defined by the "Number of slots to measure" (see "Number of Slots to measure" on page 65) and the "First Slot to measure" (see "First Slot to measure" on page 65) in the "Measurement Settings", i.e. one measurement per frame. See also chapter 3.2.8, "Defining the Scope of the Measurement", on page 43. Therefore, the rising and falling edges affect the measurement result.
- Instead of the average power, the peak power is measured.
- The number of fixed offset frequencies is lower.




Fig. 3-16: Frequency Domain of Transient Spectrum with traces and limits (red)

Transient Spectrum: List						
Offset /kHz	/dB	Lower /dBm	Δ to Lim	/dB	Upper /dBm	Δ to Lim
400	-65.2	-95.8	59.83	-64.1	-94.7	58.67
600	-67.6	-98.2	62.23	-68.1	-98.8	62.76
1200	-68.2	-98.8	62.85	-67.7	-98.3	62.35
1800	-67.6	-98.2	62.24	-68.2	-98.8	62.80

Fig. 3-17: Result Table in Transient Spectrum

To start a "Transient Spectrum" measurement, select: "Spectrum > Transient Spectrum" (see ["Transient Spectrum"](#) on page 83) and then start a measurement (RUN SINGLE/RUN CONT key).



Transient Spectrum results can be included in multiple measurements (see ["Multi Meas Tab"](#) on page 76). In this case, you do not need to start a new measurement.

If the "Transient Spectrum" softkey is not available, include "Transient Spectrum" in the multiple measurement selection or disable the multiple measurement mode.

The following default settings are used for "Transient Spectrum" measurements.

Setting	Default
Measurement Scope	The slot scope defined by First Slot to measure and Number of Slots to measure in "Measurement Settings" (see chapter 3.2.8, "Defining the Scope of the Measurement" , on page 43).
Averaging Configuration	Number of frames as selected in "Statistic Count" in "General Settings" (see "Statistic Count" on page 60).
Limit Check	According to standard. <ul style="list-style-type: none"> • Frequency Domain: Limit check of maximum (Max) trace • List: Limit check of absolute and relative scalar values • The limit masks are generated adaptively from the measured signal. • The limits depend on the following parameters: <ul style="list-style-type: none"> – Frequency band (not for MS) – Burst Type / Modulation / Filter (not for MS) – The measured reference (burst) power

3.1.11 Wide Modulation Spectrum

The "Wide Modulation Spectrum" measurement measures the spectrum due to modulation at offset frequencies up to 5.8 MHz from the carrier. In principle, this measurement provides the same functionality as the existing "Modulation Spectrum List" measurement (see [chapter 3.1.9, "Modulation Spectrum"](#), on page 23), however the measured offset frequencies are extended past the current limit of 1.8 MHz up to 5.8 MHz. The full list of measured frequencies and filter bandwidths are listed in [table 3-4](#).

Contrary to the "Modulation Spectrum" measurement, the "Wide Modulation Spectrum" measurement uses a series of gated zero-span measurements. This approach provides improved measurement dynamics compared to the "Modulation Spectrum" approach that is based on captured I/Q data.

To start a "Wide Modulation Spectrum" measurement, select "Wide Spectrum > Wide Mod Spectrum" (see "Wide Mod Spectrum" on page 84).

Wide modulation spectrum measurements are not available for signals from the Digital Baseband Interface (R&S FSV-B17).

Table 3-4: Frequencies and filter bandwidths in wide modulation spectrum measurements

Offset Frequency (kHz)	RBW (kHz)	VBW (kHz)
± 100	30	30
± 200	30	30
± 250	30	30
± 400	30	30
± 600	30	30
± 800	30	30
± 1000	30	30
± 1200	30	30
± 1400	30	30
± 1600	30	30
± 1800	30	30
± 2000	100	100
± 2200	100	100
± 2400	100	100
± 2600	100	100
± 2800	100	100
± 3000	100	100
± 3200	100	100
± 3400	100	100
± 3600	100	100
± 3800	100	100
± 4000	100	100
± 4200	100	100
± 4400	100	100
± 4600	100	100
± 4800	100	100
± 5000	100	100
± 5200	100	100
± 5400	100	100

Offset Frequency (kHz)	RBW (kHz)	VBW (kHz)
± 5600	100	100
± 5800	100	100

The measurement can be performed using either the "External" or "Power" trigger modes (see [chapter 3.2.6, "Trigger settings"](#), on page 38). The trigger signal must be received once per GSM frame.



When using a power trigger, every active burst in the frame is measured. It is therefore important that all active bursts in the frame have the same modulation and filter type, otherwise the measurement results are not standard conformant.

Power trigger operation is not recommended for modulation formats that have zero-crossings (i.e. all except GMSK, QPSK and 8PSK). Therefore, the power trigger should only be used for GMSK, QPSK and 8PSK bursts. For 16QAM and 32QAM bursts an external trigger should be used.



It is recommended that you use the "Auto Set > Trigger" functionality of the R&S FSV-K10 application before starting the wide modulation list measurement. This automatically determines the appropriate "Trigger Offset" for the given frame configuration and the signal under test (see ["Trigger Offset"](#) on page 60).

Contrary to "Modulation Spectrum", the Wide Modulation Spectrum measurement is performed in gated zero-span mode, where the gating parameters (offset and length) are calculated based on the user-defined "Trigger Offset" and "Frame Configuration" settings. 50-90% of the active part of the "Slot to Measure" (excluding TSC) are measured. This approach provides improved measurement dynamics compared to the "Modulation Spectrum" approach that is based on captured I/Q data.

Wide Modulation Spectrum: List						
Offset /kHz	/dB	Lower /dBm	Δ to Lim	/dB	Upper /dBm	Δ to Lim
2600	-81.5	-90.5	25.54	-81.6	-90.6	25.58
2800	-81.9	-90.9	25.86	-81.6	-90.6	25.61
3000	-81.7	-90.7	25.74	-82.1	-91.1	26.13
3200	-82.2	-91.2	26.18	-81.9	-90.9	25.95
3400	-82.1	-91.1	26.14	-82.5	-91.5	26.55
3600	-82.5	-91.5	26.47	-82.7	-91.8	26.75
3800	-82.8	-91.8	26.77	-82.3	-91.4	26.36
4000	-82.8	-91.8	26.76	-82.3	-91.3	26.28
4200	-82.6	-91.6	26.64	-82.7	-91.7	26.71
4400	-83.3	-92.3	27.31	-82.7	-91.7	26.67
4600	-83.4	-92.4	27.40	-83.3	-92.3	27.30
4800	-83.2	-92.2	27.21	-83.4	-92.4	27.37
5000	-83.6	-92.6	27.62	-83.1	-92.1	27.07
5200	-83.5	-92.5	27.52	-83.2	-92.2	27.19
5400	-83.6	-92.6	27.59	-83.7	-92.8	27.76
5600	-83.0	-92.0	27.04	-83.4	-92.4	27.39
5800	-83.4	-92.4	27.41	-83.2	-92.2	27.23

Fig. 3-18: Results Table in Wide Modulation Spectrum

The following default settings are used for a "Wide Modulation Spectrum" measurement.

Setting	Default
Measurement Scope	The slot selected as "Slot to measure" in "Measurement Settings" (see " Slot to Measure " on page 65).
Averaging Configuration	Number of bursts as selected in "Statistic Count" in "General Settings" "Statistic Count" on page 60.
Limit Check	According to standard. <ul style="list-style-type: none"> • List: Limit check of absolute and relative scalar values • The limits depend on the following parameters: <ul style="list-style-type: none"> – Frequency band – Device Type (only BTS type, not MS type) – Burst Type / Modulation / Filter - limits are different for Higher Symbol Rate and Wide Pulse Filter (case 2) and others (case 1), see 3GPP TS 45.005, chapter 4.2.1.3 – The measured reference power (30 kHz bandwidth) – Number of carriers for multi-carrier BTS. The limit is relaxed by $10 \cdot \log_{10}(N)$ dB for offset frequencies ≥ 1.8 MHz, see 3GPP TS 45.005 chapter 4.2.1.2

Remote commands

The "Wide Modulation Spectrum" measurement is started using the `CONFigure:WSPpectrum:MODulation[:IMMediate]` command.

The gating parameters of the "Wide Modulation Spectrum" measurement can be queried using `READ:WSPpectrum:MODulation:GATing`.

The results of the "Wide Modulation Spectrum" measurement can be queried using `READ:WSpectrum:MODulation[:ALL]` on page 234.

3.2 Further Information

This chapter provides further information on the GSM standard, the corresponding measurement settings and results for the R&S FSV-K10 application.

• List of abbreviations	31
• Short description of GSM (GMSK, EDGE and EDGE Evolution)	32
• Short Introduction to VAMOS	36
• AQPSK Modulation	37
• Transducer factors	38
• Trigger settings	38
• Working with the Frequency Mask Trigger	39
• Defining the Scope of the Measurement	43
• Overview of filters in R&S FSV-K10	44
• Definition of the Symbol Period	48
• Timeslot Alignment	51

3.2.1 List of abbreviations

16QAM	16-ary Quadrature Amplitude Modulation
32QAM	32-ary Quadrature Amplitude Modulation
3GPP	3 rd Generation Partnership Project
8PSK	Phase Shift Keying with 8 phase states
AQPSK	Adaptive Quadrature Amplitude Modulation
ARFCN	Absolute Radio Frequency Channel Number
BTS	Base Transceiver Station
DL	Downlink (MS to BTS)
DUT	Device Under Test
EDGE	Enhanced Data Rates for GSM Evolution
EGPRS	Enhanced General Packet Radio, synonym for EDGE.
EGPRS2	Enhanced General Packet Radio and support of additional modulation/coding schemes and higher symbol rate.
FDMA	Frequency Division Multiplex Access
GMSK	Gaussian Minimum Shift Keying
GPRS	General Packet Radio Service
GSM	Global System for Mobile Communication
HSCSD	High-Speed Circuit-Switch Data

IF	Intermediate Frequency
MS	Mobile Station
PCL	Power Control Level
PvT	Power vs Time
QPSK	Quadrature Phase Shift Keying
SCPIR	Subchannel Power Imbalance Ratio
SFH	Slow Frequency Hopping
TDMA	Time Division Multiplex Access
TSC	Training Sequence Code
UL	Uplink (BTS to MS)
VAMOS	Voice services over Adaptive Multi-user Channels on One Slot
YIG	Yttrium Iron Garnet

3.2.2 Short description of GSM (GMSK, EDGE and EDGE Evolution)

The GSM (Global System for Mobile Communication) standard describes the GSM mobile radio network that is in widespread use today. In a first step to enhance this network, 8PSK modulation has been defined in addition to the existing GMSK (Gaussian Minimum Shift Keying) modulation. With 8PSK, the mobile or base station operates in the EDGE mode. While the 8PSK modulation transmits 3 bits within a symbol, GMSK can only transmit 1 bit within a symbol.

In a second step to enhance this network, higher symbol rate (HSR), QPSK, 16QAM, and 32QAM modulation, narrow and wide pulse shapes for the TX filter have been defined. Here, EDGE Evolution and EGPRS2 are synonyms for this second enhancement.

This means that GSM includes different modes: GMSK, EDGE and EDGE Evolution. The terms EDGE and EDGE Evolution are used here only when there are significant differences between the modes. In all other cases, the term GSM is used.

A TDMA (Time Division Multiple Access) and FDMA (Frequency Division Multiple Access) scheme is used to transfer data in the GSM network. This means that the digital information is transmitted discretely in the time domain (mainly used to distinguish between different users) as well as in the frequency domain (mainly used to distinguish between BTS).

The time domain is divided into slots with a duration of 576.923 μ s (exact: 3/5200 s). 8 slots (with number 0 to 7) are combined into 1 frame with a duration of approx. 4.6154 ms (exactly: 3/650 s).



Multiframes and superframes

Frames can be grouped into a multiframe consisting of either 26 (for support traffic and associated control channels) or 51 (for all other purposes) frames. Multiframes can be grouped to superframes consisting of either 51 26-frame or 26 51-frame multiframes.

Multiframes and superframes are not of relevance for the physical measurements on the GSM system and thus not discussed in detail here.

A mobile phone, therefore, does not communicate continuously with the base station; instead, it communicates discretely in individual slots assigned by the base station during connection and call establishment. In the simplest case, 8 mobiles share the 8 slots of a frame (TDMA).

The frequency range assigned to GSM is divided into frequency bands, and each band, in turn, is subdivided into channels.

Each frequency channel is identified by its center frequency and a number, known as the ARFCN (Absolute Radio Frequency Channel Number), which identifies the frequency channel within the specific frequency band. The GSM channel spacing is 200 kHz.

Communication between a mobile and a base station can be either frequency-continuous or frequency-discrete – distributed across various frequency channels (FDMA). In the standard, the abbreviation "SFH" (slow frequency hopping) is used to designate the latter mode of communication.

Base stations and mobiles communicate in different frequency ranges; the mobile sends in the "uplink" (UL), and the base station in the "downlink" (DL).

The frequencies specified in the standard plus their channel numbers (ARFCN) are shown in the figure and table below.




Fig. 3-19: The frequencies specified in the GSM standard

Table 3-5: Frequencies and channel numbers (ARFCN) in the GSM standard

Band Class	UL [MHz]	Fre- quen- cy	DL [MHz]	Fre- quen- cy	Fre- quen- cy Mid- dle	Band	UL- DL Shift	ARFCN	
	Low.	Up.	Low.	Up.	UL	DL		Range 1	Range 2
T-GSM 380	380.2	389.8	390.2	399.8	385.0	395.0	10 MHz	0 ... 48 ¹⁾	–
T-GSM 410	410.2	419.8	420.2	429.8	415.0	425.0	10 MHz	0 ... 48 ¹⁾	–
GSM 450	450.4	457.6	460.4	467.6	454.0	464.0	10 MHz	259 ... 293	–
GSM 480	478.8	486.0	488.8	496.0	482.4	492.4	10 MHz	306 ... 340	–
GSM 710	698.0	716.0	728.0	746.0	707.0	737.0	30 MHz	0 ... 90 ¹⁾	–
GSM 750	747.0	762.0	777.0	792.0	754.5	784.5	30 MHz	438 ... 511	–
T-GSM 810	806.0	821.0	851.0	866.0	813.5	858.5	45 MHz	0 ... 75 ¹⁾	–
GSM 850	824.0	849.0	869.0	894.0	836.5	881.5	45 MHz	128 ... 251	–
P-GSM 900	890.0	915.0	935.0	960.0	902.5	947.5	45 MHz	1 ... 124	–
E-GSM 900	880.0	915.0	925.0	960.0	897.5	942.5	45 MHz	0 ... 124	975 ... 1023
R-GSM 900	876.0	915.0	921.0	960.0	895.5	940.5	45 MHz	0 ... 124	955 ... 1023
T-GSM 900	870.4	876.0	915.4	921.0	873.2	918.2	45 MHz	0 ... 28 ¹⁾	–
DCS 1800	1710. 0	1785. 0	1805. 0	1880. 0	1747. 5	1842. 5	95 MHz	512 ... 885	–
PCS 1900	1850. 0	1910. 0	1930. 0	1990. 0	1880. 0	1960. 0	80 MHz	512 ... 810	–

¹⁾ For these frequency bands, there is no fixed ARFCN to frequency assignment, instead it is calculated with a formula taking an OFFSET parameter which is signaled by a higher layer of the network. The given ARFCNs assume an OFFSET value of 0.

Different modulation modes are used in the GSM mobile radio network. The original GSM modulation is GMSK, with the normal symbol rate (NSR) of approx. 270.833 ksymb/s (exact: 1625/6 ksymb/s). This corresponds to a bit rate of 270.833 kbit/s. The details are specified in chapter 2 of "3GPP TS 45.004" (see [table 3-1](#)).

The 8PSK (Phase Shift Keying) modulation, which is used within EDGE, was introduced to increase the data rate on the physical link. It uses the same symbol rate (the normal

symbol rate) as GMSK (270.833 ksymb/s), but has a bit rate of 3×270.833 kbit/s (exact: 812.5 kbit/s).

In this method, three bits represent a symbol. The details are specified in chapter 3 "3GPP TS 45.004" (see [table 3-1](#)).

The 16QAM and 32QAM (Quadrature Amplitude Modulation) modulation, which are used in EDGE Evolution, were introduced to further increase the data rate on the physical link. They use the normal symbol rate (270.833 ksymb/s), but have bit rates of 4×270.833 kbit/s or 5×270.833 kbit/s, respectively. The details are specified in chapter 4 "3GPP TS 45.004" (see [table 3-1](#)).

The QPSK, 16QAM and 32QAM modulation at higher symbol rate, which are used in EDGE Evolution, were introduced to further increase the data rate on the physical link. They use a higher symbol rate (325 ksymb/s), but have bit rates of 2×325 kbit/s, 4×325 kbit/s or 5×325 kbit/s, respectively. The details are specified in chapter 5 "3GPP TS 45.004" (see [table 3-1](#)).

The figure below shows the modulation spectrum for both GMSK and 8PSK.




Fig. 3-20: GMSK and 8PSK modulation spectrum

The customers' demand for higher telecommunication speeds increases the demand for bandwidth. Therefore, the GSM standard has to evolve constantly. An example of this development is the introduction of the EDGE/EDGE Evolution specification and the GPRS/EGPRS2 and HSCSD modes.

Until now, each mobile could use only one slot per frame, but the new HSCSD (High Speed Circuit Switched Data) and GPRS (General Packet Radio Service) methods will allow permanent assignment of more than one slot per mobile, plus dynamic utilization of multiple slots.

The concept behind GPRS is dynamic assignment of up to 8 slots to each mobile for data transmission, depending on demand (and availability in the network).

HSCSD allows permanent assignment of up to 4 slots to a mobile.

The modulation modes GMSK, QPSK, 8PSK, 16QAM and 32QAM can be used with either normal or higher symbol rate and different TX filters.

What is significant for the R&S FSV-K10 application firmware in this respect is that the mobile can send power on a frequency in more than one slot.

3.2.3 Short Introduction to VAMOS

The "Voice services over Adaptive Multi-user Channels on One Slot" (VAMOS) extension to the GSM standard allows transmission of two GMSK users simultaneously within a single timeslot.

The standard specifies the downlink signal using Adaptive QPSK (AQPSK) modulation (to appear in the 3GPP Release 9 TS 45.004 document), where two "subchannel" binary sequences are multiplexed to form a single QPSK sequence. The ratio of powers for the subchannels is referred to as the "Subchannel Power Imbalance Ratio" (SCPIR). One of the subchannels is interpreted as interference. The value of SCPIR affects the shape of the AQPSK constellation. For an SCPIR of 0dB the constellation is square (as in "normal" QSPK), while for other values of the SCPIR the constellation becomes rectangular.

A new set of training sequences (TSCs) has also been proposed (see 3GPP Release 9 TS 45.002) for GMSK signals. The previous TSCs for GMSK bursts are listed as "Set 1", while the new TSCs are listed as "Set 2". AQPSK signals can be formed using TSCs from Set 1 on the first subchannel and TSCs from either Set 1 or Set 2 on the second subchannel. In case a TSC from Set 2 is used, it should match the TSC from Set 1, i.e. TSC<n> from Set 1 on subchannel 1 should match TSC<n> from Set 2 on subchannel 2, for n = 0..7.

The R&S FSV-K10 supports measurement of the following signals:

- GMSK bursts using the TSCs from Set 1 or Set 2
- AQPSK bursts with any combination of TSCs from Set 1 and 2 on the subchannels
- AQPSK bursts with a user-specified SCPIR

The following measurement of the above signals are supported:

- Auto Trigger-Offset
- Power vs Time
- Demod (Modulation Accuracy, EVM vs Time, Phase Error vs Time, Magnitude Error vs Time, Constellation)
- Spectrum (modulation, transient) including limit check
- Wide Spectrum (modulation) including limit check



Restriction

Auto Frame configuration only detects AQPSK normal bursts where the subchannels have a TSC according to [table 3-6](#). The SCPIR value is detected with a resolution of 1 dB. To obtain reliable measurement results on AQPSK normal bursts, compare the auto-detected slot settings with the settings of your device under test.

Table 3-6: Required subchannel - TSC assignment for AQPSK auto frame configuration

AQPSK		Subchannel 2															
		TSC j (Set 1)								TSC j (Set 2)							
		0	1	2	3	4	5	6	7	0	1	2	3	4	5	6	7
Sub channel 1	TSC i (Set 1)	0			x	x				x	x						
		1			x	x				x		x					
		2	x	x					x				x				
		3	x	x			x							x			
		4				x			x						x		
		5			x				x							x	
		6					x	x									x
		7	x	x													

3.2.4 AQPSK Modulation

The AQPSK modulation scheme as proposed for use in GSM systems is illustrated in figure 3-21. First, the bits from two users (subchannels 1 and 2) are interleaved. The combined bit sequence is then mapped to an AQPSK constellation which depends on the SCPIR value. The AQPSK symbols are then modulated using the linearized GMSK pulse (see 3GPP TS 45.004).




Fig. 3-21: AQPSK modulation scheme for GSM systems

The proposed AQPSK mapping (as assumed in the R&S FSV-K10 software) is given in table 3-7 and illustrated in figure 3-22, where the first (leftmost) bit corresponds to sub-channel 1 and the second (rightmost) bit corresponds to subchannel 2.

Table 3-7: AQPSK symbol mappings [reproduced from 3GPP TS 45.004]

Modulating bits for a_i, b_i	AQPSK symbol in polar notation s_i
(0,0)	$e^{j\alpha}$
(0,1)	$e^{-j\alpha}$
(1,0)	$-e^{j\alpha}$
(1,1)	$-e^{-j\alpha}$

The AQPSK modulation constellation diagram is shown in figure 3-22, where the value α is an angle related to the SCPIR as follows:

$$\text{SCPIR}_{\text{dB}} = 20 \cdot \log_{10}[\tan(\alpha)] \text{ dB}$$




Fig. 3-22: AQPSK constellation [reproduced from 3GPP change request document GP-100275].

3.2.5 Transducer factors

Transducer factors (frequency response correction of external components like power splitters, cables or attenuator pads) are not supported within the R&S FSV-K10 option.

3.2.6 Trigger settings

The GSM measurements can be performed in "Free Run" (untriggered) mode, however, an external trigger or a power trigger can speed up measurements. To perform measurements the R&S FSV-K10 needs the frame start as a time reference. The R&S FSV-K10 searches for a frame start after every IQ data capture. The required search effort depends on the trigger mode.

Note the following trigger mode settings:

- In "Free Run" mode, i.e. without any trigger, the GSM application totally relies on the frame/slot configuration to find the frame start. The start of a measurement is not triggered. Once a measurement is completed, another is started immediately. For an unambiguous frame configuration, the GSM application searches for the frame start inside the captured IQ data. This is the slowest frame search mode.
- With a "Power Trigger", the measurement is triggered by the power ramp of the received GSM bursts. Nevertheless the GSM application still relies on the frame/slot configuration to find the frame start inside the captured I/Q data. Once a measurement is completed, the GSM application waits for the next trigger event to start the next measurement. The search for the frame start is as in "Free Run" mode, except that I/Q capture is triggered.
- With the "External Trigger", the measurement is triggered by an external signal (connected to the "EXT TRIGGER" input of the R&S FSVR). The GSM application assumes that the frame start directly follows the trigger event. An external trigger requires a correct setting of the trigger offset. The search is faster compared to the free run and power trigger modes. Use an external trigger to maximize the measure-

ment speed or if the frame configuration is ambiguous (i.e. if the slot properties are cyclic with a cycle less than the frame duration).


Refer to section "General Settings" on page 56 to learn more about appropriate trigger settings and the frame/slot configuration. Refer to section "Auto Set tab" on page 78 to learn more about auto setting the trigger offset.

3.2.7 Working with the Frequency Mask Trigger

The Frequency Mask Trigger (FMT) is a trigger designed to trigger measurements if the signal violates certain conditions with respect to a frequency mask that you can define prior to the measurement.

To create and edit a frequency mask, you can access the corresponding dialog box via the "Frequency Mask" softkey in the trigger menu.

Opening the dialog box also opens a softkey submenu that contains various functionality to work with frequency masks.



- 1 = Name and description of the frequency mask
- 2 = Mask point table: table containing all mask points
- 3 = Preview pane
- 4 = Frequency mask preview: the area the frequency mask currently covers is red
- 5 = Frequency mask data points: define the shape of the frequency mask
- 6 = Preview of the current measurement trace; type and shape depend on currently selected measurement
- 7 = Insert button: insert a new data points
- 8 = Shift X button: shifts the complete frequency mask horizontally
- 9 = Delete button: deletes an existing data points
- 10 = Shift Y button: shifts the complete frequency mask vertically
- 11 = Y-Axis Rel/Abs button: switches between relative (dB) and absolute (dBm) amplitude values

- 12 = Adapt Mask button: creates a frequency mask automatically
- 13 = Trigger Condition menu: sets the trigger condition
- 14 = Activate Line buttons: select the upper and lower frequency mask; check marks next to the buttons activate and deactivate a line

3.2.7.1 Creating a Frequency Mask

Upon opening the "Edit Frequency Mask" dialog box, the R&S FSVR already provides a basic structure of an upper frequency mask in the live preview window.

It is also possible to create a new mask by pressing the "New Mask" softkey. The "New Mask" softkey resets the current shape of the mask to its default state.

Labelling a frequency mask

Assign a name to the frequency mask in the "Name" field. Activate the input in the "Name" field either by touching it or via the "Edit Name" softkey. This is also the save name of the frequency mask.

In addition to naming the mask, you can also comment on the frequency mask you are working on in the "Comment" field. Again, activate the input either by touching it or with the "Edit Comment" softkey.

SCPI command:

[CALCulate<n>:MASK:COMMeNt](#) on page 100

[CALCulate<n>:MASK:NAME](#) on page 102

Defining the frequency mask span

Define the span of the frequency mask.

The span defines the range that the frequency mask covers on the frequency axis.

SCPI command:

[CALCulate<n>:MASK:SPAN](#) on page 102

Working with upper and lower lines

A frequency mask may have an upper and a lower threshold, with the signal in between. The checkboxes next to the "Upper Line" and "Lower Line" buttons activate or deactivate the corresponding line. Note that it is not possible to deactivate both lines.

You can select the line you want to edit with the "Upper Line" / "Lower Line" buttons or by touching the corresponding area in the preview to apply any changes. The buttons turn blue if a line is selected and the R&S FSVR shows the data points in the area covered by the mask in the preview pane.

SCPI command:

[CALCulate<n>:MASK:LOWer \[:STATe\]](#) on page 101

[CALCulate<n>:MASK:UPPer \[:STATe\]](#) on page 103

Setting the trigger condition

To make the trigger work, you need to set a trigger condition with the "Trigger Condition" button. The R&S FSVR supports four conditions.

- "Entering" Activates the trigger as soon as the signal enters the frequency mask. To arm the trigger, the signal initially has to be outside the frequency mask.

"Leaving"	Activates the trigger as soon as the signal leaves the frequency mask. To arm the trigger, the signal initially has to be inside the frequency mask.
"Inside"	The trigger is active as long as the signal is inside the frequency mask. To arm the trigger, the signal initially has to be outside the frequency mask.
"Outside"	The trigger is active as long as the signal is outside the frequency mask. To arm the trigger, the signal initially has to be inside the frequency mask.

SCPI command:

`TRIGger<n>[:SEquence]:MASK:CONDition` on page 244

3.2.7.2 Editing Mask Points

You can adjust the frequency mask any way you want by adding, removing and repositioning frequency mask data points.

Data points define the shape of the frequency mask. In the preview pane, the R&S FSVR visualizes data points as blue circles. In addition, all data point positions are listed in the data point table. The number of data points is limited to 801.

Data points are defined by two values. The first value defines the position of the data point on the horizontal (frequency) axis. Frequency information is relative to the center frequency.

Note that in realtime mode, the span depends on the realtime bandwidth. That also means that the distance of a data point to the center frequency can never exceed 20 MHz as the maximum realtime bandwidth is 40 MHz.

The second value defines the position of the data point on the vertical (level) axis. By default, level information is relative to the reference level. You can, however, turn the level axis to absolute scaling with the "Y-Axis Abs/Rel" button. This also changes the unit of the vertical axis (dB for relative data points, dBm for absolute data points).

Adding data points

To add a new data point, press the "Insert" button or the "Insert Value Above" softkey. The R&S FSVR always adds the data point to the left (or in case of the table, above) of the currently selected data point. The currently selected data point is highlighted gray in the table. If no data point was selected previously, the buttons add a new point next to the very first one.

Deleting data points

The "Delete" button or the "Delete Value" softkey remove a data point from the mask. The R&S FSVR deletes the currently selected data point. If no data point is selected, it deletes the first one. The "Delete" button is inactive in that case.

Positioning data points

There are two ways to move a single data point.

In the preview pane, you can drag around the data points on the touchscreen or with a mouse and position it roughly in the place you want it to be. A more exact method is to edit the data point table itself and enter the frequencies and levels as you need.

SCPI command:

`CALCulate<n>:MASK:LOWer[:DATA]` on page 101

`CALCulate<n>:MASK:UPPer[:DATA]` on page 104

Shifting mask points as a whole

With the "Shift X" and "Shift Y" buttons you are able to move all mask points of a frequency mask as one. The "Shift X" button moves the mask point set horizontally, while the "Shift Y" button moves them vertically. This is an easy method to move mask points if the relative position of mask points to each other is alright already without adjusting each one by itself.

SCPI command:

`CALCulate<n>:MASK:LOWer:SHIFt:X` on page 101

`CALCulate<n>:MASK:LOWer:SHIFt:Y` on page 101

`CALCulate<n>:MASK:UPPer:SHIFt:X` on page 103

`CALCulate<n>:MASK:UPPer:SHIFt:Y` on page 103

Automatic alignment of the frequency mask

Instead of defining the position of every data point by hand, the R&S FSVR is able to shape the frequency mask according to the shape of the current signal. On pressing the "Auto Set Mask" button, the R&S FSVR forms the frequency mask around the current spectrum.

Note that the automatic alignment of the frequency mask works only for the upper frequency mask.

SCPI command:

`CALCulate<n>:MASK:UPPer[:DATA]` on page 104

3.2.7.3 Managing Frequency Masks

To be able to reuse or edit a frequency mask that you have defined later, you can save and restore particular frequency mask configurations.

The R&S FSVR stores files that contain such configurations on its internal hard disk.

Save Mask

The "Save" softkey opens a dialog box to save the current frequency mask configuration in a file.

If you do not name the file in the dialog box, the R&S FSVR names the file like the name of the frequency mask itself.

Load Mask

The "Load" softkey opens a dialog box to restore a frequency mask.

The dialog box contains all frequency masks already on the hard disk of the R&S FSVR. Select the mask you need and confirm the selection with the "Load" button.

SCPI command:

Path selection:

[CALCulate<n>:MASK:CDIRectory](#) on page 100

Load mask:

[CALCulate<n>:MASK:NAME](#) on page 102

Delete Mask

The Delete softkey opens a dialog box to delete a previously saved frequency mask.

The "Delete" button deletes the file. Note that you have to confirm the deletion process.

SCPI command:

[CALCulate<n>:MASK:DELeTe](#) on page 100

3.2.8 Defining the Scope of the Measurement

The R&S FSV-K10 is a slot-based application. It can measure up to 8 consecutive GSM slots (1 frame) and store the power results for all slots ("Power vs Time" measurement, see [chapter 3.1.8, "Power vs Time"](#), on page 20).

Within this measurement interval (defined by [First Slot to measure](#) and [Number of Slots to measure](#)), a single slot (["Slot to Measure"](#) on page 65) is selected for a more detailed analysis (e.g. "Modulation Accuracy" measurement, see [chapter 3.1.2, "Modulation Accuracy"](#), on page 13). The [Slot to Measure](#) provides:

- The reference power and time reference for the "Power vs Time" measurement (see [chapter 3.1.8, "Power vs Time"](#), on page 20). The masks for all slots are time-aligned according to the timing of the [Slot to Measure](#).
- The results of all "Modulation Spectrum" diagrams are based on the ["Slot to Measure"](#) on page 65 (see [chapter 3.1.9, "Modulation Spectrum"](#), on page 23). (The results of all "Transient Spectrum" diagrams are based on the slot scope, i.e. on the interval defined by the [First Slot to measure](#) and the [Number of Slots to measure](#), see [chapter 3.1.10, "Transient Spectrum"](#), on page 26).
- All results that require demodulation of one slot and their statistical analysis (e.g. [Modulation Accuracy](#), [Phase Error vs Time](#), and [EVM vs Time](#)).




Fig. 3-23: Concept of "First Slot to measure", "Number of Slots to measure" and "Slot to Measure"

The measurement interval is set in the Demod tab of the Meas Settings dialog, and it is visualized above by a filled green box and the parameter Slot to Measure is visualized by a filled yellow box.

CONFigure:MS:CHANnel:MSLots:MEASure 0 →

CONFigure:MS:CHANnel:MSLots:NOFSlots 1 →

CONFigure:MS:CHANnel:MSLots:OFFSet 0 →

CONFigure:MS:CHANnel:FRAMe:EQUal ON →

Measurement Settings
✕

Demod

Advanced

Multi Carrier

Auto Set

Single-Slot Measurements

Slot to measure

Used for:

- Modulation Accuracy / EVM
- Phase / Magnitude Error
- Modulation Spectrum
- Reference Power
- Timing Reference (Sync)

Multi-Slot Measurements

No. of Slots to measure

First Slot to measure

Used for:

- Power vs Time
- Transient Spectrum

Frame Configuration

Mode

Equal Timeslot Length

Frame: Select Slot to configure

HB
GSMK

|

|

|

|

|

|

|

0

1

2

3

4

5

6

7

3.2.9 Overview of filters in R&S FSV-K10

The R&S FSV-K10 measurement application requires a number of filters for different stages of signal processing. These include the "Multi Carrier" filter (for Multi Carrier base station measurements only), the "Power vs Time" filter and the "Measurement" filter. A signal flow diagram is shown in figure 3-24 to illustrate where the different filters are used.




Fig. 3-24: Signal flow diagram highlighting filtering operations

3.2.9.1 Multi Carrier Filter

The "Multi Carrier" filter is only applied to the captured data if the "Multi Carrier BTS" option is selected (see "Multi Carrier BTS" on page 77). This filter is used to suppress neighboring channels which may disturb measurement of the channel of interest. The output from the "Multi Carrier" filter is used to perform synchronization and demodulation. This filter is not applied for Power vs Time or Spectrum measurements. For suppression of neighboring channels in the Power vs Time measurement, see the Power vs Time Filter. The frequency response of the "Multi Carrier" filter is shown in figure 3-25.




Fig. 3-25: Frequency Response of the Multi Carrier Filter

3.2.9.2 Power vs Time Filter

The "Power vs Time" filter is used to suppress out-of-band interference in the Power vs Time measurement.

The following filters are available:

- 1 MHz Gauss
- 500 kHz Gauss
- 600 kHz
- 400 kHz MC
- 300 kHz MC

The last two "MC" filters are only available for Multi Carrier BTS measurements, i.e. if the "Multi Carrier BTS" option is selected (see "Multi Carrier BTS" on page 77). The magnitude and step responses of the different "Power vs Time" filters are shown in [figure 3-26](#) and [figure 3-27](#), respectively. In general, the smaller the filter bandwidth, the worse the step response becomes (in terms of "ringing" effects) and the better the suppression of interference at higher frequencies. Gaussian type filters are especially useful for signals with "sharp" edges as the step response does not exhibit overshoot.




Fig. 3-26: Magnitude Response of the Power vs Time Filters




Fig. 3-27: Step Response of the Power vs Time Filters

3.2.9.3 Measurement Filter

The "Measurement" filter is used to limit the bandwidth of the demodulation measurements and is described in the 3GPP Standard document *TS 45.005 V8.5.0* (2009-05) for QPSK, 8PSK, 16QAM and 32QAM as follows:

- a raised-cosine filter with roll-off 0.25 and single side-band 6 dB bandwidth 90 kHz for normal symbol rate and for higher symbol-rate using [narrow] bandwidth pulse-shaping filter
- a raised-cosine filter with roll-off [0.25] and single side-band 6 dB bandwidth [108] kHz for higher symbol-rate using [wide] bandwidth pulse-shaping filter

In addition to these filters, a "Measurement" filter for GMSK is used in the R&S FSV-K10 option to limit the effects of out-of-band interference due to the high sampling rate of 6.5 MHz which is used. The magnitude responses of all the "Measurement" filters are shown in [figure 3-28](#).




Fig. 3-28: Magnitude Responses of Measurement Filters for Demodulation Measurements

3.2.10 Definition of the Symbol Period

The following sections define the symbol period for various modulation types.

3.2.10.1 GMSK Modulation (Normal Symbol Rate)

The GMSK frequency pulse is defined in the standard document "3GPP TS 45.004" as a Gaussian pulse convolved with a rectangular pulse, as illustrated at the top of [figure 3-29](#). With the frequency pulse denoted $g(t)$, the phase of a GMSK signal due to a sequence of symbols $\{\alpha\}$ is defined in the standard as:

$$\varphi(t') = \sum_i \alpha_i \pi h \int_{-\infty}^{t'-iT} g(u) du$$

where T is the normal symbol period, and the modulating index is chosen such that the maximum phase change of $\pi/2$ radians per data interval is achieved.

Note that the standard specifies:

"The time reference $t' = 0$ is the start of the active part of the burst as shown in [figure 3-29](#). This is also the start of the bit period of bit number 0 (the first tail bit) as defined in 3GPP TS 45.002."

The phase change due to the first tail symbol is illustrated at the bottom of [figure 3-29](#), where you can see that the "decision instant" corresponding to the center of the frequency pulse occurs at the beginning of the first symbol period, i.e. at $t' = 0$.




Fig. 3-29: GMSK Frequency Pulse (top) and phase of the first tail symbol (bottom)

3.2.10.2 8PSK, 16QAM and 32QAM Modulation (Normal Symbol Rate)

The EDGE transmit pulse is defined in the standard document "3GPP TS 45.004" as a linearised GMSK pulse, as illustrated at the top of [figure 3-30](#). Note that according to the definition in the standard, the center of the pulse occurs at $2.5 T$, where T is the normal symbol period. With the transmit pulse denoted as $c_0(t)$, the baseband signal due to a sequence of symbols $\{\hat{s}_i\}$ is defined in the standard as:

$$y(t') = \sum_i \hat{s}_i \cdot c_0(t' - iT + 2T)$$

Note that the standard specifies:

"The time reference $t' = 0$ is the start of the active part of the burst as shown in [figure 3-30](#). This is also the start of the symbol period of symbol number 0 (containing the first tail bit) as defined in 3GPP TS 45.002."

The transmitted pulse for the first tail symbol is illustrated in the lower part of [figure 3-30](#), where it can be seen that the "decision instant" corresponding to the center of the transmit pulse occurs in the center of the first symbol period, i.e. at $t'=0.5T$.




Fig. 3-30: EDGE transmit pulse (top) and the first transmitted symbol (bottom)



The description above also applies to the 16QAM and 32QAM modulations defined for EDGE Evolution, using the "normal" symbol rate.

3.2.10.3 QPSK, 16QAM and 32QAM Modulation (Higher Symbol Rate)

For the newer "reduced" symbol period (higher symbol rate) the standard document "3GPP TS 45.004" defines two transmit pulse shapes; the so-called "narrow" and "wide" pulses. The narrow pulse is the same linearised GMSK pulse as described in [chapter 3.2.10.2, "8PSK, 16QAM and 32QAM Modulation \(Normal Symbol Rate\)"](#), on page 49, while the wide pulse was designed based on a numerically optimized set of discrete filter coefficients. Both narrow and wide pulse shapes are illustrated at the top of [figure 3-31](#), where you can see that the center of the pulse occurs at $3T$, with T being the reduced symbol period. Let us denote the transmit pulse by $c(t)$ (which may be either the narrow or wide pulse), then for a sequence of symbols $\{\hat{s}_i\}$ the transmitted signal is defined in the standard as:

$$y(t') = \sum_i \hat{s}_i \cdot c(t' - iT + 2.5T)$$

Note that the standard specifies:

"The time reference $t' = 0$ is the start of the active part of the burst as shown in [figure 3-31](#). This is also the start of the symbol period of symbol number 0 (containing the first tail bit) as defined in 3GPP TS 45.002."

The transmitted pulse for the first tail symbol is illustrated at the bottom of [figure 3-31](#), where you can see that the "decision instant" corresponding to the center of the transmit pulse occurs in the center of the first symbol period, i.e. at $t'=0.5T$.




Fig. 3-31: EDGE Evolution transmit pulses (top) and the first transmitted symbols (bottom)

3.2.11 Timeslot Alignment

Reference Time

The definition of a "reference time" is necessary for the following description of timeslot alignment. In the standard document "3GPP TS 5.010", in Section 5.7 it is stated that:

"Irrespective of the symbol duration used, the center of the training sequence shall occur at the same point in time. "

This is illustrated in Figure 5.7.3 of the standard document "3GPP TS 45.010" which is reproduced below for convenience ([figure 3-32](#)). Due to this requirement, the "middle of midamble" or "center of Active Part" shall be used as the reference time when specifying timeslot alignment. Additionally, the "middle of midamble" is used for the alignment of the Power vs Time limit masks (see also "[Limit Time Alignment](#)" on page 72).




Fig. 3-32: Timing alignment between normal symbol period and reduced symbol period bursts

As described in chapter 3.2.10, "Definition of the Symbol Period", on page 48, the middle of midamble can be defined with respect to symbol periods and symbol decision instants. This is illustrated in figure 3-33. You can see that for normal symbol period bursts (Normal bursts), the middle of midamble for GMSK occurs exactly at the decision instant of symbol 74. However, for EDGE it occurs between the decision instants of symbols 73 and 74, while for reduced symbol period bursts (Higher Symbol Rate bursts), it occurs exactly at the decision instant of symbol 88.




Fig. 3-33: Middle of midamble for normal and reduced symbol period bursts.

Timeslot Alignment

The standard document "3GPP TS 45.010" provides details on the alignment of slots within the GSM frame:

"Optionally, the BTS may use a timeslot length of 157 normal symbol periods on timeslots with TN = 0 and 4, and 156 normal symbol periods on timeslots with TN = 1, 2, 3, 5, 6, 7, rather than 156.25 normal symbol periods on all timeslots"

The alignment of slots therefore falls under the "Not Equal Timeslot Length" (Equal Timeslot Length = off) or the "Equal Timeslot Length" (Equal Timeslot Length = on) criterion (see also "Equal Timeslot Length" on page 66), which are illustrated in figure 3-34.




Fig. 3-34: "Not equal"(top) and "equal" (bottom) timeslot length criteria

Note that, since the reference point at the "middle of midamble" of each slot must coincide, the length of the guard interval between successive bursts will depend on both the timeslot length and the symbol rate of bursts in successive slots. As stated in the standard "3GPP TS 45.010", for the "Equal Timeslot Length" case:

"... if there is a pair of different symbol period bursts on adjacent timeslots, then the guard period between the two bursts shall be 8.5 normal symbol periods which equals 10.2 reduced symbol periods."

For the "Not Equal Timeslot Length" case, deriving the guard interval length is somewhat more complicated, and the possible values are summarized in Table 5.7.2 of "3GPP TS 45.010", reproduced below as table 3-8, for convenience:

Table 3-8: Guard period lengths between different timeslots

Burst Transition	Guard Period Between Timeslots (In terms of normal symbol periods)		Guard Period Between Timeslots (In terms of reduced symbol periods)	
	TS0 and TS1 or TS4 and TS5	Any other timeslot pair	TS0 and TS1 or TS4 and TS5	Any other timeslot pair
normal symbol period to normal symbol period	9	8	10.8	9.6
normal symbol period to reduced symbol period	9.25	8.25	11.1	9.9

Burst Transition	Guard Period Between Timeslots (In terms of normal symbol periods)		Guard Period Between Timeslots (In terms of reduced symbol periods)	
	TS0 and TS1 or TS4 and TS5	Any other timeslot pair	TS0 and TS1 or TS4 and TS5	Any other timeslot pair
reduced symbol period to normal symbol period	9.25	8.25	11.1	9.9
reduced symbol period to reduced symbol period	9.5	8.5	11.4	10.2

3.3 Softkeys and Settings of the GSM Menu

The following table shows all softkeys and settings available from the main menu of the GSM application.

Press the MEAS key to open this menu.

General Settings.....	56
L Primary Settings.....	56
L Device Under Test: Type.....	57
L Frequency Band.....	57
L Frequency.....	58
L ARFCN.....	58
L Reference Level.....	58
L External Attenuation.....	58
L Power Class.....	58
L Signal Source.....	59
L Capture Time.....	59
L Synchronization.....	59
L Measure only on Sync.....	60
L Trigger Mode.....	60
L Trigger Offset.....	60
L Statistic Count.....	60
L Advanced Settings tab.....	61
L RF Input.....	61
L Frequency Offset.....	61
L Ref. Level.....	61
L RF Atten.....	62
L Mechanical Atten.....	62
L EI Atten State.....	62
L Electrical Atten.....	62
L Preamp On/Off (option RF Preamplifier, B22/B24).....	62
L Trigger Polarity.....	63
L IF Pow.Retrig.Holdoff.....	63
L IF Pow.Retrig.Hysteresis.....	63

L Auto Track Time.....	63
L Trigger Level.....	63
L Swap I/Q.....	63
L Baseband digital.....	63
L Input Sample Rate.....	63
L Full Scale Level.....	64
Meas Settings.....	64
L Demod tab.....	64
L Slot to Measure.....	65
L Number of Slots to measure.....	65
L First Slot to measure.....	65
L Equal Timeslot Length.....	66
L Frame: Select Slot to Configure.....	66
L Burst.....	66
L Active.....	67
L Burst Type.....	67
L Modulation.....	67
L SCPIR.....	67
L Filter.....	67
L Training Sequence TSC.....	68
L User TSC.....	69
L Subchannel 1/2.....	70
L Training Sequence TSC.....	70
L User TSC.....	71
L Advanced tab.....	71
L PvT Filter.....	71
L Limit Time Alignment.....	72
L Enable Left Limit.....	72
L Enable Right Limit.....	72
L Filter Type.....	73
L Transient Ref. Power.....	73
L Mod. RBW @ 1800 kHz.....	73
L High Dynamic.....	74
L Wide Mod. Freq. List.....	74
L No. of Bins.....	74
L Adaptive Data Size.....	74
L IQ Correlation Threshold.....	75
L Symbol Decision.....	75
L Tail & TSC Bits.....	75
L Multi Meas Tab.....	76
L Multiple Measurement Mode active.....	76
L Power vs Time.....	76
L Demod.....	76
L Constellation.....	77
L Modulation Spectrum.....	77
L Transient Spectrum.....	77
L Multi Carrier tab.....	77
L Multi Carrier BTS.....	77
L No. of active Carriers.....	78
L BTS Class.....	78

L PvT Filter.....	78
L Auto Set tab.....	78
L Level.....	79
L Frame Configuration.....	79
L Trigger.....	80
Demod.....	80
L General Settings.....	80
L Meas Settings.....	80
L Modulation Accuracy.....	80
L EVM.....	81
L Phase Error.....	81
L Magnitude Error.....	81
L Constell.....	81
L Trigger to Sync.....	81
L R&S Support.....	82
PvT.....	82
L General Settings.....	82
L Meas Settings.....	82
L Full.....	82
L Rising.....	82
L Falling.....	82
L Rise & Fall.....	83
L Top.....	83
L R&S Support.....	83
Spectrum.....	83
L General Settings.....	83
L Meas Settings.....	83
L Modulation Spectrum.....	83
L Transient Spectrum.....	83
L Display List/Graph.....	84
L R&S Support.....	84
Wide Spectrum.....	84
L General Settings.....	84
L Meas Settings.....	84
L Wide Mod Spectrum.....	84
Import.....	84
Export.....	85
R&S Support.....	85

General Settings

Opens the "General Settings" dialog box.

Primary Settings ← General Settings

This tab contains the basic measurement settings.

CONFigure:MS:DEvIce:TYpe BTSNormal →

CONFigure:MS:NETWork:TYpe EGSM →

CONFigure:MS:NETWork:FREQuency:BAND 900 →

SENSe1:FREQuency:CENTer 935 MHz →

CONFigure:MS:ARFCn 0 →

DISPlay:WINDow1:TRACel:Y:SCALE:RLEVel 40 DBM →

CONFigure:MS:POWer:AUTO OFF →

DISPlay:WINDow1:TRACel:Y:SCALE:RLEVel:OFFSet 40 DB →

CONFigure:MS:POWer:CLASs 1 →

CONFigure:MS:POWer:STATic 6 →

n.a. →

SENSe1:SWEep:TIME 100 MS →

CONFigure:MS:SYNC:MODE ALL →

CONFigure:MS:SYNC:ONLY ON →

TRIGger1:SEQUence:SOURce EXTernal →

TRIGger1:SEQUence:HOLDoff 576.92 US →

SENSe1:SWEep:COUNT 20 →

General Settings

Primary Settings | Advanced Settings

Device Under Test

Type: BTS Normal

Signal Characteristics

Frequency Band: E-GSM 900

Frequency: 935 MHz

ARFCN: 0

Level Settings

Reference Level: Auto 40 dBm

External Atten.: 40 dB

Power Class: 1

Static PCL: 6

Capture Settings

Signal Source: RF Input

Capture Time: 100 ms

Synchronization: Burst + TSC

Measure only on Sync:

Trigger Mode: External

Trigger Offset: 576.92 μs 1 slots

Statistic Count: 20

Device Under Test: Type ← Primary Settings ← General Settings

To change the type of device under test (DUT), enter one of the following types:

- BTS Normal
- BTS Micro
- BTS Pico
- MS Normal
- MS Small

The default device type is "BTS Normal".

SCPI command:

[CONFigure\[:MS\]:DEvIce:TYpe](#) on page 123

Frequency Band ← Primary Settings ← General Settings

The following frequency bands are supported:

- T-GSM 380
- T-GSM 410
- GSM 450
- GSM 480
- GSM 710
- GSM 750
- T-GSM 810
- GSM 850
- P-GSM 900
- E-GSM 900
- R-GSM 900

- T-GSM 900
- DCS 1800
- PCS 1900

The default frequency band is E-GSM 900.

SCPI command:

[CONFigure\[:MS\]:NETWork\[:TYPE\]](#) on page 129

[CONFigure\[:MS\]:NETWork:FREQuency:BAND](#) on page 130

Frequency ← Primary Settings ← General Settings

Specifies the center frequency of the signal to be measured. If the frequency is modified, the "ARFCN" is updated accordingly (see "ARFCN" on page 58).

SCPI command:

[\[SENSe:\]FREQuency:CENTer](#) on page 237

ARFCN ← Primary Settings ← General Settings

To set the Absolute Radio Frequency Channel Number (ARFCN), enter the desired number in this field. Setting the ARFCN will update the Frequency.

Possible values are in the range from 0 to 1023, however, some values may not be allowed depending on the selected frequency band.

SCPI command:

[CONFigure\[:MS\]:ARFCn](#) on page 105

Reference Level ← Primary Settings ← General Settings

Defines the reference level in dBm.

The reference level value is the maximum value the AD converter can handle without distortion of the measured value. Signal levels above this value will not be measured correctly, which is indicated by the "IFOVL" status display.

"AUTO" enables continuous auto levelling. In this case, the optimal reference level for the current measurement is defined automatically.

SCPI command:

[DISPlay\[:WINDow<n>\]:TRACe<t>:Y\[:SCALe\]:RLEVel\[:RF\]](#) on page 152

[CONFigure\[:MS\]:POWer:AUTO](#) on page 133

External Attenuation ← Primary Settings ← General Settings

Specifies the external attenuation or gain applied to the RF signal. A positive value indicates attenuation, a negative value indicates gain. Displayed power level values are shifted by this value.

This setting is not available for signals from the Digital Baseband Interface (R&S FSV-B17).

SCPI command:

[DISPlay\[:WINDow<n>\]:TRACe<t>:Y\[:SCALe\]:RLEVel:OFFSet](#) on page 151

Power Class ← Primary Settings ← General Settings

The following power classes are supported:

- 1, ..., 8 (BTS)
- 1, ...,5 (MS: GMSK)

- E1, E2, E3 (MS: all except GMSK)
- M1, M2, M3 (Micro BTS)
- P1 (Pico BTS)

The default power class is 2.

SCPI command:

[CONFigure\[:MS\]:POWer:CLASs](#) on page 131

Signal Source ← Primary Settings ← General Settings

The following signal sources are supported:

- RF Input
- Digital Baseband (only with Digital Baseband Interface, R&S FSV-B17)

SCPI command:

[INPut:SElect](#) on page 193

Capture Time ← Primary Settings ← General Settings

Specifies the time (and therefore the amount of IQ data) to be captured in a single measurement. If the capture time is too short, demodulation will fail. Choose e.g. 100 ms to run a measurement. Here the capture time can be entered in seconds.

Note: The duration of one GSM slot equals $15/26 \text{ ms} = 0.576923 \text{ ms}$. The duration of one GSM frame (8 slots) equals $60/13 \text{ ms} = 4.615384 \text{ ms}$.

SCPI command:

[\[SENSe:\]SWEep:TIME](#) on page 239

Synchronization ← Primary Settings ← General Settings

Sets the synchronization mode of the R&S FSV-K10.

"Burst+TSC"	First search for the power profile (burst search) according to the frame configuration in the capture buffer. Second, inside the found bursts search for the TSC of the "Slot to measure" as given in the frame configuration. "Burst +TSC" is usually faster than "TSC" for bursted signals.
"TSC"	Search the capture buffer for the TSC of the "Slot to measure" as given in the frame configuration. This mode corresponds to a correlation with the given TSC. This mode can be used for continuous (but framed) signals or bursted signals.
"Burst"	Search for the power profile (burst search) according to the frame configuration in the capture buffer. Note: For "Burst" no demodulation measurements (e.g. "Modulation Accuracy") are supported. Only "Power vs Time", "Modulation Spectrum", "Transient Spectrum" measurements are supported.

"None" Do not synchronize at all. If an external or power trigger is chosen, the trigger instant corresponds to the frame start.
 Tip: Manually adjust the trigger offset to move the burst to be analyzed under the mask in the "Power vs Time" measurement.
 Note: For "None" no demodulation measurements (e.g. "Modulation Accuracy") are supported. Only "Power vs Time", "Modulation Spectrum", "Transient Spectrum" measurements are supported.

SCPI command:

`CONFigure[:MS]:SYNC:MODE` on page 134

Measure only on Sync ← Primary Settings ← General Settings

If activated (default), only results from frames (slots) where the "Slot to measure" was found are displayed and taken into account in the averaging of the results. The behavior of this option depends on the value of the [Synchronization](#) parameter.

Note: This parameter does not affect the "Wide Modulation Spectrum" measurement (see [chapter 3.1.11, "Wide Modulation Spectrum"](#), on page 27).

SCPI command:

`CONFigure[:MS]:SYNC:ONLY` on page 135

Trigger Mode ← Primary Settings ← General Settings

The following trigger modes are supported:

- Free Run
- External
- Power
- Frequency Mask

The default mode is Free Run.

For further information refer to [chapter 3.2.6, "Trigger settings"](#), on page 38.

For more information on the Frequency Mask Trigger see [chapter 3.2.7, "Working with the Frequency Mask Trigger"](#), on page 39.

SCPI command:

`TRIGger<n>[:SEquence]:SOURce` on page 245

Trigger Offset ← Primary Settings ← General Settings

Specifies the time offset between the trigger event (e.g. for an external or power trigger) and the frame start of the GSM signal. The value can be entered either in seconds or in slots. For details refer to [chapter 3.2.6, "Trigger settings"](#), on page 38.

Note: The duration of one GSM slot equals $15/26 \text{ ms} = 0.576923 \text{ ms}$. The duration of one GSM frame (8 slots) equals $60/13 \text{ ms} = 4.615384 \text{ ms}$.

SCPI command:

`TRIGger<n>[:SEquence]:HOLDoff[:TIME]` on page 243

Statistic Count ← Primary Settings ← General Settings

In this field, the number of frames to be measured can be set. For measurements on the [Slot to Measure](#), the statistic count corresponds to the number of bursts (slots).

The default value is 200 in accordance with the GSM standard.

SCPI command:

[SENSe:] SWEep:COUNT on page 238

Advanced Settings tab ← General Settings

To modify advanced settings in more detail (e.g. to meet special measurement requirements), modify the values for this group of parameters.

Depending on the selected signal source the available parameters vary.

SENSe:FREQuency:OFFSet 0 HZ

DISPlay:WINDow1:TRACe1:Y:SCALE:RLEVEL 40 DBM

INPut1:ATTenuation 10

INPut1:ATTenuation:AUTO ON

INPut1:ATTenuation 10

INPut1:EATT:STATE ON

INPut1:EATT:AUTO ON

INPut1:EATT 0 DB

INPut1:GAIN:STATE OFF

n.a.

n.a.

n.a.

CONFigure:MS:Power:AUTO:SWEep:TIME 10 MS

TRIGger1:SEQuence:LEVEL 1.4 V

TRIGger1:SEQuence:LEVEL:IFPower -20 DBM

SENSe:SWAPiq ON

General Settings

Primary Settings **Advanced Settings**

Advanced Capture Settings - (RF Input)

Frequency Offset 0 Hz

Ref. Level 40 dBm

RF Atten. 10 dB

Mechanical Atten. Auto 10 dB

El Atten. State On

Electrical Atten. Auto 0 dB

Preamplifier

Trigger Polarity ..

IF Pow. Retrig. Holdoff ...

IF Pow. Retrig. Hysteresis ...

Auto Track Time 10 ms 17.33 slots

Trigger Level 1.4 V

Swap IQ

RF Input ← Advanced Settings tab ← General Settings

Settings for RF Input

Frequency Offset ← RF Input ← Advanced Settings tab ← General Settings

The frequency offset shifts the displayed frequency range by the specified offset.

SCPI command:

[SENSe:] FREQuency:OFFSet on page 237

Ref. Level ← RF Input ← Advanced Settings tab ← General Settings

Defines the reference level in dBm.

The reference level value is the maximum value the AD converter can handle without distortion of the measured value. Signal levels above this value will not be measured correctly, which is indicated by the "IFOVL" status display.

SCPI command:

DISPlay[:WINDow<n>]:TRACe<t>:Y[:SCALE]:RLEVEL[:RF] on page 152

RF Atten ← RF Input ← Advanced Settings tab ← General Settings

Sets the RF attenuation automatically as a function of the selected reference level. This ensures that the optimum RF attenuation is always used.

SCPI command:

[INPut:ATTenuation:AUTO](#) on page 190

[INPut:ATTenuation](#) on page 190

Mechanical Atten ← RF Input ← Advanced Settings tab ← General Settings

To set the mechanical attenuation, edit the following two fields:

- In the "MODE" dropdown menu, either "Auto" or "Manual" are available. If set to "Auto", the mechanical attenuator is set automatically by the firmware. The default value is "Auto".
- Set the manual attenuation value of the mechanical attenuator in this field.

For details see the "Mech Att Manual" softkey in the base unit.

SCPI command:

[INPut:ATTenuation](#) on page 190

[INPut:ATTenuation:AUTO](#) on page 190

EI Atten State ← RF Input ← Advanced Settings tab ← General Settings

Switches the electronic attenuator on or off. This setting is only available with option R&S FSV-B25.

When the electronic attenuator is activated, the mechanical and electronic attenuation can be defined separately. Note however, that both parts must be defined in the same mode, i.e. either both manually, or both automatically.

- To define the mechanical attenuation, use the [Mechanical Atten](#) setting.
- To define the electronic attenuation, use the [Electrical Atten](#) setting.

SCPI command:

[INPut:EATT:AUTO](#) on page 192

Electrical Atten ← RF Input ← Advanced Settings tab ← General Settings

To set the electrical attenuation, edit the following fields:

- In the "MODE" dropdown menu, either "Auto" or "Manual" are available. If set to "Auto", the electrical attenuator is set automatically by the firmware. The default value is "Auto".
- Set the manual power level of the electrical attenuator.

SCPI command:

[INPut:EATT](#) on page 191

[INPut:EATT:AUTO](#) on page 192

[INPut:EATT:STATe](#) on page 192

Preamp On/Off (option RF Preamp, B22/B24) ← RF Input ← Advanced Settings tab ← General Settings

Switches the preamplifier on or off.

If option R&S FSV-B22 is installed, the preamplifier is only active below 7 GHz.

If option R&S FSV-B24 is installed, the preamplifier is active for all frequencies.

This function is not available for input from the R&S Digital I/Q Interface (option R&S FSV-B17).

SCPI command:

[INPut:GAIN:STATe](#) on page 192

Trigger Polarity ← RF Input ← Advanced Settings tab ← General Settings
for future use

IF Pow.Retrig.Holdoff ← RF Input ← Advanced Settings tab ← General Settings
for future use

IF Pow.Retrig.Hysteresis ← RF Input ← Advanced Settings tab ← General Settings
for future use

Auto Track Time ← RF Input ← Advanced Settings tab ← General Settings
Sets the sweep time for auto level measurements or swept measurements, and the capture time for auto detection. There are separate input fields for the unit seconds and slots.

SCPI command:

[CONFigure\[:MS\]:POWer:AUTO:SWEep:TIME](#) on page 133

Trigger Level ← RF Input ← Advanced Settings tab ← General Settings

Specifies the trigger level in Volts if the instrument is in external trigger mode, or in dBm in power trigger mode.

SCPI command:

[TRIGger<n>\[:SEquence\]:LEVel:IFPower](#) on page 244

[TRIGger<n>\[:SEquence\]:LEVel\[:EXTernal\]](#) on page 244

Swap I/Q ← RF Input ← Advanced Settings tab ← General Settings

Swaps the I and Q values of the signal. Swapping I and Q inverts the sideband.

Tip: Try this function if the TSC can not be found.

"ON" I and Q are exchanged, inverted sideband, $Q+jI$

"OFF" Normal sideband, $I+jQ$

SCPI command:

[\[SENSe:\]SWAPiq](#) on page 238

Baseband digital ← Advanced Settings tab ← General Settings

Settings for Digital Baseband (only with **Digital Baseband Interface, R&S FSV-B17**)

Input Sample Rate ← Baseband digital ← Advanced Settings tab ← General Settings

Defines the sample rate of the digital I/Q signal source. This sample rate must correspond with the sample rate provided by the connected device, e.g. a generator.

SCPI command:

[INPut:DIQ:SRATe](#) on page 191

Full Scale Level ← Baseband digital ← Advanced Settings tab ← General Settings

The "Full Scale Level" defines the level that should correspond to an I/Q sample with the magnitude "1".

SCPI command:

`INPut:DIQ:RANGe [:UPPer]` on page 190

Meas Settings

Opens the "Measurement Settings" dialog box.

The "Measurement Settings" dialog box consists of the following tabs:

- "Demod tab" on page 64
- "Advanced tab" on page 71
- "Multi Meas Tab" on page 76
- "Multi Carrier tab" on page 77
- "Auto Set tab" on page 78

Demod tab ← Meas Settings

To modify parameter values related to the demodulation and frame/slot configuration, the following parameter groups are available in the "Demod" tab.


- Single-slot measurements
- Multi-slot measurements
- Frame configuration

`CONFigure:MS:CHANnel:MSLots:MEASure 0` →

`CONFigure:MS:CHANnel:MSLots:NOFSlots 1` →

`CONFigure:MS:CHANnel:MSLots:OFFSet 0` →

`CONFigure:MS:CHANnel:FRAMe:EQUal ON` →



Slot to Measure ← Demod tab ← Meas Settings

This parameter specifies the slot to be measured in single-slot measurements relative to the GSM frame boundary. The following rule applies:

$$0 \leq \text{Slot to Measure} \leq 7$$

The "Slot to Measure" is used as the (only) slot to measure in the following measurements: (see "First Slot to measure" on page 65)

- [Modulation Accuracy](#)
- [EVM vs Time](#)
- [Phase Error vs Time](#)
- [Magnitude Error vs Time](#)
- [Modulation Spectrum](#)
- [Constellation](#)

Furthermore, the "Slot to Measure" is used to measure the reference power for the following measurements:

- [Power vs Time](#)
- [Modulation Spectrum](#)
- [Transient Spectrum](#)
- [Wide Modulation Spectrum](#)

Finally, the "Slot to Measure" is used to measure the position of its TSC, which represents the timing reference for the [Power vs Time](#) mask (limit lines) of all slots.

See also [chapter 3.2.8, "Defining the Scope of the Measurement"](#), on page 43. For details on the measurement types see [chapter 3.1, "Measurements and Result Displays"](#), on page 12.

SCPI command:

`CONFigure[:MS]:CHANnel:MSLots:MEASure` on page 109

Number of Slots to measure ← Demod tab ← Meas Settings

This parameter specifies the "Number of Slots to measure" for the measurement interval of multi-slot measurements, i.e. the "Power vs. Time" and "Transient Spectrum" measurements. Between 1 and 8 consecutive slots can be measured.

See also [chapter 3.2.8, "Defining the Scope of the Measurement"](#), on page 43.

SCPI command:

`CONFigure[:MS]:CHANnel:MSLots:NOFSlots` on page 109

First Slot to measure ← Demod tab ← Meas Settings

This parameter specifies the start of the measurement interval for multi-slot measurements, i.e. "Power vs. Time" [Power vs Time](#) and [Transient Spectrum](#) measurements, relative to the GSM frame boundary. The following conditions apply:

- First Slot to measure \leq [Slot to Measure](#)
- [Slot to Measure](#) \leq First Slot to measure + [Number of Slots to measure](#) - 1

See also [chapter 3.2.8, "Defining the Scope of the Measurement"](#), on page 43.

SCPI command:

`CONFigure[:MS]:CHANnel:MSLots:OFFSet` on page 109

Equal Timeslot Length ← Demod tab ← Meas Settings

This parameter is only taken into account if "Limit Time Alignment" is set to "Slot to measure" (see "Limit Time Alignment" on page 72).

This parameter is used to adjust the time for the "Power vs Time" masks of all slots for which the "Slot to measure" is used as the time reference for the entire frame.

If activated, all slots of a frame have the same length (8 x 156.26 normal symbol periods).

If deactivated, slots number 0 and 4 of a frame have a longer duration, all others have a shorter duration compared to the "Equal Timeslot Length" (157, 156, 156, 156, 157, 156, 156, 156 normal symbol periods).

See GPP TS 51.021 and 3GPP TS 45.010 chapter "6.7 Timeslot length" for further details.

SCPI command:

CONFigure[:MS]:CHANnel:FRAME:EQUal on page 108

Frame: Select Slot to Configure ← Demod tab ← Meas Settings

This field shows a graphical representation of the configuration of each slot. Selecting a slot leads to its "Burst" dialog box (see "Burst" on page 66).

Inside the slot the following information is given:

- The burst type, e.g. "Normal (NB)" for a normal burst.
- The modulation, e.g. GMSK.

Below the slot symbol, the corresponding slot numbers (0 to 7) are displayed. The frame always starts with slot number 0. The slots beginning with the "First slot to measure" and ending with "First slot to measure" + "Number of slots to measure" – 1 are marked with a green box, while the slot specified as the "Slot to measure" is highlighted in yellow.

The parameters of a specific slot can be edited by putting the focus (blue border) on the slot and pressing the ENTER key. The "Burst" dialog box opens (see "Burst" on page 66).

Burst ← Frame: Select Slot to Configure ← Demod tab ← Meas Settings

The "Burst" dialog box opens when you select a slot to be configured in the "Demod" tab of the "Measurement Settings" (see "Frame: Select Slot to Configure" on page 66) .

In the title bar of the dialog box the selected slot number is displayed. At the top of the dialog box, the sections of the burst and their number of bits are indicated.

The screenshot shows the 'Burst @ Slot 0' dialog box. At the top, a table indicates the structure of the burst:

Tail	Data	TSC	Data	Tail	Guard
3	58	26	58	3	8.25

Below this table, the dialog box contains the following settings:

- Active:
- Burst Type: Normal (NB)
- Modulation: GMSK
- SCPIR: 0 dB
- Filter: GMSK Pulse
- Training Sequence TSC: TSC 0 (Set 1)
- User TSC: 0000 0000

On the left side of the image, several SCPI commands are listed with arrows pointing to the corresponding fields in the dialog box:

- CONFigure:MS:CHANnel:SLOT0:STATe ON → Active
- CONFigure:MS:CHANnel:SLOT0:TYPE NB → Burst Type
- CONFigure:MS:CHANnel:SLOT0:MTYPE GMSK → Modulation
- CONFigure:MS:CHANnel:SLOT0:SCPIr 4 → SCPIR
- CONFigure:MS:CHANnel:SLOT0:FILTer GMSK → Filter
- CONFigure:MS:CHANnel:SLOT0:TSC 1 → Training Sequence TSC
- CONFigure:MS:CHANnel:SLOT0:TSC:USER '101...0' → User TSC

Active ← **Burst** ← **Frame: Select Slot to Configure** ← **Demod tab** ← **Meas Settings**
 Activates or deactivates the selected slot.

SCPI command:

[CONFigure\[:MS\]:CHANnel:SLOT<s>\[:STATe\]](#) on page 110

Burst Type ← **Burst** ← **Frame: Select Slot to Configure** ← **Demod tab** ← **Meas Settings**

Assigns a burst type to the selected slot. The following burst types are supported:

- Normal (NB)
- Higher Symbol Rate (HB)
- Access Burst (AB)

SCPI command:

[CONFigure\[:MS\]:CHANnel:SLOT<s>:TYPE](#) on page 119

Modulation ← **Burst** ← **Frame: Select Slot to Configure** ← **Demod tab** ← **Meas Settings**

Select the modulation to be used in the slot. The available selections depend on the burst type. The following modulation types are supported, depending on the burst type:

Modulation	Normal Burst (NB)	Higher Symbol Rate (HB)	Access Burst (AB)
GMSK	x	-	x
QPSK	-	x	-
8PSK	x	-	-
16QAM	x	x	-
32QAM	x	x	-
AQPSK	x	-	-

SCPI command:

[CONFigure\[:MS\]:CHANnel:SLOT<s>:MTYPE](#) on page 110

SCPIR ← **Burst** ← **Frame: Select Slot to Configure** ← **Demod tab** ← **Meas Settings**
 This parameter is only available for AQPSK modulation.

It specifies the Subchannel Power Imbalance Ratio (SCPIR). The value of SCPIR affects the shape of the AQPSK constellation (see [chapter 3.2.4, "AQPSK Modulation"](#), on page 37). For an SCPIR of 0 dB the constellation is square (as in "normal" QPSK), while for other values of SCPIR the constellation becomes rectangular.

SCPI command:

[CONFigure\[:MS\]:CHANnel:SLOT<s>:SCPIr](#) on page 112

Filter ← **Burst** ← **Frame: Select Slot to Configure** ← **Demod tab** ← **Meas Settings**
 Specifies the pulse shape of the modulator. The following filter types are supported:

- GMSK Pulse
- Linearised GMSK Pulse
- Narrow Pulse

- Wide Pulse

SCPI command:

[CONFigure\[:MS\]:CHANnel:SLOT<s>:FILTer](#) on page 110

Training Sequence TSC ← **Burst** ← **Frame: Select Slot to Configure** ← **Demod tab**
← **Meas Settings**

Selects the training sequence and the set of a single slot. The available values depend on the modulation as indicated in the table below.

For user-defined TSCs, select "User" and define the training sequence in "[User TSC](#)" on page 69.

Note: For AQPSK modulation, the training sequence is defined for each subchannel, see "[Training Sequence TSC](#)" on page 70.

Modulation	TSC
GMSK	TSC 0 (Set 1) TSC 1 (Set 1) TSC 2 (Set 1) TSC 3 (Set 1) TSC 4 (Set 1) TSC 5 (Set 1) TSC 6 (Set 1) TSC 7 (Set 1) TSC 0 (Set 2) TSC 1 (Set 2) TSC 2 (Set 2) TSC 3 (Set 2) TSC 4 (Set 2) TSC 5 (Set 2) TSC 6 (Set 2) TSC 7 (Set 2) TS 0 (Access Burst) TS 1 (Access Burst) TS 2 (Access Burst) USER
QPSK, 8PSK, 16QAM, 32QAM	TSC 0 TSC 1 TSC 2 TSC 3 TSC 4 TSC 5 TSC 6 TSC 7
User	user-defined TSCs (" User TSC " on page 69)

SCPI command:

[CONFigure\[:MS\]:CHANnel:SLOT<s>:TSC](#) on page 116

User TSC ← Burst ← Frame: Select Slot to Configure ← Demod tab ← Meas Settings

Sets the bits of the user-defined TSC. The number of bits depend on the burst type and the modulation and is indicated in the table below.

Note: For AQPSK modulation, the user-defined TSC is defined for each subchannel, see "[User TSC](#)" on page 71.

Table 3-9: Number of TSC bits depending on burst type and modulation

Burst Type	Modulation	Number of Bits
Normal	GMSK	26
Normal	8PSK	78
Normal	16QAM	104
Normal	32QAM	130
Higher Symbol Rate	QPSK	62
Higher Symbol Rate	16QAM	124
Higher Symbol Rate	32QAM	155
Access Burst	GMSK	41

SCPI command:

CONFigure[:MS]:CHANnel:SLOT<s>:TSC:USER on page 118

Subchannel 1/2 ← Burst ← Frame: Select Slot to Configure ← Demod tab ← Meas Settings

For AQPSK modulation, the training sequence and user-defined TSC are defined for each subchannel.

CONFigure:MS:CHANnel:SLOT0:STATE ON → Active
 CONFigure:MS:CHANnel:SLOT0:TYPE NB → Burst Type
 CONFigure:MS:CHANnel:SLOT0:MTYPE AQPSk → Modulation
 CONFigure:MS:CHANnel:SLOT0:SCPIr 4 → SCPIR
 CONFigure:MS:CHANnel:SLOT0:FILTer LINearised → Filter

 CONFigure:MS:CHANnel:SLOT0:SUBChannell:TSC 0,1 → Training Sequence TSC
 CONFigure:MS:CHANnel:SLOT0:SUBChannell:TSC:USER '01..0' → User TSC

 CONFigure:MS:CHANnel:SLOT0:SUBChannell2:TSC 0,2 → Training Sequence TSC
 CONFigure:MS:CHANnel:SLOT0:SUBChannell2:TSC:USER '01..0' → User TSC

Training Sequence TSC ← Subchannel 1/2 ← Burst ← Frame: Select Slot to Configure ← Demod tab ← Meas Settings

Selects the training sequence and the set of the selected subchannel of a single slot for AQPSK modulation.

"TSC 0...TSC 7 (Set 1/2)"

Selects a standard TSC of Set 1/2 that complies with the GSM standard. For subchannel 1, only "Set 1" is available.

"USER"

Selects a user-defined TSC (see "User TSC" on page 71).

SCPI command:

CONFigure[:MS]:CHANnel:SLOT<s>:SUBChannell<ch>:TSC on page 114

User TSC ← Subchannel 1/2 ← Burst ← Frame: Select Slot to Configure ← Demod tab ← Meas Settings

Sets the 26 bits of the user-defined TSC of the selected subchannel for AQPSK modulation.

SCPI command:

CONFigure[:MS]:CHANnel:SLOT<s>:SUBChannel<ch>:TSC:USER on page 115

Advanced tab ← Meas Settings

This tab contains settings related to the [Power vs Time](#), [Modulation Spectrum](#) and [Transient Spectrum](#) measurements.

CONFigure:BURSt:PTEmplate:FiLTER G1000 →	PvT Filter	1 MHz Gauss
CONFigure:BURSt:PTEmplate:TALign STM →	Limit Time Alignment	Slot to measure
CONFigure:SPECTrum:LIMit:LEFt ON →	Enable Left Limit	<input checked="" type="checkbox"/>
CONFigure:SPECTrum:LIMit:RIGHt ON →	Enable Right Limit	<input checked="" type="checkbox"/>
SENSE:BANdwidth:RESolution:TYPE P5 →	Filter Type	5-Pole
CONFigure:SPECTrum:SWITChing:TYPE RMS →	Transient Ref. Power	RMS
CONF:SPEC:MOD:LIST:RES:BW 1800000,30000 →	Mod. RBW @ 1800 kHz	30 kHz
CONFigure:SPECTrum:HDYnamic OFF →	High Dynamic	<input type="checkbox"/>
CONF:WSP:MOD:LIST:SEL WIDE →	Wide Mod. Freq. List	Wide
CONFigure:TRGS:NOFBins 10 →	No. of Bins	10
CONFigure:TRGS:ADPSize 100 →	Adaptive Data Size	100
CONFigure:MS:SYNC:IQCThreshold 85 →	IQ Correlation Threshold	85 %
CONFigure:MS:DEMod:DECision AUTO →	Symbol Decision	Auto
CONFigure:MS:DEMod:STDBits DETected →	Tail & TSC Bits	Detected

PvT Filter ← Advanced tab ← Meas Settings

The PvT Filter controls the filter used to reduced the measurement bandwidth for single carrier "Power vs Time" measurements. The parameter is only available if "Multi Carrier BTS" is switched off (see ["Multi Carrier BTS"](#) on page 77). For single-carrier measurements, the "PvT Filter" parameter in the "Multi Carrier" tab is ignored (see ["PvT Filter"](#) on page 78).

"1 MHz Gauss"

default

"500 kHz Gauss"

for backwards compatibility to FS-K5

"600 kHz"

for backwards compatibility to FS-K5

SCPI command:

[CONFigure:BURSt:PTEMplate:FILTer](#) on page 137

Limit Time Alignment ← **Advanced tab** ← **Meas Settings**

The Limit Time Alignment controls how the limit lines are aligned in a "Power vs Time" measurement graph (see [chapter 3.1.8, "Power vs Time"](#), on page 20). Limit lines are defined for each slot. The limit lines are time-aligned in each slot, based on the position of the TSC (the center of the TSC is the reference point). This parameter affects how the center of the TSC is determined for each slot:

- **Slot to measure** (default): For each slot the center of the TSC is derived from the measured center of the TSC of the "Slot to measure" and the timeslot lengths specified in the standard (see "Timeslot length" in 3GPP TS 45.010 and "[Slot to Measure](#)" on page 65).
- **Per Slot**: For each slot the center of the TSC is measured. This provides reasonable time-alignment if the slot lengths are not according to standard. Note that in this case the "Power vs Time" limit check may show "pass" even if the timeslot lengths are not correct according to the standard.

Note: The "Limit Time Alignment" also decides whether the "Delta to sync" values of the "Power vs Time" list result are measured (for "Limit Time Alignment" = "Per Slot") or if they are constant as defined by the 3PP standard (for "Limit Time Alignment" = "Slot to measure").

The R&S FSV-K10 option offers a strictly standard-conformant, multiple-slot PvT limit line check. This is based on time alignment to a single specified slot (the "Slot to Measure") and allows the user to check for correct BTS timeslot alignment in the DUT, according to the GSM standard. In addition, a less stringent test which performs PvT limit line alignment on a per-slot basis ("Per Slot") is also available.

SCPI command:

[CONFigure:BURSt:PTEMplate:TALign](#) on page 138

Enable Left Limit ← **Advanced tab** ← **Meas Settings**

This parameter controls the left limit check of the spectrum trace (spectrum graph measurement) and which offset frequencies in the table (spectrum list measurement) are checked against the limit. This parameter effects the [Modulation Spectrum](#) and [Transient Spectrum](#) measurements.

Note: For measurements on multi-carrier signals, using either the check on the left or right side allows you to measure the spectrum of the left or right-most channel while ignoring the side where adjacent channels are located.

SCPI command:

[CONFigure:SPECTrum:LIMit:LEFT](#) on page 140

Enable Right Limit ← **Advanced tab** ← **Meas Settings**

This parameter controls the right limit check of the spectrum trace (spectrum graph measurement) and which offset frequencies in the table (spectrum list measurement) are checked against the limit. This parameter effects the [Modulation Spectrum](#) and [Transient Spectrum](#) measurements.

Note: For measurements on multi-carrier signals, using either the check on the left or right side allows you to measure the spectrum of the left or right-most channel while ignoring the side where adjacent channels are located.

SCPI command:

`CONFigure:SPECTrum:LIMit:RIGHT` on page 141

Filter Type ← Advanced tab ← Meas Settings

This parameter sets the filter type for the resolution filter to "Normal" (3 dB Gauss filter) or a 5-pole (according to the GSM standard) filter for the "Modulation Spectrum", "Transient Spectrum" and "Wide Modulation Spectrum" measurements.

SCPI command:

`[SENSe]:BANDwidth[:RESolution]:TYPE` on page 236

Transient Ref. Power ← Advanced tab ← Meas Settings

This parameter controls how the reference power of the "Transient Spectrum" measurement (see [chapter 3.1.10, "Transient Spectrum"](#), on page 26) is measured.

Note: To perform the measurement according to the 3GPP standard set "Transient Ref. Power" to RMS and the [PVT Filter](#) to the slot with the highest power.

See 3GPP TS 45.005, chapter "4 Transmitter characteristics":

For GMSK modulation, the term output power refers to the measure of the power when averaged over the useful part of the burst (see annex B).

For QPSK, AQPSK, 8-PSK, 16-QAM and 32-QAM modulation, the term "output power" refers to a measure that, with sufficient accuracy, is equivalent to the long term average of the power when taken over the useful part of the burst as specified in 3GPP TS 45.002 with any fixed TSC and with random encrypted bits.

See 3GPP TS 51.021, chapter "6.5.2 Switching transients spectrum":

The reference power for relative measurements is the power measured in a bandwidth of at least 300 kHz for the TRX under test for the time slot in this test with the highest power.

"RMS" (Default:) The reference power is the RMS power level measured over the useful part of the "Slot to measure" (see ["Slot to Measure"](#) on page 65) and averaged according to the defined "Statistic Count" (see ["Statistic Count"](#) on page 60).

"Peak" The reference power is the peak power level measured over the selected slot scope (see [chapter 3.2.8, "Defining the Scope of the Measurement"](#), on page 43) and its peak taken over [Statistic Count](#) measurements (GSM frames).

SCPI command:

`CONFigure:SPECTrum:SWITching:TYPE` on page 145

Mod. RBW @ 1800 kHz ← Advanced tab ← Meas Settings

The modulation RBW at 1800 kHz controls the resolution bandwidth (RBW) and video bandwidth (VBW) used in the [Modulation Spectrum](#) and [Wide Modulation Spectrum](#) measurements at offset frequencies of +/- 1800 kHz from the carrier.

"30 kHz" (Default) RBW and VBW are set to 30 kHz for offset frequencies at +/- 1800 kHz from the carrier

"100 kHz" RBW and VBW are set to 100 kHz for offset frequencies at +/- 1800 kHz from the carrier

SCPI command:

[CONFigure:SPECTrum:MODulation:LIST:BANDwidth:RESolution](#)

on page 142

High Dynamic ← **Advanced tab** ← **Meas Settings**

If activated, the results of the (I/Q-based) [Modulation Spectrum](#) measurement are corrected by the instrument's inherent noise, which increases the dynamic range.

When "High Dynamic" is activated, a measurement of the instrument's inherent noise is automatically carried out. The instrument's inherent noise is then removed from the measured results. The inherent noise of the instrument depends on the selected center frequency and level setting. Therefore the measurement of the inherent noise is repeated whenever one of these parameters is changed.

In addition, for instruments with (early) detector boards with an even hardware code (see column "HWC" in the hardware information dialog) phase noise is reduced (at 600 kHz offset frequencies).

Note: For best performance for modulation accuracy measurements on instruments with early detector boards, deactivate the "High Dynamic" mode.

SCPI command:

[CONFigure:SPECTrum:HDYNamic](#) on page 140

Wide Mod. Freq. List ← **Advanced tab** ← **Meas Settings**

For [Wide Modulation Spectrum](#) measurements, the wide modulation frequency list controls whether offset frequencies are measured up to 1800 kHz or 5800 kHz.

"Narrow" The measurement is performed for offset frequencies up to 1800 kHz from the carrier; this setting improves measurement speed

"Wide" (Default) The measurement is performed for offset frequencies up to 5800 kHz from the carrier

SCPI command:

[CONFigure:WSPectrum:MODulation:LIST:SElect](#) on page 148

No. of Bins ← **Advanced tab** ← **Meas Settings**

This parameter specifies the number of bins for the histogram of the "Trigger to Sync" measurement.

SCPI command:

[CONFigure:TRGS:NOFBins](#) on page 146

Adaptive Data Size ← **Advanced tab** ← **Meas Settings**

This parameter specifies the number of measurements (I/Q captures) after which the x-axis is fixed for the histogram calculation of the "Trigger to Sync" measurement.

SCPI command:

[CONFigure:TRGS:ADPSize](#) on page 145

IQ Correlation Threshold ← Advanced tab ← Meas Settings

This threshold determines whether a burst is accepted if [Measure only on Sync](#) is activated. If the correlation value between the ideal IQ signal of the given TSC and the measured TSC is below the IQ correlation threshold, then the application reports "Sync not found" in the status bar. Additionally, such bursts are ignored if "Measure only on Sync" is activated.

Note: If the R&S FSV-K10 is configured to measure GMSK normal bursts, a threshold below 97% will also accept 8PSK normal bursts (with the same TSC) for analysis. In this case, activate [Measure only on Sync](#) and set the IQ Correlation Threshold to 97%. This will exclude the 8PSK normal bursts from the analysis.

SCPI command:

[CONFigure\[:MS\]:SYNC:IQThreshold](#) on page 134

Symbol Decision ← Advanced tab ← Meas Settings

The symbol decision determines how the symbols are detected in the demodulator. The setting of this parameter does not effect the demodulation of normal bursts with GMSK modulator. For normal bursts with 8PSK, 16QAM, 32QAM or AQPSK modulation or Higher Symbol Rate bursts with QPSK, 16QAM or 32QAM modulation use this parameter to get a trade-off between performance (symbol error rate of the R&S FSV-K10) and measurement speed.

"Auto"	Automatically selects the symbol decision method.
"Linear"	Linear symbol decision: Uses inverse filtering (a kind of zero-forcing filter) and a symbol-wise decision method. This method is recommended for high symbol to noise ratios, but not for Higher Symbol Rate bursts with a narrow pulse. The inverse filter colors the noise inside the signal bandwidth and therefore is not recommended for narrow-band signals or signals with a low signal to noise ratio. Peaks in the "EVM vs Time" measurement (see chapter 3.1.4, "EVM vs Time" , on page 15) may occur if the "Linear" symbol decision algorithm fails. In that case use the "Sequence" method. Linear is the fastest option.
"Sequence"	Symbol decision via sequence estimation. This method uses an algorithm that minimizes the symbol errors of the entire burst. It requires that the tail bits in the analyzed signal are correct. It has a better performance (lower symbol error rate) compared to the "Linear" method, especially at low signal to noise ratios, but with a loss of measurement speed. This method is recommended for normal bursts with 16QAM or 32QAM modulation and for Higher Symbol Rate bursts with a narrow pulse.

SCPI command:

[CONFigure\[:MS\]:DEMod:DECision](#) on page 120

Tail & TSC Bits ← Advanced tab ← Meas Settings

The R&S FSV-K10 demodulator requires the bits of the burst (Tail, Data, TSC, Data, Tail) to provide an ideal version of the measured signal. The "Data" bits can be random and are typically not known inside the demodulator of the R&S FSV-K10. "Tail" and "TSC" bits are specified in the "Burst" dialog box (see ["Burst"](#) on page 66).

"Detected" The detected Tail and TSC bits are used to construct the ideal signal.


"Standard" The standard Tail and TSC bits (as set in the "Burst" dialog box) are used to construct the ideal signal. Using the standard bits can be advantageous to verify whether the device under test sends the correct Tail and TSC bits. Incorrect bits would lead to peaks in the "EVM vs Time" trace (see [chapter 3.1.4, "EVM vs Time"](#), on page 15) at the positions of the incorrect bits.

SCPI command:

`CONFigure[:MS]:DEMod:STDBits` on page 122

Multi Meas Tab ← Meas Settings

This tab allows you to perform several measurements at once.



Multiple Measurement Mode active ← Multi Meas Tab ← Meas Settings

Activates the multiple measurement mode. In this mode, several measurement results can be calculated on the same captured I/Q data in parallel. Only the results of the selected measurements are available. The softkeys for the other measurements only become available again when you deactivate multiple measurement mode or include the measurement in the multiple measurement selection.

Use this mode to reduce total measurement time if you know in advance which measurement results are required.

SCPI command:

`CONFigure[:MS]:MULTi:STAtE` on page 128

Power vs Time ← Multi Meas Tab ← Meas Settings

If enabled, the results of the "Power vs Time" measurement (see [chapter 3.1.8, "Power vs Time"](#), on page 20) are included in an active multiple measurement.

SCPI command:

`CONFigure[:MS]:MULTi:BURSt:PTEMplate` on page 127

Demod ← Multi Meas Tab ← Meas Settings

If enabled, the results of the "Modulation Accuracy", "EVM vs Time", "Phase Error vs Time" and "Magnitude Error vs Time" measurements are included in an active multiple measurement.

See:

[chapter 3.1.2, "Modulation Accuracy"](#), on page 13

[chapter 3.1.4, "EVM vs Time"](#), on page 15

[chapter 3.1.3, "Phase Error vs Time"](#), on page 14

[chapter 3.1.5, "Magnitude Error vs Time"](#), on page 17

SCPI command:

`CONFigure[:MS]:MULTi:BURSt:DEModulation` on page 127

Constellation ← Multi Meas Tab ← Meas Settings

If enabled, the results of the "Constellation" measurement (see [chapter 3.1.6, "Constellation"](#), on page 18) are included in an active multiple measurement.

SCPI command:

`CONFigure[:MS]:MULTi:BURSt:CONStell` on page 126

Modulation Spectrum ← Multi Meas Tab ← Meas Settings

If enabled, the results of the "Modulation Spectrum" measurement (see [chapter 3.1.9, "Modulation Spectrum"](#), on page 23) are included in an active multiple measurement.

Note: By default, list results are calculated. To receive graph results, set the "Display List/Graph" softkey to "Graph" (see ["Display List/Graph"](#) on page 84).

SCPI command:

`CONFigure[:MS]:MULTi:SPECTrum:MODulation` on page 127

Transient Spectrum ← Multi Meas Tab ← Meas Settings

If enabled, the results of the "Transient Spectrum" measurement (see [chapter 3.1.10, "Transient Spectrum"](#), on page 26) are included in an active multiple measurement.


Note: By default, list results are calculated. To receive graph results, set the "Display List/Graph" softkey to "Graph" (see ["Display List/Graph"](#) on page 84).

SCPI command:

`CONFigure[:MS]:MULTi:SPECTrum:SWITChing` on page 128

Multi Carrier tab ← Meas Settings

This tab provides settings related to measurements on multi-carrier base stations.



Multi Carrier BTS ← Multi Carrier tab ← Meas Settings

This parameter informs the R&S FSV-K10 that the measured signal is a multi-carrier signal. This function is only available if the "Device Type" is a "BTS" type (see ["Device Under Test: Type"](#) on page 57).

Activating this checkbox has the following effects:

- An additional multi-carrier filter is switched into the demodulation path of the R&S FSV-K10. This filter can, for example, suppress up to six adjacent channels with

a channel spacing of 600 kHz from the measured channel (at the set center frequency) and 30 dB higher power compared to the measured channel. This filter is also taken into account during the generation of the ideal (reference) signal in order to get meaningful EVM values. (Otherwise there would be an increase in EVM because the measured signal has a smaller bandwidth compared to the reference signal).

- Additional multi-carrier parameters become available.

SCPI command:

[CONFigure\[:MS\]:MCArrier:MCBTs](#) on page 125

No. of active Carriers ← Multi Carrier tab ← Meas Settings

Specifies the total number of active carriers of the multi-carrier BTS to be measured. Its value affects the calculation of the limits according to the 3GPP standard for the modulation spectrum measurement, see 3GPP2 TS 45.005 (chapter 4.2.1. "Spectrum due to modulation and wide band noise"). The limit is relaxed by $10 \cdot \log(N)$ dB for frequencies ≥ 1.8 MHz.

SCPI command:

[CONFigure\[:MS\]:MCArrier:ACTCarriers](#) on page 124

BTS Class ← Multi Carrier tab ← Meas Settings

For future use.

SCPI command:

[CONFigure\[:MS\]:MCArrier:BTSClass](#) on page 124

PvT Filter ← Multi Carrier tab ← Meas Settings

Controls the filter used to reduced the measurement bandwidth for multi-carrier "Power vs Time" measurements. For multi-carrier BTS measurements, the PvT Filter parameter in the "Advanced" tab is ignored (see "PvT Filter" on page 71).

For further details on filtering in the R&S FSV-K10 see [chapter 3.2.9, "Overview of filters in R&S FSV-K10"](#), on page 44.

The following filters are supported:

Note: The PvT filter is optimized to get smooth edges after filtering burst signals and to suppress adjacent, active channels.

"400 kHz MC" (default) Recommended for measurements with multi channels of equal power.


"300 kHz MC" Recommended for measurement scenarios where a total of six channels is active and the channel to be measured has a reduced power (e.g. 30 dB) compared to its adjacent channels.

SCPI command:

[CONFigure\[:MS\]:MCArrier:FILTer](#) on page 124

Auto Set tab ← Meas Settings

Select the parameters to be set automatically when you press the AUTO SET key or "Auto Set" softkey.



Level ← Auto Set tab ← Meas Settings

When activated, a single auto level measurement is performed when the AUTO SET key is pressed.

Press the button to perform a single auto level measurement immediately.

SCPI command:

`CONF:AUTO:LEV ON`: Execute Auto Level on Auto Set.

`CONF:AUTO:LEV OFF`: Do not execute Auto Level on Auto Set.

`CONF:AUTO:LEV ONCE`: Perform one Auto Level measurement immediately.

see [CONFfigure\[:MS\]:AUTO:LEVel](#) on page 106

Frame Configuration ← Auto Set tab ← Meas Settings

When activated, a single auto frame configuration measurement is performed when the AUTO SET key is pressed.

The auto frame configuration measurement may take a long time, therefore it is deactivated by default. The following parameters are detected and automatically measured:

- Active slots
- Slot configuration (burst type, modulation, filter, TSC)
- Equal time slot length
- For VAMOS normal burst and GMSK: TSCs of set 1 and set 2
- For VAMOS normal burst and AQPSK: TSCs of both subchannels (restrictions see [table 3-6](#)) and SCPIR

Press the button to perform a single auto frame configuration measurement immediately.

Note: The auto frame configuration typically does not work with frequency hopping systems, unless the trigger offset is set correctly. In this case not every frame is populated by a modulated GSM signal. A workaround is to use auto frame configuration with a manually set trigger offset:

- Set "Synchronization" = "None"
- Set the trigger offset manually in the "Power vs Time" measurement.
- Set "Synchronization" back to "Burst + TSC" or "TSC".
- Deactivate the "Trigger" check box in the "Auto Set" tab.

- Press the AUTO SET key to run the auto frame configuration measurement.

SCPI command:

CONF:AUTO:FRAM ON: Execute Auto Frame Configuration on Auto Set.

CONF:AUTO:FRAM OFF: Do not execute Auto Frame Configuration on Auto Set.

CONF:AUTO:FRAM ONCE: Perform one Auto Frame Configuration measurement immediately.

see [CONFigure\[:MS\]:AUTO:FRAMe](#) on page 106

Trigger ← Auto Set tab ← Meas Settings

If activated, the following parameters are detected and automatically measured when the AUTO SET key is pressed:

- Trigger Offset (for external and IF power trigger)
- Trigger Level (for IF power trigger only)

For details on the parameters refer to "[General Settings](#)" on page 56.

SCPI command:

CONF:AUTO:TRIG ON: Execute Auto Trigger on Auto Set.

CONF:AUTO:TRIG OFF: Do not execute Auto Trigger on Auto Set.

CONF:AUTO:TRIG ONCE: Perform one Auto Trigger measurement immediately.

see [CONFigure\[:MS\]:AUTO:TRIGger](#) on page 107

Demod

Opens a demodulation submenu.

This softkey is only available if the "Synchronization" setting is set to "TSC" or "Burst +TSC" (General Settings, see "[Synchronization](#)" on page 59).

General Settings ← Demod

For details refer to the "[General Settings](#)" on page 56 softkey in the root menu of the GSM option.

Meas Settings ← Demod

For details refer to the "[Meas Settings](#)" on page 64 softkey in the root menu of the GSM option.

Modulation Accuracy ← Demod

Displays the Modulation Accuracy measurement results.

For details on the measurement refer to [chapter 3.1.2, "Modulation Accuracy"](#), on page 13.

Note: Modulation Accuracy results can be included in multiple measurements (see "[Multi Meas Tab](#)" on page 76). In this case, you do not need to start a new measurement.

If the "Modulation Accuracy" softkey is not available, include "Demod" in the multiple measurement selection or disable the multiple measurement mode.

SCPI command:

[CONFigure:BURSt:MACCuracy\[:IMMediate\]](#) on page 136

EVM ← Demod

Displays the "EVM vs Time" measurement results. For details on the measurements refer to [chapter 3.1.4, "EVM vs Time"](#), on page 15.

Note: EVM vs Time results can be included in multiple measurements (see "[Multi Meas Tab](#)" on page 76). In this case, you do not need to start a new measurement. If the "EVM vs Time" softkey is not available, include "Demod" in the multiple measurement selection or disable the multiple measurement mode.

SCPI command:

[CONFigure:BURSt:ETIME\[:IMMEDIATE\]](#) on page 136

Phase Error ← Demod

Displays the "Phase Error vs Time" measurement results. For details on the measurements refer to [chapter 3.1.3, "Phase Error vs Time"](#), on page 14.

Note: Phase Error vs Time results can be included in multiple measurements (see "[Multi Meas Tab](#)" on page 76). In this case, you do not need to start a new measurement. If the "Phase Error" softkey is not available, include "Demod" in the multiple measurement selection or disable the multiple measurement mode.

SCPI command:

[CONFigure:BURSt:PFERror\[:IMMEDIATE\]](#) on page 137

Magnitude Error ← Demod

Displays the magnitude error measurement results. For details see [chapter 3.1.5, "Magnitude Error vs Time"](#), on page 17.

Note: Magnitude Error vs Time results can be included in multiple measurements (see "[Multi Meas Tab](#)" on page 76). In this case, you do not need to start a new measurement. If the "Magnitude Error" softkey is not available, include "Demod" in the multiple measurement selection or disable the multiple measurement mode.

SCPI command:

[CONFigure:BURSt:MERRor\[:IMMEDIATE\]](#) on page 137

Constell ← Demod

Displays the "Constellation" measurement results. For details see [chapter 3.1.6, "Constellation"](#), on page 18.

Note: Constellation diagrams can be included in multiple measurements (see "[Multi Meas Tab](#)" on page 76). In this case, you do not need to start a new measurement. If the "Constell" softkey is not available, include "Constellation" in the multiple measurement selection or disable the multiple measurement mode.

SCPI command:

[CONFigure:BURSt:CONStell\[:IMMEDIATE\]](#) on page 136

Trigger to Sync ← Demod

Displays the "Trigger to Sync" measurement results. For details see [chapter 3.1.7, "Trigger to Sync"](#), on page 19.

Note: The "Trigger to Sync" measurement is only available when using external trigger mode.

SCPI command:

[CONFigure:TRGS\[:IMMediate\]](#) on page 146

R&S Support ← Demod

See "[R&S Support](#)" on page 89

PvT

Opens the submenu for "Power vs Time" settings, starts the measurement and displays the measurement results. See also [chapter 3.1.8, "Power vs Time"](#), on page 20.

Note: Power vs. Time results can be included in multiple measurements (see "[Multi Meas Tab](#)" on page 76). In this case, you do not need to start a new measurement.

If the "PvT" softkey is not available, include "Power vs. Time" in the multiple measurement selection or disable the multiple measurement mode.

SCPI command:

[CONFigure:BURSt:PTEMplate\[:IMMediate\]](#) on page 137

General Settings ← PvT

For details refer to the "[General Settings](#)" on page 56 softkey in the root menu of the GSM option.

Meas Settings ← PvT

For details refer to the "[Meas Settings](#)" on page 64 softkey in the root menu of the GSM option.

Full ← PvT

Switches the "Power vs Time" measurement to the "full burst" view.

SCPI command:

`CONF:BURS:PTEM:SEL FULL`, see [CONFigure:BURSt:PTEMplate:SElect](#) on page 138

Rising ← PvT

Switches the "Power vs Time" measurement to a view of the rising edges only (the rest of the burst is removed).

SCPI command:

`CONF:BURS:PTEM:SEL RIS`, see [CONFigure:BURSt:PTEMplate:SElect](#) on page 138

Falling ← PvT

Switches the "Power vs Time" measurement to a view of the falling edges only (the rest of the burst is removed).

SCPI command:

`CONF:BURS:PTEM:SEL FALL`, see [CONFigure:BURSt:PTEMplate:SElect](#) on page 138

Rise & Fall ← PvT

Switches the "Power vs Time" measurement to the "rise & fall" view, i.e. only rising and falling edges of the bursts are displayed.

SCPI command:

CONF:BURS:PTEM:SEL FRIS, see [CONFigure:BURSt:PTEMplate:SElect](#) on page 138

Top ← PvT

Switches the "Power vs Time" measurement to the "top" view, i.e. the useful part of the bursts are shown with a zoomed y-axis.

SCPI command:

CONF:BURS:PTEM:SEL TOP, see [CONFigure:BURSt:PTEMplate:SElect](#) on page 138

R&S Support ← PvT

See "[R&S Support](#)" on page 89

Spectrum

Opens a submenu for spectrum measurement settings.

General Settings ← Spectrum

For details refer to the [General Settings](#) softkey in the root menu of the GSM option.

Meas Settings ← Spectrum

For details refer to the [Meas Settings](#) softkey in the root menu of the GSM option.

Modulation Spectrum ← Spectrum

Displays the "Modulation Spectrum" measurement results.

For details on the measurement refer to [chapter 3.1.9, "Modulation Spectrum"](#), on page 23.

Note: Modulation Spectrum results can be included in multiple measurements (see "[Multi Meas Tab](#)" on page 76). In this case, you do not need to start a new measurement. If the "Modulation Spectrum" softkey is not available, include "Modulation Spectrum" in the multiple measurement selection or disable the multiple measurement mode.

SCPI command:

[CONFigure:SPECTrum:MODulation\[:IMMediate\]](#) on page 141

Transient Spectrum ← Spectrum

Displays the "Transient Spectrum" measurement results.

For details on the measurement refer to [chapter 3.1.10, "Transient Spectrum"](#), on page 26.

Note: Transient Spectrum results can be included in multiple measurements (see "[Multi Meas Tab](#)" on page 76). In this case, you do not need to start a new measurement. If the "Transient Spectrum" softkey is not available, include "Transient Spectrum" in the multiple measurement selection or disable the multiple measurement mode.

SCPI command:

[CONFigure:SPECTrum:SWITching\[:IMMediate\]](#) on page 144

Display List/Graph ← Spectrum

Sets the display mode of the "Modulation Spectrum" and the "Transient Spectrum" measurements.

"List" Spectrum results are measured at several frequency offsets from the center frequency. The results are displayed in a table.

"Graph" A spectrum trace is measured and displayed as a graph.

SCPI command:

[CONFigure:SPECTrum:SElect](#) on page 143

R&S Support ← Spectrum

See ["R&S Support"](#) on page 89

Wide Spectrum

Displays a menu for "Wide Spectrum" measurements.

Note: "Wide Spectrum" measurements are performed using the "Spectrum" mode and thus require either an external or IF power trigger.

General Settings ← Wide Spectrum

See ["General Settings"](#) on page 56

Meas Settings ← Wide Spectrum

See ["Meas Settings"](#) on page 64

Wide Mod Spectrum ← Wide Spectrum

Starts a "Wide Modulation Spectrum" measurement (see [chapter 3.1.11, "Wide Modulation Spectrum"](#), on page 27).

SCPI command:

[CONFigure:WSpectrum:MODulation\[:IMMEDIATE\]](#) on page 146

Import

Opens the "Choose the file to import" dialog box.

Select the IQ data file you want to import and press ENTER. The extension of data files is *.iqw.

This function is not available while a measurement is running.

I/Q data is imported into the capture buffer. Then evaluation of the data including averaging (according to [Statistic Count](#)) is started. Averaging automatically stops when the defined "Statistic Count" or the end of the captured data is reached.

To automatically detect the frame/slot configuration of the imported I/Q data, press the AUTO SET key after import (see also ["Frame Configuration"](#) on page 79).

Example: Saving I/Q data to an iqw file using MATLAB for import to the R&S FSVR-K10 option

Note:

- I/Q values are in the unit Volt
- Sample rate = 6.5 MHz
- Minimum number of complex samples = 68751 (10 ms capture time)
- Maximum number of complex samples = 6503751 (1 s capture time)
- The data order of the float values in the iqw file is III...QQQ...

```
IQ = randn(1,68751)+1i*randn(1,68751); % Example for I/Q data
iq_interleaved = [real(IQ(:)) ; imag(IQ(:)) ];
fid = fopen('IQ_for_import_into_K10.iqw','w');
fwrite(fid,single(iq_interleaved),'float32');
fclose(fid);
```

SCPI command:

[MMEMory:LOAD:IQ:STATe](#) on page 194

not available

Export

Opens the "Choose the file to export" dialog box.

Enter the path and the name of the I/Q data file you want to export and press ENTER. The extension of data files is *.iqw. If the file cannot be created or if there is no valid I/Q data to export an error message is displayed.

This function is not available while a measurement is running.

Example: Loading I/Q data exported from the R&S FSVR-K10 option using MATLAB

Note:

- I/Q values are in the unit Volt
- Sample rate = 6.5 MHz
- Minimum number of complex samples = 68751 (10 ms capture time)
- Maximum number of complex samples = 6503751 (1 s capture time)
- The data order of the float values in the iqw file is III...QQQ...

```
fid = fopen('IQ_exported_from_K10.iqw','r');
[samples, count] = fread(fid,inf,'float32');
fclose (fid);
nof_cplx_smpls = floor(count/2);
IQ = samples(1:nof_cplx_smpls) + 1i*samples(nof_cplx_smpls+1:
2*nof_cplx_smpls);
plot(20*log10(abs(IQ)),'.-');
```

SCPI command:

[MMEMory:STORe:IQ:STATe](#) on page 195

R&S Support

See "[R&S Support](#)" on page 89

3.4 FREQ Key

This key opens the "General Settings" dialog box and directly jumps to the "Frequency" field (see ["Frequency"](#) on page 58).

3.5 AMPT Key

This key opens the "General Settings" dialog box and directly jumps to the "Reference Level" field (see ["Reference Level"](#) on page 58).

3.6 AUTO SET Key

The AUTO SET key starts a single auto set procedure. Select the parameters to be set automatically in the ["Auto Set tab"](#) on page 78 of the ["Meas Settings"](#) on page 64 dialog box.

3.7 SWEEP Key

This key opens the "Sweep" menu which contains the following softkeys:

Refresh

Repeats the evaluation of the data currently in the capture buffer without capturing new data. This is useful after changing settings, for example the [Statistic Count](#). Averaging is performed according to the "Statistic Count" and automatically stops when the defined "Statistic Count" or the end of the captured data is reached.


SCPI command:

[INITiate:REFMeas\[:IMMEDIATE\]](#) on page 189

3.8 TRACE Key

This key opens the "Trace Wizard" dialog box.

Trace Wizard



In the Trace Wizard you can select which traces of a graph are displayed in which mode (Average, Max Hold, Min Hold or Clear Write) or which should be hidden (Blank). The following table shows the available traces and modes, depending on the measurement.

Measurement	Trace 1	Trace 2	Trace 3	Trace 4
Power vs Time: Graph	Average Blank	Max Hold Blank	Min Hold Blank	Clear Write Blank
EVM vs Time: Graph				
Phase Error vs Time: Graph				
Magnitude Error vs Time: Graph				
Constellation: Graph	-	-	-	Clear Write Blank
Modulation Spec- trum: Frequency Domain	Average Blank	-	-	Clear Write Blank
Transient Spec- trum: Frequency Domain	-	Max Hold Blank	-	Clear Write Blank
Trigger to Sync: Graph	Histogram Blank	PDF of Average Blank	-	-

For a description of the trace modes see the "Trace Mode Overview" section in the base unit manual.

SCPI command:

[DISPlay\[:WINDow<n>\]:TRACe<t>:MODE](#) on page 150

3.9 TRIG Key

This key opens the "General Settings" dialog box and directly jumps to the "Trigger Mode" field (see ["Trigger Mode"](#) on page 60).

3.10 Softkeys of the Marker Menu – MKR Key

The following table shows the softkeys of the marker menu specific to the GSM mode.

Marker 1/2/3/4	88
Unzoom	88
Marker Zoom	88
All Marker Off	88

Marker 1/2/3/4

Opens the "Marker" dialog box for the selected marker and activates the marker. The current marker location on the x-axis is indicated. To set the marker to a different point, enter the new x-value.

The values for all active markers are displayed in the diagram.

To deactivate a marker, select the softkey again.

SCPI command:

[CALCulate<n>:MARKer<m>\[:STATe\]](#) on page 95

To activate or deactivate a marker.

[CALCulate<n>:MARKer<m>\[:STATe\]](#) on page 95

To move a marker or query its position.

[CALCulate<n>:MARKer<m>:Y](#) on page 98

To query the value of a marker.

Unzoom

Resets the zoom to the default state.

SCPI command:

[CALCulate<n>:MARKer<m>:ZOOM](#) on page 98

Marker Zoom

Opens a dialog box in which you can enter the zoom factor for marker 1. The maximum zoom factor depends on the measurement.

SCPI command:

[CALCulate<n>:MARKer<m>:ZOOM](#) on page 98

All Marker Off

Switches all markers off.

SCPI command:

[CALCulate<n>:MARKer<m>:AOFF](#) on page 96

3.11 Softkeys of the Marker to Menu – MKR-> Key

This section describes the softkeys of the "Marker To" menu available for the GSM mode.

Marker to Trace

Opens an edit dialog box to enter the number of the trace on which the marker is to be placed.

SCPI command:

[CALCulate<n>:MARKer<m>:TRACe](#) on page 96

3.12 Softkeys of the Input/Output Menu

The following chapter describes all softkeys available in the "Input/Output" menu for GSM measurements. Note that the digital baseband functions are only available if the optional Digital Baseband Interface (R&S FSV-B17) is installed.

For details see the base unit description.

EXIQ.....	89
L TX Settings.....	89
L RX Settings.....	89
L Send To.....	89
L Firmware Update.....	89
L R&S Support.....	89
L DiglConf.....	90

EXIQ

Opens a configuration dialog box for an optionally connected R&S EX-IQ-BOX and a submenu to access the main settings quickly.

If the optional R&S DiglConf software is installed, the submenu consists only of one key to access the software. **Note that R&S DiglConf requires a USB connection (not LAN!) from the R&S FSVR to the R&S EX-IQ-BOX in addition to the R&S Digital I/Q Interface connection. R&S DiglConf version 2.10 or higher is required.**

For typical applications of the R&S EX-IQ-BOX see also the description of the R&S Digital I/Q Interface (R&S FSV-B17) in the base unit manual.

For details on configuration see the "R&S®Ex I/Q Box - External Signal Interface Module Manual".

For details on installation and operation of the R&S DiglConf software, see the "R&S®EX-IQ-BOX Digital Interface Module R&S®DiglConf Software Operating Manual".

TX Settings ← EXIQ

Opens the "EX-IQ-BOX Settings" dialog box to configure the R&S FSVR for digital output to a connected device ("Transmitter" Type).

RX Settings ← EXIQ

Opens the "EX-IQ-BOX Settings" dialog box to configure the R&S FSVR for digital input from a connected device ("Receiver" Type).

Send To ← EXIQ

The configuration settings defined in the dialog box are transferred to the R&S EX-IQ-BOX.

Firmware Update ← EXIQ

If a firmware update for the R&S EX-IQ-BOX is delivered with the R&S FSVR firmware, this function is available. In this case, when you select the softkey, the firmware update is performed.

R&S Support ← EXIQ

Stores useful information for troubleshooting in case of errors.

This data is stored in the `C:\R_S\Instr\user\Support` directory on the instrument.

If you contact the Rohde&Schwarz support to get help for a certain problem, send these files to the support in order to identify and solve the problem faster.

DigIConf ← EXIQ

Starts the optional R&S DigIConf application. This softkey is only available if the optional software is installed.

To return to the R&S FSVR application, press any key on the front panel. The application is displayed with the "EXIQ" menu, regardless of which key was pressed.

For details on the R&S DigIConf application, see the "R&S®EX-IQ-BOX Digital Interface Module R&S®DigIConf Software Operating Manual".

Note: If you close the R&S DigIConf window using the "Close" icon, the window is minimized, not closed.

If you select the "File > Exit" menu item in the R&S DigIConf window, the application is closed. Note that in this case the settings are lost and the EX-IQ-BOX functionality is no longer available until you restart the application using the "DigIConf" softkey in the R&S FSVR once again.

SCPI command:

Remote commands for the R&S DigIConf software always begin with `SOURce:EBOX`.

Such commands are passed on from the R&S FSVR to the R&S DigIConf automatically which then configures the R&S EX-IQ-BOX via the USB connection.

All remote commands available for configuration via the R&S DigIConf software are described in the "R&S®EX-IQ-BOX Digital Interface Module R&S®DigIConf Software Operating Manual".

Example 1:

```
SOURce:EBOX:*RST
```

```
SOURce:EBOX:*IDN?
```

Result:

```
"Rohde&Schwarz,DigiConf,02.05.436 Build 47"
```

Example 2:

```
SOURce:EBOX:USER:CLOCK:REference:FREQuency 5MHZ
```

Defines the frequency value of the reference clock.

4 Remote Commands (GSM)

In this section, all remote control commands specific to the GSM option R&S FSV-K10 are described in detail. For details on conventions used in this chapter refer to section [chapter 4.1, "Notation"](#), on page 91.

For further information on analyzer or basic settings commands, refer to the corresponding subsystem in the base unit description.

• Notation	91
• ABORt Subsystem	94
• CALCulate Subsystem	94
• CONFIgure Subsystem	104
• DISPlay Subsystem	149
• FETCh Subsystem	152
• INITiate Subsystem	188
• INPut Subsystem	189
• INSTrument Subsystem	193
• MMEMory Subsystem	194
• READ Subsystem	196
• SENSe Subsystem	236
• STATus Subsystem	239
• TRACe Subsystem	241
• TRIGger Subsystem	243

4.1 Notation

In the following sections, all commands implemented in the instrument are first listed and then described in detail, arranged according to the command subsystems. The notation is adapted to the SCPI standard. The SCPI conformity information is included in the individual description of the commands.

Individual Description

The individual description contains the complete notation of the command. An example for each command, the *RST value and the SCPI information are included as well.

The options and operating modes for which a command can be used are indicated by the following abbreviations:

Abbreviation	Description
A	spectrum analysis
A-F	spectrum analysis – span > 0 only (frequency mode)
A-T	spectrum analysis – zero span only (time mode)
ADEMODO	analog demodulation (option R&S FSV-K7)
BT	Bluetooth (option R&S FSV-K8)

CDMA	CDMA 2000 base station measurements (option R&S FSV-K82)
EVDO	1xEV-DO base station analysis (option R&S FSV-K84)
GSM	GSM/Edge measurements (option R&S FSV-K10)
IQ	IQ Analyzer mode
OFDM	WiMAX IEEE 802.16 OFDM measurements (option R&S FSV-K93)
OFDMA/WiBro	WiMAX IEEE 802.16e OFDMA/WiBro measurements (option R&S FSV-K93)
NF	Noise Figure measurements (R&S FSV-K30)
PHN	Phase Noise measurements (R&S FSV-K40)
PSM	Power Sensor measurements (option R&S FSV-K9)
RT	Realtime mode
SFM	Stereo FM measurements (option R&S FSV-K7S)
SPECM	Spectrogram mode (option R&S FSV-K14)
TDS	TD-SCDMA base station / UE measurements (option R&S FSV-K76/K77)
VSA	Vector Signal Analysis (option R&S FSV-K70)
WCDMA	3GPP Base Station measurements (option R&S FSV-K72), 3GPP UE measurements (option R&S FSV-K73)
WLAN	WLAN TX measurements (option R&S FSV-K91)



The spectrum analysis mode is implemented in the basic unit. For the other modes, the corresponding options are required.

Upper/Lower Case Notation

Upper/lower case letters are used to mark the long or short form of the key words of a command in the description. The instrument itself does not distinguish between upper and lower case letters.

Special Characters

	A selection of key words with an identical effect exists for several commands. These keywords are indicated in the same line; they are separated by a vertical stroke. Only one of these keywords needs to be included in the header of the command. The effect of the command is independent of which of the keywords is used.
--	---

Example:

```
SENSe:FREQuency:CW|:FIXed
```

The two following commands with identical meaning can be created. They set the frequency of the fixed frequency signal to 1 kHz:

```
SENSe:FREQuency:CW 1E3
```

```
SENSe:FREQuency:FIXed 1E3
```

A vertical stroke in parameter indications marks alternative possibilities in the sense of "or". The effect of the command differs, depending on which parameter is used.

Example: Selection of the parameters for the command

```
[SENSe<1...4>:]AVERAge<1...4>:TYPE VIDEo | LINear
```

[]	Key words in square brackets can be omitted when composing the header. The full command length must be accepted by the instrument for reasons of compatibility with the SCPI standards. Parameters in square brackets can be incorporated optionally in the command or omitted as well.
----	---

{}	Parameters in braces can be incorporated optionally in the command, either not at all, once or several times.
----	---

Description of Parameters

Due to the standardization, the parameter section of SCPI commands consists always of the same syntactical elements. SCPI has therefore specified a series of definitions, which are used in the tables of commands. In the tables, these established definitions are indicated in angled brackets (<...>) and is briefly explained in the following.

For details see the chapter "SCPI Command Structure" in the base unit description.

<Boolean>

This keyword refers to parameters which can adopt two states, "on" and "off". The "off" state may either be indicated by the keyword OFF or by the numeric value 0, the "on" state is indicated by ON or any numeric value other than zero. Parameter queries are always returned the numeric value 0 or 1.

<numeric_value> <num>

These keywords mark parameters which may be entered as numeric values or be set using specific keywords (character data). The following keywords given below are permitted:

- MAXimum: This keyword sets the parameter to the largest possible value.
- MINimum: This keyword sets the parameter to the smallest possible value.
- DEFault: This keyword is used to reset the parameter to its default value.
- UP: This keyword increments the parameter value.
- DOWN: This keyword decrements the parameter value.

The numeric values associated to MAXimum/MINimum/DEFault can be queried by adding the corresponding keywords to the command. They must be entered following the quotation mark.

Example:

```
SENSe:FREQuency:CENTer? MAXimum
```

Returns the maximum possible numeric value of the center frequency as result.

<arbitrary block program data>

This keyword is provided for commands the parameters of which consist of a binary data block.

4.2 ABORt Subsystem

The ABORt Subsystem contains the commands for aborting triggered actions. An action can be triggered again immediately after being aborted. All commands trigger events, and therefore they have no *RST value.

ABORt

This command aborts a current measurement and resets the trigger system.

Example: ABOR; INIT: IMM

Mode: all

4.3 CALCulate Subsystem

The CALCulate subsystem contains commands for converting instrument data, transforming and carrying out corrections. These functions are carried out subsequent to data acquisition, i.e. following the SENSE Subsystem.

- [CALCulate:LIMit Subsystem](#).....94
- [CALCulate:MARKer Subsystem](#).....95
- [CALCulate:MASK Subsystem](#).....98

4.3.1 CALCulate:LIMit Subsystem

The CALCulate:LIMit Subsystem contains commands for the limit lines and the corresponding limit checks. Limit lines can be defined as upper or lower limit lines. The individual Y values of the limit lines correspond to the values of the x-axis (CONTROL). The number of X and Y values must be identical.

For details on limit lines refer to chapter "Instrument Functions", section "Using Limit Lines and Display Lines – LINES Key" in the base unit description.

CALCulate<n>:LIMit<i>:FAIL?

This command queries the result of the limit check of the limit line indicated in the selected measurement window. Note that a complete sweep must have been performed to obtain a valid result. A synchronization with *OPC, *OPC? Or *WAI should therefore be provided.

For the power vs. time graph measurement, CALCulate:LIMit1:FAIL? returns the result for the Max trace and CALCulate:LIMit2:FAIL? returns the result for the Min trace.

Suffix:	
<n>	<1> irrelevant
<i>	<1..8> The number of the limit line to access. 1: Max trace 2: Min trace
Return values:	
<State>	1 0 ON OFF 1 Pass 0 Fail
Usage:	Query only
Mode:	GSM

4.3.2 CALCulate:MARKer Subsystem

The marker is used to evaluate the (graphical) measurement results at certain trace points. Therefore, the marker is placed at a certain position (by specifying the X value or a trace property like maximum or minimum peak search) and then query the marker value.



GSM mode now also supports up to 4 markers.

CALCulate<n>:MARKer<m>[:STATe].....	95
CALCulate<n>:MARKer<m>:AOFF.....	96
CALCulate<n>:MARKer<m>:TRACe.....	96
CALCulate<n>:MARKer<m>:X.....	97
CALCulate<n>:MARKer<m>:Y.....	98
CALCulate<n>:MARKer<m>:ZOOM.....	98

CALCulate<n>:MARKer<m>[:STATe] <State>

This command activates a marker in the specified window.

Suffix:	
<n>	<1> irrelevant
<m>	<1..4> Marker number
Parameters for setting and query:	
<State>	1 0 ON OFF

Example:

```
// Preset the instrument
*RST
// Enter the GSM option K10
INSTrument:SElect GSM
// Switch to single sweep mode and stop sweep
INITiate:CONTinuous OFF;:ABORT
// Activate Power vs Time measurement
CONFigure:BURSt:PTEmplate:IMMediate
// Run a (blocking) single sweep
INITiate:IMMediate;*WAI
// Switch all 4 markers on
CALCulate:MARKer1:STATe ON
CALCulate:MARKer2:STATe ON
CALCulate:MARKer3:STATe ON
CALCulate:MARKer4:STATe ON
// Assign marker 1/2/3/4 to trace 1/2/3/4
CALCulate:MARKer1:TRACe 1
CALCulate:MARKer2:TRACe 2
CALCulate:MARKer3:TRACe 3
CALCulate:MARKer4:TRACe 4
// Set marker 2 to start of active part of burst
CALCulate:MARKer:X 0
// Read y-value (level of max trace) of marker 2
CALCulate:MARKer:Y?
// Switch all markers off
CALCulate:MARKer1:AOff
```

Mode: GSM

CALCulate<n>:MARKer<m>:AOff

This command switches off all active markers, delta markers, and marker measurement functions in the specified window.

Suffix:

<n> window; For applications that do not have more than 1 measurement window, the suffix <n> is irrelevant.

<m> depends on mode
irrelevant

Example: CALC:MARK:AOff
Switches off all markers.

Mode: all

CALCulate<n>:MARKer<m>:TRACe <Trace>

This command assigns the selected marker to the indicated trace in the specified window. The corresponding trace must be active, i.e. its status must not be "BLANK".

If necessary, the corresponding marker is switched on prior to the assignment.

In the persistence spectrum result display, the command also defines if the delta marker is positioned on the persistence trace or the maxhold trace.

Suffix:

<n> window; For applications that do not have more than 1 measurement window, the suffix <n> is irrelevant.

<m> depends on mode
marker number; For applications that do not have more than 1 marker, the suffix <m> is irrelevant.

Parameters:

<Trace> **1 to 4**
Trace number the marker is assigned to.

MAXHold
Defines the maxhold trace as the trace to put the delta marker on. This parameter is available only for the persistence spectrum result display.

WRITE
Defines the persistence trace as the trace to put the delta marker on. This parameter is available only for the persistence spectrum result display.

Example: `CALC:MARK3:TRAC 2`
Assigns marker 3 to trace 2.

Mode: all

CALCulate<n>:MARKer<m>:X <Value>

This command positions the selected marker to the indicated position.

The corresponding trace must be active, i.e. its status must not be "BLANK" (see [DISPlay\[:WINDow<n>\]:TRACe<t>:MODE](#) on page 150).

Suffix:

<n> <1>
irrelevant

<m> <1..4>
Marker number

Parameters for setting and query:

<Value> numeric value
x-axis position of the marker
Default unit: NONE

Example: `CALC1:MARK1:X 5`

Mode: GSM

CALCulate<n>:MARKer<m>:Y?

This command returns the y-value at the position of the marker.

Suffix:

<n>	<1> irrelevant
<m>	<1..4> Marker number

Usage: Query only

Mode: GSM

CALCulate<n>:MARKer<m>:ZOOM <Value>

This command defines the ratio to be zoomed around the marker 1 in the selected measurement window. The default value is 1, where the full trace is shown.

Suffix:

<n>	<1> irrelevant
<m>	<1..4> irrelevant

Parameters for setting and query:

<Value>	numeric value Zoom factor Range: 1 to 100 *RST: 1 Default unit: NONE
---------	--

Mode: GSM

4.3.3 CALCulate:MASK Subsystem

The commands of the CALCulate:MASK subsystem configure the frequency mask trigger.

Programming example

```
TRIG:SOUR MASK
//Selects the frequency mask as a trigger source.
MMEM:MDIR 'C:\R_S\instr\freqmask\MyMasks'
CALC:MASK:CDIR 'MyMasks'
//Creates a directory on C:\ called 'FreqMasks' and selects it as the frequency
//mask directory.
//Defining the shape of a lower frequency mask
CALC:MASK:NAME 'MyMask'
//Creates or loads a frequency mask called 'MyMask'.
```

```

CALC:MASK:COMM 'Customized Frequency Mask'
//Adds a comment to the frequency mask.
TRIG:MASK:COND ENT
//Triggers the measurement when the signal enters the frequency mask.
CALC:MASK:MODE ABS
//Selects absolute power level values.
CALC:MASK:LOW -10MHZ,-10,-4MHZ,-10,-4MHZ,-20,4MHZ,-20,4MHZ,-10,10MHZ,-10
//Defines a lower frequency mask with 6 data points.
//The first data point position is at -10 MHz from the center frequency
//and at -10 dBm, the second at -4 MHz from the center frequency etc.
CALC:MASK:LOW:SHIF:X 1MHZ
CALC:MASK:LOW:SHIF:Y 10
//Shifts the lower frequency mask by 1 MHz to the right and 10 dB up.
CALC:MASK:LOW:STAT ON
//Turns the lower frequency mask on.

//Defining the shape of an upper frequency mask
CALC:MASK:NAME 'AnotherMask'
//Creates or loads a frequency mask called 'AnotherMask'
CALC:MASK:MODE ABS
//Selects absolute power level values.
CALC:MASK:UPP -10MHZ,-10,-4MHZ,-10,-4MHZ,-20,4MHZ,-20,4MHZ,-10,10MHZ,-10
//Defines an upper frequency mask with 6 data points.
CALC:MASK:UPP:SHIF:X -1MHZ
CALC:MASK:UPP:SHIF 10
//Shift the upper frequency mask 1 MHz to the left and 10 dB up.
CALC:MASK:UPP:STAT ON
//Turns the upper frequency mask on.
//Alternatively, you can create an upper frequency mask automatically.
CALC:MASK:UPP:AUTO
//Automatically defines the shape of an upper frequency mask.

CALC:MASK:DEL
//Deletes the frequency mask called 'MyMask' in C:\FreqMasks.

```



Before making any changes to a frequency mask, you have to select one by name with `CALCulate<n>:MASK:NAME` on page 102.

Compared to manual configuration of frequency masks, any changes made to a frequency mask via remote control are saved after the corresponding command has been sent.

<code>CALCulate<n>:MASK:CDIRectory</code>	100
<code>CALCulate<n>:MASK:COMMeNt</code>	100
<code>CALCulate<n>:MASK:DELeTe</code>	100
<code>CALCulate<n>:MASK:LOWer:SHIFt:X</code>	101
<code>CALCulate<n>:MASK:LOWer:SHIFt:Y</code>	101
<code>CALCulate<n>:MASK:LOWer[:STATe]</code>	101
<code>CALCulate<n>:MASK:LOWer[:DATA]</code>	101
<code>CALCulate<n>:MASK:MODE</code>	102

CALCulate<n>:MASK:NAME	102
CALCulate<n>:MASK:SPAN.....	102
CALCulate<n>:MASK:UPPer:AUTO.....	103
CALCulate<n>:MASK:UPPer:SHIFt:X.....	103
CALCulate<n>:MASK:UPPer:SHIFt:Y.....	103
CALCulate<n>:MASK:UPPer[:STATe].....	103
CALCulate<n>:MASK:UPPer[:DATA].....	104

CALCulate<n>:MASK:CDIRectory <Subdirectory>

This command selects the directory the R&S FSVR stores frequency masks in.

The directory must exist already for the command to work. You can create a new directory with [MMEMemory:MDIRectory](#).

Parameters:

<Subdirectory> String containing the path to the directory. The directory has to be a subdirectory of the default directory. Thus the path is always relative to the default directory (C:\R_S\INSTRI\FREQMASK). An empty string selects the default directory.

Example: See [chapter 4.3.3, "CALCulate:MASK Subsystem"](#), on page 98.

Mode: RT

CALCulate<n>:MASK:COMMeNt <Comment>

This command defines a comment for the frequency mask that you have selected with [CALCulate<n>:MASK:NAME](#) on page 102.

Parameters:

<Comment> String containing the comment for the frequency mask.

Example: See [chapter 4.3.3, "CALCulate:MASK Subsystem"](#), on page 98.

Mode: RT

CALCulate<n>:MASK:DELeTe

This command deletes the currently selected frequency mask.

Before making any changes to a frequency mask, you have to select one by name with [CALCulate<n>:MASK:NAME](#) on page 102.

Example: See [chapter 4.3.3, "CALCulate:MASK Subsystem"](#), on page 98.

Usage: Event

Mode: RT

CALCulate<n>:MASK:LOWer:SHIFt:X <Frequency>

This command shifts the lower frequency mask horizontally by a specified distance. Positive values move the mask to the right, negative values shift the mask to the left.

Before making any changes to a frequency mask, you have to select one by name with [CALCulate<n>:MASK:NAME](#) on page 102.

Parameters:

<Frequency> Defines the distance of the shift.
Default unit: Hz

Example: See [chapter 4.3.3, "CALCulate:MASK Subsystem"](#), on page 98.

Mode: RT

CALCulate<n>:MASK:LOWer:SHIFt:Y <Level>

This command shifts the lower frequency mask vertically by a specified distance. Positive values move the mask upwards, negative values shift the mask downwards.

Before making any changes to a frequency mask, you have to select one by name with [CALCulate<n>:MASK:NAME](#) on page 102.

Parameters:

<Level> Defines the distance of the shift. The shift is relative to the current position.
Default unit: dB

Example: See [chapter 4.3.3, "CALCulate:MASK Subsystem"](#), on page 98.

Mode: RT

CALCulate<n>:MASK:LOWer[:STATE] <State>

This command turns the lower frequency mask on and off.

Before making any changes to a frequency mask, you have to select one by name with [CALCulate<n>:MASK:NAME](#) on page 102.

Parameters:

<State> **ON | OFF**

Example: See [chapter 4.3.3, "CALCulate:MASK Subsystem"](#), on page 98.

Mode: RT

CALCulate<n>:MASK:LOWer[:DATA] <Frequency>,<Level>,...

This command defines the shape of the lower frequency mask.

Before making any changes to a frequency mask, you have to select one by name with [CALCulate<n>:MASK:NAME](#) on page 102.

The unit of the power levels depends on `CALCulate<n>:MASK:MODE` on page 102.

If you are using the command with the vector network analysis option (R&S FSV-K70), you can only use this command as a query.

Parameters:

<Frequency>, [N] pairs of numerical values. [N] is the number of data points the mask consists of.
 <Level> Each data point is defined by the frequency (in Hz) and the level (in dB or dBm). All values are separated by commas.
 Note that the data points have to be inside the current span.

Example: See [chapter 4.3.3, "CALCulate:MASK Subsystem"](#), on page 98.

Mode: RT

CALCulate<n>:MASK:MODE <Mode>

This command defines the scaling of the level axis for frequency masks.

Parameters:

<Mode> **ABSolute**
 absolute scaling of the level axis.
RELative
 relative scaling of the level axis.
 *RST: RELative

Mode: RT

CALCulate<n>:MASK:NAME <Name>

This command creates or selects a frequency mask with the name that you specify by the parameter. When you use it as a query, the command returns the name of the mask currently in use.

Parameters:

<Name> String containing the name of the mask.
 Note that an empty string does not select a frequency mask.

Mode: RT

**CALCulate<n>:MASK:SPAN **

This command defines the frequency span of the frequency mask.

Parameters:

 Range: 100 Hz to 40 MHz
 *RST: 40 MHz

Example: `CALC:MASK:SPAN 10 MHz`
 Defines a span of 10 MHz.

Mode: RT

CALCulate<n>:MASK:UPPer:AUTO

This command automatically defines the shape of an upper frequency mask according to the spectrum that is currently measured.

Example: See [chapter 4.3.3, "CALCulate:MASK Subsystem"](#), on page 98.

Usage: Event

Mode: RT

CALCulate<n>:MASK:UPPer:SHIFt:X <Frequency>

This command shifts the lower frequency mask horizontally by a specified distance. Positive values move the mask to the right, negative values shift the mask to the left.

You have to select a mask before you can use this command with [CALCulate<n>:MASK:NAME](#) on page 102.

Parameters:

<Frequency> Defines the distance of the shift.

Example: See [chapter 4.3.3, "CALCulate:MASK Subsystem"](#), on page 98.

Mode: RT

CALCulate<n>:MASK:UPPer:SHIFt:Y <Level>

This command shifts the upper frequency mask vertically by a specified distance. Positive values move the mask upwards, negative values shift the mask downwards.

You have to select a mask before you can use this command with [CALCulate<n>:MASK:NAME](#) on page 102.

Parameters:

<Level> Defines the distance of the shift. The shift is relative to the current position.
Default unit: dB

Example: See [chapter 4.3.3, "CALCulate:MASK Subsystem"](#), on page 98.

Mode: RT

CALCulate<n>:MASK:UPPer[:STATe] <State>

This command turns the upper frequency mask on and off.

Before making any changes to a frequency mask, you have to select one by name with [CALCulate<n>:MASK:NAME](#) on page 102.

Parameters:

<State> **ON | OFF**

Example: See [chapter 4.3.3, "CALCulate:MASK Subsystem"](#), on page 98.

Mode: RT

CALCulate<n>:MASK:UPPer[:DATA] <Frequency>,<Level>,...

This command activates and defines the shape of the upper frequency mask trigger mask.

You have to select a mask before you can use this command with [CALCulate<n>:MASK:NAME](#) on page 102.

The unit of the power levels depends on [CALCulate<n>:MASK:MODE](#) on page 102.

If you are using the command with the vector network analysis option (R&S FSV-K70), you can only use this command as a query.

Parameters:

<Frequency>, [N] pairs of numerical values. [N] is the number of data points the mask consists of.
 <Level> Each data point is defined by the frequency (in Hz) and the amplitude (in dB or dBm). All values are separated by commas.
 Note that the data points have to be inside the current span.

Example: See [chapter 4.3.3, "CALCulate:MASK Subsystem"](#), on page 98.

Mode: RT

4.4 CONFigure Subsystem

The CONFigure Subsystem is used to set up the signal characteristics which are used in the signal, as for example the frame configuration, the measurement type to use, etc.

- [Configure\[:MS\] subsystem](#)..... 104
- [CONFigure:BURSt subsystem](#)..... 136
- [CONFigure:SPECTrum subsystem](#)..... 139
- [Other Commands in the CONFigure Subsystem](#)..... 145

4.4.1 Configure[:MS] subsystem

Commands of the Configure[:MS] subsystem:

CONFigure[:MS]:ARFCn	105
CONFigure[:MS]:AUTO	106
CONFigure[:MS]:AUTO:FRAMe	106
CONFigure[:MS]:AUTO:LEVel	106
CONFigure[:MS]:AUTO:TRIGger	107
CONFigure[:MS]:BSEarch	107
CONFigure[:MS]:BSTHreshold	108
CONFigure[:MS]:CHANnel:FRAMe:EQUal	108
CONFigure[:MS]:CHANnel:MSLots:MEASure	109

CONFigure[:MS]:CHANnel:MSLots:NOFSlots.....	109
CONFigure[:MS]:CHANnel:MSLots:OFFSet.....	109
CONFigure[:MS]:CHANnel:SLOT<s>[:STATe].....	110
CONFigure[:MS]:CHANnel:SLOT<s>:FILTer.....	110
CONFigure[:MS]:CHANnel:SLOT<s>:MTYPE.....	110
CONFigure[:MS]:CHANnel:SLOT<s>:MULTi.....	111
CONFigure[:MS]:CHANnel:SLOT<s>:PCL.....	112
CONFigure[:MS]:CHANnel:SLOT<s>:SCPIr.....	112
CONFigure[:MS]:CHANnel:SLOT<s>:SCPIr.....	113
CONFigure[:MS]:CHANnel:SLOT<s>:SUBChannel<ch>:TSC.....	114
CONFigure[:MS]:CHANnel:SLOT<s>:SUBChannel<ch>:TSC:USER.....	115
CONFigure[:MS]:CHANnel:SLOT<s>:TSC.....	116
CONFigure[:MS]:CHANnel:SLOT<s>:TSC:USER.....	118
CONFigure[:MS]:CHANnel:SLOT<s>:TYPE.....	119
CONFigure[:MS]:CHANnel:TSC.....	120
CONFigure[:MS]:CHANnel:TSC:USER.....	120
CONFigure[:MS]:DEMod:DECision.....	120
CONFigure[:MS]:DEMod:STDBits.....	122
CONFigure[:MS]:DEVice:TYPE.....	123
CONFigure[:MS]:MCArrier[:STATe].....	123
CONFigure[:MS]:MCArrier:ACTCarriers.....	124
CONFigure[:MS]:MCArrier:BTSClass.....	124
CONFigure[:MS]:MCArrier:FILTer.....	124
CONFigure[:MS]:MCArrier:MCBTs.....	125
CONFigure[:MS]:MTYPE.....	125
CONFigure[:MS]:MULTi:BURSt:CONStell.....	126
CONFigure[:MS]:MULTi:BURSt:DEModulation.....	127
CONFigure[:MS]:MULTi:BURSt:PTEmplate.....	127
CONFigure[:MS]:MULTi:SPECtrum:MODulation.....	127
CONFigure[:MS]:MULTi:SPECtrum:SWITChing.....	128
CONFigure[:MS]:MULTi:STATe.....	128
CONFigure[:MS]:NETWork[:TYPE].....	129
CONFigure[:MS]:NETWork:FREQuency:BAND.....	130
CONFigure[:MS]:POWer:CLASs.....	131
CONFigure[:MS]:POWer:STATic.....	132
CONFigure[:MS]:POWer:AUTO.....	133
CONFigure[:MS]:POWer:AUTO:SWEEp:TIME.....	133
CONFigure[:MS]:PRATe.....	133
CONFigure[:MS]:RESTore.....	134
CONFigure[:MS]:SSEArch.....	134
CONFigure[:MS]:SYNC:IQCThreshold.....	134
CONFigure[:MS]:SYNC:MODE.....	134
CONFigure[:MS]:SYNC:ONLY.....	135

CONFigure[:MS]:ARFCn <Value>

This command specifies the Absolute Radio Frequency Channel Number (ARFCN) to be measured. Setting the ARFCN updates the frequency.

Parameters for setting and query:

<Value> numeric value
 Range: 0 to 1023 (some values may not be allowed depending on the selected frequency band)
 Default unit: NONE

Example: CONF:ARFC 5

Mode: GSM

CONFigure[:MS]:AUTO <Value>

This command executes the auto set routines once, i.e. its function corresponds to pressing the AUTO SET key.

Tip: Use CONFfigure:MS:AUTO:LEVel ONCE, CONFfigure:MS:AUTO:FRAMe ONCE or CONFfigure:MS:AUTO:TRIGger ONCE to execute the auto set routines separately.

Parameters for setting and query:

<Value> ONCE

Mode: GSM

CONFigure[:MS]:AUTO:FRAMe <Value>**Parameters for setting and query:**

<Value> OFF | ON | ONCE
OFF
 Switch the function off
ON
 Switch the function on
ONCE
 Execute the function once
 *RST: ON

Example: CONF:AUTO:FRAM OFF

Mode: GSM

CONFigure[:MS]:AUTO:LEVel <Value>

This command is used to switch on or off automatic level detection while running auto set. When switched on, level detection is performed on auto set. Using the ONCE argument starts one auto level measurement immediately.

Parameters for setting and query:

<Value> OFF | ON | ONCE
OFF
 Switch the function off
ON
 Switch the function on
ONCE
 Execute the function once
 *RST: ON

Example: CONF:AUTO:LEV OFF

Mode: GSM

CONFigure[:MS]:AUTO:TRIGger <Value>

This command is used to switch on or off automatic trigger (offset/level) detection while running auto set. When switched on, trigger detection is performed on auto set. Using the ONCE argument starts one auto trigger measurement immediately.

Parameters for setting and query:

<Value> OFF | ON | ONCE
OFF
 Switch the function off
ON
 Switch the function on
ONCE
 Execute the function once
 *RST: ON

Example: CONF:AUTO:TRIG OFF

Mode: GSM

CONFigure[:MS]:BSEarch <State>

This command toggles between active burst search and inactive burst search.

Note

This command is retained for compatibility with R&S FS-K5 only. Use CONFfigure:MS:SYNC:MODE BURSt or CONFfigure:MS:SYNC:MODE ALL instead (see CONFfigure[:MS]:SYNC:MODE on page 134).

Parameters for setting and query:

<State> 1 | 0 | ON | OFF
ON
 Burst search on
OFF
 Burst search off
 *RST: 1

Mode: GSM

CONFigure[:MS]:BSTHreshold <Value>

This command changes the burst find threshold.

Note

This command is retained for compatibility with R&S FS-K5 only. Due to the improved measurement capabilities of this GSM analysis software, this remote control command (and the function behind) is not required any more.

Parameters for setting and query:

<Value> numeric value
 Threshold for burst detection
 Default unit: dB

Example: CONF:BSTH 10 DB

Mode: GSM

CONFigure[:MS]:CHANnel:FRAME:EQUal <State>

If activated, all slots of a frame have the same length (8 x 156.26 normal symbol periods).

If deactivated, slots number 0 and 4 of a frame have a longer duration, all other a shorter duration compared to the "equal slot length" (157, 156, 156, 156, 157, 156, 156, 156 normal symbol periods).

See 3GPP TS 51.0213GPP TS 51.021 and 3GPP TS 45.0103GPP TS 45.010 chapter "6.7 Timeslot length" for further details.

This parameter is used to adjust the time for the "Power vs Time" masks of all slots. The "Slot to measure" is used as the time reference for the entire frame.

Parameters for setting and query:

<State> 1 | 0 | ON | OFF
 *RST: ON

Example: CONF:CHAN:FRAM:EQU OFF

Mode: GSM

CONFigure[:MS]:CHANnel:MSLots:MEASure <Value>

This command specifies the slot to be measured in single-slot measurements relative to the GSM frame start.

Parameters for setting and query:

<Value> numeric value
 Slot to measure in single-slot measurements relative to the GSM start frame
 Range: 0 to 7
 *RST: 0 Slots
 Default unit: NONE

Example: CONF:CHAN:MSL:MEAS 5

Mode: GSM

CONFigure[:MS]:CHANnel:MSLots:NOFSlots <Value>

This command specifies the number of slots to measure for the measurement interval of multi-slot measurements, i.e. the "Power vs Time" and "Transient Spectrum" measurements. Between 1 and 8 consecutive slots can be measured.

Parameters for setting and query:

<Value> numeric value
 Number of slots to measure.
 Range: 1 to 8
 *RST: 1 Slots
 Default unit: NONE

Example: CONF:CHAN:MSL:NOFS 5

Mode: GSM

CONFigure[:MS]:CHANnel:MSLots:OFFSet <Value>

This command specifies the start for the measurement interval for multi-slot measurements, i.e. the "Power vs Time" and "Transient Spectrum" measurements, relative to the GSM frame boundary.

Parameters for setting and query:

<Value> numeric value
 First slot to measure in multi-slot measurements relative to the GSM frame start.
 Range: 0 to 7
 *RST: 0 Slots
 Default unit: NONE

Example: CONF:CHAN:MSL:OFFS 5

Mode: GSM

CONFigure[:MS]:CHANnel:SLOT<s>[:STATe] <State>

This command activates this slot (this means, for example, that this slot is not considered as inactive in the PVT limit evaluation).

Suffix:

<s> <0..7>
Select the slot to configure.

Parameters for setting and query:

<State> 1 | 0 | ON | OFF
*RST: Slot 0: 1; Slot 1-7: 0

Example: CONF:CHAN:SLOT1 ON

Mode: GSM

CONFigure[:MS]:CHANnel:SLOT<s>:FILTer <Value>

This command specifies the pulse shape of the transmit filter of the specified slot.

Suffix:

<s> <0..7>
the slot to configure

Parameters for setting and query:

<Value> GMSK | LINearised | NARRow | WIDE

GMSK

GMSK Pulse

LINearised

Linearised GMSK Pulse

NARRow

Narrow Pulse

WIDE

Wide Pulse

*RST: GMSK

Example: CONF:CHAN:SLOT:FILT GMSK

Mode: GSM

CONFigure[:MS]:CHANnel:SLOT<s>:MTYPe <Value>

This command specifies the modulation type of the specified slot.

Suffix:

<s> <0..7>
the slot to configure

Parameters for setting and query:

<Value> GMSK | QPSK | PSK8 | QAM16 | QAM32 | AQPSk

Modulation type; the available values depend on the burst type.
For Normal Burst GMSK, 8PSK, 16QAM, 32QAM and AQPSK are available.
For Higher Symbol Rate Burst QPSK, 16QAM and 32QAM are available.

GMSK
GMSK, Gaussian Minimum Shift Keying, 1 bit/symbol.

QPSK
QPSK, Quadrature Phase Shift keying, 2 bits/symbol.

PSK8
8PSK (EDGE), Phase Shift Keying, 3 bits/symbol.

QAM16
16QAM, 16-ary Quadrature Amplitude Modulation, 4 bits/symbol.

QAM32
32QAM, 32-ary Quadrature Amplitude Modulation, 5 bits/symbol.

AQPSk
Adaptive Quadrature Amplitude Modulation

*RST: GMSK

Example: CONF:CHAN: SLOT:MTYP GMSK

Mode: GSM

CONFigure[:MS]:CHANnel:SLOT<s>:MULTi <Value>

This command defines the used slots of the mobile or base station. The multislot setting defines how many adjacent slots are active and which of the active slots should be used for synchronization.

For the phase-frequency error, modulation accuracy and power vs. time measurement the training sequence for the slot to synchronize must be set correctly! The reference measurement of power vs. time measurement and the questionable signal power of the main measurement is related to the slot to synchronize. In the main measurement of power vs.time, the slot to synchronize defines the synchronization point of the multislot signal on the screen. All results of the phase-frequency error and modulation accuracy measurement are related to the slot to synchronize.

In carrier power and modulation spectrum measurement the slot to synchronize is used to adjust the trigger delay so that the slot to synchronize is measured. With the slot to synchronize it is therefore possible to investigate a certain slot of multislot signals.

Note: This command is retained for compatibility with R&S FS-K5 only.Refrain from using this command in new K10 remote scripts and use pure K10 remote commands instead.

Suffix:

<s> <0..7>
 irrelevant

Parameters for setting and query:

<Value> ACT1sync1 | ACT2sync1 | ACT2sync2 | ACT3sync1 |
 ACT3sync2 | ACT3sync3 | ACT4sync1 | ACT4sync2 |
 ACT4sync3 | ACT4sync4 | ACT5sync1 | ACT5sync2 |
 ACT5sync3 | ACT5sync4 | ACT5sync5 | ACT6sync1 |
 ACT6sync2 | ACT6sync3 | ACT6sync4 | ACT6sync5 |
 ACT6sync6 | ACT7sync1 | ACT7sync2 | ACT7sync3 |
 ACT7sync4 | ACT7sync5 | ACT7sync6 | ACT7sync7 |
 ACT8sync1 | ACT8sync2 | ACT8sync3 | ACT8sync4 |
 ACT8sync5 | ACT8sync6 | ACT8sync7 | ACT8sync8

For ACT<k>sync<m> the following settings are defined:

"Slot to measure" is set to $m-1$

"No. of Slots" is set to k

"First Slot to measure" is set to 0

Slots 0 to $k-1$ are set to active; the remaining slots are set to inactive

Slot properties of slot numbers 0 to $k-1$ are copied from the last active "Slot to measure".

*RST: ACT1sync1

Example:

CONF:CHAN:SLOT:MULT ACT3sync2

Slot to measure is 1.

Number of slots is 3.

First slot to measure is 0.

Slots 0, 1, 2 are active.

Mode:

GSM

CONFigure[:MS]:CHANnel:SLOT<s>:PCL <Value>

This command is now obsolete and is retained for compatibility reasons only.

Suffix:

<s> <0..7>

Parameters for setting and query:

<Value> numeric value
 PCL or Dynamic PCL of the slot.

*RST: 0

Default unit: NONE

Example:

CONF:CHAN:SLOT:PCL 5

Mode:

GSM

CONFigure[:MS]:CHANnel:SLOT<s>:SCPir <Value>

This command specifies the Subchannel Power Imbalance Ratio (SCPIR) of the specified slot.

Note: This command is only available for AQPSK modulation.

Suffix:

<s> <0..7>
Number of slot to configure

Parameters for setting and query:

<Value> numeric value
Subchannel Power Imbalance Ratio (SCPIR) in dB
Range: -15 to 15
*RST: 0
Default unit: NONE

Example:

```
// Enter the GSM option K10
INSTRUMENT:SElect GSM
// Setup slot 0 for VAMOS AQPSK modulation
// Activate slot
CONFigure:MS:CHANnel:SLOT0:STATe ON
// Normal burst
CONFigure:MS:CHANnel:SLOT0:TYPE NB
// Adaptive QPSK modulation
CONFigure:MS:CHANnel:SLOT0:MTYPE AQPSk
// Subchannel Power Imbalance Ratio (SCPIR) = 4 dB
CONFigure:MS:CHANnel:SLOT0:SCPIr 4
// Linearised gaussian TX filter
CONFigure:MS:CHANnel:SLOT0:FILTer LINearised
// Set TSC of Subchannel 1 = TSC 0 (Set 1)
CONFigure:MS:CHANnel:SLOT0:SUBChannel1:TSC 0,1
// Query TSC and Set of Subchannel 1
CONFigure:MS:CHANnel:SLOT0:SUBChannel1:TSC?
// -> 0,1
// Set TSC of Subchannel 2 = TSC 0 (Set 2)
CONFigure:MS:CHANnel:SLOT0:SUBChannel2:TSC 0,2
// Query TSC and Set of Subchannel 2
CONFigure:MS:CHANnel:SLOT0:SUBChannel2:TSC?
// -> 0,2
```

Mode: GSM

CONFigure[:MS]:CHANnel:SLOT<s>:SCPIr <Value>

This command specifies the Subchannel Power Imbalance Ratio (SCPIR) of the specified slot.

Notes:

This command is only available for AQPSK modulation.

Suffix:

<s> <0..7>
Number of slot to configure

Parameters for setting and query:

<Value> numeric value
 Subchannel Power Imbalance Ratio (SCPIR) in dB
 Range: -15 to 15
 *RST: 0
 Default unit: NONE

Example:

```
// Enter the GSM option K10
INSTRument:SElect GSM
// Setup slot 0 for VAMOS AQPSK modulation
// Activate slot
CONFigure:MS:CHANnel:SLOT0:STATE ON
// Normal burst
CONFigure:MS:CHANnel:SLOT0:TYPE NB
// Adaptive QPSK modulation
CONFigure:MS:CHANnel:SLOT0:MTYPE AQPSk
// Subchannel Power Imbalance Ratio (SCPIR) = 4 dB
CONFigure:MS:CHANnel:SLOT0:SCIPr 4
// Linearised gaussian TX filter
CONFigure:MS:CHANnel:SLOT0:FILTer LINearised
// Set TSC of Subchannel 1 = TSC 0 (Set 1)
CONFigure:MS:CHANnel:SLOT0:SUBChannel1:TSC 0,1
// Query TSC and Set of Subchannel 1
CONFigure:MS:CHANnel:SLOT0:SUBChannel1:TSC?
// -> 0,1
// Set TSC of Subchannel 2 = TSC 0 (Set 2)
CONFigure:MS:CHANnel:SLOT0:SUBChannel2:TSC 0,2
// Query TSC and Set of Subchannel 2
CONFigure:MS:CHANnel:SLOT0:SUBChannel2:TSC?
// -> 0,2
```

Mode: GSM

CONFigure[:MS]:CHANnel:SLOT<s>:SUBChannel<ch>:TSC <Value>

This command selects the training sequence of the specified slot and subchannel used by the mobile or base station.

This command is only available for AQPSK modulation.

Suffix:

<s> <0..7>
 Number of slot to configure

<ch> <1|2>
 Subchannel number

Query parameters:

<ResultType> TSC | SET
 Queries the currently used TSC number or the set.

Parameters for setting and query:

<Value> 0,1 | 0,2 | 1,1 | 1,2 | 2,1 | 2,2 | 3,1 | 3,2 | 4,1 | 4,2 | 5,1 | 5,2 | 6,1 | 6,2 | 7,1 | 7,2 | USER

TSC number and Set or User TSC

Set 2 is only available for subchannel 2.

*RST: 0,1

Example:

```
// Enter the GSM option K10
INSTrument:SElect GSM
// Activate slot 0
CONFigure:MS:CHANnel:SLOT0:STATE ON
// Normal Burst
CONFigure:MS:CHANnel:SLOT0:TYPE NB
// AQPSK (VAMOS) modulation
CONFigure:MS:CHANnel:SLOT0:MTYPE AQPSk
// Subchannel 1: TSC 0 (Set 1)
CONFigure:MS:CHANnel:SLOT0:SUBChannel1:TSC 0,1
// Subchannel 1: Query TSC number and Set number
CONFigure:MS:CHANnel:SLOT0:SUBChannel1:TSC?
// -> 0,1
// Subchannel 1: Query TSC number
CONFigure:MS:CHANnel:SLOT0:SUBChannel1:TSC? TSC
// -> 0
// Subchannel 1: Query Set number
CONFigure:MS:CHANnel:SLOT0:SUBChannel1:TSC? SET
// -> 1
// Subchannel 2: TSC 0 (Set 1)
CONFigure:MS:CHANnel:SLOT0:SUBChannel2:TSC 0,2
// Subchannel 2: Query TSC number and Set number
CONFigure:MS:CHANnel:SLOT0:SUBChannel2:TSC?
// -> 0,2
// Subchannel 2: Query TSC number
CONFigure:MS:CHANnel:SLOT0:SUBChannel2:TSC? TSC
// -> 0
// Subchannel 2: Query Set number
CONFigure:MS:CHANnel:SLOT0:SUBChannel2:TSC? SET
// -> 2
```

Mode: GSM

CONFigure[:MS]:CHANnel:SLOT<s>:SUBChannel<ch>:TSC:USER <Value>

This command sets the bits of the user definable TSC. The number of bits must be 26. `CONFigure[:MS]:CHANnel:SLOT<s>:SUBChannel<ch>:TSC:USER` must be set first.

This command is only available for AQPSK modulation.

Suffix:

<s> <0..7>
Number of slot to configure

<ch> <1|2>
 Subchannel number

Parameters for setting and query:

<Value> string
 String containing the 26 user-defined bits

Example:

```
// Enter the GSM option K10
INSTRUMENT:SElect GSM
// Activate slot 0
CONFigure:MS:CHANnel:SLOT0:STATE ON
// Normal Burst
CONFigure:MS:CHANnel:SLOT0:TYPE NB
// AQPSK (VAMOS) modulation
CONFigure:MS:CHANnel:SLOT0:MTYPE AQPSk
// Subchannel 1: User TSC
CONFigure:MS:CHANnel:SLOT0:SUBChannel1:TSC USER
CONFigure:MS:CHANnel:SLOT0:SUBChannel1:TSC?
// -> USER
// Subchannel 1: Set User TSC bits
CONFigure:MS:CHANnel:SLOT0:SUBChannel1:TSC:USER
'10111101100110010000100001'
// Subchannel 1: Query User TSC bits
CONFigure:MS:CHANnel:SLOT0:SUBChannel1:TSC:
USER?
// -> 10111101100110010000100001
// Subchannel 2: User TSC
CONFigure:MS:CHANnel:SLOT0:SUBChannel2:TSC USER
CONFigure:MS:CHANnel:SLOT0:SUBChannel2:TSC?
// -> USER
// Subchannel 2: Set User TSC bits
CONFigure:MS:CHANnel:SLOT0:SUBChannel2:TSC:USER
'11010111111101011001110100'
// Subchannel 2: Query User TSC bits
CONFigure:MS:CHANnel:SLOT0:SUBChannel2:TSC:
USER?
// -> 11010111111101011001110100
```

Mode: GSM

CONFigure[:MS]:CHANnel:SLOT<s>:TSC <Value>

This command selects the training sequence code TSC (Normal and Higher Symbol Rate Bursts) or training (synchronization) sequence TS (for Access Bursts) of the specified slot and subchannel used by the mobile or base station. See 3GPP TS 45.002, chapter 5.2 'Bursts'.

This command is not available for AQPSK modulation (use [CONFigure\[:MS\]:CHANnel:SLOT<s>:SUBChannel<ch>:TSC](#) instead).

Suffix:

<s> 0..7
Number of the slot to configure

Query parameters:

<ResultType> TSC | SET
Queries the currently used TSC number or the set.
If no query parameter is defined, only the TS or the TSC is returned.

TSC

Only the TSC or TS is returned.

SET

The set of the TSC is returned.

Parameters for setting and query:

<Value> 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 0,1 | 0,2 | 1,1 | 1,2 | 2,1 | 2,2 | 3,1 | 3,2 |
4,1 | 4,2 | 5,1 | 5,2 | 6,1 | 6,2 | 7,1 | 7,2 | TS0 | TS1 | TS2 | USER
Training sequence for Normal Burst
0...7
One of the 7 pre-defined training sequence codes is used
**0,1 | 0,2 | 1,1 | 1,2 | 2,1 | 2,2 | 3,1 | 3,2 | 4,1 | 4,2 | 5,1 | 5,2 | 6,1 |
6,2 | 7,1 | 7,2**
TSC number and set for Normal Bursts
TS0 | TS1 | TS2
Training (synchronization) sequence for Access Bursts
USER
A user-defined training sequence is used (see [CONFigure\[:MS\]:CHANnel:SLOT<s>:TSC:USER](#) on page 118).
*RST: 0

```

Example:          // Enter the GSM option K10
                    INSTRument:SElect GSM
                    // Activate slot 0
                    CONFigure:MS:CHANnel:SLOT0:STATE ON
                    // Normal Burst
                    CONFigure:MS:CHANnel:SLOT0:TYPE NB
                    // --- GMSK modulation ---
                    CONFigure:MS:CHANnel:SLOT0:MTYPE GMSK
                    // TSC 3 (Set 1)
                    CONFigure:MS:CHANnel:SLOT0:TSC 3,1
                    // Query TSC number
                    // Note: For backwards compatibility only
                    // the TSC number is returned.
                    CONFigure:MS:CHANnel:SLOT0:TSC?
                    // -> 3
                    // Query TSC number
                    CONFigure:MS:CHANnel:SLOT0:TSC? TSC
                    // -> 3
                    // Query Set number
                    CONFigure:MS:CHANnel:SLOT0:TSC? SET
                    // -> 1
                    // --- 8PSK modulation ---
                    CONFigure:MS:CHANnel:SLOT0:MTYPE PSK8
                    // TSC 3
                    CONFigure:MS:CHANnel:SLOT0:TSC 3
                    // Query TSC number
                    CONFigure:MS:CHANnel:SLOT0:TSC?
                    // -> 3

Mode:           GSM

```

CONFigure[:MS]:CHANnel:SLOT<s>:TSC:USER <Value>

This command sets the bits of the user definable TSC. The number of bits must be in accordance with the defined burst type and modulation (as indicated in "[User TSC](#)" on page 69). `CONFigure:MS:CHANnel:SLOT0:TSC USER` must be defined first (see [CONFigure\[:MS\]:CHANnel:SLOT<s>:TSC](#) on page 116).

Note: This command is not available for AQPSK modulation (use [CONFigure\[:MS\]:CHANnel:SLOT<s>:SUBChannel<ch>:TSC:USER](#) on page 115 instead).

Suffix:

```

<s>                <0..7>
                    The slot to configure

```

Parameters for setting and query:

```

<Value>           String containing the user defined bits, e.g.
                    '101011110101010100111100' for a GMSK normal burst.

```

```

Example:          // Enter the GSM option K10
                    INSTRument:SElect GSM
                    // Activate slot 0
                    CONFigure:MS:CHANnel:SLOT0:STATE ON
                    // Deactivate all other slots(1-7)
                    CONFigure:MS:CHANnel:SLOT1:STATE OFF
                    CONFigure:MS:CHANnel:SLOT2:STATE OFF
                    CONFigure:MS:CHANnel:SLOT3:STATE OFF
                    CONFigure:MS:CHANnel:SLOT4:STATE OFF
                    CONFigure:MS:CHANnel:SLOT5:STATE OFF
                    CONFigure:MS:CHANnel:SLOT6:STATE OFF
                    CONFigure:MS:CHANnel:SLOT7:STATE OFF
                    // Set slot 0 to GMSK
                    CONFigure:MS:CHANnel:SLOT0:MTYPE GMSK
                    // User TSC 0 as user TSC in slot 0
                    CONFigure:MS:CHANnel:SLOT0:TSC USER
                    CONFigure:MS:CHANnel:SLOT0:TSC:USER
                    '00100101110000100010010111 '
                    // Activate EVM vs Time measurement
                    CONFigure:BURSt:ETIME
                    // Switch to split screen mode
                    DISPlay:FORMat SPLit
                    // Run a (blocking) single sweep
                    INITiate:IMMediate;*WAI
                    // Read the averaged EVM RMS value
                    FETCh:BURSt:MACCuracy:EVM:RMS:AVERage?
                    // -> 0.388730555772781

```

Mode: GSM

CONFigure[:MS]:CHANnel:SLOT<s>:TYPE <Value>

Specifies the type of the burst.

Suffix:

<s> <0..7>

Parameters for setting and query:

<Value> NB | HB | AB

NB
Normal Burst

HB
Higher Symbol Rate Burst

AB
Access Burst

*RST: NB

Example: CONF:CHAN:SLOT:TYPE NB

Mode: GSM

CONFigure[:MS]:CHANnel:TSC <Value>

Sets the TSC of the 'Slot to measure'. Refrain from using this command in new K10 remote scripts and use pure K10 remote commands instead. Use `CONFigure[:MS]:CHANnel:SLOT<s>:TYPE` and `CONFigure[:MS]:CHANnel:SLOT<s>:TSC`

Parameters for setting and query:

<Value> TSC number
0 | 1 | 2 | 3 | 4 | 5 | 6 | 7
 TSC number (Normal Burst)
AB0 | AB1 | AB2
 TS number (Access Burst)
USER
 User-defined TSC
 *RST: 0

Example: `CONFigure:MS:CHANnel:TSC 0`

Mode: GSM

CONFigure[:MS]:CHANnel:TSC:USER <Value>

This command sets the bits of the user definable TSC of the "Slot to measure". The number of bits must be in accordance with the set burst type and modulation. `CONFigure:MS:CHANnel:TSC USER` needs to be set first.

Refrain from using this command in new K10 remote scripts and use pure K10 remote commands instead. Use `CONFigure:MS:CHANnel:SLOT0:TSC USER` and `CONFigure:MS:CHANnel:SLOT0:TSC:USER '10101111101010101100111100'`.

Parameters for setting and query:

<Value> string

Example: `CONFigure:MS:CHANnel:TSC:USER '10101111101010101100111100'`

Mode: GSM

CONFigure[:MS]:DEMod:DECision <Value>

This command determines how the symbols are detected in the demodulator. The setting of this parameter does not effect the demodulation of Normal Bursts with GMSK modulation. For Normal Bursts with 8PSK, 16QAM, 32QAM or AQPSK modulation or Higher Symbol Rate Bursts with QPSK, 16QAM or 32QAM modulation use this parameter to get a trade-off between performance (symbol error rate of the K10) and measurement speed.

Parameters for setting and query:

<Value> AUTO | LINear | SEQuence

Symbol decision method

AUTO

Automatically selects the symbol decision method.

LINear

Linear symbol decision: Uses inverse filtering (a kind of zero-forcing filter) and a symbol-wise decision method. This method is recommended for high symbol to noise ratios, but not for Higher Symbol Rate bursts with a narrow pulse. The inverse filter colors the noise inside the signal bandwidth and therefore is not recommended for narrow-band signals or signals with a low signal to noise ratio. Peaks in the "EVM vs Time" measurement (see [chapter 3.1.4, "EVM vs Time"](#), on page 15) may occur if the "Linear" symbol decision algorithm fails. In that case use the "Sequence" method. Linear is the fastest option.

SEQuence

Symbol decision via sequence estimation. This method uses an algorithm that minimizes the symbol errors of the entire burst. It requires that the tail bits in the analyzed signal are correct. It has a better performance (lower symbol error rate) compared to the "Linear" method, especially at low signal to noise ratios, but with a loss of measurement speed. This method is recommended for normal bursts with 16QAM or 32QAM modulation and for Higher Symbol Rate bursts with a narrow pulse.

*RST: AUTO

```

Example:          // Preset the instrument
                    *RST
                    // Enter the GSM option K10
                    INSTRument:SElect GSM
                    // Switch to single sweep mode and stop sweep
                    INITiate:CONTinuous OFF;:ABORT
                    // Activate EVM vs Time measurement
                    CONFigure:BURSt:ETIME:IMMediate
                    // Set slot 0: Higher Symbol Rate burst, 16QAM, Wide Pulse &
                    TSC 0
                    CONFigure:MS:CHANnel:SLOT0:STATE ON
                    CONFigure:MS:CHANnel:SLOT0:TYPE HB
                    CONFigure:MS:CHANnel:SLOT0:MTYPE QAM16
                    CONFigure:MS:CHANnel:SLOT0:FILTer WIDE
                    CONFigure:MS:CHANnel:SLOT0:TSC 0
                    // Use 'sequence estimator' for the symbol decision
                    CONFigure:MS:DEMod:DECision SEquence
                    // Run a (blocking) single sweep
                    INITiate:IMMediate;*WAI
                    // Read the averaged EVM RMS value
                    FETCh:BURSt:MACCuracy:EVM:RMS:AVERAge?
                    // Use the 'linear' method for the symbol decision
                    CONFigure:MS:DEMod:DECision LINear
                    // Run a (blocking) single sweep
                    INITiate:IMMediate;*WAI
                    // Read the averaged EVM RMS value
                    FETCh:BURSt:MACCuracy:EVM:RMS:AVERAge?

Mode:           GSM

```

CONFigure[:MS]:DEMod:STDBits <Value>

The R&S FSV-K10 demodulator requires the bits of the burst (Tail, Data, TSC, Data, Tail) to provide an ideal version of the measured signal. The "Data" bits can be random and are typically not known inside the demodulator of the R&S FSV-K10. "Tail" and "TSC" bits are specified in the "Burst" dialog box (see ["Burst"](#) on page 66). Using the "Tail & TSC Bits" setting you can select whether the detected Tail and TSC bits or the standard bits (as set in the "Burst" dialog box) are used to construct the ideal signal. Using the standard bits can be advantageous to verify whether the device under test sends the correct Tail and TSC bits. Incorrect bits would lead to peaks in the "EVM vs Time" trace (see [chapter 3.1.4, "EVM vs Time"](#), on page 15) at the positions of the incorrect bits.

Parameters for setting and query:

```

<Value>           DETected | STD
                    *RST:      DETected

```

Example:

```
// Preset the instrument
*RST
// Enter the GSM option K10
INSTrument:SElect GSM
// Switch to single sweep mode and stop sweep
INITiate:CONTinuous OFF;:ABORT
// Activate EVM vs Time measurement
CONFigure:BURSt:ETIME:IMMediate
// Replace detected Tail & TSC bits by the standard bits
CONFigure:MS:DEMod:STDBits STD
// Run a (blocking) single sweep
INITiate:IMMediate;*WAI
// Read the averaged EVM RMS value
FETCh:BURSt:MACCuracy:EVM:RMS:AVErage?
```

Mode: GSM

CONFigure[:MS]:DEVice:TYPE <Value>

This command specifies the type of device to be measured.

Parameters for setting and query:

<Value> BTSNormal | BTSMicro | BTSPico | MSNormal | MSSMall

BTSNormal

BTS, TRX power class Normal

BTSMicro

BTS, TRX power class Micro

BTSPico

BTS, TRX power class Pico

MSNormal

MS, normal type

MSSMall

MS, small type

*RST: BTSNormal

Example: CONF:DEV:TYPE BTSNormal

Mode: GSM

CONFigure[:MS]:MCArrier[:STATe] <State>

This command is retained for compatibility with R&S FSV-K5 only. In new R&S FSV-K10 remote scripts use the commands described in the example below instead.

Parameters for setting and query:

<State> 1 | 0 | ON | OFF

*RST: 0

Example: \\Switch on mode for multi-carrier BTS measurements
 CONFigure:MS:MCARrier:STATe ON
 \\ Note: With the next command, a multi-carrier pre-filter for the
 "Demod" measurements is also activated internally.
 Switch on mode for multi-carrier BTS measurements.
 CONFigure:MS:MCARrier:MCBTs ON
 \\ Select K5-compatible multi-carrier pre-filter for PvT measure-
 ment.
 CONFigure:MS:MCARrier:FILTer MC300

Mode: GSM

CONFigure[:MS]:MCARrier:ACTCarriers <Value>

This parameter specifies the total number of active carriers of the multi-carrier BTS to be measured. Its value affects the calculation of the limits according to the 3GPP standard for the modulation spectrum measurement, see 3GPP2 TS 45.005 (chapter 4.2.1. "Spectrum due to modulation and wide band noise"). The limit is changed by $10 \cdot \log(N)$.

Parameters for setting and query:

<Value> numeric value
 Number of active carriers
 Range: 1 to 12
 *RST: 1
 Default unit: NONE

Example: CONF:MCAR:ACTC

Mode: GSM

CONFigure[:MS]:MCARrier:BTSClass <Value>

This command defines the base station class. The specified BTS Class effects the calculation of the limits according to the 3GPP standard for the modulation spectrum measurement, see 3GPP2 TS 45.005 (chapter 4.2.1. "Spectrum due to modulation and wide band noise" and chapter 4.3.2 "Base Transceiver Station", search for "Multicarrier BTS").

Parameters for setting and query:

<Value> 1 | 2
 *RST: 1

Example: CONF:MCAR:BTSClass

Mode: GSM

CONFigure[:MS]:MCARrier:FILTer <Value>

This command controls the filter used to reduce the measurement bandwidth for multi-carrier "Power vs Time" measurements.

For multi-carrier BTS, the PvT Filter parameter in the "Advanced" tab is ignored.

Parameters for setting and query:

<Value> MC400 | MC300

PvT filter type

MC400

Recommended for measurements with multi-channels of equal power.

MC300

Recommended for measurement scenarios where a total of six channels is active and the channel to be measured has a reduced power (e.g. 30 dB) compared to its adjacent channels.

The PvT filter is optimized to get smooth edges after filtering burst signals and to suppress adjacent, active channels.

*RST: MC400

Example:

CONF:MCAR:FILT MC400

Mode:

GSM

CONFigure[:MS]:MCARrier:MCBTs <State>

This parameter informs the R&S FSV-K10 that the measured signal is a multi-carrier signal. This function is only available if the "Device Type" is a "BTS" type (see [CONFigure\[:MS\]:DEVICE:TYPE](#) on page 123). If active, a special multi-carrier filter is switched into the demodulation path and further multi-carrier-specific parameters become available.

Parameters for setting and query:

<State> 1 | 0 | ON | OFF

ON

The measured signal is a multi-carrier signal.

OFF

The measured signal is a single-carrier signal.

*RST: OFF

Example:

CONF:MCAR:MCBT ON

Mode:

GSM

CONFigure[:MS]:MType <Value>

This command sets the modulation type of all slots.

Note: This command is retained for compatibility with R&S FS-K5 only.

Parameters for setting and query:

<Value> GMSK | EDGE

Modulation type

*RST: GMSK

Example:

```
// Enter the GSM option K10
INSTRument:SElect GSM
// Old FS-K5 commands
CONFigure:MS:MTYPE EDGE
// Please use the following K10 commands instead
// K5: 'GMSK' -> K10: 'GMSK'
// K5: 'EDGE' -> K10: 'PSK8'
CONFigure:MS:CHANnel:SLOT0:MTYPE PSK8
CONFigure:MS:CHANnel:SLOT1:MTYPE PSK8
CONFigure:MS:CHANnel:SLOT2:MTYPE PSK8
CONFigure:MS:CHANnel:SLOT3:MTYPE PSK8
CONFigure:MS:CHANnel:SLOT4:MTYPE PSK8
CONFigure:MS:CHANnel:SLOT5:MTYPE PSK8
CONFigure:MS:CHANnel:SLOT6:MTYPE PSK8
CONFigure:MS:CHANnel:SLOT7:MTYPE PSK8
// Old FS-K5 commands
CONFigure:MS:CHANnel:SLOT1:MTYPE GMSK
CONFigure:MS:CHANnel:SLOT1:MTYPE?
// -> GMSK
// Please use the following K10 commands instead
CONFigure:MS:CHANnel:MSLots:MEASure?
// -> 0 This is the slot number of the 'slot to measure'
// Set and query the modulation of the 'slot to measure'
CONFigure:MS:CHANnel:SLOT0:MTYPE GMSK
CONFigure:MS:CHANnel:SLOT0:MTYPE?
// -> GMSK
```

Mode: GSM

CONFigure[:MS]:MULTi:BURSt:CONStell <State>

Use this command to always include / exclude the calculation of the results of the "Constellation" measurement when the multiple measurement mode is active (see [CONFigure\[:MS\]:MULTi:STATe](#)).

Parameters for setting and query:

```
<State>          1 | 0 | ON | OFF
                 ON
                 Calculate "Constellation" results.
                 OFF
                 Do not calculate "Constellation" results.
                 *RST:      1
```

Mode: GSM

CONFigure[:MS]:MULTi:BURSt:DEModulation <State>

Use this command to always include / exclude the calculation of the results of the Modulation Accuracy, EVM vs Time, Phase Error vs Time and Magnitude Error vs Time measurements when the multiple measurement mode is active (see [CONFigure\[:MS\]:MULTi:STATe](#)).

Parameters for setting and query:

<State> 1 | 0 | ON | OFF

ON

Calculate Modulation Accuracy, EVM vs Time, Phase Error vs Time and Magnitude Error vs Time results.

OFF

Do not calculate Modulation Accuracy, EVM vs Time, Phase Error vs Time and Magnitude Error vs Time results.

*RST: 1

Mode: GSM

CONFigure[:MS]:MULTi:BURSt:PTEmplate <State>

Use this command to always include / exclude the calculation of the (graph and list) results of the "Power vs Time" measurement when the multiple measurement mode is active (see [CONFigure\[:MS\]:MULTi:STATe](#)).

Parameters for setting and query:

<State> 1 | 0 | ON | OFF

ON

Calculate Power vs Time (list and graph) results.

OFF

Do not calculate Power vs Time (list and graph) results.

*RST: 1

Mode: GSM

CONFigure[:MS]:MULTi:SPECTrum:MODulation <State>

Use this command to always include / exclude the calculation of the results of the "Modulation Spectrum" measurement when the multiple measurement mode is active (see [CONFigure\[:MS\]:MULTi:STATe](#) on page 128).

Note: When activated, list results are returned. To obtain graphical results, use `CONFigure:SPECTrum:SElect FREQdomain`, see [CONFigure:SPECTrum:SElect](#) on page 143.

Parameters for setting and query:

<State> 1 | 0 | ON | OFF

ON

Calculate "Modulation Spectrum" results.

OFF

Do not calculate "Modulation Spectrum" results.

*RST: 1

Example:

CONFigure:MS:MULTi:SPECTrum:MODulation ON

Mode:

GSM

CONFigure[:MS]:MULTi:SPECTrum:SWITChing <State>

Use this command to always include / exclude the calculation of the results of the "Transient Spectrum" measurement when the multiple measurement mode is active (see [CONFigure\[:MS\]:MULTi:STATe](#)).

Note: When activated, list results are returned. To obtain graphical results, use `CONFigure:SPECTrum:SElect FREQdomain`, see [CONFigure:SPECTrum:SElect](#) on page 143.

Parameters for setting and query:

<State> 1 | 0 | ON | OFF

ON

Calculate Transient Spectrum results.

OFF

Do not calculate Transient Spectrum results.

*RST: 1

Mode:

GSM

CONFigure[:MS]:MULTi:STATe <State>

This command activates the multiple measurement mode. Multiple measurement mode means that several measurement results can be calculated on the same I/Q data capture in parallel. If it is known in advance which measurement results are required, then use the multiple measurement mode to reduce total measurement time. When active, only the results of the selected measurements are available. Measurements that are not selected are not available.

Parameters for setting and query:

<State> 1 | 0 | ON | OFF

*RST: 0


```

Example:           // Multiple measurement mode example for a 16QAM signal
                    // Preset the instrument
                    *RST
                    // Enter the GSM option K10
                    INSTRument:SElect GSM
                    // Switch to single sweep mode and stop sweep
                    INITiate:CONTinuous OFF;:ABORT
                    // Set the center frequency to 935 MHz
                    SENSE1:FREQuency:CENTer 935MHz
                    // Multiple measurement mode example for a 16QAM signal
                    // Configure for a 16QAM signal
                    CONFigure:MS:CHANnel:SLOT0 ON
                    CONFigure:MS:CHANnel:SLOT0:TYPE NB
                    CONFigure:MS:CHANnel:SLOT0:MTYPE QAM16
                    CONFigure:MS:CHANnel:SLOT0:FILTer LINearised
                    CONFigure:MS:CHANnel:SLOT1 OFF
                    CONFigure:MS:CHANnel:SLOT2 OFF
                    CONFigure:MS:CHANnel:SLOT3 OFF
                    CONFigure:MS:CHANnel:SLOT4 OFF
                    CONFigure:MS:CHANnel:SLOT5 OFF
                    CONFigure:MS:CHANnel:SLOT6 OFF
                    CONFigure:MS:CHANnel:SLOT7 OFF
                    // Set the statistic count
                    SENSE1:SWEep:COUNT 200
                    // Activate the multi meas mode
                    CONFigure:MS:MULTi:STATE 1
                    // Select all required measurements
                    CONFigure:MS:MULTi:BURSt:DEModulation 1
                    CONFigure:MS:MULTi:SPECTrum:MODulation 1
                    CONFigure:MS:MULTi:BURSt:PTEMplate 1
                    CONFigure:MS:MULTi:SPECTrum:SWITChing 1
                    // Turn off the display while the measurement is running
                    SYST:DISP:UPD OFF
                    // Run a (blocking) single sweep
                    INITiate:IMMediate;*WAI
                    // Turn on the display to view results
                    SYST:DISP:UPD ON

```

Mode: GSM

CONFigure[:MS]:NETWork[:TYPE] <Value>

This command works in conjunction with the CONFigure[:MS]:NETWork:FRE-Quency:BAND command to specify the frequency band of the signal to be measured. The command is not in-line with the manual operation to hold the SCPI remote control part compatible with the R&S FS-K5.

Parameters for setting and query:

<Value> PGSM | EGSM | DCS | PCS | TGSM | RGSM | GSM

PGSM

Primary GSM

EGSM

Extended GSM

DCS

DCS

PCS

PCS

TGSM

T-GSM

RGSM

Railway GSM

GSM

GSM

*RST: EGSM

Example: CONF:NETW PGSM

Mode: GSM

CONFigure[:MS]:NETWork:FREQuency:BAND <Value>

This command works in conjunction with the CONFigure[:MS]:NETWork[:TYPE] command to specify the frequency band of the signal to be measured. The command is not in-line with the manual operation to hold the SCPI remote control part compatible with the R&S FS-K5.

Parameters for setting and query:

<Value>	380 410 450 480 710 750 810 850 900 1800 1900
380	380 MHz band – valid for TGSM
410	410 MHz band – valid for TGSM
450	450 MHz band – valid for GSM
480	480 MHz band – valid for GSM
710	710 MHz band – valid for GSM
750	750 MHz band – valid for GSM
810	810 MHz band – valid for TGSM
850	850 MHz band – valid for GSM
900	900 MHz band – valid for PGSM, EGSM, RGSM and TGSM
1800	1800 MHz band – valid for DCS
1900	1900 MHz band – valid for PCS
*RST:	900

Example: CONF:NETW:FREQ 380

Mode: GSM

CONFigure[:MS]:POWer:CLASs <Value>

This command the power class of the device under test.

Parameters for setting and query:

<Value> 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | E1 | E2 | E3 | M1 | M2 | M3 | P1

1
MS and BTS power class 1

2
MS and BTS power class 2

3
MS and BTS power class 3

4
MS and BTS power class 4

5
MS and BTS power class 5

6
BTS power class 6

7
BTS power class 7

8
BTS power class 8

E1
MS power class E1

E2
MS power class E2

E3
MS power class E3

M1
BTS power class M1 (Micro)

M2
BTS power class M2 (Micro)

M3
BTS power class M3 (Micro)

P1
BTS power class P1 (Pico)

*RST: 2

Example: CONF:POW:CLAS 1

Mode: GSM

CONFigure[:MS]:POWer:STATic <Value>

This command is now obsolete and is retained for compatibility reasons only.

Parameters for setting and query:

<Value> numeric value

BTS static power step / power control level.

Default unit: NONE

Example: `CONF:POW:STAT 5`

Mode: GSM

CONFigure[:MS]:POWer:AUTO <Value>

This command is used to switch on or off automatic power level detection. When switched on, power level detection is performed at the start of each measurement sweep. Using the ONCE argument starts the auto level measurement immediately.

Parameters for setting and query:

<Value> OFF | ON | ONCE

OFF
Switch the function off

ON
Switch the function on

ONCE
Execute the function once

*RST: ON

Example: `CONF:POW:AUTO OFF`

Mode: GSM

CONFigure[:MS]:POWer:AUTO:SWEep:TIME <Value>

This command is used to specify the auto track time, i.e. the sweep time for auto level measurements or swept measurements and the capture time for auto detection.

Parameters for setting and query:

<Value> numeric value

Auto level measurement sweep time

Range: 0.01 to 1

*RST: 0.1 s

Default unit: S

Example: `CONF:POW:AUTO:SWE:TIME 0.01 MS`

Mode: GSM

CONFigure[:MS]:PRATe <Value>

This command is retained for compatibility with R&S FS-K5 only. This command has no effect.

Parameters for setting and query:

<Value> numeric value

*RST: 4

Default unit: NONE

Mode: GSM

CONFigure[:MS]:REStore

This command is retained for compatibility with R&S FS-K5 only. This command has no effect.

Mode: GSM

CONFigure[:MS]:SSEarch <State>

This command is retained for compatibility with R&S FSV-K5 only. In new K10 remote scripts use `CONFigure:MS:SYNC:MODE TSC` or `CONFigure:MS:SYNC:MODE ALL` instead (see [CONFigure\[:MS\]:SYNC:MODE](#) on page 134).

Parameters for setting and query:

<State> 1 | 0 | ON | OFF

ON

TSC search on

OFF

TSC search off

*RST: 1

Example: `CONF:SSE ON`

Mode: GSM

CONFigure[:MS]:SYNC:IQThreshold <Value>

This command sets the IQ correlation threshold. The IQ correlation threshold decides whether a burst is accepted if "Measure only on Sync" is activated (see [CONFigure\[:MS\]:SYNC:ONLY](#) on page 135). If the correlation value between the ideal IQ signal of the given TSC and the measured TSC is below the IQ correlation threshold, then the application reports "Sync not found" in the status bar. Additionally, such bursts are ignored if "Measure only on Sync" is activated.

Parameters for setting and query:

<Value> numeric value

IQ Correlation Threshold

Range: 0 to 100

*RST: 85

Default unit: NONE

Example: `CONF:SYNC:IQCT 0`

Mode: GSM

CONFigure[:MS]:SYNC:MODE <Value>

This command sets the synchronization mode of the R&S FSV-K10.

Parameters for setting and query:

<Value> ALL | TSC | BURSt | NONE

ALL

First search for the power profile (burst search) according to the frame configuration in the capture buffer. Second, inside the found bursts search for the TSC of the "Slot to measure" as given in the frame configuration. "ALL" is usually faster than "TSC" for bursted signals.

TSC

Search the capture buffer for the TSC of the "Slot to measure" as given in the frame configuration. This mode corresponds to a correlation with the given TSC. This mode can be used for continuous (but framed) signals or bursted signals.

BURSt

Search for the power profile (burst search) according to the frame configuration in the capture buffer.

Note: For "Burst" no demodulation measurements (e.g. "Modulation Accuracy") are supported. Only "Power vs Time", "Modulation Spectrum", "Transient Spectrum" measurements are supported.

NONE

Do not synchronize at all. If an external or power trigger is chosen, the trigger instant corresponds to the frame start.

Tip: Manually adjust the trigger offset to move the burst to be analyzed under the mask in the "Power vs Time" measurement.

Note: For "None" no demodulation measurements (e.g. "Modulation Accuracy") are supported. Only "Power vs Time", "Modulation Spectrum", "Transient Spectrum" measurements are supported.

*RST: ALL

Example:

CONF:SYNC:MODE TSC

Mode:

GSM

CONFigure[:MS]:SYNC:ONLY <State>

If activated, only results from frames (slots) where the "Slot to measure" was found are displayed and taken into account in the averaging of the results. The behavior of this function depends on the value of the "Synchronization" parameter (see [CONFigure\[:MS\]:SYNC:MODE](#) on page 134).

Parameters for setting and query:

<State> 1 | 0 | ON | OFF

1 | ON

measure only on sync

0 | OFF

always measure even if sync not found

*RST: OFF

Example: `CONF:SYNC:MODE TSC`
 Search the capture buffer for the TSC of the "Slot to measure" as given in the frame configuration.
`CONF:SYNC:ONLY ON`
 Only if the TSC is found, the results are displayed.

Mode: GSM

4.4.2 CONFigure:BURSt subsystem

Commands of the Configure:BURSt subsystem:

CONFigure:BURSt:CONStell[:IMMEDIATE]	136
CONFigure:BURSt:ETIMe[:IMMEDIATE]	136
CONFigure:BURSt:MACCuracy[:IMMEDIATE]	136
CONFigure:BURSt:MERRor[:IMMEDIATE]	137
CONFigure:BURSt:PFERror[:IMMEDIATE]	137
CONFigure:BURSt:PTEMplate[:IMMEDIATE]	137
CONFigure:BURSt:PTEMplate:FILTer	137
CONFigure:BURSt:PTEMplate:FRZoom	138
CONFigure:BURSt:PTEMplate:SELect	138
CONFigure:BURSt:PTEMplate:TALign	138
CONFigure:BURSt:PTEMplate:TMHRes	139

CONFigure:BURSt:CONStell[:IMMEDIATE]

This command selects the constellation measurement.

Example: `CONF:BURS:CONS`

Usage: Setting only

Mode: GSM

CONFigure:BURSt:ETIMe[:IMMEDIATE]

This command selects measurement of the EVM Vs time.

Example: `CONF:BURS:ETIM`

Usage: Setting only

Mode: GSM

CONFigure:BURSt:MACCuracy[:IMMEDIATE]

This command selects measurement of the modulation accuracy.

Example: `CONF:BURS:MACC`

Usage: Setting only

Mode: GSM

CONFigure:BURSt:MERRor[:IMMediate]

This command selects measurement of the "Magnitude Error vs Time" (see [chapter 3.1.5, "Magnitude Error vs Time"](#), on page 17).

Example: CONF: BURS: MERR

Usage: Setting only

Mode: GSM

CONFigure:BURSt:PFERror[:IMMediate]

This command selects measurement of the "Phase Error vs Time" (see [chapter 3.1.3, "Phase Error vs Time"](#), on page 14).

Example: CONF: BURS: PFER

Usage: Setting only

Mode: GSM

CONFigure:BURSt:PTEMplate[:IMMediate]

This command selects the measurement of power vs. time (PvT) of the mobile or base station. Both graph and list results (slot power and "Delta to Sync" values) are displayed.

Example: CONF: BURS: PTEM

Usage: Setting only

Mode: GSM

CONFigure:BURSt:PTEMplate:FILTer <Value>

The PvT Filter controls the filter used to reduce the measurement bandwidth for single carrier "Power vs Time" measurements. The parameter is only available if "Multi Carrier BTS" in the Multi Carrier tab is switched off (see ["Multi Carrier BTS"](#) on page 77). Therefore the "PvT Filter" parameter in the "Multi Carrier" tab is ignored in the single carrier case.

Parameters for setting and query:

<Value> G1000 | G500 | B600

B600

Default Lowpass, 600 kHz

G500

Gaussian Filter, 500 kHz

G1000

Gaussian Filter, 1000 kHz

*RST: G1000

Example: `CONF:BURS:PTEM:FILT G500`

Mode: GSM

CONFigure:BURSt:PTEMplate:FRZoom <Value>

This command is retained for compatibility with R&S FSV-K5 only. Use the "Measurement Slot" selection to zoom the corresponding area.

Parameters for setting and query:

<Value> numeric value
 *RST: 1
 Default unit: NONE

Example: `CONF:BURS:PTEM:FRZ 5`

Mode: GSM

CONFigure:BURSt:PTEMplate:SELEct <Value>

Parameters for setting and query:

<Value> FULL | RISing | FALLing | TOP | FRISing

FULL

Full burst; all bursts in the slot scope are displayed

RISing

Rising edges only (the rest of the bursts are removed)

FALLing

Falling edges only (the rest of the bursts are removed)

TOP

Top high resolution (the Y axis is stretched to show the measurement slot power area in detail)

FRISing

Rising and Falling together (useful parts and guard intervals removed)

*RST: FULL

Example: `CONF:BURS:PTEM:SEL FULL`

Mode: GSM

CONFigure:BURSt:PTEMplate:TALign <Mode>

This command controls the time-alignment of the limit lines for the "Power vs Time" measurement (see "[Limit Time Alignment](#)" on page 72).

Parameters for setting and query:

<Mode> STMeasure | PSLot

STMeasure

For each slot the mid of TSC is derived from the measured mid of TSC of the "Slot to measure" and the timeslot lengths specified in the standard (see "Timeslot length" in 3GPP TS 45.010).

PSLot

For each slot the mid of TSC is measured. This provides reasonable time-alignment if the slot lengths are not according to standard. However, the "Power vs Time" limit check is also passed.

*RST: STMeasure

Example: CONF: BURS: PTEM: TAL PSL

Mode: GSM

CONFigure: BURSt: PTEmplate: TMHRes <State>

This command is retained for compatibility with R&S FSV-K5 only. Due to the improved measurement capabilities of this GSM analysis software, this remote control command (and the function behind) is not required any more.

Parameters for setting and query:

<State> 1 | 0 | ON | OFF

*RST: ON

Example: CONF: BURS: PTEM: TMHR

Mode: GSM

4.4.3 CONFigure: SPECTrum subsystem**Commands of the Configure: SPECTrum subsystem:**

CONFigure: SPECTrum: HDYnamic.....	140
CONFigure: SPECTrum: LIMit: LEFT.....	140
CONFigure: SPECTrum: LIMit: RIGHT.....	141
CONFigure: SPECTrum: MODulation[: IMMEDIATE].....	141
CONFigure: SPECTrum: MODulation: LIMIT.....	141
CONFigure: SPECTrum: MODulation: LIST: BANDwidth: RESolution.....	142
CONFigure: SPECTrum: SElect.....	143
CONFigure: SPECTrum: SWITching[: IMMEDIATE].....	144
CONFigure: SPECTrum: SWITching: LIMIT.....	144
CONFigure: SPECTrum: SWITching: TYPE.....	145

CONFigure:SPECTrum:HDYNamic <State>

If activated, the results of the (I/Q-based) "Modulation Spectrum" measurement (see [CONFigure:SPECTrum:MODulation\[:IMMediate\]](#) on page 141) are corrected by the instrument's inherent noise, which increases the dynamic range.

When "High Dynamic" is activated, a measurement of the instrument's inherent noise is automatically carried out. The instrument's inherent noise is then removed from the measured results. The inherent noise of the instrument depends on the selected center frequency and level setting. Therefore the measurement of the inherent noise is repeated whenever one of these parameters is changed.

In addition, for instruments with (early) detector boards with an even hardware code (see column "HWC" in the hardware information dialog) phase noise is reduced (at 600 kHz offset frequencies).

For best performance for modulation accuracy measurements on instruments with early detector boards, deactivate the "High Dynamic" mode.

Parameters:

<State> ON | OFF
*RST: OFF

Example:

```
// Select Modulation Spectrum measurement
// (measurement on captured I/Q data)
CONFigure:SPECTrum:MODulation:IMMediate
// Activate high dynamic mode
CONF:SPEC:HDYN ON
```

Mode: GSM

CONFigure:SPECTrum:LIMit:LEFT <State>

This command controls the left limit check of the spectrum trace (spectrum graph measurement) and which offset frequencies in the table (spectrum list measurement) are checked against the limit. This command affects the "Modulation Spectrum" and "Transient Spectrum" measurements.

Note: For measurements on multi-carrier signals, use either the check on the left or right side to measure the spectrum of the left- or right-most channel and to ignore the side where adjacent channels are located.

Parameters for setting and query:

<State> 1 | 0 | ON | OFF
ON
check limit
OFF
do not check limit
*RST: 1

Example: CONF:SPEC:LIM:LEFT OFF

Mode: GSM

CONFigure:SPECTrum:LIMit:RIGHT <State>

This command controls the right limit check of the spectrum trace (spectrum graph measurement) and which offset frequencies in the table (spectrum list measurement) are checked against the limit. This command affects the "Modulation Spectrum" and "Transient Spectrum" measurements.

Note: For measurements on multi-carrier signals, use either the check on the left or right side to measure the spectrum of the left- or right-most channel and to ignore the side where adjacent channels are located.

Parameters for setting and query:

<State> 1 | 0 | ON | OFF
 ON
 check limit
 OFF
 do not check limit
 *RST: 1

Example: CONF:SPEC:LIM:LEFT OFF

Mode: GSM

CONFigure:SPECTrum:MODulation[:IMMEDIATE]

This command selects measurement of the spectrum due to modulation (MOD). This measurement is based on captured I/Q data. Use the Wide Modulation spectrum measurements for measurements in zero span mode (see [CONFigure:WSPECTrum:MODulation\[:IMMEDIATE\]](#) on page 146).

Example: CONF:SPEC:MOD

Usage: Setting only

Mode: GSM

CONFigure:SPECTrum:MODulation:LIMIT <Mode>

This command selects whether the list results (power and limit values) of the "Modulation Spectrum" measurement are returned in a relative (dB) or absolute (dBm) unit. This command is only available when the "Modulation Spectrum" measurement is selected (see [CONFigure:SPECTrum:MODulation\[:IMMEDIATE\]](#) on page 141).

Parameters for setting and query:

<Mode> ABSolute | RELative
 *RST: RELative

```

Example:           // Select Modulation Spectrum measurement
                    // (measurement on captured I/Q data)
                    CONFigure:SPECTrum:MODulation:IMMediate
                    // Only list results are required
                    CONFigure:SPECTrum:SElect LIST
                    // Absolute power and limit results in dBm
                    CONFigure:SPECTrum:MODulation:LIMit ABSolute
                    // Run one measurement and query absolute list results
                    READ:SPECTrum:MODulation:ALL?
                    // -> 0,933200000,933200000,-108.66,-65.00,ABS,PASSED, ...

```

Mode: GSM

CONFigure:SPECTrum:MODulation:LIST:BANDwidth:RESolution <OffsetFreq>, <RBW_VBW>

This command controls the resolution bandwidth (RBW) and video bandwidth (VBW) used in the [Modulation Spectrum](#) and [Wide Modulation Spectrum](#) measurements at offset frequencies of +/- 1800 kHz from the carrier.

Parameters:

<RBW_VBW> 30000 | 100000
 RBW and VBW in Hz at the given offset frequency

Setting parameters:

<OffsetFreq> offset frequency in Hz
 Range: 1800000
 *RST: 1800000

```

Example:         // --- Mod. Spectrum measurement ---
                    // (measurement on captured I/Q data)
                    CONFigure:SPECTrum:MODulation:IMMediate
                    // Only list results are required
                    CONFigure:SPECTrum:SElect LIST
                    // RBW = 100 kHz @ 1800 kHz offset freq.
                    CONFigure:SPECTrum:MODulation:LIST:
                    BANDwidth:RESolution 1800000,100000
                    // Check set value
                    CONFigure:SPECTrum:MODulation:LIST:BANDwidth:
                    RESolution? 1800000
                    // -> 100000
                    // Run a (blocking) single sweep
                    INITiate:IMMediate;*WAI
                    // Fetch list results (table)
                    FETCh:SPECTrum:MODulation:ALL?

```

```

Example:          // --- Wide Mod. Spectrum measurement ---
                    // (gated zero span measurement)
                    CONFigure:WSPepectrum:MODulation:IMMediate
                    // Measure offset freqs. up to 1800 kHz only
                    CONFigure:WSPepectrum:MODulation:LIST:SElect
                    NARRow
                    // RBW = 100 kHz @ 1800 kHz offset freq.
                    CONFigure:SPEctrum:MODulation:LIST:BANDwidth:
                    RESolution 1800000,100000
                    // Check set value
                    CONFigure:SPEctrum:MODulation:LIST:BANDwidth:
                    RESolution? 1800000
                    // -> 100000
                    // Run a (blocking) single sweep
                    INITiate:IMMediate;*WAI
                    // Fetch list results (table)
                    FETCh:WSPepectrum:MODulation:ALL?

```

Mode: GSM

CONFigure:SPEctrum:SElect <Mode>

This command selects how the modulation and transient spectrum measurement is performed and displayed.

Parameters for setting and query:

<Mode> LIST | FREQdomain

LIST

Spectrum results are measured at several frequency offsets from the center frequency. The results are displayed in a table.

FREQdomain

A spectrum trace is measured and displayed as a graph.

*RST: FREQdomain

```

Example:          // Preset the instrument
                    *RST
                    // Enter the GSM option K10
                    INSTRument:SElect GSM
                    // Switch to single sweep mode and stop sweep
                    INITiate:CONTinuous OFF;:ABORt
                    // Modulation spectrum graph measurement
                    CONFigure:SPECTrum:MODulation:IMMediate
                    // --- Graph example ---
                    // Graph (frequency domain) and List results are required
                    CONFigure:SPECTrum:SElect FREQdomain
                    // Run a (blocking) single sweep
                    INITiate:IMMediate;*WAI
                    // Fetch graph results, i.e. average trace (trace 1)
                    TRACel:DATA? TRACel
                    // Fetch list results (table)
                    FETCh:SPECTrum:MODulation:ALL?
                    // --- List example ---
                    // Only list results are required ---
                    CONFigure:SPECTrum:SElect LIST
                    // Run a (blocking) single sweep
                    INITiate:IMMediate;*WAI
                    // Fetch list results (table)
                    FETCh:SPECTrum:MODulation:ALL?

```

Mode: GSM

CONFigure:SPECTrum:SWITching[:IMMediate]

This command selects measurement of the spectrum due to switching transients (TRA).

Example: CONF:SPEC:SWIT

Usage: Setting only

Mode: GSM

CONFigure:SPECTrum:SWITching:LIMIT <Mode>

This command selects whether the list results (power and limit values) of the "Transient Spectrum" measurement are returned in a relative (dB) or absolute (dBm) unit. This command is only available when the "Transient Spectrum" measurement is selected (see [CONFigure:SPECTrum:SWITching\[:IMMediate\]](#) on page 144).

Parameters for setting and query:

<Mode> ABSolute | RELative
 *RST: RELative


```

Example:           // Select Transient Spectrum measurement
                    // (measurement on captured I/Q data)
                    CONFigure:SPECTrum:SWITChing:IMMediate
                    // Only list results are required
                    CONFigure:SPECTrum:SElect LIST
                    // Absolute power and limit results in dBm
                    CONFigure:SPECTrum:SWITChing:LIMit ABSolute
                    // Run one measurement and query absolute list results
                    READ:SPECTrum:SWITChing:ALL?
                    // -> 0,933200000,933200000,-101.55,-36.00,ABS,PASSED, ...

Mode:             GSM

```

CONFigure:SPECTrum:SWITChing:TYPE <DetectorMode>

This command controls how the reference power of the "Transient Spectrum" measurement (see [chapter 3.1.10, "Transient Spectrum"](#), on page 26) is measured.

Parameters for setting and query:

<DetectorMode> PEAK | RMS

RMS

(Default:) The reference power is the RMS power level measured over the useful part of the "Slot to measure" (see ["Slot to Measure"](#) on page 65) and averaged according to the defined "Statistic Count" (see ["Statistic Count"](#) on page 60).

PEAK

The reference power is the peak power level measured over the selected slot scope (see [chapter 3.2.8, "Defining the Scope of the Measurement"](#), on page 43) and its peak taken over [Statistic Count](#) measurements (GSM frames).

*RST: RMS

```

Example:         CONFigure:SPECTrum:SWITChing:TYPE?

```

```

Mode:           GSM

```

4.4.4 Other Commands in the CONFigure Subsystem

CONFigure:TRGS:ADPSize	145
CONFigure:TRGS:NOFBins	146
CONFigure:TRGS[:IMMediate]	146
CONFigure:WSPectrum:MODulation[:IMMediate]	146
CONFigure:WSPectrum:MODulation:LIMIT	148
CONFigure:WSPectrum:MODulation:LIST:SElect	148

CONFigure:TRGS:ADPSize <Value>

This command specifies the number of measurements after which the x-axis is fixed for the histogram calculation of the "Trigger to Sync" measurement.

Parameters for setting and query:

<Value> numeric value
 Adaptive data size
 Range: 10 to 1000
 *RST: 100
 Default unit: NONE

Mode: GSM

CONFigure:TRGS:NOFBins <Value>

This command specifies the number of bins for the histogram of the "Trigger to Sync" measurement.

Parameters for setting and query:

<Value> numeric value
 Number of bins
 Range: 10 to 1000
 *RST: 10
 Default unit: NONE

Mode: GSM

CONFigure:TRGS[:IMMediate]

This command selects the "Trigger to Sync" measurement. This measurement is only available for external trigger mode. Make sure that the "Trigger Offset" (in the "General Settings" dialog box, see "[Trigger Offset](#)" on page 60) is set correctly, e.g. using the "Auto Set" (Trigger) functionality of the R&S FSV-K10.

Usage: Setting only

Mode: GSM

CONFigure:WSPpectrum:MODulation[:IMMediate]

This command selects the measurement of the wide spectrum due to modulation (WMOD). The wide modulation spectrum measurement uses a series of zero span mode measurements and can measure offset frequencies up to 5.8 MHz. This command is only available for IF power or external trigger mode. Make sure that the Trigger Offset (in the "General Settings" dialog) is set correctly, e.g. using the Auto Set (Trigger) functionality of the R&S FSV-K10 (see "[Trigger Mode](#)" on page 60 and "[Trigger](#)" on page 80).

```

Example:          // Preset the instrument
                    *RST
                    // Enter the GSM option K10
                    INSTRument:SElect GSM
                    // Switch to single sweep mode and stop sweep
                    INITiate:CONTinuous OFF;;ABORT
                    // Switch display on
                    SYSTem:DISPlay:UPDate ON
                    // Activate slot 0
                    CONFigure:MS:CHANnel:SLOT0:STATE ON
                    // Deactivate all other slots(1-7)
                    CONFigure:MS:CHANnel:SLOT1:STATE OFF
                    CONFigure:MS:CHANnel:SLOT2:STATE OFF
                    CONFigure:MS:CHANnel:SLOT3:STATE OFF
                    CONFigure:MS:CHANnel:SLOT4:STATE OFF
                    CONFigure:MS:CHANnel:SLOT5:STATE OFF
                    CONFigure:MS:CHANnel:SLOT6:STATE OFF
                    CONFigure:MS:CHANnel:SLOT7:STATE OFF
                    // Set slot 0 to Normal Burst, GMSK, TSC 0
                    CONFigure:MS:CHANnel:SLOT0:TYPE NB
                    CONFigure:MS:CHANnel:SLOT0:MTYPE GMSK
                    // Set center frequency to 900 MHz
                    SENSE:FREQuency:CENTer 900MHZ
                    // Set the Ref level to 0 dbm
                    DISPlay:WINDow1:TRACe1:Y:SCALE:RLEVEL:RF 0
                    // Read back the Ref Level
                    DISPlay:WINDow1:TRACe1:Y:SCALE:RLEVEL:RF?
                    // Choose the Wide Modulation spectrum measurement
                    CONFigure:WSpectrum:MODulation:IMMediate
                    // Trigger Mode should be set to Power mode by default
                    TRIGger1:SEQuence:SOURce IFPower
                    // Run Auto Trigger (determine the trigger level and offset)
                    CONFigure:MS:AUTO:TRIGger ONCE;*OPC?
                    // Read out the trigger level
                    TRIGger1:SEQuence:LEVEL:IFPower?
                    // Read out the Trigger Offset
                    TRIGger1:SEQuence:HOLDoff:TIME?
                    // Set the statistic count to 50
                    SENSE:SWEep:COUNt 50
                    // Do one measurement and read out the results for all offset fre-
                    quencies
                    READ:WSpectrum:MODulation:ALL?

Usage:          Setting only
Mode:           GSM

```

CONFigure:WSPectrum:MODulation:LIMIT <Mode>

This command selects whether the list results (power and limit values) of the "Wide Modulation Spectrum" measurement are returned in a relative (dB) or absolute (dBm) unit. This command is only available when the "Wide Modulation Spectrum" measurement is selected (see [CONFigure:WSPectrum:MODulation\[:IMMEDIATE\]](#) on page 146).

Parameters for setting and query:

<Mode> ABSolute | RELative
*RST: RELative

Example:

```
// Select Wide Modulation Spectrum measurement
// (gated zero span measurement)
CONFigure:WSPectrum:MODulation:IMMEDIATE
// Absolute power and limit results in dBm
CONFigure:WSPectrum:MODulation:LIMit ABSolute
// Run one measurement and query absolute list results
READ:WSPectrum:MODulation:ALL?
// -> 0,929200000,929200000,-104.41,-65.00,ABS,PASSED, ...
```

Mode: GSM

CONFigure:WSPectrum:MODulation:LIST:SElect <Mode>

For [Wide Modulation Spectrum](#) measurements, this command controls whether offset frequencies are measured up to 1800 kHz or 5800 kHz.

Tip: Select "Narrow" to improve speed.

Parameters for setting and query:

<Mode> **NARRow**
The measurement is performed for offset frequencies up to 1800 kHz from the carrier; this setting improves measurement speed

WIDE
The measurement is performed for offset frequencies up to 5800 kHz from the carrier

*RST: WIDE

Example:

```
// Select Wide Modulation Spectrum measurement
// (gated zero span measurement)
CONFigure:WSPectrum:MODulation:IMMEDIATE
// Absolute power and limit results in dBm
CONFigure:WSPectrum:MODulation:LIST:SElect
NARRow
// RBW = 100 kHz @ 1800 kHz offset freq.
CONFigure:SPECTrum:MODulation:LIST:BANDwidth:
RESolution 1800000,100000
// Run a (blocking) single sweep
INITiate:IMMEDIATE;*WAI
// Fetch list results (table)
FETCh:WSPectrum:MODulation:ALL?
```

Mode: GSM

4.5 DISPlay Subsystem

The DISPLay subsystem controls the selection and presentation of textual and graphic information as well as of measurement data on the display.

DISPlay:FORMat.....	149
DISPlay[:WINDow<n>]:SElect.....	149
DISPlay[:WINDow<n>]:SSElect.....	150
DISPlay[:WINDow<n>]:TRACe<t>:MODE.....	150
DISPlay[:WINDow<n>]:TRACe<t>:Y[:SCALe]:RLEVel:OFFSet.....	151
DISPlay[:WINDow<n>]:TRACe<t>:Y[:SCALe]:RLEVel[:RF].....	152

DISPlay:FORMat <Format>

This command switches the measurement result display between FULL SCREEN and SPLIT SCREEN.

Parameters:

<Format> SINGle | SPLit

SPLit
Show 2 or more screens on the display

SINGle
Show only 1 screen on the display

*RST: SPL

Example: DISP:FORM SING

Mode: all

DISPlay[:WINDow<n>]:SElect

This command selects whether screen A or screen B is active.

Suffix:

<n> <1|2>
Screen number. 1 = screen A, 2 = screen B.

Example:

```
//Preset the instrument*RST
// Enter the GSM option K10
INSTrument:SElect GSM
// Switch to single sweep mode and stop sweep
INITiate:CONTinuous OFF;:ABORT
// Activate constellation measurement
CONFigure:BURSt:CONStell:IMMEDIATE
// Run a (blocking) single sweep
INITiate:IMMEDIATE;*WAI
// Switch to full screen mode (show only one
screen)
DISPlay:FORMat SINGLE
// Select screen A (I/Q constellation graph)
DISPlay:WINDow1:SElect
// Select screen B (modulation accuracy table)
DISPlay:WINDow2:SElect
// Switch to split screen mode (show all
screens)
DISPlay:FORMat SPLit
```

Usage: Setting only

Mode: GSM

DISPlay[:WINDow<n>]:SSElect

This command selects whether screen A or screen B is active. WINDow1 corresponds to SCREEN A, WINDow2 to SCREEN B.

Suffix:

<n> <1>

Example: DISP:SSEL

Usage: Setting only

Mode: GSM

DISPlay[:WINDow<n>]:TRACe<t>:MODE <Mode>

This command controls whether a trace is displayed or not, and in which mode. Each trace can only display a certain mode, or nothing at all ("Blank"). The table below indicates which measurements can display which traces and which trace modes.

Note: even if a trace is not displayed, the results can still be queried (see [TRACe\[:DATA\]](#) on page 241).

Suffix:

<n> <1|2>
Screen number. 1 = screen A, 2 = screen B.

<t> <1..4>
Trace number

Parameters for setting and query:

<Mode> AVERAge | MAXHold | MINHold | WRITe | PDFavg | BLANK |
AVERAge | MAXHold | MINHold | WRITe | BLANK

For a description of the trace modes see the "Trace Mode Overview" section in the base unit manual.

Example:

```
// Preset the instrument
*RST
// Enter the GSM option K10
INSTRument:SElect GSM
// Switch to single sweep mode and stop sweep
INITiate:CONTinuous OFF;:ABORT
// Modulation spectrum graph measurement
CONFigure:SPECTrum:MODulation:IMMediate
CONFigure:SPECTrum:SElect FREQdomain
INITiate:IMMediate
// Switch off the display of all available traces
DISPlay:WINDow1:TRACe1:MODE BLANK
DISPlay:WINDow1:TRACe4:MODE BLANK
// Switch on the display of all available traces again
DISPlay:WINDow1:TRACe1:MODE AVERAge
DISPlay:WINDow1:TRACe4:MODE WRITe
```

Mode: GSM

Table 4-1: Available traces and trace modes for the measurement types

Measurement	Trace 1	Trace 2	Trace 3	Trace 4
Power vs Time: Graph	AVERAge BLANK	MAXHold BLANK	MINHold BLANK	WRITe BLANK
EVM vs Time: Graph				
Phase Error vs Time: Graph				
Magnitude Error vs Time: Graph				
Constellation: Graph	-	-	-	WRITe BLANK
Modulation Spec- trum: Frequency Domain	AVERAge BLANK	-	-	WRITe BLANK
Transient Spec- trum: Frequency Domain	-	MAXHold BLANK	-	WRITe BLANK

DISPlay[:WINDow<n>]:TRACe<t>:Y[:SCALE]:RLEVel:OFFSet <Value>

This command specifies the external attenuation or gain applied to the RF signal. A positive value indicates attenuation, a negative value indicates gain. Displayed power level values are shifted by this value. For details refer to the "Reference Level Offset" softkey of the base unit.

This command is not available for signals from the Digital Baseband Interface (R&S FSVR-B17).

Suffix:

<n>	<1 2> irrelevant
<t>	<1..4> irrelevant

Parameters for setting and query:

<Value>	numeric value External attenuation (positive) or gain (negative). *RST: 0 dB Default unit: dB
---------	--

Example: `DISP:TRAC:Y:SCAL:RLEV:OFFS 10 DB`

Mode: GSM

DISPlay[:WINDow<n>]:TRACe<t>:Y[:SCALe]:RLEVel[:RF] <Value>

This command can be used to retrieve or set the current internal instrument reference level for RF input used when performing measurements.

Suffix:

<n>	<1 2> irrelevant
<t>	<1..4> irrelevant

Parameters for setting and query:

<Value>	numeric value Reference level of RF input. *RST: -20 dBm Default unit: dBm
---------	---

Example: `DISP:TRAC:Y:SCAL:RLEV -20 DBM`

Mode: GSM

4.6 FETCh Subsystem

The FETCh Subsystem contains commands for reading out results of complex measurement tasks.

The following subsystems are included:

4.6.1	FETCh:BURSt subsystem	153
4.6.2	FETCh:SPEctrum subsystem.....	184
4.6.3	FETCh:WSPEctrum subsystem.....	186

4.6.1 FETCh:BURSt subsystem

FETCh:BURSt[:MACCuracy]:ADRoop:AVERage.....	154
FETCh:BURSt[:MACCuracy]:ADRoop:CURRent.....	154
FETCh:BURSt[:MACCuracy]:ADRoop:MAXimum.....	155
FETCh:BURSt[:MACCuracy]:ADRoop:SDEViation.....	155
FETCh:BURSt[:MACCuracy]:ALL.....	155
FETCh:BURSt[:MACCuracy]:BPOWer:AVERage.....	156
FETCh:BURSt[:MACCuracy]:BPOWer:CURRent.....	156
FETCh:BURSt[:MACCuracy]:BPOWer:MAXimum.....	156
FETCh:BURSt[:MACCuracy]:BPOWer:SDEViation.....	157
FETCh:BURSt[:MACCuracy][:EVM]:PEAK:AVERage.....	157
FETCh:BURSt[:MACCuracy][:EVM]:PEAK:CURRent.....	158
FETCh:BURSt[:MACCuracy][:EVM]:PEAK:MAXimum.....	158
FETCh:BURSt[:MACCuracy][:EVM]:PEAK:SDEViation.....	159
FETCh:BURSt[:MACCuracy][:EVM]:RMS:AVERage.....	159
FETCh:BURSt[:MACCuracy][:EVM]:RMS:CURRent.....	160
FETCh:BURSt[:MACCuracy][:EVM]:RMS:MAXimum.....	160
FETCh:BURSt[:MACCuracy][:EVM]:RMS:SDEViation.....	161
FETCh:BURSt[:MACCuracy]:FERRor:AVERage.....	161
FETCh:BURSt[:MACCuracy]:FERRor:CURRent.....	162
FETCh:BURSt[:MACCuracy]:FERRor:MAXimum.....	162
FETCh:BURSt[:MACCuracy]:FERRor:SDEViation.....	163
FETCh:BURSt[:MACCuracy]:FREQuency:AVERage.....	163
FETCh:BURSt[:MACCuracy]:FREQuency:CURRent.....	163
FETCh:BURSt[:MACCuracy]:FREQuency:MAXimum.....	164
FETCh:BURSt[:MACCuracy]:FREQuency:SDEViation.....	164
FETCh:BURSt[:MACCuracy]:IQIMbalance:AVERage.....	164
FETCh:BURSt[:MACCuracy]:IQIMbalance:CURRent.....	164
FETCh:BURSt[:MACCuracy]:IQIMbalance:MAXimum.....	165
FETCh:BURSt[:MACCuracy]:IQIMbalance:SDEViation.....	165
FETCh:BURSt[:MACCuracy]:IQOFFset:AVERage.....	165
FETCh:BURSt[:MACCuracy]:IQOFFset:CURRent.....	166
FETCh:BURSt[:MACCuracy]:IQOFFset:MAXimum.....	166
FETCh:BURSt[:MACCuracy]:IQOFFset:SDEViation.....	166
FETCh:BURSt[:MACCuracy]:MERRor:PEAK:AVERage.....	167
FETCh:BURSt[:MACCuracy]:MERRor:PEAK:CURRent.....	167
FETCh:BURSt[:MACCuracy]:MERRor:PEAK:MAXimum.....	167
FETCh:BURSt[:MACCuracy]:MERRor:PEAK:SDEViation.....	167
FETCh:BURSt[:MACCuracy]:MERRor:RMS:AVERage.....	168
FETCh:BURSt[:MACCuracy]:MERRor:RMS:CURRent.....	168
FETCh:BURSt[:MACCuracy]:MERRor:RMS:MAXimum.....	168
FETCh:BURSt[:MACCuracy]:MERRor:RMS:SDEViation.....	169
FETCh:BURSt[:MACCuracy]:OSUPpress:AVERage.....	169

FETCh:BURSt[:MACCuracy]:OSUPpress:CURRent.....	169
FETCh:BURSt[:MACCuracy]:OSUPpress:MAXimum.....	170
FETCh:BURSt[:MACCuracy]:OSUPpress:SDEViation.....	170
FETCh:BURSt[:MACCuracy]:PERCentile:EVM.....	170
FETCh:BURSt[:MACCuracy]:PERCentile:MERRor.....	170
FETCh:BURSt[:MACCuracy]:PERCentile:PERRor.....	171
FETCh:BURSt[:MACCuracy]:PERRor:PEAK:AVERage.....	171
FETCh:BURSt[:MACCuracy]:PERRor:PEAK:CURRent.....	171
FETCh:BURSt[:MACCuracy]:PERRor:PEAK:MAXimum.....	172
FETCh:BURSt[:MACCuracy]:PERRor:PEAK:SDEViation.....	172
FETCh:BURSt[:MACCuracy]:PERRor:RMS:AVERage.....	172
FETCh:BURSt[:MACCuracy]:PERRor:RMS:CURRent.....	173
FETCh:BURSt[:MACCuracy]:PERRor:RMS:MAXimum.....	173
FETCh:BURSt[:MACCuracy]:PERRor:RMS:SDEViation.....	173
FETCh:BURSt:PTEMplate:TRGS:AVERage.....	174
FETCh:BURSt:PTEMplate:TRGS:CURRent.....	174
FETCh:BURSt:PTEMplate:TRGS:MAXimum.....	175
FETCh:BURSt:PTEMplate:TRGS:MINimum.....	176
FETCh:BURSt:PTEMplate:TRGS:SDEViation.....	176
FETCh:BURSt:SPOWer:SLOT<s>:ALL:AVERage.....	177
FETCh:BURSt:SPOWer:SLOT<s>:ALL:CRESt.....	178
FETCh:BURSt:SPOWer:SLOT<s>:ALL:MAXimum.....	179
FETCh:BURSt:SPOWer:SLOT<s>:CURRent:AVERage.....	180
FETCh:BURSt:SPOWer:SLOT<s>:CURRent:CRESt.....	181
FETCh:BURSt:SPOWer:SLOT<s>:CURRent:MAXimum.....	182
FETCh:BURSt:SPOWer:SLOT<s>:DELTatosync.....	183

FETCh:BURSt[:MACCuracy]:ADRooP:AVERage?

This command reads out the average measurement of the Amplitude Droop taken over the selected number of bursts (see "Statistic Count" on page 60).

Return values:

<Result> numeric value
 Average value
 Default unit: dB

Example: FETC: BURS: ADR: AVER?

Usage: Query only

Mode: GSM

FETCh:BURSt[:MACCuracy]:ADRooP:CURRent?

This command reads out the currently measured value of the Amplitude Droop taken over the selected number of bursts (see "Statistic Count" on page 60).

Return values:

<Result> numeric value
 Currently measured value
 Default unit: dB

Example: FETC:BURSt:ADR:CURR?

Usage: Query only

Mode: GSM

FETCh:BURSt[:MACCuracy]:ADRoop:MAXimum?

This command reads out the maximum measurement of the Amplitude Droop taken over the selected number of bursts (see "Statistic Count" on page 60).

Return values:

<Result> numeric value
 Maximum
 Default unit: dB

Example: FETC:BURSt:ADR:MAX?

Usage: Query only

Mode: GSM

FETCh:BURSt[:MACCuracy]:ADRoop:SDEviation?

This command reads out the standard deviation measurement of the Amplitude Droop taken over the selected number of bursts (see "Statistic Count" on page 60).

Return values:

<Result> numeric value
 Standard deviation
 Default unit: dB

Example: FETC:BURSt:ADR:SDEV?

Usage: Query only

Mode: GSM

FETCh:BURSt[:MACCuracy]:ALL?

This command returns all the results of the Modulation Accuracy table. The results are output as a list of comma separated strings.

When the measurement is started, the analyzer is automatically set to single sweep.

Further results of the measurement can be queried without restart of the measurement via the FETCh:BURSt subsystem.

Return values:

<Result> <Error Vector Magnitude RMS>, <Error Vector Magnitude Peak>, <Magnitude Error RMS>, <Magnitude Error Peak>, <Phase Error RMS>, <Phase Error Peak>, <Burst Power>, <Frequency Error>, <IQ Offset>, <IB Imbalance>

Each item consists of an Average, Current, Maximum and Standard Deviation value

Example: FETC:BURSt:ALL?

Usage: Query only

Mode: GSM

FETCh:BURSt[:MACCuracy]:BPOWer:AVERage?

This command reads out the average measurement of the Burst Power taken over the selected number of bursts (see "[Statistic Count](#)" on page 60).

Return values:

<Result> numeric value
Average value
Default unit: dB

Example: FETC:BURSt:BPOW:AVER?

Usage: Query only

Mode: GSM

FETCh:BURSt[:MACCuracy]:BPOWer:CURRent?

This command reads out the currently measured value of the Burst Power taken over the selected number of bursts (see "[Statistic Count](#)" on page 60).

Return values:

<Result> numeric value
Currently measured value
Default unit: dB

Example: FETC:BURSt:BPOW:CURR?

Usage: Query only

Mode: GSM

FETCh:BURSt[:MACCuracy]:BPOWer:MAXimum?

This command reads out the maximum measurement of the Burst Power taken over the selected number of bursts (see "[Statistic Count](#)" on page 60).

Return values:

<Result> numeric value
 Maximum
 Default unit: dB

Example: FETC: BURS: BPOW: MAX?

Usage: Query only

Mode: GSM

FETCh: BURSt[:MACCuracy]: BPOWer: SDEVIation?

This command reads out the standard deviation measurement of the Burst Power taken over the selected number of bursts (see ["Statistic Count"](#) on page 60).

Return values:

<Result> numeric value
 Standard deviation
 Default unit: dB

Example: FETC: BURS: BPOW: SDEV?

Usage: Query only

Mode: GSM

FETCh: BURSt[:MACCuracy][:EVM]: PEAK: AVERAge?

This command reads out the average of the peak measurement of the Error Vector Magnitude taken over the selected number of bursts.

Return values:

<Result> numeric value
 Average value
 Default unit: NONE

Example: \\ Preset the instrument
 *RST
 \\ Enter the GSM option K10
 INSTRument: SElect GSM
 \\ Switch to single sweep mode and stop sweep
 INITiate: CONTInuous OFF; :ABORt
 \\ Activate modulation accuracy measurement
 CONFigure: BURSt: MACCuracy: IMMEDIATE
 \\ Run a (blocking) single sweep
 INITiate: IMMEDIATE; *WAI
 \\ Query the measurement result
 FETC: BURS: PEAK: AVER?

Usage: Query only

Mode: GSM

FETCh:BURSt[:MACCuracy][:EVM]:PEAK:CURRent?

This command reads out the current peak value of the Error Vector Magnitude taken over the selected number of bursts.

Return values:

<Result> numeric value
 Currently measured peak
 Default unit: NONE

Example:

```
\\ Preset the instrument
*RST
\\ Enter the GSM option K10
INSTRUMENT:SELEct GSM
\\ Switch to single sweep mode and stop sweep
INITiate:CONTinuous OFF;:ABORt
\\ Activate modulation accuracy measurement
CONFigure:BURSt:MACCuracy:IMMediate
\\ Run a (blocking) single sweep
INITiate:IMMediate;*WAI
\\ Query the measurement result
FETC:BURS:PEAK:CURR?
```

Usage: Query only

Mode: GSM

FETCh:BURSt[:MACCuracy][:EVM]:PEAK:MAXimum?

This command reads out the maximum of the peak measurement of the Error Vector Magnitude taken over the selected number of bursts.

Return values:

<Result> numeric value
 Maximum
 Default unit: NONE

Example:

```
\\ Preset the instrument
*RST
\\ Enter the GSM option K10
INSTRUMENT:SELEct GSM
\\ Switch to single sweep mode and stop sweep
INITiate:CONTinuous OFF;:ABORt
\\ Activate modulation accuracy measurement
CONFigure:BURSt:MACCuracy:IMMediate
\\ Run a (blocking) single sweep
INITiate:IMMediate;*WAI
\\ Query the measurement result
FETC:BURS:PEAK:MAX?
```

Usage: Query only

Mode: GSM

FETCh:BURSt[:MACCuracy][:EVM]:PEAK:SDEVIation?

This command reads out the standard deviation of the peak measurement of the Error Vector Magnitude taken over the selected number of bursts.

Return values:

<Result> numeric value
 Standard deviation
 Default unit: NONE

Example: \\ Preset the instrument
 *RST
 \\ Enter the GSM option K10
 INSTRument:SElect GSM
 \\ Switch to single sweep mode and stop sweep
 INITiate:CONTinuous OFF;:ABOrt
 \\ Activate modulation accuracy measurement
 CONFigure:BURSt:MACCuracy:IMMediate
 \\ Run a (blocking) single sweep
 INITiate:IMMediate;*WAI
 \\ Query the measurement result
 FETC:BURS:PEAK:SDEV?

Usage: Query only

Mode: GSM

FETCh:BURSt[:MACCuracy][:EVM]:RMS:AVERage?

This command reads out the average of the RMS measurement of the Error Vector Magnitude taken over the selected number of bursts.

Return values:

<Result> numeric value
 Average value
 Default unit: NONE

Example: \\ Preset the instrument
 *RST
 \\ Enter the GSM option K10
 INSTRument:SElect GSM
 \\ Switch to single sweep mode and stop sweep
 INITiate:CONTinuous OFF;:ABOrt
 \\ Activate modulation accuracy measurement
 CONFigure:BURSt:MACCuracy:IMMediate
 \\ Run a (blocking) single sweep
 INITiate:IMMediate;*WAI
 \\ Query the measurement result
 FETC:BURS:RMS:AVER?

Usage: Query only

Mode: GSM

FETCh:BURSt[:MACCuracy][:EVM]:RMS:CURRent?

This command reads out the current RMS value of the Error Vector Magnitude taken over the selected number of bursts.

Return values:

<Result> numeric value
 Currently measured value
 Default unit: NONE

Example: \\ Preset the instrument
 *RST
 \\ Enter the GSM option K10
 INSTRument:SElect GSM
 \\ Switch to single sweep mode and stop sweep
 INITiate:CONTinuous OFF;:ABORt
 \\ Activate modulation accuracy measurement
 CONFigure:BURSt:MACCuracy:IMMediate
 \\ Run a (blocking) single sweep
 INITiate:IMMediate;*WAI
 \\ Query the measurement result
 FETC:BURS:RMS:CURR?

Usage: Query only

Mode: GSM

FETCh:BURSt[:MACCuracy][:EVM]:RMS:MAXimum?

This command reads out the maximum of the RMS measurement of the Error Vector Magnitude taken over the selected number of bursts.

Return values:

<Result> numeric value
 Maximum
 Default unit: NONE

Example:

```

\\ Preset the instrument
*RST
\\ Enter the GSM option K10
INSTRument:SElect GSM
\\ Switch to single sweep mode and stop sweep
INITiate:CONTinuous OFF;:ABORT
\\ Activate modulation accuracy measurement
CONFigure:BURSt:MACCuracy:IMMediate
\\ Run a (blocking) single sweep
INITiate:IMMediate;*WAI
\\ Query the measurement result
FETC:BURS:RMS:MAX?

```

Usage: Query only

Mode: GSM

FETCh:BURSt[:MACCuracy][:EVM]:RMS:SDEVIation?

This command reads out the standard deviation of the RMS measurement of the Error Vector Magnitude taken over the selected number of bursts.

Return values:

<Result> numeric value
Standard deviation
Default unit: NONE

Example:

```

\\ Preset the instrument
*RST
\\ Enter the GSM option K10
INSTRument:SElect GSM
\\ Switch to single sweep mode and stop sweep
INITiate:CONTinuous OFF;:ABORT
\\ Activate modulation accuracy measurement
CONFigure:BURSt:MACCuracy:IMMediate
\\ Run a (blocking) single sweep
INITiate:IMMediate;*WAI
\\ Query the measurement result
FETC:BURS:RMS:SDEV?

```

Usage: Query only

Mode: GSM

FETCh:BURSt[:MACCuracy]:FERRor:AVERage?

This command reads out the average measurement of the Frequency Error taken over the selected number of bursts.

This command is retained for compatibility with R&S FS-K5 only. Use the [FETCh: BURSt\[:MACCuracy\]:FREQuency:AVERage](#) command which behaves the same way.

Return values:

<Result> numeric value
 Average value
 Default unit: Hz

Example: FETC: BURS: FERR: AVER?

Usage: Query only

Mode: GSM

FETCh: BURSt[:MACCuracy]: FERRor: CURRent?

This command reads out the currently measured value of the Frequency Error taken over the selected number of bursts.

This command is retained for compatibility with R&S FS-K5 only. Use the [FETCh: BURSt\[:MACCuracy\]: FREQuency: CURRent](#) command which behaves the same way.

Return values:

<Result> numeric value
 Currently measured value
 Default unit: Hz

Example: FETC: BURS: FERR: CURR?

Usage: Query only

Mode: GSM

FETCh: BURSt[:MACCuracy]: FERRor: MAXimum?

This command reads out the maximum measurement of the Frequency Error taken over the selected number of bursts.

This command is retained for compatibility with R&S FS-K5 only. Use the [FETCh: BURSt\[:MACCuracy\]: FREQuency: MAXimum](#) command which behaves the same way.

Return values:

<Result> numeric value
 Maximum
 Default unit: Hz

Example: FETC: BURS: FERR: MAX?

Usage: Query only

Mode: GSM

FETCh:BURSt[:MACCuracy]:FERRor:SDEViation?

This command reads out the standard deviation measurement of the Frequency Error taken over the selected number of bursts.

This command is retained for compatibility with R&S FS-K5 only. Use the [FETCh: BURSt\[:MACCuracy\]:FREQuency:SDEViation](#) command which behaves the same way.

Return values:

<Result> numeric value
 Standard deviation
 Default unit: Hz

Example: FETC: BURS: FERR: SDEV?

Usage: Query only

Mode: GSM

FETCh:BURSt[:MACCuracy]:FREQuency:AVERage?

This command reads out the average measurement of the Frequency Error taken over the selected number of bursts (see "[Statistic Count](#)" on page 60).

Return values:

<Result> numeric value
 Average value
 Default unit: Hz

Example: FETC: BURS: FREQ: AVER?

Usage: Query only

Mode: GSM

FETCh:BURSt[:MACCuracy]:FREQuency:CURREnt?

This command reads out the currently measured value of the Frequency Error taken over the selected number of bursts (see "[Statistic Count](#)" on page 60).

Return values:

<Result> numeric value
 Currently measured value
 Default unit: Hz

Example: FETC: BURS: FREQ: CURR?

Usage: Query only

Mode: GSM

FETCh:BURSt[:MACCuracy]:FREQuency:MAXimum?

This command reads out the maximum measurement of the Frequency Error taken over the selected number of bursts (see "Statistic Count" on page 60).

Return values:

<Result> numeric value
 Maximum
 Default unit: Hz

Example: FETC : BURS : FREQ : MAX ?

Usage: Query only

Mode: GSM

FETCh:BURSt[:MACCuracy]:FREQuency:SDEViation?

This command reads out the standard deviation measurement of the Frequency Error taken over the selected number of bursts (see "Statistic Count" on page 60).

Return values:

<Result> numeric value
 Standard deviation
 Default unit: Hz

Example: FETC : BURS : FREQ : SDEV ?

Usage: Query only

Mode: GSM

FETCh:BURSt[:MACCuracy]:IQIMbalance:AVERage?

This command reads out the average measurement of the IQ Imbalance taken over the selected number of bursts (see "Statistic Count" on page 60).

Return values:

<Result> numeric value
 Average value
 Default unit: NONE

Example: FETC : BURS : IQIM : AVER ?

Usage: Query only

Mode: GSM

FETCh:BURSt[:MACCuracy]:IQIMbalance:CURRent?

This command reads out the currently measured value of the IQ Imbalance taken over the selected number of bursts (see "Statistic Count" on page 60).

Return values:

<Result> numeric value
 Currently measured value
 Default unit: NONE

Example: FETC: BURS: IQIM: CURR?

Usage: Query only

Mode: GSM

FETCh: BURSt[:MACCuracy]: IQIMbalance: MAXimum?

This command reads out the maximum measurement of the IQ Imbalance taken over the selected number of bursts (see "[Statistic Count](#)" on page 60).

Return values:

<Result> numeric value
 Maximum
 Default unit: NONE

Example: FETC: BURS: IQIM: MAX?

Usage: Query only

Mode: GSM

FETCh: BURSt[:MACCuracy]: IQIMbalance: SDEVIation?

This command reads out the standard deviation measurement of the IQ Imbalance taken over the selected number of bursts (see "[Statistic Count](#)" on page 60).

Return values:

<Result> numeric value
 Standard deviation
 Default unit: NONE

Example: FETC: BURS: IQIM: SDEV?

Usage: Query only

Mode: GSM

FETCh: BURSt[:MACCuracy]: IQOffset: AVERAge?

This command reads out the average measurement of the IQ Offset taken over the selected number of bursts (see "[Statistic Count](#)" on page 60).

Return values:

<Result> numeric value
 Average value
 Default unit: NONE

Example: FETC:BURS:IQOF:AVER?
Usage: Query only
Mode: GSM

FETCh:BURSt[:MACCuracy]:IQOffset:CURRent?

This command reads out the currently measured value of the IQ Offset taken over the selected number of bursts (see "Statistic Count" on page 60).

Return values:

<Result> numeric value
 Currently measured value
 Default unit: NONE

Example: FETC:BURS:IQOF:CURR?
Usage: Query only
Mode: GSM

FETCh:BURSt[:MACCuracy]:IQOffset:MAXimum?

This command reads out the maximum measurement of the IQ Offset taken over the selected number of bursts (see "Statistic Count" on page 60).

Return values:

<Result> numeric value
 Maximum
 Default unit: NONE

Example: FETC:BURS:IQOF:MAX?
Usage: Query only
Mode: GSM

FETCh:BURSt[:MACCuracy]:IQOffset:SDEVIation?

This command reads out the standard deviation measurement of the IQ Offset taken over the selected number of bursts (see "Statistic Count" on page 60).

Return values:

<Result> numeric value
 Standard deviation
 Default unit: NONE

Example: FETC:BURS:IQOF:SDEV?
Usage: Query only
Mode: GSM

FETCh:BURSt[:MACCuracy]:MERRor:PEAK:AVERage?

This command reads out the average of the peak measurement of the Magnitude Error taken over the selected number of bursts.

Return values:

<Result> numeric value
 Average value
 Default unit: NONE

Example: FETC : BURS : MERR : PEAK : AVER ?

Usage: Query only

Mode: GSM

FETCh:BURSt[:MACCuracy]:MERRor:PEAK:CURRent?

This command reads out the currently measured peak value of the Magnitude Error taken over the selected number of bursts.

Return values:

<Result> numeric value
 Currently measured peak value
 Default unit: NONE

Example: FETC : BURS : MERR : PEAK : CURR ?

Usage: Query only

Mode: GSM

FETCh:BURSt[:MACCuracy]:MERRor:PEAK:MAXimum?

This command reads out the maximum of the peak measurement of the Magnitude Error taken over the selected number of bursts.

Return values:

<Result> numeric value
 Maximum
 Default unit: NONE

Example: FETC : BURS : MERR : PEAK : MAX ?

Usage: Query only

Mode: GSM

FETCh:BURSt[:MACCuracy]:MERRor:PEAK:SDEViation?

This command reads out the standard deviation of the peak measurement of the Magnitude Error taken over the selected number of bursts.

Return values:

<Result> numeric value
 Standard deviation
 Default unit: NONE

Example: FETC : BURS : MERR : PEAK : SDEV ?

Usage: Query only

Mode: GSM

FETCh:BURSt[:MACCuracy]:MERRor:RMS:AVERAge?

This command reads out the average of the RMS measurement of the Magnitude Error taken over the selected number of bursts.

Return values:

<Result> numeric value
 Average value
 Default unit: NONE

Example: FETC : BURS : MERR : RMS : AVER ?

Usage: Query only

Mode: GSM

FETCh:BURSt[:MACCuracy]:MERRor:RMS:CURRent?

This command reads out the currently measured RMS value of the Magnitude Error taken over the selected number of bursts.

Return values:

<Result> numeric value
 Currently measured value
 Default unit: NONE

Example: FETC : BURS : MERR : RMS : CURR ?

Usage: Query only

Mode: GSM

FETCh:BURSt[:MACCuracy]:MERRor:RMS:MAXimum?

This command reads out the maximum of the RMS measurement of the Magnitude Error taken over the selected number of bursts.

Return values:

<Result> numeric value
 Maximum
 Default unit: NONE

Example: FETC : BURS : MERR : RMS : MAX ?
Usage: Query only
Mode: GSM

FETCh:BURSt[:MACCuracy]:MERRor:RMS:SDEVIation?

This command reads out the standard deviation of the RMS measurement of the Magnitude Error taken over the selected number of bursts.

Return values:
 <Result> numeric value
 Standard deviation
 Default unit: NONE

Example: FETC : BURS : MERR : RMS : SDEV ?
Usage: Query only
Mode: GSM

FETCh:BURSt[:MACCuracy]:OSUPpress:AVERage?

This command reads out the average measurement of the IQ Offset Suppression taken over the selected number of bursts (see "[Statistic Count](#)" on page 60).

Return values:
 <Result> numeric value
 Average value
 Default unit: dB

Example: FETC : BURS : OSUP : AVER ?
Usage: Query only
Mode: GSM

FETCh:BURSt[:MACCuracy]:OSUPpress:CURREnt?

This command reads out the currently measured value of the IQ Offset Suppression taken over the selected number of bursts (see "[Statistic Count](#)" on page 60).

Return values:
 <Result> numeric value
 Currently measured value
 Default unit: dB

Example: FETC : BURS : OSUP : CURR ?
Usage: Query only
Mode: GSM

FETCh:BURSt[:MACCuracy]:OSUPpress:MAXimum?

This command reads out the maximum measurement of the IQ Offset Suppression taken over the selected number of bursts (see "[Statistic Count](#)" on page 60).

Return values:

<Result> numeric value
 Maximum
 Default unit: dB

Example: FETC : BURS : OSUP : MAX ?

Usage: Query only

Mode: GSM

FETCh:BURSt[:MACCuracy]:OSUPpress:SDEVIation?

This command reads out the standard deviation measurement of the IQ Offset Suppression taken over the selected number of bursts (see "[Statistic Count](#)" on page 60).

Return values:

<Result> numeric value
 Standard deviation
 Default unit: dB

Example: FETC : BURS : OSUP : SDEV ?

Usage: Query only

Mode: GSM

FETCh:BURSt[:MACCuracy]:PERCentile:EVM?

This command reads out the 95 % percentile of the Error Vector Magnitude measurement taken over the selected number of bursts.

Return values:

<Result> numeric value
 Default unit: NONE

Example: FETC : BURS : PERC : EVM ?

Usage: Query only

Mode: GSM

FETCh:BURSt[:MACCuracy]:PERCentile:MERRor?

This command reads out the 95 % percentile of the Magnitude Error measurement taken over the selected number of bursts.

Return values:

<Result> numeric value
 Default unit: NONE

Example: FETC : BURS : PERC : MERR ?

Usage: Query only

Mode: GSM

FETCh:BURSt[:MACCuracy]:PERCentile:PERRor?

This command reads out the 95 % percentile of the Phase Error measurement taken over the selected number of bursts.

Return values:

<Result> numeric value
 Default unit: NONE

Example: FETC : BURS : PERC : PERR ?

Usage: Query only

Mode: GSM

FETCh:BURSt[:MACCuracy]:PERRor:PEAK:AVERage?

This command reads out the average of the peak measurement of the Phase Error taken over the selected number of bursts.

Return values:

<Result> numeric value
 Average value
 Default unit: NONE

Example: FETC : BURS : PERR : PEAK : AVER ?

Usage: Query only

Mode: GSM

FETCh:BURSt[:MACCuracy]:PERRor:PEAK:CURRent?

This command reads out the current peak value of the Phase Error taken over the selected number of bursts.

Return values:

<Result> numeric value
 Currently measured peak
 Default unit: NONE

Example: FETC : BURS : PERR : PEAK : CURR ?

Usage: Query only

Mode: GSM

FETCh:BURSt[:MACCuracy]:PERRor:PEAK:MAXimum?

This command reads out the maximum of the peak measurement of the Phase Error taken over the selected number of bursts.

Return values:

<Result> numeric value
 Maximum
 Default unit: NONE

Example: FETC:BURS:PERR:PEAK:MAX?

Usage: Query only

Mode: GSM

FETCh:BURSt[:MACCuracy]:PERRor:PEAK:SDEVIation?

This command reads out the standard deviation of the peak measurement of the Phase Error taken over the selected number of bursts.

Return values:

<Result> numeric value
 Standard deviation
 Default unit: NONE

Example: FETC:BURS:PERR:PEAK:SDEV?

Usage: Query only

Mode: GSM

FETCh:BURSt[:MACCuracy]:PERRor:RMS:AVERAge?

This command reads out the average of the RMS measurement of the Phase Error taken over the selected number of bursts.

Return values:

<Result> numeric value
 Average value
 Default unit: NONE

Example: FETC:BURS:PERR:RMS:AVER?

Usage: Query only

Mode: GSM

FETCh:BURSt[:MACCuracy]:PERRor:RMS:CURRent?

This command reads out the currently measured RMS value of the Phase Error taken over the selected number of bursts.

Return values:

<Result> numeric value
 Currently measured value
 Default unit: NONE

Example: FETC : BURS : PERR : RMS : CURR ?

Usage: Query only

Mode: GSM

FETCh:BURSt[:MACCuracy]:PERRor:RMS:MAXimum?

This command reads out the maximum of the RMS measurement of the Phase Error taken over the selected number of bursts.

Return values:

<Result> numeric value
 Maximum
 Default unit: NONE

Example: FETC : BURS : PERR : RMS : MAX ?

Usage: Query only

Mode: GSM

FETCh:BURSt[:MACCuracy]:PERRor:RMS:SDEViation?

This command reads out the standard deviation of the RMS measurement of the Phase Error taken over the selected number of bursts.

Return values:

<Result> numeric value
 Standard deviation
 Default unit: NONE

Example: FETC : BURS : PERR : RMS : SDEV ?

Usage: Query only

Mode: GSM

FETCh:BURSt:PTEMplate:TRGS:AVERage?

This command reads out the average of the time between the external trigger event and the start of the first symbol of the training sequence (midamble) in seconds over the selected number of I/Q captures (see "Statistic Count" on page 60). This command is only available if an external trigger is selected and the "Trigger to Sync" measurement is active (see [CONFigure:TRGS\[:IMMEDIATE\]](#) on page 146).

Return values:

<Result> numeric value
Average value
Default unit: S

Example:

```
// Preset the instrument
*RST
// Enter the GSM option K10
INSTrument:SElect GSM
// Switch to single sweep mode and stop sweep
INITiate:CONTinuous OFF;:ABORt
// Set external trigger more
TRIGger1:SEquence:SOURce EXTernal
// Activate Trigger to Sync measurement
CONFigure:TRGS:IMMEDIATE
// Set minimum capture time to speed up measurement
SENSE1:SWEEp:TIME MINimum
// Auto set trigger offset
// Note: Correct frame / slot configuration assumed!
CONFigure:MS:AUTO:TRIGger ONCE
// Run a (blocking) single sweep
INITiate:IMMEDIATE;*WAI
// Query the measurement result
FETC:BURS:PTEM:TRGS:AVER?
```

Usage: Query only

Mode: GSM

FETCh:BURSt:PTEMplate:TRGS:CURRent?

This command reads out the most recently measured time between the external trigger event and the start of the first symbol of the training sequence (midamble) in seconds over the selected number of I/Q captures (see "Statistic Count" on page 60). This command is only available if an external trigger is selected and the "Trigger to Sync" measurement is active (see [CONFigure:TRGS\[:IMMEDIATE\]](#) on page 146).

Return values:

<Result> numeric value
Currently measured value
Default unit: S

```

Example:          // Preset the instrument
                    *RST
                    // Enter the GSM option K10
                    INSTRument:SElect GSM
                    // Switch to single sweep mode and stop sweep
                    INITiate:CONTinuous OFF;:ABORT
                    // Set external trigger more
                    TRIGger1:SEquence:SOURce EXTernal
                    // Activate Trigger to Sync measurement
                    CONFigure:TRGS:IMMediate
                    // Set minimum capture time to speed up measurement
                    SENSE1:SWEep:TIME MINimum
                    // Run a (blocking) single sweep
                    INITiate:IMMediate;*WAI
                    // Query the measurement result
                    FETC:BURSt:PTEM:TRGS:CURR?

```

Usage: Query only

Mode: GSM

FETCh:BURSt:PTEMplate:TRGS:MAXimum?

This command queries the maximum of the time between the external trigger event and the start of the first symbol of the training sequence (midamble) in seconds over the selected number of I/Q captures (see ["Statistic Count"](#) on page 60). This command is only available if an external trigger is selected and the "Trigger to Sync" measurement is active (see [CONFigure:TRGS\[:IMMediate\]](#) on page 146).

Return values:

<Result> numeric value
 Maximum
 Default unit: S

Example:

```
// Preset the instrument
*RST
// Enter the GSM option K10
INSTRument:SElect GSM
// Switch to single sweep mode and stop sweep
INITiate:CONTinuous OFF;;ABORT
// Set external trigger more
TRIGger1:SEquence:SOURce EXTernal
// Activate Trigger to Sync measurement
CONFigure:TRGS:IMMediate
// Set minimum capture time to speed up measurement
SENSE1:SWEep:TIME MINimum
// Auto set trigger offset
// Note: Correct frame / slot configuration assumed!
CONFigure:MS:AUTO:TRIGger ONCE
// Run a (blocking) single sweep
INITiate:IMMediate;*WAI
// Query the measurement result
FETC:BURSt:PTEMplate:TRGS:MAX?
```

Usage: Query only

Mode: GSM

FETCh:BURSt:PTEMplate:TRGS:MINimum?

This command queries the minimum of the time between the external trigger event and the start of the first symbol of the training sequence (midamble) in seconds over the selected number of I/Q captures (see "Statistic Count" on page 60). This command is only available if an external trigger is selected and the "Trigger to Sync" measurement is active (see [CONFigure:TRGS\[:IMMediate\]](#) on page 146).

Return values:

<Result> numeric value
 Minimum time
 Default unit: S

Usage: Query only

Mode: GSM

FETCh:BURSt:PTEMplate:TRGS:SDEVIation?

This command queries the standard deviation of the time between the external trigger event and the start of the first symbol of the training sequence (midamble) in seconds over the selected number of I/Q captures (see "Statistic Count" on page 60). This command is only available if an external trigger is selected and the "Trigger to Sync" measurement is active (see [CONFigure:TRGS\[:IMMediate\]](#) on page 146).

Return values:

<Result> numeric value
 Standard deviation
 Default unit: S

Example:

```
// Preset the instrument
*RST
// Enter the GSM option K10
INSTRument:SElect GSM
// Switch to single sweep mode and stop sweep
INITiate:CONTinuous OFF;;ABORT
// Set external trigger more
TRIGger1:SEquence:SOURce EXTernal
// Activate Trigger to Sync measurement
CONFigure:TRGS:IMMediate
// Set minimum capture time to speed up measurement
SENSe1:SWEep:TIME MINimum
// Auto set trigger offset
// Note: Correct frame / slot configuration assumed!
CONFigure:MS:AUTO:TRIGger ONCE
// Run a (blocking) single sweep
INITiate:IMMediate;*WAI
// Query the measurement result
FETC:BURS:PTEM:TRGS:SDEV?
```

Usage: Query only

Mode: GSM

FETCh:BURSt:SPOWer:SLOT<s>:ALL:AVERAge?

This command reads out the average power for the selected slot for all measured bursts.

This command is only available if "Power vs Time" measurement is selected (see [CONFigure:BURSt:PTEMplate\[:IMMediate\]](#) on page 137).

Suffix:

<s> <0..7>
 Slot number to measure power on. The selected slot s must be within the slot scope, i.e. (First slot to measure) <= s <= (First slot to measure + Number of Slots to measure - 1).

Return values:

<Result> numeric value
 Average value
 Default unit: dBm

Example:

```

\\ Preset the instrument
*RST
\\ Enter the GSM option K10
INSTrument:SElect GSM
\\ Switch to single sweep mode and stop sweep
INITiate:CONTinuous OFF;:ABORT
\\ Set the slot scope: Use all 8 slots for the PvT measurement.
\\ Number of slots to measure = 8
CONFigure:MS:CHANnel:MSLots:NOFSlots 8
\\ First Slot to measure = 0
CONFigure:MS:CHANnel:MSLots:OFFSet 0
\\ Activate PvT (Power vs Time) measurement
CONFigure:BURSt:PTEMplate:IMMediate
\\ Run a single sweep
\\ Note: 'FETCh' only reads the results without starting a new single sweep!
\\ Run a (blocking) single sweep
INITiate:IMMediate;*WAI
FETCh:BURSt:SPOWer:SLOT0:ALL:AVERAge?

```

Usage: Query only

Mode: GSM

FETCh:BURSt:SPOWer:SLOT<s>:ALL:CRESt?

This command reads out the crest factor for the selected slot for all measured bursts.

This command is only available if "Power vs Time" measurement is selected (see [CONFigure:BURSt:PTEMplate\[:IMMediate\]](#) on page 137).

Suffix:

<s> <0..7>
Slot number to measure power on. The selected slot s must be within the slot scope, i.e. (First slot to measure) <= s <= (First slot to measure + Number of Slots to measure - 1).

Return values:

<Result> numeric value
Crest factor
Default unit: dB

Example:

```

\\ Preset the instrument
*RST
\\ Enter the GSM option K10
INSTRument:SElect GSM
\\ Switch to single sweep mode and stop sweep
INITiate:CONTinuous OFF;:ABORT
\\ Set the slot scope: Use all 8 slots for the PvT measurement.
\\ Number of slots to measure = 8
CONFigure:MS:CHANnel:MSLots:NOFSlots 8
\\ First Slot to measure = 0
CONFigure:MS:CHANnel:MSLots:OFFSet 0
\\ Activate PvT (Power vs Time) measurement
CONFigure:BURSt:PTEMplate:IMMediate
\\ Run a single sweep
\\ Note: 'FETCh' only reads the results without starting a new single sweep!
\\ Run a (blocking) single sweep
INITiate:IMMediate;*WAI
FETCh:BURSt:SPOWer:SLOT0:ALL:CRESt?

```

Usage: Query only

Mode: GSM

FETCh:BURSt:SPOWer:SLOT<s>:ALL:MAXimum?

This command reads out the maximum power for the selected slot for all measured bursts.

This command is only available if "Power vs Time" measurement is selected (see [CONFigure:BURSt:PTEMplate\[:IMMediate\]](#) on page 137).

Suffix:

<s> <0..7>
Slot number to measure power on. The selected slot s must be within the slot scope, i.e. (First slot to measure) <= s <= (First slot to measure + Number of Slots to measure - 1).

Return values:

<Result> numeric value
Maximum
Default unit: dBm

Example:

```

\\ Preset the instrument
*RST
\\ Enter the GSM option K10
INSTrument:SElect GSM
\\ Switch to single sweep mode and stop sweep
INITiate:CONTinuous OFF;:ABORT
\\ Set the slot scope: Use all 8 slots for the PvT measurement.
\\ Number of slots to measure = 8
CONFigure:MS:CHANnel:MSLots:NOFSlots 8
\\ First Slot to measure = 0
CONFigure:MS:CHANnel:MSLots:OFFSet 0
\\ Activate PvT (Power vs Time) measurement
CONFigure:BURSt:PTEMplate:IMMediate
\\ Run a single sweep
\\ Note: 'FETCh' only reads the results without starting a new single sweep!
\\ Run a (blocking) single sweep
INITiate:IMMediate;*WAI
FETCh:BURSt:SPOWer:SLOT0:ALL:MAXimum?

```

Usage: Query only

Mode: GSM

FETCh:BURSt:SPOWer:SLOT<s>:CURRrent:AVERAge?

This command reads out the average power for the selected slot for the current burst.

This command is only available if "Power vs Time" measurement is selected (see [CONFigure:BURSt:PTEMplate\[:IMMediate\]](#) on page 137).

Suffix:

<s> <0..7>
Slot number to measure power on. The selected slot s must be within the slot scope, i.e. (First slot to measure) ≤ s ≤ (First slot to measure + Number of Slots to measure - 1).

Return values:

<Result> numeric value
Average power
Default unit: dBm

Example:

```

\\ Preset the instrument
*RST
\\ Enter the GSM option K10
INSTrument:SElect GSM
\\ Switch to single sweep mode and stop sweep
INITiate:CONTinuous OFF;:ABORt
\\ Set the slot scope: Use all 8 slots for the PvT measurement.
\\ Number of slots to measure = 8
CONFigure:MS:CHANnel:MSLots:NOFSlots 8
\\ First Slot to measure = 0
CONFigure:MS:CHANnel:MSLots:OFFSet 0
\\ Activate PvT (Power vs Time) measurement
CONFigure:BURSt:PTEMplate:IMMediate
\\ Run a single sweep
\\ Note: 'FETCh' only reads the results without starting a new single sweep!
\\ Run a (blocking) single sweep
INITiate:IMMediate;*WAI
FETCh:BURSt:SPOWer:SLOT0:CURRent:AVERAge?

```

Usage: Query only

Mode: GSM

FETCh:BURSt:SPOWer:SLOT<s>:CURRent:CRESt?

This command reads out the crest factor for the selected slot for the current burst.

This command is only available if "Power vs Time" measurement is selected (see [CONFigure:BURSt:PTEMplate\[:IMMediate\]](#) on page 137).

Suffix:

<s> <0..7>
Slot number to measure power on. The selected slot s must be within the slot scope, i.e. (First slot to measure) <= s <= (First slot to measure + Number of Slots to measure - 1).

Return values:

<Result> numeric value
Crest factor
Default unit: dB

Example:

```

\\ Preset the instrument
*RST
\\ Enter the GSM option K10
INSTrument:SElect GSM
\\ Switch to single sweep mode and stop sweep
INITiate:CONTinuous OFF;:ABORT
\\ Set the slot scope: Use all 8 slots for the PvT measurement.
\\ Number of slots to measure = 8
CONFigure:MS:CHANnel:MSLots:NOFSlots 8
\\ First Slot to measure = 0
CONFigure:MS:CHANnel:MSLots:OFFSet 0
\\ Activate PvT (Power vs Time) measurement
CONFigure:BURSt:PTEmplate:IMMediate
\\ Run a single sweep
\\ Note: 'FETCh' only reads the results without starting a new single sweep!
\\ Run a (blocking) single sweep
INITiate:IMMediate;*WAI
FETCh:BURSt:SPOWer:SLOT0:CURRent:CRESt?

```

Usage: Query only

Mode: GSM

FETCh:BURSt:SPOWer:SLOT<s>:CURRent:MAXimum?

This command reads out the maximum power for the selected slot for the current burst.

This command is only available if "Power vs Time" measurement is selected and if the slot is part of the selected slot scope (see [chapter 3.2.8, "Defining the Scope of the Measurement"](#), on page 43).

Suffix:

<s> <0..7>
Slot number to measure power on. The selected slot s must be within the slot scope, i.e. (First slot to measure) \leq s \leq (First slot to measure + Number of Slots to measure - 1).

Return values:

<Result> numeric value
Maximum
Default unit: dBm

Example:

```

\\ Preset the instrument
*RST
\\ Enter the GSM option K10
INSTrument:SElect GSM
\\ Switch to single sweep mode and stop sweep
INITiate:CONTinuous OFF;:ABORt
\\ Set the slot scope: Use all 8 slots for the PvT measurement.
\\ Number of slots to measure = 8
CONFigure:MS:CHANnel:MSLots:NOFSlots 8
\\ First Slot to measure = 0
CONFigure:MS:CHANnel:MSLots:OFFSet 0
\\ Activate PvT (Power vs Time) measurement
CONFigure:BURSt:PTEMplate:IMMediate
\\ Run a single sweep
\\ Note: 'FETCh' only reads the results without starting a new single sweep!
\\ Run a (blocking) single sweep
INITiate:IMMediate;*WAI
FETCh:BURSt:SPOWer:SLOT0:CURRent:MAXimum?

```

Usage: Query only

Mode: GSM

FETCh:BURSt:SPOWer:SLOT<s>:DELtatosync?

This command reads out the "Delta to Sync" value for the selected slot (see [chapter 3.1.8, "Power vs Time"](#), on page 20). This command is only available when the "Power vs Time" measurement is selected (see [CONFigure:BURSt:PTEMplate\[:IMMediate\]](#) on page 137).

Suffix:

<s> <0..7>
Slot number to measure power on. The selected slot must be within the slot scope, i.e.
 $(\text{First slot to measure}) \leq \text{<slot>} \leq (\text{First slot to measure} + \text{Number of Slots to measure} - 1)$.

Return values:

<Result> numeric value
Default unit: dBm

Example:	<pre> \\ Preset the instrument RST \\ Enter the GSM option K10 INSTrument:SElect GSM \\ Switch to single sweep mode and stop sweep INITiate:CONTinuous OFF;:ABORt \\ Set the slot scope: Use all 8 slots for the PvT measurement. \\ Number of slots to measure = 8 CONFigure:MS:CHANnel:MSLots:NOFSlots 8 \\ First Slot to measure = 0 CONFigure:MS:CHANnel:MSLots:OFFSet 0 \\ Activate PvT (Power vs Time) measurement CONFigure:BURSt:PTEmpLete:IMMediate \\ Run a single sweep \\ Note: "FETCh" only reads the results without starting a new single sweep. \\ Run a (blocking) single sweep INITiate:IMMediate;*WAI FETCh:BURSt:SPOWer:SLOT1:DELtatosync? </pre>
Usage:	Query only
Mode:	GSM

4.6.2 FETCh:SPECtrum subsystem

FETCh:SPECtrum:MODulation[:ALL]	184
FETCh:SPECtrum:MODulation:REFerence	185
FETCh:SPECtrum:SWITching[:ALL]	185
FETCh:SPECtrum:SWITching:REFerence	186

FETCh:SPECtrum:MODulation[:ALL]?

This command returns the measured modulation spectrum of the mobile or base station. This command is only available when "Modulation Spectrum" measurement is selected (see [CONFigure:SPECtrum:MODulation\[:IMMediate\]](#) on page 141).

The result is a list of partial result strings separated by commas.

Return values:

<Placeholder>	curently irrelevant
<Freq1>	Absolute offset frequency in Hz
<Freq2>	Absolute offset frequency in Hz
<Level>	Measured level at the offset frequency in dB or dBm (depending on CONFigure:SPECtrum:MODulation:LIMIT).
<Limit>	Limit at the offset frequency in dB or dBm (depending on CONFigure:SPECtrum:MODulation:LIMIT).

<Abs/Rel>	Indicates whether relative (dB) or absolute (dBm) limit and level values are returned (depending on CONFigure:SPECTrum:MODulation:LIMIT).
<Status>	Result of the limit check in character data form PASSED no limit exceeded FAILED limit exceeded
Example:	<code>FETC:SPEC:MOD?</code> <code>0,998200000,998200000,-84.61,-56.85,REL,PASSED,</code> <code>0,998400000,998400000,-85.20,-56.85,REL,PASSED,</code> <code>...</code>
Usage:	Query only
Mode:	GSM

FETCh:SPECTrum:MODulation:REference?

This command returns the measured reference power of the "Modulation Spectrum". This command is only available when the "Modulation Spectrum" measurement is selected (see [CONFigure:SPECTrum:MODulation\[:IMMEDIATE\]](#) on page 141).

The result is a list of partial result strings separated by commas.

Return values:

<Level1>	measured reference power in dBm
<Level2>	measured reference power in dBm
<RBW>	resolution bandwidth used to measure the reference power in Hz

Example: `FETCh:SPECTrum:MODulation:REference?`

Usage: Query only

Mode: GSM

FETCh:SPECTrum:SWITching[:ALL]?

This command reads out the result of the measurement of the transient spectrum of the mobile or base station. This command is only available when the "Transient Spectrum" measurement is selected (see [CONFigure:SPECTrum:SWITching\[:IMMEDIATE\]](#) on page 144).

The result is a list of partial result strings separated by commas.

Return values:

<Placeholder>	curently irrelevant
<Freq1>	Absolute offset frequency in Hz
<Freq2>	Absolute offset frequency in Hz

<Level>	Measured level at the offset frequency in dB or dBm For more information see CONFigure:SPECTrum:SWITching:LIMIT).
<Limit>	Limit at the offset frequency in dB or dBm. For more information see CONFigure:SPECTrum:SWITching:LIMIT).
<Abs/Rel>	Indicates whether relative (dB) or absolute (dBm) limit and level values are returned. For more information see CONFigure:SPECTrum:SWITching:LIMIT).
<Status>	Result of the limit check in character data form PASSED no limit exceeded FAILED limit exceeded
Example:	<code>FETC:SPEC:SWIT?</code> <code>0,998200000,998200000,-84.61,-56.85,REL,PASSED,</code> <code>0,998400000,998400000,-85.20,-56.85,REL,PASSED,</code>
Usage:	Query only
Mode:	GSM

FETCh:SPECTrum:SWITching:REFerence?

This command returns the measured reference power of the "Transient Spectrum". This command is only available when the "Transient Spectrum" measurement is selected (see [CONFigure:SPECTrum:SWITching\[:IMMEDIATE\]](#) on page 144).

The result is a list of partial result strings separated by commas.

Return values:

<Level1>	measured reference power in dBm
<Level2>	measured reference power in dBm
<RBW>	resolution bandwidth used to measure the reference power in Hz

Example:	<code>FETCh:SPECTrum:SWITching:REFerence?</code>
Usage:	Query only
Mode:	GSM

4.6.3 FETCh:WSPECTrum subsystem

FETCh:WSPECTrum:MODulation[:ALL]	187
FETCh:WSPECTrum:MODulation:REFerence	187

FETCh:WSPectrum:MODulation[:ALL]?

This command reads out the result of the "Wide Modulation Spectrum" measurement of the mobile or base station. This command is only available if the modulation spectrum measurement is selected (see [CONFigure:WSPectrum:MODulation\[:IMMEDIATE\]](#)).

Return values:

<Placeholder>	currently irrelevant
<Freq1>	Absolute offset frequency in Hz
<Freq2>	Absolute offset frequency in Hz
<Level>	Measured level at the offset frequency in dB or dBm.
<Limit>	Limit at the offset frequency in dB or dBm.
<Abs/Rel>	Indicates whether relative (dB) or absolute (dBm) limit and level values are returned.
<Status>	Result of the limit check in character data form PASSED no limit exceeded FAILED limit exceeded

Example: FETCh:WSPectrum:MODulation:ALL?

Usage: Query only

Mode: GSM

FETCh:WSPectrum:MODulation:REFerence?

This command returns the measured reference power of the "Wide Modulation Spectrum". This command is only available when the "Wide Modulation Spectrum" measurement is selected (see [CONFigure:WSPectrum:MODulation\[:IMMEDIATE\]](#) on page 146).

The result is a list of partial result strings separated by commas.

Return values:

<Level1>	measured reference power in dBm
<Level2>	measured reference power in dBm
<RBW>	resolution bandwidth used to measure the reference power in Hz

Example: FETCh:WSPectrum:MODulation:REFerence?

Usage: Query only

Mode: GSM

4.7 INITiate Subsystem

The INITiate subsystem is used to start and stop a measurement.

Commands of the INITiate subsystem:

INITiate<n>[:IMMEDIATE].....	188
INITiate<n>:CONTinuous.....	188
INITiate:REFMeas[:IMMEDIATE].....	189

INITiate<n>[:IMMEDIATE]

The command initiates a new measurement sequence.

With sweep count > 0 or average count > 0, this means a restart of the indicated number of measurements. With trace functions MAXHold, MINHold and AVERage, the previous results are reset on restarting the measurement.

In single sweep mode, you can synchronize to the end of the measurement with *OPC, *OPC? or *WAI. In continuous sweep mode, synchronization to the end of the measurement is not possible. Thus, it is not recommended that you use continuous sweep mode in remote control, as results like trace data or markers are only valid after a single sweep end synchronization.

Suffix:

<n> irrelevant

Example:

```
INIT:CONT OFF
```

Switches to single sweep mode.

```
DISP:WIND:TRAC:MODE AVER
```

Switches on trace averaging.

```
SWE:COUN 20
```

Setting the sweep counter to 20 sweeps.

```
INIT;*WAI
```

Starts the measurement and waits for the end of the 20 sweeps.

Mode: all

INITiate<n>:CONTinuous <State>

This command determines whether the trigger system is continuously initiated (continuous) or performs single measurements (single).

The sweep is started immediately.

Suffix:

<n> irrelevant

Parameters:

<State> ON | OFF

*RST: ON

Example: INIT:CONT OFF
Switches the sequence to single sweep.
 INIT:CONT ON
Switches the sequence to continuous sweep.

Mode: all

INITiate:REFMeas[:IMMediate]

Repeats the evaluation of the data currently in the capture buffer without capturing new data. This is useful after changing settings, for example the [Statistic Count](#). Averaging is performed according to the "Statistic Count" and automatically stops when the defined "Statistic Count" or the end of the captured data is reached.

Example: // Preset the instrument
 *RST
 // Enter the GSM option K10
 INSTrument:SELEct GSM
 // Switch to single sweep mode and do one measurement
 INITiate1:CONTInuous OFF
 // Set capture time to 1 s
 SENSE1:SWEep:TIME 1 S
 // Activate power vs time measurement
 CONFIgure:BURSt:PTEMplate:IMMediate
 // Run a (blocking) single sweep
 INITiate:IMMediate;*WAI
 // Export captured I/Q data to file
 MMEMory:STORe:IQ:STATe 1, 'C:\gsm_1.iqw'
 // Run a (blocking) single sweep
 INITiate:IMMediate;*WAI
 // Export captured I/Q data to file
 MMEMory:STORe:IQ:STATe 1, 'C:\gsm_2.iqw'
 // Now we want to analyze the first capture again
 // Import I/Q data from file
 MMEMory:LOAD:IQ:STATe 1, 'C:\gsm_1.iqw'
 // Instead of 1 slots 8 slots should be analyzed
 CONFIgure:MS:CHANnel:MSLots:NOFSlots 8
 // Refresh to apply the changed setting
 INITiate:REFMeas:IMMediate

Usage: Event

Mode: GSM

4.8 INPut Subsystem

The INPut subsystem controls the input characteristics of the RF inputs of the instrument.

[INPut:ATTenuation](#)..... 190
[INPut:ATTenuation:AUTO](#)..... 190

INPut:DIQ:RANGe[:UPPer].....	190
INPut:DIQ:SRATe.....	191
INPut:EATT.....	191
INPut:EATT:AUTO.....	192
INPut:EATT:STATe.....	192
INPut:GAIN:STATe.....	192
INPut:SELect.....	193

INPut:ATTenuation <Value>

This command programs the input attenuator. To protect the input mixer against damage from overloads, the setting 0 dB can be obtained by entering numerals, not by using the DOWN command.

The attenuation can be set in 5 dB steps (with option R&S FSV-B25: 1 dB steps). If the defined reference level cannot be set for the set RF attenuation, the reference level is adjusted accordingly.

In the default state with "Spectrum" mode, the attenuation set on the step attenuator is coupled to the reference level of the instrument. If the attenuation is programmed directly, the coupling to the reference level is switched off.

This function is not available if the R&S Digital I/Q Interface (R&S FSV-B17) is active.

Parameters:

<Value> *RST: 10 dB (AUTO is set to ON)

Example:

INP:ATT 30dB

Sets the attenuation on the attenuator to 30 dB and switches off the coupling to the reference level.

Mode: all

INPut:ATTenuation:AUTO <State>

This command automatically couples the input attenuation to the reference level (state ON) or switches the input attenuation to manual entry (state OFF).

This function is not available if the R&S Digital I/Q Interface (R&S FSV-B17) is active.

Parameters:

<State> ON | OFF
 *RST: ON

Example:

INP:ATT:AUTO ON

Couples the attenuation set on the attenuator to the reference level.

Mode: All

INPut:DIQ:RANGe[:UPPer] <Level>

Defines or queries the "Full Scale Level", i.e. the level that should correspond to an I/Q sample with the magnitude "1".

This command is only available if the optional R&S Digital I/Q Interface (option R&S FSV-B17) is installed.

For details see the R&S Digital I/Q Interface (R&S FSV-B17) description of the base unit.

Parameters:

<Level> <numeric value>
 Range: 1E-06 V to 7.071 V
 *RST: 1 V

Example: INP:DIQ:RANG 1V

Mode: A, IQ, NF, TDS, VSA, CDMA, EVDO, WCDMA, ADEMOD, GSM, OFDM, OFDMA/WiBro, WLAN

INPut:DIQ:SRATe <SampleRate>

This command specifies or queries the sample rate of the input signal from the R&S Digital I/Q Interface (see ["Input Sample Rate"](#) on page 63).

This command is only available if the optional R&S Digital I/Q Interface (option R&S FSV-B17) is installed.

For details see the R&S Digital I/Q Interface (R&S FSV-B17) description of the base unit.

Parameters:

<SampleRate> Range: 1 Hz to 10 GHz
 *RST: 32 MHz

Example: INP:DIQ:SRAT 200 MHz

Mode: A, IQ, NF, TDS, VSA, CDMA, EVDO, WCDMA, ADEMOD, GSM, OFDM, OFDMA/WiBro, WLAN

INPut:EATT <Attenuation>

Requires option R&S FSV-B25.

Switches the electronic attenuator on (if not already active) and allows the attenuation of the electronic attenuator to be set.

This command is only available with option R&S FSV-B25, but not if R&S FSV-B17 is active.

The attenuation can be varied in 1 dB steps from 0 to 25 dB. Other entries are rounded to the next lower integer value.

If the defined reference level cannot be set for the given RF attenuation, the reference level is adjusted accordingly and the warning "Limit reached" is output.

Parameters:

<Attenuation> 0...25
 *RST: 0 dB (OFF)

Example: INP1:EATT 10 dB

Mode: all

INPut:EATT:AUTO <State>

Switches the automatic behaviour of the electronic attenuator on or off. If activated, electronic attenuation is used to reduce the operation of the mechanical attenuation whenever possible.

This command is only available with option R&S FSV-B25, but not if R&S FSV-B17 is active.

Parameters:

<State> ON | OFF
*RST: ON

Example: INP1:EATT:AUTO OFF

Mode: all

INPut:EATT:STATe <State>

Switches the electronic attenuator on or off.

This command is only available with option R&S FSV-B25, but not if R&S FSV-B17 is active.

Parameters:

<State> ON | OFF
*RST: OFF

Example: INP:EATT:STAT ON
Switches the electronic attenuator into the signal path.

Mode: all

INPut:GAIN:STATe <State>

This command switches the preamplifier on or off (only for option RF Preamplifier, R&S FSV-B22/B24).

With option R&S FSV-B22, the preamplifier only has an effect below 7 GHz.

With option R&S FSV-B24, the amplifier applies to the entire frequency range.

This command is not available when using R&S Digital I/Q Interface (R&S FSV-B17).

Parameters:

<State> ON | OFF
*RST: OFF

Example: INP:GAIN:STAT ON
Switches on 20 dB preamplification.

Mode: A, ADEMOD, BT, CDMA, EVDO, NF, PHN, WCDMA, GSM, VSA, TDS

INPut:SElect <Source>

This command selects the signal source for measurements.

Parameters:

<Source> RF | DIQ

RF
Radio Frequency ("RF INPUT" connector)

DIQ
Digital IQ (only available with R&S Digital I/Q Interface, option R&S FSV-B17)

*RST: RF

Example: INP:SEL RF

Mode: A, IQ, NF, TDS, VSA, CDMA, EVDO, WCDMA, ADEMOD, GSM, OFDM, OFDMA/WiBro, WLAN

4.9 INSTrument Subsystem

The INSTrument subsystem selects the operating mode of the unit either via text parameters or fixed numbers.

Commands of the INSTrument subsystem:

INSTrument[:SElect].....193
INSTrument:NSElect.....194

INSTrument[:SElect] <Mode>

Selects the operating mode. Note that the commands are different for R&S FSVR and R&S FSQ/FSG.

Parameters for setting and query:

<Mode> SANalyzer | MGSM | GSM

SAN
Spectrum analyzer

MGSM (R&S FSQ/FSG: GSM)
GSM mode (R&S FSV-K10 option)

*RST: SAN

Example: INST MGSM

Usage: SCPI confirmed

Mode: GSM

INSTrument:NSElect <Mode>

Selects the operating mode.

Note that the commands are different for R&S FSV and R&S FSQ/FSG.

Parameters for setting and query:

<Mode> 1 | 5
 1
 Spectrum analyzer
 5
 GSM option, R&S FSV-K10
 *RST: 1

Example: INST:NSEL 5

Usage: SCPI confirmed

Mode: GSM

4.10 MMEMory Subsystem

MMEMory:LOAD:IQ:STATe.....	194
MMEMory:MDIRectory.....	195
MMEMory:STORE:IQ:STATe.....	195

MMEMory:LOAD:IQ:STATe 1, <FileName>

This command loads the I/Q data from the specified .iqw file.

Note: switch to single sweep mode (INIT:CONT OFF) before importing I/Q data as otherwise the instrument will continue to measure data and display the current results rather than the imported data.

Parameters:

<FileName> Complete file name including the path

Example:

```
// Preset the instrument
*RST
// Enter the GSM option K10
INSTRument:SElect GSM
// Switch to single sweep mode and do one measurement
INITiate1:CONTinuous OFF
// Set capture time to 1 s
SENSe1:SWEEp:TIME 1 S
// Activate power vs time measurement
CONFigure:BURSt:PTEMplate:IMMediate
// Run a (blocking) single sweep
INITiate:IMMediate;*WAI
// Export captured I/Q data to file
MMEMory:STORE:IQ:STATe 1, 'C:\gsm_1.iqw'
// Run a (blocking) single sweep
INITiate:IMMediate;*WAI
// Export captured I/Q data to file
MMEMory:STORE:IQ:STATe 1, 'C:\gsm_2.iqw'
// Now we want to analyze the first capture again
// Import I/Q data from file
MMEMory:LOAD:IQ:STATe 1, 'C:\gsm_1.iqw'
// Instead of 1 slots 8 slots should be analyzed
CONFigure:MS:CHANnel:MSLots:NOFSlots 8
// Refresh to apply the changed setting
INITiate:REFMeas:IMMediate
```

Usage: Setting only

Mode: CDMA, EVDO, GSM, IQ, TDS, VSA, WCDMA

MMEMory:MDIRectory <Directory>

This command creates a new directory. The file name includes indication of the path and may also include the drive name. The path name complies with DOS conventions.

Parameters:

<Directory> <directory_name> = DOS path name

Example: MMEM:MDIR 'C:\R_S\Instr\user'

Usage: Event

Mode: all

MMEMory:STORE:IQ:STATe 1, <FileName>

This command stores the I/Q data to the specified .iqw file.

Parameters:

<FileName> Complete file name including the path

```

Example:          // Preset the instrument
                    *RST
                    // Enter the GSM option K10
                    INSTRument:SElect GSM
                    // Switch to single sweep mode and do one measurement
                    INITiate1:CONTinuous OFF
                    // Set capture time to 1 s
                    SENSE1:SWEep:TIME 1 S
                    // Activate power vs time measurement
                    CONFigure:BURSt:PTEMplate:IMMediate
                    // Run a (blocking) single sweep
                    INITiate:IMMediate;*WAI
                    // Export captured I/Q data to file
                    MMEMemory:STORE:IQ:STATe 1, 'C:\gsm_1.iqw'
                    // Run a (blocking) single sweep
                    INITiate:IMMediate;*WAI
                    // Export captured I/Q data to file
                    MMEMemory:STORE:IQ:STATe 1, 'C:\gsm_2.iqw'
                    // Now we want to analyze the first capture again
                    // Import I/Q data from file
                    MMEMemory:LOAD:IQ:STATe 1, 'C:\gsm_1.iqw'
                    // Instead of 1 slots 8 slots should be analyzed
                    CONFigure:MS:CHANnel:MSLots:NOFSlots 8
                    // Refresh to apply the changed setting
                    INITiate:REFMeas:IMMediate

Mode:           CDMA, EVDO, GSM, IQ, TDS, VSA, WCDMA

```

4.11 READ Subsystem

The READ subsystem contains commands for starting complex measurement tasks, and for querying the results subsequently.

The following subsystems are included:

4.11.1	READ:BURSt subsystem	196
4.11.2	READ:SPECTrum subsystem.....	231
4.11.3	READ:WSPectrum subsystem.....	234

4.11.1 READ:BURSt subsystem

READ:BURSt[:MACCuracy]:ALL.....	198
READ:BURSt[:MACCuracy]:ADRoop:AVERage.....	198
READ:BURSt[:MACCuracy]:ADRoop:CURRent.....	199
READ:BURSt[:MACCuracy]:ADRoop:MAXimum.....	199
READ:BURSt[:MACCuracy]:ADRoop:SDEViation.....	199
READ:BURSt[:MACCuracy]:BPOWer:AVERage.....	200

READ:BURSt[:MACCuracy]:BPOWer:CURRent.....	200
READ:BURSt[:MACCuracy]:BPOWer:MAXimum.....	200
READ:BURSt[:MACCuracy]:BPOWer:SDEViation.....	201
READ:BURSt[:MACCuracy][:EVM]:PEAK:AVERage.....	201
READ:BURSt[:MACCuracy][:EVM]:PEAK:CURRent.....	201
READ:BURSt[:MACCuracy][:EVM]:PEAK:MAXimum.....	202
READ:BURSt[:MACCuracy][:EVM]:PEAK:SDEViation.....	202
READ:BURSt[:MACCuracy][:EVM]:RMS:AVERage.....	203
READ:BURSt[:MACCuracy][:EVM]:RMS:CURRent.....	203
READ:BURSt[:MACCuracy][:EVM]:RMS:MAXimum.....	203
READ:BURSt[:MACCuracy][:EVM]:RMS:SDEViation.....	204
READ:BURSt[:MACCuracy]:FERRor:AVERage.....	204
READ:BURSt[:MACCuracy]:FERRor:CURRent.....	205
READ:BURSt[:MACCuracy]:FERRor:MAXimum.....	205
READ:BURSt[:MACCuracy]:FERRor:SDEViation.....	206
READ:BURSt[:MACCuracy]:FREQUency:AVERage.....	206
READ:BURSt[:MACCuracy]:FREQUency:CURRent.....	206
READ:BURSt[:MACCuracy]:FREQUency:MAXimum.....	207
READ:BURSt[:MACCuracy]:FREQUency:SDEViation.....	207
READ:BURSt[:MACCuracy]:IQIMbalance:AVERage.....	208
READ:BURSt[:MACCuracy]:IQIMbalance:CURRent.....	208
READ:BURSt[:MACCuracy]:IQIMbalance:MAXimum.....	208
READ:BURSt[:MACCuracy]:IQIMbalance:SDEViation.....	209
READ:BURSt[:MACCuracy]:IQOFfset:AVERage.....	209
READ:BURSt[:MACCuracy]:IQOFfset:CURRent.....	209
READ:BURSt[:MACCuracy]:IQOFfset:MAXimum.....	210
READ:BURSt[:MACCuracy]:IQOFfset:SDEViation.....	210
READ:BURSt[:MACCuracy]:MERRor:PEAK:AVERage.....	210
READ:BURSt[:MACCuracy]:MERRor:PEAK:CURRent.....	211
READ:BURSt[:MACCuracy]:MERRor:PEAK:MAXimum.....	211
READ:BURSt[:MACCuracy]:MERRor:PEAK:SDEViation.....	212
READ:BURSt[:MACCuracy]:MERRor:RMS:AVERage.....	212
READ:BURSt[:MACCuracy]:MERRor:RMS:CURRent.....	212
READ:BURSt[:MACCuracy]:MERRor:RMS:MAXimum.....	213
READ:BURSt[:MACCuracy]:MERRor:RMS:SDEViation.....	213
READ:BURSt[:MACCuracy]:OSUPpress:AVERage.....	213
READ:BURSt[:MACCuracy]:OSUPpress:CURRent.....	214
READ:BURSt[:MACCuracy]:OSUPpress:MAXimum.....	214
READ:BURSt[:MACCuracy]:OSUPpress:SDEViation.....	215
READ:BURSt[:MACCuracy]:PERCentile:EVM.....	215
READ:BURSt[:MACCuracy]:PERCentile:MERRor.....	215
READ:BURSt[:MACCuracy]:PERCentile:PERRor.....	216
READ:BURSt[:MACCuracy]:PERRor:PEAK:AVERage.....	216
READ:BURSt[:MACCuracy]:PERRor:PEAK:CURRent.....	216
READ:BURSt[:MACCuracy]:PERRor:PEAK:MAXimum.....	217
READ:BURSt[:MACCuracy]:PERRor:PEAK:SDEViation.....	217
READ:BURSt[:MACCuracy]:PERRor:RMS:AVERage.....	217
READ:BURSt[:MACCuracy]:PERRor:RMS:CURRent.....	218
READ:BURSt[:MACCuracy]:PERRor:RMS:MAXimum.....	218
READ:BURSt[:MACCuracy]:PERRor:RMS:SDEViation.....	219

READ:BURSt:PTEMplate:TRGS:AVERAge.....	219
READ:BURSt:PTEMplate:TRGS:CURRent.....	220
READ:BURSt:PTEMplate:TRGS:MAXimum.....	221
READ:BURSt:PTEMplate:TRGS:MINimum.....	222
READ:BURSt:PTEMplate:TRGS:SDEViatiOn.....	223
READ:BURSt:SPOWer:SLOT<Slot>:ALL:AVERAge.....	224
READ:BURSt:SPOWer:SLOT<Slot>:ALL:CRESt.....	225
READ:BURSt:SPOWer:SLOT<Slot>:ALL:MAXimum.....	226
READ:BURSt:SPOWer:SLOT<Slot>:CURRent:AVERAge.....	227
READ:BURSt:SPOWer:SLOT<Slot>:CURRent:CRESt.....	228
READ:BURSt:SPOWer:SLOT<Slot>:CURRent:MAXimum.....	229
READ:BURSt:SPOWer:SLOT<Slot>:DELtatOsync.....	230

READ:BURSt[:MACCuracy]:ALL?

This command starts the measurement and returns all the results. When the measurement is started the analyzer is automatically set to single sweep.

Further results of the measurement can then be queried without restart of the measurement via the `FEtCh:BURSt` subsystem.

Example: `READ:BURSt:ALL?`

Usage: Query only

Mode: GSM

READ:BURSt[:MACCuracy]:ADRooP:AVERAge?

This command starts the measurement and reads out the average measurement of the Amplitude Droop taken over the selected number of bursts. When the measurement is started the analyzer is automatically set to single sweep. Further results of the measurement can then be queried without restart of the measurement via the `FEtCh:BURSt` subsystem.

Return values:

<Result> numeric value
 Average
 Default unit: dB

Example: `READ:BURSt:ADR:AVER?`

Usage: Query only

Mode: GSM

READ:BURSt[:MACCuracy]:ADRoop:CURRent?

This command starts the measurement and reads out the currently measured value of the Amplitude Droop taken over the selected number of bursts. When the measurement is started the analyzer is automatically set to single sweep. Further results of the measurement can then be queried without restart of the measurement via the `FETCh:BURSt` subsystem.

Return values:

<Result> numeric value
 Currently measured value
 Default unit: dB

Example: `READ:BURS:ADR:CURR?`

Usage: Query only

Mode: GSM

READ:BURSt[:MACCuracy]:ADRoop:MAXimum?

This command starts the measurement and reads out the maximum measurement of the Amplitude Droop taken over the selected number of bursts. When the measurement is started the analyzer is automatically set to single sweep. Further results of the measurement can then be queried without restart of the measurement via the `FETCh:BURSt` subsystem.

Return values:

<Result> numeric value
 Maximum
 Default unit: dB

Example: `READ:BURS:ADR:MAX?`

Usage: Query only

Mode: GSM

READ:BURSt[:MACCuracy]:ADRoop:SDEVIation?

This command starts the measurement and reads out the standard deviation measurement of the Amplitude Droop taken over the selected number of bursts. When the measurement is started the analyzer is automatically set to single sweep. Further results of the measurement can then be queried without restart of the measurement via the `FETCh:BURSt` subsystem.

Return values:

<Result> numeric value
 Standard deviation
 Default unit: dB

Example: `READ:BURS:ADR:SDEV?`

Usage: Query only

Mode: GSM

READ:BURSt[:MACCuracy]:BPOWer:AVERage?

This command starts the measurement and reads out the average measurement of the Burst Power taken over the selected number of bursts. When the measurement is started the analyzer is automatically set to single sweep. Further results of the measurement can then be queried without restart of the measurement via the `FETCh:BURSt` subsystem.

Return values:

<Result> numeric value
Average
Default unit: dB

Example: `READ:BURSt:BPOW:AVER?`

Usage: Query only

Mode: GSM

READ:BURSt[:MACCuracy]:BPOWer:CURRent?

This command starts the measurement and reads out the currently measured value of the Burst Power taken over the selected number of bursts. When the measurement is started the analyzer is automatically set to single sweep. Further results of the measurement can then be queried without restart of the measurement via the `FETCh:BURSt` subsystem.

Return values:

<Result> numeric value
Currently measured value
Default unit: dB

Example: `READ:BURSt:BPOW:CURR?`

Usage: Query only

Mode: GSM

READ:BURSt[:MACCuracy]:BPOWer:MAXimum?

This command starts the measurement and reads out the maximum measurement of the Burst Power taken over the selected number of bursts. When the measurement is started the analyzer is automatically set to single sweep. Further results of the measurement can then be queried without restart of the measurement via the `FETCh:BURSt` subsystem.

Return values:

<Result> numeric value
Maximum
Default unit: dB

Example: READ: BURS: BPOW: MAX?
Usage: Query only
Mode: GSM

READ: BURSt[:MACCuracy]: BPOWer: SDEVIation?

This command starts the measurement and reads out the standard deviation measurement of the Burst Power taken over the selected number of bursts. When the measurement is started the analyzer is automatically set to single sweep. Further results of the measurement can then be queried without restart of the measurement via the FETCh: BURSt subsystem.

Return values:

<Result> numeric value
 Standard deviation
 Default unit: dB

Example: READ: BURS: BPOW: SDEV?
Usage: Query only
Mode: GSM

READ: BURSt[:MACCuracy][:EVM]: PEAK: AVERAge?

This command starts the measurement and reads out the average of the peak measurement of the Error Vector Magnitude taken over the selected number of bursts. When the measurement is started the analyzer is automatically set to single sweep. Further results of the measurement can then be queried without restart of the measurement via the FETCh: BURSt subsystem.

Return values:

<Result> numeric value
 Average
 Default unit: NONE

Example: READ: BURS: PEAK: AVER?
Usage: Query only
Mode: GSM

READ: BURSt[:MACCuracy][:EVM]: PEAK: CURRent?

This command starts the measurement and reads out the currently measured peak value of the Error Vector Magnitude taken over the selected number of bursts. When the measurement is started the analyzer is automatically set to single sweep. Further results of the measurement can then be queried without restart of the measurement via the FETCh: BURSt subsystem.

Return values:

<Result> numeric value
 Currently measured value
 Default unit: NONE

Example: READ: BURS: PEAK: CURR?

Usage: Query only

Mode: GSM

READ: BURSt[:MACCuracy][:EVM]:PEAK:MAXimum?

This command starts the measurement and reads out the maximum of the peak measurement of the Error Vector Magnitude taken over the selected number of bursts. When the measurement is started the analyzer is automatically set to single sweep. Further results of the measurement can then be queried without restart of the measurement via the `FETCh: BURSt` subsystem.

Return values:

<Result> numeric value
 Maximum
 Default unit: NONE

Example: READ: BURS: PEAK: MAX?

Usage: Query only

Mode: GSM

READ: BURSt[:MACCuracy][:EVM]:PEAK:SDEViation?

This command starts the measurement and reads out the average of the peak measurement of the Error Vector Magnitude taken over the selected number of bursts. When the measurement is started the analyzer is automatically set to single sweep. Further results of the measurement can then be queried without restart of the measurement via the `FETCh: BURSt` subsystem.

Return values:

<Result> numeric value
 Standard deviation
 Default unit: NONE

Example: READ: BURS: PEAK: AVER?

Usage: Query only

Mode: GSM

READ:BURSt[:MACCuracy][:EVM]:RMS:AVERAge?

This command starts the measurement and reads out the average of the RMS measurement of the Error Vector Magnitude taken over the selected number of bursts. When the measurement is started the analyzer is automatically set to single sweep. Further results of the measurement can then be queried without restart of the measurement via the `FETCh:BURSt` subsystem.

Return values:

<Result> numeric value
Average
Default unit: NONE

Example: `READ:BURS:RMS:AVER?`

Usage: Query only

Mode: GSM

READ:BURSt[:MACCuracy][:EVM]:RMS:CURRent?

This command starts the measurement and reads out the currently measured RMS value of the Error Vector Magnitude taken over the selected number of bursts. When the measurement is started the analyzer is automatically set to single sweep. Further results of the measurement can then be queried without restart of the measurement via the `FETCh:BURSt` subsystem.

Return values:

<Result> numeric value
Currently measured value
Default unit: NONE

Example: `READ:BURS:RMS:CURR?`

Usage: Query only

Mode: GSM

READ:BURSt[:MACCuracy][:EVM]:RMS:MAXimum?

This command starts the measurement and reads out the maximum of the RMS measurement of the Error Vector Magnitude taken over the selected number of bursts. When the measurement is started the analyzer is automatically set to single sweep. Further results of the measurement can then be queried without restart of the measurement via the `FETCh:BURSt` subsystem.

Return values:

<Result> numeric value
Maximum
Default unit: NONE

Example: `READ:BURS:RMS:MAX?`

Usage: Query only

Mode: GSM

READ:BURSt[:MACCuracy][:EVM]:RMS:SDEVIation?

This command starts the measurement and reads out the standard deviation of the RMS measurement of the Error Vector Magnitude taken over the selected number of bursts. When the measurement is started the analyzer is automatically set to single sweep. Further results of the measurement can then be queried without restart of the measurement via the `FETCH:BURSt` subsystem.

Return values:

<Result> numeric value
 Standard deviation
 Default unit: NONE

Example: `READ:BURS:RMS:SDEV?`

Usage: Query only

Mode: GSM

READ:BURSt[:MACCuracy]:FERRor:AVERage?

This command starts the measurement and reads out the average measurement of the Frequency Error taken over the selected number of bursts. When the measurement is started the analyzer is automatically set to single sweep. Further results of the measurement can then be queried without restart of the measurement via the `FETCH:BURSt` subsystem.

This command is retained for compatibility with R&S FS-K5 only. Use the [READ: BURSt\[:MACCuracy\]:FREQuency:AVERage](#) command which behaves the same way.

Return values:

<Result> numeric value
 Average
 Default unit: Hz

Example: `READ:BURS:FERR:AVER?`

Usage: Query only

Mode: GSM

READ:BURSt[:MACCuracy]:FERRor:CURRent?

This command starts the measurement and reads out the currently measured value of the Frequency Error taken over the selected number of bursts. When the measurement is started the analyzer is automatically set to single sweep. Further results of the measurement can then be queried without restart of the measurement via the `FETCH:BURSt` subsystem.

This command is retained for compatibility with R&S FS-K5 only. Use the `READ: BURSt [:MACCuracy] :FREQuency:CURRent` command which behaves the same way.

Return values:

<Result> numeric value
 Currently measured value
 Default unit: Hz

Example: `READ: BURS: FERR: CURR?`

Usage: Query only

Mode: GSM

READ:BURSt[:MACCuracy]:FERRor:MAXimum?

This command starts the measurement and reads out the maximum measurement of the Frequency Error taken over the selected number of bursts. When the measurement is started the analyzer is automatically set to single sweep. Further results of the measurement can then be queried without restart of the measurement via the `FETCH:BURSt` subsystem.

This command is retained for compatibility with R&S FSV-K5 only. Use the `READ: BURSt [:MACCuracy] :FREQuency:MAXimum` command which behaves the same way.

Note

An ongoing measurement can be aborted via the command `ABORT`.

Return values:

<Result> numeric value
 Maximum
 Default unit: Hz

Example: `READ: BURS: FERR: MAX?`

Usage: Query only

Mode: GSM

READ:BURSt[:MACCuracy]:FERRor:SDEVIation?

This command starts the measurement and reads out the standard deviation measurement of the Frequency Error taken over the selected number of bursts. When the measurement is started the analyzer is automatically set to single sweep. Further results of the measurement can then be queried without restart of the measurement via the `FETCh:BURSt` subsystem.

This command is retained for compatibility with R&S FSV-K5 only. Use the `READ: BURSt[:MACCuracy]:FREQuency:SDEVIation` command which behaves the same way.

Return values:

<Result> numeric value
 Standard deviation
 Default unit: Hz

Example: `READ: BURS: FERR: SDEV?`

Usage: Query only

Mode: GSM

READ:BURSt[:MACCuracy]:FREQuency:AVERage?

This command starts the measurement and reads out the average measurement of the Frequency Error taken over the selected number of bursts. When the measurement is started the analyzer is automatically set to single sweep. Further results of the measurement can then be queried without restart of the measurement via the `FETCh:BURSt` subsystem.

Return values:

<Result> numeric value
 Average
 Default unit: Hz

Example: `READ: BURS: FREQ: AVER?`

Usage: Query only

Mode: GSM

READ:BURSt[:MACCuracy]:FREQuency:CURRent?

This command starts the measurement and reads out the currently measured value of the Frequency Error taken over the selected number of bursts. When the measurement is started the analyzer is automatically set to single sweep. Further results of the measurement can then be queried without restart of the measurement via the `FETCh:BURSt` subsystem.

Return values:

<Result> numeric value
 Currently measured value
 Default unit: Hz

Example: READ: BURS: FREQ: CURR?

Usage: Query only

Mode: GSM

READ: BURSt[:MACCuracy]: FREQUency: MAXimum?

This command starts the measurement and reads out the maximum measurement of the Frequency Error taken over the selected number of bursts. When the measurement is started the analyzer is automatically set to single sweep. Further results of the measurement can then be queried without restart of the measurement via the `FETCh: BURSt` subsystem.

Return values:

<Result> numeric value
 Maximum
 Default unit: Hz

Example: READ: BURS: FREQ: MAX?

Usage: Query only

Mode: GSM

READ: BURSt[:MACCuracy]: FREQUency: SDEVIation?

This command starts the measurement and reads out the standard deviation measurement of the Frequency Error taken over the selected number of bursts. When the measurement is started the analyzer is automatically set to single sweep. Further results of the measurement can then be queried without restart of the measurement via the `FETCh: BURSt` subsystem.

Return values:

<Result> numeric value
 Standard deviation
 Default unit: Hz

Example: READ: BURS: FREQ: SDEV?

Usage: Query only

Mode: GSM

READ:BURSt[:MACCuracy]:IQIMbalance:AVERAge?

This command starts the measurement and reads out the average measurement of the IQ Imbalance taken over the selected number of bursts. When the measurement is started the analyzer is automatically set to single sweep. Further results of the measurement can then be queried without restart of the measurement via the `FETCh:BURSt` subsystem.

Return values:

<Result> numeric value
Average
Default unit: NONE

Example: `READ:BURSt:IQIM:AVER?`

Usage: Query only

Mode: GSM

READ:BURSt[:MACCuracy]:IQIMbalance:CURRent?

This command starts the measurement and reads out the currently measured value of the IQ Imbalance taken over the selected number of bursts. When the measurement is started the analyzer is automatically set to single sweep. Further results of the measurement can then be queried without restart of the measurement via the `FETCh:BURSt` subsystem.

Return values:

<Result> numeric value
Currently measured value
Default unit: NONE

Example: `READ:BURSt:IQIM:CURR?`

Usage: Query only

Mode: GSM

READ:BURSt[:MACCuracy]:IQIMbalance:MAXimum?

This command starts the measurement and reads out the maximum measurement of the IQ Imbalance taken over the selected number of bursts. When the measurement is started the analyzer is automatically set to single sweep. Further results of the measurement can then be queried without restart of the measurement via the `FETCh:BURSt` subsystem.

Return values:

<Result> numeric value
Maximum
Default unit: NONE

Example: `READ:BURSt:IQIM:MAX?`

Usage: Query only

Mode: GSM

READ:BURSt[:MACCuracy]:IQIMbalance:SDEViation?

This command starts the measurement and reads out the standard deviation measurement of the IQ Imbalance taken over the selected number of bursts. When the measurement is started the analyzer is automatically set to single sweep. Further results of the measurement can then be queried without restart of the measurement via the `FETCh:BURSt` subsystem.

Return values:

<Result> numeric value
Standard deviation
Default unit: NONE

Example: `READ:BURSt:IQIM:SDEV?`

Usage: Query only

Mode: GSM

READ:BURSt[:MACCuracy]:IQOffset:AVERage?

This command starts the measurement and reads out the average measurement of the IQ Offset taken over the selected number of bursts. When the measurement is started the analyzer is automatically set to single sweep. Further results of the measurement can then be queried without restart of the measurement via the `FETCh:BURSt` subsystem.

Return values:

<Result> numeric value
Average
Default unit: NONE

Example: `READ:BURSt:IQOF:AVER?`

Usage: Query only

Mode: GSM

READ:BURSt[:MACCuracy]:IQOffset:CURRENT?

This command starts the measurement and reads out the currently measured value of the IQ Offset taken over the selected number of bursts. When the measurement is started the analyzer is automatically set to single sweep. Further results of the measurement can then be queried without restart of the measurement via the `FETCh:BURSt` subsystem.

Return values:

<Result> numeric value
Currently measured value
Default unit: NONE

Example: READ: BURS: IQOF: CURR?
Usage: Query only
Mode: GSM

READ: BURSt[:MACCuracy]: IQOffset: MAXimum?

This command starts the measurement and reads out the maximum measurement of the IQ Offset taken over the selected number of bursts. When the measurement is started the analyzer is automatically set to single sweep. Further results of the measurement can then be queried without restart of the measurement via the `FETCh: BURSt` subsystem.

Return values:

<Result> numeric value
 Maximum
 Default unit: NONE

Example: READ: BURS: IQOF: MAX?
Usage: Query only
Mode: GSM

READ: BURSt[:MACCuracy]: IQOffset: SDEVIation?

This command starts the measurement and reads out the standard deviation measurement of the IQ Offset taken over the selected number of bursts. When the measurement is started the analyzer is automatically set to single sweep. Further results of the measurement can then be queried without restart of the measurement via the `FETCh: BURSt` subsystem.

Return values:

<Result> numeric value
 Standard deviation
 Default unit: NONE

Example: READ: BURS: IQOF: SDEV?
Usage: Query only
Mode: GSM

READ: BURSt[:MACCuracy]: MERRor: PEAK: AVERAge?

This command starts the measurement and reads out the average of the peak measurement of the Magnitude Error taken over the selected number of bursts. When the measurement is started the analyzer is automatically set to single sweep. Further results of the measurement can then be queried without restart of the measurement via the `FETCh: BURSt` subsystem.

Return values:

<Result> numeric value
 Average
 Default unit: NONE

Example: READ: BURS: MERR: PEAK: AVER?

Usage: Query only

Mode: GSM

READ: BURSt[:MACCuracy]: MERRor: PEAK: CURRent?

This command starts the measurement and reads out the currently measured peak value of the Magnitude Error taken over the selected number of bursts. When the measurement is started the analyzer is automatically set to single sweep. Further results of the measurement can then be queried without restart of the measurement via the `FETCh: BURSt` subsystem.

Return values:

<Result> numeric value
 Currently measured value
 Default unit: NONE

Example: READ: BURS: MERR: PEAK: CURR?

Usage: Query only

Mode: GSM

READ: BURSt[:MACCuracy]: MERRor: PEAK: MAXimum?

This command starts the measurement and reads out the maximum of the peak measurement of the Magnitude Error taken over the selected number of bursts. When the measurement is started the analyzer is automatically set to single sweep. Further results of the measurement can then be queried without restart of the measurement via the `FETCh: BURSt` subsystem.

Return values:

<Result> numeric value
 Maximum
 Default unit: NONE

Example: READ: BURS: MERR: PEAK: MAX?

Usage: Query only

Mode: GSM

READ:BURSt[:MACCuracy]:MERRor:PEAK:SDEVIation?

This command starts the measurement and reads out the standard deviation of the peak measurement of the Magnitude Error taken over the selected number of bursts. When the measurement is started the analyzer is automatically set to single sweep. Further results of the measurement can then be queried without restart of the measurement via the `FETCh:BURSt` subsystem.

Return values:

<Result> numeric value
 Standard deviation
 Default unit: NONE

Example: `READ:BURS:MERR:PEAK:SDEV?`

Usage: Query only

Mode: GSM

READ:BURSt[:MACCuracy]:MERRor:RMS:AVERAge?

This command starts the measurement and reads out the average of the RMS measurement of the Magnitude Error taken over the selected number of bursts. When the measurement is started the analyzer is automatically set to single sweep. Further results of the measurement can then be queried without restart of the measurement via the `FETCh:BURSt` subsystem.

Return values:

<Result> numeric value
 Average
 Default unit: NONE

Example: `READ:BURS:MERR:RMS:AVER?`

Usage: Query only

Mode: GSM

READ:BURSt[:MACCuracy]:MERRor:RMS:CURRent?

This command starts the measurement and reads out the currently measured RMS value of the Magnitude Error taken over the selected number of bursts. When the measurement is started the analyzer is automatically set to single sweep. Further results of the measurement can then be queried without restart of the measurement via the `FETCh:BURSt` subsystem.

Return values:

<Result> numeric value
 Currently measured value
 Default unit: NONE

Example: `READ:BURS:MERR:RMS:CURR?`

Usage: Query only

Mode: GSM

READ:BURSt[:MACCuracy]:MERRor:RMS:MAXimum?

This command starts the measurement and reads out the maximum of the RMS measurement of the Magnitude Error taken over the selected number of bursts. When the measurement is started the analyzer is automatically set to single sweep. Further results of the measurement can then be queried without restart of the measurement via the `FETCh:BURSt` subsystem.

Return values:

<Result> numeric value
Maximum
Default unit: NONE

Example: `READ:BURSt:MErr:RMS:MAX?`

Usage: Query only

Mode: GSM

READ:BURSt[:MACCuracy]:MERRor:RMS:SDEVIation?

This command starts the measurement and reads out the standard deviation of the RMS measurement of the Magnitude Error taken over the selected number of bursts. When the measurement is started the analyzer is automatically set to single sweep. Further results of the measurement can then be queried without restart of the measurement via the `FETCh:BURSt` subsystem.

Return values:

<Result> numeric value
Standard deviation
Default unit: NONE

Example: `READ:BURSt:MErr:RMS:SDEV?`

Usage: Query only

Mode: GSM

READ:BURSt[:MACCuracy]:OSUPpress:AVERAge?

This command starts the measurement and reads out the average measurement of the IQ Offset Suppression taken over the selected number of bursts. When the measurement is started the analyzer is automatically set to single sweep. Further results of the measurement can then be queried without restart of the measurement via the `FETCh:BURSt` subsystem.

Return values:

<Result> numeric value
 Average
 Default unit: dB

Example: READ: BURS: OSUP: AVER?

Usage: Query only

Mode: GSM

READ: BURSt[:MACCuracy]: OSUPpress: CURRent?

This command starts the measurement and reads out the currently measured value of the IQ Offset Suppression taken over the selected number of bursts. When the measurement is started the analyzer is automatically set to single sweep. Further results of the measurement can then be queried without restart of the measurement via the `FETCh: BURSt` subsystem.

Return values:

<Result> numeric value
 Currently measured value
 Default unit: dB

Example: READ: BURS: OSUP: CURR?

Usage: Query only

Mode: GSM

READ: BURSt[:MACCuracy]: OSUPpress: MAXimum?

This command starts the measurement and reads out the maximum measurement of the IQ Offset Suppression taken over the selected number of bursts. When the measurement is started the analyzer is automatically set to single sweep. Further results of the measurement can then be queried without restart of the measurement via the `FETCh: BURSt` subsystem.

Return values:

<Result> numeric value
 Maximum
 Default unit: dB

Example: READ: BURS: OSUP: MAX?

Usage: Query only

Mode: GSM

READ:BURSt[:MACCuracy]:OSUPpress:SDEVIation?

This command starts the measurement and reads out the standard deviation measurement of the IQ Offset Suppression taken over the selected number of bursts. When the measurement is started the analyzer is automatically set to single sweep. Further results of the measurement can then be queried without restart of the measurement via the `FETCh:BURSt` subsystem.

Return values:

<Result> numeric value
 Standard deviation
 Default unit: dB

Example: `READ: BURS: OSUP: SDEV?`

Usage: Query only

Mode: GSM

READ:BURSt[:MACCuracy]:PERCentile:EVM?

This command starts the measurement and reads out the 95 % percentile of the Error Vector Magnitude measurement taken over the selected number of bursts. When the measurement is started the analyzer is automatically set to single sweep. Further results of the measurement can then be queried without restart of the measurement via the `FETCh:BURSt` subsystem.

Return values:

<Result> numeric value
 Default unit: NONE

Example: `READ: BURS: PERC: EVM?`

Usage: Query only

Mode: GSM

READ:BURSt[:MACCuracy]:PERCentile:MERRor?

This command starts the measurement and reads out the 95 % percentile of the Magnitude Error measurement taken over the selected number of bursts. When the measurement is started the analyzer is automatically set to single sweep. Further results of the measurement can then be queried without restart of the measurement via the `FETCh:BURSt` subsystem.

Return values:

<Result> numeric value
 Default unit: NONE

Example: `READ: BURS: PERC: MERR?`

Usage: Query only

Mode: GSM

READ:BURSt[:MACCuracy]:PERCentile:PERRor?

This command starts the measurement and reads out the 95 % percentile of the Phase Error measurement taken over the selected number of bursts. When the measurement is started the analyzer is automatically set to single sweep. Further results of the measurement can then be queried without restart of the measurement via the `FEtCh:BURSt` subsystem.

Return values:

<Result> numeric value
 Default unit: NONE

Example: `READ:BURS:PERC:PERR?`

Usage: Query only

Mode: GSM

READ:BURSt[:MACCuracy]:PERRor:PEAK:AVERAge?

This command starts the measurement and reads out the average of the peak measurement of the Phase Error taken over the selected number of bursts. When the measurement is started the analyzer is automatically set to single sweep. Further results of the measurement can then be queried without restart of the measurement via the `FEtCh:BURSt` subsystem.

Return values:

<Result> numeric value
 Average
 Default unit: NONE

Example: `READ:BURS:PERR:PEAK:AVER?`

Usage: Query only

Mode: GSM

READ:BURSt[:MACCuracy]:PERRor:PEAK:CURREnt?

This command starts the measurement and reads out the currently measured peak value of the Phase Error taken over the selected number of bursts. When the measurement is started the analyzer is automatically set to single sweep. Further results of the measurement can then be queried without restart of the measurement via the `FEtCh:BURSt` subsystem.

Return values:

<Result> numeric value
 Currently measured value
 Default unit: NONE

Example: `READ:BURS:PERR:PEAK:CURR?`

Usage: Query only

Mode: GSM

READ:BURSt[:MACCuracy]:PERRor:PEAK:MAXimum?

This command starts the measurement and reads out the maximum of the peak measurement of the Phase Error taken over the selected number of bursts. When the measurement is started the analyzer is automatically set to single sweep. Further results of the measurement can then be queried without restart of the measurement via the `FETCh:BURSt` subsystem.

Return values:

<Result> numeric value
 Maximum
 Default unit: NONE

Example: `READ:BURSt:PEAK:MAX?`

Usage: Query only

Mode: GSM

READ:BURSt[:MACCuracy]:PERRor:PEAK:SDEVIation?

This command starts the measurement and reads out the standard deviation of the peak measurement of the Phase Error taken over the selected number of bursts. When the measurement is started the analyzer is automatically set to single sweep. Further results of the measurement can then be queried without restart of the measurement via the `FETCh:BURSt` subsystem.

Return values:

<Result> numeric value
 Standard deviation
 Default unit: NONE

Example: `READ:BURSt:PEAK:SDEV?`

Usage: Query only

Mode: GSM

READ:BURSt[:MACCuracy]:PERRor:RMS:AVERage?

This command starts the measurement and reads out the average of the RMS measurement of the Phase Error taken over the selected number of bursts. When the measurement is started the analyzer is automatically set to single sweep. Further results of the measurement can then be queried without restart of the measurement via the `FETCh:BURSt` subsystem.

Return values:

<Result> numeric value
 Average
 Default unit: NONE

Example: READ: BURS: PERR: RMS: AVER?

Usage: Query only

Mode: GSM

READ: BURSt[:MACCuracy]: PERRor: RMS: CURRent?

This command starts the measurement and reads out the currently measured RMS value of the Phase Error taken over the selected number of bursts. When the measurement is started the analyzer is automatically set to single sweep. Further results of the measurement can then be queried without restart of the measurement via the `FETCh: BURSt` subsystem.

Return values:

<Result> numeric value
 Currently measured value
 Default unit: NONE

Example: READ: BURS: PERR: RMS: CURR?

Usage: Query only

Mode: GSM

READ: BURSt[:MACCuracy]: PERRor: RMS: MAXimum?

This command starts the measurement and reads out the maximum of the RMS measurement of the Phase Error taken over the selected number of bursts. When the measurement is started the analyzer is automatically set to single sweep. Further results of the measurement can then be queried without restart of the measurement via the `FETCh: BURSt` subsystem.

Return values:

<Result> numeric value
 Maximum
 Default unit: NONE

Example: READ: BURS: PERR: RMS: MAX?

Usage: Query only

Mode: GSM

READ:BURSt[:MACCuracy]:PERRor:RMS:SDEVIation?

This command starts the measurement and reads out the standard deviation of the RMS measurement of the Phase Error taken over the selected number of bursts. When the measurement is started the analyzer is automatically set to single sweep. Further results of the measurement can then be queried without restart of the measurement via the `FETCH:BURSt` subsystem.

Return values:

<Result> numeric value
 Standard deviation
 Default unit: NONE

Example: `READ:BURSt:PERRor:RMS:SDEV?`

Usage: Query only

Mode: GSM

READ:BURSt:PTEMplate:TRGS:AVERAge?

This command starts a "Trigger to Sync" measurement and queries the average time between the external trigger event and the start of the first symbol of the training sequence (midamble) in seconds over the selected number of I/Q captures (see ["Statistic Count"](#) on page 60). This command is only available if an external trigger is selected and the "Trigger to Sync" measurement is active (see [CONFIGure:TRGS\[:IMMEDIATE\]](#) on page 146).

Return values:

<Result> numeric value
 Average
 Default unit: S

Example:

```
// Preset the instrument
*RST
// Enter the GSM option K10
INSTRument:SElect GSM
// Switch to single sweep mode and stop sweep
INITiate:CONTinuous OFF;:ABORT
// Set external trigger more
TRIGger1:SEquence:SOURce EXTernal
// Activate Trigger to Sync measurement
CONFigure:TRGS:IMMediate
// Set minimum capture time to speed up measurement
SENSe1:SWEep:TIME MINimum
// Auto set trigger offset
// Note: Correct frame / slot configuration assumed!
CONFigure:MS:AUTO:TRIGger ONCE
// Note: 'READ' starts a new single sweep and then reads the
results.
// Use 'FETCh' to query several results!
READ:BURSt:PTEMplate:TRGS:AVER?
```

Usage: Query only

Mode: GSM

READ:BURSt:PTEMplate:TRGS:CURRent?

This command starts a "Trigger to Sync" measurement and queries the currently measured time between the external trigger event and the start of the first symbol of the training sequence (midamble) in seconds over the selected number of I/Q captures (see "Statistic Count" on page 60). This command is only available if an external trigger is selected and the "Trigger to Sync" measurement is active (see [CONFigure:TRGS\[:IMMediate\]](#) on page 146).

Return values:

<Result> numeric value
 Currently measured time
 Default unit: S

Example:

```
// Preset the instrument
*RST
// Enter the GSM option K10
INSTrument:SElect GSM
// Switch to single sweep mode and stop sweep
INITiate:CONTinuous OFF;:ABORT
// Set external trigger more
TRIGger1:SEquence:SOURce EXternal
// Activate Trigger to Sync measurement
CONFigure:TRGS:IMMediate
// Set minimum capture time to speed up measurement
SENSe1:SWEep:TIME MINimum
// Note: 'READ' starts a new single sweep and then reads the
// results.
// Use 'FETCh' to query several results!
READ:BURSt:PTEM:TRGS:CURR?
```

Usage: Query only

Mode: GSM

READ:BURSt:PTEMplate:TRGS:MAXimum?

This command starts a "Trigger to Sync" measurement and queries the maximum time between the external trigger event and the start of the first symbol of the training sequence (midamble) in seconds over the selected number of I/Q captures (see ["Statistic Count"](#) on page 60). This command is only available if an external trigger is selected and the "Trigger to Sync" measurement is active (see [CONFigure:TRGS\[:IMMediate\]](#) on page 146).

Return values:

<Result> numeric value
 Maximum
 Default unit: S

Example:

```
// Preset the instrument
*RST
// Enter the GSM option K10
INSTrument:SElect GSM
// Switch to single sweep mode and stop sweep
INITiate:CONTinuous OFF;:ABORT
// Set external trigger more
TRIGger1:SEquence:SOURce EXTernal
// Activate Trigger to Sync measurement
CONFigure:TRGS:IMMediate
// Set minimum capture time to speed up measurement
SENSe1:SWEep:TIME MINimum
// Auto set trigger offset
// Note: Correct frame / slot configuration assumed!
CONFigure:MS:AUTO:TRIGger ONCE
// Note: 'READ' starts a new single sweep and then reads the
results.
// Use 'FETCh' to query several results!
READ:BURS:PTEM:TRGS:MAX?
```

Usage: Query only

Mode: GSM

READ:BURSt:PTEMplate:TRGS:MINimum?

This command starts a "Trigger to Sync" measurement and queries the minimum time between the external trigger event and the start of the first symbol of the training sequence (midamble) in seconds over the selected number of I/Q captures (see ["Statistic Count"](#) on page 60). This command is only available if an external trigger is selected and the "Trigger to Sync" measurement is active (see [CONFigure:TRGS\[:IMMediate\]](#) on page 146).

Return values:

<Result> numeric value
 Minimum
 Default unit: S

Example:

```
// Preset the instrument
*RST
// Enter the GSM option K10
INSTRument:SElect GSM
// Switch to single sweep mode and stop sweep
INITiate:CONTinuous OFF;:ABORT
// Set external trigger more
TRIGger1:SEquence:SOURce EXTernal
// Activate Trigger to Sync measurement
CONFigure:TRGS:IMMediate
// Set minimum capture time to speed up measurement
SENSe1:SWEep:TIME MINimum
// Auto set trigger offset
// Note: Correct frame / slot configuration assumed!
CONFigure:MS:AUTO:TRIGger ONCE
// Note: 'READ' starts a new single sweep and then reads the
results.
// Use 'FETCh' to query several results!
READ:BURSt:PTEM:TRGS:MIN?
```

Usage: Query only

Mode: GSM

READ:BURSt:PTEMplate:TRGS:SDEVIation?

This command starts a "Trigger to Sync" measurement and queries the standard deviation of the time between the external trigger event and the start of the first symbol of the training sequence (midamble) in seconds over the selected number of I/Q captures (see "Statistic Count" on page 60). This command is only available if an external trigger is selected and the "Trigger to Sync" measurement is active (see [CONFigure:TRGS\[:IMMediate\]](#) on page 146).

Return values:

<Result> numeric value
 Standard deviation
 Default unit: S

Example:

```
// Preset the instrument
*RST
// Enter the GSM option K10
INSTrument:SElect GSM
// Switch to single sweep mode and stop sweep
INITiate:CONTinuous OFF;;ABORT
// Set external trigger more
TRIGger1:SEquence:SOURce EXTernal
// Activate Trigger to Sync measurement
CONFigure:TRGS:IMMediate
// Set minimum capture time to speed up measurement
SENSe1:SWEep:TIME MINimum
// Auto set trigger offset
// Note: Correct frame / slot configuration assumed!
CONFigure:MS:AUTO:TRIGger ONCE
// Note: 'READ' starts a new single sweep and then reads the
results.
// Use 'FETCh' to query several results!
READ:BURS:PTEM:TRGS:SDEV?
```

Usage: Query only

Mode: GSM

READ:BURSt:SPOWer:SLOT<Slot>:ALL:AVERAge?

This command starts the measurement and reads out the average power for the selected slot for all measured burst.

This command is only available if "Power vs Time" measurement is selected (see [CONFigure:BURSt:PTEMplate\[:IMMediate\]](#) on page 137).

Suffix:

<Slot> <0..7>
 Slot number to measure power on. The selected slot s must be within the slot scope, i.e. (First slot to measure) \leq s \leq (First slot to measure + Number of Slots to measure - 1).

Return values:

<Result> numeric value
 Average
 Default unit: dBm

Example:

```

\\ Preset the instrument
*RST
\\ Enter the GSM option K10
INSTrument:SElect GSM
\\ Switch to single sweep mode and stop sweep
INITiate:CONTinuous OFF;;ABORT
\\ Set the slot scope: Use all 8 slots for the PvT measurement.
\\ Number of slots to measure = 8
CONFigure:MS:CHANnel:MSLots:NOFSlots 8
\\ First Slot to measure = 0
CONFigure:MS:CHANnel:MSLots:OFFSet 0
\\ Activate PvT (Power vs Time) measurement
CONFigure:BURSt:PTEMplate:IMMediate
\\ Note: 'READ' starts a new single sweep and then reads the
results. Please use 'FETCh' to query several results!
READ:BURSt:SPOWer:SLOT1:ALL:AVERAge?

```

Usage: Query only

Mode: GSM

READ:BURSt:SPOWer:SLOT<Slot>:ALL:CRESt?

This command starts the measurement and reads out the crest factor for the selected slot for all measured burst.

This command is only available if "Power vs Time" measurement is selected (see [CONFigure:BURSt:PTEMplate\[:IMMediate\]](#) on page 137).

Suffix:

<Slot> <0..7>
Slot number to measure power on. The selected slot s must be within the slot scope, i.e. $(\text{First slot to measure}) \leq s \leq (\text{First slot to measure} + \text{Number of Slots to measure} - 1)$.

Return values:

<Result> numeric value
Crest factor
Default unit: dB

Example:

```

\\ Preset the instrument
*RST
\\ Enter the GSM option K10
INSTrument:SElect GSM
\\ Switch to single sweep mode and stop sweep
INITiate:CONTinuous OFF;;ABORT
\\ Set the slot scope: Use all 8 slots for the PvT measurement.
\\ Number of slots to measure = 8
CONFigure:MS:CHANnel:MSLots:NOFSlots 8
\\ First Slot to measure = 0
CONFigure:MS:CHANnel:MSLots:OFFSet 0
\\ Activate PvT (Power vs Time) measurement
CONFigure:BURSt:PTEMplate:IMMediate
\\ Note: 'READ' starts a new single sweep annd then reads the
results. Please use 'FETCh' to query several results!
READ:BURSt:SPOWer:SLOT1:ALL:CRESt?

```

Usage: Query only

Mode: GSM

READ:BURSt:SPOWer:SLOT<Slot>:ALL:MAXimum?

This command starts the measurement and reads out the maximum power for the selected slot for all measured burst.

This command is only available if "Power vs Time" measurement is selected (see [CONFigure:BURSt:PTEMplate\[:IMMediate\]](#) on page 137).

Suffix:

<Slot> <0..7>
Slot number to measure power on. The selected slot s must be within the slot scope, i.e. (First slot to measure) \leq s \leq (First slot to measure + Number of Slots to measure - 1).

Return values:

<Result> numeric value
Maximum
Default unit: dBm

Example:

```

\\ Preset the instrument
*RST
\\ Enter the GSM option K10
INSTRument:SElect GSM
\\ Switch to single sweep mode and stop sweep
INITiate:CONTinuous OFF;;ABORT
\\ Set the slot scope: Use all 8 slots for the PvT measurement.
\\ Number of slots to measure = 8
CONFigure:MS:CHANnel:MSLots:NOFSlots 8
\\ First Slot to measure = 0
CONFigure:MS:CHANnel:MSLots:OFFSet 0
\\ Activate PvT (Power vs Time) measurement
CONFigure:BURSt:PTEMplate:IMMediate
\\ Note: 'READ' starts a new single sweep and then reads the
results. Please use 'FETCh' to query several results!
READ:BURSt:SPOWer:SLOT1:ALL:MAXimum?

```

Usage: Query only

Mode: GSM

READ:BURSt:SPOWer:SLOT<Slot>:CURRent:AVERAge?

This command starts the measurement out the average power for the selected slot for the current burst. This command is only available when the Power vs Time measurement is selected (see [CONFigure:BURSt:PTEMplate\[:IMMediate\]](#) on page 137).

Suffix:

<Slot> <0..7>
Slot number to measure power on. The selected slot s must be within the slot scope, i.e. (First slot to measure) \leq s \leq (First slot to measure + Number of Slots to measure - 1).

Return values:

<Result> numeric value
Average
Default unit: dBm

Example:

```

\\ Preset the instrument
*RST
\\ Enter the GSM option K10
INSTrument:SElect GSM
\\ Switch to single sweep mode and stop sweep
INITiate:CONTinuous OFF;;ABORT
\\ Set the slot scope: Use all 8 slots for the PvT measurement.
\\ Number of slots to measure = 8
CONFigure:MS:CHANnel:MSLots:NOFSlots 8
\\ First Slot to measure = 0
CONFigure:MS:CHANnel:MSLots:OFFSet 0
\\ Activate PvT (Power vs Time) measurement
CONFigure:BURSt:PTEMplate:IMMediate
\\ Note: 'READ' starts a new single sweep and then reads the
results. Please use 'FETCh' to query several results!
READ:BURSt:SPOWer:SLOT1:CURRent:AVERAge?

```

Usage: Query only

Mode: GSM

READ:BURSt:SPOWer:SLOT<Slot>:CURRent:CRESt?

This command starts the measurement out the crest factor for the selected slot for the current burst. This command is only available when the "Power vs Time" measurement is selected (see [CONFigure:BURSt:PTEMplate\[:IMMediate\]](#) on page 137).

Suffix:

<Slot> <0..7>
Slot number to measure power on. The selected slot s must be within the slot scope, i.e. (First slot to measure) \leq s \leq (First slot to measure + Number of Slots to measure - 1).

Return values:

<Result> numeric value
Crest factor
Default unit: dB

Example:

```

\\ Preset the instrument
*RST
\\ Enter the GSM option K10
INSTrument:SElect GSM
\\ Switch to single sweep mode and stop sweep
INITiate:CONTinuous OFF;:ABORT
\\ Set the slot scope: Use all 8 slots for the PvT measurement.
\\ Number of slots to measure = 8
CONFigure:MS:CHANnel:MSLots:NOFSlots 8
\\ First Slot to measure = 0
CONFigure:MS:CHANnel:MSLots:OFFSet 0
\\ Activate PvT (Power vs Time) measurement
CONFigure:BURSt:PTEMplate:IMMediate
\\ Note: 'READ' starts a new single sweep and then reads the
results. Please use 'FETCh' to query several results!
READ:BURSt:SPOWer:SLOT1:CURRent:CRESt?

```

Usage: Query only

Mode: GSM

READ:BURSt:SPOWer:SLOT<Slot>:CURRent:MAXimum?

This command starts the measurement out the maximum power for the selected slot for the current burst. This command is only available when the Power vs Time measurement is selected (see [CONFigure:BURSt:PTEMplate\[:IMMediate\]](#) on page 137).

Suffix:

<Slot> <0..7>
Slot number to measure power on. The selected slot s must be within the slot scope, i.e. (First slot to measure) \leq s \leq (First slot to measure + Number of Slots to measure - 1).

Return values:

<Result> numeric value
Maximum
Default unit: dBm

Example:

```

\\ Preset the instrument
*RST
\\ Enter the GSM option K10
INSTRument:SElect GSM
\\ Switch to single sweep mode and stop sweep
INITiate:CONTinuous OFF;;ABORT
\\ Set the slot scope: Use all 8 slots for the PvT measurement.
\\ Number of slots to measure = 8
CONFigure:MS:CHANnel:MSLots:NOFSlots 8
\\ First Slot to measure = 0
CONFigure:MS:CHANnel:MSLots:OFFSet 0
\\ Activate PvT (Power vs Time) measurement
CONFigure:BURSt:PTEMplate:IMMediate
\\ Note: 'READ' starts a new single sweep and then reads the
results. Please use 'FETCh' to query several results!
READ:BURSt:SPOWer:SLOT1:CURRent:MAXimum?

```

Usage: Query only

Mode: GSM

READ:BURSt:SPOWer:SLOT<Slot>:DELtatOsync?

This command starts the measurement of the "Delta to Sync" value for the selected slot (see [chapter 3.1.8, "Power vs Time"](#), on page 20). This command is only available when the "Power vs Time" measurement is selected (see [CONFigure:BURSt:PTEMplate\[:IMMediate\]](#) on page 137).

Suffix:

<Slot> <0..7>
Slot number to measure power on. The selected slot must be within the slot scope, i.e.
 $(\text{First slot to measure}) \leq \text{<slot>} \leq (\text{First slot to measure} + \text{Number of Slots to measure} - 1)$.

Return values:

<Result> numeric value
Default unit: dBm

Example:

```

\\ Preset the instrument
RST
\\ Enter the GSM option K10
INSTrument:SElect GSM
\\ Switch to single sweep mode and stop sweep
INITiate:CONTinuous OFF;;ABORT
\\ Set the slot scope: Use all 8 slots for the PvT measurement.
\\ Number of slots to measure = 8
CONFigure:MS:CHANnel:MSLots:NOFSlots 8
\\ First Slot to measure = 0
CONFigure:MS:CHANnel:MSLots:OFFSet 0
\\ Activate PvT (Power vs Time) measurement
CONFigure:BURSt:PTEmplate:IMMediate
\\Note: READ starts a new single sweep and then reads the
results. Use FETCh to query several results.
READ:BURSt:SPOWer:SLOT1:DELTAtosync?

```

Usage: Query only

Mode: GSM

4.11.2 READ:SPECTrum subsystem

Commands of the READ:SPECTrum subsystem

READ:BURSt[:MACCuracy]:ALL.....	231
READ:SPECTrum:MODulation[:ALL].....	232
READ:SPECTrum:MODulation:REFerence[:IMMediate].....	232
READ:SPECTrum:SWITChing[:ALL].....	233
READ:SPECTrum:SWITChing:REFerence[:IMMediate].....	234
READ:SPECTrum:WMODulation:GATing (obsolete).....	234

READ:BURSt[:MACCuracy]:ALL

This command starts the measurement and returns all the results. When the measurement is started the analyzer is automatically set to single sweep.

Further results of the measurement can then be queried without restart of the measurement via the FETCh:BURSt subsystem.

Return values:

<MeasValue> <Error Vector Magnitude RMS>, <Error Vector Magnitude Peak>, <Magnitude Error RMS>, <Magnitude Error Peak>, <Phase Error RMS>, <Phase Error Peak>, <Burst Power>, <Frequency Error>, <IQ Offset>, <IB Imbalance>

The results are output as a list of comma separated strings. Each item consists of an Average, Current, Maximum and Standard Deviation value.

Example: READ:BURSt:ALL?

Mode: GSM

READ:SPECTrum:MODulation[:ALL]

This command starts the measurement and returns the result of the measured modulation spectrum of the mobile or base station. This command is only available when the "Modulation Spectrum" measurement is selected (see [CONFigure:SPECTrum:MODulation\[:IMMediate\]](#) on page 141).

The result is a list of partial result strings separated by commas.

Return values:

<Placeholder>	currently irrelevant
<Freq1>	Absolute offset frequency in Hz
<Freq2>	Absolute offset frequency in Hz
<Level>	Measured level at the offset frequency in dB or dBm (depending on CONF:WSP:MOD:LIM).
<Limit>	Limit at the offset frequency in dB or dBm (depending on CONF:WSP:MOD:LIM).
<Abs/Rel>	Indicates whether relative (dB) or absolute (dBm) limit and level values are returned (depending on CONF:WSP:MOD:LIM).
<Status>	Result of the limit check in character data form PASSED no limit exceeded FAILED limit exceeded

Example: READ:SPEC:MOD?
0,998200000,998200000,-84.61,-56.85,REL,PASSED,
0,998400000,998400000,-85.20,-56.85,REL,PASSED,

Mode: GSM

READ:SPECTrum:MODulation:REFerence[:IMMediate]?

This command starts the measurement and returns the measured reference power of the "Modulation Spectrum". This command is only available when the "Modulation Spectrum" measurement is selected (see [CONFigure:SPECTrum:MODulation\[:IMMediate\]](#) on page 141).

The result is a list of partial result strings separated by commas.

Return values:

<Level1>	measured reference power in dBm
<Level2>	measured reference power in dBm
<RBW>	resolution bandwidth used to measure the reference power in Hz

Example:	READ:SPECTrum:MODulation:REference:IMMediate?
Usage:	Query only
Mode:	GSM

READ:SPECTrum:SWITching[:ALL]?

This command starts the measurement and reads out the result of the measurement of the transient spectrum. This command is only available when the transient spectrum measurement is selected (see [CONFigure:SPECTrum:SWITching\[:IMMediate\]](#) on page 144).

The result is a list of partial result strings separated by commas.

Return values:

<Placeholder>	currently irrelevant
<Freq1>	Absolute offset frequency in Hz
<Freq2>	Absolute offset frequency in Hz
<Level>	Measured level at the offset frequency in dB or dBm. For more information see CONFigure:SPECTrum:SWITching:LIMIT .
<Limit>	Limit at the offset frequency in dB or dBm For more information see CONFigure:SPECTrum:SWITching:LIMIT .
<Abs/Rel>	Indicates whether relative (dB) or absolute (dBm) limit and level values are returned. For more information see CONFigure:SPECTrum:SWITching:LIMIT .
<Status>	Result of the limit check in character data form PASSED no limit exceeded FAILED limit exceeded

Example:	READ:SPEC:SWIT? 0,998200000,998200000,-84.61,-56.85,REL,PASSED, 0,998400000,998400000,-85.20,-56.85,REL,PASSED,
Usage:	Query only
Mode:	GSM

READ:SPECTrum:SWITching:REFerence[:IMMediate]

This command starts the measurement and returns the measured reference power of the "Transient Spectrum". This command is only available when the "Transient Spectrum" measurement is selected (see [CONFigure:SPECTrum:SWITching\[:IMMediate\]](#) on page 144).

The result is a list of partial result strings separated by commas.

Return values:

<Level1> measured reference power in dBm
 <Level2> measured reference power in dBm
 <RBW> resolution bandwidth used to measure the reference power in Hz

Example: READ:SPECTrum:SWITching:REFerence:IMMediate?

Mode: GSM

READ:SPECTrum:WMOdulation:GATing (obsolete)

This command reads out the gating settings for gated Wide Modulation Spectrum measurements. It is identical to [READ:SPECTrum:WMOdulation:GATing \(obsolete\)](#) and is maintained for compatibility reasons only.

Example: READ:SPEC:WMOD:GAT?

Mode: GSM

4.11.3 READ:WSPectrum subsystem**Commands of the READ:WSPectrum subsystem**

[READ:WSPectrum:MOdulation\[:ALL\]](#).....234
[READ:WSPectrum:MOdulation:GATing](#).....235
[READ:WSPectrum:MOdulation:REFerence\[:IMMediate\]](#).....236

READ:WSPectrum:MOdulation[:ALL]?

This command starts the measurement and reads out the result of the measurement of the "Wide Modulation Spectrum" of the mobile or base station. This command is only available when the wide modulation spectrum measurement is selected (see [CONFigure:WSPectrum:MOdulation\[:IMMediate\]](#) on page 146).

The result is a list of partial result strings separated by commas.

Return values:

<Placeholder> curently irrelevant
 <Freq1> Absolute offset frequency in Hz
 <Freq2> Absolute offset frequency in Hz

<Level>	Measured level at the offset frequency in dB or dBm.
<Limit>	Limit at the offset frequency in dB or dBm.
<Abs/Rel>	Indicates whether relative (dB) or absolute (dBm) limit and level values are returned.
<Status>	Result of the limit check in character data form PASSED no limit exceeded FAILED limit exceeded
Example:	<pre> READ:WSP:MOD? 0,998200000,998200000,-84.61,-56.85,REL,PASSED, 0,998400000,998400000,-85.20,-56.85,REL,PASSED, ... </pre>
Usage:	Query only
Mode:	GSM

READ:WSPpectrum:MODulation:GATing?

This command reads out the gating settings for gated "Modulation Spectrum" or "Wide Modulation Spectrum" measurements (see [chapter 3.1.9, "Modulation Spectrum"](#), on page 23 and [chapter 3.1.11, "Wide Modulation Spectrum"](#), on page 27).

The returned values can be used to set the gating interval for "list" measurements (i.e. a series of measurements in zero span mode at several offset frequencies). This is done in the "Spectrum" mode using the `SENSe:LIST` subsystem (see `[SENSe:]LIST:POWer:SET`).

Prior to this command make sure you set the correct Trigger Mode ("IF power" or "External") and Trigger Offset (in the "General Settings" dialog, see ["General Settings"](#) on page 56). The "Trigger Offset" can be determined using the "Auto Set" (Trigger) functionality of the R&S FSV-K10.

Return values:

<TriggerOffset>	Calculated trigger offset, based on the user-defined "Trigger Offset" and "Frame Configuration", such that 50-90% of the active part of the "Slot to measure" (excluding TSC) is measured.
<GateLength>	Calculated gate length, based on the user-defined "Trigger Offset" and "Frame Configuration", such that 50-90% of the active part of the "Slot to measure" (excluding TSC) is measured.

Example:	<code>READ:WSP:MOD:GAT?</code>
Usage:	Query only
Mode:	GSM

READ:WSPectrum:MODulation:REference[:IMMEDIATE]

This command starts the measurement and returns the measured reference power of the "Wide Modulation Spectrum". This command is only available when the "Wide Modulation Spectrum" measurement is selected (see [CONFigure:WSPectrum:MODulation\[:IMMEDIATE\]](#) on page 146).

The result is a list of partial result strings separated by commas.

Return values:

<Level1>	measured reference power in dBm
<Level2>	measured reference power in dBm
<RBW>	resolution bandwidth used to measure the reference power in Hz

Example: READ:WSPectrum:MODulation:REference:IMMEDIATE?

Mode: GSM

4.12 SENSe Subsystem

The SENSe subsystem is organized in several subsystems. The commands of these subsystems directly control device-specific settings, they do not refer to the signal characteristics of the measurement signal. The SENSe subsystem controls the essential parameters of the analyzer. In accordance with the SCPI standard, the keyword SENSe is optional for this reason, which means that it is not necessary to include the SENSe node in command sequences.

The following subsystems are included:

Commands of the SENSe subsystem:

[SENSe]:BANDwidth[:RESolution]:TYPE	236
[SENSe]:BURSt:COUNt	237
[SENSe:]FREQuency:CENTer	237
[SENSe:]FREQuency:OFFSet	237
[SENSe:]SWAPiq	238
[SENSe:]SWEep:COUNt	238
[SENSe:]SWEep:COUNt:CURRent	238
[SENSe:]SWEep:TIME	239

[SENSe]:BANDwidth[:RESolution]:TYPE <Type>

This command switches the filter type for the resolution filter for the "Modulation Spectrum", "Transient Spectrum" and "Wide Modulation Spectrum" measurement.

Parameters for setting and query:

<Type> NORMal | P5

NORMal

Gaussian filter with a 3 dB bandwidth of either 30 kHz or 100 kHz.
This value is retained for compatibility with R&S FS-K5 only.

P5

5 Pole filter with a 3 dB bandwidth of either 30 kHz or 100 kHz.
This filter is required by the GSM standard specification.

*RST: P5

Example: BAND:TYPE NORM**Mode:** GSM**[SENSe]:BURSt:COUnT <Count>**

The remote control command is used to specify the number of measurements to be averaged. This command is synonymous with [\[SENSe:\]SWEp:COUnT](#) on page 238.

Parameters for setting and query:

<Count> numeric value

Target statistic count, i.e. number of measurements to be averaged.

*RST: 200

Default unit: NONE

Example: BURSt:COUnT 5**Mode:** GSM**[SENSe:]FREQuency:CENTer <Frequency>**

This command defines the center frequency of the analyzer or the measuring frequency for span = 0.

If the frequency is modified, the "ARFCN" is updated accordingly.

Parameters:<Frequency> Range: 0 to f_{max}*RST: f_{max}/2

Default unit: Hz

f_{max} is specified in the data sheet. min span is 10 Hz**Example:** FREQ:CENT 100 MHz**Mode:** all**[SENSe:]FREQuency:OFFSet <Offset>**

This command defines the frequency offset of the instrument.

Parameters:

<Offset> Range: -100 GHz to 100 GHz
 *RST: 0 Hz

Example: `FREQ:OFFS 1GHZ`

Mode: all

[SENSe:]SWAPiQ <State>

This command defines whether or not the recorded IQ pairs should be swapped (I<->Q) before being processed. Swapping I and Q inverts the sideband.

Try this function if the TSC can not be found.

Parameters:

<State> ON | OFF
 ON
 I and Q are exchanged, inverted sideband, Q+j*I
 OFF
 Normal sideband, I+j*Q,
 *RST: OFF

Example: `SWAP ON`
 Specifies that IQ values should be swapped.

Mode: WLAN, GSM, OFDM, OFDMA/WiBro

[SENSe:]SWEep:COUNT <NumberSweeps>

This command defines the number of sweeps started with single sweep, which are used for calculating the average or maximum value. If the values 0 or 1 are set, one sweep is performed.

Parameters:

<NumberSweeps> 0 to 32767
 *RST: 0 (GSM: 200, PHN:1)

Example: `SWE:COUN 64`
 Sets the number of sweeps to 64.
 `INIT:CONT OFF`
 Switches to single sweep mode.
 `INIT;*WAI`
 Starts a sweep and waits for its end.

Mode: A, ADEMOD, BT, CDMA, EVDO, PHN, TDS, WCDMA, GSM, NF

[SENSe:]SWEep:COUNT:CURRent?

This command returns the current [Statistic Count](#). It can be used to track the progress of the averaging progress until it reaches the set "Statistic Count" (see [\[SENSe:\]SWEep:COUNT](#) on page 238).

Usage: Query only
Mode: A, BT, ADEMOD, TDS, GSM

[SENSe:]SWEep:TIME <Time>

This command defines the sweep time.

The range depends on the frequency span.

Parameters:

<Time> refer to data sheet
 *RST: (AUTO is set to ON)

Example: SWE:TIME 10s

Mode: ALL

4.13 STATus Subsystem

The STATus subsystem contains the commands for the status reporting system (for details refer to [chapter 5, "Status Reporting System"](#), on page 248). *RST does not influence the status registers.

4.13.1	Commands of the STATus subsystem.....	239
4.13.2	STATus:QUESTIONable Subsystem.....	240

4.13.1 Commands of the STATus subsystem

STATus:OPERation[:EVENT]

This command queries the contents of the EVENT section of the STATus:OPERation register. The contents of the EVENT section are deleted after readout.

Example: STAT:OPER?

Mode: all

STATus:OPERation:CONDition

This command queries the CONDition section of the STATus:OPERation register (see the base unit description of status registers in the Remote Control Basics chapter).

Readout does not delete the contents of the CONDition section. The value returned reflects the current hardware status.

Example: STAT:OPER:COND?

Mode: all

4.13.2 STATus:QUESTionable Subsystem

This subsystem queries the information in the status reporting system. For details see [chapter 5, "Status Reporting System"](#), on page 248.

STATus:QUESTionable:SYNC[:EVENT].....	240
STATus:QUESTionable:SYNC:CONDition.....	240
STATus:QUESTionable:SYNC:ENABle.....	240
STATus:QUESTionable:SYNC:NTRansition.....	241
STATus:QUESTionable:SYNC:PTRansition.....	241

STATus:QUESTionable:SYNC[:EVENT]?

This command queries the contents of the EVENT section of the STATus:QUESTionable:SYNC:EVENT? register. Readout deletes the contents of the EVENT section.

For details on possible events see [chapter 5, "Status Reporting System"](#), on page 248.

Example: STAT:QUES:SYNC

Usage: Query only

Mode: GSM

STATus:QUESTionable:SYNC:CONDition?

This command queries the contents of the CONDition section of the STATus:QUESTionable:SYNC:CONDition? register. Readout deletes the contents of the CONDition section.

Example: STAT:QUES:SYNC:COND?

Usage: Query only

Mode: GSM

STATus:QUESTionable:SYNC:ENABle <RegisterContent>

This command sets the bits of the ENABle section of the STATus:QUESTionable:SYNC:ENABle register for screen A and B. The ENABle register selectively enables the individual events of the associated EVENT section for the summary bit.

Parameters for setting and query:

<RegisterContent> numeric value
 Content of the specific aspect of the status register
 *RST: 65535

Mode: GSM

STATus:QUESTionable:SYNC:NTRansition <RegisterContent>

This command determines what bits in the `STATus:QUESTionable:SYNC:NTRansition:CONDition` register will set the corresponding bit in the `STATus:QUESTionable:SYNC:NTRansition:EVENT` register when that bit has a negative transition (1 to 0). The parameter is the sum of the decimal values of the bits that are to be enabled.

Parameters for setting and query:

<RegisterContent> numeric value
Content of the specific aspect of the status register

*RST: 0

Mode: GSM

STATus:QUESTionable:SYNC:PTRansition <RegisterContent>

This command determines what bits in the `STATus:QUESTionable:SYNC:PTRansition:CONDition` register will set the corresponding bit in the `STATus:QUESTionable:SYNC:PTRansition:EVENT` register when that bit has a positive transition (0 to 1). The parameter is the sum of the decimal values of the bits that are to be enabled.

Parameters for setting and query:

<RegisterContent> numeric value
Content of the specific aspect of the status register

*RST: 65535

Mode: GSM

4.14 TRACe Subsystem

The TRACe subsystem controls access to the instruments internal trace memory.

TRACe[:DATA]? <TraceNumber>

This command reads trace data out of the instrument. The returned values are scaled in the current level unit. In ASCII format, a list of values separated by commas is returned (Comma Separated Values = CSV).

Query parameters:

<TraceNumber> TRACe1 | TRACe2 | TRACe3 | TRACe4

Trace name to be read out

TRACe1

Average trace; (transient spectrum: Maximum trace)

TRACe2

Maximum trace

TRACe3

Minimum trace

TRACe4

Current trace

Example:

TRAC1:DATA? TRACe1

Usage:

Query only

Mode:

GSM

TRACe[:DATA]:X? <TraceNumber>

This command reads the x-values (time in seconds) of the "Power vs Time" measurement (if active).

If a trace number is defined as a parameter for this command, the x-values (time in seconds) of the "Trigger to Sync" measurement (if active) are returned.

Query parameters:

<TraceNumber> TRACe1 | TRACe2 | TRACe3 | TRACe4

Trace number

TRACe1

Average trace; (Transient Spectrum: Maximum trace, Trigger to Sync: histogram values)

TRACe2

Maximum trace (Trigger to Sync: PDF of average trace)

TRACe3

Minimum trace

TRACe4

Current trace

Example:

TRACe:DATA:X?

Returns the Power vs Time values for the active trace.

TRACe:DATA:X? TRACe1

Returns the Trigger to Sync values for trace 1.

Usage:

Query only

Mode:

GSM

TRACe<n>:IQ:DATA:MEMory <OffsetSamples>, <NoOfSamples>

Returns the captured I/Q data.

Note: The data can be only queried if the measurement is not running.

Query parameters:

<OffsetSamples> The offset of the values to be read related to the start of the captured I/Q data.

<NoOfSamples> The number of samples to be read.

Return values:

<Result> a comma separated list of values in floating point format (Comma Separated Values = CSV). The number of values returned is 2 * "# of samples", the first half being the I-values, the second half the Q-values.

The result values are scaled linearly in Volt and correspond to the voltage at the RF input of the instrument.

Default unit: Volt

Mode: GSM

4.15 TRIGger Subsystem

The TRIGger subsystem is used to synchronize instrument actions with events. It is thus possible to control and synchronize the start of a sweep.

TRIGger<n>[:SEQuence]:HOLDoff[:TIME]	243
TRIGger<n>[:SEQuence]:LEVel[:EXTErnal]	244
TRIGger<n>[:SEQuence]:LEVel:IFPower	244
TRIGger<n>[:SEQuence]:MASK:CONDition	244
TRIGger<n>[:SEQuence]:SOURce	245
TRIGger<n>[:SEQuence]:SYNChronize:ADJust:AUTO	245
TRIGger<n>[:SEQuence]:SYNChronize:ADJust:EXTErnal	246
TRIGger<n>[:SEQuence]:SYNChronize:ADJust:IFPower	246
TRIGger<n>[:SEQuence]:SYNChronize:ADJust:IMMEDIATE	247
TRIGger<n>[:SEQuence]:SYNChronize:ADJust:RFPower	247

TRIGger<n>[:SEQuence]:HOLDoff[:TIME] <TriggerOffset>

Specifies the time offset between the trigger event (e.g. for an external or power trigger) and the frame start of the GSM signal in seconds.

Suffix:

<n> <1|2>

Parameters for setting and query:

<TriggerOffset> numeric value

*RST: 0

Default unit: S

Example: TRIG:HOLD 1ms

Mode: GSM

TRIGger<n>[:SEQuence]:LEVel[:EXTernal] <Level>

This command sets the level of the external trigger source.

Suffix:

<n> <1|2>

Parameters for setting and query:

<Level> numeric value
External trigger level
*RST: 1.4 V
Default unit: V

Example: TRIG:LEV:EXT 1 MV

Mode: GSM

TRIGger<n>[:SEQuence]:LEVel:IFPower <TriggerLevel>

This command sets the level of the IF power trigger source.

Suffix:

<n> irrelevant

Parameters:

<TriggerLevel> -50 to +20 DBM
*RST: -20 DBM

Example: TRIG:LEV:IFP -30DBM

Mode: All

TRIGger<n>[:SEQuence]:MASK:CONDition <Condition>

This command sets the condition that activates the frequency mask trigger.

Parameters:

<Condition>

ENTer

Triggers on entering the frequency mask.

LEAVing

Triggers on leaving the frequency mask.

INSide

The trigger is active as long as the signal is inside the frequency mask.

OUTSide

The trigger is active as long as the signal is outside the frequency mask.

*RST: INSide

Example: See [chapter 4.3.3, "CALCulate:MASK Subsystem"](#), on page 98.

Mode: RT

TRIGger<n>[:SEQuence]:SOURce <Source>

This command selects the trigger source for the start of a sweep.

For details on trigger modes refer to the "Trg/Gate Source" softkey in the base unit description.

Suffix:

<n> irrelevant

Parameters:

<Source>

EXTernal | IFPower | IMMEDIATE | MASK | TIME | VIDEO

Note that the availability of the trigger source depends on the measurement you are in.

EXTernal

Selects an external trigger.

IFPower

Selects the trigger on the second intermediate frequency.

IMMEDIATE

Selects the free run mode (= no trigger).

MASK

Selects the frequency mask trigger.

TDTRigger

Selects the time domain trigger.

TIME

Selects the time trigger.

VIDEO

Selects the video trigger. The video trigger is available for time domain measurements.

*RST: IMMEDIATE

Example: TRIG:SOUR EXT

Selects the external trigger input as source of the trigger signal

Mode: ALL

TRIGger<n>[:SEQuence]:SYNChronize:ADJust:AUTO <Value>

This command is identical to [CONFigure\[:MS\]:AUTO:TRIGger](#) on page 107 and is maintained for compatibility reasons only.

Suffix:

<n> <1|2>

Parameters for setting and query:

<Value> OFF | ON | ONCE
 *RST: ON

Mode: GSM

TRIGger<n>[:SEquence]:SYNChronize:ADJust:EXTernal <TriggerDelay>

This command is a combination of 2 commands: Firstly, the "External" GSM trigger is selected. For all GSM measurements requiring a trigger signal and for which an external trigger is possible, the "EXTernal" trigger setting is used. If an external trigger is not possible, the "IMMediate" trigger setting is used.

Secondly, the correction value for the time offset of the external trigger from the beginning of the first active slot is defined. This correction value is needed in order to establish an exact time reference between the trigger event and the beginning of the slot if there is no midamble triggering.

Suffix:

<n> <1|2>

Parameters for setting and query:

<TriggerDelay> numeric value
 *RST: 0 s
 Default unit: S

Example: TRIG:SYNC:ADJ:EXT 1 MS

Mode: GSM

TRIGger<n>[:SEquence]:SYNChronize:ADJust:IFPower <TriggerDelay>

This command is a combination of 2 commands: Firstly, the "Power" GSM trigger is selected. For all GSM measurements for which an IF power trigger is possible, the "IFPower" trigger setting is used. If an IF power trigger is not possible, the "IMMediate" trigger setting is used.

Secondly, the correction value for the time offset of the IF power trigger from the beginning of the first active slot is defined. This correction value is needed in order to establish an exact time reference between the trigger event and the beginning of the slot if there is no midamble triggering.

Suffix:

<n> <1|2>

Parameters for setting and query:

<TriggerDelay> numeric value
 *RST: 0 s
 Default unit: S

Example: TRIG:SYNC:ADJ:IFP 1 MS

Mode: GSM

TRIGger<n>[:SEquence]:SYNChronize:ADJust:IMMEDIATE

This command selects the FREE RUN GSM trigger.

Suffix:

<n> <1|2>

Example: TRIG:SYNC:ADJ:IMM

Usage: Setting only

Mode: GSM

TRIGger<n>[:SEquence]:SYNChronize:ADJust:RFPower <TriggerDelay>

This command is a combination of 2 commands: Firstly, the "Power" GSM trigger is selected. For all GSM measurements for which an RF power trigger is possible, the "RFPower" trigger setting is used. If an RF power trigger is not possible, the "IMMEDIATE" trigger setting is used.

Secondly, the correction value for the time offset of the RF power trigger from the beginning of the first active slot is defined. This correction value is needed in order to establish an exact time reference between the trigger event and the beginning of the slot if there is no midamble triggering.

Suffix:

<n> <1|2>

Parameters for setting and query:

<TriggerDelay> numeric value
 *RST: 0 s
 Default unit: S

Example: TRIG:SYNC:ADJ:RFP 1 MS

Mode: GSM

5 Status Reporting System

In addition to the registers provided by the base system, the following register is used in the GSM option (R&S FSV-K10): `STAT:QUES:SYNC`. Although this register is provided by the base system, the GSM option (R&S FSV-K10) uses different bits and definitions.

In this section, only the new and altered status registers/bits for the GSM option (R&S FSV-K10) are described. Detailed information on the status registers of the base system is given in the section "Status Reporting System" in chapter 5 of the Operating Manual on CD.

The status reporting system stores all information on the current operating state of the instrument, e.g. that the instrument is currently performing a calibration and information on errors which have occurred. This information is stored in the status registers and in the error queue. The status registers and the error queue can be queried via IEC bus.

The information is structured hierarchically. The register *status byte* (STB) defined in IEEE 488.2 and its associated mask register *service request enable* (SRE) form the uppermost level. The STB receives its information from the standard *event status register* (ESR) which is also defined in IEEE 488.2 with the associated mask register *standard event status enable* (ESE). The STB registers `STATus:OPERation` and `STATus:QUESTIONable`, which are defined by SCPI and contain detailed information on the instrument.

The *Individual Status* flag (IST) and the *parallel poll enable* register (PPE) allocated to it are also part of the status reporting system. The IST flag, like the SRQ, combines the entire instrument status in a single bit. The PPE fulfils the same function for the IST flag as the SRE for the service request.

The output buffer contains the messages the instrument returns to the controller. It is not part of the status reporting system, but determines the value of the MAV bit in the STB.

Description of the Status Registers

All the status registers are the same as those provided by the base system, with the exception of the following:

- `STATus:OPERation` – Although this register is provided by R&S FSVR Kernel main, R&S FSV-K10 makes use of bits in this register which are not used within R&S FSVR Kernel main
- `STATus:QUES:SYNC` - Although this register is provided by the base system, the GSM option (R&S FSV-K10) uses different bits and definitions.
- `STATus:QUES:LIMit` - This register is provided by the base system; however, in the GSM option (R&S FSV-K10), there is only 1 limit register combining all displayed limits. (Limit lines are only available in screen A, which displays the traces, while screen B displays the measurement results as a list.)

The deviations from the status register structure of the base system are described below.

STATus:OPERation Register

In the CONDition part, this register contains information on which actions the instrument is being executing or, in the EVENT part, information on which actions the instrument has

executed since the last reading. It can be read using commands `STATUS:OPERation:CONDition` or `STATUS:OPERation[:EVENT]`.

Bit No	Meaning
0	CALibrating This bit is set as long as the instrument is performing a calibration.
1 to 3	These bits are not used
4	MEASuring A "1" in this bit position indicates that a measurement is in progress. R&S FSV-K10 only
5 to 7	These bits are not used
8	HardCOPy in progress This bit is set while the instrument is printing a hardcopy.
9 to 14	These bits are not used
15	This bit is always 0

STATUS:QUESTIONable Register

This register comprises information about indefinite states which may occur if the unit is operated without meeting the specifications. It can be queried with commands `STATUS:OPERation[:EVENT]` and `STATUS:OPERation:CONDition`.

Bit No	Meaning
0 to 2	These bits are not used
3	POWer This bit is set if a questionable power occurs (cf. also section "STATUS:QUESTIONable:POWer Register").
4	TEMPerature This bit is set if a questionable temperature occurs.
5	FREQuency The bit is set if a frequency is questionable (cf. section "STATUS:QUESTIONable:FREQuency Register").
6 to 7	These bits are not used
8	CALibration The bit is set if a measurement is performed uncalibrated (= ^ label "UNCAL")
9	LIMit (device-specific) This bit is set if a limit value is violated (see also section STATUS:QUESTIONable:LIMit Register). Note: Limit register is associated with limit lines for the Spectrum Mask measurement only.
10	LMARgin (device-specific) This bit is set if a margin is violated (see also section STATUS:QUESTIONable:LMARgin Register)

Bit No	Meaning
11	<p>SYNC (device-dependent)</p> <p>This bit is set if, in measurements or pre-measurements in FSV-K10 mode, synchronization fails, no signal is detected or no burst is found.</p> <p>This bit is also set if input settings conflict with the measurement setup (see also "STATUS:QUESTIONABLE:SYNC Register").</p>
12	<p>ACPLimit</p> <p>This bit is set if a limit for the adjacent channel power measurement is violated (see also section "STATUS:QUESTIONABLE:ACPLimit Register").</p>
13 to 14	These bits are not used
15	This bit is always 0

STATUS:QUESTIONABLE:SYNC Register

This contains information about sync and bursts not found, and about pre-measurement results exceeding or falling short of expected values.

The bits can be queried with commands `STATUS:QUESTIONABLE:SYNC[:EVENT]` on page 240 and `STATUS:QUESTIONABLE:SYNC:CONDITION` on page 240.

Bit No	Meaning
0	<p>BURSt not found (screen A)</p> <p>This bit is set if no burst is found in the measurements/premeasurements for phase/frequency error (PFE) or carrier power vs time (PVT) in GSM/EDGE mode.</p> <p>If a burst is found in these measurements/premeasurements, the bit is reset.</p>
1	<p>SYNC not found (screen A)</p> <p>This bit is set if the synchronization sequence (training sequence) of the midamble is not found in the measurements/premeasurements for phase/frequency error (PFE) or carrier power vs time (PVT) in GSM/EDGE mode.</p> <p>If the synchronization sequence (training sequence) of the midamble is found in these measurements/premeasurements, the bit is reset.</p>
2	<p>No carrier (screen A)</p> <p>This bit is set if, in GSM/EDGE mode, the level value determined in the premeasurements for carrier power vs time (PVT) and spectrum due to modulation is too low. The bit is reset at the beginning of the premeasurement (see also chapter 2, description of the named premeasurements).</p>
3	<p>Carrier overload (screen A)</p> <p>This bit is set if, in GSM/EDGE mode, the level value determined in the premeasurements for carrier vs time (PVT) and spectrum due to modulation is too high. The bit is reset at the beginning of the premeasurement (see also chapter 2, description of the named premeasurements).</p>
4 to 14	These bits are not used
15	This bit is always 0

List of Commands

ABORt.....	94
CALCulate<n>:LIMit<i>:FAIL.....	94
CALCulate<n>:MARKer<m>:AOFF.....	96
CALCulate<n>:MARKer<m>:TRACe.....	96
CALCulate<n>:MARKer<m>:X.....	97
CALCulate<n>:MARKer<m>:Y.....	98
CALCulate<n>:MARKer<m>:ZOOM.....	98
CALCulate<n>:MARKer<m>[:STATe].....	95
CALCulate<n>:MASK:CDIRectory.....	100
CALCulate<n>:MASK:COMMeNt.....	100
CALCulate<n>:MASK:DELete.....	100
CALCulate<n>:MASK:LOWer:SHIFt:X.....	101
CALCulate<n>:MASK:LOWer:SHIFt:Y.....	101
CALCulate<n>:MASK:LOWer[:DATA].....	101
CALCulate<n>:MASK:LOWer[:STATe].....	101
CALCulate<n>:MASK:MODE.....	102
CALCulate<n>:MASK:NAME.....	102
CALCulate<n>:MASK:SPAN.....	102
CALCulate<n>:MASK:UPPer:AUTO.....	103
CALCulate<n>:MASK:UPPer:SHIFt:X.....	103
CALCulate<n>:MASK:UPPer:SHIFt:Y.....	103
CALCulate<n>:MASK:UPPer[:DATA].....	104
CALCulate<n>:MASK:UPPer[:STATe].....	103
CONFigure:BURSt:CONStell[:IMMediate].....	136
CONFigure:BURSt:ETIME[:IMMediate].....	136
CONFigure:BURSt:MACCuracy[:IMMediate].....	136
CONFigure:BURSt:MERRor[:IMMediate].....	137
CONFigure:BURSt:PFERror[:IMMediate].....	137
CONFigure:BURSt:PTEMplate:FILTer.....	137
CONFigure:BURSt:PTEMplate:FRZoom.....	138
CONFigure:BURSt:PTEMplate:SElect.....	138
CONFigure:BURSt:PTEMplate:TALign.....	138
CONFigure:BURSt:PTEMplate:TMHRes.....	139
CONFigure:BURSt:PTEMplate[:IMMediate].....	137
CONFigure:SPECTrum:HDYNamic.....	140
CONFigure:SPECTrum:LIMit:LEFT.....	140
CONFigure:SPECTrum:LIMit:RIGHT.....	141
CONFigure:SPECTrum:MODulation:LIMIT.....	141
CONFigure:SPECTrum:MODulation:LIST:BANDwidth:RESolution.....	142
CONFigure:SPECTrum:MODulation[:IMMediate].....	141
CONFigure:SPECTrum:SElect.....	143
CONFigure:SPECTrum:SWITChing:LIMIT.....	144
CONFigure:SPECTrum:SWITChing:TYPE.....	145
CONFigure:SPECTrum:SWITChing[:IMMediate].....	144
CONFigure:TRGS:ADPSize.....	145

CONFigure:TRGS:NOFBins.....	146
CONFigure:TRGS[:IMMediate].....	146
CONFigure:WSPectrum:MODulation:LIMIT.....	148
CONFigure:WSPectrum:MODulation:LIST:SElect.....	148
CONFigure:WSPectrum:MODulation[:IMMediate].....	146
CONFigure[:MS]:ARFCn.....	105
CONFigure[:MS]:AUTO.....	106
CONFigure[:MS]:AUTO:FRAMe.....	106
CONFigure[:MS]:AUTO:LEVel.....	106
CONFigure[:MS]:AUTO:TRIGger.....	107
CONFigure[:MS]:BSEarch.....	107
CONFigure[:MS]:BSTHreshold.....	108
CONFigure[:MS]:CHANnel:FRAMe:EQUal.....	108
CONFigure[:MS]:CHANnel:MSLots:MEASure.....	109
CONFigure[:MS]:CHANnel:MSLots:NOFSlots.....	109
CONFigure[:MS]:CHANnel:MSLots:OFFSet.....	109
CONFigure[:MS]:CHANnel:SLOT<s>:FILTer.....	110
CONFigure[:MS]:CHANnel:SLOT<s>:MTYPE.....	110
CONFigure[:MS]:CHANnel:SLOT<s>:MULTi.....	111
CONFigure[:MS]:CHANnel:SLOT<s>:PCL.....	112
CONFigure[:MS]:CHANnel:SLOT<s>:SCPIr.....	112
CONFigure[:MS]:CHANnel:SLOT<s>:SCPIr.....	113
CONFigure[:MS]:CHANnel:SLOT<s>:SUBChannel<ch>:TSC.....	114
CONFigure[:MS]:CHANnel:SLOT<s>:SUBChannel<ch>:TSC:USER.....	115
CONFigure[:MS]:CHANnel:SLOT<s>:TSC.....	116
CONFigure[:MS]:CHANnel:SLOT<s>:TSC:USER.....	118
CONFigure[:MS]:CHANnel:SLOT<s>:TYPE.....	119
CONFigure[:MS]:CHANnel:SLOT<s>[:STATe].....	110
CONFigure[:MS]:CHANnel:TSC.....	120
CONFigure[:MS]:CHANnel:TSC:USER.....	120
CONFigure[:MS]:DEMod:DECision.....	120
CONFigure[:MS]:DEMod:STDBits.....	122
CONFigure[:MS]:DEVice:TYPE.....	123
CONFigure[:MS]:MCARrier:ACTCarriers.....	124
CONFigure[:MS]:MCARrier:BTSClass.....	124
CONFigure[:MS]:MCARrier:FILTer.....	124
CONFigure[:MS]:MCARrier:MCBTs.....	125
CONFigure[:MS]:MCARrier[:STATe].....	123
CONFigure[:MS]:MTYPE.....	125
CONFigure[:MS]:MULTi:BURSt:CONStell.....	126
CONFigure[:MS]:MULTi:BURSt:DEModulation.....	127
CONFigure[:MS]:MULTi:BURSt:PTEMplate.....	127
CONFigure[:MS]:MULTi:SPECTrum:MODulation.....	127
CONFigure[:MS]:MULTi:SPECTrum:SWITChing.....	128
CONFigure[:MS]:MULTi:STATe.....	128
CONFigure[:MS]:NETWork:FREQuency:BAND.....	130
CONFigure[:MS]:NETWork[:TYPE].....	129
CONFigure[:MS]:POWer:AUTO.....	133

CONFigure[MS]:POWer:AUTO:SWEep:TIME.....	133
CONFigure[MS]:POWer:CLASs.....	131
CONFigure[MS]:POWer:STATic.....	132
CONFigure[MS]:PRATe.....	133
CONFigure[MS]:RESTore.....	134
CONFigure[MS]:SSEarch.....	134
CONFigure[MS]:SYNC:IQCThreshold.....	134
CONFigure[MS]:SYNC:MODE.....	134
CONFigure[MS]:SYNC:ONLY.....	135
DISPlay:FORMat.....	149
DISPlay[WiNDoW<n>]:SElect.....	149
DISPlay[WiNDoW<n>]:SSElect.....	150
DISPlay[WiNDoW<n>]:TRACe<t>:MODE.....	150
DISPlay[WiNDoW<n>]:TRACe<t>:Y[:SCALE]:RLEVel:OFFSet.....	151
DISPlay[WiNDoW<n>]:TRACe<t>:Y[:SCALE]:RLEVel[RF].....	152
FETCh:BURSt:PTEMplate:TRGS:AVERAge.....	174
FETCh:BURSt:PTEMplate:TRGS:CURRent.....	174
FETCh:BURSt:PTEMplate:TRGS:MAXimum.....	175
FETCh:BURSt:PTEMplate:TRGS:MINimum.....	176
FETCh:BURSt:PTEMplate:TRGS:SDEVIation.....	176
FETCh:BURSt:SPOWer:SLOT<s>:ALL:AVERAge.....	177
FETCh:BURSt:SPOWer:SLOT<s>:ALL:CRESt.....	178
FETCh:BURSt:SPOWer:SLOT<s>:ALL:MAXimum.....	179
FETCh:BURSt:SPOWer:SLOT<s>:CURRent:AVERAge.....	180
FETCh:BURSt:SPOWer:SLOT<s>:CURRent:CRESt.....	181
FETCh:BURSt:SPOWer:SLOT<s>:CURRent:MAXimum.....	182
FETCh:BURSt:SPOWer:SLOT<s>:DELTAtoSync.....	183
FETCh:BURSt[:MACCuracy]:ADRoop:AVERAge.....	154
FETCh:BURSt[:MACCuracy]:ADRoop:CURRent.....	154
FETCh:BURSt[:MACCuracy]:ADRoop:MAXimum.....	155
FETCh:BURSt[:MACCuracy]:ADRoop:SDEVIation.....	155
FETCh:BURSt[:MACCuracy]:ALL.....	155
FETCh:BURSt[:MACCuracy]:BPOWer:AVERAge.....	156
FETCh:BURSt[:MACCuracy]:BPOWer:CURRent.....	156
FETCh:BURSt[:MACCuracy]:BPOWer:MAXimum.....	156
FETCh:BURSt[:MACCuracy]:BPOWer:SDEVIation.....	157
FETCh:BURSt[:MACCuracy]:FERRor:AVERAge.....	161
FETCh:BURSt[:MACCuracy]:FERRor:CURRent.....	162
FETCh:BURSt[:MACCuracy]:FERRor:MAXimum.....	162
FETCh:BURSt[:MACCuracy]:FERRor:SDEVIation.....	163
FETCh:BURSt[:MACCuracy]:FREQUency:AVERAge.....	163
FETCh:BURSt[:MACCuracy]:FREQUency:CURRent.....	163
FETCh:BURSt[:MACCuracy]:FREQUency:MAXimum.....	164
FETCh:BURSt[:MACCuracy]:FREQUency:SDEVIation.....	164
FETCh:BURSt[:MACCuracy]:IQIMbalance:AVERAge.....	164
FETCh:BURSt[:MACCuracy]:IQIMbalance:CURRent.....	164
FETCh:BURSt[:MACCuracy]:IQIMbalance:MAXimum.....	165
FETCh:BURSt[:MACCuracy]:IQIMbalance:SDEVIation.....	165

FETCh:BURSt[:MACCuracy]:IQOFset:AVERage.....	165
FETCh:BURSt[:MACCuracy]:IQOFset:CURRent.....	166
FETCh:BURSt[:MACCuracy]:IQOFset:MAXimum.....	166
FETCh:BURSt[:MACCuracy]:IQOFset:SDEVIation.....	166
FETCh:BURSt[:MACCuracy]:MERRor:PEAK:AVERage.....	167
FETCh:BURSt[:MACCuracy]:MERRor:PEAK:CURRent.....	167
FETCh:BURSt[:MACCuracy]:MERRor:PEAK:MAXimum.....	167
FETCh:BURSt[:MACCuracy]:MERRor:PEAK:SDEVIation.....	167
FETCh:BURSt[:MACCuracy]:MERRor:RMS:AVERage.....	168
FETCh:BURSt[:MACCuracy]:MERRor:RMS:CURRent.....	168
FETCh:BURSt[:MACCuracy]:MERRor:RMS:MAXimum.....	168
FETCh:BURSt[:MACCuracy]:MERRor:RMS:SDEVIation.....	169
FETCh:BURSt[:MACCuracy]:OSUPpress:AVERage.....	169
FETCh:BURSt[:MACCuracy]:OSUPpress:CURRent.....	169
FETCh:BURSt[:MACCuracy]:OSUPpress:MAXimum.....	170
FETCh:BURSt[:MACCuracy]:OSUPpress:SDEVIation.....	170
FETCh:BURSt[:MACCuracy]:PERCentile:EVM.....	170
FETCh:BURSt[:MACCuracy]:PERCentile:MERRor.....	170
FETCh:BURSt[:MACCuracy]:PERCentile:PERRor.....	171
FETCh:BURSt[:MACCuracy]:PERRor:PEAK:AVERage.....	171
FETCh:BURSt[:MACCuracy]:PERRor:PEAK:CURRent.....	171
FETCh:BURSt[:MACCuracy]:PERRor:PEAK:MAXimum.....	172
FETCh:BURSt[:MACCuracy]:PERRor:PEAK:SDEVIation.....	172
FETCh:BURSt[:MACCuracy]:PERRor:RMS:AVERage.....	172
FETCh:BURSt[:MACCuracy]:PERRor:RMS:CURRent.....	173
FETCh:BURSt[:MACCuracy]:PERRor:RMS:MAXimum.....	173
FETCh:BURSt[:MACCuracy]:PERRor:RMS:SDEVIation.....	173
FETCh:BURSt[:MACCuracy][:EVM]:PEAK:AVERage.....	157
FETCh:BURSt[:MACCuracy][:EVM]:PEAK:CURRent.....	158
FETCh:BURSt[:MACCuracy][:EVM]:PEAK:MAXimum.....	158
FETCh:BURSt[:MACCuracy][:EVM]:PEAK:SDEVIation.....	159
FETCh:BURSt[:MACCuracy][:EVM]:RMS:AVERage.....	159
FETCh:BURSt[:MACCuracy][:EVM]:RMS:CURRent.....	160
FETCh:BURSt[:MACCuracy][:EVM]:RMS:MAXimum.....	160
FETCh:BURSt[:MACCuracy][:EVM]:RMS:SDEVIation.....	161
FETCh:SPECTrum:MODulation:REFerence.....	185
FETCh:SPECTrum:MODulation[:ALL].....	184
FETCh:SPECTrum:SWITChing:REFerence.....	186
FETCh:SPECTrum:SWITChing[:ALL].....	185
FETCh:WSPectrum:MODulation:REFerence.....	187
FETCh:WSPectrum:MODulation[:ALL].....	187
INITiate:REFMeas[:IMMediate].....	189
INITiate<n>:CONTInuous.....	188
INITiate<n>[:IMMediate].....	188
INPut:ATTenuation.....	190
INPut:ATTenuation:AUTO.....	190
INPut:DIQ:RANGe[:UPPer].....	190
INPut:DIQ:SRATe.....	191

INPut:EATT.....	191
INPut:EATT:AUTO.....	192
INPut:EATT:STATe.....	192
INPut:GAIN:STATe.....	192
INPut:SElect.....	193
INSTRument:NSElect.....	194
INSTRument[:SElect].....	193
MMEMory:LOAD:IQ:STATe.....	194
MMEMory:MDIRectory.....	195
MMEMory:STORe:IQ:STATe.....	195
READ:BURSt:PTEMplate:TRGS:AVERage.....	219
READ:BURSt:PTEMplate:TRGS:CURRent.....	220
READ:BURSt:PTEMplate:TRGS:MAXimum.....	221
READ:BURSt:PTEMplate:TRGS:MINimum.....	222
READ:BURSt:PTEMplate:TRGS:SDEViation.....	223
READ:BURSt:SPOWer:SLOT<Slot>:ALL:AVERage.....	224
READ:BURSt:SPOWer:SLOT<Slot>:ALL:CRESt.....	225
READ:BURSt:SPOWer:SLOT<Slot>:ALL:MAXimum.....	226
READ:BURSt:SPOWer:SLOT<Slot>:CURRent:AVERage.....	227
READ:BURSt:SPOWer:SLOT<Slot>:CURRent:CRESt.....	228
READ:BURSt:SPOWer:SLOT<Slot>:CURRent:MAXimum.....	229
READ:BURSt:SPOWer:SLOT<Slot>:DELTAtoSync.....	230
READ:BURSt[:MACCuracy]:ADRooP:AVERage.....	198
READ:BURSt[:MACCuracy]:ADRooP:CURRent.....	199
READ:BURSt[:MACCuracy]:ADRooP:MAXimum.....	199
READ:BURSt[:MACCuracy]:ADRooP:SDEViation.....	199
READ:BURSt[:MACCuracy]:ALL.....	198
READ:BURSt[:MACCuracy]:ALL.....	231
READ:BURSt[:MACCuracy]:BPOWer:AVERage.....	200
READ:BURSt[:MACCuracy]:BPOWer:CURRent.....	200
READ:BURSt[:MACCuracy]:BPOWer:MAXimum.....	200
READ:BURSt[:MACCuracy]:BPOWer:SDEViation.....	201
READ:BURSt[:MACCuracy]:FERRor:AVERage.....	204
READ:BURSt[:MACCuracy]:FERRor:CURRent.....	205
READ:BURSt[:MACCuracy]:FERRor:MAXimum.....	205
READ:BURSt[:MACCuracy]:FERRor:SDEViation.....	206
READ:BURSt[:MACCuracy]:FREQuency:AVERage.....	206
READ:BURSt[:MACCuracy]:FREQuency:CURRent.....	206
READ:BURSt[:MACCuracy]:FREQuency:MAXimum.....	207
READ:BURSt[:MACCuracy]:FREQuency:SDEViation.....	207
READ:BURSt[:MACCuracy]:IQIMbalance:AVERage.....	208
READ:BURSt[:MACCuracy]:IQIMbalance:CURRent.....	208
READ:BURSt[:MACCuracy]:IQIMbalance:MAXimum.....	208
READ:BURSt[:MACCuracy]:IQIMbalance:SDEViation.....	209
READ:BURSt[:MACCuracy]:IQOffset:AVERage.....	209
READ:BURSt[:MACCuracy]:IQOffset:CURRent.....	209
READ:BURSt[:MACCuracy]:IQOffset:MAXimum.....	210
READ:BURSt[:MACCuracy]:IQOffset:SDEViation.....	210

READ:BURSt[:MACCuracy]:MERRor:PEAK:AVERage.....	210
READ:BURSt[:MACCuracy]:MERRor:PEAK:CURRent.....	211
READ:BURSt[:MACCuracy]:MERRor:PEAK:MAXimum.....	211
READ:BURSt[:MACCuracy]:MERRor:PEAK:SDEViation.....	212
READ:BURSt[:MACCuracy]:MERRor:RMS:AVERage.....	212
READ:BURSt[:MACCuracy]:MERRor:RMS:CURRent.....	212
READ:BURSt[:MACCuracy]:MERRor:RMS:MAXimum.....	213
READ:BURSt[:MACCuracy]:MERRor:RMS:SDEViation.....	213
READ:BURSt[:MACCuracy]:OSUPpress:AVERage.....	213
READ:BURSt[:MACCuracy]:OSUPpress:CURRent.....	214
READ:BURSt[:MACCuracy]:OSUPpress:MAXimum.....	214
READ:BURSt[:MACCuracy]:OSUPpress:SDEViation.....	215
READ:BURSt[:MACCuracy]:PERCentile:EVM.....	215
READ:BURSt[:MACCuracy]:PERCentile:MERRor.....	215
READ:BURSt[:MACCuracy]:PERCentile:PERRor.....	216
READ:BURSt[:MACCuracy]:PERRor:PEAK:AVERage.....	216
READ:BURSt[:MACCuracy]:PERRor:PEAK:CURRent.....	216
READ:BURSt[:MACCuracy]:PERRor:PEAK:MAXimum.....	217
READ:BURSt[:MACCuracy]:PERRor:PEAK:SDEViation.....	217
READ:BURSt[:MACCuracy]:PERRor:RMS:AVERage.....	217
READ:BURSt[:MACCuracy]:PERRor:RMS:CURRent.....	218
READ:BURSt[:MACCuracy]:PERRor:RMS:MAXimum.....	218
READ:BURSt[:MACCuracy]:PERRor:RMS:SDEViation.....	219
READ:BURSt[:MACCuracy][:EVM]:PEAK:AVERage.....	201
READ:BURSt[:MACCuracy][:EVM]:PEAK:CURRent.....	201
READ:BURSt[:MACCuracy][:EVM]:PEAK:MAXimum.....	202
READ:BURSt[:MACCuracy][:EVM]:PEAK:SDEViation.....	202
READ:BURSt[:MACCuracy][:EVM]:RMS:AVERage.....	203
READ:BURSt[:MACCuracy][:EVM]:RMS:CURRent.....	203
READ:BURSt[:MACCuracy][:EVM]:RMS:MAXimum.....	203
READ:BURSt[:MACCuracy][:EVM]:RMS:SDEViation.....	204
READ:SPECTrum:MODulation:REFerence[:IMMEDIATE].....	232
READ:SPECTrum:MODulation[:ALL].....	232
READ:SPECTrum:SWITChing:REFerence[:IMMEDIATE].....	234
READ:SPECTrum:SWITChing[:ALL].....	233
READ:SPECTrum:WMODulation:GATing (obsolete).....	234
READ:WSPectrum:MODulation:GATing.....	235
READ:WSPectrum:MODulation:REFerence[:IMMEDIATE].....	236
READ:WSPectrum:MODulation[:ALL].....	234
STATus:OPERation:CONDition.....	239
STATus:OPERation[:EVENT].....	239
STATus:QUEStionable:SYNC:CONDition.....	240
STATus:QUEStionable:SYNC:ENABLE.....	240
STATus:QUEStionable:SYNC:NTRansition.....	241
STATus:QUEStionable:SYNC:PTRansition.....	241
STATus:QUEStionable:SYNC[:EVENT].....	240
TRACe<n>:IQ:DATA:MEMory.....	243
TRACe[:DATA].....	241

TRACe[:DATA]:X.....	242
TRIGger<n>[:SEQuence]:HOLDoff[:TIME].....	243
TRIGger<n>[:SEQuence]:LEVel:IFPower.....	244
TRIGger<n>[:SEQuence]:LEVel[:EXTernal].....	244
TRIGger<n>[:SEQuence]:MASK:CONDition.....	244
TRIGger<n>[:SEQuence]:SOURce.....	245
TRIGger<n>[:SEQuence]:SYNChronize:ADJust:AUTO.....	245
TRIGger<n>[:SEQuence]:SYNChronize:ADJust:EXTernal.....	246
TRIGger<n>[:SEQuence]:SYNChronize:ADJust:IFPower.....	246
TRIGger<n>[:SEQuence]:SYNChronize:ADJust:IMMEDIATE.....	247
TRIGger<n>[:SEQuence]:SYNChronize:ADJust:RFPower.....	247
[SENSe:]FREQuency:CENTer.....	237
[SENSe:]FREQuency:OFFSet.....	237
[SENSe:]SWAPiq.....	238
[SENSe:]SWEep:COUNT.....	238
[SENSe:]SWEep:COUNT:CURRent.....	238
[SENSe:]SWEep:TIME.....	239
[SENSe:]BANDwidth[:RESolution]:TYPE.....	236
[SENSe:]BURSt:COUNT.....	237

Index

- 3GPP 11, 31
 3GPP TS 45.004 11
 3GPP TS 45.005 11
 3GPP TS 45.010 11
 3GPP TS 51.010 11
 3GPP TS 51.021 11
 8PSK 31, 34
 16QAM 31, 32, 35
 32QAM 31, 32, 35
- A**
- Active Part 51
 Adaptive Data Size 74
 Amplitude droop 14
 AQPSK 31, 36, 37, 67
 ARFCN 31, 33, 58, 105
 Attenuation
 Electrical 62
 External 58
 Manual 190
 RF 62
 Auto Frame 106
 Auto Level 106, 133
 AUTO SET key 78, 246, 247
 Auto Track Time 63
 remote control 133
 Auto Trigger 107
- B**
- Band class
 Primary Settings 130
 Band Class
 Primary Settings 129
 Bins
 Number 74
 BTS 31
 BTS Class 78
 Burst
 activating (remote control) 110
 Burst Configuration 66
 Burst Dialog 66
 Burst State 67
 Burst Type 67
- C**
- Capture Time 59
 Channel number 33, 58
 Characters
 Special 92
 Commands
 Description 91
 Constellation 18, 81
 Multi-measurement mode 77
- D**
- Delta to sync 72
 Demod tab 64
 Dig. Input Sample Rate
 Digital IQ 63
 DigIConf
 Softkey 90
 DL 31
 Downlink 33
 DUT 31
 Dynamic PCL 112
- E**
- EDGE 31
 EDGE Evolution 32, 35
 EGPRS 31
 EGPRS2 31, 32
 Electronic input attenuation
 FSV-B25 191
 Enable Right Limit 72
 Equal Timeslot Length 22, 66
 Evaluation
 Refreshing 86
 EVM 81
 EVM vs Time 15, 75
 Multi-measurement mode 76
 EX-IQ-BOX 89
 DigIConf 90
 Export
 I/Q data (remote) 195
 External Atten. 151
- F**
- Falling
 softkey 82
 FDMA 31, 32
 Filter 67
 Burst Dialog 110
 First Slot to measure
 remote control 109
 Frame 32
 Frame configuration
 Auto Set 79
 Measurement Settings 106
 Frequency 58
 Frequency Band 57
 Frequency Hopping 33
 Frequency mask trigger 39
 Frequency offset 61
 Full Scale Level
 Digital I/Q Interface (remote control) 190
 Digital IQ 64
- G**
- GMSK 31, 32, 34
 GMSK Pulse 48
 GPRS 31, 35
 GSM 31, 32
- H**
- High Dynamic 74
 Higher Symbol Rate bursts 32, 35, 50, 51
 HSCSD 31, 35
 HSR 32, 35

- I**
- I/Q data
 - Export (remote control) 195
 - Import (remote control) 194
 - IEC/IEEE bus
 - Command description 91
 - IF 31
 - Importing
 - I/Q data (remote) 194
 - Inherent noise 74
 - Input/Output menu 89
 - Input sample rate
 - Digital IQ 63
 - IQ Correlation Threshold 75
- K**
- key
 - AUTO SET 247
 - AUTO SET (remote control) 246
 - TRACE (remote control) 237
 - Key
 - AMPT 86
 - AUTO SET 78, 86
 - FREQ 86
 - HELP 11
 - INPUT/OUTPUT 89
 - MEAS 54
 - MKR 87
 - MKR TO 88
 - SWEEP 86
 - TRACE 86
 - TRIG 87
- L**
- Level
 - Auto Set 79
 - Measurement Settings 106
 - Reference 58, 61
 - Limit lines
 - Time alignment 72
 - Limit Time Alignment 22, 51, 72
 - Linearised GMSK Pulse 49
 - Linear Symbol Decision 75
 - Lower-case (commands) 92
- M**
- Magnitude Error 81
 - Magnitude Error vs Time 17
 - Multi-measurement mode 76
 - Markers
 - Set to trace 88
 - Measurement
 - Constellation Time 18
 - EVM vs Time 15
 - Magnitude Error vs Time 17
 - Modulation Accuracy 13
 - Modulation Spectrum 23
 - Phase Error vs Time 14
 - Power vs Time 20
 - Transient Spectrum 26
 - Trigger to Sync 19
 - Wide Modulation Spectrum 27
 - Measure only on Sync 60
 - Measure Slot 65
 - Middle of midamble 51
 - Modulation 67, 110
 - Modulation Accuracy 13, 80
 - Multi-measurement mode 76
 - Modulation Spectrum 23, 83
 - Multi-measurement mode 77
 - MS 31
 - Multi Carrier BTS 77
 - Multi-measurement mode 12, 76
 - Constellation 77
 - EVM vs Time 76
 - Magnitude Error vs Time 76
 - Modulation Accuracy 76
 - Modulation Spectrum 77
 - Phase Error vs Time 76
 - Power vs Time 76
 - Transient Spectrum 77
- N**
- Narrow Pulse 32, 50, 75
 - No. of active Carriers 25, 78
 - Normal bursts 34, 51
 - Normal symbol period 48, 49
 - NSR 34
 - Number of Slots to measure 65
 - remote control 109
- O**
- online help
 - working with 8
 - Options
 - FSV-B25 191
 - RF Preamplifier (B22) 62
- P**
- PCL 23, 31, 112
 - Phase Error 81
 - Phase Error vs Time 14
 - Multi-measurement mode 76
 - Power Class 58, 131
 - Power vs Time 20
 - Multi-measurement mode 76
 - Preamplifier (B22) 62
 - PvT 31, 82
 - PvT Filter 71, 78
- Q**
- QPSK 31, 32, 35
- R**
- R&S Support
 - softkey 89
 - Reduced symbol period 50
 - Reference level 58, 61, 152
 - Ref Level Auto 58
 - RF Preamplifier (B22) 62
 - Rising
 - softkey 82
 - Root Menu 54
 - RX Settings
 - softkey 89

S

- Sample rate
 - Digital I/Q Interface (remote control) 191
 - Digital IQ 63
 - SCPI
 - Conformity information 91
 - SCPIR 31, 36, 37, 67
 - remote control 113
 - Sequence Estimator 75
 - Settings
 - Advanced Capture Settings 61
 - General Settings 56
 - SFH 31, 33
 - Signal source 59
 - Signal Source
 - Remote control 193
 - Slot 32
 - configuration 66
 - First Slot to measure 43, 65, 66
 - Measure Slot 65
 - Number of Slots to measure 43, 65, 66
 - Slot to Measure 43, 66
 - Slot to Measure
 - remote control 109
 - softkey
 - Continue Single Sweep (remote control) 188
 - Continuous Sweep (remote control) 188
 - Cont Meas (remote control) 188
 - Full 137
 - New Folder (remote control) 195
 - R&S Support 89
 - Single Meas (remote control) 188
 - Single Sweep (remote control) 188
 - Softkey
 - All Marker Off 88
 - Annotation On/Off (remote control) 149
 - Center (remote control) 237
 - Constell 81
 - Constellation 136
 - Continuous Sweep (remote control) 188
 - Cont Meas (remote control) 188
 - Delete mask 43
 - Demodulation 80
 - DigiConf 90
 - Display List/Graph 84
 - Display List/Graph (remote control) 143
 - EL Atten (remote control) 192
 - EL Atten Mode (Auto/Man) (remote control) 191, 192
 - EVM 81, 136
 - EX-IQ-BOX 89
 - Export 85
 - Export (remote control) 195
 - Falling 82
 - Frequency mask 39
 - Frequency Offset (remote control) 237
 - Full 82
 - General Settings 56
 - Import 84
 - Import (remote control) 194
 - Load mask 42
 - Magnitude Error 81, 137
 - Marker 1 88
 - Marker to Trace 88
 - Marker to Trace (remote control) 96
 - Marker Zoom 88
 - Measurement Settings 64
 - Mech Atten Auto (remote control) 190
 - Mech Atten Manual (remote control) 190
 - Modulation Accuracy 80, 136
 - Modulation Spectrum 83
 - New mask 40
 - Phase Error 81, 137
 - Preamplifier On/Off 62
 - Preamplifier On/Off (remote control) 192
 - PvT 82
 - RF Atten Auto (remote control) 190
 - RF Atten Manual (remote control) 190
 - Rise & Fall 83
 - Rising 82
 - Save mask 42
 - Single Meas (remote control) 188
 - Single Sweep (remote control) 188
 - Spectrum 83
 - Sweep Count (remote control) 238
 - Sweep Time (remote control) 239
 - Sweeptime Manual (remote control) 239
 - Top 83
 - Transient Spectrum 83
 - Trg/Gate Source (remote control) 244, 245
 - Trigger to Sync 81
 - Unzoom 88
 - Wide Mod Spectrum 84
 - Wide Spectrum 84
 - Special characters 92
 - Spectrum 83
 - Static PCL 132
 - Statistic Count 60, 237
 - Swap I/Q 63
 - Swap IQ
 - remote control 238
 - Symbol Decision 75
 - Symbol period
 - Definition 48
 - Synchronization 59
- T**
- Tail & TSC Bits 75
 - TDMA 31, 32
 - Timeslot alignment 51
 - TRACE key 237
 - Trace Wizard 86
 - Training Sequence TSC 68
 - AQPSK 70
 - User-defined 69
 - User-defined, AQPSK 71
 - Transducer factors 38
 - Transient Ref. Power 73
 - Transient Spectrum 26, 83
 - Multi-measurement mode 77
 - Trigger
 - Auto Set 80
 - External 38
 - Free Run 38
 - level 63
 - Level 244
 - mode 60
 - offset 60
 - power 38
 - remote control 107
 - Settings 38
 - Trigger to Sync 19

Remote control	146
softkey	81
TSC	31, 36, 68
AQPSK	70
setting (remote control)	116
User-defined	69
User-defined, AQPSK	71
TX Settings	
EX-IQ-BOX	89
U	
UL	31
Uplink	33
Upper-case (commands)	92
V	
VAMOS	31, 36
W	
Wide Modulation Spectrum	27
softkey	84
Wide Pulse	32, 50
Wide Spectrum	
softkey	84
Y	
YIG	31