

# 5. Circuit Description

---

## 5-1 Logic Section

---

### 5-1-1 Power Supply

With the battery installed on the phone and by pressing the END/Ⓚ key, the VBATT and ON\_SW signals will be connected. This will turn on U123 DC\_DC convertor.

This in turn will be supplied to PIN3, PIN4 of regulators U124, PIN6 of regulators U122, thus releasing them from the shut-down state to output regulated 3.3V. (The VBATT applied to ON-SW will turn on Q103(DTC144EE) resulting in the signal ON\_SW\_SENSE to change the start from High to Low.)

The MSM recognizes this signal and sends out PS\_HOLD (logical HIGH) to turn on Q102 even after the PWR key is released.

The power from U124 is used in the digital part of MSM and BBA. The power from U122 is used in analog part of BBA.

### 5-1-2 Logic Part

The logic part consists of internal CPU of MSM, RAM, ROM and EEPROM. The MSM receives TCXO and CHIPX8 clock signals from the BBA and controls the phone during the operation. The major components are as follows:

- CPU : INTEL 80186 core (inside the MSM)
- FLASH ROM : U701 - 8 Mbit FLASH MEMORY
- SRAM : U703 - 2 Mbit STATIC RAM
- FLASH ROM : U702 - 1 Mbit FLASH MEMORY
- EEPROM : U102 - 128 Kbit SERIAL EEPROM

#### CPU

INTEL 80186 CMOS type 16-bit microprocessor is used for the main processing. The CPU controls all the circuitry. For the CPU clock, 27MHz resonator is used.

#### FLASH ROM

One 8 MBIT FROM is used to store the terminal's program. Using the down-loading program, the program can be changed even after the terminal is fully assembled.

#### SRAM

One 2 MBIT SRAM is used to store the internal flag information, call processing data, and timer data.

#### EEPROM

One 128 KBIT EEPROM is used to store ESN, NAM, power level, volume level, and telephone number.

#### KEYPAD

For key recognition, key matrix is to set up using SCAN0-6 of STORE signals and KEY0-3 of input ports of MSM. Ten LEDs and backlighting circuitry are included in the keypad for easy operation in the dark.

#### LCD MODULE

LCD module contains a controller which will display the information onto the LCD by 8-bit data from the MSM. It also consists a DC-DC converter to supply -3.5V for fine view angle and LCD reflector to improve the display efficiency.

## 5-1-3 Baseband Part

### MOBILE STATION MODEM (MSM)

The MSM equipped with the INTEL 80186 CPU core is an important component of the CDMA cellular phone. The MSM comes in a 176 pins TQFP package.

### MICROPROCESSOR INTERFACE

The interface circuitry consists of reset circuit, address bus (A0-A19), data bus (AD0-AD15), and memory controls (ALE, DT\_R, HWR/, LWR/, RAM\_CS/, ROM\_CS etc).

### INPUT CLOCK

- CPU clock: 27 MHz
- TCXO/4 (pin 34): 4.92 MHz. This clock signal from the BBA is the reference clock for the MSM except in CDMA mode.
- CHIPX8 : 9.8304 MHz. The reference clock used during the CDMA mode.

### BBA INTERFACE

#### **CDMA, FM Data Interface**

- TXIQDATA0-7 (pins 24-32) : TX data bus used during both CDMA and FM mode but it is used only for CDMA mode at this phone.

#### **Clock**

- TC\_CLK (pin 22), TX\_CLK/(pin 23) : Digital to Analog Converter (DAC) reference clock used in CDMA TX mode.
- CHIPX8 : ADC reference clock used in CDMA RX mode.

#### **ADC Interface**

ADC\_CLK (pin 3), ADC\_ENABLE (pin 1) and ADC\_DATA (pin 2) are required to control the internal ADC in the BBA.

#### **Data Port Interface**

Includes the UART. Also, supports Diagnostic Monitor (DM), HP equipment interface, down loading, and data service.

#### **CODEC Interface**

The MSM sends 2.048 MHz PCM\_CLK (pin 19) and 8 KHz PCM\_SYNC (pin 16, 20) to the CODEC (U117). The voice PCM data from the MSM (U101) PCM\_DIN (pin 135) is compressed into 8 KHz, by QCELP algorithm in the CDMA mode.

#### **RF Interface**

**TX :** TX\_AGC\_ADJ (pin 35) port is used to control the TX power level and PA\_ON (pin 44) signal is used to control the power amplifier. This signal depends on the TX vocoder rate.

**RX :** AGC\_REF (pin 36) port is used to control the RX gain and TRK\_LO\_ADJ (pin 45) is used to compensate the TCXO clock.

#### **General Purpose I/O Register Pins**

Input/output ports to control external devices.

#### **Power Down Control**

When the IDLE/ signal turns to LOW, only the TX sections will be disabled. If both the IDLE/ and SLEEP/ change to LOW, all the pins except for the TCXO and 27MHz clock are disabled.

## 5-1-4 Audio Part

### TX AUDIO PATH

The voice signal output from microphone is filtered and amplified by the internal OP-AMP and is converted to PCM data by the CODEC (U117). The signal is then applied to the MSM (U101)'s internal vocoder.

### RX AUDIO PATH

The PCM data from the MSM's converted to audio signal by ADC of CODEC (U117), is then amplified by the speaker amplifier (U111) to be sent to the speaker unit.

### TX WBD, ST, SAT

These signals are generated from MSM. The modulation level of TX WBD and ST is  $\pm 8$  kHz/dev, and SAT is  $\pm 2$  kHz/dev.

### BUZZER DRIVING CIRCUITRY

Buzzer generates alert tone when the buzzer receives the timer signal from the MSM, it generates alert tone. The buzzer level is adjusted by the alert signal's period generated from the MSM timer.

### KEY TONE GENERATION

Ringer signal (pin49) out from MSM (U101) is passed through 2 serial LPF consisting of R141, C146, R145, and C142 amplified at the speaker amp (U111), and comes out to speaker.

## 5-2 Receiver Section

---

### LOW NOISE AMPLIFIER (LNA, Q302)

The low noise amplifier amplifies a weak signal received from the base station to obtain the optimum level (Noise figure = 1.5 dB, Gain = 16 dB).

### RADIO FREQUENCY BAND PASS FILTER (RF BPF, F302)

The RF BPF accepts only a specific frequency ( $881 \pm 12.5$  MHz) from the signal received from the base station. The band width is 25 MHz.

### DOWN CONVERTER (MIXER, U301)

First local signal is applied to this down converter. The down converter transfers the signal amplified at the LNA into 85.38 MHz IF signal. 85.38 MHz IF signal is made by subtracting  $881 \pm 12.5$  MHz RF signal from  $966 \pm 12.5$  MHz first local signal.

### AUTOMATIC GAIN CONTROLLER (AGC) AMP (Q302)

85.38 MHz IF signal is applied to IF AGC amp, the IF AGC output level is applied to BBA (Baseband Analog ASIC). The IF AGC amp (Q302) keeps the signal at a constant level by controlling the gain. Dynamic range is 90dB, up gain +45dB, and down gain -45dB.

### IF SAW BAND PASS FILTER (FOR CDMA)

IF SAW BPF (F303) is used for CDMA system having 1.23 MHz wideband and  $\pm 630$  kHz bandwidth. The filter also attenuates the image product generated at the mixer.

### BUFFER AMP (Q304)

Buffer (Q304) amplifiers signal to be applied to the local input of the down converter (U301) when a phase is locked between VCO (U341) and PLL IC (U342).

#### VOLTAGE CONTROLLED OSCILLATOR (VCO, U341)

The VCO (U341) generates the signal having 966 MHz center frequency and  $\pm 12.5$  MHz deviation with the voltage control. PLL IC (U342) controls this signal.

#### ANTENNA

Antenna allows signals and sends to receive from the base station.

#### PHASE LOCKED LOOP (PLL, U342)

Input reference frequency is generated at VC\_TCXO (U343) and the divided signal is generated at VCO. PLL compares the two signals and generates the desired signal with a pre-programmed counter which controls voltage.

#### VOLTAGE CONTROLLED TEMPERATURE COMPENSATED CRYSTAL OSCILLATOR (VC-TCXO, U343)

It provides 19.68 MHz reference frequency to PLL. A correct frequency tuning is made by the voltage control.

#### DUPLEXER (F301)

Duplexer (F301) controls to transmit through the antenna only the signals within acceptable Tx frequency range ( $836 \pm 12.5$  MHz) and to receive through the antenna only the signals within acceptable Rx frequency range ( $881 \pm 12.5$  MHz). It also matches LNA input in receiving part and PA output in transmitter part with the antenna.

#### POWER SUPPLY REGULATOR (U123)

The power supply regulator generates a regulated power.

#### THERMISTOR (R498)

The thermistor (R498) detects temperature. It is used to compensate active component characteristics due to the temperature difference.

## 5-3 Transmitter Section

---

### BBA (U401)

BBA (U401) consists of ADC, DAC, LPF (CDMA), divider, VCO, logic control circuit, PLL, and mixer.

BBA performs a specific function between RF part and logic part, with MSM. The IF signal out from Rx IF AGC amp is secondly converted through the down-converter. The signal passes through the CDMA or FM filter, converts to digital signal through ADC, then is sent to MSM. The digital signal out from MSM converts to analog signal through each filter and the up-converters.

### POWER AMP MODULE (U467)

Power Amp module (U467) amplifies signal (24dB Gain) to be sent out to the base station through the antenna.

### UP CONVERTER (MIXER, U460)

The up-converter (U460) receives the first local signal to generate  $836 \pm 12.5$  MHz from the BBA.  $836 \pm 12.5$  MHz signal comes out of the mixer output by subtracting 130 MHz IF signal from  $966 \pm 12.5$  MHz first local signal.

### RF AUTOMATIC GAIN CONTROLLER AMP (U461, U464)

The signal out to the base station should be a constant level. The TX RF AGC amp controls power to keep the signal at a constant level.

### RF BAND PASS FILTER (BPF, F451)

The RF BPF ( F451) accepts only a specific frequency ( $836 \pm 12.5$ MHz) to send it out to the base station. The band width is 25 MHz.

### POWER SUPPLY SWITCHING (U484)

Power supply switching (U484) turns on TX\_POWER when the phone is in traffic mode and supplies power to the circuits.

### POWER SUPPLY REGULATOR (U482, U483)

The power supply regulators (U482,U483) supply a regulated power to each part of transmitter. U482 supplies 3.6V to TX AGC amp (U461) and up-converter (U460). U483 supplies 3.0V to power amp module control circuit (U487).