

TP 3000

manual

146 - 174 MHz

NY FRS 1/3-88



TP RADIO

Technical description TP 3000

Receiver 2m.

The incoming signal goes via the arial switch, which is a relay to the RF amplifier consisting of a bipolar transistor Q 1 and several tuned circuits to give the necessary selectivity.

The first mixer, which is a single gate junction FET, Q 2 converts the RF signal 146-174 Mhz, to 21,4 Mhz the first IF. The oscillator injection 167, 4-195,4 Mhz is injected into the source of the FET.

The IF signal is supplied to the following X-tal filter via a matching tuned circuit, and from the X-tal filter is fed to a following dual gate MOS FET amp. Q 3, giving 20 db gain. This stage is followed by the second mixer IC 1, which converts the 21,4 Mhz to 455 Khz. This mixer is an integrated balanced mixer.

It contains both mixer and oscillator with an external X-tal.

The 455 Khz IF is fed via a tuned circuit L 10 to the discriminator IC 2. The coil L 11 is the detector coil in the quadrature detector circuit. The AF output is supplied to the amplifier and squelch circuit by an emitter follower Q 4.

The AF signal goes via the electronic attenuator, consisting of the diodes D 5 and D 6. When a DC voltage is applied to these diodes, the diode current will more or less short the AF signal. The applied DC voltage is the volume control.

The volume control circuit is followed by an amplifier Q 5 which compensates in loss of signal from the following deemphasis R 34 and C 45.

The signal is then fed to the integrated audio power amplifier IC 3 which gives approx. 3-4 watt output power into the 4 ohm loudspeaker.

Pin no. 5 is used to block AF amplifier both from squelch and external blocking circuits.

The squelch circuit consists of an 7-8 Khz tuned amplifier Q 10 followed by the noise detector D 10 and D 11. When the rectified noise voltage is negativ Q 9 is activated and Q 7 is activated and Q 7 blocks the AF power amplifier.

The squelch regulation is made by a DC voltage from the control box. When the squelch is open or the channel is used, the occupied lamp is lit by means of Q 6.

Blocking of the amplifier is accomplished by the diodes D 7, D 8 and D 9.

Technical description TP 3000

2m Transmitter

The vco signal is here 21,4 Mhz higher than the receiver input frequency, therefore in order to get the transmitter frequency, a mixer is necessary.

The transmitter mixer is a balanced integrated transistor mixer, IC 1, and the local oscillator is a combined crystal osc/doubler. For simplex operation the crystal therefore must be 10,7 Mhz.

The transmitter amplifier consists of Q 1, Q 2, Q 3 and Q 4 and several tuned circuits in order to get sufficient suppression of unwanted sidebands, and the necessary output power of min. 200 mW to the power amplifier.

The 25 W power amplifier consists of the stages Q 1, Q 2 and Q 3, and a power sensing and regulation circuit IC 1 and Q 4.

From the power sensing circuit, a DC-voltage proportional to the forward output power, is led to the regulation amplifier and compared to a zener reference-voltage, and if the voltage is higher than this reference voltage, the regulation transistor Q 4 will reduce the supply voltage for the driver transistor Q 1 and thereby the output power.

The output power is adjustable between 10-25 W with the potentiometer R 12.

Note that the last two transistors in the power amplifier, are supplied independent of the key.

The TX indicator is driven by the output power.

The power amplifier is followed by the antenna filter which suppresses the harmonics from the transmitter.

Modulation amplifier.

The modulation amplifier consists of Q 7, IC and IC 3. Q 7 is the preamplifier giving a sensitivity of max. 1 mv in 1 K ohm.

It is followed by the preemphasis condenser C 32 and the sensitivity potentiometer P 1.

From here the signal is fed to the amplifier an clipper, IC 3, which limits the max output voltage.


The clipper is followed by IC 2 here used as a 3 Khz active low pass filter. The output to the vco is adjustable with P 2.

When the tone tx input is used, transistor Q7 is blocked via D4.

Technical description TP 3000

Synthesizer

The synthesizer logic in the TP 3000 is based upon the modulus prescaling technique. The principle is shown in the block diagram.



The operation is as follows:

First the prescaler divides by $P+1$, N_m times. Every time a $P+1$ pulse enters the prescaler both the N_m counter and the N_p counter are decremented by 1. This continues until the N_m counter reaches zero. At the end of $(p+1) N_m$ pulses, the state of the N_p counter is equal to $(N_p - N_m)$. Then the modulus of the prescaler is changed to P by the N_m counter. The modulus prescaler continues to divide by P until the remaining count $(N_p - N_m)$ in the N_p counter is decremented to zero. When this is completed, both counters are reset and ready to start a new cycle.

In the TP 3000 an extra control logic, IC 15, is used to control the prescaler and the timing of the two dividers N_p and N_m .

After each count cycle the counter logic delivers an output pulse. This pulse is fed to the phase detector IC 16 and compared to the reference signal in frequency and phase.

When the two signals are either out of phase or frequency, the phase comparator delivers an output voltage proportional to these differences, to the vco which in turn then tries to correct the state.

The reference oscillator consists of IC 4 and a 6,4 Mhz x-tal.

One gate is used as oscillator, the others as buffers.

The main frequency is adjusted by C 95.

The reference signal is divided down to 25 KHz by means of two dividers which are contained in the phasecomparator IC 16.

The comparator output voltage goes through an active low pass filter in order to suppress 25 KHz ripple before entering the vco.

IC 5 gives some DC amplification.

The voltage controlled oscillator consists of Q 11 and L 13, C 70.

The tuning condenser C 70 makes it possible to adjust the vco Frequency within the full 2m band.

The frequency is controlled by the tuning diode, D 12 and the diode D 13 is for the modulation.

The output from the oscillator goes to a common buffer transistor Q 12, and from there to the three output buffers Q 13 to Q 17.

Channel programming

Computation of the channel code.

$$\text{We have} \quad F_{vco} = \frac{MN_{pc} + N_{mc}}{0,025} \text{ Mhz} \quad (1)$$

N_{pc} = division ratio of the "coarse" divider where

$$512 \quad N_{pc} \quad 1023$$

$$M = 10$$

N_{mc} = division ratio of the "fine" divider where

$$0 \quad N_{mc} \quad 127$$

The receiver frequency lies 21,4 Mhz below the vco frequency

$$F_{rx} = \frac{MN_{pc} + N_{mc}}{0,025} - 21,4 \text{ Mhz} \quad (2)$$

$$\text{The total division ratio } NT = \frac{F_{vco}}{0,025} = MN_{pc} + N_{mc} \quad (3)$$

Example 1.

Known is the receiver frequency = 150,025 Mhz.

We want to find the division ratio of both the coarse and fine dividers.

$$\text{We have} \quad F_{vco} = 150,025 + 21,4 = 171,425 \text{ Mhz}$$

$$\text{From (3)} \quad NT = \frac{171,425}{0,025} = 6857$$

Entering table 1. we select $N_{pc} = 681$ and we have further that $M = 10$.

Using (3) once more and rearranging, we get

$$N_{mc} = NT - MN_{pc} = 6857 - (10 \times 681) = 47$$

This might be checked according to the working principle.

Counter N_m is set to 47 and is letting the prescaler count to 11, 47 times. This makes 517 pulses.


Counter N_p is set 681 and decremented with 47 before the prescaler change modulus. When this happens the prescaler counts to 10 (681 - 47) making 6340 pulses.

The total division ratio is then 6340 - 517 = 6857.

Frequency band code

The code of the coarse divider is set once and for all manually by strapping the desired inputs.

By the number 681 this is accomplished as follows.



All inputs are normally high.


The programmed no. is calculated on high inputs.

Channel code

For the channel code a special code plug is used for the strapping procedure, when only one channel is wanted.

In our example we have to program the figure 47.

This is shown below.



The code is read on high inputs.

When more than one channel is wanted another codeplug with a PROM must be used.

It must be noted when programming the PROM, that the input code is BCD + 1.

Channel control box	1	2	4	8	PROM channel
1	0	0	0	0	0
2	1	0	0	0	1
3	0	1	0	0	2
4	1	1	0	0	3
5	0	0	1	0	4
6	1	0	1	0	5
7	0	1	1	0	6
8	1	1	1	0	7
9	0	0	0	1	8
10	1	0	0	1	9
11	0	1	0	1	10
12	1	1	0	1	11

CODES FOR 25 Khz SPACING.

Receiver Frequency Mhz	Coarse divider ratio X10	Prescaler 10/11									
		1	2	4	8	16	32	64	128	256	512
146 - 149	6690	1	0	1	1	1	0	0	1	0	1
147.5 - 150.5	6750	1	1	0	0	0	1	0	1	0	1
149 - 152	6810	1	0	0	1	0	1	0	1	0	1
150.5 - 153.5	6870	1	1	1	1	0	1	0	1	0	1
152 - 155	6930	1	0	1	0	1	1	0	1	0	1
153.5 - 156.5	6990	1	1	0	1	1	1	0	1	0	1
155 - 158	7050	1	0	0	0	0	0	1	1	0	1
156.5 - 159.5	7110	1	1	1	0	0	0	1	1	0	1
158 - 161	7170	1	0	1	1	0	0	1	1	0	1
159.5 - 162.5	7230	1	1	0	0	1	0	1	1	0	1
161 - 164	7290	1	0	0	1	1	0	1	1	0	1
162.5 - 165.5	7350	1	1	1	1	1	0	1	1	0	1
164 - 167	7410	1	0	1	0	0	1	1	1	0	1
165.5 - 168.5	7470	1	1	0	1	0	1	1	1	0	1
167 - 170	7530	1	0	0	0	1	1	1	1	0	1
168.5 - 171.5	7590	1	1	1	0	1	1	1	1	0	1
170 - 173	7650	1	0	1	1	1	1	1	1	0	1
171.5 - 174.5	7710	1	1	0	0	0	0	0	0	1	1

Calculation example:

Wanted is a receiver frequency of 162.725 Mhz.

Step 1. Find the total division ratio according to:

$$NT = \frac{FRx + 21,4}{0.025} = \frac{162.725 + 21,4}{0.025} \text{ Mhz} = 7365.$$

Step 2. Find the division ratio of the coarse divider by entering the table above. Two possibilities are found: 7290 and 7350. We choose 7290. The coarse divider is then coded according to the table. e.i. 1 0 0 1 1 0 1 1 0 1

Step 3. Find the division ratio of the channel divider.

This is simply don by subtracting the coarse division ratio from the total division ratio.:

$$7365 - 7290 = 75$$

This code is written: 1 2 4 8 16 32 64
1 1 0 1 0 0 1

Note that before coding all inputs are "high".

Mark the bits which must be "1" and connect all other bits to chassis.

CODES FOR 20 Khz SPACING.

Receiver Frequency	Coarse divider ratio X 10	Coarse divider code Prescaler 10/11									
		1	2	4	8	16	32	64	128	256	512
Mhz											
146 - 148	8350	1	1	0	0	0	0	1	0	1	1
147 - 149	8400	0	0	0	1	0	0	1	0	1	1
148 - 150	8450	1	0	1	1	0	0	1	0	1	1
149 - 151	8500	0	1	0	0	1	0	1	0	1	1
150 - 152	8550	1	1	1	0	1	0	1	0	1	1
151 - 153	8600	0	0	1	1	1	0	1	0	1	1
152 - 154	8650	1	0	0	0	0	1	1	0	1	1
153 - 155	8700	0	1	1	0	0	1	1	0	1	1
154 - 156	8750	1	1	0	1	0	1	1	0	1	1
155 - 157	8800	0	0	0	0	1	1	1	0	1	1
156 - 158	8850	1	0	1	0	1	1	1	0	1	1
157 - 159	8900	0	1	0	1	1	1	1	0	1	1
158 - 160	8950	1	1	1	1	1	1	1	0	1	1
159 - 161	9000	0	0	1	0	0	0	0	1	1	1
160 - 162	9050	1	0	0	1	0	0	0	1	1	1
161 - 163	9100	0	1	1	1	0	0	0	1	1	1
162 - 164	9150	1	1	0	0	1	0	0	1	1	1
163 - 165	9200	0	0	0	1	1	0	0	1	1	1
164 - 166	9250	1	0	1	1	1	0	0	1	1	1
165 - 167	9300	0	1	0	0	0	1	0	1	1	1
166 - 168	9350	1	1	1	0	0	1	0	1	1	1
167 - 169	9400	0	0	1	1	0	1	0	1	1	1
168 - 170	9450	1	0	0	0	1	1	0	1	1	1
169 - 171	9500	0	1	1	0	1	1	0	1	1	1
170 - 172	9550	1	1	0	1	1	1	0	1	1	1
171 - 173	9600	0	0	0	0	0	0	1	1	1	1
172 - 174	9650	1	0	1	0	0	0	1	1	1	1
173 - 175	9700	0	1	0	1	0	0	1	1	1	1

Calculation example:

Wanted is a receiver frequency of 152.120 Mhz.

Step 1.

Find the total division ratio according to $NT = \frac{FRx + 21,4 \text{ Mhz}}{0,02}$

$$\frac{152.120 + 21,4 \text{ Mhz}}{0,02} = 8676$$

Step 2.

Find the division ratio of the coarse divider by entering the table above. Two possibilities are found 8600 and 8650. We choose 8600 for the coarse divider, which is coded according to the table:

	1	2	4	8	16	32	64	128	256	512
	0	0	1	1	1	0	1	0	1	1

Step 3.

Find the division ratio of the channel divider.

This is simply done by subtracting the coarse division ratio from the total division ratio: $8676 - 8600 = 76$ which is the channel code.

Note that before coding all inputs are in the "high" state.

Mark the bits which must be "1" and connect all other bits to chassis.

On frequencies with an odd spacing ex. 152.130 Mhz, the division ratio here is 8676.5. Go to the lowest integer, that is 8676, and readjust the main frequency. This procedure is valid for frequencies ending on 010 - 030 - 050 - 070 - 090 Khz.

BAND CODES 20 KHz SPACING
Prescaler 32/33

Receiver Frequency MHz	Divider Ratio	Total Ratio Nt.	1	2	4	8	16	32	64	128	256
145.640 - 148.180	261	8352		0		0	0	0	0	0	
146.280 - 148.820	262	8384	0			0	0	0	0	0	
146.920 - 149.46	263	8416				0	0	0	0	0	
147.560 - 150.10	264	8448	0	0	0		0	0	0	0	
148.20 - 150.74	265	8480		0	0		0	0	0	0	
148.84 - 151.38	266	8512	0		0		0	0	0	0	
149.48 - 152.020	267	8544			0		0	0	0	0	
150.120 - 152.660	268	8576	0	0			0	0	0	0	
150.760 - 153.300	269	8608		0			0	0	0	0	
151.400 - 153.94	270	8640	0				0	0	0	0	
152.040 - 154.58	271	8672					0	0	0	0	
152.680 - 155.22	272	8704	0	0	0	0		0	0	0	
153.32 - 155.86	273	8736		0	0	0		0	0	0	
153.96 - 156.50	274	8768	0		0	0		0	0	0	
154.60 - 157.14	275	8800			0	0		0	0	0	
155.24 - 157.78	276	8832	0	0		0		0	0	0	
155.88 - 158.42	277	8864		0		0		0	0	0	
156.52 - 159.06	278	8896	0			0		0	0	0	
157.16 - 159.70	279	8928				0		0	0	0	
157.80 - 160.34	280	8960	0	0	0			0	0	0	
158.44 - 160.98	281	8992		0	0			0	0	0	
159.08 - 161.62	282	9024	0		0			0	0	0	
159.72 - 162.26	283	9056			0			0	0	0	
160.36 - 162.90	284	9088	0	0				0	0	0	
161.00 - 163.54	285	9120		0				0	0	0	
161.64 - 164.18	286	9152	0					0	0	0	
162.28 - 164.82	287	9184						0	0	0	
162.92 - 165.46	288	9216	0	0	0	0	0		0	0	
163.56 - 166.10	289	9248		0	0	0	0		0	0	
164.20 - 166.74	290	9280	0		0	0	0		0	0	
164.84 - 167.38	291	9312			0	0	0		0	0	
165.48 - 168.02	292	9344	0	0		0	0		0	0	
166.12 - 168.66	293	9376		0		0	0		0	0	
166.76 - 169.30	294	9408	0			0	0		0	0	
167.40 - 169.94	295	9440				0	0		0	0	
168.04 - 170.58	296	9472	0	0	0		0		0	0	
168.68 - 171.22	297	9504		0	0		0		0	0	
169.32 - 171.86	298	9536	0		0		0		0	0	
169.96 - 172.50	299	9568			0		0		0	0	
170.60 - 173.14	300	9600	0	0			0		0	0	
171.24 - 173.78	301	9632		0			0		0	0	
171.88 - 174.42	302	9664	0				0		0	0	

Note: This code table is only valid for sets manufactured after 1.8.1987.
Using a dual modulus prescaler with the division ratio 32/33.

BAND CODES 25 Khz SPACING
 PRESCALER 32/33

Receiver Frequency Mhz	Divider Ratio	1	2	4	8	16	32	64	128	256
145.800 - 148.975	209 32 6688	0	0	0	0	0	0	0	0	0
146.600 - 149.775	210	0	0	0	0	0	0	0	0	0
147.400 - 150.575	211	0	0	0	0	0	0	0	0	0
148.200 - 151.375	212	0	0	0	0	0	0	0	0	0
149.000 - 152.175	213	0	0	0	0	0	0	0	0	0
149.800 - 152.975	214	0	0	0	0	0	0	0	0	0
150.600 - 153.775	215	0	0	0	0	0	0	0	0	0
151.400 - 154.575	216	0	0	0	0	0	0	0	0	0
152.200 - 155.375	217	0	0	0	0	0	0	0	0	0
153.000 - 156.175	218	0	0	0	0	0	0	0	0	0
153.800 - 156.975	219	0	0	0	0	0	0	0	0	0
154.600 - 157.775	220	0	0	0	0	0	0	0	0	0
155.400 - 158.575	221	0	0	0	0	0	0	0	0	0
156.200 - 159.375	222	0	0	0	0	0	0	0	0	0
157.000 - 160.175	223	0	0	0	0	0	0	0	0	0
157.800 - 160.975	224	0	0	0	0	0	0	0	0	0
158.600 - 161.775	225	0	0	0	0	0	0	0	0	0
159.400 - 162.575	226	0	0	0	0	0	0	0	0	0
160.200 - 163.375	227	0	0	0	0	0	0	0	0	0
161.000 - 164.175	228	0	0	0	0	0	0	0	0	0
161.800 - 164.975	229	0	0	0	0	0	0	0	0	0
162.600 - 165.775	230	0	0	0	0	0	0	0	0	0
163.400 - 166.575	231	0	0	0	0	0	0	0	0	0
164.200 - 167.375	232	0	0	0	0	0	0	0	0	0
165.000 - 168.175	233	0	0	0	0	0	0	0	0	0
165.800 - 168.975	234	0	0	0	0	0	0	0	0	0
166.600 - 169.775	235	0	0	0	0	0	0	0	0	0
167.400 - 170.575	236	0	0	0	0	0	0	0	0	0
168.200 - 171.375	237	0	0	0	0	0	0	0	0	0
169.000 - 172.175	238	0	0	0	0	0	0	0	0	0
169.800 - 172.975	239	0	0	0	0	0	0	0	0	0
170.600 - 173.775	240	0	0	0	0	0	0	0	0	0
171.400 - 174.575	241	0	0	0	0	0	0	0	0	0
172.200 - 175.375	242	0	0	0	0	0	0	0	0	0
173.000 - 176.175	243	0	0	0	0	0	0	0	0	0
173.800 - 176.975	244	0	0	0	0	0	0	0	0	0

Note: This code table is only valid for sets manufactured after 1.8.1987 using a dual modulus prescaler with the division ratio 32/33.

TUNING INSTRUCTIONS TP 3000 2m.

SYNTHESIZER.

First of all the set must be coded to the right channel, and the lock det. must be coded to switch all the unused channels off with bit 128 on Prom. This is done according to the instructions contained in the technical description of the synthesizer circuit.

Check the channel code and if the set contains more than one channel, select one in the middle of the band.

Check the reference oscillator with an oscilloscope on IC 4 pin 4 on print board TP103.

Connect a high input resistance DC-voltmeter to MP3, and turn the trimmer-condenser C70 until a voltage movement is obtained. Then adjust C70 until a reading of app. 4 volts is obtained. The VCO is now in lock.

Connect a frequency counter to the TX mixer output in the VCO, and adjust the VCO frequency to FRX + 21,4 Mhz by means of C95 in the ref. oscillator. Check the lock range by turning C70 and read the values on MP3. The trimmer C70 should be turned app. on full turn before going out of lock, and the voltage on MP3 should vary correspondingly from 1 - 7 volts.

In multichannel sets, select the lowest and highest channel and check that the loop still goes into lock.

If the loop is out of lock, the lock det. will switch the transmitter off. The sensitivity of the VCO is app. 1 Mhz/V, which means that within the max. bandwidth of 2 Mhz, the loop voltage must be between 3 - 5 volts. C 66 - 5,6p must be changed together with C 71 for lower frequency purposes.

TUNING OF THE RECEIVER

21,4 Mhz and 455 Khz IF.

Connect a 21,4 Mhz sweep Generator to the gate of Q 2 on print board TP103, and the DC-probe to MP 2.

Adjust L7 and L8 to min. ripple. L9 and L10 are tuned to max. amplitude and best possible symmetry.

Notice that the input level from the sweep generator is kept below the limiting level of the second mixer.

Connect the probe to the "disc out" pin, and adjust L11 to max. discriminator slope and best linearity.

Or: Use a 30 Mhz scope on D4 (10mV range) and a signal generator on antenna input and tune L7-8-9-10 to max. signal and min. distortion. Reduce input signal to 5uV. Move scope to disc. out and tune to min. dist. and max. output (200 mV pp range). The signal gen. is modulated with 1000 Hz and 8 Khz deviation. Test the sensitivity with 1000 Hz and 3 Khz deviation.

Or: Use signalgenerator and Dc. millivoltmeter in 100 mV range and adjust all circuits to max. output on MP2. Keep DC millivoltmeter 100 mV range and decrease signalgenerator.

At last adjust detector output on L11 with oscilloscope to min. distortion in 200 mV pp range.

TUNING INSTRUCTIONS TP 3000 2m.

RF-amplifier and mixer.

Connect a DC-voltmeter to MP1 and adjust L5 and L6 to max. deflection appr. 0.7 volt DC.

Connect a signal generator to the receiver input, and adjust L1, L2, L3 and L4 to max. sensitivity, which should be appr. 0.5 μ V e.m.f. at 20 db SINAD.

AF-amplifier and squelch.

Connect the signal generator to the receiver input, adjust the attenuator to 1mV and deviation to \pm 3 Khz at 1000 Hz.

Connect an AF-millivoltmeter to the "disc.out" and read app. 120 mV R.M.S. Connect a 4 ohm, 5 W resistor to the loudspeaker output and an AC-voltmeter accross the resistor. Adjust the volume control to the last but one step and read app. 3 VAC.

TUNING OF THE TRANSMITTER

Transmitter mixer and amplifier TP 106.

Connect a DC-voltmeter to MP1 and adjust C25-L11-L12-L2-L3 to max. deflection. Start up tuning with 30 Mc scope on C 25-L11-L12 in 50 mV range.

Check with a high frequency AC-voltmeter the VCO injection on the VCO input and read app. 0.2 VAC.

Connect the DC-voltmeter to MP3 and adjust L4 to max. deflection.

Move the probe to MP4 and tune L5 and L6 to max. app. 1.0 VDC.

Tune L7 and L8 to max. on MP5 app. 1.4 volts.

Now connect a wattmeter to the output of the amplifier, TP 6 and tune to max output power by means of (C23) L9-L10.

The output power should be app. 200 mW into 50 ohm.

Note that the condenser Cx accross the coil L11-L12, must be changed when the Tx-x-tal is changed.

When x-tal is 10,7 Mhz Cx is 22 pF.

When x-tal is higher than 10,7 Mhz Cx is 10 pF.

When x-tal is lower than 10,7 Mhz Cx is 47 pF.

Transmitter output stage TP 107.

Connect a wattmeter (50 ohm, 25W) to the transmitter output.

Set the supply voltage to 12,0 volt.

Turn the potentiometer R12 counter-clockwise to get the output power stabilization out of function.

Key the transmitter and adjust C3, C32 and C33 to max. output power.

Increase the supply voltage to 13,2 V and turn the potmeter clockwise until the desired output power is reached.

It is not recommended to use higher outputs than 25 watts.

Transmitter frequency.

Connect a frequency counter to the wattmeter and adjust the transmitter frequency with the capacitor C48 on print board TP 106. Check the VCO frequency before setting the Tx frequency.

Modulation amplifier TP 106.

Connect a deviationmeter to the transmitter output and a tonegenerator to the modulation input.

Turn the potentiometers P1 and P2 to center position and set the tonegenerator frequency to 1000 Hz.

With an input level of 20 mV. the potentiometer P2 is adjusted to give \pm 5Khz deviation.


TUNING INSTRUCTIONS TP 3000 2m.

Modulation amplifier TP 106

Decrease the input level 20 db to 2 mV an adjust P1 to give +/- 3 Khz deviation.

Repeat the procedure and readjust if necessary.

With an input level of 20 mV, check the symmetry of the limited signal. + and - deviation should not differ more than 0,5 Khz.




Block diagram TP 3000 Receiver - Transmitter

JS 13.03.79

TP RADIO

DRAWING NO. EA4 790303



* When tone selection is used, cut and connect to B and A.

TP 101A+ TP102 A
 Betjeningsbox 1-12 kanal
 med -uden selektiv


TP RADIO


EA3 790310

J S 13.03.79

DRAWING NO.

EA3 790310






TP 11. 02.80
 DRAWING NO
 EA3-800201

Mobil control box, BB2
 print board
 TP18B + TP19A

TP RADIO

90001 Jul 11 Red 120



MOBIL CONTROL BOX BB3
 PRINT BOARD
 TP 136 TP 137

TP RADIO


TP 06 12 82
 DRAWING NO.
 EA3-821201

16 17 18 19 20 21 22 23
 CHASSIS ON/OFF
 KEY
 SEL KEY
 SP OFF
 VOLUME
 SQUELCH

5 6 7 8 9 10 11 12 13
 UP DOWN
 VOLUME DOWN
 CHANNEL 1-9
 TX ON
 OCCUPIED
 TX OFF

TEENS
 ONES

D-9




Base station control
box print board
TP111 + TP 114

TP RADIO


TP 28.08.79
DRAWING NO.

EA3791023



6/12-86
 JS
 TP103 2M
 RECEIVER - PLL - POWERSUPPLY
 TP RADIO
 EA3-86112





TP103 2M 2ND EDITION
RECEIVER - PLL - POWERSUPPLY





14/8-87


JS

TP RADIO


EA3-870803

- BAND CODE
- 256
 - 128
 - 64
 - 32
 - 16
 - 8
 - 4
 - 2
 - 1





<p>Component Lay out Print TP103 Receiver - Logic - VCO - Powersupply</p>	<p>JS 28.08.79 COR.05.01.87</p>
<p>TP RADIO</p>	<p>DRAWING NO. EA4-790821</p>




COMPONENT LAY-OUT
TP103 2m and 4m

JS
08. 09. 87.

TP RADIO

EA3-870909



MOD. AMP Tx OSC - MIXER AND AMPLIFIER FOR VHF PRINT BOARD TP 106

FIND X1 FREQUENCY BY USING FORMULA

$$R_x + \frac{21.4 \text{ MHz} - T_x}{2} = X_1 \text{ in MHz}$$

CX1 = 47pF when X1 < 10.7 MHz

CX1 = 2.2pF when X1 = 10.7 MHz

CX1 = 10pF when X1 > 10.7 MHz

VHF TRANSMITTER 2M.


PRINT BOARDS TP107-TP106B

TP RADIO

13.12.86

JS

EA3 861113




Component lay out print board TP 107
 2,5- 25W PA-STAGE 2m


JS 28.08.79
 COR.05.01.87

TP RADIO

DRAWING NO.
 EA4-790820



01. 04. 87 AP	EA3 - 870602
Component lay out TP 106 B	TP RADIO




Print board TP 121
 Code plug for max. 12 channels
 with lock control circuit

13. 05. 80
 JS

TP RADIO

DRAWING NO.

EA4-800503




Ptint board 123
Code plug 1 channel with lock control

29. 07. 80
TP

TP RADIO

DRAWING NO.

EA4-800711





Print board TP 124
 Code plug for max 2 channels
 with lock control circuit

25. 08. 80 TP

TP RADIO

DRAWING NO
 EA4-800815




Print board TP 117
Volume down control and AF-Buffer
amplifier

JS 9. 11. 79

TP-RADIO


DRAWING NO
EA4-791124




MAIN WIRING TP 3000
 1-12 CHANNELS WITH TONE
 SYSTEM 2M - 4M
 6 - 25WATT

JS 28, 08, 80
 08, 09, 87


DRAWING NO.
EA3-790305



The "R" contacts may operate signal horn relay.



Installation TP 3000 Control box BB2 + BB3	JS. 27.08.81
TP RADIO	DRAWING NO. EA4-800710



Installation of TP 3000
1-12 channels

JS 28.08.79

TP RADIO

DRAWING NO.
EA4-790304